



**ROHDE & SCHWARZ**

Test and  
Measurement Division

## **Operating Manual**


# **VISA RSIB PASSPORT**

Printed in the Federal  
Republic of Germany

## **Contents**

<b>1</b>	<b>Overview</b>	<b>3</b>
<b>2</b>	<b>Installation</b>	<b>3</b>
<b>3</b>	<b>Passport</b>	<b>4</b>
	R&S attributes	4
	Header file "RsViRsib.h"	4
	Events	4
	Passport name	4
	RsViRsib.ini file	5

## 1 Overview



This overview shows how to control the instrument via the passport (RsViRsib.dll) which in turn requires the RSIB interface (Rsib32.dll).

## 2 Installation

Start **Setup.exe** on the installation CD. If NI-VISA has not been installed, setup is interrupted. To be VISA-conformal, use the recommended installation path.

The following requirements must be fulfilled:

- **NI – VISA 2.5** library or higher must be installed.
- The user must have administrator rights (Windows NT, Windows 2000).

The following files are contained in these directories:

- **RSIB32.dll** in the Windows system directory (e.g. C:\WinNT\System32).
- **RsViRsib.dll** passport DLL in the VISA Bin directory which may have the designation C:\VXIpn\WinNT\Bin\.
- **RsViRsib.ini** passport INI file in the VISA directory C:\VXIpn\WinNT\ in the ...**RSIB\** subdirectory.
- The entries below can be found under the registration database key **HKEY\_LOCAL\_MACHINE\SOFTWARE\National Instruments\NI-VISA for Windows 95/NT\CurrentVersion\NoLibraries\RsViRsib.dll**
  - LibraryDescription VISA Library Passport for RSIB-INSTR V1.1
  - LibraryEnabled 0x00000001
  - LibraryPath C:\VXIpn\WinNT\Bin\RsViRsib.dll

## 3 Passport

### R&S attributes

Besides the VISA attributes, the programmer may also use the Rohde & Schwarz attributes:

Attribute	Description
<b>RS_ATTR_RSIB_VER</b>	Passport version; formatting according to VPP 4.3; read only e.g. 0x00100100UL (1.1)
<b>RS_ATTR_RSIB_SRE</b>	Switches the unit to LOCAL (0) or REMOTE (1).
<b>RS_ATTR_RSIB_LOC</b>	Switches the unit temporarily to LOCAL (no transfer parameters!).

### Header file "RsViRsib.h"

The header file contains all Rohde & Schwarz-specific attributes that are supported by the passport in addition to the VISA attributes. To address these attributes from a C program, simply insert the header file.

### Events

Only the VI\_EVENT\_SERVICE\_REQ and VI\_EVENT\_IO\_COMPLETION events are supported.

### Passport name

The instrument name is structured as follows:

Examples: RSIB::192.168.1.33::INSTR or RSIB::PC-ABC::INSTR

	Description
<b>RSIB</b>	passport prefix, passport type
<b>::</b>	separator
<b>a.b.c.d</b>	host address
<b>PC-ABC</b>	host name
<b>::</b>	separator
<b>INSTR</b>	resource type (instrument)

## **RsViRsib.ini file**

This file lists all resources which can be read by means of the viFindRsrc() VISA function. It is contained in the installed directory under ...\\Rsib. If the passport cannot find the INI file in the installed directory, it searches also the standard VISA directory (e.g. C:\\VXI\\pnp\\WinNT) under ...\\Rsib. Entries in MAX or VISAIC are made only if resources are listed. The passport is nevertheless integrated so that the user can still start sessions.

Extract:

```
[RSIB-RSRC-ALIAS]
Name0 = "RSIB::192.168.1.33::INSTR"
Name1 = "RSIB::192.168.1.37::INSTR"
Name2 = "RSIB::PC-ABC::INSTR"
```

The TCP/IP address can be entered in decimal, octal or hexadecimal notation.