


















# CP-1 BOARD (SV-A) SERVO



## SERVO CIRCUIT WAVEFORMS (IC351:BU2896 Series)

TEST LOCATION	WAVEFORM & MODE/LEVEL	TEST LOCATION	WAVEFORM & MODE/LEVEL
<b>Pin 40</b> (H.A.SWITCHING)	<b>SLOW PB</b> 	<b>Pin 11</b> (COMPOSITE SYNC INPUT)	
<b>Pin 42</b> (PWM)		<b>Pin 14</b> (C-FG PULSE)	
<b>Pin 41,44,1</b> (PWM)		<b>Pin 15</b> (CTL PULSE)	<b>PB</b> 
<b>Pin 3</b> (FSC INPUT)		<b>Pin 26</b> (CTL AMP OUT)	<b>PB</b> 
<b>Pin 5</b> (ROTARY)	<b>PB</b> 	<b>Pin 28</b> (C-FG INPUT)	
<b>Pin 8</b> (D-PG MM)		<b>Pin 29</b> (D-FG INPUT)	
<b>Pin 9</b> (RF SW PULSE)		<b>Pin 30</b> (D-PG INPUT)	
<b>Pin 10</b> (AF SW PULSE)	<b>PB</b> 	<b>Pin 38</b> (ENV.SW INPUT)	<b>SLOW PB</b> 

WF-S-CE6