



A



A Tuner amplifier

- ① **Standby/on switch (⏻/⏻)**
Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.
- ② **Standby indicator (⏻)**
When the unit is connected to the AC mains supply, this indicator lights up in standby mode and goes out when the unit is turned on.
- ③ **Play timer/record timer button and indicator (⏻PLAY/⏻REC)**
- ④ **ECO mode button (MODE)**
- ⑤ **Clock/timer, demo button (CLOCK/TIMER, -DEMO)**
- ⑥ **FM mode button (FM AUTO/MONO)**
- ⑦ **6ch discrete input button (6CH DISCRETE INPUT)**
- ⑧ **Source input button (INPUT SELECTOR)**
- ⑨ **Tuner/band button (TUNER/BAND)**
- ⑩ **Digital super woofer button and indicator (DIGITAL S.WOOFER)**
- ⑪ **Volume control (VOLUME)**
- ⑫ **Headphone jack (PHONES)**
- ⑬ **Tuning mode button (TUNING MODE)**
- ⑭ **Set button (SET)**
- ⑮ **Tuning buttons (⏮, ⏭ TUNING)**
- ⑯ **RDS display mode buttons (RDS, PS-DISP MODE-PTY)**

B



B Remote controls

- Buttons ①, ⑨-⑪, ④⑤, ④⑦ and ④⑧ function in the same way as the controls on the main unit.
- ⑥① **Sleep timer button (SLEEP)**
 - ⑥② **Numbered buttons (1-9, 0, ≥10/-/-)**
 - ⑥③ **Cursor buttons (⏮, ⏭, ⏴, ⏵)**
 - ⑥④ **Channel select button (CH SELECT)**
 - ⑥⑤ **Test button (TEST)**
 - ⑥⑥ **Input select button (VCR/AUX/6CH INPUT)**
 - ⑥⑦ **TAPE select, deck 1/deck 2 select button (TAPE/DECK 1/2)**
 - ⑥⑧ **CD pause/Tape reverse playback button (⏮/⏮)**
 - ⑥⑨ **Muting button (MUTING)**
 - ⑦① **Program button (PROGRAM)**
 - ⑦② **Cancel button (CANCEL)**
 - ⑦③ **Disc button (DISC)**
 - ⑦④ **EQ button (EQ)**
 - ⑦⑤ **AV effect button (AV EFFECT)**
 - ⑦⑥ **CD button (CD)**
 - ⑦⑦ **CD play/tape forward playback button (⏭)**
 - ⑦⑧ **CD/tape stop button (■)**
 - ⑦⑨ **CD skip/search, tape fast forward/rewind buttons (⏮/⏮, ⏭/⏭)**