



- ②0 Random play button (RANDOM)
- ②1 Repeat play button (REPEAT)
- ②2 CD edit button (EDIT)
- ②3 Disc tray open/close button (▲, OPEN/CLOSE)
- ②4 Skip/search buttons (◀◀/◀, ▶▶/▶▶)
- ②5 Disc tray
- ②6 Stop button (■)
- ②7 Pause button (||)
- ②8 Play button and indicator (▷)

The colour of the indicator depends on the operation taking place.

If stopped: orange

If playing: green

If paused: flashes