



NOTE:
The number which noted at the connectors on the schematic diagram as "SCHEMATIC DIAGRAM-1" or "SCHEMATIC DIAGRAM-2" indicates the schematic diagram serial number located on the left corner in the schematic diagram.




SCHEMATIC DIAGRAM-2

→ : POSITIVE VOLTAGE LINE ⇨ : CD SIGNAL LINE



→ : POSITIVE VOLTAGE LINE

B LOADING MOTOR CIRCUIT



D OPERATION CIRCUIT

