


2. Sonderfunktionen


Aufrufen der Sonderfunktionen

- Auf der Fernbedienung Taste "CODE" drücken
- Codenummer eingeben
- Taste "OK" drücken.

Aktivieren des Zahlenschlosses:

- Auf der Fernbedienung Taste  drücken
- "Geheimzahl" eingeben und Taste "OK" drücken.

Zahlenschloß entriegeln

- Auf der Fernbedienung Taste "CODE" drücken
- Zahlenfolge 4 9 3 4 eingeben
- Taste "OK" und anschließend Taste  drücken.

2.1 GV 200..., GV 211, SE 2100 VPS, MV 2005, GV 2092 VPS

Code + OK	Funktion	Display zeigt
8510	V-Impuls-Eintastung "AUS"	-
8511	V-Impuls-Eintastung "EIN"	-
8516	Fernbedienebene "VIDEO 1" (siehe Bedienungsanleitung)	VID 1
8517	Fernbedienebene "VIDEO 2" (siehe Bedienungsanleitung)	VID 2
8518	Modulator ausgeschaltet	-
8519	Modulator eingeschaltet	-
8526	10- und 16-Bit-Geberbefehle werden angenommen (siehe Bedienungsanleitung)	VID 1/2
8527	16Bit-Geberbefehle werden angenommen (siehe Bedienungsanleitung)	VID 1/2
8528	Abgleich V-Impuls-Eintastung (siehe Bedienungsanleitung)	A7
8562	Piezo "AUS" (nur bei GV 2092 VPS)	-
8563	Piezo "EIN" (nur bei GV 2092 VPS)	-

2.2 GV 201 VPT, GV 201 GB


Code + OK	Funktion	Display zeigt
8516	Fernbedienebene "VIDEO 1" (siehe Bedienungsanleitung)	VID 1
8517	Fernbedienebene "VIDEO 2" (siehe Bedienungsanleitung)	VID 2
8518	Modulator ausgeschaltet	-
8519	Modulator eingeschaltet	-
8526	10- und 16-Bit-Geberbefehle werden angenommen (siehe Bedienungsanleitung)	VID 1/2
8527	16Bit-Geberbefehle werden angenommen (siehe Bedienungsanleitung)	VID 1/2
8528	Abgleich V-Impuls-Eintastung (siehe Bedienungsanleitung)	A7
8546	ohne Zeilensprung (312/312) - für FFS-Geräte mit 50Hz Bildwechselfrequenz	-
8547	mit Zeilensprung (312/313) - z.B. für FFS-Geräte mit 100Hz Bildwechselfrequenz	-

2. Special Functions


Calling up the Special Functions

- Depress the "CODE" button
- Feed in the Code Number
- Depress the "OK" button.

Activating the Security Code:

- Depress the  button
- Feed in the "Security Code" and depress the "OK" button.

Cancelling the Security Code:

- Press the "CODE" button on the Remote Control.
- Enter the numbers 4 9 3 4 sequentially.
- Press the "OK" button and then the button .

2.1 GV 200..., GV 211, SE 2100 VPS, MV 2005, GV 2092 VPS

Code + OK	Function	Display shows
8510	V-pulse insertion "OFF"	-
8511	V-pulse insertion "ON"	-
8516	Remote Control Level "VIDEO 1" (Refer to the Operating Book)	VID 1
8517	Remote Control Level "VIDEO 2" (Refer to the Operating Book)	VID 2
8518	Modulator "OFF"	-
8519	Modulator "ON"	-
8526	10 and 16 bit transmitter commands are accepted (Refer to the Operating Book)	VID 1/2
8527	16 bit transmitter commands are accepted (Refer to the Operating Book)	VID 1/2
8528	Adjustment of the V-pulse insertion (Refer to the Operating Book)	A7
8562	Piezo "OFF" (only with GV 2092 VPS)	-
8563	Piezo "ON" (only with GV 2092 VPS)	-

2.2 GV 201 VPT, GV 201 GB

Code + OK	Function	Display shows
8516	Remote Control Level "VIDEO 1" (Refer to the Operating Book)	VID 1
8517	Remote Control Level "VIDEO 2" (Refer to the Operating Book)	VID 2
8518	Modulator "OFF"	-
8519	Modulator "ON"	-
8526	10 and 16 bit transmitter commands are accepted (Refer to the Operating Book)	VID 1/2
8527	16 bit transmitter commands are accepted (Refer to the Operating Book)	VID 1/2
8528	Adjustment of the V-pulse insertion (Refer to the Operating Book)	A7
8546	No line interlacing (312/312) - for CTV models with 50Hz frame frequency.	-
8547	With line interlacing (312/313) - for CTV models with 100Hz frame frequency.	-