# RONDA startech – Movement Cal. 4120.B

User's Manual English

You have decided to buy a watch, which was assembled by a watch-maker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda Brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.


Description of the display and control buttons

Display elements

Minute hand
Hour hand
Alarm and reference time (hour and minute)
Second hand
Date

Control buttons

Crown
Push-button

01

Setting the time

❶* Pull out the crown to position **III** (the watch stops).

❷ Turn the crown until you reach the correct time **8:45**.

❸* Push the crown back into position **I**.

Please note:
* In order to set the time to the exact second, ❶ must be pulled out when the second hand is in position «60».
Once the hour and minute hands have been set, ❸ must be pushed back into position **I** at the exact second.

02

Setting the date (quick mode)

❶ Pull out the crown to position **II** (the watch continues to run).

❷ Turn the crown until the correct date **01** appears.

❸ Push the crown back into position **I**.

Please note:
The date of the following day must be set in the calendar changing phase between approx. 9 PM and midnight.

Setting the date too quickly in quick mode can result in the incorrect date being displayed. Switching the date between 01 and 31 (position II) restores the synchronisation.

03

Setting the time and date

Example:
– Date / time on the watch: **17** / 1:25 AM
– Present date / time: **04** / 8:30 PM

❶ Pull out the crown to position **II** (watch continues to run).

❷ Turn the crown until yesterday's date appears **03**.

❸ Pull out the crown to position **III** (the second hand stops. The display changes from alarm time to reference time.)

❹ Turn the crown until the correct date **04** appears.

❺* Continue to turn the crown until the current time 8:30 PM appears.

❻ Push the crown back into position **I** (the display changes from reference to alarm time).

Please note:
Resetting the time also requires the identical correction of the reference time.
Please refer to «setting the reference time».

* Please observe the AM/PM clock rhythm.

04

Setting the alarm time

❶ **Activate the setting mode**
Press the push-button for at least 2 seconds. As soon as the small minute hand jumps forward 1 minute, this mode is active.

❷ **Setting**
Short pressing (less than 1 second):
the alarm time is moved forward by the minute.
Long pressing (longer than 2 seconds):
the alarm time is moved forward until the push-button is released.

Please note:
If the push-button is not activated for 10 seconds, the setting mode of the alarm time deactivates itself. At the same time, 2 beeps are emitted to indicate that the alarm is switched on.

05

Switching the alarm on / off

❶ The alarm is switched on / off by briefly pressing the push-button:

2 beeps → alarm switched on

1 beep → alarm switched off

Please note:
The alarm can be set maximum 12 hours before the desired alarm time.

Once the set alarm time has been reached, a signal is emitted for 20 seconds. This signal is repeated after two minutes. Following brief pressing of the push-button, the signal is immediately switched off.

06

Setting the reference time

❶ Pull out the crown to position **III** (second hand stops. The display changes from alarm time to reference time.)

❷ **Activating the setting mode**
Press the push-button for at least 2 seconds. As soon as the small minute hand jumps forwards one minute, this mode is active.

❸ **Short pressing** (less than 1 second):
the reference time is moved forwards by the minute.

Medium pressing (1–2 seconds):
the reference time is moved forwards by the hour.

Long pressing (longer than 2 seconds):
the reference time is moved forwards until the push-button is released.

❹ Push the crown back into position **I** (the display changes from reference time to alarm time).
A 1 beep signal indicates that the alarm is switched off.

Please note:
The reference time must display the same time as the current time. This means that resetting the current time also requires the identical correction of the reference time. Afterwards, the alarm time has to be reset.

What is the reference time?

The current time is displayed by means of the hour and minute hand.

Parallel to the current time, the reference time runs in the background: the alarm time refers itself to this reference time. Thus, resetting the time also requires the identical correction of the reference time.

If the reference time is not synchronised with the current time, this results in the alarm signal being emitted at a different time to the set alarm time.

07