# Service Sheet Of MC-00AA

<RF STEREO & NICAM>

<AV STEREO>

## MC-00AA SCHEMATIC DIAGRAM

SOUND-MAX(UBB BOARD)









NOTICE

Since this is basic circuit diagram, the value of components and some partial connection are subject to be changed for improvement without notice.

The components marked ⚠ conform to VDE or IEC guide-lines and are essential for safe operation of the TV receiver.
While those marked ⚠ are required for correct operation.
Use specified parts only when replacing.

### Value of resistor, capacitor and inductor

1. Resistances are shown in ohm. K=1 000. M=1 000 000.
2. Unless otherwise noted in schematic, all capacitor values less than 1 are expressed in mfd and the values more than 1 in pF.
3. Unless otherwise noted in schematic, all inductor values more than 1 are expressed in μH and the values less than 1 in Henry(H).

### Observation of voltages and waveforms

1. Voltages read with VTVM from point to chassis ground.
   line voltage is 220H/-20% voltage, signal pattern is colour-bar.
2. The schematic shown is representative only.
3. All waveforms are taken using a wide band oscilloscope and a low capacity probe.
4. Check FINE TUNING, AGC, CONTRAST, BRIGHTNESS and COLOUR controls for best picture. Make sure that COLOUR and BRIGHTNESS are in mid-point and CONTRAST is in MAX.
5. Waveforms are taken using a standard colour signal.

## <SYSTEM OPTION>

### 1 RF STEREO

| | | | | | |
|---|---|---|---|---|---|
| | | | | | |
| | | | | | |
| | | | | | |