VIDEO MAIN SIGNAL PATH IN REC MODE
VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE
AUDIO MAIN SIGNAL PATH IN REC MODE
AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE

IC3901 AN3581S
IC3903 C1AB00001340
IC3902 LA73021M
Q3902 2SD601A (AMP)
Q3905 2SD1328 (RGB ON:ON)
Q3901 UN2212 (RGB OFF H:ON)
QR3901 UN2212 (RGB OFF H:ON)
QR3902 UN2113 (AV3 L:ON)
QR3903 UN2113 (RGB ON:ON)
Q3903 2SD601A (PROG H:ON)
Q3904 2SD601A (PROG H:ON)
Q3906 2SD601A (AMP)
Q3907 2SB709A (INV.)

PS3902 TO HI-FI AUDIO SECTION (FP9302(E-1))
PS3905 TO HI-FI AUDIO SECTION (FP9305(C-1))
PS3904 TO HI-FI AUDIO SECTION (FP9304(E-1))
PS3903 TO HI-FI AUDIO SECTION (FP9303(E-1))
PS3901 TO HI-FI AUDIO SECTION (FP9301(G-1))

AV OUT JK3902 VJJ0416
AV1 JK3906 VJS1470 (TV)
AV2 JK3905 VJS1470 (DECODER/EXT)
S-VIDEO OUT JK3904 VJJ0574
LANC JK3907 VJJ0169
JK3908 K2HZ105A0002

AV1 OUT NORMAL S

NOTE:THE MEASUREMENT MODE OF THE DC VOLTAGE IN THE BRACKETS( )ON THIS DIAGRAM IS RECORD MODE WITH PAL COLOUR SIGNAL.(SP MODE)

THE MEASUREMENT MODE OF THE DC VOLTAGE OUT OF THE BRACKETS ON THIS DIAGRAM IS PLAYBACK MODE WITH PAL COLOUR SIGNAL.(SP MODE)

NOTE: DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NV-HS870EG/B/EC
INPUT/OUTPUT PACK SCHEMATIC DIAGRAM