


80386 Hardware Reference Manual





LITERATURE

To order Intel literature write or call:

Intel Literature Sales P.O. Box 58130 Santa Clara, CA 95052-8130 Intel Literature: (800) 548-4725

Use the order blank on the facing page or call our Toll Free Number listed above to order literature. Remember to add your local sales tax and a 10% postage charge for U.S. and Canada customers, 20% for outside U.S. customers. Prices subject to change.

1987 HANDBOOKS

Product line handbooks contain data sheets, application notes, article reprints and other design information.

MAME	ORDER NUMBER	*PRICE IN U.S. DOLLARS
COMPLETE SET OF 9 HANDBOOKS Save \$50.00 off the retail price of \$175.00	231003	\$125.00
MEMORY COMPONENTS HANDBOOK	210830	\$18.00
MICROCOMMUNICATIONS HANDBOOK	231658	\$20.00
EMBEDDED CONTROLLER HANDBOOK (includes Microcontrollers and 8085, 80186, 80188)	210918	\$18.00
MICROPROCESSOR AND PERIPHERAL HANDBOOK (2 Volume Set)	230843	\$25.00
DEVELOPMENT TOOLS HANDBOOK	210940	\$12.00
DOS DEVELOPMENT SOFTWARE CATALOG	280199	N/C
OEM BOARDS AND SYSTEMS HANDBOOK	280407	\$18.00
MILITARY HANDBOOK	210461	\$18.00
COMPONENTS QUALITY/RELIABILITY HANDBOOK	210997	\$20.00
SYSTEMS QUALITY/RELIABILITY HANDBOOK	231762	\$20.00
PROGRAMMABLE LOGIC HANDBOOK (Not included in Handbook Set)	296083	\$18.00
PRODUCT GUIDE Overview of Intel's complete product lines	210846	N/C
LITERATURE PRICE LIST List of Intel Literature	210620	N/C
INTEL PACKAGING OUTLINES AND DIMENSIONS Packaging types, number of leads, etc.	231369	N/C

^{*}These prices are for the U.S. and Canada only. In Europe and other international locations, please contact your local Intel Sales Office or Distributor for literature prices.



LITERATURE SALES ORDER FORM

NAME:			
COMPANY:			
ADDRESS:			
CITY:	STATE: _	ZIP:	
COUNTRY:			
PHONE NO.: ()			
ORDER NO.	TITLE	QTY. PRICE	TOTAL
		×	_=
		×	_=
		×	_=
		×	_=
		×	_=
		×	=
		Must Add Your Local Sales Tax	·
Must add appropriate postage to subtotal	•		
(10% U.S. and Canada, 20% all other)		•	
Pay by Visa, MasterCard, American Expres	oo Chook Manay Ordar ar		
to Intel Literature Sales. Allow 2-4 weeks	for delivery.		e order payable
☐ Visa ☐ MasterCard ☐ American Ex	•		
Signature:			
		us autaida tha 11	C and Canada
Mail To: Intel Literature Sales P.O. Box 58130 Santa Clara, CA 95052-8130	International Custome should contact their localisted in the back of mo	al Intel Sales Offic	

Call Toll Free: (800) 548-4725 for phone orders

Prices good until 12/31/87.

Source HB

Mail To: Intel Literature Sales

P.O. Box 58130

Santa Clara, CA 95052-8130



80386 HARDWARE REFERENCE MANUAL

Intel Corporation makes no warranty for the use of its products and assumes no responsibility for any errors which may appear in this document nor does it make a commitment to update the information contained herein.

Intel retains the right to make changes to these specifications at any time, without notice.

Contact your local sales office to obtain the latest specifications before placing your order.

The following are trademarks of Intel Corporation and may only be used to identify Intel Products:

Above, BITBUS, COMMputer, CREDIT, Data Pipeline, FASTPATH, Genius, i, $\hat{\mathbf{1}}$, ICE, iCEL, iCS, iDBP, iDIS, I²ICE, iLBX, i_m, iMDDX, iMMX, Inboard, Insite, Intel, intel, intel, intelBOS, Intel Certified, Intelevision, intelgent Identifier, inteligent Programming, Intellec, Intellink, iOSP, iPDS, iPSC, iRMK, iRMX, iSBC, iSBX, iSDM, iSXM, KEPROM, Library Manager, MAPNET, MCS, Megachassis, MICROMAINFRAME, MULTIBUS, MULTICHANNEL, MULTIMODULE, MultiSERVER, ONCE, OpenNET, OTP, PC BUBBLE, Plug-A-Bubble, PROMPT, Promware, QUEST, QueX, Quick-Pulse Programming, Ripplemode, RMX/80, RUPI, Seamless, SLD, SugarCube, SupportNET, UPI, and VLSiCEL, and the combination of ICE, iCS, iRMX, iSBC, iSBX, iSXM, MCS, or UPI and a numerical suffix, 4-SITE.

MDS is an ordering code only and is not used as a product name or trademark. MDS® is a registered trademark of Mohawk Data Sciences Corporation.

*MULTIBUS is a patented Intel bus.

Additional copies of this manual or other Intel literature may be obtained from:

Intel Corporation Literature Distribution Mail Stop SC6-59 3065 Bowers Avenue Santa Clara, CA 95051

©INTEL CORPORATION 1987

CG-5/26/87

PREFACE

The Intel 80386 is a high-performance 32-bit microprocessor. This manual provides complete hardware reference information for 80386 system designs. It is written for system engineers and hardware designers who understand the operating principles of microprocessors and microcomputer systems. Readers of this manual should be familiar with the information in the *Introduction to the 80386* (Intel publication Order Number 231252).

RELATED PUBLICATIONS

In this manual, the 80386 is presented from a hardware perspective. Information on the software architecture, instruction set, and programming of the 80386 can be found in these related Intel publications:

- 80386 Programmer's Reference Manual, Order Number 230985
- 80386 System Software Writer's Guide, Order Number 231499
- 80386 Data Sheet, Order Number 231630

The 80386 Data Sheet contains device specifications for the 80386. Always consult the most recent version of this publication for specific 80386 parameter values.

Detailed device specifications on 80386 family components can be found in the following publications:

- 80387 Data Sheet, Order Number 231920
- 82380 Data Sheet, Order Number 290128

Together with the 80386 Hardware Reference Manual, these publications provide a complete description of the 80386 system for hardware designers, software engineers, and all users of 80386 systems.

ORGANIZATION OF THIS MANUAL

The information in this manual is divided into 12 chapters and three appendices. The material begins with a description of the 80386 microprocessor and continues with discussions of hardware design information needed to implement 80386 system designs.

- Chapter 1, "System Overview." This chapter provides an overview of the 80386 and its supporting devices.
- Chapter 2, "Internal Architecture." This chapter describes the internal architecture of the 80386.
- Chapter 3, "Local Bus Interface." This chapter discusses the 80386 local bus interface.
 This chapter includes 80386 signal descriptions, memory and I/O organization, and local bus interface guidelines.



- Chapter 4, "Performance Considerations." This chapter explores the factors that affect the performance of an 80386 system.
- Chapter 5, "Coprocessor Hardware Interface." This chapter describes the interface between the 80386 and the 80287 and 80387 Numeric Coprocessors. Each of these coprocessors expands the floating-point numerical processing capabilities of the 80386.
- Chapter 6, "Memory Interfacing." This chapter discusses techniques for designing memory subsystems for the 80386.
- Chapter 7, "Cache Subsystems." This chapter describes cache memory subsystems, which provide higher performance at lower relative cost.
- Chapter 8, "I/O Interfacing." This chapter discusses techniques for connecting I/O devices to an 80386 system.
- Chapter 9, "MULTIBUS® I and 80386." This chapter describes the interface between an 80386 system and the Intel MULTIBUS I multi-master system bus.
- Chapter 10, "MULTIBUS® II and 80386." This chapter describes the interface between an 80386 system and the Intel MULTIBUS II multi-master system bus.
- Chapter 11, "Physical Design and Debugging." This chapter contains recommendations for constructing and debugging 80386 systems.
- Chapter 12, "Test Capabilities." This chapter describes 80386 test procedures.
- Appendix A contains descriptions of the components of the basic memory interface described in Chapter 6.
- Appendix B contains descriptions of the components of the 80387 emulator described in Chapter 5.
- Appendix C contains descriptions of the components of the dynamic RAM subsystem described in Chapter 6.

CHAPTER 1	Page
SYSTEM OVERVIEW	
1.1 Microprocessor	1-1
1.2 Coprocessors	1-3
1.3 Integrated System Peripheral	1-4
1.4 Cache Controller	1-5
1.5 Clock Generator	1-5
1.6 8086/80286 Family Components	1-5
CHAPTER 2	
INTERNAL ARCHITECTURE	
2.1 Bus Interface Unit	2-2
2.2 Code Prefetch Unit	2-3
2.3 Instruction Decode Unit	2-3
2.4 Execution Unit	2-3
2.5 Segmentation Unit	2-4
2.6 Paging Unit	2-4
CHAPTER 3	
LOCAL BUS INTERFACE	
3.1 Bus Operations	3-2
3.1.1 Bus States	3-4
3.1.2 Address Pipelining	3-5
3.1.3 32-Bit Data Bus Transfers and Operand Alignment	3-5
3.1.4 Read Cycle	3-10
3.1.5 Write Cycle	3-13
3.1.6 Pipelined Address Cycle	3-14
3.1.7 Interrupt Acknowledge Cycle	3-17
3.1.8 Halt/Shutdown Cycle	3-18
3.1.9 BS16 Cycle	3-19
3.1.10 16-Bit Byte Enables and Operand Alignment	3-20
3.2 Bus Timing	3-22
3.2.1 Read Cycle Timing	3-24
3.2.2 Write Cycle Timing	3-24
3.2.3 READY# Signal Timing	3-25
3.3 Clock Generation	3-26
3.3.1 82384 Clock Generator	3-26
3.3.2 Clock Timing	3-26
3.3.3 Crystal Oscillator Clock Generator	3-27
3.4 Interrupts	3-29
3.4.1 Non-Maskable Interrupt (NMI)	3-30
3.4.2 Maskable Interrupt (INTR)	3-31
3.4.3 Interrupt Latency	3-31

	Page
3.5 Bus Lock	3-32
3.5.1 Locked Cycle Activators	3-32
3.5.2 Locked Cycle Timing	3-32
3.5.3 LOCK# Signal Duration	3-33
3.6 HOLD/HLDA (Hold Acknowledge)	3-34
3.6.1 HOLD/HLDA Timing	3-34
3.6.2 HOLD Signal Latency	3-36
3.6.3 HOLD State Pin Conditions	3-36
3.7 Reset	3-37
3.7.1 RESET Timing	3-37
3.7.2 80386 Internal States	3-38
3.7.3 80386 External States	3-38
CHAPTER 4	
PERFORMANCE CONSIDERATIONS	
4.1 Wait States and Pipelining	4-1
CHAPTER 5	
COPROCESSOR HARDWARE INTERFACE	
5.1 80287 Numeric Coprocessor Interface	5-2
5.1.1 80287 Connections	5-2
5.1.2 80287 Bus Cycles	5-2
5.1.3 80287 Clock Input	5-4
5.2 80387 Numeric Coprocessor Interface	5-4
5.2.1 80387 Connections	5-4
5.2.2 80387 Bus Cycles	5-6
5.2.3 80387 Clock Input	5-6
5.3 Local Bus Activity with the 80287/80387	5-7
5.4 Designing an Upgradable 80386 System	5-8
5.4.1 80287/80387 Recognition	5-8
5.4.1.1 Hardware Recognition of the NPX	5-8
5.4.1.2 Software Recognition of the NPX	5-8
5.4.2 80387 Emulator	5-10
CHAPTER 6	
MEMORY INTERFACING	
6.1 Memory Speed versus Performance and Cost	6-1
6.2 Basic Memory Interface	6-1
6.2.1 PAL Devices	6-2
6.2.2 Address Latch	6-3
6.2.3 Address Decoder	6-4
6.2.4 Data Transceiver	6-5
6.2.5 Bus Control Logic	6-6

	Page
6.2.6 EPROM Interface	6-9
6.2.7 SRAM Interface	6-11
6.2.8 16-Bit Interface	6-14
6.3 Dynamic RAM (DRAM) Interface	6-15
6.3.1 Interleaved Memory	6-15
6.3.2 DRAM Memory Performance	6-15
6.3.3 DRAM Controller	6-16
6.3.3.1 3-CLK DRAM Controller	6-17
6.3.3.2 2-CLK DRAM Controller	6-21
6.3.4 DRAM Design Variations	6-23
6.3.5 Refresh Cycles	6-25
6.3.5.1 Distributed Refresh	6-25
6.3.5.2 Burst Refresh	6-26
6.3.5.3 DMA Refresh using the 82380 DRAM Refresh Controller	6-26
6.3.6 Initialization	6-27
6.3.7 Timing Analysis	6-28
CHAPTER 7	
CACHE SUBSYSTEMS	
7.1 Introduction to Caches	7-2
7.1.1 Program Locality	7-2
7.1.2 Block Fetch	7-2
7.2 Cache Organizations	7-3
7.2.1 Fully Associative Cache	7-3
7.2.2 Direct Mapped Cache	7-4
7.2.3 Set Associative Cache	7-6
7.3 Cache Updating	7-8
7.3.1 Write-Through System	7-8
7.3.2 Buffered Write-Through System	7-8
7.3.3 Write-Back System	7-9
7.3.4 Cache Coherency	7-10
7.4 Efficiency and Performance	7-12
7.5 Cache and DMA	7-12
7.6 Cache Example	7-13
7.6.1 Example Design	7-14
7.6.2 Example Cache Memory Organization	7-14
7.6.3 Example Cache Implementation	7-15
CHAPTER 8	
I/O INTERFACING	
8.1 I/O Mapping versus Memory Mapping	8-1
8.2 8-Bit, 16-Bit, and 32-Bit I/O Interfaces	8-1
8.2.1 Address Decoding	8-1

	Page
8.2.2 8-Bit I/O	8-2
8.2.3 16-Bit I/O	8-4
8.2.4 32-Bit I/O	8-4
8.2.5 Linear Chip Selects	8-4
8.3 Basic I/O Interface	8-4
8.3.1 Address Latch	8-8
8.3.2 Address Decoder	8-6
8.3.3 Data Transceiver	8-8
8.3.4 Bus Control Logic	8-8
8.4 Timing Analysis for I/O Operations	8-9
8.5 Basic I/O Examples	8-1
8.5.1 8274 Serial Controller	8-14
8.5.2 82380 Programmable Interrupt Controller	8-1
8.5.2.1 Cascaded Interrupt Controllers to the 82380 PIC	8-1
8.5.3 8259A Interrupt Controller	8-1
8.5.3.1 Single Interrupt Controller	8-1
8.5.3.2 Cascaded Interrupt Controllers	8-1
8.5.3.3 Handling More Than 64 Interrupts	8-17
8.6 80286-Compatible Bus Cycles	8-17
8.6.1 A0/A1 Generator	8-18
8.6.2 S0#/S1# Generator	8-18
8.6.3 Wait-State Generator	8-19
8.6.4 Bus Controller and Bus Arbiter	8-20
8.6.5 82380 Integrated System Peripheral	8-2
8.6.6 82258 ADMA Controller	8-2
8.6.6.1 82258 as Bus Master	8-2
8.6.6.2 82258 as Peripheral	8-2
8.6.7 82586 LAN Coprocessor	8-2
8.6.7.1 Dedicated CPU	8-2
8.6.7.2 Decoupled Dual-Port Memory	8-2
8.6.7.3 Coupled Dual-Port Memory	8-3
8.6.7.4 Shared Bus	8-3
CHAPTER 9	
MULTIBUS® I AND 80386	
9.1 MULTIBUS® I (IEEE 796)	9-
9.2 MULTIBUS® I Interface Example	9-
9.2.1 Address Latches and Data Transceivers	9-
9.2.2 Address Decoder	9-
9.2.3 Wait-State Generator	9- 9-
9.2.4 Bus Controller and Bus Arbiter	9-
9.3 Timing Analysis of MULTIBUS® I Interface	9-1
9.4 82289 Bus Arbiter	9-1
V. I VEEV PUU / II DILUI	J- I

	Page
9.4.1 Priority Resolution	9-11
9.4.2 82289 Operating Modes	9-11
9.4.3 MULTIBUS® I Locked Cycles	9-14
9.5 Other MULTIBUS® I Design Considerations	9-14
9.5.1 Interrupt-Acknowledge on MULTIBUS® I	9-14
9.5.2 Byte Swapping during MULTIBUS® I Byte Transfers	9-16
9.5.3 Bus Timeout Function for MULTIBUS® I Accesses	9-17
9.5.4 MULTIBUS® I Power Failure Handling	9-17
9.6 iLBX™ Bus Expansion	9-18
9.7 Dual-Port RAM with MULTIBUS® I	9-19
9.7.1 Avoiding Deadlock with Dual-Port RAM	9-20
CHAPTER 10	
MULTIBUS® II AND 80386	
10.1 MULTIBUS® II Standard	10-1
10.2 Parallel System Bus (iPSB)	10-1
10.2.1 iPSB Interface	10-2
10.2.1.1 BAC Signals	10-4
10.2.1.2 MIC Signals	10-6
10.3 Local Bus Extension (iLBX™ II)	10-7
10.4 Serial System Bus (iSSB)	10-7
CHAPTER 11	
PHYSICAL DESIGN AND DEBUGGING	
11.1 Power and Ground Requirements	11-1
11.1.1 Power and Ground Planes	11-1
11.1.2 Decoupling Capacitors	11-2
11.2 High-Frequency Design Considerations	11-3
11.2.1 Line Termination	11-4
11.2.2 Interference	11-5
11.2.3 Latchup	11-7
11.3 Clock Distribution and Termination	11-7
11.4 Thermal Characteristics	11-7
11.5 Debugging Considerations	11-10
11.5.1 Hardware Debugging Features	11-10
11.5.2 Bus Interface	11-11
11.5.3 Simplest Diagnostic Program	11-11
11.5.4 Building and Debugging a System Incrementally	11-12
11.5.5 Other Simple Diagnostic Software	11-14
11.5.6 Debugging Hints	11-14

CHAPT	'ER 12	
	T CAPABILITIES	
	nternal Tests	12-1
	Automatic Self-Test	12-1
	Translation Lookaside Buffer Tests	12-2
12.2 E	Board-Level Tests	12-5
APPEN	IDIX A	
	AL BUS CONTROL PAL DESCRIPTIONS	
	Functions	A-1
	Functions	A-2
PAL E	quations	A-2
APPEN	INIV D	
	BIX B BY EMULATOR PAL DESCRIPTION	
APPEN	DIX C M PAL DESCRIPTIONS	
	State PAL	C-1
	Control PAL	C-13
	h Interval Counter PAL	C-13
	h Address Counter PAL	C-13
	Parameters	C-25
J		
	Figures	
Figure	Title	Page
1-1	80386 System Block Diagram	1-2
2-1	Instruction Pipelining	2-1
2-2	80386 Functional Units	2-2
3-1	CLK2 and CLK Relationship	3-5
3-2	80386 Bus States Timing Example	3-6
3-3	Bus State Diagram (Does Not Include Address Pipelining)	3-7
3-4	Non-Pipelined Address and Pipelined Address Differences	3-8
3-5	Consecutive Bytes in Hardware Implementation	3-9
3-6	Address, Data Bus, and Byte Enables for 32-Bit Bus	3-9
3-7	Misaligned Transfer	3-11
3-8	Non-Pipelined Address Read Cycles	3-12
3-9	Non-Pipelined Address Write Cycles	3-15
3-10	Pipelined Address Cycles	3-16
3-11	Interrupt Acknowledge Bus Cycles	3-18
3-12	Internal NA# and BS16# Logic	3-20
3-13	32-Bit and 16-Bit Bus Cycle Timing	3-21



Figure	Title	Page
3-14	32-Bit and 16-Bit Data Addressing	3-22
3-15	Connecting 82384 to 80386	3-27
3-16	Using CLK to Determine Bus Cycle Start	3-28
3-17	Clock Generator	3-28
3-18	ADS# Synchronizer	3-29
3-19	Error Condition Caused by Unlocked Cycles	3-33
3-20	LOCK# Signal during Address Pipelining	3-34
3-21	Bus State Diagram with HOLD State	3-35
3-22	Typical RC RESET Timing Circuit	3-37
3-23	RESET, CLK, and CLK2 Timing	3-38
5-1	80386 System with 80287 Coprocessor	5-3
5-2	80386 System with 80387 Coprocessor	5-5
5-3	Pseudo-Synchronous Interface	5-7
5-4	Software Routine to Recognize the 80287	5-9
5-5	80387 Emulator Schematic	5-11
6-1	Basic Memory Interface Block Diagram	6-2
6-2	PAL Equation and Implementation	6-4
6-3	PAL Naming Conventions	6-5
6-4	Bus Control Logic	6-7
6-5	Bus Control Signal Timing	6-8
6-6	150-Nanosecond EPROM Timing Diagram	6-10
6-7	100-Nanosecond SRAM Timing Diagram	6-12
6-8	3-CLK DRAM Controller Schematic	6-18
6-9	3-CLK DRAM Controller Cycles	6-20
6-10	2-CLK DRAM Controller Schematic	6-22
6-11	2-CLK DRAM Controller Cycles	6-24
6-12	Refresh Request Generation	6-27
7-1	Cache Memory System	7-1
7-2	Fully Associative Cache Organization	7-4
7-3	Direct Mapped Cache Organization	7-5
7-4	Two-Way Set Associative Cache Organization	7-7
7-5	Stale Data Problem	7-9
7-6	Bus Watching	7-10
7-7	Hardware Transparency	7-11
7-8	Non-Cacheable Memory	7-12
7-9	Example of Cache Memory Organization	7-15
8-1	32-Bit to 8-Bit Bus Conversion	8-3
8-2	Linear Chip Selects	8-5
8-3	Basic I/O Interface Block Diagram	8-6
8-4	Basic I/O Interface Circuit	8-7
8-5	Basic I/O Timing Diagram	8-11
8-6	8274 Interface	8-14
8-7	Single 8259A Interface	8-16



Figure	Title	Page
8-8	80286-Compatible Interface	8-19
8-9	A0, A1, and BHE# Logic	8-21
8-10	S0#/S1# Generator Logic	8-22
8-11	Wait-State Generator Logic	8-22
8-12	82288 and 82289 Connections	8-23
8-13	80386/82380 Interface	8-24
8-14	HOLD and HLDA Logic for 80386-82258 Interface	8-25
8-15	82258 Slave Mode Interface	8-26
8-16	LAN Station	8-28
8-17	Decoupled Dual-Port Memory Interface	8-29
8-18	Coupled Dual-Port Memory Interface	8-30
8-19	Shared Bus Interface	8-31
9-1	80386-MULTIBUS® I Interface	9-3
9-2	MULTIBUS® I Address Latches and Data Transceivers	9-4
9-3	Wait-State Generator Logic	9-6
9-4	MULTIBUS® Arbiter and Bus Controller	9-7
9-5	MULTIBUS® I Read Cycle Timing	9-8
9-6	MULTIBUS® I Write Cycle Timing	9-9
9-7	Bus Priority Resolution	9-12
9-8	Operating Mode Configurations	9-13
9-9	Bus-Select Logic for Interrupt Acknowledge	9-16
9-10	Byte-Swapping Logic	9-18
9-11	Bus-Timeout Protection Circuit	9-19
9-12	iLBX™ Signal Generation	9-20
10-1	iPSB Bus Cycle Timing	10-3
10-2	iPSB Bus Interface	10-4
11-1	Reducing Characteristic Impedance	11-2
11-2	Circuit without Decoupling	11-2
11-3	Decoupling Chip Capacitors	11-3
11-4	Decoupling Leaded Capacitors	11-4
11-5	Series Termination	11-5
11-6	Split Termination	11-5
11-7	Avoid Closed-Loop Signal Paths	11-6
11-8	CLK2 Series Termination	11-8
11-9	CLK2 Loading	11-9
11-10	CLK2 Waveforms	11-9
11-11	4-Byte Diagnostic Program	11-12
11-12	More Complex Diagnostic Program	11-15
11-13	Object Code for Diagnostic Program	11-16
12-1	80386 Self-Test	12-2
12-2	TLB Test Registers	12-3
A-1	PAL-1 State Listings	A-3
A-2	PAL-2 State Listings	A-9

inteľ

Figure	Title	Page
A-3	PAL-1 Equations	A-14
A-4	PAL-2 Equations	A-15
B-1	80387 Emulator PAL Equations	B-1
C-1	PAL Sampling Edges	C-1
C-2	3-CLK DRAM State PAL Equations	C-3
C-3	2-CLK DRAM State PAL Equations	C-8
C-4	3-CLK DRAM Control PAL Equations	C-15
C-5	2-CLK DRAM Control PAL Equations	C-17
C-6	Refresh Interval Counter PAL Equations	C-20
C-7	Refresh Address Counter PAL Equations	C-23
C-8	DRAM Circuit Timing Diagram	C-26
	Tables	
Table	Title	Page
1-1	80386 System Components	1-1
3-1	Summary of 80386 Signal Pins	3-3
3-2	Bus Cycle Definitions	3-4
3-3	Possible Data Transfers on 32-Bit Bus	3-10
3-4	Misaligned Data Transfers on 32-Bit Bus	3-13
3-5	Generation of BHE#, BLE#, and A1 from Byte Enables	3-23
3-6	Byte Enables during BS16 Cycles	3-23
3-7	Output Pin States during RESET	3-39
4-1	80386 Performance with Wait States and Pipelining	4-1
4-2	Performance versus Wait States and Operating Frequency	4-3
6-1	Bus Cycles Generated by Bus Controller	6-6
6-2	DRAM Memory Performance	6-16
6-3	Designs for Six DRAM Types	6-28
7-1	Cache Hit Rates	7-13
8-1	Data Lines for 8-Bit I/O Addresses	8-2
8-2	Timings for Peripherals using Basic I/O Interface	8-13
8-3	A0, A1, and BHE# Truth Table	8-20
9-1	MULTIBUS® I Timing Parameters	9-10
C-1	DRAM State PAL Pin Description	C-2
C-2	DRAM Control PAL Pin Description	C-14
C-3	Refresh Interval Counter PAL Pin Description	C-19
C-4	Refresh Address Counter PAL Pin Description	C-22
C-5	DRAM Circuit Timing Parameters	C-27



CUSTOMER SUPPORT

CUSTOMER SUPPORT

Customer Support is Intel's complete support service that provides Intel customers with hardware support, software support, customer training, and consulting services. For more information contact your local sales offices.

After a customer purchases any system hardware or software product, service and support become major factors in determining whether that product will continue to meet a customer's expectations. Such support requires an international support organization and a breadth of programs to meet a variety of customer needs. As you might expect, Intel's customer support is quite extensive. It includes factory repair services and worldwide field service offices providing hardware repair services, software support services, customer training classes, and consulting services.

HARDWARE SUPPORT SERVICES

Intel is committed to providing an international service support package through a wide variety of service offerings available from Intel Hardware Support.

SOFTWARE SUPPORT SERVICES

Intel's software support consists of two levels of contracts. Standard support includes TIPS (Technical Information Phone Service), updates and subscription service (product-specific troubleshooting guides and COMMENTS Magazine). Basic support includes updates and the subscription service. Contracts are sold in environments which represent product groupings (i.e., iRMX environment).

CONSULTING SERVICES

Intel provides field systems engineering services for any phase of your development or support effort. You can use our systems engineers in a variety of ways ranging from assistance in using a new product, developing an application, personalizing training, and customizing or tailoring an Intel product to providing technical and management consulting. Systems Engineers are well versed in technical areas such as microcommunications, real-time applications, embedded microcontrollers, and network services. You know your application needs; we know our products. Working together we can help you get a successful product to market in the least possible time.

CUSTOMER TRAINING

Intel offers a wide range of instructional programs covering various aspects of system design and implementation. In just three to ten days a limited number of individuals learn more in a single workshop than in weeks of self-study. For optimum convenience, workshops are scheduled regularly at Training Centers worldwide or we can take our workshops to you for on-site instruction. Covering a wide variety of topics, Intel's major course categories include: architecture and assembly language, programming and operating systems, bitbus and LAN applications.

CHAPTER 1 SYSTEM OVERVIEW

The 80386 is a new 32-bit microprocessor that forms the basis for a high-performance 32-bit system. The 80386 incorporates multitasking support, memory management, pipelined architecture, address translation caches, and a high-speed bus interface all on one chip. The integration of these features speeds the execution of instructions and reduces overall chip count for a system. Paging and dynamic data bus sizing can each be invoked selectively, making the 80386 suitable for a wide variety of system designs and user applications.

While the 80386 represents a significant improvement over previous generations of microprocessors, substantial ties to the earlier processors are preserved. Software compatibility at the object-code level is provided, so that an existing investment in 8086 and 80286 software can be maintained. New software can be built upon existing routines, reducing the time to market for new products. Hardware compatibility is preserved through the dynamic bussizing feature.

The major components of an 80386 system and their functions are shown in Figure 1-1. Table 1-1 describes these components.

1.1 MICROPROCESSOR

The 80386 provides unprecedented performance. At 20 MHz, the 80386 is capable of executing at sustained rates of over five million instructions per second, a speed comparable to that of most super minicomputers. This achievement is made possible through a state-of-the-art design that includes a pipelined internal architecture, address translation caches, and a high-performance bus.

The 80386 features 32-bit wide internal and external data paths and eight general-purpose 32-bit registers. The instruction set offers 8-, 16-, and 32-bit data types, and the processor outputs 32-bit physical addresses directly, for a physical memory capacity of four gigabytes.

Description Component 80386 Microprocessor 32-bit high-performance microprocessor with onchip memory management and protection 80287 or 80387 Numeric Coprocessor Performs numeric instruction in parallel with 80386; expands instruction set 82380 Integrated System Peripheral Provides 32-bit high-speed direct memory access, interrupt control, and interval timers 82385 Cache Controller Provides cache directory and management logic 82384 Clock Generator Generates system clock and RESET signal 8259A Programmable Interrupt Controller Provides interrupt control and management 82258 Advanced DMA Performs direct memory controller access (DMA)

Table 1-1. 80386 System Components




Figure 1-1. 80386 System Block Diagram



The 80386 has separate 32-bit data and address paths. A 32-bit memory access can be completed in only two clock cycles, enabling the bus to sustain a throughput of 40 megabytes per second (at 20 MHz). By making prompt transfers between the microprocessor, memory, and peripherals, the high-speed bus design ensures that the entire system benefits from the processor's increased performance.

Pipelined architecture enables the 80386 to perform instruction fetching, decoding, execution, and memory management functions in parallel. The six independent units that makeup the 80386 pipeline are described in detail in Chapter 2. Because the 80386 prefetches instructions and queues them internally, instruction fetch and decode times are absorbed in the pipeline; the processor rarely has to wait for an instruction to execute.

Pipelining is not unusual in modern microprocessor architecture; however, including the memory management unit (MMU) in the on-chip pipeline is a unique feature of the 80386. By performing memory management on-chip, the 80386 eliminates the serious access delays typical of implementations that use off-chip memory management units. The benefit is not only high performance but also relaxed memory-access time requirements, hence lower system cost.

The integrated memory management and protection mechanism translates logical addresses to physical addresses and enforces the protection rules necessary for maintaining task integrity in a multitasking environment. The paging function simplifies the operating-system swapping algorithms by providing a uniform mechanism for managing the physical structure of memory.

Task switching occurs frequently in real-time multitasking or multiuser systems. To perform task switching efficiently, the 80386 incorporates special high-speed hardware. Only a single instruction or an interrupt is needed for the 80386 to perform a complete task switch. A 20-MHz 80386 can save the state of one task (all registers), load the state of another task (all registers, even segment and paging registers if required), and resume execution in less than 14 microseconds (at 20 MHz). For less sophisticated task and interrupt handling, the latency can be as short as 2.9 microseconds (at 20 MHz).

1.2 COPROCESSORS

The performance of most applications can be enhanced by the use of specialized coprocessors. A coprocessor provides the hardware to perform functions that would otherwise be performed in software. Coprocessors extend the instruction set of the 80386.

The 80386 has a numeric coprocessor interface that can support one of two coprocessors: the 80387 or the 80287. For applications that benefit from high-precision integer and floating-point calculations, these numeric coprocessors provide full support for the IEEE standard for floating-point operations. Both the 80387 and 80287 are software compatible with the 8087, an earlier numeric coprocessor. At 16 MHz, the 80387 operates about eight times faster than a 5-MHz 80287. However, the 80287 is fast enough for many applications and is a cost-effective solution for many designs. The 80386 therefore offers the system designer the choice of low-cost or high-performance numeric solutions.



1.3 INTEGRATED SYSTEM PERIPHERAL

A DMA (Direct Memory Access) controller performs DMA transfers between main memory and an I/O device, typically a hard disk, floppy disk, or communications channel. In a DMA transfer, a large block of data can be copied from one place to another without the intervention of the CPU.

The 82380 Integrated System Peripheral is a multi-function 80386 companion chip. It integrates a 32-bit DMA Controller with other necessary processor support functions needed in an 80386 environment. The 82380 is optimized for use with the 80386 microprocessor. It enhances the overall 80386 system performance by providing high data throughput as well as efficient bus operation. The 32-bit DMA Controller provides eight independently programmable channels that can transfer data at the full bandwidth of the 80386 bus. Other features of the 82380 are listed as follows.

- High performance 32-bit DMA Controller
 - -8 independently programmable channels
 - -32 megabytes per second data transfer rate at 16 MHz
 - -40 megabytes per second data transfer rate at 20 MHz
 - Capable of transferring data between devices with different bus widths
 - Automatic byte assembly/disassembly capability for non-align data transfers
 - Buffer chaining capability for transferring data into non-contiguous memory buffers
- 20-Source Interrupt Controller
 - —15 external, 5 internal interrupt requests
 - -82C59A susperset
 - Individually programmable interrupt vectors
- Four 16-bit programmable Interval Timers
 - -82C54 compatible
- Programmable Wait State Generator
 - —0 to 15 wait states for memory and I/O access cycles
- DRAM Refresh Controller

Refresh request always has the highest priority among the DMA requests

- 80386 Shutdown Detect and Reset Control
 - -Software and hardware reset
- Optimized for use with the 80386 microprocessor
 - -Resides on local bus for maximum bus bandwidth



1.4 CACHE CONTROLLER

A cache memory subsystem provides fast local storage for frequently accessed code and data. This results in faster memory access for the microprocessor and reduces the amount of traffic on the system bus.

The 82385 Cache Controller is a high performance peripheral designed specifically for the 80386. The 82385 allows the 80386 to reach its full performance potential by offering the following features:

- * Supports a 32 kbyte cache memory organized as either 2-way set associative or direct mapped.
- * Integrated cache directory and management logic.
- * Utilizes posted writes for zero wait states on write cycles.
- * Guarantees cache coherency by bus watching.
- * Supports non-cacheable accesses.
- * Presents an 80386 interface to system resources.
- * Dhrystone benchmark shows an average hit rate of 95%.

1.5 CLOCK GENERATOR

The 82384 Clock Generator generates timing for the 80386 and its support components. The 82384 provides both the 80386 clock (CLK2) and a half-frequency clock (CLK) to indicate the internal phase of the 80386 and to drive 80286-compatible devices that may be included in the system. It can also be used to generate the RESET signal for the 80386 and other system components. Both CLK2 and CLK are used throughout this manual to describe execution times.

1.6 8086/80286 FAMILY COMPONENTS

With the appropriate interface, the 80386 can use 8086/80286 family components. These components include the 8259A and 82258.

The 8259A Programmable Interrupt Controller manages interrupts for an 80386 system. Interrupts from as many as eight external sources are accepted by one 8259A; as many as 64 requests can be accommodated by cascading several 8259A chips. The 8259A resolves priority between active interrupts, then interrupts the processor and passes a code to the processor to identify the interrupting source. Programmable features of the 8259A allow it to be used in a variety of ways to fit the interrupt requirements of a particular system.



The 82258 Advanced DMA (ADMA) Controller offers four channels and provides all the signals necessary to perform DMA transfers. Other features of the 82258 are as follows:

- Command chaining to perform multiple commands
- Data chaining to scatter data to separate memory locations (separate pages, for example) and gather data from separate locations
- Automatic assembly and disassembly to convert from 16-bit memory to 8-bit I/O, or vice versa
- Compare, translate, and verify functions
- The option to replace one of the four high-speed channels with as many as 32 lower-speed, multiplexed channels.



CHAPTER 2 INTERNAL ARCHITECTURE

The internal architecture of the 80386 consists of six functional units that operate in parallel. Fetching, decoding, execution, memory management, and bus accesses for several instructions are performed simultaneously. This parallel operation is called pipelined instruction processing. With pipelining, each instruction is performed in stages, and the processing of several instructions at different stages may overlap as illustrated in Figure 2-1. The six-stage pipelined processing of the 80386 results in higher performance and an enhanced throughput rate over non-pipelined processors.

The six functional units of the 80386 are identified as follows:

- Bus Interface Unit
- · Code Prefetch Unit
- Instruction Decode Unit
- Execution Unit
- Segmentation Unit
- · Paging Unit




Figure 2-1. Instruction Pipelining



The Execution Unit in turn consists of three subunits:

- Control Unit
- · Data Unit
- · Protection Test Unit

Figure 2-2 shows the organization of these units. This chapter describes the function of each unit, as well as interactions between units.

2.1 BUS INTERFACE UNIT

The Bus Interface Unit provides the interface between the 80386 and its environment. It accepts internal requests for code fetches (from the Code Prefetch Unit) and data transfers (from the Execution Unit), and prioritizes the requests. At the same time, it generates or




Figure 2-2. 80386 Functional Units



processes the signals to perform the current bus cycle. These signals include the address, data, and control outputs for accessing external memory and I/O. The Bus Interface Unit also controls the interface to external bus masters and coprocessors.

2.2 CODE PREFETCH UNIT

The Code Prefetch Unit performs the program look ahead function of the 80386. When the Bus Interface Unit is not performing bus cycles to execute an instruction, the Code Prefetch Unit uses the Bus Interface Unit to fetch sequentially along the instruction byte stream. These prefetched instructions are stored in the 16-byte Code Queue to await processing by the Instruction Decode Unit.

Code prefetches are given a lower priority than data transfers; assuming zero wait state memory access, prefetch activity never delays execution. On the other hand, if there is no data transfer requested, prefetching uses bus cycles that would otherwise be idle. Instruction prefetching reduces to practically zero the time that the processor spends waiting for the next instruction.

2.3 INSTRUCTION DECODE UNIT

The Instruction Decode Unit takes instruction stream bytes from the Prefetch Queue and translates them into microcode. The decoded instructions are then stored in a three-deep Instruction Queue (FIFO) to await processing by the Execution Unit. Immediate data and opcode offsets are also taken from the Prefetch Queue.

2.4 EXECUTION UNIT

The Execution Unit executes the instructions from the Instruction Queue and therefore communicates with all other units required to complete the instruction. The functions of its three subunits are as follows:

- The Control Unit contains microcode and special parallel hardware that speeds multiply, divide, and effective address calculation.
- The Data Unit contains the ALU, a file of eight 32-bit general-purpose registers, and a 64-bit barrel shifter (which performs multiple bit shifts in one clock). The Data Unit performs data operations requested by the Control Unit.
- The Protection Test Unit checks for segmentation violations under the control of the microcode.

To speed up the execution of memory reference instructions, the Execution Unit partially overlaps the execution of any memory reference instruction with the previous instruction. Because memory reference instructions are frequent, a performance gain of approximately nine percent is achieved.



2.5 SEGMENTATION UNIT

The Segmentation Unit translates logical addresses into linear addresses at the request of the Execution Unit. The on-chip Segment Descriptor Cache stores the currently used segment descriptors to speed this translation. At the same time it performs the translation, the Segmentation Unit checks for bus-cycle segmentation violations. (These checks are separate from the static segmentation violation checks performed by the Protection Test Unit.) The translated linear address is forwarded to the Paging Unit.

2.6 PAGING UNIT

When the 80386 paging mechanism is enabled, the Paging Unit translates linear addresses generated by the Segmentation Unit or the Code Prefetch Unit into physical addresses. (If paging is not enabled, the physical address is the same as the linear address, and no translation is necessary.) The Page Descriptor Cache stores recently used Page Directory and Page Table entries in its Translation Lookaside Buffer (TLB) to speed this translation. The Paging Unit forwards physical addresses to the Bus Interface Unit to perform memory and I/O accesses.



CHAPTER 3 LOCAL BUS INTERFACE

Local bus operations are considered in this chapter. The 80386 performs a variety of bus operations in response to internal conditions and external conditions (interrupt servicing, for example). The function and timing of the signals that make up the local bus interface are described, as well as the sequences of particular local bus operations.

The high-speed bus interface of the 80386 provides high performance in any system. At the same time, the bus control inputs and status outputs of the 80386 allow for adaptation to a wide variety of system environments.

The 80386 communicates with external memory, I/O, and other devices through a parallel bus interface. This interface consists of a data bus, a separate address bus, five bus status pins, and three bus control pins as follows:

- The bidirectional data bus consists of 32 pins (D31-D0). Either 8, 16, 24, or 32 bits of data can be transferred at once.
- The address bus, which generates 32-bit addresses, consists of 30 address pins (A31-A2) and four byte-enable pins (BE3#-BE0#). Each byte-enable pin corresponds to one of four bytes of the 32-bit data bus. The address pins identify a 4-byte location, and the byte-enable pins select the active bytes within the 4-byte location.
- The bus status pins establish the type of bus cycle to be performed. These outputs indicate the following conditions:

Address Status (ADS#)—address bus outputs valid Write/Read (W/R#)—write or read cycle Memory /I/O (M/IO#)—memory or I/O access Data/Control (D/C#)—data or control cycle LOCK#—locked bus cycle

• The bus control pins allow external logic to control the bus cycle on a cycle-by-cycle basis. These inputs perform the following functions:

READY#—ends the current bus cycle; controls bus cycle duration

Next Address (NA#)—allows address pipelining, that is, emitting address and status signals for the next bus cycle during the current cycle

Bus Size 16 (BS16#)—activates 16-bit data bus operation; data is transferred on the lower 16 bits of the data bus, and an extra cycle is provided for transfers of more than 16 bits



The following pins are used to control the execution of instructions in the 80386 and to interface external bus masters. The 80386 provides both a standard interface to communicate with other bus masters and a special interface support a numerics coprocessor.

- The CLK2 input provides a double-frequency clock signal for synchronous operation. This signal is divided by two internally, so the 80386 fundamental frequency is half the CLK2 signal frequency. For example, a 20-MHz 80386 uses a 40-MHz CLK2 signal.
- The RESET input forces the 80386 to a known reset state.
- The HOLD signal can be generated by another bus master to request that the 80386 release control of the bus. The 80386 responds by activating the Hold Acknowledge (HLDA) signal as it relinquishes control of the local bus.
- The Maskable Interrupt (INTR) and Non-Maskable Interrupt (NMI) inputs cause the 80386 to interrupt its current instruction stream and begin execution of an interrupt service routine.
- The BUSY#, ERROR#, and Coprocessor Request (PEREQ) signals make up the interface to an external numeric coprocessor. BUSY# and ERROR# are status signals from the coprocessor; PEREQ allows the coprocessor to request data from the 80386. The 80386 can use either the 80287 or the 80387 coprocessor.

All of the 80386 bus interface pins are summarized in Table 3-1.

3.1 BUS OPERATIONS

There are seven types of bus operations:

- Memory read
- Memory write
- I/O read
- I/O write
- Instruction fetch
- Interrupt acknowledge
- Halt/shutdown

Each bus cycle is initiated when the address is valid on the address bus, and bus status pins are driven to states that correspond to the type of bus cycle, and ADS# is driven low. Status pin states that correspond to each bus cycle type are shown in Table 3-2. Notice that the signal combinations marked as invalid states may occur when ADS# is false (high). These combinations will never occur if the signals are sampled on the CLK2 rising edge when ADS# is low, and the 80386 internal CLK is high (as indicated by the CLK output of the 82384). Bus status signals must be qualified with ADS# is true (low) to identify the bus cycle.

Memory read and memory write cycles can be locked to prevent another bus master from using the local bus and allow for indivisible read-modify-write operations.



Table 3-1. Summary of 80386 Signal Pins

Signal Name	Signal Function	Active State	Input/ Output	Input Synch or Asynch to CLK2	Output High Impedance During HLDA?
CLK2	Clock		ı	_	
D0-D31	Data Bus	High	1/0	S	Yes
BE0#-BE3#	Byte Enables	Low	0		Yes
A2-A31	Address Bus	High	0	_	Yes
W/R#	Write-Read Indication	High	0		Yes
D/C#	Data-Control Indication	High	0		Yes
M/IO#	Memory-I/O Indication	High	0		Yes
LOCK#	Bus Lock Indication	Low	0	_	Yes
ADS#	Address Status	Low	0	_	Yes
NA#	Next Address Request	Low	1	s	
BS16#	Bus Size 16	Low	1	S	_
READY#	Transfer Acknowledge	Low	ı	S	
HOLD	Bus Hold Request	High	1	S	_
HLDA	Bus Hold Acknowledge	High	0	_	No
PEREQ	Coprocessor Request	High	. 1	Α	_
BUSY#	Coprocessor Busy	Low	I	Α	_
ERROR#	Coprocessor Error	Low	I	Α	
INTR	Maskable Interrupt Request	High	1	Α	_
NMI	Non-Maskable Intrpt Request	High	1	Α	_
RESET	Reset	High	ı	S	- .



M/IO#	D/C#	W/R#	Bus Cyc	le Type	Locked?
Low	Low	Low	INTERRUPT ACKI	NOWLEDGE	Yes
Low	Low	High	does not occur		_
Low	High	Low	I/O DATA READ		No
Low	High	High	I/O DATA WRITE	I/O DATA WRITE	
High	Low	Low	MEMORY CODE READ		No
High	Low	High	HALT: Address = 2 (BE0# High BE1# High BE2# Low BE3# High A2-A31 Low)	SHUTDOWN: Address = 0 (BE0# Low BE1# High BE2# High BE3# High A2-A31 Low)	No
. High	High	Low	MEMORY DATA READ		Some Cycles

Table 3-2. Bus Cycle Definitions

3.1.1 Bus States

High

High

High

The 80386 uses a double-frequency clock input (CLK2) to generate its internal processor clock signal (CLK). As shown in Figure 3-1, each CLK cycle is two CLK2 cycles wide.

MEMORY DATA WRITE

Some Cycles

Notice that the internal 80386 matches the external 82384 CLK. The 82384 CLK is permitted to lag CLK2 slightly, but will never lead CLK2, so that it can be used reliably as a phase status indicator. All 80386 inputs are sampled at CLK2 rising edges. Many 80386 signals are sampled every other CLK2 rising edge; some are sampled on the CLK2 edge when CLK is high, while some are sampled on the CLK2 edge when CLK is low. The maximum data transfer rate for a bus operation, as determined by the 80386 internal clock, is 32 bits for every two CLK cycles, or 40 megabytes per second (CLK2 = 40 MHz, internal CLK = 20 MHz).

Each bus cycle is comprised of at least two bus states, T1 and T2. Each bus state in turn consists of two CLK2 cycles, which can be thought of as Phase 1 and Phase 2 of the bus state. Figure 3-2 shows bus states for some typical read and write cycles. During the first bus state (T1), address and bus status pins go active. During the second bus state (T2), external logic and devices respond. If the READY# input of the 80386 is sampled low at the end of the second CLK cycle, the bus cycle terminates. If READY# is high when sampled, the bus cycle continues for an additional T2 state, called a wait state, and READY# is sampled again. Wait states are added until READY# is sampled low.






Figure 3-1. CLK2 and CLK Relationship

When no bus cycles are needed by the 80386 (no bus requests are pending, the 80386 remains in the idle bus state (TI). The relationship between T1, T2, and TI is shown in Figure 3-3.

3.1.2 Address Pipelining

In the 80386, the timing address and status outputs can be controlled so the outputs become valid before the end of the previous bus cycle. This technique, which allows bus cycles to be overlapped, is called address pipelining. Figure 3-4 compares non-pipelined address cycles to pipelined address cycles.

Address pipelining increases bus throughput without decreasing allowable memory or I/O access time, thus allowing high bandwidth with relatively inexpensive components. In addition, using pipelining to address slower devices can yield the same throughput as addressing faster devices with no pipelining. A 20-MHz 80386 can transfer data at the maximum rate of 40 megabytes per second while allowing an address access time of three CLK cycles (150 nanoseconds at CLK = 20 MHz neglecting signal delays); without address pipelining, the access time is only two CLK cycles (100 nanoseconds at CLK = 20 MHz). When address pipeline is activated following an idle bus cycle, performance is decreased slightly because the first bus cycle cannot be pipelined. This condition is explained fully in Chapter 4.

3.1.3 32-Bit Data Bus Transfers and Operand Alignment

The 80386 can address up to four gigabytes (2³² bytes, addresses 00000000H-FFFFFFFH) of physical memory and up to 64 kilobytes (2¹⁶ bytes, addresses 00000000H-0000FFFFH) of I/O. The 80386 maintains separate physical memory and I/O spaces.






Figure 3-2. 80386 Bus States Timing Example

The programmer views the address space (memory or I/O) of the 80386 as a sequence of bytes. Words consist of two consecutive bytes, and double words consist of four consecutive bytes. However, in the system hardware, address space is implemented in four sections. Each of the four 8-bit portions of the data bus (D0-D7, D8-D15, D16-D23, and D24-D31) connects to a section. When the 80386 reads a doubleword, it accesses one byte from each section. The 80386 automatically translates the programmers' view of consecutive bytes into this hardware implementation (see Figure 3-5).

The 80386 memory spaces and I/O space are organized physically as sequences of 32-bit doublewords (230 32-bit memory locations and 214 32-bit I/O ports maximum). Each doubleword starts at a physical address that is a multiple of four, and has four individually addressable bytes at consecutive addresses.






Figure 3-3. Bus State Diagram (Does Not Include Address Pipelining)

Pins A31-A2 correspond to the most significant bits of the physical address; these pins address doublewords of memory. The two least significant bits of the physical address are used internally to activate the appropriate byte enable output (BE3#-BE0#). Figure 3-6 shows the relationship between physical address, doubleword location, data bus pins, and byte enables. This relationship holds for a 32-bit bus only; the organization for a 16-bit bus is described later in Section 3.1.10.

Data can be transferred in quantities of 32 bits, 24 bits, 16 bits, or 8 bits for each bus cycle of a data transfer. Table 3-3 shows which bytes of a 32-bit doubleword can be transferred in a single bus cycle. If a data transfer can be completed in a single cycle, the transfer is said to be aligned. For example, a word transfer involving D23-D8 and activating BE1# and BE2# is aligned.

Transfers of words and doublewords that overlap a doubleword boundary of the 80386 are called misaligned transfers. These transfers require two bus cycles, which are automatically generated by the 80386. For example, a word transfer at (byte) address 0003H requires two byte transfers: the first transfer activates doubleword address 0004H and uses D7-D0, and the second transfer activates doubleword address 0000H and uses D31-D24.




Figure 3-4. Non-Pipelined Address and Pipelined Address Differences






Figure 3-5. Consecutive Bytes in Hardware Implementation




Figure 3-6. Address, Data Bus, and Byte Enables for 32-Bit Bus



Table 3-3.	Passible	Data	Transfore	۸n	32-Rit Rus	2

Possible Data Transfers to 32-Bit Memory					
Size	Byte Enables				
32 bits	3-2-1-0				
24 bits	3-2-1 2-1-0				
16 bits	3-2 2-1 1-0				
8 bits	3 2 1 0				

Figure 3-7 shows the steps required for a misaligned 32-bit transfer. In the first bus cycle, the physical address crosses over into the next doubleword location, and BE0# and BE1# are active. In the second bus cycle, the address is decremented to the previous doubleword, and BE2# and BE3# are active. After the transfer, the data bits are automatically assembled in the correct order.

Table 3-4 shows the sequence of bus cycles for all possible misaligned transfers. Even though misaligned transfers are transparent to a program, they are slower than aligned transfers and should thus be avoided.

Because the 80386 operates on only bytes, words, and doublewords, certain combinations of BE3#-BE0# are never produced. For example, a bus cycle is never performed with only BE0# and BE2# active because such a transfer would be an operation on two noncontiguous bytes at the same time. A single 3-byte transfer will never occur, but a 3-byte transfer followed or preceded by a 1-byte transfer can occur for some misaligned doubleword transfers.

3.1.4 Read Cycle

Read cycles are of two types: pipelined address cycles and non-pipelined address cycles. In a non-pipelined address cycle, the address bus and bus status signals become valid during the first CLK period of the cycle. In a pipelined address cycle, the address bus and bus status signals are output before the beginning of cycle, in the previous bus cycle, to allow longer memory access times. Pipelined address cycles are described in Section 3.1.6.

The timing for two non-pipelined address read cycles (one with and one without a wait state) is shown in Figure 3-8.






Figure 3-7. Misaligned Transfer






Figure 3-8. Non-Pipelined Address Read Cycles



		First Cycle:		Second	Cycle:
Transfer Type	Physical Address	Address Bus	Byte Enables	Address Bus	Byte Enables
Word	4N + 3	4N + 4	0	4N	3
Doubleword	4N + 1	4N + 4	0	: 4N	1–3
Doubleword	4N + 2	4N + 4	0–1	4N	2–3
Doubleword	4N + 3	4N + 4	0–2	4N	3

Table 3-4. Misaligned Data Transfers on 32-Bit Bus

NOTE: 4N=Nth doubleword address

The sequence of signals for the non-pipelined read cycle is as follows:

- The 80386 initiates the cycle by driving ADS# low. The states of the address bus (A31-A2), byte enable pins (BE3#-BE0#), and bus status outputs (M/IO#, D/C#, W/R#, and LOCK#) at the CLK2 edge when ADS# is sampled low determine the type of bus cycle to be performed. For a read cycle,
 - W/R# is low
 - --- M/IO# is high for a memory read, low for an I/O read
 - For a memory read, D/C# is high if data is to be read, low if an instruction is to be read. Immediate data is included in an instruction.
 - LOCK# is low if the bus cycle is a locked cycle. In a read-modify-write sequence, both the memory data read cycle and the memory data write cycle are locked. No other bus master should be permitted to control the bus between two locked bus cycles.

The address bus, byte enable pins, and bus status pins (with the exception of ADS#) remain active through the end of the read cycle.

- At the end of T2, READY# is sampled. If READY# is low, the 80386 reads the input data on the data bus.
- If READY# is high, wait states (one CLK cycle) are added until READY# is sampled low. READY# is sampled at the end of each wait state.
- Once READY# is sampled low, the 80386 reads the input data, and the read cycle terminates. If a new bus cycle is pending, it begins on the next CLK cycle.

3.1.5 Write Cycle

Write cycles, like read cycles, are of two types: pipelined address and non-pipelined address. Pipelined address cycles are described in Section 3.1.6.



Figure 3-9 shows two non-pipelined address write cycles (one with and one without a wait state. The sequence of signals for a non-pipelined write cycle is as follows:

- The 80386 initiates the cycle by driving ADS# low. The states of the address bus (A31-A2), byte enable pins (BE3#-BE0#), and bus status outputs (M/IO#, D/C#, W/R#, and LOCK#) at the CLK edge when ADS# is sampled low to determine the type of bus cycle to be performed. For a write cycle,
 - -W/R# is high
 - -M/IO# is high for a memory write, low for an I/O write
 - -D/C# is high
 - LOCK# is low if the bus cycle is a locked cycle. In a read-modify-write sequence, both the memory data read cycle and the memory data write cycle are locked. No other bus master should be permitted to control the bus between two locked bus cycles.

The address bus, byte enable pins, and bus status pins (with the exception of ADS#) remain active through the end of the write cycle.

- At the start of Phase 2 in T1, output data becomes valid on the data bus. This data remains valid until the start of Phase 2 in T1 of the next bus cycle.
- At the end of T2, READY# is sampled. If READY# is low, the write cycle terminates.
- If READY# is not low, wait states are added until READY# is sampled low. READY# is sampled at the end of each wait state.
- Once READY# is sampled low, the write cycle terminates. If a new bus cycle is pending, it begins on the next CLK cycle.

3.1.6 Pipelined Address Cycle

Address pipelining allows bus cycles to be overlapped, increasing the amount of time available for the memory or I/O device to respond. The NA# input of the 80386 controls address pipelining. NA# is generated by logic in the system to indicate that the address bus is no longer needed (for example, after the address has been latched). If the system is designed so that NA# goes active before the end of the cycle, address pipelining may occur.

NA# is sampled at the rising CLK2 edge of Phase 2 of each CLK cycle. Once NA# is sampled active, the address, byte enables, and bus status signals for the next bus cycle are output as soon as they are available internally. Once NA# is sampled active, it is not required again until the CLK cycle after ADS# goes active.

Figure 3-10 illustrates the effect of NA#. During the second CLK cycle (T2) of a non-pipelined address cycle, NA# is sampled low. The address, byte enables, and bus status signals for the next bus cycle are output in the third CLK cycle (the first wait state of the current bus cycle). Thereafter, NA# is sampled in the next CLK cycle after ADS# is valid (T1 of each bus cycle); if NA# is active, the address, byte enables and bus-status pins for the next cycle are output in T2 if another bus cycle is pending.




Figure 3-9. Non-Pipelined Address Write Cycles






Figure 3-10. Pipelined Address Cycles

The first bus cycle after an idle bus state is always non-pipelined. To initiate address pipelining, this cycle must be extended by at least one CLK cycle so that the address and status can be output before the end of the cycle. Subsequent cycles can be pipelined as long as no idle bus cycles occur.

NA# is sampled at the start of Phase 2 of any CLK cycle in which ADS# is not active, specifically,

- The second CLK cycle of a non-pipelined address cycle
- The first CLK cycle of a pipelined address cycle
- Any wait state of a non-pipelined address or pipelined address cycle unless NA# has already been sampled active



Once NA# is sampled active, it remains active internally throughout the current bus cycle. If NA# and READY# are active in the same CLK cycle, the state of NA# is irrelevant, because READY# causes the start of a new bus cycle; therefore, the new address and status signals are always output regardless of the state of NA#.

A complete discussion of the considerations for using address pipelining can be found in the 80386 Data Sheet (Order Number 231630).

3.1.7 Interrupt Acknowledge Cycle

An unmasked interrupt causes the 80386 to suspend execution of the current program and perform instructions from another program called a service routine. Interrupts are described in detail in Section 3.4.

The 8259A Programmable Interrupt Controller is a system component that coordinates the interrupts of several devices (eight interrupts for a single 8259A; up to 64 interrupts with eight cascaded 8259As). When a device signals an interrupt request, the 8259A activates the INTR input of the 80386.

Interrupt acknowledge cycles are special bus cycles designed to activate the 8259A INTA input that enables the 8259A to output a service-routine vector on the data bus. The 80386 performs two back-to-back interrupt acknowledge cycles in response to an active INTR input (as long as the interrupt flag of the 80386 is enabled).

Interrupt acknowledge cycles are similar to regular bus cycles in that the 80386 bus outputs signals at the start of each bus cycle and an active READY# terminates each bus cycle. The cycles are shown in Figure 3-11.

- ADS# is driven low to start each bus cycle.
- Control signals M/IO#, D/C#, and W/R# are driven low to signal to interrupt-acknowledge bus cycles. These signals must be decoded to generate the INTA input signal for the 8259A. The decoding logic is usually included in the bus controller logic for the particular design. Bus controller designs are discussed in Chapters 6 and 8.
- LOCK# is active from the beginning of the first cycle to the end of the second. HOLD requests from other bus masters are not recognized until after the second interrupt acknowledge cycle.
- The address driven during the first cycle is 4; during the second cycle, the address is 0. BE3#, BE2#, and BE1# are high, BE0# is low, and A31-A3 are low for both cycles; A2 is high for the first cycle and low for the second.
- The 80386 floats D31-D0 for both cycles; however, at the end of the second cycle, the service routine vector at the 8259A outputs is read by the 80386 on pins D7-D0.
- READY# must go low to terminate each cycle.

System logic must delay READY# to extend the cycle to the minimum pulse-width requirement of the 8259A Programmable Interrupt Controller. In addition, the 80386 inserts at least 160 nanoseconds of bus idle time (four Ti states) between the two cycles to match the recovery time of the 8259A.






Figure 3-11. Interrupt Acknowledge Bus Cycles

3.1.8 Halt/Shutdown Cycle

The halt condition in the 80386 occurs in response to a HLT instruction. The shutdown condition occurs when the 80386 is processing a double fault and encounters a protection fault; the 80386 cannot recover and shuts down. Halt or shutdown cycles result from these conditions. Externally, a shutdown cycle differs from a halt cycle only in the resulting address bus outputs.

As with other bus cycles, a halt or shutdown cycle is initiated by activating ADS# and the bus status pins as follows:

• M/IO# and W/R# are driven high, and D/C# is driven low to indicate a halt cycle.



• All address bus outputs are driven low. For a halt condition, BE2# is active; for a shutdown condition, BE0# is active. These signals are used by external devices to respond to the halt or shutdown cycle.

READY# must be asserted to complete the halt or shutdown cycle. The 80386 will remain in the halt or shutdown condition until...

- NMI goes high; 80386 services the interrupt
- RESET goes high; 80386 is reinitialized

In the halt condition (but not in the shutdown condition), if maskable interrupts are enabled, an active INTR input will cause the 80386 to end the halt cycle to service the interrupt. The 80386 can service processor extension (PEREQ input) requests and HOLD (HOLD input) requests while in the halt or shutdown condition.

3.1.9 BS16 Cycle

The 80386 can perform data transfers for both 32-bit and 16-bit data buses. A control input, BS16#, allows the bus size to be specified for each bus cycle. This dynamic bus sizing gives the 80386 flexibility in using 16-bit components and buses.

The BS16# input causes the 80386 to perform data transfers for a 16-bit data bus (using data bus signals D15-D0) rather than a 32-bit data bus. The 80386 automatically performs two or three cycles for data transfers larger than 16 bits and for misaligned (odd-addressed) 16-bit transfers.

BS16# must be supplied by external hardware, either through chip select decoding or directly from the addressed device. BS16# is sampled at the start of Phase 2 only in CLK cycle as long as ADS# is not active. If BS16# and READY# are sampled low in the same CLK cycle, the 80386 assumes a 16-bit data bus.

The BS16# control input affects the performance of a data transfer only for data transfers in which 1) BE0# or BE1# is active and 2) BE2# or BE3# is active at the same time. In these transfers, the 80386 must perform two bus cycles using only the lower half of the data bus.

If a BS16 cycle requires an additional bus cycle, the 80386 will retain the current address for the second cycle. Address pipelining cannot be used with BS16 cycles because address pipelining requires that the next address be generated on the bus before the end of the current bus cycle. Therefore, because both signals are sampled at the same sampling window, BS16# must be active before or at the same time as NA# to guarantee 16-bit operation. Once NA# is sampled active in a bus cycle and BS16# is not active at that time, BS16# must be negated for the remainder of the bus cycle.

If BS16# is asserted during the last clock of the bus cycle and NA# was not asserted previously in the bus cycle, then the processor performs a 16-bit bus cycle. This is true, even if NA# is asserted during the last clock of the bus cycle. Figure 3-12 illustrates this logic.






Figure 3-12. Internal NA# and BS16# Logic

Figure 3-13 compares the signals for 32-bit and 16-bit bus cycles.

3.1.10 16-Bit Byte Enables and Operand Alignment

For a 16-bit data bus, the 80386 views memory and I/O as sequences of 16-bit words. For this configuration, the Bus High Enable (BHE#), A0 or Bus Low Enable (BLE#), and A1 signals are needed. BHE# and BLE# are byte enables that correspond to two banks of memory in the same way that BE3#-BE0# correspond to four banks. A1 is added to A31-A2 to generate the addresses of 2-byte locations instead of 4-byte locations. Figure 3-14 compares the addressing configurations of 32-bit and 16-bit data buses.

The BHE#, BLE#, and A1 signals can be generated from BE3#, BE2#, BE1#, and BE0# using just four external logic gates. Table 3-5 shows the truth table for this conversion. Note that certain combinations of BE3#-BE0# are never generated.

When BS16# is sampled active, the states of BE3#-BE0# determine how the 80386 responds:

- BS16# has no effect if activated for a bus cycle in which BE3# and BE2# are inactive.
- If BE0# and BE1# are both inactive during a BS16 cycle, and either BE2# or BE3# is active,
 - For a write cycle, data on D31-D16 is duplicated on D15-D0, regardless of the state of BS16#. (This duplication occurs because BS16# is sampled late in the cycle but data must be available early).
 - For a read cycle, data that would normally be read on D31-D24 is read on D15-D8, and data that would normally be read on D23-D16 is read on D7-D0.
- If BE0# or BE1# is active, and BE2# or BE3# is active, two bus cycles are required. The two cycles are identical except BE0# and BE1# are inactive in the second cycle and
 - For a write cycle, the data that was on D31-D16 in the first cycle is copied onto D15-D0.
 - For a read cycle, data that would normally be read on D31-D24 is read on D15-D8, and data that would normally be read on D23-D16 is read on D7-D0.






Figure 3-13. 32-Bit and 16-Bit Bus Cycle Timing






Figure 3-14. 32-Bit and 16-Bit Data Addressing

Table 3-6 shows which combinations of BE3#-BE0# require two bus cycles and the states of BE3#-BE0# for each cycle.

In some cases, 16-bit cycles may be performed without using BS16#. Address pipelining may be used as follows for these cycles.

- BS16# is not needed for cycles that use only D15-D0.
- BS16# is not needed for a word-aligned 16-bit write. For write cycles, all 32 bits of the data bus are driven regardless of bus size.

3.2 BUS TIMING

This section describes timing requirements for read cycles, write cycles, and the READY# signal.

All 80386 signals have setup and hold time requirements relative to CLK2. The timings of certain signals relative to one another depends on whether address pipelining is used. These facts must be considered when determining external logic needed to facilitate bus cycles.



Table 3-5. Generation of BHE#, BLE#, and A1 from Byte Enables

	80386 Signals				16-Bit Bus	Signals	Comments
BE3#	BE2#	BE1#	BEO#	A1	вне#	BLE# (AO)	Comments
H* H H H H H H L	H* H H L L* L	H* H L H H L H H	H* L H L H L H L	X L L H X L L H	X H L H X L L	x L H L X H L	x—no active bytes x—not contiguous bytes
L* L* L* L L L	H* H* L L* L	H* L* L* H H*	L* H* L* H L* H L*	X X H X L	X X X L X L	X X X L X H L	x—not contiguous bytes x—not contiguous bytes x—not contiguous bytes x—not contiguous bytes

BLE# asserted when D0-D7 of 16-bit bus is active. BHE# asserted when D8-D15 of 16-bit bus is active. A1 low for all even words; A1 high for all odd words.

Key:

 $\dot{x} = don't care$

H = high voltage level

L = low voltage level

* = a non-occurring pattern of Byte Enables; either none are asserted, or the pattern has Byte Enables asserted for non-contiguous bytes

Table 3-6. Byte Enables during BS16 Cycles

First Cycle:					Secon	d Cycle:	
BE3#	BE2#	BE1#	BEO#	BE3#	BE2#	BE1#	BEO#
High	High	High	Low	None			1
High	High	Low	High	None			
High	High	Low	Low	None	į.		1
High	Low	High	High	None			
High	Low	Low	High	High	Low	High	High
High	Low	Low	Low	High	Low	High	High
Low	High	High	High	None		_	
Low	Low	High	High	None	!		
Low	Low	Low	High	Low	Low	High	High
Low	Low	Low	Low	Low	Low	High	High



The analyses that follow are based on the assumption that a 16-MHz 80386 is used. If the processor is operated at a different frequency, the timings will change accordingly. Example worst-case signal parameter values from the 80386 Data Sheet (Order Number 231630) are used; consult the most recent data sheet to confirm these values. Also note that delay times and setup times must be factored into the timing of system response and interaction with the 80386 to ensure comfortable margins for all critical timings.

3.2.1 Read Cycle Timing

For read cycles, the minimum amount of time from the output of valid addresses to the reading of the data bus sets an upper limit on memory access times (including address decoding time). In a non-pipelined address cycle, this time is

Four CLK2 cycles	125 nanoseconds
- A31-A2 output delay (maximum)	-38 nanoseconds
- D31-D0 input setup (minimum)	-10 nanoseconds
	77 nanoseconds

With address pipelining and no wait states, the address is valid one CLK cycle earlier:

Non-pipelined value	77 nanoseconds
+ One CLK cycle (2 CLK2 cycles)	+62.5 nanoseconds
	139.5 nanoseconds

For both cases above, each wait state in the bus cycle adds 62.5 nanoseconds.

3.2.2 Write Cycle Timing

For write cycles, the elapsed time from the output of valid address to the end of the cycle determines how quickly the external logic must decode and latch the address. In a non-pipelined address cycle, this time is

Four CLK2 cycles — A31-A2 output delay (maximum)	125 nanoseconds —38 nanoseconds		
	87 nanoseconds		
(With address pipelining) (With N wait states)	(+ 62.5 nanoseconds) (+ N*62.5 nanoseconds)		



The minimum amount of time from the output of valid write data by the access device to the end of the write cycle is the least amount of time external logic has to read the data. This setup time is

Data outputs are valid beyond the end of the bus cycle. This data hold time is at least

(Wait states do not affect this parameter)

Wait states add the same amounts of data-to-end-of-cycle time as they do for read cycles. (See Section 3.2.1.)

3.2.3 READY# Signal Timing

The amount of time from the output of valid address signals to the assertion of READY# to end a bus cycle determines how quickly external logic must generate the READY# signal. READY# must meet the 80386 setup time. In a nonpipelined address cycle, READY# signal timing is as follows:

Four CLK2 cycles — A31-A2 output delay (maximum) —READY# setup (minimum)	125 nanoseconds - 38 nanoseconds - 20 nanoseconds
	67 nanoseconds
(With address pipelining) (With N wait states)	(+ 62.5 nanoseconds) (+ N*62.5 nanoseconds)

Again, pipelining and wait states increase this amount of time.

Because the efficiency of a cache depends upon quick turnaround of cache hits (i.e., when requested data is found in the cache) the timing of the READY# signal is critical; therefore, READY# is typically generated combinationally from the cache hit comparator. If the READY# signal is returned too slowly, the speed advantage of the cache is lost.



3.3 CLOCK GENERATION

3.3.1 82384 Clock Generator

The 82384 Clock Generator is a multifunction component of the 80386 system that provides clocking for synchronous operation of the 80386 and its support components as follows:

- Both CLK2 (a double-frequency clock for the 80386 and some support devices) and CLK (a system clock for some 80386 support devices) are generated. The phase of the 82384 CLK matches that of the CLK signal generated internally by the 80386.
- The RESET signal for the 80386 and other system components is generated. The RES# input of the 82384 accepts an asynchronous input from a simple RC circuit or similar source, synchronizes the signal with CLK, and outputs the active-high RESET signal to the 80386 and other system components. The timing and function of the RESET signal with respect to the 80386 is discussed later in this chapter.
- The 82384 uses the ADS# output of the 80386 (which guarantees setup and hold time to CLK2) to generate an ADSO# signal, which is functionally equivalent to ADS# but guarantees setup and hold times with respect to CLK. Devices that are clocked with the CLK output of the 82384 can use ADSO#.

Figure 3-15 shows a typical circuit to connect the 82384 to the 80386.

Either an external frequency source or a third overtone crystal can be used to drive the 82384. The F/C# input indicates the signal source; if F/C# is pulled high, the 82384 recognizes the signal on its External Frequency Input (EFI) pin as its frequency source. If F/C# is tied low, the crystal connected to the X1 and X2 pins of the 82384 is its frequency source. In either case, the source frequency must equal the desired CLK2 frequency. For example, a 32 MHz crystal yields a 32 MHz CLK2 signal and a 16 MHz 80386 internal clock rate.

3.3.2 Clock Timing

The CLK2 and CLK outputs of the 82384 are both MOS-level outputs with output high voltage levels of $V_{\rm CC}-0.6V$ and adequate drive for TTL inputs. CLK2 is twice the frequency of CLK.

The internal CLK signal of the 80386 is matched to the CLK output of the 82384 by the falling edge of the RESET signal. This operation is described with the RESET function in Section 3.8.

The skew between the 82384 CLK2 and CLK signals is maintained at 0-16 nanoseconds (regardless of clock frequency). For closely timed interfaces, peripheral devices must be timed by CLK2. Devices that cannot be operated at the double-clock frequency must use the CLK output of the 82384. The 80386 interface to these devices must allow for the CLK2-to-CLK skew.






Figure 3-15. Connecting 82384 to 80386

The phase of the CLK output of the 82384 is useful for determining the beginning of a bus cycle. Because each CLK2 cycle is 31.25 nanoseconds (at CLK2 = 32 MHz), and bus status signal delays may be as much as 35 nanoseconds, it is impossible to tell from these status signals alone which CLK2 cycle begins the bus cycle, and therefore when to expect valid address signals. The phase of CLK can be used to make this determination. ADS# should be sampled on rising CLK2 transitions when CLK is high, i.e., at the end of phase 2 (see Figure 3-16).

3.3.3 Crystal Oscillator Clock Generator

Figure 3-17 shows a clock generator circuit for the 80386. It is implemented with TTL and CMOS components and is functionally similar to the 82384 clock generator. This circuit replaces the 82384 and is recommended for new designs. It provides the CLK2, CLK, and RESET signals needed by the 80386 and local bus controller. The CLK2 signal provides the fundamental timing for the 80386 and is generated by a CMOS crystal oscillator. This oscillator must have a CMOS output buffer guaranteed compatible with the 80386 CLK2 input.






Figure 3-16. Using CLK to Determine Bus Cycle Start




Figure 3-17. Clock Generator



A 74F109 flip-flop divides CLK2 by two to generate CLK. CLK has the same phase as the 80386 internal clock, going low during phase 1 and high during phase 2. A 74F379 generates a synchronous RESET output, ensuring that the falling edge of RESET occurs during phase 2.

The recommended circuit does not implement the ADS# synchronization feature of the 82384. The ADS# synchronizer is not necessary if all registered PALs in the local bus controller use CLK2. Clocking PALs with CLK2 (rather than CLK) is the preferred method since it minimizes skew between the processor and its surrounding logic. If it is necessary to have an address status signal synchronous to CLK, then an ADS# synchronizer may be built using a delay line and flip-flop, as shown in Figure 3-18.

An alternative method of generating CLK2 is to use a TTL oscillator coupled to a 74ACT244 buffer. Although a typical 74ACT244 datasheet does not guarantee an output compatible with the 80386 CLK2 input, some manufacturers devices have been observed to have sufficiently fast rise/fall times (4 ns at CL=80 pf), as well as the necessary swing, to meet the 80386 CLK2 requirements. This approach is recommended if the 80386 must run synchronously with an external clock (i.e. EFI). Similarly, if a CMOS level swing is required on CLK, a 74AC109 flip-flop may be used instead of the 74F109.

3.4 INTERRUPTS

Both hardware-generated and software-generated interrupts can alter the programmed execution of the 80386. A hardware-generated interrupt occurs in response to an active input on one of two 80386 interrupt request inputs (NMI or INTR). A software-generated interrupt occurs in response to an INT instruction or an exception (a software condition that




Figure 3-18. ADS# Synchronizer



requires servicing). For complete information on software-generated interrupts, see the 80386 Programmer's Reference Manual.

In response to an interrupt request, the 80386 processes the interrupt (saves the processor state on the stack, plus task information if a task switch is required) and services the interrupt (transfers program execution to one of 256 possible interrupt service routines). Entrypoint descriptors to service routines or interrupt tasks are stored in a table (Interrupt Descriptor Table or IDT) in memory. To access a particular service routine, the 80386 must obtain a vector, or index, to the table location that contains the corresponding descriptor. The source of this vector depends on the type of interrupt; if the interrupt is maskable (INTR input active), the vector is supplied by the 8259A Interrupt Controller. If the interrupt is nonmaskable (NMI input active), location 2 in the IDT is used automatically.

The NMI request and the INTR request differ in that the 80386 can be programmed to ignore INTR requests (by clearing the interrupt flag of the 80386). An NMI request always provokes a response from the 80386 unless the 80386 is already servicing a previous NMI request. In addition, an INTR request causes the 80386 to perform two interrupt-acknowledge bus cycles to fetch the service-routine vector. These bus cycles are not required for an NMI request, because the vector location for an NMI request is fixed.

Under the following two conditions a service routine will not be interrupted by an incoming interrupt:

- The incoming interrupt is an INTR request, and the 80386 is programmed to ignore maskable interrupts. (The 80386 is automatically programmed to ignore maskable interrupts when it receives any interrupt request. This condition may be changed by the interrupt service routine.) In this case, the INTR request will be serviced only if it is still active when maskable interrupts are reenabled.
- The incoming interrupt is an NMI, and the 80386 is servicing a previous NMI. In this case, the NMI is saved automatically to be processed after the IRET instruction in the NMI service routine has been executed. Only one NMI can be saved; any others that occur while the 80386 is servicing a previous NMI will not be recognized.

If neither of the above conditions is true, and an interrupt occurs while the 80386 is servicing a previous interrupt, the new interrupt is processed and serviced immediately. The 80386 then continues with the previous service routine. The last interrupt processed is the first one serviced.

If an NMI request and an INTR request arrive at the 80386 simultaneously, the NMI request is processed first. Multiple hardware interrupts arriving at the 8259A are processed according to their priority and are sent to the 80386 INTR input one at a time.

3.4.1 Non-Maskable Interrupt (NMI)

The NMI input of the 80386 generally signals a catastrophic event, such as an imminent power loss, a memory error, or a bus parity error. This input is edge-triggered (on a low-to-high transition) and asynchronous. A valid signal is low for eight CLK2 periods before the transition and high eight CLK2 periods after the transition. The NMI signal can be asynchronous to CLK2.



An NMI request automatically causes the 80386 to execute the service routine corresponding to location 2 in the IDT. The 80386 will not service subsequent NMI requests until the current request has been serviced. The 80386 disables INTR requests (although these can be reenabled in the service routine) in Real Mode. In Protected Mode, the disabling of INTR requests depends on the gate in IDT location 2.

3.4.2 Maskable Interrupt (INTR)

The INTR input of the 80386 allows external devices to interrupt 80386 program execution. To ensure recognition by the 80386, the INTR input must be held high until the 80386 acknowledges the interrupt by performing the interrupt acknowledge sequence. The INTR input is sampled at the beginning of every instruction; it must be high at least eight CLK2 periods prior to the instruction to guarantee recognition as a valid interrupt. This requirement reduces the possibility of false inputs from voltage glitches. In addition, maskable interrupts must enabled in software for interrupt recognition. The INTR input may be asynchronous to CLK2.

The INTR signal is usually supplied by the 8259A Programmable Interrupt Controller, which in turn is connected to devices that require interrupt servicing. The 8259A, which is controlled by commands from the 80386 (the 8259A appears as a set of I/O ports), accepts interrupt requests from devices connected to the 8259A, determines the priority for transmitting the requests to the 80386, activates the INTR input, and supplies the appropriate service routine vector when requested.

An INTR request causes the 80386 to execute two back-to-back interrupt acknowledge bus cycles, as described earlier in Section 3.1.4.

3.4.3 Interrupt Latency

The time that elapses before an interrupt request is serviced (interrupt latency) varies according to several factors. This delay must be taken into account by the interrupt source. Any of the following factors can affect interrupt latency:

- If interrupts are masked, an INTR request will not be recognized until interrupts are reenabled.
- If an NMI is currently being serviced, an incoming NMI request will not be recognized until the 80386 encounters the IRET instruction.
- If the 80386 is currently executing an instruction, the instruction must be completed. An interrupt request is recognized only on an instruction boundary. (However, Repeat String instructions can be interrupted after each iteration.)
- Saving the Flags register and CS:EIP registers (which contain the return address) requires time.
- If interrupt servicing requires a task switch, time must be allowed for saving and restoring registers.
- If the interrupt service routine saves registers that are not automatically saved by the 80386, these instructions also delay the beginning of interrupt servicing.



The longest latency occurs when the interrupt request arrives while the 80386 is executing a long instruction such as multiplication, division, or a task-switch in the Protected mode.

If the instruction loads the Stack Segment register, an interrupt is not processed until after the following instruction, which should be an ESP load. This allows the entire stack pointer to be loaded without interruption.

If an instruction sets the interrupt flag (thereby enabling interrupts), an interrupt is not processed until after the next instruction.

3.5 BUS LOCK

In a system in which more than one device may control the local bus, locked cycles must be used when it is critical that two or more bus cycles follow one another immediately. Otherwise, the cycles can be separated by a cycle from another bus master.

Any bus cycles that must be performed back-to-back without any intervening bus cycles by other bus masters should be locked. The use of a semaphore is one example of this precept. The value of a semaphore indicates a condition, such as the availability of a device. If the 80386 reads a semaphore to determine that a device is available, then writes a new value to the semaphore to indicate that it intends to take control of the device, the read cycle and write cycle should be locked to prevent another bus master from reading from or writing to the semaphore in between the two cycles. The erroneous condition that could result from unlocked cycles is illustrated in Figure 3-19.

The LOCK# output of the 80386 signals the other bus masters that they may not gain control of the bus. In addition, an 80386 with LOCK# asserted will not recognize a HOLD request from another bus master.

3.5.1 Locked Cycle Activators

The LOCK# signal is activated explicitly by the LOCK prefix on certain instructions. LOCK# is also asserted automatically for an XCHG instruction, a descriptor update, interrupt acknowledge cycles, and a page table update.

3.5.2 Locked Cycle Timing

LOCK# is activated on the CLK2 edge that begins the first locked bus cycle. LOCK# is deactivated when READY# is sampled low at the end of the last bus cycle to be locked.

LOCK# is activated and deactivated on these CLK2 edges whether or not address pipelining is used. If address pipelining is used, LOCK# will remain active until after the address bus and bus cycle status signals have been asserted for the pipelined cycle. Consequently, the LOCK# signal can extend into the next memory access cycle that does not need to be locked. (See Figure 3-20.) The result is that the use of the bus by another bus master is delayed by one bus cycle.






Figure 3-19. Error Condition Caused by Unlocked Cycles

3.5.3 LOCK# Signal Duration

The maximum duration of the LOCK# signal affects the maximum HOLD request latency because HOLD is not recognized until LOCK# goes inactive. The duration of LOCK# depends on the instruction being executed and the number of wait states per cycle.

The longest duration of LOCK# in real mode is two bus cycles plus approximately two clocks. This occurs during the XCHG instruction and in LOCKed read-modify-write operations. The longest duration of LOCK# in protected mode is five bus cycles plus approximately fifteen clocks. This occurs when an interrupt (hardware or software interrupt) occurs






Figure 3-20. LOCK# Signal during Address Pipelining

and the 80386 performs a LOCKed read of the gate in the IDT (8 bytes), a read of the target descriptor (8 bytes), and a write of the accessed bit in the target descriptor.

3.6 HOLD/HLDA (Hold Acknowledge)

The 80386 provides on-chip arbitration logic that supports a protocol for transferring control of the local bus to other bus masters. This protocol is implemented through the HOLD input and HLDA output.

3.6.1 HOLD/HLDA Timing

To gain control of the local bus, the requesting bus master drives the 80386 HOLD input active. This signal must be synchronous to the CLK2 input of the 80386. The 80386 responds by completing its current bus cycle (plus a second locked cycle or a second cycle required by BS16#). Then the 80386 sets all outputs but HLDA to the three-state OFF condition to effectively remove itself from the bus and drives HLDA active to signal the requesting bus master that it may take control of the bus.



The requesting bus master must maintain HOLD active until it no longer needs the bus. When HOLD goes low, the 80386 drives HLDA low and begins a bus cycle (if one is pending).

For valid system operation, the requesting bus master must not take control of the bus before it receives the HLDA signal and must remove itself from the bus before de-asserting the HOLD signal. Setup and hold times relative to CLK2 for both rising and falling transitions of the HOLD signal must be met.

When the 80386 receives an active HOLD input, it completes the current bus cycle before relinquishing control of the bus. Figure 3-21 shows the state diagram for the bus including the HOLD state.




Figure 3-21. Bus State Diagram with HOLD State



During the HOLD state, the 80386 can continue executing instructions in its Prefetch Queue. Program execution is delayed if a read cycle is needed while the 80386 is in the HOLD state. The 80386 can queue one write cycle internally, pending the return of bus access; if more than one write cycle is needed, program execution is delayed until HOLD is released and the 80386 regains control of the bus.

HOLD has priority over most bus cycles, but HOLD is not recognized between two interrupt acknowledge cycles, between two repeated cycles of a BS16 cycle, or during locked cycles. For the 80386, HOLD is recognized between two cycles required for misaligned data transfers; for the 8086 and 80286 HOLD it is not recognized. This difference should be considered if critical misaligned data transfers are not locked.

HOLD is not recognized while RESET is active, but is recognized during the time between the high-to-low transition of RESET and the first instruction fetch.

All inputs are ignored while the 80386 is in the HOLD state, except for the following:

- HOLD is monitored to determine when the 80386 may regain control of the bus.
- RESET takes precedence over the HOLD state. An active RESET input will reinitialize
 the 80386.
- One NMI request is recognized and latched. It is serviced after HOLD is released.

3.6.2 HOLD Signal Latency

Because other bus masters such as DMA controllers are typically used in time-critical applications, the amount of time the bus master must wait (latency) for bus access can be a critical design consideration.

The minimum possible latency occurs when the 80386 receives the HOLD input during an idle cycle. HLDA is asserted on the CLK2 rising edge following the HOLD active input (synchronous to CLK2).

Because a bus cycle must be terminated before HLDA can go active, the maximum possible latency occurs when a bus-cycle instruction is being executed. Wait states increase latency, and HOLD is not recognized between locked bus cycles, repeated cycles due to BS16#, and interrupt acknowledge cycles.

3.6.3 HOLD State Pin Conditions

LOCK#, M/IO#, D/C#, W/R#, ADS#, A31-A2, BE3#-BE0#, and D31-D0 enter the three-state OFF condition in the HOLD state. Note that external pullup resistors may be required on ADS#, LOCK# and other signals to guarantee that they remain inactive during transitions between bus masters.



3.7 RESET

RESET starts or restarts the 80386. When the 80386 detects a low-to-high transition on RESET, it terminates all activities. When RESET goes low again, the 80386 is initialized to a known internal state and begins fetching instructions from the reset address.

3.7.1 RESET Timing

The 82384 Clock Generator generates the RESET signal to initialize the 80386 and other system components. The 82384 has a Schmitt-trigger RES# input signal used to generate the RESET signal from an active-low pulse. The hysteresis on the RES# input prevents the RESET output from entering an indeterminate state, so a simple RC circuit can be used to generate the RES# input on power-up. Figure 3-22 shows an RC circuit that satisfies timing requirements for the RES# input.

The RESET input of the 80386 must remain high for at least 15 CLK2 periods to ensure proper initialization (at least 80 CLK2 periods if self-test is to be performed). The CLK output of the 82384 is initialized with the rising edge of RESET. When RESET goes low, the 80386 adjusts the falling edge of its internal clock (CLK) to coincide with the start of the first CLK2 cycle after the high-to-low transition of RESET. The 82384 times the high-to-low edge of RESET (synchronous to CLK2) so that the phase of the internal CLK of the 80386 matches the phase of the CLK output of the 82384. This relationship is shown in Figure 3-23.

On the high-to-low transition of RESET, the BUSY# pin is sampled. If BUSY# is low, the 80386 will perform a self-test lasting approximately $2^{20} + 60$ CLK2 cycles before it begins executing instructions. The 80386 continues with initialization after the test, regardless of the test results.

The 80386 fetches its first instruction from linear address 0FFFFFF0H, sometime between 350 and 450 CLK2 cycles after the high-to-low transition of RESET (or, if self-test is




Figure 3-22. Typical RC RESET Timing Circuit






Figure 3-23. RESET, CLK, and CLK2 Timing

performed, after completion of self-test). Because paging is disabled, linear address 0FFFFFF0H is the same as physical address 0FFFFFF0H. This location normally contains a JMP instruction to the beginning of the bootstrap program.

3.7.2 80386 Internal States

RESET should be kept high for at least one millisecond after $V_{\rm CC}$ and CLK2 have reached their DC and AC specifications.

The 80386 samples its ERROR# input during initialization to determine the type of processor extension present in the system. This sampling occurs at some time at least 20 CLK2 periods after the high-to-low transition of RESET and before the first instruction fetch. If the ERROR# input is low, the 80386 assumes that an 80387 numeric coprocessor is being used, and the programmer must issue a command (FINIT) to reset the ERROR# input after initialization. If ERROR# is high, an 80287 or no processor extension is assumed. In this case, a software test must be run to determine whether an 80287 is actually present and to set the corresponding flag in the 80386. This test is described in Chapter 5.

3.7.3 80386 External States

RESET causes the 80386 output pins to enter the states shown in Table 3-7. Data bus pins enter the three-state condition.



Prior to its first instruction fetch, the 80386 makes no internal requests to the bus, and, therefore, will relinquish bus control if it receives a HOLD request (see Section 3.7 for a complete description of HOLD cycles).

Interrupt requests (INTR and NMI) are not recognized before the first instruction fetch.

Table 3-7. Output Pin States during RESET

Pin Name	Pin State
LOCK#, D/C#, ADS#, A31-A2 W/R#, M/IO#, HLDA, BE3#-BE0#	High Low
D31-D0	Three-State



CHAPTER 4 PERFORMANCE CONSIDERATIONS

System performance measures how fast a microprocessing system performs a given task or set of instructions. Through increased processing speed and data throughput, an 80386 operating at the heart of a system can improve overall performance immensely. The design of supporting logic and devices for efficient interaction with the 80386 is also important in optimizing system performance.

This chapter describes considerations for achieving high performance in 80386-based systems. A variety of examples illustrate the potential performance levels for a number of applications.

4.1 WAIT STATES AND PIPELINING

Because a system may include devices whose response is slow relative to the 80386 bus cycle, the overall system performance is often less than the potential performance of the 80386. Two techniques for accommodating slow devices are wait states and address pipelining. The designer must consider how to use one or both of these techniques to minimize the impact of device performance on system performance.

The impact of memory device speed on performance is generally much greater than that of I/O device speed because most programs require more memory accesses than I/O accesses. Therefore, the following discussion focuses on memory performance.

Wait states are extra CLK cycles added to the 80386 bus cycle. External logic generates wait states by delaying the READY# input to the 80386. For an 80386 operating at 16 MHz, one wait state adds 62.5 nanoseconds to the time available for the memory to respond. Each wait state increases the bus cycle time by 50 percent of the zero wait-state cycle time; however, overall system performance does not vary in direct proportion to the bus cycle increase. The second column of Table 4-1 shows the performance impact (based on an example simulation) for memory accesses requiring different numbers of wait states; one wait state results in an overall performance decrease of 19 percent.

Table 4-1. 80386 Performance with Wait States and Pipelining

Wait States When Address is Pipelined	Wait States When Address is Not Pipelined	Performance Relative to Non-Pipelined 0 Wait-State	Bus Utilization	
0	0	1.00	73%	
0	1	0.91	79%	
1	1	0.81	86%	
1	2	0.76	89%	
2	2	0.66	91%	
2	3	0.63	92%	
3 .	. 3	0.57	93%	



Unlike a wait state, address pipelining increases the time that a memory has to respond by one CLK cycle without lengthening the bus cycle. This extra CLK cycle eliminates the output delay of the 80386 address and status outputs. Address pipelining overlaps the address and status outputs of the next bus cycle with the end of the current bus cycle, lengthening the address access time by one or more CLK cycles from the point of view of the accessed memory device. An access that requires two wait states without address pipelining would require one wait state with address pipelining. The third column of Table 4-1 shows performance with pipelining for different wait-state requirements.

Address pipelining is advantageous for most bus cycles, but if the next address is not available before the current cycle ends,the 80386 cannot pipeline the next address, and the bus timing is identical to a non-pipelined bus cycle. Also, the first bus cycle after an idle bus must always be non-pipelined because there is no previous cycle in which to output the address early. If the next cycle is to be pipelined, the first cycle must be lengthened by at least one wait state so that the address can be output before the end of the cycle.

With the 80386, address pipelining is optional so that bus cycle timing can be closely tailored to the access time of the memory device; pipelining can be activated once the address is latched externally or not activated if the address is not latched.

The 80386 NA# input controls address pipelining. When the system no longer requires the 80386 to drive the address of the current bus cycle (in most systems, when the address has been latched), the system can activate the 80386 NA# input. The 80386 outputs the address and status signals for the next bus cycle on the next CLK cycle.

The system must activate the NA# signal without knowing which device the next bus cycle will access. In an optimal 80386 system, address pipelining should be used even for fast memory that does not require pipelining, because if a fast memory access is followed by a pipelined cycle to slower memory, one wait state is saved. If a fast memory access is followed by another fast memory access, the extra time is not used, and no processor time is lost. Therefore, all devices in a system must be able to accept both pipelined and non-pipelined cycles.

Consider a system in which a non-pipelined memory access requires one wait state and a non-pipelined I/O access requires four wait states. The bus control logic reads chip select signals from the address decoder to determine whether one or four wait states are required for the bus cycle. The bus control logic also determines whether the address has been pipelined, because a pipelined cycle requires one less wait state. The system includes logic for generating a Bus Idle signal that indicates whether the bus cycle has ended. The bus control logic can therefore detect that the address has been pipelined if the Address Status (ADS#) signal goes active while the Bus Idle signal is inactive.

Address pipelining is less effective for I/O devices requiring several wait states. The larger the number of wait states required, the less significant the elimination of one wait state through pipelining becomes. This fact coupled with the relative infrequency of I/O accesses means that address pipelining for I/O devices usually makes little difference to system performance.



A third and less common approach to accommodating memory speed is reducing the 80386 operating frequency. Because a slower clock frequency increases the bus cycle time, fewer wait states may be required for particular memory devices. At the same time, however, system performance depends directly on the 80386 clock frequency; execution time increases in direct proportion to the increase in clock period (reduction in clock frequency). A 12.5-MHz 80386 requires almost 33 percent more time to execute a program than a 16-MHz 80386 operating with the same number of wait states.

The design and application determine whether frequency reduction makes sense. In some instances, a slight reduction in clock frequency reduces the wait-state requirement and increases system performance. Table 4-2 shows that a 12.5-MHz 80386 operating with zero wait states yields better performance than a 16-MHz 80386 operating with two wait states.

Table 4-2. Performance versus Wait States and Operating Frequency

Number of Wait States	16 MHz Without Pipelining	16 MHz With Pipelining	12.5 MHz Without Pipelining	12.5 MHz With Pipelining
0	1.00	0.91	0.78	0.71
1	0.81	0.76	0.64	0.59
2	0.66	0.63	0.52	0.49
3	0.57		0.45	· —



CHAPTER 5 COPROCESSOR HARDWARE INTERFACE

A numeric coprocessor enhances the performance of an 80386 system by performing numeric instructions in parallel with the 80386. The 80386 automatically passes on these instructions to the coprocessor as it encounters them.

Intel offers two numeric coprocessors:

- The 80287 performs 16-bit data transfers. With the proper interface, the 80386 supports the 80287.
- The 80387 performs 32-bit data transfers and interfaces directly with the 80386. The 80387 supports the instruction set of both the 80287 and the 8087, offering additional enhancements that include full compatibility with the IEEE Floating-Point Standard, draft 10. The performance of a 16-MHz 80387 is about eight times faster than that of a 5-MHz 80287.

Either an 80287 or an 80387 numeric coprocessor can be included in an 80386 system. The 80386 samples its ERROR# input during initialization to determine which coprocessor is present. As mentioned above, the 80287 and 80387 require different interfaces and therefore slightly different protocols. The 80287 data bus is 16 bits wide, whereas the 80387 data bus is 32 bits wide.

Data transfers to and from a coprocessor are accomplished through I/O addresses 800000F8H and 800000FCH; these addresses are automatically generated by the 80386 for coprocessor instructions and allow simple chip-select generation using A31 (high) and M/IO# (low). Because A31 is high for coprocessor cycles, the coprocessor addresses lie outside the range of the programmed I/O address space and are easy to distinguish from programmed I/O addresses. Coprocessor usage is independent of the I/O privilege level of the 80386.

The 80386 has three input signals for controlling data transfer to and from an 80287 or 80387 coprocessor: BUSY#, Coprocessor Request (PEREQ), and ERROR#. These signals, which are level-sensitive and may be asynchronous to the CLK2 input of the 80386, are described as follows:

- BUSY# indicates that the coprocessor is executing an instruction and therefore cannot accept a new one. When the 80386 encounters any coprocessor instruction except FNINIT and FNCLEX, the BUSY# input must be inactive (high) before the coprocessor accepts the instruction. A new instruction therefore cannot overrun the execution of the current coprocessor instruction. (Certain 80387 instructions can be transferred when BUSY# is active (low). These instructions are queued and do not interfere with the current instruction.)
- PEREQ indicates that the coprocessor needs to transfer data to or from memory. Because the coprocessor is never a bus master, all input and output data transfers are performed by the 80386. PEREQ always goes inactive before BUSY# goes inactive.



• ERROR# is asserted after a coprocessor math instruction results in an error that is not masked by the coprocessor's control register. The data sheets for the 80287 and 80387 describe these errors and explain how to mask them under program control. If an error occurs, ERROR# goes active before BUSY# goes inactive, so that the 80386 can take care of the error before performing another data transfer.

5.1 80287 NUMERIC COPROCESSOR INTERFACE

The 80287 is described in this section only as it relates to the 80386. For a complete functional description of the 80287, see the 80287 Data Sheet.

5.1.1 80287 Connections

The connections between the 80386 and the 80287 are shown in Figure 5-1. These connections are made as follows:

- The 80287 BUSY#, ERROR#, and PEREQ outputs are connected to corresponding 80386 inputs.
- The 80287 RESET input is connected to the 82384 RESET output.
- The 80287 Numeric Processor Select chip-select inputs (NPS1# and NPS2) are connected to the latched M/IO# and A31 outputs, respectively. For coprocessor cycles, M/IO# is always low; A31, high.
- The 80287 Command inputs (CMD1 and CMD0) differentiate data from commands. These inputs are connected to ground and the latched A2 output, respectively. The 80386 outputs address 800000F8H when writing a command, address 800000FCH when writing or reading data.
- The lower half of the data bus connects to the 16 data bits of the 80287. The 80386 transfers data to and from the 80287 only over the D15-D0 lines.
- The 80287 Numeric Processor Read (NPRD#) and Numeric Processor Write (NPWR#) inputs are connected to I/O read and write signals from local bus control logic. The configuration of this logic depends on the overall system.
- The 80287 Processor Extension Acknowledge (PEACK#) input is pulled high. In an 80286 system, the 80286 generates PEACK# to disable the PEREQ output of the 80287 so that extra data is not transferred. Because the 80386 knows the length of the operand and will not transfer extra data, PEACK# is not needed or used in 80386 systems.

5.1.2 80287 Bus Cycles

When the 80386 encounters a coprocessor instruction, it automatically generates one or more I/O cycles to I/O addresses 800000F8H and 800000FCH. The 80386 performs all necessary bus cycles to memory and transfers data to and from the 80287 on the lower half of the






Figure 5-1. 80386 System with 80287 Coprocessor

data bus. The 80386 automatically converts 32-bit memory transfers to 16-bit 80287 transfers and vice versa. Because the 80386 automatically performs 80287 transfers as 16 bits wide, the BS16# input of the 80386 does not need to be activated for transfers to and from the 80287.

Bus control logic must guarantee 80287 timing requirements, particularly the minimum command inactive time (T_{CMDI}). Depending on the design of the bus controller, command delays may be required.



5.1.3 80287 Clock Input

The 80287 can operate from the CLK or CLK2 output of the 82384 or a dedicated clock oscillator. To operate the 80287 from CLK or CLK2, the Clock Mode (CKM) pin of the 80287 must be tied to ground. In this configuration, the 80287 divides the system clock frequency internally by three.

The CKM pin of the 80287 is tied high to operate the 80287 from a dedicated MOS-level clock. In this configuration, the 80287 does not internally divide the clock frequency; it operates directly from the external clock. An 8284A clock driver and an appropriate crystal can be used to provide the 80287 with the desired clock frequency.

5.2 80387 NUMERIC COPROCESSOR INTERFACE

The 80387 achieves significant enhancements in performance and instruction capabilities over the 80287. It runs at internal clock rates of 16 or 20 MHz. To achieve maximum speed, the interface with the 80386 is synchronous and includes a full 32-bit data bus. Detailed information on other 80387 enhancements can be found in the 80387 Data Sheet.

The 80387 is designed to run either fully synchronously or pseudosynchronously with the 80386. In the pseudosynchronous mode, the interface logic of the 80387 runs with the clock signal of the 80386, whereas internal logic runs with a different clock signal.

5.2.1 80387 Connections

The connections between the 80386 and the 80387 are shown in Figure 5-2 and are described as follows:

- The 80387 BUSY#, ERROR#, and PEREQ outputs are connected to corresponding 80386 inputs.
- The 80387 RESETIN input is connected to the 82384 RESET output.
- The 80387 Numeric Processor Select chip-select inputs (NPS1# and NPS2) are connected directly to the 80386 M/IO# and A31 outputs, respectively. For coprocessor cycles, M/IO# is always low; A31, high.
- The 80387 Command (CMD0#) input differentiates data from commands. This input is connected directly to the 80386 A2 output. The 80386 outputs address 800000F8H when writing a command or reading status, address 800000FCH when writing or reading data.
- All 32 bits (D31-D0) of the 80386 data bus connect directly to the data bus of the 80387. Because the data lines are connected directly, any local data bus transceivers must be disabled when the 80386 reads data from the 80387.
- The 80387 READY#, ADS#, and W/R# inputs are connected to the corresponding pins on the 80386. READY# and ADS# are used by the 80387 to track bus activity and determine when W/R#, NPS1#, NPS2, and Status Enable (STEN) can be sampled.






Figure 5-2. 80386 System with 80387 Coprocessor



- Status Enable (STEN) serves as a chip select for the 80387. This pin is high to enable the 80387, and may be driven low to float all 80387 outputs. STEN may be used to do onboard testing (using the overdrive method). STEN may also be used to activate one 80387 at a time, in systems with multiple 80387s. If not needed, STEN should be pulled high.
- Ready Out (READYO#) can be used to acknowledge 80387 bus cycles. The 80387 activates READYO# at such a time that write cycles are terminated after two clocks and read cycles are terminated after three clocks. READYO# can be connected to the 80386 READY# input through logic that ORs READY# signals from other devices. Alternatively, READYO# can be left disconnected, and external logic can be used to acknowledge 80387 bus cycles.

5.2.2 80387 Bus Cycles

When the 80386 encounters a coprocessor instruction, it automatically generates one or more I/O cycles to addresses 800000F8H and 800000FCH. The 80386 will perform all necessary bus cycles to memory and transfer data to and from the 80387. All 80387 transfers are 32 bits wide. If the memory subsystem is only 16 bits wide, the 80386 automatically performs the necessary conversion before transferring data to or from the 80387. Since the 80387 is a 32-bit device, BS16# must not be asserted during 80387 communication cycles.

Read cycles (transfers from the 80387 to the 80386) require at least one wait state, whereas write cycles to the 80387 require no wait states. This requirement is automatically reflected in the state of the READYO# output of the 80387, which can be used to generate the necessary wait state.

5.2.3 80387 Clock Input

The 80387 can be operated in two modes. In either mode, the CLK2 signal must be connected to the 386CLK2 input of the 80387 because the interface to the 80386 is always synchronous. The state of the 80387 CKM input determines its mode:

- In synchronous mode, CKM is high and the 387CLK2 input is not connected. The 80387 operates from the CLK2 signal. Operation of the 80387 is fully synchronous with that of the 80386.
- In pseudo-synchronous mode, CKM is low and a frequency source for the 387CLK2 input must be provided. Only the interface logic of the 80387 is synchronous with the 80386. The internal logic of the 80387 operates from the 387CLK2 clock source, whose frequency may be 10/16 to 16/10 times the speed of CLK2. Figure 5-3 depicts pseudo-synchronous operation.






Figure 5-3. Pseudo-Synchronous Interface

5.3 LOCAL BUS ACTIVITY WITH THE 80287/80387

Both 80287 and 80387 coprocessors use two distinct methods to interact with the 80386:

- The 80386 initiates coprocessor operations during the execution of a coprocessor instruction (an ESC instruction). These interactions occur under program control.
- The coprocessor uses the PEREQ signal to request the 80386 to initiate operand transfers to or from system memory. These operand transfers occur when the 80287/80387 requests them; thus, they are asynchronous to the instruction execution of the 80386.

When the 80386 executes an ESC instruction that requires transfers of operands to or from the coprocessor, the 80386 automatically sets an internal memory address base register, memory address limit register, and direction flag. The coprocessor can then request operand transfers by driving PEREQ active. These requests occur only when the coprocessor is executing an instruction (when BUSY# is active).

Two, three, four or five bus cycles may be necessary for each operand transfer. These cycles include one coprocessor cycle plus one of the following:

- One memory cycle for an aligned operand
- Two memory cycles for a misaligned operand
- Two or three memory cycles for misaligned 32-bit operands to 16-bit memory
- Four memory cycles for misaligned 64-bit operands to 16-bit memory

Data transfers for the coprocessor have the same bus priority as programmed data transfers.



5.4 DESIGNING AN UPGRADABLE 80386 SYSTEM

It is relatively simple to design an 80386 system with an 80287 that may be later upgraded to an 80387. The advantage of such a system is that two performance levels may be addressed by one system at minimal additional cost.

5.4.1 80287/80387 Recognition

5.4.1.1 HARDWARE RECOGNITION OF THE NPX

The 80386 identifies the type of its coprocessor (80287 or 80387) by sampling its ERROR# input some time after the falling edge of RESET and before executing the first ESC instruction. The 80287 keeps its ERROR# output in inactive state after hardware reset; the 80387 keeps its ERROR# output in active state after hardware reset. The 80386 records this difference in the ET bit of control register zero (CR0). The 80386 subsequently uses ET to control its interface with the coprocessor. If ET is set, it employs the 32-bit protocol of the 80387; if ET is not set, it employs the 16-bit protocol of the 80287.

Systems software can (if necessary) change the value of ET. There are three reasons that ET may not be set:

- 1. An 80287 is actually present.
- 2. No coprocessor is present.
- 3. An 80387 is present but it is connected in a nonstandard manner that does not trigger the setting of ET.

An example of case three is a PC/AT-compatible design. In such cases, initialization software may need to change the value of ET.

5.4.1.2 SOFTWARE RECOGNITION OF THE NPX

Figure 5-4 shows an example of a recognition routine that determines whether an NPX is present, and distinguishes between the 80387 and the 8087/80287. This routine can be executed on any 80386, 80286, or 8086 hardware configuration that has an NPX socket.

The example guards against the possibility of accidentally reading an expected value from a floating data bus when no NPX is present. Data read from a floating bus is undefined. By expecting to read a specific bit pattern from the NPX, the routine protects itself from the indeterminate state of the bus. The example also avoids depending on any values in reserved bits, thereby maintaining compatibility with future numerics coprocessors.



```
8086/87/88/186 MACRO ASSEMBLER Test for presence of a Numerics Chip, Revision 1.0
                                                                                                                PAGE
                                                                                                                        1
DOS 3.20 (033-N) 8086/87/88/186 MACRO ASSEMBLER V2.0 ASSEMBLY OF MODULE TEST_NPX
OBJECT MODULE PLACED IN FINDNPX.OBJ
LOC OBJ
                          LINE
                                   SOURCE
                             1 +1 $title('Test for presence of a Numerics Chip, Revision 1.0')
                             3
                                            name
                                                    Test NPX
                             5
                                   stack
                                           segment stack 'stack'
0000 (100
                             6
                                            du
                                                    100 dup (?)
     2222
0008 ????
                             7
                                   sst
                             8
                                   stack
                                           ends
                             10
                                   data
                                           segment public 'data'
0000 0000
                            11
                                           d⊌
                                                    Oh
                                   temp
                            12
                                   data
                                           ends
                            13
                            14
                                   dgroup group
                                                   data, stack
                            15
                                   cgroup
                                           group
                                                   code
                            16
                            17
                                   code
                                           segment public 'code'
                            18
                                           assume cs:cgroup, ds:dgroup
                            19
0000
                            20
                                   start:
                            21
                            22
                                           Look for an 8087, 80287, or 80387 NPX.
                            23
                                           Note that we cannot execute WAIT on 8086/88 if no 8087 is present.
                            24
0000
                            25
                                   test_npx:
0000 90DBE3
                            26
                                           fninit
                                                                    ; Must use non-wait form
0003 BE0000
                            27
                                                    si.offset dgroup:temp
                                           mov
0006 C7045A5A
                            28
                                           mov
                                                    word ptr [si],5A5AH; Initialize temp to non-zero value
                            29
000A 90DD3C
                                           fnstsw
                                                    [si]
                                                                    ; Must use non-wait form of fstsw
                            30
                                                                    ; It is not necessary to use a WAIT instruction
                            31
                                                                      after fistsw or fistow. Do not use one here.
000D 803C00
                            32
                                           стр
                                                    byte ptr [si],0; See if correct status with zeroes was read
0010 752A
                            33
                                                                    ; Jump if not a valid status word, meaning no NPX
                                                   no nox
                            34
                            35
                                           Now see if ones can be correctly written from the control word.
                            36
                            37
38
0012 90D93C
                                           fnstcw [si]
                                                                    ; Look at the control word; do not use WAIT form
                                                                    ; Do not use a WAIT instruction here!
                            39
0015 8804
                                           mov
                                                    ax,[si]
                                                                    ; See if ones can be written by NPX
0017 253F10
                            40
                                           and
                                                    ax,103fh
                                                                    ; See if selected parts of control word look OK
001A 3D3F00
                            41
                                                   ax,3fh
                                                                    ; Check that ones and zeroes were correctly read
                                           стр
001D 751D
                                           ine
                                                                    ; Jump if no NPX is installed
                                                   no npx
                            43
                            44
                                           Some numerics chip is installed. NPX instructions and WAIT are now safe.
                            45
                                           See if the NPX is an 8087, 80287, or 80387.
                            46
                                           This code is necessary if a denormal exception handler is used or the
                            47
                                           new 80387 instructions will be used.
                            48
                                                                                                                      G40107
```

Figure 5-4. Software Routine to Recognize the 80287



LOC	OBJ	LINE	SOURCE				
001F	9BD9E8	49		fld1		; Must use default control word from FNINIT	
0022	9BD9EE	50		fldz		; Form infinity	
0025	9BDEF9	51		fdiv		; 8087/287 says +inf = -inf	
0028	9BD9C0	52		fld	st	; Form negative infinity	
	9BD9E0	53		fchs		; 80387 says +inf <> -inf	
	9BDED9	54		fcompp		; See if they are the same and remove them	
	9BDD3C	55	•	fstsw	[si]	; Look at status from FCCMPP	
	8804	56		MOA	ax,[si]		
0036		57		sahf		; See if the infinities matched	
0037	7406	58		je	found_87_287	; Jump if 8087/287 is present	
		59	;			- 6 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
		60	;			If denormal exceptions are used for an 8087/287,	
		61	;			The 80387 will automatically normalize denormal	
		62	;	operand	s faster than	an exception handler can.	
		63	; '				
	EB0790	64		cymi	found_387		
003C		65	no_npx:				
		. 66	;	set up	for no NPX		
		67	;		• • •		
	==0.400	68	;	•	_		
003C	EB0490	69 70	£	jmpexi	τ		
0031		70 71	found_8		4 07/207		
		71	•	set up	for 87/287		
		73			•••		
0035	EB0190	73 74	;	jmp exi	+		
0042		74 75	found 3				
0042		76	· ·		for 387		
		77	:	set up	101 307		
		77 78	;		•••		
0042		79	exit:				
		80	code	ends			
		81	couc	end	stort desdar	oup,ss:dgroup:sst	

Figure 5-4. Software Routine to Recognize the 80287 (Cont'd.)

5.4.2 80387 Emulator

The 80387 emulator circuit makes a 10-MHz 80287 appear to the 80386 as an 80387. The schematic is shown in Figure 5-5. An 80387 socket (80387 PGA Adapter) is connected to the 80386 (connections not shown) as described earlier in this chapter. Please note that this circuit is provided to illustrate concepts only; it has not been tested.

The 80287 sends signals to the 80386 through the socket. The inputs coming to the socket from the 80386 are decoded by the PAL16L8 (Math Control) to provide the buffered CMD0, NPRD#, and NPWR# inputs for the 80287. The PAL equations for the Math Control PAL are listed in Appendix B of this manual.

The data lines of the 80287 are connected to the lower half of the 80386 data bus through the socket; the BUSY#, ERROR#, and PEREQ signals are returned to the 80386 through the socket as well. Note that while this circuit allows the 80386 to use an 80387 interface with the 80287, the 80287 still performs only 16-bit data transfers. Therefore, during initialization, the ERROR# output of the 80287 is high to indicate the presence of an 80287, not an 80387.





Figure 5-5. 80387 Emulator Schematic



CHAPTER 6 MEMORY INTERFACING

The 80386 high-speed bus interface has many features that contribute to high-performance memory interfaces. This chapter outlines approaches to designing memory systems that utilize these features, describes memory design considerations, and lists a number of useful examples. The concepts illustrated by these examples apply to a wide variety of memory system implementations.

6.1 MEMORY SPEED VERSUS PERFORMANCE AND COST

In a high-performance microprocessing system, overall system performance is linked to the performance of memory subsystems. Most bus cycles in a typical microprocessing system are used to access memory because memory is used to store programs as well as the data used in processing.

To realize the performance potential of the 80386, a system must use relatively fast memory. A high-performance processor coupled with low-performance memory provides no better throughput than a less expensive low-performance processor. Fast memory devices, however, cost more than slow memory devices.

The cost-performance tradeoff can be mediated by partitioning functions and using a combination of both fast and slow memories. If the most frequently used functions are placed in fast memory and all other functions are placed in slow memory, high performance for most operations can be achieved at a cost significantly less than that of a fast memory subsystem. For example, in a RAM-based system that uses read-only memory devices primarily during initialization, the PROM or EPROM can be slow (requiring three to four wait states) and yet have little effect on system performance. RAM memory can also be partitioned into fast local memory and slower system memory. Other performance considerations are described in detail in Chapter 4.

The relationship between memory subsystem performance and the speed of individual memory devices is determined by the design of the memory subsystem. Cache systems, which couple a small cache memory with a larger main memory, are described in Chapter 7. Basic memory interfaces are described in this chapter.

6.2 BASIC MEMORY INTERFACE

The high performance and flexibility of the 80386 local bus interface plus the availability of programmable and semi-custom logic (programmable logic arrays, for example) make it practical to design custom bus control logic that meets the requirements of a particular system. Standard logic components can generate the bus control signals needed to interface the 80386 with memory and I/O devices. The basic memory interface is discussed in this chapter; the basic I/O interface is presented in Chapter 8.



The block diagram of the basic memory interface is shown in Figure 6-1. The bus control logic provides the control signals for the address latches, data buffers, and memory devices; it also returns READY# active to end the 80386 bus cycle and NA# to control address pipelining. The address decoder generates chip-select signals and the BS16# signal based on the address outputs of the 80386. This interface is suitable for accessing ROMs, EPROMs, and static RAMs (SRAMs).

6.2.1 PAL Devices

Many design examples in this manual use PAL (Programmable Array Logic) devices, which can be programmed by the user to implement random logic. A PAL device can be used as a state machine or a signal decoder, for example. The advantages of PALs include the following:

- Programmability allows the PAL functions to be changed easily, simplifying prototype development.
- The designer determines PAL pinout and can simplify the board layout by moving signals as required.




Figure 6-1. Basic Memory Interface Block Diagram



- PALs are inexpensive compared to dedicated bus controllers.
- Once a PAL design has been tested, Hard Array Logic (HAL) devices, which are mask-programmed PALs, can be used in production quantities (several thousand units).

PALs also have the following disadvantages:

- Pin counts or speeds of available PALs can restrict some designs.
- Most PALs do not have buried (not connected to outputs) state registers; therefore, in state-machine implementations, registered output pins must be used to store the current state.
- The drive capability of PALs may be insufficient for some applications. In these cases, buffering is required.

A PAL device consists logically of a programmable AND array whose output terms feed a fixed OR array. Any sum-of-products equation, within the limits of the number of PAL inputs, outputs, and equation terms, can be realized by specifying the correct AND array connections. Figure 6-2 shows an example of two PAL equations and the corresponding logic array. Note that every horizontal line in the AND array represents a multi-input AND gate; every vertical line represents a possible input to the AND gate. The X at the intersection of a horizontal line and a vertical line represents a connection from the input to the AND gate.

Programming a PAL device consists of determining where the Xs must be placed in the AND array. This task is simplified by the use of a PAL assembler program. Such a program accepts input in the form of sum-of-products equations. The assembled code is then applied to a PAL device using a standard PROM programmer equipped with a special PAL enhancement.

The following conventions apply to TTL and PAL devices described in this section:

- TTL devices are specified by number (function), but not by family (speed). Virtually any family of a device can be used if it meets the performance requirements of the application. For example, a 74x00 device might be implemented with a 74F00 or 74AS00. Generally, the F and AS families provide the highest performance.
- PAL devices are specified by part number. A PAL part number generally consists of a number, a letter, and a second number, and is interpreted as shown in Figure 6-3. PALs are manufactured for a number of performance levels. Standard PALs are suitable unless otherwise specified.

6.2.2 Address Latch

Latches maintain the address for the duration of the bus cycle and are necessary to pipeline addresses because the address for the next bus cycle appears on the address lines before the current cycle ends. In this example, 74x373 latches are used. Although the 80386 can be run without address pipelining to eliminate the need for address latching, the system will usually run less efficiently.






Figure 6-2. PAL Equation and Implementation

The 74x373 Latch Enable (LE) input is controlled by the Address Latch Enable (ALE or ALE#) signal from the bus control logic that goes active at the start of each bus cycle. The 74x373 Output Enable (OE#) is always active.

6.2.3 Address Decoder

In this example, the address decoder, which converts the 80386 address into chip-select signals, is located before the address latches. In general, the decoder may also be placed after the latches. If it is placed before the latches, the chip-select signal becomes valid as early as possible but must be latched along with the address. Therefore, the number of address latches needed is determined by the location of the address decoder as well as the number of address bits and chip-select signals required by the interface. The chip-select signals are routed to the bus control logic to set the correct number of wait states for the accessed device.






Figure 6-3. PAL Naming Conventions

The decoder consists of two one-of-four decoders, one for memory address decoding and one for I/O address decoding. In general, the number of decoders needed depends on the memory mapping complexity. In this basic example, the A31 output is sufficient to determine which memory device is to be selected.

6.2.4 Data Transceiver

Standard 8-bit transceivers (74x245, in this example) provide isolation and additional drive capability for the 80386 data bus. Transceivers are necessary to prevent the contention on the data bus that occurs if some devices are slow to remove read data from the data bus after a read cycle. If a write cycle follows a read cycle, the 80386 may drive the data bus before a slow device has removed its outputs from the bus, potentially causing reliability problems. Transceivers can be omitted only if the data float time of the device is short enough and the load on the 80386 data pins meets device specifications.

A bus interface must include enough transceivers to accommodate the device with the most inputs and outputs on the data bus. Normally, 32-bit-wide memories, which require four 8-bit transceivers, are used in 80386 systems.

The 74x245 transceiver is controlled through two input signals:

- Data Transmit/Receive (DT/R#)—When high, this input enables the transceiver for a write cycle. When low, it enables the transceiver for a read cycle. This signal is just a latched version of the 80386 W/R# output.
- Data Enable (DEN#)—When low, this input enables the transceiver outputs. This signal is generated by the bus control logic.



6.2.5 Bus Control Logic

Bus control logic is shown in Figure 6-4. The bus controller is implemented in two PALs. One PAL (PAL-1) follows the 80386 bus cycles and generates the overall bus cycle timing. The second PAL (PAL-2) generates most of the bus control signals. The equations for these PALs are listed in Appendix A of this manual.

The bus controller decodes the 80386 status outputs (W/R#, M/IO#, and D/C#) and activates a command signal for the type of bus cycle requested. The command signal corresponds to the bus cycle types (described in Chapter 3) as follows:

- Memory data read and memory code read cycles generate the Memory Read Command (MRDC#) output. MRDC# commands the selected memory device to output data.
- I/O read cycles generate the I/O Read Command (IORC#) output. IORC# commands the selected I/O device to output data.
- Memory write cycles generate the Memory Write Command (MWTC#) output. MWTC#
 commands the selected memory device to receive the data on the data bus.
- I/O write cycles generate the I/O Write Command (IOWC#) output. IOWC# commands the selected I/O device to receive the data on the data bus.
- Interrupt-acknowledge cycles generate the Interrupt Acknowledge (INTA#) output, which is returned to the 8259A Interrupt Controller. The second INTA cycle commands the 8259A to place the interrupt vector on the bus.

Figure 6-5 shows the timings of bus control signals for various memory accesses.

The bus controller also controls the READY# input to the 80386 that ends each bus cycle. The PAL-2 bus control PAL counts wait states and returns READY# after the number of wait states required by the accessed device. The design of this portion of the bus controller depends on the requirements of the system; relatively simple systems need less wait-state logic than more complex systems. The basic interface described here uses a PAL device to generate READY#; other designs may use counters and/or shift registers.

The bus controller generates one of two bus cycles depending on which memory is being accessed. Two inputs to PAL-1 (CS0WS and CS1WS) from the address decoder determine the bus control signal timings. Table 6-1 shows the number of wait states, the command delay time, and the data float time for each bus cycle.

Ohin Colont	Ovela Torre	WAIT	-STATES	Command	Data Flori	
Chip-Select	Cycle Type	Pipelined	UnPipelined	Delay	Data-Float	
CS0WS	read write	0 1	1 2	1 CLK2 1 CLK2	2 CLK2 —	
CS1WS	any	1	2	2 CLK2	4 CLK2	

Table 6-1. Bus Cycles Generated by Bus Controller




Figure 6-4. Bus Control Logic




Figure 6-5. Bus Control Signal Timing



6.2.6 EPROM Interface

Figure 6-6 shows the signal timing for bus cycles from an 80386 operating at 16 MHz to a 27128-1 EPROM, which has a 150-nanosecond access time. Faster 110-nanosecond EPROMs are also available but in this design, they require the same number of wait states as the 150-nanosecond EPROMs require. Timings for a 150-nanosecond SRAM are included for comparison.

In the EPROM interface, the OE# input of each EPROM devices is connected directly to the MRDC# signal from the bus controller. The wait state requirement is calculated by adding up worst-case delays and comparing the total with the 80386 bus cycle time.

The bus cycle timings can be calculated from the waveforms in Figure 6-6. In the following example, the timings for I/O accesses are calculated for CLK2 = 32 MHz and B-series PALs. All times are in nanoseconds. Check the most recent 80386 Data Sheet to confirm all parameter values.

tAR: Address stable before Read (MRDC# fall)

= 7.75 nanoseconds

tRR: Read (MRDC#) pulse width

(4 x CLK2 period)
$$-$$
 PAL RegOut Max $+$ PAL RegOut Min (4 x 31.25) $-$ 12 $+$ 0

= 113 nanoseconds

tRA: Address hold after Read (MRDC# rise)

= -7 nanoseconds (This is acceptable because latched addresses are held for at least as long as the end of the bus cycle.)

tAD: Data delay from Address

= 148 nanoseconds




Figure 6-6. 150-Nanosecond EPROM Timing Diagram



tRD: Data delay from Read (MRDC#)

= 97 nanoseconds

tDF: read (MRDC# rise) to Data Float

= 116 nanoseconds

To pipeline the address outputs for sequential EPROM accesses, the address decoder logic must generate the Next Address (NA#) signal. Note that the initial EPROM cycle following the idle cycle cannot be address pipelined because there is no previous bus cycle. In addition, the bus cycle following the last EPROM access is pipelined regardless of which device it accesses, because the address is output before the bus cycle destination can be determined.

6.2.7 SRAM Interface

In the SRAM interface, the OE# input of each SRAM device is connected to the MRDC# signal from the bus controller; the WE# input of each SRAM device is driven by the MWTC# signal. Because it is possible to write to only some bytes of a doubleword, the MWTC# signal cannot connect directly to the WE# inputs. Each WE# input must be qualified by the latched 80386 byte-enable signals (BE3#-BE0#).

Figure 6-7 shows the signal timing for bus cycles to an Intel SRAM, which has a 100-nanosecond access time. The timing is essentially the same as for an EPROM.

The bus cycle timings can be calculated from the waveforms in Figure 6-7. In the following example, the timings for I/O accesses are calculated for CLK2 = 32 MHz and B-series PALs. All times are in nanoseconds. Check the most recent 80386 Data Sheet to confirm all parameter values.

tAR: Address stable before Read (MRDC# fall)
tAW: Address stable before Write (MWTC# fall)

= 7.75 nanoseconds




Figure 6-7. 100-Nanosecond SRAM Timing Diagram



tRR: Read (MRDC#) pulse width

= 81.75 nanoseconds

tWW: Write (MWTC#) pulse width

= 113 nanoseconds

tRA: Address Hold after Read (MRDC# rise)

= -7 nanoseconds (This is acceptable because latched addresses are held for at least as long as the end of the bus cycle.)

tWA: Address hold after Write (MWTC# rise)

= 24.25 nanoseconds

tAD: Data delay from Address

= 85.5 nanoseconds

tRD: Data delay from Read (MRDC#)

= 65.75 nanoseconds



tDF: read (MRDC# rise) to Data Float (2 x CLK2 period) — Pal RegOut Max + PAL RegOut Min + xcvr. Enable Min (2×31.25) -12+ 3 = 47.5 nanoseconds tDW: Data setup before write (MWTC# rise) (3 x CLK2 period) - PAL RegOut Max - xcvr. Enable Max + PAL RegOut Min (3×31.25) -12-11+ 0 = 70.75 nanoseconds tWD: Data hold after write (MWTC# rise) (1 x CLK2 period) - PAL RegOut Max + PAL RegOut Min

= 21.25 nanoseconds

6.2.8 16-Bit Interface

The use of a 16-bit data bus can be advantageous for some systems. Memory implemented as 16-bits wide rather than 32-bits wide reduces chip count. I/O addresses located at word boundaries rather than doubleword boundaries can be software compatible with some systems that use 16-bit microprocessors.

For example, if BS16# is asserted for EPROM accesses, only two byte-wide EPROMs are needed. Overall performance is reduced because 32-bit data accesses and all code prefetches from the EPROMs are slower (requiring two bus cycles instead of one). However, this reduction is acceptable in certain applications. A system that uses EPROMs only for power-on initialization and runs programs entirely from SRAM or DRAM has only a power-on time increase over the 32-bit EPROM system; its main programs run at the same speed as the 32-bit system.

The 80386 BS16# input directs the 80386 to perform data transfers on only the lower 16 bits of the data bus. In systems in which 16-bit memories are used, the address decoder logic must generate the BS16# signal for 16-bit accesses. Since NA# cannot be asserted during a bus cycle in which BS16# is asserted (because the current address may be needed for additional cycles), the decoder logic should also guarantee that the NA# signal is not generated. When the 80386 samples BS16# active and NA# inactive, it automatically performs any extra bus cycles necessary to complete a transfer on a 16-bit bus. The 80386 response is determined by the size and alignment of the data to be transferred, as described in Chapter 3.



6.3 DYNAMIC RAM (DRAM) INTERFACE

This section presents a dynamic RAM (DRAM) memory subsystem design that is both costeffective and fast. The design can be adapted for a wide variety of speed and system requirements to provide high throughput at minimum cost. The DRAM design in this section is to illustrate concepts only; the actual circuit has not been tested.

6.3.1 Interleaved Memory

DRAMs provide relatively fast access times at a low cost per bit; therefore, large memory systems can be created at low cost. However, DRAMs have the disadvantage that they require a brief idle time between accesses to precharge; if this idle time is not provided, the data in the DRAM can be lost. If back-to-back accesses to the same bank of DRAM chips are performed, the second access must be delayed by the precharge time. To avoid this delay, memory should be arranged so that each subsequent memory access is most likely to be directed to a different bank. In this configuration, wait time between accesses is not required because while one bank of DRAMs performs the current access, another bank precharges and will be ready to perform the next access immediately.

Most programs tend to make subsequent accesses to adjacent memory locations during code fetches, stack operations, and array accesses, for example. If DRAMs are interleaved (i.e., arranged in multiple banks so that adjacent addresses are in different banks), the DRAM precharge time can be avoided for most accesses. With two banks of DRAMs, one for even 32-bit doubleword addresses and one for odd doubleword addresses, all sequential 32-bit accesses can be completed without waiting for the DRAMs to precharge.

Even if random accesses are made, two DRAM banks allow 50 percent of back-to-back accesses to be made without waiting for the DRAMs to precharge. The precharge time is also avoided when the 80386 has no bus accesses to be performed. During these idle bus cycles, the most recently accessed DRAM bank can precharge so that the next memory access to either bank can begin immediately.

The DRAM memory system design described here uses two interleaved banks of DRAMs. The DRAM controller keeps track of the most recently accessed bank in order to guarantee the precharge time for both banks while allowing memory accesses to begin as soon as possible.

6.3.2 DRAM Memory Performance

Table 6-2 shows the performance that can be obtained using this DRAM design with a variety of processor and DRAM speeds. Performance is indicated by the number of wait states per bus cycle (the number of CLK cycles in addition to the two-CLK minimum time required to complete the access).

The performance for each processor and DRAM speed combination is given for both the case of an access to the opposite bank of interleaved memories, in which no precharge time is required, and the case of an access to the same bank, in which the precharge time is factored in.



80386 Clock Rate	DRAM Access Time (Nanoseconds)	Bus Cycle Wait-States	
		Interleaved Piped:Unpiped	Same Bank
12 MHz 12 MHz 16 MHz 16 MHz 16 MHz	120 200 80 100 150	0*:1* 1 :2 0*:1* 0*:1* 1 :2	1 * 3 1 * 1 * 1 * 3

Table 6-2. DRAM Memory Performance

Note: The numbers for the 100-nanosecond DRAM are based on the assumption that no data transceivers are used.

The number of wait states required for interleaved accesses is based on the assumption that the address for the next access is pipelined. For cycles in which the address is not pipelined, one extra wait-state must be added to the number in Table 6-2. This requirement applies to all cycles that follow an idle bus state because these cycles can never be pipelined.

The number of wait states for same-bank accesses applies only to back-to-back cycles (without intervening idle bus time) to the same bank of DRAMs. Because the controller must allow the DRAMs to precharge before starting the access, address pipelining does not speed up the same-bank cycle; the number of wait states is identical with or without address pipelining.

The numbers in Table 6-2 are affected by DRAM refresh cycles. All DRAMs require periodic refreshing of each data cell to maintain the correct voltage levels. An access to a memory cell, called a refresh cycle, accomplishes the refresh. During one of these periodic refresh cycles, the DRAM cannot respond to processor requests.

Although the distributed DRAM refresh cycles occur infrequently, they can delay the current access so that the current access requires a total of up to four wait states (for the cases marked with an asterisk (*)) or eight wait states (for the other cases).

6.3.3 DRAM Controller

The performances shown in Table 6-2 are derived from two DRAM controller designs that differ in the number of CLKs they allow for read/refresh access and precharge times. The two designs are designated by the number of CLKs required for a read cycle. The 2-CLK design is used for the cases in Table 6-2 that are marked with an asterisk (*); the 3-CLK design is used for the other cases.

^{*}Add one additional wait-state to these times for write accesses.



6.3.3.1 3-CLK DRAM CONTROLLER

Figure 6-8 shows a schematic of the 3-CLK DRAM controller. The DRAM array contains two banks of 32-bit-wide DRAMs. The top and bottom halves of the pictured array represent the two banks, which are each divided vertically along the four bytes for each doubleword.

The DRAM chips used to create the DRAM banks can be of any length (N), and they can be either one bit or four bits wide. If Nx1 DRAM chips are used, 64 chips are required for the two banks; if Nx4 DRAM chips are used, only 16 chips are required. The banks in Figure 6-8 are made from sixteen 64Kx4 DRAMs, but another type of DRAM can be substituted easily.

Two Row Address Strobe (RAS) signals are generated by the controller, one for each bank. The top bank is activated by RASO# and contains the DRAM memory locations for which the 80386 address bit A2 is low. The bottom bank is activated by RAS1#, which corresponds to 80386 addresses for which A2 is high.

Four Column Address Strobe (CAS) signals are used, one for each byte of the 80386 data bus. These CAS signals are shared by both banks. The 80386 Byte Enable signals (BE3#-BE0#) map directly to the CAS signals (CAS3#-CAS0#). CAS0# is mapped directly from BE0# and enables the least-significant byte (D7-D0). Similarly, CAS3# is mapped directly from BE3# and enables the most-significant byte (D31-D24).

Each of the 32 data lines of the 80386 are connected to one DRAM chip from each bank. If Nx1 DRAMs are used, the corresponding data line is connected to both the Din and Dout pins. If Nx4 DRAMs are used, each data line is connected only to the corresponding I/O pin.

The Write Enable (WE#) signal and the multiplexed address signals are connected to every DRAM chip in both banks. Nx4 DRAMs also require an Output Enable (OE#) signal for every DRAM chip in both banks.

A single WE# control signal and four CAS control signals ensure that only those DRAM bytes selected for a write cycle are enabled. All other data bytes maintain their outputs in the high-impedance state. A common design error is to use a single CAS# control signal and four WE# control signals, using the WE# signals to write the DRAM bytes selectively in write cycles that use fewer than 32 bits. However, although the selected bytes are written correctly, the unselected bytes are enabled for a read cycle. These bytes output their data to the unselected bits of the data bus while the data transceivers output data to every bit of the data bus. When two devices simultaneously output data to the same bus, reliability problems and even permanent component damage can result. Therefore, a DRAM design should use CAS signals to enable bytes for a write cycle.

DRAMs require both the row and column addresses to be placed sequentially onto the multiplexed address bus. A set of 74F258 multiplexers accomplishes this function.




Figure 6-8. 3-CLK DRAM Controller Schematic



Four 74F245 octal transceivers buffer the DRAM from the data bus. Most DRAMs used in the 3-CLK design require these transceivers to meet the read-data float time. When a DRAM read cycle is followed immediately by an 80386 write cycle, the 80386 drives its data bus one CLK2 period after the read cycle completes. If the data transceivers are omitted, the RAS inactive delay plus the DRAM output buffer turn-off time (t-OFF) must be less than a CLK2 period to avoid data bus contention.

PALs are used to monitor the 80386 status signals and generate the appropriate control signals for the DRAM, multiplexer, and transceivers. PAL codes and pin descriptions for the 3-CLK design are listed in Appendix C of this manual.

The DRAM State PAL performs the following functions:

- Monitors the 80386 DRAM chip-select logic
- Receives DRAM refresh requests and responds with the necessary DRAM cycles
- Keeps track of DRAM banks requiring precharge time

A DRAM read or write access is requested when all the chip-select signals of the DRAM State PAL are sampled active simultaneously. These signals become active when all of the following conditions exist at once:

- M/IO#, W/R#, and D/C# outputs of the 80386 indicate either a memory read, memory write, or code fetch.
- The bus is idle or the current bus cycle is ending (READY# active).
- ADS# is active.
- A31 is low (in this design, the lower half (two gigabytes) of 80386 memory space is mapped to the DRAM controller).

If the DRAM controller is not already performing a cycle, it begins the access immediately. However, if the DRAM controller is performing a refresh cycle, or if it is waiting for the DRAM bank to precharge, the request is latched and performed when the controller is not busy.

The DRAM Control PAL generates the majority of the DRAM control signals. The Refresh Interval Counter PAL is a timer that generates refresh requests at the necessary intervals. The Refresh Address Counter PAL maintains the next refresh address. Both the Refresh Interval Counter PAL and the Refresh Address Counter PAL are simple enough to be replaced by TTL counter chips; however, the use of PALs reduces the total chip count. If there is a spare timer or counter in the system, it can be used to replace one or both of these PALs.

Figure 6-9 shows the timing of DRAM control signals for the 3-CLK design for the following five sequential DRAM cycles:

- 1. Read cycle
- 2. Write cycle to the opposite bank (no precharge)




Figure 6-9. 3-CLK DRAM Controller Cycles



- 3. Read cycle to that same bank (requires precharge)
- 4. Refresh cycle (always requires precharge)
- 5. Read cycle (cycle after refresh always requires precharge)

During a normal DRAM access, only the RAS signal that corresponds to the selected bank is activated. During a refresh cycle, both RAS signals are activated. During write cycles, only the CAS signals corresponding to the enabled bytes are activated. During read cycles, all CAS signals are enabled.

6.3.3.2 2-CLK DRAM CONTROLLER

Figure 6-10 is a schematic of the 2-CLK design, which provides zero wait-state operation for pipelined interleaved accesses. The design differs from the 3-CLK controller in several ways.

Read and refresh cycles are completed in only two CLKs; write cycles require three CLKs to ensure that the 80386 write data is valid.

In general, the PALs that generate RAS and CAS signals can be either registered or combinatorial on the RAS and/or CAS outputs. If external registers are used, these PAL outputs must be combinatorial so that the output has time to set up the external register on the same CLK2 cycle. If the PAL outputs are used without external registers, the PAL outputs must be registered internally. When the CAS signals are registered internally, the DRAM Control PAL can sample and save the state of the Byte Enable (BE3#-BE0#) lines internally. When the CAS signals are registered externally, the BE3#-BE0# lines must be latched externally so that the DRAM Control PAL inputs maintain the valid byte enables.

For the 2-CLK design, the RAS and CAS signals are registered externally. The delay (from CLK2) for these signals is reduced, and more time is available for the DRAMs to respond. If more drive is required on these signals, multiple TTL registers can be used, each driving a small group of RAS or CAS lines. For example, in a design using Nx1 DRAMs, RAS0# must drive 32 DRAMs. To reduce the worst-case skew (caused by the heavy loading), RAS0# can be output on four register outputs, each of which drives eight DRAMs.

In the 3-CLK design, the column address does not need to be latched because the Next Address (NA#) signal is not activated until after the CAS signals go active, so the 80386 address remains valid for the memory access. Because a 2-CLK design has a shorter cycle time, NA# must be activated before the CAS signals go active to output the next address one CLK early. This early address necessitates a latch for the column addresses. In many cases, with a generalized LE control, this latch can be shared with the I/O subsystem, which usually must latch the address.

In the 2-CLK design, NA# is generated from the DRAM State PAL outputs and is therefore active in both the CLK2 cycle in which the 80386 samples NA# and the next CLK2 cycle. However, the 80386 does not sample NA# active twice. Once the 80386 outputs the next address, the address must be valid for at least two CLKs before NA# is sampled again.




Figure 6-10. 2-CLK DRAM Controller Schematic



In the 2-CLK design, the four data transceivers are optional because fast DRAMs with short read-data-float times are used. The DRAM data pins and can be connected directly to the 80386 data bus. The strong drive capability of the 80386 data bus can handle the load of one DRAM from each bank plus a transceiver load for the other peripherals.

PAL codes and pin descriptions for the 2-CLK design are listed in Appendix C of this manual. Figure 6-11 shows the timing of DRAM control signals for the 2-CLK design for the following five sequential DRAM cycles:

- 1. Read cycle
- 2. Write cycle to the opposite bank (no precharge)
- 3. Read cycle to that same bank (requires precharge)
- 4. Refresh cycle (always requires precharge)
- 5. Read cycle (cycle after refresh always requires precharge)

6.3.4 DRAM Design Variations

Some of the possible variations of the 2-CLK and 3-CLK designs are as follows:

- Both the 3-CLK and 2-CLK designs can use any length DRAM in Nx1 and Nx4 widths.
- Both 3-CLK or 2-CLK designs can use the internal PAL registers or external TTL registers on the RAS and/or CAS signals. A conservative design using Nx1 DRAMs might externally register each RAS (which drives 32 DRAMs) and internally register each CAS (which drives only 16 DRAMs).

Because internal registers have a greater maximum delay time and potentially less drive, the choice between registered PALs or external registers affects all of the DRAM timing parameters based on RAS and CAS. Some of the DRAM parameters are also affected by the minimum delay time of the internally registered PALs. Because PALs do not guarantee a minimum delay time, external TTL registers, which do guarantee a minimum delay time, can help meet these timing parameters, as well as provide greater drive capability.

- Data transceivers are optional for both designs. If a data transceiver is used, the DRAM read access must meet the 80386 read-data setup time. If no data transceiver is used, the DRAM read-data-float time must not interfere with the next 80386 cycle, particularly if it is a write cycle, and the 80386 data pin loading must not be exceeded.
- By including the column address latch and other circuitry, the DRAM controller can be
 adapted to run either 3-CLK or 2-CLK cycles depending on the speed (and cost) of
 DRAMs installed. To switch between the 3-CLK and 2-CLK controllers, the user should
 plug in a different set of DRAMs, a different DRAM State PAL, and a different DRAM
 Control PAL, and jumper the NA# logic.
- The choice of chip-select logic in both of the designs is arbitrary. Other DRAM memory-mapping schemes can be implemented by modifying the address decoding to the DRAM State PAL chip-selects.




Figure 6-11. 2-CLK DRAM Controller Cycles



• For a single DRAM bank rather than two, the user should tie the DRAM State PAL A2 input low, leave RAS1# unconnected (only RAS0# is used), and feed the 80386 address bit A2 into the address multiplexer. The DRAM State PAL equations can be modified to change the RAS1# output to duplicate the RAS0# output for more drive capability, and the A2 input can be used as another chip-select input. When only one bank is used, no accesses can be interleaved, and back-to-back accesses run with one wait state with the 2-CLK design and three wait states with the 3-CLK design (independent of address pipelining).

6.3.5 Refresh Cycles

All DRAMs require periodic refreshing of their data. For most DRAMs, periodic activation of each of the row address signals internally refreshes the data in every column of the row. Almost all DRAMs allow a RAS-only refresh cycle, the timing of which is the same as a read cycle, except that only the RAS signals are activated (no CAS signals), and all of the data pins are in the high impedance state.

Both the 3-CLK and 2-CLK designs use RAS-only refresh. The address multiplexer is placed in the high impedance state, and the Refresh Address Counter PAL is enabled to output the address of the next row to be refreshed. Then the DRAM State PAL activates both RAS0# and RAS1# to refresh the selected row for both banks at once. After the refresh cycle is complete, the Refresh Address Counter PAL increments so that the next refresh cycle refreshes the next sequential row.

The frequency of refreshing and the number of rows to be refreshed depend on the type of DRAM. For most larger DRAMs (64KxN and larger), only the lower eight multiplexed address bits (A7-A0, 256 rows) must be supplied for the refresh cycle; the upper address bits are ignored. The Refresh Address Counter PAL must output only eight bits and only the lower eight bits of the address multiplexer must be placed in the high impedance state. The OE# signals of the higher order address multiplexers can be tied low. Larger DRAMs generally require refresh every 4 milliseconds. The following sections describe refresh specifically for larger DRAMs, although the concepts apply to smaller DRAMs.

6.3.5.1 DISTRIBUTED REFRESH

In distributed refresh, the 256 refresh cycles are distributed equally within the 4-millisecond interval. Every 15.625 microseconds (4 milliseconds/256), a single row refresh is performed. After 4 milliseconds all 256 rows have been refreshed, and the pattern repeats. Both the 3-CLK and 2-CLK designs use distributed refresh.

The Refresh Interval Counter PAL is programmed to request a single distributed refresh cycle at intervals slightly under 15.625 microseconds. The counter requests a new refresh cycle after a preset number of CLK cycles. This number is dependent on the CLK frequency and can be calculated as follows for a 16-MHz CLK signal:



The term 4/256 is subtracted to allow for the time it takes the DRAM State PAL to respond to the request. Refresh requests are always given highest priority; however, if a DRAM access is already in progress, it must finish before the refresh cycle can start. The 3-CLK controller responds within 1-5 CLKs of the refresh request; the 2-CLK controller responds within 1-4 CLKs. The maximum latency (the difference between the longest and shortest responses) for either design is therefore 4 CLKs. This time is spread out among all 256 accesses, so 4/256 is subtracted in the above equations to account for the latency period. The counter immediately resets itself after it reaches the maximum count, regardless of this latency period.

Distributed refresh has two advantages over other types of refresh:

- Refresh cycles are spread out, guaranteeing that the 80386 access is never delayed very long for refresh cycles. Most programs execute in approximately the same time, regardless of when they are run with respect to DRAM refreshes.
- Distributed refresh hardware is typically simpler than hardware required for other types of refresh.

6.3.5.2 BURST REFRESH

Burst refreshes perform all 256 row refreshes consecutively once every 4 milliseconds rather than distributing them equally over the time period. Once a refresh is performed, the next 4-millisecond period is guaranteed free of refresh cycles. Time-critical sections of code can be executed during this time.

The 3-CLK and 2-CLK designs can be modified for burst refreshes by lengthening the maximum count of the Refresh Interval Counter to cover a 4-millisecond interval and holding the Refresh Request (RFRQ) signal active for 256 refresh cycles instead of a single refresh cycle. The completion of 256 refresh cycles can be determined by clearing the Refresh Address Counter PAL before the first refresh cycle and monitoring the outputs until they reach the zero address again. The Row Select (ROWSEL) signal can be used to clock the Refresh Address Counter PAL. The longer interval counter and extra logic requires another PAL device.

6.3.5.3 DMA REFRESH USING THE 82380 DRAM REFRESH CONTROLLER

The 82380 DRAM Refresh Controller can be used to perform refresh operations. The 82380 refresh logic provides a 24-bit Refresh Address Counter. Timer 1 is used to initiate refresh cycles. When the refresh function is enabled, the output of Timer 1, TOUT1/REF#, becomes the Refresh Request signal. The 82380 uses DMA operation to perform DRAM refresh. During a DRAM refresh cycle, TOUT1/REF# will be activated and a Refresh Address will be placed on the Address Bus. In order to ensure that no refresh cycles will be delayed, the Refresh Request is always arbitrated with the highest priority among the DMA requests.

DMA refresh can be used for both 3-CLK and 2-CLK designs. To activate both banks, the 82380's Refresh Request (TOUT1/REF#) is ANDed with the 80386's Hold Acknowledge (HLDA) to qualify for a valid refresh operation. The output of this ANDed signal is connected to the RFRQ input of the DRAM State PAL (see Figure 6-12). The DRAM






Figure 6-12. Refresh Request Generation

State PAL must be modified to ignore chip selects. This modification is needed to prevent the PAL from attempting to run a normal access cycle after the refresh cycle is complete.

In addition, the DRAM Control PAL must be modified so that the Ready (RDY) signal is generated on refresh accesses. Finally, the OE# input of the address multiplexer should be tied low so that it never enters the high impedance state, and the row address should include the least significant address bits (A10:3)

When using the 82380 DRAM Refresh Control to perform refresh, the Refresh Interval Counter PAL and the Refresh Address Counter PAL can be eliminated.

6.3.6 Initialization

Once the system is initialized, the integrity of the DRAM data and states is maintained, even during an 80386 halt or shutdown state or hardware reset, because all DRAM system functions are performed in hardware.

The controller PALs contain some state and counter information that is not implicitly reset during a power-up or hardware reset. The state machines are designed so that they enter the idle state within 18 CLK2 cycles regardless of whether they powerup in a valid state. The counters can start in any state. Thus, even though the state machines and counters can powerup into any state, they are ready for operation before the 80386 begins its first bus access.



Some DRAMs require a number of warm-up cycles before they can operate. Either method listed below can provide these cycles:

- Performing several dummy DRAM cycles as part of the 80386 initialization process. Setting up the 80386 registers and performing a REP LODS instruction is one way to perform these dummy cycles.
- Activating the RFRQ signal, using external logic, for a preset amount of time, causing the DRAM control hardware to run several refresh cycles.

6.3.7 Timing Analysis

The DRAM design (2-CLK or 3-CLK) for six combinations of DRAM speed and CLK frequency is listed in the Table 6-3. The table also indicates for each DRAM type whether data transceivers and/or external registers on the PAL outputs must be used with the design.

Appendix C of this manual contains a timing analysis of all 2-CLK and 3-CLK circuit parameters for all six DRAM types.

DRAM 386 CLK PAL External Data **Access Time** Rate Circuit Registers xcvrs 80 nS 16 MHz 2-CLK optional optional 100 nS 16 MHz 2-CLK optional no 120 nS 12 MHz 2-CLK optional optional 150 nS 16 MHz 3-CLK optional yes 150 nS 16 MHz 3-CLK yes yes 200 nS 12 MHz 3-CLK optional yes

Table 6-3. Designs for Six DRAM Types



CHAPTER 7 CACHE SUBSYSTEMS

Operating at 20 MHz, the 80386 can perform a complete bus cycle in only 100 nanoseconds, for a maximum bandwidth of 40 megabytes per second. To sustain this maximum speed, the 80386 must be matched with a high-performance memory system. The system must be fast enough to complete bus cycles with no wait states and large enough to allow the 80386 to execute large application programs.

Traditional memory systems have been implemented with dynamic RAMs (DRAMs), which provide a large amount of memory for a small amount of board space and money. However, no common low-cost DRAMs are available that can complete every bus cycle in 100 nanoseconds. Faster static RAMs (SRAMs) can meet the bus timing requirement, but they offer a relatively small amount of memory at a higher cost. Large SRAM systems can be prohibitively expensive.

A cache memory system contains a small amount of fast memory (SRAM) and a large amount of slow memory (DRAM). The system is configured to simulate a large amount of fast memory. Cache memory therefore provides the performance of SRAMs at a cost approaching that of DRAMs. A cache memory system (see Figure 7-1) consists of the following sections:

- Cache—fast SRAMs between the processor and the (slower) main memory
- Main memory—DRAMs
- Cache controller—logic to implement the cache




Figure 7-1. Cache Memory System



7.1 INTRODUCTION TO CACHES

In a cache memory system, all the data is stored in main memory and some data is duplicated in the cache. When the processor accesses memory, it checks the cache first. If the desired data is in the cache, the processor can access it quickly, because the cache is a fast memory. If the data is not in the cache, it must be fetched from the main memory.

A cache reduces average memory access time if it is organized so that the code and data that the processor needs most often is in the cache. Programs execute most quickly when most operations are transfers to and from the faster cache memory. If the requested data is found in the cache, the memory access is called a cache hit; if not, it is called a cache miss. The hit rate is the percentage of accesses that are hits; it is affected by the size and physical organization of the cache, the cache algorithm, and the program being run. The success of a cache system depends on its ability to maintain the data in the cache in a way that increases the hit rate. The various cache organizations presented in Section 7.2 reflect different strategies for achieving this goal.

7.1.1 Program Locality

Predicting the location of the next memory access would be impossible if programs accessed memory completely at random. However, programs usually access memory in the neighborhood of locations accessed recently. This principle is known as program locality or locality of reference.

Program locality makes cache systems possible. The same concept, on a larger scale, allows demand paging systems to work well. In typical programs, code execution usually proceeds sequentially or in small loops so that the next few accesses are nearby. Data variables are often accessed several times in succession. Stacks grow and shrink from one end so that the next few accesses are all near the top of the stack. Character strings and vectors are often scanned sequentially.

The principle of program locality pertains to how programs tend to behave, but it is not a law that all programs always obey. Jumps in code sequences and context switching between programs are examples of behavior that may not uphold program locality.

7.1.2 Block Fetch

The block fetch uses program locality to increase the hit rate of a cache. The cache controller partitions the main memory into blocks. Typical block sizes (also known as line size) are 2, 4, 8, or 16 bytes. A 32-bit processor usually uses two or four words per block. When a needed word is not in the cache, the cache controller moves not only the needed word from the main memory into the cache, but also the entire block that contains the needed word.

A block fetch can retrieve the data located before the requested byte (lookbehind), follows the requested byte (lookahead), or both. Generally, blocks are aligned (2-byte blocks on doubleword boundaries, 4-word blocks on doubleword boundaries). An access to any byte in the block copies the whole block into the cache. When memory locations are accessed in



ascending order (code accesses, for example), an access to the first byte of a block in main memory results in a lookahead block fetch. When memory locations are accessed in descending order, the block fetch is look-behind.

Block size is one of the most important parameters in the design of a cache memory system. If the block size is too small, the lookahead and look-behind are reduced, and therefore the hit rate is reduced, particularly for programs that do not contain many loops. However, too large a block size has the following disadvantages:

- Larger blocks reduce the number of blocks that fit into a cache. Because each block fetch
 overwrites older cache contents, a small number of blocks results in data being overwritten shortly after it is fetched.
- As a block becomes larger, each additional word is further from the requested word, therefore less likely to be needed by the processor (according to program locality).
- Large blocks tend to require a wider bus between the cache and the main memory, as well as more static and dynamic memory, resulting in increased cost.

As with all cache parameters, the block size must be determined by weighing performance (as estimated from simulation) against cost.

7.2 CACHE ORGANIZATIONS

7.2.1 Fully Associative Cache

Most programs make reference to code segments, subroutines, stacks, lists, and buffers located in different parts of the address space. An effective cache must therefore hold several noncontiguous blocks of data.

Ideally, a 128-block cache would hold the 128 blocks most likely to be used by the processor regardless of the distance between these words in main memory. In such a cache, there would be no single relationship between all the addresses of these 128 blocks, so the cache would have to store the entire address of each block as well as the block itself. When the processor requested data from memory, the cache controller would compare the address of the requested data with each of the 128 addresses in the cache. If a match were found, the data for that address would be sent to the processor. This type of cache organization, depicted in Figure 7-2, is called fully associative.

A fully associative cache provides the maximum flexibility in determining which blocks are stored in the cache at any time. In the previous example, up to 128 unrelated blocks could be stored in the cache. Unfortunately, a 128-address compare is usually unacceptably slow, expensive, or both. One of the basic issues of cache organization is how to minimize the restrictions on which words may be stored in the cache while limiting the number of required address comparisons.






Figure 7-2. Fully Associative Cache Organization

7.2.2 Direct Mapped Cache

In a direct mapped cache, unlike a fully associative cache, only one address comparison is needed to determine whether requested data is in the cache.

The many address comparisons of the fully associative cache are necessary because any block from the main memory can be placed in any location of the cache. Thus, every block of the cache must be checked for the requested address. The direct mapped cache reduces the number of comparisons needed by allowing each block from the main memory only one possible location in the cache.

Each direct mapped cache address has two parts. The first part, called the cache index field, contains enough bits to specify a block location within the cache. The second part, called the tag field, contains enough bits to distinguish a block from other blocks that may be stored at a particular cache location.



For example, consider a 64-kilobyte direct mapped cache that contains 16K 32-bit locations and caches 16 megabytes of main memory. The cache index field must include 14 bits to select one of the 16K blocks in the cache, plus 2 bits (or 4 byte Enables) to select a byte from the 4-byte block. The tag field must be 8 bits wide to identify one of the 256 blocks that can occupy the selected cache location. The remaining 8 bits of the 32-bit 80386 address are decoded to select the cache subsystem from among other memories in the memory space. The direct-mapped cache organization is shown in Figure 7-3.




Figure 7-3. Direct Mapped Cache Organization



In a system such as shown in Figure 7-3, a request for the data at the address 12FFE9H in the main memory is handled as follows:

- 1. The cache controller determines the cache location from the 14 most significant bits of the index field (FFE8H).
- 2. The controller compares the tag field (12H) with the tag stored at location FFE8H in the cache.
- 3. If the tag matches, the processor reads the least significant byte from the data in the cache.
- 4. If the tag does not match, the controller fetches the 4-byte block at address 12FFE8H in the main memory and loads it into location FFE8H of the cache, replacing the current block. The controller must also change the tag stored at location FFE8H to 12H. The processor then reads the least significant byte from the new block.

Any address whose index field is FFE8H can be loaded into the cache only at location FFE8H; therefore, the cache controller makes only one comparison to determine if the requested word is in the cache. Note that the address comparison requires only the tag field of the address. The index field need not be compared because anything stored in cache location FFE8H has an index field of FFE8H. The direct mapped cache uses direct addressing to eliminate all but one comparison operation.

The direct mapped cache, however, is not without drawbacks. If the processor in the example above makes frequent requests for locations 12FFE8H and 44FFE8H, the controller must access the main memory frequently, because only one of these locations can be in the cache at a time. Fortunately, this sort of program behavior is infrequent enough that the direct mapped cache, although offering poorer performance than a fully associative cache, still provides an acceptable performance at a much lower cost.

7.2.3 Set Associative Cache

The set associative cache compromises between the extremes of fully associative and direct mapped caches. This type of cache has several sets (or groups) of direct mapped blocks that operate as several direct mapped caches in parallel. For each cache index, there are several block locations allowed, one in each set. A block of data arriving from the main memory can go into a particular block location of any set. Figure 7-4 shows the organization for a 2-way set associative cache.

With the same amount of memory as the direct mapped cache of the previous example, the set associative cache contains half as many locations, but allows two blocks for each location. The index field is thus reduced to 15 bits, and the extra bit becomes part of the tag field.

Because the set associative cache has several places for blocks with the same cache index in their addresses, the excessive main memory traffic that is a drawback of a direct mapped cache is reduced and the hit rate increased. A set associative cache, therefore, performs more efficiently than a direct mapped cache.






Figure 7-4. Two-Way Set Associative Cache Organization

The set associative cache, however, is more complex than the direct mapped cache. In the 2-way set associative cache, there are two locations in the cache in which each block can be stored; therefore, the controller must make two comparisons to determine in which block, if any, the requested data is located. A set associative cache also requires a wider tag field, and thus a larger SRAM to store the tags, than a direct mapped cache with the same amount of cache memory and main memory. In addition, when information is placed into the cache, a decision must be made as to which block should receive the information.



The controller must also decide which block of the cache to overwrite when a block fetch is executed. There are several locations, rather than just one, in which the data from the main memory could be written. Three common approaches for choosing the block to overwrite are as follows:

- Overwriting the least recently accessed block. This approach requires the controller to maintain least-recently used (LRU) bits that indicate the block to overwrite. These bits must be updated by the cache controller on each cache transaction.
- Overwriting the blocks in sequential order (FIFO).
- Overwriting a block chosen at random.

The performance of each strategy depends upon program behavior. Any of the three strategies is adequate for most set associative cache designs; however, the LRU algorithm tends to provide the highest hit rate.

7.3 CACHE UPDATING

In a cache system, two copies of the same data can exist at once, one in the cache and one in the main memory. If one copy is altered and the other is not, two different sets of data become associated with the same address. A cache must contain an updating system to prevent old data values (called stale data) from being used. Otherwise, the situation shown in Figure 7-5 could occur. The following sections describe the write-through and write-back methods of updating the main memory during a write operation to the cache.

7.3.1 Write-Through System

In a write-through system, the controller copies write data to the main memory immediately after it is written to the cache. The result is that the main memory always contains valid data. Any block in the cache can be overwritten immediately without data loss.

The write-through approach is simple, but performance is decreased due to the time required to write the data to main memory and increased bus traffic (which is significant in multiprocessing systems).

7.3.2 Buffered Write-Through System

Buffered write-through is a variation of the write-through technique. In a buffered write-through system, write accesses to the main memory are buffered, so that the processor can begin a new cycle before the write cycle to the main memory is completed. If a write access is followed by a read access that is a cache hit, the read access can be performed while the main memory is being updated. The decrease in performance of the write-through system is thus avoided. However, because usually only a single write access can be buffered, two consecutive writes to the main memory will require the processor to wait. A write followed by a read miss will also require the processor to wait.






Figure 7-5. Stale Data Problem

7.3.3 Write-Back System

In a write-back system, the tag field of each block in the cache includes a bit called the altered bit. This bit is set if the block has been written with new data and therefore contains data that is more recent than the corresponding data in the main memory. Before overwriting any block in the cache, the cache controller checks the altered bit. If it is set, the controller writes the block to main memory before loading new data into the cache.

Write-back is faster than write-through because the number of times an altered block must be copied into the main memory is usually less than the number of write accesses. However, write-back has these disadvantages:

- Write-back cache controller logic is more complex than write-through. When a write-back system must write an altered block to memory, it must reconstruct the write address from the tag and perform the write-back cycle as well as the requested access.
- All altered blocks must be written to the main memory before another device can access these blocks in main memory.



• In a power failure, the data in the cache is lost, so there is no way to tell which locations of the main memory contain stale data. Therefore, the main memory as well as the cache must be considered volatile and provisions must be made to save the data in the cache in the case of a power failure.

7.3.4 Cache Coherency

Write-through and write-back eliminate stale data in the main memory caused by cache write operations. However, if caches are used in a system in which more than one device has access to the main memory (multi-processing systems or DMA systems, for example), another stale data problem is introduced. If new data is written to main memory by one device, the cache maintained by another device will contain stale data. A system that prevents the stale cache data problem is said to maintain cache coherency. Four cache coherency approaches are described below:

Bus Watching (Snooping) — The cache controller monitors the system address lines when
other masters are accessing shared memory. If another master writes to a location in
shared memory which also resides in the cache memory, the cache controller invalidates
that cache entry. The 82385 uses snooping to maintain cache coherency in multi-master
systems. Figure 7-6 illustrates bus watching.




Figure 7-6. Bus Watching



- Hardware transparency—Hardware guarantees cache coherency by ensuring that all accesses to memory mapped by a cache are seen by the cache. This is accomplished either by routing the accesses of all devices to the main memory through the same cache or by copying all cache writes both to the main memory and to all other caches that share the same memory (a technique known as broadcasting). Hardware transparent systems are illustrated in Figure 7-7.
- Non-cacheable memory Cache coherency is maintained by designating shared memory as non-cacheable. In such a system, all accesses to shared memory are cache misses, because the shared memory is never copied into the cache. The non-cacheable memory can be identified using chip-select logic or high-address bits. Figure 7-8 illustrates non-cacheable memory.

Software can offset the reduction in the hit rate caused by non-cacheable memory by using the string move instruction (REP MOVS) to copy data between non-cacheable memory and cacheable memory and by mapping shared memory accesses to the cacheable locations. This technique is especially appropriate for systems in which copying is necessary for other reasons (as in some implementations of UNIX for example).

• Cache flushing — A cache flush writes any altered data to the main memory (if this has not been done with write-through) and clears the contents of the cache. If all the caches in the system are flushed before a device writes to shared memory, the potential for stale data in any cache is eliminated.

Combinations of various cache coherency techniques may offer the optimal solution for a particular system. For example, a system might use hardware transparency for time-critical I/O operations such as paging and non-cacheable memory for slower I/O such as printing.




Figure 7-7. Hardware Transparency






Figure 7-8. Non-Cacheable Memory

7.4 EFFICIENCY AND PERFORMANCE

The measurement of cache effectiveness is divided into two topics: efficiency and performance. Cache efficiency is its ability to maintain the most used code and data requested by the microprocessor. Efficiency is measured in terms of hit rate. Performance is a measurement of the speed in which a microprocessor can perform a given task, and is measured in effective waitstates. Hit rate is but one of many factors which affect performance. Write policy, update policy, and coherency methods are performance factors as well.

Hit rate data for various cache organizations is shown in Table 7-1. These statistics were computed by analyzing several mainframe traces, and selecting the one which produced the lowest hit rate. Thus, the numbers listed are a conservative estimate of cache efficiency. Note that hit rate statistics are not absolute quantities. The hit rate of a particular cache implementation can vary widely depending on software. Therefore, Table 7-1 should only be used to compare one cache configuration against another listed. The relative hit rates should be weighed against other considerations, such as hardware complexity, in selecting a cache organization.

7.5 CACHE AND DMA

Cache coherency is an issue one must consider when placing a DMA controller in an 80386 system. Because the DMA controller has access to main memory, it can potentially introduce stale data. Stale data can be avoided in the following ways:

• Implementing bus watching (snooping). In this approach, the DMA controller writes to main memory, and the cache controller monitors DMA cycles and automatically invalidates any cache location altered by DMA.



Cache Configuration			III D-A
Size	Associativity	Line Size	Hit Rate
1K	direct	4 bytes	41%
8K	direct	4 bytes	73%
16K	direct	4 bytes	81%
32K	direct	4 bytes	86%
32K	2-way	4 bytes	87%
32K	direct	8 bytes	91%
64K	direct	4 bytes	88%
64K	2-way	4 bytes	89%
64K	4-way	4 bytes	89%
64K	direct	8 bytes	92%
64K	2-way	8 bytes	93%
128K	direct	4 bytes	89%
128K	2-way	4 bytes	89%
128K	direct	8 bytes	93%

Table 7-1. Cache Hit Rates

- Implementing a transparent cache, in which memory accesses from both the 80386 and the DMA controller are directed through the cache.
- Restrict DMA cycles to non-cacheable areas of memory.

The first method has a distinct advantage: since the DMA controller does not access the cache directly, the 80386 can read from the cache while the DMA controller is moving data to the main memory. Although bus watching is difficult to implement in a discrete cache design, the 82385 integrates this function and performs zero waitstate bus watching. The overall memory bandwidth is increased since the 80386 can access its cache at the same time as the DMA controller accesses main memory.

The second approach has the advantage of requiring minimal hardware, but has the disadvantage that the 80386 must be placed in HOLD during DMA transfers. The third approach is useful if a separate, dual-ported memory can be used as the non-cacheable memory, and the DMA device is tightly coupled to this memory. In all approaches, the cache should be made software transparent, so that DMA cycles do not require special actions by software to insure cache coherency.

7.6 CACHE EXAMPLE

The cache system example described in this section illustrates some of the decisions a cache designer must make. The requirements of a particular system may result in different choices than the ones made here. However, the issues presented in this section will arise in the process of designing any cache system.



7.6.1 Example Design

The cache system uses a direct-mapped cache. In previous generations of computers, it was often practical to build a 2-way or 4-way associative cache. SRAMs had low memory capacity, so many of them were needed to construct a cache of reasonable size. However, today's SRAMs are more dense, cost less, and take up less space. It is now more economical to increase cache efficiency by increasing cache size (SRAMs) rather than associativity (control logic and comparators).

The main memory is updated using buffered write-through. Implementing buffered write-through is slightly more complicated than unbuffered write-through, but it has the advantage that the processor can continue to run while the DRAM write is taking place. In contrast, write-back is significantly more complicated, but may be beneficial if main memory traffic must be kept to a minimum (as in multiprocessor systems, for example).

The line size is four bytes, which is most convenient for the 32-bit data bus of the 80386. An 8-byte line size would transfer twice as much data for every DRAM access, but would require a wider bus as well as more SRAMs, DRAMs, and transceivers. In such cases, one must weigh the additional cost against the additional performance.

The cache in this example stores both code and data, rather than only code. Code-only caches are easier to implement because there are no write accesses. They can be useful if data accesses are infrequent. In general, however, most programs make frequent data accesses. The code prefetch function of the 80386 makes the access time for code less critical to overall performance, since opcodes returned to the processor more quickly may only reside in the code queue longer.

7.6.2 Example Cache Memory Organization

The example cache is organized as shown in Figure 7-9. The cache holds 64 kbytes (16K locations of 4-byte blocks) of data and code and requires 16K 16-bit tag locations. The main memory can hold up to 2 Gbytes.

The 32-bit address from the 80386 is divided into the following three fields:

- Select Bit A31 is used to select the cache/DRAM subsystem.
- Tag Bits A30-A16 identify which DRAM location currently is associated with each cache location.
- Index Bits A15-A2 identify one of the 16,384 doubleword locations in the cache.

Each doubleword location of the cache can be occupied by one of the 32,768 blocks from main memory (one block from each 64-kilobyte section).

The 80386 bits A31-A2 are interpreted as follows:

- 1. Select bit A31 is low during cache/DRAM cycles.
- 2. Index bits A15-A2 select the cache location.






Figure 7-9. Example of Cache Memory Organization

- 3. Tag bits A30-A16 are compared with the tag information stored in the cache to determine of the block in the cache is the block needed by the 80386.
 - a. If the tag matches, the 80386 either reads the data in the cache or writes new data into the cache. In the case of a write, the data is also written to the main memory.
 - b. If the tag does not match during a read cycle, a doubleword is read from main memory, stored in the cache, and simultaneously presented to the 80386. The new tag is also stored in the cache. During a write, if the tag does not match, the cache is not updated.

7.6.3 Example Cache Implementation

An implementation of a cache memory similar to the one described in this section is presented in application note AP-404, 80386 Cache Memory Example, order number 231978.





CHAPER 8 I/O INTERFACING

The 80386 supports 8-bit, 16-bit, and 32-bit I/O devices that can be mapped into either the 64-kilobyte I/O address space or the 4-gigabyte physical memory address space. This chapter presents the issues to consider when designing an interface to an I/O device. Mapping as well as timing considerations are described. Several examples illustrate the design concepts.

8.1 I/O MAPPING VERSUS MEMORY MAPPING

I/O mapping and memory mapping of I/O devices differ in the following respects:

- The address decoding required to generate chip selects for I/O-mapped devices is often simpler than that required for memory-mapped devices. I/O-mapped devices reside in the I/O space of the 80386 (64 kilobytes); memory-mapped devices reside in a much larger memory space (4 gigabytes) that makes use of more address lines.
- Memory-mapped devices can be accessed using any 80386 instruction, so I/O-to-memory, memory-to-I/O, and I/O-to-I/O transfers as well as compare and test operations can be coded efficiently. I/O-mapped devices can be accessed only through the IN, OUT, INS, and OUTS instructions. All I/O transfers are performed via the AL (8-bit), AX (16-bit), or EAX (32-bit) registers. The first 256 bytes of the I/O space are directly addressable. The entire 64-kilobyte I/O space is indirectly addressable through the DX register.
- Memory mapping offers more flexibility in protection than I/O mapping does. Memory-mapped devices are protected by memory management and protection features. A device can be inaccessible to a task, visible but protected, or fully accessible, depending on where the device is mapped in the memory space. Paging provides the same protection levels for individual 4-kilobyte pages and indicates whether a page has been written to. The I/O privilege level of the 80386 protects I/O-mapped devices by either preventing a task from accessing any I/O devices or by allowing a task to access all I/O devices. A virtual-8086-mode I/O permission bitmap can be used to select the privilege level for a combination of I/O bytes.

8.2 8-BIT, 16-BIT, AND 32-BIT I/O INTERFACES

The 80386 can operate with 8-bit, 16-bit, and 32-bit peripherals. The interface to a peripheral device depends not only upon data width, but also upon the signal requirements of the device and its location within the memory space or I/O space.

8.2.1 Address Decoding

Address decoding to generate chip selects must be performed whether I/O devices are I/O-mapped or memory-mapped. The decoding technique should be simple to minimize the amount of decoding logic.



One possible technique for decoding memory-mapped I/O addresses is to map the entire I/O space of the 80386 into a 64-kilobyte region of the memory space. The address decoding logic can be configured so that each I/O device responds to both a memory address and an I/O address. Such a configuration is compatible for both software that uses I/O instructions and software that assumes memory-mapped I/O.

Address decoding can be simplified by spacing the addresses of I/O devices so that some of the lower address lines can be omitted. For example, if devices are placed at every fourth address, the 80386 Byte Enable outputs (BE3#-BE0#) can be ignored for I/O accesses and each device can be connected directly to the same eight data lines. The 64-kilobyte I/O space is large enough to allow the necessary freedom in allocating addresses for individual devices.

Addresses can be assigned to I/O devices arbitrarily within the I/O space or memory space. Addresses for either I/O-mapped or memory-mapped devices should be selected to minimize the number of address lines needed.

8.2.2 8-Bit I/O

Eight-bit I/O devices can be connected to any of the four 8-bit sections of the data bus. Table 8-1 illustrates how the address assigned to a device determines which section of the data bus is used to transfer data to and from the device.

In a write cycle, if BE3# and/or BE2# is active but not BE1# or BE0#, the write data on the top half of the data bus is duplicated on the bottom half. If the addresses of two devices differ only in the values of BE3#-BE0# (the addresses lie within the same doubleword boundaries), BE3#-BE0# must be decoded to provide a chip select signal that prevents a write to one device from erroneously performing a write to the other. This chip select can be generated using an address decoder PAL device or TTL logic.

Another technique for interfacing with 8-bit peripherals is shown in Figure 8-1. The 32-bit data bus is multiplexed onto an 8-bit bus to accommodate byte-oriented DMA or block transfers to memory-mapped 8-bit I/O devices. The addresses assigned to devices connected to this interface can be closely spaced because only one 8-bit section of the data bus is enabled at a time.

Address	4N + 3	4N + 2	4N + 1	4N		
Byte	D31-D24	D23-D16	D15-D8	D7-D0		
Word	D31-	D16	D15-D0			
Doubleword	D31-D0					

Table 8-1. Data Lines for 8-Bit I/O Addresses




Figure 8-1. 32-Bit to 8-Bit Bus Conversion



8.2.3 16-Bit I/O

To avoid extra bus cycles and to simplify device selection, 16-bit I/O devices should be assigned to even addresses. If I/O addresses are located on adjacent word boundaries, address decoding must generate the Bus Size 16 (BS16#) signal so that the 80386 performs a 16-bit bus cycle. If the addresses are located on every other word boundary (every doubleword address), BS16# is not needed.

8.2.4 32-Bit I/O

To avoid extra bus cycles and to simplify device selection, 32-bit devices should be assigned to addresses that are even multiples of four. Chip select for a 32-bit device should be conditioned by all byte enables (BE3#-BE0#) being active.

8.2.5 Linear Chip Selects

Systems with 14 or fewer I/O ports that reside only in the I/O space or that require more than one active select (at least one high active and one low active) can use linear chip selects to access I/O devices. Latched address lines A2-A15 connect directly to I/O device selects as shown in Figure 8-2.

8.3 BASIC I/O INTERFACE

In a typical 80386 system design, a number of slave I/O devices can be controlled through the same local bus interface. Other I/O devices, particularly those capable of controlling the local bus, require more complex interfaces. This section presents a basic interface for slave peripherals.

The high performance and flexibility of the 80386 local bus interface plus the increased availability of programmable and semi-custom logic make it feasible to design custom bus control logic that meets the requirements of particular system.

The basic I/O interface shown in Figure 8-3 can be used to connect the 80386 to virtually all slave peripherals. The following list includes some common peripherals compatible with this interface:

8259A Programmable Interrupt Controller

8237 DMA Controller (remote mode)

82258 Advanced DMA Controller (remote mode)

8253, 8254 Programmable Interval Timer

8272 Floppy Disk Controller

82062, 82064 Fixed Disk Controller

8274 Multi-Protocol Serial Controller

8255 Programmable Peripheral Interface

8041, 8042 Universal Peripheral Interface






Figure 8-2. Linear Chip Selects

The bus interface control logic presented here is identical to the one used in the basic memory interface described in Chapter 6. In most systems, the same control logic, address latches, and data buffers can be used to access both memory and I/O devices. The schematic of the interface is shown in Figure 8-4 and described in the following sections.

8.3.1 Address Latch

Latches maintain the address for the duration of the bus cycle. In this example, 74x373 latches are used.

The 74x373 Latch Enable (LE) input is controlled by the Address Latch Enable (ALE) signal from the bus control logic that goes active at the start of each bus cycle. The 74x373 Output Enable (OE#) is always active.






Figure 8-3. Basic I/O Interface Block Diagram

8.3.2 Address Decoder

In this example, the address decoder, which converts the 80386 address into chip-select signals, is located before the address latches. In general, the decoder may also be placed after the latches. If it is placed before the latches, the chip-select signal becomes valid as early as possible but must be latched along with the address. Therefore, the number of address latches needed is determined by the location of the address decoder as well as the number of address bits and chip-select signals required by the interface. The chip-select signals are routed to the bus control logic to set the correct number of wait states for the accessed device.

The decoder consists of two one-of-four decoders, one for memory address decoding and one for I/O address decoding. In general, the number of decoders needed depends on the memory mapping complexity. In this basic example, an output of the memory address decoder activates the I/O address decoder for I/O accesses. The addresses for the I/O devices are located so that only address bits A4 and A5 are needed to generate the correct chip-select signal.




Figure 8-4. Basic I/O Interface Circuit



8.3.3 Data Transceiver

Standard 8-bit transceivers (74x245, in this example) provide isolation and additional drive capability for the 80386 data bus. Transceivers are necessary to prevent the contention on the data bus that occurs if some devices are slow to remove read data from the data bus after a read cycle. If a write cycle follows a read cycle, the 80386 may drive the data bus before a slow device has removed its outputs from the bus, potentially causing bus contention problems. Transceivers can be omitted only if the data float time of the device is short enough and the load on the 80386 data pins meets device specifications.

A bus interface must include enough transceivers to accommodate the device with the most inputs and outputs on the data bus. If the widest device has 16 data bits and if the I/O addresses are located so that all devices are connected only to the lower half of the data bus, only two 8-bit transceivers are needed.

The 74x245 transceiver is controlled through two input signals:

- Data Transmit/Receive (DT/R#)—When high, this input enables the transceiver for a write cycle. When low, it enables the transceiver for a read cycle. This signal is just a latched version of the 80386 W/R# output.
- Data Enable (DEN#)—When low, this input enables the transceiver outputs. This signal
 is generated by the bus control logic.

Note that in a system using the 82380, the data transceivers must be disabled whenever the 80386 performs a read access to one of the internal registers of the 82380. Otherwise, both the 82380 and the data transceivers will be driving the local bus which causes data contention. This can be avoided by decoding the 82380 address space in the bus controller logic. Together with the bus cycle definition signals (W/R#, M/IO#), the data transceivers can be disabled by deactivating the DEN# signal.

8.3.4 Bus Control Logic

The bus control logic for the basic I/O interface is the same as the logic for the memory interface described in Section 6.2. The bus controller decodes the 80386 status outputs (W/R#, M/IO#, and D/C#) and activates a command signal for the type of bus cycle requested. The command signal corresponds to the bus cycle types (described in Chapter 3) as follows:

- Memory data read and memory code read cycles generate the Memory Read Command (MRDC#) output. MRDC# commands the selected memory device to output data.
- I/O read cycles generate the I/O Read Command (IORC#) output. IORC# commands the selected I/O device to output data.
- Memory write cycles generate the Memory Write Command (MWTC#) output. MWTC#
 commands the selected memory device to receive the data on the data bus.
- I/O write cycles generate the I/O Write Command (IOWC#) output. IOWC# commands the selected memory device to receive the data on the data bus.



Interrupt-acknowledge cycles generate the Interrupt Acknowledge (INTA#) output, which is returned to the 8259A Interrupt Controller.

The bus controller also controls the READY# input to the 80386 that ends each bus cycle. The PAL-2 bus control PAL counts wait states and returns READY# after the number of wait states required by the accessed device. The design of this portion of the bus controller depends on the requirements of the system; relatively simple systems need less wait-state logic than more complex systems. The basic interface described here uses a PAL device to generate READY#; other designs may use counters and/or shift registers.

If several I/O devices reside on the local bus, READY# logic can be simplified by combining into a single input the chip selects for devices that require the same number of wait states. The CSIO# input of PAL-1 generates the same number of wait states for all I/O accesses. Adding wait states to some devices to make the wait-state requirements of several devices the same does not significantly impact performance. If the response of the device is already slow (four wait states, for example), the additional wait state amounts to a relatively small delay. Typically, I/O devices are used infrequently enough that the access time is not critical.

8.4 TIMING ANALYSIS FOR I/O OPERATIONS

In this section, timing requirements for devices that use the basic I/O interface are discussed. The values of the various device specifications are examples only; for correct timing analysis, always refer to the latest data sheet for the particular device.

Timing for 80386 I/O cycles is identical to memory cycle timing in most respects; in particular, timing depends on the design of the interface. The worst-case timing values are calculated by assuming the maximum delay in the address latches, chip select logic, and command signals, and the longest propagation delay through the data transceivers (if used). These calculations yield the minimum possible access time for an I/O access for comparison with the access time of a particular I/O device. Wait states must be added to the basic worst-case values until read and write cycle times exceed minimum device access times.

The timing requirement for the address decoder dictates that the logic be combinational (not latched or registered) with a propagation delay less than the maximum delay calculated below.

The CS1WS signal requires a maximum decoder delay of 38.75 nanoseconds:

```
(3 x CLK2 period) - 80386 Addr Valid - PAL setup
(3 x 31.25) - 38 - 15
= 40.75 nanoseconds
(CLK2 = 32 MHz)
```



The CSOWS signal must be slightly faster in order to activate NA#:

The timings of the other signals can be calculated from the waveforms in Figure 8-5. In the following example, the timings for I/O accesses are calculated for CLK2 = 32 MHz and B-series PALs. All times are in nanoseconds.

tAR: Address stable before Read (IORC# fall) tAW: Address stable before Write (IOWC# fall)

= 132.75 nanoseconds

tRR: Read (IORC#) pulse width

tWW: Write (IOWC#) pulse width

= 300.5 nanoseconds

tRA: Address hold after Read (IORC# rise)

= 180.5 nanoseconds




Figure 8-5. Basic I/O Timing Diagram

tWA: Address hold after Write (IOWC# rise)

= 211.75 nanoseconds

tAD: Data delay from Address

= 335.5 nanoseconds

tRD: Data delay from Read (IORC#)

= 253.25 nanoseconds

tDF: read (IORC# rise) to Data Float

= 241 nanoseconds

tDW: Data setup before write (IOWC# rise)

= 289.5 nanoseconds



tWD: Data hold after write (IOWC# rise)

= 52.5 nanoseconds

tRV: command recovery time

= 331.75 nanoseconds

Many peripherals require a minimum recovery time between back-to-back accesses. This recovery time is usually provided in software by a series of NOP instructions. A JMP to the next instruction also provides a delay because it flushes the 80386 Prefetch Queue; this method has a more predictable execution time than the NOP method.

In 80386 systems, the instructions that provide recovery time are executed more quickly than in earlier systems. For software compatibility with earlier microprocessor generations, hardware must guarantee the recovery time. However, the circuitry to delay bus commands selectively for the specific instance of back-to-back accesses to a particular device is typically more complex than the frequency of such accesses justifies. Therefore, the preferred solution is to delay all I/O cycles by the minimum recovery time. Because most I/O accesses are relatively infrequent, performance is not degraded.

The I/O access timings of the basic interface are compatible with all of the currently available Intel peripherals. (In some cases, the high-speed versions of these peripherals are required). Table 8-2 compares several peripheral timings with the timings provided by bus controller.

	tAR	tAW	tRR	tww	tRA	tWA	tAD	tRD	tDF	tDW	tDWF	tWD	tRV
bus cntrlr	39	39	269	300	180	211	335	253	241	289		52	331
8259-2	0	0	160	190	0	0	200	120	85	160	_	0	190
8254-2	30	0	95	95	0	0	185	85	65	85		0	165
82C54-2	0	0	95	95	0	0	185	85	65	85	_	0	165
82C55-2	0	0	150	100	0	20	_	. 120	75	100	_	30	300
8272	0	0	250	250	0	0	_	200	100	150	_	5	_
82064	0	0	200	200	0	0	_	70	200	160	_	0 -	300
8041	0	0	250	250	0	0	225	225	100	150	_	0	2500
8042	0	0	160	160	0	0	130	130	85	130		0	1120
8251	0	0	250	250	0	0	_	200	100	150		20	_
8273-4	0	0	250	250	0	0	300	200	100	150	_	0	1920
8274	0	0	250	250	0	0	200	200	120	150	_	0	300
8291	0	0	140	170	0	0	250	100	60	130	_	0	l —
8292	0	0	250	250	0	0	225	225	100	150	_	0	

Table 8-2. Timings for Peripherals using Basic I/O Interface



Only two peripherals do not meet the bus controller specifications: the 8041 and 8042 UPIs (Universal Peripheral Interface 8-bit Microcomputers). These intelligent peripherals meet all but the command recovery specification, so they can be used if this delay is implemented in software.

8.5 BASIC I/O EXAMPLES

In this section, two examples of the interface to slave I/O devices are presented. Typically, several of these devices exist on the 80386 local bus. The basic I/O interface presented above is used for both examples.

8.5.1 8274 Serial Controller

The 8274 Multi-Protocol Serial Controller (MPSC) is designed to interface high-speed serial communications lines using a variety of communications protocols, including asynchronous, IBM bisynchronous, and HDLC/SDLC protocols. The 8274 contains two independent full-duplex channels and can serve as a high-performance replacement for two 8251A Universal Synchronous/Asynchronous Receiver Transmitters (USARTs).

Figure 8-6 shows connections from the basic I/O interface through which the 80386 communicates with the 8274. The 8274 is accessed as a sequence of four 8-bit I/O addresses (I/O-mapped or memory-mapped). The Serial I/O (SERIO#) signal is a chip select generated by address decoding logic. RD# and WR# signals are provided by the bus control logic. DB7-DB0 inputs connect to the lower eight outputs of the data transceiver (D7-D0).

The 8274 A1 and A0 inputs are used for channel selection and data or command selection. These inputs are connected to two address lines that are determined by the 8274 addresses. The addresses must be chosen so that the A1 and A0 inputs receive the correct signals for addressing the 8274.




Figure 8-6. 8274 Interface



The 8274 requires a minimum recovery time between back-to-back accesses that is provided for in the basic I/O interface hardware.

8.5.2 82380 Programmable Interrupt Controller

The 82380 Programmable Interrupt Controller (PIC) can be used in interrupt-driven microcomputer systems. It has 15 external and 5 internal interrupt requests. Each of the external requests can be cascaded with an additional 82C59A Interrupt Controller to accommodate up to 120 external interrupt sources.

The 82380 PIC handles interrupt priority resolution and returns a preprogrammed service routine vector to the 80386 during an interrupt acknowledge cycle. It consists of three 82C59A compatible banks. The 82380 Data Sheet contains detailed information on the 82380 PIC.

When an interrupt occurs, the 82380 PIC activates its Interrupt (INT) output, which is connected to the Interrupt Request (INTR) input of the 80386. the 80386 automatically executes two back-to-back interrupt acknowledge cycles, as described in Chapter 3. The 82380 PIC will automatically terminate the interrupt acknowledge cycles by driving its READYO# signal. Each acknowledge cycle will be extended by five wait states. Also, four idle states are inserted by the 80386 between two consecutive interrupt acknowledge cycles.

8.5.2.1 CASCADED INTERRUPT CONTROLLERS TO THE 82380 PIC

Each of the external requests of the 82380 PIC can be cascaded with one 'slave' 82C59A Interrupt Controller. With all its external requests cascaded, the 82380 PIC can handle up to 120 external requests.

For a cascaded interrupt request, the 82380 PIC will output an 8-bit cascade address on the data bus during the first interrupt acknowledge cycle. A simple circuit can latch the 8-bit address and encode it to drive the CAS signals (CAS2# — CAS0#) of the slave controllers. During the second interrupt acknowledge cycle, the 82380 will not drive the data bus; instead, the selected slave controller will put the interrupt vector on the data bus for the 80386.

Chapter 9 describes the interface to slave controllers that reside on a MULTIBUS I system bus.

8.5.3 8259A Interrupt Controller

The 8259A Programmable Interrupt Controller is designed for use in interrupt-driven microcomputer systems. A single 8259A can process up to eight interrupts. Multiple 8259As can be cascaded to accommodate up to 64 interrupts. A technique to handle more than 64 interrupts is discussed at the end of this section.

The 8259A handles interrupt priority resolution and returns a preprogrammed service routine vector to the 80386 during an interrupt-acknowledge cycle. Intel *Application Note AP-59* contains detailed information on configurations of the 8259A.



8.5.3.1 SINGLE INTERRUPT CONTROLLER

Figure 8-7 shows the connections from the basic I/O interface used for the 80386 and a single 8259A. Programmable Interrupt Controller (PIC#) is a chip-select signal from the address decoding logic. INTA#, RD#, and WR# are generated by the bus control logic. BD7-BD0 are connected to the lower eight outputs of the data transceiver. The A2 bit, connected to the 8259A A0 input, is used by the 80386 to distinguish between the two interrupt acknowledge cycles; 8259A register addresses must therefore be located at two consecutive doubleword boundaries.

When an interrupt occurs, the 8259A activates its Interrupt (INT) output, which is connected to the Interrupt Request (INTR) input of the 80386. The 80386 automatically executes two back-to-back interrupt-acknowledge cycles, as described in Chapter 3. The 8259A timing requirements are as follows:

- Each interrupt-acknowledge cycle must be extended by at least one wait state. Wait-state generator logic must provide for this extension.
- Four idle bus cycles must be inserted between the two interrupt-acknowledge cycles. The 80386 automatically inserts these idle cycles.

8.5.3.2 CASCADED INTERRUPT CONTROLLERS

Several 8259As can be cascaded to handle up to 64 interrupt requests. In a cascaded configuration, one 8259A is designated as the master controller; it receives input from the other




Figure 8-7. Single 8259A Interface



8259As, called slave controllers. The interface between the 80386 and multiple cascaded 8259As is an extension of the single-8259A interface with the following additions:

- The cascade address outputs (CAS2#-CAS0#) are output to provide address and chipselect signals for the slave controllers.
- The interrupt request lines (IR7-IR0) of the master controller are connected to the INT outputs of the slave controllers.

Each slave controller resolves priority between up to eight interrupt requests and transmits a single interrupt request to the master controller. The master controller, in turn, resolves interrupt priority between up to eight slave controllers and transmits a single interrupt request to the 80386.

The timing of the interface is basically the same as that of a single 8259A. During the first interrupt-acknowledge cycle, all the 8259As freeze the states of their interrupt request inputs. The master controller outputs the cascade address to select the slave controller that is generating the request with the highest priority. During the second interrupt-acknowledge cycle, the selected slave controller outputs an interrupt vector to the 80386.

Chapter 9 describes the interface to slave controllers that reside on a MULTIBUS I system bus.

8.5.3.3 HANDLING MORE THAN 64 INTERRUPTS

If an 80386 system requires more than 64 interrupt request lines, a third level of 8259As in polled mode can be added to the configuration described above. When a third-level controller receives an interrupt request, it drives one of the interrupt request inputs to a slave controller active. The slave controller sends an interrupt request to the master controller, and the master controller interrupts the 80386. The slave controller then returns a service-routine vector to the 80386. The service routine must include commands to poll the third level of interrupt controllers to determine the source of the interrupt request.

The only additional hardware required to handle more than 64 interrupts are the extra 8259As and the chip-select logic. For maximum performance, third-level interrupt controllers should be used only for noncritical, infrequently used interrupts.

8.6 80286-COMPATIBLE BUS CYCLES

Some devices (the 82258, for example) require an 80286-compatible interface in order to communicate with the 80386. An 80286-compatible interface must generate the following signals:

- Address bits A1 and A0, and Byte High Enable (BHE#) from the 80386 BE3#-BE0# outputs
- Bus cycle definition signals S0# and S1# from the 80386 M/IO#, W/R#, and D/C# outputs



- Address Latch Enable (ALE#), Device Enable (DEN), and Data Transmit/Receive (DT/R#) signals
- I/O Read Command (IORC#) and I/O Write Command (IOWC#) signals for I/O cycles
- Memory Read Command (MRDC#) and Memory Write Command (MWTC#) signals for memory cycles
- Interrupt Acknowledge (INTA#) signal for interrupt-acknowledge cycles

In the following example, the interface is constructed using the 80286-compatible bus controller (82288) and bus arbiter (82289). The 82289, along with the bus arbiters of other processing subsystems, coordinates control of the bus between the 80386 and other bus masters. The 82288 provides the control signals to perform bus cycles. Communication between the 80386 and these devices is accomplished through PALs that are programmed to perform all necessary signal translation and generation. Latching and buffering of the data and address buses is performed by TTL logic.

Figure 8-8 shows a block diagram of the interface, which consists of the following parts:

- A0/A1 generator—Generates the lower address bits from 80386 BE0#-BE3# outputs
- Address decoder—Determines the device the 80386 will access
- Address latches—Connect directly to 80386 address pins A19-A2 and the outputs of the A0/A1 generator
- Data transceivers—Connect directly to 80386 data pins D15-D0
- S0#/S1# generator—Translates 80386 outputs into the S0# and S1# signals
- Wait-state generator—Controls the length of the 80386 bus cycle through the READY# signal
- 82288 Bus Controller—Generates the bus command signals
- 82289 Bus Arbiter—Arbitrates contention for bus control between the 80386 and other bus masters

8.6.1 AO/A1 Generator

The A0, A1, and BHE# signals are 80286-compatible. These signals are generated from the 80386 byte enables (BE0#-BE3#) as shown in Table 8-3. The truth table can be implemented with the logic shown in Figure 8-9.

8.6.2 S0#/S1# Generator

S0# and S1# are 80286-compatible status signals that must be provided for the 82288 and 82289. The S0#/S1# logic in Figure 8-10 generates these signals from 80386 status outputs (D/C#, M/IO#, and W/R#) and wait-state generator outputs. WS1 and WS2 are wait-state generator outputs that correspond to the first and second wait states of the 80386 bus cycle. These signals ensure that S0# and S1# are valid for two CLK cycles.






Figure 8-8. 80286-Compatible Interface

8.6.3 Wait-State Generator

The wait-state generator PAL shown in Figure 8-11 controls the READY# input of the 80386. For local bus cycles, the wait-state generator produces signal outputs that correspond to each wait state of the 80386 bus cycle, and the PAL READY# output uses these signals to set READY# active after the required number of wait states. Two of the wait-state signals, WS1 and WS2, are also used to generate S0# and S1#, as described above.

The PCLK signal, which necessary for producing 80286-compatible wait states, is generated by dividing the CLK signal from the 82384 by two.



80386 Signals					16-Bit Bus	Signals	0	
BE3#	BE2#	BE1#	BEO#	A1	вне#	BLE# (A0)	Comments	
H* H H H H H H H H H	H* H H L L*	H*	H* L H L* H L	X L L H X L	X H L H X L	X L H L X H	x—no active bytes x—not contiguous bytes	
L L* L* L L*	H	H #	H L* H* L* H L*	H X X H X L	X X X L X L	H × × L × H L	x—not contiguous bytes x—not contiguous bytes x—not contiguous bytes x—not contiguous bytes	

Table 8-3. A0, A1, and BHE# Truth Table

BLE# asserted when D0-D7 of 16-bit bus is active. BHE# asserted when D8-D15 of 16-bit bus is active. A1 low for all even words; A1 high for all odd words.

Kev:

 $\dot{x} = don't care$

H = high voltage level

L = low voltage level

* = a non-occurring pattern of Byte Enables; either none are asserted, or the pattern has Byte Enables asserted for non-contiguous bytes

To meet the READY# input hold time requirement (25 nanoseconds) for the 82288 Bus Controller, the READY# signal must be two CLK cycles long. Therefore, two PAL equations are required to generate READY#. The first equation generates the Ready Pulse (RDYPLSE) output. RDYPLSE is fed into the READY# equation to extend READY# by an additional CLK cycle. These signals are gated by PCLK.

RDYPLSE := ARDY * PCLK

/READY := ARDY * PCLK + RDYPLSE

8.6.4 Bus Controller and Bus Arbiter

Connections for the 82288 and 82289 are shown in Figure 8-12. The 82288 MB input is tied low so that the 82288 operates in local-bus mode. Both the 82288 and the 82289 are selected by an output of the address decoder that selects 80286-compatible cycles. The AEN# signal from the 82289 enables the 82288 outputs.






Figure 8-9. AO, A1, and BHE# Logic

8.6.5 82380 Integrated System Peripheral

The 82380 is designed for easy interface to the 80386 processor. It consists of a set of signals to interface directly to the 80386 local bus. Figure 8-13 depicts a typical system configuration with the 80386 processor.

When the 82380 switches from slave to master mode (or vice versa), there are idle states in which the ADS# signal is left floating. In order not to confuse the internal state machine of the 82380, a 10 K ohm pull-up resistor should be used on the ADS# signal to ensure that this line is inactive during these idle states.

As described in section 8.3.3, the data transceivers should be disabled during any read access to the 82380 in the slave mode to prevent bus contention.






Figure 8-10. S0#/S1# Generator Logic




Figure 8-11. Wait-State Generator Logic






Figure 8-12. 82288 and 82289 Connections

8.6.6 82258 ADMA Controller

The 82258 Advanced Direct Memory Access (ADMA) controller performs DMA transfers between main memory and an I/O device, typically a magnetic disk or communications channel, without intervention from the 80386. Shifting the I/O processing function from the 80386 to the 82258 improves overall system performance because the 80386 doesn't have to switch context for every transfer.

The 82258 operates from the CLK output of the 82384 and provides the following advanced features that are not available in previous generations of DMA controllers:

- Command chaining to perform multiple commands sequentially
- Data chaining to scatter data to separate memory locations and to gather data from separate locations (this feature is useful for demand paging)






Figure 8-13. 80386/82380 Interface

- Auto-assembly and disassembly to convert from 16-bit memory to 8-bit I/O or vice versa
- Compare, translate, and verify functions
- The option to use one of the four high-speed channels as a lower-speed, multiplexed channel. The 82258 gains up to 32 more channels through multiplexing

The 82258, paired with the 82288 Bus Controller, is capable of being a bus master on a common local bus and/or system bus with the 80386 and its bus controller. The 82258 requires both a local bus interface to act as bus master and an 80386 interface to communicate directly with the 80386.



8.6.6.1 82258 AS BUS MASTER

The 82258 operating mode determines the type of bus interface it generates. In the 80286 mode, the 82258 generates the signals for direct interface with an 80286. In this example, the 82258 is set to 80286 mode because the 80386 resembles the 80286 more than the 80186 or 8086. The 82258 is initialized to 80286 mode by holding its A23 pin high with a pullup resistor during reset.

The 82258 interface must include logic for sharing control of the local bus with the 80386. The HOLD and Hold Acknowledge (HLDA) pins on both the 80386 and the 82258 facilitate the transfer of bus control between the 80386 and the 82258.

Figure 8-14 shows the logic to transfer bus control. When the 82258 needs bus access, it asserts its HOLD request signal, which is synchronized to CLK2 to meet the synchronous setup and hold times of the 80386. The resulting Processor Hold (PHOLD) signal sets the 80386 HOLD input active.

When the 80386 recognizes the HOLD request, it completes the current bus cycle, then places all its outputs except HLDA in the high impedance state and asserts HLDA. External




Figure 8-14. HOLD and HLDA Logic for 80386-82258 Interface



logic must use HLDA to disable the output buffers of the 80386 bus controller, data bus, and address bus, and enable the output buffers of the 82258 and its bus controller, data bus, and address bus.

The wait-state generator must be started with the ALE output of the 82288 Bus Controller. Although the 82258 can share wait-state generator logic with the 80386, the logic must be modified to support longer wait states for 82258 cycles. The 82258 divides its CLK input by two internally, so that its wait state requires two CLK cycles rather than one. In addition, the READY# output must meet the 82258 input hold time requirement of 25 nanoseconds.

When the 82258 completes its operation, its HOLD request goes inactive (low), disabling the 82258 output buffers and re-enabling the 80386 and its output buffer.

8.6.6.2 82258 AS PERIPHERAL

Although most of the communication between the 80386 and the 82258 is achieved indirectly through memory, the 80386 occasionally performs bus cycles to the 82258. For example, the 80386 performs a direct access to set the general mode register during initialization. The access occurs asynchronously over the slave mode interface of the 82258 that is shown in Figure 8-15. The interface consists of the following pins:

- Chip Select (CS#)—enables the slave mode interface
- Control (RD#, WR#)—indicates bus cycle type (asynchronous interface)
- Register Address (A7-A0)—selects an 82258 internal register
- Data (D15-D0)—transfers data to and from the 82258

With the 82258, asynchronous cycles must be used to allow time for the conversion of 80386 status signals to 80286-compatible inputs. The S0# and S1# inputs of the 82258 must therefore be inactive (high) during slave mode operations. Asynchronous cycles require an address hold time after a read command or write command, so the address outputs from the 80386




Figure 8-15. 82258 Slave Mode Interface



(A7-A2, and decoded A1, A0, and BHE#) that connect to corresponding inputs of the 82258 must be latched. Because A7-A0 and BHE# become 82258 outputs after initialization, registered transceivers (74F543) serve as these latches.

ADMA Enable (ADMAEN#) is a chip select generated by address decoding logic during 80386 accesses to the I/O addresses designated for the 82258. The RD# and WR# command signals from the 80386 bus control logic must be delayed to provide the proper setup time from chip select to command inputs. This delay can be generated using wait-state generator signals.

8.6.7 82586 LAN Coprocessor

The 82586 is an intelligent, high-performance communications controller designed to perform most tasks required for controlling access to a local area network (LAN). In most applications, the 82586 is the communication manager for a station connected to a LAN. Such a station usually includes a host CPU, shared memory, a Serial Interface Unit, a transceiver, and a LAN link (see Figure 8-16). The 82586 performs all functions associated with data transfer between the shared memory and the LAN link, including:

- Framing
- Link management
- Address filtering
- Error detection
- Data encoding
- Network management
- Direct memory access (DMA)
- Buffer chaining
- High-level (user) command interpretation

The 82586 has two interfaces: a bus interface to the 80386 local bus and a network interface to the Serial Interface Unit. The bus interface is described here. For detailed information on using the 82586, refer to the Local Area Networking (LAN) Component User's Manual.

The 82586, which is a master on the 80386 local bus, communicates directly with the 80386 through the Channel Attention (CA) and interrupt (INT) signals. There are several ways to design an interface between the 82586 and the 80386. In general, higher performance interfaces (requiring less servicing time from the 80386) are more expensive. Four types of interfaces are described in this section:

- Dedicated CPU
- Decoupled dual-port memory
- Coupled dual-port memory
- Shared bus






Figure 8-16. LAN Station

8.6.7.1 DEDICATED CPU

Dedicating a CPU to control the 82586 results in a high-performance, high-cost interface. The CPU, typically an 80186, an 80188, or a microcontroller, executes the data link layer (a functional division) of software and sometimes the network, transport, and session layers as well. (For definitions of these layers, see the *Local Area Networking (LAN) Components User's Manual*). The dedicated CPU relieves the 80386 of these layers and provides a high-level, message-oriented interface that can be treated in software as a standard I/O device. In hardware, the interface is mapped into a dual-port memory.



8.6.7.2 DECOUPLED DUAL-PORT MEMORY

A decoupled dual-port memory interface, shown in Figure 8-17, contains two sections of memory:

- 80386 core memory—typically DRAM that provides executable memory space for the operating system
- 82586 communication channel memory—typically dual-ported SRAM that contains the commands and buffers of the 82586

Only the dual-ported SRAM is shared; the 82586 cannot access the 80386 core memory. The 80386 and 82586 operate in parallel except when both require access to the SRAM. In this instance, one processor must wait while the other completes its access. At all other times, the two devices are decoupled.

This interface requires at least one level of data copying to move data between the 80386 core memory and the 82586 communication channel memory. However, usually the data must be copied to separate the frame header information.




Figure 8-17. Decoupled Dual-Port Memory Interface



8.6.7.3 COUPLED DUAL-PORT MEMORY

In a coupled dual-port memory interface, the 80386 and the 82586 share a common memory space as illustrated in Figure 8-18. The 82586, with 24 address bits, can address up to 16 megabytes of memory. If the 80386 memory is larger than 16 megabytes, some memory is inaccessible to the 82586; this memory must be taken into account in the system design.

The advantage of coupled dual-port memory is that the 82586 can perform DMA transfers directly into the operating system memory. In this case, other logic must remove the frame header information from the data prior to the DMA transfer. Through the buffer-chaining feature of the 82586, the header information can be directed to a separate buffer, as long as the minimum buffer size requirements are met.

8.6.7.4 Shared Bus

In a shared bus interface (Figure 8-19), the 80386 and the 82586 share a common address and data bus. The HOLD and HLDA signals provide bus arbitration. When one device enters the hold state in response to the HOLD input, the other device can access the bus.

The shared bus interface is probably the simplest and least expensive interface. However, the performance of the 80386 may drop tremendously because the 80386 must wait for the 82586 to complete its bus operation before it can access the bus. This wait can be several hundred CLK cycles.




Figure 8-18. Coupled Dual-Port Memory Interface






Figure 8-19. Shared Bus Interface



		1

CHAPTER 9 MULTIBUS® I AND 80386

Previous chapters have presented single-bus systems in which a single 80386 connects to memory, I/O, and coprocessors. This chapter introduces the system bus, which connects several single-bus systems to create a powerful multiprocessing system. Two examples of multiprocessing system buses are the Intel MULTIBUS I, discussed in this chapter, and the Intel MULTIBUS II, discussed in Chapter 10.

A system bus connects several processing subsystems (each of which can include a local bus and private resources) and the resources that are shared between the processing subsystems. Because all the processing subsystems perform operations simultaneously on their respective local buses, such a multiprocessing system results in a significant increase in throughput over a single-bus system.

Another advantage of using a system bus is that the system can be expanded modularly. The system bus establishes the standard interface through which additional processing subsystems communicate with one another. Through this interface, components from different vendors can be integrated.

A central concern of any multiprocessing system is dividing resources between the system bus and the individual local buses; that is, determining which resources to share between all processors and which to keep for only one processor's use. These choices affect system reliability, integrity, throughput, and performance. The deciding factors are often the requirements of the particular target system.

Because local resources are isolated from failures occurring in other parts of the system, they enhance the overall reliability of the system. Also, because the processor does not have to contend with other processors for access to its local resources, bus cycles are performed quickly. However, local resources add to the system cost because each resource must be duplicated for each subsystem that requires it.

Resources used by more than one processing subsystem but not used frequently by any subsystem should be placed on the system bus. The system can minimize the idle time of such resources. However, this advantage must be weighed against the disadvantage of increased access time when more than one processor must use a system resource.

9.1 MULTIBUS® I (IEEE 796)

The Intel MULTIBUS I (IEEE 796 Standard) is a proven, industry-standard, 16-bit multi-processing system bus. A wide variety of MULTIBUS I compatible I/O subsystems, memory boards, general purpose processing boards, and dedicated function boards are available from Intel. Designers who choose the MULTIBUS I protocols in their system bus have a ready supply of system components available for use in their products.



MULTIBUS I protocols are described in detail in the Intel MULTIBUS® I Architecture Reference Book.

One method of constructing an interface between the 80386 and the MULTIBUS I is to generate all MULTIBUS I signals using only TTL and PAL devices. A simpler method is to use the 80286-compatible interface described in Chapter 8. The latter option is described in the MULTIBUS I interface example in this chapter.

9.2 MULTIBUS® I INTERFACE EXAMPLE

The MULTIBUS I interface presented in the following example consists of the 80286-compatible 82289 Bus Arbiter and 82288 Bus Controller. The 82289, along with the bus arbiters of other processing subsystems, coordinates control of the MULTIBUS I; the 82288 provides the control signals to perform MULTIBUS I accesses. Communication between the 80386 and these devices is accomplished through PALs that are programmed to perform all necessary signal translation and generation. Latching and buffering of the data and address buses is performed by TTL logic.


Figure 9-1 shows a block diagram of the interface, which consists of the following parts:

- A0/A1 generator—Generates the lower address bits from 80386 BE0#-BE3# outputs
- Address decoder—Determines whether the bus cycle requires a MULTIBUS I access
- MULTIBUS I address latches—Connect directly to 80386 address pins A23-A2 and the outputs of the A0/A1 generator
- MULTIBUS I data latch/transceivers—Connect directly to 80386 data pins D15-D0
- S0#/S1# generator—Translates 80386 outputs into the S0# and S1# signals
- Wait-state generator—Controls the length of the 80386 bus cycle through the READY# signal
- 82288 Bus Controller—Generates the MULTIBUS I command signals
- 82289 Bus Arbiter—Arbitrates contention for bus control between the 80386 and other MULTIBUS I masters

These elements of the 80286-compatible interface are described in detail in Chapter 8. The block diagram in Figure 9-1 does not include the 80386 local bus interface and local resources. In a complete system, some logic (for example, the address decoder) is common to both MULTIBUS I and local bus interfaces. The following discussion includes only the logic necessary for the MULTIBUS I interface.

9.2.1 Address Latches and Data Transceivers

MULTIBUS I allows up to 24 address lines and 16 data lines. In this example, the MULTIBUS addresses are located in a 256-kilobyte range between F00000H and F3FFFFH, so that all 24 address lines are used. The 16 data lines correspond to the lower half of the 80386 data bus.



9-3

Figure 9-1. 80386-MULTIBUS® I Interface



Inverting address latches convert the 80386 address outputs to the active-low MULTIBUS I address bits. MULTIBUS I address bits are numbered in hexadecimal so that A23-A0 on the 80386 bus become ADR17#-ADR0# on the MULTIBUS I. The BHE# signal is latched to provide the MULTIBUS I BHEN# signal, as shown in Figure 9-2.

MULTIBUS I requires address outputs to be valid for at least 50 nanoseconds after the MULTIBUS I command goes inactive; therefore, the address on all bus cycles is latched. The Address Enable (AEN#) output of the 82289 Bus Arbiter, which goes active when the 82289 has control of the MULTIBUS I, is an output enable for the MULTIBUS I latches. The ALE# output of the 82288 latches the 80386 address for the MULTIBUS I, as shown in Figure 9-2.

Inverting latch/transceivers are needed to provide active-low MULTIBUS I data bits. MULTIBUS I data bits are numbered in hexadecimal, so D15-D0 convert to DATF#-DAT0#. Data is latched only on write cycles. For MULTIBUS I write cycles, the 82288 ALE#, DEN, and DT/R# inputs can control the address latches and data latch/transceivers. For MULTIBUS I read cycles, the local bus RD# signal can control the latch/transceivers. If DEN were used, data contention on the 80386 local bus would result when a MULTIBUS I read cycle immediately followed a local write cycle.




Figure 9-2. MULTIBUS® I Address Latches and Data Transceivers



9.2.2 Address Decoder

A MULTIBUS I system typically has both shared and local memory. I/O devices can also be located either on MULTIBUS I or a local bus. Therefore, the address space of the 80386 must be allocated between MULTIBUS I and the local bus, and address decoding logic must be used to select one bus or the other.

The following two signals are needed for MULTIBUS I selection:

- Bus Size 16 (BS16#) must be returned active to the 80386 to ensure a 16-bit bus cycle. Additional terms for other devices requiring a 16-bit bus can be added to the BS16# PAL equation.
- MULTIBUS Enable (MBEN) selects the 82288 Bus Controller and the 82289 Bus Arbiter
 on the MULTIBUS I interface. Other outputs of the decoder PAL are programmed to
 select memory and I/O devices on the local bus.

The decoding of addresses to select either the local bus or the MULTIBUS I is straight forward. In the following example, the system uses the first 64 megabytes of the 80386 memory address space, requiring 26 address lines. The MULTIBUS I memory is allocated to the addresses from F00000H to F3FFFFH. The same PAL equation generates the two PAL outputs BS16# and MBEN:

I/O resources residing on MULTIBUS I can be memory-mapped into the memory space of the 80386 or I/O-mapped into the I/O address space independent of the physical location of the devices on MULTIBUS I. The addresses of memory-mapped I/O devices must be decoded to generate I/O read or I/O write commands for memory references that fall within the I/O-mapped regions of the memory space. This technique is discussed in Chapter 8 along with the tradeoffs between memory-mapped I/O and I/O-mapped I/O.

9.2.3 Wait-State Generator

The wait-state generator controls the READY# input of the 80386. For local bus cycles, the wait-state generator produces signal outputs that correspond to each wait state of the 80386 bus cycle, and the PAL READY# output uses these signals to set READY# active after the required number of wait states. Two of the wait-state signals, WS1 and WS2, are also used to generate S0# and S1#.

READY# generation for MULTIBUS I cycles is linked to the Transfer Acknowledge (XACK#) signal, which is returned active by the accessed device on MULTIBUS I when the MULTIBUS I cycle is complete. For a system containing a MULTIBUS I interface as well as a local bus, XACK# must be incorporated into the wait-state generator to produce the READY# signal. The necessary logic is shown in Figure 9-3.






Figure 9-3. Wait-State Generator Logic

For MULTIBUS I accesses, the wait-state generator is started by the ALE# signal from the 82288. When XACK# goes active, it is synchronized to CLK. The resulting Asynchronous Ready (ARDY) signal, incorporated into the PAL equation for the READY# signal, causes READY# to be output between two and three CLK cycles after ARDY goes active.

The PCLK signal, which is necessary for producing 80286-compatible wait states, is generated by dividing the CLK signal from the 82384 by two.

To meet the READY# input hold time requirement (25 nanoseconds) for the 82288 Bus Controller, the READY# signal for MULTIBUS I cycles must be two CLK cycles long. Therefore, two PAL equations are required to generate READY#. The first equation generates the Ready Pulse (RDYPLSE) output. RDYPLSE is fed into the READY# equation to extend READY# by an additional CLK cycle. These signals are gated by MBEN and PCLK.

RDYPLSE := ARDY * MBEN * PCLK

/READY := ARDY * MBEN * PCLK + RDYPLSE * MBEN



9.2.4 Bus Controller and Bus Arbiter

Connections for the 82288 and 82289 are shown in Figure 9-4. The 82288 can operate in either local-bus mode or MULTIBUS I mode; a pullup resistor on the 82288 MB input activates the MULTIBUS I mode. Both the 82288 and the 82289 are selected by the MBEN output of the address decoder PAL. The AEN# signal from the 82289 enables the 82288 outputs.

Timing diagrams for MULTIBUS I read and write cycles are shown in Figures 9-5 and 9-6. The only differences between the timings are that a read cycle controls the data latch/transceivers using RD# and outputs the MRDC# command signal, whereas a write cycle controls the data latch/transceivers using DEN and outputs the MWTC# command.




Figure 9-4. MULTIBUS® Arbiter and Bus Controller




Figure 9-5. MULTIBUS® I Read Cycle Timing




Figure 9-6. MULTIBUS® I Write Cycle Timing



9.3 TIMING ANALYSIS OF MULTIBUS® LINTERFACE

The timing specifications for the MULTIBUS I are explained in the MULTIBUS® I Specification, Order Number 9800683. Table 9-1 lists the MULTIBUS I parameters that relate to the 80386 system. These calculations are based on the assumption that 74ALS580 latches and 74F544 transceivers are used for the MULTIBUS I address and data interface.

In addition to the parameters in Table 9-1, designers must allow for the following:

- To ensure sufficient access time for the slave device, bus operations must not be terminated until an XACK# signal is received from the slave device.
- Following an MRDC# or an IORC# command, the responding slave device must disable its data drivers within 125 nanoseconds after the return of the XACK# signal. All devices that meet the MULTIBUS I specification of 65 nanoseconds meet this requirement.

9.4 82289 BUS ARBITER

In a MULTIBUS I system, several processing subsystems contend for the use of shared resources. If one processor requests access to MULTIBUS I while another processor is using it, the requesting processor must wait. Bus arbitration logic controls access to MULTIBUS I for all processing subsystems.

Each processing subsystem contains its own 82289 Bus Arbiter. The Bus Arbiter directs its processor onto the bus and allows higher and lower priority bus masters to access the bus. Once the bus arbiter gains control of MULTIBUS I, the 80386 can access system resources. The bus arbiter handles bus contention in a manner that is transparent to the 80386.

Timing Parameter	MULTIBUS Specification	80386 System Timing		
tAS Address setup before command active	50 ns minimum	125 ns (2 CLK cycles) - 20 ns (ALE max delay) - 22 ns (74ALS580 max. delay) + 3 ns (Command min. delay) 86 ns min.		
tDS Write data setup before command active	50 ns minimum	125 ns (2 CLK cycles) - 30 ns (DEN max. delay) - 12 ns (74F544 max. delay) + 3 ns (Command min. delay) 86 ns min.		
tAH Address hold after command inactive	50 ns minimum	187.5ns (3 CLK cycles) - 25 ns (Command inactive max. delay) + 3 ns (ALE max. delay) 165.5ns min		

Table 9-1. MULTIBUS® I Timing Parameters



Each processor in the multiprocessing system initiates bus cycles as though it has exclusive use of MULTIBUS I. The bus arbiter keeps track of whether the subsystem has control of the bus and prevents the bus controller from accessing the bus when the subsystem does not control the bus.

When the bus arbiter receives control of MULTIBUS I, it enables the bus controller and address latches to drive MULTIBUS I. When the transfer is complete, MULTIBUS I returns the XACK# signal, which activates READY# to end the bus cycle.

9.4.1 Priority Resolution

Because a MULTIBUS I system includes many bus masters, logic must be provided to resolve priority between two bus masters that simultaneously request control of MULTIBUS I. Figure 9-7 shows two common methods for resolving priority: serial priority and parallel priority.

The serial priority technique is implemented by daisy-chaining the Bus Priority In (BPRN#) and Bus Priority Out (BPRO#) signals of all the bus arbiters in the system. Due to delays in the daisy chain, this technique accommodates only a limited number of bus arbiters.

The parallel priority technique requires external logic to recognize the BPRN# inputs from all bus arbiters and return the BPRO# signal active to the requesting bus arbiter that has the highest priority. The number of bus arbiters accommodated with this technique depends on the complexity of the decoding logic.

Priority resolution logic need not be included in the design of a single processing subsystem with a MULTIBUS I interface. The bus arbiter takes control of MULTIBUS I when the BPRN# signal goes active and relinquishes control when BPRN# goes inactive. As long as external logic exists to control the BPRN# inputs of all bus arbiters, a subsystem can be designed independent of the priority resolution circuit.

9.4.2 82289 Operating Modes

Following a MULTIBUS I cycle, the controlling bus arbiter can either retain bus control or release control so that another bus master can access the bus. Three modes for relinquishing bus control are as follows:

- Mode 1—The bus arbiter releases the bus at the end of each cycle.
- Mode 2—The bus arbiter retains control of the bus until another bus master (of any priority) requests control.
- Mode 3—The bus arbiter retains control of the bus until a higher priority bus master requests control.

In addition, the bus arbiter can switch between modes 2 and 3, based on the type of bus cycle.




Figure 9-7. Bus Priority Resolution



Figure 9-8 shows the strapping configurations required to implement each of these four techniques.

The operating mode of one bus arbiter affects the throughput of both the individual subsystem as well as other subsystems on MULTIBUS I. This is because the delay required to transfer MULTIBUS I control from one bus arbiter to another affects all subsystems waiting to use MULTIBUS I. Therefore, the most efficient operating mode depends on how often a subsystem accesses MULTIBUS I and how this frequency compares to that of the other subsystems.

• Mode 1 is adequate for a subsystem that needs MULTIBUS I access only occasionally. By releasing MULTIBUS I after each bus cycle, the subsystem minimizes its impact on other subsystems that use MULTIBUS I.




Figure 9-8. Operating Mode Configurations



- Mode 2 is suited for a subsystem that is one of several subsystems that are all equally likely to require MULTIBUS I. The performance decrease caused by the delay necessary to take control of MULTIBUS I is distributed evenly to all subsystems.
- Mode 3 should be used for a subsystem that uses MULTIBUS I frequently. The delay required for taking control of MULTIBUS I and the consequent performance decrease is shifted to subsystems that use MULTIBUS I less often.
- Switching between modes 2 and 3 is useful if the subsystem demand for MULTIBUS I is unknown or variable.

9.4.3 MULTIBUS® I Locked Cycles

Locked bus cycles for the local bus are described in Chapter 3. In locked bus cycles, the 80386 asserts the LOCK# signal to prevent another bus master from intervening between two bus cycles. In the same manner, an 80386 processing subsystem can assert the LLOCK# output of its bus arbiter to prevent other subsystems from gaining control of MULTIBUS I. A locked cycle overrides the normal operating mode of the bus arbiter (one of the four modes mentioned above).

Locked MULTIBUS I cycles are typically used to implement software semaphores (described in Chapter 3) for critical code sections or critical real-time events. Locked cycles can also be used for high-performance transfers within one instruction.

The 80386 initiates a locked MULTIBUS I cycle by asserting its LOCK# output to the 82289 bus arbiter. The bus arbiter outputs its LLOCK# signal to the MULTIBUS I LOCK# status line and holds LLOCK# active until the LOCK# signal from the 80386 goes inactive. The LLOCK# signal from the bus arbiter must be connected to the MULTIBUS I LOCK# status line through a tristate driver controlled by the AEN# output of the bus arbiter.

9.5 OTHER MULTIBUS® I DESIGN CONSIDERATIONS

Additional design considerations are presented in this section. These considerations include provisions for interrupt handling, 8-bit transfers, timeout protection, and power failure handling on MULTIBUS I.

9.5.1 Interrupt-Acknowledge on MULTIBUS® I

When an interrupt is received by the 80386, the 80386 generates an interrupt-acknowledge cycle (described in Chapter 3) to fetch an 8-bit interrupt vector from the 8259A Programmable Interrupt Controller. The 8259A can be located on either MULTIBUS I or a local bus.



Multiple 8259As can be cascaded (one master and up to eight slaves) to process up to 64 interrupts. Three configurations are possible for cascaded interrupt controllers:

- All of the interrupt controllers for one 80386 reside on the local bus of that processor, and all interrupt-acknowledge cycles are directed to the local bus.
- All slave interrupt controllers (those that connect directly to interrupting devices) reside
 on MULTIBUS I. The master interrupt controller may reside on either the local bus or
 MULTIBUS I. In this case, all interrupt-acknowledge cycles are directed to
 MULTIBUS I.
- Some slave interrupt controllers reside on local buses, and other slave interrupt controllers reside on MULTIBUS I. In this case, the appropriate bus for the interrupt acknowledge cycle depends on the cascade address generated by the master interrupt controller.

In the first two configurations, no decoding is needed because all interrupt acknowledge cycles are directed to one bus. However, if a system contains a master interrupt controller residing on a local bus and at least one slave interrupt controller residing on MULTIBUS I, address decoding must select the bus for each interrupt-acknowledge cycle.

The interrupt-acknowledge cycle must be considered in the design of this decoding logic. The 80386 responds to an active INTR input by performing two bus cycles. During the first cycle, the master interrupt controller determines which, if any, of its slave controllers should return the interrupt vector and drive sits cascade address pins (CAS0#, CAS1#, CAS2#) to select that slave controller. During the second cycle, the 80386 reads an 8-bit vector from the selected interrupt controller and uses this vector to service the interrupt.

In a system that has slave controllers residing on MULTIBUS I, the circuit shown in Figure 9-9 can be used to decode the three cascade address pins from the master controller to select either MULTIBUS I or the local bus for the interrupt-acknowledge cycle. If MULTIBUS I is selected, the 82289 Bus Arbiter is enabled. The 82289 in turn requests control of MULTIBUS I and enables the address and data transceivers when the request is granted.

The bus-select signal must become valid for the second interrupt-acknowledge cycle. The master controller's cascade address outputs become valid within 565 nanoseconds after the INTA# output from the bus control logic goes active. Bus-select decoding requires 30 nanoseconds, for a total of 595 nanoseconds from INTA# to bus-select valid. The four idle bus cycles that the 80386 automatically inserts between the two interrupt-acknowledge cycles provides some of this time. The wait-state generator must add wait states to the first interrupt-acknowledge cycle to provide the rest of the time needed for the bus-select signal to become valid.

The cascade address outputs are gated onto A8, A9, and A10 of the address bus through three-state drivers during the second interrupt-acknowledge cycle. Bus control logic must generate a Master Cascade Enable (MCE) signal to enable these drivers. This signal must remain valid long enough for the cascade address to be captured in MULTIBUS I address latches; however it must be de-asserted before the 80386 drives the address bus.






Figure 9-9. Bus-Select Logic for Interrupt Acknowledge

9.5.2 Byte Swapping during MULTIBUS® I Byte Transfers

The MULTIBUS I standard specifies that all byte transfers must be performed on the lower eight data lines (MULTIBUS I DATO#-DAT7#), regardless of the address of the data. An 80386 subsystem must swap data from eight of its upper 24 data lines (D8-D15, D16-D23, or D24-D31) to its lower eight data lines (D0-D7) before transferring data to MULTIBUS I, and swap data from its lower data lines to the appropriate upper data lines when reading a byte from MULTIBUS I. This byte-swapping requirement maintains compatibility between 8-bit, 16-bit, and 32-bit systems sharing the same MULTIBUS I.



The BS16# signal is generated and returned to the 80386 for all MULTIBUS I cycles. The 80386 automatically swaps data between the lower half (D15-D0) and the upper half (D31-D16) of its data bus and adds an extra bus cycle as necessary to complete the data transfer. Therefore, only the logic to swap data from D15-D8 to D7-D0 is needed to meet the byte-swapping requirement of MULTIBUS I.

Figure 9-10 illustrates a circuit that performs the byte-swapping function. The Output Enable (OE#) inputs of the data latch/transceivers are conditioned by the states of the BHE# and A0 outputs of the address decoder.

9.5.3 Bus Timeout Function for MULTIBUS® I Accesses

The MULTIBUS I XACK# signal terminates an 80386 bus cycle by driving the wait-state generator logic. However, if the 80386 addresses a nonexistent device on MULTIBUS I, the XACK# signal is never generated. Without a bus-timeout protection circuit, the 80386 waits indefinitely for an active READY# signal and prevents other processors from using MULTIBUS I.

Figure 9-11 shows an implementation of a bus-timeout circuit that ensures that all MULTIBUS I cycles eventually end. The ALE# output of the bus controller activates a one-shot that outputs a 1-millisecond pulse. The rising edge of the pulse activates the TIMEOUT# signal if READY# does not go active within 1 millisecond to clear the TIMEOUT# flip-flop. The TIMEOUT# signal is input to the wait-state generator logic to activate the READY# signal. When READY# goes active, it is returned to clear the TIMEOUT# signal.

9.5.4 MULTIBUS® I Power Failure Handling

The MULTIBUS I interface includes a Power Fail Interrupt PFIN signal to signal an impending system power failure. Typically, PFIN# is connected to the non-maskable interrupt (NMI) request input of each 80386. The NMI service routine can direct the 80386 to save its environment immediately, before falling voltages and the MULTIBUS I Memory Protect (MPRO#) signal prevent any further memory activity. In systems with memory backup power or nonvolatile memory, the saved environment can be recovered on powerup.

The power-up sequence of the 80386 can check the state of the MULTIBUS I Power Fail Sense Latch (PFSN#) to see if a previous power failure has occurred. If this signal is active (low), the 80386 can branch to a power-up routine that resets the latch using the Power Fail Sense Reset signal (PFSR#), restores the previous 80386 environment, and resumes execution.

Further guidelines for designing 80386 systems with power failure features are contained in the Intel MULTIBUS® I Specification.






Figure 9-10. Byte-Swapping Logic

9.6 iLBX™ BUS EXPANSION

The iLBX (Local Bus Expansion) is a high-performance bus interface standard that permits the modular expansion of an 80386-based system. An iLBX interface links the 80386 system board with additional boards containing memory, I/O subsystems, and other peripheral devices or bus masters. Any board that conforms to the iLBX standard can be added to the system as the user's needs dictate. For a 16-MHz 80386-based system, a typical iLBX access cycle requires six wait states.






Figure 9-11. Bus-Timeout Protection Circuit

The iLBX™ Bus Specification describes the iLBX Local Bus Expansion standard in detail.

The iLBX bus interface requires the generation of A1, A0, and BHE# from the 80386 BE3#-BE0# outputs. The iLBX connector contains 24 address bits (AB23-AB0) and 16 data bits (DB15-DB0), which are taken from the buffered address lines (A23-A0), and data lines (D15-D0) of the 80386 local bus. BHE# is inverted and buffered to provide the Byte High Enable (BHEN) signal.

The Read/Write (R/W#), Data Strobe (DSTB#), and Address Strobe (ASTB#) controls are generated from local bus control signals using the logic shown in Figure 9-12. R/W# is a delayed, inverted version of the W/R# output of the 80386. DSTB# goes active when either RD# or WR# from the local bus control goes active. ASTB# and DSTB# are delayed to allow adequate setup time for BHEN. In this example, the WS2 signal, which is active during the third CLK cycle of the 80386 bus cycle, provides the delay.

A chip-select output of address decoding logic goes active for accesses to the memory and I/O locations allocated to the iLBX bus and selects the iLBX address and data buffers. Command signals from the local bus control logic enable the outputs of the iLBX transceivers.

When an iLBX cycle is complete, the Acknowledge (ACK#) signal is returned over the iLBX bus. This signal must be synchronized and incorporated into the wait-state generator logic to provide the READY# signal.

9.7 DUAL-PORT RAM WITH MULTIBUS® I

A dual-port RAM is a memory subsystem that can be accessed by both the 80386, through its local bus, and other processing subsystems, through the MULTIBUS I system bus. Dual-port RAM offers some of the advantages of both local resources and system resources. It is an effective solution when using only local memory or only system memory would decrease system cost and/or performance significantly.






Figure 9-12. iLBX™ Signal Generation

The 80386 accesses dual-port RAM through its high-speed local bus, leaving MULTIBUS I free for other system operations. Other processing subsystems can pass data to and from the 80386 through the dual-port RAM using MULTIBUS I.

If necessary, dual-port RAM can be mapped to reserve address ranges for the exclusive use of the 80386. The 80386 and the other processing subsystems need not use the same address mapping for dual-port RAM.

The disadvantage of dual-port RAM is that its design is more complex than that of either local or system memory. Dual-port RAM requires arbitration logic to ensure that only one of the two buses gains access at one time.

9.7.1 Avoiding Deadlock with Dual-Port RAM

The MULTIBUS-LOCK# signal and the 80386 LOCK# signal mediate contention when both the 80386 and a MULTIBUS I device attempt to access dual-port RAM. However, locked cycles to dual-port RAM can potentially result in deadlock. Deadlock arises when the 80386 performs locked cycles to ensure back-to-back accesses to dual-port RAM and MULTIBUS I.



Suppose the 80386 locks an access to dual-port RAM followed by a MULTIBUS access, to ensure that the accesses are performed back-to-back. (This could happen only in protected mode during interrupt processing when the IDT is in the dual-port RAM and the target descriptor is in MULTIBUS RAM.) At the same time the 80386 performs the first locked cycle, another device gains control of MULTIBUS I for the purpose of accessing dual-port RAM. The 80386 cannot gain control of MULTIBUS I to complete the locked operation, and the other device cannot relinquish control of MULTIBUS I because it cannot complete its access to dual-port RAM. Each device therefore enters an interminable wait state.

Two approaches can be used to avoid deadlock:

- Requiring software to be free of locked accesses to dual-port RAM.
- Designing hardware to negate the LOCK# signal for transfers between dual-port RAM and MULTIBUS I. If this approach is used, software writers must be informed that such transfers will not be locked even though software dictates locked cycles.

CHAPTER 10 MULTIBUS® II AND 80386

Standard bus interfaces guarantee compatibility between existing and newly developed systems. This compatibility safeguards a user's hardware investment against obsolescence even in the face of rapidly advancing technology. The MULTIBUS I standard interface has proven its value in providing flexibility for the expansion of existing systems and the integration of new designs. The MULTIBUS II standard interface extends Intel's Open Systems design strategy into the world of 32-bit microprocessing systems.

10.1 MULTIBUS® II STANDARD

The MULTIBUS II standard is a processor-independent bus architecture that features a 32-bit parallel system bus with a maximum throughput of 40 megabytes per second, high-speed local bus access to off-board memory, a low-cost serial system bus, and full multi-processing support. MULTIBUS II achieves these features through five specialized Intel buses:

- Parallel System Bus (iPSB)
- Local Bus Extension (iLBX II)
- Serial System Bus (iSSB)
- Multi-channel DMA I/O Bus
- System Expansion I/O Bus (iSBX)

The DMA I/O Bus and the iSBX are carried over directly from MULTIBUS I architecture. See the MULTIBUS® I Architectural Specification for a full description of these buses. The multiple bus structure provides the following important advantages over a single, generalized bus:

- Each bus is optimized for a specific function.
- The buses perform operations in parallel.
- Buses that are not needed for a particular system can be omitted, avoiding unnecessary costs.

10.2 PARALLEL SYSTEM BUS (iPSB)

The Parallel System Bus (iPSB) is optimized for interprocessor data transfer and communication. Its burst transfer capability provides a maximum sustained bandwidth of 40 megabytes per second for high-performance data transfers.



The iPSB supports four address spaces per bus agent (a board that encompasses a functional subsystem). The conventional I/O and memory address spaces are included, plus two other address spaces that support advanced functions:

- An 255 address message space supports message passing. Typically, a microprocessor
 performs interprocessor communications inefficiently. Message passing allows two bus
 agents to exchange a block of data at full bus bandwidth without supervision from a
 microprocessor. An intelligent bus interface capable of message passing shifts the burden
 of interprocessor communication away from the processor, thus enhancing overall system
 performance.
- An interconnect space allows geographic addressing, which is the identification of any bus agent (board) by slot number. Every MULTIBUS II system contains a Central Services Module (CSM) that provides system services, such as uniform initialization and bus timeout detection, for all bus agents residing on the iPSB bus. The CSM may use the registers of the interconnect space of each bus agent to configure the agent dynamically. Stake pin jumpers, DIP switches, and other hardware configuration devices can be eliminated.

Because the 80386 can access only memory space or I/O space, the message space and interconnect space may be mapped into the memory space or the I/O space. Decoding logic provides chip select signals for the devices implementing the message space and the interconnect space, as well as devices in the memory space and the I/O space.

Three types of bus cycles define activity on the iPSB bus:

- Arbitration Cycle—Determines the next owner of the bus. This cycle consists of a resolution phase, in which competing bus agents determine priority for bus control, and an acquisition phase, in which the agent with the highest priority initiates a transfer cycle.
- Transfer Cycle—Performs a data transfer between the bus owner and another bus agent. This cycle consists of a request phase, in which address control signals are driven, and a reply phase, in which the two agents perform a handshake to synchronize the data transfer. The reply phase is repeated and data transfers continue until the bus owner ends the transfer cycle.
- Exception Cycle—Indicates that an exception (error) has occurred during a transfer cycle. This cycle consists of a signal phase, in which an exception signal from one bus agent causes all other bus agents to terminate any arbitration and transfer cycles in progress, and a recovery phase, in which the exception signals go inactive. A new arbitration cycle can begin on the clock cycle after the recovery phase.

Figure 10-1 shows how the timing of these cycles overlap.

10.2.1 iPSB Interface

Each bus agent must provide a means of transferring data between its 80386, its interconnect registers, and the iPSB bus. The location of bus interface logic to meet this requirement is shown in Figure 10-2. A full-featured subsystem may also include provisions for the message passing protocols used by the iPSB bus.




Figure 10-1. iPSB Bus Cycle Timing






Figure 10-2. iPSB Bus Interface

The iPSB interface may be conveniently implemented by a Bus Arbiter/Controller (BAC), a Message Interrupt Controller (MIC), and miscellaneous logic. The BAC coordinates direct interaction with the other devices on the iPSB bus, while the MIC works through the BAC to send and receive interrupt messages. Other logic is needed for address decoding, parity checking, and control signal generation.

The BAC and MIC are implemented in Intel gate arrays. In addition, Intel is developing an advanced CMOS device, the Message Passing Coprocessor (MPC), that integrates the functions of the BAC and the MIC plus parity checking and full message passing (solicited and unsolicited), all in one package called the BIC (Bus Interface Controller). Systems designed today with the available BAC and MIC can be upgraded to the MPC in the future.

10.2.1.1 BAC SIGNALS

The BAC provides arbitration and system control logic for the arbitration, transfer, and exception cycles defined by the MULTIBUS II architecture. Through the BAC, the bus agent functions as either a requestor or a replier in a transfer cycle. In all cases, the device requiring iPSB bus access (either the 80386 or the MIC) is completely isolated from the iPSB; the BAC provides all direct interaction.



The BAC signals can be divided into three functional groups:

- iPSB interface
- · Local bus interface
- Register interface with the 80386

The iPSB interface signals perform mainly arbitration and system control. Five bidirectional Arbitration signals (ARB5-ARB0) are used during reset to read a cardslot ID and arbitration ID from the CSM, and during arbitration cycles to output the arbitration ID for priority resolution. Bus Request (BREQ#) is a bidirectional signal. Each bus agent asserts BREQ# to request control of the bus and samples BREQ# to determine if other agents are also contending for bus control.

Bus Error (BUSERR#) is a bidirectional signal that a bus agent outputs to all other bus agents when it detects a parity error during a transfer cycle. Bus Timeout (TIMOUT #) is output by the CSM to all bus agents when a bus cycle fails to end within a prescribed time period.

Ten System Control signals (SC9#-SC0#) coordinate transfer cycles. The MULTIBUS® II Architectural Specification defines each of these signals. Directional enables (SCOEH and SCOEL) are provided for transceivers to buffer these bidirectional signals. External logic checks byte parity on the multiplexed address and data bus (AD31-AD0) and sets the Parity inputs (PAR3-PAR0) accordingly.

Other iPSB signals are Reset (RST#), Reset-Not-Complete (RSTNC#), and ID Latch (LACHn#, n = slot number). These signals are used only during reset.

Local bus interface signals pertain to the communication between the BAC and the 80386 or between the BAC and the MIC. These signals indicate to the BAC when to request bus control and what type of bus cycle to drive when it gains bus control.

Four control signals are necessary for each of the two devices connected to the BAC. The signals that connect to the 80386 are REQUESTA, GRANTA, READYA, and SELECTA; those that connect to the MIC are REQUESTB, GRANTB, READYB, and SELECTB.

To request bus control, the 80386 or the MIC activates one of the REQUEST signals. The corresponding GRANT signal is returned by the BAC when it has bus control. Data width and address space selections are encoded on the WIDTH1#, WIDTH0#, SPACE1#, and SPACE0# inputs, while WR# dictates either a write cycle or a read cycle. These five inputs translate directly to SC6#-SC2# outputs during the request phase of a transfer cycle. READYA or READYB indicates that WIDTH0#, WIDTH1#, SPACE0#, SPACE1#, and WR# can be read by the BAC to drive the transfer cycle.

LASTINA or LASTINB controls the end-of-cycle signal for burst transfers. The LOCK# input is activated for locked transfers.



The bus agent that receives a transfer cycle from the bus owner must have its BAC enabled by an active SELECT input. Errors detected by the replying agent are encoded by its MIC on the AGERR2-AGERR0 inputs to its BAC so that the BAC can drive the SC7#-SC5# lines accordingly. If an error occurs, the requesting agent notifies the 80386 through the EINT signal.

The register interface signals control register operations between the 80386 and the BAC. Three 5-bit registers (Arbitration ID, Slot ID, and Error Port) are addressed through RSEL1 and RSEL0. Data is transferred on RIO4-RIO0; the direction of transfer is indicated by RRW.

10.2.1.2 MIC SIGNALS

The MIC coordinates interrupt handling for a bus agent on the iPSB bus. Interrupts are implemented as virtual interrupts in the message space. To send an interrupt message, the 80386 writes four bytes to the MIC to indicate the source, destination, and type of message. The MIC then coordinates the message transfer. The MIC of the receiving bus agent reads the 4-byte message and stores it in a 4-deep message queue to be read by the 80386.

The MIC signals are divided into three groups:

- iPSB interface
- · Local bus interface
- BAC interface

The iPSB interface consists of the multiplexed address/data bus (AD31#-AD0#). Although the MIC gains access to the iPSB bus through the BAC, the MIC drives the address/data bus directly. As a requesting agent, the MIC drives the address and data at the appropriate times. As a receiving agent, the MIC monitors the address/data bus for its address. When it recognizes its address, the MIC selects its BAC to perform the required handshake and read the message into the message queue. Then, the MIC interrupts the 80386 to indicate that the message is pending in the queue. The 80386 reads the message and services the interrupt accordingly.

The local bus interface consists of seven register/ports, addressed through A2-A0, through which the MIC and the 80386 communicate. Data is transferred over D7-D0, and WR# and RD# determine the direction of transfer. Other signals include the MIC Chip Select (CS#), a WAIT# signal for adding wait states to the 80386 cycle, and a Message Interrupt (MINT) to signal an interrupt condition to the 80386.

The BAC interface includes REQUESTB, READYB, SELECTB, and GRANTB. These signals have already been described with the other BAC signals.

While the BAC and the MIC together provide the backbone for an iPSB interface, other logic provides buffering and control to round out the interface. An 8751 Microcontroller coordinates 80386 access to the interconnect space. An address decoder distinguishes between local, interconnect, and iPSB accesses. PALs control the buffering of signals between the 80386, BAC, MIC, 8751 Microcontroller, and iPSB bus.



10.3 LOCAL BUS EXTENSION (iLBX™ II)

The iLBX II bus extension is a high-speed execution bus designed for quick access to off-board memory. One iLBX II bus extension can support either two processing subsystems (called the primary requesting agent and the secondary requesting agent) plus four memory subsystems, or a single processing subsystem plus five memory subsystems. A MULTIBUS II system may contain more than one iLBX II bus extension to meet its memory requirements.

The iLBX II bus extension features a 26-bit address bus and a separate 32-bit data bus. Because these paths are separate, the extension allows pipelining of transfer cycles; the request phase of a transfer cycle can overlap the reply phase of the previous cycle.

Other features of the iLBX II bus extension are:

- A unidirectional handshake for fast data transfers
- Mutual exclusion capability to control multiported memory
- Interconnect space (for each bus agent) through which the primary requesting agent initializes and configures all other bus agents.

10.4 SERIAL SYSTEM BUS (ISSB)

The Serial System Bus (iSSB) provides a simple, low-cost alternative to the Parallel System Bus (iPSB) bus. In applications that do not require the high performance of the iPSB bus, the iSSB bus can provide some cost reduction. In systems containing both the iPSB bus and the iSSB bus, the iSSB bus provides an alternate path for interface control, diagnostics, or redundancy.

The iSSB bus can contain up to 32 bus agents distributed over a maximum of 10 meters. Bus control is determined through an access protocol called Carrier Sense Multiple Access with Collision Detection (CSMA/CD). This protocol allows agents to transmit data whenever they are ready. In case of simultaneous transmission by two or more bus agents, the iSSB invokes a deterministic collision resolution algorithm to grant fair access to all agents.

From the application point of view, the error detection capability of the iSSB bus, coupled with an intelligent bus agent interface (able to retransmit) makes the iSSB bus as reliable as the iPSB bus, even though the iSSB bus may be up to 10 meters long.

Physical Design and Debugging 11



CHAPTER 11 PHYSICAL DESIGN AND DEBUGGING

This chapter outlines recommendations for providing adequate power to the 80386, addressing high-frequency issues that do not exist for lower-frequency systems, achieving the proper thermal environment for the 80386, and building an 80386-based system successfully. The guidelines presented here allow the user to gain the full benefits of the high-performance 80386.

11.1 POWER AND GROUND REQUIREMENTS

The CHMOS III 80386 differs from previous HMOS microprocessors in that its power dissipation is primarily capacitive; there is almost no DC power dissipation. Power dissipation depends mostly on frequency.

Power dissipation can be distinguished as either internal (logic) power or I/O (bus) power. Internal power varies with operating frequency and to some extent with wait states and software. Internal power increases with supply voltage also. Process variations in manufacturing affect internal power, although to a lesser extent than with NMOS processes.

I/O power, which accounts for roughly one-fifth of the total power dissipation, varies with frequency and voltage. It also depends on capacitive bus load. Capacitive bus loadings for all output pins are specified in the 80386 data sheet. The 80386 output valid delays will increase if these loadings are exceeded. The addressing pattern of the software can affect I/O power by changing the effective frequency at the address pins. The variation in frequency at the data pins tends to be smaller; thus varying data patterns should not cause a significant change in power dissipation.

11.1.1 Power and Ground Planes

Power and ground planes must be used in 80386 systems to minimize noise. Power and ground lines have inherent inductance and capacitance, therefore an impedance $Z = (L/C)^{1/2}$. The total characteristic impedance for the power supply can be reduced by adding more lines. This effect is illustrated in Figure 11-1, which shows that two lines in parallel have half the impedance of one. To reduce the impedance even further, the user should add more lines. In the limit, an infinite number of parallel lines, or a plane, results in the lowest impedance. Planes also provide the best distribution of power and ground.

The 80386 has 20 V_{cc} pins and 21 V_{ss} (ground) pins. All power and ground pins must be connected to a plane. Ideally, the 80386 is located at the center of the board, to take full advantage of these planes.

Although the 80386 generally demands less power than the 80286, the possibility for power surges is increased due to higher frequency and pin count. Peak-to-peak noise on V_{cc} relative to V_{ss} should be maintained at no more than 400 mV, and preferably no more than 200 mV.



11.1.2 Decoupling Capacitors

The switching activity of one device can propagate to other devices through the power supply. For example, in the TTL NAND gate of Figure 11-2, both Q3 and Q4 transistors are on for a short time when the output is switching. This increased load causes a negative spike on $V_{\rm cc}$ and a positive spike on ground. In synchronous systems in which many gates switch simultaneously, the result is significant noise on the power and ground lines.




Figure 11-1. Reducing Characteristic Impedance




Figure 11-2. Circuit without Decoupling



Decoupling capacitors placed across the device between $V_{\rm cc}$ and ground reduce voltage spikes by supplying the extra current needed during switching. These capacitors should be placed close to their devices because the inductance of connection lines negates their effect.

When selecting decoupling capacitors, the user should provide 0.01 microfarads for each device and 0.1 microfarads for every 20 gates. Radio-frequency capacitors must be used; they should be distributed evenly over the board to be most effective. In addition, the board should be decoupled from the external supply line with a 2.2 microfarads capacitor.

Chip capacitors (surface-mount) are preferable because they exhibit lower inductance and require less total board space. They should be connected as in Figure 11-3. Leaded capacitors can also be used if the leads are kept as short as possible. Six leaded capacitors are required to match the effectiveness of one chip capacitor, but because only a limited number can fit around the 80386, the configuration in Figure 11-4 results.

11.2 HIGH-FREQUENCY DESIGN CONSIDERATIONS

At high signal frequencies, the transmission line properties of signal paths in a circuit must be considered. Reflections, interference, and noise become significant in comparison to the high-frequency signals. They can cause false signal transitions, data errors, and input voltage level violations. These errors can be transient and therefore difficult to debug. In this section, some high-frequency design issues are discussed; for more information, consult a reference book on high-frequency design.




Figure 11-3. Decoupling Chip Capacitors






Figure 11-4. Decoupling Leaded Capacitors

11.2.1 Line Termination

Input voltage level violations are usually due to voltage spikes that raise input voltage levels above the maximum limit (overshoot) and below the minimum limit (undershoot). These voltage levels can cause excess current on input gates that results in permanent damage to the device. Even if no damage occurs, most devices are not guaranteed to function as specified if input voltage levels are exceeded.

Signal lines are terminated to minimize signal reflections and prevent overshoot and undershoot. If the round-trip signal path delay is greater than the rise time or fall time of the signal, terminate the line. If the line is not terminated, the signal reaches its high or low level before reflections have time to dissipate, and overshoot and undershoot occur.

There are two methods of termination: series and split. A series termination compensates for excess current before the signal travels down the line; a split termination adjusts the current at the end of the line.

Series termination decreases current flow in the signal path by adding a series resistor, as shown in Figure 11-5. The resistor increases the rise and fall times of the signal so that the change in current occurs over a longer period of time. Because the amount of voltage overshoot and undershoot depends on the change in current over time $(V = L \, di/dt)$, the increased time reduces overshoot and undershoot. The series resistor should be placed as close as possible to the signal source.

Series termination is advantageous because less power is consumed than in split termination. However, series termination reduces signal rise and fall times, so it should not be used when these times are critical.






Figure 11-5. Series Termination




Figure 11-6. Split Termination

Split termination is effective in reducing signal reflection (ringing). Split termination is accomplished by the addition of two resistors, as shown in Figure 11-6. These two resistors "absorb" electrical energy at the end of the signal line. Split termination requires a line driver capable of supplying the large current drawn by R1 and R2.

11.2.2 Interference

Interference is the result of electrical activity in one conductor causing transient voltages to appear in another conductor. Interference increases with the following factors:

- Frequency-Interference is the result of changing currents and voltages. The more frequent the changes, the greater the interference.
- Closeness of the two conductors—Interference is due to electromagnetic and electrostatic fields whose effects are weaker further from the source.

There are two types of interference to consider in high frequency circuits: electromagnetic interference (EMI) and electrostatic interference (ESI).



EMI (also called crosstalk) is caused by the magnetic field that exists around any current-carrying conductor. The magnetic flux from one conductor can induce current in another conductor, resulting in transient voltage. Several precautions can minimize EMI:

- Running a ground line between two adjacent lines wherever they traverse a long section of the circuit board. The ground line should be grounded at both ends.
- Running ground lines between the lines of an address bus or a data bus if either of the following conditions exists:
 - The bus is on an external layer of the board.
 - The bus is on an internal layer but not sandwiched between power and ground planes that are at most 10 mils away.
- Avoiding closed loops in signal paths (see Figure 11-7). Closed loops cause excessive current and create inductive noise, especially in the circuitry enclosed by a loop.

ESI is caused by the capacitive coupling of two adjacent conductors. The conductors act as the plates of a capacitor; a charge built up on one induces the opposite charge on the other. The following steps reduce ESI:

- Separating signal lines so that capacitive coupling becomes negligible.
- Running a ground line between two lines to cancel the electrostatic fields.




Figure 11-7. Avoid Closed-Loop Signal Paths



11.2.3 Latchup

Latchup is a condition in a CMOS circuit in which V_{cc} becomes shorted to V_{ss} . Intel's CHMOS III process is immune to latchup under normal operating conditions. Latchup can be triggered when the voltage limits on I/O pins are exceeded, causing internal PN junctions to become forward biased. The following guidelines help prevent latchup:

- Observing the maximum rating for input voltage on I/O pins.
- Never applying power to an 80386 pin or a device connected to an 80386 pin before applying power to the 80386 itself.
- Preventing overshoot and undershoot on I/O pins by adding line termination and by designing to reduce noise and reflection on signal lines.

11.3 CLOCK DISTRIBUTION AND TERMINATION

For performance at high frequencies, the clock signal (CLK2) for the 80386 must be free of noise and within the specifications listed in the 80386 data sheet. These requirements can be met by following these guidelines:

- Using the 82384 Clock Generator to provide both CLK2 and CLK signals. The 82384 is designed to match 80386 specifications.
- Terminating the CLK2 output with a series resistor to obtain a clean signal. The resistor value is calculated by measuring the total capacitive load on the CLK2 signal and referring to Figure 11-8. If the total capacitive load is less than 80 picofarads, the user should add capacitors to make up the difference. Because of the high frequency of CLK2, the terminating resistor must have low inductance; carbon resistors are recommended.
- Not putting more than two loads on a single trace to avoid signal reflection (see Figure 11-9 for example configurations).
- Using an oscilloscope to compare the CLK2 waveform with those in Figure 11-10.

11.4 THERMAL CHARACTERISTICS

The thermal specification for the 80386 defines the maximum case temperature. This section describes how to ensure that an 80386 system meets this specification.

Thermal specifications for the 80386 are designed to guarantee a tolerable temperature at the surface of the 80386 chip. This temperature (called the junction temperature) can be determined from external measurements using the known thermal characteristics of the package. Two equations for calculating junction temperature are as follows:

$$T_i = T_a + (\theta_{ia} * PD)$$
 and

$$T_{j} = T_{c} + (\theta_{jc} * PD)$$






Figure 11-8. CLK2 Series Termination

where

 $T_i = junction temperature$

_a = ambient temperature

 $T_c = case tempterature$

 θ_{ia} = junction-to-ambient temperature coefficient

 θ_{ic} = junction-to-case temperature coefficient

PD = power dissipation (worst-case $I_{cc} * V_{cc}$






Figure 11-9. CLK2 Loading




Figure 11-10. CLK2 Waveforms

Case temperature calculations offer several advantages over ambient temperature calculations:

- Case temperature is easier to measure accurately than ambient temperature because the
 measurement is localized to a single point (top center of the package).
- The worst-case junction temperature (T_j) is lower when calculated with case temperature for the following reasons:
 - The junction-to-case thermal coefficient (θ_{jc}) is lower than the junction-to-ambient thermal coefficient (θ_{ja}); therefore, calculated junction temperature varies less with power dissipation (PD).
 - θ_{ic} is not affected by air flow in the system; θ_{ia} varies with air flow.



With the case-temperature specification, the designer can either set the ambient temperature or use fans to control case temperature. Finned heat sinks or conductive cooling may also be used in environments where the use of fans is precluded. To approximate the case temperature for various environments, the two equations above should be combined by setting the junction temperature equal for both, resulting in this equation:

$$T_a = T_c - ((\theta_{ia} - \theta_{ic}) *PD)$$

The current data sheet should be consulted to determine the values of θ_{ja} (for the system's air flow) and ambient temperature that will yield the desired case temperature. Whatever the conditions are, the case temperature is easy to verify.

11.5 DEBUGGING CONSIDERATIONS

This section outlines an approach to building and debugging 80386 hardware incrementally. In a short time, a complete 80386-based system can be built and working. This approach does not have to be followed to the letter, but it provides several valuable debugging concepts and useful hints. Use these guidelines in conjunction with the 80386 data sheet, which contains detailed information about the 80386.

11.5.1 Hardware Debugging Features

Even before a system is built, debugging can be made easier by planning a suitable environment for the 80386. The 80386 board (whether it is a printed circuit board or a wire-wrap board) must have power and ground planes. The user should provide a decoupling capacitor between $V_{\rm ce}$ and GND next to each IC on the board. All 80386 $V_{\rm ce}$ and GND pins should be connected individually to the appropriate power or ground plane; multiple power or ground pins should not be daisy-chained.

Room in the system should be included for the following physical features to aid debugging:

- Two switches: one for generating the RESET signal to the 80386 and one for tying the READY# signal high (negated).
- Connections for a logic analyzer on major control signals:

```
Inputs to the 80386:

Ready (READY#)

Next Address (NA#)

Bus Size 16 (BS16#)

Data Bus (D0-D31)

Outputs from the 80386:

Address Strobe (ADS#)

Write/Read (W/R#), Data/Control (D/C#),

Memory/IO (M/IO#), Lock (LOCK#)

Address Bus (A2-A31)

Byte Enable (BE0#-BE3#)
```



Logic analyzer connection points should be provided to all 80386 address outputs (A2-A31 and BE0#-BE3#) even if there are not enough logic analyzer inputs to accommodate all of them. Initially, only BE0#, BE1#, BE2#, BE3#, and the output of the address decoder circuit should be connected. The single output of an address decoder circuit represents many bits of address information. If the address decoder does not work as expected, more of the logic analyzer inputs should be moved to the 80386 address pins.

• Buffers and visual indicators (such as LEDs) for three or four of the critical 80386 control signals. A visual indicator for the ADS# output, for example, will light when the system is performing bus cycles.

11.5.2 Bus Interface

During initial debugging, bus-cycle operation should be simplified. The 80386 bus interface is flexible enough to be tested in stages. To simplify bus control, the initial testing should be performed with a non-pipelined address. The NA# input should be tied high (negated) to guarantee no address pipelining. The only signals that need to be controlled are the READY# input and the BS16# input.

The READY# input on the 80386 lets the user delay the end of any bus cycle for as long as necessary. For each CLK cycle after T2 that READY# is not sampled active, a wait state is added. READY# can be used to provide extra time (wait states) for slow memories or peripherals. Wait state requirements are a function of the device being addressed. Therefore, the address decoder must determine how many wait states, if any, to add to each bus cycle. The address decoder circuit (usually in conjunction with a shift register) must generate the READY# signal when it is time for the bus cycle to end. It is critical for the system to generate the READY# signal; if it does not, the 80386 will wait forever for the bus cycle to end.

EPROMs, static RAMs, and peripherals all interface in much the same way. The EPROM interface is the simplest because EPROMs are read-only devices. RAM interfaces must support byte addressability during RAM write cycles. Therefore, RAM write enables for each byte of the 32-bit data bus must be controlled separately.

The BS16# signal must be activated when the current bus cycle communicates over a 16-bit bus. An address decoder circuit can be used to determine if BS16# must be asserted during the current bus cycle.

11.5.3 Simplest Diagnostic Program

To start debugging 80386 hardware, the user should make a set of EPROMs containing a simple program, such as a 4-byte diagnostic that loops. Such a program is shown in Figure 11-11. Because the program is four bytes long, it will exercise all 32 bits of the data bus. This program tests only the code prefetch ability of the 80386.

In generating this program, the user should take into account the initial values of the 80386 CS register (F000H) and IP register (FFF0H) after reset. The software entry point (label START in Figure 11-11) must match the CS:IP location.



```
ASSUME CS:SIMPLEST_CODE
0000
                 SIMPLEST CODE
                                  SEGMENT
FFF0
                                  ORG OFFFOH
     9.0
                 START:
                                  NΠP
     9.0
                                  NOP
FFF1
                                  JMP START
FFF2 EB FC
                 SIMPLEST_CODE
FFF4
                                  ENDS
                                  END
```

Figure 11-11. 4-Byte Diagnostic Program

The 80386 is initially in Real Mode (the mode that emulates the 8086) after reset. With this simple diagnostic code, it will remain in Real Mode. In Real Mode, CS:IP generates the physical code fetch address directly, without any descriptors, by adding CS and IP in the following way:

Also, after reset (until the 80386 executes an intersegment JMP or CALL instruction), the physical base address of the code segment is set internally to FFFF0000H. Therefore, the physical address of the first code fetch after reset is always FFFFFF0H. The simple diagnostic program must begin at this location.

11.5.4 Building and Debugging a System Incrementally

When designing an 80386 system, the designer plans the entire system. The core portions must be tested, however, before building the entire system. Beginning with only the 80386 and the 82384 Clock Generator, the following steps outline an approach that enables the designer to build up a system incrementally:

- 1. Install the 82384 and its crystal. Check that the CLK2 signal is clean. Connect the CLK2 signal to the 80386.
- 2. Connect the 82384 RESET output to the 80386 RESET input, and with CLK2 running, check that the state of the 80386 during RESET is correct.



- 3. Tie the 80386 INTR, NMI, and HOLD input pins low. Tie the READY# pin high so that the first bus cycle will not end. Reset the 80386, and check that the 80386 is emitting the correct signals to perform its first code fetch from physical address FFFFFFOH. Connect the address latch, and verify that the address is driven at its outputs.
- 4. Connect the address decoding hardware to the 80386, and check that after reset, the 80386 is attempting to select the EPROM devices in which the initial code to be executed will be stored.
- 5. Connect the data transceiver to the system, and check that after reset, the transceiver control pins are being driven for a read cycle. Connect all address pins of the EPROM sockets, and check that after reset, they are receiving the correct address for the first code fetch cycle.

Intel's iPPS programmer for EPROMs supports dividing an object module into four EPROMs, as is necessary for a 32-bit data bus to EPROM. The programmer can also divide an object module into two EPROMs for a 16-bit data bus to the EPROMs. (In this case, the BS16# input to the 80386 must be asserted during all bus cycles communicating with the EPROMs).

When the 82384, crystal, 80386, address decoder, address latch, data transceiver, and READY# generation logic (including wait-state generation) are functioning, the 80386 is capable of running the software in the EPROMs. Now the simple debug program described above can be run to see whether the parts of the system work together.

After installing the EPROMs, the READY# line should be tied high (negated) so that the 80386 begins its first bus cycle after reset and then continues to add wait states. While the system is in this state, the circuit should be probed to verify signal states, using a voltmeter or oscilloscope probe.

The programmer should check whether the address latches have latched the first address and whether the address decoder is applying a chip-select signal to the EPROMs. The EPROMs should be emitting the first four opcode bytes of the first code to be executed (90H, 90H, EBH, FCH for the 4-byte program of Figure 11-11), and the opcode should be propagating through the data transceivers to the 80386 data pins.

Then the READY# input should be connected to the READY# generation logic, the 80386, and the results should be tested when the simple program runs. Because the program loops back on itself, it runs continuously. At this point, the system has progressed to running multiple bus cycles, so a logic analyzer is needed to observe the dynamic behavior of the system.

When the EPROMs programmed with the simple 4-byte diagnostic program are installed and the 80386 is executing the code, the LED indicator for ADS# (if included in the system) glows, because ADS# is generated for each bus cycle by the 80386. It is necessary to check that the EPROMs are selected for each code fetch cycle. After system operation is verified with the simple program, more complex programs can be run.



11.5.5 Other Simple Diagnostic Software

Other simple programs can be used to check the other operations the system must perform. The program described here is longer than the 4-byte program illustrated previously; it tests the abilities to write data into RAM and read the data back to the 80386.

This second diagnostic program, shown in Figure 11-12, is also suitable for placing into EPROMS. Because this diagnostic loops back to itself, the ADS# LED should glow continuously, just as it does when running the 4-byte program.

The program in Figure 11-12 is based on the assumption that hardware exists to report whether the data being read back from RAM is correct. This hardware consists of a writable output latch that can display a byte value written to it. The byte value written is a function of the RAM data comparison test. If the data is correct, the byte value written is AAH (10101010); if the data is incorrect, 55H (01010101) is written.

This diagnostic program is not comprehensive, but it does exercise EPROM, RAM, and an output latch to verify that the basic hardware works.

The program is short (45 bytes) to be easily understood. Because it is short and because it loops continuously, a logic analyzer or even an oscilloscope can be used to observe system activity.

This program can be written in ASM86 assembly language. Because the primary purpose of this program is to exercise the system hardware quickly, the 80386 is not tested extensively, and Protected Mode is not enabled.

The diagnostic software verifies the ability of the system to perform bus cycles. The 80386 fetches code from the EPROMs, implying that EPROM read cycles function correctly. Instructions in the program explicitly generate bus cycles to write and read RAM. The data value read back from RAM is checked for correctness, then a byte (AAH if the data is correct, 55H if it is not) is output to the 8-bit output latch. The program then loops back to its beginning and starts over.

After the source code is assembled, the resulting object code should be as shown in Figure 11-13.

11.5.6 Debugging Hints

The debugging approach described in this section is incremental; it lets the programmer debug the system piece by piece. If even the simple 4-byte program does not run, a logic analyzer can be used to determine where the problem is. At the very least, the 80386 should be initiating a code fetch cycle to EPROM.



```
PAGE
                          66,132
;
        EOUATES
;
LATCH
                 EQU
                          0C8H
                                           ; PRESUMES A HARDWARE
                                           ;LATCH IS AT I/O ADDR C8H
GOOD SIGNAL
                 EOU
                          0AAH
BAD SIGNAL
                 EQU
                          0.55H
        CODE TO VERIFY ABILITY TO WRITE AND READ RAM CORRECTLY
                 ASSUME CS: INITIAL CODE
INITIAL CODE
                 SEGMENT
                 ORG
                          OF000H
                                           ;THIS IS INTENDED TO BE LOCATED
                                           ;AT PHYSICAL ADDRESS FFFFF000H
TST LOOP:
                 MOV
                          вх, 0000н
                                           ;INITIALIZE BASE REGISTER TO 0
                 MOV
                          DS, BX
                                           ;INITIALIZE DS REGISTER TO 0
                 MOV
                          [BX], 5473H
                                           ;WRITE 5473H TO RAM ADDR 0 AND 1
                 MOV
                          [BX]+2, 2961H
                                           ; WRITE 2961H TO RAM ADDR 2 AND 3
                 JMP
                         READ
                                           ; JMP TO FORCE CPU TO BREAK
                                           ;PRE-FETCH QUEUE AND FETCH THE
                                           ; NEXT INSTRUCTION AGAIN. THIS
                                           ; PREVENTS THE RAM DATA WRITTEN
                                           ;FROM JUST LINGERING ON THE DATA;BUS UNTIL THE READ OCCURS
READ:
                 CMP
                          [BX], 5473H
                                           ; READ DATA FROM RAM ADDR 0 AND 1
                                           ; AND COMPARE WITH VALUE WRITTEN
                 JNE
                          BADRAM
                                           ; IF DATA DOESN'T MATCH, THEN JMP
                 CMP
                          [BX] + 2, 2961H
                                           ; READ DATA FROM RAM ADDR 2 AND 3
                                           ; AND COMPARE WITH VALUE WRITTEN
                 JNE
                          BADRAM
                                           ; IF DATA DOESN'T MATCH, THEN JMP
                 MOV
                          AL, GOOD SIGNAL
                 OUT
                          LATCH, AL
                                           ;SIGNAL THAT DATA WAS CORRECT
                 JMP
                          TST LOOP
BADRAM:
                 MOV
                          AL, BAD_SIGNAL
                 OUT
                          LATCH, AL
                                           ;SIGNAL THAT DATA WAS BAD
                 JMP
                         TST LOOP
                 ORG
                          OFFFOH
                                           ; POSITION THE FOLLOWING INSTRUCTION
                                           ;AT OFFSET OFFFOH
START:
                 JMP
                         TST LOOP
                                           ; INTRA-SEGMENT JUMP (WITHIN
                                           ; SEGMENT)
                                           ;THIS IS INTENDED TO BE THE FIRST
                                           ; INSTRUCTION EXECUTED, SO IT MUST
                                           ; BE LOCATED AT PHYSICAL ADDRESS
                                           ; FFFFFFFOH.
INITIAL CODE
                 ENDS
                 END
```

Figure 11-12. More Complex Diagnostic Program

```
PAGE
                                                           66,132
                                          EQUATES
                                  ;
                                  LATCH
                                                   EOU
                                                           0C8H
= 00C8
                                                           OAAH
= 00AA
                                  GOOD SIGNAL
                                                   EQU
                                                           055H
= 0055
                                  BAD SIGNAL
                                                   EOU
                                  ;
                                          CODE TO VERIFY ABILITY TO WRITE
                                  ;
                                          AND READ RAM CORRECTLY
                                  ;
                                  ;
                                                   ASSUME CS:INITIAL_CODE
                                  INITIAL CODE
                                                   SEGMENT
 0000
 F000
                                                   ORG
                                                            0F000H
                                                            вх, 0000н
 F000 -BB 0000
                                  TST LOOP:
                                                   MOV
                                                   MOV
                                                            DS, BX
 F003
       8E DB
                                                   MOV
                                                            [BX], 5473H
       C7 07 5473
 F005
                                                            [BX]+2, 2961H
       C7 47 02 2961
                                                   MOV
 F009
                                                   JMP
                                                            READ
 F00E
       EB 01 90
                                                   CMP
                                                            [BX], 5473H
                                  READ:
 F011
       81 3F 5473
                                                   JNE
                                                            BADRAM
       75 OD
 F015
                                                            [BX]+2, 2961H
       81 7F 02 2961
                                                   CMP
 F017
                                                   JNE
                                                            BADRAM
       75 06
 F01C
                                                   MOV
                                                            AL, GOOD SIGNAL
       BO AA
 F01E
                                                            LATCH, AL
                                                   OUT
 F020
       E6 C8
                                                            TST_LOOP
                                                   JMP
 F022
       EB DC
                                                   MOV
                                                            AL, BAD SIGNAL
                                  BADRAM:
 F024
       B0 55
                                                            LATCH, AL
 F026
       E6 C8
                                                   OUT
                                                   JMP
                                                            TST_LOOP
 F028
       EB D6
                                                            OFFFOH
 FFF0
                                                   ORG
                                                   JMP
                                                            TST_LOOP
                                  START:
 FFF0
       E9 F000 R
                                  INITIAL_CODE
                                                   ENDS
 FFF3
                                                   END
Warning Severe
Errors Errors
        0
```

Figure 11-13. Object Code for Diagnostic Program



The 80386 stops running only for one of three reasons:

- The READY# signal is never asserted to terminate the bus cycle.
- The HALT instruction is encountered, so the 80386 enters a HALT state.
- The 80386 encounters a shutdown condition. In Real Mode operation (as in the simple diagnostic program), a shutdown usually indicates that the 80386 is reading garbage on the data bus.

If the 80386 stops running, the cause can be determined easily if the system contains simple hardware decoders with associated LEDs to visually indicate halt and shutdown conditions. The 80386 emits specific codes on its W/R#, D/C#, M/IO#, and address outputs to indicate halt or shutdown. A circuit to decode these signals can be tested by executing a HLT instruction (F4H) to see if the halt LED is turned on. The shutdown LED cannot be tested in the same way, but its decoder is so similar to the halt decoder that if the halt decoder works, the shutdown decoder should also work.

If the shutdown LED comes on and the 80386 stops running, the data being read in during code fetch cycles is garbled. The programmer should check the EPROM contents, the wiring of the address path and data path, and the data transceivers. The 4-byte diagnostic program should be used to investigate the system. This program should work before more complex software is used.

If neither the halt LED nor the shutdown LED is on when the 80386 stops running, the READY# generation circuit has not activated READY# to complete the bus cycle. The 80386 is adding wait states to the cycle, waiting for the READY# signal to go active. The address at the address latch outputs and the states of the W/R#, D/C#, and M/IO# signals should be checked to narrow the investigation to a specific part of the READY# generation circuit. Then the circuit should be investigated with the logic analyzer.

Once the basic system is built and debugged, more software and further enhancements can be added to the system. The incremental approach described applies to these additions. Systematic, step-by-step testing and debugging is the surest way to build a reliable 80386-based system.





CHAPTER 12 TEST CAPABILITIES

The 80386 contains built-in features that enhance its testability. These features are derived from signature analysis, and proprietary test techniques. All the regular logic blocks of the 80386, or about half of all its internal devices, can be tested using these built-in features.

The 80386 testability features include aids for both internal and board-level testing. This chapter describes these features.

12.1 INTERNAL TESTS

Allowances have been made for two types of internal tests: automatic self-test and Translation Lookaside Buffer (TLB) tests. The automatic self-test is controlled completely by the 80386. The designer needs only to initiate the test and check the results. The TLB tests must be externally developed and applied. The 80386 provides an interface that makes this test development simple.

12.1.1 Automatic Self-Test

The 80386 can automatically verify the functionality of its three major Programmable Logic Arrays (PLAs) (the Entry Point, Control, and Test PLAs) and the contents of its Control ROM (CROM). The automatic self-test is initiated by setting the BUSY# input active during initialization (as described in Chapter 3). The test result is stored in the EAX register of the 80386.

The self-test progresses as follows (see Figure 12-1):

- 1. Normal PLA or CROM inputs are disabled.
- 2. A pseudo-random count sequence, generated by an internal Linear Feedback Shift register (LFSR), provides all possible combinations of PLA and CROM inputs.
- PLA and CROM outputs for each input combinations are directed to a parallel-load LFSR.
- 4. Through the action of this LFSR, a signature of all output results is accumulated.
- 5. After all input combinations have been sequenced, the final contents of the LFSR are XORed with a signature constant stored in the 80386. If the LFSR contents match the signature constant, the result will be all zeroes, indicating functional PLA and CROM.
- 6. The result is loaded into the EAX register.

The self-test provides 100-percent coverage of single-bit faults, which statistically comprise a high percentage of total faults.






Figure 12-1. 80386 Self-Test

12.1.2 Translation Lookaside Buffer Tests

The on-chip Page Descriptor Cache of the 80386 stores its data in the TLB. (Cache operation is discussed fully in Chapter 7.) The linear-to-physical mapping values for the most recent memory accesses are stored in the TLB, thus allowing fast translation for subsequent accesses to those locations. The TLB consists of:

- Content-addressable memory (CAM)—holds 32 linear addresses (Page Directory and Page Table fields only) and associated tag bits (used for data protection and cache implementation)
- Random access memory (RAM)—holds the 32 physical addresses (upper 20 bits only) that correspond to the linear addresses in the CAM
- Logic-implements the four-way cache and includes a 2-bit replacement pointer that determines to which of the four sets a new entry is directed during a write to the TLB.

To translate a linear address to a physical address, the 83086 tries to match the Page Directory and Page Table fields of the linear address with an entry in the CAM. If a hit (a match) occurs, the corresponding 20 bits of physical address are retrieved from the RAM and added to the 12 bits of the Offset field of the linear address, creating a 32-bit physical address. If a miss (no match) occurs, the 80386 must bring the Page Directory and Page Table values into the TLB from memory.



The 80386 provides an interface through which to test the TLB. Two 32-bit test registers of the 80386 are used to write and read the contents of the TLB through the MOV TREG, reg and MOV reg, TREG instructions. An 80386 program can be used to generate test patterns which are applied to the TLB through automatic test machines or assembly language programs.

The paging mechanism of the 80386 must be disabled during a test of the TLB. The internal response is therefore not identical to that of normal operation, but the main functionality of the TLB can be verified.

Test register #6 is used as the command register for TLB accesses; test register #7 is used as the data register. Addresses and commands are written to the TLB through the command register. Data is read from or written to the TLB through the data register.

The two test operations that may be performed on the TLB are:

- Write the physical address contained in the data register and the linear address and tag bits contained in the command register into a TLB location designed by the data register.
- Look up a TLB entry using the linear address and tag bits contained in the command register. If a hit occurs, copy the corresponding physical address into the data register, and set the value of the hit/miss bit in the data register. If a miss occurs, clear the /hit/miss bit. In this case, the physical address in the data register is undefined.

A command is initiated by writing to the command register. The command register has the format shown in Figure 12-2 (top). The two possible commands are distinguished by the




Figure 12-2. TLB Test Registers



state of bit 0 in the command register. If bit 0 = 1, a TLB lookup operation is performed. If bit 0 = 0, a TLB write is performed.

The tag bits (not including the linear address) consist of the following:

Bit	Name	Definition				
11	Valid (V)	Entry is valid				
10	Dirty (D)	Entry has been changed				
9	Not Dirty (D#)	Entry has not been changed				
8	User (U) ` ´	Entry is accessible to User privilege level				
7	Not User (U#)	Entry is not accessible to User privilege level				
6	Writable (W)	Entry may be changed				
5	Not Writable (W#)	Entry may not be changed				

The complement of the Dirty, User, and Writable bits are provided to force a hit or miss for TLB lookups. A lookup operation with a bit and its complement both low is forced to be a miss; if both bits are high, a hit is forced. A write operation must always be performed with a bit and its complement bit having opposite values.

The data register has the format shown in Figure 12-2 (bottom). The replacement pointer indicates which of the four sets of the TLB is to receive write data. Its value is changed according to a proprietary algorithm after every TLB hit. For testing, a TLB write may use the replacement pointer value that exists in the TLB, or it may use the value in bits 3 and 2 of the data register. If data register bit 4 = 0, the existing replacement pointer is used. If bit 4 = 1, bits 3 and 2 of the data register are used.

The TLB write operation progresses as follows:

- 1. The physical address, replacement bit, and replacement pointer value (optional) are written to the data register.
- 2. The linear address and tag values are written to the command register, as well as a 0 value for bit 0.

It is important not to write the same linear address to more than one TLB entry. Otherwise, hit information returned during a TLB lookup operation is undefined.

The TLB lookup operation progresses as follows:

- The linear address and tag values are written to the command register, as well as a 1 value for bit 0.
- New values for the hit/miss bit and replacement pointer are written to bits 4-2 in the data register. If the hit/miss bit (bit 4) is 1, bits 31-12 contain the physical address from the TLB. Otherwise, bits 31-12 are undefined.



For more information on how to write routines to test the TLB, refer to the 80386 Programmer's Reference Manual.

12.2 BOARD-LEVEL TESTS

For board-level testing, it is often desirable to isolate areas of the board from the interactions of other devices. The 80386 can be forced to a state in which all but two of its pins are effectively removed from their circuits. This state is accomplished through the HOLD and HLDA pins.

When the HOLD input of the 80386 is asserted, the 80386 places all of its outputs except for HLDA in the three-state condition. HLDA is then driven high. The 80386 remains in this condition until HOLD is de-asserted. Note that RESET being asserted takes priority over HOLD requests.

The 80386 completes its current bus cycle before responding to the HOLD input. Detailed information on HOLD/HLDA response is given in Chapter 3.



Appendix Local Bus Control PAL Descriptions

A

t					

APPENDIX A LOCAL BUS CONTROL PAL DESCRIPTIONS

The bus controller is implemented in two PALs. One PAL (called PAL-1) follows the 80386 bus cycles and generates the overall bus cycle timings. The second PAL (PAL-2) generates most of the bus control signals.

The PALs are clocked by CLK2. They could also be clocked by CLK. Using CLK2 has the following advantages over using CLK:

- The skew from clock to command signal is reduced, so higher performance is possible with slower devices.
- The 80386 ADS# and READY# signals can be sampled directly. If CLK were used, it
 would be possible to sample ADSO# from the 82384 instead of ADS#, but the READY#
 generation logic would be more complex because READY# must be synchronized to
 CLK2.
- The PAL can provide delays in 31-nanosecond, rather than 62-nanosecond, increments.

The advantages of using CLK to clock the PALs are as follows:

- A slower PAL device could be used.
- One PAL input is saved because only CLK, rather than CLK and CLK2, is needed.

Because CLK2 is used to clock the PALs, the choice of PALs is currently limited to only 20-pin B-series PALs.

PAL-1 FUNCTIONS

PAL-1 is implemented as two main state machines. The BUSSTATE state machine, which is used to follow the 80386 bus cycles, is specified by the state of two signals, IDLE and PIPE, and follows the 80386 bus by sampling ADS# and READY#. IDLE and PIPE are often useful in implementing other 80386 subsystems (such as the DRAM controller described later in this book).

The LOCALSTATE state machine keeps track of the local bus state and is specified by signals L2, L1, and L0. Although the local bus state usually follows the 80386 bus state, so that the LOCALSTATE and BUSSTATE states are the same, there are times when the local bus cycle lags the 80386 bus cycle in order to handle data-float and peripheral recovery times correctly. Therefore, it is easier to implement this PAL using the two separate state machines. LOCALSTATE uses the 80386 W/R# signal and various chip-select inputs to determine what type of cycle to run.

A third, simpler state machine is also implemented in PAL-1. Q1 and Q0 comprise a SEQUENCE counter that is used to implement the various time delays required by the local bus state machine.



The NA# output of PAL-1 activates address pipelining for the I/O and 1-wait-state devices. For 0-wait-state devices, external logic generates NA#, because these devices require NA# sooner than PAL-1 can generate it.

PAL-2 FUNCTIONS

PAL-2 generates most bus control signals, including all five command signals, the READY# signal, and the latch and transceiver enable signals. PAL-2 inputs the three LOCALSTATE signals from PAL-1 and the three 80386 bus cycle definition pins (MIO#, DC#, and WR#) in order to follow the local bus state. PAL-2 also inputs the 0-wait-state chip-select signal in order to set output signals quickly enough for zero wait states.

Note that the transceiver direction enable (DT/R#) is simply a latched version of W/R#. This saves a PAL output and also guarantees that the transceiver direction does not change while DEN# is enabled.

PAL EQUATIONS

The equations for PAL-1 and PAL-2 are shown in Figures A-1 and A-2, respectively. These equations are shown in a high-level PAL language (ABEL, by Data I/O) that allows the PAL to be described as a series of states rather than equations. This language frees the designer of the tedious task of implementing the state machine and reducing the logical equations manually. The language saves time not only in the initial design, but also in debugging the state machines. The automated term reduction of the high-level PAL language allows the designer to explore many implementations quickly, which is a useful feature for complex PAL designs.

Figures A-3 and A-4 show the PAL equations for PAL-1 and PAL-2 using PALASM by Monolithic Memories.



```
module
           Bus Control 386 Pal 1 flag '-r3'
title
'80386 Local Bus Controller - pal 1
                                        Intel Corp'
    BC386P1
                device 'P16R8':
                                          "use a 16R8 B-speed PAL for 16MHz 386
" Constants:
    ON
                       1;
    OFF
                       0:
   н
                       1:
    L
                       0;
                       .x.;
                                          " ABEL 'don't care' symbol
                       .c.;
                                          " ABEL 'clocking input' symbol
" State definitions for BUSSTATE (bus cycle state):
    IDLEBUS
                       ^b01;
                                      "bus is idle or first CLK of unpipelined
                                     "first CLK of pipelined cycle
    PUPERIIS
                =
                       ^b10;
                                     "subsequent CLKs of active bus
    ACTIVEBUS
               =
                       ^b00;
    ILLEGALBUS =
                       ^bl1;
                                     "unused
" State definitions for LOCALSTATE (local cycle state):
    WAITING
                       ^bl01;
                                      "waiting for next bus cycle
    SAMPLECS
                       ^b100;
                                      "CLK2 before ALE falls and CS is sampled
    CMDDELAY
                       ^b000;
                                      "delay before CMD active
                                      "IO CMD active
                       ^b010;
    TΟ
    ENDIO
                                     "IO CMD inactive
                =
                       ^bll0;
    MEMORY
                =
                       ^b011;
                                      "1WS CMD active
    FLOAT
                       ^bll1;
                                      "data bus float delay
    NOTLOCAL
                       ^b001;
                                      "OWS cycle or bus cycle not to the local bus
" State definitions for SEQUENCE (local cycle sequence counter):
    SEQ0
                       ^b00;
    SEQ1
                =
                       ^b01;
    SEQ2
                       ^b11;
                       ^b10;
    SEO3
" Pin names:
                             " Input pins
    CLK
                pin
                       2;
                                  " 82384 CLK
                                 " 80386 ADS#
                pin
    ADS
                       3;
                                 " 80386 READY#
    READY
                pin
                       4;
                                 " 80386 W/R#
                       5;
    WR
                pin
                                 " chip-select for 0 wait-state (piped) devices
    CSOWS
                pin
                       6;
    CSIWS
                pin
                                 " chip-select for 1 wait-state (piped) devices
                       7;
                                 " chip-select for peripheral devices
    CSIO
                pin
                       8;
    RESET
                pin
                       9;
                                 " 80386/82384 RESET
    CLK2
                pin
                             " Clock pin - 82384 CLK2
                       1;
                             " Output Enable pin
    ΟE
                pin
                       11;
                             " Output pins
                pin
    NA
                       19;
                                 " NEXT ADDRESS (NA) for 1WS and IO devices
                                 " bus state: IDLE or first CLK of unpiped cycle
    IDLE
                pin
                       18;
    PIPE
                pin
                       17;
                                 " bus state: first CLK of pipelined cycle
                pin
                       16;
                                 " local cycle state
    L2
                       15;
                                 " local cycle state
    Ll
                pin
    LO
                pin
                       14;
                                 " local cycle state
                                 " local cycle sequence counter
    Ql
                pin
                       13;
                                 " local cycle sequence counter
    Q0
                pin
                       12;
    BUSSTATE
                       [PIPE, IDLE];
                                          " bus cycle state
                       [L2, L1, L0];
[Q1, Q0];
    LOCALSTATE
               =
                                          " local cycle state
    SEQUENCE
                                          " local cycle sequence counter
```

Figure A-1. PAL-1 State Listings



```
" Macros:
   COUNTING
               macro
       { (Q1 # Q0) };
                             " true until sequencer counts down to zero
   LOWCOUNTING macro
                              " true until sequencer counts down to zero
       { (
               Q0) };
                                 same as COUNTING except used to reduce PAL
                                " terms and only works if count less than 3
state_diagram BUSSTATE
  state IDLEBUS:
                                      "bus is idle or first CLK of unpipelined
                                         "reset to IDLEBUS
   if RESET then IDLEBUS
     else if !CLK # ADS then IDLEBUS
                                         "remain til sample ADS active
                                         "...then go ACTIVE
                        else ACTIVEBUS;
  state ACTIVEBUS:
                                      "subsequent CLKs of active bus
                                         "reset to IDLEBUS
   if RESET then IDLEBUS
     else if !CLK # READY then ACTIVEBUS
                                        "remain til sample READY active
       else if !ADS then PIPEBUS .
                                         "...then next cycle either piped
                    else IDLEBUS;
                                         "...or idle
  state PIPEBUS:
                                      "first CLK of pipelined cycle
    if RESET then IDLEBUS
                                         "reset to IDLEBUS
                                          "remain for just one CLK
"...then go ACTIVE
     else if !CLK then PIPEBUS
                 else ACTIVEBUS;
                                        "unused state - should never occur
   state ILLEGALBUS:
                                           "if entered upon power-up...go IDLE
     goto IDLEBUS;
 state diagram LOCALSTATE
                                        "waiting for next bus cycle
   state WAITING:
     NA
          := OFF;
     if RESET then WAITING
                                           "reset to WAITING
      else if !CLK
#( ADS & IDLE)
                                                 "remain while idle bus
            #(!CSIO & LOWCOUNTING) then WAITING "..and remain for recovery time
                                   else SAMPLECS; ".. else begin bus cycle
   state SAMPLECS:
                                        "CLK2 before ALE falls and CS is sampled
     NA := OFF;
     if RESET then WAITING
                                           "reset to WAITING
       else if !CS1WS then MEMORY
                                           "start 1WS access
         else if !CSIO then CMDDELAY
                                           "start IO access
                       else NOTLOCAL:
                                           "start non-local access
   state CMDDELAY:
                                        "delay before CMD active
         := OFF:
     if RESET then WAITING
                                           "reset to WAITING
              else IO;
                                           "only in state for 1 CLK2, then IO
   state IO:
                                        "TO CMD active
     NA := (!COUNTING & CLK) # NA; if RESET then WAITING
                                           "activate NA after count down to zero
                                           "reset to WAITING
       else if !NA then IO
                                           "remain until NA active
                   else ENDIO;
                                           "...then ENDIO
                                        "IO CMD active
   state ENDIO:
     NA
         := OFF;
     if RESET then WAITING
                                           "reset to WAITING
     else if LOWCOUNTING then ENDIO
                                           "remain while COUNTING down
                                           "...then FLOAT
                        else FLOAT;
```

Figure A-1. PAL-1 State Listings (Cont'd.)



```
state MEMORY:
                                             "IWS CMD active
    NA := (!NA & CLK) # (NA & !CLK);
                                                 "activate NA on second and third CLK2
    if RESET then WAITING
                                                 "reset to WAITING
      else if LOWCOUNTING then MEMORY
                                                 "remain while COUNTING down
                                                 "...then FLOAT
                             else FLOAT;
  state FLOAT:
                                             "data bus float delay
    NΔ
         := OFF:
    if RESET then WAITING
      RESET then WAITING "reset to WAITING else if !IDLE & !CLK & CSOWS & CSIWS & CSIO then NOTLOCAL
                                              "watch for non-local bus cycle to start
        else if COUNTING then FLOAT
                                                 "...else remain while COUNTING down
                            else WAITING;
                                                 "...then WAIT
  state NOTLOCAL:
                                        "OWS cycle or bus cycle not to the local bus
    NA := OFF;
    if RESET then WAITING
                                                 "reset to WAITING
      else if READY # !CLK then NOTLOCAL
                                                "remain until bus cycle ends
                                              "...then finish FLOAT if still COUNTING
         else if COUNTING then FLOAT
           else if !ADS then SAMPLECS
                                                "...else SAMPLECS if next bus piped
                          else WAITING;
                                                 "...else WAIT
"counter for LOCALSTATE
state diagram SEQUENCE
  state SEQ3:
    if RESET then SEQ0
                                                 "reset to SEQuence 0
      else if !CLK then SEO3
                                                 "no change if CLK low
                                                 "count down every time CLK high
                     else SEO2:
  state SEQ2:
    if RESET then SEOO
      else if !CLK then SEQ2
                     else SEQ1;
  state SEQ1:
    if RESET then SEQ0
      else if !CLK then SEQ1
                     else SECO:
  state SEQ0:
                  "once count all the way down, figure out what to count next
                                                       : SEQ0; "reset to SEQuence 0 : SEQ0; "count not used
       RESET
       !RESET & (LOCALSTATE == WAITING)
      RESET & (LOCALSTATE == SAMPLECS) & !CS1WS : SEQ2; "set up for lWS MEMORY !RESET & (LOCALSTATE == SAMPLECS) & CS1WS : SEQ0; "other than lWS MEMORY !RESET & (LOCALSTATE == CMDDELAY) & WR : SEQ3; "set up for IO write
      RESET & (LOCALSTATE == CMDDELAY) & !WR
!RESET & (LOCALSTATE == IO) & !NA
                                                       : SEQ2; "set up for IO read
: SEQ0; "still in IO...remain
                                                     : SEQ1; "set up for ENDIO
       !RESET & (LOCALSTATE == IO)
                                            & NA
       !RESET & (LOCALSTATE == ENDIO)
                                                       : SEQ3; "set up for IO float
       !RESET & (LOCALSTATE == MEMORY)
                                                       : SEO1; "set up for 1WS MEMORY
      !RESET & (LOCALSTATE == FLOAT)
!RESET & (LOCALSTATE == NOTLOCAL)
                                                       : SEQ1; "set up for IO recovery : SEQ0; "count not used
    endcase:
```

Figure A-1. PAL-1 State Listings (Cont'd.)



```
( [CLK2, CLK, RESET, ADS, READY, WR, CSOWS, CS1WS, CSIO] ->
                    [LOCALSTATE, NA] )
            "[inputs] -> [outputs]
"C C
                  C C C
"L L
      E
         DE
               R
                  SSS
"K K
                             LOCALSTATE
      S
         SA
                  0 1 T
"2
                  WWO
      E
            D
      т
            Y
                  SS
[c,x, H, x,x, x, x,x,x,] -> [ WAITING, L];"initialize to IDLE and WAITING state [c,L, L, H,H, x, x,x,x] -> [ WAITING, L];
[c,H, L, H,H, x, x,x,x] \rightarrow
                              [ WAITING, L];
[c,L, L, x,H, x, x,x,x] \rightarrow
                              [ WAITING, L];
                              [SAMPLECS, L]; "100nS SRAM read
[c,H, L, L,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L]; "NA: activated externally
[c,L, L, x,H, L, L,H,H] ->
[C,H, L, H,H, x, x,x,x] ->
                              [NOTLOCAL, L];
                              [NOTLOCAL, L];
[c,L, L, x,L, x, x,x,x] ->
[c,H, L, L,L, x, x,x,x] \rightarrow
                              [SAMPLECS, L];"100nS SRAM read
                              [NOTLOCAL, L]; "NA: activated externally
[c,L, L, x,H, L, L,H,H] ->
[c,H, L, H,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
                              [NOTLOCAL, L];
[c,L, L, x,L, x, x,x,x] \rightarrow
                              [SAMPLECS, L];"100nS SRAM write
[C,H, L, L,L, x, x,x,x] \rightarrow
[c,L, L, x,H, H, L,H,H] ->
                              [NOTLOCAL, L]; "NA: activated externally
                              [NOTLOCAL, L];
[c,H, L, H,H, x, x,x,x] \rightarrow
[c,L, L, x,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
[C,H, L, x,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
                              [NOTLOCAL, L];
[c,L, L, x,L, x, x,x,x] \rightarrow
                              [SAMPLECS, L];"100nS SRAM read
[c,H, L, L,L, x, x,x,x] \rightarrow
                              [NOTLOCAL, L]; "NA: activated externally
[C,L, L, x,H, L, L,H,H] ->
[c,H, L, H,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
[c,L, L, x,L, x, x,x,x] -> [NOTLOCAL, L];
                              [SAMPLECS, L]; "non-local
[c,H, L, L,L, x, x,x,x] ->
[c,L, L, x,H, x, H,H,H] -> [NOTLOCAL, L];
[c,H, L, H,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
[c,L, L, x,L, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
                              [SAMPLECS, L];"100nS SRAM read
[C,H, L, L,L, x, x,x,x] \rightarrow
[C,L, L, x,H, x, L,H,H] ->
                              [NOTLOCAL, L]; "NA: activated externally
                              [NOTLOCAL, L];
[c,H, L, H,H, x, x,x,x] ->
[c,L, L, H,L, x, x,x,x] -> [NOTLOCAL, L];
[c,H, L, H,L, x, x,x,x] -> [ WAITING, L];"idle
[c,L, L, H,H, x, x,x,x] ->
                                WAITING, Lj;
                              Γ
                                WAITING,
[c,H, L, H,H, x, x,x,x] ->
                                          L];
[c,L, L, x,H, x, x,x,x] ->
                                WAITING, L];
[C,H, L, L,H, x, x,x,x] -> [SAMPLECS, L];"100nS SRAM write
[c,L, L, x,H, H, L,H,H] ->
                              [NOTLOCAL, L]; "NA: activated externally
[c,H, L, H,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
[c,L, L, x,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
                              [NOTLOCAL, L];
[c,H, L, H,H, x, x,x,x] \rightarrow
                              [NOTLOCAL, L];
[c,L, L, x,L, x, x,x,x] \rightarrow
[c,H, L, H,L, x, x,x,x] -> [ WAITING, L];"idle
[c,L, L, H,H, x, x,x,x] -> [ WAITING, L];
                                WAITING, L];
[c,H, L, H,H, x, x,x,x] -> [
[c,L, L, x,H, x, x,x,x] \rightarrow
                                WAITING, L];
[c,H, L, L,H, x, x,x,x] -> [SAMPLECS, L];"150nS ROM read
[c,L, L, x,H, L, H,L,H] ->
                              ]
                                MEMORY , L];
[c,H, L, H,H, x, x,x,x,] -> [c,L, L, H,H, x, x,x,x] -> [
                                MEMORY , H];
                                MEMORY , H];
                                MEMORY ,
[c,L, L, x,L, x, x,x,x] \rightarrow
                                 FLOAT , L];
[C,H,L,L,L,x,x,x,x] \rightarrow
                                 FLOAT
                                          Lj;
                                WAITING, L];
[C,L, L, x,H, x, L,x,x] ->
                              [SAMPLECS, L];"100nS SRAM read
[c,H, L, H,H, x, x,x,H] ->
[C,L, L, x,H, L, L,H,H] ->
                              [NOTLOCAL, L]; "NA: activated externally
[C,H, L, x,H, x, x,x,x] -> [NOTLOCAL, L];
```

Figure A-1. PAL-1 State Listings (Cont'd.)



```
[c,L, L, x,L, x, x,x,x] -> [NOTLOCAL, L];
                                [SAMPLECS, L];"150nS ROM read
[c,H, L, L,L, x, x,x,x] \rightarrow
[c,L, L, x,H, L, H,L,H] ->
                                  MEMORY , L];
                                  MEMORY , H];
[c,H, L, H,H, x, x,x,x] \rightarrow
[c,L, L, H,H, x, x,x,x] \rightarrow
                                  MEMORY , H];
                                  MEMORY ,
[C,H, L, H,H, x, x,x,x]
                            ->
                                             L];
[c,L, L, x,L, x, x,x,x] \rightarrow
                                   FLOAT
                                             L1:
[c,H, L, L,L, x, x,x,x] \rightarrow
                                   FLOAT
                                             L];
[c,L, L, x,H, x, x,L,x]
                                  WAITING,
                           ->
                                             L];
                                [SAMPLECS, L];"150nS SRAM write
[C,H, L, H,H, x, x,x,H] ->
                                  MEMORY , L];
[C,L, L, H,H, H, H,L,H]
                            ->
[c,H, L, H,H, x, x,x,x] \rightarrow
                                  MEMORY , H];
[c,L, L, H,H, x, x,x,x] ->
                                  MEMORY ,
                                            H];
[C,H, L, H,H, x, x,x,x] \rightarrow
                                Γ
                                  MEMORY
[c,L, L, x,L, x, x,x,x] \rightarrow
                                   FLOAT
                                             Ŀj;
                                             L];
[C,H, L, L,L, x, x,x,x] \rightarrow
                                   FLOAT
                                  WAITING, L];
[c,L, L, x,H, x, x,L,x] ->
[C,H, L, H,H, x, x,x,H] -> [SAMPLECS, L];"150nS SRAM read
                                  MEMORY ,
                                            Ŀj;
[C,L, L, H,H, L, H,L,H] ->
[C,H, L, H,H, x, x,x,x] \rightarrow
                                  MEMORY , H];
                                  MEMORY ,
[c,L, L, H,H, x, x,x,x] ->
                                            Ηj;
[c,H, L, H,H, x, x,x,x] \rightarrow
                                  MEMORY ,
                                             L];
                                   FLOAT ,
[c,L, L, H,L, x, x,x,x] ->
                                             Lj;
                                  FLOAT , L];
WAITING, L];"idle
[c,H, L, H,L, x, x,x,x] ->
[c,L, L, H,H, x, x,x,x] ->
                                  WAITING, L];
[c,H, L, H,H, x, x,x,x] \rightarrow
[C,L, L, x,H, x, x,x,x] \rightarrow
                                  WAITING, L);
[C,H, L, L,H, x, x,x,x] ->
                                [SAMPLECS, L];"150nS SRAM read
                                  MEMORY , L];
[c,L, L, x,H, L, H,L,H] \rightarrow
[c,H, L, H,H, x, x,x,x] ->
                                  MEMORY , H];
                                  MEMORY , H];
[c,L, L, x,H, x, x,x,x] \rightarrow
[c,H, L, L,H, x, x,x,x] ->
                                  MEMORY , L];
                                   FLOAT , L];
[c,L, L, L,L, x, x,x,x] ->
[c,H, L, H,L, x, x,x,x] \rightarrow
                                   FLOAT
                                          , L];
[c,L, L, H,H, x, x,x,x] \rightarrow
                                  WAITING, L]; "idle
[C,H, L, H,H, x, x,x,x] \rightarrow [WAITING, L];
[c,L, L, x,H, x, x,x,x] \rightarrow [WAITING, L];
                                [SAMPLECS, L]; "peripheral read
[c,H, L, L,H, x, x,x,x] \rightarrow
                L, H,H,L] ->
[C,L, L, x,H,
                                [CMDDELAY, L];
[c,H, L, H,H, L, x,x,x] ->
                                          , L];
                                     IO
[c,L, L, H,H, x, x,x,x] \rightarrow
                                     IO
                                          , L];
                                           , Lj;
[c,H, L, H,H, x, x,x,x] \rightarrow
                                     IO
[c,L, L, H,H, x, x,x,x] ->
                                           , Lj;
                                     IO
[c,H, L, H,H, x, x,x,x] \rightarrow
                                     TΩ
                                             Lj;
                                             L];
[c,L, L, H,H, x, x,x,x] ->
                                     IO
                                           , нј;
[c,H, L, H,H, x, x,x,x] \rightarrow
                                     IO
[c,L, L, H,H, x, x,x,x] ->
                                  ENDIO
                                           , нј;
[c,H, L, H,H, x, x,x,x] \rightarrow
                                  ENDIO
                                           , Ľj;
[c,L, L, x,L, x, x,x,x] \rightarrow
                                  FLOAT
                                           , L];
[c,H, L, L,L, x, x,x,x] ->
                                  FLOAT
                                           , L];
[c,L, L, x,H, x, x,x,L] \rightarrow
                                           , Lj;
                                  FLOAT
[c,H, L, H,H, x, x,x,x] ->
                                  FLOAT
                                            L];
[c,L, L, H,H, x, x,x,L] ->
                                  FLOAT
                                             L];
[c,H, L, H,H, x, x,x,x] \rightarrow
                                  FLOAT
                                             Lj;
[C,L, L, H,H, x, x,x,L] ->
                                WAITING
                                             L];
[c,H, L, H,H, x, x,x,L] \rightarrow
                                WAITING
                                             L];
                                [WAITING
[c,L, L, H,H, x, x,x,L] \rightarrow
                                             Lj;
[C,H, L, H,H, x, x,x,x] \rightarrow
                                [SAMPLECS, L]; "peripheral read
[c,L, L, H,H, L, H,H,L] ->
                                [CMDDELAY, L];
[c,H, L, H,H, L, x,x,x] ->
                                    TO
                                             L];
[c,L, L, H,H, x, x,x,x] \rightarrow
                                             L];
                                     IO
[C,H, L, H,H, x, x,x,x] \rightarrow
                                     IO
                                           , L];
[c,L, L, H,H, x, x,x,x] -> [c,H, L, H,H, x, x,x,x] -> [c,L, L, H,H, x, x,x,x] -> [
                                     IO
                                           , L];
                                           , Lj;
                                     IO
                                     IO
                                             L];
```

Figure A-1. PAL-1 State Listings (Cont'd.)



```
[c,H, L, H,H, x, x,x,x] \rightarrow [
                                                IO
[c,L, L, H,H, x, x,x,x] ->
                                                        , нј;
                                             ENDIO
                                          Ī
[c,H, L, H,H, x, x,x,x] -> [
[c,L, L, x,L, x, x,x,x] -> [
                                                           Lj;
                                             ENDIO
                                             FLOAT
                                                           Lj;
[c,H, L, L,L, x, x,x,x] -> [ FLOAT [c,L, L, x,H, x, L,x,x] -> [ FLOAT [c,H, L, H,H, x, x,x,x] -> [ FLOAT [c,H, L, H,H, x, x,x,x] -> [ FLOAT
                                                         , L];
                                                         , Lj;
                                                           L];
[C,L, L, H,H, x, L,x,x] -> [ FLOAT [C,H, L, H,H, x, x,x,x] -> [ FLOAT
                                                           L];
                                                           Lj;
[c,L, L, H,H, x, L,x,x] -> [WAITING ,
                                                           Lj;
                                          [SAMPLECS, L];"100ns SRAM read
[NOTLOCAL, L];"NA: activated externally
[c,H, L, H,H, x, x,x,H] ->
[c,L, L, H,H, L, L,H,H] ->
[c,H, L, H,H, x, x,x,x] \rightarrow
                                          [NOTLOCAL,
                                                           L);
                                                           L];
[c,L, L, x,L, x, x,x,x] \rightarrow
                                          [NOTLOCAL,
[c,H, L, L,L, x, x,x,x] \rightarrow
                                          [SAMPLECS, L]; "peripheral write
[c,L, L, x,H, H, H,H,L] ->
[c,H, L, H,H, H, x,x,x] ->
                                          [CMDDELAY, L];
                                                 IO
                                                           L];
                                                         , Lj;
[c,L, L, H,H, x, x,x,x] ->
                                                 IO
[c,H, L, H,H, x, x,x,x] ->
                                                 IO
                                                           Li;
 [c,L, L, H,H, x, x,x,x] -> [c,H, L, H,H, x, x,x,x] -> [
                                                 IO
                                                           L);
                                                 IO
                                                           L];
                                                 IO
                                                           L];
                                                         , Lj;
 [c,H, L, H,H, x, x,x,x] ->
                                                 ΙO
 [C,L, L, H,H, x, x,x,x] ->
[C,H, L, H,H, x, x,x,x] ->
                                                 IO
                                                           Lj;
                                                         , нј;
                                                 IO
[c,L, L, H,H, x, x,x,x] -> [ ENDIO
[c,H, L, H,H, x, x,x,x] -> [ ENDIO
[c,L, L, x,L, x, x,x,x] -> [ FLOAT
[c,H, L, x,L, x, x,x,x] -> [ FLOAT
                                                         , H];
                                                         , Lj;
                                                         , L1;
end Bus Control 386 Pal 1;
```

Figure A-1. PAL-1 State Listings (Cont'd.)



```
module
           Bus Control 386 Pal 2 flag '-r3'
title
'80386 Local Bus Controller - pal 2
                                        Intel Corp!
    BC386P2
                device 'P16R8':
                                         "use a 16R8 B-speed PAL for 16MHz 386
" Constants:
    ON
                      1;
    OFF
                      0;
    н
                =
                      1;
    L
                =
                      0;
                                         " ABEL 'don't care' symbol
    x
    c
                       .c.;
                                         " ABEL 'clocking input' symbol
" State definitions for LOCALSTATE (local cycle state):
    WAITING
                      ^b101;
                                     "waiting for next bus cycle
    SAMPLECS
                =
                      ^b100;
                                     "CLK2 before ALE falls and CS is sampled
    CMDDELAY
                =
                      ^b000;
                                     "delay before CMD active
    IO
                =
                      ^b010;
                                     "IO CMD active
                                     "IO CMD inactive
    ENDIO
                      ^bl10;
                                     "lWS CMD active
    MEMORY
                      ^b011;
                =
    FLOAT
                      ^bll1;
                                     "data bus float delay
    NOTLOCAL
                      ^b001;
                                    "OWS cycle or bus cycle not to the local bus
" Pin names:
                             " Input pins
    CLK
                pin
                      2;
                                 " 82384 CLK
    MIO
                                 " 80386 M/IO#
                pin
                      3;
                pin
                                 " 80386 D/C#
    DC
                       4:
    WR
                                 " 80386 W/R#
                pin
                      5;
    L0
                pin
                       6;
                                 " local cycle state (from PAL 1)
    Ll
                pin
                      7;
                                 " local cycle state (from PAL 1)
    T.2
                pin
                      8;
                                 " local cycle state (from PAL 1)
    CSOWS
                pin
                      9;
                                 " chip-select for 0 wait-state (piped) devices
    CLK2
                pin
                             " Clock pin - 82384 CLK2
                      1:
                             " Output Enable pin
    OE
                pin
                       11:
                             " Output pins
    MRDC
                pin
                      19:
                                  Memory Read Control signal
                                 " Memory Write Control signal
    MWTC
                pin
                      18;
    IORC
                       17;
                                 " I/O
                                          Read Control signal
                pin
                                 " Ï/O
    IOWC
                pin
                      16;
                                          Write Control signal
    INTA
                      15;
                                 " Interrupt Acknowledge Control signal
                pin
                                 " Address Latch Enable
    ALE
                pin
                      14;
                                                           Control signal
                                 " Data Transceiver Enable Control signal
    DEN
                pin
                      13;
    RDY
                pin
                                 " READY signal
                      12;
    LOCALSTATE =
                      [L2, L1, L0];
                                         " local cycle state
" Macros:
    ifMEMORYREAD macro
        & OIM ) }
                        !WR) }; " true for memory data or code read
    ifMEMORYWRITE macro
        { ( MIO & DC & WR) }; " true for memory data write
    ifIOREAD macro
        { (!MIO & DC & !WR) }; " true for I/O data read
    ifIOWRITE macro
        { (!MIO & DC & WR) }; " true for I/O data write
    ifINTACK macro
        { (!MIO & !DC & !WR) }; " true for interrupt acknowledge cycle
```

Figure A-2. PAL-2 State Listings



```
equations
!MRDC :=
    ((LOCALSTATE==WAITING)
                            & OFF)
   #((LOCALSTATE==SAMPLECS) & ifMEMORYREAD & !CSOWS)
                                                         "activate if OWS access
   #((LOCALSTATE==CMDDELAY) & OFF)
   #((LOCALSTATE==IO)
                            & ((ifMEMORYREAD & DEN) # !MRDC))
                                                                 "activate if IO
                                                                "remain if IO
   #((LOCALSTATE==ENDIO)
                            & ((ifMEMORYREAD
                                              & DEN)
                                                      # !MRDC))
   #((LOCALSTATE==MEMORY)
                                              & DEN) # !MRDC))
                                                                 "activate 1WS
                            & ((ifMEMORYREAD
   #((LOCALSTATE==FLOAT)
                            & OFF)
   #((LOCALSTATE==NOTLOCAL) & (!MRDC
                                                                 "remain if OWS
                                          & (RDY # !CLK)));
!MWTC :=
   ((LOCALSTATE==WAITING)
                          & OFF)
  #((LOCALSTATE==SAMPLECS) & ifMEMORYWRITE & !CSOWS)
  #((LOCALSTATE==CMDDELAY) & OFF)
  #((LOCALSTATE==IO)
                           & ((ifMEMORYWRITE & DEN) # (!MWTC & RDY)))
  #((LOCALSTATE==ENDIO)
                           & ((ifMEMORYWRITE & DEN) # (!MWTC & RDY)))
                           & ((ifMEMORYWRITE & DEN) # !MWTC))
  #((LOCALSTATE==MEMORY)
  #((LOCALSTATE==FLOAT)
                           & OFF)
  #((LOCALSTATE==NOTLOCAL) & (!MWTC
                                          & RDY));
!IORC :=
   ((LOCALSTATE==WAITING)
                          & OFF)
  #((LOCALSTATE==SAMPLECS) & ifIOREAD
                                           & !CSOWS)
  #((LOCALSTATE==CMDDELAY) & OFF)
  #((LOCALSTATE==IO)
                                             & DEN) # !IORC))
                           & ((ifIOREAD
                           & ((ifIOREAD
& ((ifIOREAD
                                             & DEN) # !IORC))
  #((LOCALSTATE==ENDIO)
  #((LOCALSTATE==MEMORY)
                                             & DEN) # !IORC))
   ((LOCALSTATE==FLOAT)
                           & OFF)
  #((LOCALSTATE==NOTLOCAL) & (!IORC
                                         & (RDY # !CLK)));
!IOWC :=
   ((LOCALSTATE==WAITING) & OFF)
  #((LOCALSTATE==SAMPLECS) & ifIOWRITE
                                            & !CSOWS)
  #((LOCALSTATE==CMDDELAY) & OFF)
                           & ((ifIOWRITE
                                             & DEN) # (!IOWC & RDY)))
& DEN) # (!IOWC & RDY)))
  #((LOCALSTATE==IO)
  #((LOCALSTATE==ENDIO)
                           & ((ifIOWRITE
  #((LOCALSTATE==MEMORY)
                                              & DEN) # !IOWC))
                           & ((ifIOWRITE
  #((LOCALSTATE==FLOAT)
                           & OFF)
  #((LOCALSTATE==NOTLOCAL) & (!IOWC
                                           & RDY));
!INTA :=
   ((LOCALSTATE==WAITING)
                          & OFF)
  #((LOCALSTATE==SAMPLECS) & ifINTACK
                                            & !CSOWS)
  #((LOCALSTATE==CMDDELAY) & OFF)
  #((LOCALSTATE==IO)
                           & ((ifINTACK
                                              & DEN) # !INTA))
                           & ((ifINTACK
  #((LOCALSTATE==ENDIO)
                                              & DEN) # !INTA))
                           & ((ifINTACK
  #((LOCALSTATE==MEMORY)
                                              & DEN) # !INTA))
  #((LOCALSTATE==FLOAT)
                           & OFF)
  #((LOCALSTATE==NOTLOCAL) & (!INTA
                                         & (RDY # !CLK)));
   ((LOCALSTATE==WAITING) & ON)
                                           "activate ALE while waiting
  #((LOCALSTATE==SAMPLECS) & OFF)
  #((LOCALSTATE==CMDDELAY) & OFF)
  #((LOCALSTATE==IO)
                           & OFF)
  #((LOCALSTATE==ENDIO)
                           & OFF)
  #((LOCALSTATE==MEMORY)
                           & OFF)
  #((LOCALSTATE==FLOAT)
                           & OFF)
  #((LOCALSTATE==NOTLOCAL) & ((DEN & CSOWS)
                                                "activate ALE if not-local
                                                "if active...remain active
                          #(!RDY & CLK))); "activate if last CLK2 of OWS access
```

Figure A-2. PAL-2 State Listings (Cont'd.)



```
!DEN :=
   ((LOCALSTATE==WAITING)
                               & OFF)
  #((LOCALSTATE==SAMPLECS) & OFF)
  #((LOCALSTATE==CMDDELAY) & OFF)
  #((LOCALSTATE==IO)
                               & ON)
                                                 "activate DEN while in IO
  #((LOCALSTATE==ENDIO)
                               & ON)
                                                 "activate DEN while in IO
  # ((LOCALSTATE==MEMORY)
                               (NO &
                                                "activate DEN while in 1WS access
  #((LOCALSTATE==FLOAT) & (!MWTC # !IOWC)) "remain active 1 CLK2 if write #((LOCALSTATE==NOTLOCAL) & ((!ALE & !CSOWS) "activate DEN if OWS access
                                                     "if active...remain active
                                    !DEN)
                               & (RDY # !CLK));
                                                      "...until last CLK2 of OWS access
!RDY :=
   ((LOCALSTATE==WAITING)
  #((LOCALSTATE==SAMPLECS) & OFF)
  #((LOCALSTATE==CMDDELAY) & OFF)
  #((LOCALSTATE==IO)
                              & OFF)
  #((LOCALSTATE==ENDIO)
                              & ON)
                                                "activate RDY at end of IO
                              & ((RDY & !DEN & CLK) # (!RDY & !CLK)))
  #((LOCALSTATE==MEMORY)
                                              "activate RDY at end of 1WS access
  #((LOCALSTATE==FLOAT)
                              & OFF)
  #((LOCALSTATE==NOTLOCAL) & ( ( RDY & CLK & ( (!MRDC # !IORC # !INTA)
                                                      #((!MWTC # !IOWC) & !DEN)))
                                  #(!RDY & !CLK)));
"activate RDY at end of OWS access
test vectors
                  ( [CLK2, CLK, LOCALSTATE, MIO, DC, WR, CSOWS] ->
                    [MRDC, MWTC, IORC, IOWC, INTA, ALE, DEN, RDY] )
            "[inputs] -> [outputs]
"C C
                  M D W C
                                  MMIII
                                              ADR
"Τ. Т.
                  I C R S
                                  RWOON
                                              LED
"K K LOCALSTATE O
                          0
                                  DTRWT
                                              ENY
"2
                          W
                                  CCCCA
[C,L,
               , x,x,x, x] -> [x,x,x,x,x, x,x,x]; "initialize to IDLE and WAITING
ίc,Η,
               , x,x,x, x] \rightarrow [x,x,x,x,x, x,x,x];
           х
[C,L,
           х
               , x,x,x, x] \rightarrow [x,x,x,x,x, x,x,x];
[c,H,
               , x,x,x, x] \rightarrow [x,x,x,x,x, x,x,x];
[C, L,
           х
               , x, x, x, x] \rightarrow [x, x, x, x, x, x, x, x];
[c,H,
               , x, x, x, x] \rightarrow [x, x, x, x, x, x, x, x];
           х
               , x,x,x, x] \rightarrow [x,x,x,x,x, x,x,x];
[c,L,
           x
[C,H,
           x
                , x, x, x, x] \rightarrow [x, x, x, x, x, x, x, x];
      WAITING, x, x, x, x -> [H,H,H,H,H, H,H,H];
[C,L,
[C,H,
       WAITING, x,x,x,x \rightarrow [H,H,H,H,H,H,H,H];
[C,L,
       WAITING, x,x,x,x \rightarrow [H,H,H,H,H,H,H,H];
[c,H,
       WAITING, x,x,x,x] -> [H,H,H,H,H,H,H,H];"100nS SRAM read
[c,L, SAMPLECS, H,L,L, L] \rightarrow [L,H,H,H,H, L,H,H]; [c,H, NOTLOCAL, x,x,x, L] \rightarrow [L,H,H,H,H, L,L,L];
[c,L, NOTLOCAL, x,x,x,x] -> [L,H,H,H,H, L,L,L];
[c,H, NOTLOCAL, x,x,x, x] -> [H,H,H,H,H, H,H,H];"100nS SRAM read [c,L, SAMPLECS, H,H,L, L] -> [L,H,H,H,H, L,H,H];
[c,H, NOTLOCAL, x,x,x, L] -> [L,H,H,H,H, L,L,L];
[c,L, NOTLOCAL, x,x,x,x] -> [L,H,H,H,H, L,L,L];
[c,H, NOTLOCAL, x,x,x, x] -> [H,H,H,H,H,H,H,H];"100nS SRAM write
[c,L, SAMPLECS, H,H,H, L] -> [H,L,H,H,H, L,H,H]; [c,H, NOTLOCAL, x,x,x, L] -> [H,L,H,H,H, L,L,H];
[c,L, NOTLOCAL, x,x,x, x] \rightarrow [H,L,H,H,H,L,L,H];
```

Figure A-2. PAL-2 State Listings (Cont'd.)



```
[c,H, NOTLOCAL, x,x,x,x] -> [H,L,H,H,H, L,L,L];
[c,L, NOTLOCAL, x,x,x, x] -> [H,H,H,H,H, L,L,L];
[c,H, NOTLOCAL, x,x,x, x] -> [H,H,H,H,H, H,H,H];"100ns SRAM read
[c,L, SAMPLECS, H,H,L, L] -> [L,H,H,H,H, L,H,H];
[c,H, NOTLOCAL, x,x,x, L] -> [L,H,H,H,H, L,L,L];
[c,L, NOTLOCAL, x,x,x,x] ->
                                   [L,H,H,H,H, L,L,L];
[c,H, NOTLOCAL, x,x,x,x] -> [H,H,H,H,H,H,H,H];"non-local
                                   [H,H,H,H,H, L,H,H];
[c,L, SAMPLECS, x,x,x, H] \rightarrow
[c,H, NOTLOCAL, x,x,x, H] -> [H,H,H,H,H, H,H,H]; "READY: activated externally
[c,L, NOTLOCAL, x,x,x, x] -> [H,H,H,H,H, H,H,H];
[c,H, NOTLOCAL, x,x,x, x] -> [H,H,H,H,H, H,H,H];"100nS SRAM read
[c,H, NOTLOCAL, x,x,x,x] ->
[c,L, SAMPLECS, H,L,L, L] -> [L,H,H,H,H, L,H,H];
[c,H, NOTLOCAL, x,x,x, L] -> [L,H,H,H,H, L,L,L];
[c,L, NOTLOCAL, x,x,x,x] -> [L,H,H,H,H, L,L,L];
[c,H, NOTLOCAL, x,x,x, x] -> [H,H,H,H,H, H,H,H]; "idle [c,L, WAITING, x,x,x, x] -> [H,H,H,H,H, H,H,H];
        WAITING, x, x, x, x, x] -> [H,H,H,H,H,H,H,H];
[C,H,
       WAITING, x,x,x, x] -> [H,H,H,H,H,H,H,H];
WAITING, x,x,x, x] -> [H,H,H,H,H,H,H,H];"100nS SRAM write
[C,L,
[c,H,
[c,L, SAMPLECS, H,H,H, L] \rightarrow [H,L,H,H,H, L,H,H];
[c,H, NOTLOCAL, x,x,x, L] ->
                                   [H,L,H,H,H, L,L,H];
[c,L, NOTLOCAL, x,x,x,x] -> [H,L,H,H,H, L,L,H];
[c,H, NOTLOCAL, x,x,x,x] -> [H,L,H,H,H, L,L,L];
[c,L, NOTLOCAL, x,x,x,x] ->
                                   [H,H,H,H,H, L,L,L];
[c,H, NOTLOCAL, x,x,x,x] -> [H,H,H,H,H,H,H,H];"idle
[c,L,
        WAITING, x,x,x,x ->
                                   [H,H,H,H,H, H,H,H];
[c,H,
        WAITING, x,x,x,x] -> [H,H,H,H,H,H,H,H,H];
[c,L,
        WAITING, x,x,x,x = ->
                                   [H,H,H,H,H, H,H,H];
[с,Н,
        WAITING, x,x,x, x] -> [H,H,H,H,H,H,H,H];"150nS ROM read
[c,L, SAMPLECS, x,x,x, H] -> [H,H,H,H,H, L,H,H];
[C,H,
        MEMORY , H,H,L, x] ->
                                   [L,H,H,H,H, L,L,H];
[c,L,
        MEMORY , x,x,x,x = ->
                                   [L,H,H,H,H, L,L,H];
[C,H,
        MEMORY , x,x,x,x] -> [L,H,H,H,H, L,L,L];
[c,L,
        MEMORY , x,x,x, x] -> [L,H,H,H,H, L,L,L];
         FLOAT , x, x, x, x -> [H,H,H,H,H, L,H,H];
[C,H,
         FLOAT
                , x,x,x, x] ->
                                   [H,H,H,H,H, L,H,H];
[C.L.
        WAITING, x, x, x, x = ->
[C,H,
                                   [H,H,H,H,H, H,H,H];"100nS SRAM read
[c,L, SAMPLECS, H,L,L, L] -> [L,H,H,H,H, L,H,H]; [c,H, NOTLOCAL, x,x,x, L] -> [L,H,H,H,H, L,L,L];
[c,L, NOTLOCAL, x,x,x, x] -> [L,H,H,H,H, L,L,L];
[c,H, NOTLOCAL, x,x,x, x] -> [H,H,H,H,H,H,H,H];"150nS ROM read
[c,L, SAMPLECS, x,x,x, H] -> [H,H,H,H,H, L,H,H];
        MEMORY , H,L,L, x] ->
[c,H,
                                   [L,H,H,H,H, L,L,H];
[C, L,
        MEMORY , x,x,x,x] ->
                                   [L,H,H,H,H, L,L,H];
[C,H,
        MEMORY , x,x,x, x] \rightarrow [L,H,H,H,H, L,L,L];
       MEMORY , x,x,x, x] -> [L,H,H,H,H, L,L,L];
FLOAT , x,x,x, x] -> [H,H,H,H,H, L,H,H];
[C, L,
[c,H,
         FLOAT , x,x,x,x] -> [H,H,H,H,H, L,H,H];
[C,L,
[C,H, WAITING, x,x,x, x] ->
[C,L, SAMPLECS, x,x,x, H] ->
                                   [H,H,H,H,H, H,H,H];"150ns SRAM write [H,H,H,H,H,H, L,H,H];
[C,H,
        MEMORY , H,H,H, x] -> [H,L,H,H,H, L,L,H];
        MEMORY , x,x,x,x] ->
                                   [H,L,H,H,H, L,L,H];
C.L.
c,H,
        MEMORY , x,x,x,x = ->
                                   [H,L,H,H,H, L,L,L];
        MEMORY , x,x,x, x] -> [H,L,H,H,H, L,L,L];
FLOAT , x,x,x, x] -> [H,H,H,H, L,L,H];
[C,L,
[c,H,
[C,L,
         FLOAT
                , x,x,x, x] -> [H,H,H,H,H, L,H,H];
[c,H, WAITING, x,x,x, x] -> [H,H,H,H,H, H,H,H];"150nS SRAM read [c,L, SAMPLECS, x,x,x, H] -> [H,H,H,H,H, L,H,H];
[C,H,
        MEMORY , H,H,L, x] ->
                                   [L,H,H,H,H, L,L,H];
[C, L,
        MEMORY , x, x, x, x] -> [L,H,H,H,H, L,L,H];
[C,H,
        MEMORY , x,x,x,x \rightarrow [L,H,H,H,H, L,L,L];
        MEMORY , x,x,x, x] -> [L,H,H,H,H, L,L,L];
[C,L,
[c,H,
         FLOAT , x,x,x,x] ->
                                    [H,H,H,H,H, L,H,H];
                                   [H,H,H,H,H, L,H,H];"idle
[C,L,
         FLOAT , x,x,x,x] ->
[c,H,
        WAITING, x,x,x,x] -> [H,H,H,H,H,H,H,H];
        WAITING, x,x,x,x] -> [H,H,H,H,H,H,H,H];
[c,L,
[C,H,
        WAITING, x, x, x, x -> [H,H,H,H,H,H,H,H];"150nS SRAM read
```

Figure A-2. PAL-2 State Listings (Cont'd.)



```
[c,L, SAMPLECS, x,x,x,H] -> [H,H,H,H,H, L,H,H];
C,H,
       MEMORY , H,L,L, x] -> [L,H,H,H,H, L,L,H];
[c,L,
       MEMORY , x,x,x,x] -> [L,H,H,H,H, L,L,H];
[c,H,
       MEMORY , x,x,x,x
                             ->
                                [L,H,H,H,H, L,L,L];
[c,L,
       MEMORY , x, x, x, x -> [L,H,H,H,H, L,L,L];
         FLOAT , x,x,x, x] -> [H,H,H,H,H, L,H,H];
FLOAT , x,x,x, x] -> [H,H,H,H,H, L,H,H];
[C,H,
                                [H,H,H,H,H, L,H,H];"idle
[C,L,
[C,H,
       WAITING, x,x,x,x] -> [H,H,H,H,H,H,H,H];
       WAITING, x,x,x, x] -> WAITING, x,x,x, x] ->
[C, L,
                                [H,H,H,H,H, H,H,H];
[C,H,
                                 [H,H,H,H,H,H,H,H]; "peripheral read
[c,L, SAMPLECS, x,x,x, H] -> [H,H,H,H,H, L,H,H];
[c,H, CMDDELAY, x,x,x, x] \rightarrow
                                 [H,H,H,H,H, L,H,H];
[C,L,
          IO
               , L,H,L, x] ->
                                [H,H,L,H,H, L,L,H];
[c,H,
          TΩ
                , x,x,x, x] -> [H,H,L,H,H, L,L,H];
[C,L,
          IO
                , x,x,x,xj \rightarrow
                                 [H,H,L,H,H, L,L,H];
[c,H,
                , x,x,x,x = ->
                                [H,H,L,H,H, L,L,H];
          IO
[C,L,
          IO
                , x,x,x, x] ->
                                 [H,H,L,H,H, L,L,H];
[c,H,
          IO
                , x,x,x,x] \rightarrow
                                 [H,H,L,H,H, L,L,H];
[C,L,
          IO
                , x,x,x, x] -> [H,H,L,H,H, L,L,H];
[C,H,
       ENDIO
                , x,x,x, x] ->
                                 [H,H,L,H,H, L,L,L];
C.L.
       ENDIO
                , x,x,x, x] ->
                                 [H,H,L,H,H, L,L,L];
       FLOAT
[c,H,
               , x,x,x, x] \rightarrow [H,H,H,H,H, L,H,H];
[C,L,
       FLOAT
                , x,x,x,x] \rightarrow
                                 [H,H,H,H,H, L,H,H];
[C,H,
       FLOAT
                , x,x,x, x] ->
                                 [H,H,H,H,H, L,H,H];
[c,L,
       FLOAT
                , x,x,x, x] ->
                                 [H,H,H,H,H, L,H,H];
       FLOAT
[c,H,
                , x,x,x,x = ->
                                 [H,H,H,H,H, L,H,H];
[C,L,
       FLOAT , x,x,x, x] -> [H,H,H,H,H, L,H,H];
WAITING, x,x,x, x] -> [H,H,H,H,H, H,H,H];
[c,H,
       WAITING, x,x,x,x ->
[C,L,
                                [H,H,H,H,H, H,H,H];
[c,H, WAITING, x,x,x, x] -> [H,H,H,H,H, H,H,H]; "peripheral interrupt ack. [c,L, SAMPLECS, x,x,x, H] -> [H,H,H,H,H, L,H,H];
[c,H, CMDDELAY, x,x,x,x] -> [H,H,H,H,H, L,H,H];
[c,L,
               , L,L,L, x] -> [H,H,H,H,L, L,L,H];
          IO
[C,H,
          IO
                , x,x,x, x] ->
                                [H,H,H,H,L, L,L,H];
ĺς,L,
               , x, x, x, x] \rightarrow [H, H, H, H, L, L, L, H];
          IO
[C,H,
          IO
                , x,x,x, xj ->
                                 [H,H,H,H,L, L,L,H];
[c,L,
          IO
               , x,x,x, x] ->
                                 [H,H,H,H,L, L,L,H];
[C,H,
          IO
               , x,x,x, x] \rightarrow [H,H,H,H,L, L,L,H];
                , x,x,x, xj ->
[C,L,
          IO
                                 [H,H,H,H,L, L,L,H];
                                 [H,H,H,H,L, L,L,L];
[C,H,
       ENDIO
               , x,x,x, x] ->
[c,L,
       ENDIO
               , x,x,x, x] ->
                                [H,H,H,H,L, L,L,L];
       FLOAT
[c,H,
               , x,x,x, x] ->
                                 [H,H,H,H,H, L,H,H];
[c,L,
               , x,x,x,x] \rightarrow [H,H,H,H,H,L,H,H];
       FLOAT
[C,H,
       FLOAT
                , x,x,x, x] ->
                                 [H,H,H,H,H, L,H,H];
fc.L.
       FLOAT
                , x,x,x, x] ->
                                [H,H,H,H,H, L,H,H];
       FLOAT
                , x,x,x, x] \rightarrow [H,H,H,H,H,L,H,H];
[c,H,
[C,L,
       FLOAT
                , x,x,x, x] -> [H,H,H,H,H, L,H,H];
      WAITING, x, x, x, x] -> [H,H,H,H,H, H,H,H];"100nS SRAM read SAMPLECS, H,L,L, L] -> [L,H,H,H, L,H,H];
[C,H,
                                [L,H,H,H,H, L,H,H];
[C,L,
[c,H, NOTLOCAL, x,x,x, L] ->
                                [L,H,H,H,H, L,L,L];
[C,L,
      NOTLOCAL, x,x,x,x] -> [L,H,H,H,H, L,L,L]
[C,H, NOTLOCAL, x,x,x,x] ->
                                 [H,H,H,H,H,H,H,H]; "peripheral write
[c,L, SAMPLECS, x,x,x, H] ->
                                [H,H,H,H,H, L,H,H];
[c,H, CMDDELAY, x,x,x,x] -> [H,H,H,H,H, L,H,H];
[C,L,
               , L,H,H, x] ->
          TO
                                [H,H,H,L,H, L,L,H];
[c,H,
          IO
                , x,x,x, x] \rightarrow [H,H,H,L,H, L,L,H];
[c,L,
          IO
                , x,x,x, xj ->
                                 [H,H,H,L,H, L,L,H];
                                [H,H,H,L,H, L,L,H];
[C,H,
          TO
                , x,x,x, x] ->
[c,L,
          IO
                , x,x,x, x] ->
                                [H,H,H,L,H, L,L,H];
[c,H,
          TO
                , x,x,x, x] ->
                                 [H,H,H,L,H, L,L,H];
[c,L,
          IO
                , x,x,x, x] ->
                                [H,H,H,L,H, L,L,H];
c,H,
          IO
                , x,x,x, x] -> [H,H,H,L,H, L,L,H];
[C,L,
          TO
                , x,x,x, x] -> [H,H,H,L,H, L,L,H];
[C,H,
       ENDIO
               , x,x,x, x] ->
                                [H,H,H,L,H, L,L,L];
                , x,x,x,x] \rightarrow
[C,L,
       ENDIO
                                 [H,H,H,H,H, L,L,L];
[C,H,
       FLOAT
                , x,x,x, x] ->
                                 [H,H,H,H,H, L,H,H];
[c,L,
       FLOAT
                , x, x, x, x] \rightarrow [H, H, H, H, H, L, H, H];
end Bus Control 386 Pal 2;
```

Figure A-2. PAL-2 State Listings (Cont'd.)



```
PAL16R8
                                                                            PAL DESIGN SPECIFICATIONS
PART NUMBER: 80386 LOCAL BUS CONTROLLER - PAL 1
80386 LOCAL BUS CONTROLLER: PAL 1 OF 2
INTEL, SANTA CLARA, CALIFORNIA
CLK2 CLK ADS
                          READY WR
                                              CSOWS CSIWS CSIO RESET GND
        Q0
                                                      PIPE IDLE NA
OE
                   Q1
                            T.O
                                     T.1
                                                L2
/PIPE :=
               RESET
              + /CLK * /PIPE
+ CLK * PIPE
              + /PIPE * READY
+ IDLE
              + ADS * /PIPE
              /CLK * /IDLE * /RESET
+ /IDLE * PIPE * /RESET
+ /IDLE * READY * /RESET
/IDLE :=
              + /ADS * CLK * /PIPE * /RESET
              /Ll
/NA :=
           + L2
           + /CLK * /NA
           + CLK * LO * NA
           + /L0 * /NA * Q0
+ /L0 * /NA * Q1
           /CLK * /L1 * /L2 * /RESET
+ /L0 * /L2 * /NA * /RESET
+ /L1 * /L2 * READY * /RESET
/L2 :=
           + L0 * L1 * /L2 * Q0 * /RESET
           + /L0 * /L1 * /RESET
           + /CLK * CSOWS * CS1WS * CSIO * /IDLE * LO * L1 * L2 * /RESET
/Ll :=
            RESET
           + /CLK * L0 * /L1
+ L0 * /L1 * READY
+ CS1WS * /L1 * L2
           + L0 * /L1 * L2
+ L0 * L2 * /Q0 * /Q1
+ L0 * /L1 * /Q0 * /Q1
+ /CLK * CSOWS * CSIWS * CSIO * /IDLE * L0 * L2
          /L0 * /L2 * /RESET
+ /L0 * L1 * Q0 * /RESET
+ CS1WS * /CS1O * /L0 * /L1 * /RESET
+ /ADS * CLK * CS1O * L0 * /L1 * L2 * /RESET
/L0 :=
           + /ADS * CLK * CS10 * L0 * /L1 * L2 * /Q0 * /RESET

+ CLK * CS10 * /IDLE * L0 * /L1 * L2 * /RESET

+ CLK * /IDLE * L0 * /L1 * L2 * /Q0 * /RESET

+ CLK * /IDLE * L0 * /L1 * L2 * /Q0 * /RESET

+ /ADS * CLK * /L1 * /L2 * /Q0 * /Q1 * /READY * /RESET
/Q1 :=
            RESET
           + Q0 * /Q1
           + CLK * Q0
           + L0 * /Q1
+ CS1WS * /L1 * L2 * /Q1
+ L1 * /L2 * /Q1
/Q0 :=
             RESET
          + /CLK * /Q0 * Q1
           + CLK * Q0 * /Q1
+ /L0 * L1 * L2 * /Q0 * /Q1
           + L0 * /L1 * /Q0 * /Q1
+ CS1WS * /L1 * L2 * /Q0 * /Q1
+ /L1 * /L2 * /Q0 * /Q1 * WR
+ /L0 * L1 * /NA * /Q0 * /Q1
DESCRIPTION
      This PAL is the first of two PALs that implement a 386 bus controller
```

Figure A-3. PAL-1 Equations



```
PAL16R8
                                                                                                                   PAL DESIGN SPECIFICATIONS
  PART NUMBER: 80386 LOCAL BUS CONTROLLER - PAL 2
  80386 LOCAL BUS CONTROLLER: PAL 2 OF 2
  INTEL, SANTA CLARA, CALIFORNIA
CLK2 CLK MIO DC WR L
                            MIO DC WR LO L1 L2 CSOWS GND
DEN ALE INTA IOWC IORC MWTC MRDC VCC
               RDY
                      /L0 * L1 * /MRDC
+ L1 * /L2 * /MRDC
+ /CLK * L0 * /L2 * /MRDC
  /MRDC :=
                      + /CK " LO " /L2 * /MRDC * RDY
+ /CSOWS * /L0 * /L1 * L2 * MIO * /WR
+ DEN * /L0 * L1 * MIO * /WR
+ DEN * L1 * /L2 * MIO * /WR
/MWTC := L0 * L1 * /L2 * /MWTC
+ /L0 * L1 * /MWTC * RDY
+ L0 * /L2 * /MWTC * RDY
+ /CSOWS * DC * /L0 * /L1 * L2 * MIO * WR
+ DC * DEN * /L0 * L1 * MIO * WR
+ DC * DEN * L1 * /L2 * MIO * WR
/IORC := /IORC * /LO * L1
+ /IORC * L1 * /L2
+ /CLK * /IORC * L0 * /L2
+ /IORC * L0 * /L2 * RDY
+ /CSOWS * DC * /L0 * /L1 * L2 * /MIO * /WR
+ DC * DEN * /L0 * L1 * /MIO * /WR
+ DC * DEN * L1 * /L2 * /MIO * /WR
 /IOWC := /IOWC * LO * L1 * /L2
                      + /IOWC * /LO * L1 * RDY
+ /IOWC * L0 * /L2 * RDY
                      + / IOWC ** LO * / L2 * RDI
+ / CSOWS ** DC * / L0 * / L1 * L2 * / MIO * WR
+ DC ** DEN * / L0 * L1 * / MIO * WR
+ DC ** DEN ** L1 * / L2 * / MIO * WR
/INTA := /INTA * /L0 * L1

+ /INTA * L1 * /L2

+ /CLK * /INTA * L0 * /L2

+ /INTA * L0 * /L2 * RDY

+ /CSOWS * /DC * /L0 * /L1 * L2 * /MIO * /WR

+ /DC * DEN * /L0 * L1 * /MIO * /WR

+ /DC * DEN * L1 * /L2 * /MIO * /WR
/ALE := /ALE * /CLK * /CSOWS * /L2
+ /ALE * /CLK * /DEN * /L2
+ /ALE * /CSOWS * /L2 * RDY
                    + /L0
                    + L1
                    + /ALE * /DEN * /L2 * RDY
                   /L0 * L1
+ L1 * /L2
+ /IOWC * L1
 /DEN :=
                    + /10WC - L1
+ L1 * /MWTC
+ /CLK * /DEN * L0 * /L2
+ /DEN * L0 * /L2 * RDY
+ /ALE * /CLK * /CSOWS * L0 * /L2
+ /ALE * /CSOWS * L0 * /L2 * RDY
 /RDY := /L0 * L1 * L2
                   /LO * L1 * L2

+ /CLK * LO * /L2 * /RDY

+ CLK * /DEN * LO * L1 * /L2 * RDY

+ CLK * /INRA * LO * /L1 * /L2 * RDY

+ CLK * /IORC * LO * /L1 * /L2 * RDY

+ CLK * LO * /L1 * /L2 * MRDC * RDY

+ CLK * /DEN * /IOWC * LO * /L2 * RDY

+ CLK * /DEN * LO * /L2 * /MWTC * RDY
 DESCRIPTION
          This PAL is the second of two PALs that implement a 386 bus controller
```

Figure A-4. PAL-2 Equations

Appendix 80387 Emulator PAL Description

В



APPENDIX B 80387 EMULATOR PAL DESCRIPTION

This section describes the PAL equations for the Math Control PAL in the 80386 emulator circuit. These equations are listed in Figure B-1.

The primary function of the PAL is to decode the 80386 outputs and generate 80287 inputs. The CLK16D#, DVALID#, and AVALID# signals provide for the correct timing of the outputs. The TP2 input provides the ability to force the PAL outputs to the high impedance state. For normal operation, TP2 is pulled high.

```
PAL DESIGN SPECIFICATION
PAL16L8B
386/100
                 27 February 1986
                                                  ED JACKS
PAL:
                 MATH CYCle
                                                  MATHCYC
INTel Corporation
/RDY A31 LRESET /ADS MIO /RD /AVALID /DVALID /CLK16 GND
TP2 /CLK16D /READYO /DVALIDD /AVALIDD NC /IORDD /IOWCD /READYOD VCC
IF (TP2) AVALIDD = ADS * RDY * /LRESET * CLK16 * /AVALID
           + /RDY * A31 * /MIO * /LRESET * AVALID
           + A31 * /MIO * /LRESET * AVALID * DVALID
           + ADS * /LRESET * CLK16 * /AVALID * DVALID
           + /LRESET * /CLK16 * AVALID
IF (TP2) DVALIDD = /LRESET * CLK16 * AVALID * DVALID
          + /RDY * /LRESET * DVALID
+ ADS * /LRESET * CLK16 * /DVALID
           + /LRESET * /CLK16 * DVALID
IF (TP2) IORDD = /RDY * A31 * /MIO * /RD * AVALID * DVALID
           + A31 * /MIO * /CLK16 * RD * AVALID * DVALID
IF (TP2) IOWCD - /RDY * A31 * /MIO * RD * AVALID * DVALID + A31 * /MIO * /CLK16 * /RD * AVALID * DVALID
IF (TP2) READYOD = A31 * /MIO * /CLK16 * READYO * AVALID * DVALID
          + /RDY * A31 * /MIO * CLK16 * AVALID * DVALID
CLK16D
              = /LRESET * /CLK16
```

Figure B-1. 80387 Emulator PAL Equations

Appendix DRAM PAL Descriptions

C

APPENDIX C DRAM PAL DESCRIPTIONS

This section describes the inputs, outputs, and functions of each of the PALs in the DRAM design described in Chapter 6. The terms Start-Of-Phase and Middle-Of-Phase used to describe PAL input sampling times refer to the 80386 internal CLK phase and are defined in Figure C-1.

The setup, hold, and propagation delay times for each PAL input and output can be determined from the PAL data sheets. In a few cases, the setup and hold times during certain events must be violated; in these cases, the PAL equations mask these inputs so they are not sampled. Because the states are fully registered and because inputs are masked when their setup or hold times cannot be guaranteed, no hazards exist.

DRAM STATE PAL

The DRAM State PAL determines when to run a new DRAM cycle and tracks the state of the DRAM through the cycle. The inputs sample DRAM requests from the processor (or any other bus master) as well as requests for refresh. The outputs store state information and generate the two RAS signals and two multiplexer control signals. Table C-1 contains a description of the outputs and inputs.

The equations for the 3-CLK DRAM State PAL are shown in Figure C-2; those for the 2-CLK DRAM State PAL are shown in Figure C-3. The DRAM State PAL is implemented in a 16R8 PAL if the RAS signals are registered internally, or in a 16R6 PAL if external registers are used. For a 16-MHz system, B-series PAL speeds are required.




Figure C-1. PAL Sampling Edges



Q1

Table C-1. DRAM State PAL Pin Description

	Table C-1. DRA	M State PAL Pin Description	_
	PAL CONTRO	DLS	
Name	Connects From	PAL Usage	
CLK2	Systems CLK2	PAL register clock	
OE	Tied low	Outputs always enabled	
		PAL INPUTS	
Name	Connects From	PAL Usage	Sampled
CLK	System CLK	Indicates clock phase	Every CLK2
CS0# CS1# CS2# CS3# CS4#	Chip-Select Logic (uses Address, M/IO, W/R, D/C)	DRAM access is begun (or queued if another cycle is in progress) when all selects are sampled active	Start-Of-Phase (Queue cleared after first cycle of access)
DT/R#	DRAM CONTROL PAL DT/R# out	Indicates write/read Used only in 2-CLK	Start-Of-Phase on 2nd CLK of access
A2	System Address bit 2	Selects one of the two DRAM banks	Start-Of-Phase in which DRAM access starts
RFRQ	Refresh Interval Count	Starts refresh cycle as soon as possible	Middle-Of-Phase
		PAL OUTPUTS	
Name	Connects To	PAL Usage	Changes State
RAS0#	DRAM Bank 0	Controls DRAM RAS signals	Start-Of-Phase
RAS1#	DRAM Bank 1		
ROWSEL	Addr MUX select	Select DRAM row/column	Middle-Of-Phase
MUXOE#	Addr MUX enable	Disable MUX on refresh	Middle-Of-Phase
A2REG	Not connected	Store active DRAM bank	
DRAMSELECT	Not connected	Queue DRAM requests	
Q0	For NA in 2-CLK	Stores PAL State	
		1	1

Not connected



```
PAL16R8
                                                                                     PAL DESIGN SPECIFICATIONS
PART NUMBER: 3-CLK DRAM STATE PAL
DRAM STATE PAL OF INTERLEAVED DRAM CONTROLLER FOR 80386 SYSTEMS
INTEL, SANTA CLARA, CALIFORNIA
CLK2 CLK A2 CSO CS1 CS2 CS3 CS4 RFRQ GND
OE RASO ROWSEL MUXOE QO Q1 A2REG DRAMSELECT RAS1 VCC
/ROWSEL := /ROWSEL * QO * CLK
                 + /ROWSEL * /Q1
                 + ROWSEL * /Q1 * /Q0 * /CLK
+ ROWSEL * /Q1 * Q0 * /CLK * MUXOE * RFRQ
/Q1:= ROWSEL * /Q1 * /Q0 * /CLK
+ ROWSEL * Q0 * CLK
        + ROWSEL * Q0 * CLK

+ /ROWSEL * /Q0 * CLK

+ ROWSEL * Q1 * /Q0 * CLK * /CS0 * /CS1 * /CS2 * CS3 * CS4

* /MUXOE * A2 * A2REG

+ ROWSEL * Q1 * /Q0 * CLK * /CS0 * /CS1 * /CS2 * CS3 * CS4

* /MUXOE * A2 * /A2REG

+ ROWSEL * /Q1 * Q0 * /CLK * /MUXOE

+ ROWSEL * /Q1 * Q0 * /CLK * /RFRQ
/Q0 := /ROWSEL * Q1 * Q0 * /CLK

+ /ROWSEL * /Q0 * Q1 * CLK

+ ROWSEL * /Q1 * /Q0 * /CLK

+ ROWSEL * Q1 * CLK * /CS0 * /CS1 * /CS2 * CS3 * CS4

* /MUXOE * A2 * A2REG

+ ROWSEL * Q1 * CLK * /CS0 * /CS1 * /CS2 * CS3 * CS4

* /MUXOE * /A2 * /A2REG

+ POWSEL * Q1 * CLK * /CS0 * /CS1 * /CS2 * CS3 * CS4

* /MUXOE * /A2 * /A2REG
          + ROWSEL * /Q1 * Q0 * CLK * /CS0 * /CS1 * /CS2 * CS3 * CS4 * /MUXOE

+ ROWSEL * /Q1 * Q0 * CLK * DRAMSELECT * /MUXOE

+ ROWSEL * /Q1 * Q0 * /CLK * MUXOE * RFRQ
/RASO := ROWSEL * /Q1 * /Q0 * /CLK * /A2REG
+ ROWSEL * /Q1 * /Q0 * /CLK * MUXOE
+ /ROWSEL * /A2REG
              + /ROWSEL * MUXOE
              + ROWSEL * Q1 * CLK * /A2 * /A2REG * /CSO * /CS1 * /CS2 * CS3 * CS4
                      * /MUXOÈ
              + ROWSEL * /Q1 * Q0 * CLK * /A2 * /CS0 * /CS1 * /CS2 * CS3 * CS4
                     * /MUXOE
              + ROWSEL * /01 * 00 * CLK * /A2 * DRAMSELECT * /MUXOE
/RAS1 := ROWSEL * /Q1 * /Q0 * /CLK * A2REG

+ ROWSEL * /Q1 * /Q0 * /CLK * MUXOE

+ /ROWSEL * A2REG

+ /ROWSEL * MUXOE

+ ROWSEL * Q1 * CLK * A2 * A2REG * /CS0 * /CS1 * /CS2 * CS3 * CS4
                     * /MUXOE
              + ROWSEL * /Q1 * Q0 * CLK * A2 * /CS0 * /CS1 * /CS2 * CS3 * CS4
                     * /MUXOE
              + ROWSEL * /01 * 00 * CLK * A2 * DRAMSELECT * /MUXOE
/MUXOE := /MUXOE * /QO
               + /MUXOE * CLK
                + /MUXOE * /ROWSEL * /Q1
+ /RFRQ * ROWSEL * /Q1 * Q0 * /CLK
+ /MUXOE * /RFRQ * Q1 * Q0 * /CLK
/A2REG := /A2REG * /Q0
+ /A2REG * Q1 * CLK
                + /A2REG * ROWSEL * Q1
                + /AZREG * /ROWSEL * /Q1
+ AZREG * /ROWSEL * /Q1
+ AZREG * /ROWSEL * /Q1 * Q0 * /CLK
+ /A2 * ROWSEL * /Q1 * Q0
```

Figure C-2. 3-CLK DRAM State PAL Equations



```
FUNCTION TABLE
OE CLK2 CLK CSO CS1 CS2 CS3
                                               CS4 A2 RFRO
                                                                             ;inputs
ROWSEL Q1 Q0 RASO RAS1 MUXOE DRAMSELECT A2REG
                                                                             ;outputs
;0E
   CLK2
      CLK
                                 ROWSEL
;
         /CSO
                                    Q1
            /CS1
                                      00
              /CS2
                                          /RASO
               I CS3
                                            /RAS1
                                               /MUXOE
                    CS4
                       A2
                                                 DRAMSELECT
                          RFRQ
                                                    A2REG
                                                              STATE
                                                                               COMMENTS
                                X X
X X
X X
                 X X X;
X X X;
X X X;
 L · C
                                                                      initialize to IDLE
         H
   С
      L
                                                                      initialize to IDLE
 LČHH
                                                                      initialize to IDLE
 L C L H X X X X X L
L C H H X X X X X L
                                              X X X;
X X X;
                                                                      initialize to IDLE
  C H H X X X X X L
C L H X X X X X X L
C H H X X X X X X L
C L X X X X X X X L
C L X X X X X X X L
C H H X X X X X X L
C H L X X X X X X L
C L L X X X X X X X L
C L L X X X X X X X L
C L L X X X X X X X L
C L X X X X X X X L
C L X X X X X X X L
C L X X X X X X X X L
C L X X X X X X X X L
C L X X X X X X X X L
                                                                      initialize to IDLE
                                X X X X X X X X;
X X X X X X X X;
 ĪĈ
                                                                      initialize to IDLE
                                                                      initialize to IDLE
                                         LHLLL;
                                 LLH
                                                         ACCESS3
                                                                      continue DRAM cycle
                                 LHHLHLLL;
                                                         ACCESS4
                                                                      continue DRAM cycle
                                 LHHLHLLL;
                                                         ACCESS5
                                                                      continue DRAM cycle
                                 HHL
                                         L
                                           Н
                                              L
                                                 LH;
                                                          ACCESS6
                                                                      continue DRAM cycle
                                H H L L H; ALCESSB CONTINUE DRAM CYCLE
H H H H H L L H; PRECHARGEI no dram request pending
H H H H H L L H; PRECHARGE2 wait for precharge
H L L H L L H H; ACCESSI start DRAM cycle to other bank
L L H L L L L H; ACCESS2 continue DRAM cycle
L L H H L L L H; ACCESS3 continue DRAM cycle
  L H H H L L L H;
L H H H L L L H;
H H L H L L L L L;
                                                         ACCESS4
                                                                      continue DRAM cycle
                                                         ACCESS5
                                                                      continue DRAM cycle
                                                          ACCESS6
                                                                      continue DRAM cycle
                                H H H H H L L L;PRECHARGE1 no dram request pe
H H H H H L L L;PRECHARGE2 wait for precharge
                                                                      no dram request pending
                                 HLHHHLLX;
                                                           IDLE1
                                                                      no dram request pending
 ĹC
                                 ніннні і х;
                                                           IDLE2
                                                                      wait for precharge
                                 ніннні і х;
                                                           IDLE1
                                                                      no dram request pending
                 XXXH
   C
         χ
            ХХ
                                 HLHHHHLX;
                                                           IDLE2
                                                                      refresh request sampled
НІННИННЫ;
                                                           IDLE1
                                                                      can't start: refresh pending
                                 L H L H H H H X; REFSTART2 refresh address set-up
                                HLLLLHHX;
                                                          ACCESS1
                                                                      start refresh cycle
 L C L H X X X X X L L C L H X X X X X X L
                                X
                                                                      initialize to IDLE
                                                                      initialize to IDLE
                                                                      initialize to IDLE
L C L H X X X X X L
L C H H X X X X X X
L C L H H X X X X X X
L C L X X X X X X X
L C L X X X X X X X
L C L X X X X X X X
L C L X X X X X X X
L C L X X X X X X X
L C L X I I I H H I
C C H I I I H H I
                                X X X X X X X X;
X X X X X X X X;
H L H H H L L X;
                                 X
                                                                      initialize to IDLE
                                                                      initialize to
                                                                                         IDLE
                                                           IDLE1
                                                                      remain in IDLE
                                      ННН С С Х;
                                 ΗL
                                                           IDLE2
                                                                      remain in IDLE
                                 ΗL
                                      HHHLL
                                                           IDLE1
                                                                      remain in IDLE
                                 HLHHHLL
                                                            IDLE2
                                                                      remain in IDLE
                                 H L H H H L L X;
H L H H H L L X;
                                                            IDLE1
                                                                      remain in IDLE
                                                                      remain in IDLE
                                                           IDLE2
 LCHLLLHHLL
                                                          ACCESS1
                                                                      start DRAM cycle
                                 HLLLHLHL;
      L X X X X X X L
H X X X X X X X L
L X X X X X X X L
H L L L H H X L
                                 L L L L H L L L;
L L H L H L L L;
                                                          ACCESS2
                                                                      continue DRAM cycle
 L C
                                                          ACCESS3
                                                                      continue DRAM cycle
                                            ΗL
                                                          ACCESS4
                                                                      continue DRAM cycle
  L C
                                 LHHL
                                                 L
  L C
                                 LHHLHLHL;
                                                          ACCESS5
                                                                      continue DRAM cycle new request
 L C
                                 HHLLHLHH;
                                                          ACCESS6
                                                                      continue DRAM cycle
 LCLXX
              H L L H L L H H;
L L L H L L L H;
                                                          ACCESS1
                                                                      start DRAM cycle to other bank continue DRAM cycle
                                                          ACCESS2
                 L X X L
X X X L
X L X L
                                      н н
                                                                      continue DRAM cycle
    С
      Н
               X
                                    L
                                            L
                                                  L
                                                    Η;
                                                          ACCESS3
 L C
                                 LH
                                      HHLL
                                                 LH;
                                                          ACCESS4
                                                                      continue DRAM cycle
         L C
       Н
                                                          ACCESS5
                                                                      continue DRAM cycle
 L C
                                                                      continue DRAM cycle
       L
                                                          ACCESS6
                                 H H H H H L H L;PRECHARGE1 can't start same bank cycle
```

Figure C-2. 3-CLK DRAM State PAL Equations (Cont'd.)



```
LCLXXXXXXL
                      H H H H H L H L; PRECHARGE2 wait for precharge
LCHLLLHHHL
                      HLHHHLHX;
                                              can't start same bank cycle
                                       IDLE1
                                       IDLE2
                                               wait for precharge
                      HLHHHLHX;
                                      ACCESS1 start DRAM cycle to same bank
                      HLLHLLHH;
                      L L L H L L H; ACCESS2 continue DRAM cycle
                      LLHHLLLH; ACCESS3 continue DRAM cycle
                     L H H H L L L H; ACCESS4 continue DRAM cycle
                      L H H H L L H H; ACCESS5 continue DRAM cycle new request
LCHLLLHHXH
                     H H L H L H H L; ACCESS6 continue DRAM cycle refresh h
H H H H H H H L; PRECHARGE1 can't start: refresh pending
LCLXXXXXXX
                                      ACCESS6 continue DRAM cycle refresh req
LCLXXXXXXX
                      H H H H H H L;PRECHARGE2 wait for precharge
                      н L н н н н х;
                                              can't start: refresh pending
                                        IDLE1
                      L H L H H H H X; REFSTART2 wait for precharge
                      H L L L H H X; ACCESS1 start refresh cycle
LCLXXXXXXX
                      LLLLHHX; ACCESS2 continue refresh cycle
LCHHXXXXXXL
                      LLHLLHHX; ACCESS3 continue refresh cycle
LCLXXXXXXXL
                      LHHLLHHX;
                                      ACCESS4 continue refresh cycle
                      L H H L L H H X; ACCESS5 continue refresh cycle
L C L X X X X X X L L C H H X X X X X L
                      H H L L H H X; ACCESS6 continue refresh cycle
H H H H H H H X;PRECHARGE1 can't start: refresh precharge
LCLXXXXXXXL
                      H H H H H H X; PRECHARGE2 wait for precharge
LCHHXXXXXXL
                      HLHHHHHX;
                                        IDLE1
                                              can't start: refresh precharge
LCLXXXXXXXL
                      H L H H H L H X;
                                       IDLE2
                                              wait for precharge
LCHHXXXXXLL
                      H L L L H L H L; ACCESS1 start DRAM cycle
LCLXXXXXXX
                      L L L H L L L; ACCESS2 continue DRAM cycle
DESCRIPTION
*** NOTE - SOME VERSIONS OF PALASM WILL CRASH IF THE FILE IS TOO LONG ***
*** IF YOURS DOES, DELETE THIS DESCRIPTION (FROM HERE TO END-OF-FILE) ***
This PAL implements the main state machine of the DRAM controller.
The state machine is described below.
For brevity, the following keywords are used
SELECT = (/CSO * /CS1 * /CS2 * CS3 * CS4 * CLK)
                          ; chip selects and clock must be active to select
SELECTED = (SELECT + DRAMSELECT) ; true if DRAM is now or has been selected
STARTACCESS = (SELECTED * /MUXOE) ; start dram access cycle from idle
The states are defined below and indicated by [ROWSEL:Q1:Q0:CLK].
The 4-bit binary number following the state name represents these four signals.
  state REFSTART2 = 0101 ;cycle preceding refresh
   /RASO := ON ; next cycle is first RAS for refresh
    /RAS1 := ON
    MUXOE := MUXOE
                            ;maintain MUXOE state
                                                         always
                       |MUXOE * RFRQ
  state IDLE1 = 1010 ;waiting for access or refresh
    /RASO := OFF
                            ;both RAS's idle
                                                      i<--
    /RAS1 := OFF
    MUXOE := RFRQ
                            ;sample refresh request
|/(MUXOE * RFRQ)
                              |/STARTACCESS
```

Figure C-2. 3-CLK DRAM State PAL Equations (Cont'd.)






Figure C-2. 3-CLK DRAM State PAL Equations (Cont'd.)




Figure C-2. 3-CLK DRAM State PAL Equations (Cont'd.)



```
PAL16R6
                                                                                                                      PAL DESIGN SPECIFICATIONS
 PART NUMBER: 2-CLK DRAM STATE PAL
 DRAM STATE PAL OF INTERLEAVED DRAM CONTROLLER FOR 80386 SYSTEMS
INTEL, SANTA CLARA, CALIFORNIA
CLK2 CLK A2 CS0 CS1 CS2 CS3 DT%R RFRQ GND
OE RASO ROWSEL MUXOE Q0 Q1 A2REG DRAMSELECT RAS1 VCC
/DRAMSELECT := CSO * /DRAMSELECT
+ CS1 * /DRAMSELECT
+ CS2 * /DRAMSELECT
+ /CS3 * /DRAMSELECT
+ /CK4 * /DRAMSELECT
+ /MUXOE * ROWSEL * /Q1 * /Q0 * /CLK
/ROWSEL := /ROWSEL * Q0 * CLK
+ /ROWSEL * /Q1
+ ROWSEL * /Q1 * /Q0 * /CLK
+ ROWSEL * /Q1 * Q0 * /CLK * MUXOE * RFRQ
 /Q1:= ROWSEL * /Q1 * /Q0 * /CLK
+ ROWSEL * Q0 * CLK
             + Q1 * /Q0 * CLK
             + VI - VQU - CLK
+ /ROWSEL * /QI * /QO * CLK * DT%R * /MUXOE
+ ROWSEL * /QI * QO * /CLK * /MUXOE
+ ROWSEL * /QI * QO * /CLK * /RFRQ
/Q0 := /ROWSEL * Q1 * Q0 * /CLK

+ /ROWSEL * /Q0 * Q1 * CLK

+ ROWSEL * /Q1 * /Q0 * /CLK

+ ROWSEL * Q1 * CLK * /CSO * /CS1 * /CS2 * CS3

* /MUXOE * A2 * A2REG

+ ROWSEL * Q1 * CLK * /CSO * /CS1 * /CS2 * CS3

* /MUXOE * /A2 * /A2REG

+ ROWSEL * /Q1 * Q0 * CLK * /CSO * /CS1 * /CS2 * CS3 * /MUXOE

+ ROWSEL * /Q1 * Q0 * CLK * DRAMSELECT * /MUXOE

+ ROWSEL * /Q1 * Q0 * CLK * MUXOE * RFRQ
/RASO = ROWSEL * /Q1 * /Q0 * /CLK * /A2REG
+ ROWSEL * /Q1 * /Q0 * /CLK * MUXOE
+ /ROWSEL * /A2REG
+ /ROWSEL * MUXOE
                    + ROWSEL * Q1 * CLK * /A2 * /A2REG * /CS0 * /CS1 * /CS2 * CS3 * /MUXOE

+ ROWSEL * /Q1 * Q0 * CLK * /A2 * /CS0 * /CS1 * /CS2 * CS3 * /MUXOE

+ ROWSEL * /Q1 * Q0 * CLK * /A2 * DRAMSELECT * /MUXOE
/RAS1 = ROWSEL * /Q1 * /Q0 * /CLK * A2REG
+ ROWSEL * /Q1 * /Q0 * /CLK * MUXOE
+ /ROWSEL * A2REG
+ /ROWSEL * MUXOE
                   + ROWSEL * Q1 * CLK * A2 * A2REG * /CSO * /CS1 * /CS2 * CS3 * /MUXOE
+ ROWSEL * /Q1 * Q0 * CLK * A2 * /CSO * /CS1 * /CS2 * CS3 * /MUXOE
+ ROWSEL * /Q1 * Q0 * CLK * A2 * DRAMSELECT * /MUXOE
 /MUXOE := /MUXOE * /QO
+ /MUXOE * CLK
                      + /MUXOE * /ROWSEL * /Q1
+ /RFRQ * ROWSEL * /Q1 * Q0 * /CLK
+ /MUXOE * /RFRQ * Q1 * Q0 * /CLK
 /A2REG := /A2REG * /Q0
+ /A2REG * Q1 * CLK
                      + /AZREG * Q1 ~ CLK
+ /AZREG * ROWSEL * Q1
+ /AZREG * /ROWSEL * /Q1
+ AZREG * /ROWSEL * Q1 * Q0 * /CLK
+ /A2 * ROWSEL * /Q1 * Q0
```

Figure C-3. 2-CLK DRAM State PAL Equations



```
FUNCTION TABLE
OE CLK2 CLK CSO CS1 CS2 CS3 CS4 A2 RFRQ
                                                           :inputs
ROWSEL Q1 Q0 RASO RAS1 MUXOE DRAMSELECT A2REG
                                                           ;outputs
;0E
   CLK2
     CLK
                         ROWSEL
       /cso
                           01
         /CS1
                             00
           /CS2
                               /RASO
             CS3
                                  /RAS1
               DT%R
                                     MUXOE
                                      DRAMSELECT
                 A2
                    RFRQ
                                        A2REG
                                               STATE
   COMMENTS
                               X X X
X X X
X X X
X X X
X X X
X X X
X X X
X X X
                                      X X;
X X;
X X;
X X;
L
  C
                         initialize to IDLE
initialize to IDLE
                                                      initialize to IDLE
                                                      initialize to IDLE
                                                      initialize to IDLE
                                                      initialize to IDLE
                                                      initialize to IDLE
                                               χ
                                                      initialize to IDLE
                               X X X
X X X
X X X
                                               X
                                                      initialize to IDLE
                                                      initialize to
                                                      initialize to IDLE
                               ĤĤĹĹ
                                        χ̈́;
Χ;
                                              IDLE1
                                                      remain in IDLE
                                              IDLE2
                                                      remain in IDLE
                         Н
                           LH
                               HHL
                                              IDLE1
                                                      remain in IDLE
  HHLL
                         H L H
 L
                                        Χ;
                                              IDLE2
                                                      remain in IDLE
                                        Х;
                                              IDLE1
                                                      remain in IDLE
                           LH
                               нн
                                    L
                                              IDLE2
                                                      remain in IDLE
                         Н
                           L
                             LLHLH
                                        L;
                                             ACCESS1
                                                      start DRAM cycle
                             ACCESS2
                                                      continue DRAM cycle
                           L L H L H L
                                        L;
 L
                         L
                                                      continue DRAM cycle: it's write
                         L
                                        L;
                                             ACCESS3
                         L
                           ΗН
 L
                                             ACCESS4
                                                      continue DRAM cycle
                           Н
                             HLHL
                                             ACCESS5
                                                      continue DRAM cycle new request
                             H
 L
                         нн
                                        Н;
                                             ACCESS6
                                                      continue DRAM cycle
                                                      start DRAM cycle to other bank
                                        Н;
 L
                         ΗL
                                             ACCESS1
                                                      continue DRAM cycle
                           L
                             LHL
                                    L
                                      LH;
                                             ACCESS2
                           Н
                             HHL
                                    L
                                      L
                                             ACCESS5
                                                      continue DRAM cycle: it's read
                                        Н;
                           H L H L L
                                             ACCESS6
 L
                         нн
                                      L
                                                      continue DRAM cycle
                                        L:
                                      Ĥ
                                                      can't start same bank cycle
wait for precharge
start DRAM cycle to same bank
                                        Χ;
                                              IDLE1
 L
                         ΗL
                                      Н
                                        Х;
 L
                         Н
                                              IDLE2
                         H L
                             LHLL
                                        Н;
                                             ACCESS1
                         continue DRAM cycle
                                             ACCESS2
 L
                                        Н;
                                                      continue DRAM cycle: it's write
                                        Н;
                                             ACCESS3
                         L H H H L L L H;
L H H H L L H H;
H H L H L L H L;
H L H H H L H X;
                                             ACCESS4
                                                      continue DRAM cycle
                                             ACCESS5
                                                      continue DRAM cycle new request
                                                      continue DRAM cycle
                                        L;
                                             ACCESS6
                                                      can't start same bank cycle wait for precharge
                                              IDLE1
 1
                             HHH
                                    L
                                              IDLE2
 L
                         Н
                           L
                                      Н
                         Н
                           L
                             LH
                                  LLH
                                        Н;
                                             ACCESS1
                                                      start DRAM cycle to same bank
                             LHL
                                    Н;
                                             ACCESS2
 L
                         L
                           L
                                                      continue DRAM cycle
                           Ĺ
                         L
                                        Н;
                                                      continue DRAM cycle: it's write
 L
                                             ACCESS3
                         L
                           Н
                             HHL
                                        Н;
                                             ACCESS4
                                                      continue DRAM cycle
                                                      continue DRAM cycle new request
                           Н
                             HHL
                                      Н Н;
                                             ACCESS5
                           H L H L H H
                         ΗН
                                             ACCESS6
                                                      continue DRAM cycle refresh req
                                        L;
X;
                                              IDLE1
                         Н
                                                      can't start: refresh pending
                                                      wait for precharge
                           HLHHHH
                                        Χ;
                                            REFSTART2
                         Н
                           LLLLHH
                                        Χ;
                                             ACCESS1
                                                      start refresh cycle
                           L L L L H H X;
H H L L H H X;
                         1
                                             ACCESS2
                                                      continue refresh cycle
                         Ē
 L
                                             ACCESS5
                                                      continue refresh cycle
                         HHLLLHH
                                             ACCESS6
                                                      continue refresh cycle
                         HLHHHHH
                                        Χ;
                                              IDLE1
                                                      can't start: refresh precharge
                         Н L Н Н Н L Н Х;
                                                      wait for precharge
                                              IDLE2
```

Figure C-3. 2-CLK DRAM State PAL Equations (Cont'd.)



```
LCHHXXXXXLL
                   H L L L H L H L; ACCESS1 start DRAM cycle
                   LLLLHLLL;
LCLXXXXXXXL
                                   ACCESS2 continue DRAM cycle
LCHLLLHLXL
                    LHHLHLHL;
                                   ACCESS5 continue DRAM cycle: it's read
LCLXXXXXXX
                   H H L L H L H H; ACCESS6 continue DRAM cycle
LCHLLLHXHL
                                   ACCESS1 start DRAM cycle to other bank
                   HLLHLLHH;
LCLXXXXXXXL
                    LLLHLLLH;
                                   ACCESS2 continue DRAM cycle
LCHHXXXLXL
                    LHHHLLLH;
                                   ACCESS5 continue DRAM cycle: it's read
                   H H L H L L L L;
H L H H H L L X;
L C L X X X X X X L L C H H X X X X X L
                                   ACCESS6 continue DRAM cycle
                                    IDLE1
                                          no dram request pending
LCLXXXXXXXL
                   HLHHHLLX;
                                    IDLE2 wait for precharge
LCHHXXXXX
                    HLHHHLLX;
                                    IDLE1
                                          no dram request pending refresh request sampled
LCLXXXXXXX
                   Н Г Н Н Н Н С Х;
                                    IDLE2
LCHLLLHXHH
                   HLHHHHHX;
                                    IDLE1
                                           can't start: refresh pending
LCLXXXXXXX
                    L H L H H H H X; REFSTART2 refresh address set-up
                   H L L L H H X; ACCESS1 start refresh cycle
DESCRIPTION
*** NOTE - SOME VERSIONS OF PALASM WILL CRASH IF THE FILE IS TOO LONG ***
*** IF YOURS DOES, DELETE THIS DESCRIPTION (FROM HERE TO END-OF-FILE) ***
This PAL implements the main state machine of the DRAM controller.
The state machine is described below.
For brevity, the following keywords are used
SELECT = (/CSO * /CS1 * /CS2 * CS3 * CLK)
                        ; chip selects and clock must be active to select
SELECTED = (SELECT + DRAMSELECT) :true if DRAM is now or has been selected
STARTACCESS = (SELECTED * /MUXOE) ; start dram access cycle from idle
The states are defined below and indicated by ROWSEL:Q1:Q0:CLK.
The 4-bit binary number following the state name represents these four signals.
 state REFSTART2 = 0101 ;cycle preceding refresh
   /RASO := ON
                 ;next cycle is first RAS for refresh
    /RAS1 := ON
   MUXOE := MUXOE
                          ;maintain MUXOE state
                                                    lalways
 IMUXOE * RFRQ
  state IDLE1 = 1010 ;waiting for access or refresh
   /RASO := OFF
                          ;both RAS's idle
                                                 12--
    /RAS1 := OFF
   MUXOE := RFRQ
                         ;sample refresh request
|/(MUXOE * RFRQ) |/STARTACCESS
 state IDLE2 = 1011 ; waiting for access or refresh /RASO := (/A2 * STARTACCESS) ; start access /RAS1 := ( A2 * STARTACCESS)
                              ;sample A2 state
   A2REG := A2
   MUXOE := MUXOE
                             ;maintain MUXOE state
                     STARTACCESS
```

Figure C-3. 2-CLK DRAM State PAL Equations (Cont'd.)






Figure C-3. 2-CLK DRAM State PAL Equations (Cont'd.)




Figure C-3. 2-CLK DRAM State PAL Equations (Cont'd.)



DRAM CONTROL PAL

The DRAM Control PAL generates the majority of the control signals for the DRAM circuit. The inputs sample the W/R# and byte-enable outputs of the 80386 as well as status signals from the DRAM State PAL. The outputs generate the four CAS signals, two transceiver control signals, and the signals for the 80386 READY# and Next Address (NA#) logic. Table C-2 contains a description of the outputs and inputs.

The equations for the 3-CLK DRAM Control PAL are shown in Figure C-4; those for the 2-CLK DRAM Control PAL are shown in Figure C-5. A 16R8 PAL is needed to register the CAS signals internally. A 16R4 PAL is needed when external registers drive the CAS signals. For a 16-MHz system, B-series PAL speeds are required.

REFRESH INTERVAL COUNTER PAL

The Refresh Interval Counter PAL, which periodically generates refresh requests to the DRAM State PAL, operates as a counter decremented every CLK cycle. Once the counter reaches a preset value, it resets its value to 255 and activates its RFRQ (refresh request) output. This output remains active until both REFACK (refresh acknowledge) inputs are sampled simultaneously active.

Setup and hold times for RFRQ to the DRAM State PAL are guaranteed even with a large CLK2-to-CLK skew because the Refresh Interval Counter PAL is clocked by the rising edge of CLK, and the RFRQ output is only sampled by the DRAM State PAL at the middle-of-phase CLK2 edge. However, the CLK2-to-CLK and output delays can add up so that the setup and hold times for the REFACK inputs are not met. Therefore, the REFACK inputs are activated for a minimum of four CLK2 periods to ensure deactivation of RFRQ. The exact CLK in which RFRQ is deactivated is not critical.

Table C-3 shows the inputs and outputs of the Refresh Interval Counter PAL. Figure C-6 shows its PAL equations. The same equations are used for both the 3-CLK and 2-CLK designs. A 20X10 PAL is used to implement this counter. For 16-MHz systems, A-series PAL speeds are sufficient.

REFRESH ADDRESS COUNTER PAL

The Refresh Address Counter PAL maintains the address of the next DRAM row to be refreshed. After every refresh cycle, the PAL increments this address. Table C-4 shows the inputs and outputs of the Refresh Address Counter PAL.

PAL equations are shown in Figure C-7. Both the 3-CLK and the 2-CLK design use the same equations. Most DRAMs require only 8-bits or fewer for the refresh row address, so a 16R8 PAL can be used. If necessary, 10 bits of row address can be provided using a 20X10 PAL. For a system operating at any speed, standard-PAL speeds are sufficient.



Table C-2. DRAM Control PAL Pin Description

	Table C-2. Dha	W Control PAL Pill Description	•
	PAL CONTR	OLS	
Name	Connects From	PAL Usage	
CLK2	System CLK2	PAL register clock	
OE	Tied low	Outputs always enabled	
		PAL INPUTS	<u> </u>
Name	Connects From	PAL Usage	Sampled
CLK	System CLK	Indicates clock phase	Every CLK2
BE0# BE1# BE2# BE3#	System Byte-Enables	Used to enable the DRAM CAS signals corresponding to the active bytes	Start-Of-Phase for internal reg. Every CLK2 with exter- nal reg
W/R#	System W/R#	Select write/read	Every CLK2
ROWSEL	DRAM STATE PAL	Initiate DRAM access	Middle-Of-Phase
DISABLE	DRAM STATE PAL MUXOE	Disable controls during refresh	Middle-Of-Phase
		PAL OUTPUTS	
Name	Connects To	PAL Usage	Changes State
CAS0#	DRAM Byte 0		
CAS1#	DRAM Byte 1	Controls DRAM CAS signals	Start-Of-Phase for read active and
CAS2#	DRAM Byte 2	(Separate controls for writes to individual bytes)	read/write inactive Middle-Of-Phase
CAS3#	DRAM Byte 3		for write active
DEN#	Transceiver	Control xcvr enable	Start-Of-Phase
DT/R#	Transceiver	Control xcvr direction	Any time DEN#
RDY	System Ready Logic	Control system ready	Rise: Start-Phase Fall: Middle-Phase
wc	DRAM WE# and System NA# logic	Stores PAL state used only in 3-CLK	Rise: Start-Phase Fall: Middle-Phase
WE#	DRAM WE#	Control DRAM WE# used only in 2-CLK	Rise: Start-Phase Fall: Middle-Phase

```
PAL16R8
                                                              PAL DESIGN SPECIFICATIONS
PART NUMBER: 3-CLK DRAM CONTROL PAL
DRAM CONTROL PAL OF INTERLEAVED DRAM CONTROLLER FOR 80386 SYSTEMS
INTEL, SANTA CLARA, CALIFORNIA
CLK2 CLK BEO BEI BE2 BE3 W%R ROWSEL DISABLE GND
OE CASO CASI DT%R DEN RDY WC CAS2 CAS3 VCC
/CASO := /ROWSEL * CLK * /DT%R * /DISABLE
+ /ROWSEL * WC * RDY * /CLK * /BEO
+ /ROWSEL * /CASO
                                                            ;drop CAS on read
                                                            :drop on write
                                                            ;maintain throughout cycle
                     ;BEx can disappear after CAS drop
;DISABLE must be maintained through last /ROWSEL * CLK
/CAS1 := /ROWSEL * CLK * /DT%R * /DISABLE
+ /ROWSEL * WC * RDY * /CLK * /BE1
+ /ROWSEL * /CAS1
                                                            ;drop CAS on read
                                                            ;drop on write
                                                            ;maintain throughout cycle
/CAS2 := /ROWSEL * CLK * /DT%R * /DISABLE
+ /ROWSEL * WC * RDY * /CLK * /BE2
+ /ROWSEL * /CAS2
                                                            ;drop CAS on read
                                                            ;drop on write
                                                            ;maintain throughout cycle
/CAS3 := /ROWSEL * CLK * /DT%R * /DISABLE
+ /ROWSEL * WC * RDY * /CLK * /BE3
                                                            ;drop CAS on read
                                                            ;drop on write
          + /ROWSEL * /CAS3
                                                            ;maintain throughout cycle
/DT%R := ROWSEL * DEN * /w%R
+ /ROWSEL * /DT%R
+ /DEN * /DT%R
                                                 ;sample W%R when /ROWSEL * DEN
                                                     ;otherwise: maintain state
/DEN := CLK * /ROWSEL * /DISABLE
+ /CLK * /DEN
                                                     ;when CLK: sample ROWSEL
                                                     ;otherwise: maintain state
/WC := DISABLE
                                                     ;keep low if DISABLE
                                                                  or /ROWSEL
or /RDY
         + ROWSEL
         + /RDY
         + /WC * /CLK
                                                                  or already low * /CLK
/RDY := WC * CLK
                                                     ;drop RDY
         + /RDY * /DEN
                                                     ;maintain RDY
```

Figure C-4. 3-CLK DRAM Control PAL Equations



```
FUNCTION TABLE
OE CLK2 CLK BEO BE1 BE2 BE3 W%R CASO CAS1 CAS2 CAS3 DT%R DEN RDY
                                                  ROWSEL DISABLE ;inputs
                                                  WC
                                                                        ;outputs
   CLK2
      CLK
                                  CASO
        RFO
                                    CAS1
           BE1
                                      CAS<sub>2</sub>
                                         CAS3
             BE<sub>2</sub>
                BF3
                                           DT%R
                  W%R
                                              DEN
                     ROWSEL
                                                RDY
                       DISABLE
                                                   WC
                                                                   COMMENTS
 L C H X X X X X H L
L C L X X X X X H H L
L C L X X X X X H H L
L C H X X X X X L H L
L C L X X X X X L L
L C L X X X X X X L L
                                  X
                                   Χ
                                         X X H X L H L H H L
                                                       ; initialize to IDLE
                                                         IDLE: DT%R tracking W%R IDLE: DT%R tracking W%R
                                  ĤΉ
                                      H
                                  H H H H H H L
                                                         IDLE: DT%R tracking W%R
                                  HHHHLHHL
                                 begin read: assert all CAS's
                                                         continue read:
 C H X X X X X L L
C C H X X X X X H H
C C H X X X X X H H
C C H X X X X X X L L
                                 continue read: RDY active
                                                          last read cycle
                                                         CAS's and DEN rise
                                  HHHHLHLL
                                  HHHHHHL
                                                         DT%R and RDY rises
                                  HHHHLHH
                                                          begin write: assert DEN and WE
      HLLHHLHH
                                                          continue write: assert valid CAS's
 T C C C
                                                         continue write: RDY active
                                  HLLHH
                                              LLH
                                  HLLHHLLL
                                                          continue write:
                                  HHHHHLL
                                                          CAS's and DEN rise
      L X X X X X L H L
H X X X X X X L L
L X X X X X L L
                                  HHHHLHH
                                                          RDY rises
 F C
                                      LLLLHH
                                                          begin read: assert all CAS's
                                  LL
                                  LL
                                       LLLLHH
                                                          continue read:
 ĹĊ
      HXXXXXXII
                                  LLLLLLLH
                                                          continue read: RDY active
                                  LLLLLLL
                                                          last read cycle
 L C L X X X X X L L
L C H X X X X X X H
L C L X X X X X X L H
L C L X X X X X X L H
L C L X X X X X X L H
L C L C H X X X X X X L
L C C H X X X X X X L
                                  HHHH
                                            LHL
                                                          CAS's and DEN rise
                                  HHHHXHHL
                                                          RDY rises
                                  H H H H X H H
                                                          begin refresh
                                  HHHHXHHL
                                                          continue refresh
                                 H H H H X H H L
H H H H X H H L
H H H H X H H L
                                                          continue refresh
                                                          last refresh cycle
 LCLXXXXXHL
                                  HHHHXHHL
                                                          IDLE
```

DESCRIPTION

This PAL implements most of the control signals of the DRAM controller.

Figure C-4. 3-CLK DRAM Control PAL Equations (Cont'd.)



```
PAL DESIGN SPECIFICATIONS
PART NUMBER: 2-CLK DRAM CONTROL PAL
DRAM CONTROL PAL OF INTERLEAVED DRAM CONTROLLER FOR 80386 SYSTEMS
DRAFT CONTROL FAL OF INTERCEASED BRAFT CONTROLLER FOR SOSS.

INTEL, SANTA CLARA, CALIFORNIA

CLK2 CLK BEO BE1 BE2 BE3 W%R ROWSEL DISABLE GND

OE CASO CAS1 DT%R DEN RDY WE CAS2 CAS3 VCC
/CASO = /ROWSEL * /DT%R * CLK * /DISABLE ;drop CAS on read
+ /ROWSEL * /DT%R * /DEN ;maintain CAS on read
+ /ROWSEL * /DEN * /BEO * /DISABLE ;activate CAS on write
;BEx must be maintained throughout
            ;DISABLE must be maintained through last /ROWSEL * CLK
/CAS2 = /ROWSEL * /DT%R * CLK * /DISABLE ;drop CAS on read ;maintain CAS on read + /ROWSEL * /DEN * /BE2 * /DISABLE ;activate CAS on write
/CAS3 = /ROWSEL * /DT%R * CLK * /DISABLE ;drop CAS on read ;maintain CAS on read + /ROWSEL * /DEN * /BE3 * /DISABLE ;activate CAS on write
/DT%R := ROWSEL * DEN * /W%R
                                                         ;sample W%R when /ROWSEL * DEN
           + /ROWSEL * /DT%R
+ /DEN * /DT%R
                                                            ;otherwise: maintain state
/DEN := CLK * /ROWSEL * /DISABLE
+ /CLK * /DEN
                                                           ;when CLK: sample ROWSEL
                                                            ;otherwise: maintain state
/WE := /ROWSEL * DT%R * RDY * /DISABLE ;only drops for writes
/RDY := /ROWSEL * /DT%R * /DISABLE * CLK ;drop RDY immediately for read + /WE * CLK ;drop RDY later for write
           + /RDY * /DEN
                                                             ;maintain RDY
```

Figure C-5. 2-CLK DRAM Control PAL Equations






Figure C-5. 2-CLK DRAM Control PAL Equations (Cont'd.)




	Table C-3. Refresh Interv	al Counter PAL Pin Descrip	tion
	PAL CONTROLS		
Name	Connects From	PAL Usage]
CLK	Systems CLK	PAL register clock	
OE	Tied low	Outputs always enabled	
	PAI	. INPUTS	
Name	Connects From	PAL Usage	Sampled
REFACK0# REFACK1#	DRAM RAS0# DRAM RAS1#	Indicates when refresh starts: turns off RFRQ	Every CLK that RFRQ is active
NC0 NC1 NC2 NC3 NC4 NC5 NC6	Not connected	Not used	Never
	PAL	OUTPUTS	
Name	Connects To	PAL Usage	Changes State
RFRQ	DRAM STATE RFRQ	Latch refresh request	Any CLK
Q0 Q1 Q2 Q3 Q4 Q5 Q6 Q7 Q8	Not connected	Implements up to 9-bit modulo counter	Any CLK



```
PAI 20X10
                                    PAL DESIGN SPECIFICATIONS
PART NUMBER: 16 MHz REFRESH INTERVAL COUNTER PAL
REFRESH INTERVAL PAL OF INTERLEAVED DRAM CONTROLLER FOR 80386 SYSTEMS
INTEL, SANTA CLARA, CALIFORNIA
CLK REFACKO REFACKI NC NC NC NC NC NC NC NC OC GND OE RFRQ NC Q0 Q1 Q2 Q3 Q4 Q5 Q6 Q7 VCC
      /RFRQ * Q7 * Q6 * Q5 * Q4 * Q3 * Q2 * Q1 * Q0 ; raise at 255
+ RFRQ * /REFACKO * /REFACK1 ; clear when both ACKs low
:+: /RFRQ
      /Q0 ; least-significant bit of counter + /Q7 * /Q6 * /Q5 * /Q4 * /Q3 ; set at 7 or less :+: VCC ; else decrement
/Q1 :=
      /01 + /07 * /06 * /05 * /04 * /03; set at 7 or less :+: /07 * /06 * /05 * /04 * /03; set at 7 or less ; else decrement
```

Figure C-6. Refresh Interval Counter PAL Equations





DESCRIPTION

This PAL implements the counter to determine when distributed refresh cycles should be run. This counter counts intervals of 249 clocks which is just under 15 uS at 16 MHz.

The counter counts backwards from 255 to 7. The clock after the counter reaches 7, the counter is set to 255 and will then continues to decrement. Also when 7 is hit, RFRQ is activated until both REFACKO and REFACKI are simultaneously sampled low.

Figure C-6. Refresh Interval Counter PAL Equations (Cont'd.)



Table C-4. Refresh Address Counter PAL Pin Description

	Tubic O 4. Helicoli A	duless Counter PAL PIII Descri	puşii
	PAL CONTRO	OLS	
Name	Connects From	PAL Usage	
CLOCK	RFRQ & MUXOE#	PAL register clock	
OE	RFRQ & MUXOE#	outputs enable on refresh	1
		PAL INPUTS	
Name	Connects From	PAL Usage	Sampled
NC0 NC1 NC2 NC3 NC4 NC5 NC6	Not connected	Not used	Never
		PAL OUTPUTS	
Name	Connects To	PAL Usage	Changes State
Q0 Q1 Q2 Q3 Q4 Q5 Q6 Q7	Muxed Addr 0 Muxed Addr 1 Muxed Addr 2 Muxed Addr 3 Muxed Addr 4 Muxed Addr 5 Muxed Addr 6 Muxed Addr 7	Implements 8-bit counter	Any Clock

```
PAL16R8
                                                             PAL DESIGN SPECIFICATIONS
PART NUMBER: REFRESH ADDRESS COUNTER PAL
REFRESH ADDRESS PAL OF INTERLEAVED DRAM CONTROLLER FOR 80386 SYSTEMS
INTEL, SANTA CLARA, CALIFORNIA
CLOCK NC NC NC NC NC NC NC NC GND
OE AO A1 A2 A3 A4 A5 A6 A7 VCC
/A0 := A0
                                    :least significant bit of 8-bit counter
/A1 := A1 * A0
          +/A1 */A0
/A2 := A2 * A1 * A0
          +/A2 */A1
+/A2 */A0
/A3 := A3 * A2 * A1 * A0
          +/A3 */A2
+/A3 */A1
          +/A3 */A0
/A4 := A4 * A3 * A2 * A1 * A0
          +/A4 */A3
          +/A4 */A2
+/A4 */A1
          +/A4 */A0
/A5 := A5 * A4 * A3 * A2 * A1 * A0
          +/A5 */A4
+/A5 */A3
+/A5 */A2
+/A5 */A1
+/A5 */A0
/A6 := A6 * A5 * A4 * A3 * A2 * A1 * A0
          +/A6 */A5
+/A6 */A4
          +/A6 */A3
          +/A6 */A2
+/A6 */A1
+/A6 */A0
/A7 :=
            A7 * A6 * A5 * A4 * A3 * A2 * A1 * A0; most-significant bit of counter
          A7 * A6
+/A7 */A6
+/A7 */A5
+/A7 */A4
+/A7 */A2
+/A7 */A1
          +/A7 */A0
```

Figure C-7. Refresh Address Counter PAL Equations






Figure C-7. Refresh Address Counter PAL Equations (Cont'd.)



TIMING PARAMETERS

Figure C-8 shows the timing of signals for DRAM read and write cycles. Table C-5 displays the worst-case timing parameters for six DRAM circuits, each of which uses a different type of DRAM.




Figure C-8. DRAM Circuit Timing Diagram

Chip Symbol	10 Description	From	To		Max 264-8	Min M 51C64		n Max 256-12	Min 51c25	Max 6-15		Max 54-15	Min 51025		
82384 t1	O CLK2 period	CLK2	CTK5 /		32	31	32 41) 42	31	32	31	32	40	42	
		CLK2	/ CLK2 / / CLK2 /												
		CLK2													
		CLK2													
		CTK5 \	CTK5 /												
82384 twrtWA11	O CLKperiod(s) rd WaitState O CLKperiod(s) wt WaitState	CTK5 \	CTK5 /	0 62	0 64		0 (84	62 62	64 64	62 62	64 64	80 80	84 84	
82384 tBAK2BAI 386 t12	O CLKperiod(s) back-to-back O write data out-delay		' CLK2 / ' CLK2 / '386 Data<	62 1	64 50		64 1 60 50 1		124	128 50	124	128 50	160	168 50	
386 * t21	O read data set-up	CLK2 / 386 Data	386 Data>	0	10		10 (10	0	10	0	10	0	10	
386 t22 386+HUX t6+tHUX	O read data hold O addr fr 386 thru LatchMux	CTK5 /		3	999 46		99 2 46 3		3	999 46	2 3	999 46	2 3	999 46	
PAL P	O clock to PAL outputs	CTK5 \	ROW Sel\ ROW Sel/ ROW Sel\	0	12	0	12 (12	0	12	0	12	0	12	
PALOFREG Q	O clock to PAL or REG outpt	CTK5 / CTK5 / CTK5 / CTK5 /	RAS# \ RAS# / RAS# \ RAS# /	0	12	0	12 (12	0	12	4	10	0	12	٠
Register R	O clock to register output	CTK5 \ CTK5 \ CTK5 \ CTK5 \ CTK5 \	CAS# / CAS# \ CAS# / CAS# \	0	12	0 1	12 0	12	0	12	4	10	0	12	
PAL+NAND W	O pal and write logic delay	CTK5 / CTK5 / CTK5 /	WE# /	2	18	2 1	18 2	18	2	18	2	18	2	18	
Transcvr tXCVR	O transcvr prop in-to-out	rd data< DramData> 386 Data<	386 Data< 386 Data> wrt data< DramData>	2	7	0	0 2	7	2	7	2	7	2	7	

Table C-5. DRAM Circuit Timing Parameters

386 DRAM Controller

TIMING PARAMETERS

Chip	Symbol	10 Description	From To	Min Max 51C64-8	Min Max 51C64-10	Min Max 51C256-12	Min Max 51C256-15	Min Max 2164-15	Min Max 51C256-20
DRAM	tRAS	I RAS# pulse width	RAS# \ RAS# / RAS# \ RAS# /	80 9999	100 9999	120 9999	150 9999	150 9999	200 9999
DRAM	tRC	I random read/write cycle	RAS# \ RAS# \ RAS# \ RAS# \	140 9999	160 9999	200 9999	245 9999	260 9999	315 9999
DRAM	tRP	I RAS# precharge time	RAS# / RAS# \ RAS# / RAS# \	50 9999	50 9999	70 9999	85 9999	100 9999	105 9999
DRAM	tCSH	I CAS# hold time	RAS# \ CAS# / RAS# \ CAS# /	80 9999	100 9999	120 9999	150 9999	150 9999	200 9999
DRAM	tCAS(R)	I CAS# pulse width(rd cycl)	CAS# \ CAS# /	15 9999	20 9999	25 9999	30 9999	85 9999	35 9999
DRAM	tCAS(W)		CAS# \ CAS# /	25 9999	30 9999	25 9999	30 9999	85 9999	35 9999
DRAM	tWRP	I write to RAS# precharge	WE# / RAS# \ WE# / RAS# \	-30 9999	-30 9999	10 9999	10 9999	-30 9999	10 9999
DRAM	tRWH	I RAS# to write hold time	RAS# \ WE# \	0 9999	0 9999	15 9999	20 9999	0 9999	25 9999
DRAM	tASR	I row address set-up time	row< RAS# \	0 9999	0 9999	0 9999	0 9999	0 9999	0 9999
			row< RAS# \					•	•
DRAM	tRAH	I row address hold time	RAS# \ column< RAS# \ column<	15 9999	15 9999	15 9999	20 9999	20 9999	25 9999
DRAM	tCP	I CAS# precharge	CAS# / CAS# \ CAS# / CAS# \	10 9999	10 9999	10 9999	10 9999	25 9999	10 9999
DRAM	tCRP	I CAS# to RAS# precharge	CAS# / RAS# \ CAS# / RAS# \ CAS# / RAS# \	-20 9999	-20 9999	-20 9999	-20 9999	-20 9999	-20 9999
DRAM	# tRCD	I RAS# to CAS# delay	RAS# \ CAS# \ RAS# \ CAS# \	30 9999	30 9999	30 9999	35 9999	30 9999	40 9999
DRAM	tASC	I column address set-up	column< CAS# \ column< CAS# \	0 9999	0 9999	5 9999	5 9999	0 9999	5 9999
DRAM	tCAH	I column address hold	CAS# \ DramAddr< CAS# \ DramAddr<	10 9999	10 9999	15 9999	20 9999	25 9999	25 9999
DRAM	tAR	I column addr hold fr RAS#	RAS# \ DramAddr< RAS# \ DramAddr<	40 9999	40 9999	60 9999	70 9999	90 9999	80 9999
DRAM	* tON	I output buffer turn on	CAS# \ rd data<	20 9999	20 9999	25 9999	30 9999	85 9999	35 9999
DRAM	* tOFF	I output buffer turn off	CAS# / wrt data<	20 9999	20 9999	20 9999	25 9999	30 9999	30 9999
DRAM	* tRAC	I access time from RAS#	RAS# \ rd data<	80 9999	100 9999	120 9999	150 9999	150 9999	200 9999
DRAM	* tCAC	I access time from CAS#	CAS# \ rd data<	20 9999	20 9999	25 9999	30 9999	85 9999	35 9999
DRAM	* tCAA	I access time fr column adr	column< rd data<	45 9999	55 9999	55 9999	70 9999	85 9999	90 9999
DRAM	tRSH(R)	I RAS# hold time (rd cycle)	CAS# \ RAS# /	10 9999	10 9999	10 9999	10 9999	85 9999	10 9999
DRAM	tRCS	I read command set-up time I column address to RAS#	RAS# \ rd data< column< RAS# /	0 9999 45 9999	0 9999	0 9999	0 9999	0 9999	0 9999
DRAM Dram	tCAR tRCH	I read com hold ref to CAS#	column< RAS# / CAS# / WE# \	0 9999	55 9999 0 9999	55 9999	70 9999	85 9999	90 9999
DRAM	tRRH	I read com hold ref to RAS#	RAS# / WE# \	10 9999	10 9999	0 9999 10 9999	0 9999	5 9999	0 9999
DRAM	tRSH(W)	I RAS# hold time (wrt cycl)	CAS# \ RAS# /	35 9999	35 9999	25 9999	10 9999 30 9999	20 9999 85 9999	10 9999 35 9999
DRAM	tRWL	I write command to RAS#	WE# \ RAS# /	25 9999	30 9999	25 9999	30 9999	40 9999	35 9999
DRAM	tCWL	I write command to CAS#	WE# \ CAS# /	25 9999	30 9999	25 9999	30 9999	40 9999	35 9999
DRAM	tWP	I write command pulse width	WE# \ WE# /	20 9999	20 9999	20 9999	25 9999	30 9999	30 9999
DRAM	twcs	I write command set up time	WE# \ CAS# \	0 9999	0 9999	0 9999	0 9999	10 9999	0 9999
DRAM	tWCH	I write command hold time	CAS# \ WE# /	25 9999	30 9999	25 9999	30 9999	30 9999	35 9999
DRAM	tDS	I data in set-up time	wrt data< CAS# \	0 9999	0 9999	0 9999	0 9999	0 9999	0 9999
DRAM	tDH	I data in hold time	CAS# \ DramData>	20 9999	20 9999	20 9999	25 9999	30 9999	30 9999

Table C-5. DRAM Circuit Timing Parameters (Cont'd.)

TIMING CALCULATIONS

			TIMIN	G CAL	CU	LAT	1 0	NS													
Chip	Symbol	IO Desc	ription			From		To			Max C64-8		Max 64-10		Max 56-12		Max 56-15		Max 64 - 15		Max 56-20
DRAM +Q	tRAS +trdWAI		ulse width +t1	ı +t1	+t1		-0			80	9999	100	9999	120	9999	150	9999	150	9999	200	9999
+0	+twrtWA	IT+t1	+t1	+t1	+t1	RAS#	۱.	RAS#	1	112	140	112	140	148	180	174	204	180	198	228	264
						RAS#	١	RAS#	/	174	204	174	204	228	264	174	204	180	198	228	264
DRAM +Q	tRC	random AK+trdWA	read/writ	e cycle +t1	+t1		+t1	-(140	9999	160	9999	200	9999	245	9999	260	9999	315	9999
				***	***	RAS#		RAS#		174	204	174	204	308	348	298	332	304	326	388	432
+0	+tBAK2B	AK+twrtW	NIT+t1	+t1	+t1	RAS#	+t1 \	RAS#		236	268	236	268	388	432	298	332	304	326	388	432
DRAM	tRP	RAS# D	echarge t	ine						50	9999	50	9999	70	9999	95	9999	100	9999	105	9999
+0	+tBAK2B/	NK-Q				RAS#	1		١	50	76	50		148			140		134	148	
+Q	+tBAK2B/	lK∙Q				RAS#	/	RAS#	\	50	76	50	76	148	180	112	140	118	134	148	180
DRAM +R	tCSH +trdWAI1		old time +t1	+t1	+t1		- Q			80	9999	100	9999	120	9999	150	9999	150	9999	200	9999
						RAS#	1	CAS#	1	112	140	112	140	148	180	174	204	180	198	228	264
+R	+twrtWA	11+t1	+t1	+t1	+t1	RAS#	٠٥	CAS#	/	174	204	174	204	228	264	174	204	180	198	228	264
DRAM	tCAS(R)	CAS# D	ılse width	(rd cycl)						15	9999	20	9999	25	9999	30	9999	85	9999	35	9999
+R	+trdWAI1		+t1	-R		CAS#	١	CAS#	/	50	76	50		68	96		140		134	148	
DRAM			lse_width	(WFt Cyc)							9999		9999		9999		9999		9999		9999
+R	+twrtWA1	1+11	-R			CAS#	`	CAS#	/	81	108	81	108	108	. 138	81	108	87	102	108	138
DRAM	tWRP		o RAS# pr	echarge							9999	-30	9999	10	9999	10	9999	-30	9999	10	9999
+Q +Q	+t1 +tBAK2BA	-W	17-+1	-u		WE#	/	RAS# RAS#	Ņ	13 74	42 107	13	42	22	52	13	42	17	40	22	52
••	TIDAKEDA	KT CHI CHA	11-01	•		WEA	′	KW2#	١	14	107	74	107	180	222	136	171	140	169	180	222
DRAM	tRWH		write ho	ld time							9999		9999		9999		9999		9999		9999
+₩	+t1	+t1	- Q			RAS#	١	WE#	١	52	82	52	82	70	102	52	82	54	78	70	102
DRAM	tASR		ress set-							0	9999	0	9999	0	9999	0	9999	0	9999	0	9999
+0	+t1	+t1	- t6+tMU					RAS#	,	16	73	16	73	34	93	16	73	20	71	34	93
+0	+tBAK2BA	K+TFCWAI	T -t6+tMU	•		г	o₩<	RAS#	١	16	73	16	73	114	177	140	201	144	199	194	261
DRAM	tRAH		ress hold	time							9999		9999		9999	20	9999		9999	25	9999
+ tMUX + tMUX	+P +P	+t1 +t1	- Q - Q			RAS# RAS#	,	colum		23 23	55 55	23	55	32	65	23	55	25	51	32	65
→ LMUX	78	+11	٠.٠			rus#	١	cotum	114	23	22	23	55	32	65	23	55	25	51	32	65

Table C-5. DRAM Circuit Timing Parameters (Cont'd.)

		Ţ		DRAM Cont			1 0	N S														
Chip	Symbol	IO Descr	iption			From		To			Max C64-8		Max 64-10		Max 56-12		Max 56-15		Max 64 - 15	Min 5102	Max 56-20	
DRAH	tCP	CAS# pre	echarge							10	9999	10	9999	10	9999	10	9999	25	9999	10	9999	
+R	+t1	+t1 '	+t1	+tBAK2BA	K-R																	
* +R	+t1	+t1	+tBAK2BA	NK-R		CAS#	/	CAS#	,		172 140		172 140	268 228	306 264		236 204		230 198		306 264	
DRAM	tCRP	CAS# to	RAS# pred	harne						. 20	9999	- 20	9999	.20	9999	- 20	9999	-20	9999	-20	9999	
+Q	- R					CAS#	1	RAS#	١	-12	12	-12		- 12		-12	12	-6	6	-12	12	
+0	+tBAK2BAI					CAS#	1	RAS#	١	50	76	50			180		140		134		180	
+0	+tBAK2BAI	(-R				CAS#	1	RAS#	4	50	76	50	76	148	180	112	140	118	134	148	180	
DRAM	# tRCD +t1	RAS# to	CAS# dela	y							9999		9999		9999		9999		9999		9999 96	
+R +R	+t1	+t1	-u +t1	٠0		RAS#		CAS# CAS#	'	50 81	76 108	50 81		68 108	96 138	50 81	76 108	56 87	70 102	68 108	138	
.,,				•			•	CA.38	`	٠.		٠.				٠.		•	,02		130	
DRAM			ddress se	t-up							9999		9999		9999		9999		9999		9999	
+R	+t1	-Р	- tMUX					CAS#	١	8	40	8		17		8	40	12	38	17	50	
+R	+t1	+t1	-р	- tNUX		COLL	mn<	- CAS#	`	39	72	39	72	57	92	39	72	43	70	57	92	
DRAM	tCAH	column a	ddress ho	old						10	9999	10	9999	15	9999	20	9999	25	9999	25	9999	
+tHUX	+P	+t1	+t1	+t1	-R																	
+ t MUX	+P	+t1	+t1	-R		CAS#		DramAddi DramAddi		85 54	119 87	85 54	119 87		149 107	85 54	119 87	87 56	115 83		149 107	
DRAM	tAR	column a	iddr hold	fr RAS#						40	9999	40	9999	60	9999	70	9999	90	9999	80	9999	
+tMUX	+P	+t1	+t1	+t1	+t1	RAS#	+t1 \	-Q DramAddi	٠<	147	183	147	183	192	233	147	183	149	179	192	233	
+tMUX	+P	+t1	+t1	+t1	+t1	RAS#	+t1 \	-Q DramAddi	٠<	147	183	147	183	192	233	147	183	149	179	192	233	
DRAM - txcvr	* tON -t21	+trdWAII	uffer tur	n on +t1	-R					20	9999	20	9999	25	9999	30	9999	85	9999	35	9999	
TACTA		· Crawns			•	CAS#	١	rd data	>	33	62	40	64	51	82	95	126	97	122	131	166	
DRAM	* tOFF	output b	uffer tur	n off						20	9999	20	9999	20	9999	25	9999	30	9999	30	9999	
+tXCVR	+t12	+t1 [']	+tBAK2BA	K-R		CAS#	/	wrt data	>۱	84	153	82	146	191	267	146	217	148	213	191	267	
DRAM	* tRAC	access t	ime from	RAS#						80	9999	100	9999	120	9999	150	9999	150	9999	200	9999	
- txcvr	· t21	+trdWAIT	+t1	+t1	+t1		+t1	-0		05	•24	•00	420	474	•//	457	100	450	407	211	250	
						RAS#	`	rd data	>	95	126	102	128	131	166	157	190	159	186	211	250	
DRAM	* tCAC	access t	ime from	CAS#						20	9999	20	9999	25	9999	30	9999	85	9999	35	9999	
- t XCVR	-t21	+trdWAIT	+t1	+t1	- R							4.5					424					
						CAS#	٠,١	rd data	١<	33	62	40	64	51	82	95	126	97	122	131	166	

Table C-5. DRAM Circuit Timing Parameters (Cont'd.)

386 DRAM Controller

TINING CALCULATIONS

Chip	Symbol	10 Description	From	To	Min Max 51C64-8	Min Max 51C64-10	Min Max 51C256-12	Min Max 51C256-15	Min Max 2164-15	Min Max 51C256-20
DRAM 1	tCAA -t21	access time fr column adr +trdWAIT +t1 +t1	+t1 -P column<	-tMU) rd data<	45 9999 (53 90	55 9999 60 92	55 9999 80 '120	70 9999 115 154	85 9999 115 154	90 9999 160 204
DRAM +Q	tRSH(R) +trdWAI1	RAS# hold time (rd cycle) +t1 +t1 -R	CAS# \	RAS# /	10 9999 50 76	10 9999 50 76	10 9999 68 96	10 9999 112 140	85 9999 118 134	10 9999 148 180
DRAM - txcvr	tRCS -t21	read command set-up time +trdWAIT +t1 +t1	+t1 +t1 RAS# \	-Q rd data<	0 9999 95 126	0 9999 102 128	0 9999 131 166	0 9999 157 190	0 9999 159 186	0 9999 211 250
DRAM +Q	tCAR +trdWAI1	column address to RAS# +t1 +t1 +t1	-P -tM column<		45 9999 70 104	55 9999 70 104	55 9999 97 134	70 9999 132 168	85 9999 136 166	90 9999 177 218
DRAM +W	tRCH +t1	read com hold ref to CAS# +t1 +tBAK2BAK-R	CAS# /	WE# \	0 9999 114 146	0 9999 114 146	0 9999 230 270	0 9999 176 210	5 9999 178 206	0 9999 230 270
DRAM +W	tRRH +t1	read com hold ref to RAS# +t1 +tBAK2BAK-Q	RAS# /	WE# \	10 9999 114 146	10 9999 114 146	10 9999 230 270	10 9999 176 210	20 9999 178 206	10 9999 230 270
DRAM +Q	tRSH(W) +twrtWAI	RAS# hold time (wrt cycl) T+t1 -R	CAS# \	RAS# /	35 9999 81 108	35 9999 81 108	25 9999 108 138	30 9999 81 108	85 9999 87 102	35 9999 108 138
DRAM +Q	tRWL +twrtWAI	write command to RAS# T+t1 +t1 -W	WE# \	RAS# /	25 9999 106 138	30 9999 106 138	25 9999 142 178	30 9999 106 138	40 9999 110 136	35 9999 142 178
DRAM +R	tCWL +twrtWAI	write command to CAS# T+t1 +t1 -W	WE# \	CAS# /	25 9999 106 138	30 9999 106 138	25 9999 142 178	30 9999 106 138	40 9999 110 136	35 9999 142 178
DRAM +W	tWP +t1	write command pulse width +t1 +t1 -W	WE# \	VE# /	20 9999 77 112	20 9999 77 112	20 9999 104 142	25 9999 77 112	30 9999 77 112	30 9999 104 142
DRAM +R	tWCS +t1	write command set-up time -W	WE# \	CAS# \	0 9999 13 42	0 9999 13 42	0 9999 22 52	0 9999 13 42	-10 9999 17 40	0 9999 22 52
DRAM +W	tWCH +t1	write command hold time +t1 -R	CAS# \	WE# /	25 9999 52 82	30 9999 52 82	25 9999 70 102	30 9999 52 82	30 9999 54 78	35 9999 70 102

Table C-5. DRAM Circuit Timing Parameters (Cont'd.)

386 DRAM Controller

TIMING CALCULATIONS

Chip	Symbol	10 Description	From	To	Min Max 51C64-8		Min Max 51C256-12		Min Max 2164-15	Min Max 51C256-20
DRAM +R	tDS +t1	data-in set-up time +t1 -t12 -tXCVR	wrt data<	CAS# \	0 9999 5 73	0 9999 12 75	0 9999 23 93	0 9999 5 73	0 9999 9 71	0 9999 23 93
DRAM +tXCVR	tDH +t12	data-in hold time +t1 +twrtWAIT+t1	-R	D===0-4->	20 9999	20 9999	20 9999	25 9999	30 9999	30 9999

Table C-5. DRAM Circuit Timing Parameters (Cont'd.)











DOMESTIC SALES OFFICES

ALABAMA

†Intel Corp. 5015 Bradford Dr., #2 Huntsville 35805 Tel: (205) 830-4010

ARIZONA

†Intel Corp. 11225 N. 28th Dr., #D214 Phoenix 85029 Tel: (602) 869-4980

Intel Corp. 1161 N. El Dorado Place Suite 301 Tucson 85715 Tel: (602) 299-6815

CALIFORNIA

†Intel Corp. 21515 Vanowen Street Suite 116 Canoga Park 91303 Tel: (818) 704-8500

†Intel Corp. 2250 E. Imperial Highway Suite 218 El Segundo 90245 Tel: (213) 640-6040

Intel Corp. 1510 Arden Way, Suite 101 Sacramento 95815 Tel: (916) 920-8096

†Intel Corp. 4350 Executive Drive Suite 105 San Diego 92121 Tel: (619) 452-5880

Intel Corp.*
400 N. Tustin Avenue
Suite 450
Santa Ana 92705
Tel: (714) 835-9642
TWX: 910-595-1114

fintel Corp.* San Tomas 4 2700 San Tomas Expressway Santa Clara, CA 95051 Tel: (408) 986-8086 TWX: 910-338-0255

COLORADO

Intel Corp. 4445 Northpark Drive Suite 100 Colorado Springs 80907 Tel: (303) 594-6622

†Intel Corp.* 650 S. Cherry St., Suite 915 Denver 80222 Tel: (303) 321-8086 TWX: 910-931-2289

CONNECTICUT

†Intel Corp. 26 Mill Plain Road Danbury 06811 Tel: (203) 748-3130 TWX: 710-456-1199

FLORIDA

†Intel Corp. 242 N. Westmonte Dr. Suite 105 Altamonte Springs 32714 Tel: (305) 869-5588

Intel Corp. 6363 N.W. 6th Way, Suite 100 Ft. Lauderdale 33309 Tel: (305) 771-0600 TWX: 510-956-9407

Intel Corp. 11300 4th Street North Suite 170 St. Petersburg 33702 Tel: (813) 577-2413

GEORGIA

†Intel Corp. 3280 Pointe Parkway Suite 200 Norcross 30092 Tel: (404) 449-0541

ILLINOIS

Intel Corp.* 300 N. Martingale Road, Suite 400 Schaumburg 60173 Tel: (312) 310-8031

INDIANA

†Intel Corp. 8777 Purdue Road Suite 125 Indianapolis 46268 Tel: (317) 875-0623

IOWA

Intel Corp. St. Andrews Building 1930 St. Andrews Drive N.E. Cedar Rapids 52402 Tel: (319) 393-5510

KANSAS

†Intel Corp. 8400 W. 110th Street Suite 170 Overland Park 66210 Tel: (913) 345-2727

MARYLAND

Intel Corp.*
7321 Parkway Drive South Suite C Hanover 21076 Tel: (301) 796-7500 TWX: 710-862-1944

Intel Corp. 5th Floor 7833 Walker Drive Greenbelt 20770 Tel: (301) 441-1020

MASSACHUSETTS

†Intel Corp.* Westford Corp. Center 3 Carlisle Road Westford 01886 Tel: (617) 692-3222 TWX: 710-343-6333

MICHIGAN

†Intel Corp. 7071 Orchard Lake Road Suite 100 West Bloomfield 48033 Tel: (313) 851-8096

MINNESOTA

Intel Corp. 3500 W. 80th St., Suite 360 Bloomington 55431 Tel: (612) 835-6722 TWX: 910-576-2867

MISSOURI

Intel Corp. 4203 Earth City Expressway Suite 131 Earth City 63045 Tel: (314) 291-1990

NEW JERSEY

Intel Corp.*
Parkway 109 Office Center
328 Newman Springs Road
Red Bank 07701
Tel: (201) 747-2233

Intel Corp. 280 Corporate Center 75 Livingston Avenue First Floor Roseland 07068 Tel: (201) 740-0111

NEW MEXICO

Intel Corp. 8500 Menual Boulevard N.E. Suite B 295 Albuquerque 87112 Tel: (505) 292-8086

NEW YOR

Intel Corp. 127 Main Street Binghamton 13905 Tel: (607) 773-0337

Intel Corp.*
850 Cross Keys Office Park Fairport 14450 Tel: (716) 425-2750 TWX: 510-253-7391

Intel Corp.* 300 Motor Parkway Hauppauge 11787 Tel: (516) 231-3300 TWX: 510-227-6236

Intel Corp. Suite 2B Hollowbrook Park 15 Myers Corners Road Wappinger Falls 12590 Tel: (914) 297-6161 TWX: 510-248-0060

NORTH CAROLINA

Intel Corp. 5700 Executive Center Drive Suite 213 Charlotte 28212 Tel: (704) 568-8966

†Intel Corp. 2700 Wycliff Road Suite 102 Raleigh 27607 Tel: (919) 781-8022

оню

Intel Corp.*
3401 Park Center Drive
Suite 220
Dayton 45414
Tel: (513) 890-5350
TWX: 810-450-2528

Intel Corp.*
25700 Science Park Dr., Suite 100
Beachwood 44122
Tel: (216) 464-2736
TWX: 810-427-9298

OKLAHOMA

Intel Corp. 6801 N. Broadway Suite 115 Oklahoma City 73116 Tel: (405) 848-8086

OREGON

†Intel Corp. 15254 N.W. Greenbrier Parkway, Bldg. B Beaverton 97006 Tel: (503) 645-8051 TWX: 910-467-8741

PENNSYLVANIA

Intel Corp. 1513 Cedar Cliff Drive Camp Hill 17011 Tel: (717) 737-5035

Intel Corp.* 455 Pennsylvania Avenue Fort Washington 19034 Tel: (215) 641-1000 TWX: 510-661-2077

Intel Corp.* 400 Penn Center Blvd., Suite 610 Pittsburgh 15235 Tel: (412) 823-4970

PUERTO RICO

Intel Microprocessor Corp. South Industrial Park P.O. Box 910 Las Piedras 00671 Tel: (809) 733-8616

TEXAS

†Intel Corp. 313 E. Anderson Lane Suite 314 Austin 78752 Tel: (512) 454-3628

†Intel Corp.* 12300 Ford Road Suite 380 Dallas 75234 Tel: (214) 241-8087 TWX: 910-860-5617

Intel Corp.*
7322 S.W. Freeway
Suite 1490
Houston 77074
Tel: (713) 988-8086
TWX: 910-881-2490

UTAH

Intel Corp. 5201 Green Street Suite 290 Murray 84123 Tel: (801) 263-8051

VIRGINIA

†Intel Corp. 1603 Santa Rosa Road Suite 109 Richmond 23288 Tel: (804) 282-5668

WASHINGTON

Intel Corp. 155-108 Avenue N.E. Suite 386 Bellevue 98004 Tel: (206) 453-8086 TWX: 910-443-3002

Intel Corp. 408 N. Mullan Road Suite 102 Spokane 99206 Tel: (509) 928-8086

WISCONSIN

†Intel Corp. 330 S. Executive Dr. Suite 102 Brookfield 53005 Tel: (414) 784-8087 FAX: (414) 796-2115

CANADA

BRITISH COLUMBIA

Intel Semiconductor of Canada, Ltd. 4585 Canada Way, Suite 202 Burnaby V5G 4L6 Tel: (604) 298-0387 FAX: (604) 298-8234

ONTARIO

†Intel Semiconductor of Canada, Ltd. 2650 Queensview Drive Suite 250 Ottawa K2B 8H6 Tel: (613) 829-9714 TLX: 053-4115

†Intel Semiconductor of Canada, Ltd. 190 Attwell Drive Suite 500 Rexdale M9W 6H8 Tel: (416) 675-2105 TLX: 06993574 FAX: (416) 675-2438

QUEBEC

†Intel Semiconductor of Canada, Ltd. 620 St. Jean Boulevard Pointe Claire H9R 3K3 Tel: (514) 694-9130 TWX: 514-694-9134



DOMESTIC DISTRIBUTORS

Arrow Electronics, Inc. 1015 Henderson Road Huntsville 35805 Tel: (205) 837-6955

†Hamilton/Avnet Electronics 4940 Research Drive Huntsville 35805 Tel: (205) 837-7210 TWX: 810-726-2162

Pioneer/Technologies Group Inc. 4825 University Square Huntsville 35805 Tel: (205) 837-9300 TWX: 810-726-2197

ARIZONA

†Hamilton/Avnet Electronics 505 S. Madison Drive Tempe 85281 Tel: (602) 231-5100 TWX: 910-950-0077

Kierulff Electronics, Inc. 4134 E. Wood Street Phoenix 85040 Tel: (602) 437-0750 TWX: 910-951-1550

Wyle Distribution Group 17855 N. Black Canyon Highway Phoenix 85023 Tel: (602) 866-2888

CALIEODNIA

Arrow Electronics, Inc. 19748 Dearborn Street Chatsworth 91311 Tel: (818) 701-7500 TWX: 910-493-2086

Arrow Electronics, Inc. 1502 Crocker Avenue Hayward 94544 Tel: (408) 487-4600

Arrow Electronics, Inc. 9511 Ridgehaven Court San Diego 92123 Tel: (619) 565-4800 TLX: 888064

†Arrow Electronics, Inc. 521 Weddell Drive Sunnyvale 94086 Tel: (408) 745-6600 TWX: 910-339-9371

Arrow Electronics, Inc. 2961 Dow Avenue Tustin 92680 Tel: (714) 838-5422 TWX: 910-595-2860

†Avnet Electronics 350 McCormick Aver Costa Mesa 92626 Tel: (714) 754-6051 TWX: 910-595-1928

Hamilton/Avnet Electronics 1175 Bordeaux Drive Sunnyvale 94086 Tel: (408) 743-3300 TWX: 910-339-9332

†Hamilton/Avnet Electronics 4545 Viewridge Avenue San Diego 92123 Tel: (619) 571-7500 TWX: 910-595-2638

†Hamilton/Avnet Electronics 20501 Plummer Street Chatsworth 91311 Tel: (818) 700-6271 TWX: 910-494-2207

†Hamilton/Avnet Electronics 4103 Northgate Boulevard Sacramento 95834 Tel: (916) 920-3150

†Hamilton/Avnet Electronics 3002 G Street Ontario 91311 Tel: (714) 989-9411

Hamilton/Avnet Electronics 19515 So. Vermont Avenue Torrance 90502 Tel: (213) 615-3909 TWX: 910-349-6263

Hamilton Electro Sales 9650 De Soto Avenue Chatsworth 91311 Tei: (818) 700-6500

CALIFORNIA (Cont'd)

†Hamilton Electro Sales 10950 W. Washington Blvd. Culver City 90230 Tel: (213) 558-2458 TWX: 910-340-6364

Hamilton Electro Sales 1361 B West 190th Street Gardena 90248 Tel: (213) 558-2131

†Hamilton Electro Sales 3170 Pullman Street Costa Mesa 92626 Tel: (714) 641-4150 TWX: 910-595-2638

Kierulff Electronics, Inc. 10824 Hope Street Cypress 90430 Tel: (714) 220-6300

†Kierulff Electronics, Inc. 1180 Murphy Avenue San Jose 95131 Tel: (408) 971-2600 TWX: 910-379-6430

†Kierulff Electronics, Inc. 14101 Franklin Avenue Tustin 92680 Tel: (714) 731-5711 TWX: 910-595-2599

†Kierulff Electronics, Inc. 5650 Jillson Street Commerce 90040 Tel: (213) 725-0325 TWX: 910-580-3666

Wyle Distribution Group 26560 Agoura Street Calabasas 91302 Tel: (818) 880-9000 TWX: 818-372-0232

†Wyle Distribution Group 124 Maryland Street El Segundo 90245 Tel: (213) 322-8100 TWX: 910-348-7140 or 7111

†Wyle Distribution Group 17872 Cowan Avenue Irvine 92714 Tel: (714) 863-9953 TWX: 910-595-1572

Wyle Distribution Group 11151 Sun Center Drive Rancho Cordova 95670 Tel: (916) 638-5282

†Wyle Distribution Group 9525 Chesapeake Drive San Diego 92123 Tel: (619) 565-9171 TWX: 910-335-1590

†Wyle Distribution Group 3000 Bowers Avenu Santa Clara 95051 Tel: (408) 727-2500 TWX: 910-338-0296

Wyle Military 18910 Teller Avenue Irvine 92750 Tel: (714) 851-9958 TWX: 310-371-9127

Wyle Systems 7382 Lampson Avenue Garden Grove 92641 Tel: (714) 891-1717 TWX: 910-595-2642

COLORADO

Arrow Electronics, Inc. 1390 S. Potomac Street Suite 136 Aurora 80012 Tel: (303) 696-1111

†Hamilton/Avnet Electronics 8765 E. Orchard Road Suite 708 Englewood 80111 Tel: (303) 740-1017 TWX: 910-935-0787

†Wyle Distribution Group 451 E. 124th Avenue Thornton 80241 Tel: (303) 457-9953 TWX: 910-936-0770

CONNECTICUT

†Arrow Electronics, Inc. 12 Beaumont Road Wallingford 06492 Tel: (203) 265-7741 TWX: 710-476-0162

Hamilton/Avnet Electronics Commerce Industrial Park Commerce Drive Danbury 06810 Tel: (203) 797-2800 TWX: 710-456-9974

†Pioneer Northeast Electronics 112 Main Street Norwalk 06851 Tel: (203) 853-1515 TWX: 710-468-3373

FLORIDA

†Arrow Electronics, Inc. 350 Fairway Drive Deerfield Beach 33441 Tel: (305) 429-8200 TWX: 510-955-9456

Arrow Electronics, Inc. 1001 N.W. 62nd St., Ste. 108 Ft. Lauderdale 33309 Tel: (305) 776-7790 TWX: 510-955-9456

†Arrow Electronics, Inc. 50 Woodlake Drive W., Bldg. B Palm Bay 32905 Tel: (305) 725-1480 TWX: 510-959-6337

†Hamilton/Avnet Electronics 6801 N.W. 15th Way Ft. Lauderdale 33309 Tel: (305) 971-2900 TWX: 510-956-3097

Hamilton/Avnet Electronics 3197 Tech Drive North St. Petersburg 33702 Tel: (813) 576-3930 TWX: 810-863-0374

Hamilton/Avnet Electronics 6947 University Boulevard Winterpark 32792 Tel: (305) 628-3888 TWX: 810-853-0322

†Pioneer Electronics 337 N. Lake Blvd., Ste. 1000 Alta Monte Springs 32701 Tel: (305) 834-9090 TWX: 810-853-0284

Pioneer Electronics 674 S. Military Trail Deerfield Beach 33442 Tel: (305) 428-8877 TWX: 510-955-9653

GEORGIA

†Arrow Electronics, Inc. 3155 Northwoods Parkway Suite A Norcross 30071 Tel: (404) 449-8252 TWX: 810-766-0439

Hamilton/Avnet Electronics 5825 D. Peachtree Corners Norcross 30092 Tel: (404) 447-7500 TWX: 810-766-0432

Pioneer Electronics 3100 F. Northwoods Place Norcross 30071 Tel: (404) 448-1711 TWX: 810-766-4515

ILLINOIS

†Arrow Electronics, Inc. 2000 E. Alonquin Street Schaumberg 60195 Tel: (312) 397-3440 TWX: 910-291-3544

†Hamilton/Avnet Electronics 1130 Thorndale Avenue Bensenville 60106 Tel: (312) 860-7780 TWX: 910-227-0060

Kierulff Electronics, Inc. 1140 W. Thorndale Itasca 60143 Tel: (312) 250-0500

ILLINOIS (Cont'd)

MTI Systems Sales 1100 West Thorndale Itasca 60143 Tel: (312) 773-2300

†Pioneer Electronics 1551 Carmen Drive Elk Grove Village 60007 Tel: (312) 437-9680 TWX: 910-222-1834

INDIANA

†Arrow Electronics, Inc. 2495 Directors Row, Suite H Indianapolis 46241 Tel: (317) 243-9353 TWX: 810-341-3119

Hamilton/Avnet Electronics 485 Gradle Drive Carmel 46032 Tel: (317) 844-9333 TWX: 810-260-3966

†Pioneer Electronics 6408 Castleplace Drive Indianapolis 46250 Tel: (317) 849-7300 TWX: 810-260-1794

†Hamilton/Avnet Electronics 9219 Quivera Road Overland Park 66215 Tel: (913) 888-8900 TWX: 910-743-0005

Pioneer Electronics 10551 Lackman Rd. Lenexa 66215 Tel: (913) 492-0500

KENTUCKY

Hamilton/Avnet Electronics 1051 D. Newton Park Lexington 40511 Tel: (606) 259-1475

MARYI AND

Arrow Electronics, Inc. 8300 Gulford Road #H Rivers Center Columbia 21046 Tel: (301) 995-0003 TWX: 710-236-9005

†Hamilton/Avnet Electronics 6822 Oak Hall Lane Columbia 21045 Tel: (301) 995-3500 TWX: 710-862-1861

†Mesa Technology Corp. 9720 Patuxentwood Dr. Columbia 21046 Tel: (301) 720-5020 TWX: 710-828-9702

†Pioneer Electronics 9100 Gaither Road Gaithersburg 20877 Tel: (301) 921-0660 TWX: 710-828-0545

MASSACHUSETTS

†Arrow Electronics, Inc. 1 Arrow Drive Woburn 01801 Tel: (617) 933-8130 TWX: 710-393-6770

†Hamilton/Avnet Electronics 10D Centennial Drive Peabody 01960 Tel: (617) 532-3701 TWX: 710-393-0382

Kierulff Electronics, Inc. 13 Fortune Dr. Billerica 01821 Tel: (617) 667-8331

MTI Systems Sales 13 Fortune Drive Billerica 01821

Pioneer Northeast Electronics 44 Hartwell Avenue Lexington 02173 Tel: (617) 861-9200 TWX: 710-326-6617

MICHIGAN

Arrow Electronics, Inc. 755 Phoenix Drive Ann Arbor 48104 Tel: (313) 971-8220 TWX: 810-223-6020

†Hamilton/Avnet Electronics 32487 Schoolcraft Road Livonia 48150 Tel: (313) 522-4700 TWX: 810-242-8775

Hamilton/Avnet Electronics 2215 29th Street S.E. Space A5 Grand Rapids 49508 Tel: (616) 243-8805 TWX: 810-273-6921

Pioneer Electronics 4505 Broadmoor Ave. S.E. Grand Rapids 49508 Tel: (616) 555-1800

†Pioneer Electronics 13485 Stamford Livonia 48150 Tel: (313) 525-1800 TWX: 810-242-3271

MINNESOTA

†Arrow Electronics, Inc. 5230 W. 73rd Street Edina 55435 Tel: (612) 830-1800 TWX: 910-576-3125

Hamilton/Avnet Electronics 12400 White Water Drive Minnetonka 55343 Tel: (612) 932-0600 TWX: (910) 576-2720

†Pioneer Electronics 10203 Bren Road East Minnetonka 55343 Tel: (612) 935-5444 TWX: 910-576-2738

†Arrow Electronics, Inc. 2380 Schuetz St. Louis 63141 Tel: (314) 567-6888 TWX: 910-764-0882

†Hamilton/Avnet Electronics 13743 Shoreline Court Earth City 63045 Tel: (314) 344-1200 TWX: 910-762-0684

Kierulff Electronics, Inc. 11804 Borman Dr. St. Luis 63146 Tel: (314) 997-4956

NEW HAMDSHIDE

†Arrow Electronics, Inc. 3 Perimeter Road Manchester 03103 Tel: (603) 668-6968 TWX: 710-220-1684

Hamilton/Avnet Electronics 444 E. Industrial Drive Manchester 03104 Tel: (603) 624-9400

NEW JERSEY

†Arrow Electronics, Inc. 6000 Lincoln East Mariton 08053 Tel: (609) 596-8000 TWX: 710-897-0829

†Arrow Electronics, Inc. 2 Industrial Road Fairfield 07006 Tel: (201) 575-5300 TWX: 710-998-2206

†Hamilton/Avnet Electronics 1 Keystone Avenue Bldg. 36 Cherry Hill 08003 Tel: (609) 424-0110 TWX: 710-940-0262



DOMESTIC DISTRIBUTORS

NEW JERSEY (Cont'd)

†Hamilton/Avnet Electronics 10 Industrial Fairfield 07006 Tel: (201) 575-3390 TWX: 701-734-4388

†Pioneer Northeast Electronics 45 Route 46 Pinebrook 07058 Tel: (201) 575-3510 TWX: 710-734-4382

†MTI Systems Sales 383 Route 46 W Fairfield 07006 Tel: (201) 227-5552

NEW MEXICO

Alliance Electronics Inc. 11030 Cochiti S.E. Albuquerque 87123 Tel: (505) 292-3360 TWX: 910-989-1151

Hamilton/Avnet Electronics 2524 Baylor Drive S.E. Albuquerque 87106 Tel: (505) 765-1500 TWX: 910-989-0614

NEW YORK

Arrow Electronics, Inc. 25 Hub Drive Melville 11747 Tel: (516) 694-6800 TWX: 510-224-6126

†Arrow Electronics, Inc. 3375 Brighton-Henrietta Townline Rd. Rochester 14623 Tel: (716) 427-0300 TWX: 510-253-4766

Arrow Electronics, Inc 7705 Maltage Drive Liverpool 13088 Tel: (315) 652-1000 TWX: 710-545-0230

Arrow Electronics, Inc. 20 Oser Avenue Hauppauge 11788 Tel: (516) 231-1000 TWX: 510-227-6623

Hamilton/Avnet Electronics 333 Metro Park Rochester 14623 Tel: (716) 475-9130 TWX: 510-253-5470

†Hamilton/Avnet Electronics 103 Twin Oaks Drive Syracuse 13206 Tel: (315) 437-2641 TWX: 710-541-1560

†Hamilton/Avnet Electronics 933 Motor Parkway Hauppauge 11788 Tel: (516) 231-9800 TWX: 510-224-6166

†MTI Systems Sales 38 Harbor Park Drive P.O. Box 271 Port Washington 11050 Tel: (516) 621-6200 TWX: 510-223-0846

†Pioneer Northeast Electronics 1806 Vestal Parkway East Vestal 13850 Tel: (607) 748-8211 TWX: 510-252-0893

†Pioneer Northeast Electronics 60 Crossway Park West Woodbury, Long Island 11797 Tel: (516) 921-8700 TWX: 510-221-2184

NEW YORK (Cont'd)

†Pioneer Northeast Electronics 840 Fairport Park Fairport 14450 Tel: (716) 381-7070 TWX: 510-253-7001

NORTH CAROLINA

†Arrow Electronics, Inc. 5240 Greendairy Road Raleigh 27604 Tel: (919) 876-3132 TWX: 510-928-1856

†Hamilton/Avnet Electronics 3510 Spring Forest Drive Raleigh 27604 Tel: (919) 878-0819 TWX: 510-928-1836

Pioneer Electronics 9801 A-Southern Pine Blvd. Charlotte 28210 Tel: (704) 527-8188 TWX: 810-621-0366

OHIO

Arrow Electronics, Inc. 7620 McEwen Road Centerville 45459 Tel: (513) 435-5563 TWX: 810-459-1611

†Arrow Electronics, Inc. 6238 Cochran Road Solon 44139 Tel (216) 248-3990 TWX: 810-427-9409

Hamilton/Avnet Electronics 777 Brookedge Blvd. Westerville 43081 Tel: (614) 882-7004

†Hamilton/Avnet Electronics 954 Senate Drive Dayton 45459 Tel: (513) 433-0610 TWX: 810-450-2531

Hamilton/Avnet Electronics 4588 Emery Industrial Parkway Warrensville Heights 44128 Tel: (216) 831-3500 TWX: 810-427-9452

†Pioneer Electronics 4433 Interpoint Blvd. Dayton 45424 Tel: (513) 236-9900 TWX: 810-459-1622

†Pioneer Electronics 4800 E. 131st Street Cleveland 44105 Tel: (216) 587-3600 TWX: 810-422-2211

OKLAHOMA

Arrow Electronics, Inc. 4719 S. Memorial Drive Tulsa 74145 Tel: (918) 665-7700

†Almac Electronics Corporation 1885 N.W. 169th Place

†Hamilton/Avnet Electronics 6024 S.W. Jean Road Bldg. C, Suite 10 Lake Oswego 97034 Tel: (503) 635-7848 TWX: 910-455-8179

OREGON (Cont'd)

Wyle Distribution Group 5250 N.E. Elam Young Parkway Suite 600 Hillsboro 97124 Tel: (503) 640-6000 TWX: 910-460-2203

PENNSYI VANIA

Arrow Electronics, Inc. 650 Seco Road Monroeville 15146 Tel: (412) 856-7000

Hamilton/Avnet Electronics 2800 Liberty Ave., Bldg. E Pittsburg 15238 Tel: (412) 281-4150

Pioneer Electronics 259 Kappa Drive Pittsburgh 15238 Tel: (412) 782-2300 TWX: 710-795-3122

†Pioneer Electronics 261 Gibralter Road Horsham 19044 Tel: (215) 674-4000 TWX: 510-665-6778

TEXAS

†Arrow Electronics, Inc. 3220 Commander Drive Carrollton 75006 Tel: (214) 380-6464 TWX: 910-860-5377

†Arrow Electronics, Inc. 10899 Kinghurst Suite 100 Houston 77099 Tel: (713) 530-4700 TWX: 910-880-4439

†Arrow Electronics, Inc. 10125 Metropolitan Austin 78758 Tel: (512) 835-4180 TWX: 910-874-1348

†Hamilton/Avnet Electronics 2401 Rutland Austin 78758 Tel: (512) 837-8911 TWX: 910-874-1319

†Hamilton/Avnet Electronics 2111 W. Walnut Hill Lane Irving 75062 Tel: (214) 659-4100 TWX: 910-860-5929

†Hamilton/Avnet Electronics 4850 Wright Road #190 Stafford 77477 Tel: (713) 780-1771 TWX: 910-881-5523

Kierulff Electronics, Inc. 9610 Skillman Dallas 75243 Tel: (214) 343-2400

†Pioneer Electronics 1826 D. Kramer Lane Austin 78758 Tel: (512) 835-4000 TWX: 910-874-1323

†Pioneer Electronics 13710 Omega Road Dallas 75234 Tel: (214) 386-7300 TWX: 910-850-5563

†Pioneer Electronics 5853 Point West Drive Houston 77036 Tel: (713) 988-5555 TWX: 910-881-1606

HATH

†Hamilton/Avnet Electronics 1585 West 2100 South Salt Lake City 84119 Tel: (801) 972-2800 TWX: 910-925-4018

Kierulff Electronics, Inc. 1946 W. Parkway Blvd. Salt Lake City 84119 Tel: (801) 973-6913

Wyle Distribution Group 1325 West 2200 South Suite E Salt Lake City 84119 Tel: (801) 974-9953

WACHINGTON

†Almac Electronics Corp. 14360 S.E. Eastgate Way Bellevue 98007 Tel: (206) 643-9992 TWX: 910-444-2067

Arrow Electronics, Inc. 14320 N.E. 21st Street Bellevue 98007 Tel: (206) 643-4800 TWX: 910-444-2017

Hamilton/Avnet Electronics 14212 N.E. 21st Street Bellevue 98005 Tel: (206) 453-5874 TWX: 910-443-2469

Wyle Distribution Group 1750 132nd Ave., N.E. Bellvue 98005 Tel: (206) 453-8300

†Arrow Electronics, Inc. 430 W. Rausson Avenue Oakcreek 53154 Tel: (414) 764-6600 TWX: 910-262-1193

Hamilton/Avnet Electronics 2975 Moorland Road New Berlin 53151 Tel: (414) 784-4510 TWX: 910-262-1182

Kierulff Electronics, Inc. 2238-E W. Bluemound Rd. Waukeshaw 53186 Tel: (414) 784-8160

CANADA

ALBERTA

Hamilton/Avnet Electronics 2816 21st Street N.E. Calgary T2E 622 Tel: (403) 250-9380 TWX: 03-827-642

Hamilton/Avnet Electronics 6845 Rexwood Road Unit 6 Mississauga, Ontario L4V1R2 Tel: (416) 677-0484

Zentronics 6815 8th Street, N.E., Ste. 100 Calgary T2E 7H7 Tel: (403) 295-8838

BRITISH COLUMBIA

Hamilton/Avnet Electronics 105-2550 Boundary Road Burnaby V5M 3Z3 Tel: (604) 437-6667

BRITISH COLUMBIA (Contid)

Zentronics 108-11400 Bridgeport Road Road V6X 1T2 Tel: (604) 273-5575 TWX: 04-5077-89

MANITORA

Zentronics 60-1313 Border Street Winnipeg R3H 0X4 Tel: (204) 694-1957 FAX: (204) 633-9255

ONTARIO

Arrow Electronics Inc. 24 Martin Ross Avenue Downsview M3J 2K9 Tel: (416) 661-0220 TLX: 06-218213

Arrow Electronics Inc. 148 Colonnade Road Nepean K2E 7J5 Tel: (613) 226-6903

†Hamilton/Avnet Electronics 6845 Rexwood Road Units G & H Mississauga L4V 1R2 Tel: (416) 677-7432 TWX: 610-492-8867

†Hamilton/Avnet Electronics 210 Colonnade Road South Nepean K2E 7L5 Tel: (613) 226-1700 TWX: 05-349-71

†Zentronics 8 Tilbury Court Brampton L6T 3T4 Tel: (416) 451-9600 TWX: 06-976-78

Zentronics 564/10 Weber Street North Waterloo N2L 5C6 Tel: (519) 884-5700

†Zentronics 155 Colonnade Road Unit 17 Nepean K2E 7K1 Tel: (613) 225-8840 TWX: 06-976-78

SASKATCHEWAN

Zentronics 173-1222 Alberta Avenue Saskatoon S7K 1R4 Tel: (306) 955-2202, 2207 FAX: (306) 244-3731

QUEREC

†Arrow Electronics Inc. 4050 Jean Talon Quest Montreal H4P 1W1 Tel: (514) 735-5511 TLX: 05-25596

Arrow Electronics Inc. 909 Charest Blvd. Quebec 61N 269 Tel: (418) 687-4231 TLX: 05-13388

Hamilton/Avnet Electronics 2795 Rue Halpern St. Laurent H4S 1P8 Tel: (514) 335-1000 TWX: 610-421-3731

Zentronics 505 Locke Street St. Laurent H4T 1X7 Tel: (514) 735-5361 TWX: 05-827-535



DOMESTIC SERVICE OFFICES

ALABAMA

Intel Corp. 5015 Bradford Drive, #2 Huntsville 35805 Tel: (205) 830-4010

ARIZONA

Intel Corp. 11225 N. 28th Dr., #D214 Phoenix 85029 Tel: (602) 869-4980

Intel Corp. 500 E. Fry Blvd., Suite M-15 Sierra Vista 85635 Tel: (602) 459-5010

ARKANSAS

Intel Corp. P.O. Box 206 Ulm 72170 Tel: (501) 241-3264

CALIFORNIA

Intel Corp. 21515 Vanowen St. Suite 116 Canoga Park 91303 Tel: (818) 704-8500

Intel Corp. 2250 E. Imperial Highway Suite 218 El Segundo 90245 Tel: 1-800-468-3548

Intel Corp. 1900 Prairie City Rd. Folsom 95630-9597 Tel: (916) 351-6143

Intel Corp. 2000 E. 4th Street Suite 110 Santa Ana 92705 Tel: (714) 835-5789 TWX: 910-595-2475

Intel Corp. 2700 San Tomas Expressway Santa Clara 95051 Tel: (408) 970-1740

Intel Corp. 4350 Executive Drive Suite 105 San Diego 92121 Tel: (619) 452-5880

COLORADO

Intel Corp. 650 South Cherry Suite 915 Denver 80222 Tel: (303) 321-8086 TWX: 910-931-2289 CONNECTICUT

Intel Corp. 26 Mill Plain Road Danbury 06811 Tel: (203) 748-3130 TWX: 710-456-1199

FLORIDA

Intel Corp. 1500 N.W. 62, Suite 104 Ft. Lauderdale 33309 Tel: (305) 771-0600 TWX: 510-956-9407

Intel Corp. 242 N. Westmonte Drive Suite 105 Altamonte Springs 32714 Tel: (305) 869-5588

GEORGIA

Intel Corp. 3280 Pointe Parkway Suite 200 Norcross 30092 Tel: (404) 441-1171

ILLINOIS

Intel Corp. 300 N. Martingale Rd. Suite 300 Schaumburg 60194 Tel: (312) 310-5733

INDIANA

Intel Corp. 8777 Purdue Rd., #125 Indianapolis 46268 Tel: (317) 875-0623

KANSAS

Intel Corp. 8400 W. 110th Street Suite 170 Overland Park 66210 Tel: (913) 345-2727

KENTUCKY

Intel Corp. 3525 Tatescreek Road, #51 Lexington 40502 Tel: (606) 272-6745

MARYLAND

Intel Corp. 5th Floor 7833 Walker Drive Greenbelt 20770 Tel: (301) 441-1020

MASSACHUSETTS

Intel Corp. Westford Corp. Center 3 Carlisle Road Westford 01886 Tel: (617) 692-1060 MICHIGAN

Intel Corp. 7071 Orchard Lake Road Suite 100 West Bloomfield 48033 Tel: (313) 851-8905

MISSOURI

Intel Corp. 4203 Earth City Expressway Suite 143 Earth City 63045 Tel: (314) 291-2015

NEW JERSEY

Intel Corp. 385 Sylvan Avenue Englewood Cliffs 07632 Tel: (201) 567-0821 TWX: 710-991-8593

Intel Corp. Raritan Plaza III Raritan Center Edison 08817 Tel: (201) 225-3000

NORTH CAROLINA

Intel Corp. 2306 W. Meadowview Road Suite 206 Greensboro 27407 Tel: (919) 294-1541

Intel Corp. 2700 Wycliff Rd., Suite 102 Raleigh 27607 Tel: (919) 781-8022

OHIO

Intel Corp. Chagrin-Brainard Bldg. Suite 305 28001 Chagrin Boulevard Cleveland 44122 Tel: (216) 464-6915 TWX: 810-427-9298

Intel Corp. 6500 Poe Dayton 45414 Tel: (513) 890-5350

OREGON

Intel Corp. 15254 N.W. Greenbrier Parkway, Bldg. B Beaverton 01886 Tel: (503) 645-8051 TWX: 910-467-8741

Intel Corp. 5200 N.E. Elam Young Parkway Hillsboro 97123 Tel: (503) 681-8080 PENNSYLVANIA

Intel Corp. 201 Penn Center Boulevard Suite 301 W Pittsburgh 15235 Tel: (313) 354-1540

TEXAS

Intel Corp. 313 E. Anderson Lane Suits 314. Austin 78752 Tel: (512) 454-3628 TWX: 910-874-1347.

Intel Corp. 12300 Ford Road Suite 380 Dallas 75234 Tel: (214) 241-2820 TWX: 910-860-5617

Intel Corp. 8815 Dyer St., Suite 225 El Paso 79904 Tel: (915) 751-0186

VIRGINIA

Intel Corp. 1603 Santa Rosa Rd., #109 Richmond 23288 Tel: (804) 282-5668

WASHINGTON

Intel Corp. 110 110th Avenue N.E. Suite 510 Bellevue 98004 Tel: 1-800-468-3548 TWX: 910-443-3002

WISCONSIN

Intel Corp. 330 S. Executive Dr. Suite 102 Brookfield 53005 Tel: (414) 784-8087

CANADA

Intel Corp. 190 Attwell Drive, Suite 500 Rexdale, Ontario Canada M9W 6H8 Tel: (416) 675-2105

Intel Corp. 620 St. Jean Blvd. Pointe Claire, Quebec Canada H9R 3K3 Tel: (514) 694-9130

Intel Corp. 2650 Queensview Drive, #250 Ottawa, Ontario, Canada K2B 8H6 Tel: (613) 829-9714

CUSTOMER TRAINING CENTERS

CALIFORNIA

2700 San' Tomas Expressway Santa Clara 95051 Tel: (408) 970-1700

300 N. Martingale, #300 Schaumburg 60173 Tel: (312) 310-5700 MASSACHUSETTS

3 Carlisle Road Westford 01886 Tel: (617) 692-1000 MARYLAND

7833 Walker Dr., 4th Floor Greenbelt 20770 Tel: (301) 220-3380

SYSTEMS ENGINEERING OFFICES

CALIFORNIA

2700 San Tomas Expressway Santa Clara 95051 Tel: (408) 986-8086 ILLINOIS

300 N. Martingale, #300 Schaumburg 60173 Tel: (312) 310-8031 MASSACHUSETTS

3 Carlisle Road Westford 01886 Tel: (617) 692-3222 NEW YORK

300 Motor Parkway Hauppauge 11788 Tel: (516) 231-3300



EUROPEAN SALES OFFICES

Intel Corporation S.A. B-1180 Brussels Tel: (02) 347-0666

Intel Denmark A/S* Glentevej 61 - 3rd Floor DK-2400 Copenhagen Tel: (01) 19-80-33 TLX: 19567

EINI AND

Intel Finland OY Rousilantie 2 00390 Helsinki Tel: (8) 0544-644 TLX: 123332

Intel Paris 1 Rue Edison, BP 303 78054 Saint-Quentin-er Tel: (33) 1-30-57-7000 TLX: 69901677 n-Yvelines Cedex

Intel Corporation, S.A.R.L. Immeuble BBC 4 Quai des Etroits 69005 Lyon Tel: (7) 842-4089 TLX: 305153

WEST GERMANY

Intel Semiconductor GmbH* Seidlstrasse 27 D-8000 Muenchen 2 Tel: (89) 53891 TLX: 05-23177 INTL D

Intel Semiconductor GmbH Intel Semiconductor GmbH Verkaufsbuero Wiesbaden Abraham-Lincoln Str. 16-18 6200 Wiesbaden Tel: (6121) 76050 TLX: 04186183 INTW D

Intel Semiconductor GmbH Verkaufsbuero Hannover Hohenzollernstrasse 5 3000 Hannover 1 Tel: (511) 34-40-81 TLX: 923625 INTH D

Intel Semiconductor GmbH Verkaufsbuero Stuttgart Bruckstrasse 61 7012 Fellbach Tel: (711) 58-00-82 TLX: 7254826 INTS D

Intel Semiconductor Ltd* Attidim Industrial Park Neve Sharet Dvora Hanevia Bldg. No. 13, 4th Floor P.O. Box 43202 Tel Aviv 61430 Tel: (3) 491-099, 491-098 TLX: 371215

Intel Corporation S.P.A.* Milanofiori, Palazzo E/4 20090 Assago (Milano) Tel: (02) 824-4071 TLX: 341286 INTMIL

NETHERLANDS

Intel Semiconductor (Nederland) B.V.* Alexanderpoort Building Marten Meesweg 93 3068 Rotterdam Tei: (10) 21-23-77 TLX: 22283

NODWAY

Intel Norway A/S P.O. Box 92 Hvamveien 4 N-2013, Skjetten Tel: 06-842420 TLX: 78018

Intel Iberia Calle Zurbaran 28-IZQDA 28010 Madrid Tel: (1) 410-4004 TLX: 46880

SWEDEN

Intel Sweden A.B.* Dalvagen 24 S-171 36 Solna Tel: (8) 734-0100 TLX: 12261

SWITZEDI AND

Intel Semiconductor A.G.*
Talackerstrasse 17
8152 Glattbrugg
CH-8065 Zurich
Tel: (01) 829-2977
TLX: 57989 ICH CH

UNITED KINGDOM

Intel Corporation (U.K.) Ltd.* Pipers Way Swindon, Wiltshire SN3 1RJ Tel: (0793) 696000 TLX: 444447 INT SWN

EUROPEAN DISTRIBUTORS/REPRESENTATIVES

AUSTRIA

Bacher Elektronics Ges.m.b.H. Rotenmuehlgasse 26 A-1120 Wien Tel: (222) 835-6460 TLX: 131532

Inelco Belgium S.A. Ave. des Croix de Guerre, 94 Bruxelles 1120 Tel: (02) 216-01-60 TLX: 64475

BENELUX

Koning en Hartman Electrotechniek B.V. Postbus 125 2600 AC Delft Tel: (15) 609-906 TLX: 38250

DENMARK

ITT MultiKomponent Naverland 29 DK-2600 Glostrup Tel: (02) 456-66-45 TLX: 33355 ITTCG DK

Oy Fintronic AB Melkonkatu 24A SF-00210 Helsinki 21 Tel: (0) 692-60-22 TLX: 124224 FTRON SF

FRANCE

Generim Zone d'Activite de Courtaboeuf Avenue de la Baltique 91943 Les Ulis Cedex Tel: (1) 69-07-78-78 TLX: 691700

Jermyn 73-79 Rue des Solets Silic 585 94663 Rungis Cedex Tel: (1) 45-60-04-00 TLX: 290967

Metrologie Tour d'Asnieres 4, Avenue Laurent Cely 92606 Asnieres Tel: (1) 47-90-62-40 TLX: 611448

FRANCE (Cont'd)

Tekelec Airtronic Cite des Bruyeres Rue Carle Vernet BP 2 92310 Sevres Tel: (1) 45-34-75-35 TLX: 204552

WEST GERMANY

Electronic 2000 Vertriebs AG Stahlgruberring 12 8000 Muenchen 82 Tel: (089) 42-00-10 TLX: 522561 ELEC D

Jermyn GmbH Schulstrasse 84 6277 Bad Camberg Tel: (064) 34-231 TLX: 415257-0 JERM D

Metrologie GmbH Meglingerstr. 49 8000 Muenchen 71 Tel: (089) 570-940 TLX: 5213189

Metrologie GmbH Rheinstr. 94-96 6100 Darmstadt Tel: (06151) 33661 TLX: 176151820

Proelectron Vertriebs AG Max-Planck-Strasse 1-3 6072 Dreieich Tel: (06103) 3040 TLX: 417972

ITT-MultiKomponent Bahnhofstrasse 44 7141 Moeglingen Tel: (07141) 4879 TLX: 7264399 MUKO D

ISRAEL

Eastronics Ltd. 11 Rosanis Street P.O. Box 39300 Tel Aviv 61392 Tel: (3) 47-51-51 TLX: 342610 DATIX IL or 33638 RONIX IL

Eledra Componenti S.P.A. Via Giacomo Watt, 37 20143 Milano Tel: (02) 82821 TLX: 332332

ITALY (Cont'd)

Intesi Milanofiori E5 20090 Assago Tel: (02) 824701 TLX: 311351

Lasi Elettronica S.P.A. Viale Fulvio Testi, 126 20092 Cinisello Balsamo Tel: (02) 244-0012, 244-0212 TLX: 352040

NODWAY

Nordisk Electronik A/S Postboks 130 N-1364 Hvalstad Tel: (2) 846-210 TLX: 77546 NENAS N

PORTUGAL

Ditram Avenida Marques de Tomar, 46A Lieboa P-1000 Tel: (1) 545-313 TWX: (0404) 14182

SPAIN

A.T.D. Electronica S.A. Pl. Cludad de Viena 6 28040 Madrid Tel: (1) 234-40-00 TWX: 42477

ITT SESA 21-3 Miguel Angel Madrid 28010 Tel: (1) 419-54-00 TWX: 27461

SWEDEN

Nordisk Elektronik AB Box 1409 S-171 27 Solna Tel: (8) 734-97-70 TLX: 10547

SWITZERLAND

UNITED KINGDOM

Accent Electronic Components Ltd. Jubilee House, Jubilee Way Letchworth, Herts SG6 1QH England Tel: (0462) 686666 TLX: 626923

Bytech Ltd.
Unit 2 Western Centre
Western Industrial Estate
Bracknell, Berkshire RG12 1RW
England
Tol: (0344) 482211
TLX: 848215

Comway Microsystems Ltd. John Scott House, Market St. Bracknell, Berkshire RJ12 1QP England Tel: (0344) 55333 TLX: 847201

IBR Microcomputers Ltd. Unit 2 Western Centre Western Industrial Estate Bracknell, Berkshire RG12 1RW England Tel: (0344) 486-555 TLX: 849381

Jermyn Industries Vestry Estate, Otford Road Sevenoaks, Kent TN14 5EU England Tel: (0732) 450144 TLX: 95142

Rapid Silicon Rapid House, Denmark St. High Wycombe, Bucks HP11 2ER England Tef: (0494) 442266 TLX: 837931

Rapid Systems Rapid House, Denmark St. High Wycombe, Bucks HP11 2ER England Tel: (0494) 450244 TLX: 837931

Micro Marketing Glenageary Office Park Glenageary, Co. Dublin Ireland Tel: (0001) 856288 TLX: 31584

YIIGOSI AVIA

H.R. Microelectronics Corp. 2005 De La Cruz Blvd., Ste. 223 Santa Clara, CA 95050 U.S.A. Tel: (408) 988-0286 TLX: 387452



INTERNATIONAL SALES OFFICES

AUSTRALIA

Intel Australia Pty. Ltd.* Spectrum Building 200 Pacific Hwy., Level 6 Crows Nest, NSW, 2065 Tel: (2) 957-2744 TLX: 20097 FAX: (2) 923-2632

BRAZIL

Intel Semicondutores do Brasil LTDA Av. Paulista, 1159-CJS 404/405 01311 - Sao Paulo - S.P. Tel: 9-011-55-11-287-5899 TLX: 1153146

CHINA

Intel PRC Corporation 15/F, Office 1, Citic Bldg. Jian Guo Men Wai Street Beijing, PRC Tel: (1) 500-4850 TLX: 22947 INTEL CN FAX: (1) 500-2953

HONG KONG

Intel Semiconductor Ltd.*
1701-3 Connaught Centre
1 Connaught Road
Tel: (5) 844-4555
TWX: 63869 ISLHK HX
FAX: (5) 294-589

JAPAN

Intel Japan K.K. 5-6 Tokodai Toyosato-machi Tsukuba-gun, Ibaraki-ken 300-26 Tel: 029747-8511 TLX: 3656-160 FAX: 029747-8450

Intel Japan K.K.* Dalichi Mitsugi Bidg. 1-8889 Fuchu-cho Fuchu-shi, Tokyo 183 Tel: 0423-60-7871 FAX: 0423-60-0315

Intel Japan K.K.* Flower-Hill Shin-machi Bldg. 1-23-9 Shinmachi Setagaya-ku, Tokyo 154 Tel: 03-426-2231 FAX: 03-427-7620

Intel Japan K.K.* Bldg. Kumagaya 2-69 Hon-cho Kumagaya-shi, Saitama 360 Tel: 0485-24-6871 FAX: 0485-24-7518

Intel Japan K.K.* Mitsui-Seimei Musashi-kosugi Bldg. 915 Shinmaruko, Nakahara-ku Kawasaki-shi, Kanagawa 211 Tel: 044-733-7011 FAX: 044-733-7010

JAPAN (Cont'd)

Intel Japan K.K. Nihon Seimei Atsugi Bldg. 1-2-1 Asahi-machi Atsugi-shi, Kanagawa 243 Tel: 0462-29-3731 FAX: 0462-29-3781

Intel Japan K.K.* Ryokuchi-Eki Bldg. 2-4-1 Terauchi Toyonaka-shi, Osaka 560 Tel: (06) 863-1091 FAX: 06-863-1084

Intel Japan K.K. Shinmaru Bldg. 1-5-1 Marunouchi Chiyoda-ku, Tokyo 100 Tel: 03-201-3621 FAX: 03-201-6850

Intel Japan K.K. Tokai Bldg. 1-16-30 Meleki Minami Nakamura-ku, Nagoya-shi Aichi 450 Tel: 052-561-5181 FAX: 052-561-5317

KORĖA

Intel Technology Asia Ltd. Room 906, Singsong Bldg. 25-4, Yoldo-Dong, Youngdeungpo-ku Seoul 150 Tel: (2) 784-8186 TLX: 29312 INTELKO FAX: (2) 784-8096

SINGAPORE

Intel Singapore Technology, Ltd. 101 Thomson Road #21-06 Goldhill Square Singapore 1130 Tel: 250-7811 TLX: 39921 INTEL FAX: 250-9256

TAIWAN

Intel Technology (Far East) Ltd. Taiwan Branch 10/F., No. 205, Tun Hua N. Road Taipei, R.O. 205. Tsi: 886-2-716-9660 TLX: 13159 INTELTWN FAX: 886-2-717-2455

INTERNATIONAL DISTRIBUTORS/REPRESENTATIVES

ARGENTINA

VLC S.R.L. Bartalome Mitre 1711 3 Piso 1037 Buenos Aires Tel: 54-1-49-2092 TLX: 17575 EDARG-AR

AUSTRALIA

Total Electronics Private Bag 250 9 Harker Street Burwood, Victoria 3125 Tel: 61-3-288-4044 TLX: AA 31261

Total Electronics P.O. Box 139 Artamon, N.S.W. 2064 Tel: 61-02-438-1855 TLX: 26297

BRAZII

Elebra Microelectronica S/A Geraldo Flausino Gomes, 78 9 Andar 04575 - Sao Paulo - S.P. Tel: 55-11-534-9600 TLX: 3911125131 ELBR BR FAX: 55-11-534-9424

CHILE

DIN Instruments Suecia 2323 Casilla 6055, Correo 22 Santiago Tel: 56-2-225-8139 TLX: 440422 RUDY CZ

CHINA

Novel Precision Machinery Co., Ltd. Flat D. 20 Kingsford Ind. Bildg. Phase 1, 26 Kwal Hei Street N.T., Kowloon Hong Kong Tel: 852-0-223-222 TWX: 39114 JINMI HX FAX: 852-0-261-602

CHINA (Cont'd)

Schmidt & Co. Ltd. 18/F Great Eagle Centre 23 Harbour Road Wanchai, Hong Kong Tel: 852-5-833-0222 TWX: 74766 SCHMC HX FAX: 852-5-891-8754

INDIA

Micronic Devices Arun Complex No. 65 D.V.G. Road Basavanagudi Bangalore 550 004 Tel: 91-812-600-631 TLX: 0845-8332 MD BG IN

Micronic Devices 403, Gagan Deep 12, Rajendra Place New Delhi 110 008 Tel: 91-58-97-71 TLX: 03163235 MDND IN

Micronic Devices No. 516 5th Floor Swastik Chambers Sion, Chambray Road Bombay 400 071 Tel: 91-52-39-63 TLX: 9531 171447 MDEV IN

JAPAN

Asahi Electronics Co. Ltd. KMM Bldg. 2-14-1 Asano Kokurakita-ku Kitakyushu-shi 802 Tel: 093-511-6471 FAX: 093-551-7861

C. Itoh Techno-Science Co., Ltd. C. Itoh Bldg., 2-5-1 Kita-Aoyama Minato-ku, Tokyo 107 Tel: 03-497-4840 FAX: 03-497-4969

JAPAN (Cont'd)

Dia Semicon Systems, Inc. Wacore 64, 1-37-8 Sangenjaya Setagaya-ku, Tokyo 154 Tel: 03-487-0386 FAX: 03-487-8088

Okaya Koki 2-4-18 Sakae Naka-ku, Nagoya-shi 460 Tel: 052-204-2911 FAX: 052-204-2901

Ryoyo Electro Corp. Konwa Bldg. 1-12-22 Tsukiji Chuo-ku, Tokyo 104 Tel: 03-546-5011 FAX: 03-546-5044

KOREA

J-Tak Corporation 6th Floor, Government Pension Bldg. 24-3 Yoldo-Dong Youngdeungpo-ku Seoul 150 Tal: 82-2-782-8039 TLX: 25298 KODIGIT FAX: 82-2-784-8391

Samsung Semiconductor & Telecommunications Co., Ltd. 150, 2-KA, Tafpyung-ro, Chung-ku Seoul 100 Tel: 82-2-751-3987 TLX: 27970 KORSST FAX: 82-2-753-0967

MEXICO

Dicopel S.A. Tochtii 368 Fracc. Ind. San Antonio Azcapotzalco C.P. 02760-Mexico, D.F. Tel: 52-5-561-3211 TLX: 1773790 DICOME

NEW ZEALAND

Northrup Instruments & Systems Ltd. 459 Kyber Pass Road P.O. Box 9464, Newmarket Auckland 1 Tel: 64-9-501-219, 501-801 TLX: 21570 THERMAL

Northrup Instruments & Systems Ltd. P.O. Box 2406 Wellington 856658 Tel: 64-4-856-658 TLX: N2380 FAX: 64-4-857276

SINGAPORE

Francotone Electronics Pte Ltd. 17 Harvey Road #04-01 Singapore 1336 Tel: 283-0888, 289-1618 TWX: 56541 FRELS FAX: 2895327

SOUTH AFRICA

Electronic Building Elements, Pty. Ltd. P.O. Box 4609 Pine Square, 18th Street Hazelwood, Pretoria 0001 Tel: 27-12-469921 TLX: 3-227786 SA

TAIWAN

Mitac Corporation No. 585, Ming Shen East Rd. Taipei, R.O.C. Tel: 886-2-501-8231 FAX: 886-2-501-4265

VENEZUELA

P. Benavides S/A Avilanes a Rio Residencias Kamarata Locales 4 A17 La Candelaria, Caracas Tel: 58-2-571-3996 TLX: 28450 PBVEN VC FAX: 58-2-572-3321



UNITED STATES Intel Corporation 3065 Bowers Avenue Santa Clara, CA 95051

JAPAN Intel Japan K.K. 5-6 Tokodai Toyosato-machi Tsukuba-gun, Ibaraki-ken 300-26

FRANCE Intel Paris 1 Rue Edison, BP 303 78054 Saint-Quentin-en-Yvelines Cedex

UNITED KINGDOM Intel Corporation (U.K.) Ltd. Pipers Way Swindon Wiltshire, England SN3 1RJ

WEST GERMANY Intel Semiconductor GmbH SeidIstrasse 27 D-8000 Muenchen 2

HONG KONG Intel Semiconductor Ltd. 1701-3 Connaught Centre 1 Connaught Road

CANADA Intel Semiconductor of Canada, Ltd. 190 Attwell Drive, Suite 500 Rexdale, Ontario M9W 6H8