## SGS-THOMSON MICROELECTRONICS

# **APPLICATION NOTE**

### Input Capture with ST62 Auto-reload Timer

J.NICOLAI

### INTRODUCTION

This note presents how to use the Auto-reload timer (ARTimer) of the ST62 to measure durations or frequencies of an input signal.


#### Auto-reload timer description

This timer is an 8 bit timer/counter with prescaler. It includes auto-reload PWM, capture and compare capability with one input and one output pins. It can be controlled by thefollowing registers (8 bit):

- Mode Control Register (MC)
- \_ Status registers (SC0, SC1)
- Load register (LR)
- Incremental counter register (TC)
- Compare register (CP)
- Reload/Capture register (RC)

It can also wake-up the MCU from wait mode and exit from stop mode if an external event is present on the input pin. The prescaler ratio can be programmed to choose the timer input frequency  $F_{N}$  (see Table 1).

#### Figure 1. Auto-reload Timer Block Diagram



#### Capture Mode With Reset

This can be used to measure time durations or frequencies. This mode is used to measure the time elapsed between two edges of an external signal: two rising edges, two falling edges, or one rising and one falling if the configuration of the timer is modified after the first edge detected.

The minimum duration of one signal to measure depends on the CPU clock and on the required precision. With a 8MHz Quartz crystal, a signal of 8µs duration can be measured with a resolution of 1/64.

#### Example:

Let's measure the time elapsed between two rising edges on TIMIN:

The prescaler ratio must be programmed according to the expected duration to measure. In this example it is programmed to: prescaler ratio = 4, clock source = CPU clock. (in case the duration expected can be longer than the 255 count span of the TC count register, the overflow interrupt can be used to increment a RAM variable, used as the most significant part of the result).

In the program example, waiting for the edge on TIMIN is made by a software loop (jrr 2, SC0, wt\_edge), but it is also possible to use the external event interrupt to read the result immediately after the edge without loading the rest of the program. It is also possible to read the result directly from RC without waiting or using the interrupt, if the duration is required at an asynchronous time, not just after the edge.

#### PRESCALER Bit 0 PS2 PS1 PS0 Reg. SC1 Ratio

#### Table 1. Prescaler Programming Ratio




#### **Program example**

```
.def 0FFh,0FFh,0FFh ;Accumulator
А
period .def 084h,0FFh,0FFh ;elapsed time
.def 0D9h,0FFh,0FFh
RC
                            ;reload/capture register
        .def ODAh,OFFh,OFFh ;compare register
.def OD5h,OFFh,OFFh ;mode control reg
.def OD6h,OFFh,OFFh ;status/control r
CP
MC
                             ;mode control register
SC0
                             ;status/control register 0
        .def 0D7h,0FFh,0FFh ;status/control register 1
SC1
         .def 0DBh,0FFh,0FFh
LR
                             ;load register
;______
         ldi SC1,01000100b
                             ;clock source = CPU,
                             ; prescaler ratio = 4,
                             ;pull-up on TIMIN disabled,
                             ; capture on rising edge of TIMIN
         ldi MC, 11000010b
                             ; capture with reset, ints. disabled
                             ; PWMOUT disabled, start timer
; .
; . normal program
; .
;now we want to know the elapsed time between last and
;next edge on TIMIN:
        res 2, SCO
                             ; clear external event flag
wt_edge
         jrr 2,SC0,wt_edge
                             ;wait for edge on TIMIN, then
         ld A,RC
                             ;read elapsed time from reload/capt
                             ;register into variable "period"
         ld period,A
```

The following figure shows the evolution of the contents of TC and RC during capture operation: a rising edge on TIMIN results in copying the latest value of TC into RC, and clearing TC. Afterwards, TC increments at the selected clock rate until the next capture or until it reaches 255. In the latter case, it wraps to 0. In capture mode, TC always counts from 0 to 255, it is never loaded from the RC register.

#### Figure 2. TC and RC Evolution





THE SOFTWARE INCLUDED IN THIS NOTE IS FOR GUIDANCE ONLY. SGS-THOMSON SHALL NOT BE HELD LIABLE FOR ANY DIRECT, INDIRECT OR CONSEQUENTIAL DAMAGES WITH RESPECT TO ANY CLAIMS ARISING FROM USE OF THE SOFTWARE.

Information furnished is believed to be accurate and reliable. However, SGS-THOMSON Microelectronics assumes no responsability for the consequences of use of such information nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of SGS-THOMSON Microelectronics. Specificationsmentioned in this publication are subject to change without notice. This publication supersedes and replaces all information previously supplied.

SGS-THOMSON Microelectronics products are not authorized for use as critical components in life support devices or systems without the express written approval of SGS-THOMSON Microelectronics.

© 1994 SGS-THOMSON Microelectronics - All rights reserved.

Purchase of I<sup>2</sup>C Components by SGS-THOMSON Microelectronics conveys a license under the Philips I<sup>2</sup>C Patent. Rights to use these components in an I<sup>2</sup>C system is granted provided that the system conforms to the I<sup>2</sup>C Standard Specification as defined by Philips.

SGS-THOMSON Microelectronics Group of Companies

Australia - Brazil - France - Germany - Hong Kong - Italy - Japan - Korea - Malaysia - Malta - Morocco - The Netherlands Singapore - Spain - Sweden - Switzerland - Taiwan - Thailand - United Kingdom - U.S.A.

