



TransSheet™ Laundry Instructions

The Barton TransSheets™ are made of sturdy design, however the particulars of their construction calls for specific laundry treatment.

- Machine wash at a normal setting and at 140F / 60C. Depending on the washing machine, this usually means a medium setting.
- Always use a laundry bag when washing a sheet in a top-load washing machine. If washed loose, the thicker border edges and handles of the sheet may get trapped underneath the agitator, which will lead to marking and tearing.
- Mild detergent can be used for good cleaning results.
- Do Not use chlorine bleach or detergent containing such substance.
- Tumble-dry with no heat or the lowest temperature setting.
- Do Not iron.

Note:

The most common causes of laundry damage to sheets are ***machine-washing in a top-loader without a laundry bag*** and ***drying at high temperatures***. ***Overloading a dryer***, even at low temperatures, may expose fabric directly to hot spots caused by the heating element just outside the drum.