

K2 OWNER'S MANUAL ERRATA

Rev. H-2, February 14, 2011

THESE MANUAL CORRECTIONS MUST BE MADE BEFORE YOU BEGIN ASSEMBLY

1. **Page 59, right column, first step (beginning with “Find the ‘C6’ label”):** Replace the step with the following. You can cut this step out of the errata and paste it over the original step.

Install C6 (4.7 pF) next to the “C6” label along the back edge of the board as shown. Note the center hole is not used. These pads are labeled “J15” on the top side (for use with the K60XV Option).



2. **Appendix A, K2 Packing Box Parts List:** Knob KN1, change the part number to E850013.