



## Find little problems before they become big ones.

Take troubleshooting to the next level. The new Fluke 289 True-rms Industrial Logging Multimeter with TrendCapture and advanced data logging Security (1997) A second (1997

helps you detect intermittent events and prevent and analyze failures. Use LoZ, LoPass Filter, and Lo Ohms to solve electrical and electronic problems with speed and accuracy. Need help? Just press the "i" button. It's the kind of performance you expect from a quality Fluke digital multimeter.

Demo online at www.fluke.com/289

Fluke. Keeping your world up and running.®