

# READ ME

## Before Installing

E2087: SRM/UX DLL for BASIC for Windows  
Version A.01.05

**June 1999**

### Installing the Software

The easiest way to install the TASM 2087 BASIC/WIN Client Extensions is to use one of the following BASIC commands to copy a file from the TAMS 2087 floppy disk to the directory where HP BASIC for Windows or HTBasic is installed on your PC. The following examples assume that you have installed HP BASIC for Windows or HTBasic in their default locations ("C:\hpbasic" for HP BASIC for Windows or "C:\htbwin" for HTBasic) and that your floppy disk drive in your PC is at "A:". If these default do not apply to your configuration, then you will need to modify the following commands appropriately.

Case 1: If you have HP BASIC for Windows on a PC running Windows NT:

```
COPY "A:\winnt\srmux.dw6" TO "C:\hpbasic\srmux.dw6"
```

Case 2: If you have HP BASIC for Windows on a PC running Windows 95 or Windows 98:

```
COPY "A:\win9x\srmux.dw6" TO "C:\hpbasic\srmux.dw6"
```

Case 3: If you have HTBasic on a PC running Windows NT:

```
COPY "A:\winnt\srmux.dw6" TO "C:\htbwin\srmux.dw6"
```

Case 4: If you have HTBasic on a PC running Windows 95 or Windows 98:

```
COPY "A:\win9x\srmux.dw6" TO "C:\htbwin\srmux.dw6"
```

You can also use a DOS copy command, or the File Manager, to perform the equivalent of the above operations.

### Revision History

Version 1.02 - Original release of TAMS 2087 BASIC/WIN Client Extensions

Version 1.03 - defect fix for LABEL handling if client accesses multiple SRM/UX volumes

Version 1.04 - defect fix for wildcards (\* or ?) in CAT statements

Version 1.05 - defect fix for STATUS and CONTROL registers with values greater than 32767

Part # E2087-09000

E06.30.99