

## Included with the WJ-CASE:

- Protective Front Cover
- Carrying Case
- Shoulder Strap

## Installation

1. With the oscilloscope's feet flipped open, slide the WaveJet into the back shell of the case. Be sure to align the feet with the cutouts on the bottom of the case's rear panel.
2. During the previous step, thread the case's fastening strap (top of the case) through the WaveJet's handle.



3. After threading the strap, slide it through the top case slot and fasten the snap.



4. Flip both feet on the oscilloscope to the closed position and use two hands to push the WaveJet completely into the case.

