



Fig 3. Microphone pin numbers

8. Once all soldering is complete, you may re-assemble the unit. When assembling, make sure that the wires do not touch each other or any other metal parts. Check for excessive solder which could cause a short. To re-assemble, screw the housing onto the pin receptacle body. Make sure the screw hole and threaded hole line up, and then replace the retaining screws.

Your microphone should now be ready to use with your radio.

MEMO


ZEON PDF Driver Trial  
www.zeon.com.tw