	esla, Inc. ervice Bulletin		Install Felt Flats and Felt Tape to 1 <sup>st</sup> Row Footwells	
SB-21-15-002				
April 6, 2021				
Classification			Section/Group	Mobile Service
Repair Bulletin			15 - Interior Trim	Cannot Perform
Model Year	Model		Country/Region	Version
2021	Model Y		China	All
The model(s) and m applicability of this b			ral approximation of the affected VIN list. Refer to the VIN/E	Bulletin Tracker or Customer/Vehicle profile to determine

Repair Bulletin: This repair bulletin provides instructions on addressing a noted condition or possible customer concern regarding the operation of Tesla vehicles. These instructions should only be performed by trained professionals.

## Condition

Some Model Y vehicles manufactured at Giga Shanghai might produce a squeaking noise when a shoe heel is pressed against the 1<sup>st</sup> row footwells.

## Correction

Install felt flats and apply felt tape to the driver and front passenger footwells to mitigate the noise.

Correction Description	Correction	Time	
SB-21-15-002 Not Applicable		S012115002	0.00
Install Felt Flat And Felt Tape To 1 <sup>st</sup> Row Floor		S022115002	0.95

	Part Number	Description	Quantity
Parts Required	1662269-00-A	FELT TAPE EPP PLUG, LH, MY, CN	1
	1662271-00-A 1662012-00-A	FELT TAPE EPP PLUG, RH, MY, CN FELT FLAT	1 2

These part numbers were current at the time of publication. Use the revisions listed or later, unless otherwise specified in the <u>Parts Catalog</u>.

Special Tools 1111306-00-A Glue Gun

Shop Supplies Glue Stick, Hot Melt

1

## Procedure

- 1. Remove the driver and front passenger seats (refer to Service Manual procedure 13040102).
- 2. Remove the center console (refer to Service Manual procedure <u>15190101</u>).
- 3. Remove the LH front carpet (refer to Service Manual procedure 15301001).
- 4. Position the felt flat onto the floor of the LH 1<sup>st</sup> row footwell as shown (Figure 1).




Figure 1

 If the carpet has separated from the foam backing, use the glue gun to apply hot-melt adhesive to the glue line, use a clean shop towel to firmly press the carpet to the foam backing, and hold for at least 1 minute until cool. (Figure 2).

**!** CAUTION: Wear heat resistant gloves when performing this step.



Figure 2

6. Remove the LH front carpet support plug (Figure 3).





7. Install the LH felt tape onto both sides of the LH front carpet support plug (Figures 4 and 5).




Figure 4



Figure 5

- 8. Install the LH front carpet support plug (Figure 3).
- 9. Install LH front carpet (refer to Service Manual procedure 15301001).
- 10. Repeat steps 3 through step 9 for the RH side.
- 11. Install center console (refer to Service Manual procedure 15190101).
- 12. Install the driver and front passenger seats (refer to Service Manual procedure 13040102).