


Selection Tree



IMP Microprocessor Supervisors and Power Supply Monitors



Active HIGH and Active LOW refer to polarity of reset output.

Super XRef Chart.eps