


# SWITCHING REGULATOR

—SIDE VIEW—



**INPUT**

- CS : CURRENT SENSE
- EI : ERROR AMP
- MPI : MULTIPLIER
- OVP : OVER VOLTAGE PROTECT
- VB : VOLTAGE BIAS

**OUTPUT**

- EO : ERROR AMP

