



CLOCK GENERATOR

—TOP VIEW—



INPUTS

IN : INPUT FOR REFERENCE SYNC PULSE
 FBIN : FEEDBACK
 FS0 : FREQUENCY SELECT 0
 OE : OUTPUT ENABLE

OUTPUTS

CLK1, CLK2 : CLOCK 1, 2

