



046-002-119

Figure 5-6. Frequency Standard Assembly A2A5, Schematic Diagram

5-45/(5-46 blank)

PARTS LOCATION INDEX

REF DES	LCTN	REF DES	LCTN	REF DES	LCTN	REF DES	LCTN	REF DES	LCTN
A1	4A	A1R24	5C	A2C42	12H	A2R24	14C	A4	8E
A1C1	2B	A1Y1	3B	A2C44T	10B	A2R25	13D	A4C1	8D
A1C2	3B	A2	14I	A2CR1	12H	A2R26	13A	A4C2	9E
A1C3	3B	A2C1	8C	A2CR2	11F	A2R27	14B	A4CR1	9D
A1C4	4B	A2C2	7C	A2DS1	13H	A2R28	14D	A4R1	5E
A1C5	4B	A2C3	9B	A2J1	1H, 2F, 17B	A2R29	15A	A4Q1	8E
A1C6	5B	A2C4	8D	A2J2	7E	A2R30T	15D		
A1C7	6A	A2C5	8B	A2L1	9B	A2R31T	16B		
A1C8T	2B	A2C6	8B	A2L2	13B	A2R32	5G		
A1C9	6B	A2C7	10B	A2L3	7G	A2R33	6F		
A1C10	4C	A2C8	10B	A2L4	11G	A2R34	5C		
A1C11T	3B	A2C9	10D	A2Q1	8C	A2R36	6G		
A1C12	2D	A2C10	10C	A2Q2	9B	A2R37	6H		
A1CR1	6A	A2C11	11B	A2Q3	11C	A2R38	6H		
A1CR2	5C	A2C12	11B	A2Q4	13C	A2R39	7F		
A1Q1	4B	A2C13	11B	A2Q5	15C	A2R40	8G		
A1Q2	5B	A2C14	12C	A2Q6	5G	A2R41	8H		
A1Q3	6B	A2C15	12B	A2Q7	7H	A2R42	8F		
A1Q4	3E	A2C16	14B	A2Q8	8G	A2R43	8H		
A1Q5	4E	A2C17	14C	A2Q9	11G	A2R44T	9G		
A1Q6	4C	A2C18	10B	A2Q10	12G	A2R46	10H		
A1Q7	5D	A2C19	10B	A2Q11	13G	A2R47	10G		
A1R1	2B	A2C20	14A	A2R1	7C	A2R48	11F		
A1R2	4B	A2C21	15B	A2R2	8C	A2R49	11H		
A1R3	4A	A2C22	15B	A2R3	8B	A2R51	12G		
A1R4	4A	A2C23	5G	A2R4	8B	A2R52	12H		
A1R5	4B	A2C24	5G	A2R5	9B	A2R53	12G		
A1R6	5B	A2C25	5G	A2R6	9C	A2P54	12H		
A1R7	5A	A2C26	5H	A2R7	5A	A2R55	13G		
A1R8	6A	A2C27	6H	A2R8	9A	A2R56	13H		
A1R9	2A	A2C28	6H	A2R9	8D	A2P57	13F		
A1R10T	3C	A2C29	7G	A2R10	9C	A2R58	14F		
A1R11	4C	A2C30	7H	A2R11	9D	A2R60	7G		
A1R12	6B	A2C31	8G	A2R12	9B	A2R61	9H		
A1R13	2D	A2C32	8H	A2R13	10C	A2R62	5H		
A1R14	3D	A2C33	8G	A2R14	11B	A2S1	3G		
A1R15	3E	A2C34	8G	A2R15	11D	A2T1	12B		
A1R16	3E	A2C35	6G	A2R16	11A	A2T2	15B		
A1R17	3C	A2C36	10G	A2R17	11D	A2T3	9G		
A1R18	4C	A2C37	10G	A2R18T	12B	A3	5D		
A1R19	4E	A2C38	11G	A2R19	12C	A3J2	2E, 5E		
A1R20	4E	A2C39	11G	A2R20	13B	A3Q1	6E		
A1R21	5E	A2C40	11H	A2R21	13D	A3R1	6D		
A1R22	4C	A2C41	11H	A2R22	13B	A3R2	2E		
A1R23T	4D	A2C42	13H	A2R23	13C				

