



ScopeMeter Lab Scope Accessories



C95 ScopeMeter Soft Carrying Case

Grey vinyl carrying case provides an easy way to carry your ScopeMeter around with you. Comes complete with detachable pouches for lead and accessory storage.




PM8907/808 Universal Adapter/Charger (Switchable for 115/230VAC)

Switchable Power Adapter for ScopeMeter charging and operation. Included with Fluke 98.




C98 98 Deluxe Hard Carrying Case

Molded carrying case for ScopeMeters and accessories. Rugged polyethylene with locking latches. (Included with Fluke 98)




PM 9080/001 Optically Isolated RS-232 Interface Cable and Adapters

Enables ScopeMeters to connect with PCs, modems, and serial printers.



PM9083/001 Yellow Protective Holster

Included with Fluke 98. Absorbs shocks and protects from rough handling. Built-in stand and hanger allow easy positioning.



PAC 91 Optical to Parallel Cable Adapter

Enables ScopeMeter to be used with a parallel printer.