

## Service Technical Information

Models Incorporating MD Mechanism

SUBJECT

EEP-ROM Initialization Method

REF.No. :G - A0 - 003 - E0

DATE :18. APR. 2000

## <CONTENTS>

There are instances when the MD causes erroneous action due to EEP–ROM adjustment data abnormalities. In such cases, the MD mechanism adjustment values to the default values using the methods in the following table.

After performing initialization, switch on the power again to confirm that "No Adjust" is displayed.

## <NOTE>

Always make all adjustments when EEP-ROM initialization has been performed.

The MD will work even when "No Adjust" is displayed (not portable MDs).

For models without an initialization method, perform initialization by connecting the MD mechanism to a different model.

## Initialization Method

EEP-ROM initialization is performed in the "All SV Off" state after the test mode has been activated.

Refer to the Service Manual for details regarding test mode and adjustment mode.

MODEL	TYPE	Initialization Method	
AM-F80/75/72	D,K,EZ,HR,HC,HK	Press "DSL" and "PLAY" simultaneously when in adjust mode	
AM-C80/75	C80/75 U,EZ Press "DSL" and "PLAY" simultaneously when in adjust mode		
AM-HX50/55	D,HK,K,EZ	Press "STOP" and "DISP" simultaneously when in adjust mode	
CSD-MD5	D,K,EZ,U,HE	Press the "PROGRAM" key	
CSD-MD22	D,EZ	Hold down the "EDIT" key	
CSD-MD30	D,K,EZ	Hold down the "EDIT" key	
CSD-MD50	D,U,HR,EZ	Press the "SOUND" key	
LCX-MD211	EZ	Press the "CLOCK/TIMER" key	
XR-H220MD	D,K,EZ	Press the "POP" key	
XR-H330MD	H330MD D,U,EZ,K,HD Press the TAPE "SYNC DUB" key		
XR-H550MD	D,K,EZ Press the "GEQ" key		
XR-H770MD	1770MD D,EZ Press the "BBE" key		
XR-HG5MD	EZ,K,D	Press the TAPE "SYNC DUB" key	
XR-MD85	D,LH,K,EZ	Press the "TAPE/REV MODE" key	
XR-MD90/95	D,U,K,EZ	No initialization method	
XR-MD100	D,K,LH,U	Press the CD "OPEN/CLOSE" key	
XR-MD101	EZ	Press the CD "OPEN/CLOSE" key	
XR-MD200	D,K	No initialization method	
XR-MD201	EZ	No initialization method	
XR-MD710	D,K	Press the CD1 "DISC CHANGE/OPEN/CLOSE" key	
XR-MDS7	-MDS7 D,EZ Press the CD "EJECT" key and MD "REC/EDIT" keys simultaneously		

G	R	Code No.	Access Code	Modified Ser. No.	Parts Schedule
_	-	_	_	-	_