



PIN101 (CN101)	
1	REG 12V
2	REG -33V
3	AC 4V
4	POWER ON
5	REG 5V
6	GND
7	EVER 5V
8	UNREG 18V
9	UNREG 45V
10	UNREG 45V
11	GND

TO MAIN C.B. CON202

Рис. 2.7. Принципиальная схема источника питания видеомагнитофонов HV-DK925/975/G100/110/150