

SPE Rack

SPE Rack holds up to 20 solid phase extraction cartridges for on-line purification directly on the Quest 210. The rack conveniently fits on the Quest Waste Tray simplifying product collection.

Part Number: 900182

Quantity: 1

Replacement Parts:

900184 Stainless Steel Needles and Polyethylene Stopcocks (60/pkg)



Instructions. Select the appropriate solid phase extraction (SPE) cartridge for your product work up. Install the SPE cartridges onto the SPE Rack and verify that the stopcocks are closed. Place the SPE Rack onto the Waste Tray of the Quest 210. Adjust the height of the SPE rack so that the Teflon[®] outlet tubes of the lower manifold exit into the SPE cartridges when the Waste Tray is raised. Drain the reaction vessel contents into the SPE cartridges. Remove the SPE Rack from the Quest. Stack the SPE Rack on top of a scintillation vial rack filled with vials. Open the SPE Rack stopcocks to drain the contents of the SPE cartridges into the scintillation vials. Replace the needles and stopcocks when required.

Quest Accessories