

B & K Model 666/606 Parts List

488-051-9-002C

DYNASCAN
PART No.

SCHEMATIC
SYMBOL

MISCELLANEOUS PARTS

SCHEMATIC SYMBOL	DESCRIPTION	DYNASCAN PART No.
T-1	Power Transformer	065-056-9-001
M-1	Meter	320-010-9-001
V-1	6BN8 Tube	235-060-2-148
	Knob with line	751-010-9-001
	Knob, Push button	751-036-9-001
	Case for Model 606	270-005-9-001
	Case for Model 666	271-024-9-001
	"Shorts" Lamp (NE-51) (Model 606)	401-002-9-002
	"Shorts" Lamp (Model 666)	401-002-9-003
	"Shorts" Lamp Clear Plastic Cap, Model 606	750-001-9-002
	Lamp with Resistor	401-001-9-002
	Red Plastic Cap W/Tinnerman	750-003-9-001
	Clear Plastic Cap, Model 666 Shorts indicator	750-003-9-002
	Carton and Filler Model 606	500-116-9-001
	Carton for Model 666	500-224-9-001
	Filler for Carton Model 666	503-083-9-001
	6-Foot Black Line Cord	420-001-9-009
	Plate-Grid Cap Assembly	539-069-0-000
	Instruction Manual	480-157-9-001
	Tube Chart Subscription; Consisting of 1 issue of Tube Chart and 2 supplements per year.	

NOTE: Standard value resistors are not listed. Values may be obtained from schematic diagram.

Minimum charge \$5.00 per invoice. Orders will be shipped C.O.D. unless previous open account arrangements have been made or remittance accompanies order. Advance remittance must cover postage or express charges.

SCHEMATIC SYMBOL

DESCRIPTION

DYNASCAN PART No.

CAPACITORS

C-1	.05 MFD @ 500 V Disc Ceramic Capacitor	020-401-7-503
C-2	5 MFD @ 250 V Pigtail Electrolytic Capacitor	021-018-9-001
C-3	200 MFD @ 4 V Pigtail Electrolytic Capacitor	022-001-9-007
C-4	.01 MFD @ 500 V Disc Ceramic Capacitor	020-501-7-103

RESISTORS—CONTROLS

R-3	100K Ohm 1/2 Watt Control, "Gas Sensitivity Adjust"	008-001-9-009
R-6	2 Megohm Control (Short Adjust)	008-056-9-001
R-7	500 Ohm 5 Watt 5% Wire Wound Resistor	006-005-5-501
R-9	1K Ohm Wire Wound Pot. (Special Taper) "A" Control	009-021-9-001

SWITCHES

SW-1	Heater Switch	083-027-9-001
SW-2	"C" Selector	083-034-9-001
SW-3	"B" Selector	083-035-9-001
SW-4	"Quality" Push Button Switch	091-005-9-001
SW-5	"Grid Emission" Push Button Switch	091-004-9-001

SOCKETS

	Test Sockets No. 1, No. 6 (7 Pin Min.)	749-002-9-007
	Test Sockets No. 10, No. 11 (Novar)	749-025-9-001
	Test Sockets No. 3, No. 8, No. 12 (Octal)	749-002-9-001
	Test Socket No. 4 (Loctal)	749-014-9-001
	Test Socket No. 5 (Nuvistor)	749-015-9-001
	Test Socket No. 7 (9 Pin)	749-002-9-002
	Test Socket No. 2 (10 Pin)	749-002-9-003
	Test Socket No. 9 (12 Pin)	749-024-9-001
	Test Socket No. 13 (Decal)	749-033-9-001
	7 Pin-Pin Straightener	766-004-9-001
	9 Pin-Pin Straightener	766-005-9-001

COMPOSITE
499-055-9-001 B

