Barrett Ballistic Software Quickstart

Installing Barrett Ballistic Software:

- **1.** Insert the CD-ROM to drive for installation. If the installation does not automatically start:
 - **a.** Go to Run in the Start menu.
 - **b.** Browse to and select the *X:\setup.exe* file, where *X* is the CD-ROM or DVD Drive letter.
- **2.** Follow the on screen prompts to complete the installation.

IMPORTANT NOTE

The drivers contained in this software are not Microsoft WHQL certified. Please select "Continue Anyway" or "Install these Drivers" and Allow the driver installation

Using the Barrett Ballistic Software:

The Barrett Ballistic Software is the <u>only</u> way to communicate with BORS. BORS <u>does not</u> need to be connected to the PC Cable and powered ON when creating or customizing Libraries or Cartridge Drop Tables. It is required <u>only</u> when getting Status, Uploading, or Downloading. The basic steps for using the software are listed below. Please refer to the Help Files included with the software for more information.

- **1. Create a New User Library**: To create a New User Library, go to File → New → User Library, or use the New toolbar icon and select New User Library.
- 2. Create a New Cartridge: To create a New Cartridge, first select or create the Library for the new Cartridge. Once the desired Library is selected, go to File → New → Cartridge or use the New toolbar icon and select New Cartridge
- **3.** Calculate Cartridge Drop Table: Define the Cartridge Attributes, Parametric Attributes, and Scope Elevation Knob, then use the Calculate button to generate the Cartridge Drop Table.
- **4.** Save User Library: To Save User Library, use the Save User Library toolbar icon, or go to File \rightarrow Save.
- **5. Turn BORS "ON"**: Ensure the battery is properly installed and press the Power Button to turn BORS ON. See Figure I and Figure II.
- **6. Connect the PC Cable**: Ensure the cable is properly connected to the computer and the BORS. See Figure III and Figure IV.
- 7. Download Library to BORS...: Go to BORS

 → Download Library to BORS... This will
 overwrite all previous Drop Tables in the BORS
 with the Tables in the selected Library.




Figure III. Connect Cable to BORS.




Figure I. Battery Installation.




Figure II. BORS Power Button.



Figure IV. Connect Cable to USB.