

COOLING

HAP
OCT 10/06

21-50-00
SECTION TITLE
PAGE 1

NON-ILLUSTRATED FIGURE

THE ITEMS REFLECTED IN THIS FIGURE ARE INTENTIONALLY
NON-ILLUSTRATED. THEY ARE REFERENCED TO EITHER A
NEXT HIGHER OR NEXT LOWER ASSEMBLY/INSTALLATION FIGURE.

E 21500001 REV 055

FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MAJOR MODEL BASIC AND STABLE (COOLING ONLY)

FIGURE 1

21-50-00-01

HAP
OCT 10/06

21-50-00-01
PAGE 0

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1			FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MAJOR MODEL BASIC AND STABLE (COOLING ONLY)	001030 201967	
- 1	210A0001-678		FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MAJOR MODEL BASIC AND STABLE (COOLING ONLY)	001030 201967	RF
- 20	213A3004-7		FOR NHA/OTHER SYS DET SEE: 21-00-00-33 .PANEL INSTL-RAM AIR INLET POSITION DATA: LH FOR DETAILS SEE: 21-51-21-01A 21-51-23-01A	012019	1
- 20	213A3004-9		.PANEL INSTL-RAM AIR INLET POSITION DATA: LH FOR DETAILS SEE: 21-51-21-01A 21-51-23-01A	020030	1
- 25	213A3004-10		.PANEL INSTL-RAM AIR INLET POSITION DATA: RH FOR DETAILS SEE: 21-51-21-01A 21-51-23-01A	020030	1
- 25	213A3004-8		.PANEL INSTL-RAM AIR INLET POSITION DATA: RH FOR DETAILS SEE: 21-51-21-01A 21-51-23-01A	012019	1
- 30	213A3004-5		.PANEL INSTL-RAM AIR INLET FOR DETAILS SEE: 21-51-21-01A 21-51-23-01A	001011 201967	1
- 35	213A3004-6		.PANEL INSTL-RAM AIR INLET FOR DETAILS SEE: 21-51-21-01A 21-51-23-01A	001011 201967	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

21-50-00-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

21-50-00
FIG. 01
PAGE 1
OCT 15/08

NON-ILLUSTRATED FIGURE

THE ITEMS REFLECTED IN THIS FIGURE ARE INTENTIONALLY
NON-ILLUSTRATED. THEY ARE REFERENCED TO EITHER A
NEXT HIGHER OR NEXT LOWER ASSEMBLY/INSTALLATION FIGURE.

E 21500001B REV 055

FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MINOR MODEL BASIC AND STABLE (COOLING ONLY)
FIGURE 1B

HAP
OCT 15/08

21-50-00-01B

21-50-00-01B
PAGE 0

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1B			FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MINOR MODEL BASIC AND STABLE (COOLING ONLY)	201967	
- 1	210A0001-700		FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MINOR MODEL BASIC AND STABLE (COOLING ONLY)	201967	RF
- 20	213A1001-1		FOR NHA/OTHER SYS DET SEE: 21-00-00-37 .PACK INSTL-AIR CONDITIONING POSITION DATA: LH FOR DETAILS SEE: 21-51-03-01 21-51-52-01	201967	1
- 25	213A1001-2		.PACK INSTL-AIR CONDITIONING POSITION DATA: RH FOR DETAILS SEE: 21-51-03-01 21-51-52-01	201967	1
- 30	213A1002-1		.DUCT INSTL-AIR CONDITIONING PACK POSITION DATA: LH FOR DETAILS SEE: 21-51-01-02 21-51-09-01 21-51-20-01 21-51-30-01 21-51-31-01 21-51-41-01 21-61-02-01	201967	1
- 35	213A1002-2		.DUCT INSTL-AIR CONDITIONING POSITION DATA: RH FOR DETAILS SEE: 21-51-01-03 21-51-09-02 21-51-20-02 21-51-30-02 21-51-31-02 21-51-41-02 21-61-02-02	201967	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

21-50-00-01B

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

21-50-00
FIG. 01B
PAGE 1
OCT 15/08

 **BOEING**
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1B					
- 50	213A1003-1		.SEPARATOR INSTL-AIR CONDITIONING WATER POSITION DATA: LH FOR DETAILS SEE: 21-51-05-01 21-51-32-01	201967	1
- 55	213A1003-2		.SEPARATOR INSTL-AIR CONDITIONING WATER POSITION DATA: RH FOR DETAILS SEE: 21-51-05-01 21-51-32-01	201967	1
- 60	213A1004-1		.SENSE LINE INSTL- POSITION DATA: LH FOR DETAILS SEE: 21-51-53-02	201967	1
- 65	213A1004-2		.SENSE LINE INSTL- POSITION DATA: RH FOR DETAILS SEE: 21-51-53-03	201967	1
- 70	213A3002-1		.DUCT INSTL-RAM AIR INLET POSITION DATA: LH FOR DETAILS SEE: 21-51-24-04	201967	1
- 75	213A3002-2		.DUCT INSTL-RAM AIR INLET POSITION DATA: RH FOR DETAILS SEE: 21-51-24-04	201967	1
- 80	213A3003-1		.DUCT INSTL-RAM AIR EXH POSITION DATA: LH FOR DETAILS SEE: 21-51-24-01	201967	1
- 85	213A3003-2		.DUCT INSTL-RAM AIR EXH POSITION DATA: RH FOR DETAILS SEE: 21-51-24-01	201967	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

21-50-00-01B

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

21-50-00
FIG. 01B
PAGE 2
OCT 15/08

NON-ILLUSTRATED FIGURE

THE ITEMS REFLECTED IN THIS FIGURE ARE INTENTIONALLY
NON-ILLUSTRATED. THEY ARE REFERENCED TO EITHER A
NEXT HIGHER OR NEXT LOWER ASSEMBLY/INSTALLATION FIGURE.

E 21500001C REV 055

FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MINOR MODEL BASIC AND STABLE (COOLING ONLY)
FIGURE 1C

HAP
OCT 10/06

21-50-00-01C

21-50-00-01C
PAGE 0

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1C			FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MINOR MODEL BASIC AND STABLE (COOLING ONLY)	001030	
- 1	210A0001-800		FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MINOR MODEL BASIC AND STABLE (COOLING ONLY)	001030	RF
- 20	213A1001-3		FOR NHA/OTHER SYS DET SEE: 21-00-00-38 .PACK INSTL-AIR CONDITIONING POSITION DATA: LH FOR DETAILS SEE: 21-51-03-01A 21-51-52-02	001030	1
- 25	213A1001-4		.PACK INSTL-AIR CONDITIONING POSITION DATA: LH FOR DETAILS SEE: 21-51-03-01A 21-51-52-02	001030	1
- 30	213A1002-3		.DUCT INSTL-AIR CONDITIONING PACK POSITION DATA: LH FOR DETAILS SEE: 21-51-01-04 21-51-07-01 21-51-10-01 21-51-11-02 21-51-13-01 21-51-15-01 21-51-17-02 21-51-41-03	001030	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

21-50-00-01C

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

21-50-00
FIG. 01C
PAGE 1
OCT 10/06

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1C - 35	213A1002-4		. DUCT INSTL-AIR CONDITIONING POSITION DATA: RH FOR DETAILS SEE: 21-51-01-05 21-51-07-02 21-51-10-02 21-51-11-03 21-51-13-01 21-51-15-02 21-51-17-03 21-51-41-04	001030	1
- 40	213A1003-3		. SEPARATOR INSTL-AIR CONDITIONING HIGH PRESSURE WATER POSITION DATA: LH FOR DETAILS SEE: 21-51-12-01 21-51-13-01 21-51-14-02 21-51-52-03 21-51-60-01	001030	1
- 45	213A1003-4		. SEPARATOR INSTL-AIR CONDITIONING HIGH PRESSURE WATER POSITION DATA: RH FOR DETAILS SEE: 21-51-12-01 21-51-13-01 21-51-14-02 21-51-52-03 21-51-60-01	001030	1
- 50	213A1004-3		. SENSE LINE INSTL-AIR CONDITIONING PACK POSITION DATA: L SIDE FOR DETAILS SEE: 21-51-53-18	001011	1
- 50	213A1004-5		. SENSE LINE INSTL-AIR CONDITIONING PACK POSITION DATA: L SIDE FOR DETAILS SEE: 21-51-53-18	012028	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

21-50-00-01C

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

21-50-00
FIG. 01C
PAGE 2
OCT 10/06

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1C					
- 50	213A1004-7		.SENSE LINE INSTL-AIR CONDITIONING PACK POSITION DATA: L SIDE FOR DETAILS SEE: 21-51-53-18	029030	1
- 55	213A1004-4		.SENSE LINE INSTL-AIR CONDITIONING PACK POSITION DATA: R SIDE FOR DETAILS SEE: 21-51-53-19	001030	1
- 65	213A3002-1		.DUCT INSTL-RAM AIR INLET POSITION DATA: LH FOR DETAILS SEE: 21-51-24-04	001030	1
- 70	213A3002-2		.DUCT INSTL-RAM AIR INLET POSITION DATA: RH FOR DETAILS SEE: 21-51-24-04	001030	1
- 75	213A3003-1		.DUCT INSTL-RAM AIR EXH POSITION DATA: LH FOR DETAILS SEE: 21-51-24-01	001027	1
- 75	213A3003-7		.DUCT INSTL-RAM AIR EXH POSITION DATA: LH FOR DETAILS SEE: 21-51-24-01	028030	1
- 80	213A3003-2		.DUCT INSTL-RAM AIR EXH POSITION DATA: RH FOR DETAILS SEE: 21-51-24-01	001027	1
- 80	213A3003-8		.DUCT INSTL-RAM AIR EXH POSITION DATA: RH FOR DETAILS SEE: 21-51-24-01	028030	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

21-50-00-01C

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

21-50-00
FIG. 01C
PAGE 3
OCT 10/06