

 **BOEING**
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*21	1	JUN 15/09	21-00-51- 2	0A	OCT 15/08
*21	2	JUN 15/09	21-00-51- 2	1	OCT 15/08
*21	3	JUN 15/09	21-00-51- 2	2	OCT 15/08
*21	4	JUN 15/09	21-00-51- 2	3	FEB 15/09
*21	5	JUN 15/09	21-00-51- 3	0	FEB 10/07
*21	6	JUN 15/09	21-00-51- 3	0A	FEB 10/07
*21	7	JUN 15/09	21-00-51- 3	0B	FEB 10/07
*21	8	JUN 15/09	21-00-51- 3	0C	FEB 10/07
*21	9	JUN 15/09	21-00-51- 3	0D	FEB 10/07
*21	10	JUN 15/09	21-00-51- 3	1	OCT 15/08
*21	11	JUN 15/09	21-00-51- 3	2	FEB 15/09
*21	12	JUN 15/09	21-00-51- 3	3	OCT 15/08
*21	13	JUN 15/09	21-00-51- 3	4	OCT 15/08
*21	14	JUN 15/09	21-00-51- 4	0	OCT 10/06
*21	15	JUN 15/09	21-00-51- 4	0A	OCT 10/06
*21	16	JUN 15/09	21-00-51- 4	0B	OCT 10/06
*21	17	JUN 15/09	21-00-51- 4	1	JUN 10/07
*21	18	JUN 15/09	21-00-51- 4	2	OCT 10/07
*21	19	JUN 15/09	21-00-51- 4	3	FEB 15/09
*21	20	JUN 15/09	21-00-51- 4	4	OCT 10/07
*21	21	JUN 15/09	21-00-51- 5	0	JUN 15/08
*21	22	JUN 15/09	21-00-51- 5	0A	JUN 15/08
*21	23	JUN 15/09	21-00-51- 5	1	FEB 15/09
*21	24	JUN 15/09	21-00-51- 5	2	FEB 15/09
*21	25	JUN 15/09	21-00-51- 5	3	FEB 15/09
*21	26	JUN 15/09	21-20-00	1	OCT 10/06
*21	27	JUN 15/09	21-20-00- 4	0	OCT 10/06
*21	28	JUN 15/09	21-20-00- 4	1	OCT 15/08
*21	29	JUN 15/09	21-20-00- 4	2	OCT 15/08
*21	30	JUN 15/09	21-20-00- 4	3	OCT 15/08
21-00-00	1	OCT 10/06	21-20-00- 4B	0	OCT 15/08
21-00-00-33	0	OCT 10/06	21-20-00- 4B	1	OCT 15/08
21-00-00-33	1	OCT 15/08	21-20-00- 4B	2	OCT 15/08
21-00-00-33A	0	OCT 10/06	21-20-00- 4B	3	OCT 15/08
21-00-00-33A	1	OCT 15/08	21-20-00- 4C	0	OCT 10/06
21-00-00-37	0	OCT 15/08	21-20-00- 4C	1	OCT 10/06
21-00-00-37	1	OCT 15/08	21-20-00- 4C	2	OCT 10/06
21-00-00-38	0	OCT 10/06	21-20-00- 4C	3	FEB 15/08
21-00-00-38	1	OCT 10/06	21-20-00- 4C	4	FEB 15/08
21-00-00-42	0	OCT 15/08	21-20-00- 4C	5	FEB 15/08
21-00-00-42	1	OCT 15/08	21-20-00- 4C	6	FEB 15/08
21-00-00-43	0	OCT 10/06	21-20-00- 5	0	OCT 15/08
21-00-00-43	1	OCT 10/06	21-20-00- 5	0A	OCT 15/08
21-00-00-43A	0	OCT 10/06	21-20-00- 5	0B	OCT 15/08
21-00-00-43A	1	OCT 10/06	21-20-00- 5	0C	OCT 15/08
21-00-00-46	0	OCT 10/06	21-20-00- 5	0D	OCT 15/08
21-00-00-46	1	OCT 15/08	21-20-00- 5	1	FEB 15/09
21-00-00-46A	0	OCT 15/08	21-20-00- 5	2	OCT 15/08
21-00-00-46A	1	OCT 15/08	*21-20-00- 5	3	JUN 15/09
21-00-00-46A	2	OCT 15/08	*21-20-00- 5	4	JUN 15/09
21-00-51- 2	0	OCT 15/08	*21-20-00- 5	5	JUN 15/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 1


BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-20-00- 9B	0	OCT 15/08	*21-21-01- 2	9	JUN 15/09
21-20-00- 9B	1	OCT 15/08	*21-21-01- 2	10	JUN 15/09
21-20-00- 9B	2	OCT 15/08	21-21-01- 3	0	OCT 10/06
21-20-00- 9C	0	OCT 10/06	21-21-01- 3	1	OCT 15/08
21-20-00- 9C	1	OCT 10/06	21-21-01- 5	0	OCT 10/06
21-20-00- 9C	2	OCT 10/06	21-21-01- 5	0A	OCT 10/06
21-20-00- 9C	3	OCT 10/06	21-21-01- 5	0B	OCT 10/06
21-20-00-49B	0	OCT 10/06	21-21-01- 5	1	FEB 10/07
21-20-00-49B	1	OCT 10/06	21-21-01- 5	2	FEB 10/07
21-20-00-49C	0	OCT 15/08	21-21-01- 5	3	FEB 10/07
21-20-00-49C	1	OCT 15/08	21-21-01-10	0	FEB 10/07
21-20-00-49C	2	OCT 15/08	21-21-01-10	0A	FEB 10/07
21-21-00	1	OCT 10/06	21-21-01-10	0B	FEB 10/07
21-21-01- 1	0	OCT 10/06	21-21-01-10	0C	FEB 10/07
21-21-01- 1	0A	OCT 10/06	21-21-01-10	1	FEB 15/09
21-21-01- 1	0B	OCT 10/06	*21-21-01-10	2	JUN 15/09
21-21-01- 1	0C	OCT 10/06	*21-21-01-10	3	JUN 15/09
21-21-01- 1	0D	OCT 10/06	*21-21-01-10	4	JUN 15/09
21-21-01- 1	0E	OCT 10/06	*21-21-01-10	5	JUN 15/09
21-21-01- 1	0F	OCT 10/06	*21-21-01-10	6	JUN 15/09
21-21-01- 1	0G	OCT 10/06	21-21-02- 4	0	FEB 10/07
21-21-01- 1	0H	OCT 10/06	21-21-02- 4	0A	FEB 10/07
21-21-01- 1	0I	OCT 10/06	21-21-02- 4	0B	FEB 10/07
21-21-01- 1	0J	OCT 10/06	21-21-02- 4	0C	FEB 10/07
21-21-01- 1	1	OCT 10/07	21-21-02- 4	1	OCT 15/08
21-21-01- 1	2	FEB 15/09	21-21-02- 4	2	FEB 15/09
21-21-01- 1	3	OCT 10/07	21-21-02- 4	3	OCT 15/08
21-21-01- 1	4	OCT 10/07	21-21-02- 4	4	OCT 15/08
21-21-01- 1	5	OCT 10/07	21-21-02- 4	5	OCT 15/08
21-21-01- 1	6	OCT 10/07	21-21-51- 5	0	FEB 10/07
21-21-01- 1	7	OCT 10/07	21-21-51- 5	0A	FEB 10/07
21-21-01- 1	8	OCT 15/08	21-21-51- 5	0B	FEB 10/07
21-21-01- 1	9	OCT 15/08	21-21-51- 5	1	OCT 15/08
21-21-01- 1	10	OCT 15/08	21-21-51- 5	2	OCT 15/08
21-21-01- 1	11	OCT 10/07	21-21-51- 5	3	OCT 15/08
21-21-01- 1	12	OCT 10/07	21-21-51- 5	4	OCT 15/08
21-21-01- 2	0	OCT 10/06	21-21-51- 5	5	OCT 15/08
21-21-01- 2	0A	OCT 10/06	21-21-51- 5	6	OCT 15/08
21-21-01- 2	0B	OCT 10/06	21-21-51- 5	7	OCT 15/08
21-21-01- 2	0C	OCT 10/06	21-21-51- 5B	0	FEB 15/08
21-21-01- 2	0D	OCT 10/06	21-21-51- 5B	0A	FEB 15/08
21-21-01- 2	0E	OCT 10/06	21-21-51- 5B	0B	FEB 15/08
21-21-01- 2	0F	OCT 10/06	21-21-51- 5B	1	OCT 15/08
21-21-01- 2	1	OCT 15/08	21-21-51- 5B	2	OCT 15/08
21-21-01- 2	2	OCT 15/08	21-21-51- 5B	3	OCT 15/08
21-21-01- 2	3	FEB 15/09	21-21-51- 5B	4	OCT 15/08
21-21-01- 2	4	FEB 15/09	21-21-51- 5B	5	OCT 15/08
21-21-01- 2	5	FEB 15/09	21-21-51- 5B	6	OCT 15/08
21-21-01- 2	6	FEB 15/09	21-22-00	1	OCT 10/06
*21-21-01- 2	7	JUN 15/09	21-22-00- 2	0	OCT 10/06
*21-21-01- 2	8	JUN 15/09	21-22-00- 2	0A	OCT 10/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 2


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-22-00- 2	0B	OCT 10/06	21-22-00-10	0	OCT 10/06
21-22-00- 2	0C	FEB 15/09	21-22-00-10	0A	OCT 10/06
21-22-00- 2	1	FEB 15/09	21-22-00-10	1	OCT 15/08
21-22-00- 2	2	FEB 15/09	21-22-00-10	2	OCT 15/08
21-22-00- 4	0	FEB 10/07	21-22-00-10	3	OCT 15/08
21-22-00- 4	0A	FEB 15/09	21-22-00-11	0	OCT 10/06
21-22-00- 4	0B	FEB 10/07	21-22-00-11	0A	OCT 10/06
21-22-00- 4	0C	FEB 10/07	21-22-00-11	1	OCT 15/08
21-22-00- 4	0D	FEB 10/07	21-22-00-11A	0	FEB 10/07
21-22-00- 4	0E	FEB 10/07	21-22-00-11A	1	OCT 15/08
21-22-00- 4	1	FEB 15/09	21-22-00-11A	2	OCT 15/08
*21-22-00- 4	2	JUN 15/09	21-22-01- 1	0	JUN 10/07
*21-22-00- 4	3	JUN 15/09	21-22-01- 1	0A	JUN 10/07
*21-22-00- 4	4	JUN 15/09	21-22-01- 1	0B	OCT 10/06
*21-22-00- 4	5	JUN 15/09	21-22-01- 1	1	OCT 15/08
*21-22-00- 4	6	JUN 15/09	21-22-01- 1	2	OCT 15/08
*21-22-00- 4	7	JUN 15/09	21-22-01- 1	3	FEB 15/09
21-22-00- 5	0	OCT 10/06	21-22-01- 1	4	OCT 15/08
21-22-00- 5	0A	FEB 15/09	21-22-01- 1A	0	FEB 10/07
21-22-00- 5	0B	OCT 10/06	21-22-01- 1A	0A	FEB 10/07
21-22-00- 5	0C	OCT 10/06	21-22-01- 1A	0B	FEB 10/07
21-22-00- 5	0D	OCT 10/06	21-22-01- 1A	1	FEB 15/09
21-22-00- 5	0E	OCT 10/06	21-22-01- 1A	2	FEB 15/09
21-22-00- 5	0F	OCT 10/06	21-22-01- 1A	3	FEB 15/09
21-22-00- 5	1	FEB 15/09	21-22-01- 1A	4	JUN 15/08
*21-22-00- 5	2	JUN 15/09	21-22-02- 1	0	OCT 10/06
*21-22-00- 5	3	JUN 15/09	21-22-02- 1	0A	OCT 10/06
*21-22-00- 5	4	JUN 15/09	21-22-02- 1	1	OCT 15/08
*21-22-00- 5	5	JUN 15/09	21-22-02- 1	2	FEB 15/09
*21-22-00- 5	6	JUN 15/09	21-22-02- 1A	0	FEB 10/07
21-22-00- 6	0	OCT 10/06	21-22-02- 1A	0A	FEB 10/07
21-22-00- 6	0A	OCT 10/06	21-22-02- 1A	1	FEB 15/09
21-22-00- 6	0B	OCT 10/06	21-22-02- 1A	2	FEB 15/09
21-22-00- 6	0C	FEB 15/09	*21-22-02- 2	0	JUN 15/09
21-22-00- 6	1	FEB 15/09	*21-22-02- 2	0A	JUN 15/09
21-22-00- 6	2	FEB 15/09	*21-22-02- 2	0B	JUN 15/09
21-22-00- 6	3	FEB 15/09	*21-22-02- 2	1	JUN 15/09
21-22-00- 6	4	FEB 15/09	*21-22-02- 2	2	JUN 15/09
21-22-00- 6	5	FEB 15/09	*21-22-02- 2	3	JUN 15/09
21-22-00- 6	6	FEB 15/09	*21-22-02- 2	4	JUN 15/09
21-22-00- 6	7	FEB 15/09	21-22-51- 3	0	FEB 10/07
21-22-00- 6	8	FEB 15/09	21-22-51- 3	0A	FEB 10/07
21-22-00- 6	9	FEB 15/09	21-22-51- 3	0B	OCT 10/06
21-22-00- 6	10	FEB 15/09	21-22-51- 3	0C	OCT 10/06
21-22-00- 7	0	OCT 10/06	21-22-51- 3	1	FEB 15/09
21-22-00- 7	1	FEB 15/09	21-22-51- 3	2	OCT 15/08
21-22-00- 9	0	OCT 10/06	21-22-51- 3	3	OCT 15/08
21-22-00- 9	0A	OCT 10/06	21-22-51- 3	4	OCT 15/08
21-22-00- 9	1	OCT 15/08	21-22-51- 3	5	OCT 15/08
21-22-00- 9	2	OCT 15/08	21-22-51- 3A	0	FEB 10/07
21-22-00- 9	3	OCT 15/08	21-22-51- 3A	0A	FEB 10/07

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
 JUN 15/09

21 - LIST OF EFFECTIVE PAGES
 PAGE 3


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-22-51- 3A	0B	FEB 10/07	21-23-00-16C	0B	OCT 10/06
21-22-51- 3A	0C	FEB 10/07	21-23-00-16C	1	FEB 15/09
21-22-51- 3A	1	FEB 15/09	21-23-00-16C	2	FEB 15/09
21-22-51- 3A	2	OCT 15/08	21-23-00-16C	3	JUN 15/08
21-22-51- 3A	3	OCT 15/08	21-23-00-16C	4	JUN 15/09
21-22-51- 3A	4	FEB 15/09	*21-23-00-16C	5	JUN 15/09
21-22-51- 3A	5	FEB 15/09	*21-23-00-16C	0	JUN 15/09
21-22-51- 5	0	FEB 10/07	21-23-01- 1	0A	OCT 15/08
21-22-51- 5	0A	OCT 10/06	21-23-01- 1	0B	OCT 15/08
21-22-51- 5	0B	OCT 10/06	21-23-01- 1	0C	OCT 15/08
21-22-51- 5	1	OCT 15/08	21-23-01- 1	0D	OCT 15/08
21-22-51- 5	2	OCT 15/08	21-23-01- 1	0E	OCT 15/08
21-22-51- 5	3	OCT 15/08	21-23-01- 1	0F	OCT 15/08
21-22-51- 5A	0	FEB 10/07	21-23-01- 1	0G	OCT 15/08
21-22-51- 5A	0A	FEB 10/07	21-23-01- 1	1	OCT 15/08
21-22-51- 5A	0B	FEB 10/07	21-23-01- 1	2	OCT 15/08
21-22-51- 5A	1	OCT 15/08	21-23-01- 1	3	OCT 15/08
21-22-51- 5A	2	OCT 15/08	21-23-01- 1	4	JUN 15/09
21-22-51- 5A	3	OCT 15/08	*21-23-01- 1	5	OCT 15/08
21-22-51- 5B	0	FEB 10/07	21-23-01- 1	0	OCT 15/08
21-22-51- 5B	1	OCT 15/08	21-23-01- 2	0A	JUN 15/09
21-22-51- 6	0	OCT 15/08	*21-23-01- 2	0B	OCT 15/08
21-22-51- 6	0A	OCT 15/08	21-23-01- 2	0C	OCT 15/08
21-22-51- 6	0B	FEB 15/09	21-23-01- 2	0D	OCT 15/08
21-22-51- 6	1	FEB 15/09	21-23-01- 2	1	OCT 15/08
21-22-51- 6	2	FEB 15/09	*21-23-01- 2	2	JUN 15/09
21-22-51- 6A	0	FEB 10/07	*21-23-01- 2	3	JUN 15/09
21-22-51- 6A	0A	FEB 10/07	*21-23-01- 2	4	JUN 15/09
21-22-51- 6A	0B	FEB 15/09	21-23-01- 3	0	OCT 15/08
21-22-51- 6A	1	FEB 15/09	21-23-01- 3	0A	OCT 15/08
21-22-51- 6A	2	FEB 15/09	21-23-01- 3	0B	OCT 15/08
21-23-00	1	OCT 10/06	*21-23-01- 3	0C	JUN 15/09
21-23-00-13	0	OCT 10/06	21-23-01- 3	0D	OCT 15/08
21-23-00-13	1	FEB 15/09	21-23-01- 3	0E	OCT 15/08
21-23-00-13	2	FEB 15/09	*21-23-01- 3	0F	JUN 15/09
21-23-00-15A	0	OCT 15/08	21-23-01- 3	0G	OCT 15/08
21-23-00-15A	1	OCT 15/08	*21-23-01- 3	0H	JUN 15/09
21-23-00-15B	0	OCT 10/06	21-23-01- 3	1	OCT 15/08
21-23-00-15B	1	OCT 10/06	21-23-01- 3	2	OCT 15/08
21-23-00-16B	0	JUN 15/08	*21-23-01- 3	3	JUN 15/09
21-23-00-16B	0A	JUN 15/08	*21-23-01- 3	4	JUN 15/09
21-23-00-16B	0B	JUN 10/07	*21-23-01- 3	5	JUN 15/09
21-23-00-16B	0C	JUN 10/07	*21-23-01- 3	6	JUN 15/09
21-23-00-16B	0D	JUN 10/07	*21-23-01- 3	7	JUN 15/09
*21-23-00-16B	1	JUN 15/09	*21-23-01- 3	8	JUN 15/09
*21-23-00-16B	2	JUN 15/09	*21-23-01- 3	9	JUN 15/09
*21-23-00-16B	3	JUN 15/09	21-23-01- 4A	0	OCT 10/06
*21-23-00-16B	4	JUN 15/09	21-23-01- 4A	0A	OCT 10/06
*21-23-00-16B	5	JUN 15/09	21-23-01- 4A	0B	OCT 10/06
21-23-00-16C	0	JUN 15/08	21-23-01- 4A	0C	OCT 10/06
21-23-00-16C	0A	OCT 10/06	21-23-01- 4A	0D	OCT 10/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
 JUN 15/09

21 - LIST OF EFFECTIVE PAGES
 PAGE 4


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-23-01- 4A	0E	OCT 10/06	*21-23-01- 6	6	JUN 15/09
*21-23-01- 4A	0F	JUN 15/09	*21-23-01- 6	7	JUN 15/09
21-23-01- 4A	0G	OCT 10/06	*21-23-01- 6	8	JUN 15/09
21-23-01- 4A	0H	OCT 10/06	21-23-01-16	0	OCT 10/06
21-23-01- 4A	1	FEB 10/07	21-23-01-16	1	OCT 15/08
*21-23-01- 4A	2	JUN 15/09	21-23-01-16	2	OCT 15/08
21-23-01- 4A	3	FEB 10/07	21-23-01-17A	0	FEB 15/09
21-23-01- 4A	4	FEB 10/07	*21-23-01-17A	0A	JUN 15/09
21-23-01- 5	0	OCT 10/06	21-23-01-17A	0B	FEB 10/07
21-23-01- 5	0A	OCT 10/06	21-23-01-17A	0C	FEB 10/07
21-23-01- 5	0B	OCT 10/06	21-23-01-17A	1	FEB 15/09
*21-23-01- 5	0C	JUN 15/09	21-23-01-17A	2	FEB 15/09
*21-23-01- 5	0D	JUN 15/09	21-23-01-17A	3	FEB 15/09
21-23-01- 5	0E	OCT 10/06	*21-23-01-17A	4	JUN 15/09
21-23-01- 5	0F	OCT 10/06	*21-23-01-17A	5	JUN 15/09
21-23-01- 5	0G	OCT 10/06	21-23-01-18	0	FEB 10/07
21-23-01- 5	1	OCT 10/07	21-23-01-18	1	OCT 15/08
*21-23-01- 5	2	JUN 15/09	21-23-01-20A	0	FEB 15/09
*21-23-01- 5	3	JUN 15/09	21-23-01-20A	0A	FEB 10/07
*21-23-01- 5	4	JUN 15/09	21-23-01-20A	0B	FEB 10/07
*21-23-01- 5	5	JUN 15/09	*21-23-01-20A	0C	JUN 15/09
*21-23-01- 5	6	JUN 15/09	21-23-01-20A	0D	FEB 10/07
*21-23-01- 5	7	JUN 15/09	21-23-01-20A	0E	FEB 10/07
21-23-01- 5A	0	FEB 15/09	*21-23-01-20A	0F	JUN 15/09
21-23-01- 5A	0A	OCT 10/06	21-23-01-20A	0G	FEB 10/07
*21-23-01- 5A	0B	JUN 15/09	21-23-01-20A	0H	FEB 10/07
21-23-01- 5A	0C	OCT 10/06	21-23-01-20A	1	FEB 15/09
*21-23-01- 5A	0D	JUN 15/09	21-23-01-20A	2	FEB 15/09
21-23-01- 5A	0E	OCT 10/06	21-23-01-20A	3	FEB 15/09
21-23-01- 5A	1	FEB 15/09	*21-23-01-20A	4	JUN 15/09
21-23-01- 5A	2	FEB 15/09	*21-23-01-20A	5	JUN 15/09
*21-23-01- 5A	3	JUN 15/09	*21-23-01-20A	6	JUN 15/09
21-23-01- 5A	4	FEB 15/09	*21-23-01-20A	7	JUN 15/09
*21-23-01- 5A	5	JUN 15/09	*21-23-01-20A	8	JUN 15/09
*21-23-01- 5A	6	JUN 15/09	*21-23-01-20A	9	JUN 15/09
21-23-01- 5A	7	FEB 15/09	*21-23-01-20A	10	JUN 15/09
21-23-01- 6	0	OCT 10/06	*21-23-01-20A	11	JUN 15/09
21-23-01- 6	0A	OCT 10/06	21-23-01-22	0	OCT 10/06
21-23-01- 6	0B	OCT 10/06	21-23-01-22	0A	OCT 10/06
*21-23-01- 6	0C	JUN 15/09	21-23-01-22	0B	OCT 10/06
21-23-01- 6	0D	OCT 10/06	21-23-01-22	0C	OCT 10/06
*21-23-01- 6	0E	JUN 15/09	*21-23-01-22	0D	JUN 15/09
*21-23-01- 6	0F	JUN 15/09	21-23-01-22	0E	OCT 10/06
21-23-01- 6	0G	OCT 10/06	21-23-01-22	0F	OCT 10/06
21-23-01- 6	0H	OCT 10/06	21-23-01-22	0G	OCT 10/06
21-23-01- 6	0I	OCT 10/06	*21-23-01-22	0H	JUN 15/09
21-23-01- 6	1	FEB 10/07	21-23-01-22	0I	OCT 10/06
21-23-01- 6	2	FEB 10/07	21-23-01-22	0J	OCT 10/06
*21-23-01- 6	3	JUN 15/09	21-23-01-22	1	OCT 10/07
21-23-01- 6	4	FEB 10/07	21-23-01-22	2	JUN 10/07
*21-23-01- 6	5	JUN 15/09	21-23-01-22	3	JUN 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 5



BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*21-23-01-22	4	JUN 15/09	21-23-01-28A	0A	OCT 10/06
21-23-01-22	5	JUN 10/07	21-23-01-28A	0B	OCT 10/06
21-23-01-22	6	JUN 10/07	*21-23-01-28A	0C	JUN 15/09
21-23-01-22	7	JUN 15/08	21-23-01-28A	0D	OCT 10/06
*21-23-01-22	8	JUN 15/09	21-23-01-28A	1	JUN 10/07
*21-23-01-22	9	JUN 15/09	21-23-01-28A	2	JUN 10/07
*21-23-01-22	10	JUN 15/09	21-23-01-28A	3	JUN 10/07
21-23-01-22A	0	OCT 10/06	*21-23-01-28A	4	JUN 15/09
21-23-01-22A	0A	OCT 10/06	21-23-01-28C	0	FEB 15/09
21-23-01-22A	0B	OCT 10/06	21-23-01-28C	0A	FEB 10/07
*21-23-01-22A	0C	JUN 15/09	21-23-01-28C	0B	FEB 10/07
21-23-01-22A	0D	OCT 10/06	*21-23-01-28C	0C	JUN 15/09
21-23-01-22A	0E	OCT 10/06	21-23-01-28C	0D	FEB 10/07
*21-23-01-22A	0F	JUN 15/09	21-23-01-28C	1	FEB 15/09
*21-23-01-22A	0G	JUN 15/09	21-23-01-28C	2	FEB 15/09
21-23-01-22A	0H	OCT 10/06	21-23-01-28C	3	FEB 15/09
21-23-01-22A	1	FEB 10/07	21-23-01-28C	4	FEB 15/09
21-23-01-22A	2	FEB 10/07	*21-23-01-28C	5	JUN 15/09
21-23-01-22A	3	FEB 10/07	21-23-01-28D	0	FEB 15/09
21-23-01-22A	4	FEB 10/07	21-23-01-28D	0A	OCT 10/06
*21-23-01-22A	5	JUN 15/09	21-23-01-28D	0B	OCT 10/06
21-23-01-22A	6	FEB 10/07	*21-23-01-28D	0C	JUN 15/09
21-23-01-22A	7	FEB 10/07	21-23-01-28D	0D	OCT 10/06
21-23-01-22A	8	FEB 10/07	21-23-01-28D	1	FEB 15/09
*21-23-01-22A	9	JUN 15/09	21-23-01-28D	2	FEB 15/09
21-23-01-22A	10	FEB 10/07	21-23-01-28D	3	FEB 15/09
*21-23-01-22A	11	JUN 15/09	*21-23-01-28D	4	JUN 15/09
21-23-01-22B	0	FEB 15/09	*21-23-01-28D	5	JUN 15/09
21-23-01-22B	0A	FEB 10/07	21-23-01-29	0	OCT 10/06
21-23-01-22B	0B	FEB 10/07	21-23-01-29	1	JUN 10/07
*21-23-01-22B	0C	JUN 15/09	21-23-01-30A	0	FEB 15/09
21-23-01-22B	0D	FEB 10/07	21-23-01-30A	0A	FEB 10/07
21-23-01-22B	0E	FEB 10/07	21-23-01-30A	0B	FEB 15/09
*21-23-01-22B	0F	JUN 15/09	21-23-01-30A	0C	FEB 10/07
*21-23-01-22B	0G	JUN 15/09	21-23-01-30A	0D	FEB 10/07
21-23-01-22B	0H	FEB 10/07	21-23-01-30A	0E	OCT 10/07
21-23-01-22B	1	FEB 15/09	21-23-01-30A	1	FEB 15/09
21-23-01-22B	2	FEB 15/09	21-23-01-30A	2	FEB 15/09
21-23-01-22B	3	FEB 15/09	21-23-01-30A	3	FEB 15/09
21-23-01-22B	4	FEB 15/09	21-23-01-30A	4	FEB 15/09
21-23-01-22B	5	FEB 15/09	21-23-01-30A	5	FEB 15/09
*21-23-01-22B	6	JUN 15/09	21-23-01-32D	0	OCT 15/08
*21-23-01-22B	7	JUN 15/09	21-23-01-32D	0A	OCT 10/06
*21-23-01-22B	8	JUN 15/09	21-23-01-32D	0B	OCT 10/06
21-23-01-22B	9	FEB 15/09	21-23-01-32D	0C	OCT 10/06
*21-23-01-22B	10	JUN 15/09	21-23-01-32D	0D	OCT 10/06
21-23-01-22B	11	FEB 15/09	21-23-01-32D	0E	OCT 15/08
*21-23-01-22B	12	JUN 15/09	21-23-01-32D	0F	OCT 10/06
21-23-01-23	0	OCT 10/06	21-23-01-32D	0G	OCT 10/06
21-23-01-23	1	OCT 15/08	21-23-01-32D	0H	OCT 10/06
21-23-01-28A	0	OCT 10/06	21-23-01-32D	0I	OCT 10/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 6


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-23-01-32D	0J	OCT 10/06	21-23-51-15C	0B	FEB 15/08
21-23-01-32D	1	FEB 15/09	21-23-51-15C	1	FEB 15/09
21-23-01-32D	2	OCT 10/07	21-23-51-15C	2	OCT 15/08
21-23-01-32D	3	OCT 15/08	21-23-51-15C	3	OCT 15/08
21-23-01-32D	4	OCT 15/08	21-23-51-15C	4	OCT 15/08
21-23-01-32D	5	OCT 15/08	21-23-51-22	0	OCT 10/07
21-23-01-32D	6	OCT 15/08	21-23-51-22	0A	OCT 10/07
21-23-01-32D	7	OCT 15/08	21-23-51-22	0B	OCT 10/07
21-23-01-38	0	OCT 10/06	21-23-51-22	1	OCT 15/08
21-23-01-38	1	FEB 10/07	21-23-51-22	2	OCT 15/08
21-23-01-40	0	OCT 10/06	21-23-51-24	0	FEB 15/09
21-23-01-40	1	JUN 10/07	21-23-51-24	0A	OCT 10/06
21-23-01-51	0	OCT 10/06	21-23-51-24	0B	FEB 15/09
21-23-01-51	0A	OCT 10/06	21-23-51-24	0C	FEB 15/09
21-23-01-51	1	JUN 10/07	21-23-51-24	1	OCT 10/07
21-23-01-52	0	JUN 15/08	21-23-51-24	2	FEB 15/09
21-23-01-52	0A	JUN 15/08	21-23-51-25A	0	FEB 10/07
21-23-01-52	1	FEB 15/09	21-23-51-25A	1	OCT 15/08
21-23-01-52B	0	FEB 15/08	21-23-51-25B	0	OCT 10/06
21-23-01-52B	0A	FEB 15/08	21-23-51-25B	1	FEB 10/07
21-23-01-52B	1	FEB 15/09	21-23-51-28A	0	OCT 10/06
21-23-01-52B	2	FEB 15/09	21-23-51-28A	0A	OCT 10/06
21-23-01-55	0	OCT 15/08	21-23-51-28A	0B	OCT 10/06
21-23-01-55	1	OCT 15/08	21-23-51-28A	0C	OCT 10/06
21-23-01-55A	0	JUN 15/08	21-23-51-28A	0D	OCT 10/06
21-23-01-55A	0A	JUN 15/08	21-23-51-28A	0E	OCT 10/06
21-23-01-55A	1	JUN 15/08	21-23-51-28A	0F	OCT 10/06
21-23-01-55A	2	JUN 15/08	21-23-51-28A	0G	OCT 10/06
21-23-01-56	0	OCT 15/08	21-23-51-28A	1	OCT 10/06
*21-23-01-56	1	JUN 15/09	21-23-51-28A	2	FEB 10/07
21-23-01-57	0	FEB 10/07	21-23-51-28A	3	FEB 10/07
21-23-01-57	0A	FEB 10/07	21-23-51-28A	4	FEB 10/07
21-23-01-57	1	OCT 15/08	21-23-51-28A	5	FEB 10/07
21-23-01-57	2	OCT 15/08	21-23-51-28A	6	FEB 10/07
21-23-01-58	0	OCT 15/08	21-23-51-28B	0	OCT 10/06
21-23-01-58	1	OCT 15/08	21-23-51-28B	0A	OCT 10/06
21-23-51-13B	0	FEB 15/08	21-23-51-28B	0B	OCT 10/06
21-23-51-13B	0A	FEB 15/08	21-23-51-28B	0C	OCT 10/06
21-23-51-13B	0B	FEB 15/08	21-23-51-28B	0D	OCT 10/06
21-23-51-13B	1	OCT 15/08	21-23-51-28B	0E	OCT 10/06
21-23-51-13B	2	OCT 15/08	21-23-51-28B	0F	OCT 10/06
21-23-51-13B	3	OCT 15/08	21-23-51-28B	0G	OCT 10/06
21-23-51-13C	0	FEB 15/09	21-23-51-28B	0H	OCT 10/06
21-23-51-13C	0A	FEB 15/09	21-23-51-28B	1	OCT 10/07
21-23-51-13C	0B	FEB 15/09	21-23-51-28B	2	OCT 10/07
21-23-51-13C	1	FEB 15/08	21-23-51-28B	3	OCT 10/07
21-23-51-13C	2	FEB 15/08	21-23-51-28B	4	OCT 10/07
21-23-51-13C	3	FEB 15/09	21-23-51-29A	0	OCT 15/08
21-23-51-13C	4	FEB 15/09	21-23-51-29A	0A	OCT 15/08
21-23-51-15C	0	FEB 15/08	21-23-51-29A	0B	OCT 15/08
21-23-51-15C	0A	OCT 10/07	21-23-51-29A	1	OCT 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 7


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-23-51-29A	2	OCT 15/08	21-23-51-42C	1	FEB 15/08
21-23-51-29B	0	FEB 10/07	21-23-51-42C	2	FEB 15/09
21-23-51-29B	0A	FEB 10/07	21-23-51-42C	3	OCT 15/08
21-23-51-29B	0B	FEB 15/09	21-23-51-42C	4	OCT 15/08
21-23-51-29B	1	FEB 15/08	21-23-51-42C	5	FEB 15/09
21-23-51-29B	2	FEB 15/09	21-23-51-43A	0	OCT 15/08
21-23-51-29C	0	OCT 10/07	21-23-51-43A	0A	OCT 15/08
21-23-51-29C	0A	OCT 10/07	21-23-51-43A	0B	OCT 15/08
21-23-51-29C	0B	OCT 10/07	21-23-51-43A	0C	OCT 15/08
21-23-51-29C	1	OCT 15/08	21-23-51-43A	0D	OCT 15/08
21-23-51-29C	2	OCT 15/08	21-23-51-43A	0E	OCT 15/08
21-23-51-35B	0	OCT 10/06	21-23-51-43A	0F	OCT 15/08
21-23-51-35B	0A	OCT 10/06	21-23-51-43A	0G	OCT 15/08
21-23-51-35B	0B	OCT 10/06	21-23-51-43A	0H	OCT 15/08
21-23-51-35B	0C	OCT 10/06	21-23-51-43A	0I	OCT 15/08
21-23-51-35B	0D	OCT 10/06	21-23-51-43A	0J	OCT 15/08
21-23-51-35B	0E	OCT 10/06	21-23-51-43A	0K	FEB 15/09
21-23-51-35B	1	OCT 10/06	21-23-51-43A	0L	OCT 15/08
21-23-51-35B	2	FEB 10/07	21-23-51-43A	0M	FEB 15/09
21-23-51-35B	3	OCT 10/06	21-23-51-43A	1	OCT 15/08
21-23-51-35B	4	OCT 10/06	21-23-51-43A	2	FEB 15/09
21-23-51-35B	5	FEB 10/07	21-23-51-43A	3	OCT 15/08
21-23-51-35D	0	OCT 10/06	21-23-51-43A	4	OCT 15/08
21-23-51-35D	0A	OCT 10/06	21-23-51-43A	5	FEB 15/09
21-23-51-35D	0B	OCT 10/06	21-23-51-87	0	OCT 10/07
21-23-51-35D	0C	OCT 10/06	21-23-51-87	0A	OCT 10/07
21-23-51-35D	0D	OCT 10/06	21-23-51-87	0B	OCT 10/07
21-23-51-35D	0E	OCT 10/06	21-23-51-87	0C	OCT 10/07
21-23-51-35D	0F	OCT 10/06	21-23-51-87	0D	OCT 10/07
21-23-51-35D	1	OCT 10/07	21-23-51-87	0E	OCT 10/07
21-23-51-35D	2	OCT 10/07	21-23-51-87	0F	OCT 10/07
21-23-51-35D	3	OCT 10/07	21-23-51-87	0G	OCT 10/07
21-23-51-36	0	OCT 10/07	21-23-51-87	1	OCT 10/07
21-23-51-36	0A	OCT 10/07	21-23-51-87	2	OCT 10/07
21-23-51-36	0B	OCT 10/07	21-23-51-88	0	OCT 10/07
21-23-51-36	0C	OCT 10/07	21-23-51-88	0A	OCT 10/07
21-23-51-36	1	OCT 10/07	21-23-51-88	0B	OCT 10/07
21-23-51-36	2	OCT 10/07	21-23-51-88	0C	OCT 10/07
21-23-51-42C	0	FEB 10/07	21-23-51-88	0D	OCT 10/07
21-23-51-42C	0A	FEB 10/07	21-23-51-88	1	OCT 15/08
21-23-51-42C	0B	FEB 10/07	21-23-51-88	2	OCT 15/08
21-23-51-42C	0C	FEB 10/07	21-23-51-88A	0	OCT 10/07
21-23-51-42C	0D	FEB 10/07	21-23-51-88A	0A	OCT 10/07
21-23-51-42C	0E	FEB 10/07	21-23-51-88A	0B	OCT 10/07
21-23-51-42C	0F	FEB 10/07	21-23-51-88A	0C	OCT 10/07
21-23-51-42C	0G	OCT 15/08	21-23-51-88A	1	OCT 10/07
21-23-51-42C	0H	FEB 10/07	21-23-51-88A	2	OCT 10/07
21-23-51-42C	0I	FEB 10/07	21-23-52- 1A	0	OCT 10/07
21-23-51-42C	0J	FEB 15/09	21-23-52- 1A	0A	OCT 10/07
21-23-51-42C	0K	FEB 15/09	21-23-52- 1A	0B	OCT 10/07
21-23-51-42C	0L	FEB 15/09	21-23-52- 1A	0C	OCT 10/07

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 8


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-23-52- 1A	1	OCT 15/08	21-23-52-34A	0A	OCT 10/06
21-23-52- 1A	2	OCT 15/08	21-23-52-34A	0B	OCT 10/06
21-23-52-20A	0	FEB 15/09	21-23-52-34A	0C	OCT 10/06
21-23-52-20A	0A	FEB 10/07	21-23-52-34A	0D	OCT 10/06
21-23-52-20A	0B	FEB 10/07	21-23-52-34A	0E	OCT 15/08
21-23-52-20A	0C	FEB 10/07	21-23-52-34A	0F	OCT 10/06
21-23-52-20A	0D	FEB 15/09	21-23-52-34A	0G	OCT 10/06
21-23-52-20A	1	FEB 15/08	21-23-52-34A	0H	OCT 10/06
21-23-52-20A	2	FEB 15/08	21-23-52-34A	0I	OCT 10/06
21-23-52-20A	3	FEB 15/09	21-23-52-34A	0J	OCT 10/06
21-23-52-20A	4	FEB 15/09	21-23-52-34A	0K	OCT 10/06
21-23-52-21	0	OCT 15/08	21-23-52-34A	0L	OCT 10/06
21-23-52-21	0A	FEB 15/09	21-23-52-34A	0M	OCT 10/06
21-23-52-21	0B	FEB 15/09	21-23-52-34A	1	JUN 10/07
21-23-52-21	0C	OCT 15/08	21-23-52-34A	2	FEB 15/09
21-23-52-21	0D	FEB 15/09	21-23-52-34A	3	OCT 15/08
21-23-52-21	0E	FEB 15/09	21-23-52-34A	4	OCT 15/08
21-23-52-21	0F	OCT 15/08	21-23-52-34A	5	OCT 15/08
21-23-52-21	0G	FEB 15/09	21-23-52-34A	6	OCT 15/08
21-23-52-21	1	OCT 15/08	21-23-52-35A	0	FEB 15/09
21-23-52-21	2	FEB 15/09	21-23-52-35A	0A	FEB 15/09
21-23-52-21	3	FEB 15/09	21-23-52-35A	0B	FEB 15/09
21-23-52-21	4	FEB 15/09	21-23-52-35A	0C	FEB 15/09
21-23-52-31	0	JUN 15/08	21-23-52-35A	0D	FEB 15/09
21-23-52-31	0A	FEB 10/07	21-23-52-35A	1	FEB 15/09
21-23-52-31	0B	FEB 10/07	21-23-52-35A	2	FEB 15/09
21-23-52-31	0C	FEB 10/07	21-23-52-35B	0	FEB 15/08
21-23-52-31	1	OCT 15/08	21-23-52-35B	0A	FEB 15/09
21-23-52-31	2	OCT 15/08	21-23-52-35B	0B	FEB 15/08
21-23-52-31	3	OCT 15/08	21-23-52-35B	0C	FEB 15/08
21-23-52-31	4	OCT 15/08	21-23-52-35B	0D	FEB 15/08
21-23-52-31	5	OCT 15/08	21-23-52-35B	0E	FEB 15/09
21-23-52-33	0	OCT 10/06	*21-23-52-35B	1	JUN 15/09
21-23-52-33	0A	OCT 15/08	*21-23-52-35B	2	JUN 15/09
21-23-52-33	0B	OCT 10/06	*21-23-52-35B	3	JUN 15/09
21-23-52-33	0C	OCT 10/06	21-23-52-46	0	OCT 10/06
21-23-52-33	0D	OCT 10/06	21-23-52-46	1	OCT 15/08
21-23-52-33	0E	OCT 15/08	21-23-52-46B	0	OCT 10/07
21-23-52-33	0F	OCT 10/06	21-23-52-46B	1	FEB 15/09
21-23-52-33	0G	OCT 10/06	21-23-52-46B	2	FEB 15/09
21-23-52-33	0H	OCT 10/06	21-23-52-46G	0	JUN 15/08
21-23-52-33	0I	OCT 10/06	21-23-52-46G	1	FEB 15/09
21-23-52-33	0J	OCT 10/06	21-23-52-46G	2	FEB 15/09
21-23-52-33	0K	OCT 10/06	21-23-52-48	0	OCT 10/06
21-23-52-33	0L	OCT 10/06	*21-23-52-48	1	JUN 15/09
21-23-52-33	1	JUN 10/07	21-23-52-48A	0	OCT 10/07
21-23-52-33	2	FEB 15/09	*21-23-52-48A	1	JUN 15/09
21-23-52-33	3	OCT 15/08	*21-23-52-48A	2	JUN 15/09
21-23-52-33	4	OCT 15/08	21-23-52-48E	0	JUN 15/08
21-23-52-33	5	FEB 10/07	21-23-52-48E	0A	JUN 15/08
21-23-52-34A	0	OCT 10/06	21-23-52-48E	1	FEB 15/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 9


BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-23-52-48E	2	FEB 15/09	21-23-54-89D	0	FEB 10/07
21-23-52-61	0	OCT 10/07	*21-23-54-89D	1	JUN 15/09
21-23-52-61	0A	OCT 10/07	21-23-54-89D	2	OCT 15/08
21-23-52-61	0B	OCT 10/07	21-23-54-91	0	FEB 10/07
21-23-52-61	0C	OCT 10/07	21-23-54-91	1	OCT 10/07
21-23-52-61	1	OCT 15/08	21-23-54-91	2	JUN 10/07
21-23-52-61	2	OCT 15/08	21-23-54-93	0	FEB 10/07
21-23-52-61	3	OCT 15/08	*21-23-54-93	1	JUN 15/09
21-23-52-65	0	OCT 10/07	21-23-54-93A	0	FEB 10/07
21-23-52-65	0A	FEB 15/08	21-23-54-93A	1	OCT 15/08
21-23-52-65	0B	OCT 10/07	21-24-00	1	OCT 10/06
21-23-52-65	0C	OCT 10/07	21-24-00- 1	0	OCT 15/08
21-23-52-65	0D	FEB 15/08	21-24-00- 1	1	OCT 15/08
21-23-52-65	0E	OCT 10/07	21-24-00- 1	2	OCT 15/08
21-23-52-65	0F	OCT 10/07	21-24-00- 1A	0	OCT 15/08
21-23-52-65	0G	OCT 10/07	21-24-00- 1A	1	OCT 15/08
21-23-52-65	0H	OCT 10/07	21-24-00- 1A	2	OCT 15/08
21-23-52-65	1	FEB 15/09	21-24-00- 1A	3	OCT 15/08
21-23-52-65	2	OCT 15/08	21-24-00- 4	0	OCT 10/06
21-23-52-65	3	OCT 15/08	21-24-00- 4	1	OCT 15/08
21-23-52-65	4	OCT 15/08	21-24-00- 4	2	OCT 15/08
21-23-52-66	0	OCT 10/07	21-24-00- 5	0	OCT 10/06
21-23-52-66	0A	FEB 15/08	21-24-00- 5	1	OCT 10/06
21-23-52-66	0B	OCT 10/07	21-24-00- 5	2	OCT 10/06
21-23-52-66	0C	OCT 10/07	21-24-00- 7	0	OCT 10/06
21-23-52-66	0D	FEB 15/08	21-24-00- 7	1	OCT 10/06
21-23-52-66	0E	OCT 10/07	21-24-00- 7A	0	OCT 15/08
21-23-52-66	0F	OCT 10/07	21-24-00- 7A	1	OCT 15/08
21-23-52-66	0G	OCT 10/07	21-24-00- 8	0	OCT 15/08
21-23-52-66	0H	OCT 10/07	21-24-00- 8	0A	OCT 15/08
21-23-52-66	1	FEB 15/09	21-24-00- 8	1	OCT 15/08
21-23-52-66	2	FEB 15/09	21-24-00- 9	0	OCT 10/06
21-23-52-66	3	FEB 15/09	21-24-00- 9	1	FEB 10/07
21-23-54- 4	0	OCT 10/06	21-24-00-16	0	OCT 10/06
*21-23-54- 4	1	JUN 15/09	21-24-00-16	0A	OCT 10/06
21-23-54-12	0	FEB 10/07	21-24-00-16	1	FEB 15/08
21-23-54-12	1	OCT 15/08	21-24-00-17	0	OCT 10/06
21-23-54-13A	0	FEB 10/07	21-24-00-17	0A	OCT 10/06
21-23-54-13A	1	OCT 15/08	21-24-00-17	1	OCT 10/06
21-23-54-30	0	FEB 10/07	21-24-00-28B	0	FEB 10/07
21-23-54-30	1	OCT 15/08	21-24-00-28B	1	OCT 15/08
21-23-54-30	2	OCT 15/08	21-24-00-28B	2	OCT 15/08
21-23-54-32	0	FEB 10/07	21-24-00-28B	3	OCT 15/08
21-23-54-32	1	OCT 15/08	21-24-00-28C	0	FEB 10/07
21-23-54-32	2	OCT 15/08	21-24-00-28C	1	OCT 15/08
21-23-54-77A	0	FEB 10/07	21-24-00-28C	2	OCT 15/08
21-23-54-77A	1	JUN 10/07	21-24-00-28C	3	OCT 15/08
21-23-54-77A	2	FEB 10/07	21-24-00-52	0	JUN 10/07
21-23-54-89B	0	OCT 15/08	21-24-00-52	1	JUN 10/07
21-23-54-89B	1	OCT 15/08	21-24-00-52	2	JUN 10/07
21-23-54-89B	2	OCT 15/08	21-24-00-52	3	JUN 10/07

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 10


BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-24-00-52	4	JUN 10/07	21-24-51-55A	2	FEB 15/09
21-24-00-52A	0	JUN 10/07	21-24-51-55C	0	FEB 10/07
21-24-00-52A	1	JUN 10/07	21-24-51-55C	1	FEB 15/09
21-24-00-52A	2	JUN 10/07	21-24-51-55D	0	FEB 10/07
21-24-00-52A	3	JUN 10/07	21-24-51-55D	0A	FEB 10/07
21-24-00-63D	0	OCT 15/08	21-24-51-55D	0B	FEB 10/07
21-24-00-63D	1	OCT 15/08	21-24-51-55D	0C	FEB 10/07
21-24-00-63E	0	OCT 15/08	21-24-51-55D	1	FEB 15/09
21-24-00-63E	1	OCT 15/08	21-24-51-55D	2	FEB 15/09
21-24-51- 4X	0	OCT 10/06	21-24-51-55D	3	FEB 15/09
21-24-51- 4X	1	OCT 10/06	21-24-51-57N	0	OCT 10/06
21-24-51- 5A	0	OCT 10/06	21-24-51-57N	0A	OCT 10/06
21-24-51- 5A	1	OCT 10/06	21-24-51-57N	0B	OCT 10/06
21-24-51-19	0	OCT 15/08	21-24-51-57N	1	FEB 15/09
21-24-51-19	0A	OCT 15/08	21-24-51-57N	2	FEB 15/09
21-24-51-19	1	OCT 15/08	21-24-51-57N	3	FEB 15/09
21-24-51-35C	0	JUN 10/07	21-24-51-57N	4	FEB 15/09
21-24-51-35C	0A	JUN 10/07	21-24-51-57N	5	FEB 15/09
*21-24-51-35C	1	JUN 15/09	21-24-51-57P	0	OCT 10/06
21-24-51-40C	0	JUN 10/07	21-24-51-57P	0A	OCT 10/06
21-24-51-40C	0A	JUN 10/07	21-24-51-57P	0B	JUN 10/07
21-24-51-40C	0B	JUN 10/07	21-24-51-57P	1	FEB 15/09
21-24-51-40C	1	FEB 15/09	21-24-51-57P	2	FEB 15/09
21-24-51-40C	2	FEB 15/09	21-24-51-57P	3	FEB 15/09
21-24-51-40C	3	FEB 15/09	21-24-51-57P	4	FEB 15/09
21-24-51-43	0	OCT 10/06	21-24-51-57Q	0	OCT 10/06
21-24-51-43	0A	OCT 10/06	21-24-51-57Q	0A	OCT 10/06
21-24-51-43	0B	OCT 10/06	21-24-51-57Q	0B	OCT 10/06
21-24-51-43	0C	OCT 10/06	21-24-51-57Q	0C	OCT 10/06
21-24-51-43	0D	OCT 10/06	21-24-51-57Q	1	FEB 15/09
21-24-51-43	1	JUN 10/07	21-24-51-57Q	2	FEB 15/09
21-24-51-45A	0	FEB 10/07	21-24-51-57Q	3	FEB 15/09
21-24-51-45A	0A	FEB 10/07	21-24-51-57Q	4	FEB 15/09
21-24-51-45A	0B	FEB 10/07	21-24-51-89A	0	FEB 10/07
21-24-51-45A	1	FEB 15/09	*21-24-51-89A	1	JUN 15/09
21-24-51-45A	2	FEB 15/09	21-24-51-98A	0	FEB 10/07
21-24-51-45A	3	FEB 15/09	21-24-51-98A	0A	OCT 15/08
21-24-51-45A	4	FEB 15/09	21-24-51-98A	0B	FEB 10/07
21-24-51-46N	0	OCT 10/06	21-24-51-98A	0C	FEB 10/07
21-24-51-46N	1	FEB 15/09	21-24-51-98A	1	FEB 15/09
21-24-51-46N	2	FEB 15/09	21-24-51-98A	2	FEB 15/09
21-24-51-46N	3	FEB 15/09	21-24-51-98A	3	FEB 15/09
21-24-51-46P	0	OCT 10/06	21-24-52-50Q	0	OCT 15/08
21-24-51-46P	0A	OCT 10/06	21-24-52-50Q	1	OCT 15/08
*21-24-51-46P	1	JUN 15/09	21-24-52-50R	0	OCT 15/08
21-24-51-46P	2	FEB 15/09	21-24-52-50R	1	OCT 15/08
21-24-51-46Q	0	OCT 10/06	21-24-52-51	0	FEB 10/07
21-24-51-46Q	1	FEB 15/09	21-24-52-51	1	OCT 15/08
21-24-51-46Q	2	FEB 15/09	21-24-52-51	2	OCT 15/08
21-24-51-55A	0	FEB 10/07	21-24-52-51A	0	FEB 10/07
21-24-51-55A	1	FEB 15/09	21-24-52-51A	1	OCT 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 11


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-24-52-51A	2	OCT 15/08
21-24-52-51N	0	FEB 10/07
21-24-52-51N	1	FEB 15/09
21-24-52-51P	0	FEB 10/07
21-24-52-51P	1	FEB 15/09
21-25-00	1	OCT 10/06
21-25-00- 2	0	FEB 15/09
21-25-00- 2	1	OCT 15/08
21-25-00- 2	2	OCT 15/08
21-25-00- 2	3	FEB 15/09
21-25-00- 3	0	JUN 15/08
21-25-00- 3	1	OCT 10/06
21-25-00- 3	2	OCT 10/06
21-25-00- 4	0	OCT 10/06
21-25-00- 4	1	FEB 15/09
21-25-00- 4	2	FEB 15/09
21-25-01- 1	0	OCT 10/06
21-25-01- 1	0A	OCT 10/06
21-25-01- 1	0B	OCT 10/06
21-25-01- 1	0C	OCT 10/06
21-25-01- 1	0D	OCT 10/06
21-25-01- 1	0E	OCT 10/06
21-25-01- 1	0F	OCT 10/06
21-25-01- 1	0G	OCT 10/06
21-25-01- 1	0H	OCT 10/06
21-25-01- 1	1	FEB 10/07
21-25-01- 1	2	FEB 15/09
21-25-01- 1	3	FEB 15/08
21-25-01- 1	4	FEB 15/08
21-25-01- 1	5	JUN 15/08
21-25-01- 1	6	JUN 15/08
21-25-01- 1	7	FEB 10/07
21-25-01- 1	8	JUN 15/08
21-25-01- 4	0	FEB 10/07
21-25-01- 4	0A	FEB 10/07
21-25-01- 4	0B	FEB 10/07
21-25-01- 4	0C	FEB 10/07
21-25-01- 4	1	OCT 15/08
21-25-01- 4	2	OCT 15/08
21-25-01- 4	3	OCT 15/08
21-25-01- 4	4	FEB 15/09
21-25-01- 4	5	FEB 15/09
21-25-01- 4	6	OCT 15/08
21-25-01- 4	7	OCT 15/08
21-25-02- 1	0	FEB 10/07
21-25-02- 1	1	OCT 15/08
21-25-02- 1	2	FEB 15/09
21-25-02- 1	3	FEB 15/09
21-25-02- 2	0	OCT 10/06
21-25-02- 2	1	OCT 15/08
21-25-02- 2A	0	FEB 10/07

CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-25-02- 2A	1	FEB 15/09
*21-25-02- 2A	2	JUN 15/09
*21-25-02- 2A	3	JUN 15/09
21-25-02- 6	0	FEB 10/07
21-25-02- 6	0A	FEB 15/09
21-25-02- 6	1	OCT 15/08
21-25-02- 6	2	FEB 15/09
21-25-02- 6	3	FEB 15/09
*21-25-02- 6	4	JUN 15/09
21-25-02- 6	5	OCT 15/08
21-25-02- 6	6	FEB 15/09
21-25-02- 8	0	FEB 15/09
21-25-02- 8	0A	FEB 15/09
21-25-02- 8	0B	OCT 10/06
21-25-02- 8	1	JUN 15/08
21-25-02- 8	2	FEB 15/09
21-25-02- 8	3	JUN 10/07
21-25-02- 8	4	JUN 15/08
21-25-02- 8	5	JUN 15/08
21-25-02- 8	6	FEB 10/07
21-25-02- 8	7	FEB 15/09
21-25-02- 9	0	OCT 10/06
*21-25-02- 9	1	JUN 15/09
*21-25-02- 9	2	JUN 15/09
*21-25-02- 9	3	JUN 15/09
21-25-02-25	0	OCT 10/06
21-25-02-25	1	OCT 10/06
21-25-03- 1	0	OCT 10/06
21-25-03- 1	1	FEB 10/07
21-25-03- 1	2	FEB 10/07
21-25-03- 6	0	FEB 10/07
21-25-03- 6	1	OCT 15/08
21-25-03- 6	2	OCT 15/08
21-26-00	1	OCT 10/06
21-26-01- 1	0	OCT 10/06
21-26-01- 1	1	OCT 15/08
21-26-01- 1B	0	FEB 10/07
21-26-01- 1B	1	OCT 15/08
21-26-50- 1	0	OCT 10/06
21-26-50- 1	0A	OCT 10/06
21-26-50- 1	1	OCT 15/08
21-26-51- 1	0	JUN 15/08
*21-26-51- 1	1	JUN 15/09
21-26-51- 2	0	OCT 10/06
21-26-51- 2	0A	OCT 10/06
21-26-51- 2	0B	OCT 10/06
21-26-51- 2	1	FEB 15/09
21-26-51- 2	2	JUN 10/07
21-26-51- 2	3	FEB 15/09
21-26-51- 9	0	OCT 10/06
21-26-51- 9	0A	JUN 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
 JUN 15/09

21 - LIST OF EFFECTIVE PAGES
 PAGE 12



BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-26-51- 9	1	FEB 15/09	21-27-04- 1	0	OCT 10/06
*21-26-51- 9	2	JUN 15/09	21-27-04- 1	1	OCT 15/08
*21-26-51- 9	3	JUN 15/09	21-27-04- 1A	0	FEB 10/07
21-26-51- 9B	0	FEB 10/07	21-27-04- 1A	1	OCT 15/08
21-26-51- 9B	0A	FEB 10/07	*21-27-04- 3	0	JUN 15/09
21-26-51- 9B	1	FEB 15/09	*21-27-04- 3	0A	JUN 15/09
21-26-51- 9B	2	FEB 15/09	21-27-04- 3	1	OCT 15/08
21-26-51- 9B	3	FEB 15/09	21-27-04- 3	2	FEB 15/09
21-26-51-10	0	OCT 10/06	*21-27-04- 3	3	JUN 15/09
21-26-51-10	1	OCT 15/08	21-27-04- 4	0	OCT 10/06
21-26-51-10A	0	FEB 10/07	21-27-04- 4	0A	OCT 10/06
21-26-51-10A	1	OCT 15/08	21-27-04- 4	1	OCT 15/08
21-26-51-13	0	OCT 10/06	21-27-04- 5	0	OCT 10/06
21-26-51-13	1	OCT 15/08	21-27-04- 5	0A	OCT 10/06
21-26-51-13	2	OCT 15/08	21-27-04- 5	1	OCT 15/08
21-26-51-13B	0	FEB 10/07	21-27-05- 1	0	FEB 15/09
21-26-51-13B	1	OCT 15/08	21-27-05- 1	1	OCT 15/08
21-26-51-13B	2	OCT 15/08	21-27-05- 1	2	FEB 15/09
21-26-51-16	0	OCT 10/06	21-27-51- 1	0	OCT 10/06
21-26-51-16	0A	OCT 10/06	21-27-51- 1	0A	OCT 10/06
21-26-51-16	1	OCT 15/08	21-27-51- 1	1	OCT 15/08
21-26-51-16	2	OCT 15/08	21-27-51- 1	2	FEB 15/09
21-26-51-16	3	OCT 15/08	21-27-51- 1	3	OCT 10/06
21-26-51-16	4	OCT 15/08	21-27-51- 2	0	OCT 10/06
21-26-51-16A	0	FEB 10/07	21-27-51- 2	0A	OCT 10/06
21-26-51-16A	1	OCT 15/08	21-27-51- 2	0B	JUN 10/07
21-26-51-16A	2	OCT 15/08	21-27-51- 2	1	OCT 15/08
21-27-00	1	OCT 10/06	21-27-51- 2	2	FEB 15/09
21-27-00- 1	0	OCT 10/06	21-27-51- 2	3	OCT 15/08
21-27-00- 1	1	OCT 15/08	21-27-51- 2A	0	FEB 10/07
21-27-00- 1	2	OCT 15/08	21-27-51- 2A	0A	FEB 10/07
21-27-00- 3	0	OCT 10/06	21-27-51- 2A	1	OCT 15/08
21-27-00- 3	1	OCT 15/08	21-27-51- 2A	2	FEB 15/09
21-27-00- 4	0	JUN 15/08	21-27-51- 3	0	FEB 10/07
21-27-00- 4	1	OCT 10/06	21-27-51- 3	1	OCT 15/08
21-27-00- 4	2	OCT 10/06	21-27-51- 3A	0	JUN 15/08
21-27-00- 5	0	OCT 10/06	21-27-51- 3A	1	FEB 15/09
21-27-00- 5	0A	OCT 10/06	21-27-51- 3A	2	OCT 15/08
21-27-00- 5	1	OCT 15/08	21-27-51- 4	0	JUN 10/07
21-27-00- 5	2	FEB 15/09	21-27-51- 4	0A	OCT 10/06
21-27-00- 5	3	FEB 15/09	21-27-51- 4	0B	OCT 10/07
21-27-00- 5	4	OCT 15/08	21-27-51- 4	0C	OCT 10/07
21-27-00- 5A	0	JUN 15/08	21-27-51- 4	0D	OCT 10/07
21-27-00- 5A	0A	OCT 10/06	21-27-51- 4	1	OCT 15/08
21-27-00- 5A	1	OCT 15/08	21-27-51- 4	2	OCT 15/08
21-27-00- 5A	2	OCT 15/08	21-27-51- 4	3	OCT 15/08
21-27-00- 5A	3	OCT 15/08	21-27-51- 4	4	OCT 15/08
21-27-00-12	0	OCT 10/06	21-27-51- 5	0	OCT 10/06
21-27-00-12	1	OCT 10/06	21-27-51- 5	0A	OCT 10/06
21-27-00-14	0	OCT 10/06	21-27-51- 5	0B	OCT 10/06
21-27-00-14	1	OCT 15/08	21-27-51- 5	0C	OCT 10/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 13


BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-27-51- 5	0D	OCT 10/06	21-27-51- 9	12	OCT 15/08
21-27-51- 5	1	OCT 15/08	21-27-51-10	0	FEB 15/08
21-27-51- 5	2	OCT 15/08	*21-27-51-10	1	JUN 15/09
21-27-51- 5	3	FEB 15/09	21-27-51-16	0	OCT 15/08
21-27-51- 5	4	FEB 15/09	21-27-51-16	0A	OCT 15/08
21-27-51- 5	5	OCT 15/08	21-27-51-16	0B	OCT 15/08
21-27-51- 5	6	OCT 15/08	21-27-51-16	0C	OCT 15/08
21-27-51- 5	7	OCT 15/08	21-27-51-16	0D	OCT 15/08
21-27-51- 7	0	FEB 15/09	21-27-51-16	0E	OCT 15/08
21-27-51- 7	0A	OCT 10/06	21-27-51-16	0F	OCT 15/08
21-27-51- 7	0B	FEB 15/09	21-27-51-16	1	FEB 15/09
21-27-51- 7	0C	OCT 10/06	21-27-51-16	2	OCT 15/08
21-27-51- 7	0D	OCT 10/06	21-27-51-16	3	OCT 15/08
21-27-51- 7	0E	OCT 10/06	21-27-51-16	4	OCT 15/08
21-27-51- 7	1	FEB 15/09	21-27-51-16	5	OCT 15/08
21-27-51- 7	2	FEB 15/09	21-27-51-19	0	OCT 10/07
21-27-51- 7	3	FEB 15/09	21-27-51-19	0A	OCT 10/07
21-27-51- 7	4	FEB 15/09	21-27-51-19	0B	OCT 10/07
*21-27-51- 7	5	JUN 15/09	21-27-51-19	1	OCT 15/08
*21-27-51- 7	6	JUN 15/09	21-27-51-21	0	OCT 10/06
21-27-51- 7B	0	FEB 15/09	21-27-51-21	0A	OCT 10/06
21-27-51- 7B	0A	OCT 10/06	21-27-51-21	0B	OCT 10/06
21-27-51- 7B	0B	FEB 15/09	21-27-51-21	0C	OCT 10/06
21-27-51- 7B	0C	OCT 10/06	21-27-51-21	0D	OCT 10/06
21-27-51- 7B	0D	OCT 10/06	21-27-51-21	0E	OCT 10/06
21-27-51- 7B	0E	OCT 10/06	21-27-51-21	1	FEB 15/09
21-27-51- 7B	1	FEB 15/09	21-27-51-21	2	OCT 10/06
21-27-51- 7B	2	FEB 15/09	21-27-51-21	3	OCT 10/06
21-27-51- 7B	3	FEB 15/09	21-27-51-21	4	OCT 10/06
21-27-51- 7B	4	FEB 15/09	21-27-51-22	0	OCT 10/06
21-27-51- 7B	5	FEB 15/09	21-27-51-22	0A	OCT 10/06
21-27-51- 7B	6	FEB 15/09	21-27-51-22	0B	OCT 10/06
*21-27-51- 9	0	JUN 15/09	21-27-51-22	0C	OCT 10/06
21-27-51- 9	0A	OCT 10/06	21-27-51-22	0D	OCT 10/06
21-27-51- 9	0B	OCT 10/06	21-27-51-22	0E	OCT 10/06
21-27-51- 9	0C	OCT 10/06	21-27-51-22	0F	OCT 10/06
21-27-51- 9	0D	OCT 10/06	21-27-51-22	0G	OCT 10/06
21-27-51- 9	0E	OCT 10/06	21-27-51-22	1	FEB 15/09
21-27-51- 9	0F	OCT 10/06	21-27-51-22	2	OCT 10/06
*21-27-51- 9	0G	JUN 15/09	21-27-51-22	3	OCT 10/06
21-27-51- 9	1	OCT 15/08	21-27-51-22	4	OCT 10/06
21-27-51- 9	2	OCT 15/08	21-27-51-28	0	OCT 10/06
21-27-51- 9	3	OCT 15/08	21-27-51-28	1	OCT 10/06
21-27-51- 9	4	OCT 15/08	21-27-51-33	0	OCT 10/06
21-27-51- 9	5	OCT 15/08	21-27-51-33	0A	OCT 10/06
21-27-51- 9	6	FEB 15/09	21-27-51-33	1	OCT 15/08
21-27-51- 9	7	OCT 15/08	21-27-51-33A	0	FEB 10/07
21-27-51- 9	8	OCT 15/08	21-27-51-33A	1	OCT 15/08
21-27-51- 9	9	OCT 15/08	21-27-51-41	0	OCT 10/06
21-27-51- 9	10	OCT 15/08	21-27-51-41	1	OCT 15/08
21-27-51- 9	11	OCT 15/08	21-27-51-41A	0	FEB 10/07

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 14

 **BOEING**
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-27-51-41A	1	FEB 15/09	21-27-51-50	7	JUN 10/07
*21-27-51-41B	0	JUN 15/09	21-27-51-50A	0	FEB 10/07
*21-27-51-41B	1	JUN 15/09	21-27-51-50A	0A	FEB 15/09
21-27-51-42	0	OCT 10/06	21-27-51-50A	0B	FEB 10/07
21-27-51-42	1	OCT 15/08	21-27-51-50A	0C	FEB 10/07
21-27-51-42A	0	FEB 10/07	21-27-51-50A	0D	FEB 10/07
21-27-51-42A	1	FEB 15/09	21-27-51-50A	0E	FEB 10/07
21-27-51-45	0	OCT 15/08	21-27-51-50A	0F	FEB 10/07
21-27-51-45	1	OCT 15/08	21-27-51-50A	1	FEB 15/09
21-27-51-46	0	OCT 10/06	21-27-51-50A	2	OCT 15/08
21-27-51-46	0A	OCT 10/06	21-27-51-50A	3	FEB 15/09
21-27-51-46	1	OCT 15/08	21-27-51-50A	4	OCT 15/08
21-27-51-46	2	OCT 10/06	21-27-51-50A	5	FEB 15/09
21-27-51-47	0	JUN 10/07	21-27-51-50A	6	OCT 15/08
21-27-51-47	0A	JUN 10/07	21-27-51-50A	7	FEB 15/09
21-27-51-47	0B	JUN 10/07	21-27-51-51	0	OCT 10/06
21-27-51-47	0C	OCT 10/07	21-27-51-51	1	OCT 15/08
21-27-51-47	0D	OCT 10/07	21-27-51-51	2	OCT 15/08
21-27-51-47	0E	OCT 10/07	21-27-51-71	0	FEB 15/09
21-27-51-47	1	JUN 15/08	21-27-51-71	1	OCT 15/08
21-27-51-47	2	OCT 15/08	21-27-51-71	2	OCT 15/08
21-27-51-47	3	OCT 15/08	21-27-51-71	3	FEB 15/09
21-27-51-47	4	OCT 15/08	21-27-51-71	4	FEB 15/09
21-27-51-47A	0	JUN 10/07	21-27-52- 1	0	OCT 10/06
21-27-51-47A	0A	JUN 10/07	21-27-52- 1	1	OCT 15/08
21-27-51-47A	0B	JUN 10/07	21-27-52- 1	2	FEB 15/09
21-27-51-47A	0C	JUN 10/07	21-27-52- 1	3	OCT 15/08
21-27-51-47A	0D	JUN 10/07	21-30-00	1	OCT 10/06
21-27-51-47A	1	OCT 15/08	21-30-00- 1A	0	OCT 10/06
21-27-51-47A	2	OCT 15/08	21-30-00- 1A	1	OCT 15/08
21-27-51-47A	3	OCT 15/08	21-31-00	1	OCT 10/06
21-27-51-47A	4	OCT 15/08	21-31-00- 1	0	OCT 10/06
21-27-51-47A	5	OCT 15/08	21-31-00- 1	1	OCT 15/08
21-27-51-48	0	OCT 10/06	21-31-00- 1	2	OCT 15/08
21-27-51-48	1	FEB 10/07	21-31-00- 1	3	FEB 15/09
21-27-51-48A	0	FEB 10/07	21-31-00- 2	0	FEB 15/09
21-27-51-48A	1	OCT 15/08	21-31-00- 2	1	FEB 15/09
21-27-51-48A	2	OCT 15/08	*21-31-00- 2	2	JUN 15/09
21-27-51-50	0	OCT 10/06	*21-31-00- 2	3	JUN 15/09
21-27-51-50	0A	OCT 10/06	*21-31-00- 2	4	JUN 15/09
21-27-51-50	0B	OCT 10/06	21-31-00-25	0	OCT 10/06
21-27-51-50	0C	OCT 10/06	21-31-00-25	1	OCT 10/06
21-27-51-50	0D	OCT 10/06	21-31-00-25	2	FEB 15/09
21-27-51-50	0E	OCT 10/06	21-31-00-25	3	OCT 10/06
21-27-51-50	0F	OCT 10/06	21-31-01- 2	0	FEB 10/07
21-27-51-50	1	JUN 10/07	21-31-01- 2	1	OCT 15/08
21-27-51-50	2	OCT 15/08	21-31-01- 2	2	OCT 15/08
21-27-51-50	3	FEB 15/09	21-31-01- 2	3	OCT 15/08
21-27-51-50	4	FEB 15/09	21-31-01- 2	4	OCT 15/08
21-27-51-50	5	JUN 10/07	21-31-01- 2	5	FEB 15/09
21-27-51-50	6	JUN 10/07	21-31-01- 2A	0	OCT 10/07

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 15


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-31-01- 2A	1	OCT 15/08	*21-31-02- 8	6	JUN 15/09
21-31-01- 2A	2	OCT 15/08	21-31-03- 1	0	FEB 15/09
21-31-01- 2A	3	OCT 15/08	21-31-03- 1	0A	OCT 10/06
21-31-01- 2A	4	OCT 15/08	21-31-03- 1	0B	OCT 10/06
21-31-01- 2A	5	FEB 15/09	21-31-03- 1	0C	OCT 10/06
21-31-01- 2B	0	FEB 15/09	21-31-03- 1	1	FEB 15/09
21-31-01- 2B	1	OCT 15/08	*21-31-03- 1	2	JUN 15/09
21-31-01- 2B	2	OCT 15/08	21-31-03- 1	3	FEB 15/09
21-31-01- 2B	3	OCT 15/08	21-31-03- 1	4	FEB 15/09
21-31-01- 2B	4	FEB 15/09	21-31-03- 1	5	FEB 15/09
21-31-01- 3	0	FEB 15/09	*21-31-03- 1	6	JUN 15/09
21-31-01- 3	1	OCT 15/08	*21-31-03- 1	7	JUN 15/09
21-31-01- 3	2	OCT 15/08	*21-31-03- 1	8	JUN 15/09
21-31-01- 3	3	OCT 15/08	21-32-00	1	OCT 10/06
21-31-01- 3	4	OCT 15/08	21-32-01- 1	0	OCT 10/06
21-31-01- 3	5	FEB 15/09	*21-32-01- 1	1	JUN 15/09
21-31-02- 1	0	OCT 10/06	*21-32-01- 1	2	JUN 15/09
21-31-02- 1	1	OCT 15/08	21-32-51- 2	0	JUN 10/07
21-31-02- 1	2	OCT 15/08	21-32-51- 2	1	OCT 15/08
21-31-02- 1	3	OCT 15/08	21-33-00	1	OCT 10/06
21-31-02- 1	4	OCT 15/08	*21-33-01- 1	0	JUN 15/09
21-31-02- 1	5	OCT 15/08	*21-33-01- 1	0A	JUN 15/09
21-31-02- 2	0	OCT 10/06	21-33-01- 1	1	OCT 15/08
21-31-02- 2	1	OCT 15/08	21-33-01- 1	2	OCT 15/08
*21-31-02- 2	2	JUN 15/09	*21-33-01- 1	3	JUN 15/09
*21-31-02- 2	3	JUN 15/09	*21-33-01- 1B	0	JUN 15/09
*21-31-02- 2	4	JUN 15/09	21-33-01- 1B	1	JUN 15/08
*21-31-02- 2	5	JUN 15/09	21-33-01- 1B	2	JUN 15/08
*21-31-02- 2	6	JUN 15/09	*21-33-01- 1B	3	JUN 15/09
*21-31-02- 2	7	JUN 15/09	*21-33-01- 1B	4	JUN 15/09
21-31-02- 3	0	OCT 10/07	21-33-01- 2	0	FEB 15/09
21-31-02- 3	1	OCT 15/08	21-33-01- 2	0A	OCT 10/06
21-31-02- 3	2	OCT 15/08	21-33-01- 2	1	OCT 15/08
21-31-02- 3	3	OCT 15/08	*21-33-01- 2	2	JUN 15/09
21-31-02- 3	4	OCT 15/08	21-33-01- 2	3	OCT 15/08
21-31-02- 3	5	FEB 15/09	21-33-01- 2	4	OCT 15/08
21-31-02- 5	0	FEB 15/09	21-33-01- 2	5	OCT 15/08
21-31-02- 5	1	OCT 15/08	21-33-01- 2	6	FEB 15/09
*21-31-02- 5	2	JUN 15/09	*21-33-01- 3	0	JUN 15/09
*21-31-02- 5	3	JUN 15/09	*21-33-01- 3	0A	JUN 15/09
*21-31-02- 5	4	JUN 15/09	21-33-01- 3	1	JUN 15/08
*21-31-02- 5	5	JUN 15/09	21-33-01- 3	2	JUN 10/07
*21-31-02- 5	6	JUN 15/09	21-33-01- 3	3	JUN 10/07
*21-31-02- 5	7	JUN 15/09	*21-33-01- 3	4	JUN 15/09
*21-31-02- 5	8	JUN 15/09	*21-33-02- 1	0	JUN 15/09
*21-31-02- 8	0	JUN 15/09	21-33-02- 1	1	OCT 15/08
21-31-02- 8	1	OCT 15/08	*21-33-02- 1	2	JUN 15/09
*21-31-02- 8	2	JUN 15/09	21-33-02- 2	0	FEB 15/09
*21-31-02- 8	3	JUN 15/09	21-33-02- 2	1	OCT 15/08
*21-31-02- 8	4	JUN 15/09	*21-33-02- 2	2	JUN 15/09
*21-31-02- 8	5	JUN 15/09	21-33-02- 2	3	FEB 15/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 16


BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-33-02- 3	0	OCT 15/08
21-33-02- 3	1	FEB 15/09
*21-33-02- 3	2	JUN 15/09
21-33-02- 8	0	OCT 15/08
21-33-02- 8	0A	OCT 15/08
21-33-02- 8	0B	OCT 15/08
21-33-02- 8	0C	OCT 15/08
21-33-02- 8	0D	OCT 15/08
21-33-02- 8	1	FEB 15/09
21-33-02- 8	2	FEB 15/09
21-33-02- 8	3	FEB 15/09
21-33-02- 8	4	FEB 15/09
21-33-02- 8	5	FEB 15/09
21-33-02- 8	6	FEB 15/09
21-33-04- 1	0	OCT 10/06
21-33-04- 1	1	OCT 15/08
21-33-04- 1A	0	FEB 10/07
21-33-04- 1A	1	FEB 15/09
21-33-04- 3	0	FEB 15/09
21-33-04- 3	1	FEB 15/09
21-40-00	1	OCT 10/06
21-40-00- 2	0	OCT 10/06
21-40-00- 2	1	OCT 15/08
21-40-00- 2B	0	OCT 15/08
21-40-00- 2B	1	OCT 15/08
21-40-00- 2C	0	OCT 10/06
21-40-00- 2C	1	OCT 15/08
21-43-00	1	OCT 10/06
21-43-51- 1	0	JUN 15/08
21-43-51- 1	1	OCT 15/08
21-43-51- 1	2	OCT 15/08
21-43-51- 1	3	OCT 15/08
21-43-51- 1	4	FEB 15/09
21-43-51- 1	5	FEB 15/09
21-43-51- 1	6	FEB 15/09
21-43-51- 2	0	JUN 15/08
21-43-51- 2	1	JUN 15/08
21-43-51- 2	2	JUN 15/08
21-43-51- 2	3	JUN 15/08
21-44-00	1	OCT 10/06
21-44-51- 1	0	OCT 10/06
21-44-51- 1	1	OCT 15/08
21-44-51- 1	2	OCT 15/08
21-45-00	1	OCT 10/06
21-45-00- 1	0	OCT 10/06
21-45-00- 1	1	FEB 15/09
21-45-00- 1	2	FEB 15/09
21-45-01- 1	0	OCT 10/06
21-45-01- 1	0A	OCT 10/06
21-45-01- 1	0B	OCT 10/06
21-45-01- 1	0C	OCT 10/06

CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-45-01- 1	1	OCT 15/08
21-45-01- 1	2	OCT 15/08
21-45-01- 1	3	OCT 15/08
21-45-01- 1	4	OCT 15/08
21-45-01- 1A	0	FEB 10/07
21-45-01- 1A	0A	FEB 10/07
21-45-01- 1A	0B	FEB 10/07
21-45-01- 1A	0C	FEB 10/07
21-45-01- 1A	1	FEB 15/09
21-45-01- 1A	2	FEB 15/09
21-45-01- 1A	3	FEB 15/09
21-45-01- 1A	4	FEB 15/09
21-45-01- 1A	5	FEB 15/09
*21-45-01- 1B	0	JUN 15/09
*21-45-01- 1B	0A	JUN 15/09
21-45-01- 1B	0B	FEB 15/09
21-45-01- 1B	0C	FEB 15/09
21-45-01- 1B	1	FEB 15/09
21-45-01- 1B	2	FEB 15/09
21-45-01- 1B	3	FEB 15/09
*21-45-01- 2	0	JUN 15/09
21-45-01- 2	1	FEB 15/09
21-45-01- 2	2	OCT 15/08
21-45-01- 2	3	FEB 15/09
21-45-01- 2	4	FEB 15/09
21-45-01- 2	5	FEB 15/09
21-45-01- 2A	0	FEB 10/07
21-45-01- 2A	1	OCT 15/08
21-45-01- 2A	2	OCT 15/08
21-45-01- 2A	3	OCT 15/08
21-45-01- 2A	4	OCT 15/08
21-45-51-35C	0	JUN 10/07
*21-45-51-35C	1	JUN 15/09
21-45-51-46P	0	OCT 10/06
*21-45-51-46P	1	JUN 15/09
21-50-00	1	OCT 10/06
21-50-00- 1	0	OCT 10/06
21-50-00- 1	1	OCT 15/08
21-50-00- 1B	0	OCT 15/08
21-50-00- 1B	1	OCT 15/08
21-50-00- 1B	2	OCT 15/08
21-50-00- 1C	0	OCT 10/06
21-50-00- 1C	1	OCT 10/06
21-50-00- 1C	2	OCT 10/06
21-50-00- 1C	3	OCT 10/06
21-51-00	1	OCT 10/06
21-51-00- 1	0	OCT 10/06
21-51-00- 1	1	OCT 15/08
21-51-00- 1	2	OCT 15/08
21-51-00- 1	3	OCT 15/08
21-51-00- 1	4	FEB 15/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 17



BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-51-00- 1	5	FEB 15/09	21-51-01- 6	6	FEB 15/09
21-51-00- 2	0	OCT 10/06	21-51-01- 6	7	FEB 15/09
21-51-00- 2	1	OCT 15/08	21-51-01- 6	8	FEB 15/09
21-51-01- 2	0	OCT 15/08	21-51-01-51	0	OCT 10/06
21-51-01- 2	0A	OCT 15/08	21-51-01-51	1	OCT 15/08
21-51-01- 2	0B	OCT 15/08	21-51-01-51	2	OCT 15/08
21-51-01- 2	0C	OCT 15/08	21-51-01-51	3	OCT 15/08
21-51-01- 2	0D	OCT 15/08	21-51-02- 1	0	OCT 10/06
21-51-01- 2	1	FEB 15/09	21-51-02- 1	0A	OCT 10/06
21-51-01- 2	2	OCT 15/08	21-51-02- 1	0B	OCT 10/06
21-51-01- 2	3	OCT 15/08	21-51-02- 1	0C	OCT 10/06
21-51-01- 2	4	OCT 15/08	21-51-02- 1	0D	OCT 10/06
21-51-01- 2	5	OCT 15/08	*21-51-02- 1	1	JUN 15/09
21-51-01- 2	6	OCT 15/08	21-51-02- 1	2	OCT 15/08
21-51-01- 3	0	OCT 15/08	21-51-02- 1	3	OCT 15/08
21-51-01- 3	0A	OCT 15/08	21-51-02- 1	4	OCT 15/08
21-51-01- 3	0B	OCT 15/08	21-51-02- 1	5	OCT 15/08
21-51-01- 3	0C	OCT 15/08	21-51-02- 1	6	OCT 15/08
21-51-01- 3	0D	OCT 15/08	21-51-02- 1	7	OCT 15/08
21-51-01- 3	1	FEB 15/09	21-51-02- 1	8	OCT 15/08
21-51-01- 3	2	OCT 15/08	21-51-02- 1	9	OCT 15/08
21-51-01- 3	3	OCT 15/08	21-51-02- 1	10	OCT 15/08
21-51-01- 3	4	OCT 15/08	21-51-02- 1	11	OCT 15/08
21-51-01- 3	5	OCT 15/08	21-51-02- 1	12	OCT 15/08
21-51-01- 3	6	OCT 15/08	21-51-02- 1	13	OCT 15/08
21-51-01- 4	0	OCT 10/06	21-51-02- 1	14	OCT 15/08
21-51-01- 4	0A	OCT 10/06	21-51-02- 1	15	OCT 15/08
21-51-01- 4	0B	OCT 10/06	21-51-02- 1	16	OCT 15/08
21-51-01- 4	0C	OCT 10/06	21-51-02- 1	17	OCT 15/08
21-51-01- 4	0D	OCT 10/06	21-51-02- 1	18	OCT 15/08
21-51-01- 4	1	FEB 15/09	21-51-02- 1	19	OCT 15/08
21-51-01- 4	2	JUN 15/08	21-51-02- 1	20	OCT 15/08
21-51-01- 4	3	OCT 15/08	21-51-02- 2	0	OCT 10/06
21-51-01- 4	4	OCT 15/08	21-51-02- 2	0A	OCT 10/06
21-51-01- 4	5	OCT 10/06	21-51-02- 2	0B	FEB 10/07
21-51-01- 5	0	OCT 10/06	21-51-02- 2	0C	FEB 10/07
21-51-01- 5	0A	OCT 10/06	*21-51-02- 2	1	JUN 15/09
21-51-01- 5	0B	OCT 10/06	*21-51-02- 2	2	JUN 15/09
21-51-01- 5	1	FEB 15/09	*21-51-02- 2	3	JUN 15/09
21-51-01- 5	2	JUN 15/08	*21-51-02- 2	4	JUN 15/09
21-51-01- 5	3	OCT 15/08	21-51-02- 2	5	OCT 15/08
21-51-01- 5	4	OCT 10/06	21-51-02- 2	6	OCT 15/08
21-51-01- 6	0	JUN 10/07	21-51-02- 2	7	OCT 15/08
21-51-01- 6	0A	JUN 10/07	21-51-02- 2	8	FEB 10/07
21-51-01- 6	0B	OCT 10/06	21-51-02- 2	9	FEB 10/07
21-51-01- 6	0C	OCT 10/06	21-51-02- 2	10	FEB 10/07
21-51-01- 6	1	FEB 15/09	21-51-02- 2	11	FEB 10/07
21-51-01- 6	2	OCT 15/08	21-51-02- 2	12	FEB 10/07
21-51-01- 6	3	OCT 15/08	21-51-02- 2	13	FEB 10/07
21-51-01- 6	4	OCT 15/08	21-51-02- 2	14	FEB 15/09
21-51-01- 6	5	FEB 15/09	21-51-02- 2	15	FEB 15/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 18


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-51-02- 2A	0	FEB 10/07	21-51-03- 5	4	FEB 15/09
21-51-02- 2A	0A	FEB 10/07	21-51-03- 5	5	JUN 15/08
21-51-02- 2A	0B	FEB 10/07	*21-51-03- 5	6	JUN 15/09
21-51-02- 2A	0C	FEB 10/07	*21-51-03- 5	7	JUN 15/09
21-51-02- 2A	1	FEB 15/09	21-51-03- 5	8	OCT 15/08
21-51-02- 2A	2	FEB 15/09	21-51-03- 5	9	OCT 15/08
21-51-02- 2A	3	FEB 15/09	21-51-03- 5	10	OCT 15/08
21-51-02- 2A	4	FEB 15/09	21-51-03- 5A	0	OCT 10/06
21-51-02- 2A	5	FEB 15/09	21-51-03- 5A	0A	OCT 10/06
21-51-02- 2A	6	FEB 15/09	21-51-03- 5A	0B	OCT 10/06
21-51-02- 2A	7	FEB 15/09	21-51-03- 5A	0C	OCT 10/06
21-51-02- 2A	8	FEB 15/09	21-51-03- 5A	0D	OCT 10/06
21-51-02- 2A	9	FEB 15/09	21-51-03- 5A	0E	OCT 10/06
21-51-02- 2A	10	FEB 15/09	21-51-03- 5A	0F	OCT 10/06
21-51-02- 2A	11	FEB 15/09	21-51-03- 5A	1	FEB 15/09
21-51-02- 2A	12	FEB 15/09	21-51-03- 5A	2	FEB 15/09
21-51-02- 2A	13	FEB 15/09	*21-51-03- 5A	3	JUN 15/09
21-51-02- 2A	14	FEB 15/09	*21-51-03- 5A	4	JUN 15/09
21-51-02- 2A	15	FEB 15/09	21-51-03- 5A	5	FEB 15/09
21-51-03- 1	0	FEB 10/07	21-51-03- 5A	6	FEB 15/09
21-51-03- 1	0A	FEB 10/07	21-51-03- 5A	7	FEB 15/09
21-51-03- 1	0B	FEB 10/07	21-51-03- 5A	8	FEB 15/09
21-51-03- 1	1	OCT 15/08	*21-51-03- 5A	9	JUN 15/09
21-51-03- 1	2	FEB 15/09	*21-51-03- 5A	10	JUN 15/09
21-51-03- 1	3	FEB 15/09	*21-51-03- 5A	11	JUN 15/09
21-51-03- 1	4	JUN 15/08	21-51-03- 5A	12	FEB 15/09
21-51-03- 1	5	OCT 15/08	21-51-03- 5A	13	FEB 15/09
21-51-03- 1	6	OCT 15/08	21-51-03- 6	0	OCT 10/06
21-51-03- 1A	0	JUN 15/08	*21-51-03- 6	0A	JUN 15/09
21-51-03- 1A	0A	OCT 10/06	*21-51-03- 6	0B	JUN 15/09
21-51-03- 1A	0B	OCT 10/06	*21-51-03- 6	0C	JUN 15/09
21-51-03- 1A	0C	OCT 10/06	*21-51-03- 6	0D	JUN 15/09
21-51-03- 1A	1	FEB 15/09	21-51-03- 6	1	FEB 15/09
21-51-03- 1A	2	FEB 15/09	21-51-03- 6	2	FEB 15/09
21-51-03- 1A	3	FEB 15/09	21-51-03- 6	3	FEB 15/09
21-51-03- 1A	4	FEB 15/09	*21-51-03- 6	4	JUN 15/09
21-51-03- 1A	5	FEB 15/09	*21-51-03- 6	5	JUN 15/09
21-51-03- 1A	6	FEB 15/09	*21-51-03- 6	6	JUN 15/09
21-51-03- 1A	7	FEB 15/09	*21-51-03- 6	7	JUN 15/09
21-51-03- 1A	8	OCT 15/08	*21-51-03- 6	8	JUN 15/09
21-51-03- 1A	9	OCT 15/08	*21-51-03- 6	9	JUN 15/09
21-51-03- 5	0	FEB 10/07	*21-51-03- 6A	0	JUN 15/09
21-51-03- 5	0A	FEB 10/07	21-51-03- 6A	1	FEB 15/09
21-51-03- 5	0B	FEB 10/07	21-51-03- 6A	2	FEB 15/09
21-51-03- 5	0C	FEB 10/07	*21-51-03- 6A	3	JUN 15/09
21-51-03- 5	0D	FEB 10/07	21-51-04- 1	0	OCT 10/06
21-51-03- 5	0E	FEB 10/07	21-51-04- 1	1	FEB 15/09
21-51-03- 5	0F	FEB 10/07	21-51-04- 1	2	FEB 15/09
21-51-03- 5	1	FEB 10/07	21-51-04- 1	3	FEB 15/09
21-51-03- 5	2	JUN 15/08	21-51-04- 1	4	FEB 15/09
21-51-03- 5	3	FEB 15/09	21-51-04- 1	5	FEB 15/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 19


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-51-05- 1	0	FEB 10/07	21-51-09- 5	0B	JUN 15/08
21-51-05- 1	0A	FEB 10/07	21-51-09- 5	0C	JUN 15/08
21-51-05- 1	0B	FEB 10/07	21-51-09- 5	1	FEB 15/09
21-51-05- 1	0C	FEB 10/07	21-51-09- 5	2	OCT 15/08
21-51-05- 1	1	OCT 15/08	21-51-09- 5	3	FEB 15/09
21-51-05- 1	2	FEB 15/09	21-51-09- 5	4	OCT 15/08
21-51-05- 1	3	OCT 15/08	21-51-10- 1	0	OCT 10/06
21-51-05- 1	4	OCT 15/08	21-51-10- 1	0A	OCT 10/06
21-51-05- 1	5	OCT 15/08	21-51-10- 1	0B	FEB 10/07
21-51-05- 1	6	OCT 15/08	21-51-10- 1	1	FEB 15/09
21-51-05- 2	0	FEB 10/07	21-51-10- 1	2	OCT 15/08
21-51-05- 2	1	OCT 15/08	21-51-10- 1	3	OCT 15/08
21-51-05- 2	2	OCT 15/08	21-51-10- 1	4	OCT 15/08
21-51-05- 2	3	OCT 15/08	21-51-10- 2	0	OCT 10/06
21-51-05- 3	0	JUN 15/08	21-51-10- 2	0A	OCT 10/06
21-51-05- 3	1	OCT 15/08	21-51-10- 2	0B	FEB 10/07
21-51-05- 3	2	OCT 15/08	21-51-10- 2	1	FEB 15/09
21-51-05- 3	3	OCT 15/08	21-51-10- 2	2	OCT 15/08
21-51-07- 1	0	OCT 10/06	21-51-10- 2	3	OCT 15/08
21-51-07- 1	0A	OCT 10/06	21-51-10- 3	0	OCT 10/06
21-51-07- 1	1	FEB 15/09	*21-51-10- 3	0A	JUN 15/09
21-51-07- 1	2	JUN 15/08	21-51-10- 3	0B	FEB 10/07
21-51-07- 1	3	JUN 15/08	21-51-10- 3	1	FEB 15/09
21-51-07- 2	0	OCT 10/06	21-51-10- 3	2	FEB 15/09
21-51-07- 2	0A	OCT 10/06	*21-51-10- 3	3	JUN 15/09
21-51-07- 2	1	FEB 15/09	*21-51-10- 3	4	JUN 15/09
21-51-07- 2	2	FEB 15/09	*21-51-10- 3	5	JUN 15/09
21-51-07- 2	3	JUN 15/08	21-51-10- 4	0	OCT 15/08
21-51-07- 3	0	JUN 15/08	*21-51-10- 4	0A	JUN 15/09
21-51-07- 3	0A	JUN 15/08	21-51-10- 4	0B	FEB 10/07
21-51-07- 3	1	FEB 15/09	*21-51-10- 4	1	JUN 15/09
21-51-07- 3	2	FEB 15/09	21-51-10- 4	2	FEB 15/09
21-51-07- 3	3	OCT 15/08	21-51-10- 4	3	FEB 15/09
21-51-07- 4	0	OCT 10/06	*21-51-10- 4	4	JUN 15/09
21-51-07- 4	0A	OCT 10/06	21-51-11- 2	0	OCT 10/06
21-51-07- 4	0B	OCT 10/06	21-51-11- 2	1	FEB 15/09
*21-51-07- 4	1	JUN 15/09	21-51-11- 2	2	OCT 15/08
*21-51-07- 4	2	JUN 15/09	21-51-11- 3	0	OCT 10/06
*21-51-07- 4	3	JUN 15/09	21-51-11- 3	0A	OCT 10/06
21-51-09- 1	0	OCT 15/08	21-51-11- 3	1	FEB 15/09
21-51-09- 1	1	OCT 15/08	21-51-11- 3	2	OCT 15/08
21-51-09- 2	0	OCT 15/08	*21-51-11- 4	0	JUN 15/09
21-51-09- 2	1	OCT 15/08	21-51-11- 4	0A	OCT 10/06
21-51-09- 3	0	FEB 10/07	21-51-11- 4	0B	OCT 10/06
21-51-09- 3	1	OCT 15/08	21-51-11- 4	1	FEB 15/09
21-51-09- 3	2	OCT 15/08	*21-51-11- 4	2	JUN 15/09
21-51-09- 4	0	FEB 10/07	21-51-11- 4	3	OCT 15/08
21-51-09- 4	1	OCT 15/08	21-51-11- 4	4	FEB 15/09
21-51-09- 4	2	OCT 15/08	*21-51-11- 4	5	JUN 15/09
21-51-09- 5	0	JUN 15/08	21-51-11- 5	0	OCT 10/06
21-51-09- 5	0A	JUN 15/08	21-51-11- 5	0A	OCT 10/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 20



BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*21-51-11- 5	0B	JUN 15/09	21-51-14- 2	0B	FEB 10/07
21-51-11- 5	0C	OCT 10/06	21-51-14- 2	1	FEB 15/09
*21-51-11- 5	1	JUN 15/09	21-51-14- 2	2	FEB 15/09
*21-51-11- 5	2	JUN 15/09	21-51-14- 2	3	FEB 15/09
21-51-11- 5	3	OCT 15/08	21-51-14- 2	4	FEB 15/09
21-51-11- 5	4	OCT 15/08	21-51-15- 1	0	OCT 10/06
21-51-11- 5	5	FEB 15/09	21-51-15- 1	1	FEB 15/09
*21-51-11- 5	6	JUN 15/09	21-51-15- 1	2	OCT 10/06
21-51-12- 1	0	OCT 10/06	21-51-15- 2	0	OCT 10/06
21-51-12- 1	0A	OCT 10/06	21-51-15- 2	1	OCT 10/06
21-51-12- 1	0B	OCT 10/06	21-51-15- 3	0	OCT 10/06
21-51-12- 1	1	FEB 15/09	21-51-15- 3	1	FEB 15/09
21-51-12- 1	2	FEB 15/09	21-51-15- 3	2	FEB 15/09
21-51-12- 1	3	FEB 15/09	21-51-15- 4	0	OCT 10/06
21-51-12- 1	4	FEB 15/09	21-51-15- 4	0A	OCT 10/06
21-51-12- 2	0	JUN 15/08	*21-51-15- 4	1	JUN 15/09
21-51-12- 2	0A	JUN 15/08	*21-51-15- 4	2	JUN 15/09
21-51-12- 2	1	FEB 15/09	21-51-17- 1	0	JUN 15/08
21-51-12- 2	2	FEB 15/09	21-51-17- 1	0A	JUN 15/08
21-51-13- 1	0	OCT 10/06	21-51-17- 1	0B	JUN 15/08
21-51-13- 1	0A	OCT 10/06	21-51-17- 1	0C	JUN 15/08
21-51-13- 1	0B	OCT 10/06	21-51-17- 1	0D	JUN 15/08
21-51-13- 1	1	FEB 15/09	21-51-17- 1	1	FEB 15/09
21-51-13- 1	2	FEB 15/09	21-51-17- 1	2	FEB 15/09
21-51-13- 1	3	FEB 15/09	21-51-17- 1	3	FEB 15/09
21-51-13- 1	4	FEB 15/09	21-51-17- 1	4	FEB 15/09
21-51-13- 1	5	FEB 15/09	21-51-17- 2	0	OCT 10/06
21-51-13- 1	6	FEB 15/09	21-51-17- 2	1	JUN 15/08
21-51-13- 1	7	FEB 15/09	21-51-17- 3	0	OCT 10/06
21-51-13- 1	8	FEB 15/09	21-51-17- 3	1	OCT 10/06
21-51-13- 2	0	OCT 10/06	21-51-17- 4	0	OCT 10/06
21-51-13- 2	1	FEB 15/09	21-51-17- 4	1	FEB 15/09
21-51-13- 2	2	FEB 15/09	21-51-17- 4	2	OCT 15/08
21-51-13- 2	3	FEB 15/09	21-51-17- 5	0	JUN 15/08
21-51-13- 3	0	OCT 10/06	*21-51-17- 5	1	JUN 15/09
21-51-13- 3	0A	OCT 10/06	*21-51-17- 5	2	JUN 15/09
21-51-13- 3	1	FEB 15/09	21-51-17- 6	0	JUN 15/08
21-51-13- 3	2	FEB 15/09	21-51-17- 6	0A	JUN 15/08
21-51-13- 3	3	FEB 15/09	21-51-17- 6	0B	JUN 15/08
21-51-13- 4	0	JUN 15/08	21-51-17- 6	0C	JUN 15/08
21-51-13- 4	0A	JUN 15/08	21-51-17- 6	0D	JUN 15/08
21-51-13- 4	1	FEB 15/09	21-51-17- 6	1	FEB 15/09
21-51-13- 4	2	FEB 15/09	21-51-17- 6	2	FEB 15/09
21-51-13- 4	3	FEB 15/09	21-51-17- 6	3	FEB 15/09
21-51-14- 1	0	JUN 15/08	21-51-17- 6	4	FEB 15/09
21-51-14- 1	0A	JUN 15/08	21-51-20- 1	0	OCT 15/08
21-51-14- 1	0B	JUN 15/08	21-51-20- 1	1	OCT 15/08
21-51-14- 1	1	FEB 15/09	21-51-20- 2	0	OCT 15/08
21-51-14- 1	2	FEB 15/09	21-51-20- 2	1	OCT 15/08
21-51-14- 2	0	OCT 10/06	*21-51-20- 3	0	JUN 15/09
21-51-14- 2	0A	FEB 10/07	21-51-20- 3	1	OCT 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 21



BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*21-51-20- 3	2	JUN 15/09	21-51-24- 4	2	FEB 15/09
*21-51-20- 4	0	JUN 15/09	21-51-24- 4	3	OCT 15/08
21-51-20- 4	1	OCT 15/08	21-51-24- 4	4	OCT 15/08
*21-51-20- 4	2	JUN 15/09	21-51-24- 4	5	OCT 15/08
*21-51-21- 1	0	JUN 15/09	21-51-24- 4A	0	FEB 15/08
*21-51-21- 1	0A	JUN 15/09	21-51-24- 4A	0A	OCT 10/07
21-51-21- 1	0B	OCT 10/06	21-51-24- 4A	0B	OCT 10/07
21-51-21- 1	1	OCT 15/08	21-51-24- 4A	0C	OCT 10/07
*21-51-21- 1	2	JUN 15/09	21-51-24- 4A	1	FEB 15/09
*21-51-21- 1	3	JUN 15/09	21-51-24- 4A	2	OCT 15/08
21-51-21- 1A	0	FEB 10/07	21-51-24- 4A	3	FEB 15/09
21-51-21- 1A	0A	FEB 10/07	21-51-24- 4A	4	OCT 15/08
21-51-21- 1A	0B	FEB 10/07	21-51-24- 4A	5	FEB 15/09
21-51-21- 1A	1	OCT 15/08	21-51-24- 4B	0	OCT 10/07
21-51-21- 1A	2	FEB 15/09	21-51-24- 4B	0A	OCT 10/07
21-51-21- 1A	3	OCT 15/08	21-51-24- 4B	0B	OCT 10/07
21-51-21- 1A	4	OCT 15/08	21-51-24- 4B	0C	OCT 10/07
21-51-21- 1A	4	OCT 15/08	21-51-24- 4B	1	FEB 15/09
21-51-23- 1	0	OCT 10/06	21-51-24- 4B	2	OCT 15/08
21-51-23- 1	0A	FEB 10/07	21-51-24- 4B	3	FEB 15/09
21-51-23- 1	0B	OCT 10/06	21-51-24- 4B	4	OCT 15/08
21-51-23- 1	0C	FEB 10/07	21-51-24- 4C	0	OCT 10/06
21-51-23- 1	1	OCT 15/08	21-51-24- 4C	0A	OCT 10/06
21-51-23- 1	2	FEB 15/09	21-51-24- 4C	0B	OCT 10/06
21-51-23- 1	3	OCT 15/08	21-51-24- 4C	0C	OCT 10/06
21-51-23- 1	4	OCT 15/08	21-51-24- 4C	1	FEB 15/09
21-51-23- 1	5	FEB 15/09	21-51-24- 4C	2	JUN 15/08
21-51-23- 1	6	FEB 15/09	21-51-24- 4C	3	JUN 15/08
21-51-23- 1A	0	FEB 10/07	21-51-24- 4C	4	JUN 15/08
21-51-23- 1A	0A	FEB 10/07	21-51-30- 1	0	OCT 15/08
21-51-23- 1A	0B	FEB 10/07	21-51-30- 1	0A	OCT 15/08
21-51-23- 1A	0C	FEB 10/07	21-51-30- 1	1	FEB 15/09
21-51-23- 1A	1	OCT 15/08	21-51-30- 1	2	OCT 15/08
21-51-23- 1A	2	FEB 15/09	21-51-30- 1	3	OCT 15/08
21-51-23- 1A	3	OCT 15/08	21-51-30- 2	0	OCT 15/08
21-51-23- 1A	4	OCT 15/08	21-51-30- 2	0A	OCT 15/08
21-51-23- 1A	5	OCT 15/08	21-51-30- 2	1	FEB 15/09
21-51-23- 1A	6	FEB 15/09	21-51-30- 2	2	OCT 15/08
21-51-23- 1A	7	OCT 15/08	21-51-30- 2	3	OCT 15/08
21-51-23- 1A	8	FEB 15/09	21-51-30- 3	0	FEB 10/07
21-51-23- 1A	9	FEB 15/09	*21-51-30- 3	0A	JUN 15/09
21-51-23- 1A	10	FEB 15/09	21-51-30- 3	1	FEB 15/09
21-51-24- 1	0	OCT 10/06	21-51-30- 3	2	OCT 15/08
21-51-24- 1	1	OCT 15/08	*21-51-30- 3	3	JUN 15/09
21-51-24- 1	2	OCT 15/08	21-51-30- 4	0	OCT 10/07
21-51-24- 1A	0	FEB 10/07	*21-51-30- 4	0A	JUN 15/09
21-51-24- 1A	1	OCT 15/08	*21-51-30- 4	1	JUN 15/09
21-51-24- 4	0	OCT 10/06	*21-51-30- 4	2	JUN 15/09
21-51-24- 4	0A	OCT 10/06	*21-51-30- 4	3	JUN 15/09
21-51-24- 4	0B	OCT 10/06	21-51-31- 1	0	OCT 15/08
21-51-24- 4	0C	OCT 10/06	21-51-31- 1	1	OCT 15/08
21-51-24- 4	1	OCT 15/08			

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 22


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-51-31- 1	2	OCT 15/08	*21-51-41- 8	0	JUN 15/09
21-51-31- 2	0	OCT 15/08	*21-51-41- 8	1	JUN 15/09
21-51-31- 2	1	OCT 15/08	21-51-41- 8	2	FEB 15/09
*21-51-31- 3	0	JUN 15/09	*21-51-41- 8	3	JUN 15/09
21-51-31- 3	1	OCT 15/08	21-51-41- 9	0	JUN 15/08
*21-51-31- 3	2	JUN 15/09	21-51-41- 9	1	FEB 15/09
*21-51-31- 4	0	JUN 15/09	21-51-41- 9	2	FEB 15/09
21-51-31- 4	1	OCT 15/08	21-51-41- 9	3	FEB 15/09
*21-51-31- 4	2	JUN 15/09	21-51-42- 1	0	OCT 10/06
21-51-32- 1	0	FEB 10/07	21-51-42- 1	0A	JUN 15/08
21-51-32- 1	1	OCT 15/08	21-51-42- 1	1	OCT 10/07
21-51-32- 1	2	OCT 15/08	21-51-42- 1	2	FEB 15/09
21-51-32- 1	3	OCT 15/08	21-51-42- 1	3	FEB 15/09
21-51-32- 2	0	JUN 15/08	21-51-42- 1	4	FEB 15/09
21-51-32- 2	1	OCT 15/08	21-51-51- 2	0	JUN 10/07
21-51-32- 2	2	OCT 15/08	21-51-51- 2	0A	OCT 10/06
21-51-40- 1	0	JUN 10/07	21-51-51- 2	1	OCT 10/07
21-51-40- 1	1	FEB 15/09	21-51-51- 2	2	OCT 10/07
21-51-40- 1	2	FEB 15/09	21-51-51- 2	3	FEB 15/09
21-51-40- 1	3	FEB 15/09	21-51-52- 1	0	FEB 15/08
21-51-40- 1	4	FEB 15/09	21-51-52- 1	1	OCT 15/08
21-51-41- 1	0	OCT 15/08	21-51-52- 1	2	OCT 15/08
21-51-41- 1	0A	OCT 15/08	21-51-52- 1	3	OCT 15/08
21-51-41- 1	1	FEB 15/09	21-51-52- 2	0	JUN 15/08
*21-51-41- 1	2	JUN 15/09	21-51-52- 2	1	FEB 15/09
21-51-41- 1	3	OCT 15/08	21-51-52- 2	2	FEB 15/09
21-51-41- 2	0	OCT 15/08	21-51-52- 2	3	FEB 15/09
21-51-41- 2	0A	OCT 15/08	21-51-52- 3	0	OCT 10/06
21-51-41- 2	0B	OCT 15/08	21-51-52- 3	0A	OCT 10/06
21-51-41- 2	1	FEB 15/09	*21-51-52- 3	1	JUN 15/09
*21-51-41- 2	2	JUN 15/09	*21-51-52- 3	2	JUN 15/09
21-51-41- 2	3	OCT 15/08	*21-51-52- 3	3	JUN 15/09
21-51-41- 3	0	OCT 10/06	21-51-52- 4	0	JUN 15/08
21-51-41- 3	1	FEB 15/09	21-51-52- 4	1	FEB 15/09
21-51-41- 3	2	JUN 15/08	21-51-52- 4	2	OCT 15/08
*21-51-41- 3	3	JUN 15/09	21-51-53- 2	0	FEB 10/07
21-51-41- 3	4	JUN 15/08	21-51-53- 2	0A	FEB 10/07
21-51-41- 4	0	OCT 10/06	21-51-53- 2	1	OCT 15/08
*21-51-41- 4	1	JUN 15/09	21-51-53- 2	2	OCT 15/08
*21-51-41- 5	0	JUN 15/09	21-51-53- 2	3	OCT 15/08
21-51-41- 5	1	OCT 15/08	21-51-53- 2	4	FEB 15/09
21-51-41- 5	2	OCT 15/08	21-51-53- 2	5	FEB 15/09
21-51-41- 5	3	OCT 15/08	21-51-53- 2	6	FEB 15/09
*21-51-41- 6	0	JUN 15/09	21-51-53- 3	0	FEB 10/07
21-51-41- 6	1	OCT 15/08	21-51-53- 3	1	OCT 15/08
21-51-41- 6	2	OCT 15/08	21-51-53- 3	2	OCT 15/08
*21-51-41- 6	3	JUN 15/09	*21-51-53- 3	3	JUN 15/09
*21-51-41- 7	0	JUN 15/09	*21-51-53- 3	4	JUN 15/09
21-51-41- 7	1	FEB 15/09	21-51-53- 3	5	OCT 15/08
*21-51-41- 7	2	JUN 15/09	21-51-53- 4	0	JUN 15/08
*21-51-41- 7	3	JUN 15/09	21-51-53- 4	0A	JUN 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
 JUN 15/09

21 - LIST OF EFFECTIVE PAGES
 PAGE 23



BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-51-53- 4	0B	JUN 15/08	21-51-53-10	2	OCT 15/08
21-51-53- 4	0C	OCT 10/06	21-51-53-11	0	OCT 15/08
21-51-53- 4	0D	JUN 15/08	21-51-53-11	0A	OCT 15/08
21-51-53- 4	1	FEB 15/09	21-51-53-11	0B	OCT 15/08
21-51-53- 4	2	FEB 15/09	21-51-53-11	1	FEB 15/09
21-51-53- 4	3	FEB 15/09	21-51-53-11	2	OCT 15/08
21-51-53- 4	4	FEB 15/09	21-51-53-18	0	JUN 10/07
21-51-53- 4	5	FEB 15/09	21-51-53-18	0A	OCT 10/06
*21-51-53- 4	6	JUN 15/09	21-51-53-18	0B	JUN 10/07
21-51-53- 4	7	FEB 15/09	21-51-53-18	0C	OCT 10/06
21-51-53- 4	8	FEB 15/09	21-51-53-18	0D	OCT 10/06
21-51-53- 4	9	FEB 15/09	21-51-53-18	1	FEB 10/07
*21-51-53- 4A	0	JUN 15/09	21-51-53-18	2	FEB 15/09
*21-51-53- 4A	0A	JUN 15/09	21-51-53-18	3	JUN 15/08
21-51-53- 4A	0B	JUN 15/08	21-51-53-18	4	FEB 10/07
21-51-53- 4A	0C	JUN 15/08	21-51-53-18	5	FEB 10/07
*21-51-53- 4A	0D	JUN 15/09	21-51-53-18	6	FEB 10/07
21-51-53- 4A	1	FEB 15/09	21-51-53-18	7	FEB 10/07
21-51-53- 4A	2	FEB 15/09	21-51-53-18	8	FEB 10/07
21-51-53- 4A	3	FEB 15/09	21-51-53-18	9	FEB 15/09
21-51-53- 4A	4	FEB 15/09	21-51-53-18	10	FEB 10/07
*21-51-53- 4A	5	JUN 15/09	21-51-53-19	0	JUN 10/07
*21-51-53- 4A	6	JUN 15/09	21-51-53-19	0A	JUN 10/07
*21-51-53- 4A	7	JUN 15/09	21-51-53-19	0B	JUN 10/07
*21-51-53- 4A	8	JUN 15/09	21-51-53-19	0C	JUN 10/07
21-51-53- 5	0	OCT 10/06	21-51-53-19	1	JUN 10/07
*21-51-53- 5	0A	JUN 15/09	21-51-53-19	2	FEB 15/09
*21-51-53- 5	0B	JUN 15/09	21-51-53-19	3	FEB 15/09
21-51-53- 5	0C	OCT 10/06	*21-51-53-19	4	JUN 15/09
*21-51-53- 5	0D	JUN 15/09	*21-51-53-19	5	JUN 15/09
*21-51-53- 5	0E	JUN 15/09	*21-51-53-19	6	JUN 15/09
*21-51-53- 5	1	JUN 15/09	*21-51-53-19	7	JUN 15/09
21-51-53- 5	2	FEB 15/09	*21-51-53-19	8	JUN 15/09
21-51-53- 5	3	FEB 15/09	21-51-60- 1	0	OCT 10/06
21-51-53- 5	4	FEB 15/09	21-51-60- 1	0A	OCT 10/06
21-51-53- 5	5	FEB 15/09	21-51-60- 1	1	FEB 15/09
*21-51-53- 5	6	JUN 15/09	21-51-60- 1	2	FEB 15/09
*21-51-53- 5	7	JUN 15/09	21-51-60- 1	3	FEB 15/09
*21-51-53- 5	8	JUN 15/09	21-51-60- 2	0	JUN 15/08
*21-51-53- 5	9	JUN 15/09	21-51-60- 2	1	FEB 15/09
21-51-53-10	0	JUN 15/08	21-51-65- 1	0	FEB 10/07
21-51-53-10	0A	OCT 10/06	21-51-65- 1	0A	FEB 10/07
21-51-53-10	0B	FEB 10/07	21-51-65- 1	0B	OCT 15/08
21-51-53-10	0C	FEB 10/07	21-51-65- 1	0C	FEB 10/07
21-51-53-10	0D	FEB 10/07	21-51-65- 1	1	OCT 15/08
21-51-53-10	0E	FEB 10/07	21-51-65- 1	2	OCT 15/08
21-51-53-10	0F	FEB 10/07	21-51-65- 1	3	FEB 15/09
21-51-53-10	0G	FEB 10/07	21-51-65- 1	4	FEB 15/09
21-51-53-10	0H	FEB 10/07	21-51-65- 1	5	FEB 15/09
21-51-53-10	0I	JUN 15/08	21-51-65- 1	6	OCT 15/08
21-51-53-10	1	FEB 15/09	21-51-65- 1A	0	OCT 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 24


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-51-65- 1A	0A	OCT 10/06	21-61-02- 2	2	OCT 15/08
21-51-65- 1A	0B	OCT 10/06	*21-61-02- 2	3	JUN 15/09
*21-51-65- 1A	1	JUN 15/09	21-61-02- 2	4	OCT 15/08
21-51-65- 1A	2	OCT 15/08	21-61-02- 2	5	OCT 15/08
21-51-65- 1A	3	FEB 15/09	21-61-02- 2	6	OCT 15/08
21-51-65- 1A	4	FEB 15/09	21-61-02- 2	7	OCT 15/08
21-51-65- 1A	5	FEB 15/09	21-61-02- 2	8	OCT 15/08
21-51-65- 1A	6	OCT 15/08	21-61-02- 3	0	FEB 10/07
21-60-00	1	OCT 10/06	21-61-02- 3	0A	FEB 10/07
21-60-00- 1B	0	OCT 15/08	21-61-02- 3	0B	FEB 10/07
21-60-00- 1B	1	OCT 15/08	21-61-02- 3	0C	OCT 15/08
21-60-00- 1C	0	OCT 10/06	*21-61-02- 3	0D	JUN 15/09
21-60-00- 1C	1	OCT 10/06	21-61-02- 3	0E	FEB 10/07
21-60-00- 1E	0	OCT 10/06	21-61-02- 3	0F	OCT 15/08
21-60-00- 1E	1	OCT 15/08	21-61-02- 3	0G	OCT 15/08
21-60-00- 3	0	OCT 10/06	21-61-02- 3	1	OCT 15/08
21-60-00- 3	1	OCT 10/06	21-61-02- 3	2	FEB 15/09
21-60-51- 1	0	OCT 10/06	21-61-02- 3	3	OCT 15/08
21-60-51- 1	1	OCT 15/08	21-61-02- 3	4	OCT 15/08
21-60-51- 1	2	FEB 15/09	21-61-02- 3	5	FEB 15/09
21-61-00	1	OCT 10/06	21-61-02- 3	6	FEB 15/09
21-61-00- 1	0	OCT 10/06	21-61-02- 3	7	FEB 15/09
21-61-00- 1	1	OCT 15/08	21-61-02- 3	8	OCT 15/08
21-61-00- 1	2	FEB 15/09	21-61-02- 3	9	OCT 15/08
21-61-00- 1	3	FEB 15/09	21-61-02- 3	10	OCT 15/08
21-61-00- 1	4	FEB 15/09	*21-61-02- 3	11	JUN 15/09
21-61-00- 2	0	OCT 15/08	21-61-02- 4	0	OCT 15/08
21-61-00- 2	1	OCT 15/08	21-61-02- 4	0A	FEB 10/07
21-61-00- 2	2	OCT 15/08	21-61-02- 4	0B	FEB 10/07
21-61-02- 1	0	OCT 15/08	21-61-02- 4	0C	FEB 10/07
21-61-02- 1	0A	OCT 15/08	*21-61-02- 4	0D	JUN 15/09
21-61-02- 1	0B	OCT 15/08	21-61-02- 4	0E	OCT 10/07
21-61-02- 1	0C	OCT 15/08	21-61-02- 4	0F	OCT 10/07
21-61-02- 1	0D	OCT 15/08	21-61-02- 4	1	OCT 15/08
21-61-02- 1	0E	OCT 15/08	21-61-02- 4	2	FEB 15/09
21-61-02- 1	1	FEB 15/09	21-61-02- 4	3	OCT 15/08
21-61-02- 1	2	OCT 15/08	21-61-02- 4	4	OCT 15/08
*21-61-02- 1	3	JUN 15/09	21-61-02- 4	5	FEB 15/09
21-61-02- 1	4	OCT 15/08	21-61-02- 4	6	FEB 15/09
21-61-02- 1	5	OCT 15/08	21-61-02- 4	7	OCT 15/08
21-61-02- 1	6	OCT 15/08	21-61-02- 4	8	OCT 15/08
21-61-02- 1	7	OCT 15/08	21-61-02- 4	9	OCT 15/08
21-61-02- 1	8	OCT 15/08	21-61-02- 4	10	OCT 15/08
21-61-02- 2	0	OCT 15/08	*21-61-02- 4	11	JUN 15/09
21-61-02- 2	0A	OCT 15/08	21-61-03- 3	0	FEB 10/07
21-61-02- 2	0B	OCT 15/08	21-61-03- 3	0A	FEB 10/07
21-61-02- 2	0C	OCT 15/08	21-61-03- 3	0B	FEB 10/07
21-61-02- 2	0D	OCT 15/08	21-61-03- 3	1	OCT 15/08
21-61-02- 2	0E	OCT 15/08	21-61-03- 3	2	OCT 15/08
21-61-02- 2	0F	OCT 15/08	21-61-03- 3	3	OCT 15/08
21-61-02- 2	1	FEB 15/09	21-61-03- 3	4	OCT 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 25



BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-61-03- 3	5	OCT 15/08	21-61-07- 1	2	FEB 15/09
21-61-04- 2	0	OCT 10/06	21-61-07- 1	3	FEB 15/09
*21-61-04- 2	1	JUN 15/09	21-61-07- 2	0	FEB 10/07
*21-61-04- 2	2	JUN 15/09	21-61-07- 2	0A	FEB 10/07
21-61-04- 5	0	FEB 15/09	21-61-07- 2	0B	FEB 15/09
21-61-04- 5	1	FEB 15/09	*21-61-07- 2	1	JUN 15/09
*21-61-04- 5	2	JUN 15/09	21-61-07- 2	2	FEB 15/09
21-61-04-20	0	FEB 15/09	21-61-07- 2	3	FEB 15/09
21-61-04-20	1	FEB 15/09	21-61-07- 2	4	FEB 15/09
21-61-04-22	0	FEB 15/09	21-61-07- 3	0	OCT 10/06
21-61-04-22	1	FEB 15/09	21-61-07- 3	0A	OCT 10/06
21-61-04-22	2	FEB 15/09	*21-61-07- 3	1	JUN 15/09
21-61-05- 1B	0	OCT 10/06	*21-61-07- 3	2	JUN 15/09
21-61-05- 1B	1	FEB 15/08	21-61-08-20	0	FEB 15/09
21-61-05- 1B	2	FEB 15/08	21-61-08-20	1	FEB 15/09
21-61-05- 2	0	FEB 10/07	21-61-08-20	2	FEB 15/09
21-61-05- 2	1	OCT 15/08	21-61-09- 1	0	OCT 10/06
21-61-05- 3	0	OCT 15/08	21-61-09- 1	0A	OCT 10/06
21-61-05- 3	1	OCT 15/08	21-61-09- 1	1	FEB 15/09
21-61-05- 4	0	OCT 10/06	21-61-09- 1	2	OCT 10/06
21-61-05- 4	1	JUN 15/08	21-61-09- 2	0	OCT 10/06
21-61-05- 4	2	OCT 10/06	21-61-09- 2	0A	OCT 10/06
21-61-05- 5	0	FEB 15/09	21-61-09- 2	0B	OCT 10/06
21-61-05- 5	1	FEB 15/09	21-61-09- 2	1	FEB 15/09
21-61-05- 5	2	FEB 15/09	21-61-09- 2	2	FEB 15/09
21-61-05- 7	0	FEB 10/07	21-61-10- 1B	0	OCT 10/06
21-61-05- 7	1	OCT 15/08	21-61-10- 1B	1	JUN 15/08
21-61-05- 8	0	FEB 10/07	21-61-10- 5	0	FEB 10/07
21-61-05- 8	1	OCT 15/08	21-61-10- 5	0A	FEB 10/07
21-61-05-20	0	FEB 15/09	21-61-10- 5	1	OCT 10/06
*21-61-05-20	1	JUN 15/09	21-61-10- 5	2	FEB 10/07
21-61-05-20	2	FEB 15/09	21-61-10- 5	3	FEB 10/07
21-61-05-22	0	FEB 15/09	21-61-10- 5	4	FEB 10/07
21-61-05-22	1	FEB 15/09	21-61-10- 5	5	FEB 10/07
21-61-05-22	2	FEB 15/09	21-61-10- 8	0	OCT 15/08
21-61-06- 4	0	OCT 15/08	21-61-10- 8	0A	OCT 15/08
21-61-06- 4	1	OCT 15/08	21-61-10- 8	1	OCT 15/08
21-61-06- 5	0	OCT 10/06	*21-61-10- 8	2	JUN 15/09
21-61-06- 5	0A	OCT 10/06	*21-61-10- 8	3	JUN 15/09
21-61-06- 5	1	OCT 10/06	*21-61-10- 8	4	JUN 15/09
21-61-06- 6	0	OCT 10/06	21-61-10-11	0	FEB 10/07
21-61-06- 6	1	OCT 10/06	21-61-10-11	0A	OCT 10/06
21-61-06- 6	2	OCT 10/06	21-61-10-11	0B	OCT 10/06
21-61-06- 9	0	OCT 10/07	21-61-10-11	0C	OCT 10/06
21-61-06- 9	1	OCT 15/08	21-61-10-11	1	OCT 10/06
21-61-06- 9	2	OCT 15/08	21-61-10-11	2	FEB 10/07
21-61-06-11	0	OCT 10/06	21-61-10-11	3	FEB 10/07
21-61-06-11	1	FEB 15/09	21-61-10-11	4	OCT 10/07
21-61-07- 1	0	OCT 15/08	21-61-10-13	0	OCT 10/07
21-61-07- 1	0A	OCT 15/08	21-61-10-13	0A	OCT 10/07
21-61-07- 1	1	FEB 15/09	21-61-10-13	1	OCT 15/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 26


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-61-10-13	2	OCT 15/08	21-61-11-20	4	JUN 15/08
21-61-10-13	3	OCT 15/08	21-61-20- 1	0	OCT 10/06
*21-61-10-13	4	JUN 15/09	21-61-20- 1	1	OCT 15/08
*21-61-10-13	5	JUN 15/09	21-61-20- 1	2	OCT 15/08
21-61-10-14	0	OCT 10/07	21-61-20- 2	0	OCT 10/06
21-61-10-14	0A	OCT 10/07	*21-61-20- 2	0A	JUN 15/09
21-61-10-14	1	FEB 15/09	21-61-20- 2	1	OCT 10/06
21-61-10-14	2	OCT 10/07	*21-61-20- 2	2	JUN 15/09
21-61-10-14	3	OCT 10/07	*21-61-20- 2	3	JUN 15/09
21-61-11- 1	0	FEB 10/07	21-61-20- 3	0	FEB 15/09
21-61-11- 1	1	OCT 15/08	*21-61-20- 3	1	JUN 15/09
21-61-11- 1	2	OCT 15/08	21-61-20- 3	2	FEB 15/09
21-61-11-11	0	OCT 15/08	21-61-21- 1	0	OCT 10/06
21-61-11-11	0A	OCT 15/08	21-61-21- 1	0A	OCT 10/06
21-61-11-11	0B	OCT 15/08	21-61-21- 1	0B	OCT 10/06
21-61-11-11	1	OCT 15/08	21-61-21- 1	0C	OCT 10/06
21-61-11-11	2	OCT 15/08	21-61-21- 1	0D	FEB 10/07
21-61-11-11	3	FEB 15/09	21-61-21- 1	1	FEB 15/09
21-61-11-11	4	FEB 15/09	21-61-21- 1	2	FEB 15/09
21-61-11-12	0	OCT 10/06	21-61-21- 1	3	FEB 15/09
21-61-11-12	0A	OCT 10/06	21-61-21- 1	4	FEB 15/09
21-61-11-12	0B	OCT 10/06	21-61-21- 1	5	FEB 15/09
21-61-11-12	0C	OCT 10/06	21-61-21- 1	6	FEB 15/09
21-61-11-12	1	OCT 10/06	*21-61-21- 2	0	JUN 15/09
21-61-11-12	2	FEB 10/07	21-61-21- 2	0A	OCT 10/06
21-61-11-12	3	FEB 15/09	21-61-21- 2	0B	OCT 10/06
21-61-11-12	4	FEB 15/09	21-61-21- 2	0C	OCT 10/06
21-61-11-12	5	OCT 10/06	21-61-21- 2	0D	OCT 10/06
21-61-11-17	0	OCT 10/06	21-61-21- 2	0E	OCT 10/06
21-61-11-17	0A	OCT 10/06	21-61-21- 2	0F	OCT 10/06
21-61-11-17	0B	OCT 10/06	21-61-21- 2	0G	FEB 10/07
21-61-11-17	1	OCT 10/06	21-61-21- 2	1	FEB 15/09
21-61-11-17	2	FEB 10/07	21-61-21- 2	2	OCT 10/07
21-61-11-17	3	FEB 15/09	21-61-21- 2	3	FEB 15/09
21-61-11-17	4	JUN 15/08	21-61-21- 2	4	FEB 15/09
21-61-11-17	5	JUN 15/08	21-61-21- 2	5	OCT 15/08
21-61-11-19	0	OCT 10/07	*21-61-21- 2	6	JUN 15/09
21-61-11-19	0A	OCT 10/07	21-61-21- 2	7	FEB 15/09
21-61-11-19	0B	OCT 10/07	21-61-30- 2	0	OCT 10/06
21-61-11-19	1	OCT 15/08	21-61-30- 2	1	OCT 10/06
*21-61-11-19	2	JUN 15/09	21-61-30- 5	0	FEB 15/09
21-61-11-19	3	OCT 15/08	21-61-30- 5	1	FEB 15/09
21-61-11-19	4	FEB 15/09	21-61-30- 5	2	FEB 15/09
21-61-11-19	5	OCT 15/08	21-61-30-20	0	FEB 15/09
21-61-11-19	6	OCT 15/08	21-61-30-20	1	FEB 15/09
21-61-11-20	0	OCT 10/07	21-61-30-20	2	FEB 15/09
21-61-11-20	0A	OCT 10/07	21-61-30-22	0	FEB 15/09
21-61-11-20	0B	OCT 10/07	21-61-30-22	1	FEB 15/09
21-61-11-20	1	FEB 15/09	21-61-30-22	2	FEB 15/09
21-61-11-20	2	FEB 15/09	21-61-31- 1A	0	OCT 10/06
21-61-11-20	3	OCT 10/07	21-61-31- 1A	1	OCT 10/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 27


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
21-61-32- 1	0	OCT 10/06			
21-61-32- 1	1	OCT 15/08			
*21-61-32- 1	2	JUN 15/09			
*21-61-32- 1	3	JUN 15/09			
21-61-32-10	0	FEB 15/09			
21-61-32-10	1	FEB 15/09			
21-61-32-10A	0	FEB 15/09			
*21-61-32-10A	1	JUN 15/09			
21-61-33- 1	0	FEB 10/07			
21-61-33- 1	1	OCT 15/08			
21-61-33- 1	2	OCT 15/08			
21-61-35- 1	0	OCT 15/08			
21-61-35- 1	1	OCT 15/08			
21-61-51- 2	0	FEB 15/09			
21-61-51- 2	0A	FEB 10/07			
21-61-51- 2	1	OCT 15/08			
21-61-51- 2	2	OCT 15/08			
21-61-51- 2	3	FEB 15/09			
21-61-51- 2	4	OCT 15/08			
21-61-51- 2	5	FEB 15/09			
21-61-51- 5	0	OCT 10/06			
21-61-51- 5	0A	OCT 10/06			
21-61-51- 5	0B	OCT 10/06			
21-61-51- 5	1	OCT 15/08			
21-61-51- 5	2	OCT 15/08			
21-61-51- 5	3	FEB 15/09			
21-61-51- 5	4	OCT 15/08			
21-61-51- 5	5	OCT 15/08			
21-61-51- 5	6	OCT 15/08			
21-61-52- 1	0	OCT 10/06			
*21-61-52- 1	1	JUN 15/09			
21-61-52- 1	2	FEB 15/09			
21-61-52- 1	3	FEB 15/09			
21-61-52- 1	4	FEB 15/09			
21-62-00	1	OCT 10/06			
21-62-01- 1	0	OCT 10/06			
21-62-01- 1	0A	OCT 10/06			
21-62-01- 1	1	OCT 10/06			
21-62-01- 1	2	OCT 15/08			
21-62-01- 1	3	OCT 15/08			
*21-62-01- 2	0	JUN 15/09			
21-62-01- 2	1	OCT 10/06			
*21-62-01- 2	2	JUN 15/09			
21-62-01- 3	0	OCT 10/06			
21-62-01- 3	1	FEB 15/09			
21-62-01- 3	2	FEB 15/09			
21-62-01- 3	3	FEB 15/09			
21-62-51- 1	0	FEB 15/09			
*21-62-51- 1	1	JUN 15/09			
*21-62-51- 1	2	JUN 15/09			

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP
JUN 15/09

21 - LIST OF EFFECTIVE PAGES
PAGE 28


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
AIR CONDITIONING (GENERAL)	21-00-00		
PRODUCT COLLECTOR-CUSTOMER UNIQUE (AIR CONDITIONING ONLY)	21-00-00	42	201967
PRODUCT COLLECTOR-CUSTOMER UNIQUE (AIR CONDITIONING ONLY)	21-00-00	43	001030
PRODUCT COLLECTOR-CUSTOMER UNIQUE (AIR CONDITIONING ONLY)	21-00-00	43A	001030
PRODUCT COLLECTOR-MAJOR MODEL BASIC AND STABLE (AIR CONDITIONING ONLY)	21-00-00	33	001030 201967
PRODUCT COLLECTOR-MAJOR MODEL BASIC AND STABLE (AIR CONDITIONING ONLY)	21-00-00	33A	001030 201967
PRODUCT COLLECTOR-MINOR MODEL BASIC AND STABLE (AIR CONDITIONING ONLY)	21-00-00	37	201967
PRODUCT COLLECTOR-MINOR MODEL BASIC AND STABLE (AIR CONDITIONING ONLY)	21-00-00	38	001030
PRODUCT COLLECTOR-OPT FEATURE	21-00-00	46	001030 201967
PRODUCT COLLECTOR-OPT FEATURE (AIR CONDITIONING ONLY)	21-00-00	46A	201967
SUPPORT INSTL	21-00-51	02	201967
SUPPORT INSTL	21-00-51	03	101999
SUPPORT INSTL	21-00-51	04	001100
SUPPORT INSTL	21-00-51	05	048048 050050 053100


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DISTRIBUTION	21-20-00		
DUCT INSTL-AFT EE BAY STA 350 TO STA 388 FLIGHT DECK AIR DISTR SYS	21-20-00	05	201967
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY CUSTOMER UNIQUE (DISTRIBUTION ONLY)	21-20-00	09B	201967
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY CUSTOMER UNIQUE (DISTRIBUTION ONLY)	21-20-00	09C	001030
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MAJOR MODEL BASIC AND STABLE (DISTRIBUTION ONLY)	21-20-00	04	001030 201967
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MINOR MODEL BASIC AND STABLE (DISTRIBUTION ONLY)	21-20-00	04B	201967
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY MINOR MODEL BASIC AND STABLE (DISTRIBUTION ONLY)	21-20-00	04C	001030
FUNCTIONAL COLLECTOR-BODY AIR CONT SYS CUSTOMER UNIQUE FOR 737-800	21-20-00	49B	001030
FUNCTIONAL COLLECTOR-BODY AIR CONT SYS OPT FEATURE	21-20-00	49C	201967
MAIN AIR DISTRIBUTION	21-21-00		
CONNECTOR INSTL-AIR DISTR GND SVCE	21-21-01	10	101999
DUCT INSTL-AIR DISTR MIX BAY SYS BASELINE CONFIGURATION FOR 737-700 (COLD AIR CHECK VALVE ONLY)	21-21-51	05	101101 201971
DUCT INSTL-AIR DISTR MIX BAY SYS BASELINE CONFIGURATION FOR 737-700 (COLD AIR CHECK VALVE ONLY)	21-21-51	05B	102200 972999
DUCT INSTL-AIR DISTR MIX BAY SYS BASELINE CONFIGURATION FOR 737-700 (MIX CHAMBER ONLY)	21-21-02	04	101999
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH	21-21-01	02	005005 008030 201967
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH	21-21-01	03	005005 008999
SYSTEM INSTL-AIR DISTR MIX BAY (MAIN AIR DISTRIBUTION ONLY)	21-21-01	01	001100


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
SYSTEM INSTL-AIR DISTR MIX BAY TRIM DUCTING	21-21-01	05	001100
FLIGHT COMPARTMENT CONDITIONED AIR DISTRIBUTION	21-22-00		
DUCT INSTL- E/E BAY STA 181 TO STA 262 FWD	21-22-00	06	012200 968999
DUCT INSTL-CAB. INSTR PNL GASPER/WSHLD DEFOG FT AIR OUTLET	21-22-51	03A	031200 968999
DUCT INSTL-CAB., INSTR PNL, GASPER/WSHLD DEFOG FT AIR OUTLET	21-22-51	03	001030 201967
DUCT INSTL-FLIGHT DECK AIR DISTR SYS	21-22-00	07	037100
DUCT INSTL-FLIGHT DECK AIR DISTR SYS	21-22-51	05	001030 201967
DUCT INSTL-FLIGHT DECK AIR DISTR SYS	21-22-51	05A	031200 968999
DUCT INSTL-FLIGHT DECK AIR DISTR SYS	21-22-51	05B	031200 968999
DUCT INSTL-FLIGHT DECK AIR DISTR SYS	21-22-51	06	201967
DUCT INSTL-FLIGHT DECK AIR DISTR SYS	21-22-51	06A	101200 968999
DUCT INSTL-FLIGHT DECK AIR DISTR SYS, WITH DUCT SENSORS SECT. 41, AFT, STA 262 TO 388	21-22-00	04	101200 968999
DUCT INSTL-FLIGHT DECK AIR DISTR SYS, WITH DUCT SENSORS SECT. 41, AFT, STA 262 TO 388	21-22-00	05	012100
DUCT INSTL-PUSH/PULL CABLE AND FT AIR/WSHLD DEFOG PNL (AIR OUTLET VALVE CONTROL CABLES ONLY)	21-22-02	01	001030 201967
DUCT INSTL-PUSH/PULL CABLE AND FT AIR/WSHLD DEFOG PNL (AIR OUTLET VALVE CONTROL CABLES ONLY)	21-22-02	01A	031046 054104 968972
DUCT INSTL-PUSH/PULL CABLE AND FT AIR/WSHLD DEFOG PNL (WINDSHIELD AND FOOT AIR OUTLET VALVE ONLY)	21-22-01	01	001030 201967
DUCT INSTL-PUSH/PULL CABLE AND FT AIR/WSHLD DEFOG PNL (WINDSHIELD AND FOOT AIR OUTLET VALVE ONLY)	21-22-01	01A	031046 054104 968972
DUCT INSTL-SECT. 43 AIR DISTR SYS FLIGHT DECK 737-800 BASELINE	21-22-00	02	001100


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
LINING ASSY-LH CEILING FWD (AIR CONDITIONING ONLY)	21-22-00	09	028200 968999
LINING ASSY-LH CEILING FWD (AIR CONDITIONING ONLY)	21-22-00	10	001027 201967
LINING ASSY-R FWD CLG (AIR CONDITIONING ONLY)	21-22-00	11	031200 968999
LINING ASSY-R FWD CLG (AIR CONDITIONING ONLY)	21-22-00	11A	001030 201967
R SUPPORT ASSY-FWD PNL (FLIGHT R COMPARTMENT CONDITIONED AIR R DISTRIBUTION ONLY)	21-22-02	02	047053 105200 973999
PASSENGER CABIN CONDITIONED AIR DISTRIBUTION	21-23-00		
DUCT INSTL-FWD OVERHEAD AIR DISTR SYS	21-23-01	01	201967
DUCT INSTL-MID OVERHEAD AIR DISTR SYS	21-23-01	03	201967
DUCT INSTL-MID OVHD AIR DISTR SYS (DISTRIBUTION ONLY)	21-23-01	06	001011
DUCT INSTL-OHVD AIR DISTR SYS	21-23-01	40	037100
DUCT INSTL-OVERHEAD AIR DISTR SYS	21-23-01	02	201967
DUCT INSTL-OVERHEAD AIR DISTR SYS	21-23-01	29	012100
DUCT INSTL-OVERHEAD AIR DISTR SYS (PASSENGER CABIN CONDITIONED AIR DISTRIBUTION ONLY)	21-23-01	05	001030
DUCT INSTL-OVHD AIR DISTR SYS	21-23-01	16	012036 101200 968999
DUCT INSTL-OVHD AIR DISTR SYS	21-23-01	17A	101200 968999
DUCT INSTL-OVHD AIR DISTR SYS	21-23-01	18	101200 968999
DUCT INSTL-OVHD AIR DISTR SYS	21-23-01	23	012036
DUCT INSTL-OVHD AIR DISTR SYS	21-23-01	30A	101200 968999
DUCT INSTL-OVHD AIR DISTR SYS	21-23-01	38	037100
DUCT INSTL-OVHD AIR DISTR SYS (PASSENGER CABIN CONDITIONED AIR DISTRIBUTION ONLY)	21-23-01	05A	031100
DUCT INSTL-OVHD AIR DISTR SYS (PASSENGER CABIN CONDITIONED AIR DISTRIBUTION ONLY)	21-23-01	20A	101200 968999


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-OVHD AIR DISTR SYS (PASSENGER CABIN CONDITIONED AIR DISTRIBUTION ONLY)	21-23-01	22	012030
DUCT INSTL-OVHD AIR DISTR SYS (PASSENGER CABIN CONDITIONED AIR DISTRIBUTION ONLY)	21-23-01	22A	031036
DUCT INSTL-OVHD AIR DISTR SYS (PASSENGER CABIN CONDITIONED AIR DISTRIBUTION ONLY)	21-23-01	22B	037100
DUCT INSTL-OVHD AIR DISTR SYS STA 727D TO 947.5	21-23-01	28C	101200 968999
DUCT INSTL-OVHD AIR DISTR SYS STA 727I TO 947.5	21-23-01	28A	012030
DUCT INSTL-OVHD AIR DISTR SYS STA 727I TO 947.5	21-23-01	28D	031100
DUCT INSTL-SECT. 46 OVERHEAD AIR DISTR SYS	21-23-01	04A	001011
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-01	32D	038038 042043
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	13B	001030 201967
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	13C	031036 101101 968971
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	15C	044100 102200 972999
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	22	044100
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	24	037043
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	28A	001030
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	28B	031043
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	29A	201967
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	29B	101101 968971
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	29C	102200 972999
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	35B	001030
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	35D	031043
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	36	044100


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	42C	101101 968971
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	43A	201967
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	87	044100
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	88	102200 972999
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-51	88A	044100
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	01A	102200 972999
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	20A	101101 968971
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	21	201967
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	33	001030
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	34A	031037 039041
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	35A	054100
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	35B	044053
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	61	102200 972999
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	65	102200 972999
DUCT INSTL-SIDEWALL AIR DISTR SYS	21-23-52	66	044100
DUCT INSTL-SIDEWALL RISER AIR DISTR SYS	21-23-52	31	101999
DUCT INSTL-SIDEWALL RISER AIR DISTR SYS SECT. 43	21-23-00	16B	001100
DUCT INSTL-SIDEWALL RISER AIR DISTR SYS SECT. 43	21-23-00	16C	001100
DUCT INSTL-SUPPLY AIR LAV D	21-23-52	46	001030 201967
DUCT INSTL-SUPPLY AIR LAV D	21-23-52	46B	031046 054103 968971
DUCT INSTL-SUPPLY AIR LAV D	21-23-52	46G	047053 104200 972999
DUCT INSTL-SUPPLY AIR LAV E	21-23-52	48	001030 201967

 *BOEING*
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-SUPPLY AIR LAV E	21-23-52	48A	031037 039046 054103 968971
DUCT INSTL-SUPPLY AIR LAV E	21-23-52	48E	047053 104200 972999
FUNCTIONAL COLLECTOR CUSTOMER UNIQUE (PASSENGER CABIN CONDITIONED AIR DISTRIBUTION ONLY)	21-23-00	15A	201967
FUNCTIONAL COLLECTOR CUSTOMER UNIQUE (PASSENGER CABIN CONDITIONED AIR DISTRIBUTION ONLY)	21-23-00	15B	001030
HARDWARE INSTL-LAV A (AIR CONDITIONING ONLY)	21-23-00	13	
PANEL ASSY-AFT RH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	30	028200 968999
PANEL ASSY-AFT RH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	32	001027 201967
PANEL ASSY-FWD LH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	77A	001027
PANEL ASSY-FWD LH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	89B	201967
PANEL ASSY-FWD LH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	89D	031200 968999
PANEL ASSY-FWD LH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	91	028030
PANEL ASSY-FWD RH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	13A	001027 201967
PANEL ASSY-FWD RH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	93	028036
PANEL ASSY-FWD RH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	93A	037200 968999
PANEL ASSY-LH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	04	028200 968999
PANEL ASSY-LH DOORWAY LINING (AIR CONDITIONING ONLY)	21-23-54	12	001027 201967
PROVISION INSTL-OVERHEAD AIR DISTRIBUTION SYSTEM SECTION 43	21-23-01	55	201967


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
R PROVISION INSTL-OVERHEAD AIR	21-23-01	56	031999
R DISTRIBUTION SYSTEM SECTION 44			
PROVISION INSTL-OVHD AIR DISTR SYS, SECT. 43	21-23-01	55A	044046
PROVISIONS INSTL-OVHD AIR DISTR SYS	21-23-01	51	001100
PROVISIONS INSTL-OVHD AIR DISTR SYS	21-23-01	57	101999
SECT 46, AFT			
PROVISIONS INSTL-OVHD AIR DISTR SYS, SECT 43 WITH LIFERAFTS	21-23-01	52	001043 054200 968999
PROVISIONS INSTL-OVHD AIR DISTR SYS, SECT. 43	21-23-01	52B	044053
PROVISIONS INSTL-SECT. 46 MID OVHD AIR DISTR SYS	21-23-01	58	201967
SUPPORT INSTL-AIR DISTR SYS	21-23-51	25A	101200 968999
SUPPORT INSTL-AIR DISTR SYS	21-23-51	25B	023100
GASPER AIR DISTRIBUTION	21-24-00		
HOSE INSTL-SECT. 43, 44 AND 46 PSU GASPER	21-24-51	19	201967
HOSE INSTL-STA 390 TO STA 897 PSU GASPER	21-24-51	43	001030
MODULE ASSY-LAV A (DISTRIBUTION ONLY)	21-24-51	35C	042046 051052
MODULE ASSY-LAV A (DISTRIBUTION ONLY)	21-24-51	46P	031041 047050 053200 968999
MODULE ASSY-LAV D (AIR CONDITIONING ONLY)	21-24-51	46N	031037 039041 047050 053200 968999
MODULE ASSY-LAV D (AIR CONDITIONING ONLY)	21-24-51	55A	038038 042046 051052
MODULE ASSY-LAV E (AIR CONDITIONING ONLY)	21-24-51	46Q	031037 039041 047050 053100

 **BOEING**
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
MODULE ASSY-LAV E (AIR CONDITIONING ONLY)	21-24-51	55C	038038 042046 051052
MODULE ASSY-LAV E (AIR CONDITIONING ONLY)	21-24-51	89A	101200 968999
PLUMBING ASSY-LAV A (AIR CONDITIONING ONLY)	21-24-51	40C	042046 051052
PLUMBING ASSY-LAV A (AIR CONDITIONING ONLY)	21-24-51	57P	031041 047050 053200 968999
PLUMBING ASSY-LAV D (AIR CONDITIONING ONLY)	21-24-51	45A	038038 042046 051052
PLUMBING ASSY-LAV D (AIR CONDITIONION ONLY)	21-24-51	57N	031037 039041 047050 053200 968999
PLUMBING ASSY-LAV E (AIR CONDITIONING ONLY)	21-24-51	55D	038038 042046 051052
PLUMBING ASSY-LAV E (AIR CONDITIONING ONLY)	21-24-51	98A	101200 968999
PLUMBING ASSY-LAV E (AIR CONDITIONION ONLY)	21-24-51	57Q	031037 039041 047050 053100
SERVICE UNIT ASSY-NO SPKR WITH GASPER PASS. (AIR CONDITIONING ONLY)	21-24-00	28C	001037 039040
SERVICE UNIT ASSY-NO SPKR WITH GASPER PASS. (AIR CONDITIONING ONLY)	21-24-00	52A	001030
SERVICE UNIT ASSY-NO SPKR WITH GASPER PASS. (AIR CONDITIONING ONLY)	21-24-52	50R	048048
SERVICE UNIT ASSY-NO SPKR WITH GASPER PASS. (AIR CONDITIONING ONLY)	21-24-52	51A	038038 041047 049100
SERVICE UNIT ASSY-NO SPKR WITH GASPER PASS. (AIR CONDITIONING ONLY)	21-24-52	51P	101200 968999


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
SERVICE UNIT ASSY-PASS LAV E (AIR CONDITIONING ONLY)	21-24-51	05A	006007
SERVICE UNIT ASSY-PASS. NO SPKR WITH GASPER (AIR CONDITIONING ONLY)	21-24-00	01A	201967
SERVICE UNIT ASSY-PASS. NO SPKR WITH GASPER (AIR CONDITIONING ONLY)	21-24-00	63E	201967
SERVICE UNIT ASSY-WITH SPKR AND GASPER PASS. (AIR CONDITIONING ONLY)	21-24-00	01	201967
SERVICE UNIT ASSY-WITH SPKR AND GASPER PASS. (AIR CONDITIONING ONLY)	21-24-00	52	001030
SERVICE UNIT ASSY-WITH 2K SPKR AND GASPER PASS. (AIR CONDITIONING ONLY)	21-24-00	63D	201967
SERVICE UNIT ASSY-WITH 2K SPKR AND GASPER PASS. (AIR CONDITIONING ONLY)	21-24-00	28B	001037 039040
SERVICE UNIT ASSY-WITH 2K SPKR AND GASPER PASS. (AIR CONDITIONING ONLY)	21-24-52	50Q	048048
SERVICE UNIT ASSY-WITH 2K SPKR AND GASPER PASS. (AIR CONDITIONING ONLY)	21-24-52	51	038038 041047 049100
SERVICE UNIT ASSY-WITH 2K SPKR AND GASPER PASS. (AIR CONDITIONING ONLY)	21-24-52	51N	101200 968999
STRUCTURE INSTL-LAV A (AIR CONDITIONING ONLY)	21-24-00	05	001001
STRUCTURE INSTL-LAV A (AIR CONDITIONING ONLY)	21-24-00	07	006007
STRUCTURE INSTL-LAV A (AIR CONDITIONING ONLY)	21-24-00	07A	201967
STRUCTURE INSTL-LAV A (AIR CONDITIONING ONLY)	21-24-00	09	008030
STRUCTURE INSTL-LAV D (AIR CONDITIONING ONLY)	21-24-00	17	006007
STRUCTURE INSTL-LAV D AND E (AIR CONDITIONING ONLY)	21-24-00	04	001005 008030 201967
STRUCTURE INSTL-LAV D AND G (AIR CONDITIONING ONLY)	21-24-00	08	201967
STRUCTURE INSTL-LAV D AND G (AIR CONDITIONING ONLY)	21-24-00	16	014030
STRUCTURE INSTL-LAV E (AIR CONDITIONING ONLY)	21-24-51	04X	006007

 **BOEING**
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
RECIRCULATION SYSTEM	21-25-00		
DUCT INSTL-AIR DISTR MIX BAY SYS	21-25-03	06	101999
BASELINE CONFIGURATION (RECIRCULATION			
FAN CHECK VALVE ONLY)			
DUCT INSTL-AIR DISTR MIX BAY SYS	21-25-01	04	101999
BASELINE CONFIGURATION FOR 737-700			
(RECIRCULATION AIR FILTER ONLY)			
DUCT INSTL-AIR DISTR MIX BAY, BASELINE	21-25-02	06	101999
SYS CONFIGURATION FOR 737-700			
(RECIRCULATION FAN ONLY)			
EQUIPMENT INSTL-P6 CB PNL	21-25-02	02	008030
(RECIRCULATION FAN ONLY)			201967
EQUIPMENT INSTL-P6 CB PNL	21-25-02	02A	031200
(RECIRCULATION FAN ONLY)			968999
EQUIPMENT INSTL-P6 CB PNL	21-25-02	25	001007
(RECIRCULATION FAN ONLY)			
JUNCTION BOX ASSY-J24 (RECIRCULATION	21-25-00	03	001007
SYSTEM ONLY)			
JUNCTION BOX INSTL AND ASSY - J22 (AIR	21-25-00	04	001100
CONDITIONING ONLY)			
JUNCTION BOX INSTL-J24 (RECIRCULATION	21-25-00	02	005005
SYSTEM ONLY)			008999
MODULE INSTL-P5 OVHD (RECIRCULATION	21-25-02	01	001028
SYSTEM ONLY)			201967
MODULE INSTL-P5 OVHD (RECIRCULATION	21-25-02	09	029200
SYSTEM ONLY)			968999
SYSTEM INSTL-AIR DISTR MIX BAY (AIR	21-25-02	08	001100
RECIRCULATION FAN ONLY)			
SYSTEM INSTL-AIR DISTR MIX BAY	21-25-03	01	001100
RECIRCULATION (AIR RECIRCULATION FAN			
CHECK VALVE ONLY)			
SYSTEM INSTL-AIR DISTR MIX BAY	21-25-01	01	001100
RECIRCULATION (AIR RECIRCULATION			
FILTER ONLY)			
VENTILATION SYSTEM	21-26-00		
CEILING ASSY-AFT ENTRY (AIR	21-26-51	16	001030
CONDITIONING ONLY)			201967
CEILING ASSY-AFT ENTRY (AIR	21-26-51	16A	031200
CONDITIONING ONLY)			968999

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
CEILING ASSY-FWD ENTRY (GALLEY VENTILATION MUFFLER ONLY)	21-26-01	01	001036 201967
CEILING ASSY-FWD ENTRY (GALLEY VENTILATION MUFFLER ONLY)	21-26-01	01B	037200 968999
CEILING ASSY-FWD ENTRY (VENTILATION SYSTEM ONLY)	21-26-51	13	001036 201967
CEILING ASSY-FWD ENTRY (VENTILATION SYSTEM ONLY)	21-26-51	13B	037200 968999
DUCT INSTL- WITH GALLEY VENT ONLY	21-26-51	10	008030 201967
DUCT INSTL-AFT LAV/GALLEY VENT	21-26-51	02	001007
DUCT INSTL-FWD GALLEY VENT	21-26-51	01	
DUCT INSTL-LAV A COLD AIR AND SUPPLY AIR PROVISIONS	21-26-50	01	
DUCT INSTL-WITH GALLEY VENT ONLY	21-26-51	10A	031200 968999
DUCT INSTL-WITH LAV/GALLEYS VENT	21-26-51	09	031200 968999
DUCT INSTL-WITH LAV/GALLEYS VENT	21-26-51	09B	008030 201967
EQUIPMENT COOLING SYSTEM	21-27-00		
COOLING INSTL-E8-1 RACK E/E EQUIPMENT	21-27-00	03	005005 008200 968999
DUCT INSTL- STA 181 TO STA 262 FWD EE BAY FLIGHT DECK AIR DISTR SYS	21-27-51	16	201967
DUCT INSTL-E/E COOLING EXH SECT. 41 FWD	21-27-51	50A	031200 968999
DUCT INSTL-E/E COOLING EXH SECT. 41, FWD	21-27-51	50	012030
DUCT INSTL-E/E COOLING EXHAUST SECT. 41, FWD	21-27-51	51	012200 968999
DUCT INSTL-E/E COOLING SUPPLY SECT. 41 FWD	21-27-51	47A	031200 968999
DUCT INSTL-E/E COOLING SUPPLY SECT. 41 FWD	21-27-51	48	012030
DUCT INSTL-E/E COOLING SUPPLY SECT. 41 FWD	21-27-51	48A	031200 968999
DUCT INSTL-E/E COOLING SUPPLY SECT. 41, FWD	21-27-51	47	012030
DUCT INSTL-FLIGHT DECK E/E COOLING EXH	21-27-51	01	

 **BOEING**
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-FLIGHT DECK E/E COOLING EXH	21-27-51	03	001030 201967
DUCT INSTL-FLIGHT DECK E/E COOLING EXH	21-27-51	03A	031200 968999
DUCT INSTL-FLIGHT DECK E/E COOLING EXH	21-27-51	42	002005 008030 201967
DUCT INSTL-FLIGHT DECK E/E COOLING EXH	21-27-51	42A	031047 054106 968999
DUCT INSTL-FLIGHT DECK E/E COOLING SUPPLY	21-27-51	02	001030 201967
DUCT INSTL-FLIGHT DECK E/E COOLING SUPPLY	21-27-51	02A	031200 968999
DUCT INSTL-FLIGHT DECK E/E COOLING SUPPLY	21-27-51	41	002005 008030 201967
DUCT INSTL-FLIGHT DECK E/E COOLING SUPPLY	21-27-51	41A	031047 054106 968999
DUCT INSTL-SECT. 41 FWD E/E COOLING EXH	21-27-51	05	001011 201967
DUCT INSTL-SECT. 41 FWD E/E COOLING SUPPLY	21-27-51	19	037200 968999
DUCT INSTL-SECT. 41 FWD E/E COOLING SUPPLY	21-27-51	33	001030 201967
DUCT INSTL-SECT. 41 FWD E/E COOLING SUPPLY	21-27-51	33A	031200 968999
DUCT INSTL-SECT. 41 FWD E/E COOLING SUPPLY	21-27-51	45	201967
DUCT INSTL-SECT. 41/43 LOWER INTEGRATION	21-27-51	46	
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH	21-27-04	01	001030 201967
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH	21-27-04	01A	031200 968999
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH	21-27-04	04	005005 008030 201967
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH	21-27-04	05	031200 968999

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH (EQUIPMENT COOLING EXHAUST FAN ONLY)	21-27-04	03	001004 006007 031200 968999
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH (EQUIPMENT COOLING OVERBOARD EXHAUST VALVE ONLY)	21-27-05	01	001004 006007 031200 968999
DUCT INSTL-SECT. 43 AFT E/E COOLING EXH (EQUIPMENT COOLING SYSTEM ONLY)	21-27-51	09	001004 006007 031200 968999
DUCT INSTL-SECT. 43 AFT E/E COOLING SUPPLY	21-27-51	07	001036 201967
DUCT INSTL-SECT. 43 AFT E/E COOLING SUPPLY	21-27-51	07B	037200 968999
R R R DUCT INSTL-SECT. 43 AFT E/E COOLING SUPPLY	21-27-51	10	044051 102200 972999
DUCT INSTL-SECT.41 FWD E/E COOLING SUPPLY	21-27-51	04	001011 201967
DUCT INSTL-STA 181 TO STA 262 FWD E/E BAY FLIGHT DECK AIR DISTR SYS	21-27-51	22	001011
DUCT INSTL-STA 262 TO STA 350 AFT E/E BAY FLIGHT DECK AIR DISTR SYS (EQUIPMENT COOLING SYSTEM ONLY)	21-27-51	21	001011
ELECTRICAL INSTL AND ASSY-P5 FWD OVHD (AIR CONDITIONING ONLY)	21-27-00	01	001036 201967
ELECTRICAL INSTL-P5 FWD OVHD (AIR CONDITIONING ONLY)	21-27-52	01	037200 968999
FUNCTIONAL COLLECTOR MAJOR MODEL BASIC AND STABLE (EQUIPMENT COOLING SYSTEM ONLY)	21-27-00	14	001030 201967
FUNCTIONAL COLLECTOR-CUSTOMER UNIQUE EQPT INSTL (EQUIPMENT COOLING SYSTEM ONLY)	21-27-00	12	001030
JUNCTION BOX AND COMPONENT INSTL-J20 (AIR CONDITIONING ONLY)	21-27-00	05A	001027 201967
JUNCTION BOX AND COMPONENT INSTL-J20 (EQUIPMENT COOLING SYSTEM ONLY)	21-27-00	05	028200 968999


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
JUNCTION BOX AND COMPONENT INSTL-J24 (EQUIPMENT COOLING SYSTEM ONLY)	21-27-51	71	005005 008999
JUNCTION BOX ASSY-J24 (EQUIPMENT COOLING SYSTEM ONLY)	21-27-00	04	001007
PROVISION INSTL-E/E EQPT COOLING E8 RACK	21-27-51	28	001004 006007
R SUPPORT ASSY-FWD PNL (EQUIPMENT	21-27-51	41B	048053
R COOLING SYSTEM ONLY)			107200


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
PRESSURIZATION CONTROL	21-30-00		
FUNCTIONAL COLLECTOR-AIR CONT SYS	21-30-00	01A	001030
MAJOR MODEL BASIC AND STABLE			201967
(PRESSURIZATION CONTROL ONLY)			
CABIN PRESSURE CONTROL SYSTEM	21-31-00		
EQUIPMENT INSTL AND WIRE BUNDLE ASSY-	21-31-00	25	001007
P6 CB PNL (CABIN PRESSURE CONTROL			
SYSTEMS ONLY)			
EQUIPMENT INSTL-E/E BAY E1 RACK	21-31-01	03	031200
			968999
EQUIPMENT INSTL-E/E BAY E2 RACK	21-31-01	02B	031200
			968999
EQUIPMENT INSTL-E/E BAY E2 RACK (AIR	21-31-01	02	001011
CONDITIONING ONLY)			201967
EQUIPMENT INSTL-E/E BAY E2 RACK (AIR	21-31-01	02A	012030
CONDITIONING ONLY)			
EQUIPMENT INSTL-ELEC/ELEX BAY E4 RACK	21-31-02	01	001011
(CABIN PRESSURE CONTROL MODULE ONLY)			201967
EQUIPMENT INSTL-E4 RACK	21-31-02	03	012030
(PRESSURIZATION CONTROL SYSTEM ONLY)			
EQUIPMENT INSTL-P6 CB PNL	21-31-00	01	008030
(PRESSURIZATION CONTROL SYSTEM ONLY)			201967
EQUIPMENT INSTL-P6 CB PNL	21-31-00	02	031200
(PRESSURIZATION CONTROL SYSTEM ONLY)			968999
MODULE INSTL-P5 OVHD (CABIN PRESSURE	21-31-02	02	001028
CONTROL MODULE ONLY)			201967
MODULE INSTL-P5 OVHD (PRESSURIZATION	21-31-02	05	031200
CONTROL SYSTEM ONLY)			968999
MODULE INSTL-P5 OVHD (PRESSURIZATION	21-31-02	08	029030
CONTROL SYSTEM ONLY)			
VALVE AND WIRE BUNDLE INSTL CAB.	21-31-03	01	
PRESSURE CONT SYS OUTFLOW			
CABIN PRESSURE RELIEF	21-32-00		
PEDESTAL INSTL-POSITIVE PRESSURE	21-32-51	02	
RELIEF VALVE			
VALVE INSTL-POSITIVE PRESSURE RELIEF	21-32-01	01	
CABIN PRESSURE INDICATION AND WARNING	21-33-00		
MODULE INSTL-P5 OVHD (CABIN ALTITUDE	21-33-02	01	001028
AND DIFFERENTIAL PRESSURE INDICATOR			201967
ONLY)			


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
MODULE INSTL-P5 OVHD (CABIN ALTITUDE AND DIFFERENTIAL PRESSURE INDICATOR ONLY)	21-33-02	02	029200 968999
MODULE INSTL-P5 OVHD (CABIN RATE OF CLIMB INDICATOR ONLY)	21-33-01	01	201967
MODULE INSTL-P5 OVHD (CABIN RATE OF CLIMB INDICATOR ONLY)	21-33-01	01B	001028
MODULE INSTL-P5 OVHD (CABIN RATE OF CLIMB INDICATOR ONLY)	21-33-01	02	031200 968999
MODULE INSTL-P5 OVHD (CABIN RATE OF CLIMB INDICATOR ONLY)	21-33-01	03	029030
PANEL INSTL-FWD (AIR CONDITIONING ONLY)	21-33-02	03	044100 102200 972999
PANEL INSTL-FWD (AIR CONDITIONING ONLY)	21-33-02	08	044100 102200 972999
SWITCH INSTL-PRESSURIZATION AIR CONDITIONING	21-33-04	01	001030 201967
SWITCH INSTL-PRESSURIZATION AIR CONDITIONING	21-33-04	01A	031046 054105 968999
SWITCH INSTL-PRESSURIZATION AIR CONDITIONING	21-33-04	03	047053 106200


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
HEATING	21-40-00		
FUNCTIONAL COLLECTOR-AIR CONT SYS	21-40-00	02	001030
FINAL ASSY MAJOR MODEL BASIC AND			201967
STABLE (HEATING ONLY)			
FUNCTIONAL COLLECTOR-AIR CONT SYS	21-40-00	02B	201967
FINAL ASSY MINOR MODEL BASIC AND			
STABLE (HEATING ONLY)			
FUNCTIONAL COLLECTOR-AIR CONT SYS	21-40-00	02C	001030
FINAL ASSY MINOR MODEL BASIC AND			
STABLE (HEATING ONLY)			
FORWARD CARGO COMPARTMENT HEATING SYSTEM	21-43-00		
JUNCTION BOX ASSY-J24 (FORWARD CARGO	21-43-51	02	001007
COMPARTMENT HEATING SYSTEM ONLY)			
JUNCTION BOX INSTL -J24 (FORWARD CARGO	21-43-51	01	005005
COMPARTMENT HEATING SYSTEM ONLY)			008999
AFT CARGO COMPARTMENT HEATING SYSTEM	21-44-00		
JUNCTION BOX INSTL-J20 (AFT CARGO	21-44-51	01	028200
COMPARTMENT HEATING SYSTEM ONLY)			968999
SUPPLEMENTAL HEATING SYSTEM	21-45-00		
DUCT INSTL AND WIRE BUNDLE ASSY-AFT	21-45-01	01	001030
DOOR HEAT			201967
DUCT INSTL-AFT DOOR AREA HEAT	21-45-01	01A	031050
			054200
			968999
DUCT INSTL-AFT DOOR AREA HEAT	21-45-01	01B	051053
HOSE ASSY-INSULATED FLEX DUCT	21-45-00	01	
MODULE ASSY-LAV A (HEATING ONLY)	21-45-51	35C	042046
			051052
MODULE ASSY-LAV A (HEATING ONLY)	21-45-51	46P	031041
			047050
			053200
			968999
SYSTEM INSTL-FWD DOOR AREA HEAT	21-45-01	02	031200
			968999
SYSTEM INSTL-FWD DOOR AREA HEAT	21-45-01	02A	001030
			201967


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
COOLING	21-50-00		
FUNCTIONAL COLLECTOR-AIR CONT SYS	21-50-00	01	001030
FINAL ASSY MAJOR MODEL BASIC AND			201967
STABLE (COOLING ONLY)			
FUNCTIONAL COLLECTOR-AIR CONT SYS	21-50-00	01B	201967
FINAL ASSY MINOR MODEL BASIC AND			
STABLE (COOLING ONLY)			
FUNCTIONAL COLLECTOR-AIR CONT SYS	21-50-00	01C	001030
FINAL ASSY MINOR MODEL BASIC AND			
STABLE (COOLING ONLY)			
PACK FLOW CONTROL AND COOLING SYSTEM	21-51-00		
DIFFUSER ASSY-SERIES 1,2,3	21-51-03	06A	001046
			054999
DUCT INST-R SIDE AIR CONDITIONING PACK	21-51-01	03	201967
(FLOW CONTROL AND SHUTOFF VALVE ONLY)			
DUCT INSTL-AIR CONDITIONING PACK	21-51-01	06	031200
			968999
DUCT INSTL-L SIDE AIR CONDITIONING	21-51-07	01	001030
PACK (CONDITIONED AIR CHECK VALVE ONLY)			
DUCT INSTL-L SIDE AIR CONDITIONING	21-51-07	03	031100
PACK (CONDITIONED AIR CHECK VALVE ONLY)			
DUCT INSTL-L SIDE AIR CONDITIONING	21-51-01	02	201967
PACK (FLOW CONTROL AND SHUTOFF VALVE			
ONLY)			
DUCT INSTL-L SIDE AIR CONDITIONING	21-51-01	04	001030
PACK (FLOW CONTROL AND SHUTOFF VALVE			
ONLY)			
DUCT INSTL-L SIDE AIR CONDITIONING	21-51-17	02	001030
PACK (HIGH PRESSURE WATER SEPARATOR			
MIX MUFF ONLY)			
DUCT INSTL-L SIDE AIR CONDITIONING	21-51-17	04	031100
PACK (HIGH PRESSURE WATER SEPARATOR			
MIX MUFF ONLY)			
DUCT INSTL-L SIDE AIR CONDITIONING	21-51-31	01	201967
PACK (LOW LIMIT (35 DEGREE F)			
CONTROLLER ONLY)			
DUCT INSTL-L SIDE AIR CONDITIONING	21-51-31	03	101200
PACK (LOW LIMIT (35 DEGREE F)			968999
CONTROLLER ONLY)			


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-L SIDE AIR CONDITIONING PACK (LOW LIMIT (35 DEGREE F) VALVE ONLY)	21-51-30	01	201967
DUCT INSTL-L SIDE AIR CONDITIONING PACK (LOW LIMIT (35 DEGREE F) VALVE ONLY)	21-51-30	03	101200 968999
DUCT INSTL-L SIDE AIR CONDITIONING PACK (LOW PRESSURE WATER SYSTEM MIX MUFF ONLY)	21-51-09	01	201967
DUCT INSTL-L SIDE AIR CONDITIONING PACK (LOW PRESSURE WATER SYSTEM MIX MUFF ONLY)	21-51-09	03	101200 968999
DUCT INSTL-L SIDE AIR CONDITIONING PACK (RAM AIR INLET CONTROLLER ONLY)	21-51-20	01	201967
DUCT INSTL-L SIDE AIR CONDITIONING PACK (RAM AIR INLET CONTROLLER ONLY)	21-51-20	03	101200 968999
DUCT INSTL-L SIDE AIR CONDITIONING PACK (REHEATER ONLY)	21-51-13	02	031046 054100
DUCT INSTL-L SIDE AIR CONDITIONING PACK (STANDBY TEMPERATURE CONTROL VALVE ONLY)	21-51-11	02	001030
DUCT INSTL-L SIDE AIR CONDITIONING PACK (STANDBY TEMPERATURE CONTROL VALVE ONLY)	21-51-11	04	031100
DUCT INSTL-L SIDE AIR CONDITIONING PACK (TEMPERATURE CONTROL VALVE ONLY)	21-51-10	01	001030
DUCT INSTL-L SIDE AIR CONDITIONING PACK (TEMPERATURE CONTROL VALVE ONLY)	21-51-10	03	031100
DUCT INSTL-L SIDE AIR CONDITIONING PACK (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	01	201967
DUCT INSTL-L SIDE AIR CONDITIONING PACK (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	03	001030
DUCT INSTL-L SIDE AIR CONDITIONING PACK (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	05	101200 968999
DUCT INSTL-L SIDE AIR CONDITIONING PACK (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	07	031100


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-L SIDE AIR CONDITIONING PACK (WATER EXTRACTOR DUCT ONLY)	21-51-15	01	001030
DUCT INSTL-L SIDE AIR CONDITIONING PACK (WATER EXTRACTOR DUCT ONLY)	21-51-15	03	031100
DUCT INSTL-LH RAM AIR INLET	21-51-24	04A	044100 102200 972999
DUCT INSTL-PACK BAY AIR SUPPLY	21-51-53	10	001030 201967
DUCT INSTL-PACK BAY AIR SUPPLY	21-51-53	11	031200 968999
DUCT INSTL-R SIDE AIR CONDITIONING PACK (CONDITIONED AIR CHECK VALVE ONLY)	21-51-07	02	001030
DUCT INSTL-R SIDE AIR CONDITIONING PACK (CONDITIONED CHECK VALVE ONLY)	21-51-07	04	031100
DUCT INSTL-R SIDE AIR CONDITIONING PACK (FLOW CONTROL AND SHUTOFF VALVE ONLY)	21-51-01	05	001030
DUCT INSTL-R SIDE AIR CONDITIONING PACK (HIGH PRESSURE WATER SEPARATOR MIX MUFF ONLY)	21-51-17	03	001030
DUCT INSTL-R SIDE AIR CONDITIONING PACK (HIGH PRESSURE WATER SEPARATOR MIX MUFF ONLY)	21-51-17	05	031100
DUCT INSTL-R SIDE AIR CONDITIONING PACK (LOW LIMIT (35 DEGREE F) CONTROLLER ONLY)	21-51-31	02	201967
DUCT INSTL-R SIDE AIR CONDITIONING PACK (LOW LIMIT (35 DEGREE F) CONTROLLER ONLY)	21-51-31	04	101200 968999
DUCT INSTL-R SIDE AIR CONDITIONING PACK (LOW LIMIT (35 DEGREE F) VALVE ONLY)	21-51-30	02	201967
DUCT INSTL-R SIDE AIR CONDITIONING PACK (LOW LIMIT (35 DEGREE F) VALVE ONLY)	21-51-30	04	101200 968999
DUCT INSTL-R SIDE AIR CONDITIONING PACK (LOW PRESSURE WATER SYSTEM MIX MUFF ONLY)	21-51-09	02	201967

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-R SIDE AIR CONDITIONING PACK (LOW PRESSURE WATER SYSTEM MIX MUFF ONLY)	21-51-09	04	101200 968999
DUCT INSTL-R SIDE AIR CONDITIONING PACK (RAM AIR INLET CONTROLLER ONLY)	21-51-20	02	201967
DUCT INSTL-R SIDE AIR CONDITIONING PACK (RAM AIR INLET CONTROLLER ONLY)	21-51-20	04	101200 968999
DUCT INSTL-R SIDE AIR CONDITIONING PACK (REHEATER ONLY)	21-51-13	03	031046 054100
DUCT INSTL-R SIDE AIR CONDITIONING PACK (STANDBY TEMPERATURE CONTROL VALVE ONLY)	21-51-11	03	001030
DUCT INSTL-R SIDE AIR CONDITIONING PACK (STANDBY TEMPERATURE CONTROL VALVE ONLY)	21-51-11	05	031100
DUCT INSTL-R SIDE AIR CONDITIONING PACK (TEMPERATURE CONTROL VALVE ONLY)	21-51-10	02	001030
DUCT INSTL-R SIDE AIR CONDITIONING PACK (TEMPERATURE CONTROL VALVE ONLY)	21-51-10	04	031100
DUCT INSTL-R SIDE AIR CONDITIONING PACK (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	02	201967
DUCT INSTL-R SIDE AIR CONDITIONING PACK (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	04	001030
DUCT INSTL-R SIDE AIR CONDITIONING PACK (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	06	101200 968999
DUCT INSTL-R SIDE AIR CONDITIONING PACK (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	08	031100
DUCT INSTL-R SIDE AIR CONDITIONING PACK (WATER EXTRACTOR DUCT ONLY)	21-51-15	02	001030
R DUCT INSTL-R SIDE AIR CONDITIONING	21-51-15	04	031046
R DUCT INSTL-R SIDE AIR CONDITIONING			054100
DUCT INSTL-RAM AIR EXH	21-51-24	01	001030 201967
DUCT INSTL-RAM AIR EXH	21-51-24	01A	031200 968999


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-RAM AIR INLET	21-51-24	04	001030 201967
DUCT INSTL-RAM AIR INLET	21-51-24	04C	031043 101101 968971
DUCT INSTL-RH RAM AIR INLET	21-51-24	04B	044100 102200 972999
EQUIPMENT INSTL-ELEC/ELEX BAY E4 RACK (AIR CONDITIONING ACCESSORY UNIT ONLY)	21-51-02	01	001011 201967
EQUIPMENT INSTL-E4 RACK (PACK FLOW CONTROL AND PACK COOLING SYSTEM ONLY)	21-51-02	02	031200 968999
EQUIPMENT INSTL-E4 RACK (PACK FLOW CONTROL AND PACK COOLING SYSTEM ONLY)	21-51-02	02A	012030
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY OPT FEATURE	21-51-00	02	001030 201967
MODULE INSTL-P5 OVHD (PACK FLOW CONTROL AND PACK COOLING SYSTEM ONLY)	21-51-00	01	001028 201967
MODULE INSTL-P5 OVHD (PACK FLOW CONTROL AND PACK COOLING SYSTEM ONLY)	21-51-65	01	101200 968999
MODULE INSTL-P5 OVHD (PACK FLOW CONTROL AND PACK COOLING SYSTEM ONLY)	21-51-65	01A	029100
PACK ASSY-PRIMARY HEAT EXCHANGER	21-51-03	06	
PACK ASSY-SECONDARY HEAT EXCHANGER UNIT (AIR CYCLE MACHINE ONLY)	21-51-04	01	001046 054999
PACK ASSY-SECONDARY HEAT EXCHANGER UNIT (COMPRESSOR DISCHARGE OVERHEAT SWITCH ONLY)	21-51-40	01	001047 054999
PACK ASSY-SECONDARY HEAT EXCHANGER UNIT (HEAT EXCHANGER AND PLENUM/ DIFFUSER ASSY ONLY)	21-51-03	05	101999
PACK ASSY-SECONDARY HEAT EXCHANGER UNIT (HEAT EXCHANGER AND PLENUM/ DIFFUSER ASSY ONLY)	21-51-03	05A	001046 054100
PACK INSTL-AIR CONDITIONING (HEAT EXCHANGER AND PLENUM/DIFFUSER ASSY ONLY)	21-51-03	01	101999
PACK INSTL-AIR CONDITIONING (HEAT EXCHANGER AND PLENUM/DIFFUSER ASSY ONLY)(-800,-900)	21-51-03	01A	001100



BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
PACK INSTL-AIR CONDITIONING (PACK TEMPERATURE SENSOR ONLY)	21-51-52	01	101999
PACK INSTL-AIR CONDITIONING (PACK TEMPERATURE SENSOR ONLY)	21-51-52	02	001100
PANEL INSTL-RAM AIR INLET (RAM AIR INLET ACTUATOR ONLY)	21-51-21	01	031200 968999
PANEL INSTL-RAM AIR INLET (RAM AIR INLET ACTUATOR ONLY)	21-51-21	01A	001030 201967
PANEL INSTL-RAM AIR INLET (RAM AIR INLET MODULATION PANEL ONLY)	21-51-23	01	031200 968999
PANEL INSTL-RAM AIR INLET (RAM AIR INLET MODULATION PANEL ONLY)	21-51-23	01A	001030 201967
SENSE LINE INSTL-L SIDE AIR CONDITIONING PACK	21-51-53	02	101999
SENSE LINE INSTL-L SIDE AIR CONDITIONING PACK	21-51-53	04	031046 054100
SENSE LINE INSTL-L SIDE AIR CONDITIONING PACK	21-51-53	04A	047053
SENSE LINE INSTL-L SIDE AIR CONDITIONING PACK	21-51-53	18	001030
SENSE LINE INSTL-R SIDE AIR CONDITIONING PACK	21-51-53	03	101999
SENSE LINE INSTL-R SIDE AIR CONDITIONING PACK	21-51-53	05	031100
SENSE LINE INSTL-R SIDE AIR CONDITIONING PACK	21-51-53	19	001030
SEPARATOR AND PACK INSTL-AIR CONDITIONING (REHEATER ONLY)	21-51-13	01	001046 054100
SEPARATOR ASSY-AIR COND	21-51-05	02	101105 201999
SEPARATOR ASSY-HIGH PRESSURE WATER (PACK TEMPERATURE BULB ONLY)	21-51-60	02	047053
SEPARATOR ASSY-HIGH PRESSURE WATER (PACK TEMPERATURE SENSOR ONLY)	21-51-52	04	047053
SEPARATOR ASSY-HIGH PRESSURE WATER (TURBINE INLET OVERHEAT SWITCH ONLY)	21-51-41	09	047053
SEPARATOR ASSY-WATER AIR CONDITIONING (LOW LIMIT TEMPERATURE (35 DEGREE F) SENSOR ONLY)	21-51-32	02	106200


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
SEPARATOR ASSY-WATER AIR CONDITIONING (WATER SEPARATOR AND COALESCER (BAG) ONLY)	21-51-05	03	106200
SEPARATOR ASSY-WATER SPRAY AIR CYCLE SYS (CONDENSER ONLY)	21-51-12	02	047053
SEPARATOR ASSY-WATER SPRAY AIR CYCLE SYS (REHEATER ONLY)	21-51-13	04	047053
SEPARATOR ASSY-WATER SPRAY AIR CYCLE SYS (WATER EXTRACTOR ONLY)	21-51-14	01	047053
SEPARATOR INSTL -AIR CONDITIONING WATER (PACK TEMPERATURE BULB ONLY)	21-51-60	01	001047 054100
R SEPARATOR INSTL -AIR CONDITIONING	21-51-52	03	001046
R WATER (PACK TEMPERATURE SENSOR ONLY)			054100
SEPARATOR INSTL-AIR CONDITIONING WATER (CONDENSER ONLY)	21-51-12	01	001046 054100
SEPARATOR INSTL-AIR CONDITIONING WATER (LOW LIMIT TEMPERATURE (35 DEGREE F) SENSOR ONLY)	21-51-32	01	101105 201999
SEPARATOR INSTL-AIR CONDITIONING WATER (WATER EXTRACTOR ONLY)	21-51-14	02	001046 054100
SEPARATOR INSTL-AIR CONDITIONING WATER (WATER SEPARATOR AND COALESCER (BAG) ONLY)	21-51-05	01	101106 201999
SEPARATOR INSTL-LH WATER AIR CONDITIONING	21-51-17	01	047053
SEPARATOR INSTL-RH WATER AIR CONDITIONING	21-51-17	06	047053
SEPARATOR INSTL-WATER AIR CONDITIONING	21-51-09	05	106200
SYSTEM INSTL-AIR DISTR MIX BAY (MIX MANIFOLD TEMPERATURE SENSOR ONLY)	21-51-51	02	001100
SYSTEM INSTL-AIR DISTR MIX BAY (PACK DISCHARGE OVERHEAT SWITCH ONLY)	21-51-42	01	001100
VALVE ASSY-PACK FLOW AND SHUTOFF AIR CONDITIONING PACK	21-51-01	51	001100


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
TEMPERATURE CONTROL	21-60-00		
EQUIPMENT INSTL-E3-3 SHELF	21-60-51	01	012100
FUNCTIONAL COLLECTOR MINOR MODEL BASIC AND STABLE E/E EQPT INSTL (TEMPERATURE CONTROLS ONLY)	21-60-00	03	001030
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY BASIC AND STABLE (TEMPERATURE CONTROL ONLY)	21-60-00	01B	201967
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY BASIC AND STABLE (TEMPERATURE CONTROL ONLY)	21-60-00	01C	001030
FUNCTIONAL COLLECTOR-AIR CONT SYS FINAL ASSY BASIC AND STABLE (TEMPERATURE CONTROL ONLY)	21-60-00	01E	001030 201967
ZONE TEMP. CONTROL AND INDICATION	21-61-00		
COMPARTMENT ASSY-60 IN. OVHD STOWAGE BULLNOSE CONFIG (CABIN TEMPERATURE SENSOR ASSEMBLY FILTER ONLY)	21-61-06	04	201967
COMPARTMENT ASSY-60 IN. OVHD STOWAGE BULLNOSE CONFIGURATION (CABIN TEMPERATURE SENSOR ONLY)	21-61-10	08	201967
COMPARTMENT ASSY-60 IN. OVHD STOWAGE BULLNOSE CONFIGURATION (ZONE TEMPERATURE SENSOR FAN ONLY)	21-61-11	11	201967
COMPARTMENT ASSY-60 IN. OVHD STOWAGE HNDRL CONFIGURATION (AIR FILTER ONLY)	21-61-06	05	001030
COMPARTMENT ASSY-60 IN. OVHD STOWAGE HNDRL CONFIGURATION (CABIN TEMPERATURE SENSOR ONLY)	21-61-10	11	001030
COMPARTMENT ASSY-60 IN. OVHD STOWAGE HNDRL CONFIGURATION (ZONE TEMPERATURE SENSOR FAN ONLY)	21-61-11	12	001030
COMPARTMENT ASSY-80 IN. OVHD STOWAGE (CABIN TEMPERATURE SENSOR ONLY)	21-61-10	05	001030
COMPARTMENT ASSY-80 IN. OVHD STOWAGE HNDRL CONFIG (CABIN TEMPERATURE SENSOR ASSEMBLY FILTER ONLY)	21-61-06	06	001030
COMPARTMENT ASSY-80 IN. OVHD STOWAGE HNDRL CONFIGURATION (ZONE TEMPERATURE SENSOR FAN ONLY)	21-61-11	17	001030


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-AFT E/E BAY FLIGHT DECK AIR DISTR (DUCT OVERHEAT SWITCH ONLY)	21-61-05	04	001011
DUCT INSTL-AFT E/E BAY FLIGHT DECK AIR DISTR (DUCT TEMPERATURE BULB ONLY)	21-61-30	02	001011
DUCT INSTL-AFT E/E BAY FLIGHT DECK AIR DISTR (DUCT TEMPERATURE LIMIT SENSOR ONLY)	21-61-04	02	001011
DUCT INSTL-AIR CONDITIONING PACK TRIM AIR (TRIM AIR CHECK VALVE ONLY)	21-61-09	01	001030
DUCT INSTL-AIR CONDITIONING PACK TRIM AIR (TRIM AIR CHECK VALVE ONLY)	21-61-09	02	031100
DUCT INSTL-AIR CONDITIONING PACK TRIM AIR (ZONE TRIM AIR MODULATING VALVE ONLY)	21-61-21	01	001030
DUCT INSTL-AIR CONDITIONING PACK TRIM AIR (ZONE TRIM AIR MODULATING VALVE ONLY)	21-61-21	02	031100
DUCT INSTL-AIR DISTR MIX BAY SYS BASELINE CONFIGURATION FOR 737-700 (HOT AIR CHECK VALVE ONLY)	21-61-03	03	101999
DUCT INSTL-L SIDE AIR CONDITIONING PACK (ZONE TEMPERATURE CONTROL AND INDICATION ONLY)	21-61-02	01	201967
DUCT INSTL-L SIDE AIR CONDITIONING PACK (ZONE TEMPERATURE CONTROL AND INDICATION ONLY)	21-61-02	03	101200 968999
DUCT INSTL-MID OVHD AIR DISTR SYS (CABIN TEMPERATURE BULB ONLY)	21-61-31	01A	001011
DUCT INSTL-MID OVHD AIR DISTR SYS (CABIN TEMPERATURE SENSOR ONLY)	21-61-10	01B	001011
DUCT INSTL-MID OVHD AIR DISTR SYS (DUCT OVERHEAT SWITCH ONLY)	21-61-05	01B	001011
DUCT INSTL-OVHD AIR DISTR SYS (DUCT OVERHEAT SWITCH ONLY)	21-61-05	05	001100
DUCT INSTL-OVHD AIR DISTR SYS (DUCT OVERHEAT SWITCH ONLY)	21-61-05	20	101200 968999
DUCT INSTL-OVHD AIR DISTR SYS (DUCT OVERHEAT SWITCH ONLY)	21-61-05	22	012100
DUCT INSTL-OVHD AIR DISTR SYS (DUCT TEMPERATURE ANTICIPATOR SENSOR ONLY)	21-61-08	20	101200 968999


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DUCT INSTL-OVHD AIR DISTR SYS (DUCT TEMPERATURE BULB ONLY)	21-61-30	05	001100
DUCT INSTL-OVHD AIR DISTR SYS (DUCT TEMPERATURE BULB ONLY)	21-61-30	20	101200 968999
DUCT INSTL-OVHD AIR DISTR SYS (DUCT TEMPERATURE BULB ONLY)	21-61-30	22	012100
DUCT INSTL-OVHD AIR DISTR SYS (DUCT TEMPERATURE LIMIT SENSOR ONLY)	21-61-04	05	001100
DUCT INSTL-OVHD AIR DISTR SYS (DUCT TEMPERATURE LIMIT SENSOR ONLY)	21-61-04	20	101200 968999
DUCT INSTL-OVHD AIR DISTR SYS (DUCT TEMPERATURE LIMIT SENSOR ONLY)	21-61-04	22	012100
DUCT INSTL-R SIDE AIR CONDITIONING PACK (ZONE TEMPERATURE CONTROL AND INDICATION ONLY)	21-61-02	02	201967
DUCT INSTL-R SIDE AIR CONDITIONING PACK (ZONE TEMPERATURE CONTROL AND INDICATION ONLY)	21-61-02	04	101200 968999
EQUIPMENT INSTL-ELEC/ELEX BAY E3 RACK	21-61-20	01	001011
EQUIPMENT INSTL-ELEC/ELEX BAY E4 RACK (CABIN TEMPERATURE MODULE PRINTED CIRCUIT ASSEMBLY ONLY)	21-61-35	01	201967
EQUIPMENT INSTL-E4 RACK (ZONE TEMPERATURE CONTROL INDICATION ONLY)	21-61-11	01	101200 968999
FAN ASSY-VANEAXIAL	21-61-05	02	031200 968999
FAN ASSY-VANEAXIAL	21-61-05	08	001030 201967
INDICATOR INSTL-P5 OVHD CAB. TEMP (AIR CONDITIONING ONLY)	21-61-32	10	101200 968999
INDICATOR INSTL-P5 OVHD CAB. TEMP F (AIR CONDITIONING ONLY)	21-61-32	10A	029100
LINING ASSY-AFT CLG (AIR CONDITIONING ONLY)	21-61-51	02	031200 968999
LINING ASSY-AFT CLG (AIR CONDITIONING ONLY)	21-61-51	05	001030 201967
MODULE INSTL-P5 OVHD (AIR MIX VALVE POSITION INDICATOR ONLY)	21-61-33	01	101200 968999
MODULE INSTL-P5 OVHD (CABIN TEMPERATURE INDICATOR ONLY)	21-61-32	01	001028 201967

 **BOEING**
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
MODULE INSTL-P5 OVHD (CABIN TEMPERATURE SELECTOR ONLY)	21-61-07	01	201967
MODULE INSTL-P5 OVHD (DUCT OVERHEAT SWITCH ONLY)	21-61-05	03	201967
MODULE INSTL-P5 OVHD (DUCT OVERHEAT SWITCH ONLY)	21-61-05	07	101200 968999
MODULE INSTL-P5 OVHD (PACK/ZONE TEMPERATURE CONTROLLER ONLY)	21-61-20	02	001028
MODULE INSTL-P5 OVHD (PACK/ZONE TEMPERATURE CONTROLLER ONLY)	21-61-20	03	029100
MODULE INSTL-P5 OVHD (ZONE TEMPERATURE CONTROL AND INDICATING ONLY)	21-61-00	01	001028 201967
MODULE INSTL-P5 OVHD (ZONE TEMPERATURE CONTROL AND INDICATION ONLY)	21-61-00	02	201967
MODULE INSTL-P5 OVHD (ZONE TEMPERATURE CONTROL AND INDICATION ONLY)	21-61-52	01	029200 968999
MODULE INSTL-P5 OVHD 600/700 MINOR MODEL (CABIN TEMPERATURE SELECTOR ONLY)	21-61-07	02	101200 968999
MODULE INSTL-P5 OVHD 800/900 MINOR MODEL (CABIN TEMPERATURE SELECTOR ONLY)	21-61-07	03	029100
TOP ASSY-FWD RH 60 IN. OVHD STOWAGE BIG BIN (CABIN TEMPERATURE SENSOR ASSEMBLY FILTER ONLY)	21-61-06	09	031200 968999
TOP ASSY-FWD RH 60 IN. OVHD STOWAGE BIG BIN BULLNOSE CONFIG (ZONE TEMPERATURE SENSOR FAN ONLY)	21-61-11	19	031200 968999
TOP ASSY-FWD RH 60 IN. OVHD STOWAGE BIG BIN BULLNOSE CONFIGURATION (CABIN TEMPERATURE SENSOR ONLY)	21-61-10	13	031200 968999
TOP ASSY-RH 80 IN. BIG BIN OVHD STOWAGE BULLNOSE CONFIGURATION (CABIN TEMPERATURE SENSOR ONLY)	21-61-10	14	031100
TOP ASSY-RH 80 IN. BIG BIN OVHD STOWAGE BULLNOSE CONFIGURATION (ZONE TEMPERATURE SENSOR FAN ONLY)	21-61-11	20	031100
TOP ASSY-80 IN. BIG BIN OVHD STOWAGE BULLNOSE CONFIG (CABIN TEMPERATURE SENSOR ASSEMBLY FILTER ONLY)	21-61-06	11	031100


BOEING
 737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

CHAPTER 21 — AIR CONDITIONING

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
TRIM AIR PRESSURE REGULATION AND SHUTOFF CONTROL	21-62-00		
DUCT INSTL-AIR CONDITIONING PACK TRIM AIR (TRIM AIR PRESSURE REGULATING AND SHUTOFF VALVE ONLY)	21-62-01	01	001030
DUCT INSTL-AIR CONDITIONING PACK TRIM AIR (TRIM AIR PRESSURE REGULATING AND SHUTOFF VALVE ONLY)	21-62-01	03	031100
MODULE INSTL-P5 OVHD (TRIM AIR PRESSURE REGULATING AND SHUTOFF VALVE ONLY)	21-62-01	02	001028
MODULE INSTL-P5 OVHD (TRIM AIR PRESSURE REGULATION AND SHUTOFF CONTROL ONLY)	21-62-51	01	029100