

 **BOEING**  
737-600/700/800/900  
**PARTS CATALOG (MAINTENANCE)**

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*22	1	JUN 15/09	22-11-27- 1	7	JUN 15/08
*22	2	JUN 15/09	22-11-29- 1	0	OCT 10/06
*22	3	JUN 15/09	22-11-29- 1	0A	OCT 10/06
*22	4	JUN 15/09	22-11-29- 1	0B	OCT 10/06
22-11-00	1	OCT 10/06	22-11-29- 1	1	FEB 15/09
*22-11-11- 1	0	JUN 15/09	22-11-29- 1	2	FEB 15/09
*22-11-11- 1	1	JUN 15/09	22-11-29- 1	3	FEB 15/09
22-11-11- 1	2	FEB 15/09	22-11-29- 1	4	OCT 10/07
22-11-24- 1	0	OCT 10/06	*22-11-29- 1	5	JUN 15/09
22-11-24- 1	0A	OCT 10/06	*22-11-29- 1	6	JUN 15/09
22-11-24- 1	0B	OCT 10/06	*22-11-29- 1	7	JUN 15/09
22-11-24- 1	1	FEB 15/09	*22-11-29- 1	8	JUN 15/09
*22-11-24- 1	2	JUN 15/09	*22-11-29- 1	9	JUN 15/09
*22-11-24- 1	3	JUN 15/09	*22-11-31- 1	0	JUN 15/09
*22-11-24- 1	4	JUN 15/09	22-11-31- 1	1	FEB 15/09
22-11-25- 1	0	OCT 10/06	*22-11-31- 1	2	JUN 15/09
22-11-25- 1	0A	OCT 10/06	22-11-31- 1	3	OCT 15/08
22-11-25- 1	0B	OCT 10/06	*22-11-31- 1	4	JUN 15/09
22-11-25- 1	0C	OCT 10/06	22-11-31- 1	5	OCT 15/08
22-11-25- 1	1	FEB 15/09	*22-11-32- 1	0	JUN 15/09
22-11-25- 1	2	FEB 15/09	22-11-32- 1	0A	OCT 10/07
22-11-25- 1	3	FEB 15/09	22-11-32- 1	1	OCT 15/08
22-11-25- 1	4	FEB 15/09	22-11-32- 1	2	OCT 15/08
22-11-25- 1	5	FEB 15/09	22-11-32- 1	3	OCT 15/08
22-11-25- 1	6	FEB 15/09	22-11-32- 1	4	OCT 15/08
22-11-25- 1	7	FEB 15/09	22-11-32- 2	0	FEB 15/09
22-11-25- 1	8	FEB 15/09	22-11-32- 2	0A	OCT 15/08
22-11-25- 1	9	FEB 15/09	22-11-32- 2	1	OCT 15/08
22-11-25- 1	10	FEB 15/09	22-11-32- 2	2	FEB 15/09
22-11-25- 1	11	FEB 15/09	22-11-32- 8	0	OCT 15/08
22-11-26- 1	0	OCT 15/08	22-11-32- 8	0A	OCT 15/08
22-11-26- 1	0A	OCT 10/06	22-11-32- 8	1	FEB 15/09
22-11-26- 1	0B	OCT 10/06	*22-11-32- 8	2	JUN 15/09
22-11-26- 1	1	FEB 15/09	22-11-32-11	0	OCT 15/08
22-11-26- 1	2	FEB 15/09	22-11-32-11	0A	OCT 15/08
22-11-26- 1	3	FEB 15/09	22-11-32-11	0B	OCT 15/08
22-11-26- 1	4	FEB 15/09	22-11-32-11	0C	OCT 15/08
22-11-26- 1	5	FEB 15/09	22-11-32-11	0D	OCT 15/08
22-11-26- 1	6	FEB 15/09	22-11-32-11	0E	OCT 15/08
22-11-26- 1	7	FEB 15/09	22-11-32-11	0F	OCT 15/08
22-11-26- 1	8	FEB 15/09	22-11-32-11	1	FEB 15/09
22-11-27- 1	0	OCT 10/06	*22-11-32-11	2	JUN 15/09
22-11-27- 1	0A	OCT 10/06	22-11-32-16	0	OCT 15/08
22-11-27- 1	0B	OCT 10/06	22-11-32-16	0A	OCT 15/08
22-11-27- 1	0C	OCT 10/06	22-11-32-16	0B	OCT 15/08
22-11-27- 1	1	OCT 15/08	22-11-32-16	0C	OCT 15/08
22-11-27- 1	2	OCT 15/08	22-11-32-16	0D	OCT 15/08
22-11-27- 1	3	FEB 15/09	22-11-32-16	1	FEB 15/09
22-11-27- 1	4	JUN 15/08	22-11-32-16	2	FEB 15/09
22-11-27- 1	5	FEB 15/09	22-11-32-16	3	FEB 15/09
22-11-27- 1	6	FEB 15/09	22-11-32-16	4	FEB 15/09

\* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP  
JUN 15/09

22 - LIST OF EFFECTIVE PAGES  
PAGE 1


**BOEING**  
 737-600/700/800/900  
**PARTS CATALOG (MAINTENANCE)**

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
22-11-32-16	5	FEB 15/09	22-11-37- 1	0E	FEB 15/08
22-11-33- 1	0	FEB 15/08	22-11-37- 1	1	FEB 15/09
*22-11-33- 1	1	JUN 15/09	22-11-37- 1	2	FEB 15/09
*22-11-33- 1	2	JUN 15/09	22-11-37- 1	3	FEB 15/09
*22-11-33- 1	3	JUN 15/09	22-11-37- 1	4	FEB 15/09
*22-11-33- 1	4	JUN 15/09	22-11-37- 1	5	FEB 15/09
*22-11-33- 1	5	JUN 15/09	22-11-37- 1	6	FEB 15/09
*22-11-33- 1	6	JUN 15/09	22-11-37- 1	7	FEB 15/09
*22-11-33- 1	7	JUN 15/09	22-11-37- 1	8	FEB 15/09
22-11-33- 2	0	FEB 15/08	22-11-37- 1	9	FEB 15/09
22-11-33- 2	0A	FEB 15/08	22-11-37- 1	10	FEB 15/09
22-11-33- 2	1	FEB 15/08	22-11-37- 1	11	FEB 15/09
22-11-33- 2	2	OCT 15/08	22-11-37- 2	0	JUN 15/08
22-11-33- 2	3	OCT 15/08	22-11-37- 2	0A	JUN 15/08
22-11-33- 2	4	JUN 15/08	22-11-37- 2	0B	JUN 15/08
22-11-33- 2	5	FEB 15/09	22-11-37- 2	0C	JUN 15/08
22-11-33- 2A	0	FEB 15/08	22-11-37- 2	0D	JUN 15/08
22-11-33- 2A	1	JUN 15/08	22-11-37- 2	1	FEB 15/09
22-11-33- 3	0	FEB 15/08	22-11-37- 2	2	FEB 15/09
22-11-33- 3	0A	FEB 15/08	22-11-37- 2	3	FEB 15/09
22-11-33- 3	1	FEB 15/09	22-11-37- 2	4	FEB 15/09
22-11-33- 3	2	FEB 15/09	22-11-37- 2	5	FEB 15/09
22-11-33- 3	3	FEB 15/09	22-11-37- 2	6	FEB 15/09
22-11-33- 3	4	FEB 15/09	22-11-37- 2	7	FEB 15/09
22-11-33- 3	5	FEB 15/09	22-11-37- 2	8	FEB 15/09
22-11-33- 3A	0	FEB 15/08	22-11-37- 2	9	FEB 15/09
22-11-33- 3A	1	OCT 15/08	22-11-37- 2	10	FEB 15/09
*22-11-33- 3A	2	JUN 15/09	22-11-39- 1	0	OCT 10/06
22-11-34- 1	0	FEB 10/07	*22-11-39- 1	1	JUN 15/09
22-11-34- 1	0A	FEB 10/07	*22-11-39- 1	2	JUN 15/09
22-11-34- 1	0B	OCT 10/07	*22-11-39- 1	3	JUN 15/09
22-11-34- 1	1	OCT 15/08	22-11-40- 1	0	OCT 10/06
*22-11-34- 1	2	JUN 15/09	22-11-40- 1	1	FEB 15/09
22-11-34- 1	3	FEB 15/09	22-11-40- 1	2	FEB 15/09
22-11-34- 1	4	FEB 15/09	22-11-40- 1	3	FEB 15/09
22-11-34- 1	5	FEB 15/09	22-11-40- 2	0	OCT 10/06
22-11-34- 1	6	FEB 15/09	22-11-40- 2	1	OCT 10/06
22-11-34- 1	7	FEB 15/09	22-11-40- 2	2	FEB 15/09
22-11-34- 1	8	OCT 15/08	22-11-40- 2	3	FEB 15/09
22-11-34- 2	0	OCT 10/06	22-11-40- 2	4	FEB 15/09
22-11-34- 2	0A	JUN 15/08	22-11-41- 1	0	OCT 10/06
22-11-34- 2	1	OCT 15/08	22-11-41- 1	1	FEB 15/09
22-11-34- 2	2	OCT 15/08	22-11-41- 1	2	FEB 15/09
22-11-34- 2	3	OCT 15/08	22-11-41- 1	3	FEB 15/09
22-11-34- 2	4	OCT 15/08	*22-11-92- 1	0	JUN 15/09
22-11-34- 2	5	OCT 15/08	*22-11-92- 1	1	JUN 15/09
22-11-37- 1	0	FEB 15/08	22-11-92- 1	2	OCT 15/08
22-11-37- 1	0A	FEB 15/08	22-11-92- 1	3	FEB 15/09
22-11-37- 1	0B	FEB 15/08	22-23-00	1	OCT 10/06
22-11-37- 1	0C	OCT 10/06	22-23-00- 1	0	OCT 15/08
22-11-37- 1	0D	FEB 15/08	22-23-00- 1	1	OCT 15/08

\* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP  
JUN 15/09

22 - LIST OF EFFECTIVE PAGES  
PAGE 2



**BOEING**  
737-600/700/800/900  
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
22-23-00- 1B	0	FEB 15/09	22-31-51- 2	0A	OCT 10/06
22-23-00- 1B	1	OCT 10/06	22-31-51- 2	0B	OCT 10/06
22-23-00- 1B	2	FEB 15/09	22-31-51- 2	0C	OCT 10/06
*22-23-00- 2	0	JUN 15/09	22-31-51- 2	0D	OCT 15/08
*22-23-00- 2	1	JUN 15/09	*22-31-51- 2	1	JUN 15/09
22-23-00- 2	2	OCT 15/08	*22-31-51- 2	2	JUN 15/09
22-23-00- 3	0	OCT 10/06	*22-31-51- 2	3	JUN 15/09
22-23-00- 3	1	FEB 15/09	*22-31-51- 2	4	JUN 15/09
22-23-00- 3	2	FEB 15/09	*22-31-51- 2	5	JUN 15/09
22-23-51- 1	0	OCT 10/06	*22-31-51- 2	6	JUN 15/09
22-23-51- 1	1	OCT 15/08	22-31-51- 3	0	OCT 10/06
*22-23-51- 1	2	JUN 15/09	*22-31-51- 3	1	JUN 15/09
22-23-51- 1	3	OCT 15/08	*22-31-51- 3	2	JUN 15/09
*22-23-51- 2	0	JUN 15/09	22-31-51- 3	3	OCT 10/06
*22-23-51- 2	1	JUN 15/09	22-31-81- 1	0	OCT 10/06
22-31-00	1	OCT 10/06	22-31-81- 1	0A	OCT 10/06
22-31-00- 1	0	OCT 10/06	22-31-81- 1	0B	OCT 10/06
22-31-00- 1	1	FEB 15/09	*22-31-81- 1	1	JUN 15/09
*22-31-00- 1	2	JUN 15/09	*22-31-81- 1	2	JUN 15/09
22-31-10- 1	0	OCT 10/06	*22-31-81- 1	3	JUN 15/09
22-31-10- 1	0A	OCT 10/06	*22-31-81- 1	4	JUN 15/09
22-31-10- 1	1	FEB 15/09	*22-31-81- 1	5	JUN 15/09
22-31-10- 1	2	FEB 15/09	*22-31-81- 1	6	JUN 15/09
22-31-10- 1	3	FEB 15/09	*22-31-81- 1	7	JUN 15/09
22-31-10- 1	4	FEB 15/09	22-31-81- 2	0	OCT 10/06
22-31-10- 1	5	FEB 15/09	22-31-81- 2	0A	OCT 10/06
*22-31-10- 1	6	JUN 15/09	22-31-81- 2	0B	OCT 10/06
22-31-10- 1	7	FEB 15/09	*22-31-81- 2	1	JUN 15/09
22-31-10- 1	8	FEB 15/09	*22-31-81- 2	2	JUN 15/09
*22-31-51- 1	0	JUN 15/09	*22-31-81- 2	3	JUN 15/09
22-31-51- 1	0A	OCT 15/08	*22-31-81- 2	4	JUN 15/09
*22-31-51- 1	0B	JUN 15/09	*22-31-81- 2	5	JUN 15/09
*22-31-51- 1	0C	JUN 15/09	*22-31-81- 2	6	JUN 15/09
*22-31-51- 1	0D	JUN 15/09	*22-31-81- 2	7	JUN 15/09
*22-31-51- 1	1	JUN 15/09	*22-31-81- 2	8	JUN 15/09
*22-31-51- 1	2	JUN 15/09	*22-31-91- 1	0	JUN 15/09
*22-31-51- 1	3	JUN 15/09	*22-31-91- 1	1	JUN 15/09
*22-31-51- 1	4	JUN 15/09	*22-31-91- 1	2	JUN 15/09
*22-31-51- 1	5	JUN 15/09	*22-31-91- 1	3	JUN 15/09
*22-31-51- 1	6	JUN 15/09	22-31-91- 2	0	OCT 10/06
*22-31-51- 1	7	JUN 15/09	22-31-91- 2	0A	OCT 10/06
*22-31-51- 1	8	JUN 15/09	22-31-91- 2	0B	OCT 10/06
*22-31-51- 1	9	JUN 15/09	*22-31-91- 2	1	JUN 15/09
*22-31-51- 1	10	JUN 15/09	*22-31-91- 2	2	JUN 15/09
*22-31-51- 1	11	JUN 15/09	*22-31-91- 2	3	JUN 15/09
*22-31-51- 1	12	JUN 15/09	*22-31-91- 2	4	JUN 15/09
*22-31-51- 1	13	JUN 15/09	*22-31-91- 2	5	JUN 15/09
*22-31-51- 1	14	JUN 15/09			
*22-31-51- 1	15	JUN 15/09			
*22-31-51- 1	16	JUN 15/09			
22-31-51- 2	0	OCT 10/06			

\* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HAP  
JUN 15/09

22 - LIST OF EFFECTIVE PAGES  
PAGE 3


**BOEING**  
 737-600/700/800/900  
**PARTS CATALOG (MAINTENANCE)**

**CHAPTER 22 — AUTOFLIGHT**

**TABLE OF CONTENTS**

SUBJECT	CC-SS-UU	FIGURE	EFFECT
DIGITAL FLIGHT CONTROL SYSTEM	22-11-00		
ACTUATOR ASSY-AIL. CONT AUTOPILOT (HYDRAULIC PRESSURE SWITCH ONLY)	22-11-40	01	
ACTUATOR ASSY-AUTOPILOT (HYDRAULIC PRESSURE SWITCH ONLY)	22-11-40	02	
ACTUATOR INSTL-AIL. CONT AUTOPILOT	22-11-25	01	
ACTUATOR INSTL-AUTOPILOT	22-11-26	01	
CONTROL INSTL-FEEL AND CENTERING (DIGITAL FLIGHT CONTROL SYSTEM ONLY)	22-11-31	01	
CONTROL INSTL-FEEL AND CENTERING ELEV (MACH TRIM ACTUATOR ONLY)	22-11-24	01	
DRUM MECHANISM ASSY-AIL. CONT (AUTOFLIGHT ONLY)	22-11-11	01	
EQUIPMENT AND SOFTWARE INSTL-E/E BAY E1 RACK (FLIGHT CONTROL COMPUTER ONLY)	22-11-33	01	001011 201967
EQUIPMENT INSTL-E/E BAY E1 RACK (INTEGRATED FLIGHT INSTRUMENT ACCESSORY UNIT ONLY)	22-11-37	01	001047 054106 201999
EQUIPMENT INSTL-E1 RACK E/E BAY (FLIGHT CONTROL COMPUTER ONLY)	22-11-33	02	012030
EQUIPMENT INSTL-E1 RACK E/E BAY (FLIGHT CONTROL COMPUTER ONLY)	22-11-33	03	031200 968999
EQUIPMENT INSTL-E1-1 RACK E/E BAY (INTEGRATED FLIGHT INSTRUMENT ACCESSORY UNIT ONLY)	22-11-37	02	048053 107200
R LEVER ASSY-CONT STAND THRUST (DIGITAL R FLIGHT CONTROL SYSTEM ONLY)	22-11-39	01	
PANEL INSTL-FWD (AUTOFLIGHT ONLY)	22-11-32	02	031200 968999
PANEL INSTL-FWD (AUTOFLIGHT ONLY)	22-11-32	08	031043 101101 968971
PANEL INSTL-FWD (AUTOFLIGHT ONLY)	22-11-32	11	044100 102200 972999
PANEL INSTL-FWD (AUTOFLIGHT ONLY)	22-11-32	16	044100 102200 972999
PANEL INSTL-FWD (DIGITAL FLIGHT CONTROL SYSTEM ONLY)	22-11-32	01	001030 201967


**BOEING**  
 737-600/700/800/900  
**PARTS CATALOG (MAINTENANCE)**

**CHAPTER 22 — AUTOFLIGHT**

**TABLE OF CONTENTS**

SUBJECT	CC-SS-UU	FIGURE	EFFECT
PANEL INSTL-PILOTS GLARESHIELD (DFCS MODE CONTROL PANEL ONLY)	22-11-34	01	001030 201967
PANEL INSTL-PILOTS GLARESHIELD (DFCS MODE CONTROL PANEL ONLY)	22-11-34	02	031200 968999
QUADRANT INSTL-(AUTO FLIGHT ONLY)	22-11-92	01	
SENSOR INSTL-AIL. CONT POSITION	22-11-29	01	
SOFTWARE INSTL	22-11-33	02A	012030
SOFTWARE INSTL	22-11-33	03A	031200 968999
TRANSMITTER INSTL-FLIGHT SPOILER (AUTOFLIGHT ONLY)	22-11-27	01	
WHEEL ASSY-CONT COLUMN (AUTOFLIGHT ONLY)	22-11-41	01	


**BOEING**  
 737-600/700/800/900  
**PARTS CATALOG (MAINTENANCE)**

**CHAPTER 22 — AUTOFLIGHT**

**TABLE OF CONTENTS**

SUBJECT	CC-SS-UU	FIGURE	EFFECT
YAW DAMPER SYSTEM	22-23-00		
MODULE INSTL-INSTR SWITCHING PNL	22-23-51	01	031200
P5-28/ FLIGHT CONT P5-3 (AUTOFLIGHT ONLY)			968999
MODULE INSTL-INSTR SWITCHING PNL	22-23-51	02	029030
P5-28/ FLIGHT CONT P5-3 (AUTOFLIGHT ONLY)			
MODULE INSTL-P5 OVHD (YAW DAMPER SYSTEM ONLY)	22-23-00	02	001028 201967
PANEL INSTL-FWD (AUTOFLIGHT ONLY)	22-23-00	03	031200 968999
PANEL INSTL-FWD (YAW DAMPER SYSTEM ONLY)	22-23-00	01	201967
PANEL INSTL-FWD (YAW DAMPER SYSTEM ONLY)	22-23-00	01B	001030


**BOEING**  
 737-600/700/800/900  
**PARTS CATALOG (MAINTENANCE)**

**CHAPTER 22 — AUTOFLIGHT**

**TABLE OF CONTENTS**

SUBJECT	CC-SS-UU	FIGURE	EFFECT
AUTOTHROTTLE SYSTEM	22-31-00		
AUTOTHROTTLE ASSY	22-31-91	01	
AUTOTHROTTLE ASSY (AUTOTHROTTLE DISENGAGED SWITCH ONLY)	22-31-51	01	
AUTOTHROTTLE INSTL	22-31-00	01	
EQUIPMENT INSTL-E/E BAY E1 RACK (AUTOTHROTTLE SYSTEM ONLY)	22-31-10	01	001030 201967
R     GEARBOX ASSY-AUTOTHROTTLE	22-31-91	02	
LEVER ASSY-CONT STAND THRUST (AUTOTHROTTLE ONLY)	22-31-51	03	
R     MECHANISM ASSY-AUTOTHROTTLE LEFT	22-31-81	01	
R     MECHANISM ASSY-AUTOTHROTTLE R	22-31-81	02	
SWITCHPACK ASSY AUTOTHROTTLE (AUTOFLIGHT ONLY)	22-31-51	02	