

DATA TRANSMISSION AND AUTOMATIC CALLING

HAP
OCT 10/06

23-20-00
SECTION TITLE
PAGE 1

NON-ILLUSTRATED FIGURE

THE ITEMS REFLECTED IN THIS FIGURE ARE INTENTIONALLY
NON-ILLUSTRATED. THEY ARE REFERENCED TO EITHER A
NEXT HIGHER OR NEXT LOWER ASSEMBLY/INSTALLATION FIGURE.

E 23200002 REV 054

FUNCTIONAL COLLECTOR-CUSTOMER UNIQUE E/E EQPT INSTL (DATA TRANSMISSION AND AUTOMATIC CALLING ONLY)

FIGURE 2

23-20-00-02

HAP
OCT 15/08

23-20-00-02
PAGE 0

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
2			FUNCTIONAL COLLECTOR- CUSTOMER UNIQUE E/E EQPT INSTL (DATA TRANSMISSION AND AUTOMATIC CALLING ONLY)	201967	
- 3	284A0012-2610		FUNCTIONAL COLLECTOR- CUSTOMER UNIQUE E/E EQPT INSTL (DATA TRANSMISSION AND AUTOMATIC CALLING ONLY)	201967	RF
- 50	284A0440-102		FOR NHA/OTHER SYS DET SEE: 23-00-00-02 .EQUIPMENT INSTL-E4-1 SELCAL FOR DETAILS SEE: 23-22-11-03	201967	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-20-00-02

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-20-00
FIG. 02
PAGE 1
OCT 15/08

NON-ILLUSTRATED FIGURE

THE ITEMS REFLECTED IN THIS FIGURE ARE INTENTIONALLY
NON-ILLUSTRATED. THEY ARE REFERENCED TO EITHER A
NEXT HIGHER OR NEXT LOWER ASSEMBLY/INSTALLATION FIGURE.

E 23200003 REV 055

FUNCTIONAL COLLECTOR- E/E EQPT INSTL CUSTOMER UNIQUE (DATA TRANSMISSION AND AUTOMATIC CALLING ONLY)

FIGURE 3

23-20-00-03

HAP
OCT 10/06

23-20-00-03
PAGE 0

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
3			FUNCTIONAL COLLECTOR- E/E EQPT INSTL CUSTOMER UNIQUE (DATA TRANSMISSION AND AUTOMATIC CALLING ONLY)	001030	
- 1	284A0012-3001		FUNCTIONAL COLLECTOR- CUSTOMER UNIQUE E/E EQPT INSTL (DATA TRANSMISSION AND AUTOMATIC CALLING ONLY) FOR NHA/OTHER SYS DET SEE: 23-00-00-03	001030	RF
- 10	284A0430-114		.EQUIPMENT INSTL-E3-3 ACARS FOR DETAILS SEE: 23-27-32-01	001011	1
- 25	284A0431-232201		.EQUIPMENT INSTL-E3-3 ACARS FOR DETAILS SEE: 23-27-32-02	012030	1
- 50	284A0513-1		.ANTENNA INSTL-EMER LOCATOR XMTR SYS FOR DETAILS SEE: 23-24-02-01	001011	1
- 50	284A0513-9		.ANTENNA INSTL-EMER LOCATOR XMTR SYS FOR DETAILS SEE: 23-24-02-04	012013	1
- 50	284A0513-13		.ANTENNA INSTL-EMER LOCATOR XMTR SYS FOR DETAILS SEE: 23-24-02-04	014030	1
- 60	284A0513-5		.PROGRAM SWITCH INSTL-EMER LOCATOR XMTR SYS FOR DETAILS SEE: 23-24-51-09	001030	1
- 65	284A0513-4		.TRANSMITTER INSTL-EMER LOCATOR XMTR SYS FOR DETAILS SEE: 23-24-00-01	001011	1
- 65	284A0513-10		.TRANSMITTER INSTL-EMER LOCATOR XMTR SYS FOR DETAILS SEE: 23-24-02-03	012021	1
- 65	284A0513-15		.TRANSMITTER INSTL-EMER LOCATOR XMTR SYS FOR DETAILS SEE: 23-24-02-03	022030	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-20-00-03

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-20-00
FIG. 03
PAGE 1
OCT 10/06