


STATIC DISCHARGER

HAP
OCT 10/06

23-61-00
SECTION TITLE
PAGE 1

BOEING
 737-600/700/800/900
 PARTS CATALOG (MAINTENANCE)



E 23610001 SH1 1 REV 143


DISCHARGER INSTL-STATIC
 FIGURE 1 (SHEET 1)

23-61-00-01


HAP
 JUN 15/08

23-61-00-01
 PAGE 0

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)



(A)



(B)

E 23610001 SHT 2 REV 054

DISCHARGER INSTL-STATIC
FIGURE 1 (SHEET 2)

23-61-00-01

HAP
OCT 10/06

23-61-00-01
PAGE 0A

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1			DISCHARGER INSTL-STATIC	001030 201967	
- 1	284A0826-1		DISCHARGER INSTL-WING TIP STATIC POSITION DATA: LH FOR NHA SEE: 57-00-00-05	001030 201967	RF
- 5	284A0826-2		DISCHARGER INSTL-WING TIP STATIC POSITION DATA: RH FOR NHA SEE: 57-00-00-06	001030 201967	RF
10	2-14SC1		.DISCHARGER-TIP SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740007 V55635	001030 201967	1
10	740007		.DISCHARGER-TIP SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-14SC1 VU1907	001030 201967	1
15	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740001 V55635	001030 201967	1
15	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-16SC1 VU1907	001030 201967	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-61-00-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-61-00
FIG. 01
PAGE 1
OCT 15/08

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1					
- 50	284A0826-3		DISCHARGER INSTL-WING STATIC POSITION DATA: LH FOR NHA SEE: 23-60-00-01	001030 201967	RF
- 55	284A0826-4		DISCHARGER INSTL-WING STATIC POSITION DATA: RH FOR NHA SEE: 23-60-00-01	001030 201967	RF
60	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740001 V55635	001030 201967	2
60	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-16SC1 VU1907	001030 201967	2
- 100	284A0826-5		DISCHARGER INSTL-HORIZ STAB. TIP STATIC POSITION DATA: LH FOR NHA SEE: 23-60-00-01	001030 201967	RF
- 105	284A0826-6		DISCHARGER INSTL-HORIZ STAB. TIP STATIC POSITION DATA: RH FOR NHA SEE: 23-60-00-01	001030 201967	RF
110	2-14SC1		.DISCHARGER- SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740007 V55635	001030 201967	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-61-00-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-61-00
FIG. 01
PAGE 2
OCT 15/08

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1 110	740007		.DISCHARGER- SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-14SC1 VU1907	001030 201967	1
- 150	284A0826-7		DISCHARGER INSTL-HORIZ STAB. POSITION DATA: LH FOR NHA SEE: 23-60-00-01	001030 201967	RF
- 155	284A0826-8		DISCHARGER INSTL-HORIZ STAB. POSITION DATA: RH FOR NHA SEE: 23-60-00-01	001030 201967	RF
160	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740001 V55635	001030 201967	2
160	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-16SC1 VU1907	001030 201967	2
- 200	284A0826-9		DISCHARGER INSTL-VERT STAB. TIP STATIC FOR NHA SEE: 23-60-00-01	001030 201967	RF
205	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740001 V55635	001030 201967	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-61-00-01

23-61-00
FIG. 01
PAGE 3
OCT 15/08

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1 205	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-16SC1 VU1907	001030 201967	1
210	2-14SC1		.DISCHARGER-TIP SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740007 V55635	001030 201967	1
210	740007		.DISCHARGER-TIP SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-14SC1 VU1907	001030 201967	1
- 250	284A0826-10		DISCHARGER INSTL-VERT STAB. STATIC FOR NHA SEE: 23-60-00-01	001030 201967	RF
255	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740001 V55635	001030 201967	2
255	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-16SC1 VU1907	001030 201967	2

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED


HAP

23-61-00-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-61-00
FIG. 01
PAGE 4
OCT 15/08

BOEING
 737-600/700/800/900
 PARTS CATALOG (MAINTENANCE)



E 23610002 REV 126

DISCHARGER INSTL-STATIC
 FIGURE 2

23-61-00-02

HAP
 FEB 10/07

23-61-00-02
 PAGE 0

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
2			DISCHARGER INSTL-STATIC	031200 968999	
- 100	MODREF86132		DISCHARGER INSTL-WING STATIC MODULE NUMBER: 284A0826-3 REV A POSITION DATA: LH	031200 968999	1
- 105	MODREF86133		DISCHARGER INSTL-WING STATIC MODULE NUMBER: 284A0826-4 REV A POSITION DATA: RH	031036	1
- 105	MODREF317811		DISCHARGER INSTL-WING STATIC MODULE NUMBER: 284A0826-4 REV B POSITION DATA: RH	037200 968999	1
110	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740001 V55635	031200 968999	2
110	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00	031200 968999	2
- 150	MODREF86134		DISCHARGER INSTL-HORIZ STAB. TIP STATIC MODULE NUMBER: 284A0826-5 REV A POSITION DATA: LH	031036	1
- 150	MODREF317810		DISCHARGER INSTL-HORIZ STAB. TIP STATIC MODULE NUMBER: 284A0826-5 REV B POSITION DATA: LH	037200 968999	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-61-00-02

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-61-00
FIG. 02
PAGE 1
OCT 15/08

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
2 - 155	MODREF86135		DISCHARGER INSTL-HORIZ STAB. TIP STATIC MODULE NUMBER: 284A0826-6 REV A POSITION DATA: RH	031036	1
- 155	MODREF317812		DISCHARGER INSTL-HORIZ STAB. TIP STATIC MODULE NUMBER: 284A0826-6 REV B POSITION DATA: RH	037200 968999	1
160	2-14SC1		.DISCHARGER- SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740007 V55635	031200 968999	1
160	740007		.DISCHARGER- SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-14SC1 VU1907	031200 968999	1
- 200	MODREF86136		DISCHARGER INSTL-HORIZ STAB. MODULE NUMBER: 284A0826-7 REV A POSITION DATA: LH	031036	1
- 200	MODREF317813		DISCHARGER INSTL-HORIZ STAB. MODULE NUMBER: 284A0826-7 REV B POSITION DATA: LH	037200 968999	1
- 205	MODREF86137		DISCHARGER INSTL-HORIZ STAB. MODULE NUMBER: 284A0826-8 REV A POSITION DATA: RH	031036	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-61-00-02

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-61-00
FIG. 02
PAGE 2
OCT 15/08

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
2 - 205	MODREF317814		DISCHARGER INSTL-HORIZ STAB. MODULE NUMBER: 284A0826-8 REV B POSITION DATA: RH	037200 968999	1
210	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740001 V55635	031200 968999	2
210	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00	031200 968999	2
- 300	MODREF86138		DISCHARGER INSTL-VERT STAB. TIP STATIC MODULE NUMBER: 284A0826-9 REV A	031036	1
- 300	MODREF317815		DISCHARGER INSTL-VERT STAB. TIP STATIC MODULE NUMBER: 284A0826-9 REV B	037200 968999	1
305	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740001 V55635	031200 968999	1
305	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-16SC1 VU1907	031200 968999	1

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-61-00-02

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-61-00
FIG. 02
PAGE 3
OCT 15/08

BOEING
737-600/700/800/900
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
2 310	2-14SC1		.DISCHARGER-TIP SUPPLIER CODE: VU1907 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 740007 V55635	031200 968999	1
310	740007		.DISCHARGER-TIP SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-14SC1 VU1907	031200 968999	1
- 350	MODREF86130		DISCHARGER INSTL-VERT STAB. STATIC MODULE NUMBER: 284A0826-10 REV A	031200 968999	1
355	2-16SC1		.DISCHARGER-TRAILING SUPPLIER CODE: VU1907 OPTIONAL PART: 740001 V55635	031200 968999	2
355	740001		.DISCHARGER-TRAILING SUPPLIER CODE: V55635 MAINTENANCE MANUAL REF: 23-61-00 OPTIONAL PART: 2-16SC1 VU1907	031200 968999	2

MISSING ITEM NUMBERS NOT APPLICABLE

- ITEM NOT ILLUSTRATED

HAP

23-61-00-02

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

23-61-00
FIG. 02
PAGE 4
OCT 15/08