

EQUIPMENT LIST



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			O AP0700	1	Aug 10/2009	C00300 cont.		
	1 thru 12	Aug 10/2009	O AP0900	1	Aug 10/2009	O	6	Aug 10/2009
O A00000	1	Aug 10/2009	O AP1800	1	Aug 10/2009	R C00400	1	Aug 10/2009
O	2	Aug 10/2009	O AP2800	1	Aug 10/2009	O	2	Aug 10/2009
AB0200	1	May 11/2009	O AS0000	1	Aug 10/2009	O	3	Aug 10/2009
AB0300	1	May 11/2009	O AW0200	1	Aug 10/2009	O C00500	1	Aug 10/2009
AB0400	1	May 11/2009	O AW0700	1	Aug 10/2009	R	2	Aug 10/2009
AB0500	1	May 11/2009	R C00000	1	Aug 10/2009	O C00600	1	Aug 10/2009
AB0700	1	Feb 09/2009	O	2	Aug 10/2009	O C00700	1	Aug 10/2009
AB0800	1	May 11/2009	R	3	Aug 10/2009	R	2	Aug 10/2009
AB1000	1	May 11/2009	R	4	Aug 10/2009	O	3	Aug 10/2009
AB1100	1	May 11/2009	R C00100	1	Aug 10/2009	R C00800	1	Aug 10/2009
AC0500	1	May 11/2009	R	2	Aug 10/2009	O	2	Aug 10/2009
AD0500	1	May 11/2009	R	3	Aug 10/2009	O	3	Aug 10/2009
D AE0000	1	Aug 10/2009	O	4	Aug 10/2009	R	4	Aug 10/2009
O AE0100	1	Aug 10/2009	R	5	Aug 10/2009	R C00900	1	Aug 10/2009
O AE0200	1	Aug 10/2009	O	6	Aug 10/2009	R	2	Aug 10/2009
O AE0300	1	Aug 10/2009	O C00200	1	Aug 10/2009	O C01000	1	Aug 10/2009
O AE0400	1	Aug 10/2009	O	2	Aug 10/2009	O	2	Aug 10/2009
O AE0500	1	Aug 10/2009	R	3	Aug 10/2009	R	3	Aug 10/2009
O AE0600	1	Aug 10/2009	O	4	Aug 10/2009	O	4	Aug 10/2009
O AE0800	1	Aug 10/2009	O	5	Aug 10/2009	O	5	Aug 10/2009
O AE1100	1	Aug 10/2009	O	6	Aug 10/2009	R C01100	1	Aug 10/2009
O AF0200	1	Aug 10/2009	O C00300	1	Aug 10/2009	R	2	Aug 10/2009
O AJ0000	1	Aug 10/2009	O	2	Aug 10/2009	O	3	Aug 10/2009
O AL0600	1	Aug 10/2009	O	3	Aug 10/2009	O	4	Aug 10/2009
O AL0700	1	Aug 10/2009	O	4	Aug 10/2009	R C01200	1	Aug 10/2009
O AP0600	1	Aug 10/2009	O	5	Aug 10/2009	O	2	Aug 10/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 1
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
			C09000	1	May 13/2008	D00500 cont.		
O	3	Aug 10/2009	R D00000	1	Aug 10/2009	O	6	Aug 10/2009
R	4	Aug 10/2009	R	2	Aug 10/2009	D00600	1	May 11/2009
R	5	Aug 10/2009		3	May 11/2009	R	2	Aug 10/2009
O C01300	1	Aug 10/2009	D00100	1	Feb 09/2009	R	3	Aug 10/2009
R	2	Aug 10/2009	R	2	Aug 10/2009	O	4	Aug 10/2009
R	3	Aug 10/2009		3	May 11/2009	A	5	Aug 10/2009
O	4	Aug 10/2009		4	May 11/2009	O D00700	1	Aug 10/2009
O	5	Aug 10/2009		5	May 11/2009	O	2	Aug 10/2009
R	6	Aug 10/2009		6	May 11/2009	O	3	Aug 10/2009
O	7	Aug 10/2009		7	May 11/2009	R	4	Aug 10/2009
A	8	Aug 10/2009	D00200	1	Feb 09/2009	R	5	Aug 10/2009
				2	Feb 09/2009	R	6	Aug 10/2009
C01400	1	Feb 09/2009		3	Feb 09/2009	R D00800	1	Aug 10/2009
	2	Feb 09/2009		4	Feb 09/2009	R	2	Aug 10/2009
R	3	Aug 10/2009	D00300	1	May 11/2009	R	3	Aug 10/2009
	4	Feb 09/2009	R	2	Aug 10/2009	O	4	Aug 10/2009
	5	Feb 09/2009	O	3	Aug 10/2009	O	5	Aug 10/2009
	6	Feb 09/2009	O	4	Aug 10/2009	R	6	Aug 10/2009
	7	Feb 09/2009	O	5	Aug 10/2009	A	7	Aug 10/2009
C01500	1	Feb 09/2009	D00400	1	May 11/2009	D00900	1	May 11/2009
	2	Feb 09/2009		2	May 11/2009	R	2	Aug 10/2009
C01600	1	Feb 09/2009		3	May 11/2009	R	3	Aug 10/2009
R	2	Aug 10/2009	D00500	1	May 11/2009	R	4	Aug 10/2009
	3	Feb 09/2009		2	May 11/2009		5	May 11/2009
R C02000	1	Aug 10/2009	R	3	May 11/2009	D01000	1	May 11/2009
R C02800	1	Aug 10/2009	R	4	Aug 10/2009	R	2	Aug 10/2009
R C03000	1	Aug 10/2009	R	5	Aug 10/2009	R	3	Aug 10/2009
R	2	Aug 10/2009						

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 2
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D01000 cont.			D02500 cont.			D03300	1	Feb 09/2009
	4	May 11/2009		2	May 11/2009	D03400	1	Feb 09/2009
R	5	Aug 10/2009	R	3	Aug 10/2009	D03500	1	Feb 09/2009
R	6	Aug 10/2009		4	May 11/2009		2	Feb 09/2009
D01100	1	Feb 09/2009		5	May 11/2009	D03600	1	Feb 09/2009
	2	Feb 09/2009	D02600	1	May 11/2009		2	Feb 09/2009
D01200	1	May 11/2009		2	May 11/2009		3	Feb 09/2009
	2	May 11/2009	R	3	Aug 10/2009		4	May 11/2009
D01300	1	May 11/2009	R	4	Aug 10/2009		5	May 11/2009
R D01400	1	Aug 10/2009	R	5	Aug 10/2009		6	Feb 09/2009
D01500	1	May 11/2009	R	6	Aug 10/2009		7	Feb 09/2009
D01600	1	May 11/2009	A	7	Aug 10/2009	R D03700	1	Aug 10/2009
	2	May 11/2009	O D02700	1	Aug 10/2009	O	2	Aug 10/2009
	3	May 11/2009	O	2	Aug 10/2009	D03800	1	Feb 09/2009
D01700	1	May 11/2009	O D02800	1	Aug 10/2009		2	Feb 09/2009
R	2	Aug 10/2009	R	2	Aug 10/2009		3	Feb 09/2009
D01800	1	May 11/2009	R	3	Aug 10/2009	D03900	1	Feb 09/2009
	2	May 11/2009	O	4	Aug 10/2009		2	Feb 09/2009
D01900	1	May 11/2009	R D02900	1	Aug 10/2009		3	May 11/2009
D02100	1	May 11/2009	R	2	Aug 10/2009		4	May 11/2009
	2	May 11/2009	R	3	Aug 10/2009		5	May 11/2009
D02200	1	May 11/2009	O	4	Aug 10/2009		6	May 11/2009
	2	May 11/2009	R D03000	1	Aug 10/2009		7	May 11/2009
	3	May 11/2009	R	2	Aug 10/2009		8	May 11/2009
D02300	1	May 11/2009	R D03100	1	Aug 10/2009	D04000	1	May 11/2009
D02400	1	May 11/2009	A	2	Aug 10/2009		2	May 11/2009
	2	May 11/2009	R D03200	1	Aug 10/2009		3	May 11/2009
D02500	1	May 11/2009	R	2	Aug 10/2009	D04100	1	May 11/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 3
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D04100 cont.			O D08100	1	Aug 10/2009	D10200 cont.		
	2	May 11/2009	O	2	Aug 10/2009	O	8	Aug 10/2009
R	3	Aug 10/2009	O D08300	1	Aug 10/2009	O	9	Aug 10/2009
	4	May 11/2009	O D08400	1	Aug 10/2009	O	10	Aug 10/2009
	5	May 11/2009	O D08500	1	Aug 10/2009	O D10300	1	Aug 10/2009
D04200	1	May 11/2009	O D08800	1	Aug 10/2009	O	2	Aug 10/2009
R	2	Aug 10/2009	O D09000	1	Aug 10/2009	O	3	Aug 10/2009
R	3	Aug 10/2009	O D09100	1	Aug 10/2009	O	4	Aug 10/2009
R	4	Aug 10/2009	O D09400	1	Aug 10/2009	O	5	Aug 10/2009
O	5	Aug 10/2009	O D10000	1	Aug 10/2009	O D10400	1	Aug 10/2009
A	6	Aug 10/2009	O	2	Aug 10/2009	O	2	Aug 10/2009
O D04300	1	Aug 10/2009	O	3	Aug 10/2009	O	3	Aug 10/2009
O D04400	1	Aug 10/2009	O	4	Aug 10/2009	O	4	Aug 10/2009
R D04500	1	Aug 10/2009	O	5	Aug 10/2009	O D10500	1	Aug 10/2009
O D04600	1	Aug 10/2009	O	6	Aug 10/2009	O	2	Aug 10/2009
O	2	Aug 10/2009	O	7	Aug 10/2009	R	3	Aug 10/2009
R D04700	1	Aug 10/2009	O	8	Aug 10/2009	R	4	Aug 10/2009
O D04800	1	Aug 10/2009	O D10100	1	Aug 10/2009	O	5	Aug 10/2009
O	2	Aug 10/2009	R	2	Aug 10/2009	O	6	Aug 10/2009
R D05100	1	Aug 10/2009	R	3	Aug 10/2009	O D10600	1	Aug 10/2009
R D05300	1	Aug 10/2009	R	4	Aug 10/2009	O	2	Aug 10/2009
O D05900	1	Aug 10/2009	O D10200	1	Aug 10/2009	O D10700	1	Aug 10/2009
O D06000	1	Aug 10/2009	O	2	Aug 10/2009	O	2	Aug 10/2009
R	2	Aug 10/2009	O	3	Aug 10/2009	O	3	Aug 10/2009
O D07000	1	Aug 10/2009	O	4	Aug 10/2009	O	4	Aug 10/2009
O	2	Aug 10/2009	O	5	Aug 10/2009	O	5	Aug 10/2009
O D07100	1	Aug 10/2009	O	6	Aug 10/2009	R	6	Aug 10/2009
O D08000	1	Aug 10/2009	O	7	Aug 10/2009	O D10800	1	Aug 10/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 4
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D10800 cont.			D11500 cont.			D11900 cont.		
O	2	Aug 10/2009		5	May 11/2009		3	Feb 09/2009
O D10900	1	Aug 10/2009		6	May 11/2009		4	Feb 09/2009
O	2	Aug 10/2009		7	May 11/2009		5	May 11/2009
O	3	Aug 10/2009		8	May 11/2009		6	May 11/2009
O D11000	1	Aug 10/2009		9	May 11/2009	R D12000	1	Aug 10/2009
O	2	Aug 10/2009	D11600	1	May 11/2009		2	Feb 09/2009
O	3	Aug 10/2009		2	May 11/2009		3	May 11/2009
O	4	Aug 10/2009		3	May 11/2009		4	Feb 09/2009
O D11100	1	Aug 10/2009		4	May 11/2009		5	May 11/2009
R	2	Aug 10/2009		5	May 11/2009		6	Feb 09/2009
R	3	Aug 10/2009		6	May 11/2009		7	Feb 09/2009
O	4	Aug 10/2009		7	May 11/2009		8	Feb 09/2009
R D11200	1	Aug 10/2009		8	May 11/2009	D12100	1	May 11/2009
R	2	Aug 10/2009		9	May 11/2009		2	May 11/2009
R D11300	1	Aug 10/2009	R D11700	1	Aug 10/2009		3	May 11/2009
R	2	Aug 10/2009	R	2	Aug 10/2009	R	4	Aug 10/2009
O	3	Aug 10/2009	O	3	Aug 10/2009	O	5	Aug 10/2009
O	4	Aug 10/2009	O	4	Aug 10/2009	O	6	Aug 10/2009
A	5	Aug 10/2009	D11800	1	May 11/2009	O	7	Aug 10/2009
D11400	1	Feb 09/2009		2	May 11/2009	R D12200	1	Aug 10/2009
R	2	Aug 10/2009		3	May 11/2009	O	2	Aug 10/2009
O	3	Aug 10/2009		4	May 11/2009	O	3	Aug 10/2009
O	4	Aug 10/2009		5	May 11/2009	D12300	1	May 11/2009
D11500	1	May 11/2009		6	May 11/2009		2	May 11/2009
	2	May 11/2009		7	May 11/2009	D12400	1	May 11/2009
	3	May 11/2009	D11900	1	Feb 09/2009		2	Feb 09/2009
	4	May 11/2009		2	Feb 09/2009	D12500	1	May 11/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 5
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D12600	1	May 11/2009	D30000 cont.			D40000 cont.		
	2	Feb 09/2009	R	3	Aug 10/2009	O	6	Aug 10/2009
D12700	1	Feb 09/2009		4	Feb 09/2009	O	7	Aug 10/2009
	2	May 11/2009		5	Feb 09/2009	O	8	Aug 10/2009
	3	Feb 09/2009		6	Feb 09/2009	O	9	Aug 10/2009
	4	Feb 09/2009	D30100	1	Feb 09/2009	O	10	Aug 10/2009
	5	Feb 09/2009		2	Feb 09/2009	O	11	Aug 10/2009
D12800	1	May 11/2009	D30200	1	Feb 09/2009	O	12	Aug 10/2009
D12900	1	Feb 09/2009		2	Feb 09/2009	O	13	Aug 10/2009
D13000	1	May 11/2009	R	3	Aug 10/2009	O	14	Aug 10/2009
D13100	1	May 11/2009		4	Feb 09/2009			
D13200	1	May 11/2009	D30400	1	Feb 09/2009	D40100	1	May 11/2009
D13300	1	Feb 09/2009		2	Feb 09/2009		2	Feb 09/2009
D13600	1	Feb 09/2009		3	Feb 09/2009		3	Feb 09/2009
D13700	1	Feb 09/2009		4	Feb 09/2009		4	Feb 09/2009
D13800	1	May 11/2009	D37000	1	Feb 09/2009		5	Feb 09/2009
	2	Feb 09/2009	D39900	1	Feb 09/2009	R	6	May 11/2009
	3	Feb 09/2009		2	May 11/2009	O	7	Aug 10/2009
	4	May 11/2009	R	3	Aug 10/2009	O	8	Aug 10/2009
R D13900	1	Aug 10/2009		4	May 11/2009	O	9	Aug 10/2009
	2	Feb 09/2009		5	May 11/2009	O	10	Aug 10/2009
	3	May 11/2009		6	May 11/2009	D40200	1	Feb 09/2009
R D14000	1	Aug 10/2009		7	May 11/2009	R	2	Feb 09/2009
D14100	1	Feb 09/2009	R D40000	1	Aug 10/2009	O	3	Aug 10/2009
	2	Feb 09/2009	O	2	Aug 10/2009	O	4	Aug 10/2009
D14200	1	Feb 09/2009	O	3	Aug 10/2009	R	5	Aug 10/2009
D30000	1	Feb 09/2009	R	4	Aug 10/2009	R	6	Aug 10/2009
	2	Feb 09/2009	O	5	Aug 10/2009	O	7	Aug 10/2009
							8	Aug 10/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 6
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40200 cont.			D40600 cont.			D41000	1	May 11/2009
A	9	Aug 10/2009		6	Feb 09/2009	D41100	1	May 11/2009
O D40300	1	Aug 10/2009	R	7	Aug 10/2009		2	May 11/2009
O	2	Aug 10/2009	R	8	Aug 10/2009	D41200	1	May 11/2009
O	3	Aug 10/2009	R	9	Aug 10/2009		2	May 11/2009
O	4	Aug 10/2009	R	10	Aug 10/2009	D41300	1	May 11/2009
O	5	Aug 10/2009	A	11	Aug 10/2009	D41400	1	May 11/2009
O	6	Aug 10/2009	O D40700	1	Aug 10/2009		2	May 11/2009
O	7	Aug 10/2009	O	2	Aug 10/2009	D41500	1	May 11/2009
R D40400	1	Aug 10/2009	O	3	Aug 10/2009		2	May 11/2009
R	2	Aug 10/2009	O	4	Aug 10/2009		3	May 11/2009
O	3	Aug 10/2009	O	5	Aug 10/2009	D41600	1	May 11/2009
O	4	Aug 10/2009	O	6	Aug 10/2009	D41800	1	May 11/2009
O	5	Aug 10/2009	R D40800	1	Aug 10/2009		2	May 11/2009
R	6	Aug 10/2009	R	2	Aug 10/2009	R	3	Aug 10/2009
A	7	Aug 10/2009	R	3	Aug 10/2009		4	May 11/2009
D40500	1	May 11/2009	R	4	Aug 10/2009		5	May 11/2009
R	2	Aug 10/2009	O	5	Aug 10/2009		6	May 11/2009
O	3	Aug 10/2009	R	6	Aug 10/2009	R	7	Aug 10/2009
O	4	Aug 10/2009	O	7	Aug 10/2009	D42000	1	May 11/2009
O	5	Aug 10/2009	A	8	Aug 10/2009		2	May 11/2009
O	6	Aug 10/2009	A	9	Aug 10/2009	D42100	1	May 11/2009
O	7	Aug 10/2009	O D40900	1	Aug 10/2009		2	May 11/2009
D40600	1	Feb 09/2009	O	2	Aug 10/2009		3	May 11/2009
	2	Feb 09/2009	O	3	Aug 10/2009	D42200	1	May 11/2009
	3	Feb 09/2009	R	4	Aug 10/2009	D42300	1	May 11/2009
	4	Feb 09/2009	O	5	Aug 10/2009	D42400	1	May 11/2009
	5	Feb 09/2009	A	6	Aug 10/2009	D42900	1	May 11/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 7
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
R D43000	1	Aug 10/2009	D45200 cont.			D46400	1	May 11/2009
R	2	Aug 10/2009	O	5	Aug 10/2009	D46600	1	Feb 09/2009
R	3	Aug 10/2009	O	6	Aug 10/2009		2	Feb 09/2009
R	4	Aug 10/2009	O	7	Aug 10/2009	D48000	1	Feb 09/2009
D43100	1	May 11/2009	D45300	1	May 11/2009	D48100	1	Feb 09/2009
	2	May 11/2009	D45500	1	May 11/2009	R	2	Aug 10/2009
	3	May 11/2009	R D46000	1	Aug 10/2009	R	3	Aug 10/2009
R D43200	1	Aug 10/2009	R	2	Aug 10/2009	D48300	1	Feb 09/2009
O	2	Aug 10/2009	R	2	Aug 10/2009		2	Jan 14/2008
D43300	1	May 11/2009	R	3	Aug 10/2009	D48900	1	Feb 09/2009
R	2	Aug 10/2009	R	4	Aug 10/2009	D49900	1	Feb 09/2009
O	3	Aug 10/2009	O	5	Aug 10/2009	DA1200	1	Feb 09/2009
O	4	Aug 10/2009	R	6	Aug 10/2009	DB1200	1	Feb 09/2009
O	5	Aug 10/2009	R	7	Aug 10/2009	DM0000	1	Feb 09/2009
O	6	Aug 10/2009	R	8	Aug 10/2009	R	2	Aug 10/2009
R D43900	1	Aug 10/2009	O	9	Aug 10/2009	DP1200	1	Feb 09/2009
D44100	1	May 11/2009	O	10	Aug 10/2009	DR9000	1	Oct 15/2007
R D44200	1	Aug 10/2009	R	11	Aug 10/2009	E001	1	Feb 09/2009
D44300	1	May 11/2009	R	12	Aug 10/2009	E002	1	Feb 09/2009
R D44500	1	Aug 10/2009	R	13	Aug 10/2009	E003	1	Feb 09/2009
D45000	1	May 11/2009	R	14	Aug 10/2009	E004	1	Feb 09/2009
D45100	1	May 11/2009	O	15	Aug 10/2009	E005	1	Feb 09/2009
	2	May 11/2009	A	16	Aug 10/2009	E006	1	Feb 09/2009
D45200	1	May 11/2009	R D46100	1	Aug 10/2009	E008	1	Feb 09/2009
R	2	Aug 10/2009	R	2	Aug 10/2009	E020	1	May 11/2009
O	3	Aug 10/2009	R	3	Aug 10/2009	R F00000	1	Aug 10/2009
O	4	Aug 10/2009	R	4	Aug 10/2009	R	2	Aug 10/2009
			A	5	Aug 10/2009	R	3	Aug 10/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 8
Aug 10/2009

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date	
F00000 cont.			L01100	1	Feb 09/2009	M00400	1	Feb 09/2009	
A	4	Aug 10/2009		2	Feb 09/2009	M00500	1	Feb 09/2009	
A	5	Aug 10/2009		3	Feb 09/2009	M00600	1	Feb 09/2009	
G00000	1	Feb 09/2009		4	Feb 09/2009	M00700	1	Feb 09/2009	
	2	Feb 09/2009	L01200	1	Feb 09/2009	M00800	1	Feb 09/2009	
J00000	1	Feb 09/2009		2	May 11/2009	M00900	1	May 11/2009	
L00000	1	Feb 09/2009	L01300	1	May 11/2009	M01000	1	Feb 09/2009	
	2	Feb 09/2009		2	May 11/2009	M01100	1	Feb 09/2009	
	3	Feb 09/2009		3	May 11/2009		2	Feb 09/2009	
R	4	Aug 10/2009		4	May 11/2009	M01200	1	Feb 09/2009	
L00100	1	Feb 09/2009	L01400	1	May 11/2009		2	Feb 09/2009	
	2	Feb 09/2009		2	Feb 09/2009	M01300	1	Feb 09/2009	
	3	Feb 09/2009	L03000	1	Feb 09/2009	M01400	1	Feb 09/2009	
	4	May 11/2009	M00000	1	Feb 09/2009		2	Feb 09/2009	
L00200	1	Feb 09/2009		2	May 11/2009	M01500	1	Feb 09/2009	
	2	Feb 09/2009		3	Feb 09/2009	M01600	1	Feb 09/2009	
L00300	1	Feb 09/2009		4	Feb 09/2009		2	Feb 09/2009	
	2	Feb 09/2009		5	Feb 09/2009		3	Feb 09/2009	
	3	Feb 09/2009	M00100	1	Feb 09/2009		4	Feb 09/2009	
L00400	1	Feb 09/2009		2	Feb 09/2009	M01700	1	Feb 09/2009	
	2	Feb 09/2009	M00200	1	Feb 09/2009		2	Feb 09/2009	
L00500	1	Feb 09/2009	R	2	Aug 10/2009	R	3	Aug 10/2009	
L00700	1	Feb 09/2009	O	3	Aug 10/2009	O	4	Aug 10/2009	
	2	Feb 09/2009	O	4	Aug 10/2009	O	5	Aug 10/2009	
L00800	1	Feb 09/2009	O	5	Aug 10/2009	O	6	Aug 10/2009	
L01000	1	Feb 09/2009	O			O	7	Aug 10/2009	
	2	May 11/2009	M00300	1	Feb 09/2009	R	M01800	1	Aug 10/2009
	3	Feb 09/2009		2	Feb 09/2009	O		2	Aug 10/2009
				3	Feb 09/2009				

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

 Page 9
 Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
M01800 cont.			M03000	1	Feb 09/2009	P021	1	Feb 09/2009
O	3	Aug 10/2009	M09000	1	May 13/2008	P023	1	Feb 09/2009
O	4	Aug 10/2009	M09100	1	May 13/2008	P028	1	Feb 09/2009
O	5	Aug 10/2009	M10300	1	Feb 09/2009	P041	1	Feb 09/2009
M01900	1	Feb 09/2009	M10700	1	May 11/2009	P042	1	Feb 09/2009
	2	May 11/2009	M10900	1	Feb 09/2009	P059	1	Feb 09/2009
	3	May 11/2009	M11000	1	Feb 09/2009	P061	1	Feb 09/2009
	4	May 11/2009	N00000	1	May 11/2009	P063	1	Feb 09/2009
	5	May 11/2009	N00100	1	Feb 09/2009	P091	1	Feb 09/2009
	6	May 11/2009		2	Feb 09/2009	P092	1	Feb 09/2009
	7	May 11/2009		3	Feb 09/2009	R00000	1	Feb 09/2009
M02000	1	Feb 09/2009	N00200	1	Feb 09/2009	R	2	Aug 10/2009
	2	Feb 09/2009	P001	1	Feb 09/2009		3	Feb 09/2009
	3	Feb 09/2009	P002	1	Feb 09/2009	R00100	1	Feb 09/2009
	4	Feb 09/2009	P003	1	Feb 09/2009	R00200	1	Feb 09/2009
	5	Feb 09/2009	P005	1	May 11/2009	R00300	1	Feb 09/2009
M02100	1	Feb 09/2009		2	Feb 09/2009	R00400	1	Feb 09/2009
	2	Feb 09/2009		3	Feb 09/2009	R00500	1	Feb 09/2009
M02200	1	Feb 09/2009	P006	1	Feb 09/2009	R	2	Aug 10/2009
	2	Feb 09/2009	P007	1	Feb 09/2009		3	Feb 09/2009
	3	Feb 09/2009	R P008	1	Aug 10/2009	R R00600	1	Aug 10/2009
M02300	1	Feb 09/2009	R	2	Aug 10/2009		2	Feb 09/2009
M02400	1	Feb 09/2009	P009	1	Feb 09/2009		3	Feb 09/2009
M02500	1	Feb 09/2009	P013	1	Feb 09/2009		4	Feb 09/2009
	2	Feb 09/2009	P014	1	Feb 09/2009	R00700	1	Feb 09/2009
M02600	1	May 11/2009	P015	1	Feb 09/2009		2	Feb 09/2009
	2	Feb 09/2009	P018	1	Feb 09/2009	R00800	1	Feb 09/2009
M02700	1	Feb 09/2009	P019	1	Feb 09/2009	R R00900	1	Aug 10/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 10
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
R00900 cont.			S00900 cont.			O TB0200	1	Aug 10/2009
R	2	Aug 10/2009		3	May 11/2009	O TB0300	1	Aug 10/2009
R	3	Aug 10/2009	S01000	1	May 11/2009	O TB0400	1	Aug 10/2009
	4	Feb 09/2009		2	May 11/2009	O TB0500	1	Aug 10/2009
R R01000	1	Aug 10/2009	R	3	Aug 10/2009	O	2	Aug 10/2009
R01900	1	Feb 09/2009	O	4	Aug 10/2009	O	3	Aug 10/2009
R09000	1	Nov 11/2008	R	5	Aug 10/2009	O	4	Aug 10/2009
S00000	1	May 11/2009	A	6	Aug 10/2009	O TB0600	1	Aug 10/2009
	2	May 11/2009	O S01100	1	Aug 10/2009	O	2	Aug 10/2009
R	3	Aug 10/2009	O	2	Aug 10/2009	O TB0800	1	Aug 10/2009
O	4	Aug 10/2009	R T00000	1	Aug 10/2009	O	2	Aug 10/2009
S00100	1	May 11/2009	O	2	Aug 10/2009	O	3	Aug 10/2009
R	2	Aug 10/2009	O T00100	1	Aug 10/2009	O TB1000	1	Aug 10/2009
	3	May 11/2009	O T00200	1	Aug 10/2009	O TB1100	1	Aug 10/2009
R	4	Aug 10/2009	R T00300	1	Aug 10/2009	O	2	Aug 10/2009
S00200	1	May 11/2009	O	2	Aug 10/2009	O	3	Aug 10/2009
	2	May 11/2009	O T00400	1	Aug 10/2009	O TB1200	1	Aug 10/2009
S00300	1	Feb 09/2009	O	2	Aug 10/2009	O TB1300	1	Aug 10/2009
R S00500	1	Aug 10/2009	O	3	Aug 10/2009	O TB1400	1	Aug 10/2009
R S00600	1	Aug 10/2009	O	4	Aug 10/2009	O TB1500	1	Aug 10/2009
S00700	1	Feb 09/2009	O T00500	1	Aug 10/2009	O TB1800	1	Aug 10/2009
	2	Feb 09/2009	O	2	Aug 10/2009	O	2	Aug 10/2009
R S00800	1	Aug 10/2009	O	3	Aug 10/2009	O TB2100	1	Aug 10/2009
R	2	Aug 10/2009	O T03000	1	Aug 10/2009	O TB2200	1	Aug 10/2009
O	3	Aug 10/2009	R TB0000	1	Aug 10/2009	O TB3000	1	Aug 10/2009
O	4	Aug 10/2009	O	2	Aug 10/2009	O TB3100	1	Aug 10/2009
S00900	1	May 11/2009	O	3	Aug 10/2009	O TB3200	1	Aug 10/2009
	2	May 11/2009	O TB0100	1	Aug 10/2009	O TB3300	1	Aug 10/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 11
Aug 10/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
O TB3900	1	Aug 10/2009	O Y04X	1	Aug 10/2009	O YWC+	1	Aug 10/2009
O TB4100	1	Aug 10/2009	O Y07X	1	Aug 10/2009	O YWD+	1	Aug 10/2009
O TB4200	1	Aug 10/2009	O Y08X	1	Aug 10/2009	O YWDS00	1	Aug 10/2009
O TB4600	1	Aug 10/2009	O YAAM00	1	Aug 10/2009	O YWE+	1	Aug 10/2009
O TB5000	1	Aug 10/2009	O YAAT00	1	Aug 10/2009	O YWES00	1	Aug 10/2009
O	2	Aug 10/2009	O YAAV00	1	Aug 10/2009	A	2	BLANK
O TB5100	1	Aug 10/2009	O YAB+	1	Aug 10/2009			
O TB5200	1	Aug 10/2009	O YABA00	1	Aug 10/2009			
O TB5300	1	Aug 10/2009	O YABS00	1	Aug 10/2009			
O TB5400	1	Aug 10/2009	O YAC+	1	Aug 10/2009			
O TB5800	1	Aug 10/2009	O YACA00	1	Aug 10/2009			
O TB8100	1	Aug 10/2009	O YAD+	1	Aug 10/2009			
O TB9000	1	Aug 10/2009	O YADP00	1	Aug 10/2009			
O V00000	1	Aug 10/2009	O YADS00	1	Aug 10/2009			
O	2	Aug 10/2009	O YAE+	1	Aug 10/2009			
O	3	Aug 10/2009	O YAEP00	1	Aug 10/2009			
O	4	Aug 10/2009	O YAES00	1	Aug 10/2009			
O V00100	1	Aug 10/2009	O YUR+	1	Aug 10/2009			
O	2	Aug 10/2009	O YURB00	1	Aug 10/2009			
O	3	Aug 10/2009	O YURJ00	1	Aug 10/2009			
O Y004	1	Aug 10/2009	O YURL00	1	Aug 10/2009			
O	2	Aug 10/2009	O YURP00	1	Aug 10/2009			
O Y007	1	Aug 10/2009	O YUS+	1	Aug 10/2009			
O	2	Aug 10/2009	O YUSL00	1	Aug 10/2009			
O	3	Aug 10/2009	O YUSP00	1	Aug 10/2009			
O Y008	1	Aug 10/2009	O YUXP00	1	Aug 10/2009			
O	2	Aug 10/2009	O YVEJ00	1	Aug 10/2009			
O	3	Aug 10/2009	O YVES00	1	Aug 10/2009			

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280A103

EFFECTIVE PAGES

Page 12
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
A00006		5-89354-3129 WINDSHIELD-LEFT 1	05-71761 81205	1	30-41-11 190/246/L002	ALL
A00006 T		MS25171-1S NIPPLE	96906	6	30-41-11 190/246/L002	ALL
A00009		5-89355-78 WINDOW-RIGHT 2	05-71762 81205	1	30-41-11 207/240/R032	ALL
A00010		5-89354-3130 WINDOW-RIGHT 1	05-71761 81205	1	30-41-12 190/246/R001	ALL
A00010 T		MS25171-1S NIPPLE	96906	6	30-41-12 190/246/R001	ALL
A00013		5-89355-77 WINDOW-LEFT 2	05-71762 81205	1	30-41-12 207/245/L032	ALL
A00013 T		MS25171-1S NIPPLE	96906	8	30-41-12 207/245/L032	ALL
A00021		5-89356-19 WINDOW-LEFT 3	TBD-0000 81205	1	30-41-11 245/247/L030	ALL
A00022		5-89356-20 WINDOW-RIGHT 3	TBD-0000 81205	1	30-41-12 254/258/R040	ALL
A00023		S232N911-4 HTR-LOWER LEFT PITOT	232A9101 59885	1	30-31-11 192/225/L034	YC001-YC030
A00023		S232N911-6 HTR-LOWER LEFT PITOT	232A9101 59885	1	30-31-11 192/225/L034	YC031-YM670
A00024		S232N911-4 HTR-LEFT ELEVATOR FEEL PITOT PROBE	232A9102 59885	1	30-31-11 1070/387/L008	YC001-YC030
A00024		S232N911-6 HTR-LEFT ELEVATOR FEEL PITOT PROBE	232A9102 59885	1	30-31-11 1070/387/L008	YC031-YM670
A00025		S232N911-4 HTR-LOWER RIGHT PITOT	232A9101 59885	1	30-31-12 192/213/R034	YC001-YC030
A00025		S232N911-6 HTR-LOWER RIGHT PITOT	232A9101 59885	1	30-31-12 192/213/R034	YC031-YM670
A00026		S232N911-4 HTR-UPPER RIGHT PITOT	232A9101 59885	1	30-31-12 192/224/R034	YC001-YC030
A00026		S232N911-6 HTR-UPPER RIGHT PITOT	232A9101 59885	1	30-31-12 192/224/R034	YC031-YM670

EQUIPMENT LIST

D280A103

Section A00000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
A00027		S232N911-4 HTR-RIGHT ELEVATOR FEEL PITOT	232A9102 59885	1	30-31-12 1070/387/R008	YC001-YC030
A00027		S232N911-6 HTR-RIGHT ELEVATOR FEEL PITOT	232A9102 59885	1	30-31-12 1070/387/R008	YC031-YM670

EQUIPMENT LIST

D280A103

Section A00000
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB0237A		287A4142 DISCONNECT BRACKET	141A5100	1	73-21-21 237/201/L004	ALL
AB0237B		287A4142 DISCONNECT BRACKET	141A5100 81205	1	73-21-21 241/203/L005	ALL
AB0250A		287A4142 DISCONNECT BRACKET-	141A7600	1	91-04-02 250/195/L2	ALL
AB0288		287A4021 DISCONNECT BRACKET	287A4181 81205	1	91-04-12 288/289/0	ALL

EQUIPMENT LIST

D280A103

Section AB0200

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB0340A		287A4021 DISCONNECT BRACKET-LEFT	287A4181 81205	1	91-04-12 340/295/L006	ALL
AB0340B		287A4021 DISCONNECT BRACKET-RIGHT	287A4181 81205	1	91-04-12 340/295/R006	ALL
AB0358		287A4181 DISCONNECT BRACKET	287A4181 81205	1	23-70-11 358/296/L003	YK901-YM670
AB0372	1	287A4358 DISCONNECT BRACKET-TEST RECEPTACLES	287A4352	1	00-00-00 372/184/R050	ALL
AB0373		287A4181 DISCONNECT BRACKET	287A4181 81205	1	91-04-12 373/296/L013	YC001-YC050
AB0387		287A4021 DISCONNECT BRACKET-UPR TCAS ANT	287A4181	0	91-04-12 387/298/R010	ALL

EQUIPMENT LIST

D280A103

Section AB0300
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB0405B		287A4021 DISCONNECT BRACKET	287A4181	1	91-04-12 410/288/R040	ALL
AB0410		287A4358 DISCONNECT BRACKET	287A4352	0	91-04-12 410/205/R039	YK901-YM670
AB0420A		287A4021 DISCONNECT BRACKET	288A4311 81205	1	91-04-12 424/293/L033	ALL

EQUIPMENT LIST

D280A103

Section AB0400

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB0500DL		287A4314 DISCONNECT BRACKET-LEFT WING	287A4314 81205	1	9104XX 500I/201/L040	YC001-YL430
AB0500DL		287A4314 DISCONNECT BRACKET-LEFT WING	287A4314 81205	1	9104XX 500D/201/L040	YM643-YM670
AB0500DR		69-71502 DISCONNECT BRACKET-RIGHT WING	65-49740 81205	1	9104XX 500I/201/R061	YC001-YL430
AB0500DR		69-71502 DISCONNECT BRACKET-RIGHT WING	65-49740 81205	1	9104XX 500D/201/R047	YM643-YM670
AB0501DL		69-73778 DISCONNECT BRACKET-LEFT WING	65C28038 81205	1	91-04-07 500D+7/180/L058	ALL
AB0501DR		69-73778 DISCONNECT BRACKET-RIGHT WING	65C28038 81205	1	91-04-07 500D+7/180/R058	ALL
AB0536L		278A9112-39 DISCONNECT BRACKET-LEFT AC BAY	111A2001 81205	1	91-00-00 541/159/L025	ALL
AB0536R		287A9112-83 DISCONNECT BRACKET-RIGHT AC BAY	111A2001 81205	1	91-00-00 541/159/R025	ALL

EQUIPMENT LIST

D280A103

Section AB0500
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB0727L		69-74694 DISCONNECT BRACKET-AFT CARGO COMPT	65C28058 81205	1	91-04-15 727/193/L38	ALL
AB0727R		69-74694 DISCONNECT BRACKET-AFT CARGO COMPT	287A4613 81205	1	91-04-15 727/193/R045	ALL

EQUIPMENT LIST

D280A103

Section AB0700

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB0858		287A4015-19 DISCONNECT BRACKET	287A4181 81205	1	91-04-15 858/219/R069	YC021-YM670

EQUIPMENT LIST

D280A103

Section AB0800
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB1030A		65-49766-37 DISCONNECT BRACKET-AFT PRESSURE BLKHD.	148A0931 81205	1	91-04-15 1030/301/R012	ALL
AB1030B		65-49766-14 DISCONNECT BRACKET-AFT PRESSURE BLKHD.	148A0931 81205	1	91-04-15 1030/301/0000	ALL
AB1030C		65-49766-30 DISCONNECT BRACKET-AFT PRESSURE BLKHD.	148A0931 81205	1	91-04-15 1030/301/L011	ALL
AB1042L		287A4811-71 DISCONNECT BRACKET -SEC 48 R	148A3110	0	22-18-11 1042/297/L008	YC031-YC050, YK907-YL430
AB1050L		287A4811-71 DISCONNECT BRACKET-SEC 48 L	148A3110 81205	1	91-04-15 1050/296/L015	YC008-YM670
AB1050R		287A4811-72 DISCONNECT BRACKET-SEC 48 R	148A3110 81205	1	91-04-15 1050/297/R008	YC008-YM670
AB1080	9	287A4811U83 DISCONNECT BRACKET-STA 1080 (SB 27-1253)	148A0931 81205	1	27-28-11 1080/299/0	YC001-YC030
AB1080		287A4811-31 DISCONNECT BRACKET-STA 1080	148A0931 81205	1	27-28-11 1080/299/0	ALL
AB1088		352A2300 DISCONNECT BRACKET-STA 1088	148AXXXX 81205	1	91-04-15 1088/ /	ALL

EQUIPMENT LIST

D280A103

Section AB1000

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB1156L		287A0000-00 DISCONNECT BRACKET-SEC 48 L	148A0000 81205	1	91-04-15 1156/ /	ALL
AB1156R		287A0000-00 DISCONNECT BRACKET SEC 48 R	148A0000 81205	1	91-04-15 1156/ /	ALL

EQUIPMENT LIST

D280A103

Section AB1100
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC0520		287A4302-1 DISCONNECT BRACKET	286A1140	1	91-04-13 500I+15/180/L059	ALL

EQUIPMENT LIST

D280A103

Section AC0500

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AD0520		287A4302-2 DISCONNECT BRACKET	286A1138	1	91-04-13 500D+10/194/R067	ALL

EQUIPMENT LIST

D280A103

Section AD0500
Page 1 End
May 11/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0101A		287A4134 DISCONNECT BRACKET - E1-1 SHELF	284A1711 81205	1	91-04-04 / /	ALL
AE0101B		287A4133 DISCONNECT BRACKET - E1-1 SHELF	284A1711 81205	1	91-04-04 / /	ALL
AE0102A		287A4133 DISCONNECT BRACKET - E1-2 SHELF	287A4116 81205	1	91-04-04 312/169/R023	ALL
AE0102B		284A3602 DISCONNECT BRACKET - E1-2 SHELF	284A1602 81205	1	91-04-04 / /	ALL
AE0103A		287A4134 DISCONNECT BRACKET - E1-3 SHELF	284A1713 81205	1	91-04-04 312/170/L025	ALL
AE0104A		287A4133 DISCONNECT BRACKET - E1-4 SHELF	287A4116 81205	1	91-04-04 312/160/R023	ALL
AE0104B		284A3602 DISCONNECT BRACKET - E1-4 SHELF	284A1602 81205	1	91-04-04 / /	ALL
AE0105A		287A4134 DISCONNECT BRACKET - E1-5 SHELF	284A4116 81205	1	91-04-04 312/160/R025	ALL

EQUIPMENT LIST

D280A103

Section AE0100

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0201A		287A4358 DISCONNECT BRACKET - E2-1 SHELF	284A1721 81205	1	91-04-05 E002-01/ /0023	ALL
AE0202A		287A4358 DISCONNECT BRACKET - E2-2 SHELF	284A1722 81205	1	91-04-05 E002-02/ /0033	ALL

EQUIPMENT LIST

D280A103

Section AE0200
Page 1 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0301A		287A4358 DISCONNECT BRACKET - E3-1	284A1731 81205	1	91-04-06 E003-01/ /0041	ALL
AE0302A		287A4358 DISCONNECT BRACKET - E3-2 SHELF	284A1732 81205	1	91-04-06 E003-02/ /0056	ALL
AE0303A		287A4358 DISCONNECT BRACKET - E3-3 SHELF	284A1733 81205	1	91-04-06 384/173/L005	ALL

EQUIPMENT LIST

D280A103

Section AE0300

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0401A		287A4358 DISCONNECT BRACKET - E4-1 SHELF	286A1741 81205	1	91-04-07 E004-01/ /0052	ALL
AE0401B		287A4358 DISCONNECT BRACKET - E4-1 SHELF	284A1741 81205	0	91-04-07 E004-01/ /	ALL
AE0401D		287A4357 DISCONNECT BRACKET - E4-1 SHELF	286A1741 81205	1	91-04-07 E004-01/ /0052	ALL
AE0402A		287A4358 DISCONNECT BRACKET - E4-2 SHELF	284A1742 81205	1	91-04-07 E004-02/ /0041	ALL

EQUIPMENT LIST

D280A103

Section AE0400
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0502A		284A2642 DISCONNECT BRACKET - E5-2 SHELF	284A0642 81205	1	91-04-08 E005-02/ /	ALL

EQUIPMENT LIST

D280A103

Section AE0500
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0602A		284A1762 DISCONNECT BRACKET - E6-2 SHELF	284A0762 81205	1	91-04-10 E006-02/ /	YL421-YM670

EQUIPMENT LIST

D280A103

Section AE0600
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0801A		284A2780 DISCONNECT BRACKET - E8-1 SHELF	284A1781 81205	1	91-04-11 E008-01/ /	ALL
AE0801B	1	284A2780 DISCONNECT BRACKET E08-01 SHELF	284A2781 81205	1	91-04-11 E008-01/ /	YC007-YM670
AE0801C	1	287A4134-9 DISCONNECT BRACKET - E8-1 SHELF	284A1781 81205	1	91-04-11 E008-01/ /	YC001-YC050
AE0801D		284A2780 DISCONNECT BRACKET - E8-1 SHELF	284A1781 81205	1	91-04-11 E008-01/ /	YC001-YC050, YK907-YM670
AE0801E	1	284A2780 DISCONNECT BRACKET - E8-1 SHELF	284A1781 81205	1	91-04-11 E008-01/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section AE0800

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE1100A		65C16237 DISCONNECT BRACKET - E11 SHELF	65C20884 81205	6	9104XX 212/180/R020	ALL

EQUIPMENT LIST

D280A103

Section AE1100
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AF0213A		254A1303 DISCONNECT BRACKET-AISLE CONTROL STAND	254A1220 81205	1	91-04-02 210/208/BL0	ALL
AF0222A		254A1239 DISCONNECT BRACKET-AISLE CONTROL STAND	254A1220 81205	1	91-04-01 210/208/	ALL

EQUIPMENT LIST

D280A103

Section AF0200
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AJ0004		284A1204 DISCONNECT BRACKET-J4	286A0094 81205	1	27-41-12 273/168/R024	ALL
AJ0011		284A1214 DISCONNECT BRACKET-J11	286A0122 81205	1	27-31-11 J011-00/ /	ALL
AJ0020		284A1203 DISCONNECT BRACKET-J20	286A0072 81205	1	32-31-12 J020-0B/ /	ALL
AJ0020A		284A1203 DISCONNECT BRACKET-J20-A	286A0074 81205	1	32-31-12 J020-0A/ /	ALL
AJ0020B		284A1203 DISCONNECT BRACKET-J20-B	286A0072 81205	1	32-31-12 J020-0B/ /	ALL
AJ0020C		284A1203 DISCONNECT BRACKET-J20-C	286A0074 81205	1	21-31-22 J020-0A/ /	YC028-YM670
AJ0020D		284A1203 DISCONNECT BRACKET-J20-D	286A0074 81205	1	28-23-11 J020-0D/ /	ALL
AJ0022		284A1222 DISCONNECT BRACKET-J22	286A0076 81205	1	32-31-11 J022-00/ /	ALL
AJ0023		284A1223 DISCONNECT BRACKET-J23	286A0078 81205	1	35-21-11 J023-00/ /	ALL
AJ0024		284A1224 DISCONNECT BRACKET-J24	286A0080 81205	1	78-32-61 J024-00/ /	ALL
AJ0039A		284A1239 DISCONNECT BRACKET-J39-A	286A0082	0	27-62-11 J039-0A/ /	YK907-YL430
AJ0046A		287A4140 DISCONNECT BRACKET - J46A	286ATBD 81205	1	21-25-11 263/177/R031	ALL
AJ0046B		287A4140 DISCONNECT BRACKET - J46B	286ATBD 81205	1	21-25-11 263/177/R031	ALL
AJ0048A		287A4140-5 DISCONNECT BRACKET - J48A	286ATBD 81205	1	21-25-11 263/177/L033	ALL

EQUIPMENT LIST

D280A103

Section AJ0000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AL0675A		287A4413-1 DISCONNECT BRACKET-MAIN WHEEL WELL	144A7710 81205	1	91-04-14 676/198/L040	ALL
AL0675B		287A4413-2 DISCONNECT BRACKET-MAIN WHEEL WELL	144A7710 81205	0	91-04-14 675/198/L036	ALL
AL0675C		287A4413-4 DISCONNECT BRACKET-MAIN WHEEL WELL	144A7710 81205	1	91-04-14 675/198/R036	ALL
AL0694L		287A1562-3 DISCONNECT BRACKET-STA 694	287A1552 81205	1	32-64-11 / /	ALL
AL0694R		287A1562-4 DISCONNECT BRACKET-STA 694	287A1552 81205	1	32-64-11 / /	ALL

EQUIPMENT LIST

D280A103

Section AL0600
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AL0706L		287A1542-3 DISCONNECT BRACKET-STA 706	287A1552 81205	1	32-31-12 / /	ALL
AL0706R		287A1542-4 DISCONNECT BRACKET-STA 706	287A1552 81205	1	32-31-12 / /	ALL
AL0711L		115A2162-9 DISCONNECT BRACKET-STA 711	115A1100 81205	1	32-64-12 / /	ALL
AL0711R		115A2162-9 DISCONNECT BRACKET-STA 711	115A1100 81205	1	32-64-12 / /	ALL
AL0720A		287A4413-5 DISCONNECT BRACKET-MAIN WHEEL WELL	144A7710 81205	1	91-04-14 717/200/L032	ALL
AL0720B		287A4413-6 DISCONNECT BRACKET-MAIN WHEEL WELL	144A7710 81205	0	91-04-14 717/200/L027	ALL
AL0720C		287A4413-8 DISCONNECT BRACKET-MAIN WHEEL WELL	144A7710 81205	1	91-04-14 717/200/R032	ALL
AL0720D		287A4413-7 DISCONNECT BRACKET-MAIN WHEEL WELL	144A7710 81205	0	91-04-14 717/200/R027	ALL

EQUIPMENT LIST

D280A103

Section AL0700
Page 1 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0600A		287A4124 DISCONNECT BRACKET-P5-P6 INTEGRATION	287A4106 81205	1	91-04-02 270/280/R005	ALL
AP0600B		287A4124 DISCONNECT BRACKET-LOWER P6 PANEL	287A4105 81205	1	91-04-02 260/215/R040	ALL
AP0600C		69-50971 DISCONNECT BRACKET-UPPER P6 PANEL	233A5301 81205	1	91-04-02 260/275/R015	ALL

EQUIPMENT LIST

D280A103

Section AP0600

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0700A		69-7881-1 DISCONNECT BRACKET-P7 PANEL	65-49730 81205	1	9103XX P007-00/250/L005	ALL
AP0700B		69-7881-1 DISCONNECT BRACKET-P7 PANEL	65-49730 81205	1	9103XX P007-00/250/R005	ALL

EQUIPMENT LIST

D280A103

Section AP0700
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0900A		287A4124 DISCONNECT BRACKET-P9-FWD INSTR PANEL	287A4103 81205	1	91-04-01 190/214/0	ALL

EQUIPMENT LIST

D280A103

Section AP0900

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP1800A		287A4124 DISCONNECT BRACKET-P5-P18 INTEGRATION	287A4106 81205	1	91-04-02 270/280/L005	ALL
AP1800B		287A4124 DISCONNECT BRACKET-LOWER P18 PANEL	287A4104 81205	1	91-04-02 255/215/L040	ALL

EQUIPMENT LIST

D280A103

Section AP1800
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP2800A		355A5340 DISCONNECT BRACKET-P28 PANEL	355A5300	1	49-62-11 724/172/R018	ALL

EQUIPMENT LIST

D280A103

Section AP2800

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AS0001		311A2519 DISCONNECT BRACKET-FIRE WALL	311A2511 81205	2	91-04-13 NS175/ /	ALL
AS0001L		311A2519 DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)	311A2511 81205	1	91-04-13 NS175/135/L	ALL
AS0001R		311A2519 DISCONNECT BRACKET-FIRE WALL(STRUT SIDE)	311A2511 81205	1	91-04-13 NS175/135/R	ALL
AS0002		312A2807 DISCONNECT BRACKET-LEFT SLEEVE	313A2240	0	91-04-13 NR201/136/	ALL
AS0002L		312A2807 DISCONNECT BRACKET-T/R LEFT STRUT	313A2240	0	91-04-03 NS201/136/L	ALL
AS0002R		312A2807 DISCONNECT BRACKET-T/R RIGHT STRUT	313A2240	0	91-04-03 NS201/136/R	ALL
AS0003		313A2240 DISCONNECT BRACKET RIGHT SLEEVE	312A2200	0	91-04-13 NS201/136/	ALL
AS0003L		312A2807 DISCONNECT BRACKET T/R LEFT STRUT	313A2240	0	91-04-07 NS201/136/L	ALL
AS0003R		312A2807 DISCONNECT BRACKET-T/R RIGHT STRUT	313A2240	0	91-04-07 NS201/136/R	ALL

EQUIPMENT LIST

D280A103

Section AS0000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW0219L		65C26727 DISCONNECT BRACKET-CLOSURE RIB(L-WING)	65C26707 81205	1	91-04-07 LES219/ /	ALL
AW0219R		65C26727 DISCONNECT BRACKET-CLOSURE RIB(R-WING)	65C26707 81205	1	91-04-07 / /	ALL
AW0254L		287A1542-10 DISCONNECT BRACKET-LEFT WING STA 254	287A1562 81205	1	27-53-21 / /	ALL
AW0254R		287A1542-10 DISCONNECT BRACKET-RIGHT WING STA 254	287A1562 81205	1	27-53-21 / /	ALL
AW0258L		TBD DISCONNECT BRACKET	286A1172 81205	1	91-04-13 IFSS 217/ /	ALL
AW0258R		TBD DISCONNECT BRACKET	286A1272 81205	1	91-04-13 IFSS 217/ /	ALL

EQUIPMENT LIST

D280A103

Section AW0200

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW0742L		287A1542-13 DISCONNECT BRACKET-LEFT WING STA 742	287A1552 81205	1	22-11-31 / /	ALL
AW0742R		287A1542-14 DISCONNECT BRACKET-RIGHT WING STA 742	287A1552 81205	1	22-11-31 / /	ALL

EQUIPMENT LIST

D280A103

Section AW0700
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
█ C00014		BACC18AD2 CB-AC GEN 1 IND	S281A601 81205	1	24-28-11 P091-00/ /B012	ALL
█ C00015		BACC18AD2 CB-AC APU GEN IND	S281A601 81205	1	24-28-11 P091-00/ /B011	ALL
█ C00016		BACC18AD2 CB-AC GEN 2 IND	S281A601 81205	1	24-28-11 P092-00/ /B012	ALL
C00023		BACC18AD2 CB-DC BUS INDICATION BUS 1	233A5202 81205	1	24-33-11 P006-04/ /F016	YC001-YC007
C00023		BACC18AD2 CB-DC BUS INDICATION BUS 1	233A5224 81205	1	24-33-11 P006-04/ /F016	YC008-YM670
C00025		BACC18AD2 CB-TR3-DC IND	S281A601 07217	0	24-31-12 M01720/ /C003	ALL
C00026		BACC18AD2 CB-DC BUS INDICATION BAT	233A5202 81205	1	24-33-11 P006-04/ /F014	YC001-YC007
C00026		BACC18AD2 CB-DC BUS INDICATION BAT	233A5224 81205	1	24-33-11 P006-04/ /F014	YC008-YM670
C00032		BACC18AD5 CB-FUEL FUELING CONT	233A5202 81205	1	28-44-11 P006-03/ /A003	YC001-YC007
C00032		BACC18AD5 CB-FUEL FUELING CONT	233A5223 81205	1	28-44-11 P006-03/ /A003	YC008-YM670
C00033		BACC18AD7 CB-AUX POWER UNIT CONT	233A5202 81205	1	49-62-11 P006-04/ /A014	YC001-YC007
C00033		BACC18AD7 CB-AUX POWER UNIT CONT	233A5224 81205	1	49-62-11 P006-04/ /A014	YC008-YM670
█ C00040		BACC18AD7 CB-28V AC GND SERV 2	S281A601 07217	1	24-53-11 P092-00/ /E006	ALL
█ C00041		BACC18AD5 CB-28V AC GND SERV 1	S281A601 07217	1	24-53-11 P091-00/ /E011	YC001-YK906
█ C00041		BACC18AD5 CB-28V AC GND SERV 1	S281A601 07217	1	24-53-11 P091-00/ /E012	YK907-YM670
C00054		BACC18AD10 CB-ANTI-ICE & RAIN WSHLD WIPER LEFT	233A5502 81205	1	30-42-11 P018-03/ /B003	YC001-YC007
C00054		BACC18AD10 CB-ANTI-ICE & RAIN WSHLD WIPER LEFT	233A5523 81205	1	30-42-11 P018-03/ /B003	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00055		BACC18AD10 CB-ANTI-ICE & RAIN WSHLD WIPER RIGHT	233A5502 81205	1	30-42-11 P018-03/ /B001	YC001-YC007
C00055		BACC18AD10 CB-ANTI-ICE & RAIN WSHLD WIPER RIGHT	233A5523 81205	1	30-42-11 P018-03/ /B001	YC008-YM670
C00058		BACC18AD3 CB-COMMUNICATIONS SELCAL	233A5502 81205	1	23-22-11 P018-02/ /D015	YC001-YC007
C00058		BACC18AD3 CB-COMMUNICATIONS SELCAL	233A5522 81205	1	23-22-11 P018-02/ /D015	YC008-YC050, YK907-YM670
C00058		BACC18AD3 CB-COMMUNICATIONS SELCAL (INOP)	233A5522 81205	1	23-22-11 P018-02/ /D015	YK901-YK906
C00072		BACC18AD2 CB-AC BUS STBY BUS 115V AC IND	233A5202 81205	1	24-28-11 P006-04/ /D016	YC001-YC007
C00072		BACC18AD2 CB-AC BUS STBY BUS 115V AC IND	233A5224 81205	1	24-28-11 P006-04/ /D016	YC008-YM670
C00073		BACC18AD2 CB-PASSENGER CABIN CREW CALL	233A5502 81205	1	23-42-11 P018-03/ /A009	YC001-YC007
C00073		BACC18AD2 CB-PASSENGER CABIN CREW CALL	233A5523 81205	1	23-42-11 P018-03/ /A009	YC008-YM670
C00076		BACC18AD2 CB-AIR CONDITIONING TEMP IND	233A5202 81205	1	21-61-51 P006-04/ /D008	YC001-YC007
C00076		BACC18AD2 CB-AIR CONDITIONING TEMP IND	233A5224 81205	1	21-61-51 P006-04/ /D008	YC008-YM670
C00077		BACC18AD2 CB-AIR CONDITIONING BLEED AIR PRESS IND	233A5202 81205	1	36-21-11 P006-04/ /B005	YC001-YC007
C00077		BACC18AD2 CB-AIR CONDITIONING BLEED AIR PRESS IND	233A5224 81205	1	36-21-11 P006-04/ /B005	YC008-YM670
C00080		BACC18AD3 CB-ENTERTAINMENT PA TAPE RPDR AC	233A5202 81205	1	23-31-11 P006-01/ /C009	YC001-YC007
C00080		BACC18AD3 CB-ENTERTAINMENT PA TAPE RPDR AC	233A5221 81205	1	23-31-11 P006-01/ /C009	YC008-YM670
C00082		BACC18AD10 CB-COMMUNICATIONS PA AMPL BAT	233A5202 81205	1	23-31-11 P006-01/ /D004	YC001-YC007
C00082		BACC18AD10 CB-COMMUNICATIONS PA AMPL BAT	233A5221 81205	1	23-31-11 P006-01/ /D004	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00083		BACC18AD2 CB-AUDIO CAPT	233A5202 81205	1	23-51-51 P006-02/ /D023	YC001-YC007
C00083		BACC18AD2 CB-AUDIO CAPT	233A5222 81205	1	23-51-51 P006-02/ /D023	YC008-YM670
C00084		BACC18AD2 CB-INTPH AND WARN	233A5202 81205	1	23-51-51 P006-02/ /D021	YC001-YC007
C00084		BACC18AD2 CB-INTPH AND WARN	233A5222 81205	1	23-51-51 P006-02/ /D021	YC008-YM670
C00085		BACC18AD2 CB-AUDIO OBS	233A5202 81205	1	23-51-51 P006-02/ /D024	YC001-YC007
C00085		BACC18AD2 CB-AUDIO OBS	233A5222 81205	1	23-51-51 P006-02/ /D024	YC008-YM670
C00086		BACC18AD2 CB-AUDIO F/O	233A5202 81205	1	23-51-51 P006-02/ /D022	YC001-YC007
C00086		BACC18AD2 CB-AUDIO F/O	233A5222 81205	1	23-51-51 P006-02/ /D022	YC008-YM670
■ C00087		BACC18AD10 CB-PASS READING LIGHTS LEFT	S281A601 07217	1	33-23-11 P091-00/ /B001	ALL
■ C00088		BACC18AD10 CB-PASS READING LIGHTS-LEFT	S281A601 07217	1	33-23-11 P091-00/ /B002	ALL
■ C00089		BACC18AD10 CB-PASS READING LIGHTS-LEFT	S281A601 07217	1	33-23-11 P091-00/ /B003	ALL
■ C00090		BACC18AD10 CB-PASS READING LIGHTS-LEFT	S281A601 07217	1	33-23-12 P091-00/ /B004	ALL
■ C00091		BACC18AD10 CB-PASS READING LIGHTS-LEFT	S281A601 07217	1	33-23-12 P091-00/ /B005	ALL
■ C00092		BACC18AD10 CB-PASS READING LIGHTS-LEFT	S281A601 07217	1	33-23-12 P091-00/ /B006	ALL
■ C00094		BACC18AD10 CB-PASS READING LIGHTS-RIGHT STA340-464	S281A601 07217	1	33-23-21 P092-00/ /B001	ALL
■ C00095		BACC18AD10 CB-PASS READING LIGHTS-RIGHT	S281A601 07217	1	33-23-21 P092-00/ /B002	ALL
C00096		BACC18AD10 CB-PASS READING LIGHTS-RIGHT	S281A0601 07217	1	33-23-21 P092-00/ /B003	ALL

EQUIPMENT LIST

D280A103

Section C00000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
■ C00097		BACC18AD10 CB-PASS READING LIGHTS-RIGHT	S281A601 07217	1	33-23-22 P092-00/ /B004	ALL
■ C00098		BACC18AD10 CB-PASS READING LIGHTS-RIGHT	S281A601 07217	1	33-23-22 P092-00/ /B005	ALL
■ C00099		BACC18AD10 CB-PASS READING LIGHTS-RIGHT	S281A601 07217	1	33-23-22 P092-00/ /B006	ALL

EQUIPMENT LIST

D280A103

Section C00000
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00104		BACC18AD5 CB-LAVATORY WATER HEATER A	233A5502 81205	1	38-21-11 P018-03/ /F013	YC001-YC007
C00104		BACC18AD5 CB-LAVATORY WATER HEATER A	233A5523 81205	1	38-21-11 P018-03/ /F013	YC008-YM670
C00107		BACC18AD2 CB-VOICE RCDR	233A5502 81205	1	23-71-11 P018-02/ /D007	YC001-YC007
C00107		BACC18AD2 CB-VOICE RCDR	233A5522 81205	1	23-71-11 P018-02/ /D007	YC008-YM670
C00109		BACC18AD2 CB-FLIGHT RECORDER AC	233A5502 81205	1	31-31-11 P018-02/ /C009	YC001-YC007
C00109		BACC18AD2 CB-FLIGHT RECORDER AC	233A5522 81205	1	31-31-11 P018-02/ /C009	YC008-YM670
C00110		BACC18AD2 CB-EXTERIOR LIGHTING WING SCAN	233A5502 81205	1	33-41-11 P018-03/ /A014	YC001-YC007
C00110		BACC18AD2 CB-EXTERIOR LIGHTING WING SCAN	233A5523 81205	1	33-41-11 P018-03/ /A014	YC008-YM670
C00111		BACC18AD5 CB-EXTERIOR LIGHTING ANTI COLLISION RED	233A5502 81205	1	33-44-11 P018-03/ /B012	YC001-YC007
C00111		BACC18AD5 CB-EXTERIOR LIGHTING ANTI COLLISION RED	233A5523 81205	1	33-44-11 P018-03/ /B012	YC008-YM670
C00113		BACC18AD5 CB-EXTERIOR LIGHTING POSITION RIGHT	233A5502 81205	1	33-43-11 P018-03/ /A012	YC001-YC007
C00113		BACC18AD5 CB-EXTERIOR LIGHTING POSITION RIGHT	233A5523 81205	1	33-43-11 P018-03/ /A012	YC008-YM670
C00114		BACC18AD5 CB-EXTERIOR LIGHTING POSITION LEFT	233A5502 81205	1	33-43-11 P018-03/ /A013	YC001-YC007
C00114		BACC18AD5 CB-EXTERIOR LIGHTING POSITION LEFT	233A5523 81205	1	33-43-11 P018-03/ /A013	YC008-YM670
C00115		BACC18AD7 CB-EXT LIGHTING ANTI COLLISION WHITE	233A5502 81205	1	33-44-12 P018-03/ /B013	YC001-YC007
C00115		BACC18AD7 CB-EXT LIGHTING ANTI COLLISION WHITE	233A5523 81205	1	33-44-12 P018-03/ /B013	YC008-YM670
C00116		BACC18AD7 CB-SERVICE OUTLET	S281A601 07217	1	25-29-11 P092-00/ /E007	ALL

EQUIPMENT LIST

D280A103

Section C00100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00117		BACC18AD5 CB-28V DC SERVICE OUTLETS	233A5202 81205	1	25-29-11 P006-03/ /F001	YC001-YC007
C00117		BACC18AD5 CB-28V DC SERVICE OUTLETS	233A5223 81205	1	25-29-11 P006-03/ /F001	YC008-YM670
█ C00118		BACC18AD10 CB-VAC OUTLET FWD	S281A601 07217	1	25-29-11 P092-00/ /E008	ALL
█ C00119		BACC18AD10 CB-VAC OUTLET AFT	S281A601 07217	1	25-29-11 P092-00/ /E009	ALL
C00120		BACC18AD5 CB-WEATHER RADAR RT	233A5202 81205	1	34-41-11 P006-01/ /D013	YC001-YC007
C00120		BACC18AD5 CB-WEATHER RADAR RT	233A5221 81205	1	34-41-11 P006-01/ /D013	YC008-YM670
C00123		BACC18AD10 CB-EXT LIGHTING NOSE GEAR TAXI	233A5502 81205	1	33-45-11 P018-03/ /D014	YC001-YC007
C00123		BACC18AD10 CB-EXT LIGHTING NOSE GEAR TAXI	233A5523 81205	1	33-45-11 P018-03/ /D014	YC008-YM670
C00124		BACC18AD2 CB-AIR CONDITIONING MIX VALVE POS IND	233A5224 81205	1	21-61-21 P006-04/ /D007	YM643-YM670
C00125		BACC18AD7 CB-WHEEL WELL LT	S281A601 07217	1	33-32-11 P092-00/ /C002	ALL
C00126		BACC18AD7 CB-AIR COND COMPT LT	S281A601 81205	1	33-33-11 P092-00/ /C003	ALL
C00127		BACC18AD7 CB-CARGO COMPT LT-FWD	S281A601 07217	1	33-36-11 P092-00/ /C004	ALL
C00128		BACC18AD7 CB-CARGO COMPT LT-AFT	S281A601 07217	1	33-36-12 P092-00/ /C005	ALL
C00129		BACC18AD2 CB-LANDING GEAR LATCH & PRESS WARN	233A5202 81205	1	32-31-11 P006-03/ /B017	YC001-YC007
C00129		BACC18AD2 CB-LANDING GEAR LATCH & PRESS WARN	233A5223 81205	1	32-31-11 P006-03/ /B017	YC008-YM670
C00131		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR BAT	233A5202 81205	1	31-52-11 P006-03/ /B013	YC001-YC007
C00131		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR BAT	233A5223 81205	1	31-52-11 P006-03/ /B013	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00132		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR BUS 1	233A5202 81205	1	31-52-11 P006-03/ /B012	YC001-YC007
C00132		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR BUS 1	233A5223 81205	1	31-52-11 P006-03/ /B012	YC008-YM670
C00133		BACC18AD5 CB-INDICATOR MASTER DIM DIM/TST CONT	233A5202 81205	1	33-18-11 P006-03/ /D011	YC001-YC007
C00133		BACC18AD5 CB-INDICATOR MASTER DIM DIM/TST CONT	233A5223 81205	1	33-18-11 P006-03/ /D011	YC008-YM670
C00134		BACC18AD2 CB-DC BUS INDICATION HOT BAT	233A5202 81205	1	24-33-11 P006-04/ /E015	YC001-YC007
C00134		BACC18AD2 CB-DC BUS INDICATION HOT BAT	233A5224 81205	1	24-33-11 P006-04/ /E015	YC008-YM670
C00136		BACC18AD2 CB-DC BUS INDICATION STBY	233A5202 81205	1	24-33-11 P006-04/ /E018	YC001-YC007
C00136		BACC18AD2 CB-DC BUS INDICATION STBY	233A5224 81205	1	24-33-11 P006-04/ /E018	YC008-YM670
C00137		BACC18AD3 CB-DOOR LOCK	233A5202 81205	1	52-51-11 P006-03/ /E001	YC001-YC007
C00137		BACC18AD3 CB-DOOR LOCK	233A5223 81205	1	52-51-11 P006-03/ /E001	YC008-YM670
■ C00138		BACC18AD2 CB-WATER QTY IND	S281A601 07217	1	38-41-11 P091-00/ /C009	ALL
C00139		BACC18AD7 CB-ELEC RACK LT-FWD	S281A601 07217	1	33-34-11 P091-00/ /C002	ALL
■ C00140		BACC18AD3 CB-WORK & THRSH LT	S281A601 07217	1	33-26-11 P091-00/ /C003	ALL
C00142	1	BACC18X100B CB-BATTERY CHARGER	284A0816 81205	1	24-31-11 J009-00/ /A004	ALL
C00142	2	BACC18X100 CB-BATTERY CHARGER	284A0816 81205	1	24-31-11 J009-00/ /A004	ALL
C00146		BACC18AD5 CB-ANTI-ICE & RAIN WING ANTI-ICE VALVE	233A5502 81205	1	30-11-11 P018-03/ /A001	YC001-YC007
C00146		BACC18AD5 CB-ANTI-ICE & RAIN WING ANTI-ICE VALVE	233A5523 81205	1	30-11-11 P018-03/ /A001	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00100

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00148		BACC18AD2 CB-ANTI-ICE & RAIN ENG 1 & WING CONT	233A5502 81205	1	30-21-11 P018-03/ /A006	YC001-YC007
C00148		BACC18AD2 CB-ANTI-ICE & RAIN ENG 1 & WING CONT	233A5523 81205	1	30-21-11 P018-03/ /A006	YC008-YM670
C00149		BACC18AD2 CB-ANTI-ICE & RAIN ENGINE 2 CONTROL	233A5502 81205	1	30-21-11 P018-03/ /B006	YC001-YC007
C00149		BACC18AD2 CB-ANTI-ICE & RAIN ENGINE 2 CONTROL	233A5523 81205	1	30-21-11 P018-03/ /B006	YC008-YM670
C00151		BACC18AD2 CB-ENGINE 2 IGNITION LEFT	233A5202 81205	1	74-11-11 P006-02/ /D006	YC001-YC007
C00151		BACC18AD2 CB-ENGINE 2 IGNITION LEFT	233A5222 81205	1	74-11-11 P006-02/ /D006	YC008-YM670
C00153		BACC18AD2 CB-ENGINE 1 IGNITION LEFT	233A5502 81205	1	74-11-11 P018-02/ /A003	YC001-YC007
C00153		BACC18AD2 CB-ENGINE 1 IGNITION LEFT	233A5522 81205	1	74-11-11 P018-02/ /A003	YC008-YM670
C00154		BACC18AD2 CB-ENGINE 2 START VALVE	233A5202 81205	1	80-11-11 P006-02/ /C004	YC001-YC007
C00154		BACC18AD2 CB-ENGINE 2 START VALVE	233A5222 81205	1	80-11-11 P006-02/ /C004	YC008-YM670
C00155		BACC18AD2 CB-ENTRY LIGHTS DIM	233A5202 81205	1	33-29-11 P006-04/ /E009	YC001-YC007
C00155		BACC18AD2 CB-ENTRY LIGHTS DIM	233A5224 81205	1	33-29-11 P006-04/ /E009	YC008-YM670
C00156		BACC18AD5 CB-OXYGEN IND	233A5502 81205	1	35-21-11 P018-03/ /F007	YC001-YC007
C00156		BACC18AD5 CB-OXYGEN IND	233A5523 81205	1	35-21-11 P018-03/ /F007	YC008-YM670
C00161		BACC18AD3 CB-CONTROL CABIN LIGHTING STBY COMPASS	233A5202 81205	1	33-14-12 P006-03/ /A014	YC001-YC007
C00161		BACC18AD3 CB-CONTROL CABIN LIGHTING STBY COMPASS	233A5223 81205	1	33-14-12 P006-03/ /A014	YC008-YM670
C00163		BACC18AD3 CB-LAVATORY MIRROR LIGHT	233A5502 81205	1	33-26-31 P018-03/ /E014	YC001-YC007

EQUIPMENT LIST

D280A103

Section C00100

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00163		BACC18AD3 CB-LAVATORY MIRROR LIGHT	233A5523 81205	1	33-26-31 P018-03/ /E014	YC008-YM670
C00165		BACC18AD10 CB-COMMUNICATIONS VHF 1	233A5502 81205	1	23-12-11 P018-02/ /D011	YC001-YC007
C00165		BACC18AD10 CB-COMMUNICATIONS VHF 1	233A5522 81205	1	23-12-11 P018-02/ /D011	YC008-YM670
C00166		BACC18AD10 CB-COMMUNICATIONS VHF 2	233A5202 81205	1	23-12-21 P006-01/ /C003	YC001-YC007
C00166		BACC18AD10 CB-COMMUNICATIONS VHF 2	233A5221 81205	1	23-12-21 P006-01/ /C003	YC008-YM670
C00169		BACC18X25 CB-SW HOT BAT BUS	S281A601 07217	0	24-61-11 M01720/ /B004	ALL
C00170		BACC18AD3 CB-MACH WARN SYS-1	233A5502 81205	1	34-16-11 P018-02/ /E003	YC001-YC007
C00170		BACC18AD3 CB-MACH WARN SYS-1	233A5522 81205	1	34-16-11 P018-02/ /E003	YC008-YM670
C00184		BACC18AD3 CB-GND SERV CLG NIGHT CONT	S281A601 07217	1	33-22-11 P091-00/ /C004	ALL
C00186		BACC18AD5 CB-ATC 1	233A5502 81205	1	34-53-11 P018-01/ /B005	YC001-YC007
C00186		BACC18AD5 CB-ATC 1	233A5521 81205	1	34-53-11 P018-01/ /B005	YC008-YM670
C00188		BACC18AD5 CB-ATC 2	233A5202 81205	1	34-53-21 P006-01/ /D014	YC001-YC007
C00188		BACC18AD5 CB-ATC 2	233A5221 81205	1	34-53-21 P006-01/ /D014	YC008-YM670
C00190		BACC18AD2 CB-RADIO NAVIGATION DME 1	233A5502 81205	1	34-55-11 P018-01/ /B003	YC001-YC007
C00190		BACC18AD2 CB-RADIO NAVIGATION DME 1	233A5521 81205	1	34-55-11 P018-01/ /B003	YC008-YM670
C00192		BACC18AD2 CB-RADIO NAVIGATION DME 2	233A5202 81205	1	34-55-21 P006-01/ /A014	YC001-YC007
C00192		BACC18AD2 CB-RADIO NAVIGATION DME 2	233A5221 81205	1	34-55-21 P006-01/ /A014	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00100

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00195		BACC18AD2 CB-LANDING GEAR ANTISKID OUTBD	233A5202 81205	1	32-41-11 P006-03/ /E018	YC001-YC007
C00195		BACC18AD2 CB-LANDING GEAR ANTISKID OUTBD	233A5223 81205	1	32-41-11 P006-03/ /E018	YC008-YM670
C00196		BACC18AD2 CB-LANDING GEAR ANTISKID INBD	233A5202 81205	1	32-41-11 P006-03/ /E016	YC001-YC007
C00196		BACC18AD2 CB-LANDING GEAR ANTISKID INBD	233A5223 81205	1	32-41-11 P006-03/ /E016	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00100
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00204		BACC18AD5 CB-FLIGHT CONTROL SHUTOFF VALVES SPOILER	233A5202 81205	1	27-61-11 P006-02/ /B012	YC001-YC007
C00204		BACC18AD5 CB-FLIGHT CONTROL SHUTOFF VALVES SPOILER	233A5222 81205	1	27-61-11 P006-02/ /B012	YC008-YM670
C00205		BACC18AD7 CB-ELEX PANEL LIGHTS AFT CAPT	233A6301 81205	1	33-11-41 P008-00/ /	ALL
C00207		BACC18AD7 CB-FLIGHT CONTROL STAB TRIM CONT	233A5202 81205	1	27-41-11 P006-02/ /B010	YC001-YC007
C00207		BACC18AD7 CB-FLIGHT CONTROL STAB TRIM CONT	233A5222 81205	1	27-41-11 P006-02/ /B010	YC008-YM670
C00210		BACC18AD5 CB-FLIGHT CONTROL FLAP SHUTOFF VALVES	233A5202 81205	1	27-53-11 P006-02/ /A007	YC001-YC007
C00210		BACC18AD5 CB-FLIGHT CONTROL FLAP SHUTOFF VALVES	233A5222 81205	1	27-53-11 P006-02/ /A007	YC008-YM670
C00211		BACC18AD2 CB-FLIGHT CONTROL FSEU DC 1	233A5202 81205	1	27-81-11 P006-02/ /A008	YC001-YC007
C00211		BACC18AD2 CB-FLIGHT CONTROL FSEU DC 1	233A5222 81205	1	27-81-11 P006-02/ /A008	YC008-YM670
C00213		BACC18AD2 CB-FC TE FLAP POS/SKEW SNSR & IND LEFT	233A5202 81205	1	27-52-11 P006-02/ /A012	YC001-YC007
C00213		BACC18AD2 CB-FC TE FLAP POS/SKEW SNSR & IND LEFT	233A5222 81205	1	27-52-11 P006-02/ /A012	YC008-YM670
C00219		BACC18AD3 CB-PANEL & INSTR CB PANEL	233A5202 81205	1	33-14-12 P006-03/ /C009	YC001-YC007
C00219		BACC18AD3 CB-PANEL & INSTR CB PANEL	233A5223 81205	1	33-14-12 P006-03/ /C009	YC008-YM670
C00220	9	BACC18AD2 CB-WINDOW HEAT CONT LEFT FRONT DC	SB301047 81205	1	30-41-11 P018-03/ /F005	YC001-YC007
C00220		BACC18AD2 CB-WINDOW HEAT CONT LEFT FRONT DC	233A5523 81205	1	30-41-11 P018-03/ /F005	YC008-YM670
C00221	9	BACC18AD2 CB-WINDOW HEAT CONT LEFT SIDE DC	SB301047 81205	1	30-41-12 P018-03/ /F002	YC001-YC007
C00221		BACC18AD2 CB-WINDOW HEAT CONT LEFT SIDE DC	233A5523 81205	1	30-41-12 P018-03/ /F002	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00200

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00222	9	BACC18AD2 CB-WINDOW HEAT CONT RIGHT FRONT DC	SB301047 81205	1	30-41-12 P018-03/ /F001	YC001-YC007
C00222		BACC18AD2 CB-WINDOW HEAT CONT RIGHT FRONT DC	233A5523 81205	1	30-41-12 P018-03/ /F001	YC008-YM670
C00223	9	BACC18AD2 CB-WINDOW HEAT CONT RIGHT SIDE DC	SB301047 81205	1	30-41-11 P018-03/ /F004	YC001-YC007
C00223		BACC18AD2 CB-WINDOW HEAT CONT RIGHT SIDE DC	233A5523 81205	1	30-41-11 P018-03/ /F004	YC008-YM670
C00224		BACC18AD3 CB-WINDOW HEAT CONTROL LEFT FRONT AC	233A5502 81205	1	30-41-11 P018-03/ /E001	YC001-YC007
C00224		BACC18AD3 CB-WINDOW HEAT CONTROL LEFT FRONT AC	233A5523 81205	1	30-41-11 P018-03/ /E001	YC008-YM670
C00225		BACC18AD3 CB-WINDOW HEAT CONTROL LEFT SIDE AC	233A5502 81205	1	30-41-12 P018-03/ /D002	YC001-YC007
C00225		BACC18AD3 CB-WINDOW HEAT CONTROL LEFT SIDE AC	233A5523 81205	1	30-41-12 P018-03/ /D002	YC008-YM670
C00226		BACC18AD3 CB-WINDOW HEAT CONTROL RIGHT FRONT AC	233A5502 81205	1	30-41-12 P018-03/ /D001	YC001-YC007
C00226		BACC18AD3 CB-WINDOW HEAT CONTROL RIGHT FRONT AC	233A5523 81205	1	30-41-12 P018-03/ /D001	YC008-YM670
C00227		BACC18AD3 CB-WINDOW HEAT CONTROL RIGHT SIDE AC	233A5502 81205	1	30-41-11 P018-03/ /E002	YC001-YC007
C00227		BACC18AD3 CB-WINDOW HEAT CONTROL RIGHT SIDE AC	233A5523 81205	1	30-41-11 P018-03/ /E002	YC008-YM670
C00228		BACC18X25 CB-WINDOW HEAT POWER LEFT FRONT	233A5202 81205	1	30-41-11 P006-11/ /B009	YC001-YC007
C00228		BACC18X25 CB-WINDOW HEAT POWER LEFT FRONT	233A5225 81205	1	30-41-11 P006-11/ /B009	YC008-YM670
C00229		BACC18AD5 CB-WINDOW HEAT POWER L3, L4 & L5	233A5202 81205	1	30-41-11 P006-11/ /B007	YC001-YC007
C00229		BACC18AD5 CB-WINDOW HEAT POWER L3, L4 & L5	233A5225 81205	1	30-41-11 P006-11/ /B007	YC008-YC030
C00233		BACC18AD7 CB-HEATERS DRAIN	233A5502 81205	1	30-71-11 P018-03/ /E005	YC001-YC007

EQUIPMENT LIST

D280A103

Section C00200

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00233		BACC18AD7 CB-HEATERS DRAIN	233A5523 81205	1	30-71-11 P018-03/ /E005	YC008-YM670
C00234		BACC18AD5 CB-HEATERS DRAIN MAST GND	233A5502 81205	1	30-71-11 P018-03/ /E003	YC001-YC007
C00234		BACC18AD5 CB-HEATERS DRAIN MAST GND	233A5523 81205	1	30-71-11 P018-03/ /E003	YC008-YM670
C00236		BACC18AD2 CB-HEATERS ELEV PITOT LEFT	233A5502 81205	1	30-31-11 P018-03/ /C004	YC001-YC007
C00236		BACC18AD2 CB-HEATERS ELEV PITOT LEFT	233A5523 81205	1	30-31-11 P018-03/ /C004	YC008-YM670
C00237		BACC18AD2 CB-HEATERS ELEV PITOT RIGHT	233A5502 81205	1	30-31-12 P018-03/ /D004	YC001-YC007
C00237		BACC18AD2 CB-HEATERS ELEV PITOT RIGHT	233A5523 81205	1	30-31-12 P018-03/ /D004	YC008-YM670
C00238		BACC18AD5 CB-HEATERS TEMP PROBE	233A5502 81205	1	30-31-11 P018-03/ /C002	YC001-YC007
C00238		BACC18AD5 CB-HEATERS TEMP PROBE	233A5523 81205	1	30-31-11 P018-03/ /C002	YC008-YM670
C00239		BACC18AD5 CB-INTERPHONE POWER CAPT DC 2	233A5202 81205	1	23-51-11 P006-02/ /C023	YC001-YC007
C00239		BACC18AD5 CB-INTERPHONE POWER CAPT DC 2	233A5222 81205	1	23-51-11 P006-02/ /C023	YC008-YM670
C00240		BACC18AD5 CB-INTERPHONE POWER CAPT BAT	233A5202 81205	1	23-51-11 P006-02/ /C024	YC001-YC007
C00240		BACC18AD5 CB-INTERPHONE POWER CAPT BAT	233A5222 81205	1	23-51-11 P006-02/ /C024	YC008-YM670
C00242		BACC18AD5 CB-GALLEY LT	S281A601 07217	1	33-26-21 P092-00/ /E010	ALL
C00244		BACC18AD10 CB-EXTERIOR LIGHTING RUNWAY TURNOFF LEFT	233A5502 81205	1	33-45-11 P018-03/ /C013	YC001-YC007
C00244		BACC18AD10 CB-EXTERIOR LIGHTING RUNWAY TURNOFF LEFT	233A5523 81205	1	33-45-11 P018-03/ /C013	YC008-YM670
C00245		BACC18AD10 CB-EXT LIGHTING RUNWAY TURNOFF RIGHT	233A5502 81205	1	33-45-11 P018-03/ /C012	YC001-YC007

EQUIPMENT LIST

D280A103

Section C00200

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00245		BACC18AD10 CB-EXT LIGHTING RUNWAY TURNOFF RIGHT	233A5523 81205	1	33-45-11 P018-03/ /C012	YC008-YM670
C00250		BACC18AD7 CB-PASS CABIN LIGHTING EMER CHGR FWD	233A5502 81205	1	33-51-11 P018-03/ /A011	YC001-YC007
C00250		BACC18AD7 CB-PASS CABIN LIGHTING EMER CHGR FWD	233A5523 81205	1	33-51-11 P018-03/ /A011	YC008-YM670
C00257		BACC18AD2 CB-AIR CONDITIONING OVERHEAT	233A5224 81205	1	21-51-15 P006-04/ /C004	YM643-YM670
C00258		BACC18AD2 CB-AIR CONDITIONING TEMP CONTROL AUTO R	233A5224 81205	1	21-61-22 P006-04/ /B002	YM643-YM670
C00259		BACC18AD2 CB-AIR CONDITIONING BLEED AIR VALVE ISLN	233A5202 81205	1	36-11-11 P006-04/ /A005	YC001-YC007
C00259		BACC18AD2 CB-AIR CONDITIONING BLEED AIR VALVE ISLN	233A5224 81205	1	36-11-11 P006-04/ /A005	YC008-YM670
C00262		BACC18AD2 CB-AIR CONDITIONING PACK CONT VALVES L	233A5202 81205	1	21-51-11 P006-04/ /C006	YC001-YC007
C00262		BACC18AD2 CB-AIR CONDITIONING PACK CONT VALVES L	233A5224 81205	1	21-51-11 P006-04/ /C006	YC008-YM670
C00263		BACC18AD2 CB-AIR CONDITIONING PACK CONT VALVES R	233A5202 81205	1	21-51-21 P006-04/ /C005	YC001-YC007
C00263		BACC18AD2 CB-AIR CONDITIONING PACK CONT VALVES R	233A5224 81205	1	21-51-21 P006-04/ /C005	YC008-YM670
C00265		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD CONT L	233A5224 81205	1	21-51-14 P006-04/ /A008	YM643-YM670
C00266		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD CONT R	233A5224 81205	1	21-51-24 P006-04/ /B008	YM643-YM670
C00267		BACC18AD2 CB-AIR CONDITIONING TEMP CONTROL MANUAL	233A5224 81205	1	21-61-21 P006-04/ /A003	YM643-YM670
C00268		BACC18AD2 CB-AIR CONDITIONING TEMP CONTROL AUTO L	233A5224 81205	1	21-61-21 P006-04/ /A002	YM643-YM670
C00271		BACC18AD7 CB-EXTERIOR LIGHTING LANDING LEFT FIXED	233A5502 81205	1	33-42-11 P018-03/ /B015	YC001-YC007
C00271		BACC18AD7 CB-EXTERIOR LIGHTING LANDING LEFT FIXED	233A5523 81205	1	33-42-11 P018-03/ /B015	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00200

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00272		BACC18AD7 CB-EXTERIOR LIGHTING LANDING RIGHT FIXED	233A5502 81205	1	33-42-11 P018-03/ /C014	YC001-YC007
C00272		BACC18AD7 CB-EXTERIOR LIGHTING LANDING RIGHT FIXED	233A5523 81205	1	33-42-11 P018-03/ /C014	YC008-YM670
C00273		BACC18AD7 CB-EXTERIOR LIGHTING LANDING LEFT RETR	233A5502 81205	1	33-42-11 P018-03/ /C015	YC001-YC007
C00273		BACC18AD7 CB-EXTERIOR LIGHTING LANDING LEFT RETR	233A5523 81205	1	33-42-11 P018-03/ /C015	YC008-YM670
C00274		BACC18AD7 CB-EXTERIOR LIGHTING LANDING RIGHT RETR	233A5502 81205	1	33-42-11 P018-03/ /B014	YC001-YC007
C00274		BACC18AD7 CB-EXTERIOR LIGHTING LANDING RIGHT RETR	233A5523 81205	1	33-42-11 P018-03/ /B014	YC008-YM670
C00276		BACC18AD3 CB-ENGINE 1 THRUST REVERSER CONT	233A5502 81205	1	78-34-11 P018-02/ /B005	YC001-YC007
C00276		BACC18AD3 CB-ENGINE 1 THRUST REVERSER CONT	233A5522 81205	1	78-34-11 P018-02/ /B005	YC008-YM670
C00277		BACC18AD3 CB-ENGINE 2 THRUST REVERSER CONT	233A5202 81205	1	78-34-21 P006-02/ /C007	YC001-YC007
C00277		BACC18AD3 CB-ENGINE 2 THRUST REVERSER CONT	233A5222 81205	1	78-34-21 P006-02/ /C007	YC008-YM670
C00282		BACC18AD3 CB-CONTROL CABIN LIGHTING DOME WHITE	233A5202 81205	1	33-14-12 P006-03/ /A015	YC001-YC007
C00282		BACC18AD3 CB-CONTROL CABIN LIGHTING DOME WHITE	233A5223 81205	1	33-14-12 P006-03/ /A015	YC008-YM670
C00283		BACC18AD3 CB-CONTROL CABIN LIGHTING CONT STAND	233A5202 81205	1	33-14-12 P006-03/ /A008	YC001-YC007
C00283		BACC18AD3 CB-CONTROL CABIN LIGHTING CONT STAND	233A5223 81205	1	33-14-12 P006-03/ /A008	YC008-YM670
C00284		BACC18AD7 CB-PANEL & INSTR ELEX PANEL	233A5202 81205	1	33-11-41 P006-03/ /C010	YC001-YC007
C00284		BACC18AD7 CB-PANEL & INSTR ELEX PANEL	233A5223 81205	1	33-11-41 P006-03/ /C010	YC008-YM670
C00285		BACC18AD2 CB-YAW DAMPER AC	233A5502 81205	1	22-23-11 P018-01/ /C007	YC001-YC007

EQUIPMENT LIST

D280A103

Section C00200

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00285		BACC18AD2 CB-YAW DAMPER AC	233A5521 81205	1	22-23-11 P018-01/ /C007	YC008-YM670
C00286		BACC18AD5 CB-YAW DAMPER 1 DC	233A5502 81205	1	22-23-11 P018-01/ /D007	YC001-YC007
C00286		BACC18AD5 CB-YAW DAMPER 1 DC	233A5521 81205	1	22-23-11 P018-01/ /D007	YC008-YM670
C00296		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS LEFT	233A5202 81205	1	26-21-11 P006-02/ /B022	YC001-YC007
C00296		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS LEFT	233A5222 81205	1	26-21-11 P006-02/ /B022	YC008-YM670
C00297		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS RIGHT	233A5202 81205	1	26-21-11 P006-02/ /B020	YC001-YC007
C00297		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS RIGHT	233A5222 81205	1	26-21-11 P006-02/ /B020	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00200
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00306		BACC18AD3 CB-HYDRAULIC SYSTEM BRAKE PRESS IND	233A5202 81205	1	29-32-11 P006-02/ /A013	YC001-YC007
C00306		BACC18AD3 CB-HYDRAULIC SYSTEM BRAKE PRESS IND	233A5222 81205	1	29-32-11 P006-02/ /A013	YC008-YM670
C00308		BACC18AD3 CB-CONTROL CABIN LIGHTING MAP & KIT	233A5202 81205	1	33-17-11 P006-03/ /A009	YC001-YC007
C00308		BACC18AD3 CB-CONTROL CABIN LIGHTING MAP & KIT	233A5223 81205	1	33-17-11 P006-03/ /A009	YC008-YM670
C00309		BACC18AD3 CB-CONTROL CABIN LIGHTING OBS READING	233A5202 81205	1	33-17-11 P006-03/ /A010	YC001-YC007
C00309		BACC18AD3 CB-CONTROL CABIN LIGHTING OBS READING	233A5223 81205	1	33-17-11 P006-03/ /A010	YC008-YM670
C00310		BACC18AD7 CB-INDICATOR MASTER DIM BAT	233A5202 81205	1	33-18-11 P006-03/ /D012	YC001-YC007
C00310		BACC18AD7 CB-INDICATOR MASTER DIM BAT	233A5223 81205	1	33-18-11 P006-03/ /D012	YC008-YM670
C00311		BACC18AD7 CB-INDICATOR MASTER DIM BUS 1	233A5202 81205	1	33-18-11 P006-03/ /D013	YC001-YC007
C00311		BACC18AD7 CB-INDICATOR MASTER DIM BUS 1	233A5223 81205	1	33-18-11 P006-03/ /D013	YC008-YM670
C00312		BACC18AD7 CB-INDICATOR MASTER DIM BUS 2	233A5202 81205	1	33-18-11 P006-03/ /D014	YC001-YC007
C00312		BACC18AD7 CB-INDICATOR MASTER DIM BUS 2	233A5223 81205	1	33-18-11 P006-03/ /D014	YC008-YM670
C00313		BACC18AD3 CB-INDICATOR MASTER DIM SECT 1	233A5202 81205	1	33-18-11 P006-03/ /E011	YC001-YC007
C00313		BACC18AD3 CB-INDICATOR MASTER DIM SECT 1	233A5223 81205	1	33-18-11 P006-03/ /E011	YC008-YM670
C00314		BACC18AD3 CB-INDICATOR MASTER DIM SECT 2	233A5202 81205	1	33-18-11 P006-03/ /E012	YC001-YC007
C00314		BACC18AD3 CB-INDICATOR MASTER DIM SECT 2	233A5223 81205	1	33-18-11 P006-03/ /E012	YC008-YM670
C00315		BACC18AD3 CB-INDICATOR MASTER DIM SECT 3	233A5202 81205	1	33-18-11 P006-03/ /E013	YC001-YC007

EQUIPMENT LIST

D280A103

Section C00300

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00315		BACC18AD3 CB-INDICATOR MASTER DIM SECT 3	233A5223 81205	1	33-18-11 P006-03/ /E013	YC008-YM670
C00316		BACC18AD3 CB-INDICATOR MASTER DIM SECT 4	233A5202 81205	1	33-18-11 P006-03/ /E014	YC001-YC007
C00316		BACC18AD3 CB-INDICATOR MASTER DIM SECT 4	233A5223 81205	1	33-18-11 P006-03/ /E014	YC008-YM670
C00317		BACC18AD3 CB-INDICATOR MASTER DIM SECT 5	233A5202 81205	1	33-18-11 P006-03/ /F011	YC001-YC007
C00317		BACC18AD3 CB-INDICATOR MASTER DIM SECT 5	233A5223 81205	1	33-18-11 P006-03/ /F011	YC008-YM670
C00318		BACC18AD3 CB-INDICATOR MASTER DIM SECT 6	233A5202 81205	1	33-18-11 P006-03/ /F012	YC001-YC007
C00318		BACC18AD3 CB-INDICATOR MASTER DIM SECT 6	233A5223 81205	1	33-18-11 P006-03/ /F012	YC008-YM670
C00320		BACC18AD7 CB-ELEX PANEL LIGHTS FWD	233A6301 81205	1	33-11-41 P008-00/ /	ALL
C00323		BACC18AD7 CB-OVERHEAD 28V PRI	233A5202 81205	1	33-12-11 P006-03/ /D009	YC001-YC007
C00323		BACC18AD7 CB-OVERHEAD 28V PRI	233A5223 81205	1	33-12-11 P006-03/ /D009	YC008-YM670
C00325		BACC18AD7 CB-OVERHEAD 28V SEC	233A5202 81205	1	33-12-11 P006-03/ /D010	YC001-YC007
C00325		BACC18AD7 CB-OVERHEAD 28V SEC	233A5223 81205	1	33-12-11 P006-03/ /D010	YC008-YM670
C00326		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5202 81205	1	33-12-11 P006-03/ /E008	YC001-YC007
C00326		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5223 81205	1	33-12-11 P006-03/ /E008	YC008-YM670
C00327		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5202 81205	1	33-12-12 P006-03/ /F008	YC001-YC007
C00327		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5223 81205	1	33-12-12 P006-03/ /F008	YC008-YM670
C00328		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5202 81205	1	33-12-11 P006-03/ /E010	YC001-YC007

EQUIPMENT LIST

D280A103

Section C00300

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00328		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5223 81205	1	33-12-11 P006-03/ /E010	YC008-YM670
C00329		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5202 81205	1	33-12-11 P006-03/ /E009	YC001-YC007
C00329		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5223 81205	1	33-12-11 P006-03/ /E009	YC008-YM670
C00330		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5202 81205	1	33-12-12 P006-03/ /F009	YC001-YC007
C00330		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5223 81205	1	33-12-12 P006-03/ /F009	YC008-YM670
C00331		BACC18AD7 CB-PANEL & INSTR 28V PRI CAPT & CTR	233A5202 81205	1	33-11-11 P006-03/ /B009	YC001-YC007
C00331		BACC18AD7 CB-PANEL & INSTR 28V PRI CAPT & CTR	233A5223 81205	1	33-11-11 P006-03/ /B009	YC008-YM670
C00335		BACC18AD3 CB-PANEL & INSTR 28V PRI F/O	233A5202 81205	1	33-11-21 P006-03/ /B010	YC001-YC007
C00335		BACC18AD3 CB-PANEL & INSTR 28V PRI F/O	233A5223 81205	1	33-11-21 P006-03/ /B010	YC008-YM670
C00344		BACC18AD2 CB-AIR CONDITIONING TEMP CONT 35 DEG F L	233A5224 81205	1	21-51-16 P006-04/ /A001	YM643-YM670
C00345		BACC18AD2 CB-AIR CONDITIONING TEMP CONT 35 DEG F R	233A5224 81205	1	21-51-26 P006-04/ /B001	YM643-YM670
C00347		BACC18AD5 CB-HYDRAULIC SYSTEM SHUTOFF VALVE ENG 1	233A5202 81205	1	29-11-11 P006-02/ /C019	YC001-YC007
C00347		BACC18AD5 CB-HYDRAULIC SYSTEM SHUTOFF VALVE ENG 1	233A5222 81205	1	29-11-11 P006-02/ /C019	YC008-YM670
C00348		BACC18AD5 CB-HYDRAULIC SYSTEM SHUTOFF VALVE ENG 2	233A5202 81205	1	29-11-11 P006-02/ /C018	YC001-YC007
C00348		BACC18AD5 CB-HYDRAULIC SYSTEM SHUTOFF VALVE ENG 2	233A5222 81205	1	29-11-11 P006-02/ /C018	YC008-YM670
C00355		BACC18AD3 CB-FUEL TEMP IND	233A5202 81205	1	28-42-11 P006-03/ /A007	YC001-YC007
C00355		BACC18AD3 CB-FUEL TEMP IND	233A5223 81205	1	28-42-11 P006-03/ /A007	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00300

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00357		BACC18AD3 CB-STBY ALTM/ASI VIB	233A5502 81205	1	34-21-11 P018-02/ /D010	YC001-YC007
C00357		BACC18AD3 CB-STBY ALTM/ASI VIB	233A5522 81205	1	34-21-11 P018-02/ /D010	YC008-YC050
C00359		BACC18AD2 CB-FUEL SPAR VALVE ENG 1	233A5202 81205	1	28-21-11 P006-03/ /B004	YC001-YC007
C00359		BACC18AD2 CB-FUEL SPAR VALVE ENG 1	233A5223 81205	1	28-21-11 P006-03/ /B004	YC008-YM670
C00360		BACC18AD2 CB-FUEL SPAR VALVE ENG 2	233A5202 81205	1	28-21-11 P006-03/ /B003	YC001-YC007
C00360		BACC18AD2 CB-FUEL SPAR VALVE ENG 2	233A5223 81205	1	28-21-11 P006-03/ /B003	YC008-YM670
C00361		BACC18AD2 CB-FUEL CROSS FEED VALVE	233A5202 81205	1	28-22-11 P006-03/ /B007	YC001-YC007
C00361		BACC18AD2 CB-FUEL CROSS FEED VALVE	233A5223 81205	1	28-22-11 P006-03/ /B007	YC008-YM670
C00362		BACC18AD5 CB-FLIGHT CONT SHUTOFF VALVES STBY RUD	233A5202 81205	1	27-23-11 P006-02/ /C011	YC001-YC007
C00362		BACC18AD5 CB-FLIGHT CONT SHUTOFF VALVES STBY RUD	233A5222 81205	1	27-23-11 P006-02/ /C011	YC008-YM670
C00363		BACC18AD5 CB-FLIGHT CONT SHUTOFF VALVES FLT CONT	233A5202 81205	1	27-23-11 P006-02/ /B013	YC001-YC007
C00363		BACC18AD5 CB-FLIGHT CONT SHUTOFF VALVES FLT CONT	233A5222 81205	1	27-23-11 P006-02/ /B013	YC008-YM670
C00374		BACC18AD3 CB-AFCS SYS B WARN LIGHT (BAT)	233A5202 81205	1	22-14-11 P006-02/ /B001	YC001-YC007
C00374		BACC18AD3 CB-AFCS SYS B WARN LIGHT (BAT)	233A5222 81205	1	22-14-11 P006-02/ /B001	YC008-YM670
C00388		BACC18AD3 CB-FIRE PROTECTION DET OVHT WW WING BODY	233A5202 81205	1	26-12-11 P006-02/ /A019	YC001-YC007
C00388		BACC18AD3 CB-FIRE PROTECTION DET OVHT WW WING BODY	233A5222 81205	1	26-12-11 P006-02/ /A019	YC008-YM670
C00389		BACC18AD7 CB-ACCESS COMPT LT	S281A601 07217	1	33-35-11 P091-00/ /C005	ALL

EQUIPMENT LIST

D280A103

Section C00300

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00390		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5202 81205	1	33-12-12 P006-03/ /F010	YC001-YC007
C00390		BACC18AD7 CB-OVERHEAD 5V SECONDARY	233A5223 81205	1	33-12-12 P006-03/ /F010	YC008-YM670
C00392		BACC18AD15 CB-WINDOW HEAT POWER LEFT SIDE	233A5202 81205	1	30-41-12 P006-12/ /B009	YC001-YC007
C00392		BACC18AD15 CB-WINDOW HEAT POWER LEFT SIDE	233A5226 81205	1	30-41-12 P006-12/ /B009	YC008-YM670
C00393		BACC18AD15 CB-WINDOW HEAT POWER RIGHT SIDE	233A5202 81205	1	30-41-11 P006-11/ /B008	YC001-YC007
C00393		BACC18AD15 CB-WINDOW HEAT POWER RIGHT SIDE	233A5225 81205	1	30-41-11 P006-11/ /B008	YC008-YM670
C00394		BACC18X25 CB-WINDOW HEAT POWER RIGHT FRONT	233A5202 81205	1	30-41-12 P006-12/ /B008	YC001-YC007
C00394		BACC18X25 CB-WINDOW HEAT POWER RIGHT FRONT	233A5226 81205	1	30-41-12 P006-12/ /B008	YC008-YM670
C00395		BACC18AD5 CB-WINDOW HEAT POWER R3, R4 & R5	233A5202 81205	1	30-41-12 P006-12/ /B007	YC001-YC007
C00395		BACC18AD5 CB-WINDOW HEAT POWER R3, R4 & R5	233A5226 81205	1	30-41-12 P006-12/ /B007	YC008-YC030
C00396		BACC18AD5 CB-FIRE PROT DETECTION MA WRN & CONT	233A5202 81205	1	26-11-21 P006-02/ /A021	YC001-YC007
C00396		BACC18AD5 CB-FIRE PROT DETECTION MA WRN & CONT	233A5222 81205	1	26-11-21 P006-02/ /A021	YC008-YM670
C00397		BACC18AD2 CB-FUEL QTY 1	233A5202 81205	1	28-41-11 P006-03/ /A006	YC001-YC007
C00397		BACC18AD2 CB-FUEL QTY 1	233A5223 81205	1	28-41-11 P006-03/ /A006	YC008-YM670
C00398		BACC18AD2 CB-FUEL QTY 2	233A5202 81205	1	28-41-11 P006-03/ /A005	YC001-YC007
C00398		BACC18AD2 CB-FUEL QTY 2	233A5223 81205	1	28-41-11 P006-03/ /A005	YC008-YM670
C00399		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD LEFT	233A5202 81205	1	21-51-14 P006-04/ /A004	YC001-YC007

EQUIPMENT LIST

D280A103

Section C00300

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00399		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD LEFT	233A5224 81205	1	21-51-14 P006-04/ /A004	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00300
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00400		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD RIGHT	233A5202 81205	1	21-51-24 P006-04/ /B004	YC001-YC007
C00400		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD RIGHT	233A5224 81205	1	21-51-24 P006-04/ /B004	YC008-YM670
C00403		BACC18AD5 CB-FIRE PROTECTION DETECTION APU	233A5202 81205	1	26-11-31 P006-02/ /A023	YC001-YC007
C00403		BACC18AD5 CB-FIRE PROTECTION DETECTION APU	233A5222 81205	1	26-11-31 P006-02/ /A023	YC008-YM670
C00405		BACC18AD3 CB-FIRE PROTECTION DETECTION ENG 1	233A5202 81205	1	26-11-11 P006-02/ /A024	YC001-YC007
C00405		BACC18AD3 CB-FIRE PROTECTION DETECTION ENG 1	233A5222 81205	1	26-11-11 P006-02/ /A024	YC008-YM670
C00407		BACC18AD3 CB-FIRE PROTECTION DETECTION ENG 2	233A5202 81205	1	26-11-21 P006-02/ /A022	YC001-YC007
C00407		BACC18AD3 CB-FIRE PROTECTION DETECTION ENG 2	233A5222 81205	1	26-11-21 P006-02/ /A022	YC008-YM670
C00412		BACC18AD5 CB-INSTR XFR	233A5502 81205	1	34-21-14 P018-02/ /E002	YC001-YC007
C00412		BACC18AD5 CB-INSTR XFR	233A5522 81205	1	34-21-14 P018-02/ /E002	YC008-YM670
■ C00413		BACC18AD3 CB-BRT ENTRY LT	S281A601 07217	1	33-29-11 P091-00/ /E010	YC001-YC030, YK901-YK906
■ C00413		BACC18AD3 CB-BRT ENTRY LT	S281A601 07217	1	33-29-11 P091-00/ /E011	YC031-YC050, YK907-YM670
C00425		BACC18AD3 CB-ADIRU LEFT EXC	233A5502 81205	1	34-21-11 P018-02/ /E008	YC001-YC007
C00425		BACC18AD3 CB-ADIRU LEFT EXC	233A5522 81205	1	34-21-11 P018-02/ /E008	YC008-YM670
C00426		BACC18AD3 CB-ADIRU RIGHT EXC	233A5202 81205	1	34-21-21 P006-01/ /C015	YC001-YC007
C00426		BACC18AD3 CB-ADIRU RIGHT EXC	233A5221 81205	1	34-21-21 P006-01/ /C015	YC008-YM670
C00440		BACC18AD5 CB-FLIGHT CONTROL AUTO SPEED BRAKE	233A5202 81205	1	27-62-11 P006-02/ /B009	YC001-YC007

EQUIPMENT LIST

D280A103

Section C00400

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00440		BACC18AD5 CB-FLIGHT CONTROL AUTO SPEED BRAKE	233A5222 81205	1	27-62-11 P006-02/ /B009	YC008-YM670
C00442		BACC18AD2 CB-PASSENGER CABIN SIGNS PASS SIGN CONT	233A5502 81205	1	33-25-11 P018-03/ /D011	YC001-YC007
C00442		BACC18AD2 CB-PASSENGER CABIN SIGNS PASS SIGN CONT	233A5523 81205	1	33-25-11 P018-03/ /D011	YC008-YM670
C00451		BACC18AD3 CB-LANDING GEAR AURAL WARN	233A5202 81205	1	31-51-11 P006-03/ /D018	YC001-YC007
C00451		BACC18AD3 CB-LANDING GEAR AURAL WARN	233A5223 81205	1	31-51-11 P006-03/ /D018	YC008-YM670
C00452		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS APU	233A5202 81205	1	26-21-11 P006-02/ /B021	YC001-YC007
C00452		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS APU	233A5222 81205	1	26-21-11 P006-02/ /B021	YC008-YM670
C00456		BACC18AD3 CB-AFCS SYS A MACH TRIM AC	233A5502 81205	1	22-18-11 P018-01/ /C004	YC001-YC007
C00456		BACC18AD3 CB-AFCS SYS A MACH TRIM AC	233A5521 81205	1	22-18-11 P018-01/ /C004	YC008-YM670
C00457		BACC18AD3 CB-AFCS SYS A MACH TRIM DC	233A5502 81205	1	22-18-11 P018-01/ /D004	YC001-YC007
C00457		BACC18AD3 CB-AFCS SYS A MACH TRIM DC	233A5521 81205	1	22-18-11 P018-01/ /D004	YC008-YM670
C00458		BACC18AD2 CB-ENGINE 1 IGNITION RIGHT	233A5502 81205	1	74-11-11 P018-02/ /A001	YC001-YC007
C00458		BACC18AD2 CB-ENGINE 1 IGNITION RIGHT	233A5522 81205	1	74-11-11 P018-02/ /A001	YC008-YM670
C00459		BACC18AD2 CB-ENGINE 2 IGNITION RIGHT	233A5202 81205	1	74-11-11 P006-02/ /D004	YC001-YC007
C00459		BACC18AD2 CB-ENGINE 2 IGNITION RIGHT	233A5222 81205	1	74-11-11 P006-02/ /D004	YC008-YM670
C00468		BACC18AD2 CB-FLIGHT RECORDER DC	233A5502 81205	1	31-31-11 P018-02/ /C010	YC001-YC007
C00468		BACC18AD2 CB-FLIGHT RECORDER DC	233A5522 81205	1	31-31-11 P018-02/ /C010	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00400

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00471		BACC18AD10 CB-COMMUNICATIONS VHF 3	233A5502 81205	1	23-12-31 P018-02/ /D012	YC001-YC007
C00471		BACC18AD10 CB-COMMUNICATIONS VHF 3	233A5522 81205	1	23-12-31 P018-02/ /D012	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00400
Page 3 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00523		BACC18AD2 CB-HEATERS CAPT PITOT	233A5502 81205	1	30-31-11 P018-03/ /C001	YC001-YC007
C00523		BACC18AD2 CB-HEATERS CAPT PITOT	233A5523 81205	1	30-31-11 P018-03/ /C001	YC008-YM670
C00524		BACC18AD2 CB-HEATERS AUX PITOT	233A5502 81205	1	30-31-12 P018-03/ /D006	YC001-YC007
C00524		BACC18AD2 CB-HEATERS AUX PITOT	233A5523 81205	1	30-31-12 P018-03/ /D006	YC008-YM670
C00525		BACC18AD2 CB-HEATERS F/O PITOT	233A5502 81205	1	30-31-12 P018-03/ /D005	YC001-YC007
C00525		BACC18AD2 CB-HEATERS F/O PITOT	233A5523 81205	1	30-31-12 P018-03/ /D005	YC008-YM670
C00540		BACC18AD3 CB-FUEL SPAR VALVE IND	233A5202 81205	1	28-21-11 P006-03/ /B005	YC001-YC007
C00540		BACC18AD3 CB-FUEL SPAR VALVE IND	233A5223 81205	1	28-21-11 P006-03/ /B005	YC008-YM670
C00542		170-002-140 CB-EXTERNAL POWER DC (PROV)	284A0816 07217	1	24-31-11 J009-340/166/L015	ALL
C00544		BACC18AD5 CB-FLIGHT RECORDER POSITION SENSOR	233A5502 81205	1	31-31-14 P018-02/ /C008	YC001-YC007
C00544		BACC18AD5 CB-FLIGHT RECORDER POSITION SENSOR	233A5522 81205	1	31-31-14 P018-02/ /C008	YC008-YM670
C00549		BACC18AD3 CB-MACH WARN SYS -2	233A5202 81205	1	34-16-21 P006-01/ /B007	YC001-YC007
C00549		BACC18AD3 CB-MACH WARN SYS -2	233A5221 81205	1	34-16-21 P006-01/ /B007	YC008-YM670
C00555		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD CONT L	233A5202 81205	1	21-51-14 P006-04/ /A008	YC001-YC007
C00555		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD CONT L	233A5224 81205	1	21-51-14 P006-04/ /A008	YC008-YL430
C00560		BACC18AD5 CB-INTERPHONE POWER F/O DC 2	233A5202 81205	1	23-51-21 P006-02/ /C021	YC001-YC007
C00560		BACC18AD5 CB-INTERPHONE POWER F/O DC 2	233A5222 81205	1	23-51-21 P006-02/ /C021	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00500

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00561		BACC18AD5 CB-INTERPHONE POWER F/O BAT	233A5202 81205	1	23-51-21 P006-02/ /C022	YC001-YC007
C00561		BACC18AD5 CB-INTERPHONE POWER F/O BAT	233A5222 81205	1	23-51-21 P006-02/ /C022	YC008-YM670
C00566		BACC18AD3 CB-FLIGHT CONTROL FLAP LOAD RELIEF	233A5202 81205	1	27-54-11 P006-02/ /A006	YC001-YC007
C00566		BACC18AD3 CB-FLIGHT CONTROL FLAP LOAD RELIEF	233A5222 81205	1	27-54-11 P006-02/ /A006	YC008-YM670
C00569		BACC18AD2 CB-PROBE INDICATION CAPT	233A5202 81205	1	30-31-11 P006-03/ /F018	YC001-YC007
C00569		BACC18AD2 CB-PROBE INDICATION CAPT	233A5223 81205	1	30-31-11 P006-03/ /F018	YC008-YM670
C00570		BACC18AD2 CB-PROBE INDICATION F/O	233A5202 81205	1	30-31-12 P006-03/ /F016	YC001-YC007
C00570		BACC18AD2 CB-PROBE INDICATION F/O	233A5223 81205	1	30-31-12 P006-03/ /F016	YC008-YM670
C00583		BACC18AD3 CB-LANDING GEAR AUTOBRAKE BITE CONT 1	233A5202 81205	1	32-42-11 P006-03/ /A018	YC001-YC007
C00583		BACC18AD3 CB-LANDING GEAR AUTOBRAKE BITE CONT 1	233A5223 81205	1	32-42-11 P006-03/ /A018	YC008-YM670
■ C00590		BACC18AD10 CB-CEILING LT-R	S281A601 07217	1	33-22-11 P091-00/ /D011	YC001-YC030, YK901-YK906
■ C00590		BACC18AD10 CB-CEILING LT-R	S281A601 07217	1	33-22-11 P091-00/ /E009	YC031-YC050, YK907-YM670
■ C00591		BACC18AD10 CB-CEILING LT-L	S281A601 07217	1	33-22-11 P091-00/ /D012	YC001-YC030, YK901-YK906
■ C00591		BACC18AD10 CB-CEILING LT-L	S281A601 07217	1	33-22-11 P091-00/ /E010	YC031-YC050, YK907-YM670
■ C00594		BACC18AD7 CB-WINDOW LIGHT RIGHT	S281A601 07217	1	33-21-11 P092-00/ /E011	ALL

EQUIPMENT LIST

D280A103

Section C00500

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00629		BACC18AD2 CB-GND PROX WARN	233A5502 81205	1	34-49-11 P018-01/ /B007	YC001-YC007
C00629		BACC18AD2 CB-GND PROX WARN	233A5521 81205	1	34-49-11 P018-01/ /B007	YC008-YM670
C00644		BACC18AD2 CB-EXTERIOR LIGHTING LOGO ILLUM	233A5502 81205	1	33-49-11 P018-03/ /A015	YC001-YC007
C00644		BACC18AD2 CB-EXTERIOR LIGHTING LOGO ILLUM	233A5523 81205	1	33-49-11 P018-03/ /A015	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00600
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00700		BACC18AD7 CB-HEATERS DRAIN MAST AIR	233A5502 81205	1	30-71-11 P018-03/ /E004	YC001-YC007
C00700		BACC18AD7 CB-HEATERS DRAIN MAST AIR	233A5523 81205	1	30-71-11 P018-03/ /E004	YC008-YM670
C00701		BACC18AD5 CB-EMER PANEL LTG	233A5202 81205	1	33-11-30 P006-03/ /D008	YC001-YC007
C00701		BACC18AD5 CB-EMER PANEL LTG	233A5223 81205	1	33-11-30 P006-03/ /D008	YC008-YM670
C00716		BACC18AD5 CB-AFCS SYS B ENGAGE INTLK	233A5202 81205	1	22-11-12 P006-02/ /B004	YC001-YC007
C00716		BACC18AD5 CB-AFCS SYS B ENGAGE INTLK	233A5222 81205	1	22-11-12 P006-02/ /B004	YC008-YM670
C00721		BACC18AD10 CB-AUTOTHROTTLE DC 1	233A5502 81205	1	22-31-11 P018-01/ /E001	YC001-YC007
C00721		BACC18AD10 CB-AUTOTHROTTLE DC 1	233A5521 81205	1	22-31-11 P018-01/ /E001	YC008-YC030
C00721		BACC18AD7 CB-AUTOTHROTTLE DC 1	233A5521 81205	1	22-31-11 P018-01/ /E001	YC031-YM670
C00736		BACC18AD3 CB-MISC CLOCK DISPLAY	233A5202 81205	1	31-22-11 P006-03/ /A001	YC001-YC007
C00736		BACC18AD3 CB-MISC CLOCK DISPLAY	233A5223 81205	1	31-22-11 P006-03/ /A001	YC008-YM670
C00737		BACC18AD3 CB-MISC CLOCK	233A5202 81205	1	31-22-11 P006-03/ /A002	YC001-YC007
C00737		BACC18AD3 CB-MISC CLOCK	233A5223 81205	1	31-22-11 P006-03/ /A002	YC008-YM670
C00743		BACC18AD2 CB-ACARS MU DC	233A5202 81205	1	23-27-11 P006-01/ /E008	YC001-YC007
C00743		BACC18AD2 CB-ACARS MU DC	233A5221 81205	1	23-27-11 P006-01/ /E008	YC008-YC050
C00744		BACC18AD2 CB-ACARS MU AC	233A5202 81205	1	23-27-11 P006-01/ /E007	YC001-YC007
C00744		BACC18AD2 CB-ACARS MU AC	233A5221 81205	1	23-27-11 P006-01/ /E007	YC008-YK906

EQUIPMENT LIST

D280A103

Section C00700

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00751		BACC18AD2 CB-CONT CABIN LIGHTING PANEL FLOOD CONT	233A5202 81205	1	33-14-11 P006-03/ /A011	YC001-YC007
C00751		BACC18AD2 CB-CONT CABIN LIGHTING PANEL FLOOD CONT	233A5223 81205	1	33-14-11 P006-03/ /A011	YC008-YM670
█ C00767		BACC18AD5 CB-ELEC HYD PUMP CONTROL SYS A	S281A601 07217	1	29-11-12 P092-00/ /C008	ALL
█ C00768		BACC18AD5 CB-ELEC HYD PUMP CONTROL SYS B	S281A601 07217	1	29-11-12 P091-00/ /C008	ALL
█ C00773		BACC18AD10 CB-PASS READING LIGHTS-LEFT	S281A601 07217	1	33-23-12 P091-00/ /B007	ALL
█ C00774		BACC18AD10 CB-PASS READING LIGHTS-RIGHT	S281A601 07217	1	33-23-22 P092-00/ /B007	ALL
█ C00776		BACC18AD7 CB-WINDOW LIGHT LEFT	S281A601 07217	1	33-21-11 P092-00/ /E012	ALL
C00779		BACC18AD5 CB-HYD SYS ENG PUMP DEPRESS VALVE 1	233A5202 81205	1	29-11-11 P006-02/ /B015	YC001-YC007
C00779		BACC18AD5 CB-HYD SYS ENG PUMP DEPRESS VALVE 1	233A5222 81205	1	29-11-11 P006-02/ /B015	YC008-YM670
C00780		BACC18AD5 CB-HYD SYS ENG PUMP DEPRESS VALVE 2	233A5202 81205	1	29-11-11 P006-02/ /A017	YC001-YC007
C00780		BACC18AD5 CB-HYD SYS ENG PUMP DEPRESS VALVE 2	233A5222 81205	1	29-11-11 P006-02/ /A017	YC008-YM670
C00781		BACC18AD5 CB-HYD SYS LDG GR SYS XFR VALVE PRI	233A5202 81205	1	29-23-11 P006-02/ /C016	YC001-YC007
C00781		BACC18AD5 CB-HYD SYS LDG GR SYS XFR VALVE PRI	233A5222 81205	1	29-23-11 P006-02/ /C016	YC008-YM670
C00783		BACC18AD5 CB-OXYGEN PASS LEFT	233A5502 81205	1	35-21-11 P018-03/ /F010	YC001-YC007
C00783		BACC18AD5 CB-OXYGEN PASS LEFT	233A5523 81205	1	35-21-11 P018-03/ /F010	YC008-YM670
C00784		BACC18AD5 CB-OXYGEN PASS RIGHT	233A5502 81205	1	35-21-11 P018-03/ /F009	YC001-YC007
C00784		BACC18AD5 CB-OXYGEN PASS RIGHT	233A5523 81205	1	35-21-11 P018-03/ /F009	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00700

Page 2

Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00785		BACC18AD5 CB-OXYGEN MAN CONT	233A5502 81205	1	35-21-11 P018-03/ /F008	YC001-YC007
C00785		BACC18AD5 CB-OXYGEN MAN CONT	233A5523 81205	1	35-21-11 P018-03/ /F008	YC008-YM670
C00786		BACC18AD3 CB-FLIGHT CONTROL TRIM CONT AIL	233A5202 81205	1	27-11-11 P006-02/ /D018	YC001-YC007
C00786		BACC18AD3 CB-FLIGHT CONTROL TRIM CONT AIL	233A5222 81205	1	27-11-11 P006-02/ /D018	YC008-YM670
C00787		BACC18AD3 CB-FLIGHT CONTROL TRIM CONT RUD	233A5202 81205	1	27-21-11 P006-02/ /D019	YC001-YC007
C00787		BACC18AD3 CB-FLIGHT CONTROL TRIM CONT RUD	233A5222 81205	1	27-21-11 P006-02/ /D019	YC008-YM670
C00788		BACC18AD3 CB-FLIGHT CONTROL TRIM IND RUD	233A5202 81205	1	27-28-11 P006-02/ /D016	YC001-YC007
C00788		BACC18AD3 CB-FLIGHT CONTROL TRIM IND RUD	233A5222 81205	1	27-28-11 P006-02/ /D016	YC008-YM670
C00796		BACC18AD2 CB-AIR CONDITIONING BLEED AIR VALVES L	233A5202 81205	1	36-11-11 P006-04/ /A007	YC001-YC007
C00796		BACC18AD2 CB-AIR CONDITIONING BLEED AIR VALVES L	233A5224 81205	1	36-11-11 P006-04/ /A007	YC008-YM670
C00797		BACC18AD2 CB-AIR CONDITIONING BLEED AIR VALVES R	233A5202 81205	1	36-11-11 P006-04/ /B007	YC001-YC007
C00797		BACC18AD2 CB-AIR CONDITIONING BLEED AIR VALVES R	233A5224 81205	1	36-11-11 P006-04/ /B007	YC008-YM670
C00799		BACC18AD5 CB-HYD SYS LDG GR SYS XFR VALVE SEC	233A5202 81205	1	29-23-11 P006-02/ /C015	YC001-YC007
C00799		BACC18AD5 CB-HYD SYS LDG GR SYS XFR VALVE SEC	233A5222 81205	1	29-23-11 P006-02/ /C015	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00700

Page 3 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00801		1151968-1 CB-GENERATOR BREAKER 1	S281A0601 7217	1	24-22-11 P091-00/ /	ALL
C00802		1151968-1 CB-GENERATOR BREAKER 2	S281A0601 7217	1	24-22-21 P092-00/ /	ALL
C00803		1151968-1 CB-AUXILIARY POWER BREAKER	S281A0601 7217	1	24-22-31 P091-00/ /	ALL
C00804		1151968-1 CB-BUS TIE BREAKER 1	S281A0601 7217	1	24-23-11 P091-00/ /	ALL
C00805		1151968-1 CB-BUS TIE BREAKER 2	S281A0601 7217	1	24-23-21 P092-00/ /	ALL
C00806		BACC18AC10 CB-TRU 1	S281A0601 07217	1	24-32-11 P091-00/ /A006	ALL
C00807		BACC18AC10 CB-TRU 2	S281A0601 07217	1	24-32-11 P092-00/ /A004	ALL
C00808		BACC18AC10 CB-TRU 3	S281A0601 07217	1	24-32-11 P092-00/ /A006	ALL
C00809		BACC18AC7 CB-BAT CHGR	S281A0601 07217	1	24-31-11 P092-00/ /E001	ALL
■ C00812		BACC18AE25 CB-EXT PWR 1	S281A601 07217	1	24-52-11 P092-00/ /A018	ALL
■ C00813		BACC18AE25 CB-GND SERV 1	S281A601 07217	1	24-52-11 P091-00/ /F001	YC001-YK906
■ C00813		BACC18AE25 CB-GND SERV 1	S281A601 07217	1	24-52-11 P091-00/ /A014	YK907-YM670
■ C00815		BACC18AE35 CB-MAIN BUS 1	S281A601 07217	1	24-51-11 P091-00/ /F006	ALL
■ C00817		BACC18AE35 CB-MAIN BUS 2	S281A601 07217	1	24-51-21 P092-00/ /F006	ALL
C00826		BACC18AC7 CB-FUEL BOOST PUMP TANK 1 AFT	S281A601 81205	1	28-23-11 P092-00/ /D002	YC001-YK906
C00826		BACC18AC7 CB-FUEL BOOST PUMP TANK 1 AFT	S281A601 81205	1	28-23-11 P092-00/ /D001	YK907-YM670
C00827		BACC18AC7 CB-FUEL BOOST PUMP TANK 1 FWD	S281A601 81205	1	28-23-11 P091-00/ /D002	YC001-YK906

EQUIPMENT LIST

D280A103

Section C00800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00827		BACC18AC7 CB-FUEL BOOST PUMP TANK 1 FWD	S281A601 81205	1	28-23-11 P091-00/ /D001	YK907-YM670
C00828		BACC18AC7 CB-FUEL BOOST PUMP TANK 2 AFT	S281A601 81205	1	28-23-11 P091-00/ /D004	YC001-YK906
C00828		BACC18AC7 CB-FUEL BOOST PUMP TANK 2 AFT	S281A601 81205	1	28-23-11 P091-00/ /D003	YK907-YM670
C00829		BACC18AC7 CB-FUEL BOOST PUMP TANK 2 FWD	S281A601 81205	1	28-23-11 P092-00/ /D004	YC001-YK906
C00829		BACC18AC7 CB-FUEL BOOST PUMP TANK 2 FWD	S281A601 81205	1	28-23-11 P092-00/ /D003	YK907-YM670
C00836		BACC18AC7 CB-EQPT CLG EXH FAN PWR-NORM	S281A601 07217	1	21-27-21 P091-00/ /E001	ALL
C00837		BACC18AC7 CB-EQPT CLG EXH FAN PWR-ALTN	S281A601 07217	1	21-27-21 P092-00/ /A010	YC001-YK906
C00837		BACC18AC7 CB-EQPT CLG EXH FAN PWR-ALTN	S281A601 07217	1	21-27-21 P092-00/ /D012	YK907-YM670
C00839	9	BACC18AC5 CB-COMM HF 1 (SB 23-1299)	233A5522 81205	1	23-11-11 P018-02/ /E011	YK907-YK909
C00839		BACC18AC5 CB-COMMUNICATIONS HF 1	233A5502 81205	1	23-11-11 P018-02/ /E011	YC001-YC007
C00839		BACC18AC5 CB-COMMUNICATIONS HF 1	233A5522 81205	1	23-11-11 P018-02/ /E011	YC008-YC050, YK910-YK920, YL421-YL430
C00839		BACC18AC5 CB-COMMUNICATIONS HF 1(INOP)	233A5522 81205	1	23-11-11 P018-02/ /E011	YK907-YK909, YL401
C00839		BACC18AC5 CB-COMMUNICATIONS HF 1 (INOP)	233A5522 81205	1	23-11-11 P018-02/ /E011	YM643-YM670
C00840		BACC18AE15 CB-FLIGHT CONTROL STAB TRIM ACTUATOR	233A5202 81205	1	27-41-11 P006-02/ /D010	YC004-YC007
C00840		BACC18AE15 CB-FLIGHT CONTROL STAB TRIM ACTUATOR	233A5222 81205	1	27-41-11 P006-02/ /D010	YC008-YM670
C00840	1	BACC18AC15 CB-FLIGHT CONTROL STAB TRIM ACTUATOR	233A5202 81205	1	27-41-11 P006-02/ /D010	YC001-YC003

EQUIPMENT LIST

D280A103

Section C00800

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00840	2	BACC18AE15 CB-FLIGHT CONTROL STAB TRIM ACTUATOR	233A5202 81205	1	27-41-11 P006-02/ /D010	YC001-YC003
C00841		BACC18AC10 CB-FLIGHT CONTROL ALTN T.E. FLAP DRIVE	233A5202 81205	1	27-53-12 P006-02/ /D013	YC001-YC007
C00841		BACC18AC10 CB-FLIGHT CONTROL ALTN T.E. FLAP DRIVE	233A5222 81205	1	27-53-12 P006-02/ /D013	YC008-YM670
C00845		BACC18AC10 CB-FUEL BOOST PUMP CTR TANK LEFT	S281A601 81205	1	28-23-11 P091-00/ /D006	YC001-YK906
C00845		BACC18AC10 CB-FUEL BOOST PUMP CTR TANK LEFT	S281A601 81205	1	28-23-11 P091-00/ /D005	YK907-YM670
C00846		BACC18AC10 CB-FUEL BOOST PUMP CTR TANK RIGHT	S281A601 81205	1	28-23-11 P092-00/ /D006	YC001-YK906
C00846		BACC18AC10 CB-FUEL BOOST PUMP CTR TANK RIGHT	S281A601 81205	1	28-23-11 P092-00/ /D005	YK907-YM670
C00849		BACC18AE15 CB-AFCS STABILIZER TRIM	233A5502 81205	1	22-13-11 P018-01/ /C002	YC004-YC007
C00849		BACC18AE15 CB-AFCS STABILIZER TRIM	233A5521 81205	1	22-13-11 P018-01/ /C002	YC008-YM670
C00849	1	BACC18AE15 CB-AFCS STABILIZER TRIM	233A5502 81205	1	22-13-11 P018-01/ /C002	YC001-YC003
C00849	2	BACC18AC15 CB-AFCS STABILIZER TRIM	233A5502 81205	1	22-13-11 P018-01/ /C002	YC001-YC003
C00857		BACC18AC5 CB-COMMUNICATIONS HF 2(INOP)	233A5221 81205	1	23-11-21 P006-01/ /D002	YK907-YK909, YL401, YM643- YM670
C00857		BACC18AC5 CB-COMMUNICATIONS HF 2(PROV)	233A5221 81205	1	23-11-21 P006-01/ /D002	YK910
C00857		BACC18AC5 CB-COMMUNICATIONS HF 2 (INOP)	233A5221 81205	1	23-11-21 P006-01/ /D002	YK911-YK920, YL421-YL430
C00873		BACC18AC7 CB-POT WATER COMPRESSOR	S281A601	0	38-41-13 P091-00/ /A018	YC001-YC030, YK901-YK906
C00873		BACC18AC7 CB-POT WATER COMPRESSOR	S281A601	0	38-41-13 P091-00/ /D011	YC031-YC050, YK907-YM670

EQUIPMENT LIST

D280A103

Section C00800

Page 3

Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
■ C00881		10-60806-1040 CB-ELEC HYD PUMP SYS A	S281A601 07217	1	29-11-12 P092-00/ /F003	ALL
■ C00882		10-60806-1040 CB-ELEC HYD PUMP SYS B	S281A601 07217	1	29-11-12 P091-00/ /F003	ALL
C00884		BACC18AE20 CB-AC RECIRC RIGHT FAN CABIN AIR	233A5202 81205	1	21-25-10 P006-04/ /E004	YC001-YC007
C00884		BACC18AE20 CB-AC RECIRC FAN RIGHT CABIN AIR	233A5224 81205	1	21-25-10 P006-04/ /E004	YC008-YM670

EQUIPMENT LIST

D280A103

Section C00800
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00907		BACC18AC15 CB-AFT CARGO LOADER DRIVE (INOP)	S281A601 81205	1	25-51-21 P091-00/ /E008	YC001-YC050
C00907		BACC18AC15 CB-AFT CARGO LOADER DRIVE	S281A601 81205	1	25-51-21 P091-00/ /E008	YK901-YK906, YK918
C00907		BACC18AC15 CB-AFT CARGO LOADER DRIVE	S281A601 81205	1	25-51-21 P091-00/ /A017	YK907-YK917, YK919-YM670
C00911		BACC18AE20 CB-A/C RECIRC FAN LEFT CABIN AIR	233A5502 81205	1	21-25-11 P018-03/ /E007	YC001-YC007
C00911		BACC18AE20 CB-A/C RECIRC FAN LEFT CABIN AIR	233A5523 81205	1	21-25-11 P018-03/ /E007	YC008-YL430
C00912		BACC18AE35 CB-GALLEY BUS A	S281A601 07217	1	25-31-11 P092-00/ /F007	YC001-YK911, YL421-YL426
C00912		10-60806-1050 CB-GALLEY BUS A	S281A601 07217	1	25-31-11 P092-00/ /F007	YK912-YL401, YL427-YL430, YM652
C00912		10-60806-1050 CB-GALLEY BUS A (COLLAR & INOP)	S281A601 07217	1	25-31-11 P092-00/ /F007	YM643-YM651, YM653-YM670
█ C00913		BACC18AE35 CB-GALLEY BUS C (COLLAR AND INOP)	S281A601 07217	1	25-31-11 P091-00/ /F007	YK901-YK906
█ C00913		BACC18AE35-COLLAR-INOP- CB-GALLEY BUS C	S281A601 07217	1	25-31-11 P091-00/ /F007	YK907-YK909
█ C00913		BACC18AE35 CB-GALLEY BUS C	S281A601 07217	1	25-31-11 P091-00/ /F007	YK910-YM670
█ C00914		BACC18AE35 CB-GALLEY BUS B	S281A601 07217	1	25-31-11 P092-00/ /F007	YC001-YC050
█ C00914		BACC18AE35 CB-GALLEY BUS B	S281A601 07217	1	25-31-11 P092-00/ /F008	YK901-YM670
C00915		10-60806-1050 CB-GALLEY BUS D	S281A601 07217	1	25-31-11 P091-00/ /F008	YC001-YL430
C00915		10-6080-1050 CB-GALLEY BUS D	S281A601 07217	1	25-31-11 P091-00/ /F008	YM643-YM670
█ C00922		BACC18AC7 CB-AUX BAT CHGR	S281A601 07217	1	24-31-11 P091-00/ /E003	ALL

EQUIPMENT LIST

D280A103

Section C00900

Page 1

Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00923		BACC18AD3 CB-DATA LOADER	233A5502 81205	1	34-61-18 P018-02/ /A009	YC001-YC007
C00923		BACC18AD3 CB-DATA LOADER	233A5522 81205	1	34-61-18 P018-02/ /A009	YC008-YC011
C00923		BACC18AD3 CB-DATA LOADER	233A5522 81205	1	31-32-15 P018-02/ /A009	YC012-YM670
C00934		BACC18AC7 CB-EQPT CLG SPLY FAN PWR-NORM	S281A601 07217	1	21-27-31 P092-00/ /A008	YC001-YK906
C00934		BACC18AC7 CB-EQPT CLG SPLY FAN PWR-NORM	S281A601 07217	1	21-27-31 P092-00/ /D010	YK907-YM670
C00935		BACC18AC7 CB-EQPT CLG SPLY FAN PWR-ALTN	S281A601 07217	1	21-27-31 P091-00/ /A008	ALL
■ C00936		BACC18AD3 CB-EXT PWR BPCU	S281A601 81205	1	24-41-11 P092-00/ /A012	ALL
■ C00937		1151970-1 CB-EXTERNAL POWER CONTRACTOR	S281A601 7217	1	24-41-11 P092-00/ /	ALL
■ C00941		BACC18AC10 CB-TRU 3 ALTN	S281A601 07217	1	24-32-11 P091-00/ /A004	ALL

EQUIPMENT LIST

D280A103

Section C00900

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01001		BACC18AD2 CB-ANTI-ICE & RAIN ENG 1 COWL AI VALVE	233A5502 81205	1	30-21-11 P018-03/ /A007	YC001-YC007
C01001		BACC18AD2 CB-ANTI-ICE & RAIN ENG 1 COWL AI VALVE	233A5523 81205	1	30-21-11 P018-03/ /A007	YC008-YM670
C01002		BACC18AD2 CB-ANTI-ICE & RAIN ENG 2 COWL AI VALVE	233A5502 81205	1	30-21-11 P018-03/ /B007	YC001-YC007
C01002		BACC18AD2 CB-ANTI-ICE & RAIN ENG 2 COWL AI VALVE	233A5523 81205	1	30-21-11 P018-03/ /B007	YC008-YM670
C01003		BACC18AD2 CB-ENGINE 1 THRUST REVERSER IND	233A5502 81205	1	78-36-11 P018-02/ /B004	YC001-YC007
C01003		BACC18AD2 CB-ENGINE 1 THRUST REVERSER IND	233A5522 81205	1	78-36-11 P018-02/ /B004	YC008-YM670
C01004		BACC18AD2 CB-ENGINE 2 THRUST REVERSER IND	233A5202 81205	1	78-36-21 P006-02/ /C008	YC001-YC007
C01004		BACC18AD2 CB-ENGINE 2 THRUST REVERSER IND	233A5222 81205	1	78-36-21 P006-02/ /C008	YC008-YM670
C01007		BACC18AD3 CB-ADIRU LEFT AC	233A5502 81205	1	34-21-11 P018-01/ /E007	YC001-YC007
C01007		BACC18AD3 CB-ADIRU LEFT AC	233A5521 81205	1	34-21-11 P018-01/ /E007	YC008-YM670
C01008		BACC18AD3 CB-ADIRU RIGHT AC	233A5202 81205	1	34-21-21 P006-01/ /C014	YC001-YC007
C01008		BACC18AD3 CB-ADIRU RIGHT AC	233A5221 81205	1	34-21-21 P006-01/ /C014	YC008-YM670
C01009		BACC18AD10 CB-ADIRU LEFT DC	233A5502 81205	1	34-21-11 P018-01/ /E005	YC001-YC007
C01009		BACC18AD10 CB-ADIRU LEFT DC	233A5521 81205	1	34-21-11 P018-01/ /E005	YC008-YM670
C01010		BACC18AD10 CB-ADIRU RIGHT DC	233A5202 81205	1	34-21-21 P006-01/ /C017	YC001-YC007
C01010		BACC18AD10 CB-ADIRU RIGHT DC	233A5221 81205	1	34-21-21 P006-01/ /C017	YC008-YM670
C01015		BACC18AD2 CB-AIR CONDITIONING RECIRC FAN CONT	233A5224 81205	1	21-25-10 P006-04/ /E001	YM643-YM670

EQUIPMENT LIST

D280A103

Section C01000

Page 1

Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01017		BACC18AD3 CB-FMCS CMPTR 1	233A5502 81205	1	34-61-11 P018-02/ /A006	YC001-YC007
C01017		BACC18AD3 CB-FMCS CMPTR 1	233A5522 81205	1	34-61-11 P018-02/ /A006	YC008-YM670
C01021		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS ALTN L	233A5202 81205	1	26-21-11 P006-02/ /B024	YC001-YC007
C01021		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS ALTN L	233A5222 81205	1	26-21-11 P006-02/ /B024	YC008-YM670
C01022		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS ALTN R	233A5202 81205	1	26-21-11 P006-02/ /B023	YC001-YC007
C01022		BACC18AD5 CB-FIRE PROTECTION EXTINGUISHERS ALTN R	233A5222 81205	1	26-21-11 P006-02/ /B023	YC008-YM670
C01023		BACC18AD2 CB-A/C RECIRC FAN RIGHT CONT.	233A5202 81205	1	21-25-11 P006-04/ /E002	YC001-YC007
C01023		BACC18AD2 CB-A/C RECIRC FAN RIGHT CONT.	233A5224 81205	1	21-25-11 P006-04/ /E002	YC008-YL430
C01027		BACC18AD2 CB-LANDING GEAR NOSE GEAR STEER	233A5202 81205	1	32-51-11 P006-03/ /D017	YC001-YC007
C01027		BACC18AD2 CB-LANDING GEAR NOSE GEAR STEER	233A5223 81205	1	32-51-11 P006-03/ /D017	YC008-YM670
C01037		BACC18AD3 CB-AFCS SYS B MACH TRIM AC	233A5202 81205	1	22-18-11 P006-02/ /C001	YC001-YC007
C01037		BACC18AD3 CB-AFCS SYS B MACH TRIM AC	233A5222 81205	1	22-18-11 P006-02/ /C001	YC008-YM670
C01041		BACC18Z1R CB-AFCS SYS A SNSR EXC AC	233A5502 81205	1	22-11-11 P018-01/ /C005	YC001-YC007
C01041		BACC18Z1R CB-AFCS SYS A SNSR EXC AC	233A5521 81205	1	22-11-11 P018-01/ /C005	YC008-YM670
C01042		BACC18Z1R CB-AFCS SYS B SNSR EXC AC	233A5202 81205	1	22-11-11 P006-02/ /C002	YC001-YC007
C01042		BACC18Z1R CB-AFCS SYS B SNSR EXC AC	233A5222 81205	1	22-11-11 P006-02/ /C002	YC008-YM670
C01044		BACC18AD5 CB-AFCS MCP DC 1	233A5502 81205	1	22-11-12 P018-01/ /D005	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01044		BACC18AD5 CB-AFCS MCP DC 1	233A5521 81205	1	22-11-12 P018-01/ /D005	YC008-YM670
C01045		BACC18AD5 CB-AFCS SYS A FCC DC	233A5502 81205	1	22-11-11 P018-01/ /D002	YC001-YC007
C01045		BACC18AD5 CB-AFCS SYS A FCC DC	233A5521 81205	1	22-11-11 P018-01/ /D002	YC008-YM670
C01046		BACC18AD5 CB-AFCS SYS B FCC DC	233A5202 81205	1	22-11-11 P006-02/ /B003	YC001-YC007
C01046		BACC18AD5 CB-AFCS SYS B FCC DC	233A5222 81205	1	22-11-11 P006-02/ /B003	YC008-YM670
C01047		BACC18AD5 CB-AFCS MCP DC 2	233A5202 81205	1	22-11-12 P006-02/ /C003	YC001-YC007
C01047		BACC18AD5 CB-AFCS MCP DC 2	233A5222 81205	1	22-11-12 P006-02/ /C003	YC008-YM670
C01048		BACC18AD5 CB-AFCS SYS A ENGAGE INTLK	233A5502 81205	1	22-11-12 P018-01/ /D003	YC001-YC007
C01048		BACC18AD5 CB-AFCS SYS A ENGAGE INTLK	233A5521 81205	1	22-11-12 P018-01/ /D003	YC008-YM670
C01049		BACC18AD3 CB-AFCS SYS A WARN LIGHT (BAT)	233A5502 81205	1	22-14-11 P018-01/ /D001	YC001-YC007
C01049		BACC18AD3 CB-AFCS SYS A WARN LIGHT (BAT)	233A5521 81205	1	22-14-11 P018-01/ /D001	YC008-YM670
■ C01053		BACC18AD2 CB-INVERTER VOLTS	S281A601 07217	1	24-28-11 M01720/ /A002	ALL
C01064		BACC18AD3 CB-AFCS SYS B MACH TRIM DC	233A5202 81205	1	22-18-11 P006-02/ /B002	YC001-YC007
C01064		BACC18AD3 CB-AFCS SYS B MACH TRIM DC	233A5222 81205	1	22-18-11 P006-02/ /B002	YC008-YM670
■ C01065		BACC18R60C CB-DC BUS 1 XFR	S281A601 07217	1	24-32-11 P091-00/ /A001	ALL
■ C01066		BACC18R60C CB-DC BUS 2 XFR	S281A601 07217	1	24-32-11 P092-00/ /A001	ALL
C01068		BACC18AD5 CB-FLIGHT CONTROL AUTOSLAT DC 1	233A5202 81205	1	27-83-11 P006-02/ /C014	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01068		BACC18AD5 CB-FLIGHT CONTROL AUTOSLAT DC 1	233A5222 81205	1	27-83-11 P006-02/ /C014	YC008-YM670
C01070		BACC18AD5 CB-FLIGHT CONTROL AUTOSLAT DC 2	233A5202 81205	1	27-83-21 P006-02/ /B014	YC001-YC007
C01070		BACC18AD5 CB-FLIGHT CONTROL AUTOSLAT DC 2	233A5222 81205	1	27-83-21 P006-02/ /B014	YC008-YM670
C01071		BACC18AD5 CB-HEATERS ALPHA VANE RIGHT	233A5502 81205	1	30-31-12 P018-03/ /D003	YC001-YC007
C01071		BACC18AD5 CB-HEATERS ALPHA VANE RIGHT	233A5523 81205	1	30-31-12 P018-03/ /D003	YC008-YM670
C01072		BACC18AD5 CB-HEATERS ALPHA VANE LEFT	233A5502 81205	1	30-31-11 P018-03/ /C003	YC001-YC007
C01072		BACC18AD5 CB-HEATERS ALPHA VANE LEFT	233A5523 81205	1	30-31-11 P018-03/ /C003	YC008-YM670
C01073		BACC18AD5 CB-LAVATORY WATER HEATER D	233A5202 81205	1	38-21-11 P018-03/ /F014	YC001-YC007
C01073		BACC18AD5 CB-LAVATORY WATER HEATER D	233A5523 81205	1	38-21-11 P018-03/ /F014	YC008-YM670
C01074		BACC18AD5 CB-FLIGHT CONT SHUTOFF VALVES FLT CONT	233A5202 81205	1	27-23-11 P006-02/ /C013	YC001-YC007
C01074		BACC18AD5 CB-FLIGHT CONT SHUTOFF VALVES FLT CONT	233A5222 81205	1	27-23-11 P006-02/ /C013	YC008-YM670
C01076		BACC18AD2 CB-ENGINE VIB MON	233A5202 81205	1	77-31-11 P006-02/ /A002	YC001-YC007
C01076		BACC18AD2 CB-ENGINE VIB MON	233A5222 81205	1	77-31-11 P006-02/ /A002	YC008-YM670
C01081		BACC18AD5 CB-HYDRAULIC SYSTEM PTU VALVE CONT 1	233A5202 81205	1	29-25-11 P006-02/ /A015	YC001-YC007
C01081		BACC18AD5 CB-HYDRAULIC SYSTEM PTU VALVE CONT 1	233A5222 81205	1	29-25-11 P006-02/ /A015	YC008-YM670
C01085		BACC18AD5 CB-HYDRAULIC SYSTEM PTU VALVE CONT 2	233A5202 81205	1	29-25-11 P006-02/ /A016	YC001-YC007
C01085		BACC18AD5 CB-HYDRAULIC SYSTEM PTU VALVE CONT 2	233A5222 81205	1	29-25-11 P006-02/ /A016	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01000

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01096		BACC18AD5 CB-LAVATORY WATER HEATER E	233A5202 81205	1	38-21-11 P018-03/ /F015	YC001-YC007
C01096		BACC18AD5 CB-LAVATORY WATER HEATER E	233A5523 81205	1	38-21-11 P018-03/ /F015	YC008-YM670
C01097		BACC18AD7 CB-ELEX PANEL LIGHTS AFT F/O	233A6301 81205	1	33-11-41 P008-00/ /	ALL

EQUIPMENT LIST

D280A103

Section C01000
Page 5 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01101		BACC18AD7 CB-ENTERTAINMENT MUX	65C25704 81205	1	23-34-01 P006-01/ /C010	YC001-YC007
C01101		BACC18AD7 CB-ENTERTAINMENT MUX	233A5221 81205	1	23-34-01 P006-01/ /C010	YC008-YC050
C01103		BACC18AD2 CB-ENGINE 1 START VALVE	233A5502 81205	1	80-11-11 P018-02/ /B008	YC001-YC007
C01103		BACC18AD2 CB-ENGINE 1 START VALVE	233A5522 81205	1	80-11-11 P018-02/ /B008	YC008-YM670
C01115		BACC18AD7 CB-ELEX PANEL LIGHTS AFT CENTER	233A6301 81205	1	33-11-41 P008-00/ /	ALL
C01116		BACC18AD2 CB-EQPT COOLING SUPPLY FAN CONT-NORMAL	233A5202 81205	1	21-27-31 P006-04/ /C012	YC001-YC007
C01116		BACC18AD2 CB-EQPT COOLING SUPPLY FAN CONT-NORMAL	233A5224 81205	1	21-27-31 P006-04/ /C012	YC008-YM670
C01117		BACC18AD2 CB-EQPT COOLING SUPPLY FAN CONTROL-ALTN	233A5202 81205	1	21-27-31 P006-04/ /C013	YC001-YC007
C01117		BACC18AD2 CB-EQPT COOLING SUPPLY FAN CONTROL-ALTN	233A5224 81205	1	21-27-31 P006-04/ /C013	YC008-YM670
C01125		BACC18AD2 CB-LAVATORY SMOKE	233A5502 81205	1	26-14-11 P018-03/ /E012	YC001-YC007
C01125		BACC18AD2 CB-LAVATORY SMOKE	233A5523 81205	1	26-14-11 P018-03/ /E012	YC008-YM670
C01139		BACC18AD2 CB-AFT CARGO LOADER CONT	233A5202 81205	1	25-51-21 P006-11/ /D008	YC001-YC007, YK918
C01139		BACC18AD2 CB-AFT CARGO LOADER CONT (INOP)	233A5225 81205	1	25-51-21 P006-11/ /D008	YC008-YC050
C01139		BACC18AD2 CB-AFT CARGO LOADER CONT	233A5225 81205	1	25-51-21 P006-11/ /D008	YK901-YK917, YK919-YM670
C01141		BACC18AD10 CB-AUTOTHROTTLE DC 2	233A5502 81205	1	22-31-11 P018-01/ /E003	YC001-YC007
C01141		BACC18AD10 CB-AUTOTHROTTLE DC 2	233A5521 81205	1	22-31-11 P018-01/ /E003	YC008-YC030
C01152		BACC18AD10 CB-PASS READING LIGHTS-LEFT STA768-880	S281A601 07217	1	33-23-12 P091-00/ /B008	YC001-YL430

EQUIPMENT LIST

D280A103

Section C01100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
I C01153		BACC18AC10 CB-PASS READING LIGHTS-L STA880-937	S281A601 07217	1	33-23-21 P091-00/ /B009	YC001-YL430
C01156		BACC18AD2 CB-A/C RECIRC FAN LEFT CONT	233A5502 81205	1	21-25-11 P018-03/ /E009	YC001-YC007
C01156		BACC18AD2 CB-A/C RECIRC FAN LEFT CONT	233A5523 81205	1	21-25-11 P018-03/ /E009	YC008-YL430
C01157		BACC18AD2 CB-A/C TEMP CONT VALVE CLOSE LEFT	233A5202 81205	1	21-51-12 P006-04/ /A001	YC001-YC007
C01157		BACC18AD2 CB-A/C TEMP CONT VALVE CLOSE LEFT	233A5224 81205	1	21-51-12 P006-04/ /A001	YC008-YL430
C01158		BACC18AD2 CB-AIR CONDITIONING PACK CONTROL LEFT DC	233A5202 81205	1	21-51-12 P006-04/ /A009	YC001-YC007
C01158		BACC18AD2 CB-AIR CONDITIONING PACK CONTROL LEFT DC	233A5224 81205	1	21-51-12 P006-04/ /A009	YC008-YL430
C01159		BACC18AD2 CB-AIR CONDITIONING PACK CONTROL LEFT AC	233A5202 81205	1	21-51-12 P006-04/ /A011	YC001-YC007
C01159		BACC18AD2 CB-AIR CONDITIONING PACK CONTROL LEFT AC	233A5224 81205	1	21-51-12 P006-04/ /A011	YC008-YL430
C01160		BACC18AD2 CB-A/C TEMP CONT VALVE CLOSE RIGHT	233A5202 81205	1	21-51-22 P006-04/ /B001	YC001-YC007
C01160		BACC18AD2 CB-A/C TEMP CONT VALVE CLOSE RIGHT	233A5224 81205	1	21-51-22 P006-04/ /B001	YC008-YL430
C01161		BACC18AD2 CB-AIR CONDITIONING PACK CONT RIGHT DC	237A5202 81205	1	21-51-22 P006-04/ /B009	YC001-YC007
C01161		BACC18AD2 CB-AIR CONDITIONING PACK CONT RIGHT DC	233A5224 81205	1	21-51-22 P006-04/ /B009	YC008-YL430
C01162		BACC18AD2 CB-AIR CONDITIONING PACK CONT RIGHT AC	233A5202 81205	1	21-51-22 P006-04/ /B011	YC001-YC007
C01162		BACC18AD2 CB-AIR CONDITIONING PACK CONT RIGHT AC	233A5224 81205	1	21-51-22 P006-04/ /B011	YC008-YL430
C01163		BACC18AD2 CB-A/C ZONE TEMP VALVE/FAN CONT FLT DECK	233A5202 81205	1	21-61-11 P006-04/ /B003	YC001-YC007
C01163		BACC18AD2 CB-A/C ZONE TEMP VALVE/FAN CONT FLT DECK	233A5224 81205	1	21-61-11 P006-04/ /B003	YC008-YL430

EQUIPMENT LIST

D280A103

Section C01100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01164		BACC18AD2 CB-A/C ZONE TEMP DUCT OVHT FLT DECK	233A5202 81205	1	21-61-11 P006-04/ /C004	YC001-YC007
C01164		BACC18AD2 CB-A/C ZONE TEMP DUCT OVHT FLT DECK	233A5224 81205	1	21-61-11 P006-04/ /C004	YC008-YL430
C01166		BACC18AD2 CB-A/C ZONE TEMP DUCT OVHT FWD PASS	233A5202 81205	1	21-61-13 P006-04/ /C003	YC001-YC007
C01166		BACC18AD2 CB-A/C ZONE TEMP DUCT OVHT FWD PASS	233A5224 81205	1	21-61-13 P006-04/ /C003	YC008-YL430
C01167		BACC18AD2 CB-A/C ZONE TEMP VALVE/FAN CONT FWD PASS	233A5202 81205	1	21-61-13 P006-04/ /B002	YC001-YC007
C01167		BACC18AD2 CB-A/C ZONE TEMP VALVE/FAN CONT FWD PASS	233A5224 81205	1	21-61-13 P006-04/ /B002	YC008-YL430
C01169		BACC18AD2 CB-A/C ZONE TEMP DUCT OVHT AFT PASS	233A5202 81205	1	21-61-14 P006-04/ /C002	YC001-YC007
C01169		BACC18AD2 CB-A/C ZONE TEMP DUCT OVHT AFT PASS	233A5224 81205	1	21-61-14 P006-04/ /C002	YC008-YL430
C01170		BACC18AD2 CB-A/C ZONE TEMP VALVE/FAN CONT AFT PASS	233A5202 81205	1	21-61-14 P006-04/ /A003	YC001-YC007
C01170		BACC18AD2 CB-A/C ZONE TEMP VALVE/FAN CONT AFT PASS	233A5224 81205	1	21-61-14 P006-04/ /A003	YC008-YL430
C01172		BACC18AD5 CB-AIR CONDITIONING TRIM AIR PRESS	233A5202 81205	1	21-61-15 P006-04/ /D009	YC001-YC007
C01172		BACC18AD5 CB-AIR CONDITIONING TRIM AIR PRESS	233A5224 81205	1	21-61-15 P006-04/ /D009	YC008-YL430
C01176		BACC18AD2 CB-A/C PACK/ENGINE BLEED AIR OVHT LEFT	233A5202 81205	1	21-51-15 P006-04/ /C008	YC001-YC007
C01176		BACC18AD2 CB-A/C PACK/ENGINE BLEED AIR OVHT LEFT	233A5224 81205	1	21-51-15 P006-04/ /C008	YC008-YL430
C01177		BACC18AD2 CB-A/C PACK/ENGINE BLEED AIR OVHT RIGHT	233A5202 81205	1	21-51-25 P006-04/ /C007	YC001-YC007
C01177		BACC18AD2 CB-A/C PACK/ENGINE BLEED AIR OVHT RIGHT	233A5224 81205	1	21-51-25 P006-04/ /C007	YC008-YL430
C01178		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD CONT R	233A5202 81205	1	21-51-24 P006-04/ /B008	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01100

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01178		BACC18AD2 CB-AIR CONDITIONING RAM AIR MOD CONT R	233A5224 81205	1	21-51-24 P006-04/ /B008	YC008-YL430
C01179		BACC18AD3 CB-INDICATOR MASTER DIM SECT 7	233A5202 81205	1	33-18-62 P006-03/ /F013	YC001-YC007
C01179		BACC18AD3 CB-INDICATOR MASTER DIM SECT 7	233A5223 81205	1	33-18-62 P006-03/ /F013	YC008-YM670
C01180		BACC18AD3 CB-INDICATOR MASTER DIM SECT 8	233A5202 81205	1	33-18-62 P006-03/ /F014	YC001-YC007
C01180		BACC18AD3 CB-INDICATOR MASTER DIM SECT 8	233A5223 81205	1	33-18-62 P006-03/ /F014	YC008-YM670
C01192		BACC18AD3 CB-FMCS BITE DC	233A5502 81205	1	34-61-22 P018-02/ /B010	YC001-YC007
C01192		BACC18AD3 CB-FMCS BITE DC	233A5522 81205	1	34-61-22 P018-02/ /B010	YC008-YM670
C01194		BACC18AD2 CB-ATC ANT SWITCH	233A5202 81205	1	34-53-31 P006-01/ /E014	YC001-YC007
C01194		BACC18AD2 CB-ATC ANT SWITCH	233A5221 81205	1	34-53-31 P006-01/ /E014	YC008-YM670
C01195		BACC18AD5 CB-TCAS	233A5502 81205	1	34-45-11 P018-01/ /B006	YC001-YC007
C01195		BACC18AD5 CB-TCAS	233A5521 81205	1	34-45-11 P018-01/ /B006	YC008-YM670
C01196		BACC18AD2 CB-ACMS	233A5221 81205	1	31-35-03 P006-01/ /E004	YK910-YL430, YM645-YM651, YM653-YM670
C01196		BACC18AD2 CB-ACMS (INOP)	233A5221 81205	1	31-35-03 P006-01/ /E004	YM643, YM652

EQUIPMENT LIST

D280A103

Section C01100
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
I C01200		BACC18AD3 CB-GND SERV WDO BRT CONT	S281A601 07217	1	33-21-11 P092-00/ /C001	ALL
C01204		BACC18AD5 CB-SMYD-1 CMPTR DC	233A5502 81205	1	27-32-11 P018-02/ /E005	YC001-YC007
C01204		BACC18AD5 CB-SMYD-1 CMPTR DC	233A5522 81205	1	27-32-11 P018-02/ /E005	YC008-YM670
C01205		BACC18AD2 CB-SMYD-1 SNSR EXC AC	233A5502 81205	1	27-32-11 P018-02/ /E006	YC001-YC007
C01205		BACC18AD2 CB-SMYD-1 SNSR EXC AC	233A5522 81205	1	27-32-11 P018-02/ /E006	YC008-YM670
C01206		BACC18AD5 CB-SMYD-2 CMPTR DC	233A5202 81205	1	27-32-21 P006-01/ /B005	YC001-YC007
C01206		BACC18AD5 CB-SMYD-2 CMPTR DC	233A5221 81205	1	27-32-21 P006-01/ /B005	YC008-YM670
C01207		BACC18AD2 CB-SMYD-2 SNSR EXC AC	233A5202 81205	1	27-32-21 P006-01/ /B004	YC001-YC007
C01207		BACC18AD2 CB-SMYD-2 SNSR EXC AC	233A5221 81205	1	27-32-21 P006-01/ /B004	YC008-YM670
C01208		BACC18AD2 CB-STALL WARN ASYM MODE	233A5502 81205	1	27-32-11 P018-02/ /E007	YC001-YC007
C01208		BACC18AD2 CB-STALL WARN ASYM MODE	233A5522 81205	1	27-32-11 P018-02/ /E007	YC008-YM670
C01209	1	BACC18X100B CB-AUX BAT CHARGER	284A0816 81205	1	24-31-11 J009-00/ /A003	ALL
C01209	2	BACC18X100 CB-AUX BAT CHARGER	284A0816 81205	1	24-31-11 J009-00/ /A003	ALL
C01210		BACC18AD2 CB-AUX BAT DC VOLTMETER	284A0816 81205	1	24-31-11 J009-00/ /A002	ALL
C01212		BACC18AF100 CB-DUAL BATTERY RCCB	284A0816 81205	1	24-31-11 J009-00/ /	ALL
C01216		BACC18AD2 CB-PRINTER	233A5202 81205	1	31-33-01 P006-01/ /E005	YC001-YC007
C01216		BACC18AD2 CB-PRINTER	233A5221 81205	1	31-33-01 P006-01/ /E005	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01200

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01217		BACC18AD5 CB-PASS CAB SIGNS LAVATORY OCCUPIED SIGN	233A5502 81205	1	33-26-31 P018-03/ /D009	YC001-YC007
C01217		BACC18AD5 CB-PASS CAB SIGNS LAVATORY OCCUPIED SIGN	233A5523 81205	1	33-26-31 P018-03/ /D009	YC008-YM670
C01238		BACC18AD3 CB-FMCS MCDU 1	233A5502 81205	1	34-61-11 P018-02/ /A007	YC001-YC007
C01238		BACC18AD3 CB-FMCS MCDU 1	233A5522 81205	1	34-61-11 P018-02/ /A007	YC008-YM670
C01239		BACC18AD3 CB-FMCS MCDU 2	233A5202 81205	1	34-61-11 P006-01/ /D015	YC001-YC007
C01239		BACC18AD3 CB-FMCS MCDU 2	233A5221 81205	1	34-61-11 P006-01/ /D015	YC008-YM670
C01255		BACC18AD2 CB-MIDU (INOP)	233A5202 81205	1	23-27-11 P006-01/ /E006	YC001-YC007
C01255		BACC18AD2 CB-MIDU (INOP)	233A5221 81205	1	23-27-11 P006-01/ /E006	YC008-YC050
C01262		BACC18AD3 CB-FMCS CMPTR 2 (INOP)	233A5202 81205	1	34-61-11 P006-01/ /D016	YC001-YC007
C01262		BACC18AD3 CB-FMCS CMPTR 2 (INOP)	233A5221 81205	1	34-61-11 P006-01/ /D016	YC008-YK906
C01262		BACC18AD3 CB-FMCS CMPTR 2	233A5221 81205	1	34-61-11 P006-01/ /D016	YK907-YM670
C01263		BACC18AD5 CB-FMCS XFR (INOP)	233A5202 81205	1	34-61-12 P006-01/ /E015	YC001-YC007
C01263		BACC18AD5 CB-FMCS XFR (INOP)	233A5221 81205	1	34-61-12 P006-01/ /E015	YC008-YK906
C01263		BACC18AD5 CB-FMCS XFR	233A5221 81205	1	34-61-12 P006-01/ /E015	YK907-YM670
C01266		BACC18AD5 CB-ENGINE 1 THRUST REVERSER SYNC LOCK	233A5502 81205	1	78-32-51 P018-02/ /B007	YC001-YC007
C01266		BACC18AD5 CB-ENGINE 1 THRUST REVERSER SYNC LOCK	233A5522 81205	1	78-32-51 P018-02/ /B007	YC008-YM670
C01267		BACC18AD5 CB-ENGINE 2 THRUST REVERSER SYNC LOCK	233A5202 81205	1	78-32-61 P006-02/ /C005	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01200

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01267		BACC18AD5 CB-ENGINE 2 THRUST REVERSER SYNC LOCK	233A5222 81205	1	78-32-61 P006-02/ /C005	YC008-YM670
C01269		BACC18AD7 CB-PRESSURIZATION CONTROL MANUAL	233A5202 81205	1	21-31-11 P006-04/ /F006	YC001-YC007
C01269		BACC18AD7 CB-PRESSURIZATION CONTROL MANUAL	233A5224 81205	1	21-31-11 P006-04/ /F006	YC008-YM670
C01270		BACC18AD7 CB-PRESSURIZATION CONTROL AUTO 1	233A5202 81205	1	21-31-22 P006-04/ /F003	YC001-YC007
C01270		BACC18AD7 CB-PRESSURIZATION CONTROL AUTO 1	233A5224 81205	1	21-31-22 P006-04/ /F003	YC008-YM670
C01271		BACC18AD5 CB-PRESSURIZATION CONTROL AUTO 2	233A5202 81205	1	21-31-23 P006-04/ /F005	YC001-YC007
C01271		BACC18AD5 CB-PRESSURIZATION CONTROL AUTO 2	233A5224 81205	1	21-31-23 P006-04/ /F005	YC008-YM670
C01272		BACC18AD2 CB-PRESSURIZATION CONTROL IND	233A5202 81205	1	21-31-23 P006-04/ /F007	YC001-YC007
C01272		BACC18AD2 CB-PRESSURIZATION CONTROL IND	233A5224 81205	1	21-31-23 P006-04/ /F007	YC008-YM670
C01273		BACC18AD2 CB-PRESSURIZATION CONTROL LCD LTG	233A5202 81205	1	21-31-25 P006-04/ /F001	YC001-YC007
C01273		BACC18AD2 CB-PRESSURIZATION CONTROL LCD LTG	233A5224 81205	1	21-31-25 P006-04/ /F001	YC008-YM670
C01274		BACC18AD2 CB-AIR CONDITIONING DOOR AREA HEAT CONT	233A5502 81205	1	21-42-11 P018-03/ /E011	YC001-YC007
C01274		BACC18AD2 CB-AIR CONDITIONING DOOR AREA HEAT CONT	233A5523 81205	1	21-42-11 P018-03/ /E011	YC008-YM670
C01275		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR CONT 1	233A5202 81205	1	31-52-25 P006-03/ /C011	YC001-YC007
C01275		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR CONT 1	233A5223 81205	1	31-52-25 P006-03/ /C011	YC008-YM670
C01276		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR CONT 2	233A5202 81205	1	31-52-21 P006-03/ /C012	YC001-YC007
C01276		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR CONT 2	233A5223 81205	1	31-52-21 P006-03/ /C012	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01200

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01277		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR CONT 3	233A5202 81205	1	31-52-51 P006-03/ /C013	YC001-YC007
C01277		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR CONT 3	233A5223 81205	1	31-52-51 P006-03/ /C013	YC008-YM670
C01278		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR CONT 4	233A5202 81205	1	31-52-71 P006-03/ /C014	YC001-YC007
C01278		BACC18AD3 CB-MASTER CAUTION ANNUNCIATOR CONT 4	233A5223 81205	1	31-52-71 P006-03/ /C014	YC008-YM670
█ C01279		BACC18AC5 CB-DOOR AREA HTR-AFT	S281A601 07217	1	21-42-11 P091-00/ /A014	YC001-YK906
█ C01279		BACC18AC5 CB-DOOR AREA HTR-AFT	S281A601 07217	1	21-42-11 P091-00/ /D007	YK907-YM670
█ C01280		BACC18AC5 CB-DOOR AREA HTR-FWD	S281A601 07217	1	21-42-11 P091-00/ /A016	YC001-YK906
█ C01280		BACC18AC5 CB-DOOR AREA HTR-FWD	S281A601 07217	1	21-42-11 P091-00/ /D009	YK907-YM670
C01283		BACC18AD5 CB-GENERATOR CONT UNIT 1	233A5202 81205	1	24-11-11 P006-04/ /F010	YC001-YC007
C01283		BACC18AD5 CB-GENERATOR CONT UNIT 1	233A5224 81205	1	24-11-11 P006-04/ /F010	YC008-YM670
C01284		BACC18AD5 CB-GENERATOR CONT UNIT 2	233A5202 81205	1	24-11-21 P006-04/ /F011	YC001-YC007
C01284		BACC18AD5 CB-GENERATOR CONT UNIT 2	233A5224 81205	1	24-11-21 P006-04/ /F011	YC008-YM670
C01285		BACC18AD5 CB-GENERATOR APU GEN CONT UNIT	233A5202 81205	1	24-22-31 P006-04/ /F012	YC001-YC007
C01285		BACC18AD5 CB-GENERATOR APU GEN CONT UNIT	233A5224 81205	1	24-22-31 P006-04/ /F012	YC008-YM670
C01286		BACC18AD7 CB-GENERATOR DISC 1	233A5202 81205	1	24-11-11 P006-04/ /F008	YC001-YC007
C01286		BACC18AD7 CB-GENERATOR DISC 1	233A5224 81205	1	24-11-11 P006-04/ /F008	YC008-YM670
C01287		BACC18AD7 CB-GENERATOR DISC 2	233A5202 81205	1	24-11-21 P006-04/ /F009	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01200

Page 4

Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01287		BACC18AD7 CB-GENERATOR DISC 2	233A5224 81205	1	24-11-21 P006-04/ /F009	YC008-YM670
■ C01288		BACC18AD2 CB-GEN 1 LOAD SHED	S281A601 81205	1	24-28-41 P091-00/ /C007	ALL
■ C01289		BACC18AD2 CB-GEN 2 LOAD SHED	S281A601 81205	1	24-28-41 P092-00/ /C007	ALL
C01290		BACC18AD5 CB-GENERATOR BUS PWR CONT UNIT	1151932 81205	1	24-41-11 P006-04/ /F013	YC001-YC007
C01290		BACC18AD5 CB-GENERATOR BUS PWR CONT UNIT	233A5224 81205	1	24-41-11 P006-04/ /F013	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01200
Page 5 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01312		BACC18AD2 CB-ENGINE 1 RUN/PWR	233A5502 81205	1	73-22-31 P018-02/ /B003	YC001-YC007
C01312		BACC18AD2 CB-ENGINE 1 RUN/PWR	233A5522 81205	1	73-22-31 P018-02/ /B003	YC008-YM670
C01313		BACC18AD2 CB-ENGINE 2 RUN/PWR	233A5202 81205	1	73-22-31 P006-02/ /B005	YC001-YC007
C01313		BACC18AD2 CB-ENGINE 2 RUN/PWR	233A5222 81205	1	73-22-31 P006-02/ /B005	YC008-YM670
C01314		BACC18AD2 CB-ENGINE 1 ALTN PWR CHAN A	233A5502 81205	1	73-22-11 P018-02/ /A005	YC001-YC007
C01314		BACC18AD2 CB-ENGINE 1 ALTN PWR CHAN A	233A5522 81205	1	73-22-11 P018-02/ /A005	YC008-YM670
C01315		BACC18AD2 CB-ENGINE 2 ALTN PWR CHAN A	233A5202 81205	1	73-22-11 P006-02/ /D008	YC001-YC007
C01315		BACC18AD2 CB-ENGINE 2 ALTN PWR CHAN A	233A5222 81205	1	73-22-11 P006-02/ /D008	YC008-YM670
C01316		BACC18AD2 CB-ENGINE 1 START LEVER CHAN A	233A5502 81205	1	76-21-11 P018-02/ /B001	YC001-YC007
C01316		BACC18AD2 CB-ENGINE 1 START LEVER CHAN A	233A5522 81205	1	76-21-11 P018-02/ /B001	YC008-YM670
C01317		BACC18AD2 CB-ENGINE 1 START LEVER CHAN B	233A5502 81205	1	76-21-11 P018-02/ /B002	YC001-YC007
C01317		BACC18AD2 CB-ENGINE 1 START LEVER CHAN B	233A5522 81205	1	76-21-11 P018-02/ /B002	YC008-YM670
C01318		BACC18AD2 CB-ENGINE 2 START LEVER CHAN A	233A5202 81205	1	76-21-21 P006-02/ /B006	YC001-YC007
C01318		BACC18AD2 CB-ENGINE 2 START LEVER CHAN A	233A5222 81205	1	76-21-21 P006-02/ /B006	YC008-YM670
C01319		BACC18AD2 CB-ENGINE 2 START LEVER CHAN B	233A5202 81205	1	76-21-21 P006-02/ /B007	YC001-YC007
C01319		BACC18AD2 CB-ENGINE 2 START LEVER CHAN B	233A5222 81205	1	76-21-21 P006-02/ /B007	YC008-YM670
C01320		BACC18AD2 CB-ENGINE FUEL ENGINE 1 HPSOV CONT	233A5202 81205	1	76-21-11 P006-03/ /E005	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01300

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01320		BACC18AD2 CB-ENGINE FUEL ENGINE 1 HPSOV CONT	233A5223 81205	1	76-21-11 P006-03/ /E005	YC008-YM670
C01321		BACC18AD2 CB-ENGINE FUEL ENGINE 2 HPSOV CONT	233A5202 81205	1	76-21-21 P006-03/ /E003	YC001-YC007
C01321		BACC18AD2 CB-ENGINE FUEL ENGINE 2 HPSOV CONT	233A5223 81205	1	76-21-21 P006-03/ /E003	YC008-YM670
■ C01326		BACC18AD5 CB-APU GEN CONT UNIT	S281A601 81205	1	24-22-31 P092-00/ /C009	ALL
■ C01327		BACC18AD5 CB-BUS PWR CONT UNIT	S281A601 81205	1	24-41-11 P091-00/ /C010	ALL
C01328		BACC18AD2 CB-ELECTRICAL GND SERV CONT	233A5202 81205	1	24-23-51 P006-04/ /E013	YC001-YC007
C01328		BACC18AD2 CB-ELECTRICAL GND SERV CONT	233A5224 81205	1	24-23-51 P006-04/ /E013	YC008-YM670
■ C01336		BACC18AE35 CB-APU START CONV	S281A601 07217	1	49-41-11 P091-00/ /A011	ALL
C01338		BACC18AD2 CB-DC BUS INDICATION BUS 2	233A5202 81205	1	24-33-11 P006-04/ /F018	YC001-YC007
C01338		BACC18AD2 CB-DC BUS INDICATION BUS 2	233A5224 81205	1	24-33-11 P006-04/ /F018	YC008-YM670
C01340	1	BACC18X100B CB-BATTERY BUS	284A0816 07217	1	24-31-12 J009-00/ /A005	ALL
C01340	2	BACC18X100 CB-BATTERY BUS	284A0816 07217	1	24-31-12 J009-00/ /A005	ALL
C01341		BACC18AF60 CB-STATIC INVERTER RCCB	284A0816 07217	1	24-34-11 J009-00/ /	ALL
C01343		MS26574-1-2 CB-INVERTER REMOTE	S281A601 07217	0	24-34-11 M01720/ /A005	ALL
C01344		BACC18AD5 CB-APU FIRE SW POWER	233A5202 81205	1	49-62-11 P006-02/ /B019	YC001-YC007
C01344		BACC18AD5 CB-APU FIRE SW POWER	233A5222 81205	1	49-62-11 P006-02/ /B019	YC008-YM670
C01345		BACC18AD3 CB-LANDING GEAR AUTOBRAKE BITE CONT 2	233A5202 81205	1	32-42-11 P006-03/ /A016	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01300

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01345		BACC18AD3 CB-LANDING GEAR AUTOBRAKE BITE CONT 2	233A5223 81205	1	32-42-11 P006-03/ /A016	YC008-YM670
C01346		BACC18AD2 CB-LANDING GEAR PARKING BRAKE	233A5202 81205	1	32-44-11 P006-03/ /B016	YC001-YC007
C01346		BACC18AD2 CB-LANDING GEAR PARKING BRAKE	233A5223 81205	1	32-44-11 P006-03/ /B016	YC008-YM670
C01350		BACC18AD3 CB-THRSH LT	S281A601 07217	1	33-29-11 P091-00/ /C001	ALL
C01354		BACC18AD5 CB-YAW DAMPER 2 DC	233A5502 81205	1	22-23-11 P018-01/ /D006	YC001-YC007
C01354		BACC18AD5 CB-YAW DAMPER 2 DC	233A5521 81205	1	22-23-11 P018-01/ /D006	YC008-YM670
C01355		BACC18AD2 CB-LANDING GEAR AIR/GND SYS 2	233A5202 81205	1	32-31-12 P006-03/ /C015	YC001-YC007
C01355		BACC18AD2 CB-LANDING GEAR AIR/GND SYS 2	233A5223 81205	1	32-31-12 P006-03/ /C015	YC008-YM670
C01356		BACC18AD2 CB-LANDING GEAR AIR/GND SYS 1	233A5202 81205	1	32-31-11 P006-03/ /C016	YC001-YC007
C01356		BACC18AD2 CB-LANDING GEAR AIR/GND SYS 1	233A5223 81205	1	32-31-11 P006-03/ /C016	YC008-YM670
C01357		BACC18AD7 CB-PASS CABIN LIGHTING EMER CHGR L AFT	233A5502 81205	1	33-51-11 P018-03/ /A010	YC001-YC007
C01357		BACC18AD7 CB-PASS CABIN LIGHTING EMER CHGR L AFT	233A5523 81205	1	33-51-11 P018-03/ /A010	YC008-YM670
C01358		BACC18AD7 CB-PASS CABIN LIGHTING EMER CHGR R AFT	233A5502 81205	1	33-51-11 P018-03/ /B010	YC001-YC007
C01358		BACC18AD7 CB-PASS CABIN LIGHTING EMER CHGR R AFT	233A5523 81205	1	33-51-11 P018-03/ /B010	YC008-YL430
C01358		BACC18AD5 CB-PASS CABIN LIGHTING EMER CHGR R AFT	233A5523 81205	1	33-51-11 P018-03/ /B010	YM643-YM670
C01359		BACC18AD15 CB-DISPLAY DEU 1 PRI	233A5502 81205	1	31-62-11 P018-02/ /D005	YC001-YC007
C01359		BACC18AD15 CB-DISPLAY DEU 1 PRI	233A5522 81205	1	31-62-11 P018-02/ /D005	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01300

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01360		BACC18AD15 CB-DISPLAY DEU 2 PRI	233A5202 81205	1	31-62-21 P006-01/ /D011	YC001-YC007
C01360		BACC18AD15 CB-DISPLAY DEU 2 PRI	233A5221 81205	1	31-62-21 P006-01/ /D011	YC008-YM670
C01361		BACC18AD15 CB-DISPLAY DEU 1 HOLDUP	233A5202 81205	1	31-62-11 P006-01/ /D010	YC001-YC007
C01361		BACC18AD15 CB-DISPLAY DEU 1 HOLDUP	233A5221 81205	1	31-62-11 P006-01/ /D010	YC008-YM670
C01362		BACC18AD15 CB-DISPLAY DEU 2 HOLDUP	233A5202 81205	1	31-62-21 P006-01/ /D009	YC001-YC007
C01362		BACC18AD15 CB-DISPLAY DEU 2 HOLDUP	233A5221 81205	1	31-62-21 P006-01/ /D009	YC008-YM670
C01363		BACC18AD15 CB-DISPLAY CAPT OUTBD	233A5502 81205	1	31-62-11 P018-02/ /D004	YC001-YC007
C01363		BACC18AD15 CB-DISPLAY CAPT OUTBD	233A5522 81205	1	31-62-11 P018-02/ /D004	YC008-YM670
C01364		BACC18AD15 CB-DISPLAY F/O OUTBD	233A5202 81205	1	31-62-21 P006-01/ /E010	YC001-YC007
C01364		BACC18AD15 CB-DISPLAY F/O OUTBD	233A5221 81205	1	31-62-21 P006-01/ /E010	YC008-YM670
C01365		BACC18AD15 CB-DISPLAY CAPT INBD	233A5502 81205	1	31-62-11 P018-02/ /D003	YC001-YC007
C01365		BACC18AD15 CB-DISPLAY CAPT INBD	233A5522 81205	1	31-62-11 P018-02/ /D003	YC008-YM670
C01366		BACC18AD15 CB-DISPLAY F/O INBD	233A5202 81205	1	31-62-21 P006-01/ /E011	YC001-YC007
C01366		BACC18AD15 CB-DISPLAY F/O INBD	233A5221 81205	1	31-62-21 P006-01/ /E011	YC008-YM670
C01369		BACC18AD2 CB-DISPLAY CAPT EFIS CONT PANEL	233A5502 81205	1	31-62-11 P018-02/ /D001	YC001-YC007
C01369		BACC18AD2 CB-DISPLAY CAPT EFIS CONT PANEL	233A5522 81205	1	31-62-11 P018-02/ /D001	YC008-YM670
C01370		BACC18AD2 CB-DISPLAY F/O EFIS CONT PANEL	233A5202 81205	1	31-62-21 P006-01/ /E013	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01300

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01370		BACC18AD2 CB-DISPLAY F/O EFIS CONT PANEL	233A5221 81205	1	31-62-21 P006-01/ /E013	YC008-YM670
C01372		BACC18AD15 CB-DISPLAY CTR UPR	233A5502 81205	1	31-62-11 P018-02/ /D002	YC001-YC007
C01372		BACC18AD15 CB-DISPLAY CTR UPR	233A5522 81205	1	31-62-11 P018-02/ /D002	YC008-YM670
C01373		BACC18AD15 CB-DISPLAY CTR LWR	233A5202 81205	1	31-62-21 P006-01/ /E012	YC001-YC007
C01373		BACC18AD15 CB-DISPLAY CTR LWR	233A5221 81205	1	31-62-21 P006-01/ /E012	YC008-YM670
C01374		BACC18AD2 CB-RADIO NAVIGATION VOR/MKR BCN 1	233A5502 81205	1	34-51-11 P018-01/ /A001	YC001-YC007
C01374		BACC18AD2 CB-RADIO NAVIGATION VOR/MKR BCN 1	233A5521 81205	1	34-51-11 P018-01/ /A001	YC008-YM670
C01375		BACC18AD2 CB-RADIO NAVIGATION VOR 2	233A5202 81205	1	34-51-21 P006-01/ /A012	YC001-YC007
C01375		BACC18AD2 CB-RADIO NAVIGATION VOR 2	233A5221 81205	1	34-51-21 P006-01/ /A012	YC008-YM670
C01376		BACC18AD2 CB-RADIO NAVIGATION NAV SNSR DC-1	233A5502 81205	1	34-51-41 P018-01/ /B001	YC001-YC007
C01376		BACC18AD2 CB-RADIO NAVIGATION NAV SNSR DC-1	233A5521 81205	1	34-51-41 P018-01/ /B001	YC008-YM670
C01377		BACC18AD2 CB-RADIO NAVIGATION NAV SNSR DC-2	233A5202 81205	1	34-51-41 P006-01/ /A010	YC001-YC007
C01377		BACC18AD2 CB-RADIO NAVIGATION NAV SNSR DC-2	233A5221 81205	1	34-51-41 P006-01/ /A010	YC008-YM670
C01378		BACC18AD2 CB-RADIO NAVIGATION NAV CONT PNL 1	233A5502 81205	1	34-51-11 P018-01/ /A003	YC001-YC007
C01378		BACC18AD2 CB-RADIO NAVIGATION NAV CONT PNL 1	233A5521 81205	1	34-51-11 P018-01/ /A003	YC008-YM670
C01379		BACC18AD2 CB-RADIO NAVIGATION NAV CONT PNL 2	233A5202 81205	1	34-51-21 P006-01/ /A015	YC001-YC007
C01379		BACC18AD2 CB-RADIO NAVIGATION NAV CONT PNL 2	233A5221 81205	1	34-51-21 P006-01/ /A015	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01300

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01380		BACC18AD2 CB-RADIO NAVIGATION ILS 1	233A5502 81205	1	34-31-11 P018-01/ /A002	YC006-YC007
C01380		BACC18AD2 CB-RADIO NAVIGATION ILS 1	233A5521 81205	1	34-31-11 P018-01/ /A002	YC008-YC050
C01382		BACC18AD2 CB-RADIO NAVIGATION ADF 1	233A5502 81205	1	34-57-11 P018-01/ /A004	YC001-YC007
C01382		BACC18AD2 CB-RADIO NAVIGATION ADF 1	233A5521 81205	1	34-57-11 P018-01/ /A004	YC008-YM670
█ C01383	9	BACC18AD2 CB-RADIO ADF 2 (REMOVE'INOP')(SB34-2194)	233A5221 81205	1	34-57-21 P006-01/ /A017	YC028-YC029
█ C01383		BACC18AD2 CB-RADIO NAVIGATION ADF 2 (INOP)	233A5202 81205	1	34-57-21 P006-01/ /A017	YC001-YC007
█ C01383		BACC18AD2 CB-RADIO NAVIGATION ADF 2 (INOP)	233A5221 81205	1	34-57-21 P006-01/ /A017	YC008-YM670
C01384		BACC18AD2 CB-RADIO NAVIGATION RADIO ALTM 1	233A5502 81205	1	34-33-11 P018-01/ /B004	YC001-YC007
C01384		BACC18AD2 CB-RADIO NAVIGATION RADIO ALTM 1	233A5521 81205	1	34-33-11 P018-01/ /B004	YC008-YM670
C01385		BACC18AD2 CB-RADIO NAVIGATION RADIO ALTM 2	233A5202 81205	1	34-33-21 P006-01/ /A016	YC001-YC007
C01385		BACC18AD2 CB-RADIO NAVIGATION RADIO ALTM 2	233A5221 81205	1	34-33-21 P006-01/ /A016	YC008-YM670
C01386		BACC18AD2 CB-RADIO NAVIGATION RMI	233A5502 81205	1	34-22-11 P018-01/ /A005	YC001-YC007
C01386		BACC18AD2 CB-RADIO NAVIGATION RMI	233A5521 81205	1	34-22-11 P018-01/ /A005	YC008-YM670
C01387		BACC18AD3 CB-STBY ATT IND	233A5502 81205	1	34-24-11 P018-02/ /D009	YC001-YC007
C01387		BACC18AD3 CB-STBY ATT IND	233A5521 81205	1	34-24-11 P018-02/ /D009	YC008-YC050
C01388		BACC18AD5 CB-VACUUM WASTE CONT	233A5502 81205	1	38-32-12 P091-00/ /C011	ALL
C01389		10-60806-1020 CB-VACUUM WASTE BLOWER	233A5502 81205	1	38-32-12 P091-00/ /F002	ALL

EQUIPMENT LIST

D280A103

Section C01300

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01390		BACC18AD2 CB-ENGINE 1 ALTN PWR CHAN B	233A5502 81205	1	73-22-11 P018-02/ /A004	YC001-YC007
C01390		BACC18AD2 CB-ENGINE 1 ALTN PWR CHAN B	233A5522 81205	1	73-22-11 P018-02/ /A004	YC008-YM670
C01391		BACC18AD2 CB-ENGINE 2 ALTN PWR CHAN B	233A5202 81205	1	73-22-11 P006-02/ /D007	YC001-YC007
C01391		BACC18AD2 CB-ENGINE 2 ALTN PWR CHAN B	233A5222 81205	1	73-22-11 P006-02/ /D007	YC008-YM670
C01392		BACC18AD5 CB-STICK SHAKER LEFT	233A5502 81205	1	27-32-11 P018-02/ /E004	YC001-YC007
C01392		BACC18AD5 CB-STICK SHAKER LEFT	233A5522 81205	1	27-32-11 P018-02/ /E004	YC008-YM670
C01393		BACC18AD5 CB-STICK SHAKER RIGHT	233A5202 81205	1	27-32-21 P006-01/ /B006	YC001-YC007
C01393		BACC18AD5 CB-STICK SHAKER RIGHT	233A5221 81205	1	27-32-21 P006-01/ /B006	YC008-YM670
C01395		BACC18AD2 CB-ENGINE FUEL ENGINE 1 HPSOV IND	233A5202 81205	1	76-21-11 P006-03/ /E006	YC001-YC007
C01395		BACC18AD2 CB-ENGINE FUEL ENGINE 1 HPSOV IND	233A5223 81205	1	76-21-11 P006-03/ /E006	YC008-YM670
C01396		BACC18AD2 CB-ENGINE FUEL ENGINE 2 HPSOV IND	233A5202 81205	1	76-21-21 P006-03/ /E004	YC001-YC007
C01396		BACC18AD2 CB-ENGINE FUEL ENGINE 2 HPSOV IND	233A5223 81205	1	76-21-21 P006-03/ /E004	YC008-YM670
C01397		BACC18AD2 CB-ELECTRICAL TR3 XFR RELAY CONT	233A5202 81205	1	24-32-11 P006-04/ /E011	YC001-YC007
C01397		BACC18AD2 CB-ELECTRICAL TR3 XFR RELAY CONT	233A5224 81205	1	24-32-11 P006-04/ /E011	YC008-YM670
C01398		BACC18Z1R CB-LANDING GEAR TAKEOFF WARNING CUTOFF	233A5202 81205	1	31-53-11 P006-03/ /C018	YC001-YC007
C01398		BACC18Z1R CB-LANDING GEAR TAKEOFF WARNING CUTOFF	233A5223 81205	1	31-53-11 P006-03/ /C018	YC008-YM670
C01399		BACC18AD5 CB-PSEU PRI	233A5202 81205	1	32-64-11 P006-03/ /D001	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01300

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01399		BACC18AD5 CB-PSEU PRI	233A5223 81205	1	32-64-11 P006-03/ /D001	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01300
Page 8 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01400		BACC18AD5 CB-PSEU ALTN	233A5202 81205	1	32-64-12 P006-03/ /D002	YC001-YC007
C01400		BACC18AD5 CB-PSEU ALTN	233A5223 81205	1	32-64-12 P006-03/ /D002	YC008-YM670
C01401		BACC18AD2 CB-LANDING GEAR AIR/GND RELAY	233A5202 81205	1	32-31-11 P006-03/ /D015	YC001-YC007
C01401		BACC18AD2 CB-LANDING GEAR AIR/GND RELAY	233A5223 81205	1	32-31-11 P006-03/ /D015	YC008-YM670
C01403		BACC18AD5 CB-PASSENGER CABIN PASS CALL LEFT	233A5502 81205	1	33-27-11 P018-03/ /A008	YC001-YC007
C01403		BACC18AD5 CB-PASSENGER CABIN PASS CALL LEFT	233A5523 81205	1	33-27-11 P018-03/ /A008	YC008-YM670
C01404		BACC18AD5 CB-PASSENGER CABIN PASS CALL RIGHT	233A5502 81205	1	33-27-11 P018-03/ /B008	YC001-YC007
C01404		BACC18AD5 CB-PASSENGER CABIN PASS CALL RIGHT	233A5523 81205	1	33-27-11 P018-03/ /B008	YC008-YM670
C01405		BACC18AD7 CB-PASS CABIN SIGNS FASTEN SEAT BELT L	233A5502 81205	1	33-25-11 P018-03/ /C009	YC001-YC007
C01405		BACC18AD7 CB-PASS CABIN SIGNS FASTEN SEAT BELT L	233A5523 81205	1	33-25-11 P018-03/ /C009	YC008-YM670
C01406		BACC18AD7 CB-PASS CABIN SIGNS FASTEN SEAT BELT R	233A5502 81205	1	33-25-11 P018-03/ /C008	YC001-YC007
C01406		BACC18AD7 CB-PASS CABIN SIGNS FASTEN SEAT BELT R	233A5523 81205	1	33-25-11 P018-03/ /C008	YC008-YM670
C01407		BACC18AD5 CB-PASS CABIN SIGNS NO SMOKING LEFT	233A5502 81205	1	33-25-11 P018-03/ /C011	YC001-YC007
C01407		BACC18AD5 CB-PASS CABIN SIGNS NO SMOKING LEFT	233A5523 81205	1	33-25-11 P018-03/ /C011	YC008-YM670
C01408		BACC18AD5 CB-PASS CABIN SIGNS NO SMOKING RIGHT	233A5502 81205	1	33-25-11 P018-03/ /C010	YC001-YC007
C01408		BACC18AD5 CB-PASS CABIN SIGNS NO SMOKING RIGHT	233A5523 81205	1	33-25-11 P018-03/ /C010	YC008-YM670
C01410		BACC18AD2 CB-SPCU NORMAL	S281A601 07217	0	24-31-12 M01720/ /B001	ALL

EQUIPMENT LIST

D280A103

Section C01400

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01411		BACC18AD2 CB-SPCU STANDBY	S281A601 07217	0	24-31-12 M01720/ /B002	ALL
C01412		BACC18AD3 CB-ENGINE 1 THRUST REVERSER INTLK	233A5502 81205	1	78-35-11 P018-02/ /B006	YC001-YC007
C01412		BACC18AD3 CB-ENGINE 1 THRUST REVERSER INTLK	233A5522 81205	1	78-35-11 P018-02/ /B006	YC008-YM670
C01413		BACC18AD3 CB-ENGINE 2 THRUST REVERSER INTLK	233A5202 81205	1	78-35-21 P006-02/ /C006	YC001-YC007
C01413		BACC18AD3 CB-ENGINE 2 THRUST REVERSER INTLK	233A5222 81205	1	78-35-21 P006-02/ /C006	YC008-YM670
C01419		BACC18AD2 CB-CARGO LT CONT	S281A601 07217	1	33-36-11 P092-00/ /C010	ALL
C01423		BACC18AD2 CB-VACUUM WASTE	233A5502 81205	1	38-32-13 P018-03/ /D019	YC001-YC007
C01423		BACC18AD2 CB-VACUUM WASTE	233A5523 81205	1	38-32-13 P018-03/ /D019	YC008-YM670
C01424		BACC18AD5 CB-AUX POWER UNIT SCU FAN POWER	233A5202 81205	1	49-41-11 P006-04/ /B014	YC001-YC007
C01424		BACC18AD5 CB-AUX POWER UNIT SCU FAN POWER	233A5224 81205	1	49-41-11 P006-04/ /B014	YC008-YM670
C01425		BACC18AD2 CB-CONT CABIN LIGHTING PANEL FLOOD STBY	233A5202 81205	1	33-14-11 P006-03/ /A012	YC001-YC007
C01425		BACC18AD2 CB-CONT CABIN LIGHTING PANEL FLOOD STBY	233A5223 81205	1	33-14-11 P006-03/ /A012	YC008-YM670
C01426		BACC18AD2 CB-BAT/STBY SW POS IND	S281A601 07217	0	24-31-12 M01720/ /B005	ALL
C01429		BACC18AD2 CB-YAW DAMPER IND	233A5502 81205	1	22-23-11 P018-01/ /C006	YC001-YC007
C01429		BACC18AD2 CB-YAW DAMPER IND	233A5521 81205	1	22-23-11 P018-01/ /C006	YC008-YM670
C01432		BACC18AD2 CB-LANDING GEAR ALTN EXTEND SOL	233A5202 81205	1	32-35-11 P006-03/ /D016	YC001-YC007
C01432		BACC18AD2 CB-LANDING GEAR ALTN EXTEND SOL	233A5223 81205	1	32-35-11 P006-03/ /D016	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01400

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01433		BACC18AD2 CB-EQPT COOLING LOW FLOW DETECT SUPPLY	233A5502 81205	0	21-27-31 P018-03/ /A017	YC001-YC007
C01433		BACC18AD2 CB-EQPT COOLING LOW FLOW DETECT SUPPLY	233A5523 81205	0	21-27-31 P018-03/ /A017	YC008-YM670
C01434		BACC18AD2 CB-EQPT COOLING LOW FLOW DETECT EXHAUST	233A5502 81205	0	21-27-21 P018-03/ /A018	YC001-YC007
C01434		BACC18AD2 CB-EQPT COOLING LOW FLOW DETECT EXHAUST	233A5523 81205	0	21-27-21 P018-03/ /A018	YC008-YM670
C01435		BACC18AD2 CB-EQPT COOLING EXHAUST FAN CONT NORMAL	233A5202 81205	0	21-27-21 P006-04/ /C014	YC001-YC007
C01435		BACC18AD2 CB-EQPT COOLING EXHAUST FAN CONT NORMAL	233A5224 81205	0	21-27-21 P006-04/ /C014	YC008-YM670
C01436		BACC18AD2 CB-EQPT COOLING EXHAUST FAN CONT ALTN	233A5202 81205	0	21-27-21 P006-04/ /C015	YC001-YC007
C01436		BACC18AD2 CB-EQPT COOLING EXHAUST FAN CONT ALTN	233A5224 81205	0	21-27-21 P006-04/ /C015	YC008-YM670
■ C01437		BACC18AD10 CB-PASS READING LIGHTS-R STA768-880	S281A601 07217	1	33-23-22 P092-00/ /B008	YC001-YL430
■ C01438		BACC18AD10 CB-PASS READING LIGHTS-R STA880-937	S281A601 07217	1	33-23-22 P092-00/ /B009	YC001-YL430
C01441		BACC18AD5 CB-FUEL FUELING IND	233A5202 81205	1	28-41-11 P006-03/ /A004	YC001-YC007
C01441		BACC18AD5 CB-FUEL FUELING IND	233A5223 81205	1	28-41-11 P006-03/ /A004	YC008-YM670
C01443		BACC18AD2 CB-FC TE FLAP POS/SKEW SNSR & IND RIGHT	233A5202 81205	1	27-52-11 P006-02/ /A011	YC001-YC007
C01443		BACC18AD2 CB-FC TE FLAP POS/SKEW SNSR & IND RIGHT	233A5222 81205	1	27-52-11 P006-02/ /A011	YC008-YM670
C01444		BACC18AD2 CB-A/C OVERBOARD EXHAUST VALVE CONT	233A5202 81205	1	21-43-21 P006-04/ /D001	YC001-YC007
C01444		BACC18AD2 CB-A/C OVERBOARD EXHAUST VALVE CONT	233A5224 81205	1	21-43-21 P006-04/ /D001	YC008-YM670
C01445		BACC18Z1R CB-A/C OVERBOARD EXH VALVE RECONFIG CONT	233A5202 81205	1	21-43-21 P006-04/ /D002	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01400

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01445		BACC18Z1R CB-A/C OVERBOARD EXH VALVE RECONFIG CONT	233A5224 81205	1	21-43-21 P006-04/ /D002	YC008-YM670
C01447		BACC18AD5 CB-FLIGHT CONT RUDDER AUTHORITY LIMITER	233A5202	1	27-25-11 P006-02/ /C009	YC001-YC007
C01447		BACC18AD5 CB-FLIGHT CONT RUDDER AUTHORITY LIMITER	233A5222	1	27-25-11 P006-02/ /C009	YC008-YM670
C01449		10-60806-1025 CB-STANDBY HYDRAULIC PUMP	286A8538 81205	1	29-22-11 P092-00/ /F002	ALL
C01450	9	BACC18AD5 CB-ENT VID CONT CENT DC (INOP)SB 25-1542	233A5202 81205	1	23-32-11 P006-01/ /C005	YC001-YC013, YC016-YC018, YC020-YC030
C01450		BACC18AD5 CB-ENT VID CONT CENTER DC	233A5202 81205	1	23-32-11 P006-01/ /C005	YC001-YC007
C01450		BACC18AD5 CB-ENT VID CONT CENTER DC	233A5221 81205	1	23-32-11 P006-01/ /C005	YC008-YC050
C01450		BACC18AD7 CB-ENT VID CONT CENTER DC	233A5221 81205	1	23-32-11 P006-01/ /C005	YK901-YM670
C01451	9	BACC18AD7 CB-ENT VID CONT CENT AC(INOP) SB 25-1542	233A5202 81205	1	23-32-11 P006-01/ /C007	YC001-YC013, YC016-YC018, YC020-YC030
C01451		BACC18AD7 CB-ENT VID CONT CENTER AC	233A5202 81205	1	23-32-11 P006-01/ /C007	YC001-YC007
C01451		BACC18AD7 CB-ENT VID CONT CENTER AC	233A5221 81205	1	23-32-11 P006-01/ /C007	YC008-YM670
C01452		BACC18AD7 CB-VIDEO 1	233A5202 81205	1	23-32-31 P006-01/ /D005	YC001-YC007
C01452		BACC18AD7 CB-VIDEO 1	233A5221 81205	1	23-32-31 P006-01/ /D005	YC008-YM670
C01453		BACC18AD7 CB-VIDEO 2	233A5202 81205	1	23-32-41 P006-01/ /D006	YC001-YC007
C01453		BACC18AD7 CB-VIDEO 2	233A5221 81205	1	23-32-41 P006-01/ /D006	YC008-YM670
C01454		BACC18AD7 CB-VIDEO 3	233A5202 81205	1	23-32-51 P006-01/ /D007	YC001-YC007

EQUIPMENT LIST

D280A103

Section C01400

Page 4

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01454		BACC18AD7 CB-VIDEO 3	233A5221 81205	1	23-32-51 P006-01/ /D007	YC008-YM670
C01455		BACC18AD7 CB-VIDEO 4	233A5202 81205	1	23-32-61 P006-01/ /D008	YC001-YC007
C01455		BACC18AD7 CB-VIDEO 4	233A5221 81205	1	23-32-61 P006-01/ /D008	YC008-YM670
C01456		BACC18AD7 CB-ENTERTAINMENT AUDIO	233A5202 81205	1	23-34-01 P006-01/ /C008	YC001-YC007
C01456		BACC18AD7 CB-ENTERTAINMENT AUDIO	233A5221 8 05	1	23-34-01 P006-01/ /C008	YC008-YC050
C01456		BACC18AD7 CB-ENTERTAINMENT AUDIO	233A5221 81205	1	23-34-01 P006-01/ /C008	YK901-YM670
C01459		MS26574-1-2 CB-DUAL BAT RCCB REMOTE	S281A601 07217	0	24-31-11 M01720/ /A004	ALL
C01460		BACC18AD15 CB-28V DC SERVICE OUTLETS	233A5502 81205	1	25-29-11 P018-03/ /F019	YC001-YC007
C01460		BACC18AD15 CB-28V DC SERVICE OUTLETS	233A5523 81205	1	25-29-11 P018-03/ /F019	YC008-YC050
C01463		BACC18AD5 CB-WASTE/WTR LINE HEATERS	233A5502	1	30-71-11 P018-03/ /D018	YC001-YC007
C01463		BACC18AD5 CB-WASTE/WTR LINE HEATERS	233A5523	1	30-71-11 P018-03/ /D018	YC008-YM670
C01464		BACC18AD2 CB-FLIGHT CONTROL ELEV TAB VLV RIGHT	233A5202 81205	1	27-31-11 P006-02/ /B008	YC001-YC007
C01464		BACC18AD2 CB-FLIGHT CONTROL ELEV TAB VLV RIGHT	233A5222 81205	1	27-31-11 P006-02/ /B008	YC008-YM670
C01466		BACC18AD2 CB-DC BUS INDICATION SW HOT BAT	233A5202 81205	1	24-33-11 P006-04/ /E016	YC001-YC007
C01466		BACC18AD2 CB-DC BUS INDICATION SW HOT BAT	233A5224 81205	1	24-33-11 P006-04/ /E016	YC008-YM670
C01467		BACC18AD2 CB-AC BUS XFR BUS 2 115V AC IND	233A5202 81205	1	24-28-10 P006-04/ /D013	YC001-YC007
C01467		BACC18AD2 CB-AC BUS XFR BUS 2 115V AC IND	233A5224 81205	1	24-28-10 P006-04/ /D013	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01400

Page 5

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01468		BACC18AD2 CB-FLIGHT CONTROL FSEU DC 2	233A5202 81205	1	27-81-11 P006-02/ /A009	YC001-YC007
C01468		BACC18AD2 CB-FLIGHT CONTROL FSEU DC 2	233A5222 81205	1	27-81-11 P006-02/ /A009	YC008-YM670
C01469		BACC18AD2 CB-AIR CONDITIONING BLEED AIR XDCR RIGHT	233A5202 81205	1	36-21-11 P006-04/ /B006	YC001-YC007
C01469		BACC18AD2 CB-AIR CONDITIONING BLEED AIR XDCR RIGHT	233A5224 81205	1	36-21-11 P006-04/ /B006	YC008-YM670
C01470		BACC18AD2 CB-AIR CONDITIONING BLEED AIR XDCR LEFT	233A5202 81205	1	36-21-11 P006-04/ /A006	YC001-YC007
C01470		BACC18AD2 CB-AIR CONDITIONING BLEED AIR XDCR LEFT	233A5224 81205	1	36-21-11 P006-04/ /A006	YC008-YM670
C01471		BACC18AD2 CB-FUEL SHUTOFF VALVES PWR PACK	233A5202 81205	0	28-21-21 P006-03/ /C004	YC001-YC007
C01471		BACC18AD2 CB-FUEL SHUTOFF VALVES PWR PACK	233A5223 81205	0	28-21-21 P006-03/ /C004	YC008-YM670
C01472		BACC18AD7 CB-FUEL SHUTOFF VALVES BUS	233A5202 81205	0	28-21-21 P006-03/ /C006	YC001-YC007
C01472		BACC18AD7 CB-FUEL SHUTOFF VALVES BUS	233A5223 81205	0	28-21-21 P006-03/ /C006	YC008-YM670
C01473		BACC18AD5 CB-HOSE HEATERS	233A5502 81205	1	30-71-11 P018-03/ /F016	YC001-YC007
C01473		BACC18AD5 CB-HOSE HEATERS	233A5523 81205	1	30-71-11 P018-03/ /F016	YC008-YC050
C01473		BACC18AD5 CB-HOSE HEATERS	233A5523 81205	1	30-71-11 P018-03/ /E018	YK901-YM670
C01479		BACC18AD2 CB-RADIO NAVIGATION MMR 1	233A5502 81205	1	34-31-11 P018-01/ /A002	YC001-YC003, YC006-YC007
C01479		BACC18AD2 CB-RADIO NAVIGATION MMR 1	233A5521 81205	1	34-31-11 P018-01/ /A002	YC008-YM670
C01480		BACC18AD2 CB-RADIO NAVIGATION MMR 2	233A5202 81205	1	34-31-21 P006-01/ /A013	YC001-YC003, YC006-YC007
C01480		BACC18AD2 CB-RADIO NAVIGATION MMR 2	233A5221 81205	1	34-31-21 P006-01/ /A013	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01400

Page 6

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01483		BACC18AD2 CB-CMU-1 AC	233A5221 81205	1	23-27-31 P006-01/ /E008	YK901-YM670
C01495		BACC18AD2 CB-ELT INTERFACE UNIT (INOP)	233A5502 81205	1	23-24-11 P006-03/ /C001	YC001-YC007
C01495		BACC18AD2 CB-ELT INTERFACE UNIT (INOP)	233A5223 81205	1	23-24-11 P006-03/ /C001	YC008-YC050, YL421-YL423
C01495		BACC18AD2 CB-ELT INTERFACE UNIT	233A5223 81205	1	23-24-11 P006-03/ /C001	YK901-YL401, YL424-YM670

EQUIPMENT LIST

D280A103

Section C01400
Page 7 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01500		BACC18AD2 CB-CMU/ACARS DC	233A5221 81205	1	23-27-31 P006-01/ /E009	YK901-YM670
C01514		BACC18AD2 CB-OVERWING FLIGHT LOCK-LEFT	233A5202 81205	1	52-71-13 P006-02/ /D002	YC001-YC007
C01514		BACC18AD2 CB-OVERWING FLIGHT LOCK-LEFT	233A5222 81205	1	52-71-13 P006-02/ /D002	YC008-YM670
C01515		BACC18AD2 CB-OVERWING FLIGHT LOCK-RIGHT	233A5202 81205	1	52-71-14 P006-02/ /D001	YC001-YC007
C01515		BACC18AD2 CB-OVERWING FLIGHT LOCK-RIGHT	233A5222 81205	1	52-71-14 P006-02/ /D001	YC008-YM670
C01518		BACC18AD3 CB-EXTERIOR LIGHTING GENERAL LIGHT CONT	233A5523 81205	1	33-45-11 P018-03/ /D012	YK901-YM670
C01519	9	BACC18AD2 CB-TERRAIN DISPLAY	233A5502 81205	1	34-49-11 P018-01/ /A007	YC003-YC006
C01519		BACC18AD2 CB-TERRAIN DISPLAY (INOP)	233A5502 81205	1	34-49-11 P018-01/ /A007	YC001-YC002, YC007
C01519		BACC18AD2 CB-TERRAIN DISPLAY	233A5521 81205	1	34-49-11 P018-01/ /A007	YC008-YM670
C01522	9	BACC18AD2 CB-CARGO FIRE FWD DET A	233A5502 81205	1	26-16-21 P018-03/ /C017	YC001-YC007
C01522		BACC18AD2 CB-CARGO FIRE FWD DET A	233A5523 81205	1	26-16-21 P018-03/ /C017	YC008-YM670
C01523	9	BACC18AD2 CB-CARGO FIRE FWD DET B	233A5502 81205	1	26-16-21 P018-03/ /C016	YC001-YC007
C01523		BACC18AD2 CB-CARGO FIRE FWD DET B	233A5523 81205	1	26-16-21 P018-03/ /C016	YC008-YM670
C01524	9	BACC18AD2 CB-CARGO FIRE AFT DET A	233A5502 81205	1	26-16-22 P018-03/ /C019	YC001-YC007
C01524		BACC18AD2 CB-CARGO FIRE AFT DET A	233A5523 81205	1	26-16-22 P018-03/ /C019	YC008-YM670
C01525	9	BACC18AD2 CB-CARGO FIRE AFT DET B	233A5502 81205	1	26-16-22 P018-03/ /C018	YC001-YC007
C01525		BACC18AD2 CB-CARGO FIRE AFT DET B	233A5523 81205	1	26-16-22 P018-03/ /C018	YC008-YM670

EQUIPMENT LIST

D280A103

Section C01500

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01526	9	BACC18AD5 CB-CARGO FIRE EXT 1	233A5502 81205	1	26-23-11 P018-03/ /B017	YC001-YC007
C01526		BACC18AD5 CB-CARGO FIRE EXT 1	233A5523 81205	1	26-23-11 P018-03/ /B017	YC008-YM670
C01528		BACC18AD5 CB-CARGO FIRE EXT 2	233A5523 81205	1	26-23-11 P018-03/ /B016	YK918-YL401, YL429
C01537		BACC18AD2 CB-VOICE RCDR RELAY	233A5522 81205	1	23-71-11 P018-02/ /C007	ALL
C01551		BACC18AD5 CB-ISFD	233A5522 81205	1	34-24-15 P018-02/ /D008	YK901-YM670
C01583	9	BACC18AD2 CB-ENTERTAINMENT PA SYS BAT	233A5221 81205	1	23-31-11 P006-01/ /C006	YC001-YC013
C01583		BACC18AD2 CB-ENTERTAINMENT PA SYS BAT	233A5221 81205	1	23-31-11 P006-01/ /C006	YC015-YM670
C01584	9	BACC18AD3 CB-ENTERTAINMENT AUDIO DC	233A5221 81205	1	23-34-01 P006-01/ /B010	YC001-YC013
C01584		BACC18AD3 CB-ENTERTAINMENT AUDIO DC	233A5221 8 05	1	23-34-01 P006-01/ /B010	YC015-YC050
C01584		BACC18AD3 CB-ENTERTAINMENT AUDIO DC	233A5221 81205	1	23-34-01 P006-01/ /B010	YK901-YM670

EQUIPMENT LIST

D280A103

Section C01500
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01611	9	BACC18AD5 CB-SPDBRK AUTOSTOW (APB 0802664)	233A5222	1	27-62-41 P006-02/ /A010	YC001-YC010, YC012-YC030
C01611		BACC18AD5 CB-SPDBRK AUTOSTOW	233A5222	0	27-62-41 P006-02/ /A010	YM643-YM670
C01613	9	BACC18AD2 CB-AIR COND PACK CONT VALVES L ALT	233A5224 81205	1	21-51-12 P006-04/ /D003	YC001-YC022
C01613		BACC18AD2 CB-AIR COND PACK CONT VALVES L ALT	233A5224 81205	1	21-51-12 P006-04/ /D003	YC023-YL430
C01614	9	BACC18AD2 CB-AIR COND PACK CONT VALVES R ALT	233A5224 81205	1	21-51-22 P006-04/ /D004	YC001-YC022
C01614		BACC18AD2 CB-AIR COND PACK CONT VALVES R ALT	233A5224 81205	1	21-51-22 P006-04/ /D004	YC023-YL430
C01627	9	BACC18AD2 CB-CABIN UTILITY RLY PWR	233A5225 81205	1	24-28-41 P006-11/ /A008	YC001-YC030
C01627		BACC18AD2 CB-CABIN UTIL RLY PWR	233A5225 81205	1	24-28-41 P006-11/ /A008	YC031-YM670
C01628	9	BACC18AD2 CB-FORCE FIGHT MONITOR (SB 27-1253)	233A5222	1	27-23-11 P006-02/ /D015	YC001-YC030
C01628		BACC18AD2 CB-FORCE FIGHT MONITOR	233A5222	1	27-23-11 P006-02/ /D015	YC030-YM670
C01629		BACC18AD10 CB-AFCS SYS A RUDDER DC (INOP)	233A5521 81205	1	22-11-11 P018-01/ /E004	YC031-YK920, YM643-YM646
C01629		BACC18AD10 CB-AFCS SYS A RUDDER DC	233A5521 81205	1	22-11-11 P018-01/ /E004	YL401-YL430, YM647-YM670
C01630		BACC18AD10 CB-AFCS SYS B RUDDER DC (INOP)	233A5222 81205	1	22-11-11 P006-02/ /D003	YC031-YK920, YM643-YM646
C01630		BACC18AD10 CB-AFCS SYS B RUDDER DC	233A5222 81205	1	22-11-11 P006-02/ /D003	YL401-YL430, YM647-YM670
C01631		BACC18AD5 CB-AFCS INTLK 2	233A5222 81205	1	22-11-12 P006-02/ /A003	YC031-YM670
C01637	9	BACC18AD2 CB-BOOST PMP CTR TNK L AUTO SHUT OFF-DC	233A5223 81205	1	28-23-11 P006-03/ /C003	YC001-YC030
C01637		BACC18AD2 CB-BOOST PMP CTR TNK L AUTO SHUT OFF-DC	233A5223 81205	1	28-23-11 P006-03/ /C003	YC031-YM670

EQUIPMENT LIST

D280A103

Section C01600

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01638	9	BACC18AD2 CB-BOOST PMP CTR TNK R AUTO SHUT OFF-DC	233A5223 81205	1	28-23-11 P006-03/ /C007	YC001-YC030
C01638		BACC18AD2 CB-BOOST PMP CTR TNK R AUTO SHUT OFF-DC	233A5223 81205	1	28-23-11 P006-03/ /C007	YC031-YM670
C01639	9	BACC18AD2 CB-BOOST PUMP CTR TNK L AUTO SHUT OFF-AC	233A5223 81205	1	28-23-11 P006-03/ /D007	YC001-YC030
C01639		BACC18AD2 CB-BOOST PUMP CTR TNK L AUTO SHUT OFF-AC	233A5223 81205	1	28-23-11 P006-03/ /D007	YC031-YK906
C01640	9	BACC18AD2 CB-BOOST PUMP CTR TNK R AUTO SHUT OFF-AC	233A5223 81205	1	28-23-11 P006-03/ /E007	YC001-YC030
C01640		BACC18AD2 CB-BOOST PUMP CTR TNK R AUTO SHUT OFF-AC	233A5223 81205	1	28-23-11 P006-03/ /E007	YC031-YK906
C01641		BACC18AD5 CB-SURVEILLANCE CAMERA	233A5226 81205	1	23-70-11 P006-12/ /B001	YK907-YM670
C01643	9	BACC18AD5 CB- FD - PC POWER (SB 24-1180)	233A5226 81205	1	25-29-11 P006-12/ /A003	YK907-YK909
C01643		BACC18AD5 CB- FD - PC POWER	233A5226 81205	1	25-29-11 P006-12/ /A003	YL421-YL430
C01649		BACC18AD3 CB-WINDOW HEAT POWER RIGHT SIDE	233A5226 81205	1	30-41-12 P006-12/ /B007	YC031-YM670
C01650		BACC18AD3 CB-WINDOW HEAT POWER LEFT SIDE	233A5225 81205	1	30-41-11 P006-11/ /B007	YC031-YM670
C01657		BACC18AD7 CB - NITROGEN GEN CONT (-800) (INOP)	233A5523 81205	1	47-30-11 P018-03/ /D017	YC031-YC050, YK906-YK910, YK918, YL421- YL426
C01657		BACC18AD7 CB - NITROGEN GEN CONT (-800)	233A5523 81205	1	47-30-11 P018-03/ /D017	YK911-YK917, YK919-YL401, YL427-YL430
C01657		BACC18AD7 CB - NITROGEN GEN CONT (-700) (INOP)	233A5523 81205	1	47-30-11 P018-03/ /D017	YM643-YM647
C01657		BACC18AD7 CB - NITROGEN GEN CONT (-700)	233A5523 81205	1	47-30-11 P018-03/ /D017	YM649-YM670
C01658		BACC18AD2 CB-FUEL AT S-O/UCPO BST PMP CTR TNK R AC	233A5223	0	28-23-11 P006-03/ /E007	YK907-YM670

EQUIPMENT LIST

D280A103

Section C01600

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01659		BACC18AD2 CB-AT S-O/UCPO BST PMP CTR TNK L AC	233A5223	0	28-23-11 P006-03/ /D007	YK907-YM670
C01662		BACC18AD5 CB-SPOILER PCU SOV SYS A	233A5222 81205	0	27-62-11 P006-02/ /A004	YK907-YL430
C01663		BACC18AD5 CB-SPOILER PCU SOV SYS B	233A5222 81205	0	27-62-11 P006-02/ /A005	YK907-YL430
C01670		BACC18AD2 CB-AIRSHOW AC	233A5221 81205	1	23-32-21 P006-01/ /B011	YK910-YL430, YM647-YM670
C01677		BACC18AD2 CB- FLIGHT VU SYSTEM (INOP)	233A5522 81205	1	23-70-11 P018-02/ /B009	YK901-YK906
C01680		BACC18AD7 CB-NGS ALT PWR (-800) (INOP)	233A5523	0	47-30-11 P018-03/ /E015	YC031-YC050, YK906-YK910, YK918, YL421- YL426
C01680		BACC18AD7 CB-NGS ALT PWR (-800)	233A5523	0	47-30-11 P018-03/ /E015	YK911-YK917, YK919-YL401, YL427-YL430
C01680		BACC18AD7 CB-NGS ALT PWR (-700) (INOP)	233A5523	0	47-30-11 P018-03/ /E015	YM643-YM647
C01680		BACC18AD7 CB-NGS ALT PWR (-700)	233A5523	0	47-30-11 P018-03/ /E015	YM649-YM670
C01698		BACC18AD2 CB-TAKEOFF WARNING LIGHT	233A5222 81205	1	31-53-11 P006-02/ /D020	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670

EQUIPMENT LIST

D280A103

Section C01600

Page 3 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C02022		BACC18X25 CB-HOT BAT BUS	S281A601 07217	0	24-61-11 M01720/ /B003	ALL
C02029		BACC18AD10 CB-AC BUS AC STBY BUS PWR	233A5202 81205	1	24-34-11 P006-04/ /D018	YC001-YC007
C02029		BACC18AD10 CB-AC BUS AC STBY BUS PWR	233A5224 81205	1	24-34-11 P006-04/ /D018	YC008-YM670
C02043		BACC18AD7 CB-AC BUS 28V AC XFR BUS 2 SECT 2	233A5202 81205	1	24-53-11 P006-04/ /D014	YC001-YC007
C02043		BACC18AD7 CB-AC BUS 28V AC XFR BUS 2 SECT 2	233A5224 81205	1	24-53-11 P006-04/ /D014	YC008-YM670
█ C02044		BACC18AD10 CB-28V AC XFR BUS 1	S281A601 07217	1	24-53-11 P091-00/ /B010	ALL
█ C02045		BACC18AD10 CB-28V AC XFR BUS 2	S281A601 07217	1	24-53-11 P092-00/ /B010	ALL
C02046		BACC18AD10 CB-28V AC XFR BUS 1 SECT 2	233A5502 81205	1	24-53-11 P018-03/ /C005	YC001-YC007
C02046		BACC18AD10 CB-28V AC XFR BUS 1 SECT 2	233A5523 81205	1	24-53-11 P018-03/ /C005	YC008-YM670
C02047		BACC18AD5 CB-AC BUS STBY BUS 28V AC DISTR	233A5202 81205	1	24-53-11 P006-04/ /D015	YC001-YC007
C02047		BACC18AD5 CB-AC BUS STBY BUS 28V AC DISTR	233A5224 81205	1	24-53-11 P006-04/ /D015	YC008-YM670

EQUIPMENT LIST

D280A103

Section C02000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
■ C02812		BACC18AE25 CB-EXT PWR 2	S281A601 07217	1	24-52-11 P092-00/ /A015	ALL
■ C02813		BACC18AE25 CB-GND SERV 2	S281A601 07217	1	24-52-11 P092-00/ /F001	YC001-YK906
■ C02813		BACC18AE25 CB-GND SERV 2	S281A601 07217	1	24-52-11 P092-00/ /A009	YK907-YM670

EQUIPMENT LIST

D280A103

Section C02800

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
■ C03001		BACC18AE35 CB-XFR BUS 1 SECT 1	S281A601 07217	1	24-51-11 P091-00/ /F004	ALL
■ C03002		10-60806-1050 CB-XFR BUS 1 SECT 2	S281A601 07217	1	24-51-11 P091-00/ /F005	ALL
■ C03003		10-60806-1050 CB-XFR BUS 1 IFE (INOP)	S281A601 07217	1	24-51-11 P091-00/ /F001	YC031-YC050, YK907-YM670
■ C03011		BACC18AE35 CB-XFR BUS 2 SECT 1	S281A601 07217	1	24-51-21 P092-00/ /F004	ALL
■ C03012		10-60806-1050 CB-XFR BUS 2 SECT 2	S281A601 07217	1	24-51-21 P092-00/ /F005	ALL
■ C03013		10-60806-1050 CB-XFR BUS 2 IFE (INOP)	S281A601 07217	1	24-51-21 P092-00/ /F001	YC031-YC050, YK907-YM670
■ C03041		BACC18AC10 CB-GND SERV 1 SECT 1	S281A601 07217	1	24-52-11 P091-00/ /E005	ALL
■ C03051		BACC18X50 CB-DC BUS 1 SECT 1	S281A601 07217	1	24-61-11 P091-00/ /A002	ALL
■ C03052		BACC18X35 CB-DC BUS 1 SECT 2	S281A601 07217	1	24-61-11 P091-00/ /C012	ALL
■ C03061		BACC18X25 CB-BAT BUS SECT 1	S281A601 07217	1	24-61-11 M01720/ /C004	ALL
■ C03062		BACC18X25 CB-BAT BUS SECT 2	S281A601 07217	1	24-61-11 M01720/ /C005	ALL
■ C03063		BACC18X25 CB-BAT BUS SECT 3	S281A601 07217	1	24-61-11 M01720/ /A001	ALL
C03064		BACC18AD10 CB-ELECTRICAL GND SERV DC 1	233A5202 81205	1	24-61-11 P006-04/ /D011	YC001-YC007
C03064		BACC18AD10 CB-ELECTRICAL GND SERV DC 1	233A5224 81205	1	24-61-11 P006-04/ /D011	YC008-YM670
C03065		BACC18AD10 CB-ELECTRICAL GND SERV DC HOT BAT	233A5202 81205	1	24-61-11 P006-04/ /E012	YC001-YC007
C03065		BACC18AD10 CB-ELECTRICAL GND SERV DC HOT BAT	233A5224 81205	1	24-61-11 P006-04/ /E012	YC008-YM670
C03066		BACC18X35 CB-STBY BUS SECT 1	S281A601 07217	1	24-61-11 M01720/ /C001	ALL

EQUIPMENT LIST

D280A103

Section C03000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C03067		BACC18X35 CB-STBY BUS SECT 2	S281A601 07217	1	24-61-11 M01720/ /C002	ALL
■ C03071		BACC18X35 CB-DC BUS 2 SECT 1	S281A601 07217	1	24-61-11 P092-00/ /C012	ALL
■ C03072		BACC18X50 CB-DC BUS 2 SECT 2	S281A601 07217	1	24-61-11 P092-00/ /A002	ALL

EQUIPMENT LIST

D280A103

Section C03000
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C09001	9	BACC18Z3R CB-DISPLAY/TERRAIN (737-EB34-0155)	CUSTOMER 81205	1	34-49-11 P018-01/ /	YC003-YC006
C09002	9	CUSTOMER CB-CDSS (230116)	CUSTOMER CUST	1	23-70-11 P018-02/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section C09000
Page 1 End
May 13/2008



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00042	1	BACC45FT14-12S PLUG-BATT CHARGER	81205	1	24-31-11 E002-01/ /	YC001-YC030, YK901-YM670
D00042 T	1	BACC10JC14 BACKSHELL-90 DEGREE	81205	1	24-31-11 E002-01/ /	YK901-YM670
D00044	1	MS25182-2 PLUG-BATTERY	96906	1	24-31-11 390/165/L008	YC001-YC030, YK901-YM670
D00046	1	BACC45FT14-4P PLUG-STATIC INVERT	81205	1	24-34-11 E002-02/ /	ALL
D00046 T	1	BACC10JC14 BACKSHELL-	81205	1	24-34-11 E002-02/ /	YC001-YC050
D00046 T	1	BACC10JC14 BACKSHELL-	81205	1	24-34-11 */*/*	YK901-YM670
D00048		MS90362-3 RECP-EXT PWR AC (737-800)	284A0807 88044	1	24-41-11 235/180/R028	YC001-YK912, YK918-YK919, YL401-YL429
D00048		MS90362-3 RECP-EXT PWR AC (737-700)	284A0807 88044	1	24-41-11 235/180/R028	YM643-YM652
D00057	1	795-15-9 PLUG - (C) STRAIGHT	91836	1	34-32-11 610/143/0	ALL
D00062	1	BACC45FT12-3S PLUG-LEFT WINDSHIELD WIPER MOTOR	81205	1	30-42-11 192/239/L012	ALL
D00064	1	BACC45FT12-3S PLUG-RIGHT WINDSHIELD WIPER MOTOR	81205	1	30-42-11 189/239/R012	ALL
D00070	1	BACC63BP14D4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	28-23-11 ORSS160/185/L083	YC001-YC030
D00070	1	BACC63BP14D4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	28-23-11 IRSS 160/ /	YC031-YM670
D00070 T	1	BACC10KB14 BACKSHELL	81205	1	28-23-12 */*/*	ALL
D00072	1	BACC63BP14D4SN PLUG	81205	1	28-23-11 IFSS-121/ /	ALL
D00072 T	1	BACC10KB14 BACKSHELL	81205	1	28-23-11 IFSS-121/ /	YC001-YC022

EQUIPMENT LIST

D280A103

Section D00000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00072 T	1	BACC10KC14 BACKSHELL	81205	1	28-23-11 IFSS-121/ /	YC023-YC030
D00072 T	1	BACC10KC14 BACKSHELL	81205	1	28-23-11 */*/*	YC031-YM670
D00074	1	BACC63BP14D4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	28-23-11 IRSS 145/ /	ALL
D00074 T	1	BACC10KB14 CLAMP, STRAIGHT	81205	1	28-23-11 TBD/ /	YC001-YC028
D00074 T	1	BACC10KB14 CLAMP, STRAIGHT	81205	1	28-23-11 */*/*	YC029-YM670
D00076	1	BACC63BP14D4SN PLUG	81205	1	28-23-12 IFSS 121/ /	ALL
D00076 T	1	BACC10KB14 BACKSHELL	81205	1	28-23-12 */*/*	YC001-YC022
D00076 T	1	BACC10KC14 BACKSHELL	81205	1	28-23-12 */*/*	YC023-YM670
D00085	1	796-15-9 PLUG - (C) ANGLED 90 (OUT-1)	91836	1	34-31-11 178/237/R002	ALL
D00087	1	796-15-9 PLUG - (C) ANGLED 90 (OUT-2)	91836	1	34-31-21 178/237/L002	ALL
D00089	1	795-16-9 PLUG - (C)	91836	1	34-51-11 1200/578/L001	YC001-YK912, YK918-YK919, YL401-YL426, YM643-YM652
D00089	1	795-33-9 PLUG - (C)	91836	1	34-51-11 1200/578/L001	YK913-YK917, YK920, YL427- YL430, YM653- YM670
D00090	1	BACC45FT14-7S PLUG-	81205	1	21-61-51 P005-17/ /	ALL
D00091	1	795-16-9 PLUG - (C)	91836	1	34-51-21 1200/578/R001	YC001-YK912, YK918-YK919, YL401-YL426, YM643-YM652

EQUIPMENT LIST

D280A103

Section D00000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00091	1	795-33-9 PLUG - (C)	91836	1	34-51-21 1200/578/R001	YK913-YK917, YK920, YL427- YL430, YM653- YM670
D00093	1	795-16-9 PLUG-DME ANT NO.1	91836	1	34-55-11 0465/ /	YC001-YC020
D00093	1	795-16-9 PLUG-DME ANT NO.1	91836	1	34-55-11 580.5/144/0	YC021-YM670
D00094	1	BACC63CE12S-3S PLUG-	81205	1	21-61-51 538/299/R012	YM643-YM670
D00094 T	1	BACC10HW12 BACKSHELL-	81205	1	21-61-31 */**	YM643-YM670
D00095	1	795-16-9 PLUG-DME ANT NO.2	91836	1	34-55-21 641/143/0	ALL
D00096	1	BACC45FT12-12S8 PLUG-	81205	1	36-21-11 P005-10/ /	YC001-YC030, YK901-YM670
D00098	1	BACC63BP10D5S8L PLUG-	81205	1	36-21-11 538/165/R030	ALL
D00098 T	1	BACC10KB10 BACKSHELL-90 DEGREE	81205	1	36-21-11 */**	ALL
D00099	1	795-21-9 PLUG	91836	1	34-53-31 355/149/0	ALL

EQUIPMENT LIST

D280A103

Section D00000

Page 3 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00100	1	BACC63BP10D5S8 PLUG-	81205	1	36-21-11 538/165/L030	YC001-YL430
D00100	1	BACC63BP10D5S8 PLUG-	81205	1	36-21-11 538/164/L030	YM643-YM670
D00100 T	1	BACC10KB10 BACKSHELL-90 DEGREE	81205	1	36-21-11 */**	ALL
D00102	1	DPXAMA-A10-33S PLUG-T/R UNIT	71468	1	24-32-11 E002-01/ /	ALL
D00102 T	1	63-9273-2 SPACER-	81205	1	24-32-11 E002-01/ /	ALL
D00104	1	DPXAMA-A10-33S PLUG	71468	1	24-32-11 E004-02/ /	ALL
D00104 T	1	63-9273-2 SPACER	81205	1	24-32-11 E004-02/ /	YC001-YC009
D00104 T	1	63-9273-2 SPACER	81205	1	24-32-11 */**	YC010-YM670
D00106	1	DPXAMA-A10-33S PLUG	71468	1	24-32-11 E004-02/ /	ALL
D00106 T	1	63-9273-2 SPACER	81205	1	24-32-11 E004-02/ /	YC001-YC009
D00106 T	1	63-9273-2 SPACER	81205	1	24-32-11 */**	YC010-YM670
D00115	1	796-17-9 PLUG-VHF COMM NO. 1 ANT	91836	1	23-12-11 630/305/R005	YC001-YC019
D00115	1	796-17-9 PLUG	91836	1	23-12-11 630/305/R005	YC020-YM670
D00117	1	795-21-9 PLUG- VHF COMM NO.2 ANT	91836	1	23-12-21 727D+10/149/0	ALL
D00119	1	MS3475W22-55S PLUG	96906	1	34-41-11 175/200/L003	ALL
D00119 T	1	G9263AA2206KNF BACKSHELL - 90 DEGREE	MIL	1	34-41-11 */**	ALL
D00127	1	BACC45FT10-5S PLUG-CAPT SPKR	81205	1	23-51-11 200/262/L035	ALL

EQUIPMENT LIST

D280A103

Section D00100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00129	1	BACC45FT10-5S PLUG-FO SPKR	81205	1	23-51-21 237/268/R013	ALL
D00131	1	BACC45FT14A15S7 PLUG AUDIO SEL CAPT	81205	1	23-22-11 P008-06/ /	YK907-YM670
D00133	1	MS3126F14-19S PLUG-AUD SEL CAPT-	96906	1	23-51-11 P008-06/ /	ALL
D00135	1	BACC45FT14A15S7 PLUG-AUDIO SEL F/O	81205	1	23-22-11 P008-07/ /	YK907-YM670
D00137	1	MS3126F14-19S PUG-AUDIO SEL F/O	96906	1	23-51-21 P008-7/ /	ALL
D00139	1	PT08SE-14-19S-SR- PLUG-AUDIO SEL OBS	77820	1	23-51-31 P005-15/ /	ALL
D00141	1	BACC45FT14D15S7 PLUG-	81205	1	23-22-11 P005-15/ /	YK907-YM670
D00148	1	MS3126F16-8S PLUG-	96906	1	33-44-12 1212/284/L002	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00149	1	BACC66H123C05AK01 PLUG PLATE ASSY	81205	1	34-53-11 E001-02/ /	YC001-YC030, YK901-YM670
D00149A	1	PARTAD00149 PLUG		0	34-53-11 E001-02/ /	YC001-YC030
D00149A	1	PARTAD00149 PLUG		0	34-53-11 */*/*	YK901-YM670
D00149AT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-ATC-1	81205	1	34-53-11 E001-02/ /	YC001-YC030
D00149AT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-ATC-1	81205	1	34-53-11 */*/*	YK901-YM670
D00149AU	1	125-92-9 PLUG-ATC-1	91836	1	34-53-11 E001-02/ /	YC001-YC030
D00149AU	1	125-92-9 PLUG-ATC-1	91836	1	34-53-11 */*/*	YK901-YM670
D00149B	1	PARTBD00149 PLUG		0	34-53-11 E001-02/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D00100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00149B	1	PARTBD00149 PLUG		0	34-53-11 */**	YK901-YM670
D00149BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-ATC-1	81205	1	34-53-11 E001-02/ /	YC001-YC030
D00149BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-ATC-1	81205	1	34-53-11 */**	YK901-YM670
D00149BU	1	125-95-9 PLUG-ATC-1	91836	1	34-53-11 E001-02/ /	YC001-YC030
D00149BU	1	125-95-9 PLUG-ATC-1	91836	1	34-53-11 */**	YK901-YM670
D00149C	1	PARTCD00149 PLUG		0	34-53-11 E001-02/ /	YC001-YC030
D00149C	1	PARTCD00149 PLUG		0	34-53-11 */**	YK901-YM670
D00150		5258 RCPT-CONT CAB SERVICE OUTLET	65C25704 74545	1	25-29-11 P006-00/ /	ALL
D00152		5258 RCPT-EQUIP RACK SERVICE OUTL	284A0211 74545	1	25-29-11 359/164/R004	ALL
D00154		5656 RCPT-CONT CAB SERVICE OUTLET	65C25704 74545	1	25-29-11 P006-00/ /	ALL
D00155	1	BACC66H123C05AK01 PLUG PLATE ASSY	81205	1	34-53-21 E001-05/ /	YC001-YC030, YK901-YM670
D00155A	1	PARTAOFD00155 PLUG		0	34-53-21 E001-05/ /	YC001-YC030
D00155A	1	PARTAOFD00155 PLUG		0	34-53-21 */**	YK901-YM670
D00155AT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-ATC-2	81205	1	34-53-21 E001-05/ /	YC001-YC030
D00155AT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-ATC-2	81205	1	34-53-21 */**	YK901-YM670
D00155AU	1	125-95-9 PLUG-ATC-2	91836	1	34-53-21 E001-05/ /	YC001-YC030
D00155AU	1	125-95-9 PLUG-ATC-2	91836	1	34-53-21 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D00100

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00155B	1	PARTBOFD00155 PLUG		0	34-53-21 E001-05/ /	YC001-YC030
D00155B	1	PARTBOFD00155 PLUG		0	34-53-21 */**	YK901-YM670
D00155BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-ATC-2	81205	1	34-53-21 E001-05/ /	YC001-YC030
D00155BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-ATC-2	81205	1	34-53-21 */**	YK901-YM670
D00155BU	1	125-88-9 PLUG-ATC-2	91836	1	34-53-21 E001-05/ /	YC001-YC030, YK901-YM670
D00155C	1	PARTCOFD00155 PLUG		0	34-53-21 E001-05/ /	YC001-YC030
D00155C	1	PARTCOFD00155 PLUG		0	34-53-21 */**	YK901-YM670
D00156	1	CR015I RCPT-FWD VACUUM CLEANER	411A2202 74545	1	25-29-11 293/221/R054	ALL
D00156	2	CRO20I RCPT-FWD VACUUM CLEANER	411A2202 74545	1	25-29-11 293/221/R054	ALL
D00158	1	CR015I RCPT-AFT VACUUM CLEANER	411A2204 74545	1	25-29-11 954/221/R059	ALL
D00158	2	CRO20I RCPT-AFT VACUUM CLEANER	411A2204 74545	1	25-29-11 954/221/R059	ALL
D00160	1	BACC45FT14-7S PLUG-	81205	1	21-27-21 370/164/R027	YC001-YC030, YK901-YM670
D00160 T	1	450EB001C14-347 BACKSHELL-	81205	1	21-27-21 */**	YC001-YC030, YK901-YM670
D00161	1	BACC66H125F03AK01 PLUG PLATE ASSY	81205	1	34-55-11 E001-02/ /	YC001-YC030, YK901-YM670
D00161A	1	PARTAOFD00161 PLUG		0	34-55-11 E001-02/ /	YC001-YC030
D00161A	1	PARTAOFD00161 PLUG		0	34-55-11 */**	YK901-YM670
D00161B	1	PARTBOFD00161 PLUG		0	34-55-11 E001-02/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D00100

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00161B	1	PARTBOFD00161 PLUG		0	34-55-11 */**	YK901-YM670
D00161BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-DME-1	81205	1	34-55-11 E001-02/ /	YC001-YC030
D00161BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-DME-1	81205	1	34-55-11 */**	YK901-YM670
D00161BU	1	125-91-9 PLUG-DME-1	91836	1	34-55-11 E001-02/ /	YC001-YC030
D00161BU	1	125-91-9 PLUG-DME-1	91836	1	34-55-11 */**	YK901-YM670
D00161C	1	PARTCOFD00161 PLUG		0	34-55-11 E001-02/ /	YC001-YC030
D00161C	1	PARTCOFD00161 PLUG		0	34-55-11 */**	YK901-YM670
D00162	1	BACC45FT14-7S PLUG-	81205	1	21-27-21 370/164/R027	YC001-YC030
D00162	1	BACC45FT14-7S PLUG-	81205	1	21-27-21 378/163/R027	YC031-YM652
D00162 T	1	BACC10JC14 BACKSHELL-90 DEGREE	81205	1	21-27-21 */**	YC001-YM652
D00164	1	BACC45FT12-12S PLUG-LOW FLOW SENSOR	81205	1	21-27-21 200/189/R020	YC001-YC030, YK901-YM670
D00164 T	1	BACC10JS12 BACKSHELL, STRAIGHT	81205	1	21-27-21 */**	YC001-YC030, YK901-YM670
D00169	1	BACC66H125F03AK01 PLUG PLATE ASSY	81205	1	34-55-21 E001-05/ /	YC001-YC030, YK901-YM670
D00169A	1	PARTAOFD00169 PLUG		0	34-55-21 E001-05/ /	YC001-YC030
D00169A	1	PARTAOFD00169 PLUG		0	34-55-21 */**	YK901-YM670
D00169B	1	PARTBOFD00169 PLUG		0	34-55-21 E001-05/ /	YC001-YC030
D00169B	1	PARTBOFD00169 PLUG		0	34-55-21 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D00100

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00169BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-DME-2	81205	1	34-55-21 E001-05/ /	YC001-YC030
D00169BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1-PLUG-DME-2	81205	1	34-55-21 */**	YK901-YM670
D00169BU	1	125-91-9 PLUG-DME-2	91836	1	34-55-21 E001-05/ /	YC001-YC030
D00169BU	1	125-91-9 PLUG-DME-2	91836	1	34-55-21 */**	YK901-YM670
D00169C	1	PARTCOFD00169 PLUG		0	34-55-21 E001-05/ /	YC001-YC030
D00169C	1	PARTCOFD00169 PLUG		0	34-55-21 */**	YK901-YM670
D00170	1	BACC63CB12-3SN PLUG-	81205	1	21-61-22 644/158/R012	YM643-YM670
D00170 T	1	BACC10KD12 BACKSHELL-STRAIGHT	81205	1	21-61-22 */**	YM643-YM670
D00172	1	BACC63CB12-3SN PLUG-	81205	1	21-61-21 644/158/L012	YM643-YM670
D00172 T	1	BACC10KD12 BACKSHELL-STRAIGHT	81205	1	21-62-21 */**	YM643-YM670
D00177	1	DPXBMB-57-33S-0001 PLUG- VOICE RECORDER	71468	1	23-71-01 901/194/R040	YC001-YC007
D00177	1	DPXBMB-57-33S-0001 PLUG- VOICE RECORDER	71468	1	23-71-01 902/193/R043	YC008-YL430
D00177	1	DPXBMB-57-33S-0001 PLUG- VOICE RECORDER	71468	1	23-71-01 E006-01/ /	YM643-YM670
D00179	1	MS3126F20-41S PLUG-VOICE REC CONT PNL	96906	1	23-71-01 P005-07/ /	ALL
D00183	1	DPX2MB-57S57S-33-0301 PLUG PLATE ASSY	71468	1	31-31-11 0923/294/000	ALL
D00183A	1	PARTAOFD00183 PLUG-FLT RECORDER		0	31-31-11 0923/294/000	ALL
D00183B	1	PARTBOFD00183 PLUG-FLT RECORDER		0	31-31-11 0923/295/000	ALL

EQUIPMENT LIST

D280A103

Section D00100

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00189	1	BACC66H24F12AA01 PLUG	81205	1	34-41-11 197/180/R005	YC001-YC030, YK901-YM670
D00189 T	1	3602982-0501 WAVE GUIDE INSERT	27914	1	34-41-11 */**	YC001-YC030, YK901-YM670
D00189 T	2	317-1641-000 WAVE GUIDE INSERT	71468	1	34-41-11 */**	YC001-YC030, YK901-YM670
D00189A	1	PARTAOFD00189 PLUG		0	34-41-11 197/180/R005	YC001-YC030, YK901-YM670
D00189B	1	PARTBOFD00189 PLUG		0	34-41-11 197/180/R005	YC001-YC030, YK901-YM670
D00189C	1	PARTCOFD00189 PLUG		0	34-41-11 197/180/R005	YC001-YC030, YK901-YM670
D00192	1	BACC45FT12-12S PLUG-	81205	1	38-41-11 952/186/R035	ALL
D00192 T	1	MS27559-3 BACKSHELL-	96906	1	38-41-11 */**	ALL
D00193	1	MS3126F18-32S PLUG	96906	1	34-41-11 P8-52/ /	YC001-YC007
D00193	1	MS3126F18-32S PLUG	96906	1	34-41-11 P008-52/ /	YC008-YC030, YK901-YM670
D00199	1	BACC66F11C04AE01 PLUG PLATE ASSY - VHF 1	81205	1	23-12-11 E001-03/ /	ALL
D00199A	1	PARTAOFD00199 PLUG - VHF 1		0	23-12-11 E001-03/ /	YC001-YC050, YM643-YM670
D00199A	1	PARTAOFD00199 PLUG - VHF 1		0	23-12-11 */**	YK901-YL430
D00199B	1	PARTBOFD00199 PLUG - VHF 1		0	23-12-11 E001-03/ /	YC001-YC050, YM643-YM670
D00199B	1	PARTBOFD00199 PLUG - VHF 1		0	23-12-11 */**	YK901-YL430
D00199C	1	PARTCOFD00199 PLUG - VHF 1		0	23-12-11 E001-03/ /	YC001-YC050, YM643-YM670
D00199C	1	PARTCOFD00199 PLUG - VHF 1		0	23-12-11 */**	YK901-YL430

EQUIPMENT LIST

D280A103

Section D00100
Page 7 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00201	1	BACC66F11F04AE01 PLUG-VHF-2 TRANSCEIVER	81205	1	23-12-21 E001-05/ /	YC001-YC030, YK901-YM670
D00201 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-12-21 E001-05/ /	YC001-YC030
D00201 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-12-21 */*/*	YK901-YM670
D00201A	1	PARTAOFD00201 PLUG-VHF-2 TRANSCEIVER		0	23-12-21 E001-05/ /	YC001-YC030
D00201A	1	PARTAOFD00201 PLUG-VHF-2 TRANSCEIVER		0	23-12-21 */*/*	YK901-YM670
D00201B	1	PARTBOFD00201 PLUG-VHF-2 TRANSCEIVER		0	23-12-21 E001-05/ /	YC001-YC030
D00201B	1	PARTBOFD00201 PLUG-VHF-2 TRANSCEIVER		0	23-12-21 */*/*	YK901-YM670
D00201C	1	PARTCOFD00201 PLUG-VHF-2 TRANSCEIVER		0	23-12-21 E001-05/ /	YC001-YC030
D00201C	1	PARTCOFD00201 PLUG-VHF-2 TRANSCEIVER		0	23-12-21 */*/*	YK901-YM670
D00203	1	BACC63CB16-24SN PLUG-CONDUCTIVE CONNECTOR	81205	1	23-12-11 P8-2/ /	YC001-YC030
D00203	1	BACC63CB20-41SN PLUG-	81205	1	23-12-11 P008-71/ /	YK901-YM670
D00203 T	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	23-12-11 P8-2/ /	YC001-YC026
D00203 T	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	23-12-11 */*/*	YC028-YC030
D00203 T	1	BACC10KD20 BACKSHELL- CONDUCTIVE	81205	1	23-12-11 */*/*	YK901-YM670
D00209	1	BACC63CB16-24SN PLUG-CONDUCTIVE CONNECTOR	81205	1	23-12-21 P8-3/ /	YC001-YC050
D00209	1	BACC63CB20-41SN PLUG-	81205	1	23-12-21 P008-72/ /	YK901-YM670
D00209 T	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	23-12-21 P8-3/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section D00200

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00209 T	1	BACC10KD20 BACKSHELL- CONDUCTIVE	81205	1	23-12-21 */**	YK901-YM670
D00211	1	BACC45FT16-24S7 PLUG-ATC DUAL CONT	81205	1	34-53-11 P8-29/ /	YC001-YC007
D00211	1	BACC45FT16-24S7 PLUG-ATC DUAL CONT	81205	1	34-53-11 P008-29/ /	YC008-YM670
D00211 T	1	BACC10JS16 BACKSHELL	81205	1	34-53-11 P8-29/ /	YC001-YC007
D00211 T	1	BACC10JS16 BACKSHELL	81205	1	34-53-11 P008-29/ /	YC008-YC050
D00211 T	1	BACC10JS16 BACKSHELL	81205	1	34-53-11 */**	YK901-YM670
D00229	1	BACC63BP20C16SN PLUG-CONDUCTIVE	81205	1	27-52-11 ORSS/446/	YC001-YK906
D00229	1	BACC63BP20D16SN PLUG-CONDUCTIVE	81205	1	27-52-11 ORSS/446/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00229 T	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-52-11 */**	YC001-YK906
D00229 T	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	27-52-11 */**	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00235	1	BD2P124S124S-8805 PLUG PLATE ASSEMBLY	00779	1	34-21-15 E001-01/ /	ALL
D00235A	1	PARTAOFD00235 PLUG		0	34-21-15 E001-01/ /	YC001-YC050
D00235A	1	PARTAOFD00235 PLUG		0	34-21-15 */**	YK901-YM670
D00235B	1	PARTBOFD00235 PLUG		0	34-21-15 E001-01/ /	YC001-YC050
D00235B	1	PARTBOFD00235 PLUG		0	34-21-15 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D00200

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00263	1	BACC63CB22-55S8 PLUG - CONDUCTIVE	81205	1	34-51-11 P008-25/ /	YC001-YC030, YK901-YM670
D00263 T	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-51-11 P008-25/ /	YC001-YC030, YK901-YM670
D00265	1	BACC63CB22-55S8 PLUG - CONDUCTIVE	81205	1	34-51-21 P008-26/ /	YC001-YC030, YK901-YM670
D00265 T	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-51-21 P008-26/ /	YC001-YC030, YK901-YM670
D00275	1	BACC63BP20C16SN PLUG-CONDUCTIVE	81205	1	27-52-11 ORSS/446/	YC001-YK906
D00275	1	BACC63BP20D16SN PLUG-CONDUCTIVE	81205	1	27-52-11 ORSS/446/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00275 T	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-52-11 */**	YC001-YK906
D00275 T	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	27-52-11 */**	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00277	1	BACC45FT14-7S PLUG - TAT PROBE	81205	1	34-21-22 268/192/L049	ALL
D00277 T	1	BACC10JS14 BACKSHELL	81205	1	34-21-22 */**	ALL
D00281	1	PT06E-8-2S PLUG-CONTROL COLUMN SHAKER-CAPT	77820	1	27-32-12 210/218/L20	ALL
D00287	1	BACC63CB12-12SN RCPT-AOA SENSOR-RIGHT	81205	1	27-32-21 193/205/R029	YC001-YM652
D00287 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	27-32-21 / /	YC001-YM652
D00291	1	BACC63BP12C12SN PLUG	81205	1	22-23-12 1140/365/R6	YC001-YC011
D00291	1	BACC63BP12C12SN PLUG	81205	1	22-23-12 1140/365/R006	YC012-YC019

EQUIPMENT LIST

D280A103

Section D00200

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00291	1	BACC63BP12C12SN PLUG	81205	1	22-23-12 RUD57/ /	YC020-YM670
D00291 T	1	BACC10KE12 BACKSHELL	81205	1	22-23-12 / /	YC001-YC026
D00291 T	1	BACC10KE12 BACKSHELL	81205	1	22-23-12 */*/	YC028-YM670
D00299	1	BACC63CB22-55SN PLUG - CONDUCTIVE	81205	1	22-11-11 P007/ /	ALL
D00299 T	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	22-11-11 */ /	ALL

EQUIPMENT LIST

D280A103

Section D00200
Page 4 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00301	1	BACC63CB14-15SN PLUG - CONDUCTIVE	81205	1	22-11-51 P007/ /	ALL
D00301 T	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	22-11-11 */ /	ALL
D00303	1	BACC63CB22-55SN PLUG - CONDUCTIVE	81205	1	34-51-11 P008-25/ /	YC001-YC030, YK901-YM670
D00303 T	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-51-11 P008-25/ /	YC001-YC030, YK901-YM670
D00305	1	BACC63CB22-55SN PLUG - CONDUCTIVE	81205	1	34-51-21 P008-26/ /	YC001-YC030, YK901-YM670
D00305 T	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-51-21 P008-26/ /	YC001-YC030, YK901-YM670
D00319	1	BACC45FT12-12S PLUG	81205	1	22-23-11 P001-03/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00319 T	1	BACC10JS12 BACKSHELL	81205	1	22-23-11 */*/	YC001-YC007
D00319 T	1	BACC10JS12 BACKSHELL	81205	1	22-23-11 P001-03/ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00331	1	BACC63CB20-41SN PLUG - CONDUCTIVE	81205	1	31-62-13 P002-02/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00331 T	1	BACC10KF20 BACKSHELL - CONDUCTIVE - 45	81205	1	32-42-11 */*/	YC001-YC007
D00331 T	1	BACC10KF20 BACKSHELL - CONDUCTIVE - 45	81205	1	32-42-11 P002-02/ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D00300

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00333	1	BACC63CB22-55SN PLUG - CONDUCTIVE	81205	1	32-42-11 P002-02/ /	YC001-YC030, YK901-YL429, YM643-YM652
D00333 T	1	BACC10KF22 BACKSHELL - CONDUCTIVE - 45	81205	1	32-42-11 */ /	YC001-YC030
D00333 T	1	BACC10KF22 BACKSHELL - CONDUCTIVE - 45	81205	1	32-42-11 */ /*	YK901-YL429, YM643-YM652
D00335	1	795-21-9 PLUG-VHF COMM NO. 3 ANT	91836	1	23-12-31 471/149/L0	YC001-YC007
D00335	1	795-21-9 PLUG-	91836	1	23-12-31 471/149/L000	YC008-YM670
D00337	1	1205-62-9 PLUG-HF-1 COUPLER INPUT (RF-COAX)	91836	1	23-11-11 F057/330/L04	YC001-YC007
D00337	1	1205-62-9 PLUG	91836	1	23-11-11 F057/330/L04	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00339	1	BACC45FT14-15S PLUG	81205	1	31-62-23 P002-02/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00339 T	1	BACC10JS14 BACKSHELL	81205	1	31-62-23 */ /*	YC001-YC007
D00339 T	1	BACC10JS14 BACKSHELL	81205	1	31-62-23 P002-02/ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00341	1	MS3126E16-26S PLUG	96906	1	23-11-11 F057/330/L004	YC001-YC007, YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00345	1	BACC66H125C1001 PLUG-HF-1 TRANSCEIVER	81205	1	23-11-11 E008-01/ /	YC001-YC007, YK907-YL401

EQUIPMENT LIST

D280A103

Section D00300

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00345	1	BACC66H125C1001 PLUG - HF 1 TRANSCEIVER	81205	1	23-11-11 E0800-01/ /	YL421-YL430
D00345	1	BACC66H125C1001 PLUG	81205	1	23-11-11 E006-02/ /	YM643-YM670
D00345 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-11-11 E008-01/ /	YC001-YC007
D00345 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-11-11 E008-01/ /	YK907-YL430
D00345A	1	PARTAOFD00345 PLUG- HF-1 TRANSCEIVER		0	23-11-11 E008-01/ /	YC001-YC007
D00345A	1	PARTAOFD00345 PLUG- HF-1 TRANSCEIVER		0	23-11-11 */**	YK907-YL401
D00345A	1	PARTAOFD00345 PLUG - HF 1 TRANSCEIVER		0	23-31-11 / /	YL421-YL430
D00345A	1	PARTAOFD00345 PLUG		0	23-11-11 */**	YM643-YM670
D00345B		PARTBOFD00345 PLUG - HF 1 TRANSCEIVER		0	23-11-11 / /	YL421-YL430
D00345B	1	PARTBOFD00345 PLUG-HF-1 TRANSCEIVER		0	23-11-11 E008-01/ /	YC001-YC007
D00345B	1	PARTBOFD00345 PLUG-HF-1 TRANSCEIVER		0	23-11-11 */**	YK907-YL401
D00345B	1	PARTBOFD00345 PLUG		0	23-11-11 */**	YM643-YM670
D00345BT	1	BACC47EN4A CONTACT-(COAX) SIZE 1-PLUG- XCVR-1	81205	1	23-11-11 E008-01/ /	YC001-YC007, YK907-YL401
D00345BT	1	BACC47EN4A CONTACT-(COAX) SIZE 1 PLUG - XCVR-1	81205	1	23-11-11 E008-01/ /	YL421-YL430
D00345BT	1	BACC47EN4A CONTACT-(COAX)	81205	1	23-11-11 */**	YM643-YM670
D00345BU	1	125-95-9 PLUG-HF-1 TRANSCEIVER	91836	1	23-11-11 E008-01/ /	YC001-YC007, YK907-YL401
D00345BU	1	125-95-9 PLUG - HF 1 TRANSCEIVER	91836	1	23-11-11 E008-01/ /	YL421-YL430

EQUIPMENT LIST

D280A103

Section D00300

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00345BU	1	125-95-9 PLUG	91836	1	23-11-11 */**	YM643-YM670
D00345C	1	PARTCOFD00345 PLUG-HF-1 TRANSCEIVER		0	23-11-11 E008-01/ /	YC001-YC007
D00345C	1	PARTCOFD00345 PLUG-HF-1 TRANSCEIVER		0	23-11-11 */**	YK907-YL401
D00345C	1	PARTCOFD00345 PLUG - HF 1 TRANSCEIVER		0	23-11-11 / /	YL421-YL430
D00345C	1	PARTCOFD00345 PLUG		0	23-11-11 */**	YM643-YM670
D00365	1	BACC63CB12-12SN RCPT-AOA SENSOR-LEFT	81205	1	27-32-12 193/204/L029	ALL
D00365 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	27-32-12 / /	ALL
D00367	1	PT06E-8-2S PLUG-CONTROL COLUMN SHAKER-F/O	77820	1	27-32-22 210/218/R20	ALL
D00381	1	BACC63CB18-14S8 PLUG	81205	1	22-13-11 1072/ /	YC001-YC007
D00381	1	BACC63CB18-14S8 PLUG	81205	1	22-13-11 1075/234/R003	YC008-YC030
D00381	1	BACC63CB18-14S8 PLUG	81205	1	22-13-11 1074/235/R004	YK901-YM670
D00381 T	1	BACC10KD18 BACKSHELL	81205	1	22-13-11 / /	YC001-YC007
D00381 T	1	BACC10KD18 BACKSHELL	81205	1	22-13-11 */**	YC008-YC030, YK901-YM670
D00383	1	BACC45FN10-5S RCPT	81205	1	22-11-11 238/203/L014	ALL
D00385	1	BACC45FN10-5S RCPT	81205	1	22-11-11 227/202/R27	YC001-YC019
D00385	1	BACC45FN10-5S RCPT	81205	1	22-11-11 227/202/R027	YC020-YM670
D00392	1	BACC63BN10-20SN PLUG-	81205	1	21-51-11 577/157/L011	ALL

EQUIPMENT LIST

D280A103

Section D00300

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00392 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	21-51-11 */*/*	ALL
D00394	1	BACC63BN10-20SN PLUG-	81205	1	21-51-21 577/157/R013	ALL
D00394 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	21-51-21 */*/*	ALL
D00397	1	BACC45FN10-5S RCPT	81205	1	22-11-11 206/195/L25	YC001-YC019
D00397	1	BACC45FN10-5S RCPT	81205	1	22-11-11 206/195/L025	YC020-YM670
D00398	1	BACC63CB14-7SN PLUG-	81205	1	36-111 546/166/L001	ALL
D00398 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	36-11-11 */*/*	ALL

EQUIPMENT LIST

D280A103

Section D00300

Page 5 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00417	1	BACC45FT14-15S6 PLUG	81205	1	22-13-11 AF0222A/ /	ALL
D00417 T	1	BACC10JC14 BACKSHELL	81205	1	22-13-11 / /	YC001-YC019
D00417 T	1	BACC10JC14 BACKSHELL	81205	1	22-13-11 */**	YC020-YM670
D00419	1	BACC63CB14-15S9 PLUG-CONDUCTIVE	81205	1	23-11-11 P8-11/ /	YC001-YC007
D00419 T	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	23-11-11 P8-11/ /	YC001-YC007
D00423	1	BACC63CB20-41SN PLUG - CONDUCTIVE	81205	1	31-62-13 P001-03/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00423 T	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-13 */**	YC001-YC007
D00423 T	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-13 P001-03/ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00432	1	BACC45FT10-5S PLUG-	81205	1	35-11-11 P005-14/ /	YC001-YC030, YK901-YM670
D00438	1	BACC45FT10-5S PLUG-	81205	1	35-11-11 391/167/R007	ALL
D00438 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	1	35-11-11 */**	ALL
D00440	1	BACC45FT12-12S PLUG-	81205	1	35-31-11 P005-00/ /	YC001-YC030, YK901-YM670
D00446	1	BACC45FT14-4S PLUG-	81205	1	49-71-21 P005-04/ /	ALL
D00454	1	DPAMA-32-33S PLUG-PLATE ASSY	71468	1	21-61-21 E004-01/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section D00400

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00456	1	DPAMA-32-33S PLUG-PLATE ASSY	71468	1	21-61-22 E004-01/ /	YM643-YM670
D00458	1	DPX2MB-67S67S-33B-0005 PLUG-PLATE ASSY	71468	1	21-51-11 E004-01/ /	YC001-YL430
D00458	1	DPX2MB-57S57S-33B-0005 PLUG-PLATE ASSY	71468	1	21-25-11 E004-01/ /	YM643-YM670
D00458A	1	PARTAD00458 PLUG-AIR COND RELAY NO 1		0	21-51-11 E004-01/ /	YC001-YC026
D00458A	1	PARTAD00458 PLUG-AIR COND RELAY NO 1		0	21-51-11 */*/	YC028-YL430
D00458A	1	PARTAD00458 PLUG-AIR COND RELAY MDL		0	21-25-11 */*/	YM643-YM670
D00458B	1	PARTBOF0458 PLUG-AIR COND RELAY NO 1		0	21-51-11 E004-01/ /	YC001-YC026
D00458B	1	PARTBOF0458 PLUG-AIR COND RELAY NO 1		0	21-51-11 */*/	YC028-YL430
D00458B	1	PARTBOF0458 PLUG-AIR COND RELAY MDL		0	21-25-11 */*/	YM643-YM670
D00462	1	BACC45FT18-31S7 PLUG-	81205	1	30-21-11 P005-00/ /	YC001-YC030, YK901-YM670
D00476	1	BACC63BP12C12SN PLUG-RETRACTABLE LANDING LT,R	81205	1	33-42-11 500A+10/150/R032	YC001-YC028
D00476	1	BACC63BP12C12SN PLUG-RETRACTABLE LANDING LT,R	81205	1	33-42-11 533/154/R034	YC029-YL430
D00476	1	BACC63BP12C12SN PLUG-RETRACTABLE LANDING LT,R	81205	1	33-42-11 533/154/R033	YM643-YM670
D00476 T	1	BACC10KF12 BACKSHELL-CONDUCTIVE	81205	1	33-42-11 */*/	ALL
D00482	1	BACC45FT12-12S6 PLUG-	81205	1	52-71-12 P005-20/ /	YC001-YC030, YK901-YM670
D00483	1	BACC45FT20-41S PLUG-	81205	1	21-27-21 P005-19/ /	YC001-YC030, YK901-YM670
D00486	1	BACC63BN12-3SN PLUG-	81205	1	21-51-11 582/163/L014	ALL

EQUIPMENT LIST

D280A103

Section D00400

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00486 T	1	MS27559-3 BACKSHELL-90 DEGREE	96906	1	21-51-11 */**	ALL
D00488	1	BACC63BN10-5S8 PLUG-	81205	1	21-51-11 581/159/L009	YC001-YL430
D00488	1	BACC63BN10-5S6 PLUG-	81205	1	21-51-11 581/159/L009	YM643-YM670
D00488 T	1	MS27291-1 BACKSHELL-STRAIGHT	96906	1	21-51-11 */**	ALL
D00490	1	BACC63BN12-3SN PLUG-	81205	1	21-51-21 582/163/R010	ALL
D00490 T	1	MS27559-3 BACKSHELL-90 DEGREE	96906	1	21-51-21 */**	ALL
D00492	1	BACC63BN10-5S8 PLUG-	81205	1	21-51-21 581/159/R015	YC001-YL430
D00492	1	BACC63BN10-5S6 PLUG-	81205	1	21-51-21 581/159/R015	YM643-YM670
D00492 T	1	MS27291-1 BACKSHELL-STRAIGHT	96906	1	21-51-21 */**	ALL

EQUIPMENT LIST

D280A103

Section D00400
Page 3 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00512	1	BACC45FT10-5S PLUG	81205	1	21-61-21 372/195/L055	YM643-YM670
D00512 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	1	21-61-21 */**	YM643-YM670
D00514	1	BACC45FT12-3S PLUG	81205	1	21-61-21 371/192/L058	YM643-YM670
D00514 T	1	BACC10JC12 BACKSHELL-90 DEGREE	81205	1	21-61-21 */**	YM643-YM670
D00518	1	BACC45FT10-5S PLUG-	81205	1	21-61-22 534/299/R010	YM643-YM670
D00518 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	1	21-61-22 */**	YM643-YM670
D00519	1	BACC45FT16-24S8 PLUG-ATC 2 DUAL CONTROL	81205	1	34-53-21 P008-29/ /	ALL
D00519 T	1	BACC10JS16 BACKSHELL	81205	1	34-53-21 P8-29/ /	YC001-YC050
D00519 T	1	BACC10JS16 BACKSHELL	81205	1	34-53-21 */**	YK901-YM670
D00520	1	BACC45FT12-3S PLUG-	81205	1	21-61-22 535/299/R010	YM643-YM670
D00520 T	1	BACC10JC12 BACKSHELL-90 DEGREE	81205	1	21-61-22 */**	YM643-YM670
D00522	1	BACC63CB14-7SN PLUG-	81205	1	21-61-22 653/148/R013	YM643-YM670
D00522 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-61-22 */**	YM643-YM670
D00524	1	BACC63CB14-7SN PLUG-	81205	1	21-61-21 653/148/L013	YM643-YM670
D00524 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-61-21 */**	YM643-YM670
D00526	1	BACC63BP10D20SN PLUG	81205	1	36-11-01 NSTA 231/143/R1	YC001-YC007
D00526	1	BACC63BP10D20SN PLUG	81205	1	36-11-11 NSTA 231/143/R1	YC008-YM670

EQUIPMENT LIST

D280A103

Section D00500

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00526 T	1	BACC10KA10 BACKSHELL	81205	1	36-11-01 //	YC001-YC007
D00526 T	1	440AS069ZM1003-5-16B BACKSHELL	06324	1	36-11-11 //	YC008-YM670
D00526 T	2	440AS069ZM1004-4 BACKSHELL	06324	1	36-11-11 //	YC008-YM670
D00526 U	1	202K121-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	36-11-11 //	YC008-YM670
D00526 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	1	36-11-11 //	YC008-YM670
D00526 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	36-11-11 //	YC008-YM670
D00528	1	BACC63BP10D20SN PLUG	81205	1	36-11-01 NSTA 231/143/R1	YC001-YC007
D00528	1	BACC63BP10D20SN PLUG	81205	1	36-11-11 NSTA 231/143/R1	YC008-YM670
D00528 T	1	BACC10KA10 BACKSHELL	81205	1	36-11-01 //	YC001-YC007
D00528 T	1	440AS069ZM1003-5-16B BACKSHELL	06324	1	36-11-11 //	YC008-YM670
D00528 T	2	440AS069ZM1004-4 BACKSHELL	06324	1	36-11-11 //	YC008-YM670
D00528 U	1	202K121-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	36-11-11 //	YC008-YM670
D00528 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	1	36-11-11 //	YC008-YM670
D00528 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	36-11-11 //	YC008-YM670
D00530	1	BACC63CB10-5S6 PLUG-	81205	1	21-51-15 586/161/L034	YM643-YM670
D00530 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	21-51-15 */*/*	YM643-YM670
D00532	1	BACC63CB10-5S6 PLUG-	81205	1	21-51-15 581/152/L029	YC001-YL430

EQUIPMENT LIST

D280A103

Section D00500

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00532	1	BACC63CB10-5S6 PLUG-	81205	1	21-51-15 580/152/L028	YM643-YM670
D00532 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	21-51-15 */**	ALL
D00534	1	BACC45FT10-5S8 PLUG-	81205	1	21-51-15 370/196/L056	YM643-YM670
D00534 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	1	21-51-15 */**	YM643-YM670
D00536	1	BACC63CB10-5S6 PLUG-	81205	1	21-51-25 586/161/R034	YM643-YM670
D00536 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	21-51-25 */**	YM643-YM670
D00538	1	BACC63CB10-5S6 PLUG-	81205	1	21-51-25 577/154/R034	YC001-YL430
D00538	1	BACC63CB10-5S6 PLUG-	81205	1	21-51-25 578/154/R033	YM643-YM670
D00538 T	1	BACC10KD10 BACKSHELL-STRAIGHT	81205	1	21-51-25 */**	ALL
D00539	1	BACC66F11F04AE01 PLUG PLATE ASSY	81205	1	23-12-31 E003-03/ /	YC001-YC030, YK901-YM670
D00539 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-12-31 E003-03/ /	YC001-YC030
D00539 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-12-31 */**	YK901-YM670
D00539A	1	PARTAOFD00539 PLUG - VHF 3		0	23-12-31 E003-03/ /	YC001-YC030
D00539A	1	PARTAOFD00539 PLUG - VHF 3		0	23-12-31 */**	YK901-YM670
D00539B	1	PARTBOFD00539 PLUG - VHF 3		0	23-12-31 E003-03/ /	YC001-YC030
D00539B	1	PARTBOFD00539 PLUG - VHF 3		0	23-12-31 */**	YK901-YM670
D00539C	1	PARTCOFD00539 PLUG - VHF 3		0	23-12-31 E003-03/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D00500

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00539C	1	PARTCOFD00539 PLUG - VHF 3		0	23-12-31 */**	YK901-YM670
D00540	1	BACC63CB10-5S8 PLUG-	81205	1	21-51-25 531/299/R012	YM643-YM670
D00540 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	21-51-25 */**	YM643-YM670
D00545	1	BACC63BP18C31SN PLUG	81205	1	22-18-11 1164/277/R002	YC001-YC007
D00545	1	BACC63BP18C31SN PLUG	81205	1	22-18-11 1156/277/R002	YC008-YC022
D00545	1	BACC63BP18C31SN PLUG	81205	1	22-18-11 1165/277/R002	YC023-YM670
D00545 T	1	BACC10KD18 BACKSHELL	81205	1	22-18-11 / /	YC001-YC007
D00545 T	1	BACC10KD18 BACKSHELL	81205	1	22-18-11 */**	YC008-YM670
D00549	1	BACC63CB20-41SN PLUG-	81205	1	23-12-31 P008-73/ /	YK901-YM670
D00549 T	1	BACC10KD20 BACKSHELL- CONDUCTIVE	81205	1	23-12-31 */**	YK901-YM670
D00551	1	MS3475W14-19S PLUG-SELCAL CONTROL PANEL	96906	1	23-22-11 P008-66/ /	YC001-YK906
D00551 T	1	BACC10KD14 BACKSHELL	81205	1	23-22-11 P008-66/ /	YC001-YK906
D00553	1	BACC45FT22-55S6 PLUG - INSTRUMENT SWITCHING MODULE	81205	1	34-51-41 P005-28/ /	ALL
D00553 T	1	BACC10JS22 BACKSHELL	81205	1	34-51-41 */**	ALL
D00570	1	BACC63CD24-22S RCPT-	81205	1	25-31-11 AB0288/ /	ALL
D00576	1	BACC45FT18-31S8 PLUG	81205	1	26-21-11 P008-01/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D00500

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00576 T	1	BACC10JS18 BACKSHELL	81205	1	26-21-11 */**	YC001-YC007, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00576 T	1	BACC10JS18 BACKSHELL	81205	1	26-21-11 TBD/ /	YC008-YC030
D00578	1	BACC45FT18-31S9 PLUG	81205	1	26-21-11 P008-01/ /	YC001-YC003, YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00578	1	BACC45FT18-31S9 PLUG	81205	1	26-21-11 P008-01/**	YC004-YC007
D00578 T	1	BACC10JS18 BACKSHELL	81205	1	26-21-11 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00580	1	BACC45FT18-31S7 PLUG	81205	1	26-21-11 P008-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00580 T	1	BACC10JS18 BACKSHELL	81205	1	26-21-11 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00582	1	BACC63BP14D7SN CONNECTOR-L.BOTTLE M00194	81205	1	26-21-11 708/192/L057	ALL
D00582 T	1	BACC10KB14 BACKSHELL	81205	1	26-21-11 710/189/L56	YC001-YC028
D00582 T	1	BACC10KB14 BACKSHELL	81205	1	26-21-11 */**	YC029-YM670
D00584	1	BACC63BP14D7SN CONNECTOR-R.BOTTLE M00195	81205	1	26-21-11 718/191/L55	ALL
D00584 T	1	BACC10KB14 BACKSHELL	81205	1	21-62-11 713/189/L58	ALL

EQUIPMENT LIST

D280A103

Section D00500

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00586	1	BACC63BP12D3S6 CONNECTOR-L.BOTTLE M00194	81205	1	26-21-11 709/194/L054	ALL
D00586 T	1	BACC10KB12 BACKSHELL	81205	1	26-21-11 711/188/L55	YC001-YC028
D00586 T	1	BACC10KB12 BACKSHELL	81205	1	26-21-11 */**	YC029-YM670
D00588	1	BACC63BP12D3S6 CONNECTOR-R.BOTTLE M00195	81205	1	26-21-11 718/194/L54	ALL
D00588 T	1	BACC10KB12 BACKSHELL	81205	1	26-21-11 713/190/L58	ALL
D00594	1	BACC63BP14D7S7 PLUG-SQUIB APU BTL	81205	1	26-21-11 1081/227/L024	YC001-YC030, YK901-YM670
D00594 T	1	BACC10KA14 BACKSHELL	81205	1	26-21-11 / /	YC001-YC007
D00594 T	1	BACC10KA14 BACKSHELL	81205	1	26-21-11 1081/227/L024	YC008-YC030, YK901-YK910, YL421-YL423, YM643
D00594 T	1	BACC10KA14 BACKSHELL	81205	1	26-21-11 */**	YK911-YL401, YL424-YL430, YM645-YM670

EQUIPMENT LIST

D280A103

Section D00500
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00616	1	BACC45FT14-7S PLUG-	81205	1	28-42-11 P005-02/ /	YC001-YC030, YK901-YM670
D00618	1	BACC45FT12-12S6 PLUG-	81205	1	21-61-11 P005-17/ /	YM643-YM670
D00620	1	BACC45FT12-12S6 PLUG-	81205	1	21-51-11 P005-17/ /	YM643-YM670
D00623	1	BACC66H125C1001 PLUG- HF-2 TRANSCEIVER	81205	1	23-11-21 E008-01/ /	YK907-YL401
D00623	1	BACC66H125C1001 PLUG - HF 2 TRANSCEIVER	81205	1	23-11-21 E008-01/ /	YL421-YL430
D00623	1	BACC66H125C1001 PLUG	81205	1	23-11-21 E006-02/ /	YM643-YM670
D00623 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-11-21 E008-01/ /	YK907-YL430
D00623 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-11-21 */*/*	YM643-YM670
D00623A	1	PARTAOFD00623 PLUG- HF-2 TRANSCEIVER		1	23-11-21 */*/*	YK907-YL401
D00623A	1	PARTAOFD00623 PLUG - HF 2 TRANSCEIVER		1	23-11-21 / /	YL421-YL430
D00623A	1	PARTAOFD00623 PLUG		1	23-11-21 */*/*	YM643-YM670
D00623B	1	PARTBOFD00623 PLUG- HF-2 TRANSCEIVER		1	23-11-21 */*/*	YK907-YL401
D00623B	1	PARTBOFD00623 PLUG - HF 2 TRANSCEIVER		1	23-11-21 / /	YL421-YL430
D00623B	1	PARTBOFD00623 PLUG		1	23-11-21 */*/*	YM643-YM670
D00623BT	1	BACC47EN4A CONTACT-(COAX) SIZE 1-PLUG-XCVR-1	81205	1	23-11-21 E008-01/ /	YK907-YL430
D00623BT	1	BACC47EN4A CONTACT - (COAX)	81205	1	23-11-21 */*/*	YM643-YM670
D00623BU	1	125-95-9 PLUG HF-2 TRANSCEIVER	91836	1	23-11-21 E008-01/ /	YK907-YL401

EQUIPMENT LIST

D280A103

Section D00600

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00623BU	1	125-95-9 PLUG - HF 2 TRANSCEIVER	91836	1	23-11-21 E-008-01/ /	YL421-YL430
D00623BU	1	125-95-9 PLUG	91836	1	23-11-21 */**	YM643-YM670
D00623C	1	PARTCOFD00623 PLUG- HF-2 TRANSCEIVER		1	23-11-21 */**	YK907-YL401
D00623C	1	PARTCOFD00623 PLUG - HF 2 TRANSCEIVER		1	23-11-21 / /	YL421-YL430
D00623C	1	PARTCOFD00623 PLUG		1	23-11-21 */**	YM643-YM670
D00624	1	BACC45FT22-55S6 PLUG-	81205	1	27-23-14 P005-00/ /	ALL
D00625	1	1205-62-9 PLUG-HF-2 COUPLER INPUT (RF-COAX)	91836	1	23-11-21 F057/330/L04	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00626	1	BACC45FT20-41S PLUG-	81205	1	28-43-11 P005-02/ /	YC001-YC030, YK901-YM670
D00628	1	BACC45FT20-41S6 PLUG-	81205	1	28-21-11 P005-02/ /	ALL
D00629	1	MS3126E16-26S PLUG	09922	1	23-11-21 F057/350/R002	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00630	1	BACC45FT22-55S PLUG-	81205	1	27-23-14 P005-00/ /	ALL
D00634	1	BACC45FT18-31S8 PLUG-	81205	1	24-22-21 P005-04/ /	YC001-YC030, YK901-YM670
D00636	1	BACC45FT18-31S9 PLUG-	81205	1	24-11-21 P005-05/ /	YC001-YC030, YK901-YM670
D00638	1	BACC45FT24-61S PLUG-	81205	1	30-31-12 P005-09/ /	YC001-YC030, YK901-YM670
D00642	1	BACC45FT16-24S PLUG-	81205	1	29-11-11 P005-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D00600

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00644	1	BACC45FT24-61S6 PLUG-	81205	1	30-41-12 P005-09/ /	YC001-YC030, YK901-YM670
D00646	1	BACC45FT22-55S7 PLUG-	81205	1	21-31-11 P005-10/ /	ALL
D00648	1	BACC45FT18-31S8 PLUG-	81205	1	30-21-11 P005-11/ /	YC001-YC030, YK901-YM670
D00650	1	BACC45FT22-55S9 PLUG-	81205	1	27-81-11 P005-12/ /	YC001-YC030, YK901-YM670
D00652	1	BACC45FT22-55S8 PLUG-	81205	1	24-28-11 P005-13/ /	YC001-YC030, YK901-YM670
D00654	1	BACC45FT12-12S PLUG-	81205	1	21-33-11 P005-16/ /	YC001-YC030, YK901-YM670
D00656	1	BACC45FT16-24S6 PLUG-	81205	1	21-51-21 P005-17/ /	YM643-YM670
D00660	1	BACC63BP12D3S8L PLUG-CONDUCTIVE	81205	1	29-32-11 669/181/R021	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00660 T	1	BACC10KA12 BACKSHELL-CONDUCTIVE	81205	1	29-32-11 */*/	YC001-YC028
D00660 T	1	BACC10KB12 BACKSHELL-CONDUCTIVE	81205	1	29-32-11 */*/	YC029-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00662	1	BACC63BP12D3S8L PLUG-CONDUCTIVE	81205	1	29-32-11 668/171/L048	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00662 T	1	BACC10KB12 BACKSHELL-90 DEGREE	81205	1	29-32-11 / /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D00600

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00674	1	BACC63BN10-5S6 PLUG- CONDUCTIVE	81205	1	29-31-11 678/195/R008	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00674 T	1	MS27291-1 BACKSHELL-	96906	1	29-31-11 TBD/ /	YC001-YC028
D00674 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	29-31-11 */**	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00678	1	BACC63CB10-20SN PLUG-CONDUCTIVE	81205	1	29-31-11 718/171/L000	YC001-YC030
D00678	1	BACC63CB10A20SN PLUG-CONDUCTIVE	81205	1	29-31-11 718/171/L000	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00678 T	1	BACC10KE10 BACKSHELL-CONDUCTIVE	81205	1	29-31-11 */**	YC001-YC026, YC029-YC030
D00678 T	1	BACC10KE10 BACKSHELL-CONDUCTIVE	81205	1	29-31-11 TBD/ /	YC028
D00678 T	1	M85049-51S10A BACKSHELL-CONDUCTIVE	81205	1	29-31-11 */**	YC031-YK907, YK910-YK912, YK918-YK919, YL401-YL421, YL423-YL429, YM645-YM670
D00678 T	1	M85049-51S10A BACKSHELL-CONDUCTIVE	81205	1	29-31-11 / /	YK908-YK909, YL422, YM643
D00680	1	BACC45FT22-55S6 PLUG-	81205	1	21-31-11 P005-10/ /	YC001-YC030, YK901-YM670
D00686	1	BACC45FT18-14S7 PLUG	81205	1	27-52-11 P002-02/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D00600

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00686 T	1	BACC10JS18 BACKSHELL	81205	1	27-52-11 */*/	YC001-YC007
D00686 T	1	BACC10JS18 BACKSHELL	81205	1	27-52-11 P002-02/ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00698	1	BACC45FT12-12S PLUG-STAB TRIM C/OSW	81205	1	27-41-11 AF0222A/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00698 T	1	BACC10JC12 BACKSHELL-	81205	1	27-41-11 */*/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D00600

Page 5 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00700	1	BACC63BP16C10SN PLUG-STAB TRIM ACT	81205	1	27-41-12 J011-00/ /	YC001-YC007
D00700	1	BACC63BP16C10SN PLUG-STAB TRIM ACT	81205	1	27-41-12 1072/235/R003	YC008-YM670
D00700 T	1	BACC10KD16 BACKSHELL	81205	1	27-41-11 / /	ALL
D00702	1	BACC63CB14-7SN PLUG-	81205	1	21-51-16 571/163/L024	YM643-YM670
D00702 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-16 */**	YM643-YM670
D00704	1	BACC63CB14-7SN PLUG-	81205	1	21-51-26 570/163/R024	YM643-YM670
D00704 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-26 */**	YM643-YM670
D00706	1	BACC63CB14-7SN PLUG-	81205	1	21-51-16 562/154/L039	YM643-YM670
D00706 T	1	BACC10KD14 BACKSHELL-STRAIGHT	81205	1	21-51-16 */**	YM643-YM670
D00708	1	BACC63CB14-7SN PLUG-	81205	1	21-51-26 562/154/R039	YM643-YM670
D00708 T	1	BACC10KD14 BACKSHELL-STRAIGHT	81205	1	21-51-26 */**	YM643-YM670
D00710	1	BACC63CB10-20SN PLUG-	81205	1	21-51-16 553/152/L016	YM643-YM670
D00710 T	1	BACC10KD10 BACKSHELL-STRAIGHT	81205	1	21-51-16 */**	YM643-YM670
D00712	1	BACC63CB10-20SN PLUG-	81205	1	21-51-26 553/151/R025	YM643-YM670
D00712 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	21-51-26 */**	YM643-YM670
D00714	1	BACC45FT16-24S PLUG	81205	1	31-22-11 P001-01/ /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D00700

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00714	1	BACC63CB16-24SN PLUG - CONDUCTIVE	81205	1	31-22-11 P001-01/ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00714 T	1	BACC10JC16 BACKSHELL - 90	81205	1	31-22-11 */**	YC001-YC007
D00714 T	1	BACC10KE16 BACKSHELL - CONDUCTIVE - 90	81205	1	31-22-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00716	1	BACC45FT16-24S PLUG	81205	1	31-22-11 P003-03/ /	YC001-YC007
D00716	1	BACC63CB16-24SN PLUG - CONDUCTIVE	81205	1	31-22-11 P003-03/ /	YC008-YC030, YK901-YL429, YM643-YM652
D00716 T	1	BACC10JC16 BACKSHELL - 90	81205	1	31-22-11 */ /	YC001-YC007
D00716 T	1	BACC10KE16 BACKSHELL - CONDUCTIVE - 90	81205	1	31-22-11 */ /	YC008-YC030
D00716 T	1	BACC10KE16 BACKSHELL - CONDUCTIVE - 90	81205	1	31-22-11 */**	YK901-YL429, YM643-YM652
D00722	1	BACC45FT16-24S9 PLUG-	81205	1	24-11-11 P005-04/ /	YC001-YC030, YK901-YM670
D00728	1	BACC66H21C94AA01 PLUG PLATE ASSEMBLY	81205	1	27-81-41 E001-01/ /	ALL
D00728 T	1	S280W601-116 GND - BLOCK 48	81205	1	22-11-11 E001-01/ /	YC001-YC050
D00728 T	1	S280W601-116 GND - BLOCK 48	81205	1	22-11-11 */**	YK901-YM670
D00728A	1	PARTAOFD00728 PLUG		0	27-81-11 E001-01/ /	YC001-YC050
D00728A	1	PARTAOFD00728 PLUG		0	27-81-11 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D00700

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00728B	1	PARTBOFD00728 PLUG		0	27-81-11 E001-01/ /	YC001-YC050
D00728B	1	PARTBOFD00728 PLUG		0	27-81-11 */**	YK901-YM670
D00728C	1	PARTCOFD00728 PLUG		0	27-81-41 E001-01/ /	YC001-YC050
D00728C	1	PARTCOFD00728 PLUG		0	27-81-41 */**	YK901-YM670
D00730	1	BACC45FT16-24S7 PLUG-	81205	1	24-11-11 P005-04/ /	YC001-YC030, YK901-YM670
D00732	1	BACC63CB14-7SN PLUG	81205	1	30-11-11 OFSS-258/ /	ALL
D00732 T	1	BACC10KE14 BACKSHELL	81205	1	30-11-11 OFSS-259/ /	ALL
D00734	1	BACC63CB14-7SN PLUG	81205	1	30-11-11 OFSS 258/ /	ALL
D00734 T	1	BACC10KE14 BACKSHELL	81205	1	30-11-11 */**	ALL
D00736	1	BACC63CB10-20S6 PLUG-CONDUCTIVE CONNECTOR	81205	1	30-11-11 OFSS 266/ /	ALL
D00736 T	1	BACC10KE10 BACKSHELL	81205	1	30-11-11 OFSS 266/ /	YC001-YC030
D00736 T	1	BACC10KD10 BACKSHELL	81205	1	30-11-11 OFSS 266/ /	YC031-YM670
D00738	1	BACC63CB10-20S6 PLUG-CONDUCTIVE CONNECTOR	81205	1	30-11-11 OFSS-266/ /	ALL
D00738 T	1	BACC10KE10 BACKSHELL	81205	1	30-11-11 */**	YC001-YC030
D00738 T	1	BACC10KD10 BACKSHELL	81205	1	30-11-11 */**	YC031-YM670
D00742	1	DPXBMB-57-33S-0031 PLUG	71468	1	26-12-11 E001-04/ /	ALL
D00756	1	BACC63BP10C5SN PLUG-DP SENSE SW	81205	1	27-31-37 1083/268/R13	YC001-YC007

EQUIPMENT LIST

D280A103

Section D00700

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00756	1	BACC63BP10C5SN PLUG-DP SENSE SW	81205	1	27-31-37 1083/268/R013	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00756 T	1	BACC10KD10 BACKSHELL- STRAIGHT	81205	1	27-31-37 / /	YC001-YC007
D00756 T	1	BACC10KD10 BACKSHELL- STRAIGHT	81205	1	27-31-37 */*/	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00758	1	BACC63CB14-7SN PLUG-CONDUCTIVE	81205	1	27-61-11 666/179/R051	YC001-YC030
D00758	1	BACC63CB14A7SN PLUG-CONDUCTIVE	81205	1	27-61-11 666/179/R051	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00758 T	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	27-61-11 TBD/ /	YC001-YC028
D00758 T	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	27-61-11 */*/	YC029-YC030
D00758 T	1	M85049-51S14A BACKSHELL-CONDUCTIVE	81205	1	27-61-11 */*/	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00760	1	BACC63CB14-7SN PLUG-CONDUCTIVE	81205	1	27-61-11 666/178/L056	YC001-YC030
D00760	1	BACC63CB14A7SN PLUG-CONDUCTIVE	81205	1	27-61-11 666/178/L056	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00760 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-61-11 TBD/ /	YC001-YC007
D00760 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-61-11 666/ /	YC008-YC028
D00760 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-61-11 */*/	YC029-YC030

EQUIPMENT LIST

D280A103

Section D00700

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00760 T	1	M85049-51S14A BACKSHELL- CONDUCTIVE	81205	1	27-61-11 */*/	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00762	1	MS3459LS14S-5S PLUG-CONDUCTIVE	96906	1	29-11-11 673/190/L065	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00762 T	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	29-11-11 */*/	YC001-YC028
D00762 T	1	BACC10KF14 BACKSHELL-CONDUCTIVE	81205	1	29-11-11 */*/	YC029
D00762 T	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	29-11-11 */*/	YC030, YK901- YK912, YK918- YK919, YL401- YL429, YM643- YM652
D00764	1	MS3459LS14S-5S PLUG	96906	1	29-11-11 682/189/R073	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00764 T	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	29-11-11 */*/	YC001-YC029
D00764 T	1	BACC10KB14 BACKSHELL-CONDUCTIVE	81205	1	29-11-11 */*/	YC030, YK901- YK912, YK918- YK919, YL401- YL429, YM643- YM652
D00776	1	BACC63CE14S-7S PLUG-CAB PRESS SW	81205	1	21-33-11 196/206/R001	YC001-YC030, YK901-YM670
D00786	1	BACC45FT10-5S PLUG-	81205	1	33-12-11 P005-16/ /	ALL
D00788	1	BACC63BP14C7SN PLUG-CONDUCTIVE	81205	1	28-21-11 OFSS-271/ /	ALL

EQUIPMENT LIST

D280A103

Section D00700

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00788 T	1	BACC10KE14 BACKSHELL	81205	1	28-21-11 OFSS-271/ /	ALL
D00790	1	BACC63BP14C7SN PLUG-CONDUCTIVE CONNECTOR	81205	1	28-21-11 OFSS 271/ /	ALL
D00790 T	1	BACC10KE14 BACKSHELL	81205	1	28-21-11 OFSS 271/ /	ALL
D00792	1	BACC63BP14D7SN PLUG	81205	1	28-22-11 666/183/R043	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00792 T	1	BACC10KA14 BACKSHELL	81205	1	28-22-11 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00794	1	BACC45FT8-2S PLUG-	81205	1	33-12-11 P005-16/ /	ALL
D00796	1	BACC45FT12-12S PLUG-MODULE P021-01	81205	1	33-17-11 210/217/L31	YC001-YC026
D00796	1	BACC45FT12-12S PLUG-MODULE P021-01	81205	1	33-17-11 210/217/L031	YC028-YM670
D00796 T	1	BACC10JS12 BACKSHELL-	81205	1	33-17-11 */**	ALL
D00798	1	BACC45FT12-12S PLUG-MODULE P023-01	81205	1	33-17-11 210/217/R031	ALL
D00798 T	1	BACC10JS12 BACKSHELL-	81205	1	33-17-11 */**	ALL

EQUIPMENT LIST

D280A103

Section D00700

Page 6 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00802	1	BACC63BP14D4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	28-23-11 664/182/L020	ALL
D00802 T	1	BACC10KB14 BACKSHELL	81205	1	28-23-11 */*/*	ALL
D00804	1	BACC63BP14D4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	28-23-12 663/183/R011	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00804 T	1	BACC10KA14 BACKSHELL	81205	1	28-23-12 */*/*	YC001-YC026
D00804 T	1	BACC10KA14 BACCKSHELL	81205	1	28-23-12 */*/*	YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00812	1	BACC63CE20-4S PLUG-	81205	1	29-22-11 727+18/150/R027	ALL
D00812 T	1	BACC10HW20 PLUG-	81205	1	29-22-11 */*/*	ALL
D00814	1	BACC63CB10-5SN PLUG-FLT CNTRL SYS A PRESSURE SW	81205	1	27-23-14 666/178/L053	YC001-YC030
D00814	1	BACC63CB10A5SN PLUG-FLT CNTRL SYS A PRESSURE SW	81205	1	27-23-14 666/178/L053	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00814 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	27-23-14 TBD/ /	YC001-YC007
D00814 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	27-23-14 666/ /	YC008-YC028
D00814 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	27-23-14 */*/*	YC029-YC030
D00814 T	1	M85049-51S10A BACKSHELL- CONDUCTIVE	81205	1	27-23-14 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D00800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00815	1	BACC45FN10-5S RCPT-CONT WHEEL POS SENSOR	81205	1	31-31-14 215/180/L020	YC001-YC007
D00815	1	BACC45FN10-5S RCPT-CONT WHEEL POS SENSOR	81205	1	31-31-14 222/194/L020	YC008-YM670
D00816	1	BACC63CB10-5SN PLUG-CONDUCTIVE	81205	1	27-23-14 666/179/R054	YC001-YC030
D00816	1	BACC63CB10A5SN PLUG-CONDUCTIVE	81205	1	27-23-14 666/179/R054	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00816 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	27-23-14 TBD/ /	YC001-YC028
D00816 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	27-23-14 */*/*	YC029-YC030
D00816 T	1	M85049-52S10A BACKSHELL-CONDUCTIVE	81205	1	27-23-14 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00817	1	BACC45FN10-5S RCPT-CONT COLUMN POS SENSOR	81205	1	31-31-14 230/203/L012	ALL
D00818	1	BACC63CB14-7SN PLUG-FLT CONT SYS A SHUTOFF VALVE	81205	1	27-23-11 666/178/L050	YC001-YC030
D00818	1	BACC63CB14A7SN PLUG-FLT CONT SYS A SHUTOFF VALVE	81205	1	27-23-11 666/178/L050	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00818 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-23-11 TBD/ /	YC001-YC007
D00818 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-23-11 666/ /	YC008-YC028
D00818 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-23-11 */*/*	YC029-YC030

EQUIPMENT LIST

D280A103

Section D00800

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00818 T	1	M85049-51S14A BACKSHELL- CONDUCTIVE	81205	1	27-23-11 */*/	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00819	1	BACC45FT10-5S PLUG-RUDDER PEDAL POS SENSOR	81205	1	31-31-14 234/202/R27	ALL
D00820	1	BACC63CB14-7SN PLUG	81205	1	27-23-11 666/179/R056	YC001-YC030
D00820	1	BACC63CB14A7SN PLUG	81205	1	27-23-11 666/179/R056	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00820 T	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	27-23-11 TBD/ /	YC001-YC028
D00820 T	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	27-23-11 */*/	YC029-YC030
D00820 T	1	M85049-51S14A BACKSHELL-CONDUCTIVE	81205	1	27-23-11 */*/	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00821	1	PT08SE-12-10S-SR- PLUG-ACCELEROMETER	77820	1	31-31-14 0667/193/R048	YC001-YC030
D00821	1	SP08SE-12-10S-SR- PLUG-ACCELEROMETER	77820	1	31-31-14 0667/193/R048	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00822	1	BACC63CB14-7SN PLUG-CONDUCTIVE	81205	1	27-23-11 724/168/L012	YC001-YC030
D00822	1	BACC63CB14A7SN PLUG-CONDUCTIVE	81205	1	27-23-11 724/168/L012	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00822 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-23-11 / /	YC001-YC028
D00822 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-23-11 */*/	YC029-YC030

EQUIPMENT LIST

D280A103

Section D00800

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00822 T	1	M85049-51S14A BACKSHELL- CONDUCTIVE	81205	1	27-23-11 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00824	1	BACC63CB10-5SN PLUG-CONDUCTIVE	81205	1	29-35-11 723/163/L001	YC001-YC030
D00824	1	BACC63CB10A5SN PLUG-CONDUCTIVE	81205	1	29-35-11 723/163/L001	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00824 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	29-35-11 TBD/ /	YC001-YC028
D00824 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	29-35-11 */*/*	YC029-YC030
D00824 T	1	M85049-51S10A BACKSHELL- CONDUCTIVE	81205	1	29-35-11 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00832	1	35303-75 PLUG-	73168	1	26-12-11 544/166/L039	ALL
D00834	1	35303-75 PLUG	73168	1	26-12-12 IFSS-220/ /	YC001-YC030, YK901-YM670
D00836	1	35303-75 PLUG-	73168	1	26-12-11 544/166/R039	YC001-YL430
D00836	1	35303-75 PLUG-	73168	1	26-12-11 544/167/R039	YM643-YM670
D00838	1	35303-75 PLUG	73168	1	26-12-12 IFSS 221/ /	ALL
D00840	1	35303-75 DETECTOR	73168	1	26-12-11 685/199/L036	YC001-YC030
D00842	1	35303-75 PLUG	81205	1	26-12-11 685/199/R036	YC001-YC030
D00844	1	35303-75 PLUG-	73168	1	26-12-12 563/159/R039	ALL

EQUIPMENT LIST

D280A103

Section D00800

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00846	1	35303-75 PLUG-	73168	1	26-12-11 570/164/R008	ALL
D00848	1	35303-75 PLUG-	73168	1	26-12-11 540/155/R005	ALL
D00849	1	BACC45FT12-12S PLUG	81205	1	34-21-11 193/235/L006	YC001-YC030
D00849 T	1	BACC10JS12 CLAMP	81205	1	34-21-11 / /	YC001-YC030
D00850	1	35303-75 PLUG	73168	1	26-12-11 656/147/R005	ALL
D00852	1	35303-75 PLUG-	73168	1	26-12-11 667/151/R004	ALL
D00854	1	35303-75 PLUG	81205	1	26-12-11 722/150/R004	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00856	1	35303-75 PLUG-	73168	1	26-12-11 570/164/L008	ALL
D00858	1	35303-75 PLUG-	73168	1	26-12-11 563/159/L039	ALL
D00862	1	35303-75 PLUG	73168	1	26-12-11 1016/202/L011	ALL
D00864	1	35303-75 PLUG	73168	1	26-12-11 1047/203/L011	ALL
D00866	1	35303-75 PLUG-	73168	1	26-12-11 1084/222/R012	ALL
D00868	1	BACC63BN10-5SN PLUG	81205	1	28-43-11 ORSS160/189/L085	ALL
D00868 T	1	MS27559-2 BACKSHELL	96906	1	28-43-11 */*/*	ALL
D00870	1	BACC63BN10-5SN PLUG	81205	1	28-43-11 OFSS-118/ /	ALL
D00870 T	1	MS27559-2 BACKSHELL	96906	1	28-43-11 OFSS-118/ /	ALL

EQUIPMENT LIST

D280A103

Section D00800

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00872	1	BACC63BN10-5SN PLUG	81205	1	28-43-11 IRSS148/ /	ALL
D00872 T	1	MS27559-2 BACKSHELL	96906	1	28-43-11 TBD/ /	YC001-YC028
D00872 T	1	MS27559-2 BACKSHELL	96906	1	28-43-11 */*/*	YC029-YM670
D00874	1	BACC63BN10-5SN PLUG	81205	1	28-43-11 OFSS 117/ /	ALL
D00874 T	1	MS27559-2 BACKSHELL	96906	1	28-43-11 */*/*	ALL
D00876	1	BACC63BN10-5S7 PLUG	81205	1	28-43-11 667/188/L029	ALL
D00876 T	1	MS27291-1 BACKSHELL	96906	1	28-43-11 TBD/ /	YC001-YC028
D00876 T	1	MS27291-1 BACKSHELL	96906	1	28-43-11 */*/*	YC029-YM670
D00878	1	BACC63BN10-5S7 PLUG	81205	1	28-43-11 666/186/R029	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00878 T	1	MS27291-1 BACKSHELL	96906	1	28-43-11 */*/*	YC001-YC028
D00878 T	1	MS27559-2 BACKSHELL	96906	1	28-43-11 */*/*	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00890	1	BACC63CB12-3SN PLUG	81205	1	28-44-11 OFSS 373/ /	ALL
D00890 T	1	BACC10KF12 BACKSHELL	81205	1	28-44-11 */*/*	YC001-YK910, YK918, YL421- YL426, YM643- YM646

EQUIPMENT LIST

D280A103

Section D00800

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00890 T	1	BACC10KE12 BACKSHELL	81205	1	28-44-11 */**	YK911-YK917, YK919-YL401, YL427-YL430, YM647-YM670
D00892	1	BACC63CB12-3SN PLUG	81205	1	28-44-11 OFSS 377/ /	ALL
D00892 T	1	BACC10KF12 BACKSHELL	81205	1	28-44-11 **/**	ALL
D00894	1	BACC63CB12-3SN PLUG	81205	1	28-44-11 OFSS 382/ /	ALL
D00894 T	1	BACC10KF12 BACKSHELL	81205	1	28-44-11 **/**	ALL
D00895	1	BACC63CB16-24S6 PLUG - CONDUCTIVE	81205	1	31-62-23 P001-03/ /	YC001-YC030, YK901-YL429, YM643-YM652
D00895 T	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	31-62-23 */ /	YC001-YC030
D00895 T	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	31-62-23 **/**	YK901-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D00800
Page 7 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00903	1	BACC45FT12-12S PLUG	81205	1	29-23-11 P001-01/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00903 T	1	BACC10JS12 BACKSHELL	81205	1	29-23-11 */**	YC001-YC007
D00903 T	1	BACC10JS12 BACKSHELL	81205	1	29-23-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00918	1	K-4932 PLUG-COMPASS STANDBY INDICATOR	96906	1	33-14-12 209/256/000	YC001-YC030
D00918	1	K-4942 PLUG-COMPASS STANDBY INDICATOR	96906	1	33-14-12 209/256/000	YK901-YM670
D00920	1	BACC63CB14-7SN PLUG-CONDUCTIVE	81205	1	49-62-11 666/182/L041	YC001-YC030
D00920	1	BACC63CB14A7SN PLUG-CONDUCTIVE	81205	1	49-62-11 666/182/L041	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00920 T	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	49-62-11 */ /	YC001-YC030
D00920 T	1	M85049-51S14A BACKSHELL-CONDUCTIVE	81205	1	49-62-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00922	1	BACC63CB10-5S6 PLUG-APU INLET ACT	81205	1	49-62-11 1056/241/R035	YC001-YC030, YK901-YM670
D00922 T	1	BACC10KD10 BACKSHELL	81205	1	49-62-11 / /	YC001-YC007
D00922 T	1	BACC10KD10 BACKSHELL	81205	1	49-62-11 1056/241/L035	YC008-YC030, YK901-YK910, YL421-YL423, YM643

EQUIPMENT LIST

D280A103

Section D00900

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00922 T	1	BACC10KD10 BACKSHELL	81205	1	49-62-11 */**	YK911-YL401, YL424-YL430, YM645-YM670
D00924	1	BACC63CB10-20SN PLUG-CONDUCTIVE	81205	1	32-41-11 723/197/L040	YC001-YC030
D00924	1	BACC63CB10B20SN PLUG-CONDUCTIVE	81205	1	32-41-11 723/197/L040	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D00924 T	1	BACC10KD10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC001-YC028
■ D00924 T	1	BACC10KF10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC029-YC030
■ D00924 T	1	BACC10KC10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D00926	1	BACC63CB10-20SN PLUG- CONDUCTIVE	81205	1	32-41-11 723/192/L040	YC001-YC030
D00926	1	BACC63CB10B20SN PLUG- CONDUCTIVE	81205	1	32-41-11 723/192/L040	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00926 T	1	BACC10KD10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC001-YC028
D00926 T	1	BACC10KF10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC029-YC030
D00926 T	1	BACC10KC10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00928	1	BACC63BP16C10SN PLUG- CONDUCTIVE	81205	1	32-44-11 725/191/R003	YC001-YC030

EQUIPMENT LIST

D280A103

Section D00900

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00928	1	BACC63BP16H10SN PLUG- CONDUCTIVE	81205	1	32-44-11 725/191/R003	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00928 T	1	BACC10KD16 BACKSHELL- CONDUCTIVE	81205	1	32-44-11 TBD/ /	YC001-YC028
D00928 T	1	BACC10KF16 BACKSHELL- CONDUCTIVE	81205	1	32-44-11 */**	YC029-YC030
D00928 T	1	BACC10KF16 BACKSHELL- CONDUCTIVE 45 DEG	81205	1	32-44-11 */**	YC031-YK906
D00928 T	1	620AB049C16 BACKSHELL- CONDUCTIVE 45 DEG	81205	1	32-44-11 */**	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D00930	1	BACC63CB10-20SN PLUG- CONDUCTIVE	81205	1	32-41-11 723/182/R040	YC001-YC030
D00930	1	BACC63CB10B20SN PLUG- CONDUCTIVE	81205	1	32-41-11 723/182/R040	YC031-YM670
■ D00930 T	1	BACC10KD10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 723/182/R040	YC001-YC028
■ D00930 T	1	BACC10KF10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC029-YC030
■ D00930 T	1	BACC10KC10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC031-YM670
D00932	1	BACC63CB10-20SN PLUG- CONDUCTIVE	81205	1	32-41-11 723/169/R040	YC001-YC028
D00932	1	BACC63CB10-20SN PLUG- CONDUCTIVE	81205	1	32-41-11 724/170/R040	YC029-YC030
D00932	1	BACC63CB10B20SN PLUG- CONDUCTIVE	81205	1	32-41-11 724/170/R040	YC031-YM670
■ D00932 T	1	BACC10KD10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YC028
■ D00932 T	1	BACC10KF10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC029-YC030

EQUIPMENT LIST

D280A103

Section D00900

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
I D00932 T	1	BACC10KC10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 */**	YC031-YM670
D00940	1	BACC45FT14-15S PLUG-AURAL WARNING BOX	81205	1	31-51-11 202/210/R006	YC001-YC030, YK901-YM670
D00940 T	1	BACC10JS14 BACKSHELL-	81205	1	31-51-11 202/210/R006	YC001-YC030
D00940 T	1	BACC10JS14 BACKSHELL-	81205	1	31-51-11 */**	YK901-YM670
D00944	1	BACS16W1A PLUG	81205	1	28-44-11 P006-00/ /	ALL
D00962	1	BACC63BN10-20S7 PLUG-L PACK VALVE	81205	1	21-51-11 581/157/L012	ALL
D00962 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	21-51-11 */**	ALL
D00964	1	BACC63BN10-20S7 PLUG-	81205	1	21-51-21 581/157/R012	ALL
D00964 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	21-51-21 */**	ALL
D00966	1	BACC63CB12-12SN PLUG-	81205	1	21-51-14 520/169/L056	ALL
D00966 T	1	BACC10KE12 BACKSHELL-90 DEGREE	81205	1	21-51-14 */**	ALL
D00968	1	BACC63CB12-12SN PLUG-	81205	1	21-51-24 519/166/R058	ALL
D00968 T	1	BACC10KE12 BACKSHELL-90 DEGREE	81205	1	21-51-24 */**	ALL
D00970	1	BACC63CB14-7SN PLUG-	81205	1	21-51-14 567/165/L032	YM643-YM670
D00970 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-14 */**	YM643-YM670
D00972	1	BACC63CB14-7SN PLUG-	81205	1	21-51-24 567/165/R032	YM643-YM670
D00972 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-24 */**	YM643-YM670

EQUIPMENT LIST

D280A103

Section D00900

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00998	1	DPXAMB-26-33S RECP-FIRE DET MOD TOP	71468	1	26-11-21 E002-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D00900
Page 5 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01000	1	DPXAMB-26-33S RECP-FIRE DET MOD MIDDLE	71468	1	26-11-31 E002-02/ /	YC001-YC030, YK901-YM670
D01002	1	DPXAMB-26-33S RECP-FIRE DET MOD BOTTOM	71468	1	26-11-11 E002-02/ /	YC001-YC030, YK901-YM670
D01008	1	BACC63CM1203SN PLUG-CONDUCTIVE CONNECTOR	81205	2	78-32-51 NSTA 202/120/L32	ALL
D01008 T	1	BACC10KB12 BACKSHELL	81205	2	78-32-51 / /	YC001-YC007
D01008 T	1	440AJ069ZM1204 BACKSHELL	06324	2	78-32-51 / /	YC008-YM670
D01008 U	1	202K121-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-32-51 / /	YC008-YM670
D01008 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-32-51 / /	YC008-YM670
D01008 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-32-51 / /	YC008-YM670
D01010	1	BACC63CB14-7SN PLUG- CONDUCTIVE	81205	1	27-53-11 723/167/L007	YC001-YC029
D01010	1	BACC45FT14-7S PLUG- CONDUCTIVE	81205	1	27-53-11 723/167/L007	YC030
D01010	1	BACC63CB14A7SN PLUG- CONDUCTIVE	81205	1	27-53-11 723/167/L007	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D01010 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-53-11 */ /	YC001-YC028
D01010 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-53-11 */*/	YC029
D01010 T	1	MS27559-4 BACKSHELL- CONDUCTIVE	81205	1	27-53-11 */*/	YC030

EQUIPMENT LIST

D280A103

Section D01000

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01010 T	1	M85049-51S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-11 */*/	YC031-YK907, YK910-YK912, YK918-YK919, YL401-YL421, YL423-YL429, YM645-YM670
D01010 T	1	M85049-51S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-11 / /	YK908-YK909, YL422, YM643
D01012	1	BACC63CB14-7SN PLUG- CONDUCTIVE	81205	1	27-53-12 719/173/L006	YC001-YC030
D01012	1	BACC63CB14A7SN PLUG- CONDUCTIVE	81205	1	27-53-12 719/173/L006	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D01012 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-53-12 * / /	YC001-YC030
D01012 T	1	M85049-51S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-12 */*/	YC031-YK907, YK910-YK912, YK918-YK919, YL401-YL421, YL423-YL429, YM645-YM670
D01012 T	1	M85049-51S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-12 / /	YK908-YK909, YL422, YM643
D01014	1	BACC63CB14-7SN PLUG- CONDUCTIVE	81205	1	27-53-11 723/200/R020	YC001-YC029
D01014	1	BACC45FT14-7S PLUG- CONDUCTIVE	81205	1	27-53-11 723/200/R020	YC030
D01014	1	BACC63CB14A7SN PLUG- CONDUCTIVE	81205	1	27-53-11 723/200/R020	YK901-YK912, YK918, YL401- YL426, YM643- YM652
D01014 T	1	BACC10KE14 BACKSHELL- CONDUCTIVE	81205	1	27-53-11 * / /	YC001-YC028
D01014 T	1	BACC10KD14 BACKSHELL- CONDUCTIVE	81205	1	27-53-11 * / /	YC029

EQUIPMENT LIST

D280A103

Section D01000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01014 T	1	MS27291-3 BACKSHELL- CONDUCTIVE	81205	1	27-53-11 * / /	YC030
D01014 T	1	M85049-51S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-11 * / /	YK901-YK912, YK918, YL401- YL426, YM643- YM652
D01016	1	BACC63CM1203SN PLUG-CONDUCTIVE CONNECTOR	81205	2	78-32-51 NSTA 203/68/R15	ALL
D01016 T	1	BACC10KB12 BACKSHELL	81205	2	78-32-51 / /	YC001-YC007
D01016 T	1	440AJ069ZM1204 BACKSHELL	06324	2	78-32-51 / /	YC008-YM670
D01016 U	1	202K121-25-0-225 STRAIGHR, LIPPED BOOT	06090	2	78-32-51 / /	YC008-YC030
D01016 U	1	202K121-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-32-51 / /	YC031-YM670
D01016 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-32-51 / /	YC008-YM670
D01016 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-32-51 / /	YC008-YM670
D01036	1	BACC45FT12-12S PLUG	81205	1	33-11-11 P001-05/ /	YC001-YC002, YC007-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01036	1	BACC45FT12-12S PLUG	81205	1	33-14-11 P001-05/ /	YC003-YC006
D01036 T	1	BACC10JC12 BACKSHELL - 90	81205	1	33-11-11 * / * / *	YC001-YC002, YC007
D01036 T	1	BACC10JC12 BACKSHELL - 90	81205	1	33-14-11 * / * / *	YC003-YC006

EQUIPMENT LIST

D280A103

Section D01000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01036 T	1	BACC10JC12 BACKSHELL - 90	81205	1	33-11-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01038	1	BACC63CB20-28SN PLUG - CONDUCTIVE	81205	1	33-11-11 P003-04/ /	YC001-YC030, YK901-YL429, YM643-YM652
D01038 T	1	BACC10KE20 BACKSHELL - CONDUCTIVE - 90	81205	1	33-11-11 */ /	YC001-YC030
D01038 T	1	BACC10KE20 BACKSHELL - CONDUCTIVE - 90	81205	1	33-11-11 */ */	YK901-YL429, YM643-YM652
D01040	1	BACC66F11F31AA01 PLUG PLATE ASSY- ANTI-SKID	81205	1	32-42-11 E001-03/ /	ALL
D01040A	1	PARTAOFD01040 PLUG - ANTI-SKID		0	32-42-11 E001-03/ /	YC001-YC050, YM643-YM670
D01040A	1	PARTAOFD01040 PLUG - ANTI-SKID		0	32-42-11 */ */	YK901-YL430
D01040B	1	PARTBOFD01040 PLUG - ANTI-SKID		0	32-42-11 E001-03/ /	YC001-YC050, YM643-YM670
D01040B	1	PARTBOFD01040 PLUG - ANTI-SKID		0	32-42-11 */ */	YK901-YL430
D01040C	1	PARTCOFD1040 PLUG - ANTI-SKID		0	32-42-11 E001-03/ /	YC001-YC050, YM643-YM670
D01040C	1	PARTCOFD1040 PLUG - ANTI-SKID		0	32-42-11 */ */	YK901-YL430
D01042	1	DPX2MB-26S8S-33B-0001 PLUG-PLATE ASSY	71468	1	30-41-11 E002-01/ /	ALL
D01042A	1	PARTAOFD01042 PLUG-RIGHT SIDE WINDOW CONT		0	30-41-11 E002-01/ /	ALL
D01042B	1	PARTBOFD01042 PLUG-RIGHT SIDE WINDOW CONT		0	30-41-11 E002-01/ /	ALL
D01044	1	DPX2MB-26S8S-33B-0001 PLUG-PLATE ASSY	71468	1	30-41-11 E002-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D01000

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01044A	1	PARTAD01044 PLUG-L FRONT WINDOW CONT		0	30-41-11 E002-01/ /	ALL
D01044B	1	PARTBD01044 PLUG-L FRONT WINDOW CONT		0	30-41-11 E002-01/ /	ALL
D01046	1	DPX2MB-26S8S-33B-0001 PLUG PLATE ASSY	71468	1	30-41-12 E004-02/ /	ALL
D01046A	1	PARTAOFD01046 PLUG-LEFT SIDE WINDOW CONT		0	30-41-12 E004-02/ /	ALL
D01046B	1	PARTBOFD01046 PLUG-LEFT SIDE WINDOW CONTROL		0	30-41-12 E004-02/ /	ALL
D01048	1	DPX2MB-26S8S-33B-0001 PLUG PLATE ASSY-	71468	1	30-41-12 E004-02/ /	ALL
D01048A	1	PARTAOFD01048 PLUG-R FRONT WINDOW CONT		0	30-41-12 E004-02/ /	ALL
D01048B	1	PARTBOFD01048 PLUG-R FRONT WINDOW CONT		0	30-41-12 E004-02/ /	ALL
D01070	1	35303-75 PLUG-	73168	1	26-12-11 727/201/L009	ALL
D01078	1	BACC45FT18-31S PLUG	81205	1	26-21-11 P08-01/ /	YC001-YC030
D01078	1	BACC45FT18-31S PLUG	81205	1	26-21-11 P008-01/ /	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01078 T	1	BACC10JS18 BACKSHELL	81205	1	26-11-11 TBD/ /	YC001-YC030
D01078 T	1	BACC10JS18 BACKSHELL	81205	1	26-11-11 */*/	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01080	1	BACC45FT18-31S6 PLUG	81205	1	26-21-11 P008-01/ /	YC001-YC003, YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D01000

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01080	1	BACC45FT18-31S6 PLUG	81205	1	26-21-11 P008-01/*/*	YC004-YC026
D01080 T	1	BACC10JS18 BACKSHELL	81205	1	26-21-11 */*/*	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01084	1	BACC45FT14-7S PLUG-SPEED BRAKE HANDLE ACTR	81205	1	27-62-12 199/205/L6	YC001-YC007
D01084	1	BACC45FT14-7S PLUG-SPEED BRAKE HANDLE ACTR	81205	1	27-62-12 199/205/L006	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01084 T	1	BACC10JS14 BACKSHELL-	81205	1	27-62-12 */*/*	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01086	1	BACC45FT20-41S6 PLUG-	81205	1	24-11-11 P005-05/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D01000
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01128	1	BACC45FN14-7S RCPT-	81205	1	33-26-21 AB0288/ /	ALL
D01153	1	BACC66F11C08AA01 PLUG PLATE ASSEMBLY	81205	1	34-49-11 E001-01/ /	ALL
D01153 T	1	S280W601-116 GND - BLOCK 48	81205	1	22-11-11 E001-01/ /	YC001-YC050
D01153 T	1	S280W601-116 GND - BLOCK 48	81205	1	22-11-11 */**	YK901-YM670
D01153A	1	PARTAOFD01153 PLUG		0	34-49-11 E001-01/ /	YC001-YC050
D01153A	1	PARTAOFD01153 PLUG		0	34-49-11 */**	YK901-YM670
D01153B	1	PARTBOFD01153 PLUG		0	34-49-11 E001-01/ /	YC001-YC050
D01153B	1	PARTBOFD01153 PLUG		0	34-49-11 */**	YK901-YM670
D01153C	1	PARTCOFD01153 PLUG		0	34-49-11 E001-01/ /	YC001-YC050
D01153C	1	PARTCOFD01153 PLUG		0	34-49-11 */**	YK901-YM670
D01172	1	BACC45FT10-5S PLUG-AURAL WARNING M/W M315	81205	1	34-16-11 202/210/R005	YC001-YC030, YK901-YM670
D01172 T	1	BACC10JS10 BACKSHELL-	81205	1	34-16-11 202/210/R005	YC001-YC030
D01172 T	1	BACC10JS10 BACKSHELL-	81205	1	34-16-11 */**	YK901-YM670
D01176	1	BACC63BP12D3S6 PLUG-DISCH SW APU	81205	1	26-21-11 1081/227/L024	YC001-YC007
D01176	1	BACC63BP12D3S6 PLUG-DISCH SW APU	81205	1	26-21-11 1077/229/L022	YC008-YC030, YK901-YM670
D01176 T	1	BACC10KA12 BACKSHELL	81205	1	26-21-11 / /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D01100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01176 T	1	BACC10KA12 BACKSHELL	81205	1	26-21-11 1081/224/L227	YC008-YC030, YK901-YK910, YL421-YL423, YM643
D01176 T	1	BACC10KA12 BACKSHELL	81205	1	26-21-11 */*/*	YK911-YL401, YL424-YL430, YM645-YM670

EQUIPMENT LIST

D280A103

Section D01100

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01205	1	BACC45FT14-15S PLUG	81205	1	34-49-11 P003-07/ /	YC008-YC030, YK901-YL429, YM643-YM652
D01205 T	1	BACC10JS14 BACKSHELL	81205	1	34-49-11 */ /	YC008-YC030
D01205 T	1	BACC10JS14 BACKSHELL	81205	1	34-49-11 */*/	YK901-YL429, YM643-YM652
D01218	1	BACC63CD24-22S RCPT-	81205	1	25-31-11 350/292/R025	ALL
D01246	1	BACC63BP12C12SN PLUG-APU DOOR OPEN SW	81205	1	49-41-11 1047/240/R041	YC001-YC007
D01246	1	BACC63BP12C12SN PLUG-APU DOOR OPEN SW	81205	1	49-62-11 1047/240/R041	YC008-YC030, YK901-YM670
D01246 T	1	BACC10KE12 BACKSHELL	81205	1	49-41-11 / /	YC001-YC007
D01246 T	1	BACC10KE12 BACKSHELL	81205	1	49-62-11 1047/240/RR41	YC008-YC030, YK901-YK910, YL421-YL423, YM643
D01246 T	1	BACC10KE12 BACKSHELL	81205	1	49-62-11 */*/	YK911-YL401, YL424-YL430, YM645-YM670
D01249	1	BACC63BV10F5SN RECP-CONDUCTIVE	81205	1	27-48-11 1167/265/L006	YC001-YC007
D01249	1	BACC63BV10F5SN RECP-CONDUCTIVE	81205	1	27-48-11 1167/265/L06	YC008-YM670
D01249 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	27-48-11 */*/	ALL
D01288	1	BACC63CB10-5SN PLUG-	81205	1	21-51-14 584/162/L032	YM643-YM670
D01288 T	1	BACC10KD10 BACKSHELL-STRAIGHT	81205	1	21-51-14 */*/	YM643-YM670
D01290	1	BACC63CB10-5SN PLUG-	81205	1	21-51-24 584/162/R032	YM643-YM670

EQUIPMENT LIST

D280A103

Section D01200

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01290 T	1	BACC10KD10 BACKSHELL-STRAIGHT	81205	1	21-25-11 */*/	YM643-YM670

EQUIPMENT LIST

D280A103

Section D01200
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01322	1	BACC63BP14D7S7 CONNECTOR-L.BOTTLE M00194	81205	1	21-61-11 713/190/L057	ALL
D01322 T	1	BACC10KB14 BACKSHELL	81205	1	26-21-11 714/190/L56	YC001-YC028
D01322 T	1	BACC10KB14 BACKSHELL	81205	1	26-21-11 */*/*	YC029-YM670
D01324	1	BACC63BP14D7S7 CONNECTOR-R.BOTTLE M00195	81205	1	26-21-11 722/190/L56	ALL
D01324 T	1	BACC10KB14 BACKSHELL	81205	1	26-21-11 720+5/189/L58	ALL
D01344	1	BACC45FT22-55S PLUG-DIM MODULE	81205	1	31-52-11 J019-00/ /	YC001-YC030, YK901-YM670
D01344 T	1	BACC10JS22 BACKSHELL-	81205	1	31-52-11 */*/*	YC001-YC030, YK901-YM670
D01346	1	BACC45FT22-55S6 PLUG-DIM MODULE	81205	1	31-52-11 J019-00/ /	YC001-YC030, YK901-YM670
D01346 T	1	BACC10JS22 BACKSHELL-	81205	1	31-52-11 */*/*	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D01300
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01406	1	BACC45FT12-12S7 PLUG-	81205	1	52-71-11 P005-20/ /	ALL
D01407		CN1068A22A55N RECP-FEED THROUGH	287A4110	1	34-41-11 178/195/R003	ALL
D01409	1	BACC63BP22C55PN PLUG	81205	1	34-41-11 178/195/L003	ALL
D01409 T	1	G9263AA2206KNF BACKSHELL - 90 DEGREE	MIL	1	34-41-11 */*/*	ALL
D01411	1	BACC63BP22C55SN PLUG (STA 178)	81205	1	34-41-11 178/195/L005	YC001-YC030, YK901-YM670
D01444		1990-0101-0000-PROVISIONS- RECP-DC EXTERNAL POWER	65C27368 82389	1	24-31-01 350/157/L011	ALL
D01458	1	DPX2MB-67S67S-33B-0072 PLUG	71468	1	78-36-11 E003-02/ /	ALL
D01458A	1	PARTAOFD01458 PLUG-		1	78-36-11 E003-02/ /	YC001-YC050
D01458A	1	PARTAOFD01458 PLUG-		1	78-36-11 */*/*	YK901-YM670
D01458B	1	PARTBOFD01458 PLUG		1	78-36-11 E003-02/ /	YC001-YC050
D01458B	1	PARTBOFD01458 PLUG		1	78-36-11 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D01400

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01507	1	BACC45FT16-24S PLUG - FWD LAV ANNOUCE SELECTOR PNL	81205	1	23-31-06 LAV A/ /	YK901-YM670
D01507 T	1	BACC10GH16 BACKSHELL	81205	1	23-31-06 */*/	YK901-YM670
D01582	1	BACC63CB10-20SN PLUG- CONDUCTIVE	81205	1	27-54-11 723/199/R047	YC001-YC029
D01582	1	BACC45FT10-20S PLUG- CONDUCTIVE	81205	1	27-54-11 723/199/R047	YC030
D01582	1	BACC63CB10A20SN PLUG- CONDUCTIVE	81205	1	27-54-11 723/199/R047	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01582 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	27-54-11 */ /	YC001-YC029
D01582 T	1	MS27559-2 BACKSHELL- CONDUCTIVE	81205	1	27-54-11 */ /	YC030
D01582 T	1	M85049-51S10A BACKSHELL- CONDUCTIVE	81205	1	27-54-11 */ /	YC031-YK912, YK918-YK919, YL401-YL429
D01582 T	1	M85049-51S10A BACKSHELL- CONDUCTIVE	81205	1	27-54-11 */*/	YM643-YM652
D01598	1	582587-1 RCPT-MASTER DIM	00779	1	33-18-11 P006-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D01500
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01614	1	10-60450-5 SOCKET-MASTER TEST RELAY	81205	1	33-18-11 P006-00/ /	ALL
D01616	1	10-60450-5 SOCKET-MASTER DIM RELAY	81205	1	33-18-11 P006-00/ /	ALL
D01618	1	10-60450-5 SOCKET-AUX MASTER DIM RELAY	81205	1	33-18-11 P006-00/ /	ALL
D01620	1	BACS16W1A SOCKET	81205	1	33-25-11 P006-00/ /	ALL
D01622	1	BACS16W1A SOCKET	81205	1	33-25-11 P006-00/ /	ALL
D01637	1	BACC45FN14-15S PLUG-SYSTEM TEST PLUG	81205	1	31-31-11 P018-02/ /	ALL
D01640	1	BACS16W1A SOCKET-EXT PWR SENSING RLY	81205	1	33-29-11 P006-00/ /	ALL
D01673	1	BACC45FN10-5S RCPT-	81205	1	22-11-21 238/202/L014	ALL
D01675	1	BACC45FN10-5S RCPT	81205	1	22-11-11 220/201/R27	YC001-YC019
D01675	1	BACC45FN10-5S RCPT	81205	1	22-11-11 230/199/R017	YC020-YM670
D01677	1	BACC63BV10F5SN RCPT-CONDUCTIVE	81205	1	22-12-41 1156/271/R005	ALL
D01677 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-41 */*/*	ALL
D01679	1	BACC63BV10F5SN RCPT	81205	1	22-12-41 1156/271/R8	YC001-YC007
D01679	1	BACC63BV10F5SN RCPT	81205	1	22-12-41 1156/271/R008	YC008-YM670
D01679 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-41 / /	YC001-YC007
D01679 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-41 1160/264/R5	YC008-YC030
D01679 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-41 1156/271/R008	YC031-YM670

EQUIPMENT LIST

D280A103

Section D01600

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01681	1	BACC63BP16C24SN PLUG	81205	1	22-12-31 1176/270/L010	YC001-YC007
D01681	1	BACC63BP16C24SN PLUG	81205	1	22-12-31 1156/271/L010	YC008-YC030
D01681	1	BACC63BP16C24SN PLUG	81205	1	22-12-31 1167/271/L010	YC031-YM670
D01681 T	1	BACC10KD16 BACKSHELL	81205	1	22-12-31 */**	ALL
D01687	1	BACC63BP16C24SN PLUG-	81205	1	22-12-41 1164/287/L009	ALL
D01687 T	1	BACC10KD16 BACKSHELL	81205	1	22-12-41 */**	ALL
D01691	1	BACC63BP16C24SN PLUG	81205	1	22-11-31 671/190/L053	YC001-YC030
D01691	1	BACC63BP16H24SN PLUG	81205	1	22-11-31 671/190/L053	YC031-YM670
D01691 T	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YC001-YC028
D01691 T	1	BACC10KF16 BACKSHELL-CONDUCTIVE-45 DEG.	81205	1	22-11-31 */**	YC029-YC030
D01691 T	1	620AB049C16 BACKSHELL-CONDUCTIVE-45 DEG.	81205	1	22-11-31 */**	YC031-YM670
D01695	1	BACC63BV10F5SN RCPT-SPOILER 4 SENSOR	81205	1	22-11-31 ORSS/370/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01695 T	1	BACC10KF10 BACKSHELL, 45 DEGREE	81205	1	22-11-31 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01697	1	BACC63BV10F5SN RCPT-SPOILER 9 SENSOR	81205	1	22-11-31 ORSS/370/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D01600

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01697 T	1	BACC10KF10 BACKSHELL, 45 DEGREE	81205	1	22-11-31 */*/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01699	1	BACC63BV10F5SN RCPT-SPOILER 4 SENSOR	81205	1	22-11-31 ORSS/370/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01699 T	1	BACC10KF10 BACKSHELL, 45 DEGREE	81205	1	22-11-31 */*/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D01600
Page 3 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01701	1	BACC63BV10F5SN RCPT-SPOILER 9 SENSOR	81205	1	22-11-31 ORSS/370/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01701 T	1	BACC10KF10 BACKSHELL, 45 DEGREE	81205	1	22-11-31 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01707	1	BACC63BV10F5SN RCPT	81205	1	22-11-31 667/197/L024	YC001-YC030
D01707	1	BACC63BV10H5SN RCPT	81205	1	22-11-31 667/197/L024	YC031-YM670
D01707 T	1	BACC10KD10 BACKSHELL	81205	1	22-11-31 / /	YC001-YC028
D01707 T	1	BACC10KF10 BACKSHELL-45 DEG.	81205	1	22-11-31 */**	YC029-YC030
D01707 T	1	620AB049C10 BACKSHELL-45 DEG.	81205	1	22-11-31 */**	YC031-YM670
D01709	1	BACC63BV10F5SN RCPT	81205	1	22-11-31 667/196/L024	YC001-YC030
D01709	1	BACC63BV10H5SN RCPT	81205	1	22-11-31 667/196/L024	YC031-YM670
D01709 T	1	BACC10KD10 BACKSHELL	81205	1	22-11-31 / /	YC001-YC028
D01709 T	1	BACC10KF10 BACKSHELL- 45 DEG.	81205	1	22-11-31 */**	YC029-YC030
D01709 T	1	620AB049C10 BACKSHELL- 45 DEG.	81205	1	22-11-31 */**	YC031-YL430
D01709 T	1	620AB049C10 BACKSHELL-45 DEG.	81205	1	22-11-31 / /	YM643-YM670
D01711	1	BACC63BV10F5SN RCPT	81205	1	22-12-31 1156/265/R8	YC001-YC030
D01711	1	BACC63BV10F5SN RCPT	81205	1	22-12-31 1157/265/R006	YC031-YM670

EQUIPMENT LIST

D280A103

Section D01700

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01711 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-31 / /	YC001-YC007
D01711 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-31 1156/265/R8	YC008-YM670
D01713	1	BACC45FN10-5S RCPT-	81205	1	22-11-11 225/198/L15	YC001-YC019
D01713	1	BACC45FN10-5S RCPT-	81205	1	22-11-11 225/198/L015	YC020-YM670
D01782	1	BACC63BP12C12SN PLUG- RETRACT LANDING LT.L	81205	1	33-42-11 534/154/L034	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D01782 T	1	BACC10KF12 BACKSHELL-CONDUCTIVE	81205	1	33-42-11 500A+10/150/L32	YC001-YK910, YL421-YL423, YM643
D01782 T	1	BACC10KF12 BACKSHELL-CONDUCTIVE	81205	1	33-42-11 */*/*	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM652

EQUIPMENT LIST

D280A103

Section D01700

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01805	1	BACS16X1A SOCKET-	81205	1	31-31-11 J00024/ /	ALL
D01815	1	BACC63CB22-55S6 PLUG	81205	1	22-11-11 P0007/ /	ALL
D01815 T	1	BACC10KD22 BACKSHELL	81205	1	22-11-11 / /	ALL
D01817	1	BACC45FT22-55S8 PLUG - INSTRUMENT SWITCHING MODULE	81205	1	34-51-41 P005-28/ /	YC001-YC030, YK901-YM670
D01817 T	1	BACC10JS22 BACKSHELL	81205	1	34-51-41 */**	YC001-YC030, YK901-YM670
D01827	1	BACC63BP16C24SN PLUG	81205	1	22-11-31 675/190/L039	YC001-YC030
D01827	1	BACC63BP16H24SN PLUG	81205	1	22-11-31 675/190/L039	YC031-YM670
D01827 T	1	BACC10KE16 BACKSHELL	81205	1	22-11-31 / /	YC001-YC028
D01827 T	1	BACC10KE16 BACKSHELL	81205	1	22-11-31 */**	YC029-YC030
D01827 T	1	M85049-51S16A BACKSHELL	81205	1	22-11-31 */**	YC031-YL430
D01827 T	1	M85049-51S16A BACKSHELL	81205	1	22-11-31 / /	YM643-YM670
D01829	1	BACC63BV10F5SN RCPT-CONDUCTIVE	81205	1	22-12-31 1156/271/R005	ALL
D01829 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-31 / /	YC001-YC007
D01829 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-31 1156/271/R5	YC008-YM670
D01857	1	BACC63BP10C5SN PLUG	81205	1	22-11-12 1160/288/L011	ALL
D01857 T	1	BACC10KD10 BACKSHELL	81205	1	22-11-12 */**	YC001-YC030
D01857 T	1	BACC10KE10 BACKSHELL	81205	1	22-11-12 */**	YC031-YM670

EQUIPMENT LIST

D280A103

Section D01800

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01859	1	BACC63BP10C5SN PLUG	81205	1	22-11-12 670/193/L46	YC001-YC028
D01859	1	BACC63BP10C5SN PLUG	81205	1	22-11-12 670/193/L046	YC029-YC030
D01859	1	BACC63BP10H5SN PLUG	81205	1	22-11-12 670/193/L046	YC031-YM670
D01859 T	1	BACC10KE10 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YC001-YC028
D01859 T	1	BACC10KE10 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */*/	YC029-YC030
D01859 T	1	M85049-51S10A BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */*/	YC031-YM670
D01861	1	BACC63BP10C5SN PLUG	81205	1	22-11-12 1156/278/L11	YC001-YC030
D01861	1	BACC63BP10C5SN PLUG	81205	1	22-11-12 1168/278/L011	YC031-YM670
D01861 T	1	BACC10KD10 BACKSHELL	81205	1	22-11-12 / /	YC001-YC007
D01861 T	1	BACC10KD10 BACKSHELL	81205	1	22-11-12 1156/278/L11	YC008-YM670
D01863	1	BACC63BP10C5SN PLUG	81205	1	22-11-12 668/192/L037	YC001-YC030
D01863	1	BACC63BP10H5SN PLUG	81205	1	22-11-12 668/192/L037	YC031-YM670
D01863 T	1	BACC10KD10 BACKSHELL	81205	1	22-11-12 / /	YC001-YC030
D01863 T	1	M85049-52S10A BACKSHELL	81205	1	22-11-12 / /	YC031-YM670

EQUIPMENT LIST

D280A103

Section D01800

Page 2 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01907	1	MS27473T18A53S RCPT-	96906	1	31-32-15 P061-02/ /	ALL
D01967	1	BACC66H21C09AA01 PLUG PLATE ASSY	81205	1	23-27-11 E003-03/ /	YC001-YC030
D01967 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-27-11 E003-03/ /	YC001-YC030
D01967A	1	PARTAOFD01967 PLUG - ACARS MU		0	23-27-11 E003-03/ /	YC001-YC030
D01967B	1	PARTBOFD01967 PLUG - ACARS MU		0	23-27-11 E003-03/ /	YC001-YC030
D01967C	1	PARTCOFD01967 PLUG - ACARS MU		0	23-27-11 E003-03/ /	YC001-YC030
D01986	1	BACC45FT10-5S PLUG-	81205	1	38-41-13 855/179/L049	ALL
D01986 T	1	BACC10JC10 BACKSHELL-	81205	1	38-41-13 */*/*	ALL
D01990	1	BACC45FT10-5S PLUG-	81205	1	38-41-13 958/204/R002	ALL
D01990 T	1	BACC10JC10 BACKSHELL-	81205	1	38-41-13 */*/*	ALL

EQUIPMENT LIST

D280A103

Section D01900
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02113	1	1203-15-9 RCPT - (N) IN-LINE (NC)	91836	1	34-31-11 300/177/R022	ALL
D02115	1	795-15-9 PLUG- (C) STRAIGHT (IN)	91836	1	34-31-11 300/178/R022	YC001-YC030
D02115	1	795-15-9 PLUG- (C) STRAIGHT (IN)	91836	1	34-31-11 E001-02/ /	YK901-YM670
D02117	1	1205-47-9 PLUG - (N) STRAIGHT (NO)	91836	1	34-31-11 300/178/R022	ALL
D02119	1	PT08SE-10-6S-SR- PLUG	77820	1	34-51-41 300/180/R021	YC001-YC030, YK901-YM670
D02121	1	1203-14-9 RCPT - (N) STRAIGHT	91836	1	34-31-21 305/180/R21	ALL
D02123	1	795-15-9 PLUG - (C) STRAIGHT (IN)	91836	1	34-31-21 306/180/R020	YC001-YC050, YM643-YM670
D02123	1	795-15-9 PLUG - (C) STRAIGHT (IN)	91836	1	34-31-21 E001-04/ /	YK901-YL430
D02125	1	1205-47-9 PLUG - (N) STRAIGHT (NO)	91836	1	34-31-21 305/178/R021	ALL
D02127	1	PT08SE-10-6S-SR- PLUG-LOC ANT SWITCH-2 (CONTROL)	77820	1	34-51-41 305/178/R019	ALL
D02129	1	796-15-9 PLUG - (C) ANGLED 90 (OUT-1)	91836	1	34-31-11 178/187/L10	ALL
D02131	1	796-15-9 PLUG - (C) ANGLED 90 (OUT-2)	91836	1	34-31-21 178/187/L10	ALL
D02169	1	BACC45FT18-31S PLUG PLATE ASSY - ISDU - LEFT	81205	1	34-21-11 P005-70/ /	ALL
D02169 T	1	BACC10JS18 BACKSHELL	81205	1	34-21-11 */*/*	ALL
D02171	1	BACC45FT16-24S7 PLUG PLATE ASSY-MODE SELECT UNIT - LEFT	81205	1	34-21-11 P005-69/ /	ALL
D02171 T	1	BACC10JS16 BACKSHELL	81205	1	34-21-11 */*/*	ALL
D02173	1	BACC45FT16-24S6 PLUG PLATE ASSY-MODE SELECT UNIT - RIGHT	81205	1	34-21-21 P005-69/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D02100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02173 T	1	BACC10JS16 BACKSHELL	81205	1	34-51-41 */**	YC001-YC030, YK901-YM670
D02179	1	BACC66H21C04AA01 PLUG PLATE ASSY-FMC NO. 1	81205	1	34-61-11 E005-02/ /	ALL
D02179A	1	PARTAOFD02179 PLUG PLATE ASSY-FMC NO. 1		1	34-61-11 E005-02/ /	YC001-YC011, YK901-YM670
D02179A	1	PARTAOFD02179 PLUG PLATE ASSY-FMC NO. 1		1	34-61-11 */**	YC012-YC050
D02179B	1	PARTBOFD02179 PLUG PLATE ASSY-FMC NO. 1		1	34-61-11 E005-02/ /	YC001-YC011, YK901-YM670
D02179B	1	PARTBOFD02179 PLUG PLATE ASSY-FMC NO. 1		1	34-61-11 */**	YC012-YC050
D02179C	1	PARTCOFD02179 PLUG PLATE ASSY-FMC NO. 1		1	34-61-11 E005-02/ /	YC001-YC011, YK901-YM670
D02179C	1	PARTCOFD02179 PLUG PLATE ASSY-FMC NO. 1		1	34-61-11 */**	YC012-YC050
D02181	1	BACC45FT18-31S PLUG - CDU NO.1	81205	1	34-61-11 P009-65/ /	ALL
D02181 T	1	BACC10JS18 BACKSHELL	81205	1	34-61-11 P009-65/ /	YC001-YC050
D02181 T	1	BACC10JS18 BACKSHELL	81205	1	34-61-11 */**	YK901-YM670
D02183	1	BACC45FT18-31S6 PLUG PLATE ASSY-MODE SELECT UNIT - LEFT	81205	1	34-21-21 P005-70/ /	YC001-YC030, YK901-YM670
D02183 T	1	BACC10JS18 BACKSHELL	81205	1	34-51-41 /**	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D02100
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02205	1	BACC63BV10F5SN RCPT-CONDUCTIVE	81205	1	22-12-31 1156/271/L5	YC001-YC030
D02205	1	BACC63BV10F5SN RCPT-CONDUCTIVE	81205	1	22-12-31 1166/267/L006	YC031-YM670
D02205 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-31 / /	YC001-YC007
D02205 T	1	BACC10KD10 BACKSHELL	81205	1	22-12-31 1156/271/L5	YC008-YM670
D02207	1	BACC45FT10-5S PLUG	81205	1	22-12-41 1164/266/R6	YC001-YC030
D02207	1	BACC45FT10-5S PLUG	81205	1	22-12-41 1164/266/R006	YC031-YM670
D02207 T	1	MS27291-1 BACKSHELL	96906	1	22-12-41 / /	YC001-YC007
D02207 T	1	MS27291-1 BACKSHELL	96906	1	22-12-41 1164/266/R6	YC008-YC030
D02207 T	1	MS27291-1 BACKSHELL	96906	1	22-12-41 1164/266/R006	YC031-YM670
D02209	1	BD2P124S124S-8004 PLUG PLATE ASSEMBLY	00779	1	22-11-11 E001-01/ /	ALL
D02209A	1	PARTAOFD02209 PLUG		0	22-11-11 E001-01/ /	YC001-YC050
D02209A	1	PARTAOFD02209 PLUG		0	22-11-11 */*/*	YK901-YM670
D02209B	1	PARTBOFD02209 PLUG		0	22-11-11 E001-01/ /	YC001-YC050
D02209B	1	PARTBOFD02209 PLUG		0	22-11-11 */*/*	YK901-YM670
D02221	1	BACC45FT18-31S PLUG - CDU NO.2	81205	1	34-61-11 P009-66/ /	ALL
D02221 T	1	BACC10JS18 BACKSHELL	81205	1	34-61-11 P009-66/ /	ALL
D02257	1	BACC45FT16-24S6 PLUG	81205	1	22-13-11 200/203/R13	YC001-YC019

EQUIPMENT LIST

D280A103

Section D02200

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02257	1	BACC45FT16-24S6 PLUG	81205	1	22-13-11 200/203/R013	YC020-YM670
D02257 T	1	BACC10JS16 BACKSHELL	81205	1	22-13-11 / /	YC001-YC019
D02257 T	1	BACC10JS16 BACKSHELL	81205	1	22-13-11 */**	YC020-YM670
D02269	1	BACC45FT16-24S PLUG-MASTER CAUTION UNIT-LEFT	81205	1	34-21-11 P061-01/ /	ALL
D02269 T	1	BACC10JS16 BACKSHELL	81205	1	34-21-11 P061/ /	ALL
D02271	1	BACC45FT16-24S6 PLUG-MASTER CAUTION UNIT-RIGHT	81205	1	34-21-21 P061-01/ /	ALL
D02271 T	1	BACC10JS16 BACKSHELL	81205	1	34-21-21 P061/ /	ALL
D02273	1	MS3126F10-6SW PLUG	96906	1	34-41-11 0196/189/R10	YC001-YC007
D02273	1	MS3126F10-6SW PLUG	96906	1	34-41-11 0196/189/R010	YC008-YC011
D02273	1	MS3126F10-6SW PLUG	96906	1	34-41-11 199/182/R009	YC012-YC030, YK901-YM670
D02295	1	BACC66K31C01AA01 PLUG PLATE ASSY	81205	1	31-31-11 E003-02/ /	ALL
D02295 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	31-31-11 E003-02/**	YC001-YC050
D02295 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	31-31-11 */**	YK901-YM670
D02295 U	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	31-31-11 E003-02/**	YC001-YC050
D02295 U	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	31-31-11 */**	YK901-YM670
D02295A	1	PARTAOFD02295 PLUG		1	31-31-11 E003-02/ /	YC001-YC050
D02295A	1	PARTAOFD02295 PLUG		1	31-31-11 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D02200

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02295B	1	PARTBOFD02295 PLUG		1	31-31-11 E003-02/ /	YC001-YC050
D02295B	1	PARTBOFD02295 PLUG		1	31-31-11 */*/*	YK901-YM670
D02295C	1	PARTCOFD02295 PLUG		1	31-31-11 E003-02/ /	YC001-YC050
D02295C	1	PARTCOFD02295 PLUG		1	31-31-11 */*/*	YK901-YM670
D02295D	1	PARTDOFD02295 PLUG		1	31-31-11 E003-02/ /	YC001-YC050
D02295D	1	PARTDOFD02295 PLUG		1	31-31-11 */*/*	YK901-YM670
D02295E	1	PARTEOFD02295 PLUG		1	31-31-11 E003-02/ /	YC001-YC050
D02295E	1	PARTEOFD02295 PLUG		1	31-31-11 */*/*	YK901-YM670
D02295F	1	PARTFOFD02295 PLUG		1	31-31-11 E003-02/ /	YC001-YC050
D02295F	1	PARTFOFD02295 PLUG		1	31-31-11 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D02200

Page 3 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02349	1	BACC45FT12-12S PLUG-	81205	1	27-32-11 P005-18/ /	YC001-YC030, YK901-YM670
D02351	1	BACC45FT12-12S6 PLUG-	81205	1	27-32-21 P005-18/ /	YC001-YC030, YK901-YM670
D02375	1	BACS16AG1 RELAY SOCKET	81205	1	23-31-06 J020-0B/ /	ALL

EQUIPMENT LIST

D280A103

Section D02300
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02435	1	BACC45FT14-15S PLUG	81205	1	22-14-11 P001-03/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02435 T	1	BACC10JS14 BACKSHELL	81205	1	22-14-11 */**	YC001-YC007
D02435 T	1	BACC10JS14 BACKSHELL	81205	1	22-14-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02437	1	BACC45FT14-15S6 PLUG	81205	1	22-14-11 P001-03/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02437 T	1	BACC10JS14 BACKSHELL	81205	1	22-14-11 */**	YC001-YC007
D02437 T	1	BACC10JS14 BACKSHELL	81205	1	22-14-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02439	1	BACC45FT14-15S PLUG	81205	1	22-14-11 P003-01/ /	YC001-YC030, YK901-YL429, YM643-YM652
D02439 T	1	BACC10JS14 BACKSHELL	81205	1	22-14-11 */ /	YC001-YC030
D02439 T	1	BACC10JS14 BACKSHELL	81205	1	22-14-11 */**	YK901-YL429, YM643-YM652
D02441	1	BACC45FT14-15S6 PLUG	81205	1	22-14-11 P003-01/ /	YC001-YC030, YK901-YL429, YM643-YM652
D02441 T	1	BACC10JS14 BACKSHELL	81205	1	22-14-11 */ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D02400

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02441 T	1	BACC10JS14 BACKSHELL	81205	1	22-14-11 */*/	YK901-YL429, YM643-YM652
D02473	1	125-88-9 PLUG-COAX	91836	1	34-53-31 E001-02/ /	YC001-YC030, YK901-YM670
D02475	1	125-88-9 PLUG-COAX	91836	1	34-55-11 E001-02/ /	YC001-YC030, YK901-YM670
D02477	1	125-88-9 PLUG-COAX	91836	1	34-53-31 E001-02/ /	YC001-YC030, YK901-YM670
D02485	1	BACS16W1A SOCKET-A/P STAB TRIM C/O SW. ASSY. RELAY	81205	1	22-13-11 P8/ /	ALL
D02486	1	BACC45FT16-24S6 PLUG-	81205	1	29-11-11 P005-08/ /	ALL
D02487	1	BACC45FN14-15P6 RCPT-	81205	1	22-13-11 P8/ /	ALL
D02487 T	1	BACC10JS14 BACKSHELL	81205	1	22-13-11 / /	ALL

EQUIPMENT LIST

D280A103

Section D02400
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02501	1	BACC66H21C57AA01 PLUG PLATE ASSY	81205	1	23-51-51 E004-01/ /	YC001-YC022
D02501	1	BACC66H26C57AA01 PLUG PLATE ASSY	81205	1	23-51-51 E004-01/ /	YC023-YM670
D02501 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-51-51 E004-01/ /	YC001-YC050
D02501 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-51-51 */**	YK901-YM670
D02501 U	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-51-51 / /	YC001-YC050
D02501 U	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-51-51 */**	YK901-YM670
D02501A	1	PARTAD02501 PLUG-REMOTE ELECTRONIC UNIT		0	23-51-51 E004-01/ /	YC001-YC050
D02501A	1	PARTAD02501 PLUG		0	23-51-51 */**	YK901-YL430
D02501A	1	PARTAD02501 PLUG-REMOTE ELECTRONIC UNIT		0	23-51-51 */**	YM643-YM670
D02501B	1	PARTBD02501 PLUG-REMOTE ELECTRONIC UNIT		0	23-51-51 E004-01/ /	YC001-YC050
D02501B	1	PARTBD02501 PLUG		0	23-51-51 */**	YK901-YL430
D02501B	1	PARTBD02501 PLUG-REMOTE ELECTRONIC UNIT		0	23-51-51 */**	YM643-YM670
D02501C	1	PARTCD02501 PLUG-REMOTE ELECTRONIC UNIT		0	23-51-51 E004-01/ /	YC001-YC050
D02501C	1	PARTCD02501 PLUG		0	23-51-51 */**	YK901-YL430
D02501C	1	PARTCD02501 PLUG-REMOTE ELECTRONIC UNIT		0	23-51-51 */**	YM643-YM670
D02529	1	795-16-9 PLUG - ATC TOP ANTENNA	91836	1	34-53-31 430/305/R005	YC001-YC030
D02529	1	795-33-9 PLUG - ATC TOP ANTENNA	91836	1	34-53-31 430/305/R005	YK901-YM670

EQUIPMENT LIST

D280A103

Section D02500

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02537	1	BACC45FT10-5S PLUG-SPEEDBRAKE HANDLE POS TRANSMITTER	81205	1	27-62-37 188/200/L006	YC001-YC030, YK901-YM670
D02537 T	1	BACC10JS10 BACKSHELL	81205	1	27-62-37 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D02537 T	1	BACC10JS10 BACKSHELL	81205	1	27-62-37 */**	YK911-YK917
D02537 T	1	BACC10JS10 BACKSHELL	81205	1	27-62-37 */ /	YM643-YM649
D02555	1	BACC66F11F03AA01 PLUG-PLATE ASSY-SELCAL DECODER	81205	1	23-22-11 E004-01/ /	YC001-YC050, YM643-YM670
D02555	1	BACC66F11F03AA01 PLUG	81205	1	23-22-11 E004-01/ /	YK901-YL430
D02555 T	1	S280W601-116 GND BLOCK - ARINC 600 -SELCAL DECODER	81205	1	23-22-01 E004-01/ /	YC001-YC050
D02555 T	1	S280W601-116 GND BLOCK - ARINC 600	81205	1	23-22-01 */**	YK901-YL430
D02555 T	1	S280W601-116 GND BLOCK - ARINC 600 -SELCAL DECODER	81205	1	23-22-01 */**	YM643-YM670
D02555A	1	PARTAD02555 PLUG-SELCAL		0	23-22-01 E004-01/ /	YC001-YC050
D02555A	1	PARTAD02555 PLUG		0	23-22-01 */**	YK901-YL430
D02555A	1	PARTAD02555 PLUG-SELCAL		0	23-22-01 */**	YM643-YM670
D02555B	1	PARTB-D02555 PLUG-SELCAL		0	23-22-11 E004-01/ /	YC001-YC050
D02555B	1	PARTBD02555 PLUG		0	23-22-11 */**	YK901-YL430
D02555B	1	PARTB-D02555 PLUG-SELCAL		0	23-22-11 */**	YM643-YM670
D02555C	1	PARTCD02555 PLUG-SELCAL		0	23-22-11 E004-01/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section D02500

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02555C	1	PARTCD02555 PLUG		0	23-22-11 */*/*	YK901-YL430
D02555C	1	PARTCD02555 PLUG-SELCAL		0	23-22-11 */*/*	YM643-YM670
D02564	1	BACC63BP12C3SN PLUG-CONDUCTIVE	81205	1	32-42-11 725/197/L21	YC001-YC030
D02564	1	BACC63BP12D3SN PLUG-CONDUCTIVE	81205	1	32-42-11 725/197/L21	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D02564 T	1	BACC10KD12 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 TBD/ /	YC001-YC028
■ D02564 T	1	BACC10KD12 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC029-YC030
■ D02564 T	1	BACC10KA12 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02566	1	BACC63BP12C3SN PLUG-CONDUCTIVE	81205	1	32-42-11 725/193/L018	YC001-YC030
D02566	1	BACC63BP12D3SN PLUG-CONDUCTIVE	81205	1	32-42-11 725/193/L018	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D02566 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	32-42-11 TBD/ /	YC001-YC028
■ D02566 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	32-42-11 */*/*	YC029-YC030
■ D02566 T	1	BACC10KA12 BACKSHELL-CONDUCTIVE	81205	1	32-42-11 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02570	1	BACC63CB14-7SN PLUG- CONDUCTIVE	81205	1	32-42-11 713/198/L000	YC001-YC030

EQUIPMENT LIST

D280A103

Section D02500

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02570	1	BACC63CB14A7SN PLUG- CONDUCTIVE	81205	1	32-42-11 713/198/L000	YC031-YM670
D02570 T	1	BACC10KD14 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 715/198/L003	YC001-YC028
D02570 T	1	BACC10KF14 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC029-YC030
D02570 T	1	620AB049C14 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC031-YM670
D02572	1	BACC63BP10C5SN PLUG-CONDUCTIVE	81205	1	32-42-11 716/199/L004	YC001-YC030
D02572	1	BACC63BP10H5SN PLUG- CONDUCTIVE	81205	1	32-42-11 716/199/L004	YC031-YM670
D02572 T	1	BACC10KD10 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC001-YC028
D02572 T	1	BACC10KF10 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC029-YC030
D02572 T	1	620AB049C10 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC031-YM670
D02574	1	BACC63BP12C3SN PLUG- CONDUCTIVE	81205	1	32-42-11 714/196/L003	YC001-YC030
D02574	1	BACC63BP12H3SN PLUG- CONDUCTIVE	81205	1	32-42-11 714/196/L003	YC031-YM670
D02574 T	1	BACC10KE12 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 714/196/L003	YC001-YC028
D02574 T	1	BACC10KE12 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC029-YC030
D02574 T	1	M85049-51S12A BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC031-YM670
D02576	1	BACC63BP10C5SN PLUG- CONDUCTIVE	81205	1	32-42-11 712/197/L007	YC001-YC030
D02576	1	BACC63BP10H5SN PLUG- CONDUCTIVE	81205	1	32-42-11 712/197/L007	YC031-YM670
D02576 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 712/197/L007	YC001-YC028

EQUIPMENT LIST

D280A103

Section D02500

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02576 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC029-YC030
D02576 T	1	M85049-51S10A BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */*/*	YC031-YM670
D02586	1	DPX2MB-57S57S-33B-0038 PLUG PLATE ASSY	71468	1	27-62-11 E004-02/ /	ALL
D02586A	1	PARTAOFD02586 PLUG		1	27-62-11 E004-02/ /	YC001-YC009
D02586A	1	PARTAOFD02586 PLUG		1	27-62-11 */*/*	YC010-YM670
D02586B	1	PARTBOFD02586 PLUG		1	27-62-11 E004-02/ /	YC001-YC009
D02586B	1	PARTBOFD02586 PLUG		1	27-62-11 */*/*	YC010-YM670

EQUIPMENT LIST

D280A103

Section D02500
Page 5 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02621		2439-5-1 RCPT - (TNC) FEED THRU (42 DEG KEY)	287A4110 91836	1	34-31-11 178/212/R014	ALL
D02623		2439-5-1 RCPT - (TNC) FEED THRU (42 DEG KEY)	287A4110 91836	1	34-31-11 178/ /	ALL
D02625		2439-5-6 RCPT - (TNC) FEED THRU (102 DEG KEY)	287A4110 91836	1	34-31-21 178/212/R010	ALL
D02627		2439-5-6 RCPT - (TNC) FEED THRU (102 DEG KEY)	287A4110 91836	1	34-31-21 178/ /	ALL
D02639	1	BACC66F11C07AA01 PLUG PLATE ASSY	81205	1	23-31-01 E001-03/ /	ALL
D02639A	1	PARTOFD02639 PLUG - PA AMP		1	23-31-01 E001-03/ /	YC001-YC003
D02639A	1	PARTOFD02639 PLUG - PA AMP		0	23-31-01 E001-03/ /	YC004-YC050
D02639A	1	PARTAOFD02639 PLUG - PA AMP	81205	1	23-31-01 */*/*	YK901-YL430
D02639A	1	PARTAOFD02639 PLUG - PA AMP		1	23-31-01 E001-03/ /	YM643-YM670
D02639B	1	PARTOFD02639 PLUG - PA AMP		1	23-31-01 E001-03/ /	YC001-YC003
D02639B	1	PARTOFD02639 PLUG - PA AMP		0	23-31-01 E001-03/ /	YC004-YC050
D02639B	1	PARTBOFD02639 PLUG - PA AMP	81205	1	23-31-01 */*/*	YK901-YL430
D02639B	1	PARTBOFD02639 PLUG - PA AMP		1	23-31-01 E001-03/ /	YM643-YM670
D02639C	1	PARTOFD02639 PLUG - PA AMP		1	23-31-01 E001-03/ /	YC001-YC003
D02639C	1	PARTOFD02639 PLUG - PA AMP		0	23-31-01 E001-03/ /	YC004-YC050
D02639C	1	PARTCOFD02639 PLUG - PA AMP	81205	1	23-31-01 */*/*	YK901-YL430
D02639C	1	PARTCOFD02639 PLUG - PA AMP		1	23-31-01 E001-03/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section D02600

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02643	1	BACC66H21C50AA01 PLUG-QUICK ACCESS RECORDER	81205	1	31-35-03 E008-01/ /	YK910-YK920, YL421-YM670
D02643 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	31-35-03 E008-01/ /	YK910-YK920, YL421-YM670
D02643A	1	PARTAOFD02643 PLUG - QUICK ACCESS RECORDER		0	31-35-03 E008-01/ /	YK910-YK920
D02643A	1	PARTAOFD02643 PLUG-QUICK ACCESS RECORDER		0	31-35-03 E008-01/ /	YL421-YM670
D02643B	1	PARTBOFD02643 PLUG - QUICK ACCESS RECORDER		1	31-35-03 E008-01/ /	YK910-YK920
D02643B	1	PARTBOFD02643 PLUG-QUICK ACCESS RECORDER		1	31-35-03 E008-01/ /	YL421-YM670
D02643C	1	PARTCOFD02643 PLUG - QUICK ACCESS RECORDER		1	31-35-03 E008-01/ /	YK910-YK920
D02643C	1	PARTCOFD02643 PLUG		1	31-35-03 E008-01/ /	YL421-YM670
D02649	1	MS3126F20-41S PLUG	96906	1	31-33-01 P008-54/ /	ALL
D02650	1	BACC63CB20-28SN PLUG - CONDUCTIVE	81205	1	33-11-11 P001-09/ /	YC001-YC002, YC007-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02650	1	BACC63CB20-28SN PLUG - CONDUCTIVE	81205	1	31-62-11 P001-09/ /	YC003-YC006
D02650 T	1	BACC10KE20 BACKSHELL - CONDUCTIVE - 90	81205	1	33-11-11 */*/	YC001-YC002, YC007
D02650 T	1	BACC10KE20 BACKSHELL - CONDUCTIVE - 90	81205	1	31-62-11 */*/	YC003-YC006
D02650 T	1	BACC10KE20 BACKSHELL - CONDUCTIVE - 90	81205	1	33-11-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D02600

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02664	1	BACC63CB18-8SN PLUG-	81205	1	29-11-12 671/171/L019	YC001-YC030
D02664	1	BACC63CB18A8SN PLUG-	81205	1	29-11-12 671/171/L019	YC031-YM670
D02664 T	1	BACC10KE18 BACKSHELL	81205	1	29-11-12 671/171/L19	YC001-YC030
D02664 T	1	M85049-51S18A BACKSHELL	81205	1	29-11-12 671/171/L19	YC031-YL430
D02664 T	1	M85049-51S18A BACKSHELL	81205	1	29-11-12 671/167/L019	YM643-YM670
D02666	1	BACC63CB18-8SN PLUG-	81205	1	29-11-12 674/171/R004	YC001-YC030
D02666	1	BACC63CB18A8SN PLUG-	81205	1	29-11-12 674/171/R004	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02666 T		BACC10KE18 BACKSHELL-	81205	1	29-11-12 678/171/R4	YC001-YC028
D02666 T		BACC10KE18 BACKSHELL-	81205	1	29-11-12 674/171/R004	YC029-YC030
D02666 T		M85049-51S18A BACKSHELL-	81205	1	29-11-12 674/171/R004	YC031-YK910, YL421-YL423, YM643
D02666 T		M85049-51S18A BACKSHELL-	81205	1	29-11-12 */*/*	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM652
D02668		BACC45FT12-12S-REFONLY- PLUG-SYS A ELEC HYD PUMP GND FAULT DET	284A0206 81205	1	29-11-12 P092-00/ /	ALL
D02670		BACC45FT12-12S-REFONLY- PLUG-SYS B ELEC HYD PUMP GND FAULT DET	284A0206 81205	1	29-11-12 P091-00/ /	ALL
D02674	1	BACC63BN12-12S6 PLUG-	81205	1	29-31-11 678/194/R43	YC001-YC028

EQUIPMENT LIST

D280A103

Section D02600

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02674	1	BACC63BN12-12S6 PLUG-	81205	1	29-31-11 678/194/R043	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02674 T	1	MS27291-2 BACKSHELL-STRAIGHT	96906	1	29-31-11 TBD/ /	YC001-YC028
D02674 T	1	MS27559-3 BACKSHELL-90 DEGREE	96906	1	29-31-11 */**	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02676	1	BACC63BP12D3S8L PLUG- CONDUCTIVE	81205	1	29-32-11 724/162/R010	ALL
D02676 T	1	BACC10KB12 BACKSHELL- 90 DEGREE	81205	1	29-32-11 TBD/ /	YC001-YC028
D02676 T	1	BACC10KB12 BACKSHELL- 90 DEGREE	81205	1	29-32-11 */**	YC029-YM670
D02678	1	BACC63CB10-5S10 PLUG - CONDUCTIVE	81205	1	29-32-11 P003-01/ /	YC001-YC030, YK901-YL429, YM643-YM652
D02678 T	1	BACC10KD10 BACKSHELL - CONDUCTIVE	81205	1	29-32-11 */ /	YC001-YC030
D02678 T	1	BACC10KD10 BACKSHELL - CONDUCTIVE	81205	1	29-32-11 */**	YK901-YL429, YM643-YM652
D02680	1	BACC63CB10-5SN PLUG - CONDUCTIVE	81205	1	29-33-11 666/171/L043	YC001-YC030
D02680	1	BACC63CB10A5SN PLUG - CONDUCTIVE	81205	1	29-33-11 666/171/L043	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02680 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	29-33-11 TBD/ /	YC001-YC028
D02680 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	29-33-11 */**	YC029-YC030

EQUIPMENT LIST

D280A103

Section D02600

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02680 T	1	M85049-51S10A BACKSHELL- CONDUCTIVE	81205	1	29-33-11 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02682	1	BACC63CB10-5SN PLUG-CONDUCTIVE	81205	1	29-33-11 666/181/R022	YC001-YC030
D02682	1	BACC63CB10A5SN PLUG-CONDUCTIVE	81205	1	29-33-11 666/181/R022	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02682 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */*/*	YC001-YC028
D02682 T	1	BACC10KE10 BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */*/*	YC029-YC030
D02682 T	1	M85049-52S10A BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02684	1	BACC63CB10-5SN PLUG - CONDUCTIVE	81205	1	29-33-11 666/170/L047	YC001-YC030
D02684	1	BACC63CB10A5SN PLUG - CONDUCTIVE	81205	1	29-33-11 666/170/L047	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02684 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	29-33-11 TBD/ /	YC001-YC028
D02684 T	1	BACC10KE10 BACKSHELL- CONDUCTIVE	81205	1	29-33-11 */*/*	YC029-YC030
D02684 T	1	M85049-51S10A BACKSHELL- CONDUCTIVE	81205	1	29-33-11 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02686	1	BACC63CB10-5SN PLUG-CONDUCTIVE	81205	1	29-33-11 666/181/R027	YC001-YC030

EQUIPMENT LIST

D280A103

Section D02600

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02686	1	BACC63CB10A5SN PLUG-CONDUCTIVE	81205	1	29-33-11 666/181/R027	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02686 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */**	YC001-YC028
D02686 T	1	BACC10KE10 BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */**	YC029-YC030
D02686 T	1	M85049-51S10A BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */**	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02688	1	BACC63CE10SL-4S PLUG	81205	1	29-34-11 674/165/L010	YC001-YC030
D02688	1	MS3459KS10SL-4S PLUG	81205	1	29-34-11 674/165/L010	YC031-YM670
D02688 T	1	BACC10HW12 BACKSHELL	81205	1	29-34-11 674/165/L010	YC001-YC030
D02688 T	1	BACC10KB10 BACKSHELL	81205	1	29-34-11 674/165/L010	YC031-YM670
D02690	1	BACC63CE10SL-4S PLUG-	81205	1	29-34-11 672/159/R007	YC001-YC030
D02690	1	MS3459KS10SL-4S PLUG-	81205	1	29-34-11 672/159/R007	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02690 T		BACC10HW12 BACKSHELL-	81205	1	29-34-11 672/159/R007	YC001-YC028
D02690 T		BACC10HV12 BACKSHELL-	81205	1	29-34-11 672/159/R007	YC029-YC030
D02690 T		BACC10KA10 BACKSHELL-	81205	1	29-34-11 672/159/R007	YC031-YK910, YL421-YL423, YM643

EQUIPMENT LIST

D280A103

Section D02600

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02690 T		BACC10KA10 BACKSHELL-	81205	1	29-34-11 */*/*	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM652

EQUIPMENT LIST

D280A103

Section D02600
Page 7 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02701	1	125-92-9 PLUG-COAX	91836	1	34-53-31 316/161/L-23	ALL
D02703	1	1205-48-9 PLUG-COAX	91836	1	34-53-31 316/162/L023	YC001-YC030, YK901-YM670
D02705	1	795-21-9 PLUG-COAX	91836	1	34-53-31 316/163/L-23	YC001-YC030
D02705	1	795-21-9 PLUG-COAX	91836	1	34-53-31 E001-05/ /	YK901-YM670
D02707	1	1205-62-9 PLUG-COAX	91836	1	34-53-31 314/161/L-23	ALL
D02709	1	125-95-9 PLUG-COAX	91836	1	34-53-31 314/161/L23	ALL
D02711	1	795-15-9 PLUG-COAX	91836	1	34-53-31 314/163/L-23	YC001-YC030
D02711	1	795-15-9 PLUG-COAX	91836	1	34-53-31 E001-05/ /	YK901-YM670
D02743	1	BACC66K35F40AK01 PLUG PLATE ASSEMBLY	81205	1	34-45-11 E001-01/ /	ALL
D02743A	1	PARTAOFD02743 PLUG		0	34-45-11 E001-01/ /	YC001-YC050
D02743A	1	PARTAOFD02743 PLUG		0	34-45-11 */*/*	YK901-YM670
D02743AU	1	125-96-9 PLUG	91836	4	34-45-11 E001-01/ /	YC001-YC050
D02743AU	1	125-96-9 PLUG	91836	4	34-45-11 */*/*	YK901-YM670
D02743B	1	PARTBOFD02743 PLUG		0	34-45-11 E001-01/ /	YC001-YC050
D02743B	1	PARTBOFD02743 PLUG		0	34-45-11 */*/*	YK901-YM670
D02743BU	1	125-94-9 PLUG	91836	4	34-45-11 E001-01/ /	YC001-YC050
D02743BU	1	125-94-9 PLUG	91836	4	34-45-11 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D02700

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02743C	1	PARTCOFD02743 PLUG		0	34-45-11 E001-01/ /	YC001-YC050
D02743C	1	PARTCOFD02743 PLUG		0	34-45-11 */**	YK901-YM670
D02743D	1	PARTDOFD02743 PLUG		0	34-45-11 E001-01/ /	YC001-YC050
D02743D	1	PARTDOFD02743 PLUG		0	34-45-11 */**	YK901-YM670
D02743E	1	PARTEOFD02743 PLUG		0	34-45-11 E001-01/ /	YC001-YC050
D02743E	1	PARTEOFD02743 PLUG		0	34-45-11 */**	YK901-YM670
D02743F	1	PARTFOF2743 PLUG		0	34-45-11 E001-01/ /	YC001-YC050
D02743F	1	PARTFOF2743 PLUG		0	34-45-11 */**	YK901-YM670
D02745	1	125-91-9 PLUG-COAX	91836	1	34-45-21 387/302/R005	ALL
D02747	1	125-91-9 PLUG-COAX	91836	1	34-45-21 385/302/R005	ALL
D02749	1	125-91-9 PLUG-COAX	91836	1	34-45-21 386/302/R005	ALL
D02751	1	125-91-9 PLUG-COAX	91836	1	34-45-21 385/302/R006	ALL
D02753	1	125-88-9 PLUG-COAX	91836	1	34-45-21 305/150/R001	ALL
D02755	1	125-88-9 PLUG-COAX	91836	1	34-45-21 305/150/R002	ALL
D02757	1	125-88-9 PLUG-COAX	91836	1	34-45-21 305/150/R001	ALL
D02759	1	125-88-9 PLUG-COAX	91836	1	34-45-21 305/150/L001	ALL
D02775	1	BACS16X1A RELAY SOCKET	81205	1	23-22-11 J022-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D02700
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02813	1	RM3P32C2S67S32C2S-0001 PLUG	71771	1	23-32-21 E003-02/ /	YC001-YC002, YC008-YC050
D02813	1	CPX3MA32C2S67S32C2S-33-0001 PLUG	71771	1	23-32-21 E003-02/ /	YC003-YC007
D02813	1	RM3P32C2S67S32C2S-0001 PLUG	71771	1	23-32-21 E008-01/ /	YK901-YK909, YM643-YM646
D02813	1	BACC66H52F01AA01 PLUG	81205	1	23-32-21 E008-01/ /	YK910-YL430, YM647-YM670
D02813 T	1	527-212MA9B9C4S-1 BACKSHELL - EMI		1	23-32-21 E008-01/ /	YK910-YL430
D02813 T	1	527-212MA9B9C4S-1 BACKSHELL - EMI	06324	1	23-32-21 E008-01/ /	YM647-YM670
D02813A	1	PARTAOFD02813 PLUG		1	23-32-21 E003-02/ /	YC001-YC050
D02813A	1	PARTAOFD02813 PLUG		1	23-32-21 E008-01/ /	YK901-YM670
D02813B	1	PARTBOFD02813 PLUG		1	23-32-21 E003-02/ /	YC001-YC050
D02813B	1	PARTBOFD02813 PLUG		1	23-32-21 E008-01/ /	YK901-YM670
D02813C	1	PARTCOFD02813 PLUG		1	23-32-21 E003-02/ /	YC001-YC050
D02813C	1	PARTCOFD02813 PLUG		1	23-32-21 E008-01/ /	YK901-YM670
D02819	1	756-16-9 PLUG	91836	1	23-32-21 E008-01/ /	YK901-YK909, YM643-YM646
D02821	1	756-16-9 PLUG	91836	1	23-32-21 E008-01/ /	YK901-YK906
D02849	1	125-88-9 PLUG-COAX	91836	1	34-55-21 E001-05/ /	YC001-YC030, YK901-YM670
D02851	1	125-88-9 PLUG-COAX	91836	1	34-53-31 E001-05/ /	YC001-YC030, YK901-YM670
D02853	1	125-88-9 PLUG-COAX	91836	1	34-53-31 E001-05/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D02800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02860	1	BACC63BP12D12SN PLUG-CONDUCTIVE	81205	1	29-23-11 674/158/L002	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02860 T	1	BACC10KB12 BACKSHELL-CONDUCTIVE	81205	1	29-23-11 / /	YC001-YC028
D02860 T	1	BACC10KB12 BACKSHELL-CONDUCTIVE	81205	1	29-23-11 */*/	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02864	1	BACC45FT10-5S PLUG-NOSE STEERING ACT	81205	1	32-51-11 251/203/L035	YC001-YC030, YK901-YM670
D02864 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	1	32-51-11 / /	YC001-YC030, YK901-YM670
D02866	1	BACC45FT22-55S8 PLUG-DIM MODULE	81205	1	33-18-61 J019-00/ /	YC001-YC030, YK901-YM670
D02866 T	1	BACC10JS22 BACKSHELL-	81205	1	33-18-61 */*/	YC001-YC030, YK901-YM670
D02870	1	BACC63BP14C7SN PLUG-CONDUCTIVE	81205	1	32-41-11 703/201/L027	YC001-YC030
D02870	1	BACC63BP14H7SN PLUG-CONDUCTIVE	81205	1	32-41-11 703/201/L027	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02870 T	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 / /	YC001-YC028
D02870 T	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */*/	YC029-YC030
D02870 T	1	M85049-51S14A BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */*/	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02872	1	BACC63CB10-20SN PLUG-CONDUCTIVE	81205	1	32-41-11 688/191/R065	YC001-YC030

EQUIPMENT LIST

D280A103

Section D02800

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02872	1	BACC63CB10B20SN PLUG-CONDUCTIVE	81205	1	32-41-11 688/191/R065	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02872 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YC028
D02872 T	1	BACC10KE10 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */**	YC029-YC030
D02872 T	1	BACC10KB10 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02874	1	BACC63CB10-20SN PLUG-CONDUCTIVE	81205	1	32-41-11 668/191/L066	YC001-YC030
D02874	1	BACC63CB10B20SN PLUG-CONDUCTIVE	81205	1	32-41-11 688/191/L066	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02874 T	1	BACC10KD10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YC028
D02874 T	1	BACC10KF10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC029-YC030
D02874 T	1	BACC10KC10 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02875	1	MS27473T18A53P PLUG	96906	1	31-32-15 P061-01/ /	ALL
D02875 T	1	M85049-49-2-18W BACKSHELL	96906	1	31-32-15 P061-01/ /	ALL
D02877	1	BACC45FT24-61S PLUG	81205	1	31-32-15 P061-01/ /	ALL
D02877 T	1	BACC10JS24 BACKSHELL	81205	1	31-32-15 P061/ /	ALL

EQUIPMENT LIST

D280A103

Section D02800

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02879	1	BACC45FT22-55S PLUG	81205	1	31-32-15 P061-01/ /	ALL
D02879 T	1	BACC10JS22 BACKSHELL	81205	1	31-32-15 P061/*/*	ALL
D02880	1	BACS16W5A SOCKET-OXYGEN RELAY R322	81205	1	35-21-11 J023-00/ /	ALL
D02882	1	BACS16W5A SOCKET-OXYGEN RELAY R323	81205	1	35-21-11 J023-00/ /	ALL
D02884	1	BACS16W1A SOCKET-OXYGEN RELAY R324	81205	1	35-21-11 J023-00/ /	ALL
D02886	1	BACC63BP10C5S6 PLUG-ALTITUDE PRESSURE SWITCH S813	81205	1	35-21-11 J023-00/ /	ALL
D02889	1	BACC45FT16A24S7 PLUG-ELT CONT PNL	81205	1	23-24-11 P005-80/ /	ALL

EQUIPMENT LIST

D280A103

Section D02800
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02905	1	POACONNECTOR PLUG-121.5/243 MHZ XMTR	60253	1	23-24-11 797/289/L015	ALL
D02907	1	POACONNECTOR PLUG-121.5/243 MHZ ELT ANTENNA	60253	1	23-24-11 797/289/L005	ALL
D02909	1	BACC63BP12A3SN PLUG	81205	1	31-31-14 725.9/187/L23	YC001-YC007
D02909	1	BACC63BP12A3SN PLUG	81205	1	31-31-14 725.9/187/L023	YC008-YC030
D02909	1	BACC63BP12H3SN PLUG	81205	1	31-31-14 725.9/187/L023	YC031-YK912, YK918-YK919, YL401-YL429
D02909	1	BACC63BP12H3SN PLUG	81205	1	31-31-14 726/187/L022	YM643-YM652
D02909 T	1	BACC10KE12 BACKSHELL-	81205	1	31-31-14 / /	YC001-YC028
D02909 T	1	BACC10KF12 BACKSHELL-	81205	1	31-31-14 */*/*	YC029-YC030
D02909 T	1	620AB049C12 BACKSHELL-	81205	1	31-31-14 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02911	1	BACC63BP12A3SN PLUG	81205	1	31-31-14 725/189/L004	YC001-YC030
D02911	1	BACC63BP12H3SN PLUG	81205	1	31-31-14 725/189/L004	YC031-YM670
D02911 T	1	BACC10KD12 BACKSHELL	81205	1	31-31-14 */*/*	YC001-YC028
D02911 T	1	BACC10KF12 BACKSHELL	81205	1	31-31-14 */*/*	YC029-YC030
D02911 T	1	620AB049C12 BACKSHELL	81205	1	31-31-14 */*/*	YC031-YM670
D02913	1	BACC63BP12A3SN PLUG	81205	1	31-31-14 681/193/L069	YC001-YC030

EQUIPMENT LIST

D280A103

Section D02900

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02913	1	BACC63BP12H3SN PLUG	81205	1	31-31-14 681/193/L069	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02913 T	1	BACC10KE12 BACKSHELL-	81205	1	31-31-14 / /	YC001-YC028
D02913 T	1	BACC10KE12 BACKSHELL-	81205	1	31-31-14 */**	YC029-YC030
D02913 T	1	M85049-51S12A BACKSHELL-	81205	1	31-31-14 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02915	1	BACC63BP12A3SN PLUG	81205	1	31-31-14 692/192/R068	YC001-YC030
D02915	1	BACC63BP12H3SN PLUG	81205	1	31-31-14 692/192/R068	YC031-YM670
D02915 T	1	BACC10KD12 BACKSHELL	81205	1	31-31-14 / /	YC001-YC028
D02915 T	1	BACC10KE12 BACKSHELL	81205	1	31-31-14 */**	YC029-YC030
D02915 T	1	M85049-51S12A BACKSHELL	81205	1	31-31-14 */**	YC031-YM670
D02921	1	BACC45FT10-5S PLUG-	81205	1	23-32-12 P005-81/ /	YC001-YC030
D02921	1	BACC45FT10-5S PLUG-	81205	1	23-32-14 P005-81/ /	YK901-YM670
D02928	1	BACC63CB14-12SN PLUG-CONDUCTIVE	81205	1	27-11-11 666/169/L035	YC001-YC030
D02928	1	BACC63CB14A12SN PLUG-CONDUCTIVE	81205	1	27-11-11 666/169/L035	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02928 T	1	BACC10KE14 BACKSHELL,CONDUCTIVE	81205	1	27-11-11 / /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D02900

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02928 T	1	BACC10KE14 BACKSHELL,CONDUCTIVE	81205	1	27-11-11 666/ /	YC008-YC028
D02928 T	1	BACC10KE14 BACKSHELL,CONDUCTIVE	81205	1	27-11-11 */**	YC029-YC030
D02928 T	1	M85049-51S14A BACKSHELL,CONDUCTIVE	81205	1	27-11-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02930	1	BACC45FT12-12S7 PLUG-AILERON TRIM CONT MODULE	81205	1	27-11-11 P008-43/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02930 T	1	BACC10JS12 BACKSHELL-	81205	1	27-11-11 / /	YC001-YC007
D02930 T	1	BACC10JS12 BACKSHELL-	81205	1	27-11-11 */**	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02932	1	BACC63CB14-15SN PLUG-RUDDER TRIM ACTUATOR M1125	81205	1	27-28-11 RUD51/ /4	YC001-YC019
D02932	1	BACC63CB14-15SN PLUG-RUDDER TRIM ACTUATOR M1125	81205	1	27-28-11 RUD51/ /	YC020-YM670
D02932 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	27-28-11 / /	YC001-YC030
D02932 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	27-28-11 */**	YC031-YM670
D02934	1	BACC63CB12-12SN PLUG-RUDDER TRIM INDICATOR N159	81205	1	27-28-11 P008-43/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D02934 T	1	BACC10KD12 BACKSHELL-	81205	1	27-28-11 / /	YC001-YC007
D02934 T	1	BACC10KD12 BACKSHELL-	81205	1	27-28-11 */**	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D02900

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02936	1	BACC45FT12-12P PLUG-BATTERY SENSOR	81205	1	24-31-11 392/162/L004	YC001-YC030, YK901-YM670
D02936 T	1	BACC10JC12 BACKSHELL	81205	1	24-31-11 / /	YC001-YC030, YK901-YK906
D02936 T	1	BACC10GH12 BACKSHELL	81205	1	24-31-11 / /	YK907-YM670
D02941	1	126-58-9 PLUG - ANGLE 90	91836	1	34-58-11 500A+15/306/L005	YC001-YC030, YK901-YM670
D02947	1	126-58-9 PLUG - ANGLE 90	91836	1	34-58-21 500A+5/306/R005	YC001-YL430
D02947	1	126-58-9 PLUG - ANGLE 90	91836	1	34-58-21 500A+5/316/R005	YM643-YM670
D02952	1	BACC45FT16-24S PLUG-	81205	1	73-21-12 P005-68/ /	YC001-YC030, YK901-YM670
D02968	1	AMC02PA03B PLUG-	05574	1	33-51-12 317/279/R037	ALL
D02970	1	48-7191 RCPT-	02660	1	33-51-12 269/274/L014	ALL
D02972	1	AMC02PA03B PLUG-	05574	1	33-51-12 327/285/L031	ALL
D02982	1	AMC02PA03B PLUG-	05574	1	33-51-12 971/288/L038	ALL
D02986	1	AMC02PA03B PLUG-	05574	1	33-51-14 972/283/R043	ALL
D02992	1	48-7190 PART OF ASSY 69-74399	02660	1	33-51-12 0270/284/L010	YC001-YL430
D02992	1	48-7190 PART OF ASSY 69-74399	02660	1	33-51-12 270/284/L010	YM643-YM670

EQUIPMENT LIST

D280A103

Section D02900
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03003	1	03-06-2122 PLUG-	27264	1	23-24-11 795/289/L010	ALL
D03020	1	BACC45FT18-8S PLUG-	81205	1	21-25-11 500D+9/164/R016	YM643-YM670
D03020 T	1	BACC10JS18 BACKSHELL-STRAIGHT	81205	1	21-25-11 */*/*	YM643-YM670
D03052	1	BACC63BP14A7S6 PLUG	81205	1	78-34-11 675/152/L012	YC001-YC030
D03052	1	BACC63BP14H7S6 PLUG	81205	1	78-34-11 675/152/L012	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03052 T	1	BACC10KD14 BACKSHELL	81205	1	78-34-11 672/152/L012	YC001-YC028
D03052 T	1	BACC10KF14 BACKSHELL	81205	1	78-34-11 672/152/L012	YC029-YC030
D03052 T	1	620AB049C14 BACKSHELL	81205	1	78-34-11 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03054	1	BACC63BP14A7SN PLUG	81205	1	78-36-11 673/152/L012	YC001-YC030
D03054	1	BACC63BP14H7SN PLUG	81205	1	78-36-11 673/152/L012	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03054 T	1	BACC10KD14 BACKSHELL	81205	1	78-36-11 670/152/L012	YC001-YC028
D03054 T	1	BACC10KF14 BACKSHELL	81205	1	78-36-11 670/152/L012	YC029-YC030
D03054 T	1	620AB049C14 BACKSHELL	81205	1	78-36-11 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D03000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03056	1	BACC63BP14A7S6 PLUG-	81205	1	78-34-21 675/152/R012	YC001-YC030
D03056	1	BACC63BP14H7S6 PLUG-	81205	1	78-34-21 675/152/R012	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03056 T		BACC10KD14 BACKSHELL-	81205	1	78-34-21 / /	YC001-YC028
D03056 T		BACC10KE14 BACKSHELL-	81205	1	78-34-21 */**	YC029-YC030
D03056 T		M85049-51S14A BACKSHELL-	81205	1	78-34-21 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03058	1	BACC63BP14A7SN PLUG	81205	1	78-36-21 677/152/R012	YC001-YC030
D03058	1	BACC63BP14H7SN PLUG	81205	1	78-36-21 677/152/R012	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03058 T		BACC10KD14 BACKSHELL-	81205	1	78-36-21 / /	YC001-YC028
D03058 T		BACC10KE14 BACKSHELL-	81205	1	78-36-21 */**	YC029-YC030
D03058 T		M85049-51S14A BACKSHELL-	81205	1	78-36-21 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03072	1	BACS16X1A PLUG-	81205	1	33-25-11 P005-00/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D03000
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03116	1	BACC45FT12-12S6 PLUG-AILERON/RUDDER TRIM CONT MOD	81205	1	27-21-11 P008-43/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03116 T	1	BACC10JS12 BACKSHELL-	81205	1	27-21-11 / /	YC001-YC007
D03116 T	1	BACC10JS12 BACKSHELL-	81205	1	27-21-11 */**	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03124	1	BACC45FT12-12S PLUG-F/O COLUMN SWITCHING MODULE	81205	1	27-41-11 200/198/R13	YC001-YC007
D03124	1	BACC45FT12-12S PLUG-F/O COLUMN SWITCHING MODULE	81205	1	27-41-11 200/198/R013	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03124 T	1	BACC10JS12 BACKSHELL-	81205	1	27-41-11 / /	YC001-YC007
D03124 T	1	BACC10JS12 BACKSHELL-	81205	1	27-41-11 */**	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03160	1	S280W557-121 PLUG-	81205	1	33-27-11 305/290/R003	YC001-YC026
D03160	1	BACC65AJ121S PLUG-	81205	1	33-27-11 305/290/R003	YC028-YM670
D03172	1	BACC45FT16-24S6 PLUG-	81205	1	73-21-12 P005-68/ /	YC001-YC030, YK901-YM670
D03188	1	BACC63BP10C5SN PLUG-	81205	1	27-83-11 642/162/R047	ALL
D03188 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	27-83-11 */**	ALL
D03190	1	BACC63BP10C5SN PLUG-	81205	1	27-83-21 642/161/R053	ALL

EQUIPMENT LIST

D280A103

Section D03100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03190 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	27-83-21 */*/*	ALL

EQUIPMENT LIST

D280A103

Section D03100
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03228	1	BACC66F11C40AA01 PLUG	81205	1	77-31-21 E003-02/ /	ALL
D03228 T	1	S280W601-116 BACKSHELL-	81205	1	77-31-21 E003-02/*/*	YC001-YC050
D03228 T	1	S280W601-116 BACKSHELL-	81205	1	77-31-21 */*/*	YK901-YM670
D03228A	1	PARTAOFD03228 PLUG		1	77-31-21 E003-02/ /	YC001-YC050
D03228A	1	PARTAOFD03228 PLUG		1	77-31-21 */*/*	YK901-YM670
D03228B	1	PARTBOFD03328 PLUG		1	77-31-21 E003-02/ /	YC001-YC050
D03228B	1	PARTBOFD03328 PLUG		1	77-31-21 */*/*	YK901-YM670
D03228C	1	PARTCOFD03228 PLUG-ENG VIB SIGNAL COND		1	77-31-21 E003-02/ /	YC001-YC050
D03228C	1	PARTCOFD03228 PLUG-ENG VIB SIGNAL COND		1	77-31-21 */*/*	YK901-YM670
D03242	1	BACC63BP12C3S8 PLUG	81205	1	29-25-11 667/179/R031	YC001-YC030
D03242	1	BACC63BP12H3S8 PLUG	81205	1	29-25-11 667/179/R031	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03242 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	29-25-11 / /	YC001-YC028
D03242 T	1	BACC10KE12 BACKSHELL-CONDUCTIVE	81205	1	29-25-11 */*/*	YC029-YC030
D03242 T	1	M85049-51S12A BACKSHELL-CONDUCTIVE	81205	1	29-25-11 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03244	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	29-25-11 664/150/L009	YC001-YC030

EQUIPMENT LIST

D280A103

Section D03200

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03244	1	BACC63BP16H10SN PLUG-CONDUCTIVE	81205	1	29-25-11 664/150/L009	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03244 T	1	BACC10KE16 BACKSHELL- CONDUCTIVE	81205	1	29-25-11 TBD/ /	YC001-YC007
D03244 T	1	BACC10KE16 BACKSHELL- CONDUCTIVE	81205	1	29-25-11 664/ /	YC008-YC028
D03244 T	1	BACC10KE16 BACKSHELL- CONDUCTIVE	81205	1	29-25-11 */**	YC029-YC030
D03244 T	1	M85049-51S16A BACKSHELL- CONDUCTIVE	81205	1	29-25-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03254	1	BACS16W5A SOCKET-HYD SYS B EDP RLY R353	81205	1	29-25-11 J011-00/ /	ALL
D03261	1	BACC66H21C04AA01 PLUG PLATE ASSY-FMC NO.2	81205	1	34-61-11 E005-02/ /	ALL
D03261A	1	PARTAOFD03261 PLUG FMC NO.2		1	34-61-11 E005-02/ /	ALL
D03261B	1	PARTBOFD03261 PLUG FMC NO.2		1	34-61-11 E005-02/ /	ALL
D03261C	1	PARTCOFD03261 PLUG FMC NO.2		1	34-61-11 E005-02/ /	ALL
D03263	1	MS3126F20-41S PLUG-FMCS XFER RELAY NO. 1	96906	1	34-61-12 E005-02/ /	ALL
D03265	1	MS3126F20-41SW PLUG-FMC XFER RELAY NO.1	96906	1	34-61-11 E005-02/ /	ALL
D03267	1	MS3126F20-41SX PLUG-FMCS XFER RELAY NO. 1	96906	1	34-61-11 E005-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D03200
Page 2 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03309	1	2436-81-1 PLUG - (TNC) ANGLED 90 (42 DEG KEY)	91836	1	34-31-11 178/210/R014	ALL
D03311	1	2436-81-6 PLUG - (TNC) ANGLED 90 (102 DEG KEY)	91836	1	34-31-21 178/210/R010	ALL
D03313	1	2436-81-1 PLUG - (TNC) ANGLED 90 (42 DEG KEY)	91836	1	34-31-11 178/188/L015	ALL
D03315	1	2436-81-6 PLUG - (TNC) ANGLED 90 (102 DEG KEY)	91836	1	34-31-21 178/190/L014	ALL
D03317	1	2436-81-1 PLUG - (TNC) ANGLED 90 (42 DEG KEY)	91836	1	34-31-11 178/212/R014	ALL
D03319	1	2436-81-6 PLUG - (TNC) ANGLED 90 (102 DEG KEY)	91836	1	34-31-21 178/212/R010	ALL
D03321	1	2435-81-1 PLUG - (TNC) STRAIGHT (42 DEG KEY)	91836	1	34-31-11 179/188/L015	ALL
D03323	1	2435-81-6 PLUG - (TNC) STRAIGHT (102 DEG KEY)	91836	1	34-31-21 178/191/L014	ALL

EQUIPMENT LIST

D280A103

Section D03300

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03423	1	MS3126F20-41S PLUG-FMC XFER NO.2	96906	1	34-61-12 E005-02/ /	ALL
D03425	1	MS3126F20-41SW PLUG-FMC XFER RELAY NO.2	96906	1	34-61-12 E005-02/ /	ALL
D03427	1	MS3126F20-41SX PLUG-FMC XFER RELAY NO.2	96906	1	34-61-12 E005-02/ /	ALL
D03428	1	BACC45FT16-24S PLUG-STAB TRIM & CAB DOOR MODULE	81205	1	52-51-11 P008-47/ /	YC001-YC030
D03428	1	BACC45FT16-24S7 PLUG-STAB TRIM & CAB DOOR MODULE	81205	1	52-51-11 P008-47/ /	YK901-YM670
D03428 T	1	BACC10GH16 BACKSHELL	81205	1	52-51-11 */*/*	YC001-YC002, YC008-YC030, YK901-YM670
D03432	1	BACC45FT16-10S PLUG-FLOOD AND PANEL LIGHTING MODULE	81205	1	33-11-41 P008-50/ /	YC001-YC030, YK901-YM670
D03432 T	1	BACC10JS16 BACKSHELL-	81205	1	33-11-41 */*/*	YC001-YC030, YK901-YM670
D03464	1	BACC45FT12-12S PLUG-LOW FLOW SNSR	81205	1	21-27-31 213/191/R25	ALL
D03464 T	1	BACC10JC12 BACKSHELL-90 DEGREE	81205	1	21-27-31 / /	YC001-YC030, YK901-YK905
D03464 T	1	BACC10JC12 BACKSHELL-90 DEGREE	81205	1	21-27-31 */*/*	YC031-YC050, YK906-YM670
D03470	1	BACC45FT14-7S PLUG-	81205	1	21-27-31 370/191/R50	ALL
D03470 T	1	450EB001C14-347 BACKSHELL-45 DEGREE	81205	1	21-27-31 */*/*	ALL
D03472	1	BACC45FT14-7S PLUG-	81205	1	21-27-31 368/184/R050	ALL
D03472 T	1	450EB001C14-347 BACKSHELL	81205	1	21-27-31 368/184/R050	ALL

EQUIPMENT LIST

D280A103

Section D03400

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03524	1	BACC45FN12-12P RCPT	81205	1	27-41-11 P8/ /	ALL
D03524 T	1	BACC10JS12 BACKSHELL	81205	1	27-41-11 / /	ALL
D03527	1	BACS16X1A RELAY SOCKET	81205	1	78-32-51 J022-00/ /	ALL
D03529	1	BACS16X1A SOCKET-	81205	1	78-32-61 J00024/ /	ALL
D03572	1	BACC63CB10-5SN PLUG-AILERON POS XMTR LEFT	81205	1	27-18-11 ORSS/540/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03572 T	1	BACC10KF10 BACKSHELL, 45 DEGREE	81205	1	27-18-11 / /	YC001-YK906, YM643-YM652
D03572 T	1	BACC10KF10 BACKSHELL, 45 DEGREE	81205	1	27-18-11 */ /	YK907-YK912, YK918-YK919, YL401-YL429
D03574	1	BACC63CB10-5SN PLUG-AILERON POS XMTR RIGHT	81205	1	27-18-11 ORSS/540/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03574 T	1	BACC10KF10 BACKSHELL, 45 DEGREE	81205	1	27-18-11 */ */	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03576	1	BACC63CB10-5SN PLUG-RUDDER POSITION XMTR	81205	1	27-28-11 RUD80/ /	ALL
D03576 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	27-28-11 / /	YC001-YC030
D03576 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	27-28-11 */ */	YC031-YM670
D03578	1	BACC63CB10-5SN PLUG-L ELEV POS XMTR	81205	1	27-38-11 1168/278/L032	ALL
D03578 T	1	BACC10KE10 BACKSHELL, 90 DEGREE	81205	1	27-38-11 */ */	ALL

EQUIPMENT LIST

D280A103

Section D03500

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03580	1	BACC63CB10-5SN PLUG-R ELEV POS XMTR	81205	1	27-38-11 1167/278/R32	YC001-YC016
D03580	1	BACC63CB10-5SN PLUG-R ELEV POS XMTR	81205	1	27-38-11 1167/278/R032	YC017-YM670
D03580 T	1	BACC10KE10 BACKSHELL, 90 DEGREE	81205	1	27-38-11 */**	YC001-YC016
D03580 T	1	BACC10KE10 BACKSHELL, 90 DEGREE	81205	1	27-38-11 * **/**	YC017-YM670
D03599	1	BACC66F11F22AA01 PLUG PLATE ASSY	81205	1	49-62-51 902/197/R046	YC001-YK912, YK918-YK919, YL401-YL429
D03599	1	BACC66F11F22AA01 PLUG PLATE ASSY	81205	1	49-62-51 E006/ /	YM643-YM652
D03599 T	1	S280W601-116 GROUND-48	81205	1	49-62-51 / /	YC001-YC007
D03599 T	1	S280W601-116 GROUND-48	81205	1	49-62-51 */**	YC008-YC026, YM643-YM652
D03599 T	1	S280W601-116 GROUND-48	81205	1	49-62-51 1082/197/R046	YC028-YK912, YK918-YK919, YL401-YL429
D03599A	1	PARTAOFD03599 PLUG-		1	49-62-51 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03599B	1	PARTBOFD03599 PLUG-		1	49-62-51 */**	YC001-YC030, YM643-YM652
D03599B	1	PARTBOFD03599 PLUG-		1	49-62-51 880/177/R033	YC031-YK912, YK918-YK919, YL401-YL429
D03599C	1	PARTCOFD03599 PLUG-		1	49-62-51 */**	YC001-YC030, YM643-YM652
D03599C	1	PARTCOFD03599 PLUG-		1	49-62-51 880/175/R033	YC031-YK912, YK918-YK919, YL401-YL429

EQUIPMENT LIST

D280A103

Section D03500
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03623	1	BACC66F11F02AE01 PLUG PLATE ASSEMBLY - VOR/MB -1	81205	1	34-51-11 E001-02/ /	YC001-YC030, YK901-YM670
D03623 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	34-51-11 E001-02/ /	YC001-YC030
D03623 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	34-51-11 */*/*	YK901-YM670
D03623A	1	PARTAOFD03623 PLUG PLATE ASSEMBLY - VOR/MB -1		0	34-51-11 E001-02/ /	YC001-YC030
D03623A	1	PARTAOFD03623 PLUG PLATE ASSEMBLY - VOR/MB -1		0	34-51-11 */*/*	YK901-YM670
D03623B	1	PARTBOFD03623 PLUG PLATE ASSEMBLY - VOR/MB -1		0	34-51-11 E001-02/ /	YC001-YC030
D03623B	1	PARTBOFD03623 PLUG PLATE ASSEMBLY - VOR/MB -1		0	34-51-11 */*/*	YK901-YM670
D03623C	1	PARTCOFD03623 PLUG PLATE ASSEMBLY - VOR/MB -1		0	34-51-11 E001-02/ /	YC001-YC030
D03623C	1	PARTCOFD03623 PLUG PLATE ASSEMBLY - VOR/MB -1		0	34-51-11 */*/*	YK901-YM670
D03625	1	BACC66F11F02AE01 PLUG PLATE ASSEMBLY	81205	1	34-51-21 E001-04/ /	ALL
D03625A	1	PARTAOFD03625 PLUG - VOR - 2		0	34-51-21 E001-04/ /	YC001-YL430
D03625A	1	PARTAOFD03625 PLUG - VOR - 2		0	34-51-21 */*/*	YM643-YM670
D03625B	1	PARTBOFD03625 PLUG - VOR - 2		0	34-51-21 E001-04/ /	YC001-YL430
D03625B	1	PARTBOFD03625 PLUG - VOR - 2		0	34-51-21 */*/*	YM643-YM670
D03625C	1	PARTCOFD03625 PLUG - VOR - 2		0	34-51-21 E001-04/ /	YC001-YL430
D03625C	1	PARTCOFD03625 PLUG - VOR - 2		0	34-51-21 */*/*	YM643-YM670
D03651	1	BACC66F11F05AA01 PLUG PLATE ASSY	81205	1	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D03600

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03651 T	1	S280W601-116 GND - BLOCK 48	81205	1	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670
D03651A	1	PARTAOFD03651 PLUG - RCVR-ADF 1		0	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670
D03651B	1	PARTBOFD03651 PLUG - RCVR-ADF 1		0	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670
D03651C	1	PARTCOFD03651 PLUG - RCVR-ADF 1		0	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670
D03653	1	BACC66F11F05AA01 PLUG PLATE ASSY	81205	1	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D03653 T	1	S280W601-116 GND - BLOCK 48	81205	1	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D03653A	1	PARTAOFD03653 PLUG - RCVR-ADF 2		0	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D03653B	1	PARTBOFD03653 PLUG - RCVR-ADF 2		0	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D03653C	1	PARTCOFD03653 PLUG - RCVR-ADF 2		0	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D03655	1	BACC63CB16-24S6 PLUG	81205	1	34-57-11 P008-00/ /	ALL
D03655 T	1	BACC10KD16 BACKSHELL-ADF CP-1	81205	1	34-57-11 P008-00/ /	ALL
D03657	1	BACC63CB16-24S6 PLUG	81205	1	34-57-21 P008-00/ /	ALL
D03657 T	1	BACC10KD16 BACKSHELL-(PROV) ADF CP-2	81205	1	34-57-21 P008-00/ /	ALL
D03658	1	48-7191 RCPT-	02660	1	33-51-21 290/225/R053	ALL
D03660	1	48-7190 PLUG-	02660	1	33-51-21 290/225/R052	ALL
D03662	1	48-7191 RCPT-	02660	1	33-51-21 301/226/L048	ALL
D03663	1	BACC63CB20-16SN PLUG	81205	1	34-57-11 685+9/306/R5	YC001-YC007

EQUIPMENT LIST

D280A103

Section D03600

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03663	1	BACC63CB20-16SN PLUG	81205	1	34-57-11 694/306/R005	YC008-YM670
D03663 T	1	BACC10KD20 BACKSHELL-ADF ANT-1	81205	1	34-57-11 694/ /R4.8	ALL
D03664	1	48-7190 PLUG-	02660	1	33-51-21 302/226/L047	ALL
D03665	1	BACC63CB20-16SN PLUG	81205	1	34-57-21 727A+9/305/R005	ALL
D03665 T	1	BACC10KD20 BACKSHELL-ADF ANT -2	81205	1	34-57-21 */*/*	ALL
D03666	1	48-7191 RCPT-	02660	1	33-51-21 613/224/R072	YC001-YL430
D03666	1	48-7191 RCPT-	02660	1	33-51-21 609/231/R072	YM643-YM670
D03667	1	BACC66H123F01AK01 PLUG PLATE ASSY	81205	1	34-33-11 E003-01/ /	YC001-YC030, YK901-YM670
D03667 T	1	S280W601-116 GND - BLOCK 48	81205	1	34-33-11 E003-01/ /	YC001-YC030, YK901-YM670
D03667 U	1	BACC47EN4A COAX ADAPTER	81205	1	34-33-11 E003-01/ /	YC001-YC030, YK901-YM670
D03667 V	1	BACC47EN4A COAX ADAPTER	81205	1	34-33-11 E003-01/ /	YC001-YC030, YK901-YM670
D03667A	1	PARTAOFD03667 PLUG - XCVR-RADIO ALTM-1		0	34-33-11 E003-01/ /	YC001-YC030, YK901-YM670
D03667AU	1	125-91-9 PLUG - (TNC) STRAIGHT - XCVR -1	91836	1	34-33-11 E003-01/ /	ALL
D03667B	1	PARTBOFD03667 PLUG - XCVR-RADIO ALTM-1		0	34-33-11 E003-01/ /	YC001-YC030, YK901-YM670
D03667BU	1	125-91-9 PLUG - (TNC) STRAIGHT - XCVR -1	91836	1	34-33-11 E003-01/ /	ALL
D03667C	1	PARTCOFD03667 PLUG - XCVR-RADIO ALTM-1		0	34-33-11 E003-01/ /	YC001-YC030, YK901-YM670
D03668	1	48-7190 PLUG-	02660	1	33-51-21 614/224/R067	YC001-YL430

EQUIPMENT LIST

D280A103

Section D03600

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03668	1	48-7190 PLUG-	02660	1	33-51-21 609/231/R072	YM643-YM670
D03669	1	BACC66H123F01AK01 PLUG PLATE ASSY - RADIO ALTM XCVR-2	81205	1	34-33-21 E003-02/ /	ALL
D03669 T	1	S280W601-116 BACKSHELL-	81205	1	34-33-21 E003-02/*/*	YC001-YC050
D03669 T	1	S280W601-116 BACKSHELL-	81205	1	34-33-21 */*/*	YK901-YM670
D03669A	1	PARTAOFD03669 PLUG-RADIO ALTM XCVR-2		1	34-33-21 E003-02/ /	YC001-YC050
D03669A	1	PARTAOFD03669 PLUG-RADIO ALTM XCVR-2		1	34-33-21 */*/*	YK901-YM670
D03669AT	1	BACC47EN4A CONTACT-(COAX)SIZE 1 - PLUG - XCVR - 2	81205	1	34-33-21 E003-02/*/*	YC001-YC050
D03669AT	1	BACC47EN4A CONTACT-(COAX)SIZE 1 - PLUG - XCVR - 2	81205	1	34-33-21 */*/*	YK901-YM670
D03669AU	1	125-91-9 PLUG - (TNC) STRAIGHT - XCVR -2	91836	1	34-33-21 E003-02/ /	ALL
D03669B	1	PARTBOFD03669 PLUG-RADIO ALTM XCVR-2		1	34-33-21 E003-02/ /	YC001-YC050
D03669B	1	PARTBOFD03669 PLUG-RADIO ALTM XCVR-2		1	34-33-21 */*/*	YK901-YM670
D03669BT	1	BACC47EN4A CONTACT-(COAX)SIZE 1 - PLUG - XCVR - 2	81205	1	34-33-21 E003-02/*/*	ALL
D03669BU	1	125-91-9 PLUG-(TNC) STRAIGHT - XCVR -1	91836	1	34-33-21 E003-02/ /	ALL
D03669C	1	PARTCOFD03669 PLUG-RADIO ALTM XCVR-2		1	34-33-21 E003-02/ /	YC001-YC050
D03669C	1	PARTCOFD03669 PLUG-RADIO ALTM XCVR-2		1	34-33-21 */*/*	YK901-YM670
D03670	1	48-7191 RCPT-	02660	1	33-51-21 614/225/L070	YC001-YC030, YK901-YM652
D03671	1	126-59-9 PLUG-RADIO ALTM XMTR ANTENNA -1	91836	1	34-33-11 450/150/000	ALL

EQUIPMENT LIST

D280A103

Section D03600

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03672	1	48-7190 PLUG-	02660	1	33-51-21 614/225/L070	YC001-YC030, YK901-YM652
D03673	1	126-59-9 PLUG-RADIO ALTM XMTR ANTENNA -2	91836	1	34-33-21 390/150/000	ALL
D03675	1	126-59-9 PLUG-RADIO ALTM RCVER ANTENNA -1	91836	1	34-33-11 430/150/000	ALL
D03677	1	126-59-9 PLUG-RADIO ALTM RCVR ANTENNA -2	91836	1	34-33-21 410/150/000	ALL
D03679	1	BACC45FT22-55S6 PLUG	81205	1	34-22-11 190/230/L5.3	YC001-YC030
D03679	1	BACC45FT22-55S6 PLUG	81205	1	34-22-11 190/230/L005	YK901-YM670
D03679 T	1	BACC10JS22 CLAMP	81205	1	34-22-11 P002-01/ /	YC001-YC030
D03679 T	1	BACC10JS22 CLAMP	81205	1	34-22-11 */**	YK901-YM670
D03681	1	BACC63CB16-24S6 PLUG - CONDUCTIVE	81205	1	34-24-11 190/236/L5.5	YC001-YC030
D03681 T	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	34-24-11 P002-01/ /	YC001-YC030
D03683	1	DPX2MA-D106PD106P-33B-0001 PLUG PLATE ASSY	71468	1	22-23-11 E003-02/ /	ALL
D03683A	1	PARTAOFD03683 PLUG		1	22-23-11 E003-02/ /	YC001-YC050
D03683A	1	PARTAOFD03683 PLUG		1	22-23-11 */**	YK901-YM670
D03683B	1	PARTBOFD03683 PLUG		1	22-23-11 E003-02/ /	YC001-YC050
D03683B	1	PARTBOFD03683 PLUG		1	22-23-11 */**	YK901-YM670
D03685	1	DPX2MA-D106PD106P-33B-0001 PLUG PLATE ASSY	71468	1	22-11-14 E003-02/ /	ALL
D03685A	1	PARTAOFD03685 PLUG		1	22-11-14 E003-02/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section D03600

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03685A	1	PARTAOFD03685 PLUG		1	22-11-14 */**	YK901-YM670
D03685B	1	PARTBOFD03685 PLUG		1	22-11-14 E003-02/ /	YC001-YC050
D03685B	1	PARTBOFD03685 PLUG		1	22-11-14 */**	YK901-YM670
D03687	1	BACC66H21C06AA01 PLUG PLATE ASSY - ADIRU LEFT	81205	1	34-21-11 E005-02/ /	ALL
D03687 T		S280W601-116 GND - BLOCK 48	81205	1	34-21-11 E005-02/ /	YC001-YC011
D03687 T		S280W601-116 GND - BLOCK 48	81205	1	34-21-11 */**	YC012-YM670
D03687A	1	PARTAD03687 PLUG - ADIRU LEFT		1	34-21-11 E005-02/ /	YC001-YC011, YK901-YM670
D03687A	1	PARTAD03687 PLUG - ADIRU LEFT		1	34-21-11 */**	YC012-YC050
D03687B	1	PARTBD03687 PLUG - ADIRU LEFT		1	34-21-11 E005-02/ /	YC001-YC011, YK901-YM670
D03687B	1	PARTBD03687 PLUG - ADIRU LEFT		1	34-21-11 */**	YC012-YC050
D03687C	1	PARTCD03687 PLUG - ADIRU LEFT		1	34-21-11 E005-02/ /	YC001-YC011, YK901-YM670
D03687C	1	PARTCD03687 PLUG - ADIRU LEFT		1	34-21-11 */**	YC012-YC050
D03689	1	BACC63CB16-24SN PLUG - AIR DATA MODULE - L - PITOT	81205	1	34-21-22 199/177/L14	YC001-YC006
D03689	1	BACC63CB16-24SN PLUG - AIR DATA MODULE - L - PITOT	81205	1	34-21-22 200/177/L14	YC007-YM670
D03689 T	1	S280W603-307 BACKSHELL-CONDUCTIVE	81205	1	34-21-22 */**	ALL
D03691	1	BACC63CB16-24SN PLUG - AIR DATA MODULE-L - STATIC	81205	1	34-21-12 408/205/.35	ALL
D03691 T	1	S280W603-107 BACKSHELL-CONDUCTIVE	81205	1	34-21-12 / /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D03600

Page 6

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03691 T	1	S280W603-107 BACKSHELL-CONDUCTIVE	81205	1	34-21-12 */*/*	YC008-YM670
D03693	1	BACC66H21C06AA01 PLUG PLATE ASSY - ADIRU RIGHT	81205	1	34-21-21 E005-02/ /	ALL
D03693 T		S280W601-116 GND - BLOCK 48	81205	1	34-21-21 E005-02/ /	YC001-YC050
D03693 T		S280W601-116 GND - BLOCK 48	81205	1	34-21-21 */*/*	YK901-YM670
D03693A	1	PARTAD03693 PLUG - ADIRU RIGHT		1	34-21-21 E005-02/ /	ALL
D03693B	1	PARTBD03693 PLUG - ADIRU RIGHT		1	34-21-21 E005-02/ /	ALL
D03693C	1	PARTCD03693 PLUG - ADIRU RIGHT		1	34-21-21 E005-02/ /	ALL
D03695	1	BACC63CB16-24SN PLUG - AIR DATA MODULE - R - PITOT	81205	1	34-21-22 200.618/177/17.6	YC001-YC006
D03695	1	BACC63CB16-24SN PLUG - AIR DATA MODULE - R - PITOT	81205	1	34-21-22 201/177/R18	YC007-YM652
D03695 T	1	S280W603-107 BACKSHELL-CONDUCTIVE	81205	1	34-21-22 */*/*	YC001-YM652
D03697	1	BACC63CB16-24SN PLUG - AIR DATA MODULE-R - STATIC	81205	1	34-21-22 430/205/L002	ALL
D03697 T	1	S280W603-107 BACKSHELL-CONDUCTIVE	81205	1	34-21-22 */*/*	ALL
D03699	1	1206-22-9 PLUG -	91836	1	34-51-11 302/180/R20	YC001-YC007
D03699	1	1206-22-9 PLUG -	91836	1	34-51-11 302/180/R020	YC008-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D03600

Page 7 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03732	1	BACC45FT24-43S PLUG-LAV A	81205	1	33-26-31 298/288/L010	ALL
D03732 T	1	BACC10JS24 BACKSHELL-	81205	1	33-26-31 */**	ALL
D03738	1	BACC45FT24-43S PLUG-LAV D	81205	1	33-26-31 937/289/L018	ALL
D03738 T	1	BACC10JC24 BACKSHELL-	81205	1	33-26-31 */**	ALL
D03740	1	BACC45FT24-43S PLUG-LAV E	81205	1	33-26-31 937/289/R018	ALL
D03740 T	1	BACC10JC24 BACKSHELL-	81205	1	33-26-31 */**	ALL
D03768	1	BACS16W2A RELAY SOCKET	81205	1	33-11-33 245/205/R02	YC001-YC030, YK901-YM670
D03779	1	125-88-9 PLUG -	91836	1	34-31-11 303/178/R020	ALL
D03781	1	126-58-9 PLUG -	91836	1	34-51-11 302/178/R020	YC001-YC030
D03781	1	126-58-9 PLUG -	91836	1	34-51-11 E001-02/ /	YK901-YM670
D03783	1	1206-22-9 PLUG -	91836	1	34-51-21 308/180/R20	ALL
D03784	1	172168-1 PLUG-	00779	1	33-21-12 417/271/R054	ALL
D03785	1	125-88-9 PLUG -	91836	1	34-31-21 309/178/R020	ALL
D03786	1	172160-1 RCPT-	00779	1	33-21-12 422/271/R054	YC001-YL430
D03786	1	172160-1 RCPT-	00779	1	33-21-12 420/271/R054	YM643-YM670
D03787	1	126-58-9 PLUG -	91836	1	34-51-21 308/178/R020	YC001-YC050, YM643-YM670
D03787	1	126-58-9 PLUG -	91836	1	34-51-21 E001-04/ /	YK901-YL430

EQUIPMENT LIST

D280A103

Section D03700

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03788	1	172168-1 PLUG-	00779	1	33-21-12 639/269/R058	YM643-YM670
D03790	1	172160-1 RCPT-	00779	1	33-21-12 643/271/R56	YM643-YM670
D03792	1	172168-1 PLUG-	00779	1	33-21-12 863/271/R055	ALL
D03794	1	172160-1 RCPT-	00779	1	33-21-12 867/271/R055	ALL
D03796	1	172160-1 RCPT-	00779	1	33-21-12 418/271/L054	ALL
D03798	1	172168-1 PLUG-	00779	1	33-21-12 422/271/L054	ALL

EQUIPMENT LIST

D280A103

Section D03700

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03800	1	BACC63CD24-22S RCPT-	81205	1	25-31-11 998/295/R025	ALL
D03802	1	BACC45FN14-7S RCPT-	81205	1	33-25-22 1000/295/R024	ALL
D03846	1	172160-1 RCPT-	00779	1	33-21-12 639/269/L058	YM643-YM670
D03848	1	172168-1 PLUG-	00779	1	33-21-12 645/271/L056	YM643-YM670
D03850	1	172160-1 RCPT-	00779	1	33-21-12 865/271/L55	ALL
D03852	1	172168-1 PLUG-	00779	1	33-21-12 870/271/L55	ALL
D03854	1	BACC45FT18-8S PLUG-	81205	1	21-25-11 525/165/R018	YC001-YL430
D03854 T	1	BACC10JC18 BACKSHELL-90 DEGREE	81205	1	21-25-11 */*/*	YC001-YL430
D03856	1	BACC45FT18-8S PLUG-	81205	1	21-25-11 500I+7/165/L018	YC001-YL430
D03856 T	1	BACC10JC18 BACKSHELL-90 DEGREE	81205	1	21-25-11 */*/*	YC001-YL430
D03858	1	BACC66F11C20AA PLUG PLATE ASSY-	81205	1	21-51-12 E003-03/ /	YC001-YL430
D03858A	1	PARTAOFD03858 PLUG-		0	21-51-12 E003-03/ /	YC001-YL430
D03858B	1	PARTBOFD03858 PLUG-		0	21-51-12 E003-03/ /	YC001-YL430
D03858C	1	PARTCOFD03858 PLUG-		0	21-51-12 E003-03/ /	YC001-YL430
D03860	1	BACC66F11C20AA PLUG PLATE ASSY-	81205	1	21-51-22 E003-03/ /	YC001-YL430
D03860A	1	PARTAOFD03860 PLUG-		0	21-51-22 E003-03/ /	YC001-YL430
D03860B	1	PARTBOFD03860 PLUG-		0	21-51-22 E003-03/ /	YC001-YL430

EQUIPMENT LIST

D280A103

Section D03800

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03860C	1	PARTCOFD03860 PLUG-		0	21-51-22 E003-03/ /	YC001-YL430
D03862	1	BACC63CB14-15S PLUG-	81205	1	21-51-12 645/146/L013	YC001-YL430
D03862 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-12 */**	YC001-YL430
D03864	1	BACC63BN10-5SN PLUG-	81205	1	21-51-13 646/154/L035	YC001-YL430
D03864 T	1	MS27559-2 BAKCHELL-90 DEGREE	96906	1	21-51-13 */**	YC001-YL430
D03866	1	BACC63BN10-5SN PLUG-	81205	1	21-51-12 573/154/L030	YC001-YL430
D03866 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	21-51-12 */**	YC001-YL430
D03868	1	BACC45FT10-20S PLUG	81205	1	21-51-12 500I+7/192/L003	YC001-YL430
D03872	1	BACC63CB14-15SN PLUG-	81205	1	21-51-22 644/148/R013	YC001-YL430
D03872 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-22 */**	YC001-YL430
D03874	1	BACC63BN10-5SN PLUG-	81205	1	21-51-23 646/151/R035	YC001-YL430
D03874 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	21-51-23 */**	YC001-YL430
D03876	1	BACC63BN10-5SN PLUG-	81205	1	21-51-22 573/154/R030	YC001-YL430
D03876 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	21-51-22 */**	YC001-YL430
D03878	1	BACC45FT10-20S PLUG-	81205	1	21-51-22 500I+7/194/R004	YC001-YL430
D03882	1	BACC45FT10-20S PLUG-	81205	1	21-61-12 372/195/L055	YC001-YC030, YK901-YL430
D03882 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	1	21-61-12 */**	YC001-YC030, YK901-YL430

EQUIPMENT LIST

D280A103

Section D03800

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03884	1	BACC45FT10-20S PLUG-	81205	1	21-61-11 372/196/L057	YC001-YC030, YK901-YL430
D03884 T	1	BACC10JC10 BACKSHELL- 90 DEGREE	81205	1	21-61-11 */*/*	YC001-YC030, YK901-YL430
D03886	1	BACC63CB14-15SN PLUG-	81205	1	21-61-11 542/157/L13	YC001-YL430
D03886 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-61-11 */*/*	YC001-YL430
D03888	1	BACC63CB14-15S PLUG-	81205	1	21-61-13 539/152/R012	YC001-YL430
D03888 T	1	BACC10KF14 BACKSHELL-45 DEGREE	81205	1	21-61-13 */*/*	YC001-YL430
D03890	1	BACC63CB14-15SN PLUG-	81205	1	21-61-14 548/153/R017	YC001-YL430
D03890 T	1	BACC10KD14 BACKSHELL-STRAIGHT	81205	1	21-61-15 */*/*	YC001-YC030
D03890 T	1	BACC10KF14 BACKSHELL-45 DEGREE	81205	1	21-61-15 */*/*	YC031-YL430
D03892	1	BACC45FT10-5S PLUG-	81205	1	21-61-11 373/194/L058	YC001-YC030, YK901-YL430
D03892 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	1	21-61-11 */*/*	YC001-YC030, YK901-YL430

EQUIPMENT LIST

D280A103

Section D03800
Page 3 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03906	1	BACC45FT10-5S PLUG-	81205	1	21-61-13 408/273/R28	YC001-YL430
D03908	1	BACC45FT8-3S PLUG-	81205	1	21-61-13 416/274/R031	YC001-YL430
D03910	1	BACC45FT10-5S PLUG-	81205	1	21-61-14 MULTI/ /	YC001-YL430
D03912	1	BACC45FT8-3S PLUG-	81205	1	21-61-14 MULTI/ /	YC001-YL430
D03914	1	BACC63BN10-5S6 PLUG-	81205	1	21-61-15 557/147/R014	YC001-YL430
D03914 T	1	MS27559-2 BACKSHELL-90 DEGREE	96906	1	21-61-15 */**	YC001-YL430
D03916	1	BACC63CB10-20SN PLUG-	81205	1	21-51-14 584/162/L032	YC001-YL430
D03916 T	1	BACC10KF10 BACKSHELL-45 DEGREE	81205	1	21-51-14 */**	YC001-YL430
D03918	1	BACC63CB10-20SN PLUG-	81205	1	21-51-24 584/162/R032	YC001-YL430
D03918 T	1	BACC10KE10 BACKSHELL-45 DEGREE	81205	1	21-51-24 */**	YC001-YC030
D03918 T	1	BACC10KF10 BACKSHELL-45 DEGREE	81205	1	21-51-24 */**	YC031-YL430
D03920	1	017832-3000 PLUG-	58795	1	21-61-51 410/273/R27	YC001-YL430
D03922	1	017832-3000 PLUG-	58795	1	21-61-14 MULTI/ /	YC001-YL430
D03924	1	BACC63CE12S-3S PLUG-	81205	1	21-61-51 371/194/L058	YC001-YC030, YK901-YL430
D03924 T	1	BACC10HW12 BACKSHELL-90 DEGREE	81205	1	21-61-51 */**	YC001-YC030, YK901-YL430
D03930	1	BACC63CE12S-3S PLUG-	81205	1	21-61-51 573/152/L033	YC001-YL430
D03930 T	1	BACC10HV12 BACKSHELL-STRAIGHT	81205	1	21-61-51 */**	YC001-YL430

EQUIPMENT LIST

D280A103

Section D03900

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03940	1	BACC63CB10-20SN PLUG-	81205	1	21-51-15 520/160/L017	YC001-YC007
D03940	1	BACC63CB10-2ASN PLUG-	81205	1	21-51-15 520/160/L017	YC008-YC030, YK901-YL430
D03940 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	21-51-15 */**	YC001-YC030, YK901-YK909, YL421-YL423
D03940 T	1	BACC10KD10 BACKSHELL	81205	1	21-51-15 */**	YK910-YL401, YL424-YL430
D03942	1	BACC63CB10-2ASN PLUG-	81205	1	21-51-25 521/160/R015	YC001-YL430
D03942 T	1	BACC10KD10 BACKSHELL	81205	1	21-51-25 */**	YC001-YL430
D03973	1	BACC66K33F17AH01 PLUG PLATE ASSY	81205	1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03973 T	1	S280W601-103 GND - BLOCK 90	81205	1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03973 U	1	S280W601-116 GND - BLOCK 48	81205	1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03973A	1	PARTAOFD03973 PLUG - CDS DEU 1		1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03973B	1	PARTBOFD03973 PLUG - CDS DEU 1		1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03973C	1	PARTCOFD03973 PLUG - CDS DEU 1		1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03973D	1	PARTDOFD03973 PLUG - CDS DEU 1		1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03973E	1	PARTEOFD03973 PLUG - CDS DEU 1		1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03973F	1	PARTFOFD03973 PLUG - CDS DEU 1		1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D03975	1	BACC66K33F17AH01 PLUG PLATE ASSY	81205	1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D03900

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03975 T	1	S280W601-103 GND - BLOCK 90	81205	1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D03975 U	1	S280W601-116 GND - BLOCK 48	81205	1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D03975A	1	PARTAOFD03975 PLUG - CDS DEU 2		1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D03975B	1	PARTBOFD03975 PLUG - CDS DEU 2		1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D03975C	1	PARTCOFD03975 PLUG - CDS DEU 2		1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D03975D	1	PARTDOFD03975 PLUG - CDS DEU 2		1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D03975E	1	PARTEOFD03975 PLUG - CDS DEU 2		1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D03975F	1	PARTFOFD03975 PLUG - CDS DEU 2		1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D03977	1	S280W551-211A-05 PLUG PLATE ASSY	81205	1	31-62-11 P001-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03977 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-11 */**	YC001-YC007
D03977 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03977A	1	PARTAOFD03977 INSERT A		0	31-62-11 P001-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D03900

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03977B	1	PARTBOFD03977 INSERT B		0	31-62-11 P001-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03979	1	S280W551-211A-05 PLUG PLATE ASSY	81205	1	31-62-11 P001-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03979 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-11 */ */	YC001-YC007
D03979 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03979A	1	PARTAOFD03979 INSERT A		0	31-62-11 P001-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03979B	1	PARTBOFD03979 INSERT B		0	31-62-11 P001-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03981	1	S280W551-211A-05 PLUG PLATE ASSY	81205	1	31-62-11 P002-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03981 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-11 */ */	YC001-YC007

EQUIPMENT LIST

D280A103

Section D03900

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03981 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03981A	1	PARTAOFD03981 INSERT A		0	31-62-11 P002-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03981B	1	PARTBOFD03981 INSERT B		0	31-62-11 P002-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03982	1	BACC63CE12S-3S PLUG-	81205	1	21-61-51 573/152/R033	YC001-YL430
D03982 T	1	BACC10HW12 BACKSHELL-90 DEGREE	81205	1	21-61-51 */*/	YC001-YL430
D03983	1	S280W551-211A-05 PLUG PLATE ASSY	81205	1	31-62-21 P009-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D03983 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-21 */ /	YC001-YC030
D03983 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-21 */*/	YK901-YL429, YM643-YM652
D03983A	1	PARTAOFD03983 INSERT A		0	31-62-21 P009-00/ /	YC001-YC030
D03983A	1	PARTAOFD03983 INSERT A		0	31-62-21 */*/	YK901-YL429
D03983A	1	PARTAOFD03983 INSERT A		0	31-62-21 199/221/R001	YM643-YM652
D03983B	1	PARTBOFD03983 INSERT B		0	31-62-21 */ /	YC001-YC030
D03983B	1	PARTBOFD03983 INSERT B		0	31-62-21 */*/	YK901-YL429

EQUIPMENT LIST

D280A103

Section D03900

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03983B	1	PARTBOFD03983 INSERT B		0	31-62-21 199/221/L001	YM643-YM652
D03985	1	S280W551-211A-05 PLUG PLATE ASSY	81205	1	31-62-21 P003-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D03985 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-21 */ /	YC001-YC030
D03985 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-21 */*/	YK901-YL429, YM643-YM652
D03985A	1	PARTAOFD03985 INSERT A		0	31-62-21 P003-00/ /	YC001-YC030
D03985A	1	PARTAOFD03985 INSERT A		0	31-62-21 */*/	YK901-YL429
D03985A	1	PARTAOFD03985 INSERT A		0	31-62-21 192/230/R019	YM643-YM652
D03985B	1	PARTBOFD03985 INSERT B		0	31-62-21 */ /	YC001-YC030
D03985B	1	PARTBOFD03985 INSERT B		0	31-62-21 */*/	YK901-YL429
D03985B	1	PARTBOFD03985 INSERT B		0	31-62-21 192/230/R022	YM643-YM652
D03987	1	S280W551-211A-05 PLUG PLATE ASSY	81205	1	31-62-21 P003-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D03987 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-21 */ /	YC001-YC030
D03987 T	1	S280W601-213 GND - BLOCK 16	81205	1	31-62-21 */*/	YK901-YL429, YM643-YM652
D03987A	1	PARTAOFD03987 INSERT A		0	31-62-21 P003-00/ /	YC001-YC030
D03987A	1	PARTAOFD03987 INSERT A		0	31-62-21 */*/	YK901-YL429
D03987A	1	PARTAOFD03987 INSERT A		0	31-62-21 192/230/R011	YM643-YM652

EQUIPMENT LIST

D280A103

Section D03900

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03987B	1	PARTBOFD03987 INSERT B		0	31-62-21 */ /	YC001-YC030
D03987B	1	PARTBOFD03987 INSERT B		0	31-62-21 */*/	YK901-YL429
D03987B	1	PARTBOFD03987 INSERT B		0	31-62-21 192/230/R013	YM643-YM652
D03991	1	BACC63CB16-24SN PLUG - CONDUCTIVE	81205	1	31-62-23 P003-01/ /	YC001-YC030, YK901-YL429, YM643-YM652
D03991 T	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	31-62-23 */ /	YC001-YC030
D03991 T	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	31-62-23 */*/	YK901-YL429, YM643-YM652
D03993	1	BACC63CB22-55S9 PLUG - CONDUCTIVE	81205	1	31-62-11 P007-01/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03993 T	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	31-62-11 */*/	YC001-YC007
D03993 T	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	31-62-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D03995	1	BACC63CB22-55S9 PLUG - CONDUCTIVE	81205	1	31-62-21 P007-02/ /	YC001-YC030, YK901-YL429, YM643-YM652
D03995 T	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	31-62-21 */ /	YC001-YC030
D03995 T	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	31-62-21 */*/	YK901-YL429, YM643-YM652
D03996	1	BACC45FT16-24S6 PLUG-	81205	1	21-61-11 P005-17/ /	YC001-YL430

EQUIPMENT LIST

D280A103

Section D03900

Page 7

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03998	1	BACC45FT16-24S PLUG-	81205	1	21-62-13 P005-17/ /	YC001-YL430
D03999	1	BACC63CB14-15S7 PLUG - CONDUCTIVE	81205	1	31-62-13 P003-01/ /	YC001-YC030, YK901-YK910, YL421-YL423, YM643
D03999	1	BACC63CB16-24S7 PLUG - CONDUCTIVE	81205	1	31-62-13 P003-01/ /	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM652
D03999 T	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	31-62-13 */ */	YC001-YC007
D03999 T	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	31-62-13 */ /	YC008-YC030, YK901-YK910, YL421-YL423, YM643
D03999 T	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	31-62-13 */ /	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM652

EQUIPMENT LIST

D280A103

Section D03900
Page 8 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04003J	1	48-7191 REMOVEABLE SPLICE-SOCKET	02660	1	23-51-31 P061-00/ /	YC001-YK906
D04003P	1	48-7190 REMOVEABLE SPLICE-PIN	02660	1	23-51-31 P061-00/ /	YC001-YC030, YK901-YK906
D04005J	1	48-7191-1 REMOVEABLE SPLICE-SOCKET	02660	1	23-51-31 P061-00/ /	YC001-YC030, YK901-YK906
D04005P	1	48-7190-1 REMOVEABLE SPLICE-PIN	02660	1	23-51-31 P061-00/ /	YC001-YK906
D04007J	1	MTCPQKT1R2PGDB RCPT- CONDUCTIVE	06090	1	31-33-01 E004-01/ /	YK901-YM670
D04007P	1	MTCPQKT1P2SGDB PLUG - CONDUCTIVE	06090	1	23-27-31 E004-01/ /	YK901-YM670
D04009J	1	MTCPQKT1R2PGDC RCPT- CONDUCTIVE	06090	1	31-32-15 E004-01/ /	YK901-YL430
D04009J	1	MTCPQKT1R2PGDC RCPT- CONDUCTIVE	06090	1	34-61-21 E004-01/ /	YM643-YM670
D04009P	1	MTCPQKT1P2SGDC PLUG - CONDUCTIVE	06090	1	23-27-31 E004-01/ /	YK901-YM670
D04025J	1	2431-84-2 RCPT - (C) STRAIGHT	91836	1	34-31-11 E001-02/ /	ALL
D04025P	1	2435-81-2 PLUG-COAX	91836	1	34-31-11 E001-02/ /	YC001-YC030, YK901-YM670
D04027J	1	2431-84-11 RCPT - (C) STRAIGHT	91836	1	34-31-21 E001-02/ /	ALL
D04027P	1	2435-81-11 PLUG - (C) STRAIGHT	91836	1	34-31-21 E001-02/ /	ALL
D04029J	1	BACC63CC22-55P7 RCPT - CONDUCTIVE	81205	1	34-51-11 E001-02/ /	YC001-YC030, YK901-YM670
D04029JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-51-11 E001-02/ /	YC001-YC030, YK901-YM670
D04029P	1	BACC63CB22-55S7 PLUG-CONDUCTIVE	81205	1	34-45-02 E001-02/ /	YC001-YC030, YK901-YM670
D04029PQ	1	BACC10KF22 BACKSHELL	81205	1	34-45-02 E001-02/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D04000

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04029PQ	1	BACC10KF22 BACKSHELL	81205	1	34-45-02 */**	YK901-YM670
D04031J	1	BACC63CC22-55P6 RCPT - CONDUCTIVE	81205	1	34-51-21 E001-05/ /	YC001-YC030, YK901-YM670
D04031JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-51-21 E001-05/ /	YC001-YC030, YK901-YM670
D04031P	1	BACC63CB22-55S6 PLUG-RECEPTIVE	81205	1	34-55-21 E001-05/ /	YC001-YC030
D04031P	1	BACC63CB22-55S6 PLUG-RECEPTIVE	81205	1	34-55-21 AE0105A/ /	YK901-YM670
D04031PQ	1	BACC10KD22 BACKSHELL	81205	1	28-23-12 / /	YC001-YC030
D04031PQ	1	BACC10KD22 BACKSHELL	81205	1	28-23-12 */**	YK901-YM670
D04069J	1	MTCPQKT2R22SGCA RECPT-CONDUCTIVE	06090	1	22-11-11 E001-01/ /	ALL
D04069P	1	MTCPQKT2P22PGCA PLUG-CONDUCTIVE	06090	1	22-11-11 E001-01/ /	ALL
D04073J	1	MTCPQKT2R22SGBC RECPT-CONDUCTIVE	06090	1	22-11-31 E001-01/ /	ALL
D04073P	1	MTCPQKT2P22PGBC PLUG- CONDUCTIVE	06090	1	22-11-31 E001-01/ /	ALL
D04075J	1	MTCPQKT2R22SGAC RECPT-CONDUCTIVE	06090	1	22-13-11 E001-01/ /	ALL
D04075P	1	MTCPQKT2P22PGAC PLUG- CONDUCTIVE	06090	1	22-13-11 E001-01/ /	ALL
D04077J	1	BACC63CC22-55P6 RCPT-CONDUCTIVE	81205	1	22-11-31 E001-04/ /	ALL
D04077JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YC001-YC028
D04077JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */**	YC029-YM670
D04077P	1	BACC63CB22-55S6 PLUG - CONDUCTIVE	81205	1	22-11-31 E001-04/ /	ALL

EQUIPMENT LIST

D280A103

Section D04000

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04077PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	22-11-31 E001-04/ /	YC001-YC050
D04077PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	22-11-31 */*/*	YK901-YM670
D04079J	1	MTCPQKT2R22SGCD RECPT-CONDUCTIVE	06090	1	22-11-12 E001-01/ /	ALL
D04079P	1	MTCPQKT2P22PFCD PLUG-	06090	1	22-11-12 E001-01/ /	ALL
D04081J	1	BACC45FN18-31P7 PLUG-	81205	1	22-11-21 E001-04/ /	ALL
D04081JK	1	BACC10JS18 BACKSHELL	81205	1	22-11-12 / /	ALL
D04081P	1	BACC45FT18-31S7 PLUG	81205	1	22-11-21 E001-04/ /	ALL
D04081PQ	1	BACC10JS18 CLAMP	81205	1	22-11-21 E001-04/ /	YC001-YC050
D04081PQ	1	BACC10JS18 CLAMP	81205	1	22-11-21 */*/*	YK901-YM670
D04083J	1	MTCPQKT2R26SFBB RCPT-	06090	1	22-13-11 E001-01/ /	ALL
D04083P	1	MTCPQKT2P26PFBB PLUG-	06090	1	22-13-11 E001-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D04000

Page 3 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04102J		55-9002-1 RECP-SHORT1NG-LTG P5 PNL	65-73739 77820	1	33-12-01 P005-00/ /	ALL
D04104J		55-9002-1 RECP-SHORTING-LTG P5 PNL	65-73739 77820	1	33-12-01 P005-00/ /	ALL
D04110J		55-9002-1 RECP-SHORTING-LTG P5 OVHD	65-73708 77820	1	33-12-01 260/290/L008	ALL
D04115J	1	MTCPQKT2R22PGDA RCPT- CONDUCTIVE	06090	1	31-33-01 E004-01/ /	YK901-YM670
D04115P	1	MTCPQKT2P22SGDA PLUG - CONDUCTIVE	06090	1	31-33-01 E004-01/ /	YK901-YM670
D04117J	1	MTCPQKT2R22PGDD RCPT-CONDUCTIVE	06090	1	31-32-15 E004-01/ /	YK901-YL430
D04117J	1	MTCPQKT2R22PGDD RCPT - CONDUCTIVE	06090	1	31-32-15 E004-01/ /	YM643-YM670
D04117P	1	MTCPQKT2P22SGDD PLUG - CONDUCTIVE	06090	1	31-33-01 E004-01/ /	YK901-YM670
D04119J	1	121-44-9 RCPT - (TNC)	91836	1	34-32-11 604/148/L002	ALL
D04119P	1	125-88-9 PLUG - (TNC)	91836	1	34-32-11 604/148/2	ALL
D04121J	1	2431-84-5 RCPT - (TNC)	91836	1	34-32-11 E001-02/ /	ALL
D04121P	1	2435-81-5 PLUG-COAX	91836	1	34-32-11 E001-02/ /	YC001-YC030
D04121P	1	2435-81-5 PLUG-COAX	91836	1	34-32-11 */*/*	YK901-YM670
D04123J	1	BACC63CC14-12SN RCPT-CONDUCTIVE	81205	1	23-12-11 E001-03/ /	YC001-YC030
D04123J	1	BACC45FN22-55S RCPT	81205	1	23-12-11 E001-03/ /	YK901-YM670
D04123P	1	BACC63CB14-12PN PLUG-CONDUCTIVE CONNECTOR	81205	1	23-12-11 E001-03/ /	YC001-YC030
D04123P	1	BACC45FT22-55P PLUG -	81205	1	23-12-11 E001-03/ /	YK901-YL430, YM652-YM670

EQUIPMENT LIST

D280A103

Section D04100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04123P	1	BACC45FT22-55P PLUG	81205	1	23-12-11 E001-03/ /	YM643-YM651
D04123PQ	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	23-12-11 E1-3/ /	YC001-YC030
D04125J	1	BACC63CC14-12PN RECP-CONDUCTIVE CONNECTOR	81205	1	23-12-21 E001-05/ /	YC001-YC050
D04125J	1	BACC63CC14-12PN RECP - CONDUCTIVE	81205	1	23-12-21 E001-05/ /	YK901-YM670
D04125JK	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	23-12-21 E1-5/ /	YC001-YC050
D04125JK	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	23-12-21 E001-05/ /	YK901-YM670
D04125P	1	BACC63CB14-12SN PLUG-CONDUCTIVE	81205	1	23-12-21 E001-05/ /	YC001-YC030
D04125P	1	BACC63CB14-12SN PLUG-CONDUCTIVE	81205	1	23-12-21 AE0105A/ /	YK901-YM670
D04125PQ	1	BACC10KD14 BACKSHELL	81205	1	23-12-21 / /	YC001-YC030
D04125PQ	1	BACC10KD14 BACKSHELL	81205	1	23-12-21 */*/	YK901-YM670
D04131J	9	2430-2-16 JACK - E1-5 SHELF	91836	1	23-12-21 305/171/L20	YC001-YC016
D04131J	1	2430-2-16 JACK	91836	1	23-12-21 E001-05/ /	YC017-YM670
D04131P	1	2435-81-16 PLUG-COAX	91836	1	23-12-21 E001-05/ /	YC001-YC030, YK901-YM670
D04133J	1	121-44-9 RCPT	91836	1	23-12-11 E001-03/ /	ALL
D04133P	9	125-95-9 PLUG - E1-3 SHELF	91836	1	23-12-11 E001-03/ /	YC001-YC016
D04133P	1	125-95-9 PLUG - E1-3 SHELF	91836	1	23-12-11 E001-03/ /	YC017-YC019, YM643-YM670
D04133P	1	125-95-9 PLUG	91836	1	23-12-11 E001-03/ /	YC020-YL430

EQUIPMENT LIST

D280A103

Section D04100

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04137J	1	121-46-9 JACK-STA 506	91836	1	23-12-11 472/154/L004	YC001-YC016
D04137J	1	121-46-9 JACK	91836	1	23-12-21 472/154/L004	YC017-YM670
D04137P	1	125-95-9 PLUG	91836	1	23-12-21 472/154/L004	YC001-YC030, YM643-YM670
D04137P	1	125-95-9 PLUG	91836	1	23-12-11 472/154/L004	YC031-YL430
D04141J	9	121-46-9 JACK	91836	1	23-12-11 E001-05/ /	YC001-YC016
D04141J	1	121-46-9 JACK	91836	1	23-12-11 E001-05/ /	YC017-YC019
D04141P	9	125-95-9 PLUG	91836	1	23-12-11 E001-05/ /	YC001-YC016
D04141P	1	125-95-9 PLUG	91836	1	23-12-11 E001-05/ /	YC017-YC019
D04149J	1	BACC45FN12-12S6 RCPT	81205	1	23-41-01 E001-03/ /	ALL
D04149P	1	BACC45FT12-12P6 PLUG - HANDSET JACK(CONTROL STAND)	81205	1	23-41-11 E001-03/ /	ALL
D04149PQ	1	BACC10JS12 BACKSHELL	81205	1	23-41-11 E001-03/ /	ALL
D04151J	1	BACC45FN12-12P6 RCPT-	81205	1	23-51-31 P061-00/ /	YC001-YC050
D04151J	1	BACC45FN14-15P6 RCPT-	81205	1	23-51-31 P061-00/ /	YK901-YM670
D04151P	1	BACC45FT12-12S6 PLUG-	81205	1	23-51-31 P006-00/ /	YC001-YC050
D04151P	1	BACC45FT14-15S6 PLUG-	81205	1	23-51-31 P006-00/ /	YK901-YM670
D04153J	1	MTCPQKT2R22SGBB RCPT-CONDUCTIVE	06090	1	23-51-31 E004-01/ /	ALL
D04153P	1	MTCPQKT2P22PGBB PLUG- CONDUCTIVE	06090	1	23-51-31 E004-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D04100

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04155J	1	MTCPQKT2R22SGAB RCPT-CONDUCTIVE	06090	1	23-51-11 E004-01/ /	ALL
D04155P	1	MTCPQKT2P22PGAB PLUG E4-1 SHELF	06090	1	23-51-11 E004-01/ /	ALL
D04157J	1	MTCPQKT1R2SFCD RCPT-CONDUCTIVE	06090	1	23-71-01 E004-01/ /	YC001-YC050, YM643-YM670
D04157J	1	MTCPQKT1R2SFCD RCPT-	06090	1	23-71-01 E004-01/ /	YK901-YL430
D04157P	1	MTCPQKT1P2PGCD PLUG-CONDUCTIVE CONNECTOR	06090	1	23-71-01 E004-01/ /	YC001-YC022
D04157P	1	MTCPQKT1P2PGCD PLUG-CONDUCTIVE	06090	1	23-71-01 E004-01/ /	YC023-YM670
D04161J	1	MTCPQKT1R2SFCA RCPT-	06090	1	23-41-01 E004-01/ /	ALL
D04161P	1	MTCPQKT1P2PFCA PLUG - CONDUCTIVE	06090	1	23-41-11 E004-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04171J	1	MTCPQKT2R22PGDB RCPT-CONDUCTIVE	06090	1	23-70-11 E004-01/ /	YK901-YK906
D04171P	1	MTCPQKT2P22SGDB PLUG E4-1 SHELF	06090	1	23-70-11 E004-01/ /	YK901-YK906
D04173J	1	MTCPQKT2R22PGDC RCPT-CONDUCTIVE	06090	1	23-70-11 E004-01/ /	YK901-YK906
D04173P	1	MTCPQKT2P22SGDC PLUG E4-1 SHELF	06090	1	23-70-11 E004-01/ /	YK901-YK906
D04181J	1	BACC45FN14-15S RCPT	81205	1	23-41-01 E001-03/ /	ALL
D04181P	1	BACC45FT14-15P PLUG - ATT HANDSET (AFT)	81205	1	23-42-12 E001-03/ /	ALL
D04181PQ	1	BACC10JS14 BACKSHELL	81205	1	23-41-11 E001-03/ /	YC001-YL430
D04181PQ	1	BACC10JS14 BACKSHELL	81205	1	23-41-11 */*/	YM643-YM670

EQUIPMENT LIST

D280A103

Section D04100

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04195J	1	BACC63CC22-55P7 RCPT-CONDUCTIVE	81205	1	23-12-11 E001-03/ /	ALL
D04195P	1	BACC63CB22-55S7 PLUG - CONDUCTIVE	81205	1	23-31-02 E001-03/ /	YC001-YC030, YK901-YM670
D04195PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	23-31-02 E001-03/ /	YC001-YC030, YK901-YM670
D04197J	1	BACC63CC20-41P8 RECP - CONDUCTIVE	81205	1	23-22-01 E001-05/ /	YC001-YC030
D04197J	1	BACC63CC22-55P8 RECP - CONDUCTIVE	81205	1	23-22-01 E001-05/ /	YK901-YM670
D04197JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	23-22-01 */*/*	YC001-YC030
D04197JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	23-22-01 */*/*	YK901-YM670
D04197P	1	BACC63CB20-41S8 PLUG-CONDUCTIVE	81250	1	23-22-01 E001-05/ /	YC001-YC030
D04197P	1	BACC63CB22-55S8 PLUG-CONDUCTIVE	81250	1	23-22-01 E001-05/ /	YK901-YM670
D04197PQ	1	BACC10KD20 BACKSHELL	81205	1	28-23-12 / /	YC001-YC030
D04197PQ	1	BACC10KD22 BACKSHELL	81205	1	28-23-12 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D04100
Page 5 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04205J	1	BACC63CC14-15P9 RCPT - CONDUCTIVE	81205	1	34-22-11 E001-02/ /	YC001-YC030, YK901-YM670
D04205JK	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	34-22-11 E001-02/ /	YC001-YC030
D04205JK	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	34-22-11 */*/	YK901-YM670
D04205P	1	BACC63CB14-15S9 PLUG-CONDUCTIVE	81205	1	34-22-11 E001-02/ /	YC001-YC030, YK901-YM670
D04205PQ	1	BACC10KD14 BACKSHELL	81205	1	34-45-02 E001-02/ /	YC001-YC030
D04205PQ	1	BACC10KD14 BACKSHELL	81205	1	34-45-02 */*/	YK901-YM670
D04207J	1	BACC63CC20-41P7 RCPT - CONDUCTIVE	81205	1	31-62-12 P009-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04207JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-12 */*/	YC001-YC007
D04207JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-12 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04207P	1	BACC63CB20-41S7 PLUG - CONDUCTIVE	81205	1	31-62-12 P009-00/ /	ALL
D04207PQ	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-12 */ /	ALL
D04217J	1	121-39-9 JACK-HF-1 COAX	91836	1	23-11-11 1038/305/R010	YC001-YC007
D04217J	1	2431-87-1 JACK-HF-1 COAX	91836	1	23-11-11 1038/305/R010	YK907-YL430
D04217J	1	2431-87-1 JACK- COAX	91836	1	23-11-11 1038/305/R010	YM643-YM670

EQUIPMENT LIST

D280A103

Section D04200

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04217P	1	125-95-9 PLUG-HF-1 COAX	91836	1	23-11-11 1038/305/R010	YC001-YC007
D04217P	1	2435-84-1 PLUG-	91836	1	23-11-11 1038/305/R010	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04221J	1	BACC63CC22-55P8 RCPT - CONDUCTIVE	81205	1	22-13-11 P009-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04221JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	22-13-11 */*/	YC001-YC007
D04221JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	22-13-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04221P	1	BACC63CB22-55S8 PLUG-CONDUCTIVE	81205	1	22-13-11 P009-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04221PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	22-13-11 / /	YC001-YC002, YC007-YC050
D04221PQ	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	22-13-11 / /	YC003-YC006
D04221PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	22-13-11 */*/	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04227J	1	BACC45FN20C25S RCPT-HF-1 COUPLER	81205	1	23-11-11 1037/305/R010	YC001-YC007
D04227J	1	BACC63CC20-25S7 RCPT-HF-1 COUPLER	81205	1	23-11-11 1037/305/R010	YK907-YL430
D04227J	1	BACC63CC20-25S7 RCPT	81205	1	23-11-11 1037/305/R010	YM643-YM670

EQUIPMENT LIST

D280A103

Section D04200

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04227JK	1	BACC10KD20 BACKSHELL	81205	1	23-11-11 1037/305/R010	YK907-YM670
D04227P	1	BACC45FT20-25P PLUG-HF-1 COUPLER	81205	1	23-11-11 1037/305/R010	YC001-YC007
D04227P	1	BACC63CB20-25P7 PLUG-	81205	1	23-11-11 1037/305/R010	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04227PQ	1	BACC10KD20 BACKSHELL	81205	1	23-11-11 1037/305/R010	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04237J	1	BACC63CC20-41PN RCPT - CONDUCTIVE	81205	1	31-62-22 P009-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D04237JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-22 */ /	YC001-YC030
D04237JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-22 */*/	YK901-YL429, YM643-YM652
D04237P	1	BACC63CB20-41SN PLUG - CONDUCTIVE	81205	1	31-62-22 P009-00/ /	ALL
D04237PQ	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-22 */ /	YC001-YC007
D04237PQ	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-22 */*/	YC008-YM670
D04245J	1	BACC63CC20-25SN RCPT-HF-2 COUPLER	81205	1	23-11-21 1035/305/R010	YK907-YL430
D04245J	1	BACC63CC20-25SN RCPT-	81205	1	23-11-21 1035/305/R010	YM643-YM670
D04245JK	1	BACC10KD20 BACKSHELL	81205	1	23-11-21 1035/305/R010	YK907-YM670
D04245P	1	BACC63CB20-25PN PLUG-	81205	1	23-11-21 1035/305/R010	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D04200

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04245PQ	1	BACC10KD20 BACKSHELL	81205	1	23-11-21 */*/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04251J	1	BACC63CC16-24S7 RCPT - CONDUCTIVE	81205	1	22-14-11 P009-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D04251JK	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	22-14-11 */ /	YC001-YC030
D04251JK	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	22-14-11 */*/	YK901-YL429, YM643-YM652
D04251P	1	BACC63CB16-24P7 PLUG - CONDUCTIVE	81205	1	22-14-11 P009-00/ /	ALL
D04251PQ	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	22-14-11 / /	ALL
D04267J	1	MTCPQKT2R22SGAD RCPT - CONDUCTIVE	06090	1	31-62-12 E003-01/ /	YC001-YC030, YK901-YM670
D04267P	1	MTCPQKT2P22PGAD PLUG - CONDUCTIVE	06090	1	31-62-12 E003-01/ /	ALL
D04269J	1	BACC63CC16-24P9 RECP - CONDUCTIVE	81205	1	34-31-11 E001-02/ /	YC001-YC030
D04269J	1	BACC63CC22-55P9 RECP - CONDUCTIVE	81205	1	34-31-11 E001-02/ /	YK901-YM670
D04269JK	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	34-31-11 E001-02/ /	YC001-YC030
D04269JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	34-31-11 E001-02/ /	YK901-YM670
D04269P	1	BACC63CB16-24S9 PLUG-CONDUCTIVE	81205	1	34-32-11 E001-02/ /	YC001-YC030
D04269P	1	BACC63CB22-55S9 PLUG-CONDUCTIVE	81205	1	34-32-11 E001-02/ /	YK901-YM670
D04269PQ	1	BACC10KD16 BACKSHELL	81205	1	34-45-02 / /	YC001-YC030
D04269PQ	1	BACC10KD22 BACKSHELL	81205	1	34-45-02 */*/	YK901-YM670

EQUIPMENT LIST

D280A103

Section D04200

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04271J	1	MTCPQKT1R2PGAA RCPT - CONDUCTIVE	06090	1	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670
D04271P	1	MTCPQKT1P2SGAA PLUG- E3-1 SHELF	06090	1	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670
D04273J	1	BACC63CC12-12P9 RECP - CONDUCTIVE	81205	1	23-22-01 E001-04/ /	YC001-YC030, YK901-YM670
D04273JK	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	23-22-01 */**	YC001-YC030, YK901-YM670
D04273P	1	BACC63CB12-12S9 PLUG - CONDUCTIVE	81205	1	23-22-01 E001-04/ /	ALL
D04273PQ	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	23-22-01 E001-04/ /	YC001-YC050
D04273PQ	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	23-22-01 */**	YK901-YM670
D04277J	1	MTCPQKT1R2PGDC RCPT - CONDUCTIVE	06090	1	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D04277P	1	MTCPQKT1P2SGDC PLUG-E3-1 SHELF	06090	1	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D04285J	1	MTCPQKT2R22PGAC RCPT-CONDUCTIVE	06090	1	23-12-21 E004-01/ /	ALL
D04285P	1	MTCPQKT2P22SGAC PLUG-E4-1 SHELF	06090	1	34-55-21 E004-01/ /	YC001-YC030, YK901-YM670
D04287J	1	MTCPQKT2R22PGAA RCPT-CONDUCTIVE	06090	1	23-12-11 E004-01/ /	ALL
D04287P	1	MTCPQKT2P22SGAA PLUG- E4-1 SHELF	06090	1	34-55-11 E004-01/ /	YC001-YC030, YK901-YM670
D04289J	1	MTCPQKT2R22PGDD RCPT-CONDUCTIVE	06090	1	23-12-31 E004-01/ /	YK901-YL430
D04289J	1	MTCPQKT2R22PGDD RCPT-CONDUCTIVE	06090	1	23-22-11 E004-01/ /	YM643-YM670
D04289P	1	MTCPQKT2P22SGDD PLUG - CONDUCTIVE	06090	1	23-12-31 E004-01/ /	YK901-YL430
D04289P	1	MTCPQKT2P22SGDD PLUG-CONDUCTIVE	06090	1	23-12-31 E004-01/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section D04200

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04297J	1	MTCPQKT2R22SGCA RCPT - CONDUCTIVE	06090	1	31-62-22 E003-01/ /	YC001-YC030, YK901-YM670
D04297P	1	MTCPQKT2P22PGCA PLUG - CONDUCTIVE	06090	1	31-62-22 E003-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D04200
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04311J	1	BACC63CC18-31PN RCPT-CONDUCTIVE	81205	1	22-14-11 E001-04/ /	ALL
D04311JK	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	22-14-11 / /	ALL
D04311P	1	BACC63CB18-31SN PLUG - CONDUCTIVE	81205	1	22-14-11 E001-04/ /	ALL
D04311PQ	1	BACC10KD18 BACKSHELL - CONDUCTIVE	81205	1	22-14-11 E001-04/ /	YC001-YC050
D04311PQ	1	BACC10KD18 BACKSHELL - CONDUCTIVE	81205	1	22-14-11 */*/	YK901-YM670
D04331J	1	MTCPQKT2R22SGAD RCPT-CONDUCTIVE	06090	1	23-51-02 E004-01/ /	ALL
D04331P	1	MTCPQKT2P22PGAD PLUG E4-1 SHELF	06090	1	23-51-21 E004-01/ /	ALL
D04371J	1	MTCPQKT2R22SGBC RCPT-CONDUCTIVE	06090	1	23-71-01 E004-01/ /	ALL
D04371P	1	MTCPQKT2P22PGBC PLUG-CONDUCTIVE CONNECTOR	06090	1	23-71-01 E004-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D04300

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04425J	1	MTCPQKT1R2PGBD RECPT-CONDUCTIVE	06090	1	22-18-11 E001-01/ /	ALL
D04425P	1	MTCPQKT1P2SFBD PLUG-	06090	1	22-18-11 E001-01/ /	ALL
D04435J	1	791-10-9 RECP - (C)	91836	1	34-51-11 1031/300/L001	YC001-YC030, YK901-YM670
D04435P	1	795-16-9 PLUG - (C)	91836	1	34-51-11 MULTI/ /	YC001-YK912, YK918-YK919, YL401-YL426, YM643-YM652
D04435P	1	795-33-9 PLUG - (C)	91836	1	34-51-11 MULTI/ /	YK913-YK917, YK920, YL427- YL430, YM653- YM670
D04437J	1	791-10-9 RCPT - (C)	91836	1	34-51-21 1035/300/L001	ALL
D04437P	1	795-16-9 PLUG - (C)	91836	1	34-51-21 MULTI/ /	YC001-YK912, YK918-YK919, YL401-YL426, YM643-YM652
D04437P	1	795-33-9 PLUG - (C)	91836	1	34-51-21 MULTI/ /	YK913-YK917, YK920, YL427- YL430, YM653- YM670
D04499J	1	BACC63BV12B12P6 RECPT-P19 PNL	81205	1	23-41-11 P019-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04499P	1	BACC63BP12D12S6 PLUG - CONDUCTIVE	81205	1	23-41-11 231/187/R033	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04499PQ	1	BACC10KA12 BACKSHELL - CONDUCTIVE	81205	1	23-41-11 P019-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D04400
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04578J	1	BACC63BV16F24SN RECP	81205	1	28-44-11 OFSS 388/ /	ALL
D04578JK	1	BACC10KF16 BACKSHELL	81205	1	28-44-11 */**	ALL
D04578P	1	BACC63BP16C24PN PLUG-CONDUCTIVE CONNECTOR	81205	1	28-44-12 P015-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04578PQ	1	BACC10KF16 BACKSHELL	81205	1	28-44-12 P015-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04580J	1	BACC63CC14-15S6 RCPT-CONDUCTIVE	81205	1	21-51-11 542/158/L028	ALL
D04580JK	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-11 */**	ALL
D04580P	1	BACC63CB14-15P6 PLUG-CONDUCTIVE	81205	1	21-51-15 542/158/L027	YC001-YC030, YK901-YM670
D04580PQ	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-11 */**	YC001-YC030, YK901-YM670
D04582J	1	BACC63CC14-15S6 RCPT-CONDUCTIVE	81205	1	21-51-21 542/158/R028	ALL
D04582JK	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-21 */**	ALL
D04582P	1	BACC63CB14-15P6 PLUG-CONDUCTIVE	81205	1	21-51-21 542/158/R027	ALL
D04582PQ	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-51-21 */**	ALL

EQUIPMENT LIST

D280A103

Section D04500

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04603J	1	2431-89-6 RCPT-COAX	91836	1	34-53-31 E001-02/ /	ALL
D04603P	1	2435-87-6 PLUG-COAX	91836	1	34-53-31 E001-02/ /	YC001-YC030, YK901-YM670
D04607J	1	2431-87-1 JACK-COAX	91836	1	34-53-31 E001-02/ /	ALL
D04607P	1	2435-84-1 PLUG-COAX	91836	1	34-53-31 E001-02/ /	YC001-YC030, YK901-YM670
D04609J	1	2431-87-1 RECPT-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04609P	1	2435-84-1 PLUG-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04611J	1	2431-87-6 RECPT-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04611P	1	2435-84-6 PLUG-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04613J	1	2431-87-11 RECPT-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04613P	1	2435-84-11 PLUG-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04615J	1	2431-87-16 RECPT-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04615P	1	2435-84-16 PLUG-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04617J	1	2431-84-11 RECPT-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04617P	1	2435-81-11 PLUG-COAX	91836	1	34-45-21 312/177/R017	ALL
D04619J	1	2431-84-16 RECPT-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04619P	1	2435-81-16 PLUG-COAX	91836	1	34-45-21 314/177/R016	ALL
D04621J	1	2431-84-1 RECPT-COAX	91836	1	34-45-21 E001-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D04600

Page 1

Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04621P	1	2435-81-1 PLUG-COAX	91836	1	34-45-21 312/175/R017	ALL
D04623J	1	2431-84-6 RECPT-COAX	91836	1	34-45-21 E001-01/ /	ALL
D04623P	1	2435-81-6 PLUG-COAX	91836	1	34-45-21 314/176/R016	ALL
D04625J	1	2431-88-1 RCPT	91836	1	34-45-21 AB0387/ /	ALL
D04625P	1	2435-84-1 PLUG	91836	1	34-45-02 AB0387/ /	ALL
D04627J	1	2431-88-6 RCPT	91836	1	34-45-21 AB0387/ /	ALL
D04627P	1	2435-84-6 PLUG	91836	1	34-45-02 AB0387/ /	ALL
D04629J	1	2431-88-11 RCPT	91836	1	34-45-21 AB0387/ /	ALL
D04629P	1	2435-84-11 PLUG	91836	1	34-45-02 AB0387/ /	ALL
D04633J	1	2431-88-16 RCPT	91836	1	34-45-21 AB0387/ /	ALL
D04633P	1	2435-84-16 PLUG	91836	1	34-45-02 AB0387/ /	ALL

EQUIPMENT LIST

D280A103



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04713J	1	121-39-9 JACK-HF-2 COAX	91836	1	23-11-21 1036/305/R010	YK907-YL430
D04713J	1	121-39-9 JACK- COAX	91836	1	23-11-21 1036/305/R010	YM643-YM670
D04713P	1	125-95-9 PLUG-HF-2 COAX	91836	1	23-11-21 1036/305/R010	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04721J	1	MTCPQKT1R2SFDD RCPT-	06090	1	23-22-01 E004-01/ /	YC001-YK906
D04721P	1	MTCPQKT1P2PFDD PLUG - SELCAL CONTROL	06090	1	23-22-11 E004-01/ /	YC001-YK906

EQUIPMENT LIST

D280A103

Section D04700
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04826J	1	BACC63BV14F7S8 RECP-CONDUCTIVE	81205	1	30-31-11 1038/296/L012	ALL
D04826JK	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	30-31-11 / /	ALL
D04826P	1	BACC63BP14C7P8 PLUG-PITOT HTR LEFT	81205	1	30-31-11 MULTI/ /	ALL
D04826PQ	1	BACC10KD14 BACKSHELL-	81205	1	30-31-11 */**	ALL
D04850J	1	BACC63BV22F55PN RECP-CONDUCTIVE CONNECTOR	81205	1	28-41-11 673/198/L036	YC001-YC007
D04850J	1	BACC63BV22F55PN RECP-CONDUCTIVE CONNECTOR	81205	1	28-41-11 675/198/L036	YC008-YC029
D04850J	1	BACC63BV22B55PN RECP-CONDUCTIVE CONNECTOR	81205	1	28-41-11 AL0675B/202/L032	YC030-YM670
D04850JK	1	BACC10KD22 BACKSHELL	81205	1	28-41-13 */**	YC001-YC029
D04850JK	1	BACC10KA22 BACKSHELL	81205	1	28-41-13 */**	YC030-YM670
D04850P	1	BACC63BP22C55SN PLUG-	81205	1	28-41-11 673/198/L038	YC001-YC029
D04850P	1	BACC63BP22D55SN PLUG-	81205	1	28-41-11 673/198/L038	YC030
D04850P	1	BACC63BP22D55SN PLUG-	81205	1	28-41-11 AL0675B/202/L030	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D04850PQ	1	BACC10KD22 BACKSHELL	81205	1	28-41-13 / /	YC001-YC007
D04850PQ	1	BACC10KD22 BACKSHELL	81205	1	28-41-13 */**	YC008-YC029
D04850PQ	1	BACC10KA22 BACKSHELL	81205	1	28-41-13 */**	YC030-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D04800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04889J	1	BACC45FN18-31P7 PLUG-	81205	1	23-24-11 AB0288/ /	ALL
D04889P	1	BACC45FT18-31S7 PLUG-	81205	1	23-24-11 AB0288/ /	ALL

EQUIPMENT LIST

D280A103

Section D04800
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05148J	1	BACC45FN14-12P7 RCPT-P8 AND P10 CONTROL STAND PNLS	81205	1	33-11-41 212 P8/209/R2	ALL
D05148JK	1	MS27291-3 BACKSHELL-	96906	1	33-11-41 / /	ALL
D05148P	1	BACC45FT14-12S7 PLUG-P8 AND P9 CONTROL STAND PANEL	81205	1	31-53-11 212/209/R2	YC001-YC007
D05148P	1	BACC45FT14-12S7 PLUG-P8 AND P9 CONTROL STAND PANEL	81205	1	31-53-11 212/209/R002	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D05148PQ	1	BACC10JS14 BACKSHELL-	81205	1	31-53-11 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D05150J	1	BACC45FN12-12P RCPT-P8 CONTROL STAND PANEL	81205	1	27-54-11 214 P8/208/R2	ALL
D05150JK	1	MS27291-2 BACKSHELL-	96906	1	27-54-11 / /	ALL
D05150P	1	BACC45FT12-12S PLUG-P8 AND P9 CONTROL STAND PANEL	81205	1	27-54-11 214/208/R2	YC001-YC030
D05150P	1	BACC45FT12-12S PLUG-P8 AND P9 CONTROL STAND PANEL	81205	1	27-54-11 214/208/R002	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D05150PQ	1	BACC10JS12 BACKSHELL-	81205	1	27-54-11 */**	YC001-YC030, YK901-YK906, YM643-YM652
D05150PQ	1	BACC10JS12 BACKSHELL-	81205	1	27-54-11 * **/*	YC031-YC050, YK907-YK912, YK918-YK919, YL401-YL429

EQUIPMENT LIST

D280A103

Section D05100

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05342J	1	BACC45FN14-7S7 RECP	81205	1	28-23-12 AB0500DR/ /	ALL
D05342P	1	BACC45FT14-7P7 PLUG	81205	1	28-23-11 AB0500DR/ /	ALL
D05346J	1	BACC45FN14-7S9 RECP	81205	1	28-23-11 AB0500DL/ /	ALL
D05346P	1	BACC45FT14-7P9 PLUG	81205	1	28-23-11 AB0500DL/ /	ALL
D05348J	1	BACC45FN14-7S7 RECP	81205	1	28-23-11 AB0500DL/ /	ALL
D05348P	1	BACC45FT14-7P7 PLUG	81205	1	28-23-11 AB0500DL/ /	ALL
D05350J	1	BACC45FN18-14S9 RECP	81205	1	28-23-12 AB0500DR/ /	ALL
D05350P	1	BACC45FT18-14P9 PLUG	81205	1	28-23-12 AB0500DR/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D05300
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05925J	1	MTCPQKT1R2PGBA RCPT-CONDUCTIVE	06090	1	34-61-11 E005-02/ /	YC001-YC011
D05925J	1	MTCPQKT2R22PGAD RCPT-CONDUCTIVE	06090	1	34-61-11 E005-02/ /	YC012-YM670
D05925P	1	MTCPQKT1P2SGBA PLUG-	06090	1	34-61-11 E005-02/ /	YC001-YC011
D05925P	1	MTCPQKT2P22SGAD PLUG-	06090	1	34-61-18 E005-02/ /	YC012-YC050
D05925P	1	MTCPQKT2P22SGAD PLUG-	06090	1	34-61-18 AE0502A/ /	YK901-YM670
D05971J	1	BACC45FN16-24S6 RCPT	81205	1	22-11-12 E001-04/ /	ALL
D05971P	1	BACC45FT16-24P6 PLUG	81205	1	22-11-12 E001-04/ /	ALL
D05971PQ	1	BACC10JS16 CLAMP	81205	1	22-11-12 E001-04/ /	YC001-YC050
D05971PQ	1	BACC10JS16 CLAMP	81205	1	22-11-12 */*/	YK901-YM670

EQUIPMENT LIST

D280A103

Section D05900

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06001		66-16842-15 JACK-CONT STAND MIC	65-45760 81205	1	23-31-01 243/213/L003	YC001-YC050, YM643-YM670
D06009	1	2J-1865A JACK-HANDSET-EP FLIGHT	82389	1	23-41-11 P019-00/ /	ALL
D06011	1	2J-1865A INTPH JACK - L WHEEL WELL	82389	1	23-41-11 664/161/L071	ALL
D06013	1	2J-1865A JACK	82389	1	23-41-11 OFSS 380/ /	ALL
D06015	1	2J-1865A JACK-AFT CABIN	82389	1	23-41-11 988/289/L000	ALL
D06017	1	2J-1865A APU SERVICE JACK	82389	1	23-41-11 1042/175/L042	ALL
D06019	1	2J-1865A SERVICE JACK - CONTROL STAND	82389	1	23-42-12 P008-00/ /	ALL
D06025	1	2J-1865A SERVICE INTPH JACK - E/R	82389	1	23-41-11 358/165/R006	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D06027		66-16842-19 JACK-BOOM MIC-CAPT	232A4400 81205	1	23-51-11 256/263/L045	YC001-YC050, YK907-YL430, YM652-YM670
D06027		2J-1869 JACK-BOOM MIC-CAPT	232A4400 81205	1	23-51-11 256/263/L045	YK901-YK906, YM643-YM651
D06029		66-16842-19 JACK-BOOM MIC-FO	232A4400 81205	1	23-51-21 243/263/R030	YC012-YC050, YK907-YL401
D06029		2J-1869 JACK-BOOM MIC-FO	232A4400 81205	1	23-51-21 243/263/R030	YK901-YK906, YL421-YM651
D06029		66-16842-19 JACK-BOOM MIC-FO	232A4400 81205	1	23-51-21 /263/R045	YM652-YM670
D06029	1	66-16842-19 JACK-BOOM MIC-FO	81205	1	23-51-21 243/263/R045	YC001-YC011
D06031	1	2J-1866A JACK-HEAD PHONE-CAPT	82389	1	23-51-11 240/263/L028	ALL
D06033	1	2J-1866A JACK-HEAD PHONE-FO	82389	1	23-51-21 243/263/R045	ALL

EQUIPMENT LIST

D280A103

Section D06000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06035	1	2J-1866A JACK-HEAD PHONE-10BS	8239	1	23-51-31 P061-00/ /	YC001-YC011
D06035	1	2J-1866A JACK	8239	1	23-51-31 P061-00/ /	YC012-YM670
D06037	1	2J-1866A JACK-HEAD PHONE-20BS	82389	1	23-51-31 264/258/L35	YC001-YC050, YK910-YK920
D06041	1	2J-1869 JACK-HAND MIC-CAPT	82389	1	23-51-11 224/223/L041	ALL
D06043	1	2J-1869 JACK-HAND MIC-FO	82389	1	23-51-21 220/238/R045	ALL
D06045	1	2J-1869 JACK-HAND MIC 10-BS	82389	1	23-51-31 P061-00/ /	YC001-YC011
D06045	1	2J-1869 JACK	82389	1	23-51-31 P061-00/ /	YC012-YM670
D06049	1	MS3126E10-6S JACK-OXY MIC CAPT	96906	1	23-51-11 230/215/L040	ALL
D06051	1	MS3126E10-6S JACK-OXY MIC-FO	96906	1	23-51-21 215/213/R034	ALL
D06053	1	ERA-0S-303-CLL JACK-OXY MIC-10BS	7K861	1	23-51-31 P006-00/ /	YC001-YC030, YK901-YK906
D06053	1	MS3126E10-6S PLUG	96906	1	23-51-31 P061-00/ /	YK907-YM670
D06057	1	2J-1865A INTPH JACK - R WHEEL WELL	82389	1	23-41-11 664/161/R072	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D06063J	1	BACC45FN16-24S RCPT-FMCS BITE ACCESS	81205	1	34-61-22 E005-02/ /	ALL
D06067J		BACC45FN16-24S7 RECP,BITE PRINTER	81205	1	34-61-22 264/255/L042	YC031-YM670
D06067J	1	BACC45FN16-24S7 RECP,BITE PRINTER	81205	1	34-61-22 264/255/L042	YC001-YC030
D06069		66-16842-19 BOOM - MIC HEADSET 1ST OBSV.	232A4400 81205	1	23-51-31 P061-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D06000

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07001	1	48-7190 PLUG-	02660	1	23-51-11 256/263/L045	YK901-YM670
D07003	1	48-7190-1 PLUG-	02660	1	23-51-11 256/263/L045	YK901-YM670
D07005	1	48-7191 RCPT-	02660	1	23-51-11 256/263/L045	YK901-YM670
D07007	1	48-7191-1 RCPT-	02660	1	23-51-11 256/263/L045	YK901-YM670
D07015	1	48-7190-1 PLUG - HANDSET JACK(CONTROL STAND)	02660	1	23-31-01 P008-00/ /	YC001-YC050, YM643-YM670
D07017	1	48-7191-1 RCPT - HANDSET JACK(CONTROL STAND)	02660	1	23-31-01 P008-00/ /	YC001-YC050, YM643-YM670
D07019	1	48-7190 PLUG - HANDSET JACK(CONTROL STAND)	02660	1	23-31-01 P008-00/ /	YC001-YC050, YM643-YM670
D07021	1	48-7191 RCPT - HANDSET JACK(CONTROL STAND)	02660	1	23-31-01 P008-00/ /	YC001-YC050, YM643-YM670
D07023	1	48-7190-1 PLUG-	02660	1	23-51-21 239/263/R028	YK901-YM670
D07035	1	48-7190 PLUG-	02660	1	23-51-21 239/263/R028	YK901-YM670
D07037	1	48-7191-1 RCPT-	82389	1	23-51-21 243/263/R045	YK901-YM670
D07039	1	48-7191 RCPT-	02660	1	23-51-21 239/263/R028	YK901-YM670
D07041	1	48-7190-1 PLUG -	02660	1	23-51-11 243/263/L030	YC001-YC050
D07041	1	48-7190-1 PLUG-	02660	1	23-51-11 243/263/L030	YK901-YM670
D07043	1	48-7191 RECP -	02660	1	23-51-11 243/263/L030	YC001-YC050
D07045	1	48-7190-1 PLUG -	02660	1	23-51-11 243/263/L030	YC001-YC050
D07047	1	48-7190 PLUG -	02660	1	23-51-11 243/263/L030	YC001-YC050

EQUIPMENT LIST

D280A103

Section D07000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07049	1	48-7191-1 RECP -	02660	1	23-51-11 243/263/L030	YC001-YC050
D07051	1	48-7190-1 PLUG -	02660	1	23-51-11 243/263/R030	YC001-YC050
D07051	1	48-7190-1 PLUG-	02660	1	23-51-21 243/263/R030	YK901-YM670
D07055	1	48-7191 RECP -	02660	1	23-51-11 243/263/R030	YC001-YC050
D07057	1	48-7190-1 PLUG -	02660	1	23-51-11 243/263/R030	YC001-YC050
D07059	1	48-7190 PLUG -	02660	1	23-51-11 243/263/R030	YC001-YC050
D07063	1	48-7191-1 RECP -	02660	1	23-51-11 243/263/R030	YC001-YC050
D07081	1	48-7191-1 RECP-BOOM MIC JACK	02660	1	23-51-31 P061-00/ /	YK901-YM670
D07083	1	48-7190 PLUG-BOOM MIC JACK	02660	1	23-51-31 P061-00/ /	YK901-YM670
D07085	1	48-7191 RECP-BOOM MIC JACK	02660	1	23-51-31 P061-00/ /	YK901-YM670
D07087	1	48-7190-1 PLUG-BOOM MIC JACK	02660	1	23-51-31 P061-00/ /	YK901-YM670
D07089	1	48-7190-1 PLUG-BOOM MIC JACK	02660	1	23-51-31 P061-00/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D07000

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07170J	1	48-7191 RCPT-	02660	1	35-21-21 323/291/L019	YC001-YL430
D07170J	1	48-7191 RCPT-	02660	1	35-21-21 322/290/L018	YM643-YM670
D07170P	1	48-7190 PLUG-	02660	1	35-21-21 323/291/L019	ALL
D07172J	1	48-7191 RCPT-	02660	1	35-21-21 950/295/L021	ALL
D07172P	1	48-7190 PLUG -	02660	1	35-21-21 950/295/L021	ALL
D07174J	1	48-7191 RCPT-	02660	1	33-21-11 415/295/L022	YC001-YC030, YK901-YM670
D07174P	1	48-7190 PLUG-	02660	1	33-21-12 415/295/L022	ALL
D07176J	1	48-7191-1 RCPT-	02660	1	35-21-21 316/290/L013	ALL
D07176P	1	48-7190-1 PLUG-	02660	1	35-21-21 314/290/L013	ALL
D07180J	1	48-7191 RCPT-	02660	1	35-21-31 352/294/R012	ALL
D07180P	1	48-7190 PLUG-	02660	1	35-21-31 352/294/R012	ALL
D07184J	1	48-7191-1 RCPT-	02660	1	33-51-12 338/292/R012	YK901-YM670
D07184P	1	48-7190-1 PLUG-	02660	1	33-51-12 338/292/R012	YK901-YM670
D07186J	1	48-7191-1 RCPT-	02660	1	33-51-14 933/298/L013	YK901-YM670
D07186P	1	48-7190-1 PLUG-	02660	1	33-51-14 933/298/L013	YK901-YM670
D07198J	1	48-7191-1 RCPT-	02660	1	33-51-12 500C/299/R012	YM643-YM652
D07198P	1	48-7190-1 PLUG-	02660	1	33-51-12 500C/299/R012	YM643-YM670

EQUIPMENT LIST

D280A103

Section D07100
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08002J	1	MTCPQKT2R22SGBD RECPT- E08-1	06090	1	23-11-11 E008-01/ /	YK907-YL401
D08002J	1	MTCPQKT2R22SGBD RECPT - E008-01	06090	1	23-11-11 E008-01/ /	YL421-YL430
D08002P	1	MTCPQKT2P22PGBD PLUG-CONDUCTIVE	06090	1	23-11-21 E008-001/ /	YK907-YL430
D08019J	1	BACC63CC18-31PN RCPT - CONDUCTIVE	81205	1	22-14-11 E001-04/ /	ALL
D08019JK	1	BACC10KD18 BACKSHELL	81205	1	22-14-11 / /	ALL
D08019P	1	BACC63CB18-31SN PLUG - CONDUCTIVE	81205	1	22-11-11 E001-04/ /	ALL
D08019PQ	1	BACC10KD18 BACKSHELL - CONDUCTIVE	81205	1	2211XX E001-04/ /	YC001-YC050
D08019PQ	1	BACC10KD18 BACKSHELL - CONDUCTIVE	81205	1	2211XX */*/*	YK901-YM670
D08056J	1	BACC63CS16G24S7 RECP-CONDUCTIVE CONNECTOR	81205	1	73-22-11 IFSS-233/ /	ALL
D08056JK	1	BACC10KF16 BAXKSHELL	81205	1	73-22-11 IFSS-233/ /	ALL
D08056P	1	BACC63BP16C24P7 PLUG-CONDUCTIVE	81205	1	74-11-11 NSTA 262/146/R013	ALL
D08056PQ	1	BACC10KF16 BACKSHELL	81205	1	74-11-11 / /	ALL
D08094J	1	CA66422-9 RECP	71468	1	24-21-11 IFSS 215/ /	ALL
D08094P	1	CA66434-6 PLUG-	71468	1	00-00-00 NSTA 245/145/L014	ALL

EQUIPMENT LIST

D280A103

Section D08000

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08105J	1	MTCPQKT1R2PGBC RCPT-CONDUCTIVE	06090	1	34-61-11 E005-02/ /	YC001-YC011
D08105J	1	MTCPQKT2R22PGBC RCPT-CONDUCTIVE	06090	1	34-61-11 E005-02/ /	YC012-YM670
D08105P	1	MTCPQKT1P2SGBC PLUG-	06090	1	34-61-11 E005-02/ /	YC001-YC011
D08105P	1	MTCPQKT2P22SGBC PLUG-	06090	1	34-61-11 E005-02/ /	YC012-YM670
D08123J	1	MTCPQKT2R22PGBA RCPT-CONDUCTIVE	06090	1	23-31-02 E004-01/ /	YC001-YL430
D08123J	1	MTCPQKT2R22PGBA RCPT-	06090	1	23-31-02 E004-01/ /	YM643-YM670
D08123P	1	MTCPQKT2P22SGBA PLUG-E4-1 SHELF	06090	1	23-31-02 E004-01/ /	YC001-YC030, YK901-YM670
D08156J	1	BACC63CS16G24S7 RECP-CONDUCTIVE CONNECTOR	81205	1	73-22-11 IFSS 233/ /	ALL
D08156JK	1	BACC10KF16 BACKSHELL	81205	1	73-22-11 IFSS 233/ /	ALL
D08156P	1	BACC63BP16C24P7 PLUG-CONDUCTIVE	81205	1	77-31-21 NSTA 263/146/L013	ALL
D08156PQ	1	BACC10KD16 BACKSHELL	81205	1	77-31-21 */*/*	ALL
D08189J	1	MTCPQKT1R2SGAA RCPT-CONDUCTIVE	06090	1	23-11-11 E008-01/ /	YC001-YC007
D08189J	1	MTCPQKT2R22SGAD RCPT-CONDUCTIVE	06090	1	23-11-11 E008-01/ /	YK907-YL401
D08189J	1	MTCPQKT2R22SGAD RCPT - CONDUCTIVE	06090	1	23-11-11 E008-01/ /	YL421-YL430
D08189P	1	MTCPQKT1P2PGAA PLUG-E8-1 SHELF	06090	1	23-11-11 E8-1/ /	YC001-YC007
D08189P	1	MTCPQKT1P2PGAA PLUG-E8-1 SHELF	06090	1	SPARE E008-01/ /	YC008-YC011
D08189P	1	MTCPQKT2P22PGAD PLUG-E8-1 SHELF	06090	1	23-11-11 E8-1/ /	YK907-YL430

EQUIPMENT LIST

D280A103

Section D08100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08194J	1	CA66422-9 RECP	71468	1	24-21-21 IFSS 215/ /	ALL
D08194P	1	CA66434-6 PLUG-	71468	1	24-21-21 NSTA 245/145/L14	ALL

EQUIPMENT LIST

D280A103

Section D08100
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08313J	1	BACC45FN12-12P9 RCPT - THRUST LEVER-1	81205	1	22-31-52 214/209/R1	ALL
D08313P	1	BACC45FT12-12S9 PLUG	81205	1	22-11-14 214/209/R1	YC001-YC019
D08313P	1	BACC45FT12-12S9 PLUG	81205	1	22-11-14 214/209/R001	YC020-YM670
D08313PQ	1	BACC10JS12 BACKSHELL	81205	1	22-11-14 / /	YC001-YC019
D08313PQ	1	BACC10JS12 BACKSHELL	81205	1	22-11-14 */*/	YC020-YM670
D08315J	1	BACC45FN12-12P6 RCTP - THRUST LEVER-2	81205	1	22-31-51 ENG 2/ /	ALL
D08315P	1	BACC45FT12-12S6 PLUG	81205	1	22-31-51 AF0222A/ /	ALL
D08315PQ	1	BACC10JC12 BACKSHELL	81205	1	22-11-14 */*/	ALL

EQUIPMENT LIST

D280A103

Section D08300
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08427J	1	BACC63CC20-41S RCPT	81205	1	23-34-02 438/218/R069	ALL
D08427JK		S280W604-37 BACKSHELL - 90 DEGREE - FOR D08427J	81205	1	23-34-02 438/218/R069	YC001-YC050
D08427JK		S280W604-37 BACKSHELL - 90 DEGREE	81205	1	23-34-02 */*/*	YK901-YM670
D08429J	1	BACC63CC20-41S RCPT	81205	1	23-34-02 438/218/L069	ALL
D08429JK		S280W604-37 BACKSHELL - 90 DEGREE - FOR D08429J	81205	1	23-34-02 438/218/L069	YC001-YC050
D08429JK		S280W604-37 BACKSHELL - 90 DEGREE	81205	1	23-34-02 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D08400
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08509J	1	MTCPQKT2R26SFAC RCPT-	06090	1	23-11-11 E008-01/ /	YC001-YC007, YK907-YL401
D08509J	1	MTCPQKT2R26SFAC RCPT -	06090	1	23-11-11 E008-01/ /	YL421-YL430
D08509P	1	MTCPQKT2P26PFAC PLUG-	06090	1	23-11-11 E8-1/ /	YC001-YC007
D08509P	1	MTCPQKT2P26PFAC PLUG-	06090	1	23-11-11 E008-01/ /	YK907-YL430
D08511J	1	MTCPQKT1R2SGAB RCPT-CONDUCTIVE	06090	1	23-11-11 E008-01/ /	YC001-YC007
D08511P	1	MTCPQKT1P2PGAB PLUG-CONDUCTIVE	06090	1	23-11-11 E8-1/ /	YC001-YC007
D08517J	1	121-39-9 JACK-E8-1 SHELF	91836	1	23-11-11 E008-01/ /	YC001-YC007, YK907-YL401
D08517J	1	121-39-9 JACK - E8-1 SHELF	91836	1	23-11-11 E008-01/ /	YL421-YL430
D08517P	1	125-95-9 PLUG-E8-1 SHELF	91836	1	23-11-11 E8-1/ /	YC001-YC007
D08517P	1	125-95-9 PLUG-E8-1 SHELF	91836	1	23-11-11 E008-01/ /	YK907-YL430
D08537J	1	BACC63CC20-41S RCPT	81205	1	23-34-02 683/220/R069	YK901-YL430
D08537J	1	BACC63CC20-41S RCPT	81205	1	23-34-02 680/210/R068	YM643-YM670
D08537JK		S280W604-37 BACKSHELL - 90 DEGREE	81205	1	23-34-02 */*/*	YK901-YM670
D08539J	1	BACC63CC20-41S RCPT	81205	1	23-34-02 683/220/L069	YK901-YL430
D08539J	1	BACC63CC20-41S RCPT	81205	1	23-34-02 680/210/L068	YM643-YM670
D08539JK		S280W604-37 BACKSHELL - 90 DEGREE	81205	1	23-34-02 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D08500

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08811J	1	MTCPQKT2R26SFBC RCPT-	06090	1	23-11-21 E008-01/ /	YK907-YL401
D08811J	1	MTCPQKT2R26SFBC RCPT -	06090	1	23-11-21 E008-01/ /	YL421-YL430
D08811P	1	MTCPQKT2P26PFBC PLUG-	06090	1	23-11-21 E008-01/ /	YK907-YL430
D08823J	1	121-39-9 RECPT- E08-01 SHELF	91836	1	23-11-21 E008-01/ /	YK907-YL401
D08823J	1	121-39-9 RCPT - E8-1 SHELF	91836	1	23-11-21 E088-01/ /	YL421-YL430
D08823P	1	125-95-9 PLUG- E08-01 SHELF	91836	1	23-11-21 E008-01/ /	YK907-YL430

EQUIPMENT LIST

D280A103

Section D08800

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09002J	9	48-10R18-31P6 RECEPTACLE (737-EB34-0155)	CUST	1	34-49-11 259/180/L020	YC003-YC006
D09002P	9	48-16R18-31S6 PLUG-CONDUCTIVE (737-EB34-0155)	CUST	1	34-41-11 J00022/ /	YC003
D09002P	9	48-16R18-31S6 PLUG-CONDUCTIVE (737-EB34-0155)	CUST	1	34-41-11 259/180/L020	YC004-YC006
D09003J	9	48-10R18-31P6 RECPT-CONDUCTIVE (737-EB34-0155)	CUST	1	34-49-11 E001-01/ /	YC001-YC007
D09003P	9	48-16R18-31S6 PLUG-CONDUCTIVE (737-EB34-0155)	CUST	1	34-49-11 E001-01/ /	YC001-YC007
D09004P	9	48-16R14-15S PLUG	CUST	1	34-49-11 P003-07/ /	YC001-YC002
D09004P	9	48-16R14-15S PLUG (737-EB34-0155)	CUST	1	34-49-11 P003-07/ /	YC003-YC007

EQUIPMENT LIST

D280A103

Section D09000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09113J	9	BACC45FN18-31S7 RECP	CUST	1	23-70-11 E004-01/ /	YC001-YC030
D09113P	9	BACC45FT18-31P7 PLUG	CUST	1	23-70-11 E004-01/ /	YC001-YC030
D09114J	9	BACC45FN18-31S8 RECP	CUST	1	23-70-11 E004-01/ /	YC001-YC030
D09114P	9	BACC45FT18-31P8 PLUG	CUST	1	23-70-11 E004-01/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D09100
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09455	9	MS27484T12F35S PLUG	CUST	1	23-70-11 P008-00/ /	YC001-YC030
D09462	9	MS27484T12F8S PLUG	CUST	1	23-70-11 P008-00/ /	YC001-YC030
D09463A	9	BKAD1-125-30001 PLUG	CUST	1	23-70-11 E004-01/ /	YC001-YC030
D09463B	9	BKAD1-125-30001FO PLUG	CUST	1	23-70-11 E004-01/ /	YC001-YC030
D09464A	9	DEMA-9S PLUG	CUST	1	23-70-11 292/ /	YC001-YC030
D09468A	9	DEMA-9S PLUG	CUST	1	23-70-11 355/ /	YC001-YC030
D09472A	9	DEMA-9S PLUG	CUST	1	23-70-11 355/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D09400
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10002	1	DPX2MB-67S67S-33B-0005 PLUG-PLATE ASSY	71468	1	21-51-21 E004-01/ /	YC001-YL430
D10002A	1	PARTAD10002 PLUG-AIR COND RELAY NO 2		0	21-51-21 E004-01/ /	YC001-YC026
D10002A	1	PARTAD10002 PLUG-AIR COND RELAY NO 2		0	21-51-21 */**	YC028-YL430
D10002B	1	PARTBOFD10002 PLUG-AIR COND RELAY NO 2		0	21-51-21 E004-01/ /	YC001-YC026
D10002B	1	PARTBOFD10002 PLUG-AIR COND RELAY NO 2		0	21-51-21 */**	YC028-YL430
D10009	1	BACC66F13C01AA01 PLUG PLATE ASSEMBLY	81205	1	22-31-11 E001-01/ /	YC001-YC030
D10009A	1	PARTAOFD10009 PLUG		0	22-31-11 E001-01/ /	YC001-YC030
D10009B	1	PARTBOFD10009 PLUG		0	22-31-11 E001-01/ /	YC001-YC030
D10009C	1	PARTCOFD10009 PLUG		0	22-31-11 E001-01/ /	YC001-YC030
D10010	1	172168-1 PLUG-	00779	1	33-21-12 616/270/R57	YC001-YL430
D10012	1	172160-1 RCPT-	00779	1	33-21-12 616/269/R58	YC001-YL430
D10013	1	BACC63BP12C12S6 PLUG- STANDBY RUDDER PCU	81205	1	27-24-11 1138/375/R2	YC001-YC019
D10013	1	BACC63BP12C12S6 PLUG- STANDBY RUDDER PCU	81205	1	27-24-11 RUD76.4/ /	YC020-YM670
D10013 T	1	BACC10KE12 BACKSHELL	81205	1	27-24-11 1138/375/R2	YC001-YC026
D10013 T	1	BACC10KE12 BACKSHELL	81205	1	27-24-11 */**	YC028-YM670
D10014	1	172160-1 RCPT-	00779	1	33-21-12 590/269/L058	YC001-YL430
D10015	1	BACC63CB12-12S6 PLUG-AOA SENSOR-L	81205	1	34-21-12 193/203/L029	ALL

EQUIPMENT LIST

D280A103

Section D10000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10015 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	34-21-12 */**	ALL
D10016	1	172168-1 PLUG-	00779	1	33-21-12 616/271/L056	YC001-YL430
D10017	1	BACC63CB12-12S6 PLUG-AOA SENSOR-R	81205	1	34-21-22 193/204/R029	YC001-YM652
D10017 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	34-21-22 */**	YC001-YM652
D10019	1	BACC45FT22-55S PLUG	81205	1	23-41-11 305/290/L014	YC001-YC003
D10019	1	BACC45FT22-55S PLUG	81205	1	23-41-11 LAV A/277/L014	YC004-YC050
D10019	1	BACC45FT22-55S PLUG	81205	1	23-41-11 306/290/L014	YK901-YM670
D10019 T	1	450EB001C22-347 BACKSHELL - 45	81205	1	23-41-11 */**	ALL
D10021	1	BACC45FT22-55S PLUG - LAV D ATT HANDSET	81205	1	23-42-12 938/292/L019	ALL
D10021 T	1	BACC10JC22 BACKSHELL	81205	1	23-42-12 949/ /	YC001-YL430
D10021 T	1	BACC10JC22 BACKSHELL	81205	1	23-42-12 */**	YM643-YM670
D10025	1	BACC45FT14-15S RECEPTACLE-SERVO MOTOR	81205	1	22-31-31 233/198/L7	ALL
D10025 T	1	BACC10JS14 BACKSHELL	81205	1	22-31-31 / /	ALL
D10027	1	BACC45FT14-15S RECEPTACLE-SERVO MOTOR	81205	1	22-31-41 233/200/R008	ALL
D10027 T	1	BACC10JS14 BACKSHELL	81205	1	22-31-41 / /	ALL
D10029	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 197/218/L007	ALL

EQUIPMENT LIST

D280A103

Section D10000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10030J	1	123-22-5 JACK - TNC	81205	1	31-62-42 235/208/36	YK907-YK911, YK918, YL421- YL426, YM643- YM651
D10030J	1	122-37-9 BULKHEAD JACK	81205	1	31-62-42 P009-00/ /	YK912, YK919, YL401, YL427- YL429, YM652
D10030P	1	125-94-9 PLUG - TNC	91836	1	31-62-42 235/208/L036	YK907-YK911, YK918, YL421- YL426, YM643- YM651
D10030P	1	125-94-9 PLUG	81205	1	31-62-42 190/214/0	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
D10031	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/219/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10032J	1	123-22-5 JACK - TNC	81205	1	31-62-42 235/208/36	YK907-YK911, YK918, YL421- YL426, YM643- YM651
D10032J	1	122-37-9 BULKHEAD JACK	81205	1	31-62-42 P009-00/ /	YK912-YK917, YK919-YL401, YL427-YL429, YM652
D10032P	1	125-94-9 PLUG - TNC	91836	1	31-62-42 235/208/R036	YK907-YK911, YK918, YL421- YL426, YM643- YM651
D10032P	1	125-94-9 PLUG	81205	1	31-62-42 190/214/0	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670

EQUIPMENT LIST

D280A103

Section D10000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10033	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/219/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10034J	1	123-22-5 JACK - TNC	81205	1	31-62-42 235/208/36	YK907-YK911, YK918, YL421- YL426, YM643- YM651
D10034J	1	122-37-9 BULKHEAD JACK	81205	1	31-62-42 P009-00/ /	YK912-YK917, YK919-YL401, YL427-YL429, YM652
D10034P	1	125-94-9 PLUG - TNC	91836	1	31-62-42 235/208/R036	YK907-YK911, YK918, YL421- YL426, YM643- YM651
D10034P	1	125-94-9 PLUG	81205	1	31-62-42 190/214/0	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
D10035	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/219/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10037	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/219/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10039	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/219/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D10000

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10041	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/219/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10043	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 197/218/R007	ALL
D10045	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/219/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10046	1	BACC45FT16-24S PLUG-AUX DIM/TEST MODULE	81205	1	33-18-19 P006-03/ /	ALL
D10047	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/219/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10049	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/219/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10051	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/219/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10053	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/219/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10055	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/219/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10056	1	BACC63CB10-5S6 PLUG-	81205	1	21-51-15 576/157/L036	YC001-YL430
D10056 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	21-51-15 */*/	YC001-YL430
D10057	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 197/217/L007	ALL
D10058	1	BACC63CB10-5S6 PLUG	81205	1	21-51-25 576/160/R032	YC001-YL430

EQUIPMENT LIST

D280A103

Section D10000

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10058 T	1	BACC10KD10 BACKSHELL-STRAIGHT	81205	1	21-51-21 */**	YC001-YL430
D10059	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/218/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10061	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/218/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10063	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/218/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10064	1	BACC45FN22-55P6 RECPT - TEST CONNECTOR 1	81205	1	27-28-11 E001-01/ /	ALL
D10064 T	1	BACC10JS22 BACKSHELL	81205	1	27-28-11 E001-01/ /	YC001-YC050
D10064 T	1	BACC10JS22 BACKSHELL	81205	1	27-28-11 */**	YK901-YM670
D10065	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/218/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10067	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/218/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D10000

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10069	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-12 193/218/L007	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10071	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 197/217/R007	ALL
D10073	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/218/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10075	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/218/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10076	1	BACC63CD24-22SW RCPT-	81205	1	25-31-11 1000/295/R024	YK901-YM670
D10077	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/218/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10079	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/218/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10081	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/218/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10082	1	48-7191 RCPT-	02660	1	33-51-21 995/247/L051	YC001-YC030, YK901-YL430
D10082	1	48-7191 RCPT-	02660	1	33-51-22 995/247/L051	YM643-YM652
D10083	1	1075-13-9 PLUG - (K-LOC)	91836	1	31-62-22 193/218/R007	YC001-YC030, YK901-YL429, YM643-YM652
D10084	1	48-7190 PLUG-	02660	1	33-51-21 995/247/L051	YC001-YC030, YK901-YL430
D10084	1	48-7190 PLUG-	02660	1	33-51-22 995/247/L051	YM643-YM652

EQUIPMENT LIST

D280A103

Section D10000

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10086	1	48-7191 RCPT-	02660	1	33-51-22 995/237/R052	ALL
D10088	1	48-7190 PLUG-	02660	1	33-51-22 995/236/R052	ALL

EQUIPMENT LIST

D280A103

Section D10000
Page 8 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10126	1	BACC45FN10-5S RCPT-	81205	1	33-51-21 498/202/L014	YC001-YC050
D10130	1	BACC45FN10-5S RCPT-	81205	1	33-51-22 727B/204/L010	YC001-YC030
D10132	1	BACC45FN10-5S RCPT-	81205	1	33-51-22 783/204/L010	YC001-YC030
D10135	1	BACC66H39F01AA01 PLUG PLATE ASSEMBLY	81205	1	22-11-11 E001-01/ /	ALL
D10135A	1	PARTAOFD10135 PLUG		0	22-11-11 E001-01/ /	YC001-YC050
D10135A	1	PARTAOFD10135 PLUG		0	22-11-11 */*/*	YK901-YM670
D10135B	1	PARTBOFD10135 PLUG		0	22-11-11 E001-01/ /	YC001-YC050
D10135B	1	PARTBOFD10135 PLUG		0	22-11-11 */*/*	YK901-YM670
D10135C	1	PARTCOFD10135 PLUG		0	22-11-11 E001-01/ /	YC001-YC050
D10135C	1	PARTCOFD10135 PLUG		0	22-11-11 */*/*	YK901-YM670
D10137	1	BACC66H39F01AA01 PLUG PLATE ASSY	81205	1	22-11-11 E001-04/ /	ALL
D10137A	1	PARTAOFD10137 PLUG - FLIGHT CONTROL COMPUTER - B		0	22-11-11 E001-04/ /	YC001-YC050
D10137A	1	PARTAOFD10137 PLUG - FLIGHT CONTROL COMPUTER - B		0	22-11-11 */*/*	YK901-YM670
D10137B	1	PARTBOFD10137 PLUG - FLIGHT CONTROL COMPUTER - B		0	22-11-11 E001-04/ /	YC001-YC050
D10137B	1	PARTBOFD10137 PLUG - FLIGHT CONTROL COMPUTER - B		0	22-11-11 */*/*	YK901-YM670
D10137C	1	PARTCOFD10137 PLUG - FLIGHT CONTROL COMPUTER - B		0	22-11-11 E001-04/ /	YC001-YC050
D10137C	1	PARTCOFD10137 PLUG - FLIGHT CONTROL COMPUTER - B		0	22-11-11 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D10100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10138	1	BACC45FN10-5S RCPT-	81205	1	33-51-21 500/208/L010	YC001-YC030
D10159	1	126-58-9 PLUG-COAX	91836	1	34-53-31 312/178/R17	ALL
D10161	1	125-88-9 PLUG-COAX	91836	1	34-53-31 E001-01/ /	ALL
D10163	1	125-88-9 PLUG-COAX	91836	1	34-53-31 316/178/R017	YC001-YC030, YK901-YM670
D10167	1	BACC45FN8-3S RECP-	81205	1	78-35-11 251/195/L2	YC001-YC030
D10167	1	BACC45FN8-3S RECP-	81205	1	78-35-11 250/195/L002	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10167 T	1	BACC10JS08 BACKSHELL	81205	1	78-35-11 TBD/ /	YC001-YC030
D10167 T	1	BACC10JS08 BACKSHELL	81205	1	78-35-11 */**	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10169	1	BACC45FN08-3S7 RECP-	81205	1	78-35-21 251/196/L002	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10169 T	1	BACC10JS08 BACKSHELL	81205	1	78-35-21 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10171	1	BACC45FT10-5S8 PLUG	81205	1	78-34-11 214/209/L1	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D10100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10171 T	1	BACC10JS10 BACKSHELL	81205	1	78-34-11 TBD/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10171J	1	BACC45FN10-5P8 RCPT-	81205	1	78-34-11 214/209/L001	ALL
D10173	1	BACC45FT10-5S9 PLUG	81205	1	78-34-21 AF0222A/ /	YC001-YC003
D10173	1	BACC45FT10-5S9 PLUG-	81205	1	78-34-21 AF0222A/ /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10173 T	1	BACC10JC10 BACKSHELL	81205	1	78-34-21 TBD/ /	YC001-YC003
D10173 T	1	BACC10JC10 BACKSHELL-	81205	1	78-34-21 / /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10173J	1	BACC45FN10-5P9 RCPT-	81205	1	78-34-21 AF0222A/ /	ALL
D10175	1	BACC63CC10-5SN CDS TEST CONNECTOR	81205	1	31-62-15 372/185/R058	YC001-YC030, YK901-YM670
D10175 T	1	BACC10KD10 BACKSHELL - CONDUCTIVE	81205	1	31-62-15 */**	YC001-YC030, YK901-YM670
D10180	1	S280W557-121 PLUG-	81205	1	33-27-22 959/290/R004	YC001-YC026
D10180	1	BACC65AJ121S PLUG-	81205	1	33-27-22 959/290/R004	YC028-YM670
D10193	1	BACC45FT24-61S6 PLUG-DATA LOADER CONTROL PANEL	81205	1	31-32-15 P061-01/ /	YC001-YC050
D10193	1	BACC45FT24-61S6 PLUG-DATA LOADER CONTROL PANEL	81205	1	31-32-15 P006-00/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D10100

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10193 T	1	BACC10JS24 BACKSHELL	81205	1	31-32-15 P061-00/ /	ALL
D10197		BACC63BP14C15SN PLUG-RUDDER AUTHORITY LIMITER SOLENOID	81205	1	27-25-11 STA1087/ /	YC001-YC011
D10197		BACC63BP14C15SN PLUG-RUDDER AUTHORITY LIMITER SOLENOID	81205	1	27-25-11 1087/ /	YC012-YC019
D10197		BACC63BP14C15SN PLUG-RUDDER AUTHORITY LIMITER SOLENOID	81205	1	27-25-11 RUD66.4/ /	YC020-YC030
D10197	1	BACC63BP14C15SN PLUG-	81205	1	27-25-11 RUD66.4/ /	YC031-YM670
D10197 T		BACC10KE14 BACKSHELL-90 DEGREE	81205	1	27-25-11 / /	YC001-YC030
D10197 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	27-25-11 */*/*	YC031-YM670
D10199	1	BACC45FT12-12S PLUG-	81205	1	27-62-21 197/202/L7	YC001-YC007
D10199	1	BACC45FT12-12S PLUG-	81205	1	27-62-21 197/202/L007	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10199 T	1	BACC10JS12 BACKSHELL-	81205	1	27-62-21 / /	YC001-YC007
D10199 T	1	BACC10JS12 BACKSHELL-	81205	1	27-62-21 */*/*	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D10100
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10201	1	DBMA-25S RECP	71468	1	23-32-31 451/294/L035	YC001-YC030
D10201	1	DBMA-25S RCPT	71468	1	23-32-31 451/294/L035	YK901-YM670
D10201 T		D110277 SPRING LATCH ASSY	71468	2	23-32-31 / /	YC001-YC030
D10201 T		D110277 SPRING LATCH ASSY	71468	2	23-32-31 */**	YK901-YM670
D10201 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-31 / /	YC001-YC030
D10201 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-31 */**	YK901-YM670
D10204	1	PT08SE-10-6S-SR- PLUG-COAX	77820	1	34-53-31 316/162/L025	ALL
D10205	1	CAMA-11W1P PLUG	71771	1	23-32-31 457/294/L030	YC001-YC019
D10205	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-31 457/294/L030	YC020-YC050
D10205	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-31 455/295/L030	YK901-YM670
D10205 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-31 / /	YC001-YC019
D10205 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-31 / /	YC001-YC019
D10205 U		CDSA-2P BACKSHELL	06090	1	23-32-31 */**	YC020-YM670
D10206	1	PT08SE-10-6S-SR- PLUG-COAX	77820	1	34-53-31 316/163/L025	ALL
D10207	1	CAMA-11W1P PLUG	71771	1	23-32-31 451/296/L31	YC001-YC019
D10207	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-31 451/296/L31	YC020-YC050
D10207	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-31 451/294/L031	YK901-YL430

EQUIPMENT LIST

D280A103

Section D10200

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10207	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-31 450/270/L035	YM643-YM670
D10207 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-31 / /	YC001-YC019
D10207 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-31 / /	YC001-YC019
D10207 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-31 */*/	YC020-YC050
D10207 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-31 */*/	YK901-YM670
D10211	1	DBMA-25P PLUG	71468	1	23-32-41 450/294/L31	YC001-YC030
D10211 T		D110278 END DISC LATCH ASSY	71468	2	23-32-41 / /	YC001-YC030
D10211 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-41 / /	YC001-YC030
D10213	1	CAMA-11W1P PLUG	71771	1	23-32-32 449/293/L30	YC001-YC019
D10213	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-32 449/293/L30	YC020-YC050
D10213	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-32 450/295/L030	YK901-YM670
D10213 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-32 / /	YC001-YC019
D10213 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-32 / /	YC001-YC019
D10213 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-32 */*/	YC020-YC050
D10213 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-32 */*/	YK901-YM670
D10215	1	CAMA-11W1P PLUG	71771	1	23-32-32 444/293/L31	YC001-YC019
D10215	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-32 444/293/L31	YC020-YC050

EQUIPMENT LIST

D280A103

Section D10200

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10215	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-32 450/295/L035	YK901-YM670
D10215 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-32 / /	YC001-YC019
D10215 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-32 / /	YC001-YC019
D10215 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-32 */**	YC020-YC050
D10215 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-32 */**	YK901-YM670
D10221	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-33 450/295/L035	YK901-YM670
D10221 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-33 */**	YK901-YM670
D10223	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-33 450/295/L035	YK901-YM670
D10223 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-33 */**	YK901-YM670
D10227	1	DBMA-25P PLUG	71468	1	23-32-41 458/292/L037	YK901-YL430
D10227	1	DBMA-25P PLUG	71468	1	23-32-41 450/295/L035	YM643-YM670
D10227 T		D110278 END DISC LATCH ASSY	71468	2	23-32-41 */**	YK901-YM670
D10227 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-41 */**	YK901-YM670
D10229	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-34 450/295/L035	YK901-YL430
D10229 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-34 */**	YK901-YL430
D10231	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-34 459/291/L038	YK901-YL430
D10231 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-34 */**	YK901-YL430

EQUIPMENT LIST

D280A103

Section D10200

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10233	1	DBMA-25S RECP	71468	1	23-32-41 500F+10/295/L036	YC001-YC030
D10233	1	DBMA-25S RCPT	71468	1	23-32-41 500F+10/295/L036	YK901-YM670
D10233 T		D110277 SPRING LATCH ASSY	71468	2	23-32-41 */**	YC001-YC030
D10233 T		D110277 END DISC LATCH ASSY	71468	2	23-32-41 */**	YK901-YM670
D10233 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-41 / /	YC001-YC030
D10233 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-41 */**	YK901-YM670
D10237	1	CAMA-11W1P PLUG	71771	1	23-32-41 500F+18/294/L31	YC001-YC019
D10237	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-41 500F+18/294/L31	YC020-YC050
D10237	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-41 500F+20/295/L031	YK901-YL430
D10237	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-41 550/295/L035	YM643-YM670
D10237 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-41 / /	YC001-YC019
D10237 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-41 / /	YC001-YC019
D10237 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-41 */**	YC020-YC050
D10237 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-41 */**	YK901-YM670
D10239	1	CAMA-11W1P PLUG	71771	1	23-32-41 551/297/L032	YC001-YC019
D10239	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-41 551/297/L032	YC020-YC050
D10239	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-41 500F+10/295/L035	YK901-YL430

EQUIPMENT LIST

D280A103

Section D10200

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10239	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-41 550/295/L035	YM643-YM670
D10239 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-41 / /	YC001-YC019
D10239 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-41 / /	YC001-YC019
D10239 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-41 */**	YC020-YC050
D10239 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-41 */**	YK901-YM670
D10245	1	CAMA-11W1P PLUG	71771	1	23-32-42 500F+10/294/L31	YC001-YC019
D10245	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-42 500F+10/294/L31	YC020-YC050
D10245	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-42 500F+10/295/L035	YK901-YL430
D10245	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-42 550/295/L035	YM643-YM670
D10245 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-42 / /	YC001-YC019
D10245 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-42 / /	YC001-YC019
D10245 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-42 */**	YC020-YC050
D10245 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-42 */**	YK901-YM670
D10247	1	CAMA-11W1P PLUG	71771	1	23-32-42 500F+6/294/L32	YC001-YC019
D10247	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-42 500F+6/294/L031	YC020-YC050
D10247	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-42 500F+10/295/L035	YK901-YL430
D10247	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-42 550/295/L035	YM643-YM670

EQUIPMENT LIST

D280A103

Section D10200

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10247 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-42 / /	YC001-YC019
D10247 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-42 / /	YC001-YC019
D10247 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-42 */*/	YC020-YC050
D10247 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-42 */*/	YK901-YM670
D10253	1	CAMA-11W1P PLUG	71771	1	23-32-43 500F+6/290/L37	YC001-YC019
D10253	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-43 500F+6/290/L37	YC020-YC050
D10253	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-43 500F+10/295/L035	YK901-YL430
D10253 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-43 / /	YC001-YC019
D10253 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-43 / /	YC001-YC019
D10253 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-43 */*/	YC020-YC050
D10253 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-43 */*/	YK901-YL430
D10254	1	BACS16X1A RELAY SOCKET	81205	1	33-45-11 J004-00/ /	YK901-YM670
D10255	1	CAMA-11W1P PLUG	71771	1	23-32-43 500F+9/290/L37	YC001-YC019
D10255	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-43 500F+9/290/L37	YC020-YC050
D10255	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-43 500F+10/295/L035	YK901-YL430
D10255 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-43 / /	YC001-YC019
D10255 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-43 / /	YC001-YC019

EQUIPMENT LIST

D280A103

Section D10200

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10255 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-43 */**	YC020-YC050
D10255 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-43 */**	YK901-YL430
D10265	1	DBMA-25S RECP	71468	1	23-32-51 716/295/L035	YC001-YC030
D10265	1	DBMA-25S RCPT	71468	1	23-32-51 716/295/L035	YK901-YM670
D10265 T		D110277 SPRING LATCH ASSY	71468	2	23-32-51 / /	YC001-YC030
D10265 T		D110277 SPRING LATCH ASSY	71468	2	23-32-51 */**	YK901-YM670
D10265 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-51 / /	YC001-YC030
D10265 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-51 */**	YK901-YM670
D10269	1	CAMA-11W1P PLUG	71771	1	23-32-51 702/294/L31	YC001-YC019
D10269	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-51 702/294/L31	YC020-YC050
D10269	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-51 704/295/L031	YK901-YL430
D10269	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-51 710/295/L035	YM643-YM670
D10269 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-51 / /	YC001-YC019
D10269 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-51 / /	YC001-YC019
D10269 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-51 */**	YC020-YC050
D10269 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-51 */**	YK901-YM670
D10271	1	CAMA-11W1P PLUG	71771	1	23-32-51 697/294/L31	YC001-YC019

EQUIPMENT LIST

D280A103

Section D10200

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10271	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-51 697/294/L31	YC020-YC050
D10271	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-51 695/295/L035	YK901-YL430
D10271	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-51 710/295/L035	YM643-YM670
D10271 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-51 / /	YC001-YC019
D10271 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-51 / /	YC001-YC019
D10271 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-51 */*/	YC020-YC050
D10271 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-51 */*/	YK901-YM670
D10277	1	CAMA-11W1P PLUG	71771	1	23-32-52 694/294/L31	YC001-YC019
D10277	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-52 694/294/L31	YC020-YC050
D10277	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-52 695/295/L035	YK901-YL430
D10277	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-52 710/295/L035	YM643-YM670
D10277 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-52 / /	YC001-YC019
D10277 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-52 / /	YC001-YC019
D10277 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-52 */*/	YC020-YC050
D10277 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-52 */*/	YK901-YM670
D10279	1	CAMA-11W1P PLUG	71771	1	23-32-52 690/294/L31	YC001-YC019
D10279	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-52 690/294/L31	YC020-YC050

EQUIPMENT LIST

D280A103

Section D10200

Page 8

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10279	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-52 695/295/L035	YK901-YL430
D10279	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-52 710/295/L035	YM643-YM670
D10279 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-52 / /	YC001-YC019
D10279 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-52 / /	YC001-YC019
D10279 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-52 */*/*	YC020-YC050
D10279 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-52 */*/*	YK901-YM670
D10283	1	DBMA-25P PLUG	71468	1	23-32-61 695/291/L37	YC001-YC007
D10283	1	DBMA-25P PLUG	71468	1	23-32-61 695/291/L037	YC008-YC030, YK901-YM670
D10283 T		D110278 END LATCH DISC ASSY	71468	2	23-32-61 / /	YC001-YC030
D10283 T		D110278 END DISC LATCH ASSY	71468	2	23-32-61 */*/*	YK901-YM670
D10283 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-61 / /	YC001-YC030
D10283 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-61 */*/*	YK901-YM670
D10285	1	CAMA-11W1P PLUG	71771	1	23-32-53 670/290/L37	YC001-YC019
D10285	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-53 670/290/L37	YC020-YC050
D10285	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-53 695/295/L035	YK901-YL430
D10285 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-53 / /	YC001-YC019
D10285 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-53 / /	YC001-YC019

EQUIPMENT LIST

D280A103

Section D10200

Page 9

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10285 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-53 */**	YC020-YC050
D10285 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-53 */**	YK901-YL430
D10287	1	CAMA-11W1P PLUG	71771	1	23-32-53 694/290/L37	YC001-YC019
D10287	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-53 694/290/L37	YC020-YC050
D10287	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-53 695/295/L035	YK901-YL430
D10287 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-53 / /	YC001-YC019
D10287 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-53 / /	YC001-YC019
D10287 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-53 */**	YC020-YC050
D10287 U		CDSA-2P 90 DEGREE BACKSHELL	06060	1	23-32-53 */**	YK901-YL430
D10297	1	DBMA-25S RECP	71468	1	23-32-61 727J+12/297/L035	YC001-YC030
D10297	1	DBMA-25S RCPT	71468	1	23-32-61 727J+12/297/L035	YK901-YM670
D10297 T		D110277 END DISC LATCH ASSY	71468	2	23-32-61 */**	YK901-YM670
D10297 T	1	D110277 SPRING LATCH ASSY	71468	2	23-32-61 / /	YC001-YC030
D10297 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-61 / /	YC001-YC030
D10297 U		234A032-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-61 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D10200
Page 10 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10301	1	CAMA-11W1P PLUG	71771	1	23-32-61 727J+1/272/L50	YC001-YC019
D10301	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-61 727J+1/272/L50	YC020-YC050
D10301	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-61 727J+19/295/L031	YK901-YL430
D10301	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-61 777/295/L035	YM643-YM670
D10301 T	1	D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-61 / /	YC001-YC019
D10301 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-61 / /	YC001-YC019
D10301 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-61 */**	YC020-YC050
D10301 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-61 */**	YK901-YM670
D10303	1	CAMA-11W1P PLUG	71771	1	23-32-61 727J+11/294/L32	YC001-YC019
D10303	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-61 727J+11/294/L32	YC020-YC050
D10303	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-61 727J+10/295/L035	YK901-YL430
D10303	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-61 777/295/L035	YM643-YM670
D10303 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-61 / /	YC001-YC019
D10303 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06060	1	23-32-61 / /	YC001-YC019
D10303 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06060	1	23-32-61 */**	YC020-YM670
D10309	1	CAMA-11W1P PLUG	71771	1	23-32-62 727J+8/294/L31	YC001-YC019
D10309	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-62 727J+8/294/L31	YC020-YC050

EQUIPMENT LIST

D280A103

Section D10300

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10309	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-62 727J+10/295/L035	YK901-YL430
D10309	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-62 777/295/L035	YM643-YM670
D10309 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-62 / /	YC001-YC019
D10309 U		234A021-3 REQUESTED BY T. THROOP OF WIRE INSTL.	06090	1	23-32-62 / /	YC001-YC019
D10309 U		CDSA-2P REQUESTED BY T. THROOP OF WIRE INSTL.	06090	1	23-32-62 */**	YC020-YC050
D10309 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-62 */**	YK901-YM670
D10311	1	CAMA-11W1P PLUG	71771	1	23-32-62 727J+4/294/L312	YC001-YC019
D10311	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-62 727J+4/294/L312	YC020-YC050
D10311	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-62 727J+10/295/L035	YK901-YL430
D10311	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-62 777/295/L035	YM643-YM670
D10311 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-62 / /	YC001-YC019
D10311 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-62 / /	YC001-YC019
D10311 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-62 */**	YC020-YC050
D10311 U		CDSA-2P 90 DEGREE BACKSHELL	06060	1	23-32-62 */**	YK901-YM670
D10317	1	CAMA-11W1P PLUG	71771	1	23-32-63 727J+4/290/L37	YC001-YC019
D10317	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-63 727J+4/290/L37	YC020-YC050
D10317	1	CAMA11W1PE-K87 PLUG	71468	1	23-32-63 727J+10/295/L035	YK901-YL430

EQUIPMENT LIST

D280A103

Section D10300

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10317 T	1	D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-63 / /	YC001-YC019
D10317 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-63 / /	YC001-YC019
D10317 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06090	1	23-32-63 */*/	YC020-YC050
D10317 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-63 */*/	YK901-YL430
D10319	1	CAMA-11W1P PLUG	71771	1	23-32-63 735/290/L37	YC001-YC019
D10319	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-63 735/290/L37	YC020-YC050
D10319	1	CAMA11W1PE-K87 PLUG	71771	1	23-32-63 727J+10/295/L035	YK901-YL430
D10319 T		D110278 END DISC LATCH ASSEMBLY	71468	2	23-32-63 / /	YC001-YC019
D10319 U		234A021-3 90 DEGREE THERMOFIT BACKSHELL	06060	1	23-32-63 / /	YC001-YC019
D10319 U		CDSA-2P 90 DEGREE THERMOFIT BACKSHELL	06060	1	23-32-63 */*/	YC020-YC050
D10319 U		CDSA-2P 90 DEGREE BACKSHELL	06090	1	23-32-63 */*/	YK901-YL430
D10328	1	MS25182-2 PLUG-AUX BATTERY	96906	1	24-31-12 378/165/L008	YC001-YC030, YK901-YM670
D10330	1	BACC45FT12-12P PLUG-AUX BATTERY SENSOR	81205	1	24-31-12 378/162/L005	YC001-YC030, YK901-YM670
D10330 T	1	BACC10GH12 BACKSHELL	81205	1	24-31-12 */*/	YC001-YC030, YK901-YM670
D10342	1	BACC45FT14-12S PLUG-AUX BATT CHARGER	81205	1	24-31-12 E003-03/ /	YC001-YC030, YK901-YM670
D10342 T	1	BACC10JC14 BACKSHELL-90 DEGREE	81205	1	24-31-12 */*/	YK901-YM670
D10345	1	BACC45FT12-12S PLUG	81205	1	23-32-31 385/274/L013	YC001-YC050

EQUIPMENT LIST

D280A103

Section D10300

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10347	1	755-78-9 PLUG	91836	1	23-32-31 385/274/L013	YC001-YC050
D10349	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 387/274/L013	YC001-YC050
D10349 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10351	1	BACC45FT12-12S PLUG	81205	1	23-32-31 365/273/R02	YC001-YC050
D10353	1	755-78-9 PLUG	91836	1	23-32-31 371/273/R02	YC001-YC050
D10355	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 391/272/R033	YC001-YC050
D10355 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10357	1	BACC45FT12-12S PLUG	81205	1	23-32-32 477/272/L033	YC001-YC050
D10359	1	755-78-9 PLUG	91836	1	23-32-32 478/272/L033	YC001-YC050
D10361	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 446/272/L033	YC001-YC050
D10361 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10363	1	BACC45FT12-12S PLUG	81205	1	23-32-32 480/272/R50	YC001-YC050
D10365	1	755-78-9 PLUG	91836	1	23-32-32 479/272/R50	YC001-YC050
D10367	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 489/272/R033	YC001-YC050
D10367 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10381	1	BACC45FT12-12S PLUG	81205	1	23-32-41 500C+11/272/L033	YC001-YC050
D10383	1	755-78-9 PLUG	91836	1	23-32-41 500C+11/272/L033	YC001-YC050

EQUIPMENT LIST

D280A103

Section D10300

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10385	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 500C+7/272/L033	YC001-YC050
D10385 T	1	BACC10JS8 BACKSHELL-	81025	1	33-25-51 */*/*	YC001-YC050
D10387	1	BACC45FT12-12S PLUG	81205	1	23-32-41 500C+2/272/R08	YC001-YC009
D10387	1	BACC45FT12-12S PLUG	81205	1	23-32-41 567/274/R015	YC010-YC050
D10389	1	755-78-9 PLUG	91836	1	23-32-41 500C+2/273/R08	YC001-YC009
D10389	1	755-78-9 PLUG	91836	1	23-32-41 567/274/R015	YC010-YC011
D10389	1	755-78-9 PLUG	91836	1	23-32-41 565/274/R015	YC012-YC050
D10391	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 587/273/R033	YC001-YC050
D10391 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10393	1	BACC45FT12-12S PLUG	81205	1	23-32-42 500G+2/273/L019	YC001-YC050
D10395	1	755-78-9 PLUG	91836	1	23-32-42 500G+1/273/L018	YC001-YC050
D10397	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 500G+3/273/L018	YC001-YC050
D10397 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10399	1	BACC45FT12-12S PLUG	81205	1	23-32-42 500G/273/R50	YC001-YC019
D10399	1	BACC45FT12-12S PLUG	81205	1	23-32-42 500G+3/273/R049	YC020-YC050

EQUIPMENT LIST

D280A103

Section D10300

Page 5 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10401	1	755-78-9 PLUG	91836	1	23-32-42 500G+2/272/R50	YC001-YC019
D10401	1	755-78-9 PLUG	91836	1	23-32-42 500G+3/273/R049	YC020-YC050
D10403	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 500G+4/273/R042	YC001-YC050
D10403 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10417	1	BACC45FT12-12S PLUG	81205	1	23-32-43 548/273/L019	YC001-YC050
D10419	1	755-78-9 PLUG	91836	1	23-32-43 549/273/L019	YC001-YC050
D10421	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 500G+17/272/L031	YC001-YC050
D10421 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10423	1	BACC45FT12-12S PLUG	81205	1	23-32-43 549/273/R50	YC001-YC050
D10425	1	755-78-9 PLUG	91836	1	23-32-43 547/272/R50	YC001-YC050
D10427	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 550/273/R042	YC001-YC050
D10427 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10429	1	BACC45FT12-12S PLUG	81205	1	23-32-51 641/272/L033	YC001-YC050
D10431	1	755-78-9 PLUG	91836	1	23-32-51 641/272/L033	YC001-YC050
D10433	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 650/272/L033	YC001-YC050
D10433 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10434	1	BACC63CN2842S8 RECP-CONDUCTIVE	81205	1	49-41-11 1090/235/L12	YC001-YC011

EQUIPMENT LIST

D280A103

Section D10400

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10434	1	BACC63CN2842S8 RECP-CONDUCTIVE	81205	1	49-41-11 1090/235/L012	YC012-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10434 T	1	BACC10KA28 BACKSHELL	81205	1	49-41-11 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10435	1	BACC45FT12-12S PLUG	81205	1	23-32-51 650/272/R50	YC001-YC009
D10435	1	BACC45FT12-12S PLUG	81205	1	23-32-51 679/272/R50	YC010-YC050
D10436	1	BACC63CN2842S6 RECP-CONDUCTIVE	81205	1	49-52-31 1090/225/L17	YC001-YC011
D10436	1	BACC63CN2842S6 RECP-CONDUCTIVE	81205	1	49-52-31 1090/225/L017	YC012-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10436 T	1	BACC10KA28 BACKSHELL	81205	1	49-52-31 1088/ /	YC001-YC007
D10436 T	1	BACC10KA28 BACKSHELL	81205	1	49-52-31 1088/226/L17	YC008-YC011
D10436 T	1	BACC10KA28 BACKSHELL	81205	1	49-52-31 1088/226/L017	YC012-YC050
D10436 T	1	BACC10KA28 BACKSHELL	81205	1	49-52-31 */**	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10437	1	755-78-9 PLUG	91836	1	23-32-51 651/272/R50	YC001-YC009
D10437	1	755-78-9 PLUG	91836	1	23-32-51 679/272/R50	YC010-YC050
D10439	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 651/270/R042	YC001-YC050

EQUIPMENT LIST

D280A103

Section D10400

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10439 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10453	1	BACC45FT12-12S PLUG	81205	1	23-32-52 727+13/274/L019	YC001-YC050
D10455	1	755-78-9 PLUG	91836	1	23-32-52 727+14/270/L033	YC001-YC050
D10457	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 727+14/274/L018	YC001-YC050
D10457 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10459	1	BACC45FT12-12S PLUG	81205	1	23-32-52 727+15/272/R50	YC001-YC050
D10461	1	755-78-9 PLUG	91836	1	23-32-52 727+13/272/R50	YC001-YC050
D10461	1	DPXBMA-67-33S-0001 PLUG-	71468	1	23-34-01 E003-02/ /	YK901-YM670
D10463	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 727+14/270/R042	YC001-YC050
D10463 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10465	1	BACC45FT12-12S PLUG	81205	1	23-32-53 727F+4/273/L024	YC001-YC019
D10465	1	BACC45FT12-12S PLUG	81205	1	23-32-53 727F+4/272/L024	YC020-YC050
D10467	1	755-78-9 PLUG	91836	1	23-32-53 727F+8/273/L024	YC001-YC050
D10469	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 727D+22/272/L017	YC001-YC050
D10469 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10471	1	BACC45FT12-12S PLUG	81205	1	23-32-53 727F+7/273/R019	YC001-YC050
D10473	1	755-78-9 PLUG	91836	1	23-32-53 727F+4/273/R019	YC001-YC009, YC012-YC050

EQUIPMENT LIST

D280A103

Section D10400

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10473	1	755-78-9 PLUG	91836	1	23-32-53 272F+4/273/R019	YC010-YC011
D10475	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 727+9/273/R033	YC001-YC050
D10475 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10489	1	BACC45FT12-12S PLUG	81205	1	23-32-61 727I+3/273/L024	YC001-YC050
D10491	1	755-78-9 PLUG	91836	1	23-32-61 727I+1/273/L024	YC001-YC050
D10493	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 727I+2/273/L017	YC001-YC050
D10493 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10495	1	BACC45FT12-12S PLUG	81205	1	23-32-61 727I+2/272/R50	YC001-YC050
D10497	1	755-78-9 PLUG	91836	1	23-32-61 727I+2/273/R50	YC001-YC050
D10499	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 727I+2/270/R042	YC001-YC050
D10499 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050

EQUIPMENT LIST

D280A103

Section D10400

Page 4 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10501	1	BACC45FT12-12S PLUG	81205	1	23-32-62 797/272/L50	YC001-YC050
D10503	1	755-78-9 PLUG	91836	1	23-32-62 798/272/L50	YC001-YC050
D10505	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 797/273/L017	YC001-YC050
D10505 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10507	1	BACC45FT12-12S PLUG	81205	1	23-32-62 798/273/R08	YC001-YC050
D10509	1	755-78-9 PLUG	91836	1	23-32-62 798/272/R50	YC001-YC050
D10511	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 798/270/R042	YC001-YC050
D10511 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050
D10513	1	BACC45FT12-12S PLUG	81205	1	23-32-63 849/276/L54	YC001-YC011
D10513	1	BACC45FT12-12S PLUG	81205	1	23-32-63 849/276/L054	YC012-YC050
D10515	1	755-78-9 PLUG	91836	1	23-32-63 849/276/L056	YC001-YC050
D10517	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 890/275/L017	YC001-YC050
D10517 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YC001-YC050
D10519	1	BACC45FT12-12S PLUG	81205	1	23-32-63 849/276/R56	YC001-YC050
D10521	1	755-78-9 PLUG	91836	1	23-32-63 849/276/R58	YC001-YC050
D10523	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 886/270/R042	YC001-YC050
D10523 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YC001-YC050

EQUIPMENT LIST

D280A103

Section D10500

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10525	1	BACS16X1A SOCKET-	81205	1	23-34-01 J00024/ /	ALL
D10527	1	BACC66F11C12AA01 PLUG PLATE ASSY	81205	1	23-34-01 E008-01/ /	YC001-YC050
D10527	1	BACC66F11F01AA01 PLUG PLATE ASSY	81205	1	23-34-01 E004-02/ /	YK901-YM670
D10527 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-34-01 E008-01/ /	YC001-YC007
D10527 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-34-01 / /	YC008-YC050
D10527 U		527-187MA5B5C4 EMI BACKSHELL	06324	1	23-34-01 */*/	YK901-YM670
D10527A	1	PARTAOFD10527 PLUG - MULTIPLEXER		1	23-34-01 E008-01/ /	YC001-YC050
D10527A	1	PARTAOFD10527 PLUG - MULTIPLEXER		1	23-34-01 E004-02/ /	YK901-YM670
D10527B	1	PARTBOFD10527 PLUG - MULTIPLEXER		1	23-34-01 E008-01/ /	YC001-YC050
D10527B	1	PARTBOFD10527 PLUG - MULTIPLEXER		1	23-34-01 E004-02/ /	YK901-YM670
D10527C	1	PARTCOFD10527 PLUG - MULTIPLEXER		1	23-34-01 E008-01/ /	YC001-YC050
D10527C	1	PARTCOFD10527 PLUG - MULTIPLEXER		1	23-34-01 E004-02/ /	YK901-YM670
D10529	1	BACC63BP10C20SN PLUG-RIGHT ELEVATOR TAB SOLENOID	81205	1	27-31-11 1159/288/R8	ALL
D10529 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	27-31-11 / /	YC001-YC022
D10529 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	27-31-11 */*/	YC023-YM670
D10531	1	BACC63BP10C20SN PLUG-LEFT ELEVATOR TAB SOLENOID	81205	1	27-31-11 1159/284/R8	YC001-YC007
D10531	1	BACC63BP10C20SN PLUG-LEFT ELEVATOR TAB SOLENOID	81205	1	27-31-11 1159/288/R008	YC008-YM670

EQUIPMENT LIST

D280A103

Section D10500

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10531 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	27-31-11 / /	ALL
D10533	1	BACC63BP10C20SN PLUG-CONDUCTIVE	81205	1	27-81-51 631/162/R65	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10533 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	27-81-51 632/162/R60	YC001-YC028
D10533 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	27-81-51 */*/*	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10535	1	BACC63BP10C20SN PLUG-CONDUCTIVE	81205	1	27-81-51 702/199/L011	YC001-YC030
D10535	1	BACC63BP10H20SN PLUG-CONDUCTIVE	81205	1	27-81-51 702/199/L011	YC031-YK907, YL421
D10535	1	BACC63BP10H20SN PLUG-CONDUCTIVE	81205Q	1	27-81-51 702/199/L011	YK908-YK910, YL422-YL423, YM643
D10535	1	BACC63BP10H20SN PLUG- CONDUCTIVE	81205	1	27-81-51 702/199/L011	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM670
D10535 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	27-81-51 / /	YC001-YC028
D10535 T	1	BACC10KD10 BACKSHELL-CONDUCTIVE	81205	1	27-81-51 */*/*	YC029-YC030
D10535 T	1	M85049-52S10A BACKSHELL-CONDUCTIVE	81205	1	27-81-51 */*/*	YC031-YK907, YK910-YK912, YK918-YK919, YL401-YL421, YL423-YL429, YM645-YM670
D10535 T	1	M85049-52S10A BACKSHELL-CONDUCTIVE	81205	1	27-81-51 / /	YK908-YK909, YL422, YM643

EQUIPMENT LIST

D280A103

Section D10500

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10537	1	BACC45FN10-5S7 RCPT-	81205	1	27-53-11 AF0222A/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10537 T	1	BACC10JS10 BACKSHELL-	81205	1	27-53-11 / /	YC001-YC007
D10537 T	1	BACC10JS10 BACKSHELL-	81205	1	27-53-11 */*/	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10539	1	BACC63CB10-5SN PLUG-SPOILER 3 POSITION XMTR	81205	1	27-62-14 ORSS/373/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10539 T	1	BACC10KD10 BACKSHELL, STRAIGHT	81205	1	27-62-14 / /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10541	1	BACC63CB10-5SN PLUG-SPOILER 10 POSITION XMTR	81205	1	27-62-14 ORSS/373/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10541 T	1	BACC10KD10 BACKSHELL, STRAIGHT	81205	1	27-62-14 / /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D10551	1	BACC45FN10-5S PLUG	81205	1	31-31-14 221/195/R020	ALL
D10551 T	1	BACC10JC10 BACKSHELL	81205	1	31-31-14 / /	YC001-YC019
D10551 T	1	BACC10JC10 BACKSHELL	81205	1	31-31-14 */*/	YC020-YM670
D10553	1	BACC45FN10-5S PLUG	81205	1	31-31-14 200/204/R011	ALL
D10562	1	BACC45FT10-5P PLUG-	81205	2	30-41-12 249/232/LR48	YC001-YK906

EQUIPMENT LIST

D280A103

Section D10500

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10562 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	2	30-41-12 */**	YC001-YK906
D10564	1	BACC45FN10-5S RCPT-M/W R #2 WINDOW COILED CORD	81205	1	30-41-11 249/232/R048	ALL
D10568	1	BACC45FN10-5S RCPT-M/W L #2 WINDOW COILED CORD	81205	1	30-41-12 249/232/L48	YC001-YC019
D10568	1	BACC45FN10-5S RCPT-M/W L #2 WINDOW COILED CORD	81205	1	30-41-12 249/232/L048	YC020-YM670
D10569	1	BACS16W1A RELAY SOCKET	81205	1	27-62-11 J020-0B/ /	ALL
D10570	1	BACC45FT10-5P PLUG-	81205	2	30-41-12 229/238/LR40	YC001-YK906
D10570 T	1	BACC10JS10 BACKSHELL-STRAIGHT	81205	2	30-41-12 */**	YC001-YK906
D10570 U	1	20531-9E039LL-4-TL- WINDOW HEATER COILED CORD	92607	2	30-41-12 */**	YC001-YK906
D10571	1	BACS16W1A RELAY SOCKET	81205	1	27-62-11 J022-00/ /	ALL
D10572	1	BACC45FN10-5S RCPT-	81205	2	30-41-12 230/239/LR40	ALL
D10573	1	BACS16W1A RELAY SOCKET	81205	1	27-62-11 J020-0B/ /	ALL
D10575	1	BACS16AF1 RELAY SOCKET	81205	1	27-62-11 J020-0B/ /	ALL
D10577	1	SO-1055-8690 RELAY SOCKET	35344	1	27-62-11 J020-0B/ /	ALL
D10579	1	BACS16AF1 RELAY SOCKET	81205	1	27-62-11 J020-0B/ /	ALL
D10581	1	BACS16AF1 RELAY SOCKET	81205	1	27-62-11 J020-0B/ /	ALL
D10583	1	POACONNECTOR PLUG-TPS COAX 150-1120	60253	1	23-24-11 797/289/L015	ALL
D10585	1	POACONNECTOR PLUG-TNC COAX 150-1122	60253	1	23-24-11 797/289/L005	ALL

EQUIPMENT LIST

D280A103

Section D10500

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10587	1	DAMA-15S PLUG	71468	1	23-34-02 987/280/R044	YK901-YM670
D10587 T	1	D110278 END DIC LATCH ASSY	71468	2	23-34-02 987/280/R044	YK901-YM670
D10587 U		557-400 BACKSHELL - EMI	06090	1	23-34-02 987/280/R044	YK901-YM670
D10589	1	BACC63BP8D3SN PLUG-CODUCTIVE	81205	1	27-81-12 OFSS 555/ /	ALL
D10589 T	1	BACC10KC8 BACKSHELL-CONDUCTIVE	81205	1	27-81-12 */*/*	ALL
D10591	1	BACC63BP8D3SN PLUG-CONDUCTIVE	81205	1	27-81-12 OFSS 435/ /	ALL
D10591 T	1	BACC10KC8 BACKSHELL-CONDUCTIVE	81205	1	27-81-12 */*/*	ALL
D10593	1	BACC63BP8D3SN PLUG-CONDUCTIVE	81205	1	27-81-12 OFSS 318/ /	ALL
D10593 T	1	BACC10KC8 BACKSHELL-CONDUCTIVE	81205	1	27-81-12 */*/*	ALL
D10595	1	BACC63BP8D3SN PLUG-CONDUCTIVE	81205	1	27-81-22 OFSS 318/ /	ALL
D10595 T	1	BACC10KC8 BACKSHELL-CONDUCTIVE	81205	1	27-81-22 / /	ALL
D10596	1	BACC45FT22-55S9 PLUG-	81205	1	24-31-11 P005-13/ /	YC001-YC030, YK901-YM670
D10597	1	BACC63BP8D3SN PLUG-CONDUCTIVE	81205	1	27-81-22 OFSS 435/ /	ALL
D10597 T	1	BACC10KC8 BACKSHELL-CONDUCTIVE	81205	1	27-81-22 / /	ALL
D10599	1	BACC63BP8D3SN PLUG-CONDUCTIVE	81205	1	27-81-22 OFSS 555/ /	ALL
D10599 T	1	BACC10KC8 BACKSHELL-CONDUCTIVE	81205	1	27-81-22 / /	ALL

EQUIPMENT LIST

D280A103

Section D10500

Page 6 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10601	1	BACC63CB16-24SN PLUG-	81205	1	23-12-11 P008-71/ /	YK901-YM670
D10601 T	1	BACC10KD16 BACKSHELL- CONDUCTIVE	81205	1	23-12-11 */**	YK901-YM670
D10603	1	BACC63CB16-24SN PLUG-	81205	1	23-12-21 P008-72/ /	YK901-YM670
D10603 T	1	BACC10KD16 BACKSHELL- CONDUCTIVE	81205	1	23-12-21 */**	YK901-YM670
D10605	1	BACC63CB16-24SN PLUG-	81205	1	23-11-11 P008-73/ /	YK901-YM670
D10605 T	1	BACC10KD16 BACKSHELL- CONDUCTIVE	81205	1	23-12-31 */**	YK901-YM670
D10634	1	SO-1055-8690 RELAY SOCKET	35344	1	78-32-51 J022-00/ /	ALL
D10636	1	BACS16W1A RELAY SOCKET	81205	1	78-32-51 J022-00/ /	ALL
D10638	1	SO-1055-8690 SOCKET-	35344	1	78-32-61 J00024/ /	ALL
D10640	1	BACS16W1A SOCKET-	81205	1	78-32-61 J00024/ /	ALL
D10659	1	DPXBMA-32W4-33S-0005 PLUG - VTR-1	71468	1	23-32-11 363/257/L031	YC015, YC019, YC031-YC050
D10659	1	DPXBMA-32W4-33S-0005 PLUG - VTR-1	71468	1	23-32-11 850/280/R040	YK901-YM670
D10659 T	1	249-1983-000 COAX CONTACT	71468	1	23-32-11 */**	YC015, YC019, YC031-YC050
D10661	1	DPXBMA-32W4-33S-0005 PLUG - VTR-2	71468	1	23-32-11 363/257/L031	YC015, YC019, YC031-YC050
D10661 T	1	249-1983-000 COAX CONTACT	71468	1	23-32-11 */**	YC015, YC019, YC031-YC050
D10665	1	BACC66F11F69AA01 PLUG PLATE ASSY	81205	1	23-31-06 E008-01/ /	YC001-YC006
D10665	1	BACC66F11F69AA01 PLUG PLATE ASSY	81205	1	23-34-06 E008-01/ /	YC007-YC050

EQUIPMENT LIST

D280A103

Section D10600

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10665 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-34-06 E008-01/ /	YC001-YC050
D10665A	1	PARTAOFD10665 PLUG - TAPE REPRODUCER		1	23-34-06 E008-01/ /	YC001-YC050
D10665B	1	PARTBOFD10665 PLUG - TAPE REPRODUCER		1	23-34-06 E008-01/ /	YC001-YC050
D10665C	1	PARTCOFD10665 PLUG - TAPE REPRODUCER		1	23-34-06 E008-01/ /	YC001-YC050
D10667	1	280U0013-101 PLUG PLATE ASSY - VSCU	81205	1	23-32-13 363/275/L031	YC015, YC019, YC031-YC050
D10667	1	280U0013-101 PLUG PLATE ASSY - VSCU	81205	1	23-32-13 866/278/R041	YK901-YM670
D10669	1	BACC45FT22-55S PLUG PLATE ASSY - VSCU	81205	1	23-32-12 362/264/L038	YC015, YC019, YC031-YC050
D10669	1	BACC45FT22-55S PLUG PLATE ASSY - VSCU	81205	1	23-32-12 870/278/R042	YK901-YM670
D10671	1	BACC45FT22-55S6 PLUG PLATE ASSY - VSCU	81205	1	23-32-13 362/267/L040	YC015, YC019, YC031-YC050
D10671	1	BACC45FT22-55S6 PLUG PLATE ASSY - VSCU	81205	1	23-32-13 870/280/R042	YK901-YM670
D10673	1	BACC45FT22-55S7 PLUG PLATE ASSY - VSCU	81205	1	23-32-11 363/297/L031	YC015, YC019, YC031-YC050
D10673	1	BACC45FT22-55S7 PLUG PLATE ASSY	81205	1	23-32-11 867/280/R042	YK901-YM670
D10675	1	BACC45FT22-55S8 PLUG PLATE ASSY - VSCU	81205	1	23-32-12 362/264/L042	YC015, YC019, YC031-YC050
D10675	1	BACC45FT22-55S8 PLUG PLATE ASSY - VSCU	81205	1	23-32-12 858/280/R042	YK901-YM670

EQUIPMENT LIST

D280A103

Section D10600

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10712	1	BACC45FT16-24S PLUG-	81205	1	33-51-14 604/213/L067	YM643-YM652
D10712 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-14 */**	YM643-YM652
D10714	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 604/212/R067	YM643-YM670
D10714 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-11 */**	YM643-YM670
D10715	1	BACC45FT18A31P PLUG-	81205	1	23-24-11 790/300/L016	ALL
D10716	1	BACC45FT16-24S PLUG-	81205	1	33-51-14 727C+13/212/L068	YC001-YC030, YK901-YM652
D10716 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-14 */**	YC001-YC030, YK901-YM652
D10717	1	BACC45FT16A24S PLUG-	81205	1	23-24-11 790/300/L015	ALL
D10719	1	BACC66H40F03AK01 PLUG PLATE ASSEMBLY	81205	1	34-31-11 E001-02/ /	YC001-YC030
D10719	1	BACC66H40F03AK01 PLUG PLATE ASSEMBLY - IL S RECEIVER -1	81205	1	34-31-11 E001-02/ /	YK901-YM670
D10719 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	34-31-11 E001-02/ /	YC001-YC030
D10719 T	1	S280W601-116 GROUND BLOCK, ARINC 600	81205	1	34-31-11 */**	YK901-YM670
D10719A	1	PARTAOFD10719A PLUG-		0	34-31-11 E001-02/ /	YC001-YC030
D10719A	1	PARTAOFD10719 PLUG-		0	34-31-11 */**	YK901-YM670
D10719AU	1	125-94-9 PLUG-COAX	91836	1	34-58-11 E001-02/ /	YC001-YC030
D10719AU	1	125-94-9 PLUG-COAX	91836	1	34-58-11 */**	YK901-YM670
D10719B	1	PARTBOFD10719A PLUG-		0	34-31-11 E001-02/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D10700

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10719B	1	PARTBOFD10719 PLUG-		0	34-31-11 */*/*	YK901-YM670
D10719C	1	PARTCOFD10719A PLUG-		0	34-31-11 E001-02/ /	YC001-YC030
D10719C	1	PARTCOFD10719 PLUG-		0	34-31-11 */*/*	YK901-YM670
D10721	1	BACC66H40F03AK01 PLUG PLATE ASSEMBLY	81205	1	34-31-11 E001-04/ /	ALL
D10721 T	1	S280W601-116 GND - BLOCK 48	81205	1	34-31-21 E001-04/ /	YC001-YC050
D10721 T	1	S280W601-116 GND - BLOCK 48	81205	1	34-31-11 */*/*	YK901-YM670
D10721A	1	PARTAOFD10721 PLUG - MMR-2		0	34-31-11 E001-04/ /	YC001-YC050
D10721A	1	PARTAOFD10721 PLUG - MMR-2		0	34-31-11 */*/*	YK901-YL430
D10721A	1	PARTAOFD10721 PLUG - MMR-2		1	34-31-11 */*/*	YM643-YM670
D10721AU	1	125-94-9 PLUG-COAX	91836	1	34-58-21 E001-04/ /	YC001-YC050
D10721AU	1	125-94-9 PLUG-COAX	91836	1	34-58-21 */*/*	YK901-YM670
D10721B	1	PARTBOFD10721 PLUG - MMR-2		0	34-31-11 E001-04/ /	YC001-YC050
D10721B	1	PARTBOFD10721 PLUG - MMR-2		0	34-31-11 */*/*	YK901-YL430
D10721B	1	PARTBOFD10721 PLUG - MMR-2		1	34-31-11 */*/*	YM643-YM670
D10721C	1	PARTCOFD10721 PLUG - MMR-2		0	34-31-11 E001-04/ /	YC001-YC050
D10721C	1	PARTCOFD10721 PLUG - MMR-2		0	34-31-11 */*/*	YK901-YL430
D10721C	1	PARTCOFD10721 PLUG - MMR-2		1	34-31-11 */*/*	YM643-YM670

EQUIPMENT LIST

D280A103

Section D10700

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10723	1	DPXBMA-67-33S-0001 PLUG-	71468	1	23-34-01 E008-01/ /	YC001-YC050
D10724	1	BACC45FT18-31S PLUG-	81205	1	21-31-11 P005-06/ /	YC001-YC030, YK901-YM670
D10726	1	BACC45FT18-31S6 PLUG-	81205	1	21-31-11 P005-06/ /	YC001-YC030, YK901-YM670
D10727	1	BACC66H21C58AA01 PLUG PLATE ASSY	81205	1	23-27-31 E004-01/ /	YK901-YM670
D10727 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	23-27-31 */**	YK901-YM670
D10727A	1	PARTAOFD10727 PLUG		0	23-27-31 E004-01/ /	YK901-YL430
D10727A	1	PARTAOFD10727 PLUG		0	23-27-31 */**	YM643-YM670
D10727B	1	PARTBOFD10727 PLUG		0	23-27-31 */**	YK901-YM670
D10727C	1	PARTCOFD10727 PLUG		0	23-27-31 */**	YK901-YM670
D10728	1	MS3476L12-10S PLUG-FEEDBACK MODULE (OFV)	96906	1	21-31-11 967+10/165/R030	YC001-YC007
D10728	1	MS3476L12-10S PLUG-FEEDBACK MODULE (OFV)	96906	1	21-31-11 973/183/R13	YC008-YL430
D10728	1	MS3476L12-10S PLUG-FEEDBACK MODULE (OFV)	96906	1	21-31-11 973/183/R013	YM643-YM670
D10728 T	1	BACC10KE12 BACKSHELL-90 DEGREE	81205	1	21-31-11 */**	ALL
D10730	1	MS3476L10-6S PLUG-MANUAL DC MOTOR (OFC)	96906	1	21-31-11 967+10/165/R030	YC001-YC007
D10730	1	MS3476L10-6S PLUG-MANUAL DC MOTOR (OFC)	96906	1	21-31-11 972/190/R15	YC008-YL430
D10730	1	MS3476L10-6S PLUG-MANUAL DC MOTOR (OFC)	96906	1	21-31-11 972/190/R015	YM643-YM670
D10730 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	21-31-11 */**	ALL

EQUIPMENT LIST

D280A103

Section D10700

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10732	1	MS3476L16-26S PLUG-ELECTRONIC ACTUATOR NO.1 (OFV)	96906	1	21-31-22 980/190/R013	ALL
D10732 T	1	BACC10KE16 BACKSHELL	81205	1	21-31-22 */**	ALL
D10734	1	MS3476L16-26S PLUG-ELECTRONIC ACTUATOR NO.2 (OFV)	96906	1	21-31-23 967+15/170/R026	YC001-YC007
D10734	1	MS3476L16-26S PLUG-ELECTRONIC ACTUATOR NO.2 (OFV)	96906	1	21-31-23 978/190/R14	YC008-YL430
D10734	1	MS3476L16-26S PLUG-ELECTRONIC ACTUATOR NO.2 (OFV)	96906	1	21-31-23 978/190/R014	YM643-YM670
D10734 T	1	BACC10KE16 BACKSHELL-	81205	1	21-31-23 */**	ALL
D10736	1	MS3476L14-12S PLUG-FEEDBACK MODULE (OFV)	96906	1	21-31-23 967+10/160/R026	YC001-YC007
D10736	1	MS3476L14-12S PLUG-FEEDBACK MODULE (OFV)	96906	1	21-31-23 974/185/R12	YC008-YL430
D10736	1	MS3476L14-12S PLUG-FEEDBACK MODULE (OFV)	96906	1	21-31-23 974/185/R012	YM643-YM670
D10736 T	1	BACC10KD14 BACKSHELL-	81205	1	21-31-23 */**	YC001-YC007
D10736 T	1	BACC10KE14 BACKSHELL-	81205	1	21-31-23 */**	YC008-YL430
D10736 T	1	BACC10KE14 BACKSHELL-90 DEGREE	81205	1	21-31-23 */**	YM643-YM670
D10738	1	BACC66F11C13AA01 PLUG PLATE ASSY - CABIN PRESS CONT NO. 1	81205	1	21-31-22 E002-02/ /	YC001-YC030, YK901-YM670
D10738 T	1	S280W601-116 GROUND-48	81205	1	21-31-22 E002-02/ /	YC001-YC030, YK901-YM670
D10738A	1	PARTAOFD10738 PLUG		1	21-31-22 E002-02/ /	YC001-YC030, YK901-YM670
D10738B	1	PARTBOFD10738 PLUG		1	21-31-22 E002-02/ /	YC001-YC030, YK901-YM670
D10738C	1	PARTCOFD10738 PLUG		1	21-31-22 E002-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D10700

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10740	1	BACC66F11C13AA01 PLUG-PLATE ASSY	81205	1	21-31-23 E004-01/ /	YC001-YC030
D10740	1	BACC66F11C13AA01 PLUG-PLATE ASSY	81205	1	21-31-23 E001-01/ /	YK901-YM670
D10740 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	21-31-24 E004-01/ /	YC001-YC026
D10740 T		S280W601-116 GROUND BLOCK, ARINC 600	81205	1	21-31-24 */*/*	YC028-YC030, YK901-YM670
D10740A	1	PARTAOFD10740 PLUG-PLATE ASSY		0	21-31-23 E004-01/ /	YC001-YC026
D10740A	1	PARTAOFD10740 PLUG-PLATE ASSY		0	21-31-23 */*/*	YC028-YC030, YK901-YM670
D10740B	1	PARTBOFD10740 PLUG-PLATE ASSY		0	21-31-23 E004-01/ /	YC001-YC026
D10740B	1	PARTBOFD10740 PLUG-PLATE ASSY		0	21-31-23 */*/*	YC028-YC030, YK901-YM670
D10740C	1	PARTCOFD10740 PLUG-PLATE ASSY		0	21-31-23 E004-01/ /	YC001-YC026
D10740C	1	PARTCOFD10740 PLUG-PLATE ASSY		0	21-31-23 */*/*	YC028-YC030, YK901-YM670
D10744	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 952/290/R014	ALL
D10744 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-11 */*/*	ALL
D10746	1	BACC45FT16-24S PLUG-	81205	1	33-51-14 952/290/L014	YC001-YC030, YK901-YM652
D10746 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-14 */*/*	YC001-YC030, YK901-YM652
D10748	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 322/291/R007	ALL
D10748 T	1	BACC10JC16 BACKSHELL-	81205	1	33-51-11 */*/*	ALL
D10750	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 322/291/L007	ALL

EQUIPMENT LIST

D280A103

Section D10700

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10750 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-11 */*/	ALL
D10754	1	S280W557-221 RCPT-	81205	1	33-29-11 329/293/L004	YC001-YC026
D10754	1	BACC65AK221P RCPT-	81205	1	33-29-11 329/293/L004	YC028-YM670
D10756	1	S280W557-121 PLUG-	81205	1	33-29-11 328/293/L004	YC001-YC026
D10756	1	BACC65AJ121S PLUG-	81205	1	33-29-11 328/293/L004	YC028-YM670
D10760	1	MB12P-1 PLUG-	09922	1	33-29-11 327/293/R004	ALL
D10762	1	BACS16X1A PLUG	81205	1	21-31-25 P006-00/ /	ALL
D10770	1	BACC45FT10-5S PLUG-	81205	1	21-42-11 975/297/R010	ALL
D10770 T	1	BACC10JS10 BACKSHELL-	81205	1	21-42-11 */*/	ALL

EQUIPMENT LIST

D280A103

Section D10700
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10820	1	BACS16AG1 PLUG	81205	1	21-31-11 P006-00/ /	ALL
D10822	1	BACS16AG1 PLUG	81205	1	21-31-22 P006-00/ /	ALL
D10824	1	BACS16AG1 PLUG	81205	1	21-31-23 P006-00/ /	ALL
D10845	1	BACC63BV14F7SN RCPT-	81205	1	31-31-14 FIN 73.5/285/L007	ALL
D10845 T	1	BACC10KD14 BACKSHELL-STRAIGHT	81205	1	31-31-14 */*/*	ALL
D10847	1	BACS16AF1 SOCKET-	81205	1	34-49-11 J00024/ /	YC001-YC002, YC007-YM670
D10849	1	BACS16AF1 SOCKET-TERRAIN SELECT RLY-R	81205	1	34-49-11 J022-00/ /	YC001-YC002, YC007-YM670
D10853	1	MS3126F20-41S PLUG - CONDUCTIVE	96906	1	34-24-15 P002-01/ /	YK901-YM670
D10878	1	BACC45FT12-12S PLUG-	81205	1	25-51-21 821/205/L019	ALL
D10878 T	1	BACC10JS12 BACKSHELL-	81205	1	25-51-21 821/205/L019	ALL
D10884	1	BACC45FT10-5S PLUG-	81205	1	21-42-11 273/190/L022	YC001-YC030, YK901-YM670
D10884 T	1	BACC10JS10 BACKSHELL-	81205	1	21-42-11 */*/*	YC001-YC030, YK901-YM670
D10890	1	DPX2MB-67S67S-33B-0001 PLUG PLATE ASSY	71468	1	24-22-11 E002-01/ /	ALL
D10890A	1	PARTAOFD10890 PLUG-		1	24-22-11 E002-01/ /	ALL
D10890B	1	PARTBOFD10890 PLUG-		1	24-22-11 E002-01/ /	ALL
D10892	1	DPX2MB-67S67S-33B-0001 PLUG PLATE ASSY	71468	1	24-11-21 E004-02/ /	ALL
D10892A	1	PARTAOFD10892 PLUG		1	24-11-21 E004-02/ /	YC001-YC009

EQUIPMENT LIST

D280A103

Section D10800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10892A	1	PARTAOFD10892 PLUG		1	24-11-21 */*/*	YC010-YM670
D10892B	1	PARTBOFD10892 PLUG		1	24-11-21 E004-02/ /	YC001-YC009
D10892B	1	PARTBOFD10892 PLUG		1	24-11-21 */*/*	YC010-YM670
D10896	1	DPX2MB-67S67S-33B-0001 PLUG PLATE ASSY	71468	1	24-22-31 E002-01/ /	ALL
D10896A	1	PARTAOFD10896 PLUG		1	24-22-31 E002-01/ /	ALL
D10896B	1	PARTBOFD10896 PLUG		1	24-22-31 E002-01/ /	ALL
D10898	1	DPX2MB-67S67S-33B-0061 PLUG PLATE ASSY	71468	1	24-22-21 E004-02/ /	ALL
D10898A	1	PARTAOFD10898 PLUG		1	24-22-21 E004-02/ /	YC001-YC009
D10898A	1	PARTAOFD10898 PLUG		1	24-22-21 */*/*	YC010-YM670
D10898B	1	PARTBOFD10898 PLUG		1	24-22-21 E004-02/ /	YC001-YC009
D10898B	1	PARTBOFD10898 PLUG		1	24-22-21 */*/*	YC010-YM670

EQUIPMENT LIST

D280A103

Section D10800

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10912	1	BACC63CN2842SN RECP-CONDUCTIVE	81205	1	49-61-11 1090/229/L13	YC001-YC007
D10912	1	BACC63CN2842SN RECP-CONDUCTIVE	81205	1	49-61-11 1090/229/L013	YC008-YC030, YK901-YM670
D10912 T	1	BACC10KA28 BACKSHELL	81205	1	49-61-11 1088/ /	YC001-YC007
D10912 T	1	BACC10KA28 BACKSHELL	81205	1	49-61-11 1090/229/L013	YC008-YC030, YK901-YK910, YL421-YL423, YM643
D10912 T	1	BACC10KA28 BACKSHELL	81205	1	49-61-11 */*/*	YK911-YL401, YL424-YL430, YM645-YM670
D10916	1	BACS16W1A SOCKET-	81205	1	73-22-31 J00024/ /	ALL
D10918	1	BACS16W1A RELAY SOCKET	81205	1	73-22-31 J022-00/ /	ALL
D10920	1	SO-1056-8691 RELAY SOCKET-	35344	1	76-21-11 J023-00/ /	ALL
D10922	1	SO-1056-8691 RELAY SOCKET	35344	1	76-21-11 J022-00/ /	ALL
D10924	1	SO-1056-8691 RELAY SOCKET	35344	1	76-21-21 J020-0B/ /	ALL
D10926	1	SO-1056-8691 SOCKET-	35344	1	76-21-21 J00024/ /	ALL
D10952	1	SO-1064-001 SOCKET-	35344	1	73-22-11 J00024/ /	ALL
D10954	1	SO-1064-001 RELAY SOCKET	35344	1	73-22-11 J022-00/ /	ALL
D10956	1	BACC45FT8-3S PLUG-	81205	1	21-61-21 262/278/L005	ALL
D10958	1	BACC45FT10-5S PLUG-	81205	1	21-61-11 261/278/L7	YC001-YL430
D10958	1	BACC45FT12-3S PLUG-	81205	1	21-61-21 261/278/L7	YM643-YM670

EQUIPMENT LIST

D280A103

Section D10900

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10960	1	BACC45FT8-3S PLUG	81205	1	21-61-22 424/274/R026	YM643-YM670
D10960 T	1	BACC10JS08 BACKSHELL-	81205	1	21-61-22 */**	YM643-YM670
D10962	1	BACC45FT12-3S PLUG-	81205	1	21-61-22 408/274/R028	YM643-YM670
D10964	1	017832-3000 PLUG-	58795	1	21-61-51 411/274/R028	YM643-YM670
D10982	1	BACC45FT24-61S7 PLUG-	81205	1	32-64-11 205/184/R020	YC001-YC030, YK901-YM670
D10982 T	1	BACC10JC24 BACKSHELL	81205	1	32-64-11 */**	YC001-YC030, YK901-YM670
D10984	1	BACC45FT24-61S9 PLUG-	81205	1	32-64-12 205/180/R018	YC001-YC030, YK901-YM670
D10984 T	1	BACC10JC24 BACKSHELL	81205	1	32-64-21 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D10984 T	1	BACC10JC24 BACKSHELL	81205	1	32-64-21 */**	YK911-YK917
D10984 T	1	BACC10JC24 BACKSHELL	81205	1	32-64-21 */ /	YM643-YM649
D10986	1	BACC45FT24-61S8 PLUG-	81205	1	31-53-11 205/182/R020	YC001-YC030, YK901-YM670
D10986 T	1	BACC10JC24 BACKSHELL	81205	1	52-71-11 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D10986 T	1	BACC10JC24 BACKSHELL	81205	1	52-71-11 */**	YK911-YK917
D10986 T	1	BACC10JC24 BACKSHELL	81205	1	52-71-11 */ /	YM643-YM649
D10988	1	BACC45FT24-61S10 PLUG-	81205	1	32-31-12 205/178/R018	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D10900

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10988 T	1	BACC10JC24 BACKSHELL	81205	1	32-31-11 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D10988 T	1	BACC10JC24 BACKSHELL	81205	1	32-31-11 */**	YK911-YK917
D10988 T	1	BACC10JC24 BACKSHELL	81205	1	32-31-11 */ /	YM643-YM649

EQUIPMENT LIST

D280A103

Section D10900
Page 3 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11002	1	BACS16W1A RELAY SOCKET	81205	1	32-31-11 J022-00/ /	ALL
D11004	1	BACS16W1A SOCKET-	81205	1	32-31-12 J00024/ /	ALL
D11008	1	BACS16W1A RELAY SOCKET	81205	1	32-31-11 J022-00/ /	ALL
D11010	1	BACS16W1A RELAY SOCKET	81205	1	32-31-12 J020-0B/ /	ALL
D11012	1	BACS16W1A RELAY SOCKET	81205	1	32-31-11 J022-00/ /	ALL
D11014	1	BACS16W1A RELAY SOCKET	81205	1	32-31-12 J020-0B/ /	ALL
D11016	1	BACS16W1A RELAY SOCKET	81205	1	32-31-12 J020-0B/ /	ALL
D11018	1	BACS16W1A RELAY SOCKET	81205	1	32-31-11 J022-00/ /	ALL
D11020	1	BACS16W1A RELAY SOCKET	81205	1	32-31-11 J022-00/ /	ALL
D11022	1	BACS16W1A RELAY SOCKET	81205	1	32-31-11 J022-00/ /	ALL
D11024	1	BACS16W1A RELAY SOCKET	81205	1	32-31-12 J020-0B/ /	ALL
D11026	1	BACS16W1A RELAY SOCKET	81205	1	32-31-12 J020-0B/ /	ALL
D11040	1	BACC63BP10C5SN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-44-12 OFSS 747/ /	ALL
D11040 T	1	BACC10KD10 BACKSHELL	81205	1	33-44-12 OFSS 749/ /	ALL
D11042	1	BACC63BP10C5SN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-44-12 OFSS-748/ /	ALL
D11042 T	1	BACC10KD10 BACKSHELL	81205	1	33-44-12 OFSS-749/ /	ALL
D11044	1	BACC63BP18C8SN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS 750/ /	ALL

EQUIPMENT LIST

D280A103

Section D11000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11044 T	1	BACC10KD18 BACKSHELL	81205	1	33-43-11 OFSS 748/ /	ALL
D11046	1	BACC63BP18C8SN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS-750/ /	ALL
D11046 T	1	BACC10KD18 BACKSHELL	81205	1	33-43-11 OFSS-748/ /	ALL
D11048	1	BACC63BP10C5SN PLUG-	81205	1	33-44-11 562/295/R030	ALL
D11048 T	1	BACC10KD10 BACKSHELL-	81205	1	33-44-11 */*/*	ALL
D11050	1	BACC63BP10C5SN PLUG-	81205	1	33-44-11 649/164/L055	ALL
D11050 T	1	BACC10KE10 BACKSHELL-90 DEGREE	81205	1	33-44-11 */*/*	ALL
D11052	1	BACC63BP14C4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS 768/009/R013	YC001-YC030
D11052 T	1	BACC10KD14 BACKSHELL-	81205	1	33-43-11 */*/*	YC001-YC030
D11054	1	BACC63BP14C4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS 811/009/R033	YC001-YC030
D11054 T	1	BACC10KD14 BACKSHELL-	81205	1	33-43-11 */*/*	YC001-YC030
D11056	1	BACC63BP14C4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS 768/009/L013	YC001-YC030
D11056 T	1	BACC10KD14 BACKSHELL-	81205	1	33-43-11 */*/*	YC001-YC030
D11058	1	BACC63BP14C4SN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS 811/009/L033	YC001-YC030
D11058 T	1	BACC10KD14 BACKSHELL-	81205	1	33-43-11 */*/*	YC001-YC030
D11064	1	BACC45FT22-55S9 PLUG-LAV A (P13-LIGHT)	81205	1	33-29-11 305/289/L019	YC001-YC030, YK901-YM670
D11064 T	1	450EB001C22-347 BACKSHELL-	81205	1	33-29-11 */*/*	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D11000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11066	1	BACC45FT22-55S9 PLUG-LAV D (P14-LIGHT)	81205	1	33-29-11 943/292/L019	YC001-YC030, YK901-YM670
D11066 T	1	BACC10JC22 BACKSHELL-	81205	1	33-29-11 */**	YC001-YC030, YK901-YM670
D11068	1	BACC45FT24-61S6 PLUG-LAV A (P13-MISC ELEC)	81205	1	23-42-11 305/289/L016	YC001-YC030, YK901-YM670
D11068 T	1	450EB001C24-347 BACKSHELL-	81205	1	23-42-11 */**	YC001-YC030, YK901-YM670
D11070	1	BACC45FT24-61S6 PLUG-LAV D (P14-MISC ELEC)	81205	1	38-41-11 941/292/L020	YC001-YC030, YK901-YM670
D11070 T	1	BACC10JC24 BACKSHELL-	81205	1	38-41-11 */**	YC001-YC030, YK901-YM670
D11072	1	AMC02PA03W PLUG-	05574	1	33-51-12 350/222/R067	ALL
D11073	1	BACS16W5A SOCKET-RELAY	81205	1	23-71-01 J022-00/180/L020	YC001-YC030
D11073	1	BACS16W5A SOCKET-RELAY	81205	1	23-71-01 J022-00/ /	YC031-YM670
D11074	1	AMC02PA03W PLUG-	05574	1	33-51-12 370/221/L069	YC001-YC030, YK901-YM652
D11076	1	AMC02PA03W PLUG-	05574	1	33-51-13 653/230/R071	YM643-YM670
D11078	1	AMC02PA03W PLUG-	05574	1	33-51-14 653/230/L071	YM643-YM652
D11080	1	AMC02PA03W PLUG-	05574	1	33-51-14 727F+11/175/R052	YC001-YC030, YK901-YL430
D11080	1	AMC02PA03W PLUG-	05574	1	33-51-12 763/175/R052	YM643-YM652
D11082	1	AMC02PA03W PLUG-	05574	1	33-51-13 727F+11/174/L052	YC001-YC030, YK901-YL430
D11082	1	AMC02PA03W PLUG-	05574	1	33-51-12 751/174/L052	YM643-YM652
D11084	1	AMC02PA03W PLUG-	05574	1	33-51-14 997/238/R057	ALL

EQUIPMENT LIST

D280A103

Section D11000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11086	1	AMC02PA03W PLUG-	05574	1	33-51-14 996/240/L056	YC001-YC030, YK901-YM652
D11088	1	AMC02PA03W PLUG-	05574	1	33-51-12 367/290/L031	YC001-YC030
D11090	1	AMC02PA03W PLUG-	05574	1	33-51-12 468/290/L036	YM643-YM652
D11092	1	AMC02PA03W PLUG-	05574	1	33-51-12 450/289/R035	YC001-YC050
D11094	1	AMC02PA03W PLUG-	05574	1	33-51-12 500A+12/290/R036	YM643-YM670
D11096	1	AMC02PA03W PLUG-	05574	1	33-51-12 500B+8/290/L036	YM643-YM652
D11098	1	AMC02PA03W PLUG-	05574	1	33-51-13 554/289/R035	YC001-YC050
D11098	1	AMC02PA03W PLUG-	05574	1	33-51-12 554/289/R035	YK901-YL430
D11098	1	AMC02PA03W PLUG-	05574	1	33-51-12 532/290/R036	YM643-YM670

EQUIPMENT LIST

D280A103

Section D11000
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11100	1	AMC02PA03W PLUG-	05574	1	33-51-13 727/290/L036	YC001-YC030, YK901-YL430
D11100	1	AMC02PA03W PLUG-	05574	1	33-51-12 548/290/L036	YM643-YM652
D11102	1	AMC02PA03W PLUG-	05574	1	33-51-13 612/290/R036	YM643-YM670
D11108	1	BACC63BP10A5SN PLUG-RIGHT LOGO LIGHT	81205	1	33-49-11 1224/294/R187	ALL
D11108 T	1	BACC10KE10 BACKSHELL, 90 DEGREE	81205	1	33-49-11 */**	ALL
D11110	1	BACC63BP10A5SN PLUG-LEFT LOGO LIGHT	81205	1	33-49-11 1222/295/L190	ALL
D11110 T	1	BACC10KE10 BACKSHELL, 90 DEGREE	81205	1	33-49-11 */**	ALL
D11114	1	DPX3MB-26S67S67S-33B-0001 PLUG PLATE ASSY	71468	1	49-41-11 E002-02/ /	YC001-YC004
D11114	1	DPX3MA66565-252 PLUG PLATE ASSY	71468	1	49-41-11 E002-02/ /	YC005-YC030, YK901-YM670
D11114A	1	PARTAOFD11114 PLUG		1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D11114B	1	PARTBOFD11114 PLUG		1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D11114C	1	PARTCOFD11114 PLUG		1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D11118	1	BACC63CN2430SN RECP-CONDUCTIVE	81205	1	49-41-11 1088/233/R014	YC001-YC030
D11118	1	BACC63CN2430SN RECP-CONDUCTIVE	81205	1	49-41-11 1089/229/R014	YK901-YM670
D11118 T	1	BACC10KA24 BACKSHELL	81205	1	49-41-11 1088/233/R014	YC001-YC030, YK901-YK910, YL421-YL423, YM643
D11118 T	1	BACC10KA24 BACKSHELL	81205	1	49-41-11 */**	YK911-YL401, YL424-YL430, YM645-YM670

EQUIPMENT LIST

D280A103

Section D11100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11120	1	BACC63BP12A3SN PLUG	81205	1	32-41-11 707/117/L132	ALL
D11122	1	BACC63BP12A3SN PLUG	81205	1	32-41-11 707/117/L94	ALL
D11124	1	BACC63BP12A3SN PLUG-	81205	1	32-41-11 707/117/R94	ALL
D11125	1	BACC45FT12-12S PLUG-	81205	1	23-71-01 P005-88/ /	YC001-YC030, YK901-YM670
D11126	1	BACC63BP12A3SN PLUG	81205	1	32-41-11 707/117/R132	ALL
D11128	1	BACC45FN16-24S RECP-	81205	1	78-32-51 251/195/L003	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11128 T	1	BACC10JS16 BACKSHELL	81205	1	78-32-51 TBD/ /	YC001-YC007
D11128 T	1	BACC10JS16 BACKSHELL	81205	1	78-32-51 */*/	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11130	1	BACC45FN14-15S RCPT	81205	1	78-34-11 AB0250A/195/L005	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11130 T	1	BACC10JS14 BACKSHELL	81205	1	78-34-11 P008/ /	YC001-YC030
D11130 T	1	BACC10JS14 BACKSHELL	81205	1	78-34-11 */*/	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11131	1	BACS16X4A SOCKET-RELAY	81205	1	23-71-01 J022-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D11100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11132	1	BACC45FN16-24S6 RECP-	81205	1	78-32-61 251/197/L004	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11132 T	1	BACC10JS16 BACKSHELL	81205	1	78-32-61 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11134	1	BACC45FN14-15S6 RCPT	81205	1	78-34-21 251/197/L005	YC001-YC003
D11134	1	BACC45FN14-15S6 RCPT-	81205	1	78-34-21 251/197/L005	YC004-YC030, YK901-YM670
D11134 T	1	BACC10JS14 BACKSHELL	81205	1	32-42-11 TBD/ /	YC001-YC003
D11134 T	1	BACC10JS14 BACKSHELL-	81205	1	78-34-21 / /	YC004-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D11134 T	1	BACC10JS14 BACKSHELL-	81205	1	78-34-21 */**	YK911-YK917
D11134 T	1	BACC10JS14 BACKSHELL-	81205	1	78-34-21 */ /	YM643-YM649
D11138	1	BACC45FT24-61S PLUG-	81205	1	32-64-11 205/189/R022	YC001-YC030, YK901-YM670
D11138 T	1	BACC10JC24 BACKSHELL	81205	1	32-31-11 */**	YC001-YC030, YK901-YM670
D11140	1	BACC45FT24-61S PLUG-	81205	1	32-64-12 205/175/R017	ALL
D11140 T	1	BACC10JC24 BACKSHELL-90 DEGREE	81205	1	32-31-12 / /	YC001-YC030, YK901-YK905
D11140 T	1	BACC10JC24 BACKSHELL-90 DEGREE	81205	1	32-31-12 */**	YC031-YC050, YK906-YM670
D11142	1	BACC45FT24-61S6 PLUG-	81205	1	32-31-11 205/187/R022	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D11100

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11142 T	1	BACC10JC24 BACKSHELL	81205	1	32-31-11 */**	YC001-YC030, YK901-YM670
D11154	1	BACS16AF1 SOCKET-	81205	1	32-44-11 J00024/ /	ALL
D11158	1	BACC63CC14-15S6 RCPT-	81205	1	73-21-21 238/202/L005	ALL
D11158 T	1	BACC10KD14 BACKSHELL	81205	1	73-21-21 TBD/ /	ALL
D11160	1	BACC63CC14-15S8 RCPT-	81205	1	73-21-21 238/203/L005	ALL
D11160 T	1	BACC10KD14 BACKSHELL	81205	1	73-21-21 */**	ALL
D11162	1	BACC63CC14-15S6 RCPT-	81205	1	73-21-21 238/202/R5	ALL
D11162 T	1	BACC10KD14 BACKSHELL	81205	1	73-21-21 TBD/ /	ALL
D11164	1	BACC63CC14-15S8 RCPT-	81205	1	73-21-21 238/203/R5	YC001-YL430
D11164	1	BACC63CC14-15S8 RCPT-	81205	1	73-21-21 238/203/R005	YM643-YM670
D11164 T	1	BACC10KD14 BACKSHELL	81205	1	73-21-21 TBD/ /	YC001-YL430
D11164 T	1	BACC10KD14 BACKSHELL	81205	1	73-21-21 */**	YM643-YM670
D11173	1	BACC45FT10-5S PLUG - NONCONDUCTIVE	81205	1	23-42-12 923/289/R029	YM643-YM670
D11173 T	1	BACC10JS10 BACKSHELL	81205	1	23-42-12 */**	YM643-YM670
D11179	1	BACS16AH1 SOCKET 30 SEC DELAY RELAY	81205	1	27-31-37 J011-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D11100
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11281	1	DPXBMA-10-33P-0029 PLUG	71468	1	34-24-15 E004-01/ /	YK901-YM670
D11284	1	BACC45FN20-25S RCPT-	81205	1	25-51-21 727/172/L015	YC001-YC030, YM643-YM670
D11284	1	BACC45FN20-25S RCPT-	81205	1	25-51-21 727+4/172/L015	YC031-YL430
D11286	1	BACC63CC14-15SN RECP-CONDUCTIVE	81205	1	76-21-11 213/210/L001	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11286 T	1	BACC10KD14 BACKSHELL	81205	1	76-21-21 / /	YC001-YC007
D11286 T	1	BACC10KD14 BACKSHELL	81205	1	76-21-21 */*/*	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11288	1	BACC63CC14-15S6 RECP-CONDUCTIVE	81205	1	76-21-11 213/210/R001	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11288 T	1	BACC10KD14 BACKSHELL-	81205	1	76-21-21 / /	YC001-YC030
D11288 T	1	BACC10KD14 BACKSHELL-	81205	1	76-21-21 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11290	1	BACC63CC14-15S7 RECP-CONDUCTIVE	81205	1	76-21-21 AF0222A/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D11200

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11290 T	1	BACC10KD14 BACKSHELL-	81205	1	76-21-21 / /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11292	1	BACC63CC14-15S8 RECP-CONDUCTIVE	81205	1	76-21-21 AF0222A/ /	YC001-YC003, YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11292	1	BACC63CC14-15S8 RECP-CONDUCTIVE	81205	1	76-21-21 AF0222A/*/*	YC004-YC026
D11292 T	1	BACC10KE14 BACKSHELL-	81205	1	74-11-11 */*/*	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11294	1	00855-1727-0001 PLUG-LEFT PITOT HEATER	04274	1	30-31-11 192/225/L32	ALL
D11296	1	00855-1727-0001 PLUG-LEFT ELEVATOR PITOT HEATER	04274	1	30-31-11 1071/388/L007	ALL
D11298	1	00855-1727-0001 PLUG-LWR RIGHT PITOT HEATER	04274	1	30-31-12 192/ /	YC001-YC006
D11298	1	00855-1727-0001 PLUG-LWR RIGHT PITOT HEATER	04274	1	30-31-12 193/214/R033	YC007-YM652

EQUIPMENT LIST

D280A103

Section D11200
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11300	1	00855-1727-0001 PLUG-UPPER RIGHT PITOT HEATER	04274	1	30-31-12 192/ /	YC001-YC006
D11300	1	00855-1727-0001 PLUG-UPPER RIGHT PITOT HEATER	04274	1	30-31-12 193/226/R033	YC007-YM652
D11302	1	00855-1727-0001 PLUG-RIGHT ELEVATOR PITOT HEATER	04274	1	30-31-12 1071/388/R007	ALL
D11304	1	BACC63CB18-31S6 PLUG	81205	1	28-41-11 222/178/L021	ALL
D11304 T	1	BACC10KD18 BACKSHELL	81205	1	28-41-11 */*/*	ALL
D11306	1	BACC63CB18-31SN PLUG	81205	1	28-41-11 221/179/L019	ALL
D11306 T	1	BACC10KD18 BACKSHELL	81205	1	28-41-11 TBD/ /	ALL
D11308	1	BACC63CB18-31S7 PLUG	81205	1	28-41-11 223/178/L017	ALL
D11308 T	1	BACC10KD18 BACKSHELL	81205	1	28-41-11 */*/*	ALL
D11312	1	S283A202-11 PLUG	81205	1	28-41-11 OFSS-265/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11312 T	1	BACC10KE24 BACKSHELL	81205	1	28-41-11 OFSS-265/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D11314	1	S283A202-11 PLUG	81205	1	28-41-11 OFSS 265/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D11314 T	1	BACC10KE24 BACKSHELL	81205	1	28-41-11 OFSS 265/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D11300

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11316	1	S283A202-11 PLUG	81205	1	28-41-11 666/185/L043	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11316 T	1	BACC10KE24 BACKSHELL-	81205	1	28-41-11 TBD/ /	YC001-YC007
D11316 T	1	BACC10KE24 BACKSHELL-	81205	1	28-41-11 */*/	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11318	1	BACC63BP16C24SN PLUG	81205	1	28-44-12 P015-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11318 T	1	BACC10KE16 BACKSHELL	81205	1	28-44-12 P015-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11320	1	BACC63BP16C24SN PLUG	81205	1	28-44-12 P015-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11320 T	1	BACC10KE16 BACKSHELL	81205	1	28-44-12 P015-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11322	1	BACC63BP16C24SN PLUG	81205	1	28-44-12 P015-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11322 T	1	BACC10KE16 BACKSHELL	81205	1	28-44-12 P015-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11326	1	AMC02PA03W PLUG-	05574	1	33-51-13 727D/290/L036	YC001-YC030, YK901-YL430

EQUIPMENT LIST

D280A103

Section D11300

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11326	1	AMC02PA03W PLUG-	05574	1	33-51-12 628/290/L036	YM643-YM652
D11328	1	AMC02PA03W PLUG-	05574	1	33-51-13 692/290/R036	YM643-YM670
D11330	1	AMC02PA03W PLUG-	05574	1	33-51-13 706/290/L035	YM643-YM652
D11332	1	AMC02PA03W PLUG-	05574	1	33-51-14 727B+5/290/R036	YM643-YM670
D11334	1	AMC02PA03W PLUG-	05574	1	33-51-14 727G+15/290/L036	YC001-YC030, YK901-YL430
D11334	1	AMC02PA03W PLUG-	05574	1	33-51-13 727C+1/290/L036	YM643-YM652
D11336	1	AMC02PA03W PLUG-	05574	1	33-51-14 752/290/R036	YM643-YM670
D11338	1	AMC02PA03W PLUG-	05574	1	33-51-12 767/289/L035	YC001-YC030, YK901-YM652
D11344	1	AMC02RA03W RCPT-	05574	23	33-51-21 MULTI/ /	YC001-YC011
D11352	1	BACC63CB8-2SN PLUG	81206	1	28-41-11 221/178/L018	YC001-YC003
D11352	1	BACC63CB8-2SN PLUG	81205	1	28-41-11 221/178/L018	YC004-YM670
D11352 T	1	BACC10KD8 BACKSHELL	81205	1	28-41-11 */*/*	ALL
D11354	1	BACC63CB8-2S6 PLUG	81205	1	28-41-11 223/178/L021	ALL
D11354 T	1	BACC10KD8 BACKSHELL	81205	1	28-41-11 TBD/ /	ALL
D11356	1	AMC02PA03B PLUG-	05574	1	33-26-31 370/291/L000	ALL
D11358	1	AMC02PA03B PLUG-	05574	1	33-26-31 911/292/L001	ALL
D11360	1	BACC45FT10-5S PLUG-	81205	1	21-61-21 373/196/L058	YM643-YM670

EQUIPMENT LIST

D280A103

Section D11300

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11360 T	1	BACC10JC10 BACKSHELL-90 DEGREE	81205	1	21-61-21 */*/*	YM643-YM670
D11362	1	BACC45FT10-5S PLUG-	81205	1	21-61-22 532/299/R010	YM643-YM670
D11366	1	AMC02PA03R PLUG-	05574	1	35-21-21 314/286/L027	ALL
D11368	1	AMC02PA03R PLUG-	05574	1	35-21-21 962/291/L025	ALL
D11369	1	756-16-9 PLUG	91836	1	23-32-13 848/277/R042	YK901-YM670
D11370	1	BACS16X1A SOCKET-STANDBY SHUTOFF VLV IND RLY R625	81205	1	29-25-11 J011-00/ /	ALL
D11371	1	756-16-9 PLUG	91836	1	23-32-13 848/277/R042	YK901-YM670
D11372	1	S280W557-801 PLUG-	81205	1	33-22-31 381/290/R012	YC001-YC026
D11372	1	BACC65AL801S PLUG-	81205	1	33-22-31 381/290/R012	YC028-YM670
D11382	1	S280W557-801 PLUG-	81205	1	33-22-22 899/290/R010	YC001-YC026
D11382	1	BACC65AL801S PLUG-	81205	1	33-22-22 899/290/R010	YC028-YM670
D11384	1	S280W557-801 PLUG-	81205	1	33-22-31 383/290/L012	YC001-YC026
D11384	1	BACC65AL801S PLUG-	81205	1	33-22-31 383/290/L012	YC028-YM670
D11394	1	S280W557-801 PLUG-	81205	1	33-22-22 897/290/L010	YC001-YC026
D11394	1	BACC65AL801S PLUG-	81205	1	33-22-22 897/290/L010	YC028-YM670
D11396	1	MB12P-1 PLUG-	09922	1	33-26-21 321/292/R023	ALL
D11398	1	S280W557-801 PLUG-	81205	1	33-26-21 324/291/R023	YC001-YC026

EQUIPMENT LIST

D280A103

Section D11300

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11398	1	BACC65AL803S PLUG-	81205	1	33-26-21 324/291/R023	YC028-YM670

EQUIPMENT LIST

D280A103

Section D11300
Page 5 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11400	1	S280W557-802 RCPT-	81205	1	33-26-21 324/292/R024	YC001-YC026
D11400	1	BACC65AM802P RCPT-	81205	1	33-26-21 324/292/R024	YC028-YM670
D11402	1	BACS16AF1 SOCKET-	81205	1	32-41-11 J00024/ /	ALL
D11404	1	BACS16AF1 RELAY SOCKET	81205	1	32-41-11 J022-00/ /	ALL
D11406	1	BACS16AF1 RELAY SOCKET	81205	1	32-41-11 J022-00/ /	ALL
D11409	1	BACC63BP10C5SN PLUG	81205	1	27-32-31 1083/266/L029	ALL
D11409 T	1	BACC10KE10 BACKSHELL	81205	1	27-32-31 1083/ /	YC001-YC007
D11409 T	1	BACC10KE10 BACKSHELL	81205	1	27-32-31 1083/266/L029	YC008-YC022
D11409 T	1	BACC10KE10 BACKSHELL	81205	1	27-32-31 1083/266/L29	YC023-YM670
D11412	1	BACC63CE24-10P PLUG-	81205	1	24-51-11 P91/ /	YC001-YC007
D11412	1	BACC63CE24-10P PLUG-	81205	1	24-51-11 378/179/L043	YC008-YM670
D11414	1	BACC63CE24-10PW PLUG-	81205	1	24-51-11 377 P91/179/L45	YC001-YC007
D11414	1	BACC63CE24-10PW PLUG-	81205	1	24-51-11 378/179/L046	YC008-YM670
D11416	1	BACC45FT24-43P PLUG-	81205	1	24-52-11 P091-00/ /	ALL
D11416 T	1	BACC10JS24 BACKSHELL-	81205	1	24-52-11 */*/	ALL
D11418	1	BACC45FT16-24P PLUG-	81205	1	21-42-11 378/176/L043	YC001-YC030, YK901-YM670
D11418 T	1	BACC10JC16 BACKSHELL-	81205	1	21-42-11 */*/	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D11400

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11420	1	BACC63CE24-11S PLUG-	81205	1	24-52-11 378/177/L047	ALL
D11422	1	BACC45FT14-7P6 PLUG-	81205	1	21-27-21 378/177/L045	YC001-YC030, YK901-YM670
D11422 T	1	BACC10JC14 BACKSHELL-	81205	1	21-27-21 */*/*	YC001-YC030, YK901-YM670
D11424	1	BACC63CE24-10PZ PLUG-	81205	1	24-34-11 377 P91/173/L42	YC001-YC007
D11424	1	BACC63CE24-10PZ PLUG-	81205	1	24-34-11 378/174/L043	YC008-YM670
D11426	1	BACC63CE24-10S PLUG-	81205	1	24-32-11 P091-00/ /	ALL
D11428	1	BACC63CE24-11P PLUG-	81205	1	29-11-12 P091-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11428 T	1	BACC10HV24 BACKSHELL-	81205	1	29-11-12 388/179/L46	YC001-YK910, YL421-YL423, YM643
D11428 T	1	BACC10HV24 BACKSHELL-	81205	1	29-11-12 */*/*	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM652
D11430	1	BACC63CE24-10PW PLUG-	81205	1	25-31-11 P091-00/ /	ALL
D11430 T	1	BACC10HV24 BACKSHELL-	81205	1	25-31-11 */*/*	ALL
D11432	1	BACC45FT24-61P PLUG-	81205	1	24-24-11 P091-00/ /	YC001-YC030, YK901-YM670
D11434	1	BACC45FT24-43P PLUG	81205	1	24-32-11 P091-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D11400

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11436	1	BACC45FT16-24P6 PLUG-	81205	1	24-22-31 P091-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11438	1	BACC45FT16-10P PLUG-	81205	1	24-21-31 P091-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11440	1	BACC63CE24-10P PLUG-	81205	1	24-61-11 P092 378/179/R44	YC001-YC007
D11440	1	BACC63CE24-10P PLUG-	81205	1	24-61-11 P092/ /	YC008-YM670
D11442	1	BACC63CE24-10PW PLUG-	81205	1	24-51-21 P092 378/179/R42	YC001-YC007
D11442	1	BACC63CE24-10PW PLUG-	81205	1	24-51-21 P092/ /	YC008-YM670
D11444	1	BACC63CE24-10PZ PLUG-	81205	1	24-51-21 P092 378/179/R39	YC001-YC007
D11444	1	BACC63CE24-10PZ PLUG-	81205	1	24-51-21 P092/ /	YC008-YM670
D11446	1	BACC45FT14-4P PLUG-	81205	1	24-52-11 378/177/R42	ALL
D11446 T	1	450EB001C14-347 BACKSHELL	81205	1	24-51-11 P92/ /	ALL
D11448	1	BACC45FT24-43P PLUG-	81205	1	24-41-11 P092/176/R039	YC001-YM652
D11448 T	1	BACC10JS24 BACKSHELL-	81205	1	24-41-11 */*/*	YC001-YM652
D11450	1	BACC63CE24-11S PLUG-	81205	1	24-32-11 378 P92/177/R44	YC001-YC029
D11450	1	BACC63CE24-11S PLUG-	81205	1	24-32-11 378 P92/177/R044	YC030
D11450	1	BACC63CE24-11S PLUG-	81205	1	24-32-11 378/177/R044	YK901-YM670

EQUIPMENT LIST

D280A103

Section D11400

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11450 T	1	BACC10HV24 BACKSHELL-	81205	1	24-32-11 */*/*	YC001-YC030, YK901-YM670
D11452	1	BACC45FT24-43P6 PLUG-	81205	1	33-23-21 P092-00/174/R039	ALL
D11452 T	1	BACC10GH24 BACKSHELL-	81205	1	33-23-21 */*/*	ALL
D11454	1	BACC45FT24-61P PLUG	81205	1	24-22-21 P092-00/179/R039	ALL
D11456	1	BACC63CE24-11P PLUG-	81205	1	29-11-12 P092-00/ /	ALL
D11458	1	BACC63CE24-10P PLUG-	81205	1	25-31-11 388/179/R039	ALL
D11458 T	1	BACC10HV24 BACKSHELL-	81205	1	25-31-11 */*/*	ALL
D11460	1	S280W557-121 PLUG-	81205	1	33-29-11 972/292/R007	YC001-YC026
D11460	1	BACC65AJ121S PLUG-	81205	1	33-29-11 972/292/R007	YC028-YM670
D11462	1	S280W557-221 RCPT-	81205	1	33-29-11 973/292/R008	YC001-YC026
D11462	1	BACC65AK221P RCPT-	81205	1	33-29-11 973/292/R008	YC028-YM670
D11464	1	MB12P-1 PLUG-	09922	1	33-29-11 972/293/L005	ALL
D11470	1	AMC02PA03R PLUG-	05574	1	30-71-11 868/179/L043	ALL
D11478	1	DPX2MA-67SD8S-33B-0001 PLUG PLATE ASSY	71468	1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D11478A	1	PARTAOFD11478 PLUG		1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D11478B	1	PARTBOFD11478 PLUG		1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D11480	1	AMC02PA03R PLUG-	05574	1	35-21-21 962/291/R026	ALL

EQUIPMENT LIST

D280A103

Section D11400

Page 4 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11500	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 360/274/L051	YC001-YC026
D11500	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 367/272/L055	YC028-YM670
D11500 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11502	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 380/274/L051	YC001-YC026
D11502	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 374/272/L056	YC028-YL430
D11502	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 370/274/L051	YM643-YM670
D11502 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11504	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 400/274/L051	YC001-YC026
D11504	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 402/278/L050	YC028-YL430
D11504	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 390/274/L051	YM643-YM670
D11504 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11506	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 430/274/L051	YC001-YL430
D11506	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 410/274/L051	YM643-YM670
D11506 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11508	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 450/274/L051	YC001-YL430
D11508	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 430/274/L051	YM643-YM670
D11508 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL

EQUIPMENT LIST

D280A103

Section D11500

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11510	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 470/274/L051	YC001-YL430
D11510	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 450/274/L051	YM643-YM670
D11510 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11512	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 490/274/L051	YC001-YL430
D11512	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 478/274/L051	YM643-YM670
D11512 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11514	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500+10/274/L051	YC001-YL430
D11514	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 498/274/L051	YM643-YM670
D11514 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11516	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500A+12/274/L051	YC001-YL430
D11516	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500A+14/274/L051	YM643-YM670
D11516 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11518	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500B+12/274/L051	YC001-YL430
D11518	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500C+2/274/L051	YM643-YM670
D11518 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11520	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500C+12/274/L051	YC001-YL430
D11520	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500D+19/277/L053	YM643-YM670

EQUIPMENT LIST

D280A103

Section D11500

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11520 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11522	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500D+12/274/L051	YC001-YL430
D11522 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11524	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500E+16/274/L051	YC001-YL430
D11524 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11526	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500F+14/274/L051	YC001-YL430
D11526 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11528	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500G+10/274/L051	YC001-YL430
D11528 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11530	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500H+10/274/L051	YC001-YC026
D11530	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500H+6/274/L052	YC028-YL430
D11530	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 551/279/L055	YM643-YM670
D11530 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11532	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 520/274/L051	YC001-YC026
D11532	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 500I+16/273/L054	YC028-YL430
D11532	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 566/274/L051	YM643-YM670
D11532 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL

EQUIPMENT LIST

D280A103

Section D11500

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11534	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 545/274/L051	YC001-YC026
D11534	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 531/273/L054	YC028-YL430
D11534	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 594/274/L051	YM643-YM670
D11534 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11536	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 565/274/L051	YC001-YL430
D11536	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 622/274/L051	YM643-YM670
D11536 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11538	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 588/274/L051	YC001-YL430
D11538	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 650/274/L051	YM643-YM670
D11538 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11540	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 611/274/L051	YC001-YL430
D11540	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 678/274/L051	YM643-YM670
D11540 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11542	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 630/274/L051	YC001-YL430
D11542	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 700/274/L051	YM643-YM670
D11542 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11544	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 660/274/L051	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11500

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11544	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727+19/272/L057	YM643-YM670
D11544 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11546	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 680/274/L051	YC001-YL430
D11546	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727A+15/274/L051	YM643-YM670
D11546 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11548	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 700/274/L051	YC001-YL430
D11548	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727C+13/274/L051	YM643-YM670
D11548 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11550	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 718/274/L051	YC001-YC026
D11550	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 726/272/L054	YC028-YL430
D11550	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727D+11/274/L051	YM643-YM670
D11550 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11552	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727+10/274/L051	YC001-YL430
D11552	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727E+14/272/L058	YM643-YM670
D11552 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11554	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727A+10/274/L051	YC001-YC026
D11554	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727A+16/272/L054	YC028-YL430

EQUIPMENT LIST

D280A103

Section D11500

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11554 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11556	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727B+10/274/L051	YC001-YL430
D11556 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11558	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727C+10/274/L051	YC001-YL430
D11558 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11560	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727D+10/274/L051	YC001-YL430
D11560 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11562	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727E+10/274/L051	YC001-YL430
D11562 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	YC001-YL430
D11564	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727F+10/274/L051	YC001-YL430
D11564	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 780/274/L051	YM643-YM670
D11564 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11566	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 727G+10/274/L051	YC001-YC026
D11566	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 727G+12/272/L054	YC028-YL430
D11566	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-11 815/269/L061	YM643-YM670
D11566 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11568	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727H+10/274/L051	YC001-YC026

EQUIPMENT LIST

D280A103

Section D11500

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11568	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727H+8/272/L054	YC028-YL430
D11568	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 830/274/L051	YM643-YM670
D11568 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11570	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727I+10/274/L051	YC001-YC026
D11570	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727I+16/272/L054	YC028-YL430
D11570	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 866/273/L053	YM643-YM670
D11570 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11572	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727J+10/274/L051	YC001-YC026
D11572	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 727J+8/272/L054	YC028-YL430
D11572	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 898/274/L056	YM643-YM670
D11572 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	ALL
D11574	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 757/274/L051	YC001-YC026
D11574	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 763/272/L054	YC028-YL430
D11574 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */**	YC001-YL430
D11576	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 785/274/L051	YC001-YC026
D11576	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 775/272/L054	YC028-YL430
D11576	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 914/274/L051	YM643-YM670

EQUIPMENT LIST

D280A103

Section D11500

Page 7

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11576 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11578	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 802/274/L051	YC001-YL430
D11578	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 943/277/L050	YM643-YM670
D11578 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/*	ALL
D11580	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 822/274/L051	YC001-YL430
D11580 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	YC001-YL430
D11582	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 842/274/L051	YC001-YL430
D11582 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	YC001-YL430
D11584	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 865/274/L051	YC001-YL430
D11584 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	YC001-YL430
D11586	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 890/274/L051	YC001-YC026
D11586	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 898/274/L056	YC028-YL430
D11586 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	YC001-YL430
D11588	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 924/274/L051	YC001-YL430
D11588 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	YC001-YL430
D11590	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 937/274/L051	YC001-YC026
D11590	1	BACC45FN18-14S RCPT-PSU LEFT	81205	1	33-23-12 943/277/L050	YC028-YL430

EQUIPMENT LIST

D280A103

Section D11500

Page 8

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11590 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11500
Page 9 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11600	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 360/274/R051	YC001-YL430
D11600	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 361/273/R049	YM643-YM670
D11600 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	ALL
D11602	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 380/274/R051	YC001-YC026
D11602	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 391/273/R051	YC028-YL430
D11602	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 381/275/R052	YM643-YM670
D11602 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	ALL
D11604	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 400/274/R051	YC001-YC026
D11604	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 410/273/R052	YC028-YL430
D11604	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 383/275/R052	YM643-YM670
D11604 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	ALL
D11606	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 430/274/R051	YC001-YC050
D11606	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 431/273/R052	YK901-YL430
D11606	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 410/274/R051	YM643-YM670
D11606 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	ALL
D11608	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 450/274/R051	YC001-YL430
D11608	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 436/276/R053	YM643-YM670

EQUIPMENT LIST

D280A103

Section D11600

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11608 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */**	ALL
D11610	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 470/274/R051	YC001-YL430
D11610	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 450/274/R051	YM643-YM670
D11610 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */**	ALL
D11612	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 490/274/R051	YC001-YL430
D11612	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 478/274/R051	YM643-YM670
D11612 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */**	ALL
D11613	1	BACC63BV10F5SN RCPT - CONDUCTIVE	81205	1	22-11-81 1142/ /	YC020-YC022
D11613	1	BACC63BV10F5SN RCPT - CONDUCTIVE	81205	1	22-11-81 RUD77.0/ /	YC023-YM670
D11613 T	1	BACC10KD10 BAKCSHELL	81205	1	22-11-81 */**	YC020-YM670
D11614	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500+10/274/R051	YC001-YL430
D11614	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 498/274/R051	YM643-YM670
D11614 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */**	ALL
D11615	1	BACC63BV10F5SN RCPT - CONDUCTIVE	81205	1	22-11-81 1144/ /	YC020-YC022
D11615	1	BACC63BV10F5SN RCPT - CONDUCTIVE	81205	1	22-11-81 RUD77.0/ /	YC023-YM670
D11615 T	1	BACC10KD10 BAKCSHELL	81205	1	22-11-81 */**	YC020-YM670
D11616	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500A+12/274/R051	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11600

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11616	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500A+14/274/R051	YM643-YM670
D11616 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */**	ALL
D11617	1	BACC63BP16C24SN PLUG - CONDUCTIVE	81205	1	22-11-81 1135/ /	YC020-YC022
D11617	1	BACC63BP16C24SN PLUG - CONDUCTIVE	81205	1	22-11-81 RUD82.0/ /	YC023-YM670
D11617 T	1	BACC10KF16 BACKSHELL	81205	1	22-11-81 */**	YC020-YM670
D11618	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500B+12/874/R051	YC001-YL430
D11618	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500C+10/273/R055	YM643-YM670
D11618 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */**	ALL
D11619	1	BACC63BP16C24SN PLUG - CONDUCTIVE	81205	1	22-11-81 1134/ /	YC020-YC022
D11619	1	BACC63BP16C24SN PLUG - CONDUCTIVE	81205	1	22-11-81 RUD82.0/ /	YC023-YM670
D11619 T	1	BACC10KF16 BACKSHELL	81205	1	22-11-81 */**	YC020-YM670
D11620	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500C+12/274/R051	YC001-YL430
D11620	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500D+10/274/R051	YM643-YM670
D11620 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */**	ALL
D11622	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500D+12/274/R051	YC001-YL430
D11622 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */**	YC001-YL430
D11624	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500E+16/274/R051	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11600

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11624 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	YC001-YL430
D11626	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500F+14/274/R051	YC001-YL430
D11626 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	YC001-YL430
D11628	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500G+10/274/R051	YC001-YL430
D11628 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	YC001-YL430
D11630	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500H+10/274/R051	YC001-YL430
D11630	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 559/274/R051	YM643-YM670
D11630 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	ALL
D11632	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 520/274/R051	YC001-YC026
D11632	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 500I+16/273/R054	YC028-YL430
D11632	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 566/274/R051	YM643-YM670
D11632 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/*	ALL
D11634	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 545/274/R051	YC001-YL430
D11634	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-21 594/274/R051	YM643-YM670
D11634 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11636	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 565/274/R051	YC001-YL430
D11636	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 622/274/R051	YM643-YM670

EQUIPMENT LIST

D280A103

Section D11600

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11636 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11638	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 588/274/R051	YC001-YL430
D11638	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 650/274/R051	YM643-YM670
D11638 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11640	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 611/274/R051	YC001-YL430
D11640	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 678/274/R051	YM643-YM670
D11640 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11642	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 630/274/R051	YC001-YL430
D11642	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 712/273/R060	YM643-YM670
D11642 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11644	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 660/274/R051	YC001-YL430
D11644	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727+19/271/R058	YM643-YM670
D11644 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11646	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 680/274/R051	YC001-YL430
D11646	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727A+15/274/R051	YM643-YM670
D11646 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11648	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 700/274/R051	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11600

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11648	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727C+13/274/R051	YM643-YM670
D11648 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11650	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 718/274/R051	YC001-YC026
D11650	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 726/273/R054	YC028-YL430
D11650	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727D+11/274/R051	YM643-YM670
D11650 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11652	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727+10/274/R051	YC001-YL430
D11652	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 764/273/R058	YM643-YM670
D11652 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11654	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727A+10/274/R051	YC001-YC026
D11654	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727A+16/272/R054	YC028-YL430
D11654 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430
D11656	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727B+10/274/R051	YC001-YL430
D11656 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430
D11658	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727C+10/274/R051	YC001-YC026
D11658	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727C+18/272/R054	YC028-YL430
D11658 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11600

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11660	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727D+10/274/R051	YC001-YL430
D11660 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */**	YC001-YL430
D11662	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727E+10/274/R051	YC001-YC026
D11662	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727E+18/272/R054	YC028-YL430
D11662 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */**	YC001-YL430
D11664	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727F+10/274/R051	YC001-YL430
D11664	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 774/274/R051	YM643-YM670
D11664 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */**	ALL
D11666	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727G+10/274/R051	YC001-YC026
D11666	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727G+18/272/R054	YC028-YL430
D11666	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 802/274/R051	YM643-YM670
D11666 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */**	ALL
D11668	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727H+10/274/R051	YC001-YL430
D11668	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 830/274/R051	YM643-YM670
D11668 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */**	ALL
D11670	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727I+10/274/R051	YC001-YC026
D11670	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727I+16/272/R054	YC028-YL430

EQUIPMENT LIST

D280A103

Section D11600

Page 7

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11670	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 862/273/R057	YM643-YM670
D11670 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11672	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 727J+10/274/R051	YC001-YL430
D11672	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 872/273/R056	YM643-YM670
D11672 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11674	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 757/274/R051	YC001-YC026
D11674	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 763/272/R054	YC028-YL430
D11674 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430
D11676	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 785/274/R051	YC001-YL430
D11676	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 914/274/R051	YM643-YM670
D11676 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11678	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 802/274/R051	YC001-YL430
D11678	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 932/274/R051	YM643-YM670
D11678 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	ALL
D11680	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 822/274/R051	YC001-YL430
D11680 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430
D11682	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 842/274/R051	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11600

Page 8

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11682 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430
D11684	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 865/274/R051	YC001-YL430
D11684 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430
D11686	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 890/274/R051	YC001-YL430
D11686 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430
D11688	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 924/274/R051	YC001-YL430
D11688 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430
D11690	1	BACC45FN18-14S RCPT-PSU RIGHT	81205	1	33-23-22 937/274/R051	YC001-YL430
D11690 T	1	69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11600

Page 9 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11702	1	BACC45FT16-24S PLUG-	81205	1	38-32-12 862/198/L019	ALL
D11702 T	1	BACC10JS16 BACKSHELL-	81205	1	38-32-12 */**	ALL
D11712	1	DSXN2PS8SS36C7P7301 PLUG PLATE ASSY	71468	1	24-31-11 P006-00/ /	ALL
D11712A	1	PARTAOFD11712 MATING CONNECTOR		1	24-31-11 P006-00/ /	ALL
D11712B	1	PARTBOFD11712 MATING CONNECTOR		1	24-32-11 P006-00/ /	ALL
D11714	1	DSXN2PS36C7PS67S7301 PLUG PLATE ASSY	71468	1	24-31-11 P006-00/ /	ALL
D11714A	1	PARTAOFD11714 MATING CONNECTOR		1	24-28-11 P006-00/ /	ALL
D11714B	1	PARTBOFD11714 MATING CONNECTOR		1	24-31-11 P006-00/ /	ALL
D11716	1	BACC45FN8-3S RCPT-	81205	1	38-32-12 868/178/L040	ALL
D11718	1	BACC45FT18-8S PLUG-	81205	1	38-32-12 856/190/L043	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11718 T	1	BACC10GH18 BACKSHELL-	81205	1	38-32-12 856/190/L043	YC001-YK910, YL421-YL423, YM643
D11718 T	1	BACC10GH18 BACKSHELL-	81205	1	38-32-12 */**	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM652
D11722	1	AMC02PA03B PLUG-	05574	1	33-25-21 352/279/L030	YC001-YC030, YM643-YM670
D11722	1	AMC02PA03B PLUG-	05574	1	33-25-21 368/289/L032	YC031-YL430

EQUIPMENT LIST

D280A103

Section D11700

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11724	1	AMC02RA03B RCPT-	05574	1	33-25-21 352/279/L030	YK912-YK917, YK919-YL430, YM652
D11728	1	BACC63BV10B5SN PLUG-CONDUCTIVE	81205	1	31-53-11 678/195/R063	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11728 T	1	BACC10KB10 BACKSHELL-CONDUCTIVE	81205	1	31-53-11 / /	YC001-YC028
D11728 T	1	BACC10KB10 BACKSHELL-CONDUCTIVE	81205	1	31-53-11 */*/*	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11730	1	BACC63BP12C3SN PLUG-CONDUCTIVE	81205	1	27-62-21 673/196/R060	YC001-YC030
D11730	1	BACC63BP12H3SN PLUG-CONDUCTIVE	81205	1	27-62-21 673/196/R060	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11730 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	27-62-21 TBD/ /	YC001-YC028
D11730 T	1	BACC10KF12 BACKSHELL-CONDUCTIVE	81205	1	27-62-21 */*/*	YC029-YC030
D11730 T	1	BACC10KF12 BACKSHELL-CONDUCTIVE 45 DEG	81205	1	27-62-21 */*/*	YC031-YK906
D11730 T	1	620AB049C12 BACKSHELL-CONDUCTIVE 45 DEG	81205	1	27-62-21 */*/*	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11732	1	BACC45FT18-31S PLUG	81205	1	32-64-11 P002-03/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11732 T	1	BACC10JS18 BACKSHELL	81205	1	32-64-11 */*/*	YC001-YC007

EQUIPMENT LIST

D280A103

Section D11700

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11732 T	1	BACC10JS18 BACKSHELL	81205	1	32-64-11 * / /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11734	1	BACC63CM0803SN PLUG-CONDUCTIVE	81205	1	32-35-11 680/197/L049	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11734 T	1	BACC10KB08 BACKSHELL	81205	1	32-35-11 / /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11736	1	BACC63CE22-2S PLUG-	81205	1	24-32-11 P92 388/ /	ALL
D11738	1	BACC45FT24-43P7 PLUG	81205	1	24-32-11 388/388/L42	YC001-YC007
D11738	1	BACC45FT24-43P7 PLUG	81205	1	24-32-11 P92 388/175/R42	YC008-YC030
D11738	1	BACC45FT24-43P7 PLUG	81205	1	24-32-11 P92 388/ /	YK901-YM670
D11740	1	BACC63CE22-2P PLUG-	81205	1	29-22-11 388/176/R039	ALL
D11756	1	BACS16W1A CONNECTOR	81205	1	24-23-51 P006-00/ /	ALL
D11758	1	AMC02PA03W PLUG-	05574	1	33-36-11 438/203/L011	YC001-YL430
D11758	1	AMC02PA03W PLUG-	05574	1	33-36-11 433/203/L010	YM643-YM670
D11760	1	AMC02PA03W PLUG-	05574	1	33-36-11 469/203/L010	YC001-YC007
D11760	1	AMC02PA03W PLUG-	05574	1	33-36-11 469/203/L006	YC008-YM670
D11764	1	AMC02PA03W PLUG-	05574	1	33-36-11 509/203/L010	ALL

EQUIPMENT LIST

D280A103

Section D11700

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11766	1	AMC02PA03W PLUG-	05574	1	33-36-11 500A+13/203/R012	YM643-YM670
D11768	1	AMC02PA03W PLUG-	05574	1	33-36-11 500B+09/203/L010	YM643-YM670
D11770	1	AMC02PA03W PLUG-	05574	1	33-36-12 727A+10/205/R019	ALL
D11772	1	AMC02PA03W PLUG-	05574	1	33-36-12 727B+7/205/L011	ALL
D11774	1	AMC02PA03W PLUG-	05574	1	33-36-12 727D+7/205/R011	ALL
D11776	1	AMC02PA03W PLUG-	05574	1	33-36-12 754/205/L010	ALL
D11778	1	AMC02PA03W PLUG-	05574	1	33-36-12 774/205/R010	ALL
D11782	1	AMC02PA03W PLUG-	05574	1	33-36-12 834/205/L019	ALL
D11784	1	AMC02PA03W PLUG-	05574	1	33-36-12 894/205/R010	ALL
D11786	1	BACC63BP10C5SN PLUG-	81205	1	38-32-12 1038/231/L045	ALL
D11786 T	1	BACC10KD10 BACKSHELL-	81205	1	38-32-12 */*/*	ALL
D11788	1	BACC45FT10-5S PLUG-	81205	1	38-32-13 852/172/L034	ALL
D11788 T	1	MS27559-2 BACKSHELL-	96906	1	38-32-13 */*/*	ALL
D11798	1	MS25182-2 PLUG-APU START POWER UNIT	96906	1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D11700

Page 4 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11800	1	BACC45FT14-7P PLUG-	81205	1	21-27-31 P91 378/ /	ALL
D11802	1	BACC45FT14-7P PLUG-	81205	1	21-27-31 P0092/ /	ALL
D11802 T	1	450EB001C14-347 BACKSHELL-45 DEGREE	81205	1	21-27-31 */**	ALL
D11804	1	BACC63CC16-10SN ENGINE TEST CONNECTOR	81205	1	31-62-25 372/187/R058	YC001-YC030, YK901-YM670
D11804 T	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81025	1	73-24-11 */**	YC001-YC030
D11804 T	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	73-24-11 */**	YK901-YM670
D11810	1	BACC45FT18-14S PLUG	81205	1	33-11-11 P041-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11810 T	1	BACC10JS18 BACKSHELL	81205	1	33-11-11 */**	YC001-YC007
D11810 T	1	BACC10JS18 BACKSHELL	81205	1	33-11-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11812	1	BACC45FT14-7S PLUG	81205	1	33-11-31 P041-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11812 T	1	BACC10JS14 BACKSHELL	81205	1	33-11-31 */**	YC001-YC007
D11812 T	1	BACC10JS14 BACKSHELL	81205	1	33-11-31 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D11800

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11813	1	M24308-2-281F PLUG	96906	1	23-27-39 E004-01/ /	YK901-YM670
D11813 T	1	DE44994 BACKSHELL	71468	1	23-27-39 */**	YK901-YM670
D11813 U	1	D20419 SCREW LOCK	71468	2	23-27-39 */**	YK901-YM670
D11814	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/439/	YC001-YK906
D11814	1	BACC63BP16D10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/439/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11814 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YC001-YK906
D11814 T	1	BACC10KB16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11816	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/330/	YC001-YK906
D11816	1	BACC63BP16D10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/330/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11816 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YC001-YK906
D11816 T	1	BACC10KB16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11818	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/235/	YC001-YK906
D11818	1	BACC63BP16D10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/235/	YK907-YM670

EQUIPMENT LIST

D280A103

Section D11800

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11818 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 / /	YC001-YC028
D11818 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YC029-YK906
D11818 T	1	BACC10KB16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YK907-YM670
D11820	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 721/173/L62	YC001-YC028
D11820	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 721/173/L062	YC029-YC030
D11820	1	BACC63BP16D10SN PLUG-CONDUCTIVE	81205	1	27-53-21 721/173/L062	YC031-YM670
D11820 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 / /	YC001-YC028
D11820 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YC029-YC030
D11820 T	1	BACC10KB16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YC031-YM670
D11822	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 721/173/R63	YC001-YC007
D11822	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 721/173/R063	YC008-YC030
D11822	1	BACC63BP16D10SN PLUG-CONDUCTIVE	81205	1	27-53-21 721/173/R063	YC031-YM670
D11822 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 / /	YC001-YC028
D11822 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YC029-YC030
D11822 T	1	BACC10KB16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */**	YC031-YM670
D11824	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/244/	YC001-YK906
D11824	1	BACC63BP16D10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/244/	YK907-YM670

EQUIPMENT LIST

D280A103

Section D11800

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11824 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 / /	YC001-YC028
D11824 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/	YC029-YK906
D11824 T	1	BACC10KB16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/	YK907-YM670
D11826	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/330/	YC001-YK906
D11826	1	BACC63BP16D10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/330/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11826 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/	YC001-YK906
D11826 T	1	BACC10KB16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11828	1	BACC63BP16C10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/432/	YC001-YK906
D11828	1	BACC63BP16D10SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/432/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11828 T	1	BACC10KE16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/	YC001-YK906
D11828 T	1	BACC10KB16 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11830	1	BACC45FT10-20S PLUG-	81205	1	21-61-13 500F+7/298/L012	YC001-YL430
D11832	1	BACC63CE12S-3S PLUG-	81205	1	21-61-51 500F+9/300/L012	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11800

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11834	1	BACC45FT10-5S PLUG-	81205	1	21-61-13 500+10/298/L014	YC001-YC011
D11834	1	BACC45FT10-5S PLUG-	81205	1	21-61-13 500F+10/298/L014	YC012-YL430
D11836	1	BACC45FT10-5S PLUG-	81205	1	21-61-14 536/298/R12	YC001-YL430
D11838	1	BACC63CE12S-3S PLUG-	81205	1	21-61-51 535/299/R012	YC001-YL430
D11839	9	10-60450-5 SOCKET-AUTO STOW RETRACT RELAY	81205	1	27-62-41 P006-00/ /	YC001-YC010, YC012-YC030
D11839	1	10-60450-5 SOCKET-AUTO STOW RETRACT RELAY	81205	1	27-62-41 P006-00/ /	YM643-YM670
D11840	1	BACC45FT10-20S PLUG-	81205	1	21-61-14 537/299/R012	YC001-YL430
D11841	9	BACC45FT14-7S PLUG	CUST	1	27-62-41 201/210/R002	YC001-YC010, YC012-YC030
D11841	1	BACC45FT14-7S PLUG-	81205	1	27-62-41 201/210/L002	YM643-YM670
D11842	1	BACC45FT14-7S PLUG	81205	1	33-11-21 P042-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D11842 T	1	BACC10JS14 BACKSHELL	81205	1	33-11-21 */ /	YC001-YC030
D11842 T	1	BACC10JS14 BACKSHELL	81205	1	33-11-21 */*/	YK901-YL429, YM643-YM652
D11844	1	BACC45FT14-7S6 PLUG	81205	1	33-11-32 P042-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D11844 T	1	BACC10JS14 BACKSHELL	81205	1	33-11-32 */ /	YC001-YC030
D11844 T	1	BACC10JS14 BACKSHELL	81205	1	33-11-32 */*/	YK901-YL429, YM643-YM652
D11866	1	BACS16AG1 SOCKET-	81205	1	21-25-11 J00024/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D11800

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11866	1	BACS16AF1 SOCKET-	81205	1	21-25-11 J00024/ /	YK901-YL430
D11866	1	BACS16AF1 SOCKET-	81205	1	21-25-11 J024-00/ /	YM643-YM670
D11868	1	BACS16W5A RELAY SOCKET	81205	1	21-27-31 J020-0B/ /	ALL
D11874	1	BACS16W1A SOCKET-	81205	1	21-43-21 J00024/ /	ALL
D11876	1	BACS16W5A SOCKET-	81205	1	21-43-21 J00024/ /	ALL
D11878	1	BACS16X1A SOCKET-	81205	1	21-43-21 J00024/ /	ALL
D11880	1	BACC45FT12-12S PLUG-	81205	1	21-43-21 368/154/R005	ALL
D11880 T	1	450EB001C12-347 BACKSHELL-45 DEGREE	06324	1	21-43-21 / /	YC001-YC030, YK901-YK905
D11880 T	1	450EB001C12-347 BACKSHELL-45 DEGREE	06324	1	21-43-21 */*/*	YC031-YC050, YK906-YM670
D11882	1	S280W557-801 PLUG-	81205	1	33-22-31 425/289/R031	YC001-YC026
D11882	1	BACC65AL801S PLUG-	81205	1	33-22-31 425/289/R031	YC028-YC030, YK901-YM670
D11884	1	S280W557-801 PLUG-	81205	1	33-22-31 483/289/R032	YC001-YC026
D11884	1	BACC65AL801S PLUG-	81205	1	33-22-31 483/289/R032	YC028-YC030, YK901-YM670
D11886	1	BACC65AL801S PLUG-	81205	1	33-22-31 500C+3/289/R032	YM643-YM670
D11888	1	BACC65AL801S PLUG-	81205	1	33-22-31 563/289/R032	YM643-YM670
D11890	1	BACC65AL801S PLUG-	81205	1	33-22-32 643/288/R032	YM643-YM670
D11892	1	BACC65AL801S PLUG-	81205	1	33-22-32 723/289/R032	YM643-YM670

EQUIPMENT LIST

D280A103

Section D11800

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11894	1	BACC65AL801S PLUG-	81205	1	33-22-32 727C+16/289/R032	YM643-YM670
D11896	1	BACC65AL801S PLUG-	81205	1	33-22-32 785/289/R032	YM643-YM670
D11898	1	S280W557-801 PLUG-	81205	1	33-22-32 844/288/R031	YC001-YC026
D11898	1	BACC65AL801S PLUG-	81205	1	33-22-32 844/288/R031	YC028-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D11800
Page 7 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11900	1	S280W557-801 PLUG-	81205	1	33-22-21 436/289/L032	YC001-YC026
D11900	1	BACC65AL801S PLUG-	81205	1	33-22-21 436/289/L032	YC028-YC030, YK901-YM670
D11902	1	BACC65AL801S PLUG-	81205	1	33-22-21 500+17/289/L033	YM643-YM670
D11904	1	BACC65AL801S PLUG-	81205	1	33-22-21 500D+17/289/L032	YM643-YM670
D11906	1	BACC65AL801S PLUG-	81205	1	33-22-21 602/289/L032	YM643-YM670
D11908	1	BACC65AL801S PLUG-	81205	1	33-22-21 681/289/L032	YM643-YM670
D11910	1	BACC65AL801S PLUG-	81205	1	33-22-22 727A+14/289/L033	YM643-YM670
D11912	1	BACC65AL801S PLUG-	81205	1	33-22-22 727E+10/289/L032	YM643-YM670
D11914	1	S280W557-801 PLUG-	81205	1	33-22-22 794/289/L032	YC001-YC026
D11914	1	BACC65AL801S PLUG-	81205	1	33-22-22 794/289/L032	YC028-YC030, YK901-YL430
D11914	1	BACC65AL801S PLUG-	81205	1	33-22-22 800/289/L032	YM643-YM670
D11916	1	S280W557-801 PLUG-	81205	1	33-22-22 855/289/L031	YC001-YC026
D11916	1	BACC65AL801S PLUG-	81205	1	33-22-22 855/289/L031	YC028-YC030, YK901-YL430
D11916	1	BACC65AL801S PLUG-	81205	1	33-22-22 859/289/L031	YM643-YM670
D11920	1	BACC63CC8-2SN RCPT-CONDUCTIVE	81205	1	30-71-11 526/150/R027	ALL
D11920 T	1	BACC10KD8 BACKSHELL-STRAIGHT	81205	1	30-71-11 */*/*	ALL
D11922	1	48-7191-1 RCPT- AFCS FLOODLIGHT	02660	1	33-14-11 P007-00/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D11900

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11924	1	48-7190 PLUG- AFCS FLOODLIGHT	02660	1	33-14-11 P007-00/ /	YC001-YC030, YK901-YM670
D11926	1	48-7191-1 RCPT- CENTER PANEL FLOODLIGHT	02660	1	33-14-11 P007-00/ /	YC001-YC030, YK901-YM670
D11928	1	48-7190 PLUG- CENTER PANEL FLOODLIGHT	02660	1	33-14-11 P007-00/ /	YC001-YC030, YK901-YM670
D11930	1	BACC45FT16-24S PLUG-	81205	1	33-14-11 P009 196/222/L006	ALL
D11930 T	1	450EB001C16-347 BACKSHELL-(45 DEGREE)	81205	1	33-14-11 */**	ALL
D11932	1	BACC45FT16-24S PLUG-	81205	1	33-14-11 P009 196/ /	ALL
D11932 T	1	BACC10JC16 BACKSHELL-	81205	1	33-14-11 */**	ALL
D11936	1	48-7191-1 RCPT- MOUNTED FLOODLIGHT	02660	1	33-14-11 P007-00/ /	YC001-YC030, YK901-YM670
D11938	1	48-7190 PLUG- MOUNTED FLOODLIGHT	02660	1	33-14-11 P007-00/ /	YC001-YC030, YK901-YM670
D11939		BACS16X1A RCPT-RPL CONTROL SYS A HYD	81205	1	27-25-11 P006-00/ /	YC001-YC029
D11939	1	BACS16X1A RCPT-RPL CONTROL SYS A HYD	81205	1	27-25-11 P006-00/ /	YC030-YM670
D11940	1	48-7191-1 RCPT- MOUNT FLOODLIGHT	02660	1	33-14-11 P007-00/ /	YC001-YC030, YK901-YM670
D11941		BACS16X1A RCPT-RPL CONTROL SYS B HYD	81205	1	27-25-11 P006-00/ /	YC001-YC029
D11941	1	BACS16X1A RCPT-RPL CONTROL SYS B HYD	81205	1	27-25-11 P006-00/ /	YC030-YM670
D11942	1	48-7190 PLUG- MOUNT FLOODLIGHT	02660	1	33-14-11 P007-00/ /	YC001-YC030, YK901-YM670
D11952	1	S280W557-801 PLUG-	81205	1	33-22-31 500B/289/R032	YC001-YC026
D11952	1	BACC65AL801S PLUG-	81205	1	33-22-31 500B/289/R032	YC028-YC030, YK901-YL430

EQUIPMENT LIST

D280A103

Section D11900

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11954	1	S280W557-801 PLUG-	81205	1	33-22-31 500E+13/289/R032	YC001-YC026
D11954	1	BACC65AL801S PLUG-	81205	1	33-22-31 500E+13/289/R032	YC028-YC030, YK901-YL430
D11956	1	S280W557-801 PLUG-	81205	1	33-22-31 500I+5/289/R032	YC001-YC026
D11956	1	BACC65AL801S PLUG-	81205	1	33-22-31 500I+5/289/R032	YC028-YC030, YK901-YL430
D11958	1	S280W557-801 PLUG-	81205	1	33-22-31 585/289/R032	YC001-YC026
D11958	1	BACC65AL801S PLUG-	81205	1	33-22-31 585/289/R032	YC028-YC030, YK901-YL430
D11960	1	S280W557-801 PLUG-	81205	1	33-22-32 665/288/R032	YC001-YC026
D11960	1	BACC65AL801S PLUG-	81205	1	33-22-32 665/288/R032	YC028-YC030, YK901-YL430
D11962	1	S280W557-801 PLUG-	81205	1	33-22-31 727+18/289/R032	YC001-YC026
D11962	1	BACC65AL801S PLUG-	81205	1	33-22-31 727+18/289/R032	YC028-YC030, YK901-YL430
D11964	1	S280W557-801 PLUG-	81205	1	33-22-31 727D+16/289/R032	YC001-YC026
D11964	1	BACC65AL801S PLUG-	81205	1	33-22-31 727D+16/289/R032	YC028-YC030, YK901-YL430
D11966	1	S280W557-801 PLUG-	81205	1	33-22-32 727H+8/289/R032	YC001-YC026
D11966	1	BACC65AL801S PLUG-	81205	1	33-22-32 727H+8/289/R032	YC028-YC030, YK901-YL430
D11968	1	S280W557-801 PLUG-	81205	1	33-22-32 775/289/R032	YC001-YC026
D11968	1	BACC65AL801S PLUG-	81205	1	33-22-32 775/289/R032	YC028-YC030, YK901-YL430
D11970	1	S280W557-801 PLUG-	81205	1	33-22-21 495/289/L032	YC001-YC026

EQUIPMENT LIST

D280A103

Section D11900

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11970	1	BACC65AL801S PLUG-	81205	1	33-22-21 495/289/L032	YC028-YC030, YK901-YL430
D11972	1	S280W557-801 PLUG-	81205	1	33-22-21 500C+11/289/L032	YC001-YC026
D11972	1	BACC65AL801S PLUG-	81205	1	33-22-21 500C+11/289/L032	YC028-YC030, YK901-YL430
D11974	1	S280W557-801 PLUG-	81205	1	33-22-21 500G+3/289/L032	YC001-YC026
D11974	1	BACC65AL801S PLUG-	81205	1	33-22-21 500G+3/289/L032	YC028-YC030, YK901-YL430
D11976	1	S280W557-801 PLUG-	81205	1	33-22-21 539/289/L032	YC001-YC026
D11976	1	BACC65AL801S PLUG-	81205	1	33-22-21 539/289/L032	YC028-YC030, YK901-YL430
D11978	1	S280W557-801 PLUG-	81205	1	33-22-21 618/289/L032	YC001-YC026
D11978	1	BACC65AL801S PLUG-	81205	1	33-22-21 618/289/L032	YC028-YC030, YK901-YL430
D11980	1	S280W557-801 PLUG-	81205	1	33-22-21 698/289/L032	YC001-YC026
D11980	1	BACC65AL801S PLUG-	81205	1	33-22-21 698/289/L032	YC028-YC030, YK901-YL430
D11982	1	S280W557-801 PLUG-	81205	1	33-22-22 727B+11/289/L032	YC001-YC026
D11982	1	BACC65AL801S PLUG-	81205	1	33-22-22 727B+11/289/L032	YC028-YC030
D11982	1	BACC65AL801S PLUG-	81205	1	33-22-22 727B+12/289/L032	YK901-YL430
D11984	1	S280W557-801 PLUG-	81205	1	33-22-22 727F+4/289/L032	YC001-YC026
D11984	1	BACC65AL801S PLUG-	81205	1	33-22-22 727F+4/289/L032	YC028-YC030, YK901-YL430
D11986	1	S280W557-801 PLUG-	81205	1	33-22-22 727I+18/289/L032	YC001-YC026

EQUIPMENT LIST

D280A103

Section D11900

Page 4

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11986	1	BACC65AL801S PLUG-	81205	1	33-22-22 727I+18/289/L032	YC028-YC030, YK901-YL430
D11988	1	BACC45FT14-7S PLUG-LEFT WINDSHIELD WIPER SWITCH	81205	1	30-42-11 P005-04/ /	ALL
D11990	1	BACC45FT20-16S PLUG	81205	1	32-64-11 P002-03/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11990 T	1	BACC10JS20 BACKSHELL	81205	1	32-64-11 */ */ *	YC001-YC007
D11990 T	1	BACC10JS20 BACKSHELL	81205	1	32-64-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D11994	1	AMC02PA03W PLUG-	05574	1	33-36-11 500F+15/203/R010	YC001-YC007
D11994	1	AMC02PA03W PLUG-	05574	1	33-36-11 500F+5/203/R012	YC008-YL430
D11995	1	BACC63BP12A3SN PLUG	81205	1	31-31-14 725/170/L016	YC031-YK910, YL421-YL423, YM643
D11995	1	BACC63BP12A3SN PLUG- CONDUCTIVE	81205	1	31-31-14 725/170/L016	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM670
D11995 T	1	BACC10KF12 BACKSHELL-	81205	1	31-31-14 */ */ *	YC031-YK906
D11995 T	1	620AB049C12 BACKSHELL-	81205	1	31-31-14 */ */ *	YK907, YK910- YK912, YK918- YK919, YL401- YL421, YL423- YL429, YM645- YM670

EQUIPMENT LIST

D280A103

Section D11900

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11995 T	1	620AB049C12 BACKSHELL-	81205	1	31-31-14 / /	YK908-YK909, YL422, YM643
D11996	1	AMC02PA03W PLUG-	05574	1	33-36-11 500G+15/205/L010	YC001-YC007
D11996	1	AMC02PA03W PLUG-	05574	1	33-36-11 500G+9/203/L010	YC008-YL430
D11997	1	BACS16AG1 RELAY SOCKET	81205	1	23-32-12 J004-00/ /	YK901-YM670
D11998	1	AMC02PA03W PLUG-	05574	1	33-36-12 727F+7/205/L010	YC001-YL430

EQUIPMENT LIST

D280A103

Section D11900
Page 6 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12000	1	AMC02PA03W PLUG-	05574	1	33-36-12 727H+7/205/R010	YC001-YC007
D12000	1	AMC02PA03W PLUG-	05574	1	33-36-12 727H+13/205/R009	YC008-YL430
D12002	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 500C+6/212/R067	YC001-YL430
D12002 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-11 */**	YC001-YL430
D12004	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 727C+14/212/R067	YC001-YL430
D12004 T	1	BACC10JS16 CLAMP, STRAIGHT	81205	1	33-51-11 */**	YC001-YL430
D12006	1	BACC63CB12-12SN PLUG-	81205	1	28-21-21 P006-00/ /	ALL
D12006 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	28-21-21 TBD/ /	YC001-YC013
D12006 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	28-21-21 */**	YC015-YL430
D12006 T	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	28-21-21 P006-00/ /	YM643-YM670
D12007	1	BACC45FT12-12S PLUG	81205	1	23-32-31 382/273/L049	YK901-YL430
D12007	1	BACC45FT12-12S PLUG	81205	1	23-32-31 375/270/L040	YM643-YM670
D12008	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 565/213/L068	YC001-YC030, YK901-YL430
D12008 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-11 */**	YC001-YC030, YK901-YL430
D12009	1	755-78-9 PLUG	91836	1	23-32-31 382/273/L049	YK901-YL430
D12009	1	755-78-9 PLUG	91836	1	23-32-31 375/270/L040	YM643-YM670
D12010	1	BACC45FT16-24S PLUG-	81205	1	33-51-13 565/213/R068	YC001-YL430

EQUIPMENT LIST

D280A103

Section D12000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12010 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-13 */*/	YC001-YL430
D12011	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 375/273/L049	YK901-YL430
D12011	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 375/270/L042	YM643-YM670
D12011 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/	YK901-YM670
D12012	1	AMC02PA03W PLUG-	05574	1	33-51-14 727J+15/289/R035	YC001-YL430
D12013	1	BACC45FT12-12S PLUG	81205	1	23-32-31 382/273/R050	YK901-YL430
D12013	1	BACC45FT12-12S PLUG	81205	1	23-32-31 375/270/R040	YM643-YM670
D12014	1	AMC02PA03W PLUG-	05574	1	33-51-14 873/289/R034	YC001-YC050
D12015	1	755-78-9 PLUG	91836	1	23-32-31 382/273/R050	YK901-YL430
D12015	1	755-78-9 PLUG	91836	1	23-32-31 375/270/R040	YM643-YM670
D12016	1	AMC02PA03W PLUG-	05574	1	33-51-14 888/289/L035	YC001-YC030
D12017	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 375/273/R050	YK901-YL430
D12017	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 375/270/R042	YM643-YM670
D12017 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/	YK901-YM670
D12018	1	AMC02PA03W PLUG-	05574	1	33-51-14 653/229/R071	YC001-YL430
D12019	1	BACC45FT12-12S PLUG	81205	1	23-32-32 445/270/L035	YK901-YM670
D12020	1	AMC02PA03W PLUG-	05574	1	33-51-14 634/289/R035	YC001-YL430

EQUIPMENT LIST

D280A103

Section D12000

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12021	1	755-78-9 PLUG	91836	1	23-32-32 445/270/L035	YK901-YM670
D12022	1	AMC02PA03W PLUG-	05574	1	33-51-14 727C+7/289/R035	YC001-YL430
D12023	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 443/270/L042	YK901-YM670
D12023 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/	YK901-YM670
D12024	1	AMC02PA03W PLUG-	05574	1	33-51-14 727F+21/289/R035	YC001-YL430
D12025	1	BACC45FT12-12S PLUG	81205	1	23-32-32 445/270/R035	YK901-YM670
D12026	1	AMC02PA03W PLUG-	05574	1	33-51-14 714/289/R035	YC001-YL430
D12027	1	755-78-9 PLUG	91836	1	23-32-32 445/270/R035	YK901-YM670
D12028	1	AMC02PA03B PLUG-	05574	1	33-51-13 612/296/L010	YC001-YC030, YK901-YK910, YK918, YL421- YL426
D12029	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 443/270/R042	YK901-YM670
D12029 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/	YK901-YM670
D12030	1	AMC02PA03B PLUG-	05574	1	33-51-13 628/293/L019	YM643-YM652
D12031	1	BACC45FT12-12S PLUG	81205	1	23-32-33 500/270/L035	YK901-YM670
D12032	1	AMC02PA03W PLUG-	05574	1	33-51-13 608/227/L074	YC001-YC030
D12032	1	AMC02PA03W PLUG-	05574	1	33-51-12 608/227/L074	YK901-YL430
D12033	1	755-78-9 PLUG	91836	1	23-32-33 500/270/L035	YK901-YM670

EQUIPMENT LIST

D280A103

Section D12000

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12034	1	AMC02PA03W PLUG-	05574	1	33-51-13 569/289/L035	YC001-YC030, YK901-YL430
D12035	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 500/270/L042	YK901-YM670
D12035 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */**	YK901-YM670
D12036	1	AMC02PA03W PLUG-	05574	1	33-51-13 653/227/L074	YC001-YC030, YK901-YL430
D12037	1	BACC45FT12-12S PLUG	81205	1	23-32-33 500/270/R040	YK901-YM670
D12038	1	AMC02PA03W PLUG-	05574	1	33-51-13 649/289/L035	YC001-YC030, YK901-YL430
D12039	1	755-78-9 PLUG	91836	1	23-32-33 500/270/R040	YK901-YM670
D12041	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 500/270/R042	YK901-YM670
D12041 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */**	YK901-YM670
D12043	1	BACC45FT12-12S PLUG	81205	1	23-32-34 500A+10/270/L035	YK901-YL430
D12044	1	AMC02PA03W PLUG-	05574	1	33-51-12 500G+18/289/R035	YC001-YL430
D12045	1	755-78-9 PLUG	91836	1	23-32-34 500A+10/270/L035	YK901-YL430
D12046	1	AMC02PA03W PLUG-	05574	1	33-51-12 500H+11/289/L035	YC001-YC030, YK901-YL430
D12047	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 500A+8/270/L042	YK901-YL430
D12047 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */**	YK901-YL430
D12048	1	AMC02PA03W PLUG-	05574	1	33-51-12 500A+5/289/L035	YC001-YC030, YK901-YL430
D12049	1	BACC45FT12-12S PLUG	81205	1	23-32-34 500A+10/270/R040	YK901-YL430

EQUIPMENT LIST

D280A103

Section D12000

Page 4

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12050	1	AMC02PA03W PLUG-	05574	1	33-51-12 608/227/R074	YC001-YL430
D12051	1	755-78-9 PLUG	91836	1	23-32-34 500A+10/270/R040	YK901-YL430
D12052	1	BACC45FN10-5S RCPT-	81205	1	33-51-21 430/208/L068	YK901-YM652
D12053	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 500A+8/270/R042	YK901-YL430
D12053 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YK901-YL430
D12055	1	BACC45FT12-12S PLUG	81205	1	23-32-41 500C+15/270/L040	YK901-YL430
D12055	1	BACC45FT12-12S PLUG	81205	1	23-32-41 500C/270/L040	YM643-YM670
D12057	1	755-78-9 PLUG - COAX	91836	1	23-32-41 500C+15/270/L040	YK901-YL430
D12057	1	755-78-9 PLUG - COAX	91836	1	23-32-41 500C/270/L040	YM643-YM670
D12059	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 500C+14/270/L042	YK901-YL430
D12059	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 500C/270/L042	YM643-YM670
D12059 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YK901-YM670
D12060	1	AMC02PA03W PLUG-	05574	1	33-51-12 500D+5/274/R030	YC001-YC050
D12060	1	AMC02PA03W PLUG-	05574	1	33-51-12 500D+4/291/R036	YK901-YL430
D12061	1	BACC45FT12-12S PLUG	81205	1	23-32-41 500C+15/270/R040	YK901-YL430
D12061	1	BACC45FT12-12S PLUG	81205	1	23-32-41 500C/270/R040	YM643-YM670
D12062	1	AMC02PA03W PLUG-	05574	1	33-51-12 500D+19/289/L035	YC001-YC030, YK901-YL430

EQUIPMENT LIST

D280A103

Section D12000

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12063	1	755-78-9 PLUG - COAX	91836	1	23-32-41 500C+15/270/R040	YK901-YL430
D12063	1	755-78-9 PLUG - COAX	91836	1	23-32-41 500C/270/R040	YM643-YM670
D12064	1	48-7191 RCPT-	02660	1	33-51-21 573/225/R070	YC001-YL430
D12065	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 500C+14/270/R042	YK901-YL430
D12065	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 500C/270/R042	YM643-YM670
D12065 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YK901-YM670
D12066	1	48-7190 PLUG-	02660	1	33-51-21 573/226/R070	YC001-YL430
D12067	1	BACC45FT12-12S PLUG	81205	1	23-32-42 500G+5/270/L040	YK901-YL430
D12067	1	BACC45FT12-12S PLUG	81205	1	23-32-42 563/270/L040	YM643-YM670
D12068	1	48-7191 RCPT-	02660	1	33-51-21 576/234/L062	YC001-YC030, YK901-YL430
D12069	1	755-78-9 PLUG - COAX	91836	1	23-32-42 500G+5/270/L040	YK901-YL430
D12069	1	755-78-9 PLUG - COAX	91836	1	23-32-42 563/270/L040	YM643-YM670
D12071	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 500G+6/270/L042	YK901-YL430
D12071	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 563/270/L042	YM643-YM670
D12071 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YK901-YM670
D12072	1	48-7190 PLUG-	02660	1	33-51-21 576/234/L062	YC001-YC030, YK901-YL430
D12073	1	BACC45FT12-12S PLUG	81205	1	23-32-42 500G+5/270/R040	YK901-YL430

EQUIPMENT LIST

D280A103

Section D12000

Page 6

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12073	1	BACC45FT12-12S PLUG	81205	1	23-32-42 563/270/R040	YM643-YM670
D12075	1	755-78-9 PLUG - COAX	91836	1	23-32-42 500G+5/270/R040	YK901-YL430
D12075	1	755-78-9 PLUG - COAX	91836	1	23-32-42 563/270/R040	YM643-YM670
D12077	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 500G+6/270/R042	YK901-YL430
D12077	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 563/270/R042	YM643-YM670
D12077 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YK901-YM670
D12079	1	BACC45FT12-12S PLUG	81205	1	23-32-43 555/270/L035	YK901-YL430
D12081	1	755-78-9 PLUG	91836	1	23-32-43 555/270/L035	YK901-YL430
D12083	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 557/270/L042	YK901-YL430
D12083 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YK901-YL430
D12085	1	BACC45FT12-12S PLUG	81205	1	23-32-43 555/270/R040	YK901-YL430
D12087	1	755-78-9 PLUG	91836	1	23-32-43 555/270/R040	YK901-YL430
D12089	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 557/270/R042	YK901-YL430
D12089 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YK901-YL430
D12091	1	BACC45FT12-12S PLUG	81205	1	23-32-51 670/270/L040	YK901-YM670
D12093	1	755-78-9 PLUG	91836	1	23-32-51 670/270/L040	YK901-YM670
D12095	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 670/270/L042	YK901-YM670

EQUIPMENT LIST

D280A103

Section D12000

Page 7

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12095 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YK901-YM670
D12097	1	BACC45FT12-12S PLUG	81205	1	23-32-51 670/270/R040	YK901-YM670
D12099	1	755-78-9 PLUG	91836	1	23-32-51 670/270/R040	YK901-YM670

EQUIPMENT LIST

D280A103

Section D12000
Page 8 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12100		7210B RCPT-OXYGEN CONCENTRATOR OUTLET	65C27437 74545	1	25-29-11 380/225/L068	YC001-YC050
D12101	1	BACC45FT8-3S PLUG	81205	1	33-25-61 670/270/R042	YK901-YM670
D12101 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/	YK901-YM670
D12103	1	BACC45FT12-12S PLUG	81205	1	23-32-52 727+19/273/L054	YK901-YL430
D12103	1	BACC45FT12-12S PLUG	81205	1	23-32-52 727A+15/270/L040	YM643-YM670
D12105	1	755-78-9 PLUG	91836	1	23-32-52 727+19/273/L054	YK901-YL430
D12105	1	755-78-9 PLUG	91836	1	23-32-52 727A+15/270/L040	YM643-YM670
D12106	1	48-7191-1 RCPT-	02660	1	33-14-11 P021-01/ /	ALL
D12107	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 727+18/270/L042	YK901-YL430
D12107	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 727A+15/270/L042	YM643-YM670
D12107 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/	YK901-YM670
D12108	1	48-7190 PLUG-	02660	1	33-14-11 214/230/L36	YC001-YC026
D12108	1	48-7190 PLUG-	02660	1	33-14-11 P021-01/ /	YC028-YM670
D12109	1	BACC45FT12-12S PLUG	81205	1	23-32-52 727+19/273/R055	YK901-YL430
D12109	1	BACC45FT12-12S PLUG	81205	1	23-32-52 727A+15/270/R040	YM643-YM670
D12110	1	48-7191-1 RCPT-	02660	1	33-14-11 P023-01/ /	ALL
D12111	1	755-78-9 PLUG	91836	1	23-32-52 727+19/273/R055	YK901-YL430

EQUIPMENT LIST

D280A103

Section D12100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12111	1	755-78-9 PLUG	91836	1	23-32-52 727A+15/270/R040	YM643-YM670
D12112	1	48-7190 PLUG-	02660	1	33-14-11 P023-01/ /	ALL
D12113	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 727+18/270/R042	YK901-YL430
D12113	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 727A+15/270/R042	YM643-YM670
D12113 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */**	YK901-YM670
D12115	1	BACC45FT12-12S PLUG	81205	1	23-32-53 727C+19/273/L054	YK901-YL430
D12117	1	755-78-9 PLUG	91836	1	23-32-53 727C+19/273/L054	YK901-YL430
D12119	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 727C+18/270/L042	YK901-YL430
D12119 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */**	YK901-YL430
D12121	1	BACC45FT12-12S PLUG	81205	1	23-32-53 727C+19/273/R055	YK901-YL430
D12123	1	755-78-9 PLUG	91836	1	23-32-53 727C+19/273/R055	YK901-YL430
D12125	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 727C+18/270/R042	YK901-YL430
D12125 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */**	YK901-YL430
D12127	1	BACC45FT12-12S PLUG	81205	1	23-32-61 727G+5/270/L040	YK901-YL430
D12127	1	BACC45FT12-12S PLUG	81205	1	23-32-61 727E+17/270/L040	YM643-YM670
D12129	1	755-78-9 PLUG	91836	1	23-32-61 727G+5/270/L040	YK901-YL430
D12129	1	755-78-9 PLUG	91836	1	23-32-61 727E+17/270/L040	YM643-YM670

EQUIPMENT LIST

D280A103

Section D12100

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12131	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 727G+4/270/L042	YK901-YL430
D12131	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 727E+17/270/L042	YM643-YM670
D12131 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YK901-YM670
D12133	1	BACC45FT12-12S PLUG	81205	1	23-32-61 727G+5/270/R040	YK901-YL430
D12133	1	BACC45FT12-12S PLUG	81205	1	23-32-61 727E+17/270/R040	YM643-YM670
D12135	1	755-78-9 PLUG	91836	1	23-32-61 727G+5/270/R040	YK901-YL430
D12135	1	755-78-9 PLUG	91836	1	23-32-61 727E+17/270/R040	YM643-YM670
D12137	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 727G+4/270/R042	YK901-YL430
D12137	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 727E+17/270/R042	YM643-YM670
D12137 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YK901-YM670
D12139	1	BACC45FT12-12S PLUG	81205	1	23-32-61 755/270/L040	YK901-YL430
D12139	1	BACC45FT12-12S PLUG	81205	1	23-32-61 830/270/L040	YM643-YM670
D12141	1	755-78-9 PLUG	91836	1	23-32-61 755/270/L040	YK901-YL430
D12141	1	755-78-9 PLUG	91836	1	23-32-61 830/270/L040	YM643-YM670
D12143	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 755/270/L042	YK901-YL430
D12143	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 830/270/L042	YM643-YM670
D12143 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D12100

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12145	1	BACC45FT12-12S PLUG	81205	1	23-32-62 755/270/R040	YK901-YL430
D12145	1	BACC45FT12-12S PLUG	81205	1	23-32-62 830/270/R040	YM643-YM670
D12147	1	755-78-9 PLUG	91836	1	23-32-62 755/270/R040	YK901-YL430
D12147	1	755-78-9 PLUG	91836	1	23-32-62 830/270/R040	YM643-YM670
D12149	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 755/270/R042	YK901-YL430
D12149	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 830/270/R042	YM643-YM670
D12149 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YK901-YM670
D12151	1	BACC45FT12-12S PLUG	81205	1	23-32-63 830/270/L040	YK901-YL430
D12153	1	755-78-9 PLUG	91836	1	23-32-63 830/270/L040	YK901-YL430
D12155	1	BACC45FT8-3S PLUG-	81205	1	33-25-51 830/270/L042	YK901-YL430
D12155 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-51 */*/*	YK901-YL430
D12156	1	BACC45FT12-12S PLUG-CAPTAIN COLUMN SWITCHING MODULE	81205	1	27-41-11 228/202/L011	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12156 T	1	BACC10JS12 BACKSHELL-	81205	1	27-41-11 / /	YC001-YC007
D12156 T	1	BACC10JS12 BACKSHELL-	81205	1	27-41-11 */*/*	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12157	1	BACC45FT12-12S PLUG	81205	1	23-32-63 830/270/R040	YK901-YL430

EQUIPMENT LIST

D280A103

Section D12100

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12159	1	755-78-9 PLUG	91836	1	23-32-63 830/270/R040	YK901-YL430
D12161	1	BACC45FT8-3S PLUG-	81205	1	33-25-61 830/270/R042	YK901-YL430
D12161 T	1	BACC10JS8 BACKSHELL-	81205	1	33-25-61 */*/*	YK901-YL430
D12163J	1	BACI10AL34AS INSERT	81205	1	23-34-01 AB0410/ /	YK901-YM670
D12163JK	1	BACC10LH2B BACKSHELL - EMI	81205	1	23-34-01 */*/*	YK901-YM670
D12163JT	1	BACC65AP2B01 RCPT	81205	1	23-34-01 */*/*	YK901-YM670
D12163P	1	BACI10AL34AP INSERT	81205	1	23-34-01 410/205/R039	YK901-YM670
D12163PQ	1	BACC10LH2B BACKSHELL - EMI	81205	1	23-34-01 */*/*	YK901-YM670
D12163PT	1	BACC65AN2A01 PLUG	81205	1	23-34-01 */*/*	YK901-YM670
D12164	1	AMC02PA03B PLUG-	05574	1	33-51-13 727A+9/289/L07	YC001-YC030
D12165J	1	BACI10AL34AS INSERT	81205	1	23-34-01 AB0410/ /	YK901-YM670
D12165JK	1	BACC10LH2B BACKSHELL - EMI	81205	1	23-34-01 */*/*	YK901-YM670
D12165JT	1	BACC65AP2B02 RCPT	81205	1	23-34-01 */*/*	YK901-YM670
D12165P	1	BACI10AL34AP INSERT	81205	1	23-34-01 410/205/R039	YK901-YM670
D12165PQ	1	BACC10LH2B BACKSHELL - EMI	81205	1	23-34-01 */*/*	YK901-YM670
D12165PT	1	BACC65AN2A02 PLUG	81205	1	23-34-01 */*/*	YK901-YM670
D12167J	1	BACI10AL34AS INSERT	81205	1	23-34-01 AB0410/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D12100

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12167JK	1	BACC10LH2B BACKSHELL -EMI	81205	1	23-34-01 */*/*	YK901-YM670
D12167JT	1	BACC65AP2B03 RCPT	81205	1	23-34-01 */*/*	YK901-YM670
D12167P	1	BACI10AL34AP INSERT	81205	1	23-34-01 410/205/R039	YK901-YM670
D12167PQ	1	BACC10LH2B BACKSHELL - EMI	81205	1	23-34-01 */*/*	YK901-YM670
D12167PT	1	BACC65AN2A03 PLUG	81205	1	23-34-01 */*/*	YK901-YM670
D12169J	1	BACI10AL34AP INSERT	81205	1	23-34-02 AB0410/ /	YK901-YM670
D12169JK		BACC10LH2B BACKSHELL	81205	1	23-34-02 */*/*	YK901-YM670
D12169JT	1	BACC65AP2B04 RCPT	81205	1	23-34-02 */*/*	YK901-YM670
D12169P	1	BACI10AL34AS INSERT	81205	1	23-34-02 420/204/R039	YK901-YM670
D12169PQ		BACC10LH2B BACKSHELL	81205	1	23-34-02 */*/*	YK901-YM670
D12169PT	1	BACC65AN2B04 PLUG	81205	1	23-34-02 */*/*	YK901-YM670
D12170	1	AMC02PA03W PLUG-	05574	1	33-36-11 500B+14/203/R010	YC001-YC007
D12170	1	AMC02PA03W PLUG-	05574	1	33-36-11 500B+5/203/R012	YC008-YL430
D12171J	1	BACI10AL34AP INSERT	81205	1	23-34-02 AB0410/ /	YK901-YM670
D12171JK		BACC10LH2B BACKSHELL	81205	1	23-34-02 */*/*	YK901-YM670
D12171JT	1	BACC65AP2B05 RCPT	81205	1	23-34-02 */*/*	YK901-YM670
D12172	1	AMC02PA03W PLUG-	05574	1	33-36-11 500D+12/203/L010	YC001-YC007

EQUIPMENT LIST

D280A103

Section D12100

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12172	1	AMC02PA03W PLUG-	05574	1	33-36-11 500D+9/203/L010	YC008-YL430
D12180	1	48-7191-1 RCPT-	02660	1	30-71-11 915/168/L001	ALL
D12182	1	48-7190-1 PLUG-	02660	1	30-71-11 915/168/L001	ALL
D12184	1	48-7191-1 RCPT-	02660	1	30-71-11 958/177/L001	ALL
D12186	1	48-7190-1 PLUG-	02660	1	30-71-11 958/178/L001	ALL
D12188	1	48-7191-1 RCPT-	02660	1	30-71-11 958/204/R023	ALL
D12190	1	48-7190-1 PLUG-	02660	1	30-71-11 958/204/R023	ALL
D12192	1	48-7191-1 RCPT-	02660	1	30-71-11 996/200/R038	ALL
D12194	1	48-7190-1 PLUG-	02660	1	30-71-11 996/200/R038	ALL
D12196	1	48-7191-1 RCPT-	02660	1	30-71-11 1003/203/L040	YC001-YC007, YM643-YM670
D12196	1	48-7191-1 RCPT-	02660	1	30-71-11 1003/203/L40	YC008-YL430
D12198	1	48-7190-1 PLUG-	02660	1	30-71-11 961/203/R024	YC001-YC007
D12198	1	48-7190-1 PLUG-	02660	1	30-71-11 1003/203/L40	YC008-YL430
D12198	1	48-7190-1 PLUG-	02660	1	30-71-11 1003/203/L040	YM643-YM670

EQUIPMENT LIST

D280A103

Section D12100

Page 7 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12200	1	48-7191-1 RCPT-	02660	1	30-71-11 961/203/R024	ALL
D12202	1	48-7190-1 PLUG-	02660	1	30-71-11 961/203/R024	ALL
D12204	1	48-7191-1 RCPT-	02660	1	30-71-11 910/204/R052	ALL
D12206	1	48-7190-1 PLUG-	02660	1	30-71-11 910/204/R052	ALL
D12208	1	48-7191-1 RCPT-	02660	1	30-71-11 909/203/R039	ALL
D12210	1	48-7190-1 PLUG-	02660	1	30-71-11 909/203/R039	ALL
D12211J	1	BAC110AL34AP INSERT	81205	1	23-34-02 408/205/R037	YK901-YM670
D12211JK		BACC10LH2B BACKSHELL	81205	1	23-34-02 408/205/R037	YK901-YM670
D12211JT	1	BACC65AP2B06 RCPT	81205	1	23-34-02 408/205/R037	YK901-YM670
D12212	1	48-7191-1 RCPT-	02660	1	30-71-11 909/204/R050	ALL
D12213J	1	BACC63CC22-55SN RCPT	81205	1	23-32-12 400/294/R024	YK901-YL430
D12213J	1	BACC63CC22-55SN RCPT	81205	1	23-32-12 AB0340B/ /	YM643-YM670
D12213JK		S280W603-214 BACKSHELL - 45 DEG.	81205	1	23-32-12 */*/*	YK901-YM670
D12213P	1	BACC63CB22-55PN PLUG	81205	1	23-34-01 400/294/R024	YK901-YM670
D12213PQ		S280W604-18 BACKSHELL	81205	1	23-34-01 */*/*	YK901-YM670
D12214	1	48-7190-1 PLUG-	02660	1	30-71-11 909/204/R050	ALL
D12216	1	48-7191-1 RCPT-	02660	1	30-71-11 902/201/R054	ALL

EQUIPMENT LIST

D280A103

Section D12200

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12218	1	48-7190-1 PLUG-	02660	1	30-71-11 902/201/R054	ALL
D12220	1	48-7191-1 RCPT-	02660	1	30-71-11 963/201/R026	ALL
D12222	1	48-7190-1 PLUG-	02660	1	30-71-11 963/201/R026	ALL
D12224	1	48-7191-1 RCPT-	02660	1	30-71-11 942/203/L042	ALL
D12225	1	BACS16AF1 SOCKET-	81205	1	21-25-11 J00024/ /	YK901-YM670
D12226	1	48-7190-1 PLUG-	02660	1	30-71-11 942/203/L042	ALL
D12227	1	BACS16AF1 SOCKET-	81205	1	21-25-11 J00024/ /	YK901-YM670
D12228	1	48-7191-1 RCPT-	02660	1	30-71-11 948/202/R045	ALL
D12229	1	BACS16W1A SOCKET-	81205	1	21-27-21 J00024/ /	YK901-YM670
D12230	1	48-7190-1 PLUG-	02660	1	30-71-11 948/202/R045	ALL
D12232	1	48-7191-1 RCPT-	02660	1	30-71-11 897/204/L047	ALL
D12234	1	48-7190-1 PLUG-	02660	1	30-71-11 897/204/L047	ALL
D12237	1	BACC63CB12-12SN PLUG	81205	1	23-70-11 P008/ /	YK907-YM670
D12237 T		BACC10KD12 BACKSHELL	81205	1	23-70-11 */*/*	YK907-YM670
D12239	1	BACC63CB10-5PN PLUG	81205	1	23-70-11 361/292/R008	YK907-YM670
D12239 T		BACC10KE10 BACKSHELL	81205	1	23-70-11 */*/*	YK907-YM670
D12241	1	126-58-9 PLUG	81205	1	31-62-42 355/291/R008	YK907-YM670

EQUIPMENT LIST

D280A103

Section D12200

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12243	1	BACC63CB10-5PN PLUG	81205	1	23-70-11 355/291/R008	YK907-YM670
D12243 T		BACC10KE10 BACKSHELL	81205	1	23-70-11 */*/*	YK907-YM670
D12245	1	126-58-9 PLUG	81205	1	31-62-42 349/290/R008	YK907-YM670
D12246	1	AMC02PA03W PLUG-	05574	1	33-51-12 500+12/289/R035	YC001-YL430
D12247	1	BACC63CB10-5PN PLUG	81205	1	23-70-11 348/292/R008	YK907-YM670
D12247 T		BACC10KE10 BACKSHELL	81205	1	23-70-11 */*/*	YK907-YM670
D12248	1	BACS16AG1 SOCKET-	81205	1	21-27-21 J00024/ /	ALL
D12249	1	126-58-9 PLUG	81205	1	31-62-42 343/291/R008	YK907-YM670
D12250	1	BACS16AG1 RELAY SOCKET	81205	1	21-27-31 J020-0B/ /	ALL

EQUIPMENT LIST

D280A103

Section D12200
Page 3 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12309	1	2J-1869 PUBLIC ADDRESS MIC JACK	82389	1	23-31-01 243/213/L003	YK901-YL430
D12311	1	BKAD1-125-30001 PLUG-	81205	1	23-70-11 E004-01/ /	YK901-YK906
D12311 T	1	S280W601-116 GROUND BLOCK, ARING 600	81205	1	23-70-11 / /	YK901-YK906
D12311A	1	PARTAOFD12311 PLUG		0	23-70-11 E004-01/ /	YK901-YK906
D12311B	1	PARTBOFD12311 PLUG		0	23-70-11 E004-01/ /	YK901-YK906
D12311C	1	PARTCOFD12311 PLUG		0	23-70-11 E004-01/ /	YK901-YK906
D12313	1	MS27484T12F35S PLUG	81205	1	23-70-11 P008/ /	YK901-YK906
D12313 T		620FS012M12 BACKSHELL	81205	1	23-70-11 */ /	YK901-YK906
D12315	1	MS27484T12F8S PLUG	81205	1	23-70-11 P008/ /	YK901-YK906
D12315 T		620FS012M12 BACKSHELL	81205	1	23-70-11 */ /	YK901-YK906
D12346	1	48-7191 RCPT-WTR PRESS PROX SW	02660	1	38-41-13 915/165/R010	ALL
D12348	1	48-7190 PLUG-WTR PRESS PROX SW	02660	1	38-41-13 0915/165/R010	ALL
D12350	1	AMC02PA03R PLUG-	05574	1	33-51-21 360/284/L031	YC001-YC030, YK901-YM652
D12352	1	AMC02RA03R RCPT-	05574	1	33-51-21 360/284/L031	YK912-YK917, YK919-YL430, YM652
D12392	1	48-7191 RCPT-	02660	1	33-51-21 642/237/R070	YM643-YM670
D12394	1	48-7190 PLUG-	02660	1	33-51-21 642/237/R070	YM643-YM670

EQUIPMENT LIST

D280A103

Section D12300

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12396	1	48-7191 RCPT-	02660	1	33-51-21 642/248/L070	YM643-YM652
D12398	1	48-7190 PLUG-	02660	1	33-51-21 642/248/L070	YM643-YM652

EQUIPMENT LIST

D280A103

Section D12300
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12416	1	AMC02PA03B PLUG-	05574	1	33-29-11 299/290/L008	YC001-YC030, YK901-YM670
D12430	1	48-7191 RCPT-	02660	1	33-51-21 642/224/R062	YC001-YC050
D12430	1	48-7191 RCPT-	02660	1	33-51-22 642/224/R062	YK901-YL430
D12432	1	48-7190 PLUG-	02660	1	33-51-21 642/224/R062	YC001-YC050
D12432	1	48-7190 PLUG-	02660	1	33-51-22 642/224/R062	YK901-YL430
D12434	1	48-7191 RCPT-	02660	1	33-51-21 642/224/L062	YC001-YC030
D12434	1	48-7191 RCPT-	02660	1	33-51-22 642/224/L062	YK901-YL430
D12436	1	48-7190 PLUG-	02660	1	33-51-21 642/224/L062	YC001-YC030
D12436	1	48-7190 PLUG-	02660	1	33-51-22 642/224/L062	YK901-YL430
D12442	1	48-7191 RCPT-	02660	1	33-51-13 590/270/L060	YC001-YC030, YK901-YL430
D12444	1	48-7190 PLUG-	02660	1	33-51-13 590/270/L060	YC001-YC030, YK901-YL430
D12446	1	AMC02PA03R PLUG-	05574	1	33-51-13 590/270/L060	YC001-YC030, YK901-YL430
D12448	1	48-7191 RCPT-	02660	1	33-51-13 628/270/L060	YC001-YC030, YK901-YM652
D12450	1	48-7190 PLUG-	02660	1	33-51-13 628/270/L060	YC001-YC030, YK901-YM652
D12452	1	AMC02PA03R PLUG-	05574	1	33-51-13 628/270/L060	YC001-YC030, YK901-YM652
D12454	1	48-7191 RCPT-	02660	1	33-51-13 590/270/R060	YC001-YL430
D12456	1	48-7190 PLUG-	02660	1	33-51-13 590/270/R060	YC001-YL430

EQUIPMENT LIST

D280A103

Section D12400

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12458	1	AMC02PA03R PLUG-	05574	1	33-51-13 590/270/R060	YC001-YL430
D12460	1	48-7191 RCPT-	02660	1	33-51-13 628/270/R060	ALL
D12462	1	48-7190 PLUG-	02660	1	33-51-13 628/270/R060	ALL
D12464	1	AMC02PA03R PLUG-	05574	1	33-51-13 628/270/R060	ALL
D12466	1	BACS16AG1 RELAY SOCKET	81205	1	49-62-11 J020-0B/ /	ALL
D12488	1	AMC02PA03W PLUG-	05574	1	33-51-14 810/289/R035	YC001-YL430
D12491	1	M24308-2-1F PLUG	81205	1	23-70-11 296/290/L001	YK907-YM670
D12491 T	1	DE44994 BACKSHELL	71468	1	23-70-11 */*/*	YK907-YM670
D12491 U	1	D20419 SCREW LOCK	71468	2	23-70-11 */*/*	YK907-YM670
D12493	1	M24308-2-1F PLUG	81205	1	23-70-11 337/292/L01	YK907-YM670
D12493 T	1	DE44994 BACKSHELL	71468	1	23-70-11 */*/*	YK907-YM670
D12493 U	1	D20419 SCREW LOCK	71468	2	23-70-11 */*/*	YK907-YM670
D12495	1	M24308-2-1F PLUG	81205	1	23-70-11 300/288/R021	YK907-YM670
D12495 T	1	DE44994 BACKSHELL	71468	1	23-70-11 */*/8	YK907-YM670
D12495 U	1	D20419 SCREW LOCK	71468	2	23-70-11 */*/*	YK907-YM670

EQUIPMENT LIST

D280A103

Section D12400
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12538	1	BACS16W1A RELAY SOCKET	81205	1	52-71-13 J022-00/ /	ALL
D12540	1	BACS16W1A SOCKET-	81205	1	52-71-14 J00024/ /	ALL
D12544	1	48-7191-1 RCPT-	02660	1	21-42-11 617/251/R066	ALL
D12546	1	48-7190 PLUG-	02660	1	21-42-11 617/251/R066	ALL
D12552	1	48-7191-1 RCPT-	02660	1	21-42-11 617/251/L066	YC001-YC030, YK901-YM652
D12554	1	48-7190 PLUG-	02660	1	21-42-11 617/251/L066	YC001-YC030, YK901-YM652
D12560	1	48-7191-1 RCPT-	02660	1	21-42-11 579/251/R066	YC001-YL430
D12562	1	48-7190 PLUG-	02660	1	21-42-11 579/251/R066	YC001-YL430
D12576	1	48-7191-1 RCPT-	02660	1	21-42-11 579/251/L066	YC001-YC030, YK901-YL430
D12578	1	48-7190 PLUG-	02660	1	21-42-11 579/251/L066	YC001-YC030, YK901-YL430
D12592	1	BACC45FT16-24S PLUG-	81205	1	33-14-11 P009 196/ /	ALL
D12592 T	1	450EB001C16-347 BACKSHELL-(45 DEGREE)	81205	1	33-14-11 */*/*	ALL

EQUIPMENT LIST

D280A103

Section D12500

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12606	1	AMC02PA03R PLUG-	05574	1	35-21-31 322/281/R034	ALL
D12652	1	48-7191-1 RCPT-	02660	1	21-42-11 638/251/R066	ALL
D12654	1	48-7190 PLUG-	02660	1	21-42-11 638/251/R066	ALL
D12656	1	48-7191-1 RCPT-	02660	1	21-42-11 581/229/R069	ALL
D12658	1	48-7190 PLUG-	02660	1	21-42-11 581/229/R069	ALL
D12660	1	48-7191-1 RCPT-	02660	1	21-42-11 640/229/R069	ALL
D12662	1	48-7190 PLUG-	02660	1	21-42-11 640/229/R069	ALL
D12664	1	48-7191-1 RCPT-	02660	1	21-42-11 638/251/L066	YC001-YC030, YK901-YM652
D12666	1	48-7190 PLUG-	02660	1	21-42-11 638/251/L066	YC001-YC030, YK901-YM652
D12668	1	48-7191-1 RCPT-	02660	1	21-42-11 613/229/L069	YC001-YC030, YK901-YM652
D12670	1	48-7190 PLUG-	02660	1	21-42-11 613/229/L069	YC001-YC030, YK901-YM652
D12672	1	48-7191-1 RCPT-	02660	1	21-42-11 639/229/L069	YC001-YC030, YK901-YM652
D12674	1	48-7190 PLUG-	02660	1	21-42-11 639/229/L069	YC001-YC030, YK901-YM652
D12676	1	48-7191-1 RCPT-	02660	1	21-42-11 600/251/R066	YC001-YL430
D12678	1	48-7190 PLUG-	02660	1	21-42-11 600/251/R066	YC001-YL430
D12680	1	48-7191-1 RCPT-	02660	1	21-42-11 570/229/R069	YC001-YL430
D12682	1	48-7190 PLUG-	02660	1	21-42-11 570/229/R069	YC001-YL430

EQUIPMENT LIST

D280A103

Section D12600

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12684	1	48-7191-1 RCPT-	02660	1	21-42-11 560/229/R069	YC001-YL430
D12686	1	48-7190 PLUG-	02660	1	21-42-11 560/229/R069	YC001-YL430

EQUIPMENT LIST

D280A103

Section D12600

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12700	1	48-7191-1 RCPT-	02660	1	21-42-11 600/251/L066	YC001-YC030, YK901-YL430
D12702	1	48-7190 PLUG-	02660	1	21-42-11 600/251/L066	YC001-YC030, YK901-YL430
D12704	1	48-7191-1 RCPT-	02660	1	21-42-11 575/224/L069	YC001-YC030, YK901-YL430
D12706	1	48-7190 PLUG-	02660	1	21-42-11 575/224/L069	YC001-YC030, YK901-YL430
D12708	1	48-7191-1 RCPT-	02660	1	21-42-11 604/222/L070	YC001-YC030, YK901-YL430
D12710	1	48-7190 PLUG-	02660	1	21-421 604/222/L070	YC001-YC030, YK901-YL430
D12756	1	BACS16W1A RELAY SOCKET	81205	1	52-71-13 J022-00/ /	ALL
D12758	1	BACS16W1A SOCKET-	81205	1	52-71-14 J00024/ /	ALL
D12760	1	BACC45FT24-61S CONNECTOR	81205	1	26-16-21 P08-75/ /	ALL
D12760 T	1	BACC10JS24 BACKSHELL	81205	1	26-16-21 / /	ALL
D12762	1	D38999-26WD35SN CONNECTOR	96906	1	26-16-21 450/204/L030	ALL
D12762 T	1	M85049-39S15W BACKSHELL	96906	1	26-16-21 / /	ALL
D12764	1	D38999-26WF35SN CONNECTOR	96906	1	26-16-21 450/204/L028	ALL
D12764 T	1	M85049-39S19W BACKSHELL	96906	1	26-16-21 */*/*	YC001-YL430
D12764 T	1	M85049-39S19W BACKSHELL	96906	1	26-16-21 / /	YM643-YM670
D12766	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-21 470/203/L015	ALL
D12766 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-21 */*/*	YC001-YC030

EQUIPMENT LIST

D280A103

Section D12700

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12766 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-21 */**	YC031-YL430
D12766 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-21 / /	YM643-YM670
D12767	1	125-94-9 PLUG	98136	1	23-32-21 351/177/R039	YK911-YK917, YK919-YL401, YL427-YL430, YM647-YM670
D12768	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-21 500C+10/203/L012	YC001-YL430
D12768	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-21 500A+10/203/L012	YM643-YM670
D12768 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-21 */**	YC001-YC030
D12768 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-21 */**	YC031-YL430
D12768 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-21 / /	YM643-YM670
D12769	1	125-94-9 PLUG	98136	1	23-32-21 351/177/R039	YK911-YK917, YK919-YL401, YL427-YL430, YM647-YM670
D12770	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-21 430/203/R012	ALL
D12770 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-21 */**	YC001-YC030
D12770 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-21 */**	YC031-YL430
D12770 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-21 / /	YM643-YM670
D12772	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-21 500E+10/203/R015	YC001-YL430
D12772	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-21 500+10/203/R015	YM643-YM670

EQUIPMENT LIST

D280A103

Section D12700

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12772 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-21 */**	YC001-YC030
D12772 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-21 */**	YC031-YL430
D12772 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-21 / /	YM643-YM670
D12774	1	D38999-26WD35SN CONNECTOR	96906	1	26-16-22 817/206/L030	YC001-YC030, YM643-YM652
D12774	1	D38999-26WD35SN CONNECTOR	96906	1	26-16-22 905/206/L031	YC031-YK912, YK918-YK919, YL401-YL429
D12774 T	1	M85049-39S15W BACKSHELL	96906	1	26-16-22 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12776	1	D38999-26WF35SN CONNECTOR	96906	1	26-16-22 817/206/L030	YC001-YC011, YC031-YM670
D12776	1	D38999-26WF35SN CONNECTOR	96906	1	26-16-22 905/206/L029	YC012-YC030
D12776 T	1	M85049-39S19W BACKSHELL	96906	1	26-16-22 */**	ALL
D12778	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 727C+10/205/L011	ALL
D12778 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-22 */**	YC001-YC030
D12778 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-22 */**	YC031-YM670
D12780	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 727I+11/205/L009	YC001-YL430
D12780	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 777/205/L009	YM643-YM670
D12780 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-22 / /	YC001-YC030
D12780 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-22 / /	YC031-YL430

EQUIPMENT LIST

D280A103

Section D12700

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12780 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-22 */*/*	YM643-YM670
D12782	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 877/205/L009	YC001-YC011, YC031-YM670
D12782	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 968/204/R009	YC012-YC030
D12782 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-22 */*/*	YC001-YC030
D12782 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-22 */*/*	YC031-YM670
D12784	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 727B+10/205/R010	ALL
D12784 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-22 */*/*	YC001-YC030
D12784 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-22 */*/*	YC031-YM670
D12786	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 727J+11/205/R009	YC001-YL430
D12786	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 757/205/R009	YM643-YM670
D12786 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-22 757/ /	YC001-YC030
D12786 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-22 757/ /	YC031-YL430
D12786 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-22 */*/*	YM643-YM670
D12788	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 857/205/R009	YC001-YC011, YC031-YM670
D12788	1	BACC45FT12-12S CONNECTOR	81205	1	26-16-22 938/204/R009	YC012-YC030
D12788 T	1	BACC10JS12 BACKSHELL	81205	1	26-16-22 */*/*	YC001-YC030
D12788 T	1	450EB001C12-347 BACKSHELL	81205	1	26-16-22 */*/*	YC031-YM670

EQUIPMENT LIST

D280A103

Section D12700

Page 4

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12792	1	BACC45FS10-5S CONNECTOR	81205	1	26-23-11 540/180/L016	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12792 T	1	BACC10JS10 BACKSHELL	81205	1	26-23-11 */*/*	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12794	1	BACC45FT8-3S CONNECTOR	81205	1	26-23-11 540/180/L016	YC001-YK912, YK918-YK919, YL401-YL429
D12794	1	BACC45FT8-3S CONNECTOR	81205	1	26-23-11 540/180/L16	YM643-YM652
D12794 T	1	BACC10JS08 BACKSHELL	81205	1	26-23-11 */*/*	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12796	1	BACC45FT10-5S CONNECTOR	81205	1	26-23-11 540/180/L016	YC001-YK912, YK918-YK919, YL401-YL429
D12796	1	BACC45FT10-5S CONNECTOR	81205	1	26-23-11 540/180/L16	YM643-YM652
D12796 T	1	BACC10JS10 BACKSHELL	81205	1	26-23-11 */*/*	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D12700
Page 5 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12802	1	BACC45FN10-5S RCPT-	81205	1	33-51-21 500C+10/210/L070	YK901-YM652
D12816	1	BACC45FS10-5S CONNECTOR	81205	1	26-23-11 540/180/R19	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12816 T	1	BACC10JS10 BACKSHELL	81205	1	26-23-11 */**	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12818	1	BACC45FT8-3S CONNECTOR	81205	1	26-23-11 540/180/R19	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12818 T	1	BACC10JS08 BACKSHELL	81205	1	26-23-11 */**	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12820	1	BACC45FT10-5S CONNECTOR	81205	1	26-23-11 540/180/R019	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12820 T	1	BACC10JS10 BACKSHELL	81205	1	26-23-11 */**	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D12828	1	AMC02RA03R RCPT-	05574	1	33-51-21 570/210/L075	YC001-YC030
D12828	1	BACC45FN10-5S RCPT-	81205	1	33-51-21 570/210/L075	YK901-YL430

EQUIPMENT LIST

D280A103

Section D12800

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12912	1	AMC02PA03B PLUG-	05574	1	33-51-13 7271+3/289/L019	YK901-YL430
D12968	1	BACS16W5A SOCKET	81205	1	27-31-11 J011-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D12900
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13018	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 500C+8/213/L067	YK901-YL430
D13018	1	BACC45FT16-24S PLUG-	81205	1	33-51-11 500C+7/215/L067	YM643-YM652
D13018 T	1	BACC10JS16 BACKSHELL-	81205	1	33-51-11 */*/	YK901-YM652

EQUIPMENT LIST

D280A103

Section D13000

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13118	1	AMC02PA03B PLUG-	05574	1	33-51-13 727E+18/293/L019	YM643-YM652
D13124	1	BACC45FN10-5S RCPT-	81205	1	33-51-22 855/210/L068	YK901-YM652

EQUIPMENT LIST

D280A103

Section D13100
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13258	1	BACC45FN10-5S RCPT-	81205	1	33-51-22 727C+10/210/L068	YK901-YM652
D13262	1	BACC45FN10-5S RCPT-	81205	1	33-51-21 610/210/L068	YM643-YM652

EQUIPMENT LIST

D280A103

Section D13200
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13364	1	BACS16W3A RELAY SOCKET	81205	1	27-41-12 J011-00/ /	YC001-YC011
D13364	1	BACS16W1A RELAY SOCKET	81205	1	27-41-12 J011-00/ /	YC012-YM670

EQUIPMENT LIST

D280A103

Section D13300
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13688		BACS16W1A RELAY SOCKET	81205	1	21-31-22 J020-00/ /	YC028-YM670
D13690		BACS16W1A RELAY SOCKET	81205	1	21-31-23 J020-00/ /	YC028-YM670

EQUIPMENT LIST

D280A103

Section D13600

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13712	1	BACS16W1A SOCKET - IFE/PASS SEAT CONTROL RELAY	81205	1	24-28-41 P006-00/ /	YC031-YM670
D13730	1	BACC45FT14-15S PLUG - DOOR POST ASSY INTERFACE	81205	1	52-51-11 279/284/R010	YC031-YM670
D13730 T	1	450EB001C14-347 BACKSHELL - SINGLE LEG - 45 DEG		1	52-51-11 */*/	YC031-YM670
D13790	1	BACC45FT14-15S PLUG- S1 TEST SWITCH - LEFT	81205	1	28-23-11 P061-08/ /	YC031-YM670
D13792	1	BACC45FT14-15S6 PLUG- S2 TEST SWITCH - RIGHT	81205	1	28-23-11 P061-08/ /	YC031-YM670
D13794	1	BACS16W10A RELAY SOCKET	81205	1	28-23-11 J020-00/ /	YC031-YM670
D13796	1	BACS16X6A RELAY SOCKET	81205	1	28-23-11 J020-00/ /	YC031-YM670
D13798	1	BACS16W10A RELAY SOCKET	81205	1	28-23-11 J004-00/ /	YC031-YM670

EQUIPMENT LIST

D280A103

Section D13700
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13800	1	BACS16X6A RELAY SOCKET	81205	1	28-23-11 J004-00/ /	YC031-YM670
D13804	1	BACC63BP22C55SN PLUG-	81205	1	47-30-11 500D+11/201/R012	YK911-YK917, YK919-YK920, YM651-YM670
D13804	1	BACC63BP22C55SN PLUG-	81205	1	47-30-11 500I+11/201/R012	YL401, YL427- YL430
D13804 T	1	BACC10MP22 BACKSHELL- STRAIGHT	81205	1	47-30-11 */*/*	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13806	1	BACC63BP22C55S6 PLUG-	81205	1	47-30-11 500D+6/201/R012	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13806 T	1	BACC10MP22 BACKSHELL- STRAIGHT	81205	1	47-30-11 */*/*	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13808	1	BACC63BP12D12SN PLUG-	81205	1	47-30-11 543/157/R038	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13808 T	1	BACC10MM12 BACKSHELL- 90 DEGREE	81205	1	47-30-11 543/157/R038	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13810	1	BACC63DB11-98SN PLUG-	81205	1	47-30-11 543/162/L032	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13810 T	1	BACC10MA11 BACKSHELL- 90 DEGREE	81205	1	47-30-11 543/162/L032	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670

EQUIPMENT LIST

D280A103

Section D13800

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13812	1	BACC63DB11-98SD PLUG-	81205	1	47-30-11 644/160/L054	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13812 T	1	BACC10MA11 BACKSHELL- 90 DEGREE	81205	1	47-30-11 644/160/L054	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13814	1	BACC63DB9-98SN PLUG-	81205	1	47-30-11 642/163/L048	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13814 T	1	BACC10MA9 BACKSHELL- STRAIGHT	81205	1	47-30-11 642/163/L048	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13816	1	BACC63DB9-98SD PLUG-	81205	1	47-30-11 654/161/L066	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13816 T	1	BACC10MA9 BACKSHELL- 90 DEGREE	81205	1	47-30-11 654/161/L066	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13818	1	BACC63DB9-35SN PLUG-	81205	1	47-30-11 656/158/L047	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13818 T	1	BACC10MA9 BACKSHELL- 90 DEGREE	81205	1	47-30-11 656/158/L047	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13820	1	M83723-75G1005N PLUG-	81205	1	47-30-11 605/162/L059	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670

EQUIPMENT LIST

D280A103

Section D13800

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13820 T	1	BACC10MM10 BACKSHELL- 90 DEGREE	81205	1	47-30-11 605/162/L059	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13824	1	BACC63DB9-35SN PLUG-	81205	1	47-30-11 602/161/L060	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13824 T	1	BACC10MA9 BACKSHELL- 90 DEGREE	81205	1	47-30-11 602/161/L060	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13826	1	BACC63DB9-98SN PLUG-	81205	1	47-30-11 653/162/L061	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13826 T	1	BACC10MA9 BACKSHELL- 90 DEGREE	81205	1	47-30-11 653/162/L061	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13828	1	BACC63DB11-98SN PLUG-	81205	1	47-30-11 657/161/L066	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13828 T	1	BACC10MA11 BACKSHELL- 90 DEGREE	81205	1	47-30-11 657/161/L066	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13830	1	BACC63DB9-35SN PLUG-	81205	1	47-30-11 539/167/L034	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13830 T	1	BACC10MA9 BACKSHELL- STRAIGHT	81205	1	47-30-11 539/167/L034	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670

EQUIPMENT LIST

D280A103

Section D13800

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13832	1	BACC63BP16D24PN PLUG-	81205	1	47-30-11 538/197/L041	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13832 T	1	BACC10MM16 BACKSHELL- STRAIGHT	81205	1	47-30-11 */**	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13838	1	BACC63BP10D5SN PLUG	81205	1	47-30-11 723/166/R010	YC031-YC050, YK906-YM670
D13838 T	1	387AS020Z110A-D3-342 BACKSHELL - CONDUCTIVE	81205	1	47-30-11 */**	YC031-YC050, YK906-YM670
D13842		BACS16AG1 RELAY SOCKET	81205	1	47-30-11 J020-00/ /	YC031-YC050, YK906-YM670
D13844	1	BACC45FT12-12S CONECTOR	81205	10	26-16-21 MULTI/ /	YC031-YM670
D13846	1	BACC45FN12-12P CONECTOR	81205	10	26-16-21 MULTI/ /	YC031-YM670

EQUIPMENT LIST

D280A103

Section D13800
Page 4 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13928	1	BACC63BV16B24SN RCPT - NGS INTERFACE		1	47-30-11 537/197/L041	YC031-YC050, YK906-YM670
D13928 T	1	387AS020Z116A-D3-342 BACKSHELL - CONDUCTIVE	81205	1	47-30-11 */**	YC031-YC050, YK906-YM670
D13932	1	BACC63BP22D39PN PLUG-	81205	1	47-30-11 536/164/L036	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13932 T	1	BACC10MM22 BACKSHELL- STRAIGHT	81205	1	47-30-11 536/164/L036	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13934	1	BACC63BP22D39SN PLUG-	81205	1	47-30-11 536/164/L036	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13934 T	1	BACC10MM22 BACKSHELL- 90 DEGREE	81205	1	47-30-11 */**	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13938		D38999-26FA98SN SPEED BRK GND PROX SW	81205	1	27-62-11 675/194/R067	YK907-YK912, YK918-YK919, YL401-YL429
D13938 T		M85049-39S9N BACKSHELL	81205	1	27-62-11 / /	YK907-YK912, YK918-YK919, YL401-YL429
D13940		BACS16W1A RELAY-SOCKET	81205	1	27-62-11 J039-00/ /	YK907-YL430
D13942		BACS16W1A RELAY-SOCKET	81205	1	27-62-11 J039-00/ /	YK907-YL430
D13944		BACS16W1A RELAY-SOCKET	81205	1	27-62-11 J039-00/ /	YK907-YL430
D13946		BACS16W1A RELAY-SOCKET	81205	1	27-62-11 J039-00/ /	YK907-YL430
D13948		BACS16W1A RELAY-SOCKET	81205	1	27-62-11 J039-00/ /	YK907-YL430

EQUIPMENT LIST

D280A103

Section D13900

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13950		BACS16W1A RELAY-SOCKET	81205	1	27-62-11 J039-00/ /	YK907-YL430
D13952		BACS16W1A RELAY-SOCKET	81205	1	27-62-11 J039-00/ /	YK907-YL430
D13954		BACC63BP10C5SN SPOILER-SOCKET	81205	1	27-62-11 ORSS/412/	YK907-YK912, YK918-YK919, YL401-YL429
D13954 T		BACC10KF10 BACKSHELL - 45 DEGREE	81205	1	27-62-11 ORSS/412/	YK907-YK912, YK918-YK919, YL401-YL429
D13956		BACC63BP10C5SN SPOILER-SOCKET	81205	1	27-62-11 ORSS/383/	YK907-YK912, YK918-YK919, YL401-YL429
D13956 T		BACC10KE10 BACKSHELL - 90 DEGREE	81205	1	27-62-11 ORSS/383/	YK907-YK912, YK918-YK919, YL401-YL429
D13958		BACC63BP10C5SN SPOILER-SOCKET	81205	1	27-62-11 ORSS/342/	YK907-YK912, YK918-YK919, YL401-YL429
D13958 T		BACC10KF10 BACKSHELL - 45 DEGREE	81205	1	27-62-11 ORSS/342/	YK907-YK912, YK918-YK919, YL401-YL429
D13964		BACC63BP10C5SN SPOILER - SOCKET	81205	1	27-62-11 ORSS/358/	YK907-YK912, YK918-YK919, YL401-YL429
D13964 T		BACC10KE10 BACKSHELL - 90 DEGREE	81205	1	27-62-11 ORSS/358/	YK907-YK912, YK918-YK919, YL401-YL429
D13966		BACC63BP10C5SN SPOILER - SOCKET	81205	1	27-62-11 ORSS/400/	YK907-YK912, YK918-YK919, YL401-YL429
D13966 T		BACC10KE10 BACKSHELL - 90 DEGREE	81205	1	27-62-11 ORSS/400/	YK907-YK912, YK918-YK919, YL401-YL429

EQUIPMENT LIST

D280A103

Section D13900

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13968		BACC63BP10C5SN SPOILER - SOCKET	81205	1	27-62-11 ORSS/422/	YK907-YK912, YK918-YK919, YL401-YL429
D13968 T		BACC10KE10 BACKSHELL - 90 DEGREE	81205	1	27-62-11 ORSS/422/	YK907-YK912, YK918-YK919, YL401-YL429
D13970	1	BACC63BP22D39SN PLUG-	81205	1	47-30-11 536/166/R037	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13970 T	1	BACC10MM22 BACKSHELL- 90 DEGREE	81205	1	47-30-11 */**	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13972	1	BACC63BP22D39PN PLUG-	81205	1	47-30-11 536/166/R037	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13972 T	1	BACC10MM22 BACKSHELL- STRAIGHT	81205	1	47-30-11 536/166/R037	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D13978	1	AMC02PA03B PLUG-	05574	1	33-51-13 612/288/L000	YK911-YK917, YK919-YL401, YL427-YL430

EQUIPMENT LIST

D280A103

Section D13900

Page 3 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D14006	1	M24308-4-11F PLUG-	55104	1	25-29-11 357/166/R025	YK907-YK909, YL421-YL430
D14006 T	1	557T386NF131 BACKSHELL	06324	1	25-29-11 /*/*	YK907-YK909, YL421-YL430
D14006 U	1	DE51224-1 END DISC LATCH ASSEMBLY	71468	2	25-29-11 /*/*	YK907-YK909, YL421-YL430
D14008	1	M24308-4-11F PLUG-	55104	1	25-29-11 357/166/R025	YK907-YK909, YL421-YL430
D14008 T	1	557T386NF131 BACKSHELL	06324	1	25-29-11 */*/*	YK907-YK909, YL421-YL430
D14008 U	1	DE51224-1 SLIDE LATCH ASSEMBLY	71368	2	25-29-11 */*/*	YK907-YK909, YL421-YL430
D14010	1	D38999-24MB35SN RCPT-		1	25-29-11 255/216/R040	YK907-YK909
D14010	1	D38999-24MB35SN PLUG-		1	25-29-11 255/216/R040	YL421-YL430
D14012	1	D38999-24MB35SN RCPT		1	25-29-11 253/218/L040	YK907-YK909
D14012	1	D38999-24MB35SN PLUG-		1	25-29-11 253/218/L040	YL421-YL430

EQUIPMENT LIST

D280A103

Section D14000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D14112		BACC63BV10B5PN RECPT - CONDUCTIVE	81205	1	47-30-11 723/166/R010	YC031-YC050, YK906-YM670
D14112 T		BACC10KA10 BACKSHELL - CONDUCTIVE	81205	1	47-30-11 */**	YC031-YC050, YK906, YL421
D14112 T		440AS069Z11002-3T BACKSHELL - CONDUCTIVE	81205	1	47-30-11 */**	YK907-YL401, YL422-YM670
D14114	1	172159-1 RCPT W/ SOCKET CONTACTS (170362-3)	00779	1	31-52-11 P007-00/ /	YC001-YC030, YK901-YL430
D14114	1	172159-1 RCPT W/ SOCKET CONTACTS (170362-3)	00779	1	31-52-11 P007/ /	YM643-YM670
D14114 T	1	170362-3 SOCKET CONTACTS	00779	1	31-52-11 P007-00/ /	YC001-YC030
D14114 T	1	170362-3 SOCKET CONTACTS	00779	1	31-52-11 */**	YK901-YM670
D14116	1	172159-1 RCPT W/ SOCKET CONTACTS (170362-3)	00779	1	31-52-11 P007-00/ /	YC001-YC030, YK901-YM670
D14116 T	1	170362-3 SOCKET CONTACTS	00779	1	31-52-11 P007-00/ /	YC001-YC030, YM643-YM670
D14116 T	1	170362-3 SOCKET CONTACTS	00779	1	31-52-11 */**	YK901-YL430
D14118	1	172159-1 RCPT W/ SOCKET CONTACTS (170362-3)	00779	1	33-18-51 P007-00/ /	YC001-YC030, YK901-YM670
D14118 T	1	170362-3 SOCKET CONTACTS	00779	1	33-18-61 P007-00/ /	YC001-YC030
D14118 T	1	170362-3 SOCKET CONTACTS	00779	1	33-18-61 */**	YK901-YM670
D14120	1	172159-1 RCPT W/ SOCKET CONTACTS (170362-3)	00779	1	33-18-51 P007-00/ /	YC001-YC030, YK901-YM670
D14120 T	1	170362-3 SOCKET CONTACTS	00779	1	33-18-51 P007-00/ /	YC001-YC030, YM643-YM670
D14120 T	1	170362-3 SOCKET CONTACTS	00779	1	33-18-51 */**	YK901-YL430

EQUIPMENT LIST

D280A103

Section D14100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D14124		BACC63BP10C5SN SPOILER - SOCKET	81205	1	27-62-11 ORSS/317/	YK907-YK912, YK918-YK919, YL401-YL429
D14124 T		BACC10KF10 BACKSHELL - 45 DEGREE	81205	1	27-62-11 ORSS/317/	YK907-YK912, YK918-YK919, YL401-YL429
D14126		BACC63BP10C5SN SPOILER-SOCKET	81205	1	27-62-11 ORSS/294/	YK907-YK912, YK918-YK919, YL401-YL429
D14126 T		BACC10KF10 BACKSHELL - 45 DEGREE	81205	1	27-62-11 ORSS/294/	YK907-YK912, YK918-YK919, YL401-YL429
D14156	1	BACS16X1A SOCKET-	81205	1	47-30-11 J00024/ /	YK906-YM670

EQUIPMENT LIST

D280A103

Section D14100
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D14200	1	BACC63DB13-98SN PLUG-	81205	1	47-30-11 577/155/L044	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D14200 T	1	BACC10MA13 BACKSHELL- 90 DEGREE	81205	1	47-30-11 577/155/L044	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
D14212	9	BACC45FT14-7S PLUG	81205	1	25-29-11 357/166/R024	YK907-YK909
D14212	1	BACC45FT14-7S PLUG-	81205	1	25-29-11 357/166/R024	YL421-YL430
D14212 T	9	BACC10GH14 BACKSHELL	81205	1	25-29-11 / /*	YK907-YK909
D14212 T	1	BACC10GH14 BACKSHELL	81205	1	25-29-11 / /*	YL421-YL430
D14284	1	BACC63CE14S-7S PLUG-CAB PRESS SW	81205	1	21-33-11 196/208/R001	YK911
D14284	1	BACC63CE14S-7S PLUG-CAB PRESS SW	81205	1	21-33-11 196/208/0.46	YK912-YK917, YK919-YL401, YL427-YL430, YM651-YM652

EQUIPMENT LIST

D280A103

Section D14200

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30002	1	BACC63CM1814P6 PLUG-CONDUCTIVE CONNECTOR	81205	2	78-35-11 NSTA 202/136/L12	ALL
D30002 T	1	BACC10KA18 BACKSHELL	81205	2	78-35-11 //	YC001-YC007
D30002 T	1	440AS069ZM1836-4 BACKSHELL	06324	2	78-35-11 //	YC008-YC030
D30002 T	1	440AS069ZM1836-3-63 BACKSHELL	06324	2	78-35-11 //	YC031-YM670
D30002 U	1	202K142-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YC030
D30002 U	1	202C632-50-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC031-YM670
D30002 U	2	202K142-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30002 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-35-11 //	YC008-YM670
D30006	1	BACC63CM1814P7 PLUG-CONDUCTIVE CONNECTOR	81205	2	78-35-11 NSTA 202/137/R12	ALL
D30006 T	1	BACC10KA18 BACKSHELL	81205	2	78-35-11 //	YC001-YC007
D30006 T	1	440AS069ZM1836-4 BACKSHELL	06324	2	78-35-11 //	YC008-YC030
D30006 T	1	440AS069ZM1836-3-63 BACKSHELL	06324	2	78-35-11 //	YC031-YM670
D30006 U	1	202K142-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YC030
D30006 U	1	202C632-50-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC031-YM670
D30006 U	2	202K142-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30006 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-35-11 //	YC008-YM670
D30008	1	BACC63CM1610P6 PLUG-CONDUCTIVE CONNECTOR	81205	2	78-35-11 NSTA 200/137/L12	ALL

EQUIPMENT LIST

D280A103

Section D30000

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30008 T	1	BACC10KA16 BACKSHELL	81205	2	78-35-11 //	YC001-YC007
D30008 T	1	440AS069ZM1635-4 BACKSHELL	06324	2	78-35-11 //	YC008-YC030
D30008 T	1	440AS069ZM1635-3 BACKSHELL	06324	2	78-35-11 //	YC031-YM670
D30008 U	1	202K132-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YC030
D30008 U	1	202C621-50-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC031-YM670
D30008 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30008 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-35-11 //	YC008-YM670
D30010	1	BACC63CM1610P7 PLUG-CONDUCTIVE CONNECTOR	81205	2	78-35-11 NSTA 200/137/R12	ALL
D30010 T	1	BACC10KA16 BACKSHELL	81205	2	78-35-11 //	YC001-YC007
D30010 T	1	440AS069ZM1635-4 BACKSHELL	06324	2	78-35-11 //	YC008-YC030
D30010 T	1	440AS069ZM1635-3 BACKSHELL	06324	2	78-35-11 //	YC031-YM670
D30010 U	1	202K132-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YC030
D30010 U	1	202C621-50-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC031-YM670
D30010 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30010 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-35-11 //	YC008-YM670
D30014	1	BACC63BP22C39S9 PLUG-CONDUCTIVE	81205	1	80-11-11 IFSS-229/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D30000

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30014 T	1	BACC10KD22 BACKSHELL	81205	1	80-11-11 IFSS-229/ /	YC001-YC030, YK901-YK910, YK918, YL421- YL425, YM643- YM646
D30014 T	1	BACC10KF22 BACKSHELL	81205	1	80-11-11 IFSS-229/ /	YK911-YK917, YK919-YL401, YL426-YL430, YM647-YM670
D30016	1	BACC63BP22C39P9 PLUG-CONDUCTIVE	81205	1	24-21-11 NSTA 259/146/R013	ALL
D30016 T	1	BACC10KF22 BACKSHELL	81205	1	24-21-11 / /	ALL
D30038	1	CA66287-50 PLUG	71468	2	24-21-11 TBD/ /	ALL
D30040	1	BACC63BP22C39SN PLUG-CONDUCTIVE	81205	1	78-36-11 IFSS-228/ /	YC001-YC007
D30040	1	SEESCD282A730-001 PLUG-	81205	1	78-36-11 IFSS-228/ /	YC008-YC050
D30040	1	SEEDWG325-039-002-0 PLUG-	81205	1	78-36-11 IFSS-228/ /	YK901-YM670
D30040 T	1	S280W603-213 BACKSHELL	81205	1	78-36-11 IFSS-228/ /	YC001-YC007
D30042	1	BACC63BP22C39PN PLUG-CONDUCTIVE	81205	1	73-21-21 NSTA 258/149/R013	ALL
D30042 T	1	S280W603-113 BACKSHELL	81205	1	73-21-21 / /	YC001-YC007
D30042 T	1	440AS069LF2208-4P BACKSHELL	06324	1	73-21-21 / /	YC008-YC011
D30042 T	1	440AH069LF2208-P BACKSHELL	06324	1	73-21-21 / /	YC012-YM670
D30042 U	1	BACB42F3 CLAMP/BAND	81205	1	73-21-21 / /	YC001-YC007
D30042 U	1	202K153-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	73-21-21 / /	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30042 U	2	202K153-25-0 STRAIGHT, LIPPED BOOT	06090	1	73-21-21 //	YC008-YM670
D30042 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	73-21-21 //	YC008-YM670
D30062	1	BACC63BP16C24SN PLUG-CONDUCTIVE	81205	1	26-11-11 IFSS-229/ /	YC001-YC030, YK901-YM670
D30062 T	1	BACC10KF16 BACKSHELL	81205	1	26-11-11 IFSS-229/ /	YC001-YC030, YK901-YM670
D30064	1	BACC63BP16C24PN PLUG-CONDUCTIVE	81205	1	26-11-11 NSTA 260/142/R013	ALL
D30064 T	1	BACC10KF16 BACKSHELL	81205	1	26-11-11 //	ALL
D30072	1	BACC63CM1005SN PLUG-CONDUCTIVE CONNECTOR	81205	2	78-35-11 NSTA 200/128/L25	ALL
D30072 T	1	BACC10KB10 BACKSHELL	81205	2	78-35-11 //	YC001-YC007
D30072 T	1	440AJ069ZM1003 BACKSHELL	06324	2	78-35-11 //	YC008-YM670
D30072 U	1	202K121-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30072 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30072 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-35-11 //	YC008-YM670
D30074	1	BACC63CM1005SN PLUG-CONDUCTIVE CONNECTOR	81205	2	78-35-11 NSTA 200/124/R28	ALL
D30074 T	1	BACC10KB10 BACKSHELL	81205	2	78-35-11 //	YC001-YC007
D30074 T	1	440AJ069ZM1003 BACKSHELL	06324	2	78-35-11 //	YC008-YM670
D30074 U	1	202K121-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30074 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30000

Page 4

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30074 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-35-11 //	YC008-YM670
D30076	1	BACC63CM1005SN PLUG-CONDUCTIVE CONNECTOR	81205	2	78-35-11 NSTA 200/128/L23	ALL
D30076 T	1	BACC10KB10 BACKSHELL	81205	2	78-35-11 //	YC001-YC007
D30076 T	1	440AS069ZM1003-5-16B BACKSHELL	06324	2	78-35-11 //	YC008-YM670
D30076 U	1	202K121-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30076 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30076 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-35-11 //	YC008-YM670
D30078	1	BACC63CM1005SN PLUG-CONDUCTIVE CONNECTOR	81205	2	78-35-11 NSTA 200/126/R28	ALL
D30078 T	1	BACC10KB10 BACKSHELL	81205	2	78-35-11 //	YC001-YC007
D30078 T	1	440AJ069ZM1003 BACKSHELL	06324	2	78-35-11 //	YC008-YM670
D30078 U	1	202K121-25-225-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30078 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-35-11 //	YC008-YM670
D30078 V	1	BACB42F3 STRAIGHT, LIPPED BOOT	81205	2	78-35-11 //	YC008-YM670
D30082	1	BACC63BP22C39S6 PLUG-CONDUCTIVE	81205	1	73-21-21 IFSS-228/ /	YC001-YC007
D30082	1	SEESCD282A730-003 PLUG-	81205	1	73-21-21 IFSS-228/ /	YC008-YC050
D30082	1	SEEDWG325-104-601-0 PLUG-	81205	1	73-21-21 IFSS-228/ /	YK901-YM670
D30082 T	1	S280W603-213 BACKSHELL	81205	1	73-21-21 IFSS-228/ /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D30000

Page 5

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30084	1	BACC63BP22C39P6 PLUG-CONDUCTIVE	81205	1	78-35-11 NSTA 258/144/R013	ALL
D30084 T	1	S280W603-213 BACKSHELL	81205	1	78-35-11 //	YC001-YC007
D30084 T	1	440AH069LF2208-P BACKSHELL	06324	1	78-35-11 //	YC008-YM670
D30084 U	1	BACB42F3 CLAMP/BAND	81205	1	83-511 //	YC001-YC007
D30084 U	1	202K153-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-11 //	YC008-YM670
D30084 U	2	202K153-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-11 //	YC008-YM670
D30084 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-35-11 //	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30000

Page 6 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30114	1	BACC63BP22C39S9 PLUG-CONDUCTIVE	81205	1	80-11-11 IFSS 229/ /	YC001-YC030, YK901-YM670
D30114 T	1	BACC10KD22 BACKSHELL	81205	1	80-11-11 IFSS 229/ /	YC001-YC030, YK901-YK910, YK918, YL421- YL425, YM643- YM646
D30114 T	1	BACC10KF22 BACKSHELL	81205	1	80-11-11 IFSS 229/ /	YK911-YK917, YK919-YL401, YL426-YL430, YM647-YM670
D30116	1	BACC63BP22C39P9 PLUG-CONDUCTIVE	81205	1	80-11-11 NSTA 259/146/L13	ALL
D30116 T	1	BACC10KF22 BACKSHELL-CONDUCTIVE	81205	1	80-11-11 / /	ALL
D30140	1	BACC63BP22C39SN PLUG-CONDUCTIVE	81205	1	73-24-12 IFSS 229/ /	YC001-YC007
D30140	1	SEESCD282A730-002 PLUG-	81205	1	73-24-12 IFSS 229/ /	YC008-YC050
D30140	1	SEEDWG325-039-102-0 PLUG-	81205	1	73-24-12 IFSS 229/ /	YK901-YM670
D30140 T	1	S280W603-213 BACKSHELL	81205	1	73-24-12 IFSS 229/ /	YC001-YC007
D30142	1	BACC63BP22C39PN PLUG-CONDUCTIVE	81205	1	78-35-21 NSTA 258/149/L13	ALL
D30142 T	1	S280W603-113 BACKSHELL	81205	1	78-35-21 / /	YC001-YC007
D30142 T	1	440AS069LF2208-4P BACKSHELL	06324	1	78-35-21 / /	YC008-YM670
D30142 U	1	BACB42F3 CLAMP/BAND	81205	1	78-35-21 / /	YC001-YC007
D30142 U	1	202K153-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 / /	YC008-YM670
D30142 U	2	202K153-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 / /	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30142 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-35-21 / /	YC008-YM670
D30162	1	BACC63BP16C24SN PLUG-CONDUCTIVE	81205	1	26-11-21 IFSS 230/ /	ALL
D30162 T	1	BACC10KF16 BACKSHELL	81205	1	26-11-21 IFSS 230/ /	YC001-YC030
D30162 T	1	BACC10KF16 BACKSHELL	81205	1	26-11-21 */*/	YC031-YM670
D30164	1	BACC63BP16C24PN PLUG-CONDUCTIVE	81205	1	26-11-21 NSTA 260/142/L13	ALL
D30164 T	1	BACC10KF16 BACKSHELL	81205	1	26-11-21 / /	ALL
D30182	1	BACC63BP22C39S6 PLUG-CONDUCTIVE	81205	1	73-21-21 IFSS 228/ /	YC001-YC007
D30182	1	SEESCD282A730-004 PLUG	81205	1	73-21-21 IFSS 228/ /	YC008-YC050
D30182	1	SEEDWG325-104-701-0 PLUG	81205	1	73-21-21 IFSS 228/ /	YK901-YM670
D30182 T	1	S280W603-213 BACKSHELL	81205	1	73-21-21 IFSS 228/ /	YC001-YC007
D30184	1	BACC63BP22C39P6 PLUG-CONDUCTIVE	81205	1	73-21-21 NSTA 258/144/L13	ALL
D30184 T	1	S280W603-213 BACKSHELL	81205	1	73-21-21 / /	YC001-YC007
D30184 T	1	440AH069LF2208-P BACKSHELL	06324	1	73-21-21 / /	YC008-YM670
D30184 U	1	BACB42F3 CLAMP/BAND	81205	1	73-21-21 / /	YC001-YC007
D30184 U	1	202K153-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	73-21-21 / /	YC008-YM670
D30184 U	2	202K153-25-0 STRAIGHT, LIPPED BOOT	06090	1	73-21-21 / /	YC008-YM670
D30184 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	73-21-21 / /	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30100

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30202	1	BACC63CN1814S6 RECP-CONDUCTIVE CONNECTOR	81205	1	78-36-11 NSTA 202/136/L12	ALL
D30202 T	1	BACC10KC18 BACKSHELL	81205	1	78-36-11 //	YC001-YC007
D30202 T	1	440AH069ZM1836 BACKSHELL	06324	1	78-36-11 //	YC008-YM670
D30202 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-11 //	YC008-YM670
D30202 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-11 //	YC008-YM670
D30202 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-36-11 //	YC008-YM670
D30204	1	BACC63CN1814SN RECP-CONDUCTIVE CONNECTOR	81205	1	36-11-11 NSTA 162/134/R10	ALL
D30204 T	1	387AS020Z118A-D3-342 BACKSHELL	06324	1	36-11-11 //	YC001-YC007
D30204 T	1	440AH069ZM1836 BACKSHELL	06324	1	36-11-11 //	YC008-YM670
D30204 U	1	687-062-03 CLAMP/BAND	06324	1	36-11-11 //	YC001-YC007
D30204 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	36-11-11 //	YC008-YM670
D30204 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	36-11-11 //	YC008-YM670
D30204 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	36-11-11 //	YC008-YM670
D30206	1	BACC63CN1814S7 RECP-CONDUCTIVE CONNECTOR	81205	1	78-35-21 NSTA 202/136/R12	ALL
D30206 T	1	BACC10KC18 BACKSHELL	81205	1	78-35-21 //	YC001-YC007
D30206 T	1	440AH069ZM1836 BACKSHELL	06324	1	78-35-21 //	YC008-YM670
D30206 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 //	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30200

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30206 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 //	YC008-YM670
D30206 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-35-21 //	YC008-YM670
D30208	1	BACC63CN1610S6 RECP-CONDUCTIVE CONNECTOR	81205	1	78-35-11 NSTA 200/136/L12	ALL
D30208 T	1	BACC10KC16 BACKSHELL	81205	1	78-35-11 //	YC001-YC007
D30208 T	1	440AH069ZM1635 BACKSHELL	06324	1	78-35-11 //	YC008-YM670
D30208 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-11 //	YC008-YM670
D30208 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-11 //	YC008-YM670
D30208 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-35-11 //	YC008-YM670
D30210	1	BACC63CN1610S7 RECP-CONDUCTIVE CONNECTOR	81205	1	78-36-11 NSTA 200/136/R12	ALL
D30210 T	1	BACC10KC16 BACKSHELL	81205	1	78-36-11 //	YC001-YC007
D30210 T	1	440AH069ZM1635 BACKSHELL	06324	1	78-36-11 //	YC008-YM670
D30210 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-11 //	YC008-YM670
D30210 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-11 //	YC008-YM670
D30210 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-36-11 //	YC008-YM670
D30212	1	BACC63CN1610SN RECP-CONDUCTIV CONNECTOR	81205	1	73-22-11 NSTA 178/134/R11	ALL
D30212 T	1	BACC10KC16 BACKSHELL	81205	1	73-22-11 //	ALL
D30220	1	BACC63CN1407S7 RECP-CONDUCTIVE CONNECTOR	81205	1	26-11-11 NSTA 170/136/R12	ALL

EQUIPMENT LIST

D280A103

Section D30200

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30220 T	1	BACC10KC14 BACKSHELL	81205	1	26-11-11 //	ALL
D30224	1	BACC63CN2842S7 RECP-CONDUCTIVE CONNECTOR	81205	1	78-35-21 NSTA 182/135/R11	ALL
D30224 T	1	387AS020Z128A-D3-342 BACKSHELL	06324	1	78-35-21 //	YC001-YC007
D30224 T	1	440AH069ZM2838-745 BACKSHELL	06324	1	78-35-21 //	YC008-YM670
D30224 U	1	687-062-06 CLAMP/BAND	06324	1	78-35-21 //	YC001-YC007
D30224 U	1	202K153-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 //	YC008-YM670
D30224 U	2	202K153-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 //	YC008-YM670
D30224 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-36-11 //	YC008-YM670
D30228	1	BACC63CN2430SN RECP-CONDUCTIVE CONNECTOR	81205	1	30-21-11 NSTA 166/135/R11	ALL
D30228 T	1	BACC10KC24 BACKSHELL	81205	1	30-21-11 //	ALL
D30234	1	BACC63CN2842SN RECP-CONDUCTIVE CONNECTOR	81205	1	24-21-11 NSTA 162/135/L11	ALL
D30234 T	1	BACC10KC28 BACKSHELL	81205	1	24-21-11 //	ALL
D30238	1	CA66286-45 RECP-	71468	1	24-21-11 NSTA 170/135/L11	ALL
D30252	1	BACC63CN1407S6 RECP-CONDUCTIVE	81205	1	26-11-11 NSTA 172/134/R11	ALL
D30252 T	1	BACC10KC14 BACKSHELL	81205	1	26-11-11 //	ALL
D30256	1	BACC63CN1407SN RECP-CONDUCTIVE CONNECTOR	81205	1	73-22-11 NSTA 163/136/R12	ALL
D30256 T	1	BACC10KC14 BACKSHELL	81205	1	73-22-11 //	ALL

EQUIPMENT LIST

D280A103

Section D30200

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30260	1	BACC63CN2842S6 RECP-CONDUCTIVE CONNECTOR	81205	1	73-21-21 NSTA 186/136/R11	ALL
D30260 T	1	387AS020Z128A-D3-342 BACKSHELL	06324	1	73-21-21 //	YC001-YC007
D30260 T	1	440AH069ZM2838-745 BACKSHELL	06324	1	73-21-21 //	YC008-YM670
D30260 U	1	687-062-06 CLAMP/BAND	06324	1	78-35-11 //	YC001-YC007
D30260 U	1	202K153-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	73-21-21 //	YC008-YM670
D30260 U	2	202K153-25-0 STRAIGHT, LIPPED BOOT	06090	1	73-21-21 //	YC008-YM670
D30260 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	73-21-21 //	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30200

Page 4 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30402	1	BACC63CN1814S6 RECP-CONDUCTIVE CONNECTOR	81205	1	78-36-21 NSTA 202/136/L12	ALL
D30402 T	1	BACC10KC18 BACKSHELL	81205	1	78-36-21 //	YC001-YC007
D30402 T	1	440AH069ZM1836 BACKSHELL	06324	1	78-36-21 //	YC008-YM670
D30402 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-21 //	YC008-YM670
D30402 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-21 //	YC008-YM670
D30402 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-36-21 //	YC008-YM670
D30404	1	BACC63CN1814SN RECP-CONDUCTIVE CONNECTOR	81205	1	30-11-11 NSTA 162/134/R10	ALL
D30404 T	1	387AS020Z118A-D3-342 BACKSHELL	06324	1	30-11-11 //	YC001-YC007
D30404 T	1	440AH069ZM1836 BACKSHELL	06324	1	30-11-11 //	YC008-YM670
D30404 U	1	687-062-03 CLAMP/BAND	06324	1	30-11-11 //	YC001-YC007
D30404 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	30-11-11 //	YC008-YM670
D30404 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	30-11-11 //	YC008-YM670
D30404 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	30-11-11 //	YC008-YM670
D30406	1	BACC63CN1814S7 RECP-CONDUCTIVE CONNECTOR	81205	1	78-36-21 NSTA 202/136/R12	ALL
D30406 T	1	BACC10KC18 BACKSHELL	81205	1	78-36-21 //	YC001-YC007
D30406 T	1	440AH069ZM1836 BACKSHELL	06324	1	78-36-21 //	YC008-YM670
D30406 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-21 //	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30400

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30406 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-21 //	YC008-YM670
D30406 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-36-21 //	YC008-YM670
D30408	1	BACC63CN1610S6 RECP-CONDUCTIVE CONNECTOR	81205	1	78-35-21 NSTA 200/136/L12	ALL
D30408 T	1	BACC10KC16 BACKSHELL	81205	1	78-35-21 //	YC001-YC007
D30408 T	1	440AH069ZM1635 BACKSHELL	06324	1	78-35-21 //	YC008-YM670
D30408 U	1	202K132-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 //	YC008-YM670
D30408 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 //	YC008-YM670
D30408 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-35-21 //	YC008-YM670
D30410	1	BACC63CN1610S7 RECP-CONDUCTIVE CONNECTOR	81205	1	78-36-21 NSTA 200/136/R12	ALL
D30410 T	1	BACC10KC16 BACKSHELL	81205	1	78-36-21 //	YC001-YC007
D30410 T	1	440AH069ZM1635 BACKSHELL	06324	1	78-36-21 //	YC008-YM670
D30410 U	1	202K132-25-0-225 STRAIGHT, LIPPED BOOT	06090	1	78-36-21 //	YC008-YM670
D30410 U	2	202K132-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-36-21 //	YC008-YM670
D30410 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-36-21 //	YC008-YM670
D30412	1	BACC63CN1610SN RECP-CONDUCTIVE CONNECTOR	81205	1	73-22-11 NSTA 178/134/R011	ALL
D30412 T	1	BACC10KC16 BACKSHELL	81205	1	73-22-11 */*/	ALL
D30420	1	BACC63CN1407S7 RECP-CONDUCTIVE CONNECTOR	81205	1	26-11-21 NSTA 170/136/R12	ALL

EQUIPMENT LIST

D280A103

Section D30400

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30420 T	1	BACC10KC14 BACKSHELL	81205	1	26-11-21 / /	ALL
D30424	1	BACC63CN2842S7 RECP-CONDUCTIVE CONNECTOR	81205	1	78-35-21 NSTA 182/135/R11	ALL
D30424 T	1	387AS020Z128A-D3-342 BACKSHELL	06324	1	78-35-21 8/ /	YC001-YC007
D30424 T	1	440AH069ZM2838-745 BACKSHELL	06324	1	78-35-21 8/ /	YC008-YM670
D30424 U	1	687-062-06 CLAMP/BAND	06324	1	78-35-21 / /	YC001-YC007
D30424 U	1	202K153-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 / /	YC008-YM670
D30424 U	2	202K153-25-0 STRAIGHT, LIPPED BOOT	06090	1	78-35-21 / /	YC008-YM670
D30424 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	78-35-21 / /	YC008-YM670
D30428	1	BACC63CN2430SN RECP-CONDUCTIVE CONNECTOR	81205	1	30-21-21 NSTA 166/135/R011	ALL
D30428 T	1	BACC10KC24 BACKSHELL	81205	1	30-21-21 */*/*	ALL
D30434	1	BACC63CN2842SN RCPT-CONDUCTIVE	81205	1	80-11-11 NSTA 162/135/L11	ALL
D30434 T	1	BACC10KC28 BACKSHELL-CONDUCTIVE	81205	1	80-11-11 / /	ALL
D30438	1	CA66286-45 RECP-	71468	1	24-21-11 NSTA 170/135/L11	ALL
D30452	1	BACC63CN1407S6 RECP-CONDUCTIVE CONNECTOR	81205	1	26-11-21 NSTA 172/134/R011	ALL
D30452 T	1	BACC10KC14 BACKSHELL	81205	1	26-11-21 */*/*	ALL
D30456	1	BACC63CN1407SN RECP-CONDUCTIVE CONNECTOR	81205	1	73-22-11 NSTA 163/136/R12	ALL
D30456 T	1	BACC10KC14 BACKSHELL	81205	1	73-22-11 / /	ALL

EQUIPMENT LIST

D280A103

Section D30400

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30460	1	BACC63CN2842S6 RECP-CONDUCTIVE CONNECTOR	81205	1	73-21-21 NSTA 186/136/R11	ALL
D30460 T	1	387AS020Z128A-D3-342 BACKSHELL	06324	1	73-21-21 //	YC001-YC007
D30460 T	1	440AH069ZM2838-745 BACKSHELL	06324	1	73-21-21 //	YC008-YM670
D30460 U	1	687-062-06 CLAMP/BAND	06324	1	73-21-21 //	YC001-YC007
D30460 U	1	202K153-25-225-0 STRAIGHT, LIPPED BOOT	06090	1	73-21-21 //	YC008-YM670
D30460 U	2	202K153-25-0 STRAIGHT, LIPPED BOOT	06090	1	73-21-21 //	YC008-YM670
D30460 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	1	73-21-21 //	YC008-YM670

EQUIPMENT LIST

D280A103

Section D30400

Page 4 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D37001J	1	BACC63CC12-12SN RECP	81205	1	23-70-11 AB0288/ /	YK907-YM670
D37001JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D37001P	1	BACC63CB12-12PN PLUG	81205	1	23-70-11 AB0288/ /	YK907-YM670
D37001PQ		BACC10KE12 BACKSHELL - 90 DEG.	81205	1	23-70-11 * / /	YK907-YM670
D37002J	1	BACC63CC12-12SN RECP	81205	1	23-70-11 AB0358/ /	YK907-YM670
D37002JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D37002P	1	BACC63CB12-12PN PLUG	81205	1	23-70-11 AB0358/ /	YK907-YM670
D37002PQ		BACC10KD12 BACKSHELL	81205	1	23-70-11 * / /	YK907-YM670
D37003J	1	BACC63CC12-12SN RECP	81205	1	23-70-11 326/291/R018	YK907-YM670
D37003JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D37003P	1	BACC63CB12-12PN PLUG	81205	1	23-70-11 326/291/R018	YK907-YM670
D37003PQ		BACC10KD12 BACKSHELL	81205	1	23-70-11 * / /	YK907-YM670

EQUIPMENT LIST

D280A103

Section D37000
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D39901	1	BACC63BP22C39S8 PLUG-CONDUCTIVE	81205	1	27-81-11 500I+15/181/L060	YC001-YL430
D39901	1	BACC63BP22C39S8 PLUG-CONDUCTIVE	81205	1	27-81-11 500D+15/181/L060	YM643-YM670
D39901 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	27-81-11 TBD/ /	YC001-YC030, YM643-YM670
D39901 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	27-81-11 */**	YC031-YL430
D39902	1	BACC63BP22C39S8 PLUG-CODUCTIVE	81205	1	27-81-21 500I+15/181/R059	YC001-YC007
D39902	1	BACC63BP22C39S8 PLUG-CODUCTIVE	81205	1	27-81-22 500I+15/181/R059	YC008-YL430
D39902	1	BACC63BP22C39S8 PLUG-CODUCTIVE	81205	1	27-81-21 500D+15/181/R059	YM643-YM670
D39902 T	1	BACC10KF22 BACKSHELL-CONDUCTIVE	81205	1	27-81-21 TBD/ /	ALL
D39903	1	BACC63BP22C39P8 PLUG-CONDUCTIVE	81205	1	27-81-12 IFSS-80/ /	ALL
D39903 T	1	BACC10KF22 BACKSHELL	81205	1	27-81-12 */**	ALL
D39904	1	BACC63BP22C39P8 PLUG-CONDUCTIVE	81205	1	27-81-11 IFSS 79/ /	ALL
D39904 T	1	BACC10KF22 BACKSHELL	81205	1	27-81-11 OFSS 79/ /	ALL
D39905	1	BACC63BP22C39S6 PLUG-CONDUCTIVE	81205	1	28-43-11 525/194/L067	ALL
D39905 T	1	BACC10KF22 BACKSHELL-CONDUCTIVE	81205	1	28-43-11 TBD/ /	ALL
D39906	1	BACC63BP22C39S6 PLUG-CONDUCTIVE	81205	1	28-41-11 525/194/R067	ALL
D39906 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	28-41-11 TBD/ /	YC001-YL430
D39906 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	28-41-11 */**	YM643-YM670

EQUIPMENT LIST

D280A103

Section D39900

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D39907	1	BACC63BP22C39P6 PLUG-CONDUCTIVE	81205	1	33-44-12 IFSS-93/ /	ALL
D39907 T	1	BACC10KF22 BACKSHELL	81205	1	33-44-12 IFSS-95/ /	ALL
D39908	1	BACC63BP22C39P6 PLUG-CONDUCTIVE	81205	1	28-44-11 IFSS 97/ /	ALL
D39908 T	1	BACC10KF22 BACKSHELL	81205	1	28-44-11 */*/	ALL
D39909	1	BACC63BP18C11S7 PLUG-CONDUCTIVE	81205	1	76-21-11 500I+5/188/L064	YC001-YL430
D39909	1	BACC63BP18C11S7 PLUG-CONDUCTIVE	81205	1	76-21-11 500D+5/188/L064	YM643-YM670
D39909 T	1	BACC10KE18 BACKSHELL-CONDUCTIVE	81205	1	76-21-11 TBD/ /	YC001-YC007
D39909 T	1	BACC10KE18 BACKSHELL-CONDUCTIVE	81205	1	76-21-11 */*/	YC008-YM670
D39910	1	BACC63BP18C11S7 PLUG-CONDUCTIVE	81205	1	76-21-21 500I+9/188/R064	YC001-YL430
D39910	1	BACC63BP18C11S7 PLUG-CONDUCTIVE	81205	1	76-21-21 500D+9/188/R064	YM643-YM670
D39910 T	1	BACC10KE18 BACKSHELL-CONDUCTIVE	81205	1	76-21-21 TBD/ /	ALL
D39911	1	BACC63BP18C11P7 PLUG-CONDUCTIVE	81205	1	76-21-11 IFSS-85/ /	YC001-YC030, YK901-YM670
D39911 T	1	BACC10KD18 BACKSHELL	81205	1	80-11-11 IFSS-85/ /	YC001-YC030, YK901-YM670
D39912	1	BACC63BP18C11P7 PLUG-CONDUCTIVE	81205	1	76-21-21 IFSS 85/ /	YC001-YC030, YK901-YM670
D39912 T	1	BACC10KD18 BACKSHELL	81205	1	80-11-11 IFSS 85/ /	YC001-YC030, YK901-YM670
D39913	1	BACC63BP22C39S8 PLUG-CONDUCTIVE	81205	1	28-41-11 525/187/L064	ALL
D39913 T	1	BACC10KF22 BACKSHELL-CONDUCTIVE	81205	1	28-41-11 */*/	ALL

EQUIPMENT LIST

D280A103

Section D39900

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D39914	1	BACC63BP22C39S8 PLUG-CONDUCTIVE	81205	1	28-41-11 525/186/R063	ALL
D39914 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	28-41-11 TBD/ /	ALL
D39915	1	BACC63BP22C39P8 PLUG-CONDUCTIVE CONNECTOR	81205	1	28-41-11 OFSS -90/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D39915 T	1	BACC10KE22 BACKSHELL	81205	1	28-41-11 OFSS -91/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D39916	1	BACC63BP22C39P8 PLUG-CONDUCTIVE CONNECTOR	81205	1	28-41-11 OFSS 90/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D39916 T	1	BACC10KE22 BACKSHELL	81205	1	28-41-11 OFSS 91/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D39917	1	BACC63BP22C39SN PLUG-CONDUCTIVE	81205	1	73-21-21 530/194/L066	ALL
D39917 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	73-21-21 TBD/ /	ALL
D39918	1	BACC63BP22C39SN PLUG-CONDUCTIVE	81205	1	73-21-21 530/194/R066	ALL
D39918 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	73-21-21 TBD/ /	ALL
D39919	1	BACC63BP22C39PN PLUG-CONDUCTIVE	81205	1	78-36-11 IFSS-100/ /	YC001-YC007
D39919	1	SEESCD282A730-001 PLUG-	81205	1	78-36-11 IFSS-100/ /	YC008-YC050
D39919	1	SEEDWG325-039-002-0 PLUG-	81205	1	78-36-11 IFSS-100/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D39900

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D39919 T	1	S280W603-113 BACKSHELL	81205	1	78-36-11 IFSS-100/ /	YC001-YC007
D39920	1	BACC63BP22C39PN PLUG-CONDUCTIVE	81205	1	73-24-12 IFSS 100/ /	YC001-YC007
D39920	1	SEESCD282A730-002 PLUG-	81205	1	73-24-12 IFSS 100/ /	YC008-YC050
D39920	1	SEEDWG325-039-102-0 PLUG-	81205	1	73-24-12 IFSS 100/ /	YK901-YM670
D39920 T	1	S280W603-113 BACKSHELL	81205	1	73-24-12 IFSS 100/ /	YC001-YC007
D39921	1	BACC63BP22C39S10 PLUG-CONDUCTIVE	81205	1	73-21-21 500I+5/180/L059	YC001-YL430
D39921	1	BACC63BP22C39S10 PLUG-CONDUCTIVE	81205	1	73-21-21 500D+5/180/L059	YM643-YM670
D39921 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	73-21-21 */**	ALL
D39922	1	BACC63BP22C39S10 PLUG-CONDUCTIVE	81205	1	73-21-21 500I+5/180/R060	YC001-YL430
D39922	1	BACC63BP22C39S10 PLUG-CONDUCTIVE	81205	1	73-21-21 500D+5/180/R060	YM643-YM670
D39922 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	73-21-21 TBD/ /	YC001-YL430
D39922 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	73-21-21 */**	YM643-YM670
D39923	1	BACC63BP22C39P10 PLUG-CONDUCTIVE	81205	1	73-21-21 IFSS-78/ /	YC001-YC007
D39923	1	SEESCD282A730-003 PLUG-	81205	1	73-21-21 IFSS-78/ /	YC008-YC050
D39923	1	SEEDWG325-104-601-0 PLUG-	81205	1	73-21-21 IFSS-78/ /	YK901-YM670
D39923 T	1	S280W603-213 BACKSHELL	81205	1	73-21-21 IFSS -78/ /	YC001-YC007
D39924	1	BACC63BP22C39P10 PLUG-CONDUCTIVE	81205	1	73-21-21 IFSS 78/ /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D39900

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D39924	1	SEESCD282A730-004 PLUG-	81205	1	73-21-21 IFSS 78/ /	YC008-YC050
D39924	1	SEEDWG325-104-701-0 PLUG-	81205	1	73-21-21 IFSS 78/ /	YK901-YM670
D39924 T	1	S280W603-213 BACKSHELL	81205	1	73-21-21 IFSS 78/ /	YC001-YC007
D39925	1	BACC63BP22C39S7 PLUG-CONDUCTIVE	81205	1	79-31-11 525/180/L059	ALL
D39925 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	79-31-11 TBD/ /	ALL
D39926	1	BACC63BP22C39S7 PLUG-CONDUCTIVE	81205	1	30-21-21 525/180/R060	ALL
D39926 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	30-21-21 TBD/ /	ALL
D39927	1	BACC63BP22C39P7 PLUG-CONDUCTIVE	81205	1	73-22-11 IFSS-89/ /	ALL
D39927 T	1	BACC10KD22 BACKSHELL	81205	1	73-22-11 IFSS-89/ /	ALL
D39928	1	BACC63BP22C39P7 PLUG-CONDUCTIVE	81205	1	73-22-11 IFSS 89/ /	ALL
D39928 T	1	BACC10KD22 BACKSHELL	81205	1	73-22-11 IFSS 89/ /	ALL
D39929	1	BACC63BP18C11SN PLUG-CONDUCTIVE	81205	1	26-11-11 500I+5/185/L063	YC001-YL430
D39929	1	BACC63BP18C11SN PLUG-CONDUCTIVE	81205	1	26-11-11 500D+5/185/L063	YM643-YM670
D39929 T	1	BACC10KE18 BACKSHELL-CONDUCTIVE	81205	1	26-11-11 TBD/ /	ALL
D39930	1	BACC63BP18C11SN PLUG-CONDUCTIVE	81205	1	26-12-11 500I+5/185/R063	YC001-YC030
D39930	1	BACC63BP18C11SN PLUG-CONDUCTIVE	81205	1	26-11-21 500I+5/185/R063	YC031-YL430
D39930	1	BACC63BP18C11SN PLUG-CONDUCTIVE	81205	1	26-12-11 500D+5/185/R063	YM643-YM670

EQUIPMENT LIST

D280A103

Section D39900

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D39930 T	1	BACC10KE18 BACKSHELL-CONDUCTIVE	81205	1	26-12-11 */**	ALL
D39931	1	BACC63BP18C11PN PLUG-CONDUCTIVE	81205	1	26-11-11 IFSS-81/ /	YC001-YC030, YK901-YM670
D39931 T	1	BACC10KF18 BACKSHELL	81205	1	26-11-11 IFSS-81/ /	YC001-YC030, YK901-YM670
D39932	1	BACC63BP18C11PN PLUG-CONDUCTIVE	81205	1	26-11-21 IFSS 81/ /	ALL
D39932 T	1	BACC10KF18 BACKSHELL	81205	1	73-22-11 IFSS 81/ /	YC001-YC030
D39932 T	1	BACC10KF18 BACKSHELL	81205	1	73-22-11 */**	YC031-YM670
D39933	1	BACC63BP22C39S9 PLUG-CONDUCTIVE	81205	1	24-24-11 500I+15/185/L063	YC001-YL430
D39933	1	BACC63BP22C39S9 PLUG-CONDUCTIVE	81205	1	24-24-11 500D+15/185/L063	YM643-YM670
D39933 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	24-24-11 / /	YC001-YC007
D39933 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	24-24-11 */**	YC008-YM670
D39934	1	BACC63BP22C39S9 PLUG-CONDUCTIVE	81205	1	24-21-21 500I+10/185/R062	YC001-YL430
D39934	1	BACC63BP22C39S9 PLUG-CONDUCTIVE	81205	1	24-21-21 500D+10/185/R062	YM643-YM670
D39934 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	24-21-21 TBD/ /	ALL
D39935	1	BACC63BP22C39P9 PLUG-CONDUCTIVE	81205	1	24-21-11 IFSS-87/ /	YC001-YC030, YK901-YM670
D39935 T	1	BACC10KF22 BACKSHELL	81205	1	77-12-21 IFSS-87/ /	YC001-YC030, YK901-YM670
D39936	1	BACC63BP22C39P9 PLUG-CONDUCTIVE	81205	1	24-21-21 IFSS 87/ /	YC001-YC030, YK901-YM670
D39936 T	1	BACC10KF22 BACKSHELL	81205	1	77-12-21 IFSS 87/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D39900

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D39937	1	BACC63BP22C39SN PLUG-CONDUCTIVE	81205	1	28-23-11 500I+10/178/L058	YC001-YL430
D39937	1	BACC63BP22C39SN PLUG-CONDUCTIVE	81205	1	28-23-11 500D+10/178/L058	YM643-YM670
D39937 T	1	BACC10KE22 BACKSHELL-CONDUCTIVE	81205	1	28-23-11 TBD/ /	ALL
D39938	1	BACC63BP22C39PN PLUG-CONDUCTIVE	81205	1	28-23-11 IFSS-84/ /	ALL
D39938 T	1	BACC10KF22 BACKSHELL	81205	1	28-23-11 IFSS-84/ /	YC001-YC030
D39938 T	1	BACC10KF22 BACKSHELL	81205	1	28-23-11 */*/*	YC031-YM670
D39939	1	BACC63BP22C39SN PLUG-CONDUCTIVE	81205	1	28-23-12 500I+10/178/R058	YC001-YL430
D39939	1	BACC63BP22C39SN PLUG-CONDUCTIVE	81205	1	28-23-12 500D+10/178/R058	YM643-YM670
D39939 T	1	BACC10KF22 BACKSHELL-CONDUCTIVE	81205	1	28-23-12 TBD/ /	ALL
D39940	1	BACC63BP22C39PN PLUG-CONDUCTIVE	81205	1	28-23-12 IFSS 84/ /	ALL
D39940 T	1	BACC10KF22 BACKSHELL	81205	1	28-23-12 */*/*	ALL

EQUIPMENT LIST

D280A103

Section D39900

Page 7 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40004J	1	BACC63BV22B19S6 RCPT-CONDUCTIVE	81205	1	32-41-11 722/201/R033	ALL
D40004JK	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */**	ALL
D40004P	1	BACC63BP22D19P6 PLUG-CONDUCTIVE	81205	1	32-41-11 722/201/R034	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40004PQ	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YK910, YK918, YL421- YL423, YM643
D40004PQ	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */**	YK911-YK912, YK919, YL401, YL424-YL429, YM645-YM652
D40005J	1	AMC02RA03W RCPT-	05574	1	23-31-04 392/293/R021	YC001-YL430
D40005J	1	AMC02RA03W RCPT-	05574	1	23-31-04 391/293/R021	YM643-YM670
D40005P	1	AMC02PA03W PLUG	05574	1	23-31-04 392/293/R021	ALL
D40006J	1	BACC63BV18F14S8 RCPT-CONDUCTIVE	81205	1	32-64-21 718/201/R033	YC001-YC030
D40006J	1	BACC63BV18H14S8 RCPT-CONDUCTIVE	81205	1	32-64-21 718/201/R033	YC031-YM670
D40006JK	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-64-21 */**	YC001-YC030
D40006JK	1	M85049-52S18A BACKSHELL-CONDUCTIVE	81205	1	32-64-21 */**	YC031-YM670
D40006P	1	BACC63BP18C14P8 PLUG- CONDUCTIVE	81205	1	32-64-21 718/201/R34	YC001-YC030
D40006P	1	BACC63BP18H14P8 PLUG- CONDUCTIVE	81205	1	32-64-21 718/201/R34	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D40000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40006PQ	1	BACC10KD18 BACKSHELL- CONDUCTIVE	81205	1	32-64-21 TBD/ /	YC001-YC030
D40006PQ	1	M85049-52S18A BACKSHELL- CONDUCTIVE	81205	1	32-64-21 TBD/ /	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40007J	1	AMC02RA03W RCPT-	05574	1	23-31-04 951/300/R016	YC001-YL430
D40007J	1	AMC02RA03W RCPT-	05574	1	23-31-04 954/297/R020	YM643-YM670
D40007P	1	AMC02PA03W PLUG	05574	1	23-31-04 954/297/R020	YC001-YC007, YM643-YM670
D40007P	1	AMC02PA03W PLUG	05574	1	23-31-04 952/300/R018	YC008-YL430
D40008J	1	BACC63BV12F12SN RECPT-	81205	1	26-21-11 726/199/L052	YC001-YC030
D40008J	1	BACC63BV12H12SN RECPT-	81205	1	26-21-11 726/199/L052	YC031-YM670
D40008JK	1	BACC10KE12 BACKSHELL	81205	1	26-21-11 726/200/L53	YC001-YC030
D40008JK	1	M85049-51S12A BACKSHELL	81205	1	26-21-11 726/200/L53	YC031-YM670
D40008P	1	BACC63BP12C12PN PLUG - ELEC DISC AFT	81205	1	26-21-11 726/199/L053	YC001-YC030
D40008P	1	BACC63BP12H12PN PLUG - ELEC DISC AFT	81205	1	26-21-11 726/199/L053	YC031-YL430
D40008P	1	BACC63BP12H12PN PLUG - ELEC DISC AFT	81205	1	26-21-11 725/200/L053	YM643-YM652
D40008PQ	1	BACC10KE12 BACKSHELL	81205	1	26-21-11 / /	YC001-YC030
D40008PQ	1	M85049-51S12A BACKSHELL	81205	1	26-21-11 / /	YC031-YM643
D40008PQ	1	M85049-51S12A BACKSHELL	81205	1	26-21-11 */*/	YM645-YM652

EQUIPMENT LIST

D280A103

Section D40000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40009J	1	AMC02RA03W RCPT-	05574	1	23-31-04 952/298/L15	YC001-YC030
D40009J	1	AMC02RA03W RCPT-	05574	1	23-31-04 956/300/L019	YK901-YM652
D40009P	1	AMC02PA03W PLUG	05574	1	23-31-04 952/298/L015	YC001-YL430
D40009P	1	AMC02PA03W PLUG	05574	1	23-31-04 956/299/L019	YM643-YM670
D40010J	1	BACC63BV12F12SN PLUG - ELEC DISC MID	81205	1	26-21-11 715/199/L051	YC001-YC030
D40010J	1	BACC63BV12H12SN RCPT - ELEC DISC MID	81205	1	26-21-11 715/199/L051	YC031-YM652
D40010JK	1	BACC10KD12 BACKSHELL	81205	1	26-21-11 / /	YC001-YC030
D40010JK	1	M85049-52S12A BACKSHELL	81205	1	26-21-11 / /	YC031-YM643
D40010JK	1	M85049-52S12A BACKSHELL	81205	1	26-21-11 */*/*	YM645-YM652
D40010P	1	BACC63BP12C12PN PLUG - ELEC DISC MID	81205	1	26-21-11 715/199/L053	YC001-YC030
D40010P	1	BACC63BP12H12PN PLUG - ELEC DISC MID	81205	1	26-21-11 715/199/L053	YC031-YM652
D40010PQ	1	BACC10KD12 BACKSHELL	81205	1	26-21-11 */*/*	YC001-YC030
D40010PQ	1	M85049-52S12A BACKSHELL	81205	1	26-21-11 */*/*	YC031-YM652
D40012J	1	MTCPQKT1R2PFDD RCPT-	06090	1	26-21-11 E002-02/ /	YC001-YC030, YK901-YM670
D40012P	1	MTCPQKT1P2SFDD PLUG	06090	1	26-21-11 E002-02/ /	YC001-YM652
D40014J	1	BACC63BV18F8SN RCPT-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS-769/ /	ALL
D40014JK	1	BACC10KF18 BACKSHELL	81205	1	33-43-11 OFSS-768/ /	ALL

EQUIPMENT LIST

D280A103

Section D40000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40014P	1	BACC63BP18C8PN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS 769/010/L004	YC001-YC030
D40014PQ	1	BACC10KE18 BACKSHELL-	81205	1	33-43-11 */**	YC001-YC030
D40016J	1	BACC63BV18F8SN RCPT-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS 769/ /	ALL
D40016JK	1	BACC10KF18 BACKSHELL	81205	1	33-43-11 OFSS 768/ /	ALL
D40016P	1	BACC63BP18C8PN PLUG-CONDUCTIVE CONNECTOR	81205	1	33-43-11 OFSS 769/010/R004	YC001-YC030
D40016PQ	1	BACC10KE18 BACKSHELL-	81205	1	33-43-11 */**	YC001-YC030
D40018J	1	S280W557-251 RCPT-	81205	1	33-22-31 370/290/R012	YC001-YC026
D40018J	1	BACC65AK251P RCPT-	81205	1	33-22-31 370/290/R012	YC028-YM670
D40018P	1	S280W557-151 PLUG-	81205	1	33-22-31 374/290/R013	YC001-YC026
D40018P	1	BACC65AJ151S PLUG-	81205	1	33-22-31 374/290/R013	YC028-YC030, YK901-YM670
D40019J	1	MTCPQKT2R22SGCB RECPT-CONDUCTIVE	06090	1	22-13-11 E001-01/ /	ALL
D40019P	1	MTCPQKT2P22PGCB PLUG-CONDUCTIVE	06090	1	22-13-11 E001-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40020J	1	S280W557-271 RCPT-	81205	1	33-29-11 336/292/L002	YC001-YC026
D40020J	1	BACC65AK271P RCPT-	81205	1	33-29-11 336/292/L002	YC028-YM670
D40020P	1	S280W557-171 PLUG-	81205	1	33-29-11 335/291/L002	YC001-YC026
D40020P	1	BACC65AJ171S PLUG-	81205	1	33-29-11 335/291/L002	YC028-YC030, YM643-YM670

EQUIPMENT LIST

D280A103

Section D40000

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40020P	1	BACC65AJ171S PLUG-	81205	1	33-29-11 335/292/000	YK901-YL430
D40024J	1	BACC63BV22F55SN RCPT-CONDUCTIVE	81205	1	27-53-21 ORSS/247/	YC001-YC007
D40024J	1	BACC63BV22F55PN RCPT-CONDUCTIVE	81205	1	27-53-21 ORSS/247/	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40024JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 / /	YC001-YC011
D40024JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/*	YC012-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40024P	1	BACC63BP22C55PN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/256/	YC001-YC007
D40024P	1	BACC63BP22C55SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS/256/	YC008-YM670
D40024PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/*	YC001-YC007, YC029-YM670
D40024PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 / /	YC008-YC028
D40025J	1	MTCPQKT1R2SGCB RCPT-CONDUCTIVE	06090	1	22-23-11 E003-02/ /	ALL
D40025P	1	MTCPQKT1P2PGCB PLUG- CONDUCTIVE	06090	1	22-23-11 E003-02/ /	ALL
D40026J	1	S280W557-271 RCPT-	81205	1	33-29-11 949/290/R016	YC001-YC026
D40026J	1	BACC65AK271P RCPT-	81205	1	33-29-11 949/290/R016	YC028-YM670
D40026P	1	S280W557-171 PLUG-	81205	1	33-29-11 949/290/R015	YC001-YC026
D40026P	1	BACC65AJ171S PLUG-	81205	1	33-29-11 949/290/R015	YC028-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40000

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40029J	1	MTCPQKT1R2SGDA RCPT-CONDUCTIVE	06090	1	27-24-11 E003-02/ /	ALL
D40029P	1	MTCPQKT1P2PGDA PLUG- CONDUCTIVE	06090	1	27-24-11 E003-02/ /	ALL
D40032J	1	S280W557-212 RCPT-	81205	1	23-31-11 949/290/L014	YC001-YC026
D40032J	1	BACC65AK212P RCPT-	81205	1	23-31-11 949/290/L014	YC028-YM670
D40032P	1	S280W557-112 PLUG - CABIN SERVICE JACK	81205	1	23-41-11 940/290/L014	YC001-YC026
D40032P	1	BACC65AJ112S PLUG - CABIN SERVICE JACK	81205	1	23-41-11 949/290/L013	YC028-YM670
D40034J	1	BACC63BV22F55SN RCPT-CONDUCTIVE	81205	1	27-53-21 ORSS/256/	YC001-YC007
D40034J	1	BACC63BV22F55PN RCPT-CONDUCTIVE	81205	1	27-53-21 ORSS/256/	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40034JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 / /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40034P	1	BACC63BP22C55PN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS 256/ /	YC001-YC007
D40034P	1	BACC63BP22C55SN PLUG-CONDUCTIVE	81205	1	27-53-21 ORSS 256/ /	YC008-YM670
D40034PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 */*/	YC001-YC007, YC029-YM670
D40034PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	27-53-21 / /	YC008-YC028
D40038J	1	S280W557-251 RCPT-	81205	1	33-22-22 906/290/L012	YC001-YC026
D40038J	1	BACC65AK251P RCPT-	81205	1	33-22-22 906/290/L012	YC028-YM670

EQUIPMENT LIST

D280A103

Section D40000

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40038P	1	S280W557-151 PLUG-	81205	1	33-22-22 905/289/L012	YC001-YC026
D40038P	1	BACC65AJ151S PLUG-	81205	1	33-22-22 905/289/L012	YC028-YC030, YK901-YM670
D40040J	1	S280W557-211 RCPT-	81205	1	33-51-12 317/290/L018	YC001-YC026
D40040J	1	BACC65AK211P RCPT-	81205	1	33-51-12 317/290/L018	YC028-YM670
D40040P	1	S280W557-111 PLUG-	81205	1	33-51-12 317/289/L018	YC001-YC026
D40040P	1	BACC65AJ111S PLUG-	81205	1	33-51-12 317/289/L018	YC028-YM670
D40042J	1	S280W557-211 RCPT-	81205	1	33-51-12 332/289/R026	YC001-YC026
D40042J	1	BACC65AK211P RCPT-	81205	1	33-51-12 332/289/R026	YC028-YM670
D40042P	1	S280W557-111 PLUG-	81205	1	33-51-12 331/289/R025	YC001-YC026
D40042P	1	BACC65AJ111S PLUG-	81205	1	33-51-12 331/289/R025	YC028-YM670
D40044J	1	S280W557-221 RCPT-	81205	1	33-51-14 982/298/L033	YC001-YC026
D40044J	1	BACC65AK221P RCPT-	81205	1	33-51-14 982/298/L033	YC028-YM670
D40044P	1	S280W557-121 PLUG-	81205	1	33-51-14 981/289/L033	YC001-YC026
D40044P	1	BACC65AJ121S PLUG-	81205	1	33-51-14 981/289/L033	YC028-YC030, YK901-YM652
D40046J	1	S280W557-221 RCPT-	81205	1	33-51-14 975/289/R035	YC001-YC026
D40046J	1	BACC65AK221P RCPT-	81205	1	33-51-14 975/289/R035	YC028-YM670
D40046P	1	S280W557-121 PLUG-	81205	1	33-51-14 974/289/R035	YC001-YC026

EQUIPMENT LIST

D280A103

Section D40000

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40046P	1	BACC65AJ121S PLUG-	81205	1	33-51-14 974/289/R035	YC028-YM670
D40047J	1	BACC63CC22-55P8 RCPT - CONDUCTIVE	81205	1	34-53-11 E001-04/ /	YC001-YC030, YK901-YM670
D40047JK	1	BACC10KD22 BACKSHELL	81205	1	34-53-11 */*/*	YC001-YC030, YK901-YM670
D40047P	1	BACC63CB22-55S8 PLUG - CONDUCTIVE	81205	1	34-53-11 E001-04/ /	ALL
D40047PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-53-11 E001-04/ /	YC001-YC050
D40047PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-53-11 */*/*	YK901-YM670
D40049J	1	BACC63CC12-12P6 RCPT - CONDUCTIVE	81205	1	34-22-11 E001-04/ /	YC001-YC030, YK901-YM670
D40049JK	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	34-22-11 E001-02/ /	YC001-YC030
D40049JK	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	34-22-11 */*/*	YK901-YM670
D40049P	1	BACC63CB12-12S6 PLUG - CONDUCTIVE	81205	1	34-22-11 E001-04/ /	ALL
D40049PQ	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	34-22-11 E001-04/ /	YC001-YC050
D40049PQ	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	34-22-11 */*/*	YK901-YM670
D40050J	1	BACC45FN14-12P9 RCPT-	81205	1	33-22-11 AB0340A/ /	YC001-YC030, YK901-YM670
D40050P	1	BACC45FT14-12S9 PLUG-	81205	1	33-22-11 341/296/L005	ALL
D40050PQ	1	BACC10JS14 BACKSHELL-	81205	1	33-21-11 */*/*	ALL
D40052J	1	S280W557-221 RCPT-	81205	1	33-22-21 454/301/L018	YC001-YC026
D40052J	1	BACC65AK221P RCPT-	81205	1	33-22-21 454/301/L018	YC028-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40000

Page 8

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40052JK	1	S280W557-1 MOUNTING TRACK-	81205	1	33-22-21 */**	YC001-YC026
D40052JK	1	BACT44E1S MOUNTING TRACK-	81205	1	33-22-21 */**	YC028-YC030, YK901-YM670
D40052P	1	S280W557-121 PLUG-	81205	1	33-22-11 454/301/L018	YC001-YC026
D40052P	1	BACC65AJ121S PLUG-	81205	1	33-22-11 454/301/L018	YC028-YC030, YK901-YM670
D40053J	1	MTCPQKT1R2PFAB RCPT-	06090	1	27-18-11 E003-02/ /	ALL
D40053P	1	MTCPQKT1P2SFAB PLUG-	06090	1	27-18-11 E003-02/ /	ALL
D40054J	1	BACC45FN12-12P RCPT-	81205	1	33-22-11 AB0340A/ /	YC001-YC030, YK901-YM670
D40054P	1	BACC45FT12-12S PLUG-	81205	1	33-29-11 333/295/L006	ALL
D40054PQ	1	BACC10JS12 BACKSHELL-	81205	1	33-29-11 */**	ALL
D40056J	1	BACC63CC18-31SN RCPT-CONDUCTIVE	81205	1	21-51-12 542/156/L028	YC001-YL430
D40056J	1	BACC63CC16-24SN RCPT-CONDUCTIVE	81205	1	21-51-12 542/156/L028	YM643-YM670
D40056JK	1	BACC10KE18 BACKSHELL-90 DEGREE	81205	1	24-51-14 */**	YC001-YL430
D40056JK	1	BACC10KE16 BACKSHELL-90 DEGREE	81205	1	24-51-14 */**	YM643-YM670
D40056P	1	BACC63CB18-31PN PLUG-CONDUCTIVE	81205	1	21-51-14 542/156/L027	YC001-YL430
D40056P	1	BACC63CB16-24PN PLUG-CONDUCTIVE	81205	1	21-51-14 542/156/L027	YM643-YM670
D40056PQ	1	BACC10KE18 BACKSHELL-90 DEGREE	81205	1	21-51-14 */**	YC001-YL430
D40056PQ	1	BACC10KE16 BACKSHELL-90 DEGREE	81205	1	21-51-14 */**	YM643-YM670

EQUIPMENT LIST

D280A103

Section D40000

Page 9

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40058J	1	BACC63CC18-31SN RCPT-CONDUCTIVE	81205	1	21-51-24 542/156/R028	YC001-YC030
D40058J	1	BACC63CC18-31SN RCPT-CONDUCTIVE	81205	1	21-51-24 542/158/R028	YC031-YL430
D40058J	1	BACC63CC16-24SN RCPT-CONDUCTIVE	81205	1	21-51-24 542/156/R028	YM643-YM670
D40058JK	1	BACC10KE18 BACKSHELL-90 DEGREE	81205	1	21-51-24 */*/*	YC001-YL430
D40058JK	1	BACC10KE16 BACKSHELL-90 DEGREE	81205	1	21-51-24 */*/*	YM643-YM670
D40058P	1	BACC63CB18-31PN PLUG-CONDUCTIVE	81205	1	21-51-24 542/156/R027	YC001-YL430
D40058P	1	BACC63CB16-24PN PLUG-CONDUCTIVE	81205	1	21-51-24 542/156/R027	YM643-YM670
D40058PQ	1	BACC10KE18 BACKSHELL-90 DEGREE	81205	1	21-51-24 */*/*	YC001-YL430
D40058PQ	1	BACC10KE16 BACKSHELL-90 DEGREE	81205	1	21-51-24 */*/*	YM643-YM670
D40060J	1	BACC63CN1610SN RECP-CONDUCTIVE	81205	1	26-11-31 1088/229/R014	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40060JK	1	BACC10KA16 BACKSHELL	81205	1	26-11-31 1088/ /	YC001-YC007
D40060JK	1	BACC10KA16 BACKSHELL	81205	1	26-11-31 1088/229/R14	YC008-YC011
D40060JK	1	BACC10KA16 BACKSHELL	81205	1	26-11-31 1088/229/R014	YC012-YC050
D40060JK	1	BACC10KA16 BACKSHELL	81205	1	26-11-31 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40060P	1	BACC63CM1610PN PLUG-	81205	1	26-11-31 1088/229/R014	ALL

EQUIPMENT LIST

D280A103

Section D40000

Page 10

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40060PQ	1	BACC10KB16 BACKSHELL-	81205	1	26-11-31 */*/*	ALL
D40062J	1	BACC63CN1407SN RCPT-	81205	1	26-11-31 1146/248/R012	ALL
D40062JK	1	BACC10KC14 BACKSHELL-	81205	1	26-11-31 */*/*	ALL
D40062P	1	BACC63CM1407PN PLUG-	81205	1	26-11-31 1146/248/R013	ALL
D40062PQ	1	287A4811-23 CONDUIT	81205	1	26-11-31 1146/248/R013	ALL
D40063J	1	MTCPQKT1R2SGBA RECPT-CONDUCTIVE	06090	1	2211XXX E001-01/ /	ALL
D40063P	1	MTCPQKT1P2PGBA PLUG-CONDUCTIVE	06090	1	22-11-18 E001-01/ /	YC001-YC030, YK901-YM670
D40064J	1	MTCPQKT1R2PGDC RCPT-	06090	1	21-31-23 E001-01/ /	YK901-YM670
D40064P	1	MTCPQKT1P2SGDC PLUG-	06090	1	21-31-23 E001-01/ /	YK901-YM670
D40066J	1	MTCPQKT1R2SGAC RCPT-	06090	1	21-31-23 E004-01/ /	ALL
D40066P	1	MTCPQKT1P2PGAC PLUG-	06090	1	21-31-23 E004-01/ /	ALL
D40068J	1	MTCPQKT2R26SGAC RCPT-	06090	1	30-41-12 E004-02/ /	ALL
D40068P	1	MTCPQKT2P26PGAC PLUG-CONDUCTIVE	06090	1	30-41-12 E004-02/ /	ALL
D40070J	1	MTCPQKT2R26SGBA RCPT-	06090	1	30-41-11 E002-01/ /	ALL
D40070P	1	MTCPQKT2P26PGBA PLUG-CONDUCTIVE	06090	1	30-41-12 E002-01/ /	ALL
D40072P	1	AMC02PA03B PLUG-	05574	1	33-25-31 361/293/R028	ALL
D40075J	1	MTCPQKT2R22PGBA RECP- CONDUCTIVE	06090	1	23-32-21 E008-01/ /	YK901-YK906, YL421-YM670

EQUIPMENT LIST

D280A103

Section D40000

Page 11

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40075J	1	MTCPQKT2R22PGBA RECP- CONDUCTIVE	06090	1	23-11-11 E008-01/ /	YK907-YL401
D40075P	1	MTCPQKT2P22SGBA PLUG - CONDUCTIVE	06090	1	23-11-11 E008-01/ /	YK901-YL430
D40075P	1	MTCPQKT2P22SGBA PLUG - CONDUCTIVE	06090	1	23-32-21 E008-01/ /	YM643-YM670
D40077J	1	MTCPQKT2R22PGBB RECP- CONDUCTIVE E08-01 SHELF	06090	1	23-11-21 E008-01/ /	YK907-YL401
D40077J	1	MTCPQKT2R22PGBB RCPT - CONDUCTIVE E8-1 SHELF	06090	1	23-11-21 E0800-01/ /	YL421-YL430
D40077P	1	MTCPQKT2P22SGBB PLUG	06090	1	23-11-21 E008-01/ /	YK907-YL430
D40081J	1	MTCPQKT1R2SGBB RCPT-	06090	1	34-41-11 J048-00/ /	YC004-YC006
D40081P	1	MTCPQKT1P2PGBB PLUG - CONDUCTIVE	06090	1	28-41-11 J048/ /	YC004-YC006
D40084J	1	BACC45FN16-10P8 RCPT-	81205	1	33-25-31 AB0340B/ /	ALL
D40084P	1	BACC45FT16-10S8 PLUG-	81205	1	33-25-31 AB0340B/ /	ALL
D40084PQ	1	BACC10JS16 BACKSHELL	81205	1	33-25-31 */*/*	ALL
D40086J	1	S280W557-211 RCPT-	81205	1	33-51-12 489/301/L018	YC001-YC026
D40086J	1	BACC65AK211P RCPT-	81205	1	33-51-12 489/301/L018	YC028-YC050
D40086P	1	S280W557-111 RCPT-	81205	1	33-51-12 490/301/L018	YC001-YC026
D40086P	1	BACC65AJ111S RCPT-	81205	1	33-51-12 490/301/L018	YC028-YC030
D40086PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-51-12 */*/*	YC001-YC026
D40086PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-51-12 */*/*	YC028-YC030

EQUIPMENT LIST

D280A103

Section D40000

Page 12

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40087J	1	MTCPQKT1R2SGBD RCPT-	06090	1	30-31-11 J048-00/ /	YC004-YM670
D40087P	1	MTCPQKT1P2PGBD PLUG-	06090	1	30-31-11 J048-00/ /	YC004-YM670
D40089J	1	MTCPQKT1R2SGCC RCPT-	06090	1	34-41-11 J048-00/ /	YC004-YC006
D40089P	1	MTCPQKT1P2PGCC PLUG	06090	1	34-41-11 J048-00/ /	YC004-YC006
D40090J	1	BACC45FN18-14P9 RCPT-	81205	1	26-14-11 AB0288/ /	YC001-YC030, YK901-YM670
D40090P	1	BACC45FT18-14S9 PLUG-	81205	1	26-14-11 AB0288/ /	ALL
D40090PQ	1	BACC10JS18 BACKSHELL-	81205	1	26-14-11 */**	YC001-YC007
D40090PQ	1	BACC10JS18 BACKSHELL-	81205	1	26-14-11 * **/**	YC008-YL430
D40090PQ	1	BACC10JS18 BACKSHEEO-	81205	1	26-14-11 */**	YM643-YM670
D40091J	1	MTCPQKT1R2SGCB RCPT-	06090	1	34-44-11 J048-00/ /	YC004-YC006
D40091P	1	MTCPQKT1P2PGCB PLUG	06090	1	34-44-11 J048-00/ /	YC004-YC006
D40095J	1	MTCPQKT1R2SFAD RCPT-	06090	1	34-51-41 J048-00/ /	YC004-YM670
D40095P	1	MTCPQKT1P2PGAD PLUG - CONDUCTIVE	06090	1	34-51-41 J048-00/ /	YC004-YC030, YK901-YM670
D40096J	1	BACC45FN16-24S RCPT-	81205	1	33-51-12 AB0340B/ /	ALL
D40096P	1	BACC45FT16-24P PLUG-	81205	1	33-51-12 AB0340B/ /	YC001-YC030, YK901-YM652
D40097J	1	MTCPQKT1R2SGBB RCPT-	06090	1	30-31-12 J046-00/ /	YC004-YC006
D40097J	1	MTCPQKT1R2SFBB RCPT-	06090	1	30-31-12 J046-00/ /	YC007-YM670

EQUIPMENT LIST

D280A103

Section D40000

Page 13

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40097P	1	MTCPQKT1P2PGBB PLUG-	06090	1	30-31-12 J046-00/ /	YC004-YM652
D40098J	1	S280W557-211 RCPT-	81205	1	33-51-13 608/295/R036	YC001-YC026
D40098J	1	BACC65AK211P RCPT-	81205	1	33-51-13 608/295/R036	YC028-YC030, YK901-YL430
D40098P	1	S280W557-111 PLUG-	81205	1	33-51-13 609/295/R036	YC001-YC026
D40098P	1	BACC65AJ111S PLUG-	81205	1	33-51-13 609/295/R036	YC028-YL430
D40098PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-51-13 */*/*	YC001-YC026
D40098PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-51-13 */*/*	YC028-YL430
D40099J	1	MTCPQKT1R2SGBC RCPT-	06090	1	34-41-11 J046-00/ /	YC004-YC006
D40099P	1	MTCPQKT1P2PGBC PLUG - CONDUCTIVE	06090	1	34-41-11 J046/ /	YC004-YC006

EQUIPMENT LIST

D280A103

Section D40000
Page 14 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40100J	1	S280W557-211 RCPT-	81205	1	33-51-14 958/301/L017	YC001-YC026
D40100J	1	BACC65AK211P RCPT-	81205	1	33-51-14 958/301/L017	YC028-YC030, YK901-YM652
D40100P	1	S280W557-111 PLUG-	81205	1	33-51-14 958/301/L017	YC001-YC026
D40100P	1	BACC65AJ111S PLUG-	81205	1	33-51-14 958/301/L017	YC028-YM670
D40100PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-51-14 */**	YC001-YC026
D40100PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-51-14 */**	YC028-YM670
D40101J	1	2431-84-1 RCPT - (TNC)	91836	1	31-62-12 E003-01/ /	YC001-YC030, YK901-YM670
D40101P	1	2435-81-1 PLUG - (TNC) STRAIGHT	91836	1	31-62-12 391/195/L012	ALL
D40102J	1	BACC63CC24-30P6 RCPT-	81205	1	33-23-11 AB0340A/ /	YC001-YC011
D40102J	1	BACC63CC24-30PN RCPT-	81205	1	33-23-11 AB0340A/ /	YC012-YM670
D40102P	1	BACC63CB24-30S6 PLUG-	81205	1	33-23-11 AB0340A/ /	YC001-YC011
D40102P	1	BACC63CB24-30SN PLUG-	81205	1	33-23-11 AB0340A/ /	YC012-YM670
D40102PQ	1	BACC10KD24 BACKSHELL-	81205	1	33-23-11 */**	ALL
D40103J	1	MTCPQKT1R2SFCA RCPT-	06090	1	34-53-31 J046-00/ /	YC004-YM670
D40103P	1	MTCPQKT1P2PGCA PLUG-	06090	1	34-53-21 J046-00/ /	YC004-YM670
D40104J	1	S280W557-251 RCPT-	81205	1	33-23-11 430/300/L017	YC001-YC026
D40104J	1	BACC65AK251P RCPT-	81205	1	33-23-11 430/300/L017	YC028-YM670

EQUIPMENT LIST

D280A103

Section D40100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40104P	1	S280W557-151 PLUG-	81205	1	33-23-11 430/300/L018	YC001-YC026
D40104P	1	BACC65AJ151S PLUG-	81205	1	33-23-11 430/300/L018	YC028-YM670
D40104PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-23-11 */**	YC001-YC026
D40104PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-23-11 */**	YC028-YM670
D40106J	1	S280W557-251 RCPT	81205	1	33-23-12 673/295/L035	YC001-YC026
D40106J	1	BACC65AK251P RCPT	81205	1	33-23-12 673/295/L035	YC028-YM670
D40106P	1	S280W557-151 PLUG-	81205	1	33-23-12 672/294/L035	YC001-YC026
D40106P	1	BACC65AJ151S PLUG-	81205	1	33-23-12 672/294/L035	YC028-YM670
D40106PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-23-12 */**	YC001-YC026
D40106PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-23-12 */**	YC028-YM670
D40107J	1	MTCPQKT1R2SGCB RCPT-	06090	1	34-44-11 J046-00/ /	YC004-YC006
D40107P	1	MTCPQKT1P2PGCB PLUG	06090	1	34-44-11 J046-00/ /	YC004-YC006
D40108J	1	BACC45FN18-14P8 RCPT-	81205	1	33-25-21 AB0340A/ /	ALL
D40108P	1	BACC45FT18-14S8 PLUG-	81205	1	33-25-21 AB0340A/ /	ALL
D40108PQ	1	BACC10JS18 BACKSHELL	81205	1	33-25-21 */**	ALL
D40110J	1	AMC02RA03W RCPT-	05574	1	33-22-21 445/295/L023	YC001-YC030, YK901-YM670
D40110P	1	AMC02PA03W PLUG-	05574	1	33-22-21 446/295/L023	ALL

EQUIPMENT LIST

D280A103

Section D40100

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40111J	1	BACC45FN12-12P7 RCPT	81205	1	23-11-11 E006-02/ /	YM643-YM670
D40111P	1	BACC45FT12-12S7 PLUG-	81205	1	23-11-11 E006-02/ /	YM643-YM670
D40112J	1	AMC02RA03W RCPT-	05574	1	33-22-21 674/294/L024	YC001-YC030
D40112P	1	AMC02PA03W PLUG-	05574	1	33-22-21 674/295/L24	YC001-YC050
D40113J	1	MTCPQKT2R22PGBB RCPT-CONDUCTIVE	06090	1	23-11-11 E006-02/ /	YM643-YM670
D40113P	1	MTCPQKT2P22SGBB PLUG - CONDUCTIVE	06090	1	23-11-11 E006-02/ /	YM643-YM670
D40114J	1	AMC02RA03W RCPT-	05574	1	33-22-21 879/295/L023	YC001-YC026
D40114J	1	AMC02RA03W RCPT-	05574	1	33-22-22 879/295/L023	YC028-YC030
D40114P	1	AMC02PA03W PLUG-	05574	1	33-22-22 880/295/L23	YC001-YC050
D40115J	1	MTCPQKT2R22PGAD RCPT - CONDUCTIVE	06090	1	23-11-21 E006-02/ /	YM643-YM670
D40115P	1	MTCPQKT2P22SGAD PLUG	06090	1	23-11-21 E006-02/ /	YM643-YM670
D40116J	1	S280W557-231 RCPT-	81205	1	33-25-22 900/298/L026	YC001-YC026
D40116J	1	BACC65AK231P RCPT-	81205	1	33-25-22 900/298/L026	YC028-YM670
D40116P	1	S280W557-131 PLUG-	81205	1	33-25-22 900/298/L026	YC001-YC026
D40116P	1	BACC65AJ131S PLUG-	81205	1	33-25-22 900/298/L026	YC028-YM670
D40116PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-25-22 */*/*	YC001-YC026
D40116PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-25-22 */*/*	YC028-YM670

EQUIPMENT LIST

D280A103

Section D40100

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40117J	1	MTCPQKT1R2SGAA RCPT-CONDUCTIVE	06090	1	23-11-11 E006-02/ /	YM643-YM670
D40117P	1	MTCPQKT1P2PGAA PLUG-CONDUCTIVE	06090	1	23-11-11 E006-02/ /	YM643-YM670
D40118J	1	BACC63CC14-12PN RCPT-CONDUCTIVE	81205	1	30-11-11 E002-02/ /	YC001-YC030, YK901-YM670
D40118P	1	BACC63CB14-12SN PLUG-CONDUCTIVE	81205	1	30-11-11 E002-02/ /	ALL
D40118PQ	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	30-11-11 TBD/ /	ALL
D40119J	1	MTCPQKT1R2SGAC RCPT - CONDUCTIVE	06090	1	23-11-21 E006-02/ /	YM643-YM670
D40119P	1	MTCPQKT1P2PGAC PLUG - CONDUCTIVE	06090	1	23-11-21 D006-02/ /	YM643-YM670
D40120J	1	MTCPQKT1R2PFDB RCPT-	06090	1	28-43-11 E001-01/ /	ALL
D40120P	1	MTCPQKT1P2SFDB PLUG-	06090	1	28-43-11 E001-01/ /	YC001-YL430
D40120P	1	MTCPQKT1P2SFDB PLUG-CONDUCTIVE	06090	1	28-43-11 E001-01/ /	YM643-YM670
D40121J	1	MTCPQKT2R26SFBD RCPT-	06090	1	23-11-11 E006-02/ /	YM643-YM670
D40121P	1	MTCPQKT2P26PFBD PLUG-	06090	1	23-11-11 E006-02/ /	YM643-YM670
D40122J	1	MTCPQKT2R22SFDB RCPT-	06090	1	27-81-11 E001-01/ /	ALL
D40122P	1	MTCPQKT2P22PFBD PLUG-CONDUCTIVE	06090	1	27-81-11 E001-01/ /	ALL
D40123J	1	121-39-9 JACK	91836	1	23-11-11 E006-02/ /	YM643-YM670
D40123P	1	125-95-9 PLUG-	91836	1	23-11-11 E006-02/ /	YM643-YM670
D40125J	1	MTCPQKT2R26SFBC RCPT-	06090	1	23-11-21 E006-02/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section D40100

Page 4

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40125P	1	MTCPQKT2P26PFBC PLUG-	06090	1	23-11-21 E006-02/ /	YM643-YM670
D40126J	1	MTCPQKT2R22PGBB RCPT-CONDUCTIVE	06090	1	79-31-11 E002-02/ /	YC001-YC030, YK901-YM670
D40126P	1	MTCPQKT2P22SGBB PLUG	06090	1	79-31-11 E002-02/186/L026	ALL
D40127J	1	2431-87-6 JACK	91836	1	23-11-21 E006-02/ /	YM643-YM670
D40127P	1	2435-84-6 PLUG-	91836	1	23-11-21 E006-02/ /	YM643-YM670
D40130J	1	MTCPQKT2R22SGAD RCPT-CONDUCTIVE	06090	1	77-31-11 E002-02/ /	YC001-YC030, YK901-YM670
D40130P	1	MTCPQKT2P22PGAD PLUG-CONDUCTIVE	06090	1	77-31-11 E002-02/ /	ALL
D40132J	1	MTCPQKT2R26PFAA RCPT-CONDUCTIVE	06090	1	24-11-11 E002-01/ /	ALL
D40132P	1	MTCPQKT2P26SGAA PLUG-CONDUCTIVE	06090	1	24-11-11 E002-01/ /	ALL
D40136J	1	MTCPQKT1R2SGBC RCPT-CONDUCTIVE	06090	1	80-11-11 E002-02/ /	YC001-YC030, YK901-YM670
D40136P	1	MTCPQKT1P2PGBC PLUG-CONDUCTIVE	06090	1	80-11-11 E002-02/ /	YC001-YC007, YM643-YM670
D40136P	1	MTCPQKT1P2PGBC PLUG-CONDUCTIVE	06090	1	80-11-11 AE0202A/ /	YC008-YL430
D40138J	1	MTCPQKT1R2SGBD RCPT-CONDUCTIVE	06090	1	73-22-11 E002-02/ /	YC001-YC030, YK901-YM670
D40138P	1	MTCPQKT1P2PGBD PLUG-CONDUCTIVE	06090	1	73-22-11 E002-02/ /	YC001-YC030, YM643-YM670
D40138P	1	MTCPQKT1P2PGBD PLUG-CONDUCTIVE	06090	1	73-22-11 AE0202A/ /	YC031-YL430
D40140J	1	MTCPQKT2R26PFCC RCPT-CONDUCTIVE	06090	1	24-21-21 E004-02/ /	ALL
D40140P	1	MTCPQKT2P26SGCC PLUG-CONDUCTIVE	06090	1	24-21-21 E004-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D40100

Page 5

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40142J	1	MTCPQKT1R2SFAD RCPT-	06090	1	27-31-21 E001-01/ /	ALL
D40142P	1	MTCPQKT1P2PFAD PLUG-CONDUCTIVE	06090	1	27-81-21 E001-01/ /	ALL
D40144J	1	MTCPQKT1R2SGAB RCPT-	06090	1	74-11-11 E004-01/ /	ALL
D40144P	1	MTCPQKT1P2PGAB PLUG-CONDUCTIVE	06090	1	74-11-11 E004-01/ /	YC001-YC030
D40144P	1	MTCPQKT1P2PGAB PLUG-CONDUCTIVE	06090	1	74-11-11 391/198/R39	YC031-YL430
D40144P	1	MTCPQKT1P2PGAB PLUG-CONDUCTIVE	06090	1	74-11-11 AE0401A/ /	YM643-YM670
D40147J	1	BACC63CC18-31P8 RCPT-CONDUCTIVE	81205	1	34-49-11 / /	YC001-YC002, YC007
D40147J	1	BACC63CC18-31P8 RCPT-CONDUCTIVE	81205	1	34-49-11 J022-00/ /	YC008-YC050, YM643-YM670
D40147J	1	BACC63CC18-31P8 RCPT-CONDUCTIVE	81205	1	34-41-11 J022-00/ /	YK901-YL430
D40147P	1	BACC63CB18-31S8 PLUG-CONDUCTIVE	81205	1	34-41-11 256/168/L029	YC001-YC002, YC007-YC030, YK901-YM670
D40147PQ	1	BACC10KE18 BACKSHELL-CONDUCTIVE	81205	1	34-41-11 / /	YC001-YC002, YC007-YC030, YK901-YM670
D40148J	1	S280W557-241 RCPT-	81205	1	38-41-11 853/294/L034	YC001-YC026
D40148J	1	BACC65AK241P RCPT-	81205	1	38-41-11 853/294/L034	YC028-YM670
D40148P	1	S280W557-141 PLUG-	81205	1	38-41-11 856/294/L034	YC001-YC026
D40148P	1	BACC65AJ141S PLUG-	81205	1	38-41-11 856/294/L034	YC028-YC030, YK901-YM670
D40148PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	38-41-11 */**	YC001-YC026

EQUIPMENT LIST

D280A103

Section D40100

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40148PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	38-41-11 */**	YC028-YC030, YK901-YM670
D40149J	1	MTCPQKT2R22PGDA RCPT - CONDUCTIVE	06090	1	34-41-11 E003-01/ /	YC001-YC002, YC007-YC030, YK901-YM670
D40149P	1	MTCPQKT2P22SGDA PLUG	06090	1	34-41-11 E003-01/ /	YC001-YC002, YC007-YC030, YK901-YM670
D40150J	1	S280W557-232 RCPT-	81205	1	38-32-12 860/289/L043	YC001-YC026
D40150J	1	BACC65AK232P RCPT-	81205	1	38-32-12 860/289/L043	YC028-YM670
D40150P	1	S280W557-132 PLUG-	81205	1	38-32-12 860/289/L043	YC001-YC026
D40150P	1	BACC65AJ132S PLUG-	81205	1	38-32-12 860/289/L043	YC028-YM670
D40150PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	38-32-12 */**	YC001-YC026
D40150PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	38-32-12 */**	YC028-YM670
D40152J	1	AMC02RA03W RCPT-	05574	1	38-32-12 849/188/L050	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40152P	1	AMC02PA03W PLUG-	05574	1	38-32-12 849/188/L050	ALL
D40156J	1	MTCPQKT2R22SGDB RCPT-	06090	1	73-21-21 E004-01/ /	ALL
D40156P	1	MTCPQKT2P22PGDB PLUG-CONDUCTIVE	06090	1	73-21-21 E004-01/ /	ALL
D40158J	1	MTCPQKT1R2SGBB RCPT-	06090	1	76-21-21 E004-01/ /	ALL
D40158P	1	MTCPQKT1P2PGBB PLUG-CONDUCTIVE	06090	1	76-21-21 E004-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D40100

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40160J	1	MTCPQKT2R22SFDB RCPT-	06090	1	28-21-12 E001-01/ /	ALL
D40160P	1	MTCPQKT2P22PFDB PLUG-CONDUCTIVE	06090	1	28-21-12 E001-01/ /	ALL
D40162J	1	MTCPQKT1R2SFDC RCPT-	06090	1	27-53-21 E001-01/ /	ALL
D40162P	1	MTCPQKT1P2PFDC PLUG-CONDUCTIVE	06090	1	27-53-21 E001-01/ /	ALL
D40164J	1	MTCPQKT2R26PGAC RCPT	06090	1	28-41-11 E004-02/ /	ALL
D40164P	1	MTCPQKT2P26SGAC PLUG-CONDUCTIVE	06090	1	28-41-11 E004-02/ /	ALL
D40169J	1	MTCPQKT1R2PFCA RCPT-	06090	1	23-34-02 E004-02/ /	YK901-YL401, YL422-YL430
D40169J	1	MTCPQKT1R2PGCA RCPT-	06090	1	23-34-02 E004-02/ /	YL421
D40169J	1	MTCPQKT1R2PFCA RCPT-	06090	1	28-23-11 E004-02/ /	YM643-YM670
D40169P	1	MTCPQKT1P2SGCA PLUG-CONDUCTIVE	06090	1	23-34-02 E004-02/ /	YK901-YK910, YK918-YM670
D40169P	1	MTCPQKT1P2SFCA PLUG-CONDUCTIVE	06090	1	23-34-02 E004-02/ /	YK911-YK917
D40170J	1	BACC45FN18-31P8 RCPT-	81205	1	33-51-11 AB0340A/ /	YC001-YC030, YK901-YM670
D40170P	1	BACC45FT18-31S8 PLUG-	81205	1	33-51-11 AB0340A/ /	YC001-YC004, YC008-YC030, YK901-YM670
D40170P	1	BACC45FT18-31S8 PLUG-	81205	1	33-51-11 339/296/L005	YC005-YC007
D40170PQ	1	BACC10JS18 BACKSHELL-	81205	1	33-51-11 */*/*	YC001-YC030, YK901-YM670
D40173J	1	MTCPQKT2R22PFAA RCPT-CONDUCTIVE	06090	1	23-34-01 E003-02/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D40100

Page 8

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40173P	1	MTCPQKT2P22SFAA PLUG	06090	1	23-34-01 E003-02/ /	YK901-YM670
D40180J	1	MTCPQKT1R2SFDD RCPT-	06090	1	27-53-21 E001-01/ /	ALL
D40180P	1	MTCPQKT1P2PFDD PLUG-CONDUCTIVE	06090	1	27-53-21 E001-01/ /	ALL
D40184J	1	AMC02RA03W RCPT-	05574	1	33-26-31 372/292/L022	YC001-YC030, YK901-YM670
D40184P	1	AMC02PA03W PLUG-	05574	1	33-26-31 376/292/L022	ALL
D40186J	1	AMC02RA03B RCPT-	05574	1	33-26-31 880/294/L023	YC001-YC030, YK901-YM670
D40186P	1	AMC02PA03B PLUG-	05574	1	33-26-31 880/294/L023	ALL
D40188J	1	BACC63BV14F12PN RECP-CONDUCTIVE	81205	1	27-38-11 1158/274/L026	ALL
D40188JK	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	27-38-11 */*/*	ALL
D40188P	1	BACC63BP14C12SN PLUG-CONDUCTIVE	81205	1	33-49-11 1157/273/L025	ALL
D40188PQ	1	BACC10KF14 BACKSHELL-CONDUCTIVE	81205	1	33-49-11 */*/*	ALL
D40190J	1	BACC63BV14F12PN RECP-CONDUCTIVE	81205	1	27-38-11 1158/274/R026	ALL
D40190JK	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	27-38-11 */*/*	ALL
D40190P	1	BACC63BP14C12SN PLUG-CONDUCTIVE	81205	1	33-49-11 1157/273/R025	ALL
D40190PQ	1	BACC10KF14 BACKSHELL-CONDUCTIVE	81205	1	33-49-11 */*/*	ALL
D40192J	1	BACC63BV16F24SN RCPT-CONDUCTIVE	81205	1	27-38-11 1034/300/L010	ALL
D40192JK	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	27-38-11 / /	ALL

EQUIPMENT LIST

D280A103

Section D40100

Page 9

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40192P	1	BACC63BP16C24PN PLUG-CONDUCTIVE	81205	1	27-38-11 1029/300/L10	ALL
D40192PQ	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	27-38-11 */*/*	ALL
D40194J	1	MTCPQKT2R22SFAA RCPT-	06090	1	27-28-11 E003-02/ /	ALL
D40194P	1	MTCPQKT2P22PFAA PLUG-	06090	1	27-28-11 E003-02/ /	ALL
D40196J	1	BACC45FN18-31P7 RCPT-	81205	1	33-51-11 AB0340A/ /	YC001-YC030, YK901-YM652
D40196P	1	BACC45FT18-31S7 PLUG-	81205	1	33-51-11 AB0340A/ /	ALL
D40196PQ	1	BACC10JS18 BACKSHELL-	81205	1	33-51-11 */*/*	ALL
D40198J	1	BACC45FN22-19S RCPT-	81205	1	33-25-11 P018-00/ /	ALL
D40198P	1	BACC45FT22-19P PLUG-CTR CEILING	81205	1	33-25-11 P018-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D40100
Page 10 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40201J	1	2431-84-1 RCPT - (TNC)	91836	1	31-62-22 E003-01/ /	YC001-YC030, YK901-YM670
D40201P	1	2435-81-1 RCPT - (TNC) STRAIGHT	91836	1	31-62-22 391/194/R010	ALL
D40202J	1	BACC63CC24-30P6 RCPT-	81205	1	33-23-21 AB0340B/ /	ALL
D40202P	1	BACC63CB24-30S6 PLUG-	81205	1	33-23-21 AB0340B/ /	ALL
D40202PQ	1	BACC10KD24 BACKSHELL-	81205	1	33-23-21 */*/*	ALL
D40204J	1	S280W557-251 RCPT-	81205	1	33-23-21 408/296/R026	YC001-YC026
D40204J	1	BACC65AK251P RCPT-	81205	1	33-23-21 408/296/R026	YC028-YM670
D40204P	1	S280W557-151 PLUG-	81205	1	33-23-21 408/296/R026	YC001-YC026
D40204P	1	BACC65AJ151S PLUG-	81205	1	33-23-21 408/296/R026	YC028-YM670
D40204PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-23-21 */*/*	YC001-YC026
D40204PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-23-21 */*/*	YC028-YM670
D40206J	1	S280W557-251 RCPT-	81205	1	33-23-22 675/295/R035	YC001-YC026
D40206J	1	BACC65AK251P RCPT-	81205	1	33-23-22 675/295/R035	YC028-YM670
D40206P	1	S280W557-151 PLUG-	81205	1	33-23-22 674/295/R036	YC001-YC026
D40206P	1	BACC65AJ151S PLUG-	81205	1	33-23-22 674/295/R036	YC028-YM670
D40206PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-23-22 */*/*	YC001-YC026
D40206PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-23-22 */*/*	YC028-YM670

EQUIPMENT LIST

D280A103

Section D40200

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40210J	1	S280W557-221 RCPT-	81205	1	33-21-12 414/296/R026	YC001-YC026
D40210J	1	BACC65AK221P RCPT-	81205	1	33-21-12 414/296/R026	YC028-YL430
D40210J	1	BACC65AK221P RCPT-	81205	1	33-21-12 415/296/R026	YM643-YM670
D40210JK	1	S280W557-1 MOUNTING TRACK-	81205	1	33-21-12 */*/*	YC001-YC026
D40210JK	1	BACT44E1S MOUNTING TRACK-	81205	1	33-21-12 */*/*	YC028-YM670
D40210P	1	S280W557-121 PLUG-	81205	1	33-21-12 415/297/R026	YC001-YC026
D40210P	1	BACC65AJ121S PLUG-	81205	1	33-21-12 415/297/R026	YC028-YM670
D40212J	1	AMC02RA03W RCPT-	05574	1	33-21-12 651/294/R24	YC001-YL430
D40212J	1	AMC02RA03W RCPT-	05574	1	33-21-12 651/296/R22	YM643-YM670
D40212P	1	AMC02PA03W PLUG-	05574	1	33-21-12 651/296/R022	YC001-YC026
D40212P	1	AMC02PA03W PLUG-	05574	1	33-21-12 652/295/R025	YC028-YL430
D40212P	1	AMC02PA03W PLUG-	05574	1	33-21-12 652/296/R022	YM643-YM670
D40214J	1	S280W557-221 RCPT-	81205	1	33-21-12 857/294/R035	YC001-YC026
D40214J	1	BACC65AK221P RCPT-	81205	1	33-21-12 857/294/R035	YC028-YL430
D40214J	1	BACC65AK221P RCPT-	81205	1	33-21-12 857/295/R036	YM643-YM670
D40214P	1	S280W557-121 PLUG-	81205	1	33-21-12 857/294/R035	YC001-YC026
D40214P	1	BACC65AJ121S PLUG-	81205	1	33-21-12 858/295/R036	YC028-YM670

EQUIPMENT LIST

D280A103

Section D40200

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40214PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-21-12 */*/*	YC001-YC026
D40214PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-21-12 */*/*	YC028-YM670
D40216J	1	BACC45FN14-7S6 RCPT-	81205	1	33-25-21 AB0340A/ /	ALL
D40216P	1	BACC45FT14-7P6 PLUG-	81205	1	33-25-21 AB0340A/ /	ALL
D40216PQ	1	BACC10JS14 BACKSHELL-	81205	1	33-25-21 */*/*	ALL
D40218J	1	BACC45FN24-43S7 RECP-	81205	1	33-25-11 P006-00/ /	ALL
D40218P	1	BACC45FT24-43P7 PLUG-	81205	1	33-25-11 P006-00/ /	ALL
D40220J	1	BACC45FN20-39S8 RCPT-	81205	1	33-26-31 P018-00/ /	ALL
D40220P	1	BACC45FT20-39P8 PLUG-	81205	1	33-26-31 P018-00/ /	ALL
D40222J	1	MTCPQKT2R22SFAB RCPT-	06090	1	27-23-11 E004-02/ /	ALL
D40222P	1	MTCPQKT2P22PFAB PLUG-	06090	1	27-23-11 E004-02/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40226J	1	BACC45FN14-12S8 RCPT-	81205	1	33-29-11 P006-00/ /	ALL
D40226P	1	BACC45FT14-12P8 PLUG-	81205	1	33-29-11 P006-00/ /	YC001-YC030, YK901-YM670
D40228J	1	MTCPQKT2R26SFAA RCPT	06090	1	33-42-11 E004-02/ /	ALL
D40228P	1	MTCPQKT2P26PFAA PLUG-	06090	1	33-42-11 E004-02/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D40200

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40236J	1	BACC63BV12F3SN RCPT-CONDUCTIVE	81205	1	27-31-11 1040/298/L006	YC008-YM670
D40236JK	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	27-31-11 / /	YC008-YM670
D40236P	1	BACC63BP12C3PN PLUG-CONDUCTIVE	81205	1	27-31-11 1040/298/L006	YC008-YM670
D40236PQ	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	27-31-11 / /	YC008-YM670
D40238J	1	MTCPQKT2R26SFCB RCPT-	06090	1	29-25-11 E004-02/ /	ALL
D40238P	1	MTCPQKT2P26PFCB PLUG-	06090	1	29-25-11 E004-02/ /	ALL
D40240J	1	MTCPQKT1R2SGDC RCPT-CONDUCTIVE	06090	1	21-31-22 E002-02/ /	YC001-YC030, YK901-YM670
D40240P	1	MTCPQKT1P2PGDC PLUG-	06090	1	21-31-22 E002-02/ /	ALL
D40242J	1	MTCPQKT1R2SGDB RCPT-	06090	1	21-31-22 E004-01/ /	ALL
D40242P	1	MTCPQKT1P2PGDB PLUG-	06090	1	21-31-22 E004-01/ /	ALL
D40244J	1	MTCPQKT1R2SFDA RCPT-	06090	1	21-51-14 E004-01/ /	ALL
D40244P	1	MTCPQKT1P2PFDA PLUG-	06090	1	21-51-14 E004-01/ /	ALL
D40246J	1	MTCPQKT1R2SGAA RCPT-CONDUCTIVE	06090	1	21-51-14 E002-02/ /	YC001-YC030, YK901-YM670
D40246P	1	MTCPQKT1P2PGAA PLUG-	06090	1	21-51-14 E002-02/ /	YC001-YC007, YM643-YM670
D40246P	1	MTCPQKT1P2PGAA PLUG-	06090	1	21-51-14 AE0202A/ /	YC008-YL430
D40248J	1	BACC63CC16-10S7 RCPT-	81205	1	27-53-12 727A+10/297/R027	ALL
D40248JK	1	BACC10KD16 BACKSHELL	81205	1	27-53-12 / /	ALL

EQUIPMENT LIST

D280A103

Section D40200

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40248P	1	BACC63CB16-10P7 PLUG-	81205	1	27-53-12 727A+10/298/R027	ALL
D40248PQ	1	BACC10KD16 BACKSHELL	81205	1	27-53-12 */**	ALL
D40250J	1	BACC63CC16-10S8 RCPT-	81205	1	27-41-12 727A+10/294/R036	ALL
D40250JK	1	BACC10KD16 BACKSHELL	81205	1	27-41-12 / /	ALL
D40250P	1	BACC63CB16-10P8 PLUG-	81205	1	27-53-12 727A+10/294/R036	ALL
D40250PQ	1	BACC10KD16 BACKSHELL	81205	1	27-41-12 */**	ALL
D40254J	1	MTCPQKT2R26SFBC RCPT-	06090	1	25-51-21 E002-01/ /	ALL
D40254P	1	MTCPQKT2P26PFBC PLUG-	06090	1	25-51-21 E002-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40256J	1	MTCPQKT2R26SFAD RCPT-	06090	1	25-51-21 E002-01/ /	ALL
D40256P	1	MTCPQKT2P26PFAD PLUG-	06090	1	25-51-21 E002-01/ /	ALL
D40258J	1	MTCPQKT2R26PFBD RCPT-	06090	1	28-23-11 E002-01/ /	ALL
D40258P	1	MTCPQKT2P26SFBD PLUG-	06090	1	28-23-11 E002-01/ /	ALL
D40260J	1	MTCPQKT1R2SFCD RCPT-	06090	1	25-51-21 E002-01/ /	ALL
D40260P	1	MTCPQKT1P2PFCD PLUG-	06090	1	25-51-21 E002-01/ /	YC001-YC030, YK901-YM670
D40262J	1	BACC63CC16-24S6 RCPT-	81205	1	27-53-11 727A+10/294/L035	ALL
D40262JK	1	BACC10KD16 BACKSHELL	81205	1	27-53-11 / /	ALL

EQUIPMENT LIST

D280A103

Section D40200
Page 5
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40262P	1	BACC63CB16-24P6 PLUG-	81205	1	27-53-11 727A+10/294/L035	ALL
D40262PQ	1	BACC10KD16 BACKSHELL	81205	1	27-53-11 */**	ALL
D40264J	1	BACC63CC16-10SN RCPT-	81205	1	29-25-11 727A+10/297/L027	ALL
D40264JK	1	BACC10KD16 BACKSHELL	81205	1	29-25-11 727B+10/297/L27	YC001-YL430
D40264JK	1	BACC10KD16 BACKSHELL	81205	1	29-25-11 / /	YM643-YM670
D40264P	1	BACC63CB16-10PN PLUG-	81205	1	29-25-11 727A+10/298/L027	ALL
D40264PQ	1	BACC10KD16 BACKSHELL	81205	1	29-25-11 */**	ALL
D40266J	1	BACC63CC16-10P9 RCPT-	81205	1	27-23-14 547/301/L019	ALL
D40266JK	1	BACC10KD16 BACKSHELL	81205	1	27-23-14 / /	ALL
D40266P	1	BACC63CB16-10S9 PLUG-	81205	1	27-23-14 547/301/L019	ALL
D40266PQ	1	BACC10KD16 BACKSHELL-	81205	1	27-23-14 / /	ALL
D40268J		BACC63BV22F55SN RCPT-CONDUCTIVE	81205	1	27-28-11 AB1080/ /	YC008-YC030
D40268J	1	BACC63BV14F15SN RCPT-CONDUCTIVE	81205	1	27-28-11 AB1080/ /	YC001-YC007
D40268J	1	BACC63BV22F55SN RCPT-CONDUCTIVE	81205	1	27-28-11 AB1080/ /	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40268JK		BACC10KD22 BACKSHELL-STRAIGHT	81205	1	27-28-11 */**	YC008-YC030
D40268JK	1	BACC10KD14 BACKSHELL-STRAIGHT	81205	1	27-28-11 */**	YC001-YC007

EQUIPMENT LIST

D280A103

Section D40200

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40268JK	1	BACC10KD22 BACKSHELL-STRAIGHT	81205	1	27-28-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40268P		BACC63BP22C55PN PLUG-CONDUCTIVE	81205	1	27-28-11 AB1080/ /	YC008-YC011, YC020-YC030
D40268P		BACC63BP22C55PN PLUG-CONDUCTIVE (SB 27-1253)	81205	1	27-28-11 AB1080/ /	YC012-YC019
D40268P	1	BACC63BP14C15PN PLUG-CONDUCTIVE	81205	1	27-28-11 AB1080/ /	YC001-YC007
D40268P	1	BACC63BP22C55PN PLUG-CONDUCTIVE	81205	1	27-28-11 AB1080/ /	YC031-YM670
D40268PQ		BACC10KF22 BACKSHELL-STRAIGHT	81205	1	27-28-11 / /	YC008-YC011, YC020-YC030
D40268PQ		BACC10KF22 BACKSHELL-90 DEGREE (SB 27-1253)	81205	1	27-28-11 / /	YC012-YC019
D40268PQ	1	BACC10KD14 BACKSHELL-STRAIGHT	81205	1	27-28-11 / /	YC001-YC007
D40268PQ	1	BACC10KF22 BACKSHELL-STRAIGHT	81205	1	27-28-11 */**	YC031-YM670
D40270J	1	S280W557-251 RCPT-	81205	1	33-27-22 937/300/L017	YC001-YC026
D40270J	1	BACC65AK251P RCPT-	81205	1	33-27-22 937/300/L017	YC028-YM670
D40270P	1	S280W557-151 PLUG-	81205	1	33-25-22 937/300/L017	YC001-YC026
D40270P	1	BACC65AJ151S PLUG-	81205	1	33-25-22 937/300/L017	YC028-YM670
D40270PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-25-22 */**	YC001-YC026
D40270PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-25-22 */**	YC028-YM670
D40272J	1	S280W557-251 RCPT-	81205	1	35-21-31 937/301/R017	YC001-YC026

EQUIPMENT LIST

D280A103

Section D40200

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40272J	1	BACC65AK251P RCPT-	81205	1	35-21-31 937/301/R017	YC028-YM670
D40272P	1	S280W557-151 PLUG-	81205	1	33-25-32 937/301/R017	YC001-YC026
D40272P	1	BACC65AJ151S PLUG-	81205	1	33-25-32 937/301/R017	YC028-YM670
D40272PQ	1	S280W557-1 MOUNTING TRACK-	81205	1	33-25-32 */**	YC001-YC026
D40272PQ	1	BACT44E1S MOUNTING TRACK-	81205	1	33-25-32 */**	YC028-YM670
D40276J	1	MTCPQKT1R2SGCB RCPT-CONDUCTIVE	06090	1	31-31-14 E003-02/ /	ALL
D40276P	1	MTCPQKT1P2PGCB PLUG-	06090	1	31-31-14 E003-02/ /	ALL
D40292J	1	BACC45FN18-31P8 RCPT-	81205	1	52-71-13 AB0340B/ /	ALL
D40292P	1	BACC45FT18-31S8 PLUG-	81205	1	52-71-13 AB0340B/ /	YC001-YC030, YK901-YM670
D40292PQ	1	BACC10JS18 BACKSHELL-	81205	1	52-71-13 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D40292PQ	1	BACC10JS18 BACKSHELL-	81205	1	52-71-13 */**	YK911-YK917
D40292PQ	1	BACC10JS18 BACKSHELL-	81205	1	52-71-13 */ /	YM643-YM649
D40296J	1	BACC63CC20-39P9 RCPT-CONDUCTIVE	81205	1	33-51-11 AB0340B/ /	ALL
D40296JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	33-51-11 */**	ALL
D40296P	1	BACC63CB20-39S9 PLUG-	81205	1	33-51-11 AB0340B/ /	ALL
D40296PQ	1	BACC10KD20 BACKSHELL-	81205	1	33-51-11 */**	ALL

EQUIPMENT LIST

D280A103

Section D40200

Page 8

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40298J	1	BACC45FN22-19S9 RCPT-	81205	1	33-25-11 P018-00/ /	ALL
D40298P	1	BACC45FT22-19P9 PLUG-CTR CEILING	81205	1	33-27-31 P018-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D40200
Page 9 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40301J	1	2431-84-5 RCPT - (TNC)	91836	1	31-62-12 E003-01/ /	YC001-YC030, YK901-YM670
D40301P	1	2435-81-5 PLUG - (TNC) STRAIGHT	91836	1	31-62-12 391/194/L010	ALL
D40302J	1	BACC45FN14-15S RCPT-	81205	1	32-44-11 AB0500DL/ /	YC001-YC030, YK901-YM670
D40302P	1	BACC45FT14-15P PLUG-	81205	1	32-44-11 AB0500DL/ /	ALL
D40312J	1	BACC45FN14-12S6 RCPT	81205	1	27-53-11 AB0500DL/ /	ALL
D40312P	1	BACC45FT14-12P6 PLUG-	81205	1	27-53-11 AB0500DL/ /	ALL
D40318J	1	BACC45FN16-24S6 RCPT-	81205	1	78-34-11 AB0500DL/ /	ALL
D40318P	1	BACC45FT16-24P6 PLUG-	81205	1	29-33-11 AB0500DL/ /	ALL
D40326J	1	BACC45FN18-8S7 RCPT-	81205	1	21-25-11 E004-01/ /	ALL
D40326P	1	BACC45FT18-8P7 PLUG	81205	1	21-25-11 E004-01/ /	ALL
D40326PQ	1	BACC10JS18 BACKSHELL-	81205	1	21-25-11 / /	YC001-YC026
D40326PQ	1	BACC10JS18 BACKSHELL-	81205	1	21-25-11 */*/*	YC028-YM670
D40328J	1	MTCPQKT1R2SFDC RCPT-	06090	1	21-51-14 E004-01/ /	ALL
D40328P	1	MTCPQKT1P2PFDC PLUG-	06090	1	21-51-14 E004-01/ /	YC001-YC030, YK901-YM670
D40330J	1	BACC45FN14-4S RCPT-	81205	1	21-25-11 E004-01/ /	ALL
D40330P	1	BACC45FT14-4P PLUG-	81205	1	21-25-11 E004-01/ /	ALL
D40330PQ	1	BACC10JS14 BACKSHELL-	81205	1	21-25-11 */*/*	ALL

EQUIPMENT LIST

D280A103

Section D40300

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40332J	1	BACC45FN16-24P RECEPTICAL	81205	1	47-30-11 E001-04/ /	YC031-YC050, YK906-YM670
D40332P	1	BACC45FT16-24S PLUG	81205	1	47-30-11 E001-04/ /	YK906-YM670
D40332PQ	1	BACC10GH16 BACKSHELL	81205	1	47-30-11 E001-04/ /	YK906-YM670
D40338J	1	MTCPQKT2R26PFCA RCPT-	06090	1	24-22-11 E004-02/ /	ALL
D40338P	1	MTCPQKT2P26SFCA PLUG-	06090	1	24-22-11 E004-02/ /	YC001-YC030, YK901-YM670
D40340J	1	MTCPQKT2R26PFAD RCPT-	06090	1	24-22-11 E002-01/ /	ALL
D40340P	1	MTCPQKT2P26SFAD PLUG-	06090	1	24-22-11 E002-01/ /	YC001-YC030, YK901-YM670
D40342J	1	MTCPQKT2R26PFAC RCPT-	06090	1	24-32-11 E002-01/ /	ALL
D40342P	1	MTCPQKT2P26SFAC PLUG-	06090	1	24-32-11 E002-01/ /	ALL
D40344J	1	BACC63CC18-31S8 RCPT-CONDUCTIVE	81205	1	29-32-11 E001-03/ /	ALL
D40344P	1	BACC63CB18-31P8 PLUG-	81205	1	26-11-21 E001-03/ /	ALL
D40344PQ	1	BACC10KD18 BACKSHELL	81205	1	26-11-21 */*/*	ALL
D40346J	1	BACC63CC22-55SN RCPT-	81205	1	26-11-11 E001-04/ /	ALL
D40346JK	1	BACC10KD22 BACKSHELL	81205	1	26-11-11 */*/*	ALL
D40346P	1	BACC63CB22-55PN PLUG - CONDUCTIVE	81205	1	26-11-11 E001-04/ /	ALL
D40346PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	26-11-11 E001-04/ /	YC001-YC050
D40346PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	26-11-11 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D40300

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40348J	1	MTCPQKT2R22PGCB RCPT-CONDUCTIVE	06090	1	26-11-11 E002-02/ /	YC001-YC030, YK901-YM670
D40348P	1	MTCPQKT2P22SGCB PLUG-	06090	1	26-11-11 E002-02/ /	ALL
D40349J	1	BACC45FN10-5S RCPT-	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40349P	1	BACC45FT10-5P PLUG	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40350J	1	MTCPQKT1R2SFBB RCPT-	06090	1	26-12-12 E003-02/ /	ALL
D40350P	1	MTCPQKT1P2PFBB PLUG-	06090	1	26-12-12 E003-02/ /	ALL
D40351J	1	BACC63CC12-12S6 RECP	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40351JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D40351P	1	BACC63CB12-12P6 PLUG	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40351PQ		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D40352J	1	BACC45FN22-32S9 RCPT-	81205	1	24-11-11 P006-00/ /	ALL
D40352P	1	BACC45FT22-32P9 PLUG-	81205	1	24-11-11 P006-00/ /	ALL
D40353J	1	BACC63CC12-12S8 RECP	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40353JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D40353P	1	BACC63CB12-12P8 PLUG	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40353PQ		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D40355J	1	BACC63CC12-12S9 RECP	81205	1	23-70-11 AB0358/ /	YK907-YM670

EQUIPMENT LIST

D280A103

Section D40300

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40355JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */*/	YK907-YM670
D40355P	1	BACC63CB12-12P9 PLUG	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40355PQ		BACC10KD12 BACKSHELL	81205	1	23-70-11 */*/	YK907-YM670
D40356J	1	MTCPQKT2R26PFDD RCPT-	06090	1	24-22-31 E004-02/ /	ALL
D40356P	1	MTCPQKT2P26SFDD PLUG-	06090	1	24-22-31 E004-02/ /	ALL
D40357J	1	BACC63CC12-12SN RECP	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40357JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */*/	YK907-YM670
D40357P	1	BACC63CB12-12PN PLUG	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40357PQ		BACC10KD12 BACKSHELL	81205	1	23-70-11 */*/	YK907-YM670
D40358J	1	MTCPQKT2R26PFAC RCPT-	06090	1	24-22-11 E002-01/ /	ALL
D40358P	1	MTCPQKT2P26SFAC PLUG-	06090	1	24-22-11 E002-01/ /	ALL
D40360J	1	BACC45FN20-25P7 RCPT-	81205	1	26-11-11 E002-02/ /	YC001-YC030, YK901-YM670
D40360P	1	BACC45FT20-25S7 PLUG-	81205	1	26-11-11 E002-02/ /	ALL
D40360PQ	1	BACC10GH20 BACKSHELL-SINGLE LEG, STRAIGHT	81205	1	26-11-11 E002-02/ /	YC001-YC030
D40360PQ	1	BACC10GH20 BACKSHELL-SINGLE LEG, STRAIGHT	81205	1	26-11-11 */*/	YC031-YM670
D40362J	1	MTCPQKT1R2PFBA RCPT-	06090	1	31-31-15 E003-02/ /	YC001-YC050
D40362J	1	MTCPQKT1R2PFBA RCPT-	06090	1	24-33-13 E003-02/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D40300

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40362P	1	MTCPQKT1P2SFBA PLUG-	06090	1	31-31-15 E003-02/ /	ALL
D40364J	1	MTCPQKT1R2PFCD RCPT-	06090	1	24-32-11 E001-01/ /	YC001-YC029
D40364J	1	MTCPQKT1R2PGCD RCPT-	06090	1	24-32-11 E001-01/ /	YC030-YM670
D40364P	1	MTCPQKT1P2SFCD PLUG-CONDUCTIVE	06090	1	24-32-11 E001-01/ /	YC001-YC030, YK901-YM670
D40365J	1	BACC63CC12-12S6 RECP	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40365JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D40365P	1	BACC63CB12-12P6 PLUG	81205	1	23-70-11 AB0358/ /	YK907-YM670
D40365PQ		BACC10KD12 BACKSHELL	81205	1	23-70-11 */**	YK907-YM670
D40368J	1	BACC45FN16-24S9 RCPT-	81205	1	24-23-51 P006-00/ /	ALL
D40368P	1	BACC45FT16-24P9 PLUG-	81205	1	24-32-11 P006-00/ /	YC001-YC030, YK901-YM670
D40370J	1	MTCPQKT2R26PFDB RCPT	06090	1	24-21-21 E004-02/ /	ALL
D40370P	1	MTCPQKT2P26SFDB PLUG-	06090	1	24-21-21 E004-02/ /	YC001-YC030, YK901-YM670
D40372J	1	BACC45FN14-12P RCPT-	81205	1	24-31-11 E002-01/ /	ALL
D40372P	1	BACC45FT14-12S PLUG-	81205	1	24-31-11 E002-01/ /	YC001-YC030, YK901-YM670
D40372PQ	1	BACC10GH14 BACKSHELL-SINGLE LEG, STRAIGHT	81205	1	24-31-11 E2-1 391/195/L37	YC001-YC030, YK901-YM670
D40378J	1	MTCPQKT2R22SGCB RCPT-	06090	1	21-25-11 E004-01/ /	ALL
D40378P	1	MTCPQKT2P22PGCB PLUG-	06090	1	21-25-11 E004-01/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40300

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40380J	1	MTCPQKT2R22SGBA RCPT-CONDUCTIVE	06090	1	33-32-11 E002-02/ /	YC001-YC030, YK901-YM670
D40380P	1	MTCPQKT2P22PGBA PLUG-	06090	1	33-32-11 E002-2/ /	YC001-YC030, YK901-YL430
D40380P	1	MTCPQKT2P22PGBA PLUG-	06090	1	33-32-11 AE0202A/ /	YM643-YM670
D40382J	1	MTCPQKT2R22PFCB RCPT	06090	1	24-22-21 E004-02/ /	ALL
D40382P	1	MTCPQKT2P22SFCB PLUG-	06090	1	24-22-21 E004-02/ /	ALL
D40386J	1	BACC45FN22-32S6 RCPT-	81205	1	78-36-21 P006-00/ /	ALL
D40386P	1	BACC45FT22-32P6 PLUG-	81205	1	78-36-21 P006-00/ /	ALL
D40387J	1	BACC63CC12-12S6 RECP	81205	1	23-70-11 AB0358/ /	YK901-YK906
D40387JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */ /	YK901-YK906
D40388J	1	MTCPQKT2R22SGCA RCPT-CONDUCTIVE	06090	1	27-62-11 E004-02/ /	ALL
D40388P	1	MTCPQKT2P22PGCA PLUG-	06090	1	27-62-11 E004-02/ /	ALL
D40389J	1	BACC63CC12-12SN RECP	81205	1	23-70-11 AB0358/ /	YK901-YK906
D40389JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */ /	YK901-YK906
D40390J	1	MTCPQKT2R22SGDD RCPT-	06090	1	73-21-31 E004-01/ /	ALL
D40390P	1	MTCPQKT2P22PGDD PLUG-	06090	1	73-21-31 E004-01/ /	ALL
D40391J	1	BACC63CC12-12S9 RECP	81205	1	23-70-11 AB0358/ /	YK901-YK906
D40391JK		BACC10KD12 BACKSHELL	81205	1	23-70-11 */ /	YK901-YK906

EQUIPMENT LIST

D280A103

Section D40300

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40392J	1	MTCPQKT2R22SGBC RCPT-CONDUCTIVE	06090	1	36-11-11 E003-02/ /	ALL
D40392P	1	MTCPQKT2P22PGBC PLUG-	06090	1	36-11-11 E003-02/ /	ALL
D40394J	1	MTCPQKT2R22SGCD RCPT - CONDUCTIVE	06090	1	36-11-11 E003-01/ /	YC001-YC030, YK901-YM670
D40394P	1	MTCPQKT2P22PGCD PLUG-	06090	1	36-11-11 E003-01/ /	ALL
D40396J	1	BACC45FN14-12S7 RCPT-	81205	1	24-32-11 P006-00/ /	ALL
D40396P	1	BACC45FT14-12P7 PLUG-	81205	1	24-32-11 P006-00/ /	YC001-YM652

EQUIPMENT LIST

D280A103

Section D40300

Page 7 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40400J	1	BACC45FN14-12S9 RCPT	81205	1	29-33-11 AB0500DR/ /	ALL
D40400P	1	BACC45FT14-12P9 PLUG-	81205	1	29-33-11 AB0500DR/ /	ALL
D40401J	1	2431-84-5 RCPT - (TNC)	91836	1	31-62-22 E003-01/ /	YC001-YC030, YK901-YM670
D40401P	1	2435-81-5 RCPT - (TNC) STRAIGHT	91836	1	31-62-22 391/195/R011	ALL
D40402J	1	BACC45FN16-24S RCPT	81205	1	27-41-12 AB0500DR/ /	ALL
D40402P	1	BACC45FT16-24P PLUG-	81205	1	27-41-12 AB0500DR/ /	ALL
D40404J	1	BACC45FN18-31P8 RCPT	81205	1	31-53-11 AB0500DR/ /	ALL
D40404P	1	BACC45FT18-31S8 PLUG-	81205	1	31-53-11 AB0500DR/ /	ALL
■ D40406J	1	BACC45FN14-15S RCPT-	81205	1	32-41-11 AB0500DR/ /	ALL
■ D40406P	1	BACC45FT14-15P PLUG-	81205	1	32-41-11 AB0500DR/ /	ALL
D40410J	1	BACC45FN16-24S7 RCPT-	81205	1	26-12-11 AB0500DR/ /	ALL
D40410P	1	BACC45FT16-24P7 PLUG-	81205	1	32-64-12 AB0500DR/ /	ALL
D40416J	1	BACC45FN14-12S8 RCPT	81205	1	27-23-11 AB0500DR/ /	ALL
D40416P	1	BACC45FT14-12P8 PLUG-	81205	1	27-23-11 AB0500DR/ /	ALL
D40426J	1	BACC63CC14-15P8 RCPT-	81205	1	49-52-31 E003-02/ /	ALL
D40426P	1	BACC63CB14-15S8 PLUG-CONDUCTIVE	81205	1	49-52-31 E003-02/ /	ALL
D40426PQ	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	49-52-31 / /	YC001-YC030, YK901-YK905

EQUIPMENT LIST

D280A103

Section D40400

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40426PQ	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	49-52-31 */**	YC031-YC050, YK906-YM670
D40428J	1	MTCPQKT2R26SFBD RCPT-CONDUCTIVE	06090	1	24-11-11 E002-01/ /	ALL
D40428P	1	MTCPQKT2P26PGBD PLUG-	06090	1	24-11-11 E002-01/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40430J	1	BACC63CC18-31S6 RCPT-CONDUCTIVE	81205	1	73-21-11 E002-02/ /	YC001-YC030, YK901-YM670
D40430P	1	BACC63CB18-31P6 PLUG-	81205	1	73-21-11 E2-2/ /	YC001-YC030
D40430P	1	BACC63CB18-31P6 PLUG-	81205	1	73-21-11 E002-02/ /	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40430PQ	1	BACC10KD18 BACKSHELL	81205	1	73-21-11 / /	YC001-YC030
D40430PQ	1	BACC10KD18 BACKSHELL	81205	1	73-21-11 */**	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40432J	1	MTCPQKT2R26PFBA RCPT	06090	1	27-41-11 E004-02/ /	ALL
D40432P	1	MTCPQKT2P26SFBA PLUG-	06090	1	27-41-11 E004-02/ /	ALL
D40444J	1	BACC45FN16-24S8 RCPT-	81205	1	21-25-11 P006-00/ /	ALL
D40444P	1	BACC45FT16-24P8 PLUG-	81205	1	21-25-11 P006-00/ /	YC001-YC030, YK901-YM670
D40446J	1	MTCPQKT1R2SGAD RCPT-CONDUCTIVE	06090	1	78-36-11 E003-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D40400

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40446P	1	MTCPQKT1P2PGAD PLUG-	06090	1	77-31-11 E003-02/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40448J	1	MTCPQKT2R22SGCA RCPT - CONDUCTIVE	06090	1	73-24-11 E003-01/ /	YC001-YC030, YK901-YM670
D40448P	1	MTCPQKT2P22PGCA PLUG-	06090	1	73-24-11 E003-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40450J	1	MTCPQKT2R22SGAC RCPT-CONDUCTIVE	06090	1	77-31-11 E002-02/ /	YC001-YC030, YK901-YM670
D40450P	1	MTCPQKT2P22PGAC PLUG-	06090	1	77-31-11 E2-2 391/185/L29	YC001-YC007
D40450P	1	MTCPQKT2P22PGAC PLUG-	06090	1	77-31-11 E2-2 391/185/L029	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40452J	1	MTCPQKT1R2SGBA RECPT-CONDUCTIVE	06090	1	29-23-11 E001-01/ /	ALL
D40452P	1	MTCPQKT1P2PGBA PLUG-CONDUCTIVE	06090	1	29-23-11 E001-01/ /	YC001-YC030, YK901-YM670
D40454J	1	MTCPQKT1R2SGAB RECPT-CONDUCTIVE	06090	1	31-53-11 E001-01/ /	ALL
D40454P	1	MTCPQKT1P2PGAB PLUG-CONDUCTIVE	06090	1	31-53-11 E001-01/ /	YC001-YC030, YK901-YM670
D40456J	1	MTCPQKT2R26SFCA RCPT-	06090	1	24-22-11 E002-02/ /	YC001-YC030, YK901-YM670
D40456P	1	MTCPQKT2P26PFCA PLUG-	06090	1	24-22-11 E2-2 390/186/L44	YC001-YC030, YM643-YM670
D40456P	1	MTCPQKT2P26PFCA PLUG-	06090	1	24-22-11 E002-02/ /	YK901-YL430
D40458J	1	MTCPQKT1R2SGAA RECPT - CONDUCTIVE	06090	1	34-49-11 E001-01/ /	YC001-YC002, YC007-YM670

EQUIPMENT LIST

D280A103

Section D40400

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40458P	1	MTCPQKT1P2PGAA PLUG-CONDUCTIVE	06090	1	34-49-11 E001-01/ /	YC001-YC002, YC007-YC030, YK901-YM670
D40460J	1	MTCPQKT1R2PGAA RCPT - CONDUCTIVE	06090	1	73-23-11 E003-01/ /	YC001-YC030, YK901-YM670
D40460P	1	MTCPQKT1P2SGAA PLUG-	06090	1	73-23-11 E003-01/ /	YC001-YC030, YK901-YM670
D40462J	1	MTCPQKT2R22PGBC RCPT-CONDUCTIVE	06090	1	29-23-11 E003-02/ /	ALL
D40462P	1	MTCPQKT2P22SGBC PLUG-	06090	1	29-23-11 E003-02/ /	YC001-YC030, YK901-YM670
D40464J	1	MTCPQKT1R2PFAB RCPT-	06090	1	27-81-31 E001-01/ /	YC001-YC030
D40464J	1	MTCPQKT1R2PGAB RCPT-CONDUCTIVE	06090	1	27-81-31 E001-01/ /	YK901-YM670
D40464P	1	MTCPQKT1P2SFAB PLUG-	06090	1	27-62-21 E001-01/ /	YC001-YC002, YC007
D40464P	1	MTCPQKT1P2SFAB PLUG-CONDUCTIVE	06090	1	27-62-21 E001-01/ /	YC003-YC006, YC008-YC030
D40464P	1	MTCPQKT1P2SGAB PLUG-CONDUCTIVE	06090	1	27-62-21 E001-01/ /	YK901-YM670
D40466J	1	BACC63CC22-55P7 RCPT-CONDUCTIVE	81205	1	27-62-11 E001-03/ /	ALL
D40466P	1	BACC63CB22-55S7 PLUG-CONDUCTIVE	81205	1	32-31-12 E001-03/ /	YC001-YC030, YK901-YM670
D40466PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D40466PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 */*/	YK911-YK917
D40466PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 */ /	YM643-YM649
D40468J	1	MTCPQKT1R2PFDB RCPT-	06090	1	27-32-21 E003-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D40400

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40468P	1	MTCPQKT1P2SFDB PLUG-	06090	1	27-32-21 E003-02/ /	YC001-YC030, YK901-YM670
D40470J	1	MTCPQKT1R2PFDC RCPT-	06090	1	29-23-11 E003-02/ /	YC001-YC003
D40470J	1	MTCPQKT1R2PGDC RCPT-CONDUCTIVE	06090	1	29-23-11 E003-02/ /	YC004-YM670
D40470P	1	MTCPQKT1P2SFDC PLUG-	06090	1	29-23-11 E003-02/ /	YC001-YC003
D40470P	1	MTCPQKT1P2SGDC PLUG-	06090	1	29-23-11 E003-02/ /	YC004-YC030, YK901-YM670
D40472J	1	MTCPQKT2R26PFAB RCPT	06090	1	24-22-21 E004-02/ /	ALL
D40472P	1	MTCPQKT2P26SFAB PLUG-	06090	1	24-22-21 E004-02/ /	YC001-YC030, YK901-YM670
D40474J	1	MTCPQKT1R2SGBB RCPT	06090	1	33-36-12 E004-02/ /	ALL
D40474P	1	MTCPQKT1P2PGBB PLUG-	06090	1	33-36-12 E004-02/ /	YC001-YC030, YK901-YM670
D40484J	1	MTCPQKT2R26PGDC RCPT	06090	1	27-23-11 E004-02/ /	ALL
D40484P	1	MTCPQKT2P26SGDC CONNECTOR - PLUG	06090	1	27-23-11 E004-02/ /	ALL
D40486J	1	MTCPQKT1R2PGCC RCPT-CONDUCTIVE	06090	1	78-32-61 E003-02/ /	ALL
D40486P	1	MTCPQKT1P2SFCC PLUG-	06090	1	78-32-61 E003-02/ /	ALL
D40488J	1	BACC63CC16-24P6 RCPT-CONDUCTIVE	81205	1	78-34-21 E001-03/ /	ALL
D40488P	1	BACC63CB16-24S6 PLUG-CONDUCTIVE	81205	1	32-41-11 E001-03/ /	ALL
D40488PQ	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 / /	YC001-YC030, YK901-YK905
D40488PQ	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */ */	YC031-YC050, YK906-YM670

EQUIPMENT LIST

D280A103

Section D40400

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40490J	1	BACC63CC16-24S7 RCPT-CONDUCTIVE	81205	1	78-34-21 E001-04/ /	ALL
D40490JK	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	78-34-21 / /	YC001-YC030, YK901-YK905
D40490JK	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	78-34-21 */*/	YC031-YC050, YK906-YM670
D40490P	1	BACC63CB16-24P7 PLUG - CONDUCTIVE	81205	1	78-34-21 E001-04/ /	ALL
D40490PQ	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	78-34-21 E001-04/ /	YC001-YC050
D40490PQ	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	78-34-21 */*/	YK901-YM670
D40496J	1	BACC63CC22-19P6 RCPT-	81205	1	24-11-11 E001-04/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40496JK	1	BACC10KD22 BACKSHELL,	81205	1	24-11-11 / /	YC001-YC007
D40496JK	1	BACC10KD22 BACKSHELL,	81205	1	24-11-11 */*/	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40496P	1	BACC63CB22-19S6 PLUG - CONDUCTIVE	81205	1	24-11-11 E001-04/ /	ALL
D40496PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	24-11-11 E001-04/ /	YC001-YC050
D40496PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	24-11-11 */*/	YK901-YM670
D40498J	1	BACC63CC18-31P9 RCPT-CONDUCTIVE	81205	1	32-41-11 E001-03/ /	ALL
D40498P	1	BACC63CB18-31S9 PLUG-CONDUCTIVE	81205	1	32-42-11 E001-03/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40400

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40498PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-42-11 */*/	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40400
Page 7 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40500J	1	BACC45FN24-43S8 RCPT-	81205	1	52-71-11 AB0500DL/ /	ALL
D40500P	1	BACC45FT24-43P8 PLUG-	81205	1	52-71-11 AB0500DL/ /	ALL
D40502J	1	BACC45FN14-12S9 RCPT-	81205	1	27-23-11 P006-00/ /	ALL
D40502P	1	BACC45FT14-12P9 PLUG-	81205	1	27-23-11 P006-00/ /	ALL
D40504J	1	BACC45FN14-12S RCPT	81205	1	33-42-11 P018-00/ /	ALL
D40504P	1	BACC45FT14-12P PLUG-	81205	1	33-42-11 P018-00/ /	ALL
D40506J	1	MTCPQKT2R26PFCC RCPT-	06090	1	27-53-11 E002-02/ /	YC001-YC030, YK901-YM670
D40506P	1	MTCPQKT2P26SFCC PLUG-	06090	1	27-53-11 E2-2 391/185/L44	YC001-YC022
D40506P	1	MTCPQKT2P26SFCC PLUG-	06090	1	27-53-11 AE0202A/ /	YC023-YM670
D40510J	1	MTCPQKT2R22PFBD RCPT-	06090	1	27-31-11 E001-01/ /	ALL
D40510P	1	MTCPQKT2P22SFBD PLUG-CONDUCTIVE	06090	1	27-81-11 E001-01/ /	YC001-YC030, YK901-YM670
D40512J	1	BACC45FN14-15S7 RCPT-	81205	1	21-31-22 P006-00/ /	ALL
D40512P	1	BACC45FT14-15P7 PLUG-	81205	1	21-31-22 P006-00/ /	YC001-YC030, YK901-YM670
D40514J	1	BACC45FN16-24S6 RCPT	81205	1	21-27-21 P018-00/ /	ALL
D40514P	1	BACC45FT16-24P6 PLUG-	81205	1	21-27-21 P018-00/ /	YC001-YC030, YK901-YM670
D40516J	1	MTCPQKT1R2PFAB RCPT -	06090	1	27-32-11 E003-01/ /	YC001-YC030, YK901-YM670
D40516P	1	MTCPQKT1P2SFAB PLUG-	06090	1	27-32-11 E003-01/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40500

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40518J	1	MTCPQKT2R22PGBB RCPT-	06090	1	30-41-11 E002-01/ /	ALL
D40518P	1	MTCPQKT2P22SGBB PLUG-	06090	1	24-11-11 E002-01/ /	YC001-YC030, YK901-YM670
D40520J	1	MTCPQKT2R22PGCD RCPT-	06090	1	21-31-11 E002-02/ /	YC001-YC030, YK901-YM670
D40520P	1	MTCPQKT2P22SGCD PLUG-	06090	1	21-31-11 E002-02/ /	YC001-YC030, YK901-YM670
D40522J	1	BACC45FN14-12S7 RCPT	81205	1	21-27-31 P018-00/ /	ALL
D40522P	1	BACC45FT14-12P7 PLUG-	81205	1	21-27-31 P018-00/ /	ALL
D40524J	1	BACC45FN14-12S8 RCPT	81205	1	30-42-11 P018-00/ /	ALL
D40524P	1	BACC45FT14-12P8 PLUG-	81205	1	30-42-11 P018-00/ /	ALL
D40526J	1	BACC45FN14-15S8 RCPT-	81205	1	27-23-11 P006-00/ /	ALL
D40526P	1	BACC45FT14-15P8 PLUG-	81205	1	27-23-11 P006-00/ /	ALL
D40528J	1	BACC45FN20-39P6 RCPT-	81205	1	27-23-11 P006-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40528P	1	BACC45FT20-39S6 PLUG-	81205	1	27-23-11 P006-00/ /	ALL
D40530J	1	MTCPQKT1R2PFAD RCPT-	06090	1	27-61-11 E004-01/ /	ALL
D40530P	1	MTCPQKT1P2SFAD PLUG-	06090	1	27-61-11 E004-01/ /	ALL
D40532J	1	BACC45FN16-24S6 RCPT-	81205	1	21-61-21 P006-00/ /	ALL
D40532P	1	BACC45FT16-24P6 PLUG-	81205	1	21-61-21 P006-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D40500

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40534J	1	MTCPQKT2R22PFCD RCPT-	06090	1	21-51-14 E004-01/ /	ALL
D40534P	1	MTCPQKT2P22SFCD PLUG-	06090	1	21-51-14 E004-01/ /	ALL
D40536J	1	BACC45FN18-31S8 RCPT-	81205	1	33-25-11 P006-00/ /	ALL
D40536P	1	BACC45FT18-31P8 PLUG-	81205	1	21-31-23 P006-00/ /	YC001-YC030, YK901-YM670
D40538J	1	BACC45FN12-12S9 RCPT	81205	1	21-31-11 P018-00/ /	ALL
D40538P	1	BACC45FT12-12P9 PLUG-	81205	1	21-31-11 P018-00/ /	YC001-YC030, YK901-YM670
D40540J	1	MTCPQKT2R22PFAA RCPT-	06090	1	33-51-11 E004-02/ /	ALL
D40540P	1	MTCPQKT2P22SFAA PLUG-	06090	1	33-51-11 E004-02/ /	YC001-YC030, YK901-YM670
D40542J	1	MTCPQKT2R22PGDC RCPT-	06090	1	21-31-11 E004-01/ /	ALL
D40542P	1	MTCPQKT2P22SGDC PLUG-	06090	1	21-31-11 E004-01/ /	YC001-YC030, YK901-YM670
D40544J	1	MTCPQKT1R2PFBA RCPT -	06090	1	27-32-21 E003-01/ /	YC001-YC030, YK901-YM670
D40544P	1	MTCPQKT1P2SFBA PLUG-	06090	1	27-32-21 E003-01/ /	YC001-YC030, YK901-YM670
D40550J	1	BACC45FN22-55S RCPT-	81205	1	21-31-11 P006-00/ /	ALL
D40550P	1	BACC45FT22-55P PLUG-	81205	1	21-31-11 P006-00/ /	YC001-YC030, YK901-YM670
D40554J	1	MTCPQKT2R22PGBC RCPT-	06090	1	21-31-11 E004-01/ /	YC001-YC007
D40554J	1	MTCPQKT1R2PGBC RCPT-	06090	1	21-31-11 E004-01/ /	YC008-YM670
D40554P	1	MTCPQKT2P22SGBC PLUG-	06090	1	21-31-11 E004-01/ /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D40500

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40554P	1	MTCPQKT1P2SGBC PLUG-	06090	1	21-31-11 E004-01/ /	YC008-YC030, YK901-YM670
D40556J	1	BACC45FN22-55S8 RCPT-	81205	1	24-31-11 E001-04/ /	YC001-YC030, YK901-YM670
D40556P	1	BACC45FT22-55P8 PLUG	81205	1	24-31-11 E001-04/ /	ALL
D40556PQ	1	BACC10JS22 CLAMP	81205	1	24-31-11 E001-04/ /	YC001-YC050
D40556PQ	1	BACC10JS22 CLAMP	81205	1	24-31-11 */*/*	YK901-YM670
D40558J	1	BACC45FN18-31S9 RCPT-	81205	1	21-25-11 P006-00/ /	ALL
D40558P	1	BACC45FT18-31P9 PLUG-	81205	1	21-25-11 P006-00/ /	ALL
D40560J	1	BACC45FN16-24S9 RCPT-	81205	1	28-21-11 E001-04/ /	ALL
D40560P	1	BACC45FT16-24P9 PLUG	81205	1	28-21-11 E001-04/ /	ALL
D40560PQ	1	BACC10JS16 CLAMP	81205	1	24-31-11 E001-04/ /	YC001-YC050
D40560PQ	1	BACC10JS16 CLAMP	81205	1	24-31-11 */*/*	YK901-YM670
D40562J	1	MTCPQKT2R22SFCC RCPT-	06090	1	21-25-11 E004-01/ /	ALL
D40562P	1	MTCPQKT2P22PFCC PLUG-	06090	1	21-25-11 E004-01/ /	ALL
D40564J	1	MTCPQKT2R22PFBA RCPT-	06090	1	24-22-31 E002-01/ /	ALL
D40564P	1	MTCPQKT2P22SFBA PLUG-CONDUCTIVE	06090	1	24-22-31 E002-01/ /	ALL
D40574J	1	BACC45FN18-8S8 RCPT-	81205	1	27-53-12 P006-00/ /	ALL
D40574P	1	BACC45FT18-8P8 PLUG-	81205	1	27-53-12 P006-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D40500

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40574PQ	1	BACC10JS18 BACKSHELL	81205	1	27-53-12 / /	ALL
D40576J	1	BACC45FN20-25S7 RCPT	81205	1	73-22-11 P018-00/ /	ALL
D40576P	1	BACC45FT20-25P7 PLUG-	81205	1	73-22-11 P018-00/ /	YC001-YC030, YK901-YM670
D40578J	1	BACC63CC20-39P8 RCPT - CONDUCTIVE	81205	1	29-23-11 P009-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40578JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	29-23-11 */*/	YC001-YC007
D40578JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	29-23-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40578P	1	BACC63CB20-39S8 PLUG-CONDUCTIVE	81205	1	29-23-11 P009-00/ /	YC001-YC030, YK901-YM670
D40578PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	29-23-11 */*/	YC001-YC002, YC004-YC030, YK901-YM670
D40578PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	29-23-11 / /	YC003
D40580J	1	BACC63CC12-12P6 RCPT - CONDUCTIVE	81205	1	32-64-12 P009-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D40580JK	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	32-64-12 */ /	YC001-YC030
D40580JK	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	32-64-12 */*/	YK901-YL429, YM643-YM652
D40580P	1	BACC63CB12-12S6 PLUG-CONDUCTIVE	81205	1	32-64-12 190/216/R5	YC001-YC003

EQUIPMENT LIST

D280A103

Section D40500

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40580P	1	BACC63CB12-12S6 PLUG-CONDUCTIVE	81205	1	32-64-12 190/216/R005	YC004-YC030, YK901-YM670
D40580PQ	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	32-64-12 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D40580PQ	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	32-64-12 */**	YK911-YK917
D40580PQ	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	32-64-12 */ /	YM643-YM649
D40582J	1	BACC45FN12-12S7 RCPT-	81205	1	33-17-11 P006-00/ /	ALL
D40582P	1	BACC45FT12-12P7 PLUG-	81205	1	33-17-11 P006-00/ /	ALL
D40582PQ	1	BACC10JS12 BACKSHELL-	81205	1	33-17-11 */**	ALL
D40584J	1	MTCPQKT1R2SFAB RCPT	06090	1	33-36-11 E004-02/ /	ALL
D40584P	1	MTCPQKT1P2PFAB PLUG-	06090	1	33-36-11 E004-02/ /	ALL
D40586J	1	MTCPQKT1R2SFAB RCPT-	06090	1	30-71-11 E002-02/ /	YC001-YC030, YK901-YM670
D40586P	1	MTCPQKT1P2PFAB PLUG-	06090	1	30-71-11 E2-2 391/L59/186	YC001-YC007
D40586P	1	MTCPQKT1P2PFAB PLUG-	06090	1	30-71-11 AE0202A/ /	YC008-YM670
D40594J	1	MTCPQKT1R2PFDD RCPT-	06090	1	78-36-11 E003-02/ /	ALL
D40594P	1	MTCPQKT1P2SFDD PLUG-	06090	1	78-36-11 E003-02/ /	YC001-YC030, YK901-YM670
D40596J	1	MTCPQKT1R2PFCA RCPT-	06090	1	22-23-11 E003-02/ /	ALL
D40596P	1	MTCPQKT1P2SFCA PLUG-CONDUCTIVE	06090	1	22-23-11 E003-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40500

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40598J	1	MTCPQKT1R2PFCB RCPT-	06090	1	24-22-11 E002-01/ /	ALL
D40598P	1	MTCPQKT1P2SFCB PLUG-CONDUCTIVE	06090	1	24-22-11 E002-01/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40500
Page 7 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40602J	1	BACC63CC18-8PN RCPT-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	ALL
D40602P	1	BACC63CB18-8SN PLUG-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	ALL
D40602PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-41-11 / /	ALL
D40610J	1	BACC63CC18-14P8 RCPT-CONDUCTIVE	81205	1	27-53-12 J004-00/ /	YC001-YC030
D40610J	1	BACC63CC18-14P7 RCPT-CONDUCTIVE	81205	1	27-53-12 J004-00/ /	YC031-YM670
D40610P	1	BACC63CB18-14S8 PLUG-CONDUCTIVE	81205	1	27-53-12 J004-00/ /	YC001-YC030
D40610P	1	BACC63CB18-14S7 PLUG-CONDUCTIVE	81205	1	27-53-12 J004-00/ /	YK901-YM670
D40610PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-53-12 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D40610PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-53-12 */*/	YK911-YK917
D40610PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-53-12 */ /	YM643-YM649
D40612J	1	BACC63CC18-14P9 RCPT-CONDUCTIVE	81205	1	33-45-11 J004-00/ /	YK901-YM670
D40612P	1	BACC63CB18-14S9 RCPT-CONDUCTIVE	81205	1	33-45-11 AJ0004/ /	YK901-YK906
D40612P	1	BACC63CB18-14S9 PLUG-CONDUCTIVE	81205	1	23-32-14 J004-00/ /	YK907-YM670
D40612PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	23-32-14 / /	YK911-YK917
D40612PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	23-32-14 */*/	YK918-YL401, YL427-YM649
D40612PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	23-32-14 / */	YM651-YM670

EQUIPMENT LIST

D280A103

Section D40600

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40614J	1	BACC63CC18-14P6 RCPT-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	YC001-YC030
D40614J	1	BACC63CC18-14P9 RCPT-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	YC031-YM670
D40614P	1	BACC63CB18-14S6 PLUG-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	YC001-YC030
D40614P	1	BACC63CB18-14S9 PLUG-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	YC031-YM670
D40614PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-41-11 / /	ALL
D40616J	1	BACC63CC18-8P7 RCPT-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	YC001-YC030
D40616J	1	BACC63CC18-8P8 RCPT-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	YC031-YM670
D40616P	1	BACC63CB18-8S7 PLUG-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	YC001-YC030
D40616P	1	BACC63CB18-8S8 PLUG-CONDUCTIVE	81205	1	27-41-11 J004-00/ /	YC031-YM670
D40616PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-41-11 / /	ALL
D40618J	1	MTCPQKT2R26PGAD CONNECTOR-RCPT	06090	1	24-33-11 E004-02/ /	ALL
D40618P	1	MTCPQKT2P26SGAD CONNECTOR - PLUG	06090	1	24-33-11 E004-02/ /	ALL
D40621J	1	BACC45FN12-12P RCPT	81205	1	23-11-21 E006-02/ /	YM643-YM670
D40621P	1	BACC45FT12A12S PLUG-	81205	1	23-31-06 E006-02/ /	YM643-YM652
D40623J	1	BACC63CC18-31SN RCTP-CONDUCTIVE	81205	1	34-21-21 P006-00/ /	ALL
D40623JK	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	34-21-21 P006-00/ /	ALL
D40623P	1	BACC63CB18-31PN PLUG-CONDUCTIVE	81205	1	34-21-21 P006-00/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40600

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40623PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	34-21-21 */**	YC001-YC030, YK901-YM670
D40625J	1	BACC63CC22-55S7 RCPT-CONDUCTIVE	81205	1	34-61-18 P006-00/ /	ALL
D40625JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	34-61-18 P061-00/ /	ALL
D40625P	1	BACC63CB22-55P7 PLUG-CONDUCTIVE	81205	1	34-61-18 P006-00/ /	ALL
D40625PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	34-61-18 */**	ALL
D40632J	1	BACC63CC18-31P9 RCPT-CONDUCTIVE	81205	1	32-31-12 J020-0B/ /	ALL
D40632P	1	BACC63CB18-31S9 PLUG-CONDUCTIVE	81205	1	32-31-12 J020-0B/ /	YC001-YC030, YK901-YM670
D40632PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 / /	YC001-YC030, YK901-YM670
D40634J	1	BACC63CC18-31PN RCPT-CONDUCTIVE	81205	1	27-62-11 J020-0B/ /	ALL
D40634P	1	BACC63CB18-31SN PLUG-CONDUCTIVE	81205	1	27-62-11 J020-0B/ /	ALL
D40634PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-62-11 / /	YC001-YC030, YK901-YK905
D40634PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-62-11 */**	YC031-YC050, YK906-YM670
D40636J	1	BACC63CC18-14P8 RCPT-CONDUCTIVE	81205	1	21-27-31 J020-0B/ /	ALL
D40636P	1	BACC63CB18-14S8 PLUG-CONDUCTIVE	81205	1	21-27-31 J020-0B/ /	YC001-YC026, YK901-YM670
D40636P	1	BACC63CB18-14S8 PLUG-CONDUCTIVE	81205	1	21-27-31 AJ020-0B/ /	YC028-YC030
D40636PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	21-27-31 / /	YC001-YC026
D40636PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	21-27-31 */**	YC028-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40600

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40638J	1	BACC63CC18-14P6 RCPT-CONDUCTIVE	81205	1	32-31-11 J020-0B/ /	ALL
D40638P	1	BACC63CB18-14S6 PLUG-CONDUCTIVE	81205	1	32-31-11 J020-0B/ /	ALL
D40638PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-31-11 / /	YC001-YC030, YK901-YK905
D40638PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-31-11 */**	YC031-YC050, YK906-YM670
D40640J	1	BACC63CC18-14P7 RCPT-CONDUCTIVE	81205	1	29-25-11 J020-0B/ /	ALL
D40640P	1	BACC63CB18-14S7 PLUG-CONDUCTIVE	81205	1	29-25-11 J020-0B/ /	ALL
D40640PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	29-25-11 / /	YC001-YC030, YK901-YK905
D40640PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	29-25-11 */**	YC031-YC050, YK906-YM670
D40642J	1	BACC63CC12-12PN RCPT-CONDUCTIVE	81205	1	73-24-12 J020-0B/ /	ALL
D40642P	1	BACC63CB12-12SN PLUG-CONDUCTIVE	81205	1	73-24-12 J020-00/ /	YC001-YC007, YK901-YL430
D40642P	1	BACC63CB12-12SN PLUG-CONDUCTIVE	81205	1	73-24-12 259/ /	YC008-YC026
D40642P	1	BACC63CB12-12SN PLUG-CONDUCTIVE	81205	1	73-24-12 AJ0020B/ /	YC028-YC030
D40642P	1	BACC63CB12-12SN PLUG-CONDUCTIVE	81205	1	73-24-12 AJ020-0B/ /	YM643-YM670
D40642PQ	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	73-24-12 / /	YC001-YC026
D40642PQ	1	BACC10KD12 BACKSHELL-CONDUCTIVE	81205	1	73-24-12 */**	YC028-YC030, YK901-YM670
D40646J	1	MTCPQKT1R2SFCA RCPT-	06090	1	26-16-21 E002-02/ /	YC001-YC030, YK901-YM670
D40646P	1	MTCPQKT1P2PFCA PLUG-	06090	1	26-16-21 E002-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D40600

Page 4

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40652J	1	BACC63BV14F15SN RECPT	81205	1	26-21-11 710/199/L052	YC001-YC030
D40652J	1	BACC63BV14H15SN RECPT	81205	1	26-21-11 710/199/L052	YC031-YM670
D40652JK	1	BACC10KD14 BACKSHELL	81205	1	26-21-11 TBD/ /	YC001-YC028
D40652JK	1	BACC10KD14 BACKSHELL	81205	1	26-21-11 */*/	YC029-YC030
D40652JK	1	M85049-52S14A BACKSHELL	81205	1	26-21-11 */*/	YC031-YM670
D40652P	1	BACC63BP14C15PN PLUG - ELEC DISC FWD	81205	1	26-21-11 710/199/L053	YC001-YC030
D40652P	1	BACC63BP14H15PN PLUG - ELEC DISC FWD	81205	1	26-21-11 710/199/L053	YC031-YM652
D40652PQ	1	BACC10KD14 BACKSHELL	81205	1	26-21-11 */*/	YC001-YC030
D40652PQ	1	M85049-52S14A BACKSHELL	81205	1	26-21-11 */*/	YC031-YM652
D40654J	1	BACC45FN12-12S RCPT-	81205	1	33-32-11 P006-00/ /	ALL
D40654P	1	BACC45FT12-12P PLUG-P6 LOWER	81205	1	33-32-11 P006-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40654PQ	1	BACC10JS12 BACKSHELL	81205	1	33-32-11 */*/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40656J	1	MTCPQKT1R2PFBA RCPT-	06090	1	26-21-11 E002-02/ /	YC001-YC030, YK901-YM670
D40656P	1	MTCPQKT1P2SFBA PLUG	06090	1	26-21-11 E2-2 391/186/L047	YC001-YC028
D40656P	1	MTCPQKT1P2SFBA PLUG	06090	1	26-21-11 AE0202A/ /	YC029-YM652

EQUIPMENT LIST

D280A103

Section D40600

Page 5

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40658J	1	BACC45FN18-31P6 RCPT-	81205	1	28-23-11 J004-00/ /	YC031-YM670
D40658P	1	BACC45FT18-31S6 PLUG-	81205	1	28-23-11 J004-00/ /	YK901-YM670
D40658PQ	1	BACC10GH18 BACKSHELL - STRAIGHT	81205	1	28-23-11 */**	YK901-YM670
D40666J	1	BACC63CC18-31P7 RCPT-CONDUCTIVE	81205	1	27-62-21 J022-00/ /	ALL
D40666P	1	BACC63CB18-31S7 PLUG-CONDUCTIVE	81205	1	27-62-21 256/180/L029	YC001-YC030, YM643-YM670
D40666P	1	BACC63CB18-31S7 PLUG-CONDUCTIVE	81205	1	27-62-21 J022-00/ /	YK901-YL430
D40666PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-62-21 / /	YC001-YC026
D40666PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-62-21 */**	YC028-YC030, YK901-YM670
D40668J	1	BACC63CC18-31PN RCPT-CONDUCTIVE	81205	1	29-23-11 J022-00/ /	YC001-YC030
D40668J	1	BACC63CC22-55PN RCPT-CONDUCTIVE	81205	1	29-23-11 J022-00/ /	YC031-YM670
D40668P	1	BACC63CB18-31SN PLUG-CONDUCTIVE	81205	1	29-23-11 256/174/L029	YC001-YC030
D40668P	1	BACC63CB22-55SN PLUG-CONDUCTIVE	81205	1	29-23-11 256/174/L029	YK901-YM670
D40668PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	29-23-11 / /	YC001-YC030
D40668PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	29-23-11 / /	YK901-YM670
D40670J	1	BACC63CC18-31P8 RCPT-CONDUCTIVE	81205	1	27-62-11 J022-00/ /	YC001-YC030
D40670J	1	BACC63CC22-55P8 RCPT-CONDUCTIVE	81205	1	27-62-11 J022-00/ /	YC031-YM670
D40670P	1	BACC63CB18-31S8 PLUG-CONDUCTIVE	81205	1	27-62-11 256/178/L029	YC001-YC030

EQUIPMENT LIST

D280A103

Section D40600

Page 6

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40670P	1	BACC63CB22-55S8 PLUG-CONDUCTIVE	81205	1	27-62-11 J022-00/ /	YK901-YL430
D40670P	1	BACC63CB22-55S8 PLUG-CONDUCTIVE	81205	1	27-62-11 256/178/L029	YM643-YM670
D40670PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	27-62-11 / /	YC001-YC026
D40670PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	27-62-11 */**	YC028-YC030
D40670PQ	1	BACC10KD22 BACKSHELL, CONDUCTIVE	81205	1	27-62-11 */**	YK901-YM670
D40672J	1	BACC63CC18-31P6 RCPT-CONDUCTIVE	81205	1	78-32-51 J22 256/181/L29	YC001-YC003
D40672J	1	BACC63CC18-31P6 RCPT-CONDUCTIVE	81205	1	78-32-51 J022-00/ /	YC004-YM670
D40672P	1	BACC63CB18-31S6 PLUG-CONDUCTIVE	81205	1	78-32-51 J22/ /	YC001-YC003
D40672P	1	BACC63CB18-31S6 PLUG-CONDUCTIVE	81205	1	78-32-51 J22-256/181/L29	YC004-YC007
D40672P	1	BACC63CB18-31S6 PLUG-CONDUCTIVE	81205	1	78-32-51 256/182/L029	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40672PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	78-32-51 / /	YC001-YC007
D40672PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	78-32-51 */**	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40674J	1	BACC63CC18-14P6 RCPT-CONDUCTIVE	81205	1	73-22-11 J022-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D40600

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40674P	1	BACC63CB18-14S6 PLUG-CONDUCTIVE	81205	1	73-22-11 256/172/L029	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40674PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	73-22-11 / /	YC001-YC030
D40674PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	73-22-11 */**	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40676J	1	BACC63CC18-14P9 RCPT-CONDUCTIVE	81205	1	29-25-11 J022-00/ /	ALL
D40676P	1	BACC63CB18-14S9 PLUG-CONDUCTIVE	81205	1	29-25-11 256/176/L029	YC001-YC030, YM643-YM670
D40676P	1	BACC63CB18-14S9 PLUG-CONDUCTIVE	81205	1	29-25-11 J022-00/ /	YK901-YL430
D40676PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	29-25-11 / /	YC001-YC026
D40676PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	29-25-11 */**	YC028-YC030, YK901-YM670
D40678J	1	BACC63CC18-8PN RCPT-CONDUCTIVE	81205	1	21-25-11 / /	YC001-YC007
D40678J	1	BACC63CC18-8PN RCPT-CONDUCTIVE	81205	1	21-25-11 J022-00/ /	YC008-YL430
D40678P	1	BACC63CB18-8SN PLUG-CONDUCTIVE	81205	1	21-25-11 256/184/L029	YC001-YC030
D40678P	1	BACC63CB18-8SN PLUG-CONDUCTIVE	81205	1	21-25-11 J022-00/ /	YK901-YL430
D40678PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	21-25-11 / /	YC001-YC026
D40678PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	21-25-11 */**	YC028-YC030, YK901-YL430
D40680J	1	BACC63CC18-31P7 RCPT-CONDUCTIVE	81205	1	34-49-11 J022-00/ /	YC001-YC002, YC007-YM670

EQUIPMENT LIST

D280A103

Section D40600

Page 8

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40680P	1	BACC63CB18-31S7 PLUG-CONDUCTIVE	81205	1	34-49-11 256/170/L029	YC001-YC002, YC007-YC030, YM643-YM670
D40680P	1	BACC63CB18-31S7 PLUG-CONDUCTIVE	81205	1	34-49-11 J022-00/ /	YK901-YL430
D40680PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	34-49-11 / /	YC001-YC002, YC007-YC026
D40680PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	34-49-11 */*/	YC028-YC030, YK901-YM670
D40686J	1	BACC63CC18-14P6 RCPT-CONDUCTIVE	81205	1	73-21-11 J023-00/ /	ALL
D40686P	1	BACC63CB18-14S6 PLUG-CONDUCTIVE	81205	1	73-21-11 J23/ /	YC001-YC030
D40686P	1	BACC63CB18-14S6 PLUG-CONDUCTIVE	81205	1	73-21-11 J023-00/ /	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40686PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	73-21-11 / /	YC001-YC030
D40686PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	73-21-11 */*/	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40688J	1	BACC63CC18-14P9 RCPT-CONDUCTIVE	81205	1	73-21-11 J023-00/ /	ALL
D40688P	1	BACC63CB18-14S9 PLUG-CONDUCTIVE	81205	1	24-11-11 J23/ /	YC001-YC007, YM643-YM652
D40688P	1	BACC63CB18-14S9 PLUG-CONDUCTIVE	801205	1	24-11-11 J23/ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429
D40688PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	24-11-11 / /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D40600

Page 9

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40688PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	24-11-11 */**	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40692J	1	BACC63CC18-14P8 RECP-	81205	1	78-34-21 J024-00/ /	ALL
D40692P	1	BACC63CB18-14S8 PLUG-CONDUCTIVE	81205	1	78-34-21 J024-00/ /	YC001-YC030, YK901-YK905, YL421-YL430
D40692P	1	BACC63CB18-14S8 PLUG-CONDUCTIVE	81205	1	78-34-21 256/173/R029	YC031-YC050, YK906-YL401, YM643-YM670
D40692PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	78-34-21 / /	YC001-YC030, YK901-YK905
D40692PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	78-34-21 */**	YC031-YC050, YK906-YM670
D40694J	1	BACC63CC18-31P6 RECP-	81205	1	32-31-12 J024-00/ /	ALL
D40694P	1	BACC63CB18-31S6 PLUG-CONDUCTIVE	81205	1	32-31-12 J024-00/ /	YC001-YC030, YK901-YM670
D40694PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 / /	YC001-YC030, YK901-YK910, YK918-YL430, YM651-YM670
D40694PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 */**	YK911-YK917
D40694PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 */ /	YM643-YM649
D40696J	1	BACC63CC18-31P6 RECP-	81205	1	73-21-11 J024-00/ /	ALL
D40696P	1	BACC63CB18-31S6 PLUG-	81205	1	73-21-11 AJ0024/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section D40600

Page 10

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40696P	1	BACC63CB18-31S6 PLUG-	81205	1	73-21-11 256/177/R029	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40696PQ	1	BACC10KD18 BACKSHELL-	81205	1	73-21-11 / /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40698J	1	BACC63CC18-31P7 RECP-	81205	1	29-23-11 J024-00/ /	YC001-YC030
D40698J	1	BACC63CC22-55P7 RECP-	81205	1	29-23-11 J024-00/ /	YK901-YM670
D40698P	1	BACC63CB18-31S7 PLUG-CONDUCTIVE	81205	1	29-23-11 J024-00/ /	YC001-YC030
D40698P	1	BACC63CB22-55S7 PLUG-CONDUCTIVE	81205	1	29-23-11 256/175/R029	YK901-YM670
D40698PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	29-23-11 / /	YC001-YC030
D40698PQ	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	29-23-11 / /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D40600
Page 11 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40700J	1	BACC63CC18-31P9 RECP-	81205	1	32-31-12 J024-00/ /	ALL
D40700P	1	BACC63CB18-31S9 PLUG-CONDUCTIVE	81205	1	32-31-12 J024-00/ /	YC001-YC030, YK901-YK905, YL421-YL430
D40700P	1	BACC63CB18-31S9 PLUG-CONDUCTIVE	81205	1	32-31-12 256/171/R029	YC031-YC050, YK906-YL401, YM643-YM670
D40700PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 / /	YC001-YC030, YK901-YK905
D40700PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-31-12 */*/*	YC031-YC050, YK906-YM670
D40702J	1	BACC63CC18-31PN RECP-	81205	1	32-44-11 J024-00/ /	ALL
D40702P	1	BACC63CB18-31SN PLUG-CONDUCTIVE	81205	1	32-44-11 J024-00/ /	YC001-YC030, YK901-YK905, YL421-YL430
D40702P	1	BACC63CB18-31SN PLUG-CONDUCTIVE	81205	1	32-44-11 256/169/R029	YC031-YC050, YK906-YL401, YM643-YM670
D40702PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	32-44-11 / /	YC001-YC030, YK901-YK905
D40702PQ	1	BACC10KD18 BACKSHELL, CONDUCTIVE	81205	1	32-44-11 */*/*	YC031-YC050, YK906-YM670
D40712J	1	BACC45FN20-25S9 RCPT	81205	1	30-41-12 E004-02/ /	ALL
D40712P	1	BACC45FT20-25P9 PLUG-	81205	1	30-41-12 E004-02/ /	ALL
D40712PQ	1	BACC10JS20 BACKSHELL-	81205	1	30-41-12 / /	YC001-YC026
D40712PQ	1	BACC10JS20 BACKSHELL-	81205	1	30-41-12 */*/*	YC028-YM670
D40714J	1	MTCPQKT2R26PFCB RCPT-CONDUCTIVE	06090	1	28-23-11 E004-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D40700

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40714P	1	MTCPQKT2P26SGCB PLUG	06090	1	28-23-12 E004-02/ /	ALL
D40718J	1	MTCPQKT2R26PFAB RCPT-CONDUCTIVE	06090	1	28-21-11 E002-01/ /	ALL
D40718P	1	MTCPQKT2P26SGAB PLUG-CONDUCTIVE	06090	1	28-21-11 E002-01/ /	ALL
D40720J	1	MTCPQKT2R26PFCD RCPT-CONDUCTIVE	06090	1	24-21-21 E004-02/ /	ALL
D40720P	1	MTCPQKT2P26SGCD PLUG-CONDUCTIVE	06090	1	24-21-21 E004-02/ /	ALL
D40724J	1	MTCPQKT2R22PGBC RCPT-CONDUCTIVE	06090	1	78-36-11 E002-02/ /	YC001-YC030, YK901-YM670
D40724P	1	MTCPQKT2P22SGBC PLUG-	06090	1	78-36-11 E002-02/ /	YC001-YC030, YK901-YM670
D40726J	1	MTCPQKT1R2SGAC RCPT-CONDUCTIVE	06090	1	77-31-11 E003-02/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40726P	1	MTCPQKT1P2PGAC PLUG	06090	1	77-31-11 E003-02/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40728J	1	BACC63CC16-24S6 RCPT	81205	1	77-12-11 AB0405/ /	ALL
D40728JK	1	BACC10KD16 BACKSHELL	81205	1	77-12-11 TBD/ /	ALL
D40728P	1	BACC63CB16-24P6 PLUG	81205	1	77-12-11 AB0405/ /	ALL
D40728PQ	1	BACC10KD16 BACKSHELL	81205	1	77-12-11 TBD/ /	ALL
D40730J	1	BACC63CC16-24S7 RCPT	81205	1	77-12-11 AB0405/ /	ALL
D40730JK	1	BACC10KD16 BACKSHELL	81205	1	77-12-11 TBD/ /	ALL

EQUIPMENT LIST

D280A103

Section D40700

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40730P	1	BACC63CB16-24P7 PLUG	81205	1	77-12-11 AB0405/ /	ALL
D40730PQ	1	BACC10KD16 BACKSHELL	81205	1	77-12-11 TBD/ /	ALL
D40732J	1	MTCPQKT2R22PGDB RCPT - CONDUCTIVE	06090	1	77-12-11 E003-01/ /	YC001-YC030, YK901-YM670
D40732P	1	MTCPQKT2P22SGDB PLUG	06090	1	77-12-11 E003-01/ /	ALL
D40734J	1	BACC63CC16-24S6 RCPT	81205	1	77-31-11 424/293/L032	ALL
D40734JK	1	BACC10KD16 BACKSHELL	81205	1	77-31-11 TBD/ /	ALL
D40734P	1	BACC63CB16-24P6 PLUG	81205	1	79-31-11 425/293/L034	ALL
D40734PQ	1	BACC10KD16 BACKSHELL	81205	1	79-31-11 425/293/L034	YC001-YC007
D40734PQ	1	BACC10KD16 BACKSHELL	81205	1	79-31-11 */*/*	YC008-YM670
D40736J	1	BACC63CC16-24S7 RCPT	81205	1	79-31-11 424/293/L032	ALL
D40736JK	1	BACC10KD16 BACKSHELL	81205	1	79-31-11 */*/*	ALL
D40736P	1	BACC63CB16-24P7 PLUG	81205	1	79-31-11 424/293/L032	ALL
D40736PQ	1	BACC10KD16 BACKSHELL	81205	1	79-31-11 424/293/L032	YC001-YC007
D40736PQ	1	BACC10KD16 BACKSHELL	81205	1	79-31-11 */*/*	YC008-YM670
D40738J	1	BACC63CC20-41SN RCPT - CONDUCTIVE	81205	1	31-52-11 P007-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40738JK	1	BACC10KF20 BACKSHELL - CONDUCTIVE - 45	81205	1	33-11-11 */*/*	YC001-YC007

EQUIPMENT LIST

D280A103

Section D40700

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40738JK	1	BACC10KF20 BACKSHELL - CONDUCTIVE - 45	81205	1	33-11-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40738P	1	BACC45FT20-41P PLUG-	81205	1	31-52-11 P007-00/ /	YC001-YC030, YK901-YM670
D40738PQ	1	BACC10JC20 BACKSHELL-	81205	1	31-52-11 */ */	YC001-YC030, YK901-YM670
D40740J	1	BACC63CC20-41SN RCPT - CONDUCTIVE	81205	1	31-52-11 P007-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D40740JK	1	BACC10KF20 BACKSHELL - CONDUCTIVE - 45	81205	1	31-52-11 */ /	YC001-YC030
D40740JK	1	BACC10KF20 BACKSHELL - CONDUCTIVE - 45	81205	1	31-52-11 */ */	YK901-YL429, YM643-YM652
D40740P	1	BACC45FT20-41P PLUG-	81205	1	31-52-11 P007-00/ /	YC001-YC030, YK901-YM670
D40740PQ	1	BACC10JC20 BACKSHELL-	81205	1	31-52-11 */ */	YC001-YC030, YK901-YM670
D40742J	1	BACC63CC14-7PN RCPT-CONDUCTIVE	81205	1	27-41-12 E004-02/ /	ALL
D40742P	1	BACC63CB14-7SN PLUG-CONDUCTIVE	81205	1	27-41-12 E004-02/ /	ALL
D40742PQ	1	BACC10KD14 BACKSHELL, CONDUCTIVE	81205	1	27-41-12 / /	ALL
D40744J	1	48-7191 RCPT-	02660	1	33-14-12 P006-00/ /	ALL
D40744P	1	48-7190 PLUG-	02660	1	33-14-12 P006-00/ /	ALL
D40750J	1	BACC45FN16-24S8 RCPT-	81205	1	32-31-12 P006-00/ /	YC004-YC030
D40750J	1	BACC45FN18-31S8 RCPT-	81205	1	32-31-12 P006-00/ /	YC031-YM670

EQUIPMENT LIST

D280A103

Section D40700

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40750P	1	BACC45FT16-24P8 PLUG-	81205	1	32-31-12 P006-00/ /	YC004-YC030
D40750P	1	BACC45FT18-31P8 PLUG-	81205	1	32-31-12 P006-00/ /	YC031-YM670
D40762J	1	AMC02RA03B RCPT-	05574	1	33-25-51 397/279/L048	ALL
D40762P	1	AMC02PA03B PLUG-	05574	1	33-25-51 397/279/L048	ALL
D40764J	1	AMC02RA03B RCPT-	05574	1	33-25-51 685/277/L055	YC001-YC050
D40764J	1	AMC02RA03B RCPT-	05574	1	33-25-51 687/277/L055	YK901-YM670
D40764P	1	AMC02PA03B PLUG-	05574	1	33-25-51 685/277/L055	ALL
D40774J	1	MTCPQKT1R2SGAA RCPT-	06090	1	21-25-11 E001-01/ /	YK901-YM670
D40774P	1	MTCPQKT1P2PGAA PLUG-	06090	1	21-31-24 E001-01/ /	YK901-YM670
D40790J	1	BACC63CC22-55PN RECP-CONDUCTIVE	81205	1	49-41-11 1044/299/R9	YC008-YC030
D40790J	1	BACC63CC22-55PN RECP-CONDUCTIVE	81205	1	49-41-11 AB1050R/299/R007	YK901-YM670
D40790JK	1	BACC10KF22 BACKSHELL	81205	1	49-41-11 1044/299/R9	YC008-YC030, YK901-YK910, YL421-YL423, YM643
D40790JK	1	BACC10KF22 BACKSHELL	81205	1	49-41-11 */*/*	YK911-YL401, YL424-YL430, YM645-YM670
D40790P	1	BACC63CB22-55SN PLUG-CONDUCTIVE	81205	1	49-41-11 1050/297/R008	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D40700

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40790PQ	1	BACC10KE22 BACKSHELL	81205	1	49-41-11 */*/*	YC008-YK912, YK918-YK919, YL401-YL429
D40790PQ	1	BACC10KE22 BACKSHELL	81205	1	49-41-11 1050/297/R008	YM643-YM652

EQUIPMENT LIST

D280A103

Section D40700
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40800J	1	BACC45FN20-39S8 RCPT-	81205	1	26-11-11 P006-06/ /	ALL
D40800P	1	BACC45FT20-39P8 PLUG-	81205	1	26-11-11 P006-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40800PQ	1	BACC10JS20 BACKSHELL	81205	1	26-11-11 TBD/ /	YC001-YC030
D40800PQ	1	BACC10JS20 BACKSHELL	81205	1	26-11-11 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40802J	1	BACC45FN16-24P RCPT	81205	1	30-71-11 P018-00/ /	ALL
D40802P	1	BACC45FT16-24S PLUG-	81205	1	30-71-11 P18/ /	YC001-YC030
D40802P	1	BACC45FT16-24S PLUG-	81205	1	30-71-11 P018-00/ /	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40803J	1	MTCPQKT1R2PGDD RCPT-CONDUCTIVE	06090	1	31-35-03 E008-01/ /	YK910-YK920, YL421-YM670
D40803P	1	MTCPQKT1P2SGDD PLUG-CONDUCTIVE	06090	1	31-35-03 E008-01/ /	YK910-YK920, YL421-YM670
D40804J	1	BACC63CC12-12S7 RCPT - CONDUCTIVE	81205	1	26-21-11 P009-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40804JK	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	26-21-11 */*/*	YC001-YC007

EQUIPMENT LIST

D280A103

Section D40800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40804JK	1	BACC10KD12 BACKSHELL - CONDUCTIVE	81205	1	26-21-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40804P	1	BACC45FT12-12P7 PLUG-	81205	1	26-21-11 P009-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40806J	1	BACC63CC22-55S6 RCPT-	81205	1	26-12-11 E001-04/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40806JK	1	BACC10KD22 BACKSHELL	81205	1	26-12-11 TBD/ /	YC001-YC030
D40806JK	1	BACC10KD22 BACKSHELL	81205	1	26-12-11 */ */	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40806P	1	BACC63CB22-55P6 PLUG - CONDUCTIVE	81205	1	26-12-11 E001-04/ /	ALL
D40806PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	26-12-11 E001-04/ /	YC001-YC050
D40806PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	26-12-11 */ */	YK901-YM670
D40810J	1	BACC63CC22-55P9 RCPT-CONDUCTIVE	81205	1	32-41-11 E001-03/ /	ALL
D40810P	1	BACC63CB22-55S9 PLUG	81205	1	28-21-11 E001-03/ /	YC001-YC003, YC008-YC026
D40810P	1	BACC63CB22-55S9 PLUG	81205	1	28-21-11 E001-03/ */	YC004-YC007

EQUIPMENT LIST

D280A103

Section D40800

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40810P	1	BACC63CB22-55S9 PLUG	81205	1	28-21-11 AE0103A/ /	YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40810PQ	1	BACC10KD22 BACKSHELL	81205	1	74-11-11 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40811J	1	BACC45FN12-12P7 RCPT-E8-1 SHELF	81205	1	23-11-11 E008-01/ /	YC001-YC007, YK907-YL401
D40811J	1	BACC45FN12-12P7 RCTP - E8-1 SHELF	81205	1	23-11-11 E008-01/ /	YL421-YL430
D40811P	1	BACC45FT12-12S7 PLUG-	81205	1	23-11-11 E008-01/ /	YC001-YC011, YK907-YL430
D40812J	1	BACC45FN22-55S6 RCPT-	81205	1	28-21-11 P006-06/ /	YC001-YC013, YM643-YM670
D40812J	1	BACC45FN22-55S6 RCPT-	81205	1	28-21-11 P006-00/ /	YC015-YL430
D40812P	1	BACC45FT22-55P6 PLUG	81205	1	28-21-11 P006-00/ /	YC001-YC003, YC008-YC026
D40812P	1	BACC45FT22-55P6 PLUG	81205	1	28-21-11 P006-00/**	YC004-YC007
D40812P	1	BACC45FT22-55P6 PLUG	81205	1	28-21-11 AP0600B/ /	YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40812PQ	1	BACC10JS22 BACKSHELL	81205	1	28-21-11 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40816J	1	BACC45FN14-12S9 RCPT-	81205	1	33-11-33 P006-00/ /	ALL
D40816P	1	BACC45FT14-12P9 PLUG-	81205	1	33-11-33 P006-00/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40800

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40818J	1	MTCPQKT1R2SFBC RCPT-	06090	1	27-23-11 E001-01/ /	ALL
D40818P	1	MTCPQKT1P2PFBC PLUG-CONDUCTIVE	06090	1	27-23-11 E001-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40820J	1	BACC45FN22-19S RCPT-	81205	1	27-11-11 P006-00/ /	ALL
D40820P	1	BACC45FT22-19P PLUG-	81205	1	27-11-11 P006-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40820PQ	1	BACC10JS22 BACKSHELL-	81205	1	27-11-11 */**	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40822J	1	BACC45FN16-24S7 RCPT-	81205	1	31-52-11 P006-00/ /	ALL
D40822P	1	BACC45FT16-24P7 PLUG-	81205	1	31-52-11 P006-00/ /	YC001-YC030, YK901-YM670
D40824J	1	BACC63CC20-39P9 RCPT - CONDUCTIVE	81205	1	31-52-11 P009-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D40824JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	33-11-11 */ /	YC001-YC030
D40824JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	33-11-11 */**	YK901-YL429, YM643-YM652
D40824P	1	BACC45FT20-39S9 PLUG-	81205	1	31-52-11 P009-00/ /	YC001-YC030, YK901-YM670
D40824PQ	1	BACC10JS20 BACKSHELL-	81205	1	31-52-11 */**	YC001-YC030, YK901-YM670
D40826J	1	BACC45FN20-28S9 RCPT-	81205	1	35-21-11 E001-04/ /	YC001-YC030, YK901-YM670
D40826P	1	BACC45FT20-28P9 PLUG	81205	1	35-21-11 E001-04/ /	ALL

EQUIPMENT LIST

D280A103

Section D40800

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40826PQ	1	BACC10JS20 CLAMP	81205	1	35-21-11 E001-04/ /	YC001-YC050
D40826PQ	1	BACC10JS20 CLAMP	81205	1	35-21-11 */**	YK901-YM670
D40830J	1	BACC45FN18-14S7 RCPT-	81205	1	35-21-11 P018-00/ /	ALL
D40830JK	1	BACC10JC18 BACKSHELL	81205	1	35-21-11 P018-00/ /	YC001-YC013
D40830JK	1	BACC10JC18 BACKSHELL	81205	1	35-21-11 */**	YC015-YM670
D40830P	1	BACC45FT18-14P7 PLUG-	81205	1	35-21-11 P018-00/ /	YC001-YC030, YK901-YM670
D40836J	1	BACC63CC14-12PN RCPT-CONDUCTIVE	81205	1	27-41-12 1055/298/R007	YC008-YM670
D40836JK	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	27-41-12 / /	YC008-YM670
D40836P	1	BACC63CB14-12SN PLUG-CONDUCTIVE	81205	1	27-41-12 1050/ /	YC008-YC011
D40836P	1	BACC63CB14-12SN PLUG-CONDUCTIVE	81205	1	27-41-12 1055/298/R010	YC012-YC030
D40836P	1	BACC63CB14-12SN PLUG-CONDUCTIVE	81205	1	27-41-12 AB1050R/298/R010	YC031-YM670
D40836PQ	1	BACC10KE14 BACKSHELL-CONDUCTIVE	81205	1	27-41-12 / /	YC008-YM670
D40840J	1	BACC45FN16-24P7 RCPT-	81205	1	30-41-11 P018-00/ /	YC001-YL430
D40840J	1	BACC45FN16-24P7 RCPT-	81205	1	30-81-11 P018-00/ /	YM643-YM670
D40840P	9	BACC45FT16A24S7 PLUG-	81205	1	30-41-11 P018-00/ /	YC001-YC007
D40840P	1	BACC45FT16A24S7 PLUG-	81205	1	30-81-11 P018-00/ /	YC008-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D40800

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40842J	1	BACC63CC18-31PN RCPT-CONDUCTIVE	81205	1	27-28-11 1043/296/L017	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40842JK	1	BACC10KD18 BACKSHELL-STRAIGHT	81205	1	27-28-11 */**	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40842P	1	BACC63CB18-31SN PLUG-CONDUCTIVE	81205	1	27-28-11 1043/297/L13	YC008-YC030
D40842P	1	BACC63CB18-31SN PLUG-CONDUCTIVE	81205	1	27-28-11 AB1050L/297/L013	YC031-YM670
D40842PQ	1	BACC10KE18 BACKSHELL-ANGLE	81205	1	27-28-11 / /	YC008-YM670
D40844J	1	BACC63BV10F5PN RCPT-	81205	1	21-51-11 578/154/L007	YC029-YM670
D40844JK	1	BACC10KF10 BACKSHELL,CONDUCTIVE 45 DEGREE	81205	1	21-51-11 */**	YC029-YM670
D40844P	1	BACC63BP10C5SN PLUG-CONDUCTIVE	81205	1	21-51-11 578/154/L007	YC029-YM670
D40844PQ	1	BACC10KF10 BACKSHELL,CONDUCTIVE 45 DEGREE	81205	1	21-51-11 / /	YC029-YL430
D40844PQ	1	BACC10KF10 BACKSHELL,CONDUCTIVE 45 DEGREE	81205	1	21-51-11 537/154/L007	YM643-YM670
D40846J	1	BACC63BV10F5PN RCPT-	81205	1	21-51-21 558/155/R08	YC029-YM670
D40846JK	1	BACC10KF10 BACKSHELL,CONDUCTIVE 45 DEGREE	81205	1	21-51-21 / /	YC029-YM670
D40846P	1	BACC63BP10C5SN PLUG-CONDUCTIVE	81205	1	21-51-11 558/155/R008	YC029-YL430
D40846P	1	BACC63BP10C5SN PLUG-	81205	1	21-51-11 558/155/R008	YM643-YM670
D40846PQ	1	BACC10KF10 BACKSHELL, CONDUCTIVE 45 DEGREE	81205	1	21-51-11 */**	YC029-YM670

EQUIPMENT LIST

D280A103

Section D40800

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40854J	1	BACC63CC22-55P7 RECP-CONDUCTIVE	81205	1	49-41-11 AB1050R/297/R008	YC008-YC026
D40854J	1	BACC63CC22-55P7 RECP-CONDUCTIVE	81205	1	49-41-11 AB1050R/ /	YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40854JK	1	BACC10KF22 BACKSHELL	81205	1	49-41-11 1050/ /	YC008-YC050
D40854JK	1	BACC10KF22 BACKSHELL	81205	1	49-41-11 */**	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40854P	1	BACC63CB22-55S7 PLUG-CONDUCTIVE	81205	1	49-41-11 AB1050R/297/R008	YC008-YC030, YM643-YM652
D40854P	1	BACC63CB22-55S7 PLUG-CONDUCTIVE	81205	1	49-41-11 AB1050R/ /	YC031-YK912, YK918-YK919, YL401-YL429
D40854PQ	1	BACC10KE22 BACKSHELL	81205	1	49-41-11 */**	YC008-YK912, YK918-YK919, YL401-YL429
D40854PQ	1	BACC10KE22 BACKSHELL	81205	1	49-41-11 AB1050R/297/R008	YM643-YM652
D40858J	1	BACC45FN18-31PN RCPT-	81205	1	28-23-11 J020-00/ /	YC031-YM670
D40858P	1	BACC45FT18-31SN PLUG-	81205	1	28-23-11 J020-00/ /	YC031-YM670
D40858PQ	1	BACC10GH18 BACKSHELL - STRAIGHT	81205	1	28-23-11 */**	YC031-YM670
D40862J	1	AMC02RA03B RCPT-	05574	1	33-25-61 477/281/R052	ALL
D40862P	1	AMC02PA03B PLUG-	05574	1	33-25-61 477/281/R052	ALL
D40864J	1	AMC02RA03B RCPT-	05574	1	33-25-61 684/278/R050	ALL

EQUIPMENT LIST

D280A103

Section D40800

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40864P	1	AMC02PA03B PLUG-	05574	1	33-25-61 682/278/R050	ALL
D40876J	1	BACC63CC16-10P6 RECP-CONDUCTIVE	81205	1	24-21-31 1046/298/R9	YC008-YC030
D40876J	1	BACC63CC16-10P6 RECP-CONDUCTIVE	81205	1	24-21-31 AB1050R/299/R007	YK901-YM670
D40876JK	1	BACC10KF16 BACKSHELL	81205	1	24-21-31 1044/299/R9	YC008-YC030, YK901-YK910, YL421-YL423, YM643
D40876JK	1	BACC10KF16 BACKSHELL	81205	1	24-21-31 */**	YK911-YL401, YL424-YL430, YM645-YM670
D40876P	1	BACC63CB16-10S6 PLUG-CONDUCTIVE	81205	1	24-21-31 / /	YC008-YC026
D40876P	1	BACC63CB16-10S6 PLUG-CONDUCTIVE	81205	1	24-21-31 1050/297/R008	YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40876PQ	1	BACC10KE16 BACKSHELL	81205	1	24-21-31 */**	YC008-YK912, YK918-YK919, YL401-YL429
D40876PQ	1	BACC10KE16 BACKSHELL	81205	1	24-21-31 1050/297/R008	YM643-YM652
D40878J	1	BACC63CC12-12P6 RCPT- CONDUCTIVE	81205	1	21-31-22 J020/ /	YC028-YM670
D40878P	1	BACC63CB12-12S6 PLUG-CONDUCTIVE	81205	1	21-31-22 J020/ /	YC028-YC030, YM643-YM670
D40878P	1	BACC63CB12-12S6 PLUG-CONDUCTIVE	81205	1	21-31-22 J020-00/ /	YK901-YL430
D40884J	1	BACC63CC18-31P8 RCPT- CONDUCTIVE	81205	1	21-31-23 J020/ /	YC028-YL430
D40884J	1	BACC63CC18-31P8 RCPT- CONDUCTIVE	81205	1	21-31-23 J020-00/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section D40800

Page 8

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40884P	1	BACC63CB18-31S8 PLUG-CONDUCTIVE	81205	1	21-31-23 J020/ /	YC028-YM670

EQUIPMENT LIST

D280A103

Section D40800
Page 9 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40904J	1	MTCPQKT1R2PFCB RCPT-	06090	1	49-52-31 E004-01/ /	ALL
D40904P	1	MTCPQKT1P2SFCB PLUG-	06090	1	49-52-31 E004-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40908J	1	MTCPQKT1R2PGDB RCPT-CONDUCTIVE	06090	1	49-62-11 E003-02/ /	ALL
D40908P	1	MTCPQKT1P2SGDB PLUG-	06090	1	49-62-11 E003-02/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40910J	1	MTCPQKT2R26PFBB RCPT-CONDUCTIVE	06090	1	49-52-31 E002-01/ /	ALL
D40910P	1	MTCPQKT2P26SGBB PLUG-	06090	1	49-52-31 E002-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40912J	1	MTCPQKT2R26PFAA RCPT-CONDUCTIVE	06090	1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D40912P	1	MTCPQKT2P26SFAA PLUG-	06090	1	49-41-11 E2-2/ /	YC001-YC007
D40912P	1	MTCPQKT2P26SFAA PLUG-	06090	1	49-41-11 E002-02/ /	YC008-YC026
D40912P	1	MTCPQKT2P26SFAA PLUG-	06090	1	49-41-11 E2-2 391/187/L029	YC028-YK912, YK918-YK919, YL401-YL429
D40912P	1	MTCPQKT2P26SFAA PLUG-	06090	1	49-41-11 E002-02/187/L029	YM643-YM652
D40914J	1	BACC63CC14-15P9 RCPT - CONDUCTIVE	81205	1	32-42-11 P009-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40914JK	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	32-42-11 */*/	YC001-YC007

EQUIPMENT LIST

D280A103

Section D40900

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40914JK	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	32-42-11 * / /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40914P	1	BACC45FT14-15S9 PLUG-	81205	1	32-42-11 P009-00/ /	ALL
D40914PQ	1	BACC10JS14 BACKSHELL-	81205	1	32-42-11 / /	ALL
D40924J	1	BACC63CC22-32S8 RCPT - CONDUCTIVE	81205	1	33-11-11 P009-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D40924JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	33-11-11 * / /	YC001-YC030
D40924JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	33-11-11 * / * / *	YK901-YL429, YM643-YM652
D40924P	1	BACC63CB22-32P8 PLUG-	81205	1	33-11-11 P009-00/ /	ALL
D40924PQ	1	BACC10KD22 BACKSHELL-	81205	1	33-11-11 * / * / *	ALL
D40926J	1	MTCPQKT1R2PFCA RCPT-	06090	1	49-52-31 E002-01/ /	ALL
D40926P	1	MTCPQKT1P2SFCA PLUG-	06090	1	49-52-31 E002-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40928J	1	MTCPQKT1R2PFAD RCPT-CONDUCTIVE	06090	1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D40928P	1	MTCPQKT1P2SFAD PLUG-	06090	1	49-41-11 E2-2/ /	YC001-YC007
D40928P	1	MTCPQKT1P2SFAD PLUG-	06090	1	49-41-11 E002-02/ /	YC008-YC026
D40928P	1	MTCPQKT1P2SFAD PLUG-	06090	1	49-41-11 E2-2 391/185/L050	YC028-YK912, YK918-YK919, YL401-YL429

EQUIPMENT LIST

D280A103

Section D40900

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40928P	1	MTCPQKT1P2SFAD PLUG-	06090	1	49-41-11 E002-02/185/L050	YM643-YM652
D40930J	1	MTCPQKT1R2PFBA RCPT-	06090	1	24-22-31 E004-02/ /	ALL
D40930P	1	MTCPQKT1P2SFBA PLUG-	06090	1	24-22-31 E004-02/ /	ALL
D40934J	1	MTCPQKT2R26PFAB RCPT-	06090	1	24-32-11 E002-01/ /	ALL
D40934P	1	MTCPQKT2P26SFAB PLUG-	06090	1	24-32-11 E002-01/ /	ALL
D40938J	1	MTCPQKT2R26PFDA RCPT	06090	1	24-21-21 E004-02/ /	ALL
D40938P	1	MTCPQKT2P26SFDA PLUG-	06090	1	24-21-21 E004-02/ /	YC001-YC030, YK901-YM670
D40940J	1	MTCPQKT1R2SGBC RCPT-CONDUCTIVE	06090	1	26-12-12 E003-02/ /	ALL
D40940P	1	MTCPQKT1P2PGBC PLUG-	06090	1	26-12-12 E003-02/ /	ALL
D40942J	1	MTCPQKT1R2PFAC RCPT-CONDUCTIVE	06090	1	24-21-31 E002-02/ /	YC001-YC030, YK901-YM670
D40942P	1	MTCPQKT1P2SFAC PLUG-	06090	1	24-21-31 E2-2/ /	YC001-YC007
D40942P	1	MTCPQKT1P2SFAC PLUG-	06090	1	24-21-31 E002-02/ /	YC008-YC026
D40942P	1	MTCPQKT1P2SFAC PLUG-	06090	1	24-21-31 E2-2 391/186/L029	YC028-YC030
D40942P	1	MTCPQKT1P2SFAC PLUG-	06090	1	24-21-31 AE0202A/ /	YC031-YK912, YK918-YK919, YL401-YL429
D40942P	1	MTCPQKT1P2SFAC PLUG-	06090	1	24-21-31 E002-021/186/L029	YM643-YM652

EQUIPMENT LIST

D280A103

Section D40900

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40944J	1	BACC63CC18-31SN RCPT - CONDUCTIVE	81205	1	33-14-11 P009-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40944JK	1	BACC10KD18 BACKSHELL - CONDUCTIVE	81205	1	33-14-11 */**	YC001-YC007
D40944JK	1	BACC10KD18 BACKSHELL - CONDUCTIVE	81205	1	33-14-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D40944P	1	BACC45FT18-31P PLUG-	81205	1	33-14-11 P009-00/ /	ALL
D40944PQ	1	BACC10JS18 BACKSHELL-	81205	1	33-14-11 **/*	ALL
D40946J	1	MTCPQKT2R26PFAB RCPT-	06090	1	49-62-11 E002-02/ /	YC001-YC030, YK901-YM670
D40946P	1	MTCPQKT2P26SFAB PLUG-	06090	1	49-62-11 E2-2 391/186/L029	YC001-YK912, YK918-YK919, YL401-YL429
D40946P	1	MTCPQKT2P26SFAB PLUG-	06090	1	49-62-11 E002-02/186/L029	YM643-YM652
D40948J	1	MTCPQKT1R2SFBB RCPT-	06090	1	27-81-22 E001-01/ /	ALL
D40948P	1	MTCPQKT1P2PFBB PLUG-	06090	1	27-81-22 E001-01/ /	ALL
D40950J	1	MTCPQKT1R2PFDC RCPT-	06090	1	78-34-11 E003-02/ /	YC001-YC003
D40950J	1	MTCPQKT1R2PFDC RCPT	06090	1	78-34-11 E003-02/ /	YC004-YM670
D40950P	1	MTCPQKT1P2SFDC PLUG-	06090	1	78-34-11 E003-02/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D40900

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40952J	1	MTCPQKT2R22PFAD RCPT-	06090	1	78-34-21 E003-02/ /	YC001-YC003
D40952J	1	MTCPQKT2R22PFAD RCPT	06090	1	78-34-21 E003-02/ /	YC004-YC030
D40952J	1	MTCPQKT2R22PGAD RCPT-CONDUCTIVE	06090	1	78-34-21 E003-02/ /	YK901-YM670
D40952P	1	MTCPQKT2P22SFAD PLUG-	06090	1	78-34-21 E003-02/ /	YC001-YC030
D40952P	1	MTCPQKT2P22SGAD PLUG-	06090	1	78-34-21 E003-02/ /	YK901-YM670
D40984J	1	AMC02RA03W RCPT-	05574	1	33-22-22 720/295/L024	YK901-YL430
D40984P	1	AMC02PA03W PLUG-	05574	1	33-22-21 720/295/L024	YK901-YL430
D40990J	1	AMC02RA03W RCPT-	05574	1	33-22-31 500G/296/R020	YK901-YL430
D40990J	1	AMC02RA03W RCPT-	05574	1	33-22-31 640/296/R020	YM643-YM670
D40990P	1	AMC02PA03W PLUG-	05574	1	33-22-31 500G/296/R020	YK901-YL430
D40990P	1	AMC02PA03W PLUG-	05574	1	33-22-31 640/296/R020	YM643-YM670
D40992J	1	AMC02RA03W RCPT-	05574	1	33-22-21 576/295/L024	YM643-YM670
D40992P	1	AMC02PA03W PLUG-	05574	1	33-22-21 571/296/L022	YM643-YM670
D40994J	1	AMC02RA03W RCPT-	05574	1	33-22-22 800/295/L023	YK901-YL430
D40994J	1	AMC02RA03W RCPT-	05574	1	33-22-22 800/296/L023	YM643-YM670
D40994P	1	AMC02PA03W PLUG-	05574	1	33-22-22 800/295/L022	YK901-YM670
D40996J	1	AMC02RA03W RCPT-	05574	1	33-22-32 727J/299/R020	YK901-YL430

EQUIPMENT LIST

D280A103

Section D40900

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40996P	1	AMC02PA03W PLUG-	05574	1	33-22-32 727J/299/R020	YK901-YL430

EQUIPMENT LIST

D280A103

Section D40900
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41010J	1	BACC45FN16-24P RCPT-	81205	1	21-31-11 E004-01/ /	ALL
D41010P	1	BACC45FT16-24S PLUG-	81205	1	21-31-11 E004-01/ /	ALL
D41010PQ	1	BACC10JS16 BACKSHELL-	81205	1	21-31-11 / /	YC001-YC026
D41010PQ	1	BACC10JS16 BACKSHELL-	81205	1	21-31-11 */*/	YC028-YM670
D41012J	1	MTCPQKT1R2SFDA RCPT-	06090	1	24-11-11 E002-02/ /	YC001-YC030, YK901-YM670
D41012P	1	MTCPQKT1P2PFDA PLUG-	06090	1	24-11-11 E002-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D41000
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41121J	1	MTCPQKT2R22SGDA RECPT-CONDUCTIVE	06090	1	22-11-11 E001-01/ /	ALL
D41121P	1	MTCPQKT2P22PGDA PLUG - CONDUCTIVE	06090	1	22-11-11 E001-01/ /	ALL
D41125J	1	MTCPQKT2R22SGBA RECPT-CONDUCTIVE	06090	1	34-45-21 E001-01/ /	ALL
D41125P	1	MTCPQKT2P22PGBA PLUG-CONDUCTIVE	06090	1	34-45-21 E001-01/ /	ALL
D41127J	1	BACC63CC16-24P6 RECP - CONDUCTIVE	81205	1	31-62-15 E001-02/ /	ALL
D41127JK	1	BACC10KD16 BACKSHELL	81205	1	31-62-15 / /	ALL
D41127P	1	BACC63CB16-24S6 PLUG-	81205	1	31-62-15 E001-02/ /	YC001-YC030, YK901-YM670
D41127PQ	1	BACC10KD16 BACKSHELL	81205	1	31-62-15 E001-02/ /	YC001-YC030
D41127PQ	1	BACC10KD16 BACKSHELL	81205	1	31-62-15 */*/*	YK901-YM670
D41129J	1	BACC63CC22-55SN RECP - CONDUCTIVE	81205	1	22-11-11 E001-04/ /	ALL
D41129JK	1	BACC10KD22 BACKSHELL	81205	1	22-11-11 / /	ALL
D41129P	1	BACC63CB22-55PN PLUG - CONDUCTIVE	81205	1	22-11-11 E001-04/ /	ALL
D41129PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	22-11-11 E001-04/ /	YC001-YC050
D41129PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	22-11-11 */*/*	YK901-YM670
D41131J	1	BACC63CC22-55P6 RCPT-CONDUCTIVE	81205	1	34-53-21 E001-03/ /	ALL
D41131P	1	BACC63CB22-55S6 PLUG - CONDUCTIVE	81205	1	34-53-21 E001-03/ /	YC001-YC030, YK901-YM670
D41131PQ	1	BACC10KD22 BACKSHELL	81205	1	34-53-21 */*/*	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D41100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41145J	1	MTCPQKT1R2SGAD RECPT-CONDUCTIVE	06090	1	22-11-51 E001-01/ /	ALL
D41145P	1	MTCPQKT1P2PGAD PLUG	06090	1	34-21-11 E001-01/ /	ALL
D41147J	1	MTCPQKT2R26PGCC RECPT-CONDUCTIVE	06090	1	31-62-25 E001-01/ /	ALL
D41147P	1	MTCPQKT2P26SGCC PLUG - CONDUCTIVE	06090	1	31-62-25 E001-01/ /	ALL
D41153J	1	MTCPQKT1R2SGCC RECPT-CONDUCTIVE	06090	1	22-11-53 E001-01/ /	YC012-YM670
D41153P	1	MTCPQKT1P2PGCC PLUG - CONDUCTIVE	06090	1	22-11-53 E001-01/ /	YC012-YC030, YK901-YM670
D41155J	1	MTCPQKT2R22SGDD RECPT-CONDUCTIVE	06090	1	34-61-12 E001-01/ /	ALL
D41155P	1	MTCPQKT2P22PGDD PLUG	06090	1	34-61-12 E001-01/ /	ALL
D41157J	1	MTCPQKT2R22SGCD RECPT-CONDUCTIVE	06090	1	34-61-12 E001-01/ /	ALL
D41157P	1	MTCPQKT2P22PGCD PLUG	06090	1	34-61-12 E001-01/ /	ALL
D41159J	1	MTCPQKT1R2SGBC RECPT-CONDUCTIVE	06090	1	22-31-31 E001-01/ /	ALL
D41159P	1	MTCPQKT1P2PGBC PLUG	06090	1	22-31-31 E001-01/ /	ALL
D41161J	1	MTCPQKT1R2SGAC RECPT-CONDUCTIVE	06090	1	22-31-41 E001-01/ /	ALL
D41161P	1	MTCPQKT1P2PGAC PLUG-CONDUCTIVE	06090	1	22-31-41 E001-01/ /	ALL
D41163J	1	MTCPQKT2R22PGBD RECPT-CONDUCTIVE	06090	1	31-31-13 E001-01/ /	ALL
D41163P	1	MTCPQKT2P22SGBD PLUG-CONDUCTIVE	06090	1	22-11-75 E001-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D41100
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41211J	1	BACC63CC22-55PN RCPT-CONDUCTIVE	81205	1	34-45-02 E001-02/ /	ALL
D41211JK	1	BACC10KD22 BACKSHELL	81205	1	34-45-02 / /	YC001-YC030
D41211JK	1	BACC10KD22 BACKSHELL	81205	1	34-45-02 */**	YC031-YM670
D41211P	1	BACC63CB22-55SN PLUG	81205	1	34-45-02 E001-02/ /	YC001-YC030, YK901-YM670
D41211PQ	1	BACC10KF22 BACKSHELL	81205	1	34-45-02 E001-02/ /	YC001-YC030
D41211PQ	1	BACC10KF22 BACKSHELL	81205	1	34-45-02 */**	YK901-YM670
D41213J	1	BACC63CC16-24PN RCPT - CONDUCTIVE	81205	1	34-53-11 E001-02/ /	YC001-YC030, YK901-YM670
D41213JK	1	BACC10KD16 BACKSHELL	81205	1	34-53-11 */**	YC001-YC030, YK901-YM670
D41213P	1	BACC63CB16-24SN PLUG-CONDUCTIVE	81205	1	34-45-02 E001-02/ /	YC001-YC030, YK901-YM670
D41213PQ	1	BACC10KD16 BACKSHELL	81205	1	34-45-02 E001-02/ /	YC001-YC030
D41213PQ	1	BACC10KD16 BACKSHELL	81205	1	34-45-02 */**	YK901-YM670
D41215J	1	2431-88-16 JACK-DME 1	91836	1	34-55-11 E001-02/ /	ALL
D41215P	1	2435-83-16 PLUG-DME	91836	1	34-55-11 E001-02/ /	YC001-YC030, YK901-YM670
D41217J	1	BACC63CC22-55P8 RCPT-CONDUCTIVE	81205	1	34-53-11 E001-02/ /	ALL
D41217JK	1	BACC10KD22 BACKSHELL	81205	1	34-53-11 / /	YC001-YC007
D41217JK	1	BACC10KD22 BACKSHELL	81205	1	34-53-11 E001-02/ /	YC008-YC050
D41217JK	1	BACC10KD22 BACKSHELL	81205	1	34-53-11 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D41200

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41217P	1	BACC63CB22-55S8 PLUG	81205	1	34-53-11 E001-02/ /	YC001-YC030, YK901-YM670
D41217PQ	1	BACC10KF22 BACKSHELL	81205	1	34-53-11 51PQ1-02/ /	YC001-YC030
D41217PQ	1	BACC10KF22 BACKSHELL	81205	1	34-53-11 */**	YK901-YM670
D41251J	1	BACC63CG22-55P7 RCPT-CONDUCTIVE	81205	1	34-31-11 E001-04/ /	ALL
D41251JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	34-31-11 */**	ALL
D41251P	1	BACC63CB22-55S7 PLUG-CONDUCTIVE	81205	1	34-21-13 E001-04/ /	YC001-YC030, YK901-YM670
D41251PQ	1	BACC10KF22 BACKSHELL	81205	1	34-45-02 E001-04/ /	YC001-YC030
D41251PQ	1	BACC10KF22 BACKSHELL	81205	1	34-21-13 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D41200
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41337J	1	BACC63CC18-31S8 RCPT-CONDUCTIVE	81205	1	23-31-06 E001-03/ /	YC001-YC050, YM643-YM670
D41337J	1	BACC63CC18-31S8 RCPT	81205	1	23-31-06 E001-03/ /	YK901-YL430
D41337P	1	BACC63CB18-31P8 PLUG-CONDUCTIVE	81205	1	23-31-06 E001-03/ /	ALL
D41337PQ	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	23-31-06 */*/	ALL

EQUIPMENT LIST

D280A103

Section D41300

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41400J	1	BACC45FN16-24S9 RCPT	81205	1	32-42-11 E001-03/ /	ALL
D41400P	1	BACC45FT16-24P9 PLUG-E1-3 SHELF	81205	1	32-42-11 E001-03/ /	ALL
D41400PQ	1	BACC10JS16 BACKSHELL	81205	1	32-42-11 / /	ALL
D41430J	1	BACC45FN14-4S6 RECP-	81205	1	30-41-11 P006-00/ /	ALL
D41430P	1	BACC45FT14-4P6 PLUG-	81205	1	30-41-11 P006-00/ /	ALL
D41432J	1	BACC45FN14-4P7 RCPT-	81205	1	30-41-11 E002-01/ /	ALL
D41432P	1	BACC45FT14-4S7 PLUG-	81205	1	30-41-11 E002-01/ /	ALL
D41432PQ	1	BACC10JS14 BACKSHELL-	81205	1	30-41-11 */*/	ALL
D41436J	1	BACC65AK221P RCPT-	81205	1	21-61-22 410/289/R034	YM643-YM670
D41436P	1	BACC65AJ121S PLUG-	81205	1	21-61-22 409/289/R034	YM643-YM670
D41440J	1	MTCPQKT1R2PGBC RCPT-	06090	1	30-41-12 E004-02/ /	ALL
D41440P	1	MTCPQKT1P2SGBC PLUG-	06090	1	30-41-12 E004-02/ /	YC001-YC030, YK901-YL430
D41440P	1	MTCPQKT1P2SGBC PLUG-CONDUCTIVE	06090	1	30-41-12 E004-02/ /	YM643-YM670
D41453J	1	BACC63CC22-55S8 RCPT-CONDUCTIVE	81205	1	34-31-21 E001-04/ /	ALL
D41453JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	34-31-21 E001-04/ */*	YC001-YC050
D41453JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	34-31-21 */*/	YK901-YM670
D41453P	1	BACC63CB22-55P8 PLUG - CONDUCTIVE	81205	1	34-31-21 E001-04/ /	ALL

EQUIPMENT LIST

D280A103

Section D41400

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41453PQ	1	BACC10KF22 BACKSHELL - CONDUCTIVE	81205	1	34-31-21 E001-04/ /	YC001-YC050
D41453PQ	1	BACC10KF22 BACKSHELL - CONDUCTIVE	81205	1	34-31-21 */*/*	YK901-YM670
D41463J	1	BACC63CC22-55P6 RCPT	81205	1	22-31-52 E001-04/ /	ALL
D41463JK	1	BACC10KD22 BACKSHELL	81205	1	22-31-52 / /	YC001-YC030
D41463JK	1	BACC10KD22 BACKSHELL	81205	1	22-31-52 */*/*	YC031-YM670
D41463P	1	BACC63CB22-55S6 PLUG - CONDUCTIVE	81205	1	31-31-15 E001-04/ /	ALL
D41463PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	31-31-15 E001-04/ /	YC001-YC050
D41463PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	31-31-15 */*/*	YK901-YM670

EQUIPMENT LIST

D280A103

Section D41400
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41500	1	BACC63BP22C39P10 PLUG-CONDUCTIVE	81205	1	21-51-11 542/163/L009	ALL
D41500 T	1	BACC10KF22 BACKSHELL-45 DEGREE	81205	1	21-51-11 */**	ALL
D41502	1	BACC63BP22C39S10 PLUG-	81205	1	21-42-11 536/163/L009	YC001-YC030, YK901-YM670
D41507J	1	BACC63CC22-55P7 RCPT - CONDUCTIVE	81205	1	34-53-21 E1-5 307/162/L23	YC001-YC030
D41507J	1	BACC63CC22-55P7 RCPT - CONDUCTIVE	81205	1	34-53-21 AE0105A/ /	YK901-YM670
D41507JK	1	BACC10KD22 BACKSHELL	81205	1	34-53-21 */**	YC001-YC030, YK901-YM670
D41507P	1	BACC63CB22-55S7 PLUG-CONDUCTIVE	81205	1	34-53-21 E001-05/ /	YC001-YC030
D41507P	1	BACC63CB22-55S7 PLUG-CONDUCTIVE	81205	1	34-53-21 AE0105A/ /	YK901-YM670
D41507PQ	1	BACC10KD22 BACKSHELL	81205	1	28-23-12 / /	YC001-YC030
D41507PQ	1	BACC10KD22 BACKSHELL	81205	1	28-23-12 */**	YK901-YM670
D41509J	1	BACC63CC22-55S8 RCPT-CONDUCTIVE	81205	1	23-31-06 E001-03/ /	ALL
D41509P	1	BACC63CB22-55P8 PLUG-CONDUCTIVE	81205	1	31-31-17 E001-03/ /	ALL
D41509PQ	1	BACC10KD22 BACKSHELL	81205	1	34-45-02 / /	YC001-YC030
D41509PQ	1	BACC10KD22 BACKSHELL	81205	1	34-45-02 */**	YC031-YM670
D41511J	1	2431-84-11 JACK-COAX	91836	1	34-53-31 AE0105A/ /	ALL
D41511P	1	2435-81-11 PLUG-COAX	91836	1	34-53-31 E001-05/ /	YC001-YC030, YK901-YM670
D41515J	1	2431-88-1 JACK-DME 2	91836	1	34-55-21 E001-05/ /	YC001-YL430

EQUIPMENT LIST

D280A103

Section D41500

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41515J	1	2431-88-1 JACK-DME 2	91836	1	34-55-21 AE0105A/ /	YM643-YM670
D41515P	1	2435-83-1 PLUG-COAX	91836	1	34-55-21 E001-05/ /	YC001-YC030, YK901-YM670
D41517J	1	BACC63CC22-55PN RCPT-CONDUCTIVE	81205	1	34-53-21 E001-05/ /	ALL
D41517JK	1	BACC10KD22 BACKSHELL	81205	1	34-53-21 */ /	YC001-YC050
D41517JK	1	BACC10KD22 BACKSHELL	81205	1	34-53-21 / /	YK901-YM670
D41517P	1	BACC63CB22-55SN PLUG-CONDUCTIVE	81205	1	34-53-21 E001-05/ /	YC001-YC030
D41517P	1	BACC63CB22-55SN PLUG-CONDUCTIVE	81205	1	34-53-21 AE0105A/ /	YK901-YM670
D41517PQ	1	BACC10KD22 BACKSHELL	81205	1	28-23-12 / /	YC001-YC030
D41517PQ	1	BACC10KD22 BACKSHELL	81205	1	28-23-12 */*/	YK901-YM670
D41557J	1	BACC63CC20-39P9 RCPT-CONDUCTIVE	81205	1	34-61-14 E001-05/ /	ALL
D41557JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	34-61-14 */*/	ALL
D41557P	1	BACC63CB20-39S9 PLUG-CONDUCTIVE	81205	1	34-51-41 E001-05/ /	YC001-YC030
D41557P	1	BACC63CB20-39S9 PLUG-CONDUCTIVE	81205	1	34-51-41 AE0105A/ /	YK901-YM670
D41557PQ	1	BACC10KD20 BACKSHELL	81205	1	28-23-12 / /	YC001-YC030
D41557PQ	1	BACC10KD20 BACKSHELL	81205	1	28-23-12 */*/	YK901-YM670
D41561J	1	MTCPQKT2R22SGDC RCPT-CONDUCTIVE	06090	1	34-21-13 E005-02/ /	YC001-YC030, YK901-YM670
D41561P	1	MTCPQKT2P22PGDC PLUG-	06090	1	34-21-14 E005-02/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section D41500

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41561P	1	MTCPQKT2P22PGDC PLUG-	06090	1	34-21-14 AE0502A/ /	YK901-YM670
D41563J	1	MTCPQKT1R2PGAA RECPT-CONDUCTIVE	06090	1	27-28-11 E001-01/ /	ALL
D41563P	1	MTCPQKT1P2SGAA PLUG-CONDUCTIVE	06090	1	27-28-11 E001-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D41500
Page 3 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41600	1	BACC63BP22C39P10 PLUG-CONDUCTIVE	81205	1	21-51-11 542/163/R009	ALL
D41600 T	1	BACC10KF22 BACKSHELL-45 DEGREE	81205	1	21-51-11 */*/*	ALL
D41602	1	BACC63BP22C39S10 PLUG-	81205	1	21-42-11 536/163/R009	ALL

EQUIPMENT LIST

D280A103

Section D41600
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41800J	1	MTCPQKT1R2SFBA RCPT-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41800P	1	MTCPQKT1P2PFBA PLUG-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41801J	1	BACC45FN16-24S8 RCPT	81205	1	34-45-11 P018-00/ /	YC001-YC050, YK907-YM670
D41801J	1	BACC45FN14-15S8 RCPT	81205	1	34-45-11 P018-00/ /	YK901-YK906
D41801P	1	BACC45FT16-24P8 PLUG-	81205	1	34-45-11 P018-00/ /	YC001-YC050, YK907-YM670
D41801P	1	BACC45FT14-15P8 PLUG-	81205	1	34-45-11 P018-00/ /	YK901-YK906
D41802J	1	MTCPQKT1R2SFBC RCPT-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41802P	1	MTCPQKT1P2PFBC PLUG-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41803J	1	BACC45FN20-25S6 RCPT	81205	1	22-11-12 P018-00/ /	ALL
D41803P	1	BACC45FT20-25P6 PLUG-	81205	1	22-11-12 P018-00/ /	ALL
D41804J	1	MTCPQKT1R2SFCA RCPT-	06090	1	21-51-22 E004-01/ /	YC001-YL430
D41804P	1	MTCPQKT1P2PFCA PLUG-	06090	1	21-51-22 E004-01/ /	YC001-YL430
D41805J	1	BACC45FN20-28S6 RCPT	81205	1	34-33-11 P018-00/ /	ALL
D41805P	1	BACC45FT20-28P6 PLUG-	81205	1	34-33-11 P018-00/ /	ALL
D41806J	1	MTCPQKT2R22SFAB RCPT-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41806P	1	MTCPQKT2P22PFAB PLUG-CONDUCTIVE	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41807J	1	BACC45FN22-32S8 RCPT	81205	1	34-51-11 P018-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D41800

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41807JK	1	BACC10JC22 BACKSHELL	81205	1	34-51-11 P018-00/ /	YC001-YC013
D41807JK	1	BACC10JC22 BACKSHELL	81205	1	34-51-11 */**	YC015-YM670
D41807P	1	BACC45FT22-32P8 PLUG-	81205	1	34-51-11 P018-00/ /	YC001-YC030, YK901-YM670
D41808J	1	MTCPQKT1R2SFDB RCPT-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41808P	1	MTCPQKT1P2PFDB PLUG-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41809J	1	BACC45FN20-28S9 RCPT	81205	1	31-62-11 P018-00/ /	ALL
D41809JK	1	BACC10JC20 BACKSHELL	81205	1	34-51-11 P018-00/ /	YC001-YC013
D41809JK	1	BACC10JC20 BACKSHELL	81205	1	34-51-11 */**	YC015-YM670
D41809P	1	BACC45FT20-28P9 PLUG-	81205	1	31-62-11 P018-00/ /	ALL
D41810J	1	MTCPQKT1R2SFCB RCPT-	06090	1	21-51-22 E004-01/ /	YC001-YL430
D41810P	1	MTCPQKT1P2PFCB PLUG-	06090	1	21-51-22 E004-01/ /	YC001-YL430
D41811J	1	MTCPQKT1R2PFDA RCPT-	06090	1	34-45-11 E001-01/ /	ALL
D41811P	1	MTCPQKT1P2SFDA PLUG - CONDUCTIVE	06090	1	34-45-11 E001-01/ /	ALL
D41812J	1	MTCPQKT2R2SFAA RCPT-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41812P	1	MTCPQKT2P22PFAA PLUG-	06090	1	21-51-12 E003-03/ /	YC001-YL430
D41814J	1	MTCPQKT1R2SFBB RCPT-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41814P	1	MTCPQKT1P2PFBB PLUG-	06090	1	21-51-22 E003-03/ /	YC001-YC030, YK901-YL430

EQUIPMENT LIST

D280A103

Section D41800

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41816J	1	MTCPQKT1R2SFCC RCPT-	06090	1	21-51-22 E004-01/ /	YC001-YL430
D41816P	1	MTCPQKT1P2PFCC PLUG-	06090	1	21-51-22 E004-01/ /	YC001-YL430
D41817J	1	BACC45FN14-12P RCPT - POWER	81205	1	34-33-11 E003-01/ /	YC001-YC030, YK901-YM670
D41817P	1	BACC45FT14-12S PLUG E3-1 SHELF	81205	1	34-33-11 E003-01/ /	ALL
D41817PQ	1	BACC10JS14 BACKSHELL-	81205	1	34-33-11 */*/	ALL
D41818J	1	MTCPQKT1R2SFCA RCPT-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41818P	1	MTCPQKT1P2PFCA PLUG-	06090	1	21-51-22 E003-03/ /	YC001-YL430
■ D41819J	1	BACC45FN20-28P7 RCPT	81205	1	22-23-12 E003-02/ /	ALL
■ D41819P	1	BACC45FT20-28S7 PLUG E3-2 SHELF	81205	1	22-23-12 E003-02/ /	ALL
D41819PQ	1	BACC10JS20 BACKSHELL-	81205	1	22-23-11 */*/	ALL
D41820J	1	S280W557-241 RCPT-	81205	1	21-61-13 409/289/R033	YC001-YC026
D41820J	1	BACC65AK241P RCPT-	81205	1	21-61-13 409/289/R033	YC028-YL430
D41820P	1	S280W557-141 PLUG-	81205	1	21-61-13 410/289/R034	YC001-YC026
D41820P	1	BACC65AJ141S PLUG-	81205	1	21-61-13 410/289/R034	YC028-YL430
D41821J	1	MTCPQKT2R26PFAD RCPT-	06090	1	22-11-12 E001-01/ /	ALL
D41821P	1	MTCPQKT2P26SFAD PLUG E1-1 SHELF	06090	1	22-11-12 E001-01/ /	ALL
D41822J	1	MTCPQKT1R2SFCD RCPT-	06090	1	21-51-21 E003-03/ /	YC001-YL430

EQUIPMENT LIST

D280A103

Section D41800
Page 3
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41822P	1	MTCPQKT1P2PFCD PLUG-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41823P	1	BACC63CB14-12S6 PLUG P9 PANEL	81205	1	31-62-11 P009-00/ /	YC031-YM670
D41823PQ	1	BACC10KD14 BACKSHELL - CONDUCTIVE, STRAIGHT	81205	1	31-62-11 P001-00/ /	YC031-YM670
D41824J	1	BACC45FN14-4S7 RCPT-	81205	1	21-25-11 E003-03/ /	YC001-YL430
D41824P	1	BACC45FT14-4P7 PLUG-	81205	1	21-25-11 E003-03/ /	YC001-YC030, YK901-YL430
D41824PQ	1	BACC10JS14 BACKSHELL-	81205	1	21-25-11 / /	YC001-YC026
D41824PQ	1	BACC10JS14 BACKSHELL-	81205	1	21-25-11 */*/*	YC028-YC030, YK901-YL430
D41826J	1	MTCPQKT1R2SFDA RCPT-	06090	1	21-51-22 E003-03/ /	YC001-YL430
D41826P	1	MTCPQKT1P2PFDA PLUG-	06090	1	21-51-22 E003-03/ /	YC001-YC030, YK901-YL430
D41827J	1	BACC45FN14-15S RECPT-	81205	1	34-51-11 E001-02/ /	YC001-YC030, YK901-YM670
D41827P	1	BACC45FT14-15P PLUG-	81205	1	34-51-11 E001-02/ /	YC001-YC030, YK901-YM670
D41827PQ	1	BACC10JS14 BACKSHELL-	81205	1	34-51-11 / /	YC001-YC030
D41827PQ	1	BACC10JS14 BACKSHELL-	81205	1	34-51-11 */*/*	YK901-YM670
D41828J	1	MTCPQKT1R2SFCD RCPT-	06090	1	21-51-22 E004-01/ /	YC001-YL430
D41828P	1	MTCPQKT1P2PFCD PLUG-CONDUCTIVE	06090	1	21-51-22 E004-01/ /	YC001-YC030, YK901-YL430
D41830J	1	MTCPQKT1R2SFDA RCPT-	06090	1	21-51-22 E004-01/ /	YC001-YC007
D41830J	1	MTCPQKT2R2SFDA RCPT-	06090	1	21-51-22 E004-01/ /	YC008-YC026

EQUIPMENT LIST

D280A103

Section D41800

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41830J	1	MTCPQKT2R22SFDA RCPT-	06090	1	21-31-23 E004-01/ /	YC028-YM670
D41830P	1	MTCPQKT1P2PFDA PLUG-	06090	1	21-51-22 E004-01/ /	YC001-YC007
D41830P	1	MTCPQKT2P22PFDA PLUG-	06090	1	21-51-22 E004-01/ /	YC008-YL430
D41830P	1	MTCPQKT2P22PFDA PLUG-	06090	1	21-31-23 E004-01/ /	YM643-YM670
D41831J	1	BACC45FN16-10P6 RCPT	81205	1	23-12-11 E001-03/ /	ALL
D41831P	1	BACC45FT16-10S6 PLUG E1-3 SHELF	81205	1	23-12-11 E001-03/ /	YC001-YC030, YK901-YM670
D41832J	1	BACC45FN18-31S9 RCPT-	81205	1	21-51-22 P006-00/ /	YC001-YL430
D41832P	1	BACC45FT18-31P9 PLUG-	81205	1	21-51-22 P006-00/ /	YC001-YL430
D41833J	1	BACC63CC14-12P8 RCPT - CONDUCTIVE	81205	1	31-62-11 P009-00/ /	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D41833JK	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	31-62-11 */ */	YC001-YC007
D41833JK	1	BACC10KD14 BACKSHELL - CONDUCTIVE	81205	1	31-62-11 */ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D41833P	1	BACC63CB14-12S8 PLUG	81205	1	31-62-11 P009-00/ /	YC001-YC030, YK901-YM670
D41833PQ	1	BACC10KD14 BACKSHELL - CONDUCTIVE, STRAIGHT	81205	1	31-62-11 P001-00/ /	YC001-YC030
D41833PQ	1	BACC10KD14 BACKSHELL - CONDUCTIVE, STRAIGHT	81205	1	31-62-11 */ */	YK901-YM670

EQUIPMENT LIST

D280A103

Section D41800

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41834J	1	S280W557-241 RCPT-	81205	1	21-61-14 MULTI/ /	YC001-YC026
D41834J	1	BACC65AK241P RCPT-	81205	1	21-61-14 MULTI/ /	YC028-YL430
D41834P	1	S280W557-141 PLUG-	81205	1	21-61-13 727G+17/289/R036	YC001-YC026
D41834P	1	BACC65AJ141S PLUG-	81205	1	21-61-13 727G+17/289/R036	YC028-YL430
D41836J	1	BACC45FN14-4S8 RCPT-	81205	1	21-25-11 E003-03/ /	YC001-YL430
D41836P	1	BACC45FT14-4P8 PLUG-	81205	1	21-25-11 E003-03/ /	YC001-YL430
D41836PQ	1	BACC10JS14 BACKSHELL-	81205	1	21-25-11 */**	YC001-YL430
D41837J	1	BACC45FN14-12P6 RCPT - POWER	81205	1	31-62-11 E003-01/ /	YC001-YC030, YK901-YM670
D41837P	1	BACC45FT14-12S6 PLUG E3-1 SHELF	81205	1	31-62-11 E003-01/ /	ALL
D41837PQ	1	BACC10JS14 BACKSHELL-	81205	1	31-62-11 */**	ALL
D41838J	1	BACC45FN10-5P7 RCPT-	81205	1	21-61-51 AB0340B/ /	YC001-YL430
D41838P	1	BACC45FT10-5S7 PLUG-	81205	1	21-61-51 AB0340B/ /	YC001-YL430
D41839J	1	BACC45FN12-12P6 RCPT-	81205	1	27-32-11 E003-02/ /	ALL
D41839P	1	BACC45FT12-12S6 PLUG E3-2 SHELF	81205	1	27-32-11 E003-02/ /	ALL
D41839PQ	1	BACC10JS12 BACKSHELL-	81205	1	27-32-11 */**	ALL
D41840J	1	MTCPQKT1R2SFCD RCPT-	06090	1	26-16-21 E002-02/ /	YC001-YC030, YK901-YM670
D41840P	1	MTCPQKT1P2PFCD PLUG-	06090	1	26-16-22 AE0202A/ /	YC001-YL430

EQUIPMENT LIST

D280A103

Section D41800

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41840P	1	MTCPQKT1P2PFCD PLUG-	06090	1	26-16-22 E002-02/ /	YM643-YM670
D41842J	1	MTCPQKT1R2SFBD RCPT-	06090	1	21-61-11 E003-03/ /	YC001-YL430
D41842P	1	MTCPQKT1P2PFBD PLUG-	06090	1	21-61-11 E003-03/ /	YC001-YC030, YK901-YL430
D41850J	1	BACC45FN14-7P6 RECP-	81205	1	28-22-11 AB0500DR/ /	ALL
D41850P	1	BACC45FT14-7S6 PLUG-	81205	1	28-22-11 AB0500DR/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D41852J	1	BACC45FN14-15S RECP-	81205	1	28-43-11 AB0500DL/ /	ALL
D41852P	1	BACC45FT14-15P PLUG	81205	1	28-43-11 AB0500DL/ /	ALL
D41854J	1	BACC45FN14-7S RECP-	81205	1	28-43-11 AB0500DL/ /	ALL
D41854P	1	BACC45FT14-7P PLUG-	81205	1	28-43-11 AB0500DL/ /	ALL
D41854PQ	1	BACC10JS14 BACKSHELL-	81205	1	28-43-11 / /	YC001-YC028
D41854PQ	1	BACC10JS14 BACKSHELL-	81205	1	28-43-11 */*/*	YC029-YM670
D41856J	1	BACC45FN14-7S RECP-	81205	1	28-22-11 AB0500DR/ /	ALL
D41856P	1	BACC45FT14-7P PLUG-	81205	1	28-43-11 AB0500DR/ /	ALL

EQUIPMENT LIST

D280A103

Section D41800
Page 7 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42002J	1	AMC02RA03W RCPT-	05574	1	33-22-31 427/296/L019	YC001-YC030, YK901-YM670
D42002P	1	AMC02PA03W PLUG-	05574	1	33-22-21 427/296/L019	YC001-YC026
D42002P	1	AMC02PA03W PLUG-	05574	1	33-22-31 427/296/L019	YC028-YM670
D42004J	1	AMC02RA03W RCPT-	05574	1	33-22-31 713/296/R020	YC001-YC030, YK901-YM670
D42004P	1	AMC02PA03W PLUG-	05574	1	33-22-21 711/296/R020	YC001-YC026
D42004P	1	AMC02PA03W PLUG-	05574	1	33-22-31 711/296/R020	YC028-YM670
D42005J	1	MTCPQKT1R2PGCB RCPT - CONDUCTIVE	06090	1	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670
D42005P	1	MTCPQKT1P2SGCB PLUG E3-1 SHELF	06090	1	34-57-11 E003-01/ /	ALL
D42006J	1	AMC02RA03W RCPT-	05574	1	33-22-32 865/299/R020	YC001-YC030
D42006P	1	AMC02PA03W PLUG-	05574	1	33-22-22 865/299/R020	YC001-YC026
D42006P	1	AMC02PA03W PLUG-	05574	1	33-22-32 865/299/R020	YC028-YC050
D42007J	1	MTCPQKT1R2PGAC RCPT - CONDUCTIVE	06090	1	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D42007P	1	MTCPQKT1P2SGAC PLUG E3-1 SHELF	06090	1	34-57-21 E003-01/ /	ALL
D42008J	1	BACC45FN14-12P6 RCPT-	81205	1	33-22-31 AB0340B/ /	YC001-YC030, YK901-YM670
D42008P	1	BACC45FT14-12S6 PLUG-	81205	1	33-22-11 AB0340B/ /	YC001-YC030, YK901-YM670
D42008PQ	1	BACC10JS14 BACKSHELL-	81205	1	33-22-11 */*/*	YC001-YC030, YK901-YM670
D42010J	1	AMC02RA03W RCPT-	05574	1	33-22-21 500C/295/L024	YK901-YL430

EQUIPMENT LIST

D280A103

Section D42000

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42010P	1	AMC02PA03W PLUG-	05574	1	33-22-21 500C/295/L024	YK901-YL430
D42014J	1	MTCPQKT1R2SFCC RCPT-	06090	1	26-16-22 E002-02/ /	YC001-YC030, YK901-YM670
D42014P	1	MTCPQKT1P2PFCC PLUG-	06090	1	26-16-21 E002-02/ /	ALL
D42053J	1	MTCPQKT1R2PGCA RCPT-CONDUCTIVE	06090	1	27-18-11 E003-02/ /	ALL
D42053P	1	MTCPQKT1P2SGCA PLUG-CONDUCTIVE	06090	1	27-18-11 E003-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D42000
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42100J	1	BACC63BV20F28S7 RECPT-CONDUCTIVE	81205	1	22-11-31 722/202/L033	YC001-YC030
D42100J	1	BACC63BV20B28S7 RECPT-CONDUCTIVE	81205	1	22-11-31 722/202/L033	YC031-YK906, YM643-YM670
D42100J	1	BACC63BV20B39S7 RECPT-CONDUCTIVE	81205	1	22-11-31 722/202/L033	YK907-YL430
D42100JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YC001-YC028
D42100JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */*/*	YC029-YC030
D42100JK	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */*/*	YC031-YM670
D42100P	1	BACC63BP20C28P7 PLUG-CONDUCTIVE	81205	1	27-18-11 722/201/L35	YC001-YC028
D42100P	1	BACC63BP20C28P7 PLUG-CONDUCTIVE	81205	1	27-18-11 722/201/L035	YC029-YC030
D42100P	1	BACC63BP20D28P7 PLUG-CONDUCTIVE	81205	1	27-18-11 722/201/L035	YC031-YK906, YM643-YM670
D42100P	1	BACC63BP20D39P7 PLUG-CONDUCTIVE	81205	1	27-18-11 722/201/L035	YK907-YL430
D42100PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-18-11 / /	YC001-YC028
D42100PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-18-11 */*/*	YC029-YC030
D42100PQ	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	27-18-11 */*/*	YC031-YM670
D42102J	1	BACC63BV20F28S6 RECPT-CONDUCTIVE	81205	1	22-11-31 718/201/L033	YC001-YC030
D42102J	1	BACC63BV20B28S6 RECPT-CONDUCTIVE	81205	1	22-11-31 718/201/L033	YC031-YM670
D42102JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 718/201/L033	YC001-YC028
D42102JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */*/*	YC029-YC030

EQUIPMENT LIST

D280A103

Section D42100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42102JK	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */**	YC031-YL430
D42102JK	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 718/201/L033	YM643-YM670
D42102P	1	BACC63BP20C28P6 PLUG-CONDUCTIVE	81205	1	22-11-31 720/201/L34	YC001-YC028
D42102P	1	BACC63BP20C28P6 PLUG-CONDUCTIVE	81205	1	22-11-31 720/201/L034	YC029-YC030
D42102P	1	BACC63BP20D28P6 PLUG-CONDUCTIVE	81205	1	22-11-31 720/201/L034	YC031-YM670
D42102PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YC001-YC028
D42102PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */**	YC029-YC030
D42102PQ	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */**	YC031-YM670
D42104J	1	BACC63BV20F28SN RCPT-CONDUCTIVE	81205	1	27-52-11 AB0727L/189/L039	YC001-YC007
D42104J	1	BACC63BV20F28SN RCPT-CONDUCTIVE	81205	1	27-52-11 AB0727L/ /	YC008-YM670
D42104JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-52-11 / /	ALL
D42104P	1	BACC63BP20C28PN PLUG-CONDUCTIVE	81205	1	27-52-11 AB0727L/187/L039	YC001-YC028
D42104P	1	BACC63BP20C28PN PLUG-CONDUCTIVE	81205	1	27-52-11 AB0727L/ /	YC029-YM670
D42104PQ	1	BACC10KE20 BACKSHELL-CONDUCTIVE	81205	1	27-32-21 / /	YC001-YC028
D42104PQ	1	BACC10KE20 BACKSHELL-CONDUCTIVE	81205	1	27-32-21 */**	YC029-YM670
D42111J	1	MTCPQKT1R2PFAA RCPT	06090	1	22-11-12 E004-02/ /	YC001-YC003, YC008-YM670
D42111J	1	MTCPQKT1R2PFAA RCPT-CONDUCTIVE	06090	1	22-11-12 E004-02/ /	YC004-YC007

EQUIPMENT LIST

D280A103

Section D42100

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42111P	1	MTCPQKT1P2SFAA PLUG-	06090	1	22-11-12 E004-02/ /	ALL
D42163J	1	MTCPQKT1R2PGAB RCPT - CONDUCTIVE	06090	1	34-57-11 E003-01/ /	YC001-YC030, YK901-YM670
D42163P	1	MTCPQKT1P2SGAB PLUG E3-1 SHELF	06090	1	34-57-11 E003-01/ /	ALL
D42165J	1	MTCPQKT1R2PGDD RCPT - CONDUCTIVE	06090	1	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D42165P	1	MTCPQKT1P2SGDD PLUG E3-1 SHELF	06090	1	34-57-21 E003-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D42100
Page 3 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42261J	1	MTCPQKT2R22PGAC RCPT-CONDUCTIVE	06090	1	34-61-18 E003-02/ /	ALL
D42261P	1	MTCPQKT2P22SGAC PLUG-CONDUCTIVE	06090	1	34-61-18 E003-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D42200
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42311J	1	MTCPQKT1R2PGBB RECPT-CONDUCTIVE	06090	1	31-31-14 E001-01/ /	ALL
D42311P	1	MTCPQKT1P2SGBB PLUG-CONDUCTIVE	06090	1	31-31-14 E001-01/ /	YC001-YC030, YK901-YM670
D42361J	1	MTCPQKT2R22PGBA RCPT-CONDUCTIVE	06090	1	31-31-15 E003-02/ /	ALL
D42361P	1	MTCPQKT2P22SGBA PLUG-CONDUCTIVE	06090	1	31-31-15 E003-02/ /	YC001-YC030, YK901-YM670
D42363J	1	MTCPQKT1R2PGDC RCPT-CONDUCTIVE	06090	1	27-18-11 E003-02/ /	ALL
D42363P	1	MTCPQKT1P2SGDC PLUG-CONDUCTIVE	06090	1	27-18-11 E003-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D42300
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42400J	1	BACC45FN14-4S8 RCPT-	81205	1	30-41-12 E004-02/ /	ALL
D42400P	1	BACC45FT14-4P8 PLUG-	81205	1	30-41-12 E004-02/ /	ALL
D42400PQ	1	BACC10JS14 BACKSHELL-	81205	1	30-41-12 / /	YC001-YC026
D42400PQ	1	BACC10JS14 BACKSHELL-	81205	1	30-41-12 */*/	YC028-YM670

EQUIPMENT LIST

D280A103

Section D42400
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42941J	1	121-44-9 RECP - (C) STRAIGHT	91836	1	34-58-11 E001-02/ /	YC001-YC030, YK901-YM670
D42941P	1	125-88-9 PLUG-COAX	91836	1	34-58-11 E001-02/ /	YC001-YC030, YK901-YM670
D42943J	1	121-44-9 RECP - (C) STRAIGHT	91836	1	34-58-21 E001-02/ /	ALL
D42943P	1	125-88-9 PLUG - (TNC) STRAIGHT	91836	1	34-58-21 E001-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D42900

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43008J	1	MTCPQKT1R2SFDB RCPT-	06090	1	27-53-11 E002-02/ /	YC001-YC030, YK901-YM670
D43008P	1	MTCPQKT1P2PFDB PLUG	06090	1	27-53-11 E2-2 391/186/L33	YC001-YC007
D43008P	1	MTCPQKT1P2PFDB PLUG	06090	1	27-53-11 AE0202A/ /	YC008-YM670
D43010J	1	BACC45FN20-25S8 RCPT	81205	1	32-64-12 E001-03/ /	ALL
■ D43010P	1	BACC45FT20-25P8 PLUG	81205	1	32-42-11 E001-03/ /	ALL
D43016J	1	BACC63CC16-24P7 RCPT-CONDUCTIVE	81205	1	32-44-11 E001-04/ /	YC001-YC030, YK901-YM670
D43016JK	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	32-44-11 */*/*	YC001-YC030, YK901-YM670
D43016P	1	BACC63CB16-24S7 PLUG - CONDUCTIVE	81205	1	32-44-11 E001-04/ /	ALL
D43016PQ	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	32-41-11 E001-04/ /	YC001-YC050
D43016PQ	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	32-41-11 */*/*	YK901-YM670
D43018J	1	MTCPQKT2R22SFBD RCPT-	06090	1	21-51-11 E004-01/ /	YC001-YC007
D43018J	1	MTCPQKT1R2SFBD RCPT-	06090	1	21-51-11 E004-01/ /	YC008-YM670
D43018P	1	MTCPQKT2P22PFBD PLUG-	06090	1	21-51-11 E004-01/ /	YC001-YC007
D43018P	1	MTCPQKT1P2PFBD PLUG-	06090	1	21-51-11 E004-01/ /	YC008-YC030, YK901-YM670
■ D43022J	1	MTCPQKT2R22SGBD RCPT-CONDUCTIVE	06090	1	32-41-11 E003-02/ /	ALL
■ D43022P	1	MTCPQKT2P22PGBD PLUG	06090	1	32-41-11 E003-02/ /	ALL
D43024J	1	MTCPQKT2R22SFBD RCPT-	06090	1	32-41-11 E002-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D43000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43024P	1	MTCPQKT2P22PFBD PLUG	06090	1	32-41-11 E002-02/ /	ALL
D43028J	1	MTCPQKT2R26SFAD RCPT	06090	1	27-41-12 E004-02/ /	ALL
D43028P	1	MTCPQKT2P26PFAD PLUG	06090	1	27-41-12 E004-02/ /	ALL
D43030J	1	MTCPQKT1R2PFDA RCPT-	06090	1	31-53-11 E003-02/ /	ALL
D43030P	1	MTCPQKT1P2SFDA PLUG	06090	1	31-53-11 E003-02/ /	ALL
D43038J	1	MTCPQKT2R22SFDA RCPT-	06090	1	21-25-11 E004-01/ /	ALL
D43038P	1	MTCPQKT2P22PFDA PLUG-CONDUCTIVE	06090	1	21-25-11 E004-01/ /	ALL
D43040J	1	BACC63CC16-24SN RCPT	81205	1	32-64-12 E001-03/ /	ALL
D43040P	1	BACC63CB16-24PN PLUG-CONDUCTIVE	81205	1	74-11-11 E001-03/ /	ALL
D43040PQ	1	BACC10KD16 BACKSHELL-	81205	1	74-11-11 */*/*	ALL
D43044J	1	MTCPQKT1R2SGAA RCPT-	06090	1	21-51-21 E004-01/ /	ALL
D43044P	1	MTCPQKT1P2PGAA PLUG	06090	1	21-51-21 E004-01/ /	ALL
D43046J	1	MTCPQKT1R2SGCB RCPT-CONDUCTIVE	06090	1	29-33-11 E003-02/ /	ALL
D43046P	1	MTCPQKT1P2PGCB PLUG-	06090	1	29-33-11 E003-02/ /	ALL
D43048J	1	BACC45FN14-15S7 RCPT	81205	1	29-32-11 E001-03/ /	ALL
D43048P	1	BACC45FT14-15P7 PLUG	81205	1	32-41-11 E001-03/ /	ALL
D43050J	1	MTCPQKT1R2SFBB RCPT-	06090	1	49-62-11 E002-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D43000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43050P	1	MTCPQKT1P2PFBB PLUG	06090	1	49-62-11 E002-02/ /	ALL
D43054J	1	MTCPQKT2R22SFBB RCPT-	06090	1	78-34-21 E003-02/ /	ALL
D43054P	1	MTCPQKT2P22PFBB PLUG	06090	1	78-34-21 E003-02/ /	ALL
D43060J	1	BACC63CC14-12S8 RCPT-CONDUCTIVE	81205	1	33-42-11 E002-02/ /	YC001-YC030, YK901-YM670
D43060P	1	BACC63CB14-12P8 PLUG-CONDUCTIVE	81205	1	33-42-11 / /	YC001-YC007
D43060P	1	BACC63CB14-12P8 PLUG-CONDUCTIVE	81205	1	33-42-11 391/186/L035	YC008-YM670
D43060PQ	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	33-42-11 / /	YC001-YL430
D43060PQ	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	33-42-11 */*/*	YM643-YM670
D43062J	1	MTCPQKT2R26SFCA RCPT-	06090	1	33-42-11 E004-01/ /	ALL
D43062P	1	MTCPQKT2P26PFCA PLUG-CONDUCTIVE	06090	1	33-42-11 E004-01/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D43080J	1	MTCPQKT1R2SFDD RCPT-	06090	1	77-31-21 E003-02/ /	ALL
D43080P	1	MTCPQKT1P2PFDD PLUG-	06090	1	77-31-21 E003-02/ /	ALL
D43084J	1	BACC45FN18-8P9 RECP-	81205	1	49-41-11 E002-02/ /	YC001-YC030, YK901-YM670
D43084P	1	BACC45FT18-8S9 PLUG-	81205	1	49-11-11 E2-2 391/187/L41	YC001-YC030, YM643-YM652
D43084P	1	BACC45FT18-8S9 PLUG-	81205	1	49-11-11 AE0202A/ /	YC031-YK912, YK918-YK919, YL401-YL429
D43084PQ	1	BACC10GH18 BACKSHELL-	81205	1	49-11-11 / /	YC001-YK910, YL421-YL423

EQUIPMENT LIST

D280A103

Section D43000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43084PQ	1	BACC10GH18 BACKSHELL-	81205	1	49-11-11 */*/	YK911-YK912, YK918-YK919, YL401, YL424- YL429, YM645- YM652
D43084PQ	1	BACC10GH18 BACKSHELL-	81205	1	49-11-11 E2-2 391/187/L41	YM643

EQUIPMENT LIST

D280A103

Section D43000
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43100J	1	BACC63BV20F28SN RECPT-CONDUCTIVE	81205	1	22-11-31 720/202/R033	YC001-YC030
D43100J	1	BACC63BV20B28SN RECPT-CONDUCTIVE	81205	1	22-11-31 720/202/R033	YC031-YK906, YM643-YM670
D43100J	1	BACC63BV20B39SN RECPT-CONDUCTIVE	81205	1	22-11-31 720/202/R033	YK907-YL430
D43100JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YC001-YC028
D43100JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */*/*	YC029-YC030
D43100JK	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */*/*	YC031-YL430
D43100JK	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YM643-YM670
D43100P	1	BACC63BP20C28PN PLUG-CONDUCTIVE	81205	1	27-18-11 724/201/R33	YC001-YC028
D43100P	1	BACC63BP20C28PN PLUG-CONDUCTIVE	81205	1	27-18-11 724/201/R033	YC029-YC030
D43100P	1	BACC63BP20D28PN PLUG-CONDUCTIVE	81205	1	27-18-11 724/201/R033	YC031-YK906, YM643-YM670
D43100P	1	BACC63BP20D39PN PLUG-CONDUCTIVE	81205	1	27-18-11 724/201/R033	YK907-YL430
D43100PQ	1	BACC10KD20 BACKSHELL, STRAIGHT	81205	1	27-18-11 / /	YC001-YC028
D43100PQ	1	BACC10KD20 BACKSHELL, STRAIGHT	81205	1	27-18-11 */*/*	YC029-YC030
D43100PQ	1	BACC10KA20 BACKSHELL, STRAIGHT	81205	1	27-18-11 */*/*	YC031-YM670
D43102J	1	BACC63BV20F16S6 RECPT-CONDUCTIVE	81205	1	22-11-21 722/202/R033	YC001-YC030
D43102J	1	BACC63BV20B16S6 RECPT-CONDUCTIVE	81205	1	22-11-21 722/202/R033	YC031-YM670
D43102JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YC001-YC028

EQUIPMENT LIST

D280A103

Section D43100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43102JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */**	YC029-YC030
D43102JK	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */**	YC031-YM670
D43102P	1	BACC63BP20C16P6 PLUG-CONDUCTIVE	81205	1	22-11-31 720/201/R25	YC001-YC028
D43102P	1	BACC63BP20C16P6 PLUG-CONDUCTIVE	81205	1	22-11-31 720/201/R025	YC029-YC030
D43102P	1	BACC63BP20D16P6 PLUG-CONDUCTIVE	81205	1	22-11-31 720/201/R025	YC031-YM670
D43102PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 / /	YC001-YC028
D43102PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */**	YC029-YC030
D43102PQ	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	22-11-31 */**	YC031-YM670
D43104J	1	BACC63BV20F28SN RCPT-CONDUCTIVE	81205	1	27-52-11 727+2/193/R043	ALL
D43104JK	1	BACC10KE20 BACKSHELL-CONDUCTIVE	81205	1	27-52-11 / /	ALL
D43104P	1	BACC63BP20C28PN PLUG-CONDUCTIVE	81205	1	27-52-11 727+2/191/R043	ALL
D43104PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-32-11 / /	YC001-YC028
D43104PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-32-11 */**	YC029-YM670
D43145J	1	MTCPQKT2R22SGDA RCPT - CONDUCTIVE	06090	1	34-61-12 E003-01/ /	YC001-YC030, YK901-YM670
D43145P	1	MTCPQKT2P22PGDA PLUG	06090	1	34-61-12 E003-01/ /	ALL
D43147J	1	MTCPQKT2R22SGBB RCPT - CONDUCTIVE	06090	1	34-61-12 E003-01/ /	YC001-YC030, YK901-YM670
D43147P	1	MTCPQKT2P22PGBB PLUG	06090	1	34-61-12 E003-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D43100

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43155J	1	MTCPQKT2R22SGDB RCPT - CONDUCTIVE	06090	1	34-61-12 E003-01/ /	YC001-YC030, YK901-YM670
D43155P	1	MTCPQKT2P22PGDB PLUG	06090	1	34-61-12 E003-01/ /	ALL
D43157J	1	MTCPQKT2R22SGBC RCPT - CONDUCTIVE	06090	1	34-61-12 E003-01/ /	YC001-YC030, YK901-YM670
D43157P	1	MTCPQKT2P22PGBC PLUG	06090	1	34-61-12 E003-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D43100
Page 3 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43203J	1	MTCPQKT1R2PGCC RCPT-CONDUCTIVE	06090	1	31-31-14 E003-02/ /	ALL
D43203P	1	MTCPQKT1P2SGCC PLUG-CONDUCTIVE	06090	1	31-31-14 E003-02/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D43205J	1	MTCPQKT1R2PGDD RCPT-CONDUCTIVE	06090	1	31-31-14 E003-02/ /	ALL
D43205P	1	MTCPQKT1P2SGDD PLUG-CONDUCTIVE	06090	1	31-31-14 E003-02/ /	ALL
D43209J	1	MTCPQKT1R2SGCC RCPT-CONDUCTIVE	06090	1	31-31-11 E003-02/ /	ALL
D43209P	1	MTCPQKT1P2PGCC PLUG-CONDUCTIVE	06090	1	31-31-11 E003-02/ /	ALL
D43211J	1	MTCPQKT2R2PGAA RECPT-CONDUCTIVE	06090	1	31-31-13 E001-01/ /	ALL
D43211P	1	MTCPQKT2P2SGAA PLUG-CONDUCTIVE	06090	1	31-31-13 E001-01/ /	YC001-YC030, YK901-YM670
D43215J	1	MTCPQKT1R2SGCA RCPT-CONDUCTIVE	06090	1	31-31-12 E003-02/ /	YC001-YC050
D43215J	1	MTCPQKT1R2SGCA RCPT-CONDUCTIVE	06090	1	31-33-01 E003-02/ /	YK901-YM670
D43215P	1	MTCPQKT1P2PGCA PLUG - CONDUCTIVE	06090	1	31-33-01 E003-02/ /	ALL
D43217J	1	MTCPQKT1R2PGCD RCPT-CONDUCTIVE	06090	1	31-35-03 E003-02/ /	YK910-YK920, YL421-YM670
D43217P	1	MTCPQKT1P2SGCD PLUG-CONDUCTIVE	06090	1	31-35-03 E003-02/ /	YK910-YK920, YL421-YM670
D43219J	1	MTCPQKT1R2PGDA RCPT-CONDUCTIVE	06090	1	31-31-11 E003-02/ /	ALL
D43219P	1	MTCPQKT1P2SGDA PLUG-CONDUCTIVE	06090	1	31-31-11 E003-02/ /	ALL
D43257J	1	MTCPQKT1R2SFCD RCPT-	06090	1	31-31-14 E003-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D43200

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43257P	1	MTCPQKT1P2PFCD PLUG-	06090	1	31-31-14 E003-02/ /	ALL
D43261J	1	MTCPQKT2R22PGAB RCPT-CONDUCTIVE	06090	1	31-31-12 E003-02/ /	ALL
D43261P	1	MTCPQKT2P22SGAB PLUG-CONDUCTIVE	06090	1	31-31-12 E003-02/ /	YC001-YC030, YK901-YM670
D43263J	1	MTCPQKT2R22PGBB RCPT-CONDUCTIVE	06090	1	27-28-11 E003-02/ /	ALL
D43263P	1	MTCPQKT2P22SGBB PLUG-CONDUCTIVE	06090	1	27-28-11 E003-02/ /	ALL
D43267J	1	BACC63CC14-15PN RCPT-	81205	1	31-31-11 916/295/L003	ALL
D43267P	1	BACC63CB14-15SN PLUG	81205	1	31-31-11 916/295/L003	ALL
D43267PQ	1	BACC10KD14 BACKSHELL	81205	1	31-31-11 / /	YC001-YL430
D43267PQ	1	BACC10KD14 BACKSHELL	81205	1	31-31-11 */*/*	YM643-YM670
D43277J	1	MTCPQKT1R2PGAA RCPT-CONDUCTIVE	06090	1	23-32-21 E003-02/ /	YC001-YC050
D43277P	1	MTCPQKT1P2SGAA PLUG	06090	1	23-32-21 390/189/L014	YC001-YC050

EQUIPMENT LIST

D280A103

Section D43200
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43301J	1	2431-84-1 RECPT - COAX, VHF 3 ANTENNA	91836	1	23-12-31 E003-03/ /	YC001-YC030, YK901-YM670
D43301P	1	2435-84-1 PLUG E3-3 SHELF	91836	1	23-12-31 E003-03/ /	YC001-YC007
D43301P	1	2435-84-1 PLUG	91836	1	23-12-31 E003-03/ /	YC008-YM670
D43305J	1	MTCPQKT1R2PGAA RECPT - CONDUCTIVE	06090	1	31-62-15 E003-03/ /	YC001-YC030, YK901-YM670
D43305P	1	MTCPQKT1P2SGAA PLUG - CONDUCTIVE	06090	1	23-27-11 E003-03/ /	YC001-YC030, YK901-YM670
D43306J	1	MTCPQKT1R2PGAB RECPT - CONDUCTIVE	06090	1	23-27-37 E003-03/ /	YK901-YM670
D43306P	1	MTCPQKT1P2SGAB PLUG - CONDUCTIVE	06090	1	23-27-37 E003-03/ /	YK901-YM670
D43307J	1	MTCPQKT2R22PGCA RECPT - CONDUCTIVE	06090	1	23-27-11 E003-03/ /	YC001-YC030
D43307J	1	MTCPQKT2R22PGCA RECPT - CONDUCTIVE	06090	1	23-27-38 E003-03/ /	YK901-YM670
D43307P	1	MTCPQKT2P22SGCA PLUG - CONDUCTIVE	06090	1	23-27-11 E003-03/ /	YC001-YC030, YK901-YM670
D43309J	1	BACC45FN14-12P6 RECPT-	81205	1	23-27-11 E003-03/ /	YC001-YC030
D43309J	1	BACC45FN14-12P6 RECPT-	81205	1	23-12-31 E003-03/ /	YK901-YM670
D43309P	1	BACC45FT14-12S6 PLUG-	81205	1	23-12-31 E003-03/ /	ALL
D43309PQ	1	BACC10JS14 BACKSHELL-	81205	1	23-12-31 */*/*	ALL
D43313J	1	BACC45FN14-12P RECPT-	81205	1	23-27-11 E003-03/ /	YC001-YC030
D43313J	1	BACC45FN14-12P RECPT-	81205	1	23-27-31 E003-03/ /	YK901-YM670
D43313P	1	BACC45FT14-12S PLUG-	81205	1	23-27-11 E003-03/ /	ALL

EQUIPMENT LIST

D280A103

Section D43300

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43313PQ	1	BACC10JS14 BACKSHELL-	81205	1	23-27-11 */*/*	ALL
D43314J	1	MTCPQKT1R2SGBA RECPT - CONDUCTIVE	06090	1	23-12-11 E003-03/ /	YK910-YL401, YL430, YM652- YM670
D43314P	1	MTCPQKT1P2PGBA PLUG - CONDUCTIVE	06090	1	23-12-21 E003-03/ /	YK910-YL401, YL430, YM652- YM670
D43315J	1	MTCPQKT1R2PGAC RECPT - CONDUCTIVE	06090	1	23-27-11 E003-03/ /	YC001-YC030
D43315P	1	MTCPQKT1P2SGAC PLUG-CONDUCTIVE	06090	1	23-27-11 E003-03/ /	YC001-YC030
D43317J	1	MTCPQKT2R22SGCB RECPT-CONDUCTIVE	06090	1	34-53-21 E001-01/ /	ALL
D43317P	1	MTCPQKT2P22PGCB PLUG - CONDUCTIVE	06090	1	34-53-21 E001-01/ /	YC001-YC030, YK901-YM670
D43319J	1	MTCPQKT1R2PGAD RECPT - CONDUCTIVE	06090	1	23-27-13 E003-03/ /	YC001-YC030
D43319J	1	MTCPQKT1R2PGAD RECPT - CONDUCTIVE	06090	1	23-27-33 E003-03/ /	YK901-YM670
D43319P	1	MTCPQKT1P2SGAD PLUG - CONDUCTIVE	06090	1	23-27-13 E003-03/ /	YC001-YC050
D43319P	1	MTCPQKT1P2SGAD PLUG - CONDUCTIVE	06090	1	23-27-33 E003-03/ /	YK901-YM670
D43321J	1	MTCPQKT2R22PGCB RECPT - CONDUCTIVE	06090	1	23-27-11 E003-03/ /	YC001-YC030
D43321J	1	MTCPQKT2R22PGCB RECPT - CONDUCTIVE	06090	1	23-27-31 E003-03/ /	YK901-YM670
D43321P	1	MTCPQKT2P22SGCB PLUG - CONDUCTIVE	06090	1	23-27-11 E003-03/ /	YC001-YC030, YK901-YM670
D43323J	1	MTCPQKT1R2PGCB RECPT - CONDUCTIVE	06090	1	34-61-21 E003-03/ /	YC001-YC030
D43323J	1	MTCPQKT2R22PGAC RECPT - CONDUCTIVE	06090	1	23-27-31 E003-03/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D43300

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43323P	1	MTCPQKT1P2SGCB PLUG - CONDUCTIVE	06090	1	34-61-21 E003-03/ /	YC001-YC030
D43323P	1	MTCPQKT2P22SGAC PLUG - CONDUCTIVE	06090	1	34-61-21 E003-03/ /	YK901-YM670
D43329J	1	MTCPQKT2R26SGCD RECPT - CONDUCTIVE	06090	1	23-12-31 E003-03/ /	YK901-YM670
D43329P	1	MTCPQKT2P26PGCD PLUG-CONDUCTIVE	06090	1	23-12-31 E003-03/ /	YK901-YM670
D43331J	1	MTCPQKT2R22PGDC RECPT - CONDUCTIVE	06090	1	23-12-31 E003-03/ /	YK901-YM670
D43331P	1	MTCPQKT2P22SGDC PLUG - CONDUCTIVE	06090	1	23-12-31 E003-03/ /	YK901-YL430
D43331P	1	MTCPQKT2P22SGDC PLUG-CONDUCTIVE	06090	1	23-27-11 D003-03/ /	YM643-YM670
D43333J	1	MTCPQKT1R2PGBA RECPT - CONDUCTIVE	06090	1	23-27-37 E003-03/ /	YK901-YM670
D43333P	1	MTCPQKT1P2SGBA PLUG - CONDUCTIVE	06090	1	23-27-37 E003-03/ /	YK901-YM670
D43345J	1	MTCPQKT2R22SGDB RECPT - CONDUCTIVE	06090	1	23-27-31 E003-03/ /	YK901-YM670
D43345P	1	MTCPQKT2P22PGDB PLUG - CONDUCTIVE	06090	1	23-27-31 E003-03/ /	YK901-YM670
D43347J	1	MTCPQKT2R22SGDC RECPT - CONDUCTIVE	06090	1	23-27-31 E003-03/ /	YK901-YM670
D43347P	1	MTCPQKT2P22PGDC PLUG - CONDUCTIVE	06090	1	23-27-31 E003-03/ /	YK901-YM670
D43355J	1	MTCPQKT1R2SGAA RECPT - CONDUCTIVE	06090	1	23-12-21 E003-03/ /	YK901-YM670
D43355P	1	MTCPQKT1P2PGAA PLUG - CONDUCTIVE	06090	1	23-12-21 E003-03/ /	YK901-YM670
D43357J	1	MTCPQKT1R2SGAB RECPT - CONDUCTIVE	06090	1	23-12-21 E003-03/ /	YK901-YM670
D43357P	1	MTCPQKT1P2PGAB PLUG - CONDUCTIVE	06090	1	23-12-21 E003-03/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D43300

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43359J	1	MTCPQKT1R2SGAC RECPT - CONDUCTIVE	06090	1	23-11-11 E003-03/ /	YK901-YM670
D43359P	1	MTCPQKT1P2PGAC PLUG - CONDUCTIVE	06090	1	23-11-11 E003-03/ /	YK901-YM670
D43361J	1	MTCPQKT1R2SGBC RECPT - CONDUCTIVE	06090	1	23-11-21 E003-03/ /	YK907-YM670
D43361P	1	MTCPQKT1P2PGBC PLUG - CONDUCTIVE	06090	1	23-11-21 E003-03/ /	YK907-YM670
D43363J	1	MTCPQKT1R2SGBA RECPT - CONDUCTIVE	06090	1	23-12-11 E003-03/ /	YK901-YM670
D43363P	1	MTCPQKT1P2PGBA PLUG - CONDUCTIVE	06090	1	23-12-11 E003-03/ /	YK901-YM670
D43365J	1	MTCPQKT1R2SGBB RECPT - CONDUCTIVE	06090	1	23-12-11 E003-03/ /	YK901-YM670
D43365P	1	MTCPQKT1P2PGBB PLUG - CONDUCTIVE	06090	1	23-12-11 E003-03/ /	YK901-YM670
D43367J	1	MTCPQKT1R2SGBD RECPT - CONDUCTIVE	06090	1	23-12-11 E003-03/ /	YK901-YM670
D43367P	1	MTCPQKT1P2PGBD PLUG - CONDUCTIVE	06090	1	23-12-11 E003-03/ /	YK901-YM670
D43379J	1	MTCPQKT2R22PGAD RECPT - CONDUCTIVE	06090	1	23-27-31 E003-03/ /	YK901-YM670
D43379P	1	MTCPQKT2P22SGAD PLUG - CONDUCTIVE	06090	1	23-27-31 E003-03/ /	YK901-YM670
D43387J	1	BACC63BV14F15S6 RCPT-CONDUCTIVE	81205	1	22-23-12 1080/297/L001	ALL
D43387JK	1	BACC10KD14 BACKSHELL	81205	1	22-23-12 / /	YC001-YC007
D43387JK	1	BACC10KD14 BACKSHELL	81205	1	22-23-12 */*/*	YC008-YM670
D43387P	1	BACC63BP14C15P6 PLUG-CONDUCTIVE	81205	1	22-23-12 AB1080/ /	ALL
D43387PQ	1	BACC10KD14 BACKSHELL	81205	1	22-23-12 / /	YC001-YC026

EQUIPMENT LIST

D280A103

Section D43300

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43387PQ	1	BACC10KD14 BACKSHELL	81205	1	22-23-12 */**	YC028-YC030
D43387PQ	1	BACC10KF14 BACKSHELL	81205	1	22-23-12 */**	YC031-YM670
D43389J	1	BACC63BV14F15S7 RCPT-CONDUCTIVE	81205	1	27-24-11 1080/297/L002	ALL
D43389JK	1	BACC10KD14 BACKSHELL	81205	1	27-24-11 / /	YC001-YC007
D43389JK	1	BACC10KD14 BACKSHELL	81205	1	27-24-11 */**	YC008-YM670
D43389P	1	BACC63BP14C15P7 PLUG-CONDUCTIVE	81205	1	27-24-11 AB1080/ /	YC001-YC026
D43389P	1	BACC63BP14C15P7 PLUG-CONDUCTIVE	81205	1	27-24-11 1074/298/R2	YC028-YC030
D43389P	1	BACC63BP14C15P7 PLUG-CONDUCTIVE	81205	1	27-24-11 AB1080/298/R001	YC031-YM670
D43389PQ	1	BACC10KD14 BACKSHELL	81205	1	27-24-11 / /	YC001-YC026
D43389PQ	1	BACC10KD14 BACKSHELL	81205	1	27-24-11 */**	YC028-YC030
D43389PQ	1	BACC10KF14 BACKSHELL	81205	1	27-24-11 */**	YC031-YM670
D43391J	1	MTCPQKT1R2SGAD RECPT - CONDUCTIVE	06090	1	23-12-31 E003-03/ /	YK901-YM670
D43391P	1	MTCPQKT1P2PGAD PLUG- CONDUCTIVE	06090	1	23-12-31 E003-03/ /	YK901-YM670
D43393J	1	BACC63CC16-24P6 RCPT - CONDUCTIVE	81205	1	22-18-11 1046/296/L017	YC008-YM670
D43393JK	1	BACC10KD16 BACKSHELL	81205	1	22-18-11 */**	YC008-YM670
D43393P	1	BACC63CB16-24S6 PLUG - CONDUCTIVE	81205	1	22-18-11 AB1050L/297/L013	YC008-YM670
D43393PQ	1	BACC10KF16 BACKSHELL	81205	1	22-18-11 / /	YC008-YM670

EQUIPMENT LIST

D280A103

Section D43300

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43397J	1	BACC63CC22-55P7 RCPT - CONDUCTIVE	81205	1	22-12-23 AB1050L / /	YC008-YM670
D43397JK	1	BACC10KE22 BACKSHELL	81205	1	22-12-31 * / * / *	YC008-YM670
D43397P	1	BACC63CB22-55S7 PLUG - CONDUCTIVE	81205	1	22-23-12 AB1050L / /	YC008-YM670
D43397PQ	1	BACC10KF22 BACKSHELL	81205	1	22-23-12 / /	YC008-YM670
D43399J	1	BACC63CC22-55P8 RCPT - CONDUCTIVE	81205	1	22-12-41 1052/298/R9	YC008-YM670
D43399JK	1	BACC10KE22 BACKSHELL	81205	1	22-12-41 * / * / *	YC008-YM670
D43399P	1	BACC63CB22-55S8 PLUG - CONDUCTIVE	81205	1	22-12-41 AB1050R / /	YC008-YM670
D43399PQ	1	BACC10KF22 BACKSHELL	81205	1	22-12-41 / /	YC008-YM670

EQUIPMENT LIST

D280A103

Section D43300
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43900J	1	BACI10AL17AP INSERT	81205	1	27-62-11 J039-0A/ /	YK907-YL430
D43900JT	1	BACC65AP2A01 RCPT	81205	1	27-62-11 */**	YK907-YL430
D43900P	1	BACI10AL17AS INSERT	81205	1	27-62-11 J039-0A/ /	YK907-YK912, YK918-YK919, YL401-YL429
D43900PT	1	BACC65AN2A01 PLUG	81205	1	27-62-11 */**	YK907-YK912, YK918-YK919, YL401-YL429
D43906J	1	BACI10AL30AP INSERT	81205	1	27-62-11 J039-0A/ /	YK907-YL430
D43906JT	1	BACC65AP2A04 RCPT	81205	1	27-62-11 */**	YK907-YL430
D43906P	1	BACI10AL30AS INSERT	81205	1	27-62-11 J039-0A/ /	YK907-YL430
D43906PT	1	BACC65AN2A04 PLUG-	81205	1	27-62-11 */**	YK907-YL430
D43908J	1	BACI10AL30AP INSERT	81205	1	27-62-11 J039-0A/ /	YK907-YL430
D43908JT	1	BACC65AP2B05 RCPT	81205	1	27-62-11 */**	YK907-YL430
D43908P	1	BACI10AL30AS INSERT	81205	1	27-62-11 J039-0A/ /	YK907-YL430
D43908PT	1	BACC65AN2B05 PLUG	81205	1	27-62-11 */**	YK907-YL430
D43910J	1	BACI10AL30AP INSERT	81205	1	27-62-11 J039-0A/ /	YK907-YL430
D43910JT	1	BACC65AP2B06 RCPT	81205	1	27-62-11 */**	YK907-YL430
D43910P	1	BACI10AL30AS INSERT	81205	1	27-62-11 J039-0A/ /	YK907-YL430
D43910PT	1	BACC65AN2B06 PLUG	81205	1	27-62-11 J039-0A/**	YK907-YL430

EQUIPMENT LIST

D280A103

Section D43900

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D44139J	1	MTCPQKT1R2SFCC RCPT-	06090	1	23-31-04 E004-01/ /	ALL
D44139P	1	MTCPQKT1P2PFCC PLUG	06090	1	23-31-04 E004-01/ /	ALL
D44161J	1	MTCPQKT2R22PGBD RCPT-	06090	1	34-61-17 E004-01/ /	ALL
D44161P	1	MTCPQKT2P22SGBD PLUG-CONDUCTIVE	06090	1	34-61-17 E004-01/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D44100
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D44252J	1	BACC63BV14B15PN RECP-P19 PNL	81205	1	24-41-11 P019-00/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D44252P	1	BACC63BP14D15SN PLUG-P19 PNL	81205	1	24-41-11 231/186/R034	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D44252PQ	1	BACC10KA14 BACKSHELL	81205	1	24-41-11 */*/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D44276	1	48-7191-1 RECPT	02660	1	27-62-11 192/200/L007	YK907-YK912, YK918-YK919, YL401-YL429
D44278	1	48-7190 PLUG-	82660	1	27-62-11 192/200/L007	YK907-YL430

EQUIPMENT LIST

D280A103

Section D44200

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D44381J	1	BACC63CC20-28P8 RCPT - CONDUCTIVE	81205	1	22-13-11 1051/297/L014	YC008-YC030
D44381J	1	BACC63BV22F19P7 RCPT - CONDUCTIVE	81205	1	22-13-11 AB1050L/296/L017	YK901-YM670
D44381JK	1	BACC10KE20 BACKSHELL	81205	1	22-13-11 */*/*	YC008-YC030
D44381JK	1	BACC10KE22 BACKSHELL	81205	1	22-13-11 */*/*	YK901-YM670
D44381P	1	BACC63CB20-28S8 PLUG - CONDUCTIVE	81205	1	22-13-11 / /	YC008-YC030
D44381P	1	BACC63BP22C19S7 PLUG - CONDUCTIVE	81205	1	22-13-11 AB1050L/ /	YC031-YM670
D44381PQ	1	BACC10KF20 BACKSHELL	81205	1	22-13-11 / /	YC008-YC030
D44381PQ	1	BACC10KF22 BACKSHELL	81205	1	22-13-11 / /	YC031-YM670

EQUIPMENT LIST

D280A103

Section D44300
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
I D44584J	1	BACC63BV14F7PN RCPT-CONDUCTIVE	81205	1	33-35-11 1166/244/R014	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I D44584JK	1	BACC10KD14 BACKSHELL-	81205	1	33-35-11 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D44584P	1	BACC63BP14C7SN PLUG-CONDUCTIVE	81205	1	33-35-11 1166/243/R014	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D44584PQ	1	BACC10KD14 BACKSHELL	81205	1	33-35-11 */*/*	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D44500

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45035J	1	121-40-9 COAX RCPT	91836	1	23-32-21 E008-01/ /	YK901-YK906, YK911-YK917, YK919-YL401, YL427-YL430, YM647-YM670
D45035P	1	125-88-9 PLU - COAX	91836	1	23-32-21 E008-01/ /	YK901-YK906
D45035P	1	125-88-9 PLUG	98136	1	23-32-21 E008-01/ /	YK911-YK917, YK919-YL401, YL427-YL430, YM647-YM670
D45067J	1	MTCPQKT2R22PGBB RCPT-CONDUCTIVE	06090	1	34-61-18 E005-02/ /	YC001-YC030, YK901-YM670
D45067P	1	MTCPQKT2P22SGBB PLUG-	06090	1	34-61-11 E005-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D45000
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45111J	1	MTCPQKT2R22SGBA RCPT - CONDUCTIVE	06090	1	34-31-11 E003-01/ /	YC001-YC030, YK901-YM670
D45111P	1	MTCPQKT2P22PGBA PLUG - CONDUCTIVE	06090	1	34-31-11 E003-01/ /	YC001-YC030, YK901-YM670
D45113J	1	MTCPQKT2R22SGDC RECPT-CONDUCTIVE	06090	1	34-31-11 E001-01/ /	ALL
D45113P	1	MTCPQKT2P22PGDC PLUG - CONDUCTIVE	06090	1	34-31-11 E001-01/ /	YC001-YC030, YK901-YM670
D45115J	1	BACC63CC22-55P6 RECPT - CONDUCTIVE	81205	1	34-31-11 E001-02/ /	YC001-YC030, YK901-YM670
D45115JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-31-11 E001-02/ /	YC001-YC030
D45115JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-31-11 */**	YK901-YM670
D45115P	1	BACC63CB22-55S6 PLUG-CONDUCTIVE	81205	1	22-11-51 E001-02/ /	YC001-YC030, YK901-YM670
D45115PQ	1	BACC10KF22 BACKSHELL	81205	1	34-45-02 E001-02/ /	YC001-YC030
D45115PQ	1	BACC10KF22 BACKSHELL	81205	1	34-45-02 */**	YK901-YM670
D45117J	1	MTCPQKT2R22SGAD RCPT-CONDUCTIVE	06090	1	34-31-11 E003-02/ /	ALL
D45117P	1	MTCPQKT2P22PGAD PLUG - CONDUCTIVE	06090	1	34-31-11 E003-02/ /	YC001-YC030, YK901-YM670
D45121J	1	MTCPQKT2R22SGCB RCPT - CONDUCTIVE	06090	1	34-51-21 E003-01/ /	YC001-YC030, YK901-YM670
D45121P	1	MTCPQKT2P22PGCB PLUG - CONDUCTIVE	06090	1	34-51-21 E003-01/ /	YC001-YC030, YK901-YM670
D45123J	1	BACC63CC22-55P7 RECP - CONDUCTIVE	81205	1	34-31-11 E001-04/ /	YC001-YC030, YK901-YM670
D45123JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-31-21 */**	YC001-YC030, YK901-YM670
D45123P	1	BACC63CB22-55S7 PLUG - CONDUCTIVE	81205	1	34-31-21 E001-04/ /	ALL

EQUIPMENT LIST

D280A103

Section D45100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45123PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-31-21 E001-04/ /	YC001-YC050
D45123PQ	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-31-21 */*/*	YK901-YM670
D45125J	1	BACC63CC22-55S6 RECP - CONDUCTIVE	81205	1	34-31-11 E001-05/ /	YC001-YC030, YK901-YM670
D45125JK	1	BACC10KD22 BACKSHELL - CONDUCTIVE	81205	1	34-31-21 */*/*	YC001-YC030, YK901-YM670
D45125P	1	BACC63CB22-55P6 PLUG-CONDUCTIVE	81205	1	34-31-11 E001-05/ /	YC001-YC030, YK901-YM670
D45125PQ	1	BACC10KD22 BACKSHELL	81205	1	34-31-11 / /	YC001-YC030
D45125PQ	1	BACC10KD22 BACKSHELL	81205	1	34-31-11 */*/*	YK901-YM670
D45127J	1	MTCPQKT2R22SGBD RCPT-CONDUCTIVE	06090	1	34-31-11 E003-02/ /	ALL
D45127P	1	MTCPQKT2P22PGBD PLUG - CONDUCTIVE	06090	1	34-31-11 E003-02/ /	YC001-YC030, YK901-YM670
D45131J	1	MTCPQKT2R22SGBB RCPT - CONDUCTIVE	06090	1	31-62-15 E003-01/ /	YC001-YC030, YK901-YM670
D45131P	1	MTCPQKT2P22PGBB PLUG - CONDUCTIVE	06090	1	31-62-15 E003-01/ /	YC001-YC030, YK901-YM670
D45133J	1	MTCPQKT1R2SGAC RECPT-CONDUCTIVE	06090	1	3434XX E001-01/ /	ALL
D45133P	1	MTCPQKT1P2PGAC PLUG - CONDUCTIVE	06090	1	34-36-05 E001-01/ /	YC001-YC030, YK901-YM670
D45137J	1	MTCPQKT2R22SGAC RCPT-CONDUCTIVE	06090	1	34-36-06 E003-02/ /	ALL
D45137P	1	MTCPQKT2P22PGAC PLUG - CONDUCTIVE	06090	1	34-36-06 E003-02/ /	YC001-YC030, YK901-YM670
D45141J	1	MTCPQKT2R22SGCC RCPT - CONDUCTIVE	06090	1	34-31-21 E003-01/ /	YC001-YC030, YK901-YM670
D45141P	1	MTCPQKT2P22PGCC PLUG - CONDUCTIVE	06090	1	34-31-21 E003-01/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D45100

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45143J	1	BACC63CC20-41P9 RECP - CONDUCTIVE	81205	1	22-11-51 E001-04/ /	YC001-YC030, YK901-YM670
D45143JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	22-11-51 */*/*	YC001-YC030, YK901-YM670
D45143P	1	BACC63CB20-41S9 PLUG - CONDUCTIVE	81205	1	22-11-51 E001-04/ /	ALL
D45143PQ	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	22-11-51 E001-04/ /	YC001-YC050
D45143PQ	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	22-11-51 */*/*	YK901-YM670
D45147J	1	MTCPQKT2R22SGAB RCPT-CONDUCTIVE	06090	1	27-32-22 E003-02/ /	ALL
D45147P	1	MTCPQKT2P22PGAB PLUG - CONDUCTIVE	06090	1	34-51-11 E003-02/ /	YC001-YC030, YK901-YM670
D45151J	1	MTCPQKT2R22SGBC RCPT - CONDUCTIVE	06090	1	3436XX E003-01/ /	YC001-YC030, YK901-YM670
D45151P	1	MTCPQKT2P22PGBC PLUG - CONDUCTIVE	06090	1	31-62-15 E003-01/ /	YC001-YC030, YK901-YM670
D45157J	1	MTCPQKT1R2SGAB RCPT-CONDUCTIVE	06090	1	34-36-06 E003-02/ /	YC001-YC050
D45157J	1	MTCPQKT1R2SGAB RCPT-CONDUCTIVE	06090	1	23-27-12 E003-02/ /	YK901-YM670
D45157P	1	MTCPQKT1P2PGAB PLUG - CONDUCTIVE	06090	1	23-27-12 E003-02/ /	YC001-YC030, YK901-YM670
D45177J	1	MTCPQKT1R2SGAA RCPT-CONDUCTIVE	06090	1	34-36-06 E003-02/ /	YC001-YC050
D45177J	1	MTCPQKT1R2SGAA RCPT-CONDUCTIVE	06090	1	31-33-01 E003-02/ /	YK901-YM670
D45177P	1	MTCPQKT1P2PGAA PLUG - CONDUCTIVE	06090	1	31-31-12 E003-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D45100

Page 3 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45201J	1	BACC63CC18-31S6 RECPT - CONDUCTIVE	81205	1	34-51-41 E001-02/ /	YC001-YC030, YK901-YM670
D45201JK	1	BACC10KD18 BACKSHELL - CONDUCTIVE	81205	1	34-51-41 E001-02/ /	YC001-YC030, YK901-YM670
D45201P	1	BACC63CB18-31P6 PLUG-	81205	1	34-51-41 E001-02/ /	YC001-YC030, YK901-YM670
D45201PQ	1	BACC10KD18 BACKSHELL	81205	1	34-51-41 E001-02/ /	YC001-YC030
D45201PQ	1	BACC10KD18 BACKSHELL	81205	1	34-51-41 */*/*	YK901-YM670
D45203J	1	MTCPQKT2R26SFCC RCPT-CONDUCTIVE	06090	1	34-51-41 E001-01/ /	YC001-YC029
D45203J	1	MTCPQKT2R26SGCC RCPT-CONDUCTIVE	06090	1	34-51-41 E001-01/ /	YC030-YM670
D45203P	1	MTCPQKT2P26PGCC PLUG - CONDUCTIVE	06090	1	34-51-41 E001-01/ /	YC001-YC030, YK901-YM670
D45205J	1	MTCPQKT1R2SGDD RCPT - CONDUCTIVE	06090	1	34-51-41 E003-01/ /	YC001-YC030, YK901-YM670
D45205P	1	MTCPQKT1P2PGDD PLUG - CONDUCTIVE	06090	1	34-51-41 E003-01/ /	YC001-YC030, YK901-YM670
D45207J	1	MTCPQKT1R2SGDB RCPT-CONDUCTIVE	06090	1	34-51-41 E003-02/ /	ALL
D45207P	1	MTCPQKT1P2PGDB PLUG - CONDUCTIVE	06090	1	34-51-41 E003-02/ /	YC001-YC030, YK901-YM670
D45209J	1	MTCPQKT2R26PGAA RCPT-CONDUCTIVE	06090	1	34-51-41 E005-02/ /	YC001-YC030, YK901-YM670
D45209P	1	MTCPQKT2P26SGAA PLUG-	06090	1	34-51-41 E005-02/ /	YC001-YC050
D45209P	1	MTCPQKT2P26SGAA PLUG-	06090	1	34-51-41 AE0502A/ /	YK901-YM670
D45211J	1	MTCPQKT2R22PGCB RCPT-CONDUCTIVE	06090	1	34-61-21 E005-02/ /	YC001-YC030, YK901-YM670
D45211P	1	MTCPQKT2P22SGCB PLUG-	06090	1	34-61-21 E005-02/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section D45200

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45211P	1	MTCPQKT2P22SGCB PLUG	06090	1	34-61-21 E005-02/ /	YK901-YM670
D45213J	1	MTCPQKT2R22PGCA RCPT-CONDUCTIVE	06090	1	34-61-21 E005-02/ /	YC001-YC030, YK901-YM670
D45213P	1	MTCPQKT2P22SGCA PLUG-	06090	1	34-61-21 E005-02/ /	ALL
D45221J	1	MTCPQKT2R22PFDC RCPT-	06090	1	34-61-19 E005-02/ /	ALL
D45221P	1	MTCPQKT2P22SFDC PLUG-	06090	1	34-61-12 E005-02/ /	YC001-YC050
D45221P	1	MTCPQKT2P22SFDC PLUG-	06090	1	34-61-12 AE0502A/ /	YK901-YM670
D45225J	1	MTCPQKT2R22SGAC RCPT-CONDUCTIVE	06090	1	34-61-18 E005-02/ /	ALL
D45225P	1	MTCPQKT2P22PGAC PLUG-	06090	1	34-61-18 E005-02/ /	YC001-YC050
D45225P	1	MTCPQKT2P22PGAC PLUG-	06090	1	34-61-18 AE0502A/ /	YK901-YM670
D45227J	1	BACC45FN20-41P RCPT	81205	1	23-31-06 E001-03/ /	YC001-YC050
D45227J	1	BACC45FN20-41P RCPT		1	23-34-01 E001-03/ /	YK901-YL430
D45227J	1	BACC45FN20-41P RCPT	81205	1	23-34-02 E001-03/ /	YM643-YM670
D45227P	1	BACC45FT20-41S PLUG	81205	1	23-32-12 E001-03/ /	ALL
D45227PQ		BACC10GH20 BACKSHELL	81205	1	23-32-12 */*/*	ALL
D45231J	1	BACC45FN22-55S RECP	81205	1	23-32-12 AB0340B/ /	YC001-YC050
D45231J	1	BACC45FN22-55S RCPT	81205	1	23-32-12 AB0340B/ /	YK901-YM670
D45231P	1	BACC45FT22-55P PLUG	81205	1	23-32-12 AB0340B/ /	ALL

EQUIPMENT LIST

D280A103

Section D45200

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45231PQ		BACC10JS22 BACKSHELL	81205	1	23-32-12 */*/*	ALL
D45233J	1	BACC45FN14-15S7 RCPT-	81205	1	23-32-11 P006-00/ /	ALL
D45233P	1	BACC45FT14-15P7 PLUG	81205	1	23-32-11 P006-00/ /	YC001-YC030, YK901-YM670
D45235J	1	MTCPQKT2R22PGAA RCPT-CONDUCTIVE	06090	1	34-21-11 E005-02/ /	ALL
D45235P	1	MTCPQKT2P22SGAA PLUG-	06090	1	34-21-12 E005-02/ /	YC001-YC050
D45235P	1	MTCPQKT2P22SGAA PLUG-	06090	1	34-21-12 AE0502A/ /	YK901-YM670
D45237J	1	MTCPQKT2R22PGBA RCPT-CONDUCTIVE	81205	1	34-21-21 E005-02/ /	YC001-YC003
D45237J	1	MTCPQKT2R22PGBA RCPT-CONDUCTIVE	06090	1	34-21-21 E005-02/ /	YC004-YC030, YK901-YM670
D45237P	1	MTCPQKT2P22SGBA PLUG-	06090	1	34-21-21 E005-02/ /	ALL
D45239J	1	MTCPQKT2R22PGAB RCPT-CONDUCTIVE	06090	1	34-21-12 337/169/R24	YC001-YC006
D45239J	1	MTCPQKT2R22PGAB RCPT-CONDUCTIVE	06090	1	34-21-12 E005-02/ /	YC007-YM670
D45239P	1	MTCPQKT2P22SGAB PLUG-	06090	1	34-21-12 E005-02/ /	YC001-YC050
D45239P	1	MTCPQKT2P22SGAB PLUG-	06090	1	34-21-12 AE0502A/ /	YK901-YM670
D45241J	1	MTCPQKT2R22SGBD RCPT-CONDUCTIVE	06090	1	34-21-22 E005-02/ /	YC001-YM652
D45241P	1	MTCPQKT2P22PGBD PLUG-	06090	1	34-21-22 E005-02/ /	ALL
D45245J	1	MTCPQKT2R22PGCD RCPT-CONDUCTIVE	06090	1	31-62-15 E005-02/ /	ALL
D45245P	1	MTCPQKT2P22SGCD PLUG-	06090	1	31-62-15 E005-02/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section D45200

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45245P	1	MTCPQKT2P22SGCD PLUG-	06090	1	31-62-15 AE0502A/ /	YK901-YM670
D45247J	1	MTCPQKT2R22PGAB RCPT-CONDUCTIVE	06090	1	31-62-25 E005-02/ /	ALL
D45247P	1	MTCPQKT2P22SGAB PLUG-	06090	1	31-62-25 E005-02/ /	ALL
D45253J	1	AMC02RA03W RECP	05574	1	23-32-11 387/292/R022	YC001-YC050
D45253P	1	AMC02PA03W PLUG	05547	1	23-32-11 386/292/R022	YC001-YC030
D45255J	1	MTCPQKT2R22PGDA RCPT-CONDUCTIVE	06090	1	34-61-12 E005-02/ /	ALL
D45255P	1	MTCPQKT2P22SGDA PLUG-	06090	1	34-21-13 E005-02/ /	YC001-YC050
D45255P	1	MTCPQKT2P22SGDA PLUG-	06090	1	34-21-13 AE0502A/ /	YK901-YM670
D45257J	1	MTCPQKT2R22PGAC RCPT-CONDUCTIVE	06090	1	34-61-12 E005-02/ /	ALL
D45257P	1	MTCPQKT2P22SGAC PLUG-	06090	1	34-61-12 E005-02/ /	ALL
D45259J	1	AMC02RA03W RECP	05574	1	23-32-31 451/294/L023	YC001-YC030
D45259P	1	AMC02PA03W PLUG	05547	1	23-32-31 452/294/L023	YC001-YC030
D45261J	1	MTCPQKT2R22SGDD RCPT-CONDUCTIVE	06090	1	31-31-12 E005-02/ /	YC001-YC030, YK901-YM670
D45261P	1	MTCPQKT2P22PGDD PLUG-	06090	1	31-31-15 E005-02/ /	YC001-YC050
D45261P	1	MTCPQKT2P22PGDD PLUG-	06090	1	31-31-15 AE0502A/ /	YK901-YM670
D45263J	1	MTCPQKT2R22SGAD RCPT-CONDUCTIVE	06090	1	27-32-21 E005-02/ /	ALL
D45263P	1	MTCPQKT2P22PGAD PLUG-	06090	1	31-31-13 E005-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D45200

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45265J	1	MTCPQKT2R22PGDB RCPT-CONDUCTIVE	06090	1	73-21-31 E005-02/ /	ALL
D45265P	1	MTCPQKT2P22SGDB PLUG-	06090	1	73-21-31 E005-02/ /	YC001-YC050
D45265P	1	MTCPQKT2P22SGDB PLUG-	06090	1	73-21-31 AE0502A/ /	YK901-YM670
D45269J	1	AMC02RA03W RECP	05574	1	23-32-41 500G+7/295/L023	YC001-YC030
D45269P	1	AMC02PA03W PLUG	05547	1	23-32-41 500G+8/295/L023	YC001-YC030
D45271J	1	AMC02RA03W RECP	05574	1	23-32-51 698/295/L23	YC001-YC030
D45271P	1	AMC02PA03W PLUG	05574	1	23-32-51 697/294/L23	YC001-YC030
D45273J	1	AMC02RA03W RECP	05574	1	23-32-61 727I+11/294/L024	YC001-YC030
D45273P	1	AMC02PA03W PLUG	05574	1	23-32-61 727I+11/294/L024	YC001-YC030
D45275J	1	BACC45FN18-31P RECP	81205	1	23-32-31 691/297/L018	YC001-YC030
D45275J	1	BACC45FN18-31P RCPT	81205	1	23-32-31 701/301/L019	YK901-YL430
D45275J	1	BACC45FN18-31P RCPT	81205	1	23-32-31 691/297/L018	YM643-YM670
D45275P	1	BACC45FT18-31S PLUG	81205	1	23-32-31 691/298/L018	YC001-YC050, YM643-YM670
D45275P	1	BACC45FT18-31S PLUG	81205	1	23-32-31 698/301/L019	YK901-YL430
D45279J	1	MTCPQKT2R22PFBA RCPT-	06090	1	23-34-01 E008-01/ /	YC001-YC050
D45279P	1	MTCPQKT2P22SFBA PLUG	06090	1	23-32-12 E008-01/ /	YC001-YC050
D45281J	1	BACC45FN22-55S RECP	81205	1	23-32-12 AB0373/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section D45200

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45281P	1	BACC45FT22-55P PLUG	81205	1	23-32-11 AB0373/ /	YC015, YC019, YC031-YC050
D45283J	1	BACC45FN22-55P7 RECP	81205	1	23-32-12 AB0373/ /	YC001-YC050
D45283P	1	BACC45FT22-55S7 PLUG	81205	1	23-32-11 AB0373/ /	YC015, YC019, YC031-YC050
D45285J	1	BACC45FN22-55P7 RCPT	81205	1	23-32-12 858/217/R068	YK901-YM670
D45285P	1	BACC45FT22-55S7 PLUG	81205	1	23-32-11 858/217/R069	YK901-YM670
D45285PQ	1	BACC10JS22 BACKSHELL	81205	1	23-32-12 */*/*	YK901-YM670
D45287J	1	BACC45FN20-41P6 RCPT	81205	1	23-32-21 AB0373/ /	YC001-YC050
D45287P	1	BACC45FT20-41S6 PLUG	81205	1	23-32-21 AB0373/ /	YC015, YC019, YC031-YC050
D45289J	1	BACC45FN22-55S RCPT	81205	1	23-32-11 858/222/R070	YK901-YM670
D45289P	1	BACC45FT22-55P PLUG	81205	1	23-32-11 858/222/R070	YK901-YM670
D45289PQ		BACC10JS22 BACKSHELL	81205	1	23-32-11 */*/*	YK901-YM670
D45293J	1	MTCPQKT1R2SGAD RCPT-CONDUCTIVE	06090	1	34-61-18 E005-02/ /	YC001-YC011
D45293J	1	MTCPQKT1R2SGBA RCPT-CONDUCTIVE	06090	1	34-61-18 E005-02/ /	YC012-YM670
D45293P	1	MTCPQKT1P2PGAD PLUG-	06090	1	34-61-18 E005-02/ /	YC001-YC011
D45293P	1	MTCPQKT1P2PGBA PLUG-	06090	1	34-61-18 E005-02/ /	YC012-YC050
D45293P	1	MTCPQKT1P2PGBA PLUG-	06090	1	34-61-18 AE0502A/ /	YK901-YM670
D45297J	1	280T1000-151 RCPT-MOA PER #280T1000 BACC45FN20-28S6	81205	1	23-32-21 AB0858/ /	YK901-YK906

EQUIPMENT LIST

D280A103

Section D45200

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45297J	1	BACC45FN18-31P6 RCPT	81205	1	23-32-21 AB0858/ /	YK907-YK910, YK918, YL421- YM646
D45297J	1	280T1000-151 RCPT - MOA PER DWG REF BACC45FN20-28S6	81205	1	23-32-21 AB0858/ /	YK911-YK917, YK919-YL401, YM647-YM670
D45297P	1	BACC45FT18-31S6 PLUG	81205	1	23-32-21 AB0858/ /	YK907-YK910, YK918, YL421- YM646
D45297P	1	280T1000-152 PLUG-MOA BY DWG 280T1000 BACC45FT20-28P6	81205	1	23-32-21 AB0858/ /	YK911-YK917, YK919-YL401, YM647-YM670
D45297PQ	1	BACC10GH18 BACKSHELL	81205	1	23-32-21 */*/*	YK907-YK909, YM643-YM646
D45297PQ	1	BACC10JS18 BACKSHELL	81205	1	23-32-21 */*/*	YK910, YK918, YL421-YL430
D45297PQ	1	BACC10JS20 BACKSHELL	81205	1	23-32-21 */*/*	YK911-YK917, YK919-YL401
D45297PQ	1	BACC10GH20 BACKSHELL	81205	1	23-32-21 */*/*	YM647-YM670

EQUIPMENT LIST

D280A103

Section D45200
Page 7 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45315J	1	MTCPQKT2R22PGAB RCPT-CONDUCTIVE	06090	1	23-32-21 E008-01/ /	YK901-YM670
D45315P	1	MTCPQKT2P22SGAB PLUG	06090	1	23-32-21 E008-01/ /	YK901-YM670
D45319J	1	MTCPQKT2R22SGCC RCPT-CONDUCTIVE	06090	1	23-32-21 E005-02/ /	YK901-YM670
D45319P	1	MTCPQKT2P22PGCC PLUG	06090	1	34-61-15 E005-02/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D45300

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45501J	1	BACC63CC16-24P9 RCPT - CONDUCTIVE	81205	1	22-11-81 AB1050L/ /	YC020-YC022, YC031-YM670
D45501J	1	BACC63CC16-24P9 RCPT - CONDUCTIVE	81205	1	22-11-81 AB1050L/296/R013	YC023-YC030
D45501JK	1	BACC10KE16 BACKSHELL	81205	1	22-11-81 */**	YC020-YC022
D45501JK	1	BACC10KF16 BACKSHELL	81205	1	22-11-81 */**	YC023-YM670
D45501P	1	BACC63CB16-24S9 PLUG - CONDUCTIVE	81205	1	22-11-81 AB1050L/296/R013	YC020-YC022
D45501P	1	BACC63CB16-24S9 PLUG - CONDUCTIVE	81205	1	22-11-81 AB1050L/ /	YC023-YM670
D45501PQ	1	BACC10KF16 BACKSHELL	81205	1	22-11-81 / /	YC020-YC022
D45501PQ	1	BACC10KE16 BACKSHELL	81205	1	22-11-81 / /	YC023-YM670
D45503J	1	BACC63CC16-24PN RCPT - CONDUCTIVE	81205	1	22-11-81 AB1050R/ /	YC020-YM670
D45503JK	1	BACC10KD16 BACKSHELL	81205	1	22-11-81 */**	YC020-YC022
D45503JK	1	BACC10KE16 BACKSHELL	81205	1	22-11-81 */**	YC023-YM670
D45503P	1	BACC63CB16-24SN PLUG - CONDUCTIVE	81205	1	22-11-81 AB1050R/298/L009	YC020-YC022
D45503P	1	BACC63CB16-24SN PLUG - CONDUCTIVE	81205	1	22-11-81 AB1050R/ /	YC023-YM670
D45503PQ	1	BACC10KE16 BACKSHELL	81205	1	22-11-81 / /	YC020-YC022
D45503PQ	1	BACC10KF16 BACKSHELL	81205	1	22-11-81 / /	YC023-YC026
D45503PQ	1	BACC10KF16 BACKSHELL	81205	1	22-11-81 */**	YC028-YM670
D45515J	1	MTCPQKT2R22PFCD RECPT	06090	1	22-11-75 E001-01/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section D45500

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45515P	1	MTCPQKT2P22SFCD PLUG-	06090	1	22-11-75 E001-01/ /	YC031-YM670
D45517J	1	BACC45FN14-15S6 RCPT-	81205	1	22-11-75 E001-04/ /	YC031-YM670
D45517P	1	BACC45FT14-15P6 PLUG-	81205	1	22-11-75 E001-04/ /	YK901-YM670
D45517PQ	1	BACC10JS14 BACKSHELL	81205	1	22-11-75 */*/	YK901-YM670
D45551J	1	MTCPQKT2R26SGDA RECPT-CONDUCTIVE	06090	1	22-11-81 E001-01/ /	YK901-YM670
D45551P	1	MTCPQKT2P26PGAA PLUG - CONDUCTIVE	06090	1	22-11-81 E001-01/ /	YC020-YC030
D45551P	1	MTCPQKT2P26PGDA PLUG - CONDUCTIVE	06090	1	22-11-81 E001-01/ /	YC031-YM670
D45553J	1	BACC63CC16-24P8 RCPT - CONDUCTIVE	81205	1	22-11-81 E001-04/ /	YC020-YM670
D45553JK	1	BACC10KD16 BACKSHELL	81205	1	22-11-81 */*/	YC020-YL430
D45553JK	1	BACC10KD16 BACKSHELL	81205	1	22-11-81 / /	YM643-YM670
D45553P	1	BACC63CB16-24S8 PLUG - CONDUCTIVE	81205	1	22-11-81 E001-04/ /	YK901-YM670
D45553PQ	1	BACC10KD16 BACKSHELL - CONDUCTIVE	81205	1	22-11-81 */*/	YK901-YM670

EQUIPMENT LIST

D280A103

Section D45500

Page 2 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46002J	1	BACC63BV14B7S6 RCPT-CONDUCTIVE	81205	1	32-64-11 IRSS/179/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46002JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-64-11 ORSS/179/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46002P	1	BACC63BP14D7P6 PLUG, CONDUCTIVE CONNECTOR	81205	1	32-64-11 693/191/L97	ALL
D46004J	1	BACC63BV14B7SN RCPT-CONDUCTIVE	81205	1	32-41-11 IRSS/178/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46004JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 ORSS/178/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46004P	1	BACC63BP14D7PN PLUG, CONDUCTIVE CONNECTOR	81205	1	32-31-11 694/192/L102	ALL
D46006J	1	BACC63BV14B7SN RCPT-CONDUCTIVE	81205	1	32-41-11 ORSS/217/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46006JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 / /	YC001-YC028
D46006JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */*/*	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46006P	1	BACC63BP14D7PN PLUG, CONDUCTIVE CONNECTOR	81205	1	32-31-12 706/192/L137	ALL
D46008J	1	BACC63BV14B7SN RCPT-CONDUCTIVE	81205	1	32-64-12 ORSS/169/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D46000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46008JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-64-12 / /	YC001-YC028
D46008JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-64-12 */**	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46008P	1	BACC63BP14D7PN PLUG, CONDUCTIVE CONNECTOR	81205	1	32-64-12 711/180/L86	ALL
D46010J	1	BACC63BV18F14S8 RCPT-CONDUCTIVE	81205	1	27-61-11 675/198/L040	YC001-YC019
D46010J	1	BACC63BV18F14S8 RCPT-CONDUCTIVE	81205	1	27-61-11 AL0675A/202/L037	YC020-YC030
D46010J	1	BACC63BV18H14S8 RCPT-CONDUCTIVE	81205	1	27-61-11 AL0675A/202/L037	YC031-YM670
D46010JK	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-61-11 / /	YC001-YC030
D46010JK	1	M85049-52S18A BACKSHELL-CONDUCTIVE	81205	1	27-61-11 / /	YC031-YL430
D46010JK	1	M85049-52S18A BACKSHELL-CONDUCTIVE	81205	1	27-61-11 682/201/L038	YM643
D46010JK	1	M85049-52S18A BACKSHELL-CONDUCTIVE	81205	1	27-61-11 */**	YM645-YM670
D46010P	1	BACC63BP18C14P8 PLUG-CONDUCTIVE	81205	1	27-61-11 675/198/L042	YC001-YC028
D46010P	1	BACC63BP18C14P8 PLUG-CONDUCTIVE	81205	1	27-61-11 AL0675A/202/L040	YC029-YC030
D46010P	1	BACC63BP18H14P8 PLUG-CONDUCTIVE	81205	1	27-61-11 AL0675A/202/L040	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46010PQ	1	BACC10KD18 BACKSHELL- CONDUCTIVE	81205	1	27-61-11 TBD/ /	YC001-YC007
D46010PQ	1	BACC10KD18 BACKSHELL- CONDUCTIVE	81205	1	27-61-11 682/201/L38	YC008-YC028

EQUIPMENT LIST

D280A103

Section D46000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46010PQ	1	BACC10KD18 BACKSHELL- CONDUCTIVE	81205	1	27-61-11 682/201/L038	YC029-YC030
D46010PQ	1	M85049-52S18A BACKSHELL- CONDUCTIVE	81205	1	27-61-11 */*/*	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46011J	1	BACC45FN14-15S9 RCPT-	81205	1	34-51-21 E001-04/ /	YC001-YC030, YK901-YM652
D46011P	1	BACC45FT14-15P9 PLUG	81205	1	34-51-21 E001-04/ /	ALL
D46011PQ	1	BACC10JS14 CLAMP	81205	1	34-51-21 E001-04/ /	YC001-YC050
D46011PQ	1	BACC10JS14 CLAMP	81205	1	34-51-21 */*/*	YK901-YM670
D46012J	1	BACC63BV14B7SN RCPT-CONDUCTIVE	81205	1	32-64-11 IRSS 179/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46012JK	1	BACC10KC14 BACKSHELL, CONDUCTIVE	81205	1	32-64-11 ORSS 179/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46012P	1	BACC63BP14D7PN PLUG, CONDUCTIVE CONNECTOR	81205	1	32-64-11 IRSS 178/ /	ALL
D46013J	1	MTCPQKT2R26PFDA RCPT-	06090	1	22-11-11 E001-01/ /	ALL
D46013P	1	MTCPQKT2P26SFDA PLUG - CONDUCTIVE	06090	1	22-11-11 E001-01/ /	YC001-YC030, YK901-YM652
D46014J	1	BACC63BV14B7S6 RCPT-CONDUCTIVE	81205	1	32-41-11 IRSS 178/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46014JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 ORSS 178/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D46000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46014P	1	BACC63BP14D7P6 PLUG, CONDUCTIVE CONNECTOR	81205	1	32-31-11 IRSS 178/ /	ALL
D46016J	1	BACC63BV14B7SN RCPT-CONDUCTIVE	81205	1	32-41-11 IRSS 217/ /	YC001-YC011
D46016J	1	BACC63BV14B7SN RCPT-CONDUCTIVE	81205	1	32-41-11 IRSS 215/ /	YC012-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46016JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46016P	1	BACC63BP14D7PN PLUG, CONDUCTIVE CONNECTOR	81205	1	32-31-12 IRSS 215/ /	ALL
D46017J	1	BACC45FN14-12P7 RCPT - POWER	81205	1	34-57-21 E003-01/ /	YC001-YC030, YK901-YM670
D46017P	1	BACC45FT14-12S7 PLUG E3-1 SHELF	81205	1	34-57-21 E003-01/ /	ALL
D46017PQ	1	BACC10JS14 BACKSHELL-	81205	1	34-57-21 */*/*	ALL
D46018J	1	BACC63BV14B7SN RCPT-CONDUCTIVE	81205	1	32-64-12 IRSS 170/ /	YC001-YC011
D46018J	1	BACC63BV14B7SN RCPT-CONDUCTIVE	81205	1	32-64-12 IRSS 168/ /	YC012-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46018JK	1	BACC10KC14 BACKSHELL-CONDUCTIVE	81205	1	32-64-12 TBD/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46018P	1	BACC63BP14D7PN PLUG, CONDUCTIVE CONNECTOR	81205	1	32-64-12 IRSS 168/ /	ALL
D46020J	1	BACC63BV14F7S8 RCPT-CONDUCTIVE	81205	1	27-53-11 718/202/L026	YC001-YC029

EQUIPMENT LIST

D280A103

Section D46000

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46020J	1	CN0967C14A07S8-000 RCPT-CONDUCTIVE	81205	1	27-53-11 718/202/L026	YC030
D46020J	1	BACC63BV14H7S8 RCPT-CONDUCTIVE	81205	1	27-53-11 718/202/L026	YC031-YK907, YL421
D46020J	1	BACC63BV14H12S8 RCPT-CONDUCTIVE	81205	1	27-53-11 718/202/L026	YK908-YL401, YL422-YM670
D46020JK	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	27-53-11 */**	YC001-YC030
D46020JK	1	M85049-52S14A BACKSHELL-CONDUCTIVE	81205	1	27-53-11 */**	YC031-YM670
D46020P	1	BACC63BP14C7P8 PLUG- CONDUCTIVE	81205	1	27-53-11 718/201/L25	YC001-YC029
D46020P	1	CN0966A14A07P8-000 PLUG- CONDUCTIVE	81205	1	27-53-11 718/201/L25	YC030
D46020P	1	BACC63BP14H7P8 PLUG- CONDUCTIVE	81205	1	27-53-11 718/201/L25	YC031-YK907, YL421
D46020P	1	BACC63BP14D12P8 PLUG- CONDUCTIVE	81205	1	27-53-11 718/201/L025	YK908-YK912, YK918-YK919, YL401, YL422- YL429, YM643- YM670
D46020PQ	1	BACC10KD14 BACKSHELL- CONDUCTIVE	81205	1	27-53-11 TBD/ /	YC001-YC028
D46020PQ	1	BACC10KD14 BACKSHELL- CONDUCTIVE	81205	1	27-53-11 */**	YC029-YC030
D46020PQ	1	M85049-52S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-11 */**	YC031-YK907, YK910-YK912, YK918-YK919, YL401-YL421, YL423-YL429, YM645-YM670
D46020PQ	1	M85049-52S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-11 / /	YK908-YK909, YL422, YM643
D46021J	1	BACC45FN12-12P RCPT	81205	1	34-33-21 E003-02/ /	ALL

EQUIPMENT LIST

D280A103

Section D46000

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46021P	1	BACC45FT12-12S PLUG E3-2 SHELF	81205	1	34-33-21 E003-02/ /	ALL
D46021PQ	1	BACC10JS12 BACKSHELL-	81205	1	34-33-21 */*/*	ALL
D46022J	1	MTCPQKT1R2SFCB RCPT-	06090	1	26-16-22 E002-02/ /	YC001-YC030, YK901-YM670
D46022P	1	MTCPQKT1P2PFCB PLUG-	06090	1	26-16-21 E002-02/ /	ALL
D46023J	1	MTCPQKT2R26PFCA RCPT-	06090	1	22-18-11 E001-01/ /	ALL
D46023P	1	MTCPQKT2P26SFCA PLUG	06090	1	22-18-11 E001-01/ /	YC001-YC030, YK901-YM670
D46024J	1	BACC63BV22B19SN RCPT-CONDUCTIVE	81205	1	32-41-11 718/202/L034	ALL
■ D46024JK	1	BACC10KA22 BACKSHELL-BACKSHELL	81205	1	32-41-11 / /	YC001-YL430
■ D46024JK	1	BACC10KA22 BACKSHELL-BACKSHELL	81205	1	32-41-11 718/L34/202	YM643-YM670
D46024P	1	BACC63BP22D19PN PLUG-CONDUCTIVE	81205	1	32-41-11 718/201/L34	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D46024PQ	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YC028
■ D46024PQ	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */*/*	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46026J	1	BACC63BV18F14SN RCPT-CONDUCTIVE	81205	1	32-41-11 675/198/L036	YC001-YC026
D46026J	1	BACC63BV18F14SN RCPT-CONDUCTIVE	81205	1	32-41-11 AL0675B/202/L032	YC028-YC030
D46026J	1	BACC63BV18B14SN RCPT-CONDUCTIVE	81205	1	32-41-11 AL0675B/202/L032	YC031-YL430

EQUIPMENT LIST

D280A103

Section D46000

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46026J	1	BACC63BV18B14SN RCPT-CONDUCTIVE	81205	1	32-41-11 675/198/L036	YM643-YM670
D46026JK	1	BACC10KD18 BACKSHELL	81205	1	32-41-11 / /	YC001-YC030
D46026JK	1	BACC10KA18 BACKSHELL	81205	1	32-41-11 / /	YC031-YM670
D46026P	1	BACC63BP18C14PN PLUG-CONDUCTIVE	81205	1	32-41-11 675/198/L038	YC001-YC030
D46026P	1	BACC63BP18D14PN PLUG-CONDUCTIVE	81205	1	32-41-11 AL0675B/202/L030	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46026PQ	1	BACC10KD18 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YC030
D46026PQ	1	BACC10KA18 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D46028J	1	BACC63BV22B19S8 RCPT-CONDUCTIVE	81205	1	32-41-11 675/198/L036	ALL
■ D46028JK	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 / /	ALL
■ D46028P	1	BACC63BP22D19P8 PLUG-CONDUCTIVE	81205	1	32-41-11 669/198/L038	YC001-YC030
■ D46028P	1	BACC63BP22D19P8 PLUG-CONDUCTIVE	81205	1	32-41-11 AL0675B/202/L030	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
■ D46028PQ	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46030J	1	BACC63BV22F19S7 RCPT-CONDUCTIVE	81205	1	29-33-11 675/198/L036	YC001-YC030

EQUIPMENT LIST

D280A103

Section D46000

Page 7

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46030J	1	BACC63BV22B19S7 RCPT-CONDUCTIVE	81205	1	29-33-11 675/198/L036	YC031-YM670
D46030JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	29-33-11 / /	YC001-YC030
D46030JK	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	29-33-11 / /	YC031-YM670
D46030P	1	BACC63BP22C19P7 PLUG - CONDUCTIVE	81205	1	29-33-11 671/198/L038	YC001-YC030
D46030P	1	BACC63BP22D19P7 PLUG - CONDUCTIVE	81205	1	29-33-11 AL0675B/202/L030	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46030PQ	1	BACC10KD22 BACKSHELL- CONDUCTIVE	81205	1	29-33-11 */*/*	YC001-YC030
D46030PQ	1	BACC10KA22 BACKSHELL- CONDUCTIVE	81205	1	29-33-11 */*/*	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46031J	1	BACC45FN12-12S RCPT-	81205	1	22-11-12 E001-04/ /	YC001-YC030
D46031J	1	BACC45FN14-12S RCPT-	81205	1	22-11-12 E001-04/ /	YK901-YM670
D46031P	1	BACC45FT12-12P PLUG	81205	1	22-11-12 E001-04/ /	YC001-YC030
D46031P	1	BACC45FT14-12P PLUG	81205	1	22-11-12 E001-04/ /	YK901-YM670
D46031PQ	1	BACC10JS12 CLAMP	81205	1	22-11-12 E001-04/ /	YC001-YC011
D46031PQ	1	BACC10JS12 BACKSHELL	81205	1	22-11-12 E001-04/ /	YC012-YC030
D46031PQ	1	BACC10JS14 BACKSHELL	81205	1	22-11-12 */*/*	YK901-YM670
D46032J	1	BACC63BV18F14S6 RCPT-CONDUCTIVE	81205	1	32-44-11 721/201/L026	YC001-YC030

EQUIPMENT LIST

D280A103

Section D46000

Page 8

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46032J	1	BACC63BV18B14S6 RCPT-CONDUCTIVE	81205	1	32-44-11 721/201/L026	YC031-YM670
D46032JK	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	32-44-11 */**	YC001-YC030
D46032JK	1	BACC10KA18 BACKSHELL-CONDUCTIVE	81205	1	32-44-11 */**	YC031-YM670
D46032P	1	BACC63BP18C14P6 PLUG- CONDUCTIVE	81205	1	32-44-11 721/201/L26	YC001-YC028
D46032P	1	BACC63BP18C14P6 PLUG- CONDUCTIVE	81205	1	32-44-11 721/201/L026	YC029-YC030
D46032P	1	BACC63BP18D14P6 PLUG- CONDUCTIVE	81205	1	32-44-11 721/201/L026	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D46032PQ	1	BACC10KD18 BACKSHELL- CONDUCTIVE	81205	1	32-44-11 TBD/ /	YC001-YC028
D46032PQ	1	BACC10KD18 BACKSHELL- CONDUCTIVE	81205	1	32-44-11 */**	YC029-YC030
D46032PQ	1	BACC10KA18 BACKSHELL- CONDUCTIVE	81205	1	32-44-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM670
D46033J	1	BACC63CC20-28PN RCPT - CONDUCTIVE	81205	1	31-62-21 P009-00/ /	YC001-YC030, YK901-YL429, YM643-YM652
D46033JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-21 */ /	YC001-YC030
D46033JK	1	BACC10KD20 BACKSHELL - CONDUCTIVE	81205	1	31-62-21 */**	YK901-YL429, YM643-YM652
D46033P	1	BACC63CB20-28SN PLUG - CONDUCTIVE	81205	1	31-62-21 190/214/R008	YC001-YC030, YK901-YM670
D46033PQ	1	BACC10KD20 BACKSHELL - CONDUCTIVE, STRAIGHT	81205	1	31-62-21 P003-00/ /	YC001-YC030
D46033PQ	1	BACC10KD20 BACKSHELL - CONDUCTIVE, STRAIGHT	81205	1	31-62-21 */**	YK901-YM670

EQUIPMENT LIST

D280A103

Section D46000

Page 9

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46035J	1	BACC45FN14-12P8 RCPT - POWER	81205	1	31-62-21 E003-01/ /	YC001-YC030, YK901-YM670
D46035P	1	BACC45FT14-12S8 PLUG E3-1 SHELF	81205	1	31-62-21 E003-01/ /	ALL
D46035PQ	1	BACC10JS14 BACKSHELL-	81205	1	31-62-21 */*/*	ALL
D46036J	1	BACC63BV14F7S7 RCPT-CONDUCTIVE	81205	1	27-53-12 720/201/L025	YC001-YC030
D46036J	1	BACC63BV14H7S7 RCPT-CONDUCTIVE	81205	1	27-53-12 720/201/L025	YC031-YM670
D46036JK	1	BACC10KD14 BACKSHELL-CONDUCTIVE	81205	1	27-53-12 720/201/L025	YC001-YC030
D46036JK	1	M85049-52S14A BACKSHELL-CONDUCTIVE	81205	1	27-53-12 720/201/L025	YC031-YM643
D46036JK	1	M85049-52S14A BACKSHELL-CONDUCTIVE	81205	1	27-53-12 */*/*	YM645-YM670
D46036P	1	BACC63BP14C7P7 PLUG- CONDUCTIVE	81205	1	27-53-12 719/201/L26	YC001-YC030
D46036P	1	BACC63BP14H7P7 PLUG- CONDUCTIVE	81205	1	27-53-12 719/201/L026	YC031-YK907, YL421
D46036P	1	BACC63BP14D7P7 PLUG- CONDUCTIVE	81205	1	27-53-12 719/201/L026	YK908-YK912, YK918-YK919, YL401, YL422- YL429, YM643- YM670
D46036PQ	1	BACC10KD14 BACKSHELL- CONDUCTIVE	81205	1	27-53-12 TBD/ /	YC001-YC030
D46036PQ	1	M85049-52S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-12 */*/*	YC031-YK907, YK910-YK912, YK918-YK919, YL401-YL421, YL423-YL429, YM645-YM670
D46036PQ	1	M85049-52S14A BACKSHELL- CONDUCTIVE	81205	1	27-53-12 / /	YK908-YK909, YL422, YM643

EQUIPMENT LIST

D280A103

Section D46000

Page 10

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46038J	1	BACC63BV20F28S7 RCPT-CONDUCTIVE	81205	1	27-51-11 675/198/R036	YC001-YC029
D46038J	1	CN0967C20A28S7Y000 RCPT-CONDUCTIVE	81205	1	27-51-11 675/198/R036	YC030
D46038J	1	BACC63BV20H28S7 RCPT-CONDUCTIVE	81205	1	27-51-11 675/198/R036	YC031-YM670
D46038JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-51-11 */**	YC001-YC030
D46038JK	1	M85049-52S20A BACKSHELL-CONDUCTIVE	81205	1	27-51-11 */**	YC031-YM670
D46038P	1	BACC63BP20C28P7 PLUG-CONDUCTIVE	81205	1	27-51-11 671/198/R038	YC001-YC029
D46038P	1	CN0966A20A28P7Y000 PLUG-CONDUCTIVE	81205	1	27-51-11 671/198/R038	YC030
D46038P	1	BACC63BP20H28P7 PLUG-CONDUCTIVE	81205	1	27-51-11 671/198/R038	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46038PQ	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	27-51-11 TBD/ /	YC001-YC030
D46038PQ	1	M85049-52S20A BACKSHELL-CONDUCTIVE	81205	1	27-51-11 */**	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46040J	1	BACC63BV22F19SN RCPT-CONDUCTIVE	81205	1	29-25-11 718/201/R026	YC001-YC030
D46040J	1	BACC63BV22B19SN RCPT-CONDUCTIVE	81205	1	29-25-11 718/201/R026	YC031-YC050, YK906-YM670
D46040J	1	BACC63BV22H19SN RCPT-CONDUCTIVE	81205	1	29-25-11 718/201/R026	YK901-YK905
D46040JK	1	BACC10KD22 BACKSHELL-CONDUCTIVE	81205	1	29-25-11 */**	YC001-YC030
D46040JK	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	29-25-11 */**	YC031-YC050, YK906-YM670

EQUIPMENT LIST

D280A103

Section D46000

Page 11

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46040JK	1	M85049-52S22A BACKSHELL-CONDUCTIVE	81205	1	29-25-11 */*/*	YK901-YK905
D46040P	1	BACC63BP22C19PN PLUG- CONDUCTIVE	81205	1	29-25-11 718/201/R25	YC001-YC030
D46040P	1	BACC63BP22H19PN PLUG- CONDUCTIVE	81205	1	29-25-11 718/201/R25	YK901-YK905
D46040P	1	BACC63BP22D19PN PLUG- CONDUCTIVE	81205	1	29-25-11 718/201/R25	YK906-YK912, YK918, YL401- YL426, YM643- YM652
D46040PQ	1	BACC10KD22 BACKSHELL- CONDUCTIVE	81205	1	27-31-37 */*/*	YC001-YC030
D46040PQ	1	M85049-52S22A BACKSHELL- CONDUCTIVE	81205	1	27-31-37 */*/*	YK901-YK905
D46040PQ	1	BACC10KA22 BACKSHELL- CONDUCTIVE	81205	1	27-31-37 */*/*	YK906-YK912, YK918, YL401- YL426, YM643- YM652
D46042J	1	BACC63BV16F10S6 RCPT-CONDUCTIVE	81205	1	29-33-11 675/198/R036	YC001-YC030
D46042J	1	BACC63BV16H10S6 RCPT-CONDUCTIVE	81205	1	29-33-11 675/198/R036	YC031-YM670
D46042JK	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */*/*	YC001-YC030
D46042JK	1	M85049-52S16A BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */*/*	YC031-YM670
D46042P	1	BACC63BP16C10P6 PLUG-CONDUCTIVE	81205	1	29-33-11 673/198/R038	YC001-YC030
D46042P	1	BACC63BP16H10P6 PLUG-CONDUCTIVE	81205	1	29-33-11 673/198/R038	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46042PQ	1	BACC10KD16 BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */*/*	YC001-YC030

EQUIPMENT LIST

D280A103

Section D46000

Page 12

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46042PQ	1	M85049-52S16A BACKSHELL-CONDUCTIVE	81205	1	29-33-11 */**	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46043J	1	BACC45FN12-12P9 RCPT	81205	1	27-32-21 E003-02/ /	ALL
D46043P	1	BACC45FT12-12S9 PLUG E3-2 SHELF	81205	1	27-32-21 E003-02/ /	ALL
D46043PQ	1	BACC10JS12 BACKSHELL-	81205	1	27-32-21 */**	ALL
D46044J	1	BACC63BV18F14S7 RCPT-CONDUCTIVE	81205	1	27-54-11 720/201/R033	YC001-YC030
D46044J	1	BACC63BV18H14S7 RCPT-CONDUCTIVE	81205	1	27-54-11 720/201/R033	YC031-YM670
D46044JK	1	BACC10KD18 BACKSHELL-CONDUCTIVE	81205	1	27-54-11 */**	YC001-YC030
D46044JK	1	M85049-52S18A BACKSHELL-CONDUCTIVE	81205	1	27-54-11 */**	YC031-YM670
D46044P	1	BACC63BP18C14P7 PLUG- CONDUCTIVE	81205	1	27-54-11 720/201/R34	YC001-YC030
D46044P	1	BACC63BP18H14P7 PLUG- CONDUCTIVE	81205	1	27-54-11 720/201/R34	YC031-YK912, YK918-YK919, YL401-YL429
D46044P	1	BACC63BP18H14P7 PLUG- CONDUCTIVE	81205	1	27-54-11 720/201/R034	YM643-YM652
D46044PQ	1	BACC10KD18 BACKSHELL- CONDUCTIVE	81205	1	27-54-11 TBD/ /	YC001-YC030
D46044PQ	1	M85049-52S18A BACKSHELL- CONDUCTIVE	81205	1	27-54-11 TBD/ /	YC031-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46046J	1	BACC63BV22B55SN RCPT-CONDUCTIVE	81205	1	78-34-21 675/198/R036	ALL
D46046JK	1	BACC10KA22 BACKSHELL	81205	1	78-34-21 / /	YC001-YC007

EQUIPMENT LIST

D280A103

Section D46000

Page 13

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46046JK	1	BACC10KA22 BACKSHELL	81205	1	78-34-21 */**	YC008-YL430
D46046JK	1	BACC10KA22 BACKSHELL	81205	1	78-34-21 */**	YM643-YM670
D46046P	1	BACC63BP22D55PN PLUG-CONDUCTIVE	81205	1	32-41-11 675/198/R038	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46046PQ	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YC028
D46046PQ	1	BACC10KA22 BACKSHELL-CONDUCTIVE	81205	1	32-41-11 */**	YC029-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46048J	1	BACC63BV20F16S7 RCPT-CONDUCTIVE	81205	1	32-42-11 722/201/R026	YC001-YC030
D46048J	1	BACC63BV20B16S7 RCPT-CONDUCTIVE	81205	1	32-42-11 722/201/R026	YC031-YM670
D46048JK	1	BACC10KD20 BACKSHELL-CONDUCTIVE	81205	1	32-42-11 / /	YC001-YC030
D46048JK	1	BACC10KA20 BACKSHELL-CONDUCTIVE	81205	1	32-42-11 / /	YC031-YM670
D46048P	1	BACC63BP20C16P7 PLUG- CONDUCTIVE	81205	1	32-42-11 722/201/R024	YC001-YC030
D46048P	1	BACC63BP20D16P7 PLUG- CONDUCTIVE	81205	1	32-42-11 722/201/R024	YC031-YM670
D46048PQ	1	BACC10KD20 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 722/201/R024	YC001-YC028
D46048PQ	1	BACC10KD20 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */**	YC029-YC030
D46048PQ	1	BACC10KA20 BACKSHELL- CONDUCTIVE	81205	1	32-42-11 */**	YC031-YM670
D46050J	1	BACC63BV22F19S8 RCPT	81205	1	26-11-31 724/202/R025	YC001-YC030

EQUIPMENT LIST

D280A103

Section D46000

Page 14

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46050J	1	BACC63BV22B19S8 RCPT	81205	1	26-11-31 724/202/R025	YC031-YM670
D46050JK	1	BACC10KD22 BACKSHELL	81205	1	26-11-31 / /	YC001-YC030
D46050JK	1	BACC10KA22 BACKSHELL	81205	1	26-11-31 / /	YC031-YM670
D46050P	1	BACC63BP22C19P8 PLUG- CONDUCTIVE	81205	1	32-41-11 724/201/R25	YC001-YC030
D46050P	1	BACC63BP22D19P8 PLUG- CONDUCTIVE	81205	1	32-41-11 724/201/R025	YC031-YM670
D46050PQ	1	BACC10KD22 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC001-YC030
D46050PQ	1	BACC10KA22 BACKSHELL- CONDUCTIVE	81205	1	32-41-11 TBD/ /	YC031-YM670
D46051J	1	BACC45FN18-14P6 RCPT	81205	1	23-31-01 E001-03/ /	ALL
D46051P	1	BACC45FT18-14S6 PLUG E1-3 SHELF	81205	1	23-31-01 E001-03/ /	ALL
D46052J	1	BACC45FN20-39S7 RCPT-	81205	1	33-11-11 P006-00/ /	ALL
D46052P	1	BACC45FT20-39P7 PLUG-	81205	1	33-11-11 P006-00/ /	ALL
D46061J	1	BACC45FN20-39S6 RCPT-	81205	1	34-51-21 P006-00/ /	ALL
D46061P	1	BACC45FT20-39P6 PLUG-	81205	1	34-51-21 P006-00/ /	YC001-YC030, YK901-YM652
D46063J	1	BACC45FN20-28S8 RCPT-	81205	1	31-62-21 P006-00/ /	ALL
D46063P	1	BACC45FT20-28P8 PLUG-	81205	1	31-62-21 P006-00/ /	ALL
D46065J	1	BACC45FN22-32S RCPT-	81205	1	22-11-12 P006-00/ /	ALL
D46065P	1	BACC45FT22-32P PLUG-	81205	1	22-11-12 P006-00/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D46000

Page 15

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46067J	1	BACC45FN20-28S8 RCPT-	81205	1	34-57-21 P006-00/ /	ALL
D46067P	1	BACC45FT20-28P8 PLUG-	81205	1	34-57-21 P006-00/ /	YC001-YC007
D46067P	1	BACC45FT20-28P8 PLUG-	81205	1	34-57-21 AP0600B/ /	YC008-YM670
D46069J	1	BACC45FN14-12S7 RCPT-	81205	1	22-14-11 P006-00/ /	ALL
D46069P	1	BACC45FT14-12P7 PLUG-	81205	1	22-14-11 P006-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D46000
Page 16 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46100J	1	BACC45FN20-39P6 RCPT-	81205	1	32-44-11 J046-00/ /	YC004-YM670
D46100P	1	BACC45FT20-39S6 PLUG-	81205	1	32-44-11 J046-00/ /	YC004-YM670
D46102J	1	BACC45FN20-39S9 RCPT-	81205	1	32-64-12 J046-00/ /	YC004-YM670
D46102P	1	BACC45FT20-39P9 PLUG-	81205	1	32-64-12 J046-00/ /	YC004-YC030
D46102P	1	BACC45FT20-39P9 PLUG-	81205	1	32-64-12 AJ0046A/ /	YK901-YM670
D46104J	1	BACC45FN20-39S RCPT-	81205	1	31-52-31 J046-00/ /	YC004-YM670
D46104P	1	BACC45FT20-39P PLUG-	81205	1	21-37-31 J046-00/ /	YC004-YC030, YK901-YM670
D46106J	1	BACC45FN20-39S RCPT-	81205	1	76-21-21 J046-00/ /	YC004-YM670
D46106P	1	BACC45FT20-39P PLUG-	81205	1	76-21-21 J046-00/ /	YC004-YC026
D46106P	1	BACC45FT20-39P PLUG-	81205	1	76-21-21 AJ0046B/ /	YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46106PQ	1	BACC10JS20 BACKSHELL-	81205	1	76-21-21 */*/	YC004-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46108J	1	BACC45FN20-39S6 RCPT-	81205	1	31-52-21 J046-00/ /	YC004-YM670
D46108P	1	BACC45FT20-39P6 PLUG-	81205	1	21-25-11 J046-00/ /	YC004-YC030, YK901-YM670
D46110J	1	MTCPQKT1R2PFAD RCPT	06090	1	32-42-11 J046-00/ /	YC004-YM670
D46110P	1	MTCPQKT1P2SFAD PLUG-	06090	1	27-62-21 / /	YC004-YC007

EQUIPMENT LIST

D280A103

Section D46100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46110P	1	MTCPQKT1P2SFAD PLUG-	06090	1	27-62-21 264/178/R026	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46112J	1	BACC45FN20-39S7 RCPT-	81205	1	30-31-12 J046-00/ /	YC004-YM670
D46112P	1	BACC45FT20-39P7 PLUG-	81205	1	21-27-31 J046-00/ /	YC004-YM670
D46114J	1	BACC45FN20-39S RCPT-	81205	1	21-27-21 J046-00/ /	YC004-YM670
D46114P	1	BACC45FT20-39P PLUG-	81205	1	21-27-21 J046-00/ /	YC004-YC030, YK901-YM670
D46116J	1	BACC45FN18-31S8 RCPT-	81205	1	21-27-31 J046-00/ /	YC004-YK910, YL421-YL423, YM643
D46116J	1	BACC45FN20-41S8 RCPT-	81205	1	21-27-31 J046-00/ /	YK911-YL401, YL424-YL430, YM645-YM670
D46116P	1	BACC45FT18-31P8 PLUG-	81205	1	27-62-11 J046-00/ /	YC004-YC030, YK901-YK910, YL421-YL423, YM643
D46116P	1	BACC45FT20-41P8 PLUG-	81205	1	27-62-11 J046-00/ /	YK911-YL401, YL424-YL430, YM645-YM670
D46118J	1	MTCPQKT1R2SGCA RCPT-	06090	1	73-21-11 J046-00/ /	YC004-YM670
D46118P	1	MTCPQKT1P2PGCA PLUG-	06090	1	73-21-11 J046-00/ /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46120J	1	MTCPQKT1R2SFAC RCPT-	06090	1	21-43-21 J046-00/ /	YC004-YM670
D46120P	1	MTCPQKT1P2PFAC PLUG-	06090	1	29-11-11 J046-00/ /	YC004-YM670

EQUIPMENT LIST

D280A103

Section D46100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46122J	1	BACC45FN20-39S7 RCPT-	81205	1	52-71-11 J046-00/ /	YC004-YM670
D46122P	1	BACC45FT20-39P7 PLUG-	81205	1	27-62-11 J046-00/ /	YC004-YC030
D46122P	1	BACC45FT20-39P7 PLUG-	81205	1	27-62-11 AJ0046A/ /	YK901-YM670
D46124J	1	MTCPQKT1R2SFAA RCPT-	06090	1	29-11-12 J046-00/ /	YC004-YM670
D46124P	1	MTCPQKT1P2PFAA PLUG-CONDUCTIVE	06090	1	29-11-12 J046-00/ /	YC004-YM670
D46126J	1	BACC45FN20-39S8 RCPT-	81205	1	76-21-21 J046-00/ /	YC004-YM670
D46126P	1	BACC45FT20-39P8 PLUG-	81205	1	21-43-21 J046-00/ /	YC004-YM670
D46128J	1	MTCPQKT1R2SFBA RCPT-	06090	1	36-11-11 J046-00/ /	YC004-YM670
D46128P	1	MTCPQKT1P2PFBA PLUG-	06090	1	36-21-11 J046-00/ /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46130J	1	MTCPQKT1R2SFAA RCPT-	06090	1	21-27-31 J046-00/ /	YC004-YM670
D46130P	1	MTCPQKT1P2PFAA PLUG-	06090	1	21-27-31 J046-00/ /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429
D46130P	1	MTCPQKT1P2PFAA PLUG-	06090	1	21-27-31 AJ0046A/ /	YM643-YM652
D46132J	1	MTCPQKT1R2SGAD RCPT-	06090	1	78-34-21 J046-00/ /	YC004-YM670
D46132P	1	MTCPQKT1P2PGAD PLUG-	06090	1	78-34-21 J046-00/*/*	YC004-YC026

EQUIPMENT LIST

D280A103

Section D46100

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46132P	1	MTCPQKT1P2PGAD PLUG-	06090	1	78-34-21 AJ0046B/ /	YC028-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46136J	1	MTCPQKT1R2SGBA RCPT-	06090	1	32-31-12 J046-00/ /	YC004-YM670
D46136P	1	MTCPQKT1P2PGBA PLUG-CONDUCTIVE	06090	1	32-31-12 J046-00/ /	YC004-YM670
D46138J	1	MTCPQKT1R2SFAB RCPT-	06090	1	21-27-21 J046-00/ /	YC004-YM670
D46138P	1	MTCPQKT1P2PFAB PLUG-	06090	1	21-27-31 J046-00/ /	YC004-YL430
D46138P	1	MTCPQKT1P2PFAB PLUG-	06090	1	21-27-21 J046-00/ /	YM643-YM670
D46142J	1	MTCPQKT1R2SFBD RCPT-	06090	1	21-27-21 J046-00/ /	YC004-YM670
D46142P	1	MTCPQKT1P2PFBD PLUG-	06090	1	21-27-21 J046-00/ /	YC004-YM652
D46144J	1	MTCPQKT1R2SGBC RCPT-	06090	1	30-21-21 J046-00/ /	YC004-YM670
D46144P	1	MTCPQKT1P2PGBC PLUG-	06090	1	30-21-21 J046-00/ /	YC004-YC030, YM643-YM670
D46144P	1	MTCPQKT1P2PGBC PLUG-	06090	1	30-21-21 AJ0046A/ /	YC031-YL430
D46146J	1	MTCPQKT1R2SGBD RCPT-	06090	1	73-21-11 J046-00/ /	YC004-YM670
D46146P	1	MTCPQKT1P2PGBD PLUG-	06090	1	73-21-11 J046-00/ /	YC004-YC007
D46146P	1	MTCPQKT1P2PGBD PLUG-	06090	1	73-21-11 AJ0046A/ /	YC008-YM670
D46150J	1	BACC45FN20-39P6 RCPT-	81205	1	27-62-11 J046-00/ /	YC004-YM670

EQUIPMENT LIST

D280A103

Section D46100

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46150P	1	BACC45FT20-39S6 PLUG-	81205	1	27-62-11 AJ0046A/ /	YC004-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D46100
Page 5 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46438J	1	AMC02RA03B RCPT-	05574	1	52-71-13 616/298/L015	YC001-YL430
D46438P	1	AMC02PA03B PLUG-	05574	1	52-71-13 616/298/L015	YC001-YC030, YK901-YL430
D46440J	1	AMC02RA03B RCPT-	05574	1	52-71-13 616/303/R010	YC001-YL430
D46440J	1	AMC02RA03B RCPT-	05574	1	52-71-13 640/303/L010	YM643-YM670
D46440P	1	AMC02PA03B PLUG-	05574	1	52-71-14 616/303/R010	YC001-YC030, YK901-YL430
D46440P	1	AMC02PA03B PLUG-	05574	1	52-71-13 640/303/L008	YM643-YM652
D46461J	1	MTCPQKT2R22PGAB RECPT-CONDUCTIVE	06090	1	27-53-11 E001-01/ /	ALL
D46461P	1	MTCPQKT2P22SGAB PLUG-CONDUCTIVE	06090	1	27-53-11 E001-01/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section D46400

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46602J	1	BACC45FN18-14P6 RCPT-	81205	1	29-25-11 727+2/192/R044	ALL
D46602JK	1	BACC10GH18 BACKSHELL-STRAIGHT	81205	1	29-25-11 / /	ALL
D46602P	1	BACC45FT18-14S6 PLUG-	81205	1	29-25-11 727+2/192/R044	ALL
D46602PQ	1	BACC10GH18 BACKSHELL-	81205	1	29-25-11 */*/	ALL
D46606J	1	BACC45FN18-31S6 RCPT-	81205	1	26-16-22 AB0500DL/ /	ALL
D46606P	1	BACC45FT18-31P6 PLUG-	81205	1	26-16-22 AB0500DL/ /	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46606PQ	1	BACC10JS18 BACKSHELL	81205	1	26-16-22 */*/	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46608J	1	BACC45FN12-12S RCPT-	81205	1	26-23-11 AB0500DL/ /	ALL
D46608P	1	BACC45FT12-12P PLUG-	81205	1	26-23-11 AB0500DL/ /	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46608PQ	1	BACC10JS12 BACKSHELL	81205	1	26-23-11 */*/	YC008-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D46616J	1	BACC45FN20-25P7 RCPT-	81205	1	29-25-11 J011-00/ /	YM643-YM670
D46616P	1	BACC45FT20-25S7 PLUG-	81205	1	29-25-11 907/184/R030	YM643-YM670
D46616PQ	1	BACC10JC20 BACKSHELL	81205	1	29-25-11 / /	YM643-YM670

EQUIPMENT LIST

D280A103

Section D46600

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D46618J	1	BACC45FN20-16P RCPT-	81205	1	29-25-11 J011-00/ /	YM643-YM670
D46618P	1	BACC45FT20-16S PLUG-	81205	1	29-25-11 907/186/R030	YM643-YM670
D46618PQ	1	BACC10JC20 BACKSHELL	81205	1	29-25-11 / /	YM643-YM670
D46620J	1	BACC45FN20-25P7 RCPT-	81205	1	27-31-11 J011-00/ /	YC001-YL430
D46620P	1	BACC45FT20-25S7 PLUG-	81205	1	29-25-11 902/198/R035	YC001-YL430
D46620PQ	1	BACC10JC20 BACKSHELL	81205	1	29-25-11 / /	YC001-YC007
D46620PQ	1	BACC10JC20 BACKSHELL	81205	1	29-25-11 */*/*	YC008-YL430
D46622J	1	BACC45FN20-16P RCPT-	81205	1	29-25-11 J011-00/ /	YC001-YL430
D46622P	1	BACC45FT20-16S PLUG-	81205	1	29-25-11 902/196/R035	YC001-YL430
D46622PQ	1	BACC10JC20 BACKSHELL	81205	1	29-25-11 / /	YC001-YL430

EQUIPMENT LIST

D280A103

Section D46600

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D48080J	1	BACC63BV20F16PN RCPT-CONDUCTIVE	81205	1	26-11-31 P028-00/ /	YC001-YC030
D48080P	1	BACC63BP20C16SN PLUG-CONDUCTIVE	81205	1	26-11-31 724/171/R018	YC001-YC030
D48080P	1	BACC63BP20H16SN PLUG-CONDUCTIVE	81205	1	26-11-31 724/171/R018	YC031-YM670
D48080PQ	1	BACC10KE20 BACKSHELL- CONDUCTIVE	81205	1	26-11-31 TBD/ /	YC001-YC030
D48080PQ	1	M85049-51S20A BACKSHELL- CONDUCTIVE	81205	1	26-11-31 TBD/ /	YC031-YM670

EQUIPMENT LIST

D280A103

Section D48000
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D48100J	1	MTCPQKT1R2SFAA RCPT-	06090	1	27-53-11 J048-00/ /	YC004-YM670
D48100P	1	MTCPQKT1P2PFAA PLUG-CONDUCTIVE	06090	1	30-42-11 J048-00/ /	YC004-YM670
D48102J	1	MTCPQKT1R2SGBA RCPT-	06090	1	21-27-21 J048-00/ /	YC004-YM670
D48102P	1	MTCPQKT1P2PGBA PLUG-CONDUCTIVE	06090	1	21-27-21 J048-00/ /	YC004-YC030, YK901-YM670
D48104J	1	MTCPQKT1R2SFAD RCPT-	06090	1	30-31-11 J048-00/ /	YC004-YM670
D48104P	1	MTCPQKT1P2PFAD PLUG-	06090	1	21-27-21 J048-00/ /	YC004-YM670
D48106J	1	MTCPQKT1R2SFDB RCPT-	06090	1	21-43-21 J048-00/ /	YC004-YM670
D48106P	1	MTCPQKT1P2PFDB PLUG-CONDUCTIVE	06090	1	21-43-21 J048-00/ /	YC004-YC030, YK901-YM670
D48108J	1	MTCPQKT1R2SFDC RCPT-	06090	1	24-31-11 J048-00/ /	YC004-YM670
D48108P	1	MTCPQKT1P2PFDC PLUG-	06090	1	24-31-11 J048-00/ /	YC004-YC030, YK901-YM670
D48110J	1	MTCPQKT1R2SGBC RCPT-	06090	1	30-21-11 J048-00/ /	YC004-YM670
D48110P	1	MTCPQKT1P2PGBC PLUG-	06090	1	30-21-11 J048-00/ /	YC004-YM670
D48112J	1	MTCPQKT1R2SFDD RCPT-	06090	1	21-27-21 J048-00/ /	YC004-YM670
D48112P	1	MTCPQKT1P2PFDD PLUG-	06090	1	21-27-21 J048-00/ /	YC004-YC030, YK901-YM670
D48114J	1	MTCPQKT1R2SGAA RCPT-	06090	1	21-27-31 J048-00/ /	YC004-YM670
D48114P	1	MTCPQKT1P2PGAA PLUG-	06090	1	32-64-21 J048-00/ /	YC004-YC030, YK901-YM670
D48116J	1	MTCPQKT1R2SGDA RCPT-	06090	1	21-25-11 J048-00/ /	YC004-YM670

EQUIPMENT LIST

D280A103

Section D48100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D48116P	1	MTCPQKT1P2PGDA PLUG-	06090	1	21-27-31 J048-00/ /	YC004-YM670
D48118J	1	MTCPQKT1R2SFBB RCPT-	06090	1	26-21-11 J048-00/ /	YC004-YM670
D48118P	1	MTCPQKT1P2PFBB PLUG-	06090	1	26-21-11 J048-00/ /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D48120J	1	MTCPQKT1R2SFCA RCPT-	06090	1	21-27-31 J048-00/ /	YC004-YM670
D48120P	1	MTCPQKT1P2PFCA PLUG-	06090	1	76-21-11 J048-00/ /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D48122J	1	MTCPQKT1R2SGAC RCPT-	06090	1	21-27-21 J048-00/ /	YC004-YM670
D48122P	1	MTCPQKT1P2PGAC PLUG-	06090	1	76-21-11 J048-00/ /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D48124J	1	MTCPQKT1R2SFAB RCPT-	06090	1	21-27-21 J048-00/ /	YC004-YM670
D48124P	1	MTCPQKT1P2PFAB PLUG-	06090	1	21-27-21 J048-00/ /	YC004-YC030, YK901-YM670
D48126J	1	MTCPQKT1R2SFAB RCPT-	06090	1	21-27-31 J048-00/ /	YC004-YM670
D48126P	1	MTCPQKT1P2PFAB PLUG-	06090	1	21-27-31 J048-00/ /	YC004-YM670
D48128J	1	MTCPQKT1R2SGBD RCPT-	06090	1	28-41-11 J048-00/ /	YC004-YM670
D48128P	1	MTCPQKT1P2PGBD PLUG-	06090	1	28-41-11 J048-00/ /	YC004-YM670

EQUIPMENT LIST

D280A103

Section D48100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D48130J	1	MTCPQKT1R2SFBC RCPT-	06090	1	21-27-21 J048-00/ /	YC004-YM670
D48130P	1	MTCPQKT1P2PFBC PLUG-	06090	1	21-27-21 J048-00/ /	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D48132J	1	MTCPQKT1R2SFBC RCPT-	06090	1	24-22-31 J048-00/ /	YC004-YM670
D48132P	1	MTCPQKT1P2PFBC PLUG-	06090	1	24-22-31 J048-00/ /	YC004-YC050
D48132P	1	MTCPQKT1P2PFBC PLUG-	06090	1	24-22-31 AJ0048A/ /	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
D48134J	1	MTCPQKT1R2SGBA RCPT-	06090	1	30-11-11 J048-00/ /	YC004-YM670
D48134P	1	MTCPQKT1P2PGBA PLUG-	06090	1	73-21-12 J048-00/ /	YC004-YM670
D48136J	1	MTCPQKT1R2SGAC RCPT-	06090	1	73-21-11 J048-00/ /	YC004-YM670
D48136P	1	MTCPQKT1P2PGAC PLUG-	06090	1	78-32-51 J048-00/ /	YC004-YM670
D48138J	1	MTCPQKT1R2SFCA RCPT-	06090	1	26-21-11 J048-00/ /	YC004-YM670
D48138P	1	MTCPQKT1P2PFCA PLUG-	06090	1	26-21-11 J048-00/ /	YC004-YC050
D48138P	1	MTCPQKT1P2PFCA PLUG-	06090	1	26-21-11 AJ0048A/ /	YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652

EQUIPMENT LIST

D280A103

Section D48100

Page 3 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D48323J	1	BACC45FN12-12P RCPT	81205	1	23-31-06 E008-01/ /	YC001-YC050
D48323J	1	BACC45FN12-12P RECPT-	81205	1	23-11-21 E008-01/ /	YK907-YL401
D48323J	1	BACC45FN12-12P RCPT -	8205	1	23-11-21 E008-01/ /	YL421-YL430
D48323J	1	BACC45FN12-12P RECPT-	81205	1	23-32-21 E008-01/ /	YM643-YM646
D48323JK	1	BACC10JS12 BACKSHELL	81205	1	23-31-06 E008-01/ /	YC001-YC050
D48323JK	1	BACC10JS12 BACKSHELL	81205	1	23-11-21 E008-01/ /	YM643-YM646
D48323P	1	BACC45FT12A12S PLUG-	81205	1	23-31-06 E008-01/ /	YC001-YC030, YK907-YL430
D48323P	1	BACC45FT12A12S PLUG-	81205	1	23-32-11 E008-01/ /	YM643-YM652
D48335J	1	BACC63CC16-24S8 RCPT-CONDUCTIVE	81205	1	23-34-02 E008-01/ /	YC001-YC050
D48335JK		S280W604-13 BACKSHELL - STRAIGHT - FOR D48335J	81205	1	23-34-02 E008-01/ /	YC001-YC050
D48335P	1	BACC63CB16-24P8 RCPT-CONDUCTIVE	81205	1	23-34-02 313/186/R10	YC001-YC050
D48335PQ		S280W604-13 BACKSHELL - STRAIGHT - FOR D48335P	81205	1	23-34-02 E008-01/ /	YC001-YC050
D48337J	1	MTCPQKT1R2SGAA RCPT-CONDUCTIVE	06090	1	23-31-06 E008-01/ /	YC001-YC006
D48337J	1	MTCPQKT1R2SGBB RCPT-CONDUCTIVE	06090	1	23-31-06 E008-01/ /	YC007-YC050
D48337P	1	MTCPQKT1P2PGAA PLUG - CONDUCTIVE	06090	1	23-31-06 E008-01/ /	YC001-YC006
D48337P	1	MTCPQKT1P2PGBB PLUG - CONDUCTIVE	06090	1	23-31-06 E008-01/ /	YC007-YC050
D48339J	1	BACC63CC16-24S9 RCPT-CONDUCTIVE	81205	1	23-34-02 E008-01/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section D48300

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D48339JK		S280W604-13 BACKSHELL - STRAIGHT - FOR D48339J	81205	1	23-34-02 E008-01/ /	YC001-YC050
D48339P	1	BACC63CB16-24P9 PLUG-CONDUCTIVE	81205	1	23-34-02 313/184/R11	YC001-YC050
D48339PQ		S280W604-13 BACKSHELL - STRAIGHT - FOR D48339P	81205	1	23-34-02 E008-01/ /	YC001-YC050
D48389J	1	MTCPQKT2R26PFBB RCPT-	06090	1	23-34-01 E008-01/ /	YC001-YC006
D48389J	1	MTCPQKT2R26PFAD RCPT-	06090	1	23-34-01 E008-01/ /	YC007-YC050
D48389P	1	MTCPQKT2P26SGBB PLUG - CONDUCTIVE	06090	1	23-34-01 E008-01/ /	YC001-YC006
D48389P	1	MTCPQKT2P26SGAD PLUG - CONDUCTIVE	06090	1	23-34-01 E008-01/ /	YC007-YC030

EQUIPMENT LIST

D280A103

Section D48300

Page 2 End

Jan 14/2008



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D48901J	1	BACC45FN14-4S6 RECP	81205	1	22-13-11 P018-00/ /	ALL
D48901P	1	BACC45FT14-4P6 PLUG	81205	1	22-13-11 P018-00/ /	ALL

EQUIPMENT LIST

D280A103

Section D48900
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D49994J	1	MTCPQKT1R2PGCD RCPT - CONDUCTIVE	06090	1	79-31-11 E003-01/ /	YC001-YC030, YK901-YM670
D49994P	1	MTCPQKT1P2SGCD PLUG-	06090	1	79-31-11 E003-01/ /	ALL
D49996J	1	MTCPQKT2R26PFAA RCPT-	06090	1	28-23-11 E002-01/ /	ALL
D49996P	1	MTCPQKT2P26SFAA PLUG-	06090	1	28-23-11 E002-01/ /	ALL

EQUIPMENT LIST

D280A103

Section D49900
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
DA12489	1	BACI10AL40AS INSERT A -PLUG	81205	1	23-70-11 344/250/*	YK907-YM670
DA12489 T	1	BACC65AA2AF PLUG EPX SHELL	81205	1	23-70-11 344/ /	YK907-YM670

EQUIPMENT LIST

D280A103

Section DA1200
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
DB12489	1	BAC110AL40BS INSERT B		1	23-70-11 344/250/*	YK907-YM670

EQUIPMENT LIST

D280A103

Section DB1200

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
DM0001		BACC63CP22G398 CONNECTOR-FEED THROUGH	287A4304 81205	1	27-81-12 520/ /	ALL
DM0002		BACC63CP22G398 CONNECTOR-FEED THROUGH	287A4304 81205	1	27-81-22 520/ /	ALL
DM0003		BACC63CP22G396 CONNECTOR-FEED THROUGH	287A4304 81205	1	33-44-12 520/ /	ALL
DM0004		BACC63CP22G396 CONNECTOR-FEED THROUGH	287A4304 81205	1	28-23-12 520/ /	ALL
DM0005		BACC63CP18G117 CONNECTOR-FEED THROUGH	287A4304 81205	1	76-21-11 520/ /	ALL
DM0006		BACC63CP18G117 CONNECTOR-FEED THROUGH	287A4304 81205	1	76-21-21 520/ /	ALL
DM0007		BACC63CP22G398 CONNECTOR-FEED THROUGH	287A4304 81205	1	28-41-11 520/ /	ALL
DM0008		BACC63CP22G398 CONNECTOR-FEED THROUGH	287A4304 81205	1	28-41-12 520/ /	ALL
DM0009		BACC63CP22G39N CONNECTOR-FEED THROUGH	287A4304 81205	1	78-36-11 520/ /	ALL
DM0010		BACC63CP22G39N CONNECTOR-FEED THROUGH	287A4304 81205	1	73-21-21 520/ /	ALL
DM0011		BACC63CP22G3910 CONNECTOR-FEED THROUGH	287A4304 81205	1	73-21-21 520/ /	ALL
DM0012		BACC63CP22G3910 CONNECTOR-FEED THROUGH	287A4304 81205	1	73-21-21 520/ /	ALL
DM0013		BACC63CP22G397 CONNECTOR-FEED THROUGH	287A4304 81205	1	73-22-11 520/ /	ALL
DM0014		BACC63CP22G397 CONNECTOR-FEED THROUGH	287A4304 81205	1	30-21-21 520/ /	ALL
DM0015		BACC63CP18G11N CONNECTOR-FEED THROUGH	287A4304 81205	1	26-11-11 520/ /	ALL
DM0016		BACC63CP18G11N CONNECTOR-FEED THROUGH	287A4304 81205	1	26-12-12 520/ /	ALL
DM0017		BACC63CP22G399 CONNECTOR-FEED THROUGH	287A4304 81205	1	77-12-21 520/ /	ALL

EQUIPMENT LIST

D280A103

Section DM0000

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
DM0018		BACC63CP22G399 CONNECTOR-FEED THROUGH	287A4304 81205	1	24-21-21 520/ /	ALL
DM0019		BACC63CR16G24N CONNECTOR-FEED THROUGH	288A1671 81205	1	74-11-11 AW0258L/ /	ALL
DM0020		BACC63CR16G24N CONNECTOR-FEED THROUGH	288A1681 81205	1	74-11-11 AW0258R/ /	ALL
DM0021		BACC63CP22G39N CONNECTOR-FEED THROUGH	287A4304 81205	1	28-23-11 520/ /	ALL
DM0022		BACC63CP22G39N CONNECTOR-FEED THROUGH	287A4304 81205	1	28-21-11 520/ /	ALL
DM0023		BACC63CR22G399 CONNECTOR-FEED THROUGH	288A1671 81205	1	24-21-11 AW0258L/ /	ALL
DM0024		BACC63CR22G399 CONNECTOR-FEED THROUGH	288A1681 81205	1	24-21-21 AW0258R/ /	ALL
DM0025		BACC63CR22G39N CONNECTOR-FEED THROUGH	288A1671 81205	1	73-21-21 AW0258L/ /	ALL
DM0026		BACC63CR22G39N CONNECTOR-FEED THROUGH	288A1681 81205	1	73-21-21 AW0258R/ /	ALL
DM0027		BACC63CR22G396 CONNECTOR-FEED THROUGH	288A1671 81205	1	73-21-21 AW0258L/ /	ALL
DM0028		BACC63CR22G396 CONNECTOR-FEED THROUGH	288A1681 81205	1	73-21-11 AW0258R/ /	ALL
DM0032		BACC63CP22S39N CONNECTOR FEED-THRU ASSY	287A4304 81205	1	47-30-11 536/164/L036	YC001-YL425, YL427-YM646, YM651-YM670
DM0044		BACC63CP22S39N CONNECTOR FEED-THRU ASSY	287A4304 81205	1	47-30-11 536/166/R037	YC001-YL425, YL427-YM646, YM651-YM670
DM0050		BACC63CP22G3910 CONNECTOR-FEED THROUGH	287A4304 81205	1	21-51-11 536/163/L009	ALL
DM0060		BACC63CP22G3910 CONNECTOR-FEED THROUGH	287A4304 81205	1	21-51-21 536/159/R026	ALL

EQUIPMENT LIST

D280A103

Section DM0000

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
DP1204		MS3459KS-10SL-4 PLUG-PUMP DEP VLV	REFERENCE	2	29-11-11 ENG/ /	ALL

EQUIPMENT LIST

D280A103

Section DP1200
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
DR9001	9	BACS16AF1 SOCKET (737-EB34-0155)	81205	1	34-41-11 J00022/ /	YC003-YC006
DR9002	9	BACS16AF1 SOCKET- (737-EB34-0155)	81205	1	34-49-11 J00024/ /	YC003-YC006

EQUIPMENT LIST

D280A103

Section DR9000

Page 1 End

Oct 15/2007



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E001-01		284A0711 SHELF	284A0710	0	91-03-01 E001-01/ /	ALL
E001-02		284A0712 SHELF	284A0710 81205	1	91-03-01 E001-02/ /	ALL
E001-03		284A0713 SHELF	284A0710 81205	1	91-03-01 E001-03/ /	ALL
E001-04		284A0714 SHELF	284A0710	0	91-03-01 E001-04/ /	ALL
E001-05		284A0715 SHELF	284A0710	0	91-03-01 E001-05/ /	ALL

EQUIPMENT LIST

D280A103

Section E001
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E002-01		284A0721 SHELF	284A0720 81205	1	91-03-02 E002-01/ /	ALL
E002-02		284A0722 SHELF	284A0720 81205	1	91-03-02 E002-02/ /	ALL

EQUIPMENT LIST

D280A103

Section E002
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E003-01		284A0731 SHELF	284A0730 81205	1	91-03-03 E003-01/ /	ALL
E003-02		284A0732 SHELF	284A0730 81205	1	91-03-03 E003-02/ /	ALL
E003-03		284A0733 SHELF	284A0730 81205	1	91-03-03 E003-03/ /	ALL

EQUIPMENT LIST

D280A103

Section E003
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E004-01		284A0741 SHELF	284A0740	0	91-03-04 E004-01/ /	ALL
E004-02		284A0742 SHELF	284A0740	0	91-03-04 E004-02/ /	ALL

EQUIPMENT LIST

D280A103

Section E004
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E005-01		284A0751 SHELF	284A0750	0	91-03-05 E005-01/ /	ALL
E005-02		284A0752 SHELF	284A0750	0	91-03-05 E005-02/ /	ALL

EQUIPMENT LIST

D280A103

Section E005
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E006-01		284A0761 SHELF	284A0760	1	91-03-06 E006-01/ /	ALL
E006-02		284A0762 SHELF	284A0760	0	91-03-06 E006-02/ /	ALL

EQUIPMENT LIST

D280A103

Section E006
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E008-01		284A0781 SHELF	284A0780	0	91-03-08 E008-01/ /	ALL

EQUIPMENT LIST

D280A103

Section E008
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E020-00		284A0402 SHELF-FLT DATA REC	284A0402	0	9100XX 930/295/0000	ALL

EQUIPMENT LIST

D280A103

Section E020
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
F00001C		S345A001-205 TANK UNIT 1-CENTER TANK (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00001C		S345A001-205 TANK UNIT 1-CENTER TANK (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00001L		S345A001-113 TANK UNIT 1-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00001L		S345A001-113 TANK UNIT 1-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00001R		S345A001-113 TANK UNIT 1-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00001R		S345A001-113 TANK UNIT 1-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00002C		S345A001-206 TANK UNIT 2-CENTER TANK (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00002C		S345A001-206 TANK UNIT 2-CENTER TANK (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00002L		S345A001-114 TANK UNIT 2-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00002L		S345A001-114 TANK UNIT 2-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00002R		S345A001-114 TANK UNIT 2-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00002R		S345A001-114 TANK UNIT 2-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00003C		S345A001-207 TANK UNIT 3-CENTER TANK (737-800)	345A3101 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00003C		S345A001-207 TANK UNIT 3-CENTER TANK (737-700)	345A3101 81205	1	28-41-11 //	YM643-YM652

EQUIPMENT LIST

D280A103

Section F00000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
F00003L		S345A001-115 TANK UNIT 3-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00003L		S345A001-115 TANK UNIT 3-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00003R		S345A001-115 TANK UNIT 3-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00003R		S345A001-115 TANK UNIT 3-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00004C		S345A001-204 TANK UNIT 4-CENTER TANK (737-800)	345A3101 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00004C		S345A001-204 TANK UNIT 4-CENTER TANK (737-700)	345A3101 81205	1	28-41-11 //	YM643-YM652
F00004L		S345A001-116 TANK UNIT 4-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00004L		S345A001-116 TANK UNIT 4-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00004R		S345A001-116 TANK UNIT 4-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00004R		S345A001-116 TANK UNIT 4-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00005C		S345A001-204 TANK UNIT 5-CENTER TANK (737-800)	345A3101 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00005C		S345A001-204 TANK UNIT 5-CENTER TANK (737-700)	345A3101 81205	1	28-41-11 //	YM643-YM652
F00005L		S345A001-117 TANK UNIT 5-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00005L		S345A001-117 TANK UNIT 5-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652

EQUIPMENT LIST

D280A103

Section F00000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
F00005R		S345A001-117 TANK UNIT 5-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00005R		S345A001-117 TANK UNIT 5-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00006C		S345A001-207 TANK UNIT 6-CENTER TANK (737-800)	345A3101 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00006C		S345A001-207 TANK UNIT 6-CENTER TANK (737-700)	345A3101 81205	1	28-41-11 //	YM643-YM652
F00006L		S345A001-118 TANK UNIT 6-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00006L		S345A001-118 TANK UNIT 6-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00006R		S345A001-118 TANK UNIT 6-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00006R		S345A001-118 TANK UNIT 6-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00007C		S345A001-206 TANK UNIT 7-CENTER TANK (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00007C		S345A001-206 TANK UNIT 7-CENTER TANK (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00007L		S345A001-119 TANK UNIT 7-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00007L		S345A001-119 TANK UNIT 7-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00007R		S345A001-119 TANK UNIT 7-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00007R		S345A001-119 TANK UNIT 7-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652

EQUIPMENT LIST

D280A103

Section F00000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
F00008C		S345A001-205 TANK UNIT 8-CENTER TANK (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00008C		S345A001-205 TANK UNIT 8-CENTER TANK (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00008L		S345A001-120 TANK UNIT 8-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00008L		S345A001-120 TANK UNIT 8-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00008R		S345A001-120 TANK UNIT 8-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00008R		S345A001-120 TANK UNIT 8-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00009L		S345A001-109 TANK UNIT 9-TANK 1 (737-800)	34543111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00009L		S345A001-109 TANK UNIT 9-TANK 1 (737-700)	34543111 81205	1	28-41-11 //	YM643-YM652
F00009R		S345A001-109 TANK UNIT 9-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00009R		S345A001-109 TANK UNIT 9-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00010L		S345A001-110 TANK UNIT 10-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00010L		S345A001-110 TANK UNIT 10-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00010R		S345A001-110 TANK UNIT 10-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00010R		S345A001-110 TANK UNIT 10-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652

EQUIPMENT LIST

D280A103

Section F00000

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
F00011L		S345A001-121 TANK UNIT 11-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00011L		S345A001-121 TANK UNIT 11-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00011R		S345A001-121 TANK UNIT 11-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00011R		S345A001-121 TANK UNIT 11-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00012L		S345A001-121 TANK UNIT 12-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00012L		S345A001-121 TANK UNIT 12-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00012R		S345A001-121 TANK UNIT 12-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00012R		S345A001-121 TANK UNIT 12-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00015C		S345A001-020 COMP-CENTER TANK (737-800)	345A3101 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00015C		S345A001-020 COMP-CENTER TANK (737-700)	345A3101 81205	1	28-41-11 //	YM643-YM652
F00015L		S345A001-020 COMP-TANK 1 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00015L		S345A001-020 COMP-TANK 1 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652
F00015R		S345A001-020 COMP-TANK 2 (737-800)	345A3111 81205	1	28-41-11 //	YC001-YK912, YK918-YK919, YL401-YL429
F00015R		S345A001-020 COMP-TANK 2 (737-700)	345A3111 81205	1	28-41-11 //	YM643-YM652

EQUIPMENT LIST

D280A103

Section F00000
Page 5 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
G00009		S281A001-101 GEN-INTEGRATED DRIVE	332A2200 81205	2	24-11-11 ENG/ /	ALL
G00010		S281A001-201 CONTROL UNIT-GENERATOR 1	284A0420 81205	1	24-22-11 E002-01/ /	YC001-YC011
G00010		S281A001-202 CONTROL UNIT-GENERATOR 1	284A0420 81205	1	24-22-11 E002-01/ /	YC012-YC026
G00010		S281A001-204 CONTROL UNIT-GENERATOR 1	284A0420 81205	1	24-22-11 E002-01/ /	YC028-YM670
G00012		S281A001-201 CONTROL UNIT-GENERATOR 2	284A0440 81205	1	24-22-21 E004-02/ /	YC001-YC011
G00012		S281A001-202 CONTROL UNIT-GENERATOR 2	284A0440 81205	1	24-22-21 E004-02/ /	YC012-YC026
G00012		S281A001-204 CONTROL UNIT-GENERATOR 2	284A0440 81205	1	24-22-21 E004-02/ /	YC028-YM670
G00013		28B545-7A STARTER/GENERATOR-AUXILIARY POWER UNIT	351A1000 99193	1	24-21-31 1100/232/R010	ALL
G00013 U		312W5220-3 WASHER COVER	81205	2	24-21-31 / /	ALL
G00013 V		312W5220-9 SEAL	81205	1	24-21-31 / /	ALL
G00013 W		NAS6703U22 BOLT	81205	1	24-21-31 / /	ALL
G00013 X		NAS1149C0363R WASHER	81205	1	24-21-31 / /	ALL
G00013 Y		NAS1805-3 NUT	81205	1	24-21-31 / /	ALL
G00013 Z		287T4817-5 FANNING STRIP	81205	1	24-21-31 / /	ALL
G00014		S281A001-201 CONTROL UNIT-APU GENERATOR	284A0420 81205	1	24-22-31 E002-01/ /	YC001-YC011
G00014		S281A001-202 CONTROL UNIT-APU GENERATOR	284A0420 81205	1	24-22-31 E002-01/ /	YC012-YC026
G00014		S281A001-204 CONTROL UNIT-APU GENERATOR	284A0420 81205	1	24-22-31 E002-01/ /	YC028-YM670

EQUIPMENT LIST

D280A103

Section G00000

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
G00015		S281A001-301 CONTROL UNIT-BUS POWER	284A0440 81205	1	24-41-11 E004-02/ /	YC001-YC011
G00015		S281A001-302 CONTROL UNIT-BUS POWER	284A0440 81205	1	24-41-11 E004-02/ /	YC012-YM670

EQUIPMENT LIST

D280A103

Section G00000
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
J00004		284A1204-1 JUNCTION BOX	284A1204	1	MULTI 262/167/R025	ALL
J00005		65-52259-41 JUNCTION BOX	65-52259 81205	1	27-41-11 285/166/R025	ALL
J00009		284A0816 PNL-BATTERY	284A0816 81205	1	24-31-11 344/155/L014	ALL
J00011		284A1214-NONE6- MISC RLY & CKT BRKR PNL-AFT EQPT CTR	284A0214 81205	1	MULTI 901/198/R035	YC001-YL430
J00011		284A1214-E6RACK- MISC RLY & CKT BRKR PNL-AFT EQPT CTR	284A0214 81205	1	MULTI 904/186/R031	YM643-YM670
J00019		284A0202-1 JUNCTION BOX	284A0202 81205	1	31-52-11 254/207/L003	ALL
J00020		284A1203-1 JUNCTION BOX	284A1203 81205	1	MULTI 268/166/L025	ALL
J00022		284A1222-1 JUNCTION BOX	284A1222 81205	1	MULTI 259/180/L020	ALL
J00023		284A1223-1 JUNCTION BOX	284A1223	1	MULTI 345/160/L020	ALL
J00024		284A1224-1 JUNCTION BOX	284A1224	1	MULTI 259/180/R020	ALL
J00039		284A1239 JUNCTION BOX	284A1239 81205	0	MULTI 359/166/L020	YK907-YL430
J00046		287A4130501 INTEGRATION BOX ASSY	287A4130 81205	1	21-25-11 263/177/R031	YC004-YM670
J00048		287A4140501 INTEGRATION BOX ASSY	287A4140 81205	1	21-27-21 263/177/L033	YC004-YM670

EQUIPMENT LIST

D280A103

Section J00000

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00001		10-61803-32 LT-EMERG EXIT UNARMED	65-73709 81205	1	33-51-11 P005-00/ /	ALL
L00001 T		387 LAMP-	65-73709 08806	2	33-51-11 P005-00/ /	ALL
L00006		S283A325-3 LT-OVERWING ESCAPE-L	284A0121 81205	1	33-51-13 651/227/L074	YC001-YL430
L00006		S283A325-3 LT-OVERWING ESCAPE-L	284A0121 81205	1	33-51-13 651/226/L074	YM643-YM670
L00006 T		767 LAMP-	S283A325 08806	1	33-51-14 651/227/L074	YC001-YL430
L00006 T		767 LAMP-	S283A325 08806	1	33-51-14 651/226/L074	YM643-YM670
L00007		S283A325-3 LT-OVERWING ESCAPE-R	284A0121 81205	1	33-51-13 651/226/R074	ALL
L00007 T		767 LAMP-	S283A325 08806	1	33-51-13 651/226/R074	ALL
L00008		81000-17502 LT-MAP(CAPT)	232A5112 72914	1	33-17-11 221/264/L015	YC001-YC026
L00008 T		1308 LAMP-	232A5112 08806	1	33-17-11 221/264/L015	YC001-YC026
L00009		81000-17502 LT-MAP (F/O)	232A5112 72914	1	33-17-11 221/264/R015	ALL
L00009 T		1308 LAMP-	233A5112 08806	1	33-17-11 221/264/R015	ALL
L00010		34265-8 LT-FLIGHT K1T-CAPT	232A5110 72914	1	33-17-11 219/224/L036	ALL
L00010 T		1864 LAMP-	232A5110 08806	1	33-17-11 219/224/L036	ALL
L00011		34265-8 LT-FLIGHT K1T-F/O	232A5110 72914	1	33-17-11 265/243/R022	ALL
L00011 T		1864 LAMP-	232A5110 08806	1	33-17-11 265/243/R022	ALL
L00012		34265-8 LT-F/OBS READING	232A5110 72914	1	33-17-11 265/243/R022	ALL

EQUIPMENT LIST

D280A103

Section L00000

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00012 T		1864 LAMP-	232A5110 08806	1	33-17-11 265/243/R022	ALL
L00013		34265-8 LT- S/OBS READING	233A5100 72914	1	33-17-11 254/265/L029	YC001-YC050, YK910-YK920
L00013 T		1864 LAMP-	232A5110 08806	1	33-17-11 254/265/L029	YC001-YC050, YK910-YK920
L00015		A-8985-16 LT-ACCESSORY LIGHT LEFT	284A0152 72914	1	33-35-11 1064/285/L036	ALL
L00015 T		1665 LAMP-	A008985 08806	1	33-35-11 1064/285/L038	ALL
L00016		A-8985-16 LT-ACCESSORY LIGHT RIGHT	284A0152 72914	1	33-35-11 1040/285/R038	ALL
L00016 T		1665 LAMP-	A008985 08806	1	33-35-11 1040/285/R038	ALL
L00019		10-61803-72 LT-CAPT CALL	233A3303 81205	1	23-42-11 P005-00/ /	YC001-YK906
L00019 T		387 LAMP-	65-73709 08806	2	23-42-01 P005-00/ /	YC001-YK906
L00023		S417N503-13 LT-NO SMOKING FASTEN SEAT BELTS SIGN	415A1104 81205	1	33-25-12 350/290/L023	YC001-YC050
L00023		BR9442-910 LT-NO SMOKING FASTEN SEAT BELTS SIGN	417A5601 81205	1	33-25-21 350/290/L023	YK901-YK910, YK918, YL421- YL426
L00023		BR9442-910 LT-NO SMOKING FASTEN SEAT BELTS SIGN	417A5601 81205	1	33-25-21 342/277/L027	YK911-YK917, YK919-YL401, YL427-YL430
L00023		BR9442-920 LT-NO SMOKING FASTEN SEAT BELTS SIGN	415A1104 81205	1	33-25-21 350/290/L023	YM643-YM651
L00023		BR9442-920 LT-NO SMOKING FASTEN SEAT BELTS SIGN	415A1104 81205	1	33-25-21 342/277/L027	YM652-YM670
L00034		S283A309-3 LT-WING ILLUMINATION-LEFT	284A0111 81205	1	33-41-11 500C+10/222/L074	YC001-YL430
L00034		S283A309-3 LT-WING ILLUMINATION-LEFT	284A0111 81205	1	33-41-11 470/222/L074	YM643-YM670

EQUIPMENT LIST

D280A103

Section L00000

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00034	T	HLX64621 LAMP-	S283A309 08805	1	33-41-11 500C+11/222/L074	YC001-YL430
L00034	T	HLX64621 LAMP-	S283A309 08805	1	33-41-11 470/222/L074	YM643-YM670
L00035		S283A309-4 LT-WING ILLUMINATION-RIGHT	284A0111 81205	1	33-41-11 500C+10/222/R074	YC001-YL430
L00035		S283A309-4 LT-WING ILLUMINATION-RIGHT	284A0111 81205	1	33-41-11 470/222/R074	YM643-YM670
L00035	T	HLX64621 LAMP-	S283A309 08805	1	33-41-11 500C+11/222/R074	YC001-YL430
L00035	T	HLX64621 LAMP-	S283A309 08805	1	33-41-11 470/222/R074	YM643-YM670
L00036		S283A305-1 LT-UPPER ANTI-COLLISION	284A0122 81205	1	33-44-11 568/306/R007	ALL
L00036	T	55-2211 FLASH TUBE	S283A305 72914	1	33-44-11 568/306/R007	ALL
L00037		S283A305-2 LT-LOWER ANTI-COLLISION	284A0161 81205	1	33-44-11 644/144/0000	ALL
L00037	T	55-2211 FLASH TUBE	S283A305 72914	1	33-44-11 644/144/0000	ALL
L00038		S283A313-2 FWD WING TIP ASSY R	284A1181 81205	1	33-43-11 727B/245/R663	YC001-YC050
L00038	T	HLX64621 LAMP-	S283A313 08805	2	33-43-11 727B/245/R663	YC001-YC050
L00038	U	31-8138-1 STROBE SUB ASSY	S283A313 72914	1	33-44-12 727B/245/R663	YC001-YC050
L00040		S283A313-1 FWD WING TIP ASSY L	284A1181 81205	1	33-43-11 727B/245/L663	YC001-YC050
L00040	T	HLX64621 LAMP-	S283A313 08805	2	33-43-11 727B/245/L663	YC001-YC050
L00040	U	31-8138-1 STROBE SUB ASSY	S283A313 72914	1	33-44-12 727B/245/L663	YC001-YC050
L00042		S283A313-103 LT-AFT POSITION-R	284A1183 81205	1	33-43-11 727E/245/R674	YC001-YC050

EQUIPMENT LIST

D280A103

Section L00000

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00042 T		HLX64621 LAMP-	S283A313 08805	2	33-43-11 727E/245/R674	YC001-YC050
L00043		S283A313-103 LT-AFT POSITION-L	284A1183 81205	1	33-43-11 727E/245/L674	YC001-YC050
L00043 T		HLX64621 LAMP-	S283A313 08805	2	33-43-11 727E/245/L674	YC001-YC050
L00046		30-0909-201 LT-TAIL STROBE	284A0162 72914	1	33-44-12 1216/284/0000	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
L00047		10-61803-12 LT-EQUIP COOLING EXHAUST OFF	233A3101 81205	1	21-27-21 P005-00/ /	ALL
L00050		S233W810-4 FLOODLIGHT-MAIN PANEL, CTR (-800)	233A8104 81205	1	33-14-11 P007-00/ /	YC001-YK910, YK918, YL421- YL426
L00050		800-010058-1 FLOODLIGHT-MAIN PANEL, CTR (-800)	233A8104 81205	1	33-14-11 P007-00/ /	YK911-YK917, YK919-YL401, YL427-YL430
L00050		S233W810-4 FLOODLIGHT-MAIN PANEL, CTR (-700)	233A8104 81205	1	33-14-11 P007-00/ /	YM643-YM647
L00050		800-010058-1 FLOODLIGHT-MAIN PANEL, CTR (-700)	233A8104 81205	1	33-14-11 P007-00/ /	YM649-YM670

EQUIPMENT LIST

D280A103

Section L00000

Page 4 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00170		50-0199-13 LT-NOSE GEAR TAXI	284A0101 72914	1	33-45-11 286/127/0000	ALL
L00170 T		4551 LAMP-	50-0199 08806	1	33-45-11 286/126/0000	ALL
L00171		10-0015-5 LT-NOSE WHEEL WELL FLOOD	284A0104 72914	1	33-32-11 228/177/L004	ALL
L00171 T		3011 LAMP-	10-0015 08806	1	33-32-11 228/177/L004	ALL
L00172		10-0015-5 LT-LEFT MAIN WHEEL WELL	284A0123 72914	1	33-32-11 725/194/L033	ALL
L00172 T		3011 LAMP-	10-0015 08806	1	33-32-11 725/194/L033	ALL
L00173		10-0015-5 LT-RIGHT MAIN WHL WELL	284A0123 72914	1	33-32-11 698/200/R018	ALL
L00173 T		3011 LAMP-	10-0015 08806	1	33-32-11 698/200/R018	ALL
L00174		A-8985-16 LT-MAIN GEAR INSPECTION LIGHT LEFT	284A0123 72914	1	33-32-11 666/182/L072	ALL
L00174 T		1665 LAMP-	A008985 08806	1	33-32-11 666/182/L072	ALL
L00175		A-8985-16 LT-MAIN GEAR INSPECTION LIGHT RIGHT	65-55495 72914	1	33-32-11 667/182/R072	ALL
L00175 T		1665 LAMP-	A008985 08806	1	33-32-11 667/182/R072	ALL
L00176		A-8985-16 LT-A/C COMPT LEFT	284A0124 72914	1	33-33-11 538/152/L038	ALL
L00176 T		1665 LAMP-	A008985 08806	1	33-33-11 538/152/L038	ALL
L00177		A-8985-16 LT-A/C COMPT LEFT	284A0124 72914	1	33-33-11 579/155/L038	ALL
L00177 T		1665 LAMP-	A008985 08806	1	33-33-11 579/155/L038	ALL
L00178		A-8985-16 LT-A/C COMPT LEFT	284A0124 72914	1	33-33-11 654/152/L039	ALL

EQUIPMENT LIST

D280A103

Section L00100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00178 T		1665 LAMP-	A008985 08806	1	33-33-11 654/152/L039	ALL
L00179		A-8985-16 LT-A/C COMPARTMENT RIGHT	284A0124 72914	1	33-33-11 538/154/R039	ALL
L00179 T		1665 LAMP-	A008985 08806	1	33-33-11 538/154/R039	ALL
L00180		A-8985-16 LT-A/C COMPARTMENT RIGHT	284A0124 72914	1	33-33-11 579/154/R038	ALL
L00180 T		1665 LAMP-	A008985 08806	1	33-33-11 579/154/R038	ALL
L00181		A-8985-16 LT-A/C COMPARTMENT RIGHT	284A0124 72914	1	33-33-11 654/151/R039	ALL
L00181 T		1665 LAMP-	A008985 08806	1	33-33-11 654/151/R038	ALL
L00182		A-8985-16 LT-A/C COMPARTMENT KEEL BEAM	284A0124 72914	1	33-33-11 554/158/L007	ALL
L00182 T		1665 LAMP-	A008985 08806	1	33-33-11 554/158/L007	ALL
L00183		A-8985-16 LT-A/C COMPARTMENT DOME LEFT	284A0124 72914	1	33-33-11 614/158/L009	ALL
L00183 T		1665 LAMP-	A008985 08806	1	33-33-11 614/158/L009	ALL
L00184		A-8985-16 LT-A/C COMPARTMENT DOME RIGHT	284A0124 72914	1	33-33-11 572/155/R008	ALL
L00184 T		1665 LAMP-	A008985 08806	1	33-33-11 572/155/R008	ALL
L00185		S453W071-6 LT-FWD CARGO CMPT	284A0112 81205	1	33-36-11 435/203/L010	YC001-YC030
L00185		S453W071-11 LT-FWD CARGO CMPT	284A0112 81205	1	33-36-11 435/203/L010	YC031-YM670
L00185 T		2233 LAMP-	69-23695 08806	1	33-36-11 433/203/L010	ALL
L00186		S453W07-6 LT-FWD CARGO CMPT	284A0112 81205	1	33-36-11 469/203/L005	YC001-YC030

EQUIPMENT LIST

D280A103

Section L00100

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00186		S453W071-11 LT-FWD CARGO CMPT	284A0112 81205	1	33-36-11 469/203/L005	YC031-YM670
L00186 T		2233 LAMP-	69-23695 08806	1	33-36-11 473/203/L010	ALL
L00187		S453W071-6 LT-FWD CARGO CMPT	284A0112 81205	1	33-36-11 500/203/R010	YC001-YC030
L00187		S453W071-11 LT-FWD CARGO CMPT	284A0112 81205	1	33-36-11 500/203/R010	YC031-YM670
L00187 T		2233 LAMP-	69-23695 08806	1	33-36-11 513/203/L010	ALL
L00188		S453W071-11 LT-FWD CARGO CMPT	384A0112 81205	1	33-36-11 500A+13/203/R010	YM643-YM670
L00188 T		2233 LAMP-	69-23695 08806	1	33-36-11 500A+13/203/R010	YM643-YM670
L00189		S453W071-6 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 727B+7/205/L011	YC001-YC030
L00189		S453W071-11 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 727B+7/205/L011	YC031-YM670
L00189 T		2233 LAMP-	69-23695 08806	1	33-36-12 727B+7/205/L011	ALL
L00190		S453W071-6 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 727A+10/205/R019	YC001-YC030
L00190		S453W071-11 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 727A+10/205/R019	YC031-YM670
L00190 T		2233 LAMP-	69-23695 08806	1	33-36-12 727A+10/205/R019	ALL
L00191		S453W071-6 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 754/205/L010	YC001-YC030
L00191		S453W071-11 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 754/205/L010	YC031-YM670
L00191 T		2233 LAMP-	69-23695 08806	1	33-36-12 754/205/L010	ALL
L00192		S453W071-6 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 774/205/R010	YC001-YC030

EQUIPMENT LIST

D280A103

Section L00100

Page 3

Feb 09/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00192		S453W071-11 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 774/205/R010	YC031-YM670
L00192 T		2233 LAMP-	69-23695 08806	1	33-36-12 774/205/R010	ALL
L00193		S453W071-6 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 834/205/L019	YC001-YC030
L00193		S453W071-11 LT-AFT CARGO CMPT	284A0131 81205	1	33-36-12 834/205/L019	YC031-YM670
L00193 T		2233 LAMP-	69-23695 08806	1	33-36-12 834/205/L019	ALL
L00194		15-0093-5 LT-FWD CARGO DOOR SILL	284A0112 72914	1	33-36-11 463/198/R064	ALL
L00194 T		1665IF LAMP-	15-0093 08806	1	33-36-11 463/198/R064	ALL
L00195		15-0093-5 LT-AFT CARGO DOOR SILL	284A0131 72914	1	33-36-12 795/199/R064	ALL
L00195 T		1665IF LAMP-	15-0093 08806	1	33-36-12 795/199/R064	ALL
L00199		69-23695-7 LTS-FWD LWR SERV COMPT LTS.	284A0103 81205	1	33-34-11 218/206/L005	ALL
L00199 T		1665 LAMP-	69-23695 08806	1	33-34-11 218/206/L005	ALL

EQUIPMENT LIST

D280A103

Section L00100

Page 4 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00200		69-23695-7 LTS-FWD LWR SERV COMPT LTS.	284A0103 81205	1	33-34-11 218/206/R005	ALL
L00200 T		1665 LAMP-	69-23695 08806	1	33-34-11 218/206/R005	ALL
L00201		69-23695-7 LTS-FWD LWR SERV COMPT LTS	284A0103 81205	1	33-34-11 201/204/R008	ALL
L00201 T		1665 LAMP-	69-23695 08806	1	33-34-11 201/204/R008	ALL
L00202		69-23695-7 LTS-E/E RACK	284A0102 72914	1	33-34-11 354/200/L020	ALL
L00202 T		1665 LAMP-	69-23695 08806	1	33-34-11 354/200/L020	ALL
L00203		69-23695-7 LTS-E/E RACK	284A0102 72914	1	33-34-11 354/200/R014	ALL
L00203 T		1665 LAMP-	69-23695 08806	1	33-34-11 354/200/R014	ALL
L00205		15-0103-1 LT-APU SERVICE LIGHT	284A0151 72914	1	33-35-11 1089/220/L003	ALL
L00205 T		1665 LAMP-	15-0103 08806	1	33-35-11 1089/220/L003	ALL
L00273		10-1113-3 LIGHT-WHITEDOME, LEFT	232A5110 72914	1	33-14-12 270/274/L017	ALL
L00273 T		2233 LAMP-	232A5110 08806	4	33-14-12 270/ /	ALL
L00273 U		1317 LAMP-	65-45757 08806	1	33-51-11 / /	ALL
L00274		15-0129 LIGHT-WHITEDOME, RIGHT	232A5110 72914	1	33-14-12 254/274/R016	ALL
L00274 T		2233 LAMP-	232A5110 08806	1	33-14-12 254/ /	ALL
L00277		15-0026-3 LIGHT-CONTROL STAND	233A3303 72914	1	33-14-12 P005-00/ /	ALL
L00277 T		1665 LAMP-	233A3303 08806	1	33-14-12 P005-00/ /	ALL

EQUIPMENT LIST

D280A103

Section L00200

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00278		A-8985-16 LT-TAIL CONE	284A0153 72914	1	33-35-11 1181/289/L009	ALL
L00278 T		1665 LAMP-	A008985 08806	1	33-35-11 1181/289/L009	ALL
L00279		A6850C-5 LT-OUTBOARD REFUEL PANEL FLOOD	65C28094 72914	1	28-44-11 RW350/P04/RLE	ALL
L00280		A6850C-5 LT-OUTBOARD REFUEL NOZZLE FLOOD	65C28094 72914	1	28-44-11 RW380/M03/RLE	ALL
L00282		65-0028-11 LT-TANK 1 REFUEL VALVE OPEN	69-73588 72914	1	28-44-11 P015-00/ /	ALL
L00283		65-0028-11 LT-TANK 2 REFUEL VALVE OPEN	69-73588 72914	1	28-44-11 P015-00/ /	ALL
L00284		65-0028-11 LT-CENTER TANK REFUEL VALVE OPEN	69-73588 72914	1	28-44-11 P015-00/ /	ALL

EQUIPMENT LIST

D280A103

Section L00200

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00315		A-8985-17 LT-APU REMOTE FIRE	72914	1	26-11-31 P028-00/ /	YC001-YC030
L00320		Q4559X LT-FIXED LANDING,L	284A0173 08806	1	33-42-11 530/193/L091	ALL
L00321		Q4559X LT-FIXED LANDING,R	284A0173 08806	1	33-42-11 530/193/R091	ALL
L00322		S283A321-1 LT-RETRACTABLE LANDING,L	284A0171 81205	1	33-42-11 500A+10/150/L032	YC001-YC026
L00322		S283A321-3 LT-RETRACTABLE LANDING,L	284A0171 81205	1	33-42-11 500A+10/150/L032	YC028-YM670
L00322 T		Q4559X LAMP-	S283A321 08806	1	33-42-11 500A+10/150/L032	ALL
L00323		S283A321-2 LT-RETRACTABLE LANDING,R	284A0171 81205	1	33-42-11 500A+10/150/R032	YC001-YC026
L00323		S283A321-4 LT-RETRACTABLE LANDING,R	284A0171 81205	1	33-42-11 500A+10/150/R032	YC028-YM670
L00323 T		Q4559X LAMP-	S283A321 08806	1	33-42-11 500A+10/150/R032	ALL
L00324		10-60759-5 LT-THRESHOLD,FWD	65C27093 81205	1	33-29-11 304/226/L061	ALL
L00324 T		305IF LAMP-	65-45208 08806	1	33-29-11 352/226/L061	ALL
L00330		4551 LT-TURNOFF LEFT	284A0173 08806	1	33-45-11 528/193/L083	ALL
L00331		4551 LT-TURNOFF RIGHT	284A0173 08806	1	33-45-11 528/193/R083	ALL
L00340	9	088-515-1031-107 LT-LEFT FIRE WARN ASSY, CAPT(SB 31-1284)	233A8200 81590	1	26-11-21 P007-00/250/L012	YC001-YC030
L00340		088-515-1031-107 LT-LEFT FIRE WARN ASSY, CAPT	233A8200 81590	1	26-11-21 P007-00/250/L012	YK901-YM670
L00340 T		1864 LAMP-	69-37327 08806	1	26-11-21 200/250/L012	ALL
L00340A		515-1031-007 CAP-	69-37327 81590	1	26-11-21 200/250/L012	YC001-YC050

EQUIPMENT LIST

D280A103

Section L00300

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00341	9	088-515-1031-106 LT- MASTER CAUTION ASSY, L (SB 31-1284)	233A8200 81590	1	31-52-11 P007-00/ /	YC001-YC030
L00341		088-515-1031-106 LT- MASTER CAUTION ASSY, L	233A8200 81590	1	31-52-11 P007-00/ /	YK901-YM670
L00341 T		1864 LAMP-	233A8200 08806	1	31-52-11 P007-00/ /	ALL
L00341A		515-1031-006 CAP-	233A8200 81590	1	31-52-11 P007-00/ /	YC001-YC050
L00342		10-61330-60 LT-MASTER CAUTION DISPLAY,LEFT	233A8200 81205	1	31-52-11 P007-00/ /	ALL
L00342 T		737 LAMP-	233A8200 08806	12	31-52-11 P007-00/ /	ALL
L00343		10-61330-61 LT-MASTER CAUTION DISPLAY,RIGHT	233A8200 81205	1	31-52-11 P007-00/ /	ALL
L00343 T		737 LAMP-	233A8200 08806	12	31-52-11 P007-00/ /	ALL
L00344	9	088-515-1031-106 LT- MASTER CAUTION ASSY, R (SB 31-1284)	233A8200 81590	1	31-52-11 P007-00/ /	YC001-YC030
L00344		088-515-1031-106 LT- MASTER CAUTION ASSY, R	233A8200 81590	1	31-52-11 P007-00/ /	YK901-YM670
L00344 T		1864 LAMP-	233A8200 08806	2	31-52-11 P007-00/ /	ALL
L00344A		515-1031-006 CAP-	233A8200 81590	1	31-52-11 /250/R012	YC001-YC050
L00345	9	088-515-1031-107 LT-RIGHT FIRE WARN ASSY, F/O(SB 31-1284)	233A8200 81590	1	26-11-21 P007-00/250/R012	YC001-YC030
L00345		088-515-1031-107 LT-RIGHT FIRE WARN ASSY, F/O	233A8200 81590	1	26-11-21 P007-00/250/R012	YK901-YM670
L00345 T		1864 LAMP-	69-37327 08806	1	26-11-21 200/250/R012	ALL
L00345A		515-1031-007 CAP-	69-37327 81590	1	26-11-21 200/250/R012	YC001-YC050
L00348		LH76-2LC14YN3 LT-EXT PWR CONN	284A1807 96906	1	24-41-11 P019-00/ /	ALL

EQUIPMENT LIST

D280A103

Section L00300

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00348	T	NE51H LAMP-	284A1807 08806	1	24-41-12 P019-00/ /	ALL
L00349		LH76-3LC15WT3 LT-EXT PWR NOT IN USE	284A1807 96906	1	24-41-11 P019-00/ /	ALL
L00349	T	MS25231-313 LAMP-	284A1807 96906	1	24-41-12 P019-00/ /	ALL
L00382		STB130-4ARP LT-PARKING BRAKE	254A1220 81590	1	32-44-11 222/226/L002	ALL
L00382	T	1864 LAMP-	254A1220 08806	1	32-44-11 222/226/L002	ALL
L00383		10-61800-1718 LT PLT-P5 MISC, HORIZONTAL	233A3101 81205	1	33-12-12 P005-00/ /	ALL
L00383	T	90-42301-1 LT PLT CONN-P5 MISC, HORIZONTAL	233A3303 51074	1	33-12-12 P005-00/ /	ALL
L00384		10-61800-1665 LT PLT-P5 MISC, VERTICAL	233A3101 81205	1	33-12-12 P005-00/ /	YC001-YK906
L00384		10-61800-1717 LT PLT-P5 MISC, VERTICAL	233A3101 81205	1	33-12-12 P005-00/ /	YK907-YM670
L00384	T	90-42301-1 LT PLT CONN-P5 MISC, VERTICAL	233A3101 51074	1	33-12-12 P005-00/ /	ALL
L00385		10-61800-1568 LT PLT-P5 DOME LTS	233A3101 81205	1	33-12-12 P005-00/ /	ALL
L00385	T	90-42301-1 LT PLT CONN-P5 DOME LTS	233A3306 51074	1	33-12-12 P005-00/ /	ALL
L00399		10-61800-654 LT PLT-FLAP POS P10 PNL	254A1200 81205	1	33-11-41 P010-00/ /	ALL

EQUIPMENT LIST

D280A103

Section L00300

Page 3 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00400		10-61800-731 LT PLT-STAB TRIM, CAPT	254A1220 81205	1	33-11-41 P010-00/ /	YC001-YL430
L00400		10-61800-740 LT PLT-STAB TRIM, CAPT	254A1220 81205	1	33-11-41 P010-00/ /	YM643-YM670
L00401		10-61800-730 LT PLT-STAB TRIM, F/O	254A1220 81205	1	33-11-41 P010-00/ /	YC001-YL430
L00401		10-61800-741 LT PLT-STAB TRIM, F/O	254A1220 81205	1	33-11-41 P010-00/ /	YM643-YM670
L00404		10-61800-536 LT PLT-LTG CONTROL PNL	69-76435 81205	1	33-11-41 P008-50/ /	ALL
L00410		15-0121-1 LIGHT- P18 CIRCUIT BREAKER PANEL	232A5111 72914	1	33-14-12 243/237/L046	ALL
L00410 T		1864 LAMP-	232A5111 08806	1	33-14-12 243/ /	ALL
L00411		69-43850-1 LIGHT-P18 CIRCUIT BREAKER PANEL	232A5111 81205	1	33-14-12 245/257/L033	ALL
L00411 T		1864 LAMP-	232A5111 08806	1	33-14-12 246/ /	ALL
L00412		BACS16A-2 LIGHT-PG CIRCUIT BREAKER PANEL	232A1401 81205	1	33-14-12 235/268/R013	ALL
L00412 T		303 LAMP-	232A1401 08806	1	33-14-12 253/ /	ALL
L00413		BACS16A-2 LIGHT-P6 CIRCUIT BREAKER PANEL	232A5111 81205	1	33-14-12 250/207/R026	ALL
L00413 T		1691 LAMP-	232A5111 08806	1	33-14-12 250/ /	ALL
L00414		15-0121-2 LIGHT-P6 CIRCUIT BREAKER PANEL	232A5111 72914	1	33-14-12 243/237/R046	ALL
L00414 T		1864 LAMP-	232A5111 08806	1	33-14-12 243/ /	ALL
L00461		S453W071-6 LT-AFT CARGO COMPT	284A0131 81205	1	33-36-12 894/205/R010	YC001-YC030
L00461		S453W071-11 LT-AFT CARGO COMPT	284A0131 81205	1	33-36-12 894/205/R010	YC031-YM670

EQUIPMENT LIST

D280A103

Section L00400

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00461 T		2233 LAMP-	69-23695 08806	1	33-36-12 894/205/R010	ALL
L00462		10-61800-723 LT PLT-SPEED BRAKE POS LTS	254A1220 81205	1	33-11-41 P010-00/ /	ALL
L00481		10-61803-50 LT-RIGHT MAIN GEAR SYS 2	65-73710 81205	1	32-64-12 P005-00/ /	ALL
L00482		10-61803-49 LT-LEFT MAIN GEAR SYS 2	65-73710 81205	1	32-64-12 P005-00/ /	ALL

EQUIPMENT LIST

D280A103

Section L00400
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00505		S417N503-19 LT-NO SMOKING FASTEN SEAT BELTS SIGN	415A1104 81205	1	33-25-21 993R/ /	YC001-YC050
L00505		S417N503-20 LT-NO SMOKING FASTEN SEAT BELTS SIGN	417A5601 81205	1	33-25-21 993R/ /	YK901-YK906
L00505		BR9442-10 LT-NO SMOKING FASTEN SEAT BELTS SIGN	417A5601 81205	1	33-25-21 993R/ /	YK907-YK917
L00505		BR9449-910 LT-NO SMOKING FASTEN SEAT BELTS SIGN	417A5601 81205	1	33-25-21 993R/ /	YK918-YK920
L00505		BR9442-910 LT-NO SMOKING FASTEN SEAT BELTS SIGN	417A5601 81205	1	33-25-21 993R/ /	YL401-YM670
L00547		S283A325-7 LT-OVERWING ESCAPE GROUND ILLUM-L	284A0132 81205	1	33-51-13 727F+11/169/L051	YC001-YL430
L00547		S283A325-5 LT-OVERWING ESCAPE GROUND ILLUM-L	284A0132 81205	1	33-51-13 757/171/L051	YM643-YM670
L00547 T		767 LAMP-	S283A325 08806	1	33-51-14 727F+11/169/L051	YC001-YL430
L00547 T		767 LAMP-	S283A325 08806	1	33-51-13 757/171/L051	YM643-YM670
L00548		S283A325-8 LT-OVERWING ESCAPE GROUND ILLUM-R	284A0132 81205	1	33-51-14 727F+11/170/R052	YC001-YL430
L00548		S283A325-4 LT-OVERWING ESCAPE GROUND ILLUM-R	284A0132 81205	1	33-51-13 757/171/R051	YM643-YM670
L00548 T		767 LAMP-	284A0132 08806	1	33-51-14 727F+11/170/R052	YC001-YL430
L00548 T		767 LAMP-	284A0132 08806	1	33-51-13 757/171/R051	YM643-YM670

EQUIPMENT LIST

D280A103

Section L00500

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00728		310-3 LT-MEMORY DEVICE	65-45123 08806	1	33-11-11 P009-00/ /	ALL
L00729		310-3 LT-MEMORY DEVICE	65-45123 08806	1	33-11-21 P009-00/ /	ALL
L00730		S283A325-2 LT-ESCAPE SLIDE-R, FWD	284A0106 81205	1	33-51-12 348/227/R068	ALL
L00730 T		767 LAMP-	S283A325 08806	1	33-51-12 348/227/R068	ALL
L00731		S283A325-1 LT-FWD ESCAPE SLIDE-L	284A0106 81205	1	33-51-12 365/226/L072	ALL
L00731 T		767 LAMP-	S283A325 08806	1	33-51-12 365/226/L072	ALL
L00732		S283A325-6 LT-ESCAPE SLIDE-L, AFT	284A0141 81205	1	33-51-14 1000/242/L060	ALL
L00732 T		767 LAMP-	S283A325 08806	1	33-51-14 1000/242/L060	ALL
L00733		S283A325-6 LT-ESCAPE SLIDE-R,AFT	284A0141 81205	1	33-51-14 1000/242/R060	ALL
L00733 T		767 LAMP-	S283A325 08806	1	33-51-14 1000/242/R060	ALL
L00751		S417N512-13 LT-HANDLE, EMERG HATCH	S417N512 81205	4	33-51-13 MULTI/ /	YC001-YC002
L00751		S417N512-13 LT-HANDLE, EMERG HATCH	417A5500 81205	4	33-51-13 MULTI/ /	YC003-YC026
L00751		11-5833-21 LT-HANDLE, EMERG HATCH	417A5500 81205	4	33-51-13 MULTI/ /	YC028-YL430
L00751		11-5833-21 LT-HANDLE, EMERG HATCH (LEFT AND RIGHT)	417A5500 81205	2	33-51-13 628/270/0060	YM643-YM670
L00751 T		OL-3071BPE-GPL LAMP-	S417N512 S3774	48	33-51-13 609/270/060	YC001-YC002
L00751 U		70-0366-5 BALLAST-	S417N512 81205	4	33-21-11 MULTI/ /	YC001-YL430
L00751 U		70-0366-5 BALLAST-	S417N512 81205	2	33-21-11 MULTI/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section L00700

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00751 V		5106WW LAMP-	S417N512 08805	4	33-21-11 MULTI/ /	YC001-YL430
L00751 V		5106WW LAMP-	S417N512 08805	2	33-21-11 MULTI/ /	YM643-YM670
L00751 W		1317 LAMP-	S417N512 08806	8	33-51-13 MULTI/ /	YC001-YL430
L00751 W		1317 LAMP-	S417N512 08806	4	33-51-13 628/270/0060	YM643-YM670

EQUIPMENT LIST

D280A103

Section L00700

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00818		S283A317-1 LT-LOGO L	284A0191 81205	1	33-49-11 1223/295/L190	ALL
L00818 T		HLX64621 LAMP-	S283A317 08805	1	33-49-11 1223/295/L190	ALL
L00819		S283A317-2 LT-LOGO R	284A0191 81205	1	33-49-11 1223/295/R190	ALL
L00819 T		HLX64621 LAMP-	S283A317 08805	1	33-49-11 1223/295/R190	ALL
L00836		10-61803-186 LT-INOP IND	69-37369 81205	1	34-49-11 P003-07/ /	ALL
L00876		SCN-001 LT PLT-	69-37334 95354	1	21-33-11 P005-16/ /	ALL
L00876 T		10-61800-1101 LAMP-	69-37334 81205	1	21-33-11 P005-16/ /	ALL

EQUIPMENT LIST

D280A103

Section L00800
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01001		10-61803-48 LT-NOSE GEAR SYS 2	65-73710 81205	1	32-64-12 P005-00/ /	ALL
L01002		LH73-1 LT-REPEAT PARKING BRAKE	284A1807 96906	1	32-44-11 P019-00/ /	ALL
L01003		S232W500-6 LT- CHART, CAPT	232A5114 72914	1	33-17-11 229/268/L016	YC001-YC026
L01004		S232W500-6 LT- CHART, F/O	232A5114 72914	1	33-17-11 229/268/R016	ALL
L01013		S233W810-3 FLOODLIGHT-GLARESHIELD (-800)	233A8104 81205	1	33-14-11 P007-00/ /	YC001-YK910, YK918, YL421- YL426
L01013		800-010057-1 FLOODLIGHT-GLARESHIELD (-800)	233A8104 81205	1	33-14-11 P007-00/ /	YK911-YK917, YK919-YL401, YL427-YL430
L01013		S233W810-3 FLOODLIGHT-GLARESHIELD (-700)	233A8104 81205	1	33-14-11 P007-00/ /	YM643-YM647
L01013		800-010057-1 FLOODLIGHT-GLARESHIELD (-700)	233A8104 81205	1	33-14-11 P007-00/ /	YM649-YM670
L01020		S453W071-11 LT-FWD CARGO COMP	284A0112 81205	1	33-36-11 500B+13/203/L010	YM643-YM670
L01020 T		2233 LAMP-	69-23695 08806	1	33-36-11 500B+13/203/L010	YM643-YM670
L01021		S453W071-6 LIGHT-AFT CARGO COMP	284A0131 81205	1	33-36-12 727D+17/205/R011	YC001-YC030
L01021		S453W071-11 LIGHT-AFT CARGO COMP	284A0131 81205	1	33-36-12 727D+17/205/R011	YC031-YM670
L01021 T		2233 LAMP-	69-23695 08806	1	33-36-12 727D+17/205/R011	ALL
L01063		S479W220-102 SIGN-OVERDOOR EXIT,FWD SERVICE	411A2212 S5006	1	33-51-12 318/280/R038	YC001-YC050
L01063		82000-48401 SIGN-OVERDOOR EXIT,FWD SERVICE	411A2212 S5006	1	33-51-12 318/280/R038	YK901-YM670
L01063 T		OL-3071BPE-GPL LAMP-	S479W220 53774	18	33-51-12 318/280/R038	ALL

EQUIPMENT LIST

D280A103

Section L01000

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01065		S417N504-8 LT-AISLE	412N1168 81205	17	33-51-11 MULTI/ /	YC001-YC050
L01065		S417N504-8 LT-AISLE	412N1168 81205	19	33-51-11 MULTI/ /	YK901-YL430
L01065		S417N504-8 LT-AISLE	412N1168 81205	13	33-51-11 MULTI/ /	YM643-YM670
L01065 T		1317 LAMP-	S417N504 08806	17	33-51-11 MULTI/ /	YC001-YC050
L01065 T		1317 LAMP-	S417N504 08806	19	33-51-11 MULTI/ /	YK901-YL430
L01065 T		1317 LAMP-	S417N504 08806	13	33-51-11 MULTI/ /	YM643-YM670
L01067		S479W220-102 SIGN-OVERDOOR EXIT,FWD ENTRY	411A2211 S5006	1	33-51-12 329/285/L030	YC001-YC050
L01067		82000-48401 SIGN-OVERDOOR EXIT,FWD ENTRY	411A2211 S5006	1	33-51-12 329/285/L030	YK901-YM670
L01067 T		OL-3071BPE-GPL LAMP-	S479W220 53774	18	33-51-12 329/285/L030	ALL
L01070		S479W220-103 SIGN-EXIT,MID AISLE	417A5600 81205	1	33-51-13 612/293/L019	YC001-YC050
L01070		82000-48501 SIGN-EXIT,MID AISLE	417A5601 S5006	1	33-51-13 612/293/L019	YK901-YK910, YK918, YL421- YL426
L01070		82000-79001 SIGN-EXIT,MID AISLE	417A5601 S5006	1	33-51-13 612/288/0000	YK911-YK917, YK919-YL401, YL427-YL430
L01070		82000-48501 SIGN-EXIT,MID AISLE	417A5601 S5006	1	33-51-13 628/293/L019	YM643-YM652
L01070 T		OL-3071BPE-GPL LAMP-	S479W220 53774	12	33-51-13 612/293/L019	YC001-YK910, YK918, YL421- YL426
L01070 T		OL-3071BPE-GPL LAMP-	S479W220 53774	12	33-51-13 612/288/0000	YK911-YK917, YK919-YL401, YL427-YL430

EQUIPMENT LIST

D280A103

Section L01000

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01070	T	OL-3071BPE-GPL LAMP-	S479W220 53774	12	33-51-13 628/291/L006	YM643-YM652
L01076		S479W220-102 SIGN-OVERDOOR EXIT,AFT ENTRY	411A2213 S5006	1	33-51-14 972/286/L037	YC001-YC050
L01076		82000-48401 SIGN-OVERDOOR EXIT,AFT ENTRY	411A2213 S5006	1	33-51-14 972/286/L037	YK901-YM670
L01076	T	OL-3071BPE-GPL LAMP-	S479W220 53774	18	33-51-14 972/286/L037	ALL
L01079		S479W220-102 SIGN-OVERDOOR EXIT,AFT SERVICE	411A2214 S5006	1	33-51-14 972/279/R044	YC001-YC050
L01079		82000-48401 SIGN-OVERDOOR EXIT,AFT SERVICE	411A2214 S5006	1	33-51-14 972/279/R044	YK901-YM670
L01079	T	OL-3071BPE-GPL LAMP-	S479W220 53774	18	33-51-14 972/279/R044	ALL
L01086		S479W220-101 SIGN-EXIT LOCATOR	411A3210 81205	1	33-51-12 304/288/R002	YC001-YC050
L01086		82000-48301 SIGN-EXIT LOCATOR	411A3210 S5006	1	33-51-12 304/288/R002	YK901-YM670
L01086	T	OL-3071BPE-GPL LAMP-	S479W220 53774	20	33-51-12 304/288/R002	ALL
L01086	U	387BPL LAMP-	S417N505 08806	5	23-42-01 304/ /	ALL
L01099		S233W810-9 FLOODLIGHT-MAIN PANEL, CAPT (-800)	233A8104 81205	1	33-14-11 P007-00/ /	YC001-YK910, YK918, YL421- YL426
L01099		800-010060-1 FLOODLIGHT-MAIN PANEL, CAPT (-800)	233A8104 81205	1	33-14-11 P007-00/ /	YK911-YK917, YK919-YL401, YL427-YL430
L01099		S233W810-9 FLOODLIGHT-MAIN PANEL, CAPT (-700)	233A8104 81205	1	33-14-11 P007-00/ /	YM643-YM647
L01099		800-010060-1 FLOODLIGHT-MAIN PANEL, CAPT (-700)	233A8104 81205	1	33-14-11 P007-00/ /	YM649-YM670

EQUIPMENT LIST

D280A103

Section L01000

Page 3 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01100		S233W810-10 FLOODLIGHT-MAIN PANEL, F/O (-800)	233A8104 81205	1	33-14-11 P007-00/ /	YC001-YK910, YK918, YL421- YL426
L01100		800-010056-1 FLOODLIGHT-MAIN PANEL, F/O (-800)	233A8104 81205	1	33-14-11 P007-00/ /	YK911-YK917, YK919-YL401, YL427-YL430
L01100		S233W810-10 FLOODLIGHT-MAIN PANEL, F/O (-700)	233A8104 81205	1	33-14-11 P007-00/ /	YM643-YM647
L01100		800-010056-1 FLOODLIGHT-MAIN PANEL, F/O (-700)	233A8104 81205	1	33-14-11 P007-00/ /	YM649-YM670
L01103		S233W810-7 FLOODLIGHT-OXYGEN MASK STOW, CAPT (-800)	232A5110 81205	1	33-14-11 224/223/L040	YC001-YK910, YK918, YL421- YL426
L01103		800-010059-1 FLOODLIGHT-OXYGEN MASK STOW, CAPT (-800)	232A5110 81205	1	33-14-11 224/223/L040	YK911-YK917, YK919-YL401, YL427-YL430
L01103		S233W810-7 FLOODLIGHT-OXYGEN MASK STOW, CAPT (-700)	232A5110 81205	1	33-14-11 224/223/L040	YM643-YM647
L01103		800-010059-1 FLOODLIGHT-OXYGEN MASK STOW, CAPT (-700)	232A5110 81205	1	33-14-11 224/223/L040	YM649-YM670
L01104		S233W810-7 FLOODLIGHT-OXYGEN MASK STOW, F/O (-800)	232A5110 81205	1	33-14-11 224/223/R040	YC001-YK910, YK918, YL421- YL426
L01104		800-010059-1 FLOODLIGHT-OXYGEN MASK STOW, F/O (-800)	232A5110 81205	1	33-14-11 224/223/R040	YK911-YK917, YK919-YL401, YL427-YL430
L01104		S233W810-7 FLOODLIGHT-OXYGEN MASK STOW, F/O (-700)	232A5110 81205	1	33-14-11 224/223/R040	YM643-YM647
L01104		800-010059-1 FLOODLIGHT-OXYGEN MASK STOW, F/O (-700)	232A5110 81205	1	33-14-11 224/223/R040	YM649-YM670
L01105		S417N503-19 LT-NO SMOKING FASTEN SEAT BELTS SIGN	415A1104 81205	1	33-25-21 993L/ /	YC001-YC050
L01105		BR9442-910 LT-NO SMOKING FASTEN SEAT BELTS SIGN	417A5601 81205	1	33-25-21 993L/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section L01100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01141		10-61803-12 LT-EQUIP COOLING SUPPLY OFF	233A3101 81205	1	21-27-31 P005-00/ /	ALL
L01142		10-61800-537 LIGHTPLATE	233A6101 81205	1	52-51-11 P008-47/ /	YC001-YC030
L01142		425-3 LIGHTPLATE	233A6101 81205	1	52-51-11 P008-47/ /	YC031-YM670
L01146		S417A548-1 SIGN-LAV OCCUPY	417A5800 81205	2	33-26-31 MULTI/ /	ALL
L01186		S417N510-1 LT-EXIT INDICATOR	417A5700 81205	1	33-51-21 293/230/R051	YC001-YC050
L01186		702409-1019 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 293/233/R051	YK901-YK909, YL401-YM670
L01186		702409-1001 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 293/233/R051	YK910-YK920
L01186 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 293/229/R051	YC001-YC050
L01186 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 293/233/R051	YK901-YM670
L01187		S417N510-1 LT-EXIT INDICATOR	417A5700 81205	1	33-51-21 304/229/L047	YC001-YC050
L01187		702409-1019 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 304/230/L051	YK901-YK909, YL401-YM670
L01187		702409-1001 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 304/230/L051	YK910-YK920
L01187 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 304/230/L047	YC001-YC050
L01187 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 304/230/L051	YK901-YL430
L01187 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 304/229/L047	YM643-YM670
L01188		S417N510-1002 LT-EXIT INDICATOR	417A5700 81205	1	33-51-21 614/223/R062	YC001-YC050
L01188		702409-1021 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 614/224/R062	YK901-YK909, YL401-YL430

EQUIPMENT LIST

D280A103

Section L01100

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01188		702409-1003 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 614/224/R062	YK910-YK920
L01188		702409-1021 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 606/224/R070	YM643-YM670
L01188 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 614/224/R062	YC001-YL430
L01188 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 606/224/R070	YM643-YM670
L01189		S417N510-1003 LT-EXIT INDICATOR	417A5700 81205	1	33-51-21 615/223/L062	YC001-YC050
L01189		702409-1020 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 614/224/L062	YK901-YK909, YL401-YL430
L01189		702409-1002 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 614/224/L062	YK910-YK920
L01189		702409-1020 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 606/224/L070	YM643-YM670
L01189 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 614/224/L062	YC001-YL430
L01189 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 606/224/L070	YM643-YM670
L01190		S417N510-1001 LT-EXIT INDICATOR	417A5700 81205	1	33-51-22 993/243/L053	YC001-YC050
L01190		702409-1019 LT-EXIT INDICATOR	417A5705 55438	1	33-51-22 993/244/L053	YK901-YK909, YL401-YM670
L01190		702409-1001 LT-EXIT INDICATOR	417A5705 55438	1	33-51-22 993/244/L053	YK910-YK920
L01190 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-22 993/243/L053	YC001-YC050
L01190 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-22 993/244/L053	YK901-YM670
L01191		S417N510-1001 LT-EXIT INDICATOR	417A5700 81205	1	33-51-22 993/243/R053	YC001-YC050
L01191		702409-1019 LT-EXIT INDICATOR	417A5705 55438	1	33-51-22 993/244/R053	YK901-YK909, YL401-YM670

EQUIPMENT LIST

D280A103

Section L01100

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01191		702409-1001 LT-EXIT INDICATOR	417A5705 55438	1	33-51-22 993/244/R053	YK910-YK920
L01191 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-22 993/244/R053	ALL

EQUIPMENT LIST

D280A103

Section L01100

Page 4 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01205		S453W071-6 LT-FWD CARGO CMPT	284A0131 81205	1	33-36-11 500F+15/203/R010	YC001-YC030
L01205		S453W071-11 LT-FWD CARGO CMPT	284A0131 81205	1	33-36-11 500F+15/203/R010	YC031-YL430
L01205 T		2233 LAMP-	284A0131 08806	1	33-36-11 500F+15/203/L010	YC001-YL430
L01206		S453W071-6 LT-AFT CARGO COMPT	284A0131 81205	1	33-36-12 727F+7/205/L010	YC001-YC030
L01206		S453W071-11 LT-AFT CARGO COMPT	284A0131 81205	1	33-36-12 727F+7/205/L010	YC031-YL430
L01206 T		2233 LAMP-	284A0131 08806	1	33-36-12 727+7/205/L010	YC001-YL430
L01207		S417N510-1002 LT-EXIT INDICATOR	417A5700 81205	1	33-51-21 576/223/R062	YC001-YC050
L01207		702409-1021 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 576/224/R062	YK901-YK909, YL401-YL430
L01207		702409-1003 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 576/224/R062	YK910-YK920
L01207 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 576/224/R062	YK901-YL430
L01208		S417N510-1003 LT-EXIT INDICATOR	417A5700 81205	1	33-51-21 576/234/L062	YC001-YC050
L01208		702409-1020 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 576/224/L062	YK901-YK909, YL401-YL430
L01208		702409-1002 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 576/224/L062	YK910-YK920
L01208 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 576/224/L062	YK901-YL430
L01209		S283A325-3 LT-OVERWING ESCAPE-R	284A0121	1	33-51-12 608/227/R074	YC001-YL430
L01209 T		767 LAMP-	S283A325 08806	1	33-51-14 608/227/L074	YC001-YL430
L01210		S283A325-3 LT-OVERWING ESCAPE-L	284A0121	1	33-51-13 608/227/L074	YC001-YL430

EQUIPMENT LIST

D280A103

Section L01200

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01210 T		767 LAMP-	S283A325 08806	1	33-51-14 608/227/L074	YC001-YL430
L01223		S479W220-105 SIGN-EXIT LOCATOR	417A5600 81205	1	33-51-14 964/289/0000	YC001-YC050
L01223		82000-48701 SIGN-EXIT LOCATOR	417A5601 S5006	1	33-51-14 964/287/0000	YK901-YM670
L01223 T		OL-3071BPE-GPL LAMP-	S479W220 53774	22	33-51-14 964/287/0000	ALL
L01223 U		387 LAMP-	S417N505 08806	3	23-42-01 966/ /	ALL
L01240		10-61800-751 LIGHT PLATE-REMOTE PTT SW, CAPT	233A8200 81205	1	33-11-31 P007-00/ /	YK901-YM670
L01241		10-61800-750 LIGHT PLATE-REMOTE PTT SW, F/O	233A8200 81205	1	33-11-21 P007-00/ /	YK901-YM670
L01287		BV04610 DIM ENTRY LT SOCKET	417A5470 08806	1	33-29-11 321/291/0000	ALL
L01287T		1864 DIM ENTRY LAMP	417A5470 08806	1	33-29-11 321/291/0000	ALL
L01288		FB024-830 FLUORESCENT LAMP	417A5470 3E097	1	33-29-11 M1677/ /	YC001-YL426, YL429, YM643- YM670
L01288		FB024-841 FLUORESCENT LAMP (COOL WHITE)	417A5470 3E097	1	33-29-11 M1677/ /	YL427-YL428, YL430
L01288 T		BV03112N-20 LAMPHOLDER	417A5470 17023	4	33-29-11 M1677/ /	ALL
L01289		FB024-830 FLUORESCENT LAMP	417A5470 3E097	1	33-29-11 M1677/ /	YC001-YL426, YL429, YM643- YM670
L01289		FB024-841 FLUORESCENT LAMP (COOL WHITE)	417A5470 3E097	1	33-29-11 M1677/ /	YL427-YL428, YL430
L01289 T		BV03112N-20 LAMPHOLDER	417A5470 17023	2	33-29-11 M1677/ /	ALL

EQUIPMENT LIST

D280A103

Section L01200

Page 2 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01300		FB016-830 FLUORESCENT LAMP (WARM WHITE)	417A5800 3E097	1	33-26-21 323/289/R021	YC001-YL426, YL429, YM643- YM670
L01300		FB016-841 FLUORESCENT LAMP (COOL WHITE)	417A5800 3E097	1	33-26-21 323/289/R021	YL427-YL428, YL430
L01300 T		BV03112N-20 LAMPHOLDER	417A5460 17023	2	33-26-21 323/289/R021	ALL
L01301		10-1037-3 LT-WORK	411A3220 81205	1	33-26-11 331/289/L014	ALL
L01301 T		1308 LAMP-WORK LT	S417N502 S5006	1	33-26-11 331/289/L014	ALL
L01302		10-1037-3 LT-WORK	411A2213 81205	1	33-26-11 960/288/R032	ALL
L01302 T		1308 LAMP-WORK LT	S417N502 S5006	1	33-26-11 971/288/R032	ALL
L01303		10-1037-3 LT-WORK	411A2214 81205	1	33-26-11 960/288/L032	ALL
L01303 T		1308 LAMP-WORK LT	S417N502 S5006	1	33-26-11 971/288/L032	ALL
L01304		F032-BCAC-WW FLUORESCENT LAMP	417A5475 08805	1	33-29-11 M01678/*/*	YC001-YL426, YL429, YM643- YM670
L01304		F032-BCAC-CW FLUORESCENT LAMP (COOL WHITE)	417A5475 08805	1	33-29-11 M01678/*/*	YL427-YL428, YL430
L01304 T		BV03112N LAMPHOLDER	417A5475 71023	2	33-29-11 M01678/ /	ALL
L01305		F032-BCAC-WW FLUORESCENT LAMP	417A5475 08805	1	33-29-11 M01678/*/*	YC001-YL426, YL429, YM643- YM670
L01305		F032-BCAC-CW FLUORESCENT LAMP (COOL WHITE)	417A5475 08805	1	33-29-11 M01678/*/*	YL427-YL428, YL430
L01305 T		BV03112N LAMPHOLDER	417A5475 17023	2	33-29-11 M01678/ /	ALL
L01306		BV04610 DIM ENTRY LT SOCKET	417A5475 08806	1	33-29-11 M01678/*/*	ALL

EQUIPMENT LIST

D280A103

Section L01300

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01306T		1864 DIM ENTRY LAMP	417A5475 08806	1	33-29-11 M01678/ /	ALL
L01307		15-0103-1 LT-E/E RACK	284A0102 72914	1	33-34-11 350/181/R020	ALL
L01307 T		1665 LAMP-	15-0103 08806	1	33-34-11 350/181/R020	ALL
L01308		15-0103-1 LT-APU SERVICE	284A0151 72914	1	33-35-11 1132/239/R017	ALL
L01308 T		1665 LAMP-	15-0103 08806	1	33-35-11 1132/239/R017	ALL
L01313		15-0103-1 LT-E/E RACK	284A0102 72914	1	33-34-11 350/177/L028	ALL
L01313 T		1665 LAMP-	15-0103 08806	1	33-34-11 318/181/L024	ALL
L01314		S453W071-6 LT-FWD CARGO CMPT	284A0131 81205	1	33-36-11 500G+15/205/L010	YC001-YC030
L01314		S453W071-11 LT-FWD CARGO CMPT	284A0131 81205	1	33-36-11 500G+15/205/L010	YC031-YL430
L01314 T		2233 LAMP-	284A0131 08806	1	33-36-11 500G+15/205/L010	YC001-YL430
L01315		S453W071-6 LT-AFT CARGO COMPT	284A0131 81205	1	33-36-12 727H+7/205/R010	YC001-YC030
L01315		S453W071-11 LT-AFT CARGO COMPT	284A0131 81205	1	33-36-12 727H+7/205/R010	YC031-YL430
L01315 T		2233 LAMP-	284A0131 08806	1	33-36-12 725H+7/205/R010	YC001-YL430
L01316		S479W220-1002 SIGN-EXIT LOCATOR	417A5600 81205	1	33-51-15 727A+8/289/0000	YC001-YC050
L01316 T		OL-3071BPE-GPL LAMP-	S479W220 53774	12	33-51-13 / /	YC001-YC050
L01319		S479W230-6 PROX LT-GALLEY G7	64C34310	1	33-51-21 348/230/L012	YC001-YC050
L01319 T		OL-3071BPEGPL LAMP-	S479W230 S3774	1	33-51-21 MULTI/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section L01300

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01320		S479W230-6 PROX LT-GALLEY G7	415A1107	1	33-51-21 369/230/L012	YC001-YC050
L01320 T		OL-3071BPEGPL LAMP-	S479W230 S3774	1	33-51-21 MULTI/ /	YC001-YC050
L01321		S453W071-6 LT-FORWARD CARGO COMPARTMENT	384A0112 81205	1	33-36-11 500B+13/203/R010	YC001-YC030
L01321		S453W071-11 LT-FORWARD CARGO COMPARTMENT	384A0112 81205	1	33-36-11 500B+13/203/R010	YC031-YL430
L01321 T		2233 LAMP-	384A0112 08806	1	33-36-11 500B+13/203/R010	YC001-YL430
L01322		S453W071-6 LT-FORWARD CARGO COMPARTMENT	384A0112 81205	1	33-36-11 500D+15/203/R010	YC001-YC030
L01322		S453W071-11 LT-FORWARD CARGO COMPARTMENT	384A0112 81205	1	33-36-11 500D+15/203/R010	YC031-YL430
L01322 T		2233 LAMP-	384A0112 08806	1	33-36-11 500D+15/203/R010	YC001-YL430
L01331		10-61803-469 PSEU FAULT LIGHT	233A3306	1	32-64-21 P005-00/ /	ALL
L01351		81000-33802 PROX LIGHT-FWD LHS WINDSCREEN	415A1119 S5006	1	33-51-21 350/224/L017	YK901-YK911, YK918, YL401
L01351		81000-33802 PROX LIGHT-FWD LHS WINDSCREEN	413A3101 S5006	1	33-51-21 350/224/L017	YK912-YK917, YK919-YK920, YL421-YM670
L01351 T		OL-3071BPEGPL LAMP-	S479W230 S3774	1	33-51-21 350/224/L017	YK901-YM670
L01358		S417N510-1002 LT-EXIT INDICATOR	417A5700 81205	1	33-51-21 642/224/R070	YC001-YC050
L01358		702409-1020 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 641/248/R070	YM643-YM670
L01358 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 641/248/R070	YM643-YM670
L01359		S417N510-1003 LT-EXIT INDICATOR	417A5700 81205	1	33-51-21 642/224/L070	YC001-YC050

EQUIPMENT LIST

D280A103

Section L01300

Page 3

May 11/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01359		702409-1021 LT-EXIT INDICATOR	417A5705 55438	1	33-51-21 641/248/L070	YM643-YM670
L01359 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 641/248/L070	YM643-YM670
L01365		S479W220-3 SIGN-EXIT, OVERWING	417A5600 81205	4	33-51-13 MULTI/ /	YC003-YC050
L01365		82000-36101 SIGN-EXIT, OVERWING	417A5601 S5006	4	33-51-13 MULTI/ /	YK901-YL430
L01365		82000-36101 SIGN-EXIT, OVERWING	417A5601 S5006	2	33-51-13 628/270/	YM643-YM670
L01365 T		OL-3071BPE-GPL LAMP-	S479W220 53774	48	33-51-13 MULTI/ /	YC003-YL430
L01365 T		OL-3071BPE-GPL LAMP-	S479W220 53774	24	33-51-13 628/270/	YM643-YM670

EQUIPMENT LIST

D280A103

Section L01300

Page 4 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01414		82000-48501 SIGN-EXIT, MID AISLE	417A5601 S5006	1	33-51-13 727I+3/293/L019	YK901-YK910, YK918, YL421- YL426
L01414 T		OL-3071BPE-GPL LAMP-	S479W220 53774	12	33-51-13 727I+3/293/L019	YK901-YK910, YK918, YL421- YL426
L01417		S417U006-6 EMERGENCY CEILING LIGHT	411A3230 81205	1	33-51-12 382/293/0000	YK901-YM670
L01417 T		1317 EMERGENCY CEILING LIGHT	S417U006 81205	1	33-51-12 382/293/0000	YK901-YM670
L01419		S417U006-6 EMERGENCY CEILING LIGHT	411A3430 81205	1	33-51-14 898/293/0000	YK901-YM670
L01419 T		1317 EMERGENCY CEILING LIGHT	S417U006 81205	1	33-51-14 898/293/0000	YK901-YM670
L01429		82000-48501 SIGN-EXIT LOCATOR	417A5601 S5006	1	33-51-13 727E+18/293/L019	YM643-YM652
L01429 T		OL-3071BPE-GPL LAMP-	S479W220 53774	12	33-51-13 727E+18/293/L019	YM643-YM652
L01449		737-0010-34 FWD WINGLET LIGHT ASSY-RIGHT	119A0105 81205	1	33-43-11 727B/245/R663	YK901-YK906
L01449		737-0010-36 FWD WINGLET LIGHT ASSY-RIGHT	119A0105 81205	1	33-43-11 727B/245/R663	YK907-YM670
L01449 T	9	31-9289-4 FWD WINGLET LT ASSY - RT (APB 0802664)	737-8353 72914	1	33-43-11 727B/245/R663	YC001-YC010, YC012-YC030
L01449 T		HLX64621 LAMP-	119A0105 08805	2	33-43-11 727B/245/R663	YK901-YM670
L01449 U	9	30-9294-4 FWD WINGLET LT ASSY - RT (APB 0802664)	737-8353 72914	1	33-44-12 727B/245/R663	YC001-YC010, YC012-YC030
L01449 U		30-2735-1 STROBE SUB ASSY	119A0105 72914	1	33-44-12 727B/245/R663	YK901-YM670
L01449 X	9	30-2481-5 AFT WINGLET LT ASSY - RT (APB 0802664)	737-8800 72914	1	33-43-11 727E/245/R674	YC001-YC010, YC012-YC030
L01449 X		30-2481-5 AFT WINGLET LIGHT ASSY - RIGHT	119A0105 81205	1	33-43-11 727E/245/R674	YK901-YM670

EQUIPMENT LIST

D280A103

Section L01400

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01450		737-0010-33 FWD WINGLET LIGHT ASSY-LEFT	119A0105 81205	1	33-43-11 727B/245/L663	YK901-YK906
L01450		737-0010-35 FWD WINGLET LIGHT ASSY-LEFT	119A0105 81205	1	33-43-11 727B/245/L663	YK907-YM670
L01450 T	9	31-9289-1 FWD WINGLET LT ASSY - LFT (APB 0802664)	737-8353 72914	1	33-43-11 727B/245/L663	YC001-YC010, YC012-YC030
L01450 T		HLX64621 LAMP-	119A0105 08805	2	33-43-11 727B/245/L663	YK901-YM670
L01450 U	9	31-9294-3 FWD WINGLET LT ASSY - LFT (APB 0802664)	737-8353 72914	1	33-44-12 727B/245/L663	YC001-YC010, YC012-YC030
L01450 U		30-2735-1 STROBE SUB ASSY	119A0105 72914	1	33-44-12 727B/245/L663	YK901-YM670
L01450 X	9	30-2481-5 AFT WINGLET LT ASSY - LFT (APB 0802664)	737-8800 72914	1	33-43-11 727E/245/L674	YC001-YC010, YC012-YC030
L01450 X		30-2481-5 AFT WINGLET LIGHT ASSY - LEFT	119A0105 81205	1	33-43-11 727E/245/L674	YK901-YM670
L01456		S232W500-6 LIGHT- CHART, CAPT	232A5114 72914	1	33-17-11 234/260/L030	YC028-YM670
L01462		125-1310-11-103 NGS - LED HOLDER (GREEN)	284A0810 83330	1	47-30-11 723/171/R013	YC031-YC050, YK906-YM670
L01463		125-1310-11-103 NGS - LED HOLDER (BLUE)	284A0810 83330	1	47-30-11 723/169/R013	YC031-YC050, YK906-YM670
L01464		125-1310-11-103 NGS - LED HOLDER (AMBER)	284A0810 83330	1	47-30-11 723/167/R013	YC031-YC050, YK906-YM670

EQUIPMENT LIST

D280A103

Section L01400

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L03014		81000-17502 LT-MAP(CAPT)	232A5112 72914	1	33-17-11 249/245/L026	YC028-YM670
L03014 T		1308 LAMP-	232A5112 72914	1	33-17-11 234/265/L024	YC028-YM670

EQUIPMENT LIST

D280A103

Section L03000
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00005		S282T003-3 BATTERY CHARGER	284A0420 81205	1	24-31-11 E002-01/ /	YC001-YC011
M00005		S282T003-3 BATTERY CHARGER	284A0421 81205	1	24-31-11 E002-01/ /	YC012-YM670
M00006		S282T003-1 BATTERY	284A0816 81205	1	24-31-11 390/158/L005	ALL
M00009		S282T004-10 STATIC INVERTER-	284A0420 81205	1	24-34-11 E002-02/184/L040	YC001-YC011
M00009		S282T004-10 STATIC INVERTER-	284A0421 81205	1	24-34-11 E002-02/184/L040	YC012-YC030
M00009	1	S282T004-30 STATIC INVERTER-(737-800)	284A0421 81205	1	24-34-11 E002-02/184/L040	YC031-YK910, YK918, YL421- YL426
M00009	1	S282T004-30 STATIC INVERTER- (737-800 EFFS)	284A0421 81205	1	24-34-11 E002-02/184/L040	YK911-YK912, YK919, YL401, YL427-YL429
M00009	1	S282T004-30 STATIC INVERTER-(737-700)	284A0421 81205	1	24-34-11 E002-02/184/L040	YM643-YM649
M00009	1	S282T004-30 STATIC INVERTER- (737-700 EFFS)	284A0421 81205	1	24-34-11 E002-02/184/L040	YM651-YM652
M00009	2	S282T004-20 STATIC INVERTER-(737-800)	284A0421 81205	1	24-34-11 E002-02/184/L040	YC031-YK910, YK918, YL421- YL426
M00009	2	S281W204-1 STATIC INVERTER- (737-800 EFFS)	284A0421 81205	1	24-34-11 E002-02/184/L040	YK911-YK912, YK919, YL401, YL427-YL429
M00009	2	S282T004-20 STATIC INVERTER-(737-700)	284A0421 81205	1	24-34-11 E002-02/184/L040	YM643-YM649
M00009	2	S281W204-1 STATIC INVERTER- (737-700 EFFS)	284A0421 81205	1	24-34-11 E002-02/184/L040	YM651-YM652
M00009	3	S282T004-10MODB STATIC INVERTER-(737-800)	284A0421 81205	1	24-34-11 E002-02/184/L040	YC031-YK910, YK918, YL421- YL426
M00009	3	S282T004-10MODB STATIC INVERTER-(737-700)	284A0421 81205	1	24-34-11 E002-02/184/L040	YM643-YM649

EQUIPMENT LIST

D280A103

Section M00000

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00009	4	S282T004-10 STATIC INVERTER-(737-800)	284A0421 81205	1	24-34-11 E002-02/184/L040	YC031-YK910, YK918, YL421- YL426
M00009	4	S282T004-10 STATIC INVERTER-(737-700)	284A0421 81205	1	24-34-11 E002-02/184/L040	YM643-YM649
M00021		10-61329-31 MOTOR-LEFT WINDSHIELD WIPER	232A6181 81205	1	30-42-11 191/241/L011	YC001-YC028
M00021		10-61329-39 MOTOR-LEFT WINDSHIELD WIPER	232A6181 81205	1	30-42-11 191/241/L011	YC029-YC030, YK901-YK902
M00021		10-61329-41 MOTOR-LEFT WINDSHIELD WIPER	232A6181 81205	1	30-42-11 191/241/L011	YC031-YC050, YK903-YM670
M00022		10-61329-32 MOTOR-RIGHT WINDSHIELD WIPER	232A6181 81205	1	30-42-11 191/241/R011	YC001-YC028
M00022		10-61329-40 MOTOR-RIGHT WINDSHIELD WIPER	232A6181 81205	1	30-42-11 191/241/R011	YC029-YC030, YK901-YK902
M00022		10-61329-42 MOTOR-RIGHT WINDSHIELD WIPER	232A6181 81205	1	30-42-11 191/241/R011	YC031-YC050, YK903-YM670
M00025		1200008-000 DECODER-SELCAL	284A0440 0K955	1	23-22-11 E004-01/ /	YK907-YM670
M00027		DMN27-2 ANT-MARKER BEACON	284A0507 85226	1	34-32-11 610/143/0	ALL
M00040		S41422 DUAL GLIDESLOPE ANTENNA (NOSE)	284A0504 13691	1	34-31-11 178/237/000	ALL
M00041		10-61333-3 ANT-DUAL VOR/LOC (TAIL)	284A0510 85226	1	34-51-11 FIN/274/0000	ALL
M00042		S220T116-1 ANT-DME-1	284A0502 81205	1	34-55-11 580/144/0000	YK901-YK910, YK918, YL421- YL423
M00042		DMNI50-2-6 ANT-DME-1	284A0502 81205	1	34-55-11 580/144/0000	YK911-YK917, YK919-YL401, YL424-YL430
M00042		DMN150-2-6 ANT-DME-1	284A0502 81205	1	34-55-11 580/144/0000	YM643-YM670
M00043		10-61311-4 ANT-DME-2	284A0502 81205	1	34-55-21 641/143/0	YC001-YC050

EQUIPMENT LIST

D280A103

Section M00000

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00043		S220T116-1 ANT-DME-2	284A0502 81205	1	34-55-21 641/143/0	YK901-YK910, YK918, YL421- YL423
M00043		DMNI50-2-6 ANT-DME-2	284A0502 81205	1	34-55-21 641/143/0	YK911-YK917, YK919-YL401, YL424-YL430
M00043		DMN150-2-6 ANT-DME-2	284A0502 81205	1	34-55-21 641/143/0	YM643-YM670
M00044		10-61311-4 ANT-BOTTOM AIR TRAFFIC CONTROL	286A5181 81205	1	34-53-31 355/ /	YC001-YC050, YM643-YM670
M00044		S220T116-1 ANT-BOTTOM AIR TRAFFIC CONTROL	284A0503 85526	1	34-53-31 355/ /	YK901-YK910, YK918, YL421- YL423
M00044		10-61311-4 ANT-BOTTOM AIR TRAFFIC CONTROL	284A0503 85526	1	34-53-31 355/ /	YK911-YK917, YK919-YL401, YL424-YL430
M00046		60B92404-6 BOOST PUMP-TANK 1 AFT	343A3111 81205	1	28-23-11 WBL140/ /	YC001-YC009
M00046		60B92404-7 BOOST PUMP-TANK 1 AFT	343A3111 81205	1	28-23-11 WBL140/ /	YC010-YC029
M00046		60B92404-8 BOOST PUMP-TANK 1 AFT	343A3111 81205	1	28-23-11 WBL140/ /	YC030
M00046		60B92404-10 BOOST PUMP-TANK 1 AFT	343A3111 81205	1	28-23-11 WBL140/ /	YC031-YM670
M00047		60B92404-6 BOOST PUMP-TANK 1 FWD	343A3111 81205	1	28-23-11 102/FSS/L	YC001-YC009
M00047		60B92404-7 BOOST PUMP-TANK 1 FWD	343A3111 81205	1	28-23-11 102/FSS/L	YC010-YC029
M00047		60B92404-8 BOOST PUMP-TANK 1 FWD	343A3111 81205	1	28-23-11 102/FSS/L	YC030
M00047		60B92404-10 BOOST PUMP-TANK 1 FWD	343A3111 81205	1	28-23-11 102/FSS/L	YC031-YM670
M00048		60B92404-6 BOOST PUMP-TANK 2 AFT	343A3111 81205	1	28-23-11 WBL135/ /	YC001-YC009

EQUIPMENT LIST

D280A103

Section M00000

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00048		60B92404-7 BOOST PUMP-TANK 2 AFT	343A3111 81205	1	28-23-11 WBL135/ /	YC010-YC029
M00048		60B92404-8 BOOST PUMP-TANK 2 AFT	343A3111 81205	1	28-23-11 WBL135/ /	YC030
M00048		60B92404-10 BOOST PUMP-TANK 2 AFT	343A3111 81205	1	28-23-11 WBL135/ /	YC031-YM670
M00049		60B92404-6 BOOST PUMP-TANK 2 FWD	343A3111 81205	1	28-23-11 FS104/ /	YC001-YC009
M00049		60B92404-7 BOOST PUMP-TANK 2 FWD	343A3111 81205	1	28-23-11 FS104/ /	YC010-YC029
M00049		60B92404-8 BOOST PUMP-TANK 2 FWD	343A3111 81205	1	28-23-11 FS104/ /	YC030
M00049		60B92404-10 BOOST PUMP-TANK 2 FWD	343A3111 81205	1	28-23-11 FS104/ /	YC031-YM670
M00053		10-62239-1 HORN-GRD CREW CALL	284A0806 10402	1	23-43-11 231/185/R001	ALL
M00057		DMC50-17 ANT-VHF 1 COMM	233A5202 85226	1	23-12-11 630/305/R005	YC001-YK910, YK918-YK920, YL421-YL425, YM643-YM646
M00057		DMC50-17-3 ANT-VHF 1 COMM	233A5202 85226	1	23-12-11 630/305/R005	YK911-YK917, YL401, YL426- YL430, YM647- YM670
M00058		DMC50-17-2 ANT-VHF 2 COMM	284A0501 85226	1	23-12-21 727D+11/148/0000	YC001-YC050
M00058		DMC50-17 ANT-VHF 2 COMM	284A0501 85226	1	23-12-21 727D+11/148/0000	YK901-YK910, YK918-YK920, YL421-YL423
M00058		DMC50-17-3 ANT-VHF 2 COMM	284A0501 85226	1	23-12-21 727D+11/148/0000	YK911-YK917, YL401, YL424- YM670
M00062		2041446-0401 ANT-WEATHER RADAR	284A0506 97896	1	34-41-11 178/200/R005	ALL

EQUIPMENT LIST

D280A103

Section M00000

Page 4

Feb 09/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00063		622-5342-101 AMPL-PASS ADDRESS	284A0410 13499	1	23-31-01 E001-03/ /	ALL
M00074		285W0024-1B HANDSET-FWD ATTND PNL	417A6500 81205	1	23-42-12 P013-00/ /	ALL
M00075		285W0024-1B HANDSET-AFT ATTND PNL	417A6500 81205	1	23-42-12 P014-00/ /	ALL
M00077		10-62090-30 SPKR-COCKPIT INPH-CAPT	232A1400 81205	1	23-51-01 226/268/L015	ALL
M00078		10-62090-30 SPKR-COCKPIT INPH-FO	232A1401 81205	1	23-51-02 226/268/R020	ALL
M00096		980-4700-042 FLIGHT DATA RECORDER-SOLID STATE	284A0402 97896	1	31-31-11 942/290/0	ALL
M00098		S210N701-38 FAN-NORMAL EXHAUST	217A1003 81205	1	21-27-21 362/164/R027	ALL
M00099		S210N701-38 FAN-ALTERNATE EXHAUST	217A1003 81205	1	21-27-21 370/164/R027	ALL

EQUIPMENT LIST

D280A103

Section M00000

Page 5 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00100		S210N701-43 DETECTOR-AIRFLOW	217A1002 54813	1	21-27-21 200/193/R020	ALL
M00101	9	066-50008-0406 RT-WEATHER RADAR (737-EB34-0193)	284A0804 97896	1	34-41-11 188/ /	YC001-YC007
M00101		066-50008-0405 RT-WEATHER RADAR	284A0804 97896	1	34-41-11 188/ /	YC008-YC011
M00101		066-50008-0406 RT-WEATHER RADAR	284A0804 97896	1	34-41-11 188/ /	YC012-YC050
M00101		066-50008-0408 RT-WEATHER RADAR	284A0804 97896	1	34-41-11 188/ /	YK901-YM670
M00102		10-60897 WAVEGUIDE-WEATHER RADAR	65C16133 81205	1	34-41-11 195/170/L005	ALL
M00103		2041213-0413 MOUNT-WEATHER RADAR	284A0804 97896	1	34-41-11 188/170/R008	ALL
M00110	1	69-34728-1 CIT BOARD-RADIO NOISE SUPPRES	284A1204 81205	1	27-41-11 J004-00/	ALL
M00110	2	69-34728-2 CIT BOARD-RADIO NOISE SUPPRES	284A1204 81205	1	27-41-11 J004-00/ /	ALL
M00117		65C36813-1 STRIKE-ELECTRIC	65C36804 80477	1	52-51-11 280/246/R010	YC001-YC030
M00118		VENDORSUPPLIEDSEEIPCFORP-NINFO RIGHT IGNITION EXCITER	332A2000 1Z812	2	74-11-11 ENG/ /	ALL
M00149	9	064-50000-2000 XCVR-VHF 1 (SB 23-1245)	284A0410 27914	1	23-12-11 E001-03/ /	YC001-YC030
M00149		064-50000-0110 XCVR-VHF 1	284A0410 27914	1	23-12-11 E001-03/ /	YC001-YC050
M00149		064-50000-2000 XCVR-VHF 1	284A0410 27914	1	23-12-11 E001-03/ /	YK901-YM670
M00150	9	064-50000-2000 XCVR-VHF 2 (SB 23-1245)	284A0410 27914	1	23-12-21 E001-05/ /	YC001-YC030
M00150		064-50000-0110 XCVR-VHF 2	284A0410 27914	1	23-12-21 E001-05/ /	YC001-YC050
M00150		064-50000-2000 XCVR-VHF 2	284A0410 27914	1	23-12-21 E001-05/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section M00100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00157		10-62232-01 SPEAKER-FWD ATTD	411A2211 80331	1	23-31-04 310/290/L030	ALL
M00162	1	S283A301-3 CONTROL UNIT-ANTISKID/AUTOBRAKE	284A0410 81205	1	32-41-11 E001-03/ /	ALL
M00162	2	S283A301-1 CONTROL UNIT-ANTISKID/AUTOBRAKE	284A0410 81205	1	32-41-11 E001-03/ /	ALL
M00163	9	066-01127-1602 XPDR-AIR TRAFFIC CONTROL 1 (SB 34-1765)	284A0410 22373	1	34-53-11 E001-02/ /	YC001-YC030
M00163	8	066-01127-1601 XPDR-AIR TRAFFIC CONTROL 1	284A0410 22373	1	34-53-11 E001-02/ /	YC001-YC011
M00163		066-01127-1601 XPDR-AIR TRAFFIC CONTROL 1	284A0410 22373	1	34-53-11 E001-02/ /	YC012-YC050
M00163		066-01127-1602 XPDR-AIR TRAFFIC CONTROL 1	284A0410 22373	1	34-53-11 E001-02/ /	YK901-YM670
M00164		066-50013-0101 INTERROGATOR DME-1	284A0410 27914	1	34-55-11 E001-02/ /	YC001-YC050
M00164		066-50013-0101 INTERROGATOR DME-1	284A0410 13499	1	34-55-11 E001-02/ /	YK901-YM670
M00165		066-50013-0101 INTERROGATOR DME-2	284A0410 27914	1	34-55-21 E001-05/ /	YC001-YC050
M00165		066-50013-0101 INTERROGATOR DME-2	284A0410 13499	1	34-55-21 E001-05/ /	YK901-YM670
M00171		102AH2AG SNSR-TOTAL AIR TEMPERATURE	65-20986 04274	1	30-31-11 268/191/L050	ALL
M00175		S251A301-1 PCU UNIT-RUDDER	65-45160 81205	1	22-23-12 1087/ /	ALL
M00194		10-3275-32 BOTTLE-L EXT	65-56291 81205	1	26-21-11 727/190/L070	ALL
M00195		10-3275-32 BOTTLE-R EXT	65-56291 81205	1	26-21-11 727/190/L070	ALL
M00198		10-62038-237 CONT PNL-A/P	233A8103 81205	1	22-11-11 P007-00/ /	YC001-YC030
M00198		822-1567-102 CONT PNL-A/P	233A8103 81205	1	22-11-11 P007-00/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section M00100

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00200		90234-5 HTR ASSY-AFT DRAIN MAST	417A2360 81205	1	30-71-11 995/186/L019	ALL
M00207		1N3311B DIODE-MASTER DIM	65C25703 80131	1	33-18-11 P006-00/ /	ALL
M00208		1N3311B DIODE-MASTER DIM	69-45109 80131	1	33-18-11 P006-00/ /	ALL
M00209		1N3311B DIODE-MASTER DIM	69-45109 81031	1	33-18-11 P006-00/ /	ALL
M00210		1N3311B DIODE-MASTER DIM	69-45109 81031	1	33-18-11 P006-00/ /	ALL
M00213		VENDORSUPPLIEDSEEIPCFORP-NINFO XMTR-OIL QTY	332A2000 12812	2	79-31-11 ENG/ /	ALL
M00219	1	10-61072-7 XDCCR-A/P CWS FORCE (PITCH CAPT)	251A2109 81205	1	22-11-11 223/202/L014	YC001-YC019
M00219	1	GM10503 XDCCR-A/P CWS FORCE (PITCH CAPT)	251A2109 81205	1	22-11-11 223/202/L014	YC020-YM670
M00219	2	10-61072-8 XDCCR-A/P CWS FORCE (PITCH CAPT)	251A2109 81205	1	22-11-11 223/202/L014	YC001-YC019
M00219	2	GM10603 XDCCR-A/P CWS FORCE (PITCH CAPT)	251A2109 81205	1	22-11-11 223/202/L014	YC020-YM670
M00220	1	10-61072-7 XDCCR-A/P CWS FORCE (PITCH F/O)	251A1814 81205	1	22-11-11 215/190/R015	YC001-YC019
M00220	1	GM10503 XDCCR-A/P CWS FORCE (PITCH F/O)	251A1814 81205	1	22-11-11 215/190/R015	YC020-YM670
M00220	2	10-61072-8 XDCCR-A/P CWS FORCE (PITCH F/O)	251A1814 81205	1	22-11-11 215/190/R015	YC001-YC019
M00220	2	GM10603 XDCCR-A/P CWS FORCE (PITCH F/O)	251A2109 81205	1	22-11-11 215/190/R015	YC020-YM670
M00221	1	10-61072-7 XDCCR-A/P CWS FORCE (ROLL)	65-55731 81205	1	22-11-11 215/196/L024	YC001-YC019
M00221	1	GM10603 XDCCR-A/P CWS FORCE (ROLL)	65-55731 81205	1	22-11-11 215/196/L024	YC020-YM670
M00221	2	10-61072-8 XDCCR-A/P CWS FORCE (ROLL)	65-55731 81205	1	22-11-11 215/196/L024	ALL

EQUIPMENT LIST

D280A103

Section M00200

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00223		607510-3 MDL-LEFT 35 DEG F CONTROL	213A1002 70210	1	21-51-16 566/164/L032	YM643-YM670
M00224		607510-3 MDL-RIGHT 35 DEG F CONTROL	213A1002 70210	1	21-51-26 566/164/R032	YM643-YM670
M00225		DMC50-17-2 ANT-VHF 3 COMM	284A0501 85266	1	23-12-31 471/150/0000	YC001-YC050
M00225		DMC50-17 ANT-VHF 3 COMM	284A0501 85266	1	23-12-31 471/150/0000	YK901-YK910, YK918-YK920, YL421-YL423
M00225		DMC50-17-3 ANT-VHF 3 COMM	284A0501 85266	1	23-12-31 471/150/0000	YK911-YK917, YL401, YL424- YM670
█ M00226	9	622-5272-001 XCVR-HF 1 (MR 39273-4)	284A0460 13499	1	23-11-11 E006-02/ /	YC005-YC007
█ M00226	9	964-0452-011 XCVR-HF 1 (SB 23-1299)	284A0480 13499	1	23-11-11 E008-01/ /	YK907-YK909
█ M00226		964-0452-011 XCVR-HF 1	284A0480 27914	1	23-11-11 E008-01/ /	YK910-YK920, YL421-YL430
█ M00227	9	792-6140-001 COUPLER-HF 1 ANT (MR 39274-4)	284A0519 13499	1	23-11-11 / /	YC005-YC007
█ M00227	9	964-0453-011 COUPLER-HF 1 ANT (SB 23-1299)	284A0519 13499	1	23-11-11 / /	YK907-YK909
█ M00227		964-0453-011 COUPLER-HF 1 ANT	284A0519 13499	1	23-11-11 / /	YK910-YK920
█ M00227		964-0453-011 COUPLER-HF 1 ANT	284A0519 27914	1	23-11-11 / /	YL421-YL430
M00228		176A1001-1 ANT ASSY-HF	284A0519 81205	1	23-11-11 P010-04/ /	ALL
M00232		C-07202-2 SHAKER-CAPT CONTROL COLUMN	65-46352 83326	1	27-32-11 210/220/L020	ALL
M00234		60B89004-10 BOOST PUMP CTR TANK LEFT	343A3101 81205	1	28-23-11 WBL95/ /	YC001-YC007
M00234		60B89004-12 BOOST PUMP CTR TANK LEFT	343A3101 81205	1	28-23-11 WBL95/ /	YC008-YC029

EQUIPMENT LIST

D280A103

Section M00200

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00234		60B89004-14 BOOST PUMP CTR TANK LEFT	343A3101 81205	1	28-23-11 WBL95/ /	YC030
M00234		60B89004-16 BOOST PUMP CTR TANK LEFT	343A3101 81205	1	28-23-11 WBL95/ /	YC031-YL430
M00234		60B89004-16 BOOST PUMP CTR TANK-LEFT	343A3101 81205	1	28-23-11 WBL95/ /	YM643-YM670
M00235		60B89004-10 BOOST PUMP CTR TANK RIGHT	343A3101 81205	1	28-23-11 WBL095/ /	YC001-YC007
M00235		60B89004-12 BOOST PUMP CTR TANK RIGHT	343A3101 81205	1	28-23-11 WBL095/ /	YC008-YC029
M00235		60B89004-14 BOOST PUMP CTR TANK RIGHT	343A3101 81205	1	28-23-11 WBL095/ /	YC030
M00235		60B89004-16 BOOST PUMP CTR TANK RIGHT	343A3101 81205	1	28-23-11 WBL095/ /	YC031-YL430
M00235		60B89004-16 BOOST PUMP CTR TANK-RIGHT	343A3101 81205	1	28-23-11 WBL095/ /	YM643-YM670
M00237		10-62187-1 MODULE-C0MPT 0VHT DET CONT	284A0410 81205	1	26-12-11 E001-04/ /	YC001-YC007
M00237		10-62187-2 MODULE-C0MPT 0VHT DET CONT	284A0410 81205	1	26-12-11 E001-04/ /	YC008-YM670
M00241		10-3087-4 SOLENOID-LND GR LEVER LATCH	65-54219 81205	1	32-31-11 200/238/0000	ALL
M00242		10-61292-5 PUMP-HYDRAULIC STANDBY	271A1442 81205	1	29-22-11 727+18/150/R027	ALL
M00243		85-13-06011 HANDMIC-CAPT	TBD-0000 D9240	1	23-51-01 / /	YC001-YC019
M00243		85-13-06243-03 HANDMIC-CAPT	TBD-0000 D9240	1	23-51-01 / /	YC024-YC026
M00243		903-1341 HANDMIC-CAPT	65-39526 81134	1	23-51-01 / /	YK919-YK920, YL429
M00244		85-13-06011 HANDMIC-F/O	TBD-0000 D9240	1	23-51-02 / /	YC001-YC019
M00244		85-13-06243-03 HANDMIC-F/O	TBD-0000 D9240	1	23-51-02 / /	YC024-YC026

EQUIPMENT LIST

D280A103

Section M00200

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00244		903-1341 HANDMIC-F/O	65-39526 81134	1	23-51-02 / /	YK919-YK920, YL429
M00245		85-13-06011 HANDMIC-1 OBS	TBD-0000 D9240	1	23-51-03 P006-00/ /	YC001-YC019
M00245		85-13-06243-03 HANDMIC-1 OBS	TBD-0000 D9240	1	23-51-03 P006-00/ /	YC024-YC026
M00245		903-1341 HANDMIC-1 OBS	TBD-0000 28856	1	23-51-03 P006-00/ /	YK919-YK920, YL429
M00268		35599-2-255 DETECTOR-L WING OVHT OUTBD	218A3210 73168	1	26-12-11 FS198/ /	ALL
M00269		35599-2-255 DETECTOR-R WING OVHT OUTBD	218A3210 73168	1	26-12-11 FS195/ /	ALL
M00270		35610-4-400 DETECTOR-MAIN WHEEL WELL FIRE	284A0821 73168	1	26-12-11 684/200/MULT	YC001-YC002, YC007-YC030
M00270		35614-4-400 DETECTOR-MAIN WHEEL WELL FIRE	284A0821 73168	1	26-12-11 684/200/MULT	YC003-YC006
M00270		04-90010-110D DETECTOR-MAIN WHEEL WELL FIRE	284A0821 73168	1	26-12-11 684/200/MULT	YC031-YM670
M00272		35626-4-255 DETECTOR-FWD KEEL BEAM OVHT	218A3410 73168	1	26-12-11 545/160/	ALL
M00273		35555-4-255 DETECTOR-AFT KEEL BEAM OVHT	218A3420 73168	1	26-12-11 722/151/R004	ALL
M00275		35575-2-255 DETECTOR-AFT OVHT SEC 56	218A3610 73168	1	26-12-11 1016/202/L011	ALL
M00276		35555-4-255 DETECTOR-AFT OVHT SEC 58	218A3810 73168	1	26-12-11 1045/ /	ALL
M00277		10-62239-2 HORN-APU FIRE WARN	355A5400 81205	1	26-11-31 726/172/R023	ALL
M00279		S332A250-1 MDL-ENG/APU FIRE OVHT DET CONT-WHITTAKER	284A0420 81205	1	26-11-11 E002-02/ /	YC001-YC005
M00279		S332A250-2 MDL-ENG/APU FIRE OVHT DET CONT-WHITTAKER	284A0420 81205	1	26-11-11 E002-02/ /	YC006-YM670
M00296		95-23-08906-13 HEADSET-1/OBS	TBD-0000 D9240	1	23-51-03 209/223/R011	YC001-YC003

EQUIPMENT LIST

D280A103

Section M00200

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00296		045-760-011 HEADSET-1/OBS	TBD-0000 D8114	1	23-51-03 209/223/R011	YC004-YC050
M00296		20046-1 HEADSET-1/OBS	TBD-0000 78711	1	23-51-03 209/223/R011	YK901-YK906
M00299		R620M3-12 ACTR-AIR INLET DOOR	65-50925 81039	1	49-62-11 1055/240/R037	YC001-YC050
M00299		R6200M3-13 ACTR-AIR INLET DOOR	65-50925 81039	1	49-62-11 1055/240/R037	YK901-YM670

EQUIPMENT LIST

D280A103

Section M00200
Page 5 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00315		69-78214-3 AURAL WARNING MODULE	232A4101 81205	1	31-51-11 205/209/R006	YC001-YK911, YK918, YL421- YL426, YM643- YM651
M00315		69-78214-4 AURAL WARNING MODULE	232A4101 81205	1	31-51-11 205/209/R006	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
M00320		10-61833-6 WINDOW HEAT CONTROL UNIT RIGHT SIDE	284A0420 532752	1	30-41-11 E002-01/ /	YC001-YC002, YC008-YM670
M00320		10-61833-4 WINDOW HEAT CONTROL UNIT RIGHT SIDE	284A0420 532752	1	30-41-11 E002-01/ /	YC003-YC007
M00321		10-61833-6 WINDOW HEAT CONTROL UNIT LEFT FRONT	284A0420 532752	1	30-41-11 E002-01/ /	YC001-YC002, YC008-YM670
M00321		10-61833-4 WINDOW HEAT CONTROL UNIT LEFT FRONT	284A0420 532752	1	30-41-11 E002-01/ /	YC003-YC007
M00322		10-61833-6 WINDOW HEAT CONTROL UNIT LEFT SIDE	284A0440 532752	1	30-41-12 E004-02/ /	YC001-YC002, YC008-YM670
M00322		10-61833-4 WINDOW HEAT CONTROL UNIT LEFT SIDE	284A0440 532752	1	30-41-12 E004-02/ /	YC003-YC007
M00323		10-61833-6 WINDOW HEAT CONTROL UNIT RIGHT FRONT	284A0440 532752	1	30-41-12 E004-02/ /	YC001-YC002, YC008-YM670
M00323		10-61833-4 WINDOW HEAT CONTROL UNIT RIGHT FRONT	284A0440 532752	1	30-41-12 E004-02/ /	YC003-YC007
M00324		65-52810-46 MDL-AIR COND RELAYS	284A0440 81205	1	21-51-11 E004-01/ /	YC001-YC022
M00324		65-52810-64 MDL-AIR COND RELAYS	284A0440 81205	1	21-51-11 E004-01/ /	YC023-YL430
M00324		65-52810-57 MDL-AIR COND RELAYS	284A0440 81205	1	21-51-11 E004-01/ /	YM643-YM670
M00326		541674-4 ACTR-LEFT RAM AIR	213A3004 70210	1	21-51-14 519/166/L057	ALL
M00327		541674-4 ACTR-RIGHT RAM AIR	213A3004 70210	1	21-51-24 519/166/R057	ALL

EQUIPMENT LIST

D280A103

Section M00300

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00328		607518-2 CONTROLLER-LEFT RAM AIR	213A1002 70210	1	21-51-14 567/164/L032	YM643-YM670
M00329		607518-2 CONTROLLER-RIGHT RAM AIR	213A1002 70210	1	21-51-24 567/164/R032	YM643-YM670
M00339		S256T011-6 MOT-TRAILING EDGE ALTERNATE FLAP DRIVE	256A3510 81205	1	27-53-12 727/195/0000	ALL
M00345		10-60498-13 MDL CABIN TEMP CONTROL	284A0440 81205	1	21-61-21 E004-01/ /	YM643-YM670
M00347		35646-2-255 DET-AFT CARGO COMPT OVHT	218A3610 73168	1	26-12-11 947/ /	ALL
M00348		35658-4-255 DET-AFT CARGO COMPT OVHT	218A3610 73168	1	26-12-11 727/201/L009	ALL
M00355		35594-4-255 DET-L FWD A/C PACKBAY OVHT	218A3110 73168	1	26-12-11 540/ /	ALL
M00356		35594-4-255 DET-R FWD A/C PACKBAY OVHT	218A3112 73168	1	26-12-11 580/155/R040	ALL
M00359		10-61359-3 ACTR-SPEED BRAKE HAND	251A1910 81205	1	27-62-11 199/205/L006	ALL
M00370		35574-4-255 DET-LEFT WING OVHT INBD	218A3910 73168	1	26-12-11 540/170/L025	ALL
M00371		35574-4-255 DET-RIGHT WING OVHT INBD	218A3910 73168	1	26-12-11 540/170/R025	ALL
M00381	9	066-01127-1602 XPDR-AIR TRAFFIC CONTROL 2 (SB 34-1765)	824A0410 22373	1	34-53-21 E001-05/ /	YC001-YC030
M00381		066-01127-1301 XPDR-AIR TRAFFIC CONTROL 2	824A0410 22373	1	34-53-21 E001-05/ /	YC001-YC011
M00381		066-01127-1601 XPDR-AIR TRAFFIC CONTROL 2	824A0410 22373	1	34-53-21 E001-05/ /	YC012-YC050
M00381		066-01127-1602 XPDR-AIR TRAFFIC CONTROL 2	824A0410 22373	1	34-53-21 E001-05/ /	YK901-YM670
M00383		980-6022-001 MDL-VOICE RECORDER	284A0460 97896	1	23-71-01 907/195/R045	YC001-YL430
M00383		980-6022-001 MDL-VOICE RECORDER	284A0460 97896	1	23-71-01 E006-01/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section M00300

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00392		607400-1-1 SELECTOR-CONTROL CABIN TEMP	233A3101 70210	1	21-61-21 P005-17/ /	YM643-YM670
M00393		607400-1-1 SELECTOR-PASSENGER CABIN TEMP	233A3101 70210	1	21-61-22 P005-17/ /	YM643-YM670
M00394		1N2976B DIODE-MASTER DIM	69-45109 80131	1	33-18-21 P006-00/ /	ALL

EQUIPMENT LIST

D280A103

Section M00300

Page 3 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00404		S355A001-1 BOTTLE-APU EXT	65-62582 81205	1	26-21-11 1025/ /	YC001-YC050
M00404		10-3275-32 BOTTLE-APU EXT	65-62582 81205	1	26-21-11 1025/ /	YK901-YM670
M00411	9	064-50000-2000 XCVR-VHF-3 (SB 23-1245)	284A0430 27914	1	23-12-31 E003-03/ /	YC001-YC030
M00411		064-50000-0110 XCVR-VHF-3	284A0430 27914	1	23-12-31 E003-03/ /	YC001-YC050
M00411		064-50000-2000 XCVR-VHF-3	284A0430 27914	1	23-12-31 E003-03/ /	YK901-YM670
M00414		10-61369-9 ACTR-MACH TRIM	65-45134 81205	1	22-18-11 1164/276/	ALL
M00416		1N4385 DIODE-LEVER LATCH SOLENOID	65-54219 80131	1	32-31-11 197/236/R009	ALL
M00421		VENDORSUPPLIEDSEEIPCFORP-NINFO LEFT IGNITION EXCITER	332A2000 1Z812	2	74-11-11 ENG/ /	ALL
M00424		C-07202-2 SHAKER-F/O CONTROL COLUMN	65-46353 83326	1	27-32-21 210/220/R020	ALL
M00428		MS50-T30-1 BOOM HEADSET-CAPT	TBD-0000 28856	1	23-51-01 254/ /	YC001-YC003
M00428		045-230-325 BOOM HEADSET-CAPT	TBD-0000 D8114	1	23-51-01 254/ /	YC004-YC050
M00428		045-230-325 BOOM HEADSET-CAPT	TBD-0000 28856	1	23-51-01 254/ /	YK901-YM670
M00429		MS50-T30-1 BOOM HEADSET-F/O	TBD-0000 28856	1	23-51-02 254/ /	YC001-YC003
M00429		045-203-325 BOOM HEADSET-F/O	TBD-0000 D8114	1	23-51-02 254/ /	YC004-YC050
M00429		045-230-325 BOOM HEADSET-F/O	TBD-0000 28856	1	23-51-02 254/ /	YK901-YM670
M00431		045-230-325 BOOM HEADSET-FIRST OBSERVER	TBD-0000 28856	1	23-51-02 254/ /	YK901-YM670
M00469		69-55179-78 MDL-DIMMING & ANNUNCIATION	284A0202 81205	1	31-52-11 J019-00/ /	ALL

EQUIPMENT LIST

D280A103

Section M00400
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00516		1N4385 DIODE-PASS SIGN	65-73709 80131	1	33-25-11 P005-00/ /	ALL
M00517		971-4193-001 ACCELEROMETER-FLIGHT RECORDER	284A0819 97896	1	31-31-14 666/193/R048	ALL
M00520		253T4015-7 SNSR-CAPT CONTROL WHEEL POSITION	251A1806 81205	1	31-31-14 215/180/L020	ALL
M00522		S250N104-4 SNSR-RUDDER PEDAL QUADRANT POSITION	251A3480 81205	1	31-31-14 227/194/L020	ALL
M00524		MC10-25-104 OXY MASK-CAPT	232A8100 F5341	1	23-51-01 P021-00/ /	YC001-YC050
M00524		MF10-02-11 OXY MASK-CAPT	232A8100 F5341	1	23-51-01 P021-00/ /	YK901-YM670
M00525		MC10-25-104 OXY MASK-F/O	232A8100 F5341	1	23-51-02 P023-00/ /	YC001-YC050
M00525		MF10-02-11 OXY MASK-F/O	232A8100 F5341	1	23-51-02 P023-00/ /	YK901-YM670
M00526		MC10-25-104 OXY MASK-1 OBS	232A8100 F5341	1	23-51-03 P061-00/ /	YC001-YC050
M00526		MC10-08-109 OXY MASK-FIRST OBS	232A8100 F5341	1	23-51-03 P061-00/ /	YK901-YM670
M00527		1N4754A DIODE-GROUND HORN	65-73709 80131	0	23-43-11 P005-00/ /	ALL
M00528		285A1300-1 ENGINE ACCESSORY UNIT	284A0430 81205	1	78-34-11 E003-02/ /	ALL
M00542		69-76658-7 DIODE ASSY-CAPT INPH-2 BUS	233A5201 81205	1	23-51-51 P006-02/ /	ALL
M00543		69-76658-7 DIODE ASSY-CAPT INPH-2 BUS	233A5201 81205	1	23-51-51 P006-02/ /	ALL
M00544		69-76658-7 DIODE ASSY-F/O INPH-2 BUS	233A5201 81205	1	23-51-51 P006-02/ /	ALL
M00545		69-76658-7 DIODE ASSY-F/O INPH BATT BUS	233A5201 81205	1	23-51-51 P006-02/ /	ALL
M00564		69-60764-3 MDL-MASTER DIM	233A5201 81205	1	33-18-11 265/ /	ALL

EQUIPMENT LIST

D280A103

Section M00500

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00652	9	965-0976-003-204-204 EGPWS COMPUTER (737-EB34-0155)	CUSTOMER 97896	1	34-49-11 E001-01/ /	YC001-YC007
M00652	9	965-1690-052 COMPTR-GROUND PROX WARNING (SB 31-1287)	284A0410 97896	1	34-49-11 E001-01/ /	YC008-YC030
M00652	8	965-1690-050 COMPTR-GROUND PROX WARNING (SB 31-1287)	284A0410 97896	1	34-49-11 E001-01/ /	YC008-YC030
M00652		965-0976-003-204-204 COMPTR-GROUND PROXIMITY WARNING	284A0410 97896	1	34-49-11 E001-01/ /	YC008-YC022
M00652		965-0976-003-212-212 COMPTR-GROUND PROXIMITY WARNING	284A0410 97896	1	34-49-11 E001-01/ /	YC023-YC030
M00652		965-1690-052 COMPTR-GROUND PROXIMITY WARNING	284A0410 97896	1	34-49-11 E001-01/ /	YC031-YM670
M00675		967-0212-002 DIGITAL FLIGHT DATA ACQUISITION UNIT	284A0430 97896	1	31-31-11 E003-02/ /	YC001-YK905
M00675		967-0212-050 DIGITAL FLIGHT DATA ACQUISITION UNIT	284A0430 97896	1	31-31-11 E003-02/ /	YK906-YL430
M00675		967-0212-050 DIGITAL FLIGHT DATA ACQUISITION UNIT	284A0430 13983	1	31-31-11 E003-02/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section M00600

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00753		28823-7 COMPRESSOR-POTABLE WTR,AIR	417A2610 81205	1	38-41-13 855/179/L049	ALL

EQUIPMENT LIST

D280A103

Section M00700

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00805		1N5061 DIODE-BLOCKING	69-37369 80131	1	34-49-11 P003-07/ /	ALL
M00818		1N4384 DIODE-P5-16	69-37334 80131	1	21-33-11 P005-16/ /	ALL
M00819		1N4384 DIODE-P5-16	69-37334 80131	1	21-33-11 P005-16/ /	ALL
M00820		79326-001 HEATED HOSE FWD MAST	417A2140 81205	1	30-71-11 526/150/R028	ALL
M00888		822-1126-001 MOUNT-ANT COUPLER HF 1	284A0519 13499	1	23-11-11 / /	YC001-YC050
M00889		830-6069-001 FEEDLINE ASSY-HF 1 ANT	284A0519 13499	1	23-11-11 / /	YC001-YC050

EQUIPMENT LIST

D280A103

Section M00800
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00916		2243800-71 WIRELESS RECORDER-QUICK ACCESS RECORDER	284W0441 98571	1	31-35-03 E008-01/ /	YK910-YL430, YM645-YM651, YM653-YM670
M00917		10-62017-51 CMPTR-AT/SC	284A0410 81205	1	22-31-11 E001-01/ /	YC001-YC011
M00917		760SUE1-1 CMPTR-AT/SC	284A0410 81205	1	22-31-11 E001-01/ /	YC012-YC013
M00917		760SUE2-2 CMPTR-AT/SC	284A0410 81205	1	22-31-11 E001-01/ /	YC015-YC026
M00917		760SUE2-4 CMPTR-AT/SC	284A0410 81205	1	22-31-11 E001-01/ /	YC028-YC030
M00929	1	S250N104-5 XMTR-CONT SURF POSN (ELEV POSN,DUAL)	251A2105 81205	1	22-12-31 1158/258/R010	ALL
M00929	2	60B40042-6 XMTR-CONT SURF POSN (ELEV POSN,DUAL)	65C21846 81205	1	22-12-31 1158/258/R010	ALL
M00930	1	H504B XMTR-CONT SURF POSN (SPOILER 9)	251A1230 81205	1	22-11-31 W355/P05/RRS	ALL
M00930	2	H505B XMTR-CONT SURF POSN (SPOILER 9)	251A1230 81205	1	22-11-31 W355/P05/RRS	ALL
M00931	1	H504B XMTR-CONT SURF POSN (SPOILER 4)	251A1230 81205	1	22-11-31 W355/P05/LRS	ALL
M00931	2	H505B XMTR-CONT SURF POSN (SPOILER 4)	251A1230 81205	1	22-11-31 W355/P05/LRS	ALL
M00937	1	S250N104-5 XMTR-CONT SURF POSN (AILERON DUAL)	251A1680 81205	1	22-11-31 666/187/L020	ALL
M00937	2	60B40042-6 XMTR-CONT SURF POSN (AILERON DUAL)	65C19776 81205	1	22-11-31 666/187/L020	ALL
M00943		10-61985-5 ACTR-HYD A/P (AILERON 'A')	65C19731 81205	1	22-11-31 670/193/L040	ALL
M00958		S250N104-5 SENSOR-NEUT SHIFT	251A2101 81205	1	22-12-31 1160/274/R005	ALL
M00980		65-84209-21 MDL-AUTO SP BK ACCESS	284A0440 81205	1	27-62-11 E004-02/ /	ALL

EQUIPMENT LIST

D280A103

Section M00900

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01020		10-61985-5 ACTR-HYD A/P (ELEVATOR 'A')	65C19732 81205	1	22-12-31 1165/278/L007	ALL
M01022		10-61985-5 ACTR-HYD A/P (ELEVATOR 'B')	65C19732 81205	1	22-12-41 1161/287/L007	ALL
M01024		10-61985-5 ACTR-HYD A/P (AILERON 'B')	65C19731 81205	1	22-11-31 670/193/L050	ALL

EQUIPMENT LIST

D280A103

Section M01000
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01102		DMN4-26 DUAL LOCALIZER ANTENNA (NOSE)	284A0505 85226	1	34-31-11 178/187/	ALL
M01103		10-60556-32 PUMP-SYSTEM A ELEC 2 HYDRAULIC	65C26850 81205	1	29-11-12 672/171/L019	ALL
M01104		10-60556-32 PUMP-SYSTEM B ELEC 1 HYDRAULIC	65C26850 81205	1	29-11-12 674/171/R004	ALL
M01105		436-2 DET-GND FAULT SYS A ELEC 2 HYD PUMP	65C25703 16340	1	29-11-12 P092-00/ /	ALL
M01106		436-2 DET-GND FAULT SYS B ELEC 1 HYD PUMP	65C25703 16340	1	29-11-12 P091-00/ /	ALL
M01109		965-0758-001 MANAGEMENT UNIT-ACARS	284A0430 97896	1	23-27-11 E003-03/ /	YC001-YC050
M01124		10-62026-1 ACTR-AILERON TRIM	65C25400 81205	1	27-11-11 669/179/L035	ALL
M01125		10-62025-3 ACTR-RUDDER TRIM	251A3450 81205	1	27-21-11 RUD STA/51./4	ALL
M01126		10-62220-2 SWITCH+RUDDER TRIM CONTROL	69-73703 81205	1	27-21-11 P008-43/ /	YC001-YC030
M01126		10-62220-3 SWITCH+RUDDER TRIM CONTROL	69-73703 81205	1	27-21-11 P008-43/ /	YC031-YM670
M01142		30903872 SQUIB NO. 2 FOR BOTTLE M194	65-56291 81205	1	26-21-11 713/ /	ALL
M01143		30903871 SQUIB NO. 1 FOR BOTTLE M194	65-56291 81205	1	26-21-11 713/ /	ALL
M01144		30903871 SQUIB NO. 1 FOR BOTTLE M195	65-56291 81205	1	26-21-11 713/ /	ALL
M01145		30903872 SQUIB NO. 2 FOR BOTTLE M195	65-56291 81205	1	26-21-11 713/ /	ALL
M01146		30903872 SQUIB FOR BOTTLE M404	65-56291 81205	1	26-21-11 713/ /	ALL
M01147		35675-2-255 DET-AFT CARGO COMPT OVHT	218A3610 73168	1	26-12-11 727/ /	YC001-YL430
M01147		35560-2-255 DET-AFT CARGO COMPT OVHT	218A3610 73168	1	26-12-11 727/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section M01100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01148		10-62009-1 FAN-CABIN AIR RECIRCULATION	214A3001 81205	1	21-25-10 500D+9/164/R016	YM643-YM670
M01173		10-62018-8 MDL-T/R 1 CONTROL VALVE	271A6442 02689	1	78-34-11 //	YC001-YK910, YL421-YL423, YM643
M01173		10-62018-12 MDL-T/R 1 CONTROL VALVE	271A6442 02689	1	78-34-11 //	YK911-YL401, YL424-YL430, YM645-YM670
M01174		10-62018-8 MDL-T/R 2 CONTROL VALVE	271A6442 02689	1	78-34-21 //	YC001-YK910, YL421-YL423, YM643
M01174		10-62018-12 MDL-T/R 2 CONTROL VALVE	271A6442 02689	1	78-34-21 //	YK911-YL401, YL424-YL430, YM645-YM670
M01175		10-62225-003 COMPUTER-FLIGHT MANAGEMENT NO.1	284A0450 81205	1	34-61-11 E005-02/ /	YC001-YC026
M01175		176200-01-01 COMPUTER-FLIGHT MANAGEMENT NO.1	284A0452 35351	1	34-61-11 E005-02/ /	YC028-YM670
M01177		W92C ACTR-NOSE STEERING	275A5200 81205	1	32-51-11 253/202/L036	ALL
M01180		10-62008-37 REGULATOR-BLEED AIR	332A1034 81205	2	36-11-11 210/80/L020	YC001-YK906
M01180		10-62008-41 REGULATOR-BLEED AIR	332A1034 81205	2	36-11-11 210/80/L020	YK907-YM670
M01192	1	S250N104-5 XMTR-CONT SURF POSN (STAB 'A')	251A2101 81205	1	22-12-31 1164/268/L008	ALL
M01192	2	60B40042-6 XMTR-CONT SURF POSN (STAB 'A')	65-45134 81205	1	22-12-31 1164/268/L008	ALL
M01193	1	S250N104-4 XMTR-CONT SURF POSN (STAB 'B')	251A2101 81205	1	22-12-41 1164/268/R008	ALL
M01193	2	60B40042-3 XMTR-CONT SURF POSN (STAB 'B')	65-45134 81205	1	22-12-41 1164/268/R008	ALL

EQUIPMENT LIST

D280A103

Section M01100

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01201		251A4430-1 MDL-COLUMN SWITCHING	251A4400 81205	1	22-13-11 206/200/R015	ALL
M01206		69-37399-8 UNIT-MASTER CAUTION	233A7101 81205	1	34-21-11 P061-00/ /	YC001-YC007
M01206		69-37399-12 UNIT-MASTER CAUTION	233A7101 81205	1	34-21-11 P061-00/ /	YC008-YC030
M01206		69-37399-13 UNIT-MASTER CAUTION	233A7103 81205	1	34-21-11 P061-00/ /	YC031-YM670
M01209		2041444-0401 DRIVE UNIT-WEATHER RADAR ANTENNA	284A0506 97896	1	34-41-11 178/200/R005	ALL
M01212		10-62232-01 SPEAKER-AFT ATTD LH	411A2213 80331	1	23-31-04 973/287/L032	ALL
M01213		10-62232-01 SPEAKER-AFT ATTD RH	411A2214 80331	1	23-31-04 980/287/R032	ALL
M01219		287A4123-7 RESISTOR ASSY	287A4106 81205	1	33-51-12 264/284/R006	ALL
M01220		284A1844-1 DIODE TR3	284A0430 81483	1	24-32-11 387/181/R048	YC001-YC011
M01220		284A1844-2 DIODE TR3	284A0844 81483	1	24-32-11 387/181/R048	YC012-YC030
M01220		284A1844-3 DIODE TR3	284A0844 81483	1	24-32-11 387/181/R048	YC031-YM670
M01236		10-62008-22 SOLENOID-LOW FLOW (ENG. 1)	332A2300 59364	1	30-11-11 551/177/L192	ALL
M01237		10-62008-22 SOLENOID-LOW FLOW (ENG. 2)	332A2300 59364	1	30-11-11 551/177/R192	ALL
M01240	9	241-298-002-015 ENG VIB SIGNAL COND (-800) (SB 77-1069)	284A0430 S3960	1	77-31-11 E003-02/ /	YC001-YC030, YK901-YK911, YK918, YL421- YL426
M01240	9	241-298-002-015 ENG VIB SIGNAL COND (-700) (SB 77-1069)	284A0430 S3960	1	77-31-11 E003-02/ /	YM643-YM651
M01240	8	241-298-002-011 ENG VIB SIGNAL COND (-800) (SB 77-1069)	284A0430 51057	1	77-31-11 E003-02/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section M01200

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01240	8	241-298-002-011 ENG VIB SIGNAL COND (-800) (SB 77-1069)	284A0430 S3960	1	77-31-11 E003-02/ /	YK901-YK911, YK918, YL421- YL426
M01240	8	241-298-002-011 ENG VIB SIGNAL COND (-700) (SB 77-1069)	284A0430 S3960	1	77-31-11 E003-02/ /	YM643-YM651
M01240		6672M203 ENG VIBRATION SIGNAL CONDITIONER (-800)	284A0430 95411	1	77-31-11 E003-02/ /	YC001-YC011
M01240		241-258-032-110 ENG VIBRATION SIGNAL CONDITIONER (-800)	284A0430 51057	1	77-31-11 E003-02/ /	YC012-YC022
M01240		241-280-051-012 ENG VIBRATION SIGNAL CONDITIONER (-800)	284A0430 51057	1	77-31-11 E003-02/ /	YC023-YC026
M01240		241-280-053-013 ENG VIBRATION SIGNAL CONDITIONER (-800)	284A0430 51057	1	77-31-11 E003-02/ /	YC028-YC030
M01240		241-280-056-014 ENG VIBRATION SIGNAL CONDITIONER (-800)	284A0430 51057	1	77-31-11 E003-02/ /	YC031-YK911, YK918, YL421- YL426
M01240		241-298-002-015 ENG VIBRATION SIGNAL CONDITIONER (-800)	284A0430 51057	1	77-31-11 E003-02/ /	YK912-YK917, YK919-YL401, YL427-YL430
M01240		241-280-056-014 ENG VIBRATION SIGNAL CONDITIONER (-700)	284A0430 51057	1	77-31-11 E003-02/ /	YM643-YM651
M01240		241-298-002-015 ENG VIBRATION SIGNAL CONDITIONER (-700)	284A0430 51057	1	77-31-11 E003-02/ /	YM652-YM670
M01252		280T1004-8 PLUG-SYSTEM TEST	232A4230 81205	1	31-31-11 P018-02/ /	ALL
M01276		RD-AX7360-01 TAPE REPRODUCER-PRE-REC ANNOUNCEMENT	65C14967 54473	1	23-31-06 300/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section M01200
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01322		S210N701-38 FAN-EQUIP COOLING NORMAL SUPPLY	217A1001 81205	1	21-27-31 368/191/R049	ALL
M01323		S210N701-38 FAN-EQUIP COOLING ALTERNATE SUPPLY	217A1004 81205	1	21-27-31 368/184/R049	ALL
M01346		129-6-M06 COAX CONN TEE	284A0410 91836	1	34-55-11 E001-02/ /	ALL
M01347		129-6-M06 COAX CONN TEE	65-63844 91836	1	34-55-21 E003-03/ /	ALL
M01353		10-62090-12 REMOTE ELECTRONICS UNIT	284A0440 81205	1	23-51-01 E004-01/ /	YC001-YC007
M01353		10-62090-112 REMOTE ELECTRONICS UNIT	284A0440 81205	1	23-51-01 E004-01/ /	YC008-YC018
M01353		10-62090-113 REMOTE ELECTRONICS UNIT	284A0440 81205	1	23-51-01 E004-01/ /	YC019-YC022
M01353		10-62090-120 REMOTE ELECTRONICS UNIT	284A0440 81205	1	23-51-01 E004-01/ /	YC023-YC026
M01353		10-62090-121 REMOTE ELECTRONICS UNIT	284A0440 81205	1	23-51-01 E004-01/ /	YC028-YM670
M01386		417A5700 MDL-AISLE INDICATOR LT	417A5700 81205	1	33-51-21 490/208/L068	YC001-YC050
M01387		417A5700 MDL-AISLE INDICATOR LT	417A5700 81205	1	33-51-21 500H/208/L068	YC001-YC050
M01388		417A5700 MDL-AISLE INDICATOR LT	417A5700 81205	1	33-51-22 723B/208/L068	YC001-YC050
M01389		417A5700 MDL-AISLE INDICATOR LT	417A5700 81205	1	33-51-21 783/208/L068	YC001-YC050

EQUIPMENT LIST

D280A103

Section M01300

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01406		S220T116-1 ANT-TOP AIR TRAFFIC CONTROL	284A0503 85526	1	34-53-31 430/ /	YC001-YL430
M01406		S220T116-1 ANT-TOP AIR TRAFFIC CONTROL	284A0503 81205	1	34-53-31 430/ /	YM643-YM670
M01415		10-62085 MDL-LAV A (SEE Y004+++)	65C31601 81205	1	33-26-31 / /	ALL
M01418		S417A101 AFT-LAV D (SEE Y007+++)	417A1140 81205	1	33-26-31 948/236/L014	ALL
M01419		10-62085 MDL-LAV E (SEE Y008+++)	65C31601 81205	1	33-26-31 / /	ALL
M01439		S250N104-1 XMTR-SPEEDBRAKE HANDLE POSITION	65-52881 81205	1	27-62-13 186/203/L005	ALL
M01440		10-62009-1 FAN-CABIN AIR RECIRCULATION-L	214A3001 81205	1	21-25-11 TBD/ /	YC001-YL430
M01441		10-62009-1 FAN-CABIN AIR RECIRCULATION-R	214A3001 81205	1	21-25-11 525/171/R012	YC001-YL430
M01442		10-62091-17 MDL-ZONE TEMP CONT 1	284A0430 81205	1	21-51-12 E003-03/ /	YC001-YL430
M01443		10-62091-17 MDL-ZONE TEMP CONT 2	284A0430 81205	1	21-51-22 E003-03/ /	YC001-YL430
M01445		213A4101-2 MDL-FWD PASS CABIN TEMP SENSOR	412A1150 81205	1	21-61-13 416/274/R031	YC001-YL430
M01446		213A4101-2 MDL-AFT CABIN TEMP SENSOR	412A1100 81205	1	21-61-14 727G+13/274/R031	YC001-YL430
M01455		65-52810-46 MDL-AIR COND RELAYS NO 2	284A0440 81205	1	21-51-21 E004-01/ /	YC001-YC022
M01455		65-52810-64 MDL-AIR COND RELAYS NO 2	284A0440 81205	1	21-51-21 E004-01/ /	YC023-YL430
M01456		65C33409-1 MDL-AUX DIM/TEST	69-73627 81205	1	33-18-62 P006-00/ /	YC001-YC030
M01456		65C33409-3 MDL-AUX DIM/TEST	69-73627 81205	1	33-18-62 P006-00/ /	YC031-YM670
M01464		10-62232-01 SPEAKER-FWD ATTD	411A2212 80331	1	23-31-04 310/290/	ALL

EQUIPMENT LIST

D280A103

Section M01400

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01474		65-52820-2 UNIT-INTEGRATED FLIGHT SYSTEMS ACCESSORY	284A0410 81205	1	22-11-11 E001-01/ /	ALL
M01485	9	066-50000-2220 TCAS COMPUTER	284A0410 22373	1	34-45-11 E001-01/ /	YC001-YC011
M01485		940-0300-001 TCAS COMPUTER	284A0410 22373	1	34-45-11 E001-01/ /	YK901-YM670
M01486		071-50001-8102 TCAS ANTENNA-TOP	286A4009 22373	1	34-45-21 385/ /	ALL
M01487		071-50001-8102 TCAS ANTENNA-BOTTOM	286A4009 22373	1	34-45-21 305/ /	ALL
M01499	9	921000 DIGITAL INTER UNIT420 (INOP) SB 25-1542	284A0430 70093	1	23-32-21 E003-02/ /	YC001-YC013, YC016-YC018, YC020-YC030
M01499		921000 DIGITAL INTERFACE UNIT (420 SYSTEM)	284A0430 70093	1	23-32-21 E003-02/ /	YC001-YC026
M01499		921006 DIGITAL INTERFACE UNIT (420 SYSTEM)	284A0430 70093	1	23-32-21 E003-02/ /	YC028-YC050
M01499		925010-101 DIGITAL MEDIA UNIT (4200 SYSTEM)	284A0462 70093	1	23-32-21 E008-01/ /	YK910-YL430, YM647-YM670

EQUIPMENT LIST

D280A103

Section M01400

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01501		921000 TRAY ASSEMBLY	284A1732	1	23-32-21 E003-02/ /	YC001-YC050
M01501		914023-3 MOUNTING TRAY - DIU (420 SYSTEM)	284A0480 70093	1	23-32-21 E008-01/ /	YK901-YK909, YM643-YM646
M01501		925042-100 MOUNTING TRAY - DMU (4200 SYSTEM)	284A0480 70093	1	23-32-21 E008-01/ /	YK910-YL430, YM647-YM670
M01522		110-328-01 ANTENNA-EMERGENCY LOCATOR XMTR	284A0513 60253	1	23-24-11 797/306/L005	ALL
M01523		453-0004 XMTR-EMERGENCY LOCATOR	284A0513 60253	1	23-24-11 794/301/L010	YC001-YC021
M01523		453-5004 XMTR-EMERGENCY LOCATOR	284A0513 60253	1	23-24-11 794/301/L010	YC022-YM670
M01523A		452-3052 FRAME ASSEMBLY-TOP, ELT	284A0513 60253	1	23-24-11 794/301/L010	YK901-YM670
M01523B		452-5050 MOUNTING TRAY ASSEMBLY, ELT	284A0513 60253	1	23-24-11 794/301/L010	YK901-YM670
M01523C		452-5052 MOUNTING CAP ASSEMBLY, ELT	284A0513 60253	1	23-24-11 794/301/L010	YK901-YM670
M01524		611-6013-04 COAX ASSY-ELT ANTENNA (121.5/243 MHZ)	60253	1	23-24-11 797/300/L005	ALL

EQUIPMENT LIST

D280A103

Section M01500
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01632		176200-01-01 COMPUTER-FLIGHT MANAGEMENT NO.2	284A0452 35351	1	34-61-11 E005-02/ /	YK907-YM670
M01653		10-62231-12 MDL-CABIN PRESS CONT NO.1	284A0420 81205	1	21-31-22 E002-02/ /	YC001-YC011
M01653		10-62231-22 MDL-CABIN PRESS CONT NO.1	284A0420 81205	1	21-31-22 E002-02/ /	YC012-YC030
M01653		21933-01AA MDL-CABIN PRESS CONT NO.1	284A0420 81205	1	21-31-22 E002-02/ /	YC031-YK905
M01653		21933-01AB MDL-CABIN PRESS CONT NO.1	284A0420 81205	1	21-31-22 E002-02/ /	YK906
M01653		21933-01AC MDL-CABIN PRESS CONT NO.1	284A0420 81205	1	21-31-22 E002-02/ /	YK907-YM670
M01654		10-62231-12 MDL-CABIN PRESS CONT NO.2	284A0440 81205	1	21-31-23 E004-01/ /	YC001-YC011
M01654		10-62231-22 MDL-CABIN PRESS CONT NO.2	284A0440 81205	1	21-31-23 E004-01/ /	YC012-YC030
M01654		21933-01AA MDL-CABIN PRESS CONT NO.2	284A0440 81205	1	21-31-23 E001-01/ /	YC031-YK905
M01654		21933-01AB MDL-CABIN PRESS CONT NO.2	284A0440 81205	1	21-31-23 E001-01/ /	YK906
M01654		21933-01AC MDL-CABIN PRESS CONT NO.2	284A0440 81205	1	21-31-23 E001-01/ /	YK907-YM670
M01659		10-62233-5 ACTR-COMBINED STAB TRIM	251A4500 81205	1	27-41-11 1076/264/R005	YC001-YC019
M01659		10-62233-6 ACTR-COMBINED STAB TRIM	251A4500 81205	1	27-41-11 1076/264/R005	YC020-YC030
M01659		10-62233-7 ACTR-COMBINED STAB TRIM	251A4500 81205	1	27-41-11 1076/264/R005	YC031-YM670
M01666	1	TD-1982-1000 MDL-T/R 1 TIME DELAY	284A1222 08719	1	78-32-51 J022-00/ /	YC001-YK909, YL421-YL422
M01666	1	530740-1000 MDL-T/R 1 TIME DELAY	284A1222 35344	1	78-32-51 J022-00/ /	YK910-YL401, YL423-YM670
M01666	2	10167-1000-BT MDL-T/R 1 TIME DELAY	284A1222 35344	1	78-32-51 J022-00/ /	YC001-YK909, YL421-YL422

EQUIPMENT LIST

D280A103

Section M01600

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01666	2	TD-1982-1000 MDL-T/R 1 TIME DELAY	284A1222 08719	1	78-32-51 J022-00/ /	YK910-YL401, YL423-YM670
M01666	3	530740-1000 MDL-T/R 1 TIME DELAY	284A1222 35344	1	78-32-51 J022-00/ /	YC001-YK909, YL421-YL422
M01667	1	TD-1982-1000 MDL-T/R 2 TIME DELAY	284A1224 08719	1	78-32-61 J024-00/ /	YC001-YK909, YL421-YL422
M01667	1	530740-1000 MDL-T/R 2 TIME DELAY	284A1224 35344	1	78-32-61 J024-00/ /	YK910-YL401, YL423-YM670
M01667	2	10167-1000-BT MDL-T/R 2 TIME DELAY	284A1224 35344	1	78-32-61 J024-00/ /	YC001-YK909, YL421-YL422
M01667	2	TD-1982-1000 MDL-T/R 2 TIME DELAY	284A1224 08719	1	78-32-61 J024-00/ /	YK910-YL401, YL423-YM670
M01667	3	530740-1000 MDL-T/R 2 TIME DELAY	284A1224 35344	1	78-32-61 J024-00/ /	YC001-YK909, YL421-YL422
M01667 T	1	MS25171-1S NIPPLE-	92906	2	78-32-61 J024-00/ /	ALL
M01668		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	417A5900 81205	1	33-51-13 603/212/L067	YM643-YM670
M01669		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	417A5900 81205	1	33-51-13 603/212/R067	YM643-YM670
M01670	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	417A5900 81205	1	33-51-13 727C+13/212/L068	YC001-YC030
M01670		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	417A5900 81205	1	33-51-13 727C+13/212/L068	YC031-YM670
M01671	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	411A3220 81205	1	33-51-14 727C+13/212/R068	YC001-YC030
M01671		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	411A3220 81205	1	33-51-14 727C+13/212/R068	YC031-YL430
M01672	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	411A3220 81205	1	33-51-14 952/290/R014	YC001-YC030
M01672		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	411A3420 81205	1	33-51-14 952/290/R014	YC031-YM670
M01673	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	411A3220 81205	1	33-51-14 952/290/L014	YC001-YC030

EQUIPMENT LIST

D280A103

Section M01600

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01673		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	411A3420 81205	1	33-51-14 952/290/L014	YC031-YM670
M01674	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	411A3220 81205	1	33-51-12 322/291/R007	YC001-YC030
M01674		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	411A3220 81205	1	33-51-12 322/291/R007	YC031-YM670
M01675	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	411A3220 81205	1	33-51-12 322/291/L007	YC001-YC030
M01675		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	411A3220 81205	1	33-51-12 322/291/L007	YC031-YM670
M01676	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	417A5900 81205	1	33-51-12 500C+7/213/R067	YC001-YC030
M01676		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	417A5900 81205	1	33-51-12 500C+7/213/R067	YC031-YL430
M01677		417A5470-1 FORWARD ENTRY LT ASSY	417A5472 81205	1	33-29-11 314/293/R002	YC001-YC050
M01677		417A5470-8 FORWARD ENTRY LT ASSY	417A5472 81205	1	33-29-11 314/293/R002	YK901-YM670
M01678		417A5475-1 AFT ENTRY LT ASSY	411A3220 81205	1	33-29-11 968/293/R002	YC001-YC050
M01678		417A5475-9B AFT ENTRY LT ASSY	411A3220 81205	1	33-29-11 968/293/R002	YK901-YM670
M01679		S283U008-16 BALLAST-FLUOR LT ASSY	417A5470 81205	1	33-29-11 M1677/ /	ALL
M01681		116817-5 AFT DOOR AREA HEATER	214A8002 85932	1	21-42-11 975/297/R010	ALL
M01690		PU90-13000-201 CONTROL PANEL-FWD LAV SMOKE	417A6110 55065	1	26-14-11 305/290/L016	YC001-YK909, YL421-YM651
M01690		PU90-13000-501 CONTROL PANEL-FWD LAV SMOKE	417A6110 55065	1	26-14-11 305/290/L016	YK910-YK920, YM652-YM670
M01690		PU90-13000-501 CONTROL PANEL-FWD LAV SMOKE	10-62218 55065	1	26-14-11 305/290/L016	YL401
M01694	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	417A5900 81205	1	33-51-13 565/213/L068	YC001-YC030

EQUIPMENT LIST

D280A103

Section M01600

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01694		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	417A5900 81205	1	33-51-13 565/213/L068	YC031-YL430
M01695	9	BPS7-3 BATTERY PACK-EMER LT (EO B7378-33-04-01)	417A5900 81205	1	33-51-13 565/213/R068	YC001-YC030
M01695		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	417A5900 81205	1	33-51-13 565/213/R068	YC031-YL430

EQUIPMENT LIST

D280A103

Section M01600
Page 4 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01708		116817-5 FWD DOOR AREA HEATER	214A8001 85932	1	21-42-11 273/189/L022	ALL
M01709	9	S351A401-222 MDL-APU ELECTRONIC CONTROL UNIT	SB491119 81205	1	49-62-51 E6 880/177/R032	YC001-YC011
M01709		S351A401-221 MDL-APU ELECTRONIC CONTROL UNIT	284A0460 81205	1	49-62-51 902/197/R46	YC001-YC011
M01709		S351A401-222 MDL-APU ELECTRONIC CONTROL UNIT	284A0460 81205	1	49-62-51 902/197/R46	YC012-YC050
M01709		S351A401-222 MDL-APU ELECTRONIC CONTROL UNIT	284A0460 81205	1	49-62-51 902/197/R046	YK901-YL430
M01709		S351A401-222 MDL-APU ELECTRONIC CONTROL UNIT	284A0460 81205	1	49-62-51 E6 880/177/R032	YM643-YM670
M01710		S351A401-241 MDL-APU START CONVERTER UNIT	284A0420 81205	1	49-41-11 E002-02/ /	YC001-YC004
M01710		S351A401-245 MDL-APU START CONVERTER UNIT	284A0420 81205	1	49-41-11 E002-02/ /	YC005-YC023
M01710		S351A401-250 MDL-APU START CONVERTER UNIT	284A0420 81205	1	49-41-11 E002-02/ /	YC024-YM670
M01718		213A6101 MDL-CONTROL CABIN TEMP SENSOR	232A1411 81205	0	21-61-21 259/275/L006	ALL
M01719		213A4101 MDL-PASSENGER CABIN TEMP SENSOR	412A1110 81205	0	21-61-22 416/274/R031	YM643-YM670
M01720		S281A601-3001 CONTROL UNIT-STANDBY POWER	233A5201 07217	1	24-31-11 P006-00/ /	YC001-YC002
M01720		S281A601-3000 CONTROL UNIT-STANDBY POWER	233A5201 07217	1	24-31-11 P006-00/ /	YC003-YC007
M01720		S281A601-3001 CONTROL UNIT-STANDBY POWER	233A5220 07217	1	24-31-11 P006-00/ /	YC008-YC026
M01720	1	S281A601-3003 CONTROL UNIT-STANDBY POWER	233A5220 07217	1	24-31-11 P006-00/ /	YC028-YC030
M01720	1	S281A601-3009 CONTROL UNIT-STANDBY POWER	233A5220 07217	1	24-31-11 P006-00/ /	YC031-YM670
M01720	2	S281A601-3001 CONTROL UNIT-STANDBY POWER	233A5220 07217	1	24-31-11 P006-00/ /	YC028-YC030

EQUIPMENT LIST

D280A103

Section M01700

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01720	2	S281A601-3004 CONTROL UNIT-STANDBY POWER	233A5220 07217	1	24-31-11 P006-00/ /	YC031-YM670
M01720	3	S281A601-3003 CONTROL UNIT-STANDBY POWER	233A5220 07217	1	24-31-11 P006-00/ /	YC031-YM670
M01720	4	S281A601-3001 CONTROL UNIT-STANDBY POWER	233A5220 07217	1	24-31-11 P006-00/ /	YC031-YM670
M01721		606802-2 BLOWER-VACUUM	417A8620 81205	1	38-32-12 857/196/L050	YC001-YC030
M01721	1	645172-1 BLOWER-VACUUM	417A8620 81205	1	38-32-12 857/196/L050	YC031-YM670
M01721	2	606802-2 BLOWER-VACUUM	417A8620 81205	1	38-32-12 857/196/L050	YC031-YM670
M01721	3	645172-2 BLOWER-VACUUM	417A8620 81205	1	38-32-12 857/196/L050	YC031-YM670
M01722		1742F8 MDL-VACUUM WASTE LOGIC CONTROL	417A8680 81205	1	38-32-12 860/198/L13	YC001-YC018
M01722		1742F9 MDL-VACUUM WASTE LOGIC CONTROL	417A8680 59885	1	38-32-12 860/198/L13	YC019-YM670
M01724		066-50012-0101 VOR/MARKER BEACON RECEIVER-1	284A0410 27914	1	34-51-11 E001-02/ /	YC001-YC050
M01724		066-50012-0101 VOR/MARKER BEACON RECEIVER-1	284A0410 13499	1	34-51-11 E001-02/ /	YK901-YM670
M01725		066-50012-0101 VOR RECEIVER-2	284A0410 27914	1	34-51-21 E001-04/ /	YC001-YC050
M01725		066-50012-0101 VOR RECEIVER-2	284A0410 13499	1	34-51-21 E001-04/ /	YK901-YM670
M01726		SSPD-113-7 RF POWER DIVIDER-1	284A0847 13691	1	34-31-11 309/180/R021	ALL
M01727		SSPD-113-7 RF POWER DIVIDER-2	284A0847 13691	1	34-31-21 302/180/R020	ALL
M01731		066-50014-0101 RCVR-ADF 1	284A0430 27914	1	34-57-11 E003-01/ /	YC001-YC050
M01731		066-50014-0101 RCVR-ADF 1	284A0430 13499	1	34-57-11 E003-01/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section M01700

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01732	9	066-50014-0101 RCVR-ADF 2 (SB 34-2194)	284A0430 4V792	1	34-57-21 E003-01/ /	YC028-YC029
M01733		2041683-7507 ANT-ADF 1	284A0508 27914	1	34-57-11 694/ /R004	YC001-YC011
M01733		2041683-7507 ANT-ADF 1	284A0508	1	34-57-11 694/ /R004	YC017-YC050
M01733		2041683-7507 ANT-ADF 1	284A0508 13499	1	34-57-11 694/ /R004	YK901-YM670
M01734	9	2041683-7507 ANT-ADF 2 (SB 34-2194)	284A0508 4V792	1	34-57-21 / /	YC028-YC029
M01735		066-50007-0101 XCVR-RADIO ALTM-1	284A0430 27914	1	34-33-11 E003-01/ /	YC001-YC050
M01735		066-50007-0111 XCVR-RADIO ALTM-1	284A0430 4V792	1	34-33-11 E003-01/ /	YK901-YM670
M01736		066-50007-0101 XCVR-RADIO ALTM-2	284A0430 27914	1	34-33-21 E003-02/ /	YC001-YC050
M01736		066-50007-0111 XCVR-RADIO ALTM-2	284A0430 4V792	1	34-33-21 E003-02/ /	YK901-YM670
M01737		S67-2002-18 ANT-RADIO ALTM XMTR-1	284A0509 13691	1	34-33-11 450/148/0000	ALL
M01738		S67-2002-18 ANT-RADIO ALTM XMTR-2	284A0509 13691	1	34-33-21 390/148/0000	ALL
M01739		S67-2002-18 ANT-RADIO ALTM RCVR-1	284A0509 13691	1	34-33-11 430/148/0000	ALL
M01740		S67-2002-18 ANT-RADIO ALTM RCVR-2	284A0509 13691	1	34-33-21 410/148/0000	ALL
M01742		S283A305-101 POWER SUPPLY-WING TIP STROBE LT-RIGHT	284A0181 81205	1	33-44-12 727B/245/R634	ALL
M01743		S283A305-101 POWER SUPPLY-WING TIP STROBE LT-LEFT	284A0181 81205	1	33-44-12 727B/245/L634	ALL
M01744	1	60-4983-3 POWER SUPPLY-ANTI-COLLISION LT-UPPER	284A0122 81205	1	33-44-11 568/297/R031	ALL
M01745		S283A305-101 POWER SUPPLY-ANTI-COLLISION LT-LOWER	284A0161 81205	1	33-44-11 650/144/L027	ALL

EQUIPMENT LIST

D280A103

Section M01700

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01746		285A1200-1 ELECTRONICS UNIT-FLAP/SLAT	284A0410 81205	1	27-81-41 E001-01/ /	YC001-YK906
M01746		285A1200-2 ELECTRONICS UNIT-FLAP/SLAT	284A0410 81205	1	27-81-41 E001-01/ /	YK907-YM670
M01747	9	285A1010-4 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 81205	1	27-32-11 E003-02/ /	YC001-YC007
M01747		285A1010-2 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 81205	1	27-32-11 E003-02/ /	YC001-YC007
M01747		285A1010-4 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 81205	1	27-32-11 E003-02/ /	YC008-YC026
M01747		285A1010-6 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 81205	1	27-32-11 E003-02/ /	YC028-YC030, YK901
M01747		285A1010-7 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 89954	1	27-32-11 E003-02/ /	YC031-YC050, YK907-YK909, YL421-YL423
M01747		285A1010-6 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 89954	1	27-32-11 E003-02/ /	YK902-YK906
M01747		285A1010-9 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 89954	1	27-32-11 E003-02/ /	YK910-YL401, YL424-YL430
M01747		285A1010-107 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 89954	1	27-32-11 E003-02/ /	YM643
M01747		285A1010-109 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 89954	1	27-32-11 E003-02/ /	YM645-YM670
M01748	9	285A1010-6 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0732 81205	1	27-32-21 E003-02/ /	YC001-YC007
M01748		285A1010-2 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0430 81205	1	27-32-21 E003-02/ /	YC001-YC007
M01748		285A1010-4 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0732 81205	1	27-32-21 E003-02/ /	YC008-YC026
M01748		285A1010-6 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0732 81205	1	27-32-21 E003-02/ /	YC028-YC030, YK901
M01748		285A1010-7 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0732 89954	1	27-32-21 E003-02/ /	YC031-YC050, YK907-YK909, YL421-YL423

EQUIPMENT LIST

D280A103

Section M01700

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01748		285A1010-6 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0732 89954	1	27-32-21 E003-02/ /	YK902-YK906
M01748		285A1010-9 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0732 89954	1	27-32-21 E003-02/ /	YK910-YL401, YL424-YL430
M01748		285A1010-107 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0732 89954	1	27-32-21 E003-02/ /	YM643
M01748		285A1010-109 COMPUTER-STALL MANAGEMENT YAW DAMPER	284A0732 89954	1	27-32-21 E003-02/ /	YM645-YM670
M01749		S242A101-004 UNIT-AIR DATA INERTIAL REFERENCE LEFT	284A0450 65507	1	34-21-11 E005-02/ /	YC015-YC021
M01749		S242A101-005 UNIT-AIR DATA INERTIAL REFERENCE LEFT	284A0450 65507	1	34-21-11 E005-02/ /	YC022-YC026
M01749		S242A101-006 UNIT-AIR DATA INERTIAL REFERENCE-LEFT	284A0450 65507	1	34-21-11 E005-02/ /	YC028-YM670
M01749	1	S242A101-003 UNIT-AIR DATA INERTIAL REFERENCE LEFT	284A0450 65507	1	34-21-11 E005-02/ /	YC001-YC013
M01749	2	S242A101-002 UNIT-AIR DATA INERTIAL REFERENCE LEFT	284A0450 65507	1	34-21-11 E005-02/ /	YC001-YC013
M01750	1	S242W601-100 MDL-AIR DATA-L-PITOT	232A9103 81205	1	34-21-12 199.816/175/L013	ALL
M01750	2	S242W601-101 MDL-AIR DATA-L-PITOT	232A9103 81205	1	34-21-12 199.816/175/L013	ALL
M01751	1	S242W601-100 MDL-AIR DATA-L-STATIC	232A9402 81205	1	34-21-12 409.479/205/L035	ALL
M01751	2	S242W601-101 MDL-AIR DATA-L-STATIC	232A9402 81205	1	34-21-12 409.479/205/L035	ALL
M01752		S242A101-004 UNIT-AIR DATA INERTIAL REFERENCE RIGHT	284A0450 65507	1	34-21-11 E005-02/ /	YC015-YC021
M01752		S242A101-005 UNIT-AIR DATA INERTIAL REFERENCE RIGHT	284A0450 65507	1	34-21-11 E005-02/ /	YC022-YC026
M01752		S242A101-006 UNIT-AIR DATA INERTIAL REFERENCE-RIGHT	284A0450 65507	1	34-21-21 E005-02/ /	YC028-YM670
M01752	1	S242A101-003 UNIT-AIR DATA INERTIAL REFERENCE RIGHT	284A0450 65507	1	34-21-11 E005-02/ /	YC001-YC013

EQUIPMENT LIST

D280A103

Section M01700

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01752	2	S242A101-002 UNIT-AIR DATA INERTIAL REFERENCE RIGHT	284A0450 65507	1	34-21-11 E005-02/ /	YC001-YC013
M01753		S242W601-100 MDL-AIR DATA-R-PIT0T	232A9103 81205	1	34-21-22 200.618/177/R018	ALL
M01754		S242W601-100 MDL-AIR DATA-R-STATIC	232A9402 81205	1	34-21-22 430.415/205/R035	ALL
M01755	1	S332T100-27 APU UPPER FIRE DETECTOR ASSY	355A5200 81205	1	26-11-31 1095/246/L001	ALL
M01755	2	S332T100-45 APU UPPER FIRE DETECTOR ASSY	355A5200 81205	1	26-11-31 1095/246/L001	ALL
M01756	1	S332T100-28 APU LOWER FIRE DETECTOR ASSY	355A5200 81205	1	26-11-31 1145/231/L013	ALL
M01756	2	S332T100-46 APU LOWER FIRE DETECTOR ASSY	355A5200 81205	1	26-11-31 1145/231/L013	ALL
M01757		S332T100-29 ENGINE FAN UPPER FIRE DETECTOR ASSY	332A2500 81205	2	26-11-11 / /	YC001
M01757		S332T100-44 ENGINE FAN UPPER FIRE DETECTOR ASSY	332A2500 81205	2	26-11-11 / /	YC002-YM670
M01758		S332T100-30 ENGINE FAN LOWER FIRE DETECTOR ASSY	332A2500 81205	2	26-11-11 / /	ALL
M01759		S332T100-31 ENGINE CORE AFT FIRE DETECTOR ASSY	332A2500 81205	2	26-11-11 / /	YC001
M01759		S332T100-43 ENGINE CORE AFT FIRE DETECTOR ASSY	332A2500 81205	2	26-11-11 / /	YC002-YM670
M01760		S332T100-38 ENGINE CORE RIGHT DETECTOR ASSY	332A2500 81205	2	26-11-11 / /	ALL
M01761		35712-79 L ENG STRUT CAVITY FWD OVHT DET	312A2531 73168	1	26-12-11 NSTA 188/ /	ALL
M01762		35712-75 L ENG STRUT CAVITY AFT OVHT DET	218A3630 73168	1	26-12-11 OFSS-260/ /	ALL
M01763		35712-79 R ENG STRUT CAVITY FWD OVHT DET	312A2531 73168	1	26-12-11 TBD/ /	ALL
M01764		35712-75 R ENG STRUT CAIVTY AFT OVHT DET	218A3630 73168	1	26-12-11 OFSS 260/ /	ALL

EQUIPMENT LIST

D280A103

Section M01700

Page 6

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01766		254A1150-7 AUTOTHROTTLE SW PACK #1-L ENG (SEE YWD)	254A1110 81205	1	32-42-11 232/199/L001	YC001-YC007
M01766		254A1150-9 A/T SW PACK #1-L ENG (SEE YWD) (-800)	254A1110 81205	1	32-42-11 232/199/L001	YC008-YK912, YK918-YK919, YL401-YL428
M01766		254A1150-13 A/T SW PACK #1-L ENG (SEE YWD) (-800)	254A1110 81205	1	32-42-11 232/199/L001	YK913-YK917, YK920, YL429- YL430
M01766		254A1150-9 A/T SW PACK #1-L ENG (SEE YWD) (-700)	254A1110 81205	1	32-42-11 232/199/L001	YM643-YM652
M01767		254A1150-8 AUTOTHROTTLE SW PACK #2-R ENG (SEE YWE)	254A1110 81205	1	32-42-11 235/199/R004	YC001-YC007
M01767		254A1150-10 A/T SW PACK #2-R ENG (SEE YWE) (-800)	254A1110 81205	1	32-42-11 235/199/R004	YC008-YK912, YK918-YK919, YL401-YL428
M01767		254A1150-14 A/T SW PACK #2-R ENG (SEE YWE) (-800)	254A1110 81205	1	32-42-11 235/199/R004	YK913-YK917, YK920, YL429- YL430
M01767		254A1150-10 A/T SW PACK #2-R ENG (SEE YWE) (-700)	254A1110 81205	1	32-42-11 235/199/R004	YM643-YM652

EQUIPMENT LIST

D280A103

Section M01700

Page 7 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01808		S242A801-1100 CDS DEU 1	284A0430 58960	1	31-62-11 E003-01/ /	YC001-YK910, YL421-YL423, YM643
M01808		4081600-940 CDS DEU 1	284A0430 58960	1	31-62-11 E003-01/ /	YK911-YL401, YL424-YL430, YM645-YM670
M01809		S242A801-1100 CDS DEU 2	284A0430 58960	1	31-62-21 E003-01/ /	YC001-YK910, YL421-YL423, YM643
M01809		4081600-940 CDS DEU 2	284A0430 58960	1	31-62-21 E003-01/ /	YK911-YL401, YL424-YL430, YM645-YM670
M01810		PDM-60-500-72831 COAX SPLITTER 1-CDS	287A4103 12457	1	31-62-12 193/219/L007	ALL
M01811		PDM-60-500-72831 COAX SPLITTER 2-CDS	287A4103 12457	1	31-62-22 197/218/R007	ALL
M01812		PDM-60-500-72831 COAX SPLITTER 3-CDS	287A4103 12457	1	31-62-12 193/218/L007	ALL
M01813		PDM-60-500-72831 COAX SPLITTER 4-CDS	287A4103 12457	1	31-62-22 197/216/R007	ALL
M01818		VENDORSUPPLIEDSEEIPCFORP-NINFO ELECTRONIC ENGINE CONTROL	332A2000 1Z812	2	73-24-11 ENG/ /	ALL
M01819		S254N101-4 THRUST-LEVER-ANGLE RESOLVE ENG1 (737-800	254A1100 05088	1	73-21-21 P008-00/ /	YC001-YK912, YK918-YK919, YL401-YL429
M01819		S254N101-4 THRUST-LEVER-ANGLE RESOLVE ENG1 (737-700	254A1100 05088	1	73-21-21 P008-00/ /	YM643-YM652
M01820		VENDORSUPPLIEDSEEIPCFORP-NINFO BSV SWITCH ENG-1-2	332A2000 1Z812	2	73-25-11 ENG/ /	ALL
M01822		S254N101-4 THRUST-LEVER-ANGLE RESOLVE ENG2 (737-800	254A1100 05088	1	73-21-21 P008-00/ /	YC001-YK912, YK918-YK919, YL401-YL429
M01822		S254N101-4 THRUST-LEVER-ANGLE RESOLVE ENG2 (737-700	254A1100 05088	1	73-21-21 P008-00/ /	YM643-YM652

EQUIPMENT LIST

D280A103

Section M01800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01823		VENDORSUPPLIEDSEEIPCFORP-NINFO HYDROMECHANICAL UNIT ENG-1-2	332A2000 1Z812	2	73-25-11 ENG/ /	ALL
M01824		254A1290-1 ENG 1 START LEVER SWITCH MODULE	254A1290 81205	1	76-21-11 P008-00/ /	ALL
M01825		254A1290-2 ENG 2 START LEVER SWITCH MODULE	254A1210 81205	1	76-21-21 P008-00/ /	ALL
M01826		VENDORSUPPLIEDSEEIPCFORP-NINFO EEC ALTERNATOR	332A2000 12812	2	73-22-11 ENG/ /	ALL
M01827		S345A001-010 PROCESSOR UNIT-FUEL QUANTITY	284A0834 81205	1	28-41-11 228/182/R020	YC001-YC011
M01827		S345A001-012 PROCESSOR UNIT-FUEL QUANTITY	284A0834 81205	1	28-41-11 228/182/R020	YC012-YM670
M01828		S283A202-101 CONNECTING ASSY-TANK 1	288A1176 81205	1	28-41-11 / /	ALL
M01829		S283A202-101 CONNECTING ASSY-TANK 2	288A1274 81205	1	28-41-11 / /	ALL
M01830		S283A202-102 CONNECTING ASSY-CENTER TANK	288A1178 81205	1	28-41-11 666/185/L043	ALL
M01831		S251A302-1 STANDBY RUDDER PCU	251A3430 81205	0	27-24-11 / /	ALL
M01834		417N3810-114 ATT OXYGEN MODULE	411A3420 81205	4	35-21-12 MULTI/ /	YC001-YC050
M01834		417N3810-114 ATT OXYGEN MODULE	411A3420 81205	3	35-21-12 MULTI/ /	YK901-YL430
M01834		417N3810-114 ATT OXYGEN MODULE	411A3420 81205	2	35-21-12 MULTI/ /	YM643-YM670
M01836		S254A114-1 MTR-A/T SERVO 1	254A1110	1	22-31-31 / /	ALL
M01837		S254A114-1 MTR-ATT SERVO 2	254A1110	1	22-31-41 / /	ALL
M01838		S283U008-16 BALLAST-FLOUR LT ASSY	417A5460 81205	1	33-26-21 323/289/R021	ALL
M01839		417A5460-1 MDL-GALLEY LT	411A2212 81205	1	33-26-21 324/291/R023	YC001-YK909, YL421-YM651

EQUIPMENT LIST

D280A103

Section M01800

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01839		417A5460-9 MDL-GALLEY LT	411A2212 81205	1	33-26-21 324/291/R023	YK910-YL401, YM652-YM670
M01840		4042-10 MDL-FLUOR LAMP/BALLAST	411A3220 81205	4	33-22-12 MULTI/ /	YC001-YL426, YL429, YM652- YM670
M01840		4042-10 MDL-FLUOR LAMP/BALLAST-COOL WHITE	411A3220 81205	4	33-22-12 MULTI/ /	YL427-YL428, YL430
M01840		4041-10 MDL-FLUOR LAMP/BALLAST	411A3220 81205	4	33-22-12 MULTI/ /	YM643-YM651
M01841		4041-48 MDL-FLUOR LAMP/BALLAST	417A5420 81205	6	33-22-12 MULTI/ /	YC001-YL426, YL429, YM643- YM670
M01841		4041-48 MDL-FLUOR LAMP/BALLAST-COOL WHITE	417A5420 81205	6	33-22-12 MULTI/ /	YL427-YL428, YL430
M01842		S417N514-70 MDL-FLUOR LAMP/BALLAST	417A5420 81205	16	33-22-12 MULTI/ /	YC001-YC050
M01842		4041-70 MDL-FLUOR LAMP/BALLAST	417A5420 81205	16	33-22-12 MULTI/ /	YK901-YL426, YL429
M01842		4041-70 MDL-FLUOR LAMP/BALLAST-COOL WHITE	417A5420 81205	16	33-22-12 MULTI/ /	YL427-YL428, YL430
M01842		4041-70 MDL-FLUOR LAMP/BALLAST	417A5420 81205	12	33-22-12 MULTI/ /	YM643-YM670
M01843		S283U008-16 BALLAST-FLUOR LT ASSY	417A5475 81205	1	33-29-11 M01678/ /	ALL
M01848		HB115HL HTR BLANKET-BALL VALVE (60B44001-13)	417A8660 81205	1	30-71-11 868/179/L043	YC031-YK909, YL421-YL423, YM643
M01848		HBC115 HTR BLANKET-BALL VALVE (60B44001-13)	417A8660 81205	1	30-71-11 868/179/L043	YK910-YL401, YL424-YL430, YM645-YM670
M01848	1	HB015 HTR BLANKET-BALL VALVE (60B44001-13)	417A8660 81205	1	30-71-11 868/179/L043	YC001-YC030
M01848	2	HB115 HTR BLANKET-BALL VALVE (60B44001-13)	417A8660 81205	1	30-71-11 868/179/L043	YC001-YC030

EQUIPMENT LIST

D280A103

Section M01800

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01849		90234-7 HTR ASSY-FWD DRAIN MAST	417A2160 81205	1	30-71-11 526/150/R028	ALL
M01850		S351A401-261 MDL-APU START POWER UNIT	284A0420 81205	1	49-41-11 E002-02/ /	YC001-YC023
M01850		S351A401-265 MDL-APU START POWER UNIT	284A0420 81205	1	49-41-11 E002-02/ /	YC024-YM670
M01860		TA30700100 SPREADER CLAMP	286A1062 81205	1	24-21-11 TBD/ /	ALL
M01875		10-62038-7 FLIGHT CONTROL COMPUTER - A	284A0410 81205	1	22-11-11 E001-01/ /	YC001-YC019
M01875		10-62038-8 FLIGHT CONTROL COMPUTER - A	284A0410 81205	1	22-11-11 E001-01/ /	YC020-YC030
M01875		822-1604-101 FLIGHT CONTROL COMPUTER - A	284A0410 81205	1	22-11-11 E001-01/ /	YC031-YK920, YM643-YM646
M01875		822-1604-151 FLIGHT CONTROL COMPUTER - A	284A0410 81205	1	22-11-11 E001-01/ /	YL401-YL430, YM647-YM670
M01876		10-62038-7 FLIGHT CONTROL COMPUTER - B	284A0410 81205	1	22-11-11 E001-04/ /	YC001-YC019
M01876		10-62038-8 FLIGHT CONTROL COMPUTER - B	284A0410 81205	1	22-11-11 E001-04/ /	YC020-YC030
M01876		822-1604-101 FLIGHT CONTROL COMPUTER - B	284A0410 81205	1	22-11-11 E001-04/ /	YC031-YK909, YK911-YK917, YK919-YK920, YL421-YM646
M01876		822-1604-102 FLIGHT CONTROL COMPUTER - B	284A0410 81205	1	22-11-11 E001-04/ /	YK910, YK918
M01876		822-1604-151 FLIGHT CONTROL COMPUTER - B	284A0410 81205	1	22-11-11 E001-04/ /	YL401, YM647- YM670
M01883		285A1780-5 INTEGRATED HANDSET CONTROL (FWD)	417A6110 81205	1	23-42-12 LAV-A/ /	YC001-YC013
M01883		285A1780-10 INTEGRATED HANDSET CONTROL (FWD)	417A6110 81205	1	23-42-12 LAV-A/ /	YC015-YM670
M01884		285A1780-5 INTEGRATED HANDSET CONTROL (AFT)	417A6110 81205	1	23-42-12 LAV-D/ /	YC001-YC013

EQUIPMENT LIST

D280A103

Section M01800

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01884		285A1780-10 INTEGRATED HANDSET CONTROL (AFT)	417A6110 81205	1	23-42-12 LAV-D/ /	YC015-YM670
M01885		S417A150-3 MDL-FWD LIGHTING (SEE YAD)	417A6110 81205	1	33-29-11 P013-00/ /	ALL
M01886		S417A150-4 MDL-AFT LIGHTING (SEE YAE)	417A6110 81205	1	33-29-11 P014-00/ /	ALL
M01887		285A1720-1 MDL-POTABLE WATER	417A6100 81205	1	38-41-11 P014-00/ /	ALL
M01888		S417A150-6 MDL-VACUUM WASTE SYSTEM	417A6100 81205	1	38-32-13 P014-00/ /	ALL
M01891		285A1760-2 AUDIO ENTERTAINMENT MODULE	417A6100 81205	1	23-34-01 P013-00/ /	YC001-YC050
M01891		285A1760-6 AUDIO ENTERTAINMENT MODULE	417A6100 81205	1	23-34-01 P013-00/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section M01800
Page 5 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01904		IN5618 DIODE-FWD ATTENDANT	233A3208	0	23-42-11 / /	YC001-YC050
M01905		IN5618 DIODE-AFT ATTENDANT	286ATBD	0	23-42-11 / /	YC001-YC050
M01906		79290-0351 HTR-HEATED HOSE, POTABLE WATER FILL	417A2515 81205	1	30-71-11 923/173/R014	ALL
M01907		4E3206-13 HTR-HEATED HOSE GRAY WATER DRAIN	417A2521 81205	1	30-71-11 949/178/R002	ALL
M01908		129-6-M06 COAX CONN TEE	284A0410 91836	1	34-45-31 / /	YC001-YC050
M01908		129-6-M06 COAX CONN TEE	284A0410 91836	1	34-53-31 / /	YK901-YM670
M01909		35712-80 LEFT MID A/C PACK OVHT DET	218A3112 73168	1	26-12-11 603/156/L007	ALL
M01910		35712-80 RIGHT MID A/C PACK OVHT DET	218A3112 73168	1	26-12-11 604/158/R007	YC001-YL430
M01910		35712-80 RIGHT MID A/C PACK OVHT DET	218A3112 73168	1	26-12-11 604/156/R007	YM643-YM670
M01911		35712-80 LEFT AFT A/C PACK OVHT DET	218A3112 73168	1	26-12-11 660/159/L016	ALL
M01912		35712-80 RIGHT AFT A/C PACK OVHT DET	218A3112 73168	1	26-12-11 660/159/R016	ALL
M01915		S210N701-43 SENSOR-EQUIP COOLING LOW FLOW	217A1001 54813	1	21-27-31 213/191/R025	ALL
M01916		S283W802-2 UNIT-DIMMER CONTROL, CAPT/CTR PNL FLOOD	233A2110 21862	1	33-14-11 P009-00/ /	ALL
M01917		S283W802-2 UNIT-DIMMER CONTROL, GLARSHIELD FLOOD	233A2110 21862	1	33-14-11 P009-00/ /	ALL
M01918		4E3205-12 HEATER CUFF,GRAY WATER DRAIN VALVE	417A2521 81205	1	30-71-11 949/176/0000	ALL
M01919		300-007-566-MB HTR-POTABLE FILL FITTING	417A2515 81205	1	30-71-11 920/172/R013	ALL
M01920		S417A204-1051 HTR-HEATED HOSE, AFT WTR FRM TANK (-800)	417A2410 81205	1	30-71-11 957/179/L001	YC001-YC007, YC050

EQUIPMENT LIST

D280A103

Section M01900

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01920		79290-2051 HTR-HEATED HOSE, AFT WTR FRM TANK (-800)	417A2410 81205	1	30-71-11 957/179/L001	YC008-YC049, YK901-YK912, YK918, YL401- YL426
M01920		79290-2051 HTR-HEATED HOSE, AFT WTR FRM TANK(-700)	417A2410 81205	1	30-71-11 957/179/L001	YM643-YM651
M01922		CH017 HTR-WASTE SYSTEM RINSE FITTING LINE	417A8640 81205	1	30-71-11 868/177/L010	ALL
M01923		4041-58 MDL-FLUOR LAMP/BALLAST	417A5420 81205	2	33-22-12 MULTI/ /	YC001-YL426, YL429
M01923		4041-58 MDL-FLUOR LAMP/BALLAST-COOL WHITE	417A5420 81205	2	33-22-12 MULTI/ /	YL427-YL428, YL430
M01925	1	S332T100-42 APU TAILPIPE OVERHEAT DETECTOR ASSY	335A5200 81205	1	26-11-31 1156/250/R009	YC001-YK909, YL401-YL430
M01925	1	S332T100-42 APU TAILPIPE OVERHEAT DETECTOR ASSY	355A5200 81205	1	26-11-31 1156/250/R009	YK910-YK920, YM643-YM670
M01925	2	S332T100-47 APU TAILPIPE OVERHEAT DETECTOR ASSY	335A5200 81205	1	26-11-31 1156/250/R009	YC001-YK909, YL401-YL430
M01925	2	S332T100-47 APU TAILPIPE OVERHEAT DETECTOR ASSY	355A5200 81205	1	26-11-31 1156/250/R009	YK910-YK920, YM643-YM670
M01934		700-2200-001 VDU-1	417N7380 97896	1	23-32-31 430/295/L035	YC001-YC050
M01934		700-2200-001 VDU-1	417A7663 97896	1	23-32-31 450/295/L035	YK901-YM670
M01935		700-2200-001 VDU-2	417N7380 97896	1	23-32-32 430/295/L035	YC001-YC050
M01935		700-2200-001 VDU-2	417A7663 97896	1	23-32-32 450/295/L035	YK901-YM670
M01936		700-2200-001 VDU-3	417A7663 97896	1	23-32-33 450/295/L035	YM643-YM670
M01937		RD-AV4002-10 VDU-4 (PROV)	417A7662 54473	1	23-32-34 450/295/L035	YM643-YM670
M01938		700-2200-001 VDU-5	417N7380 97896	1	23-32-41 550/295/L035	YC001-YC050

EQUIPMENT LIST

D280A103

Section M01900

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01938		700-2200-001 VDU-5	417A7663 97896	1	23-32-41 500F+10/295/L035	YK901-YL430
M01938		700-2200-001 VDU-5	417A7663 97896	1	23-32-41 550/295/L035	YM643-YM670
M01939		700-2200-001 VDU-6	417A7380 97896	1	23-32-42 550/295/L035	YC001-YC050
M01939		700-2200-001 VDU-6	417A7663 97896	1	23-32-42 500F+10/295/L035	YK901-YL430
M01939		700-2200-001 VDU-6	417A7663 97896	1	23-32-42 550/295/L035	YM643-YM670
M01940		700-2200-001 VDU-7	417N7380 97896	1	23-32-43 550/295/L035	YC001-YC050
M01940		700-2200-001 VDU-7	417A7663 97896	1	23-32-43 500F+10/295/L035	YK901-YL430
M01942		700-2200-001 VDU-9	417N7380 97896	1	23-32-51 710/295/L035	YC001-YC050
M01942		700-2200-001 VDU-9	417A7663 97896	1	23-32-51 695/295/L035	YK901-YL430
M01942		700-2200-001 VDU-9	417A7663 97896	1	23-32-51 710/295/L035	YM643-YM670
M01943		700-2200-001 VDU-10	417N7380 97896	1	23-32-52 710/295/L035	YC001-YC050
M01943		700-2200-001 VDU-10	417A7663 97896	1	23-32-52 695/295/L035	YK901-YL430
M01943		700-2200-001 VDU-10	417A7663 97896	1	23-32-52 710/295/L035	YM643-YM670
M01944		700-2200-001 VDU-11	417N7380 97896	1	23-32-53 710/295/L035	YC001-YC050
M01944		700-2200-001 VDU-11	417A7662 54473	1	23-32-53 695/295/L035	YK901-YL430
M01946		700-2200-001 VDU-13	417N7380 97896	1	23-32-61 777/295/L035	YC001-YC050
M01946		700-2200-001 VDU-13	417A7663 97896	1	23-32-61 727J+10/295/L035	YK901-YL430

EQUIPMENT LIST

D280A103

Section M01900

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01946		700-2200-001 VDU-13	417A7663 97896	1	23-32-61 777/295/L035	YM643-YM670
M01947		700-2200-001 VDU-14	417N7380 97896	1	23-32-62 777/295/L035	YC001-YC050
M01947		700-2200-001 VDU-14	417A7663 97896	1	23-32-62 727J+10/295/L035	YK901-YL430
M01947		700-2200-001 VDU-14	417A7663 97896	1	23-32-62 777/295/L035	YM643-YM670
M01948		700-2200-001 VDU-15	417N7380 97896	1	23-32-63 727J/295/L035	YC001-YC050
M01951		3100-101-6 THERMOSTAT-HEATED HOSE FWD-1 AMPERE	417A2140 81205	1	30-71-11 527/151/R030	ALL
M01952		273A3301-1 MDL-LANDING GEAR CONTROL LEVER	273A3300 81205	1	32-64-11 P002-03/ /	ALL
M01955		980-9900-001 AUDIO ENTERTAINMENT PLAYER	284A0430 97896	1	23-34-01 E003-02/ /	ALL
M01956		743-0288-001 MULTIPLEXER	284A0440 97896	1	23-34-01 E004-02/ /	YC001-YC050
M01956		743-0301-002 MULTIPLEXER	284A0431 97896	1	23-34-01 E004-02/ /	YK901-YM670
M01957		S283W008-3 BATTERY AND CHARGER SYSTEM	232A4214 81205	1	28-21-21 P006-00/ /	ALL
M01966		980-9903-007 TAPE REPRODUCER-PRE-REC ANNOUNCEMENT	284A0480 97896	1	23-31-06 E008-00/ /	YC001-YC050
M01967		253T4015-7 SNSR-F/O CONTROL WHEEL POSITION	251A1806 81205	1	31-31-14 215/180/R020	ALL
M01971		S417A204-352 HTR-HEATED HOSE, AFT WTR BETW JCT(-800)	417A2410 81205	1	30-71-11 968/198/R030	YC001-YC007, YC050
M01971		79290-1503 HTR-HEATED HOSE, AFT WTR BETW JCT(-800)	417A2410 81205	1	30-71-11 968/198/R030	YC008-YC049, YK901-YK912, YK918, YL401- YL426
M01971		79290-1503 HTR-HEATED HOSE, AFT WTR BETW JCT (-700)	417A2410 81205	1	30-71-11 968/198/R030	YM643-YM651

EQUIPMENT LIST

D280A103

Section M01900

Page 4

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01972		S417A204-1201 HTR-HEATED HOSE, WTR TO GALLEY 4 (-800)	417A2410 81205	1	30-71-11 1002/207/R044	YC001-YC007, YC050
M01972		79290-2001 HTR-HEATED HOSE, WTR TO GALLEY 4 (-800)	417A2410 81205	1	30-71-11 1002/207/R044	YC008-YC049, YK901-YK912, YK918, YL401- YL426
M01972		79290-2001 HTR-HEATED HOSE, WTR TO GALLEY 4 (-700)	417A2410 81205	1	30-71-11 1002/207/R044	YM643-YM651
M01980		79290-1952 HEATED HOSE, G6/LAV D	417A2410 81205	1	30-71-11 932/207/L059	YC008-YM670
M01980	1	79290-1156 HEATED HOSE, G6/LAV D	417A2410 81205	1	30-71-11 932/207/L059	YC001-YC007
M01980	2	79290-1157 HEATED HOSE, G6/LAV D	417A2410 81205	1	30-71-11 932/207/L059	YC001-YC007
M01981		79290-1157 HEATED HOSE, GALLEY 3/LAV E	417A2410 81205	1	30-71-11 942/207/R062	YC001-YC007
M01981		79290-1952 HEATED HOSE, GALLEY 3/LAV E	417A2410 81205	1	30-71-11 942/207/R062	YC008-YM670
M01983		251A4410-1 MDL-CAPTAIN COLUMN SWITCHING	251A4400 81205	1	27-41-11 228/202/L011	ALL
M01987		RBDSC-2 DIP SWITCH-AIR TRAFFIC CONTROL 1	284A2710 09922	1	34-53-11 E001-03/ /	ALL
M01987S1		SWITCH1-24 DIP SWITCH		1	34-53-11 E001-03/ /	ALL
M01988		RBDSC-2 DIP SWITCH-AIR TRAFFIC CONTROL 2	284A2710 09922	1	34-53-21 E001-03/ /	ALL
M01988S2		SWITCH1-24 DIP SWITCH		1	34-53-21 E001-03/ /	ALL
M01989		RBDSC-2 DIP SWITCH - GPWS	284A2710	1	34-49-11 E001-01/ /	YC001-YC007
M01990		RBDSC-2 DIP SWITCH ASSY	284A1225	0	34-61-19 P059-00/ /	ALL
M01990S1		SWITCH1-24 FMC DIP SWITCH		1	34-61-19 P059-00/ /	ALL

EQUIPMENT LIST

D280A103

Section M01900

Page 5

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01991		RBDSC-2 DIP SWITCH ASSY	284A1225	0	34-61-19 P059-00/ /	ALL
M01991S2		SWITCH1-24 FMC DIP SWITCH		1	34-61-19 P059-00/ /	ALL
M01992		RBDSC-2 MDL-PROGRAM SWITCH AUTOPILOT SYS A	284A2710 09922	0	22-11-75 E001-01/ /	YC001-YC030
M01992		RBDSC-2 MDL-PROGRAM SWITCH AUTOPILOT SYS A-1	284A2710 09922	0	22-11-75 E001-01/ /	YC031-YM670
M01992S2		SWITCH1-24 A/P SYS A DIP SW		1	22-11-75 E001-01/ /	ALL
M01993		RBDSC-2 MDL-PROGRAM SWITCH AUTOPILOT SYS B	284A2710 09922	0	22-11-75 E001-01/ /	YC001-YC030
M01993		RBDSC-2 MDL-PROGRAM SWITCH AUTOPILOT SYS B-1	284A2710 09922	0	22-11-75 E001-01/ /	YC031-YM670
M01993S3		SWITCH1-24 A/P SYS B DIP SW		1	22-11-75 E001-01/ /	ALL
M01994		RBDSC-2 MDL-PROGRAM SWITCH AUTOTHROTTLE	284A2710 09922	0	22-31-11 E001-01/ /	YC001-YC030
M01994S4		SWITCH1-24 A/T DIP SW		1	22-31-11 E001-01/ /	YC001-YC030
M01995		RBDSC-2 SELCAL SWITCH	284A2740 81295	1	23-22-11 E004-01/ /	ALL
M01995S1		SWITCH1-24 DIP SWITCH		1	23-22-11 E004-01/ /	ALL
M01996		RBDSC-2 SW-FDRS AIRPLANE ID CONFIGURATION	284A2730 09922	1	31-31-16 E003-02/ /	ALL
M01996S1		SWITCH1-24 DIP SWITCH		1	31-31-16 E003-02/ /	ALL
M01997		RBDSC-2 DIP SW - AIRLINE REGISTRY	284A2730 81295	1	23-27-16 E003-03/ /	YC001-YC050
M01997S1		SWITCH1-24 DIP SWITCH		1	23-27-16 E003-03/ /	YC001-YC050
M01998		RBDSC-2 DIP SW - AIRLINE REGISTRY	284A2730 81295	1	23-27-16 E003-03/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section M01900

Page 6

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01998S2		SWITCH1-24 DIP SWITCH		1	23-27-16 E003-03/ /	YC001-YC050
M01999		RBDSC-2 DIP SW - AIRLINE REGISTRY	284A2730 81295	1	23-27-16 E003-03/ /	YC001-YC050
M01999S3		SWITCH1-24 DIP SWITCH		1	23-27-16 E003-03/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section M01900
Page 7 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02001		1303910-101 MONITOR-1	417A3100 97896	1	23-32-31 377/270/L042	YK901-YL430
M02001		1303910-101 MONITOR-1	417A3100 97896	1	23-32-31 357.5/270/L042	YM643-YM670
M02002		1303910-100 MONITOR-2	417A3100 97896	1	23-32-31 358/270/R042	YK901-YL430
M02002		1303910-100 MONITOR-2	417A3100 97896	1	23-32-31 357.5/270/R042	YM643-YM670
M02003		617-6265-001 MONITOR-3	417A3100 97896	1	23-32-31 385/270/L032	YC001-YC007
M02003		617-6265-001 MONITOR-3	417A3100 97896	1	23-32-31 376/270/L032	YC008-YC050
M02003		1303910-101 MONITOR-3	417A3100 97896	1	23-32-32 487/270/L042	YK901-YL430
M02003		1303910-101 MONITOR-3	417A3100 97896	1	23-32-32 426.5/270/L042	YM643-YM670
M02004		617-6265-002 MONITOR-4	417A3100 97896	1	23-32-31 385/270/R032	YC001-YC007
M02004		617-6265-002 MONITOR-4	417A3100 97896	1	23-32-31 376/270/R032	YC008-YC050
M02004		1303910-100 MONITOR-4	417A3100 97896	1	23-32-32 478/270/R042	YK901-YL430
M02004		1303910-100 MONITOR-4	417A3100 97896	1	23-32-32 426.5/270/R042	YM643-YM670
M02005		617-6265-001 MONITOR-5	417A3100 97896	1	23-32-32 478/270/L032	YC001-YC050
M02005		1303910-101 MONITOR-5	417A3100 97896	1	23-32-33 484.5/270/L042	YM643-YM670
M02006		617-6265-002 MONITOR-6	417A3100 97896	1	23-32-32 478/270/R032	YC001-YC050
M02006		1303910-100 MONITOR-6	417A3100 97896	1	23-32-33 484.5/270/R042	YM643-YM670
M02009		617-6265-001 MONITOR-9	417A3100 97896	1	23-32-41 500C/270/R032	YC001-YC050

EQUIPMENT LIST

D280A103

Section M02000

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02009		1303910-101 MONITOR-9	417A3100 97896	1	23-32-41 500C+8/270/L042	YK901-YL430
M02009		1303910-101 MONITOR-9	417A3100 97896	1	23-32-41 500C+11/270/L042	YM643-YM670
M02010		617-6265-002 MONITOR-10	417A3100 97896	1	23-32-41 500C/270/R032	YC001-YC050
M02010		1303910-100 MONITOR-10	417A3100 97896	1	23-32-41 500C+2/270/R042	YK901-YL430
M02010		1303910-100 MONITOR-10	417A3100 97896	1	23-32-41 500C+11/270/R042	YM643-YM670
M02011		617-6265-001 MONITOR-11	417A3100 97896	1	23-32-42 500G/270/L032	YC001-YC050
M02011		1303910-101 MONITOR-11	417A3100 97896	1	23-32-42 500G+7/270/L042	YK901-YL430
M02011		1303910-101 MONITOR-11	417A3100 97896	1	23-32-42 578.5/270/L042	YM643-YM670
M02012		617-6265-002 MONITOR-12	417A3100 97896	1	23-32-42 500G/270/R043	YC001-YC050
M02012		1303910-100 MONITOR-12	417A3100 97896	1	23-32-42 500G+4/270/R042	YK901-YL430
M02012		1303910-100 MONITOR-12	417A3100 97896	1	23-32-42 578.5/270/R042	YM643-YM670
M02013		1303910-101 MONITOR-13	417A3100 97896	1	23-32-43 550/270/L042	YK901-YL430
M02014		1303910-100 MONITOR-14	417A3100 97896	1	23-32-43 550/270/R042	YK901-YL430
M02015		617-6265-001 MONITOR-15	417A3100 97896	1	23-32-43 550/270/L032	YC001-YC050
M02016		617-6265-002 MONITOR-16	417A3100 97896	1	23-32-43 550/270/R043	YC001-YC050
M02017		617-6265-001 MONITOR-17	417A3100 97896	1	23-32-51 679/270/L032	YC001-YC050
M02017		1303910-101 MONITOR-17	417A3100 97896	1	23-32-51 657/270/L042	YK901-YL430

EQUIPMENT LIST

D280A103

Section M02000

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02017		1303910-101 MONITOR-17	417A3100 97896	1	23-32-51 669.5/270/L042	YM643-YM670
M02018		617-6265-002 MONITOR-18	417A3100 97896	1	23-32-51 679/270/R032	YC001-YC050
M02018		1303910-100 MONITOR-18	417A3100 97896	1	23-32-51 657/270/R042	YK901-YL430
M02018		1303910-100 MONITOR-18	417A3100 97896	1	23-32-51 669.5/270/R042	YM643-YM670
M02019		1303910-101 MONITOR-19	417A3100 97896	1	23-32-52 727+17/270/L042	YK901-YL430
M02019		1303910-101 MONITOR-19	417A3100 97896	1	23-32-52 727A+9/270/L042	YM643-YM670
M02020		1303910-100 MONITOR-20	417A3100 97896	1	23-32-52 727+17/270/R042	YK901-YL430
M02020		1303910-100 MONITOR-20	417A3100 97896	1	23-32-52 727A+9/270/R042	YM643-YM670
M02021		617-6265-001 MONITOR-21	417A3100 97896	1	23-32-52 727B+3/270/L032	YC001-YC050
M02021		1303910-101 MONITOR-21	417A3100 97896	1	23-32-53 727D+22/270/L042	YK901-YL430
M02022		617-6265-002 MONITOR-22	417A3100 97896	1	23-32-52 727B+3/270/R032	YC001-YC050
M02022		1303910-100 MONITOR-22	417A3100 97896	1	23-32-53 727D+22/270/R042	YK901-YL430
M02023		617-6265-001 MONITOR-23	417A3100 97896	1	23-32-53 727F+7/270/L032	YC001-YC050
M02024		617-6265-002 MONITOR-24	417A3100 97896	1	23-32-53 727F+7/270/R043	YC001-YC050
M02025		1303910-101 MONITOR-25	417A3100 97896	1	23-32-61 727I+2/270/L042	YK901-YL430
M02025		1303910-101 MONITOR-25	417A3100 97896	1	23-32-61 743.5/270/L042	YM643-YM670
M02026		1303910-100 MONITOR-26	417A3100 97896	1	23-32-61 727I+2/270/R042	YK901-YL430

EQUIPMENT LIST

D280A103

Section M02000

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02026		1303910-100 MONITOR-26	417A3100 97896	1	23-32-61 743.5/270/R042	YM643-YM670
M02027		617-6265-001 MONITOR-27	417A3100 97896	1	23-32-61 727J+11/270/L032	YC001-YC050
M02027		1303910-101 MONITOR-27	417A3100 97896	1	23-32-62 799/270/L042	YK901-YL430
M02027		1303910-101 MONITOR-27	417A3100 97896	1	23-32-62 830.5/270/L042	YM643-YM670
M02028		617-6265-002 MONITOR-28	417A3100 97896	1	23-32-61 727J+11/270/R032	YC001-YC050
M02028		1303910-100 MONITOR-28	417A3100 97896	1	23-32-62 799/270/R042	YK901-YL430
M02028		1303910-100 MONITOR-28	417A3100 97896	1	23-32-62 830.5/270/R042	YM643-YM670
M02029		617-6265-001 MONITOR-29	417A3100 97896	1	23-32-62 828/270/L032	YC001-YC050
M02030		617-6265-002 MONITOR-30	417A3100 97896	1	23-32-62 828/270/R043	YC001-YC050
M02033	1	TD-1982-3001 MDL-AUTO SPEED BRAKE WARN TIME DELAY	284A1203 08719	1	27-62-11 J020-00/ /	ALL
M02033	2	10167-3001-BT MDL-AUTO SPEED BRAKE WARN TIME DELAY	284A1203 08719	1	27-62-11 J020-00/ /	ALL
M02039		RD-AM8131-11 BITE PANEL (PROV)	417A6700 54473	1	23-34-02 984/284/R036	YK901-YM670
M02040		611-6052 COAX ASSY-ELT ANTENNA (406 MHZ)	60253	1	23-24-11 797/300/L005	ALL
M02047		700-1516-002 TERM PLUG FWD	417N7380 97896	1	23-32-63 550/295/L035	YC001-YC050
M02047		700-1516-002 TERM PLUG FWD	417A7663 97896	1	23-32-43 500F+10/295/L035	YK901-YL430
M02047		700-1516-002 TERM PLUG FWD	417A7663 97896	1	23-32-43 550/295/L035	YM643-YM670
M02048		700-1516-002 TERM PLUG AFT	417N7380 97896	1	23-32-62 777/295/L035	YC001-YC050

EQUIPMENT LIST

D280A103

Section M02000

Page 4

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02048		700-1516-002 TERM PLUG AFT	417A7663 97896	1	23-32-63 727J+10/295/L035	YK901-YL430
M02048		700-1516-002 TERM PLUG AFT	417A7663 97896	1	23-32-63 777/295/L035	YM643-YM670
M02061		285A1600-2 MDL-PSEU	284A0200 81205	1	32-64-11 212/180/R020	YC001-YC011
M02061		285A1600-3 MDL-PSEU	284A0200 81205	1	32-64-11 212/180/R020	YC012-YC026
M02061		285A1600-4 MDL-PSEU	284A0200 81205	1	32-64-11 212/180/R020	YC028-YC030, YK901-YK906
M02061		285A1600-5 MDL-PSEU	284A0200 89954	1	32-64-11 212/180/R020	YC031-YC050, YK907-YL430
M02061		285A1600-5- MDL-PSEU	284A0200 89954	1	32-64-11 212/180/R020	YM643-YM670
M02065		743-0315-002 VIDEO SYSTEM CONTROL UNIT	417A7360 97896	1	23-32-11 / /	YC001-YC050
M02065		743-0315-006 VIDEO SYSTEM CONTROL UNIT	417A7360 97896	1	23-32-11 880/ /	YK901-YM670
M02066		743-0293-001 VEP-1	417A7360 97896	1	23-32-11 / /	YC001-YC022
M02066		743-0304-001 VEP-1	417A7360 97896	1	23-32-11 / /	YC023-YC050, YM643-YM670
M02066		743-0304-001 VEP-1	417A7360 97896	1	23-32-11 VCC/ /	YK901-YL430
M02067		743-0293-001 VEP-2	417A7360 97896	1	23-32-11 / /	YC001-YC022
M02067		743-0304-001 VEP-2	417A7360 97896	1	23-32-11 / /	YC023-YC050
M02088		69-78190-1 ENTERTAINMENT PANEL	233A3101 81205	1	23-32-12 P005-00/ /	YC001-YC050
M02088		69-78190-1 VIDEO ON LIGHT-ENT. PANEL	233A3101	0	23-32-12 / /	YK901-YL430

EQUIPMENT LIST

D280A103

Section M02000

Page 5 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02100		312BS101-1 DEDICATED BATTERY/CHARGER	284A0411 31467	1	34-24-15 E004-01/ /	YK901-YM670
M02102		S242T104-102 ANT-GLOBAL POSITIONING SYSTEM 2	284A0516 159840	1	34-58-21 500A/316/R005	ALL
M02103		S242T104-102 ANT-GLOBAL POSITIONING SYSTEM 1	284A0516 159840	1	34-58-11 500A/316/L005	ALL
M02104		822-1152-001 MMR-1	284A0410 13499	1	34-31-11 E001-02/ /	YC001-YC007
M02104		066-50029-1101 MMR-1	284A0410 27914	1	34-31-11 E001-02/ /	YC008-YC050
M02104		066-50029-1201 MMR-1	284A0410 13499	1	34-31-11 E001-02/ /	YK901-YK906, YK908-YM670
M02104		822-1821-330 MMR-1	284A0410 13499	1	34-31-11 E001-02/ /	YK907
M02105		822-1152-001 MMR-2	284A0410 13499	1	34-31-21 E001-04/ /	YC001-YC007
M02105		066-50029-1101 MMR-2	284A0410 27914	1	34-31-21 E001-04/ /	YC008-YC050
M02105		066-50029-1201 MMR-2	284A0410 13499	1	34-31-21 E001-04/ /	YK901-YK906, YK908-YM670
M02105		822-1821-330 MMR-2	284A0410 13499	1	34-31-21 E001-04/ /	YK907
M02114		453-6501 INTERFACE UNIT-ELT/NAV (PROG AND POSITN)	284A0513 60253	1	23-24-11 794/301/L010	YK901-YM670
M02115		RBDSC-2 MODULE-PROGRAMMABLE SWITCH, ELT	284A0513 09922	1	23-24-11 794/300/L015	ALL
M02115S1		SWITCH1-24 DIP SWITCH		1	23-24-11 794/ /	YK901-YM670
M02127		965-0758-002 COMM MANAGEMENT UNIT - CMU	284A0430 97896	1	23-27-31 E004-01/ /	YK901-YL422, YL424-YM670
M02174		S411N110-5 R AFT OVERWING DOOR LINING HEATER FWD	411A2710	1	21-42-11 617/251/R066	ALL
M02175		10-60911-74 R AFT CLOSE OUT PANEL HEATER	411A2819	1	21-42-11 627/222/R067	ALL

EQUIPMENT LIST

D280A103

Section M02100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02176		S411N110-5 L AFT OVERWING DOOR LINING HEATER FWD	411A2710	1	21-42-11 617/251/L066	ALL
M02177		10-60911-74 L AFT CLOSE OUT PANEL HEATER	411A2819	1	21-42-11 627/222/L067	ALL
M02178		S411N110-5 RIGHT FWD HATCH DOOR HEATER	411A2701	1	21-42-11 579/251/R066	YC003-YL430
M02179		10-60911-74 RIGHT FWD CLOSE OUT PANEL HEATER	411A2819	1	21-42-11 591/224/R068	YC001-YL430
M02182		S411N110-5 LEFT FWD HATCH DOOR HEATER	411A2710	1	21-42-11 579/251/L066	YC003-YL430
M02183		10-60911-74 LEFT FWD CLOSE OUT PANEL HEATER	411A2819	1	21-42-11 583/224/L068	YC001-YL430
M02186		S283W802-2 UNIT-DIMMER CONTROL-F/O PNL FLOOD	233A2110 21862	1	33-14-11 / /	ALL
M02195		8055515-4507 PRINTER-ACMS ARINC 740	233A6101 97896	1	31-33-01 P008-54/ /	ALL

EQUIPMENT LIST

D280A103

Section M02100
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02201		S411N110-5 R AFT OVERWING DOOR LINING HEATER AFT	411A2701	1	21-42-11 638/251/R066	ALL
M02202		S411N110-5 R AFT OVERWING DOOR TRIM HEATER FWD	411A2701	1	21-42-11 581/229/R069	ALL
M02203		S411N110-5 R AFT OVERWING DOOR TRIM HEATER AFT	411A2701	1	21-42-11 598/229/R069	ALL
M02204		S411N110-5 L AFT OVERWING DOOR LINING HEATER AFT	411A2701	1	21-42-11 638/251/L066	ALL
M02205		S411N110-5 L AFT OVERWING DOOR TRIM HEATER FWD	411A2701	1	21-42-11 581/229/L069	ALL
M02206		S411N110-5 L AFT OVERWING DOOR TRIM HEATER AFT	411A2701	1	21-42-11 639/229/L069	YC001-YL430
M02206		S411N110-5 L AFT OVERWING DOOR TRIM HEATER AFT	411A2701	1	21-42-11 598/229/L069	YM643-YM670
M02207		S411N110-5 R FWD HATCH DR LINING HTR AFT	411A2701	1	21-42-11 600/251/R066	YC001-YL430
M02208		S411N110-5 R FWD HATCH DR TRIM HTR FWD	411A2701	1	21-42-11 543/229/R069	YC001-YL430
M02209		S411N110-5 R FWD HATCH DR TRIM HTR AFT	411A2701	1	21-42-11 560/229/R069	YC001-YL430
M02213		S411N110-5 L FWD HATCH DR LINING HTR AFT	411A2701	1	21-42-11 600/251/L066	YC001-YL430
M02214		S411N110-5 L FWD OVERWING DR TRIM HTR FWD	411A2701	1	21-42-11 543/229/L069	YC001-YL430
M02215		S411N110-5 L FWD OVERWING DR TRIM HTR AFT	411A2701	1	21-42-11 560/229/L069	YC001-YL430
M02219		A420-066923-01 SOL-OVERWING FLIGHT LOCK-LEFT	258A4701	1	52-71-13 633/256/L068	YC001-YC020
M02219		A420-066923-02 SOL-OVERWING FLIGHT LOCK-LEFT	258A4701	1	52-71-13 633/256/L068	YC023-YM670
M02220		A420-066923-02 SOL-OVERWING FLIGHT LOCK-LEFT FWD	258A4701	1	52-71-13 595/256/L068	YC001-YL430
M02221		A420-066923-02 SOL-OVERWING FLIGHT LOCK-RIGHT	258A4701	1	52-71-14 621/256/R068	ALL

EQUIPMENT LIST

D280A103

Section M02200

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02222		A420-066923-02 SOL-OVERWING FLIGHT LOCK-RIGHT FWD	258A4701	1	52-71-14 583/256/R068	YC001-YL430
M02236		473925 UNIT-FWD CARGO COMPT SMOKE DET ELEX	218A4310 61423	1	26-16-21 450/204/L030	YC008-YM670
M02237		473925 UNIT-AFT CARGO COMPT SMOKE DET ELEX	218A4610 61423	1	26-16-22 817/206/L030	YC008-YM670
M02238		473597-5 FWD CARGO COMPT SMOKE DET A1	218A4310 61423	1	26-16-21 470/203/L015	YC008-YM670
M02239		473597-5 FWD CARGO COMPT SMOKE DET A2	218A4310 61423	1	26-16-21 500C+10/203/L012	YC008-YL430
M02239		473597-5 FWD CARGO COMPT SMOKE DET A2	218A4310 61423	1	26-16-21 500A+10/203/L012	YM643-YM670
M02240		473597-5 FWD CARGO COMPT SMOKE DET B1	218A4310 61423	1	26-16-21 430/203/R012	YC008-YM670
M02241		473597-5 FWD CARGO COMPT SMOKE DET B2	218A4310 61423	1	26-16-21 500E+10/203/R012	YC008-YL430
M02241		473597-5 FWD CARGO COMPT SMOKE DET B2	218A4310 61423	1	26-16-21 500+10/203/R012	YM643-YM670
M02242		473597-5 AFT CARGO COMPT SMOKE DET A1	218A4610 61423	1	26-16-22 727C+10/205/L011	YC008-YM670
M02243		473597-5 AFT CARGO COMPT SMOKE DET A2	218A4610 61423	1	26-16-22 727I+10/205/L009	YC008-YL430
M02243		473597-5 AFT CARGO COMPT SMOKE DET A2	218A4610 61423	1	26-16-22 777/205/L009	YM643-YM670
M02244		473597-5 AFT CARGO COMPT SMOKE DET A3	218A4610 61423	1	26-16-22 877/205/R009	YC008-YM670
M02245		473597-5 AFT CARGO COMPT SMOKE DET B1	218A4610 61423	1	26-16-22 727B+10/205/R010	YC008-YM670
M02246		473597-5 AFT CARGO COMPT SMOKE DET B2	218A4610 61423	1	26-16-22 727J+10/205/R009	YC008-YL430
M02246		473597-5 AFT CARGO COMPT SMOKE DET B2	218A4610 61423	1	26-16-22 757/205/R009	YM643-YM670
M02247		473597-5 AFT CARGO COMPT SMOKE DET B3	218A4610 61423	1	26-16-22 857/205/R009	YC008-YM670

EQUIPMENT LIST

D280A103

Section M02200

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02248		473957-5 EXTINGUISHER-CARGO FIRE BTL 1	218A6301 61423	1	26-23-11 540/180/L016	YC008-YC026
M02248		473957-4 EXTINGUISHER-CARGO FIRE BTL 1	218A6301 61423	1	26-23-11 540/180/L016	YC028-YM670
M02249		446616 SQUIB-CARGO FIRE EXT BTL 1 FWD	218A6301 61423	1	26-23-11 540/180/L016	YC008-YM670
M02250		446617 SQUIB-CARGO FIRE EXT BTL 1 AFT	218A6301 61423	1	26-23-11 540/180/L016	YC008-YM670
M02263		473957-4 EXTINGUISHER-CARGO FIRE BTL 2	218A6301 61423	1	26-23-11 540/180/R019	YK918-YL401, YL429
M02264		446616 SQUIB-CARGO FIRE EXT BTL 2 FWD	218A6301 61423	1	26-23-11 540/180/R019	YK918-YL401, YL429
M02265		446617 SQUIB-CARGO FIRE EXT BTL 2 AFT	218A6301 61423	1	26-23-11 540/180/R019	YK918-YL401, YL429
M02267		417A5700 MDL-AISLE INDICATOR LT	417A5700 81205	1	33-51-21 570/208/L009	YC001-YC050

EQUIPMENT LIST

D280A103

Section M02200

Page 3 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02307		285W0024-1B HANDSET-AFT ATTND PNL	417A6500 81205	1	23-42-13 / /	YM643-YM670
M02335		D717-02-001 BATTERY PACK-EMERGENCY LIGHT	417A5900 81205	1	33-51-11 500C+7/213/L067	YK901-YM670
M02373		S251A225-1 ELEVATOR FEEL SHIFT MODULE	251A2106	1	27-32-31 1085/264/L027	YC008-YM670

EQUIPMENT LIST

D280A103

Section M02300
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02445		H504B RUDDER POSN SENSOR	251A3437	0	22-11-81 / /	ALL
M02446		822-1588-101 RUDDER ACTUATOR	251A3437	0	22-11-81 / /	ALL

EQUIPMENT LIST

D280A103

Section M02400

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02502		964-0465-001 AIRPLANE PERSONALITY MODULE (APM)	284A0430 97896	0	23-27-39 E004-01/ /	YK901-YK907, YK910-YK918, YL421-YL422, YL424-YL430, YM645-YM651
M02502		964-0465-001 AIRPLANE PERSONALITY MODULE (APM)	284A0430 97896	1	23-27-39 E004-01/ /	YK908-YK909, YK919-YL401, YL423, YM652- YM670
M02536		285T0852-1 PANEL - KEYPAD, DOOR SECURITY	232A2401 81205	1	52-51-11 280/272/R010	YC031-YM670
M02537		285T0855-5 PANEL - CHIME, DOOR SECURITY	232A2401 81205	1	52-51-11 280/268/R010	YC031-YM670
M02538		B231162-501 STRIKER - SOLENOID, DOOR SECURITY	232A2401 56135	1	52-51-11 280/246/R010	YC031-YM670
M02539		RBDSC-2 MDL-PROGRAM SWITCH AUTOPILOT SYS A-2	284A2710 09922	0	22-11-75 E001-01/ /	YC031-YM670
M02539S4		SWITCH1-24 A/P SYS 1 DIP SW		1	22-11-75 E001-01/ /	YK901-YM670
M02540		RBDSC-2 MDL-PROGRAM SWITCH AUTOPILOT SYS B-2	284A2710 09922	0	22-11-75 E001-01/ /	YC031-YM670
M02540S5		SWITCH1-24 A/P SYS B DIP SW		1	22-11-75 E001-01/ /	YK901-YM670
M02554	9	10-61359-3 SPDBRK RETRACT ACTUATOR (APB 0802664)	254A1210	1	27-62-41 201/210/R002	YC001-YC010, YC012-YC030
M02554		10-61359-3 SPDBRK RETRACT ACTUATOR	254A1210	1	27-62-41 201/210/R002	YM643-YM670
M02559		1153154 MDL - NGS CONTROLLER	212A5002 07217	1	47-30-11 500I+8/201/R012	YK911-YK917, YK919-YL401, YL427-YL430
M02559		1153154 MDL - NGS CONTROLLER	212A5002 07217	1	47-30-11 500D+8/201/R012	YM651-YM670

EQUIPMENT LIST

D280A103

Section M02500

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02560		1153206-1 MDL - NGS BITE DISPLAY UNIT	212A5003 07217	1	47-30-11 543/157/R038	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
M02561		2040061-101 MDL - FILTER DELTA-P SWITCH	212A5001 92003	1	47-30-11 642/163/L048	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
M02562		1153158-1 MDL - NGS ALTITUDE SENSOR	212A5001 07217	1	47-30-11 656/158/L047	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
M02564		1153156-1 MDL - ASM HIGH D-P SENSOR	212A5001 07217	1	47-30-11 602/161/L060	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
M02565		1153222-1 MDL - NGS PRESSURE SENSOR	212A5001 07217	1	47-30-11 539/167/L034	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
M02566	9	1191-8 ISPS - POWER SUPPLY EE BAY (SB 24-1180)	284A0212 3E2Y8	1	25-29-11 360/160/25	YK907-YK909
M02566		1191-8 ISPS - POWER SUPPLY EE BAY	284A0212 3E2Y8	1	25-29-11 360/160/25	YL421-YL430
M02593	9	M83723-60-214AN J1 ISPC TERM PLUG (SB 24-1180)	284A0212 3E2Y8	1	25-29-11 360/160/R25	YK907-YK909
M02593		M83723-60-214AN J1 ISPC TERM PLUG	284A0212 3E2Y8	1	25-29-11 360/160/R25	YL421-YL430
M02596		P665A0001-00 FLT SPOILER 2	251A1210 K0648	1	27-62-11 ORSS/ /	YK907-YL430
M02597		P665A0001-00 FLT SPOILER 3	251A1210 K0648	1	27-62-11 ORSS/ /	YK907-YL430
M02598		P665A0001-00 FLT SPOILER 4	251A1210 K0648	1	27-62-11 ORSS/ /	YK907-YL430
M02599		P665A0001-00 FLT SPOILER 5	251A1210 K0648	1	27-62-11 ORSS/ /	YK907-YL430

EQUIPMENT LIST

D280A103

Section M02500

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02600		P665A0001-00 FLT SPOILER 8	251A1210 K0648	1	27-62-11 ORSS/ /	YK907-YL430
M02601		P665A0001-00 FLT SPOILER 9	251A1210 K0648	1	27-62-11 ORSS/ /	YK907-YL430
M02602		P665A0001-00 FLT SPOILER 10	251A1210 K0648	1	27-62-11 ORSS/ /	YK907-YL430
M02603		P665A0001-00 FLT SPOILER 11	251A1210 K0648	1	27-62-11 ORSS/ /	YK907-YL430
M02604		A420-062894-01 SOLENOID-SPEED BRAKE LVR LOCK	251A1910 73949	1	27-62-11 192/200/L007	YK907-YL430
M02621	9	1235-4-5 PC POWER OUTLET (P6) (SB 24-1180)	233A5105 3E2Y8	1	25-29-11 255/216/R040	YK907-YK909
M02621		1235-4-5 PC POWER OUTLET (P6)	233A5105 3E2Y8	1	25-29-11 255/216/R040	YL421-YL430
M02622	9	1235-4-5 PC POWER OUTLET (P18) (SB 24-1180)	232A1710 3E2Y8	1	25-29-11 P018-00/000/0000	YK907-YK909
M02622		1235-4-5 PC POWER OUTLET (P18)	232A1710 3E2Y8	1	25-29-11 P018-00/000/0000	YL421-YL430
M02623	9	1068808-1 J9 ISPS TERM PLUG (SB 24-1180)	284A0212 3E2Y8	1	25-29-11 360/160/R25	YK907-YK909
M02623		1068808-1 J9 ISPS TERM PLUG	284A0212 3E2Y8	1	25-29-11 360/160/R25	YL421-YL430
M02624	9	SE91D12A-F-8 J20 DUST CAP (SB 24-1180)	284A0212 3E2Y8	1	25-29-11 360/160/R25	YK907-YK909
M02624		SE91D12A-F-8 J20 DUST CAP	284A0212 3E2Y8	1	25-29-11 360/160/R25	YL421-YL430
M02625	9	SE91D12A-F-8 J21 DUST CAP (SB 24-1180)	284A0212 3E2Y8	1	25-29-11 360/160/R25	YK907-YK909
M02625		SE91D12A-F-8 J21 DUST CAP	284A0212 3E2Y8	1	25-29-11 360/160/R25	YL421-YL430
M02675		S280A100 WINDOW HEATER COIL CORD	287A4102 81205	2	30-41-11 230/ /	YK907-YM670

EQUIPMENT LIST

D280A103

Section M02600

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02692		3522W000-001 OXYGEN SENSOR	212A5001 U1605	1	47-30-11 577/155/L44	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670

EQUIPMENT LIST

D280A103

Section M02600

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02754		2234479-0256 WQAR PCMCIA CARD -0256	284W0441	1	31-35-03 / /	YK911-YL430
M02754		2234479-0512 WQAR PCMCIA CARD -0512	284W0441	1	31-35-03 / /	YM645-YM670
M02763		HR017 HTR-HEATER TAPE, 5-WAY FITTING	417A2410 79326	1	30-71-11 968/198/R030	YK913-YK917, YK919-YK920, YL427-YL430, YM652-YM670
M02764		79290-1956 HTR-HEATED HOSE, WTR SUPPLY TO G4/G4B/LC	417A2410 81205	1	30-71-11 1002/207/R044	YK913-YK917, YK919-YK920, YL427-YL430, YM652-YM670
M02765		AS5422K0620L2C HTR-HEATED HOSE, TANK TO 5-WAY FITTING	417A2410 81205	1	30-71-11 957/179/L001	YK913-YK917, YK919-YK920, YL427-YL430, YM652-YM670

EQUIPMENT LIST

D280A103

Section M02700
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M03000		FV-1060-1 CAMERA CONTROL PANEL (PROV)	284A0TBD 1UHX1	1	23-70-11 P008-00/ /	YK901-YK906
M03000		FV-1070-11 CAMERA CONTROL PANEL	233A6104 694845	1	23-70-11 P008-00/ /	YK907-YM670
M03001		FV-053010B10B VIDEO SWITCH	417A6400 694845	1	23-70-11 344/292/	YK907-YM670
M03002		FV-0406N1M9-12 CAMERA 1	417A6400 694845	1	23-70-11 285/ /0	YK907-YM670
M03003		FV-0406N1M9-12 CAMERA 2	417A6400 694845	1	23-70-11 340/ /0	YK907-YM670
M03004		FV-0406N1M9-12 CAMERA 3	417A6400 694845	1	23-70-11 333/ /R17	YK907-YM670
M03005		FV-0950N910RB CCU 1	417A6400 694845	1	23-70-11 285/ /0	YK907-YM670
M03006		FV-1038-5 IR 1	417A6400 694845	1	23-70-11 285/ /0	YK907-YM670
M03007		FV-0950N910RB CCU 2	417A6400 694845	1	23-70-11 340/ /0	YK907-YM670
M03008		FV-1038-5 IR 2	417A6400 694845	1	23-70-11 340/ /0	YK907-YM670
M03009		FV-0950N910RB CCU 3	417A6400 694845	1	23-70-11 333/ /R17	YK907-YM670
M03010		FV-1038-5 IR 3	417A6400 694845	1	23-70-11 333/ /R17	YK907-YM670
M03019		FV-0510N50RB VSU (PROV)	284A0TBD 1UHX1	1	23-70-11 E004-01/ /	YK901-YK906
M03020		FV-0830N-1 VIDEO MONITOR (PROV)	284A0TBD 1UHX1	1	23-70-11 P008-00/ /	YK901-YK906
M03054		S282T003-1 AUXILIARY BATTERY	284A0816 81205	1	24-31-11 378/158/L005	ALL
M03055		S282T003-3 AUXILIARY BATTERY CHARGER	284A0430 81205	1	24-31-11 E003-03/ /	YC001-YC011
M03055		S282T003-3 AUXILIARY BATTERY CHARGER	284A0431 81205	1	24-31-11 E003-03/ /	YC012-YM670

EQUIPMENT LIST

D280A103

Section M03000

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M09001	9	BJE53 DIODE (737-EB34-0155)	CUSTOMER CUST	1	34-49-11 E001-01/ /	YC001-YC007
M09002	9	BJE53 DIODE (737-EB34-0155)	CUSTOMER CUST	1	34-49-11 E001-01/ /	YC001-YC007
M09016	9	FV-1038-3 CDSS-IR ILLUMINATOR 1 (230116)	CUSTOMER CUST	1	23-70-11 284/ /	YC001-YC030
M09017	9	FV-0950 CDSS-CCU 2 (230116)	CUSTOMER CUST	1	23-70-11 335/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section M09000
Page 1 End
May 13/2008



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M09101	9	FV-1060-1 CDSS-CNT PNL (230116)	CUSTOMER CUST	1	23-70-11 P008-00/ /	YC001-YC030
M09102	9	FV-0830N-1 CDSS-MONITOR (230116)	CUSTOMER CUST	1	23-70-11 P008-00/ /	YC001-YC030
M09103	9	FV-0510N50RB CDSS-VIDEO SWITCHING UNIT (230116)	CUSTOMER CUST	1	23-70-11 E004-01/ /	YC001-YC030
M09104	9	FV-0950 CDSS-CCU 1 (230116)	CUSTOMER CUST	1	23-70-11 292/ /	YC001-YC030
M09105	9	FV-0405 CDSS-CAMERA 1 (230116)	CUSTOMER CUST	1	23-70-11 284/ /	YC001-YC030
M09108	9	FV-0405 CDSS-CAMERA 2 (230116)	CUSTOMER CUST	1	23-70-11 292/ /	YC001-YC030
M09109	9	FV-1038-3 CDSS-IR ILLUMINATOR 2 (230116)	CUSTOMER CUST	1	23-70-11 292/ /	YC001-YC030
M09110	9	FV-0950 CDSS-CCU 3 (230116)	CUSTOMER CUST	1	23-70-11 355/ /	YC001-YC030
M09111	9	FV-0405 CDSS-CAMERA 3 (230116)	CUSTOMER CUST	1	23-70-11 338/ /	YC001-YC030
M09112	9	FV-1038-3 CDSS-IR ILLUMINATOR 3 (230116)	CUSTOMER CUST	1	23-70-11 338/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section M09100

Page 1 End

May 13/2008



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10373		417N3810 MOD-LAVATORY OXYGEN	417A1140 81205	3	35-21-21 MULTI/ /	YC001-YL430
M10373		417N3810 MOD-LAVATORY OXYGEN	417A1140 81205	2	35-21-12 MULTI/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section M10300
Page 1 End
Feb 09/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10720		S417N511-1 MDL-FLUOR LAMP/BALLAST(PRI) SEE Y015	417A5500 72914	24	33-21-21 MULTI/ /	YC001-YC026
M10720		10-1733-1 MDL-FLUOR LAMP/BALLAST(PRI) SEE Y015	417A5500 72914	24	33-21-21 MULTI/ /	YC028-YL426, YL429
M10720		10-1733-1 MDL-FLUOR LAMP/BALLAST(PRI)-COOL WHITE	417A5500 72914	24	33-21-21 MULTI/ /	YL427-YL428, YL430
M10720		10-1733-1 MDL-FLUOR LAMP/BALLAST(PRI) SEE Y015	417A5500 72914	20	33-21-21 MULTI/ /	YM643-YM670
M10721		S417N511-2 MDL-FLUOR LAMP/(SECONDARY)SEE Y016	417A5500 72914	16	33-21-21 MULTI/ /	YC001-YC026
M10721		10-1733-2 MDL-FLUOR LAMP/(SECONDARY)SEE Y016	417A5500 72914	16	33-21-21 MULTI/ /	YC028-YL426, YL429
M10721		10-1733-2 MDL-FLUOR LAMP/(SECONDARY)-COOL WHITE	417A5500 72914	16	33-21-21 MULTI/ /	YL427-YL428, YL430
M10721		10-1733-2 MDL-FLUOR LAMP/(SECONDARY)SEE Y016	417A5500 72914	14	33-21-21 MULTI/ /	YM643-YM670
M10722		S417N511-3 MDL-FLUOR LAMP/BALLAST(SHORT)SEE Y017	417A5500 72914	4	33-21-21 MULTI/ /	YC001-YC026
M10722		10-1733-3 MDL-FLUOR LAMP/BALLAST(SHORT)SEE Y017	417A5500 72914	4	33-21-21 MULTI/ /	YC028-YC050
M10722		10-1733-3 MDL-FLUOR LAMP/BALLAST(SHORT)SEE Y017	417A5500 72914	5	33-21-21 MULTI/ /	YK901-YL426, YL429
M10722		10-1733-3 MDL-FLUOR LAMP/BALLAST(SHORT)-COOL WHITE	417A5500 72914	5	33-21-21 MULTI/ /	YL427-YL428, YL430
M10722		10-1733-3 MDL-FLUOR LAMP/BALLAST(SHORT)SEE Y017	417A5500 72914	2	33-21-21 MULTI/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section M10700

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10973		417N3011 MDL-PSU U/B	417A3100 14275	63	33-23-31 MULTI/ /	YK901-YL430
M10973		417N3011 MDL-PSU U/B	417A3100 14275	50	33-23-31 MULTI/ /	YM643-YM670
M10976		417N3011 MDL-PSU U/B	417A3100 81205	62	33-23-31 MULTI/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section M10900
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M11031		S417N313-101 MDL-PSU U/B COMPONENT	417N3011 14275	50	33-23-31 MULTI/ /	YC001-YC050, YM643-YM670
M11031		S417N313-101 MDL-PSU U/B COMPONENT	417N3011 14275	63	33-23-31 MULTI/ /	YK901-YL430
M11037		S417N313-203 MDL-PSU JUMPER	417N3011 14275	50	33-23-31 MULTI/ /	YC001-YC050, YM643-YM670
M11037		S417N313-203 MDL-PSU JUMPER	417N3011 14275	63	33-23-31 MULTI/ /	YK901-YL430
M11044	1	S417N312-13 MDL-PSU U/B SWITCH MODULE	417N3011 01781	50	33-23-31 MULTI/ /	YC001-YC050, YM643-YM670
M11044	1	S417N312-13 MDL-PSU U/B SWITCH MODULE	417N3011 01781	63	33-23-31 MULTI/ /	YK901-YL430
M11044	2	S417N312-11 MDL-PSU U/B SWITCH MODULE	417N3011 01781	50	33-23-31 MULTI/ /	YC001-YC050, YM643-YM670
M11044	2	S417N312-11 MDL-PSU U/B SWITCH MODULE	417N3011 01781	63	33-23-31 MULTI/ /	YK901-YL430

EQUIPMENT LIST

D280A103

Section M11000

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00011		162BL903 IND-TEMPERATURE	233A3101 35918	1	21-61-51 P005-17/ /	ALL
N00012		S231T245-4 IND-DUAL PRESSURE	233A3101 61349	1	36-21-11 P005-10/ /	ALL
N00020		182936 IND-CREW OXYGEN PRESSURE	233A3101 81205	1	35-11-11 P005-14/ /	ALL
N00024		10-62190-3 IND-EXHAUST GAS TEMPERATURE APU	233A3204 81205	1	49-71-21 P005-04/ /	ALL
N00041		10-60775-6 IND-YAW DAMPER SURFACE POSITION	233A2101 81205	1	22-23-11 P002-01/ /	ALL
N00042		10-60521-2 IND-FUEL TEMPERATURE	233A3101 81205	1	28-42-11 P005-02/ /	ALL
N00051		10-60726-6 IND-CAB ALTITUDE AND DIFFERENTIAL PRESS	233A3101 81205	1	33-12-11 P005-16/ /	ALL
N00054		10-61926-5 IND-FLAP POSITION	233A2101 81205	1	27-52-11 P002-02/ /	ALL
N00055		10-60755-6 IND-CABIN RATE OF CLIMB	233A3101 81205	1	33-12-11 P005-16/ /	ALL
N00074		C-5C IND-STANDBY COMPASS	233A4226 61349	1	33-14-12 212/258/000	YC001-YC030
N00074		C-5L IND-STANDBY COMPASS (737-800)	232A4226 61349	1	33-14-12 212/258/000	YC031-YK912, YK918-YK919, YL401-YL429
N00074		C-5L IND-STANDBY COMPASS (737-700)	232A4226 61349	1	33-14-12 212/258/000	YM643-YM652
N00085		WL102AMS3 IND-STANDBY ALTIMETER/AIRSPEED	65-46990 35012	1	34-21-12 P001-03/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section N00000
Page 1 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00145		60B00303-105 CLOCK-CAPTAIN	233A2101 82227	1	31-22-11 P001-01/ /	YC001-YC007
N00145		S231W130-3 CLOCK-CAPTAIN	233A2101 K0100	1	31-22-11 P001-01/ /	YC008-YC030
N00145		9010-1-3 CLOCK-CAPTAIN	233A2101 30242	1	31-22-11 P001-01/ /	YC031-YM670
N00146		60B00303-105 CLOCK-FIRST OFFICER	233A2101 82227	1	31-22-11 P003-03/ /	YC001-YC007
N00146		S231W130-3 CLOCK-FIRST OFFICER	233A2101 K0100	1	31-22-11 P003-03/ /	YC008-YC030
N00146		9010-1-3 CLOCK-FIRST OFFICER	233A2101 30242	1	31-22-11 P003-03/ /	YC031-YM670
N00158		S231W210-2 IND-HYDRAULIC BRAKE PRESSURE	233A2101 81205	1	29-32-11 P003-01/ /	ALL
N00159		10-62035-2 IND-RUDDER TRIM	233A6101 81205	1	27-28-11 P008-43/ /	ALL
N00170		10-62058-6 ANNUN-CAPTAIN AUTO FLIGHT STATUS	233A2101 13499	1	22-14-11 P001-03/ /	ALL
N00171		10-62058-6 ANNUN-FIRST OFFICER AUTO FLIGHT STATUS	233A2101 13499	1	22-14-11 P003-01/ /	ALL
N00185		S242T403-207 IND-RADIO MAGNETIC	233A2101 03483	1	34-22-11 P002-01/ /	ALL
N00186		S231A121-1 IND-STANDBY ATTITUDE	233A2101 SFENA	1	34-24-11 P002-01/ /	YC001-YC050
N00187		S243W001-2601 DISPLAY UNIT-CAPTAIN OUTBOARD	233A2101 58960	1	31-62-11 P001-00/ /	YC001-YC007
N00187		S243W001-2603 DISPLAY UNIT-CAPTAIN OUTBOARD	233A2101 58960	1	31-62-11 P001-00/ /	YC008-YC026
N00187		4086850-922 DISPLAY UNIT-CAPTAIN OUTBOARD (-800)	233A2101 58960	1	31-62-11 P001-00/ /	YC028-YK912, YK918-YK919, YL401-YL429
N00187		4086850-922 DISPLAY UNIT-CAPTAIN OUTBOARD (-700)	233A2101 58960	1	31-62-11 P001-00/ /	YM643-YM652

EQUIPMENT LIST

D280A103

Section N00100

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00188		S243W001-2601 DISPLAY UNIT-CAPTAIN INBOARD	233A2101 58960	1	31-62-11 P001-00/ /	YC001-YC007
N00188		S243W001-2603 DISPLAY UNIT-CAPTAIN INBOARD	233A2101 58960	1	31-62-11 P001-00/ /	YC008-YC026
N00188		4086850-922 DISPLAY UNIT-CAPTAIN INBOARD (-800)	233A2101 58960	1	31-62-11 P001-00/ /	YC028-YK912, YK918-YK919, YL401-YL429
N00188		4086850-922 DISPLAY UNIT-CAPTAIN INBOARD (-700)	233A2101 58960	1	31-62-11 P001-00/ /	YM643-YM652
N00189		S243W001-2601 DISPLAY UNIT-UPPER CENTER	233A2101 58960	1	31-62-11 P002-00/ /	YC001-YC007
N00189		S243W001-2603 DISPLAY UNIT-UPPER CENTER	233A2101 58960	1	31-62-11 P002-00/ /	YC008-YC026
N00189		4086850-922 DISPLAY UNIT-UPPER CENTER (-800)	233A2101 58960	1	31-62-11 P002-00/ /	YC028-YK912, YK918-YK919, YL401-YL429
N00189		4086850-922 DISPLAY UNIT-UPPER CENTER (-700)	233A2101 58960	1	31-62-11 P002-00/ /	YM643-YM652
N00190		S243W001-2601 DISPLAY UNIT-LOWER CENTER	233A2101 58960	1	31-62-21 P009-00/ /	YC001-YC007
N00190		S243W001-2603 DISPLAY UNIT-LOWER CENTER	233A2101 58960	1	31-62-21 P009-00/ /	YC008-YC026
N00190		4086850-922 DISPLAY UNIT-LOWER CENTER (-800)	233A2101 58960	1	31-62-21 P009-00/ /	YC028-YK906, YL421-YL429
N00190		4086850-924 DISPLAY UNIT-LOWER CENTER (-800)	233A2101 58960	1	31-62-21 P009-00/ /	YK907-YK912, YK918-YK919, YL401
N00190		4086850-924 DISPLAY UNIT-LOWER CENTER (-700)	233A2101 58960	1	31-62-21 P009-00/ /	YM643-YM652
N00191		S243W001-2601 DISPLAY UNIT-FIRST OFFICER OUTBOARD	233A2101 58960	1	31-62-21 P003-00/ /	YC001-YC007
N00191		S243W001-2603 DISPLAY UNIT-FIRST OFFICER OUTBOARD	233A2101 58960	1	31-62-21 P003-00/ /	YC008-YC026

EQUIPMENT LIST

D280A103

Section N00100

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00191		4086850-922 DISPLAY UNIT-FIRST OFFICER OUTBRD (-800)	233A2101 58960	1	31-62-21 P003-00/ /	YC028-YK912, YK918-YK919, YL401-YL429
N00191		4086850-922 DISPLAY UNIT-FIRST OFFICER OUTBRD (-700)	233A2101 58960	1	31-62-21 P003-00/ /	YM643-YM652
N00192		S243W001-2601 DISPLAY UNIT-FIRST OFFICER INBOARD	233A2101 58960	1	31-62-21 P003-00/ /	YC001-YC007
N00192		S243W001-2603 DISPLAY UNIT-FIRST OFFICER INBOARD	233A2101 58960	1	31-62-21 P003-00/ /	YC008-YC026
N00192		4086850-922 DISPLAY UNIT-FIRST OFFICER INBRD (-800)	233A2101 58960	1	31-62-21 P003-00/ /	YC028-YK912, YK918-YK919, YL401-YL429
N00192		4086850-922 DISPLAY UNIT-FIRST OFFICER INBRD (-700)	233A2101 58960	1	31-62-21 P003-00/ /	YM643-YM652
N00193		S345A001-001 IND-TANK 1 FUELING	344A5111 81205	1	28-44-11 / /	ALL
N00194		S345A001-001 IND-TANK 2 FUELING	344A5111 81205	1	28-44-11 / /	ALL
N00195		S345A001-001 IND-TANK CENTER FUELING	344A5111 81205	1	28-44-11 / /	ALL
N00199		S417N207-7 IND-WATER QUANTITY (PROVISION)	417A2515 81205	1	38-41-13 916/169/R010	ALL

EQUIPMENT LIST

D280A103

Section N00100

Page 3 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00226		C16221KA02 INTEGRATED STANDBY FLIGHT DISPLAY	233A2101 F9111	1	34-24-15 P002-01/ /	YK901-YK920, YM643
N00226		C16221MA01 INTEGRATED STANDBY FLIGHT DISPLAY	233A2101 F9111	1	34-24-15 P002-01/ /	YL401-YL430, YM645-YM670

EQUIPMENT LIST

D280A103

Section N00200
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P001-01		233A2220-1 PNL-CAPTAIN INSTRUMENT	233A2101 81205	1	91-03-12 P001-00/ /	ALL
P001-02		69-37301-79 PNL-CAPTAINS INSTRUMENT	233A2101 81205	1	91-03-12 P001-00/ /	ALL
P001-03		233A2221-1 PNL-CAPTAIN INSTRUMENT	233A2101 81205	1	91-03-13 P001-00/ /	YC001-YK910, YL401-YL423, YM643
P001-03		233A2221-17 PNL-CAPTAIN INSTRUMENT	233A2103 81205	1	91-03-13 P001-00/ /	YK911, YK918, YL424-YL426, YM645-YM651
P001-03		233A2221-29 PNL-CAPTAIN INSTRUMENT	233A2103 81205	1	91-03-13 P001-00/ /	YK912-YK917, YK919-YK920, YL427-YL430, YM652-YM670
P001-05		233A2229-3 PNL-MD;-FLOODLIGHT CONTROL	233A2101 81205	1	33-14-11 P001-00/ /	ALL
P001-09		233A2227-1 PNL-LIGHTING CONTROL - CAPTAIN	233A2101 81205	1	91-02-01 P001-00/ /	ALL

EQUIPMENT LIST

D280A103

Section P001
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P002-01		233A2225-1 PNL-CENTER INSTRUMENT	233A2101 81205	0	91-03-13 P002-00/ /	ALL
P002-02		233A2224-3 PNL-CENTER INSTRUMENT	233A2101 81205	1	91-03-13 P002-00/ /	YC001-YK920, YL421-YM670
P002-02		233A2224-5 PNL-CENTER INSTRUMENT	233A2101 81205	1	91-03-13 P002-00/ /	YL401
P002-03		233A2226-1 PNL-LANDING GEAR	233A2101 81205	1	32-64-10 P002-00/ /	ALL

EQUIPMENT LIST

D280A103

Section P002
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P003-01		J233A2222-1 PNL-FIRST OFFICER INSTRUMENT	233A2101 81205	1	91-02-03 P003-00/ /	YC001-YK910, YL401-YL423, YM643
P003-01		233A2222-30 PNL-FIRST OFFICER INSTRUMENT	233A2103 81205	1	91-02-03 P003-00/ /	YK911, YK918, YL424-YL426, YM645-YM651
P003-01		233A2222-52 PNL-FIRST OFFICER INSTRUMENT	233A2103 81205	1	91-02-03 P003-00/ /	YK912-YK917, YK919-YK920, YL427-YL430, YM652-YM670
P003-03		233A2223-1 PNL-FIRST OFFICER INSTRUMENT	233A2101 81205	1	91-02-03 P003-00/ /	ALL
P003-04		233A2228-1 PNL-LIGHTING CONTROL - F/O	233A2101 81205	1	91-02-03 P003-00/ /	ALL
P003-07	9	69-37369-300 PNL-GND PROX TEST	233A2101 81205	1	34-49-11 P003-00/ /	YK901-YL430
P003-07		69-37369-36 PNL-GND PROX TEST	233A2101 81205	1	91-02-03 P003-00/ /	YC001-YC007
P003-07		69-37369-300 PNL-GND PROX TEST	233A2101 81205	1	34-49-11 P003-00/ /	YC008-YM670

EQUIPMENT LIST

D280A103

Section P003

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P005-00		233A3101 PNL-PILOTS OVERHEAD (FWD AND AFT)	65-46991 81205	1	91-02-05 P005-00/280/000	ALL
P005-02		233A3202-1 PNL-FUEL SYSTEM	233A3101 81205	1	28-21-11 P005-00/ /	YC001-YC019
P005-02		233A3202-2 PNL-FUEL SYSTEM	233A3101 81205	1	28-21-11 P005-00/ /	YC020-YC028
P005-02		233A3202-3 PNL-FUEL SYSTEM	233A3101 81205	1	28-21-11 P005-00/ /	YC029-YC030
P005-02		233A3202-5 PNL-FUEL SYSTEM	233A3101 81205	1	28-43-11 P005-00/ /	YC031-YM670
P005-03	9	233A3209-2 PNL-FLIGHT CONTROL (SB 27-1262)	233A3101 81205	1	27-23-11 P005-00/ /	YC001-YC030
P005-03		233A3209-1 PNL-FLIGHT CONTROL	233A3101 81205	1	27-23-11 P005-00/ /	YC031-YM670
P005-04		233A3204-1 PNL-AC SYSTEM GEN AND APU	233A3101 81205	1	24-28-21 P005-00/ /	ALL
P005-05		233A3205-1 PNL-GEN DRIVE AND STBY PWR	233A3101 81205	1	24-28-31 P005-00/ /	ALL
P005-06		10-62231-1 PNL-CABIN PRESSURE SELECTOR	233A3101 81205	1	21-31-11 P005-00/ /	YC001-YC030
P005-06		10-62231-21 PNL-CABIN PRESSURE SELECTOR (-800)	233A3101 81205	1	21-31-11 P005-00/ /	YC031-YK912, YK918-YK919, YL401-YL429
P005-06		10-62231-21 PNL-CABIN PRESSURE SELECTOR (-700)	233A3101 81205	1	21-31-11 P005-00/ /	YM643-YM652
P005-07		980-6116-001 PNL-VOICE RECORDER	233A3101 97896	1	23-71-01 P005-00/ /	ALL
P005-08		69-37317-300 PNL-HYD PUMPS	233A3101 81205	1	29-33-11 P005-00/ /	ALL
P005-09	9	233A3201-9 PNL-WINDOW AND PITOT HEAT	SB301047 81205	1	30-31-11 P005-00/ /	YC001-YC007
P005-09		233A3201-2 PNL-WINDOW AND PITOT HEAT	233A3101 81205	1	30-31-11 P005-00/ /	YC004-YC007, YK901-YK910, YK918, YL421- YM651

EQUIPMENT LIST

D280A103

Section P005
Page 1
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P005-09		233A3201-9 PNL-WINDOW AND PITOT HEAT	233A3101 81205	1	30-31-11 P005-00/ /	YC008-YC050, YK911-YK917, YK919-YL401, YM652-YM670
P005-10		69-37319-309 PNL-AIR CONDITIONING	233A3101 81205	1	21-51-11 P005-00/ /	YC001-YL430
P005-10		69-37319-308 PNL-AIR CONDITIONING	233A3101 81205	1	21-51-11 P005-00/ /	YM643-YM670
P005-11		69-37320-104 PNL-ENGINE AND WING ANTI-ICE	233A3101 81205	1	30-21-11 P005-00/ /	ALL
P005-12		S231A219-2 PNL-LE FLAP/SLAT ANNUNCIATOR	233A3101 81205	1	27-81-11 P005-00/ /	ALL
P005-13		285A1840-2 PNL-ELEC METER,BATTERY AND GALLEY POWER	233A3101 81205	1	24-28-11 P005-00/ /	YC001-YC007
P005-13		285A1840-4 PNL-ELEC METER,BATTERY AND GALLEY POWER	233A3101 81205	1	24-28-11 P005-00/ /	YC008-YC030
P005-13		285A1840-8 PNL-ELEC METER,BATTERY AND GALLEY POWER	233A3104 81205	1	24-28-11 P005-00/ /	YC031-YM670
P005-14		69-37322-15 PNL-OXYGEN SYSTEM	233A3101 81205	1	35-21-11 P005-00/ /	ALL
P005-15		10-62090-60 PNL-OBSERVER AUDIO SELECT	233A3101 81205	1	23-51-31 P005-00/ /	YC001-YK906
P005-15		10-62090-42 PNL-OBSERVER AUDIO SELECT	233A3101 81205	1	23-51-03 P005-00/ /	YK907-YM670
P005-16		69-37334-12 PNL-CABIN ALT AND RATE OF CLIMB	233A3101 81205	1	21-33-11 P005-00/ /	ALL
P005-17		69-37324-78 PNL-CABIN TEMPERATURE	233A3101 81205	1	21-61-51 P005-00/ /	YC001-YL430
P005-17		69-37324-18 PNL-CABIN TEMPERATURE	233A3101 81205	1	21-61-51 P005-00/ /	YM643-YM670
P005-18		69-75978-1 PNL-STALL WARN NO.1 AND NO.2	233A3101 81205	1	27-32-11 P005-00/ /	ALL
P005-19		233A3208-2 PNL-FLT RCDR AND MACH AIRSPEED WARN	233A310X 81205	1	31-31-11 P005-19/ /	ALL

EQUIPMENT LIST

D280A103

Section P005

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P005-20		233A3207-6 PNL-DOOR WARNING ANNUNCIATOR	233A3101	1	52-71-11 P005-00/ /	YC001-YL430
P005-20		233A3207-4 PNL-DOOR WARNING ANNUNCIATOR	233A3101	1	52-71-11 P005-00/ /	YM643-YM670
P005-28		233A3206-1 PNL-INSTRUMENT SWITCHING	233A3101 81205	1	34-51-41 P005-00/ /	YC001-YK910, YK918, YL401- YM651
P005-28		233A3206-2 PNL-INSTRUMENT SWITCHING	233A3101 81205	1	34-51-41 P005-00/ /	YK911-YK917, YK919-YK920, YM652-YM670
P005-68		233A3203-1 PNL-ENGINE CONTROL	233A3101 81205	1	73-21-12 P005-00/ /	ALL
P005-69		69-73713-17 PNL-IRS MODE SELECTOR	233A3101 81205	1	34-21-11 P005-69/ /	YC001-YK906, YM643-YM651
P005-69		69-73713-20 PNL-IRS MODE SELECTOR	233A3101 81205	1	34-21-11 P005-69/ /	YK907-YL430, YM652-YM670
P005-70		10-62042-103 PNL-INERTIAL SYSTEM DISPLAY	233A3101 65507	1	34-21-21 P005-70/ /	ALL
P005-80		453-0161 PNL-MDL ASSY-EMER LCTR XMTR CONT	233A3101 60253	1	23-24-11 P005-00/ /	ALL
P005-81		69-78190-1 PNL-VIDEO	233A3101 97896	1	23-32-12 P005-00/ /	ALL
P005-88		233A3211-1 PNL-VOICE RECORDER	233A3101 97896	1	23-71-01 P005-00/ /	YC008-YM670

EQUIPMENT LIST

D280A103

Section P005
Page 3 End
Feb 09/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P006-01		233A5221 PNL-CB ELEX SYS F/O	233A5221 81205	1	91-02-06 P006-00/ /	ALL
P006-02		233A5222 PNL-CB ELEX SYS F/O	233A5222 81205	1	91-02-06 P006-00/ /	ALL
P006-03		233A5223 PNL-CB ELEX SYS F/O	233A5223 81205	1	91-02-06 P006-00/ /	ALL
P006-04		233A5224 PNL-CB ELEX SYS F/O	233A5224 81205	1	91-02-06 P006-00/ /	ALL
P006-11		233A5225 PNL-CB ELEX SYS F/O	233A5225 81205	1	91-02-06 P006-00/ /	ALL
P006-12		233A5226 PNL-CB ELEX SYS F/O	233A5226 81205	1	91-02-06 P006-00/ /	ALL

EQUIPMENT LIST

D280A103

Section P006
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P007-00		233A8101 PNL-LIGHTSHIELD	233A8101 81205	1	33-18-51 178/210/000	ALL
P007-01		S242A801-2100 PNL-CAPTAIN EFIS	233A2101 58960	1	31-62-13 P007-01/ /	ALL
P007-02		S242A801-2100 PNL-FIRST OFFICER EFIS	233A2101 58960	1	31-62-23 P007-02/ /	ALL

EQUIPMENT LIST

D280A103

Section P007
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P008-00		2041223-0414 PNL-WEATHER RADAR CONTROL	233A6101 81205	1	34-41-00 P008-00/ /	YC001-YC050
P008-00		2041223-3135 PNL-WEATHER RADAR CONTROL	233A6101 81205	1	34-41-00 P008-00/ /	YK901-YM670
P008-01		69-37307-300 PNL-ENGINES AND APU FIRE CONTROL	233A6101 81205	1	26-21-11 P008-00/ /	ALL
P008-02		G7400-12 PNL-VHF 1 COMM	233A6101 99837	1	23-12-11 P008-02/ /	YC001-YC050
P008-03		G7400-12 PNL-VHF 2 COMM	233A6101 99837	1	23-12-21 P008-03/ /	YC001-YC050
P008-03		622-6831-021 PNL-VHF 2 COMM	233A6101 13499	1	23-12-21 P008-03/ /	YM643-YM670
P008-06		10-62090-60 PNL-CAPTAIN AUDIO SELECT	233A6101 81205	1	23-51-11 P008-06/ /	YC001-YK906
P008-06		10-62090-42 PNL-CAPTAIN AUDIO SELECT	233A6101 81205	1	23-51-01 P008-06/ /	YK907-YM670
P008-07		10-62090-60 PNL-FIRST OFFICER AUDIO SELECT	233A6101 81205	1	23-51-21 P008-07/ /	YC001-YK906
P008-07		10-62090-42 PNL-FIRST OFFICER AUDIO SELECT	233A6101 81205	1	23-51-02 P008-07/ /	YK907-YM670
P008-11	9	622-6827-022 PNL-HF 1 CONTROL (MR 39273-4)	233A6101 13499	1	23-11-11 P008-11/ /	YC005-YC007
P008-25		G7500-01 PNL-CAPTAIN VHF NAVIGATION	233A6101 99837	1	34-51-11 P008-25/ /	YC001-YC007
P008-25		G7500-03 PNL-CAPTAIN VHF NAVIGATION	233A6101 99837	1	34-51-11 P008-25/ /	YC008-YK906
P008-25		G7501-01 PNL-CAPTAIN VHF NAVIGATION	233A6101 99837	1	34-51-11 P008-25/ /	YK907-YM670
P008-26		G7500-01 PNL-FIRST OFFICER VHF NAVIGATION	233A6101 99837	1	34-51-21 P008-26/ /	YC001-YC007
P008-26		G7500-03 PNL-FIRST OFFICER VHF NAVIGATION	233A6101 99837	1	34-51-21 P008-26/ /	YC008-YK906
P008-26		G7501-01 PNL-FIRST OFFICER VHF NAVIGATION	233A6101 99837	1	34-51-21 P008-26/ /	YK907-YM670

EQUIPMENT LIST

D280A103

Section P008

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P008-29		G6990-19 PNL-AIR TRAFFIC CONTROL TRANSPONDER	233A6101 30242	1	34-53-11 P008-29/ /	ALL
P008-43		69-73703-8 PNL-AILERON/RUDDER TRIM	233A6101 81205	1	27-11-11 P008-00/ /	YC001-YC030
P008-43		69-73703-9 PNL-AILERON/RUDDER TRIM	233A6101 81205	1	27-11-11 P008-00/ /	YC031-YM670
P008-47		69-76436-7 PNL-STABILIZER TRIM/DOOR UNLOCK	233A6101 81205	1	52-51-11 P008-00/ /	YC001-YC030
P008-47		69-76436-9 PNL-STABILIZER TRIM/DOOR UNLOCK	233A6101 81205	1	52-51-11 P008-00/ /	YC031-YM670
P008-50		69-76435-5 PNL-LTG CONTROL-CONTROL STAND	233A6101 81205	1	33-11-41 P008-00/ /	ALL
P008-52		2041223-0414 PNL-WEATHER RADAR CONTROL	233A6101 97896	1	34-41-11 P008-00/ /	YC001-YC050
P008-52		2041223-3135 PNL-WEATHER RADAR CONTROL	233A6101 97896	1	34-41-11 P008-00/ /	YK901-YM670
P008-68		G7402-05-BFE- PNL-ADF 1	233A6101 99837	1	34-57-11 P008-00/ /	YC001-YC003
P008-68		G7402-04 PNL-ADF 1	233A6101 99837	1	34-57-11 P008-00/ /	YC004-YM670
P008-69	9	G7402-04 PNL-ADF 2 (SB 34-2194)	233A6101 99837	1	34-57-21 P008-00/ /	YC028-YC029
P008-71		G7404-124 PNL-RADIO TUNING 1	233A6101 99837	1	23-12-11 P008-02/ /	YK901-YL430
P008-71		G7404-124 PNL-RADIO TUNING 1	233A6101 99837	1	23-12-11 P008-71/ /	YM643-YM670
P008-72		G7404-124 PNL-RADIO TUNING 2	233A6101 99837	1	23-12-21 P008-02/ /	YK901-YL430
P008-72		G7404-124 PNL-RADIO TUNING 2	233A6101 99837	1	23-12-21 P008-72/ /	YM643-YM670
P008-73		G7404-124 PNL-RADIO TUNING 3	233A6101 99837	1	23-12-31 P008-73/ /	YK901-YM670
P008-75		473955-1 PNL-CARGO SMOKE DET & FIRE SUPPRESSION	233A6101 61423	1	26-16-21 P008-00/ /	ALL

EQUIPMENT LIST

D280A103

Section P008
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P009-00		233A2101 PNL-FORWARD ELECTRONICS	233A2101 81205	1	91-03-29 P009-00/ /	ALL
P009-65		S242A600-2001 PNL-MULTI-PURPOSE CDU (MCDU) NO.1	233A2101 81205	1	34-61-11 P009-65/ /	YC001-YC002, YC008-YM670
P009-65		10-62194-002 PNL-MULTI-PURPOSE CDU (MCDU) NO.1	233A2101 81205	1	34-61-11 P009-65/ /	YC003-YC007
P009-66		S242A600-2001 PNL-MULTI-PURPOSE CDU (MCDU) NO.2	233A2101 81205	1	34-61-11 P009-66/ /	YC001-YC002, YC008-YM670
P009-66		10-62194-002 PNL-MULTI-PURPOSE CDU (MCDU) NO.2	233A2101 81205	1	34-61-11 P009-66/ /	YC003-YC007

EQUIPMENT LIST

D280A103

Section P009
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P013-00		417A6110-1 PNL-FORWARD ATTENDANT	417A6100 81205	1	23-42-12 304/227/L052	YC001-YC050, YK910-YK920, YM643-YM670

EQUIPMENT LIST

D280A103

Section P013
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P014-00		417A6110-2 PNL-AFT ATTENDANT	417A6100 81205	1	23-42-12 949/272/L025	YC001-YC050, YK910-YK920, YM643-YM670

EQUIPMENT LIST

D280A103

Section P014
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P015-00		344A2801-2 PNL-WING FUELING	344A5111 81205	1	28-44-11 FS350/ /	ALL

EQUIPMENT LIST

D280A103

Section P015
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P018-01		233A5521 PNL-CB ELEX SYS CAPT	233A5521 81205	1	91-02-18 P018-00/ /	ALL
P018-02		233A5522 PNL-CB ELEX SYS-CAPT	233A5522 81205	1	91-02-18 P018-00/ /	ALL
P018-03		233A5523 PNL-CB ELEX SYS CAPT	233A5523 81205	1	91-02-18 P018-00/ /	ALL

EQUIPMENT LIST

D280A103

Section P018
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P019-00		284A1807 PNL-EXTERNAL POWER RECEPTACLE	284A1807 81205	1	24-41-11 236/187/R040	ALL

EQUIPMENT LIST

D280A103

Section P019
Page 1 End
Feb 09/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P021-01		233A7201-2 PNL-CAPTAIN MAP LIGHT	233A7101 81205	1	33-17-11 215/213/L034	ALL
P021-07		MXP-147-2 PNL-CAPTAIN OXYGEN MASK STOWAGE	232A8100 F5341	1	23-51-01 215/213/L034	YC001-YC050
P021-07		MXP410-1 PNL-CAPTAIN OXYGEN MASK STOWAGE	232A8100 F5341	1	23-51-01 215/213/L034	YK901-YM670

EQUIPMENT LIST

D280A103

Section P021
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P023-01		233A7202-2 PNL-FIRST OFFICER MAP LIGHT	233A7101 81205	1	33-17-11 215/213/R034	ALL
P023-07		MXP-147-2 PNL-FIRST OFFICER OXYGEN MASK STOWAGE	232A8100 F5341	1	23-51-02 215/213/R034	YC001-YC050
P023-07		MXP410-1 PNL-FIRST OFFICER OXYGEN MASK STOWAGE	232A8100 F5341	1	23-51-02 215/213/R034	YK901-YM670

EQUIPMENT LIST

D280A103

Section P023
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P028-00		355A5340 PNL-APU REMOTE CONTROL	355A5340 81205	1	26-21-11 727/185/R025	ALL

EQUIPMENT LIST

D280A103

Section P028
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P041-00		233A2230-1 PNL-P1 AND P2 5V LIGHTING	233A2101 81205	1	33-11-11 P041-00/ /	ALL

EQUIPMENT LIST

D280A103

Section P041
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P042-00		233A2230-8 PNL-P3 5V LIGHTING	233A2101 81205	1	33-11-21 P042-00/ /	ALL

EQUIPMENT LIST

D280A103

Section P042
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P059-00		284A1225 PNL-FMC SWITCH	284A1225 81205	1	34-61-19 330/170/R022	ALL

EQUIPMENT LIST

D280A103

Section P059
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P061-01		233A7203-8 PNL-DATA LOADER CONTROL	233A7101 81205	1	31-32-15 P061-01/ /	YC012-YC029
P061-01		233A7203-10 PNL-DATA LOADER CONTROL PANEL	233A7101 81205	1	31-32-15 P061-01/ /	YC030-YM670
P061-02	9	964-0401-016 RCPT-DATA TRANSFER UNIT (EO 31-80019-8)	233A7101 81205	1	34-61-18 P061-02/ /	YC001-YC011
P061-02	9	964-0401-016 RCPT-DATA TRANSFER UNIT (EO 31-80019-8)	233A7101 81205	1	31-32-15 P061-02/ /	YC012-YC030
P061-02		964-0401-017 PNL-LOADER - AIRBORNE DATA	233A7101 97896	1	31-32-15 P061-02/ /	YK901-YM670
P061-07		MXP147-5 PNL-FIRST OBSERVER OXYGEN MASK STOWAGE	232A8100 F5341	1	23-51-02 P061-00/ /	YK907-YM670
P061-08		233A7206-1 PNL-FUEL TEST	233A7103 81205	1	28-23-11 P061-00/ /	YC031-YK906
P061-08		233A7206-2 PNL-FUEL TEST	233A7103 81205	1	28-23-11 P061-00/ /	YK907-YM670

EQUIPMENT LIST

D280A103

Section P061
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P063-00		S210A002 PNL - NGS PANEL	284A0810 81590	1	47-30-11 723/166/R010	YC031-YC050, YK906-YM670

EQUIPMENT LIST

D280A103

Section P063
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P091-00		S281A601-1120 PNL-POWER DISTRIBUTION NO.1	284A0206 07217	1	24-51-11 371/181/L016	YC001-YC011
P091-00		S281A601-1219 PNL-POWER DISTRIBUTION NO.1	284A0206 07217	1	24-51-11 371/181/L016	YC012-YC030
P091-00		S281A601-1233 PNL-POWER DISTRIBUTION NO.1	284A0206 07217	1	24-51-11 371/181/L016	YK901-YK906
P091-00		S281A601-7708 PNL-POWER DISTRIBUTION NO.1	284A0206 07217	1	24-51-11 371/181/L016	YK907, YL421
P091-00		S281A601-7233 PNL-POWER DISTRIBUTION NO.1	284A0206 07217	1	24-51-11 371/181/L016	YK908-YL401, YL422-YL430
P091-00		S281A601-7224 PNL-POWER DISTRIBUTION NO.1	284A0206 07217	1	24-51-11 371/181/L016	YM643-YM670

EQUIPMENT LIST

D280A103

Section P091
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P092-00		S281A601-2007 PNL-POWER DISTRIBUTION NO.2	284A0206 07217	1	24-51-21 371/181/R013	YC001-YC011
P092-00		S281A601-2437 PNL-POWER DISTRIBUTION NO.2	284A0206 07217	1	24-51-21 371/181/R013	YC012-YC030, YK901-YK906
P092-00		S281A601-8437 PNL-POWER DISTRIBUTION NO.2	284A0206 07217	1	24-51-21 371/181/R013	YC031-YC050, YK908-YK917, YL401, YL422- YL426
P092-00		S281A601-8702 PNL-POWER DISTRIBUTION NO.2	284A0206 07217	1	24-51-21 371/181/R013	YK907, YL421
P092-00		S281A601-8441 PNL-POWER DISTRIBUTION NO.2	284A0206 07217	1	24-51-21 371/181/R013	YK918-YK920, YL427-YL430
P092-00		S281A601-8438 PNL-POWER DISTRIBUTION NO.2	284A0206 07217	1	24-51-21 371/181/R013	YM643-YM670

EQUIPMENT LIST

D280A103

Section P092
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00001	1	S280W555-705 COMPONENT-RESISTOR	81205	1	34-41-11 E003-01/ /	YC001-YC030, YK901-YM670
R00003	1	S280W555-753 COMPONENT-DIODE	81205	1	34-41-11 E003-01/ /	YC001-YC007
R00005	1	S280W555-753 COMPONENT-DIODE	81205	1	34-41-11 E003-01/ /	YC003-YC007
R00007	1	S280W555-753 COMPONENT-DIODE	81205	1	34-41-11 E003-01/ /	YC003-YC007
R00009		SD167A RLY-CROSS BUS TIE	S2814601 OVMA8	1	24-32-11 P091-00/ /	ALL
R00011		BACR13CG2AB RLY-GROUND REFUELING POWER CONTROL	233A5220 81205	1	28-44-11 P006-00/ /	ALL
R00018		KDA-E4F RLY-TANK 1 AFT BOOST PUMP	S281A601 07217	1	28-23-11 P092-00/ /	YC001-YC030
R00018		S283A004-5 RLY-TANK 1 AFT BOOST PUMP	S281A601 58657	1	28-23-11 P092-00/ /	YC031-YC050, YK908-YL401, YL422-YM670
R00018		KDA-E4F RLY-TANK 1 AFT BOOST PUMP	S281A601 58657	1	28-23-11 P092-00/ /	YK901-YK907, YL421
R00019		KDA-E4F RLY-TANK 1 FWD BOOST PUMP	S281A601 07217	1	28-23-11 P091-00/ /	YC001-YC030
R00019		S283A004-5 RLY-TANK 1 FWD BOOST PUMP	S281A601 58657	1	28-23-11 P091-00/ /	YC031-YC050, YK908-YL401, YL422-YM670
R00019		KDA-E4F RLY-TANK 1 FWD BOOST PUMP	S281A601 58657	1	28-23-11 P091-00/ /	YK901-YK907, YL421
R00020		KDA-E4F RLY-TANK 2 AFT BOOST PUMP	S281A601 07217	1	28-23-11 P091-00/ /	YC001-YC030
R00020		S283A004-5 RLY-TANK 2 AFT BOOST PUMP	S281A601 58657	1	28-23-11 P091-00/ /	YC031-YC050, YK908-YL401, YL422-YM670
R00020		KDA-E4F RLY-TANK 2 AFT BOOST PUMP	S281A601 58657	1	28-23-11 P091-00/ /	YK901-YK907, YL421
R00021		KDA-E4F RLY-TANK 2 FORWARD BOOST PUMP	S281A601 07217	1	28-23-11 P092-00/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section R00000

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00021		S283A004-5 RLY-TANK 2 FORWARD BOOST PUMP	S281A601 58657	1	28-23-11 P092-00/ /	YC031-YC050, YK908-YL401, YL422-YM670
R00021		KDA-E4F RLY-TANK 2 FORWARD BOOST PUMP	S281A601 58657	1	28-23-11 P092-00/ /	YK901-YK907, YL421
R00025		BACR13CG2AB RELAY-NO SMOKING	69-73627 81205	1	33-25-11 P006-00/ /	YC001-YC007
R00025		BACR13CG2AB RELAY-NO SMOKING	233A5220 81205	1	33-25-11 P006-00/ /	YC008-YM670
R00026		BACR13CG2AB RLY-FASTEN BELTS	69-73627 81205	1	33-25-11 P006-00/ /	YC001-YC007
R00026		BACR13CG2AB RLY-FASTEN BELTS	233A5220 81205	1	33-25-11 P006-00/ /	YC008-YM670
R00029		KD-D4N RLY-NORMAL EXHAUST FAN CONTROL	S281A601 81205	1	21-27-21 P091-00/ /	ALL
R00030		KD-D4N RLY-ALTERNATE EXHAUST FAN CONTROL	S281A601 81205	1	21-27-21 P092-00/ /	ALL
R00033		10-60450-6 RLY-MASTER TEST	233A5201 81205	1	33-18-11 P006-00/ /	YC001-YC007
R00033		10-60450-6 RLY-MASTER TEST	233A5220 81205	1	33-18-11 P006-00/ /	YC008-YM670
R00034		10-60450-1 RLY-MASTER DIM	233A5201 81205	1	33-18-11 P006-00/ /	YC001-YC007
R00034		10-60450-1 RLY-MASTER DIM	233A5220 81205	1	33-18-11 P006-00/ /	YC008-YM670
R00047		BACR13CG2AB RLY-ELECTRICAL PANEL SENSING	TBD-0000 81205	1	33-29-11 P006-00/ /	YC001-YC007
R00047		BACR13CG2AB RLY-ELECTRICAL PANEL SENSING	233A5220 81205	1	33-29-11 P006-00/ /	YC008-YM670
R00054		KDA-E4F RLY-CENTER LEFT BOOST PUMP	S281A601 07217	1	28-23-11 P091-00/ /	YC001-YC030
R00054		S283A004-5 RLY-CENTER LEFT BOOST PUMP	S281A601 58657	1	28-23-11 P091-00/ /	YC031-YC050, YK908-YL401, YL422-YM670

EQUIPMENT LIST

D280A103

Section R00000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00054		KDA-E4F RLY-CENTER LEFT BOOST PUMP	S281A601 58657	1	28-23-11 P091-00/ /	YK901-YK907, YL421
R00055		KDA-E4F RLY-CENTER RIGHT BOOST PUMP	S281A601 07217	1	28-23-11 P092-00/ /	YC001-YC030
R00055		S283A004-5 RLY-CENTER RIGHT BOOST PUMP	S281A601 58657	1	28-23-11 P092-00/ /	YC031-YC050, YK908-YL401, YL422-YM670
R00055		KDA-E4F RLY-CENTER RIGHT BOOST PUMP	S281A601 58657	1	28-23-11 P092-00/ /	YK901-YK907, YL421
R00057		9274-6686 RLY-ALTERNATE TRAILING EDGE FLAP DOWN	284A1204 35344	1	27-53-12 J004-00/ /	YC001-YC030
R00057	1	9274-6686 RLY-ALTERNATE TRAILING EDGE FLAP DOWN	284A1204 35344	1	27-53-12 J004-00/ /	YC031-YM670
R00057	2	BACR13CC1 RLY-ALTERNATE TRAILING EDGE FLAP DOWN	284A1204 35344	1	27-53-12 J004-00/ /	YC031-YM670
R00058		9274-6686 RLY-ALTERNATE TRAILING EDGE FLAP UP	284A1204 35344	1	27-53-12 J004-00/ /	YC001-YC030
R00058	1	9274-6686 RLY-ALTERNATE TRAILING EDGE FLAP UP	284A1204 35344	1	27-53-12 J004-00/ /	YC031-YM670
R00058	2	BACR13CC1 RLY-ALTERNATE TRAILING EDGE FLAP UP	284A1204 35344	1	27-53-12 J004-00/ /	YC031-YM670
R00063		10-2262 RLY-PHASE SEQUENCE	65-52259 81205	1	27-41-11 J005-00/ /	ALL
R00064		9123-8071 RLY-STABILIZER TRIM CONTROL	284A1204 35344	1	27-41-11 J004-00/ /	ALL
R00066	1	6042H91 RLY-STABILIZER TRIM SAFETY	65-52259 15605	1	27-41-11 J005-00/ /	ALL
R00066	2	9123-8056 RLY-STABILIZER TRIM SAFETY	65-52259 35344	1	27-41-11 J005-00/ /	ALL
R00087		10-60450-1 RLY-AUXILIARY MASTER DIM	233A5201 81205	1	33-18-11 P006-00/ /	YC001-YC007
R00087		10-60450-1 RLY-AUXILIARY MASTER DIM	233A5220 81205	1	33-18-11 P006-00/ /	YC008-YM670

EQUIPMENT LIST

D280A103

Section R00000

Page 3 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00120		KDA-E4E RLY-CEILING LIGHT	S281A601 81205	1	33-22-11 P091-00/ /	ALL
R00184		KDA-E4F RLY-COMPRESSOR CONTROL	S281A601 81205	1	38-41-13 P091-00/ /	ALL
R00194		BR16-900B11-26VR0 RLY-WARNING CUTOUT	69-37334 82050	1	21-33-11 P005-16/ /	ALL

EQUIPMENT LIST

D280A103

Section R00100
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00215		69-60788-1 RESISTOR-DOME LIGHT DIMMING	233A3306 81205	1	33-14-12 P005-00/ /	ALL
R00263		BACR13CF2AB RLY-FLIGHT DIGITAL DATA ACQUISITION STAT	284A1224 81205	1	31-31-11 J024-00/ /	ALL

EQUIPMENT LIST

D280A103

Section R00200
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00315		402-188-1 RLY-LOCALIZER ANTENNA SWITCH 1	284A0847 00471	1	34-31-11 306/180/R021	ALL
R00316		402-188-1 RLY-LOCALIZER ANTENNA SWITCH 2	284A0847 00471	1	34-31-21 300/178/R022	ALL
R00317		9124-10400 RLY-SYSTEM A ELECTRIC HYDRAULIC PUMP	S281A601 35344	1	29-11-12 P092-00/ /	ALL
R00318		9124-10400 RLY-SYSTEM B ELECTRIC HYDRAULIC PUMP	S281A601 35344	1	29-11-12 P091-00/ /	ALL
R00322		TDH-7101-5001 RLY-AUTOMATIC OXYGEN DEPLOYMENT	284A1223 35344	1	35-21-11 J023-00/ /	ALL
R00323		TDH-7101-5001 RLY-MANUAL OXYGEN DEPLOYMENT	284A1223 35344	1	35-21-11 J023-00/ /	ALL
R00324		BACR13CG2AB RLY-OXYGEN INDICATOR	284A1223 81205	1	35-21-11 J023-00/ /	ALL
R00331		MS27418-2B RLY-CABIN AIR RECIRCULATE FAN	233A5201 96906	1	21-25-10 P006-00/ /	YC001-YC007
R00331		MS27418-2B RLY-CABIN AIR RECIRCULATE FAN	233A5220 96906	1	21-25-10 P006-00/ /	YC008-YM670
R00334		BACR13CF2AB RLY-FLAP LIMIT	65-73709 81205	1	33-25-11 P005-00/ /	ALL
R00340		RER60F10R0R RESISTOR	287A4123 81349	1	33-51-11 270/284/R010	ALL
R00347		KD-D4N RLY-NORMAL SUPPLY FAN CONTROL	S281A601 81205	1	21-27-31 P092-00/ /	ALL
R00353		TDH-8116-5000 RLY-HYDRAULIC SYSTEM B ENG DRIVEN PUMP	284A1214 81205	1	29-25-11 J011-00/ /	ALL
R00361		BACR13CD2 RLY-VIDEO SYSTEM NO.1	284A1203 81205	1	23-31-06 J020-0B/ /	ALL
R00373		KD-D4N RLY-ALTERNATE SUPPLY FAN CONTROL	S281A601 81205	1	21-27-31 P091-00/ /	ALL
R00384		BACR13CG2AB RLY-STABILIZER TRIM CUTOFF	65C30008 81205	1	22-13-11 P008-00/ /	ALL

EQUIPMENT LIST

D280A103

Section R00300
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00425		KA-X9E-004 RLY-CONTROL STAND-P8	284A1202 81205	1	33-11-33 J019-00/ /	ALL
R00427		KDA-E4E RLY-WINDOW LIGHT	S281A601 81205	1	33-21-11 P092-00/ /	ALL
R00429		MS27418-2B RLY-CABIN AIR RECIRCULATE	284A1222 96906	1	21-25-11 J022-00/ /	YC001-YL430
R00444		BACR13CF2AB RLY-TAXI LIGHT CONTROL	284A1204 81205	1	33-45-11 J004-00/ /	YK901-YM670
R00454		BACR13CF2AB RLY-SELCAL AURAL WARNING	284A1222 81205	1	23-22-11 J022-00/ /	ALL
R00475		172934-001 RLY-FMCS TRANSFER NO 1	284A0450 81840	1	34-61-12 E005-02/ /	ALL
R00476		172934-001 RLY-FMCS TRANSFER NO 2	284A0450 81840	1	34-61-12 E005-02/ /	ALL
R00477		JL-D4N RLY-T/R 1 SYNC LOCK LATCH	284A1222 35344	1	78-32-51 J022-00/ /	ALL
R00478		TDH-8050-1802P RLY-T/R 1 SYNC LOCK TIME DELAY	284A1222 35344	1	78-32-51 J022-00/ /	ALL
R00479		JL-D4N RLY-T/R 2 SYNC LOCK LATCH	284A1224 35344	1	78-32-61 J024-00/ /	ALL
R00480		TDH-8050-1802P RLY-T/R 2 SYNC LOCK TIME DELAY	284A1224 35344	1	78-32-61 J024-00/ /	ALL
R00489		KD-D4N RLY-AFT CARGO LOADER ENABLE M/W D176	S281A601 96906	1	25-51-21 P091-00/ /	ALL
R00495		BACR13CF2A RLY-T/R 1 SEQUENCE	284A1222 81205	1	78-32-51 J022-00/ /	ALL
R00496		BACR13CF2A RLY-T/R 2 SEQUENCE	284A1224 81205	1	78-32-61 J024-00/ /	ALL
R00498		S280W555-753 COMPONENT-DIODE	81205	1	21-31-22 E002-02/ /	YC001-YC030, YK901-YM670
R00499		S280W555-753 COMPONENT-DIODE	81205	1	21-31-22 E002-02/ /	YC001-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section R00400

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00501	1	S280W555-705 COMPONENT-RESISTOR	81205	1	34-41-11 E003-01/ /	YC001-YC030, YK901-YM670
R00508		S280W555-753 COMPONENT-DIODE	81205	1	21-61-11 E004-01/ /	YC001-YL430
R00509		S280W555-753 COMPONENT-DIODE	81205	1	21-61-13 E004-01/ /	YC001-YL430
R00510		S280W555-753 COMPONENT-DIODE	81205	1	21-61-14 E004-01/ /	YC001-YL430
R00516		S280W555-753 COMPONENT-DIODE	81205	1	21-61-11 E004-01/ /	YC001-YL430
R00517		S280W555-753 COMPONENT-DIODE	81205	1	21-61-13 E004-01/ /	YC001-YL430
R00518		S280W555-753 COMPONENT-DIODE	81205	1	21-61-14 E004-01/ /	YC001-YL430
R00519		S280W555-753 COMPONENT-DIODE	81205	1	21-61-11 E004-01/ /	YC001-YL430
R00520		S280W555-753 COMPONENT-DIODE	81205	1	21-61-13 E004-01/ /	YC001-YL430
R00521		S280W555-753 COMPONENT-DIODE	81205	1	21-61-14 E004-01/ /	YC001-YL430
R00550		BACR13CF2AB RLY-LCD BACK LIGHTING CONTROL	69-73627 81205	1	21-31-25 P006-00/ /	YC001-YC007
R00550		BACR13CF2AB RLY-LCD BACK LIGHTING CONTROL	233A5220 81205	1	21-31-25 P006-00/ /	YC008-YM670
R00554		S280W555-753 COMPONENT-DIODE	81205	1	21-42-11 J022/ /	ALL
R00555		S280W555-753 COMPONENT-DIODE	81205	1	21-42-11 J022/ /	ALL
R00556		BACR13CD2 RLY-MANUAL OVERRIDE	233A5201 81205	1	21-31-11 P006-00/ /	YC001-YC007
R00556		BACR13CD2 RLY-MANUAL OVERRIDE	233A5220 81205	1	21-31-11 P006-00/ /	YC008-YM670
R00557		BACR13CD2 RLY-AUTO FAIL 1	69-73627 81205	1	21-31-22 P006-00/ /	YC001-YC007

EQUIPMENT LIST

D280A103

Section R00500

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00557		BACR13CD2 RLY-AUTO FAIL 1	233A5220 81205	1	21-31-22 P006-00/ /	YC008-YM670
R00558		BACR13CD2 RLY-AUTO FAIL 2	69-73627 81205	1	21-31-23 P006-00/ /	YC001-YC007
R00558		BACR13CD2 RLY-AUTO FAIL 2	233A5220 81205	1	21-31-23 P006-00/ /	YC008-YM670
R00559		S280W555-753 COMPONENT-DIODE	81205	1	21-31-11 P005-00/ /	YC001-YC030, YK901-YM670
■ R00560		BACR13CG2AB RLY-DOOR AREA HEATER POWER	S281A601 81205	1	21-42-11 P091-00/ /	ALL
■ R00561		H-A3N RELAY - MAIN BUS 1 LOAD SHED	S281A601 7217	1	24-51-11 P091-00/ /	ALL
■ R00562		H-A3N RELAY, MAIN BUS 2 LOAD SHED	S281A601 7217	1	24-51-21 P092-00/ /	ALL
R00563		BACR13CG2AB RLY-ENGINE 2 RUNNING	284A1224 81205	1	73-22-31 J024-00/ /	ALL
R00564		BACR13CG2AB RLY-ENGINE 1 RUNNING	284A1222 81205	1	73-22-31 J022-00/ /	ALL
R00565		KL-D4N RLY-ENGINE 1 START LEVER CHANNEL B	284A1223 35344	1	76-21-11 J023-00/ /	ALL
R00566		KL-D4N RLY-ENGINE 1 START LEVER CHANNEL A	284A1222 35344	1	76-21-11 J022-00/ /	ALL
R00567		KL-D4N RLY-ENGINE 2 START LEVER CHANNEL B	284A1203 35344	1	76-21-21 J020-0B/ /	ALL
R00568		KL-D4N RLY-ENGINE 2 START LEVER CHANNEL A	284A1224 35344	1	76-21-21 J024-00/ /	ALL
R00575		X-D4N RLY-ENGINE 2 ALTERNATE POWER	284A1224 35344	1	73-22-11 J024-00/ /	ALL
R00576		X-D4N RLY-ENGINE 1 ALTERNATE POWER	284A1222 35344	1	73-22-11 J022-00/ /	ALL
R00581		9124-10400 RLY-VACUUM BLOWER	S281A601 81205	1	38-32-12 P091-00/ /	ALL
R00584		BACR13CG2AB RLY-AIR SENSING AIR GROUND SYSTEM 1	284A1222 81205	1	32-31-11 J022-00/ /	ALL

EQUIPMENT LIST

D280A103

Section R00500

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00585		BACR13CG2AB RLY-AIR SENSING AIR GROUND SYSTEM 2	284A1224 81205	1	32-31-12 J024-00/ /	ALL
R00587		BACR13CG2AB RLY-GROUND SENSING NOSE GEAR SYSTEM 1	284A1222 81205	1	32-31-11 J022-00/ /	ALL
R00588		BACR13CG2AB RLY-GROUND SENSING AIR/GROUND SYSTEM 2	284A1203 81205	1	32-31-11 J020-0B/ /	ALL
R00589		BACR13CG2AB RLY-GROUND SENSING AIR/GROUND SYSTEM 1	284A1222 81205	1	32-31-11 J022-00/ /	ALL
R00590	1	BACR13CG2AB RLY-GROUND SENSING AIR/GROUND SYSTEM 2	284A1203 81205	1	32-31-12 J020-0B/ /	ALL
R00591		BACR13CG2AB RLY-GROUND SENSING AIR/GROUND SYSTEM 2	284A1203 81205	1	32-31-12 J020-0B/ /	ALL
R00592		BACR13CG2AB RLY-GROUND SENSING AIR/GROUND SYSTEM 1	284A1222 81205	1	32-31-11 J022-00/ /	ALL
R00593		BACR13CG2AB RLY-GROUND SENSING AIR/GROUND SYSTEM 1	284A1222 81205	1	32-31-11 J022-00/ /	ALL
R00594		BACR13CG2AB RLY-GROUND SENSING AIR/GROUND SYSTEM 1	284A1222 81205	1	32-31-11 J022-00/ /	ALL
R00595		BACR13CG2AB RLY-GROUND SENSING NOSE GEAR SYSTEM 2	284A1203 81205	1	32-31-12 J020-0B/ /	ALL
R00596		BACR13CG2AB RLY-GROUND SENSING NOSE GEAR SYSTEM 2	284A1203 81205	1	32-31-12 J020-0B/ /	ALL

EQUIPMENT LIST

D280A103

Section R00500
Page 3 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00603		H-A3N RELAY-GALLEY BUS A LOAD SHED	S281A601 7217	1	25-31-11 P092-00/ /	ALL
R00604		H-A3N RELAY-GALLEY BUS B LOAD SHED	S281A601 7217	1	25-31-11 P092-00/ /	ALL
R00605		H-A3N RELAY-GALLEY BUS D LOAD SHED	S281A601 7217	1	25-31-11 P091-00/ /	ALL
R00606		H-A3N RELAY- GALLEY BUS C LOAD SHED	S281A601 7217	1	25-31-11 P091-00/ /	ALL
R00607		HT-A4N RELAY- GND SERVICE BUS 1	S281A601 7217	1	24-52-11 P091-00/ /	ALL
R00608		HT-A4N RELAY- GND SERVICE BUS 2	S281A601 7217	1	24-52-11 P092-00/ /	ALL
R00611		S280W555-753 COMPONENT-DIODE	81205	1	32-42-11 P006-00/ /	ALL
R00612		S280W555-753 COMPONENT-DIODE	81205	1	32-42-11 P006-00/ /	ALL
R00613		BACR13CE2 RLY-PARK BRAKE CLOSE SENSOR	284A1224 81205	1	32-44-11 J024-00/ /	ALL
R00622		HT-A4N RLY-TRANSFORMER RECTIFIER 3 TRANSFER	S281A601 25344	1	24-32-11 P092-00/ /	ALL
R00623		K-D4N RELAY-CARGO COMPT LT CONT-FWD	S281A601 35344	1	33-36-11 P092-00/E08/163	ALL
R00624		K-D4N RELAY-CARGO COMPT LT CONT-AFT	S281A601 35344	1	33-36-12 P092-00/E08/163	ALL
R00625		BACR13CF2A RLY-HYDRAULIC STANDBY SHUTOFF VALVE IND	284A1214 81205	1	29-25-11 J011-00/ /	ALL
R00626		BACR13CE2 RLY-OUTBOARD ANTISKID SENSOR	284A1224 81205	1	32-41-11 J024-00/ /	ALL
R00627		BACR13CE2 RLY-ALTERNATE ANTISKID SENSOR	284A1222 81205	1	32-41-11 J022-00/ /	ALL
R00628		BACR13CE2 RLY-INBOARD ANTISKID SENSOR	284A1222 81205	1	32-41-11 J022-00/ /	ALL
R00634		BACR13CG2AB RLY-28V DC GROUND SERVICE BUS	233A5201 81205	1	24-61-11 P006-00/ /	YC001-YC007

EQUIPMENT LIST

D280A103

Section R00600

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00634		BACR13CG2AB RLY-28V DC GROUND SERVICE BUS	233A5220 81205	1	24-61-11 P006-00/ /	YC008-YM670
R00643		9124-10400 RLY-STANDBY HYDRAULIC PUMP	286A8538 35344	1	29-22-11 P092-00/ /	ALL
R00644		BACR13CD2 RLY-RECIRCULATE FAN SWITCH BYPASS	284A1224 81205	1	21-25-11 J024-00/ /	YC001-YC030
R00644		BACR13CE2 RLY-RECIRCULATE FAN SWITCH BYPASS	284A1224 81205	1	21-25-11 J00024/ /	YC031-YM670
R00645		TDH-7101-3003 RLY-SUPPLY SYSTEM CONTROL INTERRUPT	284A1203 58657	1	21-27-31 J020-0B/ /	ALL
R00648		BACR13CG2AB RLY-SMOKE CONTROL	284A1224 81205	1	21-43-21 J024-00/ /	ALL
R00649		TDH-8127-3003 RLY-OVERBOARD EXHAUST VALVE OPEN CONTROL	284A1224 58657	1	21-43-21 J024-00/ /	ALL
R00650		BACR13CF2AB RLY-OVERBOARD EXHAUST VALVE OPEN ENABLE	284A1224 81205	1	21-43-21 J024-00/ /	ALL
R00655		S280W555-753 COMPONENT-DIODE	81205	1	21-27-21 261/280/R10	YC001-YC030, YK901-YM670
R00656		S280W555-753 COMPONENT-DIODE	81205	1	21-27-21 261/280/R8	YC001-YC030, YK901-YM670
R00660		BACR13CF2AB RELAY MUX/AEP,PWR	284A1224 81205	1	23-34-01 J024-00/ /	ALL
R00665		S280W555-706 COMPONENT-DIODE	81205	1	21-51-16 537/160/L028	YM643-YM670
R00666		S280W555-707 COMPONENT-DIODE	81205	1	21-51-26 537/159/L028	YM643-YM670
R00667		S280W555-706 COMPONENT-DIODE	81205	1	21-51-26 537/160/R028	YM643-YM670
R00668		S280W555-707 COMPONENT-DIODE	81205	1	21-51-26 537/159/R028	YM643-YM670
R00669		1N1190 DIODE-FUEL SHUT OFF VALVE BUS BLOCKING	233A5201 81205	1	28-21-21 P006-00/ /	YC001-YC007
R00669		1N1190 DIODE-FUEL SHUT OFF VALVE BUS BLOCKING	233A5220 81205	1	28-21-21 P006-00/ /	YC008-YM670

EQUIPMENT LIST

D280A103

Section R00600

Page 2

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00671		S280W555-751 COMPONENT - DIODE	81205	1	23-31-06 E001-03/ /	YC001-YC050
R00672		S280W555-751 COMPONENT - DIODE	81205	1	23-31-06 E001-03/ /	ALL
R00674		S280W555-751 COMPONENT - DIODE	81205	1	23-31-06 E001-03/ /	YC001-YC050
R00675		S280W555-751 COMPONENT - DIODE	81205	1	23-34-01 E008-01/ /	YC001-YC050
R00675		S280W555-751 COMPONENT - DIODE	81205	1	23-34-01 E001-03/ /	YK901-YM670
R00676		S280W555-751 COMPONENT - DIODE	81205	1	23-34-01 E008-01/ /	YC001-YC050
R00676		S280W555-751 COMPONENT - DIODE	81205	1	23-34-01 E001-03/ /	YK901-YM670
R00677		S280W555-751 COMPONENT - DIODE	81205	1	23-34-01 E008-01/ /	YC001-YC050
R00677		S280W555-751 COMPONENT - DIODE	81205	1	23-34-01 E001-03/ /	YK901-YM670
R00678		BACR13CD2 RLY-EQUIP COOLING EXHAUST SWITCH DISRUPT	284A1224 81205	1	21-27-21 J024-00/ /	ALL
R00679		S280W555-753 COMPONENT-DIODE	81205	1	21-27-21 J024-00/ /	ALL
R00680		S280W555-753 COMPONENT-DIODE	81205	1	21-27-21 J024-00/ /	ALL
R00681		S280W555-753 COMPONENT-DIODE	81205	1	21-27-21 J024-00/ /	ALL
R00682		BACR13CD2 RLY-EQUIP COOLING SUPPLY SWITCH DISRUPT	284A1203 81205	1	21-27-31 J020-0B/ /	ALL
R00683		S280W555-753 COMPONENT-DIODE	81205	1	21-27-31 J020-0B/ /	ALL
R00684		S280W555-753 COMPONENT-DIODE	81205	1	21-27-31 J020-0B/ /	ALL
R00685		S280W555-753 COMPONENT-DIODE	81205	1	21-27-31 J020-0B/ /	ALL

EQUIPMENT LIST

D280A103

Section R00600

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00686		S280W555-753 COMPONENT-DIODE	81205	1	78-32-51 J022-00/ /	ALL
R00687		S280W555-753 COMPONENT-DIODE	81205	1	78-32-51 J022-00/ /	ALL
R00688		S280W555-753 COMPONENT-DIODE	81205	1	78-32-61 J024-00/ /	ALL
R00689		S280W555-753 COMPONENT-DIODE	81205	1	78-32-61 J024-00/ /	ALL
R00690		S280W555-753 COMPONENT-DIODE	81205	1	76-21-11 264/282/R005	YC001-YC030, YK901-YM670
R00691		S280W555-753 COMPONENT-DIODE	81205	1	76-21-21 261/ /	ALL
R00692		S280W555-753 COMPONENT-DIODE	81205	1	28-21-11 264/280/R6	ALL
R00693		S280W555-753 COMPONENT-DIODE	81205	1	28-21-11 264/280/R6	ALL

EQUIPMENT LIST

D280A103

Section R00600
Page 4 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00708		BACR13CG2AB RLY-SPEED BRAKE ACTUATOR ENABLE	284A1203 81205	1	27-62-11 J020-0B/ /	ALL
R00709		BACR13CG2AB RLY-R/A < 10FT B	284A1222 81205	1	27-62-11 J022-00/ /	ALL
R00710		BACR13CG2AB RLY-R/A < 10FT A	284A1203 81205	1	27-62-11 J020-0B/ /	ALL
R00711		BACR13CE2 RLY-ASB ARMED	284A1203 81205	1	27-62-11 J020-0B/ /	ALL
R00712		JLD4N RLY-LATCH	284A1203 81205	1	27-62-11 J020-0B/ /	ALL
R00713		BACR13CE2 RLY-3 SECOND SHUTOFF	284A1203 81205	1	27-62-11 J020-0B/ /	ALL
R00714		BACR13CE2 RLY-3 SECOND ON	284A1203 81205	1	27-62-11 J020-0B/ /	ALL
R00720		S280W555-751 COMPONENT - DIODE	81205	1	23-31-06 E001-03/ /	YC001-YC050
R00726		S280W555-753 COMPONENT-DIODE	81205	1	29-25-11 J011-00/ /	ALL
R00727		S280W555-753 COMPONENT-DIODE	81205	1	29-25-11 J011-00/ /	ALL
R00728		S280W555-753 COMPONENT-DIODE	81205	1	29-25-11 J011-00/ /	ALL
R00733		S280W555-751 COMPONENT - DIODE	81205	1	23-34-01 E008-01/ /	YC001-YC050
R00733		S280W555-751 COMPONENT - DIODE	81205	1	23-34-01 E001-03/ /	YK901-YM670
R00735		BACR13CD2 RELAY-DATA LOAD ENABLE	284A1203 81205	1	49-62-11 J020-00/ /	ALL
R00737		BACR13CG2AB RLY 2-ENGINE 1 RUNNING	284A1222 81205	1	73-22-31 J022-00/ /	ALL
R00738		BACR13CG2AB RLY 2-ENGINE 2 RUNNING	284A1224 81205	1	73-22-31 J024-00/ /	ALL
R00740		S280W555-751 COMPONENT - DIODE	81205	1	23-32-12 E001-03/ /	YC008-YC050

EQUIPMENT LIST

D280A103

Section R00700

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00742		BACR13CG2AB RLY-OVERWING FLIGHT LOCK-LEFT	284A1222 81205	1	52-71-13 J022-00/ /	ALL
R00743		BACR13CG2AB RLY-OVERWING FLIGHT LOCK-RIGHT	284A1224 81205	1	52-71-14 J024-00/ /	ALL
R00744		S280W555-704 COMPONENT-RESISTOR	81205	1	32-64-21 P005-00/ /	YC001-YC030, YK901-YM670
R00745		BACR13CE2 RLY-TERRAIN DISPLAY	284A1224 81205	1	34-49-11 J024-00/ /	ALL
R00746		BACR13CE2 RLY-TERRAIN DISPLAY	284A1222 81205	1	34-49-11 J022-00/ /	ALL
R00749		S280W555-752 DIODE-ZENER	81205	1	52-71-13 J022-00/ /	YC001-YL430
R00749		S280W555-752 COMPONENT- DIODE,ZENER	81205	1	52-71-13 J022-00/ /	YM643-YM670
R00750		S280W555-752 COMPONENT-DIODE,ZENER	81205	1	52-71-14 J024-00/ /	YC001-YC003
R00750		S280W555-752 COMPONENT-DIODE, ZENER	81205	1	52-71-14 J024-00/ /	YC004-YC050
R00750		S280W555-752 COMPONET-DIODE, ZENER	81205	1	52-71-14 J024-00/ /	YK901-YM670
R00751		S280W555-752 DIODE-ZENER	81205	1	52-71-13 J022-00/ /	YC001-YL430
R00752		S280W555-752 COMPONENT-DIODE, ZENER	81205	1	52-71-14 J024-00/ /	YC001-YC050
R00752		S280W555-752 COMPONET-DIODE, ZENER	81205	1	52-71-14 J024-00/ /	YK901-YL430
R00779		TDH-8127-3003 RLY-CVR SENSE ENGINE RUN	284A1222 35344	1	23-71-01 J022-00/ /	ALL
R00780	9	BACR13CF2AB RLY-CVR SWITCH LATCHING	284A1222 81205	1	23-71-01 J022-00/ /	YC001-YC007
R00780		BACR13CF2AB RLY-CVR SWITCH LATCHING	284A1222 81205	1	23-71-01 J022-00/ /	YC008-YM670
R00782		TDH-8119-1002 RELAY-10 SECOND DELAY	284A1214 TBD	1	27-31-11 J011-00/ /	ALL

EQUIPMENT LIST

D280A103

Section R00700
Page 2 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00813	9	TDH-1852-3002 RELAY-30SECOND DELAY	SB271220	1	27-31-37 J011-00/ /	YC001-YC007
R00813		TDH-1852-3002 RELAY-30SECOND DELAY	284A1214	1	27-31-37 J011-00/ /	YC008-YM670
R00850	9	KA-D9F-005 RLY-STAB TRIM INTERLOCK	284A1214 58657	1	27-41-12 802/292/R036	YC001-YC011
R00850		BACR13CG2AB RLY-STAB TRIM INTERLOCK	284A1214 81205	1	27-41-12 J011-00/ /	YC012-YM670
R00897	9	10-60450-6 RELAY - AUTOSTOW RETRACT (APB 0802664)	233A5220	1	27-62-41 P006-00/ /	YC001-YC010, YC012-YC030
R00897		10-60450-6 RELAY-AUTOSTOW RETRACT	233A5220	0	27-62-41 P006-00/ /	YM643-YM670
R00898		S280W555-753 COMPONENT-DIODE	81205	1	26-16-21 E002-02/ /	YC028-YC030, YK901-YM670
R00899		S280W555-753 COMPONENT-DIODE	81205	1	21-31-22 J020/ /	YC028-YM670

EQUIPMENT LIST

D280A103

Section R00800

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00900		S280W555-753 COMPONENT-DIODE	81205	1	21-31-23 J020/ /	YC028-YM670
R00903		BACR13CG2AB RELAY-ROD 750 CARGO FIRE RELAY 1	284A1203 81205	1	21-31-22 J020-00/ /	YC028-YM670
R00904		BACR13CG2AB RELAY-ROD 750 CARGO FIRE RELAY 2	284A1203 81205	1	21-31-23 J020-00/ /	YC028-YM670
R00915		S280W555-751 COMPONENT - DIODE	81205	1	23-32-14 J004-00/ /	YK901-YM670
R00916	9	HTC7N060 RLY-XFR BUS 1 IFE/PASS SEAT SW CTRL RLY	233A5220 81205	1	24-28-41 P006-00/ /	YC001-YC030
R00916		HTC7N060 RLY-XFR BUS 1 IFE/PASS SEAT SW CTRL RLY	233A5220 81205	1	24-28-41 P006-00/ /	YC031-YM670
R00917	9	HTC7N060 RLY-XFR BUS 2 IFE/PASS SEAT SW CTRL RLY	233A5220 81205	1	24-28-41 P006-00/ /	YC001-YC030
R00917		HTC7N060 RLY-XFR BUS 2 IFE/PASS SEAT SW CTRL RLY	233A5220 81205	1	24-28-41 P006-00/ /	YC031-YM670
R00918		BACR13CG2AB RELAY-IFE/PASS SEAT CONTROL	233A5220 81205	1	24-28-41 P006-00/ /	YC031-YM670
R00919	9	BACR13CF2AB RLY - RPL CONT SYS A HYD (SB 27-1253)	233A5220	1	27-25-11 P006-00/ /	YC001-YC030
R00919		BACR13CF2AB RLY - RPL CONTROL SYSTEM A HYD	233A5220	1	27-25-11 P006-00/ /	YC030-YM670
R00920	9	BACR13CF2AB RLY - RPL CONT SYS B HYD (SB 27-1253)	233A5220	1	27-25-11 P006-00/ /	YC001-YC030
R00920		BACR13CF2AB RLY - RPL CONTROL SYSTEM B HYD	233A5220	1	27-25-11 P006-00/ /	YC030-YM670
R00921		S280W555-753 COMPONENT-DIODE-RPL CONTROL SYS A HYD		1	27-25-11 E001-01/ /	YC001-YC029
R00921		S280W555-753 COMPONENT-DIODE-RPL CONTROL SYS A HYD		1	27-25-11 */*/	YC030-YC050, YM643-YM670
R00921		S280W555-753 COMPONENT-DIODE-RPL CONTROL SYS A HYD		1	27-25-11 / /	YK901-YL430
R00922		S280W555-753 COMPONENT-DIODE-RPL CONTROL SYS A HYD		1	27-25-11 E001-01/ /	YC001-YC011

EQUIPMENT LIST

D280A103

Section R00900

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00922		S280W555-753 COMPONENT-DIODE-RPL CONTROL SYS A HYD		1	27-25-11 E001/ /	YC012-YC029
R00922		S280W555-753 COMPONENT-DIODE-RPL CONTROL SYS A HYD		1	27-25-11 */*/*	YC030-YC050, YM643-YM670
R00922		S280W555-753 COMPONENT-DIODE-RPL CONTROL SYS A HYD		1	27-25-11 / /	YK901-YL430
R00923		S280W555-751 COMPONENT-DIODE, VPR SUPPRESSION	81205	1	23-31-06 J020/ /	YC031-YM670
R00924		BACR13CD2 RLY-VIDEO DISCRETE	284A1204 81205	1	23-32-14 J004-00/ /	YK901-YM670
R00932		S280W555-751 COMPONENT - DIODE	81205	1	31-62-41 E003-01/ /	YK901-YM670
R00933		S280W555-751 COMPONENT - DIODE	81205	1	31-62-41 E003-01/ /	YK901-YM670
R00934		TDH-8116-1502 RELAY-TIME DELAY	284A1203 58657	1	28-23-11 J020-0B/166/L025	YC031-YM670
R00935		TDH-8116-1502 RELAY-TIME DELAY	284A1204 58657	1	28-23-11 J004-00/167/R025	YC031-YM670
R00936		BACR13CJ2 RELAY-115VAC	284A1203 81205	1	28-23-11 J020-0B/166/L025	YC031-YM670
R00937		BACR13CJ2 RELAY-115VAC	284A1204 81205	1	28-23-11 J004-00/167/R025	YC031-YM670
R00938		S280W555-753 COMPONENT-DIODE	81205	1	28-43-11 E002-01/ /	YC031-YM670
R00939		S280W555-753 COMPONENT-DIODE	81205	1	28-43-11 E004-02/ /	YK901-YM670
R00945		BACR13CE2 RELAY-FWD FIRE ALARM LATCH	284A1224	1	21-25-11 J00024/ /	YC031-YM670
R00946		BACR13CE2 RELAY-AFT FIRE ALARM LATCH	284A1224	1	21-25-11 J00024/ /	YC031-YM670
R00947		S280W555-753 COMPONENT-DIODE	81205	1	21-25-11 J00024/ /	YK901-YM670
R00948		S280W555-753 COMPONENT-DIODE	81205	1	21-25-11 J00024/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section R00900

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00949		BACR13CG2AB RELAY-EXHAUST SYSTEM CONTROL INTERRUPT	284A1224	1	21-27-21 J00024/ /	YC031-YM670
R00951		BACR13CD2 RLY-CTR TANK REFUEL VALVE	284A1203 81205	1	47-30-11 J00020/ /	YC031-YC050, YK906-YM670
R00952		S280W555-753 COMPONENT-DIODE	81205	1	21-43-21 J00024/ /	YK901-YM670
R00953		S280W555-753 COMPONENT-DIODE	81205	1	21-43-21 J00024/ /	YK901-YM670
R00958		S280W555-753 COMPONENT-DIODE	81205	1	21-43-21 J00024/ /	YK901-YM670
R00962		MS27418-2A RELAY-SECONDARY BOOST PUMP CTR TANK L	284A0822 96906	1	28-23-11 371/166/L035	YK907-YM670
R00963		MS27418-2A RELAY-SECONDARY BOOST PUMP CTR TANK R	284A0822 96906	1	28-23-11 361/166/R036	YK907-YM670
R00964		BACR13CG2AB RLY-SPOILER SOV A	284A1239 81205	1	27-62-11 J039/ /	YK907-YL430
R00965		BACR13CG2AB RLY-SPOILER SOV B	284A1239 81205	1	27-62-11 J039/ /	YK907-YL430
R00966		BACR13CG2AB RLY-SPOILER SOV PWR	284A1239 81205	1	27-62-11 J039/ /	YK907-YL430
R00967		BACR13CG2AB RLY-SPOILER SOV RAISE	284A1239 81205	1	27-62-11 J039/ /	YK907-YL430
R00968		BACR13CG2AB RLY-SPD BK GND PROX	284A1239 81205	1	27-62-11 J039/ /	YK907-YL430
R00969		TDH-8050-3001P RLY-SPOILER SUP TRAVEL ANNUN	284A1239 58657	1	27-62-11 J039/ /	YK907-YL430
R00970		BACR13CG2AB RLY-SPD BRK HNDL ANNUN	284A1239 81205	1	27-62-11 J039/ /	YK907-YL430
R00985		287A4402-1 RESISTOR - ASSY	81205	1	47-30-11 721/204/R035	YC031-YC050, YK906-YM670
R00986		287A4402-1 RESISTOR - ASSY	81205	1	47-30-11 721/204/R035	YC031-YC050, YK906-YM670
R00987		287A4402-1 RESISTOR - ASSY	81205	1	47-30-11 721/204/R035	YC031-YC050, YK906-YM670

EQUIPMENT LIST

D280A103

Section R00900

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00988	1	287A2369-4 RESISTOR	81205	1	78-32-51 J022-00/ /	YK901-YM670
R00989		287A2369-5 RESISTOR ASSY	81205	1	78-32-61 J024-00/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section R00900

Page 4 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R01001		BACR13CFCAB RELAY-NGS ALT PWR	284A1224	0	47-30-11 J24/ /	YC031-YC050, YK906-YM670
R01010		S280W555-753 COMPONENT-DIODE	81205	1	27-62-11 J046-00/ /	YK907-YL430
R01011		S280W555-753 COMPONENT-DIODE	81205	1	27-62-11 J046-00/ /	YK907-YL430
R01013		S280W555-706 COMPONENT-RESISTOR	81205	1	28-21-11 P005-00/ /	YK902-YK906
R01014		S280W555-706 COMPONENT-RESISTOR	81205	1	28-21-11 P005-00/ /	YK902-YK906
R01015		S280W555-706 COMPONENT-RESISTOR	81205	1	28-22-11 P005-00/ /	YK902-YK906
R01021		S280W555-753 COMPONENT - DIODE	81205	1	33-25-11 E003-02/ /	YK907-YL430
R01022		S280W555-753 COMPONENT - DIODE	81205	1	27-62-11 E003-02/ /	YK907-YL430
R01044		S280W555-751 COMPONENT-DIODE	81205	1	31-53-11 J046-00/ /	YK911-YL401, YL424-YL430, YM645-YM670
R01049		S280W555-751 COMPONENT-DIODE	81305	1	21-33-11 J046-00/ /	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670

EQUIPMENT LIST

D280A103

Section R01000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R01999		S280W555-751 COMPONENT-DIODE	81205	1	31-53-11 J046-00/ /	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670

EQUIPMENT LIST

D280A103

Section R01900
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R09001	9	BACR13CE2 RLY-TERRAIN/WX (737-EB34-0155)	CUSTOMER 81205	1	34-49-11 J00022/ /	YC003-YC006
R09002	9	BACR13CE2 RLY-TERRAIN/WX (737-EB34-0155)	CUSTOMER 81205	1	34-49-11 J00024/ /	YC003-YC006

EQUIPMENT LIST

D280A103

Section R09000
Page 1 End
Nov 11/2008



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00001		572757-1 SWITCH-LEFT TURBINE INLET OVHT	213A1002 70210	1	21-51-15 567/156/L034	YM643-YM670
S00002		572756-1 SW-LEFT COMPRESSOR DISCHARGE OVHT	213A1002 70210	1	21-51-15 576/158/L024	ALL
S00003		10-60924-1 SW-CONT CABIN DUCT OVHT 250 DEG F	214A1002 81205	1	21-51-15 370/196/L056	YM643-YM670
S00004		572757-1 SWITCH-RIGHT TURBINE INLET OVHT	213A1002 70210	1	21-51-25 575/158/R036	YM643-YM670
S00005		572756-1 SW RIGHT COMPRESSOR DISCHARGE OVHT	213A1001 70210	1	21-51-25 577/157/R026	ALL
S00006		10-60924-1 SW-PASS CABIN DUCT OVHT 250 DEG F	214A2001 81205	1	21-51-25 531/299/R010	YM643-YM670
S00007		15AT48 SW-EMERGENCY EXIT LT	65-73709 91929	1	33-51-11 P005-00/ /	ALL
S00008		10-61318-31 SW-FIRE ENG 1	69-37307 81205	1	26-21-11 P008-01/220/000	ALL
S00009		10-61318-32 SW-FIRE ENG 2	69-37307 81205	1	26-21-11 P008-01/220/000	ALL
S00010		10-61318-29 SW-FIRE APU	69-37307 81205	1	26-21-11 P008-01/220/000	ALL
S00011		S210T130-18 SW-CONTROL CABIN DUCT OVHT 190F	214A1002 81205	1	21-61-21 373/196/L058	YM643-YM670
S00012		S231T290-1001 SW-GRD SERVICE	61-30012 81205	1	24-23-51 / /	ALL
S00014		S210T130-18 SW-PASSENGER CABIN DUCT OVHT 190F	214A2001 81205	1	21-61-22 532/299/R010	YM643-YM670
S00015		MS24523-26 SW-APU BOTTLE DISCHARGE	96906	1	26-21-11 P028-00/ /	YC001-YC030
S00016		25EN52-1 SW-REMOTE APU FIRE		1	26-21-11 P028-00/ /	YC001-YC030
S00019		4HS9-118 SW-APU HORN CUTOUT	91929	1	26-11-31 P028-00/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section S00000

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00020		975-0172-006 SW-ENG 1 BLEED O/H (737-800)	312A1050 97896	1	36-11-11 574/199/L184	YC001-YK912, YK918-YK919, YL401-YL429
S00020		975-0172-006 SW-ENG 1 BLEED O/H (737-700)	312A1050 97896	1	36-11-11 574/199/L184	YM643-YM652
S00021		975-0172-006 SW-ENG 2 BLEED O/H (737-800)	312A1050 97896	1	36-11-11 574/199/R184	YC001-YK912, YK918-YK919, YL401-YL429
S00021		975-0172-006 SW-ENG 2 BLEED O/H (737-700)	312A1050 97896	1	36-11-11 574/199/R184	YM643-YM652
S00022		10-61329-34 SW-RIGHT WINDSHIELD WIPER CONTROL	233A3101 81205	1	30-42-11 P005-00/ /	ALL
S00032		D20011-01 SW-GRD CREW CALL	233A3301 81640	1	23-43-11 P005-00/ /	ALL
S00033		D204W3-JA SW-CAPTAIN CALL	284A1807 81640	1	23-43-11 P019-00/ /	ALL
S00036		D20011-01 SW-ATTENDANTS CALL	233A3301 81640	1	23-42-11 P005-00/ /	ALL
S00045		2TL1-10 SW-NO SMOKING	65-73709 91929	1	33-25-11 P005-00/ /	ALL
S00046		2TL1-10 SW-FASTEN BELTS	65-73709 91929	1	33-25-11 P005-00/ /	ALL
S00049		10-61241-1 SW-STANDBY SYSTEM RESERVOIR	276A3100 81205	1	29-31-11 715/171/00	ALL
S00050		MS24523-23 SW-INPH CUTOFF P5 PNL	233A3301 96906	1	23-41-11 P005-00/ /	ALL
S00057		MS24523-23 SW-RED ANTI-COLLISION LIGHTS	233A3101 96906	1	33-44-11 P005-00/ /	ALL
S00058		MS24525-21 SW-POS LT	233A3303 96906	1	33-43-11 P005-00/ /	ALL
S00059		MS24524-23 SW-EQUIP COOLING	233A3101 96906	1	21-27-21 P005-00/ /	ALL
S00061		A3-1080 SW-NOSE GEAR TAXI LT	233A3303 81640	1	33-45-11 P005-00/ /	ALL

EQUIPMENT LIST

D280A103

Section S00000

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00062		MS24524-23 SW-WHEEL WELL LT	233A3303 96906	1	33-32-11 P005-00/ /	ALL
S00063		MS24523-23 SW-NOSE WHL WELL LT	284A1807 96906	1	33-32-11 P019-00/ /	ALL
S00064		MS24523-23 SW-MAIN WHEEL WELL LIGHT	284A0123 96906	1	33-32-11 689/160/L070	ALL
S00065		MS24524-23 SW-A/C BAY SERVICE LIGHT,R	284A0124 96906	1	33-33-11 544/153/R034	ALL
S00066		MS24524-23 SW-A/C BAY SERVICE LIGHT,L	284A0124 96906	1	33-33-11 544/154/L039	ALL
S00067		J100 SW-CARGO LIGHTS PUSH ON PUSH OFF	284A0112 81640	1	33-36-11 440/158/R033	ALL
S00068		J100 SW-AFT CARGO LIGHTS	284A0131 81640	1	33-36-12 793/160/R033	ALL
S00071		10-61226-29 SW- #1 L MLG DN + LOCKED SENSOR	81205	1	32-64-11 700/180/L90	ALL
S00072		10-61226-29 SW- #1 L MLG UP + LOCKED SNSR (737-800)	65-55797 81205	1	32-64-11 693/188/L056	YC001-YK912, YK918-YK919, YL401-YL429
S00072		10-61226-29 SW- #1 L MLG UP + LOCKED SNSR (737-700)	65-55797 81205	1	32-64-11 693/188/L056	YM643-YM652
S00073		10-61226-29 SW- #1 R MLG DN + LOCKED SENSOR	81205	1	32-64-11 700/180/R90	ALL
S00074		10-61226-29 SW- #1 R MLG UP + LOCKED SNSR (737-800)	65-55797 81205	1	32-64-11 693/188/R056	YC001-YK912, YK918-YK919, YL401-YL429
S00074		10-61226-29 SW- #1 R MLG UP + LOCKED SNSR (737-700)	65-55797 81205	1	32-64-11 693/188/R056	YM643-YM652
S00077		2D64 SW-HORN CUT OUT	65C31503 91929	1	32-64-21 P008-00/ /	ALL
S00084		MS24523-23 SW-FWD LWR SERV COMPT LTS	284A0103 96906	1	33-34-11 204/171/L010	ALL
S00085		J100 SW-E/E COMPT LIGHTS	284A0211 81640	1	33-34-11 359/164/R007	ALL

EQUIPMENT LIST

D280A103

Section S00000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00086		MS24523-23 SW-APU COMPT LT	284A0151 96906	1	33-35-11 1090/220/L003	ALL
S00087		J100 SW-ACCESSORY LIGHTS	284A0152 81640	1	33-35-11 1064/209/L018	ALL
S00088		P6-330012 SW-ENG 1 LEFT IGN	254A1210 21649	1	76-21-11 P008-00/ /	ALL
S00089		P6-330012 SW-ENG 1 RIGHT IGN	254A1210 21649	1	76-21-10 P008-00/ /	ALL
S00090		P6-330012 SW-ENG 2 LEFT IGN	254A1210 21649	1	76-21-20 P008-00/ /	ALL
S00091		P6-330012 SW-ENG 2 RIGHT IGN	254A1210 21649	1	76-21-20 P008-00/ /	ALL
S00098		MS24523-23 SW-WING SCANNING LTS	65-46991 96906	1	33-41-11 P005-00/ /	ALL
S00099		MS24523-23 SW-TAIL CONE LT	284A0153 96906	1	33-35-11 1164/245/R016	ALL

EQUIPMENT LIST

D280A103

Section S00000
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00100		MS25008-1 SW-PARKING BRAKE	251A3190 96906	1	32-44-11 210/200/L014	ALL
S00103		MS24523-21 SW-WHITE DOME LT	233A3306 96906	1	33-14-12 P005-00/ /	ALL
S00113		C2006 SW-THROTTLE DISENG 1	65C18265 81640	1	22-31-51 216/220/	ALL
S00114		C2006 SW-THROTTLE DISENG 2	65C18265 81640	1	22-31-51 216/220/	ALL
S00115		32EN21-4 SW-ELEC STAB TRIM APL NOSE UP	251A4700 91929	1	27-41-12 1083/264/L015	ALL
S00117	1	975-0062-002 SW-RIGHT WING GROUND THERMAL ANTI-ICE	218A1660 97896	1	30-11-11 621/205/R213	ALL
S00117	2	3000-46-27 SW-RIGHT WING GROUND THERMAL ANTI-ICE	218A1660 14604	1	30-11-11 621/205/R213	ALL
S00118	1	975-0062-002 SW-LEFT WING GROUND THERMAL ANTI-ICE	218A1660 97896	1	30-11-11 621/205/R213	ALL
S00118	2	3000-46-27 SW-LEFT WING GROUND THERMAL ANTI-ICE	218A1660 14604	1	30-11-11 621/205/L213	ALL
S00125		VENDORSUPPLIEDSEEIPCFORP-NINFO SW-OIL FILTER BYPASS WARNING	332A2000 12812	2	79-33-11 ENG/ /	ALL
S00126		401-67779 SW-DIFF PRESS SENSE SYS A B	65-45171 19156	1	27-31-37 1084/266/R018	ALL
S00128		10-2638-4 SW-CABIN PRESS	216A5001 81205	1	21-33-11 190/208/R002	ALL
S00132		32EN21-4 SW-NOSE UP STAB TAKE-OFF WARN (737-800)	251A4700 91929	1	31-53-11 1082/270/L015	YC001-YK912, YK918-YK919, YL401-YL429
S00132		32EN21-4 SW-NOSE UP STAB TAKE-OFF WARN (737-700)	251A4700 91929	1	31-53-11 1082/270/L015	YM643-YM652
S00134		10-60705-1 SW-CAPT STAB TRIM	251A2110 81205	1	27-41-11 215/ /L020	ALL
S00135		10-60705-1 SW-F/O STAB TRIM	251A2110 81205	1	27-41-11 215/ /R020	ALL

EQUIPMENT LIST

D280A103

Section S00100

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00138		426EN9-8 SW-FLAP LANDING WARNING	91929	1	32-64-21 635/201/R051	YC001-YC030
S00138		426HE13-8 SW-FLAP LANDING WARNING	91929	1	32-64-21 635/201/R051	YK901-YK912, YK918, YL401- YL426, YM643- YM652
S00141		10-60552-1 SW-SYS A PRESS	65-44890 81205	1	27-23-14 666/179/L053	ALL
S00142		10-60552-1 SW-SYS B PRESS	65-44890 81205	1	27-23-14 666/179/R053	ALL
S00143	1	10-60552-35 SW-STANDBY HYDRAULIC SYSTEM LOW PRESSURE	271A2443 81205	1	29-35-11 723/163/L003	ALL
S00143	2	10-60552-22 SW-STANDBY HYDRAULIC SYSTEM LOW PRESSURE	271A2443 81205	1	29-35-11 723/163/L003	ALL
S00143	3	10-60552-11 SW-STANDBY HYDRAULIC SYSTEM LOW PRESSURE	271A2443 81205	1	29-35-11 723/163/L003	ALL
S00143	4	10-60552-1 SW-STANDBY HYDRAULIC SYSTEM LOW PRESSURE	271A2443 81205	1	29-35-11 723/163/L003	ALL
S00144		32EN21-4 SW-STAB NOSE UP LIMIT (737-800)	251A4700 91929	1	22-13-11 1084/255/L018	YC001-YK912, YK918-YK919, YL401-YL429
S00144		32EN21-4 SW-STAB NOSE UP LIMIT (737-700)	251A4700 91929	1	22-13-11 1084/255/L018	YM643-YM652
S00145		32EN21-4 SW-STAB NOSE DOWN LIMIT	251A4700 91929	1	22-13-11 1082/ /L001	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM670
S00149		MS27723-23 SW-A/P AND CRUISE TRIM C/O	65C25502 91929	1	22-13-11 P008-00/ /	ALL
S00150		60B92400-10 SW-B00ST PUMP LOW PRESS TANK 1 AFT	343A3111 81205	1	28-43-11 669/189/085L	ALL
S00151		60B92400-10 SW-BOOST PUMP LOW PRESS TANK 1 FWD	343A3111 81205	1	28-43-11 547/198/083L	ALL
S00152		60B92400-10 SW-BOOST PUMP LOW PRESS TANK 2 AFT	343A3111 81205	1	28-43-11 669/189/055	ALL

EQUIPMENT LIST

D280A103

Section S00100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00153		60B92400-10 SW-B00ST PUMP LOW PRESS TANK 2 FWD	343A3111 81205	1	28-43-11 547/195/083	ALL
S00154		60B92400-11 SW-B00ST PUMP LOW PRESS CENTER TANK LEFT	343A3101 81205	1	28-43-11 656/187/L26L	ALL
S00155		60B92400-11 SW-BOOST PUMP LOW PRESS CENTER TANK R	343A3101 81205	1	28-43-11 656/187/025R	ALL
S00156	1	10-61355-3 SW-REFUEL POWER CONTROL	65C28090 81205	1	28-44-11 OFSS 394/ /	ALL
S00157		MS24523-23 SW-TANK 1 REFUEL VALVE CONTROL	69-73588 96906	1	28-44-11 P015-00/ /	ALL
S00158		MS24523-23 SW-TANK 2 REFUEL VALVE CONTROL	69-73588 96906	1	28-44-11 P015-00/ /	ALL
S00159		MS24523-23 SW-CENTER TANK REFUEL VALVE CONTROL	69-73588 96906	1	28-44-11 P015-00/ /	ALL
S00160		MS24525-27 SW-REFUEL INDICATION TEST	69-73588 96906	1	28-44-11 P015-00/ /	ALL
S00161		P8-4000003 SW-MIC CONTROL COL CAPT	65-45123 21649	1	23-51-01 200/ /	ALL
S00168		10-61226-29 SNSR-LEADING EDGE FLAP 1 RETRACT	256A2284 81205	1	27-81-11 IFSS 193/ /	ALL
S00169		10-61226-29 SNSR-LEADING EDGE FLAP 1 EXTEND	256A2284 81205	1	27-81-11 IFSS 193/ /	ALL
S00170		10-61226-29 SNSR-LEADING EDGE FLAP 2 RETRACT	256A2284 81205	1	27-81-11 IFSS 137/ /	ALL
S00171		10-61226-29 SNSR-LEADING EDGE FLAP 2 EXTEND	256A2284 81205	1	27-81-11 IFSS 137/ /	ALL
S00172		10-61226-29 SNSR-LEADING EDGE FLAP 3 RETRACT	256A2284 81205	1	27-81-21 IFSS 137/ /	ALL
S00173		10-61226-29 SNSR-LEADING EDGE FLAP 3 EXTEND	256A2284 81205	1	27-81-21 IFSS 137/ /	ALL
S00174		10-61226-29 SNSR-LEADING EDGE FLAP 4 RETRACT	256A2284 81205	1	27-81-21 IFSS 193/ /	ALL
S00175		10-61226-29 SNSR-LEADING EDGE FLAP 4 EXTEND	256A2284 81205	1	27-81-21 IFSS 193/ /	ALL

EQUIPMENT LIST

D280A103

Section S00100

Page 3

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
I S00190		10-1468 SW-L WINDOW 5 THERMAL	69-21641 81205	1	30-41-11 231/263/L031	YC031-YC050, YM643-YM670
I S00191		10-1468 SW-R WINDOW 5 THERMAL	69-21641 81205	1	30-41-12 230/262/R031	YC031-YC050, YM643-YM670
S00194		10-61226-29 SW-FWD SERVICE DOOR SENSOR	69-42809 81205	1	52-71-11 332/267/R055	ALL
S00195		10-61226-29 SW-AFT SERVICE DOOR SENSOR	69-42809 81205	1	52-71-11 992/265/R059	ALL
S00196		S-BM8805-1-008 SW-FWD ACCESS DOOR	284A1321 96906	1	52-71-12 199/167/0	ALL
S00197		S-BM8805-1-008 SW-ELECTRONIC ACCESS DOOR	284A0323 96906	1	52-71-12 338/151/L011	ALL
S00199		10-61226-29 SW-FWD ENTRY DOOR SENSOR	284A1322 81205	1	52-71-10 308/267/L050	ALL

EQUIPMENT LIST

D280A103

Section S00100
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00200		10-61226-29 SW-AFT ENTRY DOOR SENSOR	69-43479 81205	1	52-71-11 993/265/L055	ALL
S00214		P8-4000003 SW-MIC CONTROL COL F/O	65-45123 21649	1	23-51-02 200/ /	ALL
S00231		721101-A1 SW-A/P DISENGAGE CAPT	65-45123 97564	1	22-11-12 214/237/R014	ALL
S00232		721101-A1 SW-A/P DISENGAGE F/O	65-45123 97564	1	22-11-12 214/237/L031	ALL
S00238		A3-1083 SW-COMPASS LT	233A4226 81640	1	33-14-12 212/260/	ALL
S00241		VENDORSUPPLIEDSEEIPCFORP-NINFO SW-FUEL FILTER DIFF PRESSURE ENG-1-2	332A1042 12812	2	73-31-11 ENG/ /	ALL
S00245		426EN10-8 SW-TE FLAPS UP	91929	1	27-53-12 714/195/R057	YC001-YC030
S00245		426HE13-8 SW-TE FLAPS UP	91929	1	27-53-12 714/195/R057	YK918-YK919, YL401-YL429, YM643-YM652
S00246		21EN107-6 SW-TE FLAPS DOWN	91929	1	27-53-12 714/194/R055	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
S00248		111AT-25 SW-AUXILIARY POWER UNIT MASTER	65-73709 81640	1	49-62-11 P005-00/ /	ALL
S00258		A3-1092 SW-LDG LTS-L INBD	65-73709 81640	1	33-42-11 P005-00/ /	ALL
S00259		A3-1092 SW-LDG LTS-R INBD	65-73709 81640	1	33-42-11 P005-00/ /	ALL
S00260		8906K1592 SW-LDG LTS-L RETRACT	65-73709 15605	1	33-42-11 P005-00/ /	ALL
S00261		8906K1592 SW-LDG LTS-R RETRACT	65-73709 15605	1	33-42-11 P005-00/ /	ALL
S00266		6600-2849 SW-ENG 1 START	233A3301 31946	1	74-31-11 P005-00/ /	ALL

EQUIPMENT LIST

D280A103

Section S00200

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00267		6600-2849 SW-ENG 2 START	233A3301 31946	1	74-31-11 P005-00/ /	ALL
S00268		A3-1080 SW-TURNOFF LT LEFT	233A3303 81640	1	33-45-11 P005-00/ /	ALL
S00269		A3-1080 SW-TURNOFF LT RIGHT	233A3303 81640	1	33-45-11 P005-00/ /	ALL
S00272		MS27724-23 SW-STAB TRIM C/O	254A1210 91929	1	27-41-11 F010/ /	ALL
S00276		10AT97-3 SW-SPEED BRAKE ARMING WARN	251A1911 96906	1	27-62-11 178/200/L030	ALL
S00284		2EN19-RB SW-AIR INLET DOOR POSITION	65-50925 91929	1	49-62-11 1055/240/R037	ALL

EQUIPMENT LIST

D280A103

Section S00200
Page 2 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00301		10-61226-29 SW- #2 R MLG DN + LOCKED SENSOR		1	32-64-12 710/180/R90	ALL
S00302		10-61226-29 SW- #2 L MLG DN + LOCKED SENSOR	81205	1	32-64-12 710/180/L90	ALL

EQUIPMENT LIST

D280A103

Section S00300
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00519		P8-4000003 SW-INT CONTROL COL CAPT	65-45123 21649	1	23-51-01 200/ /	ALL
S00520		P8-4000003 SW-INT CONTROL COL F/O	65-45123 21649	1	23-51-02 200/ /	ALL
S00546		32EN21-4 SW-NOSE DOWN STAB TAKE-OFF WARNING (-800)	251A4700 91929	1	31-53-11 1082/283/L014	YC001-YK912, YK918-YK919, YL401-YL429
S00546		32EN21-4 SW-NOSE DOWN STAB TAKE-OFF WARNING (-700)	251A4700 91929	1	31-53-11 1082/279/L014	YM643-YM652
S00574		F-8300-146 SW-TANK 1 REFUEL FLOAT	344A3112 50625	1	28-44-11 W0479/ /LFS	YC001-YC020
S00574		F-8300-146 SW-TANK 1 REFUEL FLOAT	344A3112 50625	1	28-44-11 W0479/000/LFS	YC021-YC026
S00574		8TJ143TAA1 SW-TANK 1 REFUEL FLOAT	344A3112 97424	1	28-44-11 W0479/ /LFS	YC028-YM670
S00576		F-8300-146 SW-CENTER TANK REFUEL FLOAT	344A3101 50625	1	28-44-11 96/ /RFS	YC001-YC020
S00576		F-8300-146 SW-CENTER TANK REFUEL FLOAT	344A3101 50625	1	28-44-11 96/000/RFS	YC021-YC026
S00576		8TJ143TAA1 SW-CENTER TANK REFUEL FLOAT	344A3101 97424	1	28-44-11 96/ /RFS	YC028-YM670
S00578		F-8300-146 SW-TANK 2 REFUEL FLOAT	344A3112 50625	1	28-44-11 480/ /RFS	YC001-YC020
S00578		F-8300-146 SW-TANK 2 REFUEL FLOAT	344A3112 50625	1	28-44-11 480/000/RFS	YC021-YC026
S00578		8TJ143TAA1 SW-TANK 2 REFUEL FLOAT	344A3112 97424	1	28-44-11 480/ /RFS	YC028-YM670
S00595		P6-330012 SW-ENGINE 1 START LEVER	254A1290 21649	1	28-21-11 P008-00/ /	ALL
S00596		P6-330012 SW-ENGINE 2 START LEVER	254A1290 21649	1	28-21-11 P008-00/ /	ALL

EQUIPMENT LIST

D280A103

Section S00500
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00635		MS24523-23 SW-LOGO LIGHT	233A3303 96906	1	33-49-11 P005-08/ /	ALL
S00650		MS25253-1 SW-REVERSE THRUST	254A1210 96906	1	27-62-11 P010-00/ /	ALL
S00651		V3L2228 SW-SPEED BRAKE TAKE-OFF WARN (737-800)	254A1210 91929	1	31-53-11 P010-00/ /	YC001-YK912, YK918-YK919, YL401-YL429
S00651		V3L2228 SW-SPEED BRAKE TAKE-OFF WARN (737-700)	254A1210 91929	1	31-53-11 P010-00/ /	YM643-YM652
S00653		D20011-01 SW-GROUND PROX SYS TEST	69-37369 81640	1	34-49-11 P003-07/ /	ALL
S00658		62AT22-3 SW-FLAP INHIBIT	69-37369 91929	1	34-49-11 P003-07/ /	ALL
S00692		1G409 SW-WTR PRESS,CUT-OUT	417A2510 81205	1	38-41-13 958/205/R3	ALL

EQUIPMENT LIST

D280A103

Section S00600
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00718		W20161-01 SW-ALT HORN CUTOUT	69-37334 81640	1	21-33-11 P005-16/ /	ALL
S00742		W0443 SW (PROV)	286A0443	1	23-51-11 200/ /	ALL
S00743		W0445 SW (PROV)	286A0445	1	23-51-11 200/ /	ALL
S00755		10-1468-5 SW-LEFT WINDOW 3 (85F) THERMAL	280A1502 81205	1	30-41-11 241/241/L043	ALL
S00756		10-1468-5 SW-RIGHT WINDOW 3 (85F) THERMAL	280A1502 81205	1	30-41-12 241/245/R043	ALL
S00762		S271T452-3 SW-LEFT BRAKE PEDAL	65C26817 81205	1	32-42-11 727/195/L030	ALL
S00763		S271T452-3 SW-RIGHT BRAKE PEDAL	65C26817 81205	1	32-42-11 727/193/L020	ALL
S00771		S271T452-17 SW-HYD PRESS (ELEV ACTR 'A')	65C19732 81205	1	22-14-11 1165/282/L010	ALL
S00772		S271T452-17 SW-HYD PRESS (AIL ACTR 'B')	65C19731 81205	1	22-14-11 673/192/L049	ALL
S00773		S271T452-17 SW-HYD PRESS (ELEV ACTR 'B')	65C19732 81205	1	22-14-11 1158/287/L010	ALL
S00774		S271T452-17 SW-HYD PRESS (AIL ACTR 'A')	65-44907 81205	1	22-14-11 668/192/L040	ALL
S00786	1	2PB11-T2 SW-TAKE-OFF/GO-AROUND	91929	1	22-11-14 220/ /	ALL
S00786A	1	PARTAOFS00786 SW-TAKE-OFF/GO-AROUND		1	22-11-14 220/ /	ALL
S00786B	1	PARTBOFS00786 SW-TAKE-OFF/GO-AROUND		1	22-11-14 220/ /	ALL
S00787	1	2PB11-T2 SW-TAKE-OFF/GO-AROUND	91929	1	22-11-14 220/ /	ALL
S00787A	1	PARTAOFS00787 SW-TAKE-OFF/GO-AROUND		1	22-11-14 220/ /	ALL
S00787B	1	PARTBOFS00787 SW-TAKE-OFF/GO-AROUND		1	22-11-14 220/ /	ALL

EQUIPMENT LIST

D280A103

Section S00700

Page 1

Feb 09/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00790		62AT22-3 SW-GEAR INHIBIT	69-37369 91929	1	34-49-11 P003-07/ /	ALL
S00794		10-60552-35 SW-SYSTEM A ELEC 2 PUMP LOW PRESSURE	65-44590 81205	1	29-33-11 666/171/L043	ALL
S00795		10-60552-35 SW-SYSTEM B ELEC 1 PUMP LOW PRESSURE	65-44590 81205	1	29-33-11 666/181/R022	ALL
S00796		10-60552-35 SW-SYSTEM A ENG 1 PUMP LOW PRESSURE	65-44580 81205	1	29-33-11 666/171/L047	ALL
S00797		10-60552-35 SW-SYSTEM B ENG 2 PUMP LOW PRESSURE	65-44580 81205	1	29-33-11 666/181/R027	ALL
S00798		10-3207-1 SW-SYSTEM A ELEC 2 PUMP OVERHEAT	65-44900 81205	1	29-34-11 673/161/L007	ALL
S00799		10-3207-1 SW-SYSTEM B ELEC 1 PUMP OVERHEAT	65-44900 81205	1	29-34-11 675/161/R007	ALL

EQUIPMENT LIST

D280A103

Section S00700

Page 2 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00806		21SN41-52 SW-C.T.A.I. DUCT OVERPRESSURE	332A2300 02750	2	30-21-11 505/187/166	ALL
S00811		S271T452-7 SW-A HYD SELECT VALVE PRESS	65C26816 81205	1	32-41-11 706/200/L025	ALL
S00813		214C40-1-110 SW-ALTITUDE PRESS	284A1223 02750	1	35-21-11 J023-00/ /	ALL
S00822		V3L2228 SW-ENGINE 1 WING ANTI-ICE	251A4430 91929	1	30-11-11 P8 0212/220/R001	ALL
S00823		V3L2228 SW-ENGINE 2 WING ANTI-ICE	251A4430 91929	1	30-11-11 P8 0212/220/R001	ALL
S00828		1SX1-H58 T/R 1 CONTROL SWITCH	254A1240 74059	1	78-34-11 P008-00/ /	ALL
S00829		1SX1-H58 T/R 2 CONTROL SWITCH	254A1240 74059	1	78-34-21 P008-00/230/0001	ALL
S00830		10-61226-22 HYD ISLN VLV 2 SNSR,INSTALLED IN M1174	10-62018 74059	1	78-36-20 / /	ALL
S00831		10-61226-30 LEFT T/R SLEEVE STOW SENSOR	81205	2	78-36-11 NSTA 202/119/L33	YC001-YC030
S00831		320FW04-5 LEFT T/R SLEEVE STOW SENSOR	81205	2	78-36-11 NSTA 202/119/L33	YC031-YM670
S00831 T	1	315A2709-1 ADAPTER-RF/EMI SHIELD TERMINATOR	81205	2	78-36-11 / /	YC008-YM670
S00831 U	1	202K121-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-36-11 / /	YC008-YM670
S00831 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-36-11 / /	YC008-YM670
S00831 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-36-11 / /	YC008-YM670
S00831 W	1	NAS1149C1063R WASHER-	96906	2	78-36-11 / /	YC008-YM670
S00831 X	1	NAS1149C1032R WASHER-	96906	2	78-36-11 / /	YC008-YM670
S00831 Y	1	NAS1149C1016R WASHER-	96906	2	78-36-11 / /	YC008-YM670

EQUIPMENT LIST

D280A103

Section S00800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00832		10-61226-30 RIGHT T/R SLEEVE STOW SENSOR	81205	2	78-36-11 NSTA 202/120/R32	YC001-YC030
S00832		320FW04-5 RIGHT T/R SLEEVE STOW SENSOR	81205	2	78-36-11 NSTA 202/120/R32	YC031-YM670
S00832 T	1	3152709-1 ADAPTER-RFI/EMI SHIELD TERMINATOR	81205	2	78-36-11 //	YC008-YM670
S00832 U	1	202K121-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-36-11 //	YC008-YM670
S00832 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-36-11 //	YC008-YM670
S00832 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-36-11 //	YC008-YM670
S00832 W	1	NAS1149C1063R WASHER-	96906	2	78-36-11 //	YC008-YM670
S00832 X	1	NAS1149C1032R WASHER-	96906	2	78-36-11 //	YC008-YM670
S00832 Y	1	NAS1149C1016R WASHER-	96906	2	78-36-11 //	YC008-YM670
S00833		10-61226-22 HYD ISLN VLV 1 SNSR INSTALLED IN M1173	10-62018 74059	1	78-36-11 //	ALL
S00834		10-61226-22 DCV 1 SNSR INSTALLED IN M1173	10-62018 74059	1	78-36-11 //	ALL
S00835		10-61226-30 LEFT T/R SLEEVE LOCK SENSOR	81205	2	78-36-11 NSTA 197/127/L27	YC001-YC030
S00835		320FW04-5 LEFT T/R SLEEVE LOCK SENSOR	81205	2	78-36-11 NSTA 197/127/L27	YC031-YM670
S00835 T	1	315A2709-1 ADAPTER-RFI/EMI SHIELD TERMINATOR	81205	2	78-36-11 //	YC008-YM670
S00835 U	1	202K121-25-0-225 STRAIGHT, LIPPED BOOT	06090	2	78-36-11 //	YC008-YM670
S00835 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-36-11 //	YC008-YM670
S00835 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-36-11 //	YC008-YM670

EQUIPMENT LIST

D280A103

Section S00800

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00835 W	1	NAS1149C1063R WASHER-	96906	4	78-36-11 //	YC008-YM670
S00835 X	1	NAS1149C1032R WASHER-	96906	2	78-36-11 //	YC008-YM670
S00835 Y	1	NAS1149C1016R WASHER-	96906	4	78-36-11 //	YC008-YM670
S00836		320FW04-5 RIGHT T/R SLEEVE LOCK SENSOR	81205	2	78-36-11 NSTA 197/128/R26	ALL
S00836 T	1	315A2709-1 ADAPTER-RF/EMI SHIELD TERMINATOR	81205	2	78-36-11 //	YC008-YM670
S00836 U	1	202K121-25-225-0 STRAIGHT, LIPPED BOOT	06090	2	78-36-11 //	YC008-YM670
S00836 U	2	202K121-25-0 STRAIGHT, LIPPED BOOT	06090	2	78-36-11 //	YC008-YM670
S00836 V	1	BACB42F3 BAND-SHIELD TERMINATOR	81205	2	78-36-11 //	YC008-YM670
S00836 W	1	NAS1149C1063R WASHER-	96906	4	78-36-11 //	YC008-YM670
S00836 X	1	NAS1149C1032R WASHER-	96906	2	78-36-11 //	YC008-YM670
S00836 Y	1	NAS1149C1016R WASHER-	96906	4	78-36-11 //	YC008-YM670
S00839		10-61226-22 DCV 2 SNSR, INSTALLED IN M1174	10-62018 74059	1	78-36-21 //	ALL
S00844		32EN21-4 SW-ELECT STAB TRIM-NOSE DN FLP UP (-800)	251A4700 91929	1	27-41-12 1082/278/L006	YC001-YK912, YK918-YK919, YL401-YL429
S00844		32EN21-4 SW-ELECT STAB TRIM-NOSE DN FLP UP (-700)	251A4700 91929	1	27-41-12 1082/278/L006	YM643-YM652
S00845		10-61226-29 SW- #1 NOSE GEAR DOWN SENSOR	81205	1	32-64-11 260/200/L10	ALL
S00846		10-61226-29 SW- #1 NOSE GESR LOCKED SENSOR	81205	1	32-64-11 280/170/L0.0	ALL

EQUIPMENT LIST

D280A103

Section S00800

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00853		10-61226-29 SW- #2 NOSE GEAR DOWN SENSOR	81205	1	32-64-12 261/190/R10	ALL
S00854		10-61226-29 SW- #2 NOSE GEAR LOCKED SENSOR	81205	1	32-64-12 280/170/R0.0	ALL
S00855		S271T452-16 SW-HYDRAULIC SYSTEM B EDP PRESSURE	69-74476 81205	1	29-25-11 667/179/R031	ALL
S00858		4TL187-12 SW-ENG IGN	233A3301 74059	1	74-31-11 P005-00/ /	ALL
S00870		MS24524-23 SW-EQUIP COOLING SUPPLY	233A3101 96906	1	21-27-31 P005-00/ /	ALL

EQUIPMENT LIST

D280A103

Section S00800
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00918		10AT96-2 SW-SPEED BRAKE HANDLE POS SW	251A1911 96906	1	27-62-21 178/200/L030	ALL
S00931		S210T130-18 SW-CONTROL CABIN DUCT OVERHEAT	214A1002 81205	1	21-61-11 373/194/L058	YC001-YL430
S00934		641172-1 SW-LEFT PACK DISCHARGE OVERHEAT	213A1002 70210	1	21-51-15 520/160/L017	YC001-YL430
S00935		641172-1 SW-RIGHT PACK DISCHARGE OVERHEAT	214A3003 70210	1	21-51-25 521/160/R015	YC001-YL430
S00938		572757-1 SW-LEFT ACM OVHT/210 DEGREES THERMAL	213A1002 70210	1	21-51-15 577/162/L031	YC001-YL430
S00939		572757-1 SW-RIGHT ACM OVHT/210 DEGREE THERMAL	213A1002 70210	1	21-51-25 578/165/R031	YC001-YL430
S00942		402-167 SW-RADIO FREQUENCY COAXIAL	287A4116 00471	1	34-53-31 316/163/L025	ALL
S00943		402-167 SW-RADIO FREQUENCY COAXIAL	287A4116 00471	1	34-53-31 316/163/L025	ALL
S00945		8102-0403 SW-WATER PRESSURE PROX	417A2516 81205	1	38-41-13 915/165/R10	ALL
S00959		MS24525-23 SW-BATT	69-37321 96906	1	24-31-12 P005-13/ /	ALL
S00960		10-62215-1 SW-FWD CARGO DOOR IND	284A0331 81205	1	52-71-12 441/164/R042	YC001-YK911, YK918, YL421- YL426, YM643- YM651
S00960		63028 SW-FWD CARGO DOOR IND	284A0331 81205	1	52-71-12 441/164/R042	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
S00961		10-62215-1 SW-AFT CARGO DOOR IND	284A0341 81205	1	52-71-12 797/170/R041	YC001-YK911, YK918, YL421- YL426, YM643- YM651

EQUIPMENT LIST

D280A103

Section S00900

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00961		63028 SW-AFT CARGO DOOR IND	284A0341 81205	1	52-71-12 797/170/R041	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
S00989		2PB11-H58 SWITCH-PTT FIRST-OFFICERS GLARESHIELD	233A8200 91929	1	23-51-02 P007-00/ /	YK901-YM670
S00994		10-61226-29 SNSR-LEADING EDGE SLAT 1 OUTBOARD	256A2284 81205	1	27-81-12 714/FSS/L	YC001-YK910, YL421-YL423, YM643
S00994		10-61226-30 SNSR-LEADING EDGE SLAT 1 OUTBOARD (-800)	256A2284 81205	1	27-81-12 714/FSS/L	YK911-YL401, YL424-YL430
S00994		10-61226-30 SNSR-LEADING EDGE SLAT 1 OUTBOARD	256A2284 81205	1	27-81-12 714/FSS/L	YM645-YM670
S00995		10-61226-29 SNSR-LEADING EDGE SLAT 1 INBOARD	256A2284 81205	1	27-81-12 659/FSS/L	YC001-YK910, YL421-YL423
S00995		10-61226-30 SNSR-LEADING EDGE SLAT 1 INBOARD	256A2284 81205	1	27-81-12 659/FSS/L	YK911-YL401, YL424-YL430
S00995		10-61226-29- SNSR-LEADING EDGE SLAT 1 INBOARD	256A2284 81205	1	27-81-12 659/FSS/L	YM643
S00995		10-61226-30- SNSR-LEADING EDGE SLAT 1 INBOARD	256A2284 81205	1	27-81-12 659/FSS/L	YM645-YM670
S00996		10-61226-29 SNSR-LEADING EDGE SLAT 2 OUTBOARD	256A2284 81205	1	27-81-12 583/FSS/L	YC001-YK910, YL421-YL423
S00996		10-61226-30 SNSR-LEADING EDGE SLAT 2 OUTBOARD	256A2284 81205	1	27-81-12 583/FSS/L	YK911-YL401, YL424-YL430
S00996		10-61226-29- SNSR-LEADING EDGE SLAT 2 OUTBOARD	256A2284 81205	1	27-81-12 583/FSS/L	YM643
S00996		10-61226-30- SNSR-LEADING EDGE SLAT 2 OUTBOARD	256A2284 81205	1	27-81-12 583/FSS/L	YM645-YM670
S00997		10-61226-29 SNSR-LEADING EDGE SLAT 2 INBOARD	256A2284 81205	1	27-81-12 533/FSS/L	YC001-YK910, YL421-YL423
S00997		10-61226-30 SNSR-LEADING EDGE SLAT 2 INBOARD	256A2284 81205	1	27-81-12 533/FSS/L	YK911-YL401, YL424-YL430
S00997		10-61226-29- SNSR-LEADING EDGE SLAT 2 INBOARD	256A2284 81205	1	27-81-12 533/FSS/L	YM643

EQUIPMENT LIST

D280A103

Section S00900

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00997		10-61226-30- SNSR-LEADING EDGE SLAT 2 INBOARD	256A2284 81205	1	27-81-12 533/FSS/L	YM645-YM670
S00998		10-61226-29 SNSR-LEADING EDGE SLAT 3 OUTBOARD	256A2284 81205	1	27-81-12 466/FSS/L	YC001-YK910, YL421-YL423
S00998		10-61226-30 SNSR-LEADING EDGE SLAT 3 OUTBOARD	256A2284 81205	1	27-81-12 466/FSS/L	YK911-YL401, YL424-YL430
S00998		10-61226-29- SNSR-LEADING EDGE SLAT 3 OUTBOARD	256A2284 81205	1	27-81-12 466/FSS/L	YM643
S00998		10-61226-30- SNSR-LEADING EDGE SLAT 3 OUTBOARD	256A2284 81205	1	27-81-12 466/FSS/L	YM645-YM670
S00999		10-61226-29 SNSR-LEADING EDGE SLAT 3 INBOARD	265A2284 81205	1	27-81-12 415/FSS/L	YC001-YK910, YL421-YL423
S00999		10-61226-30 SNSR-LEADING EDGE SLAT 3 INBOARD	265A2284 81205	1	27-81-12 415/FSS/L	YK911-YL401, YL424-YL430
S00999		10-61226-29- SNSR-LEADING EDGE SLAT 3 INBOARD	265A2284 81205	1	27-81-12 415/FSS/L	YM643
S00999		10-61226-30- SNSR-LEADING EDGE SLAT 3 INBOARD	265A2284 81205	1	27-81-12 415/FSS/L	YM645-YM670

EQUIPMENT LIST

D280A103

Section S00900
Page 3 End
May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01000		10-61226-29 SNSR-LEADING EDGE SLAT 4 OUTBOARD	265A2284 81205	1	27-81-12 349/ /RFS	YC001-YK910, YL421-YL423
S01000		10-61226-30 SNSR-LEADING EDGE SLAT 4 OUTBOARD	265A2284 81205	1	27-81-12 349/ /RFS	YK911-YL401, YL424-YL430
S01000		10-61226-29- SNSR-LEADING EDGE SLAT 4 OUTBOARD	265A2284 81205	1	27-81-12 349/ /RFS	YM643
S01000		10-61226-30- SNSR-LEADING EDGE SLAT 4 OUTBOARD	265A2284 81205	1	27-81-12 349/ /RFS	YM645-YM670
S01001		10-61226-29 SNSR-LEADING EDGE SLAT 4 INBOARD	265A2284 81205	1	27-81-12 300/ /RFS	YC001-YK910, YL421-YL423
S01001		10-61226-30 SNSR-LEADING EDGE SLAT 4 INBOARD	265A2284 81205	1	27-81-12 300/ /RFS	YK911-YL401, YL424-YL430
S01001		10-61226-29- SNSR-LEADING EDGE SLAT 4 INBOARD	265A2284 81205	1	27-81-12 300/ /RFS	YM643
S01001		10-61226-30- SNSR-LEADING EDGE SLAT 4 INBOARD	265A2284 81205	1	27-81-12 300/ /RFS	YM645-YM670
S01002		10-61226-29 SNSR-LEADING EDGE SLAT 5 OUTBOARD	256A2284 81205	1	27-81-22 349/ /RFS	YC001-YK910, YL421-YL423
S01002		10-61226-30 SNSR-LEADING EDGE SLAT 5 OUTBOARD	256A2284 81205	1	27-81-22 349/ /RFS	YK911-YL401, YL424-YL430
S01002		10-61226-29- SNSR-LEADING EDGE SLAT 5 OUTBOARD	256A2284 81205	1	27-81-22 349/ /RFS	YM643
S01002		10-61226-30- SNSR-LEADING EDGE SLAT 5 OUTBOARD	256A2284 81205	1	27-81-22 349/ /RFS	YM645-YM670
S01003		10-61226-29 SNSR-LEADING EDGE SLAT 5 INBOARD	256A2284 81205	1	27-81-22 300/ /RFS	YC001-YK910, YL421-YL423
S01003		10-61226-30 SNSR-LEADING EDGE SLAT 5 INBOARD	256A2284 81205	1	27-81-22 300/ /RFS	YK911-YL401, YL424-YL430
S01003		10-61226-29- SNSR-LEADING EDGE SLAT 5 INBOARD	256A2284 81205	1	27-81-22 300/ /RFS	YM643
S01003		10-61226-30- SNSR-LEADING EDGE SLAT 5 INBOARD	256A2284 81205	1	27-81-22 300/ /RFS	YM645-YM670
S01004		10-61226-29 SNSR-LEADING EDGE SLAT 6 OUTBOARD	256A2284 81205	1	27-81-22 466/ /RFS	YC001-YK910, YL421-YL423

EQUIPMENT LIST

D280A103

Section S01000

Page 1

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01004		10-61226-30 SNSR-LEADING EDGE SLAT 6 OUTBOARD	256A2284 81205	1	27-81-22 466/ /RFS	YK911-YL401, YL424-YL430
S01004		10-61226-29- SNSR-LEADING EDGE SLAT 6 OUTBOARD	256A2284 81205	1	27-81-22 466/ /RFS	YM643
S01004		10-61226-30- SNSR-LEADING EDGE SLAT 6 OUTBOARD	256A2284 81205	1	27-81-22 466/ /RFS	YM645-YM670
S01005		10-61226-29 SNSR-LEADING EDGE SLAT 6 INBOARD	256A2284 81205	1	27-81-22 415/ /RFS	YC001-YK910, YL421-YL423
S01005		10-61226-30 SNSR-LEADING EDGE SLAT 6 INBOARD	256A2284 81205	1	27-81-22 415/ /RFS	YK911-YL401, YL424-YL430
S01005		10-61226-29- SNSR-LEADING EDGE SLAT 6 INBOARD	256A2284 81205	1	27-81-22 415/ /RFS	YM643
S01005		10-61226-30- SNSR-LEADING EDGE SLAT 6 INBOARD	256A2284 81205	1	27-81-22 415/ /RFS	YM645-YM670
S01006		10-61226-29 SNSR-LEADING EDGE SLAT 7 OUTBOARD	256A2284 81205	1	27-81-22 583/ /	YC001-YK910, YL421-YL423
S01006		10-61226-30 SNSR-LEADING EDGE SLAT 7 OUTBOARD	256A2284 81205	1	27-81-22 583/ /	YK911-YL401, YL424-YL430
S01006		10-61226-29- SNSR-LEADING EDGE SLAT 7 OUTBOARD	256A2284 81205	1	27-81-22 583/ /	YM643
S01006		10-61226-30- SNSR-LEADING EDGE SLAT 7 OUTBOARD	256A2284 81205	1	27-81-22 583/ /	YM645-YM670
S01007		10-61226-29 SNSR-LEADING EDGE SLAT 7 INBOARD	256A2284 81205	1	27-81-22 533/ /RFS	YC001-YK910, YL421-YL423
S01007		10-61226-30 SNSR-LEADING EDGE SLAT 7 INBOARD	256A2284 81205	1	27-81-22 533/ /RFS	YK911-YL401, YL424-YL430
S01007		10-61226-29- SNSR-LEADING EDGE SLAT 7 INBOARD	256A2284 81205	1	27-81-22 533/ /RFS	YM643
S01007		10-61226-30- SNSR-LEADING EDGE SLAT 7 INBOARD	256A2284 81205	1	27-81-22 533/ /RFS	YM645-YM670
S01008		10-61226-29 SNSR-LEADING EDGE SLAT 8 OUTBOARD	256A2284 81205	1	27-81-22 715/RFS/	YC001-YK910, YL421-YL423
S01008		10-61226-30 SNSR-LEADING EDGE SLAT 8 OUTBOARD	256A2284 81205	1	27-81-22 715/RFS/	YK911-YL401, YL424-YL430

EQUIPMENT LIST

D280A103

Section S01000

Page 2

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01008		10-61226-29- SNSR-LEADING EDGE SLAT 8 OUTBOARD	256A2284 81205	1	27-81-22 715/RFS/	YM643
S01008		10-61226-30- SNSR-LEADING EDGE SLAT 8 OUTBOARD	256A2284 81205	1	27-81-22 715/RFS/	YM645-YM670
S01009		10-61226-29 SNSR-LEADING EDGE SLAT 8 INBOARD	256A2284 81205	1	27-81-22 660/RFS/	YC001-YK910, YL421-YL423
S01009		10-61226-30 SNSR-LEADING EDGE SLAT 8 INBOARD	256A2284 81205	1	27-81-22 660/RFS/	YK911-YL401, YL424-YL430
S01009		10-61226-29- SNSR-LEADING EDGE SLAT 8 INBOARD	256A2284 81205	1	27-81-22 660/RFS/	YM643
S01009		10-61226-30- SNSR-LEADING EDGE SLAT 8 INBOARD	256A2284 81205	1	27-81-22 660/RFS/	YM645-YM670
S01010		10-61226-29 SW- #1 R GEAR ON GROUND	81205	1	32-31-11 695/135/R120	ALL
S01011		10-61226-29 SW- #2 R GEAR ON GROUND	81205	1	32-31-12 700/135/R110	ALL
S01012		10-61226-29 SW- #1 L GEAR ON GROUND	81205	1	32-31-11 695/135/L115	ALL
S01013		10-61226-29 SW- #2 L GEAR ON GROUND	81205	1	32-31-12 695/135/L110	ALL
S01014		10-61226-29 SW- #1 NOSE GEAR ON GND	81205	1	32-31-11 300/135/L0.0	ALL
S01015		10-61226-29 SW- #2 NOSE GEAR ON GROUND	81205	1	32-31-12 300/135/R0.0	ALL
S01016		10-61226-29 SW- #2 L MLG JP + LOCKED SNSR (737-800)	161A6100 81205	1	32-64-12 695/188/L056	YC001-YK912, YK918-YK919, YL401-YL429
S01016		10-61226-29 SW- #2 L MLG JP + LOCKED SNSR (737-700)	161A6100 81205	1	32-64-12 695/188/L056	YM643-YM652
S01017		10-61226-29 SW- #2 R MLG JP + LOCKED SNSR (737-800)	161A6100 81205	1	32-64-12 695/188/R020	YC001-YK912, YK918-YK919, YL401-YL429
S01017		10-61226-29 SW- #2 R MLG JP + LOCKED SNSR (737-700)	161A6100 81205	1	32-64-12 695/188/R020	YM643-YM652

EQUIPMENT LIST

D280A103

Section S01000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01024		P6-330012 SW-ENGINE 1 START LEVER CH A	254A1210 21649	1	76-21-11 P008-00/ /	ALL
S01025	2	P6-330012 SW-ENG 1 START LEVER CH B	254A1210 21647	1	76-21-11 P008-00/ /	ALL
S01026		P6-330012 SW-ENG 1 FUEL HPSOV	254A1210 21649	1	76-21-11 P008-00/ /	ALL
S01027		P6-330012 SW-ENGINE 2 START LEVER CH A	254A1210 21649	1	76-21-21 P008-00/ /	ALL
S01028		P6-330012 SW-ENG 2 START LEVER CH B	254A1210 21649	1	76-21-21 P008-00/ /	ALL
S01029		P6-330012 SW-ENG 2 FUEL HPSOV	254A1210 21649	1	76-21-21 P008-00/ /	ALL
S01033		214C40-1-77 SW-ALTITUDE PRESSURE	417A8610 81205	1	38-32-12 1039/231/L046	ALL
S01034		2651-278-21 SW-DRAIN VALVE PROXIMITY	417A8630 81205	1	38-32-12 860/177/L030	ALL
S01039		P6-330012 SW-FLAP HANDLE 30 OR 40	254A1221 21649	1	27-54-11 P008-00/ /	YC001-YK910, YK918-YM670
S01039		P6-330012 SW-FLAP HANDLE 10 TO 40	254A1221 21649	1	27-54-11 P008-00/ /	YK911-YK917
S01041		RBDSC-2 DIP SWITCH-ATC 2	284A0450 09922	1	34-53-21 E001-03/ /	YC001-YC050
S01042		RBDSC-1 DIP SWITCH-GPWS	284A2710 09922	1	34-49-11 E001-01/ /	YC001-YC007
S01042	1	RBDSC-1 DIP SWITCH - GPWS	284A2710	1	34-49-11 E001-01/ /	YC001-YC007
S01049		S271T452-3 SW-GROUND SPOILER UP PRESS	251A1730 81205	1	31-53-11 676/194/RB67	ALL
S01050		10-61226-29 SNSR-GROUND SPOILER INTERLOCK VALVE CL	251A1730 81205	1	31-53-11 596/194/R067	ALL
S01051		426EN10-8 SW-TRAILING EDGE FLAPS UP	91929	1	27-31-37 634/195/R052	YC001-YC030

EQUIPMENT LIST

D280A103

Section S01000

Page 4

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01051		426HE13-8 SW-TRAILING EDGE FLAPS UP	91929	1	27-31-37 634/195/R052	YK901-YK912, YK918, YL401- YL426, YM643- YM652
S01056		RBDSC-1 DIP SWITCH - AUTOPILOT SYS A	284A2710	1	22-11-75 E001-01/ /	YC001-YC030
S01057		RBDSC-1 DIP SWITCH - AUTOPILOT SYS B	284A2710	1	22-11-75 E001-01/ /	YC001-YC030
S01058		RBDSC-1 DIP SWITCH - AUTOTHROTTLE	284A2710	0	22-31-11 E001-01/ /	ALL
S01060		MS25011-2 SW-MANUAL EXTENSION LIMIT	273A4600 96906	1	32-35-11 252/207/R013	ALL
S01076		S210T130-18 SW-ZONE DUCT OVERHEAT	214A2011 81205	1	21-61-13 500F+10/298/L014	YC001-YL430
S01077		S210T130-18 SW-AFT CABIN DUCT OVERHEAT	214A2011 81205	1	21-61-14 534/298/R014	YC001-YL430
S01078		MS24524-23-MICROSWITCHP-N69AT39-3- SW-LEFT FRONT 1 WINDSHIELD SENSOR	287A4352 81205	1	30-41-11 373/187/R050	ALL
S01079		MS24524-23-MICROSWITCHP-N69AT39-3- SW-RIGHT FRONT 1 WINDSHIELD SENSOR	287A4352 81205	1	30-41-12 372/189/R049	ALL
S01084		MS25008-1 SW-BELLY LOADER (BFE/STC)(PROV)	34-10320	1	25-51-21 788/199/R059	YC001-YC050
S01084		MIL-S-8805-31 SW-BELLY LOADER (BFE/STC)	34-10320	1	25-51-21 788/199/R059	YK901-YM670
S01090		P6-330012 SW-FLAP HANDLE UP	254A1221 21649	1	27-81-51 P008-00/ /	ALL
S01091		2PB11H58 SWITCH-PTT CAPTAINS GLARESHIELD	233A8200 91929	1	23-51-02 P007-00/ /	YK901-YL430
S01091		2PB11-H58 SWITCH-PTT CAPTAIN'S GLARESHIELD	S242A801 81640	1	23-51-02 200/ /	YM643-YM670
S01094		S256W408-1 SNSR-LE SLAT 2 RETRACT	256A2284 81205	1	27-81-12 / /	ALL
S01095		S256W408-1 SNSR-LE SLAT 3 RETRACT	256A2284 81205	1	27-81-12 / /	ALL

EQUIPMENT LIST

D280A103

Section S01000

Page 5

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01096		S256W408-1 SNSR-LE SLAT 4 RETRACT	256A2284 81205	1	27-81-12 / /	ALL
S01097		S256W408-1 SNSR-LE SLAT 5 RETRACT	256A2284 81205	1	27-81-22 / /	ALL
S01098		S256W408-1 SNSR-LE SLAT 6 RETRACT	256A2284 81205	1	27-81-22 / /	ALL
S01099		S256W408-1 SNSR-LE SLAT 7 RETRACT	256A2284 81205	1	27-81-22 / /	ALL

EQUIPMENT LIST

D280A103

Section S01000
Page 6 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01104		63026-1 SW-OVERWING DOOR-LEFT AFT-A	284A0353	1	52-71-13 616/259/L067	ALL
S01105		63026-2 SW-OVERWING DOOR-LEFT AFT-B	284A0353	1	52-71-13 639/259/L067	ALL
S01106		63026-2 SW-OVERWING DOOR-RIGHT AFT-A	284A0353	1	52-71-14 616/259/R067	ALL
S01107		63026-1 SW-OVERWING DOOR-RIGHT AFT-B	284A0353	1	52-71-14 639/259/R067	ALL
S01108		63026-1 SW-OVERWING DOOR-LEFT FWD-A	284A0353	1	52-71-13 578/259/L067	YC001-YL430
S01109		63026-2 SW-OVERWING DOOR-LEFT FWD-B	284A0353	1	52-71-13 601/259/L067	YC001-YL430
S01110		63026-2 SW-OVERWING DOOR-RIGHT FWD-A	284A0353	1	52-71-14 578/259/R067	YC001-YL430
S01111		63026-1 SW-OVERWING DOOR-RIGHT FWD-B	284A0353	1	52-71-14 601/259/R067	YC001-YL430
S01112		38HM65 SW-OVERWING FLIGHT LOCK-LEFT	258A4701	1	52-71-13 633/256/L068	ALL
S01113		38HM65 SW-OVERWING FLIGHT LOCK-LEFT FWD	258A4701	1	52-71-13 595/256/L068	YC001-YL430
S01114		38HM65 SW-OVERWING FLIGHT LOCK-RIGHT	258A4701	1	52-71-14 621/256/R068	ALL
S01115		38HM65 SW-OVERWING FLIGHT LOCK-RIGHT FWD	258A4701	1	52-71-14 583/256/R068	YC001-YL430
S01120		MS24523-23 SW-TERRAIN OVERRIDE	69-37369 91929	1	34-49-11 P003-07/ /	YC008-YM670
S01127		MS24525-23 SW-GEAR DOWN DISPATCH SWITCH	284A2211 96906	1	34-21-12 358/166/R007	YK901-YM670
S01129		5849539-1 SW - NGS THERMAL SWITCH	212A5001 70210	1	47-30-11 654/161/L066	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
S01131		80-057-01 SW-SPEED BRAKE GND PROX	251A1730 08748	1	27-62-11 675/194/R067	YK907-YL430

EQUIPMENT LIST

D280A103

Section S01100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01147		602EN1-6 SW - FWD ENTRY DOOR	284A0322 91929	1	52-71-11 347.4/270/53.9	YK907-YM670
S01153		10-2638-4 SW-CABIN PRESS	216A5001 81205	1	21-33-11 196/208/L0.4	YK911-YK917, YL919-YL401, YL427-YL430, YM651-YM670
S01182		SEEPARTA-B SW-COCKIT DOOR ENTRY DIMMING	417A1700	1	SPARE 280/280/R011	YK901-YM670
S01182A		60B40018-32 SW-COCKIT DOOR ENTRY DIMMING - ACTUATOR	417A1700	1	SPARE 280/280/R011	YK901-YM670
S01182B		60B40018-42 SW-COCKIT DOOR ENTRY DIMMING - SENSOR	417A1700	1	SPARE 280/280/R011	YK901-YM670

EQUIPMENT LIST

D280A103

Section S01100
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00006		10-60828-15 XFMR-28V AC	284A0205 81205	1	24-53-11 385/160/R027	ALL
T00010		10-60828-15 XFMR-28V AC	284A0205 81205	1	24-53-11 386/159/L026	ALL
T00011		10-3257-6 TRANSFORMER RECTIFIER UNIT-1	284A0420 81205	1	24-32-11 E002-01/ /	YC001-YC011
T00011		10-3257-6 TRANSFORMER RECTIFIER UNIT-1	284A0421 81205	1	24-32-11 E002-01/ /	YC012-YM670
T00012		10-3257-6 TRANSFORMER RECTIFIER UNIT-2	284A0440 81205	1	24-32-11 E004-02/ /	YC001-YC011
T00012		10-3257-6 TRANSFORMER RECTIFIER UNIT-2	284A0441 81205	1	24-32-11 E004-02/ /	YC012-YM670
T00013		10-3257-6 TRANSFORMER RECTIFIER UNIT-3	284A0440 81205	1	24-32-11 E004-02/ /	YC001-YC011
T00013		10-3257-6 TRANSFORMER RECTIFIER UNIT-3	284A0441 81205	1	24-32-11 E004-02/ /	YC012-YM670
T00028		BACT44C-0250 TERMINAL BLOCK TRACK- 6 POSITIONS	65-52259	0	78-32-51 J002-00/0/	ALL
T00031		16432 XFMR-VARIABLE P5 LIGHTING 0V/28V	233A3303 58474	1	33-12-11 P005-00/ /	ALL
T00033		10-60828-9 XFMR-LIGHTING 28V/5V	233A5201 81205	1	33-12-11 P006-00/ /	ALL
T00034		10-60828-9 XFMR-LIGHTING 28V/5V	233A5201 81205	1	33-12-11 P006-00/ /	ALL
■ T00036		10-60828-11 XFMR-28V AC	S281A601 07217	1	24-53-11 P091-00/ /	ALL
■ T00037		10-60828-11 XFMR-28V AC	S281A601 07217	1	24-53-11 P092-00/ /	ALL
T00038		10-60828-11 XFMR-28V AC	65-52259 81205	1	24-53-11 P018-00/ /	ALL
T00039		16432 XFMR-VARIABLE P8 LTG 0V/28V	69-76435 95266	1	33-11-41 P008-50/ /	ALL
T00040		69071111 XFMR-LIGHTING 28V/5V J19	284A1202 81205	1	33-11-41 251/204/R002	ALL

EQUIPMENT LIST

D280A103

Section T00000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00043		10-60828-10 XFMR-LANDING LIGHT LEFT FIXED	284A0173 81205	1	33-42-11 520/193/L080	ALL
T00044		10-60828-10 XFMR-LANDING LIGHT RIGHT FIXED	284A0173 81205	1	33-42-11 520/193/R080	ALL
T00052		10-60828-15 XFMR-28V AC	65-52259 81205	1	24-53-11 P006-00/ /	ALL
T00060		6430A CONTROL-CB PNL LIGHTS,0-28V	233A3303 95266	1	33-14-12 P005-00/ /	ALL

EQUIPMENT LIST

D280A103

Section T00000
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00184		10-60554-41 XMTR-SYSTEM B HYDRAULIC QUANTITY	276A3100 81205	1	29-31-11 678/194/R043	ALL
T00185	1	S271W731-1 XMTR-BRAKE PRESSURE	274A1520 81205	1	29-32-11 725/166/R028	ALL
T00185	2	10-62254-1 XMTR-BRAKE PRESSURE	274A1520 81205	1	29-32-11 725/166/R028	ALL
T00195		437-1 CT-GND FAULT SYS A ELEC HYDRAULIC PUMP	S281A601 16340	1	29-11-12 P092-00/ /	ALL
T00196		437-1 CT-GND FAULT SYS B ELEC HYDRAULIC PUMP	S281A601 16340	1	29-11-12 P091-00/ /	ALL

EQUIPMENT LIST

D280A103

Section T00100
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00203		MS27212-1-12 TS-INPH E/R	65-63810 96906	1	23-41-01 351/155/L015	ALL
T00205		MS27212-1-6 TS-INPH W/W	65-45401 96906	1	23-41-01 540/188/L024	ALL
T00207		PARTA-B TS-CONT STAND COL F/O CAPT	65-39526 96906	1	23-51-01 227/200/R013	ALL
T00207A		MS27212-2-16 TS-PART A OF T207	65-39526 96906	1	23-51-01 227/200/R013	ALL
T00207B		MS27212-2-2 TS-PART B OF T207	65-39526 96906	1	23-51-01 227/200/R013	ALL
T00209		MS27212-1-12 TS-CONT STAND-P9	65-73705 96906	1	33-11-41 193/210/	ALL
T00213		MS27212-1-12 TS-CONT STAND-P8	65-52460 96906	1	33-11-41 P008-00/ /	ALL
T00234		MS27212-3-1 TS-E2-1 (TR-1)	65-63847 96906	2	24-31-11 380/160/R040	ALL
T00234A		TS-PARTAT234 TS-E3-1	65-63847	1	24-32-01 E003-01/170/R040	ALL
T00234B		TS-PARTBT234 TS-E3-1	65-63847	1	24-31-21 E003-01/170/R040	ALL
T00236		MS27212-3-2 TS-E4-2(TRU-2,TRU-3)	65-63847 96906	1	24-32-11 380/160/R040	ALL
T00252		MS27212-1-6 TS-S845 AND S846	65-49728 96906	1	32-64-11 260/170/00	ALL
T00266		MS27212-1-2 TERMINAL STRIP-LEFT WINDOW 2	69-20829 96906	1	30-41-12 220/230/L045	ALL
T00271		MS27212-2-6 TERMINAL STRIP-LEFT SIDE WINDOW	284A0732 96906	1	30-41-12 380/159/R040	ALL
T00272		MS27212-2-6 TERMINAL STRIP-RIGHT FRONT WINDOW	284A0732 96906	1	30-41-12 380/159/R040	ALL
T00280		MS27212-1-2 TERMINAL STRIP-RIGHT WINDOW NO 2	69-20829 96906	1	30-41-11 220/230/R045	ALL

EQUIPMENT LIST

D280A103

Section T00200
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00332		VENDORSUPPLIEDSEEIPCFORP-NINFO VIBRATION TRANSDUCER, #1 BEARING	332A2000 12812	2	77-31-11 ENG/ /	ALL
T00335		POATERMBLK TB-CAPT CONTROL WHEEL(STAB TRIM SW)	65-45118	1	27-41-11 200/ /	ALL
T00336		POATERMBLK TB-F/O CONTROL WHEEL (STAB TRIM SW)	65-45118	1	27-41-11 200/ /	ALL
T00362		10-60828-9 TS-CONT STAND-P8	284A1202 81205	1	33-11-33 251/204/L001	ALL
T00371		310-14416-01 XFMR-PRESSURIZATION CONTROL-LCD LIGHTING	69-73627 95266	1	21-31-25 P006-00/ /	ALL
T00374		S281A601-12 DPCT GEN 1	281A601 81205	1	24-24-11 P091-00/ /	ALL
T00375		S281A601-12 DPCT GEN 2	281A601 81205	1	24-24-21 P092-00/ /	ALL
T00376		S281A601-12 DPCT APU GEN	281A601 81205	1	24-24-31 P091-00/ /	ALL
T00377		S281A601-12 APU SC XFMR	S281A601 7217	1	24-21-31 P091-00/ /	ALL
T00378		S281A601-12 XFMR-CURRENT LIMIT EXT POWER	281A601 81205	1	24-41-11 P092-00/ /	ALL
T00389		FT1246 XFMR-POSITION LIGHTS RIGHT	284A0181 14752	1	33-43-11 727B/245/R638	YC001-YC019
T00389		FT1348 XFMR-POSITION LIGHTS RIGHT	284A0181 14752	1	33-43-11 727B/245/R638	YC020-YM670
T00390		FT1246 XFMR-POSITION LIGHTS LEFT	284A0181 14752	1	33-43-11 727B/245/L638	YC001-YC019
T00390		FT1348 XFMR-POSITION LIGHTS LEFT	284A0181 14752	1	33-43-11 727B/245/L638	YC020-YM670
T00391		10-60828-10 XFMR-28V AC	65-52259 81205	1	24-53-11 P006-00/ /	ALL
T00392		S283T001-15 XDCCR-L OUTBD ANTISKID	165T0101 81205	1	32-41-11 / /	ALL
T00393		S283T001-15 XDCCR R INBD ANTISKID	165T0101 81205	1	32-41-11 / /	ALL

EQUIPMENT LIST

D280A103

Section T00300

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00394		S283T001-15 XDCR-L INBD ANTISKID	165T0101 81205	1	32-41-11 / /	ALL
T00395		S283T001-15 XDCR-R OUTBD ANTISKID	165T0101 81205	1	32-41-11 / /	ALL
T00396		S315N401-4 LEFT T/R SLEEVE LVDT	315A2801 22863	2	78-35-11 ENG/ /	ALL
T00397		S315N401-4 RIGHT T/R SLEEVE LVDT	315A2801 22863	2	78-35-11 ENG/ /	ALL

EQUIPMENT LIST

D280A103

Section T00300
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00402		MS28034-1 BULB-PASSENGER CABIN SUPPLY DUCT TEMP	214A2001 96906	1	21-61-51 538/299/R010	YM643-YM670
T00403		41SG265-1 XDCCR - R MANIFOLD	210A7101 61349	1	36-21-11 558/160/R042	ALL
T00404		10008792 XMTR-CREW OXYGEN	417A4120 81205	1	35-11-11 391/166/R011	ALL
T00405		41SG265-1 XDCCR - L MANIFOLD	210A7101 61349	1	36-21-11 538/165/L 30	ALL
T00406		398116-1-1 XMTR-PASSENGER CABIN MIX VALVE POSITION	213A1002 70210	1	21-61-22 644/158/R012	YM643-YM670
T00407		398116-1-1 XMTR-CONTROL CABIN MIX VALVE POSITION	213A1002 70210	1	21-61-21 644/158/L012	YM643-YM670
T00408		30136-0106 XMTR-WATER QUANTITY	417A2510 81205	1	38-41-11 951/186/R036	ALL
T00416		10-60498-7 SNSR-PASS CABIN DUCT LIMIT	214A2001 81205	1	21-61-22 534/299/R010	YM643-YM670
T00417		10-60498-4 SNSR-PASS CABIN DUCT ANTICIPATOR	214A2001 81205	1	21-61-22 535/299/R010	YM643-YM670
T00419		10-60498-7 SENSOR-CONT CAB DUCT LIMIT	214A1002 81205	1	21-61-21 372/195/L055	YM643-YM670
T00420		10-60498-4 SENSOR-CONT CAB DUCT ANTICIP	214A1002 81205	1	21-61-21 371/192/L058	YM643-YM670
T00421		VENDORSUPPLIEDSEEIPCFORP-NINFO XMTR-N1 SPEED	332A2000 12812	2	77-12-11 ENG/ /	ALL
T00422		VENDORSUPPLIEDSEEIPCFORP-NINFO XMTR-N2 SPEED	332A2000 12812	2	77-12-21 ENG/ /	ALL
T00423	1	S271W731-1 XMTR-SYSTEM B OIL PRESSURE	271A2442 81205	1	29-32-11 666/181/R014	ALL
T00423	2	10-62254-1 XMTR-SYSTEM B OIL PRESSURE	271A2442 81205	1	29-32-11 666/181/R014	ALL
T00424	1	S271W731-1 XMTR-SYSTEM A OIL PRESSURE	271A2442 81205	1	29-32-11 666/180/L039	ALL
T00424	2	10-62254-1 XMTR-SYSTEM A OIL PRESSURE	271A2442 81205	1	29-32-11 666/180/L039	ALL

EQUIPMENT LIST

D280A103

Section T00400

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00427		S256A404-50 XMTR-LEFT TE FLAP POSITION	256A3905 81205	1	27-52-11 443/RSS/L	YC001-YK906
T00427		S256A404-53 XMTR-LEFT TE FLAP POSITION	256A3905 81205	1	27-52-11 443/RSS/L	YK907-YM670
T00428		S256A404-50 XMTR-RIGHT TE FLAP POSITION	256A3905 81205	1	27-52-11 443/RSS/R	YC001-YK906
T00428		S256A404-53 XMTR-RIGHT TE FLAP POSITION	256A3905 81205	1	27-52-11 443/RSS/R	YK907-YM670
T00429		VENDORSUPPLIEDSEEIPCFORP-NINFO ENGINE OIL PRESSURE	322A2000 12812	2	79-32-11 ENG/ /	ALL
T00430		627570-1 SNSR-LEFT 35 DEG F	213A1002 70210	1	21-51-16 553/152/L017	YM643-YM670
T00431		627570-1 SNSR-RIGHT 35 DEG F	213A1002 70210	1	21-51-26 553/152/R025	YM643-YM670
T00432		VENDORSUPPLIEDSEEIPCFORP-NINFO SNSR-ENGINE OIL TEMPERATURE	332A2000 12812	2	79-34-10 ENG/ /	ALL
T00433		S233T913-4 SNSR-ANGLE OF AIRFLOW LEFT	232A9300 81205	1	27-32-11 192/204/	YC001-YC026, YM643-YM670
T00433		S233T913-5 SNSR-ANGLE OF AIRFLOW LEFT	232A9300 81205	1	27-32-11 192/204/	YC028-YL430
T00434		10-62247-1 SNSR-FUEL TEMPERATURE TANK 1	65-46514 81205	1	28-42-11 ORSS/208/	ALL
T00435		VENDORSUPPLIEDSEEIPCFORP-NINFO XMTR-FUEL FLOW	332A1043 12812	2	73-31-11 ENG/ /	ALL
T00436		10-60554-40 XMTR-SYSTEM A HYDRAULIC QUANTITY	65-44600 81205	1	29-31-11 679/196/R008	ALL
T00437		S233T913-4 SNSR-ANGLE OF AIRFLOW-RIGHT	232A9300 81205	1	27-32-21 192/204/	YC001-YC026, YM643-YM670
T00437		S233T913-5 SNSR-ANGLE OF AIRFLOW-RIGHT	232A9300 81205	1	27-32-21 192/204/	YC028-YL430
T00438		617166-1 SNSR-LEFT RAM AIR	213A1001 70210	1	21-51-14 583/161/L031	YM643-YM670
T00439		617166-1 SNSR-RIGHT RAM AIR	213A1001 70210	1	21-51-24 583/161/R031	YM643-YM670

EQUIPMENT LIST

D280A103

Section T00400

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00465		S250N104-4 XMTR-AILERON POSITION LEFT	251A1130 81205	1	27-18-11 LWING505/ /	ALL
T00466		S250N104-4 XMTR-AILERON POSITION RIGHT	251A1130 81205	1	27-18-11 RWING505/ /	ALL
T00467		S250N104-4 XMTR-ELEVATOR POSITION LEFT	251A2402 81205	1	27-38-11 LELEVPOS/30/	ALL
T00468		S250N104-4 XMTR-ELEVATOR POSITION RIGHT	251A2402 81205	1	27-38-11 RELEVPOS/30/	ALL
T00469		S250N104-4 XMTR-RUDDER POSITION	251A3480 81205	1	27-28-11 RUD80.00/ /	ALL
T00471		10-62091-11 SNSR-LEFT PACK TEMPERATURE	213A1002 81205	1	21-51-12 573/154/L030	YC001-YL430
T00472		10-62091-14 SNSR-LEFT MIX MANIFOLD TEMPERATURE	214A3003 81205	1	21-51-12 500I+7/192/L003	YC001-YL430
T00474		10-62091-11 SNSR-RIGHT PACK TEMPERATURE	213A1002 81205	1	21-51-22 573/154/R030	YC001-YL430
T00475		10-62091-14 SNSR-RIGHT MIX MANIFOLD	214A3003 81205	1	21-51-22 5002+7/192/R003	YC001-YL430
T00477		10-62091-14 SNSR-CONTROL CABIN DUCT TEMP BACK UP	214A1002 81205	1	21-61-12 372/196/L057	YC001-YL430
T00478		10-62091-14 SNSR-CONTROL CABIN DUCT TEMP PRIMARY	214A1002 81205	1	21-61-11 372/196/L057	YC001-YL430
T00481		1150002-1 SNSR-LEFT RAM AIR	213A1002 70210	1	21-51-14 584/162/L032	YC001-YL430
T00482		1150002-1 SNSR-RIGHT RAM AIR	213A1002 70210	1	21-51-24 584/162/R032	YC001-YL430
T00485		MS28034-1 BULB-CONTROL CABIN SUPPLY TEMPERATURE	214A1002 96906	1	21-61-51 371/194/L058	YC001-YL430
T00488		MS28034-1 BULB-LEFT PACK TEMPERATURE	213A1003 96906	1	21-61-51 573/152/L033	YC001-YL430
T00489		MS28034-1 BULB-RIGHT PACK TEMPERATURE	213A1003 96906	1	21-61-51 574/152/R033	YC001-YL430
T00492		65C36032-1 XMTR-MAIN BRAKE HYDRAULIC PRESSURE	274A1830 81205	1	31-31-14 727/187/L020	ALL

EQUIPMENT LIST

D280A103

Section T00400

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00493		65C36032-1 XMTR-MAIN BRAKE HYDRAULIC PRESSURE	274A1830 81205	1	31-31-14 727/189/L008	ALL
T00494		65C36032-1 XMTR-L ALT BRAKE HYDRAULIC PRESSURE	274A1810 81205	1	31-31-14 685/195/L065	ALL
T00495		65C36032-1 XMTR-R ALT BRAKE HYDRAULIC PRESSURE	274A1820 81205	1	31-31-14 692/192/L065	ALL

EQUIPMENT LIST

D280A103

Section T00400
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00504		899-156-612 SNSR-POINT LEVEL	41748670 61349	1	38-32-12 900/185/L015	ALL
T00505		899-156-612 SNSR-POINT LEVEL	417A8670 61349	1	38-32-12 900/185/L015	ALL
T00506		1721F4 SNSR-CONTINUOUS LEVEL	417A8680 81205	1	38-32-12 870/180/L025	ALL
T00507		4082740-901 REMOTE LIGHT SENSOR-CAPT	58960	1	31-62-11 P007-00/ /	YC001-YC030, YK901-YM670
T00508		4082740-901 REMOTE LIGHT SENSOR-F/O	58960	1	31-62-21 P007-00/ /	YC001-YC030, YK901-YM670
T00509		VENDORSUPPLIEDSEEIPCFORP-NINFO SNSR-FAN INLET TEMPERATURE T12	332A2000 12812	2	75-31-12 ENG/ /	ALL
T00510		VENDORSUPPLIEDSEEIPCFORP-NINFO SNSR-LP TURBINE DISCHARGE TEMPERATURE T5	332A2000 12812	2	75-31-11 ENG/ /	YC001-YC050
T00511		VENDORSUPPLIEDSEEIPCFORP-NINFO SNSR-HP TURBINE CASE TEMPERATURE	332A2000 1Z812	2	75-31-11 ENG/ /	ALL
T00513		VENDORSUPPLIEDSEEIPCFORP-NINFO SNSR-HP COMPRESSOR INLET TEMPERATURE T25	332A2000 12812	2	75-31-11 ENG/ /	ALL
T00514		VENDORSUPPLIEDSEEIPCFORP-NINFO SNSR-HP COMPRESSOR DISCHARGE TEMPERATURE	332A2000 12812	2	75-31-11 ENG/ /	ALL
T00515		VENDORSUPPLIEDSEEIPCFORP-NINFO XDCR-HP TURBINE CLEARANCE VALVE POSITION	332A2000 12812	2	75-31-11 ENG/ /	ALL
T00516		VENDORSUPPLIEDSEEIPCFORP-NINFO XDCR-LP TURBINE CLEARANCE VALVE POSITION	332A2000 12812	2	75-31-11 ENG/ /	ALL
T00517		VENDORSUPPLIEDSEEIPCFORP-NINFO XDCR-VARIABLE STATOR VANE CHAN A POSN	332A2000 12812	2	75-31-12 ENG/ /	ALL
T00518		VENDORSUPPLIEDSEEIPCFORP-NINFO XDCR-VARIABLE STATOR VANE CHAN B POSN	332A2000 12812	2	75-31-12 ENG/ /	ALL
T00519		VENDORSUPPLIEDSEEIPCFORP-NINFO VLV-TRANSIENT BLEED	332A2000 12812	2	75-31-12 ENG/ /	ALL
T00520		VENDORSUPPLIEDSEEIPCFORP-NINFO VLV-VARIABLE BLEED TRANSDUCER POSITION	332A2000 12812	2	75-31-12 ENG/ /	ALL
T00521		VENDORSUPPLIEDSEEIPCFORP-NINFO THERMOCOUPLE-EXHAUST GAS TEMP T49.5	332A2000 12812	2	77-21-11 ENG/ /	ALL

EQUIPMENT LIST

D280A103

Section T00500

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00522		VENDORSUPPLIEDSEEIPCFORP-NINFO THERMOCOUPLE-EXHAUST GAS TEMP T49.5	332A2000 12812	2	77-21-11 ENG/ /	ALL
T00523		VENDORSUPPLIEDSEEIPCFORP-NINFO THERMOCOUPLE-EXHAUST GAS TEMP T49.5	332A2000 12812	2	77-21-11 ENG/ /	ALL
T00524		VENDORSUPPLIEDSEEIPCFORP-NINFO THERMOCOUPLE-EXHAUST GAS TEMP - T49.5	332A2000 12812	2	77-21-11 ENG/ /	ALL
T00525		S256A404-1 SNSR-TRAILING EDGE FLAP SKEW 1	256A3901 81205	1	27-53-21 WING LBL/357/	YC001-YK906
T00525		S256A404-3 SNSR-TRAILING EDGE FLAP SKEW 1	256A3901 81205	1	27-53-21 WING LBL/357/	YK907-YM670
T00526		S256A404-1 SNSR-TRAILING EDGE FLAP SKEW 2	256A3902 81205	1	27-53-21 WING LBL/254/	YC001-YK906
T00526		S256A404-3 SNSR-TRAILING EDGE FLAP SKEW 2	256A3902 81205	1	27-53-21 WING LBL/254/	YK907-YM670
T00527		S256A404-1 SNSR-TRAILING EDGE FLAP SKEW 3	256A3903 81205	1	27-53-21 WING LBL/164/	YC001-YK906
T00527		S256A404-3 SNSR-TRAILING EDGE FLAP SKEW 3	256A3903 81205	1	27-53-21 WING LBL/164/	YK907-YM670
T00528		S256A404-1 SNSR-TRAILING EDGE FLAP SKEW 4	256A3904 81205	1	27-53-21 WING LBL/65/	YC001-YK906
T00528		S256A404-3 SNSR-TRAILING EDGE FLAP SKEW 4	256A3904 81205	1	27-53-21 WING LBL/65/	YK907-YM670
T00529		S256A404-1 SNSR-TRAILING EDGE FLAP SKEW 5	256A3904 81205	1	27-53-21 WING RBL/65/	YC001-YK906
T00529		S256A404-3 SNSR-TRAILING EDGE FLAP SKEW 5	256A3904 81205	1	27-53-21 WING RBL/65/	YK907-YM670
T00530		S256A404-1 SNSR-TRAILING EDGE FLAP SKEW 6	256A3903 81205	1	27-53-21 WING RBL/164/	YC001-YK906
T00530		S256A404-3 SNSR-TRAILING EDGE FLAP SKEW 6	256A3903 81205	1	27-53-21 WING RBL/164/	YK907-YM670
T00531		S256A404-1 SNSR-TRAILING EDGE FLAP SKEW 7	256A3902 81205	1	27-53-21 WING RBL/254/	YC001-YK906
T00531		S256A404-3 SNSR-TRAILING EDGE FLAP SKEW 7	256A3902 81205	1	27-53-21 WING RBL/254/	YK907-YM670

EQUIPMENT LIST

D280A103

Section T00500

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00532		S256A404-1 SNSR-TRAILING EDGE FLAP SKEW 8	256A3901 81205	1	27-53-21 WING RBL/357/	YC001-YK906
T00532		S256A404-3 SNSR-TRAILING EDGE FLAP SKEW 8	256A3901 81205	1	27-53-21 WING RBL/357/	YK907-YM670
T00533		10-62091-14 SNSR-FWD CABIN DUCT TEMPERATURE	214A2011 81205	1	21-61-13 500F+7/299/L012	YC001-YL430
T00534		MS28034-1 BULB-FWD CABIN SUPPLY TEMPERATURE	214A2011 96906	1	21-61-51 500F+9/300/L012	YC001-YL430
T00535		MS28034-1 BULB-AFT CABIN SUPPLY TEMPERATURE	214A2011 96906	1	21-61-51 535/299/R012	YC001-YL430
T00536		10-62091-14 SNSR-AFT CABIN DUCT	214A2011 81205	1	21-61-14 537/299/R012	YC001-YL430
T00537	1	VENDORSUPPLIEDSEEIPCFORP-NINFO SNSR-FAN FRAME COMPRESSOR CASE VIBRATION	332A200 12812	2	77-31-11 ENG/ /	ALL
T00538		U-221557-8 SNSR-FLAP HANDLE	253T4015 82686	1	27-51-11 214/215/RBL3	ALL
T00539		S250N104-4 XMTR-SPILER 3 POSITION	251A1230	1	27-62-14 727+18.0/215/L287	ALL
T00540		S250N104-4 XMTR-SPILER 10 POSITION	251A1230	1	27-62-14 727+18.0/215/R287	ALL
T00541		S251A303-1 ROD-RUDDER PEDAL FORCE TRANSDUCER	251A3450 22863	1	31-31-14 51/ /0000	YC008-YM670
T00542		VENDORSUPPLIEDSEEIPCFORP-NINFO VLV-VARIABLE BLEED TRANSDUCER POSITION	332A2000 12812	2	75-31-12 ENG/ /	ALL

EQUIPMENT LIST

D280A103

Section T00500

Page 3 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T03009	1	0017CC VIDEO TRANSFORMER	417A7360 70093	1	23-32-13 MULTI/ /	YK901-YM670
T03009	2	159007 VIDEO TRANSFORMER	417A7360 70093	1	23-32-13 MULTI/ /	YK901-YM670
T03019		65C36032-1 XMTR-STANDBY HYDRAULIC PRESSURE	271A5441 81205	1	31-31-14 727/187/	YC031-YM670
T03020		1153174-1 SNSR - NGS TEMP SENSOR	212A5001 07217	1	47-30-11 657/161/L066	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
T03021		NH16031 IMPEDANCE TRANSFORMER	417A6400	1	23-70-11 340/293/LBL5	YK907-YL401
T03021		NH16031 IMPEDANCE TRANSFORMER	284A0TBD	1	23-70-11 340/293/LBL5	YL421-YM670
T03022		NH16031 IMPEDANCE TRANSFORMER	417A6400	1	23-70-11 340/293/0	YK907-YL401
T03022		NH16031 IMPEDANCE TRANSFORMER	284A0TBD	1	23-70-11 340/293/0	YL421-YM670
T03023		NH16031 IMPEDANCE TRANSFORMER	417A6400	1	23-70-11 340/293/RBL5	YK907-YL401
T03023		NH16031 IMPEDANCE TRANSFORMER	284A0TBD	1	23-70-11 340/293/RBL5	YL421-YM670
T03027		NH15227 VIDEO TRANSFORMER W TNC (50/50)	284A0480	1	23-32-21 E008-01/ /	YK911-YK917, YK919-YL401, YL427-YL430, YM647-YM670

EQUIPMENT LIST

D280A103

Section T03000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
■ TB0002K		M81714-3-BD1 TERMINAL BLOCK		2	32-41-11 695/140/L118	ALL
■ TB0002L		M81714-3-BB1 TERMINAL BLOCK		1	32-41-11 695/140/L118	ALL
■ TB0004K		M81714-3-BD1 TERMINAL BLOCK		2	32-41-11 695/140/L111	ALL
■ TB0004L		M81714-3-BB1 TERMINAL BLOCK		1	32-41-11 695/140/L111	ALL
■ TB0006K		M81714-3-BD1 TERMINAL BLOCK		2	32-41-11 695/140/	ALL
■ TB0006L		M81714-3-BB1 TERMINAL BLOCK		1	32-41-11 695/140/	ALL
■ TB0008K		M81714-3-BD1 TERMINAL BLOCK		2	32-41-11 605/140/R111	ALL
■ TB0008L		M81714-3-BB1 TERMINAL BLOCK		1	32-41-11 605/140/R111	ALL
TB0020		S280W555-506 TRACK-TERMINAL BLOCK	284A1203 81205	1	32-31-11 J020-0B/ /	ALL
TB0020Y		S280W555-104 TERMINAL BLOCK -	286A0072 81205	1	32-31-12 J020-0B/ /	ALL
TB0020Z		S280W555-108 TERMINAL BLOCK -	286A0072 81205	1	21-27-31 J020-0B/ /	ALL
TB0022		S280W555-506 TRACK-TERMINAL BLOCK	284A1222 81205	1	32-31-11 J022-00/ /	ALL
TB0022Y		S280W555-104 TERMINAL BLOCK-	284A1222 81205	1	31-31-11 J022-00/ /	ALL
TB0022Z		S280W555-108 TERMINAL BLOCK-	284A1222 81205	1	32-31-11 J022-00/ /	ALL
TB0023		S280W555-504 TRACK-TERMINAL BLOCK	284A1223 81205	1	35-21-11 J023-00/ /	YC001-YC050
TB0023		S280W555-506 TRACK-TERMINAL BLOCK	284A1223 81205	1	35-21-11 J023-00/ /	YK901-YM670
TB0023V		S280W555-203 MDL-TERMINAL BLOCK	284A1223 81205	1	35-21-11 J023-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB0000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0023Y		S280W555-104 MDL-TERMINAL BLOCK	284A1223 81205	2	35-21-11 J023-00/ /	ALL
TB0024		S280W555-504 TRACK-TERMINAL BLOCK	284A1224 81205	1	78-32-61 J024-00/ /	YC001-YC030
TB0024		S280W555-506 TRACK-TERMINAL BLOCK	284A1224 81205	1	78-32-61 J024-00/ /	YC031-YM670
TB0024B		S280W555-753 DIODE-M01644	284A1224	1	78-32-61 J024-00/ /	ALL
TB0024Y		S280W555-104 TERMINAL BLOCK-	284A1224 81205	1	78-32-61 J024-00/ /	ALL
TB0024Z		S280W555-108 TERMINAL BLOCK-	284A1224 81205	1	31-31-11 J024-00/ /	ALL
TB0025		S280W555-604 TRACK-TERMINAL BLOCK	284A1214 81205	1	29-25-11 J011-00/ /	ALL
TB0025V		S280W555-203 TERMINAL BLOCK-	284A1214 81205	1	29-25-11 J011-00/ /	ALL
TB0025Y		S280W555-104 TERMINAL BLOCK-	284A1214 81205	1	29-25-11 J011-00/ /	ALL
TB0028		S280W555-502 TRACK-TERMINAL BLOCK	284A1203 81205	1	21-31-22 J020-0A/ /	YC028-YM670
TB0028Y		S280W555-104 TERMINAL BLOCK -	286A0074 81205	1	21-31-22 J020-0A/ /	ALL
TB0030		S280W555-506 TRACK-TERMINAL BLOCK	284A1203 81205	1	25-51-11 J020-0A/ /	ALL
TB0030V		S280W555-203 TERMINAL BLOCK -	286A0074 81205	1	25-51-11 J020-0A/ /	YK901-YL430
TB0030Y		S280W555-104 TERMINAL BLOCK -	286A0074 81205	1	25-51-11 J020-0A/ /	YK901-YL430
TB0032		S280W555-504 TRACK-TERMINAL BLOCK	284A1222 81205	1	32-41-11 J022-00/ /	ALL
TB0032V		S280W555-203 TERMINAL BLOCK-	284A1222 81205	1	32-41-11 J022-00/ /	ALL
TB0032W		S280W555-206 TERMINAL BLOCK-	284A1222 81205	1	32-41-11 J022-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB0000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0032Y		S280W555-104 TERMINAL BLOCK-	284A1222 81205	1	32-41-11 J022-00/ /	ALL
TB0032Z		S280W555-108 TERMINAL BLOCK-	284A1222 81205	1	34-49-11 J022-00/ /	YK901-YM670
TB0033		S280W555-504 TRACK-TERMINAL BLOCK	284A1223 81205	1	35-21-11 J023-00/ /	YK901-YM670
TB0033V		S280W555-203 MDL-TERMINAL BLOCK	284A1223 81205	1	52-61-11 */**	ALL
TB0033Y		S280W555-104 MDL-TERMINAL BLOCK	284A1223 81205	1	34-54-12 */**	ALL
TB0033Z		S280W555-108 MDL-TERMINAL BLOCK	284A1223 81205	1	52-61-11 */**	ALL
TB0034		S280W555-502 TRACK-TERMINAL BLOCK	284A1224 81205	1	78-32-61 J024-00/ /	YC001-YC030
TB0034		S280W555-504 TRACK-TERMINAL BLOCK	284A1224 81205	1	78-32-61 J024-00/ /	YC031-YM670
TB0034Y		S280W555-104 TERMINAL BLOCK-	284A1224 81205	1	21-27-21 J024-00/ /	ALL
TB0040K		M81714-3-DD1 TERMINAL BLOCK	96906	3	32-31-11 290/181/L015	YC001-YC030, YK901-YM670
TB0042K		M81714-3-DD1 TERMINAL BLOCK	96906	1	32-64-11 258/181/L015	YC001-YC030, YK901-YM670
TB0044K		M81714-3-DD1 TERMINAL BLOCK	96906	1	32-64-12 287/173/R14	YC001-YC003
TB0044K		M81714-3-DD1 TERMINAL BLOCK	96906	1	32-64-12 287/173/R014	YC004-YC030, YK901-YM670
TB0046K		M81714-3-DD1 TERMINAL BLOCK	96906	1	32-64-12 286/184/R17	YC001-YC003
TB0046K		M81714-3-DD1 TERMINAL BLOCK	96906	1	32-64-12 257/181/R014	YC004-YC030, YK901-YM670

EQUIPMENT LIST

D280A103

Section TB0000

Page 3 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0101		S280W555-506 TRACK-TERMINAL BLOCK	288A4151 81205	1	31-62-11 P001-00/ /	ALL
TB0101Y		S280W555-104 TERMINAL BLOCK	288A4151 81205	1	31-62-11 P001-00/ /	ALL
TB0101Z		S280W555-108 TERMINAL BLOCK	288A4151 81205	1	31-62-11 P001-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB0100
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0201		S280W555-506 TRACK-TERMINAL BLOCK	288A4151 81205	1	27-52-11 P002-00/ /	ALL
TB0201Y		S280W555-104 TERMINAL BLOCK	288A4151 81205	1	27-52-11 P002-00/ /	ALL
TB0201Z		S280W555-108 TERMINAL BLOCK	288A4151 81205	1	32-64-11 P002-00/ /	ALL
TB0205		S280W555-502 TRACK-TERMINAL BLOCK	286A5345 81205	0	23-41-01 540/188/R025	ALL
TB0205V		S280W555-203 TERMINAL BLOCK	286A5224 81205	1	29-25-11 534/190/R024	ALL
TB0205W		S280W555-206 TERMINAL BLOCK-	65-45401 81205	3	23-41-01 540/188/R025	ALL
TB0261		S280W555-504 TRACK-TERMINAL BLOCK	287A4106 81205	1	73-21-12 261/280/R005	ALL
TB0261X		S280W555-102 TERMINAL BLOCK-	287A4106 81205	1	73-21-12 261/280/R005	ALL
TB0261Y		S280W555-104 TERMINAL BLOCK-	287A4106 81205	1	73-21-12 261/280/R005	ALL
TB0262		S280W555-504 TRACK-TERMINAL BLOCK	287A4106 81205	1	73-21-12 264/280/R005	ALL
TB0262V		S280W555-203 TERMINAL BLOCK	287A4106 81205	1	33-14-12 261/280/R007	ALL
TB0262X		S280W555-102 TERMINAL BLOCK-	287A4106 81205	1	73-21-12 264/280/R005	ALL
TB0262Y		S280W555-104 TERMINAL BLOCK-	287A4106 81205	1	73-21-12 264/280/R005	ALL

EQUIPMENT LIST

D280A103

Section TB0200

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0301		S280W555-506 TRACK-TERMINAL BLOCK	288A4151 81205	1	31-62-23 P003-00/ /	ALL
TB0301Y		S280W555-104 TERMINAL BLOCK	288A4151 81205	1	31-62-23 P003-00/ /	ALL
TB0301Z		S280W555-108 TERMINAL BLOCK	288A4151 81205	1	31-62-23 P003-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB0300
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0403Y		S280W555-104 TERMINAL BLOCK-	284A1204 81205	1	23-32-14 J004-00/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section TB0400
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0501		S280W555-608 TRACK-TERMINAL BLOCK	287A4109 81205	1	24-32-11 P005-00/ /	ALL
TB0501V		S280W555-203 TERMINAL BLOCK-	287A4109 81205	1	33-14-12 P005-00/ /	ALL
TB0501X		S280W555-102 TERMINAL BLOCK-	287A4109 81205	1	28-21-11 250/279/L09	ALL
TB0501Y		S280W555-104 TERMINAL BLOCK-	287A4109 81205	1	28-21-11 250/279/L09	ALL
TB0501Z	9	S280W555-108 TERMINAL BLOCK-	287A4109 81205	1	33-12-12 P005-00/ /	YC001-YC007
TB0501Z		S280W555-108 TERMINAL BLOCK-	287A4109 81205	1	33-12-12 P005-00/ /	YC008-YM670
TB0502		S280W555-608 TRACK-TERMINAL BLOCK	287A4109 81205	1	24-32-11 P005-00/ /	ALL
TB0502V		S280W555-203 TERMINAL BLOCK-	287A4109 81205	1	33-41-11 P005-00/ /	ALL
TB0502Y		S280W555-104 TERMINAL BLOCK-	287A4109 81205	5	33-18-32 P005-00/ /	ALL
TB0502Z		S280W555-108 TERMINAL BLOCK-	287A4109 81205	1	33-18-32 P005-00/ /	ALL
TB0503		S280W555-608 TRACK-TERMINAL BLOCK	287A4109 81205	1	33-18-42 P005-00/ /	ALL
TB0503V		S280W555-203 TERMINAL BLOCK-	287A4109 81205	1	30-42-11 P005-00/ /	ALL
TB0503X		S280W555-102 TERMINAL BLOCK-	287A4109 81205	1	23-42-11 P005-00/ /	ALL
TB0503Y		S280W555-104 TERMINAL BLOCK-	287A4109 81205	1	31-52-25 251/278/L09	ALL
TB0503Z		S280W555-108 TERMINAL BLOCK-	287A4109 81205	1	21-27-21 P005-00/ /	ALL
TB0504		S280W555-604 TRACK-TERMINAL BLOCK	287A4109 81205	1	21-31-11 P005-00/ /	ALL
TB0504P		S280W555-102 MDL-TERMINAL BLOCK	61-30038 81205	1	21-61-22 P005-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB0500

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0504Q		S280W555-104 MDL-TERMINAL BLOCK	61-30038 81205	1	21-31-11 P005-00/ /	ALL
TB0504X		S280W555-102 TERMINAL BLOCK-	287A4109 81205	1	21-61-22 P005-00/ /	ALL
TB0504Y		S280W555-104 TERMINAL BLOCK-	287A4109 81205	1	21-31-11 254/280/R03	ALL
TB0505		S280W555-608 TRACK-TERMINAL BLOCK	287A4109 81205	1	21-27-21 P005-00/ /	ALL
TB0505Q		S280W555-104 MDL-TERMINAL BLOCK	61-30038 81205	1	21-27-21 P005-00/ /	ALL
TB0505V		S280W555-203 TERMINAL BLOCK-	287A4109 81205	1	30-42-11 P005-00/ /	ALL
TB0505Y		S280W555-104 TERMINAL BLOCK-	287A4109 81205	1	21-27-21 P005-00/ /	ALL
TB0505Z	9	S280W555-108 TERMINAL BLOCK-	287A4109 81205	1	23-43-11 P005-00/ /	YC001-YC007
TB0506		S280W555-604 TRACK-TERMINAL BLOCK	287A4109 81205	1	24-32-11 P005-00/ /	ALL
TB0506P	1	S280W555-102 MODULE-TERMINAL BLOCK	61-30038 81205	1	21-61-31 P005-00/ /	ALL
TB0506Q		S280W555-104 MDL-TERMINAL BLOCK	61-30038 81205	1	23-42-11 P005-00/ /	ALL
TB0506U		S280W555-108 MDL-TERMINAL BLOCK	61-30038 81205	1	23-42-11 P005-00/ /	ALL
TB0506X		S280W555-102 TERMINAL BLOCK-	287A4109 81205	1	21-61-31 255/278/R03	ALL
TB0506Y		S280W555-104 TERMINAL BLOCK-	287A4109 81205	1	21-61-21 P005-00/ /	ALL
TB0506Z		S280W555-108 TERMINAL BLOCK-	287A4109 81205	1	36-21-11 P005-00/ /	ALL
TB0507		S280W555-604 TRACK-TERMINAL BLOCK	287A4109 81205	1	33-18-33 P005-00/ /	ALL
TB0507Y		S280W555-104 TERMINAL BLOCK-	287A4109 81205	1	33-18-33 P005-00/ /	YC008-YM670

EQUIPMENT LIST

D280A103

Section TB0500

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0507Z		S280W555-108 TERMINAL BLOCK-	287A4109 81205	1	33-12-11 P005-00/ /	YC008-YM670
TB0508		S280W555-604 TRACK-TERMINAL BLOCK	287A4109 81205	1	33-12-11 P005-00/ /	ALL
TB0508Y		S280W555-104 TERMINAL BLOCK-	287A4109 81205	1	33-18-34 P005-00/ /	YC008-YM670
TB0508Z		S280W555-108 TERMINAL BLOCK-	287A4109 81205	1	33-12-11 P005-00/ /	YC008-YM670
TB0521	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2750 81205	1	34-61-23 E005-02/ /	ALL
TB0521Y		S280W555-104 TERMINAL BLOCK-	284A2750 81205	1	34-21-11 E005-02/ /	ALL
TB0521Z		S280W555-108 TERMINAL BLOCK-	284A2750 81205	1	34-21-13 E005-02/ /	ALL
TB0522	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2750 81205	1	34-61-15 E005-02/ /	ALL
TB0522Y	1	S280W555-104 MDL-TERMINAL BLOCK	284A2750 81205	1	34-21-11 E005-02/ /	ALL
TB0522Z		S280W555-108 MDL-TERMINAL BLOCK	284A2750 81205	1	34-21-24 E005-02/ /	ALL
TB0523	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2750 81205	1	34-61-14 E005-02/ /	ALL
TB0523Y	1	S280W555-104 MDL-TERMINAL BLOCK	284A2750 81205	1	34-21-11 E005-02/ /	ALL
TB0523Z		S280W555-108 MDL-TERMINAL BLOCK	284A2750 81205	1	34-21-14 E005-02/ /	ALL
TB0524	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2750 81205	1	34-61-14 E005-02/ /	ALL
TB0524Y		S280W555-104 TERMINAL BLOCK	284A2750 81205	1	34-21-11 E005-02/ /	ALL
TB0524Z		S280W555-108 TERMINAL BLOCK-	284A2750 81205	1	34-21-14 E005-02/ /	ALL
TB0536		S280W555-602 TRACK-TERMINAL BLOCK	287A9112 81205	1	21-51-16 542/159/L026	YM643-YM670

EQUIPMENT LIST

D280A103

Section TB0500

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0536Y		S280W555-104 TERMINAL-BLOCK	287A9112 81205	1	21-51-16 542/160/L028	YM643-YM670
TB0591X		S280W555-102 MODULE-TERMINAL BLOCK	284A1225 81205	1	34-61-12 P059-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB0500
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0602		S280W555-516 TRACK-TERMINAL BLOCK	233A5201 81205	1	21-27-31 261/191/R028	YC001-YC003
TB0602V		S280W555-203 TERMINAL BLOCK-	233A5201 81205	1	24-11-21 261/192/R035	YC001-YC003
TB0602X		S280W555-102 TERMINAL BLOCK-	233A5201 81205	7	21-27-21 261/192/R035	YC001-YC003
TB0602Y		S280W555-104 TERMINAL BLOCK-	233A5201 81205	3	21-27-21 261/192/R035	YC001-YC003
TB0604		S280W555-516 TRACK-TERMINAL BLOCK	233A5201 81205	1	21-27-31 261/191/R028	YC001-YC003
TB0604V		S280W555-203 MODULE-TERMINAL BLOCK	233A5201 81205	1	33-45-11 261/186/R035	YC001-YC003
TB0604X		S280W555-102 TERMINAL BLOCK-	233A5201 81205	4	21-27-21 261/185/R036	YC001-YC003
TB0604Y		S280W555-104 TERMINAL BLOCK-	233A5201 81205	5	21-27-21 261/186/R036	YC001-YC003
TB0604Z		S280W555-108 TERMINAL BLOCK-	233A5201 81205	1	30-11-11 261/186/R035	YC001-YC003
TB0606		S280W555-504 TRACK-TERMINAL BLOCK	287A4130 81205	1	78-32-61 270/176/R027	YC004-YM670
TB0606V		S280W555-203 TERMINAL BLOCK	287A4130 81205	2	78-32-61 270/176/R027	YC004-YM670
TB0606X		S280W555-102 TERMINAL BLOCK	287A4130 81205	1	23-42-11 270/176/R027	YC004-YM670
TB0606Y		S280W555-104 TERMINAL BLOCK-	287A4130	1	34-55-21 270/176/R027	YC004-YM670
TB0608		S280W555-504 TRACK-TERMINAL BLOCK	287A4130 81205	1	30-42-11 J046-00/ /	YC004-YM670
TB0608X		S280W555-102 TERMINAL BLOCK	287A4130 81205	1	21-25-11 268/175/R028	ALL
TB0608Z		S280W555-108 TERMINAL BLOCK	287A4130 81205	1	23-42-11 268/175/R028	YK901-YM670
TB0610		S280W555-604 TRACK-TERMINAL BLOCK	233A5305 81205	1	32-42-11 P006-00/ /	YC001-YC020

EQUIPMENT LIST

D280A103

Section TB0600

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0610		S280W555-606 TRACK-TERMINAL BLOCK	233A5305 81205	1	32-42-11 P006-00/ /	YC021-YM670
TB0610X		S280W555-102 TERMINAL BLOCK-	288A4154 81205	1	34-61-18 P006-00/ /	ALL
TB0610Y		S280W555-104 TERMINAL BLOCK-	284RXXXX 81205	1	32-42-11 P006-00/ /	ALL
TB0612		S280W555-604 TRACK-TERMINAL BLOCK	233A5302 81205	1	24-11-11 P006-00/ /	ALL
TB0621Y		S280W555-104 TERMINAL BLOCK-	81205	1	23-11-11 E006-02/ /	YM643-YM670
TB0636		S280W555-602 TRACK-TERMINAL BLOCK	287TBDD 81205	1	21-51-26 537/159/R028	YM643-YM670
TB0636Y		S280W555-104 TERMINAL-BLOCK	287ATBD 81205	1	21-51-26 541/159/R026	YM643-YM670
TB0660		S280W555-506 TRACK-TERMINAL BLOCK	287A4130 81205	1	21-25-11 J046-00/ /	YC004-YM670
TB0660Y		S280W555-104 TERMINAL BLOCK	287A4130 81205	4	21-25-11 J046-00/ /	YC004-YM670
TB0660Z		S280W555-108 TERMINAL BLOCK	287A4130 81205	1	21-25-11 J046-00/ /	YC004-YM670
TB0662		S280W555-506 TRACK-TERMINAL BLOCK	287A4130 81205	1	21-25-11 J046-00/ /	YC004-YM670
TB0662Y		S280W555-104 TERMINAL BLOCK-	287A4130 81205	3	21-25-11 J046-00/ /	YC004-YM670
TB0664		S280W555-506 TRACK-TERMINAL BLOCK	287A4130 81205	1	21-25-11 J046-00/ /	YC004-YM670
TB0664Y		S280W555-104 TERMINAL BLOCK-	287A4130 81205	3	21-25-11 J046-00/ /	YC004-YM670
TB0664Z		S280W555-108 TERMINAL BLOCK	287A4130 81205	1	21-25-11 J046-00/ /	YC004-YM670
TB0666		S280W555-506 TRACK-TERMINAL BLOCK	287A4130 81205	1	21-25-11 J046-00/ /	YC004-YM670
TB0666Y		S280W555-104 TERMINAL BLOCK-	287A4130 81205	1	21-25-11 J046-00/ /	YC004-YM670

EQUIPMENT LIST

D280A103

Section TB0600

Page 2 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0800		S280W555-606 TRACK-TERMINAL BLOCK	254A1221 81205	1	33-11-41 P010-00/ /	ALL
TB0800Z		S280W555-108 TERMINAL BLOCK-	254A1221 81205	1	33-11-41 P08-00/ /	ALL
TB0801		S280W555-506 TRACK-TERMINAL BLOCK	287A4122 81205	1	33-11-33 231/208/0	ALL
TB0801V		S280W555-203 TERMINAL BLOCK-	287A4122 81205	1	33-11-33 P008-00/ /	ALL
TB0801W		S280W555-206 TERMINAL BLOCK-	287A4122 81205	3	33-11-33 P008-00/ /	ALL
TB0801X		S280W555-102 TERMINAL BLOCK-	287A4122 81205	1	33-11-33 P008-00/ /	ALL
TB0801Y		S280W555-104 TERMINAL BLOCK-	287A4122 81205	1	33-11-33 P008-00/ /	ALL
TB0803		S280W555-606 TRACK-TERMINAL BLOCK	141A5170 81205	1	22-11-12 229/209/0	ALL
TB0803X		S280W555-102 TERMINAL BLOCK-	141A5170 81205	1	22-11-12 P008-00/ /	ALL
TB0803Y		S280W555-104 TERMINAL BLOCK-	141A5170 81205	2	22-11-12 P008-00/ /	ALL
TB0803Z		S280W555-108 TERMINAL BLOCK-	141A5170 81205	1	33-18-61 P008-00/ /	ALL
TB0804		S280W555-606 TRACK-TERMINAL BLOCK	141A5170 81205	1	21-33-11 227/209/0	ALL
TB0804X		S280W555-102 TERMINAL BLOCK-	141A5170 81205	2	33-11-31 P008-00/ /	ALL
TB0804Y		S280W555-104 TERMINAL BLOCK-	141A5170 81205	1	21-33-11 P008-00/ /	ALL
TB0804Z		S280W555-108 TERMINAL BLOCK-	141A5170 81205	3	33-11-41 P008-00/ /	ALL
TB0805		S280W555-606 TRACK-TERMINAL BLOCK	141A5170 81205	1	22-11-12 227/205/R015	ALL
TB0805V		S280W555-203 TERMINAL BLOCK	141A5170 81205	1	33-11-11 227/205/R015	ALL

EQUIPMENT LIST

D280A103

Section TB0800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0805X		S280W555-102 TERMINAL BLOCK	141A5170 81205	2	22-11-12 227/205/R015	ALL
TB0805Y		S280W555-104 TERMINAL BLOCK	141A5170 81205	1	22-11-12 227/205/R015	ALL
TB0806		S280W555-606 TRACK-TERMINAL BLOCK	141A5170 81205	1	22-11-12 221/204/L004	ALL
TB0806V		S280W555-203 TERMINAL BLOCK	141A5170 81205	1	33-11-11 221/204/L004	ALL
TB0806X		S280W555-102 TERMINAL BLOCK	141A5170 81205	2	22-11-12 221/204/L004	ALL
TB0806Y		S280W555-104 TERMINAL BLOCK	141A5170 81205	1	22-11-12 221/204/L004	ALL
TB0806Z		S280W555-108 TERMINAL BLOCK	141A5170 81205	2	33-18-61 221/204/L004	ALL
TB0811	1	S280W555-522 TRACK-TERMINAL BLOCK 22 MODULES	284A2780 81205	1	23-11-11 E008-01/ /	YC001-YC006
TB0811	1	S280W555-516 TRACK-TERMINAL BLOCK 16 MODULES	284A2780 81205	1	23-11-11 E008-01/ /	YC007-YC030, YK901-YK912, YK918, YL401- YL426, YM643- YM652
TB0811W		S280W555-206 TERMINAL BLOCK	284A2710 81205	1	23-34-01 E008-01/ /	YC001-YC050
TB0811Y		S280W555-104 TERMINAL BLOCK-	284A0781 81205	2	23-34-01 E008-01/ /	YC001-YC050
TB0811Z		S280W555-108 TERMINAL BLOCK	284A2710 81205	1	23-34-01 E008-01/ /	YC001-YC050
TB0812	1	S280W555-510 TRACK-TERMINAL BLOCK 10 MODULES	284A2780 81205	1	23-11-11 E008-01/ /	YC001-YC006
TB0812	1	S280W555-516 TRACK-TERMINAL BLOCK 16 MODULES	284A2780 81205	1	23-11-11 E008-01/ /	YC007-YC030, YK901-YK912, YK918, YL401- YL426, YM643- YM652

EQUIPMENT LIST

D280A103

Section TB0800

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0812Y		S280W555-104 TERMINAL BLOCK-	284A0781 81205	1	23-11-11 E008-01/ /	YC001-YC050, YK907-YL430
TB0812Z		280W555-108 TERMINAL BLOCK	S84A2710 81205	1	23-11-11 E008-01/ /	YK901-YM670

EQUIPMENT LIST

D280A103

Section TB0800
Page 3 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1092		S280W555-606 TRACK-TERMINAL BLOCK	288A4151 81205	1	33-11-11 P001-00/ /	ALL
TB1092V		S280W555-203 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P001-00/ /	ALL
TB1092W		S280W555-206 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P001-00/ /	ALL
TB1092X		S280W555-102 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P001-00/ /	ALL
TB1092Y		S280W555-104 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P001-00/ /	ALL
TB1092Z		S280W555-108 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P001-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB1000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1101	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1101X		S280W555-102 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1101Y		S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1101Z		S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1102	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-45-21 E001-01/ /	ALL
TB1102X		S280W555-102 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1102Y	9	S280W555-104 TERMINAL BLOCK - (SB 27-1253)	284A2710 81205	1	22-11-11 E001-01/ /	YC001-YC030
TB1102Y		S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1102Z		S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1103	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-49-11 E001-01/ /	ALL
TB1103X		S280W555-102 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1103Y		S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1103Z		S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1104	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1104X		S280W555-102 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1104Y		S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1104Z		S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL

EQUIPMENT LIST

D280A103

Section TB1100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1105	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1105W	1	S280W555-206 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1105X		S280W555-102 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1105Y		S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1105Z		S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1106	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1106X		S280W555-102 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1106Y		S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1106Z		S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1107	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1107X		S280W555-102 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1107Y		S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1107Z		S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1108	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1108Y	1	S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1108Z	1	S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1109	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-01/ /	ALL

EQUIPMENT LIST

D280A103

Section TB1100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1109Y	1	S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1109Z	1	S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1110	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1110Y	1	S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1110Z	1	S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	22-11-11 E001-01/ /	ALL
TB1111	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	21-31-24 E001-01/ /	YC031-YM670
TB1111Y	1	S280W555-104 TERMINAL BLOCK -	284A2710 81205	1	21-31-24 E001-01/ /	YC031-YM670
TB1111Z	1	S280W555-108 TERMINAL BLOCK -	284A2710 81205	1	21-31-24 E001-01/ /	YC031-YM670

EQUIPMENT LIST

D280A103

Section TB1100
Page 3 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1201Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	34-31-11 E001-02/ /	ALL
TB1201Z	1	S280W555-108 TERMINAL BLOCK	284A2710 81205	1	34-31-11 E001-02/ /	ALL
TB1202	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-53-11 E001-02/ /	ALL
TB1202Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	34-53-11 E001-02/ /	ALL
TB1203	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-53-11 E001-02/ /	ALL
TB1204	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-55-11 E001-02/ /	ALL
TB1204Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	34-55-11 E001-02/ /	ALL

EQUIPMENT LIST

D280A103

Section TB1200
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1301	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	23-12-11 E001-03/ /	ALL
TB1301W	1	S280W555-206 TERMINAL BLOCK	284A2710 81205	1	23-12-11 E001-03/ /	ALL
TB1301Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	23-12-11 E001-03/ /	ALL
TB1301Z	1	S280W555-108 TERMINAL BLOCK	284A2710 81205	1	23-12-11 E001-03/ /	ALL
TB1302	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	23-31-01 E001-03/ /	ALL
TB1302Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	23-31-02 E001-03/ /	ALL
TB1302Z	1	S280W555-108 TERMINAL BLOCK	284A2710 81205	1	23-31-02 E001-03/ /	ALL
TB1303	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	23-41-11 E001-03/ /	ALL
TB1303Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	3	23-41-01 E001-03/ /	ALL
TB1304		S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	2	23-34-01 E001-03/ /	ALL
TB1304Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	23-31-06 E001-03/ /	YC001-YC050
TB1304Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	23-34-01 E001-03/ /	YK901-YM670
TB1304Z	1	S280W555-108 TERMINAL BLOCK	284A2710 81205	1	23-31-06 E001-03/ /	YC001-YL430
TB1304Z	1	S280W555-108 TERMINAL BLOCK	284A2710 81205	1	23-34-01 E001-03/ /	YM643-YM670

EQUIPMENT LIST

D280A103

Section TB1300
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1401	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-31-21 E001-04/ /	ALL
TB1401Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-04/ /	ALL
TB1402	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-31-21 E001-04/ /	ALL
TB1402Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	22-11-12 E001-04/ /	ALL
TB1402Z	1	S280W555-108 TERMINAL BLOCK	284A2710 81205	1	22-11-11 E001-04/ /	ALL
TB1403	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-31-21 E001-04/ /	ALL
TB1403Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	34-31-21 E001-04/ /	ALL
TB1403Z	1	S280W555-108 TERMINAL BLOCK	284A2710 81205	1	34-31-21 E001-04/ /	ALL
TB1404	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-31-21 E001-04/ /	ALL
TB1404Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	26-11-21 E001-04/ /	ALL

EQUIPMENT LIST

D280A103

Section TB1400
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1501	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-55-21 E001-05/ /	ALL
TB1501Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	34-55-21 E001-05/ /	ALL
TB1502	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-53-11 E001-05/ /	ALL
TB1503	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-53-11 E001-05/ /	ALL
TB1504	1	S280W601-301 TRACK - TERMINAL BLOCK	284A2710 81205	1	34-21-24 E001-05/ /	ALL
TB1504W	1	S280W555-206 TERMINAL BLOCK	284A2710 81205	1	23-12-21 E001-05/ /	ALL
TB1504Y	1	S280W555-104 TERMINAL BLOCK	284A2710 81205	1	34-53-21 E001-05/ /	ALL

EQUIPMENT LIST

D280A103

Section TB1500
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1802		S280W555-510 TRACK-TERMINAL BLOCK	233A5501 81205	1	21-27-21 261/171/L022	YC001-YC003
TB1802X		S280W555-102 TERMINAL BLOCK-	233A5501 81205	5	21-27-31 261/179/L022	YC001-YC003
TB1802Y		S280W555-104 TERMINAL BLOCK-	233A5501 81205	2	21-27-21 262/176/L022	YC001-YC003
TB1804		S280W555-510 TRACK-TERMINAL BLOCK	233A5501 81205	1	21-27-31 262/171/L028	YC001-YC003
TB1804V		S280W555-203 TERMINAL BLOCK-	233A5501 81205	1	73-32-51 262/176/L027	YC001-YC003
TB1804X		S280W555-102 TERMINAL BLOCK-	233A5501 81205	3	21-27-31 262/176/L027	YC001-YC003
TB1804Y		S280W555-104 TERMINAL BLOCK-	233A5501 81205	2	26-21-11 261/174/L027	YC001-YC003
TB1806		S280W555-504 TRACK-TERMINAL BLOCK	288A4131 81205	1	21-25-11 261/173/L25	YC004-YM670
TB1806V		S280W555-203 TERMINAL BLOCK-	288A4131 81205	1	21-25-11 261/173/L025	YC004-YM670
TB1806X		S280W555-102 TERMINAL BLOCK	288A4131 81205	1	21-25-11 261/173/L025	YC004-YM670
TB1806Y		S280W555-104 TERMINAL BLOCK-	288A4131 81205	2	21-27-21 261/173/L025	YC001-YC002, YC004-YM670
TB1808		S280W555-504 TRACK-TERMINAL BLOCK	288A4131 81205	1	21-25-11 261/171/L025	YC004-YM670
TB1808V		S280W555-203 TERMINAL BLOCK-	288A4131 81205	1	21-25-11 261/171/L025	YC004-YM670
TB1808X		S280W555-102 TERMINAL BLOCK	288A4131 81205	1	21-25-11 261/171/L025	ALL
TB1808Y		S280W555-104 TERMINAL BLOCK-	233A4131 81205	1	31-31-11 261/171/L025	YC004-YM670
TB1882		S280W555-510 TRACK-TERMINAL BLOCK	287A4143 81205	1	21-25-11 J048-00/ /	YC004-YM670
TB1882Y		S280W555-104 TERMINAL BLOCK	287A4143 81205	5	21-25-11 J048-00/ /	YC004-YM670

EQUIPMENT LIST

D280A103

Section TB1800

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB1884		S208W555-510 TRACK-TERMINAL BLOCK	287A4140 81205	1	21-25-11 J048-00/ /	YC004-YM670
TB1884Y		S280W555-104 TERMINAL BLOCK	287A4140 81205	1	21-25-11 J048-00/ /	YC004-YM670

EQUIPMENT LIST

D280A103

Section TB1800
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB2101		S280W555-516 TRACK-TERMINAL BLOCK	284A0221 81205	1	23-71-01 E002-01/ /	ALL
TB2101X		S280W555-102 TERMINAL BLOCK-	28000000 81205	1	23-71-01 E002-01/ /	ALL
TB2101Y		S280W555-104 TERMINAL BLOCK-	28000000 81205	1	24-28-11 E002-01/ /	ALL

EQUIPMENT LIST

D280A103

Section TB2100
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB2201		S280W555-526 TRACK-TERMINAL BLOCK	287A0722 81205	1	26-11-31 E002-02/ /	ALL
TB2201Y		S280W555-104 TERMINAL BLOCK-	28000000 81205	1	24-31-11 E002-02/ /	ALL
TB2202		MS27212-2-3 TERMINAL STRIP-E2-2, APU GEN.	287A4352 81205	1	24-21-31 396/180/L40	YC005-YM670

EQUIPMENT LIST

D280A103

Section TB2200
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB3092		S280W555-606 TRACK-TERMINAL BLOCK	288A4151 81205	1	33-11-21 P003-00/ /	ALL
TB3092V		S280W555-203 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P003-00/ /	ALL
TB3092W		S280W555-206 TERMINAL BLOCK	288A4151 81205	1	33-11-21 P003-00/ /	ALL
TB3092X		S280W555-102 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P003-00/ /	ALL
TB3092Y		S280W555-104 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P003-00/ /	ALL
TB3092Z		S280W555-108 TERMINAL BLOCK	288A4151 81205	1	33-11-11 P003-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB3000

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB3101	1	S280W555-526 TRACK-TERMINAL BLOCK	284A2730 81205	1	31-62-15 E003-01/ /	ALL
TB3101Y	1	S280W555-104 TERMINAL BLOCK	284A2730 81205	1	31-62-15 E003-01/ /	ALL
TB3101Z	1	S280W555-108 TERMINAL BLOCK	284A2730 81205	1	31-62-15 E003-01/ /	ALL
TB3102	1	S280W555-526 TRACK-TERMINAL BLOCK	284A2730 81205	1	31-62-14 E003-01/ /	ALL
TB3102Y	1	S280W555-104 TERMINAL BLOCK	284A2730 81205	1	31-62-14 E003-01/ /	ALL
TB3102Z	1	S280W555-108 TERMINAL BLOCK	284A2730 81205	1	31-62-14 E003-01/ /	ALL

EQUIPMENT LIST

D280A103

Section TB3100
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB3201		S280W555-522 TRACK-TERM BLOCK	286A0321 81205	1	31-31-14 E003-2/ /	ALL
TB3201X		S280W555-102 MDL-TERMINAL BLOCK	284A1732 81205	1	27-32-11 E003-02/ /	ALL
TB3201Y		S280W555-104 MDL-TERMINAL BLOCK	284A1732 81205	1	31-31-11 E003-02/ /	ALL
TB3201Z		S280W555-108 MDL-TERMINAL BLOCK	284W1732 81205	1	31-31-11 E003-02/ /	ALL

EQUIPMENT LIST

D280A103

Section TB3200
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB3301		S280W555-514 TRACK-TERM BLOCK	284A0730 81205	1	23-27-11 E003-03/ /	YC001-YL430
TB3301V		S280W555-203 TERMINAL BLOCK -	284A0730 81205	1	23-12-31 E003-03/ /	YC001-YC050
TB3301Y		S280W555-104 TERMINAL BLOCK -	284A0730 81205	1	21-61-11 E003-03/ /	YC001-YL430
TB3301Y		S280W555-104 TERMINAL BLOCK -	284A0730 81205	1	23-12-31 E003-03/ /	YM643-YM670
TB3301Z		S280W555-108 TERMINAL BLOCK -	284A0730 81205	1	23-27-11 E003-03/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section TB3300
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB3901Y	1	S280W555-104 TERMINAL BLOCK	284A0082	0	27-62-11 AJ0039/ /	YK907-YL430
TB3901Z		S280W555-108 MDL-TERMINAL BLOCK	284A0082	0	27-62-11 AJ0039/ /	YK907-YL430

EQUIPMENT LIST

D280A103

Section TB3900
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB4101		S280W555-522 TRACK-TERMINAL BLOCK 22 MODULES	284A2740 81205	1	21-25-11 E004-01/ /	ALL
TB4101X		S280W555-102 TERMINAL BLOCK-	284A2740 81205	4	21-25-11 E004-01/ /	ALL
TB4101Y		S280W555-104 TERMINAL BLOCK-	284A2740 81205	6	21-25-11 E004-01/ /	ALL
TB4101Z	1	S280W555-108 TERMINAL BLOCK	284A2740 81205	2	21-25-11 E004-01/ /	ALL
TB4102		S280W555-606 TRACK-TERMINAL BLOCK 6 MODULES	287A4358 81205	1	21-25-11 E004-01/ /	YC001-YL430
TB4102Y		S280W555-104 TERMINAL BLOCK-	284A2740 81205	6	21-25-11 E004-01/ /	YC001-YL430

EQUIPMENT LIST

D280A103

Section TB4100
Page 1 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB4201		S280W555-506 TRACK-TERMINAL BLOCK	284A0440 81205	1	24-41-11 E004-02/ /	ALL
TB4201X	1	S280W555-102 TERMINAL BLOCK	284A0440 81205	1	23-34-02 E004-02/ /	ALL
TB4201Y	1	S280W555-104 TERMINAL BLOCK	284A0440 81205	1	24-23-51 E004-02/ /	ALL

EQUIPMENT LIST

D280A103

Section TB4200
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB4601		280W555-602 TRACK - TERMINAL BLOCK	144A7714	0	47-30-11 721/204/R035	YC031-YC050, YK906-YM670
TB4601Y		S280W555-104 TERMINAL BLOCK	284ATBD	0	47-30-11 721/204/R035	YC031-YC050, YK906-YM670

EQUIPMENT LIST

D280A103

Section TB4600
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5001		1032176-1 TERMINAL STRIP-PDP 1 GEN 1	284A0206 07217	3	24-51-11 393P91/169/L032	ALL
TB5002		1032176-1 TERMINAL STRIP-PDP 1,APU GEN	284A0206 07217	3	24-51-11 P091 392/172/L040	ALL
TB5004		1032177-1 TERMINAL STRIP-PDP 1,BUS TIE	284A0206 07217	3	24-51-11 393 P091/168/L024	ALL
TB5005		1032176-1 TERMINAL STRIP-PDP 1 GEN 2	284A0206 07217	3	24-51-21 P092 393/170/R028	ALL
TB5006		1032176-1 TERMINAL STRIP-PDP 2,EXT PWR	284A0206 07217	3	24-51-21 393/172/R036	ALL
TB5008		1032177-1 TERMINAL STRIP-PDP 2,BUS TIE	284A0206 07217	3	24-51-21 393/167/R21	ALL
TB5009		MS27212-2-1 TERMINAL STRIP-	233A5601 96906	1	33-17-11 255/261/L031	ALL
TB5010		MS27212-2-6 TERMINAL STRIP-LEFT FRONT WINDOW	284A2720 96906	1	30-41-11 E002-01/ /	ALL
TB5012		MS27212-2-6 TERMINAL STRIP	284A2740 96906	1	30-41-12 E004-02/ /	ALL
TB5014		MS27212-2-6 TERMINAL STRIP-RIGHT SIDE WINDOW	284A2720 96906	1	30-41-11 E002-01/ /	ALL
TB5016		MS27212-2-6 TERMINAL STRIP	284A2740 96906	1	30-41-12 E004-02/ /	ALL
TB5018		MS27212-2-1 TERMINAL STRIP-CAPT FLT KIT LT	141A7410 96906	1	33-17-11 226/230/L040	ALL
TB5018 T		MS25171-1S NIPPLE	96906	1	33-17-11 226/230/L040	YC001-YC026
TB5018 T		MS25171-1S NIPPLE	96906	1	33-17-11 */*/*	YC028-YM670
TB5020		MS27212-2-1 TERMINAL STRIP-F/O FLT LT	141A7410 96906	1	33-17-11 226/230/R040	ALL
TB5020 T		MS25171-1S NIPPLE	96906	1	33-17-11 226/230/R040	ALL
TB5060		SEEOTHERPARTS TERMINAL STRIP-PR	65CXXXP6	1	24-51-11 P006-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB5000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5060A		MS27212-2-12 TERMINAL STRIP-PR	65CXXXP6	0	24-61-11 P006-00/ /	ALL
TB5060B		MS27212-2-10 TERMINAL STRIP-P6	233A5201 81205	1	33-12-11 P006-00/ /	ALL
TB5060C		MS27212-2-10 TERMINAL STRIP-P6	233A5201 81205	1	24-51-11 P006-00/ /	ALL
TB5060D		MS27212-2-14 TERMINAL STRIP-P6	233A5201 81205	1	24-51-11 P006-00/ /	ALL
TB5060E		MS27212-2-11 TERMINAL STRIP-P6	233A5201 81205	1	24-51-11 P006-00/ /	ALL
TB5060F		MS27212-2-12 TERMINAL STRIP-P6	233A5201 81205	1	24-51-11 P006-00/ /	ALL
TB5060G		MS27212-2-8 TERMINAL STRIP-P6	233A5201 81205	1	24-51-11 P006-00/ /	ALL
TB5060H		MS27212-2-8 TERMINAL STRIP-P6	233A5201 81205	1	24-51-11 P006-00/ /	ALL
TB5060I		MS27212-2-1 TERMINAL STRIP-PR	233A5201 81205	1	33-12-11 P006-00/ /	ALL
TB5060IT		MS25171-4S NIPPLE	96906	1	24-31-12 P006-00/ /	YC001-YC009
TB5060J		MS27212-2-1 TERMINAL STRIP-P6	233A5220 81205	1	24-31-12 P006-00/ /	ALL
TB5060JT	1	BACN18H5 NIPPLE	81205	1	33-17-11 P006-00/ /	YC001-YC009
TB5060JT	2	MS25171-1S NIPPLE	96906	1	33-17-11 P006-00/ /	YC001-YC009
TB5060K	9	MS27212-2-12 TERMINAL STRIP-P6	233A5220 81205	1	24-51-11 P006-00/ /	YC001-YC030
TB5060K		MS27212-2-12 TERMINAL STRIP-P6	233A5220 81205	1	24-51-11 P006-00/ /	YC031-YM670

EQUIPMENT LIST

D280A103

Section TB5000
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5180		SEEOTHERPARTS TERMINAL STRIP-P18	65CXXXP18	0	24-51-11 260/243/L031	ALL
TB5180A		MS27212-2-1 TERMINAL STRIP-P18	233A5501 81205	1	33-17-11 P018-00/ /	ALL
TB5180B		MS27212-2-12 TERMINAL STRIP-P18	233A5501 81205	1	24-51-11 P018-00/ /	ALL
TB5180C		MS27212-2-9 TERMINAL STRIP-P18	233A5501 81205	1	24-51-11 P018-00/ /	ALL
TB5180D		MS27212-2-10 TERMINAL STRIP-P18	233A5501 81205	1	24-51-11 P018-00/ /	ALL
TB5180E		MS27212-2-10 TERMINAL STRIP-P18	233A5501 81205	1	24-51-11 P018-00/ /	ALL
TB5180F		MS27212-2-4 TERMINAL STRIP-P18	233A5501 81205	1	24-54-11 P018-00/ /	YC031-YM670
TB5180G		MS27212-2-14 TERMINAL STRIP-P18	288A4155	1	24-51-11 P018-00/ /	ALL

EQUIPMENT LIST

D280A103

Section TB5100

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5210		MS27212-2-14 TERMINAL STRIP-P18	65CXXXE21	1	24-51-11 E002-01/ /	ALL
TB5220		SEEOTHERPARTS TERMINAL STRIP-PR	65CXXXP6	1	24-34-11 E002-02/ /	ALL

EQUIPMENT LIST

D280A103

Section TB5200
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5301		MS27212-2-14 TERMINAL STRIP-PR	65CXXE3	1	24-31-12 E003-03/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section TB5300
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5420		MS27212-3-2 TERMINAL STRIP-E4-2	284A1844	1	24-32-11 387/181/R048	ALL

EQUIPMENT LIST

D280A103

Section TB5400
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5801		S280W555-510 TRACK-TERMINAL BLOCK	65CXXE21 81205	1	24-31-11 374/188/L060	YC001-YL430
TB5801X		S280W555-102 TERMINAL BLOCK-	286A2508 81205	1	24-31-11 374/188/L060	ALL

EQUIPMENT LIST

D280A103

Section TB5800
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB8101		S280W555-522 TRACK-TERMINAL BLOCK 22 MODULES	284A0781 81205	1	23-11-11 E008-01/ /	YC001-YC050
TB8102Y		S280W555-104 TERMINAL BLOCK-	284A0781 81205	2	23-11-11 E008-01/ /	YC001-YC050

EQUIPMENT LIST

D280A103

Section TB8100
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB9001	9	CUSTOMER TRACK-TERMINAL BLOCK (230116)	CUSTOMER CUST	1	23-70-11 E004-01/ /	YC001-YC030
TB9001Z	9	CUSTOMER TERMINAL BLOCK- (230116)	CUSTOMER CUST	1	23-70-11 E004-01/ /	YC001-YC030

EQUIPMENT LIST

D280A103

Section TB9000
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00004		S332A239-2 VLV-ENGINE COWL THERMAL ANTI-ICE	332A2300 59364	2	30-21-11 517/188/168	ALL
V00006		VENDORSUPPLIEDSEEIPCFORP-NINFO VLV-ENGINE START	232A2300 OHWN8	2	80-11-11 ENG/ /	ALL
V00007		10-61093-201 VLV-LEFT INBOARD ANTISKID	65-44530 81205	1	32-41-11 727/190/L045	ALL
V00008		10-61093-201 VLV-RIGHT INBOARD ANTISKID	65-44530 81205	1	32-41-11 727/180/R040	ALL
V00009		10-61093-201 VLV-LEFT OUTBOARD ANTISKID	65-44530 81205	1	32-41-11 727/190/L045	ALL
V00010		10-61093-201 VLV-RIGHT OUTBOARD ANTISKID	65-44530 81205	1	32-41-11 727/180/R040	ALL
V00011	1	S270T010-11 VLV-PARKING BRAKE	274A1410 91816	1	32-44-11 727/202/L010	YC001-YC022
V00011	1	S270T010-14 VLV-PARKING BRAKE	274A1410 91816	1	32-44-11 727/202/L010	YC023-YM670
V00011	2	S271N501-3 VLV-PARKING BRAKE	274A1410 79318	1	32-44-11 727/202/L010	ALL
V00011	3	S271N501-2 VLV-PARKING BRAKE	274A1410 79318	1	32-44-11 727/202/L010	ALL
V00011	4	S270T010-8 VLV-PARKING BRAKE	274A1410 91816	1	32-44-11 727/202/L010	YC001-YC011
V00016		2760000-101 BLEED AIR ISOLATION VALVE	212A1110 92003	1	36-11-11 540/166/R001	ALL
V00018		396608-1 VLV-LEFT PACK FLOW CONTROL AND SHUTOFF	213A1002 70210	1	21-51-11 581/158/L009	YC001-YL430
V00018		396498-2 VLV-LEFT PACK FLOW CONTROL AND SHUTOFF	213A1002 70210	1	21-51-11 516/156/R013	YM643-YM670
V00019		396608-1 VLV-RIGHT PACK FLOW CONTROL AND SHUTOFF	213A1002 70210	1	21-51-21 581/158/R015	YC001-YL430
V00019		396498-2 VLV-RIGHT PACK FLOW CONTROL AND SHUTOFF	213A1002 70210	1	21-51-21 576/156/R013	YM643-YM670
V00022		398116-1-1 VLV-PASSENGER CABIN MIX	213A1002 70210	1	21-61-22 652/148/R013	YM643-YM670

EQUIPMENT LIST

D280A103

Section V00000

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00023		398116-1-1 VLV-CONTROL CABIN MIX	213A1002 70210	1	21-61-21 652/148/R013	YM643-YM670
V00027		321942-1-1 VLV-LEFT 35 DEG F CONTROL	213A1002 70210	1	21-51-16 569/163/L024	YM643-YM670
V00028		321942-1-1 VLV-RIGHT 35 DEG F CONTROL	213A1002 70210	1	21-51-26 570/163/R024	YM643-YM670
V00029		10-60495-7 VLV-LEFT WING ANTI-ICE	218A1660 81205	1	30-11-11 611/205/L208	ALL
V00030		10-60495-7 VLV-RIGHT WING ANTI-ICE	218A1660 81205	1	30-11-11 611/205/R208	ALL
V00031		10-60581-3 VLV-SYSTEM B SPOILER SHUTOFF	65-44890 81205	1	27-61-11 665/180/R050	ALL
V00032		10-60581-3 VLV-SYSTEM A SPOILER SHUTOFF	65-44890 81205	1	27-61-11 665/180/L057	ALL
V00033		10-3200-6-SEE270T2001SPAREINTCHG- VLV-ENGINE 1 HYDRAULIC FLUID SHUTOFF	271A7445 81205	1	29-11-11 673/190/L064	YC001-YC007
V00033		S270T010-9-SEE270T2001SPAREINTCHG- VLV-ENGINE 1 HYDRAULIC FLUID SHUTOFF	271A7445 81205	1	29-11-11 673/190/L064	YC008-YC011
V00033		S270T010-12-SEE270T2001SPAREINTCHG- VLV-ENGINE 1 HYDRAULIC FLUID SHUTOFF	271A7445 81205	1	29-11-11 673/190/L064	YC012-YC022
V00033		S270T010-15-SEE270T2001SPAREINTCHG- VLV-ENGINE 1 HYDRAULIC FLUID SHUTOFF	271A7445 81205	1	29-11-11 673/190/L064	YC023-YM670
V00034		10-3200-6-SEE270T2001SPAREINTCHG- VLV-ENGINE 2 HYDRAULIC FLUID SHUTOFF	271A7446 81205	1	29-11-11 680/190/R064	YC001-YC007
V00034		S270T010-9-SEE270T2001SPAREINTCHG- VLV-ENGINE 2 HYDRAULIC FLUID SHUTOFF	271A7446 81205	1	29-11-11 680/190/R064	YC008-YC011
V00034		S270T010-12-SEE270T2001SPAREINTCHG- VLV-ENGINE 2 HYDRAULIC FLUID SHUTOFF	271A7446 81205	1	29-11-11 680/190/R064	YC012-YC022
V00034		S270T010-15-SEE270T2001SPAREINTCHG- VLV-ENGINE 2 HYDRAULIC FLUID SHUTOFF	271A7446 81205	1	29-11-11 680/190/R064	YC023-YM670
V00035		10-62167-3 VLV-PUMP DEPRESSURIZATION	332A1012 81205	2	29-11-11 ENG/ /	ALL
V00037		S343T003-39 ACTR-FUEL SPAR VALVE ENGINE 1	343A3111 81205	1	28-21-11 260/FSS/L	YC001-YC030

EQUIPMENT LIST

D280A103

Section V00000

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00037		S343T003-39 ACTR-FUEL SPAR VALVE ENGINE 1	343A3111 73760	1	28-21-11 260/FSS/L	YC031-YK901
V00037		MA20A2027 ACTR-FUEL SPAR VALVE ENGINE 1	343A3111 73760	1	28-21-11 260/FSS/L	YK902-YK906
V00037		S343T003-66 ACTR-FUEL SPAR VALVE ENGINE 1	343A3111 73760	1	28-21-11 260/FSS/L	YK907-YM670
V00038		S343T003-39 ACTR-FUEL SPAR VALVE ENGINE 2	343A3111 81205	1	28-21-11 W156/LE/R	YC001-YC030
V00038		S343T003-39 ACTR-FUEL SPAR VALVE ENGINE 2	343A3111 73760	1	28-21-11 W156/LE/R	YC031-YK901
V00038		MA20A2027 ACTR-FUEL SPAR VALVE ENGINE 2	343A3111 73760	1	28-21-11 W156/LE/R	YK902-YK906
V00038		S343T003-66 ACTR-FUEL SPAR VALVE ENGINE 2	343A3111 73760	1	28-21-11 W156/LE/R	YK907-YM670
V00039		S343T003-39 ACTR-FUEL CROSSFEED VALVE	343A3101 81205	1	28-22-11 77/FSS/L	YC001-YC030
V00039		S343T003-39 ACTR-FUEL CROSSFEED VALVE	343A3101 73760	1	28-22-11 77/FSS/L	YC031-YK901
V00039		MA20A2027 ACTR-FUEL CROSSFEED VALVE	343A3101 73760	1	28-22-11 77/FSS/L	YK902-YK906
V00039		S343T003-66 ACTR-FUEL CROSSFEED VALVE	343A3101 73760	1	28-22-11 77/FSS/L	YK907-YM670
V00040		10-60581-3 VLV-SYSTEM A SHUTOFF	65-44890 81205	1	27-23-11 665/180/L050	ALL
V00041		10-60581-3 VLV-SYSTEM B SHUTOFF	65-44890 81205	1	27-23-11 665/180/R057	ALL
V00042		10-60581-3 VLV-STANDBY RUDDER SHUTOFF	65-44680 81205	1	27-23-11 725/169/L014	ALL
V00043		AV16E1209D VALVE- APU FUEL SHUTOFF	346A3101 73760	1	49-62-11 663/ /L043	ALL
V00044		2670136R VLV-TANK 1 FUELING	65-46512 92003	1	28-44-11 124/ /	ALL
V00045		2670136R VLV-TANK 2 FUELING	344A3111 92003	1	28-44-11 135/ /	ALL

EQUIPMENT LIST

D280A103

Section V00000

Page 3

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00046		2670136R VLV-CENTER TANK FUELING	65-46512 92003	1	28-44-11 127/ /	ALL
V00048		10-62231-3 VLV-CABIN PRESSURE OUTFLOW	216A4001 81205	1	21-31-11 980/185/R026	YC001-YC030
V00048		10-62231-43 VLV-CABIN PRESSURE OUTFLOW	216A4001 81205	1	21-31-11 980/185/R026	YC031-YM670
V00051		10-60581-3 VLV-LEADING EDGE FLAP STANDBY DR SHUTOFF	65-44681 81205	1	27-53-11 722/169/L007	ALL
V00052		10-60710-6 VLV-TRAILING EDGE FLAPS BYPASS	65-44640 81205	1	27-53-11 723/200/R021	ALL
V00094	1	10-60811-13 VLV-FLAP LOAD RELIEF	65-44631 81205	1	27-54-11 720/198/R056	ALL
V00094	2	10-60811-8 VLV-FLAP LOAD RELIEF	65-44631 81205	1	27-54-11 720/198/R056	ALL

EQUIPMENT LIST

D280A103

Section V00000
Page 4 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00122		S274T401-6 VLV-AUTOBRAKE MODULE	274A1610 81205	1	32-42-11 711/200/	ALL
V00122 T		10-60552-8 SW-SERVO/SOLENOID-PART OF V00122	60B00263 81205	2	32-42-11 711/200/	ALL
V00123		10-62039-4 VLV-LANDING GEAR SYSTEM TRANSFER	65C25703 81205	1	29-23-11 674/159/L001	ALL
V00124		10-61093-201 VLV-RIGHT ALTERNATE ANTISKID	65C26814 81205	1	32-41-11 665/190/R070	ALL
V00125		10-61093-201 VLV-LEFT ALTERNATE ANTISKID	65C26814 81205	1	32-41-11 663/200/L070	ALL
V00132		65C26869-2 VLV-AUTOSLAT	65C26870 81205	1	27-83-11 643/162/R049	ALL
V00133		S271N501-3-SEE270T2001SPAREINTCHG- VLV-POWER TRANSFER UNIT CONTROL	65C26882 81205	1	29-25-11 666/150/L017	YC001-YC007
V00133		S270T010-8-SEE270T2001SPAREINTCHG- VLV-POWER TRANSFER UNIT CONTROL	65C26882 81205	1	29-25-11 666/150/L017	YC008-YC011
V00133		S270T010-11-SEE270T2001SPAREINTCHG- VLV-POWER TRANSFER UNIT CONTROL	271A7441 81205	1	29-25-11 666/150/L017	YC012-YC022
V00133		S270T010-14-SEE270T2001SPAREINTCHG- VLV-POWER TRANSFER UNIT CONTROL	271A7441 81205	1	29-25-11 666/150/L017	YC023-YM670
V00139		10-62091-13 VLV-LEFT TEMPERATURE CONTROL	213A1002 81205	1	21-51-12 655/147/L009	YC001-YL430
V00140		10-62091-16 VLV-LEFT STANDBY TEMPERATURE CONTROL	213A1002 81205	1	21-51-13 653/154/L028	YC001-YL430
V00141		10-62091-13 VLV-RIGHT TEMPERATURE CONTROL	213A1002 81205	1	21-51-22 656/145/R010	YC001-YL430
V00142		10-62091-16 VLV-RIGHT STANDBY TEMPERATURE CONTROL	213A1002 81205	1	21-51-23 653/151/R035	YC001-YL430
V00143		10-62091-13 VLV-CONTROL CABIN TRIM MODULATING	213A1005 81205	1	21-61-11 542/157/L012	YC001-YL430
V00144		10-62091-13 VLV-FORWARD CABIN TRIM MODULATING	213A1005 81205	1	21-61-13 540/152/R012	YC001-YL430
V00145		10-62091-13 VLV-AFT CABIN TRIM MODULATING	213A1005 81205	1	21-61-14 546/153/R016	YC001-YL430

EQUIPMENT LIST

D280A103

Section V00100

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00146		10-62091-5 VLV-TRIM PRESSURE REGULATING SHUTOFF	213A1005 81205	1	21-61-15 557/148/R014	YC001-YL430
V00148		S315N370-3 LEFT T/R SLEEVE SYNC LOCK	315A2600 21883	2	78-32-51 ENG/ /	ALL
V00150		S315N370-3 RIGHT T/R SLEEVE SYNC LOCK	315A2600 21883	2	78-32-51 ENG/ /	ALL
V00154		S273A010-2 VLV-ALTERNATE EXTEND SOLENOID	273A0100 96906	1	32-35-11 685/200/L050	ALL
V00155		196298-001 T/R 1 INTERLOCK SOLENOID	254A1110 81840	1	78-35-11 P008-00/ /	ALL
V00156		196299-001 T/R 2 INTERLOCK SOLENOID	254A1110 81840	1	78-35-21 P008-00/ /	ALL
V00157		60B40041-5 VLV-OVERBOARD EXHAUST	217A1003 624469	1	21-43-21 362/164/L010	ALL
V00158	1	10-60811-8 VLV-RUDDER AUTHORITY LIMITER SOLENOID	S251A301	1	27-25-11 1087/ /	ALL
V00158	2	10-60811-13 VLV-RUDDER AUTHORITY LIMITER SOLENOID	S251A301	1	27-25-11 1087/ /	ALL
V00159		10-62018-9 VLV-RIGHT ELEVATOR TAB SOLENOID	271A8482 92003	1	27-31-11 1158/285/R006	ALL
V00160		10-62018-9 VLV-LEFT ELEVATOR TAB SOLENOID	271A8482 92003	1	27-31-11 1158/285/R006	ALL
V00162		S256A220-1 VLV-LE UCM SHUTOFF	256A2008 81205	1	27-81-51 632/162/R060	ALL
V00163		S256A220-1 VLV-LE CRUISE DEPRESSURIZATION	256A2009 81205	1	27-81-51 701/199/L010	ALL
V00171		10-60811-8 VLV-RUDDER AUTHORITY LIMITER SOLENOID	S251A301	1	27-25-11 1087/ /	YC031-YL430
V00172		3291766-1 VLV - NGS PRES REG SOV	212A5001 59364	1	47-30-11 543/162/L032	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670

EQUIPMENT LIST

D280A103

Section V00100

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00173		3291828-1 VLV - NGS RAM AIR VALVE	212A5001 59364	1	47-30-11 644/160/L054	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
V00174		2040020-101 VLV - ASM HIGH FLOW VALVE	212A5001 92003	1	47-30-11 605/162/L059	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
V00175		4404B000-001 VLV - NGS OVERTEMP SOV	212A5001 6T577	1	47-30-11 653/162/L061	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
V00183		S251A101-1 VLV-GROUND SPOILER BYPASS	251A1730 81205	1	27-60-01 671/190/R034	ALL

EQUIPMENT LIST

D280A103

Section V00100
Page 3 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y004+++		LRUOFM01415 MODULE-LAVATORY UTILITY	10-62085 81205	1	38-21-11 //	YK901-YK910, YK918, YL421- YM651
Y004+++		LRUOFM01415 MODULE-LAVATORY UTILITY	S417A180 81205	1	38-21-11 //	YK911-YK917, YK919-YL401, YM652-YM670
Y004H01		10-61068-2 WATER HEATER-LAV	S417A101 81205	1	38-21-11 //	YC001-YK910, YK918, YL421- YM651
Y004H01		60B50064-4 WATER HEATER-LAV	S417A180 81205	1	38-21-11 //	YK911-YK917, YK919-YL401, YM652-YM670
Y004J03		48-7191 CONNECTOR-OXYGEN MODULE	10-62085 92824	1	35-21-12 M01415/ /	ALL
Y004L02		5106WW LAMP-LAV A MIRROR	10-62085 81205	2	33-26-31 //	YC001-YC030
Y004L05		1251 LAMP-LAV INCANDESCENT	10-62085 81205	1	33-26-31 //	YC001-YC030
Y004L11		5113WW LAMP-MAIN LIGHT 1 - COMMON LAV A	D72S98008 XXTBD	1	33-26-31 //	YK907-YL426, YL429, YM652- YM670
Y004L11		5113CW LAMP-MAIN LT 1 (COOL WHITE) COMMON LAV A	D72S98008 XXTBD	1	33-26-31 //	YL427-YL428, YL430
Y004L12		5113WW LAMP-MAIN LIGHT 2 - COMMON LAV A	D72S98014	1	33-26-31 //	YK907-YL426, YL429, YM643- YM670
Y004L12		5113CW LAMP-MAIN LT 2 (COOL WHITE) COMMON LAV A	D72S98014	1	33-26-31 //	YL427-YL428, YL430
Y004L14		D72D93003-111 LED-RTS SIGN COMMON LAV A	D72S98008	1	33-26-31 //	YC031-YM670
Y004L15		D27D93006-111 LED - AUX LIGHT - COMMON LAV A	D72S98008 XXTBD	1	33-26-31 //	YC031-YM670
Y004M01		S283U008-19 BALLAST-LAV A LT	10-62085 81205	1	33-26-31 //	YC001-YC030

EQUIPMENT LIST

D280A103

Section Y004

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y004M03		PU90-429 SMOKE-DETECTOR LAV A	417A1000 S5065	1	26-14-11 298/288/L010	YC001-YC050
Y004M03		PU90-429 SMOKE-DETECTOR	10-62085 81205	1	26-14-11 //	YK901-YM670
Y004M11		61-48-2 BALLAST- MAIN LT - COMMON LAV A	D72S98008 XXTBD	1	33-26-31 //	YC031-YM670
Y004P02		48-7190 CONNECTOR-OXYGEN MODULE	10-62085 92824	1	35-21-12 M01415/ /	ALL
Y004P03		DAMA-15S-WS PLUG	417A1000 71468	1	26-14-11 298/288/L010	YC001-YC050
Y004R01		BACR13CD2 RELAY-ATTENDANT CALL-COMMON LAV A	10-62085 81205	1	33-27-11 //	ALL
Y004R04		1N5618 DIODE-BLOCKING COMMON LAV A	D72S98008	1	33-27-11 //	YK907-YM670
Y004R05		1N5618 DIODE-BLOCKING COMMON LAV A	10-62085 92824	1	33-27-11 //	ALL
Y004R06		1V5618 DIODE-BLOCKING COMMON LAV A	10-62085 92824	1	33-27-11 //	YC001-YC030, YK907-YM670
Y004R14		1N5618 DIODE-BLOCKING COMMON LAV A	D72S98008	1	33-27-11 //	YC031-YK906
Y004S04		A20247AM1 SW-ATTENDANT CALL RESET	10-62085 92824	1	33-27-11 //	YC001-YC030
Y004S11		D72D93001-111 SW-DOOR MANUAL LT OVERRIDE COMMON LAV A	D72S98008	1	33-27-11 //	YC031-YM670
Y004S14		D72D93005-111 SW-ATTEND CALL RESET COMMON LAV A	D72S98008	1	33-27-11 //	YC031-YM670
Y004XL5		502B SOCKET-LAV INCANDESCENT LT	10-62085 81205	1	33-26-31 //	YC001-YC030
Y004XR1		HRTS-13KM RELAY-SOCKET-ATT CALL COMMON LAV A	10-62085 92824	1	33-27-11 //	YC001-YC030, YK907-YM670

EQUIPMENT LIST

D280A103

Section Y004
Page 2 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y007+++		LRUOFM01418 MODULE-LAVATORY UTILITY	10-62085 81205	1	38-21-11 //	YC001-YK910, YK918, YL421- YL430
Y007+++		LRUOFM01418 MODULE-LAVATORY UTILITY	S417A180 81205	1	38-21-11 //	YK911-YK917, YK919-YL401, YM652-YM670
Y007+++		LRUOFM01418 MODULE-LAVATORY UTILITY	S417A101 81205	1	38-21-11 //	YM643-YM651
Y007H01		10-61068-2 WATER HEATER-LAV	10-62085 81205	1	38-21-11 //	YC001-YK910, YK918, YL421- YM651
Y007H01		60B50064-4 WATER HEATER-LAV	S417A180 81205	1	38-21-11 //	YK911-YK917, YK919-YL401, YM652-YM670
Y007J03		48-7191 CONNECTOR-OXYGEN MODULE	10-62085 92824	1	35-21-12 M01418/ /	YM643-YM670
Y007L02		5106WW LAMP-LAV D MIRROR	10-62085 81205	1	33-26-31 //	YC001-YC030
Y007L04		D72D93003-11 LED-NS/FSB SIGN COMMON LAV D	D72S98014	1	33-26-31 //	YC001-YC030, YK907-YM670
Y007L05		1251 LAMP-LAV INCANDESCENT	10-62085 81205	1	33-26-31 //	YC001-YC030
Y007L11		5113WW LAMP-MAIN LIGHT 1 - COMMON LAV D	D72S98014	1	33-26-31 //	YC001-YL426, YL429, YM643- YM670
Y007L11		5113CW LAMP-MAIN LT 1 (COOL WHITE) COMMON LAV D	D72S98014	1	33-26-31 //	YL427-YL428, YL430
Y007L12		5113WW LAMP-MAIN LIGHT 2 - COMMON LAV D	D72S98014	1	33-26-31 //	YC001-YL426, YL429, YM643- YM670
Y007L12		5113CW LAMP-MAIN LT 2 (COOL WHITE) COMMON LAV D	D72S98014	1	33-26-31 //	YL427-YL428, YL430
Y007L14		D72D93003-111 LED-RTS SIGN COMMON LAV D	D72S98008	1	33-26-31 //	YK907-YM670

EQUIPMENT LIST

D280A103

Section Y007

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y007L15		D27D93006-111 LED - AUX LIGHT - COMMON LAV D	D72S98008 XXTBD	1	33-26-31 //	YK907-YM670
Y007M01		S283U008-19 BALLAST-LAV D LT	10-62085 81205	1	33-26-31 //	YC001-YC030
Y007M03		PU90-429 SMOKE-DETECTOR	417A1200 55065	1	26-14-11 930/301/L017	YC001-YC050
Y007M03		PU90-429 SMOKE-DETECTOR	10-62085 55065	1	26-14-11 //	YK901-YM670
Y007M09		702409-1078 FLOOD LIGHT	S417A180 55438	1	33-51-22 948/253/L014	YK901-YL430
Y007M09		702409-1078 FLOOD LIGHT	S417A180 81205	1	33-51-22 948/253/L014	YM643-YM670
Y007M11		61-48-2 BALLAST-LAV D MAIN LIGHT	D72S98014	1	33-26-31 //	YC031-YK906, YL421-YL430
Y007M11		61-48-2 BALLAST- MAIN LT - COMMON LAV D	D72S98014	1	33-26-31 //	YK907-YL401, YM643-YM670
Y007P02		48-7190 CONNECTOR-OXYGEN MODULE	10-62085 92824	1	35-21-12 M01418/ /	YM643-YM670
Y007P03		DAMA-15S-WS PLUG	417A1200 71468	1	26-14-11 930/301/L017	YC001-YC050
Y007R01		BACR13CD2 RLY-ATTENDANT CALL	10-62085 81205	1	33-27-11 //	YC001-YK906, YL421-YL430
Y007R01		BACR13CD2 RELAY-ATTENDANT CALL-COMMON LAV D	10-62085 81205	1	33-27-11 //	YK907-YL401, YM643-YM670
Y007R04		1N5618 DIODE-BLOCKING COMMON LAV D	D72S98014	1	33-27-11 //	ALL
Y007R05		1N5618 DIODE-BLOCKING	10-62085 92824	1	33-27-11 //	YC001-YK906, YL421-YL430
Y007R05		1N5618 DIODE-BLOCKING COMMON LAV D	10-62085 92824	1	33-27-11 //	YK907-YL401, YM643-YM670
Y007R06		1N5618 DIODE-BLOCKING	10-62085 92824	1	33-27-11 //	YC001-YK906, YL421-YL430
Y007R06		1N5618 DIODE-BLOCKING COMMON LAV D	10-62085 92824	1	33-27-11 //	YK907-YL401, YM643-YM670

EQUIPMENT LIST

D280A103

Section Y007

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y007S01		D72D93001-111 SW-DOOR MANUAL LT OVERRIDE	D72S98014	1	33-27-11 //	YC031-YK906
Y007S04		A20247AM1 SW-ATTENDANT CALL RESET	10-62085 92824	1	33-27-11 //	YC001-YC030
Y007S11		D72D93001-111 SW-DOOR MANUAL LT OVERRIDE COMMON LAV D	D72S98008	1	33-27-11 //	YK907-YM670
Y007S14		D72D93005-11 SW-ATTEND CALL RESET COMMON LAV D	D72S98014 92824	1	33-27-11 //	YC031-YM670
Y007XL5		502B SOCKET-LAV INCANDESCENT LT	10-62085 81205	1	33-26-31 //	YC001-YC030
Y007XR1		HRTS-13KM RELAY-SOCKET-ATT CALL COMMON LAV D	10-62085 92824	1	33-27-11 //	YC001-YC030, YK907-YM670
Y007XR2		BACS16X3 SOCKET-LAV LIGHT RELAY	10-62085 81205	1	33-26-31 //	YC001-YK906

EQUIPMENT LIST

D280A103

Section Y007
Page 3 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y008+++		LRUOFM01419 MODULE-LAVATORY UTILITY	10-62085 81205	1	38-21-11 //	YK901-YK910, YK918, YL421- YM651
Y008+++		LRUOFM01419 MODULE-LAVATORY UTILITY	S417A180 81205	1	38-21-11 //	YK911-YK917, YK919-YL401, YM652-YM670
Y008H01		10-61068-2 WATER HEATER-LAV	10-62085 81205	1	38-21-11 //	YC001-YK910, YK918, YL421- YM651
Y008H01		60B50064-4 WATER HEATER-LAV	S417A180 81205	1	38-21-11 //	YK911-YK917, YK919-YL401, YM652-YM670
Y008J03		48-7191 CONNECTOR-OXYGEN MODULE	10-62085 92824	1	35-21-12 M1419/ /	YC001-YL430
Y008L02		5106WW LAMP-LAV E MIRROR	10-62085 81205	2	33-26-31 //	YC001-YC030
Y008L05		1251 LAMP-LAV INCANDESCENT	10-62085 81205	1	33-26-31 //	YC001-YK906
Y008L11		5113WW LAMP-MAIN LIGHT 1 - COMMON LAV E	D72S98011	1	33-26-31 //	YC031-YL426, YL429, YM643- YM670
Y008L11		5113CW LAMP-MAIN LT 1 (COOL WHITE) COMMON LAV E	D72S98011	1	33-26-31 //	YL427-YL428, YL430
Y008L12		5113WW LAMP-MAIN LIGHT 2 - COMMON LAV E	D72S98011	1	33-26-31 //	YC001-YL426, YL429, YM643- YM670
Y008L12		5113CW LAMP-MAIN LT 2 (COOL WHITE) COMMON LAV E	D72S98011	1	33-26-31 //	YL427-YL428, YL430
Y008L14		D72D93003-11 LED-RTS SIGN COMMON LAV E	D72S98014	1	33-26-31 //	YK907-YM670
Y008L15		D72D93006-111 LED - AUX LIGHT - COMMON LAV E	D72S98011	1	33-26-31 //	YC031-YM670
Y008M01		S283U008-19 BALLAST-LAV E LT	10-62085 81205	1	33-26-31 //	YC001-YC030

EQUIPMENT LIST

D280A103

Section Y008

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y008M03		PU90-429 SMOKE-DETECTOR LAV E	417A1300 81205	1	26-14-11 932/301/R017	YC001-YC050
Y008M03		PU90-429 SMOKE-DETECTOR	10-62085 81205	1	26-14-11 //	YK901-YM670
Y008M11		61-48-2 BALLAST- MAIN LT - COMMON LAV E	D72S98011	1	33-26-31 //	YC031-YM670
Y008P02		48-7190 CONNECTOR-OXYGEN MODULE	10-62085 92824	1	35-21-12 M1419/ /	YC001-YL430
Y008P03		DAMA-15S-WS PLUG	417A1300 71468	1	26-14-11 932/301/R017	YC001-YC050
Y008R01		BACR13CD2 RELAY-ATTENDANT CALL	10-62085 81205	1	33-27-11 //	YC001-YC030
Y008R01		BACR13CD2 RELAY-ATTENDANT CALL-COMMOM LAV E	D72S98011 81205	1	33-27-11 //	YC031-YK906, YL421-YL430
Y008R01		BACR13CD2 RELAY-ATTENDANT CALL-COMMON LAV E	D72S98011 81205	1	33-27-11 //	YK907-YL401, YM643-YM670
Y008R04		1N5618 DIODE-BLOCKING COMMON LAV E	D72S98011	1	33-27-11 //	YC031-YM670
Y008R05		1N5618 DIODE-BLOCKING	10-62085 92824	1	33-27-11 //	YC001-YC030
Y008R05		1N5618 DIODE-BLOCKING COMMON LAV E	D72S98011	1	33-27-11 //	YC031-YM670
Y008R06		1N5618 DIODE-BLOCKING COMMON LAV E	D72S98011 92824	1	33-27-11 //	YC001-YK906, YL421-YL430
Y008R06		1V5618 DIODE-BLOCKING COMMON LAV E	10-62085 92824	1	33-27-11 //	YK907-YL401, YM643-YM670
Y008S04		A20247AM1 SW-ATTENDANT CALL RESET	10-62085 92824	1	33-27-11 //	YC001-YC030
Y008S11		D72D93001-111 SW-DOOR MANUAL LT OVERRIDE COMMON LAV E	D72S98011	1	33-27-11 //	YC031-YM670
Y008S14		D72D93005-111 SW-ATTENDANT CALL RESET COMMON LAV E	D72S98011	1	33-27-11 //	YC031-YK906, YL421-YL430
Y008S14		D72D93005-111 SW-ATTEND CALL RESET COMMON LAV E	D72S98011	1	33-27-11 //	YK907-YL401, YM643-YM670

EQUIPMENT LIST

D280A103

Section Y008

Page 2

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y008XL5		502B SOCKET-LAV INCANDESCENT LT	10-62085 81205	1	33-26-31 //	YC001-YC030
Y008XR1		HRTS-13KM RELAY-SOCKET-ATTENDANT CALL	10-62085 92824	1	33-27-11 //	YC001-YC030
Y008XR1		HRTS-13KM RELAY-SOCKET-ATT CALL COMMON LAV E	D72S98011 92824	1	33-27-11 //	YK907-YM670
Y008XR2		BACS16X3 SOCKET-LAV LIGHT RELAY	10-62085 81205	1	33-26-31 //	YC001-YK906

EQUIPMENT LIST

D280A103

Section Y008
Page 3 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y04XR11		HRTS-17KJV2 RELAY SOCKET-ATTENDANT CALL COMMON LAV A	D72S98008	1	33-27-11 //	YC031-YM670

EQUIPMENT LIST

D280A103

Section Y04X
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y07XR11		HRTS-17KJV2 RELAY SOCKET-ATTENDANT CALL COMMON LAV D	D72S98014	1	33-27-11 / /	YC031-YM670

EQUIPMENT LIST

D280A103

Section Y07X
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y08XR11		HRTS-17KJV2 RELAY-SOCKET-ATTENDANT CALL COMMON LAV E	D72S98011	1	33-27-11 //	YC031-YM670

EQUIPMENT LIST

D280A103

Section Y08X
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAAM001		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC IGNITION UNIT	351A1000 64547	1	49-41-11 APU/ /	ALL
YAAM002		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC FUEL CONTROL UNIT	351A1000 64547	1	49-62-12 APU/ /	ALL
YAAM003		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC MDL-DATA MEMORY	351A1000 64547	1	49-62-12 APU/ /	ALL

EQUIPMENT LIST

D280A103

Section YAAM00
Page 1 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAAT001		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC SNSR-OIL LEVEL	351A1000 64547	1	49-94-21 APU/ /	ALL
YAAT002		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC SNSR(+2)-INLET TEMPERATURE	351A1000 64547	1	49-94-21 APU/ /	ALL
YAAT003		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC SNSR(P2)-INLET PRESSURE	351A1000 64547	1	49-62-12 APU/ /	ALL
YAAT004		ALLIEDSIGNALSUPLIEDSEEVENDORIPC SNSR(PT)-TOTAL PRESSURE	351A1000 64547	1	49-52-31 APU/ /	ALL
YAAT006		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC SNSR-OIL TEMPERATURE	351A1000 64547	1	49-94-21 APU/ /	ALL
YAAT007		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC SNSR-SPEED	351A1000 64547	1	49-62-12 APU/ /	ALL
YAAT008		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC SW-LOW OIL PRESSURE	351A1000 64547	1	49-71-21 APU/ /	ALL
YAAT009		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC EXHAUST GAS TEMPERATURE THERMOCOUPLE 1	351A1000 64547	1	49-71-21 APU/ /	ALL
YAAT010		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC EXHAUST GAS TEMPERATURE THERMOCOUPLE 2	351A1000 64547	1	49-71-21 APU/ /	ALL
YAAT011		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC S/G FILTER BYPASS SWITCH	351A1000 64547	1	49-94-21 / /	ALL
YAAT012		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC SNSR (DELTA P)-DELTA PRESSURE	351A1000 64547	1	49-52-31 / /	ALL

EQUIPMENT LIST

D280A103

Section YAAT00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAAV001		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC VLV-BLEED	351A1000 64547	1	49-52-31 APU/ /	ALL
YAAV002		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC INLET GUIDE VANE	351A1000 64547	1	49-52-31 APU/ /	ALL
YAAV003		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC VLV-SURGE	351A1000 64547	1	49-52-31 APU/ /	ALL
YAAV004		ALLIEDSIGNALSUPPLIEDSEEVENDORIPC FLOW DIVIDER SOLENOID	351A1000 64547	1	49-62-12 APU/ /	ALL

EQUIPMENT LIST

D280A103

Section YAAV00
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAB++++		LRUOFM1888 MODULE-WASTE SYSTEM	417A6110 81205	1	38-32-13 P014-00/ /	ALL

EQUIPMENT LIST

D280A103

Section YAB+
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YABA101		285A1731-1 ASSEMBLY-PRINTED WIRING	417A6110 81205	1	38-32-13 M01888/ /	ALL

EQUIPMENT LIST

D280A103

Section YABA00
Page 1 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YABS001		2100-1 SWITCH-LAVS INOP/TEST SWITCH	417A6110 81205	1	38-32-13 M01888/ /	ALL
YABS01B		2100-240 LENS-LAVS INOP/TEST SWITCH	417A6110 81205	1	38-32-13 M01888/ /	ALL
YABS01L		AML91LA85 LAMP-LAVS INOP/TEST SWITCH	417A6110 81205	1	38-32-13 M01888/ /	ALL

EQUIPMENT LIST

D280A103

Section YABS00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAC++++		LRUOFM1887 MODULE-POTABLE WATER	A17A6110 81205	1	38-41-11 P014-00/ /	ALL

EQUIPMENT LIST

D280A103

Section YAC+
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YACA101		285A1721-1 ASSEMBLY-PRINTED WIRING	A17A6110 81205	1	38-41-11 M01887 / /	ALL

EQUIPMENT LIST

D280A103

Section YACA00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAD++++		LRUOFM01885 MDL-LIGHTING	417A5500 81205	0	33-29-11 / /	ALL

EQUIPMENT LIST

D280A103

Section YAD+
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YADP001		S906-30234-400 PLUG-ATT PNL MODULE	S417A150	1	33-29-11 //	ALL

EQUIPMENT LIST

D280A103

Section YADP00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YADS001		44MY233385 SW-CEILING	S417A150 81073	1	33-22-11 //	ALL
YADS002		44MY241308 SW-ENTRY	S417A150 81073	1	33-29-11 //	ALL
YADS003		44MY241307 SW-WINDOW	S417A150 81073	1	33-21-11 //	ALL
YADS004		2100-1 SW-GROUND SERVICE	S417A150 91929	1	24-23-51 //	ALL
YADS005		2100-3 SW-WORK	S417A150 91929	1	33-26-11 //	ALL
YADS04B		2100-100 LENS	S417A150 91929	1	24-23-51 //	ALL
YADS04L		AML91LA85 LAMP	S417A150 91929	1	24-23-51 //	ALL
YADS05B		2100-100 LENS	S417A150 91929	1	33-26-11 //	ALL
YADS05L		AML91LA85 LAMP-	S417A150 91929	1	33-26-11 //	ALL

EQUIPMENT LIST

D280A103

Section YADS00
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAE++++		LRUOFM01886 MDL-LIGHTING	417A5500 81205	0	33-29-11 / /	ALL

EQUIPMENT LIST

D280A103

Section YAE+
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAEP001		S906-30234-400 PLUG-ATT PNL MODULE	S417A150	1	33-29-11 //	ALL

EQUIPMENT LIST

D280A103

Section YAEP00
Page 1 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAES001		44MY241308 SW-ENTRY	S417A150 81073	1	33-29-11 //	ALL
YAES002		2100-13 SW-EMERGENCY EXIT LIGHTS	S417A150 91929	1	33-51-11 //	ALL
YAES003		2100-3 SW-WORK	S417A150 91929	1	33-26-11 //	ALL
YAES026		2100-11 SW-GUARD	S417A150	1	33-51-11 //	ALL
YAES02B		2100-100 LENS	S417A150 91929	1	33-51-11 //	ALL
YAES02L		AML91LA85 LAMP-	S417A150 91929	1	33-51-11 //	ALL
YAES03B		2100-100 LENS-	S417A150 91929	1	33-26-11 //	ALL
YAES03L		AML91LA85 LAMP-	S417A150	1	33-26-11 //	ALL

EQUIPMENT LIST

D280A103

Section YAES00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YUR++++		LRUOFM11031 MDL-PSU U/B COMPONENT	417N3011 81205	0	33-23-31 / /	YK901-YM670

EQUIPMENT LIST

D280A103

Section YUR+
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YURB001		S417T402-2 LATCH-PASS OXYGEN	417N3152 92552	1	35-21-41 / /	ALL

EQUIPMENT LIST

D280A103

Section YURB00
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YURJ005		48-7191 RCPT-PASS OXYGEN LATCH	S417N313 TBD	1	35-21-41 //	ALL
YURJ006		48-7191-1 RCPT-PASS OXYGEN LATCH	S417N313 TBD	1	35-21-41 //	ALL
YURJ007		TBD RCPT-PASS SIGN	S417N301	1	33-25-41 //	ALL

EQUIPMENT LIST

D280A103

Section YURJ00
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YURL004		S417N311-5 LIGHT ASSY-PASS READING	S417N313 01781	1	33-23-31 / /	YK901-YM670
YURL005		S417N311-5 LIGHT ASSY-PASS READING	S417N313 01781	1	33-23-31 / /	YK901-YM670
YURL006		S417N311-5 LIGHT ASSY-PASS READING	S417N313 01781	1	33-23-31 / /	YK901-YM670
YURL007		S417N301-2 SIGN-PSU U/B NSFBS	S417N313 30190	1	33-25-41 / /	ALL
YURL04T		9204 LAMP-PASS READING	S417N311 68045	1	33-23-31 / /	YK901-YM670
YURL05T		9204 LAMP-PASS READING	S417N311 68045	1	33-23-31 / /	YK901-YM670
YURL06T		9204 LAMP-PASS READING	S417N311 68045	1	33-23-31 / /	YK901-YM670
YURL07T		7387 LAMP-PASS SIGN	S417N301 08806	6	33-25-41 / /	ALL

EQUIPMENT LIST

D280A103

Section YURL00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YURP005		48-7190 PLUG-PASS OXYGEN LATCH	S417N313 TBD	1	35-21-41 / /	ALL
YURP006		48-7190-1 PLUG-PASS OXYGEN LATCH	S417N313 TBD	1	35-21-41 / /	ALL
YURP007		103958-2 PLUG-PASS SIGN	S417N301 TBD	1	33-25-41 / /	ALL

EQUIPMENT LIST

D280A103

Section YURP00
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YUS++++		LRUOFM11032 MODULE-PSU U/B COMPONENT	417N3011 81205	1	33-23-31 / /	YC001-YC050

EQUIPMENT LIST

D280A103

Section YUS+
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YUSL004		S417N311-1 LIGHT ASSY-PASS READING	S417N313 01781	1	33-23-31 //	YC001-YC050
YUSL005		S417N311-1 LIGHT ASSY-PASS READING	S417N313 01781	1	33-23-31 //	YC001-YC050
YUSL006		S417N311-1 LIGHT ASSY-PASS READING	S417N313 01781	1	33-23-31 //	YC001-YC050
YUSL04T		9204 LAMP-PASS READING	S417N311 TBD	1	33-23-31 //	YC001-YC050
YUSL05T		9204 LAMP-PASS READING	S417N311 TBD	1	33-23-31 //	YC001-YC050
YUSL06T		9204 LAMP-PASS READING	S417N311 TBD	1	33-23-31 //	YC001-YC050

EQUIPMENT LIST

D280A103

Section YUSL00
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YUSP003		M103958-2 PLUG-PSU COMPONENT	S417N313 TBD	1	33-23-31 //	YC001-YC050

EQUIPMENT LIST

D280A103

Section YUSP00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YUXP001		87922-4 PLUG-PSU JUMPER	S417N313 81205	1	33-23-31 / /	ALL
YUXP002		39-01-2045 PLUG-PSU JUMPER	S417N313 81205	1	33-23-31 / /	ALL
YUXP004		BACC45FT18A14P PLUG-PSU JUMPER	S417N313 81205	1	33-23-31 / /	ALL

EQUIPMENT LIST

D280A103

Section YUXP00
Page 1 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YVEJ001		103168-6 RCPT-PSU U/B SWITCH MODULE	S417N312	1	33-23-31 / /	ALL
YVEJ002		39-31-0048 RCPT-PSU U/B SWITCH MODULE	S417N312	1	33-23-31 / /	ALL
YVEJ003		103168-8 RCPT-PSU U/B SWITCH MODULE	S417N312	1	33-23-31 / /	ALL

EQUIPMENT LIST

D280A103

Section YVEJ00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YVES004		SW-5931 SW-READING LIGHT	S417N312	1	33-23-31 / /	ALL
YVES005		SW-5931 SW-READING LIGHT	S417N312	1	33-23-31 / /	ALL
YVES006		SW-5931 SW-READING LIGHT	S417N312	1	33-23-31 / /	ALL

EQUIPMENT LIST

D280A103

Section YVES00
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YWC++++		LRUOFM01834 MDL-ATTENDANTS OXYGEN	411A3420 TBD	0	35-21-12 //	ALL

EQUIPMENT LIST

D280A103

Section YWC+
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YWD++++		LRUOFM01766 SW-AUTOTHROTTLE PACK#1,L ENG	254A1150 81205	1	32-42-11 235/199/R001	ALL

EQUIPMENT LIST

D280A103

Section YWD+
Page 1 End
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YWDS001		39SE8 SW-LANDING GEAR WARNING	254A11F0 81205	1	32-64-21 235/199/R01	ALL
YWDS002		39SE8 SW-AUTOBRAKE	254A1150 91812	1	32-42-11 235/199/R004	ALL
YWDS003		39SE8 SW-AUTOBRAKE	254A1150 91812	1	32-42-11 235/199/R004	ALL
YWDS004		39SE9 SW-T/R 1 SYNC LOCK	254A1150 3G533	1	78-32-51 235/199/R004	ALL
YWDS005		39SE9 SW-T/R 1 ARM	254A1150 3G533	1	78-34-11 235/199/R004	ALL
YWDS006		39SE9 SW-T/R 1 STOW	254A1150 3G533	1	78-34-11 235/199/R004	ALL
YWDS008		39SE8 SW-LANDING GEAR WARNING	254A2250 81205	1	32-64-21 235/199/R004	ALL
YWDS009		39SE8 SW-LANDING GEAR WARNING	254A2250 81205	1	32-64-21 235/199/R004	ALL

EQUIPMENT LIST

D280A103

Section YWDS00

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YWE++++		LRUOFM01767 SW-AUTOTHROTTLE PACK#2,R ENG	254A1150 81205	1	32-42-11 235/199/R004	ALL

EQUIPMENT LIST

D280A103

Section YWE+
Page 1 End
Aug 10/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YWES001		39SE8 SW-LANDING GEAR WARNING	254A2250 81205	1	32-64-21 235/199/R004	ALL
YWES002		39SE8 SW-AUTOBRAKE	254A1150 91812	1	32-42-11 235/199/R004	ALL
YWES003		39SE8 SW-AUTOBRAKE	254A1150 91812	1	32-42-11 235/199/R004	ALL
YWES004		39SE9 SW-T/R 2 SYNC LOCK	254A1150 3G533	1	78-32-61 235/199/R004	ALL
YWES005		39SE9 SW-T/R 2 ARM	254A1150 3G533	1	78-34-21 235/199/R004	ALL
YWES006		39SE9 SW-T/R 2 STOW	254A1150 3G533	1	78-34-21 235/199/R004	ALL
YWES008		39SE8 SW-LANDING GEAR WARNING	254A2250 81205	1	32-64-21 235/199/R004	ALL
YWES009		39SE8 SW-LANDING GEAR WARNING	254A2250 81205	1	32-64-21 235/199/R004	ALL

EQUIPMENT LIST

D280A103

Section YWES00

Page 1 End

Aug 10/2009