

91-21-31

SPLICE LIST



91-21-31
SPLICE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			SP00800	1	May 11/2009	SP03700	1	Feb 09/2009
	1	Aug 10/2009		2	Feb 09/2009	SP03800	1	Feb 09/2009
	2	BLANK	R SP00900	1	Aug 10/2009	SP04000	1	Feb 09/2009
R SP00000	1	Aug 10/2009	R SP01000	1	Aug 10/2009	SP04600	1	Feb 09/2009
R	2	Aug 10/2009	SP01100	1	Feb 09/2009	SP05000	1	Feb 09/2009
	3	Feb 09/2009		2	Feb 09/2009	SP09000	1	Aug 13/2008
	4	Feb 09/2009	SP01200	1	Feb 09/2009		2	BLANK
R SP00100	1	Aug 10/2009	R SP01500	1	Aug 10/2009			
	2	Feb 09/2009	SP01700	1	Feb 09/2009			
	3	Feb 09/2009	SP01800	1	Feb 09/2009			
	4	Feb 09/2009		2	Feb 09/2009			
R	5	Aug 10/2009	SP01900	1	Feb 09/2009			
R SP00200	1	Aug 10/2009	SP02000	1	Feb 09/2009			
	2	Feb 09/2009	SP02100	1	Feb 09/2009			
	3	Feb 09/2009	SP02200	1	Feb 09/2009			
R SP00300	1	Aug 10/2009	SP02600	1	Aug 13/2008			
R	2	Aug 10/2009	SP02800	1	Feb 09/2009			
	3	Feb 09/2009		2	Feb 09/2009			
R SP00400	1	Aug 10/2009	SP02900	1	Feb 09/2009			
O	2	Aug 10/2009	R SP03000	1	Aug 10/2009			
	3	Feb 09/2009	SP03100	1	Feb 09/2009			
SP00500	1	Feb 09/2009	SP03200	1	Feb 09/2009			
	2	Feb 09/2009	SP03300	1	Feb 09/2009			
	3	Feb 09/2009	SP03400	1	Feb 09/2009			
	4	Feb 09/2009		2	Feb 09/2009			
	5	Feb 09/2009		3	Feb 09/2009			
R SP00600	1	Aug 10/2009		4	Feb 09/2009			
SP00700	1	May 11/2009	SP03500	1	May 11/2009			

A = Added, R = Revised, D = Deleted, O = Overflow

SPLICE LIST

D280A103

EFFECTIVE PAGES

Page 1
Aug 10/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00010		394/178/L047					ALL
	W5110	0510	20		S	29-11-12	YC001-YC030, YK901-YM670
	W5230	0503	18		S	29-11-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00012		394/195/R044					ALL
	W6128	0503	18		S	29-11-12	ALL
	W6410	0510	20		S	29-11-12	ALL
SP00014		//					ALL
SP00016		255/273/R018					ALL
SP00017		E004-01/ /					YK901-YM670
	W0410	0005	22		W	23-51-51	YK901-YM670
	W0411	0017	22		W	23-51-51	YK901-YM670
	W0411	0356	22		W	23-51-31	YK901-YM670
SP00020		//					ALL
SP00028		428/296/R020					ALL
	W5726	0584	20		S	49-62-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W6172	0511	20		S	49-62-11	ALL
SP00030		428/296/R020					ALL
	W5726	0598	10		S	49-62-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W6172	6003	10		S	49-62-11	ALL
SP00032		//					ALL
SP00034		//					ALL
SP00036		//					ALL
SP00038		//					ALL
SP00040		//					ALL
SP00042		//					ALL



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00044		//					ALL
SP00046		//					ALL
SP00047		1040/194/L005					ALL
	W7359	3502R	20		9	23-41-11	ALL
	W7359	3502Z				23-41-11	ALL
	W7359	A-A			9	23-41-11	ALL
SP00048		//					ALL
SP00049		1040/194/L005					ALL
	W7359	3502B	20		9	23-41-11	ALL
	W7359	A-B			9	23-41-11	ALL
SP00051		1040/194/L005					ALL
	W7359	3502Y	20		9	23-41-11	ALL
	W7359	A-C			9	23-41-11	ALL
SP00052		//					ALL
SP00054		1085/265/L001					ALL
I	W4134	1013	20		9	31-53-11	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I	W4134	A-C			9	31-53-11	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W6134	0513	20		9	31-53-11	YC001-YC007
	W6134	A-C			9	31-53-11	YC001-YC007
SP00056		1085/265/L001					ALL
I	W4134	1014	20		9	31-53-11	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I	W4134	A-B			9	31-53-11	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I	W4134	B-B			9	31-53-11	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W6134	0514	20		9	31-53-11	YC001-YC007
	W6134	A-B			9	31-53-11	YC001-YC007
	W6134	B-B			9	31-53-11	YC001-YC007
SP00058		1085/265/L001					ALL
I	W4134	A-F			9	31-53-11	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I	W4134	B-C			9	31-53-11	YC008-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W6134	A-F			9	31-53-11	YC001-YC007
	W6134	B-C			9	31-53-11	YC001-YC007

SPLICE LIST

D280A103

91-21-31

Section SP00000

Page 2

Aug 10/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00060		//					ALL
SP00064		//					ALL
SP00066		//					ALL
SP00067		265/184/L065					ALL
SP00068		//					ALL
SP00070		232/271/0					ALL
	W2218	5560	18		S	33-14-12	YC001-YC030, YK901-YM670
	W2218	A-AA			S	33-14-12	YC001-YC030, YK901-YM670
SP00072		232/271/0					ALL
	W2218	5561	18		S	33-14-12	YC001-YC030, YK901-YM670
	W2218	A-AB			S	33-14-12	YC001-YC030, YK901-YM670
SP00078		250/267/L029					ALL
SP00081		258/194/L008					YK901-YM670
	W2413	0059	24		S	23-27-31	YK901-YM670
	W2415	0059	24		S	23-27-31	YK901-YM670
	W2417	0013	24		S	SPARE	YK901-YM670
	W2417	0059	24		S	23-27-31	YK901-YM670
	W3323	0059	24		S	23-27-31	YK901-YM670
SP00082		236/210/R038					ALL
SP00083		258/194/L008					YK901-YM670
	W2413	0055	24		S	23-27-31	YK901-YM670
	W2415	0055	24		S	23-27-31	YK901-YM670
	W2417	0055	24		S	23-27-31	YK901-YM670
	W3323	0058	24		S	23-27-31	YK901-YM670
	W3323	0059	24		S	23-27-31	YK901-YM670
SP00084		//					ALL
SP00086		//					ALL

SPLICE LIST

D280A103

91-21-31

Section SP00000

Page 3

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00087		258/194/L008					YK901-YM670
	W2413	0054	24		S	23-27-31	YK901-YM670
	W2415	0054	24		S	23-27-31	YK901-YM670
	W2417	0054	24		S	23-27-31	YK901-YM670
	W3323	0055	24		S	23-27-31	YK901-YM670
	W3323	0058	24		S	23-27-31	YK901-YM670
SP00088		//					ALL
SP00089		209/206/L023					ALL
	W0145	0001	20		S	27-32-11	ALL
	W2201	0020	20		S	27-32-11	ALL
SP00091		209/206/R023					ALL
	W0147	0001	20		S	27-32-21	ALL
	W2231	0016	20		S	27-32-21	ALL
SP00092		891/297/L24					YC001-YC007
	W5124	0532	18		S	27-31-11	YC001-YC007
	W6134	0537	18		S	27-31-11	YC001-YC007
SP00094		891/297/L24					YC001-YC007
	W5124	0533	18		S	27-31-11	YC001-YC007
	W6134	0530	18		S	27-31-11	YC001-YC007
SP00098		586/200/R036					ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00102		358/201/L020					ALL
	W6110	0020	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	0030	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	B-A			S	33-34-11	YC001-YC030, YK901-YM670
SP00104		356/202/R013					ALL
	W6110	0030	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	0040	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	B-B			S	33-34-11	YC001-YC030, YK901-YM670
SP00110		727+2/198/R050					YC012-YM670
	W5124	0520	20		S	27-41-12	YC012-YM670
	W5224	0518	20		S	27-41-12	YC012-YM670
SP00112		663/165/R008					ALL
	W7122	0522	18		9	29-23-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W8122	0510	20		9	29-23-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00113		1085/232/L018					ALL
	W3381	0005	20		9	22-13-11	YC001-YC007
	W3381	A-1			9	22-13-11	YC001-YC007
	W3391	1005	20		9	22-13-11	YC008-YC030, YK901-YM670
	W3391	A-1			9	22-13-11	YC008-YC030, YK901-YM670
SP00114		727+2/199/R049					YC012-YM670
	W5124	0522	18		S	27-41-12	YC012-YM670
	W5224	0516	20		S	27-41-12	YC012-YM670
SP00115		1085/232/L018					ALL
	W3381	0010	20		9	22-13-11	YC001-YC007
	W3381	A-3			9	22-13-11	YC001-YC007
	W3391	1010	20		9	22-13-11	YC008-YC030, YK901-YM670
	W3391	A-3			9	22-13-11	YC008-YC030, YK901-YM670
SP00116		346/224/L017					YK912-YK917, YK919-YL430, YM652
	W0026	0011	20		S	33-51-21	YK912-YK917, YK919-YL430, YM652
	W0026	A-A			S	33-51-21	YK912-YK917, YK919-YL430, YM652
SP00117		1085/232/L018					ALL
	W3381	0004	20		9	22-13-11	YC001-YC007

SPLICE LIST
D280A103

91-21-31
Section SP00100
Page 1
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00117		1085/232/L018 (continued)					ALL
	W3381	B-1			9	22-13-11	YC001-YC007
	W3391	1004	20		9	22-13-11	YC008-YC030, YK901-YM670
	W3391	B-1			9	22-13-11	YC008-YC030, YK901-YM670
SP00118		346/224/L017					YK912-YK917, YK919-YL430, YM652
	W0026	0012	20		S	33-51-21	YK912-YK917, YK919-YL430, YM652
	W0026	A-B			S	33-51-21	YK912-YK917, YK919-YL430, YM652
SP00119		1085/232/L018					ALL
	W3381	0012	20		9	22-13-11	YC001-YC007
	W3381	B-3			9	22-13-11	YC001-YC007
	W3391	1012	20		9	22-13-11	YC008-YC030, YK901-YM670
	W3391	B-3			9	22-13-11	YC008-YC030, YK901-YM670
SP00124		727+2/199/R049					YC012-YM670
	W5124	0523	20		S	27-41-12	YC012-YM670
	W5224	0500	20		S	27-41-12	YC012-YM670
SP00132		//					ALL
SP00133		334/308/L020					ALL
	W3144	2401R	22		S	23-31-02	ALL
	W3150	2699R	22		S	23-31-02	ALL
	W3329	2006R	22		S	23-31-02	ALL
	W4250	2699R	22		S	23-31-03	ALL
SP00134		//					ALL
SP00135		335/290/L020					ALL
	W3144	2401B	22		S	23-31-02	ALL
	W3150	2699B	22		S	23-31-02	ALL
	W3329	2006B	22		S	23-31-02	ALL
	W4250	2699B	22		S	23-31-03	ALL
SP00136		//					ALL
SP00144		281/186/R021					ALL

SPLICE LIST

D280A103

91-21-31

Section SP00100

Page 2

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00146		281/186/21					ALL
SP00152		1085/265/L014					ALL
	W3381	A-6			9	27-41-12	YC001-YC007
	W3391	A-6			9	27-41-12	YC008-YC030, YK901-YM670
	W4222	1006	18		9	27-41-12	YC008-YM670
	W6222	0506	18		9	27-41-12	YC001-YC007
SP00153		E004-01/ /					ALL
	W0410	0006	22		W	23-51-51	ALL
	W0411	0018	22		W	23-51-51	ALL
	W0411	0349	22		W	23-51-11	YC001-YC050
	W0411	0354	22		W	23-51-11	YK901-YM670
SP00154		1085/265/L014					ALL
	W4222	1005	18		9	27-41-12	YC008-YM670
	W4222	A-E			9	27-41-12	YC008-YM670
	W4222	A-F			9	27-41-12	YC008-YM670
	W6222	0505	18		9	27-41-12	YC001-YC007
	W6222	A-E			9	27-41-12	YC001-YC007
	W6222	A-F			9	27-41-12	YC001-YC007
SP00155		E004-01/ /					ALL
	W0410	0007	22		W	23-51-51	ALL
	W0411	0019	22		W	23-51-51	ALL
	W0411	0350	22		W	23-51-21	ALL
SP00156		1085/265/L014					ALL
	W3381	A-4			9	27-41-12	YC001-YC007
	W3391	A-4			9	27-41-12	YC008-YC030, YK901-YM670
	W4222	1003	20		9	27-41-12	YC008-YM670
	W6222	0503	20		9	27-41-12	YC001-YC007
SP00157		E003-01/ /					YC008-YM670
	W0311	2029R	24		W	31-62-15	YC008-YC030, YK901-YM670
	W0311	2171R	24		W	31-62-15	YC008-YC030, YK901-YM670
	W0313	2669R	24		W	31-62-15	YC008-YC030, YK901-YM670
SP00158		1085/265/L014					ALL
	W4222	1001	20		9	27-41-12	YC008-YM670

SPLICE LIST
D280A103



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00158		1085/265/L014 (continued)					ALL
	W4222	A-J			9	27-41-12	YC008-YM670
	W6222	0501	20		9	27-41-12	YC001-YC007
	W6222	A-J			9	27-41-12	YC001-YC007
SP00159		E003-01/ /					YC008-YM670
	W0311	2029B	24		W	31-62-15	YC008-YC030, YK901-YM670
	W0311	2171B	24		W	31-62-15	YC008-YC030, YK901-YM670
	W0313	2669B	24		W	31-62-15	YC008-YC030, YK901-YM670
SP00160		1085/265/L014					ALL
	W4222	1002	20		9	27-41-12	YC008-YM670
	W4222	A-K			9	27-41-12	YC008-YM670
	W6222	0502	20		9	27-41-12	YC001-YC007
	W6222	A-K			9	27-41-12	YC001-YC007
SP00161		E003-01/ /					YC008-YM670
	W0311	2029Z			W	31-62-15	YC008-YC030, YK901-YM670
	W0311	2171Z			W	31-62-15	YC008-YC030, YK901-YM670
	W0313	2669Z			W	31-62-15	YC008-YC030, YK901-YM670
SP00162		//					ALL
SP00164		259/ /					ALL
SP00165		258/194/L008					YK901-YM670
	W2413	0040	18		S	23-12-11	YK901-YM670
	W2651	0015	16		S	23-12-11	YK901-YM670
	W2651	0026	16		S	23-12-11	YK901-YM670
SP00166		//					ALL
SP00167		269.8/199/R040					YK901-YM670
	W2383	0016	16		9	23-12-21	YK901-YM670
	W2383	0036	16		9	23-12-21	YK901-YM670
	W2415	0040	18		9	23-12-21	YK901-YM670
SP00168		//					ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00170		727+2/199/R049					YC012-YM670
	W5124	0517	20		S	27-41-12	YC012-YM670
	W5224	0523	20		S	27-41-12	YC012-YM670
SP00172		IRSS/219/					ALL
I	W7230	6002	18		9	28-42-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I	W7230	6003	20		9	28-42-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I	W7230	A-AA			9	28-42-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00174		IRSS/219/					ALL
I	W7230	6001	20		9	28-42-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I	W7230	B-BB			9	28-42-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00178		//					ALL
SP00180		//					ALL
SP00182		//					ALL
SP00184		//					ALL
SP00188		220/210/R039					ALL
SP00190		//					ALL
SP00192		//					ALL
SP00194		//					ALL



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00200		990/181/L018					ALL
SP00202		500I+17/171/L049					YC001-YL430
SP00202		500D+7/170/L049					YM643-YM670
	W5164	1301	20		S	28-21-11	ALL
	W5164	1301Z				28-21-11	ALL
	W5230	6011	18		S	28-21-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00204		* / /					ALL
SP00206		749/297/L023					ALL
SP00210		990/181/L018					ALL
	W6248	5501	20		9	30-71-11	ALL
	W6248	E-B			9	30-71-11	ALL
SP00212		990/181/L018					ALL
	W6248	5514	20		9	30-71-11	ALL
	W6248	E-C			9	30-71-11	ALL
SP00214		395/188/R010					ALL
SP00216		/ /					ALL
SP00218		/ /					ALL
SP00220		/ /					ALL
SP00222		/ /					ALL
SP00224		/ /					ALL
SP00226		858/170/L032					ALL
	W6248	5544	20		9	30-71-11	ALL
	W6248	F-A			9	30-71-11	ALL
SP00228		858/170/L032					ALL
	W6248	5545	20		9	30-71-11	ALL
	W6248	F-B			9	30-71-11	ALL

SPLICE LIST
D280A103

91-21-31
Section SP00200
Page 1
Aug 10/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00230		915/168/R002					ALL
	W6248	5546	20		9	30-71-11	ALL
	W6248	G-A			9	30-71-11	ALL
SP00232		915/168/R002					ALL
	W6248	5547	20		9	30-71-11	ALL
	W6248	G-B			9	30-71-11	ALL
SP00238		959/178/R008					ALL
	W6248	5552	20		9	30-71-11	ALL
	W6248	H-A			9	30-71-11	ALL
SP00240		959/178/R008					ALL
	W6248	5551	20		9	30-71-11	ALL
	W6248	H-B			9	30-71-11	ALL
SP00242		959/178/R008					ALL
	W6248	5564	20		9	30-71-11	ALL
	W6248	I-A			9	30-71-11	ALL
SP00244		959/178/R008					ALL
	W6248	5565	20		9	30-71-11	ALL
	W6248	I-B			9	30-71-11	ALL
SP00251		225/220/R042					ALL
SP00252		891/176/R037					YC001-YC026, YK901-YM670
	W5726	0538	22		S	49-62-11	YC001-YC026, YM643-YM652
	W5728	0504	20		S	49-62-11	YC001-YC026, YM643-YM670
SP00253		225/220/R042					ALL
SP00254		891/176/R037					YC001-YC026, YK901-YM670
	W5726	0540	22		S	49-62-11	YC001-YC026, YM643-YM652
	W5728	0502	20		S	49-62-11	YC001-YC026, YM643-YM670
SP00255		225/220/R042					ALL
SP00256		891/176/R037					YC001-YC026, YK901-YM670
	W5726	0542	22		S	49-62-11	YC001-YC026, YM643-YM652



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00256		891/176/R037 (continued)					YC001-YC026, YK901-YM670
	W5728	0501	20		S	49-62-11	YC001-YC026, YM643-YM670
SP00258		891/176/R037					YC001-YC026, YK901-YM670
	W5726	0544	22		S	49-62-11	YC001-YC026, YM643-YM652
	W5728	0503	20		S	49-62-11	YC001-YC026, YM643-YM670
SP00260		599/220/L070					YC001-YL430
	W3142	5545	20		9	21-42-11	YC001-YC030, YK901-YL430
	W3142	E-B			9	21-42-11	YC001-YC030, YK901-YL430
SP00262		//					ALL
SP00264		//					ALL
SP00266		//					ALL
SP00268		//					ALL
SP00270		599/220/L070					YC001-YL430
	W3142	5544	20		9	21-42-11	YC001-YC030, YK901-YL430
	W3142	E-A			9	21-42-11	YC001-YC030, YK901-YL430
SP00272		233/265/L025					YC028-YM670
	W2102	5528	20		S	33-17-11	YC028-YM670
	W2102	5530	20		S	33-17-11	YC028-YM670
	W2102	B-BG			S	33-17-11	YC028-YM670
SP00280		OFSS380/ /					ALL
	W1664	1035	20		9	28-44-11	ALL
	W1664	A-D			9	28-44-11	ALL
SP00286		*/ /					YC001-YC003
	W2218	5581	24		S	30-41-12	YC001-YC003
	W5506	0010	24		S	30-41-12	YC001-YC003
SP00288		*/ /					YC001-YC003
	W2112	5582	24		S	30-41-12	YC001-YC003
	W5510	0017	24		S	30-41-12	YC001-YC003

SPLICE LIST
D280A103

91-21-31
Section SP00200
Page 3 End
Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00300		237/208/L036					ALL
	W2030	1001	18		S	33-11-31	ALL
	W2030	1001Z				33-11-31	ALL
	W2363	1062	20		S	33-11-31	ALL
	W2363	1062Z				33-11-31	ALL
SP00302		265/280/L01					ALL
	W2114	0025	20		S	33-51-12	YC001-YC007
	W2114	A-AP			S	33-51-12	YC001-YC007
SP00304		269/273/L014					YM643-YM670
SP00318		500I+17/153/R009					YC001-YL430
SP00318		500D+17/153/R009					YM643-YM670
	W6128	6011	18		S	28-21-11	ALL
	W6164	1301	20		S	28-21-11	ALL
	W6164	1301Z				28-21-11	ALL
SP00321		240/197/L000					YC028-YM670
	W2265	0007	20		9	33-18-62	YC028-YM670
	W2265	0008	20		9	33-18-62	YC028-YM670
	W2403	0023	20		9	33-18-62	YC028-YC030
	W2413	0035	20		9	33-18-62	YK901-YM670
SP00326		668/167/L025					ALL
I	W5230	6011	18		9	28-21-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
I	W7230	6011	18		9	28-21-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00332		698/191/L062					ALL
	W7126	2222R	20		9	32-64-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W7126	A-R			9	32-64-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00334		698/191/L062					ALL
	W7126	2222B	20		9	32-64-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W7126	A-B			9	32-64-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00336		//					ALL
SP00342		692/192/L062					ALL
I	W7230	2222R	20		9	32-64-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652

SPLICE LIST

D280A103

91-21-31

Section SP00300

Page 1

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00342		692/192/L062 (continued)					ALL
	W7230	A-R			9	32-64-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00344		692/194/L061					ALL
	W7230	2222B	20		9	32-64-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W7230	A-B			9	32-64-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00346		//					ALL
SP00352		698/196/R061					ALL
	W8224	2224R	20		9	32-64-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W8224	A-R			9	32-64-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00354		698/196/R061					ALL
	W8224	2224B	20		9	32-64-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W8224	A-B			9	32-64-12	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00356		//					ALL
SP00358		727+2/195/L042					ALL
	W5032	6001	20		S	28-21-11	ALL
	W5530	6011	20		S	28-21-11	ALL
SP00361		250/267/R030					ALL
SP00362		692/196/R061					ALL
	W8228	2214R	20		9	32-64-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W8228	A-R			9	32-64-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00363		250/267/R030					ALL
SP00364		692/196/R061					ALL
	W8228	2214B	20		9	32-64-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W8228	A-B			9	32-64-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00365		250/267/R030					ALL
SP00366		//					ALL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00368		727+2/199/R049					YC012-YM670
	W5124	0524	20		S	27-41-12	YC012-YM670
	W5224	0519	20		S	27-41-12	YC012-YM670
SP00370		727+5/198/R050					YC012-YM670
	W5124	0525	20		S	27-41-12	YC012-YM670
	W5224	0520	20		S	27-41-12	YC012-YM670
SP00372		727+2/199/R049					YC012-YM670
	W5124	0518	18		S	27-41-12	YC012-YM670
	W5224	0525	18		S	27-41-12	YC012-YM670
SP00373		//					YC012-YM670
SP00374		727+2/199/R049					YC012-YM670
	W5124	0519	20		S	27-41-12	YC012-YM670
	W5224	0524	20		S	27-41-12	YC012-YM670
SP00376		727+2/199/R049					YC012-YM670
	W5124	0521	20		S	27-41-12	YC012-YM670
	W5224	0517	20		S	27-41-12	YC012-YM670
SP00390		208/200/R013					ALL
	W6110	0003	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	0004	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	A-C			S	33-34-11	YC001-YC030, YK901-YM670
SP00392		222/204/R011					ALL
	W6110	0004	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	A-B			S	33-34-11	YC001-YC030, YK901-YM670
SP00394		223/206/L005					ALL
	W6110	0002	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	0003	20		S	33-34-11	YC001-YC030, YK901-YM670
	W6110	A-A			S	33-34-11	YC001-YC030, YK901-YM670

SPLICE LIST

D280A103

91-21-31

Section SP00300

Page 3 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00411		250/267/R030					ALL
SP00412		937/317/L013					ALL
	W3142	0412	20		S	33-51-22	YC001-YC030, YM643-YM652
	W3142	0414	20		S	33-51-22	YK901-YL430
	W3142	0442	20		S	33-51-22	YC001-YC030, YM643-YM652
	W3144	0310	20		S	33-51-22	ALL
SP00413		250/267/R030					ALL
SP00418		533/163/R001					ALL
	W5526	0520	20		9	33-33-11	YC001-YC030, YK901-YM670
	W6230	0522	20		9	33-33-11	ALL
SP00420		533/163/R001					ALL
	W5526	0521	20		9	33-33-11	YC001-YC030, YK901-YM670
	W6230	0521	20		9	33-33-11	ALL
SP00421		OFSS 381/ /					ALL
	W1664	3002R	20		9	23-41-11	ALL
	W1664	3002ZI				23-41-11	ALL
	W1664	A-V			9	23-41-11	ALL
SP00423		OFSS 381/ /					ALL
	W1664	3002Y	20		9	23-41-11	ALL
	W1664	A-W			9	23-41-11	ALL
SP00425		OFSS 381/ /					ALL
	W1664	3002B	20		9	23-41-11	ALL
	W1664	A-U			9	23-41-11	ALL
SP00426		663/165/R008					ALL
	W6128	6011	18		9	28-21-11	ALL
	W8222	6011	18		9	28-21-11	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00436		252/237/L048					ALL
	W2102	5503	18		S	33-14-12	ALL
	W2102	5527	18		S	33-14-12	ALL
	W2102	J-JP			S	33-14-12	ALL

SPLICE LIST
D280A103

91-21-31
Section SP00400
Page 1
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00438		251/238/R048					ALL
	W2204	5502	18		S	33-14-12	ALL
	W2204	5504	18		S	33-14-12	ALL
	W2204	5506	18		S	33-14-12	ALL
	W2204	D-DP			S	33-14-12	ALL
SP00452		//					ALL
SP00458		729/198/R050					ALL
	W6028	6001	20		S	28-21-11	ALL
	W6122	6011	20		S	28-21-11	ALL
SP00460		//					ALL
SP00462		//					ALL
SP00464		//					ALL
SP00465		240/198/L001					YK907-YM670
	W3319	0054	24		9	31-62-42	YK907-YM670
	W3709	0003	24		9	31-62-42	YK907-YM670
SP00469		255.9/194/L9.2					YC001-YC030
SP00471		//					YC001-YC030
SP00472		371/294/R023					ALL
	W6122	0508	20		S	29-31-11	ALL
	W6412	0514	20		S	29-31-11	ALL
SP00474		371/294/R023					ALL
	W6122	0509	20		S	29-31-11	ALL
	W6412	0510	20		S	29-31-11	ALL
SP00476		371/294/R023					ALL
	W6122	0510	20		S	29-31-11	ALL
	W6412	0509	20		S	29-31-11	ALL
SP00478		371/294/R023					ALL
	W6122	0513	20		S	29-23-11	ALL

SPLICE LIST
D280A103

91-21-31
Section SP00400
Page 2
Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00478		371/294/R023 (continued)					ALL
	W6412	0515	22		S	29-23-11	ALL
SP00479		408/199/L35					ALL
SP00480		256/194/L9					ALL
SP00481		408/199/L35					ALL
SP00482		//					ALL
SP00484		256/194/L9					ALL
SP00486		IFSS 149/ /					ALL
	W1280	2003B	20		9	27-81-21	ALL
	W1280	K-B			9	27-81-21	ALL
SP00488		IFSS 149/ /					ALL
	W1280	2004B	20		9	27-81-21	ALL
	W1280	L-B			9	27-81-21	ALL
SP00490		IFSS 168/ /					ALL
	W1280	2002B	20		9	27-81-21	ALL
	W1280	J-B			9	27-81-21	ALL
SP00492		IFSS 165/ /					ALL
	W1280	2001B	20		9	27-81-21	ALL
	W1280	I-B			9	27-81-21	ALL
SP00496		749/297/L023					ALL
SP00498		727A+2.0/297/L023					ALL

SPLICE LIST
D280A103

91-21-31
Section SP00400
Page 3 End
Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00501		E003-01 / /					YC001-YC050
	W0311	0165	22		W	34-41-11	YC003-YC006
	W0313	0661	22		W	34-41-11	YC003-YC006
	W0313	0663	22		W	34-41-11	YC003-YC006
	W0313	0669	22		W	34-41-11	YC003-YC006
SP00502		727A+2.0/297/L023					YC008-YM670
	W3381	0020	20		S	22-13-11	YC008-YM670
	W6134	0547	18		S	27-31-11	YC008-YM670
	W6134	0548	18		S	27-31-11	YC008-YM670
SP00503		727+17/202/L053					YC008-YM670
	W5124	0508	20		S	27-31-11	YC008-YM670
	W6124	0527	20		S	27-31-11	YC008-YM670
SP00504		727A+2.0/297/L023					ALL
	W5224	0521	20		S	29-23-11	ALL
	W6134	0517	20		S	29-23-11	ALL
SP00505		727+17/202/L053					YC008-YM670
	W5124	0509	20		S	27-31-11	YC008-YM670
	W6124	0528	20		S	27-31-11	YC008-YM670
SP00506		1087/266/L014					ALL
	W3381	0017	20		9	22-13-11	YC001-YC007
	W6134	0531	18		9	27-31-11	YC001-YC007
	W6134	0532	18		9	27-31-11	YC001-YC007
SP00507		E003-01 / /					YC001-YC002, YC007-YM670
	W0311	2116R	24		W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670
	W0311	2169R	24		W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670
	W0313	2677R	24		W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670
SP00508		E003-01 / /					YC007-YM670
	W0311	2116B	24		W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670
	W0311	2169B	24		W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670
	W0313	2677B	24		W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670
SP00509		E003-01 / /					YC001-YC002, YC007-YM670
	W0311	2116Z			W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00509		E003-01/ / (continued)					YC001-YC002, YC007-YM670
	W0311	2169Z			W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670
	W0313	2677Z			W	34-21-13	YC001-YC002, YC007-YC030, YK901-YM670
SP00518		IFSS-168/ /					ALL
	W1180	2002B	20		9	27-81-11	ALL
	W1180	J-B			9	27-81-11	ALL
SP00520		IFSS-164/ /					ALL
	W1180	2001B	20		9	27-81-11	ALL
	W1180	I-B			9	27-81-11	ALL
SP00522		IFSS-149/ /					ALL
	W1180	2003B	20		9	27-81-11	ALL
	W1180	K-B			9	27-81-11	ALL
SP00524		IFSS-149/ /					ALL
	W1180	2004B	20		9	27-81-11	ALL
	W1180	L-B			9	27-81-11	ALL
SP00530		532/151/R027					ALL
	W6202	1018	20		9	30-71-11	ALL
	W6202	A-AA			9	30-71-11	ALL
SP00532		532/151/R027					ALL
SP00533		347/271/L053					YK907-YM670
	W3058	0027	24		9	52-71-11	YK907-YM670
	W3058	0028	24		9	52-71-11	YK907-YM670
	W3058	A-2			9	52-71-11	YK907-YM670
SP00535		347/271/L053					YK907-YM670
	W3058	0028	24		9	52-71-11	YK907-YM670
	W3058	A-5			9	52-71-11	YK907-YM670
SP00536		727+17*/202/L053					ALL
	W5124	0511	24		S	27-31-37	ALL
	W6124	0562	24		S	27-31-37	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00537		347/271/L053					YK907-YM670
	W3058	0029	22		9	52-71-11	YK907-YM670
	W3058	A-1			9	52-71-11	YK907-YM670
	W3058	A-4			9	52-71-11	YK907-YM670
SP00538		727+17*/202/L053					ALL
	W5124	0512	20		S	27-31-37	ALL
	W6124	0563	20		S	27-31-37	ALL
SP00539		232/271/0					YK907-YM670
SP00540		727+17*/202/L053					ALL
	W5124	0514	24		S	27-31-37	ALL
	W6124	0564	24		S	27-31-37	ALL
SP00542		727+17*/202/L053					ALL
	W5124	0516	20		S	27-31-37	YC001-YC007, YM643-YM670
	W5124	0516	22		S	27-31-37	YC008-YL430
	W6124	0506	20		S	27-31-11	ALL
	W6124	0565	20		S	27-31-11	ALL
SP00544		727A+11/297/L023					YC001-YL430
	W3142	0232	12		S	33-51-14	YC001-YC030, YK901-YL430
	W4142	0092	12		S	33-51-14	YC001-YL430
SP00545		331/289/L020					YK907-YM670
	W3701	0004	22		W	23-70-11	YK907-YM670
	W3702	0004	22		W	23-70-11	YK907-YM670
	W3703	0004	22		W	23-70-11	YK907-YM670
	W3703	0006	22		W	23-70-11	YK907-YM670
SP00546		583/297/R024					YC001-YL430
	W3142	0341	14		S	33-51-13	YC001-YC030
	W4142	0331	14		S	33-51-13	YC001-YC050
	W4142	0332	14		S	33-51-13	YC001-YC050
SP00547		331/289/L020					YK907-YM670
	W3701	0005	22		W	23-70-11	YK907-YM670
	W3702	0005	22		W	23-70-11	YK907-YM670
	W3703	0005	22		W	23-70-11	YK907-YM670



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00547		331/289/L020 (continued)					YK907-YM670
	W3703	0007	22		W	23-70-11	YK907-YM670
SP00549		301/291/L001					YK907-YM670
	W3801	0004	22		W	23-70-11	YK907-YM670
	W3801	A-AA			W	23-70-11	YK907-YM670
SP00551		301/291/L001					YK907-YM670
	W3801	0005	22		W	23-70-11	YK907-YM670
	W3801	A-AB			W	23-70-11	YK907-YM670
SP00553		320/293/L015					YK907-YM670
	W3802	0004	22		W	23-70-11	YK907-YM670
	W3802	B-BA			W	23-70-11	YK907-YM670
SP00554		IFSS 149/ /					ALL
	W1280	2003R	20		9	27-81-21	ALL
	W1280	K-R			9	27-81-21	ALL
SP00555		320/293/L015					YK907-YM670
	W3802	0005	22		W	23-70-11	YK907-YM670
	W3802	B-BB			W	23-70-11	YK907-YM670
SP00556		IFSS 149/ /					ALL
	W1280	2004R	20		9	27-81-21	ALL
	W1280	L-R			9	27-81-21	ALL
SP00557		303/288/R016					YK907-YM670
	W3803	0004	22		W	23-70-11	YK907-YM670
	W3803	C-CA			W	23-70-11	YK907-YM670
SP00558		IFSS 168/ /					ALL
	W1280	2002R	20		9	27-81-21	ALL
	W1280	J-R			9	27-81-21	ALL
SP00559		303/288/R016					YK907-YM670
	W3803	0005	22		W	23-70-11	YK907-YM670
	W3803	C-CB			W	23-70-11	YK907-YM670

SPLICE LIST
D280A103

91-21-31
Section SP00500
Page 4
Feb 09/2009

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00560		IFSS 165/ /					ALL
	W1280	2001R	20		9	27-81-21	ALL
	W1280	I-R			9	27-81-21	ALL
SP00570		532/151/R027					ALL
	W6202	A-AB			9	30-71-11	ALL
	W6202	A-AC			9	30-71-11	ALL
SP00572		532/151/R027					ALL
	W6202	5557	20		9	30-71-11	ALL
	W6202	A-AD			9	30-71-11	ALL
SP00586		IFSS-168/ /					ALL
	W1180	2002R	20		9	27-81-11	ALL
	W1180	J-R			9	27-81-11	ALL
SP00588		IFSS-164/ /					ALL
	W1180	2001R	20		9	27-81-11	ALL
	W1180	I-R			9	27-81-11	ALL
SP00590		IFSS-149/ /					ALL
	W1180	2003R	20		9	27-81-11	ALL
	W1180	K-R			9	27-81-11	ALL
SP00592		IFSS-149/ /					ALL
	W1180	2004R	20		9	27-81-11	ALL
	W1180	L-R			9	27-81-11	ALL

SPLICE LIST

D280A103

91-21-31

Section SP00500

Page 5 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00606		228/270/L020					YC001-YC026
SP00606		233/265/L025					YC028-YM670
	W2102	5505	20		S	33-17-11	ALL
	W2102	B-BP			S	33-17-11	ALL
SP00608		227/268/R019					ALL
	W2204	5517	20		S	33-17-11	ALL
	W2204	B-BP			S	33-17-11	ALL
SP00634		727+17/202/L053					ALL
	W5124	0569	18		S	29-25-11	ALL
	W6124	0576	20		S	27-53-11	ALL
	W6124	0577	20		S	27-53-11	ALL
SP00642		727A+11/297/L023					YC001-YL430
	W3142	0074	20		S	33-51-22	YC001-YC030
	W3142	0245	16		S	33-51-22	YK901-YL430
	W4142	0210	20		S	33-51-22	YC001-YC050
	W4142	0230	16		S	33-51-22	YK901-YL430
SP00656		239/197/L01					ALL
	W5170	6011	20		S	28-21-11	ALL
	W5506	6029	20		S	28-21-11	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W5506	6030	20		S	28-21-11	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W5506	6082	20		S	28-21-11	YC001-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00665		220/207/L045					ALL
SP00667		220/208/L045					ALL
SP00681		220/208/L045					ALL
SP00683		220/208/L045					ALL
SP00685		240/260/L040					ALL

SPLICE LIST
D280A103

91-21-31
Section SP00600
Page 1 End
Aug 10/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00702		636/220/L070					ALL
	W3142	5513	20		9	21-42-11	YM643-YM652
	W3142	5573	20		9	21-42-11	YC001-YC030, YK901-YL430
	W3142	C-A			9	21-42-11	YC001-YC030, YK901-YM652
SP00704		636/220/L070					ALL
	W3142	5514	20		9	21-42-11	YM643-YM652
	W3142	5574	20		9	21-42-11	YC001-YC030, YK901-YL430
	W3142	C-B			9	21-42-11	YC001-YC030, YK901-YM652
SP00706		TBD / /					ALL
SP00708		599/220/R070					YC001-YL430
	W4142	5544	20		9	21-42-11	YC001-YL430
	W4142	J-A			9	21-42-11	YC001-YL430
SP00710		599/220/R070					YC001-YL430
	W4142	5545	20		9	21-42-11	YC001-YL430
	W4142	J-B			9	21-42-11	YC001-YL430
SP00724		637/220/R070					ALL
	W4142	5513	20		9	21-42-11	ALL
	W4142	C-A			9	21-42-11	ALL
SP00726		637/220/R070					ALL
	W4142	5514	20		9	21-42-11	ALL
	W4142	C-B			9	21-42-11	ALL
SP00728		//					ALL
SP00730		//					ALL

SPLICE LIST

D280A103

91-21-31

Section SP00700

Page 1 End

May 11/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00802		639/257/L067					ALL
	W3142	0418	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	0462	20		9	52-71-13	YM643-YM652
	W3142	F-A			9	52-71-13	YC001-YC030, YK901-YM652
SP00804		635/258/L067					ALL
	W3142	0463	20		9	52-71-13	YC001-YC030, YK901-YM652
	W3142	F-B			9	52-71-13	YC001-YC030, YK901-YM652
SP00806		634/259/L068					ALL
	W3142	0464	20		9	52-71-13	YC001-YC030, YK901-YM652
	W3142	H-A			9	52-71-13	YC001-YC030, YK901-YM652
SP00808		634/259/L068					ALL
	W3142	0465	20		9	52-71-13	YC001-YC030, YK901-YM652
	W3142	H-B			9	52-71-13	YC001-YC030, YK901-YM652
SP00810		616/257/L067					ALL
	W3142	0466	20		9	52-71-13	YC001-YC030, YK901-YM652
	W3142	I-A			9	52-71-13	YC001-YC030, YK901-YM652
SP00812		616/257/L067					ALL
	W3142	0467	20		9	52-71-13	YC001-YC030, YK901-YM652
	W3142	I-B			9	52-71-13	YC001-YC030, YK901-YM652
SP00814		639/257/L067					ALL
	W3142	0460	20		9	52-71-13	YC001-YC030, YK901-YM652
	W3142	G-A			9	52-71-13	YC001-YC030, YK901-YM652
SP00816		639/257/L067					ALL
	W3142	0461	20		9	52-71-13	YC001-YC030, YK901-YM652
	W3142	G-B			9	52-71-13	YC001-YC030, YK901-YM652
SP00818		595/256/L068					YC001-YL430
	W3142	0419	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	N-A			9	52-71-13	YC001-YC030, YK901-YL430
SP00820		595/256/L068					YC001-YL430
	W3142	0420	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	N-B			9	52-71-13	YC001-YC030, YK901-YL430

SPLICE LIST
D280A103

91-21-31
Section SP00800
Page 1
May 11/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00822		595/256/L068					YC001-YL430
	W3142	0434	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	R-A			9	52-71-13	YC001-YC030, YK901-YL430
SP00824		595/256/L068					YC001-YL430
	W3142	0435	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	R-B			9	52-71-13	YC001-YC030, YK901-YL430
SP00826		575/258/L067					YC001-YL430
	W3142	0436	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	P-A			9	52-71-13	YC001-YC030, YK901-YL430
SP00828		575/258/L067					YC001-YL430
	W3142	0437	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	P-B			9	52-71-13	YC001-YC030, YK901-YL430
SP00830		604/258/L067					YC001-YL430
	W3142	0438	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	Q-A			9	52-71-13	YC001-YC030, YK901-YL430
SP00832		604/258/L067					YC001-YL430
	W3142	0439	20		9	52-71-13	YC001-YC030, YK901-YL430
	W3142	Q-B			9	52-71-13	YC001-YC030, YK901-YL430
SP00852		256/194/L8					YC001-YC003
	W2508	5671	24		S	21-43-21	YC001-YC003
	W5510	5510	24		S	21-43-21	YC001-YC003
SP00854		256/194/L8					YC001-YC003
	W2508	5672	24		S	21-43-21	YC001-YC003
	W5510	5511	24		S	21-43-21	YC001-YC003
SP00888		OFSS 126/ /					ALL
	W1664	1019	20		9	28-44-11	ALL
	W1664	B-B			9	28-44-11	ALL
SP00894		P008-00/ /					YC001-YC007
	W2110	6030	20		9	33-18-64	YC001-YC007
	W5514	5576	20		9	33-18-62	YC001-YC007
	W5514	5589	20		9	33-18-62	YC001-YC007



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00928		OFSS 375/ /					ALL
	W1664	1012	20		9	28-44-11	ALL
	W1664	1013	18		9	28-44-11	ALL
	W1664	A-B			9	28-44-11	ALL
	W1664	A-C			9	28-44-11	ALL
SP00968		257/194/L008					YC004-YM670
	W5160	6023	20		S	78-34-21	YC004-YC030, YK901-YM670
	W5160	6026	20		S	78-34-21	YC004-YC030, YK901-YM670
	W6506	6015	20		S	78-34-21	YC004-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W6510	6031	20		S	78-34-21	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP00998		OFSS 126/ /					ALL
	W1664	1026	20		9	28-44-11	ALL
	W1664	B-A			9	28-44-11	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01062		907/198/R054					YC028-YM670
	W5726	0538	22		S	49-62-11	YC028-YK912, YK918-YK919, YL401-YL429
	W5728	0506	20		S	49-62-11	YC028-YL430
SP01064		907/198/R054					YC028-YM670
	W5726	0540	22		S	49-62-11	YC028-YK912, YK918-YK919, YL401-YL429
	W5728	0507	20		S	49-62-11	YC028-YL430
SP01066		907/198/R054					YC028-YM670
	W5726	0542	22		S	49-62-11	YC028-YK912, YK918-YK919, YL401-YL429
	W5728	0508	20		S	49-62-11	YC028-YL430
SP01068		907/198/R054					YC028-YM670
	W5726	0544	22		S	49-62-11	YC028-YK912, YK918-YK919, YL401-YL429
	W5728	0509	20		S	49-62-11	YC028-YL430
SP01080		266/204/L047					ALL
	W2653	0014	10		9	30-42-11	YC020-YM670
	W5506	0019	10		9	30-42-11	YC020-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP01082		235/208/R038					ALL
	W2208	5504	10		9	30-42-11	YC020-YM670
	W5506	0019	10		9	30-42-11	YC020-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP01084		268/204/L048					ALL
	W2108	5504	10		9	30-42-11	YC020-YM670
	W2175	0026	10		9	30-42-11	YC020-YM670



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01118		305/266/L050					ALL
	W5110	2419R	20		9	52-71-11	YC001-YC030, YK901-YM670
	W5110	A-A			9	52-71-11	YC001-YC030, YK901-YM670
SP01120		305/266/L050					ALL
	W5110	0101	20		9	52-71-11	YC001-YC030, YK901-YM670
	W5110	A-C			9	52-71-11	YC001-YC030, YK901-YM670
SP01122		305/266/L050					ALL
	W5110	2419B	20		9	52-71-11	YC001-YC030, YK901-YM670
	W5110	A-B			9	52-71-11	YC001-YC030, YK901-YM670
SP01124		993/265/L055					ALL
	W6248	2409R	20		9	52-71-11	ALL
	W6248	B-A			9	52-71-11	ALL
SP01126		993/265/L055					ALL
	W6248	0102	20		9	52-71-11	ALL
	W6248	B-C			9	52-71-11	ALL
SP01128		993/265/L055					ALL
	W6248	2409B	20		9	52-71-11	ALL
	W6248	B-B			9	52-71-11	ALL
SP01144		997/261/R056					ALL
	W6248	2444R	20		9	52-71-11	ALL
	W6248	D-A			9	52-71-11	ALL
SP01146		997/261/R056					ALL
	W6248	0104	20		9	52-71-11	ALL
	W6248	D-C			9	52-71-11	ALL
SP01148		997/261/R056					ALL
	W6248	2444B	20		9	52-71-11	ALL
	W6248	D-B			9	52-71-11	ALL
SP01158		332/267/R055					ALL
	W6412	2401R	20		9	52-71-11	ALL
	W6412	C-A			9	52-71-11	ALL

SPLICE LIST
D280A103

91-21-31
Section SP01100
Page 1
Feb 09/2009

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01160		332/267/R055					ALL
	W6412	0005	20		9	52-71-11	ALL
	W6412	C-C			9	52-71-11	ALL
SP01162		332/267/R055					ALL
	W6412	2401B	20		9	52-71-11	ALL
	W6412	C-B			9	52-71-11	ALL



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01246		785/167/R044					YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
	W6248	0046	20		S	52-71-12	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
	W6248	A-A			S	52-71-12	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
SP01248		785/168/R044					YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
	W6248	0146	20		S	52-71-12	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
	W6248	A-B			S	52-71-12	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
SP01256		436/164/R041					YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
	W5248	0056	20		S	52-71-12	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
	W5248	A-A			S	52-71-12	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
SP01258		436/164/R041					YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
	W5248	0156	20		S	52-71-12	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670
	W5248	A-B			S	52-71-12	YK912-YK917, YK919-YL401, YL427-YL430, YM652-YM670

SPLICE LIST

D280A103

91-21-31

Section SP01200

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01502		257/194/L007					YC004-YM670
	W5160	0701	22		S	32-42-11	YC004-YC030, YK901-YM670
	W5160	0702	22		S	32-42-11	YC004-YC030, YK901-YM670
	W5506	0511	24		S	32-42-11	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP01504		257/194/L007					YC004-YM670
	W5160	0704	22		S	32-42-11	YC004-YC030, YK901-YM670
	W5160	0705	22		S	32-42-11	YC004-YC030, YK901-YM670
	W5506	0513	24		S	32-42-11	YC004-YC030, YK901-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP01523		1206/336/R002					YK907-YM670
	W7057	0018	22		9	23-11-11	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W7061	0018	22		9	23-11-11	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP01525		1206/336/R002					YK907-YM670
	W7057	0017	22		9	23-11-11	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652
	W7061	0017	22		9	23-11-11	YK907-YK912, YK918-YK919, YL401-YL429, YM643-YM652

SPLICE LIST

D280A103

91-21-31

Section SP01500

Page 1 End

Aug 10/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL	GA	CO	Type	Diagram	Effectivity
		Wire No.					
SP01732		OFSS 589/ /					ALL
	W1664	1024	20		9	28-44-11	ALL
	W1664	A-J			9	28-44-11	ALL
SP01734		OFSS 589/ /					ALL
	W1664	1018	20		9	28-44-11	ALL
	W1664	A-K			9	28-44-11	ALL

SPLICE LIST

D280A103

91-21-31

Section SP01700

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01802		625/257/R067					ALL
	W4142	0438	20		9	52-71-14	YC001-YL430
	W4142	0462	20		9	52-71-14	YM643-YM670
	W4142	F-A			9	52-71-14	ALL
SP01804		625/257/R067					ALL
	W4142	0463	20		9	52-71-14	ALL
	W4142	F-B			9	52-71-14	ALL
SP01806		622/261/R066					ALL
	W4142	0464	20		9	52-71-14	ALL
	W4142	H-A			9	52-71-14	ALL
SP01808		640/257/R067					ALL
	W4142	0465	20		9	52-71-14	ALL
	W4142	H-B			9	52-71-14	ALL
SP01810		616/257/R067					ALL
	W4142	0466	20		9	52-71-14	ALL
	W4142	I-A			9	52-71-14	ALL
SP01812		616/257/R067					ALL
	W4142	0467	20		9	52-71-14	ALL
	W4142	I-B			9	52-71-14	ALL
SP01814		640/259/R067					ALL
	W4142	0460	20		9	52-71-14	ALL
	W4142	G-A			9	52-71-14	ALL
SP01816		643/257/R067					ALL
	W4142	0461	20		9	52-71-14	ALL
	W4142	G-B			9	52-71-14	ALL
SP01818		583/256/R068					YC001-YL430
	W4142	0436	20		9	52-71-14	YC001-YL430
	W4142	N-A			9	52-71-14	YC001-YL430
SP01820		587/254/R068					YC001-YL430
	W4142	0435	20		9	52-71-14	YC001-YL430
	W4142	N-B			9	52-71-14	YC001-YL430

SPLICE LIST
D280A103

91-21-31
Section SP01800
Page 1
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01822		583/256/R068					YC001-YL430
	W4142	0437	20		9	52-71-14	YC001-YL430
	W4142	R-A			9	52-71-14	YC001-YL430
SP01824		583/256/R068					YC001-YL430
	W4142	0439	20		9	52-71-14	YC001-YL430
	W4142	R-B			9	52-71-14	YC001-YL430
SP01826		578/259/R067					YC001-YL430
	W4142	0440	20		9	52-71-14	YC001-YL430
	W4142	P-A			9	52-71-14	YC001-YL430
SP01828		578/259/R067					YC001-YL430
	W4142	0441	20		9	52-71-14	YC001-YL430
	W4142	P-B			9	52-71-14	YC001-YL430
SP01830		601/259/R067					YC001-YL430
	W4142	0442	20		9	52-71-14	YC001-YL430
	W4142	Q-A			9	52-71-14	YC001-YL430
SP01832		601/259/R067					YC001-YL430
	W4142	0443	20		9	52-71-14	YC001-YL430
	W4142	Q-B			9	52-71-14	YC001-YL430

SPLICE LIST
D280A103

91-21-31
Section SP01800
Page 2 End
Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01948		OFSS-712/ /					ALL
	W1188	2005R	20		9	27-81-12	ALL
	W1188	A-R			9	27-81-12	ALL

SPLICE LIST
D280A103

91-21-31
Section SP01900
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02002		368/176/L048					ALL
	W5030	5506	20		S	21-27-31	ALL
	W5122	5501	22		S	21-27-31	ALL
SP02004		371/174/R043					ALL
	W6242	5509	24		S	21-27-31	ALL
	W6430	5506	20		S	21-27-31	ALL
SP02085		237/208/L036					ALL
	W2205	0014	20		S	34-21-11	YC001-YC030
	W2205	0014	20		S	SPARE	YK901-YM670
	W2651	0010	20		S	34-21-11	YC001-YC030
	W2651	0010	20		S	SPARE	YK901-YM670

SPLICE LIST

D280A103

91-21-31

Section SP02000

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02135		237/208/L036					ALL
	W2363	1064	22		S	22-14-11	ALL
	W2363	1064Z				22-14-11	ALL
	W5514	1001	22		S	22-14-11	YC001-YC030, YK901-YM670
	W5514	1001Z				22-14-11	YC001-YC030, YK901-YM670
SP02138		237/208/L036					ALL
	W2030	5505	16		S	33-11-11	ALL
	W2102	5509	20		S	33-11-11	ALL
SP02140		236/210/R038					ALL
	W2204	5512	20		S	33-11-21	ALL
	W2383	0033	16		S	33-11-21	YC001-YC030, YK901-YM670
SP02185		237/208/L036					ALL
	W2205	0054	22		S	34-22-11	YC001-YC030, YK901-YM670
	W2651	0008	22		S	34-22-11	YC001-YC030, YK901-YM670
SP02186		237/208/L036					ALL
	W2205	0007	22		S	34-24-11	YC001-YC030
	W2205	0007	22		S	SPARE	YK901-YM670
	W2651	0009	22		S	34-24-11	YC001-YC030, YL401-YL430
	W2651	0009	22		S	SPARE	YK901-YK920, YM643-YM670
SP02195		237/208/R036					YK901-YM670
	W2205	0038	22		S	34-24-15	YK901-YK910, YL421-YL423, YM643
	W2205	0038	20		S	34-24-15	YK911-YL401, YL424-YL430, YM645-YM670
	W3319	0034	22		S	34-24-15	YK901-YK910, YL421-YL423, YM643
	W3319	0034	20		S	34-24-15	YK911-YL401, YL424-YL430, YM645-YM670

SPLICE LIST

D280A103

91-21-31

Section SP02100

Page 1 End

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02205		237/208/R036					ALL
	W2030	5508	16		S	33-11-32	ALL
	W2205	0001	20		S	33-11-32	YC001-YC030
	W2205	0003	20		S	33-11-32	YC001-YC030, YK901-YM670
	W2205	0010	20		S	33-11-32	YK901-YM670
	W2205	0015	20		S	33-11-32	YC001-YC030

SPLICE LIST

D280A103

91-21-31

Section SP02200

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02602		256/194/L8					YC001-YC003
	W2508	0006	20		S	52-71-13	YC001-YC003
	W5156	0008	20		S	52-71-13	YC001-YC003
SP02604		256/194/L8					YC001-YC003
	W5158	0009	20		S	52-71-14	YC001-YC003
	W6024	0001	20		S	52-71-14	YC001-YC003
SP02606		256/194/L8					YC001-YC003
	W2508	0008	20		S	52-71-13	YC001-YC003
	W5156	0020	20		S	52-71-13	YC001-YC003



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02802		256/194/L8					YC001-YC003
	W5156	0004	20		S	52-71-13	YC001-YC003
	W5160	0034	20		S	52-71-13	YC001-YC003
SP02804		256/194/L8					YC001-YC003
	W2114	0031	20		S	52-71-13	YC001-YC003
	W5156	0005	20		S	52-71-13	YC001-YC003
SP02806		256/194/L8					YC001-YC003
	W2114	0030	20		S	52-71-13	YC001-YC003
	W5156	0006	20		S	52-71-13	YC001-YC003
	W5158	0013	20		S	52-71-14	YC001-YC003
SP02808		256/194/L8					YC001-YC003
	W2114	0035	20		S	52-71-14	YC001-YC003
	W5156	0007	20		S	52-71-13	YC001-YC003
	W5158	0012	20		S	52-71-14	YC001-YC003
SP02818		257/194/-8					YC001-YC003
	W2114	0036	20		S	52-71-14	YC001-YC003
	W5158	0011	20		S	52-71-14	YC001-YC003
SP02832		256/194/L8					YC001-YC003
	W2508	0007	20		S	52-71-14	YC001-YC003
	W5160	0020	20		S	52-71-14	YC001-YC003
SP02834		256/194/L8					YC001-YC003
	W2114	0040	20		S	52-71-13	YC001-YC003
	W5156	0543	20		S	52-71-13	YC001-YC003
SP02842		256/194/L8					YC001-YC003
	W2114	0045	20		S	52-71-14	YC001-YC003
	W5158	0508	20		S	52-71-14	YC001-YC003
SP02846		//					YC001-YL430
SP02850		256/194/L8					YC001-YC003
	W2508	0009	20		S	52-71-14	YC001-YC003
	W5160	0540	20		S	52-71-14	YC001-YC003

SPLICE LIST
D280A103

91-21-31
Section SP02800
Page 1
Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02876		OFSS-712/ /					ALL
	W1188	2005B	20		9	27-81-12	ALL
	W1188	A-B			9	27-81-12	ALL
SP02884		OFSS-662/ /					ALL
	W1188	2006R	20		9	27-81-12	ALL
	W1188	B-R			9	27-81-12	ALL
SP02886		OFSS-662/ /					ALL
	W1188	2006B	20		9	27-81-12	ALL
	W1188	B-B			9	27-81-12	ALL



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL		GA	CO	Type	Diagram	Effectivity
		Wire No.						
SP02936		OFSS-581/ /						ALL
	W1188	2007R	20		9	27-81-12		ALL
	W1188	C-R			9	27-81-12		ALL
SP02938		OFSS-581/ /						ALL
	W1188	2007B	20		9	27-81-12		ALL
	W1188	C-B			9	27-81-12		ALL
SP02940		OFSS-534/ /						ALL
	W1188	2008R	20		9	27-81-12		ALL
	W1188	D-R			9	27-81-12		ALL
SP02942		OFSS-534/ /						ALL
	W1188	2008B	20		9	27-81-12		ALL
	W1188	D-B			9	27-81-12		ALL
SP02944		OFSS-459/ /						ALL
	W1188	2009R	20		9	27-81-12		ALL
	W1188	E-R			9	27-81-12		ALL
SP02990		333/308/L019						ALL
	W3058	0371	22		S	33-27-11		YC001-YC030, YK901-YM670
	W3150	0914	22		S	33-27-11		ALL
	W3150	0923	22		S	33-27-21		ALL

SPLICE LIST

D280A103

91-21-31

Section SP02900

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03060		856/296/L024					ALL
	W3058	0060	20		S	38-32-13	YC001-YC030, YK901-YM670
	W3058	0208	20		S	38-32-13	YC001-YC030, YK901-YM670
	W3144	0020	20		S	38-32-13	ALL
I SP03076		* / /					YC001-YC030
	W3058	0006	22		S	52-51-11	YC001-YC030
	W3058	A-A			S	52-51-11	YC001-YC030
SP03078		280/248/R010					ALL
	W3058	0007	20		S	52-51-11	YC001-YC030
	W3058	A-B			S	52-51-11	YC001-YC030
SP03097		238/196/R002					ALL
	W5369	0106	22		S	22-31-51	ALL
	W5457	0001	22		S	22-31-51	ALL
	W5457	0106	22		S	22-31-51	ALL



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03101		238/196/R002					ALL
	W5369	0108	22		S	22-31-51	ALL
	W5457	0108	22		S	22-31-51	ALL
SP03103		E003-01/ /					ALL
	W0311	0221	22		W	31-62-41	YC001-YC030
	W0311	0221	24		W	31-62-41	YK901-YM670
	W0313	0571	22		W	31-62-41	YC001-YC030
	W0313	0571	24		W	31-62-41	YK901-YM670
	W0313	0572	22		W	31-62-41	YC001-YC030
	W0313	0572	24		W	31-62-41	YK901-YM670
SP03104		E003-01/ /					YK907-YM670
	W0311	0178	24		W	31-62-42	YK907-YM670
	W0313	0631	24		W	31-62-42	YK907-YM670
	W0313	0632	24		W	31-62-42	YK907-YM670

SPLICE LIST

D280A103

91-21-31

Section SP03100

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03210		//					ALL

SPLICE LIST
D280A103

91-21-31
Section SP03200
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL	GA	CO	Type	Diagram	Effectivity
		Wire No.					
SP03362		OFSS-459/ /					ALL
	W1188	2009B	20		9	27-81-12	ALL
	W1188	E-B			9	27-81-12	ALL
SP03380		OFSS-415/ /					ALL
	W1188	2010R	20		9	27-81-12	ALL
	W1188	F-R			9	27-81-12	ALL

SPLICE LIST

D280A103

91-21-31

Section SP03300

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03420		//					ALL
SP03422		OFSS-415/ /					ALL
	W1188	2010B	20		9	27-81-12	ALL
	W1188	F-B			9	27-81-12	ALL
SP03428		OFSS-341/ /					ALL
	W1188	2011R	20		9	27-81-12	ALL
	W1188	G-R			9	27-81-12	ALL
SP03430		OFSS-341/ /					ALL
	W1188	2011B	20		9	27-81-12	ALL
	W1188	G-B			9	27-81-12	ALL
SP03432		OFSS-300/ /					ALL
	W1188	2012R	20		9	27-81-12	ALL
	W1188	H-R			9	27-81-12	ALL
SP03436		OFSS-300/ /					ALL
	W1188	2012B	20		9	27-81-12	ALL
	W1188	H-B			9	27-81-12	ALL
SP03438		OFSS 341/ /					ALL
	W1288	2005R	20		9	27-81-22	ALL
	W1288	A-R			9	27-81-22	ALL
SP03440		OFSS 341/ /					ALL
	W1288	2005B	20		9	27-81-22	ALL
	W1288	A-B			9	27-81-22	ALL
SP03442		OFSS 300/ /					ALL
	W1288	2006R	20		9	27-81-22	ALL
	W1288	B-R			9	27-81-22	ALL
SP03446		OFSS 300/ /					ALL
	W1288	2006B	20		9	27-81-22	ALL
	W1288	B-B			9	27-81-22	ALL
SP03448		OFSS 459/ /					ALL
	W1288	2007R	20		9	27-81-22	ALL

SPLICE LIST

D280A103

91-21-31

Section SP03400

Page 1

Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03448		OFSS 459/ / (continued)					ALL
	W1288	C-R			9	27-81-22	ALL
SP03450		OFSS 459/ /					ALL
	W1288	2007B	20		9	27-81-22	ALL
	W1288	C-B			9	27-81-22	ALL
SP03454		OFSS 415/ /					ALL
	W1288	2008R	20		9	27-81-22	ALL
	W1288	D-R			9	27-81-22	ALL
SP03456		OFSS 415/ /					ALL
	W1288	2008B	20		9	27-81-22	ALL
	W1288	D-B			9	27-81-22	ALL
SP03458		OFSS 581/ /					ALL
	W1288	2009R	20		9	27-81-22	ALL
	W1288	E-R			9	27-81-22	ALL
SP03460		OFSS 581/ /					ALL
	W1288	2009B	20		9	27-81-22	ALL
	W1288	E-B			9	27-81-22	ALL
SP03462		OFSS 534/ /					ALL
	W1288	2010R	20		9	27-81-22	ALL
	W1288	F-R			9	27-81-22	ALL
SP03466		OFSS 534/ /					ALL
	W1288	2010B	20		9	27-81-22	ALL
	W1288	F-B			9	27-81-22	ALL
SP03468		OFSS 712/ /					ALL
	W1288	2011R	20		9	27-81-22	ALL
	W1288	G-R			9	27-81-22	ALL
SP03470		OFSS 712/ /					ALL
	W1288	2011B	20		9	27-81-22	ALL
	W1288	G-B			9	27-81-22	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03472		OFSS 662/ /					ALL
	W1288	2012R	20		9	27-81-22	ALL
	W1288	H-R			9	27-81-22	ALL
SP03474		OFSS 662/ /					ALL
	W1288	2012B	20		9	27-81-22	ALL
	W1288	H-B			9	27-81-22	ALL
SP03476		OFSS-589/ /					ALL
	W1662	2001R	20		9	28-44-11	ALL
	W1662	M-R			9	28-44-11	ALL
SP03478		OFSS-589/ /					ALL
	W1662	2001B	20		9	28-44-11	ALL
	W1662	M-B			9	28-44-11	ALL
SP03480		333/308/L019					ALL
	W3058	0363	20		S	33-51-12	YC001-YC030, YM643-YM670
	W3058	0363	16		S	33-51-12	YK901-YL430
	W4142	0061	16		S	33-51-12	YK901-YL430
	W4142	0113	20		S	33-51-12	YC001-YC050, YM643-YM670
SP03483		265/184/L065					ALL
SP03484		937/317/L013					ALL
	W3058	0463	20		S	33-51-14	YC001-YC030, YK901-YM670
	W3142	0413	20		S	33-51-14	YC001-YC030, YK901-YL430
	W4142	0413	20		S	33-51-14	YM643-YM670
SP03485		250/195/R040					ALL
SP03490		937/298/L013					ALL
	W3058	0470	22		S	33-27-22	YC001-YC030, YK901-YM670
	W3144	0083	22		S	33-27-22	ALL
SP03492		937/300/L013					ALL
	W3058	0469	22		S	33-27-22	YC001-YC030, YK901-YM670
	W3144	0317	22		S	33-27-22	ALL
	W3144	0367	22		S	33-27-32	ALL



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03496		333/290/L019					ALL
SP03498		333/308/L019					ALL
	W3058	0372	22		S	33-27-11	YC001-YC030, YK901-YM670
	W3144	0117	22		S	33-27-11	ALL

SPLICE LIST

D280A103

91-21-31

Section SP03400

Page 4 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03504		328/291/L001					ALL
	W0050	0010	20		S	33-29-11	ALL
	W0050	A-C			S	33-29-11	ALL
	W0050	A-H			S	33-29-11	ALL
SP03506		328/291/L001					ALL
	W0050	0011	20		S	33-29-11	ALL
	W0050	A-D			S	33-29-11	ALL
	W0050	A-G			S	33-29-11	ALL
SP03508		977/293/L014					ALL
	W0052	0010	20		S	33-29-11	ALL
	W0052	A-C			S	33-29-11	ALL
	W0052	A-H			S	33-29-11	ALL
SP03512		977/293/R014					ALL
	W0052	0011	20		S	33-29-11	ALL
	W0052	A-D			S	33-29-11	ALL
	W0052	A-G			S	33-29-11	ALL
SP03522		937/317/L013					ALL
	W3058	0422	22		S	33-26-11	YC001-YC030, YK901-YM670
	W3142	0475	22		S	33-26-11	YC001-YC030, YK901-YM652
	W4142	0475	22		S	33-26-11	ALL

SPLICE LIST

D280A103

91-21-31

Section SP03500

Page 1 End

May 11/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03707		265/184/L065					ALL
SP03709		250/195/R040					ALL
SP03731		365/200/L030					ALL
SP03745		200/211/L008					ALL
SP03747		200/211/L008					ALL
SP03749		200/211/L008					ALL

SPLICE LIST

D280A103

91-21-31

Section SP03700

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03891		311/168/L042					ALL
	W2103	0010	22		S	23-31-06	YK901-YM652
	W3307	0012	22		S	23-31-06	YK901-YM670

SPLICE LIST
D280A103

91-21-31
Section SP03800
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP04010		998/300/L005					ALL
	W3158	0206	18		S	33-35-11	ALL
	W5726	0011	18		S	33-35-11	YC001-YK912, YK918-YK919, YL401-YL429, YM643-YM652
SP04012		//					ALL
SP04014		//					ALL
SP04016		*/**					ALL

SPLICE LIST

D280A103

91-21-31

Section SP04000

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP04602		263/168/R25					ALL

SPLICE LIST
D280A103

91-21-31
Section SP04600
Page 1 End
Feb 09/2009



737-700/800 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05006		240/208/R037					ALL
	W5514	0014	22		9	21-33-11	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
	W6414	0009	22		9	21-33-11	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM652
SP05008		240/208/R037					ALL
	W5514	0015	22		9	21-33-11	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM670
	W6414	0010	22		9	21-33-11	YK911-YK917, YK919-YL401, YL427-YL430, YM651-YM652

SPLICE LIST

D280A103

91-21-31

Section SP05000

Page 1 End

Feb 09/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP09002		TBD/ /					YC001-YC030
	W9103	9005R	22		S	23-70-11	YC001-YC030
SP09003		TBD/ /					YC001-YC030
	W9103	9005B	22		S	23-70-11	YC001-YC030
SP09004		TBD/ /					YC001-YC030
	W9103	9006R	22		S	23-70-11	YC001-YC030
SP09005		TBD/ /					YC001-YC030
	W9103	9006B	22		S	23-70-11	YC001-YC030
SP09008		TBD/ /					YC001-YC030
	W9103	9013R	22		S	23-70-11	YC001-YC030
SP09016		TBD/ /					YC001-YC030
	W9103	9013B	22		S	23-70-11	YC001-YC030

SPLICE LIST
D280A103

91-21-31
Section SP09000
Page 1 End
Aug 13/2008