

EQUIPMENT LIST

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			AP0000	1	Jan 21/2005	C00000 cont.		
	1 thru 15	Oct 09/2008		2	Jan 21/2005		2	Jan 21/2005
	16	BLANK	AP0100	1	Jan 21/2005	C00300	1	Jan 21/2005
AA0300	1	Jan 21/2005	AP0300	1	Jan 21/2005		2	Jan 21/2005
AA0400	1	Jan 21/2005	R AS1000	1	Oct 09/2008		3	Jan 21/2005
AA1200	1	Jan 21/2005	R AS1100	1	Oct 09/2008		4	Jan 21/2005
AA1600	1	Jan 21/2005	R AS2000	1	Oct 09/2008	C00500	1	Jan 21/2005
AA1700	1	Jan 21/2005	R AS2100	1	Oct 09/2008		2	Jan 21/2005
AA1800	1	Jan 21/2005	AT1800	1	Jan 21/2005		3	Jan 21/2005
AB0300	1	Jan 21/2005	AW1100	1	Jan 21/2005		4	Jan 21/2005
AB1200	1	Jan 21/2005	AW1200	1	Jan 21/2005		5	Jan 21/2005
AB1600	1	Jan 21/2005	AW1300	1	Jan 21/2005		6	Jan 21/2005
AB1800	1	Jan 21/2005	AW2100	1	Jan 21/2005	C00600	1	Dec 18/2007
AC0200	1	Jan 21/2005	AW2200	1	Jan 21/2005		2	Dec 18/2007
AC0300	1	Jan 21/2005	AW2300	1	Jan 21/2005		3	Dec 18/2007
AC0800	1	Jan 21/2005	AW2400	1	Jan 21/2005	R	4	Oct 09/2008
AC1000	1	Jan 21/2005	B00000	1	Jan 21/2005	O	5	Oct 09/2008
AC1100	1	Jan 21/2005		2	Jan 21/2005	R C00700	1	Oct 09/2008
AD0500	1	Jan 21/2005		3	Jan 21/2005	O	2	Oct 09/2008
AD0800	1	Jan 21/2005	B00100	1	Jan 21/2005	O	3	Oct 09/2008
AD1000	1	Jan 21/2005	B09000	1	Jan 21/2005	O	4	Oct 09/2008
AD1100	1	Jan 21/2005	B10000	1	Jan 21/2005	C00800	1	Jan 21/2005
AE0100	1	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
AE0200	1	Jan 21/2005		3	Jan 21/2005		3	Jan 21/2005
AE0300	1	Jan 21/2005	B10100	1	Jan 21/2005		4	Jan 21/2005
AE0400	1	Jan 21/2005		2	Jan 21/2005	C00900	1	Jan 21/2005
AE0500	1	Jan 21/2005	B10200	1	Jan 21/2005	C01000	1	Jan 21/2005
AE0600	1	Jan 21/2005	C00000	1	Jan 21/2005		2	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 1
Oct 09/2008



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
C01000 cont.			C04000 cont.			D00000 cont.		
	3	Jan 21/2005		5	Jan 21/2005	O	6	Oct 09/2008
	4	Jan 21/2005		6	Jan 21/2005	O	7	Oct 09/2008
C01100	1	Jan 21/2005	C04100	1	Jan 21/2005	O	8	Oct 09/2008
	2	Jan 21/2005		2	Jan 21/2005	O	9	Oct 09/2008
	3	Jan 21/2005		3	Jan 21/2005	O	10	Oct 09/2008
	4	Jan 21/2005		4	Jan 21/2005	O	11	Oct 09/2008
C01200	1	Jan 21/2005		5	Jan 21/2005	O	12	Oct 09/2008
	2	Jan 21/2005		6	Jan 21/2005	O D00100	1	Oct 09/2008
	3	Jan 21/2005	C04200	1	Jan 21/2005	O	2	Oct 09/2008
	4	Jan 21/2005		2	Jan 21/2005	O	3	Oct 09/2008
	5	Jan 21/2005		3	Jan 21/2005	O	4	Oct 09/2008
	6	Jan 21/2005		4	Jan 21/2005	R	5	Oct 09/2008
C01300	1	Jan 21/2005		5	Jan 21/2005	R	6	Oct 09/2008
	2	Jan 21/2005	O	6	Oct 09/2008	O	7	Oct 09/2008
	3	Jan 21/2005	D	7	Oct 09/2008	O D00200	1	Oct 09/2008
C01400	1	May 17/2006	O C04300	1	Oct 09/2008	O	2	Oct 09/2008
	2	Jan 21/2005	O	2	Oct 09/2008	O	3	Oct 09/2008
C01500	1	Jan 21/2005	O	3	Oct 09/2008	O	4	Oct 09/2008
	2	Jan 21/2005	O C04400	1	Oct 09/2008	O	5	Oct 09/2008
	3	Jan 21/2005	O	2	Oct 09/2008	O	6	Oct 09/2008
C03000	1	Jan 21/2005	O C04500	1	Oct 09/2008	O	7	Oct 09/2008
	2	Jan 21/2005	R C04600	1	Oct 09/2008	O	8	Oct 09/2008
	3	Jan 21/2005	O D00000	1	Oct 09/2008	O	9	Oct 09/2008
C04000	1	Jan 21/2005	O	2	Oct 09/2008	O D00300	1	Oct 09/2008
	2	Jan 21/2005	O	3	Oct 09/2008	O	2	Oct 09/2008
	3	Jan 21/2005	O	4	Oct 09/2008	O	3	Oct 09/2008
	4	Jan 21/2005	O	5	Oct 09/2008	O	4	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 2
Oct 09/2008



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D00300 cont.			D00700 cont.			D01600 cont.		
O	5	Oct 09/2008	O	4	Oct 09/2008		3	Dec 18/2007
O	6	Oct 09/2008	O D00800	1	Oct 09/2008		4	Dec 18/2007
O D00400	1	Oct 09/2008	O	2	Oct 09/2008	D01700	1	Dec 18/2007
O	2	Oct 09/2008	O	3	Oct 09/2008		2	Dec 18/2007
O	3	Oct 09/2008	O	4	Oct 09/2008		3	Dec 18/2007
O	4	Oct 09/2008	O D00900	1	Oct 09/2008		4	Dec 18/2007
O	5	Oct 09/2008	O	2	Oct 09/2008	D01800	1	Dec 18/2007
O D00500	1	Oct 09/2008	O D01000	1	Oct 09/2008		2	Dec 18/2007
O	2	Oct 09/2008	O D01100	1	Oct 09/2008		3	Dec 18/2007
O	3	Oct 09/2008	O	2	Oct 09/2008		4	Dec 18/2007
O	4	Oct 09/2008	O	3	Oct 09/2008		5	Dec 18/2007
O	5	Oct 09/2008	O D01200	1	Oct 09/2008		6	Dec 18/2007
O	6	Oct 09/2008	O	2	Oct 09/2008	D01900	1	Dec 18/2007
O D00600	1	Oct 09/2008	O	3	Oct 09/2008		2	Dec 18/2007
O	2	Oct 09/2008	O	4	Oct 09/2008		3	Dec 18/2007
O	3	Oct 09/2008	O	5	Oct 09/2008		4	Dec 18/2007
O	4	Oct 09/2008	O D01300	1	Oct 09/2008	D02000	1	Dec 18/2007
O	5	Oct 09/2008	O	2	Oct 09/2008		2	Dec 18/2007
O	6	Oct 09/2008	O	3	Oct 09/2008		3	Dec 18/2007
O	7	Oct 09/2008	R D01400	1	Oct 09/2008		4	Dec 18/2007
O	8	Oct 09/2008	A	2	Oct 09/2008	D02100	1	Jan 21/2005
O	9	Oct 09/2008	R D01500	1	Oct 09/2008		2	Jan 21/2005
O	10	Oct 09/2008	O	2	Oct 09/2008		3	Jan 21/2005
O	11	Oct 09/2008	O	3	Oct 09/2008		4	Jan 21/2005
O D00700	1	Oct 09/2008	O	4	Oct 09/2008	D02200	1	Jan 21/2005
O	2	Oct 09/2008					2	Jan 21/2005
O	3	Oct 09/2008	D01600	1	Dec 18/2007		3	Oct 09/2008
				2	Dec 18/2007	R		

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 3
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
R D02200 cont.	4	Oct 09/2008	D02900 cont.	2	Dec 18/2007	D03500 cont.	5	Jan 21/2005
D02300	1	Jan 21/2005		3	Dec 18/2007		6	Jan 21/2005
	2	Jan 21/2005		4	Dec 18/2007	D03700	1	Jan 21/2005
	3	Jan 21/2005		5	Dec 18/2007	D03800	1	Jan 21/2005
	4	Jan 21/2005		6	Dec 18/2007	D03900	1	Jan 21/2005
D02400	1	May 17/2006	D03000	1	Jan 21/2005	D04000	1	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005		3	Jan 21/2005
	4	Jan 21/2005		4	Jan 21/2005		4	Jan 21/2005
D02500	1	Jan 21/2005		5	Jan 21/2005	D04100	1	Jan 21/2005
	2	Jan 21/2005	D03100	1	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005		2	Jan 21/2005		3	Jan 21/2005
	4	Jan 21/2005	D03200	1	Jan 21/2005	D04200	1	Jan 21/2005
	5	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
D02600	1	May 17/2006		3	Jan 21/2005		3	Jan 21/2005
	2	May 17/2006		4	Jan 21/2005	D04300	1	Jan 21/2005
	3	May 17/2006		5	Jan 21/2005		2	Jan 21/2005
	4	May 17/2006	D03300	1	Jan 21/2005	D04400	1	Jan 21/2005
D02700	1	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	2	Jan 21/2005	D03400	1	Jan 21/2005		3	Jan 21/2005
	3	Jan 21/2005		2	Jan 21/2005		4	Jan 21/2005
	4	May 17/2006		3	Jan 21/2005	D04500	1	Jan 21/2005
D02800	1	May 17/2006		4	Jan 21/2005		2	Jan 21/2005
	2	May 17/2006	D03500	1	Jan 21/2005		3	Jan 21/2005
	3	Jan 21/2005		2	Jan 21/2005	D04600	1	Jan 21/2005
	4	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
D02900	1	Jan 21/2005		4	Jan 21/2005		3	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 4
Oct 09/2008



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D04600 cont.			D05900 cont.			D07000 cont.		
	4	Jan 21/2005		8	Jan 21/2005		3	Jan 21/2005
	5	Jan 21/2005		9	Jan 21/2005	D07100	1	Jan 21/2005
D04700	1	Jan 21/2005		10	Jan 21/2005	D07200	1	Jan 21/2005
	2	Jan 21/2005		11	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005		12	Jan 21/2005	D07300	1	Jan 21/2005
	4	Jan 21/2005	D06000	1	Jan 21/2005	D07400	1	Jan 21/2005
D04800	1	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	2	Jan 21/2005		3	Jan 21/2005	D07500	1	Jan 21/2005
D05000	1	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
D05100	1	Jan 21/2005		5	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005		6	Jan 21/2005		4	Jan 21/2005
D05200	1	Jan 21/2005		7	Jan 21/2005	D07600	1	May 17/2006
	2	Jan 21/2005		8	Jan 21/2005	D07700	1	Jan 21/2005
D05300	1	Jan 21/2005		9	Jan 21/2005		2	Jan 21/2005
D05400	1	Jan 21/2005		10	Jan 21/2005		3	Jan 21/2005
D05500	1	Jan 21/2005		11	Jan 21/2005	D07800	1	Jan 21/2005
D05600	1	Jan 21/2005		12	Jan 21/2005	D07900	1	Jan 21/2005
	2	Jan 21/2005	D06200	1	Jan 21/2005	D10600	1	Jan 21/2005
D05700	1	Jan 21/2005	D06300	1	Jan 21/2005	D10700	1	Jan 21/2005
D05800	1	Jan 21/2005		2	Jan 21/2005	A D11700	1	Oct 09/2008
D05900	1	Jan 21/2005	D06400	1	Jan 21/2005	O D21000	1	Oct 09/2008
	2	Jan 21/2005	D06700	1	Jan 21/2005	O D22000	1	Oct 09/2008
	3	Jan 21/2005	D06800	1	May 17/2006	O D23000	1	Oct 09/2008
	4	Jan 21/2005	R	2	Oct 09/2008	O D40000	1	Oct 09/2008
	5	Jan 21/2005	D06900	1	May 17/2006	O	2	Oct 09/2008
	6	Jan 21/2005	D07000	1	Jan 21/2005	O	3	Oct 09/2008
	7	Jan 21/2005		2	Jan 21/2005	O	4	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 5
Oct 09/2008



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D40000 cont.			D40300 cont.			D40600 cont.		
O	5	Oct 09/2008	O	7	Oct 09/2008	O	5	Oct 09/2008
O	6	Oct 09/2008	O	8	Oct 09/2008	O	6	Oct 09/2008
O	7	Oct 09/2008	O	9	Oct 09/2008	O	7	Oct 09/2008
O	8	Oct 09/2008	O	10	Oct 09/2008	O	8	Oct 09/2008
O	9	Oct 09/2008	O	11	Oct 09/2008	O D40700	1	Oct 09/2008
O	10	Oct 09/2008	O	12	Oct 09/2008	O	2	Oct 09/2008
O	11	Oct 09/2008	O	13	Oct 09/2008	O	3	Oct 09/2008
O	12	Oct 09/2008	O D40400	1	Oct 09/2008	O	4	Oct 09/2008
O D40100	1	Oct 09/2008	O	2	Oct 09/2008	O	5	Oct 09/2008
O	2	Oct 09/2008	O	3	Oct 09/2008	O D40800	1	Oct 09/2008
O	3	Oct 09/2008	O	4	Oct 09/2008	O	2	Oct 09/2008
O	4	Oct 09/2008	O	5	Oct 09/2008	O	3	Oct 09/2008
O	5	Oct 09/2008	O	6	Oct 09/2008	O	4	Oct 09/2008
O D40200	1	Oct 09/2008	O	7	Oct 09/2008	O	5	Oct 09/2008
O	2	Oct 09/2008	O	8	Oct 09/2008	O	6	Oct 09/2008
O	3	Oct 09/2008	O D40500	1	Oct 09/2008	O D40900	1	Oct 09/2008
O	4	Oct 09/2008	O	2	Oct 09/2008	O	2	Oct 09/2008
O	5	Oct 09/2008	O	3	Oct 09/2008	O	3	Oct 09/2008
O	6	Oct 09/2008	O	4	Oct 09/2008	O	4	Oct 09/2008
O	7	Oct 09/2008	O	5	Oct 09/2008	O	5	Oct 09/2008
O	8	Oct 09/2008	O	6	Oct 09/2008	O	6	Oct 09/2008
O D40300	1	Oct 09/2008	O	7	Oct 09/2008	O D41000	1	Oct 09/2008
O	2	Oct 09/2008	O	8	Oct 09/2008	O	2	Oct 09/2008
O	3	Oct 09/2008	O D40600	1	Oct 09/2008	O	3	Oct 09/2008
O	4	Oct 09/2008	O	2	Oct 09/2008	O	4	Oct 09/2008
O	5	Oct 09/2008	O	3	Oct 09/2008	O	5	Oct 09/2008
O	6	Oct 09/2008	O	4	Oct 09/2008	R	6	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 6
Oct 09/2008



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D41000 cont.			O D41400	1	Oct 09/2008	D41600 cont.		
O	7	Oct 09/2008	O	2	Oct 09/2008	O	12	Oct 09/2008
O	8	Oct 09/2008	O	3	Oct 09/2008	O D41700	1	Oct 09/2008
O D41100	1	Oct 09/2008	O	4	Oct 09/2008	O	2	Oct 09/2008
O	2	Oct 09/2008	O	5	Oct 09/2008	O	3	Oct 09/2008
O	3	Oct 09/2008	R	6	Oct 09/2008	O	4	Oct 09/2008
O	4	Oct 09/2008	O	7	Oct 09/2008	O	5	Oct 09/2008
O	5	Oct 09/2008	O	8	Oct 09/2008	O	6	Oct 09/2008
O	6	Oct 09/2008	O	9	Oct 09/2008	O	7	Oct 09/2008
O	7	Oct 09/2008	O	10	Oct 09/2008	O	8	Oct 09/2008
O	8	Oct 09/2008	O D41500	1	Oct 09/2008	O	9	Oct 09/2008
O	9	Oct 09/2008	O	2	Oct 09/2008	O	10	Oct 09/2008
O D41200	1	Oct 09/2008	O	3	Oct 09/2008	O	11	Oct 09/2008
O	2	Oct 09/2008	O	4	Oct 09/2008	O	12	Oct 09/2008
O	3	Oct 09/2008	O	5	Oct 09/2008	O	13	Oct 09/2008
O	4	Oct 09/2008	O	6	Oct 09/2008	O	14	Oct 09/2008
O	5	Oct 09/2008	O	7	Oct 09/2008	O	15	Oct 09/2008
O D41300	1	Oct 09/2008	O D41600	1	Oct 09/2008	O D41800	1	Oct 09/2008
O	2	Oct 09/2008	O	2	Oct 09/2008	O	2	Oct 09/2008
O	3	Oct 09/2008	O	3	Oct 09/2008	O	3	Oct 09/2008
O	4	Oct 09/2008	O	4	Oct 09/2008	O	4	Oct 09/2008
O	5	Oct 09/2008	O	5	Oct 09/2008	O	5	Oct 09/2008
O	6	Oct 09/2008	O	6	Oct 09/2008	O	6	Oct 09/2008
O	7	Oct 09/2008	O	7	Oct 09/2008	O	7	Oct 09/2008
O	8	Oct 09/2008	O	8	Oct 09/2008	O	8	Oct 09/2008
O	9	Oct 09/2008	O	9	Oct 09/2008	O	9	Oct 09/2008
O	10	Oct 09/2008	O	10	Oct 09/2008	O	10	Oct 09/2008
O	11	Oct 09/2008	O	11	Oct 09/2008	O	11	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 7
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D41800 cont.			D42100 cont.			O D65000	1	Oct 09/2008
O	12	Oct 09/2008	O	4	Oct 09/2008	O E001	1	Oct 09/2008
O	13	Oct 09/2008	O	5	Oct 09/2008	O E002	1	Oct 09/2008
O D41900	1	Oct 09/2008	R	6	Oct 09/2008	O E003	1	Oct 09/2008
O	2	Oct 09/2008	O	7	Oct 09/2008	O E004	1	Oct 09/2008
O	3	Oct 09/2008	O	8	Oct 09/2008	O E005	1	Oct 09/2008
O	4	Oct 09/2008	O	9	Oct 09/2008	O E006	1	Oct 09/2008
O	5	Oct 09/2008	O D42200	1	Oct 09/2008	O J00000	1	Oct 09/2008
O	6	Oct 09/2008	O	2	Oct 09/2008	O K00000	1	Oct 09/2008
O	7	Oct 09/2008	O	3	Oct 09/2008	O	2	Oct 09/2008
O	8	Oct 09/2008	O	4	Oct 09/2008	O	3	Oct 09/2008
O	9	Oct 09/2008	O	5	Oct 09/2008	O	4	Oct 09/2008
O D42000	1	Oct 09/2008	O	6	Oct 09/2008	O K00100	1	Oct 09/2008
O	2	Oct 09/2008	O	7	Oct 09/2008	O	2	Oct 09/2008
O	3	Oct 09/2008	O	8	Oct 09/2008	O	3	Oct 09/2008
O	4	Oct 09/2008	O	9	Oct 09/2008	O	4	Oct 09/2008
O	5	Oct 09/2008	O	10	Oct 09/2008	O K00200	1	Oct 09/2008
O	6	Oct 09/2008	O D42300	1	Oct 09/2008	O	2	Oct 09/2008
O	7	Oct 09/2008	O D42400	1	Oct 09/2008	R K00300	1	Oct 09/2008
O	8	Oct 09/2008	O D42500	1	Oct 09/2008	O K00400	1	Oct 09/2008
O	9	Oct 09/2008	O D43000	1	Oct 09/2008	O K00500	1	Oct 09/2008
O	10	Oct 09/2008	R	2	Oct 09/2008	O K00600	1	Oct 09/2008
O	11	Oct 09/2008	R	3	Oct 09/2008	O K00700	1	Oct 09/2008
O	12	Oct 09/2008	O D43300	1	Oct 09/2008	A K02000	1	Oct 09/2008
O	13	Oct 09/2008	O D43600	1	Oct 09/2008	K10000	1	Dec 18/2007
O D42100	1	Oct 09/2008	O D44100	1	Oct 09/2008		2	Dec 18/2007
O	2	Oct 09/2008	O D45000	1	Oct 09/2008		3	Dec 18/2007
O	3	Oct 09/2008	O D52100	1	Oct 09/2008	K10100	1	Dec 18/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 8
Oct 09/2008

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
K10100 cont.			L00000 cont.			L00400 cont.		
	2	Dec 18/2007		6	Dec 18/2007		11	Dec 18/2007
	3	Dec 18/2007		7	Dec 18/2007		12	Dec 18/2007
	4	Dec 18/2007	L00200	1	Dec 18/2007	L00500	1	Dec 18/2007
	5	Dec 18/2007		2	Dec 18/2007		2	Dec 18/2007
K10200	1	Dec 18/2007		3	Dec 18/2007		3	Dec 18/2007
	2	Dec 18/2007		4	Dec 18/2007		4	Dec 18/2007
	3	Dec 18/2007		5	Dec 18/2007	L00600	1	Dec 18/2007
	4	Dec 18/2007		6	Dec 18/2007		2	Dec 18/2007
K10300	1	Dec 18/2007		7	Dec 18/2007	L00700	1	Dec 18/2007
	2	Dec 18/2007	L00300	1	Dec 18/2007	L00800	1	Dec 18/2007
	3	Dec 18/2007		2	Dec 18/2007	L01000	1	Dec 18/2007
	4	Dec 18/2007		3	Dec 18/2007	M00000	1	Dec 18/2007
K10400	1	Dec 18/2007		4	Dec 18/2007	R	2	Oct 09/2008
R	2	Oct 09/2008		5	Dec 18/2007	R	3	Oct 09/2008
O	3	Oct 09/2008		6	Dec 18/2007	O	4	Oct 09/2008
K10500	1	Dec 18/2007		7	Dec 18/2007	R M00100	1	Oct 09/2008
	2	Dec 18/2007		8	Dec 18/2007		2	Dec 18/2007
	3	Dec 18/2007	L00400	1	Dec 18/2007		3	Dec 18/2007
R K10600	1	Oct 09/2008		2	Dec 18/2007		4	Dec 18/2007
K10700	1	Dec 18/2007		3	Dec 18/2007	R	5	Oct 09/2008
	2	Dec 18/2007		4	Dec 18/2007	O	6	Oct 09/2008
R K10800	1	Oct 09/2008		5	Dec 18/2007	O	7	Oct 09/2008
L00000	1	Dec 18/2007		6	Dec 18/2007	M00200	1	Dec 18/2007
	2	Dec 18/2007		7	Dec 18/2007		2	Dec 18/2007
	3	Dec 18/2007		8	Dec 18/2007		3	Dec 18/2007
	4	Dec 18/2007		9	Dec 18/2007		4	Dec 18/2007
	5	Dec 18/2007		10	Dec 18/2007		5	Dec 18/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 9
Oct 09/2008



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
M00200 cont.			M10000 cont.			M10700 cont.		
	6	Dec 18/2007		4	Dec 18/2007		2	Aug 01/2005
R M00300	1	Oct 09/2008	M10100	1	Dec 18/2007	M10800	1	Aug 01/2005
R	2	Oct 09/2008		2	Dec 18/2007	M10900	1	May 17/2006
R	3	Oct 09/2008		3	Dec 18/2007		2	May 17/2006
M00400	1	Dec 18/2007	M10200	1	Dec 18/2007	M11000	1	Aug 01/2005
M00500	1	Dec 18/2007		2	Dec 18/2007	M11200	1	Dec 18/2007
	2	Dec 18/2007		3	Dec 18/2007	A M11800	1	Oct 09/2008
	3	Dec 18/2007		4	Dec 18/2007	O N00000	1	Oct 09/2008
	4	Dec 18/2007		5	Dec 18/2007	O	2	Oct 09/2008
	5	Dec 18/2007	M10300	1	Dec 18/2007	O	3	Oct 09/2008
	6	Dec 18/2007		2	Dec 18/2007	O N10000	1	Oct 09/2008
	7	Dec 18/2007	R	3	Oct 09/2008	O	2	Oct 09/2008
R M00600	1	Oct 09/2008		4	Dec 18/2007	O P001	1	Oct 09/2008
O	2	Oct 09/2008		5	Dec 18/2007	O P003	1	Oct 09/2008
M00700	1	Dec 18/2007		6	Dec 18/2007	O P005	1	Oct 09/2008
	2	Dec 18/2007	M10400	1	Dec 18/2007	O P006	1	Oct 09/2008
M00800	1	Dec 18/2007		2	Dec 18/2007	O P007	1	Oct 09/2008
M00900	1	Dec 18/2007		3	Dec 18/2007	O P008	1	Oct 09/2008
	2	Dec 18/2007		4	Dec 18/2007	O P009	1	Oct 09/2008
M01000	1	Dec 18/2007		5	Dec 18/2007	O P010	1	Oct 09/2008
M01100	1	Dec 18/2007		6	Dec 18/2007	O P011	1	Oct 09/2008
M01300	1	Dec 18/2007	M10500	1	Aug 01/2005	O P013	1	Oct 09/2008
M01400	1	Dec 18/2007		2	Aug 01/2005	O P014	1	Oct 09/2008
M03000	1	Dec 18/2007	M10600	1	Aug 01/2005	O P017	1	Oct 09/2008
M10000	1	Dec 18/2007		2	Aug 01/2005	O P021	1	Oct 09/2008
	2	Dec 18/2007		3	Aug 01/2005	O P022	1	Oct 09/2008
R	3	Oct 09/2008	M10700	1	Aug 01/2005	O P023	1	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 10
Oct 09/2008

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
O P025	1	Oct 09/2008	O P080	1	Oct 09/2008	S00400	1	Dec 18/2007
O P026	1	Oct 09/2008	O QD0000	1	Oct 09/2008		2	Dec 18/2007
O P028	1	Oct 09/2008	O	2	Oct 09/2008	S00500	1	Dec 18/2007
O P030	1	Oct 09/2008	O	3	Oct 09/2008	S00600	1	Dec 18/2007
O P031	1	Oct 09/2008	O R00000	1	Oct 09/2008	S01000	1	Dec 18/2007
O P032	1	Oct 09/2008	O R00100	1	Oct 09/2008	S10000	1	Dec 18/2007
O P033	1	Oct 09/2008	O R00200	1	Oct 09/2008		2	Dec 18/2007
O P034	1	Oct 09/2008	O R00500	1	Oct 09/2008		3	Dec 18/2007
O P036	1	Oct 09/2008	O R10000	1	Oct 09/2008		4	Dec 18/2007
O P037	1	Oct 09/2008	O R10100	1	Oct 09/2008		5	Dec 18/2007
O P041	1	Oct 09/2008	O	2	Oct 09/2008	S10100	1	Dec 18/2007
O P042	1	Oct 09/2008	O	3	Oct 09/2008		2	Dec 18/2007
O P043	1	Oct 09/2008	O	4	Oct 09/2008		3	Dec 18/2007
O P044	1	Oct 09/2008	O	5	Oct 09/2008	S10200	1	Dec 18/2007
O P050	1	Oct 09/2008	O R10200	1	Oct 09/2008		2	Dec 18/2007
O P051	1	Oct 09/2008	O	2	Oct 09/2008		3	Dec 18/2007
O P054	1	Oct 09/2008	O	3	Oct 09/2008		4	Dec 18/2007
O P055	1	Oct 09/2008	R R10300	1	Oct 09/2008		5	Dec 18/2007
O P061	1	Oct 09/2008	R	2	Oct 09/2008		6	Dec 18/2007
O P062	1	Oct 09/2008	A	3	Oct 09/2008		7	Dec 18/2007
O P063	1	Oct 09/2008	R R10400	1	Oct 09/2008		8	Dec 18/2007
O P065	1	Oct 09/2008	R10500	1	Dec 18/2007	S10300	1	Dec 18/2007
O P069	1	Oct 09/2008	R S00000	1	Oct 09/2008		2	Dec 18/2007
O P070	1	Oct 09/2008	R	2	Oct 09/2008		3	Dec 18/2007
O P071	1	Oct 09/2008	O	3	Oct 09/2008		4	Dec 18/2007
O P072	1	Oct 09/2008	S00100	1	Dec 18/2007	S10400	1	Dec 18/2007
O P073	1	Oct 09/2008	S00300	1	Dec 18/2007	S10500	1	Dec 18/2007
O P076	1	Oct 09/2008		2	Dec 18/2007		2	Dec 18/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 11
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
S10600	1	Dec 18/2007	TB0100 cont.			TS0100 cont.		
A S10700	1	Oct 09/2008	O	11	Oct 09/2008	O	4	Oct 09/2008
R T00100	1	Oct 09/2008	O	12	Oct 09/2008	O TS0200	1	Oct 09/2008
O	2	Oct 09/2008	O	13	Oct 09/2008	O TS0300	1	Oct 09/2008
O	3	Oct 09/2008	R	14	Oct 09/2008	O TS5000	1	Oct 09/2008
O T10000	1	Oct 09/2008	O	15	Oct 09/2008	R	2	Oct 09/2008
O	2	Oct 09/2008	R	16	Oct 09/2008	O	3	Oct 09/2008
O TB0000	1	Oct 09/2008	R	17	Oct 09/2008	O	4	Oct 09/2008
O	2	Oct 09/2008	R	18	Oct 09/2008	O TS5100	1	Oct 09/2008
O	3	Oct 09/2008	O	19	Oct 09/2008	O	2	Oct 09/2008
O	4	Oct 09/2008	O	20	Oct 09/2008	O	3	Oct 09/2008
R	5	Oct 09/2008	O	21	Oct 09/2008	O	4	Oct 09/2008
O	6	Oct 09/2008	O	22	Oct 09/2008	O TS5200	1	Oct 09/2008
R	7	Oct 09/2008	R TB0200	1	Oct 09/2008	O TS5300	1	Oct 09/2008
O	8	Oct 09/2008	O	2	Oct 09/2008	R V00000	1	Oct 09/2008
O	9	Oct 09/2008	O	3	Oct 09/2008	R	2	Oct 09/2008
R	10	Oct 09/2008	O	4	Oct 09/2008	R	3	Oct 09/2008
R	11	Oct 09/2008	O	5	Oct 09/2008	R V00100	1	Oct 09/2008
O TB0100	1	Oct 09/2008	O	6	Oct 09/2008	O V10000	1	Oct 09/2008
O	2	Oct 09/2008	O TB0300	1	Oct 09/2008	O	2	Oct 09/2008
O	3	Oct 09/2008	R TB5000	1	Oct 09/2008	R V10100	1	Oct 09/2008
O	4	Oct 09/2008	R	2	Oct 09/2008	O YA0+	1	Oct 09/2008
O	5	Oct 09/2008	R	3	Oct 09/2008	O YA0S00	1	Oct 09/2008
R	6	Oct 09/2008	O TS0000	1	Oct 09/2008	O	2	Oct 09/2008
O	7	Oct 09/2008	O	2	Oct 09/2008	O YAA+	1	Oct 09/2008
R	8	Oct 09/2008	O TS0100	1	Oct 09/2008	O YAAS00	1	Oct 09/2008
O	9	Oct 09/2008	O	2	Oct 09/2008	O YAAV00	1	Oct 09/2008
O	10	Oct 09/2008	O	3	Oct 09/2008	O YALL00	1	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 12
Oct 09/2008

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
O YAOS00	1	Oct 09/2008	O YNP+	1	Oct 09/2008	O YPH+	1	Oct 09/2008
O YAQ+	1	Oct 09/2008	O YNQ+	1	Oct 09/2008	O YPHS00	1	Oct 09/2008
O YAQL00	1	Oct 09/2008	O YNQC	1	Oct 09/2008	O YPJ+	1	Oct 09/2008
O YAQS00	1	Oct 09/2008	O YNQS00	1	Oct 09/2008	O YPJS00	1	Oct 09/2008
O	2	Oct 09/2008	O YNR+	1	Oct 09/2008	O YPP+	1	Oct 09/2008
O YAR+	1	Oct 09/2008	O YNRL00	1	Oct 09/2008	O YPPS00	1	Oct 09/2008
O YAZS00	1	Oct 09/2008	O YNRS00	1	Oct 09/2008	O YPQS00	1	Oct 09/2008
O YBI+	1	Oct 09/2008	O	2	Oct 09/2008	O YPQV00	1	Oct 09/2008
O YBIL00	1	Oct 09/2008	O	3	Oct 09/2008	O YPR+	1	Oct 09/2008
O YBIS00	1	Oct 09/2008	O YNW+	1	Oct 09/2008	O YPRB00	1	Oct 09/2008
O YBM+	1	Oct 09/2008	O YNWB00	1	Oct 09/2008	O YPRD00	1	Oct 09/2008
O YBMM00	1	Oct 09/2008	O YNWD00	1	Oct 09/2008	O YPRL00	1	Oct 09/2008
O YBMS00	1	Oct 09/2008	O YNWL00	1	Oct 09/2008	O YQG+	1	Oct 09/2008
O YBMT	1	Oct 09/2008	O YNX+	1	Oct 09/2008	O YQGD00	1	Oct 09/2008
O YBMV00	1	Oct 09/2008	O YNXD00	1	Oct 09/2008	O YQGL00	1	Oct 09/2008
O YNBL00	1	Oct 09/2008	O YNXL00	1	Oct 09/2008	O YQH+	1	Oct 09/2008
O YNE+	1	Oct 09/2008	O YNY+	1	Oct 09/2008	O YQHB00	1	Oct 09/2008
O YNEL00	1	Oct 09/2008	O YNYB00	1	Oct 09/2008	O YQHD00	1	Oct 09/2008
O	2	Oct 09/2008	O YNYD00	1	Oct 09/2008	O YQHL00	1	Oct 09/2008
O	3	Oct 09/2008	O YNYL00	1	Oct 09/2008	O YQK+	1	Oct 09/2008
O YNM+	1	Oct 09/2008	O YNZ+	1	Oct 09/2008	O YQKB00	1	Oct 09/2008
O YNML00	1	Oct 09/2008	O YNZB00	1	Oct 09/2008	O YQKD00	1	Oct 09/2008
O YNMS00	1	Oct 09/2008	O YNZD00	1	Oct 09/2008	O YQKL00	1	Oct 09/2008
O YNNL00	1	Oct 09/2008	O YNZL00	1	Oct 09/2008	O YQL+	1	Oct 09/2008
O	2	Oct 09/2008	O YPF+	1	Oct 09/2008	O YQLL00	1	Oct 09/2008
O YNNN00	1	Oct 09/2008	O YPFS00	1	Oct 09/2008	O YQLS00	1	Oct 09/2008
O YNNS00	1	Oct 09/2008	O YPG+	1	Oct 09/2008	O YQM+	1	Oct 09/2008
O	2	Oct 09/2008	O YPGS00	1	Oct 09/2008	O YQMK00	1	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 13
Oct 09/2008

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
O YQML00	1	Oct 09/2008	YQZS00 cont.			O YRJL00	1	Oct 09/2008
O YQMS00	1	Oct 09/2008	O	2	Oct 09/2008	O YRJS00	1	Oct 09/2008
O YQN+	1	Oct 09/2008	O YRA+	1	Oct 09/2008	O YRJX	1	Oct 09/2008
O YQNL00	1	Oct 09/2008	O YRAB00	1	Oct 09/2008	O YRK+	1	Oct 09/2008
O YQP+	1	Oct 09/2008	O YRAD00	1	Oct 09/2008	O YRKH00	1	Oct 09/2008
O YQPL00	1	Oct 09/2008	O YRAL00	1	Oct 09/2008	O YRKJ00	1	Oct 09/2008
O YQPS00	1	Oct 09/2008	O YRB+	1	Oct 09/2008	O YRKK00	1	Oct 09/2008
O	2	Oct 09/2008	O YRBL00	1	Oct 09/2008	O YRKL00	1	Oct 09/2008
O YQQ+	1	Oct 09/2008	O YRD+	1	Oct 09/2008	O YRKL	1	Oct 09/2008
O YQQS00	1	Oct 09/2008	O YRDK00	1	Oct 09/2008	O YRKM00	1	Oct 09/2008
O YQS+	1	Oct 09/2008	O YRDL00	1	Oct 09/2008	O YRKP00	1	Oct 09/2008
O YQSL00	1	Oct 09/2008	O YRDS00	1	Oct 09/2008	O YRKR	1	Oct 09/2008
O YQT+	1	Oct 09/2008	O YRE+	1	Oct 09/2008	O YRKS00	1	Oct 09/2008
O YQTL00	1	Oct 09/2008	O YRES00	1	Oct 09/2008	O YRKT00	1	Oct 09/2008
O	2	Oct 09/2008	O YRH+	1	Oct 09/2008	O YRKV00	1	Oct 09/2008
O YQTS00	1	Oct 09/2008	O YRHH00	1	Oct 09/2008	O YRKX	1	Oct 09/2008
O	2	Oct 09/2008	O YRHJ00	1	Oct 09/2008	O YRL+	1	Oct 09/2008
O YQU+	1	Oct 09/2008	O YRHK00	1	Oct 09/2008	O YRLH00	1	Oct 09/2008
O YQUL00	1	Oct 09/2008	O YRHL00	1	Oct 09/2008	O YRLJ00	1	Oct 09/2008
O YQUS00	1	Oct 09/2008	O YRHL	1	Oct 09/2008	O YRLK00	1	Oct 09/2008
O YQV+	1	Oct 09/2008	O YRHM00	1	Oct 09/2008	O YRLM00	1	Oct 09/2008
O YQVL00	1	Oct 09/2008	O YRHP00	1	Oct 09/2008	O YRLP00	1	Oct 09/2008
O YQVS00	1	Oct 09/2008	O YRHR	1	Oct 09/2008	O YRLR	1	Oct 09/2008
O	2	Oct 09/2008	O YRHS00	1	Oct 09/2008	O YRLS00	1	Oct 09/2008
O	3	Oct 09/2008	O YRHT00	1	Oct 09/2008	O YRLT00	1	Oct 09/2008
O YQZJ00	1	Oct 09/2008	O YRHV00	1	Oct 09/2008	O YRLV00	1	Oct 09/2008
O YQZK00	1	Oct 09/2008	O YRHX	1	Oct 09/2008			
O YQZS00	1	Oct 09/2008	O YRJK00	1	Oct 09/2008			

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 14
Oct 09/2008

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
O YRLX	1	Oct 09/2008	O YRUC00	1	Oct 09/2008	O YTQL00	1	Oct 09/2008
O YRM+	1	Oct 09/2008	O YRUM00	1	Oct 09/2008	O YTR+	1	Oct 09/2008
O YRMH00	1	Oct 09/2008	O YRUT	1	Oct 09/2008	O YTRJ00	1	Oct 09/2008
O YRMJ00	1	Oct 09/2008	O YRV+	1	Oct 09/2008	O YTRL00	1	Oct 09/2008
O YRMK00	1	Oct 09/2008	O YRVC00	1	Oct 09/2008	O YTS+	1	Oct 09/2008
O YRML00	1	Oct 09/2008	O YRVM00	1	Oct 09/2008	O YTSJ00	1	Oct 09/2008
O YRML	1	Oct 09/2008	O YRVT	1	Oct 09/2008	O YTSL00	1	Oct 09/2008
O YRMM00	1	Oct 09/2008	O YRW+	1	Oct 09/2008	O YTVS00	1	Oct 09/2008
O YRMP00	1	Oct 09/2008	O YRWC00	1	Oct 09/2008	O YWB+	1	Oct 09/2008
O YRMR	1	Oct 09/2008	O YRWM00	1	Oct 09/2008	O YWBS00	1	Oct 09/2008
O YRMS00	1	Oct 09/2008	O YRWT	1	Oct 09/2008	A	2	BLANK
O YRMT00	1	Oct 09/2008	O YSNR00	1	Oct 09/2008			
O YRMV00	1	Oct 09/2008	O YSNS00	1	Oct 09/2008			
O YRMX	1	Oct 09/2008	O YSPP00	1	Oct 09/2008			
O YRT+	1	Oct 09/2008	O YSPR00	1	Oct 09/2008			
O YRTH00	1	Oct 09/2008	O YSPS00	1	Oct 09/2008			
O YRTJ00	1	Oct 09/2008	O YSPT00	1	Oct 09/2008			
O YRTK00	1	Oct 09/2008	O YSQD00	1	Oct 09/2008			
O YRTL00	1	Oct 09/2008	O YSQL00	1	Oct 09/2008			
O YRTL	1	Oct 09/2008	O YTF+	1	Oct 09/2008			
O YRTM00	1	Oct 09/2008	O YTFM00	1	Oct 09/2008			
O YRTP00	1	Oct 09/2008	O YTGL00	1	Oct 09/2008			
O YRTR	1	Oct 09/2008	O YTGS00	1	Oct 09/2008			
O YRTS00	1	Oct 09/2008	O YTHL00	1	Oct 09/2008			
O YRTT00	1	Oct 09/2008	O YTHS00	1	Oct 09/2008			
O YRTV00	1	Oct 09/2008	O	2	Oct 09/2008			
O YRTX	1	Oct 09/2008	O YTQ+	1	Oct 09/2008			
O YRU+	1	Oct 09/2008	O YTQJ00	1	Oct 09/2008			

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280N032

EFFECTIVE PAGES

Page 15
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AA0360		287N4401 DISC BKT-LAV A DISC	287N4124 81205	1	91-04-04 0360/290/L024	ALL

EQUIPMENT LIST

D280N032

Section AA0300

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AA0409		287N4401 DISC BKT-FWD LOWER CEILING DISC BRACKET	287N4124 81205	1	91-04-04 0409/300/000	ALL

EQUIPMENT LIST

D280N032

Section AA0400
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AA1210		287N4401 DISC BKT-LEFT AFT CABIN DISC	287N4124 81205	1	91-04-13 1210/298/L019	ALL

EQUIPMENT LIST

D280N032

Section AA1200

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AA1671		287N4401 DISC BKT-LEFT PASSENGER CABIN OVERHEAD	287N4124 81205	1	91-04-14 1651/299/L010	ALL
AA1698		415N2003 DISC BKT-UPPER AREA INTERF GAL	415N2004 81205	1	91-04-14 1698/298/	ALL

EQUIPMENT LIST

D280N032

Section AA1600
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AA1705		287N4401 DISC BKT-LEFT PASSENGER CABIN OVERHEAD	287N4601 81205	1	91-04-14 1705/298/	ALL
AA1715		287N4401 DISC BKT-LEFT PASSENGER CABIN OVERHEAD	287N4601 81205	1	91-04-14 1715/298/	ALL

EQUIPMENT LIST

D280N032

Section AA1700

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AA1862		287N8004 DISC BKT-	148N2302 81205	1	91-04-14 1863/245/L035	ALL

EQUIPMENT LIST

D280N032

Section AA1800
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB0317		415N2003 DISC BKT-SERVICE PANEL OVERHEAD GALLEY	415N2002 81205	1	91-04-04 0317/291/R009	ALL

EQUIPMENT LIST

D280N032

Section AB0300

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB1210		287N4401 DISC BKT-RIGHT AFT CABIN DISC	287N4124 81205	1	91-04-13 1210/298/R014	ALL

EQUIPMENT LIST

D280N032

Section AB1200
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB1671		287N4401 DISC BKT-RIGHT PASSENGER CABIN OVERHEAD	287N4601 81205	1	91-04-14 1651/299/R010	ALL

EQUIPMENT LIST

D280N032

Section AB1600

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AB1862		287N8002 DISC BKT-	148N2302 81205	1	91-04-14 1863/245/R035	ALL

EQUIPMENT LIST

D280N032

Section AB1800
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC0204		288N4159 DISC BKT-P10	287N4139 81205	1	91-04-12 / /	ALL
AC0210		287N4126 DISC BKT-SPEED BRAKE DISCONNECT	287N4301 81205	1	91-04-02 220/195/L014	ALL
AC0215		287N4126 DISC BKT-SPEED BRAKE DISCONNECT	287N4301 81205	1	91-04-02 0215/195/L014	ALL
AC0220		287N4126 DISC BKT-SPEED BRAKE DISCONNECT	287N4301 81205	1	91-04-02 210/195/L014	ALL

EQUIPMENT LIST

D280N032

Section AC0200

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC0393		287N6203 DISC BKT-NOSE WHEEL WELL DISC	141N2920 81205	1	91-04-05 0393/160/L020	ALL

EQUIPMENT LIST

D280N032

Section AC0300
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC0820		287N4303 DISC BKT-AIR CONDITIONING SYSTEM,LEFT	TBDN0000 81205	1	91-04-12 0829/226/L070	ALL
AC0880		287N4911 DISC BKT-LEFT FRONT SPAR DISC	TBDN0000 81205	1	91-04-12 880/120/L045	ALL
AC0881		287N4911 DISC BKT-LEFT REAR SPAR DISC	287N4301 81205	1	91-04-12 881/ /L045	ALL

EQUIPMENT LIST

D280N032

Section AC0800

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC1090		287N4408 DISC BKT-LEFT KEEL BEAM	287N4408 81205	1	91-04-12 1090/200/	ALL

EQUIPMENT LIST

D280N032

Section AC1000
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC1148		287N4415 DISC BKT-L. SPOILER DISC L. WHEEL WELL	287N4415 81205	1	91-04-12 1147/180/L068	ALL

EQUIPMENT LIST

D280N032

Section AC1100

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AD0530		TBD DISCONNECT BRACKET	2870000	1	21-65-12 530/ /	115-199

EQUIPMENT LIST

D280N032

Section AD0500
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AD0820		287N4303 DISC BKT-AIR CONDITIONING SYSTEM,RIGHT	TBDN0000 81205	1	91-04-12 0829/226/L070	ALL
AD0880		287N4911 DISC BKT-RIGHT FRONT SPAR DISC	287N4301 81205	1	91-04-12 880/120/R045	ALL
AD0881		287N4911 DISC BKT-RIGHT REAR SPAR DISC	287N4301 81205	1	91-04-12 881/ /R045	ALL

EQUIPMENT LIST

D280N032

Section AD0800

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AD1090		287N4408 DISC BKT-RIGHT KEEL BEAM	287N4408 81205	1	91-04-12 1090/200/	ALL

EQUIPMENT LIST

D280N032

Section AD1000
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AD1148		287N4403 DISC BKT-R. SPOILER DISC R. WHEEL WELL	287N4415 81205	1	91-04-12 1147/190/R068	ALL

EQUIPMENT LIST

D280N032

Section AD1100

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0101		287N4301 DISC BKT-E1-1 SHELF DISC	284N1511 81205	1	91-04-19 0430/188/R021	ALL
AE0102		287N4301 DISC BKT-E1-2 SHELF DISC	284N1512 81205	1	91-04-07 0430/178/R021	ALL

EQUIPMENT LIST

D280N032

Section AE0100
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0201		287N4301 DISC BKT-E2-1 SHELF DISC	284N1521 81205	1	91-04-07 0430/178/R021	ALL
AE0202		287N4301-348 DISC BKT-E2-2 SHELF DISC	284N1522 81205	1	91-04-07 0430/178/R021	ALL
AE0203		287N4301 DISC BKT-E2-3 SHELF DISC	284N1523 81205	1	91-04-07 0430/178/R021	ALL
AE0204		287N4301 DISC BKT-E2-4 SHELF DISC	284N1524 81205	1	91-04-07 0440/178/R021	ALL

EQUIPMENT LIST

D280N032

Section AE0200

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0301		287N4301 DISC BKT-E3-1 SHELF DISC	284N1531 81205	1	91-04-08 0440/188/L021	ALL
AE0302		287N4301 DISC BKT-E3-2 SHELF DISC	284N1532 81205	1	91-04-08 0440/178/L021	ALL
AE0303		287N4301 DISC BKT-E3-3 SHELF DISC	284N1533 81205	1	91-04-08 0440/168/L021	ALL
AE0304		287N4301 DISC BKT-E3-4 SHELF DISC	284N1534 81205	1	91-04-08 0440/158/L021	ALL

EQUIPMENT LIST

D280N032

Section AE0300
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0401		287N4301 DISC BKT-E4-1 SHELF DISC	284N1541 81205	1	91-04-08 0440/188/R021	ALL
AE0402		287N4301 DISC BKT-E4-2 SHELF DISC	284N1542 81205	1	91-04-08 0440/178/R021	ALL
AE0403		287N4301 DISC BKT-E4-3 SHELF DISC	284N1543 81205	1	91-04-08 0440/168/R021	ALL
AE0404		287N4301 DISC BKT-E4-4 SHELF DISC	TBDN0000 81205	1	91-04-08 0440/158/R021	ALL

EQUIPMENT LIST

D280N032

Section AE0400

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0501		287N4301 DISC BKT-E5-1 SHELF DISC	284N1551 81205	1	91-04-09 0560/188/R025	ALL
AE0502		287N4301 DISC BKT-E5-2 SHELF DISC	284N1552 81205	1	91-04-09 0560/178/R025	ALL
AE0503		287N4301 DISC BKT-E5-3 SHELF DISC	284N1553 81205	1	91-04-09 0560/168/R025	ALL

EQUIPMENT LIST

D280N032

Section AE0500
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0600		287N4301 DISC BKT-E6 SHELF DISC	TBDN0000 81205	1	91-04-13 / /	ALL
AE0601		287N4301 DISC BKT-E6-1 SHELF DISC	284N1561 81205	1	91-04-13 E006-01/ /	ALL
AE0602		287N4301 DISC BKT-E6-2 SHELF DISC	284N1562 81205	1	91-04-13 / /	ALL
AE0603		287N4301 DISC BKT-E6-3 SHELF DISC	284N1563 81205	1	91-04-13 / /	ALL
AE0604		287N4301 DISC BKT-E6-4 SHELF DISC	284N1564 81205	1	91-04-13 / /	115-199

EQUIPMENT LIST

D280N032

Section AE0600

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0001		287N4117 DISC BKT-CAPT. INSTRUMENT PANEL DISC-L	287N4103 81205	1	91-04-02 0223/205/L040	ALL
AP0003		287N4117 DISC BKT-F/O INSTRUMENT PANEL DISC-L	287N4103 81205	1	91-04-02 0223/205/R040	ALL
AP0005		287N4120 DISC BKT-PILOTS OVERHEAD PANEL DISC	287N4103 81205	1	91-04-03 0278/275/L008	ALL
AP0006		287N4102 DISC BKT-MAIN PWR DISTRIBUTION PNL DISC	287N4101 81205	1	91-04-03 0297/220/L050	ALL
AP0010		254N1119 DISC BKT-QUADRANT STAND	TBDN0000 81205	1	91-04-02 / /	ALL
AP0011		287N4123 DISC BKT-CIRCUIT BREAKER PANEL	287N4103 81205	1	91-04-03 AP0011/ /	ALL
AP0026		285N0001 DISC BKT-MASTER DIMMER AND TEST UNIT	TBDN0000 81205	1	91-04-03 / /	ALL
AP0031		284N1314 DISC BKT-LEFT GEN SHIELD	284N1317 81205	1	91-04-05 0400/160/	ALL
AP0032		284N1315 DISC BKT-RIGHT GEN SHIELD	284N1307 81205	1	91-04-05 0400/160/R020	ALL
AP0033		284N1318 DISC BKT-MISCELLANEOUS RELAY PANEL	284N1325 81205	1	91-04-05 0357/168/R025	ALL
AP0034		284N1317 DISC BKT-APU/EXT POWER SHIELD	284N1317 81205	1	91-04-05 0400/165/L040	ALL
AP0036		287N1403 DISC BKT-LEFT MISCELLANEOUS RELAY PANEL	287N1402 81205	1	91-04-09 0520/180/R040	ALL
AP0037		287N1113 DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL	287N1114 81205	1	91-04-06 0440/170/R044	ALL
AP0050		285N0032 DISC BKT-ELECTRICAL SYSTEM CARD FILE	284N1329 81205	1	91-04-06 0425/176/R050	ALL
AP0051		285N0005 DISC BKT-WARNING ELECTRONICS UNIT	284N1329 81205	1	91-04-06 0415/176/R050	ALL
AP0054		285N0031 DISC BKT-FIRE DETECTION CARD FILE	284N1329 81205	1	91-04-06 0400/176/R050	ALL
AP0061		287N4121 DISC BKT-MAINTENANCE PANEL	287N4103 81205	1	91-04-03 0280/250/R040	ALL

EQUIPMENT LIST

D280N032

Section AP0000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0065		287N4301 DISC BKT-MISCELLANEOUS EQUIPMENT PANEL	287N4319 81205	1	91-04-04 0470/152/R023	ALL
AP0070		284N1129 DISC BKT-RELAY PANEL	284N1547 81205	1	91-04-09 0465/183/L045	ALL
AP0071		284N1790 DISC BKT-HYDRAULIC GENERATOR CONTROL	284N1790 81205	1	91-04-06 P071-00/ /	001-099
AP0071		284N1790 DISC BKT-HYDRAULIC GENERATOR CONTROL	284N1790 81205	1	91-04-06 520/189/R054	115-199

EQUIPMENT LIST

D280N032

Section AP0000

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0101		233T2214 DISC BKT-CAPT. INSTRUMENT PANEL DISC-L	TBDN0000 81205	1	91-04-02 / /	ALL
AP0103		233T2214 DISC BKT-CAPTAINS INSTRUMENT PANEL DISC	TBDN0000 81205	1	91-04-02 / /	ALL

EQUIPMENT LIST

D280N032

Section AP0100
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0301		233T2214 DISC BKT-F/O INSTRUMENT PANEL DISC-L	TBDN0000 81205	1	91-04-02 229/230/C000	ALL
AP0303		233T2214 DISC BKT-F/O INSTRUMENT PANEL DISC	TBDN0000 81205	1	91-04-02 / /	ALL

EQUIPMENT LIST

D280N032

Section AP0300

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AS1080		TBDN0000 DISC BKT-L. ENG. STRUT FIREWALL	TBDN0000 81205	1	91-04-10 / /	ALL
■ AS1090		114N1319 DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL	TBDN0000 81205	1	91-04-10 /285/	ALL

EQUIPMENT LIST

D280N032

Section AS1000
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AS1123		TBDN0000 DISC BKT-LEFT ENGINE STRUT VAPOR SEAL	TBDN0000 81205	1	91-04-10 / /	ALL
AS1140		TBDN0000 DISC BKT-LEFT HORIZ ENG. STRUT FIREWALL	TBDN0000 81205	1	91-04-10 / /	ALL
I AS1180		114N1319 DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL	TBDN0000 81205	1	91-04-10 /285/	ALL

EQUIPMENT LIST

D280N032

Section AS1100

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AS2080		TBDN0000 DISC BKT-R. ENG. STRUT FIREWALL	TBDN0000 81205	1	91-04-10 / /	ALL
I AS2090		114N1319 DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL	TBDN0000 81205	1	91-04-10 /285/	ALL

EQUIPMENT LIST

D280N032

Section AS2000
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AS2123		TBDN0000 DISC BKT-RIGHT ENGINE STRUT VAPOR SEAL	TBDN0000 81205	1	91-04-10 / /	ALL
AS2140		TBDN0000 DISC BKT-RIGHT HORIZ ENG. STRUT FIREWALL	TBDN0000 81205	1	91-04-10 / /	ALL
I AS2180		114N1319 DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL	TBDN0000 81205	1	91-04-10 /285/	ALL

EQUIPMENT LIST

D280N032

Section AS2100

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AT1883		148N8402 DISC BKT-APU FIREWALL DISCONNECT	TBDN0000 81205	1	91-04-14 1883/240/R035	ALL

EQUIPMENT LIST

D280N032

Section AT1800
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW1156		287N1301 DISC BKT-LEFT WING REAR SPAR	287N1301 81205	1	91-04-11 0159/ /	ALL
AW1164		287N1301 DISC BKT-RIGHT WING REAR SPAR	287N1301 81205	1	91-04-11 0166/ /	ALL
AW1179		287N1301 DISC BKT-LEFT WING REAR SPAR	287N1301 81205	1	91-04-11 0182/ /	ALL
AW1180		287N1301 DISC BKT-LEFT WING REAR SPAR	287N1301 81205	1	91-04-11 0159/ /	ALL

EQUIPMENT LIST

D280N032

Section AW1100

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW1240		287N1301 DISC BKT-LEFT WING REAR SPAR	287N1301 81205	1	91-04-11 0242/ /	ALL
AW1285		114N1319 DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL	TBDN0000 81205	1	91-04-11 FSS285/ /L	ALL

EQUIPMENT LIST

D280N032

Section AW1200
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW1333		114N2122 DISC BKT-L. ENG. STRUT OUTBD CLOSURE RIB	TBDN0000 81205	1	91-04-11 / /	ALL

EQUIPMENT LIST

D280N032

Section AW1300

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW2156		287N1301 DISC BKT-RIGHT WING REAR SPAR	287N1301 81205	1	91-04-11 0159/ /	ALL
AW2164		287N1301 DISC BKT-RIGHT WING REAR SPAR	TBDN0000 81205	1	91-04-11 0166/ /	ALL
AW2179		287N1301 DISC BKT-RIGHT WING REAR SPAR	287N1301 81205	1	91-04-11 0182/ /	ALL
AW2180		287N1301 DISC BKT-RIGHT WING REAR SPAR	287N1301 81205	1	91-04-11 0182/ /	ALL

EQUIPMENT LIST

D280N032

Section AW2100

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW2240		287N1301 DISC BKT-RIGHT WING REAR SPAR	287N1301 81205	1	91-04-11 0242/ /	ALL
AW2285		114N1319 DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL	TBDN0000 81205	1	91-04-11 FSS285/ /R	ALL

EQUIPMENT LIST

D280N032

Section AW2200

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW2333		114N2122 DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB	TBDN0000 81205	1	91-04-11 / /	ALL

EQUIPMENT LIST

D280N032

Section AW2300
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW2493		287N1401 DISC BKT-WING LE STRUT	114N2125 81205	1	91-04-11 0493/ /	ALL

EQUIPMENT LIST

D280N032

Section AW2400

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00001		S222T100-102 SPEAKER-COCKPIT,CAPT	232N4312 81205	1	23-51-11 / /	ALL
B00002		S222T100-102 SPEAKER-COCKPIT,F/O	232N4312 81205	1	23-51-21 / /	ALL
B00003		64000-002 MIC/HEADSET-BOOM,CAPT	230N0101 22711	1	23-51-11 / /	001-099
B00003		MS50-T30-1 MIC/HEADSET-BOOM,CAPT	230N0101 22447	1	23-51-11 / /	115-199
B00004		64000-002 MIC/HEADSET-BOOM,F/O	230N0101 22711	1	23-51-21 / /	001-099
B00004		MS50-T30-1 MIC/HEADSET-BOOM,F/O	230N0101 22447	1	23-51-21 / /	115-199
B00010		S210N701-4 FAN 1-EQPT COOLING	217N1015 81205	1	21-58-13 0520/185/L052	ALL
B00011		S210N701-4 FAN 2-EQPT COOLING	217N1015 81205	1	21-58-13 0520/175/L045	ALL
B00013		10-62009-4 FAN-RECIRC,L	217N1017 81205	1	21-25-11 0522/196/L055	ALL
B00014		S210T130-618 FAN-RECIRC,R	214N5001 81205	1	21-25-11 0869/173/R055	ALL
B00015		S210N701-10 FAN 2-AFT EQPT/LAV/GALLEY VENT	214N3012 81205	1	21-58-21 1679/173/L023	001-006, 115-199
B00015		S210N701-38 FAN 2-AFT EQPT/LAV/GALLEY VENT	214N3009 81205	1	21-58-21 1679/173/L023	007-099
B00016		S210N701-10 FAN 1-AFT EQPT/LAV/GALLEY VENT	214N3012 81205	1	21-58-21 1679/173/L006	001-006, 115-199
B00016		S210N701-38 FAN 1-AFT EQPT/LAV/GALLEY VENT	214N3009 81205	1	21-58-21 1666/173/L023	007-099
B00017		S332T011-18 BOTTLE 1-ENGINE	312N5503 81205	1	26-21-11 1191/185/R037	ALL
B00018		S332T011-18 BOTTLE 2-ENGINE	312N5503 81205	1	26-21-11 1191/185/R048	ALL
B00025		S332T011-18 BOTTLE-APU FIRE EXT	355N5201 81205	1	26-22-21 1879/230/R025	ALL

EQUIPMENT LIST

D280N032

Section B00000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00026		S232N911-2 PITOT PROBE-CAPT	232N9001 81205	1	30-31-11 0210/208/L037	ALL
B00027		S232N911-2 PITOT PROBE-AUX,L	232N9001 81205	1	30-31-11 0210/220/L037	ALL
B00028		S232N911-2 PITOT PROBE-F/O	232N9001 81205	1	30-31-12 0210/208/R037	ALL
B00029		S232N911-2 PITOT PROBE-AUX,R	232N9001 81205	1	30-31-12 0210/220/R037	ALL
B00031		2831-1 HEATER-ELECTRIC,SHOULDER AIR,(CAPT)	214N1008 98085	1	21-45-11 0263/193/L047	ALL
B00033		2831-1 HEATER-ELECTRIC,SHOULDER AIR,(F/O)	214N1009 98085	1	21-45-11 0263/193/R047	ALL
B00035		141T4800-13 WINDOW 1,L	141N0003 32925	1	30-41-11 0219/230/L020	ALL
B00036		141N4850-1 WINDOW 2,L	141N0012 53117	1	30-41-12 0239/230/L035	ALL
B00037		141N4820-1 WINDOW 3,L	141N0004 53117	1	30-41-12 0263/230/L048	ALL
B00038		141T4800-14 WINDOW 1,R	141N0003 32925	1	30-41-12 0219/230/R020	ALL
B00039		141N4850-2 WINDOW 2,R	141N0012 53117	1	30-41-11 0239/230/R035	ALL
B00040		141N4820-2 WINDOW 3,R	141N0004 53117	1	30-41-11 0263/230/R048	ALL
B00041		10-61434-2 HTR-FWD DRAIN MAST	417N2105 81205	1	30-71-11 0871/140/L015	ALL
B00042		10-61434-2 HTR-AFT DRAIN MAST	417N2303 81205	1	30-71-11 1670/170/R025	ALL
B00043		10-60795-1 HTR GASKET-FWD TOILET DRAIN LAV "A"	417N8201 81205	1	30-71-21 425/160/L010	001-099
B00043		10-60795-1 HTR GASKET-FWD TOILET DRAIN LAV "A"	417N8201 81205	1	30-71-21 425/150/L011	115-199
B00056		S222T100-202 LOUDSPEAKER-AURAL WARNING,L	232N5030 81205	1	31-51-11 0250/252/L050	ALL

EQUIPMENT LIST

D280N032

Section B00000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00057		S222T100-202 LOUDSPEAKER-AURAL WARNING,R	232N5030 81205	1	31-51-12 0250/252/R050	ALL
B00060		430-M1 HORN-GND CREW CALL	284N1408 80252	1	23-43-11 0330/171/L020	ALL
B00061		285T0412-1 HANDSET-ATTENDANT	417N6019 81205	4	23-42-11 MULTI/ /	001-099
B00061		285N0412-1 HANDSET-ATTENDANT	417N6019 81205	4	23-42-11 MULTI/ /	115-199
B00066		S283T012-14 CABLE ASSY-ANTI COLL LT,WING TIP	284N1113 81205	2	33-44-21 MULTI/ /	ALL
B00067		S283T012-24 CABLE ASSY-ANTI COLL LT,UPR	284N1357 81205	1	33-44-11 0586/306/R004	ALL
B00068		S283T012-15 CABLE ASSY-ANTI COLL LT,LWR	284N1442 81205	1	33-44-11 1050/135/	ALL
B00085		3100-101-4 THERMOSTAT-DRAIN LINE HTR BLNKT LAV "A"	417N8202 14604	1	30-71-21 425/160/L030	001-099
B00085		3100-101-4 THERMOSTAT-DRAIN LINE HTR BLNKT LAV "A"	417N8202 14604	1	30-71-21 425/157/L030	115-199
B00092		10-60795-1 HTR GASKET-TOILET DRAIN LAV "B","C"OR"D"	417N8301 81205	1	30-71-21 1185/139/	001-099
B00092		10-60795-1 HTR GASKET-TOILET DRAIN LAV "B","C"OR"D"	417N8301 81205	1	30-71-21 1188/139/R010	115-199

EQUIPMENT LIST

D280N032

Section B00000

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00107		S417N801-11 HTR BLANKET-DRAIN LINE LAV "A"	417N8202 81205	1	30-71-21 0425/160/L015	ALL
B00109		S417N204-13 HTR TAPE-WATER SUPPLY LINE	417N8301 81205	1	30-71-21 1665/182/R050	115-199
B00111		S417N204-11 HTR TAPE-WATER SUPPLY LINE	417N8301 81205	1	30-71-21 1665/182/R050	115-199
B00113		S417N204-13 HTR TAPE-WATER SUPPLY LINE	417N8301 81205	1	30-71-21 1663/182/R053	115-199
B00114		S417N204-14 HTR TAPE-WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1619/198/R045	115-199
B00116		S417N204-18 HTR TAPE-WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1650/165/R016	115-199
B00117		S417N801-29 HTR BLANKET-DRAIN LINE LAV "A"	417N8202 81205	1	30-71-21 0425/157/L017	001-099
B00117		S417N801-12 HTR BLANKET-DRAIN LINE LAV "A"	417N8201 81205	1	30-71-21 0425/157/L017	115-199
B00118		S417N204-17 HTR TAPE-WATER SUPPLY LINE	417N2322 81205	1	30-71-21 0857/154/L017	002-099, 115-199
B00122		9643 HORN-APU FIRE WARNING	284N1761 80252	1	26-15-12 P062-00/ /	ALL
B00129		FHN20G FUSEHOLDER-EXT PWR INTERLOCK	284N1316 96906	1	24-41-11 P034-00/ /	ALL
B00129 T		322001 FUSE-EXT PWR INTERLOCK	284N1316 75915	1	24-41-11 P034-00/ /	ALL
B00130		FHN20G FUSEHOLDER-EXT PWR INTERLOCK	284N1316 96906	1	24-41-11 P034-00/ /	ALL
B00130 T		322001 FUSE-EXT PWR INTERLOCK	284N1316 75915	1	24-41-11 P034-00/ /	ALL
B00144		S222T102-101 CHIME-FWD ATT L	411N3210 81205	1	23-42-12 0360/288/R002	115-199
B00145		S222T102-101 CHIME-MID ATT R	411N3210 81205	1	23-42-12 1315/289/	115-199
B00148		S222T102-101 CHIME-AFT ATT L	411N3210 81205	1	23-42-12 1648/288/L019	115-199

EQUIPMENT LIST

D280N032

Section B00100

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B09001	9	603-8465 HAND MIC	C0CWD02 81134	1	23-51-16 P008-00/ /	115-199

EQUIPMENT LIST

D280N032

Section B09000
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B10003		S210N701-10 FAN-HEAT,FWD CARGO	215N3003 81205	1	21-43-11 0860/185/R054	ALL
B10004		L962666 N1 BALANCE PROBE	10E80008 K0680	2	77-31-11 P ENG/ /	ALL
B10005		L961716 PROBE-N1 SPEED 1	10E80008 K0680	2	77-12-11 ENG/ /	ALL
B10006		L961716 PROBE-N1 SPEED 2	10E80008 K0680	2	77-12-11 ENG/ /	ALL
B10007		L961716 PROBE-N2 SPEED 1	10E80008 K0680	2	77-12-21 ENG/ /	ALL
B10008		L961716 PROBE-N2 SPEED 2	10E80008 K0680	2	77-12-21 ENG/ /	ALL
B10009		L961716 PROBE-N2 SPEED 3	1E80008 K0680	2	77-12-21 P ENG/ /	ALL
B10010		L954004 HEATER-P1 PROBE	LJ35846 K0680	2	30-34-21 ENG/ /	ALL
B10029		S210N701-15 FAN-HTR,AFT CARGO	215N3006 81205	1	21-44-11 1195/179/L012	001-006, 115-199
B10029		S210N701-37 FAN-HTR,AFT CARGO	215N3006 81205	1	21-44-11 1195/179/L012	007-099
B10030		S210N701-10 FAN-HEAT,AFT CARGO	215N3006 81205	1	21-44-11 1195/179/R010	ALL
B10032		129-6-M06 TEE-COAXIAL CONNECTOR	287N4301 91836	1	34-53-11 E003-03/ /	ALL
B10037		3775-000 HEADPHONE-2/OBS	230N0101 22711	1	23-51-41 P061-00/ /	001-099
B10044		S214N101-3 HEATER-ELECTRIC,FOOT,(CAPT,LEFT)	214N1005 81205	1	21-45-11 0226/200/L028	ALL
B10045		S214N101-3 HEATER-ELECTRIC,FOOT,(CAPT,RIGHT)	214N1005 81205	1	21-45-11 0226/200/L013	ALL
B10046		S214N101-3 HEATER-ELECTRIC,FOOT,(F/O,RIGHT)	214N1005 81205	1	21-45-11 0226/200/R028	ALL
B10047		S214N101-3 HEATER-ELECTRIC,FOOT,(F/O,LEFT)	214N1005 81205	1	21-45-11 0226/200/R013	ALL

EQUIPMENT LIST

D280N032

Section B10000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B10049		64000-002 MIC/HEADSET-BOOM,FIRST OBSERVER	230N0101 22711	1	23-51-41 / /	001-099
B10049		MS50-T30-1 MIC/HEADSET-BOOM,FIRST OBSERVER	230N0101 22447	1	23-51-41 / /	115-199
B10054		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	67	35-21-31 MULTI/ /	001-003, 005, 007-099
B10054		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	68	35-21-31 MULTI/ /	004, 006
B10054		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	72	35-21-31 MULTI/ /	115-199
B10055		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	2	35-21-31 MULTI/ /	001-099
B10055		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	1	35-21-31 MULTI/ /	115-199
B10056		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	1	35-21-31 MULTI/ /	001-099
B10056		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	3	35-21-31 MULTI/ /	115-199
B10057		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	1	35-21-31 MULTI/ /	ALL
B10058		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	2	35-21-31 MULTI/ /	001-099
B10059		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	3	35-21-31 MULTI/*	ALL
B10061		S210N701-33 FAN 1-SUPPLY,EQPT COOLING,AFT	217N1023 81205	1	21-58-24 1520/192/R058	115-199
B10062		S210N701-33 FAN 2-SUPPLY,EQUIP COOLING,AFT	217N1023 81205	1	21-58-24 1520/193/R058	115-199
B10063		10-61479-2 HTR-FWD DRAIN MAST COILED HOSE	417N2105 81205	1	30-71-11 0871/140/L015	ALL
B10064		3100-101-3 THERMOSTAT-HTR TAPE CONT	417N2105 14604	1	30-71-11 0871/140/L015	ALL
B10067		S417T402-2-PROV- ACTUATOR-PASS OXY LATCH,LAV	417N3152 81205	4	35-21-31 MULTI/*	001-099

EQUIPMENT LIST

D280N032

Section B10000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B10067		S417T402-2 ACTUATOR-PASS OXY LATCH,LAV	417N3152 81205	4	35-21-31 MULTI/* /	115-199
B10068		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	1	35-21-31 MULTI/ /	115-199
B10071		S417T402-2 ACTUATOR-PASS OXY LATCH	417N3152 81205	1	35-21-11 MULTI/ /	004-099
B10074		S417N204-48 HTR BLANKET-WATER SUPPLY VALVE	417N2322 81205	1	30-71-21 1670/202/L009	001-099

EQUIPMENT LIST

D280N032

Section B10000

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B10101		S222T102-101 CHIME-MID ATT L	411N3210 81205	1	23-42-12 685.5/ /L029	115-199
B10102		S417N801-31 HTR BLANKET-FWD DRAIN LINE LAV"S"	417N8504 81205	1	30-71-21 705/188/L055	001-099
B10105		3100-101-3 THERMOSTAT-WTR SUPPLY LINE HTR TAPE	417N8404 14604	1	30-71-21 1670/170/R008	115-199
B10110		S222T101-101 SPEAKER-MUTED AFT	411N3210 81205	1	23-31-22 1650/290/R010	ALL
B10111		S222T101-101 SPEAKER-MUTED FWD	411N3210 81205	1	23-31-21 340/295/R019	001-099
B10111		ST222T101-10 SPEAKER-MUTED FWD	657N3560 81205	1	23-31-21 340/288/R015	115-199
B10112		S222T101-101 SPEAKER-MUTED FWD	411N3210 81205	1	23-31-21 0367/295/L010	ALL
B10114		S222T101-101 SPEAKER-MID	411N3210 81205	1	23-31-31 0712/280/L060	001-099
B10114		S222T101-101 SPEAKER-MUTED MID	411N3210 81205	1	23-31-31 0700/280/R020	115-199
B10116		S222T101-101 SPEAKER-MUTED MID	411N3210 81205	1	23-31-16 0700/280/R060	ALL
B10122		10-60795-1 HTR GASKET-TOILET DRAIN LAV "S & T"	417N8501 81205	1	30-71-21 710/180/L055	001-099
B10126		S417N204-32 HTR TAPE-DRAIN LINE LAV "B" OR "C"	417N8302 81205	1	30-71-21 1188/138/	001
B10126		S417N204-32 HTR TAPE-DRAIN LINE LAV "B" OR "C"	417N8301 81205	1	30-71-21 1187/138/L002	115-199
B10127		S417N204-33 HTR TAPE-DRAIN LINE LAV "D"	417N8302 81205	1	30-71-21 1188/146/	001-099
B10127		S417N204-32 HTR TAPE-DRAIN LINE LAV "D"	417N8301 81205	1	30-71-21 1187/145/R004	115-199
B10133		S210N701-27 EQUIP COOLING AUXILIARY FAN	217N1152 81205	1	21-58-15 0425/190/L060	ALL
B10140		S222T101-101 SPEAKER-MUTED AFT	411N3210 81205	1	23-31-32 1650/290/L010	ALL

EQUIPMENT LIST

D280N032

Section B10100

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B10156		129-16-9 TNC ADAPTER	65-63844 91836	1	34-53-21 E003-02/ /	ALL

EQUIPMENT LIST

D280N032

Section B10100

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B10201		S417N204-23 HTR TAPE-WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1610/192/R056	001-099
B10217		S417N204-14 HTR TAPE-AFT WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1618/204/R050	001-099
B10219		S417N204-13 HTR TAPE-AFT WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1664/195/R052	001-099
B10220		S417N204-13 HTR TAPE-AFT WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1674/195/R052	001-099
B10221		S417N204-11 HTR TAPE-AFT WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1664/195/R052	001-099
B10222		S417N204-18 HTR TAPE-AFT WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1650/165/R019	001-099
B10223		3100-101-3 THERMOSTAT-AFT WATER SUPPLY LINE	417N2322 81205	1	30-71-21 1650/165/R019	001-099

EQUIPMENT LIST

D280N032

Section B10200

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00001		BACC18AD2 CB-AIR DATA AOA SENSOR L	233N5211 81205	1	34-12-11 P011-01/ /A011	001-099
C00001		BACC18AD2 CB-AIR DATA AOA SENSOR L	233N5205 81205	1	34-12-11 P011-01/ /A011	115-199
C00002		BACC18AD2 CB-AIR DATA BARO CORRECT L	233N5211 81205	1	34-12-11 P011-01/ /A012	001-099
C00002		BACC18AD2 CB-AIR DATA BARO CORRECT L	233N5205 81205	1	34-12-11 P011-01/ /A012	115-199
C00003		BACC18AD2 CB-AIR DATA AOA SENSOR R	233N5212 81205	1	34-12-21 P011-02/ /F031	001-099
C00003		BACC18AD2 CB-AIR DATA AOA SENSOR R	233N5206 81205	1	34-12-21 P011-02/ /F031	115-199
C00004		BACC18AD2 CB-AIR DATA BARO CORRECT R	233N5212 81205	1	34-12-21 P011-02/ /F032	001-099
C00004		BACC18AD2 CB-AIR DATA BARO CORRECT R	233N5206 81205	1	34-12-21 P011-02/ /F032	115-199
C00020		BACC18AD3 CB-APU START	284N1690 81205	1	49-61-11 E006-00/ /	001-099
C00020		BACC18AD3 CB-APU START	284N1662 81205	1	49-61-11 E006-00/ /	115-199
C00060		BACC18Z1R CB-SMOKE DET BLOWER 1	284N1129 81205	1	26-16-21 P070-00/ /B010	ALL
C00061		BACC18Z1R CB-SMOKE DET BLOWER 2	284N1129 81205	1	26-16-21 P070-00/ /B011	ALL
C00062		BACC18Z1R CB-SMOKE DET BLOWER 3	284N1129 81205	1	26-16-21 P070-00/ /B012	ALL
C00063		BACC18Z1R CB-SMOKE DET BLOWER 4	284N1129 81205	1	26-16-21 P070-00/ /B013	ALL
C00070		BACC18AD2 CB-L TANK DEFUELING VALVE	284N1129 81205	1	28-26-11 P070-00/ /B014	ALL
C00071		BACC18AD2 CB-R TANK DEFUELING VALVE	284N1129 81205	1	28-26-11 P070-00/ /B015	ALL
C00075		BACC18AD2 CB-FUELING PANEL DOOR LTS	284N1127 81205	1	28-21-11 P037-00/ /C004	001-099

EQUIPMENT LIST

D280N032

Section C00000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00089		BACC18AC2 CB-APU TRU FAN	284N1662 81205	1	24-32-41 E006-00/ /	ALL

EQUIPMENT LIST

D280N032

Section C00000
Page 2 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00301		BACC18AC7 CB-MAIN BATTERY CHARGER	284N1127 81205	1	24-31-11 P037-00/ /B002	ALL
C00302		10-60806-1015 CB-APU BATTERY CHARGER	284N1127 81205	1	24-31-41 P037-00/ /B005	001-099
C00302		BACC18AC7 CB-APU BATTERY CHARGER	284N1127 81205	1	24-31-41 P037-00/ /B005	115-199
C00304		BACC18AC3 CB-GROUND HANDLING TRU	284N1316 81205	1	24-54-61 P034-00/ /AB01	ALL
C00305		BACC18AE25 CB-GND HDLG EXT PWR	284N1316 81205	1	24-51-61 P034-00/ /CD02	001-099
C00305		10-60806-1050 CB-GND HDLG EXT PWR	284N1316 81205	1	24-51-61 P034-00/ /CD02	115-199
C00306		10-60806-1050 CB-GND SVCE BUS EXT PWR	284N1316 81205	1	24-51-52 P034-00/ /CE02	ALL
C00307		BACC18AE20 CB-115 VAC BUS R SECT 2	287N4102 81205	1	24-51-22 P006-04/ /A023	001-099
C00307		10-60806-1020 CB-115 VAC BUS R SECT 2	287N4102 81205	1	24-51-22 P006-04/ /A023	115-199
C00308		BACC18AE20 CB-115 VAC BUS L SECT 2	287N4102 81205	1	24-51-12 P006-03/ /A017	001-099
C00308		10-60806-1020 CB-115 VAC BUS L SECT 2	287N4102 81205	1	24-51-12 P006-03/ /A017	115-199
C00309		10-60806-1025 CB-GND HDLG BUS	284N1316 81205	1	24-51-61 P034-00/ /G002	115-199
C00310		BACC18AE35 CB-115 VAC BUS L SECT 3	287N4102 81205	1	24-51-13 P006-03/ /A014	001-099
C00310		10-60806-1035 CB-115 VAC BUS L SECT 3	287N4102 81205	1	24-51-13 P006-03/ /A014	115-199
C00311		BACC18AE35 CB-UTIL BUS LEFT	284N1314 81205	1	24-51-14 P031-00/ /A002	001-099
C00311		10-60806-1035 CB-UTIL BUS LEFT	284N1314 81205	1	24-51-14 P031-00/ /A002	115-199
C00312		BACC18AE20 CB-L TRU	287N4102 81205	1	24-32-11 P006-03/ /C017	001-099

EQUIPMENT LIST

D280N032

Section C00300

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00312		10-60806-1020 CB-L TRU	287N4102 81205	1	24-32-11 P006-03/ /C017	115-199
C00313		BACC18AE20 CB-115 VAC BUS L SECT 1	287N4102 81205	1	24-51-11 P006-03/ /C014	001-099
C00313		10-60806-1020 CB-115 VAC BUS L SECT 1	287N4102 81205	1	24-51-11 P006-03/ /C014	115-199
C00315		BACC18AE35 CB-UTIL BUS RIGHT	284N1315 81205	1	24-21-24 P032-00/ /A007	001-099
C00315		10-60806-1035 CB-UTIL BUS RIGHT	284N1315 81205	1	24-21-24 P032-00/ /A007	115-199
C00316		10-60806-1050 CB-R GEN GND SVCE BUS	284N1315 81205	1	24-51-52 P032-00/ /A008	ALL
C00317		10-60806-1050 CB-115 VAC BUS R SECT 3	287N4102 81205	1	24-51-23 P006-04/ /A020	ALL
C00318		BACC18AE20 CB-R TRU	287N4102 81205	1	24-32-11 P006-04/ /C023	001-099
C00318		10-60806-1020 CB-R TRU	287N4102 81205	1	24-32-11 P006-04/ /C023	115-199
C00319		BACC18AE20 CB-115 VAC BUS R SECT 1	287N4102 81205	1	24-51-21 P006-04/ /C020	001-099
C00319		10-60806-1020 CB-115 VAC BUS R SECT 1	287N4102 81205	1	24-51-21 P006-04/ /C020	115-199
C00320		BACC18AC3 CB-GROUND POWER BPCU	284N1316 81205	1	24-41-11 P034-00/ /AB02	ALL
C00321		BACC18AE25 CB-GND HDLG APU	284N1316 81205	1	24-51-61 P034-00/ /CB02	001-099
C00321		10-60806-1050 CB-GND HDLG APU	284N1316 81205	1	24-51-61 P034-00/ /CB02	115-199
C00322		10-60806-1050 CB-GND SVCE BUS APU	284N1316 81205	1	24-51-52 P034-00/ /CA02	ALL
C00323		BACC18AE15 CB-ALTN FLAP PWR	287N4102 81205	1	27-51-11 P006-04/ /D023	001-099
C00323		10-60806-1015 CB-ALTN FLAP PWR	287N4102 81205	1	27-51-11 P006-04/ /D023	115-199

EQUIPMENT LIST

D280N032

Section C00300

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00326		BACC18AE20 CB-115V AC BUS L XFR	287N4102 81205	1	24-51-15 P006-03/ /J017	001-099
C00326		BACC18AE20 CB-115V AC BUS L XFR	287N4102 81205	1	24-51-15 P006-04/ /J017	115-199
C00327		BACC18AC10 CB-115V AC BUS R XFR	287N4102 81205	1	24-51-21 P006-04/ /	001-002
C00327		BACC18AE20 CB-115V AC BUS R XFR	287N4102 81205	1	24-51-21 P006-04/ /J023	003-099
C00327		BACC18AC10 CB-115V AC BUS R XFR	287N4102 81205	1	24-51-21 P006-04/ /J023	115-199
C00331		BACC18AE15 CB-FWD EQUIP COOL SUPPLY FAN 1	287N4102 81205	1	21-58-13 P006-03/ /F017	001-099
C00331		10-60806-1015 CB-FWD EQUIP COOL SUPPLY FAN 1	287N4102 81205	1	21-58-13 P006-03/ /F017	115-199
C00332		BACC18AE15 CB-FWD EQUIP COOL SUPPLY FAN 2	287N4102 81205	1	21-58-13 P006-04/ /F023	001-099
C00332		10-60806-1015 CB-FWD EQUIP COOL SUPPLY FAN 2	287N4102 81205	1	21-58-13 P006-04/ /F023	115-199
C00333		BACC18AC7 CB-AFT EQUIP COOLING FAN EXH 2	284N1127 81205	1	21-58-21 P037-00/ /D005	ALL
C00334		BACC18AC7 CB-AFT EQUIP COOLING FAN EXH 2	284N1129 81205	1	21-58-21 P070-00/ /B002	ALL
C00336		BACC18AE20 CB-RECIRC FAN L	284N1129 81205	1	21-25-11 P070-00/ /C010	001-099
C00336		10-60806-20 CB-RECIRC FAN L	284N1129 81205	1	21-25-11 P070-00/ /C010	115-199
C00337		BACC18AE20 CB-RECIRC FAN R	284N1127 81205	1	21-25-11 P037-00/ /J005	001-099
C00337		10-60806-1020 CB-RECIRC FAN R	284N1127 81205	1	21-25-11 P037-00/ /J005	115-199
C00360		BACC18AC7 CB-1 CARGO DOOR	284N1316 81205	1	52-34-11 P034-00/ /AA01	ALL
C00361		BACC18AC7 CB-2 CARGO DOOR	284N1316 81205	1	52-35-11 P034-00/ /AA02	ALL

EQUIPMENT LIST

D280N032

Section C00300

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00366		BACC18AC7 CB-L AFT FUEL BOOST PUMP	287N4102 81205	1	28-22-11 P006-03/ /H014	ALL
C00368		BACC18AC7 CB-R FWD FUEL BOOST PUMP	287N4102 81205	1	28-22-11 P006-03/ /H017	ALL
C00369		BACC18AC10 CB-L FUEL OVRD PUMP	287N4102 81205	1	28-22-11 P006-03/ /F014	ALL
C00370		BACC18AC10 CB-R FUEL OVRD PUMP	287N4102 81205	1	28-22-11 P006-04/ /F020	ALL
C00371		BACC18AC7 CB-R AFT FUEL BOOST PUMP	287N4102 81205	1	28-22-11 P006-04/ /H020	ALL
C00372		BACC18AC7 CB-L FWD FUEL BOOST PUMP	287N4102 81205	1	28-22-11 P006-04/ /H023	ALL
C00391		BACC18AE25 CB-WINDOW HTR 1L	284N1129 81205	1	30-41-11 P070-00/ /C013	001-099
C00391		10-60806-25 CB-WINDOW HTR 1L	284N1129 81205	1	30-41-11 P070-00/ /C013	115-199
C00392		BACC18AE25 CB-WINDOW HTR 1R	284N1127 81205	1	30-41-12 P037-00/ /J002	001-099
C00392		10-60806-1025 CB-WINDOW HTR 1R	284N1127 81205	1	30-41-12 P037-00/ /J002	115-199
C00397		BACC18AC7 CB-POT WATER CPRSR	287N4102 81205	1	38-15-11 P006-04/ /K021	ALL

EQUIPMENT LIST

D280N032

Section C00300

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00501		BACC18AD2 CB-TMC AC	233N5211 81205	1	22-31-11 P011-01/ /F014	001-099
C00501		BACC18AD2 CB-TMC AC	233N5205 81205	1	22-31-11 P011-01/ /F014	115-199
C00512		BACC18AD5 CB-TMC SERVO	233N5211 81205	1	22-31-12 P011-01/ /F016	001-099
C00512		BACC18AD5 CB-TMC SERVO	233N5205 81205	1	22-31-12 P011-01/ /F016	115-199
C00513		BACC18AD2 CB-FLT CONT CMPTR PWR L	233N5211 81205	1	22-11-11 P011-01/ /E017	001-099
C00513		BACC18AD2 CB-FLT CONT CMPTR PWR L	233N5205 81205	1	22-11-11 P011-01/ /E017	115-199
C00514		BACC18AD2 CB-FLT CONT CMPTR PWR R	233N5212 81205	1	22-11-21 P011-02/ /E035	001-099
C00514		BACC18AD2 CB-FLT CONT CMPTR PWR R	233N5206 81205	1	22-11-21 P011-02/ /E035	115-199
C00515		BACC18AD2 CB-FLT CONT CMPTR PWR C	233N5212 81205	1	22-11-31 P011-02/ /E020	001-099
C00515		BACC18AD2 CB-FLT CONT CMPTR PWR C	233N5206 81205	1	22-11-31 P011-02/ /E020	115-199
C00516		BACC18AD2 CB-MODE CONT PNL L	233N5211 81205	1	22-11-12 P011-01/ /E016	001-099
C00516		BACC18AD2 CB-MODE CONT PNL L	233N5205 81205	1	22-11-12 P011-01/ /E016	115-199
C00517		BACC18AD2 CB-MODE CONT PNL R	233N5212 81205	1	22-11-22 P011-02/ /E034	001-099
C00517		BACC18AD2 CB-MODE CONT PNL R	233N5206 81205	1	22-11-22 P011-02/ /E034	115-199
C00520		BACC18AD2 CB-MAINT CONT DSPL	233N5213 81205	1	22-41-11 P011-03/ /S003	001-099
C00520		BACC18AD2 CB-MAINT CONT DSPL	233N5207 81205	1	22-41-11 P011-03/ /S006	115-199
C00521		BACC18AD2 CB-AUTO FLT WARN	233N5211 81205	1	22-11-32 P011-01/ /A017	001-099

EQUIPMENT LIST

D280N032

Section C00500

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00521		BACC18AD2 CB-AUTO FLT WARN	233N5205 81205	1	22-11-32 P011-01/ /A017	115-199
C00522		BACC18AD5 CB-FLT CONT CMPTR SERVO L	233N5211 81205	1	22-11-12 P011-01/ /E018	001-099
C00522		BACC18AD5 CB-FLT CONT CMPTR SERVO L	233N5205 81205	1	22-11-12 P011-01/ /E018	115-199
C00523		BACC18AD5 CB-FLT CONT CMPTR SERVO R	233N5212 81205	1	22-11-22 P011-02/ /E036	001-099
C00523		BACC18AD5 CB-FLT CONT CMPTR SERVO R	233N5206 81205	1	22-11-22 P011-02/ /E036	115-199
C00524		BACC18AD5 CB-FLT CONT CMPTR SERVO C	233N5212 81205	1	22-11-32 P011-02/ /E021	001-099
C00524		BACC18AD5 CB-FLT CONT CMPTR SERVO C	233N5206 81205	1	22-11-32 P011-02/ /E021	115-199
C00525		BACC18AD5 CB-TMC DC	233N5211 81205	1	22-31-12 P011-01/ /F015	001-099
C00525		BACC18AD5 CB-TMC DC	233N5205 81205	1	22-31-12 P011-01/ /F015	115-199
C00532		BACC18AD2 CB-VOICE RECORDER	233N5212 81205	1	23-71-11 P011-02/ /H033	001-099
C00532		BACC18AD2 CB-VOICE RECORDER	233N5206 81205	1	23-71-11 P011-02/ /H033	115-199
C00539		BACC18AD2 CB-SELCAL	233N5211 81205	1	23-21-11 P011-01/ /G003	ALL
C00544		BACC18AD10 CB-VHF COMM L	233N5211 81205	1	23-12-11 P011-01/ /C003	001-099
C00544		BACC18AD10 CB-VHF COMM L	233N5205 81205	1	23-12-11 P011-01/ /C003	115-199
C00545		BACC18AD10 CB-VHF COMM R	233N5212 81205	1	23-12-21 P011-02/ /G031	001-099
C00545		BACC18AD10 CB-VHF COMM R	233N5206 81205	1	23-12-21 P011-02/ /G031	115-199
C00546		BACC18AD10 CB-VHF COMM C	233N5211 81205	1	23-12-31 P011-01/ /G004	001-099

EQUIPMENT LIST

D280N032

Section C00500

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00548		BACC18AD7 CB-PASS ADRS AMPL	233N5212 81205	1	23-31-11 P011-02/ /C022	001-099
C00548		BACC18AD7 CB-PASS ADRS AMPL	233N5206 81205	1	23-31-11 P011-02/ /C022	115-199
C00550		BACC18AD2 CB-HYD GEN 28VDC SENSE	287N4102 81205	1	24-31-11 P006-02/ /C008	003-099
C00551		BACC18AD5 CB-INTERPHONE CABIN SERVICE	233N5212 81205	1	23-42-11 P011-02/ /C024	001-099
C00551		BACC18AD5 CB-INTERPHONE CABIN SERVICE	233N5206 81205	1	23-42-11 P011-02/ /C023	115-199
C00552		BACC18AD2 CB-INTERPHONE CAPT	233N5212 81205	1	23-51-11 P011-02/ /C025	001-099
C00553		BACC18AD2 CB-INTERPHONE F/O AUDIO	233N5212 81205	1	23-51-21 P011-02/ /C026	001-099
C00554		BACC18AD2 CB-INTERPHONE CAPT AUDIO	233N5212 81205	1	23-51-11 P011-02/ /G029	001-099
C00557		BACC18AD2 CB-INTERPHONE OBSR CAPT	233N5212 81205	1	23-51-21 P011-02/ /G030	001-099
C00560		BACC18AD2 CB-GND CALL	233N5212 81205	1	23-43-11 P011-02/ /H031	001-099
C00560		BACC18AD2 CB-GND CALL	233N5206 81205	1	23-43-11 P011-02/ /H031	115-199
C00561		BACC18AD3 CB-FLIGHT RECORDER AC	233N5213 81205	1	31-31-01 P011-03/ /J007	001-099
C00561		BACC18AD3 CB-FLIGHT RECORDER AC	233N5207 81205	1	31-31-01 P011-03/ /J007	115-199
C00563		BACC18AD2 CB-CLOCK TIME BASE L	287N4102 81205	1	31-25-11 P006-01/ /G002	ALL
C00564		BACC18AD2 CB-AIDS SENSOR	233N5213 81205	1	31-31-01 P011-03/ /S001	001-099
C00564		BACC18AD2 CB-AIDS SENSOR	233N5207 81205	1	31-31-01 P011-03/ /S001	115-199
C00565		BACC18AD2 CB-WARN ELEX A	233N5214 81205	1	31-51-11 P011-04/ /J033	001-099

EQUIPMENT LIST

D280N032

Section C00500

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00565		BACC18AD2 CB-WARN ELEX A	233N5208 81205	1	31-51-11 P011-04/ /J033	115-199
C00566		BACC18AD2 CB-WARN ELEX B	233N5211 81205	1	31-51-12 P011-01/ /B018	001-099
C00566		BACC18AD2 CB-WARN ELEX B	233N5205 81205	1	31-51-12 P011-01/ /B018	115-199
C00567		BACC18AD2 CB-AURAL WARN SPKR L	233N5211 81205	1	31-51-11 P011-01/ /B016	001-099
C00567		BACC18AD2 CB-AURAL WARN SPKR L	233N5205 81205	1	31-51-11 P011-01/ /B016	115-199
C00568		BACC18AD2 CB-AURAL WARN SPKR R	233N5212 81205	1	31-51-12 P011-02/ /H035	001-099
C00568		BACC18AD2 CB-AURAL WARN SPKR R	233N5206 81205	1	31-51-12 P011-02/ /H035	115-199
C00573		BACC18AD2 CB-CLOCK IND LEFT	233N5211 81205	1	31-25-11 P011-01/ /B017	001-099
C00573		BACC18AD2 CB-CLOCK IND L	233N5205 81205	1	31-25-11 P011-01/ /B017	115-199
C00574		BACC18AD2 CB-CLOCK IND RIGHT	233N5214 81205	1	31-25-11 P011-04/ /J035	001-099
C00574		BACC18AD2 CB-CLOCK IND RIGHT	233N5208 81205	1	31-25-11 P011-04/ /J035	115-199
C00576		BACC18AD2 CB-CLOCK TIME BASE R	287N4102 81205	1	31-25-11 P006-01/ /G003	ALL
C00578		BACC18AD2 CB-FLIGHT RECORDER DC	233N5213 81205	1	31-31-11 P011-03/ /J008	001-099
C00578		BACC18AD2 CB-FLIGHT RECORDER DC	233N5207 81205	1	31-31-11 P011-03/ /J008	115-199
C00580		BACC18AD2 CB-IAS MACH L	233N5211 81205	1	34-13-11 P011-01/ /E001	001-099
C00580		BACC18AD2 CB-IAS MACH L	233N5205 81205	1	34-13-11 P011-01/ /E001	115-199
C00581		BACC18AD2 CB-IAS MACH R	233N5212 81205	1	34-13-21 P011-02/ /E022	001-099

EQUIPMENT LIST

D280N032

Section C00500

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00581		BACC18AD2 CB-IAS MACH R	233N5206 81205	1	34-13-21 P011-02/ /E022	115-199
C00582		BACC18Z02R CB-DME L	233N5211 81205	1	34-55-11 P011-01/ /E011	001-099
C00582		BACC18Z02R CB-DME L	233N5205 81205	1	34-55-11 P011-01/ /E011	115-199
C00583		BACC18Z02R CB-DME R	233N5212 81205	1	34-55-21 P011-02/ /E032	001-099
C00583		BACC18Z02R CB-DME R	233N5206 81205	1	34-55-21 P011-02/ /E032	115-199
C00584		BACC18AD2 CB-ALTM L	233N5211 81205	1	34-13-11 P011-01/ /E002	001-099
C00584		BACC18AD2 CB-ALTM L	233N5205 81205	1	34-13-11 P011-01/ /E002	115-199
C00585		BACC18AD2 CB-ALTM R	233N5212 81205	1	34-13-21 P011-02/ /E023	001-099
C00585		BACC18AD2 CB-ALTM R	233N5206 81205	1	34-13-21 P011-02/ /E023	115-199
C00586		BACC18AD2 CB-VSI L	233N5211 81205	1	34-22-82 P011-01/ /E005	001-099
C00586		BACC18AD2 CB-VSI L	233N5205 81205	1	34-22-82 P011-01/ /E005	115-199
C00587		BACC18AD2 CB-VSI R	233N5212 81205	1	34-22-92 P011-02/ /E026	001-099
C00587		BACC18AD2 CB-VSI R	233N5206 81205	1	34-22-92 P011-02/ /E026	115-199
C00588		BACC18AD2 CB-HSI L	233N5211 81205	1	34-22-16 P011-01/ /E006	001-099
C00588		BACC18AD2 CB-HSI L	233N5205 81205	1	34-22-16 P011-01/ /E006	115-199
C00589		BACC18AD2 CB-HSI R	233N5212 81205	1	34-22-26 P011-02/ /E027	001-099
C00589		BACC18AD2 CB-HSI R	233N5206 81205	1	34-22-26 P011-02/ /E027	115-199

EQUIPMENT LIST

D280N032

Section C00500

Page 5

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00591		BACC18AD2 CB-STBY ALTM VIB	233N5211 81205	1	34-13-11 P011-01/ /A008	001-099
C00591		BACC18AD2 CB-STBY ALTM VIB	233N5205 81205	1	34-13-11 P011-01/ /A008	115-199
C00592		BACC18Z02R CB-GND PROX CMPTR	233N5211 81205	1	34-46-11 P011-01/ /F004	001-099
C00592		BACC18Z02R CB-GND PROX CMPTR	233N5205 81205	1	34-46-11 P011-01/ /F004	115-199
C00593		BACC18AD2 CB-ADI L	233N5211 81205	1	34-22-16 P011-01/ /E003	001-099
C00593		BACC18AD2 CB-ADI L	233N5205 81205	1	34-22-16 P011-01/ /E003	115-199
C00594		BACC18AD2 CB-ADI R	233N5212 81205	1	34-22-26 P011-02/ /E024	001-099
C00594		BACC18AD2 CB-ADI R	233N5206 81205	1	34-22-26 P011-02/ /E024	115-199
C00595		BACC18Z02R CB-VOR/MKR L	233N5211 81205	1	34-51-11 P011-01/ /A002	001-099
C00595		BACC18Z02R CB-VOR/MKR L	233N5205 81205	1	34-51-11 P011-01/ /A002	115-199
C00596		BACC18Z02R CB-VOR R	233N5212 81205	1	34-51-21 P011-02/ /E033	001-099
C00596		BACC18Z02R CB-VOR R	233N5206 81205	1	34-51-21 P011-02/ /E033	115-199
C00597		BACC18AD2 CB-FMCS CDU L	233N5211 81205	1	34-61-11 P011-01/ /E008	001-099
C00597		BACC18AD2 CB-FMCS CDU L	233N5205 81205	1	34-61-11 P011-01/ /E008	115-199
C00598		BACC18AD2 CB-FMCS CDU R	233N5212 81205	1	34-61-21 P011-02/ /E029	001-099
C00598		BACC18AD2 CB-FMCS CDU R	233N5206 81205	1	34-61-21 P011-02/ /E029	115-199

EQUIPMENT LIST

D280N032

Section C00500

Page 6 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00600		BACC18Z02R CB-RAD ALTM L	233N5211 81205	1	34-33-11 P011-01/ /F005	001-099
C00600		BACC18Z02R CB-RAD ALTM L	233N5205 81205	1	34-33-11 P011-01/ /F005	115-199
C00601		BACC18Z02R CB-RAD ALTM R	233N5212 81205	1	34-33-21 P011-02/ /F026	001-099
C00601		BACC18Z02R CB-RAD ALTM R	233N5206 81205	1	34-33-21 P011-02/ /F026	115-199
C00602		BACC18Z02R CB-RAD ALTM C	233N5212 81205	1	34-33-31 P011-02/ /F020	001-099
C00602		BACC18Z02R CB-RAD ALTM C	233N5206 81205	1	34-33-31 P011-02/ /F020	115-199
C00603		BACC18Z02R CB-ILS L	233N5211 81205	1	34-31-11 P011-01/ /E010	001-099
C00604		BACC18AD2 CB-STBY ILS IND	233N5211 81205	1	34-24-11 P011-01/ /A009	001-099
C00604		BACC18AD2 CB-STBY ILS IND	233N5205 81205	1	34-24-11 P011-01/ /A009	115-199
C00605		BACC18Z02R CB-ILS R	233N5212 81205	1	34-31-21 P011-02/ /E031	001-099
C00606		BACC18Z02R CB-ILS C	233N5211 81205	1	34-31-31 P011-01/ /A003	001-099
C00607		BACC18Z02R CB-ADF L	233N5211 81205	1	34-57-11 P011-01/ /F006	001-099
C00607		BACC18Z02R CB-ADF L	233N5205 81205	1	34-57-11 P011-01/ /F006	115-199
C00609		BACC18AD5 CB-FMCS CMPTR L	233N5211 81205	1	34-61-11 P011-01/ /E009	001-099
C00609		BACC18AD5 CB-FMCS CMPTR L	233N5205 81205	1	34-61-11 P011-01/ /E009	115-199
C00610		BACC18AD5 CB-FMCS CMPTR R	233N5212 81205	1	34-61-21 P011-02/ /E030	001-099
C00610		BACC18AD5 CB-FMCS CMPTR R	233N5206 81205	1	34-61-21 P011-02/ /E030	115-199

EQUIPMENT LIST

D280N032

Section C00600

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00611		BACC18AD2 CB-IRS L	233N5211 81205	1	34-21-11 P011-01/ /F001	001-099
C00611		BACC18AD2 CB-IRS L	233N5205 81205	1	34-21-11 P011-01/ /F001	115-199
C00612		BACC18AD2 CB-IRS R	233N5212 81205	1	34-21-21 P011-02/ /F022	001-099
C00612		BACC18AD2 CB-IRS R	233N5206 81205	1	34-21-21 P011-02/ /F022	115-199
C00613		BACC18AD2 CB-IRS C	233N5212 81205	1	34-21-31 P011-02/ /F021	001-099
C00613		BACC18AD2 CB-IRS C	233N5206 81205	1	34-21-31 P011-02/ /F021	115-199
C00614		BACC18AD10 CB-IRS L	287N4102 81205	1	34-21-11 P006-01/ /D003	ALL
C00615		BACC18AD5 CB-WX RADAR L	233N5211 81205	1	34-43-11 P011-01/ /F002	ALL
C00619		BACC18AD5 CB-STBY ATT IND	233N5211 81205	1	34-24-11 P011-01/ /A005	001-099
C00619		BACC18AD5 CB-STBY ATT IND	233N5205 81205	1	34-24-11 P011-01/ /A005	115-199
C00620		BACC18AD10 CB-IRS R	287N4102 81205	1	34-21-21 P006-01/ /D005	ALL
C00621		BACC18AD10 CB-IRS C	287N4102 81205	1	34-21-31 P006-01/ /D004	ALL
C00622		BACC18AD2 CB-EFIS DSPL SW L	233N5211 81205	1	34-22-16 P011-01/ /A007	001-099
C00622		BACC18AD2 CB-EFIS DSPL SW L	233N5205 81205	1	34-22-16 P011-01/ /C004	115-199
C00623		BACC18AD2 CB-EFIS DSPL SW R	233N5212 81205	1	34-22-26 P011-02/ /F024	001-099
C00623		BACC18AD2 CB-EFIS DSPL SW R	233N5206 81205	1	34-22-26 P011-02/ /F024	115-199
C00625		BACC18Z1R CB-AIR DATA CMPTR L	233N5211 81205	1	34-12-11 P011-01/ /A010	001-099

EQUIPMENT LIST

D280N032

Section C00600

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00625		BACC18Z1R CB-AIR DATA CMPTR L	233N5205 81205	1	34-12-11 P011-01/ /A010	115-199
C00626		BACC18Z1R CB-AIR DATA CMPTR R	233N5212 81205	1	34-12-21 P011-02/ /F030	001-099
C00626		BACC18Z1R CB-AIR DATA CMPTR R	233N5206 81205	1	34-12-21 P011-02/ /F030	115-199
C00630		BACC18AD2 CB-FMC DATA BASE LOADER	284N1127 81205	1	34-61-15 P037-00/ /E008	001-008, 115-199
C00630		BACC18AD2 CB-FMC DATA BASE LOADER	233N5212 81205	1	34-61-15 P011-02/ /F027	009-099
C00633		BACC18AD2 CB-EFIS CONT PNL L	233N5211 81205	1	34-22-16 P011-01/ /E004	001-099
C00633		BACC18AD2 CB-EFIS CONT PNL L	233N5205 81205	1	34-22-16 P011-01/ /E004	115-199
C00634		BACC18AD2 CB-EFIS CONT PNL R	233N5212 81205	1	34-22-26 P011-02/ /E025	001-099
C00634		BACC18AD2 CB-EFIS CONT PNL R	233N5206 81205	1	34-22-26 P011-02/ /E025	115-199
C00635		BACC18AD2 CB-RDMI L	233N5211 81205	1	34-22-81 P011-01/ /A006	001-099
C00636		BACC18AD2 CB-RDMI R	233N5212 81205	1	34-22-91 P011-02/ /F025	001-099
C00637		BACC18AD2 CB-EFIS SYM GEN L	233N5211 81205	1	34-22-16 P011-01/ /F008	001-099
C00637		BACC18AD2 CB-EFIS SYM GEN L	233N5205 81205	1	34-22-16 P011-01/ /F008	115-199
C00638		BACC18AD2 CB-EFIS SYM GEN R	233N5212 81205	1	34-22-26 P011-02/ /F029	001-099
C00638		BACC18AD2 CB-EFIS SYM GEN R	233N5206 81205	1	34-22-26 P011-02/ /F029	115-199
C00639		BACC18AD2 CB-EFIS SYM GEN C	233N5211 81205	1	34-22-36 P011-01/ /F009	001-099
C00639		BACC18AD2 CB-EFIS SYM GEN C	233N5205 81205	1	34-22-36 P011-01/ /F009	115-199

EQUIPMENT LIST

D280N032

Section C00600

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00640	9	BACC18AD2 CB-FMC TUNING R (DEL SB 34-0427)	233N5212 81205	1	34-61-25 P011-02/ /F033	001
C00640	9	BACC18AD2 CB-FMC TUNING R - DELETE (SB 34-0414)	233N5206 81205	1	34-61-25 P011-02/ /F033	115-199
C00640		BACC18AD2 CB-FMC TUNING R	233N5212 81205	1	34-61-25 P011-02/ /F033	001-099
C00640		BACC18AD2 CB-FMC TUNING R	233N5206 81205	1	34-61-25 P011-02/ /F033	115-199
C00641	9	BACC18AD2 CB-FMC TUNING L (DEL SB 34-0427)	233N5211 81205	1	34-61-15 P011-01/ /F013	001
C00641	9	BACC18AD2 CB-FMC TUNING L - DELETE (SB 34-0414)	233N5205 81205	1	34-61-15 P011-01/ /F013	115-199
C00641		BACC18AD2 CB-FMC TUNING L	233N5211 81205	1	34-61-15 P011-01/ /F013	001-099
C00641		BACC18AD2 CB-FMC TUNING L	233N5205 81205	1	34-61-15 P011-01/ /F013	115-199
C00653		BACC18AD2 CB-AIR COND PACK LEFT FLOW CONT	233N5211 81205	1	21-51-11 P011-01/ /A014	001-099
C00653		BACC18AD2 CB-LEFT PACK FLOW CONT	233N5205 81205	1	21-51-11 P011-01/ /A015	115-199
C00658		BACC18AD2 CB-CABIN ALTITUDE CONTROL SEL	233N5211 81205	1	21-31-11 P011-01/ /B015	001-099
C00658		BACC18AD2 CB-CABIN ALTITUDE CONTROL SEL	233N5205 81205	1	21-31-11 P011-01/ /B015	115-199
C00660		BACC18AD2 CB-RECIRC CARGO FIRE CONT LEFT	233N5213 81205	1	21-25-11 P011-03/ /P014	001-099
C00660		BACC18AD2 CB-RECIRC CARGO FIRE CONT LEFT	233N5207 81205	1	21-25-11 P011-03/ /P014	115-199
C00661		BACC18AD2 CB-RECIRC CARGO FIRE CONT RIGHT	233N5214 81205	1	21-25-11 P011-04/ /P023	001-099
C00661		BACC18AD2 CB-RECIRC CARGO FIRE CONT RIGHT	233N5208 81205	1	21-25-11 P011-04/ /P023	115-199
C00662		BACC18AD5 CB-CAPT AUX HTR HI	284N1129 81205	1	21-45-11 P070-00/ /A006	ALL

EQUIPMENT LIST

D280N032

Section C00600

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00663		BACC18AD5 CB-CAPT AUX HTR LO	284N1129 81205	1	21-45-11 P070-00/ /A005	ALL
C00667		BACC18AD2 CB-CABIN ZONE CNTLR	233N5213 81205	1	21-61-51 P011-03/ /P016	001-099
C00667		BACC18AD2 CB-CABIN ZONE CNTLR	233N5207 81205	1	21-61-51 P011-03/ /P016	115-199
C00670		BACC18AD2 CB-CABIN TRIM AIR	233N5213 81205	1	21-61-51 P011-03/ /P015	001-099
C00670		BACC18AD2 CB-CABIN TRIM AIR	233N5207 81205	1	21-61-51 P011-03/ /P015	115-199
C00673		BACC18AD3 CB-LEFT PACK AUTO PWR	233N5213 81205	1	21-51-12 P011-03/ /M011	001-099
C00673		BACC18AD3 CB-LEFT PACK AUTO PWR	233N5207 81205	1	21-51-12 P011-03/ /M011	115-199
C00674		BACC18AD3 CB-RIGHT PACK AUTO PWR	233N5214 81205	1	21-51-22 P011-04/ /M019	001-099
C00674		BACC18AD3 CB-RIGHT PACK AUTO PWR	233N5208 81205	1	21-51-22 P011-04/ /M019	115-199
C00683		BACC18AD7 CB-CABIN ALT/PRESS MAN	233N5211 81205	1	21-31-31 P011-01/ /B014	001-099
C00683		BACC18AD7 CB-CABIN ALT/PRESS MAN	233N5205 81205	1	21-31-31 P011-01/ /B014	115-199
C00686		BACC18AD5 CB-CABIN ALT/PRESS AUTO 1	233N5213 81205	1	21-31-11 P011-03/ /N015	001-099
C00686		BACC18AD5 CB-CABIN ALT/PRESS AUTO 1	233N5207 81205	1	21-31-11 P011-03/ /N015	115-199
C00699		BACC18AD5 CB-HI F/O AUX HEATERS	284N1127 81205	1	21-45-11 P037-00/ /F004	ALL

EQUIPMENT LIST

D280N032

Section C00600

Page 5 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00700		BACC18AD5 CB-LO F/O AUX HEATERS	284N1127 81205	1	21-45-11 P037-00/ /F003	ALL
C00701		BACC18AD5 CB-CABIN ALTITUDE CONTROL AUTO 2	233N5214 81205	1	21-31-21 P011-04/ /N024	001-099
C00701		BACC18AD5 CB-CABIN ALTITUDE CONTROL AUTO 2	233N5208 81205	1	21-31-21 P011-04/ /N024	115-199
C00702		BACC18AD2 CB-AIR COND PACK LEFT AUTO CONT	233N5211 81205	1	21-51-12 P011-01/ /A013	001-099
C00702		BACC18AD2 CB-LEFT PACK AUTO CONT	233N5205 81205	1	21-51-12 P011-01/ /A014	115-199
C00703		BACC18AD2 CB-RIGHT PACK AUTO CONT	233N5212 81205	1	21-51-22 P011-02/ /A028	001-099
C00703		BACC18AD2 CB-RIGHT PACK AUTO CONT	233N5206 81205	1	21-51-22 P011-02/ /A028	115-199
C00704		BACC18AD2 CB-AIR COND PACK RIGHT FLOW CONT	233N5212 81205	1	21-51-21 P011-02/ /A029	001-099
C00704		BACC18AD2 CB-RIGHT PACK FLOW CONT	233N5206 81205	1	21-51-21 P011-02/ /A029	115-199
C00705		BACC18AD2 CB-EQUIP COOLING FAN CONT AFT EXH XFR	233N5213 81205	1	21-58-21 P011-03/ /N011	ALL
C00709		BACC18AD2 CB-PACK FLOW IND	233N5213 81205	1	21-52-31 P011-03/ /M017	001-099
C00709		BACC18AD2 CB-PACK FLOW IND	233N5207 81205	1	21-52-31 P011-03/ /M017	115-199
C00725	9	BACC18AD2 CB-FMS SW, L (SB 34-0427)	233N5211 81205	1	34-61-15 P011-01/ /E007	001
C00725	9	BACC18AD2 CB-FMS SW, L (SB 34-0414)	233N5211 81205	1	34-61-15 P011-01/ /E007	115-199
C00726	9	BACC18AD2 CB-FMS SW, R (SB 34-0427)	233N5212 81205	1	34-61-25 P011-02/ /F033	001
C00726	9	BACC18AD2 CB-FMS SW, R (SB 34-0414)	233N5212 81205	1	34-61-25 P011-02/ /F033	115-199
C00740		BACC18AD5 CB-GALLEYS FWD	233N5214 81205	1	25-31-11 P011-04/ /S034	001-099

EQUIPMENT LIST

D280N032

Section C00700

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00741		BACC18AD5 CB-GALLEYS MID FWD	233N5208 81205	1	25-31-21 P011-04/ /S034	115-199
C00743		BACC18AD5 CB-GALLEY G4B	233N5213 81205	1	25-31-33 P011-03/ /S003	001-099
C00743		BACC18AD5 CB-GALLEY AFT	233N5207 81205	1	25-31-33 P011-03/ /S005	115-199
C00763		BACC18AD2 CB-FIRE DET ALTN PWR ENG L	233N5214 81205	1	26-11-11 P011-04/ /J026	001-099
C00763		BACC18AD2 CB-FIRE DET ALTN PWR ENG L	233N5208 81205	1	26-11-11 P011-04/ /J026	115-199
C00764		BACC18AD2 CB-FIRE DET ALTN PWR ENG R	233N5214 81205	1	26-11-21 P011-04/ /J027	001-099
C00764		BACC18AD2 CB-FIRE DET ALTN PWR ENG R	233N5208 81205	1	26-11-21 P011-04/ /J027	115-199
C00765		BACC18AD2 CB-FIRE DET ALTN PWR APU	233N5214 81205	1	26-15-11 P011-04/ /J025	001-099
C00765		BACC18AD2 CB-FIRE DET ALTN PWR APU	233N5208 81205	1	26-15-11 P011-04/ /J025	115-199
C00766		BACC18AD2 CB-FIRE DET ALTN PWR CARGO	233N5214 81205	1	26-16-11 P011-04/ /J024	001-099
C00766		BACC18AD2 CB-FIRE DET ALTN PWR CARGO	233N5208 81205	1	26-16-11 P011-04/ /J024	115-199
C00770		BACC18AD2 CB-W/W FIRE DET	233N5211 81205	1	26-17-11 P011-01/ /B010	001-099
C00770		BACC18AD2 CB-W/W FIRE DET	233N5205 81205	1	26-17-11 P011-01/ /B010	115-199
C00772		BACC18AD2 CB-FIRE DETECTION CARGO 1	233N5212 81205	1	26-16-11 P011-02/ /B026	001-099
C00772		BACC18AD2 CB-FIRE DETECTION CARGO 1	233N5206 81205	1	26-16-11 P011-02/ /B026	115-199
C00773		BACC18AD7 CB-BTL 2 CARGO FIRE EXTINGUISHING	287N4102 81205	1	26-23-11 P006-01/ /H006	ALL
C00774		BACC18AD2 CB-FIRE DETECTION L ENG 1	233N5212 81205	1	26-11-11 P011-02/ /B020	001-099

EQUIPMENT LIST

D280N032

Section C00700

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00774		BACC18AD2 CB-FIRE DETECTION L ENG 1	233N5206 81205	1	26-11-11 P011-02/ /B020	115-199
C00775		BACC18AD2 CB-FIRE DETECTION R ENG 1	233N5212 81205	1	26-11-21 P011-02/ /B022	001-099
C00775		BACC18AD2 CB-FIRE DETECTION R ENG 1	233N5206 81205	1	26-11-21 P011-02/ /B022	115-199
C00776		BACC18AD2 CB-FIRE DETECTION APU 1	233N5212 81205	1	26-15-11 P011-02/ /B024	001-099
C00776		BACC18AD2 CB-FIRE DETECTION APU 1	233N5206 81205	1	26-15-11 P011-02/ /B024	115-199
C00778		BACC18AD7 CB-BTL 1 ENG L FIRE EXTINGUISHING	287N4102 81205	1	26-21-11 P006-01/ /H001	ALL
C00779		BACC18AD7 CB-BTL 1 ENG R FIRE EXTINGUISHING	287N4102 81205	1	26-21-11 P006-01/ /H003	ALL
C00780		BACC18AD7 CB-FIRE EXT APU	287N4102 81205	1	26-22-21 P006-01/ /G001	ALL
C00781		BACC18AD7 CB-BTL 1 CARGO FIRE EXTINGUISHING	287N4102 81205	1	26-23-11 P006-01/ /H005	ALL
C00783		BACC18AD2 CB-FIRE DETECTION L ENG 2	233N5212 81205	1	26-11-11 P011-02/ /B021	001-099
C00783		BACC18AD2 CB-FIRE DETECTION L ENG 2	233N5206 81205	1	26-11-11 P011-02/ /B021	115-199
C00784		BACC18AD2 CB-FIRE DETECTION R ENG 2	233N5212 81205	1	26-11-21 P011-02/ /B023	001-099
C00784		BACC18AD2 CB-FIRE DETECTION R ENG 2	233N5206 81205	1	26-11-21 P011-02/ /B023	115-199
C00785		BACC18AD2 CB-FIRE DETECTION APU 2	233N5212 81205	1	26-15-11 P011-02/ /B025	001-099
C00785		BACC18AD2 CB-FIRE DETECTION APU 2	233N5206 81205	1	26-15-11 P011-02/ /B025	115-199
C00786		BACC18AD7 CB-BTL 2 ENG L FIRE EXTINGUISHING	287N4102 81205	1	26-21-11 P006-01/ /H002	ALL
C00787		BACC18AD7 CB-BTL 2 ENG R FIRE EXTINGUISHING	287N4102 81205	1	26-21-11 P006-01/ /H004	ALL

EQUIPMENT LIST

D280N032

Section C00700

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00788		BACC18AD2 CB-FIRE DETECTION CARGO 2	233N5212 81205	1	26-16-11 P011-02/ /B027	001-099
C00788		BACC18AD2 CB-FIRE DETECTION CARGO 2	233N5206 81205	1	26-16-11 P011-02/ /B027	115-199
C00794		BACC18AD2 CB-FIRE DET CARGO FAN PWR	233N5214 81205	1	26-16-21 P011-04/ /S036	001-099
C00794		BACC18AD2 CB-FIRE DET CARGO FAN PWR	233N5208 81205	1	26-16-21 P011-04/ /S036	115-199
C00795		BACC18AD2 CB-FIRE DET CARGO FAN CONT	233N5214 81205	1	26-16-21 P011-04/ /S035	001-099
C00795		BACC18AD2 CB-FIRE DET CARGO FAN CONT	233N5208 81205	1	26-16-21 P011-04/ /S035	115-199
C00796		BACC18AD2 CB-APU REMOTE FIRE IND	233N5212 81205	1	26-15-12 P011-02/ /B033	001-099
C00796		BACC18AD2 CB-APU REMOTE FIRE IND	233N5206 81205	1	26-15-12 P011-02/ /B033	115-199

EQUIPMENT LIST

D280N032

Section C00700

Page 4 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00803		BACC18AD3 CB-BPCU SEC	233N5214 81205	1	24-41-11 P011-04/ /R032	001-099
C00803		BACC18AD3 CB-BPCU SEC	233N5208 81205	1	24-41-11 P011-04/ /R032	115-199
C00804		BACC18AD7 CB-L GEN CONT UNIT	287N4102 81205	1	24-11-11 P006-01/ /B001	ALL
C00805		BACC18AD7 CB-R GEN CONT UNIT	287N4102 81205	1	24-11-21 P006-01/ /B002	ALL
C00806		BACC18AD7 CB-APU GEN CONT UNIT	287N4102 81205	1	24-22-41 P006-01/ /B003	ALL
C00807		BACC18AD7 CB-L GEN DRIVE DISC	287N4102 81205	1	24-11-11 P006-01/ /B005	ALL
C00808		BACC18AD7 CB-R GEN DRIVE DISC	287N4102 81205	1	24-11-21 P006-01/ /B006	ALL
C00809		BACC18AD7 CB-BUS PWR CONT UNIT	287N4102 81205	1	24-41-11 P006-01/ /B004	ALL
C00811		BACC18AD2 CB-DC STBY BUS OFF	287N4102 81205	1	24-33-11 P006-01/ /A003	ALL
C00813		BACC18R75C CB-INV PWR BAT	287N4102 81205	1	24-33-11 P006-02/ /L011	ALL
C00814		BACC18AD2 CB-BAT XFR CONT	287N4102 81205	1	24-33-11 P006-01/ /D002	ALL
C00815		BACC18AD2 CB-APU GEN VOLTMETER	284N1316 81205	1	24-28-11 P034-00/ /AB03	ALL
C00816		BACC18AD2 CB-EXT PWR VOLTMETER	284N1316 81205	1	24-28-11 P034-00/ /AB04	ALL
C00817		BACC18AD2 CB-VOLT SENSE INVERTER	287N4102 81205	1	24-28-11 P006-03/ /M015	ALL
C00818		BACC18AD2 CB-L GEN VM	284N1314 81205	1	24-28-11 P031-00/ /A006	ALL
C00819		BACC18AD2 CB-R GEN VM	284N1315 81205	1	24-28-11 P032-00/ /A004	ALL
C00820		BACC18AD2 CB-APU BAT OVHT PROT	284N1690 81205	1	24-31-41 E006-00/ /	001-099

EQUIPMENT LIST

D280N032

Section C00800

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00820		BACC18AD2 CB-APU BAT OVHT PROT	284N1662 81205	1	24-31-41 E006-00/ /	115-199
C00821		BACC18AD2 CB-APU BAT DC VOLT	284N1690 81205	1	24-34-11 E006-00/ /	001-099
C00821		BACC18AD2 CB-APU BAT DC VOLT	284N1662 81205	1	24-34-11 E006-00/ /	115-199
C00822		BACC18AD2 CB-UTIL BUS L	233N5213 81205	1	24-51-14 P011-03/ /R004	001-099
C00822		BACC18AD2 CB-UTIL BUS L	233N5207 81205	1	24-51-14 P011-03/ /R004	115-199
C00823		BACC18AD2 CB-UTIL BUS R	233N5214 81205	1	24-51-24 P011-04/ /R031	001-099
C00823		BACC18AD2 CB-UTIL BUS R	233N5208 81205	1	24-51-24 P011-04/ /R031	115-199
C00824		BACC18AD2 CB-CAT III ISOL BUS L	233N5213 81205	1	24-51-31 P011-03/ /R003	001-099
C00824		BACC18AD2 CB-CAT III ISOL BUS L	233N5207 81205	1	24-51-31 P011-03/ /R003	115-199
C00825		BACC18AD2 CB-CAT III BUS ISOL R	233N5214 81205	1	24-51-31 P011-04/ /R030	001-099
C00825		BACC18AD2 CB-CAT III BUS ISOL R	233N5208 81205	1	24-51-31 P011-04/ /R030	115-199
C00826		BACC18AD2 CB-CAT III BUS ISOL BAT	233N5211 81205	1	24-51-31 P011-01/ /D006	001-099
C00826		BACC18AD2 CB-CAT III BUS ISOL BAT	233N5205 81205	1	24-51-31 P011-01/ /D006	115-199
C00827		BACC18AD2 CB-BAT OVHT PROT	287N4102 81205	1	24-31-11 P006-01/ /D001	ALL
C00828		BACC18AD2 CB-STBY PWR CONT	287N4102 81205	1	24-33-11 P006-01/ /A005	ALL
C00829		BACC18X25 CB-BAT BUS DISTR	287N4102 81205	1	24-54-71 P006-01/ /A001	ALL
C00865		BACC18AD2 CB-APU START TRU CONT	287N4102 81205	1	24-32-41 P006-02/ /H012	ALL

EQUIPMENT LIST

D280N032

Section C00800

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00868		BACC18R75C CB-APU BAT CHGR	284N1690 81205	1	24-31-41 E006-00/ /	001-099
C00868		BACC18R75C CB-APU BAT CHGR	284N1662 81205	1	24-31-41 E006-00/ /	115-199
C00869		BACC18X15 CB-APU BAT BUS	284N1690 81205	1	24-31-41 E006-00/ /	001-099
C00869		BACC18X15 CB-APU BAT BUS	284N1662 81205	1	24-31-41 E006-00/ /	115-199
C00871		BACC18X15 CB-GND XFMR	284N1127 81205	1	24-53-51 P037-00/ /E005	ALL
C00872		BACC18X25 CB-DC STBY	287N4102 81205	1	24-33-11 P006-01/ /A002	ALL
C00874		BACC18AD10 CB-AC STBY BUS PWR	287N4102 81205	1	24-33-11 P006-03/ /K016	001-099
C00874		BACC18AD10 CB-AC STBY BUS PWR	284N4102 81205	1	24-33-11 P006-03/ /K016	115-199
C00875		BACC18AD5 CB-CENTER BUS AC INVERTER	287N4102 81205	1	24-51-31 P006-03/ /M014	ALL
C00876		BACC18AD5 CB-CENTER BUS AC	287N4102 81205	1	24-51-31 P006-03/ /K017	ALL
C00877		BACC18AD7 CB-28V AC BUS L	287N4102 81205	1	24-53-11 P006-03/ /K018	ALL
C00878		BACC18AD7 CB-28V AC BUS R	287N4102 81205	1	24-53-21 P006-04/ /K024	ALL
C00879		BACC18AD2 CB-DC BUS TIE CONT	287N4102 81205	1	24-34-11 P006-01/ /A006	ALL
C00880		BACC18AD2 CB-CENTER BUS CONT	287N4102 81205	1	24-51-31 P006-01/ /G006	ALL
C00881		BACC18R100C CB-TIE L	287N4102 81205	1	24-32-11 P006-02/ /D009	ALL
C00882		BACC18X50 CB-SECT 1	287N4102 81205	1	24-54-11 P006-02/ /D008	ALL
C00883		BACC18X50 CB-SECT 2	287N4102 81205	1	24-54-11 P006-02/ /D007	ALL

EQUIPMENT LIST

D280N032

Section C00800

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00884		BACC18AD10 CB-C BUS PWR	287N4102 81205	1	24-51-31 P006-02/ /C009	ALL
C00885		BACC18X50 CB-INV PWR TRU	287N4102 81205	1	24-33-11 P006-02/ /D010	ALL
C00886		BACC18X50 CB-BAT BUS PWR TRU	287N4102 81205	1	24-33-11 P006-02/ /D011	ALL
C00887		BACC18AD2 CB-BAT BUS CONT	287N4102 81205	1	24-33-11 P006-02/ /C010	ALL
C00889		BACC18R100C CB-TIE R	287N4102 81205	1	24-32-11 P006-02/ /H009	ALL
C00890		BACC18X50 CB-SECT 2	287N4102 81205	1	24-54-21 P006-02/ /H007	ALL
C00891		BACC18X50 CB-SECT 1	287N4102 81205	1	24-54-21 P006-02/ /H008	ALL
C00892		BACC18AD2 CB-AC STBY BUS OFF	287N4102 81205	1	24-33-11 P006-03/ /M013	ALL
C00896		BACC18R100C CB-MAIN BAT CHGR	287N4102 81205	1	24-31-11 P006-02/ /L008	ALL
C00897		BACC18X50 CB-HOT BAT BUS	287N4102 81205	1	24-54-72 P006-02/ /L009	ALL
C00898		BACC18X50 CB-BAT BUS PWR	287N4102 81205	1	24-33-11 P006-02/ /L010	ALL
C00899		BACC18AD10 CB-CENTER BUS DC	287N4102 81205	1	24-51-31 P006-02/ /L012	ALL

EQUIPMENT LIST

D280N032

Section C00800

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00901		S281T004-1 CB-L GEN	284N1314 81205	1	24-22-11 P031-00/ /	ALL
C00902		S281T004-1 CB-L BUS TIE	284N1314 81205	1	24-22-12 P031-00/ /	ALL
C00903		S281T004-1 CB-R GEN	284N1315 81205	1	24-22-21 P032-00/ /	ALL
C00904		S281T004-1 CB-R BUS TIE	284N1315 81205	1	24-22-22 P032-00/ /	ALL
C00905		S281T004-1 CB-AUX PWR	284N1316 81205	1	24-22-41 P034-00/ /	ALL
C00905 M		287N1115-1 SPACER	81205	2	24-21-41 / /	ALL

EQUIPMENT LIST

D280N032

Section C00900

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01002		BACC18AD2 CB-STAB TRIM POS IND L	233N5211 81205	1	27-48-11 P011-01/ /H010	001-099
C01002		BACC18AD2 CB-STAB TRIM POS IND L	233N5205 81205	1	27-48-11 P011-01/ /M010	115-199
C01005		BACC18AD2 CB-RUDDER POS	233N5213 81205	1	27-28-11 P011-03/ /J016	001-099
C01005		BACC18AD2 CB-RUDDER POS	233N5207 81205	1	27-28-11 P011-03/ /J016	115-199
C01008		BACC18AD2 CB-FLAP POS IND L	233N5211 81205	1	27-58-11 P011-01/ /H012	001-099
C01008		BACC18AD2 CB-FLAP POS IND L	233N5205 81205	1	27-58-11 P011-01/ /H012	115-199
C01009		BACC18AD2 CB-STAB TRIM POS IND R	233N5212 81205	1	27-48-11 P011-02/ /H019	001-099
C01009		BACC18AD2 CB-STAB TRIM POS IND R	233N5206 81205	1	27-48-11 P011-02/ /H019	115-199
C01010		BACC18AD5 CB-STAB TRIM-ALTERNATE CONTROL	233N5212 81205	1	27-41-31 P011-02/ /B019	ALL
C01017	9	BACC18AD5 CB-STAB TRIM CONT L	SB270104 81205	1	27-41-11 P011-01/ /C005	001-004, 115-199
C01017		BACC18AD5 CB-STAB TRIM CONT L	233N5211 81205	1	27-41-11 P011-01/ /H011	001-004
C01017		BACC18AD5 CB-STAB TRIM CONT L	233N5211 81205	1	27-41-11 P011-01/ /C005	005-099
C01017		BACC18AD5 CB-STAB TRIM CONT L	233N5205 81205	1	27-41-11 P011-01/ /H011	115-199
C01018		BACC18AD2 CB-STAB TRIM CONT R	233N5212 81205	1	27-41-21 P011-02/ /H020	001-099
C01018		BACC18AD2 CB-STAB TRIM CONT R	233N5206 81205	1	27-41-21 P011-02/ /H020	115-199
C01022		BACC18AD2 CB-FLAP LOAD RELIEF	233N5213 81205	1	27-51-51 P011-03/ /H010	001-099
C01022		BACC18AD2 CB-FLAP LOAD RELIEF	233N5207 81205	1	27-51-51 P011-03/ /H010	115-199

EQUIPMENT LIST

D280N032

Section C01000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01023		BACC18AD5 CB-AUTO SPEED BRAKE	233N5211 81205	1	27-62-11 P011-01/ /G011	001-099
C01023		BACC18AD5 CB-AUTO SPEED BRAKE	233N5205 81205	1	27-62-11 P011-01/ /G011	115-199
C01025		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 1 PWR	233N5211 81205	1	27-51-41 P011-01/ /G012	001-099
C01025		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 1 PWR	233N5205 81205	1	27-51-41 P011-01/ /G012	115-199
C01031	9	BACC18AD2 CB-RUD RATIO	SB270104 81205	1	27-21-12 P011-01/ /D018	001-004, 115-199
C01031		BACC18AD2 CB-RUD RATIO	233N5211 81205	1	27-21-12 P011-01/ /G010	001-004
C01031		BACC18AD2 CB-RUD RATIO	233N5211 81205	1	27-21-12 P011-01/ /D018	005-099
C01031		BACC18AD2 CB-RUD RATIO	233N5205 81205	1	27-21-12 P011-01/ /G010	115-199
C01033		BACC18AD5 CB-RUDDER TRIM	233N5211 81205	1	27-21-11 P011-01/ /C010	001-099
C01033		BACC18AD5 CB-RUDDER TRIM	233N5205 81205	1	27-21-11 P011-01/ /C010	115-199
C01034		BACC18AD2 CB-RUDDER TRIM POS	233N5213 81205	1	27-28-13 P011-03/ /J017	001-099
C01034		BACC18AD2 CB-RUDDER TRIM POS	233N5207 81205	1	27-28-13 P011-03/ /J017	115-199
C01035		BACC18AD2 CB-AILERON TRIM	233N5213 81205	1	27-11-11 P011-03/ /J015	001-099
C01035		BACC18AD2 CB-AILERON TRIM	233N5207 81205	1	27-11-11 P011-03/ /J015	115-199
C01037		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 1 SENSOR	233N5211 81205	1	27-51-41 P011-01/ /G014	001-099
C01037		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 1 SENSOR	233N5205 81205	1	27-51-41 P011-01/ /G014	115-199
C01038		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 3 CONT	233N5212 81205	1	27-81-11 P011-02/ /G023	001-099

EQUIPMENT LIST

D280N032

Section C01000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01038		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 3 CONT	233N5206 81205	1	27-81-11 P011-02/ /G023	115-199
C01039		BACC18AD5 CB-STICK SHAKER L	233N5211 81205	1	27-32-11 P011-01/ /C011	001-099
C01039		BACC18AD5 CB-STICK SHAKER L	233N5205 81205	1	27-32-11 P011-01/ /C011	115-199
C01040		BACC18AD5 CB-FUEL QTY-FUEL	284N1316 81205	1	28-21-11 P034-00/ /AA10	ALL
C01041		BACC18AD5 CB-FLNG CONT-FUEL	284N1316 81205	1	28-21-11 P034-00/ /AA11	ALL
C01043		BACC18AD5 CB-FUELING CONTROL	287N4102 81205	1	28-21-11 P006-01/ /E005	ALL
C01045		BACC18AD7 CB-FUELING QTY	287N4102 81205	1	28-21-11 P006-01/ /E004	ALL
C01046		BACC18AD7 CB-FUELING VALVES	287N4102 81205	1	28-21-11 P006-01/ /E006	ALL
C01047		BACC18AD7 CB-FLNG VALVE-FUEL	284N1316 81205	1	28-21-11 P034-00/ /AA09	ALL
C01048		BACC18AD5 CB-FUEL QTY 1	233N5212 81205	1	28-21-11 P011-02/ /C034	001-099
C01048		BACC18AD5 CB-FUEL QTY L	233N5206 81205	1	28-21-11 P011-02/ /C034	115-199
C01051		BACC18Z02R CB-FUEL CROSSFEED	233N5212 81205	1	28-22-31 P011-02/ /D036	001-008
C01051		BACC18Z02R CB-FUEL CROSSFEED	233N5206 81205	1	28-22-31 P011-02/ /D036	115-199
C01052		BACC18AD2 CB-FUEL DC PUMP CONT	233N5212 81205	1	28-25-11 P011-02/ /D035	001-099
C01052		BACC18AD2 CB-FUEL DC PUMP CONT	233N5206 81205	1	28-25-11 P011-02/ /D035	115-199
C01053		BACC18AD5 CB-FUEL QTY 2	233N5214 81205	1	28-21-11 P011-04/ /L019	001-099
C01053		BACC18AD5 CB-FUEL QTY R	233N5208 81205	1	28-21-11 P011-04/ /L019	115-199

EQUIPMENT LIST

D280N032

Section C01000

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01058		BACC18AD7 CB-FUEL DC PUMP APU	233N5212 81205	1	28-25-11 P011-02/ /C033	001-099
C01058		BACC18AD7 CB-FUEL DC PUMP APU	233N5206 81205	1	28-25-11 P011-02/ /C033	115-199
C01061		BACC18Z02R CB-L SPAR FUEL VALVES	287N4102 81205	1	28-22-21 P006-01/ /E001	ALL
C01062		BACC18Z02R CB-R SPAR FUEL VALVES	287N4102 81205	1	28-22-21 P006-01/ /E002	ALL
C01063		BACC18Z02R CB-APU FUEL VALVES	287N4102 81205	1	28-25-21 P006-01/ /E003	ALL
C01080		BACC18AD2 CB-HYDRAULICS SYSTEM PRESS L	233N5213 81205	1	29-31-11 P011-03/ /K017	001-099
C01080		BACC18AD2 CB-HYDRAULICS SYSTEM PRESS L	233N5207 81205	1	29-31-11 P011-03/ /K017	115-199
C01081		BACC18AD2 CB-HYDRAULICS PRESSURE SYSTEM R	233N5214 81205	1	29-31-11 P011-04/ /K026	001-099
C01081		BACC18AD2 CB-HYDRAULICS PRESSURE SYSTEM R	233N5208 81205	1	29-31-11 P011-04/ /K026	115-199
C01082		BACC18AD2 CB-HYDRAULICS SYSTEM PRESS C	233N5213 81205	1	29-31-11 P011-03/ /K018	001-099
C01082		BACC18AD2 CB-HYDRAULICS SYSTEM PRESS C	233N5207 81205	1	29-31-11 P011-03/ /K018	115-199

EQUIPMENT LIST

D280N032

Section C01000

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01101		BACC18AD2 CB-HYDRAULICS QTY L	233N5214 81205	1	29-33-11 P011-04/ /K020	001-099
C01101		BACC18AD2 CB-HYDRAULICS QTY L	233N5208 81205	1	29-33-11 P011-04/ /K020	115-199
C01110		BACC18AD2 CB-CAPT MAIN PITOT HEAT	287N4102 81205	1	30-31-11 P006-03/ /L015	ALL
C01112		BACC18AD2 CB-L AUX PITOT HEAT	287N4102 81205	1	30-31-11 P006-03/ /L016	ALL
C01114		BACC18AD2 CB-R AUX PITOT HEAT	287N4102 81205	1	30-31-12 P006-04/ /L021	ALL
C01116		BACC18AD2 CB-F/O MAIN PITOT HEAT	287N4102 81205	1	30-31-12 P006-04/ /L022	ALL
C01120		BACC18AD2 CB-PROBE HEAT IND PITOT L	233N5211 81205	1	30-31-11 P011-01/ /D004	001-099
C01120		BACC18AD2 CB-PROBE HEAT IND PITOT L	233N5205 81205	1	30-31-11 P011-01/ /D004	115-199
C01121		BACC18AD2 CB-PROBE HEAT IND PITOT R	233N5212 81205	1	30-31-12 P011-02/ /C021	001-099
C01121		BACC18AD2 CB-PROBE HEAT IND PITOT R	233N5206 81205	1	30-31-12 P011-02/ /C021	115-199
C01124		BACC18AD7 CB-WINDOW HTR 2L	284N1127 81205	1	30-41-12 P037-00/ /E003	ALL
C01125		BACC18AD7 CB-WINDOW HTR 2R	284N1129 81205	1	30-41-11 P070-00/ /A003	ALL
C01126		BACC18AD7 CB-WINDOW HTR 3L	284N1127 81205	1	30-41-12 P037-00/ /E004	ALL
C01127		BACC18AD7 CB-WINDOW HTR 3R	284N1129 81205	1	30-41-11 P070-00/ /A004	ALL
C01128		BACC18AD2 CB-WINDOW HEAT TEST	233N5213 81205	1	30-41-11 P011-03/ /R015	001-099
C01128		BACC18AD2 CB-WINDOW HEAT TEST	233N5207 81205	1	30-41-11 P011-03/ /R015	115-199
C01132		BACC18AD5 CB-WING ANTI-ICE	233N5212 81205	1	30-11-11 P011-02/ /C029	001-099

EQUIPMENT LIST

D280N032

Section C01100

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01132		BACC18AD5 CB-WING ANTI-ICE	233N5206 81205	1	30-11-11 P011-02/ /C029	115-199
C01134		BACC18AD5 CB-L AOA HEAT	287N4102 81205	1	30-32-11 P006-03/ /L017	ALL
C01135		BACC18AD5 CB-R AOA HEAT	287N4102 81205	1	30-32-11 P006-04/ /L023	ALL
C01136		BACC18AD2 CB-RAIN REPEL R (INOP)	233N5213 81205	1	30-43-11 P011-03/ /R012	001-099
C01136		BACC18AD2 CB-RAIN REPEL R (INOP)	233N5207 81205	1	30-43-11 P011-03/ /R012	115-199
C01142		BACC18AD7 CB-AIR DRAIN MST HEATERS	284N1127 81205	1	30-71-11 P037-00/ /F007	ALL
C01143		BACC18AD10 CB-WSHLD WIPER L	233N5213 81205	1	30-42-11 P011-03/ /R013	001-099
C01143		BACC18AD10 CB-WSHLD WIPER L	233N5207 81205	1	30-42-11 P011-03/ /R013	115-199
C01144		BACC18AD10 CB-WSHLD WIPER R	233N5214 81205	1	30-42-11 P011-04/ /R022	001-099
C01144		BACC18AD10 CB-WSHLD WIPER R	233N5208 81205	1	30-42-11 P011-04/ /R022	115-199
C01145		BACC18AD2 CB-RAIN REPEL L (INOP)	233N5214 81205	1	30-43-11 P011-04/ /R021	001-099
C01145		BACC18AD2 CB-RAIN REPEL L (INOP)	233N5208 81205	1	30-43-11 P011-04/ /R021	115-199
C01147		BACC18AD2 CB-ENG ANTI-ICE L	233N5212 81205	1	30-21-11 P011-02/ /C027	001-099
C01147		BACC18AD2 CB-ENG ANTI-ICE L	233N5206 81205	1	30-21-11 P011-02/ /C027	115-199
C01148		BACC18AD2 CB-ENG ANTI-ICE R	233N5212 81205	1	30-21-11 P011-02/ /C028	001-099
C01148		BACC18AD2 CB-ENG ANTI-ICE R	233N5206 81205	1	30-21-11 P011-02/ /C028	115-199
C01149		BACC18AD3 CB-FWD WATERLINE HEATERS	284N1127 81205	1	30-71-21 P037-00/ /F005	ALL

EQUIPMENT LIST

D280N032

Section C01100

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01150		BACC18AD3 CB-MID WATERLINE HEATERS	284N1127 81205	1	30-71-21 P037-00/ /F006	ALL
C01170		BACC18AD5 CB-LANDING GEAR AIR/GND SYS 2	233N5214 81205	1	32-09-12 P011-04/ /S019	001-099
C01170		BACC18AD5 CB-LANDING GEAR AIR/GND SYS 2	233N5208 81205	1	32-09-12 P011-04/ /S019	115-199
C01171		BACC18AD2 CB-LANDING GEAR ANTISKID 1-5	233N5213 81205	1	32-42-11 P011-03/ /S018	001-099
C01171		BACC18AD2 CB-LANDING GEAR ANTISKID 1-5	233N5207 81205	1	32-42-11 P011-03/ /S018	115-199
C01172		BACC18AD2 CB-LANDING GEAR ANTISKID 4-8	233N5214 81205	1	32-42-11 P011-04/ /S022	001-099
C01172		BACC18AD2 CB-LANDING GEAR ANTISKID 4-8	233N5208 81205	1	32-42-11 P011-04/ /S022	115-199
C01173		BACC18AD2 CB-LDG GEAR AUTOBK ANTISKID TEST IND 2	233N5214 81205	1	32-42-12 P011-04/ /S021	001-099
C01173		BACC18AD2 CB-LDG GEAR AUTOBK ANTISKID TEST IND 2	233N5208 81205	1	32-42-12 P011-04/ /S021	115-199
C01174		BACC18AD2 CB-LANDING GEAR LEVER LOCK	233N5102 81205	1	32-31-11 P011-04/ /S020	ALL
C01175		BACC18AD2 CB-LANDING GEAR POS SYS 1	233N5212 81205	1	32-61-11 P011-02/ /C020	001-099
C01175		BACC18AD2 CB-LANDING GEAR POS SYS 1	233N5206 81205	1	32-61-11 P011-02/ /C030	115-199
C01176		BACC18AD2 CB-LDG GEAR AUTOBK ANTISKID TEST IND 1	233N5213 81205	1	32-42-11 P011-03/ /S014	001-099
C01176		BACC18AD2 CB-LDG GEAR AUTOBK ANTISKID TEST IND 1	233N5207 81205	1	32-42-11 P011-03/ /S014	115-199
C01179		BACC18AD5 CB-LANDING GEAR PARKING BRAKE VLV	287N4102 81205	1	32-44-11 P006-01/ /F004	ALL
C01180		BACC18AD2 CB-LANDING GEAR BRAKE PRESS IND	233N5213 81205	1	32-41-11 P011-03/ /S013	001-099
C01180		BACC18AD2 CB-LANDING GEAR BRAKE PRESS IND	233N5207 81205	1	32-41-11 P011-03/ /S013	115-199

EQUIPMENT LIST

D280N032

Section C01100

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01181		BACC18AD2 CB-LANDING GEAR BRAKE TEMP	233N5213 81205	1	32-46-11 P011-03/ /S016	115-199
C01182		BACC18AD5 CB-LANDING GEAR AIR/GND SYS 1	233N5213 81205	1	32-09-11 P011-03/ /S015	001-099
C01182		BACC18AD5 CB-LANDING GEAR AIR/GND SYS 1	233N5207 81205	1	32-09-11 P011-03/ /S015	115-199
C01183		BACC18AD2 CB-LANDING GEAR ANTI-SKID 2-6	233N5212 81205	1	32-42-11 P011-02/ /C031	001-099
C01183		BACC18AD2 CB-LDG GEAR ANTI-SKID 2-6	233N5206 81205	1	32-42-11 P011-02/ /C031	115-199
C01184		BACC18AD2 CB-LANDING GEAR ANTI-SKID 3-7	233N5212 81205	1	32-42-11 P011-02/ /C032	001-099
C01184		BACC18AD2 CB-LANDING GEAR ANTI-SKID 3-7	233N5206 81205	1	32-42-11 P011-02/ /C032	115-199

EQUIPMENT LIST

D280N032

Section C01100

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01200		BACC18AD5 CB-IND LIGHTS 1	233N5212 81205	1	33-16-51 P011-02/ /A032	001-099
C01200		BACC18AD5 CB-IND LIGHTS 1	233N5206 81205	1	33-16-51 P011-02/ /A032	115-199
C01201		BACC18AD5 CB-IND LIGHTS 2	233N5212 81205	1	33-16-61 P011-02/ /A033	001-099
C01201		BACC18AD5 CB-IND LIGHTS 2	233N5206 81205	1	33-16-61 P011-02/ /A033	115-199
C01202		BACC18AD2 CB-LDG & TAXI CONT	233N5214 81205	1	33-42-11 P011-04/ /M031	ALL
C01203		BACC18AD2 CB-NIGHT LIGHTS	284N1316 81205	1	33-21-51 P034-00/ /BH01	ALL
C01205		BACC18AD3 CB-NOSE WHEELWELL LIGHTS	284N1316 81205	1	33-31-11 P034-00/ /BG01	ALL
C01206		BACC18AD3 CB-MN GEAR WHEELWELL SERVICE LIGHTS	284N1316 81205	1	33-31-11 P034-00/ /AB05	ALL
C01210		BACC18AD7 CB-AFT CARGO COMPARTMENT LIGHTS	284N1316 81205	1	33-37-21 P034-00/ /AB09	ALL
C01211		BACC18AD5 CB-FWD CARGO COMPARTMENT LIGHTS	284N1316 81205	1	33-37-11 P034-00/ /AB08	001-099
C01211		BACC18AD7 CB-FWD CARGO COMPARTMENT LIGHTS	284N1316 81205	1	33-37-11 P034-00/ /AB08	115-199
C01213		BACC18AD3 CB-FLT DECK DOME AC LIGHTS	284N1316 81205	1	33-11-31 P034-00/ /BG02	ALL
C01214		BACC18AD2 CB-F/D DOME LTS DC	233N5212 81205	1	33-11-31 P011-02/ /A030	001-099
C01214		BACC18AD2 CB-F/D DOME LTS DC	233N5206 81205	1	33-11-31 P011-02/ /A030	115-199
C01215		BACC18AD5 CB-LAV SERVICE LIGHTS	284N1316 81205	1	33-26-11 P034-00/ /AB06	ALL
C01217		BACC18AD2 CB-CEILING LIGHTS CONT	284N1127 81205	1	33-21-11 P037-00/ /G008	ALL
C01218		BACC18X15 CB-CEILING LIGHTS L	284N1127 81205	1	33-21-11 P037-00/ /G006	ALL

EQUIPMENT LIST

D280N032

Section C01200

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01219		BACC18X15 CB-CEILING LIGHTS R	284N1127 81205	1	33-21-11 P037-00/ /G007	ALL
C01224		BACC18AD2 CB-SIDEWALL LIGHTS CONT	284N1127 81205	1	33-21-31 P037-00/ /H007	ALL
C01225		BACC18AD5 CB-ANTI-COLL RED	233N5214 81205	1	33-44-11 P011-04/ /M034	001-099
C01225		BACC18AD5 CB-ANTI-COLL RED	233N5208 81205	1	33-44-11 P011-04/ /M034	115-199
C01226		BACC18AD5 CB-ANTI-COLL WHITE	233N5213 81205	1	33-44-21 P011-03/ /M007	001-099
C01226		BACC18AD5 CB-ANTI-COLL WHITE	233N5207 81205	1	33-44-21 P011-03/ /M007	115-199
C01227		BACC18AD5 CB-WING ILLUM	233N5214 81205	1	33-41-11 P011-04/ /M035	001-099
C01227		BACC18AD5 CB-WING ILLUM	233N5208 81205	1	33-41-11 P011-04/ /M035	115-199
C01232		BACC18AD5 CB-LAV LIGHTS	284N1127 81205	1	33-26-11 P037-00/ /G003	ALL
C01237		BACC18AD2 CB-INSTRUMENT & PANEL CAPT	233N5213 81205	1	33-13-11 P011-03/ /N002	001-099
C01237		BACC18AD2 CB-INSTRUMENT & PANEL CAPT	233N5207 81205	1	33-13-11 P011-03/ /N002	115-199
C01239		BACC18AD2 CB-INST & PANEL F/O	233N5214 81205	1	33-13-21 P011-04/ /N028	001-099
C01239		BACC18AD2 CB-INST & PANEL F/O	233N5208 81205	1	33-13-21 P011-04/ /N028	115-199
C01240		BACC18AD2 CB-INST & PANEL GLARESHIELD	233N5214 81205	1	33-13-41 P011-04/ /N030	001-099
C01240		BACC18AD2 CB-INST & PANEL GLARESHIELD	233N5208 81205	1	33-13-41 P011-04/ /N030	115-199
C01241		BACC18AD2 CB-INSTRUMENT & PANEL OVHD	233N5213 81205	1	33-13-31 P011-03/ /N004	001-099
C01241		BACC18AD2 CB-INSTRUMENT & PANEL OVHD	233N5207 81205	1	33-13-31 P011-03/ /N004	115-199

EQUIPMENT LIST

D280N032

Section C01200

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01242		BACC18AD2 CB-INSTRUMENT & PANEL AISLE STAND	233N5213 81205	1	33-13-51 P011-03/ /N001	001-099
C01242		BACC18AD2 CB-INSTRUMENT & PANEL AISLE STAND	233N5207 81205	1	33-13-51 P011-03/ /N001	115-199
C01244		BACC18AD2 CB-OVHD C/B PNL	233N5213 81205	1	33-13-61 P011-03/ /N005	001-099
C01244		BACC18AD2 CB-OVHD C/B PNL	233N5207 81205	1	33-13-61 P011-03/ /N005	115-199
C01246		BACC18AD2 CB-STBY INSTR LIGHTS	233N5211 81205	1	33-13-12 P011-01/ /B007	001-099
C01246		BACC18AD2 CB-STBY INSTR LIGHTS	233N5205 81205	1	33-13-12 P011-01/ /B007	115-199
C01247		BACC18AD7 CB-NOSE GEAR LANDING L	233N5213 81205	1	33-42-11 P011-03/ /M003	001-099
C01247		BACC18AD7 CB-NOSE GEAR LANDING L	233N5207 81205	1	33-42-11 P011-03/ /M003	115-199
C01248		BACC18AD7 CB-NOSE GEAR LANDING R	233N5213 81205	1	33-42-11 P011-03/ /M004	001-099
C01248		BACC18AD7 CB-NOSE GEAR LANDING R	233N5208 81205	1	33-42-11 P011-04/ /M030	115-199
C01249		BACC18AD7 CB-WING LANDING L	233N5213 81205	1	33-42-11 P011-03/ /M005	001-099
C01249		BACC18AD7 CB-WING LANDING L	233N5207 81205	1	33-42-11 P011-03/ /M005	115-199
C01250		BACC18AD7 CB-WING LANDING R	233N5214 81205	1	33-42-11 P011-04/ /M032	001-099
C01250		BACC18AD7 CB-WING LANDING R	233N5208 81205	1	33-42-11 P011-04/ /M032	115-199
C01251		BACC18AD2 CB-MAP	233N5214 81205	1	33-14-11 P011-04/ /N031	001-099
C01251		BACC18AD2 CB-MAP	233N5208 81205	1	33-14-11 P011-04/ /N031	115-199
C01252		BACC18AD2 CB-CHART TABLE	233N5213 81205	1	33-14-21 P011-03/ /N007	001-099

EQUIPMENT LIST

D280N032

Section C01200

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01252		BACC18AD2 CB-CHART TABLE	233N5207 81205	1	33-14-21 P011-03/ /N007	115-199
C01253		BACC18AD5 CB-NO SMOKING SIGNS R	284N1316 81205	1	33-24-11 P034-00/ /BF02	ALL
C01254		BACC18AD2 CB-PASS SIGN CONT	233N5213 81205	1	33-24-11 P011-03/ /P009	001-099
C01254		BACC18AD2 CB-PASS SIGN CONT	233N5207 81205	1	33-24-11 P011-03/ /P009	115-199
C01255		BACC18AD5 CB-ENTRY & GALLEY LIGHTS	284N1127 81205	1	33-22-11 P037-00/ /G004	ALL
C01256		BACC18AD3 CB-APU & TAIL CONE COMPARTMENT LIGHTS	284N1316 81205	1	33-31-31 P034-00/ /AB07	ALL
C01257		BACC18AD3 CB-FWD ELEC EQUIP CTR LIGHTS	284N1316 81205	1	33-31-41 P034-00/ /BC01	ALL
C01259		BACC18AD5 CB-PASS READING LTS LEFT FWD	284N1129 81205	1	33-23-11 P070-00/ /B018	ALL
C01260		BACC18AD5 CB-MID FWD LEFT PASS READING LTS	284N1129 81205	1	33-23-12 P070-00/ /B020	ALL
C01261		BACC18AD5 CB-PASS READING LTS MID AFT LEFT	284N1129 81205	1	33-23-13 P070-00/ /B021	ALL
C01264		BACC18AD7 CB-SIDEWALL LIGHTS L	284N1127 81205	1	33-21-31 P037-00/ /H005	ALL
C01265		BACC18AD7 CB-SIDEWALL LIGHTS R	284N1127 81205	1	33-21-31 P037-00/ /H006	ALL
C01266		BACC18AD7 CB-LEFT SIDEWALL LIGHTS	284N1316 81205	1	33-21-31 P034-00/ /AB11	ALL
C01269		BACC18AD5 CB-FWD ENTRY ATTND LIGHTS	284N1316 81205	1	33-22-11 P034-00/ /BG03	ALL
C01270		BACC18AD7 CB-OCCUPY & DOME LAV LIGHTS	284N1316 81205	1	33-26-11 P034-00/ /BD01	001-099
C01270		BACC18AD5 CB-OCCUPY & DOME LAV LIGHTS	284N1316 81205	1	33-26-11 P034-00/ /BD01	115-199
C01271		BACC18AD2 CB-TAXI LT	233N5213 81205	1	33-42-31 P011-03/ /M008	001-099

EQUIPMENT LIST

D280N032

Section C01200

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01273		BACC18AD5 CB-R IND LTS 1	233N5214 81205	1	33-16-31 P011-04/ /P028	ALL
C01276		BACC18AD2 CB-RUNWAY TURNOFF L	233N5213 81205	1	33-42-21 P011-03/ /M006	001-099
C01276		BACC18AD2 CB-RUNWAY TURNOFF L	233N5207 81205	1	33-42-21 P011-03/ /M006	115-199
C01277		BACC18AD2 CB-RUNWAY TURNOFF R	233N5214 81205	1	33-42-21 P011-04/ /M033	001-099
C01277		BACC18AD2 CB-RUNWAY TURNOFF R	233N5208 81205	1	33-42-21 P011-04/ /M033	115-199
C01280		BACC18AD5 CB-EMERGENCY CHARGER R	233N5214 81205	1	33-51-11 P011-04/ /N036	001-099
C01280		BACC18AD5 CB-EMERGENCY CHARGER R	233N5208 81205	1	33-51-11 P011-04/ /N036	115-199
C01281		BACC18AD2 CB-UTILITY	233N5214 81205	1	33-14-31 P011-04/ /N032	001-099
C01281		BACC18AD2 CB-UTILITY	233N5208 81205	1	33-14-31 P011-04/ /N032	115-199
C01283		BACC18AD2 CB-FLOOD MAIN PANEL LIGHTS	233N5211 81205	1	33-11-11 P011-01/ /B006	001-099
C01283		BACC18AD2 CB-FLOOD MAIN PANEL LIGHTS	233N5205 81205	1	33-11-11 P011-01/ /B006	115-199
C01284		BACC18AD5 CB-R IND LTS 2	233N5214 81205	1	33-16-41 P011-04/ /P029	001-099
C01284		BACC18AD5 CB-R IND LTS 2	233N5208 81205	1	33-16-41 P011-04/ /P029	115-199
C01287		BACC18AD2 CB-FLOOD AISLE STAND	233N5214 81205	1	33-11-21 P011-04/ /N034	001-099
C01287		BACC18AD2 CB-FLOOD AISLE STAND	233N5208 81205	1	33-11-21 P011-04/ /Q032	115-199
C01288		BACC18AD2 CB-CAPT PNL FLOOD	233N5214 81205	1	33-11-11 P011-04/ /N033	001-099
C01288		BACC18AD2 CB-CAPT PNL FLOOD	233N5208 81205	1	33-11-11 P011-04/ /N033	115-199

EQUIPMENT LIST

D280N032

Section C01200

Page 5

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01289		BACC18AD2 CB-F/O PNL FLOOD	233N5213 81205	1	33-11-11 P011-03/ /N006	001-099
C01289		BACC18AD2 CB-F/O PNL FLOOD	233N5207 81205	1	33-11-11 P011-03/ /N006	115-199
C01290		BACC18AD2 CB-IND LTS DIM CONT	233N5213 81205	1	33-16-11 P011-03/ /P005	001-099
C01290		BACC18AD2 CB-IND LTS DIM CONT	233N5207 81205	1	33-16-11 P011-03/ /P005	115-199
C01292		BACC18AD5 CB-PASS READING LTS LEFT AFT	284N1129 81205	1	33-23-14 P070-00/ /B019	ALL
C01294		BACC18AD5 CB-POSITION LT LEFT	233N5214 81205	1	33-43-11 P011-04/ /Q028	ALL
C01296		BACC18AD7 CB-SEAT BELT SIGNS L	284N1316 81205	1	33-24-11 P034-00/ /BE01	ALL
C01297		BACC18AD5 CB-L IND LTS 1	233N5213 81205	1	33-16-11 P011-03/ /P001	001-099
C01297		BACC18AD5 CB-L IND LTS 1	233N5207 81205	1	33-16-11 P011-03/ /P001	115-199
C01298		BACC18AD5 CB-L IND LTS 2	233N5213 81205	1	33-16-21 P011-03/ /P002	001-099
C01298		BACC18AD5 CB-L IND LTS 2	233N5207 81205	1	33-16-21 P011-03/ /P002	115-199

EQUIPMENT LIST

D280N032

Section C01200

Page 6 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01300		BACC18AD5 CB-AIR COND COMPT HYD SVCE LIGHTS	284N1316 81205	1	33-31-21 P034-00/ /AB10	ALL
C01302		BACC18AD5 CB-EMERGENCY CHARGER L	233N5214 81205	1	33-51-11 P011-04/ /N035	001-099
C01302		BACC18AD5 CB-EMERGENCY CHARGER L	233N5208 81205	1	33-51-11 P011-04/ /N035	115-199
C01303		BACC18AD5 CB-EMERGENCY CHARGER ALT L	233N5212 81205	1	33-51-11 P011-02/ /C035	001-099
C01303		BACC18AD5 CB-EMERGENCY CHARGER ALT L	233N5206 81205	1	33-51-11 P011-02/ /C035	115-199
C01306		BACC18AD5 CB-IND LIGHTS 4	233N5212 81205	1	33-16-61 P011-02/ /A035	001-099
C01306		BACC18AD5 CB-IND LIGHTS 4	233N5206 81205	1	33-16-61 P011-02/ /A035	115-199
C01307		BACC18AD2 CB-IND LIGHTS TEST	233N5212 81205	1	33-16-51 P011-02/ /A031	001-099
C01307		BACC18AD2 CB-IND LIGHTS TEST	233N5206 81205	1	33-16-51 P011-02/ /A031	115-199
C01308		BACC18AD5 CB-IND LIGHTS 3	233N5212 81205	1	33-16-61 P011-02/ /A034	001-099
C01308		BACC18AD5 CB-IND LIGHTS 3	233N5206 81205	1	33-16-61 P011-02/ /A034	115-199
C01310		BACC18AD5 CB-EMERGENCY CHARGER ALT R	233N5212 81205	1	33-51-11 P011-02/ /C036	001-099
C01310		BACC18AD5 CB-EMERGENCY CHARGER ALT R	233N5206 81205	1	33-51-11 P011-02/ /C036	115-199
C01314		BACC18AD5 CB-POSITION LT RIGHT	233N5214 81205	1	33-43-11 P011-04/ /Q030	ALL
C01320		BACC18AD2 CB-OXYGEN PRESS	233N5214 81205	1	35-11-13 P011-04/ /S033	001-099
C01320		BACC18AD2 CB-OXYGEN PRESS	233N5208 81205	1	35-11-13 P011-04/ /S031	115-199
C01321		BACC18AD5 CB-PASSENGER OXYGEN L	233N5212 81205	1	35-21-11 P011-02/ /A021	001-099

EQUIPMENT LIST

D280N032

Section C01300

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01321		BACC18AD5 CB-PASSENGER OXYGEN L	233N5206 81205	1	35-21-11 P011-02/ /A021	115-199
C01322	9	BACC18AD7 CB-PASSENGER OXYGEN R	233N5206 81205	1	35-21-11 P011-02/ /A023	005, 007-008
C01322		BACC18AD5 CB-PASSENGER OXYGEN R	233N5212 81205	1	35-21-11 P011-02/ /A023	001-099
C01322		BACC18AD5 CB-PASSENGER OXYGEN R	233N5206 81205	1	35-21-11 P011-02/ /A023	115-199
C01323		BACC18AD2 CB-PASSENGER OXYGEN CONT	233N5212 81205	1	35-21-11 P011-02/ /A024	ALL
C01325		BACC18AD2 CB-PASSENGER OXYGEN MANUAL DEPLOY	233N5212 81205	1	35-21-11 P011-02/ /A025	ALL
C01332		BACC18AD2 CB-DUCT PRESS IND L	233N5213 81205	1	36-21-11 P011-03/ /Q016	001-099
C01332		BACC18AD2 CB-DUCT PRESS XMTR L	233N5207 81205	1	36-21-11 P011-03/ /Q016	115-199
C01333		BACC18AD2 CB-APU BLEED CONT	233N5214 81205	1	36-11-41 P011-04/ /Q023	001-099
C01333		BACC18AD2 CB-APU BLEED CONT	233N5208 81205	1	36-11-41 P011-04/ /Q023	115-199
C01336		BACC18AD2 CB-APU BLEED PWR	233N5214 81205	1	36-11-41 P011-04/ /Q022	001-099
C01336		BACC18AD2 CB-APU BLEED PWR	233N5208 81205	1	36-11-41 P011-04/ /Q022	115-199
C01337		BACC18AD2 CB-ISOL VALVE PWR	233N5211 81205	1	36-11-31 P011-01/ /B003	001-099
C01337		BACC18AD2 CB-ISOL VALVE PWR	233N5205 81205	1	36-11-31 P011-01/ /B003	115-199
C01338		BACC18AD2 CB-ISOL VALVE CONT	233N5211 81205	1	36-11-31 P011-01/ /B002	001-099
C01338		BACC18AD2 CB-ISOL VALVE CONT	233N5205 81205	1	36-11-31 P011-01/ /B002	115-199
C01339		BACC18AD5 CB-ENG BLEED CONT L	233N5213 81205	1	36-11-11 P011-03/ /Q010	001-099

EQUIPMENT LIST

D280N032

Section C01300

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01339		BACC18AD5 CB-ENG BLEED CONT L	233N5207 81205	1	36-11-11 P011-03/ /Q010	115-199
C01340		BACC18AD5 CB-R ENG BLEED CONT	233N5214 81205	1	36-11-21 P011-04/ /Q019	001-099
C01340		BACC18AD5 CB-R ENG BLEED CONT	233N5208 81205	1	36-11-21 P011-04/ /Q019	115-199
C01342		BACC18AD2 CB-DUCT PRESS IND R	233N5214 81205	1	36-21-11 P011-04/ /Q024	001-099
C01342		BACC18AD2 CB-DUCT PRESS XMTR R	233N5208 81205	1	36-21-11 P011-04/ /Q024	115-199
C01355		BACC18AD2 CB-POTABLE WATER CONT FLT	233N5214 81205	1	38-14-11 P011-04/ /S030	001-099
C01355		BACC18AD2 CB-POTABLE WATER CONT FLT	233N5208 81205	1	38-14-11 P011-04/ /S030	115-199
C01356		BACC18AD2 CB-POTW CONT GND	284N1316 81205	1	38-14-11 P034-00/ /AA04	ALL
C01382		BACC18AD7 CB-APU CONT	284N1690 81205	1	49-61-11 E006-00/ /	001-099
C01382		BACC18AD7 CB-APU CONT	284N1662 81205	1	49-61-11 E006-00/ /	115-199
C01385		BACC18AD5 CB-APU INLET DOOR ACTR	284N1690 81205	1	49-61-14 E006-00/ /	001-099
C01385		BACC18AD5 CB-APU INLET DOOR ACTR	284N1662 81205	1	49-61-14 E006-00/ /	115-199
C01390		BACC18AD7 CB-APU ALTN CONT	233N5212 81205	1	49-61-11 P011-02/ /B034	001-099
C01390		BACC18AD7 CB-APU MN BAT CONT	233N5206 81205	1	49-61-11 P011-02/ /B034	115-199

EQUIPMENT LIST

D280N032

Section C01300

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01400		BACC18AD2 CB-F/D DOOR LOCK	233N5213 81205	1	52-51-11 P011-03/ /R005	001-099
C01400		BACC18AD2 CB-F/D DOOR LOCK	233N5207 81205	1	52-51-11 P011-03/ /R005	115-199
C01403		BACC18AD5 CB-CARGO DOOR CONT	284N1316 81205	1	52-34-11 P034-00/ /AA05	ALL
C01412		BACC18AD2 CB-FUEL TEMP IND(MR69018-002 INOP)	233N5207 81205	1	28-43-11 P011-03/ /L012	115-199
C01430		BACC18AD2 CB-LEFT ENGINE IGN 1	233N5213 81205	1	74-31-11 P011-03/ /L001	001-099
C01430		BACC18AD2 CB-LEFT ENGINE IGN 1	233N5207 81205	1	74-31-11 P011-03/ /L001	115-199
C01432		BACC18AD2 CB-RIGHT ENGINE IGN 1	233N5214 81205	1	74-31-21 P011-04/ /L028	001-099
C01432		BACC18AD2 CB-RIGHT ENGINE IGN 1	233N5208 81205	1	74-31-21 P011-04/ /L028	115-199
C01434		BACC18AD2 CB-ENGINES STBY IGN L 1	233N5211 81205	1	74-31-11 P011-01/ /D007	001-099
C01434		BACC18AD2 CB-ENGINES STBY IGN L 1	233N5205 81205	1	74-31-11 P011-01/ /D007	115-199
C01435		BACC18AD2 CB-ENGINES STBY IGN L 2	233N5211 81205	1	74-31-11 P011-01/ /D008	001-099
C01435		BACC18AD2 CB-ENGINES STBY IGN L 2	233N5205 81205	1	74-31-11 P011-01/ /D008	115-199
C01437		BACC18AD2 CB-ENGINES STBY IGN R 1	233N5211 81205	1	74-31-21 P011-01/ /D009	001-099
C01437		BACC18AD2 CB-ENGINES STBY IGN R 1	233N5205 81205	1	74-31-21 P011-01/ /D009	115-199
C01438		BACC18AD2 CB-ENGINES STBY IGN R 2	233N5211 81205	1	74-31-21 P011-01/ /D010	001-099
C01438		BACC18AD2 CB-ENGINES STBY IGN R 2	233N5205 81205	1	74-31-21 P011-01/ /D010	115-199
C01464		BACC18AD2 CB-LEFT ENGINE VIB MONITOR	233N5213 81205	1	77-31-11 P011-03/ /K002	001-099

EQUIPMENT LIST

D280N032

Section C01400

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01464		BACC18AD2 CB-LEFT ENGINE VIB MONITOR	233N5207 81205	1	77-31-11 P011-03/ /K002	115-199
C01480		BACC18AD2 CB-LEFT ENGINE T/R IND	233N5211 81205	1	78-36-11 P011-01/ /D011	001-099
C01480		BACC18AD2 CB-LEFT ENGINE T/R IND	233N5213 81205	1	78-36-11 P011-03/ /K005	115-199
C01481		BACC18AD2 CB-RIGHT ENG T/R IND	233N5212 81205	1	78-36-21 P011-02/ /B029	001-099
C01481		BACC18AD2 CB-RIGHT ENGINE T/R IND	233N5206 81205	1	78-36-21 P011-02/ /B029	115-199
C01482		BACC18AD2 CB-ENGINE T/R CONT-L	233N5211 81205	1	78-34-11 P011-01/ /D012	001-099
C01482		BACC18AD2 CB-ENGINE T/R CONT-L	233N5205 81205	1	78-34-11 P011-01/ /D012	115-199
C01483		BACC18AD2 CB-RIGHT ENGINE T/R CONT	233N5212 81205	1	78-34-21 P011-02/ /B030	ALL
C01498		BACC18AD2 CB-LEFT ENGINE OIL PRESS	233N5213 81205	1	79-32-11 P011-03/ /K009	ALL
C01499		BACC18AD2 CB-RIGHT ENGINE OIL PRESS	233N5214 81205	1	79-32-11 P011-04/ /K035	ALL

EQUIPMENT LIST

D280N032

Section C01400

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01510		BACC18AD5 CB-ENGINES START CONT L	233N5212 81205	1	80-11-11 P011-02/ /D019	001-099
C01510		BACC18AD5 CB-ENGINES START CONT L	233N5206 81205	1	80-11-11 P011-02/ /D019	115-199
C01511		BACC18AD5 CB-ENGINES START CONT R	233N5212 81205	1	80-11-21 P011-02/ /D020	001-099
C01511		BACC18AD5 CB-ENGINES START CONT R	233N5206 81205	1	80-11-21 P011-02/ /D020	115-199
C01521		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 2 PWR	233N5211 81205	1	27-51-61 P011-01/ /C014	001-099
C01521		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 2 PWR	233N5205 81205	1	27-51-61 P011-01/ /C014	115-199
C01522		BACC18AD2 CB-FLAP POS IND R	233N5211 81205	1	27-58-11 P011-01/ /H013	001-099
C01522		BACC18AD2 CB-FLAP POS IND R	233N5205 81205	1	27-58-11 P011-01/ /H013	115-199
C01523		BACC18AD2 CB-STAB POS MOD L	233N5211 81205	1	27-48-21 P011-01/ /G015	001-099
C01523		BACC18AD2 CB-STAB POS MOD L	233N5205 81205	1	27-48-21 P011-01/ /G015	115-199
C01524		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 2 SENSOR	233N5211 81205	1	27-51-61 P011-01/ /C016	001-099
C01524		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 2 SENSOR	233N5205 81205	1	27-51-61 P011-01/ /C016	115-199
C01525		BACC18AD2 CB-STAB POS MOD C	233N5212 81205	1	27-48-21 P011-02/ /F019	001-099
C01525		BACC18AD2 CB-STAB POS MOD C	233N5206 81205	1	27-48-21 P011-02/ /F019	115-199
C01526		BACC18AD2 CB-STAB POS MOD R	233N5212 81205	1	27-48-21 P011-02/ /G024	001-099
C01526		BACC18AD2 CB-STAB POS MOD R	233N5206 81205	1	27-48-21 P011-02/ /G024	115-199
C01528		BACC18AD5 CB-STAB TRIM SHUTOFF L	233N5211 81205	1	27-41-11 P011-01/ /C012	001-099

EQUIPMENT LIST

D280N032

Section C01500

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01528		BACC18AD5 CB-STAB TRIM SHUTOFF L	233N5205 81205	1	27-41-11 P011-01/ /C012	115-199
C01529		BACC18AD5 CB-STAB TRIM SHUTOFF R	233N5211 81205	1	27-41-21 P011-01/ /C013	001-099
C01529		BACC18AD5 CB-STAB TRIM SHUTOFF R	233N5205 81205	1	27-41-21 P011-01/ /C013	115-199
C01531		BACC18AD2 CB-FLT CONT ELEC 1R DC	233N5211 81205	1	27-09-11 P011-01/ /G018	001-099
C01531		BACC18AD2 CB-CSEU 1R DC	233N5205 81205	1	27-09-11 P011-01/ /G018	115-199
C01532		BACC18AD2 CB-FLT CONT ELEC 2R DC	233N5212 81205	1	27-09-11 P011-02/ /G028	001-099
C01532		BACC18AD2 CB-CSEU 2R DC	233N5206 81205	1	27-09-11 P011-02/ /G028	115-199
C01533		BACC18AD2 CB-FLT CONT ELEC 2L DC	233N5211 81205	1	27-09-11 P011-01/ /C009	001-099
C01533		BACC18AD2 CB-CSEU 2L DC	233N5205 81205	1	27-09-11 P011-01/ /C009	115-199
C01534		BACC18AD2 CB-FLT CONT ELEC 1L DC	233N5211 81205	1	27-09-11 P011-01/ /C007	001-099
C01534		BACC18AD2 CB-CSEU 1L DC	233N5205 81205	1	27-09-11 P011-01/ /C007	115-199
C01535		BACC18AD2 CB-FLT CONT ELEC 2R AC	233N5212 81205	1	27-09-11 P011-02/ /G027	001-099
C01535		BACC18AD2 CB-CSEU 2R AC	233N5206 81205	1	27-09-11 P011-02/ /G027	115-199
C01536		BACC18AD2 CB-FLT CONT ELEC 1R AC	233N5211 81205	1	27-09-11 P011-01/ /G017	001-099
C01536		BACC18AD2 CB-CSEU 1R AC	233N5205 81205	1	27-09-11 P011-01/ /G017	115-199
C01537		BACC18AD2 CB-FLT CONT ELEC 2L AC	233N5211 81205	1	27-09-11 P011-01/ /C008	001-099
C01537		BACC18AD2 CB-CSEU 2L AC	233N5205 81205	1	27-09-11 P011-01/ /C008	115-199

EQUIPMENT LIST

D280N032

Section C01500

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01538		BACC18AD2 CB-FLT CONT ELEC 1L AC	233N5211 81205	1	27-09-11 P011-01/ /C006	001-099
C01538		BACC18AD2 CB-CSEU 1L AC	233N5205 81205	1	27-09-11 P011-01/ /C006	115-199
C01539		BACC18AD2 CB-FSEU 1 CONT	233N5211 81205	1	27-51-41 P011-01/ /G013	001-099
C01539		BACC18AD2 CB-FSEU 1 CONT	233N5205 81205	1	27-51-41 P011-01/ /G013	115-199
C01540		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 3 CONT	233N5212 81205	1	27-81-11 P011-02/ /G022	001-099
C01540		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 3 CONT	233N5206 81205	1	27-81-11 P011-02/ /G022	115-199
C01541		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 2 CONT	233N5211 81205	1	27-51-61 P011-01/ /C015	001-099
C01541		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 2 CONT	233N5205 81205	1	27-51-61 P011-01/ /C015	115-199
C01560		BACC18AD2 CB-YAW DAMPER L	233N5211 81205	1	22-21-11 P011-01/ /A018	001-099
C01560		BACC18AD2 CB-YAW DAMPER L	233N5205 81205	1	22-21-11 P011-01/ /A018	115-199
C01561		BACC18AD2 CB-YAW DAMPER R	233N5212 81205	1	22-21-21 P011-02/ /F034	001-099
C01561		BACC18AD2 CB-YAW DAMPER R	233N5206 81205	1	22-21-21 P011-02/ /F034	115-199

EQUIPMENT LIST

D280N032

Section C01500
Page 3 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C03000		BACC18AE35 CB-APU START TRU POWER	284N1315 81205	1	24-32-41 P032-00/ /A006	001-099
C03000		10-60806-1035 CB-APU START TRU POWER	284N1315 81205	1	24-32-41 P032-00/ /A006	115-199
C03002		BACC18AC7 CB-FWD CARGO FAN	284N1129 81205	1	21-43-11 P070-00/ /B008	ALL
C03003		BACC18AC3 CB-LAV FLUSH MOTOR A	233N5213 81205	1	38-32-11 P011-03/ /S006	001-099
C03003		BACC18AC5 CB-LAV FLUSH MOTOR A	233N5207 81205	1	38-32-11 P011-03/ /S008	115-199
C03004		BACC18AC3-PROVISIONS- CB-LAV FLUSH MOTOR B	233N5207 81205	1	38-32-11 P011-03/ /S008	001-099
C03004		BACC18AC5 CB-LAV FLUSH MOTOR B	233N5207 81205	1	38-32-11 P011-03/ /S011	115-199
C03005		BACC18AC5 CB-HF COMM L	233N5211 81205	1	23-11-11 P011-01/ /G008	ALL
C03006		BACC18AC5 CB-HF COMM R	233N5212 81205	1	23-11-21 P011-02/ /G034	ALL
C03007		BACC18AE25 CB-115VAC GND SVCE SECT 1	287N4102 81205	1	24-51-52 P006-04/ /J020	001-099
C03007		10-60806-1025 CB-115VAC GND SVCE SECT 1	287N4102 81205	1	24-51-52 P006-04/ /J020	115-199
C03008	1	10-60806-1025 CB-GND SVCE SECT 2	284N1127 81205	1	24-51-52 P037-00/ /K008	ALL
C03008	2	BACC18AE25 CB-GND SVCE SECT 2	284N1127 81205	1	24-51-52 P037-00/ /K008	ALL
C03009		BACC18AE20 CB-AFT CARGO HTR	284N1129 81205	1	21-44-11 P070-00/ /C008	001-099
C03009		10-60806-20 CB-AFT CARGO HTR	284N1129 81205	1	21-44-11 P070-00/ /C008	115-199
C03010		BACC18AC7 CB-AFT CARGO FAN	284N1127 81205	1	21-44-11 P037-00/ /C002	ALL
C03011		BACC18AC3 CB-LAV FLUSH MOTOR C	233N5214 81205	1	38-32-11 P011-04/ /S027	001-099

EQUIPMENT LIST

D280N032

Section C03000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C03011		BACC18AC5 CB-LAV FLUSH MOTOR C	233N5208 81205	1	38-32-11 P011-04/ /S025	115-199
C03012		BACC18AC3 CB-LAV FLUSH MOTOR D	233N5214 81205	1	38-32-11 P011-04/ /S030	001-099
C03012		BACC18AC5 CB-LAV FLUSH MOTOR D	233N5208 81205	1	38-32-11 P011-04/ /S028	115-199
C03013		BACC18AE35 CB-GALLEY G1A	284N1315 81205	1	25-31-11 P037-00/ /A005	001-099
C03013		10-60806-1035 CB-GALLEY PWR FWD 1	284N1127 81205	1	25-31-11 P037-00/ /K005	115-199
C03014		BACC18AE15 CB-ALTN SLAT PWR	287N4102 81205	1	27-81-11 P006-04/ /D020	001-099
C03014		10-60806-1015 CB-ALTN SLAT PWR	287N4102 81205	1	27-81-11 P006-04/ /D020	115-199
C03015		10-60806-1050 CB-MISC EQPT PWR L	284N1314 81205	1	24-51-11 P031-00/ /A001	ALL
C03016		10-60806-1050 CB-MISC EQPT BUS R	284N1315 81205	1	24-51-21 P032-00/ /A009	ALL
C03018		BACC18AC5 CB-CARGO LOADER DRIVE AFT	284N1316 81205	1	25-51-21 P034-00/ /AB16	115-199
C03020		BACC18AC10 CB-PASS SERVICE OUTLET	287N4102 81205	1	25-29-11 P006-04/ /M019	ALL
C03023		BACC18AE35 CB-FWD 2 GALLEY PWR	284N1127 81205	1	25-31-13 P037-00/ /D002	001-099
C03023		10-60806-35 CB-FWD 2 GALLEY PWR	284N1129 81205	1	25-31-13 P070-00/ /C016	115-199
C03024		10-60806-1025 CB-GALLEY PWR MID AFT R	284N1127 81205	1	25-31-23 P037-00/ /K002	115-199
C03025		10-60806-25 CB-MIDAFT GALLEY PWR	284N1129 81205	1	25-31-27 P070-00/ /C019	115-199
C03026		10-60806-1050 CB-UTIL BUS GALLEYS R	284N1315 81205	1	24-21-24 P032-00/ /A005	ALL
C03027		10-60806-1050 CB-UTIL BUS GALLEYS L	284N1314 81205	1	24-21-14 P031-00/ /A003	115-199

EQUIPMENT LIST

D280N032

Section C03000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C03028		BACC18AC5 CB-AFT EQPT COOLING FANS SPLY NO.2	284N1129 81205	1	21-58-24 P070-00/ /B005	115-199
C03029		BACC18AC5 CB-AFT EQPT COOLING FANS SPLY NO.1	284N1127 81205	1	21-58-24 P037-00/ /D002	115-199
C03043		BACC18AC3 CB-LAV FLUSH MOTOR S	233N5213 81205	1	38-32-11 P011-03/ /S009	001-099
C03044		BACC18AC5 CB-EQ COOL AUX FAN	287N4102 81205	1	21-58-15 P006-03/ /D017	ALL
C03046		BACC18AE35 CB-GALLEY G4A	284N1315 81205	1	25-31-31 P037-00/ /	001-099
C03058		BACC18AE20 CB-HMG L XFR BUS	284N1790 81205	1	24-25-12 P071-00/ /	003-099
C03059		BACC18AE20 CB-HMG R XFR BUS	284N1790 81205	1	24-25-12 P071-00/ /	003-099
C03060		BACC18AC7 CB-HMG INST XFR BUS	284N1790 81205	1	24-25-12 P071-00/ /	003-099
C03061		BACC18AC7 CB-HMG BAT CHGR	284N1790 81205	1	24-25-12 P071-00/ /	003-099

EQUIPMENT LIST

D280N032

Section C03000

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04001		BACC18AD5 CB-LAV WTR HTR A	284N1129 81205	1	38-13-11 P070-00/ /A001	115-199
C04002		BACC18AD5 CB-LAVATORY WATER HEATER B	284N1129 81205	1	38-13-11 P070-00/ /A002	115-199
C04002	1	BACC18AD5-PROVISIONS- CB-LAV WTR HTR B (INOP)	284N1129 81205	1	38-13-11 P070-00/ /A002	001-099
C04003		BACC18AD5 CB-TAT PROBE HEAT	287N4102 81205	1	30-33-11 P006-04/ /L024	ALL
C04014		BACC18AD2 CB-HYDRAULICS ELEC PUMP C-2	233N5214 81205	1	29-11-31 P011-04/ /K024	001-099
C04014		BACC18AD2 CB-HYDRAULICS ELEC PUMP C-2	233N5208 81205	1	29-11-31 P011-04/ /K024	115-199
C04019		BACC18AD2 CB-CABIN ZONE TEMP IND	233N5213 81205	1	21-65-11 P011-03/ /P017	001-099
C04019		BACC18AD2 CB-CABIN ZONE TEMP IND	233N5207 81205	1	21-65-11 P011-03/ /P017	115-199
C04020		BACC18AD2 CB-ZONE FAN AFT	233N5208 81205	1	21-61-31 P011-04/ /P022	115-199
C04021		BACC18AD2 CB-ZONE FAN FWD	233N5208 81205	1	21-61-21 P011-04/ /P021	115-199
C04023		BACC18AD5 CB-HYDRAULICS ENG PUMP SUPPLY L	233N5212 81205	1	29-11-11 P011-02/ /D028	001-099
C04023		BACC18AD5 CB-HYDRAULICS ENG PUMP SUPPLY L	233N5206 81205	1	29-11-11 P011-02/ /D028	115-199
C04024		BACC18AD2 CB-HYDRAULICS LEFT ENGINE PUMP DEPRESS	233N5213 81205	1	29-11-11 P011-03/ /K014	001-099
C04024		BACC18AD2 CB-HYDRAULICS L ENG PUMP VLV DEPRESS	233N5207 81205	1	29-11-11 P011-03/ /K014	115-199
C04025		BACC18AD5 CB-HYDRAULICS ENG PUMP SUPPLY RIGHT	233N5212 81205	1	29-11-21 P011-02/ /D029	001-099
C04025		BACC18AD5 CB-HYDRAULICS ENG PUMP SOV R	233N5206 81205	1	29-11-21 P011-02/ /D029	115-199
C04026		BACC18AD2 CB-HYDRAULICS R ENG PUMP DEPRESS	233N5214 81205	1	29-11-21 P011-04/ /K023	001-099

EQUIPMENT LIST

D280N032

Section C04000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04026		BACC18AD2 CB-HYDRAULICS R ENG PUMP VLV DEPRESS	233N5208 81205	1	29-11-21 P011-04/ /K023	115-199
C04028		BACC18AD3 CB-TAPE RPDR	284N1127 81205	1	23-31-19 P037-00/ /E002	ALL
C04029		BACC18AD2 CB-ZONE DUCT OVHT F/D	233N5214 81205	1	21-61-11 P011-04/ /P025	001-099
C04029		BACC18AD2 CB-ZONE DUCT OVHT F/D	233N5208 81205	1	21-61-11 P011-04/ /P025	115-199
C04030		BACC18AD2 CB-ZONE DUCT OVHT FWD	233N5214 81205	1	21-61-21 P011-04/ /P026	001-099
C04030		BACC18AD2 CB-ZONE DUCT OVHT FWD	233N5208 81205	1	21-61-21 P011-04/ /P026	115-199
C04031		BACC18AD2 CB-ZONE DUCT OVHT AFT	233N5214 81205	1	21-61-31 P011-04/ /P027	001-099
C04031		BACC18AD2 CB-ZONE DUCT OVHT AFT	233N5208 81205	1	21-61-31 P011-04/ /P027	115-199
C04032		BACC18AD5 CB-ELEVATOR LIMIT	233N5213 81205	1	27-31-22 P011-03/ /J012	001-099
C04032		BACC18AD5 CB-ELEVATOR LIMIT	233N5207 81205	1	27-31-22 P011-03/ /J012	115-199
C04033		BACC18AD5 CB-FLT CONT SHUTOFF TAIL L	233N5211 81205	1	27-23-11 P011-01/ /H017	001-099
C04033		BACC18AD5 CB-FLT CONT SHUTOFF TAIL L	233N5205 81205	1	27-23-11 P011-01/ /H017	115-199
C04034		BACC18AD5 CB-FLT/CONT S/O TAIL R	233N5212 81205	1	27-23-11 P011-02/ /H028	001-099
C04034		BACC18AD5 CB-FLT/CONT S/O TAIL R	233N5206 81205	1	27-23-11 P011-02/ /H028	115-199
C04035		BACC18AD5 CB-FLT CONT SHUTOFF TAIL C	233N5211 81205	1	27-23-11 P011-01/ /H018	001-099
C04035		BACC18AD5 CB-FLT CONT SHUTOFF TAIL C	233N5205 81205	1	27-23-11 P011-01/ /H018	115-199
C04036		BACC18AD2 CB-LEFT PACK STBY PWR	233N5214 81205	1	21-51-13 P011-04/ /M024	001-099

EQUIPMENT LIST

D280N032

Section C04000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04036		BACC18AD2 CB-LEFT PACK STBY PWR	233N5208 81205	1	21-51-13 P011-04/ /M024	115-199
C04037		BACC18AD2 CB-LEFT PACK STBY CONT	233N5212 81205	1	21-51-13 P011-02/ /A026	001-099
C04037		BACC18AD2 CB-L PACK STANDBY CONT	233N5206 81205	1	21-51-13 P011-02/ /A026	115-199
C04038		BACC18AD2 CB-RIGHT PACK STANDBY PWR	233N5213 81205	1	21-51-23 P011-03/ /M015	001-099
C04038		BACC18AD2 CB-RIGHT PACK STANDBY PWR	233N5207 81205	1	21-51-23 P011-03/ /M015	115-199
C04039		BACC18AD2 CB-RIGHT PACK STBY CONT	233N5211 81205	1	21-51-23 P011-01/ /A015	001-099
C04039		BACC18AD2 CB-RIGHT PACK STANDBY CONT	233N5205 81205	1	21-51-23 P011-01/ /A016	115-199
C04042		BACC18AD5 CB-SVCE OUTLET E3	284N1127 81205	1	25-29-11 P037-00/ /E006	001-099
C04042		BACC18AD10 CB-SVCE OUTLET E3	284N1127 81205	1	25-29-11 P037-00/ /E006	115-199
C04043		BACC18AD2 CB-HYDRAULICS ELEC PUMP C-1	233N5213 81205	1	29-11-31 P011-03/ /K015	001-099
C04043		BACC18AD2 CB-HYDRAULICS ELEC PUMP C-1	233N5207 81205	1	29-11-31 P011-03/ /K015	115-199
C04044		BACC18AD2 CB-HYDRAULICS ELEC PUMP R	233N5213 81205	1	29-11-22 P011-03/ /K016	001-099
C04044		BACC18AD2 CB-HYDRAULICS ELEC PUMP R	233N5207 81205	1	29-11-22 P011-03/ /K016	115-199
C04045		BACC18AD2 CB-HYDRAULICS ELEC PUMP L	233N5214 81205	1	29-11-12 P011-04/ /K025	001-099
C04045		BACC18AD2 CB-HYDRAULICS ELEC PUMP L	233N5208 81205	1	29-11-12 P011-04/ /K025	115-199
C04046		BACC18AD7 CB-CARGO LIGHTS L	284N1690 81205	1	33-37-21 E006-00/ /	001-099
C04046		BACC18AD7 CB-CARGO LIGHTS L	284N1662 81205	1	33-37-21 E006-00/ /	115-199

EQUIPMENT LIST

D280N032

Section C04000

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04047		BACC18AD7 CB-CARGO LIGHTS R	284N1690 81205	1	33-37-21 E006-00/ /	001-099
C04047		BACC18AD7 CB-CARGO LIGHTS R	284N1662 81205	1	33-37-21 E006-00/ /	115-199
C04048		BACC18AD10 CB-FWD CARGO COMPARTMENT LIGHTS	284N1360 81205	1	33-37-11 0460/163/R030	001-099
C04048		BACC18AD7 CB-FWD CARGO COMPARTMENT LIGHTS	284N1360 81205	1	33-37-11 0460/163/R030	115-199
C04051		BACC18AD5 CB-ATC L	233N5211 81205	1	34-53-11 P011-01/ /F007	001-099
C04051		BACC18AD5 CB-ATC L	233N5205 81205	1	34-53-11 P011-01/ /F007	115-199
C04052		BACC18AD5 CB-ATC R	233N5212 81205	1	34-53-21 P011-02/ /F028	001-099
C04052		BACC18AD5 CB-ATC R	233N5206 81205	1	34-53-21 P011-02/ /F028	115-199
C04054		BACC18AD5 CB-HYDRAULICS PTU CONT	233N5212 81205	1	29-22-11 P011-02/ /D031	001-099
C04054		BACC18AD5 CB-HYDRAULICS PTU CONT	233N5206 81205	1	29-22-11 P011-02/ /D031	115-199
C04059		BACC18AD2 CB-FAN CONTROL FWD CARGO	233N5213 81205	1	21-43-11 P011-03/ /N017	001-099
C04059		BACC18AD2 CB-FAN CONTROL FWD CARGO	233N5207 81205	1	21-43-11 P011-03/ /N012	115-199
C04061		BACC18AD3 CB-RAT AUTO CONT	233N5212 81205	1	29-21-31 P011-02/ /D026	001-099
C04061		BACC18AD3 CB-RAT AUTO CONT	233N5206 81205	1	29-21-31 P011-02/ /D026	115-199
C04062		BACC18AD10 CB-RAT MAN PWR	287N4102 81205	1	29-21-31 P006-01/ /F001	ALL
C04069		BACC18AD2 CB-EQUIP COOLING LO FLOW DET	233N5213 81205	1	21-58-11 P011-03/ /N013	001-099
C04069		BACC18AD2 CB-EQUIP COOLING LO FLOW DET	233N5207 81205	1	21-58-11 P011-03/ /N017	115-199

EQUIPMENT LIST

D280N032

Section C04000

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04070		BACC18AD2 CB-EQUIP COOL GND WARN AND TEST	287N4102 81205	1	21-58-11 P006-01/ /D006	001-099
C04070		BACC18AD2 CB-EQUIP COOL GND WARN AND TEST	287N1055 81205	1	21-58-11 P006-01/ /D006	115-199
C04071		BACC18AD2 CB-AFT CARGO HEAT	233N5213 81205	1	21-44-11 P011-03/ /N018	001-099
C04071		BACC18AD2 CB-AFT CARGO HEAT	233N5207 81205	1	21-44-11 P011-03/ /N018	115-199
C04072		BACC18AD2 CB-FAN CONT AFT CARGO	233N5214 81205	1	21-44-11 P011-04/ /N022	001-099
C04072		BACC18AD2 CB-FAN CONT AFT CARGO	233N5208 81205	1	21-44-11 P011-04/ /N021	115-199
C04073		BACC18AD5 CB-PASS READING LIGHTS FWD RIGHT	284N1127 81205	1	33-23-21 P037-00/ /H001	ALL
C04074		BACC18AD5 CB-PASS READING LIGHTS RIGHT MID FWD	284N1127 81205	1	33-23-22 P037-00/ /H003	ALL
C04075		BACC18AD5 CB-PASS READING LIGHTS RIGHT MID AFT	284N1127 81205	1	33-23-23 P037-00/ /H004	ALL
C04076		BACC18AD5 CB-PASS READING LIGHTS AFT RIGHT	284N1127 81205	1	33-23-24 P037-00/ /H002	ALL
C04078		BACC18AD2 CB-EICAS CMPTR L	233N5213 81205	1	31-41-11 P011-03/ /J002	001-099
C04078		BACC18AD2 CB-EICAS CMPTR L	233N5207 81205	1	31-41-11 P011-03/ /J002	115-199
C04079		BACC18AD2 CB-EICAS CMPTR R	233N5214 81205	1	31-41-21 P011-04/ /J029	001-099
C04079		BACC18AD2 CB-EICAS CMPTR R	233N5208 81205	1	31-41-21 P011-04/ /J029	115-199
C04081		BACC18AD2 CB-EICAS UPPER IND	233N5213 81205	1	31-41-11 P011-03/ /J003	001-099
C04081		BACC18AD2 CB-EICAS UPPER IND	233N5207 81205	1	31-41-11 P011-03/ /J003	115-199
C04082		BACC18AD2 CB-EICAS LOWER IND	233N5214 81205	1	31-41-21 P011-04/ /J030	001-099

EQUIPMENT LIST

D280N032

Section C04000

Page 5

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04082		BACC18AD2 CB-EICAS LOWER IND	233N5208 81205	1	31-41-21 P011-04/ /J030	115-199
C04085		BACC18AD2 CB-EQUIP COOL SMOKE DET/CONT	233N5212 81205	1	21-58-12 P011-02/ /C020	001-099
C04085		BACC18AD2 CB-EQUIP COOL SMOKE DET/CONT	233N5206 81205	1	21-58-12 P011-02/ /C020	115-199
C04086		BACC18AD2 CB-FILL CONT LAV	284N1316 81205	1	38-32-21 P034-00/ /AA03	ALL
C04087		BACC18AD2 CB-SIDEWALL	233N5207 81205	1	33-13-71 P011-03/ /P006	115-199
C04094		BACC18AD2 CB-EICAS PILOTS DSP	233N5214 81205	1	31-41-19 P011-04/ /J032	001-099
C04094		BACC18AD2 CB-EICAS PILOTS DSP	233N5208 81205	1	31-41-19 P011-04/ /J032	115-199
C04095		BACC18AD3 CB-THSHD LAV LIGHTS	284N1316 81205	1	33-26-31 P034-00/ /BD02	ALL
C04097		BACC18AD2 CB-BAT CUR MON PWR	287N4102 81205	1	24-34-11 P006-01/ /A004	ALL
C04099		BACC18AD2 CB-AILERON POS L	233N5213 81205	1	27-18-11 P011-03/ /J014	001-099
C04099		BACC18AD2 CB-AILERON POS L	233N5207 81205	1	27-18-11 P011-03/ /J014	115-199

EQUIPMENT LIST

D280N032

Section C04000

Page 6 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04100		BACC18AD2 CB-AILERON POS R	233N5214 81205	1	27-18-11 P011-04/ /J023	001-099
C04100		BACC18AD2 CB-AILERON POS R	233N5208 81205	1	27-18-11 P011-04/ /J023	115-199
C04101		BACC18AD2 CB-ELEVATOR POS L	233N5213 81205	1	27-38-11 P011-03/ /J013	001-099
C04101		BACC18AD2 CB-ELEVATOR POS L	233N5207 81205	1	27-38-11 P011-03/ /J013	115-199
C04102		BACC18AD2 CB-ELEV POS R	233N5214 81205	1	27-38-11 P011-04/ /J022	001-099
C04102		BACC18AD2 CB-ELEV POS R	233N5208 81205	1	27-38-11 P011-04/ /J022	115-199
C04103		BACC18AD2 CB-LEFT ENGINE EPR XMTR	233N5213 81205	1	77-11-11 P011-03/ /L009	ALL
C04104		BACC18AD2 CB-RIGHT ENGINE EPR XMTR	233N5214 81205	1	77-11-11 P011-04/ /L036	001-099
C04104		BACC18AD2 CB-RIGHT ENGINE EPR XMTR	233N5208 81205	1	77-11-11 P011-04/ /L016	115-199
C04107		BACC18AD2 CB-LEFT ENGINE IDLE CONT	233N5213 81205	1	76-11-21 P011-03/ /L007	ALL
C04108		BACC18AD2 CB-RIGHT ENGINE IDLE CONT	233N5214 81205	1	76-11-21 P011-04/ /L033	ALL
C04110		BACC18AD2 CB-FLAP/SLAT SHUTOFF 1	233N5211 81205	1	27-51-31 P011-01/ /C017	001-099
C04110		BACC18AD2 CB-FLAP/SLAT SHUTOFF 1	233N5005 81205	1	27-51-31 P011-01/ /C018	115-199
C04113		BACC18AD10 CB-ENGINES HP BLD VLV L	233N5212 81205	1	75-31-11 P011-02/ /D021	ALL
C04114		BACC18AD10 CB-ENGINES HP BLD VLV R	233N5212 81205	1	75-31-11 P011-02/ /D022	ALL
C04118		BACC18Z02R CB-ADF R	233N5211 81205	1	34-57-21 P011-01/ /A004	001-099
C04118		BACC18Z02R CB-ADF R	233N5206 81205	1	34-57-21 P011-02/ /F027	115-199

EQUIPMENT LIST

D280N032

Section C04100

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04119		BACC18AD2 CB-LEFT ENGINE EEC LIMITER	233N5213 81205	1	73-21-11 P011-03/ /L004	001-099
C04119		BACC18AD2 CB-LEFT ENGINE EEC LIMITER	233N5207 81205	1	73-21-11 P011-03/ /L004	115-199
C04126		BACC18AD2 CB-ENG START LD SHD RESET	233N5213 81205	1	24-51-71 P011-03/ /R002	001-099
C04126		BACC18AD2 CB-ENG START LD SHD RESET	233N5207 81205	1	24-51-71 P011-03/ /R002	115-199
C04127		BACC18AD2 CB-RIGHT ENGINE EEC LIMITER	233N5214 81205	1	73-21-21 P011-04/ /L031	ALL
C04129		BACC18AD2 CB-LEFT ENGINE EEC SUPV	233N5213 81205	1	73-21-12 P011-03/ /L005	001-099
C04129		BACC18AD2 CB-LEFT ENGINE EEC SUPV	233N5207 81205	1	73-21-12 P011-03/ /L005	115-199
C04130		BACC18AD2 CB-RIGHT ENGINE EEC SUPV	233N5214 81205	1	73-21-22 P011-04/ /L032	ALL
C04131		BACC18AD2 CB-PROBE HEAT IND TAT	233N5214 81205	1	30-33-11 P011-04/ /R025	001-099
C04131		BACC18AD2 CB-PROBE HEAT IND TAT	233N5208 81205	1	30-33-11 P011-04/ /R025	115-199
C04132		BACC18AD2 CB-FUEL DISAGREE ENABLE R	233N5212 81205	1	28-22-21 P011-02/ /D034	001-099
C04132		BACC18AD2 CB-FUEL DISAGREE ENABLE R	233N5206 81205	1	28-22-21 P011-02/ /D034	115-199
C04133		BACC18AD2 CB-FUEL DISAGREE ENABLE L	233N5212 81205	1	28-22-21 P011-02/ /D033	001-099
C04133		BACC18AD2 CB-FUEL DISAGREE ENABLE L	233N5206 81205	1	28-22-21 P011-02/ /D033	115-199
C04134		BACC18AD5 CB-LAV WATER HEATERS C	284N1127 81205	1	38-13-11 P037-00/ /F001	ALL
C04135		BACC18AD5 CB-LAV WATER HEATERS D	284N1127 81205	1	38-13-11 P037-00/ /F002	ALL
C04136		BACC18AD2 CB-FUEL COND CONT L	287N4102 81205	1	76-11-11 P006-01/ /C001	ALL

EQUIPMENT LIST

D280N032

Section C04100

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04137	9	BACC18AD2 CB-FUEL COND CONT R	SB780032 81205	1	76-11-12 P006-01/ /C002	001-002, 115-199
C04137		BACC18AD2 CB-FUEL COND CONT R	287N4102 81205	1	76-11-12 P006-01/ /C002	ALL
C04142		BACC18AD2 CB-L DC VOLT SENSE	287N4102 81205	1	24-34-11 P006-02/ /C011	ALL
C04143		BACC18AD2 CB-R DC VOLT SENSE	287N4102 81205	1	24-34-11 P006-02/ /H010	ALL
C04144		BACC18AD5 CB-DOOR IND	233N5214 81205	1	52-71-11 P011-04/ /R033	001-099
C04144		BACC18AD5 CB-DOOR IND	233N5208 81205	1	52-71-11 P011-04/ /R033	115-199
C04146		BACC18AD10 CB-MAIN ELEC EQUIP CTR LIGHTS	284N1316 81205	1	33-31-41 P034-00/ /BC02	ALL
C04149		BACC18AD7 CB-CARGO LIGHTS NO 1 DOOR	284N1360 81205	1	33-37-11 0460/163/R030	ALL
C04150		BACC18AD7 CB-NO 2 DOOR CARGO LIGHTS	284N1690 81205	1	33-37-21 E006-00/ /	001-099
C04150		BACC18AD7 CB-NO 2 DOOR CARGO LIGHTS	284N1662 81205	1	33-37-21 E006-00/ /	115-199
C04151		BACC18AD2 CB-STBY IND	233N5212 81205	1	77-12-11 P011-02/ /D023	001-099
C04151		BACC18AD2 CB-STBY IND	233N5206 81205	1	77-12-11 P011-02/ /D023	115-199
C04152		BACC18AD2 CB-ENGINES STBY IND 2	233N5206 81205	1	77-12-11 P011-02/ /D024	115-199
C04153		BACC18AD2 CB-L NEUT SEC	285N0001 81205	1	33-16-11 P026-00/ /C005	ALL
C04154		BACC18AD2 CB-L1 SEC	285N0001 81205	1	33-16-11 P026-00/ /C006	ALL
C04155		BACC18AD2 CB-L2A SEC	285N0001 81205	1	33-16-11 P026-00/ /B005	ALL
C04156		BACC18AD2 CB-L2B SEC	285N0001 81205	1	33-16-11 P026-00/ /B006	ALL

EQUIPMENT LIST

D280N032

Section C04100

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04157		BACC18AD2 CB-L AUTOBRT SEC	285N0001 81205	1	33-16-11 P026-00/ /A006	ALL
C04158		BACC18AD2 CB-R NEUT SEC	285N0001 81205	1	33-16-11 P026-00/ /C001	ALL
C04159		BACC18AD2 CB-R1A SEC	285N0001 81205	1	33-16-11 P026-00/ /C002	ALL
C04160		BACC18AD2 CB-R1B SEC	285N0001 81205	1	33-16-11 P026-00/ /B001	ALL
C04161		BACC18AD2 CB-R2A SEC	285N0001 81205	1	33-16-11 P026-00/ /B002	ALL
C04162		BACC18AD2 CB-R2B SEC	285N0001 81205	1	33-16-11 P026-00/ /A001	ALL
C04163		BACC18AD2 CB-BAT NEUT SEC	285N0001 81205	1	33-16-11 P026-00/ /C003	ALL
C04164		BACC18AD2 CB-S1 SEC	285N0001 81205	1	33-16-11 P026-00/ /C004	ALL
C04165		BACC18AD2 CB-S4 SEC	285N0001 81205	1	33-16-61 P026-00/ /B003	ALL
C04166		BACC18AD2 CB-S3 SEC	285N0001 81205	1	33-16-11 P026-00/ /B004	ALL
C04167		BACC18AD2 CB-S2 SEC	285N0001 81205	1	33-16-11 P026-00/ /A003	001-099
C04167		BACC18AD2 CB-S2 SEC	285N0001 81205	1	33-16-11 P026-00/ /A004	115-199
C04169		BACC18AD5 CB-LAV FILL VLV	284N1127 81205	1	38-32-21 P037-00/ /D008	ALL
C04175		BACC18AD2 CB-FUEL DISAGREE ENABLE APU	233N5212 81205	1	28-25-21 P011-02/ /D032	001-099
C04175		BACC18AD2 CB-FUEL DISAGREE ENABLE APU	233N5206 81205	1	28-25-21 P011-02/ /D032	115-199
C04177		BACC18AD7 CB-LANDING GEAR ALTN EXT CONT	287N4102 81205	1	32-12-11 P006-01/ /F005	ALL
C04178		BACC18AD5 CB-LANDING GEAR DOORS CLOSED GROUND ACS	233N5102 81205	1	32-12-12 P011-03/ /S017	ALL

EQUIPMENT LIST

D280N032

Section C04100

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04180		BACC18AD2 CB-AFT CARGO LOADER CONT	284N1316 81205	1	25-51-21 P034-00/ /A007	115-199
C04183		BACC18AD2 CB-DOOR GIRT BAR ENT DIM	233N5214 81205	1	25-66-11 P011-04/ /R034	001-099
C04183		BACC18AD2 CB-DOOR GIRT BAR ENT DIM	233N5208 81205	1	25-66-11 P011-04/ /R034	115-199
C04184		BACC18AD2 CB-ZONE TEMP CONT VLV CL FLT DECK	233N5214 81205	1	21-61-11 P011-04/ /N025	001-099
C04184		BACC18AD2 CB-ZONE TRIM VLV CLOSE F/D	233N5208 81205	1	21-61-11 P011-04/ /N025	115-199
C04185		BACC18AD2 CB-ZONE TEMP CONT VLV CL FWD	233N5214 81205	1	21-61-21 P011-04/ /N026	001-099
C04185		BACC18AD2 CB-ZONE TRIM VLV CLOSE FWD	233N5208 81205	1	21-61-21 P011-04/ /N026	115-199
C04186		BACC18AD2 CB-ZONE TEMP CONT VLV CL AFT	233N5214 81205	1	21-61-31 P011-04/ /N027	001-099
C04186		BACC18AD2 CB-ZONE TRIM VLV CLOSE AFT	233N5208 81205	1	21-61-31 P011-04/ /N027	115-199
C04189		BACC18AD2 CB-EICAS DISPLAY SW	233N5214 81205	1	31-41-21 P011-04/ /J031	001-099
C04189		BACC18AD2 CB-EICAS DISPLAY SW	233N5208 81205	1	31-41-21 P011-04/ /J031	115-199
C04192		BACC18AD2 CB-HYDRAULICS QTY CTR	233N5214 81205	1	29-33-11 P011-04/ /K019	001-099
C04192		BACC18AD2 CB-HYDRAULICS QTY CTR	233N5208 81205	1	29-33-11 P011-04/ /K019	115-199
C04193		BACC18AD2 CB-HYDRAULICS QTY R	233N5214 81205	1	29-33-11 P011-04/ /K021	001-099
C04193		BACC18AD2 CB-HYDRAULICS QTY R	233N5208 81205	1	29-33-11 P011-04/ /K021	115-199
C04194		BACC18AD2 CB-PROBE HEAT IND AOA LEFT	233N5211 81205	1	30-32-11 P011-01/ /D005	001-099
C04194		BACC18AD2 CB-PROBE HEAT IND AOA LEFT	233N5205 81205	1	30-32-11 P011-01/ /D005	115-199

EQUIPMENT LIST

D280N032

Section C04100

Page 5

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04195		BACC18AD2 CB-PROBE HEAT IND AOA R	233N5214 81205	1	30-32-11 P011-04/ /R027	001-099
C04195		BACC18AD2 CB-PROBE HEAT IND AOA R	233N5208 81205	1	30-32-11 P011-04/ /R027	115-199
C04196		BACC18AD2 CB-HI STAGE SW OVER L	233N5213 81205	1	36-11-12 P011-03/ /Q018	001-099
C04196		BACC18AD2 CB-HI STAGE SW OVER L	233N5207 81205	1	36-11-12 P011-03/ /Q018	115-199
C04197		BACC18AD2 CB-HI STAGE SW OVER R	233N5214 81205	1	36-11-22 P011-04/ /Q027	001-099
C04197		BACC18AD2 CB-HI STAGE SW OVER R	233N5208 81205	1	36-11-22 P011-04/ /Q027	115-199

EQUIPMENT LIST

D280N032

Section C04100

Page 6 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04203		BACC18AD5 CB-LOGO LTS L	284N1129 81205	1	33-45-11 P070-00/ /B022	ALL
C04204		BACC18AD5 CB-LOGO LTS R	284N1129 81205	1	33-45-11 P070-00/ /B023	ALL
C04205		BACC18AD2 CB-CABIN ALTM	233N5211 81205	1	21-33-11 P011-01/ /B013	001-099
C04205		BACC18AD2 CB-CABIN ALTM	233N5205 81205	1	21-33-11 P011-01/ /B013	115-199
C04206		BACC18AD2 CB-CABIN DIFF PRESS IND	233N5211 81205	1	21-33-11 P011-01/ /B012	001-099
C04206		BACC18AD2 CB-CABIN DIFF PRESS IND	233N5205 81205	1	21-33-11 P011-01/ /B012	115-199
C04207		BACC18AD2 CB-DUCT LEAK DET L	233N5213 81205	1	26-18-11 P011-03/ /Q017	001-099
C04207		BACC18AD2 CB-DUCT LEAK DET L	233N5207 81205	1	26-18-11 P011-03/ /Q017	115-199
C04208		BACC18AD2 CB-DUCT LEAK DET R	233N5214 81205	1	26-18-11 P011-04/ /Q025	001-099
C04208		BACC18AD2 CB-DUCT LEAK DET R	233N5208 81205	1	26-18-11 P011-04/ /Q025	115-199
C04209		BACC18AD5 CB-STICK SHAKER R	233N5214 81205	1	27-32-21 P011-04/ /J021	001-099
C04209		BACC18AD5 CB-STICK SHAKER R	233N5208 81205	1	27-32-21 P011-04/ /J021	115-199
C04210		BACC18AD2 CB-FLAP/SLAT ELEC UNIT 3 PWR	233N5212 81205	1	27-81-11 P011-02/ /G021	001-099
C04210		BACC18AD2 CB-FSEU 3 PWR	233N5206 81205	1	27-81-11 P011-02/ /G021	115-199
C04211		BACC18AD7 CB-RIGHT SIDEWALL LIGHTS	284N1316 81205	1	33-21-31 P034-00/ /AB12	ALL
C04212		BACC18AD5 CB-FLAP/SLAT ALTN DR ARM	233N5212 81205	1	27-51-21 P011-02/ /H023	001-099
C04212		BACC18AD5 CB-FLAP/SLAT ALTN DR ARM	233N5206 81205	1	27-51-21 P011-02/ /H023	115-199

EQUIPMENT LIST

D280N032

Section C04200

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04216		BACC18AD10 CB-RAT AUTO PWR	233N5212 81205	1	29-21-31 P011-02/ /D027	001-099
C04216		BACC18AD10 CB-RAT AUTO PWR	233N5206 81205	1	29-21-31 P011-02/ /D027	115-199
C04217		BACC18AD2 CB-STBY BUS OFF LT BAT VM	287N4102 81205	1	24-33-11 P006-01/ /G005	ALL
C04218		BACC18AD7 CB-SEAT BELT SIGNS R	284N1316 81205	1	33-24-11 P034-00/ /BE02	ALL
C04219		BACC18AD5 CB-NO SMOKING SIGNS L	284N1316 81205	1	33-24-11 P034-00/ /BF01	ALL
C04220		BACC18AD2 CB-OXY PRESS IND	284N1316 81205	1	35-11-13 P034-00/ /BB02	115-199
C04221		BACC18AD2 CB-DUCT PRESS IND PWR	233N5213 81205	1	36-21-11 P011-03/ /Q015	001-099
C04221		BACC18AD2 CB-DUCT PRESS IND PWR	233N5207 81205	1	36-21-11 P011-03/ /Q015	115-199
C04223		BACC18AD5 CB-PROX SW TEST	233N5214 81205	1	32-09-11 P011-04/ /R036	001-099
C04223		BACC18AD5 CB-PROX SW TEST	233N5208 81205	1	32-09-11 P011-04/ /R036	115-199
C04224		BACC18AD2 CB-F/O INSTR TRANSFER CONT	233N5213 81205	1	24-51-72 P011-03/ /Q006	001-099
C04224		BACC18AD2 CB-F/O INSTR TRANSFER CONT	233N5207 81205	1	24-51-72 P011-03/ /Q006	115-199
C04225		BACC18AD2 CB-CAPT INSTR XFR CONT	233N5214 81205	1	24-51-72 P011-04/ /Q033	001-099
C04225		BACC18AD2 CB-CAPT INSTR XFR CONT	233N5208 81205	1	24-51-72 P011-04/ /Q033	115-199
C04226		BACC18AD5 CB-F/O INSTR TRANSFER ALTN BUS A	233N5213 81205	1	24-51-72 P011-03/ /Q007	001-099
C04226		BACC18AD5 CB-F/O INSTR TRANSFER ALTN BUS A	233N5207 81205	1	24-51-72 P011-03/ /Q007	115-199
C04227		BACC18AD5 CB-CAPT INSTR ALT BUS A	233N5214 81205	1	24-51-72 P011-04/ /Q034	001-099

EQUIPMENT LIST

D280N032

Section C04200

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04227		BACC18AD5 CB-CAPT INSTR ALT BUS A	233N5208 81205	1	24-51-72 P011-04/ /Q034	115-199
C04228		BACC18AD5 CB-F/O INSTR TRANSFER ALTN BUS B	233N5213 81205	1	24-51-72 P011-03/ /Q008	001-099
C04228		BACC18AD5 CB-F/O INSTR TRANSFER ALTN BUS B	233N5207 81205	1	24-51-72 P011-03/ /Q008	115-199
C04229		BACC18AD5 CB-CAPT INSTR ALT BUS B	233N5214 81205	1	24-51-72 P011-04/ /Q035	001-099
C04229		BACC18AD5 CB-CAPT INSTR ALT BUS B	233N5208 81205	1	24-51-72 P011-04/ /Q035	115-199
C04230		BACC18AD5 CB-F/O INSTR TRANSFER ALTN BUS C	233N5213 81205	1	24-51-72 P011-03/ /Q009	001-099
C04230		BACC18AD5 CB-F/O INSTR TRANSFER ALTN BUS C	233N5207 81205	1	24-51-72 P011-03/ /Q009	115-199
C04231		BACC18AD5 CB-CAPT INSTR ALT BUS C	233N5214 81205	1	24-51-72 P011-04/ /Q036	001-099
C04231		BACC18AD5 CB-CAPT INSTR ALT BUS C	233N5208 81205	1	24-51-72 P011-04/ /Q036	115-199
C04234		BACC18AD5 CB-28V DC OUTLET	287N4102 81205	1	25-29-11 P006-02/ /H011	ALL
C04235		BACC18AD2 CB-SPARE LAMP TEST	233N5208 81205	1	33-14-51 P011-04/ /P032	115-199
C04239		BACC18AD2 CB-RBA	233N5205 81205	1	34-22-83 P011-01/ /A006	115-199
C04240		BACC18AD2 CB-RBA,R	233N5206 81205	1	34-22-93 P011-02/ /F025	115-199
C04246		BACC18AD2 CB-APU TOTALIZER	284N1690 81205	1	49-72-11 E006-00/ /	001-099
C04246		BACC18AD2 CB-APU TOTALIZER	284N1662 81205	1	49-72-11 E006-00/ /	115-199
C04247		BACC18AD5 CB-SVCE OUTLETS E5	284N1127 81205	1	25-29-11 P037-00/ /E007	001-099
C04247		BACC18AD10 CB-SVCE OUTLETS E5	284N1127 81205	1	25-29-11 P037-00/ /E007	115-199

EQUIPMENT LIST

D280N032

Section C04200

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04248		BACC18X35 CB-LANDING GEAR ALTN EXT MOTOR	287N4102 81205	1	32-35-11 P006-01/ /F006	ALL
C04251		BACC18AD2 CB-ENGINE SPEED CARD L	233N5212 81205	1	77-12-41 P011-02/ /B031	001-099
C04251		BACC18AD2 CB-ENGINE SPEED CARD L	233N5206 81205	1	77-12-41 P011-02/ /B031	115-199
C04252		BACC18AD2 CB-ENGINE SPEED CARD R	233N5212 81205	1	77-12-42 P011-02/ /B032	001-099
C04252		BACC18AD2 CB-ENGINE SPEED CARD R	233N5206 81205	1	77-12-42 P011-02/ /B032	115-199
C04253		BACC18AD2 CB-FLT DECK FAN	233N5208 81205	1	21-61-11 P011-04/ /P020	115-199
C04255		BACC18AD2 CB-INTERPHONE FLT AMPL ASP 1 BAT PWR	233N5206 81205	1	23-51-11 P011-02/ /C025	115-199
C04256		BACC18AD2 CB-INTERPHONE FLT AMPL ASP 1 R PWR	233N5206 81205	1	23-51-11 P011-02/ /G029	115-199
C04257		BACC18AD2 CB-INTERPHONE ASP 2 BAT PWR	233N5206 81205	1	23-51-21 P011-02/ /C026	115-199
C04258		BACC18AD2 CB-INTERPHONE ASP 2 R PWR	233N5206 81205	1	23-51-11 P011-02/ /G030	115-199
C04259		BACC18AD2 CB-RMI	233N5205 81205	1	34-22-83 P011-01/ /A007	115-199
C04260		BACC18AD2 CB-RMI R	233N5206 81205	1	34-22-93 P011-02/ /F023	115-199
C04261		BACC18AD2 CB-DUCT LEAK CONT	233N5214 81205	1	26-18-11 P011-04/ /Q026	001-099
C04261		BACC18AD2 CB-DUCT LEAK CONT	233N5208 81205	1	26-18-11 P011-04/ /Q026	115-199
C04262		BACC18AD3 CB-AFT WATERLINE HEATERS	284N1127 81205	1	30-71-21 P037-00/ /E001	ALL
C04263		BACC18AD2 CB-EFIS INSTR COMPTR	233N5211 81205	1	34-25-11 P011-01/ /F010	001-099
C04263		BACC18AD2 CB-EFIS INSTR COMPTR	233N5205 81205	1	34-25-11 P011-01/ /F010	115-199

EQUIPMENT LIST

D280N032

Section C04200

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04264		BACC18AD5 CB-CAPT PRIM INSTR BUS A	287N4102 81205	1	24-51-72 P006-03/ /M016	ALL
C04265		BACC18AD5 CB-CAPT PRIM INSTR BUS B	287N4102 81205	1	24-51-72 P006-03/ /M017	ALL
C04266		BACC18AD5 CB-CAPT PRIM INSTR BUS C	287N4102 81205	1	24-51-72 P006-03/ /M018	ALL
C04267		BACC18AD5 CB-F/O PRIM INSTR BUS A	287N4102 81205	1	24-51-72 P006-04/ /M022	ALL
C04268		BACC18AD5 CB-F/O PRIM INSTR BUS B	287N4102 81205	1	24-51-72 P006-04/ /M023	ALL
C04269		BACC18AD5 CB-F/O PRIM INSTR BUS C	287N4102 81205	1	24-51-72 P006-04/ /M024	ALL
C04270		BACC18AD2 CB-PCU MON MOD	233N5213 81205	1	27-23-21 P011-03/ /J011	001-099
C04270		BACC18AD2 CB-PCU MON MOD	233N5207 81205	1	27-23-21 P011-03/ /J011	115-199
C04271		BACC18AD2 CB-FLAP/SLAT SHUTOFF 2	233N5212 81205	1	27-51-31 P011-02/ /H024	001-099
C04271		BACC18AD2 CB-FLAP/SLAT SHUTOFF 2	233N5206 81205	1	27-51-31 P011-02/ /H024	115-199
C04275		BACC18AD2 CB-EXT STBY CONT	233N5212 81205	1	24-33-12 P011-02/ /A020	001-099
C04275		BACC18AD2 CB-EXT STBY CONT	233N5206 81205	1	24-33-11 P011-02/ /A020	115-199
C04276		1500-052-05 CB-EXT STBY BAT	233N5212 76374	1	24-33-12 P011-02/ /A019	001-099
C04276		1500-052-05 CB-EXT STBY BAT	233N5206 76374	1	24-33-12 P011-02/ /A019	115-199
C04279		BACC18AD2 CB-LANDING GEAR POS SYS 2	233N5214 81205	1	32-61-11 P011-04/ /S023	001-099
C04279		BACC18AD2 CB-LANDING GEAR POS SYS 2	233N5208 81205	1	32-61-11 P011-04/ /S023	115-199
C04280		BACC18AD2 CB-GLARESHIELD FLOOD	233N5213 81205	1	33-11-21 P011-03/ /P007	001-099

EQUIPMENT LIST

D280N032

Section C04200

Page 5

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04280		BACC18AD2 CB-GLARESHIELD FLOOD	233N5207 81205	1	33-11-21 P011-03/ /P007	115-199
C04281		BACC18AD2 CB-PARK BRAKE GND IND	233N5206 81205	1	32-44-11 P011-02/ /D025	115-199
C04282		BACC18R100C CB-APU/MAIN BAT TIE	287N4102 81205	1	24-31-11 P006-02/ /L007	ALL
C04283		BACC18AD2 CB-PCU MON SENSOR	233N5213 81205	1	27-23-21 P011-03/ /J010	001-099
C04283		BACC18AD2 CB-PCU MON SENSOR	233N5207 81205	1	27-23-21 P011-03/ /J010	115-199
C04285		BACC18AD7 CB-ENTRY & GALLEY LIGHTS PWR	284N1127 81205	1	33-22-11 P037-00/ /G005	115-199
C04286		BACC18AD2 CB-BAT DISCH IND INHIBIT	284N1690 81205	1	24-31-41 E006-00/ /	001-099
C04287		BACC18AD2 CB-RAT MAN CONT	287N4102 81205	1	29-21-31 P006-01/ /F002	001-099
C04290		BACC18AD2 CB-W/W FIRE TEST	233N5212 81205	1	26-17-11 P011-02/ /B035	001-099
C04290		BACC18AD2 CB-W/W FIRE TEST	233N5206 81205	1	26-17-11 P011-02/ /B035	115-199
C04291		BACC18AD2 CB-MN/APU BAT CHGR DET ENABLE	284N1316 81205	1	24-34-11 P034-00/ /AA16	ALL
C04292		BACC18AD7 CB-HYDRAULICS RESERVE BRAKE SOURCE	233N5214 81205	1	29-21-32 P011-04/ /K022	001-099
C04292		BACC18AD7 CB-HYDRAULICS RESERVE BRAKE SOURCE	233N5208 81205	1	29-21-32 P011-04/ /K022	115-199
C04298		BACC18AD5 CB-ENG PROBE HTR L	233N5213 81205	1	30-34-21 P011-03/ /R014	001-099
C04298		BACC18AD5 CB-ENG PROBE HTR L	233N5207 81205	1	30-34-21 P011-03/ /R014	115-199
C04299		BACC18AD5 CB-ENG PROBE HTR R	233N5214 81205	1	30-34-22 P011-04/ /R023	001-099
C04299		BACC18AD5 CB-ENG PROBE HTR R	233N5208 81205	1	30-34-22 P011-04/ /R023	115-199

EQUIPMENT LIST

D280N032

Section C04200

Page 6 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04308		BACC18AD2 CB-PROBE HEAT IND ENG L	233N5213 81205	1	30-34-21 P011-03/ /R016	001-099
C04308		BACC18AD2 CB-PROBE HEAT IND ENG L	233N5207 81205	1	30-34-21 P011-03/ /R016	115-199
C04309		BACC18AD2 CB-PROBE HEAT IND ENG R	233N5214 81205	1	30-34-22 P011-04/ /R024	001-099
C04309		BACC18AD2 CB-PROBE HEAT IND ENG R	233N5208 81205	1	30-34-22 P011-04/ /R024	115-199
C04313	9	BACC18AD5 CB-ICE DETECTOR	233N5214	0	30-81-11 P011-04/ /R019	010-099
C04317		BACC18AD2 CB-RIGHT ENGINE VIB MONITOR	233N5214 81205	1	77-31-11 P011-04/ /K028	001-099
C04317		BACC18AD2 CB-RIGHT ENGINE VIB MONITOR	233N5208 81205	1	77-31-11 P011-04/ /K028	115-199
C04329		BACC18AD2 CB-HYD EMP ENABLE C1	287N4102 81205	1	29-11-31 P006-03/ /K013	ALL
C04330		BACC18AD2 CB-HYD EMP ENABLE R	287N4102 81205	1	29-11-22 P006-03/ /K014	ALL
C04331		BACC18AD2 CB-HYD EMP ENABLE C2	287N4102 81205	1	29-11-31 P006-04/ /K019	ALL
C04341		BACC18AD5 CB-LAV WTR HTR S	284N1129 81205	1	38-13-11 P070-00/ /A002	001-099
C04348		BACC18X50 CB-HYD GEN 28V DC PWR	287N4102 81205	1	24-31-11 P006-01/ /C007	001-002
C04348		BACC18X50 CB-HYD GEN 28V DC PWR	287N4102 81205	1	24-31-11 P006-02/ /C007	003-099, 115-199
C04349		BACC18AD5 CB-HYD GEN CONT	287N4102 81205	1	24-25-11 P006-01/ /C003	ALL
C04350		BACC18AD2 CB-HYD GEN DC VOLT SENSE	284N1790 81205	1	24-25-13 P071-00/ /	001-002, 115-199
C04351		BACC18AD2 CB-HYD GEN AC VOLT SENSE	284N1790 81205	1	24-25-13 P071-00/ /	ALL
C04353		BACC18AD2 CB-28V AC BUS L XFR	287N4102 81205	1	24-51-15 P006-03/ /L013	ALL

EQUIPMENT LIST

D280N032

Section C04300

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04355		BACC18AD2 CB-28V AC BUS R XFR	287N4102 81205	1	24-51-25 P006-04/ /M021	ALL
C04356		BACC18AD2 CB-L AC BUS SENSE RELAY (REF 24-51-11)	233N5213 81205	1	24-25-11 P011-03/ /R006	ALL
C04357		BACC18AD2 CB-R AC BUS SENSE RELAY (REF 24-51-21)	233N5214 81205	1	24-25-11 P011-04/ /R029	001-099
C04357		BACC18AD2 CB-R AC BUS SENSE RELAY (REF 24-51-21)	233N5208 81205	1	24-25-11 P011-04/ /R029	115-199
C04359		BACC18AD2 CB-EMER NIGHT LTS	284N1316 81205	1	33-21-51 P034-00/ /BH01	001-099
C04359		BACC18AD2 CB-EMER NIGHT LTS	284N1316 81205	1	33-21-51 P034-00/ /BA01	115-199
C04360		BACC18AD7 CB-LAV DOME,OCCUPY LTS ALTN	284N1316 81205	1	33-26-11 P034-00/ /BA02	001-099
C04360		BACC18AD5 CB-LAV DOME,OCCUPY LTS ALTN	284N1316 81205	1	33-26-11 P034-00/ /BA02	115-199
C04361		BACC18AD7 CB-VIDEO MONITOR FWD-UTILITY	284N1127 81205	1	23-32-01 P037-00/ /C006	001-099
C04361		BACC18AD7 CB-VIDEO MONITOR FWD-UTILITY	284N1127 81205	1	23-32-01 P037-00/ /C007	115-199
C04362		BACC18AD7 CB-VIDEO SYSTEM MONITOR AFT-UTIL	284N1127 81205	1	23-32-01 P037-00/ /C007	001-099
C04362		BACC18AD7 CB-VIDEO SYSTEM MONITOR AFT-UTIL	284N1127 81205	1	23-32-01 P037-00/ /	115-199
C04363		BACC18AD7 CB-AC,VIDEO SYSTEM CONT-UTILITY	284N1127 81205	1	23-32-01 P037-00/ /C008	ALL
C04364		BACC18AD5 CB-DC,VIDEO SYSTEM CONT	233N5212 81205	1	23-32-02 P011-02/ /H030	ALL
C04366		BACC18AD2 CB-LIGHTS,EMER ATTEND WORK	284N1316 81205	1	33-22-11 P034-00/ /BA03	ALL
C04367		BACC18AD3 CB-GND-DRAIN MAST HTR	284N1316 81205	1	30-71-11 P034-00/ /BB03	ALL
C04373		BACC18AD2 CB-L RECIRC FAN CONT	284N1129 81205	1	21-25-11 P070-00/ /B016	ALL

EQUIPMENT LIST

D280N032

Section C04300

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04374		BACC18AD2 CB-R RECIRC FAN CONT	284N1127 81205	1	21-25-11 P037-00/ /D007	ALL
C04375		BACC18AD2 CB-PASS CALL/LAV SMOKE,R	233N5213 81205	1	33-25-21 P011-03/ /N009	ALL
C04376		BACC18AD2 CB-PASS CALL/LAV SMOKE,L	233N5213 81205	1	33-25-11 P011-03/ /N008	ALL

EQUIPMENT LIST

D280N032

Section C04300
Page 3 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04403		BACC18AD5 CB-MULTIPLEXER	284N1127 81205	1	23-34-15 P037-00/ /B008	001-099
C04403		BACC18AD5 CB-MULTIPLEXER	284N1127 81205	1	23-34-15 P037-00/ /	115-199
C04423		BACC18AD2 CB-ATC ANT SWITCH	233N5212 81205	1	34-53-21 P011-02/ /E028	ALL
C04426		BACC18AD5 CB-ENT TAPE RPDR	284N1127 81205	1	23-34-15 P037-00/ /B007	001-099
C04440		BACC18AD7 CB-VIDEO MONITOR FWD-MAIN	284N1127 81205	1	23-32-01 P037-00/ /A006	ALL
C04441		BACC18AD7 CB-VIDEO SYSTEM MONITOR AFT MAIN(BUS)	284N1127 81205	1	23-32-01 P037-00/ /A007	ALL
C04442		BACC18AD7 CB-AC,VIDEO SYSTEM MAIN(BUS)	284N1127 81205	1	23-32-01 P037-00/ /A008	ALL
C04443		BACC18AD5 CB-TCAS	233N5211 81205	1	34-45-01 P011-01/ /F003	001-099
C04443		BACC18AD5 CKTBKR-TCAS	233N5211 81205	1	34-45-01 P011-01/ /G002	115-199
C04459		BACC18AD3 CB-ACMS	233N5214 81205	1	31-31-02 P011-04/ /J034	001-099
C04470	9	BACC18AD5 CB-SYNC-LOCK-R	SB780032 81205	1	78-34-61 P011-04/ /K032	001-002, 115-199
C04470		BACC18AD5 CB-SYNC-LOCK-R	233N5214 81205	1	78-34-61 P011-04/ /K032	003-099
C04471	9	BACC18AD2 CB-T/R CONT-R	SB780032 81205	1	78-34-21 P011-04/ /K033	001-002, 115-199
C04471		BACC18AD2 CB-T/R CONT-R	233N5214 81205	1	78-34-21 P011-04/ /K033	003-099
C04472	9	BACC18AD5 CB-LEFT ENG SYNC LOCK CONT	SB780032 81205	1	78-34-51 P006-02/ /C012	001, 115-199
C04472	9	BACC18AD5 CB-LEFT ENG SYNC LOCK CONT	SB780028 81205	1	78-34-51 P006-02/ /C012	002
C04472		BACC18AD5 CB-LEFT ENG SYNCH LOCK	287N4102 81205	1	78-34-51 P006-02/ /C012	003-099

EQUIPMENT LIST

D280N032

Section C04400

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04474	9	BACC18AD5 CB- RIGHT ENG SYNC LOCK CONT	SB780032 81205	1	78-34-61 P006-02/ /D012	001, 115-199
C04474	9	BACC18AD5 CB- RIGHT ENG SYNC LOCK CONT	SB780028 81205	1	78-34-61 P006-02/ /D012	002
C04474		BACC18AD5 CB-RIGHT ENG SYNCH LOCK	287N4102 81205	1	78-34-61 P006-02/ /D012	003-099
C04476		BACC18Z02R CB-FWD FUEL CROSSFEED VALVE	233N5212 81205	1	28-22-31 P011-02/ /D024	009-099
C04477		BACC18Z02R CB-AFT FUEL CROSSFEED VALVE	233N5212 81205	1	28-22-31 P011-02/ /D025	009-099
C04478	9	BACC18AD2 CB-LANDING GEAR POS SYS 2 ALTN	SB780028 81205	1	32-61-11 P011-02/ /C019	001-002, 115-199
C04478		BACC18AD2 CB-LANDING GEAR POS SYS 2 ALTN	233N5212 81205	1	32-61-11 P011-02/ /C019	003-099
C04485		BACC18Z02R CB-FUEL XFEED IND	233N5212 81205	1	28-22-31 P011-02/ /D036	009-099
C04499	9	BACC18AD2 CB-METRIC ALTM,L	233N5205 81205	1	34-13-11 P011-01/ /E007	010-099

EQUIPMENT LIST

D280N032

Section C04400

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04509	9	BACC18AD2 CB-TERR DSPL	233N5102 81205	1	34-46-14 P011-01/ /E012	002

EQUIPMENT LIST

D280N032

Section C04500

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04600	9	BACC18Z02R CB-MMR L	233N5102 81205	1	34-31-11 P011-01/ /E010	115-199
C04601	9	BACC18Z02R CB-MMR R	233N5102 81205	1	34-31-21 P011-02/ /E031	115-199
C04602	9	BACC18Z02R CB-MMR C	233N5102 81205	1	34-31-31 P011-01/ /A003	115-199
C04664	9	BACC18AD2 CB-L AIR DATA SOURCE SEL RLY(SB 34A0222)	233N5040 81205	1	34-12-61 P011-01/ /B004	ALL
C04665	9	BACC18AD2 CB-R AIR DATA SOURCE SEL RLY(SB 34A0222)	233N5040 81205	1	34-12-62 P011-01/ /B005	ALL
C04679	9	BACC18AD2 CB FUEL-AUTO S/O OVRD CTR L (SB 28A0081)	233N5103 81205	1	28-22-11 P011-03/ /L013	ALL
C04680	9	BACC18AD2 CB FUEL-AUTO S/O OVRD CTR R (SB 28A0081)	233N5102 81205	1	28-22-11 P011-04/ /L025	ALL

EQUIPMENT LIST

D280N032

Section C04600

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00001	1	MS3126F20-41S PLUG-	71468	1	23-71-11 P005-00/ /	001-099
D00001	1	MS3126F20-41S PLUG-	71468	1	23-71-11 P5/ /	115-199
D00003	1	DPXBMB-57-33S-0001 PLUG-	71468	1	23-71-11 1625/293/R006	001-099
D00003	1	DPXBMB-57-33S-0001 PLUG-	71468	1	23-71-11 1625/290/R006	115-199
D00005	1	BACC66F11C1401 PLUG PLATE ASSY-	81205	1	23-31-11 E004-03/ /	001-099
D00005	1	BACC66F11C1401 PLUG PLATE ASSY-	81205	1	23-31-11 E4-3/ /	115-199
D00005A	1	PARTAOFD00005 PLUG-		0	23-31-11 E004-03/ /	001-099
D00005A	1	PARTAOFD00005 PLUG-		0	23-31-11 E4-3/ /	115-199
D00005B	1	PARTBOFD00005 PLUG-		0	23-31-11 E004-03/ /	001-099
D00005B	1	PARTBOFD00005 PLUG-		0	23-31-11 E4-3/ /	115-199
D00005C	1	PARTCOFD00005 PLUG-		0	23-31-11 E004-03/ /	001-099
D00005C	1	PARTCOFD00005 PLUG-		0	23-31-11 E4-3/ /	115-199
D00007	1	BACC66F11C0701 PLUG PLATE ASSY-	81205	1	23-31-11 E004-03/ /	001-099
D00007	1	BACC66F11C0701 PLUG PLATE ASSY-	81205	1	23-31-11 E4-3/ /	115-199
D00007A	1	PARTAOFD00007 PLUG-		0	23-31-11 E004-03/ /	001-099
D00007A	1	PARTAOFD00007 PLUG-		0	23-31-11 E4-3/ /	115-199
D00007B	1	PARTBOFD00007 PLUG-		0	23-31-11 E004-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D00000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00007B	1	PARTBOFD00007 PLUG-		0	23-31-11 E4-3/ /	115-199
D00007C	1	PARTCOFD00007 PLUG-		0	23-31-11 E004-03/ /	001-099
D00007C	1	PARTCOFD00007 PLUG-		0	23-31-11 E4-3/ /	115-199
D00009	1	BACC45FT16A24S PLUG-	81205	1	31-31-01 P061-00/ /	001-099
D00011	1	BACC66K31C0101 PLUG PLATE ASSY-	81205	1	31-31-01 E3-3/ /	001-099
D00011	1	BACC66K31C0101 PLUG PLATE ASSY-	81205	1	31-31-11 E3-3/ /	115-199
D00011A	1	PARTAOFD00011 PLUG-	81205	0	31-31-01 E3-3/ /	001-099
D00011A	1	PARTAOFD00011 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00011B	1	PARTBOFD00011 PLUG-	81205	0	31-31-01 E3-3/ /	001-099
D00011B	1	PARTBOFD00011 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00011C	1	PARTCOFD00011 PLUG-	81205	0	31-31-01 E3-3/ /	001-099
D00011C	1	PARTCOFD00011 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00011D	1	PARTDOFD00011 PLUG-	81205	0	31-31-01 E3-3/ /	001-099
D00011D	1	PARTDOFD00011 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00011E	1	PARTEOFD00011 PLUG-	81205	0	31-31-01 E3-3/ /	001-099
D00011E	1	PARTEOFD00011 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00011F	1	PARTFOFD00011 PLUG-	81205	0	31-31-01 E3-3/ /	001-099

EQUIPMENT LIST

D280N032

Section D00000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00011F	1	PARTFOFD00011 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00013	1	DPX2MB-57S00S-33-0001 PLUG PLATE ASSY-	71468	1	31-31-01 1620/295/L005	ALL
D00013A	1	PARTAOFD00013 PLUG-		0	31-31-01 1620/295/L005	ALL
D00013B	1	PARTBOFD00013 PLUG-		0	31-31-01 1620/295/L005	ALL
D00017	1	MS3126F12-10S PLUG	71468	1	31-31-13 1069/186/L025	001-008
D00017	1	MS3126F12-10S PLUG	71468	1	31-31-51 1069/186/L025	009-099, 115-199
D00018	1	BACC63BP14A7SNL PLUG-	81205	1	33-44-21 WS817/ /L	ALL
D00018 T		BACC10HG14 CABLE CLAMP-	81205	1	33-44-21 */ */*	ALL
D00020	1	BACC63BP14A7SNL PLUG-	81205	1	33-44-21 WS817/ /R	ALL
D00020 T		BACC10HG14 CABLE CLAMP-	81205	1	33-44-21 */ */*	ALL
D00022	1	BACC63BP14A4SNL PLUG-	81205	1	33-43-11 WBL740/ /L	ALL
D00022 T		BACC10HF14 CABLE CLAMP-	81205	1	33-43-11 */ /	ALL
D00025	1	BACC63BP22A19SNL PLUG.	81205	1	22-11-11 1040/185/L50	ALL
D00025 T		BACC10HF22A CABLE CLAMP	81205	1	22-11-11 1040/185/L50	ALL
D00028	1	BACC63BP14A4SNL PLUG-	81205	1	33-43-12 WBL740/ /R	ALL
D00028 T		BACC10HF14 CABLE CLAMP-	81205	1	33-43-12 WBL740/ /R	ALL
D00029	1	BACC63BP22A19SNL PLUG-	81205	1	22-11-11 1860/245/R10	ALL

EQUIPMENT LIST

D280N032

Section D00000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00029 T		BACC10HF22 CABLE CLAMP	81205	1	22-11-11 */ */	ALL
D00030	1	BACC63BP14A4SNL PLUG-	81205	1	33-43-12 WBL740/ /R	ALL
D00030 T		BACC10HF14 CABLE CLAMP-	81205	1	33-43-12 WBL740/ /	ALL
D00031	1	BACC63BP22A19SNL PLUG-	81205	1	22-11-11 FIN90/RS/	ALL
D00031 T		BACC10HG22 CABLE CLAMP	81205	1	22-11-11 */ */	ALL
D00035	1	BACC66H21C0701 PLUG PLATE ASSY-	81205	1	22-11-12 E002-01/ /	001-099
D00035	1	BACC66H21C0701 PLUG PLATE ASSY-	81205	1	22-11-12 E2-1/ /	115-199
D00035A	1	PARTAOFD00035 PLUG-		0	22-11-12 E002-01/ /	001-099
D00035A	1	PARTAOFD00035 PLUG-		0	22-11-12 E2-1/ /	115-199
D00035B	1	PARTBOFD00035 PLUG-		0	22-11-12 E002-01/ /	001-099
D00035B	1	PARTBOFD00035 PLUG-		0	22-11-12 E2-1/ /	115-199
D00035C	1	PARTCOFD00035 PLUG-		0	22-11-11 E002-01/ /	001-099
D00035C	1	PARTCOFD00035 PLUG-		0	22-11-11 E2-1/ /	115-199
D00036	1	BACC63BP14A4SNL PLUG-	81205	1	33-43-11 WBL740/ /	ALL
D00036 T		BACC10HF14 CABLE CLAMP-	81205	1	33-43-11 */ /	ALL
D00037	1	BACC45FT18A31S PLUG-	81205	1	22-11-12 P055-00/ /	ALL
D00038	1	BACC63BP14A7SNL PLUG	81205	1	33-44-11 1030/140/L010	001-099

EQUIPMENT LIST

D280N032

Section D00000

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00038	1	BACC63BP14A7SNL PLUG	81205	1	33-44-11 1030/134/L010	115-199
D00038 T	1	BACC10HF14 CABLE CLAMP	81205	1	33-44-11 */*/	ALL
D00040	1	BACC45FS14A7S PLUG-	81205	1	33-44-11 591/295/R30	ALL
D00042	1	BACC45FN24A43S RCPT-	81205	1	38-32-11 354/290/L30	001-099
D00042	1	BACC45FN24A43S RCPT-	81205	1	38-32-11 AA0360/ /	115-199
D00044	1	BACC45FT24A43S PLUG-	81205	1	38-32-11 1246/290/L24	001-099
D00044	1	BACC45FT24A43S PLUG-	81205	1	38-32-11 380/295/L37	115-199
D00045	1	BACC63BP22A19SNL PLUG	81205	1	22-11-31 1055/165/L015	ALL
D00045 T		BACC10HF22 CABLE CLAMP	81205	1	22-11-31 */*/	ALL
D00046	1	BACC45FT24A43S PLUG-	81205	1	38-32-11 1305/290/L22	001-099
D00046	1	BACC45FT24A43S PLUG-	81205	1	38-32-11 1284/295/L35	115-199
D00048	1	BACC45FT24A43S PLUG-	81205	1	38-32-11 1290/290/R22	001-099
D00048	1	BACC45FT24A43S PLUG-	81205	1	38-32-11 1284/295/R35	115-199
D00049	1	BACC63BP22A19SNL PLUG-	81205	1	22-11-31 1860/235/R10	ALL
D00049 T		BACC10HG22A CABLE CLAMP	81205	1	22-11-31 1860/235/R10	ALL
D00050	1	BACS16X1A RELAY SOCKET	81205	1	38-14-11 P34/ /	ALL
D00051	1	BACC63BP22A19SNL PLUG-	81205	1	22-11-31 FIN 90/89/	ALL

EQUIPMENT LIST

D280N032

Section D00000

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00051 T		BACC10HG22 CABLE CLAMP	81205	1	22-11-31 FIN90/89/	ALL
D00052	1	BACC45FT12D12S PLUG	81205	1	38-14-11 1670/187/0	001-099
D00052	1	BACC45FT12D12S PLUG	81205	1	38-14-11 1670/197/0	115-199
D00055	1	BACC66H21C0701 PLUG PLATE ASSY-	81205	1	22-11-31 E002-03/ /	001-099
D00055	1	BACC66H21C0701 PLUG PLATE ASSY-	81205	1	22-11-31 E2-3/ /	115-199
D00055A	1	PARTAOFD00055 PLUG-		0	22-41-11 E002-03/ /	001-099
D00055A	1	PARTAOFD00055 PLUG-		0	22-41-11 E2-3/ /	115-199
D00055B	1	PARTBOFD00055 PLUG-		0	22-41-11 E002-03/ /	001-099
D00055B	1	PARTBOFD00055 PLUG-		0	22-41-11 E2-3/ /	115-199
D00055C	1	PARTCOFD00055 PLUG-		0	22-11-31 E002-03/ /	001-099
D00055C	1	PARTCOFD00055 PLUG-		0	22-11-31 E2-3/ /	115-199
D00056	1	BACC45FT10D5S PLUG	81205	1	38-14-11 1650/158/L011	ALL
D00057	1	BACC45FT18A31S6 PLUG-	81205	1	22-11-32 P055-00/ /	ALL
D00060	1	10-60450-5 RELAY SOCKET (PLATE 'B')	81205	1	38-15-11 P037-00/ /	001-099
D00060	1	10-60450-5 RELAY SOCKET (PLATE 'B')	81205	1	38-15-11 P37/ /	115-199
D00062	1	BACC45FT10A5S PLUG	81205	1	38-15-11 1670/202/R031	001-099
D00062	1	BACC45FT10A5S PLUG	81205	1	38-15-11 1670/192/R040	115-199

EQUIPMENT LIST

D280N032

Section D00000

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00064	1	BACC45FT10D5S PLUG	81205	1	38-15-11 1684/200/R031	001-099
D00064	1	BACC45FT10D5S PLUG	81205	1	38-15-11 1684/200/R005	115-199
D00065	1	BACC63BP22A19SNL PLUG	81205	1	22-11-22 1048/170/R013	ALL
D00065 T		BACC10HF22 CABLE CLAMP	81205	1	22-11-22 */*/	ALL
D00066	1	BACC45FT16A24S PLUG-	81205	1	33-51-12 340/290/L05	ALL
D00068	1	BACC45FT16A24S PLUG-	81205	1	33-51-12 368/289/L005	001-099
D00068	1	BACC45FT16A24S PLUG-	81205	1	33-51-12 369/289/L005	115-199
D00069	1	BACC63BP22A19SNL PLUG-	81205	1	22-11-21 1860/225/R10	ALL
D00069 T		BACC10HG22 CABLE CLAMP	81205	1	22-11-21 */*/	ALL
D00070	1	BACC45FT16A24S PLUG-	81205	1	33-51-13 705/287/R46	ALL
D00071	1	BACC63BP22A19SNL PLUG-	81205	1	22-11-21 FIN90/RS4/	ALL
D00071 T		BACC10HG22 CABLE CLAMP	81205	1	22-11-21 FIN 90/ /	ALL
D00072	1	BACC45FT16A24S PLUG-	81205	1	33-51-13 705/287/L046	001-099
D00072	1	BACC45FT16A24S PLUG-	81205	1	33-51-13 705/287/L46	115-199
D00074	1	BACC45FT16A24S PLUG-	81205	1	33-51-14 1322/272/R49	ALL
D00075	1	BACC66H21C0701 PLUG-	81205	1	32-09-11 E002-02/ /	001-099
D00075	1	BACC66H21C0701 PLUG-	81205	1	22-11-21 E2-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D00000

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00075A	1	PARTAOFD00075 PLUG-		0	22-41-12 E002-02/ /	001-099
D00075A	1	PARTAOFD00075 PLUG-		0	22-11-22 E2-2/ /	115-199
D00075B	1	PARTBOFD00075 PLUG-		0	22-11-22 E002-02/ /	001-099
D00075B	1	PARTBOFD00075 PLUG-		0	22-11-22 E2-2/ /	115-199
D00075C	1	PARTCOFD00075 PLUG-		0	22-11-21 E002-02/ /	001-099
D00075C	1	PARTCOFD00075 PLUG-		0	22-11-21 E2-2/ /	115-199
D00076	1	BACC45FT16A24S PLUG-EMER LT MID-AFT	81205	1	33-51-14 1322/272/L049	001-099
D00076	1	BACC45FT16A24S PLUG-EMER LT MID-AFT	81205	1	33-51-14 1322/272/L49	115-199
D00077	1	BACC45FT18A31S7 PLUG-	81205	1	22-11-22 P055-00/ /	ALL
D00078	1	BACC45FT16A24S PLUG-	81205	1	33-51-15 1678/289/R03	ALL
D00079	1	BACC66H21C1701 PLUG PLATE ASSY-	81205	1	22-41-11 E003-02/ /	001-099
D00079	1	BACC66H21C1701 PLUG PLATE ASSY-	81205	1	22-41-11 E3-2/ /	115-199
D00079A	1	PARTAOFD00079 PLUG-		0	22-41-11 E003-02/ /	001-099
D00079A	1	PARTAOFD00079 PLUG-		0	22-41-11 E3-2/ /	115-199
D00079B	1	PARTBOFD00079 PLUG-		0	22-41-11 E003-02/ /	001-099
D00079B	1	PARTBOFD00079 PLUG-		0	22-41-11 E3-2/ /	115-199
D00079C	1	PARTCOFD00079 PLUG-		0	22-41-11 E003-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D00000

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00079C	1	PARTCOFD00079 PLUG-		0	22-41-11 E3-2/ /	115-199
D00080	1	BACC45FT16A24S PLUG-EMER LT AFT	81205	1	33-51-15 1678/289/L003	001-099
D00080	1	BACC45FT16A24S PLUG-EMER LT AFT	81205	1	33-51-15 1678/289/L03	115-199
D00081	1	BACC66K31C1101 PLUG PLATE ASSY-	81205	1	34-22-14 E002-01/ /	001-099
D00081	1	BACC66K31C1101 PLUG PLATE ASSY-	81205	1	34-22-14 E2-1/ /	115-199
D00081A	1	PARTAOFD00081 PLUG-		0	34-22-14 E002-01/ /	001-099
D00081A	1	PARTAOFD00081 PLUG-		0	34-22-14 E2-1/ /	115-199
D00081B	1	PARTBOFD00081 PLUG-		0	34-22-14 E002-01/ /	001-099
D00081B	1	PARTBOFD00081 PLUG-		0	34-22-14 E2-1/ /	115-199
D00081C	1	PARTCOFD00081 PLUG-		0	34-22-14 E002-01/ /	001-099
D00081C	1	PARTCOFD00081 PLUG-		0	34-22-14 E2-1/ /	115-199
D00081D	1	PARTDOFD00081 PLUG-		0	34-22-14 E002-01/ /	001-099
D00081D	1	PARTDOFD00081 PLUG-		0	34-22-14 E2-1/ /	115-199
D00081E	9	PARTEOFD00081 PLUG		0	34-22-18 E002-01/ /	002
D00081E	1	PARTEOFD00081 PLUG-		0	34-22-14 E002-01/ /	001-099
D00081E	1	PARTEOFD00081 PLUG-		0	34-22-14 E2-1/ /	115-199
D00081F	1	PARTFOFD00081 PLUG-		0	34-22-14 E002-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D00000

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00081F	1	PARTFOFD00081 PLUG-		0	34-22-14 E2-1/ /	115-199
D00083	1	BACC66K31C1101 PLUG-	81205	1	34-22-24 E002-02/ /	001-099
D00083	1	BACC66K31C1101 PLUG-	81205	1	34-22-24 E2-2/ /	115-199
D00083A	1	PARTAOFD00083 PLUG-		0	34-22-28 E002-02/ /	001-099
D00083A	1	PARTAOFD00083 PLUG-		0	34-22-28 E2-2/ /	115-199
D00083B	1	PARTBOFD00083 PLUG-		0	34-22-28 E002-02/ /	001-099
D00083B	1	PARTBOFD00083 PLUG-		0	34-22-28 E2-2/ /	115-199
D00083C	1	PARTCOFD00083 PLUG-		0	34-22-26 E002-02/ /	001-099
D00083C	1	PARTCOFD00083 PLUG-		0	34-22-26 E2-2/ /	115-199
D00083D	1	PARTDOFD00083 PLUG-		0	34-22-28 E002-02/ /	001-099
D00083D	1	PARTDOFD00083 PLUG-		0	34-22-28 E2-2/ /	115-199
D00083E	1	PARTEOFD00083 PLUG-		0	34-22-24 E002-02/ /	001-099
D00083E	1	PARTEOFD00083 PLUG-		0	34-22-24 E2-2/ /	115-199
D00083F	1	PARTFOFD00083 PLUG-		0	34-22-26 E002-02/ /	001-099
D00083F	1	PARTFOFD00083 PLUG-		0	34-22-26 E2-2/ /	115-199
D00085	1	BACC66K31C1101 PLUG PLATE ASSY-	81205	1	34-22-34 E002-03/ /	001-099
D00085	1	BACC66K31C1101 PLUG PLATE ASSY-	81205	1	34-22-34 E2-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D00000

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00085A	1	PARTAOFD00085 PLUG-		0	34-22-34 E002-03/ /	001-099
D00085A	1	PARTAOFD00085 PLUG-		0	34-22-34 E2-3/ /	115-199
D00085B	1	PARTBOFD00085 PLUG-		0	34-22-34 E002-03/ /	001-099
D00085B	1	PARTBOFD00085 PLUG-		0	34-22-34 E2-3/ /	115-199
D00085C	1	PARTCOFD00085 PLUG-		0	34-22-34 E002-03/ /	001-099
D00085C	1	PARTCOFD00085 PLUG-		0	34-22-34 E2-3/ /	115-199
D00085D	1	PARTDOFD00085 PLUG-		0	34-22-34 E002-03/ /	001-099
D00085D	1	PARTDOFD00085 PLUG-		0	34-22-34 E2-3/ /	115-199
D00085E	1	PARTEOFD00085 PLUG-		0	34-22-34 E002-03/ /	001-099
D00085E	1	PARTEOFD00085 PLUG-		0	34-22-34 E2-3/ /	115-199
D00085F	1	PARTFOFD00085 PLUG-		0	34-22-34 E002-03/ /	001-099
D00085F	1	PARTFOFD00085 PLUG-		0	34-22-34 E2-3/ /	115-199
D00087	1	DPXBMB-67-33S-0001 PLUG ELEX ATTD DIR IND, CAPT	71468	1	34-22-14 P001-00/ /	ALL
D00087 U		287N1424-6 MOUNTING PLATE-	81205	1	23-11-11 */*/	ALL
D00087 V		233T2313-5 FILLER-	81205	1	34-22-14 */*/	ALL
D00089	1	DPXBMB-67-33S-0002 PLUG ELEX HORIZ SITUATION IND,CAPT	71468	1	34-22-15 P001-00/ /	ALL
D00089 U		287N1424-3 MOUNTING PLATE-	81205	1	34-22-15 */*/	ALL

EQUIPMENT LIST

D280N032

Section D00000

Page 11

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00089 V		233T2313-5 FILLER-	81205	1	34-22-15 */*/	ALL
D00091	1	DPXBMB-67-33S-0001 PLUG ELEX ATTD DIR IND, F/O	71468	1	34-22-24 P003-00/ /	001-099
D00091	1	DPXBMB-67-33S-0001 PLUG ELEX ATTD DIR IND,F/O	71468	1	34-22-24 P003-00/ /	115-199
D00091 U		287N1424-5 MOUNTING PLATE-	81205	1	34-22-14 */*/	ALL
D00091 V		233T2313-5 FILLER-	81205	1	34-22-24 */*/	ALL
D00093	1	DPXBMB-67-33S-0002 PLUG ELEX HORIZ SITUATION IND, F/O	71468	1	34-22-25 P003-00/ /	ALL
D00093 U		287N1424-2 MOUNTING PLATE-	81205	1	34-22-25 */*/	ALL
D00093 V		233T2313-5 FILLER-	81205	1	34-22-25 */*/	ALL
D00095	1	BACC45FT20D41S PLUG-EFIS CONTROL PANEL,CAPT	81205	1	34-22-14 P010-00/ /	ALL
D00097	1	BACC45FT20D41S PLUG-EFIS CONTROL PANEL,F/O	81205	1	34-22-24 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D00000
Page 12 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00105	1	M24308-2-32 RCPT-	96906	1	31-51-11 P051-00/ /	ALL
D00107	1	M24308-2-32 RCPT-	96906	1	31-51-12 P051-00/ /	ALL
D00109	1	BACC45FT12-12S PLUG-	81205	1	31-51-31 250/252/L50	001-099
D00109	1	BACC45FT12-12S PLUG-	81205	1	31-51-31 250/252/L050	115-199
D00109 T		BACC10GH12 CABLE CLAMP	81205	1	31-51-31 250/252/L50	001-099
D00109 T		BACC10GH12 CABLE CLAMP	81205	1	31-51-31 */ */ *	115-199
D00111	1	BACC45FT12-12S PLUG-	81205	1	31-51-32 250/252/R50	001-099
D00111	1	BACC45FT12-12S PLUG-	81205	1	31-51-32 250/252/R050	115-199
D00111 T		BACC10GH12 CABLE CLAMP	81205	1	31-51-32 250/252/R50	001-099
D00111 T		BACC10GH12 CABLE CLAMP	81205	1	31-51-32 P5/ /	115-199
D00113	1	BACC65L66 RCPT-	81205	1	31-51-21 P051-00/ /	ALL
D00115	1	BACC65L66 RCPT-	81205	1	31-51-32 P051-00/ /	ALL
D00117	1	BACC65L66 RCPT-	81205	1	31-51-41 P051-00/ /	ALL
D00119	1	BACC65L66 RCPT-	81205	1	34-16-11 P051-00/ /	ALL
D00121	1	BACC65L66 RCPT-	81205	1	27-32-11 P051-00/ /	ALL
D00123	1	BACC45FT16A24S PLUG-	81205	1	23-12-11 P008-00/ /	ALL
D00125	1	BACC66F11C04AB01 PLUG PLATE ASSY-	81205	1	23-12-11 E004-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D00100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00125	1	BACC66F11C04AB01 PLUG PLATE ASSY-	81205	1	23-12-11 E4-3/ /	115-199
D00125A	1	PARTAOFD00125 PLUG-		0	23-12-11 E004-03/ /	001-099
D00125A	1	PARTAOFD00125 PLUG-		0	23-12-11 E4-3/ /	115-199
D00125B	1	PARTBOFD00125 PLUG-		0	23-12-11 E004-03/ /	001-099
D00125B	1	PARTBOFD00125 PLUG-		0	23-12-11 E4-3/ /	115-199
D00125C	1	PARTCOFD00125 PLUG-		0	23-12-11 E004-03/ /	001-099
D00125C	1	PARTCOFD00125 PLUG-		0	23-12-11 E4-3/ /	115-199
D00127	1	BACC45FT16A24S PLUG-	81205	1	23-12-21 P008-00/ /	ALL
D00129	1	BACC66F11C04AB01 PLUG PLATE ASSY-	81205	1	23-12-21 E004-03/ /	001-099
D00129	1	BACC66F11C04AB01 PLUG PLATE ASSY-	81205	1	23-12-21 E4-3/ /	115-199
D00129A	1	PARTAOFD00129 PLUG-		0	23-12-21 E004-03/ /	001-099
D00129A	1	PARTAOFD00129 PLUG-		0	23-12-21 E4-3/ /	115-199
D00129B	1	PARTBOFD00129 PLUG-		0	23-12-21 E004-03/ /	001-099
D00129B	1	PARTBOFD00129 PLUG-		0	23-12-21 E4-3/ /	115-199
D00129C	1	PARTCOFD00129 PLUG-		0	23-12-21 E004-03/ /	001-099
D00129C	1	PARTCOFD00129 PLUG-		0	23-12-21 E4-3/ /	115-199
D00131	1	KD-59-187-M06 PLUG-	91836	1	23-12-11 753/305/L5	001-099

EQUIPMENT LIST

D280N032

Section D00100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00131	1	KD-59-110 PLUG-	91836	1	23-12-11 753/305/L5	115-199
D00133	1	KD-59-187-M06 PLUG-	91836	1	23-12-21 730/150/O	001-099
D00133	1	KD-59-110 PLUG-	91836	1	23-12-21 730/150/O	115-199
D00135	1	BACC66F11C0301 PLUG PLATE ASSY-	81205	1	23-21-11 E004-03/ /	001-099
D00135	1	BACC66F11C0301 PLUG PLATE ASSY-	81205	1	23-21-11 E4-3/ /	115-199
D00135A	1	PARTAOFD00135 PLUG-		0	23-21-11 E004-03/ /	001-099
D00135A	1	PARTAOFD00135 PLUG-		0	23-21-11 E4-3/ /	115-199
D00135B	1	PARTBOFD00135 PLUG-		0	23-21-11 E004-03/ /	001-099
D00135B	1	PARTBOFD00135 PLUG-		0	23-21-11 E4-3/ /	115-199
D00135C	1	PARTCOFD00135 PLUG-		0	23-21-11 E004-03/ /	001-099
D00135C	1	PARTCOFD00135 PLUG-		0	23-21-11 E4-3/ /	115-199
D00137	1	BACC66H21C0601 PLUG PLATE ASSEMBLY	81205	1	34-21-11 E002-04/ /	001-099
D00137	1	BACC66H21C0601 PLUG PLATE ASSEMBLY	81205	1	34-21-11 E2-4/ /	115-199
D00137A	1	PARTAOFD00137 PLUG		0	34-21-11 */ /	ALL
D00137B	1	PARTBOFD00137 PLUG		0	34-21-11 */ /	ALL
D00137C	1	PARTCOFD00137 PLUG		0	34-21-11 */ /	ALL
D00139	1	BACC66H21C0601 PLUG PLATE ASSEMBLY	81205	1	34-21-31 E002-04/ /	001-099

EQUIPMENT LIST

D280N032

Section D00100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00139	1	BACC66H21C0601 PLUG PLATE ASSEMBLY	81205	1	34-21-31 E2-4/ /	115-199
D00139A	1	PARTAOFD00139 PLUG		0	34-21-31 */ /	ALL
D00139B	1	PARTBOFD00139 PLUG		0	34-21-31 */ /	ALL
D00139C	1	PARTCOFD00139 PLUG		0	34-21-31 */ /	ALL
D00141	1	BACC66H21C0601 PLUG PLATE ASSEMBLY	81205	1	34-21-21 E002-04/ /	001-099
D00141	1	BACC66H21C0601 PLUG PLATE ASSEMBLY	81205	1	34-21-21 E2-4/ /	115-199
D00141A	1	PARTAOFD00141 PLUG		0	34-21-21 */ /	ALL
D00141B	1	PARTBOFD00141 PLUG		0	34-21-21 */ /	ALL
D00141C	1	PARTCOFD00141 PLUG		0	34-21-21 */ /	ALL
D00145	1	BACS16W1 RELAY SOCKET-	81205	1	34-21-21 P006-00/ /	ALL
D00147	1	BACC45FT18A31S PLUG-	81205	1	34-21-11 P005-00/ /	ALL
D00149	1	BACC45FT18A31S7 PLUG	81205	1	34-21-31 P005-00/ /	ALL
D00151	1	BACC45FT18A31S6 PLUG	81205	1	34-21-21 P005-00/ /	ALL
D00153	1	DCMA-37S-WS PLUG-	71468	1	27-32-12 P51/ /	001-099
D00153	1	DCMA-37S-WS PLUG-	71468	1	27-32-12 P051-00/ /	115-199
D00159	1	BACC66H24C1201 PLUG PLATE ASSY-	81205	1	34-43-11 215/170/R020	ALL
D00159 T	1	3602982-0501 WAVE GUIDE INSERT	02987	1	34-43-11 00000215/170/0R20	001-099

EQUIPMENT LIST

D280N032

Section D00100

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00159A	1	PARTAOFD00159 PLUG-		0	34-43-11 215/170/R020	ALL
D00159B	1	PARTBOFD00159 PLUG-		0	34-43-11 215/170/R020	ALL
D00159C	1	PARTCOFD00159 PLUG-		0	34-43-11 215/170/R020	ALL
D00159T	1	3602982-0501 WAVE GUIDE INSERT	02987	1	34-43-11 */*/	115-199
D00163	1	MS3126F18-32S PLUG-	71468	1	34-43-12 P008-00/ /	001-099
D00163	1	MS3126F18-32S PLUG-	71468	1	34-43-11 P008-00/ /	115-199
D00167	1	MS3475W22-55S PLUG	71468	1	34-43-12 196/200/L3	ALL
D00167 T	1	G4993-2212-1-5N BACKSHELL	MIL	1	34-43-12 196/200/L003	ALL
D00167 T	2	G9263AS2206KNF3 BACKSHELL	MIL	1	34-43-12 196/ /	ALL
D00169	1	KD-59-186-M06 PLUG-COAX	91836	1	23-12-31 1470/140/	001-099
D00171	9	BACC45FT20A41S PLUG-	81205	1	34-61-11 P009-00/ /	115-199
D00171	1	BACC45FT18A31S PLUG-	81205	1	34-61-11 P009-00/ /	001-099
D00173	1	BACC66H21C04 PLUG PLATE ASSY-	81205	1	34-61-11 E002-01/ /	001-099
D00173	1	BACC66H21C04 PLUG PLATE ASSY-	81205	1	34-61-11 E2-1/ /	115-199
D00173A	1	PARTAOFD00173 PLUG-		0	34-61-11 E002-01/ /	001-099
D00173A	1	PARTAOFD00173 PLUG-		0	34-61-11 E2-1/ /	115-199
D00173B	1	PARTBOFD00173 PLUG-		0	34-61-11 E002-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D00100

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00173B	1	PARTBOFD00173 PLUG-		0	34-61-11 E2-1/ /	115-199
D00173C	1	PARTCOFD00173 PLUG-		0	34-61-11 E002-01/ /	001-099
D00173C	1	PARTCOFD00173 PLUG-		0	34-61-11 E2-1/ /	115-199
D00175	9	BACC45FT20A41S PLUG- (34-0414)	81205	1	34-61-21 P009-00/ /	115-199
D00175	1	BACC45FT18A31S PLUG-	81205	1	34-61-21 P009-00/ /	001-099
D00177	1	BACC66H21C0401 PLUG	81205	1	34-61-23 E002-02/ /	001-099
D00177	1	BACC66H21C0401 PLUG	81205	1	34-61-23 E2-2/ /	115-199
D00177A	1	PARTAOFD00177 PLUG-		0	34-61-23 E002-02/ /	001-099
D00177A	1	PARTAOFD00177 PLUG-		0	34-61-23 E2-2/ /	115-199
D00177B	1	PARTBOFD00177 PLUG-		0	34-61-23 E002-02/ /	001-099
D00177B	1	PARTBOFD00177 PLUG-		0	34-61-23 E2-2/ /	115-199
D00177C	1	PARTCOFD00177 PLUG-		0	34-61-23 E002-02/ /	001-099
D00177C	1	PARTCOFD00177 PLUG-		0	34-61-23 E2-2/ /	115-199
D00183	1	BACC45FT22A55S6 PLUG	81205	1	34-22-81 P003-01/ /	001-099
D00185	1	BACC45FT22A55S6 PLUG	81205	1	34-22-91 P3-1/ /	001-099
D00187	1	BACC45FT18A31S PLUG	81205	1	34-22-82 P1-3/ /	001-099
D00187	1	BACC45FT18A31S PLUG	81205	1	34-22-82 P001-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D00100

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00188	1	BACC63BP18A8SN PLUG-	81205	1	33-42-21 P063-00/ /	ALL
D00188 T		BACC10HG18A CABLE CLAMP	81205	1	33-42-21 */*/	001-099
D00188 T		BACC10HG18A CABLE CLAMP	81205	1	33-42-21 P063-00/ /	115-199
D00189	1	BACC45FT18A31S PLUG	81205	1	34-22-92 P3-3/ /	ALL
D00190	1	BACC63BP18A8SN PLUG-	81205	1	33-42-21 P62/ /	ALL
D00190 T		BACC10HG18A CABLE CLAMP	81205	1	33-42-21 P62/ /	ALL
D00191	1	KD-59-125 PLUG	91836	1	34-31-11 199/173/L003	ALL
D00193	1	KD-59-126 ANGLE PLUG	91836	1	34-31-11 199/185/L003	ALL
D00195	1	KD-59-125 PLUG	91836	1	34-31-21 199/171/R003	ALL
D00197	1	KD-59-126 ANGLE PLUG	91836	1	34-31-21 199/165/R3	ALL
D00199	1	KD-59-125 PLUG	91836	1	34-31-31 132/ /	ALL

EQUIPMENT LIST

D280N032

Section D00100

Page 7 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00201	1	KD-59-126 ANGLE PLUG	91836	1	34-31-31 199/170/L003	ALL
D00203	1	BACC66F11C51AB01 PLUG PLATE ASSY-	81205	1	34-31-11 E002-03/ /	001-099
D00203A	1	PARTAOFD00203 PLUG-		0	34-31-11 E002-03/ /	001-099
D00203B	1	PARTBOFD00203 PLUG-		0	34-31-11 E002-03/ /	001-099
D00203C	1	PARTCOFD00203 PLUG-		0	34-31-11 E002-03/ /	001-099
D00205	1	BACC66F11C51AB01 PLUG-	81205	1	34-31-21 E002-02/ /	001-099
D00205A	1	PARTAOFD00205 PLUG-		0	34-31-21 E002-02/ /	001-099
D00205B	1	PARTBOFD00205 PLUG-		0	34-22-29 E002-02/ /	001-099
D00205C	1	PARTCOFD00205 PLUG-		0	34-31-21 E002-02/ /	001-099
D00207	1	BACC66F11C51AB01 PLUG PLATE ASSY-	81205	1	34-31-31 E002-03/ /	001-099
D00207A	1	PARTAOFD00207 PLUG-		0	34-31-31 E002-03/ /	001-099
D00207B	1	PARTBOFD00207 PLUG-		0	34-31-31 E002-03/ /	001-099
D00207C	1	PARTCOFD00207 PLUG-		0	34-31-31 E002-03/ /	001-099
D00209	1	KD-59-186-M06 PLUG-	91836	1	34-32-11 650/148/0000	ALL
D00211	1	BACC66H123C01AD01 PLUG PLATE ASSY-	81205	1	34-33-11 E5-1/ /	ALL
D00211 T		BACC47EN1 COAXIAL CONTACT	81205	1	34-33-11 E5-1/ /	ALL
D00211 U		BACC47EN1 COAXIAL CONTACT	81205	1	34-33-11 E5-1/ /	ALL

EQUIPMENT LIST

D280N032

Section D00200

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00211A	1	PARTAOFD00211 PLUG		0	34-33-11 E5-1/ /	ALL
D00211B	1	PARTBOFD00211 PLUG		0	34-33-11 E5-1/ /	ALL
D00211C	1	PARTCOFD00211 PLUG		0	34-33-11 E5-1/ /	ALL
D00213	1	KA-59-186 PLUG	91836	1	34-33-11 570/148/L12	ALL
D00215	1	KA-59-186 PLUG	91836	1	34-33-11 610/148/L12	ALL
D00217	1	BACC66H123C01AD01 PLUG PLATE ASSY-	81205	1	34-33-21 E5-2/ /	001-099
D00217	1	BACC66H123C01AD01 PLUG PLATE ASSY-	81205	1	34-33-21 AE0502/ /	115-199
D00217 T		BACC47EN1 COAXIAL CONTACT	81205	1	34-33-21 E005-02/ /	ALL
D00217 U		BACC47EN1 COAXIAL CONTACT	81205	1	34-33-21 E5-2/ /	ALL
D00217A	1	PARTAOFD00217 PLUG		0	34-33-21 E5-2/ /	ALL
D00217B	1	PARTBOFD00217 PLUG		0	34-33-21 E5-2/ /	ALL
D00217C	1	PARTCOFD00217 PLUG		0	34-33-21 E5-2/ /	ALL
D00219	1	KA-59-186 PLUG	91836	1	34-33-21 570/148/R012	ALL
D00221	1	KA-59-186 PLUG	91836	1	34-33-21 610/148/R12	ALL
D00223	1	BACC66H123C01AD01 PLUG PLATE ASSY-	81205	1	34-33-31 E005-03/ /	001-099
D00223	1	BACC66H123C01AD01 PLUG PLATE ASSY-	81205	1	34-33-31 E5-3/ /	115-199
D00223 T		BACC47EN1 COAXIAL CONTACT	81205	1	34-33-31 E5-3/ /	ALL

EQUIPMENT LIST

D280N032

Section D00200

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00223 U		BACC47EN1 COAXIAL CONTACT	81205	1	34-33-31 E005-03/ /	ALL
D00223A	1	PARTAOFD00223 PLUG-		0	34-33-31 E005-03/ /	001-099
D00223A	1	PARTAOFD00223 PLUG-		0	34-33-31 E5-3/ /	115-199
D00223B	1	PARTBOFD00223 PLUG-		0	34-33-31 E005-03/ /	001-099
D00223B	1	PARTBOFD00223 PLUG-		0	34-33-31 E5-3/ /	115-199
D00223C	1	PARTCOFD00223 PLUG-		0	34-33-31 E005-03/ /	001-099
D00223C	1	PARTCOFD00223 PLUG-		0	34-33-31 E5-3/ /	115-199
D00225	1	KA-59-186 PLUG	91836	1	34-33-31 570/148/	ALL
D00227	1	KA-59-186 PLUG	91836	1	34-33-31 610/148/	ALL
D00231	1	BACC66F11C02AB01 PLUG PLATE ASSY-	81205	1	34-51-11 E003-02/ /	001-099
D00231	1	BACC66F11C0201 PLUG PLATE ASSY-	81205	1	34-51-11 E6-1/ /	115-199
D00231A	1	PARTAOFD00231 PLUG-		0	34-51-11 E003-02/ /	001-099
D00231A	1	PARTAOFD00231 PLUG-		0	34-51-11 E6-1/ /	115-199
D00231B	1	PARTBOFD00231 PLUG-		0	34-51-11 E003-02/ /	001-099
D00231B	1	PARTBOFD00231 PLUG-		0	34-51-11 E6-1/ /	115-199
D00231C	1	PARTCOFD00231 PLUG-		0	34-51-11 E003-02/ /	001-099
D00231C	1	PARTBOFD00231 PLUG-		0	34-51-11 E6-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D00200

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00235	1	BACC66F11C0201 PLUG PLATE ASSY-	81205	1	34-51-21 E003-02/ /	001-099
D00235	1	BACC66F11C0201 PLUG PLATE ASSY-	81205	1	34-51-21 E6-1/ /	115-199
D00235A	1	PARTAOFD00235 PLUG-		1	34-51-21 E003-02/ /	001-099
D00235A	1	PARTAOFD00235 PLUG-		0	34-51-21 E6-1/ /	115-199
D00235B	1	PARTBOFD00235 PLUG-		1	34-51-21 E003-02/ /	001-099
D00235B	1	PARTBOFD00235 PLUG-		0	34-51-21 E6-1/ /	115-199
D00235C	1	PARTCOFD00235 PLUG-		1	34-51-21 E003-02/ /	001-099
D00235C	1	PARTCOFD00235 PLUG-		0	34-51-21 E6-1/ /	115-199
D00237	1	KD-59-180-M06 PLUG	91836	1	34-55-11 630/150/	ALL
D00239	1	BACC66H125C03AD01 PLUG PLATE ASSY-	81205	1	34-55-11 E3-3/ /	ALL
D00239A	1	PARTAOFD00239 PLUG-	81205	0	34-55-11 E3-3/ /	ALL
D00239B	1	PARTBOFD00239 PLUG-	81205	0	34-55-11 E3-3/ /	ALL
D00239C	1	PARTCOFD00239 PLUG-	81205	0	34-55-11 E3-3/ /	ALL
D00241	1	KD-59-180-M06 PLUG	91836	1	34-55-21 690/148/L12	ALL
D00243	1	BACC66H125C03AD01 PLUG PLATE ASSY-	81205	1	34-55-21 E003-02/ /	001-099
D00243	1	BACC66H125C03AD01 PLUG PLATE ASSY-	81205	1	34-55-21 E3-2/ /	115-199
D00243A	1	PARTAOFD00243 PLUG-		0	34-55-21 E003-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D00200

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00243A	1	PARTAOFD00243 PLUG-		0	34-55-21 E3-2/ /	115-199
D00243B	1	PARTBOFD00243 PLUG-		0	34-55-21 E003-02/ /	001-099
D00243B	1	PARTBOFD00243 PLUG-		0	34-55-21 E3-2/ /	115-199
D00243C	1	PARTCOFD00243 PLUG-		0	34-55-21 E003-02/ /	001-099
D00243C	1	PARTCOFD00243 PLUG-		0	34-55-21 E3-2/ /	115-199
D00245	1	BACC66F11C0501 PLUG PLATE ASSY-	81205	1	34-57-11 E006-01/ /	001-099
D00245	1	BACC66F11C0501 PLUG PLATE ASSY-	81205	1	34-57-11 E6-1/ /	115-199
D00245A	1	PARTAOFD00245 PLUG-		0	34-57-11 E006-01/ /	001-099
D00245A	1	PARTAOFD00245 PLUG-		0	34-57-11 E6-1/ /	115-199
D00245B	1	PARTBOFD00245 PLUG-		0	34-57-11 E006-01/ /	001-099
D00245B	1	PARTBOFD00245 PLUG-		0	34-57-11 E6-1/ /	115-199
D00245C	1	PARTOFD00245 PLUG-		0	34-57-11 E006-01/ /	001-099
D00245C	1	PARTCOFD00245 PLUG-		0	34-57-11 E6-1/ /	115-199
D00249	1	KD-59-193-M06 PLUG-	91836	1	34-53-21 535/148/R015	ALL
D00251	1	BACC66H123C05AD01 PLUG PLATE ASSY-	81205	1	34-53-11 E3-3/ /	ALL
D00251A	1	PARTAOFD00251 PLUG-		0	34-53-11 E3-3/ /	ALL
D00251B	1	PARTBOFD00251 PLUG-		0	34-53-11 E3-3/ /	ALL

EQUIPMENT LIST

D280N032

Section D00200

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00251C	1	PARTCOFD00251 PLUG-		0	34-53-11 E3-3/ /	ALL
D00253	1	BACC66H123C05AD01 PLUG PLATE ASSY-	81205	1	34-53-21 E003-02/ /	001-099
D00253	1	BACC66H123C05AD01 PLUG PLATE ASSY-	81205	1	34-53-21 E3-2/ /	115-199
D00253A	1	PARTAOFD00253 PLUG-		0	34-53-21 E003-02/ /	001-099
D00253A	1	PARTAOFD00253 PLUG-		0	34-53-21 E3-2/ /	115-199
D00253B	1	PARTBOFD00253 PLUG-		0	34-53-21 E003-02/ /	001-099
D00253B	1	PARTBOFD00253 PLUG-		0	34-53-21 E3-2/ /	115-199
D00253C	1	PARTCOFD00253 PLUG-		0	34-53-21 E003-02/ /	001-099
D00253C	1	PARTCOFD00253 PLUG-		0	34-53-21 E3-2/ /	115-199
D00255	1	BACC45FT16A24S7 PLUG-	81205	1	34-53-11 P008-00/ /	001-099
D00255	1	BACC45FT16A24S7 PLUG-	81205	1	34-53-11 P8/ /	115-199
D00257	1	BACC45FT16A24S8 PLUG-	81205	1	34-53-21 P008-00/ /	001-099
D00257	1	BACC45FT16A24S8 PLUG-	81205	1	34-53-21 P8/ /	115-199
D00259	1	BACC45FT18-31S PLUG-	81205	1	34-51-12 P055-00/ /	ALL
D00261	1	BACC45FT18A31S PLUG-	81205	1	34-51-21 P055-00/ /	ALL
D00263	1	BACC45FT12-12S PLUG-	81205	1	34-55-11 P055-00/ /	ALL
D00263 T		BACC10GH12 CABLE CLAMP	81205	1	34-55-11 */ /	ALL

EQUIPMENT LIST

D280N032

Section D00200

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00265	1	BACC45FT12A12S PLUG-	81205	1	34-55-21 P055-00/ /	ALL
D00267	1	C0909A20N16SN-995 PLUG	81205	1	34-57-11 1116/300/L5	ALL
D00269	1	BACC45FT14A15S6 PLUG	81205	1	34-31-11 P008-00/ /	ALL
D00271	1	BACC45FT14A15S7 PLUG	81205	1	34-31-31 P008-00/ /	ALL
D00273	1	BACC45FT14A15S8 PLUG	81205	1	34-31-21 P008-00/ /	ALL
D00275	1	BACC45FT16A24S PLUG	81205	1	34-24-11 P1-3/ /	001-099
D00275	1	BACC45FT16A24S PLUG	81205	1	34-24-11 P001-3/ /	115-199
D00277	1	BACC45FT18A31S PLUG	81205	1	34-13-11 P1-1/ /	001-099
D00277	1	BACC45FT18A31S PLUG	81205	1	34-13-11 P001-1/ /	115-199
D00279	1	BACC45FT20A41S PLUG	81205	1	34-13-11 P1-3/ /	001-099
D00279	1	BACC45FT20A41S PLUG	81205	1	34-13-21 P001-3/ /	115-199
D00281	1	BACC45FT10D5S6 PLUG	81205	1	34-13-11 P1-3/ /	001-099
D00281	1	BACC45FT16B24S7 PLUG	81205	1	34-13-11 P001-3/ /	115-199
D00283	1	BACC45FT10-5S PLUG	81205	1	34-13-11 P1-3/ /	001-099
D00283	1	BACC45FT10-5S PLUG	81205	1	34-13-11 P001-3/ /	115-199
D00283 T		BACC10GH10 CABLE CLAMP	81205	1	34-13-11 */ */*	ALL
D00285	1	BACC45FT18A31S PLUG	81205	1	34-13-21 P3-1/ /	ALL

EQUIPMENT LIST

D280N032

Section D00200

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00287	1	BACC45FT20A41S PLUG	81205	1	34-13-21 P3-3/ /	ALL
D00289	1	BACC66H21C0201 PLUG PLATE ASSY-	81205	1	34-12-11 E002-01/ /	001-099
D00289	1	BACC66H21C0201 PLUG PLATE ASSY-	81205	1	34-12-11 E2-1/ /	115-199
D00289A	1	PARTAOFD00289 PLUG-		0	34-12-11 E002-01/ /	001-099
D00289A	1	PARTAOFD00289 PLUG-		0	34-12-11 E2-1/ /	115-199
D00289B	1	PARTBOFD00289 PLUG-		0	34-12-11 E002-01/ /	001-099
D00289B	1	PARTBOFD00289 PLUG-		0	34-12-11 E2-1/ /	115-199
D00289C	1	PARTCOFD00289 PLUG-		0	34-12-11 E002-01/ /	001-099
D00289C	1	PARTCOFD00289 PLUG-		0	34-12-11 E2-1/ /	115-199
D00291	1	BACC66H21C0201 PLUG-	81205	1	34-12-22 E002-02/ /	001-099
D00291	1	BACC66H21C0201 PLUG-	81205	1	34-12-22 E2-2/ /	115-199
D00291A	1	PARTAOFD00291 PLUG-		0	34-12-22 E002-02/ /	001-099
D00291A	1	PARTAOFD00291 PLUG-		0	34-12-22 E2-2/ /	115-199
D00291B	1	PARTBOFD00291 PLUG-		0	34-12-22 E002-02/ /	001-099
D00291B	1	PARTBOFD00291 PLUG-		0	34-12-22 E2-2/ /	115-199
D00291C	1	PARTCOFD00291 PLUG-		0	34-12-22 E002-02/ /	001-099
D00291C	1	PARTCOFD00291 PLUG-		0	34-12-22 E2-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D00200

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00293	1	BACC45FT12D12S PLUG	81205	1	34-12-21 228/197/R047	ALL
D00295	1	BACC45FT12D12S PLUG	81205	1	34-12-11 228/197/L047	ALL
D00299	1	BACC66H125C10AD01 PLUG PLATE ASSY	81205	1	23-11-11 E004-03/ /	001-099
D00299	1	BACC66H25C10AD01 PLUG PLATE ASSY-	81205	1	23-11-11 E6-3/ /	115-199
D00299A	1	PARTAOFD00299 PLUG		1	23-11-11 E004-03/ /	001-099
D00299A	1	PARTAOFD00299 PLUG-		0	23-11-11 E6-3/ /	115-199
D00299B	1	PARTBOFD00299 PLUG		1	23-11-11 E004-03/ /	001-099
D00299B	1	PARTBOFD00299 PLUG-		0	23-11-11 E6-3/ /	115-199
D00299C	1	PARTCOFD00299 PLUG		1	23-11-11 E004-03/ /	001-099
D00299C	1	PARTCOFD00299 PLUG-		0	23-11-11 E6-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D00200
Page 9 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00301	1	BACC66H125C10AD01 PLUG PLATE ASSY-	81205	1	23-11-21 E003-02/ /	001-099
D00301	1	BACC66H25C10AD01 PLUG PLATE ASSY	81205	1	23-11-21 E6-3/ /	115-199
D00301A	1	PARTAOFD00301 PLUG-		1	23-11-21 E003-02/ /	001-099
D00301A	1	PARTAOFD00301 PLUG		1	23-11-21 E6-3/ /	115-199
D00301B	1	PARTBOFD00301 PLUG-		1	23-11-21 E003-02/ /	001-099
D00301B	1	PARTBOFD00301 PLUG		1	23-11-21 E6-3/ /	115-199
D00301C	1	PARTCOFD00301 PLUG-		1	23-11-21 E003-02/ /	001-099
D00301C	1	PARTCOFD00301 PLUG		1	23-11-21 E6-3/ /	115-199
D00307	1	MS3126F16-26S PLUG-	09922	1	23-11-11 FSS225/ /	ALL
D00309	1	MS3126F16-26S PLUG-	09922	1	23-11-21 FSS280/ /	ALL
D00311	1	BACC45FT14D15S9 PLUG-	81205	1	23-11-11 P005-00/ /	001-099
D00311	1	BACC45FT14D15S9 PLUG-	81205	1	23-11-11 P5/ /	115-199
D00313	1	BACC45FT14A15S9 PLUG-	81205	1	23-11-21 P005-00/ /	001-099
D00313	1	BACC45FT14A15S9 PLUG-	81205	1	23-11-21 P5/ /	115-199
D00315	1	KN-59-330-M06 PLUG-	91836	1	23-11-11 FIN225/FS/	001-008, 115-199
D00315	1	KN-59-220 PLUG-	91836	1	23-11-11 FIN225/FS/	009-099
D00317	1	KN-59-330-M06 PLUG-	91836	1	23-11-21 FSS280/ /	001-008, 115-199

EQUIPMENT LIST

D280N032

Section D00300

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00317	1	KN-59-220 PLUG-	91836	1	23-11-21 FSS280/ /	009-099
D00319	1	BACC66K33C5601 PLUG PLATE ASSY-	81205	1	31-41-11 E4-2/ /	ALL
D00319A	1	PARTAOFD00319 PLUG-		0	31-41-11 E4-2/ /	ALL
D00319B	1	PARTBOFD00319 PLUG-		0	31-41-11 E4-2/ /	ALL
D00319C	1	PARTCOFD00319 PLUG-		0	31-41-11 E4-2/ /	ALL
D00319D	1	PARTDOFD00319 PLUG-		0	31-41-11 E4-2/ /	ALL
D00319E	1	PARTEOFD00319 PLUG-		0	31-41-11 E4-2/ /	ALL
D00319F	1	PARTFOFD00319 PLUG-		0	31-41-11 E4-2/ /	ALL
D00321	1	BACC66K33C5601 PLUG PLATE ASSY	81205	1	31-41-21 E4-2/ /	ALL
D00321A	1	PARTAOFD00321 PLUG-		0	31-41-21 E4-2/ /	ALL
D00321B	1	PARTBOFD00321 PLUG-		0	31-41-21 E4-2/ /	ALL
D00321C	1	PARTCOFD00321 PLUG-		0	31-41-21 E4-2/ /	ALL
D00321D	1	PARTDOFD00321 PLUG-		0	31-41-21 E4-2/ /	ALL
D00321E	1	PARTEOFD00321 PLUG-		0	31-41-21 E4-2/ /	ALL
D00321F	1	PARTFOFD00321 PLUG-		0	31-41-21 E4-2/ /	ALL
D00325	1	DPXBMB-67-33S-0002 PLUG-EICAS UPPER DISPLAY IND	71468	1	31-41-11 P001-00/ /	001-099
D00325	1	DPXBMB-67-33S-0002 RCPT-EICAS UPPER DISPLAY IND	71468	1	31-41-11 P001-00/ /	115-199

EQUIPMENT LIST

D280N032

Section D00300

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00325 U		287N1424-4 MOUNTING PLATE-	81205	1	31-41-11 */*/	ALL
D00325 V		233T2313-5 FILLER-	81205	1	31-41-11 */*/	ALL
D00327	1	DPXBMB-67-33S-0002 RCPT-EICAS LOWER DISPLAY IND	71468	1	31-41-11 P001-00/ /	ALL
D00327 U		287N1424-1 MOUNTING PLATE-	81205	1	31-41-21 P001-01/ /	ALL
D00327 V		233T2313-5 FILLER-	81205	1	31-41-21 P001-00/ /	ALL
D00331	1	BACC45FT20D41S6 PLUG-EICAS PILOTS DSPL SEL PNL	81205	1	31-41-14 P9/ /	ALL
D00333	1	BACC45FT22A55S PLUG-	81205	1	23-21-11 P005-00/ /	001-099
D00333	1	BACC45FT22A55S PLUG-	81205	1	23-42-11 P5/ /	115-199
D00337	1	BACC45FT20A41S PLUG-	81205	1	23-51-11 P008-00/ /	ALL
D00339	1	BACC45FT18A31S PLUG-	81205	1	23-51-11 P8/ /	ALL
D00340	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 404/288/L38	001-099
D00342	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 464/288/L38	001-099
D00342	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 463/288/L038	115-199
D00344	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 524/288/L38	001-099
D00344	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 523/288/L037	115-199
D00345	1	BACC63BP16A10SNL PLUG-	81205	1	22-21-11 FIN135/RS/	ALL
D00345 T		BACC10HG16 CABLE CLAMP	81205	1	22-21-11 FIN135/RS/	ALL

EQUIPMENT LIST

D280N032

Section D00300

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00346	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 584/288/L38	001-099
D00346	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 583/288/L038	115-199
D00347	1	BACC63BP16A10SNL PLUG-	81205	1	22-21-21 FIN135/RS/	ALL
D00347 T		BACC10HF16 CABLE CLAMP	81205	1	22-21-21 FIN135/RS/	ALL
D00348	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 643/288/L037	115-199
D00349	1	BACC66H21C1101 PLUG PLATE ASSY-	81205	1	22-21-11 E003-01/ /	ALL
D00349A	1	PARTAOFD00349 PLUG-		0	22-21-11 E003-01/ /	ALL
D00349B	1	PARTBOFD00349 PLUG-		0	22-21-11 E003-01/ /	ALL
D00349C	1	PARTCOFD00349 PLUG-		0	22-21-11 E003-01/ /	ALL
D00350	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 704/288/L38	001-099
D00350	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 704/288/L038	115-199
D00351	1	BACC66H21C1101 PLUG PLATE ASSY-	81205	1	22-21-21 E004-01/ /	001-099
D00351	1	BACC66H21C1101 PLUG PLATE ASSY-	81205	1	22-21-21 E4-1/ /	115-199
D00351A	1	PARTAOFD00351 PLUG-		0	22-21-21 E004-01/ /	001-099
D00351A	1	PARTAOFD00351 PLUG-		0	22-21-21 E4-1/ /	115-199
D00351B	1	PARTBOFD00351 PLUG-		0	22-21-21 E004-01/ /	001-099
D00351B	1	PARTBOFD00351 PLUG-		0	22-21-21 E4-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D00300

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00351C	1	PARTCOFD00351 PLUG-		0	22-21-21 E004-01/ /	001-099
D00351C	1	PARTCOFD00351 PLUG-		0	22-21-21 E4-1/ /	115-199
D00354	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 764/288/L38	001-099
D00354	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 764/288/L038	115-199
D00356	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 824/288/L38	001-099
D00356	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 824/288/L038	115-199
D00358	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 884/288/L037	ALL
D00360	1	BACC45FT12-12S PLUG-	81205	1	33-21-13 944/288/L38	ALL
D00362	1	BACC45FT12-12S PLUG-	81205	1	33-21-13 1004/288/L38	ALL
D00364	1	BACC45FT12-12S PLUG-	81205	1	33-21-13 1064/288/L38	ALL
D00366	1	BACC45FT12-12S PLUG-	81205	1	33-21-13 1124/288/L38	001-099
D00366	1	BACC45FT12-12S PLUG-	81205	1	33-21-13 1124/288/L37	115-199
D00368	1	BACC45FT12-12S PLUG-	81205	1	33-21-13 1184/288/L38	ALL
D00374	1	BACC45FT12-12S PLUG-	81205	1	33-21-14 1344/288/L38	ALL
D00376	1	BACC45FT12-12S PLUG-	81205	1	33-21-14 1404/288/L38	001-099
D00376	1	BACC45FT12-12S PLUG-	81205	1	33-21-14 1404/288/L37	115-199
D00378	1	BACC45FT12-12S PLUG-	81205	1	33-21-14 1464/288/L38	001-099

EQUIPMENT LIST

D280N032

Section D00300

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00378	1	BACC45FT12-12S PLUG-	81205	1	33-21-14 1464/288/L37	115-199
D00380	1	BACC45FT12-12S PLUG-	81205	1	33-21-14 1524/288/L38	ALL
D00381	1	BACC63BP14A7SNL PLUG-	81205	1	27-21-12 FIN117/RS/	ALL
D00381 T		BACC10HF14 CABLE CLAMP	81205	1	27-21-12 FIN117/RS/	ALL
D00382	1	BACC45FT12-12S PLUG-	81205	1	33-21-14 1584/288/L38	ALL
D00383	1	BACC66H21C2401 PLUG PLATE ASSY-	81205	1	22-32-11 E2-3/ /	ALL
D00383A	1	PARTAOFD00383 PLUG-		0	22-32-11 E002-03/ /	001-099
D00383A	1	PARTAOFD00383 PLUG-		0	22-32-11 E2-3/ /	115-199
D00383B	1	PARTBOFD00383 PLUG-		0	22-32-11 E002-03/ /	001-099
D00383B	1	PARTBOFD00383 PLUG-		0	22-32-11 E2-3/ /	115-199
D00383C	1	PARTCOFD00383 PLUG-		0	22-32-11 E002-03/ /	001-099
D00383C	1	PARTCOFD00383 PLUG-		0	22-32-11 E2-3/ /	115-199
D00397	1	BACC45FT18A31S PLUG	81205	1	22-31-12 P3-1/ /	ALL
D00399	1	MS3126F16-26S PLUG-	71468	1	22-31-11 218/198/R08	ALL

EQUIPMENT LIST

D280N032

Section D00300

Page 6 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00401	1	BACC45FT12-12S PLUG	81205	1	22-14-11 P001-01/ /	001-099
D00401	1	BACC45FT12B12S PLUG	81205	1	22-14-11 P001-3/ /	115-199
D00401 T		BACC10GH12 CABLE CLAMP	81205	1	22-14-11 */ */	ALL
D00403	1	BACC45FT12-12S PLUG	81205	1	22-14-21 P3-1/ /	ALL
D00403 T		BACC10GH12 CABLE CLAMP	81205	1	22-14-21 */ */	001-099
D00403 T		BACC10GH12 CABLE CLAMP	81205	1	22-14-21 P3-1/ /	115-199
D00413	1	2J-1865A JACK-	82389	1	23-41-11 1885/210/L005	ALL
D00415	1	2J-1865A JACK-	82389	1	23-41-11 E006-01/ /	001-099
D00415	1	2J-1865A JACK	82389	1	23-41-11 E6/ /	115-199
D00417	1	2J-1865A JACK-	82389	1	23-41-11 0SS503/ /	ALL
D00423	1	2J-1865A JACK-	82389	1	23-41-12 470/160/R027	001-099
D00423	1	2J-1865A JACK-	82389	1	23-41-11 470/160/R27	115-199
D00425	1	2J-1865A JACK -	82389	1	23-41-11 P62/ /	ALL
D00427	1	2J-1865A JACK-SERVICE INTERPHONE	82389	1	23-41-11 P72/ /	ALL
D00429	1	2J-1865A JACK	82389	1	23-41-11 1760/182/L018	001-099
D00429	1	2J-1865A JACK,INTERPHONE	82389	1	23-41-11 1760/182/L018	115-199
D00433	1	BACC66F11C0801 PLUG PLATE ASSY-	81205	1	34-46-11 E002-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D00400

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00433	1	BACC66F11C0801 PLUG PLATE ASSY-	81205	1	34-46-11 E2-3/ /	115-199
D00433A	1	PARTAOFD00433 PLUG-		0	34-46-11 E002-03/ /	001-099
D00433A	1	PARTAOFD00433 PLUG-		0	34-46-11 E2-3/ /	115-199
D00433B	1	PARTBOFD00433 PLUG-		0	34-46-11 E002-03/ /	001-099
D00433B	1	PARTBOFD00433 PLUG-		0	34-46-11 E2-3/ /	115-199
D00433C	1	PARTCOFD00433 PLUG-		0	34-46-11 E002-03/ /	001-099
D00433C	1	PARTCOFD00433 PLUG-		0	34-46-11 E2-3/ /	115-199
D00435	1	2J-1865A JACK -	82389	1	23-51-11 P62/ /	ALL
D00441	1	BACC45FT16A24S9 PLUG-	81205	1	34-57-21 P8/ /	001-009
D00443	1	BACC66F11C0501 PLUG PLATE ASSY	81205	1	34-57-21 E006-01/ /	001-099
D00443	1	BACC66F11C0501 PLUG PLATE ASSY-	81205	1	34-57-21 E6-1/ /	115-199
D00443A	1	PARTAOFD00443 PLUG		0	34-57-21 E006-01/ /	001-099
D00443A	1	PARTAOFD00443 PLUG-		0	34-57-21 E6-1/ /	115-199
D00443B	1	PARTBOFD00443 PLUG		0	34-57-21 E006-01/ /	001-099
D00443B	1	PARTBOFD00443 PLUG-		0	34-57-21 E6-1/ /	115-199
D00443C	1	PARTCOFD00443 PLUG		0	34-57-21 E006-01/ /	001-099
D00443C	1	PARTCOFD00443 PLUG-		0	34-57-21 E6-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D00400

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00445	1	C0909A20N16SN-995 PLUG	13556	1	34-57-21 1150/300/L5	ALL
D00447	1	BACC66H21C1401 PLUG PLATE ASSY-	81205	1	34-24-11 E002-03/ /	001-099
D00447	1	BACC66H21C1401 PLUG PLATE ASSY-	81205	1	34-24-11 E2-3/ /	115-199
D00447A	1	PARTAOFD00447 PLUG-		0	34-24-11 E002-03/ /	001-099
D00447A	1	PARTAOFD00447 PLUG-		0	34-24-11 E2-3/ /	115-199
D00447B	1	PARTBOFD00447 PLUG-		0	34-24-11 E002-03/ /	001-099
D00447B	1	PARTBOFD00447 PLUG-		0	34-24-11 E2-3/ /	115-199
D00447C	1	PARTCOFD00447 PLUG-		0	34-24-11 E002-03/ /	001-099
D00447C	1	PARTCOFD00447 PLUG-		0	34-24-11 E2-3/ /	115-199
D00449	1	BACC45FT20A41S PLUG-	81025	1	23-51-21 P008-00/ /	ALL
D00451	1	BACC45FT18A31S PLUG-	81205	1	23-51-21 P8/ /	ALL
D00453	1	BACC45FT20A41S PLUG-	81205	1	23-51-51 P061/ /	115-199
D00455	1	BACC45FT18D31S PLUG-	81205	1	23-51-51 P61/ /	115-199
D00457	1	BACC45FT20A41S PLUG-	81205	1	23-51-41 P17/ /	ALL
D00459	1	BACC45FT18A31S PLUG-	81205	1	23-51-41 P17/ /	ALL
D00461	1	BACC63BP12A3SNL PLUG-	81205	1	27-21-22 FIN117/RS/	ALL
D00461 T		BACC10HF12 CABLE CLAMP	81205	1	27-21-22 FIN117/RS/	ALL

EQUIPMENT LIST

D280N032

Section D00400

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00463	1	BACC45FT16A24S PLUG	81205	1	31-25-11 AP0001/ /	001-099
D00463	1	BACC45FT16A24S PLUG	81205	1	31-25-11 P001-1/ /	115-199
D00465	1	BACC45FT16A24S PLUG	81205	1	31-25-11 P3-3/ /	001-099
D00465	1	BACC45FT16A24S PLUG	81205	1	31-25-11 P3-1/ /	115-199
D00467	1	BACC45FT12D12S6 PLUG	81205	1	34-12-21 228/197/R047	ALL
D00469	1	BACC45FT12D12S6 PLUG	81205	1	34-12-11 228/197/L047	ALL
D00471	1	BACC45FT12-12S6 PLUG-	81205	1	23-41-11 P061-00/ /	001-099
D00471	1	BACC45FT12-12S6 PLUG-	81205	1	23-41-11 P61/ /	115-199
D00473	1	CN0966A22G55PN-000 FEED THROUGH DISCONNECT	81205	1	34-43-11 199/193/L9	ALL
D00473 T	1	G4993-2212-1-5N BACKSHELL	MIL	1	34-43-12 199/200/L003	ALL
D00473 T	2	G9263AS2206KNF3 BACKSHELL	MIL	1	34-43-12 199/ /	ALL
D00477	1	CN0967C22G55SN-000 RECP-	81205	1	34-43-11 199/180/L012	ALL
D00479	1	2J-1865A RECPT	82839	1	23-71-11 P62/ /	115-199
D00481	1	MS3120F10-6S RCPT-	81205	1	23-34-12 426/215/R068	001-003, 005, 007-099
D00481	1	MS3120F10-6S RCPT-	81205	1	23-34-12 455/215/R068	004, 006
D00481	1	MS3120F10-6S RCPT-	81205	1	23-34-12 401/215/R068	115-199
D00483	1	MS3120F10-6S RCPT-	81205	1	23-34-12 426/216/L063	001-099

EQUIPMENT LIST

D280N032

Section D00400

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00483	1	MS3120F10-6S RCPT-	81205	1	23-34-12 446/216/L063	115-199
D00485	1	BACC45FT14A15S PLUG	81205	1	22-14-11 P001-01/ /	001-099
D00485	1	BACC45FT14A15S PLUG	81205	1	22-14-11 P001-3/ /	115-199
D00487	1	BACC45FT14A15S PLUG	81205	1	22-14-21 P3-1/ /	ALL
D00489	1	PT06CE-8-2S-SR- RCPT-		1	27-32-21 235/198/R20	001-002, 115-199
D00489	1	PT06E-8-2S-SR- RCPT-		1	27-32-21 235/198/R20	003-099
D00489	2	PT06E-8-2S-SR- RCPT-		1	27-32-21 235/198/R20	001-002, 115-199
D00491	1	XLR-4-31 RCPT-	71468	1	23-51-15 P8/ /	115-199

EQUIPMENT LIST

D280N032

Section D00400

Page 5 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00517	1	BACC45FT20A41S8 PLUG	81205	1	31-41-19 P61/ /	ALL
D00519	1	PT06CE-8-2S-SR- RCPT-		1	27-32-11 235/198/L20	001-002, 115-199
D00519	1	PT06E-8-2S-SR- RCPT-		1	27-32-11 235/198/L20	003-099
D00519	2	PT06E-8-2S-SR- RCPT-		1	27-32-11 235/198/L20	001-002, 115-199
D00521	1	66-16842-15 JACK- OBS HAND MIC	232N4313 81205	1	23-51-41 /P17/	001-099
D00521	1	XLR-4-31 JACK-	71468	1	23-51-41 P17/ /	115-199
D00523	1	2J-1866A JACK-	82389	1	23-51-41 P17/ /	ALL
D00525	1	2J-1869 JACK-	82389	1	23-51-41 P17/ /	ALL
D00527	1	BACC45FT8A3S PLUG-	81205	1	23-51-41 P17/ /	ALL
D00528	1	BACC63BP10A5SNL PLUG	81205	1	29-35-11 1052/188/L050	ALL
D00528 T		BACC10HG10 CABLE CLAMP	81205	1	29-35-11 */ */	ALL
D00529	1	66-16842-15 JACK- F/O HAND MIC	232N4313 81205	1	23-51-21 /P14/	001-099
D00529	1	XLR-4-31 JACK-	71468	1	23-51-21 231/205/R30	115-199
D00530	1	BACC63BP10A5SNL PLUG	81205	1	29-35-11 1183/151/L060	ALL
D00530 T		BACC10HG10 CABLE CLAMP	81205	1	29-35-11 */ */	ALL
D00531	1	2J-1866A JACK-	82389	1	23-51-21 240/210/R46	001-099
D00531	1	2J-1866A JACK-	82389	1	23-51-21 P14/ /	115-199

EQUIPMENT LIST

D280N032

Section D00500

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00532	1	BACC63BP10A5SNL PLUG	81205	1	29-35-11 1052/180/R40	ALL
D00532 T		BACC10HG10 CABLE CLAMP	81205	1	29-35-11 1052/180/R40	ALL
D00533	1	2J-1869 JACK-	82389	1	23-51-21 240/210/R46	001-099
D00533	1	2J-1869 JACK-	82389	1	23-51-21 P14/ /	115-199
D00534	1	BACC45FT12-12S7 PLUG	81205	1	32-41-11 P3-1/ /	ALL
D00534 T		BACC10GH12 CABLE CLAMP	81205	1	32-41-11 */ */	001-099
D00534 T		BACC10GH12 CABLE CLAMP	81205	1	32-41-11 P3-1/ /	115-199
D00535	1	BACC45FT8A3S PLUG-	81205	1	23-51-21 P14/ /	ALL
D00536	1	BACC63BP12A3SNL PLUG	81205	1	32-41-11 1061/151/R11	ALL
D00536 T		BACC10HG12 CABLE CLAMP	81205	1	32-41-11 1061/151/R11	ALL
D00537	1	BACC45FT12-12S PLUG-	81205	1	23-51-21 P14/216/R32	001-099
D00537	1	BACC45FT12-12S PLUG-	81205	1	23-51-21 P14/ /	115-199
D00537 T		BACC10GH12 CABLE CLAMP	81205	1	23-51-21 */ /	ALL
D00539	1	66-16842-15 JACK- CAPT HAND MIC	232N4313 81205	1	23-51-11 /P13/	001-099
D00539	1	XLR-4-31 JACK-	71468	1	23-51-11 P13/ /	115-199
D00541	1	2J-1866A JACK-	82389	1	23-51-11 240/210/L46	001-099
D00541	1	2J-1866A JACK-	82389	1	23-51-11 P13/ /	115-199

EQUIPMENT LIST

D280N032

Section D00500

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00542	1	BACS16W1 RELAY SOCKET-	81205	1	24-34-11 P006-00/ /	ALL
D00543	1	2J-1869 JACK-	82389	1	23-51-11 240/210/L46	001-099
D00543	1	2J-1869 JACK-	82389	1	23-51-11 P13/ /	115-199
D00544	1	BACS16W1 RELAY SOCKET	81205	1	24-51-31 P006-00/ /	ALL
D00545	1	BACC45FT8A3S PLUG-	81205	1	23-51-11 P13/ /	ALL
D00546	1	BACC45FT12D12S PLUG-	81205	1	24-33-11 P006-00/ /	ALL
D00547	1	BACC45FT12-12S PLUG-	81205	1	23-51-11 P13/ /	ALL
D00547 T		BACC10GH12 CABLE CLAMP	81205	1	23-51-11 P13/ /	ALL
D00548	1	BACS16W1 RELAY SOCKET	81205	1	24-33-11 P006-00/ /	ALL
D00549	1	XLR-4-31 JACK-	71468	1	23-51-51 P61/ /	115-199
D00550	1	BACC66F11C9901 PLUG PLATE ASSY	81205	1	24-22-22 E005-03/ /	001-099
D00550	1	BACC66F11C9901 PLUG PLATE ASSY	81205	1	24-22-22 E5-3/ /	115-199
D00550A	1	PARTAOFD00550 PLUG-		0	24-22-22 E005-03/ /	001-099
D00550A	1	PARTAOFD00550 PLUG-		0	24-22-22 E5-3/ /	115-199
D00550B	1	PARTBOFD00550 PLUG-		0	24-22-22 E005-03/ /	001-099
D00550B	1	PARTBOFD00550 PLUG-		0	24-22-22 E5-3/ /	115-199
D00550C	1	PARTCOFD00550 PLUG-		0	24-22-22 E005-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D00500

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00550C	1	PARTCOFD00550 PLUG-		0	24-22-22 E5-3/ /	115-199
D00551	1	2J-1866A JACK	82389	1	23-51-51 P61/ /	001-099
D00551	1	2J-1866A JACK-	82389	1	23-51-51 P61/ /	115-199
D00553	1	2J-1869 JACK-	82389	1	23-51-51 P61/ /	115-199
D00554	1	BACC63BV14B7SN RECPT	81205	1	36-11-21 PPS183/ /	ALL
D00554 T		BACC10HD14A CABLE CLAMP	81205	1	36-11-21 PPS183/ /	ALL
D00555	1	BACC63BN08-3S PLUG-	81205	1	23-51-51 P61/ /	115-199
D00555 T		GTR21-8CD CABLE CLAMP	06324	1	23-51-51 */ /	115-199
D00560	1	BACC45FT20A41S7 PLUG	81205	1	26-15-11 P008-00/ /	001-099
D00560	1	BACC45FT20A41S7 PLUG	81205	1	26-15-11 P8/ /	115-199
D00568	1	BACC63BP14A7SNL PLUG	81205	1	30-11-11 OSS320/ /	ALL
D00568 T		BACC10HF14 CABLE CLAMP	81205	1	30-11-11 */*/	ALL
D00570	1	BACC63BP14A7SNL PLUG	81205	1	30-11-11 OSS320/ /	ALL
D00570 T		BACC10HF14 CABLE CLAMP	81205	1	30-11-11 */*/	ALL
D00572	1	BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	21-58-12 P036-00/ /	001-099
D00572	1	BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	21-58-12 P36/ /	115-199
D00574	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-12 P037-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D00500

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00574	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-12 P37/ /	115-199
D00578	1	BACC45FT12D12S PLUG-	81205	1	21-58-12 555/175/L045	ALL
D00580	1	BACC45FT12A12S PLUG-	81205	1	21-58-12 560/182/L062	ALL
D00582	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P036-00/ /	001-099
D00582	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	115-199
D00584	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D00585	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	31-31-12 P037-00/ /	001-099
D00585	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	31-31-12 P37/ /	115-199
D00586	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D00588	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D00589	1	BACC65L66 RCPT-	81205	1	27-32-21 P051-00/ /	ALL
D00590	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D00592	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P036-00/ /	001-099
D00592	1	BACS16W1 RELAY SOCKET	81205	1	32-09-11 P33/ /	115-199
D00594	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D00595	1	BACC65L66 RCPT-	81205	1	31-51-42 P051-00/ /	ALL
D00596	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D00500

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00597	1	KD-19-66 RECP	91836	1	34-51-11 FIN400F/385/000	001-099
D00597	1	KD-19-105-M06 RECP	91836	1	34-51-11 FIN400F/385/000	115-199
D00598	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D00500

Page 6 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00600	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P036-00/ /	001-099
D00600	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	115-199
D00602	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P036-00/ /	001-099
D00602	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	115-199
D00604	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D00606	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D00608	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D00610	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00610	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00612	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00612	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00614	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00614	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00616	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00616	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00618	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-002
D00618	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	30-31-12 P037-00/ /	003-099

EQUIPMENT LIST

D280N032

Section D00600

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00618	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	30-31-12 P37/ /	115-199
D00620	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00620	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00621	1	KD-19-66 RECP	91836	1	34-51-21 FIN400/FS/	001-099
D00621	1	KD-19-105-M06 RECP	91836	1	34-51-21 FIN400/FS/	115-199
D00622	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00622	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00623	1	BACC45FN12-12S RCPT-	81205	1	27-61-17 247/199/L006	ALL
D00624	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00624	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00625	1	BACC45FN12-12S RCPT	81205	1	27-61-13 247/199/L008	ALL
D00626	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00626	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00627	1	BACC45FN12-12S RCPT-	81205	1	27-61-18 247/199/L010	ALL
D00628	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00628	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00629	1	BACC45FN12-12S RCPT-	81205	1	27-61-15 247/199/R034	001-099

EQUIPMENT LIST

D280N032

Section D00600

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00629	1	BACC45FN12-12S RCPT-	81205	1	27-61-15 276/199/R34	115-199
D00630	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00630	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00631	1	BACC45FN12-12S RCPT	81205	1	27-61-14 247/199/R36	ALL
D00632	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00632	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00633	1	BACC45FN12-12S RCPT-	81205	1	27-61-16 247/199/R038	001-099
D00633	1	BACC45FN12-12S RCPT-	81205	1	27-61-16 247/199/R38	115-199
D00634	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00634	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00635	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-13 E003-01/ /	ALL
D00635A	1	PARTAOFD00635 PLUG-		0	27-61-13 E003-01/ /	ALL
D00635B	1	PARTBOFD00635 PLUG-		0	27-61-13 E003-01/ /	ALL
D00635C	1	PARTCOFD00635 PLUG-		0	27-61-13 E003-01/ /	ALL
D00636	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D00636	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D00637	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-17 E003-01/ /	ALL

EQUIPMENT LIST

D280N032

Section D00600

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00637A	1	PARTAOFD00637 PLUG-		0	27-61-17 E003-01/ /	ALL
D00637B	1	PARTBOFD00367 PLUG-		0	27-61-17 E003-01/ /	ALL
D00637C	1	PARTCOFD00637 PLUG-		0	27-61-17 E003-01/ /	ALL
D00639	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-18 E003-01/ /	ALL
D00639A	1	PARTAOFD00639 PLUG-		0	27-61-18 E003-01/ /	ALL
D00639B	1	PARTBOFD00639 PLUG-		0	27-61-18 E003-01/ /	ALL
D00639C	1	PARTCOFD00639 PLUG-		0	27-61-18 E003-01/ /	ALL
D00640	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 409/288/R38	115-199
D00641	1	CN0966A16A10SN-000 PLUG-	81205	1	27-61-13 WS617/ /	ALL
D00641 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-13 */ */	001-004
D00641 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-13 WS617/ /	005-099, 115-199
D00642	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 475/288/R38	ALL
D00643	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-14 WS553/ /	ALL
D00643 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-14 WS553/ /	001-099
D00643 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-14 */ /	115-199
D00644	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 536/288/R38	001-099
D00644	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 535/288/R38	115-199

EQUIPMENT LIST

D280N032

Section D00600

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00645	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-15 WS489/ /	ALL
D00645 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-15 WS489/ /	001-099
D00645 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-15 */ /	115-199
D00646	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 596/288/R38	001-099
D00646	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 595/288/R38	115-199
D00647	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-16 WS425/ /	ALL
D00647 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-16 WS425/ /	001-099
D00647 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-16 */ /	115-199
D00648	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 636/288/R38	115-199
D00649	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-17 IRSS358/ /	ALL
D00649 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-17 */ */	001-004
D00649 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-17 IRSS358/ /	005-099, 115-199
D00650	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 716/ /	001-099
D00650	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 715/288/R38	115-199
D00651	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-18 IRSS290/ /	ALL
D00651 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-18 */ */	001-099
D00651 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-18 */ /	115-199

EQUIPMENT LIST

D280N032

Section D00600

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00652	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 776/ /	001-099
D00652	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 775/288/R38	115-199
D00653	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-18 IRSS290/ /	001-004, 115-199
D00653	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-18 IRSS275/ /	005-099
D00653 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-18 */ */	001-004
D00653 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-18 IRSS290/ /	005-099, 115-199
D00655	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-17 IRSS347/ /	ALL
D00655 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-17 */ */	001-099
D00655 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-17 */ /	115-199
D00656	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 836/288/R38	001-099
D00656	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 835/288/R38	115-199
D00657	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-16 WS413/ /	ALL
D00657 T		BACC10HF16 CABLE CLAMP	81205	1	27-61-16 WS413/ /	ALL
D00658	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 896/288/R38	001-099
D00658	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 895/288/R38	115-199
D00659	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-15 WS477/ /	ALL
D00659 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-15 WS477/ /	ALL

EQUIPMENT LIST

D280N032

Section D00600

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00660	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 956/288/R38	001-099
D00660	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 955/288/R38	115-199
D00661	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-14 WS545/ /	ALL
D00661 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-14 WS545/ /	ALL
D00662	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1016/288/R38	001-099
D00662	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1015/288/R38	115-199
D00663	1	CN0966A16A10SN-000 PLUG	81205	1	27-61-13 WS605/ /	ALL
D00663 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-13 */ */	001-099
D00663 T		BACC10HG16 CABLE CLAMP	81205	1	27-61-13 WS605/ /	115-199
D00664	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1076/288/R38	001-099
D00664	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1075/288/R38	115-199
D00665	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-14 E004-01/ /	001-099
D00665	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-14 E4-1/ /	115-199
D00665A	1	PARTAOFD00665 PLUG-		0	27-61-14 E004-01/ /	001-099
D00665A	1	PARTAOFD00665 PLUG-		0	27-61-14 E4-1/ /	115-199
D00665B	1	PARTBOFD00665 PLUG-		0	27-61-14 E004-01/ /	001-099
D00665B	1	PARTBOFD00665 PLUG-		0	27-61-14 E4-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D00600

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00665C	1	PARTCOFD00665 PLUG-		0	27-61-14 E004-01/ /	001-099
D00665C	1	PARTCOFD00665 PLUG-		0	27-61-14 E4-1/ /	115-199
D00666	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1136/288/R38	001-099
D00666	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1135/288/R38	115-199
D00667	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-15 E004-01/ /	001-099
D00667	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-15 E4-1/ /	115-199
D00667A	1	PARTAOFD00667 PLUG-		0	27-61-15 E004-01/ /	001-099
D00667A	1	PARTAOFD00667 PLUG-		0	27-61-15 E4-1/ /	115-199
D00667B	1	PARTBOFD00667 PLUG-		0	27-61-15 E004-01/ /	001-099
D00667B	1	PARTBOFD00667 PLUG-		0	27-61-15 E4-1/ /	115-199
D00667C	1	PARTCOFD00667 PLUG-		0	27-61-15 E004-01/ /	001-099
D00667C	1	PARTCOFD00667 PLUG-		0	27-61-15 E4-1/ /	115-199
D00668	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1196/288/R38	001-099
D00668	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1195/288/R38	115-199
D00669	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-16 E004-01/ /	001-099
D00669	1	BACC66H21C2001 PLUG PLATE ASSY-	81205	1	27-61-16 E4-1/ /	115-199
D00669A	1	PARTAOFD00669 PLUG-		0	27-61-16 E004-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D00600

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00669A	1	PARTAOFD00669 PLUG-		0	27-61-16 E4-1/ /	115-199
D00669B	1	PARTBOFD00669 PLUG-		0	27-61-16 E004-01/ /	001-099
D00669B	1	PARTBOFD00669 PLUG-		0	27-61-16 E4-1/ /	115-199
D00669C	1	PARTCOFD00669 PLUG-		0	27-61-16 E004-01/ /	001-099
D00669C	1	PARTCOFD00669 PLUG-		0	27-61-16 E4-1/ /	115-199
D00670	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1256/288/R38	001-099
D00670	1	BACC45FT12-12S PLUG-	81205	1	33-21-22 1255/288/R38	115-199
D00671	1	BACC66H21C3101 PLUG PLATE ASSY-	81205	1	27-09-11 E004-01/ /	001-099
D00671	1	BACC66H21C3101 PLUG PLATE ASSY-	81205	1	27-09-11 E4-1/ /	115-199
D00671A	1	PARTAOFD00671 PLUG-		0	27-41-21 E004-01/ /	001-099
D00671A	1	PARTAOFD00671 PLUG-		0	27-41-21 E4-1/ /	115-199
D00671B	1	PARTBOFD00671 PLUG-		0	27-09-11 E004-01/ /	001-099
D00671B	1	PARTBOFD00671 PLUG-		0	27-09-11 E4-1/ /	115-199
D00671C	1	PARTCOFD00671 PLUG-		0	27-09-11 E004-01/ /	001-099
D00671C	1	PARTCOFD00671 PLUG-		0	27-09-11 E4-1/ /	115-199
D00673	1	BACC66H21C3101 PLUG PLATE ASSY-	81205	1	27-61-15 E004-01/ /	001-099
D00673	1	BACC66H21C3101 PLUG PLATE ASSY-	81205	1	27-61-15 E4-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D00600

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00673A	1	PARTAOFD00673 PLUG-		0	27-61-15 E004-01/ /	001-099
D00673A	1	PARTAOFD00673 PLUG-		0	27-61-15 E4-1/ /	115-199
D00673B	1	PARTBOFD00673 PLUG-		0	27-61-15 E004-01/ /	001-099
D00673B	1	PARTBOFD00673 PLUG-		0	27-61-15 E4-1/ /	115-199
D00673C	1	PARTCOFD00673 PLUG-		0	27-61-15 E004-01/ /	001-099
D00673C	1	PARTCOFD00673 PLUG-		0	27-61-15 E4-1/ /	115-199
D00674	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1356/288/R38	001-099
D00674	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1355/288/R38	115-199
D00675	1	BACC66H21C1901 PLUG PLATE ASSY-	81205	1	22-24-21 E004-01/ /	001-099
D00675	1	BACC66H21C1901 PLUG PLATE ASSY-	81205	1	22-24-21 E4-1/ /	115-199
D00675A	1	PARTAOFD00675 PLUG-		0	22-24-21 E004-01/ /	001-099
D00675A	1	PARTAOFD00675 PLUG-		0	22-24-21 E4-1/ /	115-199
D00675B	1	PARTBOFD00675 PLUG-		0	22-24-21 E004-01/ /	001-099
D00675B	1	PARTBOFD00675 PLUG-		0	22-24-21 E4-1/ /	115-199
D00675C	1	PARTCOFD00675 PLUG-		0	22-24-21 E004-01/ /	001-099
D00675C	1	PARTCOFD00675 PLUG-		0	22-24-21 E4-1/ /	115-199
D00676	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1416/288/R38	001-099

EQUIPMENT LIST

D280N032

Section D00600

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00676	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1415/288/R38	115-199
D00678	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1476/288/R38	001-099
D00678	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1475/288/R38	115-199
D00680	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1536/288/R38	001-099
D00680	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1535/288/R38	115-199
D00682	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1596/288/R38	001-099
D00682	1	BACC45FT12-12S PLUG-	81205	1	33-21-23 1595/288/R38	115-199
D00687	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	31-31-12 P037-00/ /	001-099
D00687	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	31-31-12 P37/ /	115-199
D00689	1	BACC63BP14A7SNL PLUG-	81205	1	27-31-12 1862/235/L18	ALL
D00689 T		BACC10HG14 CABLE CLAMP	81205	1	27-31-12 */ */*	ALL
D00691	1	BACC45FN10-5S9 RCPT	81205	1	23-42-11 683/295/L030	001-099

EQUIPMENT LIST

D280N032

Section D00600
Page 11 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00701	1	BACC66H21C3101 PLUG PLATE ASSY-	81205	1	27-61-17 E003-01/ /	ALL
D00701A	1	PARTAOFD00701 PLUG-		0	27-61-17 E003-01/ /	ALL
D00701B	1	PARTBOFD00701 PLUG-		0	27-61-17 E003-01/ /	ALL
D00701C	1	PARTCOFD00701 PLUG-		0	27-61-17 E003-01/ /	ALL
D00703	1	BACC66H21C3101 PLUG PLATE ASSY-	81205	1	27-61-17 E003-01/ /	ALL
D00703A	1	PARTAOFD00703 PLUG-		0	27-61-17 E003-01/ /	ALL
D00703B	1	PARTBOFD00703 PLUG-		0	27-61-17 E003-01/ /	ALL
D00703C	1	PARTCOFD00703 PLUG-		0	27-61-17 E003-01/ /	ALL
D00705	1	BACC66H21C1901 PLUG PLATE ASSY-	81205	1	22-24-11 E003-01/ /	ALL
D00705A	1	PARTAOFD00705 PLUG-		0	22-24-11 E003-01/ /	ALL
D00705B	1	PARTBOFD00705 PLUG-		0	22-24-11 E003-01/ /	ALL
D00705C	1	PARTCOFD00705 PLUG-		0	22-24-11 E003-01/ /	ALL
D00709	1	BACC66F11C2101 PLUG PLATE ASSY-	81205	1	27-21-12 E003-01/ /	ALL
D00709A	1	PARTAOFD00709 PLUG PLATE ASSY-		0	27-21-12 E003-01/ /	ALL
D00709B	1	PARTBOFD00709 PLUG PLATE ASSY-		0	27-21-12 E003-01/ /	ALL
D00709C	1	PARTCOFD00709 PLUG PLATE ASSY-		0	27-21-12 E003-01/ /	ALL
D00711	1	BACC66F11C2101 PLUG PLATE ASSY-	81205	1	27-21-22 E004-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D00700

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00711	1	BACC66F11C2101 PLUG PLATE ASSY-	81205	1	27-21-22 E4-1/ /	115-199
D00711A	1	PARTAOFD00711 PLUG-		0	27-21-22 E004-01/ /	001-099
D00711A	1	PARTAOFD00711 PLUG-		0	27-21-22 E4-1/ /	115-199
D00711B	1	PARTBOFD00711 PLUG-		0	27-21-22 E004-01/ /	001-099
D00711B	1	PARTBOFD00711 PLUG-		0	27-21-22 E4-1/ /	115-199
D00711C	1	PARTCOFD00711 PLUG-		0	27-21-22 E004-01/ /	001-099
D00711C	1	PARTCOFD00711 PLUG-		0	27-21-22 E4-1/ /	115-199
D00715	1	BACC63BV14A7SN RCPT-	81205	1	27-21-12 FIN115/RS/L4.5	ALL
D00715 T		BACC10HF14 CABLE CLAMP	81205	1	27-21-12 FIN115/RS/L4.5	ALL
D00717	1	BACC63BV14A7SN RCPT-	81205	1	27-21-22 FIN115/RS/L3	ALL
D00717 T		BACC10HF14 CABLE CLAMP	81205	1	27-21-22 FIN115/RS/L3	ALL
D00739	1	DPXBMB-67-33S-0001 PLUG-	71468	1	23-34-15 E4-4/ /	ALL
D00749	1	BACC45FT22A55S PLUG	81205	1	31-31-65 E3-3/ /	001-099
D00749	1	BACC45FT22A55S PLUG-	81205	1	31-31-12 E3-3/ /	115-199
D00751	1	BACC45FT22A55S PLUG-	81205	1	34-53-12 E3-3/ /	001-099
D00751	1	BACC45FT22A55S PLUG-	81205	1	34-53-11 E3-3/ /	115-199
D00753	1	BACC45FT22A55S PLUG-	81205	1	34-53-22 E003-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D00700

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00753	1	BACC45FT22A55S PLUG-	81205	1	34-53-21 E3-2/ /	115-199
D00755	1	BACC45FT22A55S EICAS L SHORTING RCPT-	81205	1	31-41-11 E4-2/ /	001-099
D00755	1	BACC45FT22A55S EICAS R SHORTING RCPT-	81205	1	31-41-11 E4-2/ /	115-199
D00757	1	BACC45FT22A55S EICAS R SHORTING RCPT-	81205	1	31-41-21 E4-2/ /	001-099
D00757	1	BACC45FT22A55S EICAS L SHORTING RCPT-	81205	1	31-41-21 E4-2/ /	115-199
D00759	1	BACS16AG1 RELAY SOCKET-	903743	2	23-31-16 MULTI/ /	001-099
D00759	1	BACS16AG1 RELAY SOCKET-	812053	2	23-31-16 MULTI/ /	115-199
D00761	1	BACC45FN14-15S RCPT-	81205	1	31-31-01 P061-00/ /	001-099
D00761	1	BACC45FN14-15S RCPT-	81205	1	31-31-11 P061-00/ /	115-199
D00763	1	BACC45FT10-5S PLUG	81205	1	23-51-51 P8/ /	115-199
D00763 T		BACC10GH10 CABLE CLAMP-	81205	1	23-51-51 */ /	115-199
D00765	1	BACC45FN10A5S RCPT-	81205	1	23-42-11 352/290/L35	115-199
D00767	1	XLR-5-31 JACK-	71468	1	23-42-11 1638/ /	ALL
D00771	1	BACC45FT22A55S6 PLUG	81205	1	34-22-83 P001-3/ /	115-199
D00773	1	BACC45FT12-12S7 PLUG	81205	1	34-22-83 P001-3/ /	115-199
D00773 T		BACC10GH12 CABLE CLAMP	81205	1	34-22-83 */ */	115-199
D00775	1	BACC45FT14A15S6 PLUG	81205	1	34-22-83 P001-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D00700

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00777	1	BACC66H21C5001 PLUG PLATE ASSY-	81205	1	31-31-11 E3-3/ /	115-199
D00777A	1	PARTAOFD00777 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00777B	1	PARTBOFD00777 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00777C	1	PARTCOFD00777 PLUG-	81205	0	31-31-11 E3-3/ /	115-199
D00779	1	KPSE06F14-19S PLUG-		1	31-31-11 P014-00/ /	115-199
D00781	1	BACC45FT16A24S6 PLUG-	81205	1	34-57-11 P008-00/ /	ALL
D00783	1	BACC45FT16A24S9 PLUG-	81205	1	34-57-21 P008-00/ /	010-099
D00783	1	BACC45FT16A24S9 PLUG-	81205	1	34-57-21 P8/ /	115-199
D00787	1	SO-1064-007 RELAY SOCKET	35344	1	27-41-11 E003-01/ /	ALL
D00789	1	BACC65L114 PLUG-		1	31-41-11 E4-2/ /	ALL
D00791	1	BACC65L114 PLUG-	81205	1	31-41-21 E4-2/ /	ALL
D00795	1	BACC45FT12-12S9 PLUG	81205	1	34-55-11 P001-1/ /	115-199
D00795 T		BACC10GH12 CABLE CLAMP	81205	1	34-55-11 */*/	115-199
D00797	1	BACC45FT12-12S10 PLUG	81205	1	34-55-21 P001-1/ /	115-199
D00797 T		BACC10GH12 CABLE CLAMP	81205	1	34-55-21 */*/	115-199

EQUIPMENT LIST

D280N032

Section D00700

Page 4 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00801	1	BACC45FT22A55S6 PLUG	81205	1	34-22-93 P3-3/ /	115-199
D00803	1	BACC45FT12-12S7 PLUG	81205	1	34-22-93 P3-3/ /	115-199
D00803 T		BACC10GH12 CABLE CLAMP	81205	1	34-22-93 P3-3/ /	115-199
D00805	1	BACC45FT14A15S6 PLUG	81205	1	34-22-93 P3-3/ /	115-199
D00809	1	SO-1064-007 RELAY SOCKET	35344	1	27-41-21 E004-01/ /	001-099
D00809	1	SO-1064-007 RELAY SOCKET	35344	1	27-41-21 E4-1/ /	115-199
D00811	1	BACC45FT12-12S9 PLUG	81205	1	34-55-11 P3-1/ /	115-199
D00811 T		BACC10GH12 CABLE CLAMP	81205	1	34-55-11 P3-1/ /	115-199
D00813	1	BACC45FT12-12S10 PLUG	81205	1	34-55-21 P3-1/ /	115-199
D00813 T		BACC10GH12 CABLE CLAMP	81205	1	34-55-21 P3-1/ /	115-199
D00815	1	BACC65L66 RCPT-	81205	1	31-51-36 P051-00/ /	009, 115-199
D00817	1	SO-1064-007 RELAY SOCKET	35344	1	31-51-11 P051-00/ /	ALL
D00819	1	SO-1064-007 RELAY SOCKET	35344	1	31-51-12 P051-00/ /	ALL
D00821	1	BACC65L66 RCPT	81205	1	27-48-21 P50/ /	ALL
D00823	1	BACC65L66 RCPT	81205	1	27-48-21 P50/ /	ALL
D00825	1	BACC45FT14D7S XFMR PLUG (PLATE 'B')	81205	1	27-48-21 P36/ /	ALL
D00831	1	BACC63BV14A7SN RCPT-	81205	1	22-11-21 1860/235/0	ALL

EQUIPMENT LIST

D280N032

Section D00800

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00831 T		BACC10HF14 CABLE CLAMP-	81205	1	22-11-21 */ */	ALL
D00833	1	BACC63BV14A7SN RCPT-	81205	1	22-11-31 1860/245/R10	ALL
D00833 T		BACC10HF14A CABLE CLAMP-	81205	1	22-11-31 1860/245/R10	ALL
D00835	1	BACC63BP10A5SNL PLUG-	81205	1	27-31-11 1785/231/R042	ALL
D00835 T		BACC10HG10 CABLE CLAMP-	81205	1	27-31-11 */ */	ALL
D00837	1	BACC45FN10A5S RCPT-	81205	1	23-42-11 1315/295/R035	001-099
D00837	1	BACC45FN10A5S RCPT-	81205	1	23-42-11 1293/295/R35	115-199
D00839	1	BACC45FT10-5S PLUG-	81205	1	23-42-11 656/280/R55	115-199
D00839 T		BACC10GH10 CLAMP	81205	1	23-42-11 */ /	115-199
D00843	1	2J-1865A JACK-	82389	1	23-41-12 E005-00/ /	001-099
D00843	1	2J-1865A JACK-	82389	1	23-41-11 560/192/R62	115-199
D00847	1	BACC66F11C04AB01 PLUG PLATE ASSY-VHF C	81205	1	23-12-31 E4-4/ /	001-099
D00847A	1	PARTAOFD00847 PLUG-VHF C	81205	0	23-12-31 E4-4/ /	001-099
D00847B	1	PARTBOFD00847 PLUG-VHF C	81205	0	23-12-31 E4-4/ /	001-099
D00847C	1	PARTCOFD00847 PLUG-VHF C	81205	0	23-12-31 E4-4/ /	001-099
D00849	1	BACC45FT22A55S PLUG-	81205	1	23-21-12 E004-03/ /	001-099
D00849	1	BACC45FT22A55S PLUG-	81205	1	23-21-12 E4-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D00800

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00871	1	BACC45FN12-12S RCPT	81205	1	27-61-17 210/ /	ALL
D00873	1	BACC45FN12-12S RCPT	81205	1	27-61-17 AC0220/ /	ALL
D00875	1	BACC45FN14-15S RCPT	81205	1	27-61-14 AC0210/ /	ALL
D00877	1	BACC45FN12-12S RCPT	81205	1	27-61-13 AC215/195/L011	ALL
D00878	1	53CM61 RCPT-400CPS,5AMP,115V AC	284N1360 74545	1	25-29-11 479/164/R023	ALL
D00879	1	BACC45FN14-15S RCPT	81205	1	27-61-15 AC0220/ /	ALL
D00880	1	5261 RECP-SERVICE OUTLET,115V AC,400HZ	287N4102 74545	1	25-29-11 P006-04/ /	001-099
D00880	1	5261 RECP-SERVICE OUTLET,115V AC,400HZ	287N4102 74545	1	25-29-11 P006-02/ /	115-199
D00881	1	BACC45FN14-15S RCPT	81205	1	27-61-14 AC0215/ /	ALL
D00882	1	5362 RCPT-OUTLET	411N2331 74545	1	25-29-11 0338/212/L060	ALL
D00884	1	5362 RECP-OUTLET	411N2361 74545	1	25-29-11 1320/235/L060	ALL
D00888	1	BACC45FT12A12S PLUG	81205	1	33-11-11 P007-00/ /	ALL
D00889	1	BACC45FT10-5S PLUG-	81205	1	23-42-11 682/215/R30	115-199
D00890	1	BACC45FT10-5S PLUG	81205	1	33-11-11 P7/ /	001-099
D00890	1	BACC45FT10-5S PLUG	81205	1	33-11-11 290/220/L15	115-199
D00890 T		BACC10GH10 CABLE CLAMP	81205	1	33-11-11 */ */	ALL
D00891	1	BACC45FT16A24S PLUG-	81205	1	23-12-31 P008-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D00800

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00892	1	BACC45FT16A24S PLUG	81205	1	33-11-11 210/210/R10	001-099
D00892	1	BACC45FT16A24S PLUG	81205	1	33-11-11 P3-3/ /	115-199
D00896	1	BACC45FT12A12S PLUG	81205	1	33-11-11 P007-00/ /	ALL
D00898	1	BACC45FT16A24S PLUG	81205	1	33-11-11 156/220/	001-099
D00898	1	BACC45FT16A24S PLUG	81205	1	33-11-11 P3-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D00800
Page 4 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00901	1	BACC65L66 RCPT-	81205	1	31-51-31 P051-00/ /	ALL
D00903	1	BACC65L66 RCPT-	81205	1	31-51-33 P051-00/ /	ALL
D00905	1	BACC65L66 RCPT-	81205	1	31-51-35 P051-00/ /	009, 115-199
D00907	1	BACC65L66 RCPT-	81205	1	31-51-34 P051-00/ /	009, 115-199
D00909	1	BACC65L66 RCPT	81205	1	27-48-21 P50/ /	ALL
D00913	1	BACC63BV14A7SN RCPT-	81205	1	22-11-11 1860/245/R10	ALL
D00913 T		BACC10HF14 CABLE CLAMP-	81205	1	22-11-11 */ */*	ALL
D00915	1	BACC45FN10A5S RCPT-	81205	1	23-42-11 385/275/L060	001-099
D00915	1	BACC45FN10A5S RCPT-	81205	1	23-42-11 367/290/L35	115-199
D00917	1	BACC45FN18A31S RCPT-DATA BASE LOAD, LH	81205	1	34-61-14 P017-00/ /	ALL
D00919	1	BACC66F11C5201 PLUG PLATE ASSY	81205	1	34-25-11 E2-3/ /	001, 003-099
D00919	1	BACC66F11C5201 PLUG PLATE ASSY-	81205	1	34-25-11 E2-3/ /	115-199
D00919A	1	PARTAOFD00919 PLUG-		0	34-25-11 E2-3/ /	001, 003-099, 115-199
D00919B	1	PARTBOFD00919 PLUG-		0	34-25-11 E2-3/ /	001, 003-099, 115-199
D00919C	1	PARTCOFD00919 PLUG-		0	34-25-11 E2-3/ /	001, 003-099, 115-199
D00939	1	XLR-5-31 JACK-	71468	1	23-42-11 370/244/L037	001-099
D00945	1	BACC45FT10-5P PLUG-	81205	1	23-42-11 383/275/L056	001-099

EQUIPMENT LIST

D280N032

Section D00900

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00945 T		BACC10GH10 CABLE CLAMP-	81205	1	23-42-11 */*/*	001-099
D00947	1	L14TL12P6NA PLUG	09922	1	23-32-01 453/297/L015	001-099
D00951	1	L14TL12P6NA PLUG	09922	1	23-32-01 453/295/R015	001-099
D00953	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 453/297/R020	001-099
D00955	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 954/295/R005	001-099
D00970	1	BACC45FT12A12S PLUG-	81205	1	33-27-11 347/289/R019	001-099
D00970	1	BACC45FT12A12S PLUG-	81205	1	33-27-11 345/295/R20	115-199
D00994	1	BACC45FT12A12S PLUG-	81205	1	33-27-31 1668/294/R5	001-099
D00994	1	BACC45FT12A12S PLUG-	81205	1	33-27-31 1668/294/L3	115-199

EQUIPMENT LIST

D280N032

Section D00900

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01076	1	BACC63CE24-11S PLUG	81205	1	24-32-41 1484/ /	001-099
D01076	1	BACC63CE24-11S PLUG-	81205	1	24-32-41 1630/172/R43	115-199

EQUIPMENT LIST

D280N032

Section D01000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01100J	1	BACC63CN2842SN RCPT	81205	1	80-11-11 AS1080/ /	ALL
D01100JK		BACC10HF28C CABLE CLAMP	81205	1	80-11-11 */ /	ALL
D01102J	1	BACC63CN2842S6 RCPT	81205	1	73-31-11 AS1080/ /	ALL
D01102JK		BACC10HF28C CABLE CLAMP	81205	1	73-31-11 */ /	ALL
D01104J	1	BACC63CN2842S7 RCPT	81205	1	77-12-31 78/5.0/	001-099
D01104J	1	BACC63CN2842S7 RCPT	81205	1	77-12-31 AS1080/ /	115-199
D01104JK		BACC10HF28C CABLE CLAMP	81205	1	77-12-31 78/5.0/	001-099
D01104JK		BACC10HF28C CABLE CLAMP	81205	1	77-12-31 AS1080/ /	115-199
D01106J	1	BACC63CN2842S8 RCPT	81205	1	77-11-11 PPS78/ /R05	001-099
D01106J	1	BACC63CN2842S8 RCPT	81205	1	77-11-11 AS1080/ /	115-199
D01106JK		S2277-28-34 CABLE CLAMP	07418	1	77-11-11 PPS78/ /R05	001-099
D01106JK		S2277-28-34 CABLE CLAMP	07418	1	77-11-11 */ /	115-199
D01108J	1	BACC63CN2219SN RCPT	81205	1	77-22-12 78/5.0/	001-099
D01108J	1	BACC63CN2219SN RCPT	81205	1	77-22-12 AS1080/ /	115-199
D01108JK		BACC10HF22C CABLE CLAMP	81205	1	77-22-12 78/5.0/	001-099
D01108JK		BACC10HF22C CABLE CLAMP	81205	1	77-22-12 AS1080/ /	115-199
D01110J	1	BACC63CN1814SN RCPT	81205	1	26-11-11 AS1080/ /	ALL

EQUIPMENT LIST

D280N032

Section D01100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01110JK		BACC10HF18C CABLE CLAMP	81205	1	26-11-11 AS1080/ /	ALL
D01112J	1	BACC63CN1407S6 RCPT	81205	1	77-31-11 PPS78/ /R01	001-099
D01112J	1	BACC63CN1407S6 RCPT	81205	1	77-31-11 AS1080/ /	115-199
D01112JK		BACC10HF14C CABLE CLAMP	81205	1	77-31-11 PPS78/ /R01	001-099
D01112JK		BACC10HF14C CABLE CLAMP	81205	1	77-31-11 */ /	115-199
D01114J	1	BACC63CN2430SN RCPT	81205	1	24-11-11 AS1080/ /	ALL
D01114JK		BACC10HF24 CABLE CLAMP	81205	1	24-11-11 */ /	ALL
D01116 U		312N5204-1 COVER PLATE	81205	2	24-21-11 */ */	ALL
D01116 V		312N5205-1 SEAL	81205	1	24-21-11 */ */	ALL
D01116 W		BACB30LE5-18 BOLT	81205	1	24-21-11 */ */	ALL
D01116 X		AN960C516 WASHER	81205	1	24-21-11 */ */	ALL
D01116 Y		BACN10JC5 NUT,SELF LOCKING	81205	1	24-21-11 */ */	ALL
D01116P	1	FRF6-36-5P13-747 PLUG	71468	1	24-21-11 PPS 90/136/R015	ALL
D01116PQ		G6652-36 CABLE CLAMP	06324	1	24-21-11 */ */	ALL
D01118J	1	BACC63CN1610SN RCPT	81205	1	78-36-11 AS1140/ /	ALL
D01118JK		BACC10HD16A CABLE CLAMP	81205	1	78-36-11 AS1140/ /	ALL
D01120J	1	BACC63CN1407SN RCPT	81205	1	78-34-11 AS1140/ /	ALL

EQUIPMENT LIST

D280N032

Section D01100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01120JK		BACC10HD14A CABLE CLAMP	81205	1	78-34-11 AS1140/ /	ALL

EQUIPMENT LIST

D280N032

Section D01100
Page 3 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01200J	1	BACC63CN2842SN RCPT	81205	1	80-11-21 AS2080/ /	ALL
D01200JK		BACC10HF28C CABLE CLAMP	81205	1	80-11-21 AS2080/ /	ALL
D01202J	1	BACC63CN2842S6 RCPT	81205	1	74-31-21 AS2080/ /RFS	ALL
D01202JK		BACC10HF28C CABLE CLAMP	81205	1	80-11-21 AS2080/ /	ALL
D01204J	1	BACC63CN2842S7 RCPT	81205	1	77-12-31 AS2080/ /	ALL
D01204JK		BACC10HF28C CABLE CLAMP	81205	1	77-12-31 */ /	ALL
D01206J	1	BACC63CN2842S8 RCPT	81205	1	77-11-11 W319/ /R5.0	001-099
D01206J	1	BACC63CN2842S8 RCPT	81205	1	77-11-11 WS2080/ /	115-199
D01206JK		S2277-28-34 CABLE CLAMP	07418	1	77-11-11 W319/ /R5.0	001-099
D01206JK		S2277-28-34 CABLE CLAMP	07418	1	77-11-11 */ /	115-199
D01208J	1	BACC63CN2219SN RCPT	81205	1	77-22-13 AS2080/ /	ALL
D01208JK		BACC10HF22C CABLE CLAMP	81205	1	77-22-13 */ /	ALL
D01210J	1	BACC63CN1814SN RCPT	81205	1	26-11-21 AS2080/ /	ALL
D01210JK		BACC10HF18C CABLE CLAMP	81205	1	26-11-21 AS2080/ /	ALL
D01212J	1	BACC63CN1407S6 RCPT	81205	1	77-31-11 W319/ /R1.5	001-099
D01212J	1	BACC63CN1407S6 RCPT	81205	1	77-31-11 AS2080/ /	115-199
D01212JK		BACC10HF14C CABLE CLAMP	81205	1	77-31-11 W319/ /R1.5	001-099

EQUIPMENT LIST

D280N032

Section D01200

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01212JK		BACC10HF14C CABLE CLAMP	81205	1	77-31-11 */ /	115-199
D01214J	1	BACC63CN2430SN RCPT	81205	1	24-11-21 AS2080/ /	ALL
D01214JK		BACC10HF24 CABLE CLAMP	81205	1	24-11-21 AS2080/ /	ALL
D01216 U		312N5204-1 COVER PLATE	81205	2	24-21-21 */ */	ALL
D01216 V		312N5205-1 SEAL	81205	1	24-21-21 */ */	ALL
D01216 W		BACB30LE5-18 BOLT	81205	1	24-21-21 */ */	ALL
D01216 X		AN960C516 WASHER	81205	1	24-21-21 */ */	ALL
D01216 Y		BACN10JC5 NUT,SELF LOCKING	81205	1	24-21-21 */ */	ALL
D01216P	1	FRF6-36-5P13-747 PLUG	71468	1	24-21-21 PPS 90/136/L015	ALL
D01216PQ		G6652-36 CABLE CLAMP	06324	1	24-21-21 */ */	ALL
D01218J	1	BACC63CN1610SN RCPT	81205	1	78-36-21 AS2140/ /	ALL
D01218JK		BACC10HD16A CABLE CLAMP	81205	1	78-36-21 AS2140/ /	ALL
D01220J	1	BACC63CN1407SN RCPT	81205	1	78-34-21 AS2140/ /	ALL
D01220JK		BACC10HD14A CABLE CLAMP	81205	1	78-34-21 AS2140/ /	ALL
D01221	1	BACS16AG1 RELAY SOCKET-	81205	1	23-31-22 1650/289/R003	ALL
D01223	1	BACC45FT10-5P PLUG-	81205	1	23-31-22 1610/278/L057	001-099
D01223	1	BACC45FT10-5P PLUG-	81205	1	23-31-22 1635/300/L010	115-199

EQUIPMENT LIST

D280N032

Section D01200

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01223 T		BACC10GH10 CABLE CLAMP-	81205	1	23-31-22 */ */ *	ALL
D01227	1	BACS16AG1 RELAY SOCKET-	81205	1	23-31-21 367/295/L010	ALL
D01229	1	BACC45FT10-5P6 PLUG-	81205	1	23-31-21 AA0409/ /	ALL
D01229 T		BACC10GH10 CLAMP-	81205	1	23-31-21 */ */ *	ALL
D01231	1	BACC45FN10-5S6 RCPT-	81205	1	23-31-21 409/ /	ALL
D01235	1	BACS16AG1 RELAY SOCKET-	81205	1	23-31-21 MULTI/ /	ALL
D01239	1	BACC45FT10-5P PLUG-	81205	1	23-31-21 710/290/	ALL
D01239 T		BACC10GH10 CABLE CLAMP-	81205	1	23-31-21 MULTI/ /	ALL
D01241	1	BACC45FN10-5S RCPT-	81205	1	23-31-31 712/291/R44	001-099
D01241	1	BACC45FN10-5S RCPT-	81205	1	23-31-31 712/291/R044	115-199
D01243	1	BACC45FN10-5S RCPT-	81205	1	23-31-22 1630/300/L009	001-099
D01243	1	BACC45FN10-5S RCPT-	81205	1	23-31-14 1630/300/L009	115-199
D01245	1	BACC45FN10-5S7 RCPT-	81205	1	23-31-15 1646/272/R60	001-099
D01245	1	BACC45FN10-5S7 RCPT-	81205	1	23-31-15 1620/287/R40	115-199
D01247	1	BACC45FN10-5S RCPT-	81205	1	23-31-21 708/260/L060	001-099
D01247	1	BACC45FN10-5S RCPT-	81205	1	23-31-21 705/260/L060	115-199
D01251	1	BACC45FN10-5S7 RCPT-	81205	1	27-58-31 560/192/R062	001-099

EQUIPMENT LIST

D280N032

Section D01200

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01251	1	BACC45FN10-5S7 RCPT-	81205	1	27-58-31 560/192/R62	115-199
D01273	1	MS3126F24-61S PLUG	71468	1	23-32-01 1550/274/R043	001-099
D01273	1	MS3126F24-61S PLUG	71468	1	23-32-01 1550/280/R052	115-199
D01275	1	KC-59-444 CABLE PLUG ZONE A	91836	1	23-32-01 1520/268/R40	001-099
D01275	1	KC-59-444 CABLE PLUG ZONE A	91836	1	23-32-01 1550/280/R52	115-199
D01277	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1550/268/R40	001-099
D01277	1	KC-59-261 CABLE PLUG ZONE B	91836	1	23-32-01 1550/280/R52	115-199
D01279	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1550/280/L12	001-099
D01279	1	KC-59-261 CABLE PLUG ZONE C	91836	1	23-32-01 1550/280/L12	115-199
D01281	1	KC-59-444 CABLE PLUG ZONE D	91836	1	23-32-01 1590/290/R022	001-099
D01281	1	KC-59-444 CABLE PLUG ZONE D	91836	1	23-32-01 1550/280/R52	115-199
D01283	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 657/290/L055	001-099
D01283	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 775/280/L015	115-199
D01287	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 453/297/L020	001-099
D01287	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 770/280/L015	115-199
D01291	1	BACC45FT12D12S PLUG	81205	1	23-32-01 432/297/L020	001-099
D01291	1	BACC45FT12D12S PLUG	81205	1	23-32-01 770/280/L015	115-199

EQUIPMENT LIST

D280N032

Section D01200

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01293	1	KC-59-444 CABLE PLUG	91863	1	23-32-01 432/297/L20	001-099
D01293	1	KC-59-444 CABLE PLUG	91863	1	23-32-01 770/280/L15	115-199
D01295	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 453/970/L020	001-099
D01295	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 770/280/L014	115-199
D01297	1	L14TL12P6NA PLUG	09922	1	23-32-01 770/280/L015	115-199
D01299	1	BACC45FN12A12S PLUG	81205	1	23-32-02 973/300/L015	115-199

EQUIPMENT LIST

D280N032

Section D01200

Page 5 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01301	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 799/280/L002	001-099
D01301	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 973/300/L009	115-199
D01303	1	BACC45FN12A12S RECP	81205	1	23-32-01 408/300/L012	115-199
D01305	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 395/303/0	001-099
D01305	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 408/290/L10	115-199
D01307	1	BACC45FT12-12S PLUG	81205	1	23-32-01 510/300/R010	001-099
D01307	1	BACC45FN12A12S PLUG	81205	1	23-32-01 610/300/L014	115-199
D01309	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 533/290/L5	001-099
D01309	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 610/290/L14	115-199
D01311	1	BACC45FT12D12S PLUG	81205	1	23-32-01 1292/300/L014	001-099
D01311	1	BACC45FT12D12S PLUG	81205	1	23-32-01 1330/300/L014	115-199
D01313	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1290/299/L15	001-099
D01313	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1330/300/L10	115-199
D01315	1	L14TL12P6NA PLUG	09922	1	23-32-01 1285/295/R010	001-099
D01315	1	L14TL12P6NA PLUG	09922	1	23-32-01 1330/301/L012	115-199
D01317	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1292/299/L015	001-099
D01317	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 1330/300/L014	115-199

EQUIPMENT LIST

D280N032

Section D01300

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01321	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1292/299/L015	001-099
D01321	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 1330/300/L014	115-199
D01323	1	L14TL12P6NA PLUG	09922	1	23-32-01 1292/296/R015	001-099
D01323	1	L14TL12P6NA PLUG	09922	1	23-32-01 1330/300/L012	115-199
D01325	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1292/299/L005	001-099
D01325	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 1330/300/L014	115-199
D01327	1	BACC45FN12A12S PLUG	81205	1	23-32-01 1120/300/L015	115-199
D01329	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1110/299/L015	001-099
D01329	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 1130/300/L014	115-199
D01333	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1310/290/L005	001-099
D01333	1	KC-59-261 CABLE PLUG	91836	1	23-32-01 1330/300/L014	115-199
D01335	1	BACC45FN12A12S PLUG	81205	1	23-32-01 1440/300/L015	115-199
D01337	1	KC-59-444 CABLE PLUG	91836	1	23-32-01 1440/299/L015	001-099
D01337	1	KC-59-261 CABLEP-PLUG	91836	1	23-32-01 1430/300/L014	115-199
D01349	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	23-34-15 P036-00/ /	ALL
D01351	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	23-34-15 P36/ /	115-199
D01353	1	DPXBMB-67-33S-0001 PLUG MAIN MULTIPLEXER	81205	1	23-34-15 E4-4/ /	ALL

EQUIPMENT LIST

D280N032

Section D01300

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01357	1	BACC45FT12A12S PLUG-	81205	1	22-21-11 1680/205/L25	ALL
D01359	1	BACC45FT12A12S PLUG-	81205	1	22-21-21 1680/205/R50	ALL
D01369	1	MS3120F10-6S RCPT	81205	1	23-34-12 1615/220/R065	001-099
D01369	1	MS3120F10-6S RCPT	81205	1	23-34-12 1362/ /	115-199
D01371	1	MS3120F10-6S RCPT	81205	1	23-34-12 1615/ /	001-099
D01371	1	MS3120F10-6S RCPT	81205	1	23-34-12 1362/ /	115-199
D01373	1	BACC45FN16-24S RCPT-	81205	1	23-31-19 354/294/L026	001-099

EQUIPMENT LIST

D280N032

Section D01300
Page 3 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01413	1	MS3120F10-6S RCPT	81205	1	23-34-13 625/215/L063	001-099
D01415	1	MS3120F10-6S RCPT	81205	1	23-34-13 753/215/L063	001-099
D01427	1	MS3126F10-6S PLUG	81205	1	34-53-11 E003-03/ /	001-099
D01427	1	MS3126F10-6S PLUG		1	34-53-11 E3-3/ /	115-199
D01429	1	KA-59-353-M06 PLUG-		1	34-53-11 0500/185/L040	ALL
D01431	1	KN-59-329-M06 PLUG-		1	34-53-11 E3-3/ /	ALL
D01433	1	KD-59-180-M06 PLUG-		1	34-53-21 500/184/L040	ALL
D01435	1	MS3126F10-6S PLUG	81205	1	34-53-11 E003-02/ /	001-099
D01435	1	MS3126F10-6S PLUG		1	34-53-11 E3-2/ /	115-199
D01437	1	KA-59-353-M06 PLUG-		1	34-53-11 E003-03/ /	ALL
D01439		KN-59-329-M06 PLUG-		1	34-53-11 500/174/L040	ALL
D01441	1	KD-59-180-M06 PLUG-		1	34-53-21 500/174/L040	ALL
D01443	1	KD-59-193-M06 PLUG-		1	34-53-11 535/ /	ALL
D01457	1	BACS16AF1 RELAY SOCKET (PLATE 'D')	81205	1	23-31-19 P36/ /	001-099
D01487	9	BACC45FT20A41S6 PLUG	81205	1	34-61-11 P009-00/ /	115-199
D01489	9	BACC45FT20A41S6 PLUG (34-0414)	81205	1	34-61-21 P009-00/ /	115-199
D01491	1	BACC63BN10B5S PLUG-	81205	1	31-31-51 238/185/L16	001-099

EQUIPMENT LIST

D280N032

Section D01400

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01493	1	BACC63BN10B5S PLUG-	81205	1	31-31-51 234/196/L17	001-099
D01495	1	BACC63BN10B5S PLUG-	81205	1	31-31-51 260/190/R14	001-099

EQUIPMENT LIST

D280N032

Section D01400
Page 2 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01501	1	BACC63BP12A3SNL PLUG	81205	1	31-31-52 1042/173/32	001-099
D01501 T		BACC10HF12A CABLE CLAMP	81205	1	31-31-52 1042/173/32	001-099
D01503	1	BACC63BP12A3SNL PLUG	81205	1	31-31-52 1042/182/R053	001-099
D01503 T		BACC10HF12A CABLE CLAMP	81205	1	31-31-52 1042/182/R053	001-099
D01504	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	30-21-11 P36/ /	ALL
D01505	1	BACC63BP12A3SNL PLUG	81205	1	31-31-52 1074/172/1.37	001-099
D01505 T		BACC10HF12A CABLE CLAMP	81205	1	31-31-52 1074/172/1.37	001-099
D01506	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	30-21-11 P36/ /	ALL
D01507	1	BACC63BP12A3SNL PLUG	81205	1	31-31-52 1079/164/R002	001-099
D01507 T		BACC10HF12A CABLE CLAMP	81205	1	31-31-52 1079/164/R002	001-099
D01508	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	30-21-11 P037-00/ /	001-099
D01508	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	30-21-11 P37/ /	115-199
D01510	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	30-21-11 P037-00/ /	001-099
D01510	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	30-21-11 P37/ /	115-199
D01515	9	BACS16W1A RELAY SOCKET (PLATE 'D')	81205	1	34-22-38 P036-00/ /	115-199
D01522	1	BACC63BP14A7SNL PLUG	81205	1	28-26-11 IRSS210/ /	ALL
D01522 T		BACC10HG14 CABLE CLAMP	81205	1	28-26-11 IRSS210/ /	001-099

EQUIPMENT LIST

D280N032

Section D01500

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01522 T		BACC10HG14 CABLE CLAMP	81205	1	28-26-11 */ /	115-199
D01524	1	BACC63BP14A7SNL PLUG	81205	1	28-26-11 IRSS206/ /	ALL
D01524 T		BACC10HG14 CABLE CLAMP	81205	1	28-26-11 */ */	ALL
D01560	1	CN0966A10A20SN-000 PLUG	13556	1	36-22-11 907/151/R056	ALL
D01560 T		BACC10HF10 CABLE CLAMP	81205	1	36-22-11 */ */	ALL
D01570	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-11 P36/ /	ALL
D01572	1	BACS16AH1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-11 P36/ /	ALL
D01574	1	BACC45FT10D5S6 PLUG	81205	1	21-58-11 271/171/R35	ALL
D01576	1	BACC45FT10A5S6 PLUG-	81205	1	21-58-11 207/170/R010	ALL
D01580	1	BACC45FN10A5S RECP	81205	1	21-45-11 230/200/L28	001-099
D01580	1	BACC45FN10A5S RECP	81205	1	21-45-11 225/200/L28	115-199
D01582	1	BACC45FT10A5S PLUG	81205	1	21-45-11 263/193/L47	001-099
D01582	1	BACC45FT10A5S PLUG	81205	1	21-45-11 263/200/L37	115-199
D01583		BKAE67405-54-40 PLUG PLATE ASSY-	81205	1	34-45-01 E002-01/ /	001-099
D01583		BKAE67405-54-40 PLUG PLATE ASSY-	81205	1	34-45-01 E2-1/ /	115-199
D01583A		PARTAOFD01583 PLUG-		0	34-45-01 E002-01/ /	001-099
D01583A		PARTAOFD01583 PLUG-		1	34-45-01 E2-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D01500

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01583B		PARTBOFD01583 PLUG-		0	34-45-01 E002-01/ /	001-099
D01583B		PARTBOFD01583 PLUG-		1	34-45-01 E2-1/ /	115-199
D01583C		PARTCOFD01583 PLUG-		0	34-45-01 E002-01/ /	001-099
D01583C		PARTCOFD01583 PLUG-		1	34-45-01 E2-1/ /	115-199
D01583D		PARTDOFD01583 PLUG-		0	34-45-01 E002-01/ /	001-099
D01583D		PARTDOFD01583 PLUG-		0	34-45-01 E2-1/ /	115-199
D01583E		PARTEOFD01583 PLUG-		0	34-45-01 E002-01/ /	001-099
D01583E		PARTEOFD01583 PLUG-		0	34-45-01 E2-1/ /	115-199
D01583F		PARTFOFD01583 PLUG-		0	34-45-01 E002-01/ /	001-099
D01583F		PARTFOFD01583 PLUG-		0	34-45-01 E2-1/ /	115-199
D01584	1	BACC45FN10A5S RCPT	81205	1	21-45-11 230/200/R047	001-099
D01584	1	BACC45FN10A5S RCPT	81205	1	21-45-11 225/200/R28	115-199
D01585		KA-59-439-M06 PLUG		1	34-45-02 420/290/010	ALL
D01586	1	BACC45FT10A5S PLUG	81205	1	21-45-11 260/193/R047	001-099
D01586	1	BACC45FT10A5S PLUG	81205	1	21-45-11 263/202/R58	115-199
D01587		KA-59-439-M06 PLUG		1	34-45-02 420/290/010	ALL
D01588	1	BACC45FT20A41S PLUG	81205	1	76-11-12 P008-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D01500

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01589		KA-59-439-M06 PLUG		1	34-45-02 420/290/010	ALL
D01590	1	BACC65L41 PLUG	81205	1	26-11-21 P54/ /	ALL
D01591		KA-59-439-M06 PLUG		1	34-45-02 420/290/010	ALL
D01592	1	BACC65L41 PLUG	81205	1	26-11-21 P54/ /	ALL
D01593		KA-59-438-M06 PLUG		1	34-45-02 460/140/000	ALL
D01594	1	BACC45FT20A41S6 PLUG	81205	1	76-11-11 P008-00/ /	ALL
D01595		KA-59-438-M06 PLUG		1	34-45-02 460/140/000	ALL
D01596	1	BACC65L41 PLUG	81205	1	26-11-11 P54/ /	ALL
D01597		KA-59-438-M06 PLUG		1	34-45-02 460/140/000	ALL
D01598	1	BACC65L41 PLUG	81205	1	26-11-11 P54/ /	ALL
D01599		KA-59-438-M06 PLUG		1	34-45-02 460/140/000	ALL

EQUIPMENT LIST

D280N032

Section D01500
Page 4 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01600	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-12-11 P037-00/ /	001-099
D01600	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-12-11 P37/ /	115-199
D01602	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-31 P037-00/ /	001-099
D01602	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-31 P37/ /	115-199
D01603		BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	23-32-02 P037-00/ /	001-099
D01603		BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	23-32-02 P37/ /	115-199
D01604	1	BACC63BN14C7S PLUG	81205	1	36-11-31 908/155/R44	001-008, 115-199
D01606	1	BACC63BP10A5SNL PLUG	81205	1	36-21-11 916/164/L036	115-199
D01606 T		BACC10HG10 CABLE CLAMP	81205	1	36-21-11 */*/	115-199
D01608	1	BACC63BP10A5SNL PLUG	81205	1	36-21-11 925/150/R043	115-199
D01608 T		BACC10HG10 CABLE CLAMP	81205	1	36-21-11 */*/	115-199
D01610	1	BACS16W1A RELAY SOCKET (PLATE 'B')	81205	1	36-11-41 P37/ /	001-099
D01610	1	BACS16W1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-41 P37/ /	115-199
D01612	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-41 P37/ /	ALL
D01614	1	BACS16AF1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-41 P37/ /	ALL
D01616	1	BACC63BN14B7S PLUG	81205	1	36-12-21 1876/220/L030	001-099
D01616	1	BACC63BN14B7S PLUG	81205	1	36-12-21 1876/220/L30	115-199

EQUIPMENT LIST

D280N032

Section D01600

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01626	1	BACC45FT18A8S PLUG-	81205	1	21-58-13 520/175/L057	ALL
D01628	1	BACC45FT18B8S PLUG	81205	1	21-58-13 520/192/L052	001-099
D01628	1	BACC45FT18B8S PLUG	81205	1	21-58-13 520/175/L040	115-199
D01638	1	BACC45FT10A5S8 PLUG	81205	1	21-44-11 1200/174/R038	ALL
D01640	1	BACC45FT14A12S PLUG	81205	1	21-31-11 1195/175/L015	ALL
D01642	1	BACC45FT14D7S PLUG	81205	1	21-44-11 1190/180/R020	ALL
D01644	1	BACC63BV14B7SN RCPT	81205	1	36-11-11 PPS183/ /	ALL
D01644 T		BACC10HD14A CABLE CLAMP	81205	1	36-11-11 PPS183/ /	ALL
D01650	1	BACC63CD24-22S RCPT-	81205	1	25-31-11 AB0317/ /	ALL
D01652	1	BACC45FN12-12S RCPT-	81205	1	33-27-11 314/295/R007	001-099
D01654	1	BACC63CD24-22S RCPT-	81205	1	25-31-13 385/295/R27	001-099
D01658	1	BACC63CD24-22S RCPT-	81205	1	25-31-21 690/295/R35	001-099
D01658	1	BACC63CD24-22S RCPT-	81205	1	25-31-21 690/295/R035	115-199
D01660	1	BACC45FN12-12S6 RCPT-	81205	1	33-27-21 690/295/R035	001-099
D01660	1	BACC45FN12-12S6 RCPT-	81205	1	25-31-21 690/295/R35	115-199
D01662	1	BACC63CD20-4S RCPT-	81205	1	25-31-23 750/298/R25	115-199
D01666	1	BACC63CD24-22S RCPT-	81205	1	25-31-31 1624/ /	001-099

EQUIPMENT LIST

D280N032

Section D01600

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01672	1	BACC45FT14D4P PLUG	81205	1	24-33-11 231/150/20	001-099
D01672	1	BACC45FT14D4P PLUG	81205	1	24-33-11 239/170/L20	115-199
D01678	1	BACS16W1 RELAY SOCKET	81205	1	24-33-11 P006-00/ /	ALL
D01679	1	KA-59-304 PLUG- COAX	91836	1	34-53-21 E003-02/ /	001-099
D01679	1	KA-59-304 PLUG-COAX	91836	1	34-53-21 E3-2/ /	115-199
D01680	1	BACC45FT14A12S RELAY SOCKET	81205	1	24-33-11 P6/ /	ALL
D01681	1	KA-59-304 PLUG- COAX	91836	1	34-55-21 E003-02/ /	001-099
D01681	1	KA-59-304 PLUG-COAX	91836	1	34-55-21 E3-2/ /	115-199
D01682	1	BACS16X3A RELAY SOCKET-	81205	1	24-33-11 P6/ /	ALL
D01683	1	KA-59-277 PLUG- COAX	91836	1	34-45-02 E003-02/ /	001-099
D01683	1	KA-59-277 PLUG-COAX	91836	1	34-45-02 E3-2/ /	115-199
D01685	1	KA-59-392-M06 PLUG-	91836	1	34-53-11 E003-02/ /	ALL
D01688	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1065/184/R075	ALL
D01688 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 1065/184/R075	ALL
D01690	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1065/184/R075	ALL
D01690 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 1065/184/R075	ALL
D01692	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1065/184/R075	ALL

EQUIPMENT LIST

D280N032

Section D01600

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01692 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 1065/184/R75	ALL
D01694	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1065/184/R075	ALL
D01694 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 1065/207/R075	ALL
D01696	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1078/184/R004	ALL
D01696 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 1078/184/R004	ALL
D01698	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1078/184/R004	ALL
D01698 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-11 1078/184/R004	ALL

EQUIPMENT LIST

D280N032

Section D01600
Page 4 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01702	1	BACC63BP22A19SNL PLUG	81205	1	27-58-11 IRSS585/ /	ALL
D01702 T		BACC10HG22 CABLE CLAMP	81205	1	27-58-11 */ /	ALL
D01708	1	BACC63BP18A8SNL PLUG	81205	1	27-81-11 FSS122/ /	ALL
D01708 T		BACC10HG18 CABLE CLAMP	81205	1	27-81-11 FSS122/ /	ALL
D01710	1	BACC63BP16A10SNL PLUG	81205	1	27-51-21 0880/165/L038	ALL
D01710 T		BACC10HG16A CABLE CLAMP	81205	1	27-51-21 */*/	ALL
D01712	1	BACC63BP14A7S6L PLUG	81205	1	27-81-11 FSS115/WRP/	ALL
D01712 T		BACC10HG14 CABLE CLAMP	81205	1	27-81-11 FSS115/ /	ALL
D01714	1	BACC63BP18A8SNL PLUG	81205	1	27-51-11 1063/184/L009	ALL
D01714 T		BACC10HF18 CABLE CLAMP	81205	1	27-51-11 */*/	ALL
D01716	1	BACC63BP16A10SNL PLUG	81205	1	27-51-21 1060/190/L020	ALL
D01716 T		BACC10HG16 CABLE CLAMP	81205	1	27-51-21 */*/	ALL
D01718	1	MS90362-3 RCPT- EXT PWR	284N1412 96906	1	24-41-11 P030-00/ /	ALL
D01718 T		287N5001-13 SPECIAL WIRE-WIRE TYPE ZC-	06090	1	24-41-11 P030-00/ /	ALL
D01726	1	BACS16W5A RELAY SOCKET (PLATE 'A')	81205	1	76-11-21 P36/ /	ALL
D01728	1	BACC45FT20A41S PLUG	81205	1	24-22-11 P031-00/ /	ALL
D01730	1	BACC45FT20A41S PLUG	81205	1	24-22-12 P031-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D01700

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01732	1	BACC45FT20A41S PLUG	81205	1	24-27-21 P034-00/ /	ALL
D01734	1	BACC45FT20D41S7 PLUG	81205	1	24-41-11 P034-00/ /	ALL
D01738	1	BACC63BP12A3S9L PLUG	81205	1	27-51-31 1046/186/L022	001-099
D01738	1	BACC63BP12A3S9L PLUG	81205	1	27-51-31 1046/186/L22	115-199
D01738 T		BACC10HG12 CABLE CLAMP	81205	1	27-51-31 */*/	ALL
D01742	1	BACC63BN10-5S PLUG	81205	1	27-28-11 FS150/RS/L002	ALL
D01742 T		MS27291-1 CABLE CLAMP	96906	1	27-28-11 */*/	ALL
D01744	1	BACC45FT18A14S PLUG	81205	1	27-11-11 P008-00/ /	001-099
D01744	1	BACC45FT18A14S RCPT	81205	1	27-11-11 P8/ /	115-199
D01746	1	BACC63BP18A14SNL PLUG	81205	1	27-28-13 FIN106/RS/L002	ALL
D01746 T		BACC10HG18 CABLE CLAMP	81205	1	27-28-13 */*/	ALL
D01748	1	BACC45FT10A5S RCPT.	81205	1	30-43-11 P001-03/ /	001-099
D01748	1	BACC45FT10A5S RCPT.	81205	1	30-43-11 P1-3/ /	115-199
D01750	1	BACC45FT14D7S PLUG	81205	1	30-42-11 P1-3/ /	ALL
D01756	1	BACC63BN10-5S PLUG	81205	1	28-42-11 FSS175-/ /	ALL
D01756 T		MS27559-2 CABLE CLAMP	96906	1	28-42-11 */*/	ALL
D01758	1	BACC63BN10-5S PLUG	81205	1	28-42-11 IRSS180/ /	ALL

EQUIPMENT LIST

D280N032

Section D01700

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01758 T		MS27559-2 CABLE CLAMP	96906	1	28-42-11 IRSS180/ /	001-099
D01758 T		MS27559-2 CABLE CLAMP	96906	1	28-42-11 */ /	115-199
D01760	1	BACC63BN10C5S7 PLUG	81205	1	28-42-11 1040/183/L010	ALL
D01762	1	BACC63BP14A4SNL PLUG-	81205	1	28-22-11 FSS173/ /	ALL
D01762 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-11 FSS173/ /	ALL
D01764	1	BACC63BP14A4SNL PLUG	81205	1	28-22-11 IRSS185/ /	ALL
D01764 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-11 IRSS185/ /	001-099
D01764 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-11 */ /	115-199
D01766	1	BACC63BP14A4SNL PLUG	81205	1	28-22-11 1040/175/L012	ALL
D01766 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-11 */ */	ALL
D01774	1	BACC63CE14S-5S PLUG	81205	1	29-11-11 N252/147/L6	ALL
D01774 T	1	BACC10HV14 CABLE CLAMP	81205	1	29-11-11 N252/147/L6	ALL
D01776	1	BACC45FT18D8S PLUG-	81205	1	24-32-11 E1-2/ /	ALL
D01780	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D01782	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D01784	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D01786	1	BACS16W1 RELAY SOCKET	81205	1	24-31-11 P006-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D01700

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01792	1	MS25182-2 PLUG	96906	1	24-31-11 247/160/R035	ALL
D01792 T		BACC10GL18 CABLE CLAMP	81205	1	24-31-11 */*/	ALL
D01792 U	1	287N1048-1 BATTERY BUS FEEDER CONDUIT	81205	1	24-31-11 */*/	ALL
D01792 U	2	209775-DI-0730 BATTERY BUS FEEDER CONDUIT	81205	1	24-31-11 */*/	ALL
D01792 V		186057-FK11K3 CONDUIT ADAPTER	30463	1	24-31-11 */*/	ALL
D01792 W		NAS43DD0-8 SPACER	80205	4	24-31-11 */*/	ALL
D01792 X		287N4142-16 CONDUIT BRACKET ASSY	81205	1	24-31-11 */*/	ALL
D01794	1	BACC45FT12A12P PLUG	81205	1	24-31-11 247/150/R35	001-099
D01794	1	BACC45FT12A12P PLUG	81205	1	24-31-11 247/155/R35	115-199
D01796	1	BACC66H21C1501 PLUG PLATE ASSY	81205	1	49-14-11 E6-2/ /	001-099
D01796	1	BACC66H21C1501 PLUG PLATE ASSY	81205	1	49-14-11 E6-4/ /	115-199
D01796A	1	PARTAOFD01796 PLUG		0	49-14-11 E6-2/ /	001-099
D01796A	1	PARTAOFD01796 PLUG		0	49-14-11 E6-4/ /	115-199
D01796B	1	PARTBOFD01796 PLUG		0	49-14-11 E6-2/ /	001-099
D01796B	1	PARTBOFD01796 PLUG		0	49-14-11 E6-4/ /	115-199
D01796C	1	PARTCOFD01796 PLUG		0	49-14-11 E6-2/ /	001-099
D01796C	1	PARTCOFD01796 PLUG		0	49-14-11 E6-4/ /	115-199

EQUIPMENT LIST

D280N032

Section D01700
Page 4 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01802	1	BACC63BP22A19S6L PLUG	81205	1	27-58-11 WS585/ /	ALL
D01802 T		BACC10HG22 CABLE CLAMP	81205	1	27-58-11 */ */	ALL
D01805	1	BACC63BP18A14S6L PLUG-	81205	1	27-51-41 OSS818/ /	ALL
D01805 T		BACC10HF18 CABLE CLAMP-	81205	1	27-51-41 */ /	ALL
D01806	1	BACC63BP14A7SNL PLUG	81205	1	27-51-11 1060/183/L020	ALL
D01806 T		BACC10HG14 CABLE CLAMP	81205	1	27-51-11 */ */	ALL
D01809	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	31-31-42 P37/ /	001-099
D01810	1	BACC45FN12A12S RCPT	81205	1	27-51-41 P010-00/ /	ALL
D01814	1	BACS16W5A RELAY SOCKET (PLATE 'C')	81205	1	76-11-21 P37/ /	ALL
D01816	1	BACC45FT20A41S PLUG	81205	1	24-21-21 P032-00/ /	ALL
D01818	1	BACC45FT20A41S PLUG	81205	1	24-22-22 P032-00/ /	ALL
D01822	1	BACC65L66 PLUG	81205	1	26-11-11 P54/ /	ALL
D01823	1	MS3126F20-41S PLUG	81205	1	31-31-02 P008-1/ /	001-099
D01824	1	BACC45FT10A5S RCPT	81205	1	30-43-11 297/220/R5	001-099
D01824	1	BACC45FT10A5S RCPT	81205	1	30-43-11 P1-3/ /	115-199
D01825	1	BACC45FN12A12S7 RCPT-ALT STAB TRIM	81205	1	27-41-31 215/190/L19	ALL
D01826	1	BACC45FT14D7S PLUG	81205	1	30-42-11 205.37/221/R3.2	ALL

EQUIPMENT LIST

D280N032

Section D01800

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01827	1	BACC45FN12A12S6 RCPT-ALT STAB TRIM	81205	1	27-41-31 P10/190/L19	ALL
D01828	1	BACC63BN10B5S7 PLUG	81205	1	28-42-11 1040/183/R011	ALL
D01829	1	BACC63BP16A10SNL PLUG-	81205	1	27-41-11 1725/185/L17	ALL
D01829 T		BACC10HF16A CABLE CLAMP	81205	1	27-41-11 1725/185/L17	ALL
D01830	1	BACC63BN10-5S PLUG	81205	1	28-42-11 ISS175/ /	ALL
D01830 T		MS27559-2 CABLE CLAMP	96906	1	28-42-11 */ */ *	ALL
D01831	1	BACC63BP16A10S6L PLUG-	81205	1	27-41-11 1729/187/L22	ALL
D01831 T		BACC10HF16A CABLE CLAMP	81205	1	27-41-11 1729/187/L22	ALL
D01832	1	BACC63BN10-5S PLUG	81205	1	28-42-11 IRSS182/ /	ALL
D01832 T		MS27559-2 CABLE CLAMP	96906	1	28-42-11 */ */ *	ALL
D01833	1	BACC63BP16A10SNL PLUG-	81205	1	27-41-21 1729/188/R19	ALL
D01833 T		BACC10HF16A CABLE CLAMP	81205	1	27-41-21 1729/188/R19	ALL
D01834	1	BACC63BP14A4SNL RCPT-	81205	1	28-22-11 ISS173/ /	ALL
D01834 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-11 */ */ *	ALL
D01835	1	BACC63BP16A10S6L PLUG-	81205	1	27-41-21 1729/188/R14	ALL
D01835 T		BACC10HF16A CABLE CLAMP-	81205	1	27-41-21 */ /	ALL
D01836	1	BACC63BP14A4SNL PLUG	81205	1	28-22-11 IRSS182/ /	ALL

EQUIPMENT LIST

D280N032

Section D01800

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01836 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-11 */*/	ALL
D01837	1	BACC63BP18A31S8L PLUG-	81205	1	27-41-11 1776/190/L20	ALL
D01837 T		BACC10HF18A CABLE CLAMP	81205	1	27-41-11 1776/190/L20	ALL
D01838	1	BACC63BP14A4SNL PLUG	81205	1	28-22-11 1040/175/R012	ALL
D01838 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-11 1040/175/R012	ALL
D01841	1	BACC63BP18A31S8L PLUG-	81205	1	27-48-21 1776/200/R011	ALL
D01841 T		BACC10HF18A CABLE CLAMP	81205	1	27-48-21 */*/	ALL
D01843	1	BACC63BP18A31S8L PLUG-	81205	1	27-41-21 1780/198/R16	ALL
D01843 T		BACC10HF18A CABLE CLAMP	81205	1	27-41-21 1780/198/R16	ALL
D01845	1	BACC63BP10A5SNL PLUG-	81205	1	27-41-21 1726/184/R24	ALL
D01845 T		BACC10HG10A CABLE CLAMP	81205	1	27-41-21 1726/184/R24	ALL
D01846	1	BACC63CE14SA5S PLUG	81205	1	29-11-21 PPS241/147/L6	ALL
D01847	1	BACC63BP14A15SNL PLUG-	81205	1	27-41-21 1723/185/R28	ALL
D01847 T		BACC10HF14A CABLE CLAMP	81205	1	27-41-21 1723/185/R28	ALL
D01849	1	BACC63BP10A5SNL PLUG-	81205	1	27-41-11 1726/184/L12	ALL
D01849 T		BACC10HG10A CABLE CLAMP	81205	1	27-41-11 1726/184/L12	ALL
D01850	1	BACC66F11C9801 PLUG PLATE ASSY-	81205	1	24-21-41 E5-1/ /	001-099

EQUIPMENT LIST

D280N032

Section D01800

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01850	1	BACC66F11C9801 PLUG PLATE ASSY-	81205	1	24-21-41 E5-3/ /	115-199
D01850A	1	PARTAOFD01850 PLUG		1	24-21-41 E5-1/ /	001-099
D01850A	1	PARTAOFD01850 PLUG		0	24-21-41 E5-3/ /	115-199
D01850B	1	PARTBOFD01850 PLUG		1	24-21-41 E5-1/ /	001-099
D01850B	1	PARTBOFD01850 PLUG		0	24-21-41 E5-3/ /	115-199
D01850C	1	PARTCOFD01850 PLUG		1	24-21-41 E5-1/ /	001-099
D01850C	1	PARTCOFD01850 PLUG		0	24-21-41 E5-3/ /	115-199
D01851	1	BACC63BP14A15SNL PLUG-	81205	1	27-41-11 1725/175/L20	ALL
D01851 T		BACC10HF14A CABLE CLAMP	81205	1	27-41-11 1725/175/L20	ALL
D01852	1	BACC45FT10A5P PLUG	81205	1	24-41-11 P034-00/ /	ALL
D01853	1	BACC45FT12D12S PLUG	81205	1	23-32-01 395/295/R005	001-099
D01854	1	BACC45FT12A12S PLUG	81205	1	24-31-11 255/150/R40	ALL
D01856	1	BACC45FT12A12S PLUG-	81205	1	24-32-11 P006-00/ /	ALL
D01857	1	BACC45FT12-12S PLUG	81205	1	23-32-01 954/295/R0R5	001-099
D01859	1	BACC45FT12D12S PLUG	81205	1	23-32-01 1100/295/R005	001-099
D01860	1	BACC45FT18D8S PLUG	81205	1	24-32-11 E001-01/ /	ALL
D01861	1	BACC45FT12-12S PLUG	81205	1	23-32-01 1310/ /	001-099

EQUIPMENT LIST

D280N032

Section D01800

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01863	1	BACC45FT12-12S PLUG	81205	1	23-32-01 657/ /	001-099
D01864	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	ALL
D01865	1	BACC45FT12-12S PLUG	81205	1	23-32-01 799/ /	001-099
D01866	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	ALL
D01868	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	ALL
D01869	1	BACC45FT12-12S PLUG	81205	1	23-32-01 1460/296/R015	001-099
D01870	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D01870	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D01872	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D01872	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D01874	1	BACC63BN10C5S PLUG	81205	1	27-11-11 1050/176/L017	ALL
D01876	1	BACC45FT12A12S RCPT	82105	1	27-28-13 P008-00/ /	001-099
D01876	1	BACC45FT12A12S RCPT	82105	1	27-28-13 P8/ /	115-199
D01878	1	SO-1057-8912 RELAY SOCKET-	35344	1	24-33-11 P6/ /	ALL
D01886	1	BACS16W1 RELAY SOCKET	81205	1	24-31-41 E6 RLY/PNL/	ALL
D01888	1	BACC45FT14D12S PLUG-	81205	1	24-31-41 E006-02/ /	001-099
D01888	1	BACC45FT14D12S PLUG	81205	1	24-31-41 E6/ /	115-199

EQUIPMENT LIST

D280N032

Section D01800

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01890	1	BACC45FT12A12P PLUG-	81205	1	24-31-41 E006-00/ /	001-099
D01890	1	BACC45FT12A12P PLUG-	81205	1	24-31-41 E6/ /	115-199
D01891	1	L14TL12P6NA PLUG	09922	1	23-32-01 453/ /	001-099
D01893	1	L14TL12P6NA PLUG	09922	1	23-32-01 1290/296/L015	001-099
D01896	1	MS25182-2 PLUG	96906	1	24-31-41 E6/ /	ALL
D01896 T	1	287N5001-15 JUMPER CABLE ASSY-	81205	2	24-31-41 E6/ /	115-199

EQUIPMENT LIST

D280N032

Section D01800
Page 6 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01900	1	51444-130 PLUG	31759	1	26-15-11 1932/253/R018	ALL
D01902	1	51444-129 PLUG	31759	1	26-15-11 1932/253/L018	ALL
D01904	1	51444-130 PLUG	31759	1	26-15-11 1932/253/L018	ALL
D01906	1	51444-129 PLUG	31759	1	26-15-11 1932/253/R018	ALL
D01908	1	51444-129 PLUG	31759	1	26-15-11 1945/225/R001	ALL
D01910	1	51444-130 PLUG	31759	1	26-15-11 1891/225/R001	ALL
D01912	1	51444-129 PLUG	31759	1	26-15-11 1891/233/R001	ALL
D01914	1	51444-130 PLUG	31759	1	26-15-11 1945/233/R001	ALL
D01916	1	BACC65L41 PLUG	81205	1	26-15-11 P54/ /	ALL
D01918	1	BACC65L41 PLUG	81205	1	26-15-11 P54/ /	ALL
D01923	9	BACS16W1A RELAY SOCKET (PLATE 'A') (SB 34-0020)	286N1270 81205	1	34-25-12 P37/ /	002
D01925	1	BACS16W5A RELAY SOCKET	81205	1	24-25-11 P71/ /	003-099
D01926	1	BACC63BP10A5S10L PLUG	81205	1	21-51-11 950/156/L61	ALL
D01926 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-11 */*/	ALL
D01928	1	BACC63BP10A5S8L PLUG	81205	1	21-51-11 950/156/L061	001-099
D01928	1	BACC63BP10A5S8L PLUG	81205	1	21-51-11 950/156/L61	115-199
D01928 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-11 */*/	ALL

EQUIPMENT LIST

D280N032

Section D01900

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01930	1	BACC63BP10A5SNL PLUG	81205	1	21-51-11 950/156/L061	001-099
D01930	1	BACC63BP10A5SNL PLUG	81205	1	21-51-11 950/156/L61	115-199
D01930 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-11 */*/	ALL
D01932	1	BACC63BP10A5S10L PLUG	81205	1	21-51-21 940/147/R061	ALL
D01932 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-21 */*/	ALL
D01934	1	BACC63BP10A5S8L PLUG	81205	1	21-51-21 940/149/R061	ALL
D01934 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-21 */*/	ALL
D01936	1	BACC63BP10A5SNL PLUG	81205	1	21-51-21 950/152/R061	ALL
D01936 T		BACC10HF10 CABLE CLAMP	81205	1	21-51-21 */*/	ALL
D01938	1	BACC63CD32-17S RCPT-	81205	1	25-31-33 1700/298/L005	001-099
D01938	1	BACC63CD32-17S RCPT-	81205	1	25-31-33 1693/299/	115-199
D01940	1	BACC45FN12-12S RCPT-	81205	1	25-31-33 1700/299/R1	001-099
D01940	1	BACC45FN12-12S RCPT-	81205	1	25-31-33 AA1698/ /	115-199
D01946	1	35303-77 PLUG	73168	1	26-18-11 FSS300/ /	ALL
D01948	1	35303-75 PLUG	73168	1	26-18-11 FSS90/169/L	ALL
D01950	1	35303-75 PLUG	73168	1	26-18-11 FSS300/169/L	ALL
D01952	1	35303-77 PLUG	73168	1	26-18-11 FSS90/169/L	ALL

EQUIPMENT LIST

D280N032

Section D01900

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01954	1	35303-77 PLUG	73168	1	26-18-11 920/155/R35	ALL
D01956	1	35303-75 PLUG	73168	1	26-18-11 915/160/L25	ALL
D01958	1	35303-75 PLUG	73168	1	26-18-11 920/155/R35	ALL
D01960	1	35303-77 PLUG	73168	1	26-18-11 915/160/L25	ALL
D01962	1	35303-77 PLUG	73168	1	26-18-11 1164/198/R007	ALL
D01964	1	35303-75 PLUG	73168	1	26-18-11 1053/148/R002	ALL
D01966	1	35303-75 PLUG	73168	1	26-18-11 1164/198/R007	ALL
D01968	1	35303-77 PLUG	73168	1	26-18-11 1053/148/R002	ALL
D01970	1	35303-77 PLUG	73168	1	26-18-11 1700/199/L045	001-099
D01970	1	35303-77 PLUG	73168	1	26-18-11 1691/180/L45	115-199
D01972	1	35303-75 PLUG	73168	1	26-18-11 1187/200/R016	ALL
D01974	1	35303-75 PLUG	73168	1	26-18-11 1700/199/L045	001-099
D01974	1	35303-75 PLUG	73168	1	26-18-11 1691/180/L45	115-199
D01976	1	35303-77 PLUG	73168	1	26-18-11 1187/200/R016	ALL
D01978	1	35303-75 PLUG	73168	1	26-18-11 1720/182/L023	001-099
D01978	1	35303-75 PLUG	73168	1	26-18-11 1723/182/L43	115-199
D01980	1	35303-77 PLUG	73168	1	26-18-22 1862/214/L023	001-099

EQUIPMENT LIST

D280N032

Section D01900

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01980	1	35303-77 PLUG	73168	1	26-18-11 1862/240/L25	115-199
D01982	1	35303-77 PLUG	73168	1	26-18-11 1728/182/L033	001-099
D01982	1	35303-77 PLUG	73168	1	26-18-11 1728/182/L33	115-199
D01984	1	35303-75 PLUG	73168	1	26-18-11 1862/214/L023	001-099
D01984	1	35303-75 PLUG	73168	1	26-18-11 1862/220/L25	115-199
D01986	1	35303-77 PLUG	73168	1	26-18-21 FSS300/ /	ALL
D01988	1	35303-75 PLUG	73168	1	26-18-21 ISS90/169/R	ALL
D01990	1	35303-75 PLUG	73168	1	26-18-21 FSS300/169/R	ALL
D01992	1	35303-77 PLUG	73168	1	26-18-21 FSS90/ /	ALL
D01994	1	35303-77 PLUG	73168	1	26-18-20 1011/160/R062	ALL
D01996	1	35303-77 PLUG	73168	1	26-18-21 923/160/R047	ALL
D01998	1	35303-75 PLUG	73168	1	26-18-21 1011/160/R062	ALL

EQUIPMENT LIST

D280N032

Section D01900
Page 4 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02003	9	KA-59-324 PLUG-RT ANGLE GPS ANT-L	81205	1	34-58-11 690/300/L005	115-199
D02009	9	KA-59-324 PLUG-RT ANGLE GPS ANT-R	81205	1	34-58-21 690/300/R005	115-199
D02020	1	BACS16AG1 RELAY SOCKET	81205	1	28-22-21 P33/ /	ALL
D02022	1	BACC45FS14B7S PLUG	81205	1	28-22-21 IRSS265/ /	ALL
D02026	1	35303-75 PLUG	73168	1	26-18-21 923/155/R047	ALL
D02028	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1070/184/L004	ALL
D02028 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-11 */*/*	ALL
D02030	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1078/184/L004	ALL
D02030 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-11 */*/*	ALL
D02032	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1065/187/L062	ALL
D02032 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 */*/*	ALL
D02034	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1065/187/L062	ALL
D02034 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 */*/*	ALL
D02036	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1065/187/L062	ALL
D02036 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 */*/*	ALL
D02038	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 1065/187/L062	ALL
D02038 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 */*/*	ALL

EQUIPMENT LIST

D280N032

Section D02000

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02040	1	BACC63BP12A3SNL PLUG	81205	1	32-42-14 INBD/FWD/R/H	ALL
D02040 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-14 */*/*	ALL
D02042	1	BACC63BP12A3SNL PLUG	81205	1	32-42-11 OUTBD/FWD/R/H	ALL
D02042 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-11 */*/*	ALL
D02044	1	BACC63BP12A3SNL PLUG	81205	1	32-42-14 INBD/AFT/R/H	ALL
D02044 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-14 */*/*	ALL
D02046	1	BACC63BP12A3SNL PLUG	81205	1	32-42-14 OUTBD/AFT/R/H	ALL
D02046 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-14 */*/*	ALL
D02048	1	BACC63BP12A3SNL PLUG	81205	1	32-42-14 OUTBD/FWB/L/H	ALL
D02048 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-14 */*/*	ALL
D02050	1	BACC63BP12A3SNL PLUG	81205	1	32-42-14 INBD/FWD/L/H	ALL
D02050 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-14 */*/*	ALL
D02052	1	BACC63BP12A3SNL PLUG	81205	1	32-42-14 OUTBD/AFT/L/H	ALL
D02052 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-14 */*/*	ALL
D02054	1	BACC63BP12A3SNL PLUG	81205	1	32-42-14 INBD/AFT/L/H	ALL
D02054 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-14 */*/*	ALL
D02064	1	BACS16AG1 RELAY SOCKET	81205	1	28-22-31 P33/ /	001-008, 115-199

EQUIPMENT LIST

D280N032

Section D02000

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02066	1	BACC63BN10-5S PLUG	81205	1	27-18-11 WS652/ /	ALL
D02066 T		MS27291-1 CABLE CLAMP	96906	1	27-18-11 */*/	ALL
D02068	1	BACC63BN10C5S PLUG-	81205	1	27-38-11 ELEV77/RS/	ALL
D02070	1	BACC66F11C9801 PLUG PLATE ASSY	81205	1	24-22-21 E5-2/ /	001-099
D02070	1	BACC66F11C9801 PLUG-	81205	1	24-22-21 E5-2/ /	115-199
D02070A	1	PARTAOFD02070 PLUG-		0	24-22-21 E5-2/ /	ALL
D02070B	1	PARTBOFD02070 PLUG-		0	24-22-21 E5-2/ /	ALL
D02070C	1	PARTCOFD02070 PLUG-		0	21-31-21 E5-2/ /	ALL
D02080	1	BACC65L41 PLUG	81205	1	26-11-22 P54/ /	ALL
D02082	1	BACC45FT14D12S PLUG	81205	1	24-31-11 255/150/L20	001-099
D02082	1	BACC45FT14D12S PLUG	81205	1	24-31-11 247/170/L20	115-199
D02084	1	BACS16AH1 RELAY SOCKET (PLATE 'B')	81205	1	24-51-71 P037-00/ /	001-099
D02084	1	BACS16AH1 RELAY SOCKET (PLATE 'B')	81205	1	24-51-71 P37/ /	115-199
D02086	1	000300-1560 RELAY SOCKET (PLATE 'B')	05574	1	30-31-12 P037-00/ /	001-099
D02086	1	000300-1560 RELAY SOCKET (PLATE 'B')	05574	1	30-31-12 P37/ /	115-199
D02090	1	000300-1560 RELAY SOCKET (PLATE 'B')	05574	1	30-31-12 P037-00/ /	001-099
D02090	1	000300-1560 RELAY SOCKET (PLATE 'B')	05574	1	30-31-12 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D02000

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02094	1	000300-1560 RELAY SOCKET (PLATE 'A')	05574	1	30-32-11 P037-00/ /	001-099
D02094	1	000300-1560 RELAY SOCKET (PLATE 'A')	05574	1	30-32-11 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D02000
Page 4 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02104	1	BACC63BN10-5S PLUG	81205	1	27-18-11 WS652/ /	ALL
D02104 T		MS27291-1 CABLE CLAMP	96906	1	27-18-11 WS652/ /	001-099
D02104 T		MS27291-1 CABLE CLAMP	96906	1	27-18-11 */ /	115-199
D02106	1	BACC63BN10C5S PLUG-	81205	1	27-38-11 ELEV77/RS/	ALL
D02108	1	BACC66F11C9801 PLUG PLATE ASSY-	81205	1	24-11-11 E5-1/ /	ALL
D02108A	1	PARTAOFD02108 PLUG		0	24-11-11 E5-1/ /	ALL
D02108B	1	PARTBOFD02108 PLUG		0	24-11-11 E5-1/ /	ALL
D02108C	1	PARTCOFD02108 PLUG		0	24-11-11 E5-1/ /	ALL
D02110	1	BACC65L41 PLUG	81205	1	26-11-12 P54/ /	ALL
D02114	1	000300-1560 RELAY SOCKET	05574	1	30-31-11 P33/ /	ALL
D02116	1	000300-1560 RELAY SOCKET	05574	1	30-31-11 P33/ /	ALL
D02120	1	000300-1560 RELAY SOCKET	05574	1	30-31-11 P33/ /	001-099
D02120	1	000300-1560 RELAY SOCKET	05574	1	30-32-11 P33/ /	115-199
D02122	1	MS3459KS14S-5S PLUG	14283	1	26-11-12 PPS165/ /	ALL
D02122 T		BACC10HD14A CABLE CLAMP	81205	1	26-11-12 / /	ALL
D02122 U		5100-179-16-1 CONTACT	14283	2	26-11-12 / /	ALL
D02126	1	KA-59-392-M06 PLUG-	91836	1	34-53-11 E003-03/ /	ALL

EQUIPMENT LIST

D280N032

Section D02100

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02128	1	KA-59-304 PLUG- COAX, RT ANGLE	91836	1	34-55-11 E3-3/ /	ALL
D02138	1	KA-59-304 PLUG- COAX, RT ANGLE	91836	1	34-53-11 E3-3/ /	001-099
D02138	1	KA-59-304 PLUG- COAX, RT ANGLE	91836	1	34-55-11 E3-3/ /	115-199
D02140	1	BACS16AG1 RELAY SOCKET	81205	1	28-22-21 P33/ /	ALL
D02142	1	BACC45FS14B7S PLUG	81205	1	28-22-21 IRSS265/ /	ALL
D02144	1	BACC63BP14A7SNL PLUG	81205	1	28-22-31 1040/184/L013	001-008, 115-199
D02144 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-31 1040/184/L013	001-008, 115-199
D02146	1	BACC45FN18D31S RCPT	81205	1	73-21-11 P010-00/ /	ALL
D02148	1	BACC45FN18D31S7 RCPT	81205	1	73-21-21 P010-00/ /	ALL
D02150	1	BACC63CE24-22S PLUG	81205	1	29-11-12 1065/160/L063	ALL
D02150 T		BACC10HV-24 CABLE CLAMP	81205	1	29-11-12 1065/160/L063	ALL
D02152	1	BACC63BP12A3S10L PLUG	81205	1	29-32-11 PPS226/ /	ALL
D02152 T		BACC10HF12A CABLE CLAMP	81205	1	29-32-11 */ /	ALL
D02154	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	76-11-11 P36/ /	ALL
D02158	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	76-11-11 P36/ /	ALL
D02162	1	BACC45FT10A5P PLUG	81205	1	24-23-11 P031-00/ /	ALL
D02164	1	BACC45FT10A5P PLUG-	81205	1	24-23-10 P006-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D02100

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02166	1	BACC45FT10A5P PLUG	81205	1	24-23-11 P031-00/ /	ALL
D02168	1	BACC45FT10A5P PLUG	81205	1	24-23-12 P031-00/ /	ALL
D02172	1	BACS16AF1 RELAY SOCKET (PLATE 'B')	81205	1	35-21-11 P037-00/ /	001-099
D02172	1	BACS16AF1 RELAY SOCKET (PLATE 'B')	81205	1	35-21-11 P37/ /	115-199
D02178	1	BACS16W5A RELAY SOCKET (PLATE 'B')	81205	1	35-21-11 P037-00/ /	001-099
D02178	1	BACS16W1 RELAY SOCKET (PLATE 'B')	81205	1	35-21-11 P37/ /	115-199
D02180	1	BACS16W5A RELAY SOCKET (PLATE 'B')	81205	1	35-21-11 P037-00/ /	001-099
D02180	1	BACS16W1 RELAY SOCKET (PLATE 'B')	81205	1	35-21-11 P37/ /	115-199
D02182	1	BACS16W1 RECP	81205	1	24-22-12 P031-00/ /	ALL
D02184	1	BACC45FS10D5S6 PLUG (PLATE 'F')	81205	1	35-21-11 P037-00/ /	001-099
D02184	1	BACC45FS10D5S6 PLUG (PLATE 'F')	81205	1	35-21-11 P37/ /	115-199
D02186	1	BACC45FS10D5S PLUG	81205	1	26-21-11 1191/193/R032	ALL
D02188	1	BACC45FT10D5S9 PLUG	81205	1	26-21-11 1191/181/R034	ALL
D02190	1	MS24266R8T3SN PLUG	81205	1	26-21-11 1191/181/R040	ALL
D02190 T	1	GTR21-8CD CABLE CLAMP-	02660	1	26-21-11 1191/185/R48	ALL
D02192	1	BACC45FT12-12S PLUG	81205	1	33-13-11 P1-1/ /	001-099
D02192	1	BACC45FT12-12S PLUG	81205	1	33-13-11 P001-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D02100

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02192 T		BACC10GH12 CABLE CLAMP	81205	1	33-13-11 */*/	ALL
D02198	1	BACC63BP18A8SNL PLUG-	81205	1	33-42-31 P63/ /	001-099
D02198 T		BACC10HF18 CABLE CLAMP	81205	1	33-42-31 P63/ /	001-099

EQUIPMENT LIST

D280N032

Section D02100
Page 4 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02200	1	BACC63BP12A3S10L PLUG	81205	1	29-32-21 230/154/4	ALL
D02200 T		BACC10HF12A CABLE CLAMP	81205	1	29-32-21 230/154/4	ALL
D02202	1	BACC63CE24-22S PLUG	81205	1	29-11-22 1065/160/R063	ALL
D02202 T		BACC10HV-24 CABLE CLAMP	81205	1	29-11-22 */*/	ALL
D02204	1	BACC63CE24-22S PLUG-	81205	1	29-11-31 1250/141/L052	ALL
D02204 T		BACC10HV-24 CABLE CLAMP	81205	1	29-11-31 */*/	ALL
D02206	1	BACC63CE24-22S PLUG-	81205	1	29-11-31 1250/141/L052	ALL
D02206 T		BACC10HV-24 CABLE CLAMP	81205	1	29-11-31 */*/	ALL
D02208	1	BACC45FT16A24S PLUG	81205	1	33-13-12 P001-03/ /	001-099
D02208	1	BACC45FT16A24S PLUG	81205	1	33-13-12 P001-3/ /	115-199
D02210	1	BACC45FT16A24S6 PLUG	81205	1	77-41-11 P1-3/ /	001-099
D02210	1	BACC45FT16A24S6 PLUG	81205	1	77-12-11 P001-3/ /	115-199
D02216	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	76-11-12 P037-00/ /	001-099
D02216	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	76-11-12 P37/ /	115-199
D02220	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	76-11-12 P037-00/ /	001-099
D02220	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	76-11-12 P37/ /	115-199
D02224	1	BACC45FT10A5P PLUG	81205	1	24-23-11 P032-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D02200

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02226	1	BACC45FT10A5P PLUG-	81205	1	24-23-11 P006-00/ /	ALL
D02228	1	BACC45FT10A5P PLUG	81205	1	24-23-11 P034-00/ /	001-099
D02228	1	BACC45FT10A5P PLUG	81205	1	24-23-11 P34/ /	115-199
D02230	1	BACC45FT10A5P PLUG	81205	1	24-23-11 P032-00/ /	ALL
D02232	1	BACC45FT10A5P PLUG	81205	1	24-23-12 P032-00/ /	ALL
D02234	1	BACC45FT10A5P PLUG	81205	1	24-23-12 P034-00/ /	001-099
D02234	1	BACC45FT10A5P PLUG	81205	1	24-23-12 P34/ /	115-199
D02236	1	BACC45FT10A5P PLUG	81205	1	24-23-12 P034-00/ /	001-099
D02236	1	BACC45FT10A5P PLUG	81205	1	24-23-12 P34/ /	115-199
D02238	1	BACC63BP18B14SNL PLUG	81205	1	24-21-41 APU/ /	ALL
D02238 T		BACC10HF18 CABLE CLAMP	81205	1	24-21-41 APU/ /	ALL
D02242	1	BACS16W1 PLUG	81205	1	24-22-22 P032-00/ /	ALL
D02248	1	BACC45FT14D7S PLUG	81205	1	21-43-11 860/189/R058	ALL
D02252	1	BACC45FT10D5S8 PLUG	81205	1	21-43-11 847/170/L040	ALL
D02256	1	BACC63BN14-7S PLUG	81205	1	33-31-11 1178/185/R034	ALL
D02256 T		MS27559-4 CABLE CLAMP	96906	1	33-31-11 1178/185/R34	ALL
D02258	1	BACC45FT14D7S PLUG-	81205	1	33-31-31 1744/275/L32	ALL

EQUIPMENT LIST

D280N032

Section D02200

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02262	1	MS24266R8T3SN PLUG	96906	1	26-22-21 1878/217/R025	001-099
D02262	1	MS24266R8T3SN PLUG	96906	1	26-22-21 1878.20/217/R 25	115-199
D02262 T		MS27291-13 CABLE CLAMP	02660	1	26-22-21 */*/	001-099
D02262 T	1	48-2840 CABLE CLAMP	02660	1	26-22-21 */*/	115-199
D02262 T	2	MS27291-13 CABLE CLAMP	02660	1	26-22-21 */*/	115-199
D02264	1	BACC63BP10A5SNL PLUG	81205	1	26-22-21 1878/217/R025	001-099
D02264	1	BACC63BP10A5SNL PLUG	81205	1	26-22-21 1878/217/R 25	115-199
D02264 T		BACC10HF10 CABLE CLAMP	81205	1	26-22-21 */*/	001-099
D02264 T		BACC10HF10 CABLE CLAMP-	81205	1	26-22-21 */*/	115-199
D02266	1	MS24266R8T3SN PLUG	81205	1	26-21-11 1191/181/R052	ALL
D02266 T	1	GTR21-8CD CABLE CLAMP-	02660	1	26-21-11 1191/185/R48	ALL
D02268	1	BACC45FT10D5S9 PLUG	81205	1	26-21-11 1191/181/R046	ALL
D02270	1	BACC45FS10D5S PLUG	81205	1	26-21-11 1191/193/R044	ALL
D02275	9	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	34-61-16 P036-00/ /	115-199
D02277	9	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	34-61-26 P037-00/ /	115-199
D02279	9	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	34-61-16 P036-00/ /	115-199
D02281	9	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	34-61-26 P037-00/ /	115-199

EQUIPMENT LIST

D280N032

Section D02200

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02283	9	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	34-61-26 P037-00/ /	115-199
D02284	1	BACC45FT10D5S PLUG-	81205	1	35-11-13 0629/190/R058	001-099
D02284	1	BACC45FT10D5S PLUG-	81205	1	35-11-13 630/180/R58	115-199
D02286	1	BACS16W1 RELAY SOCKET-	81205	1	33-37-11 P65/ /	ALL
D02287	1	BACS16W1 RELAY SOCKET	81205	1	33-37-21 E6 RLY/PNL/	ALL
D02290		DPX2DA-26S7S33B-1401 PLUGPLATE ASSY	71468	1	30-41-12 E001-01/ /	ALL
D02290A		PARTAOFD02290 PLUG		0	30-41-12 E001-01/ /	ALL
D02290B		PARTBOFD02290 PLUG		0	30-41-12 E001-01/ /	ALL
D02292	1	BACC63BP18A8S8L RCPT-	81205	1	33-42-12 ISS94/ /	ALL
D02292 T		BACC10HG18 CABLE CLAMP	81205	1	33-42-12 */ */ *	ALL
D02294	1	BACC63BP18A8S8 PLUG-	81205	1	33-42-12 P62/ /	001-099
D02294	1	BACC63BP18A8S8 PLUG-	81205	1	33-42-11 P62/ /	115-199
D02294 T		BACC10HG18A CABLE CLAMP	81205	1	33-42-12 P62/ /	001-099
D02294 T		BACC10HG18A CABLE CLAMP	81205	1	33-42-11 P62/ /	115-199

EQUIPMENT LIST

D280N032

Section D02200

Page 4 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02304		DPX2DA-26S7S33B-1401 PLUG PLATE ASSY	71468	1	30-41-11 E1-2/ /	ALL
D02304A		PARTAOFD02304 PLUG		0	30-41-11 E1-2/ /	ALL
D02304B		PARTBOFD02304 PLUG		0	30-41-11 E1-2/ /	ALL
D02306	1	BACC63BP18A8S8L PLUG-	81205	1	33-42-11 FSS94.5/184/L088	ALL
D02306 T		BACC10HG18 CABLE CLAMP	81205	1	33-42-11 */ */	ALL
D02308	1	BACC63BP18A8S8 PLUG-	81205	1	33-42-11 P063-00/ /	ALL
D02308 T		BACC10HG18A CABLE CLAMP	81205	1	33-42-11 P063-00/ /	ALL
D02318	1	BACC45FT10D5S6 PLUG-	81205	1	52-34-11 590/204/R065	001-099
D02318	1	BACC45FT10D5S6 PLUG-	81205	1	52-34-11 590/204/R65	115-199
D02322	1	BACC45FT10D5S6 PLUG-	81205	1	52-35-11 1420/195/R65	ALL
D02330	1	BACC65L66 PLUG	81205	1	26-11-21 P54/ /	ALL
D02332	1	BACC45FT12A12S PLUG	81205	1	21-31-11 1650/175/L051	ALL
D02334	1	BACC45FT12A12S7 PLUG	81205	1	21-31-11 1650/178/L045	ALL
D02336	1	BACC45FT12A12S PLUG	81205	1	21-31-21 1650/178/L045	001-099
D02336	1	BACC45FT12A12S PLUG	81205	1	21-31-21 1650/175/L051	115-199
D02338	1	BACC45FT10D5S PLUG	81205	1	21-31-11 1650/182/L045	001-099
D02338	1	BACC45FT10D5S PLUG	81205	1	21-31-11 1650/178/L45	115-199

EQUIPMENT LIST

D280N032

Section D02300

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02340	1	BACC66F11C0701 PLUG PLATE ASSY-	81205	1	21-31-11 E5-1/ /	ALL
D02340A	1	PARTAOFD02340 PLUG		0	21-31-11 E5-1/ /	ALL
D02340B	1	PARTBOFD02340 PLUG		0	21-31-11 E5-1/ /	ALL
D02340C	1	PARTCOFD02340 PLUG		0	21-31-11 E5-1/ /	ALL
D02342	1	BACC66F11C0701 PLUG PLATE ASSY	81205	1	21-31-21 E5-2/ /	001-099
D02342	1	BACC66F11C0701 PLUG-	81205	1	21-31-21 E5-2/ /	115-199
D02342A	1	PARTAOFD02342 PLUG-		0	21-31-21 E5-2/ /	ALL
D02342B	1	PARTBOFD02342 PLUG-		0	21-31-21 E5-2/ /	ALL
D02342C	1	PARTCOFD02342 PLUG-		0	21-31-21 E5-2/ /	ALL
D02344	1	BACC45FT18A31S PLUG	81205	1	21-31-21 P005-00/ /	001-099
D02344	1	BACC45FT18A31S PLUG	81205	1	21-31-21 P5/ /	115-199
D02346	1	BACC45FT12A12S PLUG	81205	1	21-31-31 P005-00/ /	001-099
D02346	1	BACC45FT12A12S PLUG	81205	1	29-33-11 P5/ /	115-199
D02348	1	BACC45FT16A24S PLUG	81205	1	25-31-23 P032-00/ /	115-199
D02352	1	BACC45FT16A24S PLUG	81205	1	25-31-33 P031-00/ /	ALL
D02358	1	BACC45FT14D7S PLUG	81205	1	21-58-21 1666/165/L006	ALL
D02360	1	BACC45FT14D7S PLUG	81205	1	21-58-21 1679/172/L019	ALL

EQUIPMENT LIST

D280N032

Section D02300

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02362	1	BACC65L41 PLUG	81205	1	26-11-12 P54/ /	ALL
D02372	1	BACC45FT16D24S PLUG	81205	1	32-31-11 P3-1/ /	ALL
D02374	1	BACC45FT20A41S PLUG	81205	1	32-42-12 P1-3/ /	001-099
D02374	1	BACC45FT20A41S PLUG	81205	1	32-42-12 P001-3/ /	115-199
D02376	1	BACC63BN10-5S PLUG-	81205	1	28-42-21 1040/177/L48	ALL
D02376 T		MS27559-2 CABLE CLAMP-	96906	1	28-42-21 */ */ *	ALL
D02378	1	BACS16W1 RELAY SOCKET	81205	1	49-61-11 E6 RLY/PNL/	ALL
D02380	1	BACS16X1A RELAY SOCKET	81205	1	49-61-11 E6 RLY/PNL/	ALL
D02382	1	BACC63BP14A7SNL PLUG-	81205	1	28-25-21 1040/180/L020	001-099
D02382	1	BACC63BP14A7SNL PLUG-	81205	1	28-25-21 1040/180/L27	115-199
D02382 T	1	BACC10HG14 CABLE CLAMP	81205	1	28-25-21 1040/180/L20	001-099
D02382 T	1	BACC10HG14 CABLE CLAMP	81205	1	28-25-21 1040/180/L27	115-199
D02386	1	BACC63BP14A4SNL PLUG-DC FUEL PUMP	81205	1	28-25-11 1040/180/L51	ALL
D02386 T		BACC10HF14 CABLE CLAMP-	81205	1	28-25-11 */ */ *	ALL
D02388	1	BACC63BN10-5S PLUG-	81205	1	28-25-11 IRSS181/ /	ALL
D02388 T		MS27559-2 CABLE CLAMP	81205	1	28-25-11 */ */ *	001-099
D02388 T		MS27559-2 CABLE CLAMP	81205	1	28-25-11 * */ */ *	115-199

EQUIPMENT LIST

D280N032

Section D02300

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02390	1	BACS16W1 RELAY SOCKET	81205	1	28-21-11 P33/ /	ALL
D02392	1	BACS16W1 RELAY SOCKET	81205	1	28-21-11 P33/ /	ALL
D02394	1	BACS16W1 RELAY SOCKET	81205	1	28-21-11 P33/ /	ALL

EQUIPMENT LIST

D280N032

Section D02300
Page 4 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02400	1	BACC65L41 PLUG	81205	1	26-11-22 P54/ /	ALL
D02402	1	MS3459KS14S-5S PLUG	14283	1	26-11-12 PPS165/ /	ALL
D02402 T		BACC10HD14A CABLE CLAMP	81205	1	26-11-12 PPS165/ /	ALL
D02402 U		5100-179-16-1 CONTACT	14283	2	26-11-12 / /	ALL
D02408	1	BACS16X3A RELAY SOCKET	81205	1	28-25-11 P070-00/ /	ALL
D02410	1	BACS16AG1 RELAY SOCKET	81205	1	28-25-21 E6 RLY/PNL/	ALL
D02414	1	BACS16AG1 RELAY SOCKET	81205	1	28-25-21 E6 RLY/PNL/	ALL
D02416	1	BACS16X3A RELAY SOCKET	81205	1	49-41-11 E6 RLY/PNL/	ALL
D02422	1	BACC63CE14S-6S PLUG	81205	1	26-15-12 P33/ /	ALL
D02424	1	BACS16W1 RELAY SOCKET	81205	1	26-15-12 P33/ /	ALL
D02434	1	BACS16W1 RELAY SOCKET	81205	1	49-61-11 E6 RLY/PNL/	ALL
D02436	1	BACS16X1A RELAY SOCKET	81205	1	49-61-11 E6/ /	115-199
D02440	1	BACC66H26C80AA00 PLUG PLATE ASSY	71468	1	28-41-21 E003-04/ /	001-099
D02440	1	BACC66H26C80A00 PLUG PLATE ASSY (MR69018-002)	71468	1	28-41-21 E003-04/ /	115-199
D02440A	1	PARTAOFD02440 PLUG		0	28-41-21 E003-04/ /	ALL
D02440B	1	PARTBOFD02440 PLUG		0	28-41-21 E003-04/ /	ALL
D02440C	1	PARTCOFD02440 PLUG		0	28-41-21 E003-04/ /	ALL

EQUIPMENT LIST

D280N032

Section D02400

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02444	1	BACC63BN10-5S PLUG	81205	1	28-21-23 IRSS255/ /	ALL
D02444 T		MS27559-2 CABLE CLAMP	96906	1	28-21-23 */*/	ALL
D02446	1	BACC63BN10B5S PLUG	81205	1	28-21-23 1051/172/R43	ALL
D02448	1	BACS16X1A RELAY SOCKET	81205	1	28-21-21 P33/ /	ALL
D02450	1	BACS16X1A RELAY SOCKET	81205	1	28-21-22 P33/ /	ALL
D02452	1	BACC63BP14A7SNL PLUG	81205	1	32-12-12 1126/172/R001	ALL
D02452 T		BACC10HG14 CABLE CLAMP	81205	1	32-12-12 1126/172/R001	ALL
D02454	1	BACC63BP14A7SNL PLUG-	81205	1	32-12-12 273/175/L21	ALL
D02454 T		BACC10HG14 CABLE CLAMP	81205	1	32-12-12 */*/	ALL
D02456	1	BACC63CE10SLB3S PLUG	81205	1	28-21-21 WS684/ /	ALL
D02458	1	BACC45FN20A41P RCPT-ATT PNL	81205	1	33-21-11 P021/ /	001-099
D02458	1	BACC45FN20-41P RCPT-ATT PNL	81205	1	33-21-11 P21/ /	115-199
D02466	1	BACC63BP18A8SNL PLUG-	81205	1	25-51-11 858/155/000	115-199
D02466 T		BACC10HF18 CABLE CLAMP	81205	1	25-51-11 */*/	115-199
D02468	1	BACC63BP18A8SNL PLUG-	81205	1	25-51-21 1195/150/0	115-199
D02468 T		BACC10HG18 CABLE CLAMP	81205	1	25-51-21 1195/150/0	115-199
D02470	1	BACS16X1A RELAY SOCKET (PLATE 'C')	81205	1	74-31-21 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D02400

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02472	1	BACS16X1A RELAY SOCKET (PLATE 'C')	81205	1	74-31-21 P37/ /	115-199
D02478	1	BACS16W1 RELAY SOCKET	81205	1	27-51-11 P33/ /	ALL
D02482	1	BACS16W5A RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P037-00/ /	001-099
D02482	1	BACS16W5A RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P37/ /	115-199
D02484	1	BACS16W5A RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P037-00/ /	001-099
D02484	1	BACS16W5A RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P37/ /	115-199
D02486	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P037-00/ /	001-099
D02486	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P37/ /	115-199
D02488	1	BACC63BP12A3SNL PLUG	81205	1	29-31-11 1180/172/R001	ALL
D02488 T		BACC10HF12 CABLE CLAMP	81205	1	32-12-12 1180/172/R01	ALL
D02490	1	BACC63BP14A7SNL PLUG	81205	1	29-33-11 1051/172/R43	ALL
D02490 T		BACC10HG14 CABLE CLAMP	81205	1	29-33-11 1051/172/R43	ALL
D02492	1	BACC63BP12A3SNL PLUG	81205	1	29-33-11 1188/142/L28	ALL
D02492 T		BACC10HF12 CABLE CLAMP	81205	1	29-33-11 1188/142/L28	ALL
D02494	1	BACC63BP14A7SNL PLUG	81205	1	29-33-11 1194/142/L28	ALL
D02494 T		BACC10HG14 CABLE CLAMP	81205	1	29-33-11 1194/142/L28	ALL
D02496	1	BACC45FT12D12S6 RCPT-	81205	1	27-48-11 AP10/ /	001-099

EQUIPMENT LIST

D280N032

Section D02400

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02496	1	BACC45FT12D12S6 RCPT-	81205	1	27-48-11 P010-00/ /	115-199

EQUIPMENT LIST

D280N032

Section D02400
Page 4 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02500	1	BACC63BN10-5S PLUG	81205	1	28-21-23 IRSS258/ /	ALL
D02500 T		MS27559-2 CABLE CLAMP	96906	1	28-21-21 IRSS258/ /	001-099
D02500 T		MS27559-2 CABLE CLAMP	96906	1	28-21-21 */ /	115-199
D02502	1	BACC63BN10C5S PLUG	81205	1	28-21-23 1040/180/L050	001-099
D02502	1	BACC63BN10B5S PLUG	81205	1	28-21-23 1040/180/L050	115-199
D02504	1	BACS16X1A RELAY SOCKET	81205	1	28-21-22 P33/ /	ALL
D02506	1	BACS16X1A RELAY SOCKET	81205	1	28-21-21 P33/ /	ALL
D02508	1	BACC63BP14A7SNL PLUG	81205	1	32-12-12 1122/172/L005	ALL
D02508 T		BACC10HG14 CABLE CLAMP	81205	1	32-12-12 */ */	ALL
D02510	1	BACC63CE10SLB3S PLUG	81205	1	28-21-21 IRSS684/ .5/	ALL
D02512	1	BACS16X1A RELAY SOCKET	81205	1	28-21-21 P33/ /	ALL
D02514	1	BACC65L41 RCPT	81205	1	28-21-21 P50/ /	ALL
D02520	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	74-31-11 P36/ /	115-199
D02522	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	74-31-11 P36/ /	115-199
D02524	1	BACS16W1 RELAY SOCKET (PLATE 'F')	81205	1	34-61-15 P36/ /	ALL
D02526	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	34-61-25 P037-00/ /	001-099
D02526	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	34-61-25 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D02500

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02528	1	BACS16W5A RELAY SOCKET (PLATE 'D')	81205	1	36-11-11 P36/ /	ALL
D02530	1	BACS16W5A RELAY SOCKET (PLATE 'D')	81205	1	36-11-11 P36/ /	ALL
D02532	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	36-11-11 P36/ /	ALL
D02534	1	BACC63BP12A3SNL PLUG	81205	1	29-31-11 1070/170/L005	ALL
D02534 T		BACC10HF12 CABLE CLAMP	81205	1	29-31-11 */*/	ALL
D02536	1	BACC63BP12A3SNL PLUG	81205	1	29-31-11 1090/149/L003	ALL
D02536 T		BACC10HF12 CABLE CLAMP	81205	1	29-31-11 */*/	ALL
D02538	1	BACC63BP14A7SNL PLUG	81205	1	29-33-11 1051/180/L045	ALL
D02538 T		BACC10HF14 CABLE CLAMP		1	29-33-11 */*/	ALL
D02540	1	BACC63BP14A7SNL PLUG	81205	1	29-33-11 1197/140/L60	ALL
D02540 T		BACC10HF14 CABLE CLAMP	81205	1	29-33-11 */*/	ALL
D02542	1	BACC45FT12D12S6 RCPT-	81205	1	27-48-11 P10/ /	ALL
D02546	1	BACC63BP14A15SNL PLUG	81205	1	21-61-11 885/155/L005	ALL
D02546 T		BACC10HF14 CABLE CLAMP	81205	1	21-61-11 */*/	ALL
D02548	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-11 P037-00/ /	001-099
D02548	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-11 P37/ /	115-199
D02550	1	BACC45FT10A5S PLUG	81205	1	21-61-11 350/197/L052	001-099

EQUIPMENT LIST

D280N032

Section D02500

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02550	1	BACC63BN10-5S PLUG	81205	1	21-61-11 350/197/L52	115-199
D02550 T		BACC10GH10 CABLE CLAMP	81205	1	21-61-11 */*/	115-199
D02552	1	C48-06R10-20S-106- PLUG	81205	1	21-61-11 350/197/L052	ALL
D02552 T		BACC10GH10 CABLE CLAMP	81205	1	21-61-11 */*/	ALL
D02554	1	BACC45FT10-5S PLUG	81205	1	21-61-11 275/280/L015	001-099
D02554	1	BACC45FT10-5S PLUG	81205	1	21-61-11 260/270/L020	115-199
D02558	1	BACC66F11C1101 PLUG PLATE ASSY	81205	1	21-61-11 E3-3/ /	001-099
D02558	1	BACC66F11C1101 PLUG PLATE ASSY	81205	1	21-61-11 E6-2/ /	115-199
D02558A	1	PARTAOFD02558 PLUG	81205	0	21-61-11 E3-3/ /	001-099
D02558A	1	PARTAOFD02558 PLUG	81205	0	21-61-11 E6-2/ /	115-199
D02558B	1	PARTBOFD02558 PLUG	81205	0	21-61-11 E3-3/ /	001-099
D02558B	1	PARTBOFD02558 PLUG	81205	0	21-61-11 E6-2/ /	115-199
D02558C	1	PARTCOFD02558 PLUG	81205	0	21-61-11 E3-3/ /	001-099
D02558C	1	PARTCOFD02558 PLUG	81205	0	21-61-11 E6-2/ /	115-199
D02560	1	BACC63BP14A15SNL PLUG	81205	1	21-61-21 893/155/L003	001-099
D02560	1	BACC63BP14A15SNL PLUG	81205	1	21-61-21 893/155/L3	115-199
D02560 T		BACC10HF14 CABLE CLAMP	81205	1	21-61-21 */*/	ALL

EQUIPMENT LIST

D280N032

Section D02500

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02562	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-21 P037-00/ /	001-099
D02562	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-21 P37/ /	115-199
D02564	1	BACC45FT10A5S PLUG	81205	1	21-61-21 860/300/L013	001-099
D02564	1	BACC45FT10A5S PLUG	81205	1	21-61-21 860/300/L13	115-199
D02566	1	C48-06R10-20S PLUG	86165	1	21-61-21 860/299/L11	001-099
D02566	1	C48-06R10-20S-106- PLUG	86165	1	21-61-21 860/299/L11	115-199
D02566 T		BACC10GH10 CABLE CLAMP	86165	1	21-61-21 */*/*	ALL
D02568	1	BACC45FT10-5S PLUG	81205	1	21-61-21 517/275/R029	ALL
D02570	1	BACC63BN8C3S PLUG-	81205	1	21-61-21 510/274/R35	ALL
D02574	1	BACC63BP14A15SNL PLUG	81205	1	21-61-31 893/163/L003	001-099
D02574	1	BACC63BP14A15SNL PLUG	81205	1	21-61-31 893/163/L3	115-199
D02574 T		BACC10HG14 CABLE CLAMP	81205	1	21-61-31 */*/*	ALL
D02576	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-31 P037-00/ /	001-099
D02576	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-31 P37/ /	115-199
D02578	1	BACC45FT10A5S PLUG	81205	1	21-61-31 880/300/L13	001-099
D02578	1	BACC45FT10D5S PLUG	81205	1	21-61-31 880/300/L13	115-199
D02580	1	C48-06R10-20S PLUG	13556	1	21-61-31 880/299/L11	ALL

EQUIPMENT LIST

D280N032

Section D02500

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02580 T		BACC10GH10 CABLE CLAMP	81205	1	21-61-31 */*/	001-099
D02580 T		GTR21-10CD CABLE CLAMP	06324	1	21-61-31 */*/	115-199
D02582	1	BACC45FT10-5S PLUG	81205	1	21-61-31 1174/280/R040	001-099
D02582	1	BACC45FT10-5S PLUG	81205	1	21-61-31 1177/275/R29	115-199
D02584	1	BACC45FT8A3S PLUG-	81205	1	21-61-31 1177/275/R45	ALL
D02590	1	BACC45FT18B8S PLUG	81205	1	21-25-11 869/179/R049	ALL
D02592	1	BACC45FT18D8S PLUG-	81205	1	21-25-11 522/178/L048	ALL
D02596	1	BACS16X3A RELAY SOCKET (PLATE 'D')	81205	1	21-25-11 P36/ /	ALL
D02598	1	BACC66F11C52 PLUG PLATE ASSY	81205	1	29-33-11 E003-04/ /	001-099
D02598	1	BACC66F11C52 PLUG PLATE ASSY	81205	1	29-33-11 E6-4/ /	115-199
D02598A	1	PARTAOFD02598 PLUG		0	29-33-11 E003-04/ /	001-099
D02598A	1	PARTAOFD02598 PLUG		0	29-33-11 E6-4/ /	115-199
D02598B	1	PARTBOFD02598 PLUG		0	29-33-11 E003-04/ /	001-099
D02598B	1	PARTBOFD02598 PLUG		0	29-33-11 E6-4/ /	115-199
D02598C	1	PARTCOFD02598 PLUG		0	29-33-11 E003-04/ /	001-099
D02598C	1	PARTCOFD02598 PLUG		1	29-33-11 E6-4/ /	115-199

EQUIPMENT LIST

D280N032

Section D02500

Page 5 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02602	1	BACS16X1A RELAY SOCKET (PLATE 'B')	81205	1	21-44-11 P37/ /	115-199
D02604	1	BACS16W5A RELAY SOCKET (PLATE 'B')	81205	1	21-44-11 P037-00/ /	001-099
D02604	1	BACS16W1 RELAY SOCKET (PLATE 'B')	81205	1	21-44-11 P37/ /	115-199
D02610	1	BACS16X1A RELAY SOCKET-	81205	1	25-51-11 P65/ /	115-199
D02612	1	BACS16X1A RELAY SOCKET	81205	1	25-51-21 E6/ /	115-199
D02614	1	BACS16X1A RELAY SOCKET-	81205	1	25-51-11 P65/ /	115-199
D02616	1	BACS16X1A RELAY SOCKET	81205	1	25-51-21 E6/ /	115-199
D02618	1	BACC45FS18B14S PLUG	81205	1	49-61-14 1792/268/R18	001-099
D02618	1	BACC45FS18B14S PLUG	81205	1	49-61-14 1792/280/	115-199
D02624	1	BACC63BP14A7SNL LOAD SELECT CONTROL	81205	1	28-21-22 P28/ /	ALL
D02624 T		BACC10HG14A CABLE CLAMP	81205	1	28-21-22 P28/ /	ALL
D02626	1	BACS16X1A RELAY SOCKET	81205	1	28-26-11 P33/ /	ALL
D02628	1	BACS16AG1 RELAY SOCKET	81205	1	28-26-11 P33/ /	ALL
D02630	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P037-00/ /	001-099
D02630	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P37/ /	115-199
D02632	1	BACS16AF1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P037-00/ /	001-099
D02632	1	BACS16AF1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D02600

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02638	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P037-00/ /	001-099
D02638	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P37/ /	115-199
D02640	1	BACS16X1A RELAY SOCKET (PLATE 'C')	81205	1	78-34-21 P037-00/ /	001-099
D02640	1	BACS16X1A RELAY SOCKET (PLATE 'C')	81205	1	78-34-21 P37/ /	115-199
D02646	1	BACC63BP16A10SNL PLUG	81205	1	32-44-11 1040/170/R31	ALL
D02646 T		BACC10HF16 CABLE CLAMP	81205	1	32-44-11 1040/170/R31	ALL
D02648	1	BACC63BP12B3S7L PLUG	81205	1	32-46-11 OUTBD/FWD/L/H	115-199
D02650	1	BACC63BP12B3S7L PLUG	81205	1	32-46-11 INBD/FWD/L/H	115-199
D02652	1	BACC63BP12B3S7L PLUG	81205	1	32-46-11 OUTBD/AFT/L/H	115-199
D02654	1	BACC63BP12B3S7L PLUG	81205	1	32-46-11 INBD/AFT/L/H	115-199
D02656	1	BACC63BP12B3S7L PLUG	81205	1	32-46-11 INBD/FWD/R/H	115-199
D02658	1	BACC63BP12B3S7L PLUG	81205	1	32-46-11 OUTBD/FWD/R/H	115-199
D02660	1	BACC63BP12B3S7L PLUG	81205	1	32-46-11 INBD/AFT/R/H	115-199
D02662	1	BACC63BP12B3S7L PLUG	81205	1	32-46-11 OUTBD/AFT/R/H	115-199
D02666	1	BACC63BP12A3SNL PLUG	81205	1	32-42-12 1040/170/R045	ALL
D02666 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-12 1040/170/R045	ALL
D02668	1	BACC63BP12A3S7L PLUG	81205	1	32-42-12 1040/173/L051	ALL

EQUIPMENT LIST

D280N032

Section D02600

Page 2

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02668 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-12 */*/	ALL
D02670	1	BACC63BP12A3SNL PLUG	81205	1	32-42-12 1040/175/L056	ALL
D02670 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-12 */*/	ALL
D02672	1	BACC63BP12A3S6L PLUG	81205	1	32-42-12 1040/173/L056	ALL
D02672 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-12 */*/	ALL
D02674	1	BACC63BP12A3SNL PLUG	81205	1	32-42-12 1040/172/L050	ALL
D02674 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-12 */*/	ALL
D02676	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D02676	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D02678	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P36/ /	ALL
D02690	1	BACC63BP16B10SNL PLUG	81205	1	36-11-21 PPS177/ /	ALL
D02690 T		BACC10HD16A CABLE CLAMP	81205	1	36-11-21 PPS177/ /	ALL
D02692	1	BACC63BP14A7SNL PLUG	81205	1	36-11-22 901/150/R039	ALL
D02692 T		BACC10HG14 CABLE CLAMP	81205	1	36-11-22 */*/	ALL
D02694	1	BACC45FT10A5S PLUG	81205	1	21-33-11 231/100/L045	001-099
D02694	1	BACC45FT10A5S PLUG	81205	1	21-33-11 231/174/L036	115-199
D02696	1	BACC45FT12A12S PLUG	81205	1	21-33-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D02600

Page 3

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02696	1	BACC45FT12A12S PLUG	81205	1	21-33-11 P5/ /	115-199
D02698	1	BACC45FT12A12S6 PLUG	81205	1	21-33-11 P005-00/ /	001-099
D02698	1	BACC45FT12A12S6 PLUG	81205	1	21-33-11 P5/ /	115-199

EQUIPMENT LIST

D280N032

Section D02600

Page 4 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02700	1	BACS16W1 RELAY SOCKET (PLATE 'D')	81205	1	80-11-11 P36/ /	ALL
D02702	1	BACS16AF1 RELAY SOCKET (PLATE 'D')	81205	1	80-11-11 P36/ /	ALL
D02708	1	BACS16W1 RELAY SOCKET (PLATE 'D')	81205	1	80-11-11 P36/ /	ALL
D02712	1	BACS16W1 RELAY SOCKET	81205	1	33-24-11 P34/ /	ALL
D02714	1	BACS16X2 RELAY SOCKET	81205	1	33-24-11 P34/ /	115-199
D02716	1	BACS16X1A RELAY SOCKET	81205	1	28-26-11 P33/ /	ALL
D02718	1	BACS16AG1 RELAY SOCKET	81205	1	28-26-11 P33/ /	ALL
D02720	1	BACC45FN10A5S RCPT	81205	1	21-45-11 230/200/L13	001-099
D02720	1	BACC45FN10A5S RCPT	81205	1	21-45-11 225/208/L13	115-199
D02722	1	BACC45FN10A5S RCPT	81205	1	21-45-11 232/199/R013	001-099
D02722	1	BACC45FN10A5S RCPT	81205	1	21-45-11 225/200/R13	115-199
D02734	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-42-11 P36/ /	ALL
D02736	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-42-11 P36/ /	ALL
D02738	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-42-11 P36/ /	ALL
D02740	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-42-11 P36/ /	ALL
D02742	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-42-11 P36/ /	ALL
D02744	1	BACC66F11C54 PLUG PLATE ASSY	81205	1	32-42-13 E005-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D02700

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02744	1	BACC66F11C01 PLUG PLATE ASSY	81205	1	32-42-11 E6-4/ /	115-199
D02744A	1	PARTAOFD02744 PLUG		0	32-42-13 E5-2/ /	001-099
D02744A	1	PARTAOFD02744 PLUG		0	32-42-11 E6-4/ /	115-199
D02744B	1	PARTBOFD02744 PLUG		0	32-42-13 E5-2/ /	001-099
D02744B	1	PARTBOFD02744 PLUG		0	32-42-11 E6-4/ /	115-199
D02744C	1	PARTCOFD02744 PLUG		0	32-42-13 E5-2/ /	001-099
D02744C	1	PARTCOFD02744 PLUG		1	32-42-11 E6-4/ /	115-199
D02746	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	78-34-11 P36/ /	ALL
D02752	1	BACC63BP12A3SNL PLUG	81205	1	32-42-12 1040/170/L038	ALL
D02752 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-12 */*/	001-099
D02752 T		BACC10HF12 CABLE CLAMP	81205	1	32-42-12 */*/	115-199
D02754	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D02756	1	00855-0488-0003 PLUG	04274	1	30-31-11 205/220/L045	ALL
D02758	1	00855-0488-0003 PLUG-	04274	1	30-31-11 210/208/	001-099
D02758	1	00855-0488-0003 PLUG	04274	1	30-31-11 210/214/L045	115-199
D02760	1	BACC63BP14A7SNL PLUG	81205	1	32-42-11 1040/175/R030	001-099
D02760	1	BACC63BP12A3S7L PLUG	81205	1	32-42-11 1040/175/R030	115-199

EQUIPMENT LIST

D280N032

Section D02700

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02760 T		BACC10HG14 CABLE CLAMP	81205	1	32-42-11 1040/175/R030	001-099
D02760 T		BACC10HG12 CABLE CLAMP	81205	1	32-42-11 1040/175/R030	115-199
D02762	1	00855-0488-0003 PLUG	04274	1	30-31-12 210/220/R045	001-099
D02762	1	00855-0488-0003 PLUG	04274	1	30-31-12 210/214/R045	115-199
D02764	1	00855-0488-0003 PLUG	04274	1	30-31-12 210/208/R045	001-099
D02764	1	00855-0488-0003 PLUG	04274	1	30-31-12 210/220/R45	115-199
D02768	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-44-11 P36/ /	ALL
D02774	1	BACC45FT14A7S PLUG	81205	1	34-12-11 435/202/R070	ALL
D02776	1	000300-1560 RELAY SOCKET (PLATE 'A')	05574	1	30-33-11 P037-00/ /	001-099
D02776	1	000300-1560 RELAY SOCKET (PLATE 'A')	05574	1	30-33-11 P37/ /	115-199
D02780	1	BACC63BP16B10SNL PLUG	81205	1	36-11-12 PPS175/ /	ALL
D02780 T		BACC10HD16A CABLE CLAMP	81205	1	36-11-12 PPS175/128/000	ALL
D02782	1	BACC63BP14A7SNL PLUG	81205	1	36-11-12 901/150/R036	ALL
D02782 T		BACC10HG14 CABLE CLAMP	81205	1	36-11-12 */ */	ALL
D02784	1	BACC63BP14A7SNL PLUG		1	28-41-41 FSS100/ /	115-199
D02784 T		BACC10HF14 CABLE CLAMP	81205	1	28-41-41 */ /	115-199
D02786	1	BACC63BP14A3SNL PLUG-	81205	1	28-41-41 FSS101/ /	115-199

EQUIPMENT LIST

D280N032

Section D02700

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02786 T		S2408-13-8 CABLE CLAMP	81205	1	28-41-41 */ /	115-199
D02788	1	BACC63BP20A16SNL PLUG-	81205	1	28-41-21 OSS336/ /	115-199
D02788 T		BACC10HF20 CABLE CLAMP-	81205	1	28-41-21 */ /	115-199
D02790	1	BACC63BP16D10SNL PLUG (CAP AND STOW PER MR69018-002)	81205	1	28-41-21 IRSS258/ /	115-199
D02790	2	BACC63BP16B10SNL PLUG	81205	1	28-41-21 IRSS258/ /	115-199
D02790	3	BACC63BP16A10SNL PLUG	81205	1	28-41-21 IRSS258/ /	115-199
D02790 T	1	BACC10HE16A CABLE CLAMP	81205	1	28-41-21 */ /	115-199
D02790 T	2	BACC10HG16 CABLE CLAMP	81205	1	28-41-21 */ /	115-199
D02792	1	BACC63BP14A3SNL PLUG-	81205	1	28-41-21 OSS361/ /	115-199
D02792 T		S2408-13-8 CABLE CLAMP-	07418	1	28-41-21 OSS361/ /	115-199
D02794	1	BACC66F11C1801 PLUG PLATE ASSY	81205	1	32-46-11 E6-4/ /	115-199
D02794A	1	PARTAOFD02794 PLUG		0	32-46-11 E6-4/ /	115-199
D02794B	1	PARTBOFD02794 PLUG		0	32-46-11 E6-4/ /	115-199
D02794C	1	PARTCOFD02794 PLUG		1	32-46-11 E6-4/ /	115-199
D02796	1	35303-75 PLUG-OVERHEAT DETECTION ELEM	73168	1	26-17-11 1140/191/L016	ALL
D02798	1	35303-75 PLUG	73168	1	26-17-11 1135/196/L16	ALL

EQUIPMENT LIST

D280N032

Section D02700

Page 4 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02800	1	MS3459KS14S-5S PLUG	14283	1	26-11-22 PPS153/ /	ALL
D02800 T		BACC10HD14A CABLE CLAMP	81205	1	26-11-22 PPS153/ /	ALL
D02800 U		5100-179-16-1 CONTACT	14283	2	26-11-22 / /	ALL
D02804	1	MS3459KS14S-5S PLUG	14283	1	26-11-22 PPS153/ /	ALL
D02804 T		BACC10HD14A CABLE CLAMP	81205	1	26-11-22 / /	ALL
D02804 U		5100-179-16-1 CONTACT	14283	2	26-11-22 / /	ALL
D02808	1	BACC63BP14A7SNL PLUG	81205	1	28-41-41 ISS101/ /	115-199
D02808 T		BACC10HF14 CABLE CLAMP	81205	1	28-41-41 */*/	115-199
D02810	1	BACC63BP16D10SNL PLUG (CAP AND STOW PER MR69018-002)	81205	1	28-41-41 IRSS160/ /	115-199
D02810	2	BACC63BP16B10SNL PLUG	81205	1	28-41-41 IRSS160/ /	115-199
D02810	3	BACC63BP16A10SNL PLUG	81205	1	28-41-41 IRSS160/ /	115-199
D02810 T	1	BACC10HE16A CABLE CLAMP	81205	1	28-41-41 */*/	115-199
D02810 T	2	BACC10HG16 CABLE CLAMP	81205	1	28-41-41 */*/	115-199
D02812	1	BACC63BP14A3SNL PLUG	81205	1	28-41-41 ISS101/ /	115-199
D02812 T		S2408-13-8 CABLE CLAMP	07418	1	28-41-41 */*/	115-199
D02814	1	BACC63BP20A16SNL PLUG-	81205	1	28-41-31 OSS335/ /	115-199
D02814 T		BACC10HF20 CABLE CLAMP-	81205	1	28-41-31 OSS335/ /	115-199

EQUIPMENT LIST

D280N032

Section D02800

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02816	1	BACC63BP16D10SNL PLUG (CAP AND STOW PER MR69018-002)	81205	1	28-41-31 IRSS255/ /	115-199
D02816	2	BACC63BP16B10SNL PLUG	81205	1	28-41-31 IRSS255/ /	115-199
D02816	3	BACC63BP16A10SNL PLUG	81205	1	28-41-31 IRSS255/ /	115-199
D02816 T	1	BACC10HE16A CABLE CLAMP	81205	1	28-41-31 */ */	115-199
D02816 T	2	BACC10HG16 CABLE CLAMP	81205	1	28-41-31 */ */	115-199
D02818	1	BACC63BP14A3SNL PLUG-	81205	1	28-41-31 OSS360/ /	115-199
D02818 T		S2408-13-8 CABLE CLAMP-	07414	1	28-41-31 */ /	115-199
D02820	1	35303-75 PLUG	73168	1	26-17-11 1135/197/R017	ALL
D02822	1	35303-75 PLUG	73168	1	26-17-11 1135/195/R017	ALL
D02824	1	BACC65L66 RCPT	81205	1	26-18-11 P50/ /	ALL
D02828	1	SO-1062-8917 RELAY SOCKET	35344	1	33-21-11 P034-00/ /	001-099
D02828	1	SO-1062-8917 RELAY SOCKET	35344	1	33-21-11 P34/ /	115-199
D02830	1	BACC63BP12A3S9L PLUG	81205	1	78-36-21 PPS242/ /	ALL
D02830 T		BACC10HF12A CABLE CLAMP	81205	1	78-36-21 PPS242/ /	ALL
D02832	1	BACC63BP12A3S6L PLUG	81205	1	78-34-21 PPS240/ /R	ALL
D02832 T		BACC10HF12 CABLE CLAMP	81205	1	78-34-21 PPS240/R/	ALL
D02838	1	BACC65L66 RCPT	81205	1	77-12-42 P50/ /	ALL

EQUIPMENT LIST

D280N032

Section D02800

Page 2

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02852	1	BACC45FT12A12S PLUG-	81205	1	33-27-21 697/290/R029	001-099
D02852	1	BACC45FT12A12S PLUG-	81205	1	33-27-21 697/290/R29	115-199
D02878	1	K-4932 PLUG	96906	1	33-13-12 P005-00/ /	001-099
D02878	1	K-4932 PLUG	96906	1	33-13-12 P5/ /	115-199
D02880	1	MS3126F20-41S PLUG-	09922	1	31-31-11 P061-00/ /	115-199
D02884	1	10-60450-5 PLUG	81205	1	33-13-12 P003-01/ /	ALL
D02886	1	BACC63BP16A10SNL PLUG	81205	1	27-23-11 1180/185/R042	ALL
D02886 T		BACC10HF16 CABLE CLAMP	81205	1	27-23-11 1180/185/R042	ALL
D02888	1	BACC45FT12-12S PLUG	81205	1	33-13-21 P3-1/ /	001-099
D02888	1	BACC45FT12-12S PLUG	81205	1	33-13-21 P3-3/ /	115-199
D02888 T		BACC10GH12 CABLE CLAMP	81205	1	33-13-21 */ */*	001-099
D02888 T		BACC10GH12 CABLE CLAMP	81205	1	33-13-21 P3-3/ /	115-199
D02890	1	BACC45FT12A12S PLUG	81205	1	33-13-52 P008-00/ /	ALL
D02892	1	BACC45FT12A12S PLUG	81205	1	33-13-52 P008-00/ /	ALL
D02894	1	BACC45FT12D12S PLUG	81205	1	33-13-51 P008-00/ /	001-099
D02894	1	BACC45FT12D12S PLUG	81205	1	33-13-51 P8/ /	115-199
D02896	1	BACC45FT12A12S PLUG	81205	1	33-13-71 P61/ /	115-199

EQUIPMENT LIST

D280N032

Section D02800

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02898	1	SO-1062-8917 RELAY SOCKET	35344	1	33-21-31 P34/ /	ALL

EQUIPMENT LIST

D280N032

Section D02800

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02900	1	BACC63BP12A3S9L PLUG	81205	1	78-36-11 242.8/150/L5	ALL
D02900 T		BACC10HF12C CABLE CLAMP	81205	1	78-36-11 */50/*	ALL
D02902	1	BACC63BP12A3S6L PLUG	81205	1	78-34-11 N252/147/L6	ALL
D02902 T		BACC10HF12 CABLE CLAMP	81205	1	78-34-11 */*/	ALL
D02914	1	BACC45FT12-12S PLUG	81205	1	33-13-12 P003-01/ /	ALL
D02914 T		BACC10GH12 CABLE CLAMP	81205	1	33-13-12 */*/	ALL
D02916	1	BACC63BP16A10SNL PLUG	81205	1	27-23-11 1180/180/L017	ALL
D02916 T		BACC10HG16A CABLE CLAMP	81205	1	27-23-11 */*/	001-099
D02916 T		BACC10HF16A CLAMP	81205	1	27-23-11 */*/	115-199
D02918	1	BACC63BP16A10SNL PLUG	81205	1	27-23-11 1180/195/L035	ALL
D02918 T		BACC10HG16 CABLE CLAMP	81205	1	27-23-11 */*/	ALL
D02920	1	BACC63BP14A7SNL PLUG	81205	1	27-51-31 1048/190/L021	001-099
D02920	1	BACC63BP14A7SNL PLUG	81205	1	27-51-31 1048/190/L21	115-199
D02920 T		BACC10HG14 CABLE CLAMP	81205	1	27-51-31 */*/	ALL
D02922	1	BACC45FT12-12S PLUG	81205	1	33-13-41 P3-3/ /	001-099
D02922	1	BACC45FT12-12S PLUG	81205	1	33-13-41 P3-1/ /	115-199
D02922 T		BACC10GH12 CABLE CLAMP	81205	1	33-13-41 */*/	001-099

EQUIPMENT LIST

D280N032

Section D02900

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02922 T		BACC10GH12 CABLE CLAMP	81205	1	33-13-41 P3-1/ /	115-199
D02924	1	BACC63BP12A3S7L PLUG-	81205	1	29-11-31 1215/147/L047	001-099
D02924	1	BACC63BP12A3S7L PLUG-	81205	1	29-11-31 1215/165/L50	115-199
D02924 T		BACC10HF12 CABLE CLAMP-	81205	1	29-11-31 1215/165/L50	ALL
D02926	1	BACC63BP12A3S7L PLUG-	81205	1	29-11-31 1210/165/L052	001-099
D02926	1	BACC63BP12A3S7L PLUG-	81205	1	29-11-31 1220/165/L50	115-199
D02926 T		BACC10HF12 CABLE CLAMP-	81205	1	29-11-31 1220/165/L50	ALL
D02928	1	BACC63BP12A3S7L PLUG-	81205	1	29-11-31 1210/146/L043	001-099
D02928	1	BACC63BP12A3S7L PLUG-	81205	1	29-11-31 1215/165/L50	115-199
D02928 T		BACC10HF12 CABLE CLAMP-	81205	1	29-11-31 1215/165/L50	ALL
D02930	1	BACC45FT16-24S6 PLUG	81205	1	29-11-31 P032-00/ /	ALL
D02934	1	BACC45FT16A24S6 PLUG	81205	1	29-11-31 P031-00/ /	ALL
D02939	9	BACC66H40F03BK00 PLUG PLATE ASSY	81205	1	34-31-31 E002-03/ /	115-199
D02939A	9	PARTAOFD02943 RECPT	81205	0	34-58-11 E002-03/ /	115-199
D02939B	9	PARTBOFD02943 RECPT	81205	0	34-31-31 E002-03/ /	115-199
D02939C	9	PARTCOFD02943 RECPT	81205	0	34-31-31 E002-03/ /	115-199
D02940	1	SO-1062-8917 RELAY SOCKET	35344	1	33-21-31 P34/ /	ALL

EQUIPMENT LIST

D280N032

Section D02900

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02941	9	BACC66H40F03BK00 PLUG PLATE ASSY	81205	1	34-31-21 E002-02/ /	115-199
D02941A	9	PARTAOFD02941 RECPT	81205	0	34-58-21 E002-02/ /	115-199
D02941B	9	PARTBOFD02941 RECPT	81205	0	34-58-21 E002-02/ /	115-199
D02941C	9	PARTCOFD02941 RECPT	81205	0	34-31-21 E002-02/ /	115-199
D02942	1	BACC63BP16A24SNL PLUG	81205	1	21-51-13 1049/140/L034	ALL
D02942 T		BACC10HG16 CABLE CLAMP	81205	1	21-51-13 */*/	ALL
D02943	9	BACC66H40F03BK00 PLUG PLATE ASSY	81205	1	34-31-31 E002-03/ /	115-199
D02943A	9	PARTAOFD02943 RECPT	81205	0	34-58-11 E002-03/ /	115-199
D02943B	9	PARTBOFD02943 RECPT	81205	0	34-31-31 E002-03/ /	115-199
D02943C	9	PARTCOFD02943 RECPT	81205	0	34-31-31 E002-03/ /	115-199
D02944	1	BACC63BP16A24SNL PLUG	81205	1	21-51-13 900/142/L60	ALL
D02944 T		BACC10HF16 CABLE CLAMP	81205	1	21-51-13 */*/	ALL
D02946	1	BACC63BP12A12SNL PLUG	81205	1	21-51-12 970/141/L32	ALL
D02946 T		BACC10HF12 CABLE CLAMP	81205	1	21-51-12 */*/	ALL
D02948	1	BACS16W1A RELAY SOCKET (PLATE 'F')	81205	1	21-51-12 P36/ /	001-099
D02948	1	BACS16W1 RELAY SOCKET	81205	1	21-51-12 E6/ /	115-199
D02950	1	BACS16W1A RELAY SOCKET (PLATE 'F')	81205	1	21-51-12 P36/ /	001-099

EQUIPMENT LIST

D280N032

Section D02900

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02950	1	BACS16W1 RELAY SOCKET	81205	1	21-51-12 E6/ /	115-199
D02952	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-12 943/149/L032	ALL
D02952 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-12 */*/	ALL
D02954	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-12 863/189/L009	001-099
D02954	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-12 863/189/R9	115-199
D02954 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-12 */*/	001-099
D02954 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-12 */ /	115-199
D02956	1	BACC63BP10A5SNL PLUG	81205	1	21-51-22 900/134/L038	ALL
D02956 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-22 */*/	ALL
D02958	1	BACS16AF1 RELAY SOCKET (PLATE 'D')	81205	1	27-58-11 P36/ /	ALL
D02960	1	BACC45FT12-12S PLUG	81205	1	27-58-11 P3-1/ /	ALL
D02960 T		BACC10GH12 CABLE CLAMP	81205	1	27-58-11 */*/	001-099
D02960 T		BACC10GH12 CABLE CLAMP	81205	1	27-58-11 P3-1/ /	115-199
D02962	1	BACC63BP14A15SNL PLUG	81205	1	21-51-13 970/141/L30	ALL
D02962 T		BACC10HF14 CABLE CLAMP	81205	1	21-51-13 */*/	ALL
D02964	1	BACC66F11C1601 PLUG	81205	1	21-51-12 E3-3/ /	001-099
D02964	1	BACC66F11C1601 PLUG	81205	1	21-51-12 E6-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D02900

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02964A	1	PARTAOFD02964 PLUG	81205	0	21-51-12 E3-3/ /	001-099
D02964A	1	PARTAOFD02964 PLUG	81205	0	21-51-12 E6-2/ /	115-199
D02964B	1	PARTBOFD02964 PLUG	81205	0	21-51-12 E3-3/ /	001-099
D02964B	1	PARTBOFD02964 PLUG	81205	0	21-51-12 E6-2/ /	115-199
D02964C	1	PARTCOFD02964 PLUG	81205	0	21-51-12 E3-3/ /	001-099
D02964C	1	PARTCOFD02964 PLUG	81205	0	21-51-12 E6-2/ /	115-199
D02966	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-15 985/155/L47	ALL
D02966 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-15 */*/	ALL
D02968	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-15 942/156/L024	ALL
D02968 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-15 */*/	ALL
D02970	1	BACS16X1A RELAY SOCKET (PLATE 'F')	81205	1	21-51-13 P36/ /	001-099
D02970	1	BACS16X1A RELAY SOCKET	81205	1	21-51-13 E6/ /	115-199
D02972	1	BACS16X1A RELAY SOCKET (PLATE 'F')	81205	1	21-51-13 P36/ /	001-099
D02972	1	BACS16X1A RELAY SOCKET	81205	1	21-51-13 E6/ /	115-199
D02974	1	BACS16X1A RELAY SOCKET (PLATE 'F')	81205	1	21-51-13 P36/ /	001-099
D02974	1	BACS16X1A RELAY SOCKET	81205	1	21-51-13 E6/ /	115-199
D02976	1	BACS16X1A RELAY SOCKET (PLATE 'F')	81205	1	21-51-13 P36/ /	001-099

EQUIPMENT LIST

D280N032

Section D02900

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02976	1	BACS16X1A RELAY SOCKET	81205	1	21-51-13 E6/ /	115-199
D02978	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-13 P36/ /	001-099
D02978	1	BACS16X1A RELAY SOCKET	81205	1	21-51-13 E6/ /	115-199
D02980	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-13 P36/ /	001-099
D02980	1	BACS16X1A RELAY SOCKET	81205	1	21-51-13 E6/ /	115-199
D02982	1	BACC65L41 RCPT	81205	1	21-51-13 P50/ /	ALL
D02984	1	BACC63BP18A14SNL PLUG-	81205	1	27-51-41 OSS818/ /	ALL
D02984 T		BACC10HF18 CABLE CLAMP-	81205	1	27-51-41 */ /	ALL
D02986	1	BACS16W1 RELAY SOCKET	81205	1	27-51-31 P33/ /	ALL
D02988	1	BACC65L41 RCPT	81205	1	21-51-11 P50/ /	ALL
D02990	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	80-11-11 P36/ /	115-199
D02992	1	BACS16W1 RELAY SOCKET (PLATE 'D')	81205	1	80-11-11 P36/ /	ALL
D02994	1	BACS16AF1 RELAY SOCKET (PLATE 'D')	81205	1	80-11-11 P36/ /	ALL
D02996	1	BACC65L66 RCPT	81205	1	77-12-41 P50/ /	ALL
D02998	1	BACC65L66 RCPT	81205	1	22-32-13 P50/ /	ALL

EQUIPMENT LIST

D280N032

Section D02900

Page 6 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03000	1	BACC63BP16A24SNL PLUG	81205	1	21-51-23 1049/140/R041	ALL
D03000 T		BACC10HG16 CABLE CLAMP	81205	1	21-51-23 */*/	ALL
D03002	1	BACC63BP16A24SNL PLUG	81205	1	21-51-23 885/145/R029	ALL
D03002 T		BACC10HG16 CABLE CLAMP	81205	1	21-51-23 */*/	ALL
D03003	1	BACS16W1A RELAY SOCKET-	81205	1	34-22-18 P065-00/ /	002
D03004	1	BACC63BP12A12SNL PLUG	81205	1	21-51-22 958/141/R031	ALL
D03004 T		BACC10HG12 CABLE CLAMP	81205	1	21-51-22 */*/	ALL
D03005	1	BACS16W1A RELAY SOCKET-	81205	1	34-22-28 P065-00/ /	002
D03006	1	BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-22 P037-00/ /	001-099
D03006	1	BACS16W1 RELAY SOCKET	81205	1	21-51-22 E6/ /	115-199
D03008	1	BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-22 P037-00/ /	001-099
D03008	1	BACS16W1 RELAY SOCKET	81205	1	21-51-22 E6/ /	115-199
D03010	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-22 943/149/R032	ALL
D03010 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-22 */*/	ALL
D03012	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-22 863/189/R009	001-099
D03012	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-22 863/189/R9	115-199
D03012 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-22 */*/	ALL

EQUIPMENT LIST

D280N032

Section D03000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03014	1	BACC63BP14A15SNL PLUG	81205	1	21-51-23 960/141/R031	ALL
D03014 T		BACC10HF14 CABLE CLAMP	81205	1	21-51-23 */*/	ALL
D03016	1	BACC45FT12A12S PLUG-	81205	1	33-13-61 283/272/L034	001-099
D03016	1	BACC45FT12A12S PLUG	812053	1	33-13-61 283/272/L034	115-199
D03018	1	BACC45FT12A12S PLUG-	81205	1	33-13-61 283/272/L034	ALL
D03020	1	BACC45FT12A12S PLUG-	81205	1	33-13-61 283/272/L034	001-099
D03020	1	BACC45FT12A12S PLUG	81205	1	33-13-61 283/272/L034	115-199
D03022	1	BACS16W1 RELAY SOCKET (PLATE 'D')	81205	1	27-51-51 P36/ /	ALL
D03024	1	BACC63BP14A7SNL PLUG	81205	1	27-51-51 1060/190/L020	ALL
D03024 T		BACC10HF14 CABLE CLAMP	81205	1	27-51-51 */*/	ALL
D03026	1	BACC66F11C1601 PLUG PLATE ASSY	81205	1	21-51-22 E3-2/ /	001-099
D03026	1	BACC66F11C1601 PLUGPLATE ASSY	81205	1	21-51-22 E6-2/ /	115-199
D03026A	1	PARTAOFD03026 PLUG	81205	0	21-51-22 E3-2/ /	001-099
D03026A	1	PARTAOFD03026 PLUG	81205	1	21-51-22 E6-2/ /	115-199
D03026B	1	PARTBOFD03026 PLUG	81205	0	21-51-22 E3-2/ /	001-099
D03026B	1	PARTBOFD03026 PLUG	81205	1	21-51-22 E6-2/ /	115-199
D03026C	1	PARTCOFD03026 PLUG	81205	0	21-51-22 E3-2/ /	001-099

EQUIPMENT LIST

D280N032

Section D03000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03026C	1	PARTCOFD03026 PLUG	81205	1	21-51-22 E6-2/ /	115-199
D03028	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-25 975/145/R027	ALL
D03028 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-25 */ */	ALL
D03030	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-25 942/156/R060	ALL
D03030 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-25 */ */	ALL
D03032	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-23 P037-00/ /	001-099
D03032	1	BACS16X1A RELAY SOCKET	81205	1	21-51-23 E6/ /	115-199
D03034	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-23 P037-00/ /	001-099
D03034	1	BACS16X1A RELAY SOCKET	81205	1	21-51-23 E6/ /	115-199
D03036	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-23 P037-00/ /	001-099
D03036	1	BACS16X1A RELAY SOCKET	81205	1	21-51-23 E6/ /	115-199
D03038	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-23 P037-00/ /	001-099
D03038	1	BACS16X1A RELAY SOCKET	81205	1	21-51-23 E6/ /	115-199
D03040	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-23 P037-00/ /	001-099
D03040	1	BACS16X1A RELAY SOCKET	81205	1	21-51-23 E6/ /	115-199
D03042	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	21-51-23 P037-00/ /	001-099
D03042	1	BACS16X1A RELAY SOCKET	81205	1	21-51-23 E6/ /	115-199

EQUIPMENT LIST

D280N032

Section D03000

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03044	1	BACC65L41 RCPT	81205	1	21-51-23 P50/ /	ALL
D03046	1	BACC65L41 RCPT	81205	1	21-51-21 P50/ /	ALL
D03050	1	BACC63BP14A7SNL PLUG	81205	1	27-81-21 FSS119/WRP/	ALL
D03050 T		BACC10HF14 CABLE CLAMP	81205	1	27-81-21 */ */	ALL
D03052	1	BACS16X1A RELAY SOCKET (PLATE 'C')	81205	1	80-11-12 P37/ /	115-199
D03054	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P037-00/ /	001-099
D03054	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P37/ /	115-199
D03056	1	BACS16AF1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P037-00/ /	001-099
D03056	1	BACS16AF1 RELAY SOCKET (PLATE 'C')	81205	1	80-11-21 P37/ /	115-199
D03058	1	BACC65L66 RCPT	81205	1	22-32-13 P50/ /	ALL
D03062	1	BACC45FT16A24S6 PLUG	81205	1	29-11-22 P031-00/ /	ALL
D03064	1	BACC63BP12A3S7L PLUG	81205	1	29-11-22 PPS229/148/L2	ALL
D03064 T		BACC10HF12C CABLE CLAMP	81205	1	29-11-22 */ /	ALL
D03066	1	BACC63BP12A3S7L PLUG	81205	1	29-11-22 1065/176/R61	ALL
D03066 T		BACC10HG12 CABLE CLAMP-	81205	1	29-11-22 1068/174/R58	ALL
D03072	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	29-11-31 P36/ /	ALL
D03076	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	29-11-22 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D03000

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03080	1	BACS16W2 RELAY SOCKET	81205	1	33-22-11 P34/ /	ALL
D03082	1	BACS16W2 RELAY SOCKET	81205	1	33-22-11 P34/ /	ALL
D03084	1	BACS16W1 RELAY SOCKET	81205	1	49-41-11 E6 RLY/PNL/	001-099
D03084	1	BACS16W1 RELAY SOCKET	81205	1	49-41-11 E6/ /	115-199
D03086	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 983/155/R035	001-099
D03088	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 983/147/R036	001-099
D03090	1	BACC63CE12SA3S PLUG	81205	1	21-52-11 982/151/R036	001-099
D03092	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 971/150/R038	001-099
D03094	1	BACC45FT12A12S PLUG	81205	1	21-45-11 P14/ /	ALL

EQUIPMENT LIST

D280N032

Section D03000

Page 5 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03100	1	BACC63BP12A3S7L PLUG	81205	1	29-11-12 N252/ /	ALL
D03100 T		BACC10HF12A CABLE CLAMP	81205	1	29-11-12 N252/ /	001-099
D03100 T		BACC10HF12A CABLE CLAMP	81205	1	29-11-12 */ /	115-199
D03102	1	BACC63BP12A3S7L PLUG	81205	1	29-11-12 1067.6/174/L059	ALL
D03102 T		BACC10HG12 CABLE CLAMP-	81205	1	29-11-12 */ */	ALL
D03106	1	BACC45FT16-24S6 PLUG	81205	1	29-11-12 P032-00/ /	ALL
D03114	1	BACS16X1A RELAY SOCKET	81205	1	29-11-12 P33/ /	ALL
D03118	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-002
D03118	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P037-00/ /	003-099
D03118	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P37/ /	115-199
D03120	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 983/155/L39	001-099
D03122	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 983/147/L39	001-099
D03124	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 982/151/L39	001-099
D03126	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 971/150/L37	001-099
D03130	1	BACS16X1A RELAY SOCKET	81205	1	29-22-11 P33/ /	ALL
D03136	1	BACC63BP12A3S9L PLUG	81205	1	29-22-11 1065/173/L005	ALL
D03136 T		BACC10HG12 CABLE CLAMP-	81205	1	29-22-11 */ */	ALL

EQUIPMENT LIST

D280N032

Section D03100

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03140	1	BACC63BP12A3S9L PLUG	81205	1	29-22-11 1065/173/L005	ALL
D03140 T		BACC10HG12 CABLE CLAMP	81205	1	29-22-11 */*/	ALL
D03142	1	BACC63BP16A10SNL PLUG	81205	1	29-22-11 1054.5/174/R005	ALL
D03142 T		BACC10HF16 CABLE CLAMP-	81205	1	29-22-11 1054.5/174/R005	ALL
D03152	1	BACC45FT12A12S PLUG	81205	1	21-45-11 P13/ /	ALL
D03154	1	BACC63CE12S-3S PLUG	81205	1	21-65-11 P005-00/ /	001-099
D03154	1	BACC63CE12S-3S PLUG	81205	1	21-65-11 P5/270/L20	115-199
D03156	1	BACC63CE12S-3S PLUG-	81205	1	21-65-11 512/274/R35	001-099
D03156	1	BACC63CE12S-3S PLUG-	81205	1	21-65-11 540/274/R35	115-199
D03158	1	BACC63CE12S-3S PLUG-	81205	1	21-65-11 1177/275/R45	ALL
D03192	1	BACC63BP14A7SNL PLUG	81205	1	27-62-11 IRSS230/ /	ALL
D03192 T		BACC10HG14 CABLE CLAMP	81205	1	27-62-11 */ /	ALL
D03194	1	BACS16W1 RELAY SOCKET (PLATE 'D')	81205	1	27-62-11 P36/ /	ALL
D03196	1	BACS16W1 RELAY SOCKET (PLATE 'D')	81205	1	27-62-11 P36/ /	ALL
D03198	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	27-62-11 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D03100
Page 2 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03200	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	27-62-11 P36/ /	ALL
D03202	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	27-62-11 P36/ /	ALL
D03204	1	BACC45FN12-12S6 RCPT	81205	1	27-62-11 P010-00/ /	ALL
D03206	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	27-62-11 P037-00/ /	001-099
D03206	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	27-62-11 P37/ /	115-199
D03208	1	BACC63BP14A7SNL PLUG	81205	1	27-62-11 IRSS230/ /	ALL
D03208 T		BACC10HG14 CABLE CLAMP	81205	1	27-62-11 IRSS230/ /	ALL
D03210	1	BACC66K31C50 PLUG PLATE ASSY	81205	1	32-09-11 E003-04/ /	ALL
D03210A	1	PARTAOFD03210 PLUG		0	32-09-11 E003-04/ /	ALL
D03210B	1	PARTBOFD03210 PLUG		0	32-09-11 E003-04/ /	ALL
D03210C	1	PARTCOFD03210 PLUG		0	32-09-11 E003-04/ /	001-099
D03210D	1	PARTDOFD03210 PLUG		0	32-09-11 E003-04/ /	ALL
D03210E	1	PARTEOFD03210 PLUG		0	32-09-11 E003-04/ /	ALL
D03210F	1	PARTFOFD03210 PLUG		0	32-09-11 E003-04/ /	001-099
D03212	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	30-32-11 P037-00/ /	001-099
D03212	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	30-32-11 P37/ /	115-199
D03220	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P037-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D03200

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03220	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P37/ /	115-199
D03222	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P037-00/ /	001-099
D03222	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P37/ /	115-199
D03230	1	BACC45FS10D5S PLUG (PLATE 'E')	81205	1	21-33-12 P36/ /	001-099
D03230	1	BACC45FS10-5S PLUG (PLATE 'E')	81205	1	21-33-12 P36/ /	115-199
D03232	1	BACC45FT10A5S6 PLUG	81205	1	26-21-11 P008-00/ /	ALL
D03234	1	BACC45FT12A12S7 PLUG	81205	1	26-21-11 P008-00/ /	ALL
D03242	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	29-21-31 P36/ /	ALL
D03244	1	BACS16X1A RELAY SOCKET	81205	1	29-21-31 P33/ /	ALL
D03248	1	BACC63BP14A7SNL PLUG-	81205	1	29-21-31 1180/185/R050	ALL
D03248 T		BACC10HG14 CABLE CLAMP-	81205	1	29-21-31 */*/	001-099
D03248 T		BACC10HG14A CABLE CLAMP-	81205	1	29-21-31 */*/	115-199
D03252	1	BACC63BP16A10SNL PLUG-	81205	1	29-21-31 1180/150/R50	ALL
D03252 T		BACC10HG16 CABLE CLAMP-	81205	1	29-21-31 1180/150/R50	ALL
D03254	1	BACC63BP14A7SNL PLUG-	81205	1	29-21-31 1235/147/R35	ALL
D03254 T		BACC10HG14 CABLE CLAMP-	81205	1	29-21-31 1235/147/R35	ALL
D03258	1	BACC66H21C5201 PLUG PLATE ASSY	81205	1	27-51-61 E005-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D03200

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03258	1	BACC66H21C5201 PLUG PLATE ASSY	81205	1	27-51-61 E5-3/ /	115-199
D03258A	1	PARTAOFD03258 PLUG-		0	27-51-61 E005-03/ /	001-099
D03258A	1	PARTAOFD03258 PLUG-		0	27-51-61 E5-3/ /	115-199
D03258B	1	PARTBOFD03258 PLUG-		0	27-51-61 E005-03/ /	001-099
D03258B	1	PARTBOFD03258 PLUG-		0	27-51-61 E5-3/ /	115-199
D03258C	1	PARTCOFD03258 PLUG-		0	27-51-61 E005-03/ /	001-099
D03258C	1	PARTCOFD03258 PLUG-		0	27-51-61 E5-3/ /	115-199
D03260	1	BACC66H21C5201 PLUG PLATE ASSY	81205	1	27-51-11 E5-2/ /	001-099
D03260	1	BACC66H21C5201 PLUG-	81205	1	27-51-11 E5-2/ /	115-199
D03260A	1	PARTAOFD03260 PLUG-		0	27-51-11 E5-2/ /	ALL
D03260B	1	PARTBOFD03260 PLUG-		0	27-51-11 E5-2/ /	ALL
D03260C	1	PARTCOFD03260 PLUG-		0	27-51-11 E5-2/ /	ALL
D03262	1	BACC45FS10A5S PLUG	81205	1	33-24-11 P034-00/ /	001-099
D03262	1	BACC45FS10A5S PLUG	81205	1	33-24-11 P34/ /	115-199
D03270	1	CWC01-1210 PLUG	71771	1	30-41-12 231/260/R040	ALL
D03270 T		0712 INSULATOR CAP	81323	1	30-41-12 */ */ *	ALL
D03272	1	CWC01-1210 PLUG	71771	1	30-41-12 231/270/R040	ALL

EQUIPMENT LIST

D280N032

Section D03200

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03272 T		0712 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03274	1	CWC01-1210 PLUG	71771	1	30-41-12 231/260/R040	ALL
D03274 T		0712 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03276	1	CWC02-2006 PLUG	71771	1	30-41-12 231/270/R040	ALL
D03276 T		1235 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03278	1	CWC02-2006 PLUG	71771	1	30-41-12 231/270/R040	ALL
D03278 T		1235 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03280	1	CWC02-2010 PLUG	71771	1	30-41-11 231/250/R040	ALL
D03280 T		1225 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D03282	1	CWC02-2006 PLUG	71771	1	30-41-11 231/250/R040	ALL
D03282 T		1235 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D03284	1	CWC02-2006 PLUG	71771	1	30-41-11 231/250/R040	ALL
D03284 T		1235 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D03286	1	CWC01-2010 PLUG	71771	1	30-41-11 231/250/R040	ALL
D03286 T		0712 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D03288	1	CWC02-2006 PLUG	71771	1	30-41-11 231/250/R040	ALL
D03288 T		1235 INSULATOR CAP	81323	1	30-41-11 */*/	ALL

EQUIPMENT LIST

D280N032

Section D03200

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03290	1	CWC02-2006 PLUG	71771	1	30-41-11 231/250/R040	ALL
D03290 T		1235 INSULATOR CAP	81323	1	30-41-11 */*/	ALL

EQUIPMENT LIST

D280N032

Section D03200

Page 5 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03300	1	BACS16W1 RELAY SOCKET	81205	1	30-32-11 P33/ /	ALL
D03312	1	BACC66H21C5201 PLUG-	81205	1	27-58-31 E5-1/ /	ALL
D03312A	1	PARTAOFD03312 PLUG-		0	27-58-31 E5-1/ /	ALL
D03312B	1	PARTBOFD03312 PLUG-		0	27-58-31 E5-1/ /	ALL
D03312C	1	PARTCOFD03312 PLUG-		0	27-58-31 E5-1/ /	ALL
D03314	1	BACC63BP10A5S10L PLUG	81205	1	21-61-51 903/164/L17	ALL
D03314 T		BACC10HG10 CABLE CLAMP	81205	1	21-61-51 */*/	ALL
D03322	1	CWC01-1210 PLUG	71771	1	30-41-11 231/230/L050	ALL
D03322 T		0712 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D03324	1	CWC01-1210 PLUG	71771	1	30-41-11 231/230/L050	ALL
D03324 T		0712 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D03326	1	CWC01-1210 PLUG	71771	1	30-41-11 231/230/L050	ALL
D03326 T		0712 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D03328	1	CWC02-2006 PLUG	71771	1	30-41-11 231/230/L050	ALL
D03328 T		1235 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D03330	1	CWC02-2006 PLUG	71771	1	30-41-11 231/230/L050	ALL
D03330 T		1235 INSULATOR CAP	81323	1	30-41-11 */*/	ALL

EQUIPMENT LIST

D280N032

Section D03300

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03332	1	CWC02-2010 PLUG	71771	1	30-41-12 231/250/L040	ALL
D03332 T		1225 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03334	1	CWC02-2006 PLUG	71771	1	30-41-12 231/235/L040	ALL
D03334 T		1235 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03336	1	CWC02-2006 PLUG	71771	1	30-41-12 231/235/L040	ALL
D03336 T		1235 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03338	1	CWC01-2010 PLUG	71771	1	30-41-12 255/230/L40	ALL
D03338 T		0712 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03340	1	CWC02-2006 PLUG	71771	1	30-41-12 255/230/L40	ALL
D03340 T		1235 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03342	1	CWC02-2006 PLUG	71771	1	30-41-12 255/230/L40	ALL
D03342 T		1235 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D03352	1	BACC63CE22A2S PLUG	81205	1	32-35-11 1073/147/R006	ALL
D03396	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 942/156/L024	ALL
D03398	1	BACC63BP12A3SNL PLUG	81205	1	29-11-12 1065/160/L063	ALL
D03398 T		BACC10HG-12 CABLE CLAMP	81205	1	29-11-12 1065/160/L063	ALL

EQUIPMENT LIST

D280N032

Section D03300

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03400	1	BACC63BP12A3SNL PLUG	81205	1	29-32-21 1065/160/R063	001-099
D03400	1	BACC63BP12A3SNL PLUG	81205	1	29-11-22 1065/160/R063	115-199
D03400 T		BACC10HG-12 CABLE CLAMP	81205	1	29-32-21 */*/	001-099
D03400 T		BACC10HG-12 CABLE CLAMP	81205	1	29-11-22 */*/	115-199
D03402	1	BACC63BP12A3SNL PLUG-	81205	1	29-32-31 1245/141/L052	ALL
D03402 T		BACC10HG12 CABLE CLAMP	81205	1	29-32-31 */*/	ALL
D03404	1	BACC63BP12A3SNL PLUG	81205	1	29-32-31 1250/148/L052	001-099
D03404	1	BACC63BP12A3SNL PLUG	81205	1	29-11-31 1250/148/L052	115-199
D03404 T		BACC10HG12 CABLE CLAMP	81205	1	29-32-31 */*/	001-099
D03404 T		BACC10HG12 CABLE CLAMP	81205	1	29-11-31 */*/	115-199
D03406	1	BACC45FT12-12S PLUG	81205	1	33-11-21 217.6/213/R7	001-099
D03406	1	BACC45FT12-12S PLUG	81205	1	33-11-21 P3-1/ /	115-199
D03406 T		BACC10GH12 CABLE CLAMP	81205	1	33-11-21 */*/	001-099
D03406 T		BACC10GH12 CABLE CLAMP	81205	1	33-11-21 P3-1/ /	115-199
D03408	1	BACC45FT12A12S PLUG	81205	1	33-13-32 270/265/R25	001-099
D03408	1	BACC45FT12A12S PLUG	81205	1	33-13-32 P5/ /	115-199
D03410	1	BACC45FT12A12S PLUG	81205	1	33-13-31 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D03400

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03410	1	BACC45FT12A12S PLUG	81205	1	33-13-31 P5/ /	115-199
D03412	1	BACC45FT12D12S PLUG	81205	1	33-13-31 P005-00/ /	001-099
D03412	1	BACC45FT12D12S PLUG	81205	1	33-13-31 P5/ /	115-199
D03414	1	BACC45FT12D12S PLUG	81205	1	33-13-32 270/270/R25	001-099
D03414	1	BACC45FT12D12S PLUG	81205	1	33-13-32 P5/ /	115-199
D03428	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 942/156/R060	ALL
D03430	1	BACC63BP12A3SNL PLUG	81205	1	27-23-11 1862.7/265/R023	ALL
D03430 T		BACC10HG12 CABLE CLAMP	81205	1	27-23-11 */*/	ALL
D03432	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-11 1862.7/275/L010	ALL
D03432 T		BACC10HF12A CABLE CLAMP	81205	1	27-23-11 1862.7/275/L010	ALL
D03434	1	BACC63BP12A3S10L PLUG	82105	1	27-23-11 1862.7/265/R023	ALL
D03434 T		BACC10HG12 CABLE CLAMP	81205	1	27-23-11 */*/	ALL
D03436	1	BACC63BP12A3S10L PLUG-	81205	1	27-23-11 1862.7/275/L010	ALL
D03436 T		BACC10HF12A CABLE CLAMP	81205	1	27-23-11 1862.7/275/L010	ALL
D03438	1	BACC45FT12A12S PLUG-	81205	1	33-22-11 355/295/L10	001-099
D03438	1	BACC45FT12A12S PLUG-	81205	1	33-22-11 355/295/L010	115-199
D03440	1	BACC45FT18A14P PLUG-	81205	69	33-23-31 MULTI/ /	001-003, 005, 007-008

EQUIPMENT LIST

D280N032

Section D03400

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03440	1	BACC45FT18A14P PLUG-	81205	68	33-23-31 MULTI/ /	004, 006
D03440	1	BACC45FT18A14P PLUG-	81205	70	33-23-31 MULTI/ /	009-099
D03440	1	BACC45FT20A16P PLUG-PASSENGER SERVICE UNIT U/B	81205	72	33-23-31 MULTI/ /	115-199
D03442	1	BACC45FT18A14P PLUG-	81205	2	33-23-31 MULTI/ /	001-099
D03442	1	BACC45FT20A16P PLUG-PASSENGER SERVICE UNIT U/B	81205	2	33-23-31 MULTI/ /	115-199
D03446	1	BACC45FT18A14P PLUG-	81205	6	33-23-36 MULTI/ /	001-099
D03446	1	BACC45FT20A16P PLUG-	81205	6	33-23-31 MULTI/ /	115-199
D03448	1	BACC45FT20A16P PLUG-ATTENDANT SERVICE UNIT (U/B)	81205	1	33-23-31 MULTI/ /	115-199
D03450	1	BACC45FT18A14P PLUG-PASSENGER SERVICE UNIT O/D	81205	1	33-23-34 MULTI/ /	001-099
D03450	1	BACC45FT20A16P PLUG-PASSENGER SERVICE UNIT O/D	81205	3	33-23-31 MULTI/ /	115-199
D03452	1	BACC45FT18A14P PLUG-PASSENGER SERVICE UNIT O/D	81205	2	35-21-31 MULTI/ /	001-099
D03456	1	BACC45FN20-41S RCPT-	81205	1	33-22-11 355/285/L40	115-199
D03460	1	BACC45FT18A14P PLUG-	81205	1	33-25-14 1258/290/L40	001-099
D03462	1	BACC45FT18A14P PLUG-	81205	1	33-23-13 1287/265/L60	001-099
D03462	1	BACC45FT20A16P PLUG	81205	1	33-25-14 1295/290/L45	115-199
D03468	1	BACC45FT18A14P PLUG-	81205	1	33-23-23 1285/265/R60	001-099
D03468	1	BACC45FT20A16P PLUG-	81205	1	33-25-24 1295/298/R30	115-199

EQUIPMENT LIST

D280N032

Section D03400

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03472	1	BACC45FN12-12P RCPT-	81205	1	33-22-11 MULTI/ /	001-099
D03472	1	BACC45FN12-12P RCPT-	81205	2	33-22-11 355/288/L14	115-199
D03474	1	BACC45FN12-12P RCPT-	81205	1	33-27-11 347/289/R019	001-005, 007-099
D03474	1	BACC45FN12-12P RCPT-	81205	2	33-27-11 347/289/R019	006, 115-199
D03478	1	BACC45FN12-12P RCPT-	81205	1	33-27-31 1669/290/L3	ALL
D03486	1	BACC45FT18A14P PLUG-	81205	1	33-23-31 MULTI/ /	004-099
D03490	1	BACC45FT10A5S9 PLUG	81205	1	26-11-11 P008-00/ /	ALL
D03492	1	BACC45FT14A15S PLUG	81205	1	26-12-21 P008-00/ /	ALL
D03494	1	BACC45FT10A5S8 PLUG	81205	1	26-15-11 P008-00/ /	001-099
D03494	1	BACC45FT10A5S8 PLUG	81205	1	26-15-11 P8/ /	115-199
D03496	1	BACC45FT18A31S6 PLUG	81205	1	31-51-33 P008-00/ /	ALL
D03498	1	BACC45FT18A31S7 PLUG	81205	1	31-51-33 P008-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D03400

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03500	1	BACC45FT22A55S6 PLUG	81205	1	24-51-71 P005-00/ /	001-099
D03500	1	BACC45FT22A55S6 PLUG	81205	1	24-51-71 P5/ /	115-199
D03501	1	BACC45FT14D15S6 PLUG	81205	1	33-42-21 P005-00/ /	001-099
D03501	1	BACC45FT14D15S6 PLUG	81205	1	33-42-21 P5/ /	115-199
D03502	1	BACC45FT22A55S7 PLUG	81205	1	24-22-22 P005-00/ /	001-099
D03502	1	BACC45FT22A55S7 PLUG	81205	1	24-22-22 P5/ /	115-199
D03503	1	BACC45FT14D15S8 PLUG	81205	1	33-42-21 P005-00/ /	001-099
D03503	1	BACC45FT14D15S8 PLUG	81205	1	33-42-21 P5/ /	115-199
D03504	1	BACC45FT16A10S PLUG	81205	1	24-11-21 P005-00/ /	001-099
D03504	1	BACC45FT16A10S PLUG	81205	1	24-11-21 P5/ /	115-199
D03505	1	BACC45FT16A24S9 PLUG	81205	1	33-44-21 P5/ /	001-099
D03505	1	BACC45FT20A25S6 PLUG	81205	1	33-44-21 P5/ /	115-199
D03506	1	BACC45FT16A24S6 PLUG	81205	1	33-44-21 P005-00/ /	001-099
D03506	1	BACC45FT16A24S6 PLUG	81205	1	33-44-21 P5/ /	115-199
D03507	1	BACC45FT16A24S PLUG	81205	1	33-41-11 P005-00/ /	001-099
D03507	1	BACC45FT18A14S PLUG	81205	1	33-41-11 P5/ /	115-199
D03508	1	BACC45FT20A41S PLUG	81205	1	24-33-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D03500

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03508	1	BACC45FT20A41S PLUG	81205	1	24-33-11 P5/ /	115-199
D03510	1	BACC45FT20A39S PLUG	81205	1	28-41-11 P5/ /	115-199
D03511	1	BACC45FT12A12S7 PLUG	81205	1	22-21-11 P005-00/ /	001-099
D03511	1	BACC45FT12A12S7 PLUG	81205	1	22-21-11 P5/ /	115-199
D03512	1	BACC45FT20A28S7 PLUG	81205	1	28-42-11 P005-00/ /	001-099
D03512	1	BACC45FT20A28S7 PLUG	81205	1	28-42-11 P5/ /	115-199
D03513	1	BACC45FT14A15S7 PLUG	81205	1	22-21-21 P005-00/ /	001-099
D03513	1	BACC45FT14A15S7 PLUG	81205	1	22-21-21 P5/ /	115-199
D03514	1	BACC45FT20A28S8 PLUG	81205	1	28-42-11 P005-00/ /	001-099
D03514	1	BACC45FT20A28S8 PLUG	81205	1	28-42-11 P5/ /	115-199
D03516	1	BACC45FT14A15S10 PLUG	81205	1	28-22-31 P005-00/ /	001-099
D03516	1	BACC45FT14A15S10 PLUG	81205	1	28-22-31 P5/ /	115-199
D03517	1	BACC45FT14A15S PLUG	81205	1	33-24-11 P005-00/ /	001-099
D03517	1	BACC45FT14A15S PLUG	81205	1	33-24-11 P5/ /	115-199
D03518	1	BACC45FT16A24S10 PLUG	81205	1	21-58-12 P005-00/ /	001-099
D03518	1	BACC45FT16A24S10 PLUG	81205	1	21-58-12 P5/ /	115-199
D03520	1	BACC45FT14D12S6 PLUG	81205	1	30-42-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D03500

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03520	1	BACC45FT14D12S6 PLUG	81205	1	30-42-11 P5/ /	115-199
D03521	1	BACS16AF1 SOCKET-TERR WXR	81205	1	34-46-14 P065-00/ /	002
D03522	1	BACC45FT14D12S8 PLUG	81205	1	30-42-11 P5/ /	ALL
D03525	1	BACS16AF1 SOCKET-TERR WXR		1	34-46-14 P065-00/ /	002
D03528	1	BACC45FT14A15S PLUG	81205	1	30-21-11 P005-00/ /	001-099
D03528	1	BACC45FT14A15S PLUG	81205	1	30-21-11 P5/ /	115-199
D03530	1	BACC45FT14A15S7 PLUG	81205	1	30-21-11 P005-00/ /	001-099
D03530	1	BACC45FT14A15S7 PLUG	81205	1	30-21-11 P5/ /	115-199
D03532	1	BACC45FT18D31S8 PLUG	81205	1	52-51-11 P005-00/ /	001-099
D03532	1	BACC45FT18D31S8 PLUG	81205	1	52-51-11 P5/ /	115-199
D03534	1	BACC45FT18D31S10 PLUG	81205	1	52-51-11 P005-00/ /	001-099
D03534	1	BACC45FT18D31S10 PLUG	81205	1	52-51-11 P5/ /	115-199
D03536	1	BACC45FT20A39S6 PLUG	81205	1	28-11-11 P5/ /	115-199
D03538	1	BACC45FT16A24S9 PLUG	81205	1	36-11-11 P005-00/ /	001-099
D03538	1	BACC45FT16A24S9 PLUG	81205	1	36-11-11 P5/ /	115-199
D03540	1	BACC45FT12A12S10 PLUG	81205	1	36-11-11 P005-00/ /	001-099
D03540	1	BACC45FT12A12S10 PLUG	81205	1	36-11-11 P5/ /	115-199

EQUIPMENT LIST

D280N032

Section D03500

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03542	1	BACC45FT12A12S9 PLUG	81205	1	36-11-41 P005-00/ /	001-099
D03542	1	BACC45FT12A12S9 PLUG	81205	1	36-11-41 P5/ /	115-199
D03544	1	BACC45FT20D41S6 PLUG	81205	1	29-11-22 P005-00/ /	001-099
D03544	1	BACC45FT20D41S6 PLUG	81205	1	29-11-23 P5/ /	115-199
D03546	1	BACC45FT20D39S7 PLUG	81205	1	29-11-31 P005-00/ /	001-099
D03546	1	BACC45FT20D39S7 PLUG	81205	1	29-11-31 P5/ /	115-199
D03548	1	BACC45FT20D28S PLUG	81205	1	29-32-31 P005-00/ /	001-099
D03548	1	BACC45FT20D28S PLUG	81205	1	29-32-31 P5/ /	115-199
D03550	1	BACC45FT12A12S8 PLUG	81205	1	30-11-11 P005-00/ /	001-099
D03550	1	BACC45FT12A12S8 PLUG	81205	1	30-11-11 P5/ /	115-199
D03552	1	BACC45FT18A31S9 PLUG	81205	1	30-41-11 P5/ /	ALL
D03554	1	BACC45FT20D41S7 PLUG	81205	1	30-41-12 P005-00/ /	001-099
D03554	1	BACC45FT20D41S7 PLUG	81205	1	30-41-12 P5/ /	115-199
D03556	1	BACC45FT22A55S10 PLUG	81205	1	21-51-15 P005-00/ /	001-099
D03556	1	BACC45FT22A55S10 PLUG	81205	1	21-51-15 P5/ /	115-199
D03558	1	BACC45FT22A55S9 PLUG	81205	1	21-51-25 P005-00/ /	001-099
D03558	1	BACC45FT22A55S9 PLUG	81205	1	21-51-25 P5/ /	115-199

EQUIPMENT LIST

D280N032

Section D03500

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03562	1	BACC45FT14D12S9 PLUG	81205	1	27-61-12 P005-00/ /	001-099
D03562	1	BACC45FT14D12S9 PLUG	81205	1	27-61-12 P5/ /	115-199
D03564	1	BACC45FT14D12S7 PLUG	81205	1	30-31-11 P5/ /	ALL
D03566	1	BACC45FT20D41S8 PLUG	81205	1	52-71-11 P005-00/ /	001-099
D03566	1	BACC45FT20D41S8 PLUG	81205	1	52-71-11 P5/ /	115-199
D03572	1	BACC45FT20A41S10 PLUG	81205	1	80-11-11 P005-00/ /	001-099
D03572	1	BACC45FT20A41S10 PLUG	81205	1	80-11-11 P5/ /	115-199
D03574	1	BACC45FT20A39S6 PLUG	81205	1	74-31-21 P005-00/ /	001-099
D03574	1	BACC45FT20A39S10 PLUG	81205	1	74-31-21 P-5/ /	115-199
D03576	1	BACC45FT18A31S6 PLUG	81205	1	49-61-11 P005-00/ /	001-099
D03576	1	BACC45FT12A12S8 PLUG	81205	1	49-61-11 P5/ /	115-199
D03578	1	BACC45FT14A15S PLUG	81205	1	21-65-11 P005-00/ /	001-099
D03578	1	BACC45FT14A15S PLUG	81205	1	21-65-11 P5/ /	115-199
D03580	1	BACC45FT12A12S PLUG	81205	1	74-31-11 P005-00/ /	001-099
D03580	1	BACC45FT10A5S8 PLUG	81205	1	74-31-11 P005-00/ /	115-199
D03582	1	BACC45FT12A12S9 PLUG	81205	1	74-31-21 P005-00/ /	001-099
D03582	1	BACC45FT10A5S9 PLUG	81205	1	74-31-21 P005-00/ /	115-199

EQUIPMENT LIST

D280N032

Section D03500

Page 5

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03584	1	BACC45FT14A15S9 PLUG	81205	1	28-41-11 P5/ /	115-199
D03586	1	BACC45FT10A5S8 PLUG	81205	1	33-16-52 P005-00/ /	001-099
D03586	1	BACC45FT10A5S8 PLUG	81205	1	33-16-52 P5/ /	115-199

EQUIPMENT LIST

D280N032

Section D03500

Page 6 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03702	1	BACC45FT20A41S6 PLUG	81205	1	34-12-12 P061-00/ /	ALL
D03704	1	BACC45FT20A41S7 PLUG	81205	1	30-11-11 P061-00/ /	ALL
D03706	1	BACC45FT20A41S8 PLUG	81205	1	31-51-42 P061-00/ /	001-099
D03706	1	BACC45FT20A41S8 PLUG	81205	1	31-51-42 P61/ /	115-199
D03708	1	BACC45FT16A24S6 PLUG	81205	1	24-22-11 P061-00/ /	ALL
D03710	1	BACC45FT16A24S7 PLUG	81205	1	24-22-21 P061-00/ /	ALL
D03712	1	BACC45FT14A15S6 PLUG	81205	1	27-23-11 P61/ /	ALL
D03714	1	BACC45FT16-24S8 PLUG	81205	1	24-22-41 P061-00/ /	001-099
D03714	1	BACC63BN16-24S8 PLUG	81205	1	24-22-41 P61/ /	115-199
D03714 T		BACC10GH16 CABLE CLAMP	81205	1	24-22-41 */ /	ALL
D03734	1	BACC45FT14A15S7 PLUG	81205	1	26-21-11 P061-00/ /	001-099
D03734	1	BACC45FT14A15S7 PLUG	81205	1	26-21-11 P61/ /	115-199
D03736	1	BACC45FT14A15S9 PLUG	81205	1	26-21-11 P061-00/ /	001-099
D03736	1	BACC45FT14A15S9 PLUG	81205	1	26-21-11 P61/ /	115-199

EQUIPMENT LIST

D280N032

Section D03700

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03804	1	172168-1 PLUG-	00779	1	33-21-41 440/263/R360	ALL
D03806	1	172160-1 RCPT-	00779	1	33-21-41 440/263/R60	ALL
D03808	1	172168-1 PLUG-	00779	1	33-21-41 640/268/R60	ALL
D03810	1	172160-1 RCPT-	00779	1	33-21-41 640/268/R60	ALL
D03812	1	172160-1 RCPT-	00779	1	33-21-32 440/268/L60	ALL
D03814	1	172168-1 PLUG-	00779	1	33-21-32 440/268/L60	ALL
D03816	1	172160-1 RCPT-	00779	1	33-21-32 640/268/L60	ALL
D03818	1	172168-1 PLUG-	00779	1	33-21-32 640/268/L60	ALL

EQUIPMENT LIST

D280N032

Section D03800

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03925		BACC63CB22-55SN PLUG-	81205	1	34-12-61 E002-04/ /	ALL
D03927		BACC63CB22-55SN PLUG-	81205	1	34-12-62 E002-04/ /	ALL

EQUIPMENT LIST

D280N032

Section D03900
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04006	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-41 P037-00/ /	001-099
D04006	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-41 P37/ /	115-199
D04008	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-21 P037-00/ /	001-099
D04008	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	36-11-21 P37/ /	115-199
D04010P	1	BACC45FT22-19S PLUG-	81205	1	24-51-72 P006-04/ /	ALL
D04012	1	BACC45FT10-5S CREW OXYGEN PRESSURE IND.	81205	1	35-11-13 623/188/R54	115-199
D04012 T		BACC10GH10 CLAMP-	81205	1	35-11-13 623/ /	115-199
D04014	1	BACS16X3A PLUG-	81205	1	33-22-11 MULTI/ /	001-099
D04014	1	BACS16X3A PLUG-	81205	2	33-22-11 355/288/L14	115-199
D04015	1	BACS16AG1 RELAY SOCKET (PLATE B)	81205	1	31-31-41 P037-00/ /	010-099
D04016	1	BACC45FT12A12S9 PLUG-	81205	1	33-22-11 MULTI/ /	001-099
D04016	1	BACC45FT12A12S9 PLUG-	81205	2	33-22-11 355/288/L14	115-199
D04018	1	BACC45FT12A12S9 PLUG-	81205	1	33-22-11 MULTI/ /	001-099
D04018	1	BACC45FT12A12S9 PLUG-	81205	2	33-22-11 355/288/L14	115-199
D04020		7487 RCPT-SERVICE OUTLET,28V DC	287N4102 74545	1	25-29-11 P006-00/ /	ALL
D04028	1	BACC45FT12A12S10 PLUG-	81205	1	33-27-11 347/289/R019	001-005, 007-099
D04028	1	BACC45FT12A12S10 PLUG-	81205	2	33-27-11 347/289/R019	006, 115-199

EQUIPMENT LIST

D280N032

Section D04000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04030	1	BACC45FT12A12S10 PLUG-	81205	1	33-27-11 347/289/R019	001-005, 007-099
D04030	1	BACC45FT12A12S10 PLUG-	81205	2	33-27-11 347/289/R019	006, 115-199
D04036	1	BACC45FT12A12S7 PLUG-	81205	1	33-27-31 1665/290/0	ALL
D04038	1	BACS16X3A RCPT-	81205	1	33-27-11 347/289/R019	001-005, 007-099
D04038	1	BACS16X3A RCPT-	81205	2	33-27-11 347/289/R019	006, 115-199
D04040	1	BACS16X3A SOCKET-	81205	1	33-27-11 347/289/R019	001-005, 007-099
D04040	1	BACS16X3A SOCKET-	81205	2	33-27-11 347/289/R019	006, 115-199
D04044	1	BACS16X3A RCPT-	81205	1	33-27-31 1669/290/L4	ALL
D04046	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-002
D04046	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-23 P037-00/ /	003-099
D04046	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D04052	1	BACS16AF1 RELAY SOCKET (PLATE 'D')	81205	1	21-51-12 P36/ /	001-099
D04052	1	BACS16AF1 RELAY SOCKET	81205	1	21-51-12 E6/ /	115-199
D04054	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-24 960/148/R031	ALL
D04054 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-24 */*/	ALL
D04056	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-24 982/151/R045	ALL
D04056 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-24 */*/	ALL

EQUIPMENT LIST

D280N032

Section D04000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04058	1	BACC63BP10A5SNL PLUG	81205	1	21-51-24 966/143/R035	ALL
D04058 T		BACC10HF10 CABLE CLAMP	81205	1	21-51-24 */*/	ALL
D04060	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-51-24 P037-00/ /	001-099
D04060	1	BACS16AG1 RELAY SOCKET	81205	1	21-51-24 E6/ /	115-199
D04062	1	BACC63BP28A42S6L PLUG	81205	1	73-21-22 480/157/L036	ALL
D04062 T		BACC10HG28 CABLE CLAMP	81205	1	73-21-22 */*/	ALL
D04064	1	BACC63BP24A30S6L PLUG	81205	1	73-21-21 480/157/L036	ALL
D04064 T		BACC10HG24 CABLE CLAMP	81205	1	73-21-21 */*/	ALL
D04066	1	BACC63BP14A7S6L PLUG	81205	1	75-31-11 480/157/L036	ALL
D04066 T		BACC10HG14 CABLE CLAMP	81205	1	75-31-11 */*/	ALL
D04078	1	BACC65L66 PLUG	81205	1	26-15-11 P54/ /	ALL
D04080	1	BACC63BP12A3SNL PLUG	81205	1	29-21-31 1180/138/R18	ALL
D04080 T		BACC10HF12 CABLE CLAMP-	81205	1	29-21-31 1180/138/R18	ALL
D04082	1	BACC63BP12A3S7L PLUG-	81205	1	29-21-31 1177/156/R16	ALL
D04082 T		BACC10HG12 CABLE CLAMP-	81205	1	29-21-31 1177/156/R16	ALL
D04084	1	BACC63BP14A7SNL PLUG-	81205	1	29-21-31 1180/138/R18	ALL
D04084 T		BACC10HF14 CABLE CLAMP-	81205	1	29-21-31 1180/138/R18	ALL

EQUIPMENT LIST

D280N032

Section D04000

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04086	1	CN0966A12A03SN-000 PLUG	13556	1	29-21-31 1214/154/R050	ALL
D04086 T		BACC10HG12 CABLE CLAMP	81205	1	29-21-31 */*/*	ALL
D04088		CN0966A12A03SN-000 PLUG-	13556	1	29-21-31 1214/154/R50	ALL
D04088 T		BACC10HG12 CABLE CLAMP-	81205	1	29-21-31 1214/154/R50	ALL
D04090	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-099
D04090	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D04094	1	BACC45FT14-7S PLUG	81205	1	27-51-61 P070-00/ /	ALL
D04096	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	21-51-22 P037-00/ /	001-099
D04096	1	BACS16AF1 RELAY SOCKET	81205	1	21-51-22 E6/ /	115-199
D04098	1	BACC63BP12A3SNL PLUG	81205	1	21-51-25 970/151/R036	ALL
D04098 T		BACC10HG12 CABLE CLAMP	81205	1	21-51-25 */*/*	ALL

EQUIPMENT LIST

D280N032

Section D04000

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04104	1	BACC63BP12A3SNL PLUG	81205	1	27-23-11 1862.7/265/L010	ALL
D04104 T		BACC10HG12 CABLE CLAMP	81205	1	27-23-11 */*/	ALL
D04106	1	BACC63BP12A3S10L PLUG	81205	1	27-23-11 1862.7/265/L010	ALL
D04106 T		BACC10HG12 CABLE CLAMP	81205	1	27-23-11 */*/	ALL
D04112	1	BACS16X1A RELAY SOCKET (PLATE 'B')	81205	1	35-11-13 P37/ /	115-199
D04114	1	BACC63BP10A5SNL PLUG	81205	1	21-51-12 895/155/L038	ALL
D04114 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-12 */*/	ALL
D04116	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	36-11-11 P36/ /	ALL
D04118P	1	BACC45FT22-19S PLUG-	81205	1	24-51-72 P006-03/ /	001-099
D04118P	1	BACC45FT22-19S PLUG	81205	1	24-51-72 P006-03/ /	115-199
D04122	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-002
D04122	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-23 P037-00/ /	003-099
D04122	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P37/ /	115-199
D04128	1	BACC63BP10A5S7L PLUG	81205	1	21-51-12 950/156/L61	ALL
D04128 T		BACC10HF10 CABLE CLAMP	81205	1	21-51-12 */*/	ALL
D04130	1	BACC66F11C5001 PLUG	81205	1	21-51-14 E3-3/ /	001-099
D04130	1	BACC66F11C5001 PLUG	81205	1	21-51-14 E6-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D04100

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04130A	1	PARTAOFD04130 PLUG	81205	0	21-51-14 E3-3/ /	001-099
D04130A	1	PARTAOFD04130 PLUG	81205	0	21-51-14 E6-2/ /	115-199
D04130B	1	PARTBOFD04130 PLUG	81205	0	21-51-14 E3-3/ /	001-099
D04130B	1	PARTBOFD04130 PLUG	81205	0	21-51-14 E6-2/ /	115-199
D04130C	1	PARTCOFD04130 PLUG	81205	0	21-51-14 E3-3/ /	001-099
D04130C	1	PARTCOFD04130 PLUG	81205	0	21-51-24 E6-2/ /	115-199
D04132	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-14 946/148/L035	ALL
D04132 T		BACC10HG10 CLAMP	81205	1	21-51-14 */*/	ALL
D04134	1	CN0966A10A20SN-000 PLUG	13556	1	21-51-14 987/151/L47	ALL
D04134 T		BACC10HG10 CLAMP	81205	1	21-51-14 */*/	ALL
D04136	1	BACC63BP10A5SNL PLUG	81205	1	21-51-14 966/143/L25	ALL
D04136 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-14 */*/	ALL
D04138	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	21-51-14 P36/ /	001-099
D04138	1	BACS16AG1 RELAY SOCKET	81205	1	21-51-14 E6/ /	115-199
D04160	1	BACC63BP28A42S6L PLUG	81205	1	73-21-12 456/165/L025	ALL
D04160 T		BACC10HG28 CABLE CLAMP	81205	1	73-21-12 */*/	ALL
D04162	1	BACC63BP24A30S6L PLUG	81205	1	73-21-11 456/165/L025	ALL

EQUIPMENT LIST

D280N032

Section D04100

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04162 T		BACC10HG24 CABLE CLAMP	81205	1	73-21-11 */*/	ALL
D04164	1	BACC63BP14A7S6L PLUG	81205	1	75-31-11 456/165/L025	ALL
D04164 T		BACC10HG14 CABLE CLAMP	81205	1	75-31-11 */*/	ALL
D04172	1	BACS16X1A RELAY SOCKET	81205	1	33-37-21 E6/ /	115-199
D04182	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D04184	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D04194	1	BACC63BP12A3SNL PLUG	81205	1	21-51-15 985/146/L45	ALL
D04194 T		BACC10HF12 CABLE CLAMP	81205	1	21-51-15 */*/	ALL
D04196	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P037-00/ /	001-099
D04196	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P37/ /	115-199
D04198	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-21 P037-00/ /	001-099
D04198	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-21 P37/ /	115-199
D04199		BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	27-62-11 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D04100

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04200	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P037-00/ /	001-099
D04200	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-61-11 P37/ /	115-199
D04201		D38999-26FA98SN PLUG	81205	1	27-62-11 1283/74/140	ALL
D04201 U		287N6102-37 CONDUIT	81205	1	27-62-11 R-MLG/ /MLG	ALL
D04208	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-21 P037-00/ /	001-099
D04208	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-21 P37/ /	115-199
D04210	1	SO-1061-8916 RELAY SOCKET (PLATE 'A')	35344	1	21-58-24 P36/ /	115-199
D04212	1	SO-1061-8916 RELAY SOCKET (PLATE 'A')	35344	1	21-58-24 P37/ /	115-199
D04214	1	BACC45FT18A31S PLUG	81205	1	21-58-24 1635/197/R42	115-199
D04216	1	BACC45FT18D31S PLUG	81205	1	21-58-24 1635/197/R048	115-199
D04222	1	BACC45FT10D5S6 PLUG	81205	1	21-58-11 1614/197/R41	115-199
D04228	1	BACS16X3A RELAY SOCKET (PLATE 'C')	81205	1	74-31-21 P037-00/ /	001-099
D04228	1	BACS16X3A RELAY SOCKET (PLATE 'C')	81205	1	74-31-21 P37/ /	115-199
D04232	1	SO-1061-8916 RELAY SOCKET (PLATE 'A')	35344	1	21-58-21 P037-00/ /	001-099
D04232	1	SO-1061-8916 RELAY SOCKET (PLATE 'A')	35344	1	21-58-21 P37/ /	115-199
D04234	1	SO-1061-8916 RELAY SOCKET (PLATE 'A')	35344	1	21-58-21 P36/ /	ALL
D04236	1	BACC63BP10A5S7L PLUG	81205	1	21-51-22 945/140/R061	ALL

EQUIPMENT LIST

D280N032

Section D04200

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04236 T		BACC10HG10 CABLE CLAMP	81205	1	21-51-22 */ */ *	ALL
D04240	1	BACC66F11C8101 PLUG PLATE ASSY-	81205	1	77-12-11 E4-2/ /	001-099
D04240	1	BACC66F11C0901 PLUG PLATE ASSY-	81205	1	77-31-11 E4-2/ /	115-199
D04240A	1	PARTAOFD04240 PLUG-		1	77-12-11 E4-2/ /	001-099
D04240A	1	PARTAOFD04240 PLUG-		0	77-31-11 E4-2/ /	115-199
D04240B	1	PARTBOFD04240 PLUG-		1	77-12-11 E4-2/ /	001-099
D04240B	1	PARTBOFD04240 PLUG-		0	77-31-11 E4-2/ /	115-199
D04240C	1	PARTCOFD04240 PLUG-		1	77-12-11 E4-2/ /	001-099
D04240C	1	PARTCOFD04240 PLUG-		0	77-31-11 E4-2/ /	115-199
D04242	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	21-58-11 P36/ /	ALL
D04244	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-42 P037-00/ /	001-099
D04244	1	BACS16W1A RELAY SOCKET (PLATE 'C')	81205	1	77-12-42 P37/ /	115-199
D04246	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-42 P037-00/ /	001-099
D04246	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-42 P37/ /	115-199
D04248	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	76-11-21 P037-00/ /	001-099
D04248	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	76-11-21 P37/ /	115-199
D04252	1	BACC65L66 PLUG	81205	1	26-12-21 P54/ /	ALL

EQUIPMENT LIST

D280N032

Section D04200

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04254	1	BACC65L66 PLUG	81205	1	26-16-11 P54/ /	ALL
D04258	1	BACC65L66 RCPT	81205	1	26-18-11 P50/ /	ALL
D04262	1	53CM61 RCPT,115V AC,400CPS,5AMP	284N1360 74545	1	25-29-11 560/191/R057	ALL
D04266	1	BACS16W1A RELAY SOCKET (PLATE 'F')	81205	1	21-58-12 P36/ /	ALL
D04268	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-42-11 P037-00/ /	001-099
D04268	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-42-11 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D04200
Page 3 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04300	1	BACC45FT12A12S PLUG-	81205	1	33-27-22 717/289/L025	115-199
D04306	1	BACS16X3A RELAY SOCKET (PLATE 'D')	81205	1	74-31-11 P36/ /	ALL
D04312	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	77-12-41 P36/ /	001-099
D04312	1	BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	77-12-41 P36/ /	115-199
D04314	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-41 P037-00/ /	001-099
D04314	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-41 P37/ /	115-199
D04316	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-41 P037-00/ /	001-099
D04316	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-41 P37/ /	115-199
D04322	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	76-11-21 P36/ /	ALL
D04330	1	BACC63CD20-4S RCPT-	81205	1	25-31-27 750/295/L035	115-199
D04332	1	BACC45FN12-12S RCPT-	81205	1	25-31-27 750/295/L035	115-199
D04334	1	BACC65L66 PLUG	81205	1	26-12-11 P54/ /	ALL
D04338	1	48-7191 RCPT-	02660	1	35-21-12 358/297/L025	ALL
D04340	1	48-7190 PLUG-	02660	1	35-21-12 358/297/L025	ALL
D04342	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	32-42-11 P36/ /	ALL
D04344	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	30-33-11 P037-00/ /	001-099
D04344	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	30-33-11 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D04300

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04346	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-11 P037-00/ /	001-099
D04346	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-11 P37/ /	115-199
D04348	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-11 P037-00/ /	001-099
D04348	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-61-11 P37/ /	115-199
D04350	1	BACC45FT8A3S PLUG	81205	1	21-61-11 275/280/L015	001-099
D04350	1	BACC45FT8A3S PLUG	81205	1	21-61-11 260/270/L020	115-199
D04354	1	BACS16AF1 RELAY SOCKET (PLATE 'D')	81205	1	32-35-11 P36/ /	ALL
D04360	1	BACC63BP14A7S6L PLUG	81205	1	32-35-11 384/187/L004	001-099
D04360	1	BACC63BP14A7S6L PLUG	81205	1	32-35-11 384/187/L 04	115-199
D04360 T		BACC10HF14 CABLE CLAMP	81205	1	32-35-11 */ */	ALL
D04394	1	BACS16W5A RELAY SOCKET (PLATE 'D')	81205	1	26-15-11 P36/ /	ALL
D04396	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	26-15-11 P36/ /	ALL
D04398	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	26-15-11 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D04300

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04400	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	26-15-11 P36/ /	ALL
D04402	1	BACC45FT12A12S PLUG	81205	1	26-16-11 635/293/R17	001-099
D04402	1	BACC45FT12-12S PLUG	81205	1	26-16-11 635/202/R17	115-199
D04404	1	BACC45FT12-12S PLUG	81205	1	26-16-11 638/201/R011	001-099
D04404	1	BACC45FT12-12S PLUG	81205	1	26-16-11 620/201/R11	115-199
D04406	1	BACC45FT12D12S PLUG	81205	1	26-16-11 1352/195/R053	001-099
D04406	1	BACC45FT12D12S PLUG	81205	1	26-16-11 1358/195/R53	115-199
D04408	1	BACC45FT12D12S PLUG	81205	1	26-16-11 1356/195/R048	001-099
D04408	1	BACC45FT12D12S PLUG	81205	1	26-16-11 1356/195/R53	115-199
D04410	1	BACC45FS10D5S PLUG	81205	1	26-23-11 1196/172/L012	001-099
D04410	1	BACC45FS10D5S PLUG	81205	1	26-23-11 1196/172/R012	115-199
D04412	1	BACC45FT8D3S PLUG	81205	1	26-23-11 1190/159/L013	ALL
D04414	1	BACC45FT10D5S PLUG	81205	1	26-23-11 1190/159/L008	ALL
D04416	1	BACC45FS10D5S PLUG	81205	1	26-23-11 1196/172/R009	ALL
D04418	1	BACC45FT8D3S PLUG	81205	1	26-23-11 1191/159/R008	ALL
D04420	1	BACC45FT10D5S PLUG	81205	1	26-23-11 1191/159/R013	ALL
D04422	1	BACS16W5A RELAY SOCKET (PLATE 'D')	81205	1	26-22-21 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D04400

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04424	1	BACC45FT8D3S PLUG	81205	1	26-16-21 610/203/R17	001-099
D04424	1	BACC45FT8D3S PLUG	81205	1	26-16-21 615/203/R017	115-199
D04426	1	BACC45FT8A3S PLUG	81205	1	26-16-21 607/203/R010	ALL
D04428	1	BACC45FT8D3S PLUG	81205	1	26-16-21 1353/174/R52	001-099
D04428	1	BACC45FT8D3S PLUG	81205	1	26-16-21 1353/176/R60	115-199
D04430	1	BACC45FT8D3S PLUG	81205	1	26-16-21 1356/176/R60	001-099
D04430	1	BACC45FT8D3S PLUG	81205	1	26-16-21 1356/176/R55	115-199
D04432	1	BACC45FS10A5S PLUG	81205	1	26-16-21 1356/176/R80	001-099
D04432	1	BACC45FS10D5S PLUG	81205	1	26-16-21 1356/176/R55	115-199
D04434	1	BACC45FS10A5S PLUG	81205	1	26-16-21 625/203/R10	ALL
D04438	1	BACS16W5A RELAY SOCKET (PLATE 'F')	81205	1	26-16-21 P036-00/ /	001-099
D04438	1	BACS16W5A RELAY SOCKET (PLATE 'F')	81205	1	26-16-21 P36/ /	115-199
D04440	1	BACS16W5A RELAY SOCKET (PLATE 'F')	81205	1	26-16-21 P036-00/ /	001-099
D04440	1	BACS16W5A RELAY SOCKET (PLATE 'F')	81205	1	26-16-21 P36/ /	115-199
D04452	1	BACC45FN16-24S RCPT-M00966 MICROSWITCH PACK ASSY	81205	1	31-51-42 204/173/L02	ALL
D04454	1	BACC45FN16-24S6 RCPT-M00966 MICROSWITCH PACK ASSY	81205	1	32-42-21 204/172/L002	001-099
D04454	1	BACC45FN16-24S6 RCPT-M00966 MICROSWITCH PACK ASSY	81205	1	32-42-21 204/172/L2	115-199

EQUIPMENT LIST

D280N032

Section D04400

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04462	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 426/ /	001-003, 005, 007-099
D04462	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 426/288/R38	004, 006, 115-199
D04464	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 656/288/R38	ALL
D04470	1	48-7190 PLUG-	02660	1	33-51-12 385/235/L070	001-099
D04470	1	48-7190 PLUG-	02660	1	33-51-12 385/235/L70	115-199
D04472	1	48-7191 RCPT-	02260	1	33-51-12 385/235/L070	001-099
D04472	1	48-7191 RCPT-	02260	1	33-51-12 385/235/L70	115-199
D04474	1	48-7190 PLUG	02660	1	33-51-12 372/245/R73	ALL
D04476	1	48-7191 RCPT-	02660	1	33-51-12 372/245/R73	ALL
D04478	1	48-7190 PLUG-	02660	1	33-51-13 735/240/L060	001-099
D04478	1	48-7190 PLUG-	02660	1	33-51-13 735/240/L60	115-199
D04480	1	48-7191 RCPT-	02660	1	33-51-13 735/240/L060	001-099
D04480	1	48-7191 RCPT-	02660	1	33-51-13 735/240/L60	115-199
D04482	1	48-7190 PLUG-	02660	1	33-51-13 737/240/R70	ALL
D04484	1	48-7191 RCPT-	02660	1	33-51-13 737/240/R70	ALL
D04486	1	48-7190 PLUG-	02660	1	33-51-14 1360/245/L072	ALL
D04488	1	48-7191 RCPT-	02660	1	33-51-14 1360/245/L072	001-099

EQUIPMENT LIST

D280N032

Section D04400

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04488	1	48-7191 RCPT-	02660	1	33-51-14 1360/245/L72	115-199
D04490	1	48-7190 PLUG-	02660	1	33-51-14 1355/242/R73	ALL
D04492	1	48-7191 RCPT-	02660	1	33-51-14 1355/242/R73	ALL
D04494	1	BACS16W1 RELAY SOCKET	81205	1	24-51-71 P031-00/ /	001-099
D04494	1	BACS16W1 RELAY SOCKET (PLATE 'B')	81205	1	21-51-71 P37/ /	115-199
D04496	1	BACS16AH1 RELAY SOCKET (PLATE 'B')	81205	1	24-51-71 P037-00/ /	001-099
D04496	1	BACS16AH1 RELAY SOCKET (PLATE 'B')	81205	1	24-51-71 P37/ /	115-199
D04498	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	74-31-21 P037-00/ /	001-099
D04498	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	74-31-21 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D04400

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04502	1	48-7190 PLUG-	02660	1	33-51-15 1689/240/L065	001-099
D04502	1	48-7190 PLUG-	02660	1	33-51-15 1689/240/L65	115-199
D04504	1	48-7191 RCPT-	02660	1	33-51-15 1689/240/L065	001-099
D04504	1	48-7191 RCPT-	02660	1	33-51-15 1689/240/L65	115-199
D04506	1	48-7190 PLUG-	02660	1	33-51-15 1689/255/R65	ALL
D04508	1	48-7191 RCPT-	02660	1	33-51-15 1689/255/R65	ALL
D04510	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	ALL
D04512	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 418/294/L038	115-199
D04514	1	BACC45FT10-5S6 PLUG	81205	1	29-21-31 E001-00/ /	001-099
D04514	1	BACC45FT10-5S6 PLUG	81205	1	29-21-31 435/194/L30	115-199
D04514 T		BACC10GH10 CABLE CLAMP	81205	1	29-21-31 */ */	001-099
D04514 T		BACC10GH10 CABLE CLAMP	81205	1	29-21-31 */ /	115-199
D04518	1	BACC45FN12-12S RCPT-	81205	1	33-51-13 0710/298/L10	001-099
D04518	1	BACC45FN12-12S RCPT-	81205	1	33-51-13 710/305/L10	115-199
D04520	1	BACC45FN12-12S RCPT-	81205	1	33-51-14 1350/298/L10	001-099
D04522	1	BACC45FN12-12S RCPT-	81205	1	33-51-15 1640/288/R005	001-099
D04522	1	BACC45FN12-12S RCPT-	81205	1	33-51-15 1662/288/R5	115-199

EQUIPMENT LIST

D280N032

Section D04500

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04524	1	48-7191 RCPT	02660	1	33-51-12 340/288/L6	ALL
D04526	1	48-7190 PLUG	02660	1	33-51-12 340/288/L6	ALL
D04528	1	48-7191 RCPT	02660	1	33-51-12 347/283/R50	ALL
D04530	1	48-7190 PLUG	02660	1	33-51-12 347/283/R50	ALL
D04532	1	48-7191 RCPT	02660	1	33-51-12 0358/285/L045	001-099
D04532	1	48-7191 RCPT	02660	1	33-51-12 0358/285/L45	115-199
D04534	1	48-7190 PLUG	02660	1	33-51-12 0358/285/L045	001-099
D04534	1	48-7190 PLUG	02660	1	33-51-12 0358/285/L45	115-199
D04540	1	48-7191 RCPT	02660	1	33-51-13 710/275/R55	ALL
D04542	1	48-7190 PLUG	02660	1	33-51-13 710/275/R55	ALL
D04548	1	48-7191 RCPT	02660	1	33-51-13 0710/283/L050	001-099
D04548	1	48-7191 RCPT	02660	1	33-51-13 0710/283/L50	115-199
D04550	1	48-7190 PLUG	02660	1	33-51-13 0710/283/L050	001-099
D04550	1	48-7190 PLUG	02660	1	33-51-13 0710/283/L50	115-199
D04560	1	48-7191 RCPT	02660	1	33-51-14 1330/268/L059	001-099
D04560	1	48-7191 RCPT	02660	1	33-51-14 1330/268/L59	115-199
D04562	1	48-7190 PLUG	02660	1	33-51-14 1330/268/L059	001-099

EQUIPMENT LIST

D280N032

Section D04500

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04562	1	48-7190 PLUG	02660	1	33-51-14 1330/268/L59	115-199
D04564	1	48-7191 RCPT	02660	1	33-51-15 1660/290/R35	ALL
D04566	1	48-7190 PLUG	02660	1	33-51-15 1660/290/R35	ALL
D04568	1	48-7191 RCPT	02660	1	33-51-15 1664/285/L040	001-099
D04568	1	48-7191 RCPT	02660	1	33-51-15 1664/285/L40	115-199
D04570	1	48-7190 PLUG	02660	1	33-51-15 1664/285/L040	001-099
D04570	1	48-7190 PLUG	02660	1	33-51-15 1664/285/L40	115-199
D04584	1	BACS16W1 RELAY SOCKET (PLATE 'D')	81205	1	80-11-11 P36/ /	ALL
D04586	1	BACS16W5A RELAY SOCKET	81205	1	28-21-21 P33/ /	ALL
D04590	1	BACC45FT12-12S PLUG-	81205	1	33-21-21 789/288/R38	115-199
D04594	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 750/295/L035	115-199
D04596	1	BACC45FT12-12S PLUG-	81205	1	33-21-13 1243/288/L38	ALL

EQUIPMENT LIST

D280N032

Section D04500

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04600	1	48-7191 RCPT	02660	1	33-51-14 1330/270/R62	ALL
D04602	1	48-7190 PLUG	02660	1	33-51-14 1330/270/R62	ALL
D04604	1	48-7191 RCPT	02660	1	33-51-14 1225/305/L10	001-099
D04606	1	48-7190 PLUG	02660	1	33-51-14 1225/305/L10	001-099
D04610	1	BACS16X1A RELAY SOCKET (PLATE 'B')	81205	1	30-11-11 P037-00/ /	001-099
D04610	1	BACS16X1A RELAY SOCKET (PLATE 'B')	81205	1	30-11-11 P37/ /	115-199
D04616	1	BACC45FN10A5P RCPT-	81205	1	33-22-14 1638/ /	001-099
D04616	1	BACC45FN12A12P RCPT-	81205	1	33-22-14 P22/ /	115-199
D04626	1	BACC45FT20A16P PLUG,PSU DISC	81205	1	33-26-11 393/276/L56	115-199
D04628	1	BACC45FT10A5S PLUG-	81205	1	33-22-14 1628/233/L025	001-099
D04628	1	BACC45FT12-12S PLUG-	81205	1	33-22-14 1628/233/L057	115-199
D04634	1	BACC45FN10A5P RCPT-	81205	1	33-22-12 P023-00/ /	001-099
D04642	1	BACC63BP12A12SNL PLUG	81205	1	21-52-31 934/156/L54	001-008
D04642	1	BACC63BP12A12SNL PLUG	81205	1	21-52-31 925.7/158/L45	009-099
D04642	1	BACC63BP12A12SNL PLUG	81205	1	21-52-31 934/156/L054	115-199
D04642 T		BACC10HG12 CABLE CLAMP	81205	1	21-52-31 */ */*	ALL
D04644	1	BACC63BP12A12SNL PLUG	81205	1	21-52-31 938/152/R059	001-008, 115-199

EQUIPMENT LIST

D280N032

Section D04600

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04644	1	BACC63BP12A12SNL PLUG	81205	1	21-52-31 938.4/154/R059	009-099
D04644 T		BACC10HG12 CABLE CLAMP	81205	1	21-52-31 */*/*	ALL
D04646	1	BACC66F11C1901 PLUG PLATE ASSY-	81205	1	21-52-31 E4-2/ /	ALL
D04646A	1	PARTAOFD04646 PLUG-		1	21-52-31 E4-2/ /	001-099
D04646A	1	PARTAOFD04646 PLUG-		0	21-52-31 E4-2/ /	115-199
D04646B	1	PARTBOFD04646 PLUG-		1	21-52-31 E4-2/ /	001-099
D04646B	1	PARTBOFD04646 PLUG-		0	21-52-31 E4-2/ /	115-199
D04646C	1	PARTCOFD04646 PLUG-		1	21-52-31 E4-2/ /	001-099
D04646C	1	PARTCOFD04646 PLUG-		0	21-52-31 E4-2/ /	115-199
D04648	1	BACC63CE12SA3S PLUG	81205	1	21-65-12 355/198/L054	001-099
D04648	1	BACC63CE12SA3S PLUG	81205	1	21-65-12 355/198/L54	115-199
D04650	1	BACC63CE12SA3S PLUG	81205	1	21-65-12 860/299/L11	001-099
D04650	1	BACC63CE12SB3S PLUG	81205	1	21-65-12 860/299/L11	115-199
D04652	1	BACC63CE12SB3S PLUG	81205	1	21-65-12 880/299/L11	ALL
D04654	1	BACC63BP12A12SNL PLUG	81205	1	21-64-11 886/155/L005	001-099
D04654	1	BACC63BP12A12SNL PLUG	81205	1	21-64-11 886/155/L05	115-199
D04654 T		BACC10HF12 CABLE CLAMP	81205	1	21-64-11 */*/*	ALL

EQUIPMENT LIST

D280N032

Section D04600

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04656	1	BACC63BP12A12SNL PLUG	81205	1	21-64-11 892/155/R002	001-099
D04656	1	BACC63BP12A12SNL PLUG	81205	1	21-64-11 900/148/L5	115-199
D04656 T		BACC10HF12 CABLE CLAMP	81205	1	21-64-11 */*/	ALL
D04658	1	BACC63BP12A12SNL PLUG	81205	1	21-64-11 892/163/L003	001-099
D04658	1	BACC63BP12A12SNL PLUG	81205	1	21-64-11 892/163/L3	115-199
D04658 T		BACC10HF12 CABLE CLAMP	81205	1	21-64-11 */*/	ALL
D04660	1	BACC63BP10A5S8L PLUG	81205	1	36-21-11 900/145/R038	ALL
D04660 T		BACC10HG10 CABLE CLAMP	81205	1	36-21-11 */*/	ALL
D04662	1	BACC63CE12SA3S PLUG	81205	1	36-22-21 FSS295/ /	ALL
D04664	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-42 P037-00/ /	001-099
D04664	1	BACS16W1 RELAY SOCKET (PLATE 'C')	81205	1	77-12-42 P37/ /	115-199
D04670	1	48-7191 RCPT-	02660	1	35-21-13 1655/297/L020	001-099
D04670	1	48-7191 RCPT-	02660	1	35-21-13 1680/298/L25	115-199
D04672	1	48-7190 PLUG-	02660	1	35-21-13 1665/300/L020	001-099
D04672	1	48-7190 PLUG-	02660	1	35-21-13 1690/298/L25	115-199
D04674	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-002
D04674	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	27-09-12 P037-00/ /	003-099

EQUIPMENT LIST

D280N032

Section D04600

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04674	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	27-09-12 P37/ /	115-199
D04676	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P037-00/ /	001-002
D04676	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	27-09-12 P037-00/ /	003-099
D04676	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	27-09-12 P37/ /	115-199
D04680	1	CWC01-2010 PLUG	71771	1	30-41-11 250/228/R048	ALL
D04680 T		0712 INSULATOR CAP	81323	1	30-41-11 */*/	ALL
D04682	1	CWC01-2010 PLUG	71771	1	30-41-12 250/228/L48	ALL
D04682 T		0712 INSULATOR CAP	81323	1	30-41-12 */*/	ALL
D04684	1	BACS16W1 RELAY SOCKET	81205	1	28-25-11 P070-00/ /	ALL
D04686	1	BACS16AH1 RELAY SOCKET	81205	1	28-25-11 P070-00/ /	001-099
D04686	1	BACS16W5A RELAY SOCKET	81205	1	28-25-11 P070-00/ /	115-199
D04688	1	BACC65L41 RCPT	81205	1	27-23-21 P50/ /	ALL
D04690	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 ELEV170/RS/	ALL
D04690 T		BACC10HF12 CABLE CLAMP	81205	1	27-23-21 ELEV170/RS/	ALL
D04692	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 ELEV120/RS/	ALL
D04692 T		BACC10HF12 CABLE CLAMP	81205	1	27-23-21 ELEV120/ /	ALL
D04694	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 ELEV145/RS/	ALL

EQUIPMENT LIST

D280N032

Section D04600

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04694 T		BACC10HF12 CABLE CLAMP	81205	1	27-23-21 ELEV145/RS/	ALL
D04696	1	BACC63CE12S-3S PLUG-	81205	1	29-32-41 1051/188/R50	ALL
D04696 T		BACC10HW12 CABLE CLAMP-	81205	1	29-32-41 1051/188/R50	ALL

EQUIPMENT LIST

D280N032

Section D04600
Page 5 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04700	1	BACC63BP10A5S8L PLUG	81205	1	36-21-11 900/145/L15	ALL
D04700 T		BACC10HF10 CABLE CLAMP	81205	1	36-21-11 */*/	ALL
D04701J	1	48-7191 RECP	81205	1	23-31-32 1648/285/L010	ALL
D04701P	1	48-7190 PLUG	81205	1	23-31-22 1648/300/L010	ALL
D04702	1	BACC63CE12SA3S PLUG	81205	1	36-22-21 FSS295/150/RFS	ALL
D04703J	1	48-7191 RECP	81205	1	23-31-22 1648/300/L010	ALL
D04703P	1	48-7190 PLUG	81205	1	23-31-32 1648/285/L010	ALL
D04704	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	77-12-41 P36/ /	ALL
D04705J	1	48-7191 RECP	81205	1	23-31-21 710/290/L45	ALL
D04705P	1	48-7190 PLUG	81205	1	23-31-31 710/290/L045	ALL
D04706	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	001-002
D04706	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-12 P36/ /	003-099, 115-199
D04707J	1	48-7191 RECP	81205	1	23-31-31 710/290/L045	ALL
D04707P	1	48-7190 PLUG	81205	1	23-31-21 710/290/L45	ALL
D04708	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	001-002
D04708	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	27-09-12 P36/ /	003-099, 115-199
D04710	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 FIN210/RS/L002	ALL

EQUIPMENT LIST

D280N032

Section D04700

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04710 T		BACC10HG12 CABLE CLAMP	81205	1	27-23-21 */*/	ALL
D04712	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 FIN170/RS/L002	ALL
D04712 T		BACC10HG12 CABLE CLAMP	81205	1	27-23-21 */*/	ALL
D04714	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 FIN188/RS/L002	ALL
D04714 T		BACC10HG12 CABLE CLAMP	81205	1	27-23-21 */*/	ALL
D04716	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 ELEV160/RS/	ALL
D04716 T		BACC10HF12 CABLE CLAMP	81205	1	27-23-21 ELEV160/RS/	ALL
D04718	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 ELEV112/RS/	ALL
D04718 T		BACC10HF12 CABLE CLAMP	81205	1	27-23-21 ELEV112/RS/	ALL
D04720	1	BACC63BP12A3SNL PLUG-	81205	1	27-23-21 ELEV130/RS/	ALL
D04720 T		BACC10HF12 CABLE CLAMP	81205	1	27-23-21 ELEV130/RS/	ALL
D04722	1	BACC63CE12S-3S PLUG-	81205	1	29-32-41 1051/188/L050	ALL
D04722 T		BACC10HW12 CABLE CLAMP	81205	1	29-32-41 */*/	ALL
D04724	1	BACC63CE12SB3S PLUG-	81205	1	29-32-41 1197/155/L055	ALL
D04726	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	29-11-31 P36/ /	ALL
D04734	1	BACC45FN10A5S RCPT	81205	1	73-21-12 210/199/L012	ALL
D04736	1	BACC45FN10D5S RCPT	81205	1	73-21-22 210/199/R012	ALL

EQUIPMENT LIST

D280N032

Section D04700

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04746	1	BACC63BP10A5SNL PLUG-	81205	1	25-51-11 850/155/000	115-199
D04746 T		BACC10HF10 CABLE CLAMP	81205	1	25-51-11 */*/	115-199
D04748	1	BACC63BP10A5SNL PLUG-	81205	1	25-51-21 1195/145/0	115-199
D04748 T		BACC10HG10 CABLE CLAMP	81205	1	25-51-21 1195/145/0	115-199
D04754	1	BACS16W3 RELAY SOCKET	81205	1	33-45-11 P070-00/ /	ALL
D04756	1	BACC63BP18A8SNL PLUG-	81205	1	33-45-11 ELEV112/AS/	ALL
D04756 T		BACC10HF18 CABLE CLAMP	81205	1	33-45-11 */*/	ALL
D04758	1	BACC63BP18A8SNL PLUG-	81205	1	33-45-11 ELEV125/AS/	ALL
D04758 T		BACC10HF18 CABLE CLAMP	81205	1	33-45-11 */*/	ALL
D04766	1	BACC45FT12A12S PLUG-	81205	1	24-33-12 E006-00/ /	001-099
D04766	1	BACC45FT12A12S PLUG-	81205	1	24-33-12 E6/ /	115-199
D04770	1	BACS16AG1 RELAY SOCKET	81205	1	24-33-12 P006-00/ /	001-099
D04770	1	BACS16AG1 RELAY SOCKET-	81205	1	24-33-12 P006-00/ /	115-199
D04774	1	BACS16W5A SOCKET	81205	1	24-33-12 E6 RLY/PNL/	001-099
D04774	1	BACS16W5A SOCKET	81205	1	24-33-12 E6/ /	115-199
D04786	1	BACC45FT10A5P PLUG-	81205	1	33-22-12 682/277/R047	115-199
D04788	1	BACC45FN10-5S RCPT-	81205	1	33-22-12 682/238/R017	115-199

EQUIPMENT LIST

D280N032

Section D04700

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04790	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	21-51-11 P36/ /	001-099
D04790	1	BACS16AG1 RELAY SOCKET	81205	1	21-51-11 E6/ /	115-199

EQUIPMENT LIST

D280N032

Section D04700
Page 4 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04800	1	BACC45FT16A24S PLUG	81205	1	33-51-11 P005-00/ /	001-099
D04800	1	BACC45FT16A24S PLUG	81205	1	33-51-11 P5/ /	115-199
D04802	1	BACC45FT12A12S7 PLUG	81205	1	33-51-11 P5/ /	ALL
D04806	1	SO-1057-8912 RELAY SOCKET-	35344	1	52-34-11 P65/ /	001-099
D04808	1	SO-1057-8912 RELAY SOCKET-	35344	1	52-34-11 P65/ /	001-099
D04810	1	SO-1057-8912 RELAY SOCKET	35344	1	52-35-11 E6 RLY/PNL/	001-099
D04812	1	SO-1057-8912 RELAY SOCKET	35344	1	52-35-11 E6 RLY/PNL/	001-099
D04814	1	BACC63BP18A8SNL PLUG-	81205	1	33-45-11 EVEL112/AS/	ALL
D04814 T		BACC10HF18 CABLE CLAMP	81205	1	33-45-11 */ */	ALL
D04816	1	BACC63BP18A8SNL PLUG-	81205	1	33-45-11 ELEV125/AS/	ALL
D04816 T		BACC10HF18 CABLE CLAMP	81205	1	33-45-11 */ */	ALL
D04818	1	BACC45FT20A16P PLUG-PASSENGER SERVICE UNIT U/B	81205	1	33-23-31 655ULTI/ /	115-199
D04832	1	BACS16AG1 RELAY SOCKET	81205	1	24-32-41 E6 RLY/PNL/	001-099
D04832	1	BACS16AG1 RCPT	81205	1	24-32-41 E6/ /	115-199
D04834	1	10-60450-5 RELAY SOCKET	81205	1	24-32-41 E6 RLY/PNL/	001-099
D04834	1	10-60450-5 RCPT	81205	1	24-32-41 E6/ /	115-199
D04836	1	10-60450-5 PLUG	81205	1	33-13-31 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D04800

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04836	1	10-60450-5 PLUG	81205	1	33-13-31 P5/ /	115-199
D04838	1	BACS16X3A RELAY SOCKET	81205	1	33-22-11 P34/ /	115-199

EQUIPMENT LIST

D280N032

Section D04800
Page 2 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05025	1	BACS16X1A SOCKET	81205	1	24-33-12 E6 RLY/PNL/	001-099
D05025	1	BACS16X1A SOCKET	81205	1	24-33-12 E6/ /	115-199
D05028	1	BACC45FT20A16P PLUG	81205	1	33-24-12 675/278/L060	115-199
D05030	1	BACC45FT20A16P PLUG	81205	1	33-24-21 742/278/R058	115-199
D05032		BACS16X3A PLUG	81205	1	33-13-41 P003-01/ /	001-099
D05032		BACS16X3A PLUG	81205	1	33-13-41 P003-03/ /	115-199
D05088	1	BACS16AG1 RELAY SOCKET-	81205	1	24-34-11 P006-00/ /	ALL
D05090	1	BACS16W5A RELAY SOCKET-	81205	1	24-31-11 P006-00/ /	ALL
D05091	1	BACC45FT10-5P PLUG	81205	1	33-22-12 700/ /L040	115-199
D05091 T		BACC10GH10 CABLE CLAMP	81205	1	33-22-12 / /	115-199
D05092	1	SO-1057-8912 RELAY SOCKET	35344	1	33-42-12 P034-00/ /	001-099
D05094	1	SO-1057-8912 RELAY SOCKET	35344	1	33-42-12 P034-00/ /	001-099
D05098	1	BACC45FT14A15S PLUG-	81205	1	33-22-12 686/290/L030	115-199

EQUIPMENT LIST

D280N032

Section D05000

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05100	1	SO-1057-8912 RELAY SOCKET	35344	1	33-42-11 P33/ /	ALL
D05102	1	SO-1057-8912 RELAY SOCKET	35344	1	33-42-11 P33/ /	ALL
D05106	1	BACC45FT10A5S PLUG-	81205	1	33-25-11 705/290/L010	115-199
D05116	1	BACC45FT20A41S PLUG-	81205	1	33-22-11 379/262/L036	001-099
D05118	1	BACC63BP16A10SNL PLUG-	81205	1	29-21-32 1049/166/R55	ALL
D05118 T		BACC10HG16A CABLE CLAMP-	81205	1	29-21-31 1049/166/R55	ALL
D05120	1	BACC63BP16A10SNL PLUG-	81205	1	29-21-32 1073/196/R59	ALL
D05120 T		BACC10HF16 CABLE CLAMP-	81205	1	29-21-31 1073/196/R59	ALL
D05122	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	29-11-22 P037-00/ /	001-099
D05122	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	29-11-22 P37/ /	115-199
D05142	1	BACS16W1 RELAY SOCKET (PLATE 'D')	81205	1	36-11-11 P36/ /	ALL
D05166	1	BACS16W1A RELAY SOCKET	81205	1	33-24-11 P034-00/ /	001-099
D05166	1	BACS16AG1 RELAY SOCKET	81205	1	33-24-11 P34/ /	115-199
D05188	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-11 P037-00/ /	001-099
D05188	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-11 P37/ /	115-199
D05190	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	21-58-12 P36/ /	ALL
D05192	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	21-25-11 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D05100

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05194	1	BACS16AF1 RELAY SOCKET (PLATE 'B')	81205	1	77-12-41 P037-00/ /	001-099
D05194	1	BACS16AF1 RELAY SOCKET (PLATE 'B')	81205	1	77-12-41 P37/ /	115-199
D05198	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	77-12-41 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D05100

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05206	1	BACC45FT10A5S PLUG-	81205	1	33-25-21 705/290/R010	115-199
D05208	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P037-00/ /	001-099
D05208	1	BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P37/ /	115-199
D05236	1	BACC45FT16A24S PLUG	81205	1	25-31-27 P032-00/ /	001-099
D05238	1	48-7191 RCPT-	02660	1	35-21-22 1655/290/R20	001-099
D05238	1	48-7191 RCPT-	02660	1	35-21-22 1665/290/R020	115-199
D05240	1	48-7190 PLUG-	02660	1	35-21-22 1655/290/R20	001-099
D05240	1	48-7190 PLUG-	02660	1	35-21-22 1665/290/R020	115-199
D05242	1	BACS16X3A PLUG	81205	1	33-11-11 154/210/R15	001-099
D05242	1	BACS16X3A PLUG	81205	1	33-11-11 154/ /	115-199
D05246	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	73-21-42 P037-00/ /	001-099
D05246	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	73-21-42 P37/ /	115-199
D05254	1	BACS16X3A PLUG	81205	1	33-13-11 P1/ /	115-199
D05258	1	BACS16W5A RELAY SOCKET (PLATE 'F')	81205	1	36-11-11 P36/ /	ALL
D05260	1	BACS16W5A RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P037-00/ /	001-099
D05260	1	BACS16W5A RELAY SOCKET (PLATE 'A')	81205	1	36-11-21 P37/ /	115-199
D05262	1	48-7190 PLUG	02660	1	33-51-12 288/275/L028	001-099

EQUIPMENT LIST

D280N032

Section D05200

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05262	1	48-7190 PLUG	02660	1	33-51-12 292/278/L27	115-199
D05264	1	48-7191 RCPT	02660	1	33-51-12 288/275/L028	001-099
D05264	1	48-7191 RCPT	02660	1	33-51-12 292/278/L27	115-199
D05272	1	BACC63BP12B3SNL PLUG	81205	1	36-11-11 PP144/152/8.0	ALL
D05272 T		BACC10HD12A CABLE CLAMP	81205	1	36-11-11 */ */ *	ALL
D05274	1	BACC63BP12B3SNL PLUG	81205	1	36-11-21 PP144/157/8.0	ALL
D05274 T		BACC10HD12A CABLE CLAMP	81205	1	36-11-21 PP144/157/8.0	ALL
D05292	1	BACC45FT20A16P PLUG	81205	1	33-24-31 675/269/R37	115-199
D05298	1	BACC45FN10-5S RCPT-	81205	1	33-25-12 700/ /	115-199

EQUIPMENT LIST

D280N032

Section D05200

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05330	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 968/149/L41	001-099
D05332	1	BACC63CE12SB3S PLUG	81205	1	21-52-11 968/149/R033	001-099
D05348	1	BACC45FT12-12S PLUG-	81205	1	33-21-12 633/288/L38	001-099

EQUIPMENT LIST

D280N032

Section D05300
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05422	1	000300-1560 RELAY SOCKET (PLATE 'C')	05574	1	30-34-12 P037-00/ /	001-099
D05422	1	000300-1560 RELAY SOCKET (PLATE 'C')	05574	1	30-34-22 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D05400

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05501	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	21-25-11 P36/ /	ALL
D05522	1	000300-1560 RELAY SOCKET (PLATE 'F')	05574	1	30-34-11 P36/ /	001-099
D05522	1	000300-1560 RELAY SOCKET (PLATE 'F')	05574	1	30-34-21 P36/ /	115-199
D05576	1	SO-1057-8912 RELAY SOCKET	35344	1	33-42-31 P33/ /	001-099
D05594	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	76-11-21 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D05500
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05602	1	BACC66F11C8101 PLUG PLATE ASSY-	81205	1	77-12-11 E4-2/ /	001-099
D05602	1	BACC66F11C0901 PLUG PLATE ASSY-	81205	1	77-31-11 E4-2/ /	115-199
D05602A	1	PARTAOFD05602 PLUG-		1	77-12-11 E4-2/ /	001-099
D05602A	1	PARTAOFD05602 PLUG-		0	77-31-11 E4-2/ /	115-199
D05602B	1	PARTBOFD05602 PLUG-		1	77-12-11 E4-2/ /	001-099
D05602B	1	PARTBOFD05602 PLUG-		0	77-31-11 E4-2/ /	115-199
D05602C	1	PARTCOFD05602 PLUG-		1	77-12-11 E4-2/ /	001-099
D05602C	1	PARTCOFD05602 PLUG-		0	77-31-11 E4-2/ /	115-199
D05606	1	BACC63CD24-22SW RCPT-	81205	1	25-31-11 318.8/291/R27	115-199
D05608	1	BACS16X1A RELAY SOCKET	81205	1	27-51-21 P33/ /	ALL
D05616	1	BACS16W1A RELAY SOCKET (PLATE 'F')	81205	1	21-58-12 P36/ /	ALL
D05618	1	BACS16AH1 RELAY SOCKET (PLATE 'A')	81205	1	21-58-12 P36/ /	ALL
D05622	1	BACS16AG1 RELAY SOCKET (PLATE 'D')	81205	1	21-58-12 P36/ /	ALL
D05626	1	BACS16W5A RELAY SOCKET (PLATE 'F')	81205	1	21-58-12 P36/ /	ALL
D05632	1	BACC45FT12A12S PLUG	81205	1	21-58-12 512/190/L040	001-099
D05632	1	BACC45FT12A12S PLUG	81205	1	21-58-12 560/182/L062	115-199
D05634	1	BACC45FT12A12S PLUG	81205	1	21-58-12 512/190/L040	ALL

EQUIPMENT LIST

D280N032

Section D05600

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05654	1	BACS16X3A RELAY SOCKET (PLATE 'D')	81205	1	29-11-31 P36/ /	ALL
D05660	1	BACC45FN10-5S RCPT-	81205	1	28-41-11 560/192/R062	001-099
D05660	1	BACC45FN10-5S RCPT-	81205	1	28-41-11 560/192/R62	115-199
D05662	1	BACS16X3A RELAY SOCKET (PLATE 'D')	81205	1	29-11-22 P36/ /	ALL
D05664	1	BACS16X3A RELAY SOCKET (PLATE 'D')	81205	1	29-11-31 P36/ /	ALL
D05690	1	BACC45FT24A43S PLUG-	81205	1	38-32-11 656/290/L027	001-099
D05694	1	BACS16AG1 RELAY SOCKET (PLATE 'B')	81205	1	76-11-21 P37/ /	ALL

EQUIPMENT LIST

D280N032

Section D05600

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05772	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 907/ /	001-099
D05772	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 907/265/L060	115-199
D05772 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/	001-099
D05772 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 */*/	115-199

EQUIPMENT LIST

D280N032

Section D05700

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05824	1	BACC45FT14A15S PLUG	81205	1	33-13-31 P5/ /	115-199
D05872	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 879/265/R060	001-099
D05872	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 879/265/R060	115-199
D05872 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/	001-099
D05872 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/	115-199
D05874	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 907/265/R060	001-099
D05874	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 907/265/R060	115-199
D05874 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/	001-099
D05874 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/	115-199
D05896	1	BACC45FT18A14P PLUG-	81205	1	33-25-11 670/290/L026	001-008

EQUIPMENT LIST

D280N032

Section D05800

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05902	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 385/265/L060	001-099
D05902	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 385/265/L060	115-199
D05902 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05904	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 407/265/L060	001-099
D05904	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 407/265/L060	115-199
D05904 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05904 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05906	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 429/265/L060	001-099
D05906	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 429/265/L060	115-199
D05906 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05906 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05908	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 444/265/L060	001-099
D05908	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 444/265/L060	115-199
D05908 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05908 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05910	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 475/265/L060	001-099
D05910	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 475/265/L060	115-199

EQUIPMENT LIST

D280N032

Section D05900

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05910 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05910 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05912	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 489/265/L060	001-099
D05912	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 489/265/L060	115-199
D05912 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05912 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05914	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 517/265/L060	001-099
D05914	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 517/265/L060	115-199
D05914 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05914 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05916	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 530/265/L060	001-099
D05916	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 530/265/L060	115-199
D05916 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05916 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05918	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 546/265/L060	001-099
D05918	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 546/265/L060	115-199
D05918 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099

EQUIPMENT LIST

D280N032

Section D05900

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05918 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05920	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 575/265/L060	001-099
D05920	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 575/265/L060	115-199
D05920 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05920 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05922	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 596/265/L060	001-099
D05922	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 596/265/L060	115-199
D05922 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05922 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05924	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 610/265/L060	001-099
D05924	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 610/265/L060	115-199
D05924 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05924 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05926	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 638/265/L060	001-099
D05926	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 638/265/L060	115-199
D05926 T		69-74374-3 PSU BRACKET	81205	1	33-23-11 */*/	001-099
D05926 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199

EQUIPMENT LIST

D280N032

Section D05900

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05928	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 670/296/L30	001-008
D05928	1	BACC45FN18-14S RCPT-	81205	1	33-23-11 670/273/L030	009-099
D05928	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 670/265/L040	115-199
D05928 T		69-74374-3 286N3702	81205	1	33-23-11 / /	009-099
D05928 T		69-74374-5 PSU BRACKET	81205	1	33-23-11 */*/	115-199
D05930	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 712/ /	001-099
D05930	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 712/265/L060	115-199
D05932	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 712/ /	001-099
D05932	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 712/265/L060	115-199
D05934	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 745/265/L060	001-099
D05934	1	BACC45FN20-16S RCPT-	81205	1	33-24-12 745/265/L060	115-199
D05934 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/	001-099
D05934 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 */*/	115-199
D05936	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 758/265/L060	001-099
D05936	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 758/265/L060	115-199
D05936 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/	001-099
D05936 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 */*/	115-199

EQUIPMENT LIST

D280N032

Section D05900

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05938	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 785/265/L060	001-099
D05938	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 785/265/L060	115-199
D05938 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/	001-099
D05938 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 */*/	115-199
D05940	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 813/265/L060	001-099
D05940	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 813/265/L060	115-199
D05940 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/	001-099
D05940 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 */*/	115-199
D05942	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 850/265/L060	001-099
D05942	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 850/265/L060	115-199
D05942 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/	001-099
D05942 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 */*/	115-199
D05944	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 879/265/L060	001-099
D05944	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 879/265/L060	115-199
D05944 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/	001-099
D05944 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 */*/	115-199
D05946	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 930/265/L060	001-099

EQUIPMENT LIST

D280N032

Section D05900

Page 5

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05946	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 930/265/L060	115-199
D05946 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	001-099
D05946 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 930/265/L60	115-199
D05948	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 941/265/L060	001-099
D05948	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 941/265/L060	115-199
D05948 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	001-099
D05948 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 941/265/L60	115-199
D05950	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 977/265/L060	001-099
D05950	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 977/265/L060	115-199
D05950 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	001-099
D05950 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 977/265/L60	115-199
D05952	1	BACC45FN18-14S RCPT-	81205	1	33-23-12 1008/265/L060	001-099
D05952	1	BACC45FN20-16S RCPT-	81205	1	33-23-12 1008/265/L060	115-199
D05952 T		69-74374-3 PSU BRACKET	81205	1	33-23-12 */*/*	001-099
D05952 T		69-74374-5 PSU BRACKET	81205	1	33-23-12 1008/265/L60	115-199
D05954	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1038/265/L060	001-099
D05954	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1038/265/L060	115-199

EQUIPMENT LIST

D280N032

Section D05900

Page 6

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05954 T		69-74374-3 PSU BRACKET	81205	1	33-23-13 */*/	001-099
D05954 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1038/L60/L60	115-199
D05956	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1050/265/L060	001-099
D05956	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1050/265/L060	115-199
D05956 T		69-74374-3 PSU BRACKET	81205	1	33-23-13 */*/	001-099
D05956 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1056/L60/265	115-199
D05958	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1075/265/L060	001-099
D05958	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1075/265/L060	115-199
D05958 T		69-74374-3 PSU BRACKET	81205	1	33-23-13 */*/	001-099
D05958 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1075/265/L60	115-199
D05960	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1104/265/L060	001-099
D05960	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1104/265/L060	115-199
D05960 T		69-74374-3 PSU BRACKET	81205	1	33-23-13 */*/	001-099
D05960 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1104/265/L60	115-199
D05962	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1138/265/L060	001-099
D05962	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1138/265/L060	115-199
D05962 T		69-74374-3 PSU BRACKET	81205	1	33-23-13 */*/	001-099

EQUIPMENT LIST

D280N032

Section D05900

Page 7

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05962 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1138/265/L06	115-199
D05964	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1173/265/L060	001-099
D05964	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1173/265/L060	115-199
D05964 T		69-74374-3 PSU BRACKET	81205	1	33-23-13 */*/	001-099
D05964 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1173/265/L60	115-199
D05966	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1206/265/L060	001-099
D05966	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1206/265/L060	115-199
D05966 T		69-74374-3 PSU BRACKET	81205	1	33-23-13 */*/	001-099
D05966 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1206/265/L60	115-199
D05968	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1231/265/L060	001-099
D05968	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1240/270/L38	115-199
D05968 T		69-74374-3 PSU BRACKET	81205	1	33-23-13 1231*/	001-099
D05968 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 */*/	115-199
D05970	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1250/265/L060	001-099
D05970	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1234/272/L55	115-199
D05970 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1234/272/L55	115-199
D05972	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1267/265/L060	001-099

EQUIPMENT LIST

D280N032

Section D05900

Page 8

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05972	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1266/272/L55	115-199
D05972 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1266/272/L55	115-199
D05974	1	BACC45FN18-14S RCPT-	81205	1	33-23-13 1295/265/L060	001-099
D05974	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1295/265/L060	115-199
D05976	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1331/265/L060	001-099
D05976	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1330/272/L55	115-199
D05976 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1331/*/*	001-099
D05976 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */*/*	115-199
D05978	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1365/265/L060	001-099
D05978	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1363/272/L55	115-199
D05978 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1365/*/*	001-099
D05978 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */*/*	115-199
D05980	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1393/265/L060	001-099
D05980	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1393/272/L55	115-199
D05980 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1393/*/*	001-099
D05980 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */*/*	115-199
D05982	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1429/265/L060	001-099

EQUIPMENT LIST

D280N032

Section D05900

Page 9

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05982	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1424/272/L55	115-199
D05982 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1429/*/*	001-099
D05982 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */**	115-199
D05984	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1457/265/L060	001-099
D05984	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1455/272/L55	115-199
D05984 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1457/*/*	001-099
D05984 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */**	115-199
D05986	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1470/265/L060	001-099
D05986	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1480/270/L38	115-199
D05986 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1470/*/*	001-099
D05986 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */**	115-199
D05988	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1492/265/L060	001-099
D05988	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1486/272/L55	115-199
D05988 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1492/*/*	001-099
D05988 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */**	115-199
D05990	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1520/265/L060	001-099
D05990	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1517/272/L55	115-199

EQUIPMENT LIST

D280N032

Section D05900

Page 10

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05990 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1520/*/*	001-099
D05990 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */**	115-199
D05992	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1548/265/L060	001-099
D05992	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1550/272/L55	115-199
D05992 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1548/*/*	001-099
D05992 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */**	115-199
D05994	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1583/265/L060	001-099
D05994	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1585/272/L55	115-199
D05994 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1583/*/*	001-099
D05994 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */**	115-199
D05996	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1604/265/L060	001-099
D05996	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1600/272/L55	115-199
D05996 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1604/*/*	001-099
D05996 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */**	115-199
D05998	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1623/265/L060	001-099
D05998	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1620/272/L55	115-199
D05998 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1623/*/*	001-099

EQUIPMENT LIST

D280N032

Section D05900

Page 11

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05998 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */*/	115-199

EQUIPMENT LIST

D280N032

Section D05900
Page 12 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06000	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 383/265/R060	001-099
D06000	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 383/265/R060	115-199
D06000 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06000 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06002	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 412/265/R060	001-099
D06002	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 412/265/R060	115-199
D06002 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06002 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06004	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 429/265/R060	001-099
D06004	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 429/265/R060	115-199
D06004 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06004 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06006	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 448/265/R060	001-099
D06006	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 448/265/R060	115-199
D06006 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06006 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06008	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 470/265/R060	001-099

EQUIPMENT LIST

D280N032

Section D06000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06008	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 470/265/R060	115-199
D06008 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06008 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06010	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 483/265/R060	001-099
D06010	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 483/265/R060	115-199
D06010 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06010 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06012	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 510/265/R060	001-099
D06012	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 510/265/R060	115-199
D06012 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06012 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06014	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 525/265/R060	001-099
D06014	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 525/265/R060	115-199
D06014 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06014 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06016	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 553/265/R060	001-099
D06016	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 553/265/R060	115-199

EQUIPMENT LIST

D280N032

Section D06000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06016 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06016 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06018	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 576/265/R060	001-099
D06018	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 576/265/R060	115-199
D06018 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06018 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06020	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 590/265/R060	001-099
D06020	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 590/265/R060	115-199
D06020 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06020 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06022	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 609/265/R060	001-099
D06022	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 609/265/R060	115-199
D06022 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06022 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06024	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 630/265/R060	001-099
D06024	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 630/265/R060	115-199
D06024 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099

EQUIPMENT LIST

D280N032

Section D06000

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06024 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06026	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 650/265/R060	001-099
D06026	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 650/265/R060	115-199
D06026 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06026 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06028	1	BACC45FN18-14S RCPT-	81205	1	33-23-21 656/278/R058	001-099
D06028	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 656/278/R058	115-199
D06028 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06028 T		69-74374-5 PSU BRACKET	81205	1	33-23-21 */*/	115-199
D06030	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 670/298/R035	001-099
D06030	1	BACC45FN20-16S RCPT-	81205	1	33-23-21 666/290/R44	115-199
D06030 T		69-74374-3 PSU BRACKET	81205	1	33-23-21 */*/	001-099
D06032	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 713/296/R036	001-099
D06032	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 713/296/R036	115-199
D06034	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 713/296/R036	001-099
D06034	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 713/296/R036	115-199
D06036	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 742/278/R058	001-099

EQUIPMENT LIST

D280N032

Section D06000

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06036	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 742/265/R060	115-199
D06036 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099
D06036 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/*	115-199
D06038	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 757/265/R060	001-099
D06038	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 757/265/R060	115-199
D06038 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099
D06038 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/*	115-199
D06040	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 785/265/R060	001-099
D06040	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 785/265/R060	115-199
D06040 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099
D06040 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/*	115-199
D06042	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 813/265/R060	001-099
D06042	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 813/265/R060	115-199
D06042 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099
D06042 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/*	115-199
D06044	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 849/265/R060	001-099
D06044	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 849/265/R060	115-199

EQUIPMENT LIST

D280N032

Section D06000

Page 5

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06044 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099
D06044 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/*	115-199
D06046	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 930/265/R060	001-099
D06046	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 930/265/R060	115-199
D06046 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099
D06046 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/*	115-199
D06048	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 941/265/R060	001-099
D06048	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 941/265/R060	115-199
D06048 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099
D06048 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/*	115-199
D06050	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 977/265/R060	001-099
D06050	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 977/265/R060	115-199
D06050 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099
D06050 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/*	115-199
D06052	1	BACC45FN18-14S RCPT-	81205	1	33-23-22 1008/265/R060	001-099
D06052	1	BACC45FN20-16S RCPT-	81205	1	33-23-22 1008/265/R060	115-199
D06052 T		69-74374-3 PSU BRACKET	81205	1	33-23-22 */*/*	001-099

EQUIPMENT LIST

D280N032

Section D06000

Page 6

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06052 T		69-74374-5 PSU BRACKET	81205	1	33-23-22 */*/	115-199
D06054	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1040/265/R060	001-099
D06054	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1040/265/R060	115-199
D06054 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/	001-099
D06054 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199
D06056	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1050/265/R060	001-099
D06056	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1050/265/R060	115-199
D06056 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/	001-099
D06056 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199
D06058	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1074/265/R060	001-099
D06058	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1074/265/R060	115-199
D06058 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/	001-099
D06058 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199
D06060	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1103/265/R060	001-099
D06060	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1103/265/R060	115-199
D06060 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/	001-099
D06060 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199

EQUIPMENT LIST

D280N032

Section D06000

Page 7

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06062	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1138/265/R060	001-099
D06062	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1138/265/R060	115-199
D06062 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/	001-099
D06062 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199
D06064	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1173/265/R060	001-099
D06064	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1173/265/R060	115-199
D06064 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/	001-099
D06064 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199
D06066	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1206/265/R060	001-099
D06066	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1206/265/R060	115-199
D06066 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/	001-099
D06066 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199
D06068	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1233/265/R060	001-099
D06068	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1233/265/R060	115-199
D06068 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/	001-099
D06068 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199
D06070	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1250/265/R060	001-099

EQUIPMENT LIST

D280N032

Section D06000

Page 8

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06070	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1250/265/R060	115-199
D06070 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/*	001-099
D06070 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/*	115-199
D06072	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1267/265/R060	001-099
D06072	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1267/265/R060	115-199
D06072 T		69-74374-3 PSU BRACKET	81205	1	33-23-23 */*/*	001-099
D06072 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/*	115-199
D06074	1	BACC45FN18-14S RCPT-	81205	1	33-23-23 1295/265/R060	001-099
D06074	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1295/265/R060	115-199
D06076	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1330/265/R060	001-099
D06076	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1330/265/R060	115-199
D06076 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/*	001-099
D06076 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/*	115-199
D06078	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1365/265/R060	001-099
D06078	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1365/265/R060	115-199
D06078 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/*	001-099
D06078 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/*	115-199

EQUIPMENT LIST

D280N032

Section D06000

Page 9

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06080	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1393/265/R060	001-099
D06080	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1393/265/R060	115-199
D06080 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06080 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06082	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1429/265/R060	001-099
D06082	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1429/265/R060	115-199
D06082 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06082 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06084	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1456/265/R060	001-099
D06084	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1456/265/R060	115-199
D06084 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06084 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06086	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1470/265/R060	001-099
D06086	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1470/265/R060	115-199
D06086 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06086 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06088	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1491/265/R060	001-099

EQUIPMENT LIST

D280N032

Section D06000

Page 10

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06088	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1491/265/R060	115-199
D06088 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06088 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06090	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1520/265/R060	001-099
D06090	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1520/272/R055	115-199
D06090 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06090 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06092	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1548/265/R060	001-099
D06092	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1553/272/R55	115-199
D06092 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06092 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06094	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1583/265/R060	001-099
D06094	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1583/272/R55	115-199
D06094 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06094 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06096	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1610/265/R060	001-099
D06096	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1595/272/R55	115-199

EQUIPMENT LIST

D280N032

Section D06000

Page 11

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06096 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D06096 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D06098	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1623/265/R060	001-099
D06098	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1615/272/R055	115-199
D06098 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099

EQUIPMENT LIST

D280N032

Section D06000
Page 12 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06240	1	BACC63BP14A7SNL PLUG	81205	1	29-11-12 N252/147/L6	ALL
D06240 T		BACC10HF14A CABLE CLAMP	81205	1	29-11-12 N252/143/L6	001-099
D06240 T		BACC10HF14A CABLE CLAMP	81205	1	29-11-12 */*/*	115-199
D06242	1	BACC63BP14A7SNL PLUG	81205	1	29-11-22 PPS217/148/L2	ALL
D06242 T		BACC10HF14C CABLE CLAMP	81205	1	29-11-22 /148/L2	ALL

EQUIPMENT LIST

D280N032

Section D06200

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06302	1	172168-1 PLUG-	00779	1	33-21-41 800/268/R60	ALL
D06304	1	172160-1 RCPT-	00779	1	33-21-41 800/268/R60	ALL
D06306	1	172160-1 RCPT-	00779	1	33-21-32 800/268/L60	ALL
D06308	1	172168-1 PLUG-	00779	1	33-21-32 800/268/L60	ALL
D06316	1	BACC45FN20-16S RCPT-	81205	1	33-24-12 680/290/L25	115-199
D06316 T		69-74374-5 PSU BRACKET	81205	1	33-24-12 */*/*	115-199
D06318	1	BACC45FN20-16S RCPT-	81205	1	33-24-21 670/290/R44	115-199
D06318 T		69-74374-5 PSU BRACKET	81205	1	33-24-21 670/290/R44	115-199
D06324	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	30-21-11 P037-00/ /	001-099
D06324	1	BACS16AG1 RELAY SOCKET (PLATE 'C')	81205	1	30-21-11 P37/ /	115-199
D06326	1	BACS16AG1 RELAY SOCKET (PLATE 'A')	81205	1	30-21-11 P36/ /	ALL
D06330	1	BACC45FN20-16S RCPT-	81205	1	33-24-21 730/265/R060	115-199
D06330 T		69-74374-5 PSU BRACKET	81205	1	33-24-21 730/265/R060	115-199
D06390	1	BACC45FN12-12S RCPT-	81205	1	33-51-21 520/205/L9	001-099
D06390	1	BACC45FN12-12S RCPT	81205	1	33-51-21 520/205/L9	115-199
D06392	1	BACC45FN12-12S RCPT-	81205	1	33-51-21 820/205/L9	001-099
D06392	1	BACC45FN12-12S RCPT	81205	1	33-51-21 820/205/L9	115-199

EQUIPMENT LIST

D280N032

Section D06300

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06394	1	BACC45FN12-12S RCPT-	81205	1	33-51-22 1240/205/L009	001-099
D06394	1	BACC45FN12-12S RCPT-	81205	1	33-51-22 1240/205/L9	115-199
D06396	1	BACC45FN12-12S RCPT-	81205	1	33-51-22 1520/205/L009	001-099
D06396	1	BACC45FN12-12S RCPT-	81205	1	33-51-22 1520/205/L9	115-199

EQUIPMENT LIST

D280N032

Section D06300

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06400	1	BACC45FT16D24S PLUG	81205	1	73-21-12 P005-00/ /	ALL
D06402	1	BACC45FT16A24S7 PLUG	81205	1	73-21-22 P005-00/ /	ALL
D06450	1	BACC45FT10D5S6 PLUG	81205	1	26-23-11 1190/160/0	115-199
D06486	1	BACC45FT12A12S PLUG-	81205	1	33-13-61 286/267/L039	ALL
D06488		BACC45FT12-12S PLUG	81205	1	33-13-52 P008-00/ /	001-099
D06488		BACC45FT12-12S PLUG	81250	1	33-13-52 P8/ /	115-199

EQUIPMENT LIST

D280N032

Section D06400
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06790	1	BACC63CD24-22S RCPT-	81205	1	25-31-13 AB0317/ /	115-199

EQUIPMENT LIST

D280N032

Section D06700

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06854	1	48-7191 RCPT-	02660	1	33-51-14 1000/290/L 14	001-099
D06856	1	48-7190 PLUG-	02660	1	33-51-14 1000/290/L 14	001-099
D06870	1	BACC45FT12A12S7 PLUG	81205	1	28-41-11 P005-00/ /	001-099
D06870	1	BACC45FT12A12S7 PLUG	81205	1	28-41-11 P5/ /	115-199
D06872	9	BACC45FT12A12S10 PLUG (MR69018-002)	81205	1	28-41-11 P5/ /	115-199
D06872	1	BACC45FT12A12S10 PLUG	81205	1	28-41-11 P005-00/ /	001-099
D06874	1	BACC63BP20A16SNL PLUG	82105	1	28-41-11 P28/ /	ALL
D06874 T		BACC10HG20A CABLE CLAMP	81205	1	28-41-11 P28/ /	ALL
D06876	1	BACC63BP20A16SNL CENTER LOAD SEL IND	81205	1	28-41-11 P28/ /	ALL
D06876 T		BACC10HG20A CABLE CLAMP	81205	1	28-41-11 P28/ /	ALL
D06878	1	BACC63BP20A16SNL LEFT MAIN LOAD SEL IND	81205	1	28-41-11 P28/ /	ALL
D06878 T		BACC10HG20A CABLE CLAMP	81205	1	28-41-11 P28/ /	ALL
D06880	1	CN1156-2 PLUG-	13556	1	28-41-21 OSS336/ /	001-099
D06880 T	1	BACC10HF24A CABLE CLAMP-	81205	1	28-41-21 */ /*	001-099
D06882	1	CN1156-4 PLUG	13556	1	28-41-21 IRSS258/ /	ALL
D06882 T	1	BACC10HF18A CABLE CLAMP	81205	1	28-41-21 / /	ALL
D06884	1	CN1156-2 PLUG-	13556	1	28-41-31 OSS335/ /	001-002

EQUIPMENT LIST

D280N032

Section D06800

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06884	1	CN1156-2 PLUG-	13556	1	28-41-31 OSS360/ /	003-099
D06884 T	1	BACC10HF24A CABLE CLAMP-	81205	1	28-41-31 */ /	001-099
D06886	1	CN1156-4 PLUG	13556	1	28-41-31 IRSS255/ /	ALL
D06886 T	1	BACC10HF18A CABLE CLAMP	81205	1	28-41-31 IRSS255/ /	ALL
D06888	1	CN1156-4 PLUG	13556	1	28-41-41 ISS101/ /	001-099
D06888 T		BACC10HF18A CABLE CLAMP	81205	1	28-41-41 / /	001-099
D06890	1	CN1156-4 PLUG	71785	1	28-41-41 IRSS160/ /	ALL
D06890 T	1	BACC10KD18 CABLE CLAMP	81205	1	28-41-41 */ */	ALL
D06892	1	CN1156-4 PLUG-	13556	1	28-41-41 FSS100/ /	001-099
D06892 T	1	BACC10HF18A CABLE CLAMP	81205	1	28-41-41 FSS100/ /	001-099
D06894	1	48-7190 PLUG-ALT STAB TRIM LIGHT	81205	1	33-13-51 P010-00/ /	ALL
D06896	1	48-7191 RCPT-ALT STAB TRIM LIGHT	81205	1	33-13-51 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D06800

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06910	1	BACC45FT16A24S PLUG-	81205	1	33-51-14 840/272/R049	001-006
D06912	1	BACS16X3A RELAY SOCKET (PLATE 'F')	81205	1	21-43-11 P070-00/ /	001-099
D06914	9	BACS16AF1 RELAY SOCKET (PLATE A)(MR69018-002)	81205	1	32-09-11 P036-00/ /	115-199
D06914	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	32-09-11 P36/ /	001-099
D06916	1	48-7191 RCPT-	02660	1	33-51-14 685/290/L25	001-099
D06918	1	48-7190 PLUG-	02660	1	33-51-14 685/290/L25	001-099
D06920	1	48-7191 RCPT-	02660	1	33-51-14 685/290/L25	001-099
D06922	1	48-7190 PLUG-	02660	1	33-51-14 685/290/L25	001-099

EQUIPMENT LIST

D280N032

Section D06900
Page 1 End
May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07002	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	73-21-12 P36/ /	ALL
D07004	1	BACS16W5A RELAY SOCKET (PLATE 'F')	81205	1	73-21-12 P36/ /	ALL
D07006	1	BACS16X1A RELAY SOCKET (PLATE 'B')	81205	1	73-21-22 P037-00/ /	001-099
D07006	1	BACS16X1A RELAY SOCKET (PLATE 'B')	81205	1	73-21-22 P37/ /	115-199
D07008	1	BACS16W5A RELAY SOCKET (PLATE 'B')	81205	1	73-21-22 P037-00/ /	001-099
D07008	1	BACS16W5A RELAY SOCKET (PLATE 'B')	81205	1	73-21-22 P37/ /	115-199
D07010	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1320/265/L060	001-099
D07010	1	BACC45FN20-16S RCPT-	81205	1	33-23-13 1320/272/L55	115-199
D07010 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1320/265/L060	001-099
D07010 T		69-74374-5 PSU BRACKET	81205	1	33-23-13 1320/272/L55	115-199
D07012	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1320/265/R060	001-099
D07012	1	BACC45FN20-16S RCPT-	81205	1	33-23-23 1320/265/R060	115-199
D07012 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 */*/	001-099
D07012 T		69-74374-5 PSU BRACKET	81205	1	33-23-23 */*/	115-199
D07020	1	BACS16W3 RELAY SOCKET	81205	1	33-13-52 P008-00/ /	001-099
D07020	1	BACS16W3 RELAY SOCKET	81205	1	33-13-52 P8/ /	115-199
D07026	1	BACS16X1A RELAY SOCKET (PLATE 'C')	81205	1	74-31-21 P037-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D07000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07026	1	BACS16X1A RELAY SOCKET (PLATE 'C')	81205	1	74-31-21 P37/ /	115-199
D07028	1	BACS16X1A RELAY SOCKET (PLATE 'D')	81205	1	74-31-11 P36/ /	ALL
D07036	1	BACS16W5A RELAY SOCKET (PLATE 'F')	81205	1	36-11-11 P36/ /	ALL
D07038	1	BACS16W5A RELAY SOCKET (PLATE 'B')	81205	1	36-11-21 P037-00/ /	001-099
D07038	1	BACS16W5A RELAY SOCKET (PLATE 'B')	81205	1	36-11-21 P37/ /	115-199
D07046	1	BACS16AF1 RELAY SOCKET (PLATE 'A')	81205	1	77-12-41 P36/ /	ALL
D07058	1	BACS16X3 RELAY SOCKET-P71 LEFT AC BUS OFF RELAY	81205	1	24-25-11 P71/ /	001-002, 115-199
D07060	1	BACS16X3 RELAY SOCKET-P71RIGHT AC BUS OFF RELAY	81205	1	24-25-11 P71/ /	001-002, 115-199
D07062	1	SO-1064-003 RELAY SOCKET-P71 HYD GEN CONT RELAY	35344	1	24-25-11 P71/ /	001-002, 115-199
D07064	1	BACS16AH1 RELAY SOCKET-P71 GEN RESET RELAY	81205	1	24-25-11 P71/ /	001-002, 115-199
D07066	1	R071120A25PN RCPT-HYDRAULIC MOTOR GENERATOR(P1)	41118	1	24-25-12 1170/175/L003	ALL
D07066 T		BACC10HF20 CABLE CLAMP	81205	1	24-25-12 1170/175/L003	ALL
D07068	1	BACC63BV14A4PN RCPT-HYDRAULIC MOTOR GENERATOR(P2)	81205	1	24-25-12 1165/168/L003	ALL
D07068 T		BACC10HF14 CABLE CLAMP	81205	1	24-25-12 1165/168/L003	ALL
D07070	1	BACC45FS16-24S PLUG-P71 HYD GEN CONT UNIT	81205	1	24-25-12 P71/ /	ALL
D07072	1	BACC63BP10B5SNL PLUG-HYDRAULIC MOTOR GENERATOR (J3)	81205	1	24-25-12 1170/173/L003	ALL
D07072 T		BACC10HG10 CABLE CLAMP	81205	1	24-25-12 1170/173/L003	ALL

EQUIPMENT LIST

D280N032

Section D07000

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07074	1	BACC63BP16A10SNL PLUG-HYD MTR GEN S/O VALVE	81205	1	24-25-13 1162/182/L004	ALL
D07074 T		BACC10HG16 CABLE CLAMP	81205	1	24-25-12 1162/182/L004	ALL
D07076	1	BACC45FT18B31S PLUG-EQUIP COOLING AUX FAN	81205	1	21-58-15 425/190/L060	ALL
D07078	1	BACS16W1A RELAY SOCKET (PLATE 'F')	81205	1	21-58-15 P36/ /	ALL
D07080	1	BACS16W2A RELAY SOCKET (PLATE 'A')	81205	1	33-51-11 P037-00/ /	001-099
D07080	1	BACS16W2A RELAY SOCKET (PLATE 'A')	81205	1	33-51-11 P37/ /	115-199
D07084	1	BACC63BP18A8SNL PLUG-	81205	1	33-43-11 OSS839/ /L	ALL
D07084 T		BACC10HF18 CABLE CLAMP-	81205	1	33-43-11 */ /*	ALL
D07086	1	BACC63BP18A8SNL PLUG-	81205	1	33-43-12 OSS839/ /R	ALL
D07086 T		BACC10HF18 CABLE CLAMP-	81205	1	33-43-12 FSS841/ /	ALL

EQUIPMENT LIST

D280N032

Section D07000

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07156	1	BACC45FN12-12S RCPT-	81205	1	SPARE 1311/288/L15	001-099
D07156	1	BACC45FN12-12S RCPT-	81205	1	33-51-14 1310/288/L17	115-199
D07160	1	48-7190 PLUG-FLT DECK DOOR LOCK	02660	1	52-51-11 0308/250/R.35	ALL
D07162	1	48-7191 RCPT-FLT DECK DOOR LOCK	02660	1	52-51-11 0308/250/R.35	ALL

EQUIPMENT LIST

D280N032

Section D07100
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07210	1	BACS16W2 PLUG	81205	1	33-22-11 P034-00/ /	001-099
D07210	1	BACS16W2 PLUG	81205	1	33-22-11 P34/ /	115-199
D07266	1	48-7191 RCPT-	02660	1	33-51-21 325/216/R065	001-099
D07266	1	48-7191 RCPT-	02660	1	33-51-21 325/216/R65	115-199
D07268	1	48-7191 RCPT-	02660	1	33-51-21 330/221/L70	ALL
D07270	1	48-7191 RCPT	02660	1	33-51-21 732/216/R65	001-099
D07270	1	48-7191 RCPT-	02660	1	33-51-21 732/216/R65	115-199
D07272	1	48-7191 RCPT-	02660	1	33-51-21 678/216/L70	001-099
D07272	1	48-7191 RCPT	02660	1	33-51-21 678/216/L70	115-199
D07274	1	48-7191 RECP-EMERGENCY AISLE LIGHT	02660	18	33-51-12 MULTI/ /	ALL
D07276	1	48-7190 PLUG-EMERGENCY AISLE LIGHT	02660	18	33-51-12 MULTI/ /	ALL
D07282	1	48-7191 RCPT-	02660	1	33-51-22 1684/216/R070	001-099
D07282	1	48-7191 RCPT	02660	1	33-51-22 1684/216/R70	115-199
D07284	1	48-7191 RCPT	02660	1	33-51-22 1684/216/L70	001-099
D07284	1	48-7191 RCPT-	02660	1	33-51-22 1684/216/L70	115-199
D07286	1	48-7191 RCPT-	02660	1	33-51-22 1350/239/R70	001-099
D07286	1	48-7191 RCPT	02660	1	33-51-22 1350/239/R70	115-199

EQUIPMENT LIST

D280N032

Section D07200

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07288	1	48-7191 RCPT	02660	1	33-51-22 1320/239/L70	001-099
D07288	1	48-7191 RCPT-	02660	1	33-51-22 1320/239/L70	115-199
D07290	1	BACC45FT16A24S PLUG-	81205	1	33-51-14 1240/270/R49	ALL
D07294	1	48-7190 PLUG-	02660	1	33-51-21 325/216/R065	001-099
D07294	1	48-7190 PLUG-	02660	1	33-51-21 325/216/R65	115-199
D07296	1	48-7190 PLUG-	02660	1	33-51-21 330/216/L70	001-099
D07296	1	48-7190 PLUG	02660	1	33-51-21 330/216/L70	115-199
D07298	1	48-7190 PLUG	02660	1	33-51-21 732/216/R65	001-099
D07298	1	48-7190 PLUG-	02660	1	33-51-21 732/216/R65	115-199

EQUIPMENT LIST

D280N032

Section D07200

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07300	1	48-7190 PLUG-	02660	1	33-51-21 678/216/L70	001-099
D07300	1	48-7190 PLUG	02660	1	33-51-21 678/216/L70	115-199
D07310	1	48-7190 PLUG-	02660	1	33-51-22 1684/216/R070	001-099
D07310	1	48-7190 PLUG-	02660	1	33-51-22 1684/216/R70	115-199
D07312	1	48-7190 PLUG-	02660	1	33-51-22 1684/216/L70	ALL
D07314	1	48-7190 PLUG-	02660	1	33-51-22 1350/239/R70	ALL
D07316	1	48-7190 PLUG-	02660	1	33-51-22 1320/239/L70	ALL
D07346	1	BACC45FN18-14S RCPT-	81205	1	33-23-24 1350/265/R60	001-099
D07346	1	BACC45FN20-16S RCPT-	81205	1	33-23-24 1350/265/R60	115-199
D07346 T		69-74374-3 PSU BRACKET	81205	1	33-23-24 1320/262/R60	001-099
D07346 T		69-74374-5 PSU BRACKET	81205	1	33-23-24 */*/	115-199
D07348	1	BACC45FN18-14S RCPT-	81205	1	33-23-14 1350/*/*	001-099
D07348	1	BACC45FN20-16S RCPT-	81205	1	33-23-14 1350/272/L55	115-199
D07348 T		69-74374-3 PSU BRACKET	81205	1	33-23-14 1350/*/*	001-099
D07348 T		69-74374-5 PSU BRACKET	81205	1	33-23-14 */*/	115-199

EQUIPMENT LIST

D280N032

Section D07300

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07418	1	CN0966A10A20SN-000 PLUG	13556	1	36-22-11 902/160/L65	ALL
D07418 T		BACC10HG10 CABLE CLAMP	81205	1	36-22-11 */*/*	ALL
D07454	1	172160-1 RCPT-	00779	1	33-21-32 1040/268/L60	ALL
D07456	1	172168-1 PLUG-	00779	1	33-21-32 1040/268/L60	ALL
D07458	1	172160-1 RCPT-	00779	1	33-21-32 1200/268/L60	ALL
D07460	1	172168-1 PLUG-	00779	1	33-21-32 1200/268/L60	ALL
D07462	1	172160-1 RCPT-	00779	1	33-21-32 1360/268/L60	ALL
D07464	1	172168-1 PLUG-	00779	1	33-21-32 1360/268/L60	ALL
D07466	1	172160-1 RCPT-	00779	1	33-21-32 1520/268/L60	ALL
D07472	1	172168-1 PLUG-	00779	1	33-21-41 1040/268/R60	ALL
D07474	1	172160-1 RCPT-	00779	1	33-21-41 1040/268/R60	ALL
D07476	1	172168-1 PLUG-	00779	1	33-21-41 1200/268/R60	ALL
D07478	1	172160-1 RCPT-	00779	1	33-21-41 1200/268/R60	ALL
D07480	1	172168-1 PLUG-	00779	1	33-21-41 1360/268/R60	ALL
D07482	1	172160-1 RCPT-	00779	1	33-21-41 1360/268/R60	ALL
D07484	1	172168-1 PLUG-	00779	1	33-21-41 1520/268/R60	ALL
D07486	1	172160-1 RCPT-	00779	1	33-21-41 1520/268/R60	ALL

EQUIPMENT LIST

D280N032

Section D07400

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07488	1	172168-1 PLUG-	00779	1	33-21-32 1520/268/L60	ALL
D07496	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 470/273/R30	ALL
D07498	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 470/273/R30	ALL

EQUIPMENT LIST

D280N032

Section D07400

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07500	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 770/272/R30	001-099
D07500	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 770/273/R30	115-199
D07502	1	48-7191 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 770/272/R30	001-099
D07502	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 770/273/R30	115-199
D07504	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 590/273/R30	001-099
D07504	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 590/273/R30	115-199
D07506	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 590/273/R30	001-099
D07506	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 590/273/R30	115-199
D07508	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 420/273/L030	001-099
D07508	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 420/273/L30	115-199
D07510	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 420/273/L030	001-099
D07510	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 420/273/L30	115-199
D07512	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 520/273/L030	001-099
D07512	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 520/273/R30	115-199
D07514	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 520/273/L030	001-099
D07514	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 520/273/L30	115-199
D07516	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 640/273/L030	001-099

EQUIPMENT LIST

D280N032

Section D07500

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07516	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 640/273/L30	115-199
D07518	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 640/273/L030	001-099
D07518	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-12 640/273/L30	115-199
D07520	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 880/273/R30	001-099
D07520	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 880/273/R30	115-199
D07522	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 880/273/R30	001-099
D07522	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 880/273/R30	115-199
D07524	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 820/273/L030	001-099
D07524	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 820/273/R30	115-199
D07526	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 820/273/L030	001-099
D07526	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 820/273/R30	115-199
D07528	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 1070/273/L30	001-099
D07528	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 TBD/ /	115-199
D07530	1	48-7191 RCPT-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 1070/273/L30	001-099
D07530	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 TBD/ /	115-199
D07532	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 950/273/L30	001-099
D07532	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 TBD/ /	115-199

EQUIPMENT LIST

D280N032

Section D07500

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07534	1	48-7191 RCPT-EMERGENCY AISLE LIGHTS	02660	1	33-51-13 950/273/L30	001-099
D07534	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 TBD/ /	115-199
D07536	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1190/286/L040	ALL
D07538	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1190/286/L040	ALL
D07540	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1250/273/R30	001-099
D07540	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1250/273/R030	115-199
D07542	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1250/273/R30	001-099
D07542	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1250/273/R030	115-199
D07544	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1100/ /R	001-099
D07544	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 TBD/ /	115-199
D07546	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1100/ /R	001-099
D07546	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 TBD/ /	115-199
D07556	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1400/ /R	001-099
D07556	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 TBD/ /	115-199
D07558	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1400/ /R	001-099
D07558	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 TBD/ /	115-199
D07560	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1480/ /R	001-099

EQUIPMENT LIST

D280N032

Section D07500

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07560	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1530/270/R35	115-199
D07562	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1480/ /R	001-099
D07562	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1530/270/R35	115-199
D07564	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1585/273/L030	ALL
D07566	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1585/273/L030	ALL
D07568	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1460/273/L030	001-099
D07568	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1460/273/L030	115-199
D07570	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 1460/273/L030	001-099
D07570	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-14 1460/273/L030	115-199

EQUIPMENT LIST

D280N032

Section D07500

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07602	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 980/ /R	001-099
D07602	1	48-7190 PLUG-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 TBD/ /	115-199
D07604	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 980/ /R	001-099
D07604	1	48-7191 RECP-EMERGENCY AISLE LIGHTS	02660	1	33-51-15 TBD/ /	115-199
D07608	1	BACS16X3A RELAY SOCKET (PLATE 'B')	81205	1	21-44-11 P037-00/ /	001-099
D07612	1	BACC45FN10-5S RCPT	81205	1	33-22-12 670/295/L25	001-099
D07656	1	BACC45FN24-43P RCPT-LAV B PROVISIONS	81205	1	33-26-21 1246/290/L022	001-099
D07658	1	MS3126F14-19S PLUG PRINTER	09922	1	31-31-02 P008-54/ /	001-099
D07660	1	BACS16X1A RELAY SOCKET	81205	1	24-25-11 P71/ /	003-099
D07666	1	BACC45FT12A12S PLUG	81205	1	33-13-32 286 P5/267/L39	001-099
D07666	1	BACC45FT12-12S PLUG	81205	1	33-13-32 P5/ /	115-199
D07668	1	BACS16X1A PLUG	81205	1	33-13-32 P005-00/267/L039	001-099
D07668	1	BACS16X1 PLUG	81205	1	33-13-32 P5/ /	115-199
D07672		SR-PA1-N8A-S1 RCPT	77820	1	24-25-12 E001-01/ /	003-099
D07672 T		63-9273-2 SEPARATOR-NYLON COAX	81205	1	24-25-12 */ */	003-099
D07678	1	BACS16X1 RELAY SOCKET		1	24-33-12 E6 RLY/PNL/	002-008, 010-099
D07688	1	BACC45FN12-12S RCPT-	81205	1	78-36-11 200/180/L001	ALL

EQUIPMENT LIST

D280N032

Section D07600

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07710	1	BACC45FN12-12S6 RCPT	81205	1	78-36-21 200/185/L001	ALL
D07718	9	BACS16AH1 SOCKET-INFLIGHT INHIBIT RELAY,L(PLATE A)	81205	1	78-36-11 P36/ /	001-002
D07718	9	BACS16AH1 SOCKET-INFLIGHT INHIBIT RELAY,L(PLATE A)	81205	1	78-36-11 P036-00/ /	115-199
D07718	1	BACS16AH1 SOCKET-INFLIGHT INHIBIT RELAY,L(PLATE A)	81205	1	78-36-11 P36/ /	001-099
D07720	9	BACS16AH1 RELAY SOCKET - (PLATE A) (SB78-32)	81205	1	78-36-21 P037-00/ /	001-002
D07720	9	BACS16AH1 RELAY SOCKET (PLATE A)	81205	1	78-36-21 P037-00/ /	115-199
D07720	1	BACS16AH1 RELAY SOCKET - (PLATE A) (SB78-32)	81205	1	78-36-21 P037-00/ /	001-002
D07720	1	BACS16AH1 RELAY SOCKET - (PLATE 'A')	81205	1	78-36-21 P037-00/ /	003-099
D07720	1	BACS16AH1 RELAY SOCKET (PLATE A)	81205	1	78-36-21 P037-00/ /	115-199
D07734	1	BACC63BP14A7SNL PLUG	81205	1	28-22-32 1039/187/R4	009-099
D07734 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-32 1039/187/R4	009-099
D07736	1	BACS16AF1 RELAY SOCKET	81205	1	28-22-31 P33/ /	009-099
D07738	1	BACS16AF1 RELAY SOCKET	81205	1	28-22-31 P33/ /	009-099
D07744	1	BACC63BP14A7SNL PLUG	81205	1	28-22-31 1040/184/L013	009-099
D07744 T		BACC10HG14 CABLE CLAMP	81205	1	28-22-31 */ */	009-099
D07750	9	BACS16X1A RELAY SOCKET (PLATE A)	81205	1	32-61-11 P037-00/ /	115-199
D07750	1	BACS16X1A RELAY SOCKET - (PLATE A) (SB78-32)	81205	1	32-61-11 P037-00/ /	001-002

EQUIPMENT LIST

D280N032

Section D07700

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07750	1	BACS16X1A RELAY SOCKET - (PLATE 'A')	81205	1	32-61-11 P037-00/ /	003-099
D07750	1	BACS16X1A RELAY SOCKET (PLATE A)	81205	1	32-61-11 P037-00/ /	115-199
D07766	9	BACS16X1A RELAY SOCKET (PLATE A) (SB78-32)	81205	1	78-34-61 P037-00/ /	001-002
D07766	9	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	78-34-61 P037-00/ /	115-199
D07766	1	BACS16X1A RELAY SOCKET (PLATE A) (SB78-32)	81205	1	78-34-61 P037-00/ /	001-002
D07766	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	78-34-61 P037-00/ /	003-099, 115-199
D07768	9	BACS16X1A RELAY SOCKET (PLATE 'A')	81206	1	78-34-21 P037-00/ /	115-199
D07768	1	BACS16X1A RELAY SOCKET (PLATE A)(SB78-32)	81205	1	78-34-21 P037-00/ /	001-002
D07768	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81206	1	78-34-21 P37/ /	003-099
D07768	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81206	1	78-34-21 P037-00/ /	115-199
D07776	9	BACS16X1A SOCKET - SYNC LOCK RELAY (PLATE A)	81205	1	78-34-51 P36/ /	001-002
D07776	9	BACS16X1A SOCKET-SYNC LOCK RELAY (PLATE 'A')	81205	1	78-34-51 P036-00/ /	115-199
D07776	1	BACS16X1A SOCKET - SYNC LOCK RELAY (PLATE A)	81205	1	78-34-51 P36/ /	001-002
D07776	1	BACS16X1A SOCKET-SYNC LOCK RELAY (PLATE 'A')	81205	1	78-34-51 P36/ /	003-099
D07778	9	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	78-34-61 P037-00/ /	115-199
D07778	1	BACS16X1A RELAY SOCKET (PLATE A) (SB78-32)	81205	1	78-34-61 P037-00/ /	001-002
D07778	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	78-34-61 P37/ /	003-099

EQUIPMENT LIST

D280N032

Section D07700

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07778	1	BACS16X1A RELAY SOCKET (PLATE 'A')	81205	1	78-34-61 P037-00/ /	115-199

EQUIPMENT LIST

D280N032

Section D07700

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07814	1	BACC63BN14C7S PLUG	81205	1	36-11-31 907.4/147/R033	009-099

EQUIPMENT LIST

D280N032

Section D07800
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07994	1	BACC45FT16A24S PLUG-	81205	1	33-51-14 850/272/R049	007-099

EQUIPMENT LIST

D280N032

Section D07900

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10656	1	BACC45FT10A5S PLUG	81205	1	26-23-11 1183/190/R003	001-099
D10656	1	BACC45FT10A5S PLUG	82105	1	26-23-11 1183/190/R03	115-199

EQUIPMENT LIST

D280N032

Section D10600
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10750		BACS16W1 RELAY SOCKET (PLATE 'A')	81205	1	30-31-12 P037-00/ /	001-099
D10750		BACS16W1A RELAY SOCKET (PLATE 'A')	81205	1	30-31-12 P037-00/ /	115-199

EQUIPMENT LIST

D280N032

Section D10700

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11710	9	BACS16X6A RELAY SOCKET (PLATE B)	81205	1	28-22-11 P037-00/ /	ALL
D11712	9	BACS16W10A RELAY-SOCKET (PLATE B)	81205	1	28-22-11 P037-00/ /	ALL
D11714	9	BACS16W10A RELAY SOCKET (PLATE D)	81205	1	28-22-11 P033-00/ /	ALL
D11716	9	BACS16X6A RELAY SOCKET (PLATE D)	81205	1	28-22-11 P033-00/ /	ALL
D11718		M83723-91G14156 PLUG	81205	1	28-41-41 IRSS160/ /	ALL
D11718 T		387AA020Z114A-D-342 CABLE CLAMP	06324	1	28-41-41 */ */ *	ALL
D11720		M83723-91G1415N PLUG	81205	1	28-41-41 IRSS160/ /	ALL
D11720 T		387AA020Z114AD-342 CABLE CLAMP	06324	1	28-41-41 / /	ALL

EQUIPMENT LIST

D280N032

Section D11700

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D21001J	9	BACC45FN22-55S RCPT-	81205	1	34-43-15 E002-01/ /	002
D21001P	9	BACC45FT22-55P PLUG- CONDUCTIVE (S/B: 757-34-0200)	06090	1	34-46-14 E002-01/ /	002

EQUIPMENT LIST

D280N032

Section D21000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D22001J	9	BACC45FN20-41S9 RCPT- (S/B: 757-34-0200)	81205	1	34-43-15 N002-02/ /	002
D22001P	9	BACC45FT20-41P9 PLUG- CONDUCTIVE (S/B: 757-34-0200)	06090	1	34-43-15 E002-02/ /	002

EQUIPMENT LIST

D280N032

Section D22000
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D23003J	9	BACC45FN22-55S7 RECPT- (S/B 757-34-0200)	81205	1	34-22-28 E002-03/ /	002
D23003P	9	BACC45FT22-55P7 PLUG- CONDUCTIVE (S/B: 757-34-0200)	06090	1	34-46-14 AE0203/ /	002
D23005J	9	BACC45FN18-31P9 RECPT- (S/B 757-34-0200)	81205	1	34-22-18 E002-03/ /	002
D23005P	9	BACC45FT18-31S9 PLUG- CONDUCTIVE (S/B: 757-34-0200)	06090	1	34-46-14 E002-03/ /	002

EQUIPMENT LIST

D280N032

Section D23000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40002J	1	CN0967C22G55S9-000 RCPT	13556	1	73-21-11 AC0880/ /	001-004, 115-199
D40002J	1	BACC63CC22-55S9 RCPT	13556	1	73-21-11 AC0880/ /	005-099
D40002JK		BACC10HF22C CABLE CLAMP	81205	1	73-21-11 */ /	ALL
D40002P	1	CN0966A22G55P9-000 PLUG-	13556	1	77-12-11 AC0880/177/68	001-004
D40002P	1	BACC63CB22-55P9 PLUG-	13556	1	77-12-11 AC0880/177/68	005-099
D40002P	1	CN0966A22G55P9-000 PLUG	13556	1	77-12-11 880/177/68	115-199
D40002PQ		BACC10HF22C CABLE CLAMP	81205	1	77-12-11 */ */	ALL
D40003J	1	BACC45FN20-41P6 RCPT-	81205	1	31-31-01 P061-00/ /	001-099
D40003J	1	BACC45FN20-41P6 RCPT-	81205	1	31-31-11 P061-00/ /	115-199
D40003P	1	BACC45FT20A41S6 PLUG-	81205	1	31-31-01 P061-00/ /	001-099
D40003P	1	BACC45FT20A41S6 PLUG-	81205	1	31-31-11 P061-00/ /	115-199
D40004J	1	CN0967C22G55S6-000 RCPT	13556	1	73-21-21 AD0880/ /	001-004, 115-199
D40004J	1	BACC63CC22-55S6 RCPT	13556	1	73-21-21 AD0880/ /	005-099
D40004JK		BACC10HF22C CABLE CLAMP	81205	1	73-21-21 */ /	ALL
D40004P	1	CN0966A22G55P6-000 PLUG	13556	1	77-12-31 AD0880/ /	001-004, 115-199
D40004P	1	BACC63CB22-55P6 PLUG	13556	1	77-12-31 AD0880/ /	005-099
D40004PQ		BACC10HF22C CABLE CLAMP	81205	1	77-12-31 */ */	ALL

EQUIPMENT LIST

D280N032

Section D40000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40006J	1	CN0967C28G42SN-000 RCPT	13556	1	79-34-11 AC0880/ /	001-004
D40006J	1	BACC63CC28-42SN RCPT	81205	1	79-34-11 AC0880/ /	005-099
D40006J	1	CN0967C28G42SN-000 RCPT	13556	1	73-31-11 AC0880/ /	115-199
D40006JK		BACC10HF28C CABLE CLAMP	81205	1	79-34-11 */ */	001-099
D40006JK		BACC10HF28C CABLE CLAMP	81205	1	73-31-11 */ /	115-199
D40006P	1	CN0966A28G42PN-000 PLUG	13556	1	73-31-11 AC0880/ /	001-004, 115-199
D40006P	1	BACC63CB28-42PN PLUG	13556	1	73-31-11 AC0880/ /	005-099
D40006PQ		BACC10HF28C CABLE CLAMP	81205	1	73-31-11 AC0880/ /	ALL
D40007J	1	BACC45FN10-5S7 RCPT	81205	1	27-21-11 E5-2/ /	ALL
D40007P	1	BACC45FT10-5P7 PLUG-	81205	1	27-21-11 E005-02/ /	001-099
D40007P	1	BACC45FT10-5P7 PLUG-	81205	1	27-21-11 E5-2/ /	115-199
D40009P	1	BACC45FT18A31P PLUG	81205	1	23-42-11 665/210/R65	115-199
D40012J	1	BACC63BV14B7PN RCPT	81205	1	78-34-11 AS1123/ /	ALL
D40012JK		BACC10HD14A CABLE CLAMP	81205	1	78-34-11 AS1124/ /	ALL
D40012P	1	BACC63BP14B7SNL PLUG	81205	1	78-34-11 AS11233/ /	ALL
D40012PQ		BACC10HD14A CABLE CLAMP	81205	1	78-34-11 */ */	ALL
D40014J	1	CN0967C24G30S7-000 RCPT	13556	1	76-11-11 AC0880/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D40000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40014J	1	BACC63CC24-30S7 RCPT	13556	1	76-11-11 AC0880/ /	005-099
D40014JK		BACC10HF24C CABLE CLAMP	81205	1	76-11-11 */ /	ALL
D40014P	1	CN0966A24G30P7-000 PLUG-	13556	1	77-22-12 AC0880/181/65	001-004
D40014P	1	BACC63CB24-30P7 PLUG-	13556	1	77-22-12 AC0880/181/65	005-099
D40014P	1	CN0966A24G30P7-000 PLUG	13556	1	77-22-12 880/181/65	115-199
D40014PQ		BACC10HF24C CABLE CLAMP	81205	1	77-22-12 */ */	ALL
D40015J	1	BACC45FN18-31S9 RCPT	81205	1	22-24-21 E004-01/ /	001-099
D40015J	1	BACC45FN18-31S9 RCPT	81205	1	22-24-21 E4-1/ /	115-199
D40015P	1	BACC45FT18A31P9 PLUG	81205	1	22-24-21 E004-01/ /	001-099
D40015P	1	BACC45FT18A31P9 PLUG	81205	1	22-21-21 E004-01/ /	115-199
D40016J	1	CN0967C24G30SN-000 RCPT	13556	1	26-11-21 AD0880/ /	001-004, 115-199
D40016J	1	BACC63CC24-30SN RCPT	13556	1	26-11-21 AD0880/ /	005-099
D40016JK		BACC10HF24C CABLE CLAMP	81205	1	26-11-21 */ /	ALL
D40016P	1	CN0966A24G30PN-000 PLUG	13556	1	26-18-21 AD0880/ /	001-004, 115-199
D40016P	1	BACC63CB24-30PN PLUG	13556	1	26-18-21 AD0880/ /	005-099
D40016PQ		BACC10HF24C CABLE CLAMP	81205	1	26-18-21 */ */	ALL
D40018J	1	CN0967C28G42S8-000 RCPT-	13556	1	75-31-11 AC0880/ /	001-004

EQUIPMENT LIST

D280N032

Section D40000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40018J	1	BACC63CC28-42S8 RCPT-	13556	1	75-31-11 AC0880/ /	005-099
D40018J	1	CN0967C28G42S8-000 RCPT	13556	1	75-31-11 AC0880/ /	115-199
D40018JK		BACC10HF28C CABLE CLAMP	81205	1	75-31-11 */ */	ALL
D40018P	1	CN0966A28G42P8-000 PLUG	13556	1	77-11-11 AC0880/ /	001-004, 115-199
D40018P	1	BACC63CB28-42P8 PLUG	13556	1	77-11-11 AC0880/ /	005-099
D40018PQ		BACC10HF28C CABLE CLAMP	81205	1	77-11-11 */ */	ALL
D40020J	1	CN0967C28G42S8-000 RCPT	13556	1	75-31-11 AD0880/ /	001-004, 115-199
D40020J	1	BACC63CC28-42S8 RCPT	13556	1	75-31-11 AD0880/ /	005-099
D40020JK		BACC10HF28C CABLE CLAMP	81205	1	75-31-11 */ /	ALL
D40020P	1	CN0966A28G42P8-000 PLUG-	13556	1	77-11-11 AD0880/178/R062	001-004
D40020P	1	BACC63CB28-42P8 PLUG-	13556	1	77-11-11 AD0880/178/R062	005-099
D40020P	1	CN0966A28G42P8-000 PLUG	13556	1	77-11-11 880/178/R062	115-199
D40020PQ		BACC10HF28C CABLE CLAMP	81205	1	77-11-11 */ */	001-099
D40020PQ		BACC10HF28C CABLE CLAMP	81205	1	77-11-11 */ */	115-199
D40022J	1	BACC45FN20-28S RCPT	81205	1	28-25-11 P070-00/ /	ALL
D40022P	1	BACC45FT20D28P PLUG	81205	1	28-42-21 P070-00/ /	001-099
D40022P	1	BACC45FT20D28P PLUG	81205	1	28-42-21 P70/ /	115-199

EQUIPMENT LIST

D280N032

Section D40000

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40024J	1	BACC63BV28B42SN RCPT	81205	1	24-11-11 AW1285/ /	ALL
D40024JK		BACC10HG28A CABLE CLAMP	81205	1	24-11-11 */*/	ALL
D40024P	1	BACC63BP28D42PNL PLUG	81205	1	24-11-11 AW1285/ /	ALL
D40024PQ		S2277-28-34 CABLE CLAMP	07418	1	24-11-11 */*/	ALL
D40026J	1	CN0967C18G14S7-000 RCPT	13556	1	26-11-12 AC0880/ /	001-004, 115-199
D40026J	1	BACC63CC18-14S7 RCPT	13556	1	26-11-12 AC0880/ /	005-099
D40026JK		BACC10HF18C CABLE CLAMP	81205	1	26-11-12 */ /	ALL
D40026P	1	CN0966A18G14P7-000 PLUG-	13556	1	78-34-11 AC0880/ /	001-004, 115-199
D40026P	1	BACC63CB18-14P7 PLUG-	13556	1	78-34-11 AC0880/ /	005-099
D40026PQ		BACC10HF18C CABLE CLAMP	81205	1	78-34-11 */*/	ALL
D40028J	1	BACC63BV28A42S6 RCPT	81205	1	24-11-21 AW2285/ /	ALL
D40028JK		BACC10HG28A CABLE CLAMP	81205	1	24-11-21 */*/	ALL
D40028P	1	BACC63BP28A42P6L PLUG	81205	1	24-11-21 AW2285/ /	ALL
D40028PQ		S2277-28-34 CABLE CLAMP	07418	1	24-11-21 */*/	ALL
D40029J	1	BACC45FN14-15S7 RCPT	81205	1	27-51-31 E5-1/ /	001-099
D40029J	1	BACC45FN12-12S7 RCPT	81205	1	27-51-31 E5-1/ /	115-199
D40029P	1	BACC45FT14A15P7 PLUG	81205	1	27-51-31 E005-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D40000

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40029P	1	BACC45FT12A12P7 PLUG	81205	1	27-51-31 AE0501/ /	115-199
D40031J	1	BACC45FN22-55S7 RCPT	81205	1	34-12-11 AP0001/ /	ALL
D40031P	1	BACC45FT22A55P7 PLUG	81205	1	34-12-11 AP0001/ /	001-099
D40031P	1	BACC45FT22A55P7 PLUG	81205	1	34-12-11 217.6/198/L034	115-199
D40032J	1	CN0967C28G42S7-000 RCPT	13556	1	73-31-11 AD0880/ /	001-004, 115-199
D40032J	1	BACC63CC28-42S7 RCPT	81205	1	73-31-11 AD0880/ /	005-099
D40032JK		BACC10HF28C CABLE CLAMP	81205	1	73-31-11 */ */	001-099
D40032JK		BACC10HF28C CABLE CLAMP	81205	1	73-31-11 */ /	115-199
D40032P	1	CN0966A28G42P7-000 PLUG	13556	1	80-11-21 AD0880/ /	001-004, 115-199
D40032P	1	BACC63CB28-42P7 PLUG	13556	1	80-11-21 AD0880/ /	005-099
D40032PQ		BACC10HF28C CABLE CLAMP	81205	1	80-11-21 AD0880/ /	ALL
D40035J	1	BACC45FN22-55S8 RCPT	81205	1	34-12-11 AP0003/ /	ALL
D40035P	1	BACC45FT22A55P8 PLUG	81205	1	22-41-13 AP0003/ /	001-099
D40035P	1	BACC45FT22A55P8 PLUG	81205	1	22-41-13 217.6/198/34	115-199
D40039J	1	BACC45FN22-55S8 RECPT	81205	1	34-12-11 P001-00/ /	001-099
D40039J	1	BACC45FN22-55S8 RECPT	81205	1	34-12-11 AP0001/ /	115-199
D40039P	1	BACC45FT22A55P8 PLUG	81205	1	34-24-11 AP0001/ /	001-099

EQUIPMENT LIST

D280N032

Section D40000

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40039P	1	BACC45FT22A55P8 PLUG	81205	1	34-24-11 217.6/198/L34	115-199
D40042J	1	CN0967C18G14SN-000 RCPT	13556	1	26-11-12 AC0880/ /	001-004, 115-199
D40042J	1	BACC63CC18-14SN RCPT	81205	1	26-11-12 AC0880/ /	005-099
D40042JK		BACC10HF18C CABLE CLAMP	81205	1	26-11-12 */ */	001-099
D40042JK		BACC10HF18C CABLE CLAMP	81205	1	26-11-12 */ /	115-199
D40042P	1	CN0966A18G14PN-000 PLUG	13556	1	26-12-11 AC0880/ /	001-004, 115-199
D40042P	1	BACC63CB18-14PN PLUG	13556	1	26-12-11 AC0880/ /	005-099
D40042PQ		BACC10HF18C CABLE CLAMP	81205	1	26-12-11 */ */	ALL
D40044J	1	BACC63BV18B14PN RECPT	81205	1	36-11-11 AS1123/ /	ALL
D40044JK		BACC10HD18A CABLE CLAMP	81205	1	36-11-11 AS1123/ /	ALL
D40044P	1	BACC63BP18B14SNL PLUG	81205	1	26-12-11 AS1123/ /	ALL
D40044PQ		BACC10HD18A CABLE CLAMP	81205	1	26-12-11 */ */	ALL
D40046J	1	CN0967C18G14S6-000 RCPT	13556	1	26-12-21 AD0880/ /	001-004
D40046J	1	BACC63CC18-14S6 RCPT	81205	1	26-12-21 AD0880/ /	005-099
D40046J	1	CN0967C18G14S6-000 RCPT	13556	1	26-11-22 AD0880/ /	115-199
D40046JK		BACC10HF18C CABLE CLAMP	81205	1	26-12-21 */ */	001-099
D40046JK		BACC10HF18C CABLE CLAMP	81205	1	26-11-22 */ /	115-199

EQUIPMENT LIST

D280N032

Section D40000

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40046P	1	CN0966A18G14P6-000 PLUG	13556	1	26-12-21 AD0880/ /	001-004, 115-199
D40046P	1	BACC63CB18-14P6 PLUG	13556	1	26-12-21 AD0880/ /	005-099
D40046PQ		BACC10HF18C CABLE CLAMP	81205	1	26-12-21 */ */ *	ALL
D40048J	1	BACC63BV18B14PN RECPT	81205	1	36-11-21 AS2123/ /	ALL
D40048JK		BACC10HD18A CABLE CLAMP	81205	1	36-11-21 AS2123/ /	ALL
D40048P	1	BACC63BP18B14SNL PLUG	81205	1	26-12-21 AS2123/ /	ALL
D40048PQ		BACC10HD18A CABLE CLAMP	81205	1	26-12-21 */ */ *	ALL
D40050J	1	BACC45FN22-12S7 RCPT	81205	1	21-25-21 P37/ /	ALL
D40050P	1	BACC45FT22-12P7 PLUG	81205	1	21-25-11 P037-00/ /	ALL
D40056J	1	BACC45FN22-32S6 RCPT	81205	1	21-43-11 P36/ /	ALL
D40056P	1	BACC45FT22-32P6 PLUG	81205	1	21-43-11 P036-00/ /	ALL
D40060J	1	BACC45FN22-55S7 RCPT	81205	1	36-21-11 P36/ /	ALL
D40060P	1	BACC45FT22-55P7 PLUG	81205	1	36-21-11 P036-00/ /	001-099
D40060P	1	BACC45FT22-55P7 PLUG	81205	1	36-21-11 P36/ /	115-199
D40063J	1	BACC45FN18A31S RCPT	81205	1	23-42-11 670/210/R70	115-199
D40064J	1	BACC45FN24-61S6 RCPT	81205	1	36-11-31 P37/ /	ALL
D40064P	1	BACC45FT24-61P6 PLUG	81205	1	21-51-21 P037-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D40000

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40064P	1	BACC45FT24-61P6 PLUG	81205	1	21-51-21 P37/ /	115-199
D40065P	1	BACC45FT10-5P PLUG-	81205	1	23-42-11 675/300/L30	115-199
D40065PQ		BACC10GH10 CABLE CLAMP	81205	1	23-42-11 */ */	115-199
D40068J	1	CN0967C22G55S9-000 RCPT-	13556	1	21-51-21 AD0880/ /	001-004
D40068J	1	BACC63CC22-55S9 RCPT-	81205	1	21-51-21 AD0880/ /	005-099
D40068J	1	CN0967C22G55S9-000 RCPT	13556	1	21-51-21 880/ /	115-199
D40068JK		BACC10HF22C CABLE CLAMP	81205	1	21-51-21 */ /	ALL
D40068P	1	CN0966A22G55P9-000 PLUG	13556	1	21-51-22 AD0880/ /	001-004, 115-199
D40068P	1	BACC63CB22-55P9 PLUG	81205	1	21-51-22 AD0880/ /	005-099
D40068PQ		BACC10HF22C CABLE CLAMP	81205	1	21-51-22 */ */	ALL
D40070J	1	CN0967C20G41S7-000 RCPT-	13556	1	21-51-23 AD0880/ /	001-004
D40070J	1	BACC63CC20-41S7 RCPT-	81205	1	21-51-23 AD0880/ /	005-099
D40070J	1	CN0967C20G41S7-000 RCPT	13556	1	21-51-23 880/ /	115-199
D40070JK		BACC10HF20C CABLE CLAMP	81205	1	21-51-21 */ /	ALL
D40070P	1	CN0966A20G41P7-000 PLUG	13556	1	30-71-21 AD0880/ /	001-004, 115-199
D40070P	1	BACC63CB20-41P7 PLUG	81205	1	30-71-21 AD0880/ /	005-099
D40070PQ		BACC10HF20C CABLE CLAMP	81205	1	30-71-21 */ */	ALL

EQUIPMENT LIST

D280N032

Section D40000

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40072J	1	CN0967C22G55SN-000 RCPT-	81205	1	21-51-12 AC0880/ /	001-004
D40072J	1	BACC63CC22-55SN RCPT-	81205	1	21-51-12 AC0880/ /	005-099
D40072J	1	CN0967C22G55SN-000 RCPT	13556	1	21-51-12 AC0880/ /	115-199
D40072JK		BACC10HF22C CABLE CLAMP	81205	1	21-51-12 */ */	001-099
D40072JK		BACC10HF22C CABLE CLAMP	81205	1	21-51-12 */ /	115-199
D40072P	1	CN0966A22G55PN-000 PLUG	13556	1	21-51-12 AC0880/ /	001-004, 115-199
D40072P	1	BACC63CB22-55PN PLUG	81205	1	21-51-12 AC0880/ /	005-099
D40072PQ		BACC10HF22C CABLE CLAMP	81205	1	21-51-12 */ /	ALL
D40073J	1	BACC45FN22-55S9 RCPT	81205	1	34-12-21 P003-00/ /	001-099
D40073J	1	BACC45FN22-55S9 RCPT	81205	1	34-12-21 AP0003/ /	115-199
D40073P	1	BACC45FT22A55P9 PLUG	81205	1	34-12-21 AP0003/ /	001-099
D40073P	1	BACC45FT22A55P9 PLUG	81205	1	34-12-21 217.6/198/34	115-199
D40074J	1	CN0967C20G41S6-000 RCPT	81205	1	21-51-11 880/ /	001-004
D40074J	1	BACC63CC20-41S6 RCPT	81205	1	21-51-11 880/ /	005-099
D40074J	1	CN0967C20G41S6-000 RCPT	06324	1	21-51-11 AC0880/ /	115-199
D40074JK		BACC10HF20C CABLE CLAMP	81205	1	21-51-11 */ */	001-099
D40074JK		BACC10HF20C CABLE CLAMP	81205	1	21-51-11 */ /	115-199

EQUIPMENT LIST

D280N032

Section D40000

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40074P	1	CN0966A20G41P6-000 PLUG	13556	1	21-51-11 AC0880/ /	001-004, 115-199
D40074P	1	BACC63CB20-41P6 PLUG	81205	1	21-51-11 AC0880/ /	005-099
D40074PQ		BACC10HF20C CABLE CLAMP	81205	1	21-51-11 */ /	ALL
D40076J	1	CN0967C20G28S6-000 RCPT	13556	1	27-81-11 0880/ /	001-004
D40076J	1	BACC63CC20-28S6 RCPT	13556	1	27-81-11 0880/ /	005-099
D40076J	1	CN0967C20G28S6-000 RCPT	13556	1	27-81-11 AC0880/ /	115-199
D40076JK		BACC10HF20C CABLE CLAMP	81205	1	27-81-11 */ /	001-099
D40076JK		BACC10HF20C CABLE CLAMP	81205	1	27-81-11 AC0880/ /	115-199
D40076P	1	CN0966A20G28P6-000 PLUG	13556	1	27-81-11 AC0880/ /	001-004, 115-199
D40076P	1	BACC63CB20-28P6 PLUG	13556	1	27-81-11 AC0880/ /	005-099
D40076PQ		BACC10HF20C CABLE CLAMP	81205	1	27-81-11 */ */	ALL
D40077J	1	BACC45FN22-55S6 RCPT	81205	1	34-12-21 AP0001/ /	ALL
D40077P	1	BACC45FT22D55P6 PLUG	81205	1	34-13-11 217.6-1/98-/L34	001-099
D40077P	1	BACC45FT22D55P6 PLUG	81205	1	34-13-11 AP0001/ /	115-199
D40080J	1	BACC45FN18-14S9 RCPT-	81205	1	52-34-11 P034-00/ /	001-099
D40080J	1	BACC45FN18-14S9 RCPT-	81205	1	52-34-11 P34/ /	115-199
D40080P	1	BACC45FT18-14P9 PLUG	81205	1	33-37-11 P034-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D40000

Page 11

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40082J	1	BACC63BV22B19S6 RCPT-	81205	1	32-09-11 AW1240/ /	ALL
D40082JK		BACC10HF22C CABLE CLAMP	81205	1	32-09-11 */*/	ALL
D40082P	1	BACC63BP22B19P6L PLUG	81205	1	32-42-11 AW1240/ /	ALL
D40084J	1	BACC63BV22B19SN RCPT-	81205	1	32-09-12 AW1240/ /	ALL
D40084JK		BACC10HF22C CABLE CLAMP	81205	1	32-09-12 */*/	ALL
D40084P	1	BACC63BP22B19PNL PLUG	81205	1	32-42-11 AW1240/ /	ALL
D40099J	1	BACC45FN22-55S9 RCPT-	81205	1	34-33-21 P003-00/ /	001-099
D40099J	1	BACC45FN22-55S9 RCPT-	81205	1	34-33-21 AP0003/ /	115-199
D40099P	1	BACC45FT22A55P9 PLUG	81205	1	22-14-21 217.6/200/R40	001-099
D40099P	1	BACC45FT22A55P9 PLUG	81205	1	22-14-21 AP0003/ /	115-199

EQUIPMENT LIST

D280N032

Section D40000

Page 12 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40101	1	48-7191 RECP-	81205	1	23-51-11 P13/ /	001-099
D40104J	1	BACC63CN1610SN RCPT	81205	1	33-31-31 1883/246/R21	001-099
D40104J	1	BACC63CN1610SN RCPT	81205	1	33-31-31 AT1883/ /	115-199
D40104JK		BACC10HF16A CABLE CLAMP	81205	1	33-31-31 1885/246/R21	001-099
D40104JK		BACC10HF16A CABLE CLAMP	81205	1	33-31-31 AT1883/ /	115-199
D40104P	1	BACC63CM1610PN PLUG	81205	1	33-31-11 AT1883/ /	ALL
D40104PQ		BACC10HD16A CABLE CLAMP	81205	1	33-31-11 AT1883/ /	001-099
D40104PQ		BACC10HD16A CABLE CLAMP	81205	1	33-31-11 */ */	115-199
D40105J	1	48-7191 RCPT-	02660	1	27-09-12 505/191/L032	ALL
D40105P	1	48-7190 PLUG-	02660	1	27-09-12 505/191/L032	ALL
D40107	1	48-7190-1 PLUG-	81205	1	23-51-11 P13/ /	001-099
D40111	1	48-7191-1 RECP-	81205	1	23-51-11 P13/ /	001-099
D40115	1	48-7190 PLUG-	81205	1	23-51-11 P13/ /	001-099
D40120J	1	BACC63BV16A24SN RCPT	81205	1	27-38-11 AA1715/ /L004	ALL
D40120P	1	BACC63BP16A24PNL PLUG	81205	1	27-38-11 1715/298/L000	001-099
D40120P	1	BACC63BP16A24PNL PLUG	81205	1	27-38-11 1715/ /	115-199
D40120PK	1	BACC10HF16 CLAMP	81205	1	27-38-11 */ */	001-099

EQUIPMENT LIST

D280N032

Section D40100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40120PK	1	BACC10HF16 CLAMP	81205	1	27-38-11 1715/ /	115-199
D40121	1	48-7191 RECP-	81205	1	23-51-21 P14/ /	001-099
D40123	1	48-7190-1 PLUG-	81205	1	23-51-21 P14/ /	001-099
D40125	1	48-7191-1 RECP-	81205	1	23-51-21 P14/ /	001-099
D40127	1	48-7190 PLUG-	81205	1	23-51-21 P14/ /	001-099
D40142J	1	BACC63BV18A31P8 RCPT	81205	1	27-11-11 1705/298/L000	001-099
D40142J	1	BACC63BV18A31P8 RCPT	81205	1	27-11-11 1705/ /	115-199
D40142JK	1	BACC10HF18 CABLE CLAMP	81205	1	27-11-11 */*/	001-099
D40142JK	1	BACC10HF18 CLAMP	81205	1	27-11-11 1705/ /	115-199
D40142P	1	BACC63BP18A31S8L PLUG	81205	1	27-28-13 AA1705/ /	ALL
D40162J	1	BACC63BV16B24SN RCPT	81205	1	26-15-12 393/161/L012	001-099
D40162J	1	BACC63BV16B24SN RCPT	81205	1	26-15-12 AC0393/ /	115-199
D40162JK		BACC10HF16 CABLE CLAMP	81205	1	26-15-12 */*/	ALL
D40162P		BACC63BP16B24PNL PLUG	81205	1	26-15-12 AC0393/ /	ALL
D40162PQ		208643-FS6000 ADAPTOR	17713	1	26-15-12 */*/	ALL
D40162PR		287N6202-20 FLEXIBLE CONDUIT ASSY	17713	1	26-15-12 */*/	ALL
D40164J	1	BACC45FN16-24P8 RCPT	81205	1	27-38-11 AA1715/ /	ALL

EQUIPMENT LIST

D280N032

Section D40100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40164P	1	BACC45FT16-24S8 PLUG-	81205	1	27-23-11 AA1715/ /	ALL
D40168J	1	BACC45FN18-14S8 RCPT-	81205	1	24-32-41 P006-00/ /	ALL
D40168P	1	BACC45FT18-14P8 PLUG	81205	1	24-31-41 P006-00/ /	001-099
D40168P	1	BACC45FT18-14P8 PLUG	81205	1	24-31-41 P6/ /	115-199
D40170J	1	BACC45FN18-14P RCPT	81205	1	24-31-41 E6 RLY/PNL/	001-099
D40170J	1	BACC45FN18-14P8 RCPT	81205	1	24-31-41 E6/ /	115-199
D40170P	1	BACC45FT18-14S PLUG	81205	1	24-31-41 E006-00/ /	001-099
D40170P	1	BACC45FT18-14S8 PLUG	81205	1	24-31-41 E6/ /	115-199
D40171	1	48-7191 RECP-	02660	1	23-51-41 P17/ /	001-099
D40173	1	48-7190-1 PLUG-	02660	1	23-51-41 P17/ /	001-099
D40175	1	48-7191-1 RECP-	02660	1	23-51-41 P17/ /	001-099
D40176J	1	BACC45FN22-55S6 RCPT.	81205	1	35-35-11 1210/ /	ALL
D40176P	1	BACC45FT22-55P6 PLUG	81205	1	52-35-11 1210/ /	ALL
D40177	1	48-7190 PLUG-	02660	1	23-51-41 P17/ /	001-099
D40178J	1	BACC45FN22-19S7 RCPT.	81205	1	52-35-11 1210/ /	ALL
D40178P	1	BACC45FT22-19P7 PLUG	81205	1	52-35-11 1210/ /	ALL
D40182J	1	BACC45FN20-39S RCPT	81205	1	21-31-21 E5-2/ /	ALL

EQUIPMENT LIST

D280N032

Section D40100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40182P	1	BACC45FT20-39P PLUG	81205	1	21-31-21 E005-02/ /	ALL
D40184J	1	BACC45FN22-19S6 RCPT	81205	1	21-44-11 P37/ /	ALL
D40184P	1	BACC45FT22-19P6 PLUG	81205	1	30-71-21 P037-00/ /	ALL
D40186J	1	BACC45FN18-31P9 RCPT	81205	1	21-44-11 P37/ /	ALL
D40186P	1	BACC45FT18-31S9 PLUG	81205	1	21-58-21 P037-00/ /	ALL
D40188J	1	BACC45FN18-14S RCPT-	81205	1	24-51-61 P034-00/ /	001-099
D40188J	1	BACC45FN18-14S RCPT-	81205	1	24-51-61 P34/ /	115-199
D40188P	1	BACC45FT18-14P PLUG	81205	1	52-35-11 P034-00/ /	ALL
D40190J	1	BACC45FN14-15P7 RCPT	81205	1	32-42-13 E5-2/ /	001-099
D40190P	1	BACC45FT14A15S7 PLUG	81205	1	32-42-12 E005-02/ /	001-099
D40193J	1	KN-19-198-M06 RCPT-	91836	1	23-11-11 AA1671/ /	001-008, 115-199
D40193J	1	KN-19-162 RCPT-	91836	1	23-11-11 AA1671/ /	009-099
D40193P	1	KN-59-330-M06 PLUG-	91836	1	23-11-11 1650/295/	001-099
D40193P	1	KN-59-330-M06 PLUG-	91836	1	23-11-11 AA1671/ /	115-199
D40197J	1	KN-19-198-M06 RCPT-	91836	1	23-11-21 1650/300/R10	001-008, 115-199
D40197J	1	KN-19-162 RCPT-	91836	1	23-11-21 1650/300/R10	009-099
D40197P	1	KN-59-330-M06 PLUG-	91836	1	23-11-21 AB1671/ /	ALL

EQUIPMENT LIST

D280N032

Section D40100

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40198J	1	BACC63CN2430SN RCPT	81205	1	49-14-11 1883/243/R25	001-099
D40198J	1	BACC63CN2430SN RCPT		1	49-14-11 AT1883/ /	115-199
D40198JK		BACC10HF24A CABLE CLAMP	81205	1	49-14-11 1885/243/R25	001-099
D40198JK		BACC10HF24A CABLE CLAMP	81205	1	49-14-11 AT1883/ /	115-199

EQUIPMENT LIST

D280N032

Section D40100
Page 5 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40200J	1	BACC63CN2842SN RCPT	81205	1	49-14-11 1883/235/R25	001-099
D40200J	1	BACC63CN2842SN RCPT	81205	1	49-14-11 AT1883/ /	115-199
D40200JK		BACC10HF28A CABLE CLAMP	81205	1	49-14-11 1885/235/R25	001-099
D40200JK		BACC10HF28A CABLE CLAMP	81205	1	49-14-11 AT1883/ /	115-199
D40206J	1	BACC45FN20-25S8 RCPT	81205	1	21-58-21 P36/ /	ALL
D40206P	1	BACC45FT20-25P8 PLUG	81205	1	21-58-21 P036-00/ /	ALL
D40209J	1	BACC45FN20-41P6 RCPT.	81205	1	33-16-51 P1-3/ /	ALL
D40209P	1	BACC45FT20D41S6 PLUG	81205	1	33-16-21 P001-03/ /	001-099
D40209P	1	BACC45FT20D41S6 PLUG	81205	1	33-16-21 P1-3/MO-/D	115-199
D40214J	1	BACC45FN12-12S8 RCPT-	81205	1	29-11-31 E4-2/ /	001-099
D40214J	1	BACC45FN14-15S8 RCPT-	81205	1	29-11-31 E4-2/ /	115-199
D40214P	1	BACC45FT12-12P8 PLUG	81205	1	29-11-31 E004-02/ /	001-099
D40214P	1	BACC45FT14-15P8 PLUG	81205	1	29-11-31 E4-2/ /	115-199
D40218J	1	BACC45FN22-55S6 RCPT	81205	1	26-15-11 P54/ /	ALL
D40218P	1	BACC45FT22-55P6 PLUG	81205	1	26-18-11 P54/ /	ALL
D40219J	1	BACC45FN16-24P8 RCPT	81205	1	32-42-21 E5-2/ /	001-099
D40219P	1	BACC45FT16A24S8 PLUG-	81205	1	32-42-12 E005-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D40200

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40220J	1	BACC45FN16-24S9 RCPT	81205	1	26-15-11 P54/ /	ALL
D40220P	1	BACC45FT16-24P9 PLUG	81205	1	26-15-11 P054-00/ /	001-099
D40220P	1	BACC45FT16-24P9 PLUG	81205	1	26-15-11 P54/ /	115-199
D40222J	1	FRF0-36-5S03-747 RCPT	71468	1	49-41-11 1883/239/R21	001-099
D40222J	1	FRF0-36-5S03-747 RCPT	71468	1	49-41-11 AT1883/ /	115-199
D40222JK		G6652-36 CABLE CLAMP-	06324	1	49-41-11 1883/239/R21	001-099
D40222JK		G6652-36 CABLE CLAMP-	06324	1	49-41-11 AT1883/ /	115-199
D40222P	1	FRF6-36-5P01-747 PLUG	71468	1	49-41-11 AT1883/ /	ALL
D40222PQ		G6652-36 CABLE CLAMP	06324	1	49-41-11 */ */	ALL
D40228J	1	FRF0-36-5P03-747 RCPT	71468	1	24-21-41 AT1883/ /	ALL
D40228JK		G6652-36 CABLE CLAMP	06324	1	24-21-41 AT1883/ /	ALL
D40228P	1	FRF6-36-5S01-747 PLUG	71468	1	24-21-41 AT1883/ /	ALL
D40228PQ		G6652-36 CABLE CLAMP	06324	1	24-21-41 AT1883/243/21	ALL
D40228PS		287T4817-5 FANNING STRIP	81205	1	24-21-41 AT1883/ /	ALL
D40230J	1	BACC63CN2430S7 RCPT-	81205	1	24-21-41 AT1883/ /	ALL
D40230JK		BACC10HD24A CABLE CLAMP-	81205	1	24-21-41 */ */	ALL
D40230P	1	BACC63CM2430P7 PLUG	81205	1	24-21-41 AT1883/ /	ALL

EQUIPMENT LIST

D280N032

Section D40200

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40230PQ		BACC10HF24 CABLE CLAMP	81205	1	24-21-41 AT1883/ /	ALL
D40240J	1	BACC45FN22-12S8 RCPT-	81205	1	24-51-11 P6/ /	ALL
D40240P	1	BACC45FT22-12P8 PLUG-	81205	1	24-54-11 P006-00/ /	ALL
D40242J	1	BACC45FN18-8S6 RCPT-	81205	1	24-32-11 P6/ /	ALL
D40242P	1	BACC45FT18A8P6 PLUG-	81205	1	24-32-11 P006-00/ /	001-099
D40242P	1	BACC45FT18A8P6 PLUG-	81205	1	24-32-11 P6/ /	115-199
D40244J	1	BACC45FN18-8S7 RCPT-	81205	1	24-54-73 P6/ /	ALL
D40244P	1	BACC45FT18-8P7 PLUG	81205	1	24-54-73 P006-00/ /	ALL
D40246J	1	BACC45FN22-32S RCPT-	81205	1	24-11-21 P6/ /	ALL
D40246P	1	BACC45FT22-32P PLUG-	81205	1	24-28-11 P006-00/ /	ALL
D40248J	1	BACC45FN22-12S6 RCPT-	81205	1	24-51-21 P006-00/ /	ALL
D40248P	1	BACC45FT22-12P6 PLUG	81205	1	24-51-21 P006-00/ /	ALL
D40249J	1	BACC45FN16-24P7 RCPT	81205	1	33-13-12 P3-3/ /	ALL
D40249P	1	BACC45FT16A24S7 PLUG	81205	1	34-22-28 P3-3/ /	001-099
D40249P	1	BACC45FT16A24S7 PLUG	81205	1	34-22-28 P3-1/ /	115-199
D40250J	1	BACC45FN22-12S RCPT-	81205	1	24-32-11 P006-00/ /	ALL
D40250P	1	BACC45FT22-12P PLUG	81205	1	24-32-11 P006-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D40200

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40255J	1	BACC45FN16-24S9 RCPT	81205	1	31-31-02 E3-3/ /	001-099
D40255P	1	BACC45FT16-24P9 PLUG	81205	1	31-31-02 E3-3/ /	001-099
D40258J	1	BACC45FN18-14S8 286N2818	81205	1	24-21-41 AA1705/ /	001-099
D40258J	1	BACC45FN18-14S8 RECP-	81205	1	24-21-41 AA1705/ /	115-199
D40258P	1	BACC45FT18-14P8 286N4018	81205	1	24-21-41 AA1705/ /	001-099
D40258P	1	BACC45FT18-14P8 PLUG-	81205	1	24-21-41 AA1705/ /	115-199
D40266J	1	BACC63BV16B10P6 RCPT	81205	1	78-36-11 AS1123/ /	ALL
D40266JK		BACC10HD16A CABLE CLAMP	81205	1	78-36-11 AS1123/ /	ALL
D40266P	1	BACC63BP16B10S6L PLUG	81205	1	78-36-11 AS1123/ /	ALL
D40266PQ		BACC10HD16A CABLE CLAMP	81205	1	78-36-11 */*/	ALL
D40268J	1	CN0967C12G12S9-000 RCPT	13556	1	78-36-11 AC0880/ /	001-004
D40268J	1	BACC63CC12-12S9 RCPT	81205	1	78-36-11 AC0880/ /	005-099
D40268J	1	CN0967C12G12S9-000 RCPT	13556	1	78-36-11 AC0880/190/	115-199
D40268JK		BACC10HF12C CABLE CLAMP	81205	1	78-36-11 */*/	001-099
D40268JK		BACC10HF12C CABLE CLAMP	81205	1	78-36-11 */*/	115-199
D40268P	1	CN0966A12G12P9-000 PLUG	13556	1	78-36-11 AC0880/ /	001-004, 115-199
D40268P	1	BACC63CB12-12P9 PLUG	13556	1	78-36-11 AC0880/ /	005-099

EQUIPMENT LIST

D280N032

Section D40200

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40268PQ		BACC10HF12C CABLE CLAMP	81205	1	78-36-11 */ */ *	ALL
D40270J	1	BACC45FN14-15S RCPT	81205	1	24-25-13 P71 / /	001-002, 115-199
D40270J	1	BACC45FN16-24S RCPT	81205	1	24-25-13 P71 / /	003-099
D40270P	1	BACC45FT14B15P PLUG	81205	1	24-25-13 P071-00 / /	001-002, 115-199
D40270P	1	BACC45FT16B24P PLUG	81205	1	24-25-13 P071-00 / /	003-099
D40272J	1	BACC63BV14B7PN RCPT	81205	1	78-34-21 AS2123 / /	ALL
D40272JK		BACC10HD14A CABLE CLAMP	81205	1	78-34-21 AS2123 / /	ALL
D40272P	1	BACC63BP14B7SNL PLUG	81205	1	78-34-21 AS2123 / /	ALL
D40272PQ		BACC10HD14A CABLE CLAMP	81205	1	78-34-21 */ */ *	ALL
D40274J	1	CN0967C18G14S6-000 RCPT	13556	1	78-34-21 AD0880 / /	001-004, 115-199
D40274J	1	BACC63CC18-14S6 RCPT	13556	1	78-34-21 AD0880 / /	005-099
D40274JK		BACC10HF18C CABLE CLAMP	81205	1	78-34-21 */ /	ALL
D40274P	1	CN0966A18G14P6-000 PLUG	13556	1	78-34-21 AD0880 / /	001-004, 115-199
D40274P	1	BACC63CB18-14P6 PLUG	13556	1	78-34-21 AD0880 / /	005-099
D40274PQ		BACC10HF18C CABLE CLAMP	81205	1	78-34-21 */ */ *	ALL
D40278J	1	BACC63BV16B10P6 RCPT	81205	1	78-36-21 AS2123 / /	ALL
D40278JK		BACC10HD16A CABLE CLAMP	81205	1	78-36-21 AS2123 / /	ALL

EQUIPMENT LIST

D280N032

Section D40200

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40278P	1	BACC63BP16B10S6L PLUG	81205	1	78-36-21 AS2123/ /	ALL
D40278PQ		BACC10HD16A CABLE CLAMP	81205	1	78-36-21 */ */	ALL
D40280J	1	CN0967C12G12S7-000 RCPT	13556	1	78-36-21 AD0880/ /	001-004, 115-199
D40280J	1	BACC63CC12-12S7 RCPT	81205	1	78-36-21 AD0880/ /	005-099
D40280JK		BACC10HF12C CABLE CLAMP	81205	1	78-36-21 */ */	001-099
D40280JK		BACC10HF12C CABLE CLAMP	81205	1	78-36-21 */ /	115-199
D40280P	1	CN0966A12G12P7-000 PLUG	13556	1	78-36-21 AD0880/ /	001-004, 115-199
D40280P	1	BACC63CB12-12P7 PLUG	81205	1	78-36-21 AD0880/ /	005-099
D40280PQ		BACC10HF12C CABLE CLAMP	81205	1	78-36-21 */ */	ALL
D40281J		BACC45FN16-24P RCPT-	81205	1	34-22-91 P1-1/ /	ALL
D40281P	1	BACC45FT16A24S PLUG	81205	1	34-22-91 P1-1-MO/D/	001-099
D40281P	1	BACC45FT16A24S PLUG	81205	1	34-22-91 P1-1/MO-/D	115-199
D40282J	1	BACC45FN12-12S8 RCPT-	81205	1	24-31-11 P006-00/ /	ALL
D40282P	1	BACC45FT12-12P8 PLUG	81205	1	24-31-11 P006-00/ /	001-099
D40282P	1	BACC45FT12-12P8 PLUG	81205	1	24-31-11 P6/ /	115-199
D40284J	1	BACC45FN14-15S9 RCPT-	81205	1	24-23-11 P006-00/ /	ALL
D40284P	1	BACC45FT14-15P9 PLUG-	81205	1	24-23-11 P006-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D40200

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40284P	1	BACC45FT14-15P9 PLUG-	81205	1	24-23-11 P6/ /	115-199
D40286J	1	BACC45FN12-12S7 RCPT-	81205	1	24-34-11 P006-00/ /	ALL
D40286P	1	BACC45FT12-12P7 PLUG-	81205	1	24-23-11 P006-00/ /	ALL
D40288J	1	CN0967C20G39S8-000 RCPT-	13566	1	24-11-11 AC0880/ /	001-004
D40288J	1	BACC63CC20-39S8 RCPT-	81205	1	24-11-11 AC0880/ /	005-099
D40288J	1	CN0967C20G39S8-000 RCPT	13566	1	24-11-11 ACO 880/ /	115-199
D40288JK		BACC10HF20C CABLE CLAMP-	81205	1	24-11-11 */*/	001-099
D40288JK		BACC10HF20C CABLE CLAMP	81205	1	24-11-11 * 880/ /	115-199
D40288P	1	CN0966A20G39P8-000 PLUG-	13566	1	24-11-11 AC0880/ /	001-004, 115-199
D40288P	1	BACC63CB20-39P8 PLUG-	81205	1	24-11-11 AC0880/ /	005-099
D40288PQ		BACC10HF20C CABLE CLAMP-	81205	1	24-11-11 */*/	ALL
D40290J	1	CN0967C24G30S7-000 RCPT-	13566	1	24-11-21 AD0880/ /	001-004, 115-199
D40290J	1	BACC63CC24-30S7 RCPT-	81205	1	24-11-21 AD0880/ /	005-099
D40290JK		BACC10HF24C CABLE CLAMP-	81205	1	24-11-21 */*/	ALL
D40290P	1	CN0966A24G30P7-000 PLUG	13566	1	24-11-21 AD0880/ /	001-004, 115-199
D40290P	1	BACC63CB24-30P7 PLUG	81205	1	24-11-21 AD0880/ /	005-099
D40290PQ		BACC10HF24C CABLE CLAMP	81205	1	24-11-21 */*/	ALL

EQUIPMENT LIST

D280N032

Section D40200

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40292J	1	BACC45FN14-15S6 RCPT	81205	1	24-25-13 P036-00/ /	001-002
D40292J	1	BACC45FN16-24S6 RCPT	81205	1	24-25-13 P036-00/ /	003-099
D40292J	1	BACC45FN14-15S6 RCPT	81205	1	24-25-13 P36/ /	115-199
D40292P	1	BACC45FT14A15P6 PLUG	81205	1	24-25-13 P036-00/ /	001-002, 115-199
D40292P	1	BACC45FT16A24P6 PLUG	81205	1	24-25-13 P036-00/ /	003-099
D40294J	1	BACC45FN18-8S RCPT-	81205	1	30-32-11 P006-00/ /	115-199
D40294P	1	BACC45FT18A8P PLUG	81205	1	21-58-13 P006-00/ /	115-199
D40296J	1	BACC45FN20-39S RCPT-	81205	1	24-33-11 P006-00/ /	ALL
D40296P	1	BACC45FT20-39P PLUG	81205	1	24-33-11 P006-00/ /	ALL
D40298J	1	BACC45FN14-7S8 RCPT-	81205	1	24-51-31 P006-00/ /	ALL
D40298P	1	BACC45FT14-7P8 PLUG-	81205	1	24-51-31 P006-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D40200
Page 8 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40300J	1	BACC45FN12-12S RCPT-	81205	1	24-51-31 P006-00/ /	ALL
D40300P	1	BACC45FT12-12P PLUG-	81205	1	22-11-32 P006-00/ /	ALL
D40302J	1	CN0967C24G43SN-000 RCPT	13556	1	33-42-11 880/ /	001-004
D40302J	1	BACC63CC24-43SN RCPT	13556	1	33-42-11 880/ /	005-099
D40302J	1	CN0967C24G43SN-000 RCPT	13556	1	33-42-11 AC0880/ /	115-199
D40302JK	1	BACC10HF24C CABLE CLAMP	81205	1	33-42-11 */ */	001-099
D40302JK	1	BACC10HF24C CABLE	81205	1	33-42-11 AC0880/ /	115-199
D40302P	1	CN0966A24G43PN-000 PLUG-	13556	1	33-43-11 AC0880/ /	001-004, 115-199
D40302P	1	BACC63CB24-43PN PLUG-	13556	1	33-43-11 AC0880/ /	005-099
D40302PQ		BACC10HF24C CABLE CLAMP	81205	1	33-43-11 */ */	ALL
D40304J	1	CN0967C22G19PN-000 RCPT-	81205	1	27-51-61 AW1333/ /	001-004, 115-199
D40304J	1	BACC63CC22-19PN RCPT-	81205	1	27-51-61 AW1333/ /	005-099
D40304JK		BACC10HF22C CABLE CLAMP-	81205	1	27-51-61 AW1333/ /	ALL
D40304P	1	CN0966A22G19SN-000 PLUG-	13556	1	27-51-61 AW1333/ /	001-004, 115-199
D40304P	1	BACC63CB22-19SN PLUG-	13556	1	27-51-61 AW1333/ /	005-099
D40304PQ		BACC10HF22C CABLE CLAMP-	81205	1	27-51-61 */ */	ALL
D40310J	1	BACC45FN24-43S8 RCPT	81205	1	33-25-11 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D40300

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40310P	1	BACC45FT24-43P8 PLUG-	81205	1	33-23-11 P36/ /	001-099
D40310P	1	BACC45FT24-43P8 PLUG-	81205	1	33-23-11 P036/ /	115-199
D40312J	1	BACC45FN24-43S RCPT-	81205	1	33-23-12 923/277/L056	ALL
D40312P	1	BACC45FT24A43P PLUG-	81205	1	33-23-12 925/272/L056	ALL
D40314J	1	BACC45FN22-19S RCPT-	81205	1	33-23-13 1217/276/L055	ALL
D40314P	1	BACC45FT22A19P PLUG-	81205	1	33-23-13 1217/*/*	001-099
D40314P	1	BACC45FT22A19P PLUG-	81205	1	33-23-13 1210/292/L55	115-199
D40316J	1	BACC63CN1407S6 RCPT	81205	1	26-15-11 1885/248/R025	001-099
D40316J	1	BACC63CN1407S6 RCPT	81205	1	26-18-11 AT1883/ /	115-199
D40316JK		BACC10HD14A CABLE CLAMP	81205	1	26-18-11 *//*	001-099
D40316JK		BACC10HD14A CABLE CLAMP	81205	1	26-18-11 */ /	115-199
D40316P	1	BACC63CM1407P6 PLUG	81205	1	26-15-11 AT1883/248/R025	ALL
D40316PQ		BACC10HD14A CABLE CLAMP	81205	1	26-15-11 *//*	ALL
D40318J	1	BACC63CN1407SN RCPT	81205	1	26-15-11 1885/220/R021	001-099
D40318J	1	BACC63CN1407SN RCPT	81205	1	26-15-11 AT1883/ /	115-199
D40318JK		BACC10HD14A CABLE CLAMP	81205	1	26-15-11 *//*	001-099
D40318JK		BACC10HD14A CABLE CLAMP	81205	1	26-15-11 AT1883/ /	115-199

EQUIPMENT LIST

D280N032

Section D40300

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40318P	1	BACC63CM1407PN PLUG	81205	1	26-15-11 AT1883/248/R021	ALL
D40318PQ		BACC10HD14A CABLE CLAMP	81205	1	26-15-11 */*/	ALL
D40324J	1	BACC63BV18A31SN RCPT	81205	1	28-21-11 FSS 509/ /	ALL
D40324JK		BACC10HF18 CABLE CLAMP	81205	1	28-21-11 AW2493/ /	ALL
D40324P	1	BACC63BP18A31PNL FUELING PANEL DISC	81205	1	28-21-23 AW2493/ /	ALL
D40324PQ		BACC10HF18 CABLE CLAMP	81205	1	28-21-23 AW2493/ /	ALL
D40326J	1	BACC63BV22A55S6 RCPT	81205	1	28-21-11 509/ /	ALL
D40326JK		BACC10HF22 CABLE CLAMP	81205	1	28-41-11 509/ /	ALL
D40326P	1	BACC63BP22A55P6L FUELING PANEL DISC	81205	1	28-41-11 AW2493/ /	ALL
D40326PQ		BACC10HF22 CABLE CLAMP	81205	1	28-41-11 AW2493/ /	ALL
D40328J	1	CN0967C18G31P7-000 RCPT	13556	1	28-21-11 AW2333/ /	001-004, 115-199
D40328J	1	BACC63CC18-31P7 RCPT	81205	1	28-21-11 AW2333/ /	005-099
D40328JK		BACC10HF18C CABLE CLAMP	81205	1	28-21-11 AW2333/ /	ALL
D40328P	1	CN0966A18G31S7-000 PLUG	13556	1	28-21-11 AW2333/ /	001-004, 115-199
D40328P	1	BACC63CB18-31S7 PLUG	13556	1	28-21-11 AW2333/ /	005-099
D40328PQ		BACC10HF18C CABLE CLAMP	81205	1	28-21-11 AW2333/ /	ALL
D40330J	1	CN0967C22G55P8-000 RCPT	13556	1	28-21-11 AW2333/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D40300

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40330J	1	BACC63CC22-55P8 RCPT	81205	1	28-21-11 AW2333/ /	005-099
D40330JK		BACC10HF22C CABLE CLAMP	81205	1	28-41-11 */ /	ALL
D40330P	1	CN0966A22G55S8-000 PLUG	13556	1	28-41-11 AW2333/ /	001-004, 115-199
D40330P	1	BACC63CB22-55S8 PLUG	13556	1	28-41-11 AW2333/ /	005-099
D40330PQ		BACC10HF22C CABLE CLAMP	81205	1	28-41-11 */ */	ALL
D40332J	1	CN0967C16G24S8-000 RCPT-	13556	1	28-21-22 AD0880/ /	001-004
D40332J	1	BACC63CC16-24S8 RCPT-	13556	1	28-21-22 AD0880/ /	005-099
D40332J	1	CN0967C16G24S8-000 RCPT	13556	1	28-21-22 AD0880/ /	115-199
D40332JK		BACC10HF16C CABLE CLAMP	81205	1	28-21-22 */ /	ALL
D40332P	1	CN0966A16G24P8-000 PLUG	13556	1	28-21-11 AD0880/ /	001-004, 115-199
D40332P	1	BACC63CB16-24P8 PLUG	13556	1	28-21-11 AD0880/ /	005-099
D40332PQ		BACC10HF16C CABLE CLAMP	81205	1	28-21-11 AD0880/ /	ALL
D40334J	1	CN0967C22G55SN-000 RCPT-	13556	1	28-41-11 AD0880/ /	001-004
D40334J	1	BACC63CC22-55SN RCPT-	13556	1	28-41-11 AD0880/ /	005-099
D40334J	1	CN0967C22G55SN-000 RCPT	13556	1	28-41-11 AD0880/ /	115-199
D40334JK		BACC10HF22C CABLE CLAMP	81205	1	28-41-11 */ /	ALL
D40334P	1	CN0966A22G55PN-000 RCPT	13556	1	28-41-11 AD0880/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D40300

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40334P	1	BACC63CB22-55PN RCPT	13556	1	28-41-11 AD0880/ /	005-099
D40334PQ		BACC10HF22C CABLE CLAMP	81205	1	28-41-11 AD0880/ /	ALL
D40342J	1	CN0967C20G28S8-000 RCPT	81205	1	27-51-11 1090/ /	001-004
D40342J	1	BACC63CC20-28S8 RCPT	81205	1	27-51-11 1090/ /	005-099
D40342J	1	CN0967C20G28S8-000 RCPT	13556	1	27-51-11 AC1090/ /	115-199
D40342JK		BACC10HG20C CABLE CLAMP	81205	1	27-51-11 */ /	001-099
D40342JK		BACC10HG20C CABLE CLAMP	81205	1	27-51-11 AC1090/ /	115-199
D40342P	1	CN0966A20G28P8-000 PLUG	81205	1	27-51-11 AC1090/ /	001-004, 115-199
D40342P	1	BACC63CB20-28P8 PLUG	81205	1	27-51-11 AC1090/ /	005-099
D40342PQ		BACC10HG20C CABLE CLAMP	81205	1	27-51-11 */ */	ALL
D40346J	1	CN0967C20G39S6-000 RCPT	13556	1	22-13-11 AC1090/ /	001-004, 115-199
D40346J	1	BACC63CC20-39S6 RCPT	81205	1	22-13-11 AC1090/ /	005-099
D40346JK		BACC10HG20C CABLE CLAMP-	81205	1	22-13-11 */ */	001-099
D40346JK		BACC10HG20C CABLE CLAMP-	81205	1	22-13-11 */ /	115-199
D40346P	1	CN0966A20G39P6-000 PLUG	13556	1	26-11-12 AC1090/ /	001-004
D40346P	1	BACC63CB20-39P6 PLUG	81205	1	26-11-12 AC1090/ /	005-099
D40346P	1	CN0966A20G39P6-000 PLUG	81205	1	26-11-12 AC1090/ /	115-199

EQUIPMENT LIST

D280N032

Section D40300

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40346PQ		BACC10HG20C CABLE CLAMP	81205	1	26-11-12 * / /	ALL
D40348J	1	CN0967C16G10S8-000 RCPT	13556	1	28-22-11 AC1090/ /	001-004
D40348J	1	BACC63CC16-10S8 RCPT	81205	1	28-22-11 AC1090/ /	005-099
D40348J	1	CN0967C16G10S8-000 RCPT	13556	1	32-61-11 AC1090/ /	115-199
D40348JK		BACC10HG16C CABLE CLAMP-	81205	1	28-22-11 * / *	001-099
D40348JK		BACC10HG16C CABLE CLAMP-	81205	1	32-61-11 * / /	115-199
D40348P	1	CN0966A16G10P8-000 PLUG	13556	1	28-22-11 AC1090/ /	001-004
D40348P	1	BACC63CB16-10P8 PLUG	81205	1	28-22-11 AC1090/ /	005-099
D40348P	1	CN0966A16G10P8-000 PLUG	81205	1	28-22-11 AC1090/ /	115-199
D40348PQ		BACC10HG16C CABLE CLAMP	81205	1	28-22-11 * / /	ALL
D40350J	1	CN0967C20G28SN-000 RCPT	13556	1	29-33-11 AC1090/ /	001-004, 115-199
D40350J	1	BACC63CC20-28SN RCPT	81205	1	29-33-11 AC1090/ /	005-099
D40350JK		BACC10HG20C CABLE CLAMP	81205	1	29-33-11 * / *	001-099
D40350JK		BACC10HG20C CABLE CLAMP	81205	1	29-33-11 * / /	115-199
D40350P	1	CN0966A20G28PN-000 PLUG	81205	1	28-25-11 AC1090/ /	001-004, 115-199
D40350P	1	BACC63CB20-28PN PLUG	81205	1	28-25-11 AC1090/ /	005-099
D40350PQ		BACC10HF20C CABLE CLAMP	81205	1	28-25-11 * / *	ALL

EQUIPMENT LIST

D280N032

Section D40300

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40352J	1	CN0967C20G39S7-000 RCPT	13556	1	22-13-31 AC1090/ /	001-004, 115-199
D40352J	1	BACC63CC20-39S7 RCPT	13556	1	22-13-31 AC1090/ /	005-099
D40352JK		BACC10HG20C CABLE CLAMP	81205	1	22-13-31 */ /	001-099
D40352JK		BACC10HG20C CABLE CLAMP	81205	1	22-13-31 1090/ /	115-199
D40352P	1	CN0966A20G39P7-000 PLUG	81205	1	28-21-33 AC1090/ /	001-004, 115-199
D40352P	1	BACC63CB20-39P7 PLUG	81205	1	28-21-33 AC1090/ /	005-099
D40352PQ		BACC10HG20C CABLE CLAMP	81205	1	28-21-33 */ */	ALL
D40354J	1	BACC45FN14-15P8 RCPT-	81205	1	33-51-11 400/301/R008	001-099
D40354J	1	BACC45FN14-15P8 RCPT-	81205	1	33-51-11 400/301/R8	115-199
D40354P	1	BACC45FT14-15S8 PLUG	81205	1	33-51-11 409/300/R008	001-099
D40354P	1	BACC45FT14-15S8 PLUG	81205	1	33-51-11 AA0409/ /	115-199
D40356J	1	BACC45FN14-15P RCPT-	81205	1	33-51-14 AA0409/ /	ALL
D40356P	1	BACC45FT14-15S PLUG	81205	1	33-51-11 409/300/0	001-099
D40356P	1	BACC45FT14-15S PLUG	81205	1	33-51-11 AA0409/ /	115-199
D40358J	1	CN0967C18G14S9-000 RCPT	13556	1	28-22-11 AD1090/ /	001-004
D40358J	1	BACC63CC18-14S9 RCPT	81205	1	28-22-11 AD1090/ /	005-099
D40358J	1	CN0967C18G14S9-000 RCPT	13556	1	32-61-11 AD1090/ /	115-199

EQUIPMENT LIST

D280N032

Section D40300

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40358JK		BACC10HG18C CABLE CLAMP	81205	1	28-22-11 */ /	001-099
D40358JK		BACC10HG18C CABLE CLAMP	81205	1	32-61-11 */ /	115-199
D40358P	1	CN0966A18G14P9-000 PLUG	81205	1	33-31-11 AD1090/ /	001-004, 115-199
D40358P	1	BACC63CB18-14P9 PLUG	81205	1	33-31-11 AD1090/ /	005-099
D40358PQ		BACC10HF18C CABLE CLAMP	81205	1	33-31-11 */ */	ALL
D40360J	1	CN0967C16G24SN-000 RCPT	13556	1	27-23-11 AD1090/ /	001-004, 115-199
D40360J	1	BACC63CC16-24SN RCPT	81205	1	27-23-11 AD1090/ /	005-099
D40360JK		BACC10HG16C CABLE CLAMP	81205	1	22-23-21 */ /	ALL
D40360P	1	CN0966A16G24PN-000 PLUG	81205	1	21-51-22 AD1090/ /	001-004, 115-199
D40360P	1	BACC63CB16-24PN PLUG	81205	1	21-51-22 AD1090/ /	005-099
D40360PQ		BACC10HF16C CABLE CLAMP	81205	1	21-51-22 */ */	ALL
D40362J	1	CN0967C20G28SN-000 RCPT	13556	1	32-12-12 AD1090/ /	001-004
D40362J	1	BACC63CC20-28SN RCPT	81205	1	32-12-12 AD1090/ /	005-099
D40362J	1	CN0967C20G28SN-000 RCPT	13556	1	32-61-11 AD1090/ /	115-199
D40362JK	1	BACC10HG20C CABLE CLAMP-	81205	1	32-12-12 */ */	001-099
D40362JK	1	BACC10HG20C CABLE CLAMP-	81205	1	32-61-11 */ /	115-199
D40362P	1	CN0966A20G28PN-000 PLUG	13556	1	32-12-12 AD1090/ /	001-004

EQUIPMENT LIST

D280N032

Section D40300

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40362P	1	BACC63CB20-28PN PLUG	81205	1	32-12-12 AD1090/ /	005-099
D40362P	1	CN0966A20G28PN-000 PLUG	81205	1	32-12-12 AD1090/ /	115-199
D40362PQ		BACC10HF20C CABLE CLAMP	81205	1	32-12-12 */ */	ALL
D40364J	1	CN0967C18G14SN-000 RCPT	13556	1	26-18-11 AD1090/ /	001-004, 115-199
D40364J	1	BACC63CC18-14SN RCPT	81205	1	26-18-11 AD1090/ /	005-099
D40364JK		BACC10HG18C CABLE CLAMP	81205	1	26-18-11 */ /	ALL
D40364P	1	CN0966A18G14PN-000 PLUG	81205	1	26-18-11 AD1090/ /	001-004, 115-199
D40364P	1	BACC63CB18-14PN PLUG	81205	1	26-18-11 AD1090/ /	005-099
D40364PQ		BACC10HG18C CABLE CLAMP	81205	1	26-18-11 */ */	ALL
D40366J	1	CN0967C18G11SN-000 RCPT	13556	1	29-33-11 AC1090/ /	001-004, 115-199
D40366J	1	BACC63CC18-11SN RCPT	81205	1	29-33-11 AC1090/ /	005-099
D40366JK		BACC10HF18C CABLE CLAMP	81205	1	29-33-11 */ */	001-099
D40366JK		BACC10HF18C CABLE CLAMP	81205	1	29-33-11 */ /	115-199
D40366P	1	CN0966A18G11PN-000 PLUG	81205	1	29-33-11 AC1090/ /	001-004, 115-199
D40366P	1	BACC63CB18-11PN PLUG	81205	1	29-33-11 AC1090/ /	005-099
D40366PQ		BACC10HF18C CABLE CLAMP	81205	1	29-33-11 */ */	ALL
D40368J	1	CN0967C18G11S7-000 RCPT	13556	1	26-18-21 AD1090/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D40300

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40368J	1	BACC63CC18-11S7 RCPT	81205	1	26-18-21 AD1090/ /	005-099
D40368JK		BACC10HF18C CABLE CLAMP	81205	1	26-18-21 */ */	001-099
D40368JK		BACC10HF18C CABLE CLAMP	81205	1	26-18-21 */ /	115-199
D40368P	1	CN0966A18G11P7-000 PLUG	13556	1	26-21-11 AD1090/ /	001-004
D40368P	1	BACC63CB18-11P7 PLUG	81205	1	26-21-11 AD1090/ /	005-099
D40368P	1	CN0966A18G11P7-000 PLUG	81205	1	26-21-11 AD1090/ /	115-199
D40368PQ		BACC10HF18C CABLE CLAMP	81205	1	26-21-11 */ */	001-008
D40368PQ		BACC10HF18C CABLE CLAMP	81205	1	26-21-11 AD1090/ /	009-099, 115-199
D40370J	1	CN0967C22G55S8-000 RCPT	13556	1	29-33-11 AD1090/ /	001-004, 115-199
D40370J	1	BACC63CC22-55S8 RCPT	81205	1	29-33-11 AD1090/ /	005-099
D40370JK		BACC10HG22C CABLE CLAMP	81205	1	29-33-11 */ */	001-099
D40370JK		BACC10HG22C CABLE CLAMP	81205	1	29-33-11 */ /	115-199
D40370P	1	CN0966A22G55P8-000 PLUG	13556	1	29-33-11 AD1090/ /	001-004
D40370P	1	BACC63CB22-55P8 PLUG	81205	1	29-33-11 AD1090/ /	005-099
D40370P	1	CN0966A22G55P8-000 PLUG	81205	1	29-33-11 AD1090/ /	115-199
D40370PQ		BACC10HG22C CABLE CLAMP	81205	1	29-33-11 */ */	001-008
D40370PQ		BACC10HG22C CABLE CLAMP	81205	1	29-33-11 AD1090/ /	009-099, 115-199

EQUIPMENT LIST

D280N032

Section D40300

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40374J	1	BACC45FN14-15S7 RCPT	81205	1	33-21-31 P034-00/ /	001-099
D40374J	1	BACC45FN14-15S7 RCPT	81205	1	33-21-31 P34/ /	115-199
D40374P	1	BACC45FT14-15P7 PLUG-	81205	1	33-21-32 P34/ /	ALL
D40376J	1	BACC45FN14-15S8 RCPT	81205	1	33-21-51 P034-00/ /	001-099
D40376J	1	BACC45FN14-15S8 RCPT	81205	1	33-21-51 P34/ /	115-199
D40376P	1	BACC45FT14-15P8 PLUG-	81205	1	33-21-12 P34/ /	001-099
D40376P	1	BACC45FT14-15P8 PLUG-	81205	1	33-21-12 AP0034/ /	115-199
D40378J	1	BACC45FN14-15P RCPT	81205	1	24-41-11 P034-00/ /	001-099
D40378J	1	BACC45FN12-12P RCPT	81205	1	24-41-11 P034-00/ /	115-199
D40378P	1	BACC45FT14-15S PLUG	81205	1	24-41-12 P034-00/ /	001-099
D40378P	1	BACC45FT12-12S PLUG	81205	1	24-41-12 P034-00/ /	115-199
D40380J	1	BACC63BV14B7SN RCPT	81205	1	32-61-22 AW1179/ /	001-099
D40380J	1	BACC63BV14B7SN RCPT	81205	1	32-61-12 AW1179/ /	115-199
D40380JK	1	BACC10HF14C CLAMP	81205	1	32-61-22 */ */	001-099
D40380JK	1	BACC10HF14C CLAMP	81205	1	32-61-12 */ /	115-199
D40380P	1	BACC63BP14B7PNL PLUG	81205	1	32-61-22 AW1179/ /	ALL
D40380PQ	1	100140FS6000 ADAPTER-BACKSHELL	61491	1	32-61-22 */ */	ALL

EQUIPMENT LIST

D280N032

Section D40300

Page 11

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40380PR		287N6102-12 CONDUIT	81205	1	32-61-22 */ */	ALL
D40382J	1	BACC63BV14B7S6 RCPT-	81205	1	32-61-12 AW1179/ /	ALL
D40382JK		BACC10HF14C CABLE CLAMP	81205	1	32-61-12 */ /	ALL
D40382P	1	BACC63BP14B7P6L PLUG	81205	1	32-61-12 AW1179/ /	ALL
D40382PQ	1	100140FS6000 ADAPTER-BACKSHELL	61491	1	32-61-12 */ */	ALL
D40382PR	1	287N6102-11 CONDUIT	81205	1	32-61-12 */ */	ALL
D40388J	1	FRF0-32-7S03 RCPT-	71468	1	33-31-11 393/161/L12	001-099
D40388J	1	FRF0-32-7S03 RCPT-	71468	1	33-31-11 393/161/L012	115-199
D40388JK		MS3410-D-32 CABLE CLAMP	96906	1	33-31-11 */ */	ALL
D40388P	1	FRF6-32-7P08 PLUG-	71468	1	33-42-11 AC0393/ /	ALL
D40390J	1	BACC45FN14-7P9 RCPT	81205	1	33-42-11 P36/ /	ALL
D40390P	1	BACC45FT14-7S9 PLUG	81205	1	33-11-11 P036-00/ /	ALL
D40392J	1	BACC45FN24-43S8 RCPT-	81205	1	24-21-11 P031-00/ /	ALL
D40392P	1	BACC45FT24-43P8 PLUG	81205	1	24-22-11 P031-00/ /	ALL
D40394J	1	BACC45FN22-55S8 RCPT	81205	1	24-22-22 P032-00/ /	ALL
D40394P	1	BACC45FT22-55P8 PLUG-	81205	1	24-22-12 P032-00/ /	ALL
D40398J	1	BACC45FN20-25S9 RCPT	81205	1	24-21-21 E5-2/ /	ALL

EQUIPMENT LIST

D280N032

Section D40300

Page 12

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40398P	1	BACC45FT20-25P9 PLUG-	81205	1	24-11-21 E005-02/ /	ALL

EQUIPMENT LIST

D280N032

Section D40300
Page 13 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40400J	1	BACC45FN22-55S8 RCPT	81205	1	24-23-12 P034-00/ /	ALL
D40400P	1	BACC45FT22-55P8 PLUG-	81205	1	24-22-41 P034-00/ /	ALL
D40402J	1	CN0967C24G43SN-000 RCPT-	13556	1	30-11-11 880/ /	001-004
D40402J	1	BACC63CC24-43SN RCPT-	13556	1	30-11-11 880/ /	005-099
D40402J	1	CN0967C24G43SN-000 RCPT	13556	1	30-11-11 880/ /	115-199
D40402JK		BACC10HF24C CABLE CLAMP	81205	1	30-11-11 */ */	ALL
D40402P	1	CN0966A24G43PN-000 PLUG-	13556	1	33-43-11 AD0880/ /	001-004, 115-199
D40402P	1	BACC63CB24-43PN PLUG-	81205	1	33-43-11 AD0880/ /	005-099
D40402PQ		BACC10HF24C CABLE CLAMP	81205	1	33-43-11 */ /	ALL
D40404J	1	CN0967C22G19PN-000 RCPT	13556	1	33-43-12 AW2333/ /	001-004, 115-199
D40404J	1	BACC63CC22-19PN RCPT	81205	1	33-43-12 AW2333/ /	005-099
D40404JK		BACC10HF22C CABLE CLAMP-	81205	1	33-43-12 */ /	ALL
D40404P	1	CN0966A22G19SN-000 PLUG-	13556	1	27-51-41 AW2333/ /	001-004, 115-199
D40404P	1	BACC63CB22-19SN PLUG-	13556	1	27-51-41 AW2333/ /	005-099
D40404PQ		BACC10HF22C CABLE CLAMP	81205	1	27-51-41 */ */	ALL
D40410J	1	BACC45FN18-31S RCPT	81205	1	33-25-23 P037-00/ /	001-099
D40410J	1	BACC45FN18-31S RCPT	81205	1	33-25-23 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D40400

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40410P	1	BACC45FT18-31P PLUG-	81205	1	33-23-21 P37/ /	ALL
D40412J	1	BACC45FN24-43S RCPT-	81205	1	33-23-22 923/276/R060	ALL
D40412P	1	BACC45FT24A43P PLUG-	81205	1	33-23-22 923/276/R036	001-099
D40412P	1	BACC45FT24A43P PLUG-	81205	1	33-23-22 930/295/R025	115-199
D40414J	1	BACC45FN22-19S RCPT-	81205	1	33-23-23 1215/276/R056	001-099
D40414J	1	BACC45FN22-19S RCPT-	81205	1	33-23-23 1210/295/R025	115-199
D40414P	1	BACC45FT22A19P PLUG-	81205	1	33-23-23 1215/275/R65	001-099
D40414P	1	BACC45FT22A19P PLUG-	81205	1	33-23-23 1215/275/R065	115-199
D40416J	1	BACC45FN16-10S6 PLUG	81205	1	24-51-15 P71/ /	ALL
D40416P	1	BACC45FT16B10P6 PLUG	81205	1	24-51-15 P071-00/ /	ALL
D40418J	1	BACC45FN18-8S7 RCPT	81205	1	24-25-12 P71/ /	ALL
D40418P	1	BACC45FT18B8P7 PLUG	81205	1	24-25-12 P071-00/ /	ALL
D40427J	1	BACC45FN16-24P8 RCPT.	81205	1	34-16-11 P1-3/ /	ALL
D40427P	1	BACC45FT16D24S8 PLUG	81205	1	34-46-11 P1-3/MO-/D	ALL
D40432J	1	BACC63BV14B7SN RCPT	81205	1	32-61-12 AW2179/ /	ALL
D40432JK	1	BACC10HF14C CLAMP	81205	1	32-61-12 */ */	001-099
D40432JK	1	BACC10HF14C CLAMP	81205	1	32-61-12 */ /	115-199

EQUIPMENT LIST

D280N032

Section D40400

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40432P	1	BACC63BP14B7PNL PLUG	81205	1	32-61-22 AW2179/ /	ALL
D40432PQ	1	100140FS6000 ADAPTER-BACKSHELL	61491	1	32-61-22 IRSS179/ /	ALL
D40432PR		287N6102-12 CONDUIT	81205	1	32-61-22 IRSS179/ /	ALL
D40434J	1	BACC63BV22B19SN RCPT-	81205	1	32-09-12 AW2240/ /	ALL
D40434JK		BACC10HF22C CABLE CLAMP	81205	1	32-09-12 AW2240/ /*	001-099
D40434JK		BACC10HF22C CABLE CLAMP	81205	1	32-09-12 */ */	115-199
D40434P	1	BACC63BP22B19PNL PLUG	81205	1	32-09-12 AW2240/ /	ALL
D40440J	1	BACC63BV14B7S6 RCPT-	81205	1	32-61-22 AW2179/ /	001-099
D40440J	1	BACC63BV14B7S6 RCPT-	81205	1	32-61-12 AW2179/ /	115-199
D40440JK		BACC10HF14C CABLE CLAMP	81205	1	32-61-22 */ /	001-099
D40440JK		BACC10HF14C CABLE CLAMP	81205	1	32-61-12 AW2179/ /	115-199
D40440P	1	BACC63BP14B7P6 PLUG	81205	1	32-61-22 AW2179/ /	001-099
D40440P	1	BACC63BP14B7P6L PLUG	81205	1	32-61-22 AW2179/ /	115-199
D40440PQ	1	100140FS6000 ADAPTER-BACKSHELL	61491	1	32-61-22 IRSS179/ /	ALL
D40440PR		287N6102-11 CONDUIT	81205	1	32-61-22 IRSS179/ /	ALL
D40442J	1	BACC63BV22B19S6 RCPT-	81205	1	32-09-11 AW2240/ /	ALL
D40442JK		BACC10HF22C CABLE CLAMP	81205	1	32-09-11 AW2240/ /	ALL

EQUIPMENT LIST

D280N032

Section D40400

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40442P	1	BACC63BP22B19P6L PLUG	81205	1	32-09-11 AW2240/ /	ALL
D40450J	1	BACC45FN16-24S PLUG	81205	1	24-25-12 P71/ /	ALL
D40450P	1	BACC45FT16B24P PLUG	81205	1	24-25-12 P071-00/ /	ALL
D40452J	1	BACC45FN22-12S8 PLUG	81205	1	24-51-15 P71/ /	ALL
D40452P	1	BACC45FT22B12P8 PLUG	81205	1	24-51-15 P071-00/ /	ALL
D40454J	1	BACC45FN14-15P7 RCPT-	81205	1	33-51-11 409/301/L4	ALL
D40454P	1	BACC45FT14-15S7 PLUG	81205	1	33-51-11 406/296/L005	001-099
D40454P	1	BACC45FT14-15S7 PLUG	81205	1	33-51-11 405/296/L5	115-199
D40456J	1	BACC45FN14-15P9 RCPT-	81205	1	33-51-11 AA0409/ /	ALL
D40456P	1	BACC45FT14-15S9 PLUG	81205	1	33-51-11 406/296/L005	001-099
D40456P	1	BACC45FT14-15S9 PLUG	81205	1	33-51-11 405/296/0	115-199
D40460J	1	BACC45FN22-12S7 PLUG	81205	1	24-51-25 P71/ /	ALL
D40460P	1	BACC45FT22B12P7 PLUG	81205	1	24-51-25 P71/ /	001-002, 115-199
D40460P	1	BACC45FT22B12P7 PLUG	81205	1	24-51-25 P071-00/ /	003-099
D40464J	1	BACC45FN14-3S7 RCPT	81205	1	29-33-11 E6-4/ /	115-199
D40464P	1	BACC45FT14-3P7 PLUG	81205	1	29-33-11 E6-4/ /	115-199
D40464PQ		S2407-12-9 CABLE CLAMP	07418	1	29-33-11 */ */	115-199

EQUIPMENT LIST

D280N032

Section D40400

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40471J	1	BACC45FN16-24S7 RCPT-	81205	1	22-13-11 AA1705/ /	001-099
D40471J	1	BACC45FN16-24S7 RCPT-	81205	1	22-13-11 1705/ /	115-199
D40471P	1	BACC45FT16-24P7 PLUG-	81205	1	22-13-11 AA1705/ /	ALL
D40473J	1	BACC45FN16-24S RCPT-	81205	1	22-11-31 AA1705/ /	001-099
D40473J	1	BACC45FN16-24S RCPT-	81205	1	22-11-31 1705/ /	115-199
D40473P	1	BACC45FT16-24P PLUG-	81205	1	22-11-31 AA1705/ /	ALL
D40474J	1	BACC45FN14-15S9 RCPT	81205	1	33-21-31 P034-00/ /	001-099
D40474J	1	BACC45FN14-15S9 RCPT	81205	1	33-21-31 P34/ /	115-199
D40474P	1	BACC45FT14-15P9 PLUG-	81205	1	33-21-41 P34/ /	ALL
D40475J	1	BACC45FN20-39S6 RCPT-	81205	1	27-21-12 AA1705/ /	001-099
D40475J	1	BACC45FN20-39S6 RCPT-	81205	1	27-21-12 1705/ /	115-199
D40475P	1	BACC45FT20-39P6 PLUG-	81205	1	27-21-12 AA1705/ /	ALL
D40476J	1	BACC45FN14-15S6 RCPT	81205	1	33-21-51 P034-00/ /	001-099
D40476J	1	BACC45FN14-15S6 RCPT	81205	1	33-21-51 P34/ /	115-199
D40476P	1	BACC45FT14-15P6 PLUG-	81205	1	33-21-21 P34/ /	001-099
D40476P	1	BACC45FT14-15P6 PLUG-CEILING, RIGHT	81205	1	33-21-11 P34/ /	115-199
D40478J	1	CN0967C14G07SN-000 RCPT	13556	1	26-18-11 AC0880/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D40400

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40478J	1	BACC63CC14-7SN RCPT	81205	1	26-18-11 AC0880/ /	005-099
D40478JK		BACC10HF14C CABLE CLAMP	81205	1	26-18-11 */ */	001-099
D40478JK		BACC10HF14C CABLE CLAMP	81205	1	26-18-11 */ /	115-199
D40478P	1	CN0966A14G07PN-000 PLUG	13556	1	26-18-11 AC0880/ /	001-004, 115-199
D40478P	1	BACC63CB14-7PN PLUG	81205	1	26-18-11 AC0880/ /	005-099
D40478PQ		BACC10HF14C CABLE CLAMP	81205	1	26-18-11 */ /	ALL
D40480J	1	BACC45FN14-3S6 RCPT	81205	1	29-33-11 E6-4/ /	115-199
D40480P	1	BACC45FT14-3P6 PLUG	81205	1	29-33-11 E6-4/ /	115-199
D40480PQ		S2407-12-9 CABLE CLAMP	07418	1	29-33-11 */ */	115-199
D40481J	1	BACC45FN20-39P RCPT-	81205	1	22-11-21 AA1715/ /	ALL
D40481P	1	BACC45FT20A39S PLUG-	81205	1	22-11-21 AA1715/ /	ALL
D40487J	1	BACC45FN16-24S6 RCPT-	81205	1	22-11-21 AA1705/ /	ALL
D40487P	1	BACC45FT16-24P6 PLUG-	81205	1	22-11-21 AA1705/ /	ALL
D40488J	1	FRF0-32-7SW03 RCPT-	71468	1	33-42-21 AC0393/ /	ALL
D40488JK		MS3410-D-32 CABLE CLAMP	96906	1	33-31-11 */ */	ALL
D40488P	1	FRF6-32-7PW08 PLUG-	71468	1	33-42-21 AC0393/ /	ALL
D40489J	1	BACC45FN20-39S7 RCPT-	81205	1	27-21-22 AA1705/ /	ALL

EQUIPMENT LIST

D280N032

Section D40400

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40489P	1	BACC45FT20-39P7 PLUG-	81205	1	27-21-22 AA1705/ /	ALL
D40490J	1	BACC45FN16-10S8 RCPT	81205	1	23-43-11 P37/ /	ALL
D40490P	1	BACC45FT16-10P8 PLUG	81205	1	33-11-11 P037-00/ /	ALL
D40491J	1	BACC45FN20-39P8 RCPT-	81205	1	22-11-11 AA1715/ /	ALL
D40491P	1	BACC45FT20A39S8 PLUG-	81205	1	22-11-11 AA1715/ /	ALL
D40492J	1	BACC45FN22-32P6 RCPT	81205	1	24-23-11 E5-2/ /	ALL
D40492P	1	BACC45FT22-32S6 PLUG-	81205	1	24-22-22 E005-02/ /	ALL
D40494J	1	BACC45FN16-10P8 RCPT-	81205	1	33-25-11 AA409/ /	ALL
D40494P	1	BACC45FT16-10S8 PLUG-	81205	1	38-32-11 AA0409/ /	ALL
D40495J	1	BACC45FN16-24P6 RCPT	81205	1	22-12-22 P010-00/ /	ALL
D40495P	1	BACC45FT16A24S6 PLUG	81205	1	22-11-22 AP0010/ /	001-099
D40495P	1	BACC45FT16A24S6 PLUG	81205	1	22-11-22 P10/ /	115-199
D40496J	1	BACC45FN20-25P6 RCPT	81205	1	38-13-11 P37/ /	001-099
D40496J	1	BACC45FN18-31P RCPT	81205	1	38-13-11 P37/ /	115-199
D40496P	1	BACC45FT20-25S6 PLUG-	81205	1	33-22-11 P37/ /	001-099
D40496P	1	BACC45FT18-31S PLUG-	81205	1	33-22-11 P37/ /	115-199
D40497J	1	BACC45FN20-41P7 RCPT-	81205	1	22-11-31 AA1715/ /	ALL

EQUIPMENT LIST

D280N032

Section D40400

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40497P	1	BACC45FT20A41S7 PLUG-	81205	1	22-11-31 AA1715/ /	ALL

EQUIPMENT LIST

D280N032

Section D40400

Page 8 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40501J	1	BACC45FN20-41P8 RCPT	81205	1	22-12-11 P010-00/ /	ALL
D40501P	1	BACC45FT20A41S8 PLUG	81205	1	22-12-11 P10/ /	ALL
D40503J	1	BACC45FN16-24P RCPT	81205	1	22-12-31 P010-00/ /	ALL
D40503P	1	BACC45FT16A24S PLUG-	81205	1	22-12-31 P010-00/ /	ALL
D40505J	1	BACC63CC16-10P9 RCPT-	81205	1	27-61-14 AW1156/ /	001-099
D40505J	1	CN0967C16G10S9-000 RCPT-	13556	1	27-61-14 AW1156/ /	115-199
D40505JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-14 */ */	ALL
D40505P	1	BACC63CB16-10S9 PLUG	81205	1	27-61-14 AW1156/ /	001-099
D40505P	1	CN0966A16G10P9-000 PLUG	13566	1	27-61-14 AW1156/ /	115-199
D40505PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-14 */ */	001-099
D40505PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-14 */ /	115-199
D40518J	1	BACC45FN14-3S RCPT	81205	1	29-33-11 E6-4/ /	115-199
D40518P	1	BACC45FT14-3P PLUG	81205	1	29-33-11 E6-4/ /	115-199
D40518PQ		S2407-12-9 CABLE CLAMP	07418	1	29-33-11 */ /	115-199
D40519J	1	BACC63CC16-10P9 RCPT-	81205	1	27-61-14 AW2164/ /	001-099
D40519J	1	CN0967C16G10S9-000 RCPT-	13556	1	27-61-14 AW2164/ /	115-199
D40519JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-14 * */ */	001-099

EQUIPMENT LIST

D280N032

Section D40500

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40519JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-14 */ */	115-199
D40519P	1	BACC63CB16-10S9 PLUG	81205	1	27-61-14 AW2164/ /	001-099
D40519P	1	CN0966A16G10P9-000 PLUG	13556	1	27-61-14 AW2164/ /	115-199
D40519PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-14 */ */	ALL
D40523J	1	BACC45FN22-55S6 RCPT	81205	1	34-46-11 AP0001/ /	ALL
D40523P	1	BACC45FT22A55P6 PLUG	81205	1	77-12-11 217.6/198/L34	001-099
D40523P	1	BACC45FT22A55P6 PLUG	81205	1	77-12-11 AP0001/ /	115-199
D40525J	1	BACC45FN20-41P RCPT	81205	1	34-22-27 P3-3/ /	ALL
D40525P	1	BACC45FT20A41S PLUG	81205	1	34-22-28 P3-3/ /	ALL
D40529J	1	BACC63CC16-10P9 RCPT-	81205	1	27-61-15 AW1180/ /	001-099
D40529J	1	CN0967C16G10S9-000 RCPT-	13556	1	27-61-15 AW1180/ /	115-199
D40529JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-15 */ */	ALL
D40529P	1	BACC63CB16-10S9 PLUG	81205	1	27-61-15 AW1180/ /	001-099
D40529P	1	CN0966A16G10P9-000 PLUG-	13556	1	27-61-15 AW1180/ /	115-199
D40529PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-15 */ */	001-099
D40529PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-15 */ /	115-199
D40541J	1	BACC63CC16-10P9 RCPT-	81205	1	27-61-15 AW2180/ /	001-099

EQUIPMENT LIST

D280N032

Section D40500

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40541J	1	CN0967C16G10S9-000 RCPT-	13556	1	27-61-15 AW2180/ /	115-199
D40541JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-15 */*/	ALL
D40541P	1	BACC63CB16-10S9 PLUG	81205	1	27-61-15 AW2180/ /	001-099
D40541P	1	CN0966A16G10P9-000 PLUG-	13556	1	27-61-15 AW2180/ /	115-199
D40541PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-15 */*/	ALL
D40542J	1	BACC45FN14-15P RCPT	81205	1	24-22-11 P36/ /	ALL
D40542P	1	BACC45FT14-15S PLUG	81205	1	24-22-11 P036-00/ /	ALL
D40543J	1	BACC63CC16-10P6 RCPT-	81205	1	27-61-16 AW1164/ /	001-099
D40543J	1	CN0967C16G10S6-000 RCPT-	13556	1	27-61-16 AW1164/ /	115-199
D40543JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-16 */*/	ALL
D40543P	1	BACC63CB16-10S6 PLUG	81205	1	27-61-16 AW1164/ /	001-099
D40543P	1	CN0966A16G10P6-000 PLUG	13556	1	27-61-16 AW1164/ /	115-199
D40543PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-16 */*/	001-099
D40543PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-16 */ /	115-199
D40570J	1	BACC45FN22-55S RCPT	81205	1	80-11-21 P37/ /	ALL
D40570P	1	BACC45FT22-55P PLUG	81205	1	24-11-11 P037-00/ /	001-099
D40570P	1	BACC45FT22-55P PLUG	81205	1	24-11-11 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D40500

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40571J	1	BACC63CC16-10PN RCPT-	81205	1	27-61-16 AW2156/ /	001-099
D40571J	1	CN0967C16G10SN-000 RCPT-	13556	1	27-61-16 AW2156/ /	115-199
D40571JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-16 * * / *	001-099
D40571JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-16 * / *	115-199
D40571P	1	BACC63CB16-10SN PLUG	81205	1	27-61-16 AW2156/ /	001-099
D40571P	1	CN0966A16G10PN-000 PLUG-	13556	1	27-61-16 AW2156/ /	115-199
D40571PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-16 * / *	001-099
D40571PQ		BACC10HF16C CABLE CLAMP	81205	1	27-61-16 * /	115-199
D40573J	1	CN0967C16G10P7-000 RCPT-	13556	1	27-61-13 AC1148/190/L70	001-004, 115-199
D40573J	1	BACC63CC16-10P7 RCPT-	13556	1	27-61-13 AC1148/190/L70	005-099
D40573JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-13 AC1148/ /	001-004, 115-199
D40573JK		BACC10HF16C CABLE CLAMP	13556	1	27-61-13 AC1148/ /	005-099
D40573P	1	CN0966A16G10S7-000 PLUG-	81205	1	27-61-13 AC1148/ /	001-004
D40573P	1	BACC63CB16-10S7 PLUG-	81205	1	27-61-13 AC1148/ /	005-099
D40573P	1	CN0966A16G10S7-000 PLUG-	13556	1	27-61-13 AC1148/ /	115-199
D40573PQ		BACC10HG16C CABLE CLAMP	81205	1	27-61-13 * / *	ALL
D40574J	1	BACC45FN12-12S7 RCPT	81205	1	26-18-11 P36/ /	001-099

EQUIPMENT LIST

D280N032

Section D40500

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40574P	1	BACC45FT12-12P7 PLUG-	81205	1	26-18-11 P036-00/ /	001-099
D40575J	1	CN0967C16G10P6-000 RCPT-	13556	1	27-61-13 AD1148/ /	001-004, 115-199
D40575J	1	BACC63CC16-10P6 RCPT-	13556	1	27-61-13 AD1148/ /	005-099
D40575JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-13 */*/	001-004, 115-199
D40575JK		BACC10HF16C CABLE CLAMP	13566	1	27-61-13 */*/	005-099
D40575P	1	CN0966A16G10S6-000 PLUG-	81205	1	27-61-13 1148/ /	001-004
D40575P	1	BACC63CB16-10S6 PLUG-	81205	1	27-61-13 1148/ /	005-099
D40575P	1	CN0966A16G10S6-000 PLUG-	13556	1	27-61-13 1148/ /	115-199
D40575PQ		BACC10HG16C CABLE CLAMP	81205	1	27-61-13 */*/	ALL
D40577J	1	CN0967C16G10PN-000 RCPT-	13556	1	27-61-17 AC1148/ /	001-004, 115-199
D40577J	1	BACC63CC16-10PN RCPT-	13556	1	27-61-17 AC1148/ /	005-099
D40577JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-17 */*/	001-004, 115-199
D40577JK		BACC10HF16C CABLE CLAMP	13556	1	27-61-17 */*/	005-099
D40577P	1	CN0966A16G10SN-000 PLUG-	13556	1	27-61-17 AC1148/ /	001-004, 115-199
D40577P	1	BACC63CB16-10SN PLUG-	81205	1	27-61-17 AC1148/ /	005-099
D40577PQ		BACC10HG16C CABLE CLAMP	81205	1	27-61-17 */*/	ALL
D40579J	1	CN0967C16G10PN-000 RCPT-	13556	1	27-61-17 AD1148/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D40500

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40579J	1	BACC63CC16-10PN RCPT-	13556	1	27-61-17 AD1148/ /	005-099
D40579JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-17 */ */	001-004
D40579JK		BACC10HF16C CABLE CLAMP	13556	1	27-61-17 */ */	005-099
D40579JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-17 */ /	115-199
D40579P	1	CN0966A16G10SN-000 PLUG-	13556	1	27-61-17 AD1148/ /	001-004, 115-199
D40579P	1	BACC63CB16-10SN PLUG-	81205	1	27-61-17 AD1148/ /	005-099
D40579PQ		BACC10HG16C CABLE CLAMP	81205	1	27-61-17 */ */	001-099
D40579PQ		BACC10HG16C CABLE CLAMP	81205	1	27-61-17 */ /	115-199
D40580J	1	BACC45FN18-31S7 RCPT	81205	1	24-27-11 P031-00/ /	ALL
D40580P	1	BACC45FT18-31P7 PLUG	81205	1	24-21-11 P031-00/ /	001-099
D40580P	1	BACC45FT18-31P7 PLUG	81205	1	24-21-11 P31/ /	115-199
D40581J	1	CN0967C16G10P6-000 RCPT-	13556	1	27-61-18 AC1148/ /	001-004, 115-199
D40581J	1	BACC63CC16-10P6 RCPT-	13556	1	27-61-18 AC1148/ /	005-099
D40581JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-18 */ */	001-004
D40581JK		BACC10HF16C CABLE CLAMP	13556	1	27-61-18 */ */	005-099
D40581JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-18 */ /	115-199
D40581P	1	CN0966A16G10S6-000 PLUG-	13556	1	27-61-18 AC1148/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D40500

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40581P	1	BACC63CB16-10S6 PLUG-	81205	1	27-61-18 AC1148/ /	005-099
D40581PQ		BACC10HG16C CABLE CLAMP	81205	1	27-61-18 */ */ *	ALL
D40582J	1	BACC45FN22-55P9 RCPT	81205	1	21-45-11 P36/ /	ALL
D40582P	1	BACC45FT22-55S9 PLUG	81205	1	30-21-11 P36/ /	ALL
D40584J	1	BACC45FN22-55P7 RCPT-	81205	1	36-12-11 E4-2/ /	ALL
D40584P	1	BACC45FT22-55S7 PLUG	81205	1	30-41-11 E004-02/ /	001-099
D40584P	1	BACC45FT22-55S7 PLUG	81205	1	30-41-11 E4-2/ /	115-199
D40585J	1	BACC45FN14-15S7 RCPT-	81205	1	31-51-32 P051-00/ /	001-099
D40585J	1	BACC45FN12-12S7 RCPT-	81205	1	31-51-32 P051-00/ /	115-199
D40585P	1	BACC45FT14A15P7 PLUG-	81205	1	31-51-32 P51/ /	001-099
D40585P	1	BACC45FT12A12P7 PLUG-	81205	1	31-51-32 P051-00/ /	115-199
D40587J	1	BACC45FN18-31S6 RCPT-	81205	1	31-51-31 P051-00/ /	ALL
D40587P	1	BACC45FT18A31P6 PLUG-	81205	1	31-51-31 P51/ /	001-099
D40587P	1	BACC45FT18A31P6 PLUG-	81205	1	31-51-31 P051-00/ /	115-199
D40590J	1	BACC45FN20-41P7 RCPT	81205	1	27-32-11 E005-03/ /	001-099
D40590J	1	BACC45FN20-41P7 RCPT	81205	1	27-32-11 E5-3/ /	115-199
D40590P	1	BACC45FT20-41S7 PLUG	81205	1	52-71-11 E005-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D40500

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40590P	1	BACC45FT20-41S7 PLUG	81205	1	52-71-11 E5-3/ /	115-199
D40591J	1	CN0967C16G10P7-000 RCPT-	13556	1	27-61-18 AD1148/ /	001-004, 115-199
D40591J	1	BACC63CC16-10P7 RCPT-	13556	1	27-61-18 AD1148/ /	005-099
D40591JK		BACC10HF16C CABLE CLAMP	81205	1	27-61-18 */ */	001-004, 115-199
D40591JK		BACC10HF16C CABLE CLAMP	13556	1	27-61-18 */ */	005-099
D40591P	1	CN0966A16G10S7-000 PLUG-	13566	1	27-61-18 AD1148/ /	001-004, 115-199
D40591P	1	BACC63CB16-10S7 PLUG-	81205	1	27-61-18 AD1148/ /	005-099
D40591PQ		BACC10HG16C CABLE CLAMP	81205	1	27-61-18 */ /	ALL
D40592J	1	BACC45FN18-31P7 RCPT	81205	1	24-22-22 P032-00/ /	ALL
D40592P	1	BACC45FT18-31S7 PLUG	81205	1	24-22-21 P032-00/ /	ALL
D40594J	1	BACC45FN22-55P7 RCPT	81205	1	36-11-21 P37/ /	ALL
D40594P	1	BACC45FT22A55S7 PLUG	81205	1	30-11-11 P037-00/ /	001-099
D40594P	1	BACC45FT22A55S7 PLUG	81205	1	30-11-11 P37/ /	115-199
D40598J	1	BACC45FN22-55P RCPT	81205	1	21-32-21 E5-2/ /	ALL
D40598P	1	BACC45FT22-55S PLUG	81205	1	21-61-11 E005-02/ /	001-099
D40598P	1	BACC45FT22-55S PLUG	81205	1	21-61-11 E5-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D40500

Page 8 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40600J	1	BACC45FN20-39P6 RCPT	81205	1	24-11-11 E5-2/ /	ALL
D40600P	1	BACC45FT20-39S6 PLUG	81205	1	24-11-11 E005-02/ /	001-099
D40600P	1	BACC45FT20-39S6 PLUG	81205	1	24-11-11 E5-2/ /	115-199
D40602J	1	BACC45FN12-12P RCPT-	81205	1	49-61-11 E004-02/ /	001-099
D40602J	1	BACC45FN16-24P RCPT-	81205	1	49-61-11 E4-2/ /	115-199
D40602P	1	BACC45FT12-12S PLUG	81205	1	49-61-11 E004-02/ /	001-099
D40602P	1	BACC45FT16-24S PLUG	81205	1	49-61-11 E4-2/ /	115-199
D40608J	1	BACC45FN20-39P RCPT	81205	1	30-21-11 P36/ /	ALL
D40608P	1	BACC45FT20-39S PLUG	81205	1	30-21-11 P036-00/ /	001-099
D40608P	1	BACC45FT20-39S PLUG	81205	1	30-21-11 P36/ /	115-199
D40610J	1	BACC45FN22-55S9 RCPT-	81205	1	30-41-11 P011-00/ /	ALL
D40610P	1	BACC45FT22-55P9 PLUG-	81205	1	27-51-31 P011-00/ /	001-099
D40610P	1	BACC45FT22-55P9 PLUG-	81205	1	27-51-31 P11/ /	115-199
D40612J	1	BACC45FN22-55S6 RCPT-	81205	1	23-11-11 P11/ /	ALL
D40612P	1	BACC45FT22-55P6 PLUG-	81205	1	28-22-11 P011-00/ /	001-099
D40612P	1	BACC45FT22-55P6 PLUG-	81205	1	28-22-11 P11/ /	115-199
D40614J	1	BACC45FN22-55S RCPT-	81205	1	21-51-23 P11/ /	ALL

EQUIPMENT LIST

D280N032

Section D40600

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40614P	1	BACC45FT22-55P PLUG-	81205	1	27-51-51 P011-00/ /	001-099
D40614P	1	BACC45FT22-55P PLUG-	81205	1	27-51-51 P11/ /	115-199
D40616J	1	BACC45FN14-12S7 RCPT-	81205	1	27-48-21 P011-00/ /	ALL
D40616P	1	BACC45FT14-12P7 PLUG-	81205	1	27-58-11 P011-00/ /	001-099
D40616P	1	BACC45FT14-12P7 PLUG-	81205	1	27-58-11 P11/ /	115-199
D40618J	1	BACC45FN22-55S7 RCPT-	81205	1	27-18-11 P011-00/ /	ALL
D40618P	1	BACC45FT22-55P7 PLUG-	81205	1	22-11-21 P11/ /	ALL
D40620J	1	BACC45FN22-55S8 RCPT-	81205	1	21-51-13 P011-00/ /	001-099
D40620J	1	BACC45FN22-55S8 RCPT-	81205	1	21-51-13 P11/ /	115-199
D40620P	1	BACC45FT22-55P8 PLUG-	81205	1	36-12-21 P011-00/ /	001-099
D40620P	1	BACC45FT22-55P8 PLUG-	81205	1	36-12-21 P11/ /	115-199
D40622J	1	BACC45FN20-39S8 RCPT-	81205	1	21-58-12 P011-00/ /	001-099
D40622J	1	BACC45FN20-39S8 RCPT-	81205	1	21-58-12 P11/ /	115-199
D40622P	1	BACC45FT20-39P8 PLUG-	81205	1	28-22-21 P11/ /	ALL
D40624J	1	BACC45FN20-39S9 RCPT-	81205	1	31-51-12 P011-00/ /	ALL
D40624P	1	BACC45FT20-39P9 PLUG-	81205	1	31-51-12 P011-00/ /	001-099
D40624P	1	BACC45FT20-39P9 PLUG-	81205	1	31-51-12 P11/ /	115-199

EQUIPMENT LIST

D280N032

Section D40600

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40626J	1	BACC45FN14-15S6 RCPT-	81205	1	22-11-31 P011-00/ /	001-099
D40626J	1	BACC45FN14-15S6 RCPT	81205	1	22-11-31 P011-00/ /	115-199
D40626P	1	BACC45FT14-15P6 PLUG-	81205	1	22-11-32 P011-00/ /	001-099
D40626P	1	BACC45FT14-15P6 PLUG-	81205	1	22-11-32 P11/ /	115-199
D40628J	1	BACC45FN22-55S RCPT	81205	1	21-51-13 AC0820/ /	115-199
D40628P	1	BACC45FT22A55P PLUG	81205	1	21-51-12 820/ /	115-199
D40629J	1	BACC45FN22-55S7 RCPT-	81205	1	34-51-11 AP0001/ /	ALL
D40629P	1	BACC45FT22D55P7 PLUG-	81205	1	22-11-12 AP0001/ /	ALL
D40630J	1	BACC45FN22-55S6 RCPT	81205	1	21-51-13 AC0820/ /	115-199
D40630P	1	BACC45FT22A55P6 PLUG	81205	1	21-51-13 820/ /	115-199
D40631J	1	BACC45FN22-55S7 RCPT	81205	1	34-51-21 P003-00/ /	001-099
D40631J	1	BACC45FN22-55S7 RCPT	81205	1	34-51-21 AP0003/ /	115-199
D40631P	1	BACC45FT22D55P7 PLUG	81205	1	22-11-22 AP0003/ /	ALL
D40632J	1	BACC45FN22-55S7 RCPT	81205	1	21-51-15 AC0820/ /	115-199
D40632P	1	BACC45FT22A55P7 PLUG	81205	1	21-51-15 820/ /	115-199
D40633J	1	BACC45FN14-15S9 RCPT	81205	1	22-11-32 AP0001/ /	001-099
D40633J	1	BACC45FN12-12S9 RCPT	81205	1	22-11-32 AP0001/ /	115-199

EQUIPMENT LIST

D280N032

Section D40600

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40633P	1	BACC45FT14A15P9 PLUG-	81205	1	22-11-32 AP0001/ /	001-099
D40633P	1	BACC45FT12-12P9 PLUG-	81205	1	22-11-32 AP0001/ /	115-199
D40633PQ		BACC10GH12 CABLE CLAMP-	81205	1	22-11-32 AP0001/ /	115-199
D40639J	1	BACC45FN16-24S6 RCPT-	81205	1	31-51-21 P051-00/ /	ALL
D40639P	1	BACC45FT16A24P6 PLUG	81205	1	34-16-11 P051-00/ /	001-099
D40639P	1	BACC45FT16A24P6 PLUG	81205	1	34-16-11 P51/ /	115-199
D40656J	1	BACC45FN22-55P6 PLUG	81205	1	21-51-12 E3-3/ /	001-099
D40656P	1	BACC45FT22A55S6 PLUG	81205	1	21-51-12 E003-03/ /	001-099
D40661J	1	KD-19-105-M06 PANEL JACK	91836	1	34-51-11 1671/300/L10	001-099
D40661J	1	KD-19-105-M06 PANEL JACK	91836	1	34-51-11 AA1671/ /	115-199
D40661P	1	KD-59-165 PLUG	81205	1	34-51-11 1671/300/L10	001-099
D40661P	1	KD-59-186-M06 PLUG	81205	1	34-51-11 1671/300/L10	115-199
D40662J	1	BACC45FN14-12S6 RCPT	81205	1	25-31-33 P031-00/ /	ALL
D40662P	1	BACC45FT14-12P6 PLUG-	81205	1	25-31-33 P031-00/ /	ALL
D40663J	1	KD-19-105-M06 PANEL JACK	91836	1	34-51-21 1671/300/R10	001-099
D40663J	1	KD-19-105-M06 PANEL JACK	91836	1	34-51-21 AB1671/ /	115-199
D40663P	1	KD-59-165 PLUG	81205	1	34-51-21 1671/ /	001-099

EQUIPMENT LIST

D280N032

Section D40600

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40663P	1	KD-59-186-M06 PLUG	81205	1	34-51-21 AB1671/ /	115-199
D40664J	1	BACC45FN14-15S6 RCPT	81205	1	25-31-21 P032-00/ /	001-099
D40664J	1	BACC45FN20-25S6 RCPT	81205	1	25-31-21 P032-00/ /	115-199
D40664P	1	BACC45FT14-15P6 PLUG-	81205	1	25-31-11 P032-00/ /	001-099
D40664P	1	BACC45FT20-25P6 PLUG-	81205	1	25-31-21 P32/ /	115-199
D40666J	1	BACC45FN22-55P8 PLUG	81205	1	21-51-22 E3-2/ /	001-099
D40666P	1	BACC45FT22A55S8 PLUG	81205	1	21-51-22 E003-02/ /	001-099
D40670J	1	BACC45FN22-55P8 PLUG	81205	1	21-51-24 E3-3/ /	001-099
D40670P	1	BACC45FT22A55S8 PLUG	81205	1	21-51-24 E003-03/ /	001-099
D40671J		BACC45FN20-41P7 RCPT-	81205	1	34-22-91 P1-1/ /	ALL
D40671P	1	BACC45FT20A41S7 PLUG	81205	1	34-22-91 P1-1 MO/D/	ALL
D40672J	1	BACC45FN14-12P8 RCPT-	81205	1	23-12-21 E004-03/ /	001-099
D40672J	1	BACC45FN14-12P8 RCPT-	81205	1	23-12-21 E4-3/ /	115-199
D40672P	1	BACC45FT14-12S8 PLUG-	81205	1	23-12-21 E4-3/ /	ALL
D40674J	1	BACC45FN12-12P8 RCPT-	81205	1	22-31-12 E002-03/ /	001-099
D40674J	1	BACC45FN14-15P8 RCPR-	81205	1	22-31-12 E2-3/ /	115-199
D40674P	1	BACC45FT12-12S8 PLUG-	81205	1	22-31-12 E002-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D40600

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40674P	1	BACC45FT14-15S8 PLUG-	81205	1	22-31-12 E2-3/ /	115-199
D40676J	1	BACC45FN12-12P7 RCPT	81205	1	22-11-11 E003-01/ /	001-099
D40676J	1	BACC45FN14-15P7 RCPT	81205	1	22-11-11 E003-01/ /	115-199
D40676P	1	BACC45FT12-12S7 PLUG-	81205	1	27-41-11 E003-01/ /	001-099
D40676P	1	BACC45FT14-15S7 PLUG-	81205	1	27-41-11 E3-1/ /	115-199
D40677J	1	BACC45FN16-24P6 RCPT	81205	1	33-16-51 P1-3/ /	ALL
D40677P	1	BACC45FT16A24S6 PLUG	81205	1	33-16-51 P1-3/MO-/D	ALL
D40678J	1	BACC45FN14-15P RCPT-	81205	1	34-55-11 E3-3/ /	ALL
D40678JK		BACA14BH12 ADAPTER	81205	1	34-55-11 E3-3/ /	001-099
D40678P	1	BACC45FT14-15S PLUG-	81205	1	31-31-11 E003-03/ /	001-099
D40678P	1	BACC45FT14-15S PLUG-	81205	1	31-31-11 E3-3/ /	115-199
D40680J	1	BACC45FN12-12P7 RCPT	81205	1	78-34-11 E003-04/ /	001-099
D40680J	1	BACC45FN14-15P9 RCPT	81205	1	78-34-11 E003-04/ /	115-199
D40680P	1	BACC45FT12-12S7 PLUG-	81205	1	78-34-11 E003-04/ /	001-099
D40680P	1	BACC45FT14-15S9 PLUG-	81205	1	78-34-11 E3-4/ /	115-199
D40682J	1	BACC45FN14-15P7 RCPT	81205	1	27-09-11 E004-01/ /	001-099
D40682J	1	BACC45FN12-12P7 RCPT	81205	1	27-09-11 E4-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D40600

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40682P	1	BACC45FT14-15S7 PLUG-	81205	1	27-09-11 E004-01/ /	001-099
D40682P	1	BACC45FT12-12S7 PLUG-	81205	1	27-09-11 E4-1/ /	115-199
D40684J	1	BACC45FN14-15P8 RCPT-	81205	1	31-41-11 E4-2/ /	ALL
D40684P	1	BACC45FT14-15S8 PLUG-	81205	1	23-22-11 E004-02/ /	001-099
D40684P	1	BACC45FT14-15S8 PLUG-	81205	1	23-22-11 E4-2/ /	115-199
D40686J	1	BACC45FN14-15P7 RCPT-	81205	1	23-21-11 E004-03/ /	001-099
D40686J	1	BACC45FN14-15P7 RCPT-	81205	1	23-21-11 E4-3/ /	115-199
D40686P	1	BACC45FT14-15S7 PLUG-	81205	1	23-21-11 E004-03/ /	001-099
D40686P	1	BACC45FT14-15S7 PLUG-	81205	1	23-21-11 E4-3/ /	115-199
D40688J	1	BACC45FN14A12S6 RCPT-	81205	1	23-12-31 E004-04/ /	001-099
D40688P	1	BACC45FT14A12P6 PLUG	81205	1	23-12-31 E4-4/ /	001-099
D40696J	1	BACC45FN22-55P6 RCPT	81205	1	21-58-11 P36/ /	ALL
D40696P	1	BACC45FT22-55S6 PLUG-	81205	1	21-45-11 P036-00/ /	001-099
D40696P	1	BACC45FT22-55S6 PLUG-	81205	1	21-45-11 P36/ /	115-199
D40697J	1	BACC45FN18-31P9 RCPT-	81205	1	27-41-11 AA1715/ /	ALL
D40697P	1	BACC45FT18A31S9 PLUG-	81205	1	27-41-11 AA1715/ /	ALL
D40699J	1	BACC45FN18-31P9 RCPT-	81205	1	27-41-21 AA1715/ /	ALL

EQUIPMENT LIST

D280N032

Section D40600

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40699P	1	BACC45FT18A31S9 PLUG-	81205	1	27-41-21 AA1715/ /	ALL

EQUIPMENT LIST

D280N032

Section D40600

Page 8 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40700J	1	BACC45FN12-12P RCPT-	81205	1	34-55-21 E003-02/ /	001-099
D40700P	1	BACC45FT12-12S PLUG-	81205	1	34-55-21 E3-2/ /	001-099
D40702J	1	BACC45FN14-15P7 RCPT	81205	1	52-71-11 E003-04/ /	001-099
D40702J	1	BACC45FN14-15P6 RCPT	81205	1	52-71-11 E003-04/ /	115-199
D40702P	1	BACC45FT14-15S7 PLUG-	81205	1	78-34-21 E3-4/ /	001-099
D40702P	1	BACC45FT14-15S6 PLUG-	81205	1	78-34-21 E3-4/ /	115-199
D40704J	1	BACC45FN12-12P7 RCPT-	81205	1	79-32-11 E4-2/ /	001-099
D40704J	1	BACC45FN14-15P7 RCPT-	81205	1	79-32-11 E4-2/ /	115-199
D40704P	1	BACC45FT12-12S7 PLUG-	81205	1	27-38-11 E4-2/ /	001-099
D40704P	1	BACC45FT14-15S7 PLUG-	81205	1	27-38-11 E4-2/ /	115-199
D40710J	1	BACC45FN16-10P8 RCPT	81205	1	34-33-21 E5-2/ /	ALL
D40710P	1	BACC45FT16-10S8 PLUG-	81205	1	34-33-21 E5-2/ /	ALL
D40714J	1	BACC45FN14-15P RCPT-	81205	1	31-51-11 P051-00/ /	001-099
D40714J	1	BACC45FN12-12P RCPT-	81205	1	31-51-11 P051-00/ /	115-199
D40714P	1	BACC45FT14-15S PLUG-	81205	1	31-51-11 P051-00/ /	001-099
D40714P	1	BACC45FT12-12S PLUG-	81205	1	31-51-11 P51/ /	115-199
D40715J	1	KD-19-69 BKHD JACK	91836	1	34-31-11 199/165/L008	ALL

EQUIPMENT LIST

D280N032

Section D40700

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40715P	1	KD-59-125 PLUG	91836	1	34-31-11 199/165/L008	ALL
D40716J	1	BACC45FN16-24P6 RCPT	81205	1	33-24-11 P36/ /	ALL
D40716P	1	BACC45FT16-24S6 PLUG-	81205	1	29-11-22 P036-00/ /	001-099
D40716P	1	BACC45FT16-24S6 PLUG-	81205	1	2312B1 P36/ /	115-199
D40717J	1	KD-19-69 BKHD JACK	91836	1	34-31-21 199/ /	ALL
D40717P	1	KD-59-125 PLUG	91836	1	34-31-21 199/162/R2	ALL
D40718J	1	BACC45FN22-55P7 RCPT	81205	1	36-11-31 P37/ /	ALL
D40718P	1	BACC45FT22-55S7 PLUG-	81205	1	21-43-21 P037-00/ /	001-099
D40718P	1	BACC45FT22-55S7 PLUG-	81205	1	21-43-21 P37/ /	115-199
D40719J	1	KD-19-69 BKHD JACK	91836	1	34-31-31 199/170/L008	ALL
D40719P	1	KD-59-125 PLUG	91836	1	34-31-31 199/170/L008	ALL
D40728J	1	BACC45FN20-39S8 RCPT	81205	1	75-31-11 P36/ /	ALL
D40728P	1	BACC45FT20-39P8 PLUG-	81205	1	34-12-11 P36/ /	ALL
D40734J	1	BACC45FN14-12P7 RCPT-	81205	1	23-22-11 E004-03/ /	001-099
D40734J	1	BACC45FN14-12P7 RCPT-	81205	1	23-22-11 E4-3/ /	115-199
D40734P	1	BACC45FT14-12S7 PLUG-	81205	1	23-31-11 E004-03/ /	ALL
D40736J	1	BACC45FN14-15P8 RCPT-	81205	1	31-51-12 P051-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D40700

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40736J	1	BACC45FN12-12P8 RCPT-	81205	1	31-51-12 P051-00/ /	115-199
D40736P	1	BACC45FT14-15S8 PLUG-	81205	1	31-51-12 P051-00/ /	001-099
D40736P	1	BACC45FT12-12S8 PLUG-	81205	1	31-51-12 P51/ /	115-199
D40738J	1	BACC45FN20-25P7 RCPT	81205	1	28-25-11 P37/ /	ALL
D40738P	1	BACC45FT20-25S7 PLUG-	81205	1	35-21-11 P037-00/ /	001-099
D40738P	1	BACC45FT20-25S7 PLUG-	81205	1	35-21-11 P37/ /	115-199
D40748J	1	BACC45FN20-39S RCPT-	81205	1	34-22-16 P011-00/ /	ALL
D40748P	1	BACC45FT20-39P PLUG-	81205	1	34-13-11 P011-00/ /	ALL
D40750J	1	BACC45FN20-39S RCPT-	81205	1	34-22-22 P6/ /	001-099
D40750J	1	BACC45FN20-39S RCPT-	81205	1	34-22-22 P11/ /	115-199
D40750P	1	BACC45FT20-39P PLUG-	81205	1	33-13-41 P011-00/ /	001-099
D40750P	1	BACC45FT20-39P PLUG-	81205	1	32-42-11 P011-00/ /	115-199
D40752J	1	BACC45FN14-15S6 RCPT-	81205	1	33-111 P011-00/ /	001-099
D40752J	1	BACC45FN12-12S6 RCPT-	81205	1	33-11-11 P011-00/ /	115-199
D40752P	1	BACC45FT14-15P6 PLUG-	81205	1	33-11-11 P011-00/ /	001-099
D40752P	1	BACC45FT12-12P6 PLUG-	81205	1	33-11-11 P011-00/ /	115-199
D40754J	1	BACC45FN20-39S RCPT-	81205	1	34-13-11 AP0001/ /	ALL

EQUIPMENT LIST

D280N032

Section D40700

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40754P	1	BACC45FT20A39P PLUG	81205	1	34-13-11 AP0001/ /	001-099
D40754P	1	BACC45FT20A39P PLUG	81205	1	34-13-11 217.6/198/L34	115-199
D40756J	1	BACC45FN20-39S RCPT-	81205	1	34-22-26 AP0003/ /	ALL
D40756P	1	BACC45FT20A39P PLUG	81205	1	33-13-41 AP0003/ /	001-099
D40756P	1	BACC45FT20A39P PLUG	81205	1	33-13-41 217.6/200/R40	115-199
D40758J	1	BACC45FN14-15S8 RCPT-	81205	1	33-11-11 P001-00/ /	001-099
D40758J	1	BACC45FN12-12S8 RCPT-	81205	1	33-11-11 AP0001/ /	115-199
D40758P	1	BACC45FT14D15P8 PLUG	81205	1	34-13-11 AP0001/ /	001-099
D40758P	1	BACC63BN12B12P8 PLUG	81205	1	34-13-11 217.6/198/L34	115-199
D40760J	1	BACC45FN14-7S9 RCPT	81205	1	33-21-41 P37/ /	115-199
D40760P	1	BACC45FT14A7P9 PLUG-	81205	1	33-31-41 P037-00/ /	115-199
D40774J	1	BACC45FN16-24P PLUG	81205	1	21-51-12 E3-2/ /	001-099
D40774P	1	BACC45FT16A24S PLUG	81205	1	21-61-21 E003-02/ /	001-099
D40782J	1	BACC45FN12-12P RCPT	81205	1	74-31-11 P010-00/ /	ALL
D40782P	1	BACC45FT12-12S PLUG	81205	1	27-51-41 P010-00/ /	001-099
D40782P	1	BACC45FT12A12S PLUG	81205	1	73-21-11 P010-00/ /	115-199
D40784J	1	BACC45FN12-12P6 RCPT	81205	1	74-31-21 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D40700

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40784P	1	BACC45FT12-12S6 PLUG	81205	1	78-36-11 P010-00/ /	001-099
D40784P	1	BACC45FT12A12S6 PLUGP10	81205	1	73-21-21 AP0010/ /	115-199
D40798J	1	BACC45FN20-39P7 RCPT	81205	1	21-25-11 P005-00/ /	ALL
D40798P	1	BACC45FT20-39S7 PLUG	81205	1	21-51-23 P011-00/ /	001-099
D40798P	1	BACC45FT20-39S7 PLUG	81205	1	21-51-23 P05/ /	115-199

EQUIPMENT LIST

D280N032

Section D40700
Page 5 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40800J	1	BACC45FN22-55P8 RCPT	81205	1	21-31-11 P005-00/ /	ALL
D40800P	1	BACC45FT22-55S8 PLUG	81205	1	21-31-11 P5/ /	ALL
D40802J	1	BACC45FN20-39P7 RCPT	81205	1	21-65-11 P005-00/ /	001-099
D40802J	1	BACC45FN20-39P7 RCPT	81205	1	21-65-11 AP0005/ /	115-199
D40802P	1	BACC45FT20-39S7 PLUG-	81205	1	33-44-11 P005-00/ /	001-099
D40802P	1	BACC45FT20-39S7 PLUG	81205	1	33-44-11 P005-00/ /	115-199
D40804J	1	BACC45FN22-55P8 PLUG	81205	1	21-61-31 P005-00/ /	001-099
D40804J	1	BACC45FN22-55P8 RCPT	81205	1	25-31-23 P005-00/ /	115-199
D40804P	1	BACC45FT22-55S8 PLUG	81205	1	21-61-31 P005-00/ /	ALL
D40806J	1	BACC45FN22-55P6 RCPT	81205	1	74-31-11 P005-00/ /	ALL
D40806P	1	BACC45FT22-55S6 PLUG-	81205	1	74-31-11 P005-00/ /	001-099
D40806P	1	BACC45FT22A55S6 PLUG	81205	1	74-31-11 P005-00/ /	115-199
D40808J	1	BACC45FN22-55P6 RCPT	81205	1	74-31-21 P005-00/ /	ALL
D40808P	1	BACC45FT22-55S6 PLUG-	81205	1	35-21-11 P005-00/ /	001-099
D40808P	1	BACC45FT22-55S6 PLUG	81205	1	35-21-11 P005-00/ /	115-199
D40810J	1	BACC45FN14-15P RCPT	81205	1	27-23-21 P50/ /	001-099
D40810J	1	BACC45FN12-12P RCPT	81205	1	27-23-21 P50/ /	115-199

EQUIPMENT LIST

D280N032

Section D40800

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40810P	1	BACC45FT14-15S PLUG-	81205	1	27-48-21 P050-00/ /	001-099
D40810P	1	BACC45FT12-12S PLUG-	81205	1	27-48-21 P50/ /	115-199
D40812J	1	BACC45FN14-15P9 RCPT	81205	1	28-21-21 P50/ /	ALL
D40812P	1	BACC45FT14-15S9 PLUG	81205	1	21-51-21 P050-00/ /	001-099
D40812P	1	BACC45FT14-15S9 PLUG	81205	1	21-51-21 P50/ /	115-199
D40816J	1	BACC63CN1407SN RECPT	81205	1	36-11-11 AS1140/ /	ALL
D40816JK		BACC10HD14A CABLE CLAMP	81205	1	36-11-11 AS1140/ /	ALL
D40816P	1	BACC63CM1407PN PLUG	81205	1	36-11-12 AS1140/ /	ALL
D40816PQ		BACC10HD14A CABLE CLAMP	81205	1	36-11-12 AS1140/ /	ALL
D40818J	1	BACC63CN1407SN RCPT	81205	1	26-12-21 AS2140/ /	ALL
D40818JK		BACC10HD14A CABLE CLAMP	81205	1	26-12-21 AS2140/ /	ALL
D40818P	1	BACC63CM1407PN PLUG	81205	1	36-11-21 AS2140/ /	ALL
D40818PQ		BACC10HD14A CABLE CLAMP	81205	1	36-11-21 AS2140/ /	ALL
D40824J	1	BACC45FN24-43S RCPT-	81205	1	21-61-21 P011-00/ /	ALL
D40824P	1	BACC45FT24-43P PLUG-	81205	1	23-12-21 P11/ /	ALL
D40834J	1	BACC45FN22-55P8 RCPT	81205	1	32-31-11 P003-01/ /	ALL
D40834P	1	BACC45FT22D55S8 PLUG	81205	1	22-31-12 P3-1/ /	ALL

EQUIPMENT LIST

D280N032

Section D40800

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40836J	1	BACC45FN22-55P RCPT	81205	1	32-61-12 P003-01/ /	ALL
D40836P	1	BACC45FT22D55S PLUG	81205	1	22-32-11 P3-1/ /	ALL
D40838J	1	BACC45FN22-32S RCPT-	81205	1	23-12-11 P011-00/ /	ALL
D40838P	1	BACC45FT22-32P PLUG-	81205	1	23-31-11 P011-00/ /	ALL
D40844J	1	BACC45FN16-24P PLUG	81205	1	21-61-21 E3-3/ /	001-099
D40844P	1	BACC45FT16A24S PLUG	81205	1	21-61-21 E003-03/ /	001-099
D40846J	1	BACC45FN16-24P7 PLUG	81205	1	21-51-12 E3-3/ /	001-099
D40846P	1	BACC45FT16A24S7 PLUG	81205	1	21-51-12 E003-03/ /	001-099
D40850J	1	BACC45FN22-55P RECP	81205	1	33-11-11 P007-00/ /	ALL
D40850P	1	BACC45FT22A55S PLUG	81205	1	31-25-11 P7/ /L016	001-099
D40850P	1	BACC45FT22A55S PLUG	81205	1	31-21-11 P7/ /L016	115-199
D40854J	1	BACC45FN22-55P RCPT	81205	1	33-11-11 P007-00/ /	ALL
D40854P	1	BACC45FT22A55S PLUG	81205	1	33-13-11 P7/ /	ALL
D40860J	1	BACC45FN12-12S RCPT	81205	1	30-31-11 P36/ /	115-199
D40860P	1	BACC45FT12A12P PLUG	81205	1	30-31-11 P036-00/ /	115-199
D40862J	1	BACC45FN12-12S7 PLUG	81205	1	30-31-12 P37/ /	115-199
D40862P	1	BACC45FT12A12P7 PLUG	81205	1	30-31-12 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D40800

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40864J	1	BACC45FN12-12S PLUG	81205	1	30-31-12 P37/ /	115-199
D40864P	1	BACC45FT12A12P PLUG	81205	1	30-31-12 P37/ /	115-199
D40866J	1	BACC45FN22-32S9 RCPT-	81205	1	30-31-11 P6/ /	ALL
D40866P	1	BACC45FT22-32P9 PLUG-	81205	1	30-31-11 P006-00/ /	ALL
D40868J	1	BACC45FN24-43S9 RCPT-	81205	1	30-31-12 P006-00/ /	ALL
D40868P	1	BACC45FT24-43P9 PLUG-	81205	1	28-22-11 P006-00/ /	001-099
D40868P	1	BACC45FT24-43P9 PLUG-	81205	1	28-22-11 P6/ /	115-199
D40870J	1	BACC45FN16-24S6 RCPT-	81205	1	28-21-11 P6/ /	001-002, 115-199
D40870J	1	BACC45FN14-15S6 RCPT-	81205	1	28-21-11 P6/ /	003-099
D40870P	1	BACC45FT16-24P6 PLUG-	81205	1	26-01-01 P006-00/ /	001-002, 115-199
D40870P	1	BACC45FT14-15P6 PLUG-	81205	1	26-01-01 P006-00/ /	003-099
D40874J	1	BACC45FN22-55P6 RCPT	81205	1	21-58-11 P36/ /	ALL
D40874P	1	BACC45FT22-55S6 PLUG	81205	1	21-58-11 P036-00/ /	001-099
D40874P	1	BACC45FT22-55S6 PLUG	81205	1	21-58-11 P36/ /	115-199
D40881J	1	BACC45FN22-55S RCPT-	81205	1	34-22-34 E002-02/ /	001-099
D40881J	1	BACC45FN22-55S RCPT-	81205	1	34-22-34 E2-2/ /	115-199
D40881P	1	BACC45FT22A55P PLUG	81205	1	34-22-34 E002-02/ /	ALL

EQUIPMENT LIST

D280N032

Section D40800

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40882J	1	BACC45FN20-41S RCPT-	81205	1	33-22-11 379/285/L40	001-099
D40882P	1	BACC45FT20A41P PLUG-	81205	1	33-22-11 379/ /L036	001-099
D40883J	1	BACC45FN22-55S7 RCPT-	81205	1	34-22-34 E002-03/ /	001-099
D40883J	1	BACC45FN22-55S7 RCPT-	81205	1	34-22-34 E2-3/ /	115-199
D40883P	1	BACC45FT22A55P7 PLUG	81205	1	34-22-34 E002-03/ /	ALL
D40892J	1	BACC45FN12-12P8 RCPT-	81205	1	24-34-11 E4-2/ /	001-099
D40892J	1	BACC45FN14-15P8 RCPT-	81205	1	24-34-11 E4-2/ /	115-199
D40892P	1	BACC45FT12-12S8 PLUG	81205	1	23-34-11 E004-02/ /	001-099
D40892P	1	BACC45FT14-15S8 PLUG	81205	1	23-34-11 E4-2/ /	115-199
D40893J	1	BACC45FN12D12S RCPT	81205	1	22-12-21 P010-00/ /	ALL
D40894J	1	BACC45FN14-15P7 RCPT	81205	1	24-23-11 E5-2/ /	ALL
D40894P	1	BACC45FT14-15S7 PLUG	81205	1	24-23-11 E005-02/ /	001-099
D40894P	1	BACC45FT14-15S7 PLUG	81205	1	24-23-11 E5-2/ /	115-199
D40895J	1	BACC45FN12D12S9 RCPT	81205	1	22-12-31 P010-00/ /	ALL
D40897J	1	BACC45FN14D15S RCPT	81205	1	22-32-15 P010-00/ /	ALL
D40898J	1	BACC63CC20-41PN RCPT	81205	1	27-18-11 AW1180/ /	001-099
D40898J	1	CN0967C20G41SN-000 RCPT	13556	1	27-51-41 AW1180/ /	115-199

EQUIPMENT LIST

D280N032

Section D40800

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40898JK		BACC10HF20C CABLE CLAMP	06324	1	27-18-11 */ */	001-099
D40898JK		BACC10HF20C CLAMP	81205	1	27-51-41 */ /	115-199
D40898P	1	BACC63CB20-41SN PLUG	81205	1	27-18-11 AW1180/ /	001-099
D40898P	1	CN0966A20G41PN-000 PLUG	13556	1	27-18-11 AW1180/ /	115-199
D40898PQ		BACC10HF20C CABLE CLAMP	06324	1	27-18-11 */ */	001-099
D40898PQ		BACC10HF20C CABLE CLAMP	81205	1	27-18-11 */ /	115-199
D40899J	1	BACC45FN16-24P7 RCPT	81205	1	26-11-21 P010-00/ /	ALL
D40899P	1	BACC45FT16-24S7 PLUG	81205	1	76-11-12 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D40800

Page 6 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40901J	1	BACC45FN18-31P7 RCPT	81205	1	26-11-11 P010-00/ /	ALL
D40901P	1	BACC45FT18-31S7 PLUG	81205	1	76-11-11 P010-00/ /	ALL
D40902J	1	BACC63CC16-10PN RCPT	81205	1	28-22-21 AW1164/ /	001-099
D40902J	1	CN0967C16G10SN-000 RCPT	13556	1	28-22-21 AW1164/ /	115-199
D40902JK		BACC10HF16C CABLE CLAMP	06324	1	28-22-21 */ */	001-099
D40902JK		BACC10HF16C CABLE CLAMP	81205	1	28-22-21 */ /	115-199
D40902P	1	BACC63CB16-10SN PLUG	81205	1	28-22-21 AW1164/ /	001-099
D40902P	1	CN0966A16G10PN-000 PLUG-	13556	1	28-22-21 AW1164/ /	115-199
D40902PQ		BACC10HF16C CABLE CLAMP	81205	1	28-22-21 */ */	001-099
D40902PQ		BACC10HF16C CABLE CLAMP	81205	1	28-22-21 */ /	115-199
D40904J	1	BACC45FN12-12P9 RCPT-	81205	1	32-44-11 E4-2/ /	001-099
D40904J	1	BACC45FN14-15P9 RCPT-	81205	1	32-44-11 E4-2/ /	115-199
D40904P	1	BACC45FT12-12S9 PLUG-	81205	1	24-28-11 E004-02/ /	001-099
D40904P	1	BACC45FT14-15S9 PLUG-	81205	1	24-28-11 E004-02/ /	115-199
D40908J	1	BACC45FN14-12P7 RCPT	81205	1	22-23-21 E5-2/ /	ALL
D40908P	1	BACC45FT14-12S7 PLUG-	81205	1	24-11-21 E005-02/ /	ALL
D40910J	1	BACC45FN22-32P6 RCPT	81205	1	28-22-11 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D40900

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40910P	1	BACC45FT22-32S6 PLUG-	81205	1	30-31-11 P036-00/ /	ALL
D40912J	1	BACC45FN24-43P8 RCPT	81205	1	30-32-11 P37/ /	ALL
D40912P	1	BACC45FT24-43S8 PLUG-	81205	1	24-53-21 P037-00/ /	ALL
D40914J	1	BACC45FN14-15P9 RCPT	81205	1	21-58-11 P36/ /	ALL
D40914P	1	BACC45FT14-15S9 PLUG-	81205	1	26-01-01 P036-00/ /	ALL
D40918J	1	BACC45FN16-10P7 RCPT	81205	1	21-58-13 P36/ /	ALL
D40918P	1	BACC45FT16A10S7 PLUG-	81205	1	21-58-13 P036-00/ /	001-099
D40918P	1	BACC45FT16A10S7 PLUG-	81205	1	21-58-13 P36/ /	115-199
D40920J	1	BACC45FN18-8P RCPT	81205	1	21-58-13 P37/ /	115-199
D40920P	1	BACC45FT18A8S PLUG-	81205	1	30-71-11 P037-00/ /	115-199
D40922J	1	BACC63CC16-24P7 RCPT	81205	1	28-26-11 AW1156/ /	001-099
D40922J	1	CN0967C16G24S7-000 RCPT	13556	1	27-51-61 AW1156/ /	115-199
D40922JK		BACC10HF16C CABLE CLAMP	06324	1	28-26-11 */ */	001-099
D40922JK		BACC10HF16C CABLE CLAMP	81205	1	27-51-61 AW1156/ /	115-199
D40922P	1	BACC63CB16-24S7 PLUG-	81205	1	27-51-61 AW1156/ /	001-099
D40922P	1	CN0966A16G24P7-000 PLUG	13556	1	28-26-11 AW1156/ /	115-199
D40922PQ		BACC10HF16C CABLE CLAMP	81205	1	27-51-61 */ /	001-099

EQUIPMENT LIST

D280N032

Section D40900

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40922PQ		BACC10HF16C CABLE CLAMP	81205	1	28-26-11 */ /	115-199
D40924J	1	BACC45FN12-12P6 RCPT	81205	1	34-46-21 E003-04/ /	001-099
D40924J	1	BACC45FN18-31P RCPT	81205	1	34-46-21 E003-04/ /	115-199
D40924P	1	BACC45FT12A12S6 PLUG	81205	1	34-46-21 E003-04/ /	001-099
D40924P	1	BACC45FT18A31S PLUG	81205	1	34-46-21 E003-04/ /	115-199
D40927J	1	BACC45FN12-12S6 RCPT-	81205	1	31-31-11 E3-3/ /	115-199
D40927P	1	BACC45FT12A12P6 PLUG-	81205	1	31-31-13 E3-3/ /	115-199
D40930J	1	BACC63CC20-41PN RCPT	81205	1	28-26-11 AW2180/ /	001-099
D40930J	1	CN0967C20G41SN-000 RCPT-	13556	1	28-42-11 AW2180/ /	115-199
D40930JK		BACC10HF20C CABLE CLAMP	06324	1	28-26-11 */ */	001-099
D40930JK		BACC10HF20C CABLE CLAMP	81205	1	28-42-11 AW2180/ /	115-199
D40930P	1	BACC63CB20-41SN PLUG-	81205	1	28-42-11 AW2180/ /	001-099
D40930P	1	CN0966A20G41PN-000 PLUG	13556	1	28-26-11 AW2180/ /	115-199
D40930PQ		BACC10HF20C CABLE CLAMP	06324	1	28-42-11 */ /	001-099
D40930PQ		BACC10HF20C CABLE CLAMP	81205	1	28-26-11 */ */	115-199
D40942J	1	BACC63CC16-10P8 PLUG	81205	1	28-22-21 AW2164/ /	001-099
D40942J	1	CN0967C16G10S8-000 RCPT	13556	1	28-22-21 AW2164/ /	115-199

EQUIPMENT LIST

D280N032

Section D40900

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40942JK		BACC10HF16C CABLE CLAMP	06324	1	28-22-21 */ */ *	001-099
D40942JK		BACC10HF16C CABLE CLAMP	81205	1	28-22-21 AW2164/ /	115-199
D40942P	1	BACC63CB16-10S8 PLUG	81205	1	28-22-21 AW2164/ /	001-099
D40942P	1	CN0966A16G10P8-000 PLUG	13556	1	28-22-21 AW2164/ /	115-199
D40942PQ		BACC10HF16C CABLE CLAMP	06324	1	28-22-21 */ */ *	001-099
D40942PQ		BACC10HF16C CABLE CLAMP	81205	1	28-22-21 */ */ *	115-199
D40944J	1	BACC63CC16-24P7 RCPT	81205	1	27-18-11 AW2156/ /	001-099
D40944J	1	CN0967C16G24S7-000 RCPT-	13556	1	27-51-41 AW2156/ /	115-199
D40944JK		BACC10HF16C CABLE CLAMP	06324	1	27-18-11 */ */ *	001-099
D40944JK		BACC10HF16C CABLE CLAMP	81205	1	27-51-41 */ /	115-199
D40944P	1	BACC63CB16-24S7 PLUG	81205	1	27-58-11 AW2156/ /	001-099
D40944P	1	CN0966A16G24P7-000 PLUG	13556	1	27-18-11 AW2156/ /	115-199
D40944PQ		BACC10HF16C CABLE CLAMP	06324	1	27-58-11 */ */ *	001-099
D40944PQ		BACC10HF16C CABLE CLAMP	81205	1	27-18-11 */ */ *	115-199
D40946J	1	BACC45FN18-31S9 RCPT	81205	1	26-15-11 P54/ /	ALL
D40946P	1	BACC45FT18-31P9 PLUG	81205	1	26-15-11 P054-00/ /	001-099
D40946P	1	BACC45FT18-31P9 PLUG	81205	1	26-15-11 P54/ /	115-199

EQUIPMENT LIST

D280N032

Section D40900

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40956J	1	BACC45FN18-31S7 RCPT	81205	1	24-27-11 P034-00/ /	ALL
D40956P	1	BACC45FT18-31P7 PLUG-	81205	1	24-22-22 P034-00/ /	ALL
D40957J	1	BACC45FN14-15P6 RCPT-	81205	1	27-41-11 1715/300/L002	ALL
D40957P	1	BACC45FT14A15S6 PLUG-	81205	1	27-41-11 AA1715/ /	ALL
D40959J	1	BACC45FN14-15P6 RCPT-	81205	1	27-41-21 AA1715/ /	ALL
D40959P	1	BACC45FT14A15S6 PLUG-	81205	1	27-41-21 AA1715/ /	ALL
D40964J	1	CN0967C18G14S7-000 RCPT	13556	1	32-61-11 AC1090/ /	001-004, 115-199
D40964J	1	BACC63CC18-14S7 RCPT	81205	1	32-61-11 AC1090/ /	005-099
D40964JK		BACC10HG18C CABLE CLAMP	81205	1	32-61-11 */ /	ALL
D40964P	1	CN0966A18G14P7-000 PLUG	13556	1	32-61-13 AC1090/ /	001-004
D40964P	1	BACC63CB18-14P7 PLUG	81205	1	32-61-13 AC1090/ /	005-099
D40964P	1	CN0966A18G14P7-000 PLUG	81205	1	32-61-11 AC1090/ /	115-199
D40964PQ		BACC10HG18C CABLE CLAMP	81205	1	32-61-13 */ */	001-099
D40964PQ		BACC10HG18C CABLE CLAMP	81205	1	32-61-11 */ */	115-199
D40970J	1	BACC45FN22-55P9 RCPT	81205	1	21-51-13 P50/ /	ALL
D40970P	1	BACC45FT22-55S9 PLUG	81205	1	21-51-13 P050-00/ /	001-099
D40970P	1	BACC45FT22-55S9 PLUG	81205	1	21-51-13 P50/ /	115-199

EQUIPMENT LIST

D280N032

Section D40900

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D40972J	1	BACC45FN22-55P7 RCPT	81205	1	21-51-14 P50/ /	ALL
D40972P	1	BACC45FT22-55S7 PLUG	81205	1	21-51-14 P050-00/ /	001-099
D40972P	1	BACC45FT22-55S7 PLUG	81205	1	21-51-14 P50/ /	115-199
D40974J	1	BACC45FN22-55S RCPT	81205	1	21-51-11 P50/ /	ALL
D40974P	1	BACC45FT22-55P PLUG	81205	1	21-51-11 P050-00/ /	001-099
D40974P	1	BACC45FT22-55P PLUG	81205	1	21-51-11 P50/ /	115-199
D40976J	1	BACC45FN22-55S8 RCPT	81205	1	21-51-23 P50/ /	ALL
D40976P	1	BACC45FT22-55P8 PLUG	81205	1	21-51-21 P050-00/ /	ALL
D40978J	1	BACC45FN22-19P8 RCPT	81205	1	29-11-22 P37/ /	ALL
D40978P	1	BACC45FT22-19S8 PLUG-	81205	1	24-51-51 P037-00/ /	ALL
D40996J	1	BACC45FN18-31P9 RCPT	81205	1	34-21-22 E003-04/ /	ALL
D40996P	1	BACC45FT18-31S9 PLUG	81205	1	34-21-22 E003-04/ /	001-099
D40996P	1	BACC45FT18-31S9 PLUG	81205	1	34-21-22 E3-4/ /	115-199

EQUIPMENT LIST

D280N032

Section D40900

Page 6 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41000P	1	BACC45FT16-24S7 PLUG	81205	1	33-16-11 P026-00/ /	001-099
D41000P	1	BACC45FT16-24S7 PLUG	81205	1	33-16-11 P26/ /	115-199
D41001J	1	BACC45FN18-31S8 RCPT	81205	1	34-21-21 E002-04/ /	001-099
D41001J	1	BACC45FN18-31S8 RCPT	81205	1	34-21-21 E2-4/ /	115-199
D41001P	1	BACC45FT18A31P8 PLUG-	81205	1	22-21-21 E002-04/ /	001-099
D41001P	1	BACC45FT18A31P8 PLUG-	81205	1	22-21-21 E2-4/ /	115-199
D41002P	1	BACC45FT14-12S PLUG	81205	1	33-16-11 P026-00/ /	001-099
D41002P	1	BACC45FT14-12S PLUG	81205	1	33-16-11 P26/ /	115-199
D41004P	1	BACC45FT16-24S PLUG	81205	1	33-11-51 P026-00/ /	001-099
D41004P	1	BACC45FT16-24S PLUG	81205	1	33-11-51 P26/ /	115-199
D41006P	1	BACC45FT16-24S6 PLUG	81205	1	33-16-11 P026-00/ /	001-099
D41006P	1	BACC45FT16-24S6 PLUG	81205	1	33-16-11 P26/ /	115-199
D41008P	1	BACC45FT16-24S9 PLUG	81205	1	33-16-11 P026-00/ /	001-099
D41008P	1	BACC45FT16-24S9 PLUG	81205	1	33-16-11 P26/ /	115-199
D41010P	1	BACC45FT16-24S8 PLUG	81205	1	33-16-11 P026-00/ /	001-099
D41010P	1	BACC45FT16-24S8 PLUG	81205	1	33-16-11 P26/ /	115-199
D41020J	1	BACC45FN22-55S8 RCPT	81205	1	21-31-11 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section D41000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41020P	1	BACC45FT22-55P8 PLUG	81205	1	21-51-11 P036-00/ /	ALL
D41022J	1	BACC45FN22-55S9 RCPT	81205	1	21-58-13 P36/ /	ALL
D41022P	1	BACC45FT22-55P9 PLUG	81205	1	21-51-11 P036-00/ /	ALL
D41024J	1	BACC45FN20-39S RCPT	81205	1	21-58-12 P36/ /	ALL
D41024P	1	BACC45FT20-39P PLUG	81205	1	21-51-11 P036-00/ /	001-099
D41024P	1	BACC45FT20A39P PLUG	81205	1	21-51-11 P036-00/ /	115-199
D41029J	1	KD-19-105-M06 RCPT-	91836	1	23-12-31 1470/160/L50	001-099
D41029P	1	KD-59-186-M06 PLUG-COAX	91836	1	23-12-31 1470/160/L50	001-099
D41030J	1	BACC45FN22-55S6 RCPT	81205	1	33-44-21 P37/ /	ALL
D41030P	1	BACC45FT22-55P6 PLUG	81205	1	21-51-11 P037-00/ /	ALL
D41032J	1	BACC45FN22-55S9 RCPT	81205	1	21-25-21 P37/ /	ALL
D41032P	1	BACC45FT22-55P9 PLUG	81205	1	21-51-11 P037-00/ /	ALL
D41034J	1	BACC45FN20-39S9 RCPT	81205	1	21-58-12 P37/ /	001-099
D41034J	1	BACC45FN20-39S6 RCPT	81205	1	21-58-12 P37/ /	115-199
D41034P	1	BACC45FT20-39P9 PLUG	81205	1	21-51-11 P037-00/ /	001-099
D41034P	1	BACC45FT20A39P6 PLUG	81205	1	21-51-11 P037-00/ /	115-199
D41041J	1	BACC45FN22-55P7 RCPT	81205	1	27-51-11 P003-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D41000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41041J	1	BACC45FN22-55P7 RCPT	81205	1	27-51-61 AP0003/ /	115-199
D41041P	1	BACC45FT22A55S7 PLUG	81205	1	27-51-21 AP0003/ /	001-099
D41041P	1	BACC45FT22A55S7 PLUG	81205	1	27-51-21 217.6/198/34	115-199
D41058J	1	BACC45FN20-41P6 RCPT-	81205	1	28-42-11 E4-2/ /	001-008
D41058J	1	BACC45FN22-55P6 RCPT-	81205	1	28-42-11 E4-2/ /	009-099, 115-199
D41058P	1	BACC45FT20-41S6 PLUG	81205	1	28-42-11 E004-02/ /	001-008
D41058P	1	BACC45FT22-55S6 PLUG	81205	1	28-42-11 E004-02/ /	009-099
D41058P	1	BACC45FT22-55S6 PLUG	81205	1	28-42-11 E4-2/ /	115-199
D41059J	1	BACC45FN22-55S7 RCPT-	81205	1	31-51-41 P051-00/ /	ALL
D41059P	1	BACC45FT22A55P7 PLUG-	81205	1	27-32-11 P051-00/ /	001-099
D41059P	1	BACC45FT22A55P7 PLUG-	81205	1	27-32-11 P51/ /	115-199
D41060J	1	BACC45FN20-39P9 RCPT	81205	1	21-58-11 P36/ /	ALL
D41060P	1	BACC45FT20-39S9 PLUG	81205	1	21-58-11 P036-00/ /	001-099
D41060P	1	BACC45FT20-39S9 PLUG	81205	1	21-58-11 P36/ /	115-199
D41061J	1	BACC45FN14-15P9 RCPT-	81205	1	34-43-11 E002-01/ /	001-099
D41061J	1	BACC45FN12-12P9 RCPT-	81205	1	34-43-11 E2-1/ /	115-199
D41061P	1	BACC45FT14A15S9 PLUG-	81205	1	34-43-11 E002-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41061P	1	BACC45FT12-12S9 PLUG-	81205	1	34-43-11 E002-01/ /	115-199
D41061PQ	1	BACC10HF12 CABLE CLAMP-	81205	1	34-43-11 */ */ *	115-199
D41062J	1	BACC45FN10-5P6 RECEPTACLE	81205	1	28-25-21 E6 RLY/PNL/	001-099
D41062J	1	BACC45FN10-5P9 RCPT	81205	1	28-25-21 E6 RLY/PNL/	115-199
D41062P	1	BACC45FT10-5S6 PLUG	81205	1	26-18-11 1455/190/R050	001-099
D41062P	1	BACC45FT10-5S9 PLUG	81205	1	26-18-11 E6/ /	115-199
D41063J	1	BACC45FN16-24S8 RCPT-	81205	1	34-22-28 E002-02/ /	001-099
D41063J	1	BACC45FN16-24S8 RCPT-	81205	1	34-22-28 E2-2/ /	115-199
D41063P	1	BACC45FT16A24P8 PLUG-	81205	1	34-43-11 E002-02/ /	ALL
D41065J	1	BACC45FN14-15S6 RCPT-	81205	1	31-41-19 E4-2/ /	001-099
D41065J	1	BACC45FN16-24S6 RCPT-	81205	1	31-41-19 E4-2/ /	115-199
D41065P	1	BACC45FT14A15P6 PLUG	81205	1	31-41-14 E4-2/ /	001-099
D41065P	1	BACC45FT16A24P6 PLUG	81205	1	31-41-14 E4-2/ /	115-199
D41069J	1	BACC45FN18-31S8 RCPT-	81205	1	31-41-11 E4-2/ /	ALL
D41069P	1	BACC45FT18A31P8 PLUG	81205	1	31-41-11 E004-02/ /	ALL
D41071J	1	BACC45FN18-31S7 RCPT-	81205	1	31-41-21 E4-2/ /	ALL
D41071P	1	BACC45FT18A31P7 PLUG	81205	1	31-41-11 E004-02/ /	ALL

EQUIPMENT LIST

D280N032

Section D41000

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41072J	1	BACC63CN1407SN RCPT	81205	1	26-12-11 AS1140/ /	ALL
D41072JK		BACC10HD14A CABLE CLAMP	81205	1	26-12-11 AS1140/ /	ALL
D41072P	1	BACC63CM1407PN PLUG	81205	1	26-11-12 AS1140/ /	ALL
D41072PQ		BACC10HE14A CABLE CLAMP	81205	1	26-11-12 AS1140/ /	ALL
D41073J	1	BACC45FN20-41S RCPT-	81205	1	34-22-14 E002-01/ /	001-099
D41073J	1	BACC45FN20-41S RCPT-	81205	1	34-22-14 E2-1/ /	115-199
D41073P	1	BACC45FT20A41P PLUG	81205	1	34-22-14 E002-01/ /	ALL
D41074J	1	BACC63CN1407SN RCPT	81205	1	26-11-22 AS2140/ /	ALL
D41074JK		BACC10HD14A CABLE CLAMP	81205	1	26-11-22 AS2140/ /	ALL
D41074P	1	BACC63CM1407PN PLUG	81205	1	26-11-22 AS2140/ /	ALL
D41074PQ		BACC10HE14A CABLE CLAMP	81205	1	26-11-22 AS2140/ /	ALL
D41075J	1	BACC45FN20-41S7 RCPT-	81205	1	34-22-15 E002-01/ /	001-099
D41075J	1	BACC45FN20-41S7 RCPT-	81205	1	34-22-15 E2-1/ /	115-199
D41075P	1	BACC45FT20A41P7 PLUG	81205	1	34-22-14 E002-01/ /	ALL
D41077J	1	BACC45FN20-41S6 RCPT-	81205	1	34-22-24 E2-2/ /	001-099
D41077J	1	BACC45FN22-55S6 RCPT-	81205	1	34-22-24 E2-2/ /	115-199
D41077P	1	BACC45FT20A41P6 PLUG	81205	1	34-22-24 E002-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D41000

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41077P	1	BACC45FT22A55P6 PLUG	81205	1	34-22-24 E002-02/ /	115-199
D41079J	1	BACC45FN20-41S9 RCPT-	81205	1	34-22-25 E002-02/ /	001-099
D41079J	1	BACC45FN22-55S9 RCPT-	81205	1	34-22-25 E2-2/ /	115-199
D41079P	1	BACC45FT20A41P9 PLUG	81205	1	34-22-25 E002-02/ /	001-099
D41079P	1	BACC45FT22A55P9 PLUG	81205	1	34-22-25 E002-02/ /	115-199
D41081J	9	BACC45FN16-24S9 RCPT- (34-0414)	81205	1	34-61-11 E002-001/ /	115-199
D41081J	1	BACC45FN16-24S9 RCPT-	81205	1	34-61-11 E002-01/ /	001-099
D41081P	9	BACC45FT16A24P9 PLUG-	81205	1	34-61-11 E2-1/ /	115-199
D41081P	1	BACC45FT16A24P9 PLUG-	81205	1	34-61-11 E002-01/ /	001-099
D41082J	1	BACC45FN14-7S RCPT-	81205	1	24-31-41 P037-00/ /	ALL
D41082P	1	BACC45FT14-7P PLUG	81205	1	24-31-41 P037-00/ /	001-099
D41082P	1	BACC45FT14-7P PLUG	81205	1	24-31-41 P37/ /	115-199
D41083J	1	BACC45FN16-24S RCPT-	81205	1	34-61-21 E002-02/ /	001-099
D41083J	1	BACC45FN14-15S RCPT-	81205	1	34-61-21 E2-2/ /	115-199
D41083P	9	BACC45FT18A31P PLUG (34-0414)	81205	1	34-61-21 E2-2/ /	115-199
D41083P	1	BACC45FT16A24P PLUG	81205	1	34-61-21 E2-2/ /	001-099
D41085J	1	BACC45FN22-55S9 RCPT-	81205	1	34-22-35 E002-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41000

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41085J	1	BACC45FN22-55S9 RCPT-	81205	1	34-22-35 E2-1/ /	115-199
D41085P	1	BACC45FT22A55P9 PLUG	81205	1	34-22-35 E002-01/ /	ALL
D41087J	1	BACC45FN22-55S6 RCPT-	81205	1	34-22-35 E002-03/ /	001-099
D41087J	1	BACC45FN22-55S6 RCPT-	81205	1	34-22-35 E2-3/ /	115-199
D41087P	1	BACC45FT22A55P6 PLUG	81205	1	34-22-35 E002-03/ /	ALL
D41089J	1	BACC45FN22-55S8 RCPT-	81205	1	31-41-12 E002-01/ /	001-099
D41089J	1	BACC45FN22-55S8 RCPT-	81205	1	31-41-12 E2-1/ /	115-199
D41089P	1	BACC45FT22A55P8 PLUG-	81205	1	31-41-12 E002-01/ /	001-099
D41089P	1	BACC45FT22A55P8 PLUG-	81205	1	31-41-12 E2-1/ /	115-199
D41091J	1	BACC45FN22-55S6 RCPT-	81205	1	31-31-12 E002-01/ /	001-099
D41091J	1	BACC45FN22-55S6 RCPT-	81205	1	31-31-12 E2-1/ /	115-199
D41091P	1	BACC45FT22A55P6 PLUG-	81205	1	31-31-12 E002-01/ /	001-099
D41091P	1	BACC45FT22A55P6 PLUG-	81205	1	31-31-12 E2-1/ /	115-199
D41093J	1	BACC45FN22-55S6 RCPT-	81205	1	22-41-12 E002-01/ /	001-099
D41093J	1	BACC45FN22-55S6 RCPT-	81205	1	22-41-12 E2-1/ /	115-199
D41093P	1	BACC45FT22A55P6 PLUG-	81205	1	22-41-12 E002-01/ /	001-099
D41093P	1	BACC45FT22A55P6 PLUG-	81205	1	22-41-12 E2-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D41000

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41095J	1	BACC45FN20-41S RCPT-	81205	1	22-41-12 E002-02/ /	001-099
D41095J	1	BACC45FN22-55S RCPT-	81205	1	22-41-12 E2-2/ /	115-199
D41095P	1	BACC45FT20A41P PLUG-	81205	1	22-41-11 E002-02/ /	001-099
D41095P	1	BACC45FT22A55P PLUG-	81205	1	22-41-11 E2-2/ /	115-199
D41096J	1	BACC45FN16-24S9 RCPT	81205	1	26-15-12 P33/ /	001-099
D41096J	1	BACC45FN12-12S9 RCPT	81205	1	26-15-12 P33/ /	115-199
D41096P	1	BACC45FT16-24P9 PLUG	81205	1	26-15-12 P033-00/ /	001-099
D41096P	1	BACC45FT12-12P9 PLUG	81205	1	26-15-12 P33/ /	115-199
D41097J	1	BACC45FN22-55S6 RCPT-	81205	1	22-15-11 E002-03/ /	001-099
D41097J	1	BACC45FN22-55S6 RCPT-	81205	1	22-15-11 E2-3/ /	115-199
D41097P	1	BACC45FT22A55P6 PLUG-	81205	1	22-15-11 E002-03/ /	001-099
D41097P	1	BACC45FT22A55P6 PLUG-	81205	1	22-15-11 E2-3/ /	115-199
D41099J	1	BACC45FN20-41S9 RCPT	81205	1	22-21-11 E002-04/ /	001-099
D41099J	1	BACC45FN22-55S9 RCPT	81205	1	22-21-11 E2-4/ /	115-199
D41099P	1	BACC45FT20A41P9 PLUG-	81205	1	22-15-11 E002-04/ /	001-099
D41099P	1	BACC45FT22A55P9 PLUG-	81205	1	22-15-11 E2-4/ /	115-199

EQUIPMENT LIST

D280N032

Section D41000
Page 8 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41100J	1	CN0967C20G28S6-000 RCPT	81205	1	21-51-11 880/ /	001-004
D41100J	1	BACC63CC20-28S6 RCPT	81205	1	21-51-11 880/ /	005-099
D41100J	1	CN0967C20G28S6-000 RCPT	13556	1	21-51-11 880/ /	115-199
D41100JK		BACC10HF20C CABLE CLAMP	81205	1	21-51-21 */ */	001-099
D41100JK		BACC10HF20C CABLE CLAMP	81205	1	21-51-21 */ /	115-199
D41100P	1	CN0966A20G28P6-000 PLUG	13556	1	21-51-11 AC0880/ /	001-004, 115-199
D41100P	1	BACC63CB20-28P6 PLUG	81205	1	21-51-11 AC0880/ /	005-099
D41100PQ		BACC10HF20C CABLE CLAMP	81205	1	21-51-11 */ /	ALL
D41101J	1	BACC45FN16-24S7 RCPT-	81205	1	22-41-13 P061-00/ /	ALL
D41102J	1	CN0967C20G28S6-000 RCPT	13556	1	21-51-11 880/ /	001-004, 115-199
D41102J	1	BACC63CC20-28S6 RCPT	81205	1	21-51-11 880/ /	005-099
D41102JK		BACC10HF20C CABLE CLAMP	81205	1	21-51-11 */ /	ALL
D41102P	1	CN0966A20G28P6-000 PLUG	13556	1	21-51-23 AD0880/ /	001-004, 115-199
D41102P	1	BACC63CB20-28P6 PLUG	81205	1	21-51-23 AD0880/ /	005-099
D41102PQ		BACC10HF20C CABLE CLAMP	81205	1	21-51-23 */ */	ALL
D41104J	1	BACC45FN14-12P8 RCPT	81205	1	24-51-71 P031-00/ /	001-099
D41104P	1	BACC45FT14-12S8 PLUG-	81205	1	25-31-25 P31/ /	001-099

EQUIPMENT LIST

D280N032

Section D41100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41106J	1	BACC45FN10-5S RCPT	81205	1	52-51-11 308/279/0	001-099
D41106J	1	BACC45FN10-5S RCPT	81205	1	52-51-11 308/288/0	115-199
D41106P	1	BACC63BN10-5P PLUG-	81205	1	52-51-11 308/288/0	ALL
D41106PQ		BACC10GH10 CABLE CLAMP	81205	1	52-51-11 */*/	ALL
D41112J	1	BACC63BV18A8SN RCPT	81205	1	27-38-11 AA1862/252/L037	ALL
D41112JK		BACC10HG18C CABLE CLAMP	81205	1	27-38-11 */*/	ALL
D41112P	1	BACC63BP18A8PNL PLUG	81205	1	27-38-11 AA1862/ /	ALL
D41112PQ		BACC10HF18 CABLE CLAMP-	81205	1	27-38-11 AA1862/ /	ALL
D41113J	1	BACC45FN12-12S8 RCPT	81205	1	31-31-51 E3-3/ /	001-099
D41113P	1	BACC45FT12-12P8 PLUG	81205	1	31-31-52 E003-03/ /	001-099
D41114J	1	BACC63BV18A8SN RCPT	81205	1	27-38-11 AB1862/ /	ALL
D41114JK		BACC10HG18 CABLE CLAMP	81205	1	27-38-11 */*/	ALL
D41114P	1	BACC63BP18A8PNL PLUG	81205	1	27-38-11 AB1862/ /	ALL
D41114PQ		BACC10HF18 CABLE CLAMP-	81205	1	27-38-11 AB1862/ /	ALL
D41115J	1	BACC45FN12-12S RCPT	81205	1	31-31-51 E3-3/ /	001-099
D41115P	1	BACC45FT12-12P PLUG	81205	1	31-31-52 E003-03/ /	001-099
D41116J	1	CN0967C18G14S9-000 RCPT	13556	1	26-18-21 AD0880/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D41100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41116J	1	BACC63CC18-14S9 RCPT	81205	1	26-18-21 AD0880/ /	005-099
D41116JK		BACC10HF18C CABLE CLAMP	81205	1	26-18-21 */ */	001-099
D41116JK		BACC10HF18C CABLE CLAMP	81205	1	26-18-21 */ /	115-199
D41116P	1	CN0966A18G14P9-000 PLUG	13556	1	36-11-31 AD0880/ /	001-004, 115-199
D41116P	1	BACC63CB18-14P9 PLUG	81205	1	36-11-31 AD0880/ /	005-099
D41116PQ		BACC10HF18C CABLE CLAMP	81205	1	36-11-31 */ /	ALL
D41120J	1	BACC45FN18-14P RCPT-	81205	1	38-32-11 409/301/L08	001-099
D41120J	1	BACC45FN16-10P RCPT-	81205	1	38-32-11 AA0409/ /	115-199
D41120P	1	BACC45FT18-14S PLUG	81205	1	38-32-11 P011-00/ /	001-099
D41120P	1	BACC45FT16-10S PLUG-	81205	1	38-32-11 AA0409/ /	115-199
D41122J	1	BACC45FN20-25S RCPT-	81205	1	30-41-12 P037-00/ /	001-099
D41122J	1	BACC45FN18-14S RCPT-	81205	1	30-41-12 P037-00/ /	115-199
D41122P	1	BACC45FT20-25P PLUG-	81205	1	30-41-12 P037-00/ /	001-099
D41122P	1	BACC45FT18-14P PLUG-	81205	1	30-41-12 P037-00/ /	115-199
D41136J	1	BACC45FN14-7P RCPT-	81205	1	33-37-11 600/180/R55	ALL
D41136P	1	BACC45FT14-7S PLUG-	287N4311 81205	1	33-37-11 /600/	ALL
D41145J	1	BACC45FN12-12S9 RCPT-	81205	1	31-31-51 E3-3/ /	001-099

EQUIPMENT LIST

D280N032

Section D41100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41145P	1	BACC45FT12A12P9 PLUG-	81205	1	31-31-51 E3-3/ /	001-099
D41156J	1	BACC45FN14-7P RCPT-	81205	1	33-37-21 1422/180/R55	ALL
D41156P	1	BACC45FT14-7S PLUG-	287N4311 81205	1	33-37-21 1415/ /	ALL
D41161J	1	2431-76-1 RCPT-COAX		1	34-45-02 430/290/020	ALL
D41161P	1	2435-74-1 PLUG-COAX		1	34-45-02 415/300/020	ALL
D41162J	1	BACC63BV14B7P7 RCPT	81205	1	26-12-11 AS1123/ /	ALL
D41162JK		BACC10HD14A CABLE CLAMP	81205	1	26-12-11 AS1123/ /	ALL
D41162P	1	BACC63BP14B7S7L PLUG	81205	1	26-11-12 AS1123/ /	ALL
D41162PQ		BACC10HD14A CABLE CLAMP	81205	1	26-11-12 */ */	ALL
D41163J	1	2431-76-6 RCPT-COAX		1	34-45-02 430/290/020	ALL
D41163P	1	2435-74-6 PLUG-COAX		1	34-45-02 415/300/020	ALL
D41164J	1	BACC63BV14B7P7 RCPT	81205	1	26-12-21 AS2123/ /	ALL
D41164JK		BACC10HD14A CABLE CLAMP	81205	1	26-12-21 AS2123/ /	ALL
D41164P	1	BACC63BP14B7S7L PLUG	81205	1	26-11-22 AS2123/ /	ALL
D41164PQ		BACC10HD14A CABLE CLAMP	81205	1	26-11-22 */ */	ALL
D41165J	1	2431-76-11 RCPT-COAX		1	34-45-02 430/300/015	ALL
D41165P	1	2435-74-11 PLUG-COAX		1	34-45-02 415/300/015	ALL

EQUIPMENT LIST

D280N032

Section D41100

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41167J	1	2431-76-16 RCPT-COAX		1	34-45-02 430/300/010	ALL
D41167P	1	2435-74-16 PLUG-COAX		1	34-45-02 415/300/010	ALL
D41168J	1	BACC45FN14-7S RCPT-	81205	1	33-37-21 1420/198/R55	ALL
D41168P	1	BACC45FT14-7P PLUG-	287N4311 81205	1	33-37-21 1420/198/R055	ALL
D41170J	1	BACC45FN18-31S6 RCPT	81205	1	33-16-11 AP0003/ /	ALL
D41170P	1	BACC45FT18D31P6 PLUG	81205	1	33-16-11 AP0003/ /	ALL
D41171J	1	2431-74-1 RCPT-COAX		1	34-45-02 AD0440/ /	ALL
D41171P	1	2435-74-1 PLUG-COAX		1	34-45-02 460/140/R20	ALL
D41172J	1	BACC45FN20-39S6 RCPT	81205	1	33-16-31 AP0003/ /	ALL
D41172P	1	BACC45FT20D39P6 PLUG	81205	1	33-13-41 217.6/200/R40	001-099
D41172P	1	BACC45FT20D39P6 PLUG	81205	1	33-13-41 AP0003/ /	115-199
D41173J	1	2431-74-6 RCPT-COAX		1	34-45-02 AD0440/ /	ALL
D41173P	1	2435-74-6 PLUG-COAX		1	34-45-02 460/140/R20	ALL
D41174J	1	BACC45FN22-55S6 RCPT	81205	1	33-11-11 AP0003/ /	ALL
D41174P	1	BACC45FT22A55P6 PLUG	81205	1	33-11-21 217.6/198/34	001-099
D41174P	1	BACC45FT22A55P6 PLUG	81205	1	33-11-21 AP0003/ /	115-199
D41177J	1	2431-74-11 RCPT-COAX		1	34-45-02 AD0440/ /	ALL

EQUIPMENT LIST

D280N032

Section D41100

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41177P	1	2435-74-11 PLUG-COAX		1	34-45-02 460/140/R20	ALL
D41179J	1	2431-74-16 RCPT-COAX		1	34-45-02 AD0440/ /	ALL
D41179P	1	2435-74-16 PLUG-COAX		1	34-45-02 460/140/R20	ALL
D41180J	1	BACC45FN14-15S RECPT-	81205	1	27-23-11 839/ /	ALL
D41180P	1	BACC45FT14-15P PLUG	81205	1	27-23-11 839/ /	ALL
D41181J	1	2431-74-1 RCPT-COAX		1	34-45-02 E002-01/ /	001-099
D41181J	1	2431-74-1 RCPT-COAX		1	34-45-02 E2-1/ /	115-199
D41181P	1	2435-77-1 PLUG-COAX		1	34-45-02 E2-1/ /	ALL
D41185J	1	2431-74-6 RCPT-COAX		1	34-45-02 E002-01/ /	001-099
D41185J	1	2431-74-6 RCPT-COAX		1	34-45-02 E2-1/ /	115-199
D41185P	1	2435-77-6 PLUG-COAX		1	34-45-02 E2-1/ /	ALL
D41187J	1	2431-74-11 RCPT-COAX		1	34-45-02 E002-01/ /	001-099
D41187J	1	2431-74-11 RCPT-COAX		1	34-45-02 E2-1/ /	115-199
D41187P	1	2435-77-11 PLUG-COAX		1	34-45-02 E2-1/ /	ALL
D41188J	1	BACC45FN14-7S RCPT-	81205	1	33-37-11 600/210/R52	001-099
D41188J	1	BACC45FN14-7S RCPT-	81205	1	33-37-11 600/202/R52	115-199
D41188P	1	BACC45FT14-7P PLUG-	287N4311 81205	1	33-37-11 600/202/R052	ALL

EQUIPMENT LIST

D280N032

Section D41100

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41189J	1	2431-74-16 RCPT-COAX		1	34-45-02 E002-01/ /	001-099
D41189J	1	2431-74-16 RCPT-COAX		1	34-45-02 E2-1/ /	115-199
D41189P	1	2435-77-16 PLUG-COAX		1	34-45-02 E2-1/ /	ALL
D41191J	1	2431-74-1 RCPT-COAX		1	34-45-02 E002-01/ /	001-099
D41191J	1	2431-74-1 RCPT-COAX		1	34-45-02 E2-1/ /	115-199
D41191P	1	2435-74-1 PLUG-COAX		1	34-45-02 E002-01/ /	ALL
D41192J	1	CN0967C22G19P6-000 RCPT-	81205	1	27-51-61 AW1333/ /	001-004, 115-199
D41192J	1	BACC63CC22-19P6 RCPT-	81205	1	27-51-61 AW1333/ /	005-099
D41192JK		BACC10HF22C CABLE CLAMP-	81205	1	27-51-61 AW1333/ /	ALL
D41192P	1	CN0966A22G19S6-000 PLUG-	13556	1	28-41-21 AW1333/ /	001-004, 115-199
D41192P	1	BACC63CB22-19S6 PLUG-	13556	1	28-41-21 AW1333/ /	005-099
D41192PQ		BACC10HF22C CABLE CLAMP-	81205	1	28-41-21 */ */	ALL
D41193J	1	2431-74-6 RCPT-COAX		1	34-45-02 E002-01/ /	001-099
D41193J	1	2431-74-6 RCPT-COAX		1	34-45-02 E2-1/ /	115-199
D41193P	1	2435-74-6 PLUG-COAX		1	34-45-02 E002-01/ /	ALL
D41195J	1	2431-74-11 RCPT-COAX		1	34-45-02 E002-01/ /	001-099
D41195J	1	2431-74-11 RCPT-COAX		1	34-45-02 E2-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D41100

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41195P	1	2435-74-11 PLUG-COAX		1	34-45-02 E002-01/ /	ALL
D41196J	1	CN0967C22G19P6-000 RCPT	13556	1	28-41-31 AW2333/ /	115-199
D41196JK		BACC10HF22C CABLE CLAMP	81205	1	28-41-31 AW2333/ /	115-199
D41196P	1	CN0966A22G19S6-000 PLUG-	13556	1	28-41-31 AW2333/ /	115-199
D41196PQ		BACC10HF22C CABLE CLAMP	81205	1	28-41-31 */ */	115-199
D41197J	1	2431-74-16 RCPT-COAX		1	34-45-02 E002-01/ /	001-099
D41197J	1	2431-74-16 RCPT-COAX		1	34-45-02 E2-1/ /	115-199
D41197P	1	2435-74-16 PLUG-COAX		1	34-45-02 E002-01/ /	ALL
D41198J	1	CN0967C18G31P7-000 RCPT-	13556	1	27-51-61 880/ /	001-004
D41198J	1	BACC63CC18-31P7 RCPT-	81205	1	27-51-61 880/ /	005-099
D41198J	1	CN0967C18G31P7-000 RCPT	13556	1	28-41-41 880/ /	115-199
D41198JK		BACC10HF18C CABLE CLAMP	81205	1	27-51-61 */ */	001-099
D41198JK	1	BACC10HF18C CABLE CLAMP	81205	1	28-41-41 */ */	115-199
D41198P	1	CN0966A18G31S7-000 PLUG-	13556	1	28-41-31 AD0880/ /	001-004, 115-199
D41198P	1	BACC63CB18-31S7 PLUG-	81205	1	28-41-31 AD0880/ /	005-099
D41198PQ		BACC10HF18C CABLE CLAMP	81205	1	28-41-31 */ /	ALL
D41199J	1	KA-19-143 RCPT-COAX		1	34-45-02 E002-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41100

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41199J	1	KA-19-143 RCPT-COAX		1	34-45-02 E2-1/ /	115-199
D41199P	1	KA-59-277 PLUG-COAX		1	34-45-02 E002-01/ /	ALL

EQUIPMENT LIST

D280N032

Section D41100

Page 9 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41200J	9	BACC45FN22-55S8 CONNECTOR (S/B: 757-34-0200)	81205	1	34-43-25 E002-02/ /	002
D41200P	9	BACC45FT22-55P8 PLUG-CONDUCTIVE (B/S 757-34-0200)	81205	1	34-25-12 E002-03/ /	002
D41203J	1	KA-19-143 JACK-COAX	91836	1	34-45-02 E003-02/ /	001-099
D41203J	1	KA-19-143 JACK-COAX	91836	1	34-45-02 E3-2/ /	115-199
D41203P	1	KA-59-277 PLUG-COAX		1	34-45-02 E003-02/ /	ALL
D41208J	1	CN0967C18G14S7-000 RCPT	13556	1	36-11-11 AC0880/ /	001-004, 115-199
D41208J	1	BACC63CC18-14S7 RCPT	13556	1	36-11-11 AC0880/ /	005-099
D41208JK		BACC10HF18C CABLE CLAMP	81205	1	36-11-11 */*/	ALL
D41208P	1	CN0966A18G14P7-000 PLUG	13556	1	36-11-11 AC0880/ /	001-004, 115-199
D41208P	1	BACC63CB18-14P7 PLUG	13556	1	36-11-11 AC0880/ /	005-099
D41208PQ		BACC10HF18C CABLE CLAMP	81205	1	36-11-11 */*/	ALL
D41210J	1	CN0967C18G14S9-000 RCPT	13556	1	36-11-22 880/190/R055	001-004
D41210J	1	BACC63CC18-14S9 RCPT	13556	1	36-11-22 880/190/R055	005-099
D41210J	1	CN0967C18G14S9-000 RCPT	13556	1	36-11-22 880/190/R55	115-199
D41210JK		G8993M18NF CABLE CLAMP	06324	1	36-11-22 */*/	001-004
D41210JK		BACC10HF18C CABLE CLAMP	81205	1	36-11-22 */*/	005-099, 115-199
D41210P	1	CN0966A18G14P9-000 PLUG	13556	1	26-12-21 AD0880/ /	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D41200

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41210P	1	BACC63CB18-14P9 PLUG	13556	1	26-12-21 AD0880/ /	005-099
D41210PQ		BACC10HF18C CABLE CLAMP	81205	1	26-12-21 */*/	ALL
D41220J	1	BACC45FN10A5S9 RCPT	81205	1	23-51-16 E4-3/ /	115-199
D41220P	1	BACC63BN10-5P9 PLUG	81205	1	23-51-16 E4-3/ /	115-199
D41220PQ		BACC10GH10 CABLE CLAMP-	81205	1	23-51-16 E4-3/ /	115-199
D41225J	1	BACC45FN10-5P6 RCPT-ALT STAB TRIM	81205	1	27-41-31 1650/194/R54	ALL
D41225P	1	BACC45FT10A5S6 PLUG-ALT STAB TRIM	81205	1	27-41-31 1650/104/R54	ALL
D41227J	1	BACC45FN10-5P8 RCPT-ALT STAB TRIM	81205	1	27-41-31 1650/192/R54	ALL
D41227P	1	BACC45FT10A5S8 PLUG-ALT STAB TRIM	81205	1	27-41-31 1640/104/R 54	001-099
D41227P	1	BACC45FT10A5S8 PLUG-ALT STAB TRIM	81205	1	27-41-31 1640/104/R54	115-199
D41238J	9	BACC45FN22-55S RCPT-	81205	1	34-43-15 E002-01/ /	002
D41238P	1	BACC45FT22-55P PLUG-	81205	1	34-43-11 E002-01/ /	002
D41248J	1	BACC45FN12-12S7 RCPT-	81205	1	76-11-11 P36/ /	ALL
D41248P	1	BACC45FT12A12P7 PLUG	81205	1	76-11-11 P036-00/ /	ALL
D41250J	1	BACC45FN18-14S RCPT	81205	1	26-15-11 1610/183/L053	001-099
D41250P	1	BACC45FT18A14P PLUG	81205	1	26-15-11 1610/183/L053	001-099
D41254J	1	BACC45FN10-5S RCPT	81205	1	26-15-11 1590/201/L065	001-099

EQUIPMENT LIST

D280N032

Section D41200

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41254P	1	BACC45FT10A5P PLUG	81205	1	26-15-11 1590/201/R065	001-099
D41256J	1	BACC45FN12A12S RECP	81205	1	26-16-21 615/203/R14	001-099
D41256P	1	BACC45FT12A12P RECP	81205	1	26-16-21 615/203/R14	001-099
D41258J	1	BACC45FN12-12S7 RCPT-	81205	1	76-11-12 P37/ /	ALL
D41258P	1	BACC45FT12A12P7 PLUG	81205	1	76-11-12 P037-00/ /	ALL
D41262J	1	BACC45FN12A12S RECP	81205	1	26-16-21 1353/174/R52	001-099
D41262P	1	BACC45FT12D12P PLUG	81205	1	26-16-21 1353/174/R52	001-099
D41264J	1	BACC45FN14B15S RECP	81205	1	26-16-11 635/293/R017	001-099
D41264P	1	BACC45FT14A15P PLUG	81205	1	26-16-11 635/293/R17	001-099
D41266J	1	BACC45FN14A15S RECP	81205	1	26-16-11 1352/195/R053	001-099
D41266P	1	BACC45FT14D15P PLUG	81205	1	26-16-11 1352/195/R053	001-099
D41268J	1	BACC63CC18-31SN RCPT.	81205	1	28-41-21 E003-04/ /	001-099
D41268P	1	BACC63CB18-31PN PLUG	81205	1	28-41-21 E3-4/ /	001-099
D41268PQ		BACC10HF18C CABLE CLAMP	81205	1	28-41-21 E3-4/ /	001-099
D41270J	1	BACC63CC20-39S7 RCPT.	81205	1	28-41-31 E003-04/ /	001-099
D41270P	1	BACC63CB20-39P7 PLUG	81205	1	28-41-31 E3-4/ /	001-002
D41270P	1	BACC63CB20-39P7 PLUG	81205	1	28-41-31 E003-04/ /	003-099

EQUIPMENT LIST

D280N032

Section D41200

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41270PQ		BACC10HF20C CABLE CLAMP	81205	1	28-41-31 E3-4/ /	001-002
D41270PQ		BACC10HF20C CABLE CLAMP	81205	1	28-41-31 E003-04/ /	003-099
D41272J	9	BACC45FN14-15S8 RCPT (MR69018-002)	81205	1	28-41-21 E3-4/ /	115-199
D41272J	1	BACC45FN14-15S8 RCPT.	81205	1	28-41-21 E003-04/ /	001-099
D41272P	1	BACC45FT14A15P8 PLUG	81205	1	28-41-21 E3-4/ /	ALL
D41276J	9	BACC45FN16-24S8 RCPT (MR69018-002)	81205	1	28-41-31 E3-4/ /	115-199
D41276J	1	BACC45FN16-24S8 RCPT.	81205	1	28-41-31 E003-04/ /	001-099
D41276P	1	BACC45FT16A24P8 PLUG	81205	1	28-41-31 E003-04/ /	ALL
D41280J	1	BACC45FN12-12P RCPT	81205	1	33-11-21 260/263/L023	001-099
D41280P	1	BACC45FT12A12S PLUG	81205	1	33-11-21 260/263/L023	001-099
D41282J	1	BACC45FN12-12P RCPT	81205	1	33-11-21 263/264/R020	001-099
D41282P	1	BACC45FT12A12S PLUG	81205	1	33-11-21 263/264/R020	001-099
D41284J	1	48-7191-1 RCPT-	02660	1	33-24-12 645/280/L60	001-099
D41286P	1	48-7190 PLUG-	02660	1	33-24-12 645/280/L60	001-099
D41288J	1	48-7191 RCPT-	02660	1	33-24-12 645/280/L60	001-099
D41292J	1	48-7191-1 RCPT-	02660	1	33-24-12 745/270/L50	001-099
D41292P	1	48-7190-1 PLUG-	02660	1	33-24-12 745/270/L050	001-099

EQUIPMENT LIST

D280N032

Section D41200

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41294J	1	48-7191 RCPT-	02660	1	33-24-12 745/270/L050	001-099
D41294P	1	48-7190 PLUG-	02660	1	33-24-12 745/270/L50	001-099
D41296J	1	48-7191 RCPT-	02660	1	33-24-12 745/270/L50	001-099
D41296P	1	48-7190 PLUG-	02660	1	33-24-12 745/270/L050	001-099

EQUIPMENT LIST

D280N032

Section D41200
Page 5 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41301J	1	BACC45FN22-55S9 RCPT	81205	1	22-22-11 E003-01/ /	ALL
D41301P	1	BACC45FT22A55P9 PLUG-	81205	1	27-32-11 E003-01/ /	001-099
D41301P	1	BACC45FT22A55P9 PLUG-	81205	1	27-32-11 E3-1/ /	115-199
D41302J	1	BACC45FN18-31P RCPT	81205	1	38-14-11 P37/ /	001-099
D41302J	1	BACC45FN20-39P6 RCPT	81205	1	38-14-11 P37/ /	115-199
D41302P	1	BACC45FT18-31S PLUG-	81205	1	38-32-21 P37/ /	001-099
D41302P	1	BACC45FT20-39S6 PLUG-	81205	1	38-32-21 P37/ /	115-199
D41303J	1	BACC45FN22-55S7 RCPT-	81205	1	31-31-13 E003-02/ /	001-099
D41303J	1	BACC45FN22-55S7 RCPT-	81205	1	31-31-13 E3-2/ /	115-199
D41303P	1	BACC45FT22A55P7 PLUG-	81205	1	34-53-21 E003-02/ /	001-099
D41303P	1	BACC45FT22A55P7 PLUG-	81205	1	34-53-21 E3-2/ /	115-199
D41307J	1	BACC45FN22-55S9 RCPT-	81205	1	31-31-43 E3-3/ /	001-099
D41307J	1	BACC45FN22-55S9 RCPT-	81205	1	34-53-11 E3-3/ /	115-199
D41307P	1	BACC45FT22A55P9 PLUG-	81205	1	31-31-12 E003-03/ /	001-099
D41307P	1	BACC45FT22A55P9 PLUG-	81205	1	31-31-12 E3-3/ /	115-199
D41309J	1	BACC45FN22-55S8 RCPT-	81205	1	31-31-61 E3-3/ /	001-099
D41309J	1	BACC45FN22-55S8 RCPT-	81205	1	31-31-12 E3-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41300

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41309P	1	BACC45FT22A55P8 PLUG-	81205	1	34-22-19 E003-03/ /	001-099
D41309P	1	BACC45FT22A55P8 PLUG-	81205	1	34-22-19 E3-3/ /	115-199
D41311J	1	BACC45FN18-31S7 RCPT	81205	1	34-61-14 E003-04/ /	001-099
D41311J	1	BACC45FN22-55S6 RCPT	81205	1	34-61-14 E003-04/ /	115-199
D41311P	1	BACC45FT18A31P7 PLUG-	81205	1	34-61-14 E003-04/ /	001-099
D41311P	1	BACC45FT22A55P6 PLUG-	81205	1	34-61-14 E3-4/ /	115-199
D41316J	1	BACC45FN22-32S9 RCPT	81205	1	24-21-21 P032-00/ /	ALL
D41316P	1	BACC45FT22-32P9 PLUG-	81205	1	24-22-12 P032-00/ /	ALL
D41317J	1	BACC45FN22-55S7 RCPT-	81205	1	34-61-15 E4-2/ /	ALL
D41317P	1	BACC45FT22A55P7 PLUG-	81205	1	34-61-15 E004-02/ /	001-099
D41317P	1	BACC45FT22A55P7 PLUG-	81205	1	34-61-15 E4-2/ /	115-199
D41318J	1	BACC45FN18-31S RCPT	81205	1	24-51-71 P031-00/ /	ALL
D41318P	1	BACC45FT18-31P PLUG-	81205	1	24-22-22 P031-00/ /	ALL
D41319J	1	BACC45FN22-55S6 RCPT-	81205	1	23-51-11 E004-03/ /	001-099
D41319J	1	BACC45FN22-55S6 RCPT-	81205	1	23-51-11 E4-3/ /	115-199
D41319P	1	BACC45FT22A55P6 PLUG-	81205	1	31-31-13 E004-03/ /	001-099
D41319P	1	BACC45FT22A55P6 PLUG-	81205	1	31-31-13 E4-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41300

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41320J	1	BACC45FN14-15P RCPT	81205	1	24-51-31 P032-00/ /	001-099
D41320J	1	BACC45FN12-12P RCPT	81205	1	24-51-31 P032-00/ /	115-199
D41320P	1	BACC45FT14-15S PLUG-	81205	1	24-51-31 P032-00/ /	001-099
D41320P	1	BACC45FT12-12S PLUG-	81205	1	24-51-31 P032-00/ /	115-199
D41325J	1	BACC45FN22-55S7 RCPT	81205	1	27-51-21 E5-1/ /	ALL
D41325P	1	BACC45FT22A55P7 PLUG-	81205	1	34-22-19 E005-01/ /	001-099
D41325P	1	BACC45FT22A55P7 PLUG-	81205	1	34-22-19 E5-1/ /	115-199
D41326J	1	BACC45FN22-32S6 RCPT-	81205	1	24-21-41 P034-00/ /	001-099
D41326J	1	BACC45FN22-32S6 RCPT-	81205	1	24-21-41 P34/ /	115-199
D41326P	1	BACC45FT22A32P6 PLUG-	81205	1	24-22-21 P034-00/ /	ALL
D41327J	1	BACC45FN16-24S9 RCPT	81205	1	21-31-21 E5-2/ /	ALL
D41327P	1	BACC45FT16A24P9 PLUG-	81205	1	31-31-21 E005-02/ /	001-099
D41327P	1	BACC45FT16A24P9 PLUG-	81205	1	31-31-21 E5-2/ /	115-199
D41328J	1	BACC45FN14-15P6 RCPT-	81205	1	34-22-26 E002-02/ /	001-099
D41328J	1	BACC45FN14-15P6 RCPT-	81205	1	34-22-26 E2-2/ /	115-199
D41328P	1	BACC45FT14-15S6 PLUG-	81205	1	22-11-21 E2-2/ /	ALL
D41329J	1	BACC45FN22-55S8 RCPT	81205	1	27-51-61 E005-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D41300

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41329J	1	BACC45FN22-55S8 RCPT	81205	1	27-51-61 E5-3/ /	115-199
D41329P	1	BACC45FT22A55P8 PLUG-	81205	1	21-31-11 E005-03/ /	001-099
D41329P	1	BACC45FT22A55P8 PLUG-	81205	1	21-31-11 E5-3/ /	115-199
D41335J	1	BACC45FN10-5P9 RCPT-ALT STAB TRIM	81205	1	27-41-31 1650/191/R54	ALL
D41335P	1	BACC45FT10A5S9 PLUG-ALT STAB TRIM	81205	1	27-41-31 1640/104/R54	ALL
D41337J	1	BACC45FN10-5P7 RCPT-ALT STAB TRIM	81205	1	27-41-31 1650/193/R54	ALL
D41337P	1	BACC45FT10A5S7 PLUG-ALT STAB TRIM	81205	1	27-41-31 1650/104/R54	ALL
D41339J	1	BACC45FN22-55S8 RCPT-	81205	1	34-61-15 E002-01/ /	001-099
D41339J	1	BACC45FN22-55S8 RCPT-	81205	1	34-61-15 E2-1/ /	115-199
D41339P	1	BACC45FT22A55P8 PLUG-	81205	1	34-61-15 E002-01/ /	001-099
D41339P	1	BACC45FT22A55P8 PLUG-	81205	1	34-61-15 E2-1/ /	115-199
D41345J	1	BACC45FN22-55S9 RCPT-	81205	1	34-22-29 E002-02/ /	001-099
D41345J	1	BACC45FN22-55S9 RCPT-	81205	1	34-22-29 E2-2/ /	115-199
D41345P	1	BACC45FT22A55P9 PLUG-	81205	1	31-41-22 E002-02/ /	001-099
D41345P	1	BACC45FT22A55P9 PLUG-	81205	1	31-41-22 E2-2/ /	115-199
D41347J	1	BACC45FN22-55S7 RCPT-	81205	1	22-12-21 E002-02/ /	001-099
D41347J	1	BACC45FN22-55S7 RCPT-	81205	1	22-12-21 E2-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D41300

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41347P	1	BACC45FT22A55P7 PLUG-	81205	1	22-12-21 E002-02/ /	001-099
D41347P	1	BACC45FT22A55P7 PLUG-	81205	1	22-12-21 E2-2/ /	115-199
D41348J	1	48-7191-1 RCPT-	02660	1	33-24-21 675/270/R50	001-099
D41349J	1	BACC45FN22-55S8 RCPT-	81205	1	22-32-12 E002-03/ /	001-099
D41349J	1	BACC45FN22-55S8 RCPT-	81205	1	22-32-12 E2-3/ /	115-199
D41349P	1	BACC45FT22A55P8 PLUG-	81205	1	22-32-12 E002-03/ /	001-099
D41349P	1	BACC45FT22A55P8 PLUG-	81205	1	22-32-12 E2-3/ /	115-199
D41350P	1	48-7190 PLUG-	02660	1	33-24-21 675/270/R50	001-099
D41351J	1	BACC45FN22-55S7 RCPT	81205	1	22-21-22 E002-04/ /	001-099
D41351J	1	BACC45FN22-55S7 RCPT	81205	1	22-21-22 E2-4/ /	115-199
D41351P	1	BACC45FT22A55P7 PLUG-	81205	1	22-21-21 E002-04/ /	001-099
D41351P	1	BACC45FT22A55P7 PLUG-	81205	1	22-21-21 E2-4/ /	115-199
D41352J	1	48-7191 RCPT-	02660	1	33-24-21 675/270/R50	001-099
D41353J	1	BACC45FN12-12S RCPT	81205	1	22-24-11 E003-01/ /	001-099
D41353J	1	BACC45FN18-31S RCPT	81205	1	22-24-11 E003-01/ /	115-199
D41353P	1	BACC45FT12A12P PLUG	81205	1	22-21-11 E003-01/ /	001-099
D41353P	1	BACC45FT18A31P PLUG	81205	1	22-21-11 E3-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D41300

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41354J	1	CN0967C22G55S6-000 RCPT	13556	1	80-11-11 AC0880/190/	001-004, 115-199
D41354J	1	BACC63CC22-55S6 RCPT	13556	1	80-11-11 AC0880/190/	005-099
D41354JK		BACC10HF22C CABLE CLAMP	81205	1	80-11-11 */*/	ALL
D41354P	1	CN0966A22G55P6-000 PLUG	13556	1	80-11-11 AC0880/ /	001-004, 115-199
D41354P	1	BACC63CB22-55P6 PLUG	13556	1	80-11-11 AC0880/ /	005-099
D41354PQ		BACC10HF22C CABLE CLAMP	81205	1	80-11-11 */*/	ALL
D41355J	1	BACC45FN22-55S9 RCPT-	81205	1	34-55-21 E003-02/ /	001-099
D41355J	1	BACC45FN22-55S9 RCPT-	81205	1	34-55-21 E3-2/ /	115-199
D41355P	1	BACC45FT22A55P9 PLUG-	81205	1	34-61-13 E003-02/ /	001-099
D41355P	1	BACC45FT22A55P9 PLUG-	81205	1	34-61-13 E3-2/ /	115-199
D41358J	1	CN0967C22G55S6-000 RCPT	13556	1	77-22-13 AD0880/ /	001-004, 115-199
D41358J	1	BACC63CC22-55S6 RCPT	13556	1	77-22-13 AD0880/ /	005-099
D41358JK		BACC10HF22C CABLE CLAMP	81205	1	77-22-13 */ /	ALL
D41358P	1	CN0966A22G55P6-000 PLUG	13556	1	80-11-21 AD0880/ /	001-004, 115-199
D41358P	1	BACC63CB22-55P6 PLUG	13556	1	80-11-21 AD0880/ /	005-099
D41358PQ		BACC10HF22C CABLE CLAMP	81205	1	80-11-21 */*/	ALL
D41361J	1	BACC45FN22-55S9 RCPT-	81205	1	34-53-11 E3-3/ /	ALL

EQUIPMENT LIST

D280N032

Section D41300

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41361P	1	BACC45FT22A55P9 PLUG-	81205	1	34-53-11 E003-03/ /	001-099
D41361P	1	BACC45FT22A55P9 PLUG-	81205	1	34-53-11 E3-3/ /	115-199
D41363J	1	BACC45FN18-31S9 RCPT	81205	1	34-61-24 E003-04/ /	001-099
D41363J	1	BACC45FN22-55S9 RCPT	81205	1	34-61-24 E003-04/ /	115-199
D41363P	1	BACC45FT18A31P9 PLUG-	81205	1	34-61-24 E003-04/ /	001-099
D41363P	1	BACC45FT22A55P9 PLUG-	81205	1	34-61-24 E3-4/ /	115-199
D41367J	1	BACC45FN22-55S RCPT	81205	1	22-21-21 E004-01/ /	001-099
D41367J	1	BACC45FN22-55S RCPT	81205	1	22-21-21 E4-1/ /	115-199
D41367P	1	BACC45FT22A55P PLUG-	81205	1	31-51-41 E004-01/ /	001-099
D41367P	1	BACC45FT22A55P PLUG-	81205	1	31-51-41 E4-1/ /	115-199
D41369J	1	BACC45FN20-41S7 RCPT-	81205	1	34-21-21 E4-2/ /	001-099
D41369J	1	BACC45FN22-55S7 RCPT-	81205	1	34-21-21 E4-2/ /	115-199
D41369P	1	BACC45FT20A41P7 PLUG-	81205	1	34-21-21 E004-02/ /	001-099
D41369P	1	BACC45FT22A55P7 PLUG-	81205	1	34-21-21 E4-2/ /	115-199
D41371J	1	BACC45FN22-55S RCPT-	81205	1	23-51-11 E004-03/ /	001-099
D41371J	1	BACC45FN22-55S RCPT-	81205	1	23-51-11 E4-3/ /	115-199
D41371P	1	BACC45FT22A55P PLUG-	81205	1	23-22-11 E004-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D41300

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41371P	1	BACC45FT22A55P PLUG-	81205	1	23-22-11 E4-3/ /	115-199
D41377J	1	BACC45FN22-55S8 RCPT	81205	1	27-51-51 E5-1/ /	ALL
D41377P	1	BACC45FT22A55P8 PLUG-	81205	1	27-32-11 E005-01/ /	001-099
D41377P	1	BACC45FT22A55P8 PLUG-	81205	1	27-32-11 E5-1/ /	115-199
D41379J	1	BACC45FN22-55S9 RCPT	81205	1	27-58-31 E5-2/ /	ALL
D41379P	1	BACC45FT22A55P9 PLUG-	81205	1	34-22-29 E005-02/ /	001-099
D41379P	1	BACC45FT22A55P9 PLUG-	81205	1	34-22-29 E5-2/ /	115-199
D41380J	1	BACC45FN16-24P7 RCPT	81205	1	26-18-11 P50/ /	ALL
D41380P	1	BACC45FT16-24S7 PLUG	81205	1	26-15-11 P050-00/ /	001-099
D41380P	1	BACC45FT16-24S7 PLUG	81205	1	26-15-11 P50/ /	115-199
D41381J	1	BACC45FN22-55S6 RCPT	81205	1	27-58-31 E005-03/ /	001-099
D41381J	1	BACC45FN22-55S6 RCPT	81205	1	27-58-31 E5-3/ /	115-199
D41381P	1	BACC45FT22A55P6 PLUG-	81205	1	24-22-41 E005-03/ /	001-099
D41381P	1	BACC45FT22A55P6 PLUG-	81205	1	24-22-41 E5-3/ /	115-199
D41390J		BACC45FN14-15S PLUG	81205	1	24-25-12 P71/ /	003-099
D41390P		BACC45FT14B15P RCPT	81205	1	24-25-12 P71/ /	003-099
D41391J	1	BACC45FN22-55S7 RCPT-	81205	1	34-22-38 E002-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41300

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41391J	1	BACC45FN22-55S7 RCPT-	81205	1	34-22-38 E2-1/ /	115-199
D41391P	1	BACC45FT22A55P7 PLUG-	81205	1	34-22-38 E002-01/ /	ALL
D41392J	1	CN0967C18G14P9-000 RCPT-	81205	1	33-43-11 AW1333/ /	001-004, 115-199
D41392J	1	BACC63CC18-14P9 RCPT-	81205	1	33-43-11 AW1333/ /	005-099
D41392JK		BACC10HF18C CABLE CLAMP-	81205	1	33-43-11 AW1333/ /	ALL
D41392P	1	CN0966A18G14S9-000 PLUG-	13556	1	28-41-21 AW1333/ /	001-004, 115-199
D41392P	1	BACC63CB18-14S9 PLUG-	13556	1	28-41-21 AW1333/ /	005-099
D41392PQ		BACC10HF18C CABLE CLAMP	81205	1	28-41-21 */ /*	ALL
D41393J	1	BACC45FN20-41S9 RCPT-	81205	1	22-15-11 E002-02/ /	001-099
D41393J	1	BACC45FN22-55S9 RCPT-	81205	1	22-15-11 E2-2/ /	115-199
D41393P	1	BACC45FT20A41P9 PLUG-	81205	1	34-22-28 E002-02/ /	001-099
D41393P	1	BACC45FT22A55P9 PLUG-	81205	1	34-22-28 E002-02/ /	115-199
D41394J	1	CN0967C20G39S6-000 RCPT-	13556	1	27-51-61 AC0880/ /	001-004, 115-199
D41394J	1	BACC63CC20-39S6 RCPT-	81205	1	27-51-61 AC0880/ /	005-099
D41394JK		BACC10HF20C CABLE CLAMP	81205	1	27-51-61 */ /*	ALL
D41394P	1	CN0966A20G39P6-000 PLUG-	13556	1	28-41-21 AC0880/ /	001-004, 115-199
D41394P	1	BACC63CB20-39P6 PLUG-	13556	1	28-41-21 AC0880/ /	005-099

EQUIPMENT LIST

D280N032

Section D41300

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41394PQ		BACC10HF20C CABLE CLAMP-	81205	1	28-41-21 */ */	ALL
D41395J	1	BACC45FN22-55S RCPT-	81205	1	34-22-34 E002-03/ /	001-099
D41395J	1	BACC45FN22-55S RCPT-	81205	1	34-22-34 E2-3/ /	115-199
D41395P	1	BACC45FT22A55P PLUG-	81205	1	34-22-33 E002-03/ /	ALL
D41396J	1	CN0967C18G14P9-000 RCPT	13556	1	33-43-12 FSS333/ /	001-004, 115-199
D41396J	1	BACC63CC18-14P9 RCPT	81205	1	33-43-12 FSS333/ /	005-099
D41396JK		BACC10HF18C CABLE CLAMP-	81205	1	33-43-12 */ /	ALL
D41396P	1	CN0966A18G14S9-000 PLUG-	13556	1	33-43-11 AW2333/ /	001-004, 115-199
D41396P	1	BACC63CB18-14S9 PLUG-	81205	1	33-43-11 AW2333/ /	005-099
D41396PQ		BACC10HF18C CABLE CLAMP	81205	1	33-43-11 */ /	ALL
D41397J	1	BACC45FN18-31S6 RCPT	81205	1	22-21-11 E002-04/ /	001-099
D41397J	1	BACC45FN22-55S6 RCPT	81205	1	22-21-11 E2-4/ /	115-199
D41397P	1	BACC45FT18A31P6 PLUG-	81205	1	34-22-28 E002-04/ /	001-099
D41397P	1	BACC45FT22A55P6 PLUG-	81205	1	34-22-28 E002-04/ /	115-199
D41399J	1	BACC45FN18-31S8 RCPT	81205	1	22-22-11 E003-01/ /	001-099
D41399J	1	BACC45FN22-55S8 RCPT	81205	1	22-22-11 E003-01/ /	115-199
D41399P	1	BACC45FT18A31P8 PLUG-	81205	1	22-21-11 E003-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41300

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41399P	1	BACC45FT22A55P8 PLUG-	81205	1	22-21-11 E003-01/ /	115-199

EQUIPMENT LIST

D280N032

Section D41300
Page 11 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41401J	1	BACC45FN12-12S RCPT-	81205	1	22-41-11 E003-02/ /	001-099
D41401J	1	BACC45FN16-24S RCPT-	81205	1	22-41-11 E3-2/ /	115-199
D41401P	1	BACC45FT12A12P PLUG-	81205	1	22-41-11 E003-02/ /	001-099
D41401P	1	BACC45FT16A24P PLUG-	81205	1	22-41-11 E003-02/ /	115-199
D41403J	1	BACC45FN16-24S7 RCPT-	81205	1	31-31-42 E3-3/ /	001-099
D41403J	1	BACC45FN16-24S7 RCPT-	81205	1	34-53-11 E3-3/ /	115-199
D41403P	1	BACC45FT16A24P7 PLUG-	81205	1	31-31-42 E003-03/ /	001-099
D41403P	1	BACC45FT16A24P7 PLUG-	81205	1	31-31-12 E003-03/ /	115-199
D41406J	1	CN0967C18G11S9-000 RCPT	13556	1	28-22-31 AC1090/ /	001-004, 115-199
D41406J	1	BACC63CC18-11S9 RCPT	81205	1	28-22-31 AC1090/ /	005-099
D41406JK		BACC10HF18C CABLE CLAMP	81205	1	28-22-31 */ */	001-099
D41406JK		BACC10HF18C CABLE CLAMP	81205	1	28-22-31 AC1090/ /	115-199
D41406P	1	CN0966A18G11P9-000 PLUG	81205	1	26-17-11 AC1090/ /	001-004, 115-199
D41406P	1	BACC63CB18-11P9 PLUG	81205	1	26-17-11 AC1090/ /	005-099
D41406PQ		BACC10HF18C CABLE CLAMP	81205	1	26-17-11 AC1090/ /	ALL
D41408J	1	BACC45FN24-43P6 RCPT	81205	1	33-24-11 P37/ /	ALL
D41408P	1	BACC45FT24-43S6 PLUG-	81205	1	38-15-11 P037-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D41400

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41408P	1	BACC45FT24-43S6 PLUG-	81205	1	38-15-11 P37/ /	115-199
D41409J	1	BACC45FN12-12S RCPT-	81205	1	34-33-31 E4-2/ /	001-099
D41409J	1	BACC45FN22-55S RCPT-	81205	1	34-33-31 E4-2/ /	115-199
D41409P	1	BACC45FT12A12P PLUG-	81205	1	34-21-31 E004-02/ /	001-099
D41409P	1	BACC45FT22A55P PLUG-	81205	1	34-21-31 E004-02/ /	115-199
D41410J	1	BACC45FN20-39P RCPT	81205	1	28-22-21 P33/ /	001-099
D41410J	1	BACC45FN18-31P RCPT	81205	1	28-22-11 P33/ /	115-199
D41410P	1	BACC45FT20-39S PLUG	81205	1	33-42-11 AP0033/ /	001-099
D41410P	1	BACC45FT18-31S PLUG	81205	1	33-42-11 P33/ /	115-199
D41412J	1	BACC45FN22-55P6 RCPT	81205	1	29-11-12 P33/ /	001-099
D41412J	1	BACC45FN18-31P8 RCPT	81205	1	29-11-12 P33/ /	115-199
D41412P	1	BACC45FT22-55S6 PLUG	81205	1	33-42-11 P033-00/ /	001-099
D41412P	1	BACC45FT18-31S8 PLUG	81205	1	33-42-11 P033-00/ /	115-199
D41414J	1	BACC45FN22-55P9 RCPT	81205	1	28-22-31 P33/ /	ALL
D41414P	1	BACC45FT22-55S9 PLUG	81205	1	33-22-11 P033-00/ /	001-099
D41414P	1	BACC45FT22-55S9 PLUG	81205	1	33-22-11 P33/ /	115-199
D41416J	1	BACC45FN22-19P7 RCPT	81205	1	29-11-12 P33/ /	ALL

EQUIPMENT LIST

D280N032

Section D41400

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41416P	1	BACC45FT22-19S7 PLUG-	81205	1	28-22-11 P033-00/ /	001-099
D41416P	1	BACC45FT22-19S7 PLUG-	81205	1	29-11-12 P033-00/ /	115-199
D41418J	1	BACC45FN22-12P6 RCPT	81205	1	29-11-12 P33/ /	ALL
D41418P	1	BACC45FT22-12S6 PLUG-	81205	1	27-51-11 P033-00/ /	ALL
D41419J	1	BACC45FN22-55S9 RCPT	81205	1	34-22-33 E005-03/ /	001-099
D41419J	1	BACC45FN22-55S9 RCPT	81205	1	34-22-33 E5-3/ /	115-199
D41419P	1	BACC45FT22A55P9 PLUG-	81205	1	34-22-33 E005-03/ /	ALL
D41420J	1	BACC45FN14-15P9 RCPT	81205	1	28-21-11 P33/ /	ALL
D41420P	1	BACC45FT14-15S9 PLUG-	81205	1	28-21-11 P033-00/ /	ALL
D41422J	1	BACC45FN18-14P8 RCPT	81205	1	28-21-11 P33/ /	ALL
D41422P	1	BACC45FT18-14S8 PLUG-	81205	1	28-22-11 P033-00/ /	001-099
D41422P	1	BACC45FT18-14S8 PLUG-	81205	1	28-22-11 P33/ /	115-199
D41424J	1	BACC45FN22-32P RCPT	81205	1	29-11-12 P33/ /	ALL
D41424P	1	BACC45FT22-32S PLUG-	81205	1	27-51-21 P033-00/ /	001-099
D41424P	1	BACC45FT22-32S PLUG-	81205	1	27-51-21 P33/ /	115-199
D41426J	1	BACC45FN18-8P6 RCPT	81205	1	26-15-12 P33/ /	001-099
D41426J	1	BACC45FN16-24P6 RCPT	81205	1	26-15-12 P33/ /	115-199

EQUIPMENT LIST

D280N032

Section D41400

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41426P	1	BACC45FT18-8S6 PLUG-	81205	1	28-22-21 P33/ /	001-099
D41426P	1	BACC45FT16-24S6 PLUG-	81205	1	28-22-21 P33/ /	115-199
D41429J	1	BACC45FN22-55S8 RCPT-	81205	1	34-46-11 E002-01/ /	001-099
D41429J	1	BACC45FN22-55S8 RCPT-	81205	1	34-46-11 E2-1/ /	115-199
D41429P	1	BACC45FT22A55P8 PLUG-	81205	1	34-46-11 E002-01/ /	001-099
D41429P	1	BACC45FT22A55P8 PLUG-	81205	1	34-46-11 E2-1/ /	115-199
D41431J	1	BACC45FN14-15S8 RCPT-	81205	1	23-22-12 E002-02/ /	001-099
D41431J	1	BACC45FN22-55S8 RCPT-	81205	1	23-22-12 E2-2/ /	115-199
D41431P	1	BACC45FT14A15P8 PLUG-	81205	1	23-22-12 E002-02/ /	001-099
D41431P	1	BACC45FT22A55P8 PLUG-	81205	1	23-22-12 E2-2/ /	115-199
D41433J	1	BACC45FN22-55S9 RCPT-	81205	1	34-46-11 E002-03/ /	001-099
D41433J	1	BACC45FN22-55S9 RCPT-	81205	1	34-46-11 E2-3/ /	115-199
D41433P	1	BACC45FT22A55P9 PLUG-	81205	1	34-46-11 E002-03/ /	001-099
D41433P	1	BACC45FT22A55P9 PLUG-	81205	1	34-46-11 E2-3/ /	115-199
D41434J	1	48-7191-1 RCPT-	02660	1	33-24-21 745/270/R50	001-099
D41436P	1	48-7190 PLUG-	02660	1	33-24-21 745/270/R50	001-099
D41437J	1	BACC45FN16-24S7 RCPT	81205	1	27-09-14 E003-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41400

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41437J	1	BACC45FN22-55S7 RCPT	81205	1	27-09-14 E003-01/ /	115-199
D41437P	1	BACC45FT16A24P7 PLUG-	81205	1	27-09-14 E003-01/ /	001-099
D41437P	1	BACC45FT22A55P7 PLUG-	81205	1	27-09-14 E3-1/ /	115-199
D41438J	1	48-7191 RCPT-	02660	1	33-24-21 745/270/R50	001-099
D41440J		BACC45FN14-15P RCPT	81205	1	24-25-12 E001-01/ /	003-099
D41440P		BACC45FT14-15S PLUG	81205	1	24-25-12 E1-1/ /	003-099
D41443J	1	BACC45FN22-55S9 RCPT-	81205	1	34-53-11 E3-3/ /	ALL
D41443P	1	BACC45FT22A55P9 PLUG-	81205	1	31-31-11 E003-03/ /	001-099
D41443P	1	BACC45FT22A55P9 PLUG-	81205	1	31-31-11 E3-3/ /	115-199
D41445J	1	BACC45FN18-31S8 RCPT	81205	1	31-51-42 E003-04/ /	001-099
D41445J	1	BACC45FN22-55S8 RCPT	81205	1	31-51-42 E003-04/ /	115-199
D41445P	1	BACC45FT18A31P8 PLUG-	81205	1	31-51-42 E003-04/ /	001-099
D41445P	1	BACC45FT22A55P8 PLUG-	81205	1	31-51-42 E3-4/ /	115-199
D41448J		BACC63CC14-7SN RCPT-	81205	1	78-34-51 AC0880/ /	ALL
D41448JK		BACC10HF14C CABLE CLAMP	81205	1	78-34-51 AC0880/ /	ALL
D41448P	9	BACC63CB14-7PN PLUG(SB780032)	81205	1	78-34-51 AC0880/ /	001-002, 115-199
D41448P		BACC63CB14-7PN PLUG	81205	1	78-34-51 AC0880/ /	003-099

EQUIPMENT LIST

D280N032

Section D41400

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41448PQ	9	BACC10HF14C CABLE CLAMP(SB780032)	06324	1	78-34-51 / /	001-002, 115-199
D41448PQ		BACC10HF14C CABLE CLAMP	06324	1	78-34-51 */*/	003-099
D41451J	1	BACC45FN22-55S7 RCPT-	81205	1	34-46-11 E4-2/ /	ALL
D41451P	1	BACC45FT22A55P7 PLUG-	81205	1	34-46-11 E004-02/ /	001-099
D41451P	1	BACC45FT22A55P7 PLUG-	81205	1	34-46-11 E4-2/ /	115-199
D41453J	1	BACC45FN22-55S7 RCPT-	81205	1	23-22-12 E004-03/ /	001-099
D41453J	1	BACC45FN22-55S7 RCPT-	81205	1	23-22-12 E4-3/ /	115-199
D41453P	1	BACC45FT22A55P7 PLUG-	81205	1	23-21-11 E004-03/ /	001-099
D41453P	1	BACC45FT22A55P7 PLUG-	81205	1	23-22-12 E4-3/ /	115-199
D41455J	1	BACC45FN18-31S RCPT-	81205	1	23-31-12 E004-04/ /	001-099
D41455J	1	BACC45FN18-31S RCPT-	81205	1	23-31-12 E4-4/ /	115-199
D41455P	1	BACC45FT18A31P PLUG-	81205	1	23-34-15 E4-4/ /	ALL
D41457J	1	BACC45FN14-15S RCPT	81205	1	23-31-19 E004-03/ /	001-099
D41457P	1	BACC45FT14A15P PLUG	81205	1	23-31-19 E004-03/ /	001-099
D41458J		BACC63CC14-7SN RCPT	81205	1	78-34-61 AD0880/ /	ALL
D41458JK		BACC10HF14C CABLE CLAMP	81205	1	78-34-61 */*/	ALL
D41458P	9	BACC63CB14-7PN PLUG(SB780032)	81205	1	78-34-61 AD0880/ /	001-002, 115-199

EQUIPMENT LIST

D280N032

Section D41400

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41458P		BACC63CB14-7PN PLUG	81205	1	78-34-61 AD0880/ /	003-099
D41458PQ	9	BACC10HF14C CABLE CLAMP(SB780032)	06324	1	78-34-61 */*/	001-002, 115-199
D41458PQ		BACC10HF14C CABLE CLAMP	81205	1	78-34-61 */*/	003-099
D41459J	1	BACC45FN22-55S9 RCPT	81205	1	22-23-13 E5-1/ /	001-099
D41459J	1	BACC45FN22-55S9 RCPT	81205	1	22-23-13 AE0501/ /	115-199
D41459P	1	BACC45FT22A55P9 PLUG-	81205	1	31-31-12 E005-01/ /	001-099
D41459P	1	BACC45FT22A55P9 PLUG-	81205	1	31-31-12 E5-1/ /	115-199
D41461J	1	BACC45FN22-55S9 RCPT	81205	1	22-23-13 E5-2/ /	ALL
D41461P	1	BACC45FT22A55P9 PLUG-	81205	1	24-28-21 E005-02/ /	001-099
D41461P	1	BACC45FT22A55P9 PLUG-	81205	1	24-28-21 E5-2/ /	115-199
D41462J	9	BACC45FN18-31P6 RCPT (SB78-32)	81205	1	78-34-51 P36/ /	001-002
D41462J	9	BACC45FN18-31P6 RCPT	81205	1	78-34-51 P036-00/ /	115-199
D41462J	1	BACC45FN18-31P6 RCPT (SB78-32)	81205	1	78-34-51 P036-00/ /	001-002
D41462J	1	BACC45FN18-31P6 RCPT	81205	1	78-34-51 P036-00/ /	003-099
D41462P	1	BACC45FT18A31S6 PLUG	81205	1	78-34-51 P036-00/ /	ALL
D41463J	1	BACC45FN22-55S8 RCPT	81205	1	27-32-11 E005-03/ /	001-099
D41463J	1	BACC45FN22-55S8 RCPT	81205	1	27-32-11 E5-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41400

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41463P	1	BACC45FT22A55P8 PLUG-	81205	1	27-32-11 E005-03/ /	001-099
D41463P	1	BACC45FT22A55P8 PLUG-	81205	1	27-32-11 E5-3/ /	115-199
D41470J	1	BACC45FN22-55P6 RCPT	81205	1	33-21-11 P034-00/ /	001-099
D41470J	1	BACC45FN22-55P6 RCPT	81205	1	33-21-11 P34/ /	115-199
D41470P	1	BACC45FT22-55S6 PLUG	81205	1	33-42-11 P034-00/ /	ALL
D41472J	1	BACC45FN22-55P7 RCPT	81205	1	33-21-31 P034-00/ /	001-099
D41472J	1	BACC45FN22-55P7 RCPT	81205	1	33-21-31 P34/ /	115-199
D41472P	1	BACC45FT22-55S7 PLUG-	81205	1	28-21-11 P034-00/ /	001-099
D41472P	1	BACC45FT22-55S7 PLUG-	81205	1	28-21-11 P34/ /	115-199
D41473J	1	BACC45FN22-55S8 RCPT	81205	1	21-33-12 P36/ /	ALL
D41473P	1	BACC45FT22A55P8 PLUG-	81205	1	34-61-13 P036-00/ /	001-099
D41473P	1	BACC45FT22A55P8 PLUG-	81205	1	34-61-13 P36/ /	115-199
D41474J	1	BACC45FN18-31P RCPT	81205	1	33-22-11 P034-00/ /	001-099
D41474J	1	BACC45FN18-31P RCPT	81205	1	33-22-11 P34/ /	115-199
D41474P	1	BACC45FT18-31S PLUG-	81205	1	33-22-11 P34/ /	ALL
D41475J	1	BACC45FN22-55S7 RCPT	81205	1	36-11-11 P36/ /	ALL
D41475P	1	BACC45FT22A55P7 PLUG-	81205	1	34-61-13 P036-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D41400

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41475P	1	BACC45FT22A55P7 PLUG-	81205	1	34-61-13 P36/ /	115-199
D41476J	1	BACC45FN22-19P8 RCPT	81205	1	33-21-11 P034-00/ /	001-099
D41476J	1	BACC45FN22-19P8 RCPT	81205	1	33-21-11 P34/ /	115-199
D41476P	1	BACC45FT22-19S8 PLUG-	81205	1	33-21-11 P034-00/ /	001-099
D41476P	1	BACC45FT22-19S8 PLUG-	81205	1	33-21-11 P34/ /	115-199
D41477J	1	BACC45FN22-55S6 RCPT	81205	1	22-12-11 P50/ /	ALL
D41477P	1	BACC45FT22A55P6 PLUG-	81205	1	34-61-13 P050-00/ /	001-099
D41477P	1	BACC45FT22A55P6 PLUG-	81205	1	34-61-13 P50/ /	115-199
D41478J	9	BACC45FN18-31P7 RCPT	81205	1	78-34-61 P037-00/ /	115-199
D41478J	1	BACC45FN18-31P7 RCPT (SB78-32)	81205	1	78-34-61 P037-00/ /	001-002
D41478J	1	BACC45FN18-31P7 RCPT	81205	1	78-34-61 P37/ /	003-099
D41478J	1	BACC45FN18-31P7 RCPT	81205	1	78-34-61 P037-00/ /	115-199
D41478P	1	BACC45FT18A31S7 PLUG	81205	1	78-34-61 P037-00/ /	ALL
D41481J	1	BACC45FN22-55S9 RCPT-	81205	1	27-32-11 P051-00/ /	ALL
D41481P	1	BACC45FT22A55P9 PLUG-	81205	1	27-32-11 P051-00/ /	001-099
D41481P	1	BACC45FT22A55P9 PLUG-	81205	1	27-32-11 P51/ /	115-199
D41487J	1	BACC45FN22-55S8 RCPT	81205	1	31-31-12 P37/ /	ALL

EQUIPMENT LIST

D280N032

Section D41400

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41487P	1	BACC45FT22A55P8 PLUG-	81205	1	34-61-15 P037-00/ /	001-099
D41487P	1	BACC45FT22A55P8 PLUG-	81205	1	34-61-15 P37/ /	115-199
D41489J	1	BACC45FN16-24S7 RCPT	81205	1	21-51-21 P50/ /	ALL
D41489P	1	BACC45FT16A24P7 PLUG-	81205	1	22-23-22 P050-00/ /	001-099
D41489P	1	BACC45FT16A24P7 PLUG-	81205	1	22-23-22 P50/ /	115-199
D41491J	1	BACC45FN22-55S RCPT-	81205	1	27-32-21 P051-00/ /	ALL
D41491P	1	BACC45FT22-55P PLUG-	81205	1	27-32-11 P051-00/ /	001-099
D41491P	1	BACC45FT22-55P PLUG-	81205	1	27-32-11 P51/ /	115-199
D41493J	1	BACC45FN22-55S8 RCPT	81205	1	27-09-12 P36/ /	ALL
D41493P	1	BACC45FT22A55P8 PLUG-	81205	1	22-14-31 P036-00/ /	ALL
D41495J	1	BACC45FN18-31S8 RCPT	81205	1	31-31-12 P37/ /	ALL
D41495P	1	BACC45FT18A31P8 PLUG-	81205	1	31-31-12 P037-00/ /	ALL
D41497J	1	BACC45FN22-55S7 RCPT	81205	1	23-31-14 P36/ /	ALL
D41497P	1	BACC45FT22A55P7 PLUG-	81205	1	34-46-11 P036-00/ /	001-099
D41497P	1	BACC45FT22A55P7 PLUG-	81205	1	34-46-11 P36/ /	115-199
D41498J	1	BACC45FN18-14S RCPT-	81205	1	33-24-12 665/295/L030	009-099
D41498P	1	BACC45FT18A14P PLUG-	81205	1	33-24-12 656/ /	009-099

EQUIPMENT LIST

D280N032

Section D41400

Page 10 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41513J	1	BACC45FN14-15S8 RCPT	81205	1	23-31-19 E004-03/ /	001-099
D41513J	1	BACC45FN12-12S8 RCPT-	81205	1	23-32-02 E4-3/ /	115-199
D41513P	1	BACC45FT14A15P8 PLUG	81205	1	23-32-02 E004-03/ /	001-099
D41513P	1	BACC45FT12A12P8 PLUG	81205	1	23-32-02 E004-03/ /	115-199
D41515J	1	BACC45FN10-5S PLUG	81250	1	23-32-02 E004-04/ /	001-099
D41515J	1	BACC45FN10-5S RECP	81205	1	23-32-02 E004-04/ /	115-199
D41515P	1	BACC45FT10A5P PLUG	81205	1	23-34-15 E4-4/ /	001-099
D41515P	1	BACC45FT10A5P PLUG	81205	1	23-32-02 E4-4/ /	115-199
D41519J	1	BACC45FN18-31S6 RCPT-	81205	1	31-31-01 E3-3/ /	001-099
D41519J	1	BACC45FN18-31S6 RCPT-	81205	1	31-31-11 E3-3/ /	115-199
D41519P	1	BACC45FT18A31P6 PLUG-	81205	1	31-31-01 E003-03/ /	001-099
D41519P	1	BACC45FT18A31P6 PLUG-	81205	1	31-31-11 E003-03/ /	115-199
D41521J	1	BACC45FN16-24S6 RCPT-	81205	1	31-31-01 E3-3/ /	001-099
D41521J	1	BACC45FN16-24S6 RCPT-	81205	1	31-31-11 E3-3/ /	115-199
D41521JK		BACA14BH12 ADAPTER	81205	1	31-31-11 E3-3/ /	001-099
D41521P	1	BACC45FT16A24P6 PLUG-	81205	1	31-31-01 E003-03/ /	001-099
D41521P	1	BACC45FT16A24P6 PLUG-	81205	1	31-31-11 E003-03/ /	115-199

EQUIPMENT LIST

D280N032

Section D41500

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41523J	1	BACC45FN16-24S7 RCPT-	81205	1	31-31-11 E3-3/ /	115-199
D41523P	1	BACC45FT16A24P7 PLUG-	81205	1	31-31-11 E003-03/ /	115-199
D41525J	1	BACC45FN16-24S RCPT-	81205	1	34-53-11 E3-3/ /	001-099
D41525J	1	BACC45FN14-15S RCPT-	81205	1	34-53-11 E3-3/ /	115-199
D41525P	1	BACC45FT16A24P PLUG-	81205	1	34-53-11 E003-03/ /	001-099
D41525P	1	BACC45FT14A15P PLUG-	81205	1	34-53-11 E3-3/ /	115-199
D41527J	1	BACC45FN16-24S RCPT-	81205	1	34-53-21 E003-02/ /	001-099
D41527J	1	BACC45FN14-15S RCPT-	81205	1	34-53-21 E3-2/ /	115-199
D41527P	1	BACC45FT16A24P PLUG-	81205	1	34-53-21 E003-02/ /	001-099
D41527P	1	BACC45FT14A15P PLUG-	81205	1	34-53-21 E3-2/ /	115-199
D41529J	1	BACC45FN14-12P8 RCPT-	81205	1	23-12-31 E004-04/ /	001-099
D41529P	1	BACC45FT14A12S8 PLUG	81205	1	23-12-31 E4-4/ /	001-099
D41531J	1	BACC45FN14-12S8 RCPT-	81205	1	23-12-11 E004-03/ /	001-099
D41531J	1	BACC45FN14-12S8 RCPT-	81205	1	23-12-11 E4-3/ /	115-199
D41531P	1	BACC45FT14A12P8 PLUG-	81205	1	23-12-11 E004-03/ /	ALL
D41533J	1	BACC45FN16-24S7 RCPT-	81205	1	23-12-21 E004-03/ /	001-099
D41533J	1	BACC45FN14-12S7 RCPT-	81205	1	23-12-21 E4-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41500

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41533P	1	BACC45FT16A24P7 PLUG-	81205	1	23-12-21 E004-03/ /	001-099
D41533P	1	BACC45FT14A12P7 PLUG-	81205	1	23-12-21 E004-03/ /	115-199
D41541J	1	BACC45FN22-55P9 RCPT-	81205	1	23-21-11 E004-03/ /	001-099
D41541J	1	BACC45FN22-55P9 RCPT-	81205	1	23-21-11 E4-3/ /	115-199
D41541P	1	BACC45FT22A55S9 PLUG-	81205	1	23-21-11 E004-03/ /	001-099
D41541P	1	BACC45FT22A55S9 PLUG-	81205	1	23-21-11 E4-3/ /	115-199
D41544J	1	BACC45FN22-55S8 RCPT	81205	1	32-42-11 P36/ /	ALL
D41544P	1	BACC45FT22-55P8 PLUG	81205	1	32-42-11 P036-00/ /	001-099
D41544P	1	BACC45FT22-55P8 PLUG	81205	1	32-42-11 P36/ /	115-199
D41546J	1	BACC45FN22-55S PLUG	81205	1	21-61-11 P37/ /	ALL
D41546P	1	BACC45FT22-55P PLUG	81205	1	21-51-24 P037-00/ /	001-099
D41546P	1	BACC45FT22-55P PLUG	81205	1	21-51-24 P37/ /	115-199
D41547J	1	BACC45FN18A31S9 RCPT-	81205	1	23-34-12 E004-04/ /	ALL
D41547P	1	BACC45FT18A31P9 PLUG-	81205	1	23-34-12 E4-4/ /	ALL
D41548J	1	BACC45FN20-16S RCPT-	81205	1	33-23-11 360/297/L045	ALL
D41548P	1	BACC45FT20-16P PLUG-	81205	1	33-25-11 355/290/L30	001-099
D41548P	1	BACC45FT20-16P PLUG-	81205	1	33-25-11 AA0360/ /	115-199

EQUIPMENT LIST

D280N032

Section D41500

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41549J	1	BACC45FN18A31S8 RCPT-	81205	1	23-34-12 E004-04/ /	ALL
D41549P	1	BACC45FT18A31P8 PLUG-	81205	1	23-34-12 E4-4/ /	ALL
D41551J	1	BACC45FN18-31S RCPT-	81205	1	23-42-11 E004-03/ /	001-099
D41551J	1	BACC45FN18-31S RCPT-	81205	1	23-42-11 E4-3/ /	115-199
D41551P	1	BACC45FT18A31P PLUG-	81205	1	23-42-11 E004-03/ /	001-099
D41551P	1	BACC45FT18A31P PLUG-	81205	1	23-42-11 E4-3/ /	115-199
D41553J	1	BACC45FN20-41S7 RCPT-	81205	1	23-51-11 E004-03/ /	001-099
D41553J	1	BACC45FN20-41S7 RCPT-	81205	1	23-51-11 E4-3/ /	115-199
D41553P	1	BACC45FT20A41P7 PLUG-	81205	1	23-51-11 E004-03/ /	ALL
D41555J	1	BACC45FN20-41S6 RCPT-	81205	1	23-51-21 E004-03/ /	001-099
D41555J	1	BACC45FN20-41S6 RCPT-	81205	1	23-51-21 E4-3/ /	115-199
D41555P	1	BACC45FT20A41P6 PLUG-	81025	1	23-51-21 E4-3/ /	ALL
D41557J	1	BACC45FN20-41S RCPT-	81205	1	23-51-31 E004-03/ /	115-199
D41557P	1	BACC45FT20A41P PLUG-	81205	1	23-51-51 E004-03/ /	115-199
D41559J	1	BACC45FN20-41S9 RCPT-	81205	1	23-51-41 E004-03/ /	001-099
D41559J	1	BACC45FN20-41S9 RCPT-	81205	1	23-51-41 E4-3/ /	115-199
D41559P	1	BACC45FT20A41P9 PLUG-	81205	1	23-51-41 E4-3/ /	ALL

EQUIPMENT LIST

D280N032

Section D41500

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41561J	1	BACC45FN18-31S8 RCPT-	81205	1	23-51-11 E004-03/ /	001-099
D41561J	1	BACC45FN16-24S8 RCPT-	81205	1	23-51-11 E4-3/ /	115-199
D41561P	1	BACC45FT18A31P8 PLUG-	81205	1	23-71-11 E004-03/ /	001-099
D41561P	1	BACC45FT16A24P8 PLUG-	81205	1	23-71-11 E004-03/ /	115-199
D41563J	1	BACC45FN22-55S7 RCPT-	81205	1	34-61-12 E002-01/ /	001-099
D41563J	1	BACC45FN22-55S7 RCPT-	81205	1	34-61-12 E2-1/ /	115-199
D41563P	1	BACC45FT22A55P7 PLUG-	81205	1	34-61-12 E002-01/ /	001-099
D41563P	1	BACC45FT22A55P7 PLUG-	81205	1	34-61-12 E2-1/ /	115-199
D41565J	1	BACC45FN22-55S7 RCPT-	81205	1	34-22-28 E002-02/ /	001-099
D41565J	1	BACC45FN22-55S7 RCPT-	81205	1	34-22-28 E2-2/ /	115-199
D41565P	1	BACC45FT22A55P7 PLUG-	81205	1	34-61-23 E002-02/ /	001-099
D41565P	1	BACC45FT22A55P7 PLUG-	81205	1	34-61-23 E2-2/ /	115-199
D41567J	1	BACC45FN22-55S9 RCPT-	81205	1	34-61-12 E002-03/ /	001-099
D41567J	1	BACC45FN22-55S9 RCPT-	81205	1	34-61-12 E2-3/ /	115-199
D41567P	1	BACC45FT22A55P9 PLUG-	81205	1	22-15-12 E002-03/ /	001-099
D41567P	1	BACC45FT22A55P9 PLUG-	81205	1	22-15-12 E2-3/ /	115-199
D41569J	1	BACC45FN18-31S8 RCPT	81205	1	34-21-11 E002-04/ /	001-099

EQUIPMENT LIST

D280N032

Section D41500

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41569J	1	BACC45FN22-55S8 RCPT	81205	1	34-21-11 E2-4/ /	115-199
D41569P	1	BACC45FT18A31P8 PLUG-	81205	1	34-61-12 E002-04/ /	001-099
D41569P	1	BACC45FT22A55P8 PLUG-	81205	1	34-61-12 E2-4/ /	115-199
D41576 T		S280T007-1 COIL CABLE	05973	1	30-41-11 254/257/R040	ALL
D41576J	1	BACC45FN12-12S RCPT	81205	1	30-41-11 AB0254/ /	ALL
D41576P	1	BACC45FT12-12P PLUG	81205	1	30-41-11 254/257/R040	ALL
D41578 T		S280T007-1 COIL CABLE	05973	1	30-41-12 */ */	ALL
D41578J	1	BACC45FN12-12P RCPT	81205	1	30-41-12 AA0260/ /	ALL
D41578P	1	BACC45FT12-12S PLUG	81205	1	30-41-12 262/257/L040	ALL
D41592J	1	BACC45FN14-4P RCPT	81205	1	30-41-11 E1-2/ /	ALL
D41592P	1	BACC45FT14-4S PLUG	81205	1	30-41-11 E001-02/ /	ALL
D41594J	1	BACC45FN14-15P6 RCPT	81205	1	30-41-11 E1-2/ /	ALL
D41594P	1	BACC45FT14-15S6 PLUG	81205	1	30-41-11 E001-02/ /	ALL
D41595J	1	BACC45FN22-55S RCPT-	81205	1	34-22-18 E002-01/ /	001-099
D41595J	1	BACC45FN22-55S RCPT-	81205	1	34-22-18 E2-1/ /	115-199
D41595P	1	BACC45FT22A55P PLUG-	81205	1	34-22-18 E002-01/ /	001-099
D41595P	1	BACC45FT22A55P PLUG-	81205	1	34-22-18 E2-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D41500

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41596J	1	BACC45FN14-15P9 RCPT	81205	1	30-41-11 E001-02/ /	ALL
D41596P	1	BACC45FT14-15S9 PLUG	81205	1	30-41-11 E001-02/ /	ALL
D41599J	1	BACC45FN14-15S8 RCPT-	81205	1	31-51-34 P051-00/ /	115-199
D41599P	1	BACC45FT14A15P8 PLUG	81205	1	31-51-34 P051-00/ /	115-199

EQUIPMENT LIST

D280N032

Section D41500
Page 7 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41600J	1	BACC45FN14-15P6 RCPT	81205	1	30-41-12 E001-01/ /	ALL
D41600P	1	BACC45FT14-15S6 PLUG	81205	1	30-41-12 E001-01/ /	ALL
D41601J	1	BACC45FN22-55S RCPT-	81205	1	34-61-12 E002-01/ /	001-099
D41601J	1	BACC45FN22-55S RCPT-	81205	1	34-61-12 E2-1/ /	115-199
D41601P	1	BACC45FT22A55P PLUG-	81205	1	34-61-12 E002-01/ /	001-099
D41601P	1	BACC45FT22A55P PLUG-	81205	1	34-61-12 E2-1/ /	115-199
D41602J	1	BACC45FN14-4P RCPT	81205	1	30-41-12 E001-01/ /	ALL
D41602P	1	BACC45FT14-4S PLUG	81205	1	30-41-12 E001-01/ /	ALL
D41603J	1	BACC45FN22-55S8 RCPT-	81205	1	34-61-22 E002-02/ /	001-099
D41603J	1	BACC45FN22-55S8 RCPT-	81205	1	34-61-22 E2-2/ /	115-199
D41603P	1	BACC45FT22A55P8 PLUG-	81205	1	34-22-18 E002-02/ /	001-099
D41603P	1	BACC45FT22A55P8 PLUG-	81205	1	34-22-18 E2-2/ /	115-199
D41604J	1	BACC45FN14-15P9 RCPT	812051	1	30-41-12 E001-01/ /	ALL
D41604P	1	BACC45FT14-15S9 PLUG	81205	1	30-41-12 E001-01/ /	ALL
D41605J	1	BACC45FN22-55S9 RCPT-	81205	1	34-43-11 E002-03/ /	001-099
D41605J	1	BACC45FN22-55S9 RCPT-	81205	1	34-43-11 E2-3/ /	115-199
D41605P	1	BACC45FT22A55P9 PLUG-	81205	1	34-43-11 E002-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D41600

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41605P	1	BACC45FT22A55P9 PLUG-	81205	1	34-43-11 E2-3/ /	115-199
D41606J	1	BACC45FN16-24S9 RCPT-	81205	1	22-11-11 E002-01/ /	001-099
D41606J	1	BACC45FN16-24S9 RCPT-	81205	1	22-11-11 E2-1/ /	115-199
D41606P	1	BACC45FT16-24P9 PLUG-	81205	1	22-11-11 E002-01/ /	001-099
D41606P	1	BACC45FT16-24P9 PLUG-	81205	1	22-11-11 E2-1/ /	115-199
D41610J	1	BACC45FN22-55S8 RCPT	81205	1	32-09-11 E003-04/ /	001-099
D41610J	1	BACC45FN22-55S6 RCPT	81205	1	32-09-11 E003-04/ /	115-199
D41610P	1	BACC45FT22-55P8 PLUG-	81205	1	32-09-11 E003-04/ /	001-099
D41610P	1	BACC45FT22-55P6 PLUG-	81205	1	32-09-11 E3-4/ /	115-199
D41612J	1	BACC45FN22-55S RCPT	81205	1	27-58-11 P36/ /	ALL
D41612P	1	BACC45FT22-55P PLUG-	81205	1	32-09-11 P036-00/ /	001-099
D41612P	1	BACC45FT22-55P PLUG-	81205	1	32-09-11 P36/ /	115-199
D41614J	1	BACC45FN22-55S RCPT	81205	1	28-21-22 E003-04/ /	001-099
D41614J	1	BACC45FN22-55S8 RCPT	81205	1	28-21-22 E003-04/ /	115-199
D41614P	1	BACC45FT22-55P PLUG	81205	1	28-21-22 E003-04/ /	001-099
D41614P	1	BACC45FT22-55P8 PLUG	81205	1	28-21-22 E3-4/ /	115-199
D41616J	1	BACC45FN20-41S6 RCPT	81205	1	28-22-11 P37/ /	ALL

EQUIPMENT LIST

D280N032

Section D41600

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41616P	1	BACC45FT20-41P6 PLUG	81205	1	32-09-12 P037-00/ /	001-099
D41616P	1	BACC45FT20-41P6 PLUG	81205	1	32-09-12 P37/ /	115-199
D41618J	1	BACC45FN16-24S7 RCPT	81205	1	28-41-21 E003-04/ /	001-099
D41618J	1	BACC45FN20-39S7 RCPT	81205	1	28-41-21 E003-04/ /	115-199
D41618P	1	BACC45FT16-24P7 PLUG	81205	1	28-41-21 E003-04/ /	001-099
D41618P	1	BACC45FT20-39P7 PLUG	81205	1	28-41-21 E3-4/ /	115-199
D41620J	1	BACC45FN18-31S6 RCPT	81205	1	78-36-21 E003-04/ /	001-099
D41620J	1	BACC45FN20-39S RCPT	81205	1	78-36-21 E003-04/ /	115-199
D41620P	1	BACC45FT18A31P6 PLUG	81205	1	78-36-21 E003-04/ /	001-099
D41620P	1	BACC45FT20A39P PLUG	81205	1	78-36-21 E003-04/ /	115-199
D41622J	1	BACC45FN16-24S8 RCPT	81205	1	22-13-31 E002-03/ /	001-099
D41622J	1	BACC45FN18-31S8 RCPT	81205	1	22-13-31 E2-3/ /	115-199
D41622P	1	BACC45FT16-24P8 PLUG	81205	1	22-13-31 E002-03/ /	001-099
D41622P	1	BACC45FT18-31P8 PLUG	81205	1	22-13-31 E002-03/ /	115-199
D41624J	1	BACC45FN16-24S8 RCPT-	81205	1	22-11-22 E002-02/ /	001-099
D41624J	1	BACC45FN16-24S8 RCPT-	81205	1	22-11-22 E2-2/ /	115-199
D41624P	1	BACC45FT16-24P8 PLUG	81205	1	22-31-21 E002-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D41600

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41624P	1	BACC45FT16-24P8 PLUG	81205	1	22-31-21 E2-2/ /	115-199
D41626J	1	BACC45FN16-24S7 RCPT	81205	1	26-15-12 P33/ /	001-099
D41626J	1	BACC45FN16-10S7 RCPT	81205	1	28-22-11 P33/ /	115-199
D41626P	1	BACC45FT16-24P7 PLUG-	81205	1	33-42-11 P033-00/ /	001-099
D41626P	1	BACC45FT16-10P7 PLUG-	81205	1	33-42-11 P033-00/ /	115-199
D41628J	1	BACC45FN22-55S8 RCPT-	81205	1	52-71-11 E4-2/ /	ALL
D41628P	1	BACC45FT22-55P8 PLUG	81205	1	52-71-11 E004-02/ /	001-099
D41628P	1	BACC45FT22-55P8 PLUG	81205	1	52-71-11 E4-2/ /	115-199
D41630J	1	BACC45FN14-15S6 RCPT	81205	1	27-51-41 E5-1/ /	ALL
D41630P	1	BACC45FT14-15P6 PLUG	81205	1	27-23-21 E005-01/ /	001-099
D41630P	1	BACC45FT14-15P6 PLUG	81205	1	27-51-41 E5-1/ /	115-199
D41632J	1	BACC45FN16-24S9 RCPT-	81205	1	52-71-21 E4-2/ /	001-099
D41632J	1	BACC45FN22-55S9 RCPT-	81205	1	52-71-21 E4-2/ /	115-199
D41632P	1	BACC45FT16-24P9 PLUG	81205	1	52-71-21 E004-02/ /	001-099
D41632P	1	BACC45FT22-55P9 PLUG	81205	1	52-71-21 E004-02/ /	115-199
D41634J	1	BACC45FN16-24S RCPT	81205	1	32-61-11 E003-04/ /	001-099
D41634J	1	BACC45FN18-31S RCPT	81205	1	32-61-11 E003-04/ /	115-199

EQUIPMENT LIST

D280N032

Section D41600

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41634P	1	BACC45FT16-24P PLUG	81205	1	32-12-12 E003-04/ /	001-099
D41634P	1	BACC45FT18-31P PLUG	81205	1	32-61-11 E3-4/ /	115-199
D41636J	1	BACC45FN18-31S7 RCPT	81205	1	32-61-11 E003-04/ /	ALL
D41636P	1	BACC45FT18-31P7 PLUG	81205	1	32-61-13 E003-04/ /	001-099
D41636P	1	BACC45FT18-31P7 PLUG	81205	1	32-61-11 E3-4/ /	115-199
D41637J	1	BACC45FN18-31S9 RCPT	81205	1	31-31-12 P37/ /	ALL
D41637P	1	BACC45FT18A31P9 PLUG-	81205	1	31-31-12 P037-00/ /	001-099
D41637P	1	BACC45FT18A31P9 PLUG-	81205	1	31-31-12 P37/ /	115-199
D41638J	1	BACC45FN22-55S PLUG	81205	1	21-51-23 820/ /	115-199
D41638P	1	BACC45FT22A55P PLUG	81205	1	21-51-23 820/ /	115-199
D41640J	1	BACC45FN20-25S6 RCPT	81205	1	21-61-31 530/290/R035	001-099
D41640J	1	BACC45FN22-55S6 PLUG	81205	1	21-61-31 820/ /	115-199
D41640P	1	BACC45FT20A25P6 PLUG	81205	1	21-61-31 530/290/R035	001-099
D41640P	1	BACC45FT22A55P6 PLUG	81205	1	21-61-31 820/ /	115-199
D41642J	1	BACC45FN22-55S7 PLUG	81205	1	21-51-23 820/ /	115-199
D41642P	1	BACC45FT22A55P7 PLUG	81205	1	21-51-23 820/ /	115-199
D41643J	1	BACC45FN20-41S9 RCPT-	81205	1	29-32-41 E002-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D41600

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41643J	1	BACC45FN20-41S9 RCPT-	81205	1	29-32-41 E2-3/ /	115-199
D41643P	1	BACC45FT20A41P9 PLUG-	81205	1	29-32-41 E002-03/ /	001-099
D41643P	1	BACC45FT20A41P9 PLUG-	81205	1	29-32-41 E2-3/ /	115-199
D41644J	1	BACC45FN20-16S7 RCPT	81205	1	33-31-31 E5-3/ /	115-199
D41644P	1	BACC45FT20-16P7 PLUG-	81205	1	33-31-31 E5-3/ /	115-199
D41646J	1	BACC45FN14-15S RCPT	81205	1	32-61-11 E003-04/ /	001-099
D41646J	1	BACC45FN18-14S RCPT	81205	1	32-61-11 E3-4/ /	115-199
D41646P	1	BACC45FT14-15P PLUG-	81205	1	32-61-11 E003-04/ /	001-099
D41646P	1	BACC45FT18-14P PLUG-	81205	1	32-61-11 E003-04/ /	115-199
D41648J	1	BACC45FN14-15S6 RCPT-	81205	1	23-41-11 E004-03/ /	001-099
D41648J	1	BACC45FN14-15S6 RCPT-	81205	1	23-41-11 E4-3/ /	115-199
D41648P	1	BACC45FT14-15P6 PLUG-	81205	1	23-41-11 E004-03/ /	ALL
D41650J	1	BACC45FN14-15S8 RCPT	81205	1	32-61-12 E003-04/ /	001-099
D41650J	1	BACC45FN18-14S7 RCPT	81205	1	32-61-12 E003-04/ /	115-199
D41650P	1	BACC45FT14-15P8 PLUG-	81205	1	32-61-12 E3-4/ /	001-099
D41650P	1	BACC45FT18-14P7 PLUG-	81205	1	32-61-12 E3-4/ /	115-199
D41652J	1	BACC45FN20-41S RCPT	81205	1	27-51-31 E5-1/ /	ALL

EQUIPMENT LIST

D280N032

Section D41600

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41652P	1	BACC45FT20-41P PLUG-	81205	1	27-51-41 E005-01/ /	001-099
D41652P	1	BACC45FT20-41P PLUG-	81205	1	27-51-41 E5-1/ /	115-199
D41654J	1	BACC45FN18-31S7 RCPT	81205	1	27-51-41 E5-1/ /	ALL
D41654P	1	BACC45FT18-31P7 PLUG	81205	1	27-51-41 E005-01/ /	001-099
D41654P	1	BACC45FT18-31P7 PLUG	81205	1	27-51-41 E5-1/ /	115-199
D41656J	1	BACC45FN18-31S9 RCPT	81205	1	27-51-61 E005-03/ /	001-099
D41656J	1	BACC45FN18-31S9 RCPT	81205	1	27-51-61 E5-3/ /	115-199
D41656P	1	BACC45FT18-31P9 PLUG	81205	1	27-51-61 E005-03/ /	001-099
D41656P	1	BACC45FT18-31P9 PLUG	81205	1	27-51-61 E5-3/ /	115-199
D41658J	1	BACC45FN18-31S RCPT	81205	1	27-51-61 E005-03/ /	001-099
D41658J	1	BACC45FN18-31S RCPT	81205	1	27-51-61 E5-3/ /	115-199
D41658P	1	BACC45FT18-31P PLUG	81205	1	24-41-11 E005-03/ /	001-099
D41658P	1	BACC45FT18-31P PLUG	81205	1	27-51-61 E5-3/ /	115-199
D41660J	1	BACC45FN20-41S9 RCPT-	81205	1	49-61-11 E4-2/ /	001-099
D41660J	1	BACC45FN20-39S9 RCPT-	81205	1	49-61-11 E4-2/ /	115-199
D41660P	1	BACC45FT20-41P9 PLUG	81205	1	49-61-11 E004-02/ /	001-099
D41660P	1	BACC45FT20-39P9 PLUG	81205	1	49-61-11 E4-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D41600

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41662J	1	BACC45FN20-28S6 RCPT	81205	1	49-61-11 E6-2/ /	001-099
D41662J	1	BACC45FN20-28S9 RCPT	81205	1	49-61-11 E6-4/ /	115-199
D41662P	1	BACC45FT20-28P6 PLUG	81205	1	49-61-11 E006-02/ /	001-099
D41662P	1	BACC45FT20-28P9 PLUG	81205	1	49-61-11 E6-4/ /	115-199
D41664J	1	BACC45FN12-12S6 RCPT-	81205	1	32-44-11 E4-2/ /	001-099
D41664J	1	BACC45FN20-41S6 RCPT-	81205	1	32-44-11 E4-2/ /	115-199
D41664P	1	BACC45FT12-12P6 PLUG	81205	1	32-44-11 E004-02/ /	001-099
D41664P	1	BACC45FT20-41P6 PLUG	81205	1	32-44-11 E4-2/ /	115-199
D41668J	1	BACC45FN14-15S8 RCPT	81205	1	32-42-11 E6-4/ /	115-199
D41668P	1	BACC45FT14-15P8 PLUG-	81205	1	32-42-11 E6-4/ /	115-199
D41670J	1	BACC45FN18-31S9 RCPT	81205	1	32-42-11 E6-4/ /	115-199
D41670P	1	BACC45FT18-31P9 PLUG	81205	1	32-42-11 E6-4/ /	115-199
D41672J	1	BACC45FN18-31S8 RCPT	81205	1	32-42-11 E6-4/ /	115-199
D41672P	1	BACC45FT18-31P8 PLUG-	81205	1	32-42-11 E6-4/ /	115-199
D41674J	1	BACC45FN14-15S7 RCPT	81205	1	32-42-11 E6-4/ /	115-199
D41674P	1	BACC45FT14-15P7 PLUG	81205	1	32-42-11 E6-4/ /	115-199
D41675J	1	BACC45FN14-15S6 RCPT	81205	1	22-12-31 P50/ /	ALL

EQUIPMENT LIST

D280N032

Section D41600

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41675P	1	BACC45FT14A15P6 PLUG-	81205	1	22-12-31 P050-00/ /	ALL
D41676J	1	BACC45FN22-55S7 RCPT	81205	1	49-14-11 E6-2/ /	001-099
D41676J	1	BACC45FN22-55S8 RCPT	81205	1	49-14-11 E6-4/ /	115-199
D41676P	1	BACC45FT22-55P7 PLUG	81205	1	49-14-11 E6-2/ /	001-099
D41676P	1	BACC45FT22-55P8 PLUG	81205	1	49-14-11 E6-4/ /	115-199
D41678J	1	BACC45FN20-25S RCPT	81205	1	49-14-11 E6-2/ /	001-099
D41678J	1	BACC45FN20-25S7 RCPT	81205	1	49-14-11 E6-4/ /	115-199
D41678P	1	BACC45FT20-25P PLUG	81205	1	49-14-11 E006-02/ /	001-099
D41678P	1	BACC45FT20-25P7 PLUG	81205	1	49-14-11 E006-04/ /	115-199
D41679J	1	BACC45FN22-55S9 RCPT-	81205	1	22-13-21 E002-02/ /	001-099
D41679J	1	BACC45FN22-55S9 RCPT-	81205	1	22-13-21 E2-2/ /	115-199
D41679P	1	BACC45FT22A55P9 PLUG-	81205	1	34-43-11 E002-02/ /	001-099
D41679P	1	BACC45FT22A55P9 PLUG-	81205	1	34-43-11 E2-2/ /	115-199
D41680J	1	BACC45FN22-55S7 RCPT	81205	1	49-61-11 E6 RLY/PNL/	ALL
D41680P	1	BACC45FT22-55P7 PLUG	81205	1	49-61-11 E006-00/ /	001-099
D41680P	1	BACC45FT22-55P7 PLUG	81205	1	49-61-11 E6/ /	115-199
D41681J	1	BACC45FN16-24P RCPT	81205	1	34-57-21 E006-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41600

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41681P	1	BACC45FT16A24S PLUG-	81205	1	34-57-21 E006-01/ /	001-099
D41683J	1	BACC45FN22-55P7 PLUG	81205	1	34-51-21 E6-1/ /	115-199
D41683P	1	BACC45FT22A55S7 PLUG	81205	1	23-51-11 E6-1/ /	115-199
D41684J	1	BACC45FN16-24S7 RCPT	81205	1	49-61-11 P37/ /	ALL
D41684P	1	BACC45FT16-24P7 PLUG	81205	1	36-11-41 P037-00/ /	001-099
D41684P	1	BACC45FT16-24P7 PLUG	81205	1	36-11-41 P37/ /	115-199
D41685J	1	BACC45FN22-55P7 RCPT	81205	1	34-51-11 E6-1/ /	115-199
D41685P	1	BACC45FT22A55S7 PLUG	81205	1	23-51-11 E6-1/ /	115-199
D41686J	1	BACC45FN22-55S6 RCPT	81205	1	29-33-11 E6-4/ /	115-199
D41686P	1	BACC45FT22-55P6 PLUG	81205	1	29-33-11 E6-4/ /	115-199
D41687J	1	BACC45FN18-31P6 RCPT-	81205	1	23-51-11 E4-3/ /	115-199
D41687P	1	BACC45FT18A31S6 PLUG-	81205	1	23-21-11 E4-3/ /	115-199
D41688J	1	BACC45FN22-32S6 RCPT	81205	1	49-61-14 E6 RLY/PNL/	ALL
D41688P	1	BACC45FT22-32P6 PLUG	81205	1	49-61-14 E6 RLY/PNL/	001-099
D41688P	1	BACC45FT22-32P6 PLUG	81205	1	49-61-14 E6/ /	115-199
D41689J	1	BACC45FN18-31P7 RCPT-	81205	1	23-51-11 E4-3/ /	115-199
D41689P	1	BACC45FT18A31S7 PLUG-	81205	1	23-21-11 E4-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41600

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41690J	1	BACC45FN16-24S RCPT	81205	1	27-58-11 P36/ /	ALL
D41690P	1	BACC45FT16-24P PLUG	81205	1	27-58-11 P036-00/ /	001-099
D41690P	1	BACC45FT16-24P PLUG	81205	1	27-58-11 P36/ /	115-199
D41691J	1	BACC45FN20-41S7 RCPT-	81205	1	22-11-11 E002-01/ /	001-099
D41691J	1	BACC45FN20-41S7 RCPT-	81205	1	22-11-11 E2-1/ /	115-199
D41691P	1	BACC45FT20A41P7 PLUG-	81205	1	22-11-11 E002-01/ /	ALL
D41692J	1	BACC45FN20-25S7 RCPT	81205	1	27-51-21 P33/ /	ALL
D41692P	1	BACC45FT20-25P7 PLUG-	81205	1	27-81-11 P033-00/ /	ALL
D41693J	1	BACC45FN20-41S6 RCPT-	81205	1	22-11-21 E002-02/ /	001-099
D41693J	1	BACC45FN22-55S6 RCPT-	81205	1	22-11-21 E2-2/ /	115-199
D41693P	1	BACC45FT20A41P6 PLUG-	81205	1	22-11-21 E002-02/ /	001-099
D41693P	1	BACC45FT22A55P6 PLUG-	81205	1	22-11-21 E2-2/ /	115-199
D41694J	1	BACC45FN20-39S6 RCPT	81205	1	27-81-11 E5-2/ /	ALL
D41694P	1	BACC45FT20-39P6 PLUG	81205	1	27-81-11 E005-02/ /	001-099
D41694P	1	BACC45FT20-39P6 PLUG	81205	1	27-81-11 E5-2/ /	115-199
D41695J	1	BACC45FN20-41S RCPT-	81205	1	22-11-31 E002-03/ /	001-099
D41695J	1	BACC45FN20-41S RCPT-	81205	1	22-11-31 E2-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41600

Page 11

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41695P	1	BACC45FT20A41P PLUG-	81205	1	22-11-31 E002-03/ /	001-099
D41695P	1	BACC45FT20A41P PLUG-	81205	1	22-11-31 E2-3/ /	115-199
D41696J	1	BACC45FN18-31S7 RCPT	81205	1	27-81-21 E5-1/ /	ALL
D41696P	1	BACC45FT18-31P7 PLUG	81205	1	27-81-21 E005-01/ /	001-099
D41696P	1	BACC45FT18-31P7 PLUG	81205	1	27-81-21 E5-1/ /	115-199
D41698J	1	BACC45FN18-31S9 RCPT-	81205	1	27-23-11 E4-2/ /	001-099
D41698J	1	BACC45FN20-41S9 RCPT-	81205	1	27-23-11 E4-2/ /	115-199
D41698P	1	BACC45FT18-31P9 PLUG-	81205	1	27-23-11 E004-02/ /	001-099
D41698P	1	BACC45FT20-41P9 PLUG-	81205	1	27-23-11 E4-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D41600
Page 12 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41700J	1	BACC45FN12-12S6 RCPT-	81205	1	23-42-11 E004-03/ /	001-099
D41700J	1	BACC45FN12-12S6 RCPT-	81205	1	23-42-11 E4-3/ /	115-199
D41700P	1	BACC45FT12-12P6 PLUG-	81205	1	23-42-11 E004-03/ /	ALL
D41701J	1	BACC45FN12-12S6 RCPT-	81205	1	22-11-11 E002-01/ /	001-099
D41701J	1	BACC45FN22-55S6 RCPT-	81205	1	22-11-11 E2-1/ /	115-199
D41701P	1	BACC45FT12A12P6 PLUG	81205	1	22-11-11 E002-01/ /	001-099
D41701P	1	BACC45FT22A55P6 PLUG	81205	1	22-11-11 E002-01/ /	115-199
D41702J	1	BACC45FN18-31S7 RCPT-	81205	1	23-34-11 E4-4/ /	001-099
D41702J	1	BACC45FN18-31S7 RCPT-	81205	1	23-31-12 E4-4/ /	115-199
D41702P	1	BACC45FT18A31P7 PLUG-	81205	1	23-34-15 E4-4/ /	ALL
D41703J	1	BACC45FN12-12S7 RCPT-	81205	1	22-11-22 E002-02/ /	001-099
D41703J	1	BACC45FN22-55S7 RCPT-	81205	1	22-11-22 E2-2/ /	115-199
D41703P	1	BACC45FT12A12P7 PLUG	81205	1	22-11-21 E2-2/ /	001-099
D41703P	1	BACC45FT22A55P7 PLUG	81205	1	22-11-21 E2-2/ /	115-199
D41704J	1	BACC45FN22-32S RCPT	81205	1	32-09-11 P33/ /	ALL
D41704P	1	BACC45FT22-32P PLUG-	81205	1	28-21-11 P033-00/ /	ALL
D41705J	1	BACC45FN12-12S8 RCPT-	81205	1	22-11-31 E002-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D41700

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41705J	1	BACC45FN22-55S8 RCPT-	81205	1	22-11-31 E2-3/ /	115-199
D41705P	1	BACC45FT12A12P8 PLUG	81205	1	22-11-31 E002-03/ /	001-099
D41705P	1	BACC45FT22A55P8 PLUG	81205	1	22-11-31 E002-03/ /	115-199
D41706J	1	BACC45FN16-24S9 RCPT	81205	1	52-71-11 E003-04/ /	ALL
D41706P	1	BACC45FT16-24P9 PLUG-	81205	1	25-66-11 E3-4/ /	001-099
D41706P	1	BACC45FT16-24P9 PLUG-	81205	1	25-66-11 E003-04/ /	115-199
D41707J	1	BACC45FN16-24S6 RCPT	81205	1	27-41-21 E004-01/ /	001-099
D41707J	1	BACC45FN16-24S6 RCPT	81205	1	27-41-21 E4-1/ /	115-199
D41707P	1	BACC45FT16A24P6 PLUG-	81205	1	27-41-21 E4-1/ /	ALL
D41708J	1	BACC45FN14-15S9 RCPT	81205	1	52-71-21 E3-4/ /	001-099
D41708J	1	BACC45FN14-15S8 RCPT	81205	1	52-71-21 E003-04/ /	115-199
D41708P	1	BACC45FT14-15P9 PLUG-	81205	1	25-66-11 E3-4/ /	001-099
D41708P	1	BACC45FT14-15P8 PLUG-	81205	1	25-66-11 E3-4/ /	115-199
D41709J	1	BACC45FN16-24S9 RCPT	81205	1	22-24-11 E003-01/ /	ALL
D41709P	1	BACC45FT16A24P9 PLUG	81205	1	27-41-11 E3-1/ /	ALL
D41711J	1	BACC45FN16-24S6 RCPT-	81205	1	22-32-14 E002-03/ /	001-099
D41711J	1	BACC45FN18-31S6 RCPT-	81205	1	22-32-14 E2-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41700

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41711P	1	BACC45FT16A24P6 PLUG	81205	1	22-32-14 E002-03/ /	001-099
D41711P	1	BACC45FT18A31P6 PLUG	81205	1	22-32-14 E002-03/ /	115-199
D41713J	1	BACC45FN14-15S7 RCPT	81205	1	27-62-11 P36/ /	001-099
D41713J	1	BACC45FN12-12S7 RCPT	81205	1	27-62-11 P36/ /	115-199
D41713P	1	BACC45FT14A15P7 PLUG	81205	1	27-62-11 P36/ /	001-099
D41713P	1	BACC45FT12A12P7 PLUG	81205	1	27-62-11 P36/ /	115-199
D41714J	1	BACC45FN14-15S6 RCPT-	81205	1	33-21-12 930/390/L28	001-099
D41714J	1	BACC45FN10-5S RECP-	81205	1	33-21-12 930/300/L030	115-199
D41714P	1	BACC45FT14A15P6 PLUG-	81205	1	33-21-13 930/300/L34	001-099
D41714P	1	BACC45FT10A5P PLUG-	81205	1	33-21-12 930/300/L30	115-199
D41715J	1	BACC45FN12-12S6 RCPT-	81205	1	32-42-12 E2-1/ /	115-199
D41715P	1	BACC45FT12A12P6 PLUG	81205	1	32-42-12 E2-1/ /	115-199
D41716J	1	BACC45FN14-15S6 RCPT	81205	1	33-21-13 1235/300/L28	001-099
D41716J	1	BACC45FN10-5S RECP-	81205	1	33-21-13 1215/295/L35	115-199
D41716P	1	BACC45FT14A15P6 PLUG-	81205	1	33-21-14 1235/300/L28	001-099
D41716P	1	BACC45FT10A5P PLUG-	81205	1	33-21-13 1215/295/L35	115-199
D41718J	1	BACC45FN22-55S9 RCPT	81205	1	28-26-11 P33/ /	ALL

EQUIPMENT LIST

D280N032

Section D41700

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41718P	1	BACC45FT22-55P9 PLUG	81205	1	28-21-21 P033-00/ /	001-099
D41718P	1	BACC45FT22-55P9 PLUG	81205	1	28-21-21 P33/ /	115-199
D41719J	1	KD-19-105-M06 RCPT-	91836	1	23-12-31 E4-4/ /	001-099
D41719P	1	KD-59-161 PLUG	91836	1	23-12-31 E4-4/ /	001-099
D41720J	1	BACC45FN16-24S6 RCPT-	81205	1	27-18-11 E4-2/ /	001-099
D41720J	1	BACC45FN20-41S6 RCPT-	81205	1	27-18-11 E4-2/ /	115-199
D41720P	1	BACC45FT16-24P6 PLUG	81205	1	27-18-11 E004-02/ /	001-099
D41720P	1	BACC45FT20-41P6 PLUG	81205	1	27-18-11 E4-2/ /	115-199
D41721J	1	KD-19-68 RCPT-	91836	1	23-12-11 E004-03/ /	001-099
D41721J	1	KD-19-68 RCPT-	91836	1	23-12-11 E4-3/ /	115-199
D41721P	1	KD-59-187-M06 PLUG-	91836	1	23-12-11 E4-3/ /	001-099
D41721P	1	KD-59-110 PLUG-	91836	1	23-12-11 E4-3/ /	115-199
D41722J	1	BACC45FN16-10S RCPT	81205	1	28-22-11 P33/ /	ALL
D41722P	1	BACC45FT16-10P PLUG	81205	1	28-22-11 P033-00/ /	001-099
D41722P	1	BACC45FT16-10P PLUG	81205	1	28-22-11 P33/ /	115-199
D41728J	1	BACC45FN22-55S6 RCPT	81205	1	28-41-11 P37/ /	001-099
D41728J	1	BACC45FN20-16S6 RCPT	81205	1	28-41-11 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section D41700

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41728P	1	BACC45FT22-55P6 PLUG	81205	1	28-22-11 P037-00/ /	001-099
D41728P	1	BACC45FT20-16P6 PLUG	81205	1	28-22-11 P037-00/ /	115-199
D41730J	1	BACC45FN14-15S8 RCPT	81205	1	22-23-21 E5-2/ /	ALL
D41730P	1	BACC45FT14-15P8 PLUG	81205	1	22-23-21 E005-02/ /	001-099
D41730P	1	BACC45FT14-15P8 PLUG	81205	1	22-23-21 E5-2/ /	115-199
D41731J	1	KD-19-68 RCPT-	91836	1	23-12-21 E004-03/ /	001-099
D41731J	1	KD-19-68 RCPT-	91836	1	23-12-21 E4-3/ /	115-199
D41731P	1	KD-59-187-M06 PLUG-	91836	1	23-12-21 E004-03/ /	001-099
D41731P	1	KD-59-110 PLUG-	91836	1	23-12-21 E004-03/ /	115-199
D41732J	1	BACC45FN16-10S9 RCPT	81205	1	28-22-11 P37/ /	ALL
D41732P	1	BACC45FT16-10P9 PLUG	81205	1	28-22-11 P037-00/ /	001-099
D41732P	1	BACC45FT16-10P9 PLUG	81205	1	28-22-11 P37/ /	115-199
D41733J	1	BACC45FN12-12P7 RCPT-	81205	1	23-11-11 1685/298/L010	001-099
D41733J	1	BACC45FN12-12P7 RCPT-	81205	1	23-11-11 1685/304/L010	115-199
D41733P	1	BACC63BN12-12S7 PLUG-	81205	1	23-11-11 1685/298/L010	001-099
D41733P	1	BACC63BN12-12S7 PLUG-	81205	1	23-11-11 1685/304/L010	115-199
D41734J	1	BACC45FN22-55S RCPT-	81205	1	78-36-11 E4-2/ /	001-099

EQUIPMENT LIST

D280N032

Section D41700

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41734J	1	BACC45FN22A55S RCPT-	81205	1	78-36-11 E4-2/ /	115-199
D41734P	1	BACC45FT22-55P PLUG	81205	1	78-36-11 E004-02/ /	001-099
D41734P	1	BACC45FT22-55P PLUG	81205	1	78-36-11 E4-2/ /	115-199
D41735J	1	BACC45FN14-15S RCPT-	81205	1	23-11-21 1670/ /	001-099
D41735J	1	BACC45FN12-12P8 RCPT-	81205	1	23-11-21 1685/298/R010	115-199
D41735P	1	BACC45FT14A15P PLUG-	81205	1	23-11-21 1670/ /	001-099
D41735P	1	BACC63BN12-12S8 PLUG-	81205	1	23-11-21 1685/298/R010	115-199
D41736J	1	BACC45FN22-55S RCPT-	81205	1	79-43-11 E4-2/ /	ALL
D41736P	1	BACC45FT22-55P PLUG	81205	1	79-43-11 E004-02/ /	001-099
D41736P	1	BACC45FT22-55P PLUG	81205	1	79-43-11 E4-2/ /	115-199
D41738J	1	BACC45FN22-55S RCPT-	81205	1	49-61-11 E4-2/ /	001-099
D41738J	1	BACC45FN22A55S RCPT-	81205	1	49-61-11 E4-2/ /	115-199
D41738P	1	BACC45FT22-55P PLUG	81205	1	26-11-11 E004-02/ /	ALL
D41739J	1	BACC45FN22-55S6 RCPT	81205	1	22-31-13 P37/ /	ALL
D41739P	1	BACC45FT22A55P6 PLUG-	81205	1	22-31-13 P037-00/ /	001-099
D41739P	1	BACC45FT22A55P6 PLUG-	81205	1	22-31-13 P37/ /	115-199
D41741J	1	BACC45FN14-15S8 RCPT-	81205	1	22-41-13 E003-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D41700

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41741J	1	BACC45FN16-24S8 RCPT-	81205	1	22-41-13 E3-2/ /	115-199
D41741P	1	BACC45FT14A15P8 PLUG-	81205	1	22-41-13 E003-02/ /	001-099
D41741P	1	BACC45FT16A24P8 PLUG-	81205	1	22-41-13 E003-02/ /	115-199
D41742J	1	BACC45FN22-32P RCPT	81205	1	24-23-11 E5-1/ /	ALL
D41742P	1	BACC45FT22-32S PLUG	81205	1	24-22-11 E005-01/ /	ALL
D41743J	1	BACC45FN18-31S7 RCPT-	81205	1	22-15-11 E002-02/ /	001-099
D41743J	1	BACC45FN22-55S7 RCPT-	81205	1	22-15-11 E2-2/ /	115-199
D41743P	1	BACC45FT18A31P7 PLUG-	81205	1	22-14-11 E002-02/ /	001-099
D41743P	1	BACC45FT22A55P7 PLUG-	81205	1	22-14-11 E2-2/ /	115-199
D41744J	1	BACC45FN14-15P8 RCPT	81205	1	24-23-12 E005-03/ /	001-099
D41744J	1	BACC45FN14-15P8 RCPT	81205	1	24-23-12 E5-3/ /	115-199
D41744P	1	BACC45FT14-15S8 PLUG	81205	1	24-22-11 E005-03/ /	ALL
D41745J	1	BACC45FN14-15S8 RCPT-	81205	1	22-15-11 E002-01/ /	001-099
D41745J	1	BACC45FN22-55S8 RCPT-	81205	1	22-15-11 E2-1/ /	115-199
D41745P	1	BACC45FT14A15P8 PLUG-	81205	1	22-15-11 E002-01/ /	001-099
D41745P	1	BACC45FT22A55P8 PLUG-	81205	1	22-15-11 E2-1/ /	115-199
D41746J	1	BACC45FN20-25P6 RCPT	81205	1	24-53-11 P070-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D41700

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41746P	1	BACC45FT20D25S6 PLUG-	81205	1	24-53-11 P070-00/ /	ALL
D41747J	1	BACC45FN14-15S8 RCPT	81205	1	23-11-21 E6-3/ /	115-199
D41747P	1	BACC45FT14A15P8 PLUG	81205	1	23-11-21 E6-3/ /	115-199
D41748J	1	BACC45FN24-43P8 RCPT	81205	1	30-33-11 P37/ /	ALL
D41748P	1	BACC45FT24-43S8 PLUG-	81205	1	24-22-22 P037-00/ /	ALL
D41749J	1	KD-19-68 RCPT-	91836	1	34-32-11 E003-02/ /	001-099
D41749P	1	KD-59-186-M06 PLUG-	91836	1	34-32-11 E3-2/ /	001-099
D41750J	1	BACC45FN18-31P9 RCPT	81205	1	24-22-22 E005-03/ /	001-099
D41750J	1	BACC45FN18-31P9 RCPT	81205	1	24-22-22 E5-3/ /	115-199
D41750P	1	BACC45FT18-31S9 PLUG-	81205	1	24-22-22 E005-03/ /	ALL
D41752J	1	BACC45FN14-15P7 RCPT	81205	1	34-23-11 E5-1/ /	ALL
D41752P	1	BACC45FT14-15S7 PLUG-	81205	1	24-23-11 E5-1/ /	ALL
D41753J	1	KN-19-195-M06 RCPT-	91836	1	34-53-11 E3-3/ /	ALL
D41753P	1	KN-59-329-M06 PLUG-		1	34-53-11 E003-03/ /	ALL
D41754J	1	BACC45FN22-12S8 RCPT-	81205	1	30-41-11 P070-00/ /	ALL
D41754P	1	BACC45FT22D12P8 PLUG-	81205	1	30-41-11 P70/ /	ALL
D41755J	1	KN-19-195-M06 RCPT- COAX	91836	1	34-53-21 E003-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D41700

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41755J	1	KN-19-195-M06 RCPT- COAX	91836	1	34-53-21 E3-2/ /	115-199
D41755P	1	KN-59-329-M06 PLUG-		1	34-53-21 E003-02/ /	ALL
D41756J	1	BACC45FN22-12P9 RCPT	81205	1	30-41-12 E001-01/ /	ALL
D41756P	1	BACC45FT22-12S9 PLUG-	81205	1	30-41-12 E001-01/ /	001-099
D41756P	1	BACC45FT22-12S9 PLUG-	81205	1	30-41-12 E1-1/ /	115-199
D41758J	1	BACC45FN10-5P RCPT-	81205	1	34-21-11 E002-04/ /	001-099
D41758J	1	BACC45FN14-4P RCPT	81205	1	34-21-11 E2-4/ /	115-199
D41758P	1	BACC45FT10-5S PLUG-	81205	1	34-21-11 E002-04/ /	001-099
D41758P	1	BACC45FT14-4S PLUG-	81205	1	34-21-11 E002-04/ /	115-199
D41761J	1	BACC45FN18-31S9 RCPT	81205	1	27-61-13 E003-01/ /	001-099
D41761J	1	BACC45FN20-41S9 RCPT	81205	1	27-61-13 E003-01/ /	115-199
D41761P	1	BACC45FT18A31P9 PLUG-	81205	1	27-61-13 E003-01/ /	001-099
D41761P	1	BACC45FT20A41P9 PLUG-	81205	1	27-61-13 E003-01/ /	115-199
D41763J	1	BACC45FN18-31S8 RCPT	81205	1	27-61-17 E003-01/ /	001-099
D41763J	1	BACC45FN20-41S8 RCPT	81205	1	27-61-17 E003-01/ /	115-199
D41763P	1	BACC45FT18A31P8 PLUG-	81205	1	27-61-17 E003-01/ /	001-099
D41763P	1	BACC45FT20A41P8 PLUG-	81205	1	27-61-17 E003-01/ /	115-199

EQUIPMENT LIST

D280N032

Section D41700

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41764J	1	BACC45FN16-24S8 RCPT-	81205	1	26-11-11 E004-2/ /	001-099
D41764J	1	BACC45FN20-41S6 RCPT-	81205	1	80-11-11 E4-2/ /	115-199
D41764P	1	BACC45FT16A24P8 PLUG	81205	1	73-33-11 E004-02/ /	001-099
D41764P	1	BACC45FT20A41P6 PLUG	81205	1	73-33-11 E004-02/ /	115-199
D41765J	1	BACC45FN18-31S6 RCPT	81205	1	27-61-13 E003-01/ /	001-099
D41765J	1	BACC45FN20-41S6 RCPT	81205	1	27-61-13 E003-01/ /	115-199
D41765P	1	BACC45FT18A31P6 PLUG	81205	1	27-61-13 E003-01/ /	001-099
D41765P	1	BACC45FT20A41P6 PLUG	81205	1	27-61-13 E003-01/ /	115-199
D41766J	1	BACC45FN16-24S6 RCPT	81205	1	30-11-11 P37/ /	001-099
D41766J	1	BACC45FN16-24S6 PLUG	81205	1	30-11-11 P37/ /	115-199
D41766P	1	BACC45FT16-24P6 PLUG	81205	1	30-11-11 P037-00/ /	001-099
D41766P	1	BACC45FT16-24P6 PLUG	81205	1	30-11-11 P37/ /	115-199
D41767J	1	BACC45FN20-41S9 RCPT	81205	1	27-61-14 E004-01/ /	001-099
D41767J	1	BACC45FN20-41S9 RCPT	81205	1	27-61-14 E4-1/ /	115-199
D41767P	1	BACC45FT20A41P9 PLUG-	81205	1	27-61-14 E004-01/ /	001-099
D41767P	1	BACC45FT20A41P9 PLUG-	81205	1	27-61-14 E4-1/ /	115-199
D41769J	1	BACC45FN20-41S7 RCPT	81205	1	27-61-15 E004-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41700

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41769J	1	BACC45FN20-41S7 RCPT	81205	1	27-61-15 E4-1/ /	115-199
D41769P	1	BACC45FT20A41P7 PLUG-	81205	1	27-61-15 E004-01/ /	001-099
D41769P	1	BACC45FT20A41P7 PLUG-	81205	1	27-61-15 E4-1/ /	115-199
D41770J	1	BACC45FN12-12S8 RCPT	81205	1	28-25-11 E6 RLY/PNL/	001-099
D41770J	1	BACC45FN12-12S6 RCPT	81205	1	28-25-11 E6 RLY/PNL/	115-199
D41770P	1	BACC45FT12-12P8 PLUG	81205	1	28-25-21 1451/ /	001-099
D41770P	1	BACC45FT12-12P6 PLUG	81205	1	28-25-21 E6/ /	115-199
D41771J	1	BACC45FN20-41S RCPT	81205	1	27-61-14 E004-01/ /	001-099
D41771J	1	BACC45FN20-41S RCPT	81205	1	27-61-14 E4-1/ /	115-199
D41771P	1	BACC45FT20A41P PLUG	81205	1	27-61-14 E4-1/ /	ALL
D41772J	1	BACC45FN18-31P8 RECPT-	81205	1	73-21-12 E4-2/ /	001-099
D41772J	1	BACC45FN18A31S8 RCPT-	81205	1	77-11-11 E4-2/ /	115-199
D41772P	1	BACC45FT18A31S8 PLUG	81205	1	77-11-11 E004-02/ /	001-099
D41772P	1	BACC45FT18A31P8 PLUG	81205	1	77-11-11 E004-02/ /	115-199
D41773J	1	BACC45FN22-55P9 RCPT	81205	1	27-21-22 E004-01/ /	001-099
D41773J	1	BACC45FN22-55P9 RCPT	81205	1	27-21-22 E4-1/ /	115-199
D41773P	1	BACC45FT22A55S9 PLUG-	81205	1	22-24-21 E004-01/ /	ALL

EQUIPMENT LIST

D280N032

Section D41700

Page 11

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41774J	1	BACC45FN16-24P6 RCPT-	81205	1	77-41-11 E4-2/ /	001-099
D41774J	1	BACC45FN20-41S RCPT-	81205	1	80-11-21 E4-2/ /	115-199
D41774P	1	BACC45FT16A24S6 PLUG	81205	1	77-41-11 E004-02/ /	001-099
D41774P	1	BACC45FT20A41P PLUG	81205	1	77-41-11 E004-02/ /	115-199
D41775J	1	BACC45FN20-41P8 RCPT	81205	1	22-21-11 E003-01/ /	001-099
D41775J	1	BACC45FN22-55P8 RCPT	81205	1	22-21-11 E003-01/ /	115-199
D41775P	1	BACC45FT20A41S8 PLUG-	81205	1	22-24-21 E003-01/ /	001-099
D41775P	1	BACC45FT22A55S8 PLUG-	81205	1	22-24-21 E003-01/ /	115-199
D41776J	1	BACC45FN20-41S8 RCPT-	81205	1	79-35-11 E4-2/ /	001-099
D41776J	1	BACC45FN22A55S8 RCPT-	81205	1	79-35-11 E4-2/ /	115-199
D41776P	1	BACC45FT20-41P8 PLUG	81205	1	26-21-11 E004-02/ /	001-099
D41776P	1	BACC45FT22-55P8 PLUG	81205	1	26-21-11 E004-02/ /	115-199
D41777J	1	BACC45FN22-55P6 RCPT	81205	1	27-21-12 E004-01/ /	001-099
D41777J	1	BACC45FN22-55P6 RCPT	81205	1	27-21-12 E4-1/ /	115-199
D41777P	1	BACC45FT22A55S6 PLUG-	81205	1	27-21-12 E004-01/ /	ALL
D41779J	1	BACC45FN20-41P RCPT	81205	1	27-21-12 E003-01/ /	001-099
D41779J	1	BACC45FN22-55P RCPT	81205	1	27-21-12 E003-01/ /	115-199

EQUIPMENT LIST

D280N032

Section D41700

Page 12

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41779P	1	BACC45FT20A41S PLUG-	81205	1	27-21-21 E003-01/ /	001-099
D41779P	1	BACC45FT22A55S PLUG-	81205	1	27-21-21 E003-01/ /	115-199
D41781J	1	BACC45FN20-41P8 RCPT	81205	1	22-22-11 E004-01/ /	001-099
D41781J	1	BACC45FN20-41P8 RCPT	81205	1	22-22-11 E4-1/ /	115-199
D41781P	1	BACC45FT20A41S8 PLUG-	81205	1	22-22-11 E004-01/ /	ALL
D41782J	1	BACC45FN12-12P7 RCPT-	81205	1	22-33-11 E2-3/ /	001-099
D41782J	1	BACC45FN20-16P7 RCPT-	81205	1	22-33-11 E2-3/ /	115-199
D41782P	1	BACC45FT12A12S7 PLUG	81205	1	22-33-11 E002-03/ /	001-099
D41782P	1	BACC45FT20A16S7 PLUG	81205	1	22-33-11 E002-03/ /	115-199
D41783J	1	BACC45FN16-24P6 RCPT	81205	1	22-22-11 E003-01/ /	001-099
D41783J	1	BACC45FN20-41P6 RCPT	81205	1	22-22-11 E003-01/ /	115-199
D41783P	1	BACC45FT16A24S6 PLUG-	81205	1	22-22-11 E003-01/ /	001-099
D41783P	1	BACC45FT20A41S6 PLUG-	81205	1	22-22-11 E003-01/ /	115-199
D41784J	1	BACC45FN12-12P RCPT-	81205	1	22-33-11 E2-3/ /	001-099
D41784J	1	BACC45FN16-10P RCPT-	81205	1	22-33-11 E2-3/ /	115-199
D41784P	1	BACC45FT12A12S PLUG	81205	1	22-33-11 E2-3/ /	001-099
D41784P	1	BACC45FT16A10S PLUG	81205	1	22-33-11 E2-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41700

Page 13

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41785J	1	BACC45FN16-24P8 RCPT	81205	1	27-61-12 E004-01/ /	001-099
D41785J	1	BACC45FN16-24P8 RCPT	81205	1	27-61-12 E4-1/ /	115-199
D41785P	1	BACC45FT16A24S8 PLUG-	81205	1	27-21-12 E004-01/ /	ALL
D41787J	1	BACC45FN16-24P6 RCPT	81205	1	27-21-12 E003-01/ /	ALL
D41787P	1	BACC45FT16A24S6 PLUG-	81205	1	27-21-12 E003-01/ /	ALL
D41788J	1	BACC45FN18-31P7 RECPT-	81205	1	73-31-11 E4-2/ /	001-099
D41788J	1	BACC45FN18A31S7 RCPT-	81205	1	75-31-11 E4-2/ /	115-199
D41788P	1	BACC45FT18A31S7 PLUG	81205	1	75-31-11 E4-2/ /	001-099
D41788P	1	BACC45FT18A31P7 PLUG	81205	1	75-31-11 E4-2/ /	115-199
D41789J	1	BACC45FN12-12P8 RCPT-	81205	1	22-21-11 E003-01/ /	ALL
D41789P	1	BACC45FT12A12S8 PLUG-	81205	1	22-21-11 E3-1/ /	ALL
D41791J	1	BACC45FN12-12P8 RCPT-	81205	1	22-21-21 E004-01/ /	001-099
D41791J	1	BACC45FN12-12P8 RCPT-	81205	1	22-21-21 E4-1/ /	115-199
D41791P	1	BACC45FT12A12S8 PLUG-	81205	1	22-21-21 E4-1/ /	ALL
D41792J	1	BACC45FN12-12S9 RCPT-	81205	1	29-31-11 E4-2/ /	001-099
D41792J	1	BACC45FN16-24S9 RCPT-	81205	1	29-31-11 E4-2/ /	115-199
D41792P	1	BACC45FT12-12P9 PLUG	81205	1	29-31-11 E004-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D41700

Page 14

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41792P	1	BACC45FT16-24P9 PLUG	81205	1	29-31-11 E4-2/ /	115-199
D41793J	1	BACC45FN20-39S9 RCPT	81205	1	22-21-22 E004-01/ /	001-099
D41793J	1	BACC45FN20-39S9 RCPT	81205	1	22-21-22 E4-1/ /	115-199
D41793P	1	BACC45FT20A39P9 PLUG-	81205	1	27-21-22 E004-01/ /	001-099
D41793P	1	BACC45FT20A39P9 PLUG-	81205	1	27-21-22 E4-1/ /	115-199
D41794J	1	BACC45FN12-12S7 RCPT-	81205	1	29-31-11 E4-2/ /	001-099
D41794J	1	BACC45FN16-24S7 RCPT-	81205	1	29-31-11 E4-2/ /	115-199
D41794P	1	BACC45FT12-12P7 PLUG	81205	1	29-31-11 E004-02/ /	001-099
D41794P	1	BACC45FT16-24P7 PLUG	81205	1	29-31-11 E4-2/ /	115-199
D41795J	1	BACC45FN20-39S RCPT	81205	1	22-22-11 E003-01/ /	ALL
D41795P	1	BACC45FT20A39P PLUG-	81205	1	27-21-12 E003-01/ /	001-099
D41795P	1	BACC45FT20A39P PLUG-	81205	1	27-21-12 E3-1/ /	115-199
D41797J	1	BACC45FN14-15S RCPT-	81205	1	23-11-11 E6-3/ /	115-199
D41797P	1	BACC45FT14A15P PLUG-	81205	1	23-11-11 E6-3/ /	115-199
D41799J	1	BACC45FN14-15S RCPT-	81205	1	23-11-11 E6-3/ /	115-199
D41799P	1	BACC45FT14A15P PLUG-	81205	1	23-11-11 E6-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41700

Page 15 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41801J	1	KN-19-195-M06 RCPT-COAX		1	34-53-21 E003-02/ /	001-099
D41801J	1	KN-19-195-M06 RCPT	91836	1	34-53-21 E3-2/ /	115-199
D41801P	1	KN-59-329-M06 PLUG-		1	34-53-21 E003-02/ /	ALL
D41805J	1	KD-19-66 RCPT	91836	1	23-11-21 E6-3/ /	115-199
D41805P	1	KD-59-186-M06 PLUG	91836	1	23-11-21 E006-03/ /	115-199
D41807J	1	KD-19-66 RCPT-	91836	1	23-11-11 E6-3/ /	115-199
D41807P	1	KD-59-186-M06 PLUG-	91836	1	23-11-11 E6-3/ /	115-199
D41810J	1	BACC45FN14-15S RCPT-	81205	1	32-42-12 E2-1/ /	115-199
D41810P	1	BACC45FT14-15P PLUG	81205	1	32-42-12 E2-1/ /	115-199
D41812J	1	CN0967C16G24SN-000 RCPT-	13556	1	32-42-11 AC1090/ /	001-004
D41812J	1	BACC63CC16-24SN RCPT-	13556	1	32-42-11 AC1090/ /	005-099
D41812J	1	CN0967C16G24SN-000 RCPT-		1	32-42-11 AC1090/ /	115-199
D41812JK		BACC10HG16C CABLE CLAMP	81205	1	32-42-11 */*/	001-004, 115-199
D41812JK		BACC10HG16C CABLE CLAMP	06324	1	32-42-11 */*/	005-099
D41812P	1	CN0966A16G24PN-000 PLUG	13556	1	32-42-11 AC1090/ /	001-004
D41812P	1	BACC63CB16-24PN PLUG	81205	1	32-42-11 AC1090/ /	005-099
D41812P	1	CN0966A16G24PN-000 PLUG	81205	1	32-42-11 AC1090/ /	115-199

EQUIPMENT LIST

D280N032

Section D41800

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41812PQ		BACC10HG16C CABLE CLAMP	81205	1	32-42-11 */ */ *	ALL
D41813J	1	BACC45FN14-15S RCPT	81205	1	23-11-21 E6-3/ /	115-199
D41813P	1	BACC45FT14A15P PLUG	81205	1	23-11-21 E6-3/ /	115-199
D41814J	1	BACC45FN14-15S6 RCPT-	81205	1	33-21-21 930/300/R30	001-099
D41814J	1	BACC45FN10-5S RECP-	81205	1	33-21-22 930/300/R30	115-199
D41814P	1	BACC45FT14A15P6 PLUG-	81205	1	33-21-22 930/300/R30	001-099
D41814P	1	BACC45FT10A5P PLUG-	81205	1	33-21-22 930/300/R30	115-199
D41815J	1	BACC45FN20-41S7 RCPT-	81205	1	22-11-31 E2-3/ /	001-002
D41815J	1	BACC45FN22-55S7 RCPT-	81205	1	22-11-31 E002-03/ /	003-099
D41815J	1	BACC45FN22-55S7 RCPT-	81205	1	22-11-31 E2-3/ /	115-199
D41815P	1	BACC45FT20A41P7 PLUG-	81205	1	22-22-11 E002-03/ /	001-002
D41815P	1	BACC45FT22A55P7 PLUG-	81205	1	22-22-11 E002-03/ /	003-099, 115-199
D41816J	1	BACC45FN14-15S6 RCPT-	81205	1	33-21-22 1270/290/R40	001-099
D41816J	1	BACC45FN10-5S RECP-	81205	1	33-21-22 1230/300/R28	115-199
D41816P	1	BACC45FT14A15P6 PLUG-	81205	1	33-21-23 1270/290/R40	001-099
D41816P	1	BACC45FT10A5P PLUG-	81205	1	33-21-23 1230/300/R28	115-199
D41817J	1	BACC45FN18-31S9 RCPT-	81205	1	22-31-12 E002-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41800

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41817J	1	BACC45FN22-55S9 RCPT-	81205	1	22-31-12 E2-1/ /	115-199
D41817P	1	BACC45FT18A31P9 PLUG-	81205	1	22-31-12 E002-01/ /	001-099
D41817P	1	BACC45FT22A55P9 PLUG-	81205	1	22-31-12 E2-1/ /	115-199
D41818J	1	CN0967C18G14S6-000 RCPT-	13556	1	32-42-11 AD1090/ /	001-004
D41818J	1	BACC63CC18-14S6 RCPT-	81205	1	32-42-11 AD1090/ /	005-099
D41818J	1	CN0967C18G14S6-000 RCPT-		1	32-42-11 AD1090/ /	115-199
D41818JK		BACC10HG18C CABLE CLAMP	81205	1	32-42-11 */ /	ALL
D41818P	1	CN0966A18G14P6-000 PLUG	13556	1	32-42-11 AD1090/ /	001-004
D41818P	1	BACC63CB18-14P6 PLUG	81205	1	32-42-11 AD1090/ /	005-099
D41818P	1	CN0966A18G14P6-000 PLUG	81205	1	32-42-11 AD1090/ /	115-199
D41818PQ		BACC10HF18C CABLE CLAMP	81205	1	32-42-11 */ */	ALL
D41819J	1	BACC45FN16-24S8 RCPT-	81205	1	22-32-11 E002-03/ /	001-099
D41819J	1	BACC45FN22-55S8 RCPT-	81205	1	22-32-11 E2-3/ /	115-199
D41819P	1	BACC45FT16A24P8 PLUG-	81205	1	22-32-11 E002-03/ /	001-099
D41819P	1	BACC45FT22A55P8 PLUG-	81205	1	22-32-11 E2-3/ /	115-199
D41820J	1	BACC45FN12A12P8 RCPT-	81205	1	23-31-19 E004-03/ /	001-099
D41820P	1	BACC45FT12A12S8 PLUG-	81205	1	23-31-19 E004-03/ /	001-099

EQUIPMENT LIST

D280N032

Section D41800

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41821J	1	BACC45FN14-15S7 RCPT-	81205	1	34-12-22 E002-02/ /	001-099
D41821J	1	BACC45FN22-55S7 RCPT-	81205	1	34-12-22 E2-2/ /	115-199
D41821P	1	BACC45FT14A15P7 PLUG-	81205	1	22-32-11 E002-02/ /	001-099
D41821P	1	BACC45FT22A55P7 PLUG-	81205	1	22-32-11 E2-2/ /	115-199
D41823J	1	BACC45FN12-12S7 RCPT-	81205	1	22-32-11 E002-03/ /	001-099
D41823J	1	BACC45FN22-55S7 RCPT-	81205	1	22-32-11 E2-3/ /	115-199
D41823P	1	BACC45FT12A12P7 PLUG-	81205	1	22-32-11 E002-03/ /	001-099
D41823P	1	BACC45FT22A55P7 PLUG-	81205	1	22-32-11 E2-3/ /	115-199
D41828J	1	BACC45FN14-15S RCPT	81205	1	27-51-61 E005-03/ /	001-099
D41828J	1	BACC45FN14-15S RCPT	81205	1	27-51-61 E5-3/ /	115-199
D41828P	1	BACC45FT14-15P PLUG	81205	1	27-51-61 E005-03/ /	ALL
D41829J	1	BACC45FN14-15P6 RCPT-	81205	1	34-51-21 E2-2/ /	115-199
D41829P	1	BACC45FT14A15S6 PLUG	81205	1	34-51-21 E2-2/ /	115-199
D41830J	1	BACC45FN14-12P7 RCPT	81205	1	23-11-21 E6-3/ /	115-199
D41830P	1	BACC45FT14A12S7 PLUG	81205	1	23-11-21 E6-3/ /	115-199
D41831J	1	BACC45FN14-15P8 RCPT-	81205	1	34-22-19 E2-1/ /	115-199
D41831P	1	BACC45FT14A15S8 PLUG-	81205	1	34-51-11 E2-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D41800

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41833J	1	BACC45FN14-15P RCPT	81205	1	32-42-12 E6-4/ /	115-199
D41833P	1	BACC45FT14A15S PLUG	8105	1	32-42-12 E6-4/ /	115-199
D41834J	1	BACC45FN18-31S7 RCPT	81205	1	33-16-11 AP0003/ /	ALL
D41834P	1	BACC45FT18A31P7 PLUG	81205	1	33-16-11 217.6/198/R34	001-099
D41834P	1	BACC45FT18A31P7 PLUG	81205	1	23-73-01 AP0003/ /	115-199
D41835J	1	BACC45FN14-15S7 RCPT	81205	1	27-48-21 P50/ /	ALL
D41835P	1	BACC45FT14A15P7 PLUG-	81205	1	27-48-21 P050-00/ /	ALL
D41837J	1	BACC45FN14-15S8 RCPT	81205	1	27-48-21 P50/ /	ALL
D41837P	1	BACC45FT14A15P8 PLUG-	81205	1	27-48-21 P050-00/ /	001-099
D41837P	1	BACC45FT14A15P8 PLUG-	81205	1	27-48-21 P50/ /	115-199
D41838J	1	BACC45FN12-12S9 RCPT	81205	1	27-41-11 E003-01/ /	001-099
D41838J	1	BACC45FN14-12S9 RCPT	81205	1	27-41-11 E003-01/ /	115-199
D41838P	1	BACC45FT12-12P9 PLUG	81205	1	22-24-11 E003-01/ /	001-099
D41838P	1	BACC45FT14-12P9 PLUG	81205	1	22-24-11 E3-1/ /	115-199
D41839J	1	BACC45FN14-15S RCPT	81205	1	27-48-21 P50/ /	ALL
D41839P	1	BACC45FT14A15P PLUG-	81205	1	27-48-21 P050-00/ /	001-099
D41839P	1	BACC45FT14A15P PLUG-	81205	1	27-48-21 P50/ /	115-199

EQUIPMENT LIST

D280N032

Section D41800

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41840J	1	BACC45FN12-12P RCPT-	81205	1	30-41-11 E4-2/ /	001-099
D41840J	1	BACC45FN22-55P RCPT-	81205	1	30-41-11 E4-2/ /	115-199
D41840P	1	BACC45FT12-12S PLUG	81205	1	30-41-11 E4-2/ /	001-099
D41840P	1	BACC45FT22-55S PLUG	81205	1	30-41-11 E4-2/ /	115-199
D41841J	1	BACC45FN14-15S8 RCPT	81205	1	27-31-12 E003-01/ /	ALL
D41841P	1	BACC45FT14A15P8 PLUG-	81205	1	27-41-11 E003-01/ /	ALL
D41842J	1	BACC45FN12-12P9 RCPT-	81205	1	30-11-11 E4-2/ /	001-099
D41842J	1	BACC45FN18-31P9 RCPT-	81205	1	30-11-11 E4-2/ /	115-199
D41842P	1	BACC45FT12A12S9 PLUG	81205	1	30-11-11 E004-02/ /	001-099
D41842P	1	BACC45FT18A31S9 PLUG	81205	1	30-11-11 E004-02/ /	115-199
D41843J	1	BACC45FN14-15S7 RCPT	81205	1	27-41-21 E004-01/ /	001-099
D41843J	1	BACC45FN14-15S7 RCPT	81205	1	27-41-21 E4-1/ /	115-199
D41843P	1	BACC45FT14A15P7 PLUG-	81205	1	22-23-22 E004-01/ /	001-099
D41843P	1	BACC45FT14A15P7 PLUG-	81205	1	22-23-22 E4-1/ /	115-199
D41844J	1	BACC45FN16-24S6 RCPT-	81205	1	21-58-12 E4-2/ /	001-099
D41844J	1	BACC45FN20-39S7 RCPT-	81205	1	21-58-12 E4-2/ /	115-199
D41844P	1	BACC45FT16-24P6 PLUG	81205	1	21-58-12 E004-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D41800

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41844P	1	BACC45FT20-39P7 PLUG	81205	1	21-58-12 E4-2/ /	115-199
D41845J	1	BACC45FN22-55S8 RCPT	81205	1	21-51-12 E6 RLY/PNL/	115-199
D41845P	1	BACC45FT22-55P8 PLUG	81205	1	21-51-12 E6-0/ /	115-199
D41846J	1	BACC45FN20-39S RCPT	81205	1	33-13-11 AP0001/ /	ALL
D41846P	1	BACC45FT20A39P PLUG	81205	1	33-13-11 P1/ /	001-099
D41846P	1	BACC45FT20A39P PLUG	81205	1	33-13-11 P1-1/ /	115-199
D41848J	1	BACC45FN20-39S RCPT	81205	1	23-31-13 P034-00/ /	001-099
D41848J	1	BACC45FN20-39S RCPT	81205	1	23-31-13 P34/ /	115-199
D41848P	1	BACC45FT20A39P PLUG	81205	1	33-42-11 P034-00/ /	001-099
D41848P	1	BACC45FT20A39P PLUG	81205	1	33-42-11 P34/ /	115-199
D41850J	1	BACC45FN22-55P6 RCPT	81205	1	21-58-11 P36/ /	ALL
D41850P	1	BACC45FT22-55S6 PLUG	81205	1	24-11-11 P036-00/ /	001-099
D41850P	1	BACC45FT22-55S6 PLUG	81205	1	24-11-11 P36/ /	115-199
D41851J	1	KN-19-195-M06 RCPT	91836	1	34-53-11 E3-3/ /	ALL
D41851P	1	KN-59-329-M06 PLUG-		1	34-53-11 E003-03/ /	ALL
D41852J	1	BACC45FN18-31P7 RCPT	81205	1	21-61-11 P37/ /	ALL
D41852P	1	BACC45FT18-31S7 PLUG	81205	1	21-61-11 P37/ /	ALL

EQUIPMENT LIST

D280N032

Section D41800

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41854J	1	BACC45FN18-31P7 RCPT	81205	1	21-51-51 P37/ /	ALL
D41854P	1	BACC45FT18A31S7 PLUG	81205	1	36-11-31 P037-00/ /	001-099
D41854P	1	BACC45FT18A31S7 PLUG	81205	1	36-11-31 P37/ /	115-199
D41855J	1	BACC45FN22-55S RCPT	81205	1	21-51-22 E6 RLY/PNL/	115-199
D41855P	1	BACC45FT22-55P PLUG	81205	1	21-51-22 E6-0/ /	115-199
D41856J	1	BACC45FN22-55P8 RCPT	81205	1	21-25-21 P37/ /	ALL
D41856P	1	BACC45FT22-55S8 PLUG	81205	1	28-42-11 P037-00/ /	001-099
D41856P	1	BACC45FT22-55S8 PLUG	81205	1	28-42-11 P37/ /	115-199
D41858J	1	BACC45FN18-31P7 RCPT	81205	1	21-58-12 P37/ /	ALL
D41858P	1	BACC45FT18-31S7 PLUG	81205	1	35-21-11 P037-00/ /	001-099
D41858P	1	BACC45FT18-31S7 PLUG	81205	1	35-21-11 P37/ /	115-199
D41860J	1	BACC45FN18-31P9 RCPT	81205	1	21-58-11 P37/ /	ALL
D41860P	1	BACC45FT18-31S9 PLUG	81205	1	21-58-13 P037-00/ /	001-099
D41860P	1	BACC45FT18-31S9 PLUG	81205	1	21-58-13 P37/ /	115-199
D41862J	1	BACC45FN14-15S9 RCPT	81205	1	27-61-12 E004-01/ /	001-099
D41862J	1	BACC45FN14-15S9 RCPT	81205	1	27-61-12 E4-1/ /	115-199
D41862P	1	BACC45FT14-15P9 PLUG	81205	1	22-21-21 E004-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41800

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41862P	1	BACC45FT14-15P9 PLUG	81205	1	22-21-21 E004-011/ /	115-199
D41864J	1	BACC45FN22-55P9 RCPT	81205	1	34-33-11 E5-1/ /	ALL
D41864P	1	BACC45FT22-55S9 PLUG	81205	1	21-31-11 E005-01/ /	001-099
D41864P	1	BACC45FT22-55S9 PLUG	81205	1	21-31-11 E5-1/ /	115-199
D41867J		BACC45FN22-55S RCPT-	81205	1	76-11-12 E4-2/ /	001-099
D41867J	1	BACC45FN22-55S RCPT-	81205	1	76-11-12 E4-2/ /	115-199
D41867P	1	BACC45FT22A55P PLUG-	81205	1	76-11-12 E004-02/ /	001-099
D41867P	1	BACC45FT22A55P PLUG-	81205	1	76-11-12 E4-2/ /	115-199
D41868J	1	BACC45FN18-31S RCPT	81205	1	24-22-41 E005-03/ /	001-099
D41868J	1	BACC45FN18-31S RCPT	81205	1	24-22-41 E5-3/ /	115-199
D41868P	1	BACC45FT18-31P PLUG	81205	1	24-22-41 E005-03/ /	001-099
D41868P	1	BACC45FT18-31P PLUG	81205	1	24-22-41 E5-3/ /	115-199
D41870J	1	BACC45FN18-31P8 RCPT	81205	1	28-22-11 P33/ /	ALL
D41870P	1	BACC45FT18-31S8 PLUG	81205	1	28-22-11 P033-00/ /	001-099
D41870P	1	BACC45FT18-31S8 PLUG	81205	1	28-22-11 P33/ /	115-199
D41872J	1	BACC45FN18-31P8 RCPT	81205	1	30-41-11 E001-01/ /	ALL
D41872P	1	BACC45FT18-31S8 PLUG	81205	1	30-41-11 E001-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D41800

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41872P	1	BACC45FT18-31S8 PLUG	81205	1	30-41-12 E001-01/ /	115-199
D41874J	1	BACC45FN22-55P8 RCPT	81205	1	30-41-11 E001-02/ /	ALL
D41874P	1	BACC45FT22-55S8 PLUG	81205	1	30-41-11 E1-2/ /	ALL
D41876J	1	BACC45FN18-31P6 RCPT	81205	1	28-41-11 E003-04/ /	001-099
D41876J	1	BACC45FN22-55P8 RCPT	81205	1	28-41-11 E003-04/ /	115-199
D41876P	1	BACC45FT18-31S6 PLUG	81205	1	28-41-11 E003-04/ /	001-099
D41876P	1	BACC45FT22-55S8 PLUG	81205	1	28-41-11 E3-4/ /	115-199
D41878J	1	BACC45FN20-39S RCPT	81205	1	33-11-11 AP0003/ /	ALL
D41878P	1	BACC45FT20A39P PLUG	81205	1	33-16-21 217.6/198/R34	001-099
D41878P	1	BACC45FT20A39P PLUG	81205	1	33-16-21 AP0003/ /	115-199
D41879J	1	BACC45FN22-55S9 RCPT-	81205	1	32-61-12 E4-2/ /	ALL
D41879P	1	BACC45FT22A55P9 PLUG-	81205	1	32-61-12 E004-02/ /	001-099
D41879P	1	BACC45FT22A55P9 PLUG-	81205	1	32-61-12 E4-2/ /	115-199
D41880J	1	BACC45FN20-39S6 RCPT-	81205	1	21-45-11 P070-00/ /	001-099
D41880J	1	BACC45FN20-39S6 RCPT-	81205	1	21-45-11 P70/ /	115-199
D41880P	1	BACC45FT20D39P6 PLUG-	81205	1	21-44-11 P70/ /	ALL
D41881J	1	BACC45FN22-55S RCPT-	81205	1	34-61-22 E002-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D41800

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41881J	1	BACC45FN22-55S RCPT-	81205	1	34-61-22 E2-2/ /	115-199
D41881P	1	BACC45FT22A55P PLUG-	81205	1	34-21-21 E002-02/ /	001-099
D41881P	1	BACC45FT22A55P PLUG-	81205	1	34-21-21 E2-2/ /	115-199
D41882J	1	BACC45FN14-12P8 RCPT	81205	1	27-51-41 E5-1/ /	ALL
D41882P	1	BACC45FT14-12S8 PLUG-	81205	1	27-51-41 E005-01/ /	001-099
D41882P	1	BACC45FT14-12S8 PLUG-	81205	1	27-51-41 E5-1/ /	115-199
D41883J	1	BACC45FN22-55S RCPT	81205	1	21-31-21 E5-2/ /	ALL
D41883P	1	BACC45FT22A55P PLUG-	81205	1	34-21-31 E005-02/ /	001-099
D41883P	1	BACC45FT22A55P PLUG-	81205	1	34-21-31 E5-2/ /	115-199
D41884J	1	BACC45FN12-12P RCPT-	81205	1	22-11-31 E002-03/ /	001-099
D41884J	1	BACC45FN14-15P RCPT-	81205	1	22-11-31 E2-3/ /	115-199
D41884P	1	BACC45FT12-12S PLUG-	81205	1	22-11-32 E2-3/ /	001-099
D41884P	1	BACC45FT14-15S PLUG-	81205	1	22-11-32 E2-3/ /	115-199
D41888J	1	BACC45FN12-12P9 RCPT-	81205	1	22-11-31 E002-03/ /	001-099
D41888J	1	BACC45FN12-12P9 RCPT-	81205	1	22-11-31 E2-3/ /	115-199
D41888P	1	BACC45FT12-12S9 PLUG-	81205	1	22-11-32 E002-03/ /	001-099
D41888P	1	BACC45FT12-12S9 PLUG-	81205	1	22-11-32 E2-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41800

Page 11

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41890J	1	BACC45FN12-12P8 RCPT-	81205	1	34-21-31 E002-03/ /	001-099
D41890J	1	BACC45FN14-15P8 RCPT-	81205	1	34-21-31 E2-3/ /	115-199
D41890P	1	BACC45FT12-12S8 PLUG-	81205	1	22-11-32 E002-03/ /	001-099
D41890P	1	BACC45FT14-15S8 PLUG-	81205	1	22-11-32 E2-3/ /	115-199
D41891J	1	BACC45FN10A5S RCPT	81205	1	23-42-11 675/300/L30	115-199
D41892J	1	BACC45FN14-15P6 RCPT	81205	1	34-33-31 E005-03/ /	001-099
D41892J	1	BACC45FN14-15P6 RCPT	81205	1	34-33-31 E5-3/ /	115-199
D41892P	1	BACC45FT14-15S6 PLUG-	81205	1	34-33-31 E005-03/ /	001-099
D41892P	1	BACC45FT14-15S6 PLUG-	81205	1	34-33-31 E5-3/ /	115-199
D41893J	1	BACC45FN10A5S RCPT-	81205	1	23-42-11 1633/300/L025	001-099
D41893J	1	BACC45FN10A5S RCPT	81205	1	23-42-11 1630/300/L25	115-199
D41893P	1	BACC45FT10-5P PLUG-	81205	1	23-42-11 1638/300/L025	ALL
D41893PQ		BACC10GH10 CLAMP-	81205	1	23-42-11 */*/*	ALL
D41894J	1	BACC45FN14-12P RCPT	81205	1	24-11-11 E5-1/ /	ALL
D41894P	1	BACC45FT14-12S PLUG-	81205	1	24-11-11 E005-01/ /	ALL
D41896J	1	BACC45FN14-15P9 RCPT	81205	1	24-22-41 E005-03/ /	001-099
D41896J	1	BACC45FN14-15P9 RCPT	81205	1	24-22-41 E5-3/ /	115-199

EQUIPMENT LIST

D280N032

Section D41800

Page 12

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41896P	1	BACC45FT14-15S9 PLUG-	81205	1	24-22-41 E005-03/ /	ALL
D41898J	1	BACC45FN22-32S6 RCPT	81205	1	24-21-11 E5-1/ /	ALL
D41898P	1	BACC45FT22-32P6 PLUG-	81205	1	24-11-11 E005-01/ /	001-099
D41898P	1	BACC45FT22-32P6 PLUG-	81205	1	24-11-11 E5-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D41800
Page 13 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41900J	1	BACC45FN22-55P RCPT	81205	1	24-23-12 E005-03/ /	001-099
D41900J	1	BACC45FN22-55P RCPT	81205	1	24-23-12 E5-3/ /	115-199
D41900P	1	BACC45FT22-55S PLUG-	81205	1	24-21-41 E005-03/ /	ALL
D41902J	1	BACC45FN12-12P7 RCPT	81205	1	27-32-11 E003-01/ /	001-099
D41902J	1	BACC45FN14-15P7 RCPT	81205	1	27-32-11 E003-01/ /	115-199
D41902P	1	BACC45FT12-12S7 PLUG-	81205	1	27-32-11 E003-01/ /	001-099
D41902P	1	BACC45FT14-15S7 PLUG-	81205	1	27-32-11 E3-1/ /	115-199
D41904J	1	BACC45FN14-15S6 RCPT-	81205	1	26-21-11 P6/ /	001-002, 115-199
D41904J	1	BACC45FN16-24S6 RCPT-	81205	1	26-21-11 P6/ /	003-099
D41904P	1	BACC45FT14-15P6 PLUG	81205	1	26-21-11 P006-00/ /	001-002, 115-199
D41904P	1	BACC45FT16-24P6 PLUG	81205	1	26-21-11 P006-00/ /	003-099
D41905J	1	BACC45FN22-55S9 RCPT	81205	1	31-31-12 E002-01/ /	001-099
D41905J	1	BACC45FN22-55S9 RCPT	81205	1	31-31-12 E2-1/ /	115-199
D41905P	1	BACC45FT22A55P9 PLUG-	81205	1	34-12-61 E002-01/ /	001-099
D41905P	1	BACC45FT22A55P9 PLUG-	81205	1	34-12-61 E2-1/ /	115-199
D41907J	1	BACC45FN20-41S6 RCPT-	81205	1	34-12-62 E002-02/ /	001-099
D41907J	1	BACC45FN22-55S6 RCPT-	81205	1	34-12-62 E2-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D41900

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41907P	1	BACC45FT20A41P6 PLUG-	81205	1	34-61-25 E002-02/ /	001-099
D41907P	1	BACC45FT22A55P6 PLUG	81205	1	34-12-22 E2-2/ /	115-199
D41908J	1	BACC45FN14-12P6 RCPT	81205	1	34-51-21 E6-1/ /	115-199
D41908P	1	BACC45FT14-12S6 PLUG-	81205	1	34-51-21 E6-1/ /	115-199
D41909J	1	BACC45FN22-55S8 RCPT	81205	1	34-12-62 P37/ /	ALL
D41909P	1	BACC45FT22A55P8 PLUG-	81205	1	34-12-62 P037-00/ /	001-099
D41909P	1	BACC45FT22A55P8 PLUG-	81205	1	34-12-62 P37/ /	115-199
D41910J	1	BACC45FN14-15P RCPT-	81205	1	22-11-11 E002-01/ /	001-008
D41910J	1	BACC45FN16-24P RCPT-	81205	1	22-11-11 E002-01/ /	009-099
D41910J	1	BACC45FN14-15P8 RCPT-	81205	1	22-11-11 E2-1/ /	115-199
D41910P	1	BACC45FT14-15S PLUG-	81205	1	22-11-11 E002-01/ /	001-008
D41910P	1	BACC45FT16-24S PLUG-	81205	1	22-11-11 E002-01/ /	009-099
D41910P	1	BACC45FT14-15S8 PLUG-	81205	1	22-11-11 E2-1/ /	115-199
D41912J	1	BACC45FN10-5P6 RCPT	81205	1	24-21-41 E5-1/ /	001-099
D41912P	1	BACC45FT10A5S6 PLUG	81205	1	24-22-41 E005-01/ /	001-099
D41914J	1	BACC45FN20-25P9 RCPT	81205	1	30-41-11 E1-2/ /	ALL
D41914P	1	BACC45FT20-25S9 PLUG-	81205	1	30-41-11 E001-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D41900

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41914P	1	BACC45FT20-25S9 PLUG-	81205	1	30-41-11 E1-2/ /	115-199
D41916J	1	BACC45FN10-5P7 RCPT-	81205	1	34-21-21 E002-04/ /	001-099
D41916J	1	BACC45FN14-12P7 RCPT	81205	1	34-21-21 E2-4/ /	115-199
D41916P	1	BACC45FT10-5S7 PLUG-	81205	1	34-21-21 E2-4/ /	001-099
D41916P	1	BACC45FT14-12S7 PLUG-	81205	1	34-21-21 E2-4/ /	115-199
D41917J	1	KD-19-68 RCPT	81205	1	34-32-11 E6-1/ /	115-199
D41917P	1	KD-59-186-M06 PLUG-	91836	1	34-32-11 E6-1/ /	115-199
D41918J	1	BACC45FN14-15P6 RCPT	81205	1	27-09-11 E004-01/ /	001-099
D41918J	1	BACC45FN14-15P6 RCPT	81205	1	27-09-11 E4-1/ /	115-199
D41918P	1	BACC45FT14A15S6 PLUG-	81205	1	27-41-21 E4-1/ /	ALL
D41920J	1	BACC45FN10-5P RCPT	81205	1	24-21-41 E5-1/ /	001-099
D41920P	1	BACC45FT10A5S PLUG	81205	1	24-22-41 E005-01/ /	001-099
D41922J	1	BACC45FN20-16S RCPT	81205	1	52-34-11 P065-00/ /	ALL
D41922P	1	BACC45FT20-16P PLUG-	81205	1	52-34-11 P65/ /	ALL
D41924J	1	BACC45FN16-24S9 RCPT	81205	1	21-31-11 E5-1/ /	ALL
D41924P	1	BACC45FT16-24P9 PLUG	81205	1	21-31-11 E005-01/ /	ALL
D41926J	1	BACC45FN22-32P7 RCPT-	81205	1	52-34-11 P65/ /	001-099

EQUIPMENT LIST

D280N032

Section D41900

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41926J	1	BACC45FN22-32P7 RCPT-	81205	1	52-34-11 AP0065/ /	115-199
D41926P	1	BACC45FT22-32S7 PLUG-	81205	1	25-51-11 P65/ /	ALL
D41928J	1	BACC45FN14-15S6 RCPT	81205	1	52-34-11 E003-04/ /	001-099
D41928J	1	BACC45FN16-24S6 RCPT	81205	1	52-34-11 E003-04/ /	115-199
D41928P	1	BACC45FT14-15P6 PLUG	81205	1	52-34-11 E003-04/ /	001-099
D41928P	1	BACC45FT16-24P6 PLUG	81205	1	52-34-11 E003-04/ /	115-199
D41930J	1	BACC45FN14-15S8 RCPT	81205	1	52-34-11 E003-04/ /	001-099
D41930J	1	BACC45FN16-24S8 RCPT	81205	1	52-34-11 E3-4/ /	115-199
D41930P	1	BACC45FT14-15P8 PLUG	81205	1	52-71-21 E003-04/ /	001-099
D41930P	1	BACC45FT16-24P8 PLUG	81205	1	52-71-21 E003-04/ /	115-199
D41932J	1	BACC45FN20-25S7 RCPT	81205	1	52-35-11 E6 RLY/PNL/	001-099
D41932J	1	BACC45FN22-32S7 RCPT	81205	1	52-35-11 E6/ /	115-199
D41932P	1	BACC45FT20-25P7 PLUG-	81205	1	52-35-11 E6/ /	001-099
D41932P	1	BACC45FT22-32P7 PLUG-	81205	1	52-35-11 E6/ /	115-199
D41934J	1	BACC45FN20-25S RCPT	81205	1	21-25-11 P070-00/ /	ALL
D41934P	1	BACC45FT20D25P PLUG	81205	1	21-25-11 P070-00/ /	ALL
D41936J	1	BACC45FN14-15P RCPT	81205	1	26-11-11 P54/ /	ALL

EQUIPMENT LIST

D280N032

Section D41900

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41936P	1	BACC45FT14A15S PLUG	81205	1	77-22-12 P054-00/ /	ALL
D41938J	1	BACC45FN16-24S7 RCPT	81205	1	74-31-11 P36/ /	001-099
D41938J	1	BACC45FN16-24P7 RCPT	81205	1	74-31-11 P36/ /	115-199
D41938P	1	BACC45FT16A24P7 PLUG	81205	1	80-11-11 P036-00/ /	001-099
D41938P	1	BACC45FT16A24S7 PLUG	81205	1	80-11-11 P036-00/ /	115-199
D41940J	1	BACC45FN14-15P6 RECT		1	26-11-21 P54/ /	ALL
D41940P	1	BACC45FT14A15S6 PLUG	81205	1	77-22-13 P054-00/ /	ALL
D41942J	1	BACC45FN20-25S8 RCPT	81205	1	21-44-11 P070-00/ /	ALL
D41942P	1	BACC45FT20D25P8 PLUG	81205	1	21-43-11 P070-00/ /	ALL
D41944J	1	BACC45FN22-55P RCPT	81205	1	26-11-11 P54/ /	ALL
D41944P	1	BACC45FT22-55S PLUG	81205	1	77-22-12 P054-00/ /	ALL
D41946J	1	BACC45FN22-55S7 RCPT	81205	1	26-11-11 P54/ /	ALL
D41946P	1	BACC45FT22-55P7 PLUG	81205	1	26-11-21 P054-00/ /	ALL
D41948J	1	BACC45FN22-55P RCPT	81205	1	80-11-11 P36/ /	ALL
D41948P	1	BACC45FT22-55S PLUG	81205	1	80-11-11 P036-00/ /	ALL
D41950J	1	BACC45FN14-15P6 RCPT	81205	1	28-22-21 P33/ /	ALL
D41950P	1	BACC45FT14-15S6 PLUG-	81205	1	28-22-21 P033-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D41900

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41956J	1	BACC45FN14-15P8 RCPT-	81205	1	31-31-51 E3-3/ /	001-099
D41956J	1	BACC45FN14-15P8 RCPT-	81205	1	31-31-13 E3-3/ /	115-199
D41956JK		BACA14BH12 ADAPTER	81205	1	31-31-13 E3-3/ /	001-099
D41956P	1	BACC45FT14-15S8 PLUG	81205	1	78-36-11 E003-03/ /	001-099
D41956P	1	BACC45FT14-15S8 PLUG	81205	1	78-36-11 E3-3/ /	115-199
D41958J	1	BACC45FN22-55P9 RCPT	81205	1	74-31-11 P36/ /	ALL
D41958P	1	BACC45FT22-55S9 PLUG	81205	1	78-36-11 P036-00/ /	001-099
D41958P	1	BACC45FT22-55S9 PLUG	81205	1	78-36-11 P36/ /	115-199
D41962J	1	BACC45FN14-12P6 RCPT	81205	1	34-51-11 E6-1/ /	115-199
D41962P	1	BACC45FT14-12S6 PLUG-	81205	1	49-61-11 E6-1/ /	115-199
D41964J	1	BACC45FN12-12P7 RCPT	81205	1	27-09-11 E003-01/ /	001-099
D41964J	1	BACC45FN14-15P7 RCPT	81205	1	27-09-11 E003-01/ /	115-199
D41964P	1	BACC45FT12-12S7 PLUG-	81205	1	27-09-11 E3-1/ /	001-099
D41964P	1	BACC45FT14-15S7 PLUG-	81205	1	27-09-11 E3-1/ /	115-199
D41966J	1	BACC45FN14-15P6 RCPT	81205	1	27-51-61 E005-03/ /	001-099
D41966J	1	BACC45FN14-15P6 RCPT	81205	1	27-51-61 E5-3/ /	115-199
D41966P	1	BACC45FT14-15S6 PLUG-	81205	1	27-51-61 E5-3/ /	ALL

EQUIPMENT LIST

D280N032

Section D41900

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41968J	1	BACC45FN20-28P7 RCPT-	81205	1	26-16-21 P070-00/ /	001-099
D41968J	1	BACC45FN20-28P7 RCPT-	81205	1	26-16-21 P70/ /	115-199
D41968P	1	BACC45FT20D28S7 PLUG-	81205	1	27-51-61 P70/ /	ALL
D41970J	1	BACC45FN14-12S7 RCPT-	81205	1	27-48-21 P011-00/ /	ALL
D41970P	1	BACC45FT14-12P7 PLUG-	81205	1	27-51-21 P011-00/ /	001-099
D41970P	1	BACC45FT14-12P7 PLUG-	81205	1	27-51-21 P11/ /	115-199
D41972J	1	BACC45FN24-43S RCPT-	81205	1	35-21-11 P011-00/ /	ALL
D41972P	1	BACC45FT24-43P PLUG-	81205	1	35-21-11 P011-00/ /	001-099
D41972P	1	BACC45FT24-43P PLUG-	81205	1	35-21-11 P11/ /	115-199
D41974J	1	BACC45FN14-15P8 RCPT-	81205	1	23-11-11 E6-3/ /	115-199
D41974P	1	BACC45FT14A15S8 PLUG-	81205	1	23-11-11 E6-3/ /	115-199
D41986J	1	BACC45FN16-24P6 RCPT	81205	1	26-11-11 P54/ /	ALL
D41986P	1	BACC45FT16-24S6 PLUG	81205	1	26-15-11 P054-00/ /	001-099
D41986P	1	BACC45FT16-24S6 PLUG	81205	1	26-15-11 P54/ /	115-199
D41988J	1	BACC45FN20-16P6 RCPT	81205	1	75-31-11 P36/ /	ALL
D41988P	1	BACC45FT20A16S6 PLUG	81205	1	75-31-11 P036-00/ /	ALL
D41990J	1	BACC45FN22-55S RCPT	81205	1	78-34-21 P50/ /	ALL

EQUIPMENT LIST

D280N032

Section D41900

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41990P	1	BACC45FT22-55P PLUG	81205	1	80-11-21 P050-00/ /	ALL
D41992J	1	BACC45FN14-15P8 RCPT	81205	1	26-11-21 P54/ /	ALL
D41992P	1	BACC45FT14-15S8 PLUG	81205	1	26-11-22 P054-00/ /	001-099
D41992P	1	BACC45FT14-15S8 PLUG	81205	1	26-11-22 P54/ /	115-199
D41993J	1	BACC45FN16-24S7 RCPT	81205	1	34-57-21 E006-01/ /	001-099
D41993J	1	BACC45FN16-24S7 RCPT	81205	1	34-57-21 E6-1/ /	115-199
D41993P	1	BACC45FT16A24P7 PLUG	81205	1	34-57-21 E6-1/ /	ALL
D41994J	1	BACC45FN20-41S RCPT	81205	1	74-31-21 P37/ /	001-002, 115-199
D41994J	1	BACC45FN22-55S RCPT	81205	1	74-31-21 P37/ /	003-099
D41994P	1	BACC45FT20-41P PLUG	81205	1	74-31-21 P037-00/ /	001-002
D41994P	1	BACC45FT22-55P PLUG	81205	1	74-31-21 P037-00/ /	003-099
D41994P	1	BACC45FT20-41P PLUG	81205	1	74-31-21 P37/ /	115-199
D41995J	1	KD-19-68 RCPT	81205	1	34-51-11 E6-1/ /	115-199
D41995P	1	KD-59-186-M06 PLUG	91836	1	34-51-11 E6-1/ /	115-199
D41997J	1	KD-19-68 RCPT	81205	1	34-51-21 E6-1/ /	115-199
D41997P	1	KD-59-186-M06 PLUG	91836	1	34-51-21 E6-1/ /	115-199
D41998J	1	BACC45FN16-10P8 RCPT	81205	1	75-31-11 P37/ /	001-099

EQUIPMENT LIST

D280N032

Section D41900

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D41998J	1	BACC45FN16-10P7 RCPT	81205	1	78-36-11 P37/ /	115-199
D41998P	1	BACC45FT16A10S8 PLUG	81205	1	75-31-11 P37/ /	001-099
D41998P	1	BACC45FT16A10S7 PLUG	81205	1	75-31-11 P37/ /	115-199
D41999J	1	BACC45FN16-24S8 RCPT	81205	1	34-51-11 E6-1/ /	115-199
D41999P	1	BACC45FT16A24P8 PLUG	81205	1	34-57-11 E6-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D41900

Page 9 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42000J	1	BACC45FN16-24P9 RCPT	81205	1	80-11-11 P50/ /	ALL
D42000P	1	BACC45FT16-24S9 PLUG	81205	1	26-18-11 P050-00/ /	001-099
D42000P	1	BACC45FT16-24S9 PLUG	81205	1	26-18-11 P50/ /	115-199
D42001J	1	BACC45FN14-15P RCPT-	81205	1	34-51-11 E6-1/ /	115-199
D42001P	1	BACC45FT14A15S PLUG	81205	1	34-51-11 E6-1/ /	115-199
D42002J	1	BACC45FN16-24P8 RCPT	81205	1	80-11-21 P50/ /	ALL
D42002P	1	BACC45FT16-24S8 PLUG	81205	1	26-18-21 P050-00/ /	001-099
D42002P	1	BACC45FT16-24S8 PLUG	81205	1	26-18-21 P50/ /	115-199
D42003J	1	BACC45FN14-15P7 RCPT-	81205	1	34-51-21 E6-1/ /	115-199
D42003P	1	BACC45FT14A15S7 PLUG	81205	1	34-51-21 E6-1/ /	115-199
D42004J	1	BACC45FN16-24S8 RCPT	81205	1	77-12-41 P50/ /	ALL
D42004P	1	BACC45FT16-24P8 PLUG	81205	1	80-11-11 P050-00/ /	ALL
D42005J	1	BACC45FN16-24P RCPT-	81205	1	34-57-11 E006-01/ /	001-099
D42005J	1	BACC45FN14-15P7 RCPT-	81205	1	34-57-11 E6-1/ /	115-199
D42005P	1	BACC45FT16A24S PLUG-	81205	1	34-57-11 E006-01/ /	001-099
D42005P	1	BACC45FT14A15S7 PLUG-	81205	1	34-57-11 E006-01/ /	115-199
D42006J	1	BACC45FN18-31P RCPT	81205	1	28-22-31 P33/ /	ALL

EQUIPMENT LIST

D280N032

Section D42000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42006P	1	BACC45FT18-31S PLUG-	81205	1	28-22-21 P033-00/ /	ALL
D42007J	1	BACC45FN14-15P9 RCPT-	81205	1	34-57-21 E6-1/ /	115-199
D42007P	1	BACC45FT14A15S9 PLUG-	81205	1	34-57-21 E6-1/ /	115-199
D42008J	1	BACC45FN18-31S7 RCPT	81205	1	74-31-21 P37/ /	001-099
D42008J	1	BACC45FN18-31P8 RCPT	81205	1	74-31-21 P37/ /	115-199
D42008P	1	BACC45FT18A31P7 PLUG	81205	1	80-11-21 P037-00/ /	001-099
D42008P	1	BACC45FT18A31S8 PLUG	81205	1	80-11-21 P037-00/ /	115-199
D42010J	1	BACC45FN20-41P9 RCPT	81205	1	76-11-12 P37/ /	ALL
D42010P	1	BACC45FT20-41S9 PLUG	81205	1	80-11-21 P037-00/ /	ALL
D42011J	1	BACC45FN20-41S RCPT-	81205	1	34-12-11 E002-01/ /	001-099
D42011J	1	BACC45FN22-55S RCPT-	81205	1	34-12-11 E2-1/ /	115-199
D42011P	1	BACC45FT20A41P PLUG	81205	1	34-12-11 E002-01/ /	001-099
D42011P	1	BACC45FT22A55P PLUG	81205	1	34-12-11 E2-1/ /	115-199
D42012J	1	BACC45FN16-24P6 RCPT	81205	1	78-34-11 E003-04/ /	ALL
D42012P	1	BACC45FT16-24S6 PLUG	81205	1	78-34-11 E003-04/ /	ALL
D42013J	1	BACC45FN22-55S6 RCPT-	81205	1	22-14-11 E002-01/ /	001-099
D42013J	1	BACC45FN22-55S6 RCPT-	81205	1	22-14-11 E2-1/ /	115-199

EQUIPMENT LIST

D280N032

Section D42000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42013P	1	BACC45FT22A55P6 PLUG-	81205	1	22-14-11 E002-01/ /	001-099
D42013P	1	BACC45FT22A55P6 PLUG-	81205	1	22-14-11 E2-1/ /	115-199
D42014J	1	BACC45FN16-24P7 RCPT	81205	1	78-34-21 E003-04/ /	001-099
D42014J	1	BACC45FN18-31P7 RCPT	81205	1	78-34-21 E003-04/ /	115-199
D42014P	1	BACC45FT16-24S7 PLUG	81205	1	78-34-21 E003-04/ /	001-099
D42014P	1	BACC45FT18-31S7 PLUG	81205	1	78-34-21 E003-04/ /	115-199
D42015J	1	BACC45FN12-12S6 RCPT	81205	1	34-21-11 E002-04/ /	001-099
D42015J	1	BACC45FN14-15S6 RCPT	81205	1	34-21-11 E2-4/ /	115-199
D42015P	1	BACC45FT12A12P6 PLUG	81205	1	34-21-12 E002-04/ /	001-099
D42015P	1	BACC45FT14A15P6 PLUG	81205	1	34-21-12 E2-4/ /	115-199
D42016J	1	BACC45FN22-55P9 RCPT	81205	1	78-36-11 E003-04/ /	001-099
D42016J	1	BACC45FN18-31P9 RCPT	81205	1	78-36-11 E003-04/ /	115-199
D42016P	1	BACC45FT22-55S9 PLUG	81205	1	78-36-11 E003-04/ /	001-099
D42016P	1	BACC45FT18-31S9 PLUG	81205	1	78-36-11 E3-4/ /	115-199
D42018J	1	BACC45FN22-55P6 RCPT	81205	1	78-36-21 E003-04/ /	001-099
D42018J	1	BACC45FN20-41P6 RCPT	81205	1	78-36-21 E003-04/ /	115-199
D42018P	1	BACC45FT22-55S6 PLUG	81205	1	78-36-21 E003-04/ /	001-099

EQUIPMENT LIST

D280N032

Section D42000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42018P	1	BACC45FT20-41S6 PLUG	81205	1	78-36-21 E3-4/ /	115-199
D42019J	1	BACC45FN18-31S7 RCPT-	81205	1	34-53-11 E3-3/ /	ALL
D42019P	1	BACC45FT18A31P7 PLUG	81205	1	34-51-12 E003-03/ /	001-099
D42019P	1	BACC45FT18A31P7 PLUG	81205	1	34-51-12 E3-3/ /	115-199
D42020J	1	BACC45FN14-15P6 RCPT	81205	1	27-41-21 E004-01/ /	001-099
D42020J	1	BACC45FN12-12P6 RCPT	81205	1	27-41-21 E4-1/ /	115-199
D42020P	1	BACC45FT14-15S6 PLUG	81205	1	27-41-21 E004-01/ /	001-099
D42020P	1	BACC45FT12A12S6 PLUG	81205	1	27-41-11 E004-01/ /	115-199
D42021J	1	BACC45FN18-31S RCPT-	81205	1	22-14-11 E002-03/ /	001-099
D42021J	1	BACC45FN18-31S RCPT-	81205	1	22-14-11 E2-3/ /	115-199
D42021P	1	BACC45FT18A31P PLUG	81205	1	22-14-11 E002-03/ /	001-099
D42021P	1	BACC45FT18A31P PLUG	81205	1	22-14-11 E2-3/ /	115-199
D42023J	1	BACC45FN16-24S6 RCPT-	81205	1	77-12-11 E4-2/ /	001-099
D42023J	1	BACC45FN18-31S6 RCPT-	81205	1	77-12-11 E4-2/ /	115-199
D42023P	1	BACC45FT16A24P6 PLUG	81205	1	77-12-11 E004-02/ /	001-099
D42023P	1	BACC45FT18A31P6 PLUG	81205	1	77-12-11 E4-2/ /	115-199
D42026J	1	BACC45FN12-12P6 RCPT	81205	1	27-41-11 E003-01/ /	ALL

EQUIPMENT LIST

D280N032

Section D42000

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42026P	1	BACC45FT12-12S6 PLUG	81205	1	22-41-11 E003-01/ /	ALL
D42028J	1	BACC45FN14-15S7 RCPT	81205	1	29-33-11 E6-4/ /	115-199
D42028P	1	BACC45FT14-15P7 PLUG	81205	1	29-33-11 E6-4/ /	115-199
D42030J	1	BACC45FN14-12S7 RCPT	81205	1	28-22-31 P33/ /	001-099
D42030J	1	BACC45FN14-12S7 RCPT	81205	1	30-31-11 P33/ /	115-199
D42030P	1	BACC45FT14-12P7 PLUG	81205	1	30-31-11 P033-00/ /	ALL
D42031J	1	BACC45FN14-15S9 RCPT-	81205	1	23-11-11 E004-03/ /	001-099
D42031P	1	BACC45FT14A15P9 PLUG-	81205	1	23-11-11 E004-03/ /	001-099
D42032J	1	BACC45FN18-8S9 RCPT	81205	1	25-51-21 E6/ /	115-199
D42032P	1	BACC45FT18-8P9 PLUG-	81205	1	33-37-21 E6/ /	115-199
D42033J	1	BACC45FN14-15S RCPT-	81205	1	23-11-11 E004-03/ /	001-099
D42033P	1	BACC45FT14A15P PLUG-	81205	1	23-11-11 E4-3/ /	001-099
D42035J	1	BACC45FN18-31S6 RCPT-	81205	1	34-12-21 E002-02/ /	001-099
D42035J	1	BACC45FN22-55S6 RCPT-	81205	1	34-12-21 E2-2/ /	115-199
D42035P	1	BACC45FT18A31P6 PLUG	81205	1	34-12-21 E002-02/ /	001-099
D42035P	1	BACC45FT22A55P6 PLUG	81205	1	34-12-21 E002-02/ /	115-199
D42038J	1	BACC45FN20-25P9 RCPT	81205	1	25-51-21 E6 RLY/PNL/	ALL

EQUIPMENT LIST

D280N032

Section D42000

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42038P	1	BACC45FT20-25S9 PLUG	81205	1	25-51-21 E006-00/ /	ALL
D42039J	1	BACC45FN12-12S8 RCPT-	81205	1	34-12-61 E3-2/ /	115-199
D42039P	1	BACC63BN12-12P8 PLUG	81205	1	34-53-21 E3-2/ /	115-199
D42039PQ		BACC10GH-12 CABLE CLAMP	81205	1	34-53-21 E3-2/ /	115-199
D42041J	1	BACC45FN16-24S9 RCPT-	81205	1	77-11-11 E4-2/ /	001-099
D42041J	1	BACC45FN18-31S9 RCPT-	81205	1	77-11-11 E4-2/ /	115-199
D42041P	1	BACC45FT16A24P9 PLUG	81205	1	77-11-11 E004-02/ /	001-099
D42041P	1	BACC45FT18A31P9 PLUG	81205	1	77-11-11 E004-02/ /	115-199
D42043J	1	KD-19-66 RCPT	91836	1	23-11-11 E004-03/ /	001-099
D42043P	1	KD-59-186-M06 PLUG-	91836	1	23-11-11 E4-3/ /	001-099
D42044J	1	BACC63BV12A3S7 RCPT-	81205	1	33-45-11 AA1862/ /	ALL
D42044JK		BACC10HF12 CABLE CLAMP	81205	1	33-45-11 */ */	ALL
D42044P	1	BACC63BP12A3P7L PLUG-	81205	1	33-45-11 AA1862/ /	ALL
D42044PQ		BACC10HF12 CABLE CLAMP	81205	1	33-45-11 AA1862/ /	ALL
D42045J	1	BACC45FN14-15S RCPT-	81205	1	23-11-21 E003-02/ /	001-099
D42045P	1	BACC45FT14A15P PLUG-	81205	1	23-11-21 E003-02/ /	001-099
D42047J	1	BACC45FN22-55S9 RCPT	81205	1	34-24-11 AP0001/ /	ALL

EQUIPMENT LIST

D280N032

Section D42000

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42047P	1	BACC45FT22A55P9 PLUG	81205	1	34-24-11 217.6/198/R34	001-099
D42047P	1	BACC45FT22A55P9 PLUG	81205	1	34-24-11 AP0001/ /	115-199
D42049J	1	BACC45FN20-41S9 RCPT-	81205	1	34-24-11 E002-03/ /	001-099
D42049J	1	BACC45FN22-55S9 RCPT-	81205	1	34-24-11 E2-3/ /	115-199
D42049P	1	BACC45FT20A41P9 PLUG	81205	1	34-24-11 E2-3/ /	001-099
D42049P	1	BACC45FT22A55P9 PLUG	81205	1	34-24-11 E002-03/ /	115-199
D42050J	1	BACC45FN22-32P7 RCPT	81205	1	49-61-11 E6 RLY/PNL/	ALL
D42050P	1	BACC45FT22A32S7 PLUG-	81205	1	49-61-11 E006-00/ /	001-099
D42050P	1	BACC45FT22A32S7 PLUG-	81205	1	49-61-11 E6/ /	115-199
D42051J	1	BACC45FN12-12S RCPT	81205	1	34-22-82 E2-4/ /	001-099
D42051J	1	BACC45FN18-31S RCPT	81205	1	34-22-82 E2-4/ /	115-199
D42051P	1	BACC45FT12A12P PLUG	81205	1	34-22-82 E2-4/ /	001-099
D42051P	1	BACC45FT18A31P PLUG	81205	1	34-22-82 E002-04/ /	115-199
D42052J	1	BACC45FN14-15S RCPT-	81205	1	33-22-14 1633/280/L25	001-099
D42052J	1	BACC45FN12-12S RCPT-	81205	1	33-22-14 1633/280/L25	115-199
D42052P	1	BACC45FT14A15P PLUG-	81205	1	33-22-14 1633/300/L025	001-099
D42052P	1	BACC45FT12-12P PLUG-	81205	1	33-22-14 1633/300/L025	115-199

EQUIPMENT LIST

D280N032

Section D42000

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42053J	1	BACC45FN14-15S7 RCPT	81205	1	27-51-61 E005-03/ /	001-099
D42053J	1	BACC45FN14-15S7 RCPT	81205	1	27-51-61 E5-3/ /	115-199
D42053P	1	BACC45FT14A15P7 PLUG	81205	1	27-51-61 E005-03/ /	ALL
D42055J	1	BACC45FN22-55S8 RCPT	81205	1	27-51-21 AP0003/ /	001-099
D42055J	1	BACC45FN20-41S8 RCPT	81205	1	27-51-21 AP0003/ /	115-199
D42055P	1	BACC45FT22A55P8 PLUG	81205	1	27-51-21 217.6/200/R40	001-099
D42055P	1	BACC45FT20A41P8 PLUG	81205	1	27-51-21 AP0003/ /	115-199
D42057J	1	KD-19-66 RCPT-	91836	1	23-11-21 E003-02/ /	001-099
D42057P	1	KD-59-186-M06 PLUG-	91836	1	23-11-21 E003-02/ /	001-099
D42059J	1	BACC45FN12-12S6 RCPT-	81205	1	23-11-21 E003-02/ /	001-099
D42059P	1	BACC45FT12A12P6 PLUG-	81205	1	23-11-21 E3-2/ /	001-099
D42060J	1	BACC45FN18-31S RCPT	81205	1	28-21-22 E003-04/ /	001-099
D42060J	1	BACC45FN18-31S9 RCPT	81205	1	28-21-22 E003-04/ /	115-199
D42060P	1	BACC45FT18-31P PLUG	81205	1	28-21-22 E003-04/ /	001-099
D42060P	1	BACC45FT18-31P9 PLUG	81205	1	28-21-22 E3-4/ /	115-199
D42062J	1	BACC45FN18-14P9 RCPT	81205	1	80-11-21 P37/ /	ALL
D42062P	1	BACC45FT18-14S9 PLUG	81205	1	28-22-11 P037-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D42000

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42062P	1	BACC45FT18-14S9 PLUG	81205	1	28-22-11 P37/ /	115-199
D42063J	1	BACC45FN16-24S8 RCPT-	81205	1	34-22-91 E002-03/ /	001-099
D42063J	1	BACC45FN16-24S8 RCPT-	81205	1	34-22-91 E2-3/ /	115-199
D42063P	1	BACC45FT16A24P8 PLUG	81205	1	34-22-91 E002-03/ /	ALL
D42065J	1	BACC45FN22-55S9 RCPT-	81205	1	34-12-11 E002-01/ /	001-099
D42065J	1	BACC45FN20-41S9 RCPT-	81205	1	34-12-11 E2-1/ /	115-199
D42065P	1	BACC45FT22A55P9 PLUG	81205	1	34-12-11 E002-01/ /	001-099
D42065P	1	BACC45FT20A41P9 PLUG	81205	1	34-12-11 E002-01/ /	115-199
D42069J	1	BACC45FN16-24S8 RCPT	81205	1	27-51-21 E5-1/ /	001-099
D42069J	1	BACC45FN14-15S8 RCPT	81205	1	27-51-21 E5-1/ /	115-199
D42069P	1	BACC45FT16A24P8 PLUG	81205	1	27-51-41 E005-01/ /	001-099
D42069P	1	BACC45FT14A15P8 PLUG	81205	1	27-51-41 E005-01/ /	115-199
D42071J	1	BACC45FN14-15S6 RCPT-	81205	1	34-53-11 E3-3/ /	001-099
D42071J	1	BACC45FN16-24S6 RCPT-	81205	1	34-53-11 E3-3/ /	115-199
D42071P	1	BACC45FT14A15P6 PLUG	81205	1	34-53-11 E003-03/ /	001-099
D42071P	1	BACC45FT16A24P6 PLUG	81205	1	34-53-11 E003-03/ /	115-199
D42073J	1	BACC45FN16-24S7 RCPT-	81205	1	32-61-12 E4-2/ /	ALL

EQUIPMENT LIST

D280N032

Section D42000

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42073P	1	BACC45FT16A24P7 PLUG	81205	1	77-12-11 E004-02/ /	001-099
D42073P	1	BACC45FT16A24P7 PLUG	81205	1	32-61-12 E004-02/ /	115-199
D42074J	1	BACC45FN20-39P9 RCPT	81205	1	21-25-11 P070-00/ /	ALL
D42074P	1	BACC45FT20D39S9 PLUG	81205	1	21-25-11 P070-00/ /	001-099
D42074P	1	BACC45FT20D39S9 PLUG	81205	1	21-25-11 P70/ /	115-199
D42076J	1	CN0967C18G14S9-000 RCPT-	13556	1	27-51-41 AD0880/ /	001-004
D42076J	1	BACC63CC18-14S9 RCPT-	13556	1	27-51-41 AD0880/ /	005-099
D42076J	1	CN0967C18G14S9-000 RCPT	13556	1	27-51-41 AD0880/ /	115-199
D42076JK		BACC10HF18C CABLE CLAMP-	81205	1	27-51-41 */ */	001-099
D42076JK	1	BACC10HF18C CABLE CLAMP-	81205	1	27-51-41 */ /	115-199
D42076P	1	CN0966A18G14P9-000 PLUG-	13556	1	27-51-41 AD0880/ /	001-004, 115-199
D42076P	1	BACC63CB18-14P9 PLUG-	13556	1	27-51-41 AD0880/ /	005-099
D42076PQ		BACC10HF18C CABLE CLAMP	81205	1	27-51-41 */ */	ALL
D42080J	1	BACC45FN14-15S9 RCPT	81205	1	49-61-11 P36/ /	ALL
D42080P	1	BACC45FT14-15P9 PLUG	81205	1	49-61-11 P036-00/ /	001-099
D42080P	1	BACC45FT14-15P9 PLUG	81205	1	49-61-11 P36/ /	115-199
D42081J	1	BACC45FN14-15S9 RCPT-	81205	1	31-51-21 P051-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D42000

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42081P	1	BACC45FT14A15P9 PLUG	81205	1	22-14-21 P051-00/ /	ALL
D42083J	1	BACC45FN14-15S6 RCPT-	81205	1	22-14-21 E002-03/ /	001-099
D42083J	1	BACC45FN18-31S6 RCPT-	81205	1	22-14-21 E2-3/ /	115-199
D42083P	1	BACC45FT14A15P6 PLUG	81205	1	22-14-21 E002-03/ /	001-099
D42083P	1	BACC45FT18A31P6 PLUG	81205	1	22-14-21 E2-3/ /	115-199
D42084J	1	BACC45FN20-41P6 RCPT-	81205	1	21-52-11 E4-2/ /	001-099
D42084J	1	BACC45FN22-55P6 RCPT-	81205	1	21-52-11 E4-2/ /	115-199
D42084P	1	BACC45FT20-41S6 PLUG	81205	1	21-52-11 E004-02/ /	001-099
D42084P	1	BACC45FT22-55S6 PLUG	81205	1	21-52-11 E4-2/ /	115-199
D42085J	1	BACC45FN22-55S9 RCPT-	81205	1	34-13-21 E002-02/ /	001-099
D42085J	1	BACC45FN22-55S9 RCPT-	81205	1	34-13-21 E2-2/ /	115-199
D42085P	1	BACC45FT22A55P9 PLUG	81205	1	34-12-21 E002-02/ /	001-099
D42085P	1	BACC45FT22A55P9 PLUG	81205	1	34-12-21 E2-2/ /	115-199
D42086J	1	BACC45FN22-55P RCPT-	81205	1	21-52-11 E4-2/ /	ALL
D42086P	1	BACC45FT22-55S PLUG	81205	1	21-52-11 E004-02/ /	001-099
D42086P	1	BACC45FT22-55S PLUG	81205	1	21-52-11 E4-2/ /	115-199
D42087J	1	BACC45FN16-24S8 RCPT-	81205	1	34-22-27 E002-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D42000

Page 11

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42087J	1	BACC45FN16-24S8 RCPT-	81205	1	34-22-27 E2-2/ /	115-199
D42087P	1	BACC45FT16A24P8 PLUG	81205	1	34-51-21 E002-02/ /	001-099
D42087P	1	BACC45FT16A24P8 PLUG	81205	1	34-51-21 E2-2/ /	115-199
D42089J	1	BACC45FN12-12S6 RCPT	81205	1	34-21-21 E002-04/ /	001-099
D42089J	1	BACC45FN16-24S6 RCPT	81205	1	34-21-21 E2-4/ /	115-199
D42089P	1	BACC45FT12A12P6 PLUG	81205	1	34-21-21 E002-04/ /	001-099
D42089P	1	BACC45FT16A24P6 PLUG	81205	1	34-21-21 E2-4/ /	115-199
D42091J	1	BACC45FN18-31S6 RCPT-	81205	1	34-51-21 E003-02/ /	001-099
D42091J	1	BACC45FN22-55S6 RCPT-	81205	1	34-51-21 E3-2/ /	115-199
D42091P	1	BACC45FT18A31P6 PLUG	81205	1	34-22-91 E003-02/ /	001-099
D42091P	1	BACC45FT22A55P6 PLUG	81205	1	34-22-91 E3-2/ /	115-199
D42093J	1	BACC45FN14-15S8 RCPT-	81205	1	32-61-12 E4-2/ /	ALL
D42093P	1	BACC45FT14A15P8 PLUG	81205	1	32-61-21 E004-02/ /	001-099
D42093P	1	BACC45FT14A15P8 PLUG	81205	1	32-61-12 E4-2/ /	115-199
D42094J	1	BACC45FN18-8P8 RCPT	81205	1	29-21-31 P33/ /	001-099
D42094J	1	BACC45FN18-14P8 RCPT	81205	1	29-21-31 P33/ /	115-199
D42094P	1	BACC45FT18-8S8 PLUG	81205	1	29-21-31 P033-00/ /	001-099

EQUIPMENT LIST

D280N032

Section D42000

Page 12

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42094P	1	BACC45FT18-14S8 PLUG	81205	1	29-21-31 P33/ /	115-199
D42095J	1	BACC45FN22-55S8 RCPT	81205	1	27-51-11 E5-2/ /	001-099
D42095J	1	BACC45FN18-31S8 RCPT	81205	1	27-51-11 E5-2/ /	115-199
D42095P	1	BACC45FT22A55P8 PLUG	81205	1	27-51-11 E005-02/ /	001-099
D42095P	1	BACC45FT18A31P8 PLUG	81205	1	27-51-61 E5-2/ /	115-199
D42096J	1	BACC45FN20-25P RCPT	81205	1	29-21-31 P36/ /	ALL
D42096P	1	BACC45FT20-25S PLUG	81205	1	29-21-31 P036-00/ /	ALL
D42098J	1	BACC63BV12A3S7 RCPT-	81205	1	33-45-11 AB1862/ /	ALL
D42098JK		BACC10HF12 CABLE CLAMP	81205	1	33-45-11 */*/	ALL
D42098P	1	BACC63BP12A3P7L PLUG-	81205	1	33-45-11 AB1862/250/	ALL
D42098PQ		BACC10HF12 CABLE CLAMP	81205	1	33-45-11 AB1862/250/	ALL

EQUIPMENT LIST

D280N032

Section D42000
Page 13 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42105J	1	BACC45FN14-15S9 RCPT-	81205	1	34-31-11 E002-03/ /	001-099
D42105J	1	BACC45FN14-15S9 RCPT-	81205	1	34-31-11 E2-3/ /	115-199
D42105P	1	BACC45FT14A15P9 PLUG	81205	1	34-31-11 E002-03/ /	ALL
D42107J	1	BACC45FN12-12S RCPT-	81205	1	34-31-21 E002-02/ /	001-099
D42107J	1	BACC45FN14-15S RCPT-	81205	1	34-31-21 E2-2/ /	115-199
D42107P	1	BACC45FT12A12P PLUG	81205	1	34-31-21 E002-02/ /	001-099
D42107P	1	BACC45FT14A15P PLUG	81205	1	34-31-21 E002-02/ /	115-199
D42109J	1	BACC45FN14-15S6 RCPT-	81205	1	34-31-31 E002-03/ /	001-099
D42109J	1	BACC45FN14-15S6 RCPT-	81205	1	34-31-31 E2-3/ /	115-199
D42109P	1	BACC45FT14A15P6 PLUG	81205	1	34-31-31 E002-03/ /	ALL
D42118J	1	BACC45FN20-16P RCPT	81205	1	24-22-41 E5-1/ /	001-099
D42118P	1	BACC45FT20A16S PLUG	81205	1	24-21-41 E005-01/ /	001-099
D42120J	1	BACC45FN18-14P6 RCPT	81205	1	24-21-41 E5-1/ /	001-099
D42120P	1	BACC45FT18A14S6 PLUG	81205	1	24-21-41 E005-01/ /	001-099
D42121J	1	KA-19-83 RCPT-	81205	1	34-31-11 E002-03/ /	001-099
D42121J	1	KA-19-83 RCPT-	812051	1	34-31-11 E2-3/ /	115-199
D42121P	1	KA-59-188 PLUG	91836	1	34-31-11 E002-03/ /	ALL

EQUIPMENT LIST

D280N032

Section D42100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42123J	1	KA-19-83 RCPT-	81205	1	34-31-21 E002-02/ /	001-099
D42123J	1	KA-19-83 RCPT-	81205	1	34-31-21 E2-2/ /	115-199
D42123P	1	KA-59-188 PLUG	91836	1	34-31-21 E002-02/ /	ALL
D42125J	1	KD-19-69 RCPT-	81205	1	34-31-11 E002-03/ /	001-099
D42125J	1	KD-19-69 RCPT-	812051	1	34-31-11 E2-3/ /	115-199
D42125P	1	KD-59-125 PLUG	91836	1	34-31-11 E002-03/ /	ALL
D42127J	1	KD-19-69 RCPT-	81205	1	34-31-21 E002-02/ /	001-099
D42127J	1	KD-19-69 RCPT-	81205	1	34-31-21 E2-2/ /	115-199
D42127P	1	KD-59-125 PLUG	91836	1	34-31-21 E002-02/ /	ALL
D42129J	1	BACC45FN14-15S6 RCPT-	81205	1	34-12-11 E002-01/ /	001-099
D42129J	1	BACC45FN12-12S6 RCPT-	81205	1	34-12-11 E2-1/ /	115-199
D42129P	1	BACC45FT14A15P6 PLUG	81205	1	34-12-11 E002-01/ /	001-099
D42129P	1	BACC45FT12-12P6 PLUG	81205	1	34-12-11 E002-01/ /	115-199
D42129PQ		BACC10GH12 CABLE CLAMP	81205	1	34-12-11 */ /	115-199
D42132J	1	BACC45FN14-3S6 RCPT		1	29-33-11 E003-04/ /	001-099
D42132P	1	BACC45FT14-3P6 PLUG	81205	1	29-33-11 E003-04/ /	001-099
D42133J	1	BACC45FN14-15S RCPT-	81205	1	34-12-21 E002-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D42100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42133J	1	BACC45FN12-12S RCPT-	81205	1	34-12-21 E2-2/ /	115-199
D42133P	1	BACC45FT14A15P PLUG	81205	1	34-12-21 E002-02/ /	001-099
D42133P	1	BACC45FT12-12P PLUG	81205	1	34-12-21 E002-02/ /	115-199
D42133PQ		BACC10GH12 CABLE CLAMP	81205	1	34-12-21 */*/	115-199
D42134J	1	BACC45FN14-3S8 RCPT		1	29-33-11 E003-04/ /	001-099
D42134P	1	BACC45FT14-3P8 PLUG	81205	1	29-33-11 E003-04/ /	001-099
D42134PQ		S2407-12-9 CABLE CLAMP	07418	1	29-33-11 */*/	001-099
D42135J	1	BACC45FN12-12S6 RCPT-	81205	1	34-12-11 E002-01/ /	001-099
D42135J	1	BACC45FN10-5S6 RCPT-	81205	1	34-12-11 E2-1/ /	115-199
D42135P	1	BACC45FT12-12P6 PLUG	81205	1	34-12-11 E002-01/ /	001-099
D42135P	1	BACC45FT10-5P6 PLUG	81205	1	34-12-11 E002-01/ /	115-199
D42135PQ		BACC10GH12 CABLE CLAMP	81205	1	34-12-11 */*/	001-099
D42135PQ		BACC10GH10 CABLE CLAMP	81205	1	34-12-11 */*/	115-199
D42137J	1	KA-19-83 RCPT-	81205	1	34-31-31 E002-03/ /	001-099
D42137J	1	KA-19-83 RCPT-	81205	1	34-31-31 E2-3/ /	115-199
D42137P	1	KA-59-188 PLUG	91836	1	34-31-31 E002-03/ /	ALL
D42138J	1	BACC45FN14-3S7 RCPT		1	29-33-11 E003-04/ /	001-099

EQUIPMENT LIST

D280N032

Section D42100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42138P	1	BACC45FT14-3P7 PLUG	81205	1	29-33-11 E003-04/ /	001-099
D42139J	1	KD-19-69 RCPT-	81205	1	34-31-31 E002-03/ /	001-099
D42139J	1	KD-19-69 RCPT-	81205	1	34-31-31 E2-3/ /	115-199
D42139P	1	KD-59-125 PLUG	91836	1	34-31-31 E002-03/ /	ALL
D42143J	1	BACC45FN14-15S6 RCPT-	81205	1	34-12-21 E002-02/ /	001-099
D42143J	1	BACC45FN12-12S6 RCPT-	81205	1	34-12-21 E2-2/ /	115-199
D42143P	1	BACC45FT14A15P6 PLUG	81205	1	34-12-21 E002-02/ /	001-099
D42143P	1	BACC45FT12-12P6 PLUG	81205	1	34-12-21 E002-02/ /	115-199
D42143PQ		BACC10GH12 CABLE CLAMP	81205	1	34-12-21 E2-2/ /	115-199
D42144J	1	BACC45FN14-15P RCPT	81205	1	26-23-11 1189/163/L018	ALL
D42144P	1	BACC45FT14D15S PLUG	81205	1	26-23-11 1189/163/L018	001-099
D42144P	1	BACC45FT14D15S PLUG	82105	1	26-23-11 1189/163/L018	115-199
D42145J	1	KN-19-195-M06 RCPT-	91836	1	34-55-11 E3-3/ /	ALL
D42145P	1	KN-59-329-M06 PLUG	91836	1	34-55-11 E003-03/ /	ALL
D42146J	1	BACC45FN12-12P RCPT	81205	1	26-23-11 1189/163/R018	ALL
D42146P	1	BACC45FT12D12S PLUG	81205	1	26-23-11 1189/163/R018	ALL
D42147J	1	KN-19-195-M06 RCPT- COAX	91836	1	34-55-21 E003-02/ /	001-099

EQUIPMENT LIST

D280N032

Section D42100

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42147J	1	KN-19-195-M06 RCPT- COAX	91836	1	34-55-21 E3-2/ /	115-199
D42147P	1	KN-59-329-M06 PLUG	91836	1	34-55-21 E3-2/ /	ALL
D42148J	1	BACC45FN14D15P6 RCPT	81205	1	26-21-11 1187/185/R031	ALL
D42148P	1	BACC45FT14D15S6 PLUG	81205	1	26-21-11 1187/185/R031	ALL
D42149J	1	KD-19-68 RCPT-	91836	1	34-51-11 E003-02/ /	001-099
D42149P	1	KD-59-186-M06 PLUG	91836	1	34-51-11 E003-02/ /	001-099
D42150J	1	BACC45FN12D12P6 RCPT	81205	1	26-21-11 1196/184/R056	ALL
D42150P	1	BACC45FT12D12S6 PLUG	81205	1	26-21-11 1196/184/R056	001-099
D42150P	1	BACC45FT12D12S6 PLUG	81205	1	26-23-11 1196/184/R056	115-199
D42151J	1	KD-19-68 RCPT-	91836	1	34-51-21 E003-02/ /	001-099
D42151P	1	KD-59-186-M06 PLUG	91836	1	34-51-21 E3-2/ /	001-099
D42163J	1	BACC45FN16-24S9 RCPT-	81205	1	34-57-11 E6-1/ /	001-099
D42163P	1	BACC45FT16A24P9 PLUG	81205	1	34-57-11 E6-1/ /	001-099
D42165J	1	BACC45FN22-55S8 RCPT	81205	1	22-14-11 AP0003/ /	ALL
D42165P	1	BACC45FT22D55P8 PLUG	81205	1	22-14-11 217.6/200/R40	001-099
D42165P	1	BACC45FT22D55P8 PLUG	81205	1	22-14-11 AP0003/ /	115-199
D42166J	1	BACC45FN14-12P7 RCPT	81205	1	28-22-11 P070-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D42100

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42166P	1	BACC45FT14D12S7 PLUG	81205	1	28-22-11 P70/ /	ALL
D42167J	1	BACC45FN12-12S8 RCPT-	81205	1	22-14-11 E002-03/ /	001-099
D42167J	1	BACC45FN12-12S8 RCPT-	81205	1	22-14-11 E2-3/ /	115-199
D42167P	1	BACC45FT12A12P8 RCPT	81205	1	22-14-11 E002-03/ /	001-099
D42167P	1	BACC63BN12-12P8 RCPT	81205	1	22-14-11 E002-03/ /	115-199
D42167PQ		BACC10GH12 CABLE CLAMP	81205	1	22-14-11 E2-3/ /	115-199
D42169J	1	BACC45FN12-12S RCPT	81205	1	32-35-11 E003-04/ /	001-099
D42169J	1	BACC45FN12C12S9 RCPT	81205	1	32-35-11 E003-04/ /	115-199
D42169P	1	BACC45FT12A12P PLUG	81205	1	32-41-11 E003-04/ /	001-099
D42169P	1	BACC63BN12-12P9 PLUG	81205	1	32-41-11 E003-04/ /	115-199
D42169PQ		BACC10GH12 CABLE CLAMP	81205	1	32-41-11 E3-4/ /	115-199
D42172J	1	BACC45FN10-5S RCPT-	81205	1	33-22-12 685/272/L38	115-199
D42173J	9	BACC45FN22-55S8 RCPT (34-0414)	81205	1	34-61-26 E002-001/ /	115-199
D42173P	9	BACC45FT22A55P8 PLUG- (34-0414)	81205	1	34-61-26 E002-01/ /	115-199
D42174J	1	BACC45FN14-15P6 RCPT	81205	1	32-35-11 P003-01/ /	ALL
D42174P	1	BACC45FT14D15S6 PLUG	81205	1	32-35-11 P3-1/ /	ALL
D42175J		BACC45FN16-24SN RCPT-	81205	1	27-32-11 E002-01/ /	ALL

EQUIPMENT LIST

D280N032

Section D42100

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42175P		BACC45FT16-24PN PLUG-	81205	1	34-12-61 E002-01/ /	ALL
D42176J	1	BACC45FN18-31S8 RCPT	81205	1	28-22-11 P37/ /	ALL
D42176P	1	BACC45FT18-31P8 PLUG	81205	1	28-21-11 P037-00/ /	001-099
D42176P	1	BACC45FT18-31P8 PLUG	81205	1	28-22-11 P37/ /	115-199
D42178J	1	BACC45FN16-24S RCPT	81205	1	24-33-12 E6 RLY/PNL/	001-099
D42178J	1	BACC45FN16-24S6 RCPT	81205	1	24-33-12 E6/ /	115-199
D42178P	1	BACC45FT16A24P PLUG-	81205	1	24-33-12 E006-00/ /	001-099
D42178P	1	BACC45FT16A24P6 PLUG-	81205	1	24-33-12 E6 RLY/ /	115-199
D42180J	1	BACC45FN22-55S8 RCPT	81205	1	32-42-11 E6-4/ /	115-199
D42180P	1	BACC45FT22A55P8 PLUG	81205	1	21-51-15 E6-4/ /	115-199
D42182J	1	BACC45FN22-55P RECPT	81205	1	21-51-12 E6-2/ /	115-199
D42182P	1	BACC45FT22A55S PLUG	81205	1	21-51-12 E6-2/ /	115-199
D42183J	1	BACC45FN14-15S6 RCPT-	81205	1	34-61-14 E002-01/ /	001-099
D42183J	1	BACC45FN18-31S6 RCPT-	81205	1	34-61-14 E2-1/ /	115-199
D42183P	1	BACC45FT14A15P6 PLUG-	81205	1	34-61-14 E002-01/ /	001-099
D42183P	1	BACC45FT18A31P6 PLUG-	81205	1	34-61-14 E002-01/ /	115-199
D42184J	1	BACC45FN22-55S9 RCPT	81205	1	21-51-22 E6-4/ /	115-199

EQUIPMENT LIST

D280N032

Section D42100

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42184P	1	BACC45FT22A55P9 PLUG	81205	1	32-42-12 E6-4/ /	115-199
D42185J	9	BACC45FN22-55S RCPT- (S/B 757-34-0200)	81205	1	29-31-11 E004-02/ /	002
D42185J	1	BACC45FN18-31S RCPT-	81205	1	29-31-11 E4-2/ /	001, 003-099
D42185J	1	BACC45FN22-55S RCPT-	81205	1	29-31-11 E4-2/ /	115-199
D42185P	9	BACC45FT22-55P PLUG-	81205	1	27-21-12 E004-02/ /	002
D42185P	1	BACC45FT18A31P PLUG-	81205	1	27-21-12 E004-02/ /	001, 003-099
D42185P	1	BACC45FT22A55P PLUG-	81205	1	27-21-12 E4-2/ /	115-199
D42186J	1	BACC45FN22-55P RECPT	81205	1	21-51-12 E6-2/ /	115-199
D42186P	1	BACC45FT22A55S PLUG	81205	1	21-51-12 E6-2/ /	115-199
D42187J	1	BACC45FN22-55S9 RCPT	81205	1	34-21-31 E5-1/ /	ALL
D42187P	1	BACC45FT22A55P9 PLUG-	81205	1	34-21-31 E005-01/ /	ALL
D42188J	1	BACC45FN22-55P8 RECPT	81205	1	21-51-12 E6-2/ /	115-199
D42188P	1	BACC45FT22A55S8 PLUG	81205	1	21-61-51 E6-2/ /	115-199
D42189J	1	CN0967C16G10S6-000 RCPT-	13556	1	32-42-11 AC1090/ /	001-004
D42189J	1	BACC63CC16-10S6 RCPT-	13556	1	32-42-11 AC1090/ /	005-099
D42189J	1	CN0967C16G10S6-000 RCPT-		1	32-42-11 AC1090/ /	115-199
D42189JK		BACC10HG16C CABLE CLAMP	81205	1	32-42-11 */ */	001-004, 115-199

EQUIPMENT LIST

D280N032

Section D42100

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42189JK		BACC10HG16C CABLE CLAMP		1	32-42-11 */*/	005-099
D42189P	1	CN0966A16G10P6-000 PLUG	13556	1	32-42-11 AC1090/ /	001-004
D42189P	1	BACC63CB16-10P6 PLUG	81205	1	32-42-11 AC1090/ /	005-099
D42189P	1	CN0966A16G10P6-000 PLUG	81205	1	32-42-11 AC1090/ /	115-199
D42189PQ		BACC10HG16C CABLE CLAMP	81205	1	32-42-11 */*/	ALL
D42190J	1	BACC45FN22-55P7 RECPT	81205	1	32-42-12 E6-2/ /	115-199
D42190P	1	BACC45FT22A55S7 PLUG	81205	1	32-42-12 E6-2/ /	115-199
D42196J	1	BACC45FN22-55P9 RECPT	81205	1	32-42-12 E6-2/ /	115-199
D42196P	1	BACC45FT22A55S9 PLUG	81205	1	21-51-22 E6-2/ /	115-199

EQUIPMENT LIST

D280N032

Section D42100

Page 9 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42201J	1	BACC45FN16-24S6 RCPT	81205	1	34-21-11 E002-04/ /	001-099
D42201J	1	BACC45FN16-24S6 RCPT	81205	1	34-21-11 E2-4/ /	115-199
D42201P	1	BACC45FT16A24P6 PLUG-	81205	1	34-21-11 E002-04/ /	ALL
D42203J	1	BACC45FN16-24S9 RCPT	81205	1	34-21-21 E002-04/ /	001-099
D42203J	1	BACC45FN16-24S9 RCPT	81205	1	34-21-21 E2-4/ /	115-199
D42203P	1	BACC45FT16A24P9 PLUG	81205	1	34-21-21 E002-04/ /	ALL
D42204J	1	BACC45FN14-15S8 RCPT-	81205	1	24-51-72 P006-00/ /	001-099
D42204J	1	BACC45FN14-12S8 RCPT-	81205	1	24-51-72 P006-00/ /	115-199
D42204P	1	BACC45FT14-15P8 PLUG-	81205	1	24-51-72 P006-00/ /	001-099
D42204P	1	BACC45FT14-12P8 PLUG-	81205	1	24-51-72 P006-00/ /	115-199
D42205J	1	BACC45FN16-24S9 RCPT	81205	1	34-21-31 E002-04/ /	001-099
D42205J	1	BACC45FN16-24S9 RCPT	81205	1	34-21-31 E2-4/ /	115-199
D42205P	1	BACC45FT16A24P9 PLUG	81205	1	34-21-31 E002-04/ /	ALL
D42206J	1	BACC45FN14-15S6 RCPT-	81205	1	24-51-72 P006-00/ /	001-099
D42206J	1	BACC45FN14-12S6 RCPT-	81205	1	24-51-72 P006-00/ /	115-199
D42206P	1	BACC45FT14-15P6 PLUG-	81205	1	24-51-72 P006-00/ /	001-099
D42206P	1	BACC45FT14-12P6 PLUG-	81205	1	24-51-72 P006-00/ /	115-199

EQUIPMENT LIST

D280N032

Section D42200

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42207J	1	BACC45FN14-15P7 RCPT	81205	1	23-51-41 E6-3/ /	115-199
D42207P	1	BACC45FT14A15S7 PLUG	81205	1	23-51-14 E6-3/ /	115-199
D42208J	1	BACC45FN10-5P8 RCPT	81205	1	21-61-51 E6-2/ /	001-099
D42208J	1	BACC45FN14-12P7 RCPT	81205	1	32-46-11 E6-4/ /	115-199
D42208P	1	BACC45FT10-5S8 PLUG	81205	1	21-61-51 E006-02/ /	001-099
D42208P	1	BACC45FT14-12S7 PLUG-	81205	1	32-46-11 E006-04/ /	115-199
D42209P	1	BACC45FT10-5P PLUG-	81205	1	23-42-11 352/290/L35	115-199
D42209PQ		BACC10GH10 CLAMP-	81205	1	23-42-11 / /	115-199
D42211J	1	BACC45FN14-15P7 RCPT-	81205	1	23-51-11 E6-3/ /	115-199
D42211P	1	BACC45FT14A15S7 PLUG	81205	1	23-51-11 E6-3/ /	115-199
D42212J	1	BACC45FN14-12P RCPT	81205	1	21-51-13 E6 RLY/PNL/	115-199
D42212P	1	BACC45FT14-12S PLUG-	81205	1	21-51-13 E6/ /	115-199
D42214J	1	BACC45FN14-12P RCPT	81205	1	32-42-11 E6-4/ /	115-199
D42214P	1	BACC45FT14-12S PLUG-	81205	1	29-33-11 E6-4/ /	115-199
D42216J	1	BACC45FN14-12P6 RCPT	81205	1	21-51-23 E6 RLY/PNL/	115-199
D42216P	1	BACC45FT14-12S6 PLUG-	81205	1	21-51-23 E6/ /	115-199
D42218J	1	BACC45FN10-5P RECPT-	81205	1	32-42-11 E6-2/ /	001-099

EQUIPMENT LIST

D280N032

Section D42200

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42218J	1	BACC45FN16-24P6 RECPT	81205	1	32-42-11 E6-4/ /	115-199
D42218P	1	BACC45FT10-5S PLUG-	81205	1	32-42-11 E6-2/ /	001-099
D42218P	1	BACC45FT16-24S6 PLUG-	81205	1	28-25-11 E6-4/ /	115-199
D42220J	1	BACC63CC14-3S8 RCPT	81205	1	28-41-21 E003-04/ /	001-099
D42220J	1	BACC45FN14-3S8 RCPT	81205	1	28-41-21 E003-04/ /	115-199
D42220P	1	BACC63CB14-3P8 PLUG		1	28-41-21 E3-4/ /	001-099
D42220P	1	BACC45FT14-3P8 PLUG-	81205	1	28-41-21 E3-4/ /	115-199
D42220PQ		BACC10HF14C CABLE CLAMP	81205	1	28-41-21 E3-4/ /	001-099
D42220PQ		S2407-12-9 CABLE CLAMP-	07418	1	28-41-21 E3-4/ /	115-199
D42221J		BACC45FN22-55S8 RCPT-	81205	1	34-12-61 E002-02/ /	ALL
D42221P		BACC45FT22-55P8 PLUG-	81205	1	34-12-61 E002-02/ /	ALL
D42222J	1	BACC63CC14-3SN RCPT	81205	1	28-41-31 E003-04/ /	001-099
D42222J	1	BACC45FN14-3S RCPT	81205	1	28-41-31 E003-04/ /	115-199
D42222P	1	BACC63CB14-3PN PLUG	81205	1	28-41-31 E3-4/ /	001-002
D42222P	1	BACC63CB14-3PN PLUG	81205	1	28-41-31 E003-04/ /	003-099
D42222P	1	BACC45FT14-3P PLUG	81205	1	28-41-31 E003-04/ /	115-199
D42222PQ		BACC10HF14C CABLE CLAMP	81205	1	28-41-31 E3-4/ /	001-002

EQUIPMENT LIST

D280N032

Section D42200

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42222PQ		BACC10HF14C CABLE CLAMP	81205	1	28-41-31 E003-04/ /	003-099
D42222PQ		S2407-12-9 CABLE CLAMP-	07418	1	28-41-31 */*/	115-199
D42224J	1	BACC63CC18-11S9 RCPT	81205	1	28-41-41 E003-04/ /	001-099
D42224J	1	BACC45FN14-3S7 RCPT	81205	1	28-41-41 E003-04/ /	115-199
D42224P	1	BACC63CB18-11P9 PLUG		1	28-41-41 E3-4/ /	001-099
D42224P	1	BACC45FT14-3P7 PLUG-	81205	1	28-41-41 E3-4/ /	115-199
D42224PQ		BACC10HF18C CABLE CLAMP	81205	1	28-41-41 E3-4/ /	001-099
D42224PQ		S2407-12-9 CABLE CLAMP-	07418	1	28-41-41 E3-4/ /	115-199
D42225J	1	BACC45FN14-4P9 RCPT-	81205	1	34-21-11 E002-04/ /	001-099
D42225J	1	BACC45FN14-4P9 RCPT	81205	1	34-21-11 E2-4/ /	115-199
D42225P	1	BACC45FT14-4S9 PLUG-	81205	1	34-21-11 E002-04/ /	ALL
D42226J	1	BACC63CC18-11SN RCPT	81205	1	28-41-41 E003-04/ /	001-099
D42226J	1	BACC45FN14-3S RCPT	81205	1	28-41-41 E003-04/ /	115-199
D42226P	1	BACC63CB18-11PN PLUG	81205	1	28-41-41 E3-4/ /	001-002
D42226P	1	BACC63CB18-11PN PLUG	81205	1	28-41-41 E003-04/ /	003-099
D42226P	1	BACC45FT14-3P PLUG	81205	1	28-41-41 E003-04/ /	115-199
D42226PQ		BACC10HF18C CABLE CLAMP	81205	1	28-41-41 E3-4/ /	001-002

EQUIPMENT LIST

D280N032

Section D42200

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42226PQ		BACC10HF18C CABLE CLAMP	81205	1	28-41-41 E003-04/ /	003-099
D42226PQ		S2407-12-9 CABLE CLAMP-	07418	1	28-41-41 */*/	115-199
D42227J	1	BACC45FN14-4P7 RCPT-	81205	1	34-21-21 E002-04/ /	001-099
D42227J	1	BACC45FN14-4P7 RCPT	81205	1	34-21-21 E2-4/ /	115-199
D42227P	1	BACC45FT14-4S7 PLUG-	81205	1	34-21-21 E002-04/ /	ALL
D42228J	1	BACC45FN14-15P9 RCPT	81205	1	27-51-41 E5-1/ /	ALL
D42228P	1	BACC45FT14-15S9 PLUG	81205	1	27-51-41 E005-01/ /	001-099
D42228P	1	BACC45FT14A15S9 PLUG	81205	1	27-51-41 E005-01/ /	115-199
D42229J	1	BACC45FN14-4P8 RCPT-	81205	1	34-21-31 E002-04/ /	001-099
D42229J	1	BACC45FN14-4P8 RCPT	81205	1	34-21-31 E2-4/ /	115-199
D42229P	1	BACC45FT14-4S8 PLUG-	81205	1	34-21-31 E002-04/ /	ALL
D42230J	1	BACC45FN14-15P7 RCPT-	81205	1	73-21-12 E002-01/ /	001-099
D42230J	1	BACC45FN14-15P7 RCPT-	81205	1	73-21-12 E2-1/ /	115-199
D42230P	1	BACC45FT14A15S7 PLUG	81205	1	73-21-12 E002-01/ /	ALL
D42233J		BACC45FN18-31S RCPT-	81205	1	34-12-62 E002-02/ /	ALL
D42233P		BACC45FT18-31P PLUG-	81205	1	34-12-62 E002-02/ /	ALL
D42238J	1	BACC45FN14-12P RCPT	81205	1	49-61-11 E6 RLY/PNL/	001-099

EQUIPMENT LIST

D280N032

Section D42200

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42238J	1	BACC45FN20-25P RCPT	81205	1	49-61-11 E6 RLY/PNL/	115-199
D42238P	1	BACC45FT14-12S PLUG-	81205	1	28-25-11 E-6/ /	001-099
D42238P	1	BACC45FT20-25S PLUG-	81205	1	28-25-11 E6/ /	115-199
D42272J	1	CN0967C28G42P8-000 PLUG	13566	1	77-11-11 AW1285/ /	001-004
D42272J	1	BACC63CC28-42P8 PLUG	13566	1	77-11-11 AW1285/ /	005-099
D42272J	1	CN0967C28G42P8-000 PLUG	13556	1	77-11-11 AW1285/ /	115-199
D42272JK		BACC10HF28C CABLE CLAMP	81205	1	77-11-11 */ */	001-004, 115-199
D42272JK		BACC10HF28C CABLE CLAMP	06324	1	77-11-11 */ */	005-099
D42272P	1	CN0966A28G42S8-000 PLUG	13556	1	77-11-11 AW1285/ /	001-004, 115-199
D42272P	1	BACC63CB28-42S8 PLUG	13556	1	77-11-11 AW1285/ /	005-099
D42272PQ		S2277-28-34 CABLE CLAMP	07418	1	77-11-11 */ */	ALL
D42276J	1	CN0967C28G42S8-000 RCPT	13556	1	73-31-11 AW1285/ /	001-004, 115-199
D42276J	1	BACC63CC28-42S8 RCPT	13556	1	73-31-11 AW1285/ /	005-099
D42276JK		BACC10HF28C CABLE CLAMP	81205	1	73-31-11 */ /	ALL
D42276P	1	CN0966A28G42P8-000 PLUG	13556	1	73-31-11 AW1285/ /	001-004, 115-199
D42276P	1	BACC63CB28-42P8 PLUG	13556	1	73-31-11 AW1285/ /	005-099
D42276PQ		S2277-28-34 CABLE CLAMP	07418	1	73-31-11 */ */	ALL

EQUIPMENT LIST

D280N032

Section D42200

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42278J	1	CN0967C28G42S7-000 RCPT	13556	1	80-11-11 AW1285/ /	001-004, 115-199
D42278J	1	BACC63CC28-42S7 RCPT	13556	1	80-11-11 AW1285/ /	005-099
D42278JK		BACC10HF28C CABLE CLAMP	81205	1	80-11-11 */*/	ALL
D42278P	1	CN0966A28G42P7-000 PLUG	13556	1	80-11-11 AW1285/ /	001-004, 115-199
D42278P	1	BACC63CB28-42P7 PLUG	13556	1	80-11-11 AW1285/ /	005-099
D42278PQ		BACC10HF28C CABLE CLAMP	81205	1	80-11-11 */*/	001-004, 115-199
D42278PQ		BACC10HF28C CABLE CLAMP	06324	1	80-11-11 */*/	005-099
D42280J	1	CN0967C28G42P7-000 RECPT	13556	1	77-22-12 AW1285/ /	001-004
D42280J	1	BACC63CC28-42P7 RECPT	13556	1	77-22-12 AW1285/ /	005-099
D42280J	1	CN0967C28G42P7-000 RECPT-	13556	1	77-22-12 AW1285/ /	115-199
D42280JK		BACC10HF28C CABLE CLAMP	81205	1	77-22-12 */*/	001-004, 115-199
D42280JK		BACC10HF28C CABLE CLAMP	06324	1	77-22-12 */*/	005-099
D42280P	1	CN0966A28G42S7-000 PLUG	13556	1	77-22-12 AW1285/ /	001-004, 115-199
D42280P	1	BACC63CB28-42S7 PLUG	13556	1	77-22-12 AW1285/ /	005-099
D42280PQ		S2277-28-34 CABLE CLAMP	07418	1	77-22-12 */*/	ALL
D42282J	1	CN0967C24G30SN-000 RECPT-	13556	1	77-12-11 AW1285/ /	001-004, 115-199
D42282J	1	BACC63CC24-30SN RECPT-	13556	1	77-12-11 AW1285/ /	005-099

EQUIPMENT LIST

D280N032

Section D42200

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42282JK		BACC10HF24C CABLE CLAMP	81205	1	77-12-11 */*/	001-004, 115-199
D42282JK		BACC10HF24C CABLE CLAMP	06324	1	77-12-11 */*/	005-099
D42282P	1	CN0966A24G30PN-000 PLUG	13556	1	77-12-11 AW1285/ /	001-004, 115-199
D42282P	1	BACC63CB24-30PN PLUG	13556	1	77-12-11 AW1285/ /	005-099
D42282PQ		BACC10HF24C CABLE CLAMP	81205	1	77-12-11 */*/	ALL
D42284J	1	CN0967C28G42P8-000 PLUG	13556	1	77-11-11 AW2285/ /	001-004
D42284J	1	BACC63CC28-42P8 PLUG	13556	1	77-11-11 AW2285/ /	005-099
D42284J	1	CN0967C28G42P8-000 RECPT-	13556	1	77-11-11 AW2285/ /	115-199
D42284JK		S2277-28-34 CABLE CLAMP	07418	1	77-11-11 */*/	ALL
D42284P	1	CN0966A28G42S8-000 PLUG-	13556	1	77-11-11 AW2285/ /	001-004, 115-199
D42284P	1	BACC63CB28-42S8 PLUG-	81205	1	77-11-11 AW2285/ /	005-099
D42284PQ		S2277-28-34 CABLE CLAMP	07418	1	77-11-11 */*/	ALL
D42288J	1	CN0967C28G42SN-000 RCPT	13556	1	80-11-21 AW2285/ /	001-004, 115-199
D42288J	1	BACC63CC28-42SN RCPT	13556	1	80-11-21 AW2285/ /	005-099
D42288JK		BACC10HF28C CABLE CLAMP	81205	1	80-11-21 */*/	ALL
D42288P	1	CN0966A28G42PN-000 PLUG	13556	1	80-11-21 AW2285/ /	001-004, 115-199
D42288P	1	BACC63CB28-42PN PLUG	13556	1	80-11-21 AW2285/ /	005-099

EQUIPMENT LIST

D280N032

Section D42200

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42288PQ		BACC10HF28C CABLE CLAMP	81205	1	80-11-21 */*/	001-004, 115-199
D42288PQ		BACC10HF28C CABLE CLAMP	06324	1	80-11-21 */*/	005-099
D42290J	1	CN0967C28G42S7-000 RCPT	13556	1	80-11-21 AW2285/ /	001-004, 115-199
D42290J	1	BACC63CC28-42S7 RCPT	13556	1	80-11-21 AW2285/ /	005-099
D42290JK		BACC10HF28C CABLE CLAMP	81205	1	80-11-21 */*/	ALL
D42290P	1	CN0966A28G42P7-000 PLUG	13556	1	80-11-21 AW2285/ /	001-004, 115-199
D42290P	1	BACC63CB28-42P7 PLUG	13556	1	80-11-21 AW2285/ /	005-099
D42290PQ		S2277-28-34 CABLE CLAMP	07418	1	80-11-21 */*/	ALL
D42292J	1	CN0967C28G42P7-000 RECPT-	13556	1	77-12-31 AW2285/ /	001-004, 115-199
D42292J	1	BACC63CC28-42P7 RECPT-	13556	1	77-12-31 AW2285/ /	005-099
D42292JK		BACC10HF28C CABLE CLAMP	81205	1	77-12-31 */*/	001-004, 115-199
D42292JK		BACC10HF28C CABLE CLAMP	06324	1	77-12-31 */*/	005-099
D42292P	1	CN0966A28G42S7-000 PLUG-	13556	1	77-12-31 AW2285/ /	001-004, 115-199
D42292P	1	BACC63CB28-42S7 PLUG-	13556	1	77-12-31 AW2285/ /	005-099
D42292PQ		S2277-28-34 CABLE CLAMP	07418	1	77-12-31 */*/	ALL
D42294J	1	CN0967C24G30SN-000 RECPT-	13556	1	26-18-21 AW2285/ /	001-004, 115-199
D42294J	1	BACC63CC24-30SN RECPT-	13556	1	26-18-21 AW2285/ /	005-099

EQUIPMENT LIST

D280N032

Section D42200

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42294JK		BACC10HF24C CABLE CLAMP	81205	1	26-18-21 */*/	001-004, 115-199
D42294JK		BACC10HF24C CABLE CLAMP	06324	1	26-18-21 */*/	005-099
D42294P	1	CN0966A24G30PN-000 PLUG-	13556	1	26-18-21 AW2285/ /	001-004, 115-199
D42294P	1	BACC63CB24-30PN PLUG-	13556	1	26-18-21 AW2285/ /	005-099
D42294PQ		BACC10HF24C CABLE CLAMP	81205	1	26-18-21 */*/	ALL

EQUIPMENT LIST

D280N032

Section D42200

Page 10 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42368J	1	BACC45FN12-12P8 RCPT	81205	1	24-21-41 E5-1/ /	001-099
D42368P	1	BACC45FT12A12S8 PLUG	81205	1	24-21-41 E005-01/ /	001-099

EQUIPMENT LIST

D280N032

Section D42300
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42412J	1	BACC45FN12-12S RCPT	81205	1	32-42-21 E5-2/ /	001-099
D42412P	1	BACC45FT12A12P PLUG	81205	1	32-42-12 E5-2/ /	001-099
D42414J	1	BACC45FN12-12S9 RCPT	81205	1	32-42-21 E5-2/ /	001-099
D42414P	1	BACC45FT12A12P9 PLUG	81205	1	32-42-12 E5-2/ /	001-099

EQUIPMENT LIST

D280N032

Section D42400

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D42510J	1	BACC45FN14-15S6 RCPT	81205	1	32-42-11 E5-2/ /	001-099
D42510P	1	BACC45FT14A15P6 PLUG	81205	1	32-42-12 E005-02/ /	001-099
D42512J	1	BACC45FN10-5S8 RCPT	81205	1	32-42-11 E5-2/ /	001-099
D42512P	1	BACC45FT10A5P8 PLUG	81205	1	32-42-11 E005-02/ /	001-099
D42514J	1	BACC45FN10-5S7 RCPT	81205	1	32-42-11 E5-2/ /	001-099
D42514P	1	BACC45FT10A5P7 PLUG	81205	1	32-42-11 E5-2/ /	001-099
D42516J	1	BACC45FN16-24S6 RCPT	81205	1	32-42-11 E5-2/ /	001-099
D42516P	1	BACC45FT16A24P6 PLUG-	81205	1	32-42-12 E5-2/ /	001-099
D42518J	1	BACC45FN12-12S8 RCPT	81205	1	32-42-21 E5-2/ /	001-099
D42518P	1	BACC45FT12A12P8 PLUG	81205	1	32-42-11 E005-02/ /	001-099
D42520J	1	BACC45FN12-12S6 RCPT	81205	1	32-42-14 E5-2/ /	001-099
D42520P	1	BACC45FT12A12P6 PLUG	81205	1	32-42-11 E5-2/ /	001-099

EQUIPMENT LIST

D280N032

Section D42500
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43001J	1	BACC45FN16-24S8 RCPT-		1	34-51-11 E003-02/ /	001-099
D43001P	1	BACC45FT16A24P8 PLUG-	81205	1	34-51-11 E003-02/ /	001-099
D43003J	1	BACC45FN22-55S9 RCPT-	81205	1	34-51-11 E002-01/ /	001-099
D43003J	1	BACC45FN22-55S9 RCPT-	81205	1	34-45-01 E2-1/ /	115-199
D43003P	1	BACC45FT22A55P9 PLUG-	81205	1	34-51-11 E002-01/ /	001-099
D43003P	1	BACC45FT22A55P9 PLUG-	81205	1	34-45-01 E2-1/8/8	115-199
D43005J	1	BACC45FN18-31S7 RCPT-	81205	1	34-51-21 E003-02/ /	001-099
D43005J	1	BACC45FN16-24S7 RCPT	81205	1	34-45-02 E3-2/ /	115-199
D43005P	1	BACC45FT18A31P7 PLUG-	81205	1	34-51-21 E003-02/ /	001-099
D43005P	1	BACC45FT16A24P7 PLUG-	81205	1	34-45-02 E3-2/ /	115-199
D43007J	1	BACC45FN16-24S7 RCPT-	81205	1	34-51-21 E002-02/ /	001-099
D43007P	1	BACC45FT16A24P7 PLUG-	81205	1	34-51-21 E002-02/ /	001-099
D43009J	1	BACC45FN16-24S8 PLUG-		1	34-51-11 E003-02/ /	001-099
D43009P	1	BACC45FT16A24P8 PLUG	81205	1	34-32-11 E003-02/ /	001-099
D43010J	1	CN0967C18G14SN-000 RCPT-	13556	1	32-42-11 AD1090/ /	001-004
D43010J	1	BACC63CC18-14SN RCPT-	81205	1	32-42-11 AD1090/ /	005-099
D43010J	1	CN0967C18G14SN-000 RCPT-		1	32-42-11 AD1090/ /	115-199

EQUIPMENT LIST

D280N032

Section D43000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43010JK		BACC10HG18C CABLE CLAMP	81205	1	32-42-11 */ /	ALL
D43010P	1	CN0966A18G14PN-000 PLUG	81205	1	32-42-11 AD1090/ /	001-004, 115-199
D43010P	1	BACC63CB18-14PN PLUG	81205	1	32-42-11 AD1090/ /	005-099
D43010PQ		BACC10HF18C CABLE CLAMP	81205	1	32-42-11 */ */	ALL
D43011J	1	BACC45FN10-5S7 PLUG-	81205	1	34-51-11 E003-02/ /	001-099
D43011P	1	BACC45FT10A5P7 PLUG	81205	1	34-51-11 E3-2/ /	001-099
D43012J	1	BACC45FN18-31S RCPT	81205	1	32-42-11 E6-4/ /	115-199
D43012P	1	BACC45FT18-31P PLUG	81205	1	32-42-11 E6-4/ /	115-199
D43014J	1	BACC45FN18-31S6 RCPT	81205	1	32-42-11 E6-4/ /	115-199
D43014P	1	BACC45FT18-31P6 PLUG	81205	1	32-42-11 E6-4/ /	115-199
D43015J	1	BACC45FN10-5S7 PLUG-	81205	1	34-21-51 E003-02/ /	001-099
D43015P	1	BACC45FT10A5P7 PLUG	81205	1	34-51-21 E3-2/ /	001-099
D43017J	9	BACC45FN18-31S9 RCPT	81205	1	34-61-26 P0037-00/ /	115-199
D43017P	9	BACC45FT18A31P9 PLUG- (34-0414)	81205	1	34-61-26 P037-00/ /	115-199
D43019J	9	BACC45FN22-55S RCPT-	81205	1	34-22-38 P036-00/ /	115-199
D43019P	9	BACC45FT22A55P PLUG (34-0414)	81205	1	34-61-16 P036-00/ /	115-199
D43021J	1	BACC45FN18-31S9 RCPT-	81205	1	34-61-26 E002-02/ /	010-099

EQUIPMENT LIST

D280N032

Section D43000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43021P	9	BACC45FT22A55P9 PLUG- (34-0414)	81205	1	34-61-26 E002-02/ /	115-199
D43021P	1	BACC45FT18-31P9 PLUG-	81205	1	34-61-24 E002-02/ /	010-099
D43023J	9	BACC45FN22-55S7 RCPT (34-0414)	81205	1	34-61-16 E002-001/ /	115-199
D43023P	9	BACC45FN22A55P7 PLUG (34-0414)	81205	1	31-31-02 E002-01/ /	115-199

EQUIPMENT LIST

D280N032

Section D43000

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43309J	1	BACC45FN18-31P6 RCPT-	81205	1	31-31-61 E003-03/ /	010-099
D43309P	1	BACC45FT18A31S6 PLUG-	81205	1	31-31-61 E003-03/ /	010-099
D43315J	1	BACC45FN18-31P6 RCPT-	81205	1	31-31-61 E003-03/ /	010-099
D43315P	1	BACC45FT18-31S6 PLUG-	81205	1	31-31-41 E003-03/ /	010-099

EQUIPMENT LIST

D280N032

Section D43300
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D43683P	1	BACC45FT16A24S PLUG	81205	1	34-57-21 E3-2/ /	001-009
D43685J	1	BACC45FN16-24P9 RCPT	81205	1	34-57-11 E003-02/ /	001

EQUIPMENT LIST

D280N032

Section D43600

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D44102J	1	BACC45FN12-12P6 RECP	81205	1	26-21-11 P061-00/ /	001-099
D44102J	1	BACC45FN12-12P6 RECP	81205	1	26-21-11 P61/ /	115-199
D44102P	1	BACC45FT12A12S6 PLUG	81205	1	26-21-11 P061-00/ /	ALL
D44104J	1	BACC45FN10-5P9 RECP	81205	1	26-21-11 P061-00/ /	001-099
D44104J	1	BACC45FN10-5P9 RECP	81205	1	26-21-11 P61/ /	115-199
D44104P	1	BACC45FT10A5S9 PLUG	81205	1	26-23-11 P061-00/ /	ALL
D44106J	1	BACC45FN12-12P RECP	81205	1	26-21-11 P061-00/ /	001-099
D44106J	1	BACC45FN12-12P RECP	81205	1	26-21-11 P61/ /	115-199
D44106P	1	BACC45FT12A12S PLUG	81205	1	26-23-11 P061-00/ /	ALL
D44108J	1	BACC45FN10-5P7 RECP	81205	1	26-21-11 P061-00/ /	001-099
D44108J	1	BACC45FN10-5P7 RECP	81205	1	26-21-11 P61/ /	115-199
D44108P	1	BACC45FT10A5S7 PLUG	81205	1	26-21-11 P061-00/ /	ALL

EQUIPMENT LIST

D280N032

Section D44100
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D45001J	1	BACC45FN16-24P6 RCPT-	81205	1	34-22-81 E003-02/ /	001-099
D45001P	1	BACC45FT16A24S6 PLUG	81205	1	23-51-13 E003-02/ /	001-099
D45003J	1	BACC45FN16-24P9 RCPT		1	23-51-13 E006-01/ /	001-099
D45003P	1	BACC45FT16A24S9 PLUG	81205	1	23-51-13 E006-01/ /	001-099
D45005J	1	BACC45FN16-24P7 RCPT-	81205	1	23-51-13 E003-02/ /	001-099
D45005P	1	BACC45FT16A24S7 PLUG	81205	1	23-51-13 E3-2/ /	001-099
D45007J	1	BACC45FN16-24P8 RPT		1	23-51-13 E006-01/ /	001-099
D45007P	1	BACC45FT16A24S8 PLUG	81205	1	23-51-13 E6-1/ /	001-099
D45017J	9	121-44-9 RECPT	91836	1	34-58-11 E002-03/ /	115-199
D45017P	9	125-88-9 PLUG	91836	1	34-58-11 E002-03/ /	115-199
D45019J	9	121-44-9 RECPT	91836	1	34-58-21 E002-02/ /	115-199
D45019P	9	125-88-9 PLUG - (TNC) STRAIGHT	91836	1	34-58-21 E002-02/ /	115-199

EQUIPMENT LIST

D280N032

Section D45000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D52172P	1	BACC45FT10A5P PLUG-	81205	1	33-22-12 682/238/L047	115-199

EQUIPMENT LIST

D280N032

Section D52100
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D65001J	9	BACC45FN24-61S7 RECEPT- (S/B: 757-34-0200)	81205	1	34-46-14 P065-00/ /	002
D65001P	9	BACC45FT24-61P7 PLUG- (S/B: 757-34-0200)	81205	1	34-46-14 P065-00/ /	002
D65003J	9	BACC45FN24-61S PLUG- (S/B: 757-34-0200)	81205	1	34-46-14 P065-00/ /	002
D65003P	9	BACC45FT24-61P PLUG- (S/B: 757-34-0200)	81205	1	34-46-14 P065-00/ /	002

EQUIPMENT LIST

D280N032

Section D65000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E001-01		284N1511 SHELF E1-1	284N1310 81205	1	91-03-01 E001-01/ /	ALL
E001-02		284N1512 SHELF E1-2	284N1310 81205	1	91-03-01 E001-02/ /	ALL

EQUIPMENT LIST

D280N032

Section E001
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E002-01		284N1521 SHELF E2-1	284N1310 81205	1	22-21-21 E002-01/ /	ALL
E002-02		284N1522 SHELF E2-3	284N1310 81205	1	91-03-02 E002-02/ /	ALL
E002-03		284N1523 SHELF E2-3	284N1310 81205	1	30-41-11 E002-03/ /	ALL
E002-04		284N1524 SHELF E2-4	284N1310 81205	1	91-03-02 E002-04/ /	ALL

EQUIPMENT LIST

D280N032

Section E002
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E003-01		284N1531 SHELF E3-1	284N1310 81205	1	30-32-11 E003-01/ /	ALL
E003-02		284N1532 SHELF E3-2	284N1310 81205	1	91-03-03 E003-02/ /	ALL
E003-03		284N1506 SHELF E3-3	284N1310 81205	1	22-32-13 E003-03/ /	ALL
E003-04		284N1534 SHELF E3-4	284N1310 81205	1	27-23-11 E003-04/ /	ALL

EQUIPMENT LIST

D280N032

Section E003
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E004-01		284N1541 SHELF E4-1	284N1310 81205	1	22-21-11 E004-01/ /	ALL
E004-02		284N1542 SHELF E4-2	284N1310 81205	1	21-25-21 E004-02/ /	ALL
E004-03		284N1543 SHELF E4-3	284N1310 81205	1	21-51-11 E004-03/ /	ALL
E004-04		284N1544 SHELF E4-4	284N1310 81205	1	22-21-21 E004-04/ /	ALL

EQUIPMENT LIST

D280N032

Section E004
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E005-01		284N1551 SHELF E5-1	284N1310 81205	1	91-03-05 E005-01/ /	ALL
E005-02		284N1552 SHELF E5-2	284N1310 81205	1	21-31-21 E005-02/ /	ALL
E005-03		284N1553 SHELF E5-3	284N1310 81205	1	21-31-11 E005-03/ /	ALL

EQUIPMENT LIST

D280N032

Section E005
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E006-00		284N1474 RACK	284N1460 81205	1	91-03-06 E006-00/ /	ALL
E006-01		284N1561 SHELF E6-1	284N1470 81205	1	91-03-06 E006-01/ /	ALL
E006-02		284N1562 SHELF E6-2	284N1470 81205	1	91-03-06 E006-02/ /	ALL
E006-03		284N1563 SHELF E6-3	284N1470	0	91-03-06 E006-03/ /	ALL

EQUIPMENT LIST

D280N032

Section E006
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
J00001		287N6110-1 JUNCTION BOX-LEFT LANDING GEAR FWD.	287N6100 81205	1	32-42-11 / /	001-099
J00002		287N6109-1 JUNCTION BOX-LEFT LANDING GEAR AFT.	287N6100	0	32-42-11 / /	001-099
J00003		287N6110-1 JUNCTION BOX-RIGHT LANDING GEAR FWD	287N6100 81205	1	32-42-11 / /	001-099
J00004		287N6109-1 JUNCTION BOX-RIGHT LANDING GEAR AFT.	287N6100 81205	1	32-42-11 / /	001-099

EQUIPMENT LIST

D280N032

Section J00000
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00004		TDH-7101-5001 RELAY-OXYGEN CONTROL	284N1127 35344	1	35-21-11 P037-00/ /	001-099
K00004	1	BACR13CG2A RELAY-OXYGEN CONTROL	284N1127 81205	1	35-21-11 P037-00/ /	115-199
K00004	2	BACR13CG2AB RELAY-OXYGEN CONTROL	284N1127 81205	1	35-21-11 P037-00/ /	115-199
K00005		BACR13CF2AB RELAY-POWER,LAVATORIES	284N1316 81205	1	38-14-11 P034-00/* /	001-099
K00005		BACR13CF2AB RELAY-POWER,LAVATORIES	284N1125 81205	1	38-14-11 P034-00/ /	115-199
K00006		10-60450-6 RELAY-WATER PRESS SYS	284N1127 81205	1	38-15-11 P037-00/ /	001-099
K00006		10-60450-2 RELAY-WATER PRESS SYS	284N1127 81205	1	38-15-11 P037-00/ /	115-199
K00007		TDH-7101-5001 RELAY-OXY CONT,MANUAL DEPLOY	284N1127 35344	1	35-21-11 P037-00/ /	001-099
K00007	1	BACR13CG2A RELAY-OXY CONT,MANUAL DEPLOY	284N1127 81205	1	35-21-11 P037-00/ /	115-199
K00007	2	BACR13CG2AB RELAY-OXY CONT,MANUAL DEPLOY	284N1127 81205	1	35-21-11 P037-00/ /	115-199
K00015		BACR13CD2 RELAY-FLT REC EFIS I/P SWITCHING	284N1127 81205	1	31-31-41 P037-00/ /	ALL
K00021		BACR13CD2 RELAY-AIR SUPPLY ISLN VLV,CLOSED IND	284N1320 81205	1	36-11-31 P037-00/ /	ALL
K00022		BACR13CD2 RELAY-AIR SUPPLY ISLN VLV,OPEN IND	284N1320 81205	1	36-11-31 P037-00/ /	ALL
K00023		BACR13CG2AB RELAY-APU AIR SUPPLY VALVE,CONTROL	284N1127 81205	1	36-11-41 P037-00/ /	ALL
K00024		BACR13CD2 RELAY-APU AIR SUPPLY VALVE,CLOSED POSN	284N1127 81205	1	36-11-41 P037-00/ /	ALL
K00025		BACR13CE2 RELAY-OPEN POSN,APU AIR SUPPLY VALVE	284N1127 81205	1	36-11-41 P037-00/ /	ALL
K00026		BACR13CF2A RELAY-THRUST REV STOW,L ENG	284N1125 81205	1	78-34-11 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00027		BACR13CF2A RELAY-THRUST REV STOW,R ENG	284N1127 81205	1	78-34-21 P037-00/ /	ALL
K00031		MS27706-2B RELAY-CARGO DR HINGE CONTROL	284N1747 96906	1	52-34-11 P065-00/ /	115-199
K00036		MS27706-2B RELAY-NO.2 CARGO DR HINGE	284N1680 96906	1	52-35-11 E006-00/ /	115-199
K00049		BACR13CG2AB RELAY-AUTO/MANUAL 1,R PACK	284N1127 81205	1	21-51-22 P037-00/ /	001-099
K00049		BACR13CG2AB RELAY-AUTO/MANUAL 1,R PACK	284N1680 81205	1	21-51-22 E006-00/ /	115-199
K00050		BACR13CG2AB RELAY-AUTO/MANUAL 2,R PACK	284N1127 81205	1	21-51-22 P037-00/ /	001-099
K00050		BACR13CG2AB RELAY-AUTO/MANUAL 2,R PACK	284N1680 81205	1	21-51-22 E006-00/ /	115-199
K00051		BACR13CF2AB RELAY-PACK EXIT DOOR OPEN MAN,RIGHT	284N1127 81205	1	21-51-23 P037-00/ /	001-099
K00051		BACR13CF2AB RELAY-PACK EXIT DOOR OPEN MAN,RIGHT	284N1680 81205	1	21-51-23 E006-00/ /	115-199
K00052		BACR13CF2AB RELAY-PACK EXIT DOOR CLOSE MAN,RIGHT	284N1127 81205	1	21-51-23 P037-00/ /	001-099
K00052		BACR13CF2AB RELAY-PACK EXIT DOOR CLOSE MAN,RIGHT	284N1680 81205	1	21-51-23 E006-00/ /	115-199
K00053		BACR13CF2AB RELAY-PACK INLET DOOR OPEN MAN,RIGHT	284N1127 81205	1	21-51-23 P037-00/ /	001-099
K00053		BACR13CF2AB RELAY-PACK INLET DOOR OPEN MAN,RIGHT	284N1680 81205	1	21-51-23 E006-00/ /	115-199
K00054		BACR13CF2AB RELAY-INLET DOOR CLOSE,MAN,R	284N1127 81205	1	21-51-23 P037-00/ /	001-099
K00054		BACR13CF2AB RELAY-INLET DOOR CLOSE,MAN,R	284N1680 81205	1	21-51-23 E006-00/ /	115-199
K00055		BACR13CF2AB RELAY-TEMP CONT VALVE OPEN MAN,RIGHT	284N1127 81205	1	21-51-23 P037-00/ /	001-099
K00055		BACR13CF2AB RELAY-TEMP CONT VALVE OPEN MAN,RIGHT	284N1680 81205	1	21-51-23 E006-00/ /	115-199

EQUIPMENT LIST

D280N032

Section K00000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00056		BACR13CF2AB RELAY-TEMP CONT VLV CLOSE,MAN,R	284N1127 81205	1	21-51-23 P037-00/ /	001-099
K00056		BACR13CF2AB RELAY-TEMP CONT VLV CLOSE,MAN,R	284N1680 81205	1	21-51-23 E006-00/ /	115-199
K00057		BACR13CG2AB RELAY-AUTO/MANUAL 1,LEFT PACK	284N1125 81205	1	21-51-12 P036-00/ /	001-099
K00057		BACR13CG2AB RELAY-AUTO/MANUAL 1,LEFT PACK	284N1680 81205	1	21-51-12 E006-00/ /	115-199
K00058		BACR13CG2AB RELAY-AUTO/MANUAL 2,LEFT PACK	284N1125 81205	1	21-51-12 P036-00/ /	001-099
K00058		BACR13CG2AB RELAY-AUTO/MANUAL 2,LEFT PACK	284N1680 81205	1	21-51-12 E006-00/ /	115-199
K00059		BACR13CF2AB RELAY-PACK EXIT DOOR OPEN MAN,LEFT	284N1125 81205	1	21-51-13 P036-00/ /	001-099
K00059		BACR13CF2AB RELAY-PACK EXIT DOOR OPEN MAN,LEFT	284N1680 81205	1	21-51-13 E006-00/ /	115-199
K00060		BACR13CF2AB RELAY-PACK EXIT DOOR CLOSE MAN,LEFT	284N1125 81205	1	21-51-13 P036-00/ /	001-099
K00060		BACR13CF2AB RELAY-PACK EXIT DOOR CLOSE MAN,LEFT	284N1680 81205	1	21-51-13 E006-00/ /	115-199
K00061		BACR13CF2AB RELAY-PACK INLET DOOR OPEN MAN,LEFT	284N1125 81205	1	21-51-13 P036-00/ /	001-099
K00061		BACR13CF2AB RELAY-PACK INLET DOOR OPEN MAN,LEFT	284N1680 81205	1	21-51-13 E006-00/ /	115-199
K00062		BACR13CF2AB RELAY-INLET DOOR CLOSE,MAN,LEFT	284N1125 81205	1	21-51-13 P036-00/ /	001-099
K00062		BACR13CF2AB RELAY-INLET DOOR CLOSE,MAN,LEFT	284N1680 81205	1	21-51-13 E006-00/ /	115-199
K00063		BACR13CF2AB RELAY-TEMP CONT VALVE OPEN MAN,LEFT	284N1125 81205	1	21-51-13 P036-00/ /	001-099
K00063		BACR13CF2AB RELAY-TEMP CONT VALVE OPEN MAN,LEFT	284N1680 81205	1	21-51-13 E006-00/ /	115-199
K00064		BACR13CF2AB RELAY-TEMP CONT VLV CLOSE,MAN,L	284N1125 81205	1	21-51-13 P036-00/ /	001-099

EQUIPMENT LIST

D280N032

Section K00000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00064		BACR13CF2AB RELAY-TEMP CONT VLV CLOSE,MAN,L	284N1680 81205	1	21-51-13 E006-00/ /	115-199
K00087		BACR13CG2A RELAY-AUTO SPEED BRAKE AIR/GND,1	284N1125 81205	1	27-62-11 P036-00/ /	ALL
K00088		BACR13CG2A RELAY-AUTO SPEED BRAKE AIR/GND,2	284N1125 81205	1	27-62-11 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00000
Page 4 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00101		10-61445-24 RELAY-GND HANDLING	284N1316 81205	1	24-51-61 P034-00/ /	ALL
K00102		10-61445-23 RELAY-TRANSFER,GND SERVICE	284N1316 81205	1	24-51-51 P034-00/ /	001-099
K00102		10-61445-23 RELAY-TRANSFER,GND SERVICE	284N1127 81205	1	24-51-51 P037-00/ /	115-199
K00103		10-61445-23 RELAY-SELECT,GND SERVICE	284N1316 81205	1	24-51-51 P034-00/ /	ALL
K00104		10-61445-21 RELAY-MAIN BAT	287N4102 81205	1	24-33-11 P006-00/ /	ALL
K00105		E-308AH RELAY-AC STBY PWR	287N4102 74063	1	24-33-11 P006-00/ /	ALL
K00106		10-61445-21 RELAY-MAIN BAT XFR	287N4102 81205	1	24-33-11 P006-00/ /	ALL
K00107		BACR13CG2A RELAY-CTR BUS XFR	287N4102 81205	1	24-51-31 P006-00/ /	ALL
K00108		A-1077DD RELAY-TIE,DC	287N4102 74063	1	24-32-11 P006-00/ /	ALL
K00109		MS27743-6 RELAY-STBY PWR	287N4102 96906	1	24-33-11 P006-00/ /	ALL
K00110		BACR13CG2A RELAY-DC STBY BUS OFF	287N4102 81205	1	24-33-11 P006-00/ /	ALL
K00113		E-311P RELAY-DC UNDER VOLTAGE SENSE	287N4102 74063	1	24-33-11 P006-00/ /	ALL
K00114		S281T004-2 CONTACTOR-EXTERNAL POWER	284N1316 81205	1	24-41-11 P034-00/ /	ALL
K00115		BACR13CG2A RELAY-MAIN BAT CHGR DISABLE	287N4102 81205	1	24-31-11 P006-00/ /	ALL
K00116		BACR13CG2A RELAY-APU BAT CHGR INTLK	284N1680 81205	1	24-31-41 E006-00/ /	001-099
K00116		BACR13CG2A RELAY-APU BAT CHGR INTLK	284N1690 81205	1	24-31-41 E006-00/ /	115-199
K00117		A-703CD CONTACTOR-APU CRANK	284N1474 74063	1	49-41-11 E006-00/174/R050	001-099

EQUIPMENT LIST

D280N032

Section K00100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00117		A-703CD CONTACTOR-APU CRANK	284N1680 74063	1	49-41-11 E006-00/174/R050	115-199
K00119		10-61445-21 RELAY-UTILITY BUS,LEFT	284N1129 81205	1	24-51-14 P070-00/ /	ALL
K00120		10-61445-21 RELAY-UTILITY BUS,RIGHT	284N1320 81205	1	24-51-24 P037-00/ /	ALL
K00122		BACR13CG2AB RELAY-ISLN REQUEST	287N4102 81205	1	24-51-31 P006-00/ /	ALL
K00123		BACR13CG2A RELAY-CTR BUS ISOL	287N4102 81205	1	24-51-31 P006-00/ /	ALL
K00124		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00128		BACR13CF2A RELAY-CONTROL,C2 EMP	284N1125 81205	1	29-11-31 P036-00/ /	ALL
K00135		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00137	1	M83726-3-155 RELAY-IRS DC POWER DISCONNECT	287N4102 96906	1	34-21-21 P006-00/ /	001-099
K00137	1	M83726-3-155 RELAY-IRS DC POWER DISCONNECT	287N4102 96906	1	34-21-11 P006-00/ /	115-199
K00137	2	M83726-28-3003-P RELAY-IRS DC POWER DISCONNECT	287N4102 96906	1	34-21-21 P006-00/ /	001-099
K00137	2	M83726-28-3003-P RELAY-IRS DC POWER DISCONNECT	287N4102 96906	1	34-21-11 P006-00/ /	115-199
K00138		BACR13CJ2 RELAY-AC STBY BUS OFF	287N4102 81205	1	24-33-11 P006-00/ /	ALL
K00140		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00141		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00142		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00143		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00144		BACR13CG2A RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	001-099
K00144		BACR13CG2A RELAY-AIR/GND,SYS 1	284N1318 81205	1	32-09-11 P033-00/ /	115-199
K00145		BACR13CG2A RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00148		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00149		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00161		MS27743-6 RELAY-LDG LT DIMMING,LEFT	284N1318 96906	1	33-42-11 P033-00/ /	ALL
K00162		MS27743-6 RELAY-LDG LT DIMMING,RIGHT	284N1316 96906	1	33-42-11 P034-00/ /	001-099
K00162		MS27751-1 RELAY-LDG LT DIMMING,RIGHT	284N1316 96906	1	33-42-11 P034-00/ /	115-199
K00167		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00170		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00175		BACR13CG2A RELAY-APU FUEL CONTROL	284N1680 81205	1	49-61-11 E006-00/ /	ALL
K00176		BACR13CF2A RELAY-APU INLET DOOR	284N1680 81205	1	49-61-11 E006-00/ /	ALL
K00177		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00178		BACR13CG2A RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K00179		BACR13CG2A RELAY-FUELING PANEL DOOR	284N1318 81205	1	28-21-11 P033-00/ /	ALL
K00180		TDH-8116-5001 RELAY-OVERFILL SET	284N1318 35344	1	28-21-21 P033-00/ /	ALL
K00181		BACR13CF2A RELAY-OVERFILL CONT	284N1318 81205	1	28-21-21 P033-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00187		MS27418-2A RELAY-FUEL BOOST PUMP CONT,L AFT	284N1318 96906	1	28-22-11 P033-00/ /	ALL
K00188		MS27418-2A RELAY-FUEL BOOST PUMP CONT,L FWD	284N1127 96906	1	28-22-11 P037-00/ /	ALL
K00189		MS27418-2A RELAY-FUEL BOOST PUMP CONT,R AFT	284N1127 96906	1	28-22-11 P037-00/ /	ALL
K00190		MS27418-2A RELAY-FUEL BOOST PUMP CONT,R FWD	284N1318 96906	1	28-22-11 P033-00/ /	ALL
K00191	1	9324-7424 RELAY-FUEL PUMP CONT,DC	284N1129 96906	1	28-25-11 P070-00/ /	ALL
K00191	2	MS27418-2B RELAY-FUEL PUMP CONT,DC	284N1129 96906	1	28-25-11 P070-00/ /	ALL
K00197		BACR13CG2A RELAY-APU START	284N1680 81205	1	49-41-11 E006-00/ /	ALL
K00199		BACR13CG2A RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00100
Page 4 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00200		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00201		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00202		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00203		BACR13CG2A RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00204		BACR13CG2A RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00205		BACR13CG2A RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00206		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00207		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00208		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00209		BACR13CG2A RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00211		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00213		BACR13CG2A RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00214		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00215		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K00217		BACR13CF2A RELAY-AUTO SPEED BRAKE EXT	284N1125 81205	1	27-62-11 P036-00/ /	ALL
K00218		BACR13CF2A RELAY-AUTO SPEED BRAKE RET	284N1125 81205	1	27-62-11 P036-00/ /	ALL
K00219		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00200

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00220		BACR13CD2 RELAY-AUTO SPEED BRAKE WRN	284N1125 81205	1	27-62-11 P036-00/ /	ALL
K00238		BACR13CG2AB RELAY-ZONE DUCT OVHT,FLT DECK	284N1320 81205	1	21-61-11 P037-00/ /	ALL
K00239		BACR13CG2AB RELAY-DUCT OVHT,FWD,ZONE	284N1320 81205	1	21-61-21 P037-00/ /	ALL
K00240		BACR13CG2AB RELAY-DUCT OVHT,AFT,ZONE	284N1127 81205	1	21-61-31 P037-00/ /	ALL
K00242	1	080-20465-01 RELAY-CURRENT SENSING,AUX PITOT,L	284N1318 95266	1	30-31-11 P033-00/ /	ALL
K00243		080-20465-01 RELAY-CURRENT SENSING,PITOT,CAPT	284N1318 95266	1	30-31-11 P033-00/ /	ALL
K00263		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00200
Page 2 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00310		080-20465-01 RELAY-CURRENT SENSING,PITOT,F/O	284N1127 95266	1	30-31-12 P037-00/ /	ALL
K00312		080-20465-01 RELAY-CURRENT SENSING,AUX PITOT,R	284N1127 95266	1	30-31-12 P037-00/ /	ALL
K00343		9123-8072 RELAY-FWD EQUIP SUPPLY FAN 1	284N1125 35344	1	21-58-13 P036-00/ /	ALL
K00344		9123-8072 RELAY-FWD EQUIP SUPPLY FAN 2	284N1127 35344	1	21-58-13 P037-00/ /	ALL
K00346		KDA-E4F RELAY-AFT EQUIP EXHAUST FAN 1	284N1127 35344	1	21-58-21 P037-00/ /	ALL
K00347		KDA-E4F RELAY-AFT EQUIP/LAV/GALLEY VENT FAN 2	284N1125 35344	1	21-58-21 P036-00/ /	ALL
K00356		BACR13CG2A RELAY-FUEL QTY PWR XFER	284N1318 81205	1	28-21-11 P033-00/ /	ALL
K00357		BACR13CG2A RELAY-FUELING PWR XFER	284N1318 81205	1	28-21-11 P033-00/ /	ALL
K00359		10-61445-21 RELAY-EXT,ALT FLAP	284N1318 81205	1	27-51-11 P033-00/ /	ALL
K00360		10-61445-21 RELAY-RET,ALT FLAP	284N1318 81205	1	27-51-11 P033-00/ /	ALL
K00369		BACR13CG2AB RELAY-SUPPLY SMOKE SENSING	284N1125 81205	1	21-58-12 P036-00/ /	ALL
K00396		10-60450-2 RELAY-LTG,STBY INSTR	233N2400 81205	1	33-13-11 P003-01/ /	ALL

EQUIPMENT LIST

D280N032

Section K00300

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00400		770-540-1 RELAY-CURRENT SENSING,R	284N1127 F0553	1	30-32-11 P037-00/ /	ALL
K00401		770-540-1 RELAY-CURRENT SENSING,L	284N1318 F0553	1	30-32-11 P033-00/ /	ALL
K00410		770-540-1 RELAY-CURRENT SENSING,TAT PROBE,R	284N1127 F0553	1	30-33-11 P037-00/ /	ALL
K00415		9123-8072 RELAY-RECIRC FAN,L	284N1129 96906	1	21-25-11 P070-00/ /	ALL
K00416		9123-8072 RELAY-RECIRC FAN,R	284N1127 35344	1	21-25-11 P037-00/ /	ALL
K00419		BACR13CE2 RELAY-PARKING BRAKE CLOSE SENSE	284N1125 81205	1	32-44-11 P036-00/ /	ALL
K00420		083-20229-01 RELAY-INTERRUPTER,APU HORN	284N1318 95266	1	26-15-12 P033-00/ /	ALL
K00421		BACR13CG2A RELAY-EXTERNAL SHUTDOWN	284N1318 81205	1	26-15-12 P033-00/ /	ALL
K00435		MS27743-6 RELAY-NLG LT,RIGHT	284N1316 96906	1	33-42-11 P034-00/ /	001-099
K00435		MS27751-1 RELAY-NLG LT,RIGHT	284N1316 96906	1	33-42-11 P034-00/ /	115-199
K00449		BACR13CD2 RELAY-DEFUEL VALVE IND,L	284N1318 81205	1	28-26-11 P033-00/ /	ALL
K00450		BACR13CD2 RELAY-DEFUEL VALVE IND,R	284N1318 81205	1	28-26-11 P033-00/ /	ALL
K00452		BACR13CF2A RELAY-DEFUEL VALVE CONT,L	284N1318 81205	1	28-26-11 P033-00/ /	ALL
K00453		BACR13CF2A RELAY-DEFUEL VALVE CONT,R	284N1318 81205	1	28-26-11 P033-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00400

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00505		BACR13CG2A RELAY-APU FUEL PUMP XFR	284N1129 81205	1	28-25-11 P070-00/ /	ALL
K00510		BACR13CD2 RELAY-IRS SEL,R	284N1127 81205	1	32-42-11 P037-00/ /	ALL
K00511		BACR13CD2 RELAY-IRS SEL,L	284N1125 81205	1	32-42-11 P036-00/ /	ALL
K00512		TDH-1852-1002 RELAY-PUMP START,L FWD	284N1129 35344	1	28-25-11 P070-00/ /	001-099
K00512		TDH-8119-1002 RELAY-PUMP START,L FWD	284N1129 35344	1	28-25-11 P070-00/ /	115-199
K00526		BACR13CG2AB RELAY-AUTOLAND,LEFT	284N1314 81205	1	24-22-12 P031-00/ /	ALL
K00527		BACR13CG2AB RELAY-AUTOLAND,RIGHT	284N1315 81205	1	24-22-22 P032-00/ /	ALL
K00550		BACR13CD2 RELAY-PRESS,LDG GEAR TILT	284N1127 81205	1	27-62-11 P037-00/ /	ALL
K00551		MS27743-6 RELAY-NOSE GEAR TAXI LT	284N1318 96906	1	33-42-31 P033-00/ /	001-099
K00574		X-D4N RELAY-TRIM LIMIT SELECT,LEFT	284N1541 35344	1	27-41-11 E003-01/ /	ALL
K00575		X-D4N RELAY-TRIM LIMIT SELECT,RIGHT	284N1531 35344	1	27-41-21 E004-01/ /	ALL

EQUIPMENT LIST

D280N032

Section K00500

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00616		BACR13CD2 RELAY-APU START TRU OVHT PROT	284N1680 81205	1	24-32-41 E006-00/ /	ALL
K00619		10-60450-1 RELAY-APU START TRU FAN PWR	284N1680 81205	1	24-32-41 E006-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00600
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00757		BACR13CG2AB RELAY-FMC TUNING,L	284N1125 81205	1	34-61-15 P036-00/ /	ALL
K00758		BACR13CG2AB RELAY-FMC TUNING,R	284N1127 81205	1	34-61-25 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K00700

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02065	9	BACR13CD2 RELAY-CDU NAV ENABLE,LEFT (SB 34-0427)	284N1125 35344	1	34-61-15 P036-00/ /	001
K02065	9	BACR13CD2 RELAY-CDU NAV ENABLE,LEFT (SB 34-0414)	284N1125 35344	1	34-61-15 P036-00/ /	115-199
K02066	9	BACR13CD2 RELAY-CDU NAV ENABLE,RIGHT (SB 34-0427)	284N1127 35344	1	34-61-15 P037-00/ /	001
K02066	9	BACR13CD2 RELAY-CDU NAV ENABLE,RIGHT (34-0414)	284N1127 35344	1	34-61-15 P037-00/ /	115-199
K02067	9	BACR13CD2 RELAY-FCC SOURCE SELECT,LEFT(SB 34-0427)	284N1125 35344	1	34-61-15 P036-00/ /	001
K02067	9	BACR13CD2 RELAY-FCC SOURCE SELECT,LEFT(SB 34-0414)	284N1125 35344	1	34-61-15 P036-00/ /	115-199
K02068	9	BACR13CD2 RELAY-FCC SOURCE SELECT,RIGHT(SB34-0427)	284N1127 35344	1	34-61-25 P037-00/ /	001
K02068	9	BACR13CD2 RELAY-FCC SOURCE SELECT,RIGH (SB34-0414)	284N1127 35344	1	34-61-25 P037-00/ /	115-199
K02069	9	BACR13CD2 RELAY-CAPT & F/O B/ON SG-C (SB 34-0427)	284N1127 35344	1	34-61-25 P037-00/ /	001
K02069	9	BACR13CD2 RELAY-CAPT & F/O B/ON SG-C (SB 34-0414)	284N1127 35344	1	34-61-25 P037-00/ /	115-199

EQUIPMENT LIST

D280N032

Section K02000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10010		10-61445-21 RELAY-APU TRU START	284N1690 81205	1	24-32-41 E006-00/ /	ALL
K10011		MS27418-2A RELAY-OVRD FUEL BOOST PUMP CONT,L	284N1318 96906	1	28-22-11 P033-00/ /	ALL
K10012		MS27418-2A RELAY-OVRD FUEL BOOST PUMP CONT,R	284N1127 96906	1	28-22-11 P037-00/ /	ALL
K10013		BACR13CF2A RELAY-REFUELING VALVE,L CTR	284N1318 81205	1	28-21-22 P033-00/ /	ALL
K10024		BACR13CF2A RELAY-REFUELING VALVE,R	284N1318 81205	1	28-21-22 P033-00/ /	ALL
K10025		BACR13CF2A RELAY-REFUELING VALVE,L	284N1318 81205	1	28-21-22 P033-00/ /	ALL
K10028		9324-7424 RELAY-FASTEN SEAT BELT	284N1316 35344	1	33-24-11 P034-00/ /	ALL
K10029		BACR13CG2A RELAY-NO SMOKING	284N1316 81205	1	33-24-11 P034-00/ /	ALL
K10030		BACR13CF2A RELAY-APU START CONTROL	284N1680 81205	1	49-61-11 E006-00/ /	115-199
K10033		BACR13CG2A RELAY-APU FAULT	284N1680 81205	1	49-61-11 E006-00/ /	ALL
K10038		BACR13CE2 RELAY-OXYGEN DEPLOY INDICATION	284N1127 81205	1	35-21-11 P037-00/ /	ALL
K10047		BACR13CG2A RELAY-AFT CARGO COMPARTMENT LTS ENABLE	284N1554 81205	1	33-37-21 E006-00/ /	001-099
K10047		BACR13CG2A RELAY-AFT CARGO COMPARTMENT LTS ENABLE	284N1680 81205	1	33-37-21 E006-00/ /	115-199
K10048		BACR13CG2AB RELAY-FWD CARGO COMPT LTS ENABLE	284N1747 81205	1	33-37-11 P065-00/ /	ALL
K10051		BACR13CF2A RELAY-PTU,ON	284N1318 81205	1	29-22-11 P033-00/ /	ALL
K10057		MS27418-2B RELAY-CARGO FAN,FWD	284N1129 96906	1	21-43-11 P070-00/ /	ALL
K10058		BACR13CF2A RELAY-RAT MANUAL CONTROL	284N1125 81205	1	29-21-31 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10000

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10059		BACR13CF2A RELAY-RAT AUTO CONTROL	284N1318 81205	1	29-21-31 P033-00/ /	ALL
K10060		BACR13CF2A RELAY-PRESS SENSE ANTI-ICE ENG,L	284N1125 81205	1	30-21-11 P036-00/ /	ALL
K10061		BACR13CF2A RELAY-SELECT,ANTI-ICE ENG L	284N1125 81205	1	30-21-11 P036-00/ /	ALL
K10062		BACR13CF2A RELAY-PRESS SENSE ANTI-ICE ENG R	284N1127 81205	1	30-21-11 P037-00/ /	001-099
K10062		BACR13CF2A RELAY-PRESS SENSE ANTI-ICE ENG,R	284N1127 81205	1	30-21-11 P037-00/ /	115-199
K10063		BACR13CF2A RELAY-SELECT,ANTI-ICE ENG R	284N1127 81205	1	30-21-11 P037-00/ /	ALL
K10064		KCA-E-4-F RELAY-SIDEWALL LTS CONTROL,GND	284N1316 81205	1	33-21-31 P034-00/ /	ALL
K10073		KCA-E-4-E RELAY-CEILING LTS CONTROL	284N1316 35344	1	33-21-11 P034-00/ /	ALL
K10075		KCA-E-4-F RELAY-SIDEWALL LTS CONTROL,AIR	284N1316 81205	1	33-21-31 P034-00/ /	ALL
K10079		BACR13CD2 RELAY-POWER XFR	284N1125 81205	1	21-58-11 P036-00/ /	ALL
K10080	1	600-154-3002 RELAY-HORN (T/D-30 SEC)	284N1125 15420	1	21-58-11 P036-00/ /	ALL
K10080	2	TDH-1852-3002 RELAY-HORN (T/D-30 SEC)	284N1125 35344	1	21-58-11 P036-00/ /	ALL
K10083		10-61445-21 RELAY-HEATER,AFT CARGO	284N1129 81205	1	21-44-11 P070-00/ /	ALL
K10084		MS27418-2B RELAY-FAN,AFT CARGO	284N1127 96906	1	21-44-11 P037-00/ /	ALL
K10086		BACR13CD2 RELAY-OEV OPEN INDICATION	284N1320 81205	1	21-58-12 P037-00/ /	ALL
K10093		MS27743-6 RELAY-NLG LT,LEFT	284N1318 96906	1	33-42-11 P033-00/ /	ALL
K10094		BACR13CD2 RELAY-DISAGREEMENT,FUEL CROSSFEED VALVE	284N1318 81205	1	28-22-31 P033-00/ /	001-008, 115-199

EQUIPMENT LIST

D280N032

Section K10000

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10095		BACR13CG2A RELAY-FLAP/SLAT ALT DRIVE ARM	284N1318 81205	1	27-51-21 P033-00/ /	ALL
K10097		10-61445-21 RELAY-EXT,ALT SLAT	284N1318 81205	1	27-81-11 P033-00/ /	ALL
K10098		10-61445-21 RELAY-RET,ALT SLAT	284N1318 81205	1	27-81-11 P033-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10000

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10102		600-486 RELAY-IDLE CONT,R ENG	284N1127 15420	1	76-11-21 P037-00/ /	003-099
K10102	1	TDH-8119-5001 RELAY-IDLE CONT,R ENG	284N1127 35344	1	76-11-21 P037-00/ /	001-002, 115-199
K10102	2	TDH-8116-5001 RELAY-IDLE CONT,R ENG	284N1127 35344	1	76-11-21 P037-00/ /	001-002, 115-199
K10103		600-486 RELAY-IDLE CONT,L ENG	233N1125 15420	1	76-11-21 P036-00/ /	003-099
K10103	1	TDH-8119-5001 RELAY-IDLE CONT,L ENG	233N1125 35344	1	76-11-21 P036-00/ /	001-002, 115-199
K10103	2	TDH-8116-5001 RELAY-IDLE CONT,L ENG	284N1125 35344	1	76-11-21 P036-00/ /	001-002, 115-199
K10104		BACR13CG2A RELAY-DEPRESSURIZATION	284N1318 81205	1	27-51-31 P033-00/ /	ALL
K10107		BACR13CG2A RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K10108		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K10109	1	600-159-1501 RELAY-UTIL/GLY PWR FLT RESET	284N1127 15420	1	24-51-71 P037-00/ /	ALL
K10109	2	TDH-1853-1501 RELAY-UTIL/GLY PWR FLT RESET	284N1127 35344	1	24-51-71 P037-00/ /	ALL
K10110		BACR13CD2 RELAY-DISAGREE ENBL,R SPAR VALVE	284N1318 81205	1	28-22-21 P033-00/ /	ALL
K10111		BACR13CD2 RELAY-DISAGREE ENBL,L SPAR VALVE	284N1318 81205	1	28-22-21 P033-00/ /	ALL
K10124		BACR13CD2 RELAY-CLOSE DISAGREE,L	284N1125 81205	1	76-11-11 P036-00/ /	ALL
K10125		BACR13CD2 RELAY-CLOSE DISAGREE,R	284N1127 81205	1	76-11-12 P037-00/ /	ALL
K10126		BACR13CD2 RELAY-OPEN DISAGREE,L	284N1125 81205	1	76-11-11 P036-00/ /	115-199
K10127		BACR13CD2 RELAY-OPEN DISAGREE,R	284N1127 81205	1	76-11-12 P037-00/ /	115-199

EQUIPMENT LIST

D280N032

Section K10100

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10136		BACR13CG2AB RELAY-GALLEY GND LOAD SHED	284N1314 81205	1	24-51-71 P031-00/ /	001-099
K10136		BACR13CG2AB RELAY-GALLEY GND LOAD SHED	284N1127 81205	1	24-51-71 P037-00/ /	115-199
K10137		BACR13CG2A RELAY-PILOTS LEFT TEST	285N0001 81205	1	33-16-11 P026-00/*/	001-099
K10137	1	BACR13CG2A RELAY-PILOTS LEFT TEST	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10137	2	BACR13CG2AB RELAY-PILOTS LEFT TEST	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10138		BACR13CG2A RELAY-PILOTS RIGHT TEST	285N0001 81205	1	33-16-11 P026-00/*/	001-099
K10138	1	BACR13CG2A RELAY-PILOTS RIGHT TEST	285N0001 81205	1	33-16-11 P026-00/*/	115-199
K10138	2	BACR13CG2AB RELAY-PILOTS RIGHT TEST	285N0001 81205	1	33-16-11 P026-00/*/	115-199
K10139		BACR13CG2A RELAY-PILOTS BATT TEST	285N0001 81205	1	33-16-11 P026-00/*/	001-099
K10139	1	BACR13CG2A RELAY-PILOTS BATT TEST	285N0001 81205	1	33-16-11 P026-00/*/	115-199
K10139	2	BACR13CG2AB RELAY-PILOTS BATT TEST	285N0001 81205	1	33-16-11 P026-00/*/	115-199
K10140		BACR13CF2A RELAY-PILOTS NEUTRAL LEFT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/*/	001-099
K10140	1	BACR13CF2A RELAY-PILOTS NEUTRAL LEFT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/*/	115-199
K10140	2	BACR13CF2AB RELAY-PILOTS NEUTRAL LEFT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/*/	115-199
K10141		BACR13CF2A RELAY-PILOTS LEFT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/*/	001-099
K10141	1	BACR13CF2A RELAY-PILOTS LEFT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/*/	115-199
K10141	2	BACR13CF2AB RELAY-PILOTS LEFT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/*/	115-199

EQUIPMENT LIST

D280N032

Section K10100

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10142		BACR13CF2A RELAY-PILOTS RIGHT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	001-099
K10142	1	BACR13CF2A RELAY-PILOTS RIGHT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10142	2	BACR13CF2AB RELAY-PILOTS RIGHT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10143		BACR13CF2A RELAY-PILOTS BATT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	001-099
K10143	1	BACR13CF2A RELAY-PILOTS BATT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10143	2	BACR13CF2AB RELAY-PILOTS BATT DIM CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10144		J-D9B-013 RELAY-L1 PILOTS DIM	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10145		J-D9B-013 RELAY-L2 PILOTS DIM	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10146		J-D9B-013 RELAY-R1 A PILOTS DIM	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10147		J-D9B-013 RELAY-R1 B PILOTS DIM	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10148		J-D9B-013 RELAY-R2 PILOTS DIM	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10149		J-D9B-013 RELAY-BATT 1 A PILOTS DIM	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10150		J-D9B-013 RELAY-BATT 1 B PILOTS DIM	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10151		J-D9B-013 RELAY-BATT 2 PILOTS DIM	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10152		J-D9B-013 RELAY-AUTOBRIGHT BATT CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10153		BACR13CF2A RELAY-AUTOBRIGHT LEFT/RIGHT CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	001-099
K10153	1	BACR13CF2A RELAY-AUTOBRIGHT LEFT/RIGHT CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	115-199

EQUIPMENT LIST

D280N032

Section K10100

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10153	2	BACR13CF2AB RELAY-AUTOBRIGHT LEFT/RIGHT CONTROL	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10155		10-60450-3 RELAY-DOME LIGHT	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10156		BACR13CG2A RELAY-FLIGHT DECK OVRD	285N0001 81205	1	33-16-11 P026-00/ /	001-099
K10156	1	BACR13CG2A RELAY-FLIGHT DECK OVRD	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10156	2	BACR13CG2AB RELAY-FLIGHT DECK OVRD	285N0001 81205	1	33-16-11 P026-00/ /	115-199
K10157		BACR13CF2A RELAY-REFUELING VALVE,R CTR	284N1318 81205	1	28-21-22 P033-00/ /	ALL
K10159		BACR13CJ2 RELAY-GND SERVICE SENSE	284N1129 81205	1	28-25-11 P070-00/ /	ALL
K10160		BACR13CD2 RELAY-DISAGREE,APU SOV,1	284N1471 81205	1	28-25-21 E006-00/ /	ALL
K10162		BACR13CD2 RELAY-DISAGREE ENABLE,APU SOV	284N1680 81205	1	28-25-21 E006-00/ /	001-099
K10162		BACR13CD2 RELAY-DISAGREE ENABLE,APU SOV	284N1471 81205	1	28-25-21 E006-00/ /	115-199
K10163		BACR13CJ2 RELAY-APU START ENABLE	284N1680 81205	1	49-41-11 E006-00/ /	ALL
K10164		TDH-8127-2002 RELAY-CARGO FAN FAILURE TIME DELAY,AFT	284N1127 35344	1	21-44-11 P037-00/ /	001-099
K10164		M83726-4-118 RELAY-CARGO FAN FAILURE TIME DELAY,AFT	284N1127 35344	1	21-44-11 P037-00/ /	115-199
K10167		BACR13CJ2 RELAY-OEV INHIBIT	286N1125 81205	1	21-25-11 P036-00/ /	ALL
K10187		MS27706-1B RELAY-AFT CARGO LOADER PDU	284N1680 96906	1	25-51-21 E006-00/ /	115-199
K10188		BACR13CF2A RELAY-IGN XFER 1,L ENG	284N1125 81205	1	74-31-11 P036-00/ /	115-199
K10189		BACR13CF2A RELAY-IGN XFER 2,L ENG	284N1125 81205	1	74-31-11 P036-00/ /	115-199

EQUIPMENT LIST

D280N032

Section K10100

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10192		BACR13CF2A RELAY-IGN XFER 1,R ENG	284N1127 81205	1	74-31-21 P037-00/ /	115-199
K10193		BACR13CF2A RELAY-IGN XFER 2,R ENG	284N1127 81205	1	74-31-21 P037-00/ /	115-199
K10197	1	TDH-8119-5001 RELAY-PRSOV/HP6 VALVE OFF,L	284N1125 35344	1	36-11-11 P036-00/ /	ALL
K10197	2	TDH-8116-5001 RELAY-PRSOV/HP6 VALVE OFF,L	284N1125 35344	1	36-11-11 P036-00/ /	ALL
K10198	1	TDH-8119-5001 RELAY-PRSOV/HP6 VALVE AUTO,L	284N1125 35344	1	36-11-11 P036-00/ /	ALL
K10198	2	TDH-8116-5001 RELAY-PRSOV/HP6 VALVE AUTO,L	284N1125 35344	1	36-11-11 P036-00/ /	ALL
K10199		BACR13CF2A RELAY-PRSOV/HP6 VALVE CONTROL,L	284N1125 81205	1	36-11-11 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10100
Page 5 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10201		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10202		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10203		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10204	1	TDH-8119-5001 RELAY-PRSOV/HP6 VALVE OFF,R	284N1127 35344	1	36-11-21 P037-00/ /	ALL
K10204	2	TDH-8116-5001 RELAY-PRSOV/HP6 VALVE OFF,R	284N1127 35344	1	36-11-21 P037-00/ /	ALL
K10205	1	TDH-8119-5001 RELAY-PRSOV/HP6 VALVE AUTO,R	284N1127 35344	1	36-11-21 P037-00/ /	ALL
K10205	2	TDH-8116-5001 RELAY-PRSOV/HP6 VALVE AUTO,R	284N1127 35344	1	36-11-21 P037-00/ /	ALL
K10206		BACR13CF2A RELAY-PRSOV/HP6 VALVE CONT,R	284N1127 81205	1	36-11-21 P037-00/ /	ALL
K10207		BACR13CF2AB RELAY-CARGO FAILURE,AFT	284N1127 81205	1	21-44-11 P037-00/ /	115-199
K10208		BACR13CG2A RELAY-CONTROLS POWER,L ENG	284N1125 81205	1	80-11-11 P036-00/ /	ALL
K10209		BACR13CE2 RELAY-START DISAGREEMENT,L ENG	284N1125 81205	1	80-11-11 P036-00/ /	ALL
K10212		BACR13CG2A RELAY-START TO STOP,L ENG	284N1125 81205	1	80-11-11 P036-00/ /	ALL
K10216		BACR13CF2A RELAY-AFT CARGO RETRACT INTERRUPT	284N1680 81205	1	25-51-21 E006-00/ /	115-199
K10218		BACR13CF2A RELAY-AFT CARGO EXTEND INTERRUPT	284N1680 81205	1	25-51-21 E006-00/ /	115-199
K10219		BACR13CJ1 RELAY-10,000 FT CABIN PRESSURE	284N1316 81205	1	33-24-11 P034-00/ /	115-199
K10220		BACR13CG2A RELAY-CONTROLS POWER,R ENG	284N1127 81205	1	80-11-21 P037-00/ /	ALL
K10221		BACR13CE2 RELAY-START DISAGREEMENT,R ENG	284N1127 81205	1	80-11-21 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10200

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10224		BACR13CG2A RELAY-START TO STOP,R ENG	284N1127 81205	1	80-11-21 P037-00/ /	ALL
K10229		BACR13CD2 RELAY-ANTI-SKID LT,1-5	284N1125 81205	1	32-42-11 P036-00/ /	ALL
K10230		BACR13CD2 RELAY-ANTI-SKID LT,4-8	284N1125 81205	1	32-42-11 P036-00/ /	ALL
K10231		BACR13CD2 RELAY-ANTI-SKID LT,2-6	284N1125 81205	1	32-42-11 P036-00/ /	ALL
K10232		BACR13CD2 RELAY-ANTI-SKID LT,3-7	284N1125 81205	1	32-42-11 P036-00/ /	ALL
K10233		BACR13CD2 RELAY-ANTI-SKID LT,ALT	284N1125 81205	1	32-42-11 P036-00/ /	ALL
K10238		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K10239		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10240		BACR13CG2A RELAY-GEAR LEVER DOWN	284N1125 81205	1	32-61-11 P036-00/ /	ALL
K10244		BACR13CE2 RELAY-LE/TE TRANSFER	284N1125 81205	1	27-58-11 P036-00/ /	ALL
K10245		BACR13CG2A RELAY-FLAP LOAD RELIEF	284N1125 81205	1	27-51-51 P036-00/ /	ALL
K10246		BACR13CF2A RELAY-START,L ENG 1	284N1125 81205	1	80-11-11 P036-00/ /	115-199
K10247		BACR13CG2A RELAY-START,L ENG 2	284N1125 81205	1	80-11-11 P036-00/ /	ALL
K10248		BACR13CE2 RELAY-START,L ENG 3	284N1125 81205	1	80-11-11 P036-00/ /	ALL
K10249		BACR13CF2A RELAY-START,R ENG 1	284N1127 81205	1	80-11-21 P037-00/ /	115-199
K10250		BACR13CG2A RELAY-START,R ENG 2	284N1127 81205	1	80-11-21 P037-00/ /	ALL
K10251		BACR13CE2 RELAY-START,R ENG 3	284N1127 81205	1	80-11-21 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10200

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10253		BACR13CF2A RELAY-CONT L EMP	284N1318 81205	1	29-11-12 P033-00/ /	ALL
K10255		BACR13CF2A RELAY-CONT R EMP	284N1125 81205	1	29-11-22 P036-00/ /	ALL
K10256		KA-X9E-004 RELAY-FLT DECK DOOR OPEN/CLOSE	284N1316 81205	1	33-22-11 P034-00/ /	ALL
K10257		KA-X9E-004 RELAY-NO 1 PASS DR L OPEN/CLOSE LOGIC	284N1316 35344	1	33-22-11 P034-00/ /	ALL
K10258		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10264		BACR13CG2A RELAY-R PROBE TEST	284N1127 81205	1	30-32-11 P037-00/ /	ALL
K10265		BACR13CG2A RELAY-L PROBE TEST	284N1318 81205	1	30-32-11 P033-00/ /	ALL
K10266		BACR13CD2 RELAY-GEAR DISAGREE	284N1127 81205	1	32-61-11 P037-00/ /	ALL
K10267		BACR13CD2 RELAY-GEAR DOORS OPEN	284N1127 81205	1	32-61-11 P037-00/ /	ALL
K10270		BACR13CD2 RELAY-MUTING	417N3100 81205	1	23-31-42 MULTI/ /	115-199
K10271		BACR13CJ2 RELAY-CAPT STANDBY	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10272		BACR13CF2A RELAY-CAPT OVERRIDE	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10273		BACR13CJ2 RELAY-F/O STANDBY	233N2400 81205	1	33-11-11 0200/220/R015	ALL
K10274		BACR13CF2A RELAY-F/O OVERRIDE	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10277		BACR13CF2A RELAY-GND HDLG PWR TRANSFER	284N1127 81205	1	35-11-13 P037-00/ /	115-199
K10280		BACR13CD2 RELAY-AIR SUPPLY OVERRIDE,APU	284N1320 81205	1	36-11-41 P037-00/ /	ALL
K10281		BACR13CD2 RELAY-AIR SUPPLY ENG START,RIGHT	284N1320 81205	1	36-11-21 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10200

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10282		BACR13CD2 RELAY-AIR SUPPLY ENG START,LEFT	284N1125 81205	1	36-11-11 P036-00/ /	ALL
K10283		BACR13CJ2 RELAY-FLUORESCENT LIGHT CONT	417N5113 81205	2	33-22-11 MULTI/ /	001-099
K10283		BACR13CJ2 RELAY-FLUORESCENT LIGHT CONT	417N5113 81205	1	33-22-11 355/288/L014	115-199
K10289		BACR13CJ2 RELAY-FWD GALLEY LT CONT	417N5111 81205	1	33-27-11 0347/289/R019	ALL
K10290		BACR13CJ2 RELAY-FWD GALLEY LT DIM	417N5111 81205	1	33-27-11 0347/289/R019	ALL
K10291		BACR13CJ2-PROVISIONS- RELAY-MID FWD GALLEY LT CONTROL,RIGHT	417N5114 81205	1	33-27-21 710/289/R025	ALL
K10292		BACR13CJ2 RELAY-AFT GALLEY LT CONT	417N5112 81205	1	33-27-31 1668/294/R005	ALL
K10293		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10294		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10297		10-61445-21 RELAY-UTIL BUS L,GALLEYS	284N1129 81205	1	24-51-14 P070-00/ /	115-199
K10298		10-61445-21 RELAY-UTIL BUS R,GALLEYS	284N1127 81205	1	24-51-24 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10200
Page 4 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10305		BACR13CF2A RELAY-LTS ENABLE,NO.3 CARGO DR	284N1680 81205	1	33-37-21 E006-00/ /	115-199
K10306		BACR13CG2A RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K10307		BACR13CG2A RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K10308		BACR13CG2A RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10309		BACR13CG2A RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10310		BACR13CJ2-PROVISIONS- RELAY-MID FWD GALLEY LT CONTROL,LEFT	417N5114 81205	1	33-27-22 717/289/L032	115-199
K10311		BACR13CD2 RELAY-AUTO/OFF,FLT DK	284N1320 81205	1	21-61-11 P037-00/ /	ALL
K10312		BACR13CD2 RELAY-AUTO/OFF,FWD ZONE	284N1127 81205	1	21-61-21 P037-00/ /	ALL
K10313		BACR13CD2 RELAY-AUTO/OFF,AFT ZONE	284N1320 81205	1	21-61-31 P037-00/ /	ALL
K10315		BACR13CE2 RELAY-PACK AUTO/MAN 3,L	284N1125 81205	1	21-51-12 P036-00/ /	001-099
K10315		BACR13CE2 RELAY-PACK AUTO/MAN 3,L	284N1680 81205	1	21-51-12 E006-00/ /	115-199
K10316		BACR13CE2 RELAY-PACK AUTO/MAN,3,R	284N1127 81205	1	21-51-22 P037-00/ /	001-099
K10316		BACR13CE2 RELAY-PACK AUTO/MAN,3,R	284N1680 81205	1	21-51-22 E006-00/ /	115-199
K10317		BACR13CD2 RELAY-PACK LOW LIMIT VLV,L	284N1125 81205	1	21-51-14 P036-00/ /	001-099
K10317		BACR13CD2 RELAY-PACK LOW LIMIT VLV,L	284N1680 81205	1	21-51-14 E006-00/ /	115-199
K10318		BACR13CD2 RELAY-PACK LOW LIMIT VLV,R	284N1127 81205	1	21-51-24 P037-00/ /	001-099
K10318		BACR13CD2 RELAY-PACK LOW LIMIT VLV,R	284N1680 81205	1	21-51-24 E006-00/ /	115-199

EQUIPMENT LIST

D280N032

Section K10300

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10322		BACR13CD2 RELAY-AFT EQUIP EXH FAN 1 FAIL	284N1127 81205	1	21-58-21 P037-00/ /	ALL
K10323		KDA-E4F RELAY-SUPPLY FAN 1,EQUIP COOLING,AFT	284N1125 35344	1	21-58-24 P036-00/ /	115-199
K10324		KDA-E4F RELAY-SUPPLY FAN 2,EQUIP COOLING,AFT	284N1127 35344	1	21-58-24 P037-00/ /	115-199
K10329		BACR13CJ2 RELAY-BUS POWER SENSE,L	284N1125 81205	1	74-31-11 P036-00/ /	ALL
K10331		BACR13CJ2 RELAY-BUS SENSE,R	284N1127 81205	1	74-31-21 P037-00/ /	ALL
K10334		TDH-8119-1001 RELAY-APU FIRE	284N1125 35344	1	26-15-11 P036-00/ /	ALL
K10335		BACR13CD2 RELAY-TEST	284N1125 81205	1	26-15-11 P036-00/ /	ALL
K10336		TDH-8119-1002 RELAY-APU BOTTLE DISCH	284N1125 35344	1	26-22-21 P036-00/ /	ALL
K10337		BACR13CG2A RELAY-L ENG OUT 1	284N1125 81205	1	77-12-41 P036-00/ /	ALL
K10338		BACR13CG2A RELAY-L ENG OUT 2	284N1127 81205	1	77-12-41 P037-00/ /	ALL
K10339		BACR13CD2 RELAY-L ENG OUT 3	284N1127 81205	1	77-12-41 P037-00/ /	ALL
K10340		BACR13CF2A RELAY-R ENG OUT 1	284N1125 81205	1	77-12-42 P036-00/ /	ALL
K10341		BACR13CG2A RELAY-R ENG OUT 2	284N1127 81205	1	77-12-41 P037-00/ /	ALL
K10342		BACR13CD2 RELAY-R ENG OUT 3	284N1127 81205	1	77-12-42 P037-00/ /	ALL
K10343		X-D4N RELAY-PSU A FAULT	285N0005 35344	1	31-51-11 P051-00/ /	ALL
K10344		X-D4N RELAY-PSU B FAULT	285N0005 35344	1	31-51-12 P051-00/ /	ALL
K10348		BACR13CD2 RELAY-FLAP SIGNAL,R	284N1125 81205	1	76-11-21 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10300

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10349		BACR13CD2 RELAY-FLAP SIGNAL,L	284N1125 81205	1	76-11-21 P036-00/ /	ALL
K10360		BACR13CG2AB RELAY-SUPPLY SMOKE SHUTDOWN	284N1125 81205	1	21-58-12 P036-00/ /	ALL
K10362		BACR13CD2 RELAY-FLT DK ZONE INOP	284N1320 81205	1	21-61-11 P037-00/ /	ALL
K10363		BACR13CD2 RELAY-FWD ZONE INOP	284N1320 81205	1	21-61-21 P037-00/ /	ALL
K10364		BACR13CD2 RELAY-AFT ZONE INOP	284N1127 81205	1	21-61-31 P037-00/ /	ALL
K10369		D-7AC RELAY-CONTROL ALTERNATE EXTENSION	284N1125 74063	1	32-35-11 P036-00/ /	ALL
K10370		BACR13CE2 RELAY-LATCH,ALTN EXT CONT	284N1125 81205	1	32-35-11 P036-00/ /	ALL
K10373		BACR13CD2 RELAY-APU GND	284N1125 81205	1	26-15-11 P036-00/ /	ALL
K10374		BACR13CF2A RELAY-APU REMOTE WARN	284N1125 81205	1	26-15-11 P036-00/ /	ALL
K10378		TDH-8116-6002 RELAY-DELAY,BLOWER 1	284N1125 35344	1	26-16-21 P036-00/ /	ALL
K10379		TDH-8116-6002 RELAY-DELAY,BLOWER 3	284N1125 35344	1	26-16-21 P036-00/ /	ALL
K10384		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K10385		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K10386		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10387		BACR13CE2 RELAY-AIR/GND,SYS 2	284N1127 81205	1	32-09-12 P037-00/ /	ALL
K10388		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	ALL
K10391	1	600-154-3001 RELAY-GALLEY GND LOAD SHED CONT	286N1127 15420	1	24-51-71 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10300

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10391	2	TDH-1852-3001 RELAY-GALLEY GND LOAD SHED CONT	286N1127 35344	1	24-51-71 P037-00/ /	ALL
K10398		BACR13CG2A RELAY-L ENG OUT,4	284N1125 81205	1	77-12-41 P036-00/ /	ALL
K10399		BACR13CG2A RELAY-R ENG OUT,4	284N1127 81205	1	77-12-42 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10300
Page 4 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10401		BACR13CG2A RELAY-CONT,AUTO IGN,L ENG	284N1125 81205	1	74-31-11 P036-00/ /	ALL
K10402		BACR13CG2A RELAY-CONT,AUTO IGN,R ENG	284N1127 81205	1	74-31-21 P037-00/ /	ALL
K10403		BACR13CF2A RELAY-TEST SAFETY	284N1127 81205	1	30-11-11 P037-00/ /	ALL
K10404		BACR13CF2A RELAY-EMP CONTROL,C1	284N1125 81205	1	29-11-31 P036-00/ /	ALL
K10405		KA-D9F-005 RELAY-LOGO LTS CONT	284N1129 35344	1	33-45-11 P070-00/ /	ALL
K10411		MS27743-6 RELAY-HINGE PDU RAISE,NO 1 CARGO DR	284N1747 96906	1	52-34-11 P065-00/ /	001-099
K10412		MS27743-6 RELAY-HINGE PDU LOWER,NO 1 CARGO DR	284N1747 96906	1	52-34-11 P065-00/ /	001-099
K10413	1	KC-D4A-300L RELAY-HINGE PDU RAISE,NO 2 CARGO DR	284N1554 96906	1	52-35-11 E006-00/ /	001-099
K10413	2	MS27743-6 RELAY-HINGE PDU RAISE,NO 2 CARGO DR	284N1554 96906	1	52-35-11 E006-00/ /	001-099
K10414	1	KC-D4A-300L RELAY-HINGE PDU LOWER,NO 2 CARGO DR	284N1554 96906	1	52-35-11 E006-00/ /	001-099
K10414	2	MS27743-6 RELAY-HINGE PDU LOWER,NO 2 CARGO DR	284N1554 96906	1	52-35-11 E006-00/ /	001-099
K10416		BACR13CD2 RELAY-EXTENDED STBY PWR IND	287N4102 81205	1	24-33-12 P006-00/ /	ALL
K10418		TD-1862-7500 RELAY-APU BAT CHGR DET	284N1471 35344	1	24-33-12 E006-00/ /	ALL
K10419		10-60450-2 RELAY-LTG,STBY INSTR	233N2400 81205	1	33-13-31 P012-00/ /	ALL
K10420		BACR13CD2 RELAY-PACK ON APU COMMAND	284N1125 81205	1	21-51-11 P036-00/ /	001-099
K10420		BACR13CD2 RELAY-PACK ON APU COMMAND	284N1680 81205	1	21-51-11 E006-00/ /	115-199
K10421		BACR13CJ2 RELAY-ENTRY & GALLEY LTS	284N1316 81205	1	33-22-11 P034-00/ /	115-199

EQUIPMENT LIST

D280N032

Section K10400

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10422		BACR13CF2A RELAY-BAT DISCH IND INHIBIT	284N1471 81205	1	24-33-12 E006-00/ /	ALL
K10423		BACR13CJ2 RELAY-STBY LTG, GLARESHIELD	233N2400 81205	1	33-13-41 P003-01/ /	ALL
K10424		BACR13CD2 RELAY-MN/APU BAT CHGR DET ENABLE	287N4102 81205	1	24-34-11 P006-00/ /	ALL
K10425		TD-1862-7500 RELAY-MN BAT CHGR DET	287N4102 35344	1	24-31-11 P006-00/ /	ALL
K10426		BACR13CG2A RELAY-RESERVE BRAKE CONTROL	284N1127 81205	1	29-21-32 P037-00/ /	ALL
K10432		BACR13CD2 RELAY-FWD CARGO FIRE	284N1127 81205	1	21-25-11 P037-00/ /	ALL
K10435		BACR13CG2A RELAY-L PRSOV/HP6 OVRD	284N1125 81205	1	36-11-11 P036-00/ /	ALL
K10436		BACR13CG2A RELAY-R PRSOV/HP6 OVRD	284N1127 81205	1	36-11-21 P037-00/ /	ALL
K10437		BACR13CG2A RELAY-PASS SIGN/CEILING LT DEPRESS CONT	284N1316 81205	1	33-24-11 P034-00/ /	001-099
K10437		BACR13CD2 RELAY-PASS SIGN CONT	284N1316 81205	1	33-24-11 P034-00/ /	115-199
K10442		BACR13CF2AB RELAY-OEV COMMAND	284N1125 81205	1	21-58-12 P036-00/ /	ALL
K10443		BACR13CD2 RELAY-AFT CARGO FIRE	284N1125 81205	1	21-25-11 P036-00/ /	ALL
K10444		BACR13CE2 RELAY-R ENG OUT,5	284N1127 81205	1	77-12-42 P037-00/ /	ALL
K10446		BACR13CE2 RELAY-L ENG OUT,5	284N1125 81205	1	77-12-41 P036-00/ /	ALL
K10448		BACR13CE2 RELAY-R ENG OUT,6	284N1127 81205	1	77-12-42 P037-00/ /	ALL
K10449		BACR13CJ2 RELAY-STBY CONTROL SWITCHING	233N2400 81205	1	33-13-11 / /	115-199
K10451		BACR13CF2A RELAY-AUTOBRIGHT CONTROL CH 1	285N0001 81205	1	33-16-11 P026-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10400

Page 2

Oct 09/2008

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10452		BACR13CF2A RELAY-AUTOBRIGHT CONTROL CH 2	285N0001 81205	1	33-16-11 P026-00/ /	ALL
K10453	1	TDH-8119-5001 RELAY-L PRSOV CLOSED	284N1125 35344	1	36-11-11 P036-00/ /	ALL
K10453	2	TDH-8116-5001 RELAY-L PRSOV CLOSED	284N1125 35344	1	36-11-11 P036-00/ /	ALL
K10454	1	TDH-8119-5001 RELAY-R PRSOV CLOSED	284N1127 35344	1	36-11-21 P037-00/ /	ALL
K10454	2	TDH-8116-5001 RELAY-R PRSOV CLOSED	284N1127 35344	1	36-11-21 P037-00/ /	ALL
K10478	9	770-540-1 RELAY-CURRENT SENSING,L ENG PROBE	284N1319 F0553	1	30-34-21 P036-00/ /	115-199
K10478		770-540-1 RELAY-CURRENT SENSING,L ENG PROBE	284N1319 F0553	1	30-34-21 P036-00/ /	001-099
K10479	9	770-540-1 RELAY-CURRENT SENSING,R ENG PROBE	284N1320 F0553	1	30-34-22 P037-00/ /	115-199
K10479		770-540-1 RELAY-CURRENT SENSING,R ENG PROBE	284N1320 F0553	1	30-34-22 P037-00/ /	001-099
K10494		BACR13CF2A RELAY-ALT LEADING EDGE FAIL	284N1318 81205	1	27-51-21 P033-00/ /	ALL
K10497		BACR13CD2 RELAY-L RECIRC OVERRIDE	284N1125 81205	1	21-25-11 P036-00/ /	ALL
K10498		BACR13CD2 RELAY-MUTING PA SYS	411N3210 81205	1	23-31-22 1650/289/L008	ALL
K10499		BACR13CD2 RELAY-MUTING PA SYS	411N3210 81205	1	23-31-21 0377/288/	115-199

EQUIPMENT LIST

D280N032

Section K10400

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10500		BACR13CD2 RELAY-MUTING PA SYS	411N3210 81205	1	23-31-21 0377/288/L008	ALL
K10502		BACR13CD2 RELAY-MUTING PA SYS	411N3210 81205	1	23-31-16 0377/288/	115-199
K10503		BACR13CD2 RELAY-MUTING PA SYS	411N3210 81205	1	23-31-16 0700/288/L010	001-099
K10503		BACR13CD2 RELAY-MUTING PA SYS	411N3210 81205	1	23-31-16 0700/ /	115-199
K10504		BACR13CD2 RELAY-NOSE GEAR SIGNAL,R	284N1127 81205	1	76-11-21 P037-00/ /	ALL
K10505		BACR13CD2 RELAY-NOSE GEAR SIGNAL,L	284N1125 81205	1	76-11-21 P036-00/ /	ALL
K10506		BACR13CG2AB RELAY-ALT MODE	284N1125 81205	1	21-58-12 P036-00/ /	ALL
K10507		TDH-1853-3003 RELAY-OVHT LIGHT INHIBIT	284N1125 35344	1	21-58-12 P036-00/ /	ALL
K10509		BACR13CD2 RELAY-EXHAUST SMOKE SENSING	284N1125 81205	1	21-58-12 P036-00/ /	ALL
K10511		TDH-7101-2002 RELAY-AUTO TEST	284N1125 35344	1	21-58-12 P036-00/ /	ALL
K10517		BACR13CD2 RELAY-AFT CARGO EXTEND ENABLE	284N1482 81205	1	25-51-21 E006-00/ /	115-199
K10525		BACR13CJ2 RELAY-HYD EMP ENABLE R	284N1125 81205	1	29-11-22 P036-00/ /	ALL
K10526		BACR13CJ2 RELAY-C1 HYD EMP ENABLE	284N1125 81205	1	29-11-31 P036-00/ /	ALL
K10527		BACR13CJ2 RELAY-HYD EMP ENABLE C2	284N1125 81205	1	29-11-31 P036-00/ /	ALL
K10541		BACR13CF2A RELAY-EEC RESET 1 L	284N1125 81205	1	73-21-12 P036-00/ /	ALL
K10542		TDH-8120-1001 RELAY-EEC RESET 2 L	284N1125 81205	1	73-21-12 P036-00/ /	ALL
K10543		BACR13CF2A RELAY-EEC RESET 1 R	284N1127 81205	1	73-21-22 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10500

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10544		TDH-8120-1001 RELAY-EEC RESET 2 R	284N1127 81205	1	73-21-22 P037-00/ /	ALL
K10546		KA-D9F-005 RELAY-AISLE STAND STANDBY LIGHTING	233N2400 35344	1	33-13-52 P008-00/ /	ALL
K10549		BACR13CF2AB RELAY-TPU OVERRIDE,R	284N1320 81205	1	74-31-21 P037-00/ /	ALL
K10550		BACR13CF2AB RELAY-TPU OVERRIDE,L	284N1125 81205	1	74-31-11 P036-00/ /	ALL
K10554		TDH8120-1002 RELAY-L ENG START/PRSOV OVERRIDE	284N1125 81205	1	36-11-11 P036-00/ /	001-099
K10554	1	TDH8120-1002 RELAY-L ENG START/PRSOV OVERRIDE	284N1125 81205	1	36-11-11 P036-00/ /	115-199
K10554	2	285N0126-11 RELAY-L ENG START/PRSOV OVERRIDE	284N1125 81205	1	36-11-11 P036-00/ /	115-199
K10555		TDH8120-1002 RELAY-R ENG START/PRSOV OVERRIDE	284N1270 81205	1	36-11-21 P037-00/ /	001-099
K10555	1	TDH8120-1002 RELAY-R ENG START/PRSOV OVERRIDE	284N1270 81205	1	36-11-21 P037-00/ /	115-199
K10555	2	285N0126-11 RELAY-R ENG START/PRSOV OVERRIDE	284N1270 81205	1	36-11-21 P037-00/ /	115-199
K10556		BACR13CE2 RELAY-L ENG OUT NO.6	286N1260 81205	1	77-12-41 P036-00/ /	ALL
K10561		BACR13CJ2 RELAY-LEFT AC BUS OFF	284N1790 81205	1	24-25-11 P071-00/ /	001-002, 115-199
K10562		BACR13CJ2 RELAY-RIGHT AC BUS OFF	284N1790 81205	1	24-25-11 P071-00/ /	001-002, 115-199
K10563		XL-D4N-009 RELAY-HYDRAULIC GENERATOR CONTROL	284N1790 35344	1	24-25-11 P071-00/ /	001-002, 115-199
K10564		A-1077DD RELAY-28V DC POWER	284N1790 74063	1	24-25-11 P071-00/ /	001-002, 115-199
K10565		HT-C7N-060 RELAY-CAPT 115V AC FLT INSTR TRANSFER	284N1790 35344	1	24-25-11 P071-00/ /	ALL
K10566		HT-C7N-060 RELAY-115V AC L TRANSFER	284N1790 35344	1	24-25-11 P071-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10500

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10567		HT-C7N-060 RELAY-115V AC R TRANSFER	284N1790 35344	1	24-25-11 P071-00/ /	ALL
K10568		TDH-1853-1501 RELAY-GEN RESET	284N1790 58657	1	24-25-11 P071-00/ /	001-002, 115-199
K10569		BACR13CG2AB RELAY-EQUIP COOLING AUX FAN	284N1125 81205	1	21-58-15 P036-00/ /	ALL
K10570		KA-X9E-004 RELAY-EMER LT ALT XFR	284N1127 35344	1	33-51-11 P037-00/ /	ALL
K10574		KA-X9E-004 RELAY-EMER ATTEND WORK LT ALT XFR	284N1316 35344	1	33-22-11 P034-00/ /	ALL
K10597		BACR13CJ2 RELAY-FWD CARGO FAN SENSE	284N1129 81205	1	21-43-11 P070-00/ /	001-099
K10598		BACR13CJ2 RELAY-AFT CARGO FAN SENSE	284N1320 81205	1	21-44-11 P037-00/ /	001-099
K10599		BACR13CF2AB RELAY-PWR,MULTIPLEXER	284N1307 81205	1	23-34-15 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10500
Page 3 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10600		BACR13CF2AB RELAY-TAPE REP PWR	284N1307 81205	1	23-34-15 P036-00/ /	115-199
K10601		BACR13CD2 RELAY-DISAGREE,ANTI-ICE ENG L	284N1125 81205	1	30-21-11 P036-00/ /	ALL
K10602		BACR13CD2 RELAY-DISAGREE,ANTI-ICE ENG R	284N1127 81205	1	30-21-11 P037-00/ /	ALL
K10637		BACR13CE2 RELAY-ANN CONT	411N3210 81205	1	23-31-18 P036-00/288/	001-099
K10639	9	BACR13CG2AB RELAY-CTR SYM GEN NAV SRCE (SB 34-0427)	284N1125 81205	1	34-22-38 P036-00/ /	001
K10639	9	BACR13CG2AB RELAY-CTR SYM GEN NAV SRCE (SB 34-0414)	284N1125 81205	1	34-22-38 P036-00/ /	115-199
K10642		BACR13CG2AB RELAY-BUS SWITCHING	284N1307 81205	1	23-32-02 P037-00/ /	ALL
K10677		BACR13CD2 RELAY-FLT REC FMC INTERCEPT POINT SWITCH	284N1127 81205	1	31-31-42 P037-00/ /	001-099
K10688	9	BACR13CG2AB RELAY-EFIS/EICAS ATT COMP (SB 34-0200)	284N1127 81205	1	34-25-12 P037-00/ /	002
K10690		BACR13CF2AB RELAY-HYDR GEN 28V DC SENSOR	284N1790 81205	1	24-25-11 P071-00/ /	003-099
K10691	9	BACR13CE2 RELAY-AIR/GND,SYS 1	MR69018 81205	1	32-09-11 P036-00/ /	115-199
K10691		BACR13CE2 RELAY-AIR/GND,SYS 1	284N1125 81205	1	32-09-11 P036-00/ /	001-099
K10698		TDH-8116-5001 RELAY-BOOST PUMP READY	284N1790 81205	1	24-25-11 P071-00/ /	003-099

EQUIPMENT LIST

D280N032

Section K10600

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10704	9	BACR13CF2AB RELAY-LTG TRANSFER	MR69018 81205	1	33-13-32 P012-00/ /	115-199
K10704		BACR13CF2AB RELAY-LTG TRANSFER	233N2400 81205	1	33-13-32 P012-00/ /	001-099
K10706		BACR13CF2A RELAY-APU BATTERY,FAA CONFIG	284N1554 81205	1	24-33-12 E006-00/ /	002-099
K10712	9	600-154-3002 RELAY-30 SEC AFTER STOW COMMAND-LEFT	SB780032 81205	1	78-36-11 P036-00/ /	001-002, 115-199
K10712	1	TDH-1852-3002 RELAY-30 SEC AFTER STOW COMMAND-LEFT	284N1125 81205	1	78-36-11 P036-00/ /	004-099
K10712	2	600-154-3002 RELAY-30 SEC AFTER STOW COMMAND-LEFT	284N1125 81205	1	78-36-11 P036-00/ /	004-099
K10713	9	600-154-3002 RELAY-30 SEC AFTER STOW COMMAND-RIGHT	SB780032 81205	1	78-36-21 P037-00/ /	001-002, 115-199
K10713	1	THD-1852-3002 RELAY-30 SEC AFTER STOW COMMAND-RIGHT	284N1127 81205	1	78-36-21 P037-00/ /	003-099
K10713	2	600-154-3002 RELAY-30 SEC AFTER STOW COMMAND-RIGHT	284N1127 81205	1	78-36-21 P037-00/ /	003-099
K10714		BACR13CE2 RELAY-AFT FUEL CROSSFEED DISAGREE	284N1318 81205	1	28-22-31 P033-00/ /	009-099
K10715		BACR13CE2 RELAY-FWD FUEL CROSSFEED DISAGREE	284N1318 81205	1	28-22-32 P033-00/ /	009-099
K10718	9	BACR13CF2A RELAY-ETOPS BATTERY BUS TRANSFER	SB780032 81205	1	32-61-11 P037-00/ /	001-002, 115-199
K10718		BACR13CF2A RELAY-ETOPS BATTERY BUS TRANSFER	284N1127 81205	1	32-61-11 P037-00/ /	003-099
K10723	9	BACR13CF2A RELAY-SYNC LOCK PWR SENSOR R ENG T/R	SB780032 81205	1	78-34-61 P037-00/ /	001-002, 115-199
K10723		BACR13CF2A RELAY-SYNC LOCK PWR SENSOR R ENG T/R	284N1125 81205	1	78-34-61 P037-00/ /	003-099
K10724	9	BACR13CF2A RELAY-HIGH VOLTAGE PWR SENSOR-R ENG T/R	SB780032 81205	1	78-34-21 P037-00/ /	001-002, 115-199
K10724		BACR13CF2A RELAY-HIGH VOLTAGE PWR SENSOR-R ENG T/R	284N1125 81205	1	78-34-21 P037-00/ /	003-099

EQUIPMENT LIST

D280N032

Section K10700

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10725	9	BACR13CF2A RELAY-SYNC LOCK L	SB780032 81205	1	78-34-51 P036-00/ /	001-002, 115-199
K10725		BACR13CF2A RELAY-SYNC LOCK L	284N1127 81205	1	78-34-51 P036-00/ /	003-099
K10726	9	BACR13CF2A RELAY-SYNC LOCK R	SB780032 81205	1	78-34-61 P037-00/ /	001-002, 115-199
K10726		BACR13CF2A RELAY-SYNC LOCK R	284N1125 81205	1	78-34-61 P037-00/ /	003-099
K10783	9	BACR13CE2 RELAY-TERR WXR (SB 34-0200)	284N1746 81205	1	34-46-14 P065-00/ /	002
K10785	9	BACR13CE2 RELAY-TERR WXR (SB 34-0200)	284N1746 81205	1	34-46-14 P065-00/ /	002
K10790	9	BACR13CG2AB RELAY-R EFIS CP DATA (SB 34-0200)	284N1747 81205	1	34-22-28 P065-00/ /	002
K10799	9	KA-D9F-005 POSITION LIGHT CONTROL RELAY (PLATE 'B')	SB330039 35344	1	33-43-11 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10700

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10802	9	128941-001 RLY - L AIR DATA SOURCE SEL (SB 34A0222)	284N1269 81840	1	34-12-61 E002-04/ /	ALL
K10803	9	128941-001 RLY - R AIR DATA SOURCE SEL (SB 34A0222)	284N1269 81840	1	34-12-62 E002-04/ /	ALL
K10813	9	BACR13CD2 RELAY-FLT REC EFIS I/P SWITCHING	284N1127 81205	1	31-31-41 P037-00/ /	010-099
K10845	9	BACR13CG2A RELAY-GEAR TILT-RIGHT GEAR (SB 27A0130)	284N1203 81205	1	27-62-11 P037-00/ /	ALL
K10847	9	BACR13CG2A RELAY-AIR/GND,SYS 2 (SB 27A0130)	284N1203 81205	1	32-09-12 P037-00/ /	ALL
K10870	9	BACR13CJ2 RLY-R CTR OVRD AUTO S/O ENBL (SB28A0081)	284N1127 81205	1	28-22-11 P037-00/ /	ALL
K10871	9	TDH-8116-1502 RLY TD-R CTR OVRD AUTO S/O (SB 28A0081)	284N1127 58657	1	28-22-11 P037-00/ /	ALL
K10872	9	TDH-8116-1502 RLY TD-L CTR OVRD AUTO S/O (SB 28A0081)	284N1318 58657	1	28-22-11 P033-00/ /	ALL
K10873	9	BACR13CJ2 RLY-L CTR OVRD AUTO S/O ENBL (SB28A0081)	284N1318 81205	1	28-22-11 P033-00/ /	ALL
K10874	9	MS27418-2A RLY-OVRD BST PMP,SEC CONT,R (SB 28A0105)	012N0038 96906	1	28-22-11 P037-00/ /	ALL
K10875	9	MS27418-2A RLY-OVRD BST PMP,SEC CONT,L (SB 28A0105)	012N0038 96906	1	28-22-11 P033-00/ /	ALL

EQUIPMENT LIST

D280N032

Section K10800
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00004		13-32480-5 LT-AC CONNECTED	284N1412 87034	1	24-41-12 P030-00/ /	ALL
L00004 T		MS25231-1873 LAMP	284N1412 87034	1	24-41-12 P030-00/ /	ALL
L00005		13-32480-17 LT-PWR NOT IN USE	284N1412 87034	1	24-41-12 P030-00/ /	ALL
L00005 T		MS25231-1873 LAMP	284N1412 87034	1	24-41-12 P030-00/ /	ALL
L00007		33-32683 LT-HOT BUS WARN,TIE BUS,L	284N1314 87034	1	24-21-51 P031-00/ /	001-099
L00007		33-32683-6P1 LT-HOT BUS WARN,TIE BUS,L	284N1314 29207	1	24-21-51 P031-00/ /	115-199
L00008		33-32683 LT-HOT BUS WARN,TIE BUS,R	284N1315 87034	1	24-21-51 P032-00/ /	001-099
L00008		33-32683-6P1 LT-HOT BUS WARN,TIE BUS,R	284N1315 29207	1	24-21-51 P032-00/ /	115-199
L00009		33-32683 LT-HOT BUS WARN,TIE BUS,EXT	284N1316 87034	1	24-21-51 P034-00/ /	001-099
L00009		33-32683-6P1 LT-HOT BUS WARN,TIE BUS,EXT	284N1316 29207	1	24-21-51 P034-00/ /	115-199
L00010		33-32683 LT-HOT BUS WARN	284N1316 87034	1	24-21-41 P034-00/ /	001-099
L00010		33-32683-6P1 LT-HOT BUS WARN	284N1316 29207	1	24-21-41 P034-00/ /	115-199
L00011		33-32683 LT-HOT BUS WARN,GEN L	284N1314 87034	1	24-21-11 P031-00/ /	001-099
L00011		33-32683-6P1 LT-HOT BUS WARN,GEN L	284N1314 29207	1	24-21-11 P031-00/ /	115-199
L00012		33-32683 LT-HOT BUS WARN,115 VAC L	284N1314 87034	1	24-21-11 P031-00/ /	001-099
L00012		33-32683-6P1 LT-HOT BUS WARN,115 VAC L	284N1314 29207	1	24-21-11 P031-00/ /	115-199
L00013		33-32683 LT-HOT BUS WARN,115 VAC R	284N1315 87034	1	24-21-21 P032-00/ /	001-099

EQUIPMENT LIST

D280N032

Section L00000

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00013		33-32683-6P1 LT-HOT BUS WARN,115 VAC R	284N1315 29207	1	24-21-21 P032-00/ /	115-199
L00014		33-32683 LT-HOT BUS WARN,GEN R	284N1315 87034	1	24-21-21 P032-00/ /	001-099
L00014		33-32683-6P1 LT-HOT BUS WARN,GEN R	284N1315 29207	1	24-21-21 P032-00/ /	115-199
L00015		33-32683 LT-HOT BUS WARN,EXT PWR	284N1316 87034	1	24-41-11 P034-00/ /	001-099
L00015		33-32683-6P1 LT-HOT BUS WARN,EXT PWR	284N1316 29207	1	24-41-11 P034-00/ /	115-199
L00016		S283T013-19 LT ASSY-POSITION,LEFT WING REAR	284N1112 81205	1	33-43-11 WBL 740/ /L	ALL
L00016 T		1978X LAMP-	284N1112 08805	1	33-43-11 845/742/L	ALL
L00017		S283T013-5 LT ASSY-POSITION,LEFT WING FWD	284N1112 81205	1	33-43-11 WBL 740/ /L	ALL
L00017 T		1978X LAMP-	284N1112 08805	1	33-43-11 830/745/L	ALL
L00018		S283T013-6 LT ASSY-POSITION,RIGHT WING FWD	284N1112 81205	1	33-43-11 830/745/R	ALL
L00018 T	8	1978X LAMP-(COCA169215 CI223)	COCOOAAL 08805	1	33-43-11 830/745/R	ALL
L00018 T		1978X LAMP-	284N1112 08805	1	33-43-11 830/745/R	ALL
L00019		S283T013-19 LT ASSY-POSITION,RIGHT WING REAR	284N1112 81205	1	33-43-11 845/742/R	ALL
L00019 T		1978X LAMP-	284N1112 08805	1	33-43-11 845/742/R	ALL
L00020		S283T012-31 LT-ANTI-COLLISION,L WING	284N1113 81205	1	33-44-21 WBL740/ /L	001-099
L00020		S283T012-11 LT-ANTI-COLLISION,L WING	284N1113 81205	1	33-44-21 WBL740/ /L	115-199
L00020 T		31-5451-1 LAMP-MODULE	284N1113 72914	1	33-44-21 WBL740/ /L	ALL

EQUIPMENT LIST

D280N032

Section L00000

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00021		S283T012-32 LT-ANTI-COLLISION,R WING	284N1113 81205	1	33-44-21 WBL740/ /R	001-099
L00021		S283T012-12 LT-ANTI-COLLISION,R WING	284N1113 81205	1	33-44-21 WBL740/ /R	115-199
L00021 T		31-5451-1 LAMP-MODULE	284N1113 72914	1	33-44-21 WBL740/ /R	ALL
L00022	1	S283T012-27 LT-ANTI-COLLISION,UPR BODY	284N1357 81205	1	33-44-11 0590/306/R005	ALL
L00022	2	S283T012-26 LT-ANTI-COLLISION,UPR BODY	284N1357 81205	1	33-44-11 0590/306/R005	ALL
L00022	3	S283T012-23 LT-ANTI-COLLISION,UPR BODY	284N1357 81205	1	33-44-11 0590/306/R005	ALL
L00022 T		31-5241-1 LAMP-QUARTZ XENON	284N1357 72914	1	33-44-11 0590/306/R005	ALL
L00023	1	S283T012-27 LT-ANTI-COLLISION,LWR BODY	284N1442 81205	1	33-44-11 1050/135/0	ALL
L00023	2	S283T012-26 LT-ANTI-COLLISION,LWR BODY	284N1442 81205	1	33-44-11 1050/135/0	ALL
L00023	3	S283T012-23 LT-ANTI-COLLISION,LWR BODY	284N1442 81205	1	33-44-11 1050/135/0	ALL
L00023 T		31-5241-1 LAMP-QUARTZ XENON	284N1442 72914	1	33-44-11 1045/133/	ALL
L00024		S231T300-1010 LT-AUTOBRAKE	233N2221 81205	1	32-42-12 P001-03/ /	ALL
L00025	1	S283T008-61 LT-EMERGENCY SLIDE,DR 1 L	284N1402 81205	1	33-51-12 0385/242/L073	ALL
L00025	2	S283T008-39 LT-EMERGENCY SLIDE,DR 1 L	284N1402 81205	1	33-51-12 0385/242/L073	ALL
L00025 T		767 LAMP-	S283T008 08806	1	33-51-12 0385/242/L073	ALL
L00026		S417N505-21 LT-EMERGENCY EXIT LOCATOR SIGN	411N3210 81205	1	33-51-12 346/288/L008	ALL
L00026 T		OL-3071BPEGPL LAMP-	S417N505 S3774	24	33-51-12 346/288/L008	ALL

EQUIPMENT LIST

D280N032

Section L00000

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00027		S417N505-28 LT-EMERGENCY EXIT SIGN,DOOR 1 R	417N5200 81205	1	33-51-12 346/281/R046	ALL
L00027 T		OL-3071BPEGPL LAMP-	S417N505 S3774	21	33-51-12 0346/281/R046	ALL
L00030	1	S283T008-62 LT-EMERGENCY SLIDE,DR 1 R	284N1402 81205	1	33-51-12 372/242/R073	ALL
L00030	2	S283T008-24 LT-EMERGENCY SLIDE,DR 1 R	284N1402 81205	1	33-51-12 372/242/R073	ALL
L00030 T		767 LAMP-	S283T008 08806	1	33-51-12 0372/242/R073	ALL
L00031		S417N505-28 LT-EMERGENCY EXIT SIGN,DOOR 1 LEFT	417N5200 81205	1	33-51-12 0358/287/L040	ALL
L00031 T		OL-3071BPEGPL LAMP-	S417N505 S3774	21	33-51-12 0358/287/L040	ALL
L00035	1	S283T008-65 LT-EMERGENCY SLIDE, DR 2 L	284N1402 81205	1	33-51-13 735/242/L073	ALL
L00035	2	S283T008-55 LT-EMERGENCY SLIDE,DR 2 L	284N1402 81205	1	33-51-13 735/242/L073	ALL
L00035 T		767 LAMP-	S283T008 08806	1	33-51-13 0735/242/L073	ALL
L00037		S417N505-27 LT-EMERGENCY EXIT SIGN,DOOR 2 R	417N5200 81205	1	33-51-13 710/283/R046	ALL
L00037 T		OL-3071BPEGPL LAMP-	S417N505 S3774	30	33-51-13 710/283/R046	ALL
L00041	1	S283T008-64 LT-EMERGENCY SLIDE,DR 2 R	284N1402 81205	1	33-51-13 735/242/R073	ALL
L00041	2	S283T008-54 LT-EMERGENCY SLIDE,DR 2 R	284N1402 81205	1	33-51-13 735/242/R073	ALL
L00041 T		767 LAMP-	S283T008 08806	1	33-51-13 0735/242/R073	ALL
L00043		S417N505-27 LT-EMERGENCY EXIT SIGN,DOOR 2 L	417N5200 81205	1	33-51-13 0710/284/L050	ALL
L00043 T		OL-3071BPEGPL LAMP-	S417N505 S3774	30	33-51-13 0710/284/L050	ALL

EQUIPMENT LIST

D280N032

Section L00000

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00047	1	S283T008-67 LT-EMERGENCY SLIDE,DR 3 L	284N1402 81205	1	33-51-14 1355/242/L073	ALL
L00047	2	S283T008-57 LT-EMERGENCY SLIDE,DR 3 L	284N1402 81205	1	33-51-14 1355/242/L073	ALL
L00047 T		767 LAMP-	S283T008 08806	1	33-51-14 1355/242/L073	ALL
L00048		S417N505-125 LT-EMERGENCY EXIT LOCATOR SIGN	417N5200 81205	1	33-51-14 1222/293/L006	001-099
L00048 T		OL-3071BPEGPL LAMP-	S417N505 S3774	30	33-51-14 1222/293/L006	001-099
L00049		S417N505-28 LT-EMERGENCY EXIT SIGN,DOOR 3 R	417N5200 81205	1	33-51-14 1335/266/R058	ALL
L00049 T		OL-3071BPEGPL LAMP-	S417N505 S3774	21	33-51-14 1335/266/R058	ALL
L00050	1	S283T008-66 LT-EMERGENCY SLIDE,DR 3 R	284N1402 81205	1	33-51-14 1355/242/R073	ALL
L00050	2	S283T008-56 LT-EMERGENCY SLIDE,DR 3 R	284N1402 81205	1	33-51-14 1355/242/R073	ALL
L00050 T		767 LAMP-	S283T008 08806	1	33-51-14 1355/242/R073	ALL
L00052		S417N505-28 LT-EMERGENCY EXIT SIGN,DR 3 L	417N5200 81205	1	33-51-14 1335/266/L058	ALL
L00052 T		OL-3071BPEGPL LAMP-	S417N505 S3774	21	33-51-14 1335/266/L058	ALL
L00056	1	S283T008-59 LT-EMERGENCY SLIDE,DR 4 L	284N1402 81205	1	33-51-15 1689/245/L066	ALL
L00056	2	S283T008-37 LT-EMERGENCY SLIDE,DR 4 L	284N1402 81205	1	33-51-15 1689/245/L066	ALL
L00056 T		767 LAMP-	S283T008 08806	1	33-51-15 1689/245/L066	ALL
L00057		S417N505-28 LT-EMERGENCY EXIT SIGN,DOOR 4 R	417N5200 81205	1	33-51-15 1664/287/R038	ALL
L00057 T		OL-3071BPEGPL LAMP-	S417N505 S3774	21	33-51-15 1664/287/R038	ALL

EQUIPMENT LIST

D280N032

Section L00000

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00060	1	S283T008-60 LT-EMERGENCY SLIDE,DR 4 R	284N1402 81205	1	33-51-15 1689/245/R066	ALL
L00060	2	S283T008-38 LT-EMERGENCY SLIDE,DR 4 R	284N1402 81205	1	33-51-15 1689/245/R066	ALL
L00060 T		767 LAMP-	S283T008 08806	1	33-51-15 1689/245/R066	ALL
L00062		S417N505-28 LT-EMERGENCY EXIT SIGN,DOOR 4 LEFT	417N5200 81205	1	33-51-15 1664/287/L038	ALL
L00062 T		OL-3071BPEGPL LAMP-	S417N505 S3774	21	33-51-15 1664/287/L038	ALL
L00069		S283T008-22 LT-WING ILLUMINATION,R	284N1358 81205	1	33-41-11 0650/215/R007	001-002, 115-199
L00069		S283T008-100 LT-WING ILLUMINATION,R	284N1358 81205	1	33-41-11 0650/215/R072	003-099
L00069 T		Q4631 LAMP-	284N1358 08805	1	33-41-11 0650/215/R072	ALL
L00070		S283T008-21 LT-WING ILLUMINATION,L	284N1358 81205	1	33-41-11 650/215/L072	001-002, 115-199
L00070		S283T008-101 LT-WING ILLUMINATION,L	284N1358 81205	1	33-41-11 650/215/L072	003-099
L00070 T		Q4631 LAMP-	284N1358 08805	1	33-41-11 650/215/L072	ALL
L00071		10-0015-17 LT-WHEEL WELL,NOSE GEAR	284N1419 72914	1	33-31-11 381/190/L004	ALL
L00071 T		3011 LAMP-	284N1419 08805	1	33-31-11 381/190/L004	ALL
L00072		10-0015-17 LT-WHEEL WELL,MAIN,R	284N1441 72914	1	33-31-11 1180/185/R035	ALL
L00072 T		3011 LAMP-	284N1441 08805	1	33-31-11 1180/185/R035	ALL
L00073		10-0015-17 LT-WHEEL WELL,MAIN,R	284N1441 72914	1	33-31-11 1072/196/R028	ALL
L00073 T		3011 LAMP-	284N1441 08805	1	33-31-11 1072/196/R028	ALL

EQUIPMENT LIST

D280N032

Section L00000

Page 6

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00076		10-0015-17 LT-WHEEL WELL,MAIN,L	284N1441 72914	1	33-31-11 1072/196/L028	ALL
L00076 T		3011 LAMP-	284N1441 08805	1	33-31-11 1072/196/L028	ALL
L00077		10-0015-17 LT-WHEEL WELL,MAIN,L	284N1441 72914	1	33-31-11 1180/185/L035	ALL
L00077 T		3011 LAMP-	284N1441 08805	1	33-31-11 1180/185/L035	ALL
L00078		10-0015-17 LT-WHEEL WELL,NOSE GEAR	284N1419 72914	1	33-31-11 0274/175/R025	ALL
L00078 T		3011 LAMP-	284N1419 08805	1	33-31-11 0274/175/R025	ALL
L00079		284N1067-21 LT-RUNWAY TURNOFF,L	284N1761 81205	1	33-42-21 P063-00/ /	ALL
L00079 T		4551 LAMP-	284N1761 08805	1	33-42-21 P063-00/ /	ALL
L00080		284N1067-22 LT-RUNWAY TURNOFF,R	284N1761 81205	1	33-42-21 P062-00/ /	ALL
L00080 T		4551 LAMP-	284N1761 08805	1	33-42-21 P062-00/ /	ALL
L00081		121-563-1005-005 LT-REFUELING VALVE OPEN,R	344N5101 81590	1	28-21-23 P028-00/ /	ALL
L00082		121-563-1005-005 LT-REFUELING VALVE OPEN,R CTR	344N5101 81590	1	28-21-23 P028-00/ /	ALL
L00083		121-563-1005-005 LT-REFUELING VALVE OPEN,L	344N5101 81590	1	28-21-23 P028-00/ /	ALL

EQUIPMENT LIST

D280N032

Section L00000

Page 7 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00224	1	15-0188-11 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1230/200/R015	ALL
L00224	2	BR7203-701 LT-AFT CARGO COMPT	453N4210 17023	1	33-37-21 1230/200/R015	ALL
L00224	3	15-0188-7 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1230/200/R015	ALL
L00224 T		3011 LAMP-	453N4210 08806	1	33-37-21 1230/200/R015	ALL
L00225	1	15-0188-11 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1380/200/R015	ALL
L00225	2	BR7203-701 LT-AFT CARGO COMPT	453N4210 17023	1	33-37-21 1380/200/R015	ALL
L00225	3	15-0188-7 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1380/200/R015	ALL
L00225 T		3011 LAMP-	453N4210 08806	1	33-37-21 1380/200/R015	ALL
L00226	1	15-0188-11 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1430/200/R015	ALL
L00226	2	BR7203-701 LT-AFT CARGO COMPT	453N4210 17023	1	33-37-21 1430/200/R015	ALL
L00226	3	15-0188-7 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1430/200/R015	ALL
L00226 T		3011 LAMP-	453N4210 08806	1	33-37-21 1470/200/R015	ALL
L00227	1	15-0188-11 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1530/200/R015	ALL
L00227	2	BR7203-701 LT-AFT CARGO COMPT	453N4210 17023	1	33-37-21 1530/200/R015	ALL
L00227	3	15-0188-7 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1530/200/R015	ALL
L00227 T		3011 LAMP-	453N4210 08806	1	33-37-21 1530/200/R015	ALL
L00228	1	15-0188-11 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1590/200/L015	ALL

EQUIPMENT LIST

D280N032

Section L00200

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00228	2	BR7203-701 LT-AFT CARGO COMPT	453N4210 17023	1	33-37-21 1590/200/L015	ALL
L00228	3	15-0188-7 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1590/200/L015	ALL
L00228 T		3011 LAMP-	453N4210 08806	1	33-37-21 1590/200/L015	ALL
L00229	1	15-0188-11 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1470/200/L015	ALL
L00229	2	BR7203-701 LT-AFT CARGO COMPT	453N4210 17023	1	33-37-21 1470/200/L015	ALL
L00229	3	15-0188-7 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1470/200/L015	ALL
L00229 T		3011 LAMP-	453N4210 08806	1	33-37-21 1470/200/L015	ALL
L00230	1	15-0188-11 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1390/200/L015	ALL
L00230	2	BR7203-701 LT-AFT CARGO COMPT	453N4210 17023	1	33-37-21 1390/200/L015	ALL
L00230	3	15-0188-7 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1390/200/L015	ALL
L00230 T		3011 LAMP-	253N4210 08806	1	33-37-21 1390/200/L015	ALL
L00231	1	15-0188-11 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1290/200/L015	ALL
L00231	2	BR7203-701 LT-AFT CARGO COMPT	453N4210 17023	1	33-37-21 1290/200/L015	ALL
L00231	3	15-0188-7 LT-AFT CARGO COMPT	453N4210 72914	1	33-37-21 1290/200/L015	ALL
L00231 T		3011 LAMP-	453N4210 08806	1	33-37-21 1290/200/L015	ALL
L00232	1	15-0188-11 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 750/201/L015	ALL
L00232	2	BR7203-701 LT-FWD CARGO COMPT	453N4110 17023	1	33-37-11 750/201/L015	ALL

EQUIPMENT LIST

D280N032

Section L00200

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00232	3	15-0188-7 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 750/201/L015	ALL
L00232 T		3011 LAMP-	453N4110 08806	1	33-37-11 750/201/L015	ALL
L00233	1	15-0188-11 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 630/200/L015	ALL
L00233	2	BR7203-701 LT-FWD CARGO COMPT	453N4110 17023	1	33-37-11 630/200/L015	ALL
L00233	3	15-0188-7 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 630/200/L015	ALL
L00233 T		3011 LAMP-	453N4110 08806	1	33-37-11 630/201/L022	ALL
L00234	1	15-0188-11 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 810/201/R015	ALL
L00234	2	BR7203-701 LT-FWD CARGO COMPT	453N4110 17023	1	33-37-11 810/201/R015	ALL
L00234	3	15-0188-7 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 810/201/R015	ALL
L00234 T		3011 LAMP-	453N4110 08806	1	33-37-11 810/201/R015	ALL
L00235	1	15-0188-11 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 690/201/R015	ALL
L00235	2	BR7203-701 LT-FWD CARGO COMPT	453N4110 17023	1	33-37-11 690/201/R015	ALL
L00235	3	15-0188-7 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 690/201/R015	ALL
L00235 T		3011 LAMP-	453N4110 08806	1	33-37-11 690/201/R015	ALL
L00236		15-0491-1 LT-THRESHOLD STEP	232N5004 72914	1	33-14-41 304/215/L020	ALL
L00236 T		1864 LAMP-	232N5004 24455	1	33-14-41 304/215/L020	ALL
L00237		S231T300-1054 LT-MKR BCN,CAPT,INNER	233N2201 81205	1	34-32-11 P001-03/ /	ALL

EQUIPMENT LIST

D280N032

Section L00200

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00238		S231T300-1070 LT-MKR BCN,CAPT,MIDDLE	233N2201 81205	1	34-32-11 P001-03/ /	ALL
L00239		S231T300-1082 LT-MKR BCN,CAPT,OUTER	233N2201 81205	1	34-32-11 P001-03/ /	ALL
L00240		S231T300-1054 LT-MKR BCN,F/O,INNER	233N2204 81205	1	34-32-11 P003-03/ /	ALL
L00241		S231T300-1070 LT-MKR BCN,F/O,MIDDLE	233N2204 81205	1	34-32-11 P003-03/ /	ALL
L00242		S231T300-1082 LT-MKR BCN,F/O,OUTER	233N2204 81205	1	34-32-11 P003-03/ /	ALL
L00243		15-0143-35 LT-FUELING PANEL	284N1114 72914	1	28-21-11 OSS495/ /RLE	ALL
L00243 T		GE-1691 LAMP-	284N1114 08806	1	28-21-11 OSS495/ /RLE	ALL
L00252		S417N502-1 LT-ENTRY SPOT	412N1240 81205	1	33-22-12 682/270/L053	115-199
L00252 T		1308 LAMP-ENTRY SPOT,MID FWD	S417N502 S5006	1	33-22-12 0682/270/L053	115-199
L00253		S417N502-1 LT-ENTRY SPOT	412N1240 81205	1	33-22-12 0737/270/L053	ALL
L00253 T		1308 LAMP-ENTRY SPOT,MID FWD	S417N502 S5006	1	33-22-12 0737/270/L053	ALL
L00259		S417N502-2 LT-WORK,L FWD	411N3210 81205	1	33-22-11 361/288/L024	ALL
L00259 T		1308 LAMP-WORK,L FWD	S417N502 S5006	1	33-22-11 0361/288/L024	ALL
L00260		S417N502-4 LT-THRESHOLD,L FWD	411N3210 81205	1	33-22-11 0349/288/L024	ALL
L00260 T		1308 LAMP-THRESHOLD,L FWD	S417N502 S5006	1	33-22-11 0349/288/L024	ALL
L00267		S417N502-5 LT-THRESHOLD	411N3210 81205	1	33-22-14 1677/288/L032	ALL
L00267 T		1308 LAMP-THRESHOLD LT	S417N502 S5006	1	33-22-14 1677/288/L032	ALL

EQUIPMENT LIST

D280N032

Section L00200

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00269		S231T300-1226 LT-CAUTION DISPLAY	233N2221 81205	1	22-14-11 P001-03/ /	ALL
L00270		121-563-1005-005 LT-DEFUEL VALVE,R	344N5101 81590	1	28-26-11 P028-00/ /	ALL
L00271		121-563-1005-005 LT-DEFUEL VALVE,L	344N5001 81590	1	28-26-11 P028-00/ /	ALL
L00272		S233T810-1 LT ASSY-FLOOD,CAPT INSTR PNL	233N8100 81205	1	33-11-11 P007-00/ /	ALL
L00272 T		GE5108WW LAMP-	233N8100 08806	2	33-11-11 P007-00/ /	ALL
L00273		S233T810-10 LT ASSY-FLOOD,CENTER INSTR PNL	233N8100 81205	1	33-11-11 P007-00/220/L015	ALL
L00273 T		GE5108WW LAMP-	233N8100 08806	1	33-11-11 290/220/L015	ALL
L00274		S233T810-1 LT ASSY-FLOOD,F/O INSTR PNL	233N8100 81205	1	33-11-11 P007-00/ /	ALL
L00274 T		GE5108WW LAMP-	233N8100 08806	2	33-11-11 P007-00/ /	ALL
L00275		60B40059-4 LT-DOME,CAPT	232N5001 81205	1	33-11-31 258/260/L024	ALL
L00275 T		1665 LAMP-	232N5001 24455	1	33-11-31 258/260/L024	ALL
L00276		60B40059-4 LT-DOME,F/O	232N5001 81205	1	33-11-31 258/260/R024	ALL
L00276 T		1665 LAMP-	232N5001 24455	1	33-11-31 258/260/R024	ALL
L00277		232T500-1 LT-MAP,CAPT OVHD	232N5002 81205	1	33-14-11 0247/255/L018	ALL
L00277 T		1308 LAMP-	232N5002 S5006	1	33-14-11 247/255/L018	ALL
L00278		232T500-1 LT-MAP,F/O OVHD	232N5002 81205	1	33-14-11 247/255/R018	ALL
L00278 T		1308 LAMP-	232N5002 S5006	1	33-14-11 247/255/R018	ALL

EQUIPMENT LIST

D280N032

Section L00200

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00279		69B41965-1 LT-CAPT CHART	232N5010 81205	1	33-14-21 P007-00/ /	ALL
L00279 T		1864 LAMP-	232N5010 24455	1	33-14-21 P007-00/ /	ALL
L00280		69B41965-1 LT-F/O CHART	232N5010 81205	1	33-14-21 P007-00/ /	ALL
L00280 T		1864 LAMP-	232N5010 24455	1	33-14-21 P007-00/ /	ALL
L00283		S233T100-8001 LT PLATE-ROW A	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00284		S233T100-8002 LT PLATE-ROW A/B	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00285		S233T100-8002 LT PLATE-ROW B/C	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00286		S233T100-8002 LT PLATE-ROW C/D	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00287		S233T100-8002 LT PLATE-ROW D/E	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00288		S233T100-8002 LT PLATE-ROW E/F	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00289		S233T100-8002 LT PLATE-ROW F/G	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00290		S233T100-8002 LT PLATE-ROW G/H	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00291		S233T100-8001 LT PLATE-ROW J	233N5200 81205	1	33-13-61 P011-03/ /	ALL
L00292		S233T100-8002 LT PLATE-ROW J/K	233N5200 81205	1	33-13-61 P011-03/ /	ALL
L00293		S233T100-8002 LT PLATE-ROW K/L	233N5200 81205	1	33-13-61 P011-03/ /	ALL
L00294		S233T100-8002 LT PLATE-ROW L/M	233N5200 81205	1	33-13-61 P011-03/ /	ALL
L00295		S233T100-8002 LT PLATE-ROW M/N	233N5200 81205	1	33-13-61 P011-03/ /	ALL

EQUIPMENT LIST

D280N032

Section L00200

Page 6

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00296		S233T100-8002 LT PLATE-ROW N/P	233N5200 81205	1	33-13-61 P011-03/ /	ALL
L00297		S233T100-8002 LT PLATE-ROW P/Q	233N5200 81205	1	33-13-61 P011-03/ /	ALL
L00298		S233T100-8002 LT PLATE-ROW Q/R	233N5200 81205	1	33-13-61 P011-03/ /	ALL
L00299		S233T100-8002 LT PLATE-ROW R/S	233N5200 81205	1	33-13-61 P011-03/ /	ALL

EQUIPMENT LIST

D280N032

Section L00200
Page 7 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00300		S233T100-8003 LT PLATE-ROW A	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00301		S233T100-8002 LT PLATE-ROW A/B	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00302		S233T100-8002 LT PLATE-ROW B/C	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00303		S233T100-8002 LT PLATE-ROW C/D	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00304		S233T100-8002 LT PLATE-ROW D/E	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00305		S233T100-8002 LT PLATE-ROW E/F	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00306		S233T100-8002 LT PLATE-ROW F/G	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00307		S233T100-8002 LT PLATE-ROW G/H	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00308		S233T100-8003 LT PLATE-ROW J	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00309		S233T100-8002 LT PLATE-ROW J/K	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00310		S233T100-8002 LT PLATE-ROW K/L	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00311		S233T100-8002 LT PLATE-ROW L/M	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00312		S233T100-8002 LT PLATE-ROW M/N	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00313		S233T100-8002 LT PLATE-ROW N/P	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00314		S233T100-8002 LT PLATE-ROW P/Q	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00315		S233T100-8002 LT PLATE-ROW Q/R	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00316		S233T100-8002 LT PLATE-ROW R/S	233N5200 81205	1	33-13-61 P011-04/ /	ALL

EQUIPMENT LIST

D280N032

Section L00300

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00324		855320-7-387 LT-CALL,ATTEND,FWD	411N3270 14889	1	23-42-11 350/288/L005	ALL
L00324 T		387 LAMP-	411N3270 08806	1	23-42-11 350/288/L005	ALL
L00335		15-0129-7 LT-FWD ELEC EQUIP CTR	284N1401 72914	1	33-31-41 0263/196/L031	ALL
L00335 T		2233 LAMP-	284N1401 24455	1	33-31-41 0263/196/L031	ALL
L00336		15-0129-7 LT-FWD ELEC EQUIP CTR	284N1401 72914	1	33-31-41 0263/196/R031	ALL
L00336 T		2233 LAMP-	284N1401 24455	1	33-31-41 0263/196/R031	ALL
L00337		15-0129-7 LT-MN ELEC EQUIP CTR	284N1355 72914	1	33-31-41 0362/201/R041	ALL
L00337 T		2233 LAMP-	284N1355 24455	1	33-31-41 0362/201/R041	ALL
L00338		15-0129-7 LT-MN ELEC EQUIP CTR	284N1355 72914	1	33-31-41 0418/198/R013	ALL
L00338 T		2233 LAMP-	284N1355 24455	1	33-31-41 0418/198/R013	ALL
L00339		15-0129-7 LT-MN ELEC EQUIP,CTR	284N1355 72914	1	33-31-41 0418/198/L006	ALL
L00339 T		2233 LAMP-	284N1355 24455	1	33-31-41 0418/198/L006	ALL
L00340		15-0129-7 LT-MN ELEC EQUIP CTR	284N1355 72914	1	33-31-41 0418/198/L029	ALL
L00340 T		2233 LAMP-	284N1355 24455	1	33-31-41 0418/198/L029	ALL
L00341		15-0129-7 LT-MN ELEC EQUIP CTR	284N1355 72914	1	33-31-41 0463/201/L003	ALL
L00341 T		2233 LAMP-	284N1355 24455	1	33-31-41 0463/201/L003	ALL
L00342		15-0129-7 LT-MN ELEC EQUIP CTR	284N1355 72914	1	33-31-41 0471/201/R016	ALL

EQUIPMENT LIST

D280N032

Section L00300

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00342 T		2233 LAMP-	284N1355 24455	1	33-31-41 0471/201/R016	ALL
L00343		15-0129-7 LT-MN ELEC EQUIP,CTR	284N1355 72914	1	33-31-41 0477/201/L016	ALL
L00343 T		2233 LAMP-	284N1355 24455	1	33-31-41 0477/201/L016	ALL
L00344		15-0143-29 LT-AIR COND COMPT LEFT	284N1447 72914	1	33-31-21 961/160/L030	ALL
L00344 T		2233 LAMP-	284N1447 24455	1	33-31-21 961/160/L030	ALL
L00345		15-0143-29 LT-AIR COND COMPT LEFT	284N1447 72914	1	33-31-21 1037/137/L016	ALL
L00345 T		2233 LAMP-	284N1447 24455	1	33-31-21 1037/137/L016	ALL
L00346		15-0143-29 LT-AIR COND COMPT RIGHT	284N1447 72914	1	33-31-21 961/160/R045	ALL
L00346 T		2233 LAMP-	284N1447 24455	1	33-31-21 961/160/R045	ALL
L00347		15-0143-29 LT-AIR COND COMPT RIGHT	284N1447 72914	1	33-31-21 1037/137/R020	ALL
L00347 T		2233 LAMP-	284N1447 24455	1	33-31-21 1037/137/R020	ALL
L00348		15-0143-29 LT-TAILCONE COMPT	284N1481 72914	1	33-31-31 1727/245/L030	ALL
L00348 T		2233 LAMP-	284N1481 24455	1	33-31-31 1727/245/L030	ALL
L00349		15-0143-29 LT-TAILCONE COMPT	284N1481 72914	1	33-31-31 1727/245/R030	ALL
L00349 T		2233 LAMP-	284N1481 24455	1	33-31-31 1727/245/R030	ALL
L00350		15-0143-29 LT-TAILCONE COMPT	284N1481 72914	1	33-31-31 1864/275/L009	ALL
L00350 T		2233 LAMP-	284N1481 24455	1	33-31-31 1864/275/L009	ALL

EQUIPMENT LIST

D280N032

Section L00300

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00351		15-0143-29 LT-APU COMPT	284N1481 72914	1	33-31-31 1885/224/R016	ALL
L00351 T		2233 LAMP-	284N1481 24455	1	33-31-31 1885/224/R016	ALL
L00352		S417N502-3 LT-THRESHOLD,FWD LAV A	411N3210 81205	1	33-26-31 319/290/L017	001-099
L00352		S417N502-3 LT-THRESHOLD,FWD LAV A	411N3210 81205	1	33-26-31 319/289/L017	115-199
L00352 T		1251 LAMP-THRESHOLD,FWD LAV A	S417N502 08806	1	33-26-31 319/289/L017	ALL
L00354		S417N502-3 LT-THRESHOLD,MID LAV C	411N3210 81205	1	33-26-31 1300/289/L019	001-099
L00354		S417N502-3 LT-THRESHOLD,MID LAV C	411N3210 81205	1	33-26-31 1303/289/L019	115-199
L00354 T		1251 LAMP-THRESHOLD,MID LAV C	S417N502 08806	1	33-26-31 1303/289/L019	ALL
L00355		S417N502-3 LT-THRESHOLD,MID LAV D	411N3210 81205	1	33-26-31 1300/289/R019	001-099
L00355		S417N502-3 LT-THRESHOLD,MID LAV D	411N3210 81205	1	33-26-31 1303/289/R019	115-199
L00355 T		1251 LAMP-THRESHOLD,MID LAV D	S417N502 08806	1	33-26-31 1303/289/R019	ALL
L00356		284N1111-3 LT-FIXED LDG,LEFT	284N1111 81205	1	33-42-11 FSS97/184/W88	ALL
L00356 T		Q4559X LAMP-	284N1111 24455	1	33-42-11 FSS97/ /	ALL
L00357		284N1111-3 LT-FIXED LDG,RIGHT	284N1111 81205	1	33-42-12 FSS94.5/ /RLE	ALL
L00357 T		Q4559X LAMP-	284N1111 24455	1	33-42-11 ISS97/ /RLE	ALL
L00358		284N1067-69 LT-NLG LDG,LEFT	284N1761 81205	1	33-42-11 P063-00/ /	ALL
L00358 T		Q4559X LAMP-	284N1761 24455	1	33-42-11 P063-00/ /	ALL

EQUIPMENT LIST

D280N032

Section L00300

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00359		284N1067-69 LIGHT-NLG LDG,RIGHT	284N1761 81205	1	33-42-11 P062-00/ /	ALL
L00359 T		Q4559X LAMP-	284N1761 24455	1	33-42-11 P062-00/ /	ALL
L00361		S233T100-5008 LT PLATE-LH INSTR SOURCE CONT PNL	233N2101 81205	1	33-13-11 P001-01/ /	ALL
L00367		S233T100-5009 LT PLATE-RH INSTR SOURCE CONT PNL	233N2101 81205	1	33-13-21 P003-03/ /	ALL
L00370		S233T100-5021 LT PLATE-LANDING GEAR/FLAP CONTROL	233N2101 81205	1	33-13-21 P003-01/ /	001-099
L00370		S233T100-5020 LT PLATE-LANDING GEAR/FLAP CONTROL	233N2101 81205	1	33-13-21 P003-01/ /	115-199
L00371		S233T100-5012 LT PLATE-CAUTION CANCEL/RECALL	233N2101 81205	1	33-13-12 P001-03/ /	ALL
L00372		S233T100-5014 LT PLATE-AUTO BRAKE CONTROL	233N2101 81205	1	33-13-11 P001-03/ /	001-099
L00372		S233T100-5002 LT PLATE-AUTO BRAKE CONTROL	233N2101 81205	1	33-13-12 P001-03/ /	115-199
L00373		33-32683-6P1 LT-HOT BUS WARN,GND SVCE	284N1127 29207	1	24-51-52 P037-00/ /	ALL
L00374	1	15-0188-11 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 590/201/R015	ALL
L00374	2	BR7203-701 LT-FWD CARGO COMPT	453N4110 17023	1	33-37-11 590/201/R015	ALL
L00374	3	15-0188-7 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 590/201/R015	ALL
L00374 T		3011 LAMP-	453N4110 08806	1	33-37-11 590/201/R015	ALL
L00375		34265-8 LT-FLT KIT,CAPT	232N5003 72914	1	33-14-31 244/215/L048	ALL
L00375 T		1864 LAMP-	232N5003 24455	1	33-14-31 0244/215/L048	ALL
L00376		34265-8 LT-FLT KIT,F/O	232N5003 72914	1	33-14-31 240/220/R048	ALL

EQUIPMENT LIST

D280N032

Section L00300

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00376 T		1864 LAMP-	232N5003 24455	1	33-14-31 0240/220/R048	ALL
L00377		34265-8 LT-UTILITY,S/OBS	232N5003 72914	1	33-14-31 0275/245/R033	ALL
L00377 T		1864 LAMP-	232N5003 24455	1	33-14-31 0275/245/R033	ALL
L00379		15-0143-35 LT-FUELING PANEL	284N1114 72914	1	28-21-11 OSS515/ /RLE	ALL
L00379 T		GE-1691 LAMP-	284N1114 08806	1	28-21-11 OSS515/ /RLE	ALL
L00380		15-0143-29 LT-TAILCONE COMPT	284N1481 72914	1	33-31-31 1825/282/R016	ALL
L00380 T		2233 LAMP-	284N1481 24455	1	33-31-31 1825/282/R016	ALL
L00381		15-0129-7 LT-MN ELEC EQUIP,CTR	452N4110 72914	1	33-37-11 0520/200/R028	ALL
L00381 T		2233 LAMP-	453N4110 24455	1	33-37-11 520/200/R028	ALL
L00384		15-0129-7 LT-FWD ELEC EQUIP,CTR	284N1401 72914	1	33-31-41 0245/182/	ALL
L00384 T		2233 LAMP-	284N1401 24455	1	33-31-41 0245/182/	ALL
L00385		15-0133-1 LT-NO.1 CARGO DOOR,LOWER FWD	453N4120 72914	1	33-37-11 0568/ /	ALL
L00385 T		3011 LAMP-	453N4120 08806	1	33-37-11 0568/*/	ALL
L00386		15-0133-1 LT-NO.1 CARGO DOOR,CENTER	453N4120 72914	1	33-37-11 0568/ /	ALL
L00386 T		3011 LAMP-	453N4120 08806	1	33-37-11 0568/*/	ALL
L00387		15-0133-1 LT-NO.1 CARGO DOOR,LOWER AFT	453N4120 72914	1	33-37-11 0594/ /	ALL
L00387 T		3011 LAMP-	453N4120 08806	1	33-37-11 0594/*/	ALL

EQUIPMENT LIST

D280N032

Section L00300

Page 6

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00388		15-0133-1 LT-NO.1 CARGO DOOR,UPPER FWD	453N4120 72914	1	33-37-11 0612/ /	ALL
L00388 T		3011 LAMP-	453N4120 08806	1	33-37-11 0612/*/	ALL
L00389		15-0133-1 LT-FWD CARGO DOOR,UPPER AFT	453N4120 72914	1	33-37-11 0612/ /	ALL
L00389 T		3011 LAMP-	453N4120 08806	1	33-37-11 0612/*/	ALL
L00390		15-0133-1 LT-NO.2 CARGO DOOR,LOWER FWD	453N4120 72914	1	33-37-21 1388/ /	ALL
L00390 T		3011 LAMP-	453N4120 08806	1	33-37-21 1388/*/	ALL
L00391		15-0133-1 LT-NO.2 CARGO DOOR,CENTER	453N4120 72914	1	33-37-21 1388/ /	ALL
L00391 T		3011 LAMP-	453N4120 08806	1	33-37-21 1388/*/	ALL
L00392		15-0133-1 LT-NO.2 CARGO DOOR,LOWER AFT	453N4120 72914	1	33-37-21 1415/ /	ALL
L00392 T		3011 LAMP-	453N4120 08806	1	33-37-21 1415/*/	ALL
L00393		15-0133-1 LT-NO.2 CARGO DOOR,UPPER FWD	453N4120 72914	1	33-37-21 1432/ /	ALL
L00393 T		3011 LAMP-	453N4120 08806	1	33-37-21 1432/*/	ALL
L00394		15-0133-1 LT-NO.2 CARGO DOOR,UPPER AFT	453N4120 72914	1	33-37-21 1432/ /	ALL
L00394 T		3011 LAMP-	453N4120 08806	1	33-37-21 1432/*/	ALL
L00395		50-0130-1 LT-TAXI	284N1621 72914	1	33-42-31 P063-00/ /	001-099
L00395 T		4551 LAMP-	284N1621 08805	1	33-42-31 378/98/	001-099
L00396		S231T301-1203 LT-DOORS	233N2222 81205	1	32-61-11 P003-01/ /	ALL

EQUIPMENT LIST

D280N032

Section L00300

Page 7

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00397		S231T301-1204 LT-GEAR	233N2222 81205	1	32-61-11 P003-01/ /	ALL
L00398		S231T301-1205 LT-NOSE	233N2222 81205	1	32-61-12 P003-01/ /	ALL
L00398 T		MS25237-387 LAMP-	233N2222 96906	2	32-61-12 P003-01/ /	ALL
L00398 U		434-093-003 MODULE-DIODE/FUSE	233N2222 81205	1	32-61-12 P003-01/ /	ALL
L00399		S231T301-1207 LT-RIGHT	233N2222 81205	1	32-61-12 P003-01/ /	ALL
L00399 T		MS25237-387 LAMP-	233N2222 96906	2	32-61-12 P003-01/ /	ALL
L00399 U		434-093-003 MODULE-DIODE/FUSE	233N2222 81205	1	32-61-12 P003-01/ /	ALL

EQUIPMENT LIST

D280N032

Section L00300
Page 8 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00400		S231T301-1206 LT-LEFT	233N2222 81205	1	32-61-12 P003-01/ /	ALL
L00400 T		MS25237-387 LAMP-	233N2222 96906	2	32-61-12 P003-01/ /	ALL
L00400 U		434-093-003 MODULE-DIODE/FUSE	233N2222 81205	1	32-61-12 P003-01/ /	ALL
L00401		A8985-4 LT-FIRE,APU	284N1625 72914	1	26-15-12 P062-00/ /	ALL
L00402		121-563-1005-005 LT-REFUELING VALVE OPEN,L CTR	344N5101 81590	1	28-21-23 P028-00/ /	ALL
L00403		250-650-0994-001 LT-GIRT BAR ANN,NO 1 PASS DR,LEFT	411N2331 81590	1	25-66-11 360/288/L040	ALL
L00403 T		387 LAMP-	411N2331 08806	2	25-66-11 0360/288/L040	ALL
L00404		250-650-0994-001 LT-GIRT BAR ANN,NO 1 PASS DR,RIGHT	411N2331 81590	1	25-66-11 352/286/R050	ALL
L00404 T		387 LAMP-	411N2331 08806	2	25-66-11 0352/286/R050	ALL
L00405		250-650-0994-001 LT-GIRT BAR ANN,NO 2 PASS DR,LEFT	411N2009 81590	1	25-66-11 720/285/L050	ALL
L00405 T		387 LAMP-	411N2009 08806	2	25-66-11 720/285/L050	ALL
L00406		250-650-0994-001 LT-GIRT BAR ANN,NO 2 PASS DR,RIGHT	411N2009 81590	1	25-66-11 712/282/R050	ALL
L00406 T		387 LAMP-	411N2009 08806	2	25-66-11 0712/282/R050	ALL
L00407		250-650-0994-001 LT-GIRT BAR ANN,NO 4 PASS DR,LEFT	411N2331 81590	1	25-66-11 1664/290/L060	ALL
L00407 T		387 LAMP-	411N2331 08806	2	25-66-11 1664/290/L060	ALL
L00408		250-650-0994-001 LT-GIRT BAR ANN,NO 4 PASS DR,RIGHT	411N2331 81590	1	25-66-11 1679/280/R060	ALL
L00408 T		387 LAMP-	411N2331 08806	2	25-66-11 1679/280/R060	ALL

EQUIPMENT LIST

D280N032

Section L00400

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00409		S417N503-10 LT-MID FWD ATTND SIGN	417N5159 81205	1	33-24-12 0737/277/L037	001-099
L00409 T		387 LT-MID FWD ATTND SIGN	S417N503 08806	5	33-24-12 0737/277/L037	001-099
L00410		S417N503-10 LT-FWD ATTND SIGN	417N5159 81205	1	33-24-12 0340/275/L026	001-099
L00410		S417N503-7 LT-FWD ATTND SIGN	417N5159 81205	1	33-24-12 379/262/L031	115-199
L00410 T		387 LAMP-FWD ATTND SIGN	S417N503 08806	5	33-24-12 0340/275/L026	001-099
L00410 T		387 LAMP-FWD ATTND SIGN	S417N503 08806	5	33-24-12 0379/262/L031	115-199
L00412		S417N503-10 LT-MID AFT ATTND SIGN	417N5159 81205	1	33-24-14 1502/290/L001	001-099
L00412		S417N503-7 LT-MID AFT ATTND SIGN	417N5159 81205	1	33-24-14 1502/290/R001	115-199
L00412 T		387 LAMP-MID AFT ATTND SIGN	S417N503 08806	5	33-24-14 1502/290/L001	001-099
L00412 T		387 LAMP-MID AFT ATTND SIGN	S417N503 08806	5	33-24-14 1502/290/R001	115-199
L00413		S231T300-1234 LT-PARK BRAKE	233N6101 81205	1	32-44-11 P010-00/*	ALL
L00418		S417N506-2 LT-LAVATORY OCCUPIED SIGN	417N5159 81205	1	33-26-21 378/298/R002	001-099
L00418 T		387 LAMP-LAVATORY OCCUPIED SIGN	S417N506 08806	14	33-26-21 0378/290/R001	001-099
L00419		S417N506-2 LT-LAVATORY OCCUPIED SIGN	417N5159 81205	1	33-26-21 1243/289/L001	001-099
L00419		S417N506-1 LT-LAVATORY OCCUPIED SIGN	417N5159 81205	1	33-26-21 1243/289/L001	115-199
L00419 T		387 LAMP-LAVATORY OCCUPIED SIGN	S417N506 08806	14	33-26-21 1243/289/L001	001-099
L00419 T		387 LAMP-LAVATORY OCCUPIED SIGN	S417N506 08806	7	33-26-21 1243/289/L001	115-199

EQUIPMENT LIST

D280N032

Section L00400

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00420		S417N506 LT-LAVATORY OCCUPIED SIGN	417N5159 81205	1	33-26-21 1316/289/L001	001-099
L00420 T		387 LAMP-LAVATORY OCCUPIED SIGN	S417N506 08806	14	33-26-21 1316/289/L001	001-099
L00421		S283T008-33 LIGHT-LOGO,LEFT INBOARD	284N2801 81205	1	33-45-11 ELEV112/AS/	001-002, 115-199
L00421		S283T008-109 LIGHT-LOGO,LEFT INBOARD	284N2801 81205	1	33-45-11 ELEV112/AS/	003-008
L00421		S283T008-113 LIGHT-LOGO,LEFT INBOARD	284N2801 81205	1	33-45-11 ELEV112/AS/	009-099
L00421 T		Q4631 LAMP-	284N2801 08805	1	33-45-11 ELEV112/AS/	ALL
L00422		S283T008-35 LIGHT-LOGO,LEFT OUTBOARD	284N1801 81205	1	33-45-11 ELEV125/AS/	001-002, 115-199
L00422		S283T008-107 LIGHT-LOGO,LEFT OUTBOARD	284N1801 81205	1	33-45-11 ELEV125/AS/	003-008
L00422		S283T008-111 LIGHT-LOGO,LEFT OUTBOARD	284N1801 81205	1	33-45-11 ELEV125/AS/	009-099
L00422 T		Q4631 LAMP-	284N1801 08805	1	33-45-11 ELEV125/AS/	ALL
L00423		S283T008-34 LIGHT-LOGO,RIGHT INBOARD	284N1801 81205	1	33-45-11 ELEV/112/AS	001-002, 115-199
L00423		S283T008-108 LIGHT-LOGO,RIGHT INBOARD	284N1801 81205	1	33-45-11 ELEV/112/AS	003-008
L00423		S283T008-112 LIGHT-LOGO,RIGHT INBOARD	284N1801 81205	1	33-45-11 ELEV/112/AS	009-099
L00423 T		Q4631 LAMP-	284N1801 08805	1	33-45-11 ELEV/112/AS	ALL
L00424		S283T008-36 LIGHT-LOGO,RIGHT OUTBOARD	284N1801 81205	1	33-45-11 ELEV/125/AS	001-002, 115-199
L00424		S283T008-106 LIGHT-LOGO,RIGHT OUTBOARD	284N1801 81205	1	33-45-11 ELEV/125/AS	003-008
L00424		S283T008-110 LIGHT-LOGO,RIGHT OUTBOARD	284N1801 81205	1	33-45-11 ELEV/125/AS	009-099

EQUIPMENT LIST

D280N032

Section L00400

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00424 T		Q4631 LAMP-	284N1801 08805	1	33-45-11 ELEV/125/AS	ALL
L00429		S233T100-8003 LT PLATE-ROW H	233N5200 81205	1	33-13-61 P011-01/ /	ALL
L00430		S233T100-8003 LT PLATE-ROW S	233N5200 81205	1	33-13-61 P011-03/ /	ALL
L00431		S233T100-8001 LT PLATE-ROW H	233N5200 81205	1	33-13-61 P011-02/ /	ALL
L00432		S233T100-8001 LT PLATE-ROW S	233N5200 81205	1	33-13-61 P011-04/ /	ALL
L00433	1	S231T300-2236 LT-LEADING EDGE	233N2222 81205	1	27-51-41 P003-01/ /	ALL
L00433	2	S231T300-1236 LT-LEADING EDGE	233N2222 81205	1	27-51-41 P003-01/ /	ALL
L00434	1	S231T300-2237 LT-TRAILING EDGE	233N2222 81205	1	27-51-41 P003-01/ /	ALL
L00434	2	S231T300-1237 LT-TRAILING EDGE	233N2222 81205	1	27-51-41 P003-01/ /	ALL
L00441		L0060001 LT ASSY-GLARESHIELD FLDT,L	233N8100 51896	1	33-11-21 P007-00/ /	ALL
L00442		L0060002 LT ASSY-GLARESHIELD FLDT,R	233N8100 51896	1	33-11-21 P007-00/ /	ALL
L00443		B9735-2-1385 LT ASSY-FLOOD LT AISLE STAND,L	232N5007 72914	1	33-11-21 0255/260/L018	ALL
L00443 T		1385 LAMP-	232N5007 24455	1	33-11-21 0255/260/L018	ALL
L00444		B9735-1-1385 LT ASSY-FLOOD LT AISLE STAND,R	232N5007 72914	1	33-11-21 0255/260/R018	ALL
L00444 T		1385 LAMP-	232N5007 24455	1	33-11-21 0255/260/R018	ALL
L00445	1	S231T300-2294 LT-WHEELWELL FIRE	233N2222 81205	1	26-17-11 P003-01/ /	ALL
L00445	2	S231T300-1294 LT-WHEELWELL FIRE	233N2222 81205	1	26-17-11 P003-01/ /	ALL

EQUIPMENT LIST

D280N032

Section L00400

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00447		S417N301-1 LT-PASS INFO SIGN	417N3001 81205	69	33-24-31 MULTI/ /	001-003, 005, 007-099
L00447		S417N301-1 LT-PASS INFO SIGN	417N3001 81205	68	33-24-31 MULTI/ /	004, 006
L00447		S417N301-1 LT-PASS INFO SIGN	417N3001 81205	72	33-24-31 MULTI/ /	115-199
L00447 T		387 LAMP-PASS INFO SIGN	S417N301 08806	414	33-24-31 MULTI/ /	001-003, 005, 007-099
L00447 T		387 LAMP-PASS INFO SIGN	S417N301 08806	408	33-24-31 MULTI/ /	004, 006
L00447 T		387 LAMP-PASS INFO SIGN	S417N301 08806	432	33-24-31 MULTI/ /	115-199
L00448		SEEPARTA-B-C-D-E-ORF MODULE LT ASSY-PASS READ LT	417N3100 81205	65	33-23-31 MULTI/ /	001-003, 005, 007-099
L00448		SEEPARTA-B-C-D-E-ORF MODULE LT ASSY-PASS READ LT	417N3100 81205	86	33-23-31 MULTI/ /	004, 006
L00448		SEEPARTA-B-C-D-E-ORF MODULE LT ASSY-PASS READ LT	417N3100 81205	72	33-23-31 MULTI/ /	115-199
L00448A		S417N302-1 LT-PASS READ,LEFT	417N3100 81205	34	33-23-31 MULTI/ /	001-099
L00448A		S417N302-1 LT-PASS READ,LEFT	417N3100 81205	35	33-23-31 MULTI/ /	115-199
L00448AT		1308 LAMP-PASS READ LT	S417N302 S5006	34	33-23-31 MULTI/*/	001-099
L00448AT		1308 LAMP-PASS READ LT	S417N302 S5006	35	33-23-31 MULTI/ /	115-199
L00448B		S417N302-1 LT-PASS READ,LEFT	417N3100 81205	34	33-23-31 MULTI/ /	001-099
L00448B		S417N302-1 LT-PASS READ	417N3100 81205	35	33-23-31 MULTI/ /	115-199
L00448BT		1308 LAMP-PASS READ LT	S417N302 S5006	34	33-23-31 MULTI/*/	001-099
L00448BT		1308 LAMP-PASS READ LT	S417N302 S5006	35	33-23-31 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section L00400

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00448C		S417N302-1 LT-PASS READ,LEFT	417N3100 81205	34	33-23-31 MULTI/ /	001-099
L00448C		S417N302-1 LT-PASS READ	417N3100 81205	35	33-23-31 MULTI/ /	115-199
L00448CT		1308 LAMP-PASS READ LT	S417N302 S5006	34	33-23-31 MULTI/* /	001-099
L00448CT		1308 LAMP-PASS READ LT	S417N302 S5006	35	33-23-31 MULTI/ /	115-199
L00448D		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	35	33-23-31 MULTI/ /	001-003, 005, 007-099
L00448D		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	34	33-23-31 MULTI/ /	004, 006
L00448D		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	37	33-23-31 MULTI/ /	115-199
L00448DT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	35	33-23-31 MULTI/ /	001-003, 005, 007-099
L00448DT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	34	33-23-31 MULTI/ /	004, 006
L00448DT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	37	33-23-31 MULTI/ /	115-199
L00448E		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	35	33-23-31 MULTI/* /	001-003, 005, 007-099
L00448E		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	34	33-23-31 MULTI/* /	004, 006
L00448E		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	37	33-23-31 MULTI/* /	115-199
L00448ET		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	35	33-23-31 MULTI/* /	001-003, 005, 007-099
L00448ET		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	34	33-23-31 MULTI/* /	004, 006
L00448ET		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	37	33-23-31 MULTI/* /	115-199
L00448F		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	35	33-23-31 MULTI/ /	001-003, 005, 007-099

EQUIPMENT LIST

D280N032

Section L00400

Page 6

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00448F		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	34	33-23-31 MULTI/ /	004, 006
L00448F		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	37	33-23-31 MULTI/*/	115-199
L00448FT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	35	33-23-31 MULTI/*/	001-003, 005, 007-099
L00448FT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	34	33-23-31 MULTI/*/	004, 006
L00448FT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	37	33-23-31 MULTI/*/	115-199
L00449		S417N301-1 LT-PASS INFO SIGN	417N3001 81205	2	33-24-31 MULTI/ /	ALL
L00449 T		387 LAMP-PASS INFO SIGN	S417N301 08806	12	33-24-31 MULTI/ /	001-099
L00450		SEEPARTA-B-C-D-E-ORF MODULE LT ASSY-PASS READ LT	417N3100 81205	2	33-23-31 MULTI/ /	001-099
L00450A		S417N302-1 LT-PASS READ,LEFT	417N3100 81205	1	33-23-31 MULTI/ /	ALL
L00450AT		1308 LAMP-PASS READ LT,LEFT	S417N302 S5006	1	33-23-31 MULTI/ /	ALL
L00450B		S417N302-1 LT-PASS READ,LEFT	417N3100 81205	1	33-23-31 MULTI/ /	ALL
L00450BT		1308 LAMP-PASS READ LT,LEFT	S417N302 S5006	1	33-23-31 MULTI/ /	ALL
L00450C		S417N302-1 LT-PASS READ,LEFT	417N3100 81205	1	33-23-31 MULTI/ /	ALL
L00450CT		1308 LAMP-PASS READ LT,LEFT	S417N302 S5006	1	33-23-31 MULTI/ /	ALL
L00450D		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	1	33-23-31 MULTI/ /	ALL
L00450DT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	1	33-23-31 MULTI/ /	115-199
L00450E		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	1	33-23-31 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section L00400

Page 7

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00450ET		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	1	33-23-31 MULTI/ /	115-199
L00450F		S417N302-2 LT-PASS READ,RIGHT	417N3100 81205	1	33-23-31 MULTI/ /	ALL
L00450FT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	1	33-23-31 MULTI/ /	ALL
L00453		S417N301-1 LT-PASS INFO SIGN,SPACER PNL	417N3001 81205	4	33-24-31 MULTI/ /	001-099
L00453		S417N301-1 LT-PASS INFO SIGN,SPACER PNL	417N3001 81205	6	33-24-31 MULTI/ /	115-199
L00453 T		387 LAMP-PASS INFO SIGN,SPACER PNL	S417N301 08806	24	33-24-31 MULTI/*/	001-099
L00453 T		387 LAMP-PASS INFO SIGN,SPACER PNL	S417N301 08806	36	33-24-31 MULTI/ /	115-199
L00454		SEEPARTC-ORD MODULE LT ASSY-ATT WK LT	417N3700 81205	1	33-23-31 MULTI/ /	001-099
L00454		SEEPARTA-B-C-ORD MODULE LT ASSY-ATT WK LT	417N3700 81205	1	33-23-31 MULTI/ /	115-199
L00454A		S417N302-5-PROVISIONS- LT-ATT WK,LEFT	417N3700 81205	1	33-23-31 MULTI/ /	115-199
L00454C		S417N302-6 LT-ATT WK,RIGHT	417N3700 81205	1	33-23-31 MULTI/ /	115-199
L00454CT		1308 LAMP-ATT WK LT,RIGHT	S417N302 S5006	1	33-23-31 MULTI/ /	ALL
L00454D		S417N302-6 LT-ATT WK,RIGHT	417N3700 81205	1	33-23-31 MULTI/ /	115-199
L00454DT		1308 LAMP-ATT WK LT,RIGHT	S417N302 S5006	1	33-23-31 MULTI/ /	ALL
L00455		SEEPARTC-ORD MODULE LT ASSY-PASS READ LT	417N3200 81205	1	33-23-31 MULTI/*/	001-099
L00455		SEEPARTA-B-C-ORD MODULE LT ASSY-PASS READ LT	417N3200 81205	3	33-23-31 MULTI/ /	115-199
L00455A		S417N302-3 LT-PASS READ,LEFT	417N3200 81205	2	33-23-31 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section L00400

Page 8

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00455AT		1308 LAMP-PASS READ LT,LEFT	S417N302 S5006	2	33-23-31 MULTI/* /	115-199
L00455B		S417N302-3 LT-PASS READ,LEFT	417N3200 81205	2	33-23-31 MULTI/ /	115-199
L00455BT		1308 LAMP-PASS READ LT,LEFT	S417N302 S5006	2	33-23-31 MULTI/* /	115-199
L00455C		S417N302-4 LT-PASS READ,RIGHT	417N3200 81205	1	33-23-31 MULTI/* /	ALL
L00455CT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	1	33-23-31 MULTI/* /	ALL
L00455D		S417N302-4 LT-PASS READ,RIGHT	417N3200 81205	1	33-23-31 MULTI/* /	ALL
L00455DT		1308 LAMP-PASS READ LT,RIGHT	S417N302 S5006	1	33-23-31 MULTI/ /	ALL
L00456		121-563-1005-003 LT-PARKING BRAKE ON	284N1761 81590	1	32-44-11 P062-00/ /	115-199
L00457		F15T8WW LAMP-FLUORESCENT,FWD ENTRY LT ASSY	417N5113 08805	1	33-22-11 355/288/L014	ALL
L00457A		BV03112N03-25 LT ASSY SOCKET-FWD ENTRY	417N5113 17023	2	33-22-11 355/288/L014	ALL
L00458		F15T8WW LAMP-FLUORESCENT,FWD ENTRY LT ASSY	417N5113 08805	1	33-22-11 355/288/L014	ALL
L00458A		BV03112N03-25 LT ASSY SOCKET-FWD ENTRY	417N5113 17023	2	33-22-11 355/288/L014	ALL
L00459		F15T8WW LAMP-FLUORESCENT,FWD ENTRY LT ASSY	417N5113 08805	1	33-22-11 355/288/L014	ALL
L00459A		BV03112N03-25 LT ASSY SOCKET-FWD ENTRY	417N5113 17023	2	33-22-11 355/288/L014	ALL
L00460		F15T8WW LAMP-FLUORESCENT,FWD ENTRY LT ASSY	417N5113 08805	1	33-22-11 355/288/L014	ALL
L00460A		BV03112N03-25 LT ASSY SOCKET-FWD ENTRY	417N5113 17023	2	33-22-11 355/288/L014	001-099
L00460A		BV03112N03-25 LT ASSY SOCKET-FWD ENTRY	417N5113 17023	2	33-22-11 0359/293/L008	115-199

EQUIPMENT LIST

D280N032

Section L00400

Page 9

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00461		5108WW LT-FWD GALLEY	417N5111 08805	1	33-27-11 347/289/R019	001-099
L00461		5108WW LT-FWD GALLEY	417N5111 08805	1	33-27-11 355/288/L014	115-199
L00461A		BV03300-23 LT ASSY SOCKET-FWD GALLEY	417N5111 17023	2	33-27-11 0347/289/R019	ALL
L00462		5108WW LT-FWD GALLEY	417N5111 08805	1	33-27-11 347/289/R019	ALL
L00462A		BV03300-23 LT ASSY SOCKET-FWD GALLEY	417N5111 17023	2	33-27-11 0347/289/R019	ALL
L00463		5108WW LT-FWD GALLEY	417N5111 08805	1	33-27-11 347/289/R019	ALL
L00463A		BV03300-23 LT ASSY SOCKET-FWD GALLEY	417N5111 17023	2	33-27-11 0347/289/R019	ALL
L00464		5108WW LT-FWD GALLEY	417N5111 08805	1	33-27-11 347/289/R019	ALL
L00464A		BV03300-23 LT ASSY SOCKET-FWD GALLEY	417N5111 17023	2	33-27-11 0347/289/R019	ALL
L00465		F15T8WW-PROVISIONS- LT-MID GALLEY	417N5114 08805	1	33-27-21 710/289/R025	ALL
L00465A		BV03112N03-25-PROVISIONS- LT ASSY SOCKET-MID GALLEY	417N5114 17023	2	33-27-21 710/289/R025	ALL
L00466		F15T8WW-PROVISIONS- LT-MID GALLEY	417N5114 08805	1	33-27-21 710/289/R025	ALL
L00466A		BV03112N03-25-PROVISIONS- LT ASSY SOCKET-MID GALLEY	417N5114 17023	2	33-27-21 710/289/R025	ALL
L00467		F15T8WW-PROVISIONS- LT-MID GALLEY	417N5114 08805	1	33-27-21 710/289/R025	ALL
L00467A		BV03112N03-25-PROVISIONS- LT ASSY SOCKET-MID GALLEY	417N5114 17023	2	33-27-21 710/289/R025	ALL
L00468		F15T8WW-PROVISIONS- LT-MID GALLEY	417N5114 08805	1	33-27-21 710/289/R025	ALL
L00468A		BV03112N03-25-PROVISIONS- LT ASSY SOCKET-MID GALLEY	417N5114 17023	2	33-27-21 710/289/R025	ALL

EQUIPMENT LIST

D280N032

Section L00400

Page 10

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00469		F40WW LT-AFT GALLEY	417N5112 08805	1	33-27-31 1668/294/R005	ALL
L00469A		BV03112N40 LT ASSY SOCKET-AFT GALLEY	417N5112 17023	2	33-27-31 1668/294/R005	ALL
L00470		F40WW LT-AFT GALLEY	417N5112 08805	1	33-27-31 1668/294/R005	ALL
L00470A		BV03112N40 LT ASSY SOCKET-AFT GALLEY	417N5112 17023	2	33-27-31 1668/294/R005	ALL
L00471		S231T300-227 LT-ANNUN IND,FLIGHT MANAGEMENT COMPUTER	233N2221 81205	1	34-61-15 P001-03/ /	ALL
L00472		15-0093-5 LT-NO.3 CARGO DR	453N4221 72914	1	33-37-21 1570/193/R063	115-199
L00472 T		1665 LAMP-	453N4210 24455	1	33-37-21 1570/193/R063	115-199
L00474		S231T300-1264 LT-L OIL PRESS	233N2221 81205	1	79-33-11 P001-03/ /	ALL
L00475		S231T300-1265 LT-R OIL PRESS	233N2221 81205	1	79-33-11 P001-03/ /	ALL
L00476		F15T8WW-PROVISIONS- LT-MID GALLEY,LEFT	417N5114 08805	1	33-27-22 717/289/L032	115-199
L00476A		BV03112N03-25-PROVISIONS- LT ASSY SOCKET-MID GALLEY	417N5114 17023	2	33-27-22 717/289/L032	115-199
L00477		F15T8WW-PROVISIONS- LT-MID GALLEY,LEFT	417N5114 08805	1	33-27-22 717/289/L032	115-199
L00477A		BV03112N03-25-PROVISIONS- LT ASSY SOCKET-MID GALLEY	417N5114 17023	2	33-27-22 717/289/L032	115-199
L00478		F15T8WW-PROVISIONS- LT-MID GALLEY,LEFT	417N5114 08805	1	33-27-22 717/289/L032	115-199
L00478A		BV03112N03-25-PROVISIONS- LT ASSY SOCKET-MID GALLEY	417N5114 17023	2	33-27-22 717/289/L032	115-199
L00479		F15T8WW-PROVISIONS- LT-MID GALLEY,LEFT	417N5114 08805	1	33-27-22 717/289/L032	115-199
L00479A		BV03112N03-25-PROVISIONS- LT ASSY SOCKET-MID GALLEY	417N5114 17023	2	33-27-22 717/289/L032	ALL

EQUIPMENT LIST

D280N032

Section L00400

Page 11

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00480		S417N502-3 LT-THRESHOLD,FWD LAV F	411N3210 81205	1	33-26-31 392/288/L014	115-199
L00480 T		1251 LAMP-THRESHOLD,FWD LAV F	S417N502 08806	1	33-26-31 0392/288/L014	115-199
L00482		S233T100-013 LT PLATE-LH CLOCK/LIGHT CONT PNL	233N2101 81205	1	33-13-41 P007-00/ /	ALL
L00483		S233T100-014 LT PLATE-RH CLOCK/LIGHT CONT PNL	233N2101 81205	1	33-13-41 P007-00/ /	ALL
L00485		S231T300-224 LT-ALTITUDE ALERT	233N8200 81205	1	34-16-11 P001-03/ /	ALL
L00486		S231T300-1225 LT-A/T DISC	233N2221 81205	1	22-34-11 P001-03/ /	ALL
L00487		15-0143-29 LT-HYDRAULIC SERVICE CENTER	284N1483 72914	1	33-31-21 1194/147/L062	ALL
L00487 T		2233 LAMP-	284N1483 24455	1	33-31-21 1194/147/L062	ALL
L00488		15-0143-29 LT-HYDRAULIC SERVICE CENTER	284N1483 72914	1	33-31-21 1226/147/L062	ALL
L00488 T		2233 LAMP-	284N1483 24455	1	33-31-21 1226/147/L062	ALL
L00489		A-8985-10 LT-NOSE GEAR DOOR UNSAFE	284N1763 72914	1	32-12-12 263/155/C000	ALL
L00490		A-8985-10 LT-MAIN GEAR DOOR UNSAFE,R	284N1839 72914	1	32-12-12 1111/126/R006	ALL
L00491		S231T300-1257 LT-BRAKE SOURCE	233N2222 81205	1	32-41-11 P001-03/ /	ALL
L00495		S233T100-5504 LT PLATE-STAB TRIM CONT	254N1112 81205	1	33-13-51 P010-00/*/	ALL
L00497		S233T100-509 LT PLATE-FLAP POSN SELECTOR	254N1112 81205	1	33-13-51 P010-00/*/	ALL
L00498		S233T100-510 LT PLATE-SPDBRK POSN SELECTOR	254N1112 81205	1	33-13-51 P010-00/*/	ALL
L00499		S233T100-508 LT PLATE-FUEL CONT	254N1112 81205	1	33-13-51 P010-00/*/	ALL

EQUIPMENT LIST

D280N032

Section L00400
Page 12 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00504	1	15-0188-11 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 530/201/L015	ALL
L00504	2	BR7203-701 LT-FWD CARGO COMPT	453N4110 17023	1	33-37-11 530/201/L015	ALL
L00504	3	15-0188-7 LT-FWD CARGO COMPT	453N4110 72914	1	33-37-11 530/201/L015	ALL
L00504 T		3011 LAMP-	453N4110 08806	1	33-37-11 530/201/L015	ALL
L00505		A-8985-10 LT-MAIN GEAR DOOR UNSAFE,L	284N1839 72914	1	32-12-12 1105/140/L010	ALL
L00516		S417N503-7-PROVISIONS- LT-AFT ATTENDANT SIGN	417N5159 81205	1	33-24-23 1694/280/R008	009
L00516		S417N503-7 LT-AFT ATTENDANT SIGN	417N5159 81205	1	33-24-23 1684/279/R008	115-199
L00516 T		387 LAMP-AFT ATTENDANT SIGN	S417N503 08806	5	33-24-23 1684/279/R008	115-199
L00518		S417N502-2 LT-ATTENDANT WORK,AFT LEFT	411N3210 81205	1	33-22-14 1650/288/L024	ALL
L00518 T		1308 LAMP-ATTENDANT WORK LT,AFT LEFT	S417N502 S5006	1	33-22-14 1659/288/L029	001-099
L00518 T		1308 LAMP-ATTENDANT WORK LT,AFT LEFT	S417N502 S5006	1	33-22-14 1650/288/L024	115-199
L00519		855320-8-387 LT-FWD LAV CALL	411N3210 08717	1	33-25-11 350/288/L005	001-099
L00519		855320-8-387 LT-FWD LAV CALL	411N3270 08717	1	33-25-11 350/288/L005	115-199
L00520		855320-3-387 LT-FWD PASS CALL	411N3210 08717	1	33-25-11 350/288/L005	001-099
L00520		855320-3-387 LT-FWD PASS CALL	411N3270 08717	1	33-25-11 350/288/L005	115-199
L00521		S417N502-3-PROVISIONS- LT-GALLEY WALL THRESHOLD,G2A	411N3250 81205	1	33-26-31 0662/293/R007	115-199
L00521 T		1251-PROVISIONS- LAMP-GALLEY WALL THRESHOLD,G2A	S417N502 08806	1	33-26-31 0662/293/R007	115-199

EQUIPMENT LIST

D280N032

Section L00500

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00522		S417N502-3-PROVISIONS- LT-GALLEY WALL THRESHOLD,G2B	411N3250 81205	1	33-26-31 0747/293/R007	115-199
L00522 T		1251-PROVISIONS- LAMP-GALLEY WALL THRESHOLD,G2B	S417N502 08806	1	33-26-31 0747/293/R007	115-199
L00523		S417N502-3-PROVISIONS- LT-GALLEY WALL THRESHOLD,G2D	411N3250 81205	1	33-26-31 747/293/L007	115-199
L00523 T		1251-PROVISIONS- LAMP-GALLEY WALL THRESHOLD,G2D	S417N502 08806	1	33-26-31 747/293/L007	115-199
L00531		S417N502-2 LT-ATTENDANT WORK,AFT RIGHT	411N3210 81205	1	33-22-14 1650/288/R024	001-099
L00531		S417N502-2 LT-ATTENDANT WORK,AFT RIGHT	411N3210 81205	1	33-22-14 1660/288/R018	115-199
L00531 T		1308 LAMP-ATTENDANT WORK,AFT RIGHT	S417N502 S5006	1	33-22-14 1650/288/R024	001-099
L00531 T		1308 LAMP-ATTENDANT WORK,AFT RIGHT	S417N502 S5006	1	33-22-14 1659/288/R029	115-199
L00532		S417N503-7 LT-MID FWD ATTENDANT SIGN,R	417N5159 81205	1	33-24-21 737/277/R037	115-199
L00532 T		387 LAMP-MID FWD ATTENDANT SIGN,R	S417N503 08806	5	33-24-21 0737/277/R037	115-199
L00533		69B41965-1 LT-FLOOD AUXILLIARY CIRCUIT BREAKER PNL	232N5011 81205	1	33-11-61 P061-00/ /	ALL
L00533 T		1864 LAMP-	232N5011 24455	1	33-11-61 P061-00/ /	ALL
L00535A		S417N302-1 LT-PASS READ	417N3100 81205	1	33-23-31 MULTI/ /	115-199
L00535B		S417N302-1 LT-PASS READ	417N3100 81205	1	33-23-31 MULTI/ /	115-199
L00535C		S417N302-1 LT-PASS READ	417N3100 81205	1	33-23-31 MULTI/ /	115-199
L00536		S417N503-7 LT-MID FWD PASS INFO SIGN	417N5159 81205	1	33-24-12 0683/277/L037	115-199
L00536 T		387 LAMP-MID FWD PASS INFO SIGN	S417N503 08806	5	33-24-12 0683/277/L037	115-199

EQUIPMENT LIST

D280N032

Section L00500

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00540		15-0143-29 LT-APU COMPARTMENT	284N1481 72914	1	33-31-31 1886/224/L016	ALL
L00540 T		2233 LAMP-	284N1481 24455	1	33-31-31 1886/224/L016	ALL
L00541		15-0143-29 LT-APU COMPARTMENT	284N1481 72914	1	33-31-31 1907/235/L035	ALL
L00541 T		2233 LAMP-	284N1481 24455	1	33-31-31 1907/235/L035	ALL
L00542		S233T100-5018 LT PLATE-RESERVE BRAKES	233N2221 81205	1	33-13-12 P001-03/ /	ALL
L00546		S417N503-10 LT-MID FWD ATTENDANT SIGN,R	417N5159 81205	1	33-24-21 0683/277/R037	001-099
L00546		S417N503-7 LT-MID FWD ATTENDANT SIGN,R	417N5159 81205	1	33-24-21 0683/277/R037	115-199
L00546 T		387 LAMP-MID FWD ATTENDANT SIGN,R	S417N503 08806	5	33-24-21 0683/277/R037	115-199
L00547		S417N503-10 LT-AFT ATTENDANT SIGN,R	417N5159 81205	1	33-24-23 1684/276/R045	001-099
L00547 T		387 LAMP-AFT ATTENDANT SIGN,R	S417N503 08806	5	33-24-23 1684/276/R045	001-008, 010-099
L00547 T		387-PROVISIONS- LAMP-AFT ATTENDANT SIGN,R	S417N503 08806	5	33-24-23 1684/276/R045	009
L00548		S417N503-10 LT-AFT ATTEND SIGN,L	417N5159 81205	1	33-24-23 1684/276/L045	001-008, 010-099
L00548		S417N503-10-PROVISIONS- LT-AFT ATTEND SIGN,L	417N5159 81205	1	33-24-23 1684/276/L045	009
L00548 T		387 LAMP-AFT ATTENDANT SIGN,L	S417N503 08806	5	33-24-23 1684/276/L045	001-008, 010-099
L00548 T		387-PROVISIONS- LAMP-AFT ATTENDANT SIGN,L	S417N503 08806	5	33-24-23 1684/276/L045	009
L00574		S233T100-5027 LT PLT-HEADING REFERENCE SWITCH	233N2222 81205	1	33-13-12 P003-01/ /	ALL
L00575		34265-8 LT-UTILITY,FIRST OBSERVER	232N5003 72914	1	33-14-31 0292/266/L027	ALL

EQUIPMENT LIST

D280N032

Section L00500

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00575 T		1864 LAMP-	232N5003 24455	1	33-14-31 0292/266/L027	ALL
L00586		S417N502-3 LT-THRESHOLD,MID FWD LAV S	411N3210 81205	1	33-26-31 0657/290/L019	001-099
L00586 T		1251 LAMP-THRESHOLD,MID FWD LAV S	S417N502 08806	1	33-26-31 0657/290/L019	001-099

EQUIPMENT LIST

D280N032

Section L00500
Page 4 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00616		S417N506-2015 LT-LAVATORIES SIGN	417N5159 81205	1	33-26-21 1316/291/L012	115-199
L00616 T		387 LAMP-LAVATORY SIGN	417N506 08806	5	33-26-21 1316/291/L012	115-199
L00617		S417N506-2016 LT-OCCUPIED SIGN	417N5159 81205	1	33-26-21 1315/291/L012	115-199
L00617 T		387 LAMP-OCCUPIED SIGN	417N506 08806	5	33-26-21 1315/291/L012	115-199
L00629		S417N510-1 LT-EXIT INDICATOR DR 1 R	417N5210 81205	1	33-51-21 325/216/R065	ALL
L00629 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 325/216/R065	ALL
L00630		S417N510-1 LT-EXIT INDICATOR DR 1 L	417N5210 81205	1	33-51-21 336/216/L065	ALL
L00630 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 336/216/L065	ALL
L00631		S417N510-1 LT-EXIT INDICATOR DR 2 R	417N5210 81205	1	33-51-21 732/216/R065	ALL
L00631 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 732/216/R065	ALL
L00632		S417N510-1 LT-EXIT INDICATOR DR 2 L	417N5210 81205	1	33-51-21 688/216/L065	ALL
L00632 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-21 688/216/L065	ALL
L00637		S417N510-1 LT-EXIT INDICATOR DR 4 R	417N5210 81205	1	33-51-22 1684/216/R068	001-008, 010-099, 115-199
L00637		S417N510-1-PROVISIONS- LT-EXIT INDICATOR DR 4 R	417N5210 81205	1	33-51-22 1684/216/R068	009
L00637 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-22 1684/216/R068	001-008, 010-099, 115-199
L00637 T		OL-3071BPEGPL-PROVISIONS- LAMP-	S417N510 S3774	5	33-51-22 1684/216/R068	009
L00638		S417N510-1 LT-EXIT INDICATOR DR 4 L	417N5210 81205	1	33-51-22 1684/216/L068	001-008, 010-099, 115-199

EQUIPMENT LIST

D280N032

Section L00600

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00638		S417N510-1-PROVISIONS- LT-EXIT INDICATOR DR 4 L	417N5210 81205	1	33-51-22 1684/229/L068	009
L00638 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-22 1684/216/L068	001-008, 010-099, 115-199
L00638 T		OL-3071BPEGPL-PROVISIONS- LAMP-	S417N510 S3774	5	33-51-22 1684/216/L068	009
L00639		S417N510-1 LT-EXIT INDICATOR DR 3 R	417N5210 81205	1	33-51-22 1350/239/R065	ALL
L00639 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-22 1355/216/R065	ALL
L00640		S417N510-1 LT-EXIT INDICATOR DR 3 L	417N5210 81205	1	33-51-22 1320/239/L065	ALL
L00640 T		OL-3071BPEGPL LAMP-	S417N510 S3774	5	33-51-22 1315/216/L065	ALL
L00641		S417N506-2017 LT-LAVATORIES SIGN	417N5159 81205	1	33-26-21 1315/291/R018	115-199
L00641 T		387 LAMP-LAVATORY SIGN	417N506 08806	5	33-26-21 1315/291/R018	115-199
L00642		S417N506-2018 LT-OCCUPIED SIGN	417N5159 81205	1	33-26-21 1315/290/R018	115-199
L00642 T		387 LAMP-OCCUPIED SIGN	417N506 08806	5	33-26-21 1315/290/R018	115-199
L00643		S417N506-2 LT-LAVATORY OCCUPIED SIGN	417N5159 81205	1	33-26-21 0412/288/L001	115-199
L00643 T		387 LAMP-LAVATORY OCCUPIED SIGN	S417N506 08806	7	33-26-21 0412/288/L001	115-199
L00649		S231T300-2308 LT-WINDSHEAR	233N2221 81205	1	34-46-11 P001-03/ /	ALL

EQUIPMENT LIST

D280N032

Section L00600

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00716		S231T300-1300 LT-SPEED BRAKE	233N2221 81205	1	31-51-43 P001-03/ /	ALL

EQUIPMENT LIST

D280N032

Section L00700

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00815		S231T100-569 LT-PILOT ALT STAB TRIM	254N1112 81205	1	33-13-51 P010-00/ /	ALL
L00827		S417N506-2001 LT-LAVATORY SIGN	417N5159 81205	1	33-26-21 6832/72/L035	001-099
L00828		S417N506-2002 LT-OCCUPIED SIGN	417N5159 81205	1	33-26-21 6832/72/L035	001-099
L00829		S417N506-2037 LT-OCCUPIED SIGN	417N5159 81205	1	33-26-21 6832/72/L035	001-099
L00830		S417N506-2036 LT-OCCUPIED SIGN	417N5159 81205	1	33-26-21 6832/72/L035	001-099

EQUIPMENT LIST

D280N032

Section L00800
Page 1 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01065		S417N504-1 LT-EMERGENCY AISLE	412N1168 81205	18	33-51-11 MULTI/ /	ALL
L01065 T		1317 LAMP-	S417N504 08806	18	33-51-11 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section L01000

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00001		233T3232-9 PNL-APU CONTROL(SEE YRD++++)	233N3101 81205	1	49-61-11 P005-00/ /	001-099
M00013	1	S210T160-62 PNL-CABIN ALTITUDE CONT	233N3101 81205	1	21-31-11 P005-00/ /	001-008, 115-199
M00013	1	S210T160-72 PNL-CABIN ALTITUDE CONT	233N3101 81205	1	21-31-11 P005-00/ /	009-099
M00013	2	S210T160-42 PNL-CABIN ALTITUDE CONT	233N3101 81205	1	21-31-11 P005-00/ /	ALL
M00019		S231N210-14 PNL-CABIN PRESSURIZATION	233N3101 81205	1	21-33-11 P005-00/ /	001-099
M00019		S231N210-15 PNL-CABIN PRESSURIZATION	233N3101 81205	1	21-33-11 P005-00/ /	115-199
M00033		233N7508-7 PNL-FLIGHT RECORDER/SERVICE INTERPHONE	233N7401 81205	1	31-31-01 P061-00/ /	001-099
M00043		233T3210-28 PNL-EMER LIGHTS/PASS OXY(SEE YBI++++)	233N3101 81205	1	33-51-11 P005-00/ /	001-099
M00043		233T3210-30 PNL-EMER LIGHTS/PASS OXY(SEE YBI++++)	233N3101 81205	1	33-51-11 P005-00/ /	115-199
M00050		93-A152-50 PNL-VOICE RECORDER	233N3101 06141	1	23-71-11 P005-00/ /	001, 009
M00050		980-6109-017 PNL-VOICE RECORDER	233N3101 97896	1	23-71-11 P005-00/ /	002-008, 010-099
M00050		93-A152-60 PNL-VOICE RECORDER	233N3101 06141	1	23-71-11 P005-00/ /	115-199
M00051		285T0024-27 PNL-PILOTS CALL	233N3101 81205	1	23-42-11 P005-00/ /	001-099
M00051		285T0024-25 PNL-PILOTS CALL	233N3101 81205	1	23-42-11 P005-00/ /	115-199
M00052		233T3216-10 PNL-PASS SIGN(SEE YNQ++++)	233N3101 81205	1	33-24-11 P005-00/ /	ALL
M00056		233T3217-40 PNL-ANTI-COLLISION & LANDING LTS CONT	233N3101 81205	1	33-44-11 P005-00/ /	001-099
M00059	1	S242T101-203 PNL-INERTIAL REFERENCE SYSTEM	233N3101 81205	1	34-21-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section M00000

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00059	1	S242T101-204 PNL-INERTIAL REFERENCE SYSTEM	233N3101 81205	1	34-21-11 P005-00/ /	115-199
M00059	2	S242T101-202 PNL-INERTIAL REFERENCE SYSTEM	233N3101 81205	1	34-21-11 P005-00/ /	115-199
M00070		285T0022-43 PNL-AUDIO SEL,CAPTAIN	233N6101 81205	1	23-51-11 P008-00/ /	001-008, 010-099
M00070		285T0022-41 PNL-AUDIO SEL,CAPTAIN	233N6101 81205	1	23-51-11 P008-00/ /	009
M00070		285T0022-44 PNL-AUDIO SEL,CAPTAIN	233N6101 81205	1	23-51-11 P008-00/ /	115-199
M00071		285T0022-43 SEL PNL-AUDIO,F/O	233N6101 81205	1	23-51-21 P008-00/ /	001-008, 010-099
M00071		285T0022-41 SEL PNL-AUDIO,F/O	233N6101 81205	1	23-51-21 P008-00/ /	009
M00071		285T0022-44 SEL PNL-AUDIO,F/O	233N6101 81205	1	23-51-21 P008-00/ /	115-199
M00073		254N1106-30 CONT MDL-FUEL(SEE YQS++++)(RR)	254N1008 81205	1	28-22-21 P010-00/ /	001-002, 115-199
M00073		254N1106-34 CONT MDL-FUEL(SEE YQS++++)(RR)	254N1008 81205	1	28-22-21 P010-00/ /	003-099
M00074		233T6201-21 CONT PNL-AILERON & RUDDER TRIM SEE YAR	233N6101 81205	1	27-11-11 P008-00/ /	ALL
M00075	9	2041223-0418 CONT PNL-WEATHER RADAR (SB 34-0394)	233N6101 27914	1	34-43-12 P008-00/ /	115-199
M00075		622-5129-108 CONT PNL-WEATHER RADAR	233N6101 13499	1	34-43-12 P008-00/ /	001-008, 010-099
M00075		2041223-0402 CONT PNL-WEATHER RADAR	233N6101 27914	1	34-43-12 P008-00/ /	009
M00075		S220T109-401 CONT PNL-WEATHER RADAR	233N6101 81205	1	34-43-12 P008-00/ /	115-199
M00076	9	S242T102-161 CONT DISP UNIT-FMCS, L (SB 34-0427)	233N6101 81205	1	34-61-11 P009-00/ /	001
M00076	9	S242T102-161 CONT DISP UNIT-FMCS, L (34-0414)	233N6101 81205	1	34-61-11 P009-00/ /	115-199

EQUIPMENT LIST

D280N032

Section M00000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00076		S242T102-103 CONT DISP UNIT-FLT MGMT COMPUTER,L	233N6101 81205	1	34-61-11 P009-00/ /	ALL
M00077	9	S242T102-161 CONT DISP UNIT-FMCS, R (SB 34-0427)	233N6101 81205	1	34-61-21 P009-00/ /	001
M00077	9	S242T102-161 CONT DISP UNIT-FMCS, R (34-0414)	233N6101 81205	1	34-61-21 P009-00/ /	115-199
M00077		S242T102-103 CONT DISP UNIT-FLT MGMT COMPUTER,R	233N6101 81205	1	34-61-21 P009-00/ /	ALL
M00078		622-6831-002 CONT PNL-VHF COMM,L	233N6101 13499	1	23-12-11 P008-00/ /	001-008, 010-099
M00078		G6317 CONT PNL-VHF COMM,L	233N6101 99837	1	23-12-11 P008-00/ /	009
M00078		G-6317-04 CONT PNL-VHF COMM,L	233N6101 99837	1	23-12-11 P008-00/ /	115-199
M00079		622-6831-002 CONT PNL-VHF COMM,R	233N6101 13499	1	23-12-21 P008-00/ /	001-008, 010-099
M00079		G-6317 CONT PNL-VERY HIGH FREQUENCY COMM,R	233N6101 99837	1	23-12-21 P008-00/ /	009
M00079		G-6317-04 CONT PNL-VERY HIGH FREQUENCY COMM,R	233N6101 99837	1	23-12-21 P008-00/ /	115-199
M00080		622-6831-002 CONT PNL-VERY HIGH FREQUENCY COMM,C	233N6101 13499	1	23-12-31 P008-00/ /	001-008, 010-099
M00082		622-6827-002 CONT PNL-HIGH FREQUENCY COMMUNICATION,L	233N3101 13499	1	23-11-11 P005-00/ /	001-099
M00082	1	622-5432-002 CONT PNL-HIGH FREQUENCY COMMUNICATION,L	233N3101 13499	1	23-11-11 P005-00/ /	115-199
M00082	2	622-6827-002 CONT PNL-HIGH FREQUENCY COMMUNICATION,L	233N3101 13499	1	23-11-11 P005-00/ /	115-199
M00083		622-6827-002 CONT PNL-HIGH FREQUENCY COMMUNICATION,R	233N3101 13499	1	23-11-21 P005-00/ /	001-099
M00087		285T0553-4 CONT PNL-INSTRUMENT LANDING SYSTEM	233N6101 81205	1	34-31-11 P008-00/ /	ALL
M00090	9	S241T100-211 PNL-MODE CONT,AUTO FLT CONT SYS(SB22A49)	233N2101 81205	1	22-11-12 P055-00/ /	001-099

EQUIPMENT LIST

D280N032

Section M00000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00090	9	S241T100-252 PNL-MODE CONT,AUTO FLT CONT SYS(SB22A49)	233N2101 81205	1	22-11-12 P055-00/ /	115-199
M00090		S241T100-202 PNL-MODE CONT,AUTO FLT CONT SYSTEM	233N2101 81205	1	22-11-12 P055-00/ /	001-099
M00090		S241T100-251 PNL-MODE CONT,AUTO FLT CONT SYSTEM	233N2101 81205	1	22-11-12 P055-00/ /	115-199
M00091		285T0554-5 CONT PNL-VOR,LEFT	233N2101 81205	1	34-51-11 P055-00/ /	001-099
M00091	1	285T0554-5 CONT PNL-VOR,LEFT	233N2101 81205	1	34-51-11 P055-00/ /	ALL
M00091	2	285T0554-3 CONT PNL-VOR,LEFT	233N2101 81205	1	34-51-11 P055-00/ /	115-199
M00092		285T0554-5 CONT PNL-VOR,RIGHT	233N2101 81205	1	34-51-21 P055-00/ /	001-099
M00092	1	285T0554-5 CONT PNL-VOR,RIGHT	233N2101 81205	1	34-51-21 P055-00/ /	ALL
M00092	2	285T0554-3 CONT PNL-VOR,RIGHT	233N2101 81205	1	34-51-21 P055-00/ /	115-199
M00093		S242T404-341 CONT PNL-EFIS,F/O	233N6101 81205	1	34-22-24 P010-00/ /	001-099
M00093		S242T404-344 CONT PNL-EFIS,F/O	233N6101 81205	1	34-22-24 P010-00/ /	115-199
M00094		S242T404-341 CONT PNL-EFIS,CAPT	233N6101 81205	1	34-22-14 P010-00/ /	001-099
M00094		S242T404-344 CONT PNL-EFIS,CAPT	233N6101 81205	1	34-22-14 P010-00/ /	115-199
M00098		285T0022-43 PNL-AUDIO SELECTOR,OBSERVER	233N7101 81205	1	23-51-41 P017-00/ /	001-008, 010-099
M00098		285T0022-41 PNL-AUDIO SELECTOR,OBSERVER	233N7101 81205	1	23-51-41 P017-00/ /	009
M00098		285T0022-44 PNL-AUDIO SELECTOR,OBSERVER	233N7101 81205	1	23-51-41 P017-00/ /	115-199

EQUIPMENT LIST

D280N032

Section M00000

Page 4 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00100		S242T210-206 COMPUTER-AIR DATA,LEFT	284N1800 81205	1	34-12-11 E002-01/ /	ALL
M00101		S242T210-206 COMPUTER-AIR DATA,RIGHT	284N1800 81205	1	34-12-21 E002-02/ /	ALL
M00102		S283T001-18 CONT UNIT-ANTISKID/AUTOBRAKE	284N1725 81205	1	32-42-11 E005-02/ /	001-099
M00102		S283T001-18 CONT UNIT-ANTISKID/AUTOBRAKE	284N1725 81205	1	32-42-11 E006-02/ /	115-199
M00108		285T0001-69 ACCESSORY UNIT-AUDIO	284N1800 81205	1	23-31-11 E004-03/ /	001-099
M00108		285T0001-57 ACCESSORY UNIT-AUDIO	284N1800 81205	1	23-31-11 E004-03/ /	115-199
M00115		S283T002-1 UNIT-MONITOR,BRAKE TEMP	284N1564 81205	1	32-46-11 E006-04/ /	115-199
M00116	1	S281T001-23 CONT UNIT-BUS POWER	284N1800 81205	1	24-41-11 E005-03/ /	ALL
M00116	2	S281T001-15 CONT UNIT-BUS POWER	284N1800 81205	1	24-41-11 E005-03/ /	ALL
M00118		S210T160-43 CONT UNIT-CABIN PRESSURE,AUTO,1	284N1800 81205	1	21-31-11 E005-01/ /	001-002, 115-199
M00118		S210T160-63 CONT UNIT-CABIN PRESSURE,AUTO,1	284N1800 81205	1	21-31-11 E005-01/ /	003-099
M00119		S210T160-43 CONT UNIT-CABIN PRESSURE,AUTO 2	284N1352 81205	1	21-31-21 E005-02/ /	001-002, 115-199
M00119		S210T160-63 CONT UNIT-CABIN PRESSURE,AUTO 2	284N1352 81205	1	21-31-21 E005-02/ /	003-099
M00121		S345N001-030 UNIT-FUEL QUANTITY PROCESSOR	284N1800 81205	1	28-41-11 E003-04/ /	001-002, 115-199
M00121		S345N001-031 UNIT-FUEL QUANTITY PROCESSOR	284N1800 81205	1	28-41-11 E003-04/ /	003-009
M00122		S271T455-15 UNIT-HYD QUANTITY MONITOR	284N1534 81205	1	29-33-11 E003-04/ /	001-009
M00122		S271T455-19 UNIT-HYD QUANTITY MONITOR	284N1534 81205	1	29-33-11 E003-04/ /	010-099

EQUIPMENT LIST

D280N032

Section M00100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00122		S271T455-15 UNIT-HYD QUANTITY MONITOR	284N1562 81205	1	29-33-11 E006-04/ /	115-199
M00123		2041167-3703 INTERROGATOR-DISTANT MEASURING EQPT,L	284N1800 27914	1	34-55-11 E003-03/ /	001, 009
M00123		622-4540-001 INTERROGATOR-DISTANT MEASURING EQPT,L	284N1800 13499	1	34-55-11 E003-03/ /	002-008, 010-099
M00123		2041167-3704 INTERROGATOR-DISTANT MEASURING EQPT,L	284N1800 27914	1	34-55-11 E003-03/ /	115-199
M00124		2041167-3703 INTERROGATOR-DISTANT MEASURING EQPT,R	284N1800 27914	1	34-55-21 E003-02/ /	001, 009
M00124		622-4540-001 INTERROGATOR-DISTANT MEASURING EQPT,R	284N1800 13499	1	34-55-21 E003-02/ /	002-008, 010-099
M00124		2041167-3704 INTERROGATOR-DISTANT MEASURING EQPT,R	284N1800 27914	1	34-55-21 E003-02/ /	115-199
M00126		S210T130-69 CONTROLLER-PACK TEMPERATURE,LEFT	284N1471 81205	1	21-51-12 E003-03/ /	001-099
M00126		S210T130-69 CONTROLLER-PACK TEMPERATURE,LEFT	284N1686 81205	1	21-51-12 E006-02/ /	115-199
M00126	1	S210T130-66 CONTROLLER-PACK TEMPERATURE,LEFT	284N1471 81205	1	21-51-12 E003-03/ /	001-099
M00126	1	S210T130-66 CONTROLLER-PACK TEMPERATURE,LEFT	284N1686 81205	1	21-51-12 E006-02/ /	115-199
M00127		S210T130-69 CONTROLLER-PACK TEMPERATURE,RIGHT	284N1725 81205	1	21-51-22 E003-02/*/	001-099
M00127		S210T130-69 CONTROLLER-PACK TEMPERATURE,RIGHT	284N1686 81205	1	21-51-22 E006-02/*/	115-199
M00127	1	S210T130-66 CONTROLLER-PACK TEMPERATURE,RIGHT	284N1725 81205	1	21-51-22 E003-02/*/	001-099
M00130		RD-AX7002-01 TAPE REPRODUCER	284N1800 0FF57	1	23-34-11 E004-04/ /	ALL
M00132		S360N021-451 UNIT-MONITOR,ENGINE VIBRATION	284N1800 81205	1	77-31-11 E004-02/ /	ALL
M00134	9	S242T102-331 CMPTR-FLT MGMT, L	SB340154 81205	1	34-61-11 E002-01/ /	001-002, 004-099

EQUIPMENT LIST

D280N032

Section M00100

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00134	9	S242T102-455 COMPUTER-FLIGHT MGMT, LEFT (SB 34-0301)	SB340154 81205	1	34-61-11 E002-01/ /	003
M00134	9	S242T102-455 CMPTR-FLT MGMT, L (SB 34-0379 R01)	233N2220 81205	1	34-61-11 E002-01/ /	115-199
M00134	8	S242T102-331 COMPUTER-FLIGHT MANAGEMENT,LEFT	SB340154 81205	1	34-61-11 E002-01/ /	003
M00134	8	S242T102-331 CMPTR-FLT MGMT, L (SB 34-0154)	233N2220 81205	1	34-61-11 E002-01/ /	115-199
M00134		S242T102-329 COMPUTER-FLIGHT MANAGEMENT,LEFT	233N2220 81205	1	34-61-11 E002-01/ /	ALL
M00135	9	S242T102-331 COMPUTER-FLIGHT MANAGEMENT,RIGHT	SB340154 81205	1	34-61-21 E002-02/ /	001-002, 004-099
M00135	9	S242T102-455 COMPUTER-FLIGHT MGMT, RIGHT (SB 34-0301)	SB340154 81205	1	34-61-21 E002-02/ /	003
M00135	9	S242T102-455 COMPUTER-FLT MGMT,R (SB 34-0379 R01)	233N2220 81205	1	34-61-21 E002-02/ /	115-199
M00135	8	S242T102-331 COMPUTER-FLIGHT MANAGEMENT,RIGHT	SB340154 81205	1	34-61-21 E002-02/ /	003
M00135	8	S242T102-331 COMPUTER-FLT MGMT,R (SB 34-0154)	233N2220 81205	1	34-61-21 E002-02/ /	115-199
M00135		S242T102-329 COMPUTER-FLIGHT MANAGEMENT,RIGHT	233N2223 81205	1	34-61-21 E002-02/ /	ALL
M00138	9	967-0212-002 DGTL FLT DATA ACQUISITION (SB 31-0094)	284N1800 97896	1	31-31-01 E003-03/ /	010-099
M00138		2233000-4A UNIT-DIGITAL FLIGHT DATA ACQUISITION	284N1800 98571	1	31-31-01 E003-03/ /	001-099
M00138		2227000-5 UNIT-DIGITAL FLIGHT DATA ACQUISITION	284N1800 98571	1	31-31-01 E003-03/ /	115-199
M00139	9	S241T100-151 CMPUTR-FLIGHT CONTROL,LEFT (SB 22-0073)	284N1800 81205	1	22-11-11 E002-01/ /	115-199
M00139		S241T100-109 COMPUTER-FLIGHT CONTROL,LEFT	284N1800 81205	1	22-11-11 E002-01/ /	ALL
M00140	9	S241T100-151 CMPTR-FLIGHT CONTROL,CENTER (SB 22-0073)	284N1800 81205	1	22-11-31 E002-03/ /	115-199

EQUIPMENT LIST

D280N032

Section M00100

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00140		S241T100-109 COMPUTER-FLIGHT CONTROL,CENTER	284N1800 81205	1	22-11-31 E002-03/ /	ALL
M00141	9	S241T100-151 CMPTR-FLIGHT CONTROL,RIGHT (SB 22-0073)	284N1800 81205	1	22-11-21 E002-02/ /	115-199
M00141		S241T100-109 COMPUTER-FLIGHT CONTROL,RIGHT	284N1800 81205	1	22-11-21 E002-02/ /	ALL
M00142		60B50012-6 AIR COMPRESSOR-POTABLE WATER	417N2601 81205	1	38-15-11 1670/204/R038	ALL
M00143		S281T001-32 CONT UNIT-GENERATOR,APU	284N1353 81205	1	24-21-41 E005-01/ /	ALL
M00144		S281T001-32 CONT UNIT-GENERATOR,L	284N1351 81205	1	24-11-11 E005-01/ /	ALL
M00146		S281T001-32 CONT UNIT-GENERATOR,R	284N1352 81205	1	24-11-21 E005-02/ /	ALL
M00147		S220T102-206 COMPUTER-GROUND PROXIMITY	284N1800 81205	1	34-46-11 E002-03/ /	001-005, 115-199
M00147		S220T102-209 COMPUTER-GROUND PROXIMITY	284N1800 81205	1	34-46-11 E002-03/ /	006-099
M00148		S242T404-420 SYMBOL GEN-ELEX FLT INSTR SYS,LEFT	284N2101 81205	1	34-22-14 E002-01/ /	001-002, 115-199
M00148		S242T404-421 SYMBOL GEN-ELEX FLT INSTR SYS,LEFT	284N1800 81205	1	34-22-14 E002-01/ /	003-099
M00149		S242T404-420 SYMBOL GEN-ELEX FLT INSTR SYS,CENTER	284N1800 81205	1	34-22-34 E002-03/ /	001-002, 115-199
M00149		S242T404-421 SYMBOL GEN-ELEX FLT INSTR SYS,CENTER	284N1800 81205	1	34-22-34 E002-03/ /	003-099
M00150		S242T404-420 SYMBOL GEN-ELEX FLT INSTR SYS,RIGHT	284N1800 81205	1	34-22-24 E002-02/ /	001-002, 115-199
M00150		S242T404-421 SYMBOL GEN-ELEX FLT INSTR SYS,RIGHT	284N1800 81205	1	34-22-24 E002-02/ /	003-099
M00152		622-5272-001 XCVR-HIGH FREQUENCY COMM,L	284N1800 13499	1	23-11-11 E004-03/ /	001-099
M00156		2041230-3517 RCVR-INSTRUMENT LANDING SYS,LEFT	284N1800 27914	1	34-31-11 E002-03/ /	001, 009

EQUIPMENT LIST

D280N032

Section M00100

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00156		622-5221-102 RCVR-INSTRUMENT LANDING SYS,LEFT	284N1800 13499	1	34-31-11 E002-03/ /	002-008, 010-099
M00157		2041230-3517 RCVR-INSTRUMENT LANDING SYS,CENTER	284N1800 27914	1	34-31-31 E002-03/ /	001, 009
M00157		622-5221-102 RCVR-INSTRUMENT LANDING SYS,CENTER	284N1800 13499	1	34-31-31 E002-03/ /	002-008, 010-099
M00158		2041230-3517 RCVR-INSTRUMENT LANDING SYS,RIGHT	284N1800 27914	1	34-31-21 E002-02/ /	001, 009
M00158	1	622-5220-102 RCVR-INSTRUMENT LANDING SYS,RIGHT	284N1800 4V792	1	34-31-21 E002-02/ /	002-008, 010-099
M00159		S242T101-107 UNIT-INERTIAL REFERENCE,LEFT	284N1800 81205	1	34-21-11 E002-04/ /	001-099
M00159	1	S242T101-105 UNIT-INERTIAL REFERENCE,LEFT	284N1800 81205	1	34-21-11 E002-04/ /	115-199
M00159	2	S242T101-106 UNIT-INERTIAL REFERENCE,LEFT	284N1800 81205	1	34-21-11 E002-04/ /	115-199
M00160		S242T101-107 UNIT-INERTIAL REFERENCE,CENTER	284N1800 81205	1	34-21-31 E002-04/ /	001-099
M00160	1	S242T101-105 UNIT-INERTIAL REFERENCE,CENTER	284N1800 81205	1	34-21-31 E002-04/ /	115-199
M00160	2	S242T101-106 UNIT-INERTIAL REFERENCE,CENTER	284N1800 81205	1	34-21-31 E002-04/ /	115-199
M00161		S242T101-107 UNIT-INERTIAL REFERENCE,RIGHT	284N1800 81205	1	34-21-21 E002-04/ /	001-099
M00161	1	S242T101-105 UNIT-INERTIAL REFERENCE,RIGHT	284N1800 81205	1	34-21-21 E002-04/ /	115-199
M00161	2	S242T101-106 UNIT-INERTIAL REFERENCE,RIGHT	284N1800 81205	1	34-21-21 E002-04/ /	115-199
M00162		S283T006-24 ELEX UNIT-PROX SW	284N1800 81205	1	32-09-11 E003-04/ /	ALL
M00168	9	S241T100-305 PNL-MAINT CONTROL & DSPL (SB 34-0427)	284N1800 81205	1	22-41-11 E003-02/ /	001
M00168		S241T100-305 PNL-MAINTENANCE CONTROL & DSPL	284N1800 81205	1	22-41-11 E003-02/ /	ALL

EQUIPMENT LIST

D280N032

Section M00100

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00177		622-5342-101 AMPL-LEFT PASS ADDRESS	284N1800 13499	1	23-31-11 E004-03/ /	001-099
M00177	1	622-5342-001 AMPL-PASS ADDRESS	284N1800 13499	1	23-31-11 E004-03/ /	115-199
M00177	2	256-4 AMPL-PASS ADDRESS	284N1800 16340	1	23-31-11 E004-03/ /	115-199
M00180		NA138-714A DCDR-SELCAL	284N1800 89507	1	23-21-11 E004-03/ /	001-099
M00180		NA138-714A DCDR-SELCAL	284N1800 89507	1	23-21-11 E004-03/*/	115-199
M00183		S241T200-414 COMPUTER-THRUST MANAGEMENT	284N1800 81205	1	22-31-11 E002-03/ /	ALL
M00186		2041231-3608 RCVR-VOR/MKR,L	284N1460 27914	1	34-51-11 E003-02/*/	001, 009
M00186		622-5220-103 RCVR-VOR/MKR,L	284N1460 4V792	1	34-51-11 E003-02/*/	002-008, 010-099
M00186	1	2041231-3608 RCVR-VOR/MKR,L	284N1686 27914	1	34-51-11 E006-01/*/	115-199
M00186	2	2041231-3609 RCVR-VOR/MKR,L	284N1686 27914	1	34-51-11 E006-01/*/	115-199
M00187		2041231-3608 RCVR-VOR/MKR,R	284N1460 27914	1	34-51-21 E003-02/*/	001, 009
M00187		622-5220-103 RCVR-VOR/MKR,R	284N1460 4V792	1	34-51-21 E003-02/*/	002-008, 010-099
M00187	1	2041231-3608 RCVR-VOR/MKR,R	284N1686 27914	1	34-51-21 E006-01/ /	115-199
M00187	2	2041231-3609 RCVR-VOR/MKR,R	284N1686 27914	1	34-51-21 E006-01/ /	115-199
M00188		622-5219-004 XCVR-VHF COMM,L	284N1800 13499	1	23-12-11 E004-03/*/	001-008, 010-099
M00188		2041237-4411 XCVR-VHF COMM,L	284N1800 27914	1	23-12-11 E004-03/ /	009
M00188		2041237-4412 XCVR-VHF COMM,L	284N1800 27914	1	23-12-11 E004-03/ /	115-199

EQUIPMENT LIST

D280N032

Section M00100

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00189		622-5219-004 XCVR-VHF COMM,R	284N1800 13499	1	23-12-21 E004-03/ /	001-008, 010-099
M00189		2041237-4411 XCVR-VHF COMM,R	284N1307 27914	1	23-12-21 E004-03/ /	009
M00189		2041237-4412 XCVR-VHF COMM,R	284N1800 27914	1	23-12-21 E004-03/ /	115-199
M00190		622-5219-004 XCVR-VHF COMM,C	284N1800 13499	1	23-12-31 E004-04/ /	001-008, 010-099
M00190		2041237-4417 XCVR-VHF COMM,C	284N1800 27914	1	23-12-31 E004-04/*/	009
M00191		S283T007-5 CONT UNIT-WINDOW HEAT,L	284N1800 81205	1	30-41-11 E001-02/ /	001-099
M00191		S283T007-3 CONT UNIT-WINDOW HEAT,L	284N1800 81205	1	30-41-11 E001-02/ /	115-199
M00192		S283T007-5 CONT UNIT-WINDOW HEAT,R	284N1800 81205	1	30-41-12 E001-01/ /	001-099
M00192		S283T007-3 CONT UNIT-WINDOW HEAT,R	284N1800 81205	1	30-41-12 E001-01/ /	115-199
M00195		S210T130-67 CONT UNIT-ZONE TEMP	284N1563 81205	1	21-61-11 E003-03/*/	001-099
M00195		S210T130-67 CONT UNIT-ZONE TEMP	284N1686 81205	1	21-61-11 E006-02/ /	115-199

EQUIPMENT LIST

D280N032

Section M00100

Page 7 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00200	9	980-4700-042 RCDR-DIGITAL FLIGHT DATA (SB:31-0094)	284N1469 97896	1	31-31-01 1615/295/L005	010-099
M00200		10077A500-107 RCDR-DIGITAL FLIGHT DATA	284N1469 92685	1	31-31-01 1615/295/L005	001-099
M00200		980-4100-DXUN RCDR-DIGITAL FLIGHT DATA	284N1469 97896	1	31-31-01 1615/295/L005	115-199
M00201		93-A100-80 RCDR-VOICE	284N1469 06141	1	23-71-11 1615/290/R005	001
M00201		980-6005-076 RCDR-VOICE	284N1469 97896	1	23-71-11 1615/290/R005	002-008, 010-099
M00201		93-A100-30 RCDR-VOICE	284N1469 06141	1	23-71-11 1615/290/R005	115-199
M00202		622-4542-103 RCVR-XMTR RADIO ALTIMETER,LEFT	284N1800 13499	1	34-33-11 E005-01/ /	001-008, 010-099
M00202		2041166-5203 RCVR-XMTR RADIO ALTIMETER,LEFT	284N1800 13499	1	34-33-11 E005-01/ /	009
M00202		2041166-5204 RCVR-XMTR RADIO ALTIMETER,LEFT	284N1800 81205	1	34-33-11 E005-01/ /	115-199
M00203		622-4542-103 RCVR-XMTR RADIO ALTIMETER,RIGHT	284N1800 13499	1	34-33-21 E005-02/ /	001-008, 010-099
M00203		2041166-5203 RCVR-XMTR RADIO ALTIMETER,RIGHT	284N1800 13499	1	34-33-21 E005-02/ /	009
M00203		2041166-5204 RCVR-XMTR RADIO ALTIMETER,RIGHT	284N1800 81205	1	34-33-21 E005-02/ /	115-199
M00204		622-4542-103 RCVR-XMTR RADIO ALTIMETER,CENTER	284N1800 13499	1	34-33-31 E005-03/ /	001-008, 010-099
M00204		2041166-5203 RCVR-XMTR RADIO ALTIMETER,CENTER	284N1800 13499	1	34-33-31 E005-03/ /	009
M00204		2041166-5204 RCVR-XMTR RADIO ALTIMETER,CENTER	284N1800 81205	1	34-33-31 E005-03/ /	115-199
M00206		S351T020-18 CONT UNIT-AUX POWER	284N1725 81205	1	49-61-11 E006-02/ /	ALL
M00207		S282T002-6 CHGR-APU BAT	284N1471 81205	1	24-31-41 E006-00/ /	001-099

EQUIPMENT LIST

D280N032

Section M00200

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00207		S282T002-4 CHGR-APU BAT	284N1471 81205	1	24-31-41 E006-00/ /	115-199
M00208		S282T002-1 BATTERY-APU	284N1471 81205	1	24-31-41 E006-00/ /	ALL
M00213	9	622-5132-633 RCVR/XMTR-W/R (SB 34-0200)	284N1416 13499	1	34-43-11 0240/170/R020	002
M00213	9	2041217-0416 RCVR/XMTR-W/R (SB 34-0394)	284N1416 27914	1	34-43-11 0240/170/R020	115-199
M00213		622-5132-106 RCVR/XMTR-W/R	284N1416 13499	1	34-43-11 0240/170/R020	001-008, 010-099
M00213		2041217-0415 RCVR/XMTR-W/R	284N1416 27914	1	34-43-11 0240/170/R020	009
M00213	1	622-5132-106 XMTR RCVR-WEATHER RADAR,LEFT	284N1416 13499	1	34-43-11 0240/170/R020	115-199
M00213	2	S220T109-101 XMTR RCVR-WEATHER RADAR,LEFT	284N1416 81205	1	34-43-11 0240/170/R020	115-199
M00213 T		622-5133-005 MOUNT-XMTR RCVR WEATHER RADAR LEFT	284N1416 13499	1	34-43-11 0240/170/R020	001-008, 010-099
M00213 T		2041213-0405 MOUNT-XMTR RCVR WEATHER RADAR LEFT	284N1416 27914	1	34-43-11 0240/170/R020	009
M00213 T		S220T109-601 MOUNT-XMTR RCVR WEATHER RADAR LEFT	284N1416 81205	1	34-43-11 0240/170/R020	115-199
M00215		2041168-7510 RECEIVER-ADF,LEFT	284N1500 27914	1	34-57-11 E006-01/ /	001, 009
M00215		622-5222-102 RECEIVER-ADF,LEFT	284N1500 13499	1	34-57-11 E006-01/ /	002-008, 010-099
M00215		2041168-7512 RECEIVER-ADF,LEFT	284N1725 27914	1	34-57-11 E006-01/ /	115-199
M00216		2041168-7510 RECEIVER-ADF RIGHT	284N1500 27914	1	34-57-21 E006-01/ /	001, 009
M00216		622-5222-102 RECEIVER-ADF,RIGHT	284N1500 13499	1	34-57-21 E006-01/ /	002-008, 010-099
M00216		2041168-7512 RECEIVER-ADF,RIGHT	284N1725 27914	1	34-57-21 E006-01/ /	115-199

EQUIPMENT LIST

D280N032

Section M00200

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00217	9	S282T004-8 STATIC INVERTER-	SB24A069 81205	1	24-33-11 0239/170/L020	001-004
M00217		S282T004-7 STATIC INVERTER-	284N1409 81205	1	24-33-11 0239/170/L020	001-004
M00217		S282T004-8 STATIC INVERTER-	284N1409 81205	1	24-31-11 0239/170/L020	005-099
M00217		S282T004-4 STATIC INVERTER-	284N1409 81205	1	24-33-11 0239/170/L020	115-199
M00218		S282T002-6 CHGR-MAIN BATTERY	284N1409 81205	1	24-31-11 247/170/L020	001-099
M00218		S282T002-4 CHGR-MAIN BATTERY	284N1409 81205	1	24-31-11 247/170/L020	115-199
M00223		S282T002-1 BATTERY-MAIN	284N1411 81205	1	24-31-11 247/150/R025	ALL
M00224		MS91586-7 SHUNT-MAIN BATT	284N1411 96906	1	24-31-11 247/152/35	ALL
M00225		S281T003-1 ELCU-GALLEY PWR,MID FWD,R	284N1315 81205	1	25-31-21 P032-00/ /R035	115-199
M00227		S281T003-1 ELCU-GALLEY PWR,AFT,L	284N1314 81205	1	25-31-33 P031-00/ /	ALL
M00229		S253T409-1 SERVOMOTOR-A/T,GENERATOR,LEFT	253T7121 81205	1	22-31-11 218/200/R010	ALL
M00231		S270T200-5 PUMP-ELEC HYDRAULIC,L	271N1058 81205	1	29-11-12 1065/160/L063	ALL
M00234		S270T200-5 PUMP-ELEC HYDRAULIC,R	271N1058 81205	1	29-11-22 1070/168/54	001-099
M00234		S270T200-5 PUMP-ELEC HYDRAULIC,R	271N1058 81205	1	29-11-22 1065/160/R063	115-199
M00237		S232T601-65 MOTOR-WINDSHIELD WIPER,L	232N6001 81205	1	30-42-11 P001-03/ /	ALL
M00238		S232T601-66 MOTOR-WINDSHIELD WIPER,R	232N6101 81205	1	30-42-11 0205/222/R003	ALL
M00239		S274T401-4 MODULE-HYDRAULIC AUTOBRAKE(SEE YAA)	274N1001 81205	1	32-42-12 1040/173/L051	ALL

EQUIPMENT LIST

D280N032

Section M00200

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00239	1	S272T401-3 MODULE-HYDRAULIC AUTOBRAKE(SEE YAA)	274N1001 81205	1	32-42-12 1040/173/L051	ALL
M00240		C-07202-2 STICK SHAKER-LEFT	251N1019 73326	1	27-32-11 */*/	ALL
M00241		792-6140-001 ANTENNA COUPLER-HF COMM,L	284N1704 13499	1	23-11-11 FIN225/FS/	ALL
M00242		792-6140-001 ANTENNA COUPLER-HF COMM,R	284N1704 13499	1	23-11-21 FIN225/FS/	ALL
M00243		DMN27-2 ANTENNA-MKR BCN	284N1349 85226	1	34-32-11 650/148/	ALL
M00244		174T1103-2 ANTENNA-HF COMM	170N0001 81205	1	23-11-11 F195*/FS	ALL
M00245		DMC50-17 ANTENNA-VHF COMM,L	284N1345 85226	1	23-12-11 753/305/L005	ALL
M00246		DMC50-17 ANTENNA-VHF COMM,R	284N1345 85226	1	23-12-21 730/150/	ALL
M00247		DMC50-17 ANTENNA-VHF COMM,C	284N1345 85226	1	23-12-31 1473*/	001-099
M00248		60B00024-2 ANTENNA-DUAL LOCALIZER,LEFT & RIGHT	284N1414 81205	1	34-31-11 0200/173/	ALL
M00249		60B00024-2 ANTENNA-DUAL LOCALIZER,CTR	284N1414 81205	1	34-31-31 0200/209/C000	ALL
M00250		S41422 ANTENNA-DUAL G/S,LEFT & RIGHT	284N1414 13691	1	34-31-11 0198/165/	ALL
M00251		S41422 ANTENNA-DUAL G/S,CTR	284N1414 13691	1	34-31-31 0198/169/	ALL
M00252	1	S220T112-101 ANTENNA-XMTR RADIO ALTIMETER,LEFT	284N1348 81205	1	34-33-11 570/148/L012	115-199
M00252	2	S220T112-102 ANTENNA-XMTR RADIO ALTIMETER,LEFT	284N1348 81205	1	34-33-11 570/148/L012	115-199
M00253	1	S220T112-101 ANTENNA-RCVR RADIO ALTIMETER,LEFT	284N1348 81205	1	34-33-11 0610/148/L012	115-199
M00253	2	S220T112-102 ANTENNA-RCVR RADIO ALTIMETER,LEFT	284N1348 81205	1	34-33-11 0610/148/L012	ALL

EQUIPMENT LIST

D280N032

Section M00200

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00254		S220T112-102 ANTENNA-XMTR RADIO ALTIMETER,RIGHT	284N1348 81205	1	34-33-21 0570/148/R012	001-099
M00254	1	S220T112-101 ANTENNA-XMTR RADIO ALTIMETER,RIGHT	284N1348 81205	1	34-33-21 0570/148/R012	115-199
M00255	1	S220T112-101 ANTENNA-RCVR RADIO ALTIMETER,RIGHT	284N1348 81205	1	34-33-21 0610/148/R012	ALL
M00255	2	S220T112-102 ANTENNA-RCVR RADIO ALTIMETER,RIGHT	284N1348 81205	1	34-33-21 0610/148/R012	ALL
M00256	1	S220T112-101 ANTENNA-XMTR RADIO ALTIMETER,CENTER	284N1348 81205	1	34-33-31 0570/148/	115-199
M00256	2	S220T112-102 ANTENNA-XMTR RADIO ALTIMETER,CENTER	284N1348 81205	1	34-33-31 0570/148/	115-199
M00257		S220T112-102 ANTENNA-RCVR RADIO ALTIMETER,CENTER	284N1348 81205	1	34-33-31 0610/148/	ALL
M00257	1	S220T112-101 ANTENNA-RCVR RADIO ALTIMETER,CENTER	284N1348 81205	1	34-33-31 0610/148/	115-199
M00262		S220T114-101 ANTENNA-VOR	284N1703 81205	1	34-51-11 FIN400/FS/	ALL
M00263		S220T116-1 ANTENNA-DME,LEFT	284N1346 81205	1	34-55-11 630/150/	ALL
M00264		S220T116-1 ANTENNA-DME,RIGHT	284N1346 81205	1	34-55-21 690/148/L012	ALL
M00265		2041683-7504 ANTENNA-ADF,LEFT	284N1448 27914	1	34-57-11 1116/307/L005	001, 009, 115-199
M00265		622-5404-003 ANTENNA-ADF,LEFT	284N1448 4V792	1	34-57-11 1116/307/L005	002-008, 010-099
M00266		2041683-7504 ANTENNA-ADF,RIGHT	284N1448 27914	1	34-57-21 1156/307/L005	001, 009, 115-199
M00266		622-5404-003 ANTENNA-ADF,RIGHT	284N1448 13499	1	34-57-21 1156/307/L005	002-008, 010-099
M00269		622-5137-001 ANTENNA-FLAT PLATE - WXR	284N1415	1	34-43-11 199/200/	001-008, 010-099
M00269		2041446-0401 ANTENNA-FLAT PLATE - WXR	284N1415 27914	1	34-43-11 199/200/	009

EQUIPMENT LIST

D280N032

Section M00200

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00269		S220T109-202 ANTENNA-FLAT PLATE	284N1415 81205	1	34-43-11 199/200/	115-199
M00269 T		622-5135-002 MOUNT-ANTENNA,WEATHER RADAR	284N1415	1	34-43-11 199/200/	001-008, 010-099
M00269 T		2041444-0401 MOUNT-ANTENNA,WEATHER RADAR	284N1415 27914	1	34-43-11 199/200/	009
M00269 T		S220T109-701 MOUNT-ANTENNA,WEATHER RADAR	284N1415 81205	1	34-43-11 199/200/	115-199
M00271		251N2814-1 SERVO-A/P PITCH CONTROL,LEFT	251N2003 81205	1	22-11-11 1864/251/R002	ALL
M00272		S251N212-2 SERVO-A/P PITCH CONTROL,CENTER	251N2002 81205	1	22-11-31 1863/245/R002	ALL
M00273		S251N212-2 SERVO-A/P PITCH CONTROL,RIGHT	251N2003 81205	1	22-11-21 1856/230/R020	ALL
M00277		S251N312-1 SERVO-A/P ROLLOUT GUIDANCE,LEFT	251N3003 81205	1	22-11-11 FIN90/RS/	ALL
M00278		S251N312-1 SERVO-A/P ROLLOUT GUIDANCE,CENTER	251N3003 81205	1	22-11-31 FIN90/RS/	ALL
M00279		S251N312-1 SERVO-A/P ROLLOUT GUIDANCE,RIGHT	251N3003 81205	1	22-11-21 FIN90/RS/	ALL
M00281		S281T001-37 GEN-AUXILIARY POWER UNIT	351N1101 81205	1	24-21-41 APU/ /	ALL

EQUIPMENT LIST

D280N032

Section M00200

Page 6 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00306	9	S251N111-6A PCU ASSY-OUTBD SPOILER 1 (SB 27A0105)	SB27A0105 81205	1	27-61-13 WS610/ /LRS	001-002
M00306	9	S251N111-6A PWR CONT UNIT ASSY-OUTBD SPOILER 1	SB27A105 81205	1	27-61-13 WS610/ /LRS	115-199
M00306		S251N111-6 PWR CONT UNIT ASSY-OUTBD SPOILER 1	251N1003 81205	1	27-61-13 WS610/ /LRS	ALL
M00307	9	S251N111-6A PCU ASSY-OUTBD SPOILER 2 (SB 27A0105)	SB27A0105 81205	1	27-61-14 WS546/ /LRS	001-002
M00307	9	S251N111-6A PWR CONT UNIT ASSY-OUTBD SPOILER 2	SB27A105 81205	1	27-61-14 WS546/ /LRS	115-199
M00307		S251N111-6 PWR CONT UNIT ASSY-OUTBD SPOILER 2	S251N100 81205	1	27-61-14 WS546/ /LRS	ALL
M00308	9	S251N111-6A PCU ASSY-OUTBD SPOILER 3 (SB 27A0105)	SB27A0105 81205	1	27-61-15 WS480/ /LRS	001-002
M00308	9	S251N111-6A PWR CONT UNIT ASSY-OUTBD SPOILER 3	SB27A105 81205	1	27-61-15 WS480/ /LRS	115-199
M00308		S251N111-6 PWR CONT UNIT ASSY-OUTBD SPOILER 3	S251N100 81205	1	27-61-15 WS480/ /LRS	ALL
M00309	9	S251N111-6A PCU ASSY-OUTBD SPOILER 4 (SB S7A0105)	SB27A0105 81205	1	27-61-16 WS415/ /LRS	001-002
M00309	9	S251N111-6A PWR CONT UNIT ASSY-OUTBD SPOILER 4	SB27A105 81205	1	27-61-16 WS415/ /LRS	115-199
M00309		S251N111-6 PWR CONT UNIT ASSY-OUTBD SPOILER 4	S251N100 81205	1	27-61-16 WS415/ /LRS	ALL
M00310	9	S251N111-6A PCU ASSY-INBD SPOILER 5 (SB 27A0105)	SB27A0105 81205	1	27-61-17 WS346/ /LRS	001-002
M00310	9	S251N111-6A PWR CONT UNIT ASSY-INBD SPOILER 5	SB27A105 81205	0	27-61-17 */*/	115-199
M00310		S251N111-6 PWR CONT UNIT ASSY-INBD SPOILER 5	251N1003 81205	1	27-61-17 WS346/ /LRS	ALL
M00311	9	S251N118-7A PCU ASSY-INBD SPOILER 6 (SB 27A0105)	SB27A0105 81205	1	27-61-18 IRSS290/ /	001-002
M00311	9	S251N118-7A PWR CONT UNIT ASSY-INBD SPOILER 6	SB27A105 81205	1	27-61-18 IRSS290/ /	115-199

EQUIPMENT LIST

D280N032

Section M00300

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00311		S251N118-7 PWR CONT UNIT ASSY-INBD SPOILER 6	251N1016 81205	1	27-61-18 IRSS290/ /	ALL
M00312	9	S251N118-7A PCU ASSY-INBD SPOILER 7 (SB 27A0105)	SB27A0105 81205	1	27-61-18 IRSS290/ /	001-002
M00312	9	S251N118-7A PWR CONT UNIT ASSY-INBD SPOILER 7	SB27A105 81205	1	27-61-18 IRSS290/ /	115-199
M00312		S251N118-7 PWR CONT UNIT ASSY-INBD SPOILER 7	251N1016 81205	1	27-61-18 IRSS290/ /	ALL
M00313	9	S251N111-6A PCU ASSY-INBD SPOILER 8 (SB 27A0105)	SB27A0105 81205	1	27-61-17 IRSS347/ /RRS	001-002
M00313	9	S251N111-6A PWR CONT UNIT ASSY-INBD SPOILER 8	SB27A105 81205	1	27-61-17 IRSS347/ /RRS	115-199
M00313		S251N111-6 PWR CONT UNIT ASSY-INBD SPOILER 8	251N1003 81205	1	27-61-17 IRSS347/ /RRS	ALL
M00314	9	S251N111-6A PCU ASSY-OUTBD SPOILER 9 (SB 27A0105)	SB27A0105 81205	1	27-61-16 WS415/ /RRS	001-002
M00314	9	S251N111-6A PWR CONT UNIT ASSY-OUTBD SPOILER 9	SB27A105 81205	1	27-61-16 WS415/ /RRS	115-199
M00314		S251N111-6 PWR CONT UNIT ASSY-OUTBD SPOILER 9	S251N100 81205	1	27-61-16 WS415/ /RRS	ALL
M00315	9	S251N111-6A PCU ASSY-OUTBD SPOILER 10 (SB 27A0105)	SB27A0105 81205	1	27-61-15 WS478/ /RRS	001-002
M00315	9	S251N111-6A PWR CONT UNIT ASSY-OUTBD SPOILER 10	SB27A105 81205	1	27-61-15 WS478/ /RRS	115-199
M00315		S251N111-6 PWR CONT UNIT ASSY-OUTBD SPOILER 10	S251N100 81205	1	27-61-15 WS478/ /RRS	ALL
M00316	9	S251N111-6A PCU ASSY-OUTBD SPOILER 11 (SB 27A0105)	SB27A0105 81205	1	27-61-14 WS545/ /RRS	001-002
M00316	9	S251N111-6A PWR CONT UNIT ASSY-OUTBD SPOILER 11	SB27A105 81205	1	27-61-14 WS545/ /RRS	115-199
M00316		S251N111-6 PWR CONT UNIT ASSY-OUTBD SPOILER 11	S251N100 81205	1	27-61-14 WS545/ /RRS	ALL
M00317	9	S251N111-6A PCU ASSY-OUTBD SPOILER 12 (SB 27A0105)	SB27A0105 81205	1	27-61-13 WS610/ /RRS	001-002

EQUIPMENT LIST

D280N032

Section M00300

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00317	9	S251N111-6A PWR CONT UNIT ASSY-OUTBD SPOILER 12	SB27A105 81205	1	27-61-13 WS610/ /RRS	115-199
M00317		S251N111-6 PWR CONT UNIT ASSY-OUTBD SPOILER 12	251N1003 81205	1	27-61-13 WS610/ /RRS	ALL
M00320		S210T130-40 ACTR-RAM AIR EXHAUST DOOR,LEFT	213N3011 81205	1	21-51-12 1049/140/L040	ALL
M00321		S210T130-40 ACTR-RAM AIR EXIT,RIGHT PACK	213N3011 81205	1	21-51-22 1049/140/R041	ALL
M00322		S210T130-40 ACTR-RAM AIR INLET DOOR,LEFT	213N3001 81205	1	21-51-12 885/151/L044	ALL
M00323		S210T130-40 ACTR-RAM AIR INLET,RIGHT PACK	213N3001 81205	1	21-51-22 0885/144/R029	ALL
M00332		60B92404-6 PUMP-FUEL BOOST,L FWD	343N3301 81205	1	28-22-11 ISS173/ /LLE	ALL
M00333		60B92404-6 PUMP-FUEL BOOST,L AFT	343N3301 81205	1	28-22-11 IRSS182/ /LRS	ALL
M00334		60B92404-6 PUMP-FUEL BOOST,R FWD	343N3301 81205	1	28-22-11 ISS173/ /RLE	ALL
M00335		60B92404-6 PUMP-FUEL BOOST,R AFT	343N3301 81205	1	28-22-11 IRSS182/ /RRS	ALL
M00336		60B92403-10 PUMP-FUEL,DC	346N3001 81205	1	28-25-11 1050/180/L051	ALL
M00338		S271T455-3 XMTR-HYD SYS QTY,L	271N3001 81205	1	29-33-11 1052/188/L050	ALL
M00339		S271T455-8 XMTR-HYD SYS QTY,CTR	271N3002 81205	1	29-33-11 1197/140/L060	ALL
M00340		S271T455-3 XMTR-HYD SYS QTY,R	271N3007 81205	1	29-33-11 1051/172/R043	ALL
M00341		S271T451-1 XMTR-HYD SYS PRESS,L	271N5006 81205	1	29-31-11 1070/170/L005	ALL
M00342		S271T451-1 XMTR-HYD SYS PRESS,CTR	271N5007 81205	1	29-31-11 1090/ /L004	ALL
M00343		S271T451-1 XMTR-HYD SYS PRESS,R	271N5008 81205	1	29-31-11 1180/172/R001	ALL

EQUIPMENT LIST

D280N032

Section M00300

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00406		S353T010-5 ACTR-APU INLET DOOR	353N1001 81205	1	49-61-14 1797/280/R015	ALL
M00488		60B80030-4 ACTR-TRIM,AILERON	25N1008 81205	1	27-11-11 1045/170/L020	ALL
M00499		10167-4001BT MDL-TIME DELAY,ELEC HYD PUMP L ON	284N1318 08719	1	29-11-12 P033-00/ /	ALL
M00499 T		MS25171-1S NIPPLE	96906	2	29-11-12 P33/ /	ALL

EQUIPMENT LIST

D280N032

Section M00400
Page 1 End
Dec 18/2007

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00500		10167-5001BT MDL-TIME DELAY,ELEC HYD PUMP R ON	284N1125 08719	1	29-11-22 P036-00/ /	ALL
M00500 T		MS25171-1S NIPPLE	96906	2	29-11-22 P36/ /	ALL
M00505		S233T810-14 CU-FLOOD LTS,CAPT & CTR PNLS	233N2400 81205	1	33-11-11 P003-01/ /	001, 115-199
M00505		S233T810-20 CU-FLOOD LTS,CAPT & CTR PNLS	233N2400 81205	1	33-11-11 P003-01/ /	002-099
M00506		S233T810-14 CU-FLOOD LTS, FIRST OFFICER PNL	233N2400 81205	1	33-11-11 P003-01/ /	001, 115-199
M00506		S233T810-20 CU-FLOOD LTS,FIRST OFFICER PNL	233N2400 81205	1	33-11-11 P003-01/ /	002-099
M00509	1	S252T704-11 SERVO LEFT - YAW DAMPER (APL LH SIDE)	251N3004 81205	1	22-21-11 FIN135/RS/	ALL
M00509	2	S251N313 SERVO LEFT - YAW DAMPER (APL LH SIDE)	251N3004 81205	1	22-21-11 FIN135/RS/	ALL
M00510	1	S252T704-11 SERVO RIGHT - YAW DAMPER (APL RH SIDE)	251N3004 81205	1	22-21-21 FIN135/RS/	ALL
M00510	2	S251N313 SERVO RIGHT - YAW DAMPER (APL RH SIDE)	251N3004 81205	1	22-21-21 FIN135/RS/	ALL
M00515		S251T320-2 ACTR-RUDDER TRIM	251N3006 81205	1	27-21-11 FIN106/RS/	ALL
M00516	1	S250N104-4 XMTR-RUDDER POSITION	251N3009 81205	1	27-28-11 FIN145/RS/	ALL
M00516	2	S250N104-1 XMTR-RUDDER POSITION	251N3009 81205	1	27-28-11 FIN145/RS/	ALL
M00516	3	60B40042-3 XMTR-RUDDER POSITION	251N3009 81205	1	27-28-11 FIN145/RS/	ALL
M00517	1	S250N104-4 XMTR-ELEVATOR POSITION,L INBD	251N2009 81205	1	27-38-11 ELEV77/RS/	ALL
M00517	2	S250N104-1 XMTR-ELEVATOR POSITION,L INBD	251N2009 81205	1	27-38-11 ELEV77/RS/	ALL
M00517	3	60B40042-3 XMTR-ELEVATOR POSITION,L INBD	251N2009 81205	1	27-38-11 ELEV77/RS/	ALL

EQUIPMENT LIST

D280N032

Section M00500

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00518	1	S250N104-4 XMTR-ELEVATOR POSITION,R INBD	251N2009 81205	1	27-38-11 ELEV77/RS/	ALL
M00518	2	S250N104-1 XMTR-ELEVATOR POSITION,R INBD	251N2009 81205	1	27-38-11 ELEV77/RS/	ALL
M00518	3	60B40042-3 XMTR-ELEVATOR POSITION,R INBD	251N2009 81205	1	27-38-11 ELEV77/RS/	ALL
M00519		S251T440-103 MODULE-POSITION TRANSMITTER,LEFT	251N2020 81205	1	27-48-21 1777/185/L025	ALL
M00520		S251T440-103 MODULE-POSITION TRANSMITTER,RIGHT	251N2020 81205	1	27-48-21 1777/190/R030	ALL
M00521		S251T440-103 MODULE-POSITION TRANSMITTER,CENTER	251N2020 81205	1	27-48-21 1777/190/R025	ALL
M00522	9	285T0013-110 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	ALL
M00522	8	285T0013-108 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	ALL
M00522	7	285T0013-110 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	ALL
M00522	6	285T0013-108 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	001-002, 115-199
M00522	6	285T0013-106 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	003-099
M00522	5	285T0013-106 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	001-002, 115-199
M00522	5	285T0013-107 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	003-099
M00522	1	285T0013-124 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	001-002, 115-199
M00522	1	285T0013-125 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	003-099
M00522	2	285T0013-123 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	001-002, 115-199
M00522	2	285T0013-124 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	003-099

EQUIPMENT LIST

D280N032

Section M00500

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00522	3	285T0013-109 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	001-002, 115-199
M00522	3	285T0013-123 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	003-099
M00522	4	285T0013-107 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	001-002, 115-199
M00522	4	285T0013-109 MODULE-YAW DAMPER,LEFT	284N1800 81205	1	22-21-11 E003-01/ /	003-099
M00523	9	285T0013-110 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	ALL
M00523	8	285T0013-108 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	ALL
M00523	7	285T0013-110 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	ALL
M00523	6	285T0013-108 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	001-002, 115-199
M00523	6	285T0013-106 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	003-099
M00523	5	285T0013-106 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	001-002, 115-199
M00523	5	285T0013-107 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	003-099
M00523	1	285T0013-124 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	001-002, 115-199
M00523	1	285T0013-125 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	003-099
M00523	2	285T0013-123 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	001-002, 115-199
M00523	2	285T0013-124 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	003-099
M00523	3	285T0013-109 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	001-002, 115-199
M00523	3	285T0013-123 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	003-099

EQUIPMENT LIST

D280N032

Section M00500

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00523	4	285T0013-107 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	001-002, 115-199
M00523	4	285T0013-109 MODULE-YAW DAMPER,RIGHT	284N1800 81205	1	22-21-21 E004-01/ /	003-099
M00524	5	285T0015-107 MODULE-STAB TRIM AND ELEV ASYM LIMIT,L	284N1800 81205	1	22-24-11 E003-01/ /	ALL
M00524	1	285T0015-116 MODULE-STAB TRIM AND ELEV ASYM LIMIT,L	284N1800 81205	1	22-24-11 E003-01/ /	ALL
M00524	2	285T0015-117 MODULE-STAB TRIM AND ELEV ASYM LIMIT,L	284N1800 81205	1	22-24-11 E003-01/ /	ALL
M00524	3	285T0015-114 MODULE-STAB TRIM AND ELEV ASYM LIMIT,L	284N1800 81205	1	22-24-11 E003-01/ /	ALL
M00524	4	285T0015-113 MODULE-STAB TRIM AND ELEV ASYM LIMIT,L	284N1800 81205	1	22-24-11 E003-01/ /	ALL
M00525	5	285T0015-107 MODULE-STAB TRIM AND ELEV ASYM LIMIT,R	284N1800 81205	1	22-24-21 E004-01/ /	ALL
M00525	1	285T0015-116 MODULE-STAB TRIM AND ELEV ASYM LIMIT,R	284N1800 81205	1	22-24-21 E004-01/ /	ALL
M00525	2	285T0015-117 MODULE-STAB TRIM AND ELEV ASYM LIMIT,R	284N1800 81205	1	22-24-21 E004-01/ /	ALL
M00525	3	285T0015-114 MODULE-STAB TRIM AND ELEV ASYM LIMIT,R	284N1800 81205	1	22-24-21 E004-01/ /	ALL
M00525	4	285T0015-113 MODULE-STAB TRIM AND ELEV ASYM LIMIT,R	284N1800 81205	1	22-24-21 E004-01/ /	ALL
M00528	1	285T0014-104 MODULE-RUDDER RATIO CHANGER,LEFT	284N1800 81205	1	27-21-22 E003-01/ /	ALL
M00528	2	285T0014-103 MODULE-RUDDER RATIO CHANGER,LEFT	284N1800 81205	1	27-21-22 E003-01/ /	ALL
M00529	1	285T0014-104 MODULE-RUDDER RATIO CHANGER,RIGHT	284N1800 81205	1	27-21-12 E004-01/ /	ALL
M00529	2	285T0014-103 MODULE-RUDDER RATIO CHANGER,RIGHT	284N1800 81205	1	27-21-12 E004-01/ /	ALL
M00530	1	285T0012-118 CONT MDL-SPOILER,1L	284N1800 81205	1	27-61-13 E003-01/ /	001-002, 115-199

EQUIPMENT LIST

D280N032

Section M00500

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00530	1	285T0012-201 CONT MDL-SPOILER,1L	284N1800 81205	1	27-61-13 E003-01/ /	003-099
M00530	2	285T0012-117 CONT MDL-SPOILER,1L	284N1800 81205	1	27-61-13 E003-01/ /	001-002, 115-199
M00530	2	285T0012-118 CONT MDL-SPOILER,1L	284N1800 81205	1	27-61-13 E003-01/ /	003-099
M00530	3	285T0012-117 CONT MDL-SPOILER,1L	284N1307 81205	1	27-61-13 E003-01/ /	003-099
M00531	1	285T0012-118 CONT MDL-SPOILER,2L	284N1800 81205	1	27-61-17 E003-01/ /	001-002, 115-199
M00531	1	285T0012-201 CONT MDL-SPOILER,2L	284N1800 81205	1	27-61-17 E003-01/ /	003-099
M00531	2	285T0012-117 CONT MDL-SPOILER,2L	284N1800 81205	1	27-61-17 E003-01/ /	001-002, 115-199
M00531	2	285T0012-118 CONT MDL-SPOILER,2L	284N1800 81205	1	27-61-17 E003-01/ /	003-099
M00531	3	285T0012-117 CONT MDL-SPOILER,2L	284N1800 81205	1	27-61-17 E003-01/ /	003-099
M00532	1	285T0012-118 CONT MDL-SPOILER 3L	284N1800 81205	1	27-61-18 E003-01/ /	001-002, 115-199
M00532	1	285T0012-201 CONT MDL-SPOILER 3L	284N1800 81205	1	27-61-18 E003-01/ /	003-099
M00532	2	285T0012-117 CONT MDL-SPOILER 3L	284N1800 81205	1	27-61-18 E003-01/ /	001-002, 115-199
M00532	2	285T0012-118 CONT MDL-SPOILER 3L	284N1800 81205	1	27-61-18 E003-01/ /	003-099
M00532	3	285T0012-117 CONT MDL-SPOILER 3L	284N1800 81205	1	27-61-18 E003-01/ /	003-099
M00533	1	285T0012-118 CONT MDL-SPOILER 1R	284N1800 81205	1	27-61-14 E004-01/ /	001-002, 115-199
M00533	1	285T0012-201 CONT MDL-SPOILER 1R	284N1800 81205	1	27-61-14 E004-01/ /	003-099
M00533	2	285T0012-117 CONT MDL-SPOILER 1R	284N1800 81205	1	27-61-14 E004-01/ /	001-002, 115-199

EQUIPMENT LIST

D280N032

Section M00500

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00533	2	285T0012-118 CONT MDL-SPOILER 1R	284N1800 81205	1	27-61-14 E004-01/ /	003-099
M00533	3	285T0012-117 CONT MDL-SPOILER 1R	284N1800 81205	1	27-61-14 E004-01/ /	003-099
M00534	1	285T0012-118 CONT MDL-SPOILER 2R	284N1800 81205	1	27-61-15 E004-01/ /	001-002, 115-199
M00534	1	285T0012-201 CONT MDL-SPOILER 2R	284N1800 81205	1	27-61-15 E004-01/ /	003-099
M00534	2	285T0012-117 CONT MDL-SPOILER 2R	284N1800 81205	1	27-61-15 E004-01/ /	001-002, 115-199
M00534	2	285T0012-118 CONT MDL-SPOILER 2R	284N1800 81205	1	27-61-15 E004-01/ /	003-099
M00534	3	285T0012-117 CONT MDL-SPOILER 2R	284N1800 81205	1	27-61-15 E004-01/ /	003-099
M00535	1	285T0012-118 CONT MDL-SPOILER 3R	284N1800 81205	1	27-61-16 E004-01/ /	001-002, 115-199
M00535	1	285T0012-201 CONT MDL-SPOILER 3R	284N1800 81205	1	27-61-16 E004-01/ /	003-099
M00535	2	285T0012-117 CONT MDL-SPOILER 3R	284N1800 81205	1	27-61-16 E004-01/ /	001-002, 115-199
M00535	2	285T0012-118 CONT MDL-SPOILER 3R	284N1800 81205	1	27-61-16 E004-01/ /	003-099
M00535	3	285T0012-117 CONT MDL-SPOILER 3R	284N1800 81205	1	27-61-16 E004-01/ /	003-099
M00536		285T0017-104 MODULE-POWER SUPPLY 1L	284N1800 81205	1	27-09-11 E003-01/ /	ALL
M00537		285T0017-104 MODULE-POWER SUPPLY 2L	284N1800 81205	1	27-09-11 E003-01/ /	ALL
M00538		285T0017-104 MODULE-POWER SUPPLY 1R	284N1800 81205	1	27-09-11 E004-01/ /	ALL
M00539		285T0017-104 MODULE-POWER SUPPLY 2R	284N1800 81205	1	27-09-11 E004-01/ /	ALL
M00540		10167-3000BT MODULE-C BUS XFER TIME DELAY	287N4102 08719	1	24-51-31 P006-00/ /	ALL

EQUIPMENT LIST

D280N032

Section M00500

Page 6

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00546		S281T003-1 ELCU-GALLEY PWR G1A	284N1315 81205	1	25-31-11 P032-00/ /	001-099
M00547		S251N406-2 MOTOR-DRIVE,ALT TE FLAPS	251N4052 81205	1	27-51-11 1060/183/L010	ALL
M00570		S283T012-25 PWR SUPPLY-ANTI-COLL LT,UPR	284N1357 81205	1	33-44-11 590/300/R030	ALL
M00571		S283T012-25 PWR SUPPLY-ANTI-COLL LT,LWR	284N1442 81205	1	33-44-11 1030/140/L000	ALL
M00577		S253T402-2 ACTR-AUTO SPEED BRAKE	254N1053 81205	1	27-62-11 P010-00/* /	ALL
M00586		S344N001-3 CONT CARD-FUEL LEVEL SENSOR	284N1327 81205	1	28-21-21 P050-00/ /	ALL
M00588		S283T012-25 PWR SUPPLY-ANTI-COLL LT,L WING	284N1113 81205	1	33-44-21 WS838/ /L	ALL
M00589		S283T012-25 PWR SUPPLY-ANTI-COLL LT,R WING	284N1113 81205	1	33-44-21 WS838/ /R	ALL

EQUIPMENT LIST

D280N032

Section M00500

Page 7 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00609		41SG118-1 XMTR-PRESSURE,AIR SUPPLY DUCT,LEFT	212N3001 02750	1	36-21-11 900/140/L036	115-199
M00610		41SG118-1 XMTR-PRESSURE,AIR SUPPLY DUCT,RIGHT	212N3001 02750	1	36-21-11 900/155/R043	115-199
M00615		285T1104-17 MODULE-STALL WARNING,LEFT	284N1800 81205	1	27-32-11 P051-00/ /	001-002, 115-199
M00615		285T1104-17 MODULE-STALL WARNING,LEFT	284N1307 81205	1	27-32-11 P051-00/ /	003-006
M00615		285T1104-19 MODULE-STALL WARNING,LEFT	284N1307 81205	1	27-32-11 P051-00/ /	007-099
M00616		285T0035-11 MODULE-POWER SUPPLY A	285N0005 81205	1	31-51-11 P051-00/ /	ALL
M00617	9	285T0030-14 MODULE-ALTITUDE ALERT (SB 22-0074 R02)	285N0005 81205	1	34-16-11 P051-00/*/	115-199
M00617	8	285T0030-15 MODULE-ALTITUDE ALERT (SB 22-0074 R01)	285N0005 81205	1	34-16-11 P051-00/*/	115-199
M00617		285T0030-14 MODULE-ALTITUDE ALERT	285N0005 81205	1	34-16-11 P051-00/*/	001-099
M00617		285T0030-17 MODULE-ALTITUDE ALERT	285N0005 81205	1	34-16-11 P051-00/*/	115-199
M00618		285T0032-19 MODULE-MASTER WARNING	285N0005 81205	1	31-51-21 P051-00/ /	ALL
M00619		285T0034-26 MODULE-AURAL WARN SIREN/OWL,RIGHT	285N0005 81205	1	31-51-32 P051-00/ /	ALL
M00620		285T0259-19 MODULE-T/O CONFIGURATION WARNING	285N0005 81205	1	31-51-41 P051-00/ /	001-099
M00620		285T0259-17 MODULE-TO CONFIGURATION WARNING	285N0005 81205	1	31-51-41 P051-00/ /	115-199
M00621		285T0035-11 MODULE-POWER SUPPLY B	285N0005 81205	1	31-51-12 P051-00/ /	ALL
M00626	1	S251T360-105 ACTR-RATIO CHANGER,RUD	251N3005 81205	1	27-21-12 FIN117/ /RS	ALL
M00626	2	S251T360-105 ACTR-RATIO CHANGER,RUD	251N3005 81205	1	27-21-12 FIN117/ /RS	ALL

EQUIPMENT LIST

D280N032

Section M00600

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00626	3	S251T360-103 ACTR-RATIO CHANGER,RUD	251N3005 81205	1	27-21-12 FIN117/ /RS	ALL
M00629		S140T261-6 PDU-NO.1 CARGO DOOR HINGE	143N6605 81205	1	52-34-11 0592/204/R060	ALL
M00631		S140T261-6 PDU-NO.2 CARGO DOOR HINGE	146N6605 81205	1	52-35-11 1420/195/R065	ALL
M00635		4399 UNIT-FLT DECK DOOR LOCK	417N1079 80477	1	52-51-11 308/250/R001	001-008, 115-199
M00635		S232T200-8 UNIT-FLT DECK DOOR LOCK	417N1123 81205	1	52-51-11 308/250/R.35	009-099
M00638		S345N001-020 UNIT-LOAD SELECT CONT	344N5001 81205	1	28-21-22 P028-00/ /	001-099
M00638		S345T002-20 UNIT-LOAD SELECT CONT	344N5001 81205	1	28-21-22 P028-00/ /	115-199
M00681		51653-177 CARD-FIRE DET LEFT,LOOP 1	284N1329 81205	1	26-11-11 P054-00/*/	ALL
M00682		51653-177 CARD-FIRE DET LEFT,LOOP 2	284N1329 81205	1	26-11-11 P054-00/*/	ALL
M00683		51653-177 CARD-FIRE DET RIGHT,LOOP 1	284N1329 81205	1	26-11-21 P054-00/*/	ALL
M00684		51653-177 CARD-FIRE DET RIGHT,LOOP 2	284N1329 81205	1	26-11-21 P054-00/*/	ALL
M00685		51653-177 CARD-FIRE DET,APU,LOOP 1	284N1329 81205	1	26-15-11 P054-00/*/	ALL
M00686		51653-177 CARD-FIRE DET,APU,LOOP 2	284N1329 81205	1	26-15-11 P054-00/*/	ALL
M00691		S283N001-1 CARD-DUCT LEAK AND WHEEL WELL FIRE	280N7101 81205	1	26-18-11 P050-00/ /	ALL

EQUIPMENT LIST

D280N032

Section M00600

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00722		S345T002-153 UNIT-BUSSING PLUG,L TANK	345N2001 81205	1	28-41-21 OSS361/ /	115-199
M00723		S345T002-153 UNIT-BUSSING PLUG,R TANK	345N2001 81205	1	28-41-31 OSS360/ /	115-199
M00726		S345T002-365 ASSEMBLY-HARNESS,L MAIN TANK	345N2001 81205	1	28-41-21 OSS336/ /	115-199
M00727		S345T002-365 ASSEMBLY-HARNESS,R MAIN TANK	345N2001 81205	1	28-41-31 WS349/WRP/RFS	115-199
M00730		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-12 0340/290/L005	001-099
M00730		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-12 0340/288/L005	115-199
M00731		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-12 368/290/L008	ALL
M00732		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-13 0705/287/R046	ALL
M00733		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-13 705/287/L046	ALL
M00734		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-14 1322/272/R049	001-099
M00734		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-14 1324/272/R049	115-199
M00735		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-14 1322/272/L049	001-099
M00735		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-14 1324/272/L049	115-199
M00736		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-15 1678/289/R003	ALL
M00737		S283T014-3 POWER SUPPLY-EMERGENCY LTS	417N5201 81205	1	33-51-15 1678/289/L003	ALL
M00779		S231T301-1104 MODULE-WARNING DISPLAY,DISCRETE	233N2221 81205	1	33-16-11 P001-03/ /	ALL
M00788	1	S283T019-3 CONT UNIT-DIMMER,INSTR & PNL LTS,CAPT	233N2400 81205	1	33-13-11 P001-01/ /	ALL

EQUIPMENT LIST

D280N032

Section M00700

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00788	2	S283T019-2 CONT UNIT-DIMMER,INSTR & PNL LTS,CAPT	233N2400 81205	1	33-13-11 P001-01/ /	ALL
M00789	2	S283T019-3 CONT UNIT-DIMMER,F/O	233N2400 81205	1	33-13-21 P003-03/ /	ALL
M00790	1	S283T019-3 CONT UNIT-DIMMER,PILOTS CTR PNL	233N2400 81205	1	33-13-12 P003-01/ /	ALL
M00790	2	S283T019-2 CONT UNIT-DIMMER,PILOTS CTR PNL	233N2400 81205	1	33-13-12 P003-01/ /	ALL
M00791	1	S283T019-3 CONT UNIT-DIMMER,PILOTS OVHD & PNL LT,L	233N2400 81205	1	33-13-31 P012-00/ /	ALL
M00791	2	S283T019-2 CONT UNIT-DIMMER,PILOTS OVHD & PNL LT,L	233N2400 81205	1	33-13-31 P012-00/ /	ALL
M00792	1	S283T019-3 CONT UNIT-DMR,PILOT OVHD PNL LT,R OUTBD	233N2400 81205	1	33-13-32 P012-00/ /	ALL
M00792	2	S283T019-3 CONT UNIT-DMR,PILOT OVHD PNL LT,R OUTBD	233N2400 81205	1	33-13-32 P012-00/ /	ALL
M00793	1	S283T019-3 CONT UNIT-DMR,GLR SHLD INST & PNL LTS	233N2400 81205	1	33-13-41 P003-01/ /	ALL
M00793	2	S283T019-2 CONT UNIT-DMR,GLR SHLD INST & PNL LTS	233N2400 81205	1	33-13-41 P003-01/ /	ALL
M00794	1	S283T019-3 CONT UNIT-DMR,AISLE STAND INST & PNL LT	287N4134 81205	1	33-13-52 206/199/L006	ALL
M00794	2	S283T019-2 CONT UNIT-DMR,AISLE STAND INST & PNL LT	287N4134 81205	1	33-13-52 206/199/L006	ALL
M00795	1	S283T019-3 CONT UNIT-DMR,AISLE STAND INST & PNL LT	287N4134 81205	1	33-13-51 205/190/R010	ALL
M00795	2	S283T019-2 CONT UNIT-DMR,AISLE STAND INST & PNL LT	287N4134 81205	1	33-13-51 205/190/R010	ALL
M00796	1	S283T019-3 CONT UNIT-DMR,AISLE STAND INST & PNL LT	233N2400 81205	1	33-13-52 0251/202/R002	ALL
M00796	2	S283T019-2 CONT UNIT-DMR,AISLE STAND INST & PNL LT	233N2400 81205	1	33-13-52 0251/202/R002	ALL

EQUIPMENT LIST

D280N032

Section M00700

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00800	1	S283T019-3 DMR CONT UNIT-OVHD CAB PNL LTS	233N2400 81205	1	33-13-61 283/272/L034	ALL
M00800	2	S283T019-2 DMR CONT UNIT-OVHD CAB PNL LTS	233N2400 81205	1	33-13-61 283/272/L034	ALL
M00803	1	S283T019-3 CMR CONT UNIT-OVHD CAB PNL LTS	233N2400 81205	1	33-13-61 283/272/L034	ALL
M00803	2	S283T019-2 DMR CONT UNIT-OVHD CAB PNL LTS	233N2400 81205	1	33-13-61 283/272/L034	ALL
M00804	1	S283T019-3 DMR CONT UNIT-OVHD CAB PNL LTS	233N2400 81205	1	33-13-61 283/174/L028	ALL
M00804	2	S283T019-2 DMR CONT UNIT-OVHD CAB PNL LTS	233N2400 81205	1	33-13-61 283/174/L028	ALL
M00805	1	S283T019-3 DMR CONT UNIT-OVHD CAB PNL LTS	233N2400 81205	1	33-13-61 283/277/L024	ALL
M00805	2	S283T019-2 DMR CONT UNIT-OVHD CAB PNL LTS	233N2400 81205	1	33-13-61 283/277/L024	ALL
M00843	1	S283T019-4 CONT UNIT-DIMMER, GLARE SHIELD FLOOD LTS	233N2400 81205	1	33-11-21 0220/213/R007	ALL
M00843	2	S283T019-4 CONT UNIT-DIMMER, GLARE SHIELD FLOOD LTS	233N2400 81205	1	33-11-21 P003-01/ /	ALL
M00863		285T0093-8 CARD ASSY-PACK FLOW CONT, LEFT	284N1328 81205	1	21-51-11 P050-00/ /	ALL
M00864		285T0093-8 CARD ASSY-PACK FLOW CONT, RIGHT	285N1328 81205	1	21-51-21 P050-00/ /	ALL
M00893		519858 MOTOR-AUXILIARY POWER UNIT STARTER	351T0100 99193	1	49-41-11 APU/ /	ALL

EQUIPMENT LIST

D280N032

Section M00800

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00901		233T7210-6 MODULE-HEATER CAPT AUX(SEE YPF)	233N7101 81205	1	21-45-11 P013-00/ /	ALL
M00902		233T7210-6 MODULE-HEATER FIRST OFFICER AUX(SEE YPG)	233N7101 81205	1	21-45-11 P014-00/ /	ALL
M00916		11199-4 PROCESSOR-PACK FLOW	284N1800 07148	1	21-52-31 E004-02/ /	ALL
M00917		S231T110-103 UNIT-STATIC INVERTER/ILS PROCESSOR	284N1800 81205	1	34-24-11 E002-03/ /	ALL
M00933		MXP147 STOWAGE-OXY MASK,CAPT	232N8001 F0553	1	23-51-11 239/210/L050	ALL
M00934		MXP147 STOWAGE-OXY MASK,F/O	232N8001 F0553	1	23-51-21 ****/*/	ALL
M00937	9	257T1103-15 MODULE-LANDING GEAR LEVER	SB320088 81205	1	32-61-11 P003-01/ /	001, 009
M00937		257T1103-14 MODULE-LANDING GEAR LEVER	233N2222 81205	1	32-61-11 P003-01/ /	ALL
M00938		285T1104-17 MODULE-STALL WARNING,RIGHT	284N1800 81205	1	27-32-21 P051-00/ /	001-002, 115-199
M00938		285T1104-17 MODULE-STALL WARNING,RIGHT	284N1307 81205	1	27-32-21 P051-00/ /	003-006
M00938		285T1104-19 MODULE-STALL WARNING,RIGHT	284N1307 81205	1	27-32-21 P051-00/ /	007-099
M00950		S251T220-2 COMPUTER-ELEVATOR FEEL	251N2036 81205	1	27-31-11 1785/231/R042	ALL
M00952		C-07202-2 STICK SHAKER-RIGHT	251N1019 73326	1	27-32-21 ****/*/	ALL
M00963		10167-3-BT MDL-T/D,AUTO SPOILER WRN	284N1125 08719	1	27-62-11 P036-00/ /	ALL
M00963 T		MS25171-1S NIPPLE	96906	2	27-62-11 P36/ /	ALL
M00966	9	254N1184 ASSY-MICROSWITCH PACK(SEE YRE++++)	SB780032 81205	1	32-42-12 P010-00/ /	001-002, 115-199
M00966		254N1184 ASSY-MICROSWITCH PACK(SEE YRE++++)	254N1058 81205	1	32-42-12 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section M00900

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00968	1	280T1004-8 TEST PLUG	287N4138 81205	1	31-31-11 P061-00/ /	ALL
M00968	2	280T1004-1 TEST PLUG	287N4138 81205	1	31-31-11 P061-00/ /	ALL
M00974		280T1003-1 RCPT-SHORTING,SELCAL	287N4301 81205	1	23-21-12 E004-03/ /	ALL
M00976		280T1003-1 RCPT-SHORTING,FLT RECORDER	287N4301 81205	1	31-31-65 E003-03/ /	ALL
M00977		280T1003-1 RCPT-SHORTING,L ATC XPDR	287N4301 81205	1	34-53-12 E003-03/ /	ALL
M00978		280T1003-1 RCPT-SHORTING,R ATC XPDR	287N4301 81205	1	34-53-21 E003-02/ /	ALL
M00983		285T0031-17 MODULE-LANDING CONFIGURATION WARNING	285N0005 81205	1	31-51-42 P051-00/ /	ALL
M00983	2	285T0031-17 MODULE-LANDING CONFIGURATION WARNING	285N0005 81205	1	31-51-42 P051-00/ /	001-099
M00985		254N1008-18 MODULE-THRUST LEVER	254N1054 96906	1	22-12-11 P010-00/ /	ALL
M00999		285T0034-26 MODULE-AURAL WARN SIREN/OWL,LEFT	285N0005 81205	1	31-51-31 P051-00/ /	ALL

EQUIPMENT LIST

D280N032

Section M00900

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01000	9	285T0385-5 MODULE-AURAL WARN BELL/CHIME(SB 31-0164)	285N0005 81205	1	31-51-32 P051-00/ /	115-199
M01000		285T0385-5 MODULE-AURAL WARN BELL/CHIME	285N0005 81205	1	31-51-32 P051-00/ /	001-008, 010-099
M01000		285T0385-6 MODULE-AURAL WARN BELL/CHIME	285N0005 81205	1	31-51-32 P051-00/ /	009, 115-199
M01046		285T0557-2 CONTROL PANEL-ADF DUAL	233N6101 81205	1	34-57-11 P008-00/ /	001
M01046		622-6830-001 CONTROL PANEL-ADF DUAL	233N6101 13499	1	34-57-11 P008-00/ /	002-008, 010-099
M01046		285T0557-1 CONTROL PANEL-ADF DUAL	233N6101 27914	1	34-57-11 P008-00/ /	009
M01046		285T0557-1 CONTROL PANEL-ADF DUAL	233N6101 81205	1	34-57-11 P008-00/ /	115-199
M01060		S242T404-802 UNIT-EFIS INSTR COMPARATOR	284N1800 81205	1	34-25-11 E002-03/ /	ALL
M01088		41SG118-2 XMTR-PRESS,AIR SUPPLY EICAS DUCT,R	212N3001 02750	1	36-21-11 0900/145/R038	ALL
M01089		41SG118-2 XMTR-PRESS,AIR SUPPLY EICAS DUCT,L	212N3001 02750	1	36-21-11 907/148/R032	ALL

EQUIPMENT LIST

D280N032

Section M01000

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01102		10S1034A MODULE-400HZ EMI FILTER	285N0005 56289	1	31-51-11 P051-00/ /	ALL
M01103		10S1034A MODULE-400HZ EMI FILTER	285N0005 56289	1	31-51-12 P051-00/ /	ALL
M01174		10167-7000-BT MODULE-TIME DELAY,AUTOBRAKES LIGHT	233N2101 08719	1	32-42-12 P001-03/ /	ALL

EQUIPMENT LIST

D280N032

Section M01100
Page 1 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01330		NO-425 GLIDE SLOPE ANTENNA DIRECTOR BAR	284N1418 26066	1	34-31-21 0185/166/	115-199

EQUIPMENT LIST

D280N032

Section M01300

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01411		285T1111-1 MODULE- WEU BITE	284N1329 81205	1	27-32-12 P051-00/ /	ALL

EQUIPMENT LIST

D280N032

Section M01400
Page 1 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M03012		417N3100 MODULE-PSU U/B	417N3001 81205	69	33-23-31 MULTI/ /	001-003, 005, 007-099
M03012		417N3100 MODULE-PSU U/B	417N3001 81205	68	33-23-31 MULTI/ /	004, 006
M03013		417N3100-299 MODULE-PARTIAL PSU U/B	417N3001 81205	1	23-31-42 0407/ /	004-099
M03014		417N3050 MODULE-INFORMATION SIGN PANEL ASSEMBLY	417N3001 81205	4	33-24-31 MULTI/ /	001-099

EQUIPMENT LIST

D280N032

Section M03000

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10001		S281T003-3 CONT UNIT-ELEC LOAD,ELEC HYD PUMP,L	284N1315 81205	1	29-11-12 P032-00/ /	ALL
M10004	9	10167-1000-BT 100 MS TIME DELAY-L	284N1125 81205	1	78-34-11 P036-00/ /	001-002, 115-199
M10004	1	530740-1000 100 MS TIME DELAY-L	284N1125 81205	1	78-34-11 P036-00/ /	003-099
M10004	2	10167-1000-BT 100 MS TIME DELAY-L	284N1125 81205	1	78-34-11 P036-00/ /	003-099
M10004	3	TD1982-1000 100 MS TIME DELAY-L	284N1125 81205	1	78-34-11 P036-00/ /	ALL
M10005		S281T003-3 CONT UNIT-ELEC LOAD,ELEC HYD PUMP,R	284N1314 81205	1	29-11-22 P031-00/ /	ALL
M10006		S281T003-3 CONT UNIT-ELEC LOAD,ELEC HYD PMP,C1	284N1314 81205	1	29-11-31 P031-00/ /	ALL
M10010	9	10167-1000-BT 100 MIL-STD TIME DELAY-R	284N1127 81205	1	78-34-21 P037-00/ /	001-002, 115-199
M10010	1	530740-1000 100 MIL-STD TIME DELAY-R	284N1127 81205	1	78-34-21 P037-00/ /	003-099
M10010	2	10167-1000-BT 100 MIL-STD TIME DELAY-R	284N1127 81205	1	78-34-21 P037-00/ /	003-099
M10010	3	TD1982-1000 100 MIL-STD TIME DELAY-R	284N1127 81205	1	78-34-21 P037-00/ /	ALL
M10012		S417N101-101A MODULE-LAV A,FWD,L(SEE YRH++++)	417N1070 81205	1	25-41-01 338/290/L020	001-099
M10012		S417N101-21A MODULE-LAV A,FWD,L(SEE YRH++++)	417N1070 81205	1	25-41-01 352/290/L025	115-199
M10013		S417N101-27A MODULE-LAV B,FWD,L(SEE YRJ++++)	417N1069 81205	1	25-41-01 0379/290/L019	115-199
M10014		S417N101-104A MODULE-LAV C,MID,L(SEE YRK++++)	417N1069 81205	1	25-41-01 1281/290/L022	001-099
M10014		S417N101-24A MODULE-LAV C,MID,L(SEE YRK++++)	417N1069 81205	1	25-41-01 1281/290/L035	115-199
M10015		S417N101-105A MODULE-LAV D,MID,R(SEE YRL++++)	417N1062 81205	1	25-41-01 1281/290/R022	001-099

EQUIPMENT LIST

D280N032

Section M10000

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10015		S417N101-25A MODULE-LAV D,MID,R(SEE YRL++++)	417N1062 81205	1	25-41-01 1281/290/R035	115-199
M10016		60B89004-10 PUMP-OVRD FUEL BOOST,L	343N3301 81205	1	28-22-11 1040/180/L010	ALL
M10017		60B89004-10 PUMP-OVRD FUEL BOOST,R	343N3301 81205	1	28-22-11 1040/175/R012	ALL
M10020		10167-3001BT MODULE-ELEC HYD PUMP ON DELAY,C2	284N1125 08719	1	29-11-31 P036-00/ /	ALL
M10020 T		MS25171-1S NIPPLE	96906	2	29-11-31 P36/ /	ALL
M10022		S281T003-3 CONT UNIT-ELEC LOAD,ELEC HYD PUMP,C2	284N1315 81205	1	29-11-31 P032-00/ /	ALL
M10023		233N3201-11 PANEL-WINDSHIELD CLEARANCE(SEE YPP++++)	233N3101 81205	1	30-42-11 P005-00/ /	ALL
M10024		215N1002-15 MODULE-TEMP SNSR,AFT CABIN (SEE YRV++++)	215N1001 81205	1	21-61-31 1177/275/R029	ALL
M10025		215N1002-15 MODULE-TEMP SNSR,FWD CABIN (SEE YRW++++)	215N1001 81205	1	21-61-21 517/275/R029	ALL
M10029		S270T200-5 PUMP-ELEC HYDRAULIC,C1	271N1058 81205	1	29-11-31 1250/141/L052	001-099
M10029		S270T200-5 PUMP-ELEC HYDRAULIC,C1	271N1058 81205	1	29-11-31 1250/148/L042	115-199
M10030		S270T200-5 PUMP-ELEC HYDRAULIC,C2	271N1058 81205	1	29-11-31 1250/149/L042	001-099
M10030		S270T200-5 PUMP-ELEC HYDRAULIC,C2	271N1058 81205	1	29-11-31 1250/148/L042	115-199
M10040		S251N115-3 SERVO-A/P LAT CONTROL,LEFT	251N1023 81205	1	22-11-11 1050/165/R015	ALL
M10041		S251N115-3 SERVO-A/P LAT CONTROL,CENTER	251N1023 81205	1	22-11-31 1052/162/L020	ALL
M10042		S251N115-3 SERVO-A/P LAT CONTROL,RIGHT	251N1023 81205	1	22-11-21 1045/162/L020	ALL
M10048		S251N206-2 ACTR-ELEVATOR ASYMMETRICAL LIMIT	251N2061 81205	1	27-31-12 1862/235/R018	ALL

EQUIPMENT LIST

D280N032

Section M10000

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10050		233N3205-26 PANEL-HYDRAULICS(SEE YQT++++)	233N3101 81205	1	29-11-12 P005-00/ /	115-199
M10050	1	233N3205-24 PANEL-HYDRAULICS(SEE YQT++++)	233N3101 81205	1	29-11-12 P005-00/ /	001-099
M10050	2	233N3205-27 PANEL-HYDRAULICS(SEE YQT++++)	233N3101 81205	1	29-11-12 P005-00/ /	001-099
M10054		S345N001-001 PANEL-FUEL QTY	233N3101 81205	1	28-41-11 P005-00/ /	001-099
M10054		S345N001-001 PANEL-FUEL QTY (KG)(MR69018-002)	233N3101 81205	1	28-41-11 P005-00/ /	115-199
M10055	9	233N3206-2015 PANEL-FUEL CONTROL (SB 28A0105)	233N3101 81205	1	28-22-11 P005-00/ /	001-008
M10055	9	233N3206-3019 PANEL-FUEL CONTROL (SB 28A0105)	233N3101 81205	1	28-22-11 P005-00/ /	009-099
M10055	9	233N3206-2017 PANEL-FUEL CONTROL (SB 28A0105)	233N3101 81205	1	28-22-11 P005-00/ /	115-199
M10056		233N3214-31 PANEL-LIGHTING CONTROL,L (SEE YSN++++)	233N3101 81205	1	33-11-21 P005-00/ /	001-099
M10056		233N3214-33 PANEL-LIGHTING CONTROL,LEFT	233N3101 81205	1	33-11-21 P005-00/ /	115-199
M10057		233N3221-57 MODULE-LIGHTING CONTROL,R (SEE YSP++++)	233N3101 81205	1	33-11-31 P005-00/ /	001-099
M10057		233N3221-60 MODULE-LIGHTING CONTROL,R (SEE YSP++++)	233N3101 81205	1	33-11-31 P005-00/ /	115-199
M10062		233N3211-31 PANEL-BATT/STANBY PWR (SEE YTG++++)	233N3101 81205	1	24-33-11 P005-00/ /	001-099
M10062		233N3211-24 PANEL-BATT/STANBY PWR (SEE YTG++++)	233N3101 81205	1	24-33-11 P005-00/ /	115-199
M10063		233N3209-18 PANEL-ELECTRICAL (SEE YTH++++)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
M10063		233N3209-12 PANEL-ELECTRICAL (SEE YTH++++)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
M10067		233N3203-32 PANEL-EQUIPMENT COOLING (SEE YNM++++)	233N3101 81205	1	21-58-12 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section M10000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10067		233N3203-34 PANEL-EQUIPMENT COOLING (SEE YNM++++)	233N3101 81205	1	21-58-12 P005-00/ /	115-199
M10078		S231N211-2 PANEL-COMPARTMENT TEMP	233N3101 81205	1	21-65-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section M10000

Page 4 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10137		S345T002-364 ASSEMBLY-HARNESS R,CTR TANK	345N2001 81205	1	28-41-41 900/WRP/R076	115-199
M10139		S345T002-157 UNIT-BUSSING PLUG R,CTR TANK	345N2001 81205	1	28-41-41 ISS101/ /	115-199
M10140		622-8594-001 PNL-TRANSPONDER CONTROL	233N6101 13499	1	34-53-11 P008-00/ /	001-006
M10140		622-8974-314 PNL-TRANSPONDER CONTROL	233N6101 13499	1	34-53-11 P008-00/ /	007-099
M10140		071-01478-0002 PNL-TRANSPONDER CONTROL	233N6101 22373	1	34-53-11 P008-00/ /	115-199
M10141		622-7878-201 TRANSPONDER-LEFT	284N1800 13499	1	34-53-11 E003-03/ /	001-099
M10141		066-1127-0000 TRANSPONDER-LEFT	284N1800 22373	1	34-53-11 E003-03/ /	115-199
M10142		622-7878-201 TRANSPONDER-RIGHT	284N1800 13499	1	34-53-21 E003-02/ /	001-099
M10142		066-1127-0000 TRANSPONDER-RIGHT	284N1800 22373	1	34-53-21 E003-02/ /	115-199
M10143		S220T116-1 ANT BOTTOM ATC	284N1347 81205	1	34-53-11 496/148/	115-199
M10144		S220T116-1 ANT-BOTTOM ATC	284N1347 81205	1	34-53-11 535/148/	115-199
M10145		10167-3001-BT MODULE-PTU ON DELAY#1	284N1318 08719	1	29-22-11 P033-00/ /	ALL
M10145 T		MS25171-1S NIPPLE	96906	2	29-22-11 P33/ /	115-199
M10146		10167-3001-BT MODULE-PTU IND DELAY	284N1318 08719	1	29-22-11 P033-00/ /	ALL
M10146 T		MS25171-1S NIPPLE	96906	2	29-22-11 P33/ /	115-199
M10148		S258T710-9 TURBINE-RAM AIR	271N0005 81205	1	29-21-31 1235/147/R035	ALL
M10149		L963010 UNIT-IGNITION A	10E80008 K0680	1	74-31-11 ENG/ /	ALL

EQUIPMENT LIST

D280N032

Section M10100

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10150		L963010 UNIT-IGNITION B	10E80008 K0680	1	74-31-11 ENG/ /	ALL
M10151		L922214 XMTR-FLOWMETER,FUEL	10E80008 K0680	2	73-31-11 ENG/ /	ALL
M10152		L962571 XMTR-TACHOMETER-N3	10E80008 K0680	2	77-12-31 ENG/ /	ALL
M10153		C8E38-7 UNIT-BLEED VALVE CONTROL	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10154		L150901 MOTOR,FFR TRIM	10E80008 K0680	2	73-21-11 ENG/ /	ALL
M10156		L963013 DEDICATED GENERATOR-ROTOR	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10157	1	L963022 CONT UNIT-PWR CONDTNG & DED. GEN. A	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10157	2	L963024 CONT UNIT-PWR CONDTNG & DED. GEN. A	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10157	3	47385 CONT UNIT-PWR CONDTNG & DED. GEN. A	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10158		UL10933 MDL-ELECTRONIC ENGINE CONTROL PATCH	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10160		S281T001-33 GEN-INTEGRATED DRIVE	332N5002 81205	2	24-11-11 ENG/ /	001-003, 115-199
M10160		S281T001-38 GEN-INTEGRATED DRIVE	332N5002 81205	2	24-11-11 ENG/ /	004-099
M10162		L925656 XDCE-ENGINE PRESSURE RATIO	10E80008 K0680	2	77-11-11 ENG/ /	ALL
M10164		L963021 DEDICATED GENERATOR-STATOR	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10165	1	L963022 CONT UNIT-PWR CONDTNG & DED GEN B	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10165	2	L963024 CONT UNIT-PWR CONDTNG & DED GEN B	10E80008 K0680	2	75-31-11 ENG/ /	ALL
M10166		ETPU100-02C UNIT-TRANSIENT PRESSURE	286N5000 49367	1	75-31-11 ENG/ /	ALL

EQUIPMENT LIST

D280N032

Section M10100

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10167		UL17527 IGNITION RELAY ASSY	S300N501 81205	1	74-31-21 ENG/ /	001-099
M10175		284T0736-7 ANTENNA FEEDLINE ASSY-HF COMM,L	284N1704 81205	1	23-11-11 F195/ /FS	ALL
M10181	9	S242N701-1001 COMPUTER-EICAS,L	SB310059 4V792	1	31-41-11 E004-02/ /	ALL
M10181		S242N701-111 COMPUTER-EICAS,L	284N1800 81205	1	31-41-11 E004-02/ /	001-099
M10181		S242N701-110 COMPUTER-EICAS,L	284N1800 81205	1	31-41-11 E004-02/ /	115-199
M10182	9	S242N701-1001 COMPUTER-EICAS,R	SB310059 4V792	1	31-41-21 E004-02/ /	ALL
M10182		S242N701-111 COMPUTER-EICAS,R	284N1800 81205	1	31-41-21 E004-02/ /	001-099
M10182		S242N701-110 COMPUTER-EICAS,R	284N1800 81205	1	31-41-21 E004-02/ /	115-199
M10190		284T0736-8 ANTENNA FEEDLINE ASSY-HF COMM,R	284N1704 81205	1	23-11-11 F195/ /FS	001-099
M10191		233N7503-32 PNL-GEN FIELD AND HYD (SEE YQZ++++)	233N7401 81205	1	24-11-11 P061-00/ /	001-003, 115-199
M10191		233N7503-56 PNL-HYD FLIGHT CONTROL (SEE YQZ++++)	233N7401 81205	1	27-23-11 P061-00/ /	004-099
M10193		233N3217-15 PNL-AIR CONDITIONING CONTROL (YNR++++)	233N3101 81205	1	21-25-11 P005-00/ /	001-099
M10193		233N3217-17 PNL-AIR CONDITIONING CONTROL (YNR++++)	233N3101 81205	1	21-25-11 P005-00/ /	115-199
M10195		S242N701-206 PNL-EICAS PILOTS DISPLAY SELECT	233N6101 81205	1	31-41-19 P009-00/ /	ALL

EQUIPMENT LIST

D280N032

Section M10100

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10204		RD-AM6839-3 CABLE-SIDEWALL TO SEAT JCT BOX	414N1001 0FF57	4	23-34-13 MULTI/ /	115-199
M10209		417N5111-4 MDL-FWD GALLEY LT ASSY	411N3210 81205	1	33-27-11 0347/289/R019	ALL
M10210		417N5114-1-PROVISIONS- MDL-R MID FWD GALLEY LIGHT ASSY	417N7002 81205	1	33-27-21 0698/290/R027	ALL
M10211		417N5112-3 MDL-AFT GALLEY LIGHT ASSY	417N5102 81205	1	33-27-31 1668/294/R005	ALL
M10212		S282N001-3 MONITOR-BATTERY CURRENT	284N1411 81205	1	24-31-11 255/150/R040	001-099
M10212		S282N001-4 MONITOR-BATTERY CURRENT	284N1686 30242	1	24-31-11 255/150/R040	115-199
M10213		S282N002-2 CONT UNIT-DIRECT CURRENT TIE	287N4102 81205	1	24-34-11 P006-00/ /	ALL
M10216		285T0022-44 PNL-AUDIO SELECT,P61	233N7401 81205	1	23-51-51 P061-00/ /	115-199
M10220		S251N406-2 MOTOR-DRIVE,SLAT ALT	251N4052 81205	1	27-81-11 FSS122/ /	ALL
M10222 T		MS25171-1S NIPPLE	96906	2	76-11-21 P36/ /	ALL
M10223 T		MS25171-1S NIPPLE	96906	2	76-11-21 P37/ /	115-199
M10224	5	285N0028-17 PC ASSY 1-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-11-11 P054-00/ /	ALL
M10224	1	285N0028-136 PC ASSY 1-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-11-11 P054-00/ /	ALL
M10224	2	285N0028-36 PC ASSY 1-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-11-11 P054-00/ /	ALL
M10224	3	285N0028-21 PC ASSY 1-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-11-11 P054-00/ /	ALL
M10224	4	285N0028-20 PC ASSY 1-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-11-11 P054-00/ /	ALL
M10225		65B81529-6 ASSY-AILERON POS XMTR,L	251N1007 81205	1	27-18-11 WS652/ /LRS	ALL

EQUIPMENT LIST

D280N032

Section M10200

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10226		65B81529-5 ASSY-AILERON POS XMTR,R	251N1007 81205	1	27-18-11 WS652/ /RRS	ALL
M10229		6445-01 CARD-OVHT DET,L NACELLE,1	284N1328 81205	1	26-11-12 P054-00/ /	ALL
M10230		6445-01 CARD-OVHT DET,R NACELLE,1	284N1329 81205	1	26-11-22 P054-00/ /	ALL
M10231	1	S273N401-4 MOTOR-ALT L/G EXT	273N4010 K0654	1	32-35-11 1073/147/	ALL
M10231	2	S273N401-3 MOTOR-ALT L/G EXT	273N4010 K0654	1	32-35-11 1073/147/	ALL
M10232	1	S283T019-4 CONT UNIT-DMR,PILOT OVHD PNL LT,CTR	233N2400 81205	1	33-13-31 P012-00/ /	ALL
M10232	2	S283T019-3 CONT UNIT-DMR,PILOT OVHD PNL LT,CTR	233N2400 81205	1	33-13-31 P005-00/ /	ALL
M10232	3	S283T019-2 CONT UNIT-DMR,PILOT OVHD PNL LT,CTR	284N1202 81205	1	33-13-31 P005-00/ /	ALL
M10233	1	S283T019-3 CONT UNIT-DMR,PILOT OVHD PNL LT,R INBD	233N2400 81205	1	33-13-32 P005-00/ /	ALL
M10233	2	S283T019-2 CONT UNIT-DMR,PILOT OVHD PNL LT,R INBD	233N2400 81205	1	33-13-32 P005-00/ /	ALL
M10250	1	233N3216-20 PNL-YAW DAMPER(SEE YPJ++++)	233N3101 81205	1	22-21-11 P005-00/ /	ALL
M10250	2	233N3216-22 PNL-YAW DAMPER(SEE YPJ++++)	233N3101 81205	1	22-21-11 P005-00/ /	ALL
M10250	3	233N3216-18 PNL-YAW DAMPER(SEE YPJ++++)	233N3101 81205	1	22-21-11 P005-00/ /	ALL
M10250	4	233N3216-14 PNL-YAW DAMPER(SEE YPJ++++)	233N3101 81205	1	22-21-11 P005-00/ /	ALL
M10251		MS91586-7 SHUNT-AUX PWR UNIT BATTERY CHARGER	284N1690 96906	1	24-31-41 E006-00/ /	ALL
M10253		S417N505-122 LT ASSY-EMERGENCY EXIT SIGN	417N5200 81205	1	33-51-13 0710/293/L006	001-099
M10253		S417N505-147 LT ASSY-EMERGENCY EXIT SIGN	417N5200 81205	1	33-51-13 0710/291/L006	115-199

EQUIPMENT LIST

D280N032

Section M10200

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10253 T		OL-3071BPEGPL LAMP-	S417N505 S3774	30	33-51-13 0710/293/L006	001-099
M10253 T		OL-3071BPEGPL LAMP-	S417N505 S3774	30	33-51-13 0710/291/L006	115-199
M10253 U		387 LAMP-CALL	S417N505 88806	3	33-25-11 0710/293/L006	ALL
M10254		S417N505-123 LT ASSY-EMERGENCY EXIT LOCATOR SIGN	417N5200 81205	1	33-51-14 1337/292/L006	001-099
M10254 T		OL-3071BPEGPL LAMP-	S417N505 S3774	30	33-51-14 1337/292/L006	001-099
M10254 U		387 LAMP-CALL	S417N505 08806	3	33-25-11 1337/292/L006	001-099
M10255		S417N505-124 LT ASSY-EMERGENCY EXIT LOCATOR SIGN	417N5206 81205	1	33-51-15 1657/288/L006	001-099
M10255		S417N505-131 LT ASSY-EMERGENCY EXIT LOCATOR SIGN	417N5200 81205	1	33-51-15 1657/288/L006	115-199
M10255 T		OL-3071BPEGPL LAMP	S417N505 S3774	30	33-51-15 1657/288/L006	ALL
M10255 U		387 LAMP-CALL	S417N505 08806	3	33-25-11 1657/288/L006	001-099
M10255 U		387 LAMP-CALL	S417N505 08806	4	33-25-11 1657/288/L006	115-199
M10256		MXP147 STOWAGE-OXY MASK-F/08S	232N8001 F0553	1	23-51-41 P017-00/ /	ALL
M10257		MXP147 STOWAGE-OXY MASK,P61	232N8001 F0553	1	23-51-51 P061-00/ /	115-199
M10258		S241T200-154 PNL-THRUST MODE SELECT	233N2101 81205	1	22-31-12 P003-01/ /	ALL
M10259		233N3215-16 PNL-BLEED AIR (SEE YNN++++)	233N3101 81205	1	36-11-11 P005-00/ /	001-099
M10259		233N3215-19 PNL-BLEED AIR (SEE YNN++++)	233N3101 81205	1	36-11-11 P005-00/ /	115-199
M10261		285T0097-6 PC CARD-DIMMER,TYPE I,L1	285N0001 81205	1	33-16-11 P026-00/ /	ALL

EQUIPMENT LIST

D280N032

Section M10200

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10262		285T0097-6 PC CARD-DIMMER,TYPE I,L2 A	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10263		285T0097-6 PC CARD-DIMMER,TYPE I,L2 B	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10264		285T0097-6 PC CARD-DIMMER,TYPE I,R1 A	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10265		285T0097-6 PC CARD-DIMMER,TYPE I,R1 B	285N0001 81205	1	33-16-11 1662/288/	ALL
M10266		285T0097-6 PC CARD-DIMMER,TYPE I,R2 A	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10267		285T0097-6 PC CARD-DIMMER,TYPE I,R2 B	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10268		285T0097-6 PC CARD-DIMMER,TYPE I,BATT 3	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10269		285T0097-6 PC CARD-DIMMER,TYPE I,BATT 1	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10270		285T0097-6 PC CARD-DIMMER,TYPE I,BATT 2	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10274	5	285N0028-17 PC ASSY 2-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-11-21 P054-00/ /	ALL
M10274	1	285N0028-136 PC ASSY 2-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-11-21 P054-00/ /	ALL
M10274	2	285N0028-36 PC ASSY 2-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-11-21 P054-00/ /	ALL
M10274	3	285N0028-21 PC ASSY 2-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-11-21 P054-00/ /	ALL
M10274	4	285N0028-20 PC ASSY 2-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-11-21 P054-00/ /	ALL
M10275		6445-01 CARD-OVHT DET,R NACELLE,2	284N1329 81205	1	26-11-22 P054-00/ /	ALL
M10276		6445-01 CARD-OVHT DET,L NACELLE,2	284N1329 81205	1	26-11-12 P054-00/ /	ALL
M10279		10-60811-3 SOL-UNLOCK,R MN GR DR ACTR	273N4041 81205	1	32-12-12 1126/172/R001	ALL

EQUIPMENT LIST

D280N032

Section M10200

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10280	1	10-60811-11 SOL-UNLOCK,L MN GR DR ACTR	273N4171 81205	1	32-12-12 1126/172/L005	ALL
M10280	2	10-60811-3 SOL-UNLOCK,L MN GR DR ACTR	273N4171 81205	1	32-12-12 1126/172/L005	ALL
M10280	3	10-60811-7 SOL-UNLOCK,L MN GR DR ACTR	273N4171 81205	1	32-12-12 1126/172/L005	ALL
M10281		10-60811-3 SOL-UNLOCK,NOSE GR DR ACTR	273N4034 81205	1	32-12-12 269/175/L030	ALL
M10287		1880T100-1 PDU-AFT CARGO LOADER	451N7210 98889	1	25-51-21 1190/146/	115-199
M10292		S212N101-49 PILOT-HIGH STAGE,LEFT	312N5301 81205	1	36-11-12 N177/130/L	ALL
M10292	2	S212N101-43 PILOT-HIGH STAGE,LEFT	312N5301 81205	1	36-11-12 N177/130/L	ALL
M10293		S212N101-49 PILOT-HIGH STAGE,RIGHT	312N5301 81205	1	36-11-22 N177/130/R	ALL
M10293	1	S212N101-43 PILOT-HIGH STAGE,RIGHT	312N5301 81205	1	36-11-22 N177/130/R	ALL
M10293	2	S212N101-39 PILOT-HIGH STAGE,RIGHT	312N5301 81205	1	36-11-22 N177/130/R	001, 115-199
M10294		S345T002-363 ASSEMBLY-HARNESS,L CTR TANK	345N2001 81205	1	28-41-41 / /	115-199
M10295		S345T002-157 UNIT-BUSSING PLUG,L CTR TANK	345N2001 81205	1	28-41-41 FSS101/ /	115-199
M10298		S283N901-4 CARD-ENG SPEED L	284N1327 81205	1	77-12-41 P050-00/ /	001-009, 115-199
M10298		S28SN0200-203 CARD-ENG SPEED L	284N1800 81205	1	77-12-41 P050-00/ /	010-099

EQUIPMENT LIST

D280N032

Section M10200

Page 5 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10301		2227050-2 PNL-FLIGHT DATA ENTRY	233N7401 98571	1	31-31-11 P061-00/ /	115-199
M10303		S251N404-1 SOL-FLAP LOAD RELIEF	251N4052 81205	1	27-51-51 1060/190/L020	ALL
M10304		S251N404-1 SOL-AUTOSLAT VALVE	251N5091 81205	1	27-81-21 FSS119/ /	ALL
M10311		S283N901-4 CARD-ENG SPEED R	284N1327 81205	1	77-12-42 P050-00/ /	001-009, 115-199
M10311		S285N0200-203 CARD-ENG SPEED R	284N1800 81205	1	77-12-42 P050-00/ /	010-099
M10312	1	285N0006-12 CARD-ECS BLEED CONFIGURATION,RIGHT	284N1800 81205	1	36-11-21 P050-00/ /	ALL
M10312	2	285N0006-11 CARD-ECS BLEED CONFIGURATION,RIGHT	284N1800 81205	1	36-11-21 P050-00/ /	ALL
M10313	1	285N0006-12 CARD-ECS BLEED CONFIGURATION,LEFT	284N1800 81205	1	36-11-11 P050-00/ /	ALL
M10313	2	285N0006-11 CARD-ECS BLEED CONFIGURATION,LEFT	284N1800 81205	1	36-11-11 P050-00/ /	ALL
M10315		S417N507-13 MDL-FLUOR LAMP/BALLAST ASSY(SEE YQK)	417N5120 81205	1	33-21-21 MULTI/ /	001-099
M10315		S417N507-3-PROVISIONS- MDL-FLUOR LAMP/BALLAST ASSY(SEE YQK)	417N5120 81205	1	33-21-21 MULTI/ /	115-199
M10316		S417N507-12 MDL-FLUOR LAMP/BALLAST ASSY(SEE YNW)	417N5120 81205	10	33-21-12 MULTI/ /	001-099
M10316		S417N507-2 MDL-FLUOR LAMP/BALLAST ASSY(SEE YNW)	417N5120 81205	10	33-21-12 MULTI/ /	115-199
M10317		S417N507-14 MDL-FLUOR LAMP ASSY(SEE YNX)	417N5120 81205	16	33-21-12 MULTI/ /	001-099
M10317		S417N507-4 MDL-FLUOR LAMP ASSY(SEE YNX)	417N5120 81205	16	33-21-12 MULTI/ /	115-199
M10318		S417N507-17 MDL-FLUOR LAMP/BALLAST ASSY(SEE YNY)	417N5120 81205	1	33-21-13 MULTI/ /	001-099
M10318		S417N507-7 MDL-FLUOR LAMP/BALLAST ASSY(SEE YNY)	417N5120 81205	1	33-21-13 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section M10300

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10319		S417N507-19 MDL-FLUOR LAMP/BALLAST ASSY(SEE YNZ)	417N5120 81205	1	33-21-14 1584/288/L038	001-099
M10319		S417N507-9 MDL-FLUOR LAMP/BALLAST ASSY(SEE YNZ)	417N5120 81205	1	33-21-12 1584/288/L038	115-199
M10321		417N5113-2 FWD ENTRY LIGHT ASSY-	417N5103 81205	1	33-22-11 355/288/L014	ALL
M10323		10167-2500BT MDL-RAM AIR TURBINE TIME DELAY	284N1318 08719	1	29-21-31 P033-00/ /	ALL
M10323 T		MS25171-1S NIPPLE	96906	2	29-21-31 P33/ /	ALL
M10324		233N3222-8 PNL-AUX PWR UNIT START (SEE YQL++++)	233N3101 81205	1	49-61-11 P005-00/ /	115-199
M10331	1	285N0011-40 UNIT-FLAP/SLAT ELEX-1	284N1800 81205	1	27-58-31 E005-01/ /	ALL
M10331	2	285N0011-32 UNIT-FLAP/SLAT ELEX-1	284N1800 81205	1	27-58-31 E005-01/ /	ALL
M10331	3	285N0011-17 UNIT-FLAP/SLAT ELEX-1	284N1800 81205	1	27-58-31 E005-01/ /	ALL
M10331	4	285N0011-14 UNIT-FLAP/SLAT ELEX-1	284N1800 81205	1	27-58-31 E005-01/ /	ALL
M10332	1	285N0011-40 UNIT-FLAP/SLAT ELEX-2	284N1800 81205	1	27-58-31 E005-03/ /	ALL
M10332	2	285N0011-32 UNIT-FLAP/SLAT ELEX-2	284N1800 81205	1	27-58-31 E005-03/ /	ALL
M10332	3	285N0011-17 UNIT-FLAP/SLAT ELEX-2	284N1800 81205	1	27-58-31 E005-01/ /	ALL
M10332	4	285N0011-14 UNIT-FLAP/SLAT ELEX-2	284N1800 81205	1	27-58-31 E005-01/ /	ALL
M10333	1	285N0011-40 UNIT-FLAP/SLAT ELEX-3	284N1800 81205	1	27-58-31 E005-02/ /	ALL
M10333	2	285N0011-32 UNIT-FLAP/SLAT ELEX-3	284N1800 81205	1	27-58-31 E005-02/ /	ALL
M10333	3	285N0011-17 UNIT-FLAP/SLAT ELEX-3	284N1800 81205	1	27-58-31 E005-01/ /	ALL

EQUIPMENT LIST

D280N032

Section M10300

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10333	4	285N0011-14 UNIT-FLAP/SLAT ELEX-3	284N1800 81205	1	27-58-31 E005-01/ /	ALL
M10334		10167-2-BT MDL-DELAY,START/FAIL,L	284N1125 08719	1	80-11-11 P036-00/ /	ALL
M10334 T		MS25171-1S NIPPLE	96906	2	80-11-11 P36/ /	ALL
M10335	1	10167-2001-BT MDL-DELAY,START/FAIL,R (PLATE C)	284N1127 08719	1	80-11-21 P037-00/ /	ALL
M10335	2	10167-2-BT MDL-DELAY,START/FAIL,R (PLATE C)	284N1127 08719	1	80-11-21 P037-00/ /	ALL
M10336		S417N507-11 MDL-FLUOR B/NIGHT LP ASSY(SEE YPR)	417N5120 81205	8	33-21-12 MULTI/ /	001-099
M10336		S417N507-1 MDL-FLUOR B/NIGHT LP ASSY(SEE YPR)	417N5120 81205	8	33-21-12 MULTI/ /	115-199
M10342		S222T101-101 SPEAKER-PSU	417N3100 81205	37	23-31-16 MULTI/ /	001-099
M10342		S222T101-101 SPEAKER-PSU	417N3100 81205	40	23-31-16 MULTI/ /	115-199
M10343		S222T101-101 SPEAKER-PSU,MUTED	417N3100 81205	1	23-31-16 MULTI/ /	115-199
M10346		S222T101-201 SPEAKER-AFT GALLEY	411N3210 81205	1	23-31-16 1650/295/L005	115-199
M10349		P5VA-C8962 SPKR-AFT MID ATTEND	411N3210 07109	1	23-31-16 1300/295/R010	115-199
M10350		S222T101-101 SPKR-POWER SUPPLY UNIT	417N3001 81205	1	23-31-16 0715/265/L060	115-199
M10353		417N3100-117 MODULE-PSU U/B	417N3001 81205	17	33-23-31 MULTI/ /	115-199
M10354		417N3100-36 MODULE-PSU U/B	417N3001 81205	17	33-23-31 MULTI/ /	115-199
M10355		417N3100-113 MODULE-PSU U/B	417N3001 81205	18	33-23-31 MULTI/ /	115-199
M10356		417N3100-58 MODULE-PSU U/B	417N3001 81205	20	33-23-31 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section M10300

Page 3

Oct 09/2008

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10358		417N3100-21 MODULE-PSU U/B	417N3001 81205	1	33-23-31 MULTI/ /	001-099
M10361		417N3700-2 MODULE-ATT SERVICE UNIT U/B	417N3001 81205	1	33-23-31 MULTI/ /	115-199
M10362		417N3200 MODULE-PSU,O/D LEFT	417N3001 81205	2	35-21-31 MULTI/ /	001-099
M10363		417N3200 MODULE-PSU O/D	417N3001 81205	1	33-23-31 MULTI/ /	001-099
M10363		417N3200-31 MODULE-PSU O/D	417N3001 81205	2	33-23-31 MULTI/ /	115-199
M10368		280T1003-1 RCPT-SHORTING,EICAS L	284N1542 81205	1	31-41-14 E004-02/ /	ALL
M10369		280T1003-1 RCPT-SHORTING,EICAS R	284N1542 81205	1	31-41-24 E004-02/ /	ALL
M10370		233N6202-1 PNL-INTERCOM RATE OF TURN SWITCH	233N6101 82389	1	23-51-51 P008-00/ /	115-199
M10372		233N7509-1 PNL-EICAS MAINTENANCE	233N7401 81205	1	31-41-19 P061-00/ /	ALL
M10373		417N3810 MDL-ATT OXYGEN ASSY	417N3001 81205	3	35-21-31 MULTI/ /	ALL
M10374	1	S281N001-2 UNIT-CAPT INSTRUMENT BUS VOLTAGE SENSOR	287N4102 15420	1	24-51-72 P006-00/ /	ALL
M10374	2	S281N001-1 UNIT-CAPT INSTRUMENT BUS VOLTAGE SENSOR	287N4102 15420	1	24-51-72 P006-00/ /	ALL
M10375		S281N001-1 UNIT-F/O INSTRUMENT BUS VOLTAGE SENSOR	287N4102 15420	1	24-51-72 P006-00/ /	ALL
M10375	1	S281N001-2 UNIT-F/O INSTRUMENT BUS VOLTAGE SENSOR	287N4102 15420	1	24-51-72 P006-00/ /	ALL
M10375	2	S281N001-1 UNIT-F/O INSTRUMENT BUS VOLTAGE SENSOR	287N4102 15420	1	24-51-72 P006-00/ /	ALL
M10376		S417N507-15 MDL-FLUOR LAMP ASSY(SEE YQG)	417N5120 81205	2	33-21-22 MULTI/ /	001-099
M10376		S417N507-5 MDL-FLUOR LAMP ASSY(SEE YQG)	417N5120 81205	2	33-21-12 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section M10300

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10377		S417N507-8 MDL-FLUOR LAMP/BALLAST ASSY(SEE YQH)	417N5120 81205	1	33-21-12 MULTI/ /	ALL
M10379		S283N702-108 BALLAST-FLUORESCENT LIGHT ASSY	417N5113 81205	1	33-22-11 355/288/L014	ALL
M10380		S283N702-108 BALLAST-FLUORESCENT LIGHT ASSY	417N5113 81205	1	33-22-11 0355/288/L014	001-099
M10380		S283N702-108 BALLAST-FLUORESCENT LIGHT ASSY	417N5113 81205	1	33-22-11 355/288/L014	115-199
M10381		S283N702-109 BALLAST-FLUORESCENT LIGHTING,FWD GALLEY	417N5111 81205	1	33-27-11 0347/289/R019	ALL
M10382		S283N702-109 BALLAST-FLUORESCENT LIGHTING,FWD GALLEY	417N5111 81205	1	33-27-11 0347/289/R019	ALL
M10383		S283N702-108-PROVISIONS- BALLAST-FLUOR LIGHTING,R MID FWD GALLEY	417N5114 81205	1	33-27-21 710/289/R043	ALL
M10384		S283N702-108-PROVISIONS- BALLAST-FLUOR LIGHTING,R MID FWD GALLEY	417N5114 81205	1	33-27-21 710/289/R043	ALL
M10385		S283N702-110 BALLAST-FLUORESCENT LIGHTS,AFT GALLEY	417N5112 81205	1	33-27-31 1668/294/R005	ALL
M10387		D17666 RECORDER-QUICK ACCESS (QAR)	284N1800 K1474	1	31-31-11 E003-03/ /	115-199
M10389		S210T130-28 CONTROLLER-PACK STANDBY TEMP	284N1725 81205	1	21-51-14 E003-03/ /	001-099
M10389		S210T130-28 CONTROLLER-PACK STANDBY TEMP	284N1686 81205	1	21-51-14 E006-02/ /	115-199
M10391	1	356A7065G152 UNIT-ELEC ENG CONT,L	284N1375 K0680	1	73-21-11 456/165/L025	ALL
M10391	2	356A7065G151 UNIT-ELEC ENG CONT,L	284N1375 K0680	1	73-21-11 456/165/L025	ALL
M10391	3	ESC103-04CA UNIT-ELEC ENG CONT,L	284N1375 K0680	1	73-21-11 456/165/L025	ALL
M10392	1	356A7065G152 UNIT-ELEX ENG CONT,R	284N1375 K0680	1	73-21-21 480/165/L025	ALL
M10392	2	356A7065G151 UNIT-ELEX ENG CONT,R	284N1375 K0680	1	73-21-21 480/165/L025	ALL

EQUIPMENT LIST

D280N032

Section M10300

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10392	3	ESC103-04C4 UNIT-ELEX ENG CONT,R	284N1375 K0680	1	73-21-21 480/165/L025	ALL
M10393		232N4704-3 BOX-SPARE LAMP & FUSE TESTER	232N4704 81205	1	33-14-51 0297/261/R005	115-199
M10394		233N3202-17 PANEL-ANNUNCIATOR	233N3101 81205	1	52-71-11 P005-00/ /	ALL
M10395		233N3212-11 PANEL- WINDOW HEAT (SEE YA0++++)	233N3101 81205	1	30-41-11 P005-00/ /	001-099
M10395		233N3212-13 PANEL- WINDOW HEAT (SEE YA0++++)	233N3101 81205	1	30-41-11 P005-00/ /	115-199
M10396		233N3210-15 PANEL-LIGHTING ANTI-COLLISION	233N3101 81205	1	33-44-11 P005-00/ /	115-199
M10397		233N3204-19 PANEL-ANTI-ICE (SEE YAQ++++)	233N3101 81205	1	30-21-11 P005-00/ /	001-099
M10397		233N3204-21 PANEL-ANTI-ICE (SEE YAQ++++)	233N3101 81205	1	30-21-11 P005-00/ /	115-199
M10398		233N7501-36 PANEL-TEST PANEL(SEE YPH++++)	233N7401 81205	1	28-41-14 P061-00/ /	003-099
M10398	1	233N7501-36 PANEL-TEST PANEL(SEE YPH++++)	233N7401 81205	1	28-41-14 P061-00/ /	001-002, 115-199
M10398	2	233N7501-35 PANEL-TEST PANEL(SEE YPH++++)	233N7401 81205	1	28-41-14 P061-00/ /	001-002, 115-199
M10399		233N7502 PANEL-SERVICE INTERPHONE	234N7401 81205	1	23-41-11 P061-00/ /	115-199

EQUIPMENT LIST

D280N032

Section M10300

Page 6 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10400	5	285N0028-17 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-15-11 P054-00/ /	ALL
M10400	1	285N0028-136 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-15-11 P054-00/ /	ALL
M10400	2	285N0028-36 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-15-11 P054-00/ /	ALL
M10400	3	285N0028-21 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-15-11 P054-00/ /	ALL
M10400	4	285N0028-20 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-15-11 P054-00/ /	ALL
M10401		233N7506-1 PANEL-SQUIB TEST(SEE YQM++++)	233N7401 81205	1	26-21-11 P061-00/ /	ALL
M10403	1	285T0094-6 CARD ASSY-PACK BACKUP TEMP CONT,LEFT	284N1328 81205	1	21-51-13 P050-00/ /	ALL
M10403	2	282T0094-3 CARD ASSY-PACK BACKUP TEMP CONT,LEFT	284N1328 81205	1	21-51-13 P050-00/ /	ALL
M10404	1	285T0094-6 CARD ASSY-PACK BACKUP TEMP CONT,RIGHT	284N1328 81205	1	21-51-23 P050-00/ /	ALL
M10404	2	285T0094-3 CARD ASSY-PACK BACKUP TEMP CONT,RIGHT	284N1328 81205	1	21-51-23 P050-00/ /	ALL
M10405		271N1049-5 MODULE-SW,RAT GND MANUAL	271N0174 96906	1	29-21-31 1180/138/R018	ALL
M10406		S271N102-1 ACTUATOR-RAT SOLENOID,MANUAL	271N0174 81205	1	29-21-31 1214/154/R050	ALL
M10407		S271N102-1 ACTUATOR-RAT SOLENOID,AUTO	271N0174 81205	1	29-21-31 1214/154/R050	ALL
M10408		285N0029-1 MODULE-STAB POSITION,LEFT	284N1800 81205	1	27-48-21 P050-00/ /	ALL
M10409		285N0029-1 MODULE-STAB POSITION,CENTER	284N1800 81205	1	27-48-21 P050-00/ /	ALL
M10410		285N0029-1 MODULE-STAB POSITION,RIGHT	284N1800 81205	1	27-48-21 P050-00/ /	ALL
M10412		S283N702-108-PROVISIONS- BALLAST-FLUOR LT,L MID FWD GALLEY	417N5114 81205	1	33-27-22 717/289/L032	115-199

EQUIPMENT LIST

D280N032

Section M10400

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10413		S283N702-108-PROVISIONS- BALLAST-FLUOR LT,L MID FWD GALLEY	417N5114 81205	1	33-27-22 717/289/L032	115-199
M10414		417N5114-2-PROVISIONS- MODULE-L MID FWD GALLEY LIGHT ASSY(2D)	417N7002 81205	1	33-27-22 0724/290/L027	115-199
M10417		285N0055-1 MODULE-EICAS DISPLAY SWITCHING	284N1800 81205	1	31-41-11 E004-02/ /	ALL
M10418		285N0055-1 MODULE-EICAS DISPLAY SWITCHING	284N1800 81205	1	31-41-21 E004-02/ /	ALL
M10421	9	285N0041-10 MOD-AURAL WARN CLKER/WLER,L (SB 31-0164)	285N0005 81205	1	31-51-35 P051-00/ /	115-199
M10421		285N0041-10 MODULE-AURAL WARN CLACKER/WAILER,LEFT	285N0005 81205	1	31-51-35 P051-00/ /	009, 115-199
M10422	9	285N0041-10 MOD-AURAL WARN CLKER/WLER,R (SB 31-0164)	285N0005 81205	1	31-51-36 P051-00/ /	115-199
M10422		285N0041-10 MODULE-AURAL WARN CLACKER/WAILER,RIGHT	285N0005 81205	1	31-51-36 P051-00/ /	009, 115-199
M10423		285N0042-12 MODULE-AURAL WARN DECISION HEIGHT	285N0005 81205	1	31-51-34 P051-00/ /	115-199
M10425		285N0028-37 PC ASSY 4-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-12-11 P054-00/ /	003-099
M10425	1	285N0028-35 PC ASSY 4-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-12-11 P054-00/ /	001-002, 115-199
M10425	2	285N0028-24 PC ASSY 4-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-12-11 P054-00/ /	001-002, 115-199
M10425	3	285N0028-23 PC ASSY 4-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-12-11 P054-00/ /	001-002, 115-199
M10426		285N0028-37 PC ASSY 5-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-12-21 P054-00/ /	003-099
M10426	1	285N0028-35 PC ASSY 5-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-12-21 P054-00/ /	001-002, 115-199
M10426	2	285N0028-24 PC ASSY 5-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-12-21 P054-00/ /	001-002, 115-199
M10426	3	285N0028-23 PC ASSY 5-FIRE/OVHT,LOGIC/TEST	284N1328 81205	1	26-12-21 P054-00/ /	001-002, 115-199

EQUIPMENT LIST

D280N032

Section M10400

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10427	5	285N0028-17 PC ASSY 6-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-16-11 P054-00/ /	ALL
M10427	1	285N0028-36 PC ASSY 6-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-16-11 P054-00/ /	ALL
M10427	2	285N0028-21 PC ASSY 6-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-16-11 P054-00/ /	ALL
M10427	3	285N0028-20 PC ASSY 6-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-16-11 P054-00/ /	ALL
M10427	4	285N0028-10 PC ASSY 6-FIRE/OVHT,LOGIC/TEST	284N1329 81205	1	26-16-11 P054-00/ /	ALL
M10428		S283N001-2 PWR SUPPLY CARD-DUCT LEAK AND W/W	280N7101 81205	1	26-18-11 P050-00/ /	ALL
M10438		285T0097-6 PC CARD-DIMMER,TYPE 1,BATT 4	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10439		10167-2001BT MODULE-T/R ISOL VALVE DELAY,R	284N1127 08719	1	78-36-21 P037-00/ /	003-099
M10439 T		MS25171-1S NIPPLE	96906	2	78-36-21 P37/ /	ALL
M10440 T		MS25171-1S NIPPLE	96906	2	78-36-11 P36/ /	ALL
M10443		233N6205-12 PANEL-FIRE CONTROL(SEE YQN++++)	233N6101 81205	1	26-11-11 P008-00/ /	ALL
M10444		233N6203-103 PANEL-APU & CARGO FIRE CONTROL(SEE YQP)	233N6101 81205	1	26-16-11 P008-00/ /	001-008
M10444		233N6203-161 PANEL-APU & CARGO FIRE CONTROL(SEE YQP)	233N6101 81205	1	26-16-11 P008-00/ /	009-099
M10444		233N6203-105 PANEL-APU & CARGO FIRE CONTROL(SEE YQP)	233N6101 81205	1	26-16-11 P008-00/ /	115-199
M10445		233N6204-15 PANEL-FIRE/OVHT TEST(SEE YQQ++++)	233N6101 81205	1	26-11-11 P008-00/ /	001-099
M10445		233N6204-17 PANEL-FIRE/OVHT TEST(SEE YQQ++++)	233N6101 81205	1	26-11-11 P008-00/ /	115-199
M10452		215N1002-15 MODULE-FLT DK TEMP SNSE (SEE YRU++++)	215N1001 81205	1	21-61-11 260/270/L020	ALL

EQUIPMENT LIST

D280N032

Section M10400

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10455		413N3107 MODULE-DOOR 4 PARTITION,LEFT	413N3103 81205	1	23-42-11 / /	ALL
M10458		2156-204A DETECTOR-SMOKE,FWD 1	453N2110 03972	1	26-16-11 635/200/R017	ALL
M10459		2156-204A DETECTOR-SMOKE,FWD 2	453N2110 03972	1	26-16-11 635/200/R012	ALL
M10460		2156-204A DETECTOR-SMOKE,AFT,1	453N2210 03972	1	26-16-11 1352/195/R048	ALL
M10461		2156-204A DETECTOR-SMOKE,AFT,2	453N2210 03972	1	26-16-11 1356/195/R048	ALL
M10462		033638 BLOWER 1-SMOKE DET FWD	453N2110 82877	1	26-16-21 607/203/R015	ALL
M10463		033638 BLOWER 2-SMOKE DET FWD	453N2110 82877	1	26-16-21 607/203/R014	ALL
M10464		033638 BLOWER 3-SMOKE DET AFT	453N2210 82877	1	26-16-21 1353/174/R052	ALL
M10465		033638 BLOWER 4-SMOKE DET AFT	453N2210 82877	1	26-16-21 1356/176/R052	ALL
M10466		S453T201-28 BOTTLE 1-CARGO	453N2220 81205	1	26-23-11 1190/160/L010	ALL
M10467		S453T201-28 BOTTLE 2-CARGO	453N2220 81205	1	26-23-11 1190/160/R010	ALL
M10468		233N3223-51 PANEL-ENGINE START/RAT(SEE YQU++++)	233N3101 81205	1	74-31-11 P005-00/ /	115-199
M10468	2	233N3223-39 PANEL-ENGINE START/RAT(SEE YQU++++)	233N3101 81205	1	74-31-11 P005-00/ /	001-099
M10471		417N3100-126 MODULE-PASSENGER SERVICE UNIT U/B	417N3001 81205	1	33-23-31 MULTI/ /	ALL
M10473		417N3200-4 MODULE-PASSENGER SERVICE UNIT O/D	417N3001 81205	1	33-23-31 MULTI/ /	115-199
M10474		417N3010-2 MODULE-SPEAKER PNL O/D	417N3001 81205	1	23-31-16 MULTI/ /	115-199
M10477		417N3810-2-PROV- MODULE-PASS OXYGEN ASSY,LAV	417N3001 81205	1	35-21-31 MULTI/ /	001-099

EQUIPMENT LIST

D280N032

Section M10400

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10477		417N3810-2 MODULE-PASS OXYGEN ASSY,LAV	417N3001 81205	4	35-21-31 MULTI/ /	115-199
M10479		10167-1202BT TIME DELAY-TEST SAFETY	284N1127 08719	1	30-11-11 P037-00/ /	ALL
M10479 T		MS25171-1S NIPPLE	96906	2	30-11-11 P37/ /	ALL
M10480		285T0464-1 PC CARD-REVERSE CURRENT BLOCKING DIODES	285N0001 81205	1	33-16-11 P026-00/ /	ALL
M10481		285N0078-18 MODULE-PCU MONITOR	284N1800 81205	1	27-23-21 P050-00/ /	ALL
M10482		10167-2001BT MODULE,TIME DELAY,C1	284N1125 08719	1	29-11-31 P036-00/ /	ALL
M10482 T		MS25171-1S NIPPLE	96906	2	29-11-31 P36/ /	ALL
M10486		S414N201-12K MODULE-DOOR 2 SEAT,RIGHT	414N2000 81205	1	23-42-11 / /	115-199
M10490		253T7122-3 RESOLVER ASSY-TLA POSITION,L ENG	254N1058 81205	1	73-21-12 205/199/L012	ALL
M10491		253T7122-3 RESOLVER ASSY-TLA POSITION,R ENG	254N1058 81205	1	73-21-22 190/200/R025	ALL
M10492		S417N507-10 MODULE-FLUOR LAMP/BALLAST ASSY(SEE YRA)	417N5120 81205	1	33-21-14 MULTI/ /	004, 006
M10492		S417N507-20 MODULE-FLUOR LAMP/BALLAST ASSY(SEE YRA)	417N5120 81205	3	33-21-14 MULTI/ /	115-199
M10494		417N3100-121 MODULE-PSU U/B	417N3001 81205	1	33-23-31 MULTI/ /	115-199
M10495		S282N001-4 MONITOR-BAT CURRENT APU	284N1500 30242	1	24-33-12 E006-00/ /	001-099
M10495		S282N001-4 MONITOR-BAT CURRENT APU	284N1686 30242	1	24-33-12 E006-00/ /	115-199
M10496		SM600BA100A1 RCCB-MN/APU BAT TIE	284N1500 27193	1	24-33-12 E006-00/ /	001-099
M10496		SM600BA100A1 RCCB-MN/APU BAT TIE	284N1686 27193	1	24-33-12 E006-00/ /	115-199

EQUIPMENT LIST

D280N032

Section M10400

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10496 T		287N5001-233 FLEX TUBING-WIRE TYPE ZC	81205	1	24-33-12 E6/ /	115-199

EQUIPMENT LIST

D280N032

Section M10400

Page 6 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10534		413N3105 MODULE-DOOR 1 PARTITION,LEFT	413N3101 81205	1	23-42-11 370/244/L037	001-099
M10535		415N7002-6-PROVISIONS- MODULE-L CEILING PNL ASSY,PASS DR 2	415N7001 81205	1	33-22-12 0686/290/L030	115-199
M10549		10-1113-1 MODULE-FLT DK DOME/EMER LT	232N5001 72914	1	33-11-31 292/278/L027	ALL
M10550		S212N101-45 CONTROLLER-REVERSE FLOW CHECK,L	312N5301 81205	1	36-11-11 PPS 144/152/L008	001-099
M10550		S212N101-21 CONTROLLER-REVERSE FLOW CHECK,L	312N5301 81205	1	36-11-11 PPS 144/152/L008	115-199
M10551		S212N101-45 CONTROLLER-REVERSE FLOW CHECK,R	312N5301 81205	1	36-11-21 PPS 144/152/R008	001-099
M10551		S212N101-21 CONTROLLER-REVERSE FLOW CHECK,R	312N5301 81205	1	36-11-21 PPS 144/152/R008	115-199
M10554		S417N101-132A MODULE-LAV G,MID FWD,R(SEE YRN++++)	417N1115 81205	1	25-41-01 0682/290/R042	001-099
M10557		10167-2001-BT MODULE-T/D,L EMP IND	284N1318 08719	1	29-11-12 P033-00/ /	ALL
M10557 T		MS25171-1S NIPPLE	96906	2	29-11-12 P33/ /	ALL
M10558		10167-2001-BT MODULE-T/D,L SYS IND	284N1318 08719	1	29-11-12 P033-00/ /	ALL
M10558 T		MS25171-1S NIPPLE	96906	2	29-11-12 P33/ /	ALL
M10559		10167-2001-BT MODULE-T/D,R EMP IND	284N1125 08719	1	29-11-22 P036-00/ /	ALL
M10559 T		MS25171-1S NIPPLE	96906	2	29-11-22 P36/ /	ALL
M10560		10167-2001-BT MODULE-T/D,R SYS IND	284N1125 08719	1	29-11-22 P036-00/ /	ALL
M10560 T		MS25171-1S NIPPLE	96906	2	29-11-22 P36/ /	ALL
M10571		S360N021-451 UNIT-MONITOR,ENG VIBRATION,R	284N1800 81205	1	77-31-11 E004-02/ /	ALL

EQUIPMENT LIST

D280N032

Section M10500

Page 1

Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10574		285N0096-1 MODULE-HIGH VOLT ISOL	287N1406 81205	1	73-21-12 E002-01/* /	ALL
M10575		285N0096-1 MODULE-HIGH VOLT ISOL	287N1406 81205	1	73-21-12 E002-01/* /	ALL
M10576		285N0094-12 MODULE-HIGH VOLT ISOL	284N1333 81205	1	31-31-44 E003-03/ /	001-099
M10577		285N0094-12 MODULE-HIGH VOLT ISOL	284N1333 81205	1	31-31-44 E003-03/ /	001-099
M10578		285N0096-1 MODULE-HIGH VOLT ISOL	288N1322 81205	1	73-21-12 E002-02/* /	ALL
M10579		285N0096-1 MODULE-HIGH VOLT ISOL	288N1322 81205	1	73-21-12 E002-02/* /	ALL
M10580		285N0094-12 MODULE-HIGH VOLT ISOL	284N1342 81205	1	77-11-11 E004-02/ /	ALL
M10581		285N0094-12 MODULE-HIGH VOLT ISOL	284N1342 81205	1	77-11-11 E004-02/ /	ALL
M10582		285N0094-12 MODULE-HIGH VOLT ISOL	284N1342 81205	1	77-11-11 E004-02/ /	ALL
M10583		285N0094-12 MODULE-HIGH VOLT ISOL	284N1342 81205	1	77-11-11 E004-02/ /	ALL
M10584		285N0089-8 MODULE-L N1 IND	287N4104 81205	1	77-12-11 E004-02/ /	ALL
M10585		285N0089-8 MODULE-R N1 IND	287N4104 81205	1	77-12-11 E004-02/ /	ALL
M10586		285N0094-12 MODULE-HIGH VOLT ISOL	284N1333 81205	1	31-31-44 E003-03/ /	ALL
M10587		285N0094-12 MODULE-HIGH VOLT ISOL	284N1333 81205	1	31-31-44 E003-03/ /	ALL
M10588		S222T101-101 SPEAKER-PSU,MUTED	417N3100 81205	1	23-31-16 MULTI/ /	115-199
M10593		417N3010-8 MODULE-SPEAKER PNL O/D	417N3001 81205	1	23-31-16 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section M10500

Page 2 End

Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10617		287N1404-12 JUMPER ASSY-	284N1127 81205	1	SPARE P037-00/ /	ALL
M10618		287N1404-9 JUMPER ASSY-	284N1127 81205	1	SPARE P037-00/ /	ALL
M10619		287N1404-22 JUMPER ASSY-	284N1127 81205	1	SPARE P037-00/ /	ALL
M10648		S222T101-101 SPKR-PASS ADDRESS	417N3100 81205	1	23-31-42 PSU/ /	004-099
M10653		233N3227-1 MODULE, CAPT DOME LIGHT OVRD	233N3101 81205	1	33-11-14 P005-00/ /	115-199
M10654		S417N101-103A MODULE-LAV S. MID FWD L(SEE YRT++++)	417N1070 81205	1	25-41-01 0656/290/L027	001-099
M10660		287N1404-23 JUMPER ASSY	284N1127 81205	1	SPARE P037-00/ /	ALL
M10661		66079 HYDRAULIC MOTOR GENERATOR (AC/DC)	271N1077 75250	1	24-25-12 1165/168/L003	001-002, 115-199
M10661		S281N002-1 HYDRAULIC MOTOR GENERATOR	271N1077 75250	1	24-25-12 1165/168/L003	003-099
M10662		21428 CONTROL UNIT-GENERATOR,HYDRAULIC DRIVEN	284N1790 75250	1	24-25-11 P071-00/ /	001-002, 115-199
M10662		S281N002-2 CONTROL UNIT-GENERATOR,HYDRAULIC DRIVEN	284N1790 75250	1	24-25-12 P071-00/ /	003-099
M10663	1	10167-5000BT MODULE-TIME DELAY	08719	1	24-25-11 P71/ /	001-002, 115-199
M10664	1	10167-5000BT MODULE-TIME DELAY	08719	1	24-25-11 P71/ /	001-002, 115-199
M10668		RD-AV4003-PROVISION- JUNCTION BOX	417N7303 61058	1	23-32-01 1550/ /	001-099
M10668		RD-AV4003 JUNCTION BOX	417N7303 61058	1	23-32-01 1550/ /	115-199
M10669		RD-AV2132-PROVISION- MONITOR 1	417N7300 61058	1	23-32-01 0408/289/	001-099
M10669		RD-AV2132 MONITOR 1	417N7300 61058	1	23-32-01 0408/289/	115-199

EQUIPMENT LIST

D280N032

Section M10600

Page 1

Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10670		700-1597-001 MONITOR 2	417N7300 97896	1	23-32-01 0392/292/	115-199
M10671		RD-AV2133-PROVISION- MONITOR 3	417N7300 61058	1	23-32-01 0677/292/	001-099
M10671		RD-AV2133 MONITOR 3	417N7300 61058	1	23-32-01 0775/292/	115-199
M10672		RD-AV2133-PROVISION- MONITOR 4	417N7300 61058	1	23-32-01 0819/292/	001-099
M10672		RD-AV2133 MONITOR 4	417N7300 61058	1	23-32-01 0973/292/	115-199
M10673		RD-AV2133-PROVISION- MONITOR 6	417N7300 61058	1	23-32-01 1130-292/ /	001-099
M10673		RD-AV2133 MONITOR 5	417N7300 61058	1	23-32-01 1130/292/	115-199
M10674		RD-AV2133-PROVISION- MONITOR 7	417N7300 TBD	0	23-32-01 1330/ /	001-099
M10674		RD-AV2133 MONITOR 6	417N7300 61058	1	23-32-01 1330/292/	115-199
M10675		RD-AV2133-PROVISION- MONITOR 8	417N7300 61058	1	23-32-01 1460/292/	001-099
M10675		RD-AV2133 MONITOR 7	417N7300 61058	1	23-32-01 1460/292/	115-199
M10680		S417N505-146 LT ASSY-EMERGENCY EXIT SIGN	417N5200 81205	1	33-51-14 1310/288/L017	115-199
M10680 T		0L-2071BPEGPL-PROVISIONS- LAMP	S417N505 S3774	30	33-51-14 1107/290/L021	115-199
M10684		RD-AV4004-PROVISION- INTERFACE BOX FWD	417N7100 61058	1	23-32-01 0432/ /	001-099
M10684		RD-AV4004 INTERFACE BOX FWD	417N7100 61058	1	23-32-01 0770/ /	115-199
M10685		RD-AV4004-PROVISION- INTERFACE BOX AFT	417N7100 61058	1	23-32-01 1292/ /	001-099
M10685		RD-AV4004 INTERFACE BOX AFT	417N7100 61058	1	23-32-01 1330/ /	115-199

EQUIPMENT LIST

D280N032

Section M10600

Page 2

Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10688	1	10167-1002-BT TIME DELAY-10 SEC	284N1127 08719	1	21-58-12 P037-00/ /	ALL
M10688	2	TD-1767-1002 TIME DELAY-10 SEC	284N1127 35344	1	21-58-12 P037-00/ /	ALL
M10689	1	TD1767-7500 TIME DELAY-.75 SEC	284N1125 35344	1	21-58-12 P036-00/ /	ALL
M10689	2	10167-7500-BT TIME DELAY-.75 SEC	284N1125 08719	1	21-58-12 P036-00/ /	ALL
M10690		10167-3001-BT TIME DELAY-3 SEC	284N1125 08719	1	21-58-12 P036-00/ /	ALL
M10691		10167-3001-BT TIME DELAY-3 SEC	284N1125 08719	1	21-58-12 P036-00/ /	ALL
M10699		S283T014-3 POWER SUPPLY-EMERGENCY LIGHTS	417N5201 81205	1	33-51-14 1232/272/R049	ALL

EQUIPMENT LIST

D280N032

Section M10600
Page 3 End
Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10720		S417N511-1 MODULE-FLUOR LAMP/BALLAST(PRIMARY)	417N5106 72914	28	33-21-31 / /	001-003, 005, 007-099
M10720		S417N511-1 MODULE-FLUOR LAMP/BALLAST(PRIMARY)	417N5106 72914	27	33-21-31 / /	004, 006
M10720		S417N511-1 MODULE-FLUOR LAMP/BALLAST(PRIMARY)	417N5106 72914	25	33-21-31 / /	115-199
M10721		S417N511-2 MODULE-FLUOR LAMP/BALLAST(SECONDARY)	417N5106 72914	20	33-21-31 / /	001-099
M10721		S417N511-2 MODULE-FLUOR LAMP/BALLAST(SECONDARY)	417N5106 72914	17	33-21-31 / /	115-199
M10722		S417N511-3 MODULE-FLUOR LAMP/BALLAST(SHORT SINGLE)	417N5106 72914	10	33-21-31 / /	001-003, 005, 007-099
M10722		S417N511-3 MODULE-FLUOR LAMP/BALLAST(SHORT SINGLE)	417N5106 72914	11	33-21-31 / /	004, 006
M10722		S417N511-3 MODULE-FLUOR LAMP/BALLAST(SHORT SINGLE)	417N5106 72914	6	33-21-31 / /	115-199
M10733		RD-AX1017 MULTIPLEXER	284N1800 0FF57	1	23-34-15 E004-04/ /	ALL
M10734		9000003-1 ACCELEROMETER-MODAL SUPPRESSION,LEFT	284N1702 96774	1	22-21-11 1681/205/L030	ALL
M10735		9000003-1 ACCELEROMETER-MODAL SUPPRESSION,RIGHT	284N1702 96774	1	22-21-21 1681/205/R044	ALL
M10748		RD-AX7308-01 TAPE REPRODUCER-PRE-REC ANNOUNCEMENTS	417N6025 0FF57	1	23-31-19 / /	001-099
M10761		233T3242-6 MODULE-EEC CONTROL (SEE YTV++++)	286N4242 81205	1	73-21-12 P005-00/ /	001-099
M10761		233T3242-7 MODULE-EEC CONTROL (SEE YTV++++)	286N4242 81205	1	73-21-12 P005-00/ /	115-199
M10762		417N5210 MODULE-AISLE INDICATOR	417N5200 81205	1	33-51-22 1240/205/L009	ALL
M10763		417N5210 MODULE-AISLE INDICATOR	417N5200 81205	1	33-51-21 820/205/L009	ALL
M10764		417N5210 MODULE-AISLE INDICATOR	400N9001 81205	1	33-51-21 520/205/L009	ALL

EQUIPMENT LIST

D280N032

Section M10700

Page 1

Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10765		417N5210 MODULE-AISLE INDICATOR	417N5200 81205	1	33-51-22 1520/205/L009	ALL
M10769		S220T116-1 ANT TOP ATC	284N1347 81205	1	34-53-11 535/ /	115-199
M10779		RD-AV2133-PROVISION- MONITOR 5	417N7300 61058	1	23-32-01 974/292/	001-099
M10781		S283T019-3 CONT UNIT-DMR,AISLE STAND INSTR & PNL LT	233N2400 81205	1	33-13-52 0251/205/R002	ALL
M10797		RD-AV2133-PROVISION- MONITOR 2	417N7300 61058	1	23-32-01 533/292/	001-099

EQUIPMENT LIST

D280N032

Section M10700
Page 2 End
Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10820		622-8973-001 ANTENNA-TCAS TOP	284N1169 13499	1	34-45-02 426.5/ /	009-099
M10821		622-8973-001 ANTENNA-TCAS BOTTOM	284N1169 13499	1	34-45-02 446.5/ /	009-099
M10895		S251T440-103 MODULE-POSITION TRANSMITTER,CENTER	251N2020 81205	1	27-48-21 1777/190/R025	ALL
M10896		S251T440-103 MODULE-POSITION TRANSMITTER,RIGHT	251N2020 81205	1	27-48-21 1777/190/R030	ALL
M10897		S252U200-201 MODULE-TRIM CONT,STAB,LEFT	251N2012 81205	1	27-41-11 / /	ALL
M10898		S252U200-201 MODULE-TRIM CONT,STAB,RIGHT	251N2012 81205	1	27-41-11 1723/188/R020	ALL
M10899		S251T440-103 MODULE-POSITION TRANSMITTER,LEFT	251N2020 81205	1	27-48-21 1777/185/L025	ALL

EQUIPMENT LIST

D280N032

Section M10800

Page 1 End

Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10901		60B92018-30 UNIT-DENSITOMETER,L MAIN TANK	345N2001 81205	1	28-41-21 IRSS258/ /	ALL
M10902		60B92018-30 UNIT-DENSITOMETER,R MAIN TANK	345N2001 81205	1	28-41-31 WS255/WRP/RMS	ALL
M10903		60B92018-30 UNIT-DENSITOMETER,CTR TANK	345N2001 81205	1	28-41-41 IRSS/160/	ALL
M10908		S283T025-201 ASSY-CONNECTING,L MAIN TANK	345N2001 81205	1	28-41-51 OSS336/ /	001-007
M10909		S283T025-211 ASSY-DAISY CHAIN,L MAIN TANK	345N2001 81205	1	28-41-51 OSS336/ /	001-007
M10910		S283T025-203 ASSY-CONNECTING,L CTR TANK	345N2001 81205	1	28-41-51 ***/*/	001-007
M10911		S283T025-212 ASSY-CONNECTING,L CTR TANK DAISY CHAIN	345N2001 81205	1	28-41-51 ***/*/	001-007
M10912		S283T025-204 ASSY-CONNECTING,R CTR TANK	345N2001 81205	1	28-41-51 0900/WRP/R076	001-007
M10913		S283T025-213 ASSY-CONNECTING,R CTR TANK DAISY CHAIN	345N2001 81205	1	28-41-51 0900/WRP/R076	001-007
M10914		S283T025-201 ASSY-CONNECTING,R MAIN TANK	345N2001 81205	1	28-41-51 OSS360/WRP/RFS	001-007
M10915		S283T025-211 ASSY-CONNECTING,R MAIN TANK DAISY CHAIN	345N2001 81205	1	28-41-51 WS349/WRP/RFS	001-007
M10916		S283T025-202 ASSY-DENSITOMETER CONN,L MAIN TANK	345N2001 81205	1	28-41-21 OSS336/ /	ALL
M10917		S283T025-207 ASSY-CONNECTING,CTR TANK DENSITOMETER	345N2001 81205	1	28-41-41 0900/WRP/R076	ALL
M10918		S283T025-202 ASSY-CONNECTING,R TANK DENSITOMETER	345N2001 81205	1	28-41-31 WS349/WRP/RFS	ALL
M10919		S283T014-3 POWER SUPPLY-EMERGENCY LIGHTS	417N5201 81205	1	33-51-13 840/272/R049	001-006
M10938	9	S28ET019-4 DIMMER CONT UNIT-AUXILIARY	MR69018 81205	1	33-13-32 P012-00/ /	115-199
M10938		S28ET019-4 CONT UNIT-DMR, AUXILARY	233N2400 81205	1	33-13-32 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section M10900

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10955		S283T025-208 ASSY-CONNECTING,L MAIN TANK	345N2001 81205	1	28-41-21 WS342/ /LH	008-099
M10956		S283T025-208 ASSY-CONNECTING,R MAIN TANK	345N2001 81205	1	28-41-31 WS349/WRP/RFS	008-099
M10957		S283T025-205 ASSY-CONNECTING,L CTR TANK	345N2001 81205	1	28-41-41 ***/*	008-099
M10958		S283T025-206 ASSY-CONNECTING,R CTR TANK	345N2001 81205	1	28-41-41 0900/WRP/R076	008-099

EQUIPMENT LIST

D280N032

Section M10900

Page 2 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M11030		S283T014-3 POWER SUPPLY-EMERGENCY LIGHTS	417N5201 81205	1	33-51-14 850/272/R049	007-099

EQUIPMENT LIST

D280N032

Section M11000
Page 1 End
Aug 01/2005



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M11247	9	S67-1575-133 GPS ANT-L	284N1191 81205	1	34-58-11 690/300/L005	115-199
M11248	9	S67-1575-133 GPS ANT-R	284N1191 81205	1	34-58-21 690/300/R005	115-199
M11249	9	822-1821-001 RCVR-MMR, LEFT	284N1800 4V792	1	34-31-11 E002-03/ /	115-199
M11250	9	822-1821-001 RCVR-MMR RIGHT	284N1800 4V792	1	34-31-21 E002-02/ /	115-199
M11251	9	822-1821-001 RCVR-MMR CENTER	284N1800 4V792	1	34-31-31 E002-03/ /	115-199

EQUIPMENT LIST

D280N032

Section M11200

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M11872	9	30283-0101 HOT SHORT PROTECTOR (SB 28A0085)	SB28A0085 81205	1	28-41-41 IRSS165/ /	ALL

EQUIPMENT LIST

D280N032

Section M11800
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00001		S231T100-1 IND-MACH/AIRSPEED,CAPT	233N2101 81205	1	34-13-11 P001-01/* /	001-099
N00001		S231T100-2 IND-MACH/AIRSPEED,CAPT	233N2101 81205	1	34-13-11 P001-01/* /	115-199
N00002		S231T120-1 CLOCK-CAPT	233N2101 81205	1	31-25-11 P001-03/ /	001-003
N00002		60B00303-107 CLOCK-CAPT	233N2101 81205	1	31-25-11 P001-03/* /	004-008
N00002		60B00303-107 CLOCK-CAPT	233N2101 81205	1	31-25-11 P001-01/* /	009-099
N00002		S231T120-1 CLOCK-CAPT	233N2101 81205	1	31-25-11 P001-01/ /	115-199
N00003		S242T403-109 IND-RADIO DISTANCE MAGNETIC,LEFT	233N2101 81205	1	34-22-81 P001-01/* /	001-099
N00004		S242T404-511 IND-ELEX ATTD DIR,CAPT	233N2101 81205	1	34-22-14 P001-00/ /	ALL
N00005		S242T404-611 IND-ELEX HORIZ SITUATION,CAPT	233N2101 81205	1	34-22-15 P001-00/ /	ALL
N00008		S231T101-1 IND-ALTIMETER,CAPT	233N2101 81205	1	34-13-11 P001-03/* /	001-099
N00008		S231T101-1 IND-ALTIMETER,CAPT	233N2101 81205	1	34-13-11 P001-00/ /	115-199
N00009		S231T102-1 IND-VERTICAL SPEED,LEFT	233N2101 81205	1	34-22-82 P001-03/ /	ALL
N00010		S231T231-9 IND-BRAKE PRESSURE	233N2202 81205	1	32-41-11 P003-01/ /	ALL
N00015		S231T280-1 IND-FLAPS POSITION	233N2222 81205	1	27-58-11 P003-01/ /	ALL
N00020		S231T110-6 IND-ATTITUDE/ILS,STANDBY	233N2101 81205	1	34-24-11 P001-03/* /	ALL
N00022		S231T112-1 IND-AIRSPEED,STANDBY	233N2101 81205	1	34-13-11 P001-03/* /	001-099
N00022		S231T112-4 IND-AIRSPEED,STANDBY	233N2101 81205	1	34-13-11 P001-03/* /	115-199

EQUIPMENT LIST

D280N032

Section N00000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00023		S231T113-2 IND-ALTIMETER,STANDBY	233N2101 81205	1	34-13-11 P001-03/*	001-099
N00023		S231T113-7 IND-ALTIMETER,STANDBY	233N2101 81205	1	34-13-11 P001-03/*	115-199
N00029		S271T455-13 IND-REMOTE HYD QTY	271N5024 81205	1	29-33-11 1180/142/L028	ALL
N00041		S231T100-1 IND-MACH/AIRSPEED,F/O	233N2101 81205	1	34-13-21 P003-01/*	001-099
N00041		S231T100-2 IND-MACH/AIRSPEED,F/O	233N2101 81205	1	34-13-21 P003-01/*	115-199
N00042		S231T120-1 CLOCK-F/O	233N2101 81205	1	31-25-11 P003-03/*	001-008
N00042		60B00303-107 CLOCK-F/O	233N2101 81205	1	31-25-11 P003-03/*	009-099
N00042		S231T120-1 CLOCK-F/O	233N2101 81205	1	31-25-11 P003-01/*	115-199
N00043		S242T403-109 IND-RADIO DISTANCE MAGNETIC,RIGHT	233N2101 81205	1	34-22-91 P003-01/*	001-099
N00044		S242T404-511 IND-ELEX ATTD DIR,F/O	233N2121 81205	1	34-22-24 P003-00/ /	ALL
N00045		S242T404-611 IND-ELEX HORIZ SITUATION,F/O	233N2101 81205	1	34-22-25 P003-00/ /	ALL
N00048		S231T101-1 IND-ALTIMETER,F/O	233N2101 81205	1	34-13-21 P003-03/*	001-099
N00048		S231T101-1 IND-ALTIMETER,F/O	233N2101 81205	1	34-13-21 P003-03/ /	115-199
N00049		S231T102-1 IND-VERTICAL SPEED,RIGHT	233N2101 81205	1	34-22-92 P003-03/ /	ALL
N00068		S253T405-6 IND-STAB TRIM POS,F/O	233N4133 81205	1	27-48-11 P010-00/ /	ALL
N00069		S253T405-6 IND-STAB TRIM POS,CAPT	233N4133 81205	1	27-48-11 P010-00/ /	ALL
N00070	9	S241T120-1 ANN-AUTOLAND STATUS,CAPT (SB 22-0072)	233N2101 81205	1	22-14-11 P001-03/ /	115-199

EQUIPMENT LIST

D280N032

Section N00000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00070		S241T120-1 ANN-AUTOLAND STATUS,CAPT	233N2101 81205	1	22-14-11 P001-03/ /	001-099
N00070		S241T120-2 ANN-AUTOLAND STATUS,CAPT	233N2101 81205	1	22-14-11 P001-03/ /	115-199
N00071	9	S241T120-1 ANN-AUTOLAND STATUS,F/O (SB 22-0072)	233N2101 81205	1	22-14-21 P003-01/* /	115-199
N00071		S241T120-1 ANN-AUTOLAND STATUS,F/O	233N2101 81205	1	22-14-21 P003-01/* /	001-099
N00071		S241T120-2 ANN-AUTOLAND STATUS,F/O	233N2101 81205	1	22-14-21 P003-01/* /	115-199
N00083	1	S231T282-2 IND-RUDDER TRIM	233N6101 81205	1	27-28-13 P008-00/* /	ALL
N00083	2	S231T282-1 IND-RUDDER TRIM	233N6101 81205	1	27-28-13 P008-00/* /	ALL
N00099		C5H IND-STANDBY COMPASS	232N4311 61349	1	33-13-12 0231/248/	ALL

EQUIPMENT LIST

D280N032

Section N00000

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N10005		60B50402-14 IND-WATER QUANTITY	417N2106 81205	1	38-14-11 0333/281/R048	115-199
N10006		60B50402-15 IND-WATER QUANTITY	417N2515 81205	1	38-14-11 1654/166/L018	001-099
N10006		60B50402-15 IND-WATER QUANTITY	417N2515 81205	1	38-14-11 1652/158/	115-199
N10013	1	S242T404-611 IND-EICAS UPPER DISPLAY UNIT	232N2101 81205	1	31-41-11 P001-00/ /	ALL
N10013	2	S242T404-610 IND-EICAS UPPER DISPLAY UNIT	232N2101 81205	1	31-41-11 P001-00/ /	ALL
N10014	1	S242T404-611 IND-EICAS LOWER DISPLAY UNIT	232N2101 81205	1	31-41-21 P001-00/ /	ALL
N10014	2	S242T404-610 IND-EICAS LOWER DISPLAY UNIT	232N2101 81205	1	31-41-21 P001-00/ /	ALL
N10015		S231T290-2070 IND-LT SW GND PROX ALERT/G/S INHB	233N2221 81205	1	34-46-11 P001-03/ /	ALL
N10016		S231N001-7 IND-STANDBY ENGINE	233N2101 81205	1	77-12-11 P001-03/ /	ALL
N10017		56517 IND-RUN TIME	284N1690 16476	1	49-72-11 E006-00/ /	001-099
N10017		56517 IND-RUN TIME	284N1471 16476	1	49-72-11 E006-01/ /	115-199
N10023		10-60735-2 IND-CREW OXYGEN PRESSURE	417N4401 07294	1	35-11-13 P073-00/ /	115-199
N10024		S242T403-204 IND-RADIO MAGNETIC,LEFT	233N2101 81205	1	34-22-83 P001-03/ /	115-199
N10025		S242T403-401 ANN-RMI BEARING,LEFT	233N2101 81205	1	34-22-83 P001-03/ /	115-199
N10026		S242T403-204 IND-RADIO MAGNETIC,RIGHT	233N2101 81205	1	34-22-93 P003-03/ /	115-199
N10027		S242T403-401 ANN-RMI BEARING,RIGHT	233N2101 81205	1	34-22-93 P003-03/ /	115-199
N10028		S258T710-4 TACHOMETER-RAT	271N0174 81205	1	29-21-31 1180/138/R018	ALL

EQUIPMENT LIST

D280N032

Section N10000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N10030		S242T403-302 IND-DME,LEFT	233N2101 81205	1	34-55-11 P001-01/ /	115-199
N10031		S242T403-302 IND-DME,RIGHT	233N2101 81205	1	34-55-21 P003-01/ /	115-199
N10032		B56C8CE-172 IND-CYCLE METER	284N1690 10236	1	49-72-11 E006-00/ /	001-099
N10032		B56C8CE-172 IND-CYCLE METER	284N1662 10236	1	49-72-11 E006-00/ /	115-199
N10038		S345N001-010 IND-LOAD SELECT,R MAIN TANK	344N5001 81205	1	28-41-11 P028-00/ /	ALL
N10039		S345N001-010 IND-LOAD SELECT,CTR TANK	344N5001 81205	1	28-41-11 P028-00/ /	ALL
N10040		S345N001-010 IND-LOAD SELECT,L MAIN TANK	344N5001 81205	1	28-41-11 P028-00/ /	ALL

EQUIPMENT LIST

D280N032

Section N10000

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P001-00		233N2101-5006 PNL-CAPT INSTR	230N0901 81205	1	91-02-01 P001-00/ /	001-099
P001-00		233N2101-5003 PNL-CAPT INSTR	230N0901 81205	1	91-02-01 P001-00/ /	115-199
P001-01		233N2220 PNL-CAPT MAIN INSTR	233N2101 81205	1	33-13-11 P001-01/* /	ALL
P001-03		233N2221 PNL-CAPT CTR INSTR	233N2101 81205	1	26-11-11 P001-03/ /	ALL

EQUIPMENT LIST

D280N032

Section P001
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P003-00		233N2101-5006 PNL-F/O INSTR	230N0901 81205	1	91-02-02 P003-00/* /	001-099
P003-00		233N2101-5003 PNL-F/O INSTR	230N0901 81205	1	91-02-02 P003-00/* /	115-199
P003-01		233N2222 PNL-F/O CTR INSTR	233N2101 81205	1	27-51-21 P003-01/ /	ALL
P003-03		233N2223 PNL-F/O MAIN INSTR	233N2101 81205	1	91-02-02 P003-01/* /	ALL

EQUIPMENT LIST

D280N032

Section P003
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P005-00		233N3101 PNL-PLT OVHD	230N0901 81205	1	91-02-03 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section P005
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P006-00		287N4102-15 PANEL-MAIN POWER DISTRIBUTION	287N4101 81205	1	91-02-04 P006-00/ /	001-099
P006-00		287N4102-217 PANEL-MAIN POWER DISTRIBUTION	287N4101 81205	1	91-02-04 P006-00/ /	115-199

EQUIPMENT LIST

D280N032

Section P006
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P007-00		233N8100 PNL-GLARESHIELD	233N2101 81205	1	91-02-08 P007-00/* /	ALL

EQUIPMENT LIST

D280N032

Section P007
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P008-00		233N6101-5006 PNL-ELECTRONICS,AFT	230N0901 81205	1	91-02-09 P008-00/*/	001-099
P008-00		233N6101-5003 PNL-ELECTRONICS,AFT	230N0901 81205	1	91-02-09 P008-00/*/	115-199

EQUIPMENT LIST

D280N032

Section P008
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P009-00		233N6101-5006 PNL-ELETRONICS,FWD	230N0901 81205	1	91-02-09 P009-00/ /	001-099
P009-00		233N6101-5003 PNL-ELETRONICS,FWD	230N0901 81205	1	91-02-09 P009-00/ /	115-199

EQUIPMENT LIST

D280N032

Section P009
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P010-00		233N6101-5006 STAND-QUADRANT	230N0901 81205	1	91-02-10 P010-00/ /	001-099
P010-00		233N6101-5003 STAND-QUADRANT	230N0901 81205	1	91-02-10 P010-00/ /	115-199

EQUIPMENT LIST

D280N032

Section P010
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P011-00		233N5101 PNL-OVHD CIRCUIT BREAKER	230N0901 81205	1	91-02-11 P011-00/ /	001-099
P011-00		233N5101-5007 PNL-OVHD CIRCUIT BREAKER	230N0901 81205	1	91-02-11 P011-00/ /	115-199
P011-01		233N5205 PNL ASSY-CIRCUIT BREAKER	233N5101 81205	1	91-02-11 P011-00/* /	001-099
P011-01		233N5205-17 PNL ASSY-CIRCUIT BREAKER	233N5101 81205	1	91-02-11 P011-00/ /	115-199
P011-02		233N5206 PNL ASSY-CIRCUIT BREAKER	233N5101 81205	1	91-02-12 P011-00/* /	001-099
P011-02		233N5206-17 PNL ASSY-CIRCUIT BREAKER	233N5101 81205	1	91-02-12 P011-00/ /	115-199
P011-03		233N5207 PNL ASSY-CIRCUIT BREAKER	233N5101 81205	1	91-02-13 P011-00/ /	001-099
P011-03		233N5207-17 PNL ASSY-CIRCUIT BREAKER	233N5101 81205	1	91-02-13 P011-00/ /	115-199
P011-04		233N5208 PNL ASSY-CIRCUIT BREAKER	233N5101 81205	1	91-02-14 P011-00/ /	001-099
P011-04		233N5208-17 PNL ASSY-CIRCUIT BREAKER	233N5101 81205	1	91-02-14 P011-00/ /	115-199

EQUIPMENT LIST

D280N032

Section P011
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P013-00		233N7101-5005 PNL-CAPT AUX INSTR,FWD	230N0901 81205	1	91-01-21 P013-00/* /	001-099
P013-00		233N7101-5002 PNL-CAPT AUX INSTR,FWD	230N0901 81205	1	91-01-21 P013-00/ /	115-199

EQUIPMENT LIST

D280N032

Section P013
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P014-00		233N7101-5005 PNL-F/O AUX INSTR,FWD	230N0901 81205	1	91-01-21 P014-00/* /	001-099
P014-00		233N7101-5002 PNL-F/O AUX INSTR,FWD	230N0901 81205	1	91-01-21 P014-00/ /	115-199

EQUIPMENT LIST

D280N032

Section P014
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P017-00		233N7101-5005 PNL-FIRST OBSERVER INSTR	230N0901 81205	1	91-01-21 P017-00/* /	001-099
P017-00		233N7101-5002 PNL-FIRST OBSERVER INSTR	230N0901 81205	1	91-01-21 P017-00/ /	115-199

EQUIPMENT LIST

D280N032

Section P017
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P021-00		417N6002-51 PNL-ATTENDANT,FWD	417N6001 81205	1	33-22-11 379/265/L037	001-099
P021-00		417N6002-31 PNL-ATTENDANT,FWD	417N6001 81205	1	33-22-11 0340/265/L024	115-199

EQUIPMENT LIST

D280N032

Section P021
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P022-00		417N6002-6 PNL-ATTENDANT,AFT	417N6001 81205	1	33-22-14 1638/264/L033	001-099
P022-00		417N6002-2 PNL-ATTENDANT,AFT	417N6001 81205	1	33-22-14 1638/233/L057	115-199

EQUIPMENT LIST

D280N032

Section P022

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P023-00		417N6012-TBD PNL-ATTENDANT,MID(DOOR 2LH)	417N6001 81205	1	33-22-12 682/265/L030	001-099

EQUIPMENT LIST

D280N032

Section P023
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P025-00		146N3640-1 PNL-WATER SERVICE	146N3600 81205	1	38-14-11 1654/166/L018	ALL

EQUIPMENT LIST

D280N032

Section P025
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P026-00		285N0001-32 PNL-LIGHTING EQUIPMENT	287N4101 81205	1	33-16-11 0297/228/R046	001-099
P026-00		285N0001-31 PNL-LIGHTING EQUIPMENT	287N4101 81205	1	33-16-11 0297/228/R046	115-199

EQUIPMENT LIST

D280N032

Section P026
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P028-00		344N5101 PNL-FUELING	344N5001 81205	1	28-21-11 0503/* /	ALL

EQUIPMENT LIST

D280N032

Section P028
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P030-00		284N1412 PNL-EXT PWR RCPT PNL	284N1410 81205	1	24-41-11 424/155/R015	ALL

EQUIPMENT LIST

D280N032

Section P030
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P031-00		284N1314 PANEL-LEFT GEN PWR	284N1317 81205	1	91-02-17 0400/180/	ALL

EQUIPMENT LIST

D280N032

Section P031
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P032-00		284N1315 PANEL-R GEN PWR	284N1317 81205	1	91-02-18 0400/180/R020	ALL

EQUIPMENT LIST

D280N032

Section P032
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P033-00		284N1318 PANEL-MISC RELAY	284N1325 81205	1	91-02-19 0360/180/R025	ALL

EQUIPMENT LIST

D280N032

Section P033
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P034-00		284N1316 PANEL-APU/EXT POWER	284N1317 81205	1	91-02-20 0400/180/L020	ALL

EQUIPMENT LIST

D280N032

Section P034
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P036-00		284N1125-1 PANEL-MISC ELEC EQUIP	284N1525 81205	1	91-02-23 0510/167/R030	ALL

EQUIPMENT LIST

D280N032

Section P036
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P037-00		284N1127-1 PANEL-MISC ELEC EQUIP,R	284N1526 81205	1	91-02-26 0450/192/R046	ALL

EQUIPMENT LIST

D280N032

Section P037
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P041-00		284N1339 CONT PNL-INT,NO.1 CARGO DOOR	284N0900 81205	1	52-34-11 0580/196/R014	ALL

EQUIPMENT LIST

D280N032

Section P041
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P042-00		284N1339 CONT PNL-INT,NO.2 CARGO DR	284N0900 81205	1	52-35-11 1400/195/R014	ALL

EQUIPMENT LIST

D280N032

Section P042
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P043-00		284N1338 CONT PNL-EXT,NO.1 CARGO DR	284N0900 81205	1	52-34-11 0629/170/R050	ALL

EQUIPMENT LIST

D280N032

Section P043
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P044-00		284N1338 CONT PNL-EXT,NO.2 CARGO DR	284N0900 81205	1	52-35-11 1449/170/R050	ALL

EQUIPMENT LIST

D280N032

Section P044
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P050-00		284N1327 PNL-ELEC SYS CARD FILE	284N1329 81205	1	21-51-11 P050-00/*/	001-099
P050-00		285N0032-5 PNL-ELEC SYS CARD FILE	284N1329 81205	1	21-51-11 P050-00/*/	115-199

EQUIPMENT LIST

D280N032

Section P050
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P051-00		284N1328 PNL-WARN ELEX CARD FILE	284N1329 81205	1	91-02-32 P051-00/*	ALL

EQUIPMENT LIST

D280N032

Section P051
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P054-00		285N0031-4 PNL-FIRE DET CARD FILE	284N1329 81205	1	26-11-11 P054-00/* /	ALL

EQUIPMENT LIST

D280N032

Section P054
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P055-00		233N2301 PNL-GLARE SHIELD,CTR	233N2101 81205	1	91-02-08 P055-00/ /	ALL

EQUIPMENT LIST

D280N032

Section P055
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P061-00		233N7401-5007 PNL-SIDEWALL	230N0901 81205	1	91-02-16 P061-00/*/	001-099
P061-00		233N7401-5004 PNL-SIDEWALL	230N0901 81205	1	91-02-16 P061-00/*/	115-199

EQUIPMENT LIST

D280N032

Section P061
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P062-00		284N1758-6 CONT PNL-NLG-R	284N1761 81205	1	33-42-11 0388/120/	001-099
P062-00		284N1758-7 CONT PNL-NLG-R	284N1761 81205	1	33-42-11 0388/120/	115-199

EQUIPMENT LIST

D280N032

Section P062
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P063-00		284N1758-5 CONT PNL-NLG-L	284N1761 81205	1	33-42-11 388/120/	ALL

EQUIPMENT LIST

D280N032

Section P063
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P065-00		284N1747-3 EQUIPMENT PANEL-MISC ELECT	284N1746 81205	1	33-37-11 0456/158/R020	001-099
P065-00		284N1747-7 EQUIPMENT PANEL-MISC ELECT	284N1746 81205	1	33-37-11 0456/158/R020	115-199

EQUIPMENT LIST

D280N032

Section P065
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P069-00		284T0032-2 RELAY PANEL	284N1542 81205	1	31-41-11 E004-02/ /	ALL

EQUIPMENT LIST

D280N032

Section P069
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P070-00		284N1129-1 PANEL-MISC ELEC EQUIP	284N1527 81205	1	91-02-35 0460/190/L050	ALL

EQUIPMENT LIST

D280N032

Section P070
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P071-00		284N1790 PANEL ASSY-HYDRAULIC GENERATOR CONTROL	284N1790 81205	1	24-25-11 0520/189/R054	ALL

EQUIPMENT LIST

D280N032

Section P071
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P072-00		284N1745 PNL-RIGHT W/W ELEC SERVICE	284N1446 81205	1	32-12-11 1224/136/R012	001-099
P072-00		284N1745 PNL-MAIN W/W ELEC SERVICE	284N1446 81205	1	32-12-11 1205/137/R025	115-199

EQUIPMENT LIST

D280N032

Section P072
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P073-00		417N4401-1 PNL-CREW OXYGEN REMOTE FILL	417N4400 81205	1	35-11-13 0623/188/R054	115-199

EQUIPMENT LIST

D280N032

Section P073
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P076-00		417N6011-6 PNL-ATTENDANT,MID(DOOR 2 RH)	417N6010 81205	1	33-22-12 0682/238/R047	115-199

EQUIPMENT LIST

D280N032

Section P076
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P080-00		284N1745 PNL-LEFT W/W ELEC SERVICE	284N1446 81205	1	32-12-12 1224/136/L012	001-099

EQUIPMENT LIST

D280N032

Section P080
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
QD0001		TSE-20-01 QUICK DISCONNECT	11139	1	SPARE 233- / /	ALL
QD0002		TSE-20-01 QUICK DISCONNECT	11139	1	SPARE 233- / /	ALL
QD0003		TSE-20-01 QUICK DISCONNECT	11139	1	SPARE 233- / /	ALL
QD0004		TSE-20-01 QUICK DISCONNECT	11139	1	SPARE 233- / /	ALL
QD0005		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 233/ /	ALL
QD0006		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 233/ /	ALL
QD0007		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 233/ /	ALL
QD0008		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 233/ /	ALL
QD0009		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-11 233/ /	ALL
QD0010		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-11 233/ /	ALL
QD0011		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 233/ /	ALL
QD0012		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 233/ /	ALL
QD0013		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 233/ /	ALL
QD0014		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 233/ /	ALL
QD0015		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 233/ /	ALL
QD0016		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-11 233/ /	ALL
QD0017		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-32 233/ /	ALL

EQUIPMENT LIST

D280N032

Section QD0000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
QD0018		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 233/ /	ALL
QD0019		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 233/ /	ALL
QD0020		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-32 233/ /	ALL
QD0021		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-11 233/ /	ALL
QD0022		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-21 233/ /	ALL
QD0023		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-21 233/ /	ALL
QD0024		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-21 233/ /	ALL
QD0025		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-21 233/ /	ALL
QD0026		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-12 233/ /	ALL
QD0027		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-12 233/ /	ALL
QD0028		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 233/ /	ALL
QD0029		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 233/ /	ALL
QD0030		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 233/ /	ALL
QD0031		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 233/ /	ALL
QD0032		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-21 233/ /	ALL
QD0033		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-12 233/ /	ALL
QD0034		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-32 233/ /	ALL

EQUIPMENT LIST

D280N032

Section QD0000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
QD0035		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 233/ /	ALL
QD0036		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 233/ /	ALL
QD0037		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-32 233/ /	ALL
QD0038		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-12 233/ /	ALL
QD0039		TSE-20-01 QUICK DISCONNECT	11139	1	SPARE 233-/ /	ALL
QD0040		TSE-20-01 QUICK DISCONNECT	11139	1	SPARE 233-/ /	ALL
QD0041		TSE-20-01 QUICK DISCONNECT	11139	1	SPARE 233-/ /	ALL
QD0042		TSE-20-01 QUICK DISCONNECT	11139	1	SPARE 233-/ /	ALL

EQUIPMENT LIST

D280N032

Section QD0000

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00001		YHLZD-33 DIODE-(TB0111)	286N2072 09922	1	24-51-31 P011-00/* /	001-099
R00001		YHLZD-33 DIODE-(TB0111)	286N0122 09922	1	24-51-31 P011-00/* /	115-199
R00002		YHLZD-33 DIODE-(TB0111)	286N2072 09922	1	24-51-31 P011-00/* /	001-099
R00002		YHLZD-33 DIODE-(TB0111)	286N0122 09922	1	24-51-31 P011-00/* /	115-199
R00003		YHLZD-33 DIODE-(TB0111)	286N2072 09922	1	24-51-31 P011-00/* /	001-099
R00003		YHLZD-33 DIODE-(TB0111)	286N0122 09922	1	24-51-31 P011-00/* /	115-199
R00004		YHLZD-33 DIODE-GCB TRIP ISOL,LEFT (TB0131)	286N1136 09922	1	24-22-11 P031-00/* /	ALL
R00005		YHLZD-33 DIODE-GCB TRIP ISOL,RIGHT (TB0132)	286N1138 09922	1	24-22-21 P032-00/ /	ALL
R00006		YHLZD-33 DIODE-APB TRIP ISOL (TB0134)	286N1128 09922	1	24-22-41 P034-00/* /	ALL
R00007		YHLZD-33 DIODE-BTB TRIP ISOL,LEFT (TB0131)	286N1136 09922	1	24-22-12 P031-00/* /	ALL
R00008		YHLZD-33 DIODE-BTB TRIP ISOL,RIGHT (TB0132)	286N1138 09922	1	24-22-22 P032-00/ /	ALL
R00011		JANTX1N1206A DIODE-APU CONT,MAIN	284N1680 81205	1	49-61-11 E006-00/ /	ALL
R00012		JANTX1N1206A DIODE-APU CONT,BATT	284N1680 81205	1	49-61-11 E006-00/ /	ALL
R00058		YHLZD-33 DIODE	286N2156 09922	1	23-51-21 272/280/L015	ALL
R00059		YHLZD-33 DIODE	286N2156 00922	1	23-51-11 272/280/L015	ALL
R00060		YHLZD-33 DIODE	286N2156 09922	1	23-51-21 272/280/L015	ALL
R00061		YHLZD-33 DIODE	286N2156 09922	1	23-51-11 272/280/L015	ALL

EQUIPMENT LIST

D280N032

Section R00000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00108	1	YHLZD-33 DIODE-ISOLATION(TB163B)	284N1319 09922	1	26-16-21 P036-00/*	ALL
R00108	2	YHLZD-30 DIODE-ISOLATION(TB163B)	284N1319 09922	1	26-16-21 P036-00/*	ALL
R00109	1	YHLZD-33 DIODE-ISOLATION(TB163B)	284N1319 09922	1	26-16-21 P036-00/*	ALL
R00109	2	YHLZD-30 DIODE-ISOLATION(TB163B)	284N1319 09922	1	26-16-21 P036-00/*	ALL
R00129		YHLZD-32 DIODE-ALTN ANTISKID BLOCKING	284N1125 09922	1	32-42-11 P036-00/*	ALL
R00193		YHLZD-33 DIODE-L ENG FIRE BAT BUS ISOL	286N0134 09922	1	26-11-11 */*	ALL
R00194		YHLZD-33 DIODE-L ENG FIRE R BUS ISOL	286N0134 09922	1	26-11-11 /*	ALL
R00197		YHLZD-33 DIODE-R ENG FIRE BAT BUS ISOL	286N0134 09922	1	26-11-21 /*	ALL
R00198		YHLZD-33 DIODE-R ENG FIRE R BUS ISOL	286N0134 09922	1	26-11-21 */*	ALL

EQUIPMENT LIST

D280N032

Section R00100
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00201		YHLZD-33 DIODE-APU FIRE BAT BUS ISOL	286N0134 09922	1	26-15-11 */*/	ALL
R00202		YHLZD-33 DIODE-APU FIRE R BUS ISOL	286N0134 09922	1	26-15-11 */*/	ALL
R00203		YHLZD-33 DIODE-CARGO SMOKE BAT BUS ISOL	286N0134 09922	1	26-16-11 */*/	ALL
R00204		YHLZD-33 DIODE-CARGO SMOKE R BUS ISOL	286N0134 09922	1	26-16-11 */*/	ALL
R00217		YHLZD-33 DIODE	286N2156 09922	1	32-42-12 272/280/L015	ALL
R00218		YHLZD-33 DIODE	286N2156 09922	1	32-42-11 272/280/L015	ALL

EQUIPMENT LIST

D280N032

Section R00200

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00503		26416 RHEOSTAT-LIGHT,CAPT CHART	233N8200 95266	1	33-14-21 P007-00/ /	ALL
R00504		26416 RHEOSTAT-LIGHT,F/O CHART	233N8200 95266	1	33-14-21 P007-00/ /	ALL
R00505		26405 RHEOSTAT-MAP LT,CAPT	233N8200 95266	1	33-14-11 P007-00/ /	ALL
R00506		26405 RHEOSTAT-MAP LT,F/O	233N8200 95266	1	33-14-11 P007-00/ /	ALL
R00507		86A2EZ28BA0689 POTENTIOMETER-PNL FLDT CONT,CAPT & CTR	55578	1	33-11-11 P007-00/ /	ALL
R00508		86A2EZ28BA0689 POTENTIOMETER-PNL FLDT CONT,CAPT & CTR	55578	1	33-11-11 P007-00/ /	ALL
R00511		WA03923A POTENTIOMETER-CAPT INSTR & PNL LT CONT	55578	1	33-13-11 P007-00/ /	ALL
R00512		WA03923A POTENTIOMETER-F/O INSTR & PNL LT CONT	55578	1	33-13-21 P007-00/ /	ALL
R00531		YHLZR-17 RESISTOR ASSY-BTB INHIB PULLUP (TB134B)	286N1128 09922	1	24-41-11 P034-00/*/	ALL

EQUIPMENT LIST

D280N032

Section R00500

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10044		YHLZD-33 DIODE-BLOCKING (TB166A)	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10050		YHLZD-15 DIODE-BLOCKING,AFT CARGO FAN	284N1127 09922	1	21-44-11 P037-00/ /	ALL
R10074		YHLZD-33 DIODE-BLOCKING	284N1127 09922	1	21-58-12 P037-00/ /	ALL
R10076		YHLZD-33 DIODE-APU OFF LIGHT ISOL	284N1600 09922	1	24-27-41 E006-00/ /	ALL
R10077		YHLZD-33 DIODE-ISOLATION	284N1680 09922	1	49-61-11 E006-00/ /	001-099
R10077	1	YHLZD-33 DIODE-ISOLATION	284N1680 09922	1	49-61-11 E006-00/ /	115-199
R10077	2	YHLZD-30 DIODE-ISOLATION	284N1680 09922	1	49-61-11 E006-00/ /	115-199
R10085		YHLZR-10 RESISTOR-PULLUP	286N1433 09922	6	31-31-13 / /	115-199
R10088		YHLZD-33 DIODE-ISOL 1 (TB166A)	284N1125 09922	1	26-15-11 P036-00/ /	ALL
R10089		YHLZD-33 DIODE-ISOL 2(TB165C)	284N1125 09922	1	26-15-11 P036-00/ /	ALL
R10096		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-11 P036-00/ /	115-199

EQUIPMENT LIST

D280N032

Section R10000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10102		YHLZD-26 DIODE-FLT DK ZONE INOP	284N1127 09922	1	21-61-11 P037-00/ /	ALL
R10103		YHLZD-26 DIODE-FWD CAB ZONE INOP	286N1270 09922	1	21-61-21 P037-00/ /	ALL
R10104		YHLZD-26 DIODE-AFT CAB ZONE INOP	286N1127 09922	1	21-61-31 P037-00/ /	ALL
R10105		YHLZR-22 RESISTOR-KVA LIMITER (M225)	284N1315 09922	1	25-31-21 P032-00/ /	115-199
R10107		YHLZR-27 RESISTOR-KVA LIMITER(M227)	286N1314 81205	1	25-31-33 P031-00/ /	001-099
R10108		YHLZD-15 DIODE-BLOCKING,SMOKE LIGHT,FWD EQUIP	284N1127 09922	1	21-58-12 P037-00/ /	115-199
R10110		YHLZD-15 DIODE-BLOCKING,SMOKE RLY,AFT EQUIP	284N1125 09922	1	21-58-12 P036-00/ /	115-199
R10111		YHLZR-30 RESISTOR-IDG OIL TEMP METER,L	286N1203 09922	1	24-11-11 540/ /	ALL
R10112		YHLZR-30 RESISTOR-IDG OIL TEMP METER,R	286N1203 09922	1	24-11-21 540/ /	ALL
R10119		YHLZD-33 DIODE 1-START IND,L	284N1125 09922	1	80-11-11 P036-00/ /	ALL
R10120		YHLZD-33 DIODE 1-START IND,R	284N1127 09922	1	80-11-21 P037-00/ /	ALL
R10125	1	YHLZD-33 DIODE-ISOL 3(TB165C)	284N1125 09922	1	26-15-11 P036-00/ /	ALL
R10125	2	YHLZD-29 DIODE-ISOL 3(TB165C)	284N1125 09922	1	26-15-11 P036-00/ /	ALL
R10126		YHLZD-29 DIODE-CAPT PITOT	284N1125 09922	1	30-31-11 P036-00/ /	ALL
R10127		YHLZD-33 DIODE-L AUX PITOT (TB160A)	284N1125 09922	1	30-31-11 P036-00/ /	ALL
R10128		YHLZD-29 DIODE-F/O PITOT	284N1125 09922	1	30-31-12 P036-00/ /	ALL
R10129		YHLZD-33 DIODE-R AUX PITOT (TB179A)	284N1125 09922	1	30-31-12 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section R10100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10130	1	YHLZD-33 DIODE-ISOL L ENG,1(TB158)	286N4228 09922	1	26-11-11 P008-00/ /	ALL
R10130	2	YHLZD-29 DIODE-ISOL L ENG,1(TB158)	286N4228 09922	1	26-11-11 P008-00/ /	ALL
R10131	1	YHLZD-33 DIODE-ISOL L ENG,2(TB158)	286N4228 09922	1	26-11-11 P008-00/ /	ALL
R10131	2	YHLZD-29 DIODE-ISOL L ENG,2(TB158)	286N4228 09922	1	26-11-11 P008-00/ /	ALL
R10132	1	YHLZD-33 DIODE-ISOL R ENG,1(TB159)	286N4236 09922	1	26-11-21 P008-00/ /	ALL
R10132	2	YHLZD-29 DIODE-ISOL R ENG,1(TB159)	286N4236 09922	1	26-11-21 P008-00/ /	ALL
R10133	1	YHLZD-33 DIODE-ISOL R ENG,2(TB159)	286N4236 09922	1	26-11-21 P008-00/ /	ALL
R10133	2	YHLZD-29 DIODE-ISOL R ENG,2(TB159)	286N4236 09922	1	26-11-21 P008-00/ /	ALL
R10134	1	YHLZD-33 DIODE-ISOL APU,2(TB158A)	286N2134 09922	1	26-15-11 P008-00/ /	ALL
R10134	2	YHLZD-29 DIODE-ISOL APU,2(TB158A)	286N2134 09922	1	26-15-11 P008-00/ /	ALL
R10135	1	YHLZD-33 DIODE-ISOL APU,1(TB158A)	286N2134 09922	1	26-15-11 P008-00/ /	ALL
R10135	2	YHLZD-29 DIODE-ISOL APU,1(TB158A)	286N2134 09922	1	26-15-11 P008-00/ /	ALL
R10136	1	YHLZD-33 DIODE-ISOL R ENG,3(TB159)	286N4236 09922	1	26-11-21 P008-00/ /	ALL
R10136	2	YHLZD-29 DIODE-ISOL R ENG,3(TB159)	286N4236 09922	1	26-11-21 P008-00/ /	ALL
R10137	1	YHLZD-33 DIODE-ISOL L ENG,3(TB158)	286N4228 09922	1	26-11-11 P008-00/ /	ALL
R10137	2	YHLZD-29 DIODE-ISOL L ENG,3(TB158)	286N4228 09922	1	26-11-11 P008-00/ /	ALL
R10138		YHLZD-33 RECTIFIER	284N1690 09922	1	24-31-41 E006-00/ /	115-199

EQUIPMENT LIST

D280N032

Section R10100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10139		JANTX1N3315B DIODE-ZENER,BPCU	285N0001 81205	1	33-16-11 P026-00/ /	ALL
R10140		YHLZD-33 DIODE 2-START IND,R	284N1127 09922	1	80-11-21 P037-00/ /	ALL
R10141		YHLZD-33 DIODE 2-START IND,L	284N1125 09922	1	80-11-11 P036-00/ /	ALL
R10142		YHLZR-29 RESISTOR-APU RPM	284N1307 09922	1	49-73-11 / /	ALL
R10143		YHLZR-29 RESISTOR-APU EGT	284N1307 09922	1	49-71-11 /***/	ALL
R10144	1	YHLZD-33 DIODE-BLOCKING	286N1275 09922	1	26-17-11 E004-02/ /	ALL
R10144	2	YHLZD-29 DIODE-BLOCKING	286N1275 09922	1	26-17-11 E004-02/ /	ALL
R10151	1	CSK21120 FILTER-L/C	284N1542 56289	1	27-18-11 E004-02/ /	ALL
R10151	2	9000-103-0192-A FILTER-L/C	284N1542 56289	1	27-18-11 E004-02/ /	ALL
R10152	1	CSK21120 FILTER-L/C	284N1542 56289	1	27-18-11 E004-02/ /	ALL
R10152	2	9000-103-0192-A FILTER-L/C	284N1542 56289	1	27-18-11 E004-02/ /	ALL
R10153		YHLZD-33 DIODE-PTU ISOLATION	286N1270 09922	1	29-22-11 P037-00/ /	001-099
R10153	1	YHLZD-33 DIODE-PTU ISOLATION	286N1270 09922	1	29-22-11 P037-00/ /	115-199
R10153	2	YHLZD-29 DIODE-PTU ISOLATION	286N1270 09922	1	29-22-11 P037-00/ /	115-199
R10168		YHLZD-33 DIODE-BLOCKING, L PRSOV/HP6 (TB166A)	284N1125 09922	1	36-11-11 P036-00/ /	ALL
R10169		YHLZD-15 DIODE-BLOCKING, R PRSOV/HP6	284N1127 09922	1	36-11-21 P037-00/ /	ALL
R10170		YHLZD-15 DIODE-BLOCKING	284N1127 09922	1	21-58-12 P037-00/ /	115-199

EQUIPMENT LIST

D280N032

Section R10100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10171		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10172		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10173		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-11 P036-00/ /	ALL
R10174		YHLZD-33 DIODE-BLOCKING (TB166A)	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10178		JANTXIN3312B DIODE-ZENER,DOME LIGHT	285N0001 81205	1	33-16-11 P026-00/ /	001-099
R10178		JANTXIN3312B DIODE-ZENER,DOME LIGHT	284N0001 81205	1	33-16-11 P026-00/ /	115-199
R10179		YHLZD-33 DIODE-BLOCKING	284N1127 09922	1	21-58-12 P037-00/ /	ALL
R10180		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10181		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10183	1	YHLZD-33 DIODE-FWD ISOLATION(TB163B)	284N1319 09922	1	26-16-21 P036-00/ /	ALL
R10183	2	YHLZD-30 DIODE-FWD ISOLATION(TB163B)	284N1319 09922	1	26-16-21 P036-00/ /	ALL
R10184	1	YHLZD-33 DIODE-AFT ISOLATION(TB163B)	284N1319 09922	1	26-16-21 P036-00/ /	ALL
R10184	2	YHLZD-30 DIODE-AFT ISOLATION(TB163B)	284N1319 09922	1	26-16-21 P036-00/ /	ALL
R10194		YHLZD-29 DIODE-ISOL HYD,L	284N1307 09922	1	29-33-11 E004-02/ /	ALL
R10195		YHLZD-29 DIODE-ISOL HYD,C	284N1307 09922	1	29-33-11 E004-02/ /	ALL
R10196		YHLZD-29 DIODE-ISOL HYD,R	284N1307 09922	1	29-33-11 E004-02/ /	ALL
R10197		YHLZD-29 DIODE-ISOL HYD RESERVOIR,L	284N1307 09922	1	29-33-11 E004-02/ /	ALL

EQUIPMENT LIST

D280N032

Section R10100

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10198		YHLZD-29 DIODE-ISOL HYD RESERVOIR,C	284N1307 09922	1	29-33-11 E004-02/ /	ALL
R10199		YHLZD-29 DIODE-ISOL HYD RESERVOIR,R	284N1307 09922	1	29-33-11 E004-02/ /	ALL

EQUIPMENT LIST

D280N032

Section R10100
Page 5 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10202		YHLZR-21 RESISTOR-L EGT	286N1275 09922	1	77-21-11 E004-02/ /	001-099
R10203		YHLZR-21 RESISTOR-R EGT	286N1275 09922	1	77-21-11 E004-02/ /	001-099
R10204		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10205		YHLZD-33 DIODE-ISOL,L ELEC PUMP PRESS LT(TB0113A)	286N2156 09922	1	29-11-12 P005-00/ /	ALL
R10207		YHLZR-17 RESISTOR-ISOL,L ELEC PUMP PRESS LT	286N2070 09922	1	29-11-12 P005-00/ /	ALL
R10209		YHLZD-33 DIODE-ISOL,R ELEC PUMP PRESS LT(TB0111A)	286N0122 09922	1	29-11-22 P005-00/ /	ALL
R10211		YHLZR-17 RESISTOR-ISOL,R ELEC PUMP PRESS LT	286N2066 09922	1	29-11-22 P005-00/ /	ALL
R10213		YHLZD-33 DIODE-ISOL,AUTO SPEED BRAKE LT	284N1127 09922	1	27-62-11 P037-00/ /	ALL
R10214		YHLZR-17 RESISTOR-ISOL,AUTO SPEED BRAKE LT	284N1127 09922	1	27-62-11 P037-00/ /	ALL
R10215	1	YHLZD-33 DIODE-NO. 3 CARGO DOOR WARN IND	284N1307 09922	1	52-71-21 E003-04/ /	115-199
R10215	2	YHLZD-15 DIODE-NO. 3 CARGO DOOR WARN IND	284N1307 09922	1	52-71-21 E003-04/ /	115-199
R10218		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10220		YHLZD-29 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	115-199
R10221		YHLZD-33 DIODE-BLOCKING (TB166A)	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10222		YHLZD-29 DIODE-LDG GR LEVER ISOLATION	284N1316 09922	1	33-42-11 P034-00/ /	ALL
R10223		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-25-11 P036-00/ /	ALL
R10224		YHLZD-33 DIODE-BLOCKING	284N1127 09922	1	21-25-11 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section R10200

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10225		YHLZD-33 DIODE-BLOCKING	284N1127 09922	1	21-58-12 P037-00/ /	ALL
R10226		YHLZD-33 DIODE-BLOCKING	284N1127 09922	1	21-58-21 P037-00/ /	ALL
R10229		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	115-199
R10230		YHLZD-33 DIODE-BLOCKING (TB166A)	284N1125 09922	1	21-58-12 P036-00/ /	ALL
R10233		YHLZR-27 RESISTOR (TB141B)	286N1163 09922	1	23-51-14 E004-03/ /	ALL
R10234		YHLZR-27 RESISTOR (TB141B)	286N1163 09922	1	23-51-14 E004-03/ /	ALL
R10238		287N5002-13 RESISTOR ASSY-FLT DK DOME/EMER LT	287N4110 81205	1	33-51-12 262/273/R001	ALL
R10240		YHLZD-33 DIODE-PTU ISOLATION	284N1318 09922	1	29-22-11 P033-00/ /	ALL
R10250		YHLZR-22 RESISTOR-KVA LIMITER(M546)	284N1315 09922	1	25-31-11 P032-00/ /	ALL
R10251		YHLZD-33 L STARTER CUTOUT DIODE (TB0183)	286N1282 09922	1	80-11-11 E005-01/ /	001-099
R10252		YHLZD-33 R STARTER CUTOUT DIODE (TB0184)	286N1284 09922	1	80-11-21 E005-02/ /	001-099
R10253		YHLZD-33 DIODE-SUPPRESSION LAND GEAR LEVER	286N003 81205	0	32-31-11 P003-01/ /	001-099
R10256		-VENDORSUPPLIEDSEEIPCFORP-NINFO- RESISTOR-BVCU,270 OHM,10 WATT	PSE1070	0	71-51-11 ENG/ /	ALL
R10262		YHLZD-33 DIODE,SUPPRESSOR S10379	286N4012 81205	1	75-31-11 0560/180/L046	ALL
R10263		YHLZD-33 DIODE,SUPPRESSOR S10380	286N4014 81205	1	75-31-11 0560/180/R046	ALL
R10266		YHLZD-38 DIODE-ZENER	286N1260 09922	1	32-35-11 P036-00/ /	ALL
R10267		YHLZD-38 DIODE-ZENER	286N1260 09922	1	32-35-11 P036-00/ /	ALL

EQUIPMENT LIST

D280N032

Section R10200

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10268		YHLZD-33 DIODE-(TB0160A)	284N1319 09922	1	32-09-11 P036-00/ /	ALL
R10270		YHLZD-33 DIODE- (TB0160A)	284N1319 09222	1	32-09-11 P036-00/ /	ALL
R10271		YHLZD-33 DIODE- (TB0160A)	284N1319 09222	1	32-09-11 P036-00/ /	ALL
R10279		YHLZD-33 DIODE-AUTOBRAKE SWITCH SUPPRESSION	233N2301 81205	1	32-42-12 / /	ALL
R10293		YHLZD-33 DIODE-	286N1260 09922	1	30-21-11 P036-00/ /	ALL
R10294		YHLZD-33 DIODE-	286N1260 09922	1	30-21-11 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section R10200

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10304		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-11 P036-00/ /	001-099
R10305		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-11 P036-00/ /	001-099
R10306		YHLZD-33 DIODE-BLOCKING	284N1125 09922	1	21-58-12 P036-00/ /	001-099
R10319		YHLZD-33 DIODE- (TB0160A)	284N1319 09222	1	32-09-11 P036-00/ /	ALL
R10336	9	YHLZD-33 DIODE-K758 RELAY ISOL (SB 34-0427)	286N1173 09922	1	34-61-25 E002-02/ /	001
R10336	9	YHLZD-33 DIODE-K758 RELAY ISOL (SB 34-0414)	286N1173 09922	1	34-61-25 E002-02/ /	115-199
R10340	9	YHLZD-33 DIODE-K757 RELAY ISOL (SB 34-0427)	286N1171 09922	1	34-61-15 E002-01/ /	001
R10340	9	YHLZD-33 DIODE-K757 RELAY ISOL (SB 34-0414)	286N1171 09922	1	34-61-15 E002-01/ /	115-199
R10341	9	YHLZD-33 DIODE-K2067 RELAY ISOL (SB 34-0427)	286N1171 09922	1	34-61-16 E002-01/ /	001
R10341	9	YHLZD-33 DIODE-K2067 RELAY ISOL (34-0414)	286N1171 09922	1	34-61-16 E002-01/ /	115-199
R10342	9	YHLZD-33 DIODE-K2065 RELAY ISOL (SB 34-0427)	286N1171 09922	1	34-61-16 E002-01/ /	001
R10342	9	YHLZD-33 DIODE-K2065 RELAY ISOL (34-0414)	286N1171 09922	1	34-61-16 E002-01/ /	115-199
R10343	9	YHLZD-33 DIODE-K2066 RELAY ISOL (SB 34-0427)	286N1173 09922	1	34-61-26 E002-02/ /	001
R10343	9	YHLZD-33 DIODE-K2066 RELAY ISOL (34-0414)	286N1173 09922	1	34-61-26 E002-02/ /	115-199
R10344	9	YHLZD-33 DIODE-K2068 RELAY ISOL (SB 34-0427)	286N1173 09922	1	34-61-26 E002-02/ /	001
R10344	9	YHLZD-33 DIODE-K2068 RELAY ISOL (34-0414)	286N1173 09922	1	34-61-26 E002-02/ /	115-199
R10345	9	YHLZD-33 DIODE-K2069 RELAY ISOL (SB 34-0427)	286N1173 09922	1	34-61-26 E002-02/ /	001

EQUIPMENT LIST

D280N032

Section R10300

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10345	9	YHLZD-33 DIODE-K2069 RELAY ISOL (34-0414)	286N1173 09922	1	34-61-26 E002-02/ /	115-199
R10346		YHLZD-33 DIODE-ISOL. ENG FUEL S/O VLV,L	286N1260 09922	1	76-11-11 P036-00/ /	ALL
R10347		YHLZD-33 DIODE-ISOL,ENG FUEL S/O VLV,L	286N1260 09922	1	76-11-11 P036-00/ /	ALL
R10348		YHLZD-33 DIODE-ISOL,ENG FUEL S/O VLV,L	286N1260 09922	1	76-11-11 P036-00/ /	ALL
R10349		YHLZD-33 DIODE-ISOL,ENG FUEL S/O VLV,R	286N1270 09922	1	76-11-12 P037-00/ /	ALL
R10350		YHLZD-33 DIODE-ISOL,ENG FUEL S/O VLV,R	286N1270 09922	1	76-11-12 P037-00/ /	ALL
R10351		YHLZD-33 DIODE-ISOL,ENG FUEL S/O VLV,R	286N1270 09922	1	76-11-12 P037-00/ /	ALL
R10352		YHLZR-32 RESISTOR-100K OHM ISOLATION	2861265 09922	1	31-31-62 E003-01/ /	001-099
R10353		YHLZR-32 RESISTOR-100K OHM ISOLATION	2861265 09922	1	31-31-62 E003-01/ /	001-099
R10354		YHLZD-33 DIODE-LANDING GEAR IND ISOLATION NO.1	284N1310 81205	1	32-61-11 E003-04/ /	ALL
R10355		YHLZD-33 DIODE-LANDING GEAR IND ISOLATION NO.2	284N1310 81205	1	32-61-11 E003-04/ /	ALL
R10360		YHLZR-32 RESISTOR-100K OHM ISOLATION	286N1115 09922	1	31-31-61 P010-00/ /	001-099
R10361		YHLZR-32 RESISTOR-100K OHM ISOLATION	286N1115 09922	1	31-31-61 P010-00/ /	001-099
R10362		YHLZD-33 DIODE-(ALTERNATE STAB TRIM)	280N1115 09922	1	27-41-31 / /	002-099
R10363		YHLZD-33 DIODE-(ALTERNATE STAB TRIM)	280N1115 09922	1	27-41-31 / /	002-099
R10367		YHLZD-33 DIODE (TBO160A)	284N1319 09222	1	32-09-11 P036-00/ /	001-099
R10368		YHLZD-33 DIODE-BURNDY BLOCK	284N1129 09922	1	24-51-14 P031-00/ /	ALL

EQUIPMENT LIST

D280N032

Section R10300

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10369		YHLZD-33 DIODE-BURNDY BLOCK	284N1320 09922	1	24-51-24 P032-00/ /	ALL
R10381		RER60F10R0R RESISTOR-FLT DK DOME/EMER LT	96906	1	33-11-52 260/263/L023	001-099
R10393		YHLZD-33 DIODE-(TB0360A)	284N1319 09922	1	32-09-11 P036-00/ /	003-099
R10398	9	YHLZD-33 SYNC LOCK SOLEN,SUPPRESS DIODE,L T/R	SB780032 81205	1	78-34-51 P036-00/ /	001-002, 115-199
R10398		YHLZD-33 SYNC LOCK SOLEN,SUPPRESS DIODE,L T/R	286N1260 81205	1	78-34-51 P036-00/ /	003-099
R10399	9	YHLZD-33 SYNC LOCK SOLEN,SUPPRESS DIODE,R T/R	SB780032 81205	1	78-34-61 P037-00/ /	001-002, 115-199
R10399		YHLZD-33 SYNC LOCK SOLEN,SUPPRESS DIODE,R T/R	286N1270 81205	1	78-34-61 P037-00/ /	003-099

EQUIPMENT LIST

D280N032

Section R10300
Page 3 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10409		69-58806-4 DIODE ASSEMBLY- L TANK V10003	81205	1	28-21-23 IRSS258/ /	010-099
R10410		69-58806-4 DIODE ASSEMBLY-L CTR TANK V10001	81205	1	28-21-23 1040/180/L050	010-099
R10411		69-58806-4 DIODE ASSEMBLY-R CTR TANK V10064	81205	1	28-21-23 1051/172/R43	010-099
R10412		69-58806-4 DIODE ASSEMBLY- R TANK V10003	81205	1	28-21-23 IRSS255/ /	010-099
R10465	9	YHLZD-30 DIODE-BURNDY BLOCK (SB 34-0427)	284NXXXX 81205	1	34-22-16 P036-00/ /	001
R10465	9	YHLZD-33 DIODE-BURNDY BLOCK (SB 34-0414)	284NXXXX 81205	1	34-22-16 P036-00/ /	115-199
R10472	9	YHLZD-33 DIODE-BLOCKING (TB173A)	284N1127 09922	1	31-31-41 P037-00/ /	010-099
R10490		YHLZD-33 COMPONENT-DIODE (TB141)	286N1163	1	23-31-41 E004-03/ /	ALL
R10491		YHLZD-33 COMPONENT-DIODE	286N1163	0	23-31-41 / /	ALL
R10494		YHLZD-33 COMPONENT-DIODE (TB141)	286N1163	1	23-31-41 E004-03/ /	ALL

EQUIPMENT LIST

D280N032

Section R10400

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10558	9	YHLZR-33 RESISTOR-ISOL,AUTO SPEED BRAKE EXT (10K)	284N1125 09922	1	27-62-11 P036-00/ /	010-099
R10559	9	YHLZD-30 DIODE-ISOL,AUTO SPEED BRAKE EXT	284N1125 09922	1	27-62-11 P036-00/ /	010-099
R10584	9	YHLZD-30 DIODE-L ADC SRC SELECT RLY (SB 34A0222)	280N3341 09922	1	34-12-61 / /	ALL
R10585	9	YHLZD-30 DIODE-R ADC SRC SELECT RLY (SB 34A0222)	280N3341 09922	1	34-12-62 / /	ALL

EQUIPMENT LIST

D280N032

Section R10500
Page 1 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00001		AC-45-0008-1 SW-FD INSTR SOURCE SELECT,CAPT	233N2220 81205	1	34-22-17 P001-01/ /	ALL
S00002	9	AC45-0082 SWITCH-CAPT FMCS NAV SRC SEL(SB 34-0427)	233N2220 91812	1	34-61-15 P001-01/ /	001
S00002	9	AC45-0082 SWITCH-CAPT FMCS NAV SRC SEL(34-0414)	233N2220 91812	1	34-61-15 P001-01/ /	115-199
S00002		S231T290-1001 SWITCH-CAPT FMCS NAV SOURCE SELECT	233N2220 81205	1	34-22-17 P001-01/ /	ALL
S00003		S231T290-1001 SW-EFI INSTR SOURCE SELECT,CAPT	233N2220 81205	1	34-22-17 P001-01/ /	ALL
S00004		S231T290-1001 SW-IRS INSTR SOURCE SELECT,CAPT	233N2220 81205	1	34-22-17 P001-01/ /	ALL
S00005		721101A1 SW-AUTOPILOT DISENGAGE,CAPT	251N1140 97564	1	22-11-12 0169/238/L028	ALL
S00006		721101A1 SW-AUTOPILOT DISENGAGE,F/O	251N1140 97564	1	22-11-12 0169/238/R024	ALL
S00009		AC-45-0008-1 SW-FD INSTR SOURCE SELECT,F/O	233N2223 81205	1	34-22-27 P003-03/ /	ALL
S00010	9	AC45-0082 SWITCH-F/O FMCS NAV SRC SEL (SB 34-0427)	233N2223 91812	1	34-61-25 P003-03/ /	001
S00010	9	AC45-0082 SWITCH-F/O FMCS NAV SRC SEL (34-0414)	233N2223 91812	1	34-61-25 P003-03/ /	115-199
S00010		S231T290-1001 SWITCH-F/O FMCS NAV SOURCE SELECT	233N2223 81205	1	34-22-27 P003-03/ /	ALL
S00011		S231T290-1001 SW-EFI INSTR SOURCE SELECT,F/O	233N2223 81205	1	34-22-27 P003-03/ /	ALL
S00012		S231T290-1001 SW-IRS INSTR SOURCE SELECT,F/O	233N2223 81205	1	34-22-27 P003-03/ /	ALL
S00021		S210T130-18 SW-DUCT OVHT,FLT DECK ZONE	214N1011 81205	1	21-61-11 0350/197/L052	ALL
S00022		S210T130-18 SW-DUCT OVHT,FWD CABIN ZONE	214N2002 81205	1	21-61-21 0860/300/L013	ALL
S00023		S210T130-18 SW-DUCT OVHT,AFT ZONE	214N2002 81205	1	21-61-31 0880/300/L013	ALL

EQUIPMENT LIST

D280N032

Section S00000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00024	1	S283T022-3 SW-AUTOBRAKE LANDING SELECT	233N2221 81205	1	32-42-12 P001-03/ /	ALL
S00024	2	S283T022-1 SW-AUTOBRAKE LANDING SELECT	233N2221 81205	1	32-42-12 P001-03/ /	ALL
S00025		S271T452-8 SW-PRESS,ELEC HYD PUMP L	271N2003 81205	1	29-11-12 1068/174/L058	ALL
S00027		S271T452-18 SW-PRESS,L HYD SYS	271N2001 81205	1	29-11-12 PPS230/ /	ALL
S00030		S271T452-8 SW-PRESS,ELEC HYD PUMP,R	271N2003 81205	1	29-11-22 1068/174/R058	ALL
S00032		S271T452-18 SW-PRESS,R HYD SYS	271N2001 81205	1	29-11-22 PPS230/ /R	ALL
S00037	1	10-61318-51 SW-FIRE,L ENG	233N6101 81205	1	26-11-11 P008-00/ /	ALL
S00037	2	10-61318-14 SW-FIRE,L ENG	233N6101 81205	1	26-11-11 P008-00/ /	ALL
S00038	1	10-61318-52 SW-FIRE,R ENG	233N6101 81205	1	26-11-21 P008-00/ /	ALL
S00038	2	10-61318-15 SW-FIRE,R ENG	233N6101 81205	1	26-11-21 P008-00/ /	ALL
S00039		10-61318-16 SW-FIRE,APU	233N6101 81205	1	26-15-11 P008-00/ /	ALL
S00048		S210T130-25 SWITCH-PACK OVERHEAT TEMP,LEFT	213N1002 81205	1	21-51-15 0942/156/L024	ALL
S00049		S210T130-25 SWITCH-PACK OVERHEAT TEMP,RIGHT	213N1002 81205	1	21-51-25 0953/156/R051	ALL
S00070		60B92400-3 SW-PRESS,FUEL BOOST PUMP,L FWD	343N3301 81205	1	28-42-11 ISS173/ /LRS	ALL
S00071		60B92400-3 SW-PRESS,FUEL BOOST PUMP,L AFT	343N3301 81205	1	28-42-11 IRSS181/ /LRS	ALL
S00072		60B92400-3 SW-PRESS,FUEL BOOST PUMP,R FWD	343N3301 81205	1	28-42-11 ISS173/ /	ALL
S00073		60B92400-3 SW-PRESS,FUEL BOOST PUMP,R AFT	343N3301 81205	1	28-42-11 IRSS182/ /RRS	ALL

EQUIPMENT LIST

D280N032

Section S00000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00074		60B92400-3 SW-PRESSURE,DC FUEL PUMP	346N3001 81205	1	28-42-21 RS/181/	ALL
S00080	9	S253T407-4 SW-MAN STAB TRIM,CAPT	SB270110 81205	1	27-41-11 0239/229/L021	001-002, 115-199
S00081	9	S253T407-4 SW-MAN STAB TRIM,F/O	SB270110 81205	1	27-41-21 239/230/R021	001-002, 115-199
S00082		S271T452-3 SW-METERED PRESS,L	274N1002 81205	1	32-42-12 1040/170/L039	ALL
S00083		S271T452-3 SW-METERED PRESS,R	274N1002 81205	1	32-42-12 1040/170/R046	ALL

EQUIPMENT LIST

D280N032

Section S00000

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00119	9	214C40-1-122 SW-ALTITUDE PRESSURE	284N1127 02750	1	35-21-11 P037-00/ /	005, 007-008
S00119		214C40-1-75 SW-ALTITUDE PRESSURE	284N1127 02750	1	35-21-11 P037-00/ /	ALL
S00134		MS24547-1 SW-T/R CONT,L	254N1054 96906	1	78-34-51 P010-00/ /	ALL
S00135		MS24547-1 SW-T/R CONT,R	254N1054 96906	1	78-34-61 P010-00/ /	ALL
S00164		S283T006-8 SW-PROX SNSR,LOCK,LH ACTUATOR,L ENG	10E80008 81205	1	78-36-11 ENG/ /	ALL
S00165		S283T006-8 SW-PROX SNSR,LOCK,RH ACTUATOR,L ENG	10E80008 81205	1	78-36-11 ENG/ /	ALL
S00166		S283T006-5 SW-PROX SNSR,DEPLOY,LH,T/R,L ENG	10E80008 81205	1	78-36-11 ENG/ /	ALL
S00167		S283T006-5 SW-PROX SNSR,DEPLOY,RH,T/R,L ENG	10E80008 81205	1	78-36-11 ENG/ /	ALL

EQUIPMENT LIST

D280N032

Section S00100

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00318		MS25306-232 SW-INSP LIGHT,WHEEL WELL,MAIN	284N1745 96906	1	33-31-11 1210/145/R025	001-099
S00318		MS25306-222 SW-INSP LIGHT,WHEEL WELL,MAIN	284N1745 96906	1	33-31-11 1210/145/R025	115-199
S00320		2PB11-H58 SW-CLOCK,CAPT	233N8200 91929	1	31-25-11 P007-00/ /	ALL
S00321		2PB11-H58 SW-CLOCK,F/O	233N8200 91929	1	31-25-11 P007-00/ /	ALL
S00324		MS25306-222 SW-LIGHT,WHEEL WELL,NOSE GEAR	284N1758 96906	1	33-31-11 P063-00/ /	ALL
S00330		S271T452-10 SW-HYDRAULIC PRESSURE,T/R	271N5001 81205	1	78-36-11 PPS242/ /L	ALL
S00331		S271T452-10 SW-HYDRAULIC PRESSURE,T/R	271N5001 81205	1	78-36-21 PPS242/ /R	ALL
S00332		60B50024-1 SW-WATER PRESSURE CUT-OUT	417N2608 81205	1	38-15-11 1684/202/R012	ALL
S00334		10AT96-1 SW-LEFT COL-OUTBD AFT	251N2564 82647	1	27-41-11 0239/188/L030	ALL
S00335		10AT96-1 SW-LEFT COL-OUTBD FWD	251N2564 82647	1	27-41-11 0239/188/L030	ALL
S00337		10AT96-1 SW-RIGHT COL-OUTBD AFT	251N2564 82647	1	27-41-21 333/190/L20	ALL
S00338		10AT96-1 SW-RIGHT COL-OUTBD FWD	251N2564 82647	1	27-41-21 229/190/L20	ALL
S00341		S271T462-3 SW-REMOTE HYD QTY SELECT	271N5024	1	29-33-11 1192/169/L028	ALL
S00345		MS24523-22 SW-FUELING POWER SELECT	344N5101 96906	1	28-21-11 P028-00/ /	ALL
S00346		60B40018-42 SW-FUELING PANEL DOOR	344N5101 81205	1	28-21-11 OSS504/ /RLE	ALL
S00347		MS25089-1CR SW-OVERFILL RESET	344N5101 96906	1	28-21-21 P028-00/ /	ALL
S00348		2TL82-3 SW-REFUELING VALVE CONT,L TANK	344N5101 82647	1	28-21-22 P028-00/ /	ALL

EQUIPMENT LIST

D280N032

Section S00300

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00349		2TL82-3 SW-REFUELING VALVE CONT,R TANK	344N5101 82647	1	28-21-22 P028-00/ /	ALL
S00350		MS24523-22 SW-DEFUEL VALVE CONT,L	344N5001 96906	1	28-26-11 P028-00/ /	ALL
S00351		MS24523-22 SW-DEFUEL VALVE CONT,R	344N5001 96906	1	28-26-11 P028-00/ /	ALL
S00355		MS25307-222 SW-E/E CTR LTS, MAIN	284N1360 96906	1	33-31-41 477/162/R023	ALL
S00357		MS25306-222 SW-E/E CTR LTS, FWD	284N1401 96906	1	33-31-41 231/157/R007	ALL
S00358	1	975-0172-006 SW-AIR SUPPLY OVHT,L	212N3001 97896	1	36-22-11 0913/148/L021	ALL
S00358	2	3000-46-29 SW-AIR SUPPLY OVHT,L	212N3001 14604	1	36-22-11 0913/148/L021	ALL
S00359	1	975-0172-006 SW-AIR SUPPLY OVHT,R	212N3001 97896	1	36-22-11 185/151/L003	ALL
S00359	2	3000-46-29 SW-AIR SUPPLY OVHT,R	212N3001 14604	1	36-22-11 185/151/L003	ALL
S00361		MS25306-222 SW-AIR COND COMPT LTS, LEFT	284N1447 96906	1	33-31-21 1035/134/L016	ALL
S00362		MS25306-222 SW-AIR COND COMPT LTS, RIGHT	284N1447 96906	1	33-31-21 1035/134/R016	ALL
S00364		S210N701-8 SW-TEMP CONTROL,CARGO,FWD	215N3003 81205	1	21-43-11 0847/170/L040	ALL
S00371		10AT97-3 SW-ARMING,AUTO SPEED BRAKE	254N1053 82647	1	27-62-11 P010-00/ /	ALL
S00374		10AT96-2 SW-ENG THRUST REV	254N1053 82647	1	27-62-11 P010-00/ /	ALL
S00397		S210T130-27 SW-PACK ALT,RIGHT	213N1001 81205	1	21-51-22 0895/148/L038	ALL

EQUIPMENT LIST

D280N032

Section S00300

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00415		S271T452-15 SW-PRESS,ALT VALVE SELECT	274N1003 81205	1	32-42-11 1044/172/R022	001-099
S00415		S271T452-8 SW-PRESS,ALT VALVE SELECT	274N1003 81205	1	32-42-11 1044/172/R022	115-199
S00416		MS25089-1CR SW-OVERFILL SYS TEST	344N5101 96906	1	28-21-21 P028-00/ /	ALL
S00417		2TL82-3 SW-REFUELING VALVE CONT,CTR TANK	344N5101 82647	1	28-21-22 P028-00/ /	ALL
S00418		MS25089-2CR SW-TANK LOAD SET,L	344N5101 96906	1	28-21-22 P028-00/ /	ALL
S00419		MS25089-2CR SW-TANK LOAD SET,R	344N5101 96906	1	28-21-22 P028-00/ /	ALL
S00420		MS25089-2CR SW-TANK LOAD SET,CTR	344N5101 96906	1	28-21-22 P028-00/ /	ALL
S00421		MS25089-2CR SW-TEST,SHUTOFF SYS	344N5101 96906	1	28-21-22 P028-00/ /	ALL
S00426		D20011-01 SW-FLIGHT DECK CALL	284N1758 81640	1	23-43-11 P062-00/ /	ALL
S00427		MS25306-232 SW-TAILCONE COMPT LTS,FWD	284N1481 96906	1	33-31-31 1759/190/L018	ALL
S00428		MS25306-222 SW-APU COMPT LTS	284N1482 96906	1	33-31-31 1886/210/L005	ALL
S00429		MS25306-222 SW-AFT CARGO COMPT LIGHTS	284N1338 96906	1	33-37-21 P044-00/ /	ALL
S00431		214C40-1-71 SW-CABIN ALTITUDE WARNING	284N1125 02750	1	21-33-12 P036-00/ /	ALL
S00441	9	2PB11H58 SWITCH-CAPT GLARESHIELD (SB 23-0101)	233N8200 91929	1	23-51-11 P007-00/ /	115-199
S00442	9	2PB11H58 SWITCH-F/O GLARESHIELD (SB 23-0101)	233N8200 91929	1	23-51-21 P007-00/ /	115-199
S00443		MS25306-232 SW-TAILCONE COMPT LTS,AFT	284N1481 96906	1	33-31-31 1864/212/R018	ALL
S00452		S271T452-7 SW-PRESS,L GEAR TILT	273N2087 81205	1	27-62-11 IRSS250/ /LRS	ALL

EQUIPMENT LIST

D280N032

Section S00400

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00453		S271T452-7 SW-PRESS,R GEAR TILT	273N2087 81205	1	27-62-11 IRSS250/ /RRS	ALL
S00457		MS25089-2CR SW-INDICATOR TEST	344N5101 96906	1	28-21-22 P028-00/ /	ALL
S00459		MS25008-1 SW-PARKING BRAKE	274N2012 96906	1	32-44-11 217/183/L016	ALL
S00482	1	S231T290-2001 SW-ADC INSTR SOURCE SELECT,CAPT	233N2220 81205	1	34-12-61 P001-01/ /	ALL
S00482	2	S231T290-1001 SW-ADC INSTR SOURCE SELECT,CAPT	233N2220 81205	1	34-12-61 P001-01/ /	ALL
S00483	1	S231T290-2001 SW-ADC INSTR SOURCE SELECT,F/O	233N2223 81205	1	34-12-62 P003-03/ /	ALL
S00483	2	S231T290-1001 SW-ADC INSTR SOURCE SELECT,F/O	233N2223 81205	1	34-12-62 P003-03/ /	ALL
S00484		1HE49 SW-APU FIRE SHT DN	284N1625 91929	1	26-15-12 P062-00/ /	ALL
S00485		1HE48 SW-APU BTL 1 DISCH	284N1625 91929	1	26-15-12 P062-00/ /	ALL
S00493		10-AT304-1 SW-SPOILER HANDLE DETENT SW POSITION	233N6101 91929	1	32-42-12 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section S00400
Page 2 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00507		S231T290-1042 SW-MASTER CAUTION/WARNING LT,CAPT	233N8200 81205	1	31-51-21 P007-00/ /	ALL
S00508		S231T290-1042 SW-MASTER CAUTION/WARNING LT,F/O	233N8200 81205	1	31-51-21 P007-00/ /	ALL
S00549	1	C2006-CB SW-INTPH PTT,CAPT	251N1140 78048	1	23-51-11 0169/238/L028	ALL
S00549	2	C2006-CB SW-INTPH PTT,CAPT	251N1140 78048	1	23-51-11 0169/238/L028	ALL
S00550	1	C2006-CB SW-R/T PTT,CAPT	251N1140 78048	1	23-51-11 0169/238/L028	ALL
S00550	2	C2006-CB SW-R/T PTT,CAPT	251N1140 78048	1	23-51-11 0169/238/L028	ALL
S00551	1	C2006-CB SW-INTPH PTT,F/O	251N1140 78048	1	23-51-21 0169/238/R024	ALL
S00551	2	C2006-CB SW-INTPH PTT,F/O	251N1140 78048	1	23-51-21 0169/238/R024	ALL
S00552	1	C2006-CB SW-R/T PTT,F/O	251N1140 78048	1	23-51-21 0169/238/R024	ALL
S00552	2	C2006-CB SW-R/T PTT,F/O	251N1140 78048	1	23-51-21 0169/238/R024	ALL
S00575		10AT96-2 SW-MECHANICAL PITCH TRIM	254N1055 82647	1	31-31-31 P010-00/ /	115-199

EQUIPMENT LIST

D280N032

Section S00500

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00616		64AT343D SW-MAG/TRUE	233N2222 91929	1	34-22-36 P003-00/ /	ALL
S00633		7GR159 SW-PRESS,FWD CARGO FIRE EXT DISCH LINE	208N4667 09049	1	26-23-11 1183/190/R03	ALL

EQUIPMENT LIST

D280N032

Section S00600
Page 1 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01042		S10380 SPLC	286N4236	0	75-31-11 E001-01/ /	115-199

EQUIPMENT LIST

D280N032

Section S01000

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10002		S271T452-8 SW-PRESS,CTR HYD SYS	271N2004 81205	1	29-11-31 1215/150/L043	ALL
S10003		S271T452-8 SW-PRESS,ELEC HYD PUMP C1	271N2004 81205	1	29-11-31 1220/154/L043	ALL
S10006		S271T454-1 SW-ENGINE PUMP,CASE DRAIN TEMP,L	271T0068 81205	1	29-32-11 PPS226/ /L	ALL
S10007		S271T454-1 SW-ENGINE PUMP,CASE DRAIN TEMP,R	271T0068 81205	1	29-32-21 PPS226/ /R	ALL
S10010		60B92400-5 SW-PRESS,FUEL OVERRIDE PUMP,L	343N3301 81205	1	28-42-11 ***/**/L010	ALL
S10011		60B92400-5 SW-PRESS,FUEL OVERRIDE PUMP,R	343N3301 81205	1	28-42-11 ***/**/R010	ALL
S10016		S271T452-8 SW-PRESS,ELEC HYD PUMP C2	271N2004 81205	1	29-11-31 1215/165/L050	ALL
S10031		60B40018-42 SW-APU INLET DOOR	353N1020 81205	1	49-61-14 1821/286/R014	ALL
S10032		S271N302-2 SW-HYD RESERVOIR PRESSURE,LEFT	271N3001 81205	1	29-35-11 1052/188/L050	ALL
S10033		S271N302-2 SW-HYD RESERVOIR PRESSURE,CENTER	271N3002 81205	1	29-35-11 1180/ /L060	ALL
S10034		S271N302-2 SW-HYD RESERVOIR PRESSURE,RIGHT	271N3003 81205	1	29-35-11 1052/189/50	ALL
S10035		MS25308-302 SW-TEST,EMER LT	284N1758 96906	1	33-51-11 P062-00/ /	ALL
S10057	1	S283T006-28 SW-PROX SNSR,R GEAR DOWN & LOCKED,SYS 1	81205	1	32-61-22 R MLG/ /	ALL
S10059	1	S283T006-10 SW-PROX SNSR,R TRUCK NOT TILTED,SYS 2	81205	1	32-09-12 R MLG/ /	ALL
S10059	2	S283T006-5 SW-PROX SNSR,R TRUCK NOT TILTED,SYS 2	81205	1	32-09-12 R MLG/ /	ALL
S10060	1	S283T006-10 SW-PROX SNSR,R TRUCK NOT TILTED,SYS 1	81205	1	32-09-11 R MLG/ /	ALL
S10060	2	S283T006-5 SW-PROX SNSR,R TRUCK NOT TILTED,SYS 1	81205	1	32-09-11 R MLG/ /	ALL

EQUIPMENT LIST

D280N032

Section S10000

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10061	1	S283T006-28 SW-PROX SNSR,L GEAR DOWN & LOCKED,SYS 1	81205	1	32-61-22 L MLG/ /	ALL
S10062	1	S283T006-10 SW-PROX SNSR,L TRUCK NOT TILTED,SYS 1	81205	1	32-09-11 L MLG/ /	ALL
S10062	2	S283T006-5 SW-PROX SNSR,L TRUCK NOT TILTED,SYS 1	81205	1	32-09-11 L MLG/ /	ALL
S10064	1	S283T006-10 SW-PROX SNSR,L TRUCK NOT TILTED,SYS 2	81205	1	32-09-12 L MLG/ /	ALL
S10064	2	S283T006-5 SW-PROX SNSR,L TRUCK NOT TILTED,SYS 2	81205	1	32-09-12 L MLG/ /	ALL
S10065	1	S283T006-28 SW-PROX SNSR,NOSE GEAR LOCKED,SYS 1	284N1623 81205	1	32-61-12 395/192/R002	ALL
S10065	2	S283T006-8 SW-PROX SNSR,NOSE GEAR LOCKED,SYS 1	284N1623 81205	1	32-61-12 395/192/R002	ALL
S10065	3	S283T006-3 SW-PROX SNSR,NOSE GEAR LOCKED,SYS 1	284N1623 81205	1	32-61-12 MLG/ /	ALL
S10066	1	S283T006-10 SW-PROX SNSR,NOSE GEAR DOWN,SYS 1	284N1623 81205	1	32-61-12 350/192/L020	ALL
S10066	2	S283T006-5 SW-PROX SNSR,NOSE GEAR DOWN,SYS 1	284N1623 81205	1	32-61-12 350/192/L020	ALL
S10067	1	S283T006-10 SW-PROX SNSR,NOSE GEAR NOT CPRSD,SYS 1	284N1624 81205	1	32-09-11 NWW/ /	ALL
S10067	2	S283T006-5 SW-PROX SNSR,NOSE GEAR NOT CPRSD,SYS 1	284N1624 81205	1	32-09-11 NWW/ /	ALL
S10068	1	S283T006-10 SW-PROX SNSR,NOSE GEAR NOT CPRSD,SYS 2	284N1624 81205	1	32-09-11 NWW/ /	ALL
S10068	2	S283T006-5 SW-PROX SNSR,NOSE GEAR NOT CPRSD,SYS 2	284N1624 81205	1	32-09-11 NWW/ /	ALL
S10069	1	S283T006-28 SW-PROX SNSR,R GEAR UP & LOCKED,SYS 2	284N1612 81205	1	32-61-11 1068/175/R065	ALL
S10069	2	S283T006-8 SW-PROX SNSR,R GEAR UP & LOCKED,SYS 2	284N1612 81205	1	32-61-11 1068/175/R065	ALL
S10069	3	S283T006-3 SW-PROX SNSR,R GEAR UP & LOCKED,SYS 2	284N1612 81205	1	32-61-11 1068/175/R065	ALL

EQUIPMENT LIST

D280N032

Section S10000

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10070	1	S283T006-28 SW-PROX SNSR,R GEAR DOWN & LOCKED,SYS 2	81205	1	32-61-22 R MLG/ /	ALL
S10072	1	S283T006-10 SW-PROX SNSR,R GEAR DOOR CLOSED,SYS 2	284N1445 81205	1	32-61-11 1070/145/R060	ALL
S10072	2	S283T006-5 SW-PROX SNSR,R GEAR DOOR CLOSED,SYS 2	284N1445 81205	1	32-61-11 1070/145/R060	ALL
S10073	1	S283T006-28 SW-PROX SNSR,L GEAR UP & LOCKED,SYS 2	284N1612 81205	1	32-61-11 1130/170/L050	ALL
S10073	2	S283T006-8 SW-PROX SNSR,L GEAR UP & LOCKED,SYS 2	284N1612 81205	1	32-61-11 1130/170/L050	ALL
S10073	3	S283T006-3 SW-PROX SNSR,L GEAR UP & LOCKED,SYS 2	284N1612 81205	1	32-61-11 1130/170/L050	ALL
S10074	1	S283T006-28 SW-PROX SNSR,L GEAR DOWN & LOCKED,SYS 2	81205	1	32-61-12 L MLG/ /	ALL
S10074 U		NAS1515H5H WASHER, NYLON		1	32-61-22 1089/191/L112	ALL
S10076	1	S283T006-10 SW-PROX SNSR,L GEAR DOOR CLOSED,SYS 2	284N1445 81205	1	32-61-11 LWW/ /	ALL
S10076	2	S283T006-5 SW-PROX SNSR,L GEAR DOOR CLOSED,SYS 2	284N1445 81205	1	32-61-11 LWW/ /	ALL
S10077	1	S283T006-10 SW-PROX SNSR,NOSE GEAR UP,SYS 2	284N1623 81205	1	32-61-13 350/192/R017	ALL
S10077	2	S283T006-5 SW-PROX SNSR,NOSE GEAR UP,SYS 2	284N1623 81205	1	32-61-13 350/192/R017	ALL
S10078	1	S283T006-28 SW-PROX SNSR,NOSE GEAR LOCKED,SYS 2	284N1623 81205	1	32-61-12 NLG/ /	ALL
S10078	2	S283T006-8 SW-PROX SNSR,NOSE GEAR LOCKED,SYS 2	284N1623 81205	1	32-61-12 NLG/ /	ALL
S10078	3	S283T006-3 SW-PROX SNSR,NOSE GEAR LOCKED,SYS 2	284N1623 81205	1	32-61-12 NLG/ /	ALL
S10079	1	S283T006-10 SW-PROX SNSR,NOSE GEAR DOWN,SYS 2	284N1623 81205	1	32-61-12 350/192/R020	ALL
S10079	2	S283T006-5 SW-PROX SNSR,NOSE GEAR DOWN,SYS 2	284N1623 81205	1	32-61-12 350/192/R020	ALL

EQUIPMENT LIST

D280N032

Section S10000

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10081	1	S283T006-10 SW-PROX SNSR,NOSE GEAR DOOR CLOSED,SYS 2	284N1406 81205	1	32-61-11 263/158/R009	ALL
S10081	2	S283T006-5 SW-PROX SNSR,NOSE GEAR DOOR CLOSED,SYS 2	284N1406 81205	1	32-61-11 263/158/R009	ALL
S10083	1	S283T006-10 SW-SNSR,NO.1 CARGO DR	284N1363 81205	1	52-71-21 582/200/R065	ALL
S10083	2	S283T006-5 SW-SNSR,NO.1 CARGO DR	284N1363 81205	1	52-71-21 0560/169/R046	ALL
S10085	1	S283T006-10 SW-SNSR,FWD ACCESS DR	284N1407 81205	1	52-71-11 230/148/	ALL
S10085	2	S283T006-5 SW-SNSR,FWD ACCESS DR	284N1407 81205	1	52-71-11 230/148/	ALL
S10086	1	S283T006-10 SW-SNSR,E/E ACCESS DR	284N1362 81205	1	52-71-11 468/152/R009	ALL
S10086	2	S283T006-5 SW-SNSR,E/E ACCESS DR	284N1362 81205	1	52-71-11 467/150/R008	ALL
S10088	1	S283T006-10 SW-SNSR,NO.2 CARGO DR	284N1464 81205	1	52-71-21 1380/194/R044	ALL
S10088	2	S283T006-5 SW-SNSR,NO.2 CARGO DR	284N1464 81205	1	52-71-21 1380/194/R044	ALL
S10089	1	S283T006-10 SW-SNSR,NO.3 CARGO DR	284N1752 81205	1	52-71-21 1640/160/R040	115-199
S10089	2	S283T006-5 SW-SNSR,NO.3 CARGO DR	284N1752 81205	1	52-71-21 1640/160/R040	115-199
S10090	1	S283T006-10 SW-SNSR,NO.1 PASS DR R	284N1403 81205	1	52-71-21 333/265/R060	ALL
S10090	2	S283T006-5 SW-SNSR,NO.1 PASS DR R	284N1403 81205	1	52-71-21 333/265/R060	ALL
S10091	1	S283T006-10 SW-SNSR,NO.2 PASS DR R	284N1361 81205	1	52-71-21 737/267/R060	ALL
S10091	2	S283T006-5 SW-SNSR,NO.2 PASS DR R	284N1361 81205	1	52-71-21 0730/270/R060	ALL
S10092	1	S283T006-10 SW-SNSR,NO.3 EMER EXIT R	284N1465 81205	1	52-71-21 1320/210/R065	ALL

EQUIPMENT LIST

D280N032

Section S10000

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10092	2	S283T006-5 SW-SNSR,NO.3 EMER EXIT R	284N1465 81205	1	52-71-21 1320/210/R065	ALL
S10093	1	S283T006-10 SW-SNSR,NO.4 PASS DR R	284N1466 81205	1	52-71-21 1682/220/R062	ALL
S10093	2	S283T006-5 SW-SNSR,NO.4 PASS DR R	284N1466 81205	1	52-71-21 1682/220/R062	ALL
S10094	1	S283T006-10 SW-SNSR,NO.1 PASS DR L	284N1403 81205	1	52-71-11 377/274/L056	ALL
S10094	2	283T006-5 SW-SNSR,NO.1 PASS DR L	284N1403 81205	1	52-71-11 377/274/L056	ALL
S10095	1	S283T006-10 SW-SNSR,NO.2 PASS DR L	284N1361 81205	1	52-71-11 729/277/L057	ALL
S10095	2	S283T006-5 SW-SNSR,NO.2 PASS DR L	284N1361 81205	1	52-71-11 729/277/L057	ALL
S10096	1	S283T006-10 SW-SNSR,NO.3 EMER EXIT L	284N1465 81205	1	52-71-11 1320/240/L072	ALL
S10096	2	283T006-5 SW-SNSR,NO.3 EMER EXIT L	284N1465 81205	1	52-71-11 1320/240/L072	ALL
S10097	1	S283T006-10 SW-SNSR,NO.4 PASS DR L	284N1466 81205	1	52-71-11 1682/220/L065	ALL
S10097	2	S283T006-5 SW-SNSR,NO.4 PASS DR L	284N1466 81205	1	52-71-11 1682/220/L065	ALL

EQUIPMENT LIST

D280N032

Section S10000
Page 5 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10105		S283T006-5 SW-PROX SNSR,AUTO STOW,L	10E80008 81205	1	78-34-11 ENG/ /	ALL
S10108		S283T006-5 SW-PROX SNSR,AUTO STOW,R	10E80008 81205	1	78-34-11 ENG/ /	ALL
S10128		MS25306-222 SW-FWD CARGO COMPT LTS	284N1338 96906	1	33-37-11 P043-00/ /	ALL
S10129		S271T452-10 SW-PTU CONT PRESSURE	271N2040 81205	1	29-22-11 1065/175/L005	ALL
S10130		L907217 SW-LOW OIL PRESSURE	10E80008 K0680	2	79-33-11 ENG/ /	ALL
S10131		L907219 SW-OIL FILTER BYPASS PRESSURE,MAIN	10E80008 K0680	2	79-35-11 ENG/ /	ALL
S10132		L907219 SW-OIL FILTER BYPASS PRESSURE,SCAV	10E80008 K0680	2	79-35-11 ENG/ /	ALL
S10133		L907223 SW-FUEL FILTER PRESSURE	10E80008 K0680	2	73-33-11 ENG/ /	ALL
S10134		L907222 SW-FUEL LOW PRESSURE	10E80008 K0680	2	73-34-11 ENG/ /	ALL
S10135		VENDORSUPPLIED-SEEIPCFORP-NINFO SW-NOSE COWL ANTI-ICING LOW PRESSURE	10E80008 K0680	2	30-21-11 ENG/ /	ALL
S10137		VENDORSUPPLIED-SEEIPCFORP-NINFO SW-NOSE COWL ANTI-ICING HIGH PRESSURE	10E80008 K0680	2	30-21-11 ENG/ /	ALL
S10138		PARTOFL150901-FFR- SW-VALVE POSITION(FSO)	10E80008 K0680	2	76-11-11 ENG/ /	ALL
S10139		0205K0S600 SW-ENG INTERNAL OVERHEAT SYSTEM (1)	10E80008 K0680	2	26-13-11 ENG/ /	ALL
S10140		0205K0S600 SW-ENG INTERNAL OVERHEAT SYSTEM (2)	10E80008 K0680	2	26-13-11 ENG/ /	ALL
S10142		L908002 SW-ALTITUDE	10E80008 K0680	2	75-31-11 ENG/ /	ALL
S10146		T2L1-6 BVCU GND PWR TEST SW	PSE1070	1	71-51-11 ENG/ /	115-199
S10150		102TL1-7 BVCU GND TEST SW.	UL20373 49367	1	71-51-11 ENG/ /	ALL

EQUIPMENT LIST

D280N032

Section S10100

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10151		102TLI-6 SW-GND TEST	10E80008 K0680	2	75-31-11 ENG/ /	ALL
S10159		2100-8 SW-ENTRY LT,MID FWD ATTEND PNL	417N6002 91929	1	33-22-12 P023-00/ /	001-099
S10159		2100-8 SW-ENTRY LT,MID FWD ATTEND PNL	417N6011 91929	1	33-22-12 P076-00/ /	115-199
S10159 T		2100-100 LENS-ENTRY LTS SW MID ATTEND PNL	417N6002 91929	1	33-22-12 P023-00/ /	001-099
S10159 T		2100-100 LENS-ENTRY LTS SW MID ATTEND PNL	417N6011 91929	1	33-22-12 P076-00/ /	115-199
S10165		SEEPARTA-B SW-DOOR OPEN/CLOSED,FLT DK DOOR ASSY	417N1079 81205	1	33-22-11 0308/244/R002	ALL
S10165A		60B40018-32 SW-FLT DECK OPEN/CLOSE DOOR ACTUATOR	417N1106 81205	1	33-22-11 0308/244/R002	ALL
S10165B		60B40018-42 SW-FLT DECK OPEN/CLOSE DOOR SENSOR	81205	1	33-22-11 0308/250/R.35	ALL
S10167		2100-8 SW-THRESHOLD LTS,AFT ATTEND PNL	417N6002 91929	1	33-22-14 P022-00/ /	ALL
S10167 T		2100-100 LENS-THRESHOLD LTS,SW ATTEND PNL	417N6002 81205	1	33-22-14 P022-00/ /	ALL
S10169		S210N701-8 SW-TEMP CONTROL,AFT CARGO	215N3006 81205	1	21-44-11 1200/174/R033	ALL
S10170		2PB11-T2 SW-EICAS DISPLAY,CANCEL	232N2101 91929	1	31-41-14 P001-03/ /	ALL
S10172		S231T290-235 SW-GND PROX FLAP OVERRIDE	233N2222 81205	1	34-46-11 P003-01/ /	ALL
S10179		79-1970 SW-BOARDING MUSIC REMOTE CONTROL	417N6002 91812	1	23-34-16 P021-00/ /	115-199
S10180		MS25307-262 SW-DOOR CONTROL	284N1339 96906	1	52-34-11 578/200/R020	ALL
S10181		MS25307-262 SW-DR CONTROL	284N1339 96906	1	52-35-11 1397/204/R016	ALL
S10182		MS25307-272 SW-CARGO DR CONTROL	284N1338 96906	1	52-35-11 P044-00/ /	ALL

EQUIPMENT LIST

D280N032

Section S10100

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10183		MS25307-272 SW-CARGO DOOR CONTROL	284N1338 96906	1	52-34-11 P043-00/ /	ALL
S10189		60B92400-3 SW-PRESS,PUMP SYS	343N3301 81205	1	28-25-11 IRSS180/ /LRS	ALL
S10190		MS24658-26F SW-ALL DOORS OPEN	284N1446 96906	1	32-12-11 1218/133/R025	ALL
S10191		MS24658-26F SW-ALL DOORS OPEN ARM	284N1446 96906	1	32-12-11 1218/133/R025	ALL
S10192		MS24658-26F SW-MAIN GEAR D00RS CLOSE	284N1446 96906	1	32-12-12 1216/133/R025	ALL
S10193		MS24658-26F SW-CLOSE,NOSE GEAR DOOR	284N1069 96906	1	32-12-12 P063-00/ /	ALL
S10194		975-0304-003 SW-OVHT,L STRUT,LOOP 1,NO 1	312N5504 97896	1	26-12-11 PPS135/ /	ALL
S10195		975-0304-004 SW-OVHT,L STRUT,LOOP 1,NO 2	312N5504 97896	1	26-12-11 PPS166/154/	ALL
S10196		975-0304-003 SW-OVHT,L STRUT,LOOP 1,NO 3	312N5504 97896	1	26-12-11 PPS185/ /	ALL
S10197		975-0304-004 SW-OVHT,L STRUT,LOOP 2,NO 2	312N5504 97896	1	26-12-11 PPS166/154/	ALL
S10198		975-0304-003 SW-OVHT,L STRUT,LOOP 2,NO 1	312N5504 97896	1	26-12-11 PPS135/ /	ALL
S10199		975-0304-003 SW-OVHT,L STRUT,LOOP 2,NO 3	312N5504 97896	1	26-12-11 PPS185/ /	ALL

EQUIPMENT LIST

D280N032

Section S10100

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10200		975-0304-004 SW-OVHT,R STRUT,LOOP 1,NO 2	312N5504 97896	1	26-12-21 PPS166/154/R	ALL
S10201		975-0304-003 SW-OVHT,R STRUT,LOOP 1,NO 1	312N5504 97896	1	26-12-21 PPS135/ /	ALL
S10202		975-0304-003 SW-OVHT,R STRUT,LOOP 1,NO 3	312N5504 97896	1	26-12-21 PPS185/ /	ALL
S10203		975-0304-004 SW-OVHT,R STRUT,LOOP 2,NO 2	312N5504 97896	1	26-12-21 PPS166/154/R	ALL
S10204		975-0304-003 SW-OVHT,R STRUT,LOOP 2,NO 1	312N5504 97896	1	26-12-21 PPS135/ /	ALL
S10205		975-0304-003 SW-OVHT,R STRUT,LOOP 2,NO 3	312N5504 97896	1	26-12-21 PPS185/ /	ALL
S10207		MS25307-272 SW-AFT CARGO LOADER CONTROL	451N7230 96906	1	25-51-21 1400/200/L020	115-199
S10209		60B40018-42 SW-FWD CARGO LOADER RETR LIMIT	451N7150 81205	1	25-51-11 0699/196/R050	115-199
S10210		60B40018-42 SW-AFT CARGO LOADER RETR LIMIT	451N7250 81205	1	25-51-21 1301/196/R050	115-199
S10212		GAC1001-4 SW-AFT CARGO LOADER EXT LIMIT	451N7250 81205	1	25-51-21 1206/190/R049	115-199
S10214		60B40018-42 SW-GIRT BAR PROX SNSR A,NO 1 PASS DR,L	284N1420 81205	1	25-66-11 0343/208/L066	ALL
S10215		60B40018-42 SW-GIRT BAR PROX SNSR B,NO 1 PASS DR,L	284N1420 81205	1	25-66-11 0360/210/L065	ALL
S10216		60B40018-42 SW-GIRT BAR PROX SNSR A,NO 1 PASS DR,R	284N1420 81205	1	25-66-11 332/208/R066	ALL
S10217		60B40018-42 SW-GIRT BAR PROX SNSR B,NO 1 PASS DR,R	284N1420 81205	1	25-66-11 362/210/R065	ALL
S10218		60B40018-42 SW-GIRT BAR PROX SNSR A,NO 2 PASS DR,L	284N1420 81205	1	25-66-11 720/210/L065	ALL
S10219		60B40018-42 SW-GIRT BAR PROX SNSR B,NO 2 PASS DR,L	284N1420 81205	1	25-66-11 725/210/L065	ALL
S10220		60B40018-42 SW-GIRT BAR PROX SNSR A,NO 2 PASS DR,R	284N1420 81205	1	25-66-11 695/210/R065	ALL

EQUIPMENT LIST

D280N032

Section S10200

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10221		60B40018-42 SW-GIRT BAR PROX SNSR B,NO 2 PASS DR,R	284N1420 81205	1	25-66-11 720/210/R065	ALL
S10222		60B40018-42 SW-GIRT BAR PROX SNSR A,NO 4 PASS DR,L	284N1420 81205	1	25-66-11 1644/210/L060	ALL
S10223		60B40018-42 SW-GIRT BAR PROX SNSR B,NO 4 PASS DR,L	284N1420 81205	1	25-66-11 1679/210/L060	ALL
S10224		60B40018-42 SW-GIRT BAR PROX SNSR A,NO 4 PASS DR,R	284N1420 81205	1	25-66-11 1644/210/R065	ALL
S10225		60B40018-42 SW-GIRT BAR PROX SNSR B,NO 4 PASS DR,R	284N1420 81205	1	25-66-11 1684/208/R060	ALL
S10228		GBC-300-89 SW-BARO,BASS,LEFT	212N3001	1	36-11-12 0902/150/R036	ALL
S10229		GBC-300-89 SW-BARO,BASS,RIGHT	212N3001	1	36-11-22 0901/150/R036	ALL
S10230		2PB11-T2 SW-EICAS DISPLAY,RECALL	232N2101 91929	1	31-41-19 P001-03/ /	ALL
S10231		S231T290-257 SW-GND PROX/CONFIG GEAR OVRD	233N8200	1	31-51-31 P003-01/ /	ALL
S10234		10AT96-1 SW-RIGHT COLUMN-INBD AFT	251N2564 82647	1	27-41-11 239/188/R029	ALL
S10235		10AT96-1 SW-RIGHT COLUMN-INBD FWD	251N2564 82647	1	27-41-11 0239/188/R030	ALL
S10236		10AT96-1 SW-LEFT COLUMN-INBD AFT	251N2564 82647	1	27-41-21 232/190/L20	ALL
S10237		10AT96-1 SW-LEFT COLUMN-INBD FWD	251N2564 82647	1	27-41-21 231/190/L20	ALL
S10238	1	S283T006-10 SW-PROX SNSR,NOSE GEAR UP,SYS 1	284N1623 81205	1	32-61-11 350/192/L018	ALL
S10238	2	S283T006-5 SW-PROX SNSR,NOSE GEAR UP,SYS 1	284N1623 81205	1	32-61-11 350/192/L018	ALL
S10239	1	S283T006-28 SW-PROX SNSR,R GEAR UP AND LOCKED,SYS 1	284N1612 81205	1	32-61-11 MLG/ /	ALL
S10239	2	S283T006-8 SW-PROX SNSR,R GEAR UP AND LOCKED,SYS 1	284N1612 81205	1	32-61-11 MLG/ /	ALL

EQUIPMENT LIST

D280N032

Section S10200

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10239	3	S283T006-3 SW-PROX SNSR,R GEAR UP AND LOCKED,SYS 1	284N1612 81205	1	32-61-11 MLG/ /	ALL
S10240	1	S283T006-28 SW-PROX SNSR,L GEAR UP AND LOCKED,SYS 1	284N1612 81205	1	32-61-11 1118/185/60	ALL
S10240	2	S283T006-8 SW-PROX SNSR,L GEAR UP AND LOCKED,SYS 1	284N1612 81205	1	32-61-11 1118/185/60	ALL
S10240	3	S283T006-3 SW-PROX SNSR,L GEAR UP AND LOCKED,SYS 1	284N1612 81205	1	32-61-11 MLG/ /	ALL
S10241	1	S283T006-10 SW-PROX SNSR,R GEAR DOOR CLOSED,SYS 1	284N1445 81205	1	32-61-11 RWW/ /	ALL
S10241	2	S283T006-5 SW-PROX SNSR,R GEAR DOOR CLOSED,SYS 1	284N1445 81205	1	32-61-11 RWW/ /	ALL
S10242	1	S283T006-10 SW-PROX SNSR,L GEAR DOOR CLOSED,SYS 1	284N1445 81205	1	32-61-11 1064/145/L061	ALL
S10242	2	S283T006-5 SW-PROX SNSR,L GEAR DOOR CLOSED,SYS 1	284N1445 81205	1	32-61-11 LWW/ /	ALL
S10243	1	S283T006-10 SW-PROX SNSR,NOSE GEAR DOOR CLOSED,SYS 1	284N1406 81205	1	32-61-11 263/158/L009	ALL
S10243	2	S283T006-5 SW-PROX SNSR,NOSE GEAR DOOR CLOSED,SYS 1	284N1406 81205	1	32-61-11 263/158/L009	ALL
S10246		S271T452-10 SW-PRESS,PTU IND	271N2040 81205	1	29-22-11 1065/172/L005	ALL
S10254	1	S231T290-4001 SW-FLAP ARM	233N2222 81205	1	27-51-21 P003-01/ /	001-099
S10254	1	S231T290-5001 SW-FLAP ARM	233N2222 81205	1	27-51-21 P003-01/ /	115-199
S10254	2	S231T290-5001 SW-FLAP ARM	233N2222 81205	1	27-51-21 P003-01/ /	001-099
S10254	2	S231T290-3001 SW-FLAP ARM	233N2222 81205	1	27-51-21 P003-01/ /	115-199
S10255	1	S231T290-4001 SW-SLAT ARM	233N2222 81205	1	27-51-21 P003-01/ /	001-099
S10255	1	S231T290-5001 SW-SLAT ARM	233N2222 81205	1	27-51-21 P003-01/ /	115-199

EQUIPMENT LIST

D280N032

Section S10200

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10255	2	S231T290-4001 SW-SLAT ARM	233N2222 81205	1	27-51-21 P003-01/ /	001-099
S10255	2	S231T290-3001 SW-SLAT ARM	233N2222 81205	1	27-51-21 P003-01/ /	115-199
S10256		AC45-0035 SW-ALT FLAP/SLAT POSN	233N2222 91812	1	27-51-11 P003-01/ /	ALL
S10258		MS21321-2 SW-LIMIT,RAT STOWED	271N0174 96906	1	29-21-31 1235/157/R035	ALL
S10259		214C40-1-71 SW-10K/FT CABIN PRESS	284N1316 02750	1	33-24-11 P034-00/ /	ALL
S10260		MS24524-26 SW-ALT L/G EXT	233N2222 81205	1	32-35-11 P003-01/ /	001-099
S10260		S231T290-5076 SW-ALT L/G EXT	233N2222 81205	1	32-35-11 P003-01/ /	115-199
S10260 T		MS25237-387 LAMP-ALT L/G EXT	S231T290 96906	2	32-35-11 P003-01/ /	115-199
S10260 U		851-30768-3823 MODULE-DIODE/FUSE	S231T290 96182	1	32-35-11 P003-01/ /	115-199
S10262		S271T452-5 SW-ELEV HI PRESS,R	251N2024 81205	1	27-23-11 1850/265/R018	ALL
S10263		S271T452-5 SW-ELEV HI PRESS,C	251N2027 81205	1	27-23-11 1863/275/L015	ALL
S10264		S271T452-5 SW-ELEV HI PRESS,L	251N2026 81205	1	27-23-11 1863/265/L010	ALL
S10265		S271T452-12 SW-ELEV LO PRESS,R	251N2024 81205	1	27-23-11 1850/265/R018	ALL
S10266		S271T452-12 SW-ELEV LO PRESS,C	251N2027 81205	1	27-23-11 1863/275/L015	ALL
S10267		S271T452-12 SW-ELEV LO PRESS,L	251N2026 81205	1	27-23-11 1863/265/L010	ALL
S10271		920055 SW-PASS CALL	417N3100 97564	69	33-25-31 MULTI/ /	001-003, 005, 007-099
S10271		920055 SW-PASS CALL	417N3100 97564	68	33-25-31 MULTI/ /	004, 006

EQUIPMENT LIST

D280N032

Section S10200

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10271		920055 SW-PASS CALL	417N3100 97564	73	33-25-31 MULTI/ /	115-199
S10271 T		387 LAMP-PASS CALL SW	417N3100 08806	9	33-25-31 MULTI/ /	001-099
S10271 T		387 LAMP-PASS CALL SW	417N3100 08806	73	33-25-31 MULTI/ /	115-199
S10272		1TW2-3 SW-PASS CALL SELECT	417N3100 27193	9	33-25-31 MULTI/ /	001-099
S10272		2TW2-3 SW-PASS CALL SELECT	417N3100 27193	73	33-25-31 MULTI/ /	115-199
S10273		920056 SW-PASS READ LT	417N3100 97564	69	33-23-31 MULTI/ /	001-003, 005, 007-099
S10273		920056 SW-PASS READ LT	417N3100 97564	68	33-23-31 MULTI/ /	004, 006
S10273		920056 SW-PASS READ LT	417N3100 97564	72	33-23-31 MULTI/ /	115-199
S10274		920056 SW-PASS READ LT	417N3100 97564	69	33-23-31 MULTI/ /	001-003, 005, 007-099
S10274		920056 SW-PASS READ LT	417N3100 97564	68	33-23-31 MULTI/ /	004, 006
S10274		920056 SW-PASS READ LT	417N3100 97564	72	33-23-31 MULTI/ /	115-199
S10275		920056 SW-PASS READ LT	417N3100 97564	69	33-23-31 MULTI/ /	001-003, 005, 007-099
S10275		920056 SW-PASS READ LT	417N3100 97564	68	33-23-31 MULTI/ /	004, 006
S10275		920056 SW-PASS READ LT	417N3100 97564	72	33-23-31 MULTI/ /	115-199
S10276		920055 SW-PASS CALL	417N3100 97564	2	33-25-31 MULTI/ /	001-099
S10276		920055 SW-PASS CALL	417N3100 97564	1	33-25-31 MULTI/ /	115-199
S10276 T		387 LAMP-PASS CALL SW	417N3100 08806	2	33-25-31 MULTI/ /	001-099

EQUIPMENT LIST

D280N032

Section S10200

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10276 T		387 LAMP-PASS CALL SW	417N3100 08806	1	33-25-31 MULTI/ /	115-199
S10277		1TW2-3 SW-PASS CALL SELECT	417N3100 27193	2	33-25-31 MULTI/ /	001-099
S10277		2TW2-3 SW-PASS CALL SELECT	417N3100 27193	1	33-25-31 MULTI/ /	115-199
S10278		920056 SW-PASS READ LT	417N3100 97564	2	33-23-31 MULTI/ /	ALL
S10279		920056 SW-PASS READ LT	417N3100 97564	2	33-23-31 MULTI/ /	ALL
S10280		920056 SW-PASS READ LT	417N3100 97564	2	33-23-31 MULTI/ /	ALL
S10286		920055 SW-PASS CALL	417N3200 97564	1	33-25-31 MULTI/ /	001-099
S10286		920055 SW-PASS CALL	417N3200 97564	3	33-25-31 MULTI/ /	115-199
S10286 T		387 LAMP-PASS CALL SW	417N3200 08806	1	33-25-31 MULTI/ /	001-099
S10286 T		387 LAMP-PASS CALL SW	417N3200 08806	3	33-25-31 MULTI/ /	115-199
S10287		1TW2-3 SW-PASS CALL SELECT	417N3200 27193	1	33-25-31 MULTI/ /	001-099
S10287		2TW2-3 SW-PASS CALL SELECT	417N3200 27193	3	33-25-31 MULTI/ /	115-199
S10288		920056 SW-PASS READ LT	417N3200 97564	1	33-23-31 MULTI/ /	001-099
S10288		920056 SW-PASS READ LT	417N3200 97564	3	33-23-31 MULTI/ /	115-199
S10289		920056 SW-PASS READ LT	417N3200 97564	1	33-23-31 MULTI/ /	001-099
S10289		920056 SW-PASS READ LT	417N3200 97564	3	33-23-31 MULTI/ /	115-199
S10291		920056 SW-ATT WK LT	417N3700 97564	1	33-23-31 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section S10200

Page 6

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10292		2100-7 SW-EMER LT TEST,FWD	411N2331 81205	1	33-51-12 0345/285/L039	ALL
S10292 T		2100-100 LENS-EMER TEST SW,FWD	411N2331 81205	1	33-51-12 0345/285/L039	ALL
S10292 U		2100-11 GUARD-EMER LT TEST SW	411N2331 81205	1	33-51-12 0345/285/L039	ALL
S10293		2100-7 SW-EMER LT TEST	411N2009 81205	1	33-51-13 0694/284/L047	ALL
S10293 T		2100-100 LENS-EMER TEST SW,MID FWD	411N2009 81205	1	33-51-13 694/284/L047	ALL
S10293 U		2100-11 GUARD-EMER LT TEST SW	411N2009 81205	1	33-51-13 0694/284/L047	ALL
S10294		2100-7 SW-EMER LT TEST,MID AFT	411N2361 81205	1	33-51-14 1326/262/L061	ALL
S10294 T		2100-100 LENS-EMER TEST SW,MID AFT	411N2361 81205	1	33-51-14 1326/262/L061	ALL
S10294 U		2100-11 GUARD-EMER LT TEST SW	411N2361 81205	1	33-51-14 1326/262/L061	ALL
S10295		2100-7 SW-EMER LTS TEST,AFT	411N2331 81205	1	33-51-15 1656/286/L038	ALL
S10295 T		2100-100 LENS-EMER TEST SW,AFT	411N2331 81205	1	33-51-15 1656/286/L038	ALL
S10295 U		2100-11 GUARD-EMER LT TEST SW	411N2331 81205	1	33-51-15 1656/286/L038	ALL
S10296		2100-6 SW-GND SERVICE LTS	417N6002 91929	1	24-51-51 P021-00/ /	ALL
S10296 T		2100-100 LENS-GND SERVICE LTS SW	417N6002 81205	1	24-51-51 P021-00/ /	ALL
S10297		2100-13 SW-EMER LT CONT	417N6002 81205	1	33-51-11 P021-00/ /	ALL
S10297 T		2100-101 LENS-EMER LT CONT SW (P21)	417N6002 81205	1	33-51-11 P021-00/ /	ALL
S10297A		2100-11 GUARD-EMER LT CONT SW	417N6002 81205	1	33-51-11 P021-00/ /	ALL

EQUIPMENT LIST

D280N032

Section S10200

Page 7

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10298		44-MY-232404 SW-CEILING LTS CONTROL	417N6002 81073	1	33-21-11 P021-00/ /	ALL
S10299		44-YY-26087 SW-SIDEWALL LTS CONTROL	417N6002 81073	1	33-21-31 P021-00/ /	ALL

EQUIPMENT LIST

D280N032

Section S10200

Page 8 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10300		2100-8 SW-WORK LTS FWD,ATT PNL	417N6002 91929	1	33-22-11 P021-00/ /	ALL
S10300 T		2100-100 LENS-WORK LTS,SW ATTEND PNL(P21)	417N6002 81205	1	33-22-11 P021-00/ /	ALL
S10301		2100-8 SW-THRESHOLD LTS,FWD ATT PNL	417N6002 91929	1	33-22-11 P021-00/ /	ALL
S10301 T		2100-100 LENS-THRESHOLD LTS,SW ATTEND PNL(P21)	417N6002 81205	1	33-22-11 P021-00/ /	ALL
S10302		44-YY-26087 SW-ENTRY LTS,FWD ATT PNL	417N6002 81073	1	33-22-11 P021-00/ /	ALL
S10305		S210T130-27 SW-PACK ALT,LEFT	212N1001 81205	1	21-51-12 0895/155/L038	ALL
S10308		MS25008-1 SW-L CAPT PEDAL-AIDS	274N2013 96906	1	31-31-13 215/180/L015	115-199
S10309		MS25008-1 SW-R CAPT PEDAL-AIDS	274N2013 96906	1	31-31-13 215/180/L010	115-199
S10311		MS25306-222 SW-CARGO LTS	284N1662 96906	1	33-37-21 E006-00/ /	115-199
S10323		S271T452-8 SW-PRESS,RAM AIR TURBINE	271N0174 81205	1	29-21-31 1177/156/R017	ALL
S10325		641137-1 SWITCH-COMP OVERHEAT,LEFT PACK	S210T130 70210	1	21-51-15 0970/155/L030	ALL
S10326		641137-1 SWITCH-COMP OVERHEAT,RIGHT PACK	S210T130 70210	1	21-51-25 0970/151/R036	ALL
S10328		MS25306-222 SW-HYDRAULIC SERVICE CENTER LTS	284N1483 96906	1	33-31-21 1183/136/L031	ALL
S10329		D20011-01 SW-FLA TEST	284N1360 81640	1	27-51-51 475/160/R025	ALL
S10331		920056 SW-ATT WK LT	417N3700 97564	1	33-23-31 MULTI/ /	115-199
S10332		32V92 PRESS SW-AFT PLENUM	453N2210 09049	1	26-16-21 1351/177/R052	ALL
S10333		32V92 PRESS SW-FWD PLENUM	453N2210 09049	1	26-16-21 605/203/R013	ALL

EQUIPMENT LIST

D280N032

Section S10300

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10334		6510-X SW-Q,RAT ARM	284N1050 07147	1	29-21-31 0435/193/L046	ALL
S10336		2100-8 SW-WORK LT,AFT ATTENDANT PNL	417N6002 91929	1	33-22-14 P022-00/ /	ALL
S10336 T		2100-100 LENS-WORK LTS,SW ATTENDANT PNL	417N6002 91929	1	33-22-14 P022-00/ /	ALL
S10338		31EN102-6 SW-SLAT LOSS SENSING,R INBD	251N5016 91929	1	27-81-31 FSS106/WRP/R090	ALL
S10339		21EN262-6 SW-SLAT LOSS SENSING,R OUTBD	251N5153 91929	1	27-81-31 OSS627/ /RLE	ALL
S10340		31EN101-6 SW-SLAT LOSS SENSING,L INBD	251N5016 91929	1	27-81-31 FSS106/WRP/L090	ALL
S10341		21EN262-6 SW-SLAT LOSS SENSING,L OUTBD	251N5153 91929	1	27-81-31 OSS630/WRP/L090	ALL
S10350	1	S283T006-10 PROX SNSR A-NO.1 CARGO DR OPEN	284N1364 81205	1	52-34-11 575/202/R065	ALL
S10350	2	S283T006-5 PROX SNSR A-NO.1 CARGO DR OPEN	284N1364 81205	1	52-34-11 575/202/R065	ALL
S10352	1	S283T006-10 PROX SNSR A-NO.1 CARGO DR DN	284N1364 81205	1	52-34-11 0560/169/R046	ALL
S10352	2	S283T006-5 PROX SNSR A-NO.1 CARGO DR DN	284N1364 81205	1	52-34-11 0560/169/R046	ALL
S10357	1	S283T006-10 PROX SNSR A-NO.2 CARGO DR OPEN	284N1463 81205	1	52-35-11 1394/194/R059	ALL
S10357	2	S283T006-5 PROX SNSR A-NO.2 CARGO DR OPEN	284N1463 81205	1	52-35-11 1394/194/R059	ALL
S10359	1	S283T006-10 PROX SNSR A-NO.2 CARGO DR DN	284N1463 81205	1	52-35-11 1380/160/R044	ALL
S10359	2	S283T006-5 PROX SNSR A-NO.2 CARGO DR DN	284N1463 81205	1	52-35-11 1380/160/R044	ALL
S10361		702PB1 SW-PTT,NOSE GEAR DOOR UNSAFE LT	284N1069 91929	1	32-12-12 P063-00/ /	ALL
S10362		31EN1-6 SW-NOSE GEAR DOOR LOCK	273N4034 96906	1	32-12-12 273/173/L028	ALL

EQUIPMENT LIST

D280N032

Section S10300

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10363	1	31EN94-6 SW-MAIN GEAR DOOR LOCK,R	273N4041 91929	1	32-12-12 1121/180/R002	ALL
S10363	2	31EN11-6 SW-MAIN GEAR DOOR LOCK,R	273N4041 91929	1	32-12-12 1121/180/R002	ALL
S10364		31EN1-6 SW-MAIN GEAR DOOR LOCK,L	273N4041 91929	1	32-12-12 1121/180/L002	ALL
S10365	1	MS24524-30 SW-PTT,MAIN GEAR DOOR UNSAFE LT	284N1446 96906	1	32-12-12 1216/133/R025	ALL
S10365	2	MS24524-26 SW-PTT,MAIN GEAR DOOR UNSAFE LT	284N1446 96906	1	32-12-12 1216/133/R025	ALL
S10366		S271T452-11 SW-HYDRAULIC PRESSURE	271N6412 81205	1	32-35-11 0384/187/L043	ALL
S10368		44-YY-26087 SW-AFT GALLEY (G4B) LIGHT CONTROL	417N6002 81073	1	33-27-31 P022-00/ /	115-199
S10369		44-YY-26087 SW-FWD GALLEY (G1A) LIGHT CONTROL	417N6002 81073	1	33-27-11 P021-00/ /	115-199
S10370		21EN107-6 SW-MAIN GEAR DOOR CLOSED,R	284N1445 91929	1	32-12-12 1070/145/	ALL
S10371		21EN107-6 SW-MAIN GEAR DOOR CLOSED,L	284N1445 81205	1	32-12-12 1063/140/L062	ALL
S10372		21EN107-6 SW-NOSE GEAR DOOR CLOSED	284N1406 81205	1	32-12-12 263/159/L008	ALL
S10379		26ET24-3 SW-EEC GND TEST,L	284N1375 91929	1	75-31-11 454/161/L026	ALL
S10380		26ET24-3 SW-EEC GND TEST,R	284N1375 91929	1	75-31-11 482/160/L021	ALL
S10381		920056 SW-PASS READ LT	417N3100 97564	1	33-23-31 MULTI/ /	115-199
S10382		920056 SW-PASS READ LT	417N3100 97564	1	33-23-31 MULTI/ /	115-199
S10383		920056 SW-PASS READ LT	417N3100 97564	1	33-23-31 MULTI/ /	115-199
S10384		2TW2-3 SW-PASS CALL SELECT	417N3100 27193	1	33-25-31 MULTI/ /	115-199

EQUIPMENT LIST

D280N032

Section S10300

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10385		920055 SW-PASS CALL	417N3100 97564	1	33-25-31 MULTI/ /	115-199
S10385 T		387 LAMP-PASS CALL SW	417N3100 08806	1	33-25-31 MULTI/ /	115-199
S10390	1	S231T290-4081 SW-RESERVE BRAKE	233N2221 81205	1	29-21-32 P001-03/ /	001-099
S10390	1	S231T290-5081 SW-RESERVE BRAKE	233N2221 81205	1	29-21-32 P001-03/ /	115-199
S10390	2	S231T290-5081 SW-RESERVE BRAKE	233N2221 81205	1	29-21-32 P001-03/ /	001-099
S10390	2	S231T290-3081 SW-RESERVE BRAKE	233N2221 81205	1	29-21-32 P001-03/ /	115-199

EQUIPMENT LIST

D280N032

Section S10300

Page 4 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10471	9	MS24525-23 SW-ALTERNATE VMO/MMO SELECT	284N1360 96906	1	34-12-12 475/163/R028	115-199
S10479		44-YY-26087 SW-ENTERTAINMENT SYSTEM	417N6002 81073	1	23-34-15 P021-00/ /	ALL

EQUIPMENT LIST

D280N032

Section S10400
Page 1 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10533	1	975-0172-006 SW-AIR SUPPLY OVHT,L	212N3001 97896	1	36-22-11 0902/150/L065	ALL
S10533	2	3000-46-29 SW-AIR SUPPLY OVHT,L	212N3001 14604	1	36-22-11 0902/150/L065	ALL
S10540		S271T452-15 SW-PRESS,ENG HYD PUMP L	271N2001 81205	1	29-11-13 PPS210/ /	ALL
S10541		S271T452-15 SW-PRESS,ENG HYD PUMP,R	271N2001 81205	1	29-11-22 PPN210/ /R	ALL
S10561	9	21EN107-6 SW-NO.1 CARGO DOOR MOTOR INTERLOCKED	284N1391 81205	1	52-34-11 0600/180/R067	ALL
S10561		21EN107-6 SW-NO.1 CARGO DOOR MOTOR INTERLOCKED	284N1391 81205	1	52-34-11 0600/180/R067	ALL
S10562		21EN107-6 SW-NO.2 CARGO DOOR MOTOR INTERLOCKED	284N1391 81205	1	52-35-11 1420/172/R066	ALL
S10563		D2-729B001 ATC-ANTENNA LINE SWITCH, TOP	284N1880 50667	1	34-53-11 E003-03/ /	001-009, 115-199
S10563		402-167 ATC-ANTENNA LINE SWITCH, TOP	284N1880 00471	1	34-53-11 E003-03/ /	010-099
S10563	1	D2-729B005 ATC-ANTENNA LINE SWITCH, TOP	284N1880 50667	1	34-53-11 E003-03/ /	010-099
S10563	2	D2-729B001 ATC-ANTENNA LINE SWITCH, TOP	284N1880 50667	1	34-53-11 E003-03/ /	010-099
S10564		D2-729B001 ATC-ANTENNA LINE SWITCH, BOTTOM	284N1880 50667	1	34-53-11 E003-02/ /	001-009, 115-199
S10564		402-167 ATC-ANTENNA LINE SWITCH, BOTTOM	284N1880 00471	1	34-53-11 E003-02/ /	010-099
S10564	1	D2-729B005 ATC-ANTENNA LINE SWITCH, BOTTOM	284N1880 50667	1	34-53-11 E003-02/ /	010-099
S10564	2	D2-729B001 ATC-ANTENNA LINE SWITCH, BOTTOM	284N1880 50667	1	34-53-11 E003-02/ /	010-099
S10565		7GR953 SW-PRESS,AFT CARGO FIRE EXT DISCH LINE	208N4667 09049	1	26-23-11 1190/160/	115-199
S10580		10AT96-1 SW-STANDBY TRIM	254N1055 82647	1	27-41-31 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section S10500

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10588	9	251N5046-2 SW-SLAT LOSS SENSING,R INBD (SB 27-0117)	251N5017 CUST	1	27-81-31 FSS248/+9/R217	ALL
S10589	9	251N5046-1 SW-SLAT LOSS SENSING,L INBD (SB 27-0117)	251N5017 CUST	1	27-81-31 FSS248/+9/L217	ALL

EQUIPMENT LIST

D280N032

Section S10500
Page 2 End
Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10680	9	S231T290-4057 SW-GND PROX TERRAIN OVERRIDE (SB 34-0200)	233N2222 81205	1	34-46-11 P003-01/ /	002
S10697	9	8-527-03 SW-GEAR TILT-RIGHT GEAR (SB 27A0130)	284N1613 08748	1	27-62-11 1283/74/140	ALL

EQUIPMENT LIST

D280N032

Section S10600

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10711	9	64AT34-7E SW- FUEL TEST AUTO S/O - R (SB 28A0081)	284N1270 91929	0	28-22-11 E002-01/ /	ALL
S10712	9	64AT34-7E SW- FUEL TEST AUTO S/O - L (SB 28A0081)	284N1270 91929	1	28-22-11 E002-01/ /	ALL

EQUIPMENT LIST

D280N032

Section S10700
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00101		S282T001-1 TRU-LEFT	284N1312 81205	1	24-32-11 E001-02/ /	ALL
T00102		S282T001-1 TRU-RIGHT	284N1311 81205	1	24-32-11 E001-01/ /	ALL
T00103		10-60011-2 XFMR RECT UNIT-GND HDLG BUS (PLATE E)	284N1316 81205	1	24-54-61 P034-00/ /	ALL
T00105		S281T001-4 XFMR-DIFF PROT CUR,GEN,L	284N1314 81205	1	24-23-11 P031-00/ /	ALL
T00106		S281T001-4 XFMR-DIFF PROT CUR,L GEN	81205	1	24-23-11 P6-3/ /	ALL
T00107		S281T001-4 XFMR-DIFF PROT CUR,R GEN	284N1315 81205	1	24-23-11 P032-00/ /	ALL
T00108		S281T001-4 XFMR-DIFF PROT CUR,R GEN	81205	1	24-23-11 P6-4/ /	001-099
T00108		S281T001-4 XFMR-DIFF PROT CUR,R GEN	81205	1	24-23-11 P006-04/ /	115-199
T00111		S281T001-4 XFMR-DIFF PROT CUR,APU GEN	284N1316 81205	1	24-23-11 P034-00/ /	ALL
T00112		S281T001-4 XFMR-DIFF PROT CUR,TIE BUS,L	284N1314 81205	1	24-23-12 P031-00/ /	ALL
T00113		S281T001-4 XFMR-DIFF PROT CUR,TIE BUS,R	284N1315 81205	1	24-23-11 P032-00/ /	ALL
T00115		S281T001-4 XFMR-DIFF PROT CUR,TIE BUS APU	284N1316 81205	1	24-23-12 P034-00/ /	ALL
T00116		S281T001-4 XFMR-DIFF PROT CUR,TIE BUS EXT	284N1316 81205	1	24-23-12 P034-00/ /	ALL
T00122		S281T001-4 XFMR-CURRENT,GROUND POWER	284N1316 81205	1	24-41-11 P034-00/ /	ALL
T00123		60B40026-14 XFMR-28V AC BUS,LEFT	284N1129 81205	1	24-53-11 P070-00/ /	ALL
T00124		60B40026-14 XFMR-28V AC BUS,RIGHT	284N1318 81205	1	24-53-21 P033-00/ /	ALL
T00126		60B40026-13 XFMR-28V AC BUS,GND SERVICE	284N1316 81205	1	24-53-51 P034-00/ /	001-099

EQUIPMENT LIST

D280N032

Section T00100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00126		60B40026-13 XFMR-28V AC BUS,GND SERVICE	284N1127 81205	1	24-53-51 P037-00/ /	115-199
T00127		S281T001-4 XFMR-CURRENT,OVERLAP,L	284N1314 81205	1	24-23-11 P031-00/ /	ALL
T00128		S281T001-4 XFMR-CURRENT,OVERLAP,R	284N1315 81205	1	24-23-11 P032-00/ /	ALL
T00129		FT1221 XFMR-FIXED LDG LT,LEFT	284N1111 14752	1	33-42-11 FSS94/ /	ALL
T00130		FT1221 XFMR-FIXED LDG LT,RIGHT	284N1111 14752	1	33-42-11 FSS84/184/RW88	001-099
T00130		FT1221 XFMR-FIXED LDG LT,RIGHT	284N1111 14752	1	33-42-11 0880/184/RW88	115-199
T00137		FT1222 XFMR-RUNWAY TURNOFF LT,LEFT	284N1761 14752	1	33-42-21 P063-00/ /	ALL
T00138		FT1222 XFMR-RUNWAY TURNOFF LT,RIGHT	284N1761 14752	1	33-42-21 P062-00/ /	ALL
T00139		10615 XFMR-AIR DATA COMPUTER,LEFT	284N1125 95266	1	34-12-11 P036-00/ /	ALL
T00140		10615 XFMR-AIR DATA COMPUTER,RIGHT	284N1320 95266	1	34-12-21 P037-00/ /	ALL
T00141		60B40026-20 XFMR-WHEEL WELL LIGHT	284N1441 81205	1	33-31-11 1178/189/R036	ALL
T00142		FT1222 XFMR-TAXI LIGHT	284N1761 14752	1	33-42-31 / /	001-099
T00143		FT1221 XFMR-NLG LDG LT,LEFT	284N1761 14752	1	33-42-11 P063-00/ /	ALL
T00144		FT1221 XFMR-NLG LDG LT,RIGHT	284N1761 14752	1	33-42-11 P062-00/ /	ALL
T00148		60B40026-17 XFMR-FWD CARGO COMPT LTS	284N1747 81205	1	33-37-11 P065-00/ /	ALL
T00149		60B40026-20 XFMR-COMPT LTS,APU & TAILCONE	284N1481 81205	1	33-31-31 1744/271/L036	ALL
T00153		60B40026-20 XFMR-FSEU-2 SENSOR EXCT	284N1129 81205	1	27-51-61 P070-00/ /	001-099

EQUIPMENT LIST

D280N032

Section T00100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00153		60B40026-19 XFMR-FSEU-2 SENSOR EXCT	284N1129 81205	1	27-51-61 P070-00/ /	115-199
T00155		314-14544-01 XFMR-R SYS HYD LEAK DET CURRENT	284N1314 95266	1	29-11-22 P031-00/ /	115-199
T00155 T		MS25171-1S NIPPLE	96906	2	29-11-22 P031-00/ /	ALL
T00156		314-14544-01 XFMR-L SYS HYD LEAK DET CURRENT	284N1315 95266	1	29-11-12 P032-00/ /	115-199
T00156 T		MS25171-1S NIPPLE	96906	2	29-11-12 P032-00/ /	ALL
T00157		314-14544-01 XFMR-C SYS HYD LEAK DET CURRENT	284N1314 95266	1	29-11-31 P031-00/ /	115-199
T00157 T		MS25171-1S NIPPLE	96906	2	29-11-31 P031-00/ /	ALL
T00189		60B40104-2 TRU-APU START	284N1565 94889	1	24-32-41 1467/156/R024	001-099
T00189		60B40104-2 TRU-APU START	284N1857 94889	1	24-32-41 1620/170/R043	115-199

EQUIPMENT LIST

D280N032

Section T00100

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T10002		60B40026-17 XFMR-AFT CARGO COMPT LIGHTS	284N1554 81205	1	33-37-21 E006-00/ /	001-099
T10002		60B40026-17 XFMR-AFT CARGO COMPT LIGHTS	284N1680 81205	1	33-37-21 E006-00/ /	115-199
T10003		60B40026-15 XFMR-CEILING LTS RIGHT	284N1316 81205	1	33-21-11 P034-00/ /	ALL
T10004		60B40026-15 XFMR-CEILING LTS LEFT	284N1316 81205	1	33-21-11 P034-00/ /	ALL
T10012		60B40026-17 XFMR-PASS READ LTS,L MID FWD	412N3410 81205	1	33-23-12 802/274/L054	ALL
T10013		60B40026-17 XFMR-PASS READ LTS,L MID AFT	412N3410 81205	1	33-23-13 1083/278/L057	ALL
T10014		60B40026-17 XFMR-PASS READ LTS,L AFT	412N3410 81205	1	33-23-14 1420/274/L054	ALL
T10016		60B40026-17 XFMR-PASS READ LTS,R MID FWD	412N3410 81205	1	33-23-22 803/275/R055	ALL
T10017		60B40026-17 XFMR-PASS READ LTS,R MID AFT	412N3410 81205	1	33-23-23 1083/278/R054	ALL
T10018		60B40026-17 XFMR-PASS READ LTS,R AFT	412N3410 81205	1	33-23-24 1380/274/R054	ALL
T10022		60B40026-15 XFMR-GALLEY & ENTRY LTS	284N1316 81205	1	33-22-11 P034-00/ /	ALL
T10031		60B40026-19 STAB-POS PWR XFMR,C	284N1125 81205	1	27-48-21 P036-00/ /	ALL
T10040		60B40026-16 XFMR-28V AC XFR BUS LEFT	287N4102 81205	1	24-51-15 P006-00/ /	ALL
T10041		60B40026-16 XFMR-28V AC XFR BUS RIGHT	287N4102 81205	1	24-51-25 P006-00/ /	ALL
T10043		FT1246 XFMR-POSITION LIGHTS,LEFT WING	284N1112 14752	1	33-43-11 WS807/ /LTIP	ALL
T10044		FT1246 XFMR-POSITION LIGHTS,RIGHT WING	284N1112 14752	1	33-43-11 WS807/ /RTIP	ALL
T10051		60B40026-17 XFMR-PASS READ LTS,L FWD	412N3410 81205	1	33-23-11 0470/274/L054	ALL

EQUIPMENT LIST

D280N032

Section T10000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T10052		60B40026-17 XFMR-PASS READ LTS,R FWD	412N3410 81205	1	33-23-21 530/275/R055	ALL
T10053		S271T451-1 TRANSMITTER-PRESSURE,HYDRAULIC	274N1118 81205	1	31-31-52 1042/173/L028	001-099
T10054		S271T451-1 TRANSMITTER-PRESSURE,HYDRAULIC	274N1118 81205	1	31-31-52 1042/181/R057	001-099
T10055		S271T451-1 TRANSMITTER-PRESSURE,HYDRAULIC	274N1117 81205	1	31-31-52 1074/177/L001	001-099
T10056		S271T451-1 TRANSMITTER-PRESSURE,HYDRAULIC	274N1117 81205	1	31-31-52 1079/168/R002	001-099
T10060		10-3257-5 TRU-HMG	284N1800 81205	1	24-25-12 E001-01/ /	003-099

EQUIPMENT LIST

D280N032

Section T10000

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0001	1	97437-121-01A-MATRIXP-N- TERMINAL BLOCK TRACK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0001	2	3600097-ROLLS-ROYCEP-N- TERMINAL BLOCK TRACK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0001N	1	12103B16E16-204-MATRIP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	001, 003-099, 115-199
TB0001N	2	2506685-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0001P	1	12103B16E15-204-MATRIXP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	001, 003-099, 115-199
TB0001P	2	2506678-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0001P	3	592852-1-AMPP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0001Q	1	MRFB16E11-204-MATRIXP-N- TERMINAL BLOCK-	RTS7067 14283	6	71-51-11 ENG/ /	001, 003-099, 115-199
TB0001Q	2	2506677-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	6	71-51-11 ENG/ /	ALL
TB0001R	1	MRFB16E12-204-MATRIXP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	001, 003-099, 115-199
TB0001R	2	2506681-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0001S	1	MRFB16E02-204-MATRIXP-N- TERMINAL BLOCK-	RTS7067 14283	4	71-51-11 ENG/ /	001, 003-099, 115-199
TB0001S	2	2506682-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	4	71-51-11 ENG/ /	ALL
TB0001T	1	MRFB16E04-204-MATRIXP-N- TERMINAL BLOCK-	RTS7067 14283	12	71-51-11 ENG/ /	001, 003-099, 115-199
TB0001T	2	2506680-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	12	71-51-11 ENG/ /	ALL
TB0001U	1	MRFB16E03-204-MATRIXP-N- TERMINAL BLOCK-	RTS7067 14283	4	71-51-11 ENG/ /	001, 003-099, 115-199
TB0001U	2	2506679-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	4	71-51-11 ENG/ /	ALL

EQUIPMENT LIST

D280N032

Section TB0000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0001V	1	12103B16E14-204-MATRIP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	001, 003-099, 115- 199
TB0001V	2	2506684-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0001W	1	12093B16E13-204MATRIP-N- TERMINAL BLOCK-	RTS7067 14283	8	71-51-11 ENG/ /	001, 003-099, 115- 199
TB0001W	2	2506683-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	8	71-51-11 ENG/ /	ALL
TB0002	1	12220BE01A-MATRIP-N- TERMINAL BLOCK TRACK-	RTS7067 14283	2	71-51-11 ENG/ /	001, 003-099, 115- 199
TB0002	2	2508409-ROLLS-ROYCEP-N- TERMINAL BLOCK TRACK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0002A	1	12220B16E09-MATRIP-N- TERMINAL BLOCK-	RTS7067 14283	4	71-51-11 ENG/ /	001, 003-099, 115- 199
TB0002A	2	2508410-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	4	71-51-11 ENG/ /	ALL
TB0002J	1	MRTB16E06-204-MATRIP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	001, 003-099, 115- 199
TB0002J	2	2508412-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0002L	1	MRTB16E03-204-MATRIP-N- TERMINAL BLOCK-	RTS7067 14283	4	71-51-11 ENG/ /	001, 003-099, 115- 199
TB0002L	2	2508411-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	4	71-51-11 ENG/ /	ALL
TB0002M	1	MRTB16E04-204-MATRIP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	001, 003-099, 115- 199
TB0002M	2	2508413-ROLLS-ROYCEP-N- TERMINAL BLOCK-	RTS7067 14283	2	71-51-11 ENG/ /	ALL
TB0005		MRTBL-7 TERMINAL BLOCK TRACK- 8 P0S.	344N5101 14283	1	28-41-11 P028-00/ /	001, 003-099, 115- 199
TB0005A		M81714-1-DB3 MODULAR TERMINAL BLOCK	35344	4	28-21-22 P028-00/ /	ALL
TB0005B		M81714-1-DA1 MODULAR TERMINAL BLOCK	35344	1	28-21-23 P028-00/ /	ALL

EQUIPMENT LIST

D280N032

Section TB0000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0005C		M81714-1-DB1 MODULAR TERMINAL BLOCK	35344	1	28-21-23 P028-00/ /	ALL
TB0005P		M81714-2-BC1 MODULAR TERMINAL BLOCK	35344	1	28-41-11 P28/ /	ALL
TB0012		TERMSTRIP TERMINAL STRIP-1	287N1406 96906	1	24-31-11 E001-01/ /	003-099
TB0013		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	33-13-12 P001-00/ /	001, 003-099, 115-199
TB0013X	9	BACM15C3A TERMINAL BLOCK (SB 34A0222)	280N3341 81205	1	34-12-62 AP0001/ /	ALL
TB0013X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-61 AP0001/ /	001-099
TB0013X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-61 P1/ /	115-199
TB0013Y		BACM15C3B TERMINAL BLOCK	81205	1	31-51-42 AP0001/ /	001-099
TB0013Y		BACM15C3B TERMINAL BLOCK	81205	1	31-51-42 P1/ /	115-199
TB0013Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-11 AP0001/ /	001-099
TB0013Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-11 P1/ /	115-199
TB0014		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	34-22-14 P001-00/ /	001, 003-099, 115-199
TB0014A	1	YHLZD-33 DIODE-AUTOBRAKE SWITCH SUPPRESSION	81205	1	32-42-12 P1-1/ /	ALL
TB0014A	2	YHLZD-29 DIODE-AUTOBRAKE SWITCH SUPPRESSION	81205	1	32-42-12 P1-1/ /	ALL
TB0014X		BACM15C3A TERMINAL BLOCK	81205	1	31-41-19 AP0001/ /	001-099
TB0014X		BACM15C3A TERMINAL BLOCK	81205	1	31-41-19 P1/ /	115-199
TB0014Y		BACM15C3B TERMINAL BLOCK	81205	1	31-51-42 AP0001/ /	001-099

EQUIPMENT LIST

D280N032

Section TB0000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0014Y		BACM15C3B TERMINAL BLOCK	81205	1	31-51-42 P1/ /	115-199
TB0014Z		BACM15C3C TERMINAL BLOCK	81205	1	31-51-42 AP0001/ /	ALL
TB0015		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	34-22-27 P003-00/ /	001, 003-099, 115-199
TB0015A		YHLZD-33 DIODE (R10012-R10017)	09922	6	32-61-12 AP0301/ /	001-099
TB0015A	1	YHLZD-33 BLOCK, DIODE(R10012-R10017)	09922	6	32-61-12 P3/ /	115-199
TB0015A	2	YHLZD-29 BLOCK, DIODE(R10012-R10017)	09922	6	32-61-12 P3/ /	115-199
TB0015X		BACM15C3A TERMINAL BLOCK	81205	1	33-13-41 P3 PNL/ /	001-099
TB0015X		BACM15C3A TERMINAL BLOCK	81205	1	33-13-41 P3/ /	115-199
TB0015Y		BACM15C3B TERMINAL BLOCK	81205	1	34-22-27 P3 PNL/ /	001-099
TB0015Y		BACM15C3B TERMINAL BLOCK	81205	1	34-22-27 P3/ /	115-199
TB0015Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-21 P3 PNL/ /	001-099
TB0015Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-21 P3/ /	115-199
TB0016		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	34-22-24 P003-00/ /	001, 003-099, 115-199
TB0016X		BACM15C3A TERMINAL BLOCK	81205	1	34-22-81 P3 PNL/ /	001-099
TB0016X		BACM15C3A TERMINAL BLOCK	81205	1	34-22-81 P3/ /	115-199
TB0016Y		BACM15C3B TERMINAL BLOCK	81205	1	34-22-91 P3 PNL/ /	001-099
TB0016Y		BACM15C3B TERMINAL BLOCK	81205	1	34-22-91 P3/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0000

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0016Z		BACM15C3C TERMINAL BLOCK	81205	1	34-22-81 P3 PNL/ /	001-099
TB0016Z		BACM15C3C TERMINAL BLOCK	81205	1	34-22-81 P3/ /	115-199
TB0024		BACT44A0700U TERMINAL BLOCK TRACK- 20 POS.	287N4102 09922	1	24-34-11 P006-01/ /	001, 003-099, 115-199
TB0024X		BACM15C3A HIGH DENSITY TERMINAL MODULE	81205	1	24-34-11 P006-00/ /	ALL
TB0024Y		BACM15C3B HIGH DENSITY TERMINAL MODULE	81205	3	24-34-11 P006-00/ /	001-099
TB0024Y		BACM15C3B HIGH DENSITY TERMINAL MODULE	81205	1	24-34-11 P006-00/ /	115-199
TB0024Z		BACM15C3C HIGH DENSITY TERMINAL MODULE	81205	1	24-51-72 P006-00/ /	ALL
TB0025		M81714-5-7 TERMINAL BLOCK TRACK- 8 POS.	284N1759 14283	1	26-15-12 P062-00/ /	001, 003-099
TB0025		M81714-5-10 TERMINAL BLOCK TRACK- 12 POS.	284N1759 14283	1	26-15-12 P062-00/ /	115-199
TB0025B	1	TJM112602 TERM. BLOCK	58982	1	33-42-11 P62-00/ /	ALL
TB0025B	2	M81714-4-DB1 TERM. BLOCK	14283	1	33-42-11 P62-00/ /	ALL
TB0025C		M81714-3-DC2 TERM. BLOCK	14283	1	33-42-21 P62/ /	ALL
TB0025K		M81714-3-DD1 TERM. BLOCK	14283	3	23-43-11 P62/ /	ALL
TB0025L		M81714-3-BB1 TERMINAL BLOCK	96906	1	26-15-12 P62/ /	115-199
TB0027		BACT44B0400U TERMINAL BLOCK TRACK- 10 POS.	286N1152 81205	1	27-51-51 P036-00/ /	001, 003-099, 115-199
TB0028		BACT44B0400U TERMINAL BLOCK TRACK- 10 POS.	286N1154 81205	1	21-58-11 P036-00/ /	001, 003-099, 115-199
TB0029		BACT44B0400U TERMINAL BLOCK TRACK- 10 POS.	286N1156 81205	1	21-58-12 P036-00/ /	001, 003-099, 115-199

EQUIPMENT LIST

D280N032

Section TB0000

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0031		BACT44B0450U TERMINAL BLOCK TRACK- 12 POS.	286N1162 81205	1	30-21-11 P037-00/ /	001, 003-099, 115-199
TB0032		BACT44B0450U TERMINAL BLOCK TRACK- 12 POS.	286N1164 81205	1	21-51-22 P037-00/ /	001, 003-099, 115-199
TB0033		BACT44B0450U TERMINAL BLOCK TRACK- 12 POS.	286N1166 81205	1	21-44-11 P037-00/ /	001, 003-099, 115-199
TB0036	1	AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1012 09922	1	28-25-21 E6 RACK/ /	001, 003-099, 115-199
TB0037		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1010 09922	1	49-61-11 E6 RACK/ /	001, 003-099, 115-199
TB0037B	1	YHLZD-33 DIODE TERMINAL BLOCK (R10138,R10295)	09922	2	24-31-41 E006-00/ /	001-099
TB0037B	1	YHLZD-33 DIODE TERMINAL BLOCK (R10138,R10295)	09922	2	24-31-41 E6/ /	115-199
TB0037B	2	YHLZD-29 DIODE TERMINAL BLOCK (R10138)	09922	1	24-31-41 E6/ /	115-199
TB0037C		YHLZD-33 DIODE TERMINAL BLOCK (R10077)	09922	1	49-61-11 E006-00/ /	001-099
TB0037C	1	YHLZD-33 DIODE TERMINAL BLOCK (R10077)	09922	1	49-61-11 E6/ /	115-199
TB0037C	2	YHLZD-30 DIODE TERMINAL BLOCK (R10077)	09922	1	49-61-11 E6/ /	115-199
TB0037G		BACM15C1B TERMINAL BLOCK-BURNDY "G"	09922	6	52-35-11 E006-00/ /	001-099
TB0037Y		BACM15C3B TERMINAL BLOCK - BURNDY "Y"	81205	9	49-61-11 E006-00/ /	001-099
TB0037Y		BACM15C3B TERMINAL BLOCK - BURNDY "Y"	81205	9	49-61-11 E6/ /	115-199
TB0037Z		BACM15C3C TERMINAL BLOCK - BURNDY "Z"	81205	3	21-51-13 E006-00/ /	001-099
TB0037Z		BACM15C3C TERMINAL BLOCK - BURNDY "Z"	81205	3	21-51-13 E6/ /	115-199
TB0045		M81714-5-1 TERMINAL BLOCK TRACK- 10 POS.	284N7175 96906	1	33-42-11 P063-00/ /	001, 003-099, 115-199

EQUIPMENT LIST

D280N032

Section TB0000

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0045A		M81714-3-DD1 TERM.BLOCK	14283	1	32-09-11 P063-00/ /	ALL
TB0045B	1	TJM112602 TERM. BLOCK	58982	1	33-42-21 P063-00/ /	001-099
TB0045B	1	TJM112601 TERM. BLOCK	58982	1	33-42-21 P063-00/ /	115-199
TB0045B	2	M81714-4-DB1 TERM. BLOCK	14283	1	33-42-21 P063-00/ /	001-099
TB0045B	2	M81714-3-DA1 TERM. BLOCK	14283	1	33-42-21 P063-00/ /	115-199
TB0045C		M81714-3-DA1 TERM. BLOCK	14283	1	33-42-11 P063-00/ /	001-099
TB0045C		M81714-4-DB1 TERM. BLOCK	14283	1	33-42-11 P063-00/ /	115-199
TB0045D		M81714-3-DB1 TERM. BLOCK	14283	1	33-42-21 P063-00/ /	ALL
TB0046		BACT44B0900U TERMINAL BLOCK TRACK- 27 POS. (PLATE A)	284N1318 81205	1	33-42-11 P033-00/ /	001, 003-099, 115-199
TB0046A		YHLZD-33 DIODE (R10240)	09902	1	29-22-11 P33/ /	001-099
TB0046A		YHLZD-33 DIODE (R10240)	81205	1	29-22-11 P33/ /	115-199
TB0046B	9	YHLZD-32 DIODE (R10608)	09922	1	28-22-11 P033-00/ /	ALL
TB0046G		BACM15C1B TERMINAL BLOCK	81205	2	28-22-11 P33/ /	ALL
TB0046H		BACM15C2A TERMINAL BLOCK	81205	1	28-21-21 P33/ /	001-099
TB0046Y		BACM15C3B TERMINAL BLOCK	81205	3	28-21-11 P33/ /	ALL
TB0046Z		BACM15C3C TERMINAL BLOCK	81205	1	28-21-11 P33/ /	115-199
TB0047		BACT44C0900U TERMINAL BLOCK TRACK- 27 POS.	286N1240 81205	1	33-22-11 P034-00/ /	001, 003-099, 115-199

EQUIPMENT LIST

D280N032

Section TB0000

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0047A		YHLZD-29 DIODE BLOCK	09922	1	33-42-12 P034-00/ /	001-099
TB0047A	1	YHLZD-33 DIODE BLOCK(R10222)	09922	1	33-42-12 P34/ /	115-199
TB0047A	2	YHLZD-29 DIODE BLOCK(R10222)	09922	1	33-42-12 P34/ /	115-199
TB0047F		BACM15C1A TERMINAL BLOCK	81205	4	33-21-11 P034-00/ /	001-099
TB0047F		BACM15C1A TERMINAL BLOCK	81205	6	33-21-11 P34/ /	115-199
TB0047G		BACM15C1B TERMINAL BLOCK	81205	1	33-21-31 P034-00/ /	001-099
TB0047G		BACM15C1B TERMINAL BLOCK	81205	1	33-21-31 P34/ /	115-199
TB0047X		BACM15C3A TERMINAL BLOCK	81205	1	33-21-31 P034-00/ /	001-099
TB0047X		BACM15C3A TERMINAL BLOCK	81205	2	33-21-31 P34/ /	115-199
TB0047Y		BACM15C3B TERMINAL BLOCK	81205	5	33-21-11 P034-00/ /	001-099
TB0047Y		BACM15C3B TERMINAL BLOCK	81205	5	33-21-11 P34/ /	115-199
TB0047Z		BACM15C3C TERMINAL BLOCK	81205	5	33-22-11 P034-00/ /	001-099
TB0047Z		BACM15C3C TERMINAL BLOCK	81205	3	33-22-11 P34/ /	115-199
TB0051		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1131 81205	0	34-22-17 E003-01/ /	001, 003-099, 115-199
TB0058		BACT44B0560U TERMINAL BLOCK TRACK- 15 POS.	287N4114 81205	1	33-13-52 253/207/R006	001, 003-099, 115-199
TB0058X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-51 253/207/R006	001-099
TB0058X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-51 253/207/R6	115-199

EQUIPMENT LIST

D280N032

Section TB0000

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0058Y		BACM15C3B TERMINAL BLOCK	81205	1	33-16-51 253/207/R006	001-099
TB0058Y		BACM15C3B TERMINAL BLOCK	81205	1	33-16-51 253/207/R6	115-199
TB0058Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-51 255/187/14	001-099
TB0058Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-51 253/207/R6	115-199
TB0059		BACT44B0560U TERMINAL BLOCK TRACK- 15 POS.	287N4114 81205	1	33-13-52 253/207/L006	001, 003-099, 115-199
TB0059X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-11 253/207/L006	001-099
TB0059X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-11 253/207/L6	115-199
TB0059Y		BACM15C3B TERMINAL BLOCK	81205	1	33-15-27 253/207/L006	001-099
TB0059Y		BACM15C3B TERMINAL BLOCK	81205	1	33-15-27 253/207/L6	115-199
TB0059Z		BACM15C3C TERMINAL BLOCK	81205	1	33-11-11 253/207/L006	001-099
TB0059Z		BACM15C3C TERMINAL BLOCK-	81205	1	33-13-51 253/207/L6	115-199
TB0061		YHLS-33 DIODE	286N2156 09922	1	23-51-11 272/280/L015	ALL
TB0064		AMY4100T-10 TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	0	33-16-11 ***/*	001, 003-099, 115-199
TB0064Y		BACM15C3B TERMINAL BLOCK	81205	3	34-46-11 P1-3/ /	ALL
TB0064Z		BACM15C3C TERMINAL BLOCK	81205	6	33-16-11 P1-3/ /	ALL
TB0065X		BACM15C3A TERMINAL BLOCK	81205	1	23-51-11 P10/ /	ALL
TB0065Y		BACM15C3B TERMINAL BLOCK	81205	1	27-41-11 P10/ /	ALL

EQUIPMENT LIST

D280N032

Section TB0000

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0069		285N0031-3 TERMINAL BLOCK TRACK-	285N0031 81205	1	26-11-11 P054-00/ /	001, 003-099, 115-199
TB0069Y	1	BACM15C3B TERMINAL BLOCK MODULE	81205	5	26-11-11 P54/ /	ALL
TB0069Z	1	BACM15C3C TERMINAL BLOCK MODULE	81205	5	26-11-11 P54/ /	ALL
TB0070		BACT44B0560U TERMINAL BLOCK TRACK- 15 POS.	286N0002	1	33-13-21 P003-01/ /	001, 003-099, 115-199
TB0070Z	1	BACM15C3C TERMINAL BLOCK	81205	2	33-13-21 P003-01/ /	ALL
TB0071		AMY4100-T-10U TERMINAL BLOCK TRACK- 133 POS.	233N2202	1	27-51-61 P003-01/ /	001, 003-099, 115-199
TB0071A		YHLZD-33 DIODE TERMINAL BLOCK (R10253)	81205	1	32-31-11 P003-01/ /	ALL
TB0071Y	1	BACM15C3B TERMINAL BLOCK	81205	2	33-16-41 P003-01/ /	ALL
TB0071Z	1	BACM15C3C TERMINAL BLOCK	81205	1	27-51-21 P003-01/ /	ALL
TB0072		BACT44B TERMINAL BLOCK TRACK-	285N0005 81205	1	31-51-21 P051-00/ /	001, 003-099, 115-199
TB0072Y	1	BACM15C3B BURNDY BLOCK	81205	1	27-32-11 P051-00/ /	115-199
TB0072Z	1	BACM15C3C TERMINAL BLOCK	81205	2	31-51-21 P051-00/ /	001-099
TB0072Z	1	BACM15C3C BURNDY BLOCK	81205	2	31-51-21 P051-00/ /	115-199
TB0079		BACM15C3B TERMINAL BLOCK TRACK-	286N1182 81205	1	27-51-51 ***/**/	001, 003-099, 115-199
TB0080		BACT44B0450U TERMNAL BLOCK TRACK- 13 POS.(PLATE D)	284N1318 81205	1	29-22-11 P033-00/ /	001, 003-099, 115-199
TB0080G	9	BACM15C1B TERMINAL BLOCK (MR69018-002)	81205	1	28-21-11 P33-00/ /	115-199
TB0080G		BACM15C1B TERMINAL BLOCK	81205	4	28-21-21 P33/ /	001-099

EQUIPMENT LIST

D280N032

Section TB0000

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0080H		BACM15C2A TERMINAL BLOCK	81205	1	28-21-21 P33/ /	001-099
TB0080Y		BACM15C3B TERMINAL BLOCK	81205	5	29-11-12 P33/ /	001-099
TB0080Y		BACM15C3B TERMINAL BLOCK	81205	4	29-11-12 P33/ /	115-199
TB0080Z		BACM15C3C TERMINAL BLOCK	81205	1	28-21-22 P33/ /	115-199
TB0081		BACT44B0450U TERMINAL BLOCK TRACK- 12 POS (PLATE C)	284N1318 81205	1	28-22-31 P033-00/ /	ALL
TB0081Y		BACM15C3B TERMINAL BLOCK	81205	2	28-22-31 P33/ /	ALL
TB0084		BACT44B0800U TERMINAL BLOCK TRACK- 24 POS.	284N1318 81205	1	27-81-41 P033-00/ /	001, 003-099, 115-199

EQUIPMENT LIST

D280N032

Section TB0000
Page 11 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0100F		BACM15C1A TERMINAL BLOCK	81205	1	73-21-11 222/196/R10	115-199
TB0100X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-51 222/196/R010	001-099
TB0100X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-51 222/196/R10	115-199
TB0100Y		BACM15C3B TERMINAL BLOCK	81205	1	33-16-41 222/196/R010	001-099
TB0100Y		BACM15C3B TERMINAL BLOCK	81205	1	33-16-41 222/196/R10	115-199
TB0100Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-52 222/196/R010	001-099
TB0100Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-52 222/196/R10	115-199
TB0101F		BACM15C1A TERMINAL BLOCK	81205	1	73-21-21 222/196/L010	115-199
TB0101X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-11 222/196/L010	001-099
TB0101X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-11 222/196/L10	115-199
TB0101Y		BACM15C3B TERMINAL BLOCK	81205	1	33-13-52 222/196/L010	001-099
TB0101Y		BACM15C3B TERMINAL BLOCK	81205	1	33-13-52 222/196/L10	115-199
TB0101Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-52 222/196/L010	001-099
TB0101Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-52 222/196/L10	115-199
TB0103		BACT44B0300U TERMINAL STRIP	284N1792 81205	1	24-25-11 P071-00/ /	001, 003-099, 115-199
TB0103Y		BACM15C3B TERMINAL BLOCK	81205	1	24-25-11 P71/ /	ALL
TB0106X	1	BACM15C3A TERMINAL MODULE	09922	1	30-41-11 E1-2/ /	ALL

EQUIPMENT LIST

D280N032

Section TB0100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0106Y	1	BACM15C3B TERMINAL MODULE	81205	1	30-41-11 E1-2/ /	ALL
TB0107X	1	BACM15C3A TERMINAL MODULE	09922	1	30-41-12 E001-01/ /	115-199
TB0108		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1165 81205	1	27-09-11 E004-01/ /	001, 003-099, 115-199
TB0108Y		BACM15C3B BURNDY BLOCK	81205	1	27-61-15 E004-01/ /	001-099
TB0108Y		BACM15C3B BURNDY BLOCK	81205	1	27-61-15 E4-1/ /	115-199
TB0108Z		BACM15C3C BURNDY BLOCK	81205	1	27-61-15 E004-01/ /	001-099
TB0108Z		BACM15C3C BURNDY BLOCK	81205	1	27-61-15 E4-1/ /	115-199
TB0109		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1265 81205	1	27-09-11 E003-01/ /	001, 003-099
TB0109A		YHLZD-33 DIODE(R10190,R10191)	09922	2	27-31-12 E003-01/ /	001-099
TB0109A	1	YHLZD-33 DIODE(R10190,R10191)	09922	2	27-31-12 E3-1/ /	115-199
TB0109A	2	YHLZD-29 DIODE(R10190,R10191)	09922	2	27-31-12 E3-1/ /	115-199
TB0109B		YHLZR-32 RESISTOR(R10352,R10353,R10360,R10361)	09922	4	31-31-62 E003-01/ /	001-099
TB0109Y		BACM15C3B BURNDY BLOCK	81205	1	27-61-13 E003-01/ /	ALL
TB0109Z		BACM15C3C BURNDY BLOCK	81205	1	27-61-13 E003-01/ /	ALL
TB0111		MS27212-12 TERMINAL BLOCK TRACK-24 POS.	287N4120 96906	1	33-13-32 272/280/14	ALL
TB0111A		YHLZD-33 DIODE (R00001-R00003,R10209)	09922	4	24-51-31 272/280/L014	001-099
TB0111A		YHLZD-33 DIODE (R00001-R00003,R10209)	09922	4	24-51-31 272/280/L14	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0111B		YHLZR-17 RESISTOR	09922	1	29-11-22 272/280/L014	001-099
TB0111B		YHLZR-17 RESISTOR	09922	1	29-11-22 272/280/L 14	115-199
TB0111X		BACM15C3A BLOCK	81205	1	23-11-11 272/280/L014	001-099
TB0111X		BACM15C3A BLOCK	81205	1	23-11-11 272/280/L14	115-199
TB0111Y		BACM15C3B TERMINAL BLOCK	81205	1	33-15-27 272/280/L014	001-099
TB0111Y		BACM15C3B TERMINAL BLOCK	81205	1	33-15-27 272/280/L 14	115-199
TB0111Z		BACM15C3C BLOCK	81205	1	30-32-11 272/280/L014	001-099
TB0111Z		BACM15C3C BLOCK	81205	1	30-32-11 272/280/L 14	115-199
TB0112		MS27212-12 TERMINAL BLOCK TRACK-24 POS.	287N4120 96906	1	33-16-11 272/280/R014	ALL
TB0112A		YHLZD-33 DIODE (R00193-R00202)	09922	8	26-11-11 272/280/R014	001-099
TB0112A		YHLZD-33 DIODE TERMINAL MODULE	09922	8	26-11-11 272/280/R14	115-199
TB0112X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-11 272/280/R014	001-099
TB0112X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-11 272/280/R14	115-199
TB0112Y		BACM15C3B TERMINAL BLOCK	81205	1	33-15-27 272/280/R014	001-099
TB0112Y		BACM15C3B TERMINAL BLOCK	81205	1	33-15-27 272/280/R14	115-199
TB0112Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 272/280/R014	001-099
TB0112Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 272/280/R14	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0113		MS27212-12 TERMINAL BLOCK TRACK-24 POS.	287N4120 96906	1	33-16-11 272/280/L015	ALL
TB0113A		YHLZD-33 DIODE (R58-R61,R217-R218,R10205)	09922	7	23-51-11 272/280/L015	001-099
TB0113A		YHLZD-33 DIODE (R58-R61,R217-R218,R10205)	09922	7	23-51-11 272/280/L015	115-199
TB0113B		YHLZR-17 RESISTOR	09922	1	29-11-12 272/280/L015	001-099
TB0113B		YHLZR-17 RESISTOR	09922	1	29-11-12 272/280/L15	115-199
TB0113X		BACM15C3A BLOCK	81205	1	31-51-11 272/280/L015	001-099
TB0113X		BACM15C3A 1	81205	3	31-51-11 272/280/L15	115-199
TB0113Y		BACM15C3B BLOCK	81205	1	33-16-11 272/280/L015	001-099
TB0113Y		BACM15C3B BLOCK	81205	1	33-16-11 272/280/L15	115-199
TB0113Z		BACM15C3C TERMINAL BLOCK	812053	1	33-16-13 272/280/L015	001-099
TB0113Z		BACM15C3C TERMINAL BLOCK	812053	1	33-16-13 272/280/L15	115-199
TB0114		MS27212-12 TERMINAL BLOCK TRACK-24 POS.	287N4120 96906	1	33-16-42 272/280/R015	ALL
TB0114F		BACM15C1A TERMINAL BLOCK	81205	2	73-21-21 272/280/R15	001-099
TB0114X		BACM15C3A TERMINAL BLOCK	81205	1	33-15-27 272/280/R015	001-099
TB0114X		BACM15C3A TERMINAL BLOCK	81205	1	33-15-27 272/280/R15	115-199
TB0114Y		BACM15C3B TERMINAL BLOCK	81205	1	33-13-71 272/280/R015	001-099
TB0114Y		BACM15C3B TERMINAL BLOCK	81205	1	33-13-71 272/280/R15	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0114Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 272/280/R015	001-099
TB0114Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 272/280/R15	115-199
TB0115		MS27212-12 TERMINAL BLOCK TRACK-24 POS.	287N4120 96906	1	33-16-52 272/280/L016	ALL
TB0115X		BACM15C3A BLOCK	81205	1	24-34-11 272/280/L016	001-099
TB0115X		BACM15C3A BLOCK		1	31-51-11 272/280/L16	115-199
TB0115X		BACM15C3A TERMINAL BLOCK		1	33-13-57 272/280/L16	115-199
TB0115Y		BACM15C3B TERMINAL BLOCK	81205	1	33-15-27 272/280/L016	001-099
TB0115Y		BACM15C3B TERMINAL BLOCK	81205	1	33-15-27 272/280/L16	115-199
TB0115Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 272/280/L016	001-099
TB0115Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 272/280/L16	115-199
TB0116		MS27212-12 TERMINAL BLOCK TRACK-24 POS.	287N4120 96906	1	33-16-52 272/280/R016	ALL
TB0116F		BACM15C1A TERMINAL BLOCK	81205	2	73-21-11 272/280/R016	001-099
TB0116X		BACM15C3A TERMINAL BLOCK	81205	1	33-15-27 272/280/R016	001-099
TB0116X		BACM15C3A TERMINAL BLOCK	81205	1	33-15-27 272/280/R16	115-199
TB0116Y		BACM15C3B BLOCK	81205	1	33-16-51 272/280/R015	001-099
TB0116Y		BACM15C3B BLOCK	81205	1	33-16-51 272/280/R16	115-199
TB0116Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 272/280/R016	001-099

EQUIPMENT LIST

D280N032

Section TB0100

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0116Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 272/280/R16	115-199
TB0121X		BACM15C3A TERMINAL BLOCK	81205	1	23-51-11 P061-00/ /	ALL
TB0121Y		BACM15C3B TERMINAL BLOCK	81205	2	25-65-11 P061-00/ /	001-099
TB0121Y		BACM15C3B BLOCK	81205	1	21-31-31 P061/ /	115-199
TB0121Z		BACM15C3C TERMINAL BLOCK	81205	1	33-15-27 P061-00/ /	ALL
TB0121Z		BACM15C3C TERMINAL BLOCK - DUMMY	286N2070 81205	1	33-15-27 P009-00/ /	002
TB0131		BACT44A0580D TERMINAL BLOCK TRACK- 16 POS (PLATE B)	284N1314 09922	1	24-22-12 P031-00/ /	115-199
TB0131A		YHLZD-33 DIODE (R4,R7,R10368)	09922	3	24-22-12 P031-00/ /	001-099
TB0131A		YHLZD-33 DIODE (R4,R7,R10368)	09922	3	24-22-12 P031-00/ /	115-199
TB0131B		YHLZR-27 RESISTOR (R10107)	81205	1	25-31-33 P031-00/ /	001-099
TB0131X		BACM15C3A HIGH DENSITY TERMINAL MODULE	81205	1	29-11-32 P031-00/ /	ALL
TB0131Y		BACM15C3B HIGH DENSITY TERMINAL MODULE	81205	4	24-22-12 P031-00/ /	ALL
TB0132		BACT44A0580D TERMINAL BLOCK TRACK-16 POS (PLATE B)	284N1315 09922	1	24-22-21 P032-00/ /	001, 003-099, 115-199
TB0132A		YHLZD-33 DIODE (R5,R8,R10369)	09922	3	24-22-21 P032-00/ /	001-099
TB0132A		YHLZD-33 DIODE (R5,R8,R30,R10369)	09922	4	24-22-21 P032-00/ /	115-199
TB0132B		YHLZR-22 RESISTOR (R10250)	81205	1	25-31-11 P032-00/ /	001-099
TB0132B		YHLZR-22 COMPONENT BLOCK RESISTOR (R10105)	09922	1	25-31-11 P032-00/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0132G		BACM15C1B HIGH DENSITY TERMINAL MODULE	81205	2	29-11-12 P032-00/ /	001-099
TB0132X		BACM15C3A HIGH DENSITY TERMINAL MODULE	81205	1	29-11-12 P032-00/ /	115-199
TB0132Y		BACM15C3B HIGH DENSITY TERMINAL MODULE	81205	4	24-22-22 P032-00/ /	ALL
TB0134		BACT44A0350D TERMINAL BLOCK TRACK- 16 POS.	284N1316 09922	1	24-22-41 P034-00/ /	001, 003-099, 115-199
TB0134A		YHLZD-33 DIODE (R6)	09922	1	24-22-41 P034-00/ /	001-099
TB0134A		YHLZD-33 DIODE (R00006)	09922	1	24-22-41 P034-00/ /	115-199
TB0134B		YHLZR-17 RESISTOR (R531)	09922	1	24-41-11 P034-00/ /	001-099
TB0134B		YHLZR-17 COMPONENT BLOCK RESISTOR(R531)	09922	1	24-41-11 P034-00/ /	115-199
TB0134Y		BACM15C3B HIGH DENSITY MODULE	81205	1	24-22-12 P034-00/ /	ALL
TB0135		M81714-5-8 TERMINAL BLOCK TRACK- 9 POS.	287N4106 96906	1	33-43-11 WBL740/ /	001, 003-099, 115-199
TB0136		M81714-5-8 TERMINAL BLOCK TRACK- 9 POS.	287N4106 96906	1	33-43-12 WBL740/ /	001, 003-099, 115-199
TB0137		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	22-41-12 E003-02/ /	001, 003-099, 115-199
TB0137Y	1	BACM15C3B TERMINAL BLOCK	81205	2	22-41-12 E003-02/ /	001-099
TB0137Y	1	BACM15C3B BURNDY BLOCK	81205	1	22-41-12 E3-2/ /	115-199
TB0141		BACM15C3 TERMINAL BLOCK TRACK-	287N1406 81205	0	23-51-11 E004-03/ /	001, 003-099, 115-199
TB0141A		YHLZD-33 BLOCK-DIODE (R00076)	09922	1	23-22-11 E004-03/ /	001-099
TB0141A		YHLZD-33 BLOCK-DIODE	09922	3	23-34-15 E4-3/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 7

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0141B		YHLZR-27 RESISTOR (R10233,R10234,R10236)	09922	3	23-51-11 E004-03/ /	001-099
TB0141B		YHLZR-27 RESISTOR (R10233,R10234)	09922	2	23-51-14 E004-03/ /	115-199
TB0141X		BACM15C3A TERMINAL BLOCK-	81205	1	23-22-12 E4-3/ /	001-099
TB0141Y		BACM15C3B TERMINAL BLOCK-	81205	1	23-51-11 E4-3/ /	ALL
TB0141Z		BACM15C3C TERMINAL BLOCK-	81205	1	23-51-11 E4-3/ /	ALL
TB0147A	1	YHLZD-33 DIODE	09922	2	21-51-15 P50/ /	ALL
TB0147Y		BACM15C3B BLOCK	81205	6	29-11-12 P50/ /	ALL
TB0147Z		BACM15C3C BLOCK	81205	2	36-11-11 P50/ /	ALL
TB0150		BACC TERMINAL BLOCK TRACK-	286N2019 81205	1	34-43-11 215/167/R010	115-199
TB0150F	1	BACM15C1A BURNDYBLOCK	81205	2	34-43-11 200/210/R015	115-199
TB0150X	1	BACM15C3A BURNDYBLOCK	81205	1	34-43-11 215/170/R015	001-099
TB0155		BACT44B0400U TERMINAL BLOCK TRACK- 10 POS (PLATE F)	284N1129 81205	1	21-43-11 P070-00/ /	001, 003-099, 115-199
TB0155X		BACM15C3A TERMINAL BLOCK	81205	1	21-43-11 P070-00/ /	ALL
TB0155Y		BACM15C3B TERMINAL BLOCK	81205	3	21-43-11 P070-00/ /	001-099
TB0155Y		BACM15C3B TERMINAL BLOCK	81205	2	21-43-11 P070-00/ /	115-199
TB0158		BACT44B0560U TERMINAL BLOCK TRACK- 15 POS.	287N4114 81205	1	28-22-21 253/207/R006	001, 003-099, 115-199
TB0158A		YHLZD-33 DIODE BLOCK	09922	5	26-15-11 250/205/R10	001-099

EQUIPMENT LIST

D280N032

Section TB0100

Page 8

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0158A	1	YHLZD-33 DIODE(R10130,1,4,5,7)	09922	5	26-15-11 253/207/R6	115-199
TB0158A	2	YHLZD-29 DIODE(R10130,1,4,5,7)	09922	5	26-15-11 253/207/R6	115-199
TB0158F		BACM15C1A TERMINALBLOCK	81205	1	33-13-51 250/205/R010	001-099
TB0158F		BACM15C1A TERMINAL BLOCK	81205	1	73-21-11 253/207/R6	115-199
TB0158X		BACM15C3A TERMINAL BLOCK	81205	1	27-21-11 250/205/R010	001-099
TB0158X		BACM15C3A TERMINAL BLOCK	81205	1	27-21-11 250/205/R10	115-199
TB0158Y		BACM15C3B TERMINAL BLOCK	81205	1	28-22-21 250/205/R010	ALL
TB0159		BACT44B0560U TERMINAL BLOCK TRACK- 15 POS.	287N2297 81205	1	33-13-52 253/207/L006	ALL
TB0159A		YHLZD-33 DIODE BLOCK (R10132,R10133,R10136)	09922	3	26-11-21 250/205/L010	001-099
TB0159A	1	YHLZD-33 DIODE (R10132,R10133,R10136)	09922	3	26-11-21 253/207/L006	115-199
TB0159A	2	YHLZD-29 DIODE (R10132,R10133,R10136)	09922	3	26-11-21 253/207/L6	115-199
TB0159F		BACM15C1A TERMINAL BLOCK	81205	1	33-13-52 253/207/L006	001-099
TB0159F		BACM15C1A TERMINAL BLOCK	81205	1	73-21-21 253/207/L6	115-199
TB0159X		BACM15C3A TERMINAL BLOCK	81205	1	73-21-21 253/207/L6	115-199
TB0159Z		BACM15CSC TERMINAL BLOCK	XXXXXXX 81205	1	23-51-11 253/207/L6	ALL
TB0160A		YHLZD-33 DIODE (R10126,127,204,306)	09922	4	21-58-12 P036-00/ /	001-099
TB0160A		YHLZD-33 DIODE (R10039-40,204,268,270,271,319)	09922	7	21-58-12 P36/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 9

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0160C	1	YHLZD-33 DIODE (R10126,R10127)	09922	2	30-31-11 P36/ /	115-199
TB0160C	2	YHLZD-29 DIODE (R10126,R10127)	09922	2	30-31-11 P36/ /	115-199
TB0160F		BACM15C1A TERMINAL BLOCK	81205	1	21-58-13 P36/ /	115-199
TB0160G		BACM15C1B TERMINAL BLOCK	81205	2	30-34-11 P36/ /	001-099
TB0160J		YHLZD-33 DIODE (R10239)	09922	1	21-58-24 P36/ /	115-199
TB0160X		BACM15C3A TERMINAL BLOCK	81205	1	21-58-24 P36/ /	115-199
TB0160Y		BACM15C3B TERMINAL BLOCK	81205	2	21-45-11 P36/ /	001-099
TB0160Y		BACM15C3B TERMINAL BLOCK	81205	5	21-45-11 P36/ /	115-199
TB0160Z		BACM15C3C TERMINAL BLOCK	81205	2	32-09-11 P36/ /	001-099
TB0160Z		BACM15C3C TERMINAL BLOCK	81205	5	32-09-11 P36/ /	115-199
TB0161A		YHLZD-33 DIODE (R10171-173,181,218,293,304-05)	09922	8	21-58-11 P036-00/ /	001-099
TB0161A		YHLZD-33 DIODE (22,93,6,109-10,71-3,81,218,35,93)	09922	12	21-58-11 P36/ /	115-199
TB0161C	9	YHLZD-33 DIODE (R10220,R10221,R10398)	09922	2	21-58-12 P36/ /	115-199
TB0161C		YHLZD-33 DIODE (R10398) (SB78-32)	81205	1	78-34-51 P36/ /	001-002
TB0161C		YHLZD-33 DIODE (R10398)	81205	1	78-34-51 P036-00/ /	003-099
TB0161C	1	YHLZD-33 DIODE (R10220,R10221)	09922	2	21-58-12 P36/ /	115-199
TB0161C	2	YHLZD-29 DIODE (R10220,R10221)	09922	2	21-58-12 P36/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 10

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0161G		BACM15C1B TERMINAL BLOCK	81205	1	78-34-51 P036-00/ /	003-099
TB0161G		BACM15C1B TERMINAL BLOCK	81205	2	30-34-21 P36/ /	115-199
TB0161J		YHLZD-33 DIODE	09922	1	21-58-13 P36/ /	115-199
TB0161X		BACM15C3A TERMINAL BLOCK	81205	1	21-58-13 P36/ /	ALL
TB0161Y		BACM15C3B TERMINAL BLOCK	81205	2	21-58-11 P036-00/ /	001-099
TB0161Y		BACM15C3B TERMINAL BLOCK	81205	5	21-58-11 P36/ /	115-199
TB0161Z		BACM15C3C TERMINAL BLOCK	81205	1	21-58-11 P036-00/ /	001-099
TB0161Z		BACM15C3C TERMINAL BLOCK	81205	2	21-58-11 P36/ /	115-199
TB0163A		YHLZD-33 DIODE (R10117,180)	09922	2	21-58-11 P036-00/ /	001-002
TB0163A		YHLZD-33 DIODE (R10180)	09922	1	21-58-11 P036-00/ /	003-099
TB0163A		YHLZD-33 DIODE (R10180,10227)	09922	2	21-58-12 P36/ /	115-199
TB0163B		YHLZD-33 DIODE (R00108,109,183,184)	09922	4	26-16-21 P036-00/ /	001-099
TB0163B	1	YHLZD-33 DIODE (R00108,R00109,R100183,R10184)	09925	4	26-16-21 P36/ /	115-199
TB0163B	2	YHLZD-30 DIODE (R00108,R00109,R100183,R10184)	09925	4	26-16-21 P36/ /	115-199
TB0163C	1	YHLZD-33 DIODE (R10204)	09922	1	21-58-14 P36/ /	115-199
TB0163C	2	YHLZD-29 DIODE (R10204)	09922	1	21-58-14 P36/ /	115-199
TB0163G		BACM15C1B TERMINAL BLOCK	81205	1	21-58-13 P36/ /	ALL

EQUIPMENT LIST

D280N032

Section TB0100

Page 11

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0163X		BACM15C3A TERMINAL BLOCK	81205	1	21-58-11 P36/ /	115-199
TB0163Y		BACM15C3B TERMINAL BLOCK	81205	1	73-21-32 P036-00/ /	001-099
TB0163Y		BACM15C3B TERMINAL BLOCK	81205	4	21-58-11 P36/ /	115-199
TB0163Z		BACM15C3C TERMINAL BLOCK	81205	2	21-58-11 P036-00/ /	001-099
TB0163Z		BACM15C3C TERMINAL BLOCK	81205	1	21-58-11 P36/ /	115-199
TB0164		BACT44B0400U TERMINAL BLOCK TRACK- 10 POS. (PLATE C)	284N1125 81205	1	21-58-12 P036-00/ /	ALL
TB0164A		YHLZD-33 DIODE (R10346,347,348)	81205	3	76-11-11 P36/ /	ALL
TB0165A	9	YHLZD-33 DIODE (R10023,117,223,367)(MR69018-002)	09922	4	21-25-11 P36/ /	115-199
TB0165A		YHLZD-33 DIODE (R10125,223,367)	09922	4	26-15-11 P036-00/ /	001-099
TB0165A		YHLZD-33 DIODE (R10023,117,223)	09922	3	21-25-11 P36/ /	115-199
TB0165B	9	YHLZD-40 DIODE (R10466) (SB 76-0014)	CUSTOMER 09922	1	76-11-11 P036-00/ /	ALL
TB0165C	1	YHLZD-33 DIODE (R10088,R10089,R10125)	09922	3	26-15-11 P36/ /	115-199
TB0165C	2	YHLZD-29 DIODE (R10088,R10089,R10125)	09922	3	26-15-11 P36/ /	115-199
TB0165G		BACM15C1B TERMINAL BLOCK	81205	1	75-31-11 P36/ /	ALL
TB0165Y		BACM15C3B TERMINAL BLOCK	81205	4	21-58-11 P036-00/ /	001-099
TB0165Y		BACM15C3B TERMINAL BLOCK	81205	6	21-58-11 P36/ /	115-199
TB0165Z		BACM15C3C TERMINAL BLOCK	81205	1	21-58-11 P036-00/ /	001-099

EQUIPMENT LIST

D280N032

Section TB0100

Page 12

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0165Z		BACM15C3C TERMINAL BLOCK	81205	2	21-58-11 P36/ /	115-199
TB0166		BACT44B1300U TERMINAL BLOCK TRACK- 32 POS.(PLATE D)	284N1125 81205	1	21-58-12 P036-00/ /	ALL
TB0166A		YHLZD-33 DIODE (R10044,88,99,168,174,221,230)	09922	7	80-11-11 P036-00/ /	001-099
TB0166A		YHLZD-33 DIODE (R10044,119,168,174,221,230)	09922	6	21-58-12 P36/ /	115-199
TB0166B		YHLZR-33 RESISTOR (R10558)	09922	1	27-62-11 P036-00/ /	010-099
TB0166C		YHLZD-30 DIODE (R10558)	09922	1	27-62-11 P036-00/ /	010-099
TB0166G		BACM15C1B TERMINAL BLOCK	81205	2	29-11-31 P36/ /	001-099
TB0166G		BACM15C1B TERMINAL BLOCK	81205	1	29-11-31 P36/ /	115-199
TB0166Y		BACM15C3B TERMINAL BLOCK	81205	3	27-51-51 P036-00/ /	001-099
TB0166Y		BACM15C3B TERMINAL BLOCK	81205	6	27-51-51 P36/ /	115-199
TB0166Z		BACM15C3C TERMINAL BLOCK	81205	3	80-11-11 P36/ /	ALL
TB0168A		YHLZD-33 DIODE (R10141,119,194-196)	09922	5	80-11-11 P036-00/ /	001-099
TB0168A	1	YHLZD-33 DIODE (R10119)	09922	1	80-11-11 P36/ /	115-199
TB0168A	2	YHLZD-15 DIODE (R10119)	09922	1	80-11-11 P36/ /	115-199
TB0168X		BACM15C3A TERMINAL BLOCK	81205	1	76-11-21 P036-00/ /	001-099
TB0168X		BACM15C3A TERMINAL BLOCK	81205	2	21-58-24 P36/ /	115-199
TB0168Y		BACM15C3B TERMINAL BLOCK	81205	2	21-58-11 P036-00/ /	001-099

EQUIPMENT LIST

D280N032

Section TB0100

Page 13

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0168Y		BACM15C3B TERMINAL BLOCK	81205	6	21-58-11 P36/ /	115-199
TB0168Z		BACM15C3C TERMINAL BLOCK	81205	1	21-58-11 P036-00/ /	001-099
TB0168Z		BACM15C3C TERMINAL BLOCK	81205	2	21-58-11 P36/ /	115-199
TB0170A	9	YHLZD-33 DIODE (SB 31-0034)	09922	1	31-31-21 P037-00/ /	115-199
TB0170A		YHLZD-33 DIODE (R10179,,224,226)	09922	3	21-58-12 P37/ /	001-099
TB0170A		YHLZD-33 DIODE (R10179,224,226)	09922	3	21-58-12 P37/ /	115-199
TB0170Y		BACM15C3B TERMINAL BLOCK	81205	4	21-58-12 P37/ /	ALL
TB0170Z		BACM15C3C TERMINAL BLOCK	81205	2	21-61-21 P37/ /	001-099
TB0170Z		BACM15C3C TERMINAL BLOCK	81205	1	21-61-21 P37/ /	115-199
TB0171A	1	YHLZD-33 DIODE (R10179)	09922	1	21-58-24 P37/ /	115-199
TB0171A	2	YHLZD-15 DIODE (R10179)	09922	1	21-58-24 P37/ /	115-199
TB0171C	1	YHLZD-33 DIODE (R10128)	09922	1	30-31-12 P37/ /	115-199
TB0171C	2	YHLZD-29 DIODE (R10128)	09922	1	30-31-12 P37/ /	115-199
TB0171Y		BACM15C3B TERMINAL BLOCK	81205	1	27-09-12 P37/ /	001-099
TB0171Y		BACM15C3B TERMINAL BLOCK	81205	2	27-09-12 P37/ /	115-199
TB0171Z		BACM15C3C TERMINAL BLOCK	81205	3	32-09-12 P37/ /	001-099
TB0171Z		BACM15C3C TERMINAL BLOCK	81205	4	32-09-12 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 14

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0172A		YHLZD-33 DIODE (R10074)	09922	1	21-58-12 P37/ /	ALL
TB0172G		BACM15C1B TERMINAL BLOCK	81205	4	35-21-11 P37/ /	ALL
TB0172X		BACM15C3A TERMINAL BLOCK	81205	1	73-21-42 P37/ /	001-099
TB0172Y		BACM15C3B TERMINAL BLOCK	81205	2	21-58-13 P37/ /	001-099
TB0172Y		BACM15C3B TERMINAL BLOCK	81205	3	21-58-13 P37/ /	115-199
TB0172Z		BACM15C3C TERMINAL BLOCK	81205	1	21-44-11 P37/ /	001-099
TB0172Z		BACM15C3C TERMINAL BLOCK	81205	2	21-44-11 P37/ /	115-199
TB0173A		YHLZD-33 DIODE (R10050,153,213)	09922	3	29-22-11 P37/ /	001-099
TB0173B		YHLZR-17 RESISTOR (R10214)	09922	1	27-62-11 P37/ /	ALL
TB0173C	1	YHLZD-33 DIODE (R10153,R10214)	09922	2	29-22-11 P37/ /	115-199
TB0173C	2	YHLZD-29 DIODE (R10153,R10214)	09922	2	29-22-11 P37/ /	115-199
TB0173F		BACM15C1A TERMINAL BLOCK	81205	1	21-44-11 P37/ /	115-199
TB0173X		BACM15C3A TERMINAL BLOCK	81205	1	21-44-11 P37/ /	ALL
TB0173Y		BACM15C3B TERMINAL BLOCK	81205	5	27-62-11 P37/ /	001-099
TB0173Y		BACM15C3B TERMINAL BLOCK	81205	1	27-62-11 P37/ /	115-199
TB0173Z		BACM15C3C TERMINAL BLOCK	81205	1	36-11-41 P37/ /	001-099
TB0173Z		BACM15C3C TERMINAL BLOCK	81205	1	36-11-31 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 15

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0174		BACT44B1000U TERMINAL BLOCK TRACK- 30 POS (PLATE C)	284N1127 81205	1	74-31-21 P037-00/ /	001, 003-099, 115-199
TB0174A		YHLZD-33 DIODE (R10120,140,349,350,351)	09922	5	78-36-21 P37/ /	001-099
TB0174A	1	YHLZD-33 DIODE (R10118,120,140,349,350,351)	09922	6	78-36-21 P37/ /	115-199
TB0174A	2	YHLZD-15 DIODE (R10118,120,140)	09922	3	78-36-21 P37/ /	115-199
TB0174B	9	YHLZD-40 DIODE (R10467) (SB 76-0014)	CUSTOMER 09922	1	76-11-12 P037-00/ /	ALL
TB0174C	1	YHLZD-33 DIODE (R10197-199)	09922	3	29-35-11 P37/ /	115-199
TB0174C	2	YHLZD-29 DIODE (R10197-199)	09922	3	29-35-11 P37/ /	115-199
TB0174G		BACM15C1B TERMINAL BLOCK	81205	1	75-31-11 P37/ /	001-099
TB0174G		BACM15C1B TERMINAL BLOCK	81205	2	75-31-11 P37/ /	115-199
TB0174X		BACM15C3A TERMINAL BLOCK	81205	1	73-21-42 P37/ /	001-099
TB0174Y		BACM15C3B TERMINAL BLOCK	81205	2	30-11-11 P37/ /	001-099
TB0174Y		BACM15C3B TERMINAL BLOCK	81205	5	30-11-11 P37/ /	115-199
TB0174Z		BACM15C3C TERMINAL BLOCK	81205	1	80-11-21 P37/ /	ALL
TB0177A	1	YHLZD-33 DIODE (R10169,170)	09922	2	21-44-11 P37/ /	115-199
TB0177A	2	YHLZD-15 DIODE (R10169,170)	09922	2	21-44-11 P37/ /	115-199
TB0177C	1	YHLZD-33 DIODE (R10224)	09922	1	21-58-12 P37/ /	115-199
TB0177C	2	YHLZD-29 DIODE (R10224)	09922	1	21-58-12 P37/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0100

Page 16

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0177F		BACM15C1A TERMINAL BLOCK	81205	2	21-58-24 P37/ /	ALL
TB0177G		BACM15C1B TERMINAL BLOCK	81205	1	30-34-12 P37/ /	001-099
TB0177X		BACM15C3A TERMINAL BLOCK	81205	1	21-58-24 P37/ /	ALL
TB0177Y		BACM15C3B TERMINAL BLOCK	81205	1	29-22-11 P37/ /	ALL
TB0177Z		BACM15C3C TERMINAL BLOCK	81205	2	21-44-11 P37/ /	115-199
TB0178		BACT44B1400U TERMINAL BLOCK TRACK- 43 POS.	284N1127 81205	1	21-58-13 P037-00/ /	ALL
TB0178A		YHLZD-33 DIODE(R10051,197-199,225)	09922	6	21-58-12 P37/ /	001-099
TB0178A		YHLZD-33 DIODE (R10225)	09922	1	21-58-12 P37/ /	115-199
TB0178C	1	YHLZD-33 DIODE (R10225,226)	09922	2	21-58-12 P37/ /	115-199
TB0178C	2	YHLZD-29 DIODE (R10225,226)	09922	2	21-58-12 P37/ /	115-199
TB0178D	9	YHLZD-32 DIODE (R10607)	09922	1	28-22-11 P037-00/ /	ALL
TB0178F		BACM15C1A TERMINAL BLOCK	81205	2	21-44-11 P37/ /	115-199
TB0178G		BACM15C1B TERMINAL BLOCK	81205	2	30-33-11 P37/ /	001-099
TB0178G		BACM15C1B TERMINAL BLOCK	81205	5	30-33-11 P37/ /	115-199
TB0178X		BACM15C3A TERMINAL BLOCK	81205	1	21-58-13 P37/ /	001-099
TB0178X		BACM15C3A TERMINAL BLOCK	81205	3	21-58-13 P37/ /	115-199
TB0178Y		BACM15C3B TERMINAL BLOCK	81205	7	21-45-11 P37/ /	ALL

EQUIPMENT LIST

D280N032

Section TB0100

Page 17

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0178Z		BACM15C3C TERMINAL BLOCK	81205	2	30-32-11 P37/ /	001-099
TB0178Z		BACM15C3C TERMINAL BLOCK	81205	3	30-32-11 P37/ /	115-199
TB0179		BACT44B0625U TERMINAL BLOCK TRACK-18 POS.(PLATE A)	284N1127 81205	1	21-61-11 P037-00/ /	001, 003-099, 115-199
TB0179A		YHLZD-33 DIODE (R10169,128,102,104,129,294)	09922	7	30-31-12 P37/ /	001-099
TB0179A		YHLZD-33 DIODE (R10294)	09922	1	21-61-21 P37/ /	115-199
TB0179C	1	YHLZD-33 DIODE (R10129)	09922	1	30-31-12 P37/ /	115-199
TB0179C	2	YHLZD-29 DIODE (R10129)	09922	1	30-31-12 P37/ /	115-199
TB0179D	1	YHLZD-33 DIODE (R10102-104)	09922	3	21-61-21 P37/ /	115-199
TB0179D	2	YHLZD-26 DIODE (R10102-104)	09922	3	21-61-21 P37/ /	115-199
TB0179Y		BACM15C3B TERMINAL BLOCK	81205	1	21-61-11 P37/ /	001-099
TB0179Y		BACM15C3B TERMINAL BLOCK	81205	3	21-61-11 P37/ /	115-199
TB0179Z		BACM15C3C TERMINAL BLOCK	81205	2	21-61-11 P37/ /	001-099
TB0179Z		BACM15C3C TERMINAL BLOCK	81205	1	21-61-11 P37/ /	115-199
TB0180		BACT44B0400U TERMINAL BLOCK TRACK- 11 POS.(PLATE A)	284N1127 81205	1	21-58-21 P037-00/ /	001, 003-099, 115-199
TB0180A	9	YHLZD-33 DIODE (R10399) (SB78-32)	81205	1	78-34-61 P037-00/ /	001-002
TB0180A	9	YHLZD-33 DIODE (R10399)	81205	1	78-34-61 P037-00/ /	115-199
TB0180A		YHLZD-33 DIODE (R10399) (SB78-32)	81205	1	78-34-61 P037-00/ /	001-002

EQUIPMENT LIST

D280N032

Section TB0100

Page 18

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0180A		YHLZD-33 DIODE (R10399)	81205	1	78-34-61 P37/ /	003-099
TB0180A		YHLZD-33 DIODE (R10399)	81205	1	78-34-61 P037-00/ /	115-199
TB0180F		BACM15C1A TERMINAL BLOCK	81205	1	21-58-21 P37/ /	115-199
TB0180G	9	BACM15C1B COMPONENT RLOCK	81205	1	78-34-61 P037-00/ /	115-199
TB0180G		BACM15C1B COMPONENT RLOCK	81205	1	78-34-61 P37/ /	003-099
TB0180G		BACM15C1B COMPONENT RLOCK	81205	1	78-34-61 P037-00/ /	115-199
TB0180X		BACM15C3A TERMINAL BLOCK	81205	1	21-58-24 P37/ /	115-199
TB0180Y		BACM15C3B TERMINAL BLOCK	81205	2	21-51-51 P37/ /	115-199
TB0180Z		BACM15C3C TERMINAL BLOCK	81205	1	21-51-23 P37/ /	001-099
TB0180Z		BACM15C3C TERMINAL BLOCK	81205	1	32-09-12 P37/ /	115-199
TB0181		AMY4100T-10U TERMINAL BLOCK TRACK-133 POS.	287N1406 09922	1	31-31-11 E003-03/ /	001, 003-099, 115-199
TB0181A		YHLZD-33 DIODE BLOCK	09922	1	31-31-42 E3-3/ /	001-099
TB0181A		YHLZD-33 BLOCK-DIODE	09922	1	34-53-11 E3-3/ /	115-199
TB0181B	1	YHLZR-10 RESISTOR(R10085)	09922	6	31-31-13 E3-3/ /	115-199
TB0181C	1	285N0094-12 MODULE (M10576,M10577,M10586,M10587)	81205	4	31-31-44 E003-03/ /	001-099
TB0181C	1	285N0094-12 MODULE (M10576,M10577,M10586,M10587)	81205	4	31-31-12 E003-03/ /	115-199
TB0181X	1	BACM15C3A BURNDY BLOCK	81205	1	31-31-01 E3-3/ /	001-099

EQUIPMENT LIST

D280N032

Section TB0100

Page 19

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0181X	1	BACM15C3A BURNDY BLOCK	81205	1	31-31-11 E3-3/ /	115-199
TB0181Y	1	BACM15C3B BURNDY BLOCK	81205	2	31-31-01 E3-3/ /	001-099
TB0181Y	1	BACM15C3B BURNDY BLOCK	81205	2	31-31-11 E3-3/ /	115-199
TB0181Z	1	BACM15C3C BURNDY BLOCK	81205	3	31-31-44 E3-3/ /	001-099
TB0181Z	1	BACM15C3C BURNDY BLOCK	81205	3	31-31-11 E3-3/ /	115-199
TB0182		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	32-61-11 E003-04/ /	001, 003-099, 115-199
TB0182A	1	YHLZD-33 R10263	09922	1	75-31-11 E003-04/ /	001-099
TB0182A	1	YHLZD-33 R10215,R10263	09922	2	52-71-21 E003-04/ /	115-199
TB0182A	2	YHLZD-15 DIODE MODULE	09922	1	52-71-21 E003-04/ /	115-199
TB0182C		YHLZD-33 DIODE (R10354,R10355)	09922	2	32-61-11 E003-04/ /	ALL
TB0182X	1	BACM15C3A TERMINAL BLOCK	81205	1	73-21-31 E003-04/ /	001-099
TB0182Y	1	BACM15C3B TERMINAL MODULE	81205	16	32-09-11 E003-04/ /	ALL
TB0182Z	1	BACM15C3C TERMINAL MODULE	81205	1	32-12-11 E003-04/ /	ALL
TB0183		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	21-31-21 E005-01/ /	001, 003-099, 115-199
TB0183X		BACM15C3A TERMINAL BLOCK -BURNDY "X"	81205	8	73-21-31 E5-1/ /	001-099
TB0183Y		BACM15C3B TERMINAL BLOCK - BURNDY "Y"	81205	10	21-31-21 E5-1/ /	ALL
TB0183Z		BACM15C3C TERMINAL BLOCK - BURNDY "Z"	81205	2	21-31-21 E5-1/ /	ALL

EQUIPMENT LIST

D280N032

Section TB0100

Page 20

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0184		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	21-31-21 E005-02/ /	001, 003-099, 115-199
TB0184X		BACM15C3A TERMINAL BLOCK-BURNDY "X"	81205	8	73-21-41 E5-2/ /	001-099
TB0184X		BACM15C3A TERMINAL BLOCK-BURNDY "X"	81205	1	27-58-31 AE0502/ /	115-199
TB0184Y		BACM15C3B TERMINAL BLOCK - BURNDY "Y"	81205	9	21-31-21 E5-2/ /	001-099
TB0184Y		BACM15C3B TERMINAL BLOCK - BURNDY "Y"	81205	8	21-31-21 AE0502/ /	115-199
TB0184Z		BACM15C3C TERMINAL BLOCK - BURNDY "Z"	81205	2	31-41-22 E5-2/ /	001-099
TB0184Z		BACM15C3C TERMINAL BLOCK - BURNDY "Z"	81205	2	31-41-22 AE0502/ /	115-199
TB0185		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	24-28-21 E005-03/ /	001, 003-099, 115-199
TB0185Y		BACM15C3B TERMINAL BLOCK - BURNDY "Y"	81205	3	24-28-21 E005-03/ /	001-099
TB0185Y		BACM15C3B TERMINAL BLOCK - BURNDY "Y"	81205	3	24-28-21 E5-3/ /	115-199
TB0185Z		BACM15C3C TERMINAL MODULE	81205	1	31-31-12 E5-3/ /	115-199
TB0187	9	S280W555-506 TB TRACK W/INT GND-24 POS (SB 34-0200)	824N1065 81205	1	34-46-14 P065-00/ /	002
TB0187Y	9	S280W555-506 TB TRACK W/INT GND-24 POS (757-34-0200)	81205	1	34-46-14 P065-00/ /	002
TB0187Z	9	S280W555-506 TB TRACK W/INT GND-24 POS (757-34-0200)	81205	1	34-46-14 P065-00/ /	002
TB0188		BACT44B0800U TERMINAL BLOCK TRACK- 32 POS.	284N1747 81205	1	52-34-11 P065-00/ /	001, 003-099, 115-199
TB0188Y		BACM15C3B BURNDY BLOCK-	81205	1	25-51-11 P65/ /	ALL
TB0188Z		S280W555-108 TERMINAL BLOCK	81205	1	34-46-14 P065-00/ /	002

EQUIPMENT LIST

D280N032

Section TB0100

Page 21

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0190		BACT44A0500U TERMINAL BLOCK TRACK- 14 POS.	286N0151 81205	1	34-22-16 P010-00/ /	001, 003-099, 115-199
TB0190X		BACM15C3A TERMINAL BLOCK	81205	1	33-16-51 P010-00/ /	ALL
TB0190Y		BACM15C3B TERMINAL BLOCK	81205	1	33-16-51 P010-00/ /	ALL
TB0190Z		BACM15C3C TERMINAL BLOCK	81205	1	33-16-51 P010-00/ /	ALL
TB0191		BACM15C3A TERMINAL BLOCK TRACK-	280N0151 81205	0	34-22-26 / /	001, 003-099, 115-199
TB0192		BACT44A0400U TERMINAL BLOCK TRACK- 10 POS.	286N0151 81205	1	33-13-52 P010-00/ /	001, 003-099, 115-199
TB0192Y		BACM15C3B TERMINAL BLOCK	81205	2	33-13-52 P010-00/ /	ALL
TB0192Z		BACM15C3C TERMINAL BLOCK	81205	1	33-13-52 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section TB0100

Page 22 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0200		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1020 09922	1	32-00-00 E006-02/ /	001, 003-099
TB0200A		YHLZD-33 DIODE TERMINAL BLOCK (R10076)	09922	1	24-27-41 E6-2/ /	001-099
TB0200Y		BACM15C3B TERMINAL MODULE - BURNDY "Y"	81205	5	32-00-00 E6-2/ /	001-099
TB0201		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1171 81205	0	34-22-14 E002-01/ /	001, 003-099
TB0201A		285N0096-1 MODULE (M10574, M10575)	81205	2	73-21-12 E002-02/ /	ALL
TB0201B	9	HLZD-33 DIODE (R10340) (34-0414)	09922	2	34-61-15 E002-001/ /	115-199
TB0201B		YHLZD-33 DIODE(R10262)	09922	1	75-31-11 E002-01/ /	001-099
TB0201B		YHLZD-33 DIODE(R10262)	09922	1	75-31-11 E2-1/ /	115-199
TB0201D	9	YHLZD-33 DIODE(R10341) 34-0414	09922	1	34-61-16 E002-001/ /	115-199
TB0201E	9	YHLZD-33 DIODE(R10342) (34-0414)	09922	1	34-61-16 E002-001/ /	115-199
TB0201F	9	BACM15C3B BLOCK-DIODE (R10584) (SB 34A0222)	280N3341 81205	1	34-12-61 E002-01/ /	ALL
TB0201X		BACM15C3A TERMINAL BLOCK	81205	1	22-11-13 E002-01/ /	009-099
TB0201Y		BACM15C3B TERMINAL BLOCK	81205	1	34-22-18 E002-01/ /	001-099
TB0201Y		BACM15C3B BURNDY MODULE	81205	1	34-22-18 E2-1/ /	115-199
TB0201Z		BACM15C3C TERMINAL BLOCK	81205	1	34-22-18 E002-01/ /	001-099
TB0201Z		BACM15C3C BURNDY MODULE	81205	1	34-22-18 E2-1/ /	115-199
TB0202Y		BACM15C3B TERMINAL BLOCK	81205	1	34-43-11 E002-01/ /	001-099

EQUIPMENT LIST

D280N032

Section TB0200

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0202Y		BACM15C3B BURNDY MODULE	81205	1	34-43-11 E2-2/ /	115-199
TB0203A		285N0096-1 MODULE (M10578,M10579)	81205	2	73-21-12 E002-02/ /	001-099
TB0203A		285N0096-1 MODULE (M10578, M10579)	81205	2	73-21-12 E002-02/ /	115-199
TB0203L	9	BACM15C3B BLOCK-DIODE (R10585) (SB 34A0222)	280N3341 81205	1	34-12-62 E002-02/ /	ALL
TB0203X		BACM15C3A TERMINAL BLOCK	81205	1	22-11-23 E002-02/ /	009-099
TB0203Y		BACM15C3B TERMINAL BLOCK	81205	1	34-31-21 E2-2/ /	001-099
TB0203Y		BACM15C3B BURNDYBLOCK	81205	1	34-31-21 E2-2/ /	115-199
TB0203Z		BACM15C3C TERMINAL BLOCK	81205	1	34-13-11 E002-02/ /	001-099
TB0203Z		BACM15C3C BURNDYBLOCK	81205	1	34-13-11 E2-2/ /	115-199
TB0204Y		BACM15C3B TERMINAL BLOCK	81205	1	34-43-11 E002-02/ /	001-099
TB0204Y		BACM15C3B BURNDYBLOCK	81205	1	34-43-11 E2-2/ /	115-199
TB0205		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1175 81205	0	34-22-34 E002-03/ /	001, 003-099
TB0205A	9	YHLZD-33 DIOD (R10478) (S/B 757-34-0200)	81205	2	34-43-14 E002-03/ /	002
TB0205X		BACM15C3A TERMINAL BLOCK	81205	1	22-32-12 E2-3/ /	001-099
TB0205X	1	BACM15C3A BURNDY BLOCK	81205	1	22-32-12 E2-3/ /	115-199
TB0205Y		BACM15C3B TERMINAL BLOCK	81205	1	34-22-36 E2-3/ /	001-099
TB0205Y		BACM15C3B BURNDY MODULE	81205	1	34-22-36 E2-3/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0200

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0205Z		BACM15C3C TERMINAL BLOCK	81205	1	34-22-36 E2-3/ /	001-099
TB0205Z		BACM15C3C BURNDY MODULE	81205	1	34-22-36 E2-3/ /	115-199
TB0206A		YHLZR-16 BURNDY MODULE	81205	4	34-43-11 E002-03/ /	001-099
TB0206A		YHLZR-16 BURNDY MODULE	09922	2	34-43-11 E2-3/ /	115-199
TB0207		AMY4100T-10U TERMINAL BLOCK TRACK- 124 POS.	287N1406 09922	1	31-41-11 E004-02/ /	001, 003-099, 115-199
TB0207A		YHLZD-33 DIODE (R10144)	09922	1	26-11-11 E4-2/ /	001-099
TB0207A	1	YHLZD-33 DIODE (R10144)	09922	1	26-11-11 E4-2/ /	115-199
TB0207A	2	YHLZD-29 DIODE (R10144)	09922	1	26-11-11 E4-2/ /	115-199
TB0207B		YHLZR-30 RESISTOR (R10111,R10112)	81205	2	24-11-11 E4-2/ /	001-099
TB0207B		YHLZR-30 BURNDY BLOCK (RESISTOR)	81205	2	24-11-11 E4-2/ /	115-199
TB0207C		YHLZR-29 RESISTOR (R10142,R10143)	09922	2	49-71-11 E4-2/ /	001-099
TB0207C		YHLZR-29 BURNDY RESISTOR BLOCK	09922	2	49-71-11 E4-2/ /	115-199
TB0207D		285N0094-12 MODULE (M10580,M10581,M10582,M10583)	81205	4	73-21-31 E004-02/ /	001-099
TB0207D		285N0094-12 MODULE(M10580,M10581,M10582,M10583)	81205	4	77-11-11 E004-02/ /	115-199
TB0207E		285N0089-8 MODULE(M10584,M10585)	81205	2	77-12-11 E004-02/ /	001-099
TB0207E		285N0089-8 TERMINAL MODULE,N1 IND.	81205	2	77-41-11 E004-02/ /	115-199
TB0207G		BACM15C1B TERMINAL BLOCK	81205	1	73-21-12 E4-2/ /	001-099

EQUIPMENT LIST

D280N032

Section TB0200

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0207G	1	BACM15C1B BURNDY BLOCK	81205	1	73-21-12 E4-2/ /	115-199
TB0207X		BACM15C3A TERMINAL BLOCK-	81205	1	73-21-31 E4-2/ /	001-099
TB0207X	1	BACM15C3A BURNDY BLOCK	81205	0	77-11-11 E4-2/ /	115-199
TB0207Y		BACM15C3B TERMINAL BLOCK	81205	1	77-11-11 E4-2/ /	001-099
TB0207Y		BACM15C3B BURNDY BLOCK	81205	100	77-11-11 E4-2/ /	115-199
TB0207Z	1	BACM15C3C TERMINAL BLOCK	81205	1	77-11-11 E4-2/ /	001-099
TB0207Z	1	BACM15C3C BURNDY BLOCK	81205	0	77-11-11 E4-2/ /	115-199
TB0208		BACT44B0250U TERMINAL BLOCK TRACK- 5 POS.	283N4303 09922	1	33-25-11 690/ /	115-199
TB0208A	1	YHLZD-33 DIODE (R10123,R10124)	09922	2	33-25-12 700/305/L015	115-199
TB0208A	2	YHLZD-15 DIODE (R10123,R10124)	09922	2	33-25-12 700/305/L15	115-199
TB0209		M81714-5-7 TERMINAL BLOCK TRACK- 8 POS.	286N3010 14823	1	32-42-11 L/MLG/ /	001, 003-099
TB0209		M81714-5-3 TERMINAL BLOCK TRACK- 4 POS.	286N3010 14823	1	32-42-11 L/MLG/ /	115-199
TB0209K		M81714-3-BD1 TERMINAL BLOCK-	14283	2	32-42-11 J-BOX/FWD/L/H	001-099
TB0209K		M81714-3-BD1 TERMINAL BLOCK-	286N3004 14283	1	32-42-14 J-BOX/FWD/L/H	002
TB0209K		M81714-3-BD1 TERMINAL BLOCK-	14283	3	32-42-11 J-BOX/FWD/L/H	115-199
TB0209L		M81714-3-BB1 TERMINAL BLOCK	14283	1	32-46-11 J-BOX/FWD/L/H	ALL
TB0210		M81714-5-7 TERMINAL BLOCK TRACK- 8 POS.	286N3012 14823	1	32-42-11 L/MLG/ /	001, 003-099

EQUIPMENT LIST

D280N032

Section TB0200

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0210		M81714-5-3 TERMINAL BLOCK TRACK- 4 POS.	286N3012 14823	1	32-42-11 L/MLG/ /	115-199
TB0210K		M81714-3-BD1 TERMINAL BLOCK	14283	1	32-46-11 J-BOX/AFT/L/H	ALL
TB0210K		M81714-3-BD1 TERMINAL BLOCK-	286N3012 14283	1	32-42-14 J-BOX/AFT/L/H	002
TB0210L		M81714-3-BB1 TERMINAL BLOCK-	14283	1	32-46-11 J-BOX/AFT/L/H	ALL
TB0211		M81714-5-7 TERMINAL BLOCK TRACK- 8 POS.	286N4910 14823	1	32-42-11 R/MLG/ /	001, 003-099
TB0211		M81714-5-3 TERMINAL BLOCK TRACK- 4 POS.	286N4910 14823	1	32-42-11 R/MLG/ /	115-199
TB0211K		M81714-3-BD1 TERMINAL BLOCK-	14283	1	32-09-11 J-BOX/FWD/R/H	ALL
TB0211K		M81714-3-BD1 TERMINAL BLOCK-	286N4904 14283	1	32-42-14 J-BOX/FWD/R/H	002
TB0211L		M81714-3-BB1 TERMINAL BLOCK	14283	1	32-42-11 J-BOX/FWD/R/H	ALL
TB0212		M81714-5-7 TERMINAL BLOCK TRACK- 8 POS.	286N4912 14823	1	32-42-11 R/MLG/ /	001, 003-099
TB0212		M81714-5-3 TERMINAL BLOCK TRACK- 4 POS.	286N4912 14823	1	32-42-11 R/MLG/ /	115-199
TB0212K		M81714-3-BD1 TERMINAL BLOCK	14283	2	32-09-12 J-BOX/AFT/R/H	001-099
TB0212K		M81714-3-BD1 TERMINAL BLOCK-	286N4902 14283	1	32-42-14 J-BOX/AFT/R/H	002
TB0212K		M81714-3-BD1 TERMINAL BLOCK	14283	3	32-09-12 J-BOX/AFT/R/H	115-199
TB0212L		M81714-3-BB1 TERMINAL BLOCK-	286N4924 14283	1	32-46-11 J-BOX/AFT/R/H	001, 003-099, 115-199
TB0212L		M81714-3-BB1 TERMINAL BLOCK-	14283	1	32-42-11 J-BOX/AFT/R/H	ALL
TB0221		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	287N1406 09922	1	34-21-11 E002-04/ /	001, 003-099, 115-199

EQUIPMENT LIST

D280N032

Section TB0200

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0221Y	1	BACM15C3B TERMINAL BLOCK	81205	1	34-21-11 E002-04/ /	001-099
TB0221Y	1	BACM15C3B BURNDY BLOCK	81205	5	34-21-11 E2-4/ /	115-199
TB0221Z	1	BACM15C3C TERMINAL BLOCK	81205	1	34-21-11 E002-04/ /	001-099
TB0221Z	1	BACM15C3C BURNDY BLOCK	81205	5	34-21-11 E2-4/ /	115-199
TB0225		M81714-5-7 TERMINAL BLOCK TRACK- 8 POS.	284N1759 14283	1	26-15-12 P062-00/ /	001, 003-099
TB0225A	1	TJM112603 TERM. BLOCK	58982	1	33-42-31 P62-00/ /	001-099
TB0225A	2	M81714-4-DB2 TERM. BLOCK	96906	1	33-42-31 P62-00/ /	001-099
TB0225C		M81714-3-BC2 TERMINAL BLOCK	14283	2	26-15-12 P062-00/ /	001-099
TB0225K		M81714-3-BD1 TERMINAL BLOCK	14283	1	26-15-12 P062-00/ /	001-099

EQUIPMENT LIST

D280N032

Section TB0200
Page 6 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0300		AMY4100T-10U TERMINAL BLOCK TRACK- 133 POS.	286N1032 09922	1	32-00-00 E006-04/ /	115-199
TB0300A	1	YHLZD-33 DIODE TERMINAL BLOCK (R10076)	09922	1	24-27-41 E6-4/ /	115-199
TB0300A	2	YHLZD-29 DIODE TERMINAL BLOCK (R10076)	09922	1	24-27-41 E6-4/ /	115-199
TB0300Y		BACM15C3B TERMINAL MODULE - BURNDY "Y"	81205	1	32-00-00 E6-4/ /	115-199
TB0300Z		BACM15C3C TERMINAL MODULE - BURNDY "Z"	09922	1	32-00-00 E6-4/ /	115-199
TB0360A		YHLZD-38 DIODE (R10266,R10267)	09922	2	32-35-11 P36/ /	ALL
TB0360B		YHLZD-33 DIODE (R10393)	09922	1	32-09-11 P036-00/ /	003-099
TB0360X		BACM15C3A TERMINAL BLOCK	81205	2	73-21-32 P036-00/ /	001-099
TB0360X		BACM15C3A TERMINAL BLOCK	81205	1	21-58-12 P36/ /	115-199
TB0360Y		BACM15C3B TERMINAL BLOCK	81205	5	21-58-12 P36/ /	115-199
TB0361Z		BACM15C3C TERMINAL BLOCK	81205	2	21-58-12 P36/ /	115-199
TB0362C	1	YHLZD-33 DIODE(R10194-196,218,219,223)	09922	6	29-33-11 P36/ /	115-199
TB0362C	2	YHLZD-29 DIODE(R10194-196,218,219,223)	09922	6	29-33-11 P36/ /	115-199
TB0362J		YHLZD-33 DIODE	09922	3	21-58-12 P36/ /	115-199

EQUIPMENT LIST

D280N032

Section TB0300

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5001		MS27212-2-12 TERMINAL STRIP-	233N3101 96906	1	24-51-21 275/270/L015	ALL
TB5002		MS27212-2-12 TERMINAL STRIP-	233N3101 96906	1	24-51-21 275/270/R015	ALL
TB5003		MS27212-2-12 TERMINAL STRIP-	287N1046 96906	0	24-51-13 275/270/L015	ALL
TB5004		MS27212-2-12 TERMINAL STRIP-	233N3101 96906	1	24-51-21 275/270/R015	ALL
TB5005		MS27212-2-12 TERMINAL STRIP-	233N3101 96906	1	24-54-73 272/250/L010	ALL
TB5006		MS27212-2-12 TERMINAL STRIP-	233N3101 96906	1	24-51-31 272/250/R010	ALL
TB5007		MS27212-3-1 TERMINAL STRIP-	287N4102 96906	1	24-32-11 P006-01/ /	001, 003-099, 115-199
TB5008		MS27212-3-1 TERMINAL STRIP-	287N4102 96906	1	24-32-11 P006-01/ /	001, 003-099, 115-199
TB5009		MS27212-3-1 TERMINAL STRIP-	287N4102 96906	1	24-31-11 P006-02/ /	001, 003-099, 115-199
TB5010		MS27212-3-1 TERMINAL STRIP-	287N4102 96906	1	24-31-11 P006-02/ /	001, 003-099, 115-199
TB5011		MS27212-2-10 TERMINAL STRIP-	287N4102 96906	1	24-54-11 P006-00/ /	ALL
TB5012		MS27212-3-3 TERMINAL STRIP-	287N4102 96906	1	24-51-11 P006-03/ /	ALL
TB5013		MS27212-2-8 TERMINAL STRIP-	287N4102 96906	1	24-51-13 P006-03/ /	ALL
TB5014		MS27212-3-3 TERMINAL STRIP-	287N4102 96906	1	24-51-21 P006-04/ /	ALL
TB5015		MS27212-2-3 TERMINAL STRIP-	287N4102 96906	1	24-51-52 P006-04/ /	ALL
TB5016		MS27212-2-6 TERMINAL STRIP-	287N4102 96906	1	24-54-21 P006-04/ /	ALL
TB5017		MS27212-5-1 TERMINAL STRIP-	287N4102 96906	1	24-33-12 P006-02/ /	001, 003-099, 115-199

EQUIPMENT LIST

D280N032

Section TB5000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5019		MS27212-2-12 TERMINAL STRIP-	287N4102 96906	1	24-51-72 P006-03/ /	ALL
TB5021		MS27212-6-2 TERMINAL STRIP-	287N4149 96906	1	33-14-31 288/253/L045	ALL
TB5025		MS27212-2-10 TERMINAL STRIP-	287N4102 96906	1	24-51-25 P006-00/ /	ALL
TB5028		MS27212-2-7 TERMINAL STRIP-	287N4132 96906	0	30-41-11 225/225/L037	ALL
TB5029		MS27212-1-7 TERMINAL STRIP-	287NTBD 96906	0	30-41-12 APR235/ /	001, 003-099, 115-199
TB5030		MS27212-1-7 TERMINAL STRIP-	287N4132 96906	0	30-41-12 250/215/L047	ALL
TB5031		MS27212-2-15 TERMINAL STRIP- (PLATE B)	284N1314 96906	1	24-51-11 P031-00/ /	ALL
TB5032		MS27212-2-15 TERMINAL STRIP- (PLATE B)	284N1315 96906	1	24-21-21 P032-00/ /	ALL
TB5034		MS27212-2-4 TERMINAL STRIP- (PLATE D)	284N1316 96906	1	24-53-51 P034-00/ /	001, 003-099, 115-199
TB5038		MS27212-2-7 TERMINAL STRIP-	287N4132 96906	0	30-41-12 223/230/R040	ALL
TB5039		MS27212-1-7 TERMINAL STRIP-	287NTBD 96906	0	30-41-11 255/216/R047	001, 003-099, 115-199
TB5040		MS27212-1-7 TERMINAL STRIP-	287N4132 96906	0	30-41-11 255/216/R047	ALL
TB5041		MS27212-6-2 TERMINAL STRIP-	287N4154 96906	1	33-14-31 239/225/L047	ALL
TB5042		MS27212-6-2 TERMINAL STRIP-	287N4149 96906	1	33-14-31 239/224/R045	ALL
TB5043		MS27212-6-2 TERMINAL STRIP-	287N4121 96906	1	33-14-31 P061-00/ /	ALL
TB5044		MS27212-1-3 TERMINAL STRIP-	232N4704 96906	1	33-14-51 297/261/R005	115-199
TB5047		MS18029-5S2 TERMINAL STRIP-	284N1482 96906	1	24-31-41 E006-00/ /	001

EQUIPMENT LIST

D280N032

Section TB5000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5047		MS18029-5S3 TERMINAL STRIP-	284N1482 96906	1	24-31-41 E006-00/ /	003-099
TB5047		MS18029-5S3 TERMINAL STRIP-	284N1729 96906	1	24-31-41 E006-00/ /	115-199
TB5048		MS18029-5S3 TERMINAL STRIP-	284N1471 96906	1	24-32-41 E006-00/ /	ALL
TB5050		MS27212-1-12 TERMINAL STRIP- (PLATE D)	284N1129 96906	0	24-51-11 P070-00/ /	ALL
TB5070		MS27212-2-12 TERMINAL STRIP-	284N1127 96906	0	24-32-41 P037-00/ /	ALL

EQUIPMENT LIST

D280N032

Section TB5000
Page 3 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0012		S233T913-1 SNSR-ANGLE OF ATTACK,L	232N9601 81205	1	34-12-11 227/198/L047	ALL
TS0013		S233T913-1 SNSR-ANGLE OF ATTACK,R	233N9601 81205	1	34-12-21 227/198/R047	ALL
TS0028		971-4193-001 XDCR-ACCELERATION,3 AXIS	284N1444 97896	1	31-31-51 1065/185/L003	ALL
TS0035		S253T404-2 XDCR-LIN VAR DISPL,SPD BRK	254N1053 81205	3	27-61-13 1065/ /	ALL
TS0041		625928-2 SENSOR-LEFT PACK COMPRESSOR OUTLET TEMP	213N1001 08179	1	21-51-15 990/155/L047	ALL
TS0042		625928-2 TEMP SENSOR-RIGHT PACK COMPRESSOR OUTLET	213N1001 08179	1	21-51-25 0975/155/R027	ALL
TS0082		S283T001-15 XDCR-ANTISKID,1	161N0001 81205	1	32-42-11 ***/ /	001-099
TS0082	1	S283T001-15 XDCR-ANTISKID,1	161N0001 81205	1	32-42-11 ***/ /	115-199
TS0082	2	S283T001-10 XDCR-ANTISKID,1	161N0001 81205	1	32-42-11 ***/ /	115-199
TS0083		S283T001-15 XDCR-ANTISKID,2	161N0001 81205	1	32-42-11 ***/ /	001-099
TS0083	1	S283T001-15 XDCR-ANTISKID,2	161N0001 81205	1	32-42-11 ***/ /	115-199
TS0083	2	S283T001-10 XDCR-ANTISKID,2	161N0001 81205	1	32-42-11 ***/ /	115-199
TS0084		S283T001-15 XDCR-ANTISKID,5	161N0001 81205	1	32-42-11 ***/ /	001-099
TS0084	1	S283T001-15 XDCR-ANTISKID,5	161N0001 81205	1	32-42-11 ***/ /	115-199
TS0084	2	S283T001-10 XDCR-ANTISKID,5	161N0001 81205	1	32-42-11 ***/ /	115-199
TS0085		S283T001-15 XDCR-ANTISKID,6	161N0001 81205	1	32-42-11 ***/ /	001-099
TS0085	1	S283T001-15 XDCR-ANTISKID,6	161N0001 81205	1	32-42-11 ***/ /	115-199

EQUIPMENT LIST

D280N032

Section TS0000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0085	2	S283T001-10 XDCR-ANTISKID,6	161N0001 81205	1	32-42-11 *** / /	115-199
TS0086		S283T001-15 XDCR-ANTISKID,3	161N0001 81205	1	32-42-11 *** / *	001-099
TS0086	1	S283T001-15 XDCR-ANTISKID,3	161N0001 81205	1	32-42-11 *** / *	115-199
TS0086	2	S283T001-10 XDCR-ANTISKID,3	161N0001 81205	1	32-42-11 *** / *	115-199
TS0087		S283T001-15 XDCR-ANTISKID,4	161N0001 81205	1	32-42-11 *** / *	001-099
TS0087	1	S283T001-15 XDCR-ANTISKID,4	161N0001 81205	1	32-42-11 *** / *	115-199
TS0087	2	S283T001-10 XDCR-ANTISKID,4	161N0001 81205	1	32-42-11 *** / *	115-199
TS0088		S283T001-15 XDCR-ANTISKID,7	161N0001 81205	1	32-42-11 **** / **	001-099
TS0088	1	S283T001-15 XDCR-ANTISKID,7	161N0001 81205	1	32-42-11 **** / **	115-199
TS0088	2	S283T001-10 XDCR-ANTISKID,7	161N0001 81205	1	32-42-11 **** / **	115-199
TS0089		S283T001-15 XDCR-ANTISKID,8	161N0001 81205	1	32-42-11 / /	001-099
TS0089	1	S283T001-15 XDCR-ANTISKID,8	161N0001 81205	1	32-42-11 / /	115-199
TS0089	2	S283T001-10 XDCR-ANTISKID,8	161N0001 81205	1	32-42-11 / /	115-199
TS0090		S271T451-1 XDCR-HYDRAULIC BRAKE PRESS	274N1006 81205	1	32-41-11 1100/145/	ALL

EQUIPMENT LIST

D280N032

Section TS0000

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0108		60B92018-56 UNIT COMPENSATOR,L MAIN TANK	345N2001 81205	1	28-41-51 WS234/WRP/LMS	001-099
TS0108		S345T002-307 UNIT COMPENSATOR,L MAIN TANK	345N2001 81205	1	28-41-21 WS234/WRP/LMS	115-199
TS0109		S345N001-130 UNIT 1-TANK,L MAIN	345N2001 81205	1	28-41-51 WS236/WRP/LMS	001-099
TS0109		S345T002-311 UNIT 1-TANK,L MAIN	345N2001 81205	1	28-41-21 WS236/WRP/LMS	115-199
TS0110		S345N001-131 UNIT 2-TANK,L MAIN	345N2001 81205	1	28-41-51 WS261/WRP/LMS	001-099
TS0110		S345T002-312 UNIT 2-TANK,L MAIN	345N2001 81205	1	28-41-21 WS261/WRP/LMS	115-199
TS0111		S345N001-132 UNIT 3-TANK,L MAIN	345N2001 81205	1	28-41-51 WS288/WRP/LMS	001-099
TS0111		S345T002-313 UNIT 3-TANK,L MAIN	345N2001 81205	1	28-41-21 WS288/WRP/LMS	115-199
TS0112		S345N001-133 UNIT 4-TANK,L MAIN	345N2001 81205	1	28-41-51 WS316/WRP/LMS	001-099
TS0112		S345T002-314 UNIT 4-TANK,L MAIN	345N2001 81205	1	28-41-21 WS316/WRP/LMS	115-199
TS0113		S345N001-134 UNIT 5-TANK,L MAIN	345N2001 81205	1	28-41-51 WS372/WRP/LMS	001-099
TS0113		S345T002-315 UNIT 5-TANK,L MAIN	345N2001 81205	1	28-41-21 WS372/WRP/LMS	115-199
TS0114		S345N001-134 UNIT 6-TANK,L MAIN	345N2001 81205	1	28-41-51 W0400/WRP/LMS	001-099
TS0114		S345T002-315 UNIT 6-TANK,L MAIN	345N2001 81205	1	28-41-21 W0400/WRP/LMS	115-199
TS0115		S345N001-135 UNIT 7-TANK,L MAIN	345N2001 81205	1	28-41-51 WS428/WRP/LRS	001-099
TS0115		S345T002-316 UNIT 7-TANK,L MAIN	345N2001 81205	1	28-41-21 WS428/WRP/LRS	115-199
TS0116		S345N001-136 UNIT 8-TANK,L MAIN	345N2001 81205	1	28-41-51 WS456/WRP/LFS	001-099

EQUIPMENT LIST

D280N032

Section TS0100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0116		S345T002-317 UNIT 8-TANK,L MAIN	345N2001 81205	1	28-41-21 WS456/WRP/LFS	115-199
TS0117		S345N001-137 UNIT 9-TANK,L MAIN	345N2001 81205	1	28-41-51 WS512/WRP/LRS	001-099
TS0117		S345T002-318 UNIT 9-TANK,L MAIN	345N2001 81205	1	28-41-21 WS512/WRP/LRS	115-199
TS0118		S345N001-138 UNIT 10-TANK,L MAIN	345N2001 81205	1	28-41-51 WS540/WRP/LMS	001-099
TS0118		S345T002-319 UNIT 10-TANK,L MAIN	345N2001 81205	1	28-41-21 WS540/WRP/LMS	115-199
TS0119		60B92018-56 UNIT-COMPENSATOR,R MAIN TANK	345N2001 81205	1	28-41-51 WS234/WRP/RMS	001-099
TS0119		S345T002-307 UNIT-COMPENSATOR,R MAIN TANK	345N2001 81205	1	28-41-31 WS234/WRP/RMS	115-199
TS0120		803163-01 XDCR-PRESS,OXY	417N4224 53655	1	35-11-13 0629/190/R058	001-099
TS0120		803163-01 XDCR-PRESS,OXY	417N4224 53655	1	35-11-13 0629/193/R058	115-199
TS0146		S345N001-130 UNIT 1-TANK,R MAIN	345N2001 81205	1	28-41-51 WS236/WRP/RMS	001-099
TS0146		S345T002-311 UNIT 1-TANK,R MAIN	345N2001 81205	1	28-41-31 WS236/WRP/RMS	115-199
TS0147		S345N001-131 UNIT 2-TANK,R MAIN	345N2001 81205	1	28-41-51 WS261/WRP/RMS	001-099
TS0147		S345T002-312 UNIT 2-TANK,R MAIN	345N2001 81205	1	28-41-31 WS261/WRP/RMS	115-199
TS0148		S345N001-132 UNIT 3-TANK,R MAIN	345N2001 81205	1	28-41-51 WS288/WRP/RRS	001-099
TS0148		S345T002-313 UNIT 3-TANK,R MAIN	345N2001 81205	1	28-41-31 WS288/WRP/RRS	115-199
TS0149		S345N001-133 UNIT 4-TANK,R MAIN	345N2001 81205	1	28-41-51 WS316/WRP/RMS	001-099
TS0149		S345T002-314 UNIT 4-TANK,R MAIN	345N2001 81205	1	28-41-31 WS316/WRP/RMS	115-199

EQUIPMENT LIST

D280N032

Section TS0100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0150		S345N001-134 UNIT 5-TANK,R MAIN	345N2001 81205	1	28-41-51 WS372/WRP/RRS	001-099
TS0150		S345T002-315 UNIT 5-TANK,R MAIN	345N2001 81205	1	28-41-31 WS372/WRP/RRS	115-199
TS0151		S345N001-134 UNIT 6-TANK,R MAIN	345N2001 81205	1	28-41-51 WS400/WRP/RMS	001-099
TS0151		S345T002-315 UNIT 6-TANK,R MAIN	345N2001 81205	1	28-41-31 WS400/WRP/RMS	115-199
TS0152		S345N001-135 UNIT 7-TANK,R MAIN	345N2001 81205	1	28-41-51 WS428/WPR/RRS	001-099
TS0152		S345T002-316 UNIT 7-TANK,R MAIN	345N2001 81205	1	28-41-31 WS428/WPR/RRS	115-199
TS0153		S345N001-136 UNIT 8-TANK,R MAIN	345N2001 81205	1	28-41-51 WS456/WRP/RMS	001-099
TS0153		S345T002-317 UNIT 8-TANK,R MAIN	345N2001 81205	1	28-41-31 WS456/WRP/RMS	115-199
TS0154		S345N001-137 UNIT 9-TANK,R MAIN	345N2001 81205	1	28-41-51 WS512/WRP/RRS	001-099
TS0154		S345T002-318 UNIT 9-TANK,R MAIN	345N2001 81205	1	28-41-31 WS512/WRP/RRS	115-199
TS0155		S345N001-138 UNIT 10-TANK,R MAIN	345N2001 81205	1	28-41-51 WS540/WRP/RMS	001-099
TS0155		S345T002-319 UNIT 10-TANK,R MAIN	345N2001 81205	1	28-41-31 WS540/WRP/RMS	115-199
TS0164		2156-204 SNSR-SMOKE,EQUIPMENT COOLING,FWD	217N1016 03972	1	21-58-12 555/188/L058	ALL
TS0167		60B50402-2 XMTR-WATER QUANTITY	417N2508 81205	1	38-14-11 1670/187/	001-099
TS0167		60B50402-2 XMTR-WATER QUANTITY	417N2508 81205	1	38-14-11 1674/182/R024	115-199
TS0171		S331T001-5 XDCR-THROTTLE LEVER ANGLE,R ENG	254N1058 81205	1	73-21-12 0210/199/R012	ALL
TS0175		S210T130-75 SNSR-TEMP,DUCT AIR,FLT DECK ZONE	214N1011 81205	1	21-61-11 0350/197/L052	001-099

EQUIPMENT LIST

D280N032

Section TS0100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0175		S210T130-19 SNSR-TEMP,DUCT AIR,FLT DECK ZONE	214N1011 81205	1	21-61-11 0350/197/L052	115-199
TS0177		S210T130-75 SNSR-FWD CABIN ZONE DUCT AIR TEMP	214N2002 81205	1	21-61-21 0860/299/L011	001-099
TS0177		S210T130-19 SNSR-FWD CABIN ZONE DUCT AIR TEMP	214N2002 81205	1	21-61-21 0860/299/L011	115-199
TS0179		S210T130-75 SNSR-AFT CABIN ZONE DUCT AIR TEMP	214N2002 81205	1	21-61-31 0880/299/L011	001-099
TS0179		S210T130-19 SNSR-AFT CABIN ZONE DUCT AIR TEMP	214N2002 81205	1	21-61-31 0880/299/L011	115-199
TS0184		MS28034-1 SNSR-TEMP,FLT DECK DUCT	214N1011 96906	1	21-65-12 0355/198/L054	ALL
TS0185		MS28034-1 SNSR-TEMP,FWD DUCT	214N2002 96906	1	21-65-12 0860/299/L011	ALL
TS0186		MS28034-1 SNSR-TEMP,AFT DUCT	214N2002 96906	1	21-65-12 880/299/L011	ALL
TS0187		S242T404-701 SNSR-EFIS REMOTE LIGHT,CAPT	233N8100 81205	1	34-22-15 P007-00/ /	ALL
TS0188		S242T404-701 SNSR-EFIS REMOTE LIGHT,F/O	233N8100 81205	1	34-22-25 P007-00/ /	ALL
TS0194		S251T362-3 LVDT-RATIO CHANGER,RUD	251N3005 81205	1	27-21-12 FS117RS/ /	ALL
TS0195		S344N001-2 SNSR-FUEL LEVEL,SURGE TANK,L	344N3001 81205	1	28-21-21 WS682/WRP/LFS	ALL
TS0196		S344N001-2 SNSR-FUEL LEVEL,SURGE TANK,R	344N3001 81205	1	28-21-21 WS682/LRS/WRP	ALL
TS0198		624014-1 SENSOR-LEFT PACK TEMP	213N1001 81205	1	21-51-12 0943/149/L032	ALL
TS0199		624014-1 TEMP SENSOR-RIGHT PACK	213N1001 81205	1	21-51-22 0943/149/R032	ALL

EQUIPMENT LIST

D280N032

Section TS0100
Page 4 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0200		S210T130-75 SENSOR-LEFT MIX MANIFOLD TEMP	213N2003 81205	1	21-51-12 883/175/L040	001-099
TS0200		S210T130-19 SENSOR-LEFT MIX MANIFOLD TEMP	213N2003 81205	1	21-51-12 863/189/L009	115-199
TS0201		S210T130-75 TEMP SENSOR-RIGHT MIX MANIFOLD	213N2003 81205	1	21-51-22 883/163/L020	001-099
TS0201		S210T130-19 TEMP SENSOR-RIGHT MIX MANIFOLD	213N2003 81205	1	21-51-22 883/163/L020	115-199
TS0202		S283N001-50 SNSR-DET ELEM,L WW	284N1443 81205	1	26-17-11 1140/198/L017	ALL
TS0203		S283N001-51 SNSR-DET ELEM,L WW	284N1443 81205	1	26-17-11 1136/198/L017	ALL
TS0204		S283N001-50 SNSR-DET ELEM,R WW	284N1443 81205	1	26-17-11 1140/198/R017	ALL
TS0205		S283N001-51 SNSR-DET ELEM,R WW	284N1443 81205	1	26-17-11 1136/198/R017	ALL
TS0281	1	285T0112-6 SNSR ASSY-AUTO BRT,MD&T	233N2221 81205	1	33-16-11 P001-03/ /	ALL
TS0281	2	285T0112-4 SNSR ASSY-AUTO BRT,MD&T	233N2221 81205	1	33-16-11 P001-03/ /	ALL
TS0285		11198-4 SENSOR-AIR FLOW,LEFT PACK	213N1001 07148	1	21-52-31 934/158/L054	001-008, 115-199
TS0285		11198-4 SENSOR-AIR FLOW,LEFT PACK	213N1001 07148	1	21-52-31 925.7/158/45.3	009-099
TS0286		11198-4 SENSOR-AIR FLOW,RIGHT PACK	213N1001 07148	1	21-52-31 938/153/R059	001-008, 115-199
TS0286		11198-4 SENSOR-AIR FLOW,RIGHT PACK	213N1001 07148	1	21-52-31 938/154/R059	009-099

EQUIPMENT LIST

D280N032

Section TS0200

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0350		MS28034-1 SNSR-TEMP,L PRECOOLER OUT	316N5101 96906	1	36-22-21 FSS290.5/ /	ALL
TS0351		MS28034-1 SNSR-TEMP,R PRECOOLER OUT	316N5101 96906	1	36-22-21 FFS290/ /	ALL
TS0352		U-217939 SYNCHRO-AIDS	254N1053 82686	1	31-31-12 P010-00/ /	115-199

EQUIPMENT LIST

D280N032

Section TS0300
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5001		102LA2AG PROBE-TAT,R	232N9401 04274	1	34-12-11 0433/202/R070	ALL
TS5002		MS28034-1 TEMP BULB-RIGHT PACK DISCHARGE	213N3001 96906	1	21-52-11 0942/156/R051	ALL
TS5003		MS28034-1 TEMP BULB-LEFT PACK DISCHARGE	212N3001 96906	1	21-52-11 0942/156/L024	ALL
TS5010		60B92018-56 UNIT-COMPENSATOR,CTR TANK	345N2001 81205	1	28-41-51 0966/WRP/R073	001-099
TS5010		S345T002-307 UNIT-COMPENSATOR,CTR TANK	345N2001 81205	1	28-41-41 0966/WRP/R073	115-199
TS5011		S345N001-144 UNIT 1-TANK,CTR	345N2001 81205	1	28-41-51 1007/WRP/L002	001-099
TS5011		S345T002-335 UNIT 1-TANK,CTR	345N2001 81205	1	28-41-41 1007/WRP/L002	115-199
TS5012		S345N001-142 UNIT 2-TANK,CTR	345N2001 81205	1	28-41-51 0946/WRP/LO75	001-099
TS5012		S345T002-333 UNIT 2-TANK,CTR	345N2001 81205	1	28-41-41 0946/WRP/LO75	115-199
TS5013		S345N001-143 UNIT 3-TANK,CTR	345N2001 81205	1	28-41-51 1011/WRP/L076	001-099
TS5013		S345T002-334 UNIT 3-TANK,CTR	345N2001 81205	1	28-41-41 1011/WRP/L076	115-199
TS5014		S345N001-141 UNIT 4-TANK,CTR	345N2001 81205	1	28-41-51 W0200/WRP/LFS	001-099
TS5014		S345T002-332 UNIT 4-TANK,CTR	345N2001 81205	1	28-41-41 W0200/WRP/LFS	115-199
TS5015		S345N001-140 UNIT 5-TANK,CTR	345N2001 81205	1	28-41-51 WS228/WRP/LMS	001-099
TS5015		S345T002-331 UNIT 5-TANK,CTR	345N2001 81205	1	28-41-41 WS228/WRP/LMS	115-199
TS5016		S345N001-142 UNIT 6-TANK,CTR	345N2001 81205	1	28-41-51 0946/WRP/R075	001-099
TS5016		S345T002-333 UNIT 6-TANK,CTR	345N2001 81205	1	28-41-41 0946/WRP/R075	115-199

EQUIPMENT LIST

D280N032

Section TS5000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5017		S345N001-143 UNIT 7-TANK,CTR	345N2001 81205	1	28-41-51 1011/WRP/R076	001-099
TS5017		S345T002-334 UNIT 7-TANK,CTR	345N2001 81205	1	28-41-41 1011/WRP/R076	115-199
TS5018		285T0177-3 SNSR-CURRENT,CARGO FAN,FWD	284N1129 81205	1	21-43-11 P070-00/ /	115-199
TS5019		L922213 TRANSDUCER-OIL QUANTITY	10E80008 K0680	2	79-31-11 ENG/ /	ALL
TS5020		L930804 TRANSDUCER-OIL TEMPERATURE	10E80008 K0680	2	79-34-11 ENG/ /	ALL
TS5021		L962658 TRANSDUCER-OIL PRESSURE	10E80008 K0680	2	79-32-11 ENG/ /	ALL
TS5023		14FF104 TRANSDUCER-POWER LEVER ANGLE	10E80008 K0624	2	75-31-11 ENG/ /	ALL
TS5024		L961747 THERMOCOUPLE-T2 SONIC	10E80008 K0680	1	75-31-11 ENG/ /	ALL
TS5025		L961724 THERMOCOUPLE,TGT	10E80008 K0680	2	77-21-11 ENG/ /	ALL
TS5027		PARTOFL150901-FFR- XMTR-FFR TRIM MOTOR POSITION	10E80008 K0680	2	73-21-11 ENG/ /	ALL
TS5028		L970331 TRANSDUCER-VIBRATION NO.2	10E80008 K0680	1	77-31-11 ENG/ /	ALL
TS5038		L970331 TRANSDUCER-VIBRATION NO.1	10E80008 K0680	1	77-31-11 ENG/ /	ALL
TS5044		285T0177-3 SNSR-CURRENT,CARGO FAN,AFT (PLATE B)	284N1320 81205	1	21-44-11 P037-00/ /	115-199
TS5046		S251N403-12 SNSR-FLAP LEVER,2	254N1052 81205	1	27-51-41 P010-00/ /	ALL
TS5047		S251N403-16 SNSR-POSITION,SLAT,RIGHT	251N5001 81205	1	27-51-41 0SS816/ /RLE	ALL
TS5048		S251N403-14 SENSOR-POSITION,SLAT PDU	251N5091 81205	1	27-81-11 FSS115/ /	ALL
TS5049		S251N403-17 SENSOR-POSITION,FLAP,L	251N4001 81205	1	27-51-41 WS583/ /	ALL

EQUIPMENT LIST

D280N032

Section TS5000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5050		S251N403-13 SENSOR-POSITION,FLAP,PDU	251N4001 81205	1	27-51-11 1060/183/L020	ALL
TS5051		S251N403-18 SENSOR-POSITION,FLAP,R	251N4001 81205	1	27-51-41 WS586/ /RRS	ALL
TS5062		S332T301-19 DETECTOR-FIRE,APU LOOP 2 LOWER	355N5101 81205	1	26-15-11 1945/233/R001	ALL
TS5063		S332T301-39 DETECTOR-FIRE,APU,LOOP 2 UPPER	355N5101 81205	1	26-15-11 1932/253/LR18	ALL
TS5064		S332T301-240 DET-OVHT,NACELLE,LOOP 1	312N5504 81205	2	26-11-12 PPS165/ /	ALL
TS5065		S332T301-240 DET-OVHT,NACELLE,LOOP 2	312N5504 81205	2	26-11-12 PPS165/ /	ALL
TS5066		S332T301-19 DETECTOR-FIRE,APU,LOOP 1 LOWER	355N5101 81205	1	26-15-11 1891/225/R001	ALL
TS5067		S332T301-39 DETECTOR-FIRE,APU,LOOP 1 UPPER	355N5101 81205	1	26-15-11 1932/253/LR18	ALL
TS5072		S231N210-2 SNSR-DIFFERENTIAL PRESSURE	232N9205 81205	1	21-33-11 0231/188/L042	ALL
TS5073		S332T301-240 DET-OVHT,NACELLE,LOOP 1	312N5504 81205	1	26-11-22 N165/132/L006	ALL
TS5074		S332T301-240 DET-OVHT,NACELLE,LOOP 2	312N5504 81205	1	26-11-22 N165/132/R006	ALL
TS5075		S345N001-141 UNIT 8-TANK,CTR	345N2001 81205	1	28-41-41 WS200/WRP/RFS	001-099
TS5075		S345T002-332 UNIT 8-TANK,CTR	345N2001 81205	1	28-41-41 WS200/WRP/RFS	115-199
TS5076		S345N001-140 UNIT 9-TANK,CTR	345N2001 81205	1	28-41-41 WS228/WRP/RRS	001-099
TS5076		S345T002-331 UNIT 9-TANK,CTR	345N2001 81205	1	28-41-41 WS228/WRP/RRS	115-199
TS5081		S251N119-31 XDCR UNIT-CAPT WHL CMD	251N1014 81205	1	27-61-13 332/200/L003	ALL
TS5082		S251N119-31 XDCR UNITS-F/O WHL CMD	251N1014 81205	1	27-61-14 232/200/R038	ALL

EQUIPMENT LIST

D280N032

Section TS5000

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5083		S251N403-15 SNSR-POS,SLAT,LEFT	251N5001 81205	1	27-51-41 OSS812/ /LLE	ALL
TS5084		S256T007-8 SNSR-SLAT POS REF	284N1125 81205	1	27-58-11 P036-00/ /LFS	ALL

EQUIPMENT LIST

D280N032

Section TS5000
Page 4 End
Oct 09/2008

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5132		624014-1 TEMP SENSOR-PACK #2,L	213N1001 07217	1	21-51-14 946/158/L043	ALL
TS5133		625928-2 TEMP SNSR-PACK COMP OUTLET #2,L	213N1001 07217	1	21-51-14 982/151/L047	ALL
TS5134		624014-1 TEMP SENSOR-STANDBY,RIGHT PACK OUTLET	213N1001 07217	1	21-51-24 960/148/R031	ALL
TS5135		625928-2 TEMP SENSOR-RIGHT PACK COMP OUTLET	213N1001 07217	1	21-51-24 982/151/R035	ALL
TS5138		S210N701-2 SNSR-LOW FLOW,EQUIP COOLING,AFT	213N1023 81205	1	21-58-11 1494/194/R056	115-199
TS5140		57B28A SNSR-FUEL TEMP	345N2000 35918	1	28-43-11 0265/ /RS	ALL
TS5141		51236-003 DETECTOR-FIRE,LOOP 2,NO.4	10E80008 K1536	2	26-11-11 ENG/ /	ALL
TS5142		51236-003 DETECTOR-FIRE,LOOP 1,NO.4	10E80008 K1536	2	26-11-11 ENG/ /	001-099
TS5143		51236-001 DETECTOR-FIRE,LOOP 2,NO.3	10E80008 K1536	2	26-11-11 ENG/ /	ALL
TS5144		51236-001 DETECTOR-FIRE,LOOP 1,NO.3	10E80008 K1536	2	26-11-11 ENG/ /	ALL
TS5145		51216-001 DETECTOR-FIRE,LOOP 2,NO.1	10E80008 K1536	2	26-11-11 ENG/ /	ALL
TS5146		51216-001 DETECTOR-FIRE,LOOP 1,NO.1	10E80008 K1536	2	26-11-11 ENG/ /	ALL
TS5147		51216-002 DETECTOR-FIRE,LOOP 2,NO.2	10E80008 K1536	2	26-11-11 ENG/ /	ALL
TS5148		51216-002 DETECTOR-FIRE,LOOP 1,NO.2	10E80008 K1536	2	26-11-11 ENG/ /	ALL
TS5151		S251N222-1 XDCR-ELEVATOR NEUTRAL SHIFT LINEAR,LEFT	251N2241 81205	1	22-11-11 1862/240/R012	ALL
TS5152		S251N222-1 XDCR-ELEVATOR NEUTRAL SHIFT LINEAR,RIGHT	251N2241 81205	1	22-11-21 1870/200/R015	ALL
TS5153		S251N222-1 XDCR-ELEVATOR NEUTRAL SHIFT LINEAR,CTR	251N2241 81205	1	22-11-31 1862/240/R010	ALL

EQUIPMENT LIST

D280N032

Section TS5100

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5155		S210N701-2 SNSR-LOW FLOW,FWD EQUIP SUPPLY	217N2002 81205	1	21-58-11 0271/171/R035	ALL
TS5157		S283N001-12 DETECTOR-ELEMENT ZONE 1,L WING,LOOP A	218N4009 81205	1	26-18-11 FSS100/ /LFS	ALL
TS5158		S283N001-12 DETECTOR-ELEMENT ZONE 1,L WING,LOOP B	218N4009 81205	1	26-18-11 FSS100/ /LFS	ALL
TS5159		S283N001-13 DETECTOR-ELEMENT ZONE 1,L WING,LOOP A	218N4009 81205	1	26-18-11 FSS/150/LFS	ALL
TS5160		S283N001-13 DETECTOR-ELEMENT ZONE 1,L WING,LOOP B	218N4009 81205	1	26-18-11 FSS/150/LFS	ALL
TS5161		S283N001-16 DETECTOR-ELEMENT ZONE 1,L WING,LOOP A	218N4009 81205	1	26-18-11 FSS250/**/	ALL
TS5162		S283N001-16 DETECTOR-ELEMENT ZONE 1,L WING,LOOP B	218N4009 81205	1	26-18-11 FSS250/**/	ALL
TS5163		S283N001-15 DETECTOR ELEMENT ZONE 2 L PACK LOOP A	218N4008 81205	1	26-18-11 1030/160/	ALL
TS5164		S283N001-15 DETECTOR ELEMENT ZONE 2 L PACK LOOP B	218N4008 81205	1	26-18-11 1030/160/	ALL
TS5165		S283N001-17 DETECTOR ELEMENT ZONE 2 L PACK LOOP A	218N4008 81205	1	26-18-11 900/155/R015	ALL
TS5166		S283N001-17 DETECTOR-ELEMENT ZONE 2,L PACK,LOOP B	218N4008 81205	1	26-18-11 900/155/R015	ALL
TS5167		S283N001-18 DETECTOR-ELEMENT ZONE 2,L PACK,LOOP A	218N4008 81205	1	26-18-11 920/160/L025	ALL
TS5168		S283N001-18 DETECTOR-ELEMENT ZONE 2,L PACK,LOOP B	218N4008 81205	1	26-18-11 920/160/L035	ALL
TS5169		S283N001-11 DETECTOR ELEMENT ZONE 3 ECS R WW LOOP A	218N4006 81205	1	26-18-11 1080/190/R007	ALL
TS5170		S283N001-11 DETECTOR ELEMENT ZONE 3 ECS R WW LOOP B	218N4006 81205	1	26-18-11 1080/190/R007	ALL
TS5171		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP A	218N4004 81205	1	26-18-11 1210/198/L045	ALL
TS5172		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP B	218N4004 81205	1	26-18-11 1210/198/L045	ALL

EQUIPMENT LIST

D280N032

Section TS5100

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5173		S283N001-16 DETECTOR ELEMENT ZONE 4 SEC 46 LOOP A	218N4004 81205	1	26-18-11 1300/198/L045	ALL
TS5174		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP B	218N4004 81205	1	26-18-11 1300/198/L045	ALL
TS5175		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP A	218N4004 81205	1	26-18-11 1420/198/L045	ALL
TS5176		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP B	218N4004 81205	1	26-18-11 1420/198/L045	ALL
TS5177		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP A	218N4004 81205	1	26-18-11 1530/198/L045	ALL
TS5178		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP B	218N4004 81205	1	26-18-11 1530/198/L045	ALL
TS5179		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP A	218N4004 81205	1	26-18-11 1680/198/L030	ALL
TS5180		S283N001-16 DETECTOR-ELEMENT ZONE 4,SEC 46,LOOP B	218N4004 81205	1	26-18-11 1680/198/L030	ALL
TS5181		S283N001-31 DETECTOR-ELEMENT ZONE 5,SEC 48,LOOP A	218N4002 81205	1	26-18-11 1740/220/L020	ALL
TS5182		S283N001-31 DETECTOR-ELEMENT ZONE 5,SEC 48,LOOP B	218N4002 81205	1	26-18-11 1740/220/L020	ALL
TS5183		S283N001-32 DETECTOR-ELEMENT ZONE 5,SEC 48,LOOP A	218N4004 81205	1	26-18-11 1840/230/L020	ALL
TS5184		S283N001-32 DETECTOR-ELEMENT ZONE 5,SEC 48,LOOP B	218N4002 81205	1	26-18-11 1840/230/L020	ALL
TS5185		S283N001-12 DETECTOR-ELEMENT ZONE 6,R WING,LOOP A	218N4009 81205	1	26-18-21 FSS100/ /RFS	ALL
TS5186		S283N001-12 DETECTOR-ELEMENT ZONE 6,R WING,LOOP B	218N4009 81205	1	26-18-21 FSS100/ /RFS	ALL
TS5187		S283N001-13 DETECTOR-ELEMENT ZONE 6,R WING,LOOP A	218N4009 81205	1	26-18-21 FSS150/ /RFS	ALL
TS5188		S283N001-13 DETECTOR-ELEMENT ZONE 6,R WING,LOOP B	218N4009 81205	1	26-18-21 FSS150/ /RFS	ALL
TS5189		S283N001-16 DETECTOR-ELEMENT ZONE 6,R WING,LOOP A	218N4009 81205	1	26-18-21 FSS250/ /RFS	ALL

EQUIPMENT LIST

D280N032

Section TS5100

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5190		S283N001-16 DETECTOR-ELEMENT ZONE 6,R WING,LOOP B	218N4009 81205	1	26-18-21 FSS250/ /RFS	ALL
TS5191		S283N001-14 DETECTOR-ELEMENT ZONE 7,R PACK,LOOP A	218N4008 81205	1	26-18-21 970/155/R070	ALL
TS5192		S283N001-14 DETECTOR-ELEMENT ZONE 7,R PACK,LOOP B	218N4008 81205	1	26-18-21 970/155/R070	ALL
TS5193		270T245-1 SNSR-HYD RSVR TEMP,L	271N3001 81205	1	29-32-41 1052/188/L050	ALL
TS5194		270T245-1 SNSR-HYD RSVR TEMP,C	271N3002 81205	1	29-32-41 1198/140/L055	ALL
TS5195		270T245-1 SNSR-HYD RSVR TEMP,R	271N3003 81205	1	29-32-41 1052/188/R050	ALL
TS5196		S345N001-139 UNIT 11-TANK,L MAIN	345N2001 81205	1	28-41-21 WS591/WRP/LRS	001-099
TS5196		S345T002-320 UNIT 11-TANK,L MAIN	345N2001 81205	1	28-41-21 WS591/WRP/LRS	115-199
TS5197		S345N001-139 UNIT 12-TANK,L MAIN	345N2001 81205	1	28-41-21 WS626/WRP/LFS	001-099
TS5197		S345T002-320 UNIT 12-TANK,L MAIN	345N2001 81205	1	28-41-21 WS626/WRP/LFS	115-199
TS5198		S345N001-139 UNIT 11-TANK,R MAIN	345N2001 81205	1	28-41-31 WS591/WRP/RRS	001-099
TS5198		S345T002-320 UNIT 11-TANK,R MAIN	345N2001 81205	1	28-41-31 WS591/WRP/RRS	115-199
TS5199		S345N001-139 UNIT 12-TANK,R MAIN	345N2001 81205	1	28-41-31 WS626/WRP/RFS	001-099
TS5199		S345T002-320 UNIT 12-TANK,R MAIN	345N2001 81205	1	28-41-31 WS626/WRP/RFS	115-199

EQUIPMENT LIST

D280N032

Section TS5100
Page 4 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5200		S251N233-3 PCU-OUTBD	S251N211 81205	1	27-23-21 ELEV/170/RS	ALL
TS5201		S251N233-3 PCU-INBD	S251N211 81205	1	27-23-21 ELEV/120/RRS	ALL
TS5202		S251N233-3 PCU-CTR	S251N211 81205	1	27-23-21 ELEV/145/R005	ALL
TS5203		S251N233-4 PCU-TOP	S251N311 81205	1	27-23-21 ****/**/	ALL
TS5204		S251N233-4 PCU-BOTTOM	S251N311 81205	1	27-23-21 FS170/RS/	ALL
TS5205		S251N233-4 PCU-CTR	S251N311 81205	1	27-23-21 FS180/RS/	ALL
TS5206		S251N233-3 PCU-OUTBD	S251N211 81205	1	27-23-21 ELEV/160/LRS	ALL
TS5207		S251N233-3 PCU-INBD	S251N211 81205	1	27-23-21 ELEV/112/LRS	ALL
TS5208		S251N233-3 PCU-CTR	S251N211 81205	1	27-23-21 ELEV/130/LRS	ALL
TS5267		2156-204A SENSOR-FWD EQPT SUPPLY SMOKE 1	217N1017 03972	1	21-58-12 0512/190/L040	ALL
TS5268		2156-204A SENSOR-FWD EQPT SUPPLY SMOKE 2	217N1017 03972	1	21-58-12 0512/190/L040	ALL

EQUIPMENT LIST

D280N032

Section TS5200

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5301		S250N104-4 SENSOR-SYNCHRO,CONTROL WHEEL	251N1434 81205	1	31-31-51 / /	001-099
TS5302		S250N104-4 SENSOR-SYNCHRO,CONTROL COLUMN	251N1416 81205	1	31-31-51 / /	001-099
TS5303		S250N104-4 SENSOR-SYNCHRO,RUDDER PEDAL	251N3048 81205	1	31-31-51 / /	001-099

EQUIPMENT LIST

D280N032

Section TS5300
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00001		S210T130-74 VALVE-TRIM AIR MODULATING,FLT DECK ZONE	213N2002 81205	1	21-61-11 0886/160/L010	ALL
V00002		S210T130-74 VALVE-FWD CABIN TRIM AIR MODULATING	213N2002 81205	1	21-61-21 0892/160/	ALL
V00003		S210T130-74 VALVE-TRIM AIR MODULATING,AFT CABIN ZONE	213N2002 81205	1	21-61-31 0893/163/L010	ALL
V00004		S210T130-36 VALVE-TRIM AIR PRESSURE REGULATING	213N2001 81205	1	21-61-51 0903/161/L017	ALL
V00015		S210T160-94 VALVE-OUTFLOW,CABIN PRESSURE	216N1003 81205	1	21-31-11 1651/175/L040	ALL
V00016		S210T130-608 VALVE-PACK FLOW CONTROL AND SHUTOFF,L	213N1003 81205	1	21-51-11 0950/156/L061	ALL
V00017		S210T130-608 VALVE-PACK FLOW CONTROL AND SHUTOFF,R	213N1003 81205	1	21-51-21 0950/150/R061	ALL
V00018		398750-4 VALVE-PACK TEMP CONTROL,L	S210T130 81205	1	21-51-12 0970/141/L042	ALL
V00019		398750-4 VALVE-PACK TEMP CONTROL,RIGHT	S210T130 81205	1	21-51-22 0970/150/R025	ALL
V00024	9	S343T003-66 ACTUATOR-FUEL CROSSFEED VAL.(SB 28A0088)	343N3101 81205	1	28-22-31 1040/182/L020	ALL
V00024		S343T003-14 ACTUATOR-FUEL CROSSFEED VALVE	343N3101 81205	1	28-22-31 1040/182/L020	001, 115-199
V00024		S343T003-39 ACTUATOR-FUEL CROSSFEED VALVE	343N3101 81205	1	28-22-31 1040/182/L020	002-008
V00025	9	S343T003-66 ACT-FUEL SHUTOFF VALE,L SPAR(SB 28A0088)	343N3101 81205	1	28-22-21 IRSS266/ /LRS	ALL
V00025		S343T003-14 ACTUATOR-FUEL SHUTOFF VALVE,L SPAR	343N3101 81205	1	28-22-21 IRSS266/ /LRS	001, 115-199
V00025		S343T003-39 ACTUATOR-FUEL SHUTOFF VALVE,L SPAR	343N3101 81205	1	28-22-21 IRSS266/ /LRS	002-099
V00026	9	S343T003-66 ACTUAT-FUEL SHUTF VAL,R SPAR SB 28A0088	343N3101 81205	1	28-22-21 IRSS265/ /RRS	ALL
V00026		S343T003-14 ACTUATOR-FUEL SHUTOFF VALVE,R SPAR	343N3101 81205	1	28-22-21 IRSS265/ /RRS	001, 115-199

EQUIPMENT LIST

D280N032

Section V00000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00026		S343T003-39 ACTUATOR-FUEL SHUTOFF VALVE,R SPAR	343N3101 81205	1	28-22-21 IRSS265/ /RRS	002-099
V00029		S283T001-2 VALVE-ANTISKID,2	274N1007 81205	1	32-42-11 1065/184/L062	ALL
V00030		S283T001-2 VALVE-ANTISKID,1	274N1007 81205	1	32-42-11 1065/187/L062	ALL
V00031		S283T001-2 VALVE-ANTISKID,6	274N1007 81205	1	32-42-11 1065/187/L062	ALL
V00032		S283T001-2 VALVE-ANTISKID,5	274N1007 81205	1	32-42-11 1065/187/L062	ALL
V00033		S283T001-2 VALVE-ANTISKID,3	274N1007 81205	1	32-42-11 1065/184/R075	ALL
V00034		S283T001-2 VALVE-ANTISKID,4	274N1007 81205	1	32-42-11 1065/184/R075	ALL
V00035		S283T001-2 VALVE-ANTISKID,7	274N1007 81205	1	32-42-11 1065/184/R075	ALL
V00036		S283T001-2 VALVE-ANTISKID,8	274N1007 81205	1	32-42-11 1065/184/R075	ALL
V00037		S283T001-2 VALVE-ANTISKID,RESERVE (5 & 6)	274N1008 81205	1	32-42-11 1070/184/L004	ALL
V00038		S283T001-2 VALVE-ANTISKID,RESERVE (1 & 2)	274N1008 81205	1	32-42-11 1078/184/L004	ALL
V00039		S283T001-2 VALVE-ANTISKID,RESERVE (7 & 8)	274N1008 81205	1	32-42-11 1070/184/R005	ALL
V00040		S283T001-2 VALVE-ANTISKID,RESERVE (3 & 4)	274N1008 81205	1	32-42-11 1070/184/R005	ALL
V00041	6	S270T010-2 VALVE-PARKING BRAKE	274N1005 91816	1	32-44-11 1040/170/R040	ALL
V00041	5	S270T010-5 VALVE-PARKING BRAKE	274N1005 91816	1	32-44-11 1040/170/R040	ALL
V00041	1	S270T010-11 VALVE-PARKING BRAKE	274N1005 91816	1	32-44-11 1040/170/R040	ALL
V00041	2	S271N501-3 VALVE-PARKING BRAKE	274N1005 79318	1	32-44-11 1040/170/R040	ALL

EQUIPMENT LIST

D280N032

Section V00000

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00041	3	S271N501-2 VALVE-PARKING BRAKE	274N1005 79318	1	32-44-11 1040/170/R040	ALL
V00041	4	S270T010-8 VALVE-PARKING BRAKE	274N1005 91816	1	32-44-11 1040/170/R040	ALL
V00042		S212N101-37 VALVE-PRESS REG AND SHUTOFF,AIR SUPPLY,L	312N5301 81205	1	36-11-11 PPS183/ /	001, 115-199
V00042		S212N101-47 VALVE-PRESS REG AND SHUTOFF,AIR SUPPLY,L	312N5301 81205	1	36-11-11 PPS183/ /	002-099
V00043		S212N101-37 VALVE-PRESS REG AND SHUTOFF,AIR SUPPLY,R	312N5301 81205	1	36-11-21 N174/140/R	001, 115-199
V00043		S212N101-47 VALVE-PRESS REG AND SHUTOFF,AIR SUPPLY,R	312N5301 81205	1	36-11-21 N174/140/R	002-099
V00046		S210N701-11 VALVE-AIR SUPPLY ISOLATION	212N3001 81205	1	36-11-31 0908/160/044	001-008, 115-199
V00047		S210N701-11 VALVE-APU AIR SUPPLY	212N3007 81205	1	36-11-41 1876/220/L030	ALL
V00052		2780537-104 VALVE-ANTI-ICE,L WING	218N1001 92003	1	30-11-11 OSS320/ /LLE	ALL
V00057		2780537-104 VALVE-ANTI-ICE,R WING	218N1001 92003	1	30-11-11 OSS320/ /RLE	ALL
V00095		60B40041-3 VALVE-OVERBOARD EXHAUST	217N1016 81205	1	21-58-12 555/170/L030	ALL
V00096	9	S343T003-66 ACTUAT-APU FUEL SHUTOFF VALVESB 28A0088	346N3001 81205	1	28-25-21 1040/180/L030	ALL
V00096		S343T003-14 ACTUATOR-APU FUEL SHUTOFF VALVE	346N3001 81205	1	28-25-21 1040/180/L030	001, 115-199
V00096		S343T003-39 ACTUATOR-APU FUEL SHUTOFF VALVE	346N3001 81205	1	28-25-21 1040/180/L030	002-099

EQUIPMENT LIST

D280N032

Section V00000

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00101		S271N501-3 VALVE-RUDDER/ELEVATOR HYD SHUTOFF,R	271N5015 81205	1	27-23-11 1180/189/R046	ALL
V00102		S271N501-3 VALVE-RUDDER/ELEVATOR HYD SHUTOFF,CTR	271N5015 81205	1	27-23-11 1180/170/L020	ALL
V00103		S271N501-3 VALVE-RUDDER/ELEVATOR HYD SHUTOFF,L	271N5015 81205	1	27-23-11 1180/193/L033	ALL
V00105		S270T002-3 VALVE-BYPASS,TE FLAP	274N1005 81205	1	27-51-21 1060/190/L020	ALL
V00106		S271T527-5 VALVE-T/R ISOLATION,L ENG	271N5001 81205	1	78-34-11 PPS240/ /L	001-099
V00106		S271T527-3 VALVE-T/R ISOLATION,L ENG	271N5001 81205	1	78-34-11 PPS240/ /L	115-199
V00107		S271T527-3 VALVE-T/R ISOLATION,R ENG	271N5001 81205	1	78-34-21 PPS240/ /R	115-199
V00108	9	S343T003-66 VALVE-DEFUEL, L TANK (SB 28A0088)	344N3001 81205	1	28-26-11 IRSS208/ /LRS	ALL
V00108		S343T003-14 VALVE-DEFUEL, L TANK	344N3001 81205	1	28-26-11 IRSS208/ /LRS	001, 115-199
V00108		S343T003-39 VALVE-DEFUEL, L TANK	344N3001 81205	1	28-26-11 IRSS208/ /LRS	002-099
V00109	9	S343T003-66 VALVE-DEFUEL, R TANK (SB 28A0088)	344N3001 81205	1	28-26-11 IRSS206/ /RRS	ALL
V00109		S343T003-14 VALVE-DEFUEL, R TANK	344N3001 81205	1	28-26-11 IRSS206/ /RRS	001, 115-199
V00109		S343T003-39 VALVE-DEFUEL, R TANK	344N3001 81205	1	28-26-11 IRSS206/ /RRS	002-099
V00118		60B40038-2 VALVE-WINDSHIELD RAIN REPELLENT,L	232N6201 81205	1	30-43-11 P001-03/ /	ALL
V00119		60B40038-2 VALVE-WINDSHIELD RAIN REPELLENT,R	232N6201 81205	1	30-43-11 P003-01/ /	ALL

EQUIPMENT LIST

D280N032

Section V00100

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V10001		60B92602-9 CONTROL UNIT-REFUELING VALVE L CTR TANK	344N3001 81205	1	28-21-23 1040/184/L050	001-002, 115-199
V10001		60B92602-14 CONTROL UNIT-REFUELING VALVE L CTR TANK	344N3001 81205	1	28-21-23 1040/184/L050	003-099
V10002		60B92602-9 CONTROL UNIT-REFUELING VALVE R TANK	344N3001 81205	1	28-21-23 IRSS255/ /RRS	001-002, 115-199
V10002		60B92602-14 CONTROL UNIT-REFUELING VALVE R TANK	344N3001 81205	1	28-21-23 IRSS255/ /RRS	003-099
V10003		60B92602-9 CONTROL UNIT-REFUELING VALVE,L TANK	344N3001 81205	1	28-21-23 IRSS258/ /LRS	001-002, 115-199
V10003		60B92602-14 CONTROL UNIT-REFUELING VALVE L TANK	344N3001 81205	1	28-21-23 IRSS258/ /LRS	003-099
V10005		10-3200-6 VALVE-PRIMARY ENG PUMP SUPPLY SHUTOFF,L	271N5001 81205	1	29-11-11 PPS236/ /	ALL
V10006		10-3200-6 VALVE-PRIMARY ENG PUMP SUPPLY SHUTOFF,R	271N5001 81205	1	29-11-21 PPS236/ /	ALL
V10007		S271N501-3 VALVE-PTU CONTROL	271N1010 81205	1	29-22-11 1061/160/R006	ALL
V10008		L925658 VALVE-ENGINE STARTER	10E80008 K0680	1	80-11-11 ENG/ /	ALL
V10009		PARTOFL150901-FFR- VALVE-MIN FLOW RESET SOLENOID(FFR)	10E80008 K0680	2	76-11-11 ENG/ /	ALL
V10010		PARTOFL150901 VALVE-IDLE RESET SOLENOID(FFG)	10E80008 K0680	2	76-11-21 ENG/ /	ALL
V10011		PARTOFL150901-FFR- VALVE-COLD DAY ENRICHMENT SOLENOID(FFR)	10E80008 K0680	2	76-11-11 ENG/ /	ALL
V10014		L913587 VALVE-HP3 BLEED SOLENOID,NO.2	10E80008 K0680	2	75-31-11 ENG/ /	ALL
V10018		L913586 VALVE-HP3 BLEED SOLENOID,NO.1	10E80008 K0680	2	75-31-11 ENG/ /	ALL
V10019		L913585 VALVE-IP BLEED SOLENOID,NO.1	10E80008 K0680	2	75-31-11 ENG/ /	ALL
V10020		L913585 VALVE-IP BLEED SOLENOID,NO.2	10E80008 K0680	2	75-31-11 ENG/ /	ALL

EQUIPMENT LIST

D280N032

Section V10000

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V10025		PARTOFL150901-FFR- SOLENOID-FFR FAIL FIX	10E80008 K0680	2	73-21-11 ENG/ /	ALL
V10026		PARTOFL150901-FFR- VALVE-FUEL SHUTOFF(FFR)	10E80008 K0680	2	76-11-11 ENG/ /	ALL
V10027		60B00200-4 SOLENOID-HYDRAULIC PUMP CONT	10E80008 81205	2	29-11-11 ENG/ /	001-099
V10027	1	570932 SOLENOID-HYDRAULIC PUMP CONT	10E80008 22681	2	29-11-11 ENG/ /	115-199
V10027	2	394357 SOLENOID-HYDRAULIC PUMP CTRL	10E80008 22681	2	29-11-11 ENG/ /	115-199
V10028		L945924 VALVE-NOSE COWL ANTI-ICING SOLENOID	10E80008 K0680	2	30-21-11 ENG/ /	001-003, 115-199
V10028		L945932 VALVE-NOSE COWL ANTI-ICING SOLENOID	10E80008 K0680	2	30-21-11 ENG/ /	004-099
V10031		TFU100MK2 UNIT-TRANSIENT FUEL	286N5003 49367	1	75-31-11 ENG/ /	ALL
V10059		S270T002-3 VALVE-BYPASS,LE SLAT	251N5011 81205	1	27-51-21 FSS158/ /	ALL
V10060		S251N402-1 VALVE-DEPRESSURIZATION MODULE	251N4016 81205	1	27-51-31 1040/ /	ALL
V10064		60B92602-9 CONTROL UNIT-REFUELING VALVE R CTR TANK	344N3001 81205	1	28-21-23 1040/180/R050	001-002, 115-199
V10064		60B92602-14 CONTROL UNIT-REFUELING VALVE R CTR TANK	344N3001 81205	1	28-21-23 1040/180/R050	003-099
V10069		271N1013-1 VALVE-SAFETY	271N0174 81205	1	29-21-31 1180/175/R050	ALL
V10070		S270T002-3 VALVE-RAT CONT	271N0174 81205	1	29-21-31 1180/150/R050	ALL
V10076		3289696-1 VALVE-PACK LOW LIMIT,RIGHT	S210T130 70210	1	21-51-24 966/150/R042	ALL
V10077		3289696-1 VALVE-PACK LOW LIMIT,LEFT	S210T130 70210	1	21-51-14 966/143/L032	ALL

EQUIPMENT LIST

D280N032

Section V10000

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V10112		S315N305-1 VALVE-CONTROL,L DIRECTIONAL	312N3101 81205	1	78-34-12 /***/	001-099
V10117		S270T002-3 VALVE-STANDPIPE SELECTOR	274NTBD 81205	1	29-21-32 1049/166/R055	ALL
V10118		S271N501-3 VALVE-SYSTEM ISOLATION	274NTBD 81205	1	29-21-32 1073/196/R059	ALL
V10128		S270T002-3 VALVE-HYD MTR DRIVEN GEN S/O	270N0901	1	24-25-13 1162/182/L004	ALL
V10138	9	S343T003-66 ACTUAT FWD FUEL CROSSFE. VAL SB 28A0088	343N3101 81205	1	28-22-31 / /	ALL
V10138		S343T003-39 ACTUATOR FWD FUEL CROSSFEED VALVE	343N3101 81205	1	28-22-31 / /	009-099
V10139	9	S343T003-66 ACTUATOR-AFT FUEL CROSSF VAL SB 28A0088	343N3101 81205	1	28-22-31 1040/182/L020	ALL
V10139		S343T003-39 ACTUATOR-AFT FUEL CROSSFEED VALVE	343N3101 81205	1	28-22-31 1040/182/L020	009-099
V10140		S210N701-11 VALVE-AIR SUPPLY ISOLATION	212N3001 81205	1	36-11-31 907.4/147/R033	009-099

EQUIPMENT LIST

D280N032

Section V10100

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA0++++		LRUOFM10395 MODULE- WINDOW HEAT	233N3101 81205	1	30-41-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YA0+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA0S01+		S231T290-5016 SW-R. SIDE WINDOW	233N3212 81205	1	30-41-11 P005-00/ /	115-199
YA0S01+	1	S231T290-4016 SW-R. SIDE WINDOW	233N3212 81205	1	30-41-11 P005-00/ /	001-099
YA0S01+	2	S231T290-5016 SW-R. SIDE WINDOW	233N3212 81205	1	30-41-11 P005-00/ /	001-099
YA0S01A		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	30-41-11 P005-00/ /	ALL
YA0S01B		MS25237-387 LAMP-(INOP)	S231T290 96906	2	30-41-11 P005-00/ /	ALL
YA0S01D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	30-41-11 P005-00/ /	001-099
YA0S01D		851-30768-3823 MODULE-DIODE/FUSE	S231T290 96182	1	30-41-11 P005-00/ /	115-199
YA0S01E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	30-41-11 P005-00/ /	001-099
YA0S02+		S231T290-5016 SW-R. FRONT WINDOW	233N3212 81205	1	30-41-12 P005-00/ /	115-199
YA0S02+	1	S231T290-4016 SW-R. FRONT WINDOW	233N3212 81205	1	30-41-12 P005-00/ /	001-099
YA0S02+	2	S231T290-5016 SW-R. FRONT WINDOW	233N3212 81205	1	30-41-12 P005-00/ /	001-099
YA0S02A		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	30-41-12 P005-00/ /	ALL
YA0S02B		MS25237-387 LAMP-(INOP)	S231T290 96906	2	30-41-12 P005-00/ /	ALL
YA0S02D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	30-41-12 P005-00/ /	001-099
YA0S02D		851-30768-3823 MODULE-DIODE/FUSE	S231T290 96182	1	30-41-12 P005-00/ /	115-199
YA0S02E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	30-41-12 P005-00/ /	001-099
YA0S03+		S231T290-5016 SW-L. FRONT WINDOW	233N3212 81205	1	30-41-11 P005-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YA0S00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA0S03+	1	S231T290-4016 SW-L. FRONT WINDOW	233N3212 81205	1	30-41-11 P005-00/ /	001-099
YA0S03+	2	S231T290-5016 SW-L. FRONT WINDOW	233N3212 81205	1	30-41-11 P005-00/ /	001-099
YA0S03A		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	30-41-11 P005-00/ /	ALL
YA0S03B		MS25237-387 LAMP-(INOP)	S231T290 96906	2	30-41-11 P005-00/ /	ALL
YA0S03D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	30-41-11 P005-00/ /	001-099
YA0S03D		851-30768-3823 MODULE-DIODE/FUSE	S231T290 96182	1	30-41-11 P005-00/ /	115-199
YA0S03E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	30-41-11 P005-00/ /	001-099
YA0S04+		S231T290-5016 SW-L. SIDE WINDOW	233N3212 81205	1	30-41-12 P005-00/ /	115-199
YA0S04+	1	S231T290-4016 SW-L. SIDE WINDOW	233N3212 81205	1	30-41-12 P005-00/ /	001-099
YA0S04+	2	S231T290-5016 SW-L. SIDE WINDOW	233N3212 81205	1	30-41-12 P005-00/ /	001-099
YA0S04A		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	30-41-12 P005-00/ /	ALL
YA0S04B		MS25237-387 LAMP-(INOP)	S231T290 96906	2	30-41-12 P005-00/ /	ALL
YA0S04D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	30-41-12 P005-00/ /	001-099
YA0S04D		851-30768-3823 MODULE-DIODE/FUSE	S231T290 96182	1	30-41-12 P005-00/ /	115-199
YA0S04E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	30-41-12 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YA0S00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAA++++		LRUOFM00239 MODULE-HYD AUTOBRAKE	274N1001 81205	1	32-42-12 1040/170/L046	ALL

EQUIPMENT LIST

D280N032

Section YAA+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAAS001		S271T452-3 SW-AUTOBRAKE CTRL VALVE PRESS	274N1001 81205	1	32-42-12 1040/170/L046	ALL
YAAS002		S271T452-3 SW-AUTOBRAKE SOLENOID VALVE PRESS	274N1001 81205	1	32-42-12 1040/170/L046	ALL

EQUIPMENT LIST

D280N032

Section YAAS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAAV001		10-60811-3 VALVE-AUTOBRAKE SOLENOID	274N1001 81205	1	32-42-12 1040/170/L046	ALL
YAAV002		20101461 VALVE-AUTOBRAKE PRESS CONT	274N1001 81205	1	32-42-12 1040/170/L046	ALL

EQUIPMENT LIST

D280N032

Section YAAV00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YALL013		S231T300-1111 LIGHT-STAB TRIM IND	233N3202 81205	1	27-41-11 ***/**/	ALL
YALL016		S231T300-1067 LIGHT-MACH SPEED TRIM	233N3202 81205	1	22-24-11 *** /	ALL
YALL017		S231T300-1267 LT-UNSCHED STAB	233N3202 81205	1	27-41-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YALL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAOS01A		MS25237-387 LAMP-	S231T290 96906	2	30-41-11 P005-00/ /	001-099
YAOS01B		MS24515-685AS15 LAMP-	S231T290 96906	2	30-41-11 P005-00/ /	001-099
YAOS01D		433-097-003 MODULE-DIODE/FUSE (OPT 1 SW ONLY)	S231T290 81590	1	30-41-11 P005-00/ /	001-099
YAOS01E		851-30768-3052 MODULE-DIODE/FUSE (OPT 2 SW ONLY)	S231T290 96182	1	30-41-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YAOS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
Y AQ++++		LRUOFM10397 MODULE-WING AND ENG ANTI-ICE	233N3101 81205	1	30-21-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section Y AQ+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAQL01+	1	S231T300-2115 LT-VALVE,L	233N3204 81205	1	30-11-11 P005-00/ /	ALL
YAQL01+	2	S231T300-1115 LT-VALVE,L	233N3204 81205	1	30-11-11 P005-00/ /	ALL
YAQL01A		MS25237-387 LAMP-	S231T300 96906	2	30-11-11 P005-00/ /	ALL
YAQL01D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T300 96182	1	30-11-11 P005-00/ /	ALL
YAQL01E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T300 81590	1	30-11-11 P005-00/ /	ALL
YAQL02+	1	S231T300-2115 LT-VALVE,R	233N3204 81205	1	30-11-11 P005-00/ /	ALL
YAQL02+	2	S231T300-1115 LT-VALVE,R	233N3204 81205	1	30-11-11 P005-00/ /	ALL
YAQL02A		MS25237-387 LAMP-	S231T300 96906	2	30-11-11 P005-00/ /	ALL
YAQL02D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T300 96182	1	30-11-11 P005-00/ /	ALL
YAQL02E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T300 81590	1	30-11-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YAQL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAQS01+		S231T290-5027 SW-L ENG VALVE	233N3204 81205	1	30-21-11 P005-00/ /	115-199
YAQS01+	1	S231T290-4027 SW-L ENG VALVE	233N3204 81205	1	30-21-11 P005-00/ /	001-099
YAQS01+	2	S231T290-5027 SW-L ENG VALVE	233N3204 81205	1	30-21-11 P005-00/ /	001-099
YAQS01A		MS25237-387 LAMP-(VALVE)	S231T290 96906	2	30-21-11 P005-00/ /	ALL
YAQS01B		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	30-21-11 P005-00/ /	ALL
YAQS01D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	30-21-11 P005-00/ /	001-099
YAQS01D		851-30768-3823 MODULE-DIODE/FUSE	S231T290 96182	1	30-21-11 P005-00/ /	115-199
YAQS01E		434-093-1001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	30-21-11 P005-00/ /	001-099
YAQS02+		S231T290-5027 SW-R ENG VALVE	233N3204 81205	1	30-21-11 P005-00/ /	115-199
YAQS02+	1	S231T290-4027 SW-R ENG VALVE	233N3204 81205	1	30-21-11 P005-00/ /	001-099
YAQS02+	2	S231T290-5027 SW-R ENG VALVE	233N3204 81205	1	30-21-11 P005-00/ /	001-099
YAQS02A		MS25237-387 LAMP-(VALVE)	S231T290 96906	2	30-21-11 P005-00/ /	ALL
YAQS02B		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	30-21-11 P005-00/ /	001-099
YAQS02B		MS24515-685AS15 LAMP-(ON)	S231T290 96906	0	30-21-11 P005-00/ /	115-199
YAQS02D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	30-21-11 P005-00/ /	001-099
YAQS02D		851-30768-3823 MODULE-DIODE/FUSE	S231T290 96182	1	30-21-11 P005-00/ /	115-199
YAQS02E		851-30768-3823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	30-21-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YAQS00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAQS03+		S231T290-5012 SW-WING ANTI-ICE	233N3204 81205	1	30-11-11 P005-00/ /	115-199
YAQS03+	1	S231T290-4012 SW-WING ANTI-ICE	233N3204 81205	1	30-11-11 P005-00/ /	001-099
YAQS03+	2	S231T290-5012 SW-WING ANTI-ICE	233N3204 81205	1	30-11-11 P005-00/ /	001-099
YAQS03A		MS24515-685AS15 LAMP-	S231T290 96906	2	30-11-11 P005-00/ /	001-099
YAQS03A		MS24515-685AS15 LAMP-	233N3204 96906	2	30-11-11 P005-00/ /	115-199
YAQS03D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 SW ONLY)	S231T290 81590	1	30-11-11 P005-00/ /	001-099
YAQS03D		851-30768-3823 MODULE-DIODE/FUSE	S231T290 96182	1	30-11-11 P005-00/ /	115-199
YAQS03E		434-093-001 MODULE-DIODE/FUSE (OPT 2 SW ONLY)	S231T290 96182	1	30-11-11 P005-00/ /	001-099
YAQS03E		851-30768-3052 MODULE-DIODE/FUSE (OPT 2 SW ONLY)	S231T290 96182	1	30-11-11 P005-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YAQS00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAR++++		LRUOFM00074 CTRL PNL-AILERON & RUDDER TRIM	233N6101 81205	1	27-11-11 P008-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YAR+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAZS005		MS24523-23 SW-STAB TRIM,SHUTOFF,CENTER	254N1106 96906	1	27-41-11 *** / /	ALL
YAZS006		MS24523-23 SW-STAB TRIM,SHUTOFF,RIGHT	254N1106 96906	1	27-41-21 / /	ALL

EQUIPMENT LIST

D280N032

Section YAZS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBI++++		LRUOFM00043 CTRL PNL-EMER LTS	233N3101 81205	1	33-51-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YBI+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBIL001		S231T300-1113 LT-UNARMED	233T3210 81205	1	33-51-11 P005-00/ /	ALL
YBIL01A		MS25237-387 LAMP-	S231T300 96906	2	33-51-11 M00043/ /	ALL
YBIL01D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	33-51-11 M00043/ /	ALL

EQUIPMENT LIST

D280N032

Section YBIL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBIS001		68AT34-1 SW-EMER LTS	233T3210 91929	1	33-51-11 P005-00/ /	ALL
YBIS002		S231T290-5041 SW-PASS OXY	233N3210 81205	1	35-21-11 / /	115-199
YBIS002	1	S231T290-4041-SEEYSQ—— SW-PASS OXY	233N3210 81205	1	35-21-11 P005-00/ /	001-099
YBIS002	2	S231T290-5041-SEEYSQ—— SW-PASS OXY	233N3210 81205	1	35-21-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YBIS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBM++++		AIRESEARCHSUPPLIED APU-	351T0100 99193	1	49-14-11 APU/ /	ALL

EQUIPMENT LIST

D280N032

Section YBM+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMM001		AIRESEARCHSUPPLIED UNIT-IGNITION	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMM002		AIRESEARCHSUPPLIED SOLENOID-FUEL FLOW DIVIDER	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMM003		AIRESEARCHSUPPLIED SOLENOID-DE-OILING	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMM004		AIRESEARCHSUPPLIED MOTOR-FUEL CONTROL TORQUE	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMM005		AIRESEARCHSUPPLIED MOTOR-SURGE VALVE TORQUE	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMM006		AIRESEARCHSUPPLIED ACTUATOR-IGV	351T0100 99193	1	49-14-11 APU/ /	ALL

EQUIPMENT LIST

D280N032

Section YBMM00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMS001		AIRESEARCHSUPPLIED SW-CLOGGED GENERATOR OIL FILTER	315T0100 99193	1	49-14-11 APU/ /	ALL
YBMS002		AIRESEARCHSUPPLIED SW-LOW OIL PRESSURE	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMS003		AIRESEARCHSUPPLIED SNSR-OIL LEVEL	351T0100 99193	1	49-94-11 APU/ /	001-099
YBMS003		S351N101-1 SNSR-OIL LEVEL	351T0100 81205	1	49-94-14 APU/ /	115-199
YBMS004		AIRESEARCHSUPPLIED SW-FAN VALVE POSITION	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMS005		AIRESEARCHSUPPLIED SW-OIL TEMP	351T0100 99193	1	49-14-11 APU/ /	ALL

EQUIPMENT LIST

D280N032

Section YBMS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMTS01		AIRESEARCHSUPPLIED SNSR-OIL TEMP	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMTS02		AIRESEARCHSUPPLIED SNSR-DRIVEN COMP DISCHARGE	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMTS03		AIRESEARCHSUPPLIED SNSR-DRIVEN COMP	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMTS04		AIRESEARCHSUPPLIED SNSR-COMPRESSOR INLET PRESSURE	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMTS05		AIRESEARCHSUPPLIED SNSR-COMP INLET TEMP	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMTS06		AIRESEARCHSUPPLIED SNSR-THERMOCOUPLE ASSEMBLY 1	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMTS07		AIRESEARCHSUPPLIED SNSR-THERMOCOUPLE ASSEMBLY 2	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMTS08		AIRESEARCHSUPPLIED SNSR-MONOPOLE 1	351T0100 99193	1	49-14-11 APU/ /	ALL
YBMTS09		AIRESEARCHSUPPLIED SNSR-MONOPOLE 2	351T0100 99193	1	49-14-11 APU/ /	ALL

EQUIPMENT LIST

D280N032

Section YBMT
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMV001		AIRESEARCHSUPPLIED VALVE-FUEL SOLENOID	351T0100 99193	1	49-14-11 APU/ /	ALL

EQUIPMENT LIST

D280N032

Section YBMV00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNBL1M1		387 LAMP-	S417N101 08805	1	24-41-11 0338/209/L020	001-099

EQUIPMENT LIST

D280N032

Section YNBL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNE++++		LRUOFM10394 PNL-AUXILIARY ANNUNCIATOR	233N3202 81205	1	52-71-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNE+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNEL014		S231T300-1110 LT-SPOILERS	233N3202 81205	1	27-61-12 P005-00/ /	ALL
YNEL015		S231T300-1012 LT-AUTOSPEED BRAKE	233N3202 81205	1	27-62-11 P005-00/ /	ALL
YNEL018		S231T300-1105 LT-RUDDER RATIO	233N3202 81205	1	27-21-12 P005-00/ /	ALL
YNEL019		S231T300-1212 LT-ANTI-SKID	233N3101 81205	1	32-42-11 P005-00/ /	ALL
YNEL01+		S231T300-244 LIGHT-ENTRY DOORS	233N3202 81205	1	52-71-11 P005-00/ /	ALL
YNEL01A		MS25237-387 LAMP-	S231T300 96906	2	52-71-11 P005-00/ /	ALL
YNEL01D		434-093-003 MODULE-DIODE/FUSE	S231T300 81205	1	52-71-11 P005-00/ /	ALL
YNEL02+		S231T300-245 LIGHT-EMER DOORS	233N3202 81205	1	52-71-11 P005-00/ /	ALL
YNEL02A		MS25237-387 LAMP-	S231T300 96906	2	52-71-11 P005-00/ /	ALL
YNEL02D		434-093-003 MODULE-DIODE/FUSE	S231T300 81205	1	52-71-11 P005-00/ /	ALL
YNEL03+		S231T300-246 LIGHT-CARGO DOORS	233N3202 81205	1	52-71-11 P005-00/ /	ALL
YNEL03A		MS25237-387 LAMP-	S231T300 81205	2	52-71-11 P005-00/ /	ALL
YNEL03D		434-093-003 MODULE-DIODE/FUSE	S231T300 81205	1	52-71-11 P005-00/ /	ALL
YNEL04+		S231T300-247 LIGHT-ACCESS DOORS	233N3202 81205	1	52-71-11 P005-00/ /	ALL
YNEL04A		MS25237-387 LAMP-	S231T300 96906	2	52-71-11 P005-00/ /	ALL
YNEL04D		434-093-003 MODULE-DIODE/FUSE	S231T300 81205	1	52-71-11 P005-00/ /	ALL
YNEL05+	1	S231T300-2259 LT-CAPT'S PITOT	233N3202 81205	1	30-31-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNEL00

Page 1

Oct 09/2008

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNEL05+	2	S231T300-1259 LT-CAPT'S PITOT	233N3202 81205	1	30-31-11 P005-00/ /	ALL
YNEL05A		MS25237-387 LAMP-	S231T300 96906	2	30-31-11 P005-00/ /	ALL
YNEL05D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	30-31-11 P005-00/ /	ALL
YNEL06+	1	S231T300-2260 LT-F/O'S PITOT	S231T300 81205	1	30-31-11 P005-00/ /	ALL
YNEL06+	2	S231T300-1260 LT-F/O'S PITOT	S231T300 81205	1	30-31-11 P005-00/ /	ALL
YNEL06A		MS25237-387 LAMP-	S231T300 96906	2	30-31-11 P005-00/ /	ALL
YNEL06D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	30-31-11 P005-00/ /	ALL
YNEL07+	1	S231T300-2202 LT-L ANGLE OF ATTACK	233N3202 81205	1	30-32-11 P005-00/ /	ALL
YNEL07+	2	S231T300-1202 LT-L ANGLE OF ATTACK	233N3202 81205	1	30-32-11 P005-00/ /	ALL
YNEL07A		MS25237-387 LAMP-	S231T300 96906	2	30-32-11 P005-00/ /	ALL
YNEL07D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	30-32-11 P005-00/ /	ALL
YNEL08+	1	S231T300-2203 LT-R ANGLE OF ATTACK	233N3202 81205	1	30-32-11 P005-00/ /	ALL
YNEL08+	2	S231T300-1203 LT-R ANGLE OF ATTACK	233N3202 81205	1	30-32-11 P005-00/ /	ALL
YNEL08A		MS25237-387 LAMP-	S231T300 96906	2	30-32-11 P005-00/ /	ALL
YNEL08D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	30-32-11 P005-00/ /	ALL
YNEL09+	1	S231T300-2261 LT-L AUX PITOT	233N3202 81205	1	30-31-12 P005-00/ /	ALL
YNEL09+	2	S231T300-1261 LT-L AUX PITOT	233N3202 81205	1	30-31-12 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNEL00

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNEL09A		MS25237-387 LAMP-	S231T300 96906	2	30-31-12 P005-00/ /	ALL
YNEL09D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	30-31-12 P005-00/ /	ALL
YNEL10+	1	S231T300-2262 LT-R AUX PITOT	233N3202 81205	1	30-31-12 P005-00/ /	ALL
YNEL10+	2	S231T300-1262 LT-R AUX PITOT	233N3202 81205	1	30-31-12 P005-00/ /	ALL
YNEL10A		MS25237-387 LAMP-	S231T300 96906	2	30-31-12 P005-00/ /	ALL
YNEL10D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	30-31-12 P005-00/ /	ALL
YNEL11+	1	S231T300-2112 LT-TOTAL AIR TEMP	233N3202 81205	1	30-33-11 P005-00/ /	ALL
YNEL11+	2	S231T300-1112 LT-TOTAL AIR TEMP	233N3202 81205	1	30-33-11 P005-00/ /	ALL
YNEL11A		MS25237-387 LAMP-	S231T300 96906	2	30-33-11 P005-00/ /	ALL
YNEL11D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	30-33-11 P005-00/ /	ALL
YNEL19A		MS25237-387 LAMP-	233N3102 96906	2	32-42-11 P005-00/ /	ALL
YNEL19D		433-097-003 MODULE-DIODE/FUSE	233N3102 81590	1	32-42-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNEL00
Page 3 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNM++++		LRUOFM100067 MODULE-E/E COOLING	233N3203 81205	1	21-58-12 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNM+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNML003		S231T300-274 LAMP-CABIN ALTITUDE WARNING	233N3101 81205	1	21-33-12 P005-00/ /	115-199
YNML01+	1	S231T300-2108 LIGHT-SMOKE INDICATION	233N3203 81205	1	21-58-12 P005-00/ /	ALL
YNML01+	2	S231T300-1108 LIGHT-SMOKE INDICATION	233N3203 81205	1	21-58-12 P005-00/ /	ALL
YNML01A		MS25237-387 LAMP	S231T300 96906	2	21-58-12 P005-00/ /	ALL
YNML01D	1	851-30768-3823 MODULE DIODE/FUSE (OPT 1 ONLY)	S231T300 96182	1	21-58-12 P005-00/ /	ALL
YNML01D	2	434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T300 81590	1	21-58-12 P005-00/ /	ALL
YNML02+	1	S231T300-2274 LIGHT-CABIN ALTITUDE	233N3203 81205	1	21-33-12 P005-00/ /	ALL
YNML02+	2	S231T300-1274 LIGHT-CABIN ALTITUDE	233N3203 81205	1	21-33-12 P005-00/ /	ALL
YNML02A		MS25237-387 LAMP-	S231T300 96906	2	21-58-11 P005-00/ /	ALL
YNML02D	1	851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T300 96182	1	21-58-12 P005-00/ /	ALL
YNML02D	2	434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T300 81590	1	21-58-12 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNML00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNMS01+		S231T290-5080 SW-EQUIP COOL,ALT/OVHT	233N3203 81205	1	21-58-12 P005-00/ /	115-199
YNMS01+	1	S231T290-4080 SW-EQUIP COOL,ALT/OVHT	233N3202 81205	1	21-58-12 P005-00/ /	001-099
YNMS01+	2	S231T290-5080 SW-EQUIP COOL,ALT/OVHT	233N3202 81205	1	21-58-12 P005-00/ /	001-099
YNMS01A		MS25237-387 LAMP (OVHT)	S231T290 96906	2	21-58-12 P005-00/ /	ALL
YNMS01B		MS24515-685AS15 LAMP (OVHT)	S231T290 96906	2	21-58-12 P005-00/ /	ALL
YNMS01D		433-097-003 MODULE-DIODE/FUSE (OPT 1 SW ONLY)	S231T290 81590	1	21-58-12 P005-00/ /	001-099
YNMS01D		851-30768-823 MODULE-DIODE/FUSE	S231T290 96182	1	21-58-12 P005-00/ /	115-199
YNMS01E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 SW ONLY)	S231T290 96182	1	21-58-12 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNMS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNNL003		S231T300-273 LT-L BLEED	233N3101 81205	1	36-22-11 P005-00/ /	ALL
YNNL004		S231T300-273 LT-R BLEED	233N3101 81205	1	36-22-11 P005-00/ /	ALL
YNNL03+	1	S231T300-2273 LT-L ENG BLEED SUPPLY OVERHEAT	233N3215 81205	1	36-22-11 P005-00/ /	ALL
YNNL03+	2	S231T300-1273 LT-L ENG BLEED SUPPLY OVERHEAT	233N3215 81205	1	36-22-11 P005-00/ /	ALL
YNNL03A		MS2537-387 LAMP-	S231T300 96906	2	36-22-11 P005-00/ /	ALL
YNNL03D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T300 96182	1	36-22-11 P005-00/ /	ALL
YNNL03E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T300 81590	1	36-22-11 P005-00/ /	ALL
YNNL04+	1	S231T300-2273 LT-R ENG BLEED SUPPLY OVERHEAT	233N3215 81205	1	36-22-11 P005-00/ /	ALL
YNNL04+	2	S231T300-1273 LT-R ENG BLEED SUPPLY OVERHEAT	233N3215 81205	1	36-22-11 P005-00/ /	ALL
YNNL04A		MS2537-387 LAMP-	S231T300 96906	2	36-22-11 P005-00/ /	ALL
YNNL04D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T300 96182	1	36-22-11 P005-00/ /	ALL
YNNL04E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T300 81590	1	36-22-11 P005-00/ /	ALL
YNNL05+	1	S231T300-2051 LT-L HIGH STAGE	233N3215 81205	1	36-11-12 P005-00/ /	ALL
YNNL05+	2	S231T300-1051 LT-L HIGH STAGE	233N3215 81205	1	36-11-12 P005-00/ /	ALL
YNNL05A		MS25237-387 LAMP-	S231T300 96906	2	36-11-12 P005-00/ /	ALL
YNNL05D		851-30768-3825 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T300 96182	1	36-11-12 P005-00/ /	ALL
YNNL05E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T300 81590	1	36-11-12 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNNL00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNNL06+	1	S231T300-2051 LT-R HIGH STAGE	233N3215 81205	1	36-11-22 P005-00/ /	ALL
YNNL06+	2	S231T300-1051 LT-R HIGH STAGE	233N3215 81205	1	36-11-22 P005-00/ /	ALL
YNNL06A		MS25237-387 LAMP-	S231T300 96906	2	36-11-22 P005-00/ /	ALL
YNNL06D		851-30768-3823 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T300 96182	1	36-11-22 P005-00/ /	ALL
YNNL06E		434-093-001 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T300 81590	1	36-11-22 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNNL00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNNN001		231T245-3 IND-DUCT PRESSURE,AIR SUPPLY DUAL	233N3101 81205	1	36-21-11 P005-00/ /	001-099
YNNN001		231T245-2 IND-DUCT PRESSURE,AIR SUPPLY DUAL	233N3101 81205	1	36-21-11 P005-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YNNN00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNNS01+		S231T290-5030 SW-L ENG BLEED AIR SUPPLY	233N3215 81205	1	36-11-11 P005-00/ /	115-199
YNNS01+	1	S231T290-4030 SW-L ENG BLEED AIR SUPPLY	233N3215 81205	1	36-11-11 P005-00/ /	001-099
YNNS01+	2	S231T290-5030 SW-L ENG BLEED AIR SUPPLY	233N3215 81205	1	36-11-11 P005-00/ /	001-099
YNNS01A		MS25237-387 LAMP-(OFF)	S231T290 96906	2	36-11-11 P005-00/ /	ALL
YNNS01B		MS24515-685AS15 LAMP-(BAR)	S231T290 96906	2	36-11-11 P005-00/ /	ALL
YNNS01D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	36-11-11 P005-00/ /	001-099
YNNS01E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	36-11-11 P005-00/ /	001-099
YNNS02+		S231T290-5067 SW-APU AIR SUPPLY	233N3215 81205	1	36-11-41 P005-00/ /	115-199
YNNS02+	1	S231T290-4067 SW-APU AIR SUPPLY	233N3215 81590	1	36-11-41 P005-00/ /	001-099
YNNS02+	2	S231T290-5067 SW-APU AIR SUPPLY	233N3215 96182	1	36-11-41 P005-00/ /	001-099
YNNS02A		MS25237-387 LAMP-(VALVE)	S231T290 96906	2	36-11-41 P005-00/ /	ALL
YNNS02B		MS24515-685AS15 LAMP-(BAR)	S231T290 96906	2	36-11-41 P005-00/ /	ALL
YNNS02D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	36-11-41 P005-00/ /	001-099
YNNS02D		851-30768-823 MODULE-DIODE/FUSE	S231T290 96182	1	36-11-41 P005-00/ /	115-199
YNNS02E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	36-11-41 P005-00/ /	001-099
YNNS03+		S231T290-5038 SW-ISOLATION VALVE	233N3215 81205	1	36-11-31 P005-00/ /	115-199
YNNS03+	1	S231T290-4038 SW-ISOLATION VALVE	233N3215 81205	1	36-11-31 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YNNS00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNNS03+	2	S231T290-5038 SW-ISOLATION VALVE	233N3215 81205	1	36-11-31 P005-00/ /	001-099
YNNS03A		MS25237-387 LAMP-(VALVE)	S231T290 96906	2	36-11-31 P005-00/ /	001-099
YNNS03A		MS25237-387 LAMP-(VALVE)	233N3215 96906	2	36-11-31 P005-00/ /	115-199
YNNS03B		MS24515-68AS15 LAMP-(BAR)	S231T290 96906	2	36-11-31 P005-00/ /	001-099
YNNS03B		MS24515-685AS15 LAMP-(BAR)	233N3215 96906	2	36-11-31 P005-00/ /	115-199
YNNS03D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	36-11-31 P005-00/ /	001-099
YNNS03D		851-30768-823 MODULE-DIODE/FUSE	S231T290 96182	1	36-11-31 P005-00/ /	115-199
YNNS03E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	36-11-31 P005-00/ /	001-099
YNNS04+		S231T290-5013 SW-R ENG BLEED AIR SUPPLY	233N3215 81205	1	36-11-21 P005-00/ /	115-199
YNNS04+	1	S231T290-4013 SW-R ENG BLEED AIR SUPPLY	233N3215 81205	1	36-11-21 P005-00/ /	001-099
YNNS04+	2	S231T290-5013 SW-R ENG BLEED AIR SUPPLY	233N3215 81205	1	36-11-21 P005-00/ /	001-099
YNNS04A		MS25237-387 LAMP-(OFF)	S231T290 96906	2	36-11-21 P005-00/ /	ALL
YNNS04B		MS24515-685AS15 LAMP-(BAR)	S231T290 96906	2	36-11-21 P005-00/ /	ALL
YNNS04D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	36-11-21 P005-00/ /	001-099
YNNS04D		851-30768-823 MODULE-DIODE/FUSE	S231T290 96182	1	36-11-21 P005-00/ /	115-199
YNNS04E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	36-11-21 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YNNS00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNP++++		LRUOFM10078 MODULE-COMPARTMENT TEMP	233N3101 81205	1	21-65-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNP+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNQ++++		LRUOFM00052 CONT PNL-PASS SIGN	233N3101 81205	1	33-24-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNQ+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNQCR01		JANTXIN5618 DIODE-BLOCKING,NSFSB SIGN	233T3216 09922	1	33-24-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNQC
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNQS001		AC45-0008-1 SW-PASS SIGNS,SEATBELTS	233T3216 91812	1	33-24-11 P005-00/ /	ALL
YNQS002		AC45-0009-1 SW-PASS SIGNS,NO SMOKING	233T3216 91812	1	33-24-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNQS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNR++++		LRUOFM10193 MODULE-AIR CONDITIONING CONTROL	233N3101 81205	1	21-25-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNR+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNRL01+	1	S231T300-2238 LIGHT-FLIGHT DECK	233N3217 81205	1	21-61-11 P005-00/ /	ALL
YNRL01+	2	S231T300-1238 LIGHT-FLIGHT DECK	233N3217 81205	1	21-61-11 P005-00/ /	ALL
YNRL01A		MS25237-387 LAMP-	S231T300 96906	2	21-61-11 P005-00/ /	ALL
YNRL01D		851-30768-3823 DIODE/FUSE MODULE (OPT 1 ONLY)	S231T300 96182	1	21-61-11 P005-00/ /	ALL
YNRL01E		434-093-001 DIODE/FUSE MODULE (OPT 2 ONLY)	S231T300 81590	1	21-61-11 P005-00/ /	ALL
YNRL02+	1	S231T300-2238 LIGHT-FWD CAB	233N3217 81205	1	21-61-21 P005-00/ /	ALL
YNRL02+	2	S231T300-1238 LIGHT-FWD CAB	233N3217 81205	1	21-61-21 P005-00/ /	ALL
YNRL02A		MS25237-387 LAMP	S231T300 96906	2	21-61-21 P005-00/ /	ALL
YNRL02D		851-30768-3823 DIODE/FUSE MODULE (OPT 1 ONLY)	S231T300 96182	1	21-61-21 P005-00/ /	ALL
YNRL02E		434-093-001 DIODE/FUSE MODULE (OPT 2 ONLY)	S231T300 81590	1	21-61-21 P005-00/ /	ALL
YNRL03+	1	S231T300-2238 LIGHT- AFT CAB	233N3217 81205	1	21-61-31 P005-00/ /	ALL
YNRL03+	2	S231T300-1238 LIGHT- AFT CAB	233N3217 81205	1	21-61-31 P005-00/ /	ALL
YNRL03A		MS25237-387 LAMP-	S231T300 96906	2	21-61-31 P005-00/ /	ALL
YNRL03D		851-30768-3053 DIODE/FUSE MODULE (OPT 1 ONLY)	S231T300 96182	1	21-61-31 P005-00/ /	ALL
YNRL03E		434-093-001 DIODE/FUSE MODULE (OPT 2 ONLY)	S231T300 81590	1	21-61-31 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YNRL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNRS006		S210T130-24 SELECTOR-ZONE TEMP,FLT DK	233N3101 81205	1	21-61-11 P005-00/ /	ALL
YNRS007		S210T130-24 SELECTOR-ZONE TEMP,FWD	233N7401 81205	1	21-61-21 P061-00/ /	ALL
YNRS008		S210T130-24 SELECTOR-ZONE TEMP,AFT	233N3101 81205	1	21-61-31 P061-00/ /	ALL
YNRS009		AC45-0022-2 SELECTOR-PACK,LEFT	233N3217 91812	1	21-51-11 P005-00/ /	ALL
YNRS010		AC45-0022-22 SELECTOR-PACK,RIGHT	233N3217 91812	1	21-51-21 P005-00/ /	ALL
YNRS01+		S231T290-5016 SW-FAN,RECIRC,L	233N3217 81205	1	21-25-11 P005-00/ /	115-199
YNRS01+	1	S231T290-4016 SW-FAN,RECIRC,L	233N3217 81205	1	21-25-11 P005-00/ /	001-099
YNRS01+	2	S231T290-5016 SW-FAN,RECIRC,L	233N3217 81205	1	21-25-11 P005-00/ /	001-099
YNRS01A		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	21-25-11 P005-00/ /	ALL
YNRS01B		MS25237-387 LAMP-(INOP)	S231T290 96906	2	21-25-11 P005-00/ /	ALL
YNRS01D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	21-25-11 P005-00/ /	001-099
YNRS01D		851-30768-823 MODULE-DIODE/FUSE	S231T290 96182	1	21-25-11 P005-00/ /	115-199
YNRS01E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	21-25-11 P005-00/ /	001-099
YNRS02+		S231T290-5016 SW-FAN,RECIRC,R	233N3217 81205	1	21-25-11 P005-00/ /	115-199
YNRS02+	1	S231T290-4016 SW-FAN,RECIRC,R	233N3217 81205	1	21-25-11 P005-00/ /	001-099
YNRS02+	2	S231T290-5016 SW-FAN,RECIRC,R	233N3217 81205	1	21-25-11 P005-00/ /	001-099
YNRS02A		MS24515-685AS15 LAMP-(ON)	S231T290 96906	1	21-25-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YNRS00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNRS02A		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	21-25-11 P005-00/ /	115-199
YNRS02B		MS25237-387 LAMP-(INOP)	S231T290 96906	1	21-25-11 P005-00/ /	001-099
YNRS02B		MS25237-387 LAMP-(INOP)	S231T290 96906	2	21-25-11 P005-00/ /	115-199
YNRS02D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	21-25-11 P005-00/ /	001-099
YNRS02D		851-30768-823 DIODE/FUSE MODULE	S231T290 96182	1	21-25-11 P005-00/ /	115-199
YNRS02E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	21-25-11 P005-00/ /	001-099
YNRS03+		S231T290-5024 SW-TRIM AIR	233N3217 81205	1	21-61-51 P005-00/ /	115-199
YNRS03+	1	S231T290-4024 SW-TRIM AIR	233N3217 81205	1	21-61-51 P005-00/ /	001-099
YNRS03+	2	S231T290-5024 SW-TRIM AIR	233N3217 81205	1	21-61-51 P005-00/ /	001-099
YNRS03A		MS24515-685AS15 LAMP-(ON)	S231T290 96906	2	21-61-51 P005-00/ /	ALL
YNRS03B		MS25237-387 LAMP-(OFF)	S231T290 96906	2	21-61-51 P005-00/ /	ALL
YNRS03D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	21-61-51 P005-00/ /	001-099
YNRS03D		851-30768-823 DIODE/FUSE MODULE	S231T290 96182	1	21-61-51 P005-00/ /	115-199
YNRS03E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	21-61-51 P005-00/ /	001-099
YNRS04+		S231T290-5056 SW-PACK RESET,L	233N3217 80205	1	21-51-15 P005-00/ /	115-199
YNRS04+	1	S231T290-4056 SW-PACK RESET,L	233N3217 81205	1	21-51-15 P005-00/ /	001-099
YNRS04+	2	S231T290-5056 SW-PACK RESET,L	233N3217 81205	1	21-51-15 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YNRS00

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNRS04A		MS25237-387 LAMP-(INOP)	S231T290 96906	2	21-51-15 P005-00/ /	ALL
YNRS04B		MS25237-387 LAMP-(PACK OFF)	S231T290 96906	2	21-51-15 P005-00/ /	ALL
YNRS04D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	21-51-15 P005-00/ /	001-099
YNRS04D		851-30768-823 DIODE/FUSE MODULE	S231T290 96182	1	21-51-15 P005-00/ /	115-199
YNRS04E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	21-51-15 P005-00/ /	001-099
YNRS05+		S231T290-5056 SW-PACK RESET,R	233N3217 81205	1	21-51-25 P005-00/ /	115-199
YNRS05+	1	S231T290-4056 SW-PACK RESET,R	233N3217 81205	1	21-51-25 P005-00/ /	001-099
YNRS05+	2	S231T290-5056 SW-PACK RESET,R	233N3217 81205	1	21-51-25 P005-00/ /	001-099
YNRS05A		MS25237-387 LAMP-(INOP)	S231T290 96906	2	21-51-25 P005-00/ /	ALL
YNRS05B		MS25237-387 LAMP-(PACK OFF)	S231T290 96906	2	21-51-25 P005-00/ /	ALL
YNRS05D		433-097-003 MODULE-DIODE/FUSE (OPT 1 ONLY)	S231T290 81590	1	21-51-25 P005-00/ /	001-099
YNRS05D		851-30768-823 DIODE/FUSE MODULE	S231T290 96182	1	21-51-25 P005-00/ /	115-199
YNRS05E		851-30768-823 MODULE-DIODE/FUSE (OPT 2 ONLY)	S231T290 96182	1	21-51-25 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YNRS00

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNW++++		LRUOFM10316 FLUO LAMP/BALLAST ASSY	417N5120 81205	0	33-21-12 / /	001-099
YNW++++		LRUOFM10316 FLUO LAMP ASSY	417N5120 81205	0	33-21-12 / /	115-199

EQUIPMENT LIST

D280N032

Section YNW+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNWB001		S283N702-103 BALLAST-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNWB00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNWD001		BACC63BN12-12S7 PLUG-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-12 / /	001-099
YNWD001		BACC63BN12-12S7 RCPT-FLUO BALLAST ASSY	417N5120 81205	1	33-21-12 / /	115-199
YNWD002		BACC45FN12-12P RCPT-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNWD00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNWL001		F40D30 LAMP-FLUO LAMP/BALLAST ASSY	417N5120 08805	1	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNWL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNX++++		LRUOFM10317 FLUO LAMP ASSY-	417N5120 81205	0	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNX+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNXD001		BACC45FN12-12P RCPT-FLUO LAMP ASSY	417N5120 81205	1	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNXD00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNXL001		F40D30 LAMP-FLUO LAMP ASSY	417N5120 08805	1	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNXL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNY++++		LRUOFM10318 FLUO LAMP/BALLAST ASSY	417N5120 81205	0	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNY+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNYB001		S283N702-107 BALLAST-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNYB00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNYD001		BACC63BN12-12S9 PLUG-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-12 / /	ALL
YNYD002		BACC45FN12-12P RCPT-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YNYD00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNYL001		F15T8WW LAMP-FLUO LAMP/BALLAST ASSY	417N5120 08805	1	33-21-12 / /	001-099
YNYL001		F15T8WW LAMP-FLUO LAMP ASSY	417N5120 08805	1	33-21-12 / /	115-199

EQUIPMENT LIST

D280N032

Section YNYL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNZ++++		LRUOFM10319 FLUO LAMP/BALLAST ASSY-	417N5120 81205	0	33-21-14 / /	ALL

EQUIPMENT LIST

D280N032

Section YNZ+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNZB001		S283N702-104 BALLAST-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-14 / /	ALL

EQUIPMENT LIST

D280N032

Section YNZB00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNZD001		BACC63BN12-12S7 PLUG-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-14 / /	ALL
YNZD002		BACC45FN12-12P RCPT-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-14 / /	ALL

EQUIPMENT LIST

D280N032

Section YNZD00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YNZL001		F40D30 LAMP-FLUO LAMP/BALLAST ASSY	417N5120 08805	1	33-21-14 / /	ALL

EQUIPMENT LIST

D280N032

Section YNZL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPF++++		LRUOFM00901 MODULE-HEATER CAPT AUX	233N7101 81205	1	21-45-11 P013-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YPF+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPFS001		102TL2-12A SW-SHOULDER HEATER,CAPT	233N7101 91929	1	21-45-11 P013-00/ /	ALL
YPFS002		102TL2-12A SW-FOOT HEATER,CAPT	233N7101 91929	1	21-45-11 P013-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YPFS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPG++++		LRUOFM00902 MODULE-HEATER F/O AUX	233N7101 81205	1	21-45-11 P014-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YPG+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPGS001		102TL2-12A SW-SHOULDER HEATER,F/O	233N7101 91929	1	21-45-11 P014-00/ /	ALL
YPGS002		102TL2-12A SW-FOOT HEATER,F/O	233N7101 91929	1	21-45-11 P014-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YPGS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPH++++		LRUOFM10398 MODULE-TEST PNL	233N7501 81205	1	22-21-11 ****/**/	ALL

EQUIPMENT LIST

D280N032

Section YPH+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPHS001		BACS30EM44 SW-STALL TEST LEFT	233N7501 81205	1	27-32-11 P061-00/ /	ALL
YPHS002		BACS30EM44 SW-STALL TEST RIGHT	233N7501 81205	1	27-32-21 P061-00/ /	ALL
YPHS003		BACS30EM44 SW-TAKE-OFF/LANDING CONFIGURATION	233N7501 81205	1	31-51-42 P061-00/ /	ALL
YPHS005		BACS30ES44 SW-WING ANTI-ICE & WINDOW/PROBE HEAT	233N7401 81205	1	30-11-11 P061-00/ /	ALL
YPHS006		BACS30EM44 SW-DUCT LEAK/FUEL QTY	233N7501 81205	1	26-18-11 P061-00/ /	ALL
YPHS007		BACS30EM44 SW-YAW DAMPER TEST	233N7501 81205	1	22-21-11 P061-00/ /	ALL
YPHS008		BACS30ES44 SW-SMOKE/LOW FLOW TEST F&A EQ COOL	233N7501 81205	1	21-58-12 P061-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YPHS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPJ++++		LRUOFM10250 PNL-YAW DAMPER	233N3101 81205	1	22-21-11 *** / /	ALL

EQUIPMENT LIST

D280N032

Section YPJ+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPJS001	5	S231T290-1016 SW-YAW DAMPER INOP LIGHT,LEFT	233N3216 81205	1	22-21-11 P005-00/ /	ALL
YPJS001	1	S231T290-5016 SW-YAW DAMPER INOP LIGHT,LEFT	233N3216 81205	1	22-21-11 P005-00/ /	ALL
YPJS001	2	S231T290-4016 SW-YAW DAMPER INOP LIGHT,LEFT	233N3216 81205	1	22-21-11 P005-00/ /	ALL
YPJS001	3	S231T290-3016 SW-YAW DAMPER INOP LIGHT,LEFT	233N3216 81205	1	22-21-11 P005-00/ /	ALL
YPJS001	4	S231T290-2016 SW-YAW DAMPER INOP LIGHT,LEFT	233N3216 81205	1	22-21-11 P005-00/ /	ALL
YPJS002	5	S231T290-1016 SW-YAW DAMPER INOP LIGHT,RIGHT	233N3216 81205	1	22-21-21 P005-00/ /	ALL
YPJS002	1	S231T290-5016 SW-YAW DAMPER INOP LIGHT,RIGHT	233N3216 81205	1	22-21-21 P005-00/ /	ALL
YPJS002	2	S231T290-4016 SW-YAW DAMPER INOP LIGHT,RIGHT	233N3216 81205	1	22-21-21 P005-00/ /	ALL
YPJS002	3	S231T290-3016 SW-YAW DAMPER INOP LIGHT,RIGHT	233N3216 81205	1	22-21-21 P005-00/ /	ALL
YPJS002	4	S231T290-2016 SW-YAW DAMPER INOP LIGHT,RIGHT	233N3216 81205	1	22-21-21 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YPJS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPP++++		LRUOFM10023 CONT PNL-RAIN REPEL & WSHLD WIPER	233N3201 81205	1	30-42-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YPP+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPPS001		S232T601-58 SW-WIPER	233N3201 81205	1	30-42-11 P005-00/ /	ALL
YPPS002		D20011B-01GUB SW-RAIN REPELLENT,L	233N3201 21649	1	30-42-11 P005-00/ /	ALL
YPPS003		D20011B-01GUB SW-RAIN REPELLENT,R	233N3201 21649	1	30-42-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YPPS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPQS001		S271T452-10 SW-PRESSURE	251N402 81205	1	27-51-31 RS/191/L020	ALL

EQUIPMENT LIST

D280N032

Section YPQS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPQV001		10-60811-3 VALVE-SOLENOID	251N402 81205	1	27-51-31 RS/191/L020	ALL

EQUIPMENT LIST

D280N032

Section YPQV00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPR++++		LRUOFM10336 FLUO BALLAST/NIGHT LAMP ASSY-	417N5120 81205	0	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YPR+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPRB001		S283N702-103 BALLAST-FLUO BALLAST/NIGHT LAMP ASSY	417N5120 81205	1	33-21-12 / /	001-099
YPRB001		S283N702-103 BALLAST-FLUO LAMP ASSY	417N5120 81205	1	33-21-12 / /	115-199

EQUIPMENT LIST

D280N032

Section YPRB00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPRD001		BACC63BN12-12S7 PLUG-FLUO BALLAST/NIGHT LAMP ASSY	417N5120 81205	1	33-21-12 / /	001-099
YPRD001		BACC63BN12-12S7 RCPT-FLUO BALLAST LAMP ASSY	417N5120 81205	1	33-21-12 / /	115-199
YPRD002		BACC45FN12-12P RCPT-FLUO BALLAST/NIGHT LAMP ASSY	417N5120 81205	1	33-21-12 / /	ALL

EQUIPMENT LIST

D280N032

Section YPRD00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YPRL001		F40D30 LAMP-FLUO BALLAST/NIGHT LAMP ASSY	417N5120 08805	1	33-21-12 / /	001-099
YPRL001		F40D30 LAMP-FLUO LAMP ASSY	417N5120 08805	1	33-21-12 / /	115-199
YPRL002		1864 LAMP-NIGHT LTS	417N5120 08806	1	33-21-12 / /	001-099
YPRL002		GE1864 LAMP-NIGHT LTS	417N5120 08806	1	33-21-12 / /	115-199

EQUIPMENT LIST

D280N032

Section YPRL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQG++++		LRUOFM10376 FLUO LAMP ASSY-	417N5120 81205	0	33-21-22 / /	ALL

EQUIPMENT LIST

D280N032

Section YQG+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQGD001		BACC45FN12-12P RCPT-FLUO LAMP ASSY	417N5120 81205	1	33-21-22 / /	ALL

EQUIPMENT LIST

D280N032

Section YQGD00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQGL001		F40D30 LAMP-FLUO LAMP ASSY	417N5120 08805	1	33-21-22 / /	ALL

EQUIPMENT LIST

D280N032

Section YQGL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQH++++		LRUOFM10377 FLUO LAMP BALLAST ASSY-	417N5120 81205	0	33-21-23 / /	115-199

EQUIPMENT LIST

D280N032

Section YQH+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQHB001		S283N702-104 BALLAST-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-23 / /	ALL

EQUIPMENT LIST

D280N032

Section YQHB00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQHD001		BACC63BN12-12S7 RCPT-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-23 / /	ALL
YQHD002		BACC45FN12-12P RCPT-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-23 / /	ALL

EQUIPMENT LIST

D280N032

Section YQHD00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQHL001		F40WW LAMP-FLUO LAMP/BALLAST ASSY	417N5120 08805	1	33-21-23 / /	ALL

EQUIPMENT LIST

D280N032

Section YQHL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQK++++		LRUOFM10315 FLUO LAMP/BALLAST ASSY	417N5120 81205	0	33-21-21 / /	001-099
YQK++++		LRUOFM10315-PROVISIONS- FLUO LAMP/BALLAST ASSY	417N5120 81205	0	33-21-21 / /	115-199

EQUIPMENT LIST

D280N032

Section YQK+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQKB001		S283N702-104 BALLAST-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-21 / /	001-099
YQKB001		S283N702-104-PROVISIONS- BALLAST-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-21 / /	115-199

EQUIPMENT LIST

D280N032

Section YQKB00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQKD001		BACC63BN12-12S7-PROVISIONS- PLUG-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-21 / /	115-199
YQKD002		BACC45FN12-12P RCPT-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-21 / /	001-099
YQKD002		BACC45FN12-12P-PROVISIONS- RCPT-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-21 / /	115-199

EQUIPMENT LIST

D280N032

Section YQKD00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQKL001		F40D30 LAMP-FLUO LAMP/BALLAST ASSY	417N5120 08805	1	33-21-21 / /	001-099
YQKL001		F40WW-PROVISIONS- LAMP-FLUO LAMP/BALLAST ASSY	417N5120 08805	1	33-21-21 / /	115-199

EQUIPMENT LIST

D280N032

Section YQKL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQL++++		LRUOFM10324 PNL-APU START	233N3222 81205	1	49-61-11 P005-00/* /	115-199

EQUIPMENT LIST

D280N032

Section YQL+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQLL01+	1	S231T300-2122 LT-RUN	233N3222 81205	1	49-61-11 P005-00/ /	115-199
YQLL01+	2	S231T300-1122 LT-RUN	233N3222 81205	1	49-61-11 P005-00/ /	115-199
YQLL01A		MS25237-387 LAMP-	S231T300 96906	2	49-61-11 P005-00/ /	115-199
YQLL01B		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	49-61-11 P005-00/ /	115-199
YQLL02+	1	S231T300-2036 LT-APU FAULT	233N3222 81205	0	49-61-11 P005-00/*/	115-199
YQLL02+	2	S231T300-1036 LT-APU FAULT	233N3222 81205	0	49-61-11 P005-00/*/	115-199
YQLL02A		MS25237-387 LAMP-	S231T300 96906	2	49-61-11 P005-00/ /	115-199
YQLL02B		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	49-61-11 P005-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YQLL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQLS001		AC45-0003-2 SW-APU START	233N3222 91812	1	49-61-11 P005-00/* /	115-199

EQUIPMENT LIST

D280N032

Section YQLS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQM++++		LRUOFM10401 PANEL-SQUIB TEST	233N7401 81205	0	26-21-11 P061-00/* /	ALL

EQUIPMENT LIST

D280N032

Section YQM+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQMK001		BACR13CE2 RELAY-ENG SQUIB TEST	233N7401 81205	1	26-21-11 P061-00/* /	ALL
YQMK002		BACR13CE2 RELAY-CARGO SQUIB TEST	233N7401 81205	1	26-23-11 P061-00/* /	ALL
YQMK003		BACR13CE2 RELAY-APU SQUIB TEST	233N7401 81205	1	26-22-21 P061-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQMK00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQML001		116-565-1042-001 LT-L ENG 1	233N7401 81590	1	26-21-11 P061-00/ /	ALL
YQML002		116-565-1042-001 LT-L ENG 2	233N7401 81590	1	26-21-11 P061-00/* /	ALL
YQML003		116-565-1042-001 LT-R ENG 1	233N7401 81590	1	26-21-11 P061-00/* /	ALL
YQML004		116-565-1042-001 LT-R ENG 2	233N7401 81590	1	26-21-11 P061-00/* /	ALL
YQML005		116-565-1042-001 LT-APU	233N7401 81590	1	26-22-21 P061-00/ /	ALL
YQML006		116-565-1042-001 LT-FWD CARGO 1	233N7401 81590	1	26-23-11 / /	ALL
YQML007		116-565-1042-001 LT-FWD CARGO 2	233N7401 81590	1	26-23-11 / /	ALL
YQML008		116-565-1042-001 LT-AFT CARGO 1	233N7401 81590	1	26-23-11 / /	ALL
YQML009		116-565-1042-001 LT-AFT CARGO 2	233N7401 81590	1	26-23-11 / /	ALL

EQUIPMENT LIST

D280N032

Section YQML00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQMS001		P4-1056-12 SW-SQUIB TEST	233N7401 15703	1	26-21-11 P061-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQMS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQN++++		LRUOFM10443 CONTROL PNL-ENG FIRE	233N6201 81205	1	26-11-12 P008-00/* /	ALL

EQUIPMENT LIST

D280N032

Section YQN+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQNL01+	1	S231T300-2056 LT-L ENG OVHT	233N6205 81205	1	26-11-12 P008-00/ /	ALL
YQNL01+	2	S231T300-1056 LT-L ENG OVHT	233N6205 81205	1	26-11-12 P008-00/ /	ALL
YQNL01A		MS25237-387 LAMP-	S231T300 96906	2	26-11-12 P008-00/ /	ALL
YQNL01D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	26-11-12 P008-00/ /	ALL
YQNL02+	1	S231T300-2016 LT-ENG BTL 1 DISCH	233N6205 81205	1	26-11-12 P008-00/ /	ALL
YQNL02+	2	S231T300-1016 LT-ENG BTL 1 DISCH	233N6205 81205	1	26-11-12 P008-00/ /	ALL
YQNL02A		MS25237-387 LAMP-	S231T300 96906	2	26-11-12 P008-00/ /	ALL
YQNL02D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	26-11-12 P008-00/ /	ALL
YQNL03+	1	S231T300-2017 LT-ENG BTL 2 DISCH	233N6205 81205	1	26-11-12 P008-00/ /	ALL
YQNL03+	2	S231T300-1017 LT-ENG BTL 2 DISCH	233N6205 81205	1	26-11-12 P008-00/ /	ALL
YQNL03A		MS25237-387 LAMP-	S231T300 96906	2	26-11-12 P008-00/ /	ALL
YQNL03D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	26-11-12 P008-00/ /	ALL
YQNL04+	1	S231T300-2097 LT-R ENG OVHT	233N6205 81205	1	26-11-12 P008-00/ /	ALL
YQNL04+	2	S231T300-1097 LT-R ENG OVHT	233N6205 81205	1	26-11-12 P008-00/ /	ALL
YQNL04A		MS25237-387 LAMP-	S231T300 96906	2	26-11-12 P008-00/ /	ALL
YQNL04D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	26-11-12 P008-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQNL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQP++++		LRUOFM10444 CONT PNL-APU/CARGO FIRE	233N6101 81205	1	26-16-11 P008-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQP+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQPL01+	1	S231T300-2015 LT-APU BOTTLE DISCHARGE	233N6203 81205	1	26-22-21 P008-00/ /	ALL
YQPL01+	2	S231T300-1015 LT-APU BOTTLE DISCHARGE	233N6203 81205	1	26-22-21 P008-00/ /	ALL
YQPL01A		MS25237-387 LAMP-	S231T300 96906	2	26-22-21 P008-00/ /	ALL
YQPL01D		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	26-22-21 P008-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQPL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQPS01+		S231T290-5061 SW-FWD CARGO FIRE	233N6203 81205	1	26-23-11 P008-00/ /	115-199
YQPS01+	1	S231T290-4061 SW-FWD CARGO FIRE	233N6203 81205	1	26-23-11 P008-00/ /	001-099
YQPS01+	2	S231T290-5061 SW-FWD CARGO FIRE	233N6203 81205	1	26-23-11 P008-00/ /	001-099
YQPS01A		MS25237-387 LAMP-	S231T290 96906	2	26-23-11 P008-00/ /	ALL
YQPS01B		MS24515-685 LAMP-	S231T290 96906	2	26-23-11 P008-00/ /	ALL
YQPS01D		851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-23-11 P008-00/ /	115-199
YQPS01D	1	433-097-003 MODULE-DIODE/FUSE (KORRY SW ONLY)	S231T290 81590	1	26-23-11 P008-00/ /	001-099
YQPS01D	2	851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-23-11 P008-00/ /	001-099
YQPS02+		S231T290-5062 SW-AFT CARGO FIRE	233N6203 81205	1	26-23-11 P008-00/ /	115-199
YQPS02+	1	S231T290-4062 SW-AFT CARGO FIRE	233N6203 81205	1	26-23-11 P008-00/ /	001-099
YQPS02+	2	S231T290-5062 SW-AFT CARGO FIRE	233N6203 81205	1	26-23-11 P008-00/ /	001-099
YQPS02A		MS25237-387 LAMP-	S231T290 96906	2	26-23-11 P008-00/ /	ALL
YQPS02B		MS24515-685 LAMP-	S231T290 96906	2	26-23-11 P008-00/ /	ALL
YQPS02D		851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-23-11 P008-00/ /	115-199
YQPS02D	1	433-097-003 MODULE-DIODE/FUSE (KORRY SW ONLY)	S231T290 81590	1	26-23-11 P008-00/ /	001-099
YQPS02D	2	851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-23-11 P008-00/ /	001-099
YQPS03+		S231T290-5060 SW-BOTTLE 1 DISCHARGE	233N6203 81205	1	26-23-11 P008-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YQPS00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQPS03+	1	S231T290-4060 SW-BOTTLE 1 DISCHARGE	233N6203 81205	1	26-23-11 P008-00/ /	001-008
YQPS03+	1	S231T290-4006 SW-BOTTLE 1 DISCHARGE	233N6203 81205	1	26-23-11 P008-00/ /	009-099
YQPS03+	2	S231T290-5060 SW-BOTTLE 1 DISCHARGE	233N6203 81205	1	26-23-11 P008-00/ /	001-099
YQPS03A		MS25237-387 LAMP-	S231T290 96906	2	26-23-11 P008-00/ /	ALL
YQPS03D		851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-23-11 P008-00/ /	115-199
YQPS03D	1	433-097-003 MODULE-DIODE/FUSE (KORRY SW ONLY)	S231T290 81590	1	26-23-11 P008-00/ /	001-099
YQPS03D	2	851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-23-11 P008-00/ /	001-099
YQPS04+		S231T290-5060 SW-BOTTLE 2 DISCHARGE	233N6203 81205	1	26-23-11 P008-00/ /	115-199
YQPS04+	1	S231T290-4060 SW-BOTTLE 2 DISCHARGE	233N6203 81205	1	26-23-11 P008-00/ /	001-008
YQPS04+	1	S231T290-4006 SW-BOTTLE 2 DISCHARGE	233N6203 81205	1	26-23-11 P008-00/ /	009-099
YQPS04+	2	S231T290-5060 SW-BOTTLE 2 DISCHARGE	233N6203 81205	1	26-23-11 P008-00/ /	001-099
YQPS04A		MS25237-387 LAMP-	S231T290 96906	2	26-23-11 P008-00/ /	ALL
YQPS04D		851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-23-11 P008-00/ /	115-199
YQPS04D	1	433-097-003 MODULE-DIODE/FUSE (KORRY SW ONLY)	S231T290 81590	1	26-23-11 P008-00/ /	001-099
YQPS04D	2	851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-23-11 P008-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YQPS00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQQ++++		LRUOFM10445 PNL-FIRE TEST	233N6101 81205	1	26-11-11 P008-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQQ+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQQS002		702PB1 SW-ENG TEST	233N6101 91929	1	26-12-11 P008-00/ /	ALL
YQQS004		702PB1 SW-WW FIRE TEST	233N6204 91929	1	26-17-11 P008-00/ /	115-199
YQQS03+		S231T290-5063 SW-FAIL LT RESET	633N6204 81205	1	26-11-11 P008-00/ /	115-199
YQQS03+	1	S231T290-4063 SW-FAIL LT RESET	633N6204 81205	1	26-11-11 P008-00/ /	001-099
YQQS03+	2	S231T290-5063 SW-FAIL LT RESET	633N6204 81205	1	26-11-11 P008-00/ /	001-099
YQQS03A		MS25237-387 LAMP-	S231T290 96906	2	26-11-11 P008-00/ /	ALL
YQQS03D		851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-11-11 P008-00/ /	115-199
YQQS03D	1	433-097-001 MODULE-DIODE/FUSE (KORRY SW ONLY)	S231T290 81590	1	26-11-11 P008-00/ /	001-099
YQQS03D	2	851-30768-3823 MODULE-DIODE/FUSE (MSC SW ONLY)	S231T290 96182	1	26-11-11 P008-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YQQS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQS++++		LRUOFM00073 CONT MDL-FUEL	233N6101 81205	1	28-22-21 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQS+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQSL01+	1	S231T300-1109 LT-L SPAR VALVE DISAGREE	254N1106 81205	1	28-22-21 P010-00/ /	ALL
YQSL02+	1	S231T300-2034 LT-L ENG VALVE	254N1106 81205	1	76-11-11 P010-00/ /	ALL
YQSL02+	2	S231T300-1034 LT-L ENG VALVE	254N1106 81205	1	76-11-11 P010-00/ /	ALL
YQSL03+	1	S231T300-1109 LT-R SPAR VALVE DISAGREE	254N1106 81205	1	28-22-21 P010-00/ /	ALL
YQSL03A		MS25237-387 LAMP-	254N1195 96906	2	28-22-21 P010-00/ /	115-199
YQSL03B		434-093-001 MODULE-DIODE/FUSE	254N1195 81590	1	28-22-21 P010-00/ /	115-199
YQSL04+	1	S231T300-2034 LT-R ENG VALVE	254N1106 81205	1	76-11-12 P010-00/ /	ALL
YQSL04+	2	S231T300-1034 LT-R ENG VALVE	254N1106 81205	1	76-11-12 P010-00/ /	ALL
YQSL05+	1	S231T300-1101 LT-REV ISLN	254N1195 81205	1	78-36-11 P010-00/ /	ALL
YQSL05+	2	S231T300-2101 LT-REV ISLN	254N1195 81205	1	78-36-11 P010-00/ /	ALL
YQSL05A		MS25237-387 LAMP-	S231T300 96906	2	78-36-11 P010-00/ /	ALL
YQSL05B		434-09-001 MODULE-DIODE/FUSE	S231T300 81590	1	78-36-11 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQSL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQT++++		LRUOFM10050 CONT PNL-HYD SYS	233N3101 81205	1	29-11-12 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQT+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQTL001	1	S231T300-2088 LT-L HYD SYS PRESS	233N3205 81205	1	29-11-12 P005-00/ /	ALL
YQTL001	2	S231T300-1188 LT-L HYD SYS PRESS	233N3205 81205	1	29-11-12 P005-00/ /	ALL
YQTL002	1	S231T300-2298 LT-L SYS RSVR	233N3205 81205	1	29-33-11 P005-00/ /	ALL
YQTL002	2	S231T300-1298 LT-L SYS RSVR	233N3205 81205	1	29-33-11 P005-00/ /	ALL
YQTL003	1	S231T300-2088 LT-R HYD SYS PRESS	233N3205 81205	1	29-11-22 P005-00/ /	ALL
YQTL003	2	S231T300-1188 LT-R HYD SYS PRESS	233N3205 81205	1	29-11-22 P005-00/ /	ALL
YQTL004	1	S231T300-2298 LT-R SYS RSVR	233N3205 81205	1	29-33-11 P005-00/ /	ALL
YQTL004	2	S231T300-1298 LT-R SYS RSVR	233N3205 81205	1	29-33-11 P005-00/ /	ALL
YQTL005	1	S231T300-2088 LT-CTR HYD SYS PRESS	233N3205 81205	1	29-11-31 P005-00/ /	ALL
YQTL005	2	S231T300-1188 LT-CTR HYD SYS PRESS	233N3205 81205	1	29-11-31 P005-00/ /	ALL
YQTL006	1	S231T300-2298 LT-CTR SYS RSVR	233N3205 81205	1	29-33-11 P005-00/ /	ALL
YQTL006	2	S231T300-1298 LT-CTR SYS RSVR	233N3205 81205	1	29-33-11 P005-00/ /	ALL
YQTL007	1	S231T300-2086 LT-L ENGINE PUMP OVHT	233N3205 81205	1	29-32-11 P005-00/ /	ALL
YQTL007	2	S231T300-1086 LT-L ENGINE PUMP OVHT	233N3205 81205	1	29-32-11 P005-00/ /	ALL
YQTL008	1	S231T300-2086 LT-CTR ELEC PUMP 1 OVHT	233N3205 81205	1	29-32-31 P005-00/ /	ALL
YQTL008	2	S231T300-1086 LT-CTR ELEC PUMP 1 OVHT	233N3205 81205	1	29-32-31 P005-00/ /	ALL
YQTL009	1	S231T300-2086 LT-CTR ELEC PUMP 2 OVHT	233N3205 81205	1	29-32-31 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQTL00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQTL009	2	S231T300-1086 LT-CTR ELEC PUMP 2 OVHT	233N3205 81205	1	29-32-31 P005-00/ /	ALL
YQTL010	1	S231T300-2086 LT-R ENGINE PUMP OVHT	233N3205 81205	1	29-32-21 P005-00/ /	ALL
YQTL010	2	S231T300-1086 LT-R ENGINE PUMP OVHT	233N3205 81205	1	29-32-21 P005-00/ /	ALL
YQTL011	1	S231T300-2086 LT-L ELEC PUMP OVHT	233N3205 81205	1	29-32-11 P005-00/ /	ALL
YQTL011	2	S231T300-1086 LT-L ELEC PUMP OVHT	233N3205 81205	1	29-32-11 P005-00/ /	ALL
YQTL012	1	S231T300-2086 LT-R ELEC PUMP OVHT	233N3205 81205	1	29-32-21 P005-00/ /	ALL
YQTL012	2	S231T300-1086 LT-R ELEC PUMP OVHT	233N3205 81205	1	29-32-21 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQTL00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQTS001	1	S231T290-4020 SW-L ENG HYD PUMP	233N3101 81205	1	29-11-12 P005-00/ /	001-099
YQTS001	1	S231T290-5020 SW-L ENG HYD PUMP	233N3101 81205	1	29-11-12 P005-00/ /	115-199
YQTS001	2	S231T290-5020 SW-L ENG HYD PUMP	233N3101 81205	1	29-11-12 P005-00/ /	001-099
YQTS001	2	S231T290-3020 SW-L ENG HYD PUMP	233N3101 81205	1	29-11-12 P005-00/ /	115-199
YQTS002	1	S231T290-4020 SW-ELEC #1 HYD PUMP	233N3101 81205	1	29-11-31 P005-00/*/	001-099
YQTS002	1	S231T290-5020 SW-ELEC #1 HYD PUMP	233N3101 81205	1	29-11-31 P005-00/*/	115-199
YQTS002	2	S231T290-5020 SW-ELEC #1 HYD PUMP	233N3101 81205	1	29-11-31 P005-00/*/	001-099
YQTS002	2	S231T290-3020 SW-ELEC #1 HYD PUMP	233N3101 81205	1	29-11-31 P005-00/*/	115-199
YQTS003	1	S231T290-4020 SW-ELEC #2 HYD PUMP	233N3101 81205	1	29-11-31 P005-00/*/	001-099
YQTS003	1	S231T290-5020 SW-ELEC #2 HYD PUMP	233N3101 81205	1	29-11-31 P005-00/*/	115-199
YQTS003	2	S231T290-5020 SW-ELEC #2 HYD PUMP	233N3101 81205	1	29-11-31 P005-00/*/	001-099
YQTS003	2	S231T290-3020 SW-ELEC #2 HYD PUMP	233N3101 81205	1	29-11-31 P005-00/*/	115-199
YQTS004	1	S231T290-1020 SW-R ENG HYD PUMP	233N3101 81205	1	29-11-22 P005-00/*/	001-099
YQTS004	1	S231T290-5020 SW-R ENG HYD PUMP	233N3101 81205	1	29-11-22 P005-00/*/	115-199
YQTS004	2	S231T290-3020 SW-R ENG HYD PUMP	233N3101 81205	1	29-11-22 P005-00/*/	ALL
YQTS005	1	S231T290-4020 SW-L ELECT PUMP	233N3101 81205	1	29-11-12 P005-00/*/	001-099
YQTS005	1	S231T290-5020 SW-L ELECT PUMP	233N3101 81205	1	29-11-12 P005-00/*/	115-199

EQUIPMENT LIST

D280N032

Section YQTS00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQTS005	2	S231T290-5020 SW-L ELECT PUMP	233N3101 81205	1	29-11-12 P005-00/*/	001-099
YQTS005	2	S231T290-3020 SW-L ELECT PUMP	233N3101 81205	1	29-11-12 P005-00/*/	115-199
YQTS006	1	S231T290-4020 SW-R ELECT PUMP	233N3101 81205	1	29-11-22 P005-00/*/	001-099
YQTS006	1	S231T290-5020 SW-R ELECT PUMP	233N3101 81205	1	29-11-22 P005-00/*/	115-199
YQTS006	2	S231T290-5020 SW-R ELECT PUMP	233N3101 81205	1	29-11-22 P005-00/*/	001-099
YQTS006	2	S231T290-3020 SW-R ELECT PUMP	233N3101 81205	1	29-11-22 P005-00/*/	115-199

EQUIPMENT LIST

D280N032

Section YQTS00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQU++++		LRUOFM10468 CONT PNL-ENG START/RAT	233N3223 81205	1	74-31-11 P005-00/* /	ALL

EQUIPMENT LIST

D280N032

Section YQU+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQUL01+		S231T300-1115 LT-L ENG VALVE	233N3223 81205	1	80-11-11 P005-00/ /	ALL
YQUL01A		MS25237-387 LAMP-	S231T300 96906	1	80-11-11 P005-00/ /	ALL
YQUL01B		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	80-11-11 P005-00/ /	ALL
YQUL02+		S231T300-1115 LT-R ENG VALVE	233N3223 81205	1	80-11-21 P005-00/ /	ALL
YQUL02A		MS25237-387 LAMP-	S231T300 96906	1	80-11-21 P005-00/ /	ALL
YQUL02B		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	80-11-21 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQUL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQUS001	1	S231T290-4036 SW-RAT DEPLOYMENT	233N3101 81205	1	29-21-31 P005-00/*/	001-099
YQUS001	1	S231T290-5036 SW-RAT DEPLOYMENT	233N3101 81205	1	29-21-31 P005-00/*/	115-199
YQUS001	2	S231T290-5036 SW-RAT DEPLOYMENT	233N3101 81205	1	29-21-31 P005-00/*/	001-099
YQUS001	2	S231T290-3036 SW-RAT DEPLOYMENT	233N3101 81205	1	29-21-31 P005-00/*/	115-199
YQUS05+		S231T290-5016 SW-L ENG LIMITER	233N3223 81205	1	73-21-11 P005-00/ /	115-199
YQUS05+	1	S231T290-4016 SW-L ENG LIMITER	233N3223 81205	1	73-21-11 P005-00/ /	001-099
YQUS05+	2	S231T290-5016 SW-L ENG LIMITER	233N3223 81205	1	73-21-11 P005-00/ /	001-099
YQUS05A		MS25237-387 LAMP-TYPE 387	S231T290 96906	1	73-21-11 P005-00/ /	001-099
YQUS05A		MS25237-387AS15 LAMP-TYPE 387	S231T290 96906	1	73-21-11 P005-00/ /	115-199
YQUS05B		MS24515-685 LAMP-TYPE 685	S231T290 96906	1	73-21-11 P005-00/ /	ALL
YQUS06+		S231T290-5016 SW-R ENG LIMITER	233N3223 81205	1	73-21-21 P005-00/ /	115-199
YQUS06+	1	S231T290-4016 SW-R ENG LIMITER	233N3223 81205	1	73-21-21 P005-00/ /	001-099
YQUS06+	2	S231T290-5016 SW-R ENG LIMITER	233N3223 81205	1	73-21-21 P005-00/ /	001-099
YQUS06A		MS25237-387AS15 LAMP-TYPE 387	S231T290 96906	1	73-21-21 P005-00/ /	ALL
YQUS06B		MS24515-685AS15 LAMP-TYPE 685	S231T290 96906	1	73-21-21 P005-00/ /	001-099
YQUS06B		MS24515-685 LAMP-TYPE 685	S231T290 96906	1	73-21-21 P005-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YQUS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQV++++		LRUOFM10055 PANEL-FUEL CONTROL	233N3101 81205	1	28-22-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQV+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQVL01+	1	S231T300-2293 LT-FUEL CONFIG	233N3206 81205	1	28-41-13 P005-00/* /	ALL
YQVL01+	2	S231T300-1293 LT-FUEL CONFIG.	233N3206 81205	1	28-41-13 P005-00/ /	ALL
YQVL01A		MS25237-387AS15 LAMP-FUEL CONFIG. LT	233N3206 96906	2	28-41-13 P005-00/ /	ALL
YQVL01B		434-093-001 MODULE-DIODE/FUSE	233N3206 81590	1	28-41-13 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQVL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQVS01+	1	S231T290-4026 SW-L AFT FUEL BOOST PUMP(KRY)	233N3206 81205	1	28-22-13 P005-00/*/	001-099
YQVS01A		MS25237-387 LAMP-DISPLAY,LOWER HALF	233N3206 96906	2	28-22-13 P005-00/ /	ALL
YQVS01B		MS24515-685AS15 LAMP-DISPLAY,UPPER HALF	233N3206 96906	2	28-22-13 P005-00/ /	ALL
YQVS01C		851-30768-3823 MODULE-DIODE/FUSE	233N3206 96182	1	28-22-13 P005-00/ /	115-199
YQVS01C	1	433-097-003 MODULE-DIODE/FUSE(KORRY SW ONLY)	233N3206 96182	1	28-22-13 P005-00/ /	001-099
YQVS01C	2	851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-13 P005-00/ /	001-099
YQVS02+	1	S231T290-4026 SW-L FWD FUEL BOOST PUMP(KRY)	233N3206 81205	1	28-22-11 P005-00/ /	001-099
YQVS02A		MS25237-387 LAMP-DISPLAY,LOWER HALF	233N3206 96906	2	28-22-11 P005-00/ /	ALL
YQVS02B		MS24515-685AS15 LAMP-DISPLAY,UPPER HALF	233N3206 96906	2	28-22-11 P005-00/ /	ALL
YQVS02C		851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-11 P005-00/ /	115-199
YQVS02C	1	433-097-003 MODULE-DIODE/FUSE(KORRY SW ONLY)	233N3206 96182	1	28-22-11 P005-00/ /	001-099
YQVS02C	2	851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-11 P005-00/ /	001-099
YQVS03+		S231T290-5038 SW-CROSSFEED VALVE(MSC)	233N3206 81205	1	28-22-31 P005-00/*/	115-199
YQVS03+	1	S231T290-4038 SW-CROSSFEED VALVE(KRY)	233N3206 81205	1	28-22-31 P005-00/*/	001-008
YQVS03+	1	S231T290-4038 SW-AFT FUEL CROSSFEED VALVE (KRY)	233N3206 81205	1	28-22-31 P005-00/*/	009-099
YQVS03+	2	S231T290-5038 SW-CROSSFEED VALVE(MSC)	233N3206 81205	1	28-22-31 P005-00/*/	001-008
YQVS03+	2	S231T290-5038 SW-AFT FUEL CROSSFEED VALVE (MSC)	233N3206 81205	1	28-22-31 P005-00/*/	009-099

EQUIPMENT LIST

D280N032

Section YQVS00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQVS03A		MS25237-387 LAMP-DISPLAY,LOWER HALF	233N3206 96906	2	28-22-31 P005-00/ /	ALL
YQVS03B		MS24515-685AS15 LAMP-DISPLAY,UPPER HALF	233N3206 96906	2	28-22-31 P005-00/ /	ALL
YQVS03C		851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-31 P005-00/ /	115-199
YQVS03C	1	433-097-003 MODULE-DIODE/FUSE(KORRY SW ONLY)	233N3206 96182	1	28-22-31 P005-00/ /	001-099
YQVS03C	2	851-30768-823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-31 P005-00/ /	001-099
YQVS04+	1	S231T290-4026 SW-R AFT FUEL BOOST PUMP(KRY)	233N3206 81205	1	28-22-11 P005-00/*/	001-099
YQVS04A		MS25237-387 LAMP-DISPLAY,LOWER HALF	233N3206 96906	2	28-22-12 P005-00/ /	ALL
YQVS04B		MS24515-685AS15 LAMP-DISPLAY,UPPER HALF	233N3206 96906	2	28-22-12 P005-00/ /	ALL
YQVS04C		851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-12 P005-00/ /	115-199
YQVS04C	1	433-097-003 MODULE-DIODE/FUSE(KORRY SW ONLY)	233N3206 96182	1	28-22-12 P005-00/ /	001-099
YQVS04C	2	851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-12 P005-00/ /	001-099
YQVS05+	1	S231T290-4026 SW-R FWD FUEL BOOST PUMP(KRY)	233N3206 81205	1	28-22-13 P005-00/*/	001-099
YQVS05A		MS25237-387 LAMP-DISPLAY,LOWER HALF	233N3206 96906	2	28-22-13 P005-00/ /	ALL
YQVS05B		MS24515-685AS15 LAMP-DISPLAY,UPPER HALF	233N3206 96906	2	28-22-13 P005-00/ /	ALL
YQVS05C		851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-13 P005-00/ /	115-199
YQVS05C	1	433-097-003 MODULE-DIODE/FUSE(KORRY SW ONLY)	233N3206 96182	1	28-22-13 P005-00/ /	001-099
YQVS05C	2	851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-13 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YQVS00

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQVS06+	1	S231T290-4021 SW-L OVRD FUEL BOOST PUMP(KRY)	233N3206 81205	1	28-22-11 P005-00/*/	001-099
YQVS06A		MS25237-387 LAMP-DISPLAY,RIGHT HALF	233N3206 96906	2	28-22-11 P005-00/ /	ALL
YQVS06B		MS24515-685AS15 LAMP-DISPLAY,LEFT HALF	233N3206 96906	2	28-22-11 P005-00/ /	ALL
YQVS06C		851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-11 P005-00/ /	115-199
YQVS06C	1	433-097-003 MODULE-DIODE/FUSE(KORRY SW ONLY)	233N3206 96182	1	28-22-11 P005-00/ /	001-099
YQVS06C	2	851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-11 P005-00/ /	001-099
YQVS07+	1	S231T290-4022 SW-R OVRD FUEL BOOST PUMP(KRY)	233N3206 81205	1	28-22-12 P005-00/*/	001-099
YQVS07A		MS25237-387 LAMP-DISPLAY,LEFT HALF	233N3206 96906	2	28-22-12 P005-00/ /	ALL
YQVS07B		MS24515-685AS15 LAMP-DISPLAY,RIGHT HALF	233N3206 96906	2	28-22-12 P005-00/ /	ALL
YQVS07C		851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-12 P005-00/ /	115-199
YQVS07C	1	433-097-003 MODULE-DIODE/FUSE(KORRY SW ONLY)	233N3206 96182	1	28-22-12 P005-00/ /	001-099
YQVS07C	2	851-30768-3823 MODULE-DIODE/FUSE(MSC SW ONLY)	233N3206 96182	1	28-22-12 P005-00/ /	001-099
YQVS08+		S231T290-4038 SW-FWD FUEL CROSSFEED VALVE (KRY)	233N3206 82105	1	28-22-31 P005-00/*/	009-099
YQVS08A		MS25237-387 LAMP-DISPLAY,LOWER HALF	233N3206 96906	2	28-22-31 P005-00/ /	009-099
YQVS08B		MS24515-685AS15 LAMP DISPLAY,UPPER HALF	233N3206 96906	2	28-22-31 P005-00/ /	009-099
YQVS08C	1	433-097-003 MODULE-DIODE/FUSE (KORRY SW ONLY)	233N3206 96182	1	28-22-31 P005-00/ /	009-099
YQVS08C	2	851-30768-823 MODULE-DIODE/FUSE (MSC SW ONLY)	233N3206 96182	1	28-22-31 P005-00/ /	009-099

EQUIPMENT LIST

D280N032

Section YQVS00

Page 3 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQZJ005		2854-0 TEST POINT-L HYDR LEAK	233N7401 95266	1	29-11-12 P061-00/ /	115-199
YQZJ006		2854-2 TEST POINT-L HYDR LEAK	233N7401 95266	1	29-11-12 P061-00/ /	115-199
YQZJ007		2854-0 TEST POINT-CTR HYDR LEAK	233N7401 95266	1	29-11-31 P061-00/ /	115-199
YQZJ008		2854-2 TEST POINT-CTR HYDR LEAK	233N7401 95266	1	29-11-31 P061-00/ /	115-199
YQZJ009		2854-0 TEST POINT-R HYDR LEAK	233N7401 95266	1	29-11-22 P061-00/ /	115-199
YQZJ010		2854-2 TEST POINT-R HYDR LEAK	233N7401 95266	1	29-11-22 P061-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YQZJ00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQZK001		600-149-1001 TIMER-RELAY (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQZK00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQZS001		S231T290-5073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	115-199
YQZS001	1	S231T290-4073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	001-003
YQZS001	2	S231T290-5073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	001-003
YQZS002		S231T290-5073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	115-199
YQZS002	1	S231T290-4073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	001-003
YQZS002	2	S231T290-5073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	001-003
YQZS003		S231T290-5073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	115-199
YQZS003	1	S231T290-4073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	001-003
YQZS003	2	S231T290-5073 SW-PUSHBUTTON (M10191)	233N7401 81205	1	24-11-11 P061-00/ /	001-003
YQZS004	1	S231T290-4024 SW-HYD FLT CONT SHUT-OFF,L	233N7503 81205	1	27-23-11 P061-00/ /	001-099
YQZS004	1	S231T290-5024 SW-HYD FLT CONT SHUT-OFF,L	233N7503 81205	1	27-23-11 P061-00/ /	115-199
YQZS004	2	S231T290-5024 SW-HYD FLT CONT SHUT-OFF,L	233N7503 81205	1	27-23-11 P061-00/ /	001-099
YQZS004	2	S231T290-3024 SW-HYD FLT CONT SHUT-OFF,L	233N7503 81205	1	27-23-11 P061-00/ /	115-199
YQZS005	1	S231T290-4024 SW-HYD FLT CONT SHUT-OFF,CTR	233N7503 81205	1	27-23-11 P061-00/ /	001-099
YQZS005	1	S231T290-5024 SW-HYD FLT CONT SHUT-OFF,CTR	233N7503 81205	1	27-23-11 P061-00/ /	115-199
YQZS005	2	S231T290-5024 SW-HYD FLT CONT SHUT-OFF,CTR	233N7503 81205	1	27-23-11 P061-00/ /	001-099
YQZS005	2	S231T290-3024 SW-HYD FLT CONT SHUT-OFF,CTR	233N7503 81205	1	27-23-11 P061-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YQZS00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YQZS006	1	S231T290-4024 SW-HYD FLT CONT SHUT-OFF,R	233N7503 81205	1	27-23-11 P061-00/ /	001-099
YQZS006	1	S231T290-5024 SW-HYD FLT CONT SHUT-OFF,R	233N7503 81205	1	27-23-11 P061-00/ /	115-199
YQZS006	2	S231T290-5024 SW-HYD FLT CONT SHUT-OFF,R	233N7503 81205	1	27-23-11 P061-00/ /	001-099
YQZS006	2	S231T290-3024 SW-HYD FLT CONT SHUT-OFF,R	233N7503 81205	1	27-23-11 P061-00/ /	115-199
YQZS007		BACS30EM55 SW-PTU,LRU OF M10191	233N7401 81205	1	29-22-11 P061-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YQZS00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRA++++		LRUOFM10492 FLUO LAMP/BALLAST ASSY	417N5120 81205	0	33-21-21 / /	115-199

EQUIPMENT LIST

D280N032

Section YRA+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRAB001		S283N702-5 BALLAST-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-21 / /	115-199

EQUIPMENT LIST

D280N032

Section YRAB00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRAD001		BACC63BN12-12S8 PLUG-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-21 / /	115-199
YRAD002		BACC45FN12-12P RCPT-FLUO LAMP/BALLAST ASSY	417N5120 81205	1	33-21-21 / /	115-199

EQUIPMENT LIST

D280N032

Section YRAD00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRAL001		F20T12WW LAMP-FLUO LAMP/BALLAST ASSY	417N5120 05374	1	33-21-21 / /	115-199

EQUIPMENT LIST

D280N032

Section YRAL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRB++++		LRUOFM10549 LAMP ASSY	232N5001 81205	1	33-11-31 292/278/L027	ALL

EQUIPMENT LIST

D280N032

Section YRB+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRBL001		1665 LAMP-AFT FLT DK DOME LT,AFT	232N5001 08806	1	33-11-31 292/278/L027	ALL
YRBL002		1317 LAMP-FLT DK EMER LT	232N5001 08806	1	33-51-12 292/278/L027	ALL

EQUIPMENT LIST

D280N032

Section YRBL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRD++++		LRUOFM00001 PNL APU CONTROL	233N3101 81205	1	49-61-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YRD+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRDK001		BACR13CD2 RELAY-APU START	233N3101 81205	1	49-61-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YRDK00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRDL001	1	S231T300-1036 LIGHT-FAULT	233N3232 81205	1	49-61-11 P005-00/ /	001-099
YRDL01+	1	S231T300-1036 LIGHT-FAULT	233N3232 81205	1	49-61-11 P005-00/ /	001-099
YRDL01+	2	S231T300-2036 LIGHT-FAULT	233N3232 81205	1	49-61-11 P005-00/ /	001-099
YRDL01A		MS25237-387 LAMP-	S231T300 96906	2	49-61-11 P005-00/ /	001-099
YRDL01B		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	49-61-11 P005-00/ /	001-099
YRDL02+	1	S231T300-1122 LIGHT-RUN	233N3232 81205	1	49-61-11 P005-00/ /	001-099
YRDL02+	2	S231T300-2122 LIGHT-RUN	233N3232 81205	1	49-61-11 P005-00/ /	001-099
YRDL02A		MS25237-387 LAMP-	S231T300 96906	2	49-61-11 P005-00/ /	001-099
YRDL02B		434-093-001 MODULE-DIODE/FUSE	S231T300 81590	1	49-61-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YRDL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRDS001	1	AC45-0003-4 SW-APU START	233N3232 91812	1	49-61-11 P005-00/ /	001-099
YRDS001	2	AC45-0003-3 SW-APU START	233N3232 91812	1	49-61-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YRDS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRE++++		LRUOFM00966 ASSY-MICROSWITCH PACK	254N1058 81205	1	32-42-12 P010-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YRE+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRES002		141SM2-T2 SW-THRUST LEVER LEFT NO.1	254N1058 81205	1	32-42-12 P010-00/ /	ALL
YRES003		BACS30BV1 SW-THRUST LEVER LEFT NO.2	254N1058 81205	1	32-42-12 P010-00/ /	ALL
YRES006		141SM2-T2 SW-THRUST LEVER RIGHT NO.1	254N1058 81205	1	32-42-12 P010-00/ /	ALL
YRES007		BACS30BV1 SW-THRUST LEVER RIGHT NO.2	254N1058 81205	1	32-42-12 P010-00/ /	ALL
YRES010		BACS30BV1 SW-L SPEEDBRAKE RETRACT	254N1185 81205	1	27-62-11 P010-00/ /	ALL
YRES014		BACS30BV1 SW-R SPEEDBRAKE RETRACT	254N1185 81205	1	27-62-11 P010-00/ /	ALL
YRES021		BACS308V1 T/R CONT SW-L	254N1185 81205	1	78-34-11 P010-00/ /	003-099
YRES022		BACS30BV1 T/R CONT SW-R	254N1185 81205	1	78-34-21 P010-00/ /	003-099
YRES023		BACS30BV1 L T/R IND CONT	254N1185 81205	1	78-36-11 P010-00/ /	003-099
YRES024		BACS30BV1 R T/R IND CONT	254N1185 81205	1	78-36-21 P010-00/ /	003-099

EQUIPMENT LIST

D280N032

Section YRES00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRH++++		LRUOFM10012 MODULE-LAVATORY UTILITY	417N1070 81205	1	25-41-01 / /	ALL

EQUIPMENT LIST

D280N032

Section YRH+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHH001		60B50064-1 HEATER-WATER	S417N101 81205	1	38-13-11 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHH00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHJ002		BACC45FN14-7S RCPT-	S417N101 81205	1	25-41-01 0338/290/L020	ALL
YRHJ003		BACC45FN14-15S RCPT-	S417N101 81205	1	25-41-01 0338/290/L020	ALL
YRHJ004		48-7190 PLUG-	S417N101 02660	1	25-41-01 0338/290/L020	ALL
YRHJ005		48-7191 RCPT-	S417N101 02660	1	25-41-01 0338/290/L020	ALL
YRHJ006		48-7191 RCPT-	S417N101 02660	1	25-41-01 0338/290/L020	001-099
YRHJ007		XLR-5-31 RCPT-	S417N101 71468	1	25-41-01 0338/290/L020	115-199
YRHJ008		48-7191 RCPT-	S417N101 02660	1	25-41-01 0338/290/L020	001-099
YRHJ009		48-7191 RCPT-	S417N101 02660	1	25-41-01 0338/290/L020	001-099

EQUIPMENT LIST

D280N032

Section YRHJ00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHK001		BACR13CD2 RELAY-CALL	S417N101 81205	1	33-25-31 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHK00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHL001		5113WW LAMP-FLUORESCENT	S417N101 08805	1	33-26-11 0338/290/L020	ALL
YRHL002		5113WW LAMP-FLUORESCENT	S417N101 08805	1	33-26-11 0338/290/L020	ALL
YRHL003		L18615-11-14 LAMP ASSY WITH LAMP 1691IF	S417N101 17744	1	33-26-11 0338/290/L020	ALL
YRHL004		387 LAMP-	S417N101 08806	1	33-25-31 0338/290/L020	001-099
YRHL1M1		82003-11101 LAMP ASSY WITH TWO 387 LAMPS	S417N101 S5006	1	33-24-31 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHLS01		PV5A-C8962 SPEAKER	S417N101 00614	1	25-41-01 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHL
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHM001		2A112-0086-7 PANEL,UTILITY	S417N101 81205	1	25-41-01 0338/290/L020	ALL
YRHM002		S417N102-1 ASSY,FLUSHING TOILET	417N1112 81205	1	38-32-11 0338/290/L020	ALL
YRHM004		PU90-499 SMOKE DETECTOR-LAV A	S417N101 S5065	1	26-14-11 338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHM00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHP001		BACC45FT24C43P PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	ALL
YRHP002		BACC45FT14C7S PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	ALL
YRHP004		BACC45FT10C5S PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	ALL
YRHP005		BACC45FT12C12S PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	ALL
YRHP006		48-7190 PLUG-	S417N101 02660	1	25-41-01 0338/290/L020	001-099
YRHP006		BACC45FT20-41S PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	115-199
YRHP007		BACC63BN10A5P PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	115-199
YRHP008		48-7190 PLUG-	S417N101 02660	1	25-41-01 0388/290/L020	001-099
YRHP008		BACC45FT14A15S PLUG-	S417N101 81205	1	25-41-01 0388/290/L020	115-199
YRHP009		48-7190 PLUG-	S417N101 02660	1	25-41-01 0338/290/L020	001-099
YRHP009		BACC45FT20C41P PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	115-199
YRHP010		L10TF6S6NA RCPT-SHAVER	S417N101 81205	1	25-41-01 0338/290/L020	001-099
YRHP011		BACC45FT14-15P PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	115-199
YRHP015		DAMA15SWS PLUG-	S417N101 71468	1	26-14-11 338/290/L020	ALL
YRHP1M1		BACC45FT14-15P PLUG-	S417N101 81205	1	25-41-01 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHP00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHRT01		10-60752-11 BALLAST	S417N101 81205	1	33-26-11 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHR
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHS001		10C10B SWITCH,D00R	S417N101 15438	1	33-26-11 0338/290/L020	ALL
YRHS002		60B50058-6 SWITCH,FLUSH TIMER LAV A	S417N101 81205	1	38-32-11 0338/290/L020	ALL
YRHS003		A20247AM1 SWITCH,CALL RESET	S417N101 81640	1	33-25-31 0338/290/L020	ALL
YRHS1M1		AML21KBA2AC-003 SWITCH,ATTEN CALL	S417N101 91929	1	33-25-31 0338/290/L020	001-099
YRHS1M1		AML21KBA2AC-002 SWITCH,ATTEN CALL	S417N101 91929	1	33-25-31 0338/290/L020	115-199
YRHS1M2		S283N202-1 DETECTOR-WASTE TANK OVERFILL	417N1017 81205	1	38-32-21 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHT001		Z3691-1 TRANSFORMER	S417N101 00614	1	25-41-01 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHT00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHV1M2		60B50341-1 VALVE-SHUT-OFF,TOILET FILL LINE	417N1017 81205	1	38-32-21 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHV00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRHXK01		HRTS-17KM SOCKET,RELAY	S417N101 91663	1	33-25-31 0338/290/L020	ALL
YRHXL01		BV5-01258 SOCKET,FLUORESCENT	S417N101 17023	1	33-26-11 0338/290/L020	ALL
YRHXL02		BV5-01261 SOCKET,FLUORESCENT	S417N101 17023	1	33-26-11 0338/290/L020	ALL

EQUIPMENT LIST

D280N032

Section YRHX
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRJK001		BACR13CD2 RELAY,CALL (PROVISIONS)	S417N101 81205	1	33-25-31 1246/290/L022	001-099

EQUIPMENT LIST

D280N032

Section YRJK00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRJL004		387 LAMP-(PROVISIONS)	S417N101 08806	1	33-25-31 1246/290/L022	001-099
YRJL1M1		82003-11101 LAMP ASSY WITH TWO 387 LAMPS	S417N101 S5006	1	33-24-31 1246/290/L022	001-099

EQUIPMENT LIST

D280N032

Section YRJL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRJS003		A20247AM1 SWITCH-CALL RESET (PROVISIONS)	S417N101 81640	1	33-25-31 1246/290/L022	001-099
YRJS1M1		AML21KBA2AC-002 SWITCH-ATTEN CALL(PROVISIONS)	S417N101 91929	1	33-25-31 1246/290/L022	001-099

EQUIPMENT LIST

D280N032

Section YRJS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRJXK01		HRTS-17KM SOCKET-RELAY(PROVISIONS)	S417N101 91663	1	33-25-31 1246/290/L022	001-099

EQUIPMENT LIST

D280N032

Section YRJX
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRK++++		LRUOFM10014 MODULE-LAVATORY UTILITY	417N1069 81205	1	25-41-01 / /	ALL

EQUIPMENT LIST

D280N032

Section YRK+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKH001		60B50064-1 HEATER,WATER	S417N101 81205	1	38-13-11 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKH00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKJ001		BACC45FN24-43P RCPT-	S417N101 81205	1	25-41-01 1281/290/L022	ALL
YRKJ002		BACC45FN14-7S RCPT-	S417N101 81205	1	25-41-01 1281/290/L022	ALL
YRKJ003		BACC45FN14-15S RCPT-	S417N101 81205	1	25-41-01 1281/290/L022	ALL
YRKJ004		48-7190 PLUG-	S417N101 02660	1	25-41-01 1281/290/L022	ALL
YRKJ005		48-7191 RCPT-	S417N101 02660	1	25-41-01 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKJ00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKK001		BACR13CD2 RELAY,CALL	S417N101 81205	1	33-25-31 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKK00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKL001		F15T12WW LAMP,FLUORESCENT	S417N101 08805	1	33-26-11 1281/290/L022	ALL
YRKL002		F15T12WW LAMP,FLUORESCENT	S417N101 08805	1	33-26-11 1281/290/L022	ALL
YRKL003		L18615-11-14 LAMP ASSY WITH LAMP 1691IF	S417N101 17744	1	33-26-11 1281/290/L022	001-099
YRKL003		L18615-11-14 LAMP ASSY WITH LAMP 1691	S417N101 17744	1	33-26-11 1281/290/L022	115-199
YRKL004		387 LAMP-	S417N101 08806	1	33-25-31 1281/290/L022	001-099
YRKL1M1		82003-11101 LAMP-ASSY WITH TWO 387 LAMPS	S417N101 S5006	1	33-24-31 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKLS01		PV5A-C8962 SPEAKER	S417N101 00614	1	25-41-01 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKL
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKM001		2A122-0089-7 PANEL, UTILITY	S417N101 81205	1	25-41-01 1281/290/L022	ALL
YRKM002		S417N102-10 ASSY, FLUSHING TOILET	417N1112 81205	1	38-32-11 1281/290/L022	ALL
YRKM004		PU90-499 SMOKE DETECTOR-LAV C	S417N101 S5065	1	26-14-11 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKM00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKP002		BACC45FT14C7S PLUG-	S417N101 81205	1	25-41-01 1281/290/L022	ALL
YRKP004		BACC45FT10C5S PLUG-	S417N101 81205	1	25-41-01 1281/290/L022	ALL
YRKP005		BACC45FT12C12S PLUG-	S417N101 81205	1	25-41-01 1281/290/L022	ALL
YRKP015		DAMA15SWS PLUG-	S417N101 71468	1	26-14-11 1281/290/L022	ALL
YRKP1M1		BACC45FT14-15P PLUG-	S417N101 81205	1	25-41-01 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKP00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKRT01		60B40025-43 BALLAST	S417N101 81205	1	33-26-11 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKR
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKS001		10C10B SWITCH,DOOR	S417N101 15438	1	33-26-11 1281/290/L022	ALL
YRKS002		60B50058-6 SWITCH,FLUSH TIMER LAV C	S417N101 81205	1	38-32-11 1281/290/L022	ALL
YRKS003		A20247AM1 SWITCH	S417N101 81640	1	33-25-31 1281/290/L022	ALL
YRKS1M1		AML21KBA2AC-003 SWITCH,ATTEN CALL	S417N101 91929	1	33-25-31 1281/290/L022	ALL
YRKS1M2		S283N202-1 DETECTOR,WASTE TANK OVERFILL	417N1017 81205	1	38-32-21 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKT001		Z3691-1 TRANSFORMER	S417N101 00614	1	25-41-01 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKT00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKV1M2		60B50341-1 VALVE-SHUT-OFF,TOILET FILL LINE	417N1017 81205	1	38-32-21 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKV00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRKXK01		HRTS-17KM SOCKET,RELAY	S417N101 91663	1	33-25-31 1281/290/L022	ALL
YRKXL01		BV03112N-40 SOCKET,FLUORESCENT	S417N101 17023	1	33-26-11 1281/290/L022	ALL
YRKXL02		BV03112N-40 SOCKET,FLUORESCENT	S417N101 17023	1	33-26-11 1281/290/L022	ALL

EQUIPMENT LIST

D280N032

Section YRKX
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRL++++		LRUOFM10015 MODULE-LAVATORY UTILITY	417N1062 81205	1	25-41-01 / /	ALL

EQUIPMENT LIST

D280N032

Section YRL+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLH001		60B50064-1 HEATER,WATER	S417N101 81205	1	38-13-11 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLH00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLJ001		BACC45FN24-43P RCPT-	S417N101 81205	1	25-41-01 1281/290/R022	ALL
YRLJ002		BACC45FN14-7S RCPT-	S417N101 81205	1	25-41-01 1281/290/R022	ALL
YRLJ003		BACC45FN14-15S RCPT-	S417N101 81205	1	25-41-01 1281/290/R022	ALL
YRLJ004		48-7190 PLUG-	S417N101 02660	1	25-41-01 1281/290/R022	ALL
YRLJ005		48-7191 RCPT-	S417N101 02660	1	25-41-01 1281/290/R022	ALL
YRLJ007		XLR-5-31 PLUG-	S417N101 71468	1	25-41-01 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLJ00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLK001		BACR13CD2 RELAY,CALL	S417N101 81205	1	33-25-31 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLK00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLL001		F15T12WW LAMP,FLUORESCENT	S417N101 08805	1	33-26-11 1281/290/R022	ALL
YRLL002		F15T12WW LAMP,FLUORESCENT	S417N101 08805	1	33-26-11 1281/290/R022	ALL
YRLL003		L18615-11-14 LAMP ASSY WITH LAMP 1691IF	S417N101 17744	1	33-26-11 1281/290/R022	ALL
YRLL004		387 LAMP-	S417N101 08806	1	33-25-31 1281/290/R022	001-099
YRLL1M1		82003-11101 LAMP ASSY WITH TWO 387 LAMPS	S417N101 S5006	1	33-24-31 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLLS01		PV5A-C8962 SPEAKER	S417N101 00614	1	25-41-01 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLL
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLM001		2A122-0089-7 PANEL, UTILITY	S417N101 81205	1	25-41-01 1281/290/R022	001-099
YRLM001		2A122-0089-8 PANEL, UTILITY	S417N101 81205	1	25-41-01 1281/290/R022	115-199
YRLM002		S417N102-9 ASSY, FLUSHING TOILET	417N1112 81205	1	38-32-11 1281/290/R022	ALL
YRLM004		PU90-499 SMOKE DETECTOR-LAV D	S417N101 S5065	1	26-14-11 1281/290/R022	115-199

EQUIPMENT LIST

D280N032

Section YRLM00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLP002		BACC45FT14C7S PLUG-	S417N101 81205	1	25-41-01 1281/290/R022	ALL
YRLP004		BACC45FT10C5S PLUG-	S417N101 81205	1	25-41-01 1281/290/R022	ALL
YRLP005		BACC45FT12C12S PLUG-	S417N101 81205	1	25-41-01 1281/290/R022	ALL
YRLP007		BACC63BN10C5P PLUG-HANDSET	S417N101 81205	1	25-41-01 1281/290/R022	001-099
YRLP007		BACC63BN10A5P PLUG-HANDSET	S417N101 81205	1	25-41-01 1281/290/R022	115-199
YRLP010		L10TF6S6NA RCPT-	S417N101 81205	1	25-41-01 1281/290/R022	001-099
YRLP015		DAMA15SWS PLUG-	S417N101 71468	1	26-14-11 1281/290/R022	ALL
YRLP1M1		BACC45FT14-15P PLUG-	S417N101 81205	1	25-41-01 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLP00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLRT01		60B40025-43 BALLAST	S417N101 81205	1	33-26-11 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLR
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLS001		10C10B SWITCH,D00R	S417N101 15438	1	33-26-11 1281/290/R022	ALL
YRLS002		60B50058-6 SWITCH,FLUSH TIMER LAV D	S417N101 81205	1	38-32-11 1281/290/R022	ALL
YRLS003		A20247AM1 SWITCH,CALL RESET	S417N101 81640	1	33-25-31 1281/290/R022	ALL
YRLS1M1		AML21KBA2AC-003 SWITCH,ATTEN CALL	S417N101 91929	1	33-25-31 1281/290/R022	001-099
YRLS1M1		AML21KBA2AC-002 SWITCH,ATTEN CALL	S417N101 91929	1	33-25-31 1281/290/R022	115-199
YRLS1M2		S283N202-1 DETECTOR,WASTE TANK OVERFILL	417N1017 81205	1	38-32-21 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLT001		Z3691-1 TRANSFORMER	S417N101 00614	1	25-41-01 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLT00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLV1M2		60B50341-1 VALVE-SHUT-OFF,TOILET FILL LINE	417N1017 81205	1	38-32-21 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLV00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRLXK01		HRTS-17KM SOCKET,RELAY	S417N101 91663	1	33-25-31 1281/290/R022	ALL
YRLXL01		BV03112N-40 SOCKET,FLUORESCENT	S417N101 17023	1	33-26-11 1281/290/R022	ALL
YRLXL02		BV03112N-40 SOCKET,FLUORESCENT	S417N101 17023	1	33-26-11 1281/290/R022	ALL

EQUIPMENT LIST

D280N032

Section YRLX
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRM++++		LRUOFM10013 MODULE-LAVATORY UTILITY	417N1107 81205	1	25-41-01 / /	115-199

EQUIPMENT LIST

D280N032

Section YRM+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMH001		60B50064-1 HEATER,WATER	S417N101 81205	1	38-13-11 0400/290/L022	115-199

EQUIPMENT LIST

D280N032

Section YRMH00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMJ001		BACC45FN24-43P RCPT-	S417N101 81205	1	25-41-01 379/290/L019	115-199
YRMJ002		BACC45FN14-7S RCPT-	S417N101 81205	1	25-41-01 379/290/L019	115-199
YRMJ003		BACC45FN14-15S RCPT-	S417N101 81205	1	25-41-01 379/290/L019	115-199
YRMJ004		48-7190 PLUG-	S417N101 02660	1	25-41-01 379/290/L019	115-199
YRMJ005		48-7191 RCPT-	S417N101 02660	1	25-41-01 379/290/L019	115-199

EQUIPMENT LIST

D280N032

Section YRMJ00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMK001		BACR13CD2 RELAY,CALL	S417N101 81205	1	33-25-31 0400/290/L022	115-199

EQUIPMENT LIST

D280N032

Section YRMK00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRML001		F15T12WW LAMP,FLUORESCENT	S417N101 08805	1	33-26-11 0400/290/L022	115-199
YRML002		F15T12WW LAMP,FLUORESCENT	S417N101 08805	1	33-26-11 0400/290/L022	115-199
YRML003		L18615-11-14 LAMP ASSY WITH LAMP 1691	S417N101 17744	1	33-26-11 0400/290/L022	115-199
YRML1M1		82003-11101 LAMP ASSY WITH TWO 387 LAMPS	S417N101 S5006	1	33-24-31 0400/290/L022	115-199

EQUIPMENT LIST

D280N032

Section YRML00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMLS01		PV5A-C8962 SPEAKER	S417N101 00614	1	25-41-01 0400/290/L022	115-199

EQUIPMENT LIST

D280N032

Section YRML
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMM001		2A122-0089-8 PANEL, UTILITY	S417N101 81205	1	25-41-01 0400/290/L022	115-199
YRMM002		S417N102-3 ASSY, FLUSHING TOILET	417N1112 81205	1	38-32-11 0379/290/L019	115-199
YRMM004		PU90-499 SMOKE DETECTOR-LAV F	S417N101 S5065	1	26-14-11 0379/290/L019	115-199

EQUIPMENT LIST

D280N032

Section YRMM00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMP002		BACC45FT14C7S PLUG-	S417N101 81205	1	25-41-01 379/290/L019	115-199
YRMP004		BACC45FT10C5S PLUG-	S417N101 81205	1	25-41-01 0379/290/L019	115-199
YRMP005		BACC45FT12C12S PLUG-	S417N101 81205	1	25-41-01 0379/290/L019	115-199
YRMP015		DAMA15SWS PLUG-	S417N101 71468	1	26-14-11 0379/290/L019	115-199
YRMP1M1		BACC45FT14-15P PLUG-	S417N101 81205	1	25-41-01 379/290/L019	115-199

EQUIPMENT LIST

D280N032

Section YRMP00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMRT01		60B40025-43 BALLAST	S417N101 81205	1	33-26-11 0400/290/L022	115-199

EQUIPMENT LIST

D280N032

Section YRMR

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMS001		10C10B SWITCH,DOOR	S417N101 15438	1	33-26-11 0400/290/L022	115-199
YRMS002		60B50058-6 SWITCH,FLUSH TIMER	S417N101 81205	1	38-32-11 0400/290/L022	115-199
YRMS003		A20247AM1 SWITCH,CALL RESET	S417N101 81640	1	33-25-31 0400/290/L022	115-199
YRMS1M1		AML21KBA2AC-002 SWITCH,ATTEN CALL	S417N101 91929	1	33-25-31 0400/290/L022	115-199
YRMS1M2		S283N202-1 DETECTOR,WASTE TANK OVERFILL	417N1017 81205	1	25-41-01 0379/290/L019	115-199

EQUIPMENT LIST

D280N032

Section YRMS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMT001		Z3691-1 TRANSFORMER	S417N101 00614	1	25-41-01 0400/290/L022	115-199

EQUIPMENT LIST

D280N032

Section YRMT00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMV1M2		60B50341-1 VALVE-SHUT-OFF,TOILET FILL LINE	417N1017 81205	1	25-41-01 0379/290/L019	115-199

EQUIPMENT LIST

D280N032

Section YRMV00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRMXK01		HRTS-17KM SOCKET,RELAY	S417N101 91663	1	33-25-31 0400/290/L022	115-199
YRMXL01		BV03112N-40 SOCKET,FLUORESCENT	S417N101 17023	1	33-26-11 0400/290/L022	115-199
YRMXL02		BV03112N-40 SOCKET,FLUORESCENT	S417N101 17023	1	33-26-11 0400/290/L022	115-199

EQUIPMENT LIST

D280N032

Section YRMX

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRT++++		LRUOFM10654 MODULE-LAVATORY UTILITY	417N101 81205	1	25-41-01 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRT+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTH001		60B50064-1 HEATER-WATER	S417N101 81205	1	38-13-11 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTH00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTJ001		BACC45FN24-43P RCPT-	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTJ002		BACC45FN14-7S RCPT-	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTJ003		BACC45FN14-15S RCPT-	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTJ004		48-7190 PLUG-	S417N101 02660	1	25-41-01 0656/290/L027	001-099
YRTJ005		48-7191 RCPT-	S417N101 02660	1	25-41-01 0656/290/L027	001-099
YRTJ007		XLR-5-31 RCPT-	S417N101 71468	1	25-41-01 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTJ00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTK001		BACR13CD2 RELAY-CALL	S417N101 81205	1	33-25-31 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTK00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTL001		F15T12WW LAMP-FLUORESCENT	S417N101 08805	1	33-26-11 0656/290/L027	001-099
YRTL002		F15T12WW LAMP-FLUORESCENT	S417N101 08805	1	33-26-11 0656/290/L027	001-099
YRTL003		L18615-11-14 LAMP ASSY WITH LAMP 1691IF	S417N101 17744	1	33-26-11 0656/290/L027	001-099
YRTL004		387 LAMP-	S417N101 08806	1	33-25-31 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTLS01		PV5A-C8962 SPEAKER	S417N101 00614	1	25-41-01 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTL
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTM001		2A122-0089-7 PANEL-UTILITY	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTM002		S417N102-6 ASSY,FLUSHING TOILET	417N1112 81205	1	38-32-11 0656/290/L027	001-099
YRTM004		PU90-499 SMOKE DETECTOR-LAV S	S417N101 S5065	1	26-14-11 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTM00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTP002		BACC45FT14C7S PLUG-	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTP004		BACC45FT10C5S PLUG-	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTP005		BACC45FT12C12S PLUG-	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTP006		BACC45FT10A5S PLUG-	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTP007		BACC63BN10A5P PLUG-	S417N101 81205	1	25-41-01 0656/290/L027	001-099
YRTP015		DAMA15SWS PLUG-	S417N101 71468	1	26-14-11 656/290/L027	001-099
YRTP1M1		BACC45FT14-15P PLUG-	S417N101 81205	1	25-41-01 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTP00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTRT01		60B40025-43 BALLAST	S417N101 81205	1	33-26-11 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTR
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTS001		10C10B SWITCH-DOOR	S417N101 15438	1	33-26-11 0656/290/L027	001-099
YRTS003		A20247AM1 SWITCH-CALL RESET	S417N101 81640	1	33-25-31 0656/290/L027	001-099
YRTS1M1		AML21KBA2AC-001 SWITCH-ATTEN CALL	S417N101 91929	1	33-25-31 0656/290/L027	001-099
YRTS1M2		S283N202-1 DETECTOR,WASTE TANK OVERFILL	417N1017 81205	1	38-32-21 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTT001		Z3691-1 TRANSFORMER	S417N101 00614	1	25-41-01 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTT00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTV1M2		60B50341-1 VALVE-SHUT-OFF,TOILET FILL LINE	417N1017 81205	1	38-32-21 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTV00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRTXK01		HRTS-17KM SOCKET-RELAY	S417N101 91663	1	33-25-31 0656/290/L027	001-099
YRTXL01		BV03112N-40 SOCKET-FLUORESCENT	S417N101 17023	1	33-26-11 0656/290/L027	001-099
YRTXL02		BV03112N-40 SOCKET-FLUORESCENT	S417N101 17023	1	33-26-11 0656/290/L027	001-099

EQUIPMENT LIST

D280N032

Section YRTX
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRU++++		LRUOFM10452 MODULE-FLT DK TEMP SNSR	215N1001 81205	1	21-61-11 0260/270/L020	ALL

EQUIPMENT LIST

D280N032

Section YRU+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRUC001		259P3349330T13 CAPACITOR-FLT DK TEMP SNSR MODULE	215N1001	1	21-61-11 / /	ALL

EQUIPMENT LIST

D280N032

Section YRUC00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRUM001		024116 FAN-FLT DK TEMP SNSR MODULE	215N1001 81205	1	21-61-11 / /	ALL

EQUIPMENT LIST

D280N032

Section YRUM00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRUTS01		S210T130-21 SENSOR-FLT DK TEMP SNSR MODULE	215N1001	1	21-61-11 / /	ALL
YRUTS02		1122027 BULB-FLT DK TEMP SNSR MODULE	215N1001 81205	1	21-61-11 / /	ALL

EQUIPMENT LIST

D280N032

Section YRUT
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRV++++		LRUOFM10024 MODULE-AFT CABIN TEMP SNSR	215N1001 81205	1	21-61-31 1210/280/R040	ALL

EQUIPMENT LIST

D280N032

Section YRV+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRVC001		259P3349330T13 CAPACITOR-AFT CABIN TEMP SNSR MODULE	215N1001	1	21-61-31 / /	ALL

EQUIPMENT LIST

D280N032

Section YRVC00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRVM001		024116 FAN-AFT CABIN TEMP SNSR MODULE	215N1001 81205	1	21-61-31 / /	ALL

EQUIPMENT LIST

D280N032

Section YRVM00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRVTS01		S210T130-21 SENSOR-AFT CABIN TEMP SNSR MODULE	215N1001	1	21-61-31 / /	ALL
YRVTS02		1122027 BULB-AFT CABIN TEMP SNSR MODULE	215N1001	1	21-61-31 / /	ALL

EQUIPMENT LIST

D280N032

Section YRVT
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRW++++		LRUOFM10025 MODULE-FWD CABIN TEMP SNSR	215N1001 81205	1	21-61-21 0545/278/R030	ALL

EQUIPMENT LIST

D280N032

Section YRW+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRWC001		259P3349330T13 CAPACITOR-FWD CABIN TEMP SNSR MODULE	215N1001	1	21-61-21 / /	ALL

EQUIPMENT LIST

D280N032

Section YRWC00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRWM001		024116 FAN-FWD CABIN TEMP SNSR MODULE	215N1001 81205	1	21-61-21 / /	ALL

EQUIPMENT LIST

D280N032

Section YRWM00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YRWTS01		S210T130-21 SENSOR-FWD CABIN TEMP SNSR MODULE	215N1001	1	21-61-21 / /	ALL
YRWTS02		1122027 BULB-FWD CABIN TEMP SNSR MODULE	215N1001 81205	1	21-61-21 / /	ALL

EQUIPMENT LIST

D280N032

Section YRWT
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YSNR001		WA03924A RHEOSTAT-PANEL/FLOOD LTS, GLARESHIELD	233N3214 55578	1	33-13-41 M10056/ /	ALL
YSNR002		200-26549-01 RHEOSTAT-PANEL/FLOOD LTS, AISLE STAND	233N3214 95266	1	33-13-51 M10056/ /	ALL

EQUIPMENT LIST

D280N032

Section YSNR00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YSNS001		MS25306-222 SW-RUNWAY TURNOFF,LEFT	233N3214 96906	1	33-42-21 M10056/ /	ALL
YSNS002		MS25306-222 SW-RUNWAY TURNOFF,RIGHT	233N3214 96906	1	33-42-21 M10056/ /	ALL
YSNS003		S231T290-5012 SWITCH LIGHT-LIGHTS,OVERIDE	233N3214 81205	1	33-11-31 M10056/ /	115-199
YSNS003	1	S231T290-4012 SWITCH LIGHT-LIGHTS,OVERIDE	233N3214 81205	1	33-11-31 M10056/ /	001-099
YSNS003	2	S231T290-5012 SWITCH LIGHT-LIGHTS,OVERIDE	233N3214 81205	1	33-11-31 M10056/ /	001-099
YSNS004		MS25306-222 SW-TAXI LIGHT	233N3214 96906	1	33-42-31 M10056/ /	001-099
YSNS03A		685 LAMP-	233N3214 08806	2	33-11-41 M10056/ /	ALL
YSNS03D		433-097-003 ASSEMBLY-CIRCUIT MODULE	233N3214 81590	1	33-11-41 M10056/ /	001-099
YSNS03T		685 LAMP-	233N3214 08806	2	33-11-31 M10056/ /	ALL

EQUIPMENT LIST

D280N032

Section YSNS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YSP001		BACC63BN12-12S PLUG-RHEOSTAT,CIRCUIT BREAKER PANEL LTS	233N3221 81205	1	33-13-61 M10057/ /	ALL

EQUIPMENT LIST

D280N032

Section YSP00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YSPR001		200-26550-01 RHEOSTAT-PANEL LTS,CIRCUIT BREAKER	233N3221 95266	1	33-13-61 M10057/ /	ALL
YSPR002		WA03923A RHEOSTAT-PANEL LTS,OVERHEAD	233N3221 55578	1	33-13-31 M10057/ /	ALL
YSPR003		RER60F1000R RESISTOR-DROPPING,AUX CKT BKR PNL FLOOD	233N3221 81205	1	33-11-61 M10057/ /	ALL

EQUIPMENT LIST

D280N032

Section YSPR00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YSPS001		S231T290-5077 SWITCH LIGHT-DOOR LOCK,FLIGHT DECK	233N3221 81205	1	52-51-11 M10057/ /	115-199
YSPS001	1	S231T290-4077 SWITCH LIGHT-DOOR LOCK,FLIGHT DECK	233N3221 81205	1	52-51-11 M10057/ /	001-099
YSPS001	2	S231T290-5077 SWITCH LIGHT-DOOR LOCK,FLIGHT DECK	233N3221 81205	1	52-51-11 M10057/ /	001-099
YSPS002		82PB19T2 SW-TEST,INDICATOR LIGHTS	233N3221 91929	1	33-16-11 M10057/ /	ALL
YSPS003	1	AC90-0002-2 SW-BRIGHT/DIM,INDICATOR LIGHTS	233N3221 91812	1	33-16-11 M10057/ /	ALL
YSPS003	2	AC90-0002-1 SW-BRIGHT/DIM,INDICATOR LIGHTS	233N3221 91812	1	33-16-11 M10057/ /	ALL
YSPS004		S231T290-4012 SWITCH LIGHT-LOGO LIGHTS	233N3221 81205	1	33-45-11 M10057/ /	001-099
YSPS004		S231T290-5012 SWITCH LIGHT-LOGO LIGHTS	233N3221 81205	1	33-45-11 M10057/ /	115-199
YSPS01A		387 LAMP-	233N3221 08806	2	52-51-11 M10057/ /	ALL
YSPS01B		685 LAMP-	233N3221 08806	2	52-51-11 M10057/ /	ALL
YSPS01D		851-30768-3823 MODULE-FUSE/DIODE	233N3221 96182	1	52-51-11 M10057/ /	115-199
YSPS01D	1	433-097-003 ASSEMBLY-CIRCUIT MODULE	233N3221 81590	1	52-51-11 M10057/ /	001-099
YSPS01D	2	851-30768-3823 MODULE-FUSE/DIODE	233N3221 96182	1	52-51-11 M10057/ /	001-099
YSPS04A		685 LAMP-	233N3221 08806	2	33-45-11 M10057/ /	ALL
YSPS04D		851-30768-3823 MODULE-FUSE/DIODE	233N3221 96182	1	33-45-11 M10057/ /	115-199
YSPS04D	1	433-097-003 ASSEMBLY-CIRCUIT MODULE	233N3221 81590	1	33-45-11 M10057/ /	001-099
YSPS04D	2	851-30768-3823 MODULE-FUSE/DIODE	233N3221 96182	1	33-45-11 M10057/ /	001-099

EQUIPMENT LIST

D280N032

Section YSPS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YSPT001		6430A TRANSFORMER-DIMMING,DOME LIGHTS	233N3221 95266	1	33-11-31 M10057/ /	ALL

EQUIPMENT LIST

D280N032

Section YSPT00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YSQD001	1	851-30768-3823 MODULE-DIODE/FUSE	233N3210 81205	1	35-21-11 P005-00/ /	001-099
YSQD001	2	433-097-001 MODULE-DIODE/FUSE	233N3210 81205	1	35-21-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YSQD00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YSQL001	1	387 LAMP-	233N3210 81205	2	35-21-11 P005-00/ /	001-099
YSQL001	2	387 LAMP-	233N3210 81205	2	35-21-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YSQL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTF++++		LRUOFM00162 PROX SW ELEC UNIT	S283T006 81205	1	32-09-11 E003-04/ /	ALL

EQUIPMENT LIST

D280N032

Section YTF+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTFM001	5	8-535-02 PROX CARD (SLOT 2,3,4,12,14,15)	S283T006 81205	6	32-09-11 E003-04/ /	ALL
YTFM001	1	8-535-04 PROX CARD (SLOT 2,3,4,12,14,15)	S283T006 81205	6	32-09-11 E003-04/ /	ALL
YTFM001	2	8-535-03 PROX CARD (SLOT 2,3,4,12,14,15)	S283T006 81205	6	32-09-11 E003-04/ /	ALL
YTFM001	3	8-356-06 PROX CARD (SLOT 2,3,4,12,14,15)	S283T006 81205	6	32-09-11 E003-04/ /	ALL
YTFM001	4	8-442-02 PROX CARD (SLOT 2,3,4,12,14,15)	S283T006 81205	6	32-09-11 E003-04/ /	ALL
YTFM002	1	8-632-02 LOGIC 1 CARD (SLOT 5,11)	S283T006 81205	2	32-09-11 E003-04/ /	ALL
YTFM002	2	8-632-01 LOGIC 1 CARD (SLOT 5,11)	S283T006 81205	2	32-09-11 E003-04/ /	ALL
YTFM002	3	8-417-04 LOGIC 1 CARD (SLOT 5,11)	S283T006 81205	2	32-09-11 E003-04/ /	ALL
YTFM003	1	8-351-07 DRIVER CARD (SLOT 6,7,10)	S283T006 81205	3	32-09-11 E003-04/ /	ALL
YTFM003	2	8-351-06 DRIVER CARD (SLOT 6,7,10)	S283T006 81205	3	32-09-11 E003-04/ /	ALL
YTFM003	3	8-351-05 DRIVER CARD (SLOT 6,7,10)	S283T006 81205	3	32-09-11 E003-04/ /	ALL
YTFM004	1	8-420-05 BITE MODULE (SLOT 8)	S283T006 81205	1	32-09-11 E003-04/ /	ALL
YTFM004	2	8-420-04 BITE MODULE (SLOT 8)	S283T006 81205	1	32-09-11 E003-04/ /	ALL
YTFM005	1	8-418-02 LOGIC 2 CARD (SLOT 9)	S283T006 81205	1	32-09-11 E003-04/ /	ALL
YTFM005	2	8-418-03 LOGIC 2 CARD (SLOT 9)	S283T006 81205	1	32-09-11 E003-04/ /	ALL

EQUIPMENT LIST

D280N032

Section YTFM00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTGL001		S231T300-1194 LT-INDICATOR (M10062)	233N3101 81205	1	24-33-11 P005-00/ /	ALL
YTGL002		S231T300-1291 LT-INDICATOR (M10062)	233N3101 81205	1	24-33-11 P005-00/ /	ALL
YTGL003		S231T300-1292 LT-INDICATOR (M10062)	233N3101 81205	1	24-33-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YTGL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTGS001		AC45-0036 SW-ROTARY (M10062)	233N3101 81205	1	24-33-11 P005-00/ /	ALL
YTGS002		S231T290-5024 LT-SWITCH (M10062)	233N3101 81205	1	24-33-11 P005-00/ /	115-199
YTGS002	1	S231T290-4024 LT-SWITCH (M10062)	233N3101 81205	1	24-33-11 P005-00/ /	001-099
YTGS002	2	S231T290-5024 LT-SWITCH (M10062)	233N3101 81205	1	24-33-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YTGS00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTHL005		S231T300-1021 LT-INDICATOR (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	ALL
YTHL006		S231T300-1021 LT-INDICATOR (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	ALL

EQUIPMENT LIST

D280N032

Section YTHL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTHS001		S231T290-5007 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS001	1	S231T290-4007 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS001	2	S231T290-5007 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS002		S231T290-5007 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS002	1	S231T290-4007 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS002	2	S231T290-5007 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS003		S231T290-5031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS003	1	S231T290-4031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS003	2	S231T290-5031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS004		S231T290-5031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS004	1	S231T290-4031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS004	2	S231T290-5031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS007		S231T290-5054 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS007	1	S231T290-4054 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS007	2	S231T290-5054 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS008		S231T290-5053 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS008	1	S231T290-4053 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YTHS00

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTHS008	2	S231T290-5053 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS009		S231T290-5064 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS009	1	S231T290-4064 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS009	2	S231T290-5064 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS010		S231T290-5064 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS010	1	S231T290-4064 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS010	2	S231T290-5064 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS011		S231T290-5031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS011	1	S231T290-4031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS011	2	S231T290-5031 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS012		S231T290-5045 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	115-199
YTHS012	1	S231T290-4045 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099
YTHS012	2	S231T290-5045 SW-LIGHT (M10063)	233N3101 81205	1	24-11-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YTHS00

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTQ++++		LRUOFM10720 MODULE-FLUOR LAMP/BALLAST(PRIMARY) ASSY	417N5016 72914	0	33-21-31 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section YTQ+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTQJ001		172168-1 PLUG-SIDEWALL LTS	417N5016 00779	1	33-21-31 MULTI/ /	ALL
YTQJ002		172160-1 RCPT-SIDEWALL LTS	417N5016 00779	1	33-21-31 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section YTQJ00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTQL001		F18T5WWRS LAMP-FLOUR/BALLAST(PRIMARY) ASSY	417N5016 08805	1	33-21-31 MULTI/ /	001-099

EQUIPMENT LIST

D280N032

Section YTQL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTR++++		LRUOFM10721 MODULE-FLOUR LAMP/BALLAST(SECONDARY)	417N5016 72914	0	33-21-31 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section YTR+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTRJ001		172168-1 PLUG-SIDEWALL LTS	417N5016 00779	1	33-21-31 MULTI/ /	ALL
YTRJ002		172160-1 RCPT-SIDEWALL LTS	417N5016 00779	1	33-21-31 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section YTRJ00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTRL001		F18T5WWRS LAMP-FLUOR/BALLAST(SECONDARY)	417N5016 08805	1	33-21-31 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section YTRL00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTS++++		LRUOFM10722 MODULE-FLUOR LAMP/BALLAST(SHORT SINGLE)	417N5016 72914	0	33-21-31 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section YTS+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTSJ001		172168-1 PLUG-SIDEWALL LTS	417N5016 00779	1	33-21-31 MULTI/ /	ALL
YTSJ002		172160-1 RCPT-SIDEWALL LTS	417N5016 00779	1	33-21-31 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section YTSJ00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTSL001		5106WW LAMP-FLUOR LAMP/BALLAST(SHORT SINGLE)	417N5016 08805	1	33-21-31 MULTI/ /	ALL

EQUIPMENT LIST

D280N032

Section YTSL00
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YTVS001	1	S231T290-4016 SW-LEFT SUPERVISORY	233T3242 81205	1	73-21-12 P005-00/ /	001-099
YTVS001	1	S231T290-5016 SW-LEFT SUPERVISORY	233T3242 81205	1	73-21-12 P005-00/ /	115-199
YTVS001	2	S231T290-5016 SW-LEFT SUPERVISORY	233T3242 81205	1	73-21-12 P005-00/ /	001-099
YTVS001	2	S231T290-3016 SW-LEFT SUPERVISORY	233T3242 81205	1	73-21-12 P005-00/ /	115-199
YTVS002	1	S231T290-4016 SW-RIGHT SUPERVISORY	233T3242 81205	1	73-21-22 P005-00/ /	001-099
YTVS002	1	S231T290-5016 SW-RIGHT SUPERVISORY	233T3242 81205	1	73-21-22 P005-00/ /	115-199
YTVS002	2	S231T290-5016 SW-RIGHT SUPERVISORY	233T3242 81205	1	73-21-22 P005-00/ /	001-099
YTVS002	2	S231T290-3016 SW-RIGHT SUPERVISORY	233T3242 81205	1	73-21-22 P005-00/ /	115-199

EQUIPMENT LIST

D280N032

Section YTVS00

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YWB++++		REPLUNITS MS6 ANTI-COLLISION & LDG LTS CONT PANEL	233N3101	1	33-44-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YWB+
Page 1 End
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YWBS001	1	S231T209-3012 SW-POSITION LTS	233T3217 81205	1	33-43-11 P005-00/ /	001-099
YWBS001	2	S231T209-1012 SW-POSITION LTS	233T3217 81205	1	33-43-11 P005-00/ /	001-099
YWBS002		A3-50 SW-LEFT WING LANDING LT	23373217 81640	1	33-42-11 P005-00/ /	001-099
YWBS003		A3-50 SW-RIGHT WING LANDING LT	23373217 81640	1	33-42-11 P005-00/ /	001-099
YWBS004		A3-1207 SW-NOSE GEAR LANDING LT	23373217 81640	1	33-42-11 P005-00/ /	001-099
YWBS005	1	S231T209-3012 SW-WHITE ANTI-COLLISION LTS	233T3217 81205	1	33-44-21 P005-00/ /	001-099
YWBS005	2	S231T209-1012 SW-WHITE ANTI-COLLISION LTS	233T3217 81205	1	33-44-21 P005-00/ /	001-099
YWBS006	1	S231T209-3012 SW-WING ILLUMINATION LTS	233T3217 81205	1	33-41-11 P005-00/ /	001-099
YWBS006	2	S231T209-1012 SW-WING ILLUMINATION LTS	233T3217 81205	1	33-41-11 P005-00/ /	001-099
YWBS007	1	S231T290-3012 SW-RED ANTI-COLLISION LTS	233T3217 81205	1	33-44-11 P005-00/ /	001-099
YWBS007	2	S231T290-1012 SW-RED ANTI-COLLISION LTS	233T3217 81205	1	33-44-11 P005-00/ /	001-099

EQUIPMENT LIST

D280N032

Section YWBS00

Page 1 End

Oct 09/2008