

91-21-31

SPLICE LIST

91-21-31
SPICE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			SP00400 cont.			SP01900	1	May 17/2006
	1	Oct 09/2008		2	Jan 21/2005		2	May 17/2006
	2	BLANK	SP00500	1	Jan 21/2005		3	May 17/2006
SP00000	1	May 17/2006		2	Jan 21/2005		4	May 17/2006
	2	May 17/2006		3	Jan 21/2005	SP02000	1	Jan 21/2005
	3	May 17/2006		4	Jan 21/2005	SP02100	1	Jan 21/2005
	4	May 17/2006	SP00600	1	Jan 21/2005	SP02200	1	Jan 21/2005
	5	May 17/2006	SP00700	1	Jan 21/2005	SP02500	1	Jan 21/2005
	6	May 17/2006	SP01000	1	Jan 21/2005	SP02600	1	Jan 21/2005
	7	May 17/2006		2	Jan 21/2005	SP02800	1	Jan 21/2005
SP00100	1	Jan 21/2005		3	Jan 21/2005	SP03000	1	Jan 21/2005
	2	Jan 21/2005		4	Jan 21/2005	A SP05000	1	Oct 09/2008
	3	Jan 21/2005	SP01100	1	Jan 21/2005	O SP26000	1	Oct 09/2008
	4	Jan 21/2005		2	Jan 21/2005	O SP27000	1	Oct 09/2008
	5	Jan 21/2005		3	Jan 21/2005	D	2	BLANK
	6	Jan 21/2005	SP01200	1	Jan 21/2005			
SP00200	1	Jan 21/2005		2	Jan 21/2005			
	2	Jan 21/2005	SP01300	1	Jan 21/2005			
	3	Jan 21/2005		2	Jan 21/2005			
	4	Jan 21/2005	SP01400	1	Jan 21/2005			
	5	Jan 21/2005	SP01500	1	Jan 21/2005			
	6	Jan 21/2005		2	Jan 21/2005			
SP00300	1	Jan 21/2005		3	Jan 21/2005			
	2	Jan 21/2005		4	Jan 21/2005			
	3	Jan 21/2005	SP01600	1	Jan 21/2005			
	4	Jan 21/2005	SP01700	1	Jan 21/2005			
	5	Jan 21/2005	SP01800	1	Jan 21/2005			
SP00400	1	Jan 21/2005		2	Jan 21/2005			

A = Added, R = Revised, D = Deleted, O = Overflow

SPICE LIST

D280N032

EFFECTIVE PAGES

Page 1
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00001		1680/300/					ALL
	W3133	0009	20		9	23-11-11	ALL
	W3135	0010	20		9	23-11-21	001-099
	W3135	0010	20		9	23-11-11	115-199
SP00003		1681/299/R001					ALL
	W3133	0010	20		9	23-11-11	ALL
	W3135	0009	20		9	23-11-21	001-099
	W3135	0009	20		9	23-11-11	115-199
SP00006		435/295/R010					001-099
SP00006		435/295/R008					115-199
	W3572	0123	20		9	33-25-21	001-099
	W3572	0176	20		9	33-25-21	115-199
	W3802	0805	22		9	33-25-21	ALL
	W3802	0825	22		9	33-25-23	ALL
SP00011		520/200/L004					ALL
	W2604	0010	18		9	29-32-11	ALL
	W4473	0181	22		9	29-32-11	ALL
SP00017		225/174/R020					ALL
	W2357	0056Y	22		9	27-41-21	ALL
	W2357	A-B			9	27-41-21	ALL
SP00019		225/174/R020					ALL
	W2357	0058Y	22		9	27-41-21	ALL
	W2357	C-B			9	27-41-21	ALL
SP00021		225/174/R020					ALL
	W2357	0060Y	22		9	27-41-21	ALL
	W2357	A-A			9	27-41-21	ALL
SP00023		225/174/R020					ALL
	W2357	0062Y	22		9	27-41-21	ALL
	W2357	C-A			9	27-41-21	ALL
SP00024		268/150/R020					ALL
	W2052	2001R	20		9	32-61-13	ALL
	W2052	A-H			9	32-61-13	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00000

Page 1

May 17/2006

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00025		225/174/R020					ALL
	W2355	0096Y	22		9	27-41-11	ALL
	W2355	B-B			9	27-41-11	ALL
SP00026		268/150/R020					ALL
	W2052	2001B	20		9	32-61-13	ALL
	W2052	A-G			9	32-61-13	ALL
SP00027		225/198/R020					ALL
	W2355	0098Y	22		9	27-41-11	ALL
	W2355	D-B			9	27-41-11	ALL
SP00028		390/192/R002					ALL
	W2052	2002R	20		9	32-61-22	ALL
	W2052	A-D			9	32-61-22	ALL
SP00029		225/174/R020					ALL
	W2355	0100Y	22		9	27-41-11	ALL
	W2355	B-A			9	27-41-11	ALL
SP00030		390/192/R002					ALL
	W2052	2002B	20		9	32-61-22	ALL
	W2052	A-C			9	32-61-22	ALL
SP00031		225/174/R020					ALL
	W2355	0102Y	22		9	27-41-11	ALL
	W2355	D-A			9	27-41-11	ALL
SP00032		360/178/L020					ALL
	W2052	2003R	20		9	32-61-22	ALL
	W2052	A-F			9	32-61-22	ALL
SP00034		360/178/L020					ALL
	W2052	2003B	20		9	32-61-22	ALL
	W2052	A-E			9	32-61-22	ALL
SP00035		1068/140/L065					ALL
	W2416	1028	18		9	32-12-12	ALL
	W2416	A-AE			9	32-12-12	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00036		360/178/L020					ALL
	W2052	2004R	20		9	32-61-13	ALL
	W2052	A-B			9	32-61-13	ALL
SP00037		1065/145/R060					001-099
SP00037		1068/140/R065					115-199
	W2516	1023	18		9	32-12-12	ALL
	W2516	A-AE			9	32-12-12	ALL
SP00038		360/178/L020					ALL
	W2052	2004B	20		9	32-61-13	ALL
	W2052	A-A			9	32-61-13	ALL
SP00040		395/192/R002					ALL
	W2152	2001B	20		9	32-61-22	ALL
	W2152	A-C			9	32-61-22	ALL
SP00042		395/192/R002					ALL
	W2152	2001R	20		9	32-61-22	ALL
	W2152	A-D			9	32-61-22	ALL
SP00043		IRSS253/ /					115-199
	W3306	0016	20		9	28-41-21	115-199
	W5100	1008	20		9	28-41-21	115-199
	W5100	1008Z				28-41-21	115-199
	W5100	FRAP				28-41-21	115-199
SP00044		360/190/L020					ALL
	W2152	2002B	20		9	32-61-22	ALL
	W2152	A-A			9	32-61-22	ALL
SP00046		360/190/L020					ALL
	W2152	2002R	20		9	32-61-22	ALL
	W2152	A-B			9	32-61-22	ALL
SP00048		1395/198/R060					ALL
	W2632	2001R	24		9	52-35-11	ALL
	W2632	A-RD			9	52-35-11	ALL

SPlice LIST

D280N032

91-21-31

Section SP00000

Page 3

May 17/2006

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00050		340/210/L070					ALL
	W3576	0049	24		9	33-22-11	001-099
	W3576	0049	22		9	33-22-11	115-199
	W3582	0003	20		9	25-66-11	ALL
	W3582	0009	20		9	25-66-11	115-199
	W3582	A-PA			9	25-66-11	ALL
SP00052		377/210/L070					ALL
	W3582	0012	20		9	25-66-11	ALL
	W3582	B-PA			9	25-66-11	ALL
SP00053		1040/160/R020					ALL
	W2416	1032	18		9	32-12-12	ALL
	W2516	1032	18		9	32-12-12	ALL
SP00054		1395/198/R060					ALL
	W2632	2001B	24		9	52-35-11	ALL
	W2632	A-BL			9	52-35-11	ALL
SP00056		677/211/L069					ALL
	W3582	0006	20		9	25-66-11	ALL
	W3582	0010	20		9	25-66-11	115-199
	W3582	C-PA			9	25-66-11	ALL
SP00057		377/174/R56					115-199
	W2150	2502B	20		9	23-71-11	115-199
	W2351	2505B	24		9	23-71-11	115-199
SP00058		735/212/L070					ALL
	W3582	0013	20		9	25-66-11	ALL
	W3582	D-PA			9	25-66-11	ALL
SP00059		377/174/R56					115-199
	W2150	2502R	20		9	23-71-11	115-199
	W2351	2505R	24		9	23-71-11	115-199
SP00060		1645/210/L064					ALL
	W3582	0008	20		9	25-66-11	ALL
	W3582	0011	20		9	25-66-11	115-199
	W3582	E-PA			9	25-66-11	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00000

Page 4

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00061		377/174/R56					115-199
	W2150	2502Z			9	23-71-11	115-199
	W2351	2505Z			9	23-71-11	115-199
SP00062		1685/210/L061					ALL
	W3582	0014	20		9	25-66-11	ALL
	W3582	F-PA			9	25-66-11	ALL
SP00064		1886/225/L013					ALL
	W2822	0005	20		9	33-31-31	ALL
	W2822	A-H			9	33-31-31	ALL
SP00065		377/174/R56					115-199
	W2150	2501R	20		9	23-71-11	115-199
	W2351	2506R	24		9	23-71-11	115-199
SP00067		377/174/R56					115-199
	W2150	2501B	20		9	23-71-11	115-199
	W2351	2506B	24		9	23-71-11	115-199
SP00068		327/210/R066					ALL
	W3682	0003	20		9	25-66-11	ALL
	W3682	0009	20		9	25-66-11	115-199
	W3682	A-PA			9	25-66-11	ALL
SP00069		377/174/R56					115-199
	W2150	2501Z			9	23-71-11	115-199
	W2351	2506Z			9	23-71-11	115-199
SP00070		362/210/R070					ALL
	W3682	0012	20		9	25-66-11	ALL
	W3682	B-PA			9	25-66-11	ALL
SP00074		690/210/R070					ALL
	W3682	0006	20		9	25-66-11	ALL
	W3682	0010	20		9	25-66-11	115-199
	W3682	C-PA			9	25-66-11	ALL
SP00075		200/175/L002					ALL
	W2355	0103	24		9	24-22-22	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00000

Page 5

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00075		200/175/L002 (continued)					ALL
	W2355	0104	24		9	24-22-22	ALL
	W2357	0107	24		9	24-22-22	ALL
SP00076		730/210/R070					ALL
	W3682	0013	20		9	25-66-11	ALL
	W3682	D-PA			9	25-66-11	ALL
SP00078		1620/314/R023					ALL
	W3682	0008	20		9	25-66-11	ALL
	W3682	0011	20		9	25-66-11	115-199
	W3682	E-PA			9	25-66-11	ALL
SP00080		1678/210/R070					ALL
	W3682	0014	20		9	25-66-11	ALL
	W3682	F-PA			9	25-66-11	ALL
SP00081		415/156/L022					ALL
	W2602	0018	18		9	33-31-21	ALL
	W2608	0012	18		9	33-31-21	ALL
SP00083		860/203/L026					ALL
	W2608	0012	18		9	33-31-21	ALL
	W2608	0013	18		9	33-31-21	ALL
	W4006	0035	18		9	33-31-21	ALL
SP00084		575/198/R068					ALL
	W4104	2001R	22		9	52-34-11	ALL
	W4104	A-RD			9	52-34-11	ALL
SP00085		200/175/L005					115-199
	W2070	0093	24		9	21-31-21	115-199
	W2357	0109	24		9	21-31-21	115-199
SP00086		575/198/R068					ALL
	W4104	2001B	22		9	52-34-11	ALL
	W4104	A-BL			9	52-34-11	ALL
SP00087		1210/145/L060					ALL
	W2608	0014	18		9	33-31-21	ALL

SPLICE LIST
D280N032

91-21-31
Section SP00000
Page 6
May 17/2006

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00087		1210/145/L060 (continued)					ALL
	W2608	A-AB			9	33-31-21	ALL
	W2608	A-AC			9	33-31-21	ALL
SP00092		560/165/R045					ALL
	W4104	2003R	22		9	52-34-11	ALL
	W4104	C-RD			9	52-34-11	ALL
SP00094		560/165/R045					ALL
	W4104	2003B	22		9	52-34-11	ALL
	W4104	C-BL			9	52-34-11	ALL
SP00099		512/175/R040					ALL
	W2606	0010	18		9	29-32-21	ALL
	W4106	0163	22		9	29-32-21	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00000

Page 7 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00100		1378/155/R045					ALL
	W2632	2003R	24		9	52-35-11	ALL
	W2632	C-RD			9	52-35-11	ALL
SP00102		1378/155/R045					ALL
	W2632	2003B	24		9	52-35-11	ALL
	W2632	C-BL			9	52-35-11	ALL
SP00107		263/190/					ALL
	W2295	0008	24		9	23-51-21	ALL
	W2297	0008	24		9	23-51-11	115-199
	W2297	0022	24		9	23-51-11	001-099
SP00108		1886/225/L013					ALL
	W2822	0006	20		9	33-31-31	ALL
	W2822	A-J			9	33-31-31	ALL
SP00130		230/156/L005					ALL
	W3582	2001R	24		9	52-71-11	001-099
	W3582	2001R	20		9	52-71-11	115-199
	W3582	G-PA			9	52-71-11	ALL
SP00132		230/156/L005					ALL
	W3582	2001B	24		9	52-71-11	001-099
	W3582	2001B	20		9	52-71-11	115-199
	W3582	G-GA			9	52-71-11	ALL
SP00134		376/270/L059					ALL
	W3582	2002R	24		9	52-71-11	001-099
	W3582	2002R	20		9	52-71-11	115-199
	W3582	H-PA			9	52-71-11	ALL
SP00136		376/270/L059					ALL
	W3582	2002B	24		9	52-71-11	001-099
	W3582	2002B	20		9	52-71-11	115-199
	W3582	H-GA			9	52-71-11	ALL
SP00138		470/151/R010					ALL
	W3582	2003R	24		9	52-71-11	001-099
	W3582	2003R	20		9	52-71-11	115-199

SPLICE LIST
D280N032

91-21-31
Section SP00100
Page 1
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00138		470/151/R010 (continued)					ALL
	W3582	J-PA			9	52-71-11	ALL
SP00140		470/151/R010					ALL
	W3582	2003B	24		9	52-71-11	001-099
	W3582	2003B	20		9	52-71-11	115-199
	W3582	J-GA			9	52-71-11	ALL
SP00142		735/277/L057					ALL
	W3582	2004R	24		9	52-71-11	001-099
	W3582	2004R	20		9	52-71-11	115-199
	W3582	K-PA			9	52-71-11	ALL
SP00144		735/277/L057					ALL
	W3582	2004B	24		9	52-71-11	001-099
	W3582	2004B	20		9	52-71-11	115-199
	W3582	K-GA			9	52-71-11	ALL
SP00146		1320/225/L073					ALL
	W3582	2005R	24		9	52-71-11	001-099
	W3582	2005R	20		9	52-71-11	115-199
	W3582	L-PA			9	52-71-11	ALL
SP00148		1320/225/L073					ALL
	W3582	2005B	24		9	52-71-11	001-099
	W3582	2005B	20		9	52-71-11	115-199
	W3582	L-GA			9	52-71-11	ALL
SP00150		1685/215/L064					ALL
	W3582	2006R	24		9	52-71-11	001-099
	W3582	2006R	20		9	52-71-11	115-199
	W3582	M-PA			9	52-71-11	ALL
SP00152		1685/215/L064					ALL
	W3582	2006B	24		9	52-71-11	001-099
	W3582	2006B	20		9	52-71-11	115-199
	W3582	M-GA			9	52-71-11	ALL
SP00154		327/288/R070					ALL
	W3682	2001R	24		9	52-71-21	001-099

SPLICE LIST

D280N032

91-21-31

Section SP00100

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00154		327/288/R070 (continued)					ALL
	W3682	2001R	20		9	52-71-21	115-199
	W3682	G-PA			9	52-71-21	ALL
SP00156		327/288/R070					ALL
	W3682	2001B	24		9	52-71-21	001-099
	W3682	2001B	20		9	52-71-21	115-199
	W3682	G-GA			9	52-71-21	ALL
SP00158		730/270/R062					ALL
	W3682	2002R	24		9	52-71-21	001-099
	W3682	2002R	20		9	52-71-21	115-199
	W3682	H-PA			9	52-71-21	ALL
SP00160		730/270/R062					ALL
	W3682	2002B	24		9	52-71-21	001-099
	W3682	2002B	20		9	52-71-21	115-199
	W3682	H-GA			9	52-71-21	ALL
SP00162		1320/225/R073					ALL
	W3682	2003R	24		9	52-71-21	001-099
	W3682	2003R	20		9	52-71-21	115-199
	W3682	J-PA			9	52-71-21	ALL
SP00164		1320/225/R073					ALL
	W3682	2003B	24		9	52-71-21	001-099
	W3682	2003B	20		9	52-71-21	115-199
	W3682	J-GA			9	52-71-21	ALL
SP00165		225/174/L020					ALL
	W2355	0101Y	22		9	27-41-11	ALL
	W2355	C-A			9	27-41-11	ALL
SP00166		1690/230/R070					ALL
	W3682	2004R	24		9	52-71-21	001-099
	W3682	2004R	20		9	52-71-21	115-199
	W3682	K-PA			9	52-71-21	ALL
SP00167		225/174/L020					ALL
	W2355	0097Y	22		9	27-41-11	ALL

SPLICE LIST
D280N032

91-21-31
Section SP00100
Page 3
Jan 21/2005

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00167		225/174/L020 (continued)					ALL
	W2355	C-B			9	27-41-11	ALL
SP00168		1690/230/R070					ALL
	W3682	2004B	24		9	52-71-21	001-099
	W3682	2004B	20		9	52-71-21	115-199
	W3682	K-GA			9	52-71-21	ALL
SP00169		225/174/L020					ALL
	W2355	0095Y	22		9	27-41-11	ALL
	W2355	A-B			9	27-41-11	ALL
SP00170		585/198/R045					ALL
	W4104	2005R	24		9	52-71-21	ALL
	W4104	E-RD			9	52-71-21	ALL
SP00171		225/174/L020					ALL
	W2355	0099Y	22		9	27-41-11	ALL
	W2355	A-A			9	27-41-11	ALL
SP00172		585/198/R045					ALL
	W4104	2005B	24		9	52-71-21	ALL
	W4104	E-BL			9	52-71-21	ALL
SP00173		223/186/L023					ALL
	W2045	0001	22		9	27-32-11	ALL
	W2355	0032	22		9	27-32-11	ALL
SP00174		1410/198/R060					ALL
	W2632	2005B	24		9	52-71-21	ALL
	W2632	G-BL			9	52-71-21	ALL
SP00175		223/186/L023					ALL
	W2045	0002	22		9	27-32-11	ALL
	W2355	0033	22		9	27-32-11	ALL
SP00176		1410/198/R060					ALL
	W2632	2005R	24		9	52-71-21	ALL
	W2632	G-RD			9	52-71-21	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00100

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00177		225/174/L020					ALL
	W2357	0061Y	22		9	27-41-21	ALL
	W2357	D-A			9	27-41-21	ALL
SP00178		630/175/R055					ALL
	W0816	0001	22		9	52-34-11	ALL
	W4104	0050	22		9	52-34-11	ALL
SP00179		225/174/L020					ALL
	W2357	0057Y	22		9	27-41-21	ALL
	W2357	D-B			9	27-41-21	ALL
SP00180		630/173/R050					ALL
	W0816	0004	22		9	52-34-11	ALL
	W4162	0033	22		9	52-34-11	ALL
SP00181		225/174/L020					ALL
	W2357	0055Y	22		9	27-41-21	ALL
	W2357	B-B			9	27-41-21	ALL
SP00182		630/175/R055					ALL
	W0816	0003	22		9	52-34-11	ALL
	W4104	0048	22		9	52-34-11	ALL
	W4162	0045	22		9	52-34-11	ALL
SP00183		225/174/L020					ALL
	W2357	0059Y	22		9	27-41-21	ALL
	W2357	B-A			9	27-41-21	ALL
SP00184		1450/178/R060					ALL
	W1016	0003	22		9	52-35-11	ALL
	W2632	0230	22		9	52-35-11	001-099
	W2662	0054	22		9	52-35-11	ALL
	W2716	0230	22		9	52-35-11	115-199
SP00185		225/180/R020					ALL
	W2055	0001	22		9	27-32-21	ALL
	W2357	0026	22		9	27-32-21	ALL

SPLICE LIST
D280N032

91-21-31
Section SP00100
Page 5
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00186		1450/180/R068					ALL
	W1016	0001	22		9	52-35-11	ALL
	W2632	0231	22		9	52-35-11	001-099
	W2716	0231	22		9	52-35-11	115-199
SP00187		225/180/R020					ALL
	W2055	0002	22		9	27-32-21	ALL
	W2357	0027	22		9	27-32-21	ALL
SP00188		1450/178/R060					ALL
	W1016	0004	22		9	52-35-11	ALL
	W2662	0037	22		9	52-35-11	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00100

Page 6 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00201		520/195/R025					ALL
	W4162	0019	18		9	33-37-11	ALL
	W4162	A-PA			9	33-37-11	ALL
SP00202		1301/196/R050					115-199
	W2662	0010	20		9	25-51-21	115-199
	W2662	B-RD			9	25-51-21	115-199
SP00204		1886/235/R023					ALL
	W2654	0030	20		9	33-31-31	ALL
	W2818	0008	20		9	33-31-31	ALL
SP00205		229/212/R024					ALL
	W0001	0310	20		W	33-11-21	ALL
	W0003	0300	20		W	33-11-21	ALL
	W0003	0316	20		W	33-11-21	ALL
SP00206		1820/280/R010					ALL
	W2654	0028	20		9	49-61-14	ALL
	W2654	A-A			9	49-61-14	ALL
SP00207		229/212/R024					ALL
	W0001	0149	20		W	33-13-12	ALL
	W0001	0151	20		W	33-13-12	ALL
	W0001	0154	20		W	33-13-12	ALL
	W0003	0150	20		W	33-13-21	ALL
	W0003	0197	20		W	33-13-21	ALL
	W0003	0203	20		W	33-13-21	ALL
	W0003	0437	20		W	33-13-21	ALL
	W0003	0605	20		W	33-13-21	002
SP00208		524/230/R070					115-199
	W2650	0001	22		9	24-22-41	115-199
	W4018	0012	22		9	24-22-41	115-199
SP00209		229/212/R024					ALL
	W0003	0135	20		9	33-13-41	ALL
	W0003	0137	20		9	33-13-41	ALL
	W2051	0021	20		9	33-13-41	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00200

Page 1

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00211		229/212/L024					ALL
	W0003	0488	20		W	33-13-41	ALL
	W2041	0022	20		W	33-13-41	ALL
SP00213		229/212/L024					ALL
	W0003	0138	20		W	33-13-41	ALL
	W2061	0006	20		W	33-13-41	ALL
SP00215		229/212/R024					ALL
	W0001	0205	20		W	33-13-41	ALL
	W0003	0139	20		W	33-13-41	ALL
	W0003	0485	20		W	33-13-41	ALL
SP00217		229/212/R024					ALL
	W0001	0484	20		W	33-13-41	ALL
	W0003	0484	20		W	33-13-41	ALL
SP00226		365/203/R038					ALL
	W4086	0007	18		9	33-31-41	ALL
	W4086	0009	18		9	33-31-41	ALL
	W4086	A-A			9	33-31-41	ALL
SP00228		418/202/R010					ALL
	W4086	0009	18		9	33-31-41	ALL
	W4086	0010	18		9	33-31-41	ALL
	W4086	A-B			9	33-31-41	ALL
SP00230		418/202/L010					ALL
	W4086	0010	18		9	33-31-41	ALL
	W4086	0011	18		9	33-31-41	ALL
	W4086	A-C			9	33-31-41	ALL
SP00232		418/202/L024					ALL
	W4086	0011	18		9	33-31-41	ALL
	W4086	A-D			9	33-31-41	ALL
SP00234		460/195/L002					ALL
	W4086	0008	18		9	33-31-41	ALL
	W4086	0012	18		9	33-31-41	ALL
	W4086	0014	18		9	33-31-41	ALL

SPlice LIST

D280N032

91-21-31

Section SP00200

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00234		460/195/L002 (continued)					ALL
	W4086	A-E			9	33-31-41	ALL
SP00236		468/195/R024					ALL
	W4086	0012	18		9	33-31-41	ALL
	W4086	A-F			9	33-31-41	ALL
SP00238		468/195/L024					ALL
	W4086	0014	18		9	33-31-41	ALL
	W4086	A-G			9	33-31-41	ALL
SP00246		230/197/R002					ALL
	W2356	0056	20		9	33-31-41	001-099
	W2356	0057	20		9	33-31-41	001-099
	W2356	0058	20		9	33-31-41	001-099
	W2356	A-K			9	33-31-41	001-099
	W4086	0003	20		9	33-31-41	115-199
	W4086	0004	20		9	33-31-41	115-199
	W4086	0005	20		9	33-31-41	115-199
	W4086	A-K			9	33-31-41	115-199
SP00248		257/202/L020					ALL
	W2356	0057	20		9	33-31-41	001-099
	W2356	A-L			9	33-31-41	001-099
	W4086	0004	20		9	33-31-41	115-199
	W4086	A-L			9	33-31-41	115-199
SP00250		257/202/R029					ALL
	W2356	0058	20		9	33-31-41	001-099
	W2356	A-M			9	33-31-41	001-099
	W4086	0005	20		9	33-31-41	115-199
	W4086	A-M			9	33-31-41	115-199
SP00252		E006-00/ /					ALL
	W0818	0007	16		9	33-37-11	ALL
	W0818	A-A			9	33-37-11	ALL
SP00254		E006-00/ /					ALL
	W0818	0006	16		9	33-37-11	ALL
	W0818	0007	16		9	33-37-11	ALL

SPLICE LIST
D280N032

91-21-31
Section SP00200
Page 3
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00254		E006-00/ / (continued)					ALL
	W0818	A-B			9	33-37-11	ALL
SP00256		E006-00/ /					ALL
	W0818	0010	16		9	33-37-11	ALL
	W0818	B-B			9	33-37-11	ALL
SP00258		E006-00/ /					ALL
	W0818	0005	16		9	33-37-11	ALL
	W0818	0006	16		9	33-37-11	ALL
	W0818	A-C			9	33-37-11	ALL
SP00260		E006-00/ /					ALL
	W0818	0004	16		9	33-37-11	ALL
	W0818	A-D			9	33-37-11	ALL
SP00262		E006-00/ /					ALL
	W0818	0015	16		9	33-37-11	ALL
	W0818	B-E			9	33-37-11	ALL
SP00264		E006-00/ /					ALL
	W0818	0003	16		9	33-37-11	ALL
	W0818	0004	16		9	33-37-11	ALL
	W0818	0005	16		9	33-37-11	ALL
	W0818	A-E			9	33-37-11	ALL
SP00266		E008-00/ /					ALL
	W1018	0007	16		9	33-37-21	ALL
	W1018	A-A			9	33-37-21	ALL
SP00268		E006-00/ /					ALL
	W1018	0006	16		9	33-37-21	ALL
	W1018	0007	16		9	33-37-21	ALL
	W1018	A-B			9	33-37-21	ALL
SP00270		E006-00/ /					ALL
	W1018	0010	16		9	33-37-21	ALL
	W1018	B-B			9	33-37-21	ALL

SPlice LIST

D280N032

91-21-31

Section SP00200

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00272		E006-00/ /					ALL
	W1018	0005	16		9	33-37-21	ALL
	W1018	0006	16		9	33-37-21	ALL
	W1018	A-C			9	33-37-21	ALL
SP00274		E006-00/ /					ALL
	W1018	0004	16		9	33-37-21	ALL
	W1018	A-D			9	33-37-21	ALL
SP00276		E006-00/ /					ALL
	W1018	0015	16		9	33-37-21	ALL
	W1018	B-E			9	33-37-21	ALL
SP00277		425/157/L017					001-099
	W4104	0077	20		9	30-71-21	001-099
	W4104	0082	20		9	30-71-21	001-099
	W4104	E-PR			9	30-71-21	001-099
	W4104	G-PR			9	30-71-21	001-099
SP00278		E006-00/ /					ALL
	W1018	0003	16		9	33-37-21	ALL
	W1018	0004	16		9	33-37-21	ALL
	W1018	0005	16		9	33-37-21	ALL
	W1018	A-E			9	33-37-21	ALL
SP00279		425/157/L017					001-099
	W4104	B-WT			9	30-71-21	001-099
	W4104	C-BK			9	30-71-21	001-099
SP00283		710/190/L043					001-099
	W4104	I-BK			9	30-71-21	001-099
	W4104	L-GD			9	30-71-21	001-099
SP00285		710/190/L043					001-099
	W4104	0082	20		9	30-71-21	001-099
	W4104	0085	20		9	SPARE	001
	W4104	0085	20		Y	SPARE	001
	W4104	0085	20		9	30-71-21	002-099
	W4104	I-PR			9	30-71-21	001-099
	W4104	K-PR			9	30-71-21	001-099

SPLICE LIST
D280N032

91-21-31
Section SP00200
Page 5
Jan 21/2005

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00286		1235/295/R025					ALL
	W3534	0008	24		9	33-51-14	ALL
	W3534	0035	22		9	33-51-14	ALL
	W3634	0008	24		9	33-51-14	ALL
	W3634	0508	24		9	33-51-14	ALL
	W3672	0083	24		9	33-51-14	ALL
SP00290		705/300/R020					ALL
	W3532	0037	22		9	33-51-13	ALL
	W3532	0108	24		9	33-51-13	ALL
	W3632	0108	24		9	33-51-13	ALL
	W3632	0708	24		9	33-51-14	001-099
	W3672	0082	24		9	33-51-13	001-099
	W3672	0082	22		9	33-51-13	115-199
SP00294		1664/297/R007					ALL
	W3534	0037	22		9	33-51-15	ALL
	W3534	0108	24		9	33-51-15	ALL
	W3634	0108	24		9	33-51-15	ALL
	W3672	0085	24		9	33-51-15	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00200

Page 6 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00300		1040/145/R010					ALL
	W2416	1009	18		9	26-17-11	ALL
	W2514	1002	18		9	26-17-11	ALL
SP00302		705/300/R020					ALL
	W3632	0110	22		9	33-51-13	115-199
	W3632	0113	20		9	33-51-13	001-099
	W3672	0123	20		9	33-51-13	001-099
	W3672	0123	22		9	33-51-13	115-199
SP00306		1664/297/R007					ALL
	W3534	0110	20		9	33-51-15	115-199
	W3634	0113	20		9	33-51-15	001-099
	W3672	0127	20		9	33-51-15	ALL
SP00308		1727/247/L030					ALL
	W2818	0009	20		9	33-31-31	ALL
	W2818	A-AP			9	33-31-31	ALL
SP00310		1828/286/R001					ALL
	W2818	0010	20		9	33-31-31	ALL
	W2818	0015	20		9	33-31-31	ALL
	W2818	0019	20		9	33-31-31	ALL
	W2818	B-BP			9	33-31-31	ALL
SP00313		1064/202/L062					ALL
	W2646	2504R	20		9	32-09-12	ALL
	W4206	2001R	20		9	32-09-12	ALL
SP00315		1064/202/L062					ALL
	W2646	2504B	20		9	32-09-12	ALL
	W2646	2504Z			9	32-09-12	ALL
	W4206	2001B	20		9	32-09-12	ALL
SP00317		1063/203/R064					001-099
SP00317		1062/200/R060					115-199
	W2648	2503B	20		9	32-09-12	ALL
	W2648	2503Z			9	32-09-12	ALL
	W4216	2013B	20		9	32-09-12	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00300

Page 1

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00318		960/160/R048					ALL
	W2506	1009	18		9	33-31-21	ALL
	W2506	A-BK			9	33-31-21	ALL
SP00319		1063/203/R064					001-099
SP00319		1062/200/R060					115-199
	W2648	2503R	20		9	32-09-12	ALL
	W4216	2013R	20		9	32-09-12	ALL
SP00323		860/150/L005					002-099
	W4104	0085	20		9	30-71-21	002-099
	W4104	T-BK			9	30-71-21	002-099
SP00325		280/230/R035					115-199
	W0041	3501B	24		9	23-51-51	115-199
	W0041	B-BL			9	23-51-51	115-199
	W0041	C-BL			9	23-51-51	115-199
SP00326		882/133/L010					001-099
SP00326		880/130/L007					115-199
	W2506	1003	20		9	30-71-11	ALL
	W2506	A-PR			9	30-71-11	ALL
	W2506	C-PN			9	30-71-11	ALL
SP00327		280/230/R035					115-199
	W0041	3501R	24		9	23-51-51	115-199
	W0041	3501Z				23-51-51	115-199
	W0041	C-RD			9	23-51-51	115-199
SP00329		280/230/R035					115-199
	W0041	3501Y	24		9	23-51-51	115-199
	W0041	B-BK			9	23-51-51	115-199
	W0041	C-BK			9	23-51-51	115-199
SP00332		970/160/L031					001-099
SP00332		940/145/L035					115-199
	W2406	1008	18		9	33-31-21	ALL
	W2406	A-BK			9	33-31-21	ALL

SPlice LIST

D280N032

91-21-31

Section SP00300

Page 2

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00334		1863/274/L005					ALL
	W2818	0019	20		9	33-31-31	ALL
	W2818	B-CP			9	33-31-31	ALL
SP00336		1886/230/R019					ALL
	W2822	0003	20		9	33-31-31	ALL
	W2822	0005	20		9	33-31-31	ALL
	W2822	0007	20		9	33-31-31	ALL
	W2822	A-B			9	33-31-31	ALL
SP00338		1045/145/R010					ALL
	W2414	1001	18		9	32-12-12	ALL
	W2512	1015	18		9	32-12-12	ALL
	W2512	1016	18		9	32-12-12	ALL
SP00339		492/192/R051					001-099
	W3576	0144	22		9	23-31-19	001-099
	W4477	0057	22		9	23-31-19	001-099
SP00342		E006-00/ /					ALL
	W0818	0008	16		9	33-37-11	ALL
	W0818	B-A			9	33-37-11	ALL
SP00344		E006-00/ /					ALL
	W0818	0012	16		9	33-37-11	ALL
	W0818	B-C			9	33-37-11	ALL
SP00346		E006-00/ /					ALL
	W0818	0013	16		9	33-37-11	ALL
	W0818	B-D			9	33-37-11	ALL
SP00348		E006-00/ /					ALL
	W1018	0013	16		9	33-37-21	ALL
	W1018	B-D			9	33-37-21	ALL
SP00350		E006-00/ /					ALL
	W1018	0012	16		9	33-37-21	ALL
	W1018	B-C			9	33-37-21	ALL

SPLICE LIST
D280N032

91-21-31
Section SP00300
Page 3
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00352		E006-00/ /					ALL
	W1018	0008	16		9	33-37-21	ALL
	W1018	B-A			9	33-37-21	ALL
SP00362		1615/200/R050					115-199
	W2632	0048	20		9	30-71-21	115-199
	W2632	D-BK			9	30-71-21	115-199
SP00364		1645/180/R020					115-199
	W2632	0109	20		9	30-71-21	115-199
	W2632	E-BK			9	30-71-21	115-199
	W2632	S-GD			9	30-71-21	115-199
SP00366		1675/175/R024					ALL
	W2632	0050	20		9	30-71-11	ALL
	W2632	H-PR			9	30-71-11	ALL
SP00380		630/175/R055					ALL
	W0816	0007	22		9	33-37-11	001-099
	W0816	0007	18		9	33-37-11	115-199
	W4104	0051	22		9	33-37-11	001-099
	W4104	0051	18		9	33-37-11	115-199
SP00382		630/175/R055					ALL
	W0816	0008	22		9	33-37-11	001-099
	W0816	0008	18		9	33-37-11	115-199
	W4104	0052	22		9	33-37-11	001-099
	W4104	0052	20		9	33-37-11	115-199
SP00386		1450/178/R060					ALL
	W1016	0008	18		9	33-37-21	ALL
	W2632	0070	20		9	33-37-21	001-099
	W2632	0080	20		9	33-37-21	115-199
SP00388		1450/178/R060					ALL
	W1016	0007	18		9	33-37-21	ALL
	W2632	0066	18		9	33-37-21	ALL
	W2632	0082	20		9	33-37-21	115-199

SPlice LIST

D280N032

91-21-31

Section SP00300

Page 4

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00389		1720/270/L017					ALL
	W2803	0027Y	20		9	27-41-31	ALL
	W2821	0007Y	20		9	27-41-31	ALL
SP00391		1720/270/L017					ALL
	W2803	0026Y	20		9	27-41-31	ALL
	W2821	0008Y	20		9	27-41-31	ALL
SP00397		225/174/R020					ALL
	W2355	0043Y	20		9	27-41-31	ALL
	W2613	0001Y	20		9	27-41-31	ALL
	W2613	0002Y	20		9	27-41-31	115-199
SP00399		225/174/R020					001-099
	W2355	0046Y	20		9	27-41-31	001-099
	W2613	0002Y	20		9	27-41-31	001-099

SPLICE LIST

D280N032

91-21-31

Section SP00300

Page 5 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00401		418/150/10					115-199
	W4106	I-BK			9	30-71-21	115-199
	W4106	L-WT			9	30-71-21	115-199
SP00408		1645/180/R020					115-199
	W2632	0101	20		9	30-71-21	115-199
	W2632	R-PR			9	30-71-21	115-199
SP00410		1660/195/R050					115-199
	W2632	0109	20		9	30-71-21	115-199
	W2632	M-BK			9	30-71-21	115-199
	W2632	N-BK			9	30-71-21	115-199
	W2632	O-BK			9	30-71-21	115-199
SP00420		860/150/L002					115-199
	W4106	0091	24		9	30-71-21	115-199
	W4106	A-BK			9	30-71-21	115-199
SP00422		418/150/L010					115-199
	W4106	0077	24		9	30-71-21	115-199
	W4106	0091	24		9	30-71-21	115-199
	W4106	H-PR			9	30-71-21	115-199
	W4106	M-PR			9	30-71-21	115-199
SP00426		418/150/L010					ALL
	W4104	A-BK			9	30-71-21	001-099
	W4104	F-GD			9	30-71-21	001-099
	W4106	I-GD			9	30-71-21	115-199
	W4106	J-BK			9	30-71-21	115-199
SP00478		1195/150/R019					ALL
	W2632	0063	20		9	30-71-21	001-099
	W2632	0064	20		9	30-71-21	115-199
	W2632	B-PR			9	30-71-21	ALL
	W2632	W-BN			9	30-71-21	ALL
	W2632	X-BN			9	30-71-21	ALL
SP00480		1900/229/L033					ALL
	W2822	0007	20		9	33-31-31	ALL
	W2822	A-F			9	33-31-31	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00400

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00482		1900/229/L033					ALL
	W2822	0008	20		9	33-31-31	ALL
	W2822	A-G			9	33-31-31	ALL
SP00485		434/200/L000					002
	W2309	5010R	22		9	34-43-14	002
	W4471	5228R	22		9	34-43-14	002
	W4477	5086R	22		9	34-43-14	002
SP00487		434/200/L000					002
	W2309	5010B	22		9	34-43-14	002
	W4471	5228B	22		9	34-43-14	002
	W4477	5086B	22		9	34-43-14	002
SP00489		434/200/L000					002
	W2309	5010Z			9	34-43-14	002
	W4471	5228Z			9	34-43-14	002
	W4477	5086Z			9	34-43-14	002
SP00496		411/199/R040					001-099
SP00496		380/182/R062					115-199
	W2078	0004	20		9	21-31-31	ALL
	W2626	0017	20		9	21-31-31	ALL
SP00497		434/200/L000					002
SP00498		411/199/R040					001-099
SP00498		380/182/R062					115-199
	W2078	0005	20		9	21-31-31	ALL
	W2626	0018	20		9	21-31-31	ALL

SPLICE LIST

D280N032

91-21-31

Section SP00400

Page 2 End

Jan 21/2005

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00500		MULTI/ /					115-199
	W0512	0011RG	20		9	35-21-31	115-199
	W0512	D-P			9	35-21-31	115-199
SP00502		MULTI/ /					ALL
	W0514	0011G	20		WI	35-21-31	001-099
	W0514	0011RG	20		9	35-21-31	115-199
	W0514	A-B			WI	35-21-31	001-099
	W0514	D-P			9	35-21-31	115-199
SP00504		PSU/ /					115-199
	W0520	0011RG	20		9	35-21-31	115-199
	W0520	D-P			9	35-21-31	115-199
SP00506		950/ /					ALL
	W0522	0011G	20		9	35-21-31	001-099
	W0522	0011RG	20		9	35-21-31	115-199
	W0522	A-B			9	35-21-31	001-099
	W0522	D-P			9	35-21-31	115-199
SP00508		830/198/R059					ALL
	W4216	0049	22		9	28-21-23	001-099
	W4216	0049	20		9	28-21-23	115-199
	W4226	0007	22		9	28-21-23	001-099
	W4226	0007	20		9	28-21-23	115-199
SP00512		830/198/R059					ALL
	W4202	0026	22		9	28-21-23	001-099
	W4202	0026	20		9	28-21-23	115-199
	W4216	0050	22		9	28-21-23	001-099
	W4216	0050	20		9	28-21-23	115-199
SP00516		830/198/R059					ALL
	W4216	0048	22		9	28-21-23	001-099
	W4216	0048	20		9	28-21-23	115-199
	W4220	0048	22		9	28-21-23	ALL
SP00518		MULTI/PSU/					115-199
	W0520	0010K	18		9	35-21-31	115-199
	W0520	D-G			9	35-21-31	115-199

SPLICE LIST

D280N032

91-21-31

Section SP00500

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00522		718/PSU/					001-099
	W0524	0010	18		9	35-21-31	001-099
	W0524	D-G			9	35-21-31	001-099
SP00524		718/PSU/					001-099
	W0524	0011	20		9	35-21-31	001-099
	W0524	D-P			9	35-21-31	001-099
SP00528		1225/300/L028					115-199
	W3536	0002	22		9	33-27-31	115-199
	W3572	0065	22		9	33-27-31	115-199
SP00530		1225/300/L028					115-199
	W3572	0064	22		9	33-27-31	115-199
	W3576	0064	22		9	33-27-31	115-199
SP00532		1225/300/L028					115-199
	W3572	0063	22		9	33-27-31	115-199
	W3576	0062	20		9	33-27-31	115-199
SP00534		370/300/R001					001-099
SP00534		370/298/R008					115-199
	W3572	0109	22		9	33-25-11	ALL
	W3672	0008	22		9	33-25-11	ALL
SP00536		370/300/R001					001-099
SP00536		370/298/R008					115-199
	W3572	0107	22		9	33-25-11	ALL
	W3572	0168	22		9	33-25-11	115-199
	W3672	0007	22		9	33-25-11	ALL
	W3672	0023	22		9	33-25-11	115-199
SP00538		705/300/R020					001-099
	W3672	0024	22		9	33-25-11	001-099
	W3702	0938	22		9	33-25-11	001-099
SP00540		1010/302/R022					001-099
	W3672	0033	22		9	33-25-11	001-099
	W3804	0940	22		9	33-25-23	001-099

SPLICE LIST
D280N032

91-21-31
Section SP00500
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00542		705/300/R020					ALL
	W3672	0034	22		9	33-25-11	001-099
	W3672	0138	22		9	33-25-12	115-199
	W3672	0147	22		9	33-25-21	115-199
	W3702	0942	22		9	33-25-11	001-099
	W3702	0942	22		9	33-25-12	115-199
	W3802	0942	22		9	33-25-21	ALL
SP00544		1310/296/L015					001-099
SP00544		1235/295/L015					115-199
	W3672	0091	22		9	33-25-14	001-099
	W3672	0139	22		9	33-25-14	115-199
	W3672	0247	22		9	SPARE	001-099
	W3706	0944	22		9	33-25-14	ALL
	W3806	0944	22		9	33-25-24	001-099
SP00546		1235/305/L015					001-099
	W3572	0117	22		9	33-25-14	001-099
	W3672	0092	22		9	33-25-14	001-099
	W3672	0095	22		9	33-25-14	001-099
	W3672	0098	22		9	33-25-14	001-099
	W3672	0099	22		9	33-25-24	001-099
	W3672	0248	22		9	SPARE	001-099
SP00548		1625/295/L010					ALL
	W3672	0096	22		9	33-25-14	ALL
	W3706	0948	22		9	33-25-14	ALL
	W3806	0948	22		9	33-25-24	ALL
SP00550		1235/305/L015					001-099
	W3572	0055	16		9	33-26-21	001-099
	W3672	0075	16		9	33-26-21	001-099
SP00552		420/300/L002					001-099
SP00552		436/300/R020					115-199
	W3702	0952	22		9	33-25-11	001-099
	W3702	0952	22		9	SPARE	115-199
	W3802	0952	22		9	33-25-21	001-099

SPlice LIST

D280N032

91-21-31

Section SP00500

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00554		520/200/L004					001-099
SP00554		520/200/R011					115-199
	W2350	0057	22		9	29-32-31	ALL
	W2608	0010	18		9	29-32-31	ALL
SP00556		512/175/R040					ALL
	W2354	0066	22		9	29-32-31	ALL
	W2610	0010	18		9	29-32-31	ALL
SP00564		1727/247/R030					ALL
	W2818	0015	20		9	33-31-31	ALL
	W2818	B-AP			9	33-31-31	ALL
SP00576		FSS493/ /					ALL
	W3426	1006	20		9	28-21-11	ALL
	W3426	1006Z				28-21-11	ALL
	W3426	A-AI			9	28-21-11	ALL
	W3426	FRAC				28-21-11	ALL
SP00578		FSS493/ /					ALL
	W3426	0004	18		9	28-21-11	ALL
	W3426	A-AF			9	28-21-11	ALL
	W3426	A-AG			9	28-21-11	ALL
SP00580		FSS493/ /					ALL
	W3426	1007	20		9	28-21-11	ALL
	W3426	A-AD			9	28-21-11	ALL
	W3426	A-AE			9	28-21-11	ALL

SPLICE LIST
D280N032

91-21-31
Section SP00500
Page 4 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00600		1886/230/R019					ALL
	W2822	0004	20		9	33-31-31	ALL
	W2822	0006	20		9	33-31-31	ALL
	W2822	0008	20		9	33-31-31	ALL
	W2822	B-B			9	33-31-31	ALL
SP00602		1130/180/R002					ALL
	W2416	1027	18		9	32-12-12	ALL
	W2516	1024	18		9	32-12-12	ALL
	W2516	A-AA			9	32-12-12	ALL
	W2516	A-AF			Y	32-12-12	ALL
	W2516	A-AG			Y	32-12-12	ALL
	W2516	A-AH			Y	32-12-12	ALL
SP00604		430/172/L026					ALL
	W2240	2002B	22		9	24-34-11	ALL
	W2244	2001B	24		9	24-34-11	001-099
	W2244	2001B	22		9	24-34-11	115-199
SP00606		430/172/L026					ALL
	W2240	2002R	22		9	24-34-11	ALL
	W2244	2001R	24		9	24-34-11	001-099
	W2244	2001R	22		9	24-34-11	115-199

SPlice LIST

D280N032

91-21-31

Section SP00600

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00726		362/208/R070					ALL
	W3682	0015	20		9	25-66-11	ALL
	W3682	B-GA			9	25-66-11	ALL
SP00728		735/210/R070					ALL
	W3682	0016	20		9	25-66-11	ALL
	W3682	D-GA			9	25-66-11	ALL
SP00730		1681/210/R065					ALL
	W3682	0017	20		9	25-66-11	ALL
	W3682	F-GA			9	25-66-11	ALL
SP00732		377/210/L070					ALL
	W3582	0015	20		9	25-66-11	ALL
	W3582	B-GA			9	25-66-11	ALL
SP00734		735/212/L070					ALL
	W3582	0016	20		9	25-66-11	ALL
	W3582	D-GA			9	25-66-11	ALL
SP00736		1685/210/L061					ALL
	W3582	0017	20		9	25-66-11	ALL
	W3582	F-GA			9	25-66-11	ALL

SPLICE LIST
D280N032

91-21-31
Section SP00700
Page 1 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01000		MULTI/ /					115-199
	W0512	0010K	18		WI	35-21-31	115-199
	W0512	0020K	18		WI	33-25-31	115-199
	W0512	D-G			WI	35-21-31	115-199
SP01002		MULTI/ /					ALL
	W0514	0010K	18		WI	35-21-31	ALL
	W0514	0020AH	22		WI	33-25-31	001-099
	W0514	0020K	18		WI	33-25-31	115-199
	W0514	0030K	20		WI	23-31-42	115-199
	W0514	0030Y	20		WI	23-31-42	001-099
	W0514	A-A			WI	35-21-31	001-099
	W0514	D-G			WI	35-21-31	115-199
SP01004		MULTI/ /					ALL
	W0522	0010K	18		WI	35-21-31	ALL
	W0522	0020AH	22		WI	33-25-31	001-099
	W0522	0020K	18		WI	33-25-31	115-199
	W0522	A-A			WI	35-21-31	001-099
	W0522	D-G			WI	35-21-31	115-199
SP01010		830/198/R059					ALL
	W4216	0064	20		9	28-21-23	ALL
	W4226	0008	20		9	28-21-23	ALL
SP01012		830/182/R062					ALL
	W4202	0027	20		9	28-21-23	ALL
	W4216	0065	20		9	28-21-23	ALL
SP01016		830/182/R062					ALL
	W4216	0063	20		9	28-21-23	ALL
	W4220	0049	20		9	28-21-23	ALL
SP01032		E002-04/ /					ALL
	W2250	1052	20		9	34-21-11	ALL
	W2250	1052Z				34-21-11	ALL
	W2350	0013	20		9	34-21-11	ALL
SP01036		IRSS264/ /					ALL
	W3406	2510R	18		9	28-43-11	ALL

SPlice LIST

D280N032

91-21-31

Section SP01000

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01036		IRSS264/ / (continued)					ALL
	W3406	B-02			9	28-43-11	ALL
SP01038		IRSS264/ /RRS					ALL
	W3406	0008	18		9	28-43-11	115-199
	W3406	2510B	18		9	28-43-11	ALL
	W3406	A-01			9	28-43-11	ALL
SP01040		482/158/L031					ALL
	W4236	0193	16		9	75-31-11	ALL
	W4236	A-A			9	75-31-11	ALL
	W4236	A-B			9	75-31-11	ALL
	W4236	A-H			Y	75-31-11	ALL
SP01042		482/158/L031					ALL
	W4236	0192	16		9	75-31-11	ALL
	W4236	A-C			9	75-31-11	ALL
SP01044		482/158/L031					ALL
	W4236	0226	16		9	75-31-11	115-199
	W4236	0238	16		9	75-31-11	001-099
	W4236	A-D			Y	75-31-11	ALL
	W4236	A-G			9	75-31-11	ALL
SP01046		455/162/L038					ALL
	W4228	0193	16		9	75-31-11	ALL
	W4228	A-A			9	75-31-11	ALL
	W4228	A-B			9	75-31-11	ALL
	W4228	A-H			Y	75-31-11	ALL
SP01048		455/162/L042					ALL
	W4228	0192	16		9	75-31-11	ALL
	W4228	A-C			9	75-31-11	ALL
SP01050		455/162/L042					ALL
	W4228	0213	16		9	75-31-11	ALL
	W4228	A-D			Y	75-31-11	ALL
	W4228	A-G			9	75-31-11	ALL

SPLICE LIST
D280N032

91-21-31
Section SP01000
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01052		490/185/R065					001-099
SP01052		465/185/R065					115-199
	W2602	0063	22		9	52-35-11	ALL
	W4104	0042	22		9	52-34-11	ALL
	W4104	0074	22		9	33-37-11	ALL
	W4104	0079	22		9	52-34-11	ALL
	W4104	0080	22		9	52-34-11	ALL
	W4104	0081	22		9	52-34-11	115-199
SP01054		1450/178/R060					115-199
	W2632	0081	22		9	33-37-21	115-199
	W2716	0227	22		9	52-35-11	115-199
	W2716	0228	22		9	52-35-11	115-199
	W2716	0229	22		9	52-35-11	115-199
SP01056		288/230/L050					ALL
	W2293	0001	20		9	33-13-11	ALL
	W2368	0007	20		9	33-13-11	ALL
SP01070		370/295/R005					ALL
	W3532	0008	24		9	33-51-12	ALL
	W3532	0035	22		9	33-51-12	ALL
	W3632	0008	24		9	33-51-12	ALL
	W3672	0089	24		9	33-51-12	ALL
SP01072		705/300/R020					ALL
	W3532	0102	22		9	33-51-13	ALL
	W3672	0086	22		9	33-51-14	ALL
	W3672	0168	22		9	33-51-12	ALL
SP01074		343/298/R005					115-199
	W3576	0060	22		9	33-27-11	115-199
	W3644	0034	22		9	33-27-11	115-199
SP01078		343/298/R005					115-199
	W3576	0061	22		9	33-27-11	115-199
	W3644	0036	22		9	33-27-11	115-199
SP01080		343/298/R005					115-199
	W3576	0059	22		9	33-27-11	115-199

SPlice LIST

D280N032

91-21-31

Section SP01000

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01080		343/298/R005 (continued)					115-199
	W3644	0037	22		9	33-27-11	115-199
SP01084		1635/280/L025					115-199
	W3536	0011	22		9	33-27-31	115-199
	W3576	0063	22		9	33-27-31	115-199
SP01086		1635/280/L025					115-199
	W3536	0003	22		9	33-27-31	115-199
	W3576	0065	22		9	33-27-31	115-199
SP01090		1040/160/R020					ALL
	W2416	1031	18		9	32-12-12	ALL
	W2516	1050	18		9	32-12-12	ALL
SP01094		525/178/R058					ALL
	W2362	0006	24		9	24-51-31	ALL
	W2370	0006	24		9	24-51-31	ALL

SPLICE LIST

D280N032

91-21-31

Section SP01000

Page 4 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01100		268/166/R020					ALL
	W2150	0014	18		9	32-12-12	ALL
	W2150	A-01			9	32-12-12	ALL
SP01102		274/166/R027					001-099
SP01102		268/166/R020					115-199
	W2150	0025	20		9	32-12-12	115-199
	W2150	2501R	20		9	32-12-12	001-099
	W2150	2501Z				32-12-12	001-099
	W2150	A-02			9	32-12-12	ALL
	W2150	A-04			Y	32-12-12	ALL
	W2150	A-05			Y	32-12-12	ALL
	W2150	A-06			Y	32-12-12	ALL
	W2150	B-01			9	32-12-12	ALL
SP01104		274/166/R027					001-099
SP01104		268/150/R020					115-199
	W2150	0026	20		9	32-12-12	115-199
	W2150	2501B	20		9	32-12-12	001-099
	W2150	A-03			9	32-12-12	ALL
	W2152	0022	18		Y	SPARE	115-199
SP01108		274/166/R027					001-099
SP01108		268/150/R020					115-199
	W2150	0021	18		9	32-12-12	ALL
	W2150	B-02			9	32-12-12	ALL
	W2150	B-03			Y	32-12-12	115-199
	W2150	B-05			Y	32-12-12	115-199
	W2152	0023	18		Y	SPARE	115-199
SP01110		E004-03/169/33					ALL
	W2150	0014	18		9	32-12-12	ALL
	W2250	0032	18		9	32-35-11	001-099
	W2250	0032	20		9	32-35-11	115-199
	W4220	0070	18		9	32-35-11	001-099
	W4220	0070	20		9	32-35-11	115-199
SP01112		OSS630/ /					ALL
	W3326	1001	20		9	27-81-31	ALL
	W3326	A-B			Y	27-81-31	ALL
	W3326	A-D			9	27-81-31	ALL

SPLICE LIST

D280N032

91-21-31

Section SP01100

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01116		OSS630/ /					ALL
	W3426	1001	20		9	27-81-31	ALL
	W3426	A-B			Y	27-81-31	ALL
	W3426	A-D			9	27-81-31	ALL
SP01120		705/300/R020					115-199
	W3672	0148	22		9	33-25-21	115-199
	W3702	0962	22		9	33-25-11	115-199
	W3802	0962	22		9	33-25-21	115-199
SP01122		705/300/R054					115-199
	W3672	0133	22		9	33-25-12	115-199
	W3672	0141	22		9	33-25-21	115-199
	W3702	0966	22		9	33-25-12	115-199
SP01124		705/300/R054					115-199
	W3672	0137	22		9	33-25-12	115-199
	W3672	0144	22		9	33-25-21	115-199
	W3702	0965	22		9	33-25-12	115-199
	W3802	0972	22		9	33-25-21	115-199
SP01126		705/300/L020					115-199
	W3672	0149	22		9	33-25-12	115-199
	W3702	0963	22		9	33-25-12	115-199
SP01128		705/300/L020					115-199
	W3672	0150	22		9	33-25-12	115-199
	W3702	0964	22		9	33-25-12	115-199
SP01130		1625/295/L010					115-199
	W3672	0140	22		9	33-25-14	115-199
	W3706	0966	22		9	33-25-14	115-199
	W3806	0964	22		9	33-25-24	115-199
SP01132		1540/159/R038					115-199
	W2632	2002R	24		9	52-71-21	115-199
	W2632	J-RD			9	52-71-21	115-199
SP01134		1540/159/R038					115-199
	W2632	2002B	24		9	52-71-21	115-199

SPLICE LIST
D280N032

91-21-31
Section SP01100
Page 2
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01134		1540/159/R038 (continued)					115-199
	W2632	J-BL			9	52-71-21	115-199
SP01152		1235/295/R025					ALL
	W3534	0002	22		9	33-51-14	ALL
	W3534	0102	22		9	33-51-15	ALL
	W3672	0086	22		9	33-51-14	ALL
SP01154		370/295/R005					ALL
	W3632	0002	22		9	33-51-12	ALL
	W3672	0087	22		9	33-51-12	ALL
	W3672	0088	22		9	33-51-12	ALL
SP01160		704/300/L020					115-199
	W3576	0020	22		9	33-22-12	115-199
	W3672	0178	22		9	33-22-12	115-199
SP01162		700/298/L010					115-199
	W3576	0026	20		9	33-22-12	115-199
	W3672	0177	20		9	33-22-12	115-199
SP01164		705/300/L020					115-199
	W3672	0175	18		9	35-21-12	115-199
	W3702	0877	18		9	35-21-12	115-199
SP01166		705/300/L020					115-199
	W3672	0176	20		9	35-21-12	115-199
	W3702	0876	20		9	35-21-12	115-199
SP01180		P062-00/ /					115-199
	W3050	2503B	20		9	32-12-12	115-199
	W3050	2503Z				32-12-12	115-199
	W3052	2501B	20		9	32-12-12	115-199
	W3052	2501Z				32-12-12	115-199
SP01182		P062-00/ /					115-199
	W3050	2503R	20		9	32-12-12	115-199
	W3052	2501R	20		9	32-12-12	115-199

SPLICE LIST

D280N032

91-21-31

Section SP01100

Page 3 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01224		1610/300/L030					001-099
	W3536	0002	22		9	33-27-31	001-099
	W3576	0124	22		9	33-27-31	001-099
SP01226		1610/300/L030					001-099
	W3536	0008	22		9	33-27-31	001-099
	W3576	0123	22		9	33-27-31	001-099
SP01228		1610/300/L022					001-099
	W3536	0012	20		9	33-27-31	001-099
	W3576	0122	22		9	33-27-31	001-099
SP01236		268/166/R020					ALL
	W2150	0023	18		9	32-12-12	ALL
	W2150	B-06			9	32-12-12	ALL
SP01238		268/166/R020					ALL
	W2150	0024	18		9	32-12-12	ALL
	W2150	B-03			Y	32-12-12	001-099
	W2150	B-04			9	32-12-12	ALL
	W2150	B-05			Y	32-12-12	001-099
SP01240		1068/140/L065					ALL
	W2416	2520B	18		9	32-12-12	ALL
	W2416	A-AJ			9	32-12-12	ALL
SP01242		1068/140/L065					ALL
	W2416	2520R	18		9	32-12-12	ALL
	W2416	A-AL			9	32-12-12	ALL
SP01244		1068/140/R065					ALL
	W2416	2520B	18		9	32-12-12	ALL
	W2516	2520B	18		9	32-12-12	ALL
	W2516	A-AJ			9	32-12-12	ALL
SP01246		1068/140/R065					ALL
	W2416	2520R	18		9	32-12-12	ALL
	W2516	1018	18		9	32-12-11	ALL
	W2516	2520R	18		9	32-12-12	ALL
	W2516	A-AL			9	32-12-12	ALL

SPLICE LIST
D280N032

91-21-31
Section SP01200
Page 1
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01248		705/300/R020					001-099
	W3572	0170	22		9	33-25-11	001-099
	W3672	0022	22		9	33-25-11	001-099
	W3672	0023	22		9	33-25-11	001-099
SP01250		1064/203/R064					ALL
	W2644	2503B	20		9	32-09-11	ALL
	W2644	2503Z			9	32-09-11	ALL
	W4212	2001B	20		9	32-09-11	ALL
SP01252		1064/203/R064					ALL
	W2644	2503R	20		9	32-09-11	ALL
	W4212	2001R	20		9	32-09-11	ALL
SP01254		1064/203/L064					ALL
	W2642	2503B	20		9	32-09-11	ALL
	W2642	2503Z			9	32-09-11	ALL
	W4202	2001B	20		9	32-09-11	ALL
SP01256		1064/203/L064					ALL
	W2642	2503R	20		9	32-09-11	ALL
	W4202	2001R	20		9	32-09-11	ALL
SP01262		455/164/L035					ALL
	W4228	0255	16		9	75-31-11	ALL
	W4228	A-E			9	75-31-11	ALL
SP01264		482/161/L033					ALL
	W4236	0255	16		9	75-31-11	ALL
	W4236	A-E			9	75-31-11	ALL
SP01266		370/295/R005					001-099
	W3572	0177	24		9	SPARE	001-099
	W3672	0182	24		9	SPARE	001-099
SP01280		490/185/R065					ALL
	W2346	0010	24		9	33-51-11	ALL
	W2356	0089	24		9	33-51-11	ALL

SPLICE LIST

D280N032

91-21-31

Section SP01200

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01312		510/298/R022					001-099
	W3576	0005	22		9	33-22-11	001-099
	W3576	0106	22		9	33-22-11	001-099
	W3576	0107	22		9	33-22-11	001-099
	W3644	0007	22		9	33-27-11	001-099
SP01314		510/300/R025					001-099
	W3576	0006	22		9	33-22-11	001-099
	W3576	0104	22		9	33-22-11	001-099
	W3576	0105	22		9	33-22-11	001-099
	W3644	0008	22		9	33-27-11	001-099
SP01316		510/300/R025					001-099
	W3576	0011	22		9	33-22-11	001-099
	W3576	0103	22		9	33-22-11	001-099
	W3576	0129	22		9	33-22-11	001-099
	W3644	0001	22		9	33-27-11	001-099
SP01318		735/300/					001-099
	W3576	0107	22		9	33-22-11	001-099
	W3576	0122	22		9	33-27-31	001-099
	W3644	0038	22		9	33-27-21	001-099
SP01320		735/300/					001-099
	W3576	0105	22		9	33-22-11	001-099
	W3576	0123	22		9	33-27-31	001-099
	W3644	0039	22		9	33-27-21	001-099
SP01322		735/300/					001-099
	W3576	0103	22		9	33-22-11	001-099
	W3576	0124	22		9	33-27-31	001-099
	W3644	0040	22		9	33-27-21	001-099
SP01348		705/300/R025					ALL
	W3532	0503	20		9	33-51-21	ALL
	W3632	0504	20		9	33-51-21	115-199
	W3632	0510	20		9	33-51-21	001-099
SP01350		705/300/R025					ALL
	W3532	0501	20		9	33-51-21	ALL

SPLICE LIST
D280N032

91-21-31
Section SP01300
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01350		705/300/R025 (continued)					ALL
	W3632	0501	20		9	33-51-21	ALL
SP01354		1070/290/L020					ALL
	W3532	0514	20		9	33-51-22	ALL
	W3632	0710	20		9	33-51-22	001-099
	W3634	0513	20		9	33-51-22	115-199
SP01356		1050/290/L020					ALL
	W3534	0505	20		9	33-51-22	ALL
	W3634	0510	20		9	33-51-22	001-099
	W3634	0512	20		9	33-51-22	115-199
SP01358		1625/290/R010					ALL
	W3534	0509	20		9	33-51-22	ALL
	W3634	0010	20		9	33-51-22	001-099
	W3634	0524	20		9	33-51-22	115-199
SP01360		1625/290/L010					ALL
	W3534	0511	20		9	33-51-22	ALL
	W3634	0110	20		9	33-51-22	001-099
	W3634	0528	20		9	33-51-22	115-199
SP01370		1335/290/R020					115-199
	W3634	0011	20		9	33-51-14	115-199
	W3672	0125	20		9	33-51-14	115-199

SPlice LIST

D280N032

91-21-31

Section SP01300

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01456		FSS106/ /					ALL
SP01458		FSS106/ /					ALL
SP01460		ISS106/ /					ALL
SP01462		FSS106/ /					ALL
SP01464		P005-00/ /					115-199
	W2078	0194	24		9	33-11-21	115-199
	W2366	B-A			9	33-11-21	115-199
	W2366	C-A			9	33-11-21	115-199
SP01466		1645/210/L064					ALL
	W3582	0014	20		9	25-66-11	ALL
	W3582	E-GA			9	25-66-11	ALL
SP01474		333/210/L070					ALL
	W3582	0012	20		9	25-66-11	ALL
	W3582	A-GA			9	25-66-11	ALL
SP01476		677/210/L070					ALL
	W3582	0013	20		9	25-66-11	ALL
	W3582	C-GA			9	25-66-11	ALL
SP01478		327/208/R070					ALL
	W3682	0012	20		9	25-66-11	ALL
	W3682	A-GA			9	25-66-11	ALL
SP01484		690/210/R070					ALL
	W3682	0013	20		9	25-66-11	ALL
	W3682	C-GA			9	25-66-11	ALL

SPLICE LIST
D280N032

91-21-31
Section SP01400
Page 1 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01514		1230/170/R050					ALL
	W2516	1-05			9	29-21-31	ALL
	W2516	1-06			Y	29-21-31	ALL
	W2516	3505Y	20		9	29-21-31	ALL
SP01516		1230/170/R050					ALL
	W2516	1-09			9	29-21-31	ALL
	W2516	3505B	20		9	29-21-31	ALL
SP01518		1230/170/R050					ALL
	W2516	1-08			9	29-21-31	ALL
	W2516	3505R	20		9	29-21-31	ALL
SP01520		1230/170/R050					ALL
	W2516	1-10			9	29-21-31	ALL
	W2516	1007	20		9	29-21-31	ALL
SP01522		1230/170/R050					ALL
	W2516	1-11			Y	29-21-31	ALL
	W2516	1-12			9	29-21-31	ALL
	W2516	1011	20		9	29-21-31	ALL
SP01524		P033-00/ /					115-199
	W2358	0401	12		9	29-21-31	115-199
	W4220	0102	12		9	29-21-31	115-199
SP01526		520/190/R035					ALL
	W2260	0028	12		9	29-21-31	ALL
	W4236	0175	12		9	29-21-31	ALL
SP01534		1655/180/L050					ALL
	W2632	2009R	24		9	21-31-21	ALL
	W2634	2009R	24		9	21-31-21	ALL
SP01536		1655/180/L050					ALL
	W2632	2009B	24		9	21-31-21	ALL
	W2634	2009B	24		9	21-31-21	ALL
SP01538		1120/182/L003					ALL
	W2416	1026	18		9	32-12-12	ALL

SPlice LIST

D280N032

91-21-31

Section SP01500

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01538		1120/182/L003 (continued)					ALL
	W2416	A-AA			9	32-12-12	ALL
SP01540		1120/182/L003					ALL
	W2416	1031	18		9	32-12-12	ALL
	W2416	A-AB			9	32-12-12	ALL
SP01542		1120/182/L003					ALL
	W2416	1027	18		9	32-12-12	ALL
	W2416	A-AC			9	32-12-12	ALL
	W2416	A-AF			Y	32-12-12	ALL
	W2416	A-AG			Y	32-12-12	ALL
	W2416	A-AH			Y	32-12-12	ALL
SP01544		1068/140/L065					ALL
	W2416	1026	18		9	32-12-12	ALL
	W2416	1032	18		9	32-12-12	ALL
	W2416	A-AD			9	32-12-12	ALL
	W2416	A-AI			Y	32-12-12	ALL
	W2416	A-AK			Y	32-12-12	ALL
SP01546		1065/145/R060					001-099
SP01546		1068/140/R065					115-199
	W2516	1020	18		9	32-12-12	ALL
	W2516	1022	18		9	32-12-12	ALL
	W2516	A-AD			9	32-12-12	ALL
	W2516	A-AI			Y	32-12-12	ALL
	W2516	A-AK			Y	32-12-12	ALL
SP01548		1130/180/R002					ALL
	W2516	1021	18		9	32-12-12	ALL
	W2516	A-AC			9	32-12-12	ALL
SP01550		1130/180/R002					ALL
	W2516	1022	18		9	32-12-12	ALL
	W2516	A-AB			9	32-12-12	ALL
SP01554		1642/210/R070					ALL
	W3682	0014	20		9	25-66-11	ALL
	W3682	E-GA			9	25-66-11	ALL

SPLICE LIST
D280N032

91-21-31
Section SP01500
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01560		715/295/L030					115-199
	W3544	0014	20		9	33-24-12	115-199
	W3702	0913	20		9	33-24-12	115-199
SP01562		715/296/L030					115-199
	W3544	0015	20		9	33-24-12	115-199
	W3702	0912	16		9	33-24-12	115-199
SP01564		1210/145/R025					ALL
	W2512	2503R	20		9	23-41-12	001-099
	W2512	3502R	20		9	23-41-12	115-199
	W2512	A-AA			9	23-41-12	ALL
SP01566		1210/145/R025					ALL
	W2512	2503B	20		9	23-41-12	001-099
	W2512	3502B	20		9	23-41-12	115-199
	W2512	A-AB			9	23-41-12	ALL
SP01568		1210/145/R025					ALL
	W2512	2503Z			9	23-41-12	001-099
	W2512	3502Y	20		9	23-41-12	115-199
	W2512	3502Z				23-41-12	115-199
	W2512	A-AC			9	23-41-12	ALL
SP01572		970/160/L031					001-099
SP01572		955/160/L035					115-199
	W2406	1002	18		9	33-31-21	ALL
	W2406	A-WT			9	33-31-21	ALL
SP01574		960/160/R048					ALL
	W2506	1002	18		9	33-31-21	ALL
	W2506	A-WT			9	33-31-21	ALL
SP01580		880/130/L007					ALL
	W2506	B-PR			9	30-71-11	ALL
	W2506	C-PR			9	30-71-11	ALL
SP01586		705/300/R020					ALL
	W3632	0102	22		9	33-51-13	ALL
	W3672	0087	22		9	33-51-12	ALL

SPLICE LIST

D280N032

91-21-31

Section SP01500

Page 3

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01586		705/300/R020 (continued)					ALL
	W3672	0169	22		9	33-51-14	ALL
SP01588		1235/296/R022					001-099
SP01588		1235/295/R025					115-199
	W3632	0702	22		9	33-51-14	001-099
	W3634	0002	22		9	33-51-14	ALL
	W3634	0102	22		9	33-51-15	ALL
	W3634	0502	22		9	33-51-14	ALL
	W3672	0169	22		9	33-51-14	ALL
SP01592		370/295/R005					ALL
	W3532	0002	22		9	33-51-12	ALL
	W3672	0084	22		9	33-51-12	ALL
	W3672	0168	22		9	33-51-12	ALL
SP01594		1315/290/R020					115-199
	W3672	0167	22		9	33-25-24	115-199
	W3806	0965	22		9	33-25-24	115-199

SPLICE LIST

D280N032

91-21-31

Section SP01500

Page 4 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01600		655/ /					115-199
	W0534	0010K	18		WI	35-21-31	115-199
	W0534	0020K	18		WI	33-25-31	115-199
	W0534	D-G			WI	35-21-31	115-199
SP01602		655/ /					115-199
	W0534	0011RG	20		9	35-21-31	115-199
	W0534	D-P			9	35-21-31	115-199

SPLICE LIST

D280N032

91-21-31

Section SP01600

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01712		TBD/ /					ALL
	W0818	0009	22		9	52-34-11	ALL
	W0818	C-1			9	52-34-11	ALL
	W0818	C-2			Y	52-34-11	ALL
	W0818	C-4			Y	52-34-11	ALL
	W0818	C-5			Y	52-34-11	ALL
	W0818	C-6			Y	52-34-11	ALL
SP01714		TBD/ /					ALL
	W0818	0011	22		9	52-34-11	ALL
	W0818	C-3			9	52-34-11	ALL
SP01718		1422/180/R055					ALL
	W1018	0009	22		9	52-35-11	ALL
	W1018	C-1			9	52-35-11	ALL
	W1018	C-2			Y	52-35-11	ALL
	W1018	C-4			Y	52-35-11	ALL
	W1018	C-5			Y	52-35-11	ALL
	W1018	C-6			Y	52-35-11	ALL
SP01720		TBD/ /					ALL
	W1018	0011	22		9	52-35-11	ALL
	W1018	C-3			9	52-35-11	ALL

SPLICE LIST
D280N032

91-21-31
Section SP01700
Page 1 End
Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01820		715/305/R9.5					115-199
	W3544	0010	22		9	33-27-22	115-199
	W3644	0016	22		9	33-27-21	115-199
	W3644	0038	22		9	33-27-21	115-199
SP01822		715/305/R9.5					115-199
	W3544	0011	22		9	33-27-22	115-199
	W3644	0017	22		9	33-27-21	115-199
	W3644	0039	22		9	33-27-21	115-199
SP01824		715/305/R9.5					115-199
	W3544	0012	22		9	33-27-22	115-199
	W3644	0015	22		9	33-27-21	115-199
	W3644	0040	22		9	33-27-21	115-199
SP01872		WBL740/ /LH					ALL
	W3326	0014	18			33-43-11	ALL
	W3326	2506R	12		9	33-43-11	ALL
	W3326	2506Z				33-43-11	ALL
	W3348	2001R	12		9	33-43-11	ALL
	W3348	2003R	12		9	33-43-11	ALL
	W3348	2005R	12		9	33-43-11	ALL
SP01874		WBL740/ /LH					ALL
	W3326	2506B	12		9	33-43-11	ALL
	W3348	2005B	12		9	33-43-11	ALL
SP01892		705/300/R025					001-099
	W3632	0704	22		9	33-51-14	001-099
	W3634	0030	22		9	33-51-14	001-099
SP01894		705/300/R025					001-099
	W3632	0703	22		9	33-51-14	001-099
	W3634	0031	22		9	33-51-14	001-099
	W3634	0503	22		9	33-51-14	001-099
SP01896		1645/180/R020					001-099
	W2632	0127	20		9	30-71-21	001-099
	W2632	0128	20		9	30-71-21	001-099
	W2632	A-BF			9	30-71-21	001-099

SPLICE LIST

D280N032

91-21-31

Section SP01800

Page 1

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01896		1645/180/R020 (continued)					001-099
	W2632	A-BS			9	30-71-21	001-099
SP01898		1660/195/R050					001-099
	W2632	0127	20		9	30-71-21	001-099
	W2632	A-BI			9	30-71-21	001-099
	W2632	A-BO			9	30-71-21	001-099
	W2632	A-BQ			9	30-71-21	001-099

SPLICE LIST

D280N032

91-21-31

Section SP01800

Page 2 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01900		1611/200/R050					001-099
	W2632	0128	20		9	30-71-21	001-099
	W2632	A-BG			9	30-71-21	001-099
	W2632	A-BU			Y	30-71-21	001-099
SP01902		1645/180/R020					001-099
	W2632	0101	20		9	30-71-21	001-099
	W2632	A-BE			9	30-71-21	001-099
SP01908		1335/290/R020					001-099
	W3534	0113	20		9	33-51-14	001-099
	W3672	0125	20		9	33-51-14	001-099
	W3672	0250	20		9	SPARE	001-099
SP01912		490/185/R065					003-099
	W2070	0605	18		9	28-22-11	003-099
	W2346	0018	18		9	28-22-11	003-099
SP01914		490/185/R065					003-099
	W2070	0606	18		9	28-22-11	003-099
	W2346	0019	18		9	28-22-11	003-099
SP01930		TBD/TBD/TBD					115-199
	W2066	2010B	18		9	28-43-11	115-199
	W2070	2070B	18		9	28-43-11	115-199
SP01932		TBD/TBD/TBD					115-199
	W2066	2010R	18		9	28-43-11	115-199
	W2070	2070R	18		9	28-43-11	115-199
SP01934		TBD/TBD/TBD					115-199
	W2070	0615	20		9	33-13-32	115-199
	W2078	0214	22		9	33-16-51	115-199
	W2078	0529	22		9	33-16-51	115-199
SP01936		TBD/TBD/TBD					115-199
	W2066	0301	24		9	33-16-12	115-199
	W2070	0276	24		9	33-16-12	115-199
	W2070	0616	20		9	33-13-32	115-199

SPLICE LIST

D280N032

91-21-31

Section SP01900

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01942		530/185/R040					ALL
	W2244	0003	16		9	78-34-61	ALL
	W4108	0008	16		9	78-34-61	ALL
SP01944		510/185/R020					ALL
	W2240	0001	16		9	78-34-51	ALL
	W4028	0008	16		9	78-34-51	ALL
SP01948		272/280/R015					001-002, 115-199
SP01950		508/169/R053					ALL
	W2354	0042	22		9	32-61-11	ALL
	W4420	0061	22		9	32-61-11	001-002, 115-199
	W4424	0038	22		9	32-61-11	003-099
SP01952		508/169/R053					ALL
	W2354	0014	22		9	32-61-11	ALL
	W4420	0062	22		9	32-61-11	001-002, 115-199
	W4424	0039	22		9	32-61-11	003-099
SP01960		1120/181/R061					ALL
	W2510	2501R	20		9	32-61-13	ALL
	W2510	A-AA			9	32-61-13	ALL
SP01962		1120/181/R061					ALL
	W2510	2501B	20		9	32-61-13	ALL
	W2510	2501ZI			9	32-61-13	ALL
	W2510	A-AB			9	32-61-13	ALL
SP01964		1068/140/R065					ALL
	W2510	2502R	20		9	32-61-13	ALL
	W2510	A-BA			9	32-61-13	ALL
SP01966		1068/140/R065					ALL
	W2510	2502B	20		9	32-61-13	ALL
	W2510	2502ZI			9	32-61-13	ALL
	W2510	A-BB			9	32-61-13	ALL
SP01968		1068/140/L065					ALL
	W2412	2511R	20		9	32-61-13	ALL

SPLICE LIST
D280N032

91-21-31
Section SP01900
Page 2
May 17/2006



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01968		1068/140/L065 (continued)					ALL
	W2412	A-AA			9	32-61-13	ALL
SP01970		1068/140/L065					ALL
	W2412	2511B	20		9	32-61-13	ALL
	W2412	2511ZI			9	32-61-13	ALL
	W2412	A-AB			9	32-61-13	ALL
SP01972		1120/170/L060					ALL
	W2412	2502R	20		9	32-61-13	ALL
	W2412	A-BA			9	32-61-13	ALL
SP01974		1120/170/L060					ALL
	W2412	2502B	20		9	32-61-13	ALL
	W2412	2502ZI			9	32-61-13	ALL
	W2412	A-BB			9	32-61-13	ALL
SP01976		360/190/L020					ALL
	W2152	2004R	20		9	32-61-13	ALL
	W2152	A-F			9	32-61-13	ALL
SP01978		360/190/L020					ALL
	W2152	2004B	20		9	32-61-13	ALL
	W2152	A-E			9	32-61-13	ALL
SP01980		268/150/R020					ALL
	W2152	2005R	20		9	32-61-13	ALL
	W2152	A-H			9	32-61-13	ALL
SP01982		268/150/R020					ALL
	W2152	2005B	20		9	32-61-13	ALL
	W2152	A-G			9	32-61-13	ALL
SP01984		1120/182/L060					ALL
	W2414	2508R	20		9	32-61-13	ALL
	W2414	A-AA			9	32-61-13	ALL
SP01986		1120/182/L060					ALL
	W2414	2508B	20		9	32-61-13	ALL
	W2414	2508ZI			9	32-61-13	ALL

SPlice LIST

D280N032

91-21-31

Section SP01900

Page 3

May 17/2006

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01986		1120/182/L060 (continued)					ALL
	W2414	A-AB			9	32-61-13	ALL
SP01988		1060/140/L065					ALL
	W2414	2513R	20		9	32-61-13	ALL
	W2414	A-BA			9	32-61-13	ALL
SP01990		1060/140/L065					ALL
	W2414	2513B	20		9	32-61-13	ALL
	W2414	2513ZI			9	32-61-13	ALL
	W2414	A-BB			9	32-61-13	ALL
SP01992		1120/186/R061					ALL
	W2512	2501R	20		9	32-61-13	ALL
	W2512	A-BA			9	32-61-13	ALL
SP01994		1120/186/R061					ALL
	W2512	2501B	20		9	32-61-13	ALL
	W2512	2501ZI			9	32-61-13	ALL
	W2512	A-BB			9	32-61-13	ALL
SP01996		1060/140/R065					ALL
	W2512	2502R	20		9	32-61-13	ALL
	W2512	A-CA			9	32-61-13	ALL
SP01998		1060/140/R065					ALL
	W2512	2502B	20		9	32-61-13	ALL
	W2512	2502ZI			9	32-61-13	ALL
	W2512	A-CB			9	32-61-13	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02028		1610/285/L050					ALL
	W3536	0001	20		9	33-24-14	001-099
	W3536	0016	20		9	33-24-14	115-199
	W3706	0881	20		9	33-24-14	ALL
SP02030		1610/285/L050					ALL
	W3536	0010	20		9	33-24-14	001-099
	W3536	0017	20		9	33-24-14	115-199
	W3706	0880	16		9	33-24-14	ALL

SPLICE LIST

D280N032

91-21-31

Section SP02000

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02156		P061-00/245/R040					001-099
	W2156	2501B	24		9	23-51-41	001-099
	W2156	2501Z				23-51-41	001-099
	W2156	A-BL			9	23-51-41	001-099
SP02158		P061-00/245/R040					001-099
	W2156	2501R	24		9	23-51-41	001-099
	W2156	A-BK			9	23-51-41	001-099
SP02194		FSS248/ /					ALL
	W3346	1004	20		9	27-81-31	ALL
	W3346	1005	20		9	27-81-31	ALL
	W3346	A-B			Y	27-81-31	ALL
	W3346	A-D			9	27-81-31	ALL
SP02196		FSS248/ /					ALL
	W3424	1004	20		9	27-81-31	ALL
	W3424	1005	20		9	27-81-31	ALL
	W3424	A-B			Y	27-81-31	ALL
	W3424	A-D			9	27-81-31	ALL

SPLICE LIST

D280N032

91-21-31

Section SP02100

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02226		525/180/R059					002
	W2352	0028	22		9	34-46-14	002
	W2379	0002	22		9	34-46-14	002

SPLICE LIST

D280N032

91-21-31

Section SP02200

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02586		1040/206/R057					115-199
SP02590		1040/206/R057					115-199

SPLICE LIST

D280N032

91-21-31

Section SP02500

Page 1 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02604		1040/206/R057					115-199
SP02614		1064/203/R064					115-199

SPLICE LIST

D280N032

91-21-31

Section SP02600

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02872		OSS630/ /					ALL
	W3426	0014	18			33-43-12	ALL
	W3426	2506R	12		9	33-43-12	ALL
	W3426	2506Z				33-43-12	ALL
	W3448	2001R	12		9	33-43-12	ALL
	W3448	2003R	12		9	33-43-12	ALL
	W3448	2005R	12		9	33-43-12	ALL
SP02874		OSS630/ /					ALL
	W3426	2506B	12		9	33-43-12	ALL
	W3448	2005B	12		9	33-43-12	ALL

SPLICE LIST

D280N032

91-21-31

Section SP02800

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03024		MULTI/ /					001-099
	W0512	0010K	18		WI	35-21-31	001-099
	W0512	0020AH	22		WI	33-25-31	001-099
	W0512	A-A			WI	35-21-31	001-099
SP03026		MULTI/ /					001-099
	W0512	0011G	20		WI	35-21-31	001-099
	W0512	A-B			WI	35-21-31	001-099
SP03030		MULTI/ /					004-099
	W0536	0010K	18		WI	35-21-31	004-099
	W0536	A-A			WI	35-21-31	004-099
SP03032		MULTI/ /					004-099
	W0536	0011G	20		WI	35-21-31	004-099
	W0536	A-B			WI	35-21-31	004-099

SPLICE LIST

D280N032

91-21-31

Section SP03000

Page 1 End

Jan 21/2005



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05002		AC0880/ /					ALL
	W3342	3001R	18		9	28-22-11	ALL
	W3342	YAAB				28-22-11	ALL
	W4206	3001R	18		9	28-22-11	ALL
SP05004		AC0880/ /					ALL
	W3342	3001Y	18		9	28-22-11	ALL
	W4206	3001Y	18		9	28-22-11	ALL
SP05006		AC0880/ /					ALL
	W3342	3001B	18		9	28-22-11	ALL
	W4206	3001B	18		9	28-22-11	ALL
SP05008		AC0880/ /					ALL
	W3306	3001R	18		9	28-22-11	ALL
	W4202	3002R	18		9	28-22-11	ALL
SP05010		AC0880/ /					ALL
	W3306	3001Y	18		9	28-22-11	ALL
	W4202	3002Y	18		9	28-22-11	ALL
SP05012		AC0880/ /					ALL
	W3306	3001B	18		9	28-22-11	ALL
	W4202	3002B	18		9	28-22-11	ALL
SP05014		AC0880/ /					ALL
	W3406	3001R	18		9	28-22-11	ALL
	W4216	3002R	18		9	28-22-11	ALL
	W4216	YAAF				28-42-11	115-199
SP05016		AC0880/ /					ALL
	W3406	3001Y	18		9	28-22-11	ALL
	W4216	3002Y	18		9	28-22-11	ALL
SP05018		AC0880/ /					ALL
	W3406	3001B	18		9	28-22-11	ALL
	W4216	3002B	18		9	28-22-11	ALL

SPLICE LIST

D280N032

91-21-31

Section SP05000

Page 1 End

Oct 09/2008



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP26001		474/201/R020					ALL
	W2360	0051	20		9	23-32-01	ALL
	W2843	0001	20		9	23-32-01	ALL
	W2843	0007	20		9	23-32-01	ALL
	W2843	0015	20		9	23-32-01	ALL
	W2843	0020	20		9	23-32-01	ALL
	W2843	0028	20		9	23-32-01	ALL
SP26003		506/165/R040					ALL
	W2843	0019	20		9	23-32-01	ALL
	W4473	0274	20		9	23-32-01	ALL
SP26005		506/165/R040					ALL
	W2843	0002	20		9	23-32-01	ALL
	W4473	0275	20		9	23-32-01	ALL
SP26007		506/165/R040					ALL
	W2843	0006	20		9	23-32-01	ALL
	W2843	0014	20		9	23-32-01	ALL
	W2843	0027	20		9	23-32-01	ALL
	W4473	0273	20		9	23-32-01	ALL

SPLICE LIST

D280N032

91-21-31

Section SP26000

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP27001		506/186/L040					ALL
	W2077	0029	22		9	34-53-11	ALL
	W2077	0032	22		9	34-53-11	ALL
	W2354	0020	22		9	34-53-21	ALL

SPLICE LIST

D280N032

91-21-31

Section SP27000

Page 1 End

Oct 09/2008