

91-21-12

SPARE WIRE LIST

91-21-12
SPARE WIRE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			AD0880 cont.			AE0204		
	1 thru 4	Oct 09/2008		4	May 17/2006		1	May 17/2006
AA0360	1	May 17/2006		5	May 17/2006		2	Dec 18/2007
AA0409	1	May 17/2006		6	May 17/2006		3	Dec 18/2007
AA1705	1	May 17/2006		7	May 17/2006	AE0301	1	May 17/2006
AA1715	1	May 17/2006	AD1090	1	May 17/2006		2	May 17/2006
AA1862	1	May 17/2006	AD1650	1	May 17/2006		3	May 17/2006
AB1210	1	May 17/2006	AE0101	1	May 17/2006	AE0302	1	May 17/2006
AB1862	1	May 17/2006	AE0102	1	May 17/2006		2	May 17/2006
AC0204	1	May 17/2006	AE0201	1	May 17/2006		3	May 17/2006
AC0210	1	May 17/2006	R	2	Oct 09/2008	AE0303	1	May 17/2006
AC0215	1	May 17/2006		3	May 17/2006		2	May 17/2006
AC0393	1	May 17/2006	O	4	Oct 09/2008		3	Dec 18/2007
AC0820	1	May 17/2006	R	5	Oct 09/2008		4	Dec 18/2007
	2	May 17/2006	R	6	Oct 09/2008	AE0304	1	Dec 18/2007
AC0880	1	May 17/2006	R AE0202	1	Oct 09/2008		2	Dec 18/2007
O	2	Oct 09/2008	O	2	Oct 09/2008		3	Dec 18/2007
O	3	Oct 09/2008	O	3	Oct 09/2008		4	Dec 18/2007
O	4	Oct 09/2008	O	4	Oct 09/2008		5	Dec 18/2007
O	5	Oct 09/2008	O	5	Oct 09/2008		6	Dec 18/2007
	6	May 17/2006	R	6	Oct 09/2008	AE0401	1	Dec 18/2007
AC1090	1	May 17/2006	O AE0203	1	Oct 09/2008		2	Dec 18/2007
AC1148	1	May 17/2006	O	2	Oct 09/2008		3	Dec 18/2007
AD0820	1	May 17/2006	R	3	Oct 09/2008	AE0402	1	Dec 18/2007
	2	May 17/2006	R	4	Oct 09/2008		2	Dec 18/2007
AD0880	1	May 17/2006	O	5	Oct 09/2008		3	Dec 18/2007
	2	May 17/2006	O	6	Oct 09/2008		4	Dec 18/2007
	3	May 17/2006	O	7	Oct 09/2008		5	Dec 18/2007
						R	6	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

SPARE WIRE LIST

D280N032

EFFECTIVE PAGES

Page 1
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

91-21-12 SPARE WIRE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
AE0402 cont.			AE0601 cont.			AP0011 cont.		
	7	Dec 18/2007		2	Dec 18/2007	O	5	Oct 09/2008
	8	Dec 18/2007	AE0602	1	Dec 18/2007	O	6	Oct 09/2008
	9	Dec 18/2007	AE0603	1	Dec 18/2007	AP0031	1	Dec 18/2007
	10	Dec 18/2007	AE0604	1	Dec 18/2007	AP0032	1	Dec 18/2007
	11	Dec 18/2007		2	Dec 18/2007	AP0033	1	Dec 18/2007
O	12	Oct 09/2008		3	Dec 18/2007	O	2	Oct 09/2008
AE0403	1	Dec 18/2007	AP0001	1	Dec 18/2007		3	Dec 18/2007
	2	Dec 18/2007		2	Dec 18/2007		4	Dec 18/2007
	3	Dec 18/2007		3	Dec 18/2007		5	Dec 18/2007
AE0404	1	Dec 18/2007		4	Dec 18/2007		6	Dec 18/2007
AE0501	1	Dec 18/2007		5	Dec 18/2007	AP0034	1	Dec 18/2007
	2	Dec 18/2007	AP0003	1	Dec 18/2007		2	Dec 18/2007
	3	Dec 18/2007		2	Dec 18/2007		3	Dec 18/2007
	4	Dec 18/2007		3	Dec 18/2007	AP0036	1	Dec 18/2007
R	5	Oct 09/2008		4	Dec 18/2007		2	Dec 18/2007
AE0502	1	Dec 18/2007		5	Dec 18/2007		3	Dec 18/2007
	2	Dec 18/2007		6	Dec 18/2007		4	Dec 18/2007
	3	Dec 18/2007	O AP0005	1	Oct 09/2008		5	Dec 18/2007
	4	Dec 18/2007	AP0006	1	Dec 18/2007		6	Dec 18/2007
	5	Dec 18/2007		2	Dec 18/2007		7	Dec 18/2007
AE0503	1	Dec 18/2007		3	Dec 18/2007		8	Dec 18/2007
	2	Dec 18/2007		4	Dec 18/2007		9	Dec 18/2007
	3	Dec 18/2007	AP0010	1	Dec 18/2007		10	Dec 18/2007
AE0600	1	Dec 18/2007	AP0011	1	Dec 18/2007		11	Dec 18/2007
	2	Dec 18/2007	O	2	Oct 09/2008		12	Dec 18/2007
	3	Dec 18/2007	O	3	Oct 09/2008	O AP0037	1	Oct 09/2008
AE0601	1	Dec 18/2007	O	4	Oct 09/2008	O	2	Oct 09/2008

A = Added, R = Revised, D = Deleted, O = Overflow

SPARE WIRE LIST

D280N032

EFFECTIVE PAGES

Page 2
Oct 09/2008

91-21-12
SPARE WIRE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
AP0037 cont.			AP0301	1	Dec 18/2007	AW2333 cont.		
	3	Dec 18/2007	AS1080	1	Dec 18/2007		3	Dec 18/2007
O	4	Oct 09/2008		2	Dec 18/2007	AW2493	1	Dec 18/2007
O	5	Oct 09/2008	AS1123	1	Dec 18/2007	R D00044	1	Oct 09/2008
	6	Dec 18/2007	AS1140	1	Dec 18/2007	D00477	1	Dec 18/2007
	7	Dec 18/2007	AS2080	1	Dec 18/2007	D02458	1	Dec 18/2007
	8	Dec 18/2007		2	Dec 18/2007	D04616	1	Dec 18/2007
	9	Dec 18/2007	AS2123	1	Dec 18/2007	D05928	1	Dec 18/2007
	10	Dec 18/2007	AS2140	1	Dec 18/2007	D40312J	1	Dec 18/2007
	11	Dec 18/2007	AT1883	1	Dec 18/2007	D40312P	1	Dec 18/2007
	12	Dec 18/2007		2	Dec 18/2007	D40314P	1	Dec 18/2007
	13	Dec 18/2007	AW1156	1	Dec 18/2007	D40412J	1	Dec 18/2007
	14	Dec 18/2007	AW1180	1	Dec 18/2007	D40412P	1	Dec 18/2007
	15	Dec 18/2007	AW1240	1	Dec 18/2007	D40414J	1	Dec 18/2007
AP0050	1	Dec 18/2007	AW1285	1	Dec 18/2007	D40414P	1	Dec 18/2007
O	2	Oct 09/2008		2	Dec 18/2007	D40882J	1	Dec 18/2007
	3	Dec 18/2007		3	Dec 18/2007	D40882P	1	Dec 18/2007
AP0051	1	Dec 18/2007		4	Dec 18/2007	D41180J	1	Dec 18/2007
	2	Dec 18/2007	AW1333	1	Dec 18/2007	D41498J	1	Dec 18/2007
	3	Dec 18/2007	AW2156	1	Dec 18/2007	R D41714J	1	Oct 09/2008
AP0054	1	Dec 18/2007	AW2180	1	Dec 18/2007	D41714P	1	Dec 18/2007
	2	Dec 18/2007	AW2240	1	Dec 18/2007	D41716P	1	Dec 18/2007
AP0061	1	Dec 18/2007	AW2285	1	Dec 18/2007	R D41735J	1	Oct 09/2008
AP0065	1	Dec 18/2007		2	Dec 18/2007	R D41735P	1	Oct 09/2008
AP0070	1	Dec 18/2007		3	Dec 18/2007	D41814J	1	Dec 18/2007
	2	Dec 18/2007		4	Dec 18/2007	D41814P	1	Dec 18/2007
AP0071	1	Dec 18/2007	AW2333	1	Dec 18/2007	D41816P	1	Dec 18/2007
AP0103	1	Dec 18/2007		2	Dec 18/2007	D42052P	1	Dec 18/2007

A = Added, R = Revised, D = Deleted, O = Overflow

SPARE WIRE LIST

D280N032

EFFECTIVE PAGES

Page 3
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

91-21-12 SPARE WIRE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
GALLEY 2A	1	Dec 18/2007	M00732	1	Dec 18/2007	O M10654	1	Oct 09/2008
K00124	1	Dec 18/2007	M00733	1	Dec 18/2007	O M10680	1	Oct 09/2008
K00140	1	Dec 18/2007	M00736	1	Dec 18/2007	O M10919	1	Oct 09/2008
K00200	1	Dec 18/2007	M00737	1	Dec 18/2007	O M11030	1	Oct 09/2008
K00419	1	Dec 18/2007	M00968	1	Dec 18/2007	O N10013	1	Oct 09/2008
K10126	1	Dec 18/2007	M10013	1	Dec 18/2007	O N10014	1	Oct 09/2008
L00809	1	May 17/2006	M10014	1	Dec 18/2007	O SPEAKER	1	Oct 09/2008
L823	1	May 17/2006	M10015	1	Dec 18/2007	O TB0190	1	Oct 09/2008
L824	1	May 17/2006	M10023	1	Dec 18/2007	O TB0192	1	Oct 09/2008
M00001	1	May 17/2006	M10050	1	Dec 18/2007	O TB0203	1	Oct 09/2008
M00013	1	May 17/2006	R M10054	1	Oct 09/2008	O TB0207	1	Oct 09/2008
M00019	1	May 17/2006	A	2	Oct 09/2008	O TS5082	1	Oct 09/2008
M00033	1	May 17/2006	R M10055	1	Oct 09/2008	O W3054	1	Oct 09/2008
M00051	1	May 17/2006	R M10056	1	Oct 09/2008	O UNK	1	Oct 09/2008
M00056	1	May 17/2006	O M10057	1	Oct 09/2008	O	2	Oct 09/2008
R M00076	1	Oct 09/2008	R M10063	1	Oct 09/2008	O	3	Oct 09/2008
R M00077	1	Oct 09/2008	O M10140	1	Oct 09/2008	O	4	Oct 09/2008
M00090	1	Dec 18/2007	O M10191	1	Oct 09/2008	O	5	Oct 09/2008
M00091	1	May 17/2006	O M10193	1	Oct 09/2008	D	6	BLANK
M00092	1	May 17/2006	O M10250	1	Oct 09/2008			
M00093	1	May 17/2006	O M10259	1	Oct 09/2008			
R M00138	1	Oct 09/2008	O M10321	1	Oct 09/2008			
M00147	1	Dec 18/2007	O M10324	1	Oct 09/2008			
M00241	1	Dec 18/2007	O M10394	1	Oct 09/2008			
M00242	1	Dec 18/2007	O M10396	1	Oct 09/2008			
R M00269	1	Oct 09/2008	O M10397	1	Oct 09/2008			
M00726	1	Dec 18/2007	O M10398	1	Oct 09/2008			
M00727	1	Dec 18/2007	O M10401	1	Oct 09/2008			

A = Added, R = Revised, D = Deleted, O = Overflow

SPARE WIRE LIST

D280N032

EFFECTIVE PAGES

Page 4
Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AA0360	01	W3572	L1	DISC BKT-LAV A DISC								
D00042	25		0090	20	GA	D40496P	5		AP0037	15	001-099	
D00042	25		0090	20	GA	D40496P	5		AP0037	21	115-199	
D00042	26		0091	20	GA	D40496P	6		AP0037	15	001-099	
D00042	26		0091	20	GA	D40496P	6		AP0037	21	115-199	
D00042	CAP	Y	0151	20	GA	D41120J	CAP	Y	AA0409	01	001-099	
D00042	12		0155	20	GA	D40496P	15		AP0037	15	001-099	
AA0360	03	W3576	R1	DISC BKT-LAV A DISC								
D03456	CAP	Y	0052	22	GA	D03438	11		M10321		115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AA0360

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AA0409	01	W3572	L1	DISC BKT-FWD LOWER CEILING DISC BRACKET								
D41120J	CAP	Y	0089	20 GA	D05690	12		M10654		001-099		
D41120J	10		0089	20 GA	D00044	12		M10013		115-199		
D41120J	CAP	Y	0151	20 GA	D00042	CAP	Y	AA0360	01	001-099		
D41120J	9		0166	20 GA	D41104P	3		AP0031	07	001-099		
AA0409	03	W3632	R2	DISC BKT-FWD LOWER CEILING DISC BRACKET								
D40454J	5		0040	20 GA	D00070	CAP	Y	M00732		ALL		
D40454J	6		0041	20 GA	D00070	CAP	Y	M00732		ALL		
AA0409	04	W3672	R1	DISC BKT-FWD LOWER CEILING DISC BRACKET								
D40494J	8		0175	20 GA	D00046	10		M10014		001-099		
AA0409	05	W3634	R2	DISC BKT-FWD LOWER CEILING DISC BRACKET								
D40456J	5		0040	20 GA	D00078	CAP	Y	M00736		ALL		
D40456J	6		0041	20 GA	D00078	CAP	Y	M00736		ALL		
AA0409	06	W3534	R2	DISC BKT-FWD LOWER CEILING DISC BRACKET								
D40356J	5		0040	20 GA	D00080		Y	M00737		ALL		
D40356J	6		0041	20 GA	D00080	CAP	Y	M00737		ALL		
AA0409	09	W3532	R2	DISC BKT-FWD LOWER CEILING DISC BRACKET								
D40354J	5		0040	20 GA	D00072	CAP	Y	M00733		ALL		
D40354J	6		0041	20 GA	D00072	CAP	Y	M00733		ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AA0409

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AA1705												
		04	W4204	L2B	DISC BKT-LEFT PASSENGER CABIN OVERHEAD							
D40142J		12		0046	22	GA	D41628P	35		AE0402	40	ALL
D40142J		13		0047	22	GA	D41628P	36		AE0402	40	ALL
AA1705												
		09	W2818	A1	DISC BKT-LEFT PASSENGER CABIN OVERHEAD							
D40258J		2		0013	20	GA	D40230J	2		AT1883	03	001-099
D40258J		14		0014	20	GA	D40230J	14		AT1883	03	001-099
D40258P		2		0013	20	GA	D40230J	2		AT1883	03	115-199
D40258P		14		0014	20	GA	D40230J	14		AT1883	03	115-199
AA1705												
		09	W4018	A1	DISC BKT-LEFT PASSENGER CABIN OVERHEAD							
D40258J		2		0013	20	GA	D41644P	2		AE0503	19	115-199
D40258J		14		0014	20	GA	D41644P	4		AE0503	19	115-199
D40258P		2		0013	20	GA	D42120P	12		AE0501	25	001-099
D40258P		14		0014	20	GA	D42120P	13		AE0501	25	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section AA1705

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AA1715	01	W2605	L2	DISC BKT-LEFT PASSENGER CABIN OVERHEAD								
D40697P	6		0024Y	22 QB	D41841P	10		AE0301	10	ALL		
AA1715	03	W2812	L2	DISC BKT-LEFT PASSENGER CABIN OVERHEAD								
D40120J	9		0016	20 GA	D42044J	2		AA1862	02	ALL		
AA1715	03	W4204	L2B	DISC BKT-LEFT PASSENGER CABIN OVERHEAD								
D40120P	9		0044	22 GA	D41628P	33		AE0402	40	ALL		
D40120P	10		0045	22 GA	D41628P	34		AE0402	40	ALL		
AA1715	05	W2621	C2	DISC BKT-LEFT PASSENGER CABIN OVERHEAD								
D40497P	40		3010B	22 GC	D41695P	40		AE0203	06	ALL		
D40497P	39		3010R	22 GC	D41695P	39		AE0203	06	ALL		
D40497P	41		3010Y	22 GC	D41695P	41		AE0203	06	ALL		
AA1715	06	W2814	R2	DISC BKT-LEFT PASSENGER CABIN OVERHEAD								
D40164J	9		0016	20 HL	D42098J	2		AB1862	02	ALL		
AA1715	06	W4224	R2A	DISC BKT-LEFT PASSENGER CABIN OVERHEAD								
D40164P	9		0045	20 GA	D41180P	9		D41180J		ALL		
AA1715	07	W2611	R2	DISC BKT-LEFT PASSENGER CABIN OVERHEAD								
D40699P	6		0010	22 GA	D41843P	6		AE0401	24	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AA1715

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AA1862		02	W2812	L2	DISC BKT-							
D42044J		2		0016	20	GA	D40120J	9		AA1715	03	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AA1862

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AB1210	01	W2602	R1	DISC BKT-RIGHT AFT CABIN DISC								
D40178J	1		0001	18	GA	D40184P	1		AP0037	12	ALL	
D40178J	18		0020	18	GA	D40188P	3		AP0034	01	001-099	
D40178J	4		0021	18	GA	D40188P	6		AP0034	01	001-099	
D40178J	19		0036	18	GA	D40188P	9		AP0034	01	001-099	
AB1210	02	W2602	R1	DISC BKT-RIGHT AFT CABIN DISC								
D40176J	26		0016	24	GK	D40186P	8		AP0037	14	ALL	
D40176J	14		0019	22	GA	D40188P	2		AP0034	01	001-099	
D40176J	4		0044	20	GA	D40186P	4		AP0037	14	001-099	
D40176J	5		0045	20	GA	D40186P	5		AP0037	14	001-099	
D40176J	32		0046	24	GK	D40186P	9		AP0037	14	ALL	
D40176J	34		0048	22	GA	D40186P	11		AP0037	14	001-099	
D40176J	35		0049	22	GA	D40186P	12		AP0037	14	001-099	
D40176J	36		0050	20	GA	D40186P	13		AP0037	14	001-099	
D40176J	37		0051	20	GA	D40186P	14		AP0037	14	001-099	
D40176J	33		0059	20	GA	D40188P	5		AP0034	01	001-099	
D40176J	12		0060	20	GA	D40188P	8		AP0034	01	001-099	
D40176J	44		0080	22	GA	D40186P	27		AP0037	14	001-099	
D40176J	45		0081	22	GA	D40186P	28		AP0037	14	001-099	
D40176J	46		0082	24	GK	D40186P	29		AP0037	14	001-099	
D40176J	47		0083	24	GK	D40186P	31		AP0037	14	001-099	
D40176J	48		0084	24	GK	D40186P	30		AP0037	14	001-099	
AB1210	02	W2632	R1	DISC BKT-RIGHT AFT CABIN DISC								
D40176P	12		0073	20	GA	D42038P	17		AE0600	16	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AB1210

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AB1862	02	W2814	R2	DISC BKT-								
D42098J	2		0016	20	HL	D40164J	9		AA1715	06	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AB1862

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AC0204	1	W4028	S2B	DISC BKT-P10						
D07688	CAP	Y	0012	22 GA	D41462P	21		AP0036	43	ALL
AC0204	4	W4108	S2B	DISC BKT-P10						
D07710	CAP	Y	0012	22 GA	D41478P	21		AP0037	53	001-002, 115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AC0204

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AC0210	03	W2615	L2	DISC BKT-SPEED BRAKE DISCONNECT								
D01827	5		2503B	20	H5	D41225P	4		AD1650	01	ALL	
D01827	3		2503R	20	H5	D41225P	3		AD1650	01	ALL	
D01827	DED		2503Z			D41225P	DED		AD1650	01	ALL	
AC0210	04	W2613	R2	DISC BKT-SPEED BRAKE DISCONNECT								
D01825	2		2503B	20	H5	D41227P	4		AD1650	03	ALL	
D01825	1		2503R	20	H5	D41227P	3		AD1650	03	ALL	
D01825	DED		2503Z			D41227P	DED		AD1650	03	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AC0210

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description							
Equip	Term	Type	Wire No.	GA	TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AC0215	02	W2447	R*	DISC BKT-SPEED BRAKE DISCONNECT							
D00881	11		2014B	22	GB	D41771P	31		AE0401	11	001-099
D00881	12		2014R	22	GB	D41771P	32		AE0401	11	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section AC0215

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AC0393	02	W2150	S2	DISC BKT-NOSE WHEEL WELL DISC						
D40162J	8		0002	20 GA	D41096P	8		AP0033	08	001-099
D40162J	22		0007	20 GA	D41096P	22		AP0033	08	001-099
D40162J	12		0009	20 GA	D41096P	12		AP0033	08	001-099
AC0393	02	W3050	S2	DISC BKT-NOSE WHEEL WELL DISC						
D40162P	22		0007	20 HL	TB0025K	G006	1	W3054		001-099
D40162P	8		0008	20 HL	TB0225K	A003	1			001-099
AC0393	03	W2152	L1	DISC BKT-NOSE WHEEL WELL DISC						
D40388J	L		0020	18 GA	D40390P	5		AP0036	08	115-199
D40388J	N		0022	18 GA	SP01104	CAP	Y			115-199
D40388J	O		0023	18 GA	SP01108	CAP	Y			115-199
D40388J	L		0033	20 GA	D40390P	6		AP0036	08	001-099
AC0393	03	W3052	L1	DISC BKT-NOSE WHEEL WELL DISC						
D40388P	O		0030	18 HL	S10361	CAP	Y			115-199
D40388P	N		0031	18 HL	S10361	CAP	Y			115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AC0393

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AC0820	01	W2706	L2	DISC BKT-AIR CONDITIONING SYSTEM,LEFT								
D40628P	40		0007	24 GK	D42188P	40		AE0602	05	115-199		
D40628P	41		0008	24 GK	D41845P	41		AE0600	09	115-199		
D40628P	45		0009	24 GK	D42180P	45		AE0604	05	115-199		
D40628P	46		2000B	24 GL	D42180P	46		AE0604	05	115-199		
D40628P	47		2000R	24 GL	D42180P	47		AE0604	05	115-199		
AC0820	01	W4006	L2	DISC BKT-AIR CONDITIONING SYSTEM,LEFT								
D40628J	40		0051	22 GA	D41100J	13		AC0880	09	115-199		
D40628J	51		0053	22 GA	D40072J	14		AC0880	17	115-199		
D40628J	46		2002B	24 GL	D40072J	23		AC0880	17	115-199		
D40628J	47		2002R	24 GL	D40072J	24		AC0880	17	115-199		
AC0820	02	W2706	L2	DISC BKT-AIR CONDITIONING SYSTEM,LEFT								
D40630P	42		0010	24 GK	D41845P	42		AE0600	09	115-199		
D40630P	48		0011	24 GK	D42180P	48		AE0604	05	115-199		
AC0820	02	W4006	L2	DISC BKT-AIR CONDITIONING SYSTEM,LEFT								
D40630J	48		0136	24 GK	D41544P	13		AP0036	05	115-199		
D40630J	18		0235	24 GK	D41544P	53		AP0036	05	115-199		
D40630J	32		0261	24 GK	D41544P	51		AP0036	05	115-199		
D40630J	43		0273	22 GA	D40060P	41		AP0036	07	115-199		
D40630J	50		0309	22 GA	D40974P	50		AP0050	01	115-199		
D40630J	52		0311	22 GA	D42084P	52		AE0402	17	115-199		
D40630J	40		1001	22 GT	D41544P	52		AP0036	05	115-199		
D40630J	DED		1001Z		D41544P	DED		AP0036	05	115-199		
AC0820	03	W2706	L2	DISC BKT-AIR CONDITIONING SYSTEM,LEFT								
D40632P	43		0012	24 GK	D41845P	43		AE0600	09	115-199		
D40632P	44		0013	24 GK	D41845P	44		AE0600	09	115-199		
D40632P	13		0224	24 GK	D42180P	22		AE0604	05	115-199		
D40632P	14		0225	24 GK	D42180P	23		AE0604	05	115-199		
D40632P	15		0226	24 GK	D42180P	24		AE0604	05	115-199		
D40632P	16		0227	24 GK	D42180P	25		AE0604	05	115-199		
D40632P	17		0228	24 GK	D42180P	26		AE0604	05	115-199		
D40632P	18		0229	24 GK	D42180P	27		AE0604	05	115-199		
D40632P	19		0230	24 GK	D42180P	28		AE0604	05	115-199		
D40632P	45		2002B	24 GL	D41845P	45		AE0600	09	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AC0820

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AC0820		03	W2706	L2	DISC BKT-AIR CONDITIONING SYSTEM,LEFT (continued)							
D40632P		46		2002R	24	GL	D41845P	46		AE0600	09	115-199
AC0820		03	W4006	L2	DISC BKT-AIR CONDITIONING SYSTEM,LEFT							
D40632J		43		0138	22	GA	D41544P	14		AP0036	05	115-199
D40632J		44		0301	22	GA	D40060P	44		AP0036	07	115-199
D40632J		32		0302	22	GA	D41544P	2		AP0036	05	115-199
D40632J		33		0303	22	GA	D40060P	34		AP0036	07	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AC0820

Page 2 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AC0880	05	W3328	L1	DISC BKT-LEFT FRONT SPAR DISC								
D41208P	8		0016	18 HL	D40044P	12		AS1123	03	ALL		
D41208P	9		0017	18 HL	D40044P	13		AS1123	03	ALL		
AC0880	06	W3328	L1	DISC BKT-LEFT FRONT SPAR DISC								
D40042P	5		0018	20 HL	D40044P	14		AS1123	03	ALL		
AC0880	06	W4210	S2	DISC BKT-LEFT FRONT SPAR DISC								
D40042J	5		0084	20 GA	D41986P	3		AP0054	05	001-099		
D40042J	5		0109	22 GA	D41986P	11		AP0054	05	115-199		
AC0880	07	W3314	L1	DISC BKT-LEFT FRONT SPAR DISC								
D40288P	25		0006	20 GA	D40024J	25		AW1285	03	ALL		
D40288P	26		0007	20 GA	D40024J	26		AW1285	03	ALL		
D40288P	22		2003B	20 GB	D40024J	22		AW1285	03	ALL		
D40288P	23		2003R	20 GB	D40024J	23		AW1285	03	ALL		
AC0880	07	W4300	L1	DISC BKT-LEFT FRONT SPAR DISC								
D40288J	32		0602	20 GA	D41898P	16		AE0501	04	ALL		
D40288J	38		0603	20 GA	D41898P	17		AE0501	04	ALL		
D40288J	21		2003B	20 GB	D41898P	21		AE0501	04	ALL		
D40288J	26		2003R	20 GB	D41898P	26		AE0501	04	ALL		
AC0880	08	W3380	S2A	DISC BKT-LEFT FRONT SPAR DISC								
D41354P	16		0012	20 GA	D42278J	16		AW1285	01	ALL		
D41354P	17		2504B	20 GF	D42278J	17		AW1285	01	ALL		
D41354P	18		2504R	20 GF	D42278J	18		AW1285	01	ALL		
D41354P	S/R		2504Z		D42278J	S/R		AW1285	01	ALL		
D41354P	30		2505B	20 GF	D42278J	30		AW1285	01	ALL		
D41354P	31		2505R	20 GF	D42278J	31		AW1285	01	ALL		
D41354P	S/R		2505Z		D42278J	S/R		AW1285	01	ALL		
AC0880	08	W4230	S2	DISC BKT-LEFT FRONT SPAR DISC								
D41354J	20		0004	22 GA	D41764P	10		AE0402	23	001-099		
D41354J	30		0022	22 GA	D41936P	8		AP0054	07	ALL		
D41354J	31		0023	20 GA	D41936P	9		AP0054	07	ALL		
D41354J	19		0026	20 GA	D41764P	17		AE0402	23	001-099		
D41354J	19		0026	20 GA	D41764P	17		AE0402	04	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AC0880

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AC0880	08	W4230	S2	DISC BKT-LEFT FRONT SPAR DISC (continued)							
D41354J	17		0027	22 GA	D41764P	12		AE0402	23	001-099	
D41354J	17		0027	22 GA	D41764P	12		AE0402	04	115-199	
D41354J	16		0028	22 GA	D41764P	11		AE0402	23	001-099	
D41354J	16		0028	22 GA	D41764P	11		AE0402	04	115-199	
D41354J	18		0029	22 GA	D41764P	13		AE0402	23	001-099	
D41354J	18		0029	22 GA	D41764P	13		AE0402	04	115-199	
AC0880	09	W4006	L2	DISC BKT-LEFT FRONT SPAR DISC							
D41100J	13		0051	22 GA	D40628J	40		AC0820	01	115-199	
AC0880	12	W3342	R1	DISC BKT-LEFT FRONT SPAR DISC							
D41394P	22		0035	20 GA	D40304P	11		AW1333	01	ALL	
D41394P	14		4501AA	20 4K	D41192P	14		AW1333	02	115-199	
D41394P	15		4501WV	20 4K	D41192P	15		AW1333	02	115-199	
AC0880	12	W4206	R2A	DISC BKT-LEFT FRONT SPAR DISC							
D41394J	22		0041	22 GA	D41656P	28		AE0503	03	ALL	
D41394J	14		4501AA	20 4K	D41636P	23		AE0304	20	115-199	
D41394J	15		4501WV	20 4K	D41636P	24		AE0304	20	115-199	
D41394J	S/R		YAAC		GD03073	ST..	E			001-099	
AC0880	15	W3302	S2	DISC BKT-LEFT FRONT SPAR DISC							
D40006P	1		0035	20 GA	D42276J	32		AW1285	07	115-199	
D40006P	1		2504B	20 GF	D42276J	32		AW1285	07	001-099	
D40006P	2		2504R	20 GF	D42276J	33		AW1285	07	001-099	
D40006P	4		2504Z		D42276J	35		AW1285	07	001-099	
D40006P	2		2505B	20 GF	D42276J	33		AW1285	07	115-199	
D40006P	3		2505R	20 GF	D42276J	34		AW1285	07	115-199	
D40006P	4		2505Z		D42276J	35		AW1285	07	115-199	
D40006P	40		3506B	20 GG	D42276J	12		AW1285	07	ALL	
D40006P	41		3506R	20 GG	D42276J	13		AW1285	07	ALL	
D40006P	42		3506Y	20 GG	D42276J	14		AW1285	07	ALL	
D40006P	S/R		3506Z		D42276J	S/R		AW1285	07	ALL	
AC0880	15	W4210	S2	DISC BKT-LEFT FRONT SPAR DISC							
D40006J	40		0001	22 GA	D41958P	38		AP0036	13	115-199	
D40006J	41		0002	22 GA	D41958P	39		AP0036	13	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AC0880

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AC0880	15	W4210	S2	DISC BKT-LEFT FRONT SPAR DISC (continued)								
D40006J	40		0103	22 GA	D41734P	47		AE0402	41	001-099		
D40006J	41		0105	22 GA	D41734P	48		AE0402	41	001-099		
D40006J	42		0107	22 GA	D41734P	49		AE0402	41	001-099		
D40006J	1		0158	20 GA	D41734P	33		AE0402	41	115-199		
D40006J	1		2507B	22 GU	D41734P	45		AE0402	41	001-099		
D40006J	2		2507R	22 GU	D41734P	54		AE0402	41	001-099		
D40006J	4		2507Z		D41734P	55		AE0402	41	001-099		
D40006J	2		2508B	20 GU	D41734P	46		AE0402	41	115-199		
D40006J	3		2508R	20 GU	D41734P	54		AE0402	41	115-199		
D40006J	4		2508Z		D41734P	55		AE0402	41	115-199		
AC0880	17	W4006	L2	DISC BKT-LEFT FRONT SPAR DISC								
D40072J	14		0053	22 GA	D40846P	17		AE0303	24	001-099		
D40072J	14		0053	22 GA	D40628J	51		AC0820	01	115-199		
D40072J	23		2002B	24 GL	D40628J	46		AC0820	01	115-199		
D40072J	24		2002R	24 GL	D40628J	47		AC0820	01	115-199		
AC0880	18	W3320	N2	DISC BKT-LEFT FRONT SPAR DISC								
D40026P	6		2003B	20 GL	D40012P	6		AS1123	01	ALL		
D40026P	5		2003R	20 GL	D40012P	5		AS1123	01	ALL		
AC0880	18	W4228	S2	DISC BKT-LEFT FRONT SPAR DISC								
D40026J	9		0097	20 GA	D42012P	9		AE0304	12	001-002, 115-199		
AC0880	19	W4204	L2B	DISC BKT-LEFT FRONT SPAR DISC								
D40302J	10		0011	22 GA	D41626P	13		AP0033	22	001-099		
D40302J	6		0050	22 GA	D41618P	4		AE0304	29	115-199		
D40302J	7		0051	22 GA	D41618P	5		AE0304	29	115-199		
D40302J	8		0192	22 GA	D40574P	3		AP0036	36	001-099		
D40302J	9		0193	22 GA	D40574P	7		AP0036	36	001-099		
AC0880	20	W3304	S2	DISC BKT-LEFT FRONT SPAR DISC								
D40018P	15		0008	20 GA	D42272P	6		AW1285	06	001-099		
D40018P	18		0009	20 GA	D42272P	9		AW1285	06	001-099		
D40018P	15		0010	20 GA	D42272P	5		AW1285	06	115-199		
D40018P	18		2502B	20 GF	D42272P	6		AW1285	06	115-199		
D40018P	32		2502R	20 GF	D42272P	28		AW1285	06	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AC0880

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AC0880	20	W3304	S2	DISC BKT-LEFT FRONT SPAR DISC (continued)							
D40018P	S/R		2502Z		D42272P	S/R		AW1285	06	115-199	
D40018P	38		2507B	20 GF	D42272P	25		AW1285	06	115-199	
D40018P	19		2507R	20 GF	D42272P	26		AW1285	06	115-199	
D40018P	S/R		2507Z		D42272P	S/R		AW1285	06	115-199	
D40018P	17		2508B	20 GF	D42272P	26		AW1285	06	001-099	
D40018P	19		2508R	20 GF	D42272P	25		AW1285	06	001-099	
D40018P	S/R		2508Z		D42272P	S/R		AW1285	06	001-099	
D40018P	20		2509B	20 GF	D42272P	5		AW1285	06	001-099	
D40018P	21		2509R	20 GF	D42272P	27		AW1285	06	001-099	
D40018P	S/R		2509Z		D42272P	S/R		AW1285	06	001-099	
AC0880	20	W4232	S2	DISC BKT-LEFT FRONT SPAR DISC							
D40018J	15		0015	20 GA	D41772P	12		AE0402	18	001-099	
D40018J	18		0016	20 GA	D41772P	18		AE0402	18	001-099	
D40018J	17		2503B	20 GU	D41782P	8		AE0203	29	001-099	
D40018J	19		2503R	20 GU	D41782P	9		AE0203	29	001-099	
D40018J	S/R		2503Z		D41782P	10		AE0203	29	001-099	
D40018J	20		2504B	20 GU	D41988P	3		AP0036	33	001-099	
D40018J	21		2504R	20 GU	D41988P	4		AP0036	33	001-099	
D40018J	S/R		2504Z		D41988P	5		AP0036	33	001-099	
AC0880	21	W3342	R1	DISC BKT-LEFT FRONT SPAR DISC							
D40076P	16		0027	20 GA	D40304P	1		AW1333	01	ALL	
D40076P	11		0028	20 GA	D40304P	2		AW1333	01	ALL	
AC0880	21	W4208	R1B	DISC BKT-LEFT FRONT SPAR DISC							
D40076J	11		0030	20 GA	D41766P	1		AP0037	07	ALL	
D40076J	16		0031	20 GA	D41766P	2		AP0037	07	ALL	
D40076J	10		0043	20 GA	D41694P	21		AE0502	24	001-099	
AC0880	22	W3300	S2	DISC BKT-LEFT FRONT SPAR DISC							
D40002P	41		0066	20 GA	D42280P	6		AW1285	05	001-099	
D40002P	30		0094	20 GA	D42280P	27		AW1285	05	001-099	
D40002P	29		0095	20 GA	D42280P	26		AW1285	05	001-099	
D40002P	21		1006	20 GE	D42280P	19		AW1285	05	001-099	
D40002P	S/R		1006Z		D42280P	S/R		AW1285	05	001-099	
D40002P	13		1008	20 GE	D42280P	12		AW1285	05	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AC0880

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AC0880	22	W3300	S2	DISC BKT-LEFT FRONT SPAR DISC (continued)							
D40002P	S/R		1008Z		D42280P	S/R		AW1285	05	001-099	
D40002P	22		2506B	20 GF	D42280P	4		AW1285	05	115-199	
D40002P	41		2506R	20 GF	D42280P	6		AW1285	05	115-199	
D40002P	S/R		2506Z		D42280P	S/R		AW1285	05	115-199	
D40002P	9		2510B	20 GF	D42280P	2		AW1285	05	115-199	
D40002P	10		2510R	20 GF	D42280P	3		AW1285	05	115-199	
D40002P	S/R		2510Z		D42280P	S/R		AW1285	05	115-199	
D40002P	23		2511B	20 GF	D42280P	20		AW1285	05	001-099	
D40002P	24		2511R	20 GF	D42280P	21		AW1285	05	001-099	
D40002P	25		2511Z		D42280P	22		AW1285	05	001-099	
D40002P	26		2512B	20 GF	D42280P	23		AW1285	05	001-099	
D40002P	27		2512R	20 GF	D42280P	24		AW1285	05	001-099	
D40002P	28		2512Z		D42280P	25		AW1285	05	001-099	
D40002P	9		3504B	20 GG	D42280P	2		AW1285	05	001-099	
D40002P	10		3504R	20 GG	D42280P	3		AW1285	05	001-099	
D40002P	22		3504Y	20 GG	D42280P	4		AW1285	05	001-099	
D40002P	S/R		3504Z		D42280P	S/R		AW1285	05	001-099	
AC0880	22	W4228	S2	DISC BKT-LEFT FRONT SPAR DISC							
D40002J	10		0094	20 GA	D41948P	14		AP0036	22	115-199	
D40002J	9		0105	20 GA	D42006P	27		AP0033	16	115-199	
D40002J	21		0108	22 GA	D42004P	10		AP0050	08	001-099	
D40002J	22		0108	22 GA	D40901P	6		AP0010	01	115-199	
D40002J	41		0109	20 GA	D41738P	42		AE0402	16	001-099	
D40002J	41		0109	22 GA	D40901P	10		AP0010	01	115-199	
D40002J	13		0201	22 GA	D42006P	14		AP0033	16	001-099	
D40002J	30		0258	20 GA	D42012P	13		AE0304	12	001-099	
D40002J	23		2509B	20 GU	D41944P	43		AP0054	01	001-099	
D40002J	24		2509R	20 GU	D41944P	44		AP0054	01	001-099	
D40002J	25		2509Z		D41944P	45		AP0054	01	001-099	
D40002J	26		2510B	20 GU	D41948P	48		AP0036	22	001-099	
D40002J	27		2510R	20 GU	D41948P	25		AP0036	22	001-099	
D40002J	28		2510Z		D41948P	26		AP0036	22	001-099	
AC0880	23	W3300	S2	DISC BKT-LEFT FRONT SPAR DISC							
D40014P	11		0057	20 GA	D42282P	11		AW1285	04	ALL	
D40014P	12		0058	20 GA	D42282P	12		AW1285	04	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AC0880

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description			To					
Equip	Term	Type	Wire No.	GA	TY		Equip	Term	Type	Matewith	Pos	Effectivity
AC0880	23	W4228	S2	DISC BKT-LEFT FRONT SPAR DISC								
D40014J	12		0096	22	GA		D41948P	11		AP0036	22	001-099
D40014J	12		0096	20	GA		D40901P	8		AP0010	01	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AC0880

Page 6 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AC1090	01	W2646	R2A	DISC BKT-LEFT KEEL BEAM								
D41812J	16		0016	20 GA	D42516P	21		AE0502	17	001-099		
D41812J	16		0016	20 GA	D41672P	26		AE0604	12	115-199		
D41812J	17		0017	20 GA	D42516P	22		AE0502	17	001-099		
D41812J	17		0017	20 GA	D41672P	27		AE0604	12	115-199		
AC1090	03	W2646	R2A	DISC BKT-LEFT KEEL BEAM								
D42189J	5		0027	20 GA	D42516P	24		AE0502	17	001-099		
AC1090	05	W4206	R2A	DISC BKT-LEFT KEEL BEAM								
D40964J	13		0038	22 GA	D41792P	10		AE0402	03	ALL		
AC1090	11	W4202	L2A	DISC BKT-LEFT KEEL BEAM								
D40348J	8		0093	20 GA	D41610P	40		AE0304	10	001-099		
D40348J	8		0093	20 GA	D41610P	40		AE0304	09	115-199		
AC1090	13	W4226	C2	DISC BKT-LEFT KEEL BEAM								
D40352J	34		0011	20 GA	D41622P	21		AE0203	38	001-099		
D40352J	34		0011	20 GA	D41622P	28		AE0203	38	115-199		
D40352J	35		0012	20 GA	D41622P	23		AE0203	38	001-099		
D40352J	35		0012	20 GA	D41622P	29		AE0203	38	115-199		
AC1090	19	W4202	L2A	DISC BKT-LEFT KEEL BEAM								
D40346J	29		0001	20 GA	D41704P	9		AP0033	24	ALL		
D40346J	30		0066	20 GA	D41652P	19		AE0501	01	ALL		
D40346J	32		0090	20 GA	D41610P	37		AE0304	10	001-099		
D40346J	32		0090	20 GA	D41610P	37		AE0304	09	115-199		
D40346J	33		0091	20 GA	D41606P	1		AE0201	31	001-099		
D40346J	33		0091	20 GA	D41610P	38		AE0304	09	115-199		
D40346J	34		0092	20 GA	D41610P	39		AE0304	10	001-099		
D40346J	34		0092	20 GA	D41610P	39		AE0304	09	115-199		
AC1090	21	W4208	R1B	DISC BKT-LEFT KEEL BEAM								
D40342J	6		0037	22 GA	D41692P	3		AP0033	28	001-099		
D40342J	6		0037	22 GA	D41766P	8		AP0037	07	115-199		
D40342J	20		0038	22 GA	D41694P	16		AE0502	24	ALL		
D40342J	22		0043	20 GA	D41696P	22		AE0501	07	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AC1090

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AC1148		02	W2441	L*	DISC BKT-L. SPOILER DISC L. WHEEL WELL							
D40573P		4		2007B	20	GB	D41761P	4		AE0301	03	ALL
D40573P		2		2007R	20	GB	D41761P	2		AE0301	03	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AC1148

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AD0820	01	W2716	R2	DISC BKT-AIR CONDITIONING SYSTEM,RIGHT								
D41638P	46		0008	24 GK	D41855P	46		AE0600	14	115-199		
D41638P	47		0009	24 GK	D41855P	47		AE0600	14	115-199		
D41638P	48		0014	24 GK	D42190P	48		AE0602	07	115-199		
D41638P	49		0015	24 GK	D42190P	49		AE0602	07	115-199		
D41638P	37		2000B	24 GL	D42190P	37		AE0602	07	115-199		
D41638P	38		2000R	24 GL	D42190P	38		AE0602	07	115-199		
AD0820	01	W4106	R2	DISC BKT-AIR CONDITIONING SYSTEM,RIGHT								
D41638J	48		0150	24 GK	D40068J	22		AD0880	01	115-199		
D41638J	49		0151	24 GK	D40068J	32		AD0880	01	115-199		
D41638J	37		2000B	24 GL	D40070J	25		AD0880	16	115-199		
D41638J	38		2000R	24 GL	D40070J	24		AD0880	16	115-199		
AD0820	02	W2716	R2	DISC BKT-AIR CONDITIONING SYSTEM,RIGHT								
D41640P	27		0242	24 GK	D41855P	55		AE0600	14	115-199		
D41640P	28		0243	24 GK	D41855P	54		AE0600	14	115-199		
AD0820	02	W4106	R2	DISC BKT-AIR CONDITIONING SYSTEM,RIGHT								
D41640J	53		0157	24 GK	D41546P	49		AP0037	31	115-199		
D41640J	27		0242	24 GK	D40064P	55		AP0037	40	115-199		
D41640J	28		0243	24 GK	D40064P	54		AP0037	40	115-199		
AD0820	03	W2716	R2	DISC BKT-AIR CONDITIONING SYSTEM,RIGHT								
D41642P	48		0010	24 GK	D41855P	48		AE0600	14	115-199		
D41642P	49		0011	24 GK	D41855P	49		AE0600	14	115-199		
D41642P	43		0012	24 GK	D42184P	23		AE0604	03	115-199		
D41642P	44		0013	24 GK	D42184P	24		AE0604	03	115-199		
D41642P	38		0016	24 GK	D42190P	34		AE0602	07	115-199		
D41642P	41		0017	24 GK	D42190P	35		AE0602	07	115-199		
D41642P	39		2004B	24 GL	D42190P	39		AE0602	07	115-199		
D41642P	40		2004R	24 GL	D42190P	40		AE0602	07	115-199		
AD0820	03	W4106	R2	DISC BKT-AIR CONDITIONING SYSTEM,RIGHT								
D41642J	41		0162	24 GK	D40064P	24		AP0037	40	115-199		
D41642J	42		0244	22 GA	D40064P	52		AP0037	40	115-199		
D41642J	43		0245	22 GA	D40064P	53		AP0037	40	115-199		
D41642J	34		0248	24 GK	D42086P	34		AE0402	36	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AD0820

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AD0820	03	W4106	R2	DISC BKT-AIR CONDITIONING SYSTEM,RIGHT (continued)								
D41642J	35		0249	24	GK	D42086P	35		AE0402	36	115-199	
D41642J	39		2029B	24	GL	D40976P	49		AP0050	04	115-199	
D41642J	40		2029R	24	GL	D40976P	50		AP0050	04	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AD0820

Page 2 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AD0880	01	W4106	R2	DISC BKT-RIGHT FRONT SPAR DISC								
D40068J	22		0150	24 GK	D41638J	48		AD0820	01	115-199		
D40068J	32		0151	24 GK	D41638J	49		AD0820	01	115-199		
AD0880	03	W3480	S2A	DISC BKT-RIGHT FRONT SPAR DISC								
D41358P	16		0012	20 GA	D42290J	16		AW2285	07	ALL		
D41358P	17		2504B	20 GF	D42290J	17		AW2285	07	ALL		
D41358P	18		2504R	20 GF	D42290J	18		AW2285	07	ALL		
D41358P	S/R		2504Z		D42290J	S/R		AW2285	07	ALL		
D41358P	30		2505B	20 GF	D42290J	30		AW2285	07	ALL		
D41358P	31		2505R	20 GF	D42290J	31		AW2285	07	ALL		
D41358P	S/R		2505Z		D42290J	S/R		AW2285	07	ALL		
AD0880	03	W4234	S2	DISC BKT-RIGHT FRONT SPAR DISC								
D41358J	19		0011	22 GA	D41774P	14		AE0402	14	001-099		
D41358J	19		0011	22 GA	D41774P	14		AE0402	46	115-199		
D41358J	20		0012	22 GA	D41940P	7		AP0054	09	ALL		
D41358J	30		0025	22 GA	D41940P	10		AP0054	09	ALL		
D41358J	31		0026	22 GA	D41940P	11		AP0054	09	ALL		
D41358J	17		2503B	22 GU	D41774P	12		AE0402	14	001-099		
D41358J	17		2503B	22 GU	D41774P	12		AE0402	46	115-199		
D41358J	16		2503R	22 GU	D41774P	11		AE0402	14	001-099		
D41358J	16		2503R	22 GU	D41774P	11		AE0402	46	115-199		
D41358J	18		2503Z		D41774P	13		AE0402	14	001-099		
D41358J	18		2503Z		D41774P	13		AE0402	46	115-199		
AD0880	04	W3446	L1	DISC BKT-RIGHT FRONT SPAR DISC								
D42076P	1		0001	20 GA	D40404P	1		AW2333	02	ALL		
D42076P	11		0011	20 GA	D40404P	11		AW2333	02	ALL		
D42076P	12		0012	20 GA	D40404P	12		AW2333	02	ALL		
D42076P	13		0013	20 GA	D40404P	13		AW2333	02	ALL		
D42076P	14		0014	20 GA	D40404P	14		AW2333	02	ALL		
AD0880	04	W4212	L2	DISC BKT-RIGHT FRONT SPAR DISC								
D42076J	11		0015	22 GA	D41654P	19		AE0501	21	001-099		
D42076J	11		0015	22 GA	D41634P	8		AE0304	06	115-199		
D42076J	12		0016	22 GA	D41634P	18		AE0304	06	001-099		
D42076J	12		0016	22 GA	D41634P	9		AE0304	06	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AD0880

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description			To						
Equip	Term	Type	Wire No.	GA	TY		Equip	Term	Type	Matewith	Pos	Effectivity	
AD0880	05	W3402	S2	DISC BKT-RIGHT FRONT SPAR DISC									
D40032P	1		0035	20	GA		D42288J	1		AW2285	01	115-199	
D40032P	1		2504B	20	GF		D42288J	1		AW2285	01	001-099	
D40032P	2		2504R	20	GF		D42288J	2		AW2285	01	001-099	
D40032P	4		2504Z				D42288J	4		AW2285	01	001-099	
D40032P	2		2505B	20	GF		D42288J	2		AW2285	01	115-199	
D40032P	3		2505R	20	GF		D42288J	3		AW2285	01	115-199	
D40032P	4		2505Z				D42288J	4		AW2285	01	115-199	
D40032P	40		3506B	20	GG		D42288J	40		AW2285	01	ALL	
D40032P	41		3506R	20	GG		D42288J	41		AW2285	01	ALL	
D40032P	42		3506Y	20	GG		D42288J	42		AW2285	01	ALL	
D40032P	S/R		3506Z				D42288J	S/R		AW2285	01	ALL	
AD0880	05	W4220	S2	DISC BKT-RIGHT FRONT SPAR DISC									
D40032J	41		0044	20	GA		D41736P	5		AE0402	11	115-199	
D40032J	42		0045	20	GA		D41736P	6		AE0402	11	115-199	
D40032J	40		0149	22	GA		D41736P	49		AE0402	11	001-099	
D40032J	41		0150	22	GA		D41736P	50		AE0402	11	001-099	
D40032J	42		0151	22	GA		D41736P	51		AE0402	11	001-099	
D40032J	1		0158	20	GA		D41736P	47		AE0402	11	115-199	
D40032J	1		2504B	22	GU		D41736P	52		AE0402	11	001-099	
D40032J	2		2504R	22	GU		D41736P	53		AE0402	11	001-099	
D40032J	4		2504Z				D41736P	54		AE0402	11	001-099	
D40032J	2		2508B	20	GU		D41736P	48		AE0402	11	115-199	
D40032J	3		2508R	20	GU		D41736P	49		AE0402	11	115-199	
D40032J	4		2508Z				D41736P	50		AE0402	11	115-199	
AD0880	06	W3460	S2	DISC BKT-RIGHT FRONT SPAR DISC									
D40334P	15		0015	20	GA		D40330P	15		AW2333	01	115-199	
D40334P	21		0021	20	GA		D40330P	21		AW2333	01	115-199	
D40334P	48		2001B	20	GB		D40330P	48		AW2333	01	ALL	
D40334P	49		2001R	20	GB		D40330P	49		AW2333	01	ALL	
D40334P	50		2002B	20	GB		D40330P	50		AW2333	01	ALL	
D40334P	51		2002R	20	GB		D40330P	51		AW2333	01	ALL	
D40334P	52		2003B	20	GB		D40330P	52		AW2333	01	ALL	
D40334P	53		2003R	20	GB		D40330P	53		AW2333	01	ALL	
D40334P	54		2004B	20	GB		D40330P	54		AW2333	01	ALL	
D40334P	55		2004R	20	GB		D40330P	55		AW2333	01	ALL	
D40334P	CAP	Y	2006B	20	GB		D40330P	CAP	Y	AW2333	01	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AD0880

Page 2

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AD0880	06	W3460	S2	DISC BKT-RIGHT FRONT SPAR DISC (continued)								
D40334P	CAP	Y	2006R	20 GB	D40330P	CAP	Y	AW2333	01	115-199		
D40334P	13		2007B	20 GB	D40330P	13		AW2333	01	115-199		
D40334P	CAP	Y	2007R	20 GB	D40330P	12		AW2333	01	115-199		
D40334P	CAP	Y	2009B	20 GB	D40330P	17		AW2333	01	115-199		
D40334P	16		2009R	20 GB	D40330P	16		AW2333	01	115-199		
D40334P	CAP	Y	2010B	20 GB	D40330P	CAP	Y	AW2333	01	115-199		
D40334P	CAP	Y	2010R	20 GB	D40330P	CAP	Y	AW2333	01	115-199		
D40334P	25		2013B	20 GB	D40330P	25		AW2333	01	115-199		
D40334P	24		2013R	20 GB	D40330P	24		AW2333	01	115-199		
D40334P	38		4001R	20 GD	D40330P	38		AW2333	01	115-199		
AD0880	06	W4216	R2A	DISC BKT-RIGHT FRONT SPAR DISC								
D40334J	15		0043	20 GA	D41614P	3		AE0304	30	115-199		
D40334J	21		0045	20 GA	D41614P	CAP	Y	AE0304	30	115-199		
D40334J	26		0073	22 GA	D41718P	5		AP0033	29	001-099		
D40334J	8		0101	20 GA	D42060P	2		AE0304	28	001-099		
D40334J	3		0103	22 GA	D42060P	9		AE0304	28	001-099		
D40334J	48		0108	20 GA	D41718P	32		AP0033	29	115-199		
D40334J	49		0109	20 GA	D41718P	33		AP0033	29	ALL		
D40334J	50		0110	20 GA	D41718P	34		AP0033	29	ALL		
D40334J	25		2005B	20 GB	D41614P	16		AE0304	30	115-199		
D40334J	24		2005R	20 GB	D41614P	17		AE0304	30	115-199		
D40334J	CAP	Y	2006B	20 GB	D41614P	CAP	Y	AE0304	30	115-199		
D40334J	CAP	Y	2006R	20 GB	D41614P	CAP	Y	AE0304	30	115-199		
D40334J	13		2007B	20 GB	D41614P	8		AE0304	30	115-199		
D40334J	CAP	Y	2007R	20 GB	D41614P	9		AE0304	30	115-199		
D40334J	CAP	Y	2008B	20 GB	D41614P	CAP	Y	AE0304	30	115-199		
D40334J	CAP	Y	2008R	20 GB	D41614P	CAP	Y	AE0304	30	115-199		
D40334J	CAP	Y	2009B	20 GB	D41614P	CAP	Y	AE0304	30	115-199		
D40334J	16		2009R	20 GB	D41614P	13		AE0304	30	115-199		
D40334J	38		4002R	22 GD	D41614P	32		AE0304	30	115-199		
AD0880	07	W3458	S2	DISC BKT-RIGHT FRONT SPAR DISC								
D40332P	18		2001B	20 GB	D40328P	18		AW2333	03	ALL		
D40332P	19		2001R	20 GB	D40328P	19		AW2333	03	ALL		
AD0880	07	W4216	R2A	DISC BKT-RIGHT FRONT SPAR DISC								
D40332J	18		0111	20 GA	D41718P	35		AP0033	29	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AD0880

Page 3

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AD0880	07	W4216	R2A	DISC BKT-RIGHT FRONT SPAR DISC (continued)							
D40332J	19		0112	20 GA	D41718P	36		AP0033	29	ALL	
AD0880	08	W3400	S2	DISC BKT-RIGHT FRONT SPAR DISC							
D40004P	25		0062	20 GA	D42292P	6		AW2285	05	ALL	
D40004P	41		0064	20 GA	D42292P	7		AW2285	05	ALL	
D40004P	18		1005	20 GE	D42292P	18		AW2285	05	001-099	
D40004P	S/R		1005Z		D42292P	S/R		AW2285	05	001-099	
D40004P	38		2509B	20 GF	D42292P	38		AW2285	05	001-099	
D40004P	39		2509R	20 GF	D42292P	39		AW2285	05	001-099	
D40004P	S/R		2509Z		D42292P	S/R		AW2285	05	001-099	
D40004P	12		2510B	20 GF	D42292P	40		AW2285	05	001-099	
D40004P	13		2510R	20 GF	D42292P	41		AW2285	05	001-099	
D40004P	S/R		2510Z		D42292P	S/R		AW2285	05	001-099	
AD0880	08	W4236	S2	DISC BKT-RIGHT FRONT SPAR DISC							
D40004J	41		0083	20 GA	D41776P	12		AE0402	10	115-199	
D40004J	25		0084	20 GA	D42010P	14		AP0037	48	115-199	
D40004J	43		0152	20 GA	D42014P	14		AE0304	28	115-199	
D40004J	18		0220	22 GA	D41990P	16		AP0050	06	001-099	
D40004J	41		0221	20 GA	D41776P	12		AE0402	10	001-099	
D40004J	12		2509B	20 GU	D41776P	40		AE0402	10	001-099	
D40004J	13		2509R	20 GU	D41776P	41		AE0402	10	001-099	
D40004J	S/R		2509Z		D41776P	9		AE0402	10	001-099	
D40004J	38		2510B	20 GU	D42010P	37		AP0037	48	001-099	
D40004J	39		2510R	20 GU	D42010P	38		AP0037	48	001-099	
D40004J	S/R		2510Z		D42010P	39		AP0037	48	001-099	
AD0880	10	W3424	R2	DISC BKT-RIGHT FRONT SPAR DISC							
D40402P	6		0003	20 GA	D41196P	16		AW2333	04	115-199	
D40402P	7		0004	20 GA	D41196P	17		AW2333	04	115-199	
D40402P	13		0010	20 GA	D41196P	18		AW2333	04	115-199	
D40402P	11		0011	20 GA	D41196P	19		AW2333	04	115-199	
AD0880	10	W4218	R2A	DISC BKT-RIGHT FRONT SPAR DISC							
D40402J	13		0010	22 GA	D41728P	12		AP0037	24	001-099	
D40402J	11		0011	22 GA	D41632P	11		AE0402	26	001-099	
D40402J	2		0033	20 GA	D41728P	9		AP0037	24	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AD0880

Page 4

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AD0880	10	W4218	R2A	DISC BKT-RIGHT FRONT SPAR DISC (continued)								
D40402J	19		0043	20 GA	D41620P	21		AE0304	31	115-199		
D40402J	20		0044	20 GA	D41620P	23		AE0304	31	115-199		
AD0880	12	W3420	N2	DISC BKT-RIGHT FRONT SPAR DISC								
D40274P	6		2003B	20 GL	D40272P	6		AS2123	01	ALL		
D40274P	5		2003R	20 GL	D40272P	5		AS2123	01	ALL		
AD0880	12	W4236	S2	DISC BKT-RIGHT FRONT SPAR DISC								
D40274J	9		0089	20 GA	D42014P	9		AE0304	15	001-099		
D40274J	9		0089	20 GA	D42014P	7		AE0304	28	115-199		
D40274J	6		2003B	20 GB	D41946P	25		AP0054	02	115-199		
D40274J	5		2003R	20 GB	D41946P	26		AP0054	02	115-199		
AD0880	14	W4220	S2	DISC BKT-RIGHT FRONT SPAR DISC								
D40280J	10		2005B	20 GB	D42018P	15		AE0304	04	115-199		
D40280J	9		2005R	20 GB	D42018P	41		AE0304	04	115-199		
AD0880	15	W3400	S2	DISC BKT-RIGHT FRONT SPAR DISC								
D40016P	27		0067	20 GA	D42294P	5		AW2285	04	001-099		
D40016P	28		2505B	20 GF	D42294P	1		AW2285	04	115-199		
D40016P	29		2505R	20 GF	D42294P	2		AW2285	04	115-199		
D40016P	S/R		2505Z		D42294P	S/R		AW2285	04	115-199		
D40016P	30		2506B	20 GF	D42294P	3		AW2285	04	115-199		
D40016P	27		2506R	20 GF	D42294P	5		AW2285	04	115-199		
D40016P	S/R		2506Z		D42294P	S/R		AW2285	04	115-199		
D40016P	28		3504B	20 GG	D42294P	1		AW2285	04	001-099		
D40016P	29		3504R	20 GG	D42294P	2		AW2285	04	001-099		
D40016P	30		3504Y	20 GG	D42294P	3		AW2285	04	001-099		
D40016P	S/R		3504Z		D42294P	S/R		AW2285	04	001-099		
AD0880	15	W4236	S2	DISC BKT-RIGHT FRONT SPAR DISC								
D40016J	28		0085	20 GA	D41946P	23		AP0054	02	115-199		
D40016J	29		0086	20 GA	D41946P	24		AP0054	02	115-199		
D40016J	27		0236	20 GA	D42010P	36		AP0037	48	001-099		
AD0880	16	W4106	R2	DISC BKT-RIGHT FRONT SPAR DISC								
D40070J	25		2000B	24 GL	D41638J	37		AD0820	01	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AD0880

Page 5

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AD0880	16	W4106	R2	DISC BKT-RIGHT FRONT SPAR DISC (continued)								
D40070J	24		2000R	24 GL	D41638J	38		AD0820	01	115-199		
AD0880	18	W3424	R2	DISC BKT-RIGHT FRONT SPAR DISC								
D41198P	14		4501AA	20 4K	D41196P	14		AW2333	04	115-199		
D41198P	15		4501WV	20 4K	D41196P	15		AW2333	04	115-199		
AD0880	18	W4218	R2A	DISC BKT-RIGHT FRONT SPAR DISC								
D41198J	14		4501AA	20 4K	D41620P	38		AE0304	31	115-199		
D41198J	15		4501WV	20 4K	D41620P	39		AE0304	31	115-199		
AD0880	20	W3404	S2	DISC BKT-RIGHT FRONT SPAR DISC								
D40020P	15		0010	20 GA	D42284P	15		AW2285	06	115-199		
D40020P	21		2502B	20 GF	D42284P	19		AW2285	06	001-099		
D40020P	12		2502B	20 GF	D42284P	12		AW2285	06	115-199		
D40020P	27		2502R	20 GF	D42284P	20		AW2285	06	001-099		
D40020P	18		2502R	20 GF	D42284P	18		AW2285	06	115-199		
D40020P	28		2502Z		D42284P	S/R		AW2285	06	001-099		
D40020P	S/R		2502Z		D42284P	S/R		AW2285	06	115-199		
D40020P	15		2506B	20 GF	D42284P	17		AW2285	06	001-099		
D40020P	18		2506R	20 GF	D42284P	18		AW2285	06	001-099		
D40020P	S/R		2506Z		D42284P	S/R		AW2285	06	001-099		
D40020P	19		2507B	20 GF	D42284P	19		AW2285	06	115-199		
D40020P	20		2507R	20 GF	D42284P	20		AW2285	06	115-199		
D40020P	S/R		2507Z		D42284P	S/R		AW2285	06	115-199		
AD0880	20	W4238	S2	DISC BKT-RIGHT FRONT SPAR DISC								
D40020J	21		2502B	22 GU	D41788P	1		AE0402	20	001-099		
D40020J	27		2502R	22 GU	D41788P	23		AE0402	20	001-099		
D40020J	28		2502Z		D41788P	11		AE0402	20	001-099		
D40020J	15		2503B	20 GU	D41998P	4		AP0037	41	001-099		
D40020J	18		2503R	20 GU	D41998P	5		AP0037	41	001-099		
D40020J	19		2503Z		D41998P	6		AP0037	41	001-099		
AD0880	21	W3428	R2	DISC BKT-RIGHT FRONT SPAR DISC								
D40046P	1		0009	20 HL	D40048P	1		AS2123	03	ALL		
D40046P	6		0010	20 HL	D40048P	6		AS2123	03	ALL		
D40046P	7		0011	20 HL	D40048P	7		AS2123	03	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AD0880

Page 6

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AD0880	21	W4220	S2	DISC BKT-RIGHT FRONT SPAR DISC							
D40046J	6		0020	20 GA	D41992P	5		AP0054	08	001-099	
AD0880	23	W3414	R1	DISC BKT-RIGHT FRONT SPAR DISC							
D40290P	25		0006	20 GA	D40028J	25		AW2285	02	ALL	
D40290P	26		0007	20 GA	D40028J	26		AW2285	02	ALL	
D40290P	22		2003B	20 GB	D40028J	22		AW2285	02	ALL	
D40290P	23		2003R	20 GB	D40028J	23		AW2285	02	ALL	
AD0880	23	W4302	R1	DISC BKT-RIGHT FRONT SPAR DISC							
D40290J	29		0004	20 GA	D40398P	24		AE0502	23	ALL	
D40290J	30		0005	20 GA	D40398P	25		AE0502	23	ALL	
D40290J	21		2003B	20 GB	D40398P	7		AE0502	23	ALL	
D40290J	23		2003R	20 GB	D40398P	13		AE0502	23	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AD0880

Page 7 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AD1090	03	W4220	S2	DISC BKT-RIGHT KEEL BEAM							
D40370J	23		0089	20 GA	D41736P	40		AE0402	11	115-199	
D40370J	10		0090	20 GA	D41736P	41		AE0402	11	115-199	
AD1090	08	W4216	R2A	DISC BKT-RIGHT KEEL BEAM							
D40358J	5		0107	20 GA	D42062P	CAP	Y	AP0037	39	001-099	
AD1090	10	W4216	R2A	DISC BKT-RIGHT KEEL BEAM							
D40360J	19		0106	22 GA	D41730P	11		AE0502	10	115-199	
AD1090	18	W2644	L2B	DISC BKT-RIGHT KEEL BEAM							
D43010J	4		0028	20 GA	D42512P	4		AE0502	05	001-099	
D43010J	5		0029	20 GA	D42512P	5		AE0502	05	001-099	
AD1090	20	W2644	L2B	DISC BKT-RIGHT KEEL BEAM							
D41818J	7		0027	20 GA	D42510P	14		AE0502	04	001-099	
AD1090	22	W4212	L2	DISC BKT-RIGHT KEEL BEAM							
D40362J	22		0019	20 GA	D41722P	5		AP0033	21	ALL	
AD1090	8	W4216	R2A	DISC BKT-RIGHT KEEL BEAM							
D40358J	5		0107	20 GA	D42062P	CAP	Y	AP0037	39	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AD1090

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AD1650	01	W2615	L2								
D41225P	4		2503B	20	H5	D01827	5		AC0210	03	ALL
D41225P	3		2503R	20	H5	D01827	3		AC0210	03	ALL
D41225P	DED		2503Z			D01827	DED		AC0210	03	ALL
AD1650	03	W2613	R2								
D41227P	4		2503B	20	H5	D01825	2		AC0210	04	ALL
D41227P	3		2503R	20	H5	D01825	1		AC0210	04	ALL
D41227P	DED		2503Z			D01825	DED		AC0210	04	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AD1650

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0101	12	W2244	R1	DISC BKT-E1-1 SHELF DISC								
D41756P	7		0057	16	GA	D41122P	7		AP0037	09	115-199	
D41756P	8		0058	16	GA	D41122P	8		AP0037	09	115-199	
D41756P	9		0604	20	GA	D41122P	9		AP0037	09	115-199	
D41756P	10		0605	20	GA	D41122P	10		AP0037	09	115-199	
D41756P	11		0606	20	GA	D41122P	11		AP0037	09	115-199	
D41756P	12		0607	20	GA	D41122P	12		AP0037	09	115-199	
AE0101	14	W2072	R*	DISC BKT-E1-1 SHELF DISC								
D41872P	7		0115	20	GA	D41842P	16		AE0402	31	115-199	
D41872P	8		0116	20	GA	D41842P	17		AE0402	31	115-199	
D41872P	9		0117	20	GA	D41848P	9		AP0034	12	ALL	
D41872P	10		0118	20	GA	D41848P	10		AP0034	12	ALL	
D41872P	11		0119	20	GA	D41848P	11		AP0034	12	115-199	
D41872P	12		0120	20	GA	D41848P	12		AP0034	12	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0101

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0102	12	W2352	L1	DISC BKT-E1-2 SHELF DISC								
D41914P	5		0636	20	GA	D41880P	27		AP0070	07	115-199	
D41914P	6		0637	20	GA	D41880P	22		AP0070	07	115-199	
D41914P	7		0638	20	GA	D41880P	28		AP0070	07	115-199	
D41914P	8		0639	20	GA	D41880P	24		AP0070	07	115-199	
D41914P	9		0640	20	GA	D41880P	25		AP0070	07	115-199	
D41914P	10		0641	20	GA	D41880P	26		AP0070	07	115-199	
D41914P	18		0643	12	GA	D41754P	11		AP0070	09	115-199	
D41914P	19		0651	20	GA	D41880P	29		AP0070	07	115-199	
D41914P	20		0652	20	GA	D41880P	30		AP0070	07	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0102

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0201	01	W4479	L2	DISC BKT-E2-1 SHELF DISC							
D41595P	28		0021	22 GA	D41567P	38		AE0203	13	ALL	
D41595P	38		0022	22 GA	D41743P	4		AE0202	12	ALL	
AE0201	02	W4475	C2	DISC BKT-E2-1 SHELF DISC							
D41391P	13		0011	22 GA	D41493P	1		AP0036	29	115-199	
D41391P	15		0018	22 GA	D41395P	34		AE0203	23	115-199	
D41391P	18		0021	22 GA	D41395P	37		AE0203	23	ALL	
D41391P	23		0024	22 GA	D41395P	46		AE0203	23	115-199	
D41391P	24		0025	22 GA	D41395P	47		AE0203	23	115-199	
D41391P	28		0050	22 GA	D41493P	3		AP0036	29	115-199	
D41391P	8		5007B	24 G2	D41395P	16		AE0203	23	ALL	
D41391P	7		5007R	24 G2	D41395P	15		AE0203	23	ALL	
D41391P	9		5007Z		D41395P	17		AE0203	23	ALL	
D41391P	26		5020B	24 G2	D41393P	26		AE0202	13	ALL	
D41391P	25		5020R	24 G2	D41393P	25		AE0202	13	ALL	
D41391P	27		5020Z		D41393P	27		AE0202	13	ALL	
D41391P	2		5021B	24 G2	D41395P	54		AE0203	23	115-199	
D41391P	1		5021R	24 G2	D41395P	53		AE0203	23	115-199	
D41391P	3		5021Z		D41395P	55		AE0203	23	115-199	
D41391P	30		5023B	24 G2	D41397P	28		AE0204	16	115-199	
D41391P	29		5023R	24 G2	D41397P	27		AE0204	16	115-199	
D41391P	31		5023Z		D41397P	29		AE0204	16	115-199	
AE0201	03	W4471	L2	DISC BKT-E2-1 SHELF DISC							
D43003P	15		0283	22 GA	D43001P	15		AE0302	33	001-099	
D43003P	3		0284	24 GK	D43001P	16		AE0302	33	001-099	
D43003P	1		0327	22 GA	D41325P	7		AE0501	16	003-099	
D43003P	13		5088B	24 G2	D43001P	18		AE0302	33	001-099	
D43003P	12		5088R	24 G2	D43001P	17		AE0302	33	001-099	
D43003P	14		5088Z		D43001P	19		AE0302	33	001-099	
AE0201	10	W4471	L2	DISC BKT-E2-1 SHELF DISC							
D41089P	51		0100	24 GK	D41095P	7		AE0202	28	115-199	
D41089P	24		5007B	24 G2	D41309P	2		AE0303	05	115-199	
D41089P	23		5007R	24 G2	D41309P	1		AE0303	05	115-199	
D41089P	25		5007Z		D41309P	3		AE0303	05	115-199	
D41089P	41		5042B	24 G2	D41317P	25		AE0402	07	001-099	
D41089P	40		5042R	24 G2	D41317P	24		AE0402	07	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0201

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0201	10	W4471	L2	DISC BKT-E2-1 SHELF DISC (continued)								
D41089P	DED		5042Z		D41317P	26		AE0402	07	001-099		
AE0201	11	W4481	R2	DISC BKT-E2-1 SHELF DISC								
D41601P	42		0019	24 GK	D41605P	36		AE0203	20	001-099		
D41601P	43		0023	22 GA	D41679P	36		AE0202	41	ALL		
D41601P	2		0034	24 GK	D41679P	50		AE0202	41	115-199		
D41601P	3		0035	24 GK	D41603P	31		AE0202	33	ALL		
D41601P	36		5001B	24 G2	D41603P	48		AE0202	33	001-099		
D41601P	35		5001R	24 G2	D41603P	47		AE0202	33	001-099		
D41601P	37		5001Z		D41603P	49		AE0202	33	001-099		
D41601P	32		5012B	24 G2	D41603P	2		AE0202	33	115-199		
D41601P	31		5012R	24 G2	D41603P	1		AE0202	33	115-199		
D41601P	33		5012Z		D41603P	3		AE0202	33	115-199		
AE0201	13	W2251	L2	DISC BKT-E2-1 SHELF DISC								
D42065P	15		0006	22 GA	D40035J	13		AP0003	12	115-199		
D42065P	16		0009	24 GK	D40035J	29		AP0003	12	115-199		
D42065P	13		2005B	22 GB	D40035J	15		AP0003	12	001-099		
D42065P	13		2005B	22 GB	D40035J	38		AP0003	12	115-199		
D42065P	14		2005R	22 GB	D40035J	14		AP0003	12	001-099		
D42065P	14		2005R	22 GB	D40035J	37		AP0003	12	115-199		
AE0201	15	W2241	L2	DISC BKT-E2-1 SHELF DISC								
D42013P	2		0059	22 GA	D40629J	2		AP0001	08	001-099		
D42013P	22		0064	22 GA	D40629J	27		AP0001	08	115-199		
D42013P	23		0065	22 GA	D40629J	28		AP0001	08	115-199		
D42013P	29		2525B	24 G2	D40629J	30		AP0001	08	115-199		
D42013P	28		2525R	24 G2	D40629J	29		AP0001	08	115-199		
D42013P	30		2525Z		D40629J	31		AP0001	08	115-199		
D42013P	20		2526B	24 G2	D40629J	33		AP0001	08	115-199		
D42013P	19		2526R	24 G2	D40629J	32		AP0001	08	115-199		
D42013P	21		2526Z		D40629J	34		AP0001	08	115-199		
D42013P	22		5021B	24 G2	D40629J	45		AP0001	08	001-099		
D42013P	26		5021B	24 G2	D40629J	45		AP0001	08	115-199		
D42013P	21		5021R	24 G2	D40629J	44		AP0001	08	001-099		
D42013P	25		5021R	24 G2	D40629J	44		AP0001	08	115-199		
D42013P	23		5021Z		D40629J	46		AP0001	08	001-099		
D42013P	27		5021Z		D40629J	46		AP0001	08	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0201

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0201	17	W2350	L1	DISC BKT-E2-1 SHELF DISC							
D41910P	6		0018	22 GA	D40610P	18		AP0011	03	ALL	
D41910P	1		0031	24 GK	D40610P	31		AP0011	03	002, 009-099, 115-199	
D41910P	17		0066	22 GA	D40612P	46		AP0011	04	009-099	
D41910P	18		0067	22 GA	D40612P	47		AP0011	04	009-099	
D41910P	4		0082	24 GK	D40610P	32		AP0011	03	001-099	
AE0201	21	W4471	L2	DISC BKT-E2-1 SHELF DISC							
D41091P	28		0043	22 GA	D41481P	27		AP0051	01	ALL	
D41091P	48		0073	22 GA	D41317P	30		AE0402	07	ALL	
D41091P	2		0143	22 GA	D41301P	29		AE0301	08	ALL	
D41091P	55		0145	22 GA	D41303P	34		AE0302	40	ALL	
AE0201	22	W4481	R2	DISC BKT-E2-1 SHELF DISC							
D41745P	11		0033	24 GK	D41821P	8		AE0202	30	115-199	
D41745P	12		0036	24 GK	D41679P	51		AE0202	41	ALL	
D41745P	14		5011B	24 G2	D41821P	14		AE0202	30	001, 003-099	
D41745P	REF	JB	5011B	24 G2	D41821P	14		AE0202	30	002	
D41745P	13		5011R	24 G2	D41821P	13		AE0202	30	001, 003-099	
D41745P	REF	JB	5011R	24 G2	D41821P	13		AE0202	30	002	
D41745P	15		5011Z		D41821P	15		AE0202	30	001, 003-099	
D41745P	DED		5011Z		D41821P	15		AE0202	30	002	
AE0201	25	W2331	N2	DISC BKT-E2-1 SHELF DISC							
D41081P	13		5004B	24 G2	D00171	CAP	Y	M00076		115-199	
D41081P	12		5004R	24 G2	D00171	CAP	Y	M00076		115-199	
D41081P	14		5004Z		GD01100	ST..	E			115-199	
AE0201	28	W2241	L2	DISC BKT-E2-1 SHELF DISC							
D42011P	37		0032	22 GA	D40039J	35		AP0001	12	115-199	
D42011P	14		2002B	22 GB	D40039J	14		AP0001	12	001-099	
D42011P	13		2002R	22 GB	D40039J	13		AP0001	12	001-099	
D42011P	42		2512B	24 G2	D40039J	38		AP0001	12	115-199	
D42011P	41		2512R	24 G2	D40039J	37		AP0001	12	115-199	
D42011P	43		2512Z		D40039J	39		AP0001	12	115-199	
D42011P	11		3002B	24 GM	D40039J	11		AP0001	12	001-099	
D42011P	10		3002R	24 GM	D40039J	10		AP0001	12	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0201

Page 3

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0201	28	W2241	L2	DISC BKT-E2-1 SHELF DISC (continued)							
D42011P	12		3002Y	24 GM	D40039J	12		AP0001	12	001-099	
D42011P	3		5001B	24 G2	D40031J	23		AP0001	16	115-199	
D42011P	2		5001R	24 G2	D40031J	22		AP0001	16	115-199	
D42011P	1		5001Z		D40031J	24		AP0001	16	115-199	
D42011P	29		5008B	24 G2	D40039J	29		AP0001	12	ALL	
D42011P	28		5008R	24 G2	D40039J	28		AP0001	12	ALL	
D42011P	30		5008Z		D40039J	30		AP0001	12	ALL	
AE0201	31	W4202	L2A	DISC BKT-E2-1 SHELF DISC							
D41606P	3		0088	20 GA	D41610P	35		AE0304	10	001-099	
D41606P	3		0088	20 GA	D41610P	35		AE0304	09	115-199	
D41606P	4		0089	20 GA	D41610P	36		AE0304	10	001-099	
D41606P	4		0089	20 GA	D41610P	36		AE0304	09	115-199	
D41606P	1		0091	20 GA	D40346J	33		AC1090	19	001-099	
AE0201	32	W4477	S2	DISC BKT-E2-1 SHELF DISC							
D41429P	7		0004	24 GK	D41433P	7		AE0203	03	002	
D41429P	2		0116	24 GK	D41443P	33		AE0303	08	115-199	
D41429P	27		0126	24 GK	D41453P	46		AE0403	07	115-199	
D41429P	28		0134	24 GK	D41453P	2		AE0403	07	115-199	
AE0201	35	W4471	L2	DISC BKT-E2-1 SHELF DISC							
D41905P	5		0113	24 GK	D41473P	33		AP0036	21	001-099	
D41905P	28		0177	24 GK	D41879P	44		AE0402	38	001-099	
D41905P	6		0234	22 GA	D41643P	6		AE0203	31	001-099	
D41905P	13		0329	24 GK	D41643P	25		AE0203	31	002	
D41905P	14		0330	24 GK	D41643P	26		AE0203	31	002	
D41905P	15		0331	24 GK	D41643P	27		AE0203	31	002	
D41905P	11		0332	24 GK	D41643P	28		AE0203	31	002	
AE0201	37	W4471	L2	DISC BKT-E2-1 SHELF DISC							
D41093P	18		0124	24 GK	D41879P	40		AE0402	38	115-199	
D41093P	22		0125	24 GK	D41879P	41		AE0402	38	115-199	
D41093P	34		0146	24 GK	D41473P	47		AP0036	21	ALL	
D41093P	38		0147	24 GK	D41477P	1		AP0050	02	ALL	
D41093P	49		0182	24 GK	D41475P	1		AP0036	02	115-199	
D41093P	50		0183	24 GK	D41475P	2		AP0036	02	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0201

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0201	37	W4471	L2	DISC BKT-E2-1 SHELF DISC (continued)							
D41093P	13		5020B	24 G2	D41325P	15		AE0501	16	115-199	
D41093P	11		5020R	24 G2	D41325P	16		AE0501	16	115-199	
D41093P	12		5020Z		D41325P	17		AE0501	16	115-199	
D41093P	30		5040B	24 G2	D41097P	40		AE0203	21	002	
D41093P	29		5040R	24 G2	D41097P	39		AE0203	21	002	
D41093P	28		5040Z		D41097P	38		AE0203	21	002	
D41093P	36		5044B	24 G2	D41325P	52		AE0501	16	115-199	
D41093P	35		5044R	24 G2	D41325P	51		AE0501	16	115-199	
D41093P	37		5044Z		D41325P	53		AE0501	16	115-199	
D41093P	32		5049B	24 G2	D41309P	CAP	Y	AE0303	05	001-099	
D41093P	31		5049R	24 G2	D41309P	CAP	Y	AE0303	05	001-099	
D41093P	33		5049Z		D41309P	DED		AE0303	05	001-099	
AE0201	38	W4473	R2	DISC BKT-E2-1 SHELF DISC							
D41339P	1		0001	22 GA	D41487P	1		AP0037	50	009-099	
D41339P	24		0111	22 GA	D41487P	9		AP0037	50	001-099	
D41339P	15		0177	22 GA	D41377P	27		AE0501	05	115-199	
D41339P	18		0216	22 GA	D41349P	37		AE0203	33	001, 003-099, 115-199	
D41339P	18		0216	22 GA	D41349P	REF	VP	AE0203	33	002	
D41339P	25		0329	24 GK	D41881P	20		AE0202	11	003-099	
D41339P	27		0330	24 GK	D41881P	21		AE0202	11	003-099	
D41339P	12		0332	22 GA	D43005P	7		AE0302	02	115-199	
D41339P	13		0333	24 GK	D43005P	8		AE0302	02	115-199	
D41339P	29		5065B	24 G2	D41001P	8		AE0204	05	ALL	
D41339P	28		5065R	24 G2	D41001P	7		AE0204	05	ALL	
D41339P	30		5065Z		D41001P	9		AE0204	05	ALL	
D41339P	38		5093B	24 G2	D41355P	47		AE0302	41	115-199	
D41339P	37		5093R	24 G2	D41355P	46		AE0302	41	115-199	
D41339P	36		5093Z		D41355P	48		AE0302	41	115-199	
D41339P	43		5120B	24 G2	D43005P	10		AE0302	02	115-199	
D41339P	42		5120R	24 G2	D43005P	9		AE0302	02	115-199	
D41339P	44		5120Z		D43005P	11		AE0302	02	115-199	
AE0201	40	W4479	L2	DISC BKT-E2-1 SHELF DISC							
D41563P	10		0019	22 GA	D41565P	41		AE0202	07	115-199	
D41563P	11		0020	22 GA	D41567P	37		AE0203	13	ALL	
D41563P	42		5013B	24 G2	D41565P	36		AE0202	07	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0201

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0201	40	W4479	L2	DISC BKT-E2-1 SHELF DISC (continued)								
D41563P	41		5013R	24 G2	D41565P	35		AE0202	07	115-199		
D41563P	43		5013Z		D41565P	37		AE0202	07	115-199		
D41563P	45		5015B	24 7K	D41567P	10		AE0203	13	002		
D41563P	46		5015W	24 7K	D41567P	11		AE0203	13	002		
D41563P	44		5015Z		D41567P	12		AE0203	13	002		
D41563P	48		5017B	24 G2	D41567P	14		AE0203	13	115-199		
D41563P	47		5017R	24 G2	D41567P	13		AE0203	13	115-199		
D41563P	49		5017Z		D41567P	15		AE0203	13	115-199		
AE0201	41	W4479	L2	DISC BKT-E2-1 SHELF DISC								
D41817P	30		0035	24 GK	D41743P	18		AE0202	12	001, 003-099		
D41817P	REF	JB	0035	24 GK	D41743P	18		AE0202	12	002		
D41817P	29		0036	24 GK	D41819P	14		AE0203	43	001, 003-099		
D41817P	24		5034B	24 G2	D41743P	16		AE0202	12	001-099		
D41817P	23		5034R	24 G2	D41743P	15		AE0202	12	001-099		
D41817P	25		5034Z		D41743P	17		AE0202	12	001-099		
D41817P	27		5035B	24 G2	D41819P	12		AE0203	43	001, 003-099		
D41817P	26		5035R	24 G2	D41819P	11		AE0203	43	001, 003-099		
D41817P	28		5035Z		D41819P	13		AE0203	43	001, 003-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0201

Page 6 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0202	02	W4473	R2	DISC BKT-E2-2 SHELF DISC								
D41347P	21		0072	22	GA	D41379P	38		AE0502	03	001-099	
D41347P	21		0072	24	GK	D41379P	38		AE0502	03	115-199	
D41347P	51		0099	24	GK	D41379P	19		AE0502	03	115-199	
D41347P	22		0103	22	GA	D41349P	14		AE0203	33	001, 003-099	
D41347P	22		0103	24	GK	D41349P	REF	VP	AE0203	33	002	
D41347P	22		0103	24	GK	D41349P	14		AE0203	33	115-199	
D41347P	27		0121	20	GA	D41909P	17		AP0037	20	001-099	
D41347P	31		0123	24	GK	D41377P	14		AE0501	05	115-199	
D41347P	30		0132	24	GK	D41487P	44		AP0037	50	115-199	
D41347P	48		0134	22	GA	D41489P	21		AP0050	12	001-099	
D41347P	48		0134	24	GK	D41489P	21		AP0050	12	115-199	
AE0202	04	W2354	R1	DISC BKT-E2-2 SHELF DISC								
D41328P	14		0004	24	GK	D40618P	6		AP0011	13	002	
I AE0202	05	W2333	N2	DISC BKT-E2-2 SHELF DISC								
I D41083P	13		5004B	24	G2	D00175	CAP	Y	M00077		115-199	
I D41083P	12		5004R	24	G2	D00175	CAP	Y	M00077		115-199	
I D41083P	14		5004Z			D00175	DED		M00077		115-199	
AE0202	07	W4479	L2	DISC BKT-E2-2 SHELF DISC								
I D41565P	41		0019	22	GA	D41563P	10		AE0201	40	115-199	
I D41565P	36		5013B	24	G2	D41563P	42		AE0201	40	115-199	
I D41565P	35		5013R	24	G2	D41563P	41		AE0201	40	115-199	
I D41565P	37		5013Z			D41563P	43		AE0201	40	115-199	
AE0202	08	W4473	R2	DISC BKT-E2-2 SHELF DISC								
D41345P	44		0341	24	GK	D41355P	46		AE0302	41	001, 003-099	
D41345P	REF	VP	0341	24	GK	D41355P	46		AE0302	41	002	
D41345P	36		5015B	24	G2	D41379P	25		AE0502	03	115-199	
D41345P	35		5015R	24	G2	D41379P	24		AE0502	03	115-199	
D41345P	37		5015Z			D41379P	26		AE0502	03	115-199	
D41345P	49		5038B	24	G2	D41369P	52		AE0402	32	115-199	
D41345P	38		5038R	24	G2	D41369P	51		AE0402	32	115-199	
D41345P	50		5038Z			D41369P	53		AE0402	32	115-199	
D41345P	54		5039B	24	G2	D41355P	3		AE0302	41	115-199	
D41345P	53		5039R	24	G2	D41355P	2		AE0302	41	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0202

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0202	08	W4473	R2	DISC BKT-E2-2 SHELF DISC (continued)								
D41345P	55		5039Z		D41355P	21		AE0302	41	115-199		
AE0202	10	W4477	S2	DISC BKT-E2-2 SHELF DISC								
D41431P	12		0089	20 GA	D41433P	32		AE0203	03	001-099		
D41431P	14		0089	20 GA	D41739P	24		AP0037	29	115-199		
D41431P	1		0117	24 GK	D41453P	52		AE0403	07	115-199		
D41431P	3		0128	24 GK	D41451P	16		AE0402	12	ALL		
D41431P	22		0152	20 GA	D41739P	38		AP0037	29	115-199		
AE0202	11	W1173	R2	DISC BKT-E2-2 SHELF DISC								
D41881J	16		5078B	24 G2	TB0203Z	105	BJ			001-099		
D41881J	16		5078B	24 G2	TB0203Z	105	BJ	TB0203		115-199		
D41881J	17		5078R	24 G2	TB0203Z	106	BJ			001-099		
D41881J	17		5078R	24 G2	TB0203Z	106	BJ	TB0203		115-199		
D41881J	18		5078Z		GD01914	ST..	2			001-099		
D41881J	18		5078Z		GD01916	ST..	2			115-199		
D41881J	34		5125B	24 G2	TB0203Z	105	BJ	TB0203		115-199		
D41881J	33		5125R	24 G2	TB0203Z	106	BJ	TB0203		115-199		
D41881J	32		5125Z		GD01916	ST..	2			115-199		
AE0202	11	W4473	R2	DISC BKT-E2-2 SHELF DISC								
D41881P	24		0098	24 GK	D41487P	34		AP0037	50	115-199		
D41881P	31		0105	24 GK	D41351P	7		AE0204	02	115-199		
D41881P	22		0130	24 GK	D41487P	38		AP0037	50	ALL		
D41881P	19		0173	24 GK	D41491P	41		AP0051	05	115-199		
D41881P	23		0195	22 GA	D41349P	33		AE0203	33	115-199		
D41881P	20		0329	24 GK	D41339P	25		AE0201	38	003-099		
D41881P	21		0330	24 GK	D41339P	27		AE0201	38	003-099		
D41881P	16		5009B	24 G2	D41487P	3		AP0037	50	ALL		
D41881P	17		5009R	24 G2	D41487P	4		AP0037	50	ALL		
D41881P	18		5009Z		D41487P	5		AP0037	50	ALL		
D41881P	27		5042B	24 G2	D41349P	22	VP	AE0203	33	002		
D41881P	26		5042R	24 G2	D41349P	21	VP	AE0203	33	002		
D41881P	25		5042Z		D41349P	20		AE0203	33	002		
D41881P	34		5044B	24 G2	D41361P	18		AE0303	36	115-199		
D41881P	33		5044R	24 G2	D41361P	17		AE0303	36	115-199		
D41881P	32		5044Z		D41361P	16		AE0303	36	115-199		
D41881P	29		5094B	24 G2	D41355P	54		AE0302	41	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0202

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0202	11	W4473	R2	DISC BKT-E2-2 SHELF DISC (continued)							
D41881P	28		5094R	24 G2	D41355P	53		AE0302	41	115-199	
D41881P	30		5094Z		D41355P	55		AE0302	41	115-199	
AE0202	12	W4479	L2	DISC BKT-E2-2 SHELF DISC							
D41743P	4		0022	22 GA	D41595P	38		AE0201	01	ALL	
D41743P	18		0035	24 GK	D41817P	30		AE0201	41	001, 003-099	
D41743P	18		0035	24 GK	D41817P	REF	JB	AE0201	41	002	
D41743P	15		0048	22 GA	D41567P	51		AE0203	13	115-199	
D41743P	16		5034B	24 G2	D41817P	24		AE0201	41	001-099	
D41743P	15		5034R	24 G2	D41817P	23		AE0201	41	001-099	
D41743P	17		5034Z		D41817P	25		AE0201	41	001-099	
AE0202	13	W4475	C2	DISC BKT-E2-2 SHELF DISC							
D41393P	12		0012	22 GA	D41395P	28		AE0203	23	001, 003-099, 115-199	
D41393P	12		0012	22 GA	D41395P	REF	JB	AE0203	23	002	
D41393P	14		0014	22 GA	D41395P	30		AE0203	23	ALL	
D41393P	22		0026	22 GA	D41395P	48		AE0203	23	115-199	
D41393P	23		0027	22 GA	D41395P	49		AE0203	23	115-199	
D41393P	32		0058	22 GA	D41495P	13		AP0037	30	115-199	
D41393P	26		5020B	24 G2	D41391P	26		AE0201	02	ALL	
D41393P	25		5020R	24 G2	D41391P	25		AE0201	02	ALL	
D41393P	27		5020Z		D41391P	27		AE0201	02	ALL	
AE0202	14	W1173	R2	DISC BKT-E2-2 SHELF DISC							
D42035J	35		0354	24 GK	D41907J	39		AE0202	26	115-199	
D42035J	36		0355	24 GK	D41907J	40		AE0202	26	115-199	
AE0202	14	W2243	R2	DISC BKT-E2-2 SHELF DISC							
D42035P	9		0009	22 GA	D40077J	51		AP0001	07	115-199	
D42035P	32		0020	22 GA	D40077J	53		AP0001	07	115-199	
D42035P	33		0021	22 GA	D40077J	54		AP0001	07	115-199	
D42035P	35		0097	22 GA	D40077J	41		AP0001	07	115-199	
D42035P	36		0098	22 GA	D40077J	42		AP0001	07	115-199	
D42035P	22		2002B	22 GB	D40077J	22		AP0001	07	001-099	
D42035P	21		2002R	22 GB	D40077J	21		AP0001	07	001-099	
D42035P	19		3002B	24 GM	D40077J	19		AP0001	07	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0202

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0202	14	W2243	R2	DISC BKT-E2-2 SHELF DISC (continued)								
D42035P	18		3002R	24 GM	D40077J	18		AP0001	07	001-099		
D42035P	20		3002Y	24 GM	D40077J	20		AP0001	07	001-099		
AE0202	17	W2253	R2	DISC BKT-E2-2 SHELF DISC								
D42087P	13		0095	22 GA	D40631J	46		AP0003	08	115-199		
D42087P	10		5016B	24 G2	D40073J	28		AP0003	10	ALL		
D42087P	11		5016R	24 G2	D40073J	29		AP0003	10	ALL		
D42087P	12		5016Z		D40073J	30		AP0003	10	ALL		
AE0202	24	W4473	R2	DISC BKT-E2-2 SHELF DISC								
D43007P	15		0285	22 GA	D43005P	15		AE0302	02	001-099		
D43007P	13		5087B	24 G2	D43005P	18		AE0302	02	001-099		
D43007P	12		5087R	24 G2	D43005P	17		AE0302	02	001-099		
D43007P	14		5087Z		D43005P	19		AE0302	02	001-099		
D43007P	20		5132B	24 G2	D41361P	18		AE0303	36	010-099		
D43007P	19		5132R	24 G2	D41361P	17		AE0303	36	010-099		
D43007P	21		5132Z		D41361P	19		AE0303	36	010-099		
AE0202	26	W1173	R2	DISC BKT-E2-2 SHELF DISC								
D41907J	39		0354	24 GK	D42035J	35		AE0202	14	115-199		
D41907J	40		0355	24 GK	D42035J	36		AE0202	14	115-199		
AE0202	26	W4473	R2	DISC BKT-E2-2 SHELF DISC								
D41907P	12		0047	24 GK	D41867P	32		AE0402	01	ALL		
D41907P	26		0108	24 GK	D41867P	33		AE0402	01	ALL		
D41907P	2		5037B	24 G2	D41491P	24		AP0051	05	001-099		
D41907P	1		5037R	24 G2	D41491P	23		AP0051	05	001-099		
D41907P	3		5037Z		D41491P	25		AP0051	05	001-099		
AE0202	28	W4471	L2	DISC BKT-E2-2 SHELF DISC								
D41095P	7		0100	24 GK	D41089P	51		AE0201	10	115-199		
D41095P	CAP	Y	0210	22 GA	D41327P	9		AE0502	16	115-199		
D41095P	13		5045B	24 G2	D41303P	39		AE0302	40	ALL		
D41095P	12		5045R	24 G2	D41303P	38		AE0302	40	ALL		
D41095P	14		5045Z		D41303P	40		AE0302	40	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0202

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0202	30	W4481	R2	DISC BKT-E2-2 SHELF DISC								
D41821P	8		0033	24	GK	D41745P	11		AE0201	22	115-199	
D41821P	9		0037	24	GK	D41823P	7		AE0203	12	115-199	
D41821P	14		5011B	24	G2	D41745P	14		AE0201	22	001, 003-099	
D41821P	14		5011B	24	G2	D41745P	REF	JB	AE0201	22	002	
D41821P	13		5011R	24	G2	D41745P	13		AE0201	22	001, 003-099	
D41821P	13		5011R	24	G2	D41745P	REF	JB	AE0201	22	002	
D41821P	15		5011Z			D41745P	15		AE0201	22	001, 003-099	
D41821P	15		5011Z			D41745P	DED		AE0201	22	002	
D41821P	11		5013B	24	G2	D41823P	9		AE0203	12	001, 003-099	
D41821P	11		5013B	24	G2	D41823P	REF	JB	AE0203	12	002	
D41821P	10		5013R	24	G2	D41823P	8		AE0203	12	001, 003-099	
D41821P	10		5013R	24	G2	D41823P	REF	JB	AE0203	12	002	
D41821P	12		5013Z			D41823P	10		AE0203	12	001, 003-099	
D41821P	12		5013Z			D41823P	DED		AE0203	12	002	
AE0202	31	W2253	R2	DISC BKT-E2-2 SHELF DISC								
D42085P	3		0003	22	GA	D40099J	3		AP0003	13	ALL	
D42085P	15		0021	22	GA	D40099J	1		AP0003	13	115-199	
D42085P	16		0022	22	GA	D40099J	2		AP0003	13	115-199	
D42085P	36		0034	22	GA	D40631J	12		AP0003	08	001-099	
D42085P	51		2501B	24	G2	D40073J	45		AP0003	10	001-099	
D42085P	50		2501R	24	G2	D40073J	44		AP0003	10	001-099	
D42085P	52		2501Z			D40073J	46		AP0003	10	001-099	
D42085P	13		2502B	24	G2	D40073J	49		AP0003	10	115-199	
D42085P	12		2502R	24	G2	D40073J	48		AP0003	10	115-199	
D42085P	14		2502Z			D40073J	50		AP0003	10	115-199	
D42085P	32		2511B	24	G2	D40631J	37		AP0003	08	115-199	
D42085P	31		2511R	24	G2	D40631J	36		AP0003	08	115-199	
D42085P	33		2511Z			D40631J	38		AP0003	08	115-199	
D42085P	9		5003B	24	G2	D40073J	9		AP0003	10	115-199	
D42085P	8		5003R	24	G2	D40073J	8		AP0003	10	115-199	
D42085P	10		5003Z			D40073J	10		AP0003	10	115-199	
AE0202	32	W2323	R2	DISC BKT-E2-2 SHELF DISC								
D41077P	34		0028	24	GK	D00097	14		M00093		002	
AE0202	33	W4481	R2	DISC BKT-E2-2 SHELF DISC								
D41603P	50		0025	24	GK	D41605P	37		AE0203	20	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0202

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

	From Matewith From	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos		
	AE0202	33	W4481	R2	DISC BKT-E2-2 SHELF DISC (continued)								
	D41603P	31		0035	24	GK	D41601P	3		AE0201	11	ALL	
	D41603P	48		5001B	24	G2	D41601P	36		AE0201	11	001-099	
	D41603P	47		5001R	24	G2	D41601P	35		AE0201	11	001-099	
	D41603P	49		5001Z			D41601P	37		AE0201	11	001-099	
I	D41603P	2		5012B	24	G2	D41601P	32		AE0201	11	115-199	
I	D41603P	1		5012R	24	G2	D41601P	31		AE0201	11	115-199	
I	D41603P	3		5012Z			D41601P	33		AE0201	11	115-199	
	AE0202	41	W4481	R2	DISC BKT-E2-2 SHELF DISC								
	D41679P	36		0023	22	GA	D41601P	43		AE0201	11	ALL	
	D41679P	50		0034	24	GK	D41601P	2		AE0201	11	115-199	
	D41679P	51		0036	24	GK	D41745P	12		AE0201	22	ALL	
I	D41679P	52		0038	24	GK	D41605P	49		AE0203	20	001-099	
	D41679P	37		0039	24	GK	D41605P	51		AE0203	20	001, 003-099	
	D41679P	37		0039	24	GK	D41605P	REF	JB	AE0203	20	002	
	D41679P	53		0039	24	GK	D41605P	51		AE0203	20	115-199	
	D41679P	5		5015B	24	7K	D41605P	11		AE0203	20	002	
	D41679P	6		5015W	24	7K	D41605P	10		AE0203	20	002	
	D41679P	4		5015Z			D41605P	12		AE0203	20	002	
I	D41679P	12		5017B	24	G2	D41605P	25		AE0203	20	115-199	
I	D41679P	11		5017R	24	G2	D41605P	24		AE0203	20	115-199	
I	D41679P	13		5017Z			D41605P	26		AE0203	20	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0202

Page 6 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0203	03	W1175	C2	DISC BKT-E2-3 SHELF DISC							
D41433J			0260	20 GA	GD02112	ST..	2			115-199	
D41433J	18		5072B	24 G2	D00433B	D01		M00147		115-199	
D41433J	19		5072R	24 G2	D00433B	C01		M00147		115-199	
D41433J			5072Z		D00433B	DED		M00147		115-199	
D41433J	20		FRAH		D41433J			AE0203	03	115-199	
D41433J			FRAH		D41433J	20		AE0203	03	115-199	
AE0203	03	W4477	S2	DISC BKT-E2-3 SHELF DISC							
D41433P	7		0004	24 GK	D41429P	7		AE0201	32	002	
D41433P	32		0089	20 GA	D41431P	12		AE0202	10	001-099	
D41433P	29		0094	22 GA	D41451P	34		AE0402	12	ALL	
D41433P	30		0095	22 GA	D41497P	16		AP0036	12	115-199	
D41433P	31		0096	22 GA	D41497P	17		AP0036	12	115-199	
D41433P	39		0113	24 GK	D41059P	9		AP0051	03	115-199	
D41433P	CAP	Y	0121	24 GK	D41451P	51		AE0402	12	115-199	
D41433P	CAP	Y	0122	24 GK	D41453P	53		AE0403	07	115-199	
D41433P	41		0136	24 GK	D41453P	40		AE0403	07	115-199	
D41433P	42		0142	24 GK	D41497P	22		AP0036	12	115-199	
D41433P	46		0181	22 GA	D41461P	22		AE0502	28	115-199	
D41433P	47		0182	22 GA	D41461P	23		AE0502	28	115-199	
D41433P	52		0196	20 GA	D41739P	40		AP0037	29	ALL	
D41433P	18		5005B	24 G2	D41451P	18		AE0402	12	ALL	
D41433P	19		5005R	24 G2	D41451P	19		AE0402	12	ALL	
D41433P	20		5005Z		D41451P	20		AE0402	12	ALL	
AE0203	06	W2621	C2	DISC BKT-E2-3 SHELF DISC							
D41695P	40		3010B	22 GC	D40497P	40		AA1715	05	ALL	
D41695P	39		3010R	22 GC	D40497P	39		AA1715	05	ALL	
D41695P	41		3010Y	22 GC	D40497P	41		AA1715	05	ALL	
AE0203	07	W4475	C2	DISC BKT-E2-3 SHELF DISC							
D41815P	18		0054	24 GK	D41409P	11		AE0402	29	115-199	
D41815P	33		5024B	24 G2	D41399P	13		AE0301	17	001, 003-099	
D41815P	REF	JB	5024B	24 G2	D41399P	13		AE0301	17	002	
D41815P	34		5024B	24 G2	D41399P	13		AE0301	17	115-199	
D41815P	18		5024R	24 G2	D41399P	12		AE0301	17	001, 003-099	
D41815P	REF	JB	5024R	24 G2	D41399P	12		AE0301	17	002	
D41815P	33		5024R	24 G2	D41399P	12		AE0301	17	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0203

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0203	07	W4475	C2	DISC BKT-E2-3 SHELF DISC (continued)								
D41815P	37		5024Z		D41399P	14		AE0301	17	001, 003-099		
D41815P	REF	JB	5024Z		D41399P	14		AE0301	17	002		
D41815P	35		5024Z		D41399P	14		AE0301	17	115-199		
AE0203	08	W2245	2C	DISC BKT-E2-3 SHELF DISC								
D42049P	17		0006	22 GA	D40633J	6		AP0001	06	001-099		
D42049P	30		0010	22 GA	D40633J	10		AP0001	06	115-199		
D42049P	31		0011	22 GA	D40633J	11		AP0001	06	115-199		
D42049P	18		0016	22 GA	D42047J	24		AP0001	10	ALL		
D42049P	20		2001B	24 GL	D42047J	22		AP0001	10	ALL		
D42049P	21		2001R	24 GL	D42047J	21		AP0001	10	ALL		
D42049P	28		5004B	24 G2	D40633J	8		AP0001	06	ALL		
D42049P	27		5004R	24 G2	D40633J	7		AP0001	06	ALL		
D42049P	29		5004Z		D40633J	9		AP0001	06	ALL		
AE0203	11	W1175	C2	DISC BKT-E2-3 SHELF DISC								
D42021J	6		0365	24 GK	D41643J	17		AE0203	31	115-199		
D42021J	7		0366	24 GK	D41643J	18		AE0203	31	115-199		
AE0203	11	W2241	L2	DISC BKT-E2-3 SHELF DISC								
D42021P	6		0010	22 GA	D40039J	6		AP0001	12	ALL		
D42021P	28		0028	22 GA	D40523J	28		AP0001	15	115-199		
D42021P	1		0038	24 GK	D40523J	16		AP0001	15	001-099		
D42021P	1		0038	22 GA	D40523J	16		AP0001	15	115-199		
D42021P	23		0040	22 GA	D40523J	23		AP0001	15	115-199		
D42021P	7		0045	22 GA	D40039J	7		AP0001	12	115-199		
D42021P	30		2518B	24 G2	D40523J	39		AP0001	15	115-199		
D42021P	29		2518R	24 G2	D40523J	38		AP0001	15	115-199		
D42021P	31		2518Z		D40523J	40		AP0001	15	115-199		
AE0203	12	W4481	R2	DISC BKT-E2-3 SHELF DISC								
D41823P	7		0037	24 GK	D41821P	9		AE0202	30	115-199		
D41823P	9		5013B	24 G2	D41821P	11		AE0202	30	001, 003-099		
D41823P	REF	JB	5013B	24 G2	D41821P	11		AE0202	30	002		
D41823P	8		5013R	24 G2	D41821P	10		AE0202	30	001, 003-099		
D41823P	REF	JB	5013R	24 G2	D41821P	10		AE0202	30	002		
D41823P	10		5013Z		D41821P	12		AE0202	30	001, 003-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0203

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0203	12	W4481	R2	DISC BKT-E2-3 SHELF DISC (continued)								
D41823P	DED		5013Z		D41821P	12		AE0202	30	002		
AE0203	13	W1175	C2	DISC BKT-E2-3 SHELF DISC								
D41567J	35		0008	24 GK	D00085A	B09				001-099		
AE0203	13	W4479	L2	DISC BKT-E2-3 SHELF DISC								
D41567P	37		0020	22 GA	D41563P	11		AE0201	40	ALL		
D41567P	38		0021	22 GA	D41595P	28		AE0201	01	ALL		
D41567P	51		0048	22 GA	D41743P	15		AE0202	12	115-199		
D41567P	10		5015B	24 7K	D41563P	45		AE0201	40	002		
D41567P	11		5015W	24 7K	D41563P	46		AE0201	40	002		
D41567P	12		5015Z		D41563P	44		AE0201	40	002		
D41567P	14		5017B	24 G2	D41563P	48		AE0201	40	115-199		
D41567P	13		5017R	24 G2	D41563P	47		AE0201	40	115-199		
D41567P	15		5017Z		D41563P	49		AE0201	40	115-199		
D41567P	52		5038B	24 G2	D41569P	26		AE0204	10	001-099		
D41567P	51		5038R	24 G2	D41569P	25		AE0204	10	001-099		
D41567P	53		5038Z		D41569P	27		AE0204	10	001-099		
AE0203	17	W2247	2S	DISC BKT-E2-3 SHELF DISC								
D42167P	5		0012	22 GA	D42165J	12		AP0003	09	001, 003-099		
D42167P	5		0012	22 GA	D42165J	12		AP0003	09	115-199		
D42167P	6		0013	22 GA	D42165J	13		AP0003	09	115-199		
D42167P	7		0014	22 GA	D42165J	14		AP0003	09	115-199		
D42167P	8		0015	22 GA	D42165J	15		AP0003	09	115-199		
AE0203	18	W2358	S1	DISC BKT-E2-3 SHELF DISC								
D41884P	2		0617	20 GA	D40622P	20		AP0011	05	115-199		
AE0203	20	W4481	R2	DISC BKT-E2-3 SHELF DISC								
D41605P	36		0019	24 GK	D41601P	42		AE0201	11	001-099		
D41605P	37		0025	24 GK	D41603P	50		AE0202	33	001-099		
D41605P	49		0038	24 GK	D41679P	52		AE0202	41	001-099		
D41605P	51		0039	24 GK	D41679P	37		AE0202	41	001, 003-099		
D41605P	REF	JB	0039	24 GK	D41679P	37		AE0202	41	002		
D41605P	51		0039	24 GK	D41679P	53		AE0202	41	115-199		
D41605P	11		5015B	24 7K	D41679P	5		AE0202	41	002		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0203

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0203	20	W4481	R2	DISC BKT-E2-3 SHELF DISC (continued)								
D41605P	10		5015W	24 7K	D41679P	6		AE0202	41	002		
D41605P	12		5015Z		D41679P	4		AE0202	41	002		
D41605P	25		5017B	24 G2	D41679P	12		AE0202	41	115-199		
D41605P	24		5017R	24 G2	D41679P	11		AE0202	41	115-199		
D41605P	26		5017Z		D41679P	13		AE0202	41	115-199		
AE0203	21	W4471	L2	DISC BKT-E2-3 SHELF DISC								
D41097P	47		0149	24 GK	D41477P	47		AP0050	02	001-099		
D41097P	CAP	Y	0168	22 GA	D41477P	50		AP0050	02	115-199		
D41097P	52		0179	22 GA	D41309P	45		AE0303	05	002		
D41097P	40		5040B	24 G2	D41093P	30		AE0201	37	002		
D41097P	39		5040R	24 G2	D41093P	29		AE0201	37	002		
D41097P	38		5040Z		D41093P	28		AE0201	37	002		
D41097P	43		5041B	24 G2	D41879P	8		AE0402	38	002		
D41097P	42		5041R	24 G2	D41879P	7		AE0402	38	002		
D41097P	41		5041Z		D41879P	6		AE0402	38	002		
AE0203	22	W2362	C1	DISC BKT-E2-3 SHELF DISC								
D41890P	2		0002	20 GA	D40626P	2		AP0011	11	ALL		
D41890P	11		0101	20 GA	D40626P	11		AP0011	11	115-199		
D41890P	12		0102	20 GA	D40626P	12		AP0011	11	115-199		
D41890P	13		0103	20 GA	D40626P	13		AP0011	11	115-199		
D41890P	14		0104	20 GA	D40626P	14		AP0011	11	115-199		
AE0203	23	W4475	C2	DISC BKT-E2-3 SHELF DISC								
D41395P	28		0012	22 GA	D41393P	12		AE0202	13	001, 003-099, 115-199		
D41395P	REF	JB	0012	22 GA	D41393P	12		AE0202	13	002		
D41395P	30		0014	22 GA	D41393P	14		AE0202	13	ALL		
D41395P	34		0018	22 GA	D41391P	15		AE0201	02	115-199		
D41395P	37		0021	22 GA	D41391P	18		AE0201	02	ALL		
D41395P	46		0024	22 GA	D41391P	23		AE0201	02	115-199		
D41395P	47		0025	22 GA	D41391P	24		AE0201	02	115-199		
D41395P	48		0026	22 GA	D41393P	22		AE0202	13	115-199		
D41395P	49		0027	22 GA	D41393P	23		AE0202	13	115-199		
D41395P	16		5007B	24 G2	D41391P	8		AE0201	02	ALL		
D41395P	15		5007R	24 G2	D41391P	7		AE0201	02	ALL		
D41395P	17		5007Z		D41391P	9		AE0201	02	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0203

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0203	23	W4475	C2	DISC BKT-E2-3 SHELF DISC (continued)								
D41395P	25		5010B	24	G2	D41419P	22		AE0503	15	001, 003-099	
D41395P	REF	JB	5010B	24	G2	D41419P	22		AE0503	15	002	
D41395P	25		5010B	24	G2	D41397P	10		AE0204	16	115-199	
D41395P	26		5010R	24	G2	D41419P	21		AE0503	15	001, 003-099	
D41395P	REF	JB	5010R	24	G2	D41419P	21		AE0503	15	002	
D41395P	26		5010R	24	G2	D41397P	11		AE0204	16	115-199	
D41395P	27		5010Z			D41419P	23		AE0503	15	001, 003-099	
D41395P	REF	JB	5010Z			D41419P	23		AE0503	15	002	
D41395P	27		5010Z			D41397P	12		AE0204	16	115-199	
D41395P	54		5021B	24	G2	D41391P	2		AE0201	02	115-199	
D41395P	53		5021R	24	G2	D41391P	1		AE0201	02	115-199	
D41395P	55		5021Z			D41391P	3		AE0201	02	115-199	
AE0203	25	W2370	C2	DISC BKT-E2-3 SHELF DISC								
D41888P	3		0104	22	GA	D40300P	10		AP0006	14	115-199	
D41888P	4		0105	22	GA	D40300P	11		AP0006	14	115-199	
AE0203	26	W2253	R2	DISC BKT-E2-3 SHELF DISC								
D42083P	4		0004	22	GA	D40099J	4		AP0003	13	115-199	
D42083P	16		0016	22	GA	D40099J	21		AP0003	13	115-199	
D42083P	17		0017	22	GA	D40073J	47		AP0003	10	115-199	
D42083P	25		0025	22	GA	D40099J	28		AP0003	13	115-199	
D42083P	26		0026	22	GA	D40099J	29		AP0003	13	115-199	
D42083P	27		0027	22	GA	D40099J	30		AP0003	13	115-199	
D42083P	28		0028	22	GA	D40099J	31		AP0003	13	115-199	
D42083P	21		0030	22	GA	D40073J	34		AP0003	10	115-199	
D42083P	29		0036	22	GA	D40631J	14		AP0003	08	115-199	
D42083P	30		0037	22	GA	D40631J	15		AP0003	08	115-199	
D42083P	12		0079	22	GA	D40099J	18		AP0003	13	115-199	
D42083P	15		0080	24	GK	D40099J	19		AP0003	13	001-099	
D42083P	15		0080	22	GA	D40099J	19		AP0003	13	115-199	
D42083P	18		0081	22	GA	D40099J	35		AP0003	13	115-199	
D42083P	19		0082	22	GA	D40099J	36		AP0003	13	115-199	
D42083P	2		5026B	24	G2	D42095P	33		AE0502	13	001-099	
D42083P	1		5026R	24	G2	D42095P	32		AE0502	13	001-099	
D42083P	3		5026Z			D42095P	34		AE0502	13	001-099	
D42083P	7		5027B	24	G2	D40099J	30		AP0003	13	001-099	
D42083P	6		5027R	24	G2	D40099J	29		AP0003	13	001, 003-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0203

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0203	26	W2253	R2	DISC BKT-E2-3 SHELF DISC (continued)								
D42083P	CAP	Y	5027R	24 G2	D40099J	29		AP0003	13	002		
D42083P	8		5027Z		D40099J	31		AP0003	13	001-099		
AE0203	27	W2251	L2	DISC BKT-E2-3 SHELF DISC								
D42063P	15		2006B	22 GB	D42055J	24		AP0003	19	115-199		
D42063P	14		2006R	22 GB	D42055J	23		AP0003	19	115-199		
D42063P	12		2501B	24 G2	D40035J	46		AP0003	12	115-199		
D42063P	11		2501R	24 G2	D40035J	45		AP0003	12	115-199		
D42063P	13		2501Z		D40035J	47		AP0003	12	115-199		
D42063P	23		5006B	24 G2	D42055J	11		AP0003	19	ALL		
D42063P	22		5006R	24 G2	D42055J	10		AP0003	19	ALL		
D42063P	24		5006Z		D42055J	12		AP0003	19	ALL		
D42063P	20		5008B	24 G2	D40035J	11		AP0003	12	115-199		
D42063P	19		5008R	24 G2	D40035J	10		AP0003	12	115-199		
D42063P	21		5008Z		D40035J	12		AP0003	12	115-199		
AE0203	29	W4232	S2	DISC BKT-E2-3 SHELF DISC								
D41782P	8		2503B	20 GU	D40018J	17		AC0880	20	001-099		
D41782P	9		2503R	20 GU	D40018J	19		AC0880	20	001-099		
D41782P	10		2503Z		D40018J	S/R		AC0880	20	001-099		
AE0203	31	W1175	C2	DISC BKT-E2-3 SHELF DISC								
D41643J	17		0365	24 GK	D42021J	6		AE0203	11	115-199		
D41643J	18		0366	24 GK	D42021J	7		AE0203	11	115-199		
AE0203	31	W4471	L2	DISC BKT-E2-3 SHELF DISC								
D41643P	6		0234	22 GA	D41905P	6		AE0201	35	001-099		
D41643P	25		0329	24 GK	D41905P	13		AE0201	35	002		
D41643P	26		0330	24 GK	D41905P	14		AE0201	35	002		
D41643P	27		0331	24 GK	D41905P	15		AE0201	35	002		
D41643P	28		0332	24 GK	D41905P	11		AE0201	35	002		
AE0203	33	W4473	R2	DISC BKT-E2-3 SHELF DISC								
D41349P	30		0016	24 GK	D41487P	49		AP0037	50	001, 003-099		
D41349P	REF	VP	0016	22 GA	D41487P	49		AP0037	50	002		
D41349P	13		0102	24 GK	D41361P	4		AE0303	36	115-199		
D41349P	14		0103	22 GA	D41347P	22		AE0202	02	001, 003-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0203

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0203	33	W4473	R2	DISC BKT-E2-3 SHELF DISC (continued)							
D41349P	REF	VP	0103	24 GK	D41347P	22		AE0202	02	002	
D41349P	14		0103	24 GK	D41347P	22		AE0202	02	115-199	
D41349P	15		0106	22 GA	D41867P	11		AE0402	01	001, 003-099	
D41349P	REF	VP	0106	22 GA	D41867P	11		AE0402	01	002	
D41349P	15		0106	24 GK	D41351P	37		AE0204	02	115-199	
D41349P	16		0109	24 GK	D41361P	6		AE0303	36	115-199	
D41349P	33		0195	22 GA	D41881P	23		AE0202	11	115-199	
D41349P	41		0199	24 GK	D41487P	41		AP0037	50	001, 003-099	
D41349P	REF	VP	0199	24 GK	D41487P	41		AP0037	50	002	
D41349P	37		0216	22 GA	D41339P	18		AE0201	38	001, 003-099, 115-199	
D41349P	REF	VP	0216	22 GA	D41339P	18		AE0201	38	002	
D41349P	27		5011B	24 G2	D41369P	23		AE0402	32	115-199	
D41349P	26		5011R	24 G2	D41369P	24		AE0402	32	115-199	
D41349P	28		5011Z		D41369P	25		AE0402	32	115-199	
D41349P	22	VP	5042B	24 G2	D41881P	27		AE0202	11	002	
D41349P	21	VP	5042R	24 G2	D41881P	26		AE0202	11	002	
D41349P	20		5042Z		D41881P	25		AE0202	11	002	
D41349P	5		5075B	24 G2	D41001P	14		AE0204	05	001, 003-099	
D41349P	REF	VP	5075B	24 G2	D41001P	14		AE0204	05	002	
D41349P	4		5075R	24 G2	D41001P	13		AE0204	05	001, 003-099	
D41349P	REF	VP	5075R	24 G2	D41001P	13		AE0204	05	002	
D41349P	6		5075Z		D41001P	15		AE0204	05	001, 003-099	
D41349P	REF	VP	5075Z		D41001P	15		AE0204	05	002	
AE0203	38	W4226	C2	DISC BKT-E2-3 SHELF DISC							
D41622P	21		0011	20 GA	D40352J	34		AC1090	13	001-099	
D41622P	28		0011	20 GA	D40352J	34		AC1090	13	115-199	
D41622P	23		0012	20 GA	D40352J	35		AC1090	13	001-099	
D41622P	29		0012	20 GA	D40352J	35		AC1090	13	115-199	
AE0203	43	W4479	L2	DISC BKT-E2-3 SHELF DISC							
D41819P	14		0036	24 GK	D41817P	29		AE0201	41	001, 003-099	
D41819P	12		5035B	24 G2	D41817P	27		AE0201	41	001, 003-099	
D41819P	11		5035R	24 G2	D41817P	26		AE0201	41	001, 003-099	
D41819P	13		5035Z		D41817P	28		AE0201	41	001, 003-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0203

Page 7 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0204	02	W4473	R2	DISC BKT-E2-4 SHELF DISC								
D41351P	6		0104	22 GA	D41367P	26		AE0401	23	001-099		
D41351P	6		0104	24 GK	D41367P	26		AE0401	23	115-199		
D41351P	7		0105	22 GA	D41369P	23		AE0402	32	001-099		
D41351P	7		0105	24 GK	D41881P	31		AE0202	11	115-199		
D41351P	37		0106	24 GK	D41349P	15		AE0203	33	115-199		
D41351P	44		0138	22 GA	D41883P	1		AE0502	31	115-199		
D41351P	45		0139	22 GA	D41883P	2		AE0502	31	115-199		
D41351P	46		0140	22 GA	D41883P	3		AE0502	31	115-199		
D41351P	47		0141	22 GA	D41883P	4		AE0502	31	115-199		
D41351P	48		0142	22 GA	D41883P	5		AE0502	31	115-199		
D41351P	49		0143	22 GA	D41883P	6		AE0502	31	115-199		
D41351P	50		0144	22 GA	D41883P	11		AE0502	31	115-199		
D41351P	51		0145	22 GA	D41883P	31		AE0502	31	115-199		
AE0204	05	W4473	R2	DISC BKT-E2-4 SHELF DISC								
D41001P	8		5065B	24 G2	D41339P	29		AE0201	38	ALL		
D41001P	7		5065R	24 G2	D41339P	28		AE0201	38	ALL		
D41001P	9		5065Z		D41339P	30		AE0201	38	ALL		
D41001P	14		5075B	24 G2	D41349P	5		AE0203	33	001, 003-099		
D41001P	14		5075B	24 G2	D41349P	REF	VP	AE0203	33	002		
D41001P	13		5075R	24 G2	D41349P	4		AE0203	33	001, 003-099		
D41001P	13		5075R	24 G2	D41349P	REF	VP	AE0203	33	002		
D41001P	15		5075Z		D41349P	6		AE0203	33	001, 003-099		
D41001P	15		5075Z		D41349P	REF	VP	AE0203	33	002		
AE0204	06	W2245	2C	DISC BKT-E2-4 SHELF DISC								
D42051P	3		0012	22 GA	D42047J	37		AP0001	10	ALL		
D42051P	4		0013	22 GA	D42047J	38		AP0001	10	115-199		
D42051P	5		0014	22 GA	D42047J	39		AP0001	10	115-199		
D42051P	12		5005B	24 G2	D42047J	26		AP0001	10	001-099		
D42051P	26		5005B	24 G2	D42047J	26		AP0001	10	115-199		
D42051P	11		5005R	24 G2	D42047J	25		AP0001	10	001-099		
D42051P	25		5005R	24 G2	D42047J	25		AP0001	10	115-199		
D42051P	4		5005Z		D42047J	27		AP0001	10	001-099		
D42051P	27		5005Z		D42047J	27		AP0001	10	115-199		
D42051P	23		5006B	24 G2	D42047J	35		AP0001	10	115-199		
D42051P	22		5006R	24 G2	D42047J	34		AP0001	10	115-199		
D42051P	24		5006Z		D42047J	36		AP0001	10	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0204

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AE0204	09	W2241	L2	DISC BKT-E2-4 SHELF DISC						
D42015P	3		0090	22 GA	D40523J	36		AP0001	15	115-199
D42015P	9		5014B	24 G2	D40031J	39		AP0001	16	001-099
D42015P	8		5014R	24 G2	D40031J	38		AP0001	16	001-099
D42015P	10		5014Z		D40031J	40		AP0001	16	001-099
AE0204	10	W4479	L2	DISC BKT-E2-4 SHELF DISC						
D41569P	26		5038B	24 G2	D41567P	52		AE0203	13	001-099
D41569P	25		5038R	24 G2	D41567P	51		AE0203	13	001-099
D41569P	27		5038Z		D41567P	53		AE0203	13	001-099
AE0204	14	W2253	R2	DISC BKT-E2-4 SHELF DISC						
D42089P	2		0002	24 GK	D40073J	37		AP0003	10	115-199
D42089P	17		0084	22 GA	D40073J	24		AP0003	10	115-199
D42089P	10		2505B	24 G2	D40099J	23		AP0003	13	115-199
D42089P	9		2505R	24 G2	D40099J	22		AP0003	13	115-199
D42089P	11		2505Z		D40099J	24		AP0003	13	115-199
D42089P	13		2506B	24 G2	D40099J	26		AP0003	13	115-199
D42089P	12		2506R	24 G2	D40099J	25		AP0003	13	115-199
D42089P	14		2506Z		D40099J	27		AP0003	13	115-199
D42089P	10		5028B	24 G2	D40099J	23		AP0003	13	001-099
D42089P	9		5028R	24 G2	D40099J	22		AP0003	13	001-099
D42089P	11		5028Z		D40099J	24		AP0003	13	001-099
AE0204	16	W4475	C2	DISC BKT-E2-4 SHELF DISC						
D41397P	30		0051	22 GA	D41409P	8		AE0402	29	115-199
D41397P	34		0052	22 GA	D41409P	52		AE0402	29	115-199
D41397P	10		5010B	24 G2	D41395P	25		AE0203	23	115-199
D41397P	11		5010R	24 G2	D41395P	26		AE0203	23	115-199
D41397P	12		5010Z		D41395P	27		AE0203	23	115-199
D41397P	28		5023B	24 G2	D41391P	30		AE0201	02	115-199
D41397P	27		5023R	24 G2	D41391P	29		AE0201	02	115-199
D41397P	29		5023Z		D41391P	31		AE0201	02	115-199
D41397P	25		5025B	24 G2	D41399P	20		AE0301	17	001-099
D41397P	32		5025B	24 G2	D41399P	20		AE0301	17	115-199
D41397P	24		5025R	24 G2	D41399P	19		AE0301	17	001-099
D41397P	31		5025R	24 G2	D41399P	19		AE0301	17	115-199
D41397P	26		5025Z		D41399P	21		AE0301	17	001-099
D41397P	33		5025Z		D41399P	21		AE0301	17	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AE0204

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0204	20	W4471	L2	DISC BKT-E2-4 SHELF DISC								
D41099P	15		0135	22	GA	D41317P	16		AE0402	07	001-099	
D41099P	15		0135	22	GA	D41325P	47		AE0501	16	115-199	
D41099P	16		0136	22	GA	D41317P	8		AE0402	07	001-099	
D41099P	16		0136	22	GA	D41325P	48		AE0501	16	115-199	
D41099P	17		0137	22	GA	D41473P	52		AP0036	21	001-099	
D41099P	17		0137	22	GA	D41325P	49		AE0501	16	115-199	
D41099P	18		0138	22	GA	D41325P	50		AE0501	16	115-199	
D41099P	22		0142	22	GA	D42187P	4		AE0501	17	115-199	
D41099P	26		0151	22	GA	D41301P	34		AE0301	08	ALL	
D41099P	30		0162	24	GK	D41319P	20		AE0403	12	115-199	
D41099P	31		0163	24	GK	D41319P	21		AE0403	12	115-199	
D41099P	32		0164	24	GK	D41319P	22		AE0403	12	115-199	
D41099P	8		0192	22	GA	D41473P	42		AP0036	21	001-099	
D41099P	24		5047B	24	G2	D41301P	32		AE0301	08	ALL	
D41099P	23		5047R	24	G2	D41301P	31		AE0301	08	ALL	
D41099P	25		5047Z			D41301P	33		AE0301	08	ALL	
D41099P	28		5048B	24	G2	D41473P	49		AP0036	21	001-099	
D41099P	28		5048B	24	G2	D41473P	27		AP0036	21	115-199	
D41099P	27		5048R	24	G2	D41473P	48		AP0036	21	001-099	
D41099P	27		5048R	24	G2	D41473P	14		AP0036	21	115-199	
D41099P	29		5048Z			D41473P	50		AP0036	21	001-099	
D41099P	29		5048Z			D41473P	33		AP0036	21	115-199	
D41099P	19		5074B	24	G2	D40015P	8		AE0401	20	001-099	
D41099P	18		5074R	24	G2	D40015P	7		AE0401	20	001-099	
D41099P	20		5074Z			D40015P	9		AE0401	20	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0204

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0301	02	W2358	S1	DISC BKT-E3-1 SHELF DISC							
D41964P	12		0022	22 GA	D40622P	22		AP0011	05	115-199	
D41964P	8		0608	22 GA	D40622P	28		AP0011	05	115-199	
D41964P	10		0610	22 GA	D40622P	23		AP0011	05	115-199	
AE0301	03	W2441	L*	DISC BKT-E3-1 SHELF DISC							
D41761P	4		2007B	20 GB	D40573P	4		AC1148	02	ALL	
D41761P	2		2007R	20 GB	D40573P	2		AC1148	02	ALL	
AE0301	04	W4425	C2	DISC BKT-E3-1 SHELF DISC							
D41783P	13		0013	22 GA	D41781P	13		AE0401	10	ALL	
D41783P	14		0014	22 GA	D41781P	14		AE0401	10	ALL	
D41783P	20		0020	20 GA	D41781P	20		AE0401	10	115-199	
D41783P	24		0024	22 GA	D41781P	24		AE0401	10	115-199	
D41783P	15		2001B	22 GB	D41781P	15		AE0401	10	115-199	
D41783P	16		2001R	22 GB	D41781P	16		AE0401	10	115-199	
D41783P	21		3001B	22 GC	D41781P	21		AE0401	10	115-199	
D41783P	22		3001R	22 GC	D41781P	22		AE0401	10	115-199	
D41783P	23		3001Y	22 GC	D41781P	23		AE0401	10	115-199	
AE0301	05	W4421	L2	DISC BKT-E3-1 SHELF DISC							
D41775P	1		0001	22 GA	D41773P	1		AE0401	08	ALL	
D41775P	7		0007	22 GA	D41773P	7		AE0401	08	ALL	
D41775P	39		0039	22 GA	D41773P	39		AE0401	08	ALL	
D41775P	40		0040	22 GA	D41773P	40		AE0401	08	115-199	
D41775P	41		0041	22 GA	D41773P	41		AE0401	08	115-199	
D41775P	20		2002B	22 GB	D41773P	20		AE0401	08	115-199	
D41775P	19		2002R	22 GB	D41773P	19		AE0401	08	115-199	
D41775P	29		3001B	22 GC	D41773P	29		AE0401	08	115-199	
D41775P	28		3001R	22 GC	D41773P	28		AE0401	08	115-199	
D41775P	30		3001Y	22 GC	D41773P	30		AE0401	08	115-199	
AE0301	08	W4471	L2	DISC BKT-E3-1 SHELF DISC							
D41301P	1		0018	24 GK	D41481P	1		AP0051	01	ALL	
D41301P	29		0143	22 GA	D41091P	2		AE0201	21	ALL	
D41301P	34		0151	22 GA	D41099P	26		AE0204	20	ALL	
D41301P	12		0285	22 GA	D42187P	22		AE0501	17	001-099	
D41301P	27		2003B	24 GL	D41309P	16		AE0303	05	001-009	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0301

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0301	08	W4471	L2	DISC BKT-E3-1 SHELF DISC (continued)								
D41301P	26		2003R	24 GL	D41309P	15		AE0303	05	001-009		
D41301P	15		2007B	22 GB	D41477P	25		AP0050	02	ALL		
D41301P	14		2007R	22 GB	D41477P	24		AP0050	02	ALL		
D41301P	32		5047B	24 G2	D41099P	24		AE0204	20	ALL		
D41301P	31		5047R	24 G2	D41099P	23		AE0204	20	ALL		
D41301P	33		5047Z		D41099P	25		AE0204	20	ALL		
AE0301	10	W2605	L2	DISC BKT-E3-1 SHELF DISC								
D41841P	10		0024Y	22 QB	D40697P	6		AA1715	01	ALL		
AE0301	12	W4477	S2	DISC BKT-E3-1 SHELF DISC								
D41437P	13		0188	24 GK	D41451P	33		AE0402	12	001-099		
D41437P	10		0220	22 GA	D42185P	4		AE0402	24	001-099		
AE0301	17	W4475	C2	DISC BKT-E3-1 SHELF DISC								
D41399P	7		0031	22 GA	D41675P	5		AP0050	16	115-199		
D41399P	24		0047	22 GA	D41409P	7		AE0402	29	001-099		
D41399P	22		0056	22 GA	D41493P	6		AP0036	29	115-199		
D41399P	23		0059	22 GA	D41495P	14		AP0037	30	115-199		
D41399P	24		0060	22 GA	D41675P	6		AP0050	16	115-199		
D41399P	13		5024B	24 G2	D41815P	33		AE0203	07	001, 003-099		
D41399P	13		5024B	24 G2	D41815P	REF	JB	AE0203	07	002		
D41399P	13		5024B	24 G2	D41815P	34		AE0203	07	115-199		
D41399P	12		5024R	24 G2	D41815P	18		AE0203	07	001, 003-099		
D41399P	12		5024R	24 G2	D41815P	REF	JB	AE0203	07	002		
D41399P	12		5024R	24 G2	D41815P	33		AE0203	07	115-199		
D41399P	14		5024Z		D41815P	37		AE0203	07	001, 003-099		
D41399P	14		5024Z		D41815P	REF	JB	AE0203	07	002		
D41399P	14		5024Z		D41815P	35		AE0203	07	115-199		
D41399P	20		5025B	24 G2	D41397P	25		AE0204	16	001-099		
D41399P	20		5025B	24 G2	D41397P	32		AE0204	16	115-199		
D41399P	19		5025R	24 G2	D41397P	24		AE0204	16	001-099		
D41399P	19		5025R	24 G2	D41397P	31		AE0204	16	115-199		
D41399P	21		5025Z		D41397P	26		AE0204	16	001-099		
D41399P	21		5025Z		D41397P	33		AE0204	16	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0301

Page 2

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0301	19	W2350	L1	DISC BKT-E3-1 SHELF DISC							
D40676P	1		0005	22 GA	D40610P	49		AP0011	03	ALL	
AE0301	23	W4423	R2	DISC BKT-E3-1 SHELF DISC							
D41779P	5		0005	22 GA	D41777P	5		AE0401	21	ALL	
D41779P	37		0037	22 GA	D41777P	37		AE0401	21	ALL	
D41779P	38		0038	22 GA	D41777P	38		AE0401	21	ALL	
D41779P	39		0039	22 GA	D41777P	39		AE0401	21	115-199	
D41779P	40		0040	22 GA	D41777P	40		AE0401	21	115-199	
D41779P	41		0041	22 GA	D41777P	41		AE0401	21	115-199	
D41779P	18		2002B	22 GB	D41777P	18		AE0401	21	115-199	
D41779P	17		2002R	22 GB	D41777P	17		AE0401	21	115-199	
D41779P	20		3001B	22 GC	D41777P	20		AE0401	21	115-199	
D41779P	19		3001R	22 GC	D41777P	19		AE0401	21	115-199	
D41779P	21		3001Y	22 GC	D41777P	21		AE0401	21	115-199	
AE0301	26	W4427	S2	DISC BKT-E3-1 SHELF DISC							
D41787P	5		0005	22 GA	D41785P	5		AE0401	22	ALL	
D41787P	14		0014	22 GA	D41785P	14		AE0401	22	ALL	
D41787P	15		2001B	22 GB	D41785P	15		AE0401	22	ALL	
D41787P	16		2001R	22 GB	D41785P	16		AE0401	22	ALL	
D41787P	19		2002B	22 GB	D41785P	19		AE0401	22	ALL	
D41787P	20		2002R	22 GB	D41785P	20		AE0401	22	ALL	
AE0301	29	W2360	S1	DISC BKT-E3-1 SHELF DISC							
D41902P	3		0603	22 GA	D40624P	3		AP0011	12	ALL	
D41902P	4		0604	22 GA	D40624P	4		AP0011	12	ALL	
D41902P	5		0605	22 GA	D40624P	5		AP0011	12	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0301

Page 3 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0302	01	W2229	R2	DISC BKT-E3-2 SHELF DISC							
D43683P	14		0014	24 GK	D41681P	14		AE0601	01	001-009	
D43683P	9		2502B	24 G2	D41681P	8		AE0601	01	001-009	
D43683P	8		2502R	24 G2	D41681P	9		AE0601	01	001-009	
D43683P	10		2502Z		D41681P	10		AE0601	01	001-009	
D43683P	11		5006B	24 G2	D41681P	11		AE0601	01	003-009	
D43683P	12		5006R	24 G2	D41681P	12		AE0601	01	003-009	
D43683P	13		5006Z		D41681P	13		AE0601	01	003-009	
AE0302	02	W4473	R2	DISC BKT-E3-2 SHELF DISC							
D43005P	15		0285	22 GA	D43007P	15		AE0202	24	001-099	
D43005P	7		0332	22 GA	D41339P	12		AE0201	38	115-199	
D43005P	8		0333	24 GK	D41339P	13		AE0201	38	115-199	
D43005P	18		5087B	24 G2	D43007P	13		AE0202	24	001-099	
D43005P	17		5087R	24 G2	D43007P	12		AE0202	24	001-099	
D43005P	19		5087Z		D43007P	14		AE0202	24	001-099	
D43005P	10		5120B	24 G2	D41339P	43		AE0201	38	115-199	
D43005P	9		5120R	24 G2	D41339P	42		AE0201	38	115-199	
D43005P	11		5120Z		D41339P	44		AE0201	38	115-199	
AE0302	03	W2665	R2	DISC BKT-E3-2 SHELF DISC							
D42059P	9		0009	20 GA	D41735J	9		D41735P		001-099	
D42059P	10		0010	20 GA	D41735J	10		D41735P		001-099	
AE0302	09	W4515	L2	DISC BKT-E3-2 SHELF DISC							
D45001P	2		0002	24 GK	D45003P	2		AE0601	12	001-099	
D45001P	6		2502B	24 G2	D45003P	6		AE0601	12	001-099	
D45001P	7		2502R	24 G2	D45003P	7		AE0601	12	001-099	
D45001P	8		2502Z		D45003P	8		AE0601	12	001-099	
D45001P	15		5003B	24 G2	D45003P	15		AE0601	12	001-099	
D45001P	16		5003R	24 G2	D45003P	16		AE0601	12	001-099	
D45001P	17		5003Z		D45003P	17		AE0601	12	001-099	
AE0302	17	W4106	R2	DISC BKT-E3-2 SHELF DISC							
D40666P	39		0242	24 GK	D40064P	55		AP0037	40	001-099	
D40666P	40		0243	24 GK	D40064P	54		AP0037	40	001-099	
D40666P	41		0244	22 GA	D40064P	52		AP0037	40	001-099	
D40666P	42		0245	22 GA	D40064P	53		AP0037	40	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0302

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0302	17	W4106	R2	DISC BKT-E3-2 SHELF DISC (continued)							
D40666P	49		0248	24 GK	D42086P	34		AE0402	36	001-099	
D40666P	50		0249	24 GK	D42086P	35		AE0402	36	001-099	
AE0302	19	W2358	S1	DISC BKT-E3-2 SHELF DISC							
D43011P	2		0046	20 GA	D40622P	16		AP0011	05	001-099	
AE0302	26	W2253	R2	DISC BKT-E3-2 SHELF DISC							
D42091P	14		0020	22 GA	D40073J	27		AP0003	10	ALL	
D42091P	43		0077	22 GA	D40631J	42		AP0003	08	115-199	
D42091P	44		0078	22 GA	D40631J	43		AP0003	08	115-199	
D42091P	9		2503B	24 G2	D40073J	54		AP0003	10	115-199	
D42091P	8		2503R	24 G2	D40073J	53		AP0003	10	115-199	
D42091P	10		2503Z		D40073J	55		AP0003	10	115-199	
D42091P	41		2510B	24 G2	D40631J	40		AP0003	08	115-199	
D42091P	40		2510R	24 G2	D40631J	39		AP0003	08	115-199	
D42091P	42		2510Z		D40631J	41		AP0003	08	115-199	
D42091P	16		5006B	24 G2	D40073J	16		AP0003	10	001-099	
D42091P	15		5006R	24 G2	D40073J	15		AP0003	10	001-099	
D42091P	17		5006Z		D40073J	17		AP0003	10	001-099	
AE0302	28	W2077	R2	DISC BKT-E3-2 SHELF DISC							
D41527P	7		0007	22 GA	D00257	17		M10140		115-199	
D41527P	1		0009	24 GK	D00257	19		M10140		115-199	
AE0302	29	W4517	R2	DISC BKT-E3-2 SHELF DISC							
D45005P	2		0002	24 GK	D45007P	2		AE0601	09	001-099	
D45005P	6		2502B	24 G2	D45007P	6		AE0601	09	001-099	
D45005P	7		2502R	24 G2	D45007P	7		AE0601	09	001-099	
D45005P	8		2502Z		D45007P	8		AE0601	09	001-099	
D45005P	15		5003B	24 G2	D45007P	15		AE0601	09	001-099	
D45005P	16		5003R	24 G2	D45007P	16		AE0601	09	001-099	
D45005P	17		5003Z		D45007P	17		AE0601	09	001-099	
AE0302	33	W4471	L2	DISC BKT-E3-2 SHELF DISC							
D43001P	15		0283	22 GA	D43003P	15		AE0201	03	001-099	
D43001P	16		0284	24 GK	D43003P	3		AE0201	03	001-099	
D43001P	18		5088B	24 G2	D43003P	13		AE0201	03	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0302

Page 2

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0302	33	W4471	L2	DISC BKT-E3-2 SHELF DISC (continued)								
D43001P	17		5088R	24 G2	D43003P	12		AE0201	03	001-099		
D43001P	19		5088Z		D43003P	14		AE0201	03	001-099		
AE0302	38	W2353	L2	DISC BKT-E3-2 SHELF DISC								
D41741P	11		0008	22 GA	D41101J	11				ALL		
D41741P	12		0009	22 GA	D41101J	12				ALL		
D41741P	13		0010	22 GA	D41101J	13				ALL		
AE0302	40	W4471	L2	DISC BKT-E3-2 SHELF DISC								
D41303P	34		0145	22 GA	D41091P	55		AE0201	21	ALL		
D41303P	35		0279	20 GA	D41309P	34		AE0303	05	001-099		
D41303P	39		5045B	24 G2	D41095P	13		AE0202	28	ALL		
D41303P	38		5045R	24 G2	D41095P	12		AE0202	28	ALL		
D41303P	40		5045Z		D41095P	14		AE0202	28	ALL		
AE0302	41	W4473	R2	DISC BKT-E3-2 SHELF DISC								
D41355P	25		0097	22 GA	D41909P	28		AP0037	20	115-199		
D41355P	26		0107	22 GA	D41909P	29		AP0037	20	115-199		
D41355P	35		0120	24 GK	D41371P	11		AE0403	14	115-199		
D41355P	46		0341	24 GK	D41345P	44		AE0202	08	001, 003-099		
D41355P	46		0341	24 GK	D41345P	REF	VP	AE0202	08	002		
D41355P	3		5039B	24 G2	D41345P	54		AE0202	08	115-199		
D41355P	2		5039R	24 G2	D41345P	53		AE0202	08	115-199		
D41355P	21		5039Z		D41345P	55		AE0202	08	115-199		
D41355P	47		5093B	24 G2	D41339P	38		AE0201	38	115-199		
D41355P	46		5093R	24 G2	D41339P	37		AE0201	38	115-199		
D41355P	48		5093Z		D41339P	36		AE0201	38	115-199		
D41355P	54		5094B	24 G2	D41881P	29		AE0202	11	115-199		
D41355P	53		5094R	24 G2	D41881P	28		AE0202	11	115-199		
D41355P	55		5094Z		D41881P	30		AE0202	11	115-199		
AE0302	43	W2243	R2	DISC BKT-E3-2 SHELF DISC								
D42039P	5		5006B	24 G2	D40077J	36		AP0001	07	115-199		
D42039P	4		5006R	24 G2	D40077J	35		AP0001	07	115-199		
D42039P	6		5006Z		D40077J	37		AP0001	07	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0302

Page 3 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0303	05	W4471	L2	DISC BKT-E3-3 SHELF DISC							
D41309P	12		0013	24 GK	D41473P	3		AP0036	21	001-099	
D41309P	48		0152	24 GK	D41319P	19		AE0403	12	001-099	
D41309P	52		0166	24 GK	D41473P	10		AP0036	21	001-009, 115-199	
D41309P	47		0178	24 GK	D41319P	18		AE0403	12	115-199	
D41309P	45		0179	22 GA	D41097P	52		AE0203	21	002	
D41309P	34		0279	20 GA	D41303P	35		AE0302	40	001-099	
D41309P	11		2001B	24 GL	D41473P	2		AP0036	21	001-099	
D41309P	10		2001R	24 GL	D41473P	1		AP0036	21	001-099	
D41309P	14		2002B	24 GL	D41473P	5		AP0036	21	001-009	
D41309P	13		2002R	24 GL	D41473P	4		AP0036	21	001-009	
D41309P	16		2003B	24 GL	D41301P	27		AE0301	08	001-009	
D41309P	15		2003R	24 GL	D41301P	26		AE0301	08	001-009	
D41309P	2		5007B	24 G2	D41089P	24		AE0201	10	115-199	
D41309P	1		5007R	24 G2	D41089P	23		AE0201	10	115-199	
D41309P	3		5007Z		D41089P	25		AE0201	10	115-199	
D41309P	31		5032B	24 G2	D41317P	35		AE0402	07	001-099	
D41309P	32		5032R	24 G2	D41317P	36		AE0402	07	001-099	
D41309P	33		5032Z		D41317P	37		AE0402	07	001-099	
D41309P	CAP	Y	5049B	24 G2	D41093P	32		AE0201	37	001-099	
D41309P	CAP	Y	5049R	24 G2	D41093P	31		AE0201	37	001-099	
D41309P	DED		5049Z		D41093P	33		AE0201	37	001-099	
AE0303	06	W2075	L2	DISC BKT-E3-3 SHELF DISC							
D41525P	1		0009	24 GK	D00255	19		M10140		115-199	
AE0303	08	W4477	S2	DISC BKT-E3-3 SHELF DISC							
D41443P	3		0018	22 GA	D41739P	4		AP0037	29	001-099	
D41443P	26		0031	24 GK	D41451P	10		AE0402	12	115-199	
D41443P	39		0098	24 GK	D41455J	8		AE0404	01	001-099	
D41443P	33		0116	24 GK	D41429P	2		AE0201	32	115-199	
D41443P	37		0123	24 GK	D41739P	31		AP0037	29	115-199	
D41443P	41		0129	24 GK	D41451P	35		AE0402	12	115-199	
D41443P	43		0146	24 GK	D41739P	21		AP0037	29	115-199	
D41443P	44		0166	22 GA	D41497P	29		AP0036	12	001-099	
D41443P	34		0222	24 GK	D41459P	9		AE0501	03	001-099	
D41443P	28		5014B	24 G2	D41453P	45		AE0403	07	001-099	
D41443P	27		5014R	24 G2	D41453P	44		AE0403	07	001-099	
D41443P	29		5014Z		D41453P	41		AE0403	07	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0303

Page 1

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0303	13	W4471	L2	DISC BKT-E3-3 SHELF DISC								
D41307P	26		0216	22 GA	D41311P	34		AE0304	07	115-199		
D41307P	28		0218	22 GA	D41311P	35		AE0304	07	115-199		
D41307P	5		0287	22 GA	D41311P	24		AE0304	29	001-009		
D41307P	5		0287	22 GA	D41311P	CAP	Y	AE0304	29	010-099		
D41307P	25		2014B	24 GL	D41475P	10		AP0036	02	115-199		
D41307P	24		2014R	24 GL	D41475P	9		AP0036	02	115-199		
AE0303	16	W2251	L2	DISC BKT-E3-3 SHELF DISC								
D42071P	7		0022	24 GK	D40035J	7		AP0003	12	115-199		
D42071P	8		0023	22 GA	D40035J	8		AP0003	12	115-199		
D42071P	9		0024	22 GA	D40035J	9		AP0003	12	ALL		
D42071P	3		0035	22 GA	D40035J	41		AP0003	12	115-199		
D42071P	16		0057	22 GA	D42055J	25		AP0003	19	115-199		
D42071P	17		0058	22 GA	D42055J	26		AP0003	19	115-199		
D42071P	18		0059	22 GA	D42055J	27		AP0003	19	115-199		
D42071P	14		5004B	24 G2	D42055J	14		AP0003	19	001-099		
D42071P	13		5004R	24 G2	D42055J	13		AP0003	19	001-099		
D42071P	15		5004Z		D42055J	15		AP0003	19	001-099		
D42071P	5		5005B	24 G2	D40035J	17		AP0003	12	115-199		
D42071P	4		5005R	24 G2	D40035J	16		AP0003	12	115-199		
D42071P	6		5005Z		D40035J	18		AP0003	12	115-199		
AE0303	18	W2350	L1	DISC BKT-E3-3 SHELF DISC								
D40678P	9		0029	22 GA	D40610P	29		AP0011	03	115-199		
D40678P	1		0604	22 GA	D40610P	9		AP0011	03	115-199		
D40678P	2		0605	22 GA	D40610P	11		AP0011	03	115-199		
AE0303	24	W4006	L2	DISC BKT-E3-3 SHELF DISC								
D40846P	17		0053	22 GA	D40072J	14		AC0880	17	001-099		
D40846P	18		0135	24 GK	D40060P	49		AP0036	07	001-099		
D40846P	20		0138	22 GA	D41544P	14		AP0036	05	001-099		
AE0303	26	W2299	N2	DISC BKT-E3-3 SHELF DISC								
D41519P	3		0003	22 GA	D40003P	3		AP0061	04	ALL		
D41519P	4		0004	22 GA	D40003P	4		AP0061	04	001-099		
D41519P	18		0008	22 GA	D40003P	18		AP0061	04	115-199		
D41519P	19		0009	22 GA	D40003P	19		AP0061	04	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0303

Page 2

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0303	26	W2299	N2	DISC BKT-E3-3 SHELF DISC (continued)							
D41519P	20		0010	22 GA	D40003P	20		AP0061	04	001-099	
D41519P	25		0015	22 GA	D40003P	25		AP0061	04	001-099	
D41519P	30		0015	22 GA	D40003P	25		AP0061	04	115-199	
D41519P	11		5001B	24 G2	D40003P	11		AP0061	04	001-099	
D41519P	10		5001R	24 G2	D40003P	10		AP0061	04	001-099	
D41519P	17		5003B	24 G2	D40003P	17		AP0061	04	001-099	
D41519P	16		5003R	24 G2	D40003P	16		AP0061	04	001-099	
D41519P	29		5003Z		D40003P	33		AP0061	04	001-099	
D41519P	19		5005B	24 G2	D40003P	19		AP0061	04	001-099	
D41519P	18		5005R	24 G2	D40003P	18		AP0061	04	001-099	
D41519P	30		5005Z		D40003P	37		AP0061	04	001-099	
AE0303	30	W2241	L2	DISC BKT-E3-3 SHELF DISC							
D42019P	9		0066	22 GA	D40629J	35		AP0001	08	ALL	
D42019P	23		0099	22 GA	D40629J	36		AP0001	08	115-199	
D42019P	7		5012B	24 G2	D40031J	54		AP0001	16	001-099	
D42019P	6		5012R	24 G2	D40031J	53		AP0001	16	001-099	
D42019P	8		5012Z		D40031J	55		AP0001	16	001-099	
AE0303	36	W1433	N2	DISC BKT-E3-3 SHELF DISC							
D41361J			0160	20 GA	GD01947	ST..	2			115-199	
D41361J	18		5040B	24 G2	D00011D	F14		M00138		115-199	
D41361J	17		5040R	24 G2	D00011D	E14		M00138		115-199	
D41361J			5040Z		D00011D	DED		M00138		115-199	
D41361J			FRBD		D41361J	16		AE0303	36	115-199	
D41361J	16		FRBD		D41361J			AE0303	36	115-199	
AE0303	36	W4473	R2	DISC BKT-E3-3 SHELF DISC							
D41361P	15		0078	24 GK	D41371P	17		AE0403	14	115-199	
D41361P	4		0102	24 GK	D41349P	13		AE0203	33	115-199	
D41361P	6		0109	24 GK	D41349P	16		AE0203	33	115-199	
D41361P	47		2008B	24 GL	D41487P	55		AP0037	50	115-199	
D41361P	48		2008R	24 GL	D41487P	46		AP0037	50	115-199	
D41361P	18		5044B	24 G2	D41881P	34		AE0202	11	115-199	
D41361P	17		5044R	24 G2	D41881P	33		AE0202	11	115-199	
D41361P	16		5044Z		D41881P	32		AE0202	11	115-199	
D41361P	18		5132B	24 G2	D43007P	20		AE0202	24	010-099	
D41361P	17		5132R	24 G2	D43007P	19		AE0202	24	010-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0303

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AE0303		36	W4473	R2	DISC BKT-E3-3 SHELF DISC (continued)							
D41361P	19		5132Z				D43007P	21		AE0202	24	010-099
AE0303		42	W2359	C2	DISC BKT-E3-3 SHELF DISC							
D40927P	3		0009		22	GA	D40503P	11		AP0010	03	115-199
D40927P	4		0010		22	GA	D40503P	10		AP0010	03	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AE0303

Page 4 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0304	03	W4210	S2	DISC BKT-E3-4 SHELF DISC								
D42016P	27		0082	22 GA	D41958P	CAP	Y	AP0036	13	001-099		
AE0304	04	W4220	S2	DISC BKT-E3-4 SHELF DISC								
D42018P	38		0088	24 GK	D41736P	38		AE0402	11	115-199		
D42018P	15		2005B	20 GB	D40280J	10		AD0880	14	115-199		
D42018P	41		2005R	20 GB	D40280J	9		AD0880	14	115-199		
AE0304	05	W4477	S2	DISC BKT-E3-4 SHELF DISC								
D41445P	8		0090	22 GA	D41451P	48		AE0402	12	115-199		
D41445P	9		0091	22 GA	D41451P	49		AE0402	12	115-199		
D41445P	10		0092	22 GA	D41739P	25		AP0037	29	115-199		
D41445P	11		0093	22 GA	D41739P	26		AP0037	29	115-199		
D41445P	14		0127	24 GK	D41451P	53		AE0402	12	115-199		
D41445P	13		0132	24 GK	D41451P	38		AE0402	12	ALL		
D41445P	23		0202	24 GK	D41451P	48		AE0402	12	001-009		
D41445P	CAP	Y	0202	24 GK	D41451P	48		AE0402	12	010-099		
D41445P	30		0203	24 GK	D41451P	49		AE0402	12	001-099		
AE0304	06	W4212	L2	DISC BKT-E3-4 SHELF DISC								
D41634P	19		0014	22 GA	D41794P	1		AE0402	02	001-099		
D41634P	16		0014	22 GA	D41794P	1		AE0402	02	115-199		
D41634P	8		0015	22 GA	D42076J	11		AD0880	04	115-199		
D41634P	18		0016	22 GA	D42076J	12		AD0880	04	001-099		
D41634P	9		0016	22 GA	D42076J	12		AD0880	04	115-199		
AE0304	07	W4204	L2B	DISC BKT-E3-4 SHELF DISC								
D41618P	6		0052	22 GA	D41630P	12		AE0501	14	001-099		
D41618P	16		0183	22 GA	D41628P	4		AE0402	40	001-099		
D41618P	15		0184	22 GA	D41628P	3		AE0402	40	001-099		
AE0304	07	W4471	L2	DISC BKT-E3-4 SHELF DISC								
D41311P	18		0154	22 GA	D41879P	10		AE0402	38	115-199		
D41311P	19		0155	24 GK	D41879P	11		AE0402	38	115-199		
D41311P	20		0156	24 GK	D41481P	22		AP0051	01	115-199		
D41311P	21		0157	24 GK	D41481P	23		AP0051	01	115-199		
D41311P	22		0158	24 GK	D41481P	24		AP0051	01	115-199		
D41311P	23		0172	22 GA	D41879P	12		AE0402	38	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0304

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0304	07	W4471	L2	DISC BKT-E3-4 SHELF DISC (continued)								
D41311P	24		0173	22 GA	D41879P	13		AE0402	38	115-199		
D41311P	25		0174	22 GA	D41879P	14		AE0402	38	115-199		
D41311P	34		0216	22 GA	D41307P	26		AE0303	13	115-199		
D41311P	35		0218	22 GA	D41307P	28		AE0303	13	115-199		
AE0304	08	W4473	R2	DISC BKT-E3-4 SHELF DISC								
D41363P	5		0110	24 GK	D41491P	14		AP0051	05	115-199		
D41363P	18		0137	24 GK	D41491P	38		AP0051	05	001-099		
D41363P	19		0137	24 GK	D41491P	38		AP0051	05	115-199		
D41363P	28		0189	22 GA	D41867P	24		AE0402	01	ALL		
AE0304	09	W2070	R*	DISC BKT-E3-4 SHELF DISC								
D41876P	25		0016	22 GA	D41470P	32		AP0034	09	001-099		
AE0304	09	W4202	L2A	DISC BKT-E3-4 SHELF DISC								
D41610P	35		0088	20 GA	D41606P	3		AE0201	31	115-199		
D41610P	36		0089	20 GA	D41606P	4		AE0201	31	115-199		
D41610P	37		0090	20 GA	D40346J	32		AC1090	19	115-199		
D41610P	38		0091	20 GA	D40346J	33		AC1090	19	115-199		
D41610P	39		0092	20 GA	D40346J	34		AC1090	19	115-199		
D41610P	40		0093	20 GA	D40348J	8		AC1090	11	115-199		
D41610P	43		0094	20 GA	D40898J	31		AW1180	02	115-199		
D41610P	28		2012B	22 GB	D41612P	45		AP0036	28	115-199		
D41610P	29		2012R	22 GB	D41612P	27		AP0036	28	115-199		
AE0304	10	W2070	R*	DISC BKT-E3-4 SHELF DISC								
D41876P	25		0016	22 GA	D41470P	32		AP0034	09	115-199		
D41876P	5		0086	24 GK	D03536	38		M10054		115-199		
D41876P	26		0094	22 GA	D41856P	46		AP0037	33	115-199		
D41876P	CAP	Y	2001B	24 GL	D03536	20		M10054		115-199		
D41876P	6		2001R	24 GL	D03536	39		M10054		115-199		
D41876P	CAP	Y	2002B	24 GL	D03536	19		M10054		115-199		
D41876P	CAP	Y	2002R	24 GL	D03536	18		M10054		115-199		
D41876P	11		2003B	24 GL	D03536	32		M10054		115-199		
D41876P	10		2003R	24 GL	D03536	16		M10054		115-199		
D41876P	13		2008B	24 GL	D03536	10		M10054		115-199		
D41876P	12		2008R	24 GL	D03536	24		M10054		115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0304

Page 2

Dec 18/2007

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AE0304	10	W4202	L2A	DISC BKT-E3-4 SHELF DISC						
D41610P	13		0002	22 GA	D41704P	8		AP0033	24	001-099
D41610P	1		0010	20 GA	D41704P	1		AP0033	24	001-099
D41610P	30		0029	20 GA	D41704P	29		AP0033	24	001-099
D41610P	35		0088	20 GA	D41606P	3		AE0201	31	001-099
D41610P	36		0089	20 GA	D41606P	4		AE0201	31	001-099
D41610P	37		0090	20 GA	D40346J	32		AC1090	19	001-099
D41610P	39		0092	20 GA	D40346J	34		AC1090	19	001-099
D41610P	40		0093	20 GA	D40348J	8		AC1090	11	001-099
D41610P	43		0094	20 GA	D40898P	27		AW1180	02	001-099
D41610P	16		2005B	22 GB	D40898P	4		AW1180	02	001-099
D41610P	15		2005R	22 GB	D40898P	3		AW1180	02	001-099
D41610P	42		2006B	22 GB	D40898P	2		AW1180	02	001-099
D41610P	41		2006R	22 GB	D40898P	1		AW1180	02	001-099
D41610P	28		2012B	24 GL	D41612P	45		AP0036	28	001-099
D41610P	29		2012R	24 GL	D41612P	27		AP0036	28	001-099
AE0304	11	W2247	2S	DISC BKT-E3-4 SHELF DISC						
D42169P	1	18	0016	18 GA	D42165J	16	18	AP0003	09	001-099
D42169P	2		0017	22 GA	D42165J	17		AP0003	09	115-199
D42169P	3		0018	22 GA	D42165J	18		AP0003	09	115-199
D42169P	4		0019	22 GA	D42165J	19		AP0003	09	115-199
D42169P	12		0020	22 GA	D42165J	20		AP0003	09	115-199
AE0304	12	W4228	S2	DISC BKT-E3-4 SHELF DISC						
D42012P	9		0097	20 GA	D40026J	9		AC0880	18	001-002, 115-199
D42012P	11		0149	22 GA	D41948P	19		AP0036	22	001-099
D42012P	13		0258	20 GA	D40002J	30		AC0880	22	001-099
AE0304	15	W4216	R2A	DISC BKT-E3-4 SHELF DISC						
D42060P	6		0014	22 GA	D41616P	22		AP0037	49	115-199
D42060P	29		0103	22 GA	D41658P	11		AE0503	18	115-199
AE0304	15	W4236	S2	DISC BKT-E3-4 SHELF DISC						
D42014P	9		0089	20 GA	D40274J	9		AD0880	12	001-099
D42014P	15		0153	24 GK	D41950P	15		AP0033	19	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section AE0304

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0304	20	W4206	R2A	DISC BKT-E3-4 SHELF DISC								
D41636P	10		0042	20 GA	D41656P	29		AE0503	03	ALL		
D41636P	23		4501AA	20 4K	D41394J	14		AC0880	12	115-199		
D41636P	24		4501WV	20 4K	D41394J	15		AC0880	12	115-199		
AE0304	21	W2066	L*	DISC BKT-E3-4 SHELF DISC								
D40996P	19		0154	24 GK	D40874P	22		AP0036	17	001-099		
D40996P	8		0270	24 GK	D03510	38		M10054		115-199		
D40996P	15		0277	24 GK	D03510	25		M10054		115-199		
D40996P	3		0557	20 GA	D40972P	24		AP0050	03	ALL		
D40996P	4		2001B	24 GL	D03510	32		M10054		115-199		
D40996P	24		2001R	24 GL	D03510	16		M10054		115-199		
D40996P	5		2005B	24 GL	D03510	12		M10054		115-199		
D40996P	7		2005R	24 GL	D03510	11		M10054		115-199		
D40996P	21		2006B	24 GL	D03510	29		M10054		115-199		
D40996P	6		2006R	24 GL	D03510	13		M10054		115-199		
D40996P	13		2007B	24 GL	D03510	10		M10054		115-199		
D40996P	16		2007R	24 GL	D03510	24		M10054		115-199		
D40996P	CAP	Y	2008B	24 GL	D03510	20		M10054		115-199		
D40996P	CAP	Y	2008R	24 GL	D03510	39		M10054		115-199		
D40996P	CAP	Y	2009B	24 GL	D03510	19		M10054		115-199		
D40996P	CAP	Y	2009R	24 GL	D03510	18		M10054		115-199		
AE0304	23	W2350	L1	DISC BKT-E3-4 SHELF DISC								
D40680P	5		0045	22 GA	D40612P	45		AP0011	04	ALL		
D40680P	15		0105	22 GA	D40612P	5		AP0011	04	115-199		
D40680P	1		0141	22 GA	D42216P	1		AE0600	07	115-199		
AE0304	24	W2354	R1	DISC BKT-E3-4 SHELF DISC								
D40702P	14		0015	22 GA	D40824P	14		AP0011	14	ALL		
D40702P	2		0597	22 GA	D40618P	18		AP0011	13	115-199		
D40702P	3		0598	22 GA	D40618P	20		AP0011	13	115-199		
D40702P	5		0608	22 GA	D40618P	47		AP0011	13	115-199		
D40702P	6		0610	22 GA	D40618P	49		AP0011	13	115-199		
AE0304	26	W2072	R*	DISC BKT-E3-4 SHELF DISC								
D40924P	7		0153	24 GK	D40594P	20		AP0037	02	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0304

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0304	28	W4216	R2A	DISC BKT-E3-4 SHELF DISC							
D42060P	6		0014	22 GA	D41616P	22		AP0037	49	001-099	
D42060P	2		0101	20 GA	D40334J	8		AD0880	06	001-099	
D42060P	9		0103	22 GA	D40334J	3		AD0880	06	001-099	
D42060P	11		0106	22 GA	D40930P	34		AW2180	01	001-099	
AE0304	28	W4236	S2	DISC BKT-E3-4 SHELF DISC							
D42014P	7		0089	20 GA	D40274J	9		AD0880	12	115-199	
D42014P	14		0152	20 GA	D40004J	43		AD0880	08	115-199	
D42014P	15		0153	24 GK	D41950P	15		AP0033	19	115-199	
AE0304	29	W4204	L2B	DISC BKT-E3-4 SHELF DISC							
D41618P	29		0009	22 GA	D41628P	11		AE0402	40	115-199	
D41618P	30		0010	22 GA	D41628P	12		AE0402	40	115-199	
D41618P	31		0011	22 GA	D41628P	13		AE0402	40	115-199	
D41618P	32		0012	22 GA	D41628P	14		AE0402	40	115-199	
D41618P	33		0013	22 GA	D41628P	15		AE0402	40	115-199	
D41618P	2		0048	22 GA	D41626P	9		AP0033	22	115-199	
D41618P	3		0049	22 GA	D41626P	10		AP0033	22	115-199	
D41618P	4		0050	22 GA	D40302J	6		AC0880	19	115-199	
D41618P	5		0051	22 GA	D40302J	7		AC0880	19	115-199	
D41618P	6		0052	22 GA	D41630P	12		AE0501	14	115-199	
D41618P	37		0183	22 GA	D41628P	4		AE0402	40	115-199	
D41618P	36		0184	22 GA	D41628P	3		AE0402	40	115-199	
AE0304	29	W4471	L2	DISC BKT-E3-4 SHELF DISC							
D41311P	2		0049	22 GA	D41473P	14		AP0036	21	001-099	
D41311P	19		0155	24 GK	D41879P	11		AE0402	38	001-099	
D41311P	25		0174	22 GA	D41879P	14		AE0402	38	001-099	
D41311P	24		0287	22 GA	D41307P	5		AE0303	13	001-009	
D41311P	CAP	Y	0287	22 GA	D41307P	5		AE0303	13	010-099	
AE0304	30	W4216	R2A	DISC BKT-E3-4 SHELF DISC							
D41614P	50		0008	20 GA	D41616P	17		AP0037	49	115-199	
D41614P	3		0043	20 GA	D40334J	15		AD0880	06	115-199	
D41614P	CAP	Y	0045	20 GA	D40334J	21		AD0880	06	115-199	
D41614P	16		2005B	20 GB	D40334J	25		AD0880	06	115-199	
D41614P	17		2005R	20 GB	D40334J	24		AD0880	06	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0304

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0304	30	W4216	R2A	DISC BKT-E3-4 SHELF DISC (continued)								
D41614P	CAP	Y	2006B	20 GB	D40334J	CAP	Y	AD0880	06	115-199		
D41614P	CAP	Y	2006R	20 GB	D40334J	CAP	Y	AD0880	06	115-199		
D41614P	8		2007B	20 GB	D40334J	13		AD0880	06	115-199		
D41614P	9		2007R	20 GB	D40334J	CAP	Y	AD0880	06	115-199		
D41614P	CAP	Y	2008B	20 GB	D40334J	CAP	Y	AD0880	06	115-199		
D41614P	CAP	Y	2008R	20 GB	D40334J	CAP	Y	AD0880	06	115-199		
D41614P	CAP	Y	2009B	20 GB	D40334J	CAP	Y	AD0880	06	115-199		
D41614P	13		2009R	20 GB	D40334J	16		AD0880	06	115-199		
D41614P	32		4002R	22 GD	D40334J	38		AD0880	06	115-199		
AE0304	31	W4218	R2A	DISC BKT-E3-4 SHELF DISC								
D41620P	26		0011	24 GK	D41632P	11		AE0402	26	115-199		
D41620P	27		0012	22 GA	D41728P	12		AP0037	24	115-199		
D41620P	28		0013	22 GA	D41728P	13		AP0037	24	115-199		
D41620P	21		0043	20 GA	D40402J	19		AD0880	10	115-199		
D41620P	23		0044	20 GA	D40402J	20		AD0880	10	115-199		
D41620P	33		0321	22 GA	D41632P	1		AE0402	26	115-199		
D41620P	34		0322	22 GA	D41632P	2		AE0402	26	115-199		
D41620P	31		0359	24 GK	D41728P	33		AP0037	24	001-099		
D41620P	CAP	Y	2006B	22 GB	D41728P	CAP	Y	AP0037	24	115-199		
D41620P	CAP	Y	2006R	22 GB	D41728P	CAP	Y	AP0037	24	115-199		
D41620P	38		4501AA	20 4K	D41198J	14		AD0880	18	115-199		
D41620P	39		4501WV	20 4K	D41198J	15		AD0880	18	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0304

Page 6 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0401	02	W2350	L1	DISC BKT-E4-1 SHELF DISC							
D40682P	6		0728	22 GA	D40612P	29		AP0011	04	115-199	
D40682P	7		0729	22 GA	D40612P	28		AP0011	04	ALL	
AE0401	08	W4421	L2	DISC BKT-E4-1 SHELF DISC							
D41773P	1		0001	22 GA	D41775P	1		AE0301	05	ALL	
D41773P	7		0007	22 GA	D41775P	7		AE0301	05	ALL	
D41773P	39		0039	22 GA	D41775P	39		AE0301	05	ALL	
D41773P	40		0040	22 GA	D41775P	40		AE0301	05	115-199	
D41773P	41		0041	22 GA	D41775P	41		AE0301	05	115-199	
D41773P	20		2002B	22 GB	D41775P	20		AE0301	05	115-199	
D41773P	19		2002R	22 GB	D41775P	19		AE0301	05	115-199	
D41773P	29		3001B	22 GC	D41775P	29		AE0301	05	115-199	
D41773P	28		3001R	22 GC	D41775P	28		AE0301	05	115-199	
D41773P	30		3001Y	22 GC	D41775P	30		AE0301	05	115-199	
AE0401	10	W4425	C2	DISC BKT-E4-1 SHELF DISC							
D41781P	13		0013	22 GA	D41783P	13		AE0301	04	ALL	
D41781P	14		0014	22 GA	D41783P	14		AE0301	04	ALL	
D41781P	20		0020	20 GA	D41783P	20		AE0301	04	115-199	
D41781P	24		0024	22 GA	D41783P	24		AE0301	04	115-199	
D41781P	15		2001B	22 GB	D41783P	15		AE0301	04	115-199	
D41781P	16		2001R	22 GB	D41783P	16		AE0301	04	115-199	
D41781P	21		3001B	22 GC	D41783P	21		AE0301	04	115-199	
D41781P	22		3001R	22 GC	D41783P	22		AE0301	04	115-199	
D41781P	23		3001Y	22 GC	D41783P	23		AE0301	04	115-199	
AE0401	11	W2447	R*	DISC BKT-E4-1 SHELF DISC							
D41771P	29		2013B	22 GB	D00631	11		TS5082		001-099	
D41771P	30		2013R	22 GB	D00631	12		TS5082		001-099	
D41771P	31		2014B	22 GB	D00881	11		AC0215	02	001-099	
D41771P	32		2014R	22 GB	D00881	12		AC0215	02	001-099	
AE0401	13	W2072	R*	DISC BKT-E4-1 SHELF DISC							
D41862P	5		0109	20 GA	D41842P	10		AE0402	31	115-199	
D41862P	6		0110	20 GA	D41842P	11		AE0402	31	115-199	
D41862P	15		0112	20 GA	D41842P	13		AE0402	31	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0401

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0401	14	W2354	R1	DISC BKT-E4-1 SHELF DISC								
D41918P	5		0603	22 GA	D40618P	38		AP0011	13	115-199		
D41918P	6		0604	22 GA	D40618P	40		AP0011	13	115-199		
D41918P	8		0605	22 GA	D40618P	41		AP0011	13	115-199		
AE0401	20	W4471	L2	DISC BKT-E4-1 SHELF DISC								
D40015P	8		5074B	24 G2	D41099P	19		AE0204	20	001-099		
D40015P	7		5074R	24 G2	D41099P	18		AE0204	20	001-099		
D40015P	9		5074Z		D41099P	20		AE0204	20	001-099		
AE0401	21	W4423	R2	DISC BKT-E4-1 SHELF DISC								
D41777P	5		0005	22 GA	D41779P	5		AE0301	23	ALL		
D41777P	37		0037	22 GA	D41779P	37		AE0301	23	ALL		
D41777P	38		0038	22 GA	D41779P	38		AE0301	23	ALL		
D41777P	39		0039	22 GA	D41779P	39		AE0301	23	115-199		
D41777P	40		0040	22 GA	D41779P	40		AE0301	23	115-199		
D41777P	41		0041	22 GA	D41779P	41		AE0301	23	115-199		
D41777P	18		2002B	22 GB	D41779P	18		AE0301	23	115-199		
D41777P	17		2002R	22 GB	D41779P	17		AE0301	23	115-199		
D41777P	20		3001B	22 GC	D41779P	20		AE0301	23	115-199		
D41777P	19		3001R	22 GC	D41779P	19		AE0301	23	115-199		
D41777P	21		3001Y	22 GC	D41779P	21		AE0301	23	115-199		
AE0401	22	W4427	S2	DISC BKT-E4-1 SHELF DISC								
D41785P	5		0005	22 GA	D41787P	5		AE0301	26	ALL		
D41785P	14		0014	22 GA	D41787P	14		AE0301	26	ALL		
D41785P	15		2001B	22 GB	D41787P	15		AE0301	26	ALL		
D41785P	16		2001R	22 GB	D41787P	16		AE0301	26	ALL		
D41785P	19		2002B	22 GB	D41787P	19		AE0301	26	ALL		
D41785P	20		2002R	22 GB	D41787P	20		AE0301	26	ALL		
AE0401	23	W4473	R2	DISC BKT-E4-1 SHELF DISC								
D41367P	1		0013	24 GK	D41491P	6		AP0051	05	ALL		
D41367P	47		0037	22 GA	D41487P	10		AP0037	50	ALL		
D41367P	3		0053	24 GK	D41369P	41		AE0402	32	001-099		
D41367P	26		0104	22 GA	D41351P	6		AE0204	02	001-099		
D41367P	26		0104	24 GK	D41351P	6		AE0204	02	115-199		
D41367P	27		0112	24 GK	D41491P	17		AP0051	05	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0401

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AE0401		23	W4473	R2	DISC BKT-E4-1 SHELF DISC (continued)							
D41367P		28		0113	24	GK	D41487P	36		AP0037	50	115-199
D41367P		30		0135	24	GK	D41491P	31		AP0051	05	115-199
AE0401		24	W2611	R2	DISC BKT-E4-1 SHELF DISC							
D41843P		6		0010	22	GA	D40699P	6		AA1715	07	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AE0401

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0402	01	W1275	N2	DISC BKT-E4-2 SHELF DISC								
D41867J	51		6494	24 GK	TB0207Y	C100	BJ	TB0207		115-199		
AE0402	01	W4473	R2	DISC BKT-E4-2 SHELF DISC								
D41867P	32		0047	24 GK	D41907P	12		AE0202	26	ALL		
D41867P	1		0062	24 GK	D41487P	17		AP0037	50	115-199		
D41867P	2		0063	24 GK	D41491P	41		AP0051	05	001, 003-099		
D41867P	REF	VP	0063	24 GK	D41491P	41		AP0051	05	002		
D41867P	2		0063	24 GK	D41487P	18		AP0037	50	115-199		
D41867P	11		0106	22 GA	D41349P	15		AE0203	33	001, 003-099		
D41867P	11		0106	22 GA	D41349P	REF	VP	AE0203	33	002		
D41867P	33		0108	24 GK	D41907P	26		AE0202	26	ALL		
D41867P	10		0118	24 GK	D41487P	37		AP0037	50	115-199		
D41867P	24		0189	22 GA	D41363P	28		AE0304	08	ALL		
AE0402	02	W4212	L2	DISC BKT-E4-2 SHELF DISC								
D41794P	1		0014	22 GA	D41634P	19		AE0304	06	001-099		
D41794P	1		0014	22 GA	D41634P	16		AE0304	06	115-199		
AE0402	03	W4206	R2A	DISC BKT-E4-2 SHELF DISC								
D41792P	8		0010	20 GA	D41732P	6		AP0037	28	ALL		
D41792P	10		0038	22 GA	D40964J	13		AC1090	05	ALL		
D41792P	11		0039	22 GA	D40922P	10		AW1156	02	001-099		
D41792P	11		0039	22 GA	D40922J	10		AW1156	02	115-199		
AE0402	04	W2078	S*	DISC BKT-E4-2 SHELF DISC								
D41844P	21		0402	20 GA	D03548	CAP	Y	M10050		001-099		
D41844P	22		0403	20 GA	D03548	CAP	Y	M10050		001-099		
D41844P	23		0420	20 GA	D41878J	20		AP0003	14	001-099		
AE0402	04	W4230	S2	DISC BKT-E4-2 SHELF DISC								
D41764P	20		0024	22 GA	D41936P	2		AP0054	07	115-199		
D41764P	17		0026	20 GA	D41354J	19		AC0880	08	115-199		
D41764P	12		0027	22 GA	D41354J	17		AC0880	08	115-199		
D41764P	11		0028	22 GA	D41354J	16		AC0880	08	115-199		
D41764P	13		0029	22 GA	D41354J	18		AC0880	08	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description							
Equip	Term	Type	Wire No.	GA	TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AE0402	05	W2311	N2	DISC BKT-E4-2 SHELF DISC							
D41069P	25		2509T	24	BV	D00325	CAP	Y	N10013		001-099
D41069P	26		2509W	24	BV	D00325	CAP	Y	N10013		001-099
D41069P	27		2509Z			D00325	DED		N10013		001-099
AE0402	06	W2064	L*	DISC BKT-E4-2 SHELF DISC							
D41840P	11		0087	24	GK	D40582P	6		AP0036	25	001-099
D41840P	5		0150	24	GK	D40582P	5		AP0036	25	001-099
D41840P	6		0151	20	GA	D40582P	7		AP0036	25	115-199
D41840P	7		0152	20	GA	D40582P	8		AP0036	25	115-199
D41840P	8		0153	20	GA	D40582P	11		AP0036	25	115-199
AE0402	07	W1275	N2	DISC BKT-E4-2 SHELF DISC							
D41317J	45		6126	24	GK	D00319D	C15				001-099
D41317J	45		6127	24	GK	D00321D	C15				001-099
AE0402	07	W4471	L2	DISC BKT-E4-2 SHELF DISC							
D41317P	15		0029	24	GK	D41325P	8		AE0501	16	115-199
D41317P	24		0036	24	GK	D41319P	6		AE0403	12	115-199
D41317P	25		0051	24	GK	D41325P	34		AE0501	16	115-199
D41317P	26		0052	24	GK	D41325P	35		AE0501	16	115-199
D41317P	30		0073	22	GA	D41091P	48		AE0201	21	ALL
D41317P	38		0083	24	GK	D41473P	20		AP0036	21	ALL
D41317P	40		0086	24	GK	D41325P	39		AE0501	16	115-199
D41317P	45		0093	24	GK	D41473P	28		AP0036	21	ALL
D41317P	16		0135	22	GA	D41099P	15		AE0204	20	001-099
D41317P	8		0136	22	GA	D41099P	16		AE0204	20	001-099
D41317P	8		0160	24	GK	D41325P	CAP	Y	AE0501	16	115-199
D41317P	9		0161	24	GK	D41473P	51		AP0036	21	115-199
D41317P	35		5032B	24	G2	D41309P	31		AE0303	05	001-099
D41317P	36		5032R	24	G2	D41309P	32		AE0303	05	001-099
D41317P	37		5032Z			D41309P	33		AE0303	05	001-099
D41317P	42		5034B	24	G2	D41477P	39		AP0050	02	115-199
D41317P	41		5034R	24	G2	D41477P	38		AP0050	02	115-199
D41317P	43		5034Z			D41477P	40		AP0050	02	115-199
D41317P	25		5042B	24	G2	D41089P	41		AE0201	10	001-099
D41317P	24		5042R	24	G2	D41089P	40		AE0201	10	001-099
D41317P	26		5042Z			D41089P	DED		AE0201	10	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0402	08	W4202	L2A	DISC BKT-E4-2 SHELF DISC								
D41698P	18		0057	22 GA	D40898P	31		AW1180	02	001-099		
D41698P	18		0057	22 GA	D40898J	35		AW1180	02	115-199		
D41698P	29		0059	22 GA	D41652P	34		AE0501	01	001-099		
D41698P	39		0059	22 GA	D41652P	34		AE0501	01	115-199		
AE0402	09	W4006	L2	DISC BKT-E4-2 SHELF DISC								
D41664P	1		0272	22 GA	D41544P	50		AP0036	05	001-099		
D41664P	30		0272	22 GA	D41544P	50		AP0036	05	115-199		
AE0402	10	W4236	S2	DISC BKT-E4-2 SHELF DISC								
D41776P	12		0083	20 GA	D40004J	41		AD0880	08	115-199		
D41776P	33		0131	22 GA	D41946P	31		AP0054	02	ALL		
D41776P	12		0221	20 GA	D40004J	41		AD0880	08	001-099		
D41776P	40		2509B	20 GU	D40004J	12		AD0880	08	001-099		
D41776P	41		2509R	20 GU	D40004J	13		AD0880	08	001-099		
D41776P	9		2509Z		D40004J	S/R		AD0880	08	001-099		
AE0402	11	W4220	S2	DISC BKT-E4-2 SHELF DISC								
D41736P	5		0044	20 GA	D40032J	41		AD0880	05	115-199		
D41736P	6		0045	20 GA	D40032J	42		AD0880	05	115-199		
D41736P	38		0088	24 GK	D42018P	38		AE0304	04	115-199		
D41736P	40		0089	20 GA	D40370J	23		AD1090	03	115-199		
D41736P	41		0090	20 GA	D40370J	10		AD1090	03	115-199		
D41736P	49		0149	22 GA	D40032J	40		AD0880	05	001-099		
D41736P	50		0150	22 GA	D40032J	41		AD0880	05	001-099		
D41736P	51		0151	22 GA	D40032J	42		AD0880	05	001-099		
D41736P	47		0158	20 GA	D40032J	1		AD0880	05	115-199		
D41736P	52		2504B	22 GU	D40032J	1		AD0880	05	001-099		
D41736P	53		2504R	22 GU	D40032J	2		AD0880	05	001-099		
D41736P	54		2504Z		D40032J	4		AD0880	05	001-099		
D41736P	48		2508B	20 GU	D40032J	2		AD0880	05	115-199		
D41736P	49		2508R	20 GU	D40032J	3		AD0880	05	115-199		
D41736P	50		2508Z		D40032J	4		AD0880	05	115-199		
AE0402	12	W4477	S2	DISC BKT-E4-2 SHELF DISC								
D41451P	1		0001	24 GK	D41739P	18		AP0037	29	001-099		
D41451P	1		0001	24 GK	D41497P	1		AP0036	12	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0402	12	W4477	S2	DISC BKT-E4-2 SHELF DISC (continued)							
D41451P	10		0031	24 GK	D41443P	26		AE0303	08	115-199	
D41451P	48		0090	22 GA	D41445P	8		AE0304	05	115-199	
D41451P	49		0091	22 GA	D41445P	9		AE0304	05	115-199	
D41451P	34		0094	22 GA	D41433P	29		AE0203	03	ALL	
D41451P	51		0121	24 GK	D41433P	CAP	Y	AE0203	03	115-199	
D41451P	53		0127	24 GK	D41445P	14		AE0304	05	115-199	
D41451P	16		0128	24 GK	D41431P	3		AE0202	10	ALL	
D41451P	35		0129	24 GK	D41443P	41		AE0303	08	115-199	
D41451P	38		0132	24 GK	D41445P	13		AE0304	05	ALL	
D41451P	54		0138	24 GK	D41459P	CAP	Y	AE0501	03	001-099	
D41451P	33		0188	24 GK	D41437P	13		AE0301	12	001-099	
D41451P	48		0202	24 GK	D41445P	23		AE0304	05	001-009	
D41451P	48		0202	24 GK	D41445P	CAP	Y	AE0304	05	010-099	
D41451P	49		0203	24 GK	D41445P	30		AE0304	05	001-099	
D41451P	18		5005B	24 G2	D41433P	18		AE0203	03	ALL	
D41451P	19		5005R	24 G2	D41433P	19		AE0203	03	ALL	
D41451P	20		5005Z		D41433P	20		AE0203	03	ALL	
AE0402	13	W2250	S1	DISC BKT-E4-2 SHELF DISC							
D40904P	4		0012	22 GA	D40246P	25		AP0006	05	ALL	
D40904P	6		0013	22 GA	D40246P	24		AP0006	05	115-199	
D40904P	15		0015	22 GA	D40246P	15		AP0006	05	115-199	
D40904P	10		0028	20 GA	D40246P	30		AP0006	05	115-199	
D40904P	9		0029	20 GA	D40246P	29		AP0006	05	115-199	
D40904P	14		0055	20 GA	D40246P	13		AP0006	05	115-199	
AE0402	14	W4234	S2	DISC BKT-E4-2 SHELF DISC							
D41774P	14		0011	22 GA	D41358J	19		AD0880	03	001-099	
D41774P	16		0014	22 GA	D41940P	9		AP0054	09	001-099	
D41774P	20		0024	24 GK	D42008P	10		AP0037	22	001-099	
D41774P	21		0032	24 GK	D42008P	14		AP0037	22	001-099	
D41774P	24		0033	20 GA	D42008P	15		AP0037	22	001-099	
D41774P	12		2503B	22 GU	D41358J	17		AD0880	03	001-099	
D41774P	11		2503R	22 GU	D41358J	16		AD0880	03	001-099	
D41774P	13		2503Z		D41358J	18		AD0880	03	001-099	
AE0402	15	W2253	R2	DISC BKT-E4-2 SHELF DISC							
D42093P	2		0071	22 GA	D41041J	24		AP0003	16	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0402	15	W2253	R2	DISC BKT-E4-2 SHELF DISC (continued)								
D42093P	3		0072	22 GA	D41041J	25		AP0003	16	115-199		
D42093P	5		2504B	24 G2	D41041J	54		AP0003	16	001-099		
D42093P	4		2504R	24 G2	D41041J	53		AP0003	16	001-099		
D42093P	6		2504Z		D41041J	55		AP0003	16	001-099		
AE0402	16	W4228	S2	DISC BKT-E4-2 SHELF DISC								
D41738P	7		0027	22 GA	D41944P	36		AP0054	01	ALL		
D41738P	42		0109	20 GA	D40002J	41		AC0880	22	001-099		
AE0402	17	W4006	L2	DISC BKT-E4-2 SHELF DISC								
D42084P	52		0311	22 GA	D40630J	52		AC0820	02	115-199		
AE0402	18	W4232	S2	DISC BKT-E4-2 SHELF DISC								
D41772P	12		0015	20 GA	D40018J	15		AC0880	20	001-099		
D41772P	18		0016	20 GA	D40018J	18		AC0880	20	001-099		
AE0402	19	W2080	A*	DISC BKT-E4-2 SHELF DISC								
D40602P	14		0027	22 GA	D41868P	21		AE0503	01	115-199		
D40602P	15		0028	22 GA	D41868P	22		AE0503	01	115-199		
D40602P	9		0029	22 GA	D41868P	23		AE0503	01	115-199		
D40602P	10		0030	22 GA	D41868P	24		AE0503	01	115-199		
D40602P	7		0032	20 GA	D03576	CAP	Y	M00001		001-099		
D40602P	7		0032	20 GA	D03506	CAP	Y	M10063		115-199		
D40602P	8		0035	20 GA	D03576	CAP	Y	M00001		001-099		
D40602P	8		0035	20 GA	D03576	CAP	Y	M10324		115-199		
D40602P	11		0036	20 GA	D03714	CAP	Y	M10191		ALL		
AE0402	20	W2078	S*	DISC BKT-E4-2 SHELF DISC								
D41844P	3		0126	24 GK	D40570P	8		AP0037	06	115-199		
D41844P	17		0339	20 GA	D41850P	37		AP0036	14	115-199		
D41844P	18		0340	20 GA	D41850P	38		AP0036	14	115-199		
D41844P	19		0341	20 GA	D41850P	39		AP0036	14	115-199		
D41844P	20		0342	20 GA	D41850P	40		AP0036	14	115-199		
D41844P	21		0402	20 GA	D03548	CAP	Y	M10050		115-199		
D41844P	22		0403	20 GA	D03548	CAP	Y	M10050		115-199		
D41844P	23		0404	20 GA	D03504	CAP	Y	M10063		115-199		
D41844P	24		0405	20 GA	D03504	CAP	Y	M10063		115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 5

Dec 18/2007

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0402	20	W2078	S*	DISC BKT-E4-2 SHELF DISC (continued)								
D41844P	25		0406	20 GA	D03504	CAP	Y	M10063		115-199		
D41844P	26		0407	20 GA	D03516	CAP	Y	M10055		115-199		
D41844P	27		0408	20 GA	D03516	CAP	Y	M10055		115-199		
D41844P	28		0409	20 GA	D03516	CAP	Y	M10055		115-199		
D41844P	29		0410	20 GA	D02346	CAP	Y	M00013		115-199		
D41844P	30		0411	20 GA	D02346	CAP	Y	M00013		115-199		
D41844P	31		0412	20 GA	D02346	CAP	Y	M00013		115-199		
D41844P	35		0416	20 GA	D40296P	26		AP0006	01	115-199		
D41844P	36		0417	20 GA	D40296P	27		AP0006	01	115-199		
D41844P	39		0420	20 GA	D41878J	20		AP0003	14	115-199		
AE0402	20	W4238	S2	DISC BKT-E4-2 SHELF DISC								
D41788P	1		2502B	22 GU	D40020J	21		AD0880	20	001-099		
D41788P	23		2502R	22 GU	D40020J	27		AD0880	20	001-099		
D41788P	11		2502Z		D40020J	28		AD0880	20	001-099		
AE0402	21	W2650	A2	DISC BKT-E4-2 SHELF DISC								
D41660P	9		0018	22 GA	D41662P	3		AE0604	08	115-199		
D41660P	15		0070	22 GA	D41680P	44		AE0600	03	001-099		
D41660P	28		0072	22 GA	D42080P	11		AP0036	03	001-099		
AE0402	22	W2070	R*	DISC BKT-E4-2 SHELF DISC								
D41058P	19		0030	24 GK	D40598P	1		AE0502	26	115-199		
D41058P	22		0041	22 GA	D40590P	16		AE0503	14	115-199		
D41058P	34		0124	22 GA	D41470P	CAP	Y	AP0034	09	115-199		
D41058P	6		0145	24 GK	D40598P	45		AE0502	26	115-199		
D41058P	36		0458	20 GA	D41172J	22		AP0003	07	ALL		
D41058P	CAP	Y	0461	20 GA	D03546	CAP	Y	M10050		115-199		
D41058P	40		0462	20 GA	D03546	CAP	Y	M10050		115-199		
D41058P	CAP	Y	0463	20 GA	D03502	CAP	Y	M10063		ALL		
D41058P	22		0464	20 GA	D03502	CAP	Y	M10063		001-099		
D41058P	42		0464	20 GA	D03502	CAP	Y	M10063		115-199		
D41058P	43		0465	20 GA	D03520	CAP	Y	M10023		115-199		
D41058P	44		0466	20 GA	D03520	CAP	Y	M10023		115-199		
D41058P	45		0467	20 GA	D03532	CAP	Y	M10057		115-199		
D41058P	50		0468	20 GA	D03532	CAP	Y	M10057		115-199		
D41058P	51		0469	20 GA	D03540	CAP	Y	M10259		115-199		
D41058P	52		0470	20 GA	D03540	CAP	Y	M10259		115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 6

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0402	22	W2070	R*	DISC BKT-E4-2 SHELF DISC (continued)								
D41058P	53		0471	20 GA	D03704	CAP	Y	M10398		115-199		
D41058P	19		0472	20 GA	D03704	CAP	Y	M10398		001-099		
D41058P	54		0472	20 GA	D03704	CAP	Y	M10398		115-199		
D41058P	55		0473	20 GA	D03704	CAP	Y	M10398		115-199		
D41058P	39		0484	24 GK	D40598P	6		AE0502	26	001-099		
D41058P	CAP	Y	0800	20 GA	D03532	22		M10057		115-199		
D41058P	38	18	0803	18 GA	D03532	21	18	M10057		115-199		
AE0402	23	W4230	S2	DISC BKT-E4-2 SHELF DISC								
D41764P	10		0004	22 GA	D41354J	20		AC0880	08	001-099		
D41764P	20		0024	22 GA	D41936P	2		AP0054	07	001-099		
D41764P	17		0026	20 GA	D41354J	19		AC0880	08	001-099		
D41764P	12		0027	22 GA	D41354J	17		AC0880	08	001-099		
D41764P	11		0028	22 GA	D41354J	16		AC0880	08	001-099		
D41764P	13		0029	22 GA	D41354J	18		AC0880	08	001-099		
D41764P	15		0035	24 GK	D41938P	12		AP0036	23	001-099		
AE0402	24	W4477	S2	DISC BKT-E4-2 SHELF DISC								
D42185P	7		0159	24 GK	D41059P	40		AP0051	03	ALL		
D42185P	10		0165	24 GK	D41497P	28		AP0036	12	115-199		
D42185P	14		0171	22 GA	D41739P	37		AP0037	29	ALL		
D42185P	4		0220	22 GA	D41437P	10		AE0301	12	001-099		
AE0402	25	W2251	L2	DISC BKT-E4-2 SHELF DISC								
D42073P	12		0004	22 GA	D40035J	33		AP0003	12	ALL		
D42073P	13		0005	22 GA	D40035J	34		AP0003	12	115-199		
D42073P	11		0026	22 GA	D40035J	48		AP0003	12	115-199		
AE0402	26	W4218	R2A	DISC BKT-E4-2 SHELF DISC								
D41632P	11		0011	22 GA	D40402J	11		AD0880	10	001-099		
D41632P	11		0011	24 GK	D41620P	26		AE0304	31	115-199		
D41632P	1		0321	22 GA	D41620P	33		AE0304	31	115-199		
D41632P	2		0322	22 GA	D41620P	34		AE0304	31	115-199		
D41632P	24		0358	24 GK	D41728P	32		AP0037	24	001-099		
AE0402	27	W4216	R2A	DISC BKT-E4-2 SHELF DISC								
D41720P	7		0079	22 GA	D41616P	27		AP0037	49	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 7

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AE0402	27	W4216	R2A	DISC BKT-E4-2 SHELF DISC (continued)						
D41720P	20		0082	24 GK	D41616P	39		AP0037	49	115-199
D41720P	21		0083	24 GK	D41616P	40		AP0037	49	115-199
D41720P	16		0105	22 GA	D40930P	24		AW2180	01	001-099
D41720P	16		0105	22 GA	D40930J	26		AW2180	01	115-199
AE0402	29	W4475	C2	DISC BKT-E4-2 SHELF DISC						
D41409P	7		0047	22 GA	D41399P	24		AE0301	17	001-099
D41409P	8		0051	22 GA	D41397P	30		AE0204	16	115-199
D41409P	52		0052	22 GA	D41397P	34		AE0204	16	115-199
D41409P	11		0054	24 GK	D41815P	18		AE0203	07	115-199
AE0402	31	W2072	R*	DISC BKT-E4-2 SHELF DISC						
D41842P	7		0074	24 GK	D40594P	51		AP0037	02	ALL
D41842P	10		0109	20 GA	D41862P	5		AE0401	13	115-199
D41842P	11		0110	20 GA	D41862P	6		AE0401	13	115-199
D41842P	12		0111	20 GA	D40594P	14		AP0037	02	115-199
D41842P	13		0112	20 GA	D41862P	15		AE0401	13	115-199
D41842P	14		0113	20 GA	D40594P	16		AP0037	02	115-199
D41842P	15		0114	20 GA	D40594P	17		AP0037	02	115-199
D41842P	16		0115	20 GA	D41872P	7		AE0101	14	115-199
D41842P	17		0116	20 GA	D41872P	8		AE0101	14	115-199
AE0402	32	W4473	R2	DISC BKT-E4-2 SHELF DISC						
D41369P	26		0038	24 GK	D41487P	11		AP0037	50	115-199
D41369P	32		0044	24 GK	D41379P	22		AE0502	03	115-199
D41369P	33		0045	24 GK	D41379P	23		AE0502	03	115-199
D41369P	40		0052	24 GK	D41487P	14		AP0037	50	ALL
D41369P	41		0053	24 GK	D41367P	3		AE0401	23	001-099
D41369P	41		0053	24 GK	D41379P	32		AE0502	03	115-199
D41369P	42		0055	24 GK	D41487P	16		AP0037	50	115-199
D41369P	43		0056	24 GK	D41379P	33		AE0502	03	115-199
D41369P	23		0105	22 GA	D41351P	7		AE0204	02	001-099
D41369P	54		0116	24 GK	D41379P	48		AE0502	03	115-199
D41369P	55		0117	24 GK	D41371P	10		AE0403	14	115-199
D41369P	27		2002B	24 GL	D41379P	29		AE0502	03	115-199
D41369P	28		2002R	24 GL	D41379P	30		AE0502	03	115-199
D41369P	23		5011B	24 G2	D41349P	27		AE0203	33	115-199
D41369P	24		5011R	24 G2	D41349P	26		AE0203	33	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 8

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0402	32	W4473	R2	DISC BKT-E4-2 SHELF DISC (continued)								
D41369P	25		5011Z		D41349P	28		AE0203	33	115-199		
D41369P	48		5022B	24 G2	D41489P	16		AP0050	12	115-199		
D41369P	47		5022R	24 G2	D41489P	15		AP0050	12	115-199		
D41369P	49		5022Z		D41489P	17		AP0050	12	115-199		
D41369P	52		5038B	24 G2	D41345P	49		AE0202	08	115-199		
D41369P	51		5038R	24 G2	D41345P	38		AE0202	08	115-199		
D41369P	53		5038Z		D41345P	50		AE0202	08	115-199		
AE0402	33	W2243	R2	DISC BKT-E4-2 SHELF DISC								
D42041P	10		0001	24 GK	D40077J	10		AP0001	07	001-099		
D42041P	10		0001	22 GA	D40077J	10		AP0001	07	115-199		
D42041P	8		2502B	24 G2	D40077J	8		AP0001	07	115-199		
D42041P	7		2502R	24 G2	D40077J	7		AP0001	07	115-199		
D42041P	9		2502Z		D40077J	9		AP0001	07	115-199		
D42041P	2		2504B	24 G2	D40077J	30		AP0001	07	001-099		
D42041P	1		2504R	24 G2	D40077J	29		AP0001	07	001-099		
D42041P	3		2504Z		D40077J	31		AP0001	07	001-099		
D42041P	20		2508B	24 G2	D40077J	47		AP0001	07	115-199		
D42041P	19		2508R	24 G2	D40077J	46		AP0001	07	115-199		
D42041P	21		2508Z		D40077J	48		AP0001	07	115-199		
AE0402	35	W2350	L1	DISC BKT-E4-2 SHELF DISC								
D40684P	6		0034	24 GK	D40610P	34		AP0011	03	115-199		
D40684P	8		0323	22 GA	D40612P	23		AP0011	04	115-199		
D40684P	9		0324	22 GA	D40612P	24		AP0011	04	115-199		
D40684P	12		0502	22 GA	D40610P	5		AP0011	03	115-199		
AE0402	36	W4106	R2	DISC BKT-E4-2 SHELF DISC								
D42086P	34		0248	24 GK	D40666P	49		AE0302	17	001-099		
D42086P	34		0248	24 GK	D41642J	34		AD0820	03	115-199		
D42086P	35		0249	24 GK	D40666P	50		AE0302	17	001-099		
D42086P	35		0249	24 GK	D41642J	35		AD0820	03	115-199		
AE0402	37	W2313	N2	DISC BKT-E4-2 SHELF DISC								
D41071P	25		2509T	24 BV	D00327	CAP	Y	N10014		001-099		
D41071P	26		2509W	24 BV	D00327	CAP	Y	N10014		001-099		
D41071P	27		2509Z		D00327	DED		N10014		001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 9

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0402	38	W1275	N2	DISC BKT-E4-2 SHELF DISC								
D41879J	54		6495	24 GK	TB0207Y	C083	BJ	TB0207		115-199		
AE0402	38	W4471	L2	DISC BKT-E4-2 SHELF DISC								
D41879P	40		0124	24 GK	D41093P	18		AE0201	37	115-199		
D41879P	41		0125	24 GK	D41093P	22		AE0201	37	115-199		
D41879P	10		0154	22 GA	D41311P	18		AE0304	07	115-199		
D41879P	11		0155	24 GK	D41311P	19		AE0304	29	001-099		
D41879P	11		0155	24 GK	D41311P	19		AE0304	07	115-199		
D41879P	12		0172	22 GA	D41311P	23		AE0304	07	115-199		
D41879P	13		0173	22 GA	D41311P	24		AE0304	07	115-199		
D41879P	14		0174	22 GA	D41311P	25		AE0304	29	001-099		
D41879P	14		0174	22 GA	D41311P	25		AE0304	07	115-199		
D41879P	44		0177	24 GK	D41905P	28		AE0201	35	001-099		
D41879P	16		0185	24 GK	D41473P	54		AP0036	21	ALL		
D41879P	17		0187	24 GK	D41475P	4		AP0036	02	001-099		
D41879P	18		0188	24 GK	D41637P	7		AP0037	36	115-199		
D41879P	20		0190	24 GK	D41475P	5		AP0036	02	115-199		
D41879P	21		2009B	24 GL	D41319P	23		AE0403	12	115-199		
D41879P	22		2009R	24 GL	D41319P	24		AE0403	12	115-199		
D41879P	8		5041B	24 G2	D41097P	43		AE0203	21	002		
D41879P	7		5041R	24 G2	D41097P	42		AE0203	21	002		
D41879P	6		5041Z		D41097P	41		AE0203	21	002		
AE0402	39	W2241	L2	DISC BKT-E4-2 SHELF DISC								
D42023P	20		0031	24 GK	D40523J	31		AP0001	15	001-099		
D42023P	31		0031	24 GK	D40523J	31		AP0001	15	115-199		
D42023P	13		0041	22 GA	D40523J	25		AP0001	15	115-199		
D42023P	1		2508B	24 G2	D40523J	1		AP0001	15	115-199		
D42023P	2		2508R	24 G2	D40523J	2		AP0001	15	115-199		
D42023P	3		2508Z		D40523J	3		AP0001	15	115-199		
D42023P	4		2509B	24 G2	D40523J	4		AP0001	15	001-099		
D42023P	5		2509R	24 G2	D40523J	5		AP0001	15	001-099		
D42023P	6		2509Z		D40523J	6		AP0001	15	001-099		
AE0402	40	W4204	L2B	DISC BKT-E4-2 SHELF DISC								
D41628P	11		0009	22 GA	D41618P	29		AE0304	29	115-199		
D41628P	12		0010	22 GA	D41618P	30		AE0304	29	115-199		
D41628P	13		0011	22 GA	D41618P	31		AE0304	29	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 10

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0402	40	W4204	L2B	DISC BKT-E4-2 SHELF DISC (continued)							
D41628P	14		0012	22 GA	D41618P	32		AE0304	29	115-199	
D41628P	15		0013	22 GA	D41618P	33		AE0304	29	115-199	
D41628P	33		0044	22 GA	D40120P	9		AA1715	03	ALL	
D41628P	34		0045	22 GA	D40120P	10		AA1715	03	ALL	
D41628P	35		0046	22 GA	D40142J	12		AA1705	04	ALL	
D41628P	36		0047	22 GA	D40142J	13		AA1705	04	ALL	
D41628P	4		0183	22 GA	D41618P	16		AE0304	07	001-099	
D41628P	4		0183	22 GA	D41618P	37		AE0304	29	115-199	
D41628P	3		0184	22 GA	D41618P	15		AE0304	07	001-099	
D41628P	3		0184	22 GA	D41618P	36		AE0304	29	115-199	
AE0402	41	W4210	S2	DISC BKT-E4-2 SHELF DISC							
D41734P	18		0017	22 GA	D41986P	2		AP0054	05	001-099	
D41734P	35		0054	22 GA	D41686P	12		AE0604	09	115-199	
D41734P	36		0055	22 GA	D41686P	13		AE0604	09	115-199	
D41734P	45		0100	22 GA	D41686P	15		AE0604	09	115-199	
D41734P	47		0103	22 GA	D40006J	40		AC0880	15	001-099	
D41734P	47		0103	22 GA	D41958P	CAP	Y	AP0036	13	115-199	
D41734P	48		0105	22 GA	D40006J	41		AC0880	15	001-099	
D41734P	48		0105	22 GA	D41986P	3		AP0054	05	115-199	
D41734P	49		0107	22 GA	D40006J	42		AC0880	15	001-099	
D41734P	49		0107	22 GA	D42000P	19		AP0050	09	115-199	
D41734P	50		0108	22 GA	D42000P	20		AP0050	09	ALL	
D41734P	52		0111	22 GA	D41958P	45		AP0036	13	001-099	
D41734P	33		0158	20 GA	D40006J	1		AC0880	15	115-199	
D41734P	45		2507B	22 GU	D40006J	1		AC0880	15	001-099	
D41734P	54		2507R	22 GU	D40006J	2		AC0880	15	001-099	
D41734P	55		2507Z		D40006J	4		AC0880	15	001-099	
D41734P	46		2508B	20 GU	D40006J	2		AC0880	15	115-199	
D41734P	54		2508R	20 GU	D40006J	3		AC0880	15	115-199	
D41734P	55		2508Z		D40006J	4		AC0880	15	115-199	
AE0402	42	W2354	R1	DISC BKT-E4-2 SHELF DISC							
D40704P	5		0025	22 GA	D40824P	24		AP0011	14	115-199	
D40704P	11		0601	22 GA	D40824P	20		AP0011	14	115-199	
D40704P	12		0602	22 GA	D40618P	36		AP0011	13	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 11

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0402	45	W2244	R1	DISC BKT-E4-2 SHELF DISC							
D40892P	9		0009	22 GA	D40286P	9		AP0006	09	ALL	
D40892P	10		0010	22 GA	D40286P	10		AP0006	09	ALL	
D40892P	13		0609	20 GA	D41122P	13		AP0037	09	115-199	
D40892P	14		0610	20 GA	D40894P	13		AE0502	02	115-199	
AE0402	46	W4234	S2	DISC BKT-E4-2 SHELF DISC							
D41774P	14		0011	22 GA	D41358J	19		AD0880	03	115-199	
D41774P	16		0014	22 GA	D41940P	9		AP0054	09	115-199	
D41774P	20		0024	24 GK	D42008P	10		AP0037	41	115-199	
D41774P	12		2503B	22 GU	D41358J	17		AD0880	03	115-199	
D41774P	11		2503R	22 GU	D41358J	16		AD0880	03	115-199	
D41774P	13		2503Z		D41358J	18		AD0880	03	115-199	
AE0402	47	W2066	L*	DISC BKT-E4-2 SHELF DISC							
D40584P	CAP	Y	0130	24 GK	D41854P	3		AP0037	47	ALL	
D40584P	38		0131	24 GK	D41864P	4		AE0501	22	001-099	
D40584P	12		0240	24 GK	D40874P	18		AP0036	17	ALL	
D40584P	45		0430	22 GA	D41870P	4		AP0033	23	ALL	
D40584P	6		0532	20 GA	D03544	CAP	Y	M10050		ALL	
D40584P	7		0533	20 GA	D03544	CAP	Y	M10050		ALL	
D40584P	46		0534	20 GA	D03503	CAP	Y	M10056		001-099	
D40584P	46		0534	20 GA	D03500	CAP	Y	M10063		115-199	
D40584P	47		0535	20 GA	D03503	CAP	Y	M10056		001-099	
D40584P	47		0535	20 GA	D03500	CAP	Y	M10063		115-199	
D40584P	53		0537	20 GA	D03538	CAP	Y	M10259		ALL	
D40584P	54		0538	20 GA	D03702	CAP	Y	M10398		ALL	
D40584P	55		0539	20 GA	D03538	CAP	Y	M10259		001-099	
D40584P	55		0539	20 GA	D02344	CAP	Y	M00013		115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0402

Page 12 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0403	02	W1163	L2	DISC BKT-E4-3 SHELF DISC								
D41689J	19		5021B	24 G2	D41319J	16		AE0403	12	115-199		
D41689J	20		5021R	24 G2	D41319J	17		AE0403	12	115-199		
D41689J	21		5021Z		D41319J	18		AE0403	12	115-199		
AE0403	02	W4063	L2	DISC BKT-E4-3 SHELF DISC								
D41689P	26		5004B	24 G2	D41685P	26		AE0601	16	115-199		
D41689P	27		5004R	24 G2	D41685P	27		AE0601	16	115-199		
D41689P	28		5004Z		D41685P	28		AE0601	16	115-199		
AE0403	07	W4477	S2	DISC BKT-E4-3 SHELF DISC								
D41453P	19		0013	24 GK	D41455J	3		AE0404	01	001-099		
D41453P	25		0059	24 GK	D41455J	13		AE0404	01	001-099		
D41453P	38		0084	22 GA	D41497P	13		AP0036	12	115-199		
D41453P	39		0085	22 GA	D41739P	19		AP0037	29	115-199		
D41453P	52		0117	24 GK	D41431P	1		AE0202	10	115-199		
D41453P	53		0122	24 GK	D41433P	CAP	Y	AE0203	03	115-199		
D41453P	46		0126	24 GK	D41429P	27		AE0201	32	115-199		
D41453P	1		0133	24 GK	D41497P	26		AP0036	12	ALL		
D41453P	2		0134	24 GK	D41429P	28		AE0201	32	115-199		
D41453P	37		0135	24 GK	D41739P	34		AP0037	29	ALL		
D41453P	40		0136	24 GK	D41433P	41		AE0203	03	115-199		
D41453P	10		0156	22 GA	D41739P	15		AP0037	29	001-099		
D41453P	54		0189	22 GA	D41455J	26		AE0404	01	001-099		
D41453P	28		0224	22 GA	D41059P	42		AP0051	03	001-008, 010-099		
D41453P	28		0224	22 GA	D41059P	43		AP0051	03	009		
D41453P	22		0231	22 GA	D41455J	25		AE0404	01	001-099		
D41453P	18		2011B	22 GB	D41455J	2		AE0404	01	001-099		
D41453P	17		2011R	22 GB	D41455J	1		AE0404	01	001-099		
D41453P	45		5014B	24 G2	D41443P	28		AE0303	08	001-099		
D41453P	44		5014R	24 G2	D41443P	27		AE0303	08	001-099		
D41453P	41		5014Z		D41443P	29		AE0303	08	001-099		
AE0403	09	W2663	L2	DISC BKT-E4-3 SHELF DISC								
D42033P	9		0009	20 GA	D41733P	9				001-099		
D42033P	10		0010	20 GA	D41733P	10				001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0403

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0403	12	W1163	L2	DISC BKT-E4-3 SHELF DISC							
D41319J	16		5021B	24 G2	D41689J	19		AE0403	02	115-199	
D41319J	17		5021R	24 G2	D41689J	20		AE0403	02	115-199	
D41319J	18		5021Z		D41689J	21		AE0403	02	115-199	
AE0403	12	W4471	L2	DISC BKT-E4-3 SHELF DISC							
D41319P	6		0036	24 GK	D41317P	24		AE0402	07	115-199	
D41319P	19		0152	24 GK	D41309P	48		AE0303	05	001-099	
D41319P	20		0162	24 GK	D41475P	7		AP0036	02	001-099	
D41319P	20		0162	24 GK	D41099P	30		AE0204	20	115-199	
D41319P	21		0163	24 GK	D41099P	31		AE0204	20	115-199	
D41319P	22		0164	24 GK	D41099P	32		AE0204	20	115-199	
D41319P	18		0178	24 GK	D41309P	47		AE0303	05	115-199	
D41319P	23		2009B	24 GL	D41879P	21		AE0402	38	115-199	
D41319P	24		2009R	24 GL	D41879P	22		AE0402	38	115-199	
AE0403	14	W1163	L2	DISC BKT-E4-3 SHELF DISC							
D41371J	17		0418	24 GK	TB0141Z	4	BJ			115-199	
AE0403	14	W4473	R2	DISC BKT-E4-3 SHELF DISC							
D41371P	17		0078	24 GK	D41361P	15		AE0303	36	115-199	
D41371P	10		0117	24 GK	D41909P	11		AP0037	20	001-099	
D41371P	10		0117	24 GK	D41369P	55		AE0402	32	115-199	
D41371P	11		0120	24 GK	D41355P	35		AE0302	41	115-199	
AE0403	15	W2358	S1	DISC BKT-E4-3 SHELF DISC							
D40734P	5		0003	22 GA	D40622P	3		AP0011	05	115-199	
D40734P	6		0004	22 GA	D40622P	24		AP0011	05	115-199	
AE0403	18	W2354	R1	DISC BKT-E4-3 SHELF DISC							
D40672P	7		0040	22 GA	D40618P	12		AP0011	13	115-199	
D40672P	6		0058	22 GA	D40618P	2		AP0011	13	115-199	
D40672P	10		0640	18 GA	D40824P	34		AP0011	14	115-199	
AE0403	23	W2351	N2	DISC BKT-E4-3 SHELF DISC							
D41541P	17		0045	24 GK	D00333	50		M00051		115-199	
D41541P	51		0055	24 GK	D00471	12		M00033		001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0403

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0403	32	W2350	L1	DISC BKT-E4-3 SHELF DISC								
D40686P	2		0002	22	GA	D40610P	2		AP0011	03	115-199	
D40686P	3		0717	22	GA	D40610P	28		AP0011	03	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0403

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY		To Equip	Term	Type	Matewith	Pos	Effectivity
AE0404	01	W4477	S2	DISC BKT-E4-4 SHELF DISC							
D41455J	3		0013	24	GK	D41453P	19		AE0403	07	001-099
D41455J	13		0059	24	GK	D41453P	25		AE0403	07	001-099
D41455J	8		0098	24	GK	D41443P	39		AE0303	08	001-099
D41455J	26		0189	22	GA	D41453P	54		AE0403	07	001-099
D41455J	25		0231	22	GA	D41453P	22		AE0403	07	001-099
D41455J	2		2011B	22	GB	D41453P	18		AE0403	07	001-099
D41455J	1		2011R	22	GB	D41453P	17		AE0403	07	001-099
AE0404	07	W3576	R1	DISC BKT-E4-4 SHELF DISC							
D41702J	2		0029	22	GA	D40882J	29		D40882P		001-099
D41702J	3		0031	22	GA	D40882J	30		D40882P		001-099
D41702J	9		0050	22	GA	D41474P	23		AP0034	16	115-199
D41702J	6		3001B	22	GC	D40882J	28		D40882P		001-099
D41702J	5		3001R	22	GC	D40882J	26		D40882P		001-099
D41702J	7		3001Y	22	GC	D40882J	27		D40882P		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section AE0404

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0501	01	W4202	L2A	DISC BKT-E5-1 SHELF DISC								
D41652P	34		0059	22 GA	D41698P	29		AE0402	08	001-099		
D41652P	34		0059	22 GA	D41698P	39		AE0402	08	115-199		
D41652P	19		0066	20 GA	D40346J	30		AC1090	19	ALL		
D41652P	35		0069	22 GA	D41612P	47		AP0036	28	ALL		
D41652P	40		0095	22 GA	D41612P	48		AP0036	28	ALL		
D41652P	41		0096	22 GA	D41612P	49		AP0036	28	ALL		
AE0501	03	W4477	S2	DISC BKT-E5-1 SHELF DISC								
D41459P	9		0081	24 GK	D41739P	17		AP0037	29	115-199		
D41459P	10		0082	24 GK	D41739P	18		AP0037	29	115-199		
D41459P	CAP	Y	0138	24 GK	D41451P	54		AE0402	12	001-099		
D41459P	20		0139	24 GK	D41461P	3		AE0502	28	115-199		
D41459P	22		0140	24 GK	D41461P	2		AE0502	28	ALL		
D41459P	12		0192	22 GA	D41497P	36		AP0036	12	115-199		
D41459P	14		0204	24 GK	D41461P	8		AE0502	28	001-099		
D41459P	15		0205	24 GK	D41461P	9		AE0502	28	001-099		
D41459P	16		0206	24 GK	D41461P	10		AE0502	28	001-099		
D41459P	17		0207	24 GK	D41461P	11		AE0502	28	001-099		
D41459P	18		0208	24 GK	D41461P	15		AE0502	28	001-099		
D41459P	19		0209	24 GK	D41461P	16		AE0502	28	001-099		
D41459P	21		0210	22 GA	D41497P	3		AP0036	12	001-099		
D41459P	9		0222	24 GK	D41443P	34		AE0303	08	001-099		
D41459P	26		5016B	24 G2	D41461P	13		AE0502	28	115-199		
D41459P	27		5016R	24 G2	D41461P	12		AE0502	28	115-199		
D41459P	28		5016Z		D41461P	14		AE0502	28	115-199		
D41459P	32		5018B	24 G2	D41461P	37		AE0502	28	115-199		
D41459P	33		5018R	24 G2	D41461P	38		AE0502	28	115-199		
D41459P	34		5018Z		D41461P	39		AE0502	28	115-199		
AE0501	04	W4300	L1	DISC BKT-E5-1 SHELF DISC								
D41898P	16		0602	20 GA	D40288J	32		AC0880	07	ALL		
D41898P	17		0603	20 GA	D40288J	38		AC0880	07	ALL		
D41898P	21		2003B	20 GB	D40288J	21		AC0880	07	ALL		
D41898P	26		2003R	20 GB	D40288J	26		AC0880	07	ALL		
AE0501	05	W4473	R2	DISC BKT-E5-1 SHELF DISC								
D41377P	43		0019	24 GK	D41491P	14		AP0051	05	001-099		
D41377P	44		0020	24 GK	D41491P	13		AP0051	05	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0501

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0501	05	W4473	R2	DISC BKT-E5-1 SHELF DISC (continued)							
D41377P	19		0056	24 GK	D41379P	33		AE0502	03	001-099	
D41377P	14		0123	24 GK	D41347P	31		AE0202	02	115-199	
D41377P	23		0126	24 GK	D41489P	19		AP0050	12	001-099	
D41377P	15		0136	24 GK	D41491P	32		AP0051	05	ALL	
D41377P	21		0138	22 GA	D41883P	1		AE0502	31	001-099	
D41377P	22		0139	22 GA	D41883P	2		AE0502	31	001-099	
D41377P	8		0170	24 GK	D41883P	23		AE0502	31	115-199	
D41377P	27		0177	22 GA	D41339P	15		AE0201	38	115-199	
D41377P	20		0262	22 GA	D41381P	13		AE0503	16	001-099	
D41377P	21		4001B	24 G4	D41883P	17		AE0502	31	115-199	
D41377P	19		4001G	24 G4	D41883P	15		AE0502	31	115-199	
D41377P	22		4001R	24 G4	D41883P	18		AE0502	31	115-199	
D41377P	20		4001Y	24 G4	D41883P	16		AE0502	31	115-199	
D41377P	23		4001Z		D41883P	19		AE0502	31	115-199	
AE0501	07	W4208	R1B	DISC BKT-E5-1 SHELF DISC							
D41696P	22		0043	20 GA	D40342J	22		AC1090	21	115-199	
AE0501	08	W2634	L1	DISC BKT-E5-1 SHELF DISC							
D41924P	11		0021	20 GA	D40206P	8		AP0036	10	115-199	
D41924P	12		0022	20 GA	D40206P	9		AP0036	10	115-199	
D41924P	13		0025	20 GA	D41942P	7		AP0070	04	115-199	
D41924P	14		0026	20 GA	D41942P	8		AP0070	04	115-199	
AE0501	10	W2350	L1	DISC BKT-E5-1 SHELF DISC							
D41882P	10		0205	18 GA	D40610P	23	18	AP0011	03	115-199	
D41882P	5		0703	22 GA	D40612P	25		AP0011	04	115-199	
D41882P	4		0705	22 GA	D40612P	39		AP0011	04	115-199	
D41882P	7		0706	22 GA	D40612P	40		AP0011	04	115-199	
AE0501	11	W2250	S1	DISC BKT-E5-1 SHELF DISC							
D41894P	4		0008	16 GA	D40908P	10		AE0502	27	ALL	
D41894P	10		0017	18 GA	D40246P	10		AP0006	05	ALL	
D41894P	3		0603	20 GA	D40246P	18		AP0006	05	ALL	
D41894P	6		0607	20 GA	D40908P	5		AE0502	27	115-199	
D41894P	7		0608	20 GA	D40908P	6		AE0502	27	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0501

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0501	12	W2240	L2	DISC BKT-E5-1 SHELF DISC								
D41752P	5		0601	22 GA	D40284P	CAP	Y	AP0006	08	001-002, 115-199		
D41752P	6		0602	22 GA	D40284P	6		AP0006	08	115-199		
D41752P	7		0603	22 GA	D40284P	7		AP0006	08	115-199		
D41752P	8		0604	22 GA	D40284P	8		AP0006	08	115-199		
D41752P	9		0605	22 GA	D40284P	9		AP0006	08	115-199		
D41752P	10		0606	20 GA	D40284P	10		AP0006	08	ALL		
D41752P	11		0607	20 GA	D40284P	11		AP0006	08	115-199		
D41752P	12		0608	20 GA	D40284P	12		AP0006	08	115-199		
D41752P	13		0609	20 GA	D40284P	13		AP0006	08	115-199		
AE0501	14	W4204	L2B	DISC BKT-E5-1 SHELF DISC								
D41630P	12		0052	22 GA	D41618P	6		AE0304	07	001-099		
D41630P	12		0052	22 GA	D41618P	6		AE0304	29	115-199		
AE0501	15	W2251	L2	DISC BKT-E5-1 SHELF DISC								
D42069P	3		0021	22 GA	D40035J	22		AP0003	12	115-199		
D42069P	6		0029	22 GA	D40035J	14		AP0003	12	115-199		
D42069P	7		0030	22 GA	D40035J	15		AP0003	12	115-199		
D42069P	4		0031	22 GA	D42055J	5		AP0003	19	115-199		
D42069P	5		0032	22 GA	D42055J	4		AP0003	19	115-199		
D42069P	8		0050	22 GA	D42055J	8		AP0003	19	115-199		
D42069P	11		0051	22 GA	D42055J	9		AP0003	19	115-199		
D42069P	10		0052	22 GA	D42055J	7		AP0003	19	115-199		
D42069P	9		0053	22 GA	D42055J	6		AP0003	19	115-199		
D42069P	13		5010B	24 G2	D40035J	37		AP0003	12	001-099		
D42069P	12		5010R	24 G2	D40035J	36		AP0003	12	001-099		
D42069P	14		5010Z		D40035J	38		AP0003	12	001-099		
AE0501	16	W4471	L2	DISC BKT-E5-1 SHELF DISC								
D41325P	8		0029	24 GK	D41317P	15		AE0402	07	115-199		
D41325P	34		0051	24 GK	D41317P	25		AE0402	07	115-199		
D41325P	35		0052	24 GK	D41317P	26		AE0402	07	115-199		
D41325P	39		0086	24 GK	D41317P	40		AE0402	07	115-199		
D41325P	23		0104	22 GA	D41329P	5		AE0503	17	115-199		
D41325P	45		0112	22 GA	D41481P	18		AP0051	01	ALL		
D41325P	47		0135	22 GA	D41099P	15		AE0204	20	115-199		
D41325P	48		0136	22 GA	D41099P	16		AE0204	20	115-199		
D41325P	49		0137	22 GA	D41099P	17		AE0204	20	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0501

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0501	16	W4471	L2	DISC BKT-E5-1 SHELF DISC (continued)							
D41325P	50	Y	0138	22 GA	D41099P	18		AE0204	20	115-199	
D41325P	CAP		0160	24 GK	D41317P	8		AE0402	07	115-199	
D41325P	7		0327	22 GA	D43003P	1		AE0201	03	003-099	
D41325P	19		2004B	24 GL	D41477P	19		AP0050	02	115-199	
D41325P	18		2004R	24 GL	D41477P	18		AP0050	02	115-199	
D41325P	21		2005B	24 GL	D41477P	21		AP0050	02	115-199	
D41325P	20		2005R	24 GL	D41477P	20		AP0050	02	115-199	
D41325P	15		5020B	24 G2	D41093P	13		AE0201	37	115-199	
D41325P	16		5020R	24 G2	D41093P	11		AE0201	37	115-199	
D41325P	17		5020Z		D41093P	12		AE0201	37	115-199	
D41325P	52		5044B	24 G2	D41093P	36		AE0201	37	115-199	
D41325P	51		5044R	24 G2	D41093P	35		AE0201	37	115-199	
D41325P	53		5044Z		D41093P	37		AE0201	37	115-199	
AE0501	17	W4471	L2	DISC BKT-E5-1 SHELF DISC							
D42187P	4		0142	22 GA	D41099P	22		AE0204	20	115-199	
D42187P	18		0253	22 GA	D41473P	38		AP0036	21	001-099	
D42187P	39		0281	24 GK	D41329P	3		AE0503	17	001-099	
D42187P	22		0285	22 GA	D41301P	12		AE0301	08	001-099	
D42187P	4		2016B	24 GL	D41327P	12		AE0502	16	001-099	
D42187P	3		2016R	24 GL	D41327P	11		AE0502	16	001-099	
AE0501	20	W4500	L1	DISC BKT-E5-1 SHELF DISC							
D41742P	7		0037	20 GA	D40542P	7		AP0036	30	115-199	
D41742P	26		0601	20 GA	D40542P	5		AP0036	30	115-199	
D41742P	27		0602	20 GA	D40542P	8		AP0036	30	115-199	
D41742P	28		0603	20 GA	D40542P	9		AP0036	30	115-199	
D41742P	3		0616	20 GA	D40392P	26		AP0031	04	ALL	
D41742P	5		0617	20 GA	D40392P	30		AP0031	04	ALL	
AE0501	21	W4212	L2	DISC BKT-E5-1 SHELF DISC							
D41654P	19		0015	22 GA	D42076J	11		AD0880	04	001-099	
D41654P	17		0017	22 GA	D40944P	4		AW2156	01	001-099	
D41654P	17		0017	22 GA	D40944J	4		AW2156	01	115-199	
D41654P	18		0018	22 GA	D40944P	5		AW2156	01	001-099	
D41654P	18		0018	22 GA	D40944J	5		AW2156	01	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0501

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To					Effectivity	
	Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos			
I	AE0501		22	W2066	L*	DISC BKT-E5-1 SHELF DISC								
	D41864P		4		0131	24	GK	D40584P	38		AE0402	47	001-099	
	D41864P		37		0238	24	GK	D41854P	2		AP0037	47	001-099	
	D41864P		35		0579	22	GA	TB0112X	B015	BJ			001-099	
	D41864P		36		0580	22	GA	TB0112X	A015	BJ			001-099	
	AE0501		23	W2650	A2	DISC BKT-E5-1 SHELF DISC								
	D41912P		2		0066	22	GA	D41662P	25		AE0602	07	001-099	
	AE0501		25	W4018	A1	DISC BKT-E5-1 SHELF DISC								
	D42120P		12		0013	20	GA	D40258P	2		AA1705	09	001-099	
	D42120P		13		0014	20	GA	D40258P	14		AA1705	09	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0501

Page 5 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0502	02	W2244	R1	DISC BKT-E5-2 SHELF DISC							
D40894P	5		0001	22 GA	D40286P	CAP	Y	AP0006	09	001-002, 115-199	
D40894P	6		0002	22 GA	D40286P	6		AP0006	09	ALL	
D40894P	13		0610	20 GA	D40892P	14		AE0402	45	115-199	
AE0502	03	W4473	R2	DISC BKT-E5-2 SHELF DISC							
D41379P	22		0044	24 GK	D41369P	32		AE0402	32	115-199	
D41379P	23		0045	24 GK	D41369P	33		AE0402	32	115-199	
D41379P	32		0053	24 GK	D41369P	41		AE0402	32	115-199	
D41379P	33		0056	24 GK	D41377P	19		AE0501	05	001-099	
D41379P	33		0056	24 GK	D41369P	43		AE0402	32	115-199	
D41379P	38		0072	22 GA	D41347P	21		AE0202	02	001-099	
D41379P	38		0072	24 GK	D41347P	21		AE0202	02	115-199	
D41379P	19		0099	24 GK	D41347P	51		AE0202	02	115-199	
D41379P	48		0116	24 GK	D41369P	54		AE0402	32	115-199	
D41379P	50		0125	24 GK	D41491P	30		AP0051	05	115-199	
D41379P	51		0126	24 GK	D41489P	19		AP0050	12	115-199	
D41379P	53		0128	24 GK	D41381P	1		AE0503	16	ALL	
D41379P	55		0129	24 GK	D41381P	11		AE0503	16	115-199	
D41379P	28		2001B	24 GL	D41489P	2		AP0050	12	115-199	
D41379P	27		2001R	24 GL	D41489P	1		AP0050	12	115-199	
D41379P	29		2002B	24 GL	D41369P	27		AE0402	32	115-199	
D41379P	30		2002R	24 GL	D41369P	28		AE0402	32	115-199	
D41379P	25		5015B	24 G2	D41345P	36		AE0202	08	115-199	
D41379P	24		5015R	24 G2	D41345P	35		AE0202	08	115-199	
D41379P	26		5015Z		D41345P	37		AE0202	08	115-199	
D41379P	46		5037B	24 G2	D41491P	24		AP0051	05	115-199	
D41379P	45		5037R	24 G2	D41491P	23		AP0051	05	115-199	
D41379P	47		5037Z		D41491P	25		AP0051	05	115-199	
AE0502	04	W2644	L2B	DISC BKT-E5-2 SHELF DISC							
D42510P	13		0009	20 GA	D40442J	17		AW2240	02	001-099	
D42510P	14		0027	20 GA	D41818J	7		AD1090	20	001-099	
AE0502	05	W2644	L2B	DISC BKT-E5-2 SHELF DISC							
D42512P	4		0028	20 GA	D43010J	4		AD1090	18	001-099	
D42512P	5		0029	20 GA	D43010J	5		AD1090	18	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0502

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0502	09	W2078	S*	DISC BKT-E5-2 SHELF DISC								
D40600P	3		0344	20 GA	D41850P	42		AP0036	14	115-199		
D40600P	12		0345	22 GA	D41850P	43		AP0036	14	001-099		
D40600P	4		0345	20 GA	D41850P	43		AP0036	14	115-199		
D40600P	1		0531	22 GA	D40570P	11		AP0037	06	001-099		
D40600P	5		0532	24 GK	D40570P	12		AP0037	06	001-099		
AE0502	10	W4216	R2A	DISC BKT-E5-2 SHELF DISC								
D41730P	11		0106	22 GA	D40360J	19		AD1090	10	115-199		
AE0502	12	W4502	R1	DISC BKT-E5-2 SHELF DISC								
D40492P	28		0602	22 GA	D41750P	28		AE0503	07	115-199		
D40492P	29		0603	22 GA	D41750P	29		AE0503	07	115-199		
D40492P	5		0607	22 GA	D41316P	5		AP0032	05	ALL		
D40492P	31		0611	22 GA	D41318P	31		AP0031	01	ALL		
AE0502	13	W2253	R2	DISC BKT-E5-2 SHELF DISC								
D42095P	8		0050	22 GA	D41041J	3		AP0003	16	ALL		
D42095P	20		0051	22 GA	D41041J	4		AP0003	16	ALL		
D42095P	29		2509B	24 G2	D41041J	34		AP0003	16	115-199		
D42095P	28		2509R	24 G2	D41041J	33		AP0003	16	115-199		
D42095P	30		2509Z		D41041J	35		AP0003	16	115-199		
D42095P	11		5020B	24 G2	D41041J	27		AP0003	16	001-099		
D42095P	12		5020R	24 G2	D41041J	28		AP0003	16	001-099		
D42095P	13		5020Z		D41041J	29		AP0003	16	001-099		
D42095P	27		5024B	24 G2	D40099J	40		AP0003	13	001-099		
D42095P	26		5024R	24 G2	D40099J	39		AP0003	13	001-099		
D42095P	25		5024Z		D40099J	41		AP0003	13	001-099		
D42095P	29		5025B	24 G2	D41041J	34		AP0003	16	001-099		
D42095P	28		5025R	24 G2	D41041J	33		AP0003	16	001-099		
D42095P	30		5025Z		D41041J	35		AP0003	16	001-099		
D42095P	33		5026B	24 G2	D42083P	2		AE0203	26	001-099		
D42095P	32		5026R	24 G2	D42083P	1		AE0203	26	001-099		
D42095P	34		5026Z		D42083P	3		AE0203	26	001-099		
AE0502	16	W4471	L2	DISC BKT-E5-2 SHELF DISC								
D41327P	9		0210	22 GA	D41095P	CAP	Y	AE0202	28	115-199		
D41327P	12		2016B	24 GL	D42187P	4		AE0501	17	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0502

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0502	16	W4471	L2	DISC BKT-E5-2 SHELF DISC (continued)								
D41327P	11		2016R	24 GL	D42187P	3		AE0501	17	001-099		
AE0502	17	W2646	R2A	DISC BKT-E5-2 SHELF DISC								
D42516P	23		0013	20 GA	D40084J	18		AW1240	01	001-099		
D42516P	21		0016	20 GA	D41812J	16		AC1090	01	001-099		
D42516P	22		0017	20 GA	D41812J	17		AC1090	01	001-099		
D42516P	24		0027	20 GA	D42189J	5		AC1090	03	001-099		
AE0502	23	W4302	R1	DISC BKT-E5-2 SHELF DISC								
D40398P	24		0004	20 GA	D40290J	29		AD0880	23	ALL		
D40398P	25		0005	20 GA	D40290J	30		AD0880	23	ALL		
D40398P	7		2003B	20 GB	D40290J	21		AD0880	23	ALL		
D40398P	13		2003R	20 GB	D40290J	23		AD0880	23	ALL		
AE0502	24	W4208	R1B	DISC BKT-E5-2 SHELF DISC								
D41694P	16		0038	22 GA	D40342J	20		AC1090	21	ALL		
D41694P	33		0041	22 GA	D41692P	12		AP0033	28	ALL		
D41694P	34		0042	22 GA	D41692P	13		AP0033	28	ALL		
D41694P	21		0043	20 GA	D40076J	10		AC0880	21	001-099		
AE0502	25	W2642	L2A	DISC BKT-E5-2 SHELF DISC								
D42518P	7		0001	20 GA	D40082J	17		AW1240	02	001-099		
AE0502	26	W2070	R*	DISC BKT-E5-2 SHELF DISC								
D40598P	1		0030	24 GK	D41058P	19		AE0402	22	115-199		
D40598P	30		0104	24 GK	D03710	CAP	Y	M10191		001-099		
D40598P	30		0104	24 GK	D03710	5		M10191		115-199		
D40598P	45		0145	24 GK	D41058P	6		AE0402	22	115-199		
D40598P	27		0331	24 GK	D41856P	27		AP0037	33	001-099		
D40598P	6		0484	24 GK	D41058P	39		AE0402	22	001-099		
AE0502	27	W2250	S1	DISC BKT-E5-2 SHELF DISC								
D40908P	10		0008	16 GA	D41894P	4		AE0501	11	ALL		
D40908P	7		0031	18 GA	D40246P	8		AP0006	05	ALL		
D40908P	3		0604	20 GA	D40246P	19		AP0006	05	ALL		
D40908P	5		0607	20 GA	D41894P	6		AE0501	11	115-199		
D40908P	6		0608	20 GA	D41894P	7		AE0501	11	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0502

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0502	27	W2250	S1	DISC BKT-E5-2 SHELF DISC (continued)								
D40908P	8		0609	20 GA	D41896P	6		AE0503	13	115-199		
D40908P	11		0610	20 GA	D41896P	8		AE0503	13	115-199		
D40908P	12		0611	20 GA	D41896P	9		AE0503	13	115-199		
AE0502	28	W4477	S2	DISC BKT-E5-2 SHELF DISC								
D41461P	3		0139	24 GK	D41459P	20		AE0501	03	115-199		
D41461P	2		0140	24 GK	D41459P	22		AE0501	03	ALL		
D41461P	21		0177	24 GK	D41497P	31		AP0036	12	115-199		
D41461P	22		0181	22 GA	D41433P	46		AE0203	03	115-199		
D41461P	23		0182	22 GA	D41433P	47		AE0203	03	115-199		
D41461P	8		0204	24 GK	D41459P	14		AE0501	03	001-099		
D41461P	9		0205	24 GK	D41459P	15		AE0501	03	001-099		
D41461P	10		0206	24 GK	D41459P	16		AE0501	03	001-099		
D41461P	11		0207	24 GK	D41459P	17		AE0501	03	001-099		
D41461P	15		0208	24 GK	D41459P	18		AE0501	03	001-099		
D41461P	16		0209	24 GK	D41459P	19		AE0501	03	001-099		
D41461P	14		0228	24 GK	D41497P	35		AP0036	12	001-099		
D41461P	13		5016B	24 G2	D41459P	26		AE0501	03	115-199		
D41461P	12		5016R	24 G2	D41459P	27		AE0501	03	115-199		
D41461P	14		5016Z		D41459P	28		AE0501	03	115-199		
D41461P	37		5018B	24 G2	D41459P	32		AE0501	03	115-199		
D41461P	38		5018R	24 G2	D41459P	33		AE0501	03	115-199		
D41461P	39		5018Z		D41459P	34		AE0501	03	115-199		
AE0502	29	W2648	R2B	DISC BKT-E5-2 SHELF DISC								
D42520P	7		0001	20 GA	D40434J	15		AW2240	01	001-099		
AE0502	30	W2354	R1	DISC BKT-E5-2 SHELF DISC								
D40710P	9		0019	18 GA	D40618P	17	18	AP0011	13	115-199		
D40710P	7		0624	18 GA	D40824P	41		AP0011	14	115-199		
AE0502	31	W4473	R2	DISC BKT-E5-2 SHELF DISC								
D41883P	1		0138	22 GA	D41377P	21		AE0501	05	001-099		
D41883P	1		0138	22 GA	D41351P	44		AE0204	02	115-199		
D41883P	2		0139	22 GA	D41377P	22		AE0501	05	001-099		
D41883P	2		0139	22 GA	D41351P	45		AE0204	02	115-199		
D41883P	3		0140	22 GA	D41351P	46		AE0204	02	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0502

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0502	31	W4473	R2	DISC BKT-E5-2 SHELF DISC (continued)								
D41883P	4		0141	22	GA	D41351P	47		AE0204	02	115-199	
D41883P	5		0142	22	GA	D41351P	48		AE0204	02	115-199	
D41883P	6		0143	22	GA	D41351P	49		AE0204	02	115-199	
D41883P	11		0144	22	GA	D41351P	50		AE0204	02	115-199	
D41883P	31		0145	22	GA	D41351P	51		AE0204	02	115-199	
D41883P	23		0170	24	GK	D41377P	8		AE0501	05	115-199	
D41883P	24		0171	24	GK	D41381P	12		AE0503	16	ALL	
D41883P	40		0215	24	GK	D41909P	32		AP0037	20	ALL	
D41883P	17		4001B	24	G4	D41377P	21		AE0501	05	115-199	
D41883P	15		4001G	24	G4	D41377P	19		AE0501	05	115-199	
D41883P	18		4001R	24	G4	D41377P	22		AE0501	05	115-199	
D41883P	16		4001Y	24	G4	D41377P	20		AE0501	05	115-199	
D41883P	19		4001Z			D41377P	23		AE0501	05	115-199	
D41883P	25		5052B	24	G2	D41381P	14		AE0503	16	115-199	
D41883P	26		5052R	24	G2	D41381P	13		AE0503	16	115-199	
D41883P	27		5052Z			D41381P	15		AE0503	16	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0502

Page 5 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0503	01	W2080	A*	DISC BKT-E5-3 SHELF DISC							
D41868P	21		0027	22 GA	D40602P	14		AE0402	19	115-199	
D41868P	22		0028	22 GA	D40602P	15		AE0402	19	115-199	
D41868P	23		0029	22 GA	D40602P	9		AE0402	19	115-199	
D41868P	24		0030	22 GA	D40602P	10		AE0402	19	115-199	
D41868P	9		0033	20 GA	D03576	CAP	Y	M00001		001-099	
D41868P	9		0033	20 GA	D03506	CAP	Y	M10063		115-199	
D41868P	10		0034	20 GA	D03576	CAP	Y	M10324		115-199	
D41868P	11		0037	20 GA	D03714	CAP	Y	M10191		115-199	
AE0503	03	W4206	R2A	DISC BKT-E5-3 SHELF DISC							
D41656P	27		0040	22 GA	D40922P	7		AW1156	02	001-099	
D41656P	27		0040	22 GA	D40922J	7		AW1156	02	115-199	
D41656P	28		0041	22 GA	D41394J	22		AC0880	12	ALL	
D41656P	29		0042	20 GA	D41636P	10		AE0304	20	ALL	
AE0503	04	W2358	S1	DISC BKT-E5-3 SHELF DISC							
D41966P	8		0606	22 GA	D40622P	30		AP0011	05	115-199	
AE0503	05	W4477	S2	DISC BKT-E5-3 SHELF DISC							
D41463P	5		0038	24 GK	D41059P	5		AP0051	03	ALL	
D41463P	6		0039	24 GK	D41059P	6		AP0051	03	ALL	
D41463P	12		0141	24 GK	D41059P	34		AP0051	03	ALL	
D41463P	13		0193	22 GA	D41497P	35		AP0036	12	115-199	
D41463P	14		0218	24 GK	D41059P	41		AP0051	03	001-099	
D41463P	15		5028B	24 G2	D41059P	42		AP0051	03	115-199	
D41463P	14		5028R	24 G2	D41059P	41		AP0051	03	115-199	
D41463P	16		5028Z		D41059P	43		AP0051	03	115-199	
AE0503	06	W4504	A1	DISC BKT-E5-3 SHELF DISC							
D41900P	48		0056	22 GA	D41326P	11		AP0034	05	115-199	
D41900P	47		0060	22 GA	D41326P	12		AP0034	05	ALL	
D41900P	46	18	0062	18 GA	D40400P	11	18	AP0034	03	115-199	
D41900P	49		0601	20 GA	D41326P	5		AP0034	05	ALL	
D41900P	50		0602	20 GA	D41326P	6		AP0034	05	115-199	
D41900P	51		0606	20 GA	D40400P	1		AP0034	03	ALL	
D41900P	52		0607	20 GA	D40400P	12		AP0034	03	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0503

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0503	07	W4502	R1	DISC BKT-E5-3 SHELF DISC							
D41750P	16		0042	20 GA	D40394P	46		AP0032	04	ALL	
D41750P	17		0043	20 GA	D40394P	47		AP0032	04	001-099	
D41750P	26		0601	22 GA	D40394P	26		AP0032	04	ALL	
D41750P	28		0602	22 GA	D40492P	28		AE0502	12	115-199	
D41750P	29		0603	22 GA	D40492P	29		AE0502	12	115-199	
AE0503	08	W2362	C1	DISC BKT-E5-3 SHELF DISC							
D41892P	6		0106	22 GA	D40626P	6		AP0011	11	ALL	
D41892P	7		0107	22 GA	D40626P	7		AP0011	11	115-199	
D41892P	8		0108	22 GA	D40626P	8		AP0011	11	ALL	
AE0503	09	W4500	L1	DISC BKT-E5-3 SHELF DISC							
D41744P	14		0011	24 GK	D40542P	14		AP0036	30	001-099	
D41744P	11		0607	20 GA	D40542P	12		AP0036	30	115-199	
D41744P	12		0608	20 GA	D40542P	13		AP0036	30	115-199	
D41744P	8		0613	20 GA	D40392P	39		AP0031	04	ALL	
D41744P	9		0614	20 GA	D40392P	40		AP0031	04	ALL	
AE0503	10	W4218	R2A	DISC BKT-E5-3 SHELF DISC							
D41828P	10		0045	22 GA	D41180J	9				115-199	
AE0503	11	W2247	2S	DISC BKT-E5-3 SHELF DISC							
D42053P	1		0031	22 GA	D42165J	36		AP0003	09	001-099	
D42053P	1		0031	22 GA	D42165J	36		AP0003	09	115-199	
D42053P	2		0032	22 GA	D42165J	37		AP0003	09	115-199	
D42053P	3		0033	22 GA	D42165J	38		AP0003	09	115-199	
D42053P	4		0034	22 GA	D42165J	39		AP0003	09	115-199	
AE0503	13	W2250	S1	DISC BKT-E5-3 SHELF DISC							
D41896P	6		0609	20 GA	D40908P	8		AE0502	27	115-199	
D41896P	8		0610	20 GA	D40908P	11		AE0502	27	115-199	
D41896P	9		0611	20 GA	D40908P	12		AE0502	27	115-199	
AE0503	14	W2070	R*	DISC BKT-E5-3 SHELF DISC							
D40590P	4		0015	20 GA	D41470P	28		AP0034	09	ALL	
D40590P	16		0041	22 GA	D41058P	22		AE0402	22	115-199	
D40590P	29		0261	22 GA	D41470P	29		AP0034	09	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0503

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0503	15	W4475	C2	DISC BKT-E5-3 SHELF DISC							
D41419P	15		0055	24 GK	D41495P	11		AP0037	30	115-199	
D41419P	22		5010B	24 G2	D41395P	25		AE0203	23	001, 003-099	
D41419P	22		5010B	24 G2	D41395P	REF	JB	AE0203	23	002	
D41419P	21		5010R	24 G2	D41395P	26		AE0203	23	001, 003-099	
D41419P	21		5010R	24 G2	D41395P	REF	JB	AE0203	23	002	
D41419P	23		5010Z		D41395P	27		AE0203	23	001, 003-099	
D41419P	23		5010Z		D41395P	REF	JB	AE0203	23	002	
AE0503	16	W4473	R2	DISC BKT-E5-3 SHELF DISC							
D41381P	4		0029	24 GK	D41487P	8		AP0037	50	115-199	
D41381P	9		0081	22 GA	D41491P	21		AP0051	05	115-199	
D41381P	1		0128	24 GK	D41379P	53		AE0502	03	ALL	
D41381P	11		0129	24 GK	D41379P	55		AE0502	03	115-199	
D41381P	12		0171	24 GK	D41883P	24		AE0502	31	ALL	
D41381P	11		0261	22 GA	D41489P	10		AP0050	12	001-099	
D41381P	13		0262	22 GA	D41377P	20		AE0501	05	001-099	
D41381P	14		5052B	24 G2	D41883P	25		AE0502	31	115-199	
D41381P	13		5052R	24 G2	D41883P	26		AE0502	31	115-199	
D41381P	15		5052Z		D41883P	27		AE0502	31	115-199	
AE0503	17	W4471	L2	DISC BKT-E5-3 SHELF DISC							
D41329P	5		0104	22 GA	D41325P	23		AE0501	16	115-199	
D41329P	16		0165	22 GA	D41473P	52		AP0036	21	115-199	
D41329P	23		0271	22 GA	D41475P	38		AP0036	02	001-099	
D41329P	3		0281	24 GK	D42187P	39		AE0501	17	001-099	
AE0503	18	W4216	R2A	DISC BKT-E5-3 SHELF DISC							
D41658P	11		0103	22 GA	D42060P	29		AE0304	15	115-199	
D41658P	12		0104	22 GA	D40930P	26		AW2180	01	001-099	
D41658P	12		0104	22 GA	D40930J	24		AW2180	01	115-199	
D41658P	9		0117	22 GA	D40930J	28		AW2180	01	115-199	
AE0503	19	W4018	A1	DISC BKT-E5-3 SHELF DISC							
D41644P	2		0013	20 GA	D40258J	2		AA1705	09	115-199	
D41644P	4		0014	20 GA	D40258J	14		AA1705	09	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0503

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0600	01	W2354	R1	DISC BKT-E6 SHELF DISC							
D42212P	8		0062	20 GA	D40824P	5		AP0011	14	115-199	
D42212P	9		0514	22 GA	D40824P	6		AP0011	14	115-199	
D42212P	5		0644	22 GA	D40618P	45		AP0011	13	115-199	
D42212P	3		0645	22 GA	D40824P	3		AP0011	14	115-199	
AE0600	03	W2650	A2	DISC BKT-E6 SHELF DISC							
D41680P	44		0070	22 GA	D41660P	15		AE0402	21	001-099	
D41680P	23		0071	22 GA	D42080P	9		AP0036	03	001-099	
D41680P	30		2003B	24 GL	D41684P	12		AP0037	18	001-099	
D41680P	31		2003R	24 GL	D41684P	13		AP0037	18	001-099	
AE0600	04	W2700	R1	DISC BKT-E6 SHELF DISC							
D40170P	1		0007	22 GA	D40168P	1		AP0006	17	115-199	
D40170P	3		0009	20 GA	D40168P	3		AP0006	17	115-199	
D40170P	7		0601	20 GA	D40168P	2		AP0006	17	115-199	
D40170P	8		0602	20 GA	D40168P	6		AP0006	17	115-199	
D40170P	9		0603	20 GA	D41082P	7		AP0037	01	115-199	
D40170P	10		0604	20 GA	D40168P	8		AP0006	17	115-199	
D40170P	11		0605	20 GA	D40168P	9		AP0006	17	115-199	
AE0600	06	W2700	R1	DISC BKT-E6 SHELF DISC							
D40170P	1		0007	22 GA	D40168P	1		AP0006	17	001-099	
D40170P	3		0009	20 GA	D40168P	3		AP0006	17	001-099	
D40170P	12		0022	24 GK	D41082P	1		AP0037	01	001-099	
D40170P	13		0023	24 GK	D41082P	3		AP0037	01	001-099	
D40170P	7		0601	20 GA	D40168P	2		AP0006	17	001-099	
D40170P	8		0602	20 GA	D40168P	6		AP0006	17	001-099	
D40170P	9		0603	20 GA	D41082P	7		AP0037	01	001-099	
D40170P	10		0604	20 GA	D40168P	8		AP0006	17	001-099	
D40170P	11		0605	20 GA	D40168P	9		AP0006	17	001-099	
AE0600	07	W2350	L1	DISC BKT-E6 SHELF DISC							
D42216P	9		0049	20 GA	D40612P	49		AP0011	04	115-199	
D42216P	1		0141	22 GA	D40680P	1		AE0304	23	115-199	
D42216P	5		0520	22 GA	D40610P	6		AP0011	03	115-199	
D42216P	3		0730	22 GA	D40610P	4		AP0011	03	115-199	
D42216P	7		0731	22 GA	D40612P	7		AP0011	04	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0600

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0600	07	W2626	S2	DISC BKT-E6 SHELF DISC							
D41062P	2		0012	20 GA	D40218P	12		AP0054	04	001-099	
D41062P	5		0016	20 GA	D40218P	16		AP0054	04	001-099	
AE0600	09	W2706	L2	DISC BKT-E6 SHELF DISC							
D41845P	41		0008	24 GK	D40628P	41		AC0820	01	115-199	
D41845P	42		0010	24 GK	D40630P	42		AC0820	02	115-199	
D41845P	43		0012	24 GK	D40632P	43		AC0820	03	115-199	
D41845P	44		0013	24 GK	D40632P	44		AC0820	03	115-199	
D41845P	47		0014	24 GK	D42188P	47		AE0602	05	115-199	
D41845P	48		0015	24 GK	D42188P	48		AE0602	05	115-199	
D41845P	49		0016	24 GK	D42180P	49		AE0604	05	115-199	
D41845P	50		0017	24 GK	D42180P	50		AE0604	05	115-199	
D41845P	36		0258	24 GK	D42182P	2		AE0602	01	115-199	
D41845P	45		2002B	24 GL	D40632P	45		AC0820	03	115-199	
D41845P	46		2002R	24 GL	D40632P	46		AC0820	03	115-199	
AE0600	10	W2626	S2	DISC BKT-E6 SHELF DISC							
D41062P	2		0012	20 GA	D40218P	12		AP0054	04	115-199	
D41062P	5		0016	20 GA	D40218P	16		AP0054	04	115-199	
AE0600	12	W2654	A2	DISC BKT-E6 SHELF DISC							
D41688P	CAP	Y	0047	20 GA	D40198J	24		AT1883	06	115-199	
D41688P	11		0048	20 GA	D40198J	25		AT1883	06	115-199	
AE0600	13	W2654	A2	DISC BKT-E6 SHELF DISC							
D41688P	22		0047	20 GA	D40198J	24		AT1883	06	001-099	
D41688P	14		0048	20 GA	D40198J	25		AT1883	06	001-099	
AE0600	14	W2716	R2	DISC BKT-E6 SHELF DISC							
D41855P	46		0008	24 GK	D41638P	46		AD0820	01	115-199	
D41855P	47		0009	24 GK	D41638P	47		AD0820	01	115-199	
D41855P	48		0010	24 GK	D41642P	48		AD0820	03	115-199	
D41855P	49		0011	24 GK	D41642P	49		AD0820	03	115-199	
D41855P	23		0018	24 GK	D42190P	41		AE0602	07	115-199	
D41855P	25		0019	24 GK	D42190P	42		AE0602	07	115-199	
D41855P	38		0020	24 GK	D42184P	39		AE0604	03	115-199	
D41855P	44		0021	24 GK	D42184P	44		AE0604	03	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0600

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0600	14	W2716	R2	DISC BKT-E6 SHELF DISC (continued)								
D41855P	55		0242	24	GK	D41640P	27		AD0820	02	115-199	
D41855P	54		0243	24	GK	D41640P	28		AD0820	02	115-199	
AE0600	16	W2632	R1	DISC BKT-E6 SHELF DISC								
D42038P	17		0073	20	GA	D40176P	12		AB1210	02	001-099	
AE0600	16	W2650	A2	DISC BKT-E6 SHELF DISC								
D41680P	29		0037	22	GA	D41684P	11		AP0037	18	115-199	
D41680P	30		2003B	24	GL	D41684P	12		AP0037	18	115-199	
D41680P	31		2003R	24	GL	D41684P	13		AP0037	18	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0600

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0601	01	W2229	R2	DISC BKT-E6-1 SHELF DISC							
D41681P	14		0014	24 GK	D43683P	14		AE0302	01	001-009	
D41681P	8		2502B	24 G2	D43683P	9		AE0302	01	001-009	
D41681P	9		2502R	24 G2	D43683P	8		AE0302	01	001-009	
D41681P	10		2502Z		D43683P	10		AE0302	01	001-009	
D41681P	11		5006B	24 G2	D43683P	11		AE0302	01	003-009	
D41681P	12		5006R	24 G2	D43683P	12		AE0302	01	003-009	
D41681P	13		5006Z		D43683P	13		AE0302	01	003-009	
AE0601	09	W4517	R2	DISC BKT-E6-1 SHELF DISC							
D45007P	2		0002	24 GK	D45005P	2		AE0302	29	001-099	
D45007P	6		2502B	24 G2	D45005P	6		AE0302	29	001-099	
D45007P	7		2502R	24 G2	D45005P	7		AE0302	29	001-099	
D45007P	8		2502Z		D45005P	8		AE0302	29	001-099	
D45007P	15		5003B	24 G2	D45005P	15		AE0302	29	001-099	
D45007P	16		5003R	24 G2	D45005P	16		AE0302	29	001-099	
D45007P	17		5003Z		D45005P	17		AE0302	29	001-099	
AE0601	12	W4515	L2	DISC BKT-E6-1 SHELF DISC							
D45003P	2		0002	24 GK	D45001P	2		AE0302	09	001-099	
D45003P	6		2502B	24 G2	D45001P	6		AE0302	09	001-099	
D45003P	7		2502R	24 G2	D45001P	7		AE0302	09	001-099	
D45003P	8		2502Z		D45001P	8		AE0302	09	001-099	
D45003P	15		5003B	24 G2	D45001P	15		AE0302	09	001-099	
D45003P	16		5003R	24 G2	D45001P	16		AE0302	09	001-099	
D45003P	17		5003Z		D45001P	17		AE0302	09	001-099	
AE0601	14	W2358	S1	DISC BKT-E6-1 SHELF DISC							
D41962P	6		0046	20 GA	D40622P	16		AP0011	05	115-199	
D41962P	5		0115	20 GA	D40622P	26		AP0011	05	115-199	
AE0601	16	W4063	L2	DISC BKT-E6-1 SHELF DISC							
D41685P	26		5004B	24 G2	D41689P	26		AE0403	02	115-199	
D41685P	27		5004R	24 G2	D41689P	27		AE0403	02	115-199	
D41685P	28		5004Z		D41689P	28		AE0403	02	115-199	
AE0601	18	W2354	R1	DISC BKT-E6-1 SHELF DISC							
D41908P	4		0515	16 GA	D40824P	43		AP0011	14	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0601

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AE0601	18	W2354	R1		DISC BKT-E6-1 SHELF DISC (continued)							
D41908P	10		0630		18	GA	D40824P	38		AP0011	14	115-199
AE0601	21	W2253	R2		DISC BKT-E6-1 SHELF DISC							
D42003P	9		0096		22	GA	D41041J	15		AP0003	16	115-199
D42003P	10		0097		22	GA	D41041J	16		AP0003	16	115-199
D42003P	11		0098		22	GA	D41041J	18		AP0003	16	115-199
D42003P	12		5021B		24	G2	D41041J	31		AP0003	16	115-199
D42003P	13		5021R		24	G2	D41041J	30		AP0003	16	115-199
D42003P	14		5021Z				D41041J	32		AP0003	16	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AE0601

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0602	01	W2706	L2	DISC BKT-E6-2 SHELF DISC								
D42182P	2		0258	24 GK	D41845P	36		AE0600	09	115-199		
AE0602	02	W2654	A2	DISC BKT-E6-2 SHELF DISC								
D41676P	17		0042	20 GA	D40200J	22		AT1883	08	001-099		
D41676P	18		0043	20 GA	D40200J	28		AT1883	08	001-099		
D41676P	41		0044	20 GA	D40200J	29		AT1883	08	001-099		
AE0602	05	W2706	L2	DISC BKT-E6-2 SHELF DISC								
D42188P	40		0007	24 GK	D40628P	40		AC0820	01	115-199		
D42188P	47		0014	24 GK	D41845P	47		AE0600	09	115-199		
D42188P	48		0015	24 GK	D41845P	48		AE0600	09	115-199		
AE0602	07	W2650	A2	DISC BKT-E6-2 SHELF DISC								
D41662P	24		0002	24 GK	D42080P	6		AP0036	03	001-099		
D41662P	25		0066	22 GA	D41912P	2		AE0501	23	001-099		
D41662P	26		0068	22 GA	D42080P	10		AP0036	03	001-099		
AE0602	07	W2716	R2	DISC BKT-E6-2 SHELF DISC								
D42190P	48		0014	24 GK	D41638P	48		AD0820	01	115-199		
D42190P	49		0015	24 GK	D41638P	49		AD0820	01	115-199		
D42190P	34		0016	24 GK	D41642P	38		AD0820	03	115-199		
D42190P	35		0017	24 GK	D41642P	41		AD0820	03	115-199		
D42190P	41		0018	24 GK	D41855P	23		AE0600	14	115-199		
D42190P	42		0019	24 GK	D41855P	25		AE0600	14	115-199		
D42190P	12		0022	24 GK	D42184P	45		AE0604	03	115-199		
D42190P	11		0023	22 GA	D42184P	46		AE0604	03	115-199		
D42190P	37		2000B	24 GL	D41638P	37		AD0820	01	115-199		
D42190P	38		2000R	24 GL	D41638P	38		AD0820	01	115-199		
D42190P	39		2004B	24 GL	D41642P	39		AD0820	03	115-199		
D42190P	40		2004R	24 GL	D41642P	40		AD0820	03	115-199		
AE0602	09	W2654	A2	DISC BKT-E6-2 SHELF DISC								
D41678P	15		0041	20 GA	D40198J	18		AT1883	06	001-099		
D41678P	12		2511B	20 GU	D40200J	19		AT1883	08	001-099		
D41678P	13		2511R	20 GU	D40200J	20		AT1883	08	001-099		
D41678P	DED		2511Z		D40200J	21		AT1883	08	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0602

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AE0603			W2665	R2	DISC BKT-E6-3 SHELF DISC							
D41813P		9		0009	20	GA	D41735P	9				115-199
D41813P		10		0010	20	GA	D41735P	10				115-199
AE0603		10	W2350	L1	DISC BKT-E6-3 SHELF DISC							
D41974P		14		0712	22	GA	D40612P	31		AP0011	04	115-199
D41974P		13		0716	22	GA	D40610P	25		AP0011	03	115-199
AE0603		11	W2663	L2	DISC BKT-E6-3 SHELF DISC							
D41799P		9		0009	20	GA	D41733P	9				115-199
D41799P		10		0010	20	GA	D41733P	10				115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AE0603

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AE0604	02	W2654	A2	DISC BKT-E6-4 SHELF DISC								
D41678P	15		0041	20 GA	D40198J	18		AT1883	06	115-199		
D41678P	12		2511B	20 GU	D40200J	19		AT1883	08	115-199		
D41678P	13		2511R	20 GU	D40200J	20		AT1883	08	115-199		
D41678P	DED		2511Z		D40200J	21		AT1883	08	115-199		
AE0604	03	W2716	R2	DISC BKT-E6-4 SHELF DISC								
D42184P	23		0012	24 GK	D41642P	43		AD0820	03	115-199		
D42184P	24		0013	24 GK	D41642P	44		AD0820	03	115-199		
D42184P	39		0020	24 GK	D41855P	38		AE0600	14	115-199		
D42184P	44		0021	24 GK	D41855P	44		AE0600	14	115-199		
D42184P	45		0022	24 GK	D42190P	12		AE0602	07	115-199		
D42184P	46		0023	22 GA	D42190P	11		AE0602	07	115-199		
AE0604	05	W2706	L2	DISC BKT-E6-4 SHELF DISC								
D42180P	45		0009	24 GK	D40628P	45		AC0820	01	115-199		
D42180P	48		0011	24 GK	D40630P	48		AC0820	02	115-199		
D42180P	49		0016	24 GK	D41845P	49		AE0600	09	115-199		
D42180P	50		0017	24 GK	D41845P	50		AE0600	09	115-199		
D42180P	22		0224	24 GK	D40632P	13		AC0820	03	115-199		
D42180P	23		0225	24 GK	D40632P	14		AC0820	03	115-199		
D42180P	24		0226	24 GK	D40632P	15		AC0820	03	115-199		
D42180P	25		0227	24 GK	D40632P	16		AC0820	03	115-199		
D42180P	26		0228	24 GK	D40632P	17		AC0820	03	115-199		
D42180P	27		0229	24 GK	D40632P	18		AC0820	03	115-199		
D42180P	28		0230	24 GK	D40632P	19		AC0820	03	115-199		
D42180P	46		2000B	24 GL	D40628P	46		AC0820	01	115-199		
D42180P	47		2000R	24 GL	D40628P	47		AC0820	01	115-199		
AE0604	08	W2650	A2	DISC BKT-E6-4 SHELF DISC								
D41662P	3		0018	22 GA	D41660P	9		AE0402	21	115-199		
AE0604	09	W4210	S2	DISC BKT-E6-4 SHELF DISC								
D41686P	12		0054	22 GA	D41734P	35		AE0402	41	115-199		
D41686P	13		0055	22 GA	D41734P	36		AE0402	41	115-199		
D41686P	15		0100	22 GA	D41734P	45		AE0402	41	115-199		
D41686P	18		0104	22 GA	D41958P	43		AP0036	13	115-199		
D41686P	20		0118	24 GK	D41958P	51		AP0036	13	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AE0604

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0604	09	W4210	S2	DISC BKT-E6-4 SHELF DISC (continued)							
D41686P	21		0119	24 GK	D41958P	52		AP0036	13	115-199	
AE0604	12	W2646	R2A	DISC BKT-E6-4 SHELF DISC							
D41672P	28		0013	20 GA	D40084J	18		AW1240	01	115-199	
D41672P	29		0014	20 GA	D40084J	17		AW1240	01	115-199	
D41672P	26		0016	20 GA	D41812J	16		AC1090	01	115-199	
D41672P	27		0017	20 GA	D41812J	17		AC1090	01	115-199	
AE0604	14	W2648	R2B	DISC BKT-E6-4 SHELF DISC							
D41674P	13		0001	20 GA	D40434J	15		AW2240	01	115-199	
D41674P	11		0002	20 GA	D40434J	16		AW2240	01	115-199	
D41674P	12		0003	20 GA	D40434J	17		AW2240	01	115-199	
AE0604	15	W2644	L2B	DISC BKT-E6-4 SHELF DISC							
D41670P	23		0009	20 GA	D40442J	17		AW2240	02	115-199	
D41670P	21		0010	20 GA	D40442J	18		AW2240	02	115-199	
D41670P	22		0011	20 GA	D40442J	CAP	Y	AW2240	02	115-199	
AE0604	17	W2642	L2A	DISC BKT-E6-4 SHELF DISC							
D41668P	6		0001	20 GA	D40082J	17		AW1240	02	115-199	
D41668P	13		0002	20 GA	D40082J	18		AW1240	02	115-199	
D41668P	12		0003	20 GA	D40082J	19		AW1240	02	115-199	
AE0604	20	W2350	L1	DISC BKT-E6-4 SHELF DISC							
D42208P	4		0732	22 GA	D40610P	32		AP0011	03	115-199	
D42208P	3		0733	22 GA	D40612P	13		AP0011	04	115-199	
AE0604	22	W2358	S1	DISC BKT-E6-4 SHELF DISC							
D42218P	8		0438	22 GA	D40728P	38		AP0036	27	115-199	
D42218P	9		0439	22 GA	D40728P	39		AP0036	27	115-199	
AE0604	24	W2354	R1	DISC BKT-E6-4 SHELF DISC							
D42214P	4		0642	22 GA	D40618P	44		AP0011	13	115-199	
D42214P	2		0643	22 GA	D40824P	2		AP0011	14	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0604

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AE0604	28	W1032	S2	DISC BKT-E6-4 SHELF DISC								
D41676J	9		0336	22	GA	D01796B	CAP	Y			115-199	
AE0604	28	W2654	A2	DISC BKT-E6-4 SHELF DISC								
D41676P	16		0037	20	GA	D40198J	14		AT1883	06	115-199	
D41676P	17		0042	20	GA	D40200J	22		AT1883	08	115-199	
D41676P	18		0043	20	GA	D40200J	28		AT1883	08	115-199	
D41676P	41		0044	20	GA	D40200J	29		AT1883	08	115-199	
D41676P	15		0049	20	GA	D40198J	15		AT1883	06	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AE0604

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0001	06	W2061	C2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L							
D40633P	7		0009	22 GA	D00057	9		M00090		115-199	
D40633P	8		0010	22 GA	D00057	10		M00090		115-199	
AP0001	06	W2245	2C	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L							
D40633J	6		0006	22 GA	D42049P	17		AE0203	08	001-099	
D40633J	10		0010	22 GA	D42049P	30		AE0203	08	115-199	
D40633J	11		0011	22 GA	D42049P	31		AE0203	08	115-199	
D40633J	8		5004B	24 G2	D42049P	28		AE0203	08	ALL	
D40633J	7		5004R	24 G2	D42049P	27		AE0203	08	ALL	
D40633J	9		5004Z		D42049P	29		AE0203	08	ALL	
AP0001	07	W0001	L*	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L							
D40077P	42		0663	24 GK	D40427P	15		AP0103	03	115-199	
AP0001	07	W2243	R2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L							
D40077J	10		0001	24 GK	D42041P	10		AE0402	33	001-099	
D40077J	10		0001	22 GA	D42041P	10		AE0402	33	115-199	
D40077J	51		0009	22 GA	D42035P	9		AE0202	14	115-199	
D40077J	53		0020	22 GA	D42035P	32		AE0202	14	115-199	
D40077J	54		0021	22 GA	D42035P	33		AE0202	14	115-199	
D40077J	41		0097	22 GA	D42035P	35		AE0202	14	115-199	
D40077J	42		0098	22 GA	D42035P	36		AE0202	14	115-199	
D40077J	22		2002B	22 GB	D42035P	22		AE0202	14	001-099	
D40077J	21		2002R	22 GB	D42035P	21		AE0202	14	001-099	
D40077J	8		2502B	24 G2	D42041P	8		AE0402	33	115-199	
D40077J	7		2502R	24 G2	D42041P	7		AE0402	33	115-199	
D40077J	9		2502Z		D42041P	9		AE0402	33	115-199	
D40077J	30		2504B	24 G2	D42041P	2		AE0402	33	001-099	
D40077J	29		2504R	24 G2	D42041P	1		AE0402	33	001-099	
D40077J	31		2504Z		D42041P	3		AE0402	33	001-099	
D40077J	47		2508B	24 G2	D42041P	20		AE0402	33	115-199	
D40077J	46		2508R	24 G2	D42041P	19		AE0402	33	115-199	
D40077J	48		2508Z		D42041P	21		AE0402	33	115-199	
D40077J	19		3002B	24 GM	D42035P	19		AE0202	14	001-099	
D40077J	18		3002R	24 GM	D42035P	18		AE0202	14	001-099	
D40077J	20		3002Y	24 GM	D42035P	20		AE0202	14	001-099	
D40077J	36		5006B	24 G2	D42039P	5		AE0302	43	115-199	
D40077J	35		5006R	24 G2	D42039P	4		AE0302	43	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0001

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0001	07	W2243	R2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L (continued)								
D40077J	37		5006Z		D42039P	6		AE0302	43	115-199		
AP0001	08	W2041	L*	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L								
D40629P	27		0027	22 GA	D00037	CAP	Y	M00090		115-199		
D40629P	35		0029	22 GA	D00259	CAP	Y	M00091		115-199		
D40629P	36		0030	22 GA	D00259	CAP	Y	M00091		115-199		
AP0001	08	W2241	L2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L								
D40629J	2		0059	22 GA	D42013P	2		AE0201	15	001-099		
D40629J	27		0064	22 GA	D42013P	22		AE0201	15	115-199		
D40629J	28		0065	22 GA	D42013P	23		AE0201	15	115-199		
D40629J	35		0066	22 GA	D42019P	9		AE0303	30	ALL		
D40629J	36		0099	22 GA	D42019P	23		AE0303	30	115-199		
D40629J	30		2525B	24 G2	D42013P	29		AE0201	15	115-199		
D40629J	29		2525R	24 G2	D42013P	28		AE0201	15	115-199		
D40629J	31		2525Z		D42013P	30		AE0201	15	115-199		
D40629J	33		2526B	24 G2	D42013P	20		AE0201	15	115-199		
D40629J	32		2526R	24 G2	D42013P	19		AE0201	15	115-199		
D40629J	34		2526Z		D42013P	21		AE0201	15	115-199		
D40629J	45		5021B	24 G2	D42013P	22		AE0201	15	001-099		
D40629J	45		5021B	24 G2	D42013P	26		AE0201	15	115-199		
D40629J	44		5021R	24 G2	D42013P	21		AE0201	15	001-099		
D40629J	44		5021R	24 G2	D42013P	25		AE0201	15	115-199		
D40629J	46		5021Z		D42013P	23		AE0201	15	001-099		
D40629J	46		5021Z		D42013P	27		AE0201	15	115-199		
AP0001	09	W2368	S1	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L								
D40758J	7		0607	22 GA	D40752P	7		AP0011	18	115-199		
D40758J	8		0608	22 GA	D40752P	8		AP0011	18	115-199		
D40758J	11		0611	22 GA	D40752P	11		AP0011	18	115-199		
AP0001	10	W2245	2C	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L								
D42047J	37		0012	22 GA	D42051P	3		AE0204	06	ALL		
D42047J	38		0013	22 GA	D42051P	4		AE0204	06	115-199		
D42047J	39		0014	22 GA	D42051P	5		AE0204	06	115-199		
D42047J	24		0016	22 GA	D42049P	18		AE0203	08	ALL		
D42047J	22		2001B	24 GL	D42049P	20		AE0203	08	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0001

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0001	10	W2245	2C	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L (continued)							
D42047J	21		2001R	24 GL	D42049P	21		AE0203	08	ALL	
D42047J	26		5005B	24 G2	D42051P	12		AE0204	06	001-099	
D42047J	26		5005B	24 G2	D42051P	26		AE0204	06	115-199	
D42047J	25		5005R	24 G2	D42051P	11		AE0204	06	001-099	
D42047J	25		5005R	24 G2	D42051P	25		AE0204	06	115-199	
D42047J	27		5005Z		D42051P	4		AE0204	06	001-099	
D42047J	27		5005Z		D42051P	27		AE0204	06	115-199	
D42047J	35		5006B	24 G2	D42051P	23		AE0204	06	115-199	
D42047J	34		5006R	24 G2	D42051P	22		AE0204	06	115-199	
D42047J	36		5006Z		D42051P	24		AE0204	06	115-199	
AP0001	11	W2364	L1	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L							
D40754J	2		0002	24 GK	D40748P	1		AP0011	16	ALL	
D40754J	3		0003	22 GA	D40748P	11		AP0011	16	001-009, 115-199	
D40754J	11		0011	22 GA	D40748P	7		AP0011	16	ALL	
D40754J	24		0603	22 GA	D40748P	24		AP0011	16	ALL	
D40754J	25		0605	22 GA	D40748P	25		AP0011	16	115-199	
D40754J	26		0606	22 GA	D40748P	26		AP0011	16	115-199	
D40754J	27		0607	22 GA	D40748P	27		AP0011	16	115-199	
D40754J	28		0608	22 GA	D40748P	28		AP0011	16	115-199	
AP0001	12	W0001	L*	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L							
D40039P	6		0665	24 GK	D40209P	31		AP0103	02	115-199	
D40039P	7		0666	24 GK	D40209P	32		AP0103	02	115-199	
AP0001	12	W2241	L2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L							
D40039J	6		0010	22 GA	D42021P	6		AE0203	11	ALL	
D40039J	35		0032	22 GA	D42011P	37		AE0201	28	115-199	
D40039J	7		0045	22 GA	D42021P	7		AE0203	11	115-199	
D40039J	9		0052	22 GA	D40639P	2		AP0051	07	115-199	
D40039J	27		0053	22 GA	D40639P	3		AP0051	07	115-199	
D40039J	14		2002B	22 GB	D42011P	14		AE0201	28	001-099	
D40039J	13		2002R	22 GB	D42011P	13		AE0201	28	001-099	
D40039J	38		2512B	24 G2	D42011P	42		AE0201	28	115-199	
D40039J	37		2512R	24 G2	D42011P	41		AE0201	28	115-199	
D40039J	39		2512Z		D42011P	43		AE0201	28	115-199	
D40039J	11		3002B	24 GM	D42011P	11		AE0201	28	001-099	
D40039J	10		3002R	24 GM	D42011P	10		AE0201	28	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0001

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0001	12	W2241	L2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L (continued)								
D40039J	12		3002Y	24 GM	D42011P	12		AE0201	28	001-099		
D40039J	29		5008B	24 G2	D42011P	29		AE0201	28	ALL		
D40039J	28		5008R	24 G2	D42011P	28		AE0201	28	ALL		
D40039J	30		5008Z		D42011P	30		AE0201	28	ALL		
AP0001	14	W2064	L*	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L								
D41846J	3		0152	20 GA	D40582P	8		AP0036	25	001-099		
D41846J	4		0153	20 GA	D40582P	11		AP0036	25	001-099		
D41846J	5		0166	20 GA	D40582P	26		AP0036	25	001-099		
D41846J	6		0167	20 GA	D40582P	27		AP0036	25	001-099		
D41846J	7		0173	20 GA	D40582P	16		AP0036	25	001-099		
AP0001	15	W2241	L2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L								
D40523J	28		0028	22 GA	D42021P	28		AE0203	11	115-199		
D40523J	31		0031	24 GK	D42023P	20		AE0402	39	001-099		
D40523J	31		0031	24 GK	D42023P	31		AE0402	39	115-199		
D40523J	16		0038	24 GK	D42021P	1		AE0203	11	001-099		
D40523J	16		0038	22 GA	D42021P	1		AE0203	11	115-199		
D40523J	23		0040	22 GA	D42021P	23		AE0203	11	115-199		
D40523J	25		0041	22 GA	D42023P	13		AE0402	39	115-199		
D40523J	48		0043	22 GA	D40639P	12		AP0051	07	115-199		
D40523J	36		0090	22 GA	D42015P	3		AE0204	09	115-199		
D40523J	1		2508B	24 G2	D42023P	1		AE0402	39	115-199		
D40523J	2		2508R	24 G2	D42023P	2		AE0402	39	115-199		
D40523J	3		2508Z		D42023P	3		AE0402	39	115-199		
D40523J	4		2509B	24 G2	D42023P	4		AE0402	39	001-099		
D40523J	5		2509R	24 G2	D42023P	5		AE0402	39	001-099		
D40523J	6		2509Z		D42023P	6		AE0402	39	001-099		
D40523J	39		2518B	24 G2	D42021P	30		AE0203	11	115-199		
D40523J	38		2518R	24 G2	D42021P	29		AE0203	11	115-199		
D40523J	40		2518Z		D42021P	31		AE0203	11	115-199		
D40523J	45		2520B	24 G2	D40639P	16		AP0051	07	ALL		
D40523J	44		2520R	24 G2	D40639P	15		AP0051	07	ALL		
D40523J	46		2520Z		D40639P	17		AP0051	07	ALL		
AP0001	16	W2241	L2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L								
D40031J	23		5001B	24 G2	D42011P	3		AE0201	28	115-199		
D40031J	22		5001R	24 G2	D42011P	2		AE0201	28	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0001

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AP0001		16	W2241	L2	DISC BKT-CAPT. INSTRUMENT PANEL DISC-L (continued)							
D40031J		24		5001Z			D42011P	1		AE0201	28	115-199
D40031J		54		5012B	24	G2	D42019P	7		AE0303	30	001-099
D40031J		53		5012R	24	G2	D42019P	6		AE0303	30	001-099
D40031J		55		5012Z			D42019P	8		AE0303	30	001-099
D40031J		39		5014B	24	G2	D42015P	9		AE0204	09	001-099
D40031J		38		5014R	24	G2	D42015P	8		AE0204	09	001-099
D40031J		40		5014Z			D42015P	10		AE0204	09	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section AP0001

Page 5 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0003	03	W2066	L*	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D41170J	8		0439	20 GA	D40874P	25		AP0036	17	001-099		
D41170J	10		0441	20 GA	D40874P	32		AP0036	17	001-099		
D41170J	4		0540	20 GA	D06872	CAP	Y	M10054		001-099		
D41170J	4		0540	20 GA	D03584	CAP	Y	M10054		115-199		
AP0003	04	W2066	L*	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D41834J	6		0541	20 GA	D06872	CAP	Y	M10054		001-099		
D41834J	6		0541	20 GA	D03584	CAP	Y	M10054		115-199		
AP0003	07	W0003	R*	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D41172P	20		0287	22 GA	D40836P	10		AP0301	04	115-199		
AP0003	07	W2070	R*	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D41172J	33		0404	20 GA	D41860P	15		AP0037	11	001-008		
D41172J	36		0405	20 GA	D41860P	16		AP0037	11	001-099		
D41172J	37		0406	20 GA	D41860P	17		AP0037	11	001-008		
D41172J	38		0407	20 GA	D41860P	18		AP0037	11	001-008		
D41172J	22		0458	20 GA	D41058P	36		AE0402	22	ALL		
AP0003	08	W2051	R2	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D40631P	14		0023	22 GA	D00077	CAP	Y	M00090		115-199		
D40631P	15		0024	22 GA	D00077	CAP	Y	M00090		115-199		
D40631P	37		0026	22 GA	D00261	CAP	Y	M00092		115-199		
AP0003	08	W2253	R2	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D40631J	12		0034	22 GA	D42085P	36		AE0202	31	001-099		
D40631J	14		0036	22 GA	D42083P	29		AE0203	26	115-199		
D40631J	15		0037	22 GA	D42083P	30		AE0203	26	115-199		
D40631J	42		0077	22 GA	D42091P	43		AE0302	26	115-199		
D40631J	43		0078	22 GA	D42091P	44		AE0302	26	115-199		
D40631J	46		0095	22 GA	D42087P	13		AE0202	17	115-199		
D40631J	40		2510B	24 G2	D42091P	41		AE0302	26	115-199		
D40631J	39		2510R	24 G2	D42091P	40		AE0302	26	115-199		
D40631J	41		2510Z		D42091P	42		AE0302	26	115-199		
D40631J	37		2511B	24 G2	D42085P	32		AE0202	31	115-199		
D40631J	36		2511R	24 G2	D42085P	31		AE0202	31	115-199		
D40631J	38		2511Z		D42085P	33		AE0202	31	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0003

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AP0003	09	W2247	2S	DISC BKT-F/O INSTRUMENT PANEL DISC-L							
D42165J	12	18	0012	22	GA	D42167P	5	18	AE0203	17	001, 003-099
D42165J	16		0016	18	GA	D42169P	1		AE0304	11	001-099
D42165J	36		0031	22	GA	D42053P	1		AE0503	11	001-099
D42165J	12		0012	22	GA	D42167P	5		AE0203	17	115-199
D42165J	13		0013	22	GA	D42167P	6		AE0203	17	115-199
D42165J	14		0014	22	GA	D42167P	7		AE0203	17	115-199
D42165J	15		0015	22	GA	D42167P	8		AE0203	17	115-199
D42165J	17		0017	22	GA	D42169P	2		AE0304	11	115-199
D42165J	18		0018	22	GA	D42169P	3		AE0304	11	115-199
D42165J	19		0019	22	GA	D42169P	4		AE0304	11	115-199
D42165J	20		0020	22	GA	D42169P	12		AE0304	11	115-199
D42165J	36		0031	22	GA	D42053P	1		AE0503	11	115-199
D42165J	37		0032	22	GA	D42053P	2		AE0503	11	115-199
D42165J	38		0033	22	GA	D42053P	3		AE0503	11	115-199
D42165J	39		0034	22	GA	D42053P	4		AE0503	11	115-199
AP0003	10	W2253	R2	DISC BKT-F/O INSTRUMENT PANEL DISC-L							
D40073J	37		0002	24	GK	D42089P	2		AE0204	14	115-199
D40073J	47		0017	22	GA	D42083P	17		AE0203	26	115-199
D40073J	27		0020	22	GA	D42091P	14		AE0302	26	ALL
D40073J	34		0030	22	GA	D42083P	21		AE0203	26	115-199
D40073J	24		0084	22	GA	D42089P	17		AE0204	14	115-199
D40073J	45		2501B	24	G2	D42085P	51		AE0202	31	001-099
D40073J	44		2501R	24	G2	D42085P	50		AE0202	31	001-099
D40073J	46		2501Z			D42085P	52		AE0202	31	001-099
D40073J	49		2502B	24	G2	D42085P	13		AE0202	31	115-199
D40073J	48		2502R	24	G2	D42085P	12		AE0202	31	115-199
D40073J	50		2502Z			D42085P	14		AE0202	31	115-199
D40073J	54		2503B	24	G2	D42091P	9		AE0302	26	115-199
D40073J	53		2503R	24	G2	D42091P	8		AE0302	26	115-199
D40073J	55		2503Z			D42091P	10		AE0302	26	115-199
D40073J	9		5003B	24	G2	D42085P	9		AE0202	31	115-199
D40073J	8		5003R	24	G2	D42085P	8		AE0202	31	115-199
D40073J	10		5003Z			D42085P	10		AE0202	31	115-199
D40073J	16		5006B	24	G2	D42091P	16		AE0302	26	001-099
D40073J	15		5006R	24	G2	D42091P	15		AE0302	26	001-099
D40073J	17		5006Z			D42091P	17		AE0302	26	001-099
D40073J	28		5016B	24	G2	D42087P	10		AE0202	17	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AP0003

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0003	10	W2253	R2	DISC BKT-F/O INSTRUMENT PANEL DISC-L (continued)								
D40073J	29		5016R	24 G2	D42087P	11		AE0202	17	ALL		
D40073J	30		5016Z		D42087P	12		AE0202	17	ALL		
AP0003	11	W2366	R1	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D40756J	2		0002	24 GK	D40750P	2		AP0011	21	115-199		
D40756J	15		0019	20 GA	D40750P	19		AP0011	21	ALL		
D40756J	16		0020	22 GA	D40750P	20		AP0011	21	001-099		
D40756J	16		0020	20 GA	D40750P	20		AP0011	21	115-199		
D40756J	21		0021	20 GA	D40750P	21		AP0011	21	115-199		
D40756J	20		0024	20 GA	D40750P	24		AP0011	21	115-199		
D40756J	27		0127	22 GA	D40750P	27		AP0011	21	ALL		
AP0003	12	W2251	L2	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D40035J	33		0004	22 GA	D42073P	12		AE0402	25	ALL		
D40035J	34		0005	22 GA	D42073P	13		AE0402	25	115-199		
D40035J	13		0006	22 GA	D42065P	15		AE0201	13	115-199		
D40035J	29		0009	24 GK	D42065P	16		AE0201	13	115-199		
D40035J	22		0021	22 GA	D42069P	3		AE0501	15	115-199		
D40035J	7		0022	24 GK	D42071P	7		AE0303	16	115-199		
D40035J	8		0023	22 GA	D42071P	8		AE0303	16	115-199		
D40035J	9		0024	22 GA	D42071P	9		AE0303	16	ALL		
D40035J	48		0026	22 GA	D42073P	11		AE0402	25	115-199		
D40035J	14		0029	22 GA	D42069P	6		AE0501	15	115-199		
D40035J	15		0030	22 GA	D42069P	7		AE0501	15	115-199		
D40035J	41		0035	22 GA	D42071P	3		AE0303	16	115-199		
D40035J	15		2005B	22 GB	D42065P	13		AE0201	13	001-099		
D40035J	38		2005B	22 GB	D42065P	13		AE0201	13	115-199		
D40035J	14		2005R	22 GB	D42065P	14		AE0201	13	001-099		
D40035J	37		2005R	22 GB	D42065P	14		AE0201	13	115-199		
D40035J	46		2501B	24 G2	D42063P	12		AE0203	27	115-199		
D40035J	45		2501R	24 G2	D42063P	11		AE0203	27	115-199		
D40035J	47		2501Z		D42063P	13		AE0203	27	115-199		
D40035J	17		5005B	24 G2	D42071P	5		AE0303	16	115-199		
D40035J	16		5005R	24 G2	D42071P	4		AE0303	16	115-199		
D40035J	18		5005Z		D42071P	6		AE0303	16	115-199		
D40035J	11		5008B	24 G2	D42063P	20		AE0203	27	115-199		
D40035J	10		5008R	24 G2	D42063P	19		AE0203	27	115-199		
D40035J	12		5008Z		D42063P	21		AE0203	27	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0003

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AP0003	12	W2251	L2	DISC BKT-F/O INSTRUMENT PANEL DISC-L (continued)						
D40035J	37		5010B	24 G2	D42069P	13		AE0501	15	001-099
D40035J	36		5010R	24 G2	D42069P	12		AE0501	15	001-099
D40035J	38		5010Z		D42069P	14		AE0501	15	001-099
AP0003	13	W0003	R*	DISC BKT-F/O INSTRUMENT PANEL DISC-L						
D40099P	15		0126	22 GA	D40836P	5		AP0301	04	115-199
AP0003	13	W2253	R2	DISC BKT-F/O INSTRUMENT PANEL DISC-L						
D40099J	3		0003	22 GA	D42085P	3		AE0202	31	ALL
D40099J	4		0004	22 GA	D42083P	4		AE0203	26	115-199
D40099J	21		0016	22 GA	D42083P	16		AE0203	26	115-199
D40099J	1		0021	22 GA	D42085P	15		AE0202	31	115-199
D40099J	2		0022	22 GA	D42085P	16		AE0202	31	115-199
D40099J	28		0025	22 GA	D42083P	25		AE0203	26	115-199
D40099J	29		0026	22 GA	D42083P	26		AE0203	26	115-199
D40099J	30		0027	22 GA	D42083P	27		AE0203	26	115-199
D40099J	31		0028	22 GA	D42083P	28		AE0203	26	115-199
D40099J	18		0079	22 GA	D42083P	12		AE0203	26	115-199
D40099J	19		0080	24 GK	D42083P	15		AE0203	26	001-099
D40099J	19		0080	22 GA	D42083P	15		AE0203	26	115-199
D40099J	35		0081	22 GA	D42083P	18		AE0203	26	115-199
D40099J	36		0082	22 GA	D42083P	19		AE0203	26	115-199
D40099J	37		0093	22 GA	D42081P	13		AP0051	09	115-199
D40099J	38		0094	22 GA	D42081P	14		AP0051	09	115-199
D40099J	23		2505B	24 G2	D42089P	10		AE0204	14	115-199
D40099J	22		2505R	24 G2	D42089P	9		AE0204	14	115-199
D40099J	24		2505Z		D42089P	11		AE0204	14	115-199
D40099J	26		2506B	24 G2	D42089P	13		AE0204	14	115-199
D40099J	25		2506R	24 G2	D42089P	12		AE0204	14	115-199
D40099J	27		2506Z		D42089P	14		AE0204	14	115-199
D40099J	13		5015B	24 G2	D42081P	4		AP0051	09	ALL
D40099J	12		5015R	24 G2	D42081P	3		AP0051	09	ALL
D40099J	14		5015Z		D42081P	5		AP0051	09	ALL
D40099J	40		5024B	24 G2	D42095P	27		AE0502	13	001-099
D40099J	39		5024R	24 G2	D42095P	26		AE0502	13	001-099
D40099J	41		5024Z		D42095P	25		AE0502	13	001-099
D40099J	30		5027B	24 G2	D42083P	7		AE0203	26	001-099
D40099J	29		5027R	24 G2	D42083P	6		AE0203	26	001, 003-099

SPARE WIRE LIST

D280N032

91-21-12

Section AP0003

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0003	13	W2253	R2	DISC BKT-F/O INSTRUMENT PANEL DISC-L (continued)								
D40099J	29		5027R	24 G2	D42083P	CAP	Y	AE0203	26	002		
D40099J	31		5027Z		D42083P	8		AE0203	26	001-099		
D40099J	23		5028B	24 G2	D42089P	10		AE0204	14	001-099		
D40099J	22		5028R	24 G2	D42089P	9		AE0204	14	001-099		
D40099J	24		5028Z		D42089P	11		AE0204	14	001-099		
AP0003	14	W2078	S*	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D41878J	8		0382	20 GA	D41414P	49		AP0033	26	001-008, 115-199		
D41878J	20		0420	20 GA	D41844P	23		AE0402	04	001-099		
D41878J	20		0420	20 GA	D41844P	39		AE0402	20	115-199		
AP0003	15	W2078	S*	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D41174J	21	18	0172	18 GA	D40296P	12	18	AP0006	01	ALL		
D41174J	2		0380	20 GA	D41414P	47		AP0033	26	ALL		
D41174J	3		0381	20 GA	D41414P	48		AP0033	26	ALL		
AP0003	16	W2253	R2	DISC BKT-F/O INSTRUMENT PANEL DISC-L								
D41041J	3		0050	22 GA	D42095P	8		AE0502	13	ALL		
D41041J	4		0051	22 GA	D42095P	20		AE0502	13	ALL		
D41041J	24		0071	22 GA	D42093P	2		AE0402	15	115-199		
D41041J	25		0072	22 GA	D42093P	3		AE0402	15	115-199		
D41041J	49		0090	24 GK	D42081P	1		AP0051	09	115-199		
D41041J	15		0096	22 GA	D42003P	9		AE0601	21	115-199		
D41041J	16		0097	22 GA	D42003P	10		AE0601	21	115-199		
D41041J	18		0098	22 GA	D42003P	11		AE0601	21	115-199		
D41041J	54		2504B	24 G2	D42093P	5		AE0402	15	001-099		
D41041J	53		2504R	24 G2	D42093P	4		AE0402	15	001-099		
D41041J	55		2504Z		D42093P	6		AE0402	15	001-099		
D41041J	34		2509B	24 G2	D42095P	29		AE0502	13	115-199		
D41041J	33		2509R	24 G2	D42095P	28		AE0502	13	115-199		
D41041J	35		2509Z		D42095P	30		AE0502	13	115-199		
D41041J	27		5020B	24 G2	D42095P	11		AE0502	13	001-099		
D41041J	28		5020R	24 G2	D42095P	12		AE0502	13	001-099		
D41041J	29		5020Z		D42095P	13		AE0502	13	001-099		
D41041J	31		5021B	24 G2	D42003P	12		AE0601	21	115-199		
D41041J	30		5021R	24 G2	D42003P	13		AE0601	21	115-199		
D41041J	32		5021Z		D42003P	14		AE0601	21	115-199		
D41041J	34		5025B	24 G2	D42095P	29		AE0502	13	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0003

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0003	16	W2253	R2	DISC BKT-F/O INSTRUMENT PANEL DISC-L (continued)							
D41041J	33		5025R	24 G2	D42095P	28		AE0502	13	001-099	
D41041J	35		5025Z		D42095P	30		AE0502	13	001-099	
AP0003	19	W2251	L2	DISC BKT-F/O INSTRUMENT PANEL DISC-L							
D42055J	5		0031	22 GA	D42069P	4		AE0501	15	115-199	
D42055J	4		0032	22 GA	D42069P	5		AE0501	15	115-199	
D42055J	8		0050	22 GA	D42069P	8		AE0501	15	115-199	
D42055J	9		0051	22 GA	D42069P	11		AE0501	15	115-199	
D42055J	7		0052	22 GA	D42069P	10		AE0501	15	115-199	
D42055J	6		0053	22 GA	D42069P	9		AE0501	15	115-199	
D42055J	25		0057	22 GA	D42071P	16		AE0303	16	115-199	
D42055J	26		0058	22 GA	D42071P	17		AE0303	16	115-199	
D42055J	27		0059	22 GA	D42071P	18		AE0303	16	115-199	
D42055J	24		2006B	22 GB	D42063P	15		AE0203	27	115-199	
D42055J	23		2006R	22 GB	D42063P	14		AE0203	27	115-199	
D42055J	14		5004B	24 G2	D42071P	14		AE0303	16	001-099	
D42055J	13		5004R	24 G2	D42071P	13		AE0303	16	001-099	
D42055J	15		5004Z		D42071P	15		AE0303	16	001-099	
D42055J	11		5006B	24 G2	D42063P	23		AE0203	27	ALL	
D42055J	10		5006R	24 G2	D42063P	22		AE0203	27	ALL	
D42055J	12		5006Z		D42063P	24		AE0203	27	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0003

Page 6 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0005	14	W2064	L*	DISC BKT-PILOTS OVERHEAD PANEL DISC								
D40798J	19		0089	22 GA	D41410P	15		AP0033	06	001-099		
D40798J	10		0112	24 GK	D40582P	43		AP0036	25	001-099		
D40798J	8		0192	22 GA	D40582P	39		AP0036	25	001-099		
AP0005	16	W2066	L*	DISC BKT-PILOTS OVERHEAD PANEL DISC								
D40800J	42		0008	22 GA	D40972P	16		AP0050	03	ALL		
D40800J	35		0104	24 GK	D41854P	8		AP0037	47	ALL		
D40800J	55		0241	24 GK	D03538	14		M10259		ALL		
AP0005	17	W2078	S*	DISC BKT-PILOTS OVERHEAD PANEL DISC								
D40806J	7		0530	22 GA	D40570P	9		AP0037	06	001-099		
AP0005	31	W2070	R*	DISC BKT-PILOTS OVERHEAD PANEL DISC								
D40802J	1		0019	20 GA	D03502	18		M10063		115-199		
D40802J	2		0332	22 GA	D42176P	26		AP0037	05	001-099		
D40802J	3		0394	24 GK	D41856P	26		AP0037	33	001-099		
AP0005	33	W2072	R*	DISC BKT-PILOTS OVERHEAD PANEL DISC								
D40804J	36		0131	20 GA	D40594P	37		AP0037	02	001-099		
D40804J	36		0131	22 GA	D40594P	37		AP0037	02	115-199		
AP0005	34	W2156	S*	DISC BKT-PILOTS OVERHEAD PANEL DISC								
D40808J	4		0016	22 GA	D41060P	8		AP0036	24	001-099		
D40808J	29		0130	20 GA	D41060P	17		AP0036	24	001-099		
D40808J	CAP	Y	0131	20 GA	D41060P	19		AP0036	24	001-002		
D40808J	13		0131	20 GA	D41060P	19		AP0036	24	003-099		
D40808J	32		0135	20 GA	D41858P	16		AP0037	43	001-002		
D40808J	25		0136	20 GA	D41858P	17		AP0037	43	001-002		
D40808J	13		0151	22 GA	TB0115X	C016	BJ			115-199		
D40808J	14		0152	22 GA	TB0115X	C015	BJ			115-199		
D40808J	30		0176	22 GA	TB0058Y	CAP	Y			115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0005

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0006	01	W2078	S*	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC							
D40296P	12	18	0172	18 GA	D41174J	21	18	AP0003	15	ALL	
D40296P	31		0357	20 GA	D41850P	55		AP0036	14	115-199	
D40296P	13		0373	20 GA	D41414P	40		AP0033	26	ALL	
D40296P	17		0374	20 GA	D41414P	41		AP0033	26	ALL	
D40296P	18		0375	20 GA	D41414P	42		AP0033	26	115-199	
D40296P	19		0376	20 GA	D41414P	43		AP0033	26	115-199	
D40296P	20		0395	20 GA	D40570P	38		AP0037	06	ALL	
D40296P	25		0397	20 GA	D40570P	40		AP0037	06	ALL	
D40296P	26		0416	20 GA	D41844P	35		AE0402	20	115-199	
D40296P	27		0417	20 GA	D41844P	36		AE0402	20	115-199	
AP0006	02	W2010	C1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC							
D40298P	4		0004	18 GA	TB5006	CAP	Y			ALL	
D40298P	5		0005	16 GA	TB5006	CAP	Y			ALL	
AP0006	03	W2260	S1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC							
D40870P	5		0055	20 GA	D40914P	5		AP0036	16	001-002	
D40870P	8		0603	22 GA	D41420P	4		AP0033	13	115-199	
D40870P	9		0604	22 GA	D41420P	5		AP0033	13	115-199	
D40870P	10		0605	22 GA	D41420P	6		AP0033	13	115-199	
D40870P	12		0606	22 GA	D41420P	7		AP0033	13	115-199	
D40870P	14		0607	22 GA	D41420P	8		AP0033	13	115-199	
D40870P	18		0609	22 GA	D40914P	2		AP0036	16	115-199	
D40870P	22		0611	20 GA	D40914P	4		AP0036	16	115-199	
D40870P	6		0614	20 GA	D40914P	9		AP0036	16	115-199	
D40870P	7		0615	20 GA	D41420P	9		AP0033	13	115-199	
AP0006	05	W2250	S1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC							
D40246P	25		0012	22 GA	D40904P	4		AE0402	13	ALL	
D40246P	24		0013	22 GA	D40904P	6		AE0402	13	115-199	
D40246P	15		0015	22 GA	D40904P	15		AE0402	13	115-199	
D40246P	10		0017	18 GA	D41894P	10		AE0501	11	ALL	
D40246P	30		0028	20 GA	D40904P	10		AE0402	13	115-199	
D40246P	29		0029	20 GA	D40904P	9		AE0402	13	115-199	
D40246P	8		0031	18 GA	D40908P	7		AE0502	27	ALL	
D40246P	13		0055	20 GA	D40904P	14		AE0402	13	115-199	
D40246P	18		0603	20 GA	D41894P	3		AE0501	11	ALL	
D40246P	19		0604	20 GA	D40908P	3		AE0502	27	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0006

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0006	07	W2260	S1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC								
D40870P	5		0055	20 GA	D40914P	5		AP0036	16	003-099		
AP0006	08	W2240	L2	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC								
D40284P	CAP	Y	0601	22 GA	D41752P	5		AE0501	12	001-002, 115-199		
D40284P	6		0602	22 GA	D41752P	6		AE0501	12	115-199		
D40284P	7		0603	22 GA	D41752P	7		AE0501	12	115-199		
D40284P	8		0604	22 GA	D41752P	8		AE0501	12	115-199		
D40284P	9		0605	22 GA	D41752P	9		AE0501	12	115-199		
D40284P	10		0606	20 GA	D41752P	10		AE0501	12	ALL		
D40284P	11		0607	20 GA	D41752P	11		AE0501	12	115-199		
D40284P	12		0608	20 GA	D41752P	12		AE0501	12	115-199		
D40284P	13		0609	20 GA	D41752P	13		AE0501	12	115-199		
AP0006	09	W2244	R1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC								
D40286P	CAP	Y	0001	22 GA	D40894P	5		AE0502	02	001-002, 115-199		
D40286P	6		0002	22 GA	D40894P	6		AE0502	02	ALL		
D40286P	9		0009	22 GA	D40892P	9		AE0402	45	ALL		
D40286P	10		0010	22 GA	D40892P	10		AE0402	45	ALL		
AP0006	10	W2256	L1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC								
D40866P	18		0006	20 GA	D40910P	12		AP0036	04	115-199		
D40866P	19		0008	20 GA	D40910P	13		AP0036	04	115-199		
D40866P	22		0011	20 GA	D40910P	16		AP0036	04	115-199		
D40866P	27		0026	20 GA	D41416P	14		AP0033	25	115-199		
D40866P	29		0030	20 GA	D41746P	2		AP0070	02	ALL		
D40866P	31		0032	20 GA	D41746P	4		AP0070	02	ALL		
D40866P	9		0601	20 GA	D41416P	6		AP0033	25	115-199		
D40866P	11		0603	20 GA	D40910P	5		AP0036	04	115-199		
D40866P	25		0612	20 GA	D41746P	17		AP0070	02	115-199		
D40866P	8		0613	14 GA	D40910P	1		AP0036	04	115-199		
AP0006	12	W2258	R1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC								
D40868P	1		0001	16 GA	D40912P	1		AP0037	45	001-099		
D40868P	1		0001	20 GA	D40912P	1		AP0037	45	115-199		
D40868P	3		0003	20 GA	D40912P	3		AP0037	45	115-199		
D40868P	7		0007	20 GA	D40912P	7		AP0037	45	115-199		
D40868P	9		0009	20 GA	D40912P	9		AP0037	45	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0006

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0006	12	W2258	R1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC (continued)								
D40868P	25		0025	20 GA	D40912P	25		AP0037	45	115-199		
D40868P	2		0601	20 GA	D40912P	2		AP0037	45	ALL		
D40868P	42		0603	16 GA	D40912P	42		AP0037	45	115-199		
D40868P	41		0604	16 GA	D40912P	41		AP0037	45	115-199		
D40868P	40		0605	16 GA	D40912P	40		AP0037	45	115-199		
D40868P	27		0606	16 GA	D40912P	27		AP0037	45	115-199		
D40868P	13		0607	20 GA	D40912P	13		AP0037	45	115-199		
D40868P	15		0609	18 GA	D40912P	15		AP0037	45	ALL		
D40868P	16		0611	20 GA	D40912P	16		AP0037	45	115-199		
D40868P	17		0612	20 GA	D40912P	17		AP0037	45	115-199		
D40868P	18		0613	20 GA	D40912P	18		AP0037	45	115-199		
D40868P	19		0614	20 GA	D40912P	19		AP0037	45	115-199		
D40868P	20		0615	20 GA	D40912P	20		AP0037	45	115-199		
D40868P	4		0616	20 GA	D40912P	4		AP0037	45	115-199		
D40868P	6		0617	20 GA	D40912P	6		AP0037	45	115-199		
D40868P	8		0618	20 GA	D40912P	8		AP0037	45	115-199		
D40868P	10		0619	20 GA	D40912P	10		AP0037	45	115-199		
AP0006	14	W2370	C2	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC								
D40300P	7		0101	22 GA	D41320P	6		AP0032	01	ALL		
D40300P	8		0102	22 GA	D41320P	7		AP0032	01	ALL		
D40300P	9		0103	22 GA	D41320P	8		AP0032	01	115-199		
D40300P	10		0104	22 GA	D41888P	3		AE0203	25	115-199		
D40300P	11		0105	22 GA	D41888P	4		AE0203	25	115-199		
AP0006	16	W2244	R1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC								
D40294P	4		0601	14 GA	D40920P	3		AP0037	46	115-199		
D40294P	5		0602	14 GA	D40920P	4		AP0037	46	115-199		
D40294P	6		0603	14 GA	D40920P	5		AP0037	46	115-199		
AP0006	17	W2700	R1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC								
D40168P	1		0007	22 GA	D40170P	1		AE0600	06	001-099		
D40168P	1		0007	22 GA	D40170P	1		AE0600	04	115-199		
D40168P	3		0009	20 GA	D40170P	3		AE0600	06	001-099		
D40168P	3		0009	20 GA	D40170P	3		AE0600	04	115-199		
D40168P	2		0601	20 GA	D40170P	7		AE0600	06	001-099		
D40168P	2		0601	20 GA	D40170P	7		AE0600	04	115-199		
D40168P	6		0602	20 GA	D40170P	8		AE0600	06	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0006

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0006	17	W2700	R1	DISC BKT-MAIN PWR DISTRIBUTION PNL DISC (continued)								
D40168P	6		0602	20	GA	D40170P	8		AE0600	04	115-199	
D40168P	8		0604	20	GA	D40170P	10		AE0600	06	001-099	
D40168P	8		0604	20	GA	D40170P	10		AE0600	04	115-199	
D40168P	9		0605	20	GA	D40170P	11		AE0600	06	001-099	
D40168P	9		0605	20	GA	D40170P	11		AE0600	04	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0006

Page 4 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0010	01	W4228	S2	DISC BKT-QUADRANT STAND							
D40901P	CAP	Y	0046	22 GA	D41948P	6		AP0036	22	001-002, 115-199	
D40901P	CAP	Y	0047	22 GA	D41948P	7		AP0036	22	001-002, 115-199	
D40901P	8		0096	20 GA	D40014J	12		AC0880	23	115-199	
D40901P	6		0108	22 GA	D40002J	22		AC0880	22	115-199	
D40901P	10		0109	22 GA	D40002J	41		AC0880	22	115-199	
AP0010	03	W1115	S*	DISC BKT-QUADRANT STAND							
D40503J	11		0438	22 GA	TB0192Y	A002	BJ	TB0192		001-099	
D40503J	10		0439	22 GA	TB0192Y	A001	BJ	TB0192		001-099	
D40503J	24		0440	22 GA	TB0190X	A001	BJ	TB0190		001-099	
D40503J	20		2002B	22 GB	TB0190X	D002	BJ	TB0190		001-099	
D40503J	19		2002R	22 GB	TB0190X	C002	BJ	TB0190		001-099	
AP0010	03	W2359	C2	DISC BKT-QUADRANT STAND							
D40503P	11		0009	22 GA	D40927P	3		AE0303	42	115-199	
D40503P	10		0010	22 GA	D40927P	4		AE0303	42	115-199	
AP0010	05	W4220	S2	DISC BKT-QUADRANT STAND							
D40784P	2		0106	24 GK	D41994P	CAP	Y	AP0037	34	001-003	
D40784P	2		0106	24 GK	D41994P	31		AP0037	34	004-099	
AP0010	05	W4238	S2	DISC BKT-QUADRANT STAND							
D40784P	2		0015	24 GK	D41998P	5		AP0037	22	115-199	
AP0010	08	W4236	S2	DISC BKT-QUADRANT STAND							
D40899P	CAP	Y	0053	22 GA	D42010P	CAP	Y	AP0037	48	001-002, 115-199	
D40899P	CAP	Y	0054	22 GA	D42010P	CAP	Y	AP0037	48	001-002, 115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0010

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0011	01	W2352	L1	DISC BKT-CIRCUIT BREAKER PANEL							
D40614P	49		0002	24 GK	D40696P	32		AP0036	26	001-099	
D40614P	50		0003	24 GK	D40696P	33		AP0036	26	001-099	
D40614P	4		0004	24 GK	D40696P	8		AP0036	26	ALL	
D40614P	8		0008	24 GK	D40696P	9		AP0036	26	ALL	
D40614P	10		0010	24 GK	D41880P	10		AP0070	07	115-199	
D40614P	19		0019	24 GK	D40696P	21		AP0036	26	ALL	
D40614P	34		0034	22 GA	D40696P	27		AP0036	26	115-199	
D40614P	1		0201	20 GA	D40810P	1		AP0050	15	115-199	
D40614P	3		0501	24 GK	D40696P	2		AP0036	26	ALL	
D40614P	17		0603	24 GK	D40810P	3		AP0050	15	ALL	
D40614P	20		0604	24 GK	D40810P	6		AP0050	15	ALL	
D40614P	21		0605	24 GK	D40810P	8		AP0050	15	ALL	
D40614P	22		0606	24 GK	D40810P	9		AP0050	15	115-199	
D40614P	23		0607	24 GK	D40810P	10		AP0050	15	115-199	
D40614P	25		0609	20 GA	D40810P	12		AP0050	15	ALL	
D40614P	26		0614	22 GA	D41880P	18		AP0070	07	115-199	
D40614P	27		0615	22 GA	D41880P	19		AP0070	07	115-199	
D40614P	30		0616	22 GA	D41880P	20		AP0070	07	115-199	
D40614P	33		0619	24 GK	D40696P	4		AP0036	26	115-199	
D40614P	35		0620	24 GK	D40696P	23		AP0036	26	115-199	
D40614P	36		0621	24 GK	D40696P	24		AP0036	26	115-199	
D40614P	44		0647	20 GA	D41880P	33		AP0070	07	115-199	
D40614P	45		0648	20 GA	D41880P	34		AP0070	07	115-199	
AP0011	02	W2352	L1	DISC BKT-CIRCUIT BREAKER PANEL							
D40616P	1		0626	22 GA	D40696P	31		AP0036	26	115-199	
D40616P	2		0627	20 GA	D40696P	32		AP0036	26	115-199	
D40616P	3		0628	20 GA	D40696P	33		AP0036	26	115-199	
D40616P	6		0629	20 GA	D40696P	37		AP0036	26	115-199	
D40616P	7		0630	20 GA	D40696P	39		AP0036	26	115-199	
D40616P	8		0631	20 GA	D40696P	40		AP0036	26	115-199	
D40616P	11		0632	20 GA	D40696P	45		AP0036	26	115-199	
D40616P	12		0633	20 GA	D40696P	47		AP0036	26	001, 003-099, 115-199	
D40616P	REF	JB	0633	20 GA	D40696P	47		AP0036	26	002	
AP0011	03	W2350	L1	DISC BKT-CIRCUIT BREAKER PANEL							
D40610P	2		0002	22 GA	D40686P	2		AE0403	32	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0011

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0011	03	W2350	L1	DISC BKT-CIRCUIT BREAKER PANEL (continued)								
D40610P	49		0005	22 GA	D40676P	1		AE0301	19	ALL		
D40610P	18		0018	22 GA	D41910P	6		AE0201	17	ALL		
D40610P	29		0029	22 GA	D40678P	9		AE0303	18	115-199		
D40610P	31		0031	24 GK	D41910P	1		AE0201	17	002, 009-099, 115-199		
D40610P	34		0034	24 GK	D40684P	6		AE0402	35	115-199		
D40610P	41		0041	22 GA	D41422P	8		AP0033	15	ALL		
D40610P	32		0082	24 GK	D41910P	4		AE0201	17	001-099		
D40610P	23	18	0205	18 GA	D41882P	10		AE0501	10	115-199		
D40610P	5		0502	22 GA	D40684P	12		AE0402	35	115-199		
D40610P	6		0520	22 GA	D42216P	5		AE0600	07	115-199		
D40610P	9		0604	22 GA	D40678P	1		AE0303	18	115-199		
D40610P	11		0605	22 GA	D40678P	2		AE0303	18	115-199		
D40610P	25		0716	22 GA	D41974P	13		AE0603	10	115-199		
D40610P	28		0717	22 GA	D40686P	3		AE0403	32	115-199		
D40610P	4		0730	22 GA	D42216P	3		AE0600	07	115-199		
D40610P	32		0732	22 GA	D42208P	4		AE0604	20	115-199		
AP0011	04	W2350	L1	DISC BKT-CIRCUIT BREAKER PANEL								
D40612P	45		0045	22 GA	D40680P	5		AE0304	23	ALL		
D40612P	49		0049	20 GA	D42216P	9		AE0600	07	115-199		
D40612P	46		0066	22 GA	D41910P	17		AE0201	17	009-099		
D40612P	47		0067	22 GA	D41910P	18		AE0201	17	009-099		
D40612P	5		0105	22 GA	D40680P	15		AE0304	23	115-199		
D40612P	23		0323	22 GA	D40684P	8		AE0402	35	115-199		
D40612P	24		0324	22 GA	D40684P	9		AE0402	35	115-199		
D40612P	16		0406	24 GK	D41422P	13		AP0033	15	ALL		
D40612P	34		0514	22 GA	D41422P	1		AP0033	15	115-199		
D40612P	36		0611	22 GA	D41422P	3		AP0033	15	115-199		
D40612P	37		0612	22 GA	D41422P	4		AP0033	15	ALL		
D40612P	38		0613	22 GA	D41422P	5		AP0033	15	ALL		
D40612P	25		0703	22 GA	D41882P	5		AE0501	10	115-199		
D40612P	39		0705	22 GA	D41882P	4		AE0501	10	115-199		
D40612P	40		0706	22 GA	D41882P	7		AE0501	10	115-199		
D40612P	41		0707	22 GA	D41422P	6		AP0033	15	115-199		
D40612P	42		0708	22 GA	D41422P	9		AP0033	15	115-199		
D40612P	43		0709	22 GA	D41422P	10		AP0033	15	115-199		
D40612P	32		0710	22 GA	D41422P	11		AP0033	15	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0011

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0011	04	W2350	L1	DISC BKT-CIRCUIT BREAKER PANEL (continued)								
D40612P	31		0712	22 GA	D41974P	14		AE0603	10	115-199		
D40612P	29		0728	22 GA	D40682P	6		AE0401	02	115-199		
D40612P	28		0729	22 GA	D40682P	7		AE0401	02	ALL		
D40612P	7		0731	22 GA	D42216P	7		AE0600	07	115-199		
D40612P	13		0733	22 GA	D42208P	3		AE0604	20	115-199		
AP0011	05	W2358	S1	DISC BKT-CIRCUIT BREAKER PANEL								
D40622P	3		0003	22 GA	D40734P	5		AE0403	15	115-199		
D40622P	24		0004	22 GA	D40734P	6		AE0403	15	115-199		
D40622P	13		0013	22 GA	D40728P	23		AP0036	27	115-199		
D40622P	22		0022	22 GA	D41964P	12		AE0301	02	115-199		
D40622P	16		0046	20 GA	D43011P	2		AE0302	19	001-099		
D40622P	16		0046	20 GA	D41962P	6		AE0601	14	115-199		
D40622P	26		0115	20 GA	D41962P	5		AE0601	14	115-199		
D40622P	17		0501	22 GA	D40728P	17		AP0036	27	115-199		
D40622P	30		0606	22 GA	D41966P	8		AE0503	04	115-199		
D40622P	28		0608	22 GA	D41964P	8		AE0301	02	115-199		
D40622P	23		0610	22 GA	D41964P	10		AE0301	02	115-199		
D40622P	20		0617	20 GA	D41884P	2		AE0203	18	115-199		
AP0011	06	W2358	S1	DISC BKT-CIRCUIT BREAKER PANEL								
D40838P	2		0020	22 GA	D40728P	8		AP0036	27	115-199		
D40838P	23		0206	20 GA	D40728P	6		AP0036	27	115-199		
AP0011	08	W2356	R1	DISC BKT-CIRCUIT BREAKER PANEL								
D41970P	5		0020	20 GA	D41408P	23		AP0037	04	115-199		
D41970P	6		0036	20 GA	D40718P	36		AP0037	38	115-199		
AP0011	09	W2360	S1	DISC BKT-CIRCUIT BREAKER PANEL								
D41972P	12		0024	24 GK	D40738P	9		AP0037	27	003-099		
D41972P	5		0515	24 GK	D40738P	15		AP0037	27	115-199		
D41972P	22		0611	22 GA	D40738P	22		AP0037	27	115-199		
D41972P	24		0613	22 GA	D40738P	24		AP0037	27	115-199		
D41972P	25		0614	22 GA	D40738P	25		AP0037	27	115-199		
AP0011	10	W2356	R1	DISC BKT-CIRCUIT BREAKER PANEL								
D40620P	4		0004	24 GK	D40718P	4		AP0037	38	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0011

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AP0011	10	W2356	R1	DISC BKT-CIRCUIT BREAKER PANEL (continued)						
D40620P	13		0013	24 GK	D40812P	1		AP0050	19	ALL
D40620P	14		0014	22 GA	D40716P	4		AP0036	20	003-099
D40620P	23		0023	22 GA	D40812P	5		AP0050	19	ALL
D40620P	24		0024	24 GK	D40718P	24		AP0037	38	ALL
D40620P	27		0027	22 GA	D40714P	3		AP0051	08	115-199
D40620P	29		0029	24 GK	D40714P	2		AP0051	08	115-199
D40620P	50		0050	24 GK	D40718P	34		AP0037	38	ALL
D40620P	52		0203	20 GA	D40714P	9		AP0051	08	115-199
D40620P	53		0204	20 GA	D40714P	10		AP0051	08	115-199
D40620P	54		0205	24 GK	D40718P	1		AP0037	38	001-099
D40620P	54		0205	20 GA	D40714P	11		AP0051	08	115-199
D40620P	55		0206	24 GK	D40718P	45		AP0037	38	001-099
D40620P	55		0206	20 GA	D40714P	12		AP0051	08	115-199
D40620P	48		0211	24 GK	D40812P	2		AP0050	19	ALL
D40620P	38		0213	20 GA	D41472P	52		AP0034	13	001-099
D40620P	42		0217	20 GA	D40716P	11		AP0036	20	115-199
D40620P	43		0218	20 GA	D40716P	12		AP0036	20	ALL
D40620P	CAP	Y	0605	20 GA	D40716P	20		AP0036	20	115-199
D40620P	35		0613	22 GA	D41424P	17		AP0033	27	115-199
D40620P	37		0614	22 GA	D41472P	47		AP0034	13	ALL
AP0011	11	W2362	C1	DISC BKT-CIRCUIT BREAKER PANEL						
D40626P	2		0002	20 GA	D41890P	2		AE0203	22	ALL
D40626P	11		0101	20 GA	D41890P	11		AE0203	22	115-199
D40626P	12		0102	20 GA	D41890P	12		AE0203	22	115-199
D40626P	13		0103	20 GA	D41890P	13		AE0203	22	115-199
D40626P	14		0104	20 GA	D41890P	14		AE0203	22	115-199
D40626P	6		0106	22 GA	D41892P	6		AE0503	08	ALL
D40626P	7		0107	22 GA	D41892P	7		AE0503	08	115-199
D40626P	8		0108	22 GA	D41892P	8		AE0503	08	ALL
AP0011	12	W2360	S1	DISC BKT-CIRCUIT BREAKER PANEL						
D40624P	1		0001	22 GA	D40738P	1		AP0037	27	ALL
D40624P	3		0603	22 GA	D41902P	3		AE0301	29	ALL
D40624P	4		0604	22 GA	D41902P	4		AE0301	29	ALL
D40624P	5		0605	22 GA	D41902P	5		AE0301	29	ALL
D40624P	16		0606	22 GA	D40738P	10		AP0037	27	115-199
D40624P	18		0608	22 GA	D40738P	7		AP0037	27	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AP0011

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0011	12	W2360	S1	DISC BKT-CIRCUIT BREAKER PANEL (continued)							
D40624P	19		0609	20 GA	D40738P	19		AP0037	27	115-199	
D40624P	6		0616	22 GA	D40736P	6		AP0051	10	115-199	
D40624P	7		0617	22 GA	D40736P	7		AP0051	10	115-199	
D40624P	8		0618	22 GA	D40736P	8		AP0051	10	115-199	
D40624P	9		0619	22 GA	D40736P	9		AP0051	10	115-199	
AP0011	13	W2354	R1	DISC BKT-CIRCUIT BREAKER PANEL							
D40618P	6	18	0004	24 GK	D41328P	14		AE0202	04	002	
D40618P	17		0019	18 GA	D40710P	9		AE0502	30	115-199	
D40618P	12		0040	22 GA	D40672P	7		AE0403	18	115-199	
D40618P	2		0058	22 GA	D40672P	6		AE0403	18	115-199	
D40618P	18		0597	22 GA	D40702P	2		AE0304	24	115-199	
D40618P	20		0598	22 GA	D40702P	3		AE0304	24	115-199	
D40618P	36		0602	22 GA	D40704P	12		AE0402	42	115-199	
D40618P	38		0603	22 GA	D41918P	5		AE0401	14	115-199	
D40618P	40		0604	22 GA	D41918P	6		AE0401	14	115-199	
D40618P	41		0605	22 GA	D41918P	8		AE0401	14	115-199	
D40618P	47		0608	22 GA	D40702P	5		AE0304	24	115-199	
D40618P	49		0610	22 GA	D40702P	6		AE0304	24	115-199	
D40618P	44		0642	22 GA	D42214P	4		AE0604	24	115-199	
D40618P	45		0644	22 GA	D42212P	5		AE0600	01	115-199	
AP0011	14	W2354	R1	DISC BKT-CIRCUIT BREAKER PANEL							
D40824P	14		0015	22 GA	D40702P	14		AE0304	24	ALL	
D40824P	24		0025	22 GA	D40704P	5		AE0402	42	115-199	
D40824P	5		0062	20 GA	D42212P	8		AE0600	01	115-199	
D40824P	6		0514	22 GA	D42212P	9		AE0600	01	115-199	
D40824P	43		0515	16 GA	D41908P	4		AE0601	18	115-199	
D40824P	20		0601	22 GA	D40704P	11		AE0402	42	115-199	
D40824P	41		0624	18 GA	D40710P	7		AE0502	30	115-199	
D40824P	38		0630	18 GA	D41908P	10		AE0601	18	115-199	
D40824P	34		0640	18 GA	D40672P	10		AE0403	18	115-199	
D40824P	2		0643	22 GA	D42214P	2		AE0604	24	115-199	
D40824P	3		0645	22 GA	D42212P	3		AE0600	01	115-199	
AP0011	16	W2364	L1	DISC BKT-CIRCUIT BREAKER PANEL							
D40748P	1		0002	24 GK	D40754J	2		AP0001	11	ALL	
D40748P	11		0003	22 GA	D40754J	3		AP0001	11	001-009, 115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0011

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0011	16	W2364	L1	DISC BKT-CIRCUIT BREAKER PANEL (continued)							
D40748P	7		0011	22 GA	D40754J	11		AP0001	11	ALL	
D40748P	24		0603	22 GA	D40754J	24		AP0001	11	ALL	
D40748P	25		0605	22 GA	D40754J	25		AP0001	11	115-199	
D40748P	26		0606	22 GA	D40754J	26		AP0001	11	115-199	
D40748P	27		0607	22 GA	D40754J	27		AP0001	11	115-199	
D40748P	28		0608	22 GA	D40754J	28		AP0001	11	115-199	
AP0011	18	W2368	S1	DISC BKT-CIRCUIT BREAKER PANEL							
D40752P	7		0607	22 GA	D40758J	7		AP0001	09	115-199	
D40752P	8		0608	22 GA	D40758J	8		AP0001	09	115-199	
D40752P	11		0611	22 GA	D40758J	11		AP0001	09	115-199	
AP0011	21	W2366	R1	DISC BKT-CIRCUIT BREAKER PANEL							
D40750P	2		0002	24 GK	D40756J	2		AP0003	11	115-199	
D40750P	19		0019	20 GA	D40756J	15		AP0003	11	ALL	
D40750P	20		0020	22 GA	D40756J	16		AP0003	11	001-099	
D40750P	20		0020	20 GA	D40756J	16		AP0003	11	115-199	
D40750P	21		0021	20 GA	D40756J	21		AP0003	11	115-199	
D40750P	24		0024	20 GA	D40756J	20		AP0003	11	115-199	
D40750P	27		0127	22 GA	D40756J	27		AP0003	11	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0011

Page 6 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0031	01	W4502	R1	DISC BKT-LEFT GEN SHIELD								
D41318P	21		0029	22	GA	D40956P	12		AP0034	04	115-199	
D41318P	7		0039	22	GA	D40394P	45		AP0032	04	115-199	
D41318P	24		0092	22	GA	D41316P	20		AP0032	05	ALL	
D41318P	27		0140	20	GA	D40956P	15		AP0034	04	001-099	
D41318P	28		0142	20	GA	D40394P	32		AP0032	04	001-099	
D41318P	3		0211	22	GA	D41748P	11		AP0037	25	ALL	
D41318P	31		0611	22	GA	D40492P	31		AE0502	12	ALL	
AP0031	04	W4500	L1	DISC BKT-LEFT GEN SHIELD								
D40392P	37		0021	22	GA	D40542P	1		AP0036	30	ALL	
D40392P	23		0609	20	GA	D40542P	3		AP0036	30	115-199	
D40392P	24		0610	20	GA	D40542P	4		AP0036	30	115-199	
D40392P	39		0613	20	GA	D41744P	8		AE0503	09	ALL	
D40392P	40		0614	20	GA	D41744P	9		AE0503	09	ALL	
D40392P	26		0616	20	GA	D41742P	3		AE0501	20	ALL	
D40392P	30		0617	20	GA	D41742P	5		AE0501	20	ALL	
AP0031	07	W3572	L1	DISC BKT-LEFT GEN SHIELD								
D41104P	3		0166	20	GA	D41120J	9		AA0409	01	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0031

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0032	01	W2370	C2	DISC BKT-RIGHT GEN SHIELD							
D41320P	6		0101	22 GA	D40300P	7		AP0006	14	ALL	
D41320P	7		0102	22 GA	D40300P	8		AP0006	14	ALL	
D41320P	8		0103	22 GA	D40300P	9		AP0006	14	115-199	
AP0032	02	W3644	R1	DISC BKT-RIGHT GEN SHIELD							
D40664P	13		0059	22 GA	D01660	9		GALLEY 2A		001-099	
D40664P	14		0060	22 GA	D01660	10		GALLEY 2A		001-099	
AP0032	03	W2070	R*	DISC BKT-RIGHT GEN SHIELD							
D40592P	14		0096	20 GA	D41412P	14		AP0033	30	001-099	
D40592P	14		0096	20 GA	D41412P	14		AP0033	10	115-199	
D40592P	6		0178	22 GA	D41856P	55		AP0037	33	ALL	
D40592P	20		0522	22 GA	D42176P	13		AP0037	05	115-199	
D40592P	21		0523	22 GA	D42176P	14		AP0037	05	115-199	
AP0032	04	W4502	R1	DISC BKT-RIGHT GEN SHIELD							
D40394P	45		0039	22 GA	D41318P	7		AP0031	01	115-199	
D40394P	46		0042	20 GA	D41750P	16		AE0503	07	ALL	
D40394P	47		0043	20 GA	D41750P	17		AE0503	07	001-099	
D40394P	52		0045	22 GA	D40956P	10		AP0034	04	001-099	
D40394P	53		0046	22 GA	D41748P	12		AP0037	25	001-099	
D40394P	54		0047	22 GA	D40956P	11		AP0034	04	001-099	
D40394P	32		0142	20 GA	D41318P	28		AP0031	01	001-099	
D40394P	32		0142	20 GA	D41748P	6		AP0037	25	115-199	
D40394P	26		0601	22 GA	D41750P	26		AE0503	07	ALL	
AP0032	05	W4502	R1	DISC BKT-RIGHT GEN SHIELD							
D41316P	21		0022	22 GA	D41748P	5		AP0037	25	ALL	
D41316P	20		0092	22 GA	D41318P	24		AP0031	01	ALL	
D41316P	5		0607	22 GA	D40492P	5		AE0502	12	ALL	
D41316P	22		0608	22 GA	D40956P	22		AP0034	04	115-199	
D41316P	23		0609	22 GA	D40956P	23		AP0034	04	115-199	
D41316P	24		0610	22 GA	D40956P	24		AP0034	04	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0032

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0033	06	W2064	L*	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41410P	28		0036	22 GA	D40582P	36		AP0036	25	001-099		
D41410P	30		0037	22 GA	D40582P	37		AP0036	25	001-099		
D41410P	15		0089	22 GA	D40798J	19		AP0005	14	001-099		
D41410P	13		0166	20 GA	D40582P	26		AP0036	25	115-199		
D41410P	16		0167	20 GA	D40582P	27		AP0036	25	115-199		
D41410P	19		0170	20 GA	D41852P	21		AP0037	10	ALL		
D41410P	20		0171	20 GA	D41852P	22		AP0037	10	ALL		
D41410P	17		0172	20 GA	D41852P	23		AP0037	10	001-099		
D41410P	21		0172	20 GA	D41852P	23		AP0037	10	115-199		
D41410P	22		0173	20 GA	D41852P	24		AP0037	10	115-199		
D41410P	23		0174	20 GA	D41852P	25		AP0037	10	115-199		
D41410P	24		0175	20 GA	D41852P	26		AP0037	10	115-199		
D41410P	25		0176	20 GA	D03505	CAP	Y	M10396		115-199		
D41410P	26		0177	20 GA	D03505	CAP	Y	M00056		001-099		
D41410P	26		0177	20 GA	D03505	CAP	Y	M10396		115-199		
D41410P	1		0260	20 GA	D40582P	15		AP0036	25	ALL		
D41410P	2		0261	20 GA	D40582P	12		AP0036	25	ALL		
AP0033	08	W2150	S2	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41096P	8		0002	20 GA	D40162J	8		AC0393	02	001-099		
D41096P	22		0007	20 GA	D40162J	22		AC0393	02	001-099		
D41096P	12		0009	20 GA	D40162J	12		AC0393	02	001-099		
AP0033	10	W2070	R*	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41412P	5		0090	20 GA	D41470P	21		AP0034	09	115-199		
D41412P	14		0096	20 GA	D40592P	14		AP0032	03	115-199		
D41412P	4		0125	24 GK	D40608P	1		AP0036	06	115-199		
D41412P	7		0439	20 GA	D03514	14		M10055		115-199		
D41412P	9		0441	20 GA	D03546	CAP	Y	M10050		115-199		
D41412P	10		0442	20 GA	D03546	CAP	Y	M10050		115-199		
D41412P	11		0443	20 GA	D03502	CAP	Y	M10063		115-199		
D41412P	16		0444	20 GA	D03502	CAP	Y	M10063		115-199		
D41412P	17		0445	20 GA	D03502	CAP	Y	M10063		115-199		
D41412P	19		0446	20 GA	D03532	CAP	Y	M10057		115-199		
D41412P	21		0447	20 GA	D03532	CAP	Y	M10057		115-199		
D41412P	22		0448	20 GA	D03532	CAP	Y	M10057		115-199		
D41412P	23		0449	20 GA	D03520	CAP	Y	M10023		115-199		
D41412P	24		0450	20 GA	D03520	CAP	Y	M10023		115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0033

Page 1

Dec 18/2007

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0033	10	W2070	R*	DISC BKT-MISCELLANEOUS RELAY PANEL (continued)								
D41412P	25		0451	20 GA	D03520	CAP	Y	M10023		115-199		
D41412P	27		0453	20 GA	D03540	CAP	Y	M10259		115-199		
D41412P	28		0454	20 GA	D03540	CAP	Y	M10259		115-199		
D41412P	30		0456	20 GA	D03704	CAP	Y	M10398		115-199		
D41412P	CAP	Y	0457	20 GA	D03704	CAP	Y	M10398		115-199		
AP0033	13	W2260	S1	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41420P	4		0603	22 GA	D40870P	8		AP0006	03	115-199		
D41420P	5		0604	22 GA	D40870P	9		AP0006	03	115-199		
D41420P	6		0605	22 GA	D40870P	10		AP0006	03	115-199		
D41420P	7		0606	22 GA	D40870P	12		AP0006	03	115-199		
D41420P	8		0607	22 GA	D40870P	14		AP0006	03	115-199		
D41420P	9		0615	20 GA	D40870P	7		AP0006	03	115-199		
AP0033	14	W2358	S1	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41426P	13		0123	22 GA	D40728P	14		AP0036	27	115-199		
D41426P	11		0124	22 GA	D40728P	15		AP0036	27	115-199		
D41426P	12		0125	22 GA	D40728P	16		AP0036	27	115-199		
D41426P	2		0507	22 GA	D40728P	3		AP0036	27	115-199		
D41426P	17		0522	22 GA	D40728P	24		AP0036	27	115-199		
AP0033	15	W2350	L1	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41422P	8		0041	22 GA	D40610P	41		AP0011	03	ALL		
D41422P	13		0406	24 GK	D40612P	16		AP0011	04	ALL		
D41422P	1		0514	22 GA	D40612P	34		AP0011	04	115-199		
D41422P	3		0611	22 GA	D40612P	36		AP0011	04	115-199		
D41422P	4		0612	22 GA	D40612P	37		AP0011	04	ALL		
D41422P	5		0613	22 GA	D40612P	38		AP0011	04	ALL		
D41422P	6		0707	22 GA	D40612P	41		AP0011	04	115-199		
D41422P	9		0708	22 GA	D40612P	42		AP0011	04	115-199		
D41422P	10		0709	22 GA	D40612P	43		AP0011	04	115-199		
D41422P	11		0710	22 GA	D40612P	32		AP0011	04	115-199		
AP0033	16	W1230	R*	DISC BKT-MISCELLANEOUS RELAY PANEL								
D42006J	14		0084	20 GA	TB0046Y	C006	BJ			115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0033

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0033	16	W4228	S2	DISC BKT-MISCELLANEOUS RELAY PANEL								
D42006P	3		0072	20 GA	D41948P	12		AP0036	22	009-099		
D42006P	27		0105	20 GA	D40002J	9		AC0880	22	115-199		
D42006P	4		0141	20 GA	D41948P	15		AP0036	22	009-099		
D42006P	10		0154	22 GA	D41944P	23		AP0054	01	ALL		
D42006P	11		0174	22 GA	D42004P	8		AP0050	08	001-099		
D42006P	12		0194	22 GA	D41948P	27		AP0036	22	ALL		
D42006P	13		0195	22 GA	D41948P	33		AP0036	22	001-099		
D42006P	14		0201	22 GA	D40002J	13		AC0880	22	001-099		
AP0033	19	W4236	S2	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41950P	15		0153	24 GK	D42014P	15		AE0304	15	001-099		
D41950P	15		0153	24 GK	D42014P	15		AE0304	28	115-199		
AP0033	21	W4212	L2	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41722P	5		0019	20 GA	D40362J	22		AD1090	22	ALL		
AP0033	22	W4204	L2B	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41626P	13		0011	22 GA	D40302J	10		AC0880	19	001-099		
D41626P	9		0048	22 GA	D41618P	2		AE0304	29	115-199		
D41626P	10		0049	22 GA	D41618P	3		AE0304	29	115-199		
AP0033	23	W2066	L*	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41870P	3	18	0268	18 GA	D40972P	14	18	AP0050	03	ALL		
D41870P	2		0269	20 GA	D40972P	15		AP0050	03	ALL		
D41870P	4		0430	22 GA	D40584P	45		AE0402	47	ALL		
D41870P	8		0439	20 GA	D40874P	25		AP0036	17	115-199		
D41870P	10		0441	20 GA	D40874P	32		AP0036	17	115-199		
D41870P	18		0445	24 GK	D40874P	39		AP0036	17	001-099		
D41870P	30		0553	22 GA	D03512	CAP	Y	M10055		115-199		
AP0033	24	W4202	L2A	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41704P	9		0001	20 GA	D40346J	29		AC1090	19	ALL		
D41704P	8		0002	22 GA	D41610P	13		AE0304	10	001-099		
D41704P	7		0003	20 GA	D40898P	29		AW1180	02	001-099		
D41704P	7		0003	20 GA	D40898J	32		AW1180	02	115-199		
D41704P	19		0008	20 GA	D41612P	14		AP0036	28	ALL		
D41704P	1		0010	20 GA	D41610P	1		AE0304	10	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0033

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0033	24	W4202	L2A	DISC BKT-MISCELLANEOUS RELAY PANEL (continued)								
D41704P	29		0029	20 GA	D41610P	30		AE0304	10	001-099		
AP0033	25	W2256	L1	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41416P	14		0026	20 GA	D40866P	27		AP0006	10	115-199		
D41416P	15		0027	20 GA	D40910P	18		AP0036	04	115-199		
D41416P	16		0028	20 GA	D40910P	19		AP0036	04	115-199		
D41416P	6		0601	20 GA	D40866P	9		AP0006	10	115-199		
D41416P	5		0604	20 GA	D40910P	9		AP0036	04	115-199		
AP0033	26	W2078	S*	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41414P	3		0026	22 GA	D40570P	2		AP0037	06	001-099		
D41414P	23		0336	20 GA	D41850P	34		AP0036	14	001-099		
D41414P	24		0337	20 GA	D41850P	35		AP0036	14	001-099		
D41414P	25		0358	20 GA	D03501	CAP	Y	M10056		115-199		
D41414P	26		0359	20 GA	D03501	CAP	Y	M10056		115-199		
D41414P	27		0360	20 GA	D03528	CAP	Y	M10397		115-199		
D41414P	28		0361	20 GA	D03528	CAP	Y	M10397		115-199		
D41414P	29		0362	20 GA	D03528	CAP	Y	M10397		115-199		
D41414P	30		0363	20 GA	D03528	CAP	Y	M10397		115-199		
D41414P	31		0364	20 GA	D03528	CAP	Y	M10397		115-199		
D41414P	32		0365	20 GA	D02696	CAP	Y	M00019		115-199		
D41414P	33		0366	20 GA	D02696	CAP	Y	M00019		115-199		
D41414P	34		0367	20 GA	D02696	CAP	Y	M00019		115-199		
D41414P	35		0368	20 GA	D02696	CAP	Y	M00019		115-199		
D41414P	36		0369	20 GA	D02696	CAP	Y	M00019		115-199		
D41414P	37		0370	20 GA	D03734	CAP	Y	M10401		115-199		
D41414P	38		0371	20 GA	D03734	CAP	Y	M10401		ALL		
D41414P	39		0372	20 GA	D03734	CAP	Y	M10401		ALL		
D41414P	40		0373	20 GA	D40296P	13		AP0006	01	ALL		
D41414P	41		0374	20 GA	D40296P	17		AP0006	01	ALL		
D41414P	42		0375	20 GA	D40296P	18		AP0006	01	115-199		
D41414P	43		0376	20 GA	D40296P	19		AP0006	01	115-199		
D41414P	44		0377	20 GA	D41380P	1		AP0050	17	ALL		
D41414P	45		0378	20 GA	D41380P	2		AP0050	17	ALL		
D41414P	46		0379	20 GA	D41380P	3		AP0050	17	115-199		
D41414P	47		0380	20 GA	D41174J	2		AP0003	15	ALL		
D41414P	48		0381	20 GA	D41174J	3		AP0003	15	ALL		
D41414P	49		0382	20 GA	D41878J	8		AP0003	14	001-008, 115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0033

Page 4

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0033	27	W2356	R1	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41424P	4		0283	22 GA	D40812P	6		AP0050	19	115-199		
D41424P	11		0308	20 GA	D40718P	8		AP0037	38	115-199		
D41424P	12		0309	20 GA	D40718P	9		AP0037	38	115-199		
D41424P	13		0343	20 GA	D40718P	43		AP0037	38	115-199		
D41424P	24		0345	20 GA	D40718P	45		AP0037	38	115-199		
D41424P	15		0355	20 GA	D40718P	55		AP0037	38	115-199		
D41424P	17		0613	22 GA	D40620P	35		AP0011	10	115-199		
AP0033	28	W4208	R1B	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41692P	3		0037	22 GA	D40342J	6		AC1090	21	001-099		
D41692P	12		0041	22 GA	D41694P	33		AE0502	24	ALL		
D41692P	13		0042	22 GA	D41694P	34		AE0502	24	ALL		
AP0033	29	W1230	R*	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41718J	1		0085	20 GA	TB0046Y	C005	BJ			115-199		
D41718J	2		0086	22 GA	TB0046Y	C005	BJ			115-199		
D41718J	CAP	Y	0151	22 GA	TB0046Y	C005	BJ			115-199		
AP0033	29	W4216	R2A	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41718P	5		0073	22 GA	D40334J	26		AD0880	06	001-099		
D41718P	32		0108	20 GA	D40930P	35		AW2180	01	001-099		
D41718P	32		0108	20 GA	D40334J	48		AD0880	06	115-199		
D41718P	33		0109	20 GA	D40334J	49		AD0880	06	ALL		
D41718P	34		0110	20 GA	D40334J	50		AD0880	06	ALL		
D41718P	35		0111	20 GA	D40332J	18		AD0880	07	ALL		
D41718P	36		0112	20 GA	D40332J	19		AD0880	07	ALL		
AP0033	30	W2070	R*	DISC BKT-MISCELLANEOUS RELAY PANEL								
D41412P	5		0090	20 GA	D41470P	21		AP0034	09	001-099		
D41412P	14		0096	20 GA	D40592P	14		AP0032	03	001-099		
D41412P	4		0125	24 GK	D40608P	1		AP0036	06	001-099		
D41412P	7		0439	20 GA	D03514	CAP	Y	M10055		001-099		
D41412P	10		0442	20 GA	D03546	CAP	Y	M10050		001-099		
D41412P	23		0449	20 GA	D03520	CAP	Y	M10023		001-099		
D41412P	24		0450	20 GA	D03520	CAP	Y	M10023		001-099		
D41412P	25		0451	20 GA	D03704	CAP	Y	M10398		001-099		
D41412P	28		0454	20 GA	D03540	CAP	Y	M10259		001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0033

Page 5

Dec 18/2007



From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0033	30	W2070	R*	DISC BKT-MISCELLANEOUS RELAY PANEL (continued)								
D41412P	30		0456	20	GA	D03704	CAP	Y	M10398		001-099	
D41412P	32		0474	22	GA	D41856P	38		AP0037	33	001-099	
D41412P	33		0475	22	GA	D41856P	44		AP0037	33	001-099	
D41412P	34		0476	22	GA	D41856P	47		AP0037	33	001-099	
D41412P	35		0477	22	GA	D41856P	52		AP0037	33	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0033

Page 6 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0034	01	W2602	R1	DISC BKT-APU/EXT POWER SHIELD								
D40188P	2		0019	22 GA	D40176J	14		AB1210	02	001-099		
D40188P	3		0020	18 GA	D40178J	18		AB1210	01	001-099		
D40188P	6		0021	18 GA	D40178J	4		AB1210	01	001-099		
D40188P	9		0036	18 GA	D40178J	19		AB1210	01	001-099		
D40188P	5		0059	20 GA	D40176J	33		AB1210	02	001-099		
D40188P	8		0060	20 GA	D40176J	12		AB1210	02	001-099		
AP0034	02	W4104	R1	DISC BKT-APU/EXT POWER SHIELD								
D40080P	6		0068	22 GA	D41922J	2		AP0065	01	001-099		
D40080P	7		0069	18 GA	D41922J	9		AP0065	01	001-099		
D40080P	8		0070	18 GA	D41922J	10		AP0065	01	001-099		
D40080P	9		0071	18 GA	D41922J	11		AP0065	01	001-099		
AP0034	03	W4504	A1	DISC BKT-APU/EXT POWER SHIELD								
D40400P	11	18	0062	18 GA	D41900P	46	18	AE0503	06	115-199		
D40400P	1		0606	20 GA	D41900P	51		AE0503	06	ALL		
D40400P	12		0607	20 GA	D41900P	52		AE0503	06	ALL		
D40400P	43		0609	20 GA	D40978P	16		AP0037	08	ALL		
AP0034	04	W4502	R1	DISC BKT-APU/EXT POWER SHIELD								
D40956P	12		0029	22 GA	D41318P	21		AP0031	01	115-199		
D40956P	10		0045	22 GA	D40394P	52		AP0032	04	001-099		
D40956P	11		0047	22 GA	D40394P	54		AP0032	04	001-099		
D40956P	16	16	0062	16 GA	D41748P	27		AP0037	25	ALL		
D40956P	17		0088	24 GK	D41748P	16		AP0037	25	ALL		
D40956P	15		0140	20 GA	D41318P	27		AP0031	01	001-099		
D40956P	27		0605	22 GA	D41748P	29		AP0037	25	ALL		
D40956P	28		0606	22 GA	D41748P	30		AP0037	25	ALL		
D40956P	22		0608	22 GA	D41316P	22		AP0032	05	115-199		
D40956P	23		0609	22 GA	D41316P	23		AP0032	05	115-199		
D40956P	24		0610	22 GA	D41316P	24		AP0032	05	115-199		
AP0034	05	W4504	A1	DISC BKT-APU/EXT POWER SHIELD								
D41326P	11		0056	22 GA	D41900P	48		AE0503	06	115-199		
D41326P	12		0060	22 GA	D41900P	47		AE0503	06	ALL		
D41326P	28	18	0061	18 GA	D40978P	5		AP0037	08	115-199		
D41326P	5		0601	20 GA	D41900P	49		AE0503	06	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0034

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0034	05	W4504	A1	DISC BKT-APU/EXT POWER SHIELD (continued)								
D41326P	6		0602	20 GA	D41900P	50		AE0503	06	115-199		
D41326P	7		0603	20 GA	D40978P	11		AP0037	08	115-199		
D41326P	8		0604	20 GA	D40978P	13		AP0037	08	115-199		
D41326P	9		0605	20 GA	D40978P	14		AP0037	08	115-199		
AP0034	09	W2070	R*	DISC BKT-APU/EXT POWER SHIELD								
D41470P	28		0015	20 GA	D40590P	4		AE0503	14	ALL		
D41470P	32		0016	22 GA	D41876P	25		AE0304	09	001-099		
D41470P	32		0016	22 GA	D41876P	25		AE0304	10	115-199		
D41470P	21		0090	20 GA	D41412P	5		AP0033	30	001-099		
D41470P	21		0090	20 GA	D41412P	5		AP0033	10	115-199		
D41470P	CAP	Y	0124	22 GA	D41058P	34		AE0402	22	115-199		
D41470P	29		0261	22 GA	D40590P	29		AE0503	14	ALL		
D41470P	34		0513	22 GA	D42166P	7		AP0070	03	ALL		
D41470P	35		0514	22 GA	D42166P	8		AP0070	03	ALL		
D41470P	36		0518	22 GA	D42176P	9		AP0037	05	115-199		
D41470P	37		0519	22 GA	D42176P	10		AP0037	05	115-199		
AP0034	10	W2356	R1	DISC BKT-APU/EXT POWER SHIELD								
D41476P	1		0248	18 GA	D41408P	28		AP0037	04	115-199		
D41476P	2		0249	18 GA	D41408P	29		AP0037	04	115-199		
D41476P	4		0251	18 GA	D41408P	31		AP0037	04	115-199		
D41476P	5		0284	18 GA	D41408P	15		AP0037	04	115-199		
D41476P	6		0285	18 GA	D41408P	22		AP0037	04	115-199		
D41476P	7		0286	18 GA	D41408P	27		AP0037	04	115-199		
D41476P	11		0332	22 GA	D41408P	20		AP0037	04	115-199		
D41476P	14		0612	18 GA	D41408P	40		AP0037	04	115-199		
AP0034	11	W3514	R1	DISC BKT-APU/EXT POWER SHIELD								
D40376P	8		0308	20 GA	D41714J	8		D41714P		001-099		
D40376P	9		0309	20 GA	D41714J	9		D41714P		001-099		
D40376P	12		0312	20 GA	D41714J	12		D41714P		001-099		
AP0034	12	W2072	R*	DISC BKT-APU/EXT POWER SHIELD								
D41848P	9		0117	20 GA	D41872P	9		AE0101	14	ALL		
D41848P	10		0118	20 GA	D41872P	10		AE0101	14	ALL		
D41848P	11		0119	20 GA	D41872P	11		AE0101	14	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0034

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0034	12	W2072	R*	DISC BKT-APU/EXT POWER SHIELD (continued)								
D41848P	12		0120	20 GA	D41872P	12		AE0101	14	115-199		
AP0034	13	W2356	R1	DISC BKT-APU/EXT POWER SHIELD								
D41472P	46		0054	22 GA	D40716P	2		AP0036	20	115-199		
D41472P	6		0055	22 GA	D40716P	3		AP0036	20	115-199		
D41472P	52		0213	20 GA	D40620P	38		AP0011	10	001-099		
D41472P	3		0234	22 GA	D40718P	29		AP0037	38	ALL		
D41472P	4		0244	22 GA	D40718P	32		AP0037	38	ALL		
D41472P	5		0245	20 GA	D40718P	40		AP0037	38	115-199		
D41472P	10		0253	22 GA	D41408P	43		AP0037	04	115-199		
D41472P	17		0262	22 GA	D41408P	1		AP0037	04	115-199		
D41472P	25	18	0270	18 GA	D40716P	10	18	AP0036	20	115-199		
D41472P	27		0272	22 GA	D41408P	8		AP0037	04	115-199		
D41472P	30		0275	22 GA	D41408P	11		AP0037	04	001-099		
D41472P	31		0276	22 GA	D41408P	12		AP0037	04	001-099		
D41472P	42		0293	22 GA	D40718P	51		AP0037	38	115-199		
D41472P	54		0324	20 GA	D41408P	24		AP0037	04	115-199		
D41472P	55		0325	20 GA	D41408P	25		AP0037	04	115-199		
D41472P	47		0614	22 GA	D40620P	37		AP0011	10	ALL		
AP0034	15	W3614	R1	DISC BKT-APU/EXT POWER SHIELD								
D40476P	8		0308	20 GA	D41814J	8		D41814P		001-099		
D40476P	9		0309	20 GA	D41814J	9		D41814P		001-099		
D40476P	12		0312	20 GA	D41814J	12		D41814P		001-099		
AP0034	16	W3576	R1	DISC BKT-APU/EXT POWER SHIELD								
D41474P	23		0050	22 GA	D41702J	9		AE0404	07	115-199		
D41474P	29		0072	24 GK	D42052J	11		D42052P		001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0034

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0036	02	W4471	L2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL							
D41475P	7		0162	24 GK	D41319P	20		AE0403	12	001-099	
D41475P	1		0182	24 GK	D41093P	49		AE0201	37	115-199	
D41475P	2		0183	24 GK	D41093P	50		AE0201	37	ALL	
D41475P	4		0187	24 GK	D41879P	17		AE0402	38	001-099	
D41475P	5		0190	24 GK	D41879P	20		AE0402	38	115-199	
D41475P	38		0271	22 GA	D41329P	23		AE0503	17	001-099	
D41475P	10		2014B	24 GL	D41307P	25		AE0303	13	115-199	
D41475P	9		2014R	24 GL	D41307P	24		AE0303	13	115-199	
AP0036	03	W2650	A2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL							
D42080P	6		0002	24 GK	D41662P	24		AE0602	07	001-099	
D42080P	10		0068	22 GA	D41662P	26		AE0602	07	001-099	
D42080P	9		0071	22 GA	D41680P	23		AE0600	03	001-099	
D42080P	11		0072	22 GA	D41660P	28		AE0402	21	001-099	
AP0036	04	W2256	L1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL							
D40910P	12		0006	20 GA	D40866P	18		AP0006	10	115-199	
D40910P	13		0008	20 GA	D40866P	19		AP0006	10	115-199	
D40910P	16		0011	20 GA	D40866P	22		AP0006	10	115-199	
D40910P	18		0027	20 GA	D41416P	15		AP0033	25	115-199	
D40910P	19		0028	20 GA	D41416P	16		AP0033	25	115-199	
D40910P	20		0033	20 GA	D41746P	5		AP0070	02	115-199	
D40910P	25		0037	20 GA	D41746P	9		AP0070	02	115-199	
D40910P	5		0603	20 GA	D40866P	11		AP0006	10	115-199	
D40910P	9		0604	20 GA	D41416P	5		AP0033	25	115-199	
D40910P	11		0606	20 GA	D41746P	19		AP0070	02	115-199	
D40910P	27		0607	20 GA	D41746P	12		AP0070	02	115-199	
D40910P	28		0608	20 GA	D41746P	13		AP0070	02	115-199	
D40910P	29		0609	20 GA	D41746P	16		AP0070	02	115-199	
D40910P	30		0610	20 GA	D41746P	15		AP0070	02	115-199	
D40910P	1		0613	14 GA	D40866P	8		AP0006	10	115-199	
AP0036	05	W4006	L2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL							
D41544P	13		0136	24 GK	D40630J	48		AC0820	02	115-199	
D41544P	14		0138	22 GA	D40846P	20		AE0303	24	001-099	
D41544P	14		0138	22 GA	D40632J	43		AC0820	03	115-199	
D41544P	53		0235	24 GK	D40630J	18		AC0820	02	115-199	
D41544P	51		0261	24 GK	D40630J	32		AC0820	02	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0036	05	W4006	L2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)								
D41544P	50		0272	22	GA	D41664P	1		AE0402	09	001-099	
D41544P	50		0272	22	GA	D41664P	30		AE0402	09	115-199	
D41544P	2		0302	22	GA	D40632J	32		AC0820	03	115-199	
D41544P	52		1001	22	GT	D40630J	40		AC0820	02	115-199	
D41544P	DED		1001Z			D40630J	DED		AC0820	02	115-199	
AP0036	06	W2070	R*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40608P	1		0125	24	GK	D41412P	4		AP0033	30	001-099	
D40608P	1		0125	24	GK	D41412P	4		AP0033	10	115-199	
D40608P	30		0146	24	GK	D40970P	12		AP0050	05	115-199	
D40608P	39		0385	22	GA	D41860P	4		AP0037	11	ALL	
D40608P	38		0387	22	GA	D41860P	6		AP0037	11	115-199	
D40608P	13		0402	20	GA	D41860P	13		AP0037	11	001-099	
D40608P	14		0403	22	GA	D41860P	14		AP0037	11	ALL	
D40608P	15		0404	20	GA	D41860P	15		AP0037	11	115-199	
D40608P	16		0405	20	GA	D41860P	16		AP0037	11	115-199	
D40608P	CAP	Y	0409	20	GA	D41860P	20		AP0037	11	115-199	
D40608P	21		0421	20	GA	D03546	CAP	Y	M10050		115-199	
D40608P	CAP	Y	0422	20	GA	D03546	CAP	Y	M10050		115-199	
D40608P	23		0423	20	GA	D03704	CAP	Y	M10398		115-199	
D40608P	24		0424	20	GA	D03502	CAP	Y	M10063		115-199	
D40608P	25		0425	20	GA	D03502	CAP	Y	M10063		115-199	
D40608P	CAP	Y	0426	20	GA	D03540	CAP	Y	M10259		115-199	
D40608P	29		0429	20	GA	D03546	CAP	Y	M10050		115-199	
D40608P	34		0433	20	GA	D40970P	29		AP0050	05	ALL	
AP0036	07	W4006	L2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40060P	49		0135	24	GK	D40846P	18		AE0303	24	001-099	
D40060P	41		0273	22	GA	D40630J	43		AC0820	02	115-199	
D40060P	44		0301	22	GA	D40632J	44		AC0820	03	115-199	
D40060P	34		0303	22	GA	D40632J	33		AC0820	03	115-199	
AP0036	08	W2152	L1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40390P	5		0020	18	GA	D40388J	L		AC0393	03	115-199	
D40390P	6		0033	20	GA	D40388J	L		AC0393	03	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0036	10	W2634	L1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40206P	8		0021	20 GA	D41924P	11		AE0501	08	115-199		
D40206P	9		0022	20 GA	D41924P	12		AE0501	08	115-199		
D40206P	10		0023	20 GA	D41942P	5		AP0070	04	115-199		
AP0036	11	W4424	S2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41024P	2		0002	24 GK	D41034P	2		AP0037	32	115-199		
D41024P	4		0004	20 GA	D41034P	4		AP0037	23	001-099		
D41024P	4		0004	20 GA	D41034P	4		AP0037	32	115-199		
D41024P	5		0005	24 GK	D41034P	5		AP0037	32	115-199		
D41024P	6		0006	24 GK	D41034P	6		AP0037	32	115-199		
D41024P	7		0007	20 GA	D41034P	7		AP0037	32	115-199		
D41024P	10		0010	24 GK	D41034P	10		AP0037	32	115-199		
D41024P	15		0015	22 GA	D41034P	15		AP0037	23	001-099		
D41024P	16		0016	22 GA	D41034P	16		AP0037	23	001-099		
D41024P	18		0018	24 GK	D41034P	18		AP0037	23	001-099		
D41024P	19		0019	22 GA	D41034P	19		AP0037	23	001-099		
D41024P	20		0020	22 GA	D41034P	20		AP0037	23	001-099		
D41024P	22		0022	22 GA	D41034P	22		AP0037	23	001-099		
D41024P	22		0022	22 GA	D41034P	22		AP0037	32	115-199		
D41024P	24		0024	22 GA	D41034P	24		AP0037	23	001-099		
D41024P	24		0024	22 GA	D41034P	24		AP0037	32	115-199		
D41024P	25		0025	22 GA	D41034P	25		AP0037	23	001-099		
D41024P	25		0025	22 GA	D41034P	25		AP0037	32	115-199		
D41024P	30		0030	24 GK	D41034P	30		AP0037	23	001-099		
D41024P	32		0041	22 GA	D41034P	32		AP0037	23	003-099		
D41024P	33		0042	22 GA	D41034P	33		AP0037	23	003-099		
D41024P	34		0043	20 GA	D41034P	34		AP0037	23	003-099		
D41024P	35		0044	20 GA	D41034P	35		AP0037	23	003-099		
D41024P	36		0045	20 GA	D41034P	36		AP0037	23	003-099		
AP0036	12	W1260	L*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41497J	3		5644	24 GK	D00582	3		K00124		115-199		
D41497J	4		5646	24 GK	D02768	1		K00419		115-199		
AP0036	12	W4477	S2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41497P	1		0001	24 GK	D41451P	1		AE0402	12	115-199		
D41497P	12		0055	24 GK	D41059P	24		AP0051	03	ALL		
D41497P	13		0084	22 GA	D41453P	38		AE0403	07	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0036	12	W4477	S2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)								
D41497P	16		0095	22 GA	D41433P	30		AE0203	03	115-199		
D41497P	17		0096	22 GA	D41433P	31		AE0203	03	115-199		
D41497P	26		0133	24 GK	D41453P	1		AE0403	07	ALL		
D41497P	22		0142	24 GK	D41433P	42		AE0203	03	115-199		
D41497P	23		0143	24 GK	D41059P	35		AP0051	03	115-199		
D41497P	28		0165	24 GK	D42185P	10		AE0402	24	115-199		
D41497P	29		0166	22 GA	D41443P	44		AE0303	08	001-099		
D41497P	31		0177	24 GK	D41461P	21		AE0502	28	115-199		
D41497P	36		0192	22 GA	D41459P	12		AE0501	03	115-199		
D41497P	35		0193	22 GA	D41463P	13		AE0503	05	115-199		
D41497P	3		0210	22 GA	D41459P	21		AE0501	03	001-099		
D41497P	35		0228	24 GK	D41461P	14		AE0502	28	001-099		
AP0036	13	W4210	S2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41958P	38		0001	22 GA	D40006J	40		AC0880	15	115-199		
D41958P	39		0002	22 GA	D40006J	41		AC0880	15	115-199		
D41958P	CAP	Y	0082	22 GA	D42016P	27		AE0304	03	001-099		
D41958P	CAP	Y	0084	22 GA	D41986P	21		AP0054	05	115-199		
D41958P	CAP	Y	0085	22 GA	D41986P	22		AP0054	05	115-199		
D41958P	CAP	Y	0103	22 GA	D41734P	47		AE0402	41	115-199		
D41958P	43		0104	22 GA	D41686P	18		AE0604	09	115-199		
D41958P	45		0111	22 GA	D41734P	52		AE0402	41	001-099		
D41958P	51		0118	24 GK	D41686P	20		AE0604	09	115-199		
D41958P	52		0119	24 GK	D41686P	21		AE0604	09	115-199		
D41958P	53		0135	22 GA	TB0116Y	C006	BJ			001-099		
D41958P	1		0147	22 GA	D40022P	10		AP0070	06	ALL		
AP0036	14	W2078	S*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41850P	25		0327	20 GA	D40570P	25		AP0037	06	115-199		
D41850P	34		0336	20 GA	D41414P	23		AP0033	26	001-099		
D41850P	35		0337	20 GA	D41414P	24		AP0033	26	001-099		
D41850P	37		0339	20 GA	D41844P	17		AE0402	20	115-199		
D41850P	38		0340	20 GA	D41844P	18		AE0402	20	115-199		
D41850P	39		0341	20 GA	D41844P	19		AE0402	20	115-199		
D41850P	40		0342	20 GA	D41844P	20		AE0402	20	115-199		
D41850P	42		0344	20 GA	D40600P	3		AE0502	09	115-199		
D41850P	43		0345	22 GA	D40600P	12		AE0502	09	001-099		
D41850P	43		0345	20 GA	D40600P	4		AE0502	09	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 4

Dec 18/2007

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0036	14	W2078	S*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)								
D41850P	44		0346	22 GA	D03511	11		M10250		115-199		
D41850P	50		0352	20 GA	D03501	CAP	Y	M10056		115-199		
D41850P	51		0353	20 GA	D03528	CAP	Y	M10397		115-199		
D41850P	52		0354	20 GA	D03528	CAP	Y	M10397		115-199		
D41850P	54		0356	20 GA	D03734	CAP	Y	M10401		ALL		
D41850P	55		0357	20 GA	D40296P	31		AP0006	01	115-199		
AP0036	16	W2260	S1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40914P	5		0055	20 GA	D40870P	5		AP0006	03	001-002		
D40914P	5		0055	20 GA	D40870P	5		AP0006	07	003-099		
D40914P	2		0609	22 GA	D40870P	18		AP0006	03	115-199		
D40914P	4		0611	20 GA	D40870P	22		AP0006	03	115-199		
D40914P	9		0614	20 GA	D40870P	6		AP0006	03	115-199		
AP0036	17	W2066	L*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40874P	22		0154	24 GK	D40996P	19		AE0304	21	001-099		
D40874P	18		0240	24 GK	D40584P	12		AE0402	47	ALL		
D40874P	25		0439	20 GA	D41170J	8		AP0003	03	001-099		
D40874P	25		0439	20 GA	D41870P	8		AP0033	23	115-199		
D40874P	32		0441	20 GA	D41170J	10		AP0003	03	001-099		
D40874P	32		0441	20 GA	D41870P	10		AP0033	23	115-199		
D40874P	39		0445	24 GK	D41870P	18		AP0033	23	001-099		
D40874P	41		0505	20 GA	D03702	CAP	Y	M10398		ALL		
D40874P	44		0508	20 GA	D03538	CAP	Y	M10259		001-099		
D40874P	44		0508	20 GA	D02344	CAP	Y	M00013		115-199		
D40874P	45		0509	20 GA	D03538	CAP	Y	M10259		001-099		
D40874P	45		0509	20 GA	D02344	CAP	Y	M00013		115-199		
D40874P	47		0511	20 GA	D03538	CAP	Y	M10259		ALL		
D40874P	48		0512	20 GA	D41854P	28		AP0037	47	ALL		
AP0036	18	W4420	L2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41020P	1		0001	22 GA	D41030P	1		AP0037	37	ALL		
D41020P	2		0002	22 GA	D41030P	2		AP0037	37	115-199		
D41020P	6		0006	24 GK	D41030P	6		AP0037	37	ALL		
D41020P	12		0012	22 GA	D41030P	12		AP0037	37	115-199		
D41020P	14		0014	20 GA	D41030P	14		AP0037	37	001-099		
D41020P	18		0018	20 GA	D41030P	18		AP0037	37	115-199		
D41020P	22		0022	24 GK	D41030P	22		AP0037	37	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 5

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0036	18	W4420	L2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)								
D41020P	23		0023	20	GA	D41030P	23		AP0037	37	115-199	
D41020P	24		0024	20	GA	D41030P	24		AP0037	37	115-199	
D41020P	25		0025	20	GA	D41030P	25		AP0037	37	115-199	
D41020P	26		0026	20	GA	D41030P	26		AP0037	37	115-199	
D41020P	27		0027	22	GA	D41030P	27		AP0037	37	ALL	
D41020P	28		0028	22	GA	D41030P	28		AP0037	37	ALL	
D41020P	29		0029	22	GA	D41030P	29		AP0037	37	115-199	
D41020P	30		0030	24	GK	D41030P	30		AP0037	37	ALL	
D41020P	33		0033	22	GA	D41030P	33		AP0037	37	115-199	
D41020P	34		0034	22	GA	D41030P	34		AP0037	37	115-199	
D41020P	35		0035	24	GK	D41030P	35		AP0037	37	115-199	
D41020P	36		0036	22	GA	D41030P	36		AP0037	37	115-199	
D41020P	37		0037	22	GA	D41030P	37		AP0037	37	115-199	
D41020P	38		0038	22	GA	D41030P	38		AP0037	37	115-199	
D41020P	39		0039	22	GA	D41030P	39		AP0037	37	115-199	
D41020P	40		0040	24	GK	D41030P	40		AP0037	37	ALL	
D41020P	42		0042	24	GK	D41030P	42		AP0037	37	115-199	
D41020P	44		0044	22	GA	D41030P	44		AP0037	37	115-199	
D41020P	45		0045	22	GA	D41030P	45		AP0037	37	115-199	
D41020P	46		0046	22	GA	D41030P	46		AP0037	37	ALL	
D41020P	47		0047	24	GK	D41030P	47		AP0037	37	001-099	
D41020P	48		0048	24	GK	D41030P	48		AP0037	37	001-099	
D41020P	49		0049	24	GK	D41030P	49		AP0037	37	115-199	
D41020P	53		0053	20	GA	D41030P	53		AP0037	37	115-199	
D41020P	54		0054	20	GA	D41030P	CAP	Y	AP0037	37	115-199	
D41020P	55		0055	20	GA	D41030P	CAP	Y	AP0037	37	115-199	
AP0036	20	W2356	R1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40716P	4		0014	22	GA	D40620P	14		AP0011	10	003-099	
D40716P	2		0054	22	GA	D41472P	46		AP0034	13	115-199	
D40716P	3		0055	22	GA	D41472P	6		AP0034	13	115-199	
D40716P	11		0217	20	GA	D40620P	42		AP0011	10	115-199	
D40716P	12		0218	20	GA	D40620P	43		AP0011	10	ALL	
D40716P	10	18	0270	18	GA	D41472P	25	18	AP0034	13	115-199	
D40716P	8		0330	22	GA	D41408P	18		AP0037	04	115-199	
D40716P	14		0331	22	GA	D41408P	CAP	Y	AP0037	04	115-199	
D40716P	20		0605	20	GA	D40620P	CAP	Y	AP0011	10	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 6

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0036	21	W4471	L2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41473P	3		0013	24	GK	D41309P	12		AE0303	05	001-099	
D41473P	7		0022	24	GK	D41481P	7		AP0051	01	115-199	
D41473P	14		0049	22	GA	D41311P	2		AE0304	29	001-099	
D41473P	20		0083	24	GK	D41317P	38		AE0402	07	ALL	
D41473P	28		0093	24	GK	D41317P	45		AE0402	07	ALL	
D41473P	33		0113	24	GK	D41905P	5		AE0201	35	001-099	
D41473P	52		0137	22	GA	D41099P	17		AE0204	20	001-099	
D41473P	47		0146	24	GK	D41093P	34		AE0201	37	ALL	
D41473P	51		0161	24	GK	D41317P	9		AE0402	07	115-199	
D41473P	52		0165	22	GA	D41329P	16		AE0503	17	115-199	
D41473P	10		0166	24	GK	D41309P	52		AE0303	05	001-009, 115-199	
D41473P	53		0170	24	GK	D41481P	25		AP0051	01	ALL	
D41473P	54		0185	24	GK	D41879P	16		AE0402	38	ALL	
D41473P	42		0192	22	GA	D41099P	8		AE0204	20	001-099	
D41473P	38		0253	22	GA	D42187P	18		AE0501	17	001-099	
D41473P	2		2001B	24	GL	D41309P	11		AE0303	05	001-099	
D41473P	1		2001R	24	GL	D41309P	10		AE0303	05	001-099	
D41473P	5		2002B	24	GL	D41309P	14		AE0303	05	001-009	
D41473P	4		2002R	24	GL	D41309P	13		AE0303	05	001-009	
D41473P	49		5048B	24	G2	D41099P	28		AE0204	20	001-099	
D41473P	27		5048B	24	G2	D41099P	28		AE0204	20	115-199	
D41473P	48		5048R	24	G2	D41099P	27		AE0204	20	001-099	
D41473P	14		5048R	24	G2	D41099P	27		AE0204	20	115-199	
D41473P	50		5048Z			D41099P	29		AE0204	20	001-099	
D41473P	33		5048Z			D41099P	29		AE0204	20	115-199	
AP0036	22	W4228	S2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41948P	6		0046	22	GA	D40901P	CAP	Y	AP0010	01	001-002, 115-199	
D41948P	7		0047	22	GA	D40901P	CAP	Y	AP0010	01	001-002, 115-199	
D41948P	10		0067	20	GA	D42004P	4		AP0050	08	ALL	
D41948P	11		0068	20	GA	D42004P	5		AP0050	08	115-199	
D41948P	12		0072	20	GA	D42006P	3		AP0033	16	009-099	
D41948P	14		0094	20	GA	D40002J	10		AC0880	22	115-199	
D41948P	11		0096	22	GA	D40014J	12		AC0880	23	001-099	
D41948P	15		0141	20	GA	D42006P	4		AP0033	16	009-099	
D41948P	19		0149	22	GA	D42012P	11		AE0304	12	001-099	
D41948P	19		0149	22	GA	D41944P	43		AP0054	01	115-199	
D41948P	20		0150	22	GA	D41944P	44		AP0054	01	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 7

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0036	22	W4228	S2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)								
D41948P	22		0151	22 GA	D41944P	45		AP0054	01	115-199		
D41948P	23		0152	22 GA	D41944P	46		AP0054	01	ALL		
D41948P	27		0194	22 GA	D42006P	12		AP0033	16	ALL		
D41948P	33		0195	22 GA	D42006P	13		AP0033	16	001-099		
D41948P	48		2510B	20 GU	D40002J	26		AC0880	22	001-099		
D41948P	25		2510R	20 GU	D40002J	27		AC0880	22	001-099		
D41948P	26		2510Z		D40002J	28		AC0880	22	001-099		
AP0036	23	W4230	S2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41938P	12		0035	24 GK	D41764P	15		AE0402	23	001-099		
AP0036	24	W2156	S*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41060P	8		0016	22 GA	D40808J	4		AP0005	34	001-099		
D41060P	10		0125	22 GA	D41858P	1		AP0037	43	ALL		
D41060P	14		0127	22 GA	D41858P	5		AP0037	43	ALL		
D41060P	17		0130	20 GA	D40808J	29		AP0005	34	001-099		
D41060P	19		0131	20 GA	D40808J	CAP	Y	AP0005	34	001-002		
D41060P	19		0131	20 GA	D40808J	13		AP0005	34	003-099		
D41060P	19		0131	20 GA	D41858P	CAP	Y	AP0037	43	115-199		
D41060P	21		0132	16 GA	D03530	CAP	Y	M10397		115-199		
D41060P	22		0133	20 GA	D41858P	14		AP0037	43	115-199		
D41060P	36		0134	20 GA	D41858P	15		AP0037	43	115-199		
D41060P	24		0135	20 GA	D41858P	16		AP0037	43	115-199		
D41060P	25		0136	20 GA	D41858P	17		AP0037	43	115-199		
D41060P	26		0137	20 GA	D41858P	18		AP0037	43	115-199		
D41060P	27		0138	20 GA	D41858P	19		AP0037	43	115-199		
D41060P	28		0139	20 GA	D41858P	20		AP0037	43	115-199		
D41060P	29		0140	20 GA	D41858P	21		AP0037	43	115-199		
D41060P	30		0146	20 GA	D03530	CAP	Y	M10397		115-199		
AP0036	25	W2064	L*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40582P	36		0036	22 GA	D41410P	28		AP0033	06	001-099		
D40582P	37		0037	22 GA	D41410P	30		AP0033	06	001-099		
D40582P	6		0087	24 GK	D41840P	11		AE0402	06	001-099		
D40582P	43		0112	24 GK	D40798J	10		AP0005	14	001-099		
D40582P	5		0150	24 GK	D41840P	5		AE0402	06	001-099		
D40582P	7		0151	20 GA	D41840P	6		AE0402	06	115-199		
D40582P	8		0152	20 GA	D41846J	3		AP0001	14	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 8

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description			To						
Equip	Term	Type	Wire No.	GA	TY		Equip	Term	Type	Matewith	Pos	Effectivity	
AP0036	25	W2064	L*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)									
D40582P	8		0152	20	GA		D41840P	7		AE0402	06	115-199	
D40582P	11		0153	20	GA		D41846J	4		AP0001	14	001-099	
D40582P	11		0153	20	GA		D41840P	8		AE0402	06	115-199	
D40582P	13		0154	20	GA		D41852P	4		AP0037	10	115-199	
D40582P	14		0155	20	GA		D41852P	5		AP0037	10	115-199	
D40582P	16		0156	20	GA		D41852P	7		AP0037	10	115-199	
D40582P	17		0157	20	GA		D41852P	8		AP0037	10	115-199	
D40582P	18		0158	20	GA		D41852P	9		AP0037	10	115-199	
D40582P	19		0159	20	GA		D41852P	10		AP0037	10	115-199	
D40582P	20		0160	20	GA		D41852P	11		AP0037	10	115-199	
D40582P	21		0161	20	GA		D41852P	12		AP0037	10	115-199	
D40582P	22		0162	20	GA		D41852P	13		AP0037	10	115-199	
D40582P	23		0163	20	GA		D41852P	14		AP0037	10	115-199	
D40582P	26		0166	20	GA		D41846J	5		AP0001	14	001-099	
D40582P	26		0166	20	GA		D41410P	13		AP0033	06	115-199	
D40582P	27		0167	20	GA		D41846J	6		AP0001	14	001-099	
D40582P	27		0167	20	GA		D41410P	16		AP0033	06	115-199	
D40582P	16		0173	20	GA		D41846J	7		AP0001	14	001-099	
D40582P	30		0178	20	GA		D03505	CAP	Y	M00056		001-099	
D40582P	30		0178	20	GA		D03505	CAP	Y	M10396		115-199	
D40582P	31		0179	20	GA		D03505	CAP	Y	M00056		001-099	
D40582P	31		0179	20	GA		D03505	CAP	Y	M10396		115-199	
D40582P	39		0192	22	GA		D40798J	8		AP0005	14	001-099	
D40582P	15		0260	20	GA		D41410P	1		AP0033	06	ALL	
D40582P	12		0261	20	GA		D41410P	2		AP0033	06	ALL	
AP0036	26	W2352	L1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL									
D40696P	32		0002	24	GK		D40614P	49		AP0011	01	001-099	
D40696P	33		0003	24	GK		D40614P	50		AP0011	01	001-099	
D40696P	8		0004	24	GK		D40614P	4		AP0011	01	ALL	
D40696P	9		0008	24	GK		D40614P	8		AP0011	01	ALL	
D40696P	21		0019	24	GK		D40614P	19		AP0011	01	ALL	
D40696P	27		0034	22	GA		D40614P	34		AP0011	01	115-199	
D40696P	2		0501	24	GK		D40614P	3		AP0011	01	ALL	
D40696P	4		0619	24	GK		D40614P	33		AP0011	01	115-199	
D40696P	23		0620	24	GK		D40614P	35		AP0011	01	115-199	
D40696P	24		0621	24	GK		D40614P	36		AP0011	01	115-199	
D40696P	31		0626	22	GA		D40616P	1		AP0011	02	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 9

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0036	26	W2352	L1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)								
D40696P	32		0627	20 GA	D40616P	2		AP0011	02	115-199		
D40696P	33		0628	20 GA	D40616P	3		AP0011	02	115-199		
D40696P	37		0629	20 GA	D40616P	6		AP0011	02	115-199		
D40696P	39		0630	20 GA	D40616P	7		AP0011	02	115-199		
D40696P	40		0631	20 GA	D40616P	8		AP0011	02	115-199		
D40696P	45		0632	20 GA	D40616P	11		AP0011	02	115-199		
D40696P	47		0633	20 GA	D40616P	12		AP0011	02	001, 003-099, 115-199		
D40696P	47		0633	20 GA	D40616P	REF	JB	AP0011	02	002		
D40696P	52		0649	20 GA	D41880P	31		AP0070	07	115-199		
D40696P	53		0650	20 GA	D41880P	32		AP0070	07	115-199		
AP0036	27	W2358	S1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40728P	23		0013	22 GA	D40622P	13		AP0011	05	115-199		
D40728P	8		0020	22 GA	D40838P	2		AP0011	06	115-199		
D40728P	13		0028	24 GK	D41968P	13		AP0070	08	001-099		
D40728P	14		0123	22 GA	D41426P	13		AP0033	14	115-199		
D40728P	15		0124	22 GA	D41426P	11		AP0033	14	115-199		
D40728P	16		0125	22 GA	D41426P	12		AP0033	14	115-199		
D40728P	6		0206	20 GA	D40838P	23		AP0011	06	115-199		
D40728P	38		0438	22 GA	D42218P	8		AE0604	22	115-199		
D40728P	39		0439	22 GA	D42218P	9		AE0604	22	115-199		
D40728P	17		0501	22 GA	D40622P	17		AP0011	05	115-199		
D40728P	3		0507	22 GA	D41426P	2		AP0033	14	115-199		
D40728P	4		0510	24 GK	D41968P	10		AP0070	08	115-199		
D40728P	13		0513	20 GA	D41968P	13		AP0070	08	115-199		
D40728P	24		0522	22 GA	D41426P	17		AP0033	14	115-199		
AP0036	28	W1260	L*	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41612J	45		2007B	24 GL	D00584	1		K00140		115-199		
D41612J	27		2007R	24 GL	D00584	13		K00140		115-199		
AP0036	28	W4202	L2A	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41612P	14		0008	20 GA	D41704P	19		AP0033	24	ALL		
D41612P	47		0069	22 GA	D41652P	35		AE0501	01	ALL		
D41612P	48		0095	22 GA	D41652P	40		AE0501	01	ALL		
D41612P	49		0096	22 GA	D41652P	41		AE0501	01	ALL		
D41612P	45		2012B	24 GL	D41610P	28		AE0304	10	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 10

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0036	28	W4202	L2A	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)								
D41612P	45		2012B	22 GB	D41610P	28		AE0304	09	115-199		
D41612P	27		2012R	24 GL	D41610P	29		AE0304	10	001-099		
D41612P	27		2012R	22 GB	D41610P	29		AE0304	09	115-199		
AP0036	29	W4475	C2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41493P	1		0011	22 GA	D41391P	13		AE0201	02	115-199		
D41493P	3		0050	22 GA	D41391P	28		AE0201	02	115-199		
D41493P	6		0056	22 GA	D41399P	22		AE0301	17	115-199		
D41493P	7		0057	22 GA	D41495P	12		AP0037	30	ALL		
D41493P	4		0062	22 GA	D41675P	5		AP0050	16	001-099		
AP0036	30	W4500	L1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40542P	14		0011	24 GK	D41744P	14		AE0503	09	001-099		
D40542P	1		0021	22 GA	D40392P	37		AP0031	04	ALL		
D40542P	7		0037	20 GA	D41742P	7		AE0501	20	115-199		
D40542P	5		0601	20 GA	D41742P	26		AE0501	20	115-199		
D40542P	8		0602	20 GA	D41742P	27		AE0501	20	115-199		
D40542P	9		0603	20 GA	D41742P	28		AE0501	20	115-199		
D40542P	12		0607	20 GA	D41744P	11		AE0503	09	115-199		
D40542P	13		0608	20 GA	D41744P	12		AE0503	09	115-199		
D40542P	3		0609	20 GA	D40392P	23		AP0031	04	115-199		
D40542P	4		0610	20 GA	D40392P	24		AP0031	04	115-199		
AP0036	32	W4422	R2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41022P	1		0001	24 GK	D41032P	1		AP0037	44	115-199		
D41022P	2		0002	24 GK	D41032P	2		AP0037	44	001-099		
D41022P	3		0003	24 GK	D41032P	3		AP0037	44	ALL		
D41022P	5		0005	24 GK	D41032P	5		AP0037	44	115-199		
D41022P	6		0006	24 GK	D41032P	6		AP0037	44	115-199		
D41022P	18		0018	20 GA	D41032P	18		AP0037	44	115-199		
D41022P	20		0020	20 GA	D41032P	20		AP0037	44	ALL		
D41022P	21		0021	22 GA	D41032P	21		AP0037	44	115-199		
D41022P	22		0022	22 GA	D41032P	22		AP0037	44	115-199		
D41022P	25		0025	22 GA	D41032P	25		AP0037	44	115-199		
D41022P	28		0028	22 GA	D41032P	28		AP0037	44	115-199		
D41022P	30		0030	24 GK	D41032P	30		AP0037	44	115-199		
D41022P	36		0036	24 GK	D41032P	36		AP0037	44	115-199		
D41022P	38		0038	24 GK	D41032P	38		AP0037	44	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 11

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0036	32	W4422	R2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL (continued)								
D41022P	39		0039	24 GK	D41032P	39		AP0037	44	115-199		
D41022P	41		0041	22 GA	D41032P	41		AP0037	44	ALL		
D41022P	42		0042	22 GA	D41032P	42		AP0037	44	115-199		
D41022P	43		0043	22 GA	D41032P	43		AP0037	44	115-199		
D41022P	44		0044	22 GA	D41032P	44		AP0037	44	115-199		
D41022P	45		0045	22 GA	D41032P	45		AP0037	44	115-199		
D41022P	46		0046	22 GA	D41032P	46		AP0037	44	115-199		
D41022P	47		0047	22 GA	D41032P	47		AP0037	44	115-199		
D41022P	48		0048	22 GA	D41032P	48		AP0037	44	115-199		
D41022P	49		0049	22 GA	D41032P	49		AP0037	44	115-199		
D41022P	50		0050	24 GK	D41032P	50		AP0037	44	115-199		
D41022P	51		0051	20 GA	D41032P	51		AP0037	44	115-199		
D41022P	52		0052	20 GA	D41032P	52		AP0037	44	115-199		
D41022P	53		5001B	22 GU	D41032P	53		AP0037	44	115-199		
D41022P	54		5001R	22 GU	D41032P	54		AP0037	44	115-199		
D41022P	55		5001Z		D41032P	55		AP0037	44	115-199		
AP0036	33	W4232	S2	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41988P	3		2504B	20 GU	D40018J	20		AC0880	20	001-099		
D41988P	4		2504R	20 GU	D40018J	21		AC0880	20	001-099		
D41988P	5		2504Z		D40018J	S/R		AC0880	20	001-099		
AP0036	34	W3702	N1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40310P	22		0822	16 GA	D40312J	22		D40312P		ALL		
D40310P	11		0911	20 GA	D40312J	11		D40312P		001-099		
D40310P	11		0911	20 GA	D40312J	10		D40312P		115-199		
AP0036	36	W4204	L2B	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40574P	3		0192	22 GA	D40302J	8		AC0880	19	001-099		
D40574P	7		0193	22 GA	D40302J	9		AC0880	19	001-099		
AP0036	38	W2348	S1	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D40292P	17		0029	20 GA	D40270P	8		AP0071	3	003-099		
AP0036	43	W4028	S2B	DISC BKT-LEFT MISCELLANEOUS RELAY PANEL								
D41462P	21		0012	22 GA	D07688	CAP	Y	AC0204	1	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0036

Page 12 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0037	01	W2700	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41082P	1		0022	24	GK	D40170P	12		AE0600	06	001-099	
D41082P	3		0023	24	GK	D40170P	13		AE0600	06	001-099	
D41082P	7		0603	20	GA	D40170P	9		AE0600	06	001-099	
D41082P	7		0603	20	GA	D40170P	9		AE0600	04	115-199	
AP0037	02	W2072	R*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40594P	44		0016	24	GK	D03566	2		M10394		115-199	
D40594P	51		0074	24	GK	D41842P	7		AE0402	31	ALL	
D40594P	14		0111	20	GA	D41842P	12		AE0402	31	115-199	
D40594P	16		0113	20	GA	D41842P	14		AE0402	31	115-199	
D40594P	17		0114	20	GA	D41842P	15		AE0402	31	115-199	
D40594P	30		0121	20	GA	D03513	CAP	Y	M10250		ALL	
D40594P	31		0122	20	GA	D03513	CAP	Y	M10250		ALL	
D40594P	32		0123	20	GA	D03513	CAP	Y	M10250		115-199	
D40594P	33		0124	20	GA	D03513	CAP	Y	M10250		115-199	
D40594P	19		0130	20	GA	D03507	CAP	Y	M00056		001-099	
D40594P	37		0131	20	GA	D40804J	36		AP0005	33	001-099	
D40594P	37		0131	22	GA	D40804J	36		AP0005	33	115-199	
D40594P	45		0132	22	GA	D03513	14		M10250		115-199	
D40594P	39		0133	22	GA	D03513	13		M10250		115-199	
D40594P	40		0134	22	GA	D03513	2		M10250		115-199	
D40594P	41		0135	22	GA	D03513	1		M10250		115-199	
D40594P	43		0136	22	GA	D03513	15		M10250		115-199	
D40594P	20		0153	24	GK	D40924P	7		AE0304	26	001-099	
AP0037	04	W2356	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41408P	23		0020	20	GA	D41970P	5		AP0011	08	115-199	
D41408P	28		0248	18	GA	D41476P	1		AP0034	10	115-199	
D41408P	29		0249	18	GA	D41476P	2		AP0034	10	115-199	
D41408P	31		0251	18	GA	D41476P	4		AP0034	10	115-199	
D41408P	43		0253	22	GA	D41472P	10		AP0034	13	115-199	
D41408P	1		0262	22	GA	D41472P	17		AP0034	13	115-199	
D41408P	8		0272	22	GA	D41472P	27		AP0034	13	115-199	
D41408P	11		0275	22	GA	D41472P	30		AP0034	13	001-099	
D41408P	12		0276	22	GA	D41472P	31		AP0034	13	001-099	
D41408P	15		0284	18	GA	D41476P	5		AP0034	10	115-199	
D41408P	22		0285	18	GA	D41476P	6		AP0034	10	115-199	
D41408P	27		0286	18	GA	D41476P	7		AP0034	10	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	04	W2356	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)								
D41408P	24		0324	20 GA	D41472P	54		AP0034	13	115-199		
D41408P	25		0325	20 GA	D41472P	55		AP0034	13	115-199		
D41408P	18		0330	22 GA	D40716P	8		AP0036	20	115-199		
D41408P	CAP	Y	0331	22 GA	D40716P	14		AP0036	20	115-199		
D41408P	20		0332	22 GA	D41476P	11		AP0034	10	115-199		
D41408P	40		0612	18 GA	D41476P	14		AP0034	10	115-199		
AP0037	05	W2070	R*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D42176P	26		0332	22 GA	D40802J	2		AP0005	31	001-099		
D42176P	5		0509	22 GA	D42166P	3		AP0070	03	ALL		
D42176P	6		0510	22 GA	D42166P	4		AP0070	03	ALL		
D42176P	9		0518	22 GA	D41470P	36		AP0034	09	115-199		
D42176P	10		0519	22 GA	D41470P	37		AP0034	09	115-199		
D42176P	13		0522	22 GA	D40592P	20		AP0032	03	115-199		
D42176P	14		0523	22 GA	D40592P	21		AP0032	03	115-199		
D42176P	15		0524	22 GA	D40970P	30		AP0050	05	115-199		
D42176P	17		0525	22 GA	D40970P	31		AP0050	05	115-199		
D42176P	16		0526	20 GA	D42166P	5		AP0070	03	001-099		
AP0037	06	W2078	S*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40570P	2		0026	22 GA	D41414P	3		AP0033	26	001-099		
D40570P	6		0036	22 GA	D41380P	12		AP0050	17	ALL		
D40570P	8		0126	24 GK	D41844P	3		AE0402	20	115-199		
D40570P	25		0327	20 GA	D41850P	25		AP0036	14	115-199		
D40570P	30		0387	20 GA	D03528	CAP	Y	M10397		ALL		
D40570P	31		0388	20 GA	D03528	CAP	Y	M10397		ALL		
D40570P	32		0389	20 GA	D02696	CAP	Y	M00019		115-199		
D40570P	33		0390	20 GA	D02696	CAP	Y	M00019		115-199		
D40570P	34		0391	20 GA	D02696	CAP	Y	M00019		115-199		
D40570P	35		0392	20 GA	D03734	CAP	Y	M10401		ALL		
D40570P	36		0393	20 GA	D03734	CAP	Y	M10401		ALL		
D40570P	37		0394	20 GA	D03734	CAP	Y	M10401		115-199		
D40570P	38		0395	20 GA	D40296P	20		AP0006	01	ALL		
D40570P	40		0397	20 GA	D40296P	25		AP0006	01	ALL		
D40570P	9		0530	22 GA	D40806J	7		AP0005	17	001-099		
D40570P	11		0531	22 GA	D40600P	1		AE0502	09	001-099		
D40570P	12		0532	24 GK	D40600P	5		AE0502	09	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	07	W4208	R1B	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41766P	1		0030	20 GA	D40076J	11		AC0880	21	ALL		
D41766P	2		0031	20 GA	D40076J	16		AC0880	21	ALL		
D41766P	8		0037	22 GA	D40342J	6		AC1090	21	115-199		
AP0037	08	W4504	A1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40978P	5		0061	18 GA	D41326P	28	18	AP0034	05	115-199		
D40978P	11		0603	20 GA	D41326P	7		AP0034	05	115-199		
D40978P	13		0604	20 GA	D41326P	8		AP0034	05	115-199		
D40978P	14		0605	20 GA	D41326P	9		AP0034	05	115-199		
D40978P	16		0609	20 GA	D40400P	43		AP0034	03	ALL		
AP0037	09	W2244	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41122P	7		0057	16 GA	D41756P	7		AE0101	12	115-199		
D41122P	8		0058	16 GA	D41756P	8		AE0101	12	115-199		
D41122P	9		0604	20 GA	D41756P	9		AE0101	12	115-199		
D41122P	10		0605	20 GA	D41756P	10		AE0101	12	115-199		
D41122P	11		0606	20 GA	D41756P	11		AE0101	12	115-199		
D41122P	12		0607	20 GA	D41756P	12		AE0101	12	115-199		
D41122P	13		0609	20 GA	D40892P	13		AE0402	45	115-199		
AP0037	10	W2064	L*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41852P	4		0154	20 GA	D40582P	13		AP0036	25	115-199		
D41852P	5		0155	20 GA	D40582P	14		AP0036	25	115-199		
D41852P	7		0156	20 GA	D40582P	16		AP0036	25	115-199		
D41852P	8		0157	20 GA	D40582P	17		AP0036	25	115-199		
D41852P	9		0158	20 GA	D40582P	18		AP0036	25	115-199		
D41852P	10		0159	20 GA	D40582P	19		AP0036	25	115-199		
D41852P	11		0160	20 GA	D40582P	20		AP0036	25	115-199		
D41852P	12		0161	20 GA	D40582P	21		AP0036	25	115-199		
D41852P	13		0162	20 GA	D40582P	22		AP0036	25	115-199		
D41852P	14		0163	20 GA	D40582P	23		AP0036	25	115-199		
D41852P	21		0170	20 GA	D41410P	19		AP0033	06	ALL		
D41852P	22		0171	20 GA	D41410P	20		AP0033	06	ALL		
D41852P	23		0172	20 GA	D41410P	17		AP0033	06	001-099		
D41852P	23		0172	20 GA	D41410P	21		AP0033	06	115-199		
D41852P	24		0173	20 GA	D41410P	22		AP0033	06	115-199		
D41852P	25		0174	20 GA	D41410P	23		AP0033	06	115-199		
D41852P	26		0175	20 GA	D41410P	24		AP0033	06	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 3

Dec 18/2007

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	10	W2064	L*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)								
D41852P	15		0188	20 GA	D03505	CAP	Y	M00056		001-099		
D41852P	15		0188	20 GA	D03505	CAP	Y	M10396		115-199		
D41852P	16		0189	20 GA	D03505	CAP	Y	M00056		001-099		
D41852P	16		0189	20 GA	D03505	CAP	Y	M10396		115-199		
AP0037	11	W2070	R*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41860P	4		0385	22 GA	D40608P	39		AP0036	06	ALL		
D41860P	6		0387	22 GA	D40608P	38		AP0036	06	115-199		
D41860P	13		0402	20 GA	D40608P	13		AP0036	06	001-099		
D41860P	14		0403	22 GA	D40608P	14		AP0036	06	ALL		
D41860P	15		0404	20 GA	D41172J	33		AP0003	07	001-008		
D41860P	15		0404	20 GA	D40608P	15		AP0036	06	115-199		
D41860P	16		0405	20 GA	D41172J	36		AP0003	07	001-099		
D41860P	16		0405	20 GA	D40608P	16		AP0036	06	115-199		
D41860P	17		0406	20 GA	D41172J	37		AP0003	07	001-008		
D41860P	18		0407	20 GA	D41172J	38		AP0003	07	001-008		
D41860P	20		0409	20 GA	D40608P	CAP	Y	AP0036	06	115-199		
D41860P	23		0412	22 GA	D40970P	20		AP0050	05	001-099		
D41860P	23		0412	20 GA	D40970P	20		AP0050	05	115-199		
D41860P	25		0414	20 GA	D03546	CAP	Y	M10050		ALL		
D41860P	26		0415	20 GA	D03502	CAP	Y	M10063		115-199		
D41860P	27		0416	20 GA	D03502	CAP	Y	M10063		ALL		
D41860P	28		0417	20 GA	D03532	CAP	Y	M10057		115-199		
D41860P	29		0418	20 GA	D03532	CAP	Y	M10057		115-199		
D41860P	CAP	Y	0419	20 GA	D03540	CAP	Y	M10259		001-002, 115-199		
D41860P	30		0419	20 GA	D03540	CAP	Y	M10259		003-099		
AP0037	12	W2602	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40184P	1		0001	18 GA	D40178J	1		AB1210	01	ALL		
AP0037	14	W2602	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40186P	8		0016	24 GK	D40176J	26		AB1210	02	ALL		
D40186P	4		0044	20 GA	D40176J	4		AB1210	02	001-099		
D40186P	5		0045	20 GA	D40176J	5		AB1210	02	001-099		
D40186P	9		0046	24 GK	D40176J	32		AB1210	02	ALL		
D40186P	11		0048	22 GA	D40176J	34		AB1210	02	001-099		
D40186P	12		0049	22 GA	D40176J	35		AB1210	02	001-099		
D40186P	13		0050	20 GA	D40176J	36		AB1210	02	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 4

Oct 09/2008

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AP0037	14	W2602	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)						
D40186P	14		0051	20 GA	D40176J	37		AB1210	02	001-099
D40186P	27		0080	22 GA	D40176J	44		AB1210	02	001-099
D40186P	28		0081	22 GA	D40176J	45		AB1210	02	001-099
D40186P	29		0082	24 GK	D40176J	46		AB1210	02	001-099
D40186P	31		0083	24 GK	D40176J	47		AB1210	02	001-099
D40186P	30		0084	24 GK	D40176J	48		AB1210	02	001-099
AP0037	15	W3572	L1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D40496P	5		0090	20 GA	D00042	25		AA0360	01	001-099
D40496P	6		0091	20 GA	D00042	26		AA0360	01	001-099
D40496P	13		0092	20 GA	D05690	25		M10654		001-099
D40496P	15		0155	20 GA	D00042	12		AA0360	01	001-099
D40496P	18		0177	24 GK	SP01266		9			001-099
AP0037	15	W3672	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41302P	29		0114	20 GA	D00048	31		M10015		115-199
D41302P	30		0115	20 GA	D00048	32		M10015		115-199
D41302P	31		0116	20 GA	D00048	33		M10015		115-199
D41302P	24		0117	20 GA	D00046	24		M10014		115-199
D41302P	25		0118	20 GA	D00046	25		M10014		115-199
D41302P	26		0119	20 GA	D00046	26		M10014		115-199
AP0037	18	W2650	A2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41684P	11		0037	22 GA	D41680P	29		AE0600	16	115-199
D41684P	12		2003B	24 GL	D41680P	30		AE0600	03	001-099
D41684P	12		2003B	24 GL	D41680P	30		AE0600	16	115-199
D41684P	13		2003R	24 GL	D41680P	31		AE0600	03	001-099
D41684P	13		2003R	24 GL	D41680P	31		AE0600	16	115-199
AP0037	20	W4473	R2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41909P	28		0097	22 GA	D41355P	25		AE0302	41	115-199
D41909P	29		0107	22 GA	D41355P	26		AE0302	41	115-199
D41909P	11		0117	24 GK	D41371P	10		AE0403	14	001-099
D41909P	17		0121	20 GA	D41347P	27		AE0202	02	001-099
D41909P	32		0215	24 GK	D41883P	40		AE0502	31	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 5

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	21	W3572	L1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40496P	5		0090	20 GA	D00042	25		AA0360	01	115-199		
D40496P	6		0091	20 GA	D00042	26		AA0360	01	115-199		
D40496P	13		0092	20 GA	D00044	25		M10013		115-199		
D40496P	14		0093	20 GA	D00044	26		M10013		115-199		
AP0037	21	W3672	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41302P	29		0114	20 GA	D00048	31		M10015		001-099		
D41302P	30		0115	20 GA	D00048	32		M10015		001-099		
D41302P	31		0116	20 GA	D00048	33		M10015		001-099		
D41302P	24		0117	20 GA	D00046	24		M10014		001-099		
D41302P	25		0118	20 GA	D00046	CAP	Y	M10014		001-099		
D41302P	26		0119	20 GA	D00046	CAP	Y	M10014		001-099		
AP0037	22	W4234	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D42008P	10		0024	24 GK	D41774P	20		AE0402	14	001-099		
D42008P	14		0032	24 GK	D41774P	21		AE0402	14	001-099		
D42008P	15		0033	20 GA	D41774P	24		AE0402	14	001-099		
AP0037	22	W4238	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41998P	5		0015	24 GK	D40784P	2		AP0010	05	115-199		
AP0037	23	W4424	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41034P	4		0004	20 GA	D41024P	4		AP0036	11	001-099		
D41034P	15		0015	22 GA	D41024P	15		AP0036	11	001-099		
D41034P	16		0016	22 GA	D41024P	16		AP0036	11	001-099		
D41034P	18		0018	24 GK	D41024P	18		AP0036	11	001-099		
D41034P	19		0019	22 GA	D41024P	19		AP0036	11	001-099		
D41034P	20		0020	22 GA	D41024P	20		AP0036	11	001-099		
D41034P	22		0022	22 GA	D41024P	22		AP0036	11	001-099		
D41034P	24		0024	22 GA	D41024P	24		AP0036	11	001-099		
D41034P	25		0025	22 GA	D41024P	25		AP0036	11	001-099		
D41034P	30		0030	24 GK	D41024P	30		AP0036	11	001-099		
D41034P	32		0041	22 GA	D41024P	32		AP0036	11	003-099		
D41034P	33		0042	22 GA	D41024P	33		AP0036	11	003-099		
D41034P	34		0043	20 GA	D41024P	34		AP0036	11	003-099		
D41034P	35		0044	20 GA	D41024P	35		AP0036	11	003-099		
D41034P	36		0045	20 GA	D41024P	36		AP0036	11	003-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 6

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	24	W1270	R*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41728J	CAP	Y	2004B	24 GL	D00610	9		K00200		115-199		
D41728J	CAP	Y	2004R	24 GL	D00610	11		K00200		115-199		
AP0037	24	W4218	R2A	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41728P	12		0010	22 GA	D40402J	13		AD0880	10	001-099		
D41728P	12		0012	22 GA	D41620P	27		AE0304	31	115-199		
D41728P	13		0013	22 GA	D41620P	28		AE0304	31	115-199		
D41728P	9		0033	20 GA	D40402J	2		AD0880	10	ALL		
D41728P	32		0358	24 GK	D41632P	24		AE0402	26	001-099		
D41728P	33		0359	24 GK	D41620P	31		AE0304	31	001-099		
D41728P	CAP	Y	2006B	22 GB	D41620P	CAP	Y	AE0304	31	115-199		
D41728P	CAP	Y	2006R	22 GB	D41620P	CAP	Y	AE0304	31	115-199		
AP0037	25	W4502	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41748P	5		0022	22 GA	D41316P	21		AP0032	05	ALL		
D41748P	12		0046	22 GA	D40394P	53		AP0032	04	001-099		
D41748P	27		0062	16 GA	D40956P	16	16	AP0034	04	ALL		
D41748P	16		0088	24 GK	D40956P	17		AP0034	04	ALL		
D41748P	6		0142	20 GA	D40394P	32		AP0032	04	115-199		
D41748P	11		0211	22 GA	D41318P	3		AP0031	01	ALL		
D41748P	29		0605	22 GA	D40956P	27		AP0034	04	ALL		
D41748P	30		0606	22 GA	D40956P	28		AP0034	04	ALL		
AP0037	26	W3802	N1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40410P	22	16	0822	16 GA	D40412J	22		D40412P		ALL		
D40410P	5		0845	22 GA	D01241	3		SPEAKER		001-099		
D40410P	5		0845	22 GA	D01241	3				115-199		
D40410P	11		0911	20 GA	D40412J	11		D40412P		ALL		
AP0037	27	W2360	S1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40738P	1		0001	22 GA	D40624P	1		AP0011	12	ALL		
D40738P	9		0024	24 GK	D41972P	12		AP0011	09	003-099		
D40738P	15		0515	24 GK	D41972P	5		AP0011	09	115-199		
D40738P	10		0606	22 GA	D40624P	16		AP0011	12	115-199		
D40738P	7		0608	22 GA	D40624P	18		AP0011	12	115-199		
D40738P	19		0609	20 GA	D40624P	19		AP0011	12	115-199		
D40738P	22		0611	22 GA	D41972P	22		AP0011	09	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 7

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	27	W2360	S1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)								
D40738P	24		0613	22 GA	D41972P	24		AP0011	09	115-199		
D40738P	25		0614	22 GA	D41972P	25		AP0011	09	115-199		
AP0037	28	W4206	R2A	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41732P	6		0010	20 GA	D41792P	8		AE0402	03	ALL		
AP0037	29	W4477	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41739P	18		0001	24 GK	D41451P	1		AE0402	12	001-099		
D41739P	4		0018	22 GA	D41443P	3		AE0303	08	001-099		
D41739P	17		0081	24 GK	D41459P	9		AE0501	03	115-199		
D41739P	18		0082	24 GK	D41459P	10		AE0501	03	115-199		
D41739P	19		0085	22 GA	D41453P	39		AE0403	07	115-199		
D41739P	24		0089	20 GA	D41431P	14		AE0202	10	115-199		
D41739P	25		0092	22 GA	D41445P	10		AE0304	05	115-199		
D41739P	26		0093	22 GA	D41445P	11		AE0304	05	115-199		
D41739P	31		0123	24 GK	D41443P	37		AE0303	08	115-199		
D41739P	34		0135	24 GK	D41453P	37		AE0403	07	ALL		
D41739P	39		0145	24 GK	D41059P	36		AP0051	03	115-199		
D41739P	21		0146	24 GK	D41443P	43		AE0303	08	115-199		
D41739P	38		0152	20 GA	D41431P	22		AE0202	10	115-199		
D41739P	15		0156	22 GA	D41453P	10		AE0403	07	001-099		
D41739P	37		0171	22 GA	D42185P	14		AE0402	24	ALL		
D41739P	40		0196	20 GA	D41433P	52		AE0203	03	ALL		
AP0037	30	W4475	C2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41495P	11		0055	24 GK	D41419P	15		AE0503	15	115-199		
D41495P	12		0057	22 GA	D41493P	7		AP0036	29	ALL		
D41495P	13		0058	22 GA	D41393P	32		AE0202	13	115-199		
D41495P	14		0059	22 GA	D41399P	23		AE0301	17	115-199		
AP0037	31	W4106	R2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41546P	49		0157	24 GK	D41640J	53		AD0820	02	115-199		
AP0037	32	W4424	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41034P	2		0002	24 GK	D41024P	2		AP0036	11	115-199		
D41034P	4		0004	20 GA	D41024P	4		AP0036	11	115-199		
D41034P	5		0005	24 GK	D41024P	5		AP0036	11	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 8

Dec 18/2007

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AP0037	32	W4424	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)						
D41034P	6		0006	24 GK	D41024P	6		AP0036	11	115-199
D41034P	7		0007	20 GA	D41024P	7		AP0036	11	115-199
D41034P	10		0010	24 GK	D41024P	10		AP0036	11	115-199
D41034P	22		0022	22 GA	D41024P	22		AP0036	11	115-199
D41034P	24		0024	22 GA	D41024P	24		AP0036	11	115-199
D41034P	25		0025	22 GA	D41024P	25		AP0036	11	115-199
AP0037	33	W2070	R*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41856P	46		0094	22 GA	D41876P	26		AE0304	10	115-199
D41856P	50		0114	22 GA	D03546	CAP	Y	M10050		ALL
D41856P	55		0178	22 GA	D40592P	6		AP0032	03	ALL
D41856P	27		0331	24 GK	D40598P	27		AE0502	26	001-099
D41856P	26		0394	24 GK	D40802J	3		AP0005	31	001-099
D41856P	38		0474	22 GA	D41412P	32		AP0033	30	001-099
D41856P	44		0475	22 GA	D41412P	33		AP0033	30	001-099
D41856P	47		0476	22 GA	D41412P	34		AP0033	30	001-099
D41856P	52		0477	22 GA	D41412P	35		AP0033	30	001-099
D41856P	34		0533	22 GA	D03520	CAP	Y	M10023		001-099
AP0037	34	W1270	R*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41994J	CAP	Y	0118	24 GK	D41030J	40		AP0037	37	003
D41994J	31		0118	24 GK	D41030J	40		AP0037	37	004-099
AP0037	34	W4220	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41994P	CAP	Y	0106	24 GK	D40784P	2		AP0010	05	001-003
D41994P	31		0106	24 GK	D40784P	2		AP0010	05	004-099
AP0037	36	W4471	L2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41637P	7		0188	24 GK	D41879P	18		AE0402	38	115-199
AP0037	37	W1270	R*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41030J	40		0118	24 GK	D41994J	CAP	Y	AP0037	34	003
D41030J	40		0118	24 GK	D41994J	31		AP0037	34	004-099
AP0037	37	W4420	L2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL						
D41030P	1		0001	22 GA	D41020P	1		AP0036	18	ALL
D41030P	2		0002	22 GA	D41020P	2		AP0036	18	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 9

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	37	W4420	L2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)								
D41030P	6		0006	24 GK	D41020P	6		AP0036	18	ALL		
D41030P	12		0012	22 GA	D41020P	12		AP0036	18	115-199		
D41030P	14		0014	20 GA	D41020P	14		AP0036	18	001-099		
D41030P	18		0018	20 GA	D41020P	18		AP0036	18	115-199		
D41030P	22		0022	24 GK	D41020P	22		AP0036	18	115-199		
D41030P	23		0023	20 GA	D41020P	23		AP0036	18	115-199		
D41030P	24		0024	20 GA	D41020P	24		AP0036	18	115-199		
D41030P	25		0025	20 GA	D41020P	25		AP0036	18	115-199		
D41030P	26		0026	20 GA	D41020P	26		AP0036	18	115-199		
D41030P	27		0027	22 GA	D41020P	27		AP0036	18	ALL		
D41030P	28		0028	22 GA	D41020P	28		AP0036	18	ALL		
D41030P	29		0029	22 GA	D41020P	29		AP0036	18	115-199		
D41030P	30		0030	24 GK	D41020P	30		AP0036	18	ALL		
D41030P	33		0033	22 GA	D41020P	33		AP0036	18	115-199		
D41030P	34		0034	22 GA	D41020P	34		AP0036	18	115-199		
D41030P	35		0035	24 GK	D41020P	35		AP0036	18	115-199		
D41030P	36		0036	22 GA	D41020P	36		AP0036	18	115-199		
D41030P	37		0037	22 GA	D41020P	37		AP0036	18	115-199		
D41030P	38		0038	22 GA	D41020P	38		AP0036	18	115-199		
D41030P	39		0039	22 GA	D41020P	39		AP0036	18	115-199		
D41030P	40		0040	24 GK	D41020P	40		AP0036	18	ALL		
D41030P	42		0042	24 GK	D41020P	42		AP0036	18	115-199		
D41030P	44		0044	22 GA	D41020P	44		AP0036	18	115-199		
D41030P	45		0045	22 GA	D41020P	45		AP0036	18	115-199		
D41030P	46		0046	22 GA	D41020P	46		AP0036	18	ALL		
D41030P	47		0047	24 GK	D41020P	47		AP0036	18	001-099		
D41030P	48		0048	24 GK	D41020P	48		AP0036	18	001-099		
D41030P	49		0049	24 GK	D41020P	49		AP0036	18	115-199		
D41030P	53		0053	20 GA	D41020P	53		AP0036	18	115-199		
D41030P	CAP	Y	0054	20 GA	D41020P	54		AP0036	18	115-199		
D41030P	CAP	Y	0055	20 GA	D41020P	55		AP0036	18	115-199		
AP0037	38	W2356	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40718P	4		0004	24 GK	D40620P	4		AP0011	10	ALL		
D40718P	24		0024	24 GK	D40620P	24		AP0011	10	ALL		
D40718P	36		0036	20 GA	D41970P	6		AP0011	08	115-199		
D40718P	34		0050	24 GK	D40620P	50		AP0011	10	ALL		
D40718P	1		0205	24 GK	D40620P	54		AP0011	10	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 10

Dec 18/2007



From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	38	W2356	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)								
D40718P	45		0206	24 GK	D40620P	55		AP0011	10	001-099		
D40718P	29		0234	22 GA	D41472P	3		AP0034	13	ALL		
D40718P	32		0244	22 GA	D41472P	4		AP0034	13	ALL		
D40718P	40		0245	20 GA	D41472P	5		AP0034	13	115-199		
D40718P	51		0293	22 GA	D41472P	42		AP0034	13	115-199		
D40718P	8		0308	20 GA	D41424P	11		AP0033	27	115-199		
D40718P	9		0309	20 GA	D41424P	12		AP0033	27	115-199		
D40718P	43		0343	20 GA	D41424P	13		AP0033	27	115-199		
D40718P	45		0345	20 GA	D41424P	24		AP0033	27	115-199		
D40718P	55		0355	20 GA	D41424P	15		AP0033	27	115-199		
AP0037	39	W4216	R2A	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D42062P	CAP	Y	0107	20 GA	D40358J	5		AD1090	08	001-099		
D42062P	CAP	Y	0107	20 GA	D40358J	5		AD1090	8	115-199		
D42062P	CAP	Y	0119	20 GA	D40930P	28		AW2180	01	001-099		
AP0037	40	W4106	R2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40064P	58		0105	24 GK	D40976P	24		AP0050	04	001-099		
D40064P	47		0109	24 GK	D40976P	21		AP0050	04	115-199		
D40064P	24		0162	24 GK	D41642J	41		AD0820	03	115-199		
D40064P	55		0242	24 GK	D40666P	39		AE0302	17	001-099		
D40064P	55		0242	24 GK	D41640J	27		AD0820	02	115-199		
D40064P	54		0243	24 GK	D40666P	40		AE0302	17	001-099		
D40064P	54		0243	24 GK	D41640J	28		AD0820	02	115-199		
D40064P	52		0244	22 GA	D40666P	41		AE0302	17	001-099		
D40064P	52		0244	22 GA	D41642J	42		AD0820	03	115-199		
D40064P	53		0245	22 GA	D40666P	42		AE0302	17	001-099		
D40064P	53		0245	22 GA	D41642J	43		AD0820	03	115-199		
AP0037	41	W4234	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D42008P	10		0024	24 GK	D41774P	20		AE0402	46	115-199		
AP0037	41	W4238	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41998P	4		2503B	20 GU	D40020J	15		AD0880	20	001-099		
D41998P	5		2503R	20 GU	D40020J	18		AD0880	20	001-099		
D41998P	6		2503Z		D40020J	19		AD0880	20	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 11

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	43	W2156	S*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41858P	1		0125	22 GA	D41060P	10		AP0036	24	ALL		
D41858P	5		0127	22 GA	D41060P	14		AP0036	24	ALL		
D41858P	CAP	Y	0131	20 GA	D41060P	19		AP0036	24	115-199		
D41858P	14		0133	20 GA	D41060P	22		AP0036	24	115-199		
D41858P	15		0134	20 GA	D41060P	36		AP0036	24	115-199		
D41858P	16		0135	20 GA	D40808J	32		AP0005	34	001-002		
D41858P	16		0135	20 GA	D41060P	24		AP0036	24	115-199		
D41858P	17		0136	20 GA	D40808J	25		AP0005	34	001-002		
D41858P	17		0136	20 GA	D41060P	25		AP0036	24	115-199		
D41858P	18		0137	20 GA	D41060P	26		AP0036	24	115-199		
D41858P	19		0138	20 GA	D41060P	27		AP0036	24	115-199		
D41858P	20		0139	20 GA	D41060P	28		AP0036	24	115-199		
D41858P	21		0140	20 GA	D41060P	29		AP0036	24	115-199		
D41858P	22		0141	20 GA	D03530	CAP	Y	M10397		115-199		
D41858P	24		0143	20 GA	D03530	CAP	Y	M10397		115-199		
D41858P	25		0144	20 GA	D03530	CAP	Y	M10397		ALL		
AP0037	44	W4422	R2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41032P	1		0001	24 GK	D41022P	1		AP0036	32	115-199		
D41032P	2		0002	24 GK	D41022P	2		AP0036	32	001-099		
D41032P	3		0003	24 GK	D41022P	3		AP0036	32	ALL		
D41032P	5		0005	24 GK	D41022P	5		AP0036	32	115-199		
D41032P	6		0006	24 GK	D41022P	6		AP0036	32	115-199		
D41032P	18		0018	20 GA	D41022P	18		AP0036	32	115-199		
D41032P	20		0020	20 GA	D41022P	20		AP0036	32	ALL		
D41032P	21		0021	22 GA	D41022P	21		AP0036	32	115-199		
D41032P	22		0022	22 GA	D41022P	22		AP0036	32	115-199		
D41032P	25		0025	22 GA	D41022P	25		AP0036	32	115-199		
D41032P	28		0028	22 GA	D41022P	28		AP0036	32	115-199		
D41032P	30		0030	24 GK	D41022P	30		AP0036	32	115-199		
D41032P	36		0036	24 GK	D41022P	36		AP0036	32	115-199		
D41032P	38		0038	24 GK	D41022P	38		AP0036	32	115-199		
D41032P	39		0039	24 GK	D41022P	39		AP0036	32	115-199		
D41032P	41		0041	22 GA	D41022P	41		AP0036	32	ALL		
D41032P	42		0042	22 GA	D41022P	42		AP0036	32	115-199		
D41032P	43		0043	22 GA	D41022P	43		AP0036	32	115-199		
D41032P	44		0044	22 GA	D41022P	44		AP0036	32	115-199		
D41032P	45		0045	22 GA	D41022P	45		AP0036	32	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 12

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0037	44	W4422	R2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)								
D41032P	46		0046	22	GA	D41022P	46		AP0036	32	115-199	
D41032P	47		0047	22	GA	D41022P	47		AP0036	32	115-199	
D41032P	48		0048	22	GA	D41022P	48		AP0036	32	115-199	
D41032P	49		0049	22	GA	D41022P	49		AP0036	32	115-199	
D41032P	50		0050	24	GK	D41022P	50		AP0036	32	115-199	
D41032P	51		0051	20	GA	D41022P	51		AP0036	32	115-199	
D41032P	52		0052	20	GA	D41022P	52		AP0036	32	115-199	
D41032P	53		5001B	22	GU	D41022P	53		AP0036	32	115-199	
D41032P	54		5001R	22	GU	D41022P	54		AP0036	32	115-199	
D41032P	55		5001Z			D41022P	55		AP0036	32	115-199	
AP0037	45	W2258	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40912P	1		0001	16	GA	D40868P	1		AP0006	12	001-099	
D40912P	1		0001	20	GA	D40868P	1		AP0006	12	115-199	
D40912P	3		0003	20	GA	D40868P	3		AP0006	12	115-199	
D40912P	7		0007	20	GA	D40868P	7		AP0006	12	115-199	
D40912P	9		0009	20	GA	D40868P	9		AP0006	12	115-199	
D40912P	25		0025	20	GA	D40868P	25		AP0006	12	115-199	
D40912P	2		0601	20	GA	D40868P	2		AP0006	12	ALL	
D40912P	42		0603	16	GA	D40868P	42		AP0006	12	115-199	
D40912P	41		0604	16	GA	D40868P	41		AP0006	12	115-199	
D40912P	40		0605	16	GA	D40868P	40		AP0006	12	115-199	
D40912P	27		0606	16	GA	D40868P	27		AP0006	12	115-199	
D40912P	13		0607	20	GA	D40868P	13		AP0006	12	115-199	
D40912P	15		0609	18	GA	D40868P	15		AP0006	12	ALL	
D40912P	16		0611	20	GA	D40868P	16		AP0006	12	115-199	
D40912P	17		0612	20	GA	D40868P	17		AP0006	12	115-199	
D40912P	18		0613	20	GA	D40868P	18		AP0006	12	115-199	
D40912P	19		0614	20	GA	D40868P	19		AP0006	12	115-199	
D40912P	20		0615	20	GA	D40868P	20		AP0006	12	115-199	
D40912P	4		0616	20	GA	D40868P	4		AP0006	12	115-199	
D40912P	6		0617	20	GA	D40868P	6		AP0006	12	115-199	
D40912P	8		0618	20	GA	D40868P	8		AP0006	12	115-199	
D40912P	10		0619	20	GA	D40868P	10		AP0006	12	115-199	
AP0037	46	W2244	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D40920P	3		0601	14	GA	D40294P	4		AP0006	16	115-199	
D40920P	4		0602	14	GA	D40294P	5		AP0006	16	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 13

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0037	46	W2244	R1	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)								
D40920P	5		0603	14 GA	D40294P	6		AP0006	16	115-199		
AP0037	47	W2066	L*	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41854P	8		0104	24 GK	D40800J	35		AP0005	16	ALL		
D41854P	9		0129	24 GK	D40972P	12		AP0050	03	ALL		
D41854P	3		0130	24 GK	D40584P		CAP Y	AE0402	47	ALL		
D41854P	2		0238	24 GK	D41864P	37		AE0501	22	001-099		
D41854P	31		0246	24 GK	D03556	34		M10193		115-199		
D41854P	14		0428	24 GK	D40972P	17		AP0050	03	ALL		
D41854P	28		0512	20 GA	D40874P	48		AP0036	17	ALL		
D41854P	17		0521	20 GA	D40972P	21		AP0050	03	115-199		
D41854P	18		0522	20 GA	D40972P	22		AP0050	03	115-199		
D41854P	23		0527	20 GA	D42074P	13		AP0070	05	ALL		
D41854P	24		0528	20 GA	D03503		CAP Y	M10056		ALL		
D41854P	25		0529	20 GA	D06872		CAP Y	M10054		001-099		
D41854P	25		0529	20 GA	D03510		CAP Y	M10054		115-199		
D41854P	26		0530	20 GA	D03538		CAP Y	M10259		115-199		
D41854P	27		0531	20 GA	D03702		CAP Y	M10398		ALL		
AP0037	48	W4236	S2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D42010P	CAP	Y	0053	22 GA	D40899P		CAP Y	AP0010	08	001-002, 115-199		
D42010P	CAP	Y	0054	22 GA	D40899P		CAP Y	AP0010	08	001-002, 115-199		
D42010P	10		0067	20 GA	D41990P	8		AP0050	06	115-199		
D42010P	11		0068	20 GA	D41990P	9		AP0050	06	115-199		
D42010P	14		0084	20 GA	D40004J	25		AD0880	08	115-199		
D42010P	CAP	Y	0134	22 GA	D41946P	40		AP0054	02	001-002, 115-199		
D42010P	13		0134	22 GA	D41946P	40		AP0054	02	003-099		
D42010P	36		0236	20 GA	D40016J	27		AD0880	15	001-099		
D42010P	37		2510B	20 GU	D40004J	38		AD0880	08	001-099		
D42010P	38		2510R	20 GU	D40004J	39		AD0880	08	001-099		
D42010P	39		2510Z		D40004J		S/R	AD0880	08	001-099		
AP0037	49	W4216	R2A	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL								
D41616P	17		0008	20 GA	D41614P	50		AE0304	30	115-199		
D41616P	22		0014	22 GA	D42060P	6		AE0304	28	001-099		
D41616P	22		0014	22 GA	D42060P	6		AE0304	15	115-199		
D41616P	27		0079	22 GA	D41720P	7		AE0402	27	ALL		
D41616P	39		0082	24 GK	D41720P	20		AE0402	27	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 14

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0037	49	W4216	R2A	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL (continued)							
D41616P	40		0083	24 GK	D41720P	21		AE0402	27	115-199	
AP0037	50	W4473	R2	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL							
D41487P	1		0001	22 GA	D41339P	1		AE0201	38	009-099	
D41487P	7		0012	24 GK	D41491P	12		AP0051	05	001-099	
D41487P	7		0012	24 GK	D41491P	5		AP0051	05	115-199	
D41487P	49		0016	24 GK	D41349P	30		AE0203	33	001, 003-099	
D41487P	49		0016	22 GA	D41349P	REF	VP	AE0203	33	002	
D41487P	8		0029	24 GK	D41381P	4		AE0503	16	115-199	
D41487P	10		0037	22 GA	D41367P	47		AE0401	23	ALL	
D41487P	11		0038	24 GK	D41369P	26		AE0402	32	115-199	
D41487P	13		0051	20 GA	D41489P	9		AP0050	12	115-199	
D41487P	14		0052	24 GK	D41369P	40		AE0402	32	ALL	
D41487P	15		0054	24 GK	D41489P	10		AP0050	12	115-199	
D41487P	16		0055	24 GK	D41369P	42		AE0402	32	115-199	
D41487P	17		0062	24 GK	D41867P	1		AE0402	01	115-199	
D41487P	18		0063	24 GK	D41867P	2		AE0402	01	115-199	
D41487P	34		0098	24 GK	D41881P	24		AE0202	11	115-199	
D41487P	9		0111	22 GA	D41339P	24		AE0201	38	001-099	
D41487P	36		0113	24 GK	D41367P	28		AE0401	23	115-199	
D41487P	37		0118	24 GK	D41867P	10		AE0402	01	115-199	
D41487P	38		0130	24 GK	D41881P	22		AE0202	11	ALL	
D41487P	44		0132	24 GK	D41347P	30		AE0202	02	115-199	
D41487P	41		0199	24 GK	D41349P	41		AE0203	33	001, 003-099	
D41487P	41		0199	24 GK	D41349P	REF	VP	AE0203	33	002	
D41487P	55		2008B	24 GL	D41361P	47		AE0303	36	115-199	
D41487P	46		2008R	24 GL	D41361P	48		AE0303	36	115-199	
D41487P	3		5009B	24 G2	D41881P	16		AE0202	11	ALL	
D41487P	4		5009R	24 G2	D41881P	17		AE0202	11	ALL	
D41487P	5		5009Z		D41881P	18		AE0202	11	ALL	
AP0037	53	W4108	S2B	DISC BKT-RIGHT MISCELLANEOUS RELAY PANEL							
D41478P	21		0012	22 GA	D07710	CAP	Y	AC0204	4	001-002, 115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0037

Page 15 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0050	01	W4006	L2	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D40974P	50		0309	22 GA	D40630J	50		AC0820	02	115-199		
AP0050	02	W4471	L2	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D41477P	1		0147	24 GK	D41093P	38		AE0201	37	ALL		
D41477P	47		0149	24 GK	D41097P	47		AE0203	21	001-099		
D41477P	50		0168	22 GA	D41097P		CAP	AE0203	21	115-199		
D41477P	19		2004B	24 GL	D41325P	19		AE0501	16	115-199		
D41477P	18		2004R	24 GL	D41325P	18		AE0501	16	115-199		
D41477P	21		2005B	24 GL	D41325P	21		AE0501	16	115-199		
D41477P	20		2005R	24 GL	D41325P	20		AE0501	16	115-199		
D41477P	25		2007B	22 GB	D41301P	15		AE0301	08	ALL		
D41477P	24		2007R	22 GB	D41301P	14		AE0301	08	ALL		
D41477P	39		5034B	24 G2	D41317P	42		AE0402	07	115-199		
D41477P	38		5034R	24 G2	D41317P	41		AE0402	07	115-199		
D41477P	40		5034Z		D41317P	43		AE0402	07	115-199		
AP0050	03	W2066	L*	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D40972P	16		0008	22 GA	D40800J	42		AP0005	16	ALL		
D40972P	2		0094	22 GA	D03702		CAP	M10398		ALL		
D40972P	12		0129	24 GK	D41854P	9		AP0037	47	ALL		
D40972P	14	18	0268	18 GA	D41870P	3		AP0033	23	ALL		
D40972P	15		0269	20 GA	D41870P	2		AP0033	23	ALL		
D40972P	28		0273	24 GK	D42074P	11		AP0070	05	ALL		
D40972P	17		0428	24 GK	D41854P	14		AP0037	47	ALL		
D40972P	21		0521	20 GA	D41854P	17		AP0037	47	115-199		
D40972P	22		0522	20 GA	D41854P	18		AP0037	47	115-199		
D40972P	27		0526	24 GK	D42074P	12		AP0070	05	ALL		
D40972P	24		0557	20 GA	D40996P	3		AE0304	21	ALL		
AP0050	04	W4106	R2	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D40976P	24		0105	24 GK	D40064P	58		AP0037	40	001-099		
D40976P	21		0109	24 GK	D40064P	47		AP0037	40	115-199		
D40976P	49		2029B	24 GL	D41642J	39		AD0820	03	115-199		
D40976P	50		2029R	24 GL	D41642J	40		AD0820	03	115-199		
AP0050	05	W2070	R*	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D40970P	12		0146	24 GK	D40608P	30		AP0036	06	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0050

Page 1

Dec 18/2007

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0050	05	W2070	R*	DISC BKT-ELECTRICAL SYSTEM CARD FILE (continued)								
D40970P	20		0412	22 GA	D41860P	23		AP0037	11	001-099		
D40970P	20		0412	20 GA	D41860P	23		AP0037	11	115-199		
D40970P	29		0433	20 GA	D40608P	34		AP0036	06	ALL		
D40970P	30		0524	22 GA	D42176P	15		AP0037	05	115-199		
D40970P	31		0525	22 GA	D42176P	17		AP0037	05	115-199		
AP0050	06	W4236	S2	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D41990P	8		0067	20 GA	D42010P	10		AP0037	48	115-199		
D41990P	9		0068	20 GA	D42010P	11		AP0037	48	115-199		
D41990P	16		0220	22 GA	D40004J	18		AD0880	08	001-099		
AP0050	08	W4228	S2	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D42004P	4		0067	20 GA	D41948P	10		AP0036	22	ALL		
D42004P	5		0068	20 GA	D41948P	11		AP0036	22	115-199		
D42004P	10		0108	22 GA	D40002J	21		AC0880	22	001-099		
D42004P	8		0174	22 GA	D42006P	11		AP0033	16	001-099		
AP0050	09	W4210	S2	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D42000P	19		0107	22 GA	D41734P	49		AE0402	41	115-199		
D42000P	20		0108	22 GA	D41734P	50		AE0402	41	ALL		
AP0050	12	W4473	R2	DISC BKT-ELECTRICAL SYSTEM CARD FILE								
D41489P	9		0051	20 GA	D41487P	13		AP0037	50	115-199		
D41489P	10		0054	24 GK	D41487P	15		AP0037	50	115-199		
D41489P	19		0126	24 GK	D41377P	23		AE0501	05	001-099		
D41489P	19		0126	24 GK	D41379P	51		AE0502	03	115-199		
D41489P	21		0134	22 GA	D41347P	48		AE0202	02	001-099		
D41489P	21		0134	24 GK	D41347P	48		AE0202	02	115-199		
D41489P	10		0261	22 GA	D41381P	11		AE0503	16	001-099		
D41489P	17		0264	24 GK	D41491P	50		AP0051	05	001-099		
D41489P	2		2001B	24 GL	D41379P	28		AE0502	03	115-199		
D41489P	1		2001R	24 GL	D41379P	27		AE0502	03	115-199		
D41489P	16		5022B	24 G2	D41369P	48		AE0402	32	115-199		
D41489P	15		5022R	24 G2	D41369P	47		AE0402	32	115-199		
D41489P	17		5022Z		D41369P	49		AE0402	32	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0050

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0050	15	W2352	L1	DISC BKT-ELECTRICAL SYSTEM CARD FILE							
D40810P	1		0201	20 GA	D40614P	1		AP0011	01	115-199	
D40810P	3		0603	24 GK	D40614P	17		AP0011	01	ALL	
D40810P	6		0604	24 GK	D40614P	20		AP0011	01	ALL	
D40810P	8		0605	24 GK	D40614P	21		AP0011	01	ALL	
D40810P	9		0606	24 GK	D40614P	22		AP0011	01	115-199	
D40810P	10		0607	24 GK	D40614P	23		AP0011	01	115-199	
D40810P	12		0609	20 GA	D40614P	25		AP0011	01	ALL	
AP0050	16	W4475	C2	DISC BKT-ELECTRICAL SYSTEM CARD FILE							
D41675P	5		0031	22 GA	D41399P	7		AE0301	17	115-199	
D41675P	6		0060	22 GA	D41399P	24		AE0301	17	115-199	
D41675P	5		0062	22 GA	D41493P	4		AP0036	29	001-099	
AP0050	17	W2078	S*	DISC BKT-ELECTRICAL SYSTEM CARD FILE							
D41380P	12		0036	22 GA	D40570P	6		AP0037	06	ALL	
D41380P	1		0377	20 GA	D41414P	44		AP0033	26	ALL	
D41380P	2		0378	20 GA	D41414P	45		AP0033	26	ALL	
D41380P	3		0379	20 GA	D41414P	46		AP0033	26	115-199	
AP0050	19	W2356	R1	DISC BKT-ELECTRICAL SYSTEM CARD FILE							
D40812P	1		0013	24 GK	D40620P	13		AP0011	10	ALL	
D40812P	5		0023	22 GA	D40620P	23		AP0011	10	ALL	
D40812P	2		0211	24 GK	D40620P	48		AP0011	10	ALL	
D40812P	6		0283	22 GA	D41424P	4		AP0033	27	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0050

Page 3 End

Dec 18/2007

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0051	01	W4471	L2	DISC BKT-WARNING ELECTRONICS UNIT								
D41481P	1		0018	24 GK	D41301P	1		AE0301	08	ALL		
D41481P	7		0022	24 GK	D41473P	7		AP0036	21	115-199		
D41481P	27		0043	22 GA	D41091P	28		AE0201	21	ALL		
D41481P	18		0112	22 GA	D41325P	45		AE0501	16	ALL		
D41481P	22		0156	24 GK	D41311P	20		AE0304	07	115-199		
D41481P	23		0157	24 GK	D41311P	21		AE0304	07	115-199		
D41481P	24		0158	24 GK	D41311P	22		AE0304	07	115-199		
D41481P	25		0170	24 GK	D41473P	53		AP0036	21	ALL		
AP0051	03	W4477	S2	DISC BKT-WARNING ELECTRONICS UNIT								
D41059P	5		0038	24 GK	D41463P	5		AE0503	05	ALL		
D41059P	6		0039	24 GK	D41463P	6		AE0503	05	ALL		
D41059P	24		0055	24 GK	D41497P	12		AP0036	12	ALL		
D41059P	9		0113	24 GK	D41433P	39		AE0203	03	115-199		
D41059P	34		0141	24 GK	D41463P	12		AE0503	05	ALL		
D41059P	35		0143	24 GK	D41497P	23		AP0036	12	115-199		
D41059P	36		0145	24 GK	D41739P	39		AP0037	29	115-199		
D41059P	40		0159	24 GK	D42185P	7		AE0402	24	ALL		
D41059P	41		0218	24 GK	D41463P	14		AE0503	05	001-099		
D41059P	42		0224	22 GA	D41453P	28		AE0403	07	001-008, 010-099		
D41059P	43		0224	22 GA	D41453P	28		AE0403	07	009		
D41059P	42		5028B	24 G2	D41463P	15		AE0503	05	115-199		
D41059P	41		5028R	24 G2	D41463P	14		AE0503	05	115-199		
D41059P	43		5028Z		D41463P	16		AE0503	05	115-199		
AP0051	05	W4473	R2	DISC BKT-WARNING ELECTRONICS UNIT								
D41491P	12		0012	24 GK	D41487P	7		AP0037	50	001-099		
D41491P	5		0012	24 GK	D41487P	7		AP0037	50	115-199		
D41491P	6		0013	24 GK	D41367P	1		AE0401	23	ALL		
D41491P	14		0019	24 GK	D41377P	43		AE0501	05	001-099		
D41491P	13		0020	24 GK	D41377P	44		AE0501	05	001-099		
D41491P	41		0063	24 GK	D41867P	2		AE0402	01	001, 003-099		
D41491P	41		0063	24 GK	D41867P	REF	VP	AE0402	01	002		
D41491P	21		0081	22 GA	D41381P	9		AE0503	16	115-199		
D41491P	14		0110	24 GK	D41363P	5		AE0304	08	115-199		
D41491P	17		0112	24 GK	D41367P	27		AE0401	23	115-199		
D41491P	30		0125	24 GK	D41379P	50		AE0502	03	115-199		
D41491P	31		0135	24 GK	D41367P	30		AE0401	23	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0051

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0051	05	W4473	R2	DISC BKT-WARNING ELECTRONICS UNIT (continued)								
D41491P	32		0136	24 GK	D41377P	15		AE0501	05	ALL		
D41491P	38		0137	24 GK	D41363P	18		AE0304	08	001-099		
D41491P	38		0137	24 GK	D41363P	19		AE0304	08	115-199		
D41491P	41		0173	24 GK	D41881P	19		AE0202	11	115-199		
D41491P	50		0264	24 GK	D41489P	17		AP0050	12	001-099		
D41491P	24		5037B	24 G2	D41907P	2		AE0202	26	001-099		
D41491P	24		5037B	24 G2	D41379P	46		AE0502	03	115-199		
D41491P	23		5037R	24 G2	D41907P	1		AE0202	26	001-099		
D41491P	23		5037R	24 G2	D41379P	45		AE0502	03	115-199		
D41491P	25		5037Z		D41907P	3		AE0202	26	001-099		
D41491P	25		5037Z		D41379P	47		AE0502	03	115-199		
AP0051	07	W2241	L2	DISC BKT-WARNING ELECTRONICS UNIT								
D40639P	12		0043	22 GA	D40523J	48		AP0001	15	115-199		
D40639P	2		0052	22 GA	D40039J	9		AP0001	12	115-199		
D40639P	3		0053	22 GA	D40039J	27		AP0001	12	115-199		
D40639P	16		2520B	24 G2	D40523J	45		AP0001	15	ALL		
D40639P	15		2520R	24 G2	D40523J	44		AP0001	15	ALL		
D40639P	17		2520Z		D40523J	46		AP0001	15	ALL		
AP0051	08	W2356	R1	DISC BKT-WARNING ELECTRONICS UNIT								
D40714P	3		0027	22 GA	D40620P	27		AP0011	10	115-199		
D40714P	2		0029	24 GK	D40620P	29		AP0011	10	115-199		
D40714P	9		0203	20 GA	D40620P	52		AP0011	10	115-199		
D40714P	10		0204	20 GA	D40620P	53		AP0011	10	115-199		
D40714P	11		0205	20 GA	D40620P	54		AP0011	10	115-199		
D40714P	12		0206	20 GA	D40620P	55		AP0011	10	115-199		
AP0051	09	W2253	R2	DISC BKT-WARNING ELECTRONICS UNIT								
D42081P	1		0090	24 GK	D41041J	49		AP0003	16	115-199		
D42081P	13		0093	22 GA	D40099J	37		AP0003	13	115-199		
D42081P	14		0094	22 GA	D40099J	38		AP0003	13	115-199		
D42081P	4		5015B	24 G2	D40099J	13		AP0003	13	ALL		
D42081P	3		5015R	24 G2	D40099J	12		AP0003	13	ALL		
D42081P	5		5015Z		D40099J	14		AP0003	13	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0051

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AP0051	10	W2360	S1	DISC BKT-WARNING ELECTRONICS UNIT								
D40736P	6		0616	22	GA		D40624P	6		AP0011	12	115-199
D40736P	7		0617	22	GA		D40624P	7		AP0011	12	115-199
D40736P	8		0618	22	GA		D40624P	8		AP0011	12	115-199
D40736P	9		0619	22	GA		D40624P	9		AP0011	12	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AP0051

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0054	01	W4228	S2	DISC BKT-FIRE DETECTION CARD FILE							
D41944P	36		0027	22 GA	D41738P	7		AE0402	16	ALL	
D41944P	43		0149	22 GA	D41948P	19		AP0036	22	115-199	
D41944P	44		0150	22 GA	D41948P	20		AP0036	22	115-199	
D41944P	45		0151	22 GA	D41948P	22		AP0036	22	115-199	
D41944P	46		0152	22 GA	D41948P	23		AP0036	22	ALL	
D41944P	23		0154	22 GA	D42006P	10		AP0033	16	ALL	
D41944P	43		2509B	20 GU	D40002J	23		AC0880	22	001-099	
D41944P	44		2509R	20 GU	D40002J	24		AC0880	22	001-099	
D41944P	45		2509Z		D40002J	25		AC0880	22	001-099	
AP0054	02	W4236	S2	DISC BKT-FIRE DETECTION CARD FILE							
D41946P	23		0085	20 GA	D40016J	28		AD0880	15	115-199	
D41946P	24		0086	20 GA	D40016J	29		AD0880	15	115-199	
D41946P	31		0131	22 GA	D41776P	33		AE0402	10	ALL	
D41946P	40		0134	22 GA	D42010P	CAP	Y	AP0037	48	001-002, 115-199	
D41946P	40		0134	22 GA	D42010P	13		AP0037	48	003-099	
D41946P	25		2003B	20 GB	D40274J	6		AD0880	12	115-199	
D41946P	26		2003R	20 GB	D40274J	5		AD0880	12	115-199	
AP0054	04	W2626	S2	DISC BKT-FIRE DETECTION CARD FILE							
D40218P	12		0012	20 GA	D41062P	2		AE0600	07	001-099	
D40218P	12		0012	20 GA	D41062P	2		AE0600	10	115-199	
D40218P	14		0014R	22 QA	D41250P	14				001-099	
D40218P	16		0016	20 GA	D41062P	5		AE0600	07	001-099	
D40218P	16		0016	20 GA	D41062P	5		AE0600	10	115-199	
AP0054	05	W4210	S2	DISC BKT-FIRE DETECTION CARD FILE							
D41986P	2		0017	22 GA	D41734P	18		AE0402	41	001-099	
D41986P	3		0084	20 GA	D40042J	5		AC0880	06	001-099	
D41986P	21		0084	22 GA	D41958P	CAP	Y	AP0036	13	115-199	
D41986P	22		0085	22 GA	D41958P	CAP	Y	AP0036	13	115-199	
D41986P	3		0105	22 GA	D41734P	48		AE0402	41	115-199	
D41986P	11		0109	22 GA	D40042J	5		AC0880	06	115-199	
AP0054	07	W4230	S2	DISC BKT-FIRE DETECTION CARD FILE							
D41936P	8		0022	22 GA	D41354J	30		AC0880	08	ALL	
D41936P	9		0023	20 GA	D41354J	31		AC0880	08	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0054

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0054	07	W4230	S2	DISC BKT-FIRE DETECTION CARD FILE (continued)							
D41936P	2		0024	22 GA	D41764P	20		AE0402	23	001-099	
D41936P	2		0024	22 GA	D41764P	20		AE0402	04	115-199	
AP0054	08	W4220	S2	DISC BKT-FIRE DETECTION CARD FILE							
D41992P	5		0020	20 GA	D40046J	6		AD0880	21	001-099	
AP0054	09	W4234	S2	DISC BKT-FIRE DETECTION CARD FILE							
D41940P	7		0012	22 GA	D41358J	20		AD0880	03	ALL	
D41940P	9		0014	22 GA	D41774P	16		AE0402	14	001-099	
D41940P	9		0014	22 GA	D41774P	16		AE0402	46	115-199	
D41940P	10		0025	22 GA	D41358J	30		AD0880	03	ALL	
D41940P	11		0026	22 GA	D41358J	31		AD0880	03	ALL	
AP0054	10	W2628	S2	DISC BKT-FIRE DETECTION CARD FILE							
D40220P	5		0058R	20 QA	D41254P	4				001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0054

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0061	04	W0069	N2	DISC BKT-MAINTENANCE PANEL								
D40003J	11		5001B	24	G2	D00761	13		M00968		001-099	
D40003J	10		5001R	24	G2	D00761	12		M00968		001-099	
D40003J	7		5001Z			D00761			M00968		001-099	
D40003J	17		5003B	24	G2	D00761	7		M00968		001-099	
D40003J	16		5003R	24	G2	D00761	6		M00968		001-099	
D40003J	33		5003Z			D00761			M00968		001-099	
AP0061	04	W2299	N2	DISC BKT-MAINTENANCE PANEL								
D40003P	3		0003	22	GA	D41519P	3		AE0303	26	ALL	
D40003P	4		0004	22	GA	D41519P	4		AE0303	26	001-099	
D40003P	18		0008	22	GA	D41519P	18		AE0303	26	115-199	
D40003P	19		0009	22	GA	D41519P	19		AE0303	26	115-199	
D40003P	20		0010	22	GA	D41519P	20		AE0303	26	001-099	
D40003P	25		0015	22	GA	D41519P	25		AE0303	26	001-099	
D40003P	25		0015	22	GA	D41519P	30		AE0303	26	115-199	
D40003P	11		5001B	24	G2	D41519P	11		AE0303	26	001-099	
D40003P	10		5001R	24	G2	D41519P	10		AE0303	26	001-099	
D40003P	17		5003B	24	G2	D41519P	17		AE0303	26	001-099	
D40003P	16		5003R	24	G2	D41519P	16		AE0303	26	001-099	
D40003P	33		5003Z			D41519P	29		AE0303	26	001-099	
D40003P	19		5005B	24	G2	D41519P	19		AE0303	26	001-099	
D40003P	18		5005R	24	G2	D41519P	18		AE0303	26	001-099	
D40003P	37		5005Z			D41519P	30		AE0303	26	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0061

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0065	01	W4104	R1	DISC BKT-MISCELLANEOUS EQUIPMENT PANEL								
D41922J	2		0068	22	GA	D40080P	6		AP0034	02	001-099	
D41922J	9		0069	18	GA	D40080P	7		AP0034	02	001-099	
D41922J	10		0070	18	GA	D40080P	8		AP0034	02	001-099	
D41922J	11		0071	18	GA	D40080P	9		AP0034	02	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0065

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AP0070	02	W2256	L1	DISC BKT-RELAY PANEL								
D41746P	2		0030	20 GA	D40866P	29		AP0006	10	ALL		
D41746P	4		0032	20 GA	D40866P	31		AP0006	10	ALL		
D41746P	5		0033	20 GA	D40910P	20		AP0036	04	115-199		
D41746P	9		0037	20 GA	D40910P	25		AP0036	04	115-199		
D41746P	19		0606	20 GA	D40910P	11		AP0036	04	115-199		
D41746P	12		0607	20 GA	D40910P	27		AP0036	04	115-199		
D41746P	13		0608	20 GA	D40910P	28		AP0036	04	115-199		
D41746P	16		0609	20 GA	D40910P	29		AP0036	04	115-199		
D41746P	15		0610	20 GA	D40910P	30		AP0036	04	115-199		
D41746P	17		0612	20 GA	D40866P	25		AP0006	10	115-199		
AP0070	03	W2070	R*	DISC BKT-RELAY PANEL								
D42166P	3		0509	22 GA	D42176P	5		AP0037	05	ALL		
D42166P	4		0510	22 GA	D42176P	6		AP0037	05	ALL		
D42166P	7		0513	22 GA	D41470P	34		AP0034	09	ALL		
D42166P	8		0514	22 GA	D41470P	35		AP0034	09	ALL		
D42166P	5		0526	20 GA	D42176P	16		AP0037	05	001-099		
AP0070	04	W2634	L1	DISC BKT-RELAY PANEL								
D41942P	5		0023	20 GA	D40206P	10		AP0036	10	115-199		
D41942P	7		0025	20 GA	D41924P	13		AE0501	08	115-199		
D41942P	8		0026	20 GA	D41924P	14		AE0501	08	115-199		
AP0070	05	W2066	L*	DISC BKT-RELAY PANEL								
D42074P	11		0273	24 GK	D40972P	28		AP0050	03	ALL		
D42074P	12		0526	24 GK	D40972P	27		AP0050	03	ALL		
D42074P	13		0527	20 GA	D41854P	23		AP0037	47	ALL		
AP0070	06	W4210	S2	DISC BKT-RELAY PANEL								
D40022P	10		0147	22 GA	D41958P	1		AP0036	13	ALL		
AP0070	07	W2352	L1	DISC BKT-RELAY PANEL								
D41880P	10		0010	24 GK	D40614P	10		AP0011	01	115-199		
D41880P	18		0614	22 GA	D40614P	26		AP0011	01	115-199		
D41880P	19		0615	22 GA	D40614P	27		AP0011	01	115-199		
D41880P	20		0616	22 GA	D40614P	30		AP0011	01	115-199		
D41880P	27		0636	20 GA	D41914P	5		AE0102	12	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AP0070

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0070	07	W2352	L1	DISC BKT-RELAY PANEL (continued)								
D41880P	22		0637	20	GA	D41914P	6		AE0102	12	115-199	
D41880P	28		0638	20	GA	D41914P	7		AE0102	12	115-199	
D41880P	24		0639	20	GA	D41914P	8		AE0102	12	115-199	
D41880P	25		0640	20	GA	D41914P	9		AE0102	12	115-199	
D41880P	26		0641	20	GA	D41914P	10		AE0102	12	115-199	
D41880P	33		0647	20	GA	D40614P	44		AP0011	01	115-199	
D41880P	34		0648	20	GA	D40614P	45		AP0011	01	115-199	
D41880P	31		0649	20	GA	D40696P	52		AP0036	26	115-199	
D41880P	32		0650	20	GA	D40696P	53		AP0036	26	115-199	
D41880P	29		0651	20	GA	D41914P	19		AE0102	12	115-199	
D41880P	30		0652	20	GA	D41914P	20		AE0102	12	115-199	
AP0070	08	W2358	S1	DISC BKT-RELAY PANEL								
D41968P	13		0028	24	GK	D40728P	13		AP0036	27	001-099	
D41968P	10		0510	24	GK	D40728P	4		AP0036	27	115-199	
D41968P	13		0513	20	GA	D40728P	13		AP0036	27	115-199	
AP0070	09	W2352	L1	DISC BKT-RELAY PANEL								
D41754P	11		0643	12	GA	D41914P	18		AE0102	12	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0070

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AP0071	3	W2348	S1	DISC BKT-HYDRAULIC GENERATOR CONTROL								
D40270P	8		0029	20	GA	D40292P	17		AP0036	38	003-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AP0071

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AP0103		02	W0001	L*	DISC BKT-CAPTAINS INSTRUMENT PANEL DISC							
D40209P		31		0665	24	GK	D40039P	6		AP0001	12	115-199
D40209P		32		0666	24	GK	D40039P	7		AP0001	12	115-199
AP0103		03	W0001	L*	DISC BKT-CAPTAINS INSTRUMENT PANEL DISC							
D40427P		15		0663	24	GK	D40077P	42		AP0001	07	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AP0103

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AP0301	02	W0003	R*	DISC BKT-F/O INSTRUMENT PANEL DISC-L						
D42174P	7		0223	20 GA	GD01248	DC..	2			001-099
AP0301	04	W0002	N2	DISC BKT-F/O INSTRUMENT PANEL DISC-L						
D40836J	33		0115	24 GK	S10172	7	1A			115-199
AP0301	04	W0003	R*	DISC BKT-F/O INSTRUMENT PANEL DISC-L						
D40836P	5		0126	22 GA	D40099P	15		AP0003	13	115-199
D40836P	10		0287	22 GA	D41172P	20		AP0003	07	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AP0301

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AS1080	01	W5104	S2	DISC BKT-L. ENG. STRUT FIREWALL							
D01106J	32		0010	20	5J	D42272J	5		AW1285	06	115-199
D01106J	31		0028	20	5J	D42272J	6		AW1285	06	001-099
D01106J	33		0029	20	5J	D42272J	9		AW1285	06	001-099
D01106J	20		2502B	20	5P	D42272J	26		AW1285	06	001-099
D01106J	13		2502B	20	5P	D42272J	6		AW1285	06	115-199
D01106J	22		2502R	20	5P	D42272J	25		AW1285	06	001-099
D01106J	20		2502R	20	5P	D42272J	28		AW1285	06	115-199
D01106J	S/R		2502Z			D42272J	S/R		AW1285	06	ALL
D01106J	32		2506B	20	5P	D42272J	5		AW1285	06	001-099
D01106J	13		2506R	20	5P	D42272J	27		AW1285	06	001-099
D01106J	S/R		2506Z			D42272J	S/R		AW1285	06	001-099
D01106J	31		2507B	20	5P	D42272J	25		AW1285	06	115-199
D01106J	33		2507R	20	5P	D42272J	26		AW1285	06	115-199
D01106J	S/R		2507Z			D42272J	S/R		AW1285	06	115-199
AS1080	02	W5108	S2A	DISC BKT-L. ENG. STRUT FIREWALL							
D01110J	9		2505B	20	5P	D42278P	30		AW1285	01	ALL
D01110J	10		2505R	20	5P	D42278P	31		AW1285	01	ALL
D01110J	S/R		2505Z			D42278P	S/R		AW1285	01	ALL
AS1080	04	W5100	S2	DISC BKT-L. ENG. STRUT FIREWALL							
D01108J	16		0057	20	5J	D42282J	11		AW1285	04	ALL
D01108J	17		0058	20	5J	D42282J	12		AW1285	04	ALL
AS1080	06	W5100	S2	DISC BKT-L. ENG. STRUT FIREWALL							
D01104J	10		0066	20	5J	D42280J	6		AW1285	05	001-099
D01104J	23		0096	20	5J	D42280J	26		AW1285	05	001-099
D01104J	24		0097	20	5J	D42280J	27		AW1285	05	001-099
D01104J	2		1003	20	5N	D42280J	19		AW1285	05	001-099
D01104J	S/R		1003Z			D42280J	S/R		AW1285	05	001-099
D01104J	6		2505B	20	5P	D42280J	2		AW1285	05	115-199
D01104J	31		2505R	20	5P	D42280J	3		AW1285	05	115-199
D01104J	S/R		2505Z			D42280J	S/R		AW1285	05	115-199
D01104J	8		2506B	20	5P	D42280J	4		AW1285	05	115-199
D01104J	20		2506R	20	5P	D42280J	6		AW1285	05	115-199
D01104J	S/R		2506Z			D42280J	S/R		AW1285	05	115-199
D01104J	15		2510B	20	5P	D42280J	20		AW1285	05	001-099
D01104J	16		2510R	20	5P	D42280J	21		AW1285	05	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section AS1080

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AS1080	06	W5100	S2	DISC BKT-L. ENG. STRUT FIREWALL (continued)								
D01104J	17		2510Z		D42280J	22		AW1285	05	001-099		
D01104J	18		2511B	20 5P	D42280J	23		AW1285	05	001-099		
D01104J	19		2511R	20 5P	D42280J	24		AW1285	05	001-099		
D01104J	20		2511Z		D42280J	25		AW1285	05	001-099		
D01104J	6		3504B	20 5Q	D42280J	2		AW1285	05	001-099		
D01104J	31		3504R	20 5Q	D42280J	3		AW1285	05	001-099		
D01104J	8		3504Y	20 5Q	D42280J	4		AW1285	05	001-099		
D01104J	S/R		3504Z		D42280J	S/R		AW1285	05	001-099		
AS1080	07	W5102	S2	DISC BKT-L. ENG. STRUT FIREWALL								
D01102J	42		0035	20 5J	D42276P	32		AW1285	07	115-199		
D01102J	42		2504B	20 5P	D42276P	32		AW1285	07	001-099		
D01102J	40		2504R	20 5P	D42276P	33		AW1285	07	001-099		
D01102J	24		2504Z		D42276P	35		AW1285	07	001-099		
D01102J	40		2505B	20 5P	D42276P	33		AW1285	07	115-199		
D01102J	41		2505R	20 5P	D42276P	34		AW1285	07	115-199		
D01102J	24		2505Z		D42276P	35		AW1285	07	115-199		
D01102J	1		3506B	20 5Q	D42276P	12		AW1285	07	ALL		
D01102J	4		3506R	20 5Q	D42276P	13		AW1285	07	ALL		
D01102J	5		3506Y	20 5Q	D42276P	14		AW1285	07	ALL		
D01102J	S/R		3506Z		D42276P	S/R		AW1285	07	ALL		
AS1080	08	W5108	S2A	DISC BKT-L. ENG. STRUT FIREWALL								
D01100J	4		0012	20 5J	D42278P	16		AW1285	01	ALL		
D01100J	10		2504B	20 5P	D42278P	17		AW1285	01	ALL		
D01100J	11		2504R	20 5P	D42278P	18		AW1285	01	ALL		
D01100J	S/R		2504Z		D42278P	S/R		AW1285	01	ALL		
AS1080	10	W5114	L1	DISC BKT-L. ENG. STRUT FIREWALL								
D01114J	25		0006	20 5J	D40024P	25		AW1285	03	ALL		
D01114J	26		0007	20 5J	D40024P	26		AW1285	03	ALL		
D01114J	22		2003B	20 5K	D40024P	22		AW1285	03	ALL		
D01114J	23		2003R	20 5K	D40024P	23		AW1285	03	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AS1080

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AS1123	01	W3316	N2	DISC BKT-LEFT ENGINE STRUT VAPOR SEAL						
D40012J	6		2003B	20 FB	D01120J	5		AS1140	02	ALL
D40012J	5		2003R	20 FB	D01120J	7		AS1140	02	ALL
AS1123	01	W3320	N2	DISC BKT-LEFT ENGINE STRUT VAPOR SEAL						
D40012P	6		2003B	20 GL	D40026P	6		AC0880	18	ALL
D40012P	5		2003R	20 GL	D40026P	5		AC0880	18	ALL
AS1123	03	W3328	L1	DISC BKT-LEFT ENGINE STRUT VAPOR SEAL						
D40044P	12		0016	18 HL	D41208P	8		AC0880	05	ALL
D40044P	13		0017	18 HL	D41208P	9		AC0880	05	ALL
D40044P	14		0018	20 HL	D40042P	5		AC0880	06	ALL
AS1123	03	W3330	L1	DISC BKT-LEFT ENGINE STRUT VAPOR SEAL						
D40044J	14		0015	20 7A	D40816J	7		AS1140	04	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AS1123

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AS1140	02	W3316	N2	DISC BKT-LEFT HORIZ ENG. STRUT FIREWALL								
D01120J	5		2003B		20	FB	D40012J	6		AS1123	01	ALL
D01120J	7		2003R		20	FB	D40012J	5		AS1123	01	ALL
AS1140	04	W3330	L1	DISC BKT-LEFT HORIZ ENG. STRUT FIREWALL								
D40816J	7		0015		20	7A	D40044J	14		AS1123	03	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AS1140

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AS2080	01	W5204	S2	DISC BKT-R. ENG. STRUT FIREWALL							
D01206J	32		0010	20	5J	D42284J	15		AW2285	06	115-199
D01206J	13		2502B	20	5P	D42284J	12		AW2285	06	115-199
D01206J	20		2502R	20	5P	D42284J	18		AW2285	06	115-199
D01206J	S/R		2502Z			D42284J	S/R		AW2285	06	115-199
D01206J	31		2507B	20	5P	D42284J	19		AW2285	06	115-199
D01206J	33		2507R	20	5P	D42284J	20		AW2285	06	115-199
D01206J	S/R		2507Z			D42284J	S/R		AW2285	06	115-199
D01206J	31		2508B	20	5P	D42284J	17		AW2285	06	001-099
D01206J	32		2508R	20	5P	D42284J	18		AW2285	06	001-099
D01206J	S/R		2508Z			D42284J	S/R		AW2285	06	001-099
D01206J	33		2509B	20	5P	D42284J	19		AW2285	06	001-099
D01206J	34		2509R	20	5P	D42284J	20		AW2285	06	001-099
D01206J	S/R		2509Z			D42284J	S/R		AW2285	06	001-099
AS2080	02	W5208	S2A	DISC BKT-R. ENG. STRUT FIREWALL							
D01210J	9		2505B	20	5P	D42290P	30		AW2285	07	ALL
D01210J	10		2505R	20	5P	D42290P	31		AW2285	07	ALL
D01210J	S/R		2505Z			D42290P	S/R		AW2285	07	ALL
AS2080	04	W5200	S2	DISC BKT-R. ENG. STRUT FIREWALL							
D01208J	16		0062	20	5J	D42292J	6		AW2285	05	ALL
D01208J	17		0064	20	5J	D42292J	7		AW2285	05	ALL
AS2080	06	W5200	S2	DISC BKT-R. ENG. STRUT FIREWALL							
D01204J	6		2505B	20	5P	D42294J	1		AW2285	04	ALL
D01204J	31		2505R	20	5P	D42294J	2		AW2285	04	ALL
D01204J	S/R		2505Z			D42294J	S/R		AW2285	04	ALL
D01204J	8		2506B	20	5P	D42294J	3		AW2285	04	ALL
D01204J	20		2506R	20	5P	D42294J	5		AW2285	04	ALL
D01204J	S/R		2506Z			D42294J	S/R		AW2285	04	ALL
AS2080	07	W5202	S2	DISC BKT-R. ENG. STRUT FIREWALL							
D01202J	42		0035	20	5J	D42288P	1		AW2285	01	115-199
D01202J	42		2504B	20	5P	D42288P	1		AW2285	01	001-099
D01202J	40		2504R	20	5P	D42288P	2		AW2285	01	001-099
D01202J	24		2504Z			D42288P	4		AW2285	01	001-099
D01202J	40		2505B	20	5P	D42288P	2		AW2285	01	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AS2080

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AS2080	07	W5202	S2	DISC BKT-R. ENG. STRUT FIREWALL (continued)								
D01202J	41		2505R	20 5P	D42288P	3		AW2285	01	115-199		
D01202J	24		2505Z		D42288P	4		AW2285	01	115-199		
D01202J	1		3506B	20 5Q	D42288P	40		AW2285	01	ALL		
D01202J	4		3506R	20 5Q	D42288P	41		AW2285	01	ALL		
D01202J	5		3506Y	20 5Q	D42288P	42		AW2285	01	ALL		
D01202J	S/R		3506Z		D42288P	S/R		AW2285	01	ALL		
AS2080	08	W5208	S2A	DISC BKT-R. ENG. STRUT FIREWALL								
D01200J	4		0012	20 5J	D42290P	16		AW2285	07	ALL		
D01200J	10		2504B	20 5P	D42290P	17		AW2285	07	ALL		
D01200J	11		2504R	20 5P	D42290P	18		AW2285	07	ALL		
D01200J	S/R		2504Z		D42290P	S/R		AW2285	07	ALL		
AS2080	10	W5214	R1	DISC BKT-R. ENG. STRUT FIREWALL								
D01214J	25		0006	20 5J	D40028P	25		AW2285	02	ALL		
D01214J	26		0007	20 5J	D40028P	26		AW2285	02	ALL		
D01214J	22		2003B	20 5K	D40028P	22		AW2285	02	ALL		
D01214J	23		2003R	20 5K	D40028P	23		AW2285	02	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AS2080

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AS2123	01	W3416	N2	DISC BKT-RIGHT ENGINE STRUT VAPOR SEAL							
D40272J	6		2003B	20 FB	D01220J	5		AS2140	02	ALL	
D40272J	5		2003R	20 FB	D01220J	7		AS2140	02	ALL	
AS2123	01	W3420	N2	DISC BKT-RIGHT ENGINE STRUT VAPOR SEAL							
D40272P	6		2003B	20 GL	D40274P	6		AD0880	12	ALL	
D40272P	5		2003R	20 GL	D40274P	5		AD0880	12	ALL	
AS2123	03	W3428	R2	DISC BKT-RIGHT ENGINE STRUT VAPOR SEAL							
D40048P	1		0009	20 HL	D40046P	1		AD0880	21	ALL	
D40048P	6		0010	20 HL	D40046P	6		AD0880	21	ALL	
D40048P	7		0011	20 HL	D40046P	7		AD0880	21	ALL	
AS2123	03	W3430	R1	DISC BKT-RIGHT ENGINE STRUT VAPOR SEAL							
D40048J	7		0015	20 7A	D40818J	7		AS2140	04	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AS2123

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AS2140		02	W3416	N2	DISC BKT-RIGHT HORIZ ENG. STRUT FIREWALL							
D01220J		5		2003B	20	FB	D40272J	6		AS2123	01	ALL
D01220J		7		2003R	20	FB	D40272J	5		AS2123	01	ALL
AS2140		04	W3430	R1	DISC BKT-RIGHT HORIZ ENG. STRUT FIREWALL							
D40818J		7		0015	20	7A	D40048J	7		AS2123	03	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section AS2140

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
AT1883	01	W2822	N2	DISC BKT-APU FIREWALL DISCONNECT						
D40104P	6		0002	20 HA	S00428	3	C			115-199
AT1883	02	W2028	S2	DISC BKT-APU FIREWALL DISCONNECT						
D40316J	2		0017R	20 QA	D41250J	13				001-002
D40316J	1		0018R	20 QA	D41250J	14				001-099
AT1883	03	W2818	A1	DISC BKT-APU FIREWALL DISCONNECT						
D40230J	2		0013	20 GA	D40258J	2		AA1705	09	001-099
D40230J	2		0013	20 GA	D40258P	2		AA1705	09	115-199
D40230J	14		0014	20 GA	D40258J	14		AA1705	09	001-099
D40230J	14		0014	20 GA	D40258P	14		AA1705	09	115-199
AT1883	04	W2048	S2	DISC BKT-APU FIREWALL DISCONNECT						
D40318J	2		0003R	20 QA	D41254J	3				001-002
D40318J	5		0004R	20 QA	D41254J	4				001-099
AT1883	06	W2654	A2	DISC BKT-APU FIREWALL DISCONNECT						
D40198J	14		0037	20 GA	D41676P	16		AE0604	28	115-199
D40198J	18		0041	20 GA	D41678P	15		AE0602	09	001-099
D40198J	18		0041	20 GA	D41678P	15		AE0604	02	115-199
D40198J	24		0047	20 GA	D41688P	22		AE0600	13	001-099
D40198J	24		0047	20 GA	D41688P	CAP	Y	AE0600	12	115-199
D40198J	25		0048	20 GA	D41688P	14		AE0600	13	001-099
D40198J	25		0048	20 GA	D41688P	11		AE0600	12	115-199
D40198J	15		0049	20 GA	D41676P	15		AE0604	28	115-199
AT1883	08	W2654	A2	DISC BKT-APU FIREWALL DISCONNECT						
D40200J	22		0042	20 GA	D41676P	17		AE0602	02	001-099
D40200J	22		0042	20 GA	D41676P	17		AE0604	28	115-199
D40200J	28		0043	20 GA	D41676P	18		AE0602	02	001-099
D40200J	28		0043	20 GA	D41676P	18		AE0604	28	115-199
D40200J	29		0044	20 GA	D41676P	41		AE0602	02	001-099
D40200J	29		0044	20 GA	D41676P	41		AE0604	28	115-199
D40200J	19		2511B	20 GU	D41678P	12		AE0602	09	001-099
D40200J	19		2511B	20 GU	D41678P	12		AE0604	02	115-199
D40200J	20		2511R	20 GU	D41678P	13		AE0602	09	001-099
D40200J	20		2511R	20 GU	D41678P	13		AE0604	02	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AT1883

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AT1883	08	W2654	A2	DISC BKT-APU FIREWALL DISCONNECT (continued)							
D40200J	21		2511Z		D41678P	DED		AE0602	09	001-099	
D40200J	21		2511Z		D41678P	DED		AE0604	02	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AT1883

Page 2 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AW1156	02	W4206	R2A	DISC BKT-LEFT WING REAR SPAR							
D40922J	10		0039	22	GA	D41792P	11		AE0402	03	115-199
D40922J	7		0040	22	GA	D41656P	27		AE0503	03	115-199
D40922P	10		0039	22	GA	D41792P	11		AE0402	03	001-099
D40922P	7		0040	22	GA	D41656P	27		AE0503	03	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section AW1156

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW1180	02	W4202	L2A	DISC BKT-LEFT WING REAR SPAR								
D40898J	32		0003	20	GA	D41704P	7		AP0033	24	115-199	
D40898J	35		0057	22	GA	D41698P	18		AE0402	08	115-199	
D40898J	31		0094	20	GA	D41610P	43		AE0304	09	115-199	
D40898P	29		0003	20	GA	D41704P	7		AP0033	24	001-099	
D40898P	31		0057	22	GA	D41698P	18		AE0402	08	001-099	
D40898P	27		0094	20	GA	D41610P	43		AE0304	10	001-099	
D40898P	4		2005B	22	GB	D41610P	16		AE0304	10	001-099	
D40898P	3		2005R	22	GB	D41610P	15		AE0304	10	001-099	
D40898P	2		2006B	22	GB	D41610P	42		AE0304	10	001-099	
D40898P	1		2006R	22	GB	D41610P	41		AE0304	10	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AW1180

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW1240	01	W2646	R2A	DISC BKT-LEFT WING REAR SPAR								
D40084J	18		0013	20	GA	D42516P	23		AE0502	17	001-099	
D40084J	18		0013	20	GA	D41672P	28		AE0604	12	115-199	
D40084J	17		0014	20	GA	D41672P	29		AE0604	12	115-199	
AW1240	02	W2642	L2A	DISC BKT-LEFT WING REAR SPAR								
D40082J	17		0001	20	GA	D42518P	7		AE0502	25	001-099	
D40082J	17		0001	20	GA	D41668P	6		AE0604	17	115-199	
D40082J	18		0002	20	GA	D41668P	13		AE0604	17	115-199	
D40082J	19		0003	20	GA	D41668P	12		AE0604	17	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AW1240

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW1285	01	W3380	S2A	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL							
D42278J	16		0012	20 GA	D41354P	16		AC0880	08	ALL	
D42278J	17		2504B	20 GF	D41354P	17		AC0880	08	ALL	
D42278J	18		2504R	20 GF	D41354P	18		AC0880	08	ALL	
D42278J	S/R		2504Z		D41354P	S/R		AC0880	08	ALL	
D42278J	30		2505B	20 GF	D41354P	30		AC0880	08	ALL	
D42278J	31		2505R	20 GF	D41354P	31		AC0880	08	ALL	
D42278J	S/R		2505Z		D41354P	S/R		AC0880	08	ALL	
AW1285	01	W5108	S2A	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL							
D42278P	16		0012	20 5J	D01100J	4		AS1080	08	ALL	
D42278P	17		2504B	20 5P	D01100J	10		AS1080	08	ALL	
D42278P	18		2504R	20 5P	D01100J	11		AS1080	08	ALL	
D42278P	S/R		2504Z		D01100J	S/R		AS1080	08	ALL	
D42278P	30		2505B	20 5P	D01110J	9		AS1080	02	ALL	
D42278P	31		2505R	20 5P	D01110J	10		AS1080	02	ALL	
D42278P	S/R		2505Z		D01110J	S/R		AS1080	02	ALL	
AW1285	03	W3314	L1	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL							
D40024J	25		0006	20 GA	D40288P	25		AC0880	07	ALL	
D40024J	26		0007	20 GA	D40288P	26		AC0880	07	ALL	
D40024J	22		2003B	20 GB	D40288P	22		AC0880	07	ALL	
D40024J	23		2003R	20 GB	D40288P	23		AC0880	07	ALL	
AW1285	03	W5114	L1	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL							
D40024P	25		0006	20 5J	D01114J	25		AS1080	10	ALL	
D40024P	26		0007	20 5J	D01114J	26		AS1080	10	ALL	
D40024P	22		2003B	20 5K	D01114J	22		AS1080	10	ALL	
D40024P	23		2003R	20 5K	D01114J	23		AS1080	10	ALL	
AW1285	04	W3300	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL							
D42282P	11		0057	20 GA	D40014P	11		AC0880	23	ALL	
D42282P	12		0058	20 GA	D40014P	12		AC0880	23	ALL	
AW1285	04	W5100	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL							
D42282J	11		0057	20 5J	D01108J	16		AS1080	04	ALL	
D42282J	12		0058	20 5J	D01108J	17		AS1080	04	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AW1285

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW1285	05	W3300	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL								
D42280P	6		0066	20	GA	D40002P	41		AC0880	22	001-099	
D42280P	27		0094	20	GA	D40002P	30		AC0880	22	001-099	
D42280P	26		0095	20	GA	D40002P	29		AC0880	22	001-099	
D42280P	19		1006	20	GE	D40002P	21		AC0880	22	001-099	
D42280P	S/R		1006Z			D40002P	S/R		AC0880	22	001-099	
D42280P	12		1008	20	GE	D40002P	13		AC0880	22	001-099	
D42280P	S/R		1008Z			D40002P	S/R		AC0880	22	001-099	
D42280P	4		2506B	20	GF	D40002P	22		AC0880	22	115-199	
D42280P	6		2506R	20	GF	D40002P	41		AC0880	22	115-199	
D42280P	S/R		2506Z			D40002P	S/R		AC0880	22	115-199	
D42280P	2		2510B	20	GF	D40002P	9		AC0880	22	115-199	
D42280P	3		2510R	20	GF	D40002P	10		AC0880	22	115-199	
D42280P	S/R		2510Z			D40002P	S/R		AC0880	22	115-199	
D42280P	20		2511B	20	GF	D40002P	23		AC0880	22	001-099	
D42280P	21		2511R	20	GF	D40002P	24		AC0880	22	001-099	
D42280P	22		2511Z			D40002P	25		AC0880	22	001-099	
D42280P	23		2512B	20	GF	D40002P	26		AC0880	22	001-099	
D42280P	24		2512R	20	GF	D40002P	27		AC0880	22	001-099	
D42280P	25		2512Z			D40002P	28		AC0880	22	001-099	
D42280P	2		3504B	20	GG	D40002P	9		AC0880	22	001-099	
D42280P	3		3504R	20	GG	D40002P	10		AC0880	22	001-099	
D42280P	4		3504Y	20	GG	D40002P	22		AC0880	22	001-099	
D42280P	S/R		3504Z			D40002P	S/R		AC0880	22	001-099	
AW1285	05	W5100	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL								
D42280J	6		0066	20	5J	D01104J	10		AS1080	06	001-099	
D42280J	26		0096	20	5J	D01104J	23		AS1080	06	001-099	
D42280J	27		0097	20	5J	D01104J	24		AS1080	06	001-099	
D42280J	19		1003	20	5N	D01104J	2		AS1080	06	001-099	
D42280J	S/R		1003Z			D01104J	S/R		AS1080	06	001-099	
D42280J	2		2505B	20	5P	D01104J	6		AS1080	06	115-199	
D42280J	3		2505R	20	5P	D01104J	31		AS1080	06	115-199	
D42280J	S/R		2505Z			D01104J	S/R		AS1080	06	115-199	
D42280J	4		2506B	20	5P	D01104J	8		AS1080	06	115-199	
D42280J	6		2506R	20	5P	D01104J	20		AS1080	06	115-199	
D42280J	S/R		2506Z			D01104J	S/R		AS1080	06	115-199	
D42280J	20		2510B	20	5P	D01104J	15		AS1080	06	001-099	
D42280J	21		2510R	20	5P	D01104J	16		AS1080	06	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AW1285

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AW1285	05	W5100	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL (continued)								
D42280J	22		2510Z		D01104J	17		AS1080	06	001-099		
D42280J	23		2511B	20 5P	D01104J	18		AS1080	06	001-099		
D42280J	24		2511R	20 5P	D01104J	19		AS1080	06	001-099		
D42280J	25		2511Z		D01104J	20		AS1080	06	001-099		
D42280J	2		3504B	20 5Q	D01104J	6		AS1080	06	001-099		
D42280J	3		3504R	20 5Q	D01104J	31		AS1080	06	001-099		
D42280J	4		3504Y	20 5Q	D01104J	8		AS1080	06	001-099		
D42280J	S/R		3504Z		D01104J	S/R		AS1080	06	001-099		
AW1285	06	W3304	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL								
D42272P	6		0008	20 GA	D40018P	15		AC0880	20	001-099		
D42272P	9		0009	20 GA	D40018P	18		AC0880	20	001-099		
D42272P	5		0010	20 GA	D40018P	15		AC0880	20	115-199		
D42272P	6		2502B	20 GF	D40018P	18		AC0880	20	115-199		
D42272P	28		2502R	20 GF	D40018P	32		AC0880	20	115-199		
D42272P	S/R		2502Z		D40018P	S/R		AC0880	20	115-199		
D42272P	25		2507B	20 GF	D40018P	38		AC0880	20	115-199		
D42272P	26		2507R	20 GF	D40018P	19		AC0880	20	115-199		
D42272P	S/R		2507Z		D40018P	S/R		AC0880	20	115-199		
D42272P	26		2508B	20 GF	D40018P	17		AC0880	20	001-099		
D42272P	25		2508R	20 GF	D40018P	19		AC0880	20	001-099		
D42272P	S/R		2508Z		D40018P	S/R		AC0880	20	001-099		
D42272P	5		2509B	20 GF	D40018P	20		AC0880	20	001-099		
D42272P	27		2509R	20 GF	D40018P	21		AC0880	20	001-099		
D42272P	S/R		2509Z		D40018P	S/R		AC0880	20	001-099		
AW1285	06	W5104	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL								
D42272J	5		0010	20 5J	D01106J	32		AS1080	01	115-199		
D42272J	6		0028	20 5J	D01106J	31		AS1080	01	001-099		
D42272J	9		0029	20 5J	D01106J	33		AS1080	01	001-099		
D42272J	26		2502B	20 5P	D01106J	20		AS1080	01	001-099		
D42272J	6		2502B	20 5P	D01106J	13		AS1080	01	115-199		
D42272J	25		2502R	20 5P	D01106J	22		AS1080	01	001-099		
D42272J	28		2502R	20 5P	D01106J	20		AS1080	01	115-199		
D42272J	S/R		2502Z		D01106J	S/R		AS1080	01	ALL		
D42272J	5		2506B	20 5P	D01106J	32		AS1080	01	001-099		
D42272J	27		2506R	20 5P	D01106J	13		AS1080	01	001-099		
D42272J	S/R		2506Z		D01106J	S/R		AS1080	01	001-099		

SPARE WIRE LIST

D280N032

91-21-12

Section AW1285

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW1285	06	W5104	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL (continued)							
D42272J	25		2507B	20 5P	D01106J	31		AS1080	01	115-199	
D42272J	26		2507R	20 5P	D01106J	33		AS1080	01	115-199	
D42272J	S/R		2507Z		D01106J	S/R		AS1080	01	115-199	
AW1285	07	W3302	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL							
D42276J	32		0035	20 GA	D40006P	1		AC0880	15	115-199	
D42276J	32		2504B	20 GF	D40006P	1		AC0880	15	001-099	
D42276J	33		2504R	20 GF	D40006P	2		AC0880	15	001-099	
D42276J	35		2504Z		D40006P	4		AC0880	15	001-099	
D42276J	33		2505B	20 GF	D40006P	2		AC0880	15	115-199	
D42276J	34		2505R	20 GF	D40006P	3		AC0880	15	115-199	
D42276J	35		2505Z		D40006P	4		AC0880	15	115-199	
D42276J	12		3506B	20 GG	D40006P	40		AC0880	15	ALL	
D42276J	13		3506R	20 GG	D40006P	41		AC0880	15	ALL	
D42276J	14		3506Y	20 GG	D40006P	42		AC0880	15	ALL	
D42276J	S/R		3506Z		D40006P	S/R		AC0880	15	ALL	
AW1285	07	W5102	S2	DISC BKT-L. LEAD. EDGE STRUT VAPOR SEAL							
D42276P	32		0035	20 5J	D01102J	42		AS1080	07	115-199	
D42276P	32		2504B	20 5P	D01102J	42		AS1080	07	001-099	
D42276P	33		2504R	20 5P	D01102J	40		AS1080	07	001-099	
D42276P	35		2504Z		D01102J	24		AS1080	07	001-099	
D42276P	33		2505B	20 5P	D01102J	40		AS1080	07	115-199	
D42276P	34		2505R	20 5P	D01102J	41		AS1080	07	115-199	
D42276P	35		2505Z		D01102J	24		AS1080	07	115-199	
D42276P	12		3506B	20 5Q	D01102J	1		AS1080	07	ALL	
D42276P	13		3506R	20 5Q	D01102J	4		AS1080	07	ALL	
D42276P	14		3506Y	20 5Q	D01102J	5		AS1080	07	ALL	
D42276P	S/R		3506Z		D01102J	S/R		AS1080	07	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AW1285

Page 4 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AW1333	01	W3342	R1		DISC BKT-L. ENG. STRUT OUTBD CLOSURE RIB							
D40304P	1		0027		20	GA	D40076P	16		AC0880	21	ALL
D40304P	2		0028		20	GA	D40076P	11		AC0880	21	ALL
D40304P	11		0035		20	GA	D41394P	22		AC0880	12	ALL
AW1333	02	W3326	N2		DISC BKT-L. ENG. STRUT OUTBD CLOSURE RIB							
D41192J	14		4501AA		20	4K	D02788	13		M00726		115-199
D41192J	15		4501WV		20	4K	D02788	14		M00726		115-199
AW1333	02	W3342	R1		DISC BKT-L. ENG. STRUT OUTBD CLOSURE RIB							
D41192P	14		4501AA		20	4K	D41394P	14		AC0880	12	115-199
D41192P	15		4501WV		20	4K	D41394P	15		AC0880	12	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AW1333

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW2156	01	W4212	L2	DISC BKT-RIGHT WING REAR SPAR								
D40944J	4		0017	22	GA	D41654P	17		AE0501	21	115-199	
D40944J	5		0018	22	GA	D41654P	18		AE0501	21	115-199	
D40944P	4		0017	22	GA	D41654P	17		AE0501	21	001-099	
D40944P	5		0018	22	GA	D41654P	18		AE0501	21	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AW2156

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW2180	01	W4216	R2A	DISC BKT-RIGHT WING REAR SPAR								
D40930J	24		0104	22	GA	D41658P	12		AE0503	18	115-199	
D40930J	26		0105	22	GA	D41720P	16		AE0402	27	115-199	
D40930J	28		0117	22	GA	D41658P	9		AE0503	18	115-199	
D40930P	26		0104	22	GA	D41658P	12		AE0503	18	001-099	
D40930P	24		0105	22	GA	D41720P	16		AE0402	27	001-099	
D40930P	34		0106	22	GA	D42060P	11		AE0304	28	001-099	
D40930P	35		0108	20	GA	D41718P	32		AP0033	29	001-099	
D40930P	28		0119	20	GA	D42062P	CAP	Y	AP0037	39	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section AW2180

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
AW2240	01	W2648	R2B		DISC BKT-RIGHT WING REAR SPAR							
D40434J	15		0001		20	GA	D42520P	7		AE0502	29	001-099
D40434J	15		0001		20	GA	D41674P	13		AE0604	14	115-199
D40434J	16		0002		20	GA	D41674P	11		AE0604	14	115-199
D40434J	17		0003		20	GA	D41674P	12		AE0604	14	115-199
AW2240	02	W2644	L2B		DISC BKT-RIGHT WING REAR SPAR							
D40442J	17		0009		20	GA	D42510P	13		AE0502	04	001-099
D40442J	17		0009		20	GA	D41670P	23		AE0604	15	115-199
D40442J	18		0010		20	GA	D41670P	21		AE0604	15	115-199
D40442J	CAP	Y	0011		20	GA	D41670P	22		AE0604	15	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AW2240

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AW2285	01	W3402	S2	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL								
D42288J	1		0035	20 GA	D40032P	1		AD0880	05	115-199		
D42288J	1		2504B	20 GF	D40032P	1		AD0880	05	001-099		
D42288J	2		2504R	20 GF	D40032P	2		AD0880	05	001-099		
D42288J	4		2504Z		D40032P	4		AD0880	05	001-099		
D42288J	2		2505B	20 GF	D40032P	2		AD0880	05	115-199		
D42288J	3		2505R	20 GF	D40032P	3		AD0880	05	115-199		
D42288J	4		2505Z		D40032P	4		AD0880	05	115-199		
D42288J	40		3506B	20 GG	D40032P	40		AD0880	05	ALL		
D42288J	41		3506R	20 GG	D40032P	41		AD0880	05	ALL		
D42288J	42		3506Y	20 GG	D40032P	42		AD0880	05	ALL		
D42288J	S/R		3506Z		D40032P	S/R		AD0880	05	ALL		
AW2285	01	W5202	S2	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL								
D42288P	1		0035	20 5J	D01202J	42		AS2080	07	115-199		
D42288P	1		2504B	20 5P	D01202J	42		AS2080	07	001-099		
D42288P	2		2504R	20 5P	D01202J	40		AS2080	07	001-099		
D42288P	4		2504Z		D01202J	24		AS2080	07	001-099		
D42288P	2		2505B	20 5P	D01202J	40		AS2080	07	115-199		
D42288P	3		2505R	20 5P	D01202J	41		AS2080	07	115-199		
D42288P	4		2505Z		D01202J	24		AS2080	07	115-199		
D42288P	40		3506B	20 5Q	D01202J	1		AS2080	07	ALL		
D42288P	41		3506R	20 5Q	D01202J	4		AS2080	07	ALL		
D42288P	42		3506Y	20 5Q	D01202J	5		AS2080	07	ALL		
D42288P	S/R		3506Z		D01202J	S/R		AS2080	07	ALL		
AW2285	02	W3414	R1	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL								
D40028J	25		0006	20 GA	D40290P	25		AD0880	23	ALL		
D40028J	26		0007	20 GA	D40290P	26		AD0880	23	ALL		
D40028J	22		2003B	20 GB	D40290P	22		AD0880	23	ALL		
D40028J	23		2003R	20 GB	D40290P	23		AD0880	23	ALL		
AW2285	02	W5214	R1	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL								
D40028P	25		0006	20 5J	D01214J	25		AS2080	10	ALL		
D40028P	26		0007	20 5J	D01214J	26		AS2080	10	ALL		
D40028P	22		2003B	20 5K	D01214J	22		AS2080	10	ALL		
D40028P	23		2003R	20 5K	D01214J	23		AS2080	10	ALL		

SPARE WIRE LIST

D280N032

91-21-12

Section AW2285

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW2285	04	W3400	S2	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL							
D42294P	5		0067	20 GA	D40016P	27		AD0880	15	001-099	
D42294P	1		2505B	20 GF	D40016P	28		AD0880	15	115-199	
D42294P	2		2505R	20 GF	D40016P	29		AD0880	15	115-199	
D42294P	S/R		2505Z		D40016P	S/R		AD0880	15	115-199	
D42294P	3		2506B	20 GF	D40016P	30		AD0880	15	115-199	
D42294P	5		2506R	20 GF	D40016P	27		AD0880	15	115-199	
D42294P	S/R		2506Z		D40016P	S/R		AD0880	15	115-199	
D42294P	1		3504B	20 GG	D40016P	28		AD0880	15	001-099	
D42294P	2		3504R	20 GG	D40016P	29		AD0880	15	001-099	
D42294P	3		3504Y	20 GG	D40016P	30		AD0880	15	001-099	
D42294P	S/R		3504Z		D40016P	S/R		AD0880	15	001-099	
AW2285	04	W5200	S2	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL							
D42294J	1		2505B	20 5P	D01204J	6		AS2080	06	ALL	
D42294J	2		2505R	20 5P	D01204J	31		AS2080	06	ALL	
D42294J	S/R		2505Z		D01204J	S/R		AS2080	06	ALL	
D42294J	3		2506B	20 5P	D01204J	8		AS2080	06	ALL	
D42294J	5		2506R	20 5P	D01204J	20		AS2080	06	ALL	
D42294J	S/R		2506Z		D01204J	S/R		AS2080	06	ALL	
AW2285	05	W3400	S2	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL							
D42292P	6		0062	20 GA	D40004P	25		AD0880	08	ALL	
D42292P	7		0064	20 GA	D40004P	41		AD0880	08	ALL	
D42292P	18		1005	20 GE	D40004P	18		AD0880	08	001-099	
D42292P	S/R		1005Z		D40004P	S/R		AD0880	08	001-099	
D42292P	38		2509B	20 GF	D40004P	38		AD0880	08	001-099	
D42292P	39		2509R	20 GF	D40004P	39		AD0880	08	001-099	
D42292P	S/R		2509Z		D40004P	S/R		AD0880	08	001-099	
D42292P	40		2510B	20 GF	D40004P	12		AD0880	08	001-099	
D42292P	41		2510R	20 GF	D40004P	13		AD0880	08	001-099	
D42292P	S/R		2510Z		D40004P	S/R		AD0880	08	001-099	
AW2285	05	W5200	S2	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL							
D42292J	6		0062	20 5J	D01208J	16		AS2080	04	ALL	
D42292J	7		0064	20 5J	D01208J	17		AS2080	04	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AW2285

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW2285	06	W3404	S2	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL							
D42284P	15		0010	20 GA	D40020P	15		AD0880	20	115-199	
D42284P	19		2502B	20 GF	D40020P	21		AD0880	20	001-099	
D42284P	12		2502B	20 GF	D40020P	12		AD0880	20	115-199	
D42284P	20		2502R	20 GF	D40020P	27		AD0880	20	001-099	
D42284P	18		2502R	20 GF	D40020P	18		AD0880	20	115-199	
D42284P	S/R		2502Z		D40020P	28		AD0880	20	001-099	
D42284P	S/R		2502Z		D40020P	S/R		AD0880	20	115-199	
D42284P	17		2506B	20 GF	D40020P	15		AD0880	20	001-099	
D42284P	18		2506R	20 GF	D40020P	18		AD0880	20	001-099	
D42284P	S/R		2506Z		D40020P	S/R		AD0880	20	001-099	
D42284P	19		2507B	20 GF	D40020P	19		AD0880	20	115-199	
D42284P	20		2507R	20 GF	D40020P	20		AD0880	20	115-199	
D42284P	S/R		2507Z		D40020P	S/R		AD0880	20	115-199	
AW2285	06	W5204	S2	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL							
D42284J	15		0010	20 5J	D01206J	32		AS2080	01	115-199	
D42284J	12		2502B	20 5P	D01206J	13		AS2080	01	115-199	
D42284J	18		2502R	20 5P	D01206J	20		AS2080	01	115-199	
D42284J	S/R		2502Z		D01206J	S/R		AS2080	01	115-199	
D42284J	19		2507B	20 5P	D01206J	31		AS2080	01	115-199	
D42284J	20		2507R	20 5P	D01206J	33		AS2080	01	115-199	
D42284J	S/R		2507Z		D01206J	S/R		AS2080	01	115-199	
D42284J	17		2508B	20 5P	D01206J	31		AS2080	01	001-099	
D42284J	18		2508R	20 5P	D01206J	32		AS2080	01	001-099	
D42284J	S/R		2508Z		D01206J	S/R		AS2080	01	001-099	
D42284J	19		2509B	20 5P	D01206J	33		AS2080	01	001-099	
D42284J	20		2509R	20 5P	D01206J	34		AS2080	01	001-099	
D42284J	S/R		2509Z		D01206J	S/R		AS2080	01	001-099	
AW2285	07	W3480	S2A	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL							
D42290J	16		0012	20 GA	D41358P	16		AD0880	03	ALL	
D42290J	17		2504B	20 GF	D41358P	17		AD0880	03	ALL	
D42290J	18		2504R	20 GF	D41358P	18		AD0880	03	ALL	
D42290J	S/R		2504Z		D41358P	S/R		AD0880	03	ALL	
D42290J	30		2505B	20 GF	D41358P	30		AD0880	03	ALL	
D42290J	31		2505R	20 GF	D41358P	31		AD0880	03	ALL	
D42290J	S/R		2505Z		D41358P	S/R		AD0880	03	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AW2285

Page 3

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW2285	07	W5208	S2A	DISC BKT-R. LEAD. EDGE STRUT VAPOR SEAL								
D42290P	16		0012	20	5J	D01200J	4		AS2080	08	ALL	
D42290P	17		2504B	20	5P	D01200J	10		AS2080	08	ALL	
D42290P	18		2504R	20	5P	D01200J	11		AS2080	08	ALL	
D42290P	S/R		2504Z			D01200J	S/R		AS2080	08	ALL	
D42290P	30		2505B	20	5P	D01210J	9		AS2080	02	ALL	
D42290P	31		2505R	20	5P	D01210J	10		AS2080	02	ALL	
D42290P	S/R		2505Z			D01210J	S/R		AS2080	02	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AW2285

Page 4 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW2333	01	W3426	N2	DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB							
D40330J	21		1011	20 GE	D40326J	21		AW2493	02	115-199	
D40330J	S/R		1011Z		GD02609	ST..	E			115-199	
D40330J	15		1015	20 GE	D40326J	15		AW2493	02	115-199	
D40330J	S/R		1015Z		GD02609	ST..	E			115-199	
D40330J	48		2501B	20 GF	D40326J	48		AW2493	02	ALL	
D40330J	49		2501R	20 GF	D40326J	49		AW2493	02	ALL	
D40330J	S/R		2501Z		GD00443	ST..	E			ALL	
D40330J	50		2502B	20 GF	D40326J	50		AW2493	02	ALL	
D40330J	51		2502R	20 GF	D40326J	51		AW2493	02	ALL	
D40330J	S/R		2502Z		GD00443	ST..	E			ALL	
D40330J	52		2503B	20 GF	D40326J	52		AW2493	02	ALL	
D40330J	53		2503R	20 GF	D40326J	53		AW2493	02	ALL	
D40330J	S/R		2503Z		GD00443	ST..	E			ALL	
D40330J	54		2504B	20 GF	D40326J	54		AW2493	02	ALL	
D40330J	55		2504R	20 GF	D40326J	55		AW2493	02	ALL	
D40330J	S/R		2504Z		GD00443	ST..	E			ALL	
D40330J	13		2507B	20 GF	D40326J	13		AW2493	02	115-199	
D40330J	12		2507R	20 GF	D40326J	CAP	Y	AW2493	02	115-199	
D40330J	S/R		2507Z		GD02609	ST..	E			115-199	
D40330J	17		2516B	20 GF	D40326J	CAP	Y	AW2493	02	115-199	
D40330J	16		2516R	20 GF	D40326J	16		AW2493	02	115-199	
D40330J	S/R		2516Z		GD02609	ST..	E			115-199	
D40330J	25		2519B	20 GF	D40326J	25		AW2493	02	115-199	
D40330J	24		2519R	20 GF	D40326J	24		AW2493	02	115-199	
D40330J	S/R		2519Z		GD02609	ST..	E			115-199	
D40330J	38		4253R	20 GH	D40326J	CAP	Y	AW2493	02	115-199	
AW2333	01	W3460	S2	DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB							
D40330P	15		0015	20 GA	D40334P	15		AD0880	06	115-199	
D40330P	21		0021	20 GA	D40334P	21		AD0880	06	115-199	
D40330P	48		2001B	20 GB	D40334P	48		AD0880	06	ALL	
D40330P	49		2001R	20 GB	D40334P	49		AD0880	06	ALL	
D40330P	50		2002B	20 GB	D40334P	50		AD0880	06	ALL	
D40330P	51		2002R	20 GB	D40334P	51		AD0880	06	ALL	
D40330P	52		2003B	20 GB	D40334P	52		AD0880	06	ALL	
D40330P	53		2003R	20 GB	D40334P	53		AD0880	06	ALL	
D40330P	54		2004B	20 GB	D40334P	54		AD0880	06	ALL	
D40330P	55		2004R	20 GB	D40334P	55		AD0880	06	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section AW2333

Page 1

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To							
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity		
AW2333	01	W3460	S2	DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB (continued)								
D40330P	CAP	Y	2006B	20 GB	D40334P	CAP	Y	AD0880	06	115-199		
D40330P	CAP	Y	2006R	20 GB	D40334P	CAP	Y	AD0880	06	115-199		
D40330P	13		2007B	20 GB	D40334P	13		AD0880	06	115-199		
D40330P	12		2007R	20 GB	D40334P	CAP	Y	AD0880	06	115-199		
D40330P	17		2009B	20 GB	D40334P	CAP	Y	AD0880	06	115-199		
D40330P	16		2009R	20 GB	D40334P	16		AD0880	06	115-199		
D40330P	CAP	Y	2010B	20 GB	D40334P	CAP	Y	AD0880	06	115-199		
D40330P	CAP	Y	2010R	20 GB	D40334P	CAP	Y	AD0880	06	115-199		
D40330P	25		2013B	20 GB	D40334P	25		AD0880	06	115-199		
D40330P	24		2013R	20 GB	D40334P	24		AD0880	06	115-199		
D40330P	38		4001R	20 GD	D40334P	38		AD0880	06	115-199		
AW2333	02	W3446	L1	DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB								
D40404P	1		0001	20 GA	D42076P	1		AD0880	04	ALL		
D40404P	11		0011	20 GA	D42076P	11		AD0880	04	ALL		
D40404P	12		0012	20 GA	D42076P	12		AD0880	04	ALL		
D40404P	13		0013	20 GA	D42076P	13		AD0880	04	ALL		
D40404P	14		0014	20 GA	D42076P	14		AD0880	04	ALL		
AW2333	03	W3426	N2	DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB								
D40328J	18		2512B	20 GF	D40324J	18		AW2493	01	ALL		
D40328J	19		2512R	20 GF	D40324J	19		AW2493	01	ALL		
D40328J	S/R		2512Z		GD00433	ST..	E			ALL		
AW2333	03	W3458	S2	DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB								
D40328P	18		2001B	20 GB	D40332P	18		AD0880	07	ALL		
D40328P	19		2001R	20 GB	D40332P	19		AD0880	07	ALL		
AW2333	04	W3424	R2	DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB								
D41196P	16		0003	20 GA	D40402P	6		AD0880	10	115-199		
D41196P	17		0004	20 GA	D40402P	7		AD0880	10	115-199		
D41196P	18		0010	20 GA	D40402P	13		AD0880	10	115-199		
D41196P	19		0011	20 GA	D40402P	11		AD0880	10	115-199		
D41196P	14		4501AA	20 4K	D41198P	14		AD0880	18	115-199		
D41196P	15		4501WV	20 4K	D41198P	15		AD0880	18	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section AW2333

Page 2

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description			To					
Equip	Term	Type	Wire No.	GA	TY		Equip	Term	Type	Matewith	Pos	Effectivity
AW2333	04	W3462	N2	DISC BKT-R. ENG. STRUT OUTBD CLOSURE RIB								
D41196J	14		4501AA	20	4K		D02814	13		M00727		115-199
D41196J	15		4501WV	20	4K		D02814	14		M00727		115-199

SPARE WIRE LIST

D280N032

91-21-12

Section AW2333

Page 3 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
AW2493	01	W3426	N2	DISC BKT-WING LE STRUT								
D40324J	18		2512B	20	GF	D40328J	18		AW2333	03	ALL	
D40324J	19		2512R	20	GF	D40328J	19		AW2333	03	ALL	
AW2493	02	W3426	N2	DISC BKT-WING LE STRUT								
D40326J	21		1011	20	GE	D40330J	21		AW2333	01	115-199	
D40326J	15		1015	20	GE	D40330J	15		AW2333	01	115-199	
D40326J	48		2501B	20	GF	D40330J	48		AW2333	01	ALL	
D40326J	49		2501R	20	GF	D40330J	49		AW2333	01	ALL	
D40326J	50		2502B	20	GF	D40330J	50		AW2333	01	ALL	
D40326J	51		2502R	20	GF	D40330J	51		AW2333	01	ALL	
D40326J	52		2503B	20	GF	D40330J	52		AW2333	01	ALL	
D40326J	53		2503R	20	GF	D40330J	53		AW2333	01	ALL	
D40326J	54		2504B	20	GF	D40330J	54		AW2333	01	ALL	
D40326J	55		2504R	20	GF	D40330J	55		AW2333	01	ALL	
D40326J	13		2507B	20	GF	D40330J	13		AW2333	01	115-199	
D40326J	CAP	Y	2507R	20	GF	D40330J	12		AW2333	01	115-199	
D40326J	CAP	Y	2516B	20	GF	D40330J	17		AW2333	01	115-199	
D40326J	16		2516R	20	GF	D40330J	16		AW2333	01	115-199	
D40326J	25		2519B	20	GF	D40330J	25		AW2333	01	115-199	
D40326J	24		2519R	20	GF	D40330J	24		AW2333	01	115-199	
D40326J	CAP	Y	4253R	20	GH	D40330J	38		AW2333	01	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section AW2493

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith		Pos	Bundle	Sep	Description		To					
From												
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D00044			W3574	N2	PLUG-							
D07656	28			0001	16	GA	D07656	29		D00044		001-099
D07656	29			0001	16	GA	D07656	28		D00044		001-099
D07656	31			0002	16	GA	D07656	32		D00044		001-099
D07656	32			0002	16	GA	D07656	31		D00044		001-099
D07656	33			0003	16	GA	D07656	41		D00044		001-099
D07656	41			0003	16	GA	D07656	33		D00044		001-099
D07656	42			0004	16	GA	D07656	43		D00044		001-099
D07656	43			0004	16	GA	D07656	42		D00044		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D00044

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D00477			W2021	N2	RECP-							
D00473		CAP	Y	2506B	22	GF	D00167	CAP	Y	M00269		ALL
D00473		CAP	Y	2506R	22	GF	D00167	CAP	Y	M00269		ALL
D00473		DED		2506Z			D00167	DED		M00269		ALL

SPARE WIRE LIST

D280N032

91-21-12

Section D00477

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D02458		W0558	N2	RCPT-ATT PNL							
D05116	21		0021	20	GA	D40882P	21		D40882J		001-099
D05116	21		0021	20	GA	D40882P	21		D40882J		001-099
D05116	22		0022	22	GA	D40882P	22		D40882J		001-099
D05116	22		0022	22	GA	D40882P	22		D40882J		001-099
D05116	29		0029	22	GA	D40882P	29		D40882J		001-099
D05116	29		0029	22	GA	D40882P	29		D40882J		001-099
D05116	30		0030	22	GA	D40882P	30		D40882J		001-099
D05116	30		0030	22	GA	D40882P	30		D40882J		001-099
D05116	31		0031	20	GA	D40882P	31		D40882J		001-099
D05116	31		0031	20	GA	D40882P	31		D40882J		001-099
D05116	35		0035	22	GA	D40882P	35		D40882J		001-099
D05116	35		0035	22	GA	D40882P	35		D40882J		001-099
D05116	36		0036	22	GA	D40882P	36		D40882J		001-099
D05116	36		0036	22	GA	D40882P	36		D40882J		001-099
D05116	37		0037	22	GA	D40882P	37		D40882J		001-099
D05116	37		0037	22	GA	D40882P	37		D40882J		001-099
D05116	28		3001B	22	GC	D40882P	28		D40882J		001-099
D05116	28		3001B	22	GC	D40882P	28		D40882J		001-099
D05116	26		3001R	22	GC	D40882P	26		D40882J		001-099
D05116	26		3001R	22	GC	D40882P	26		D40882J		001-099
D05116	27		3001Y	22	GC	D40882P	27		D40882J		001-099
D05116	27		3001Y	22	GC	D40882P	27		D40882J		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D02458

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D04616			W0530	N2	RCPT-							
D04628		5		0005	22	GK	D42052P	5				001-099
D04628		10		0010	22	GK	D42052P	10				115-199

SPARE WIRE LIST

D280N032

91-21-12

Section D04616

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
D05928		W3572	L1	RCPT-								
D05896	7		0175	20	GA	D05690	9		M10654		001-008	
D05896	1		0176	20	GA	D05690	10		M10654		001-008	

SPARE WIRE LIST

D280N032

91-21-12

Section D05928

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
D40312J		W3704	N1	RCPT-								
D40312P	22		0822	16	GA	D40314J	19		D40314P		001-099	
D40312P	22		0822	16	GA	D40314J	18		D40314P		115-199	
D40312P	11		0911	20	GA	D40314J	11		D40314P		001-099	
D40312P	10		0911	20	GA	D40314J	11		D40314P		115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section D40312J

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D40312P		W3702	N1	PLUG-							
D40312J	22		0822	16	GA	D40310P	22		AP0036	34	ALL
D40312J	11		0911	20	GA	D40310P	11		AP0036	34	001-099
D40312J	10		0911	20	GA	D40310P	11		AP0036	34	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section D40312P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D40314P			W3704	N1	PLUG-							
D40314J	19		0822		16	GA	D40312P	22		D40312J		001-099
D40314J	18		0822		16	GA	D40312P	22		D40312J		115-199
D40314J	11		0911		20	GA	D40312P	11		D40312J		001-099
D40314J	11		0911		20	GA	D40312P	10		D40312J		115-199

SPARE WIRE LIST

D280N032

91-21-12

Section D40314P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D40412J		W3804	N1	RCPT-							
D40412P	22		0822	16	GA	D40414J	19		D40414P		ALL
D40412P	11		0911	20	GA	D40414J	11		D40414P		ALL

SPARE WIRE LIST

D280N032

91-21-12

Section D40412J

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
D40412P		W3802	N1	PLUG-								
D40412J	22		0822	16	GA	D40410P	22	16	AP0037	26	ALL	
D40412J	11		0911	20	GA	D40410P	11		AP0037	26	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section D40412P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To					
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity
D40414J		W3806	N1	RCPT-						
D40414P	19		0816	22 GA	D01245	3		SPEAKER		ALL

SPARE WIRE LIST

D280N032

91-21-12

Section D40414J

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D40414P		W3804	N1	PLUG-							
D40414J	19		0822	16	GA	D40412P	22		D40412J		ALL
D40414J	11		0911	20	GA	D40412P	11		D40412J		ALL

SPARE WIRE LIST

D280N032

91-21-12

Section D40414P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D40882J		W0558	N2	RCPT-							
D40882P	21		0021	20	GA	D05116	21		D02458		001-099
D40882P	22		0022	22	GA	D05116	22		D02458		001-099
D40882P	29		0029	22	GA	D05116	29		D02458		001-099
D40882P	30		0030	22	GA	D05116	30		D02458		001-099
D40882P	31		0031	20	GA	D05116	31		D02458		001-099
D40882P	35		0035	22	GA	D05116	35		D02458		001-099
D40882P	36		0036	22	GA	D05116	36		D02458		001-099
D40882P	37		0037	22	GA	D05116	37		D02458		001-099
D40882P	28		3001B	22	GC	D05116	28		D02458		001-099
D40882P	26		3001R	22	GC	D05116	26		D02458		001-099
D40882P	27		3001Y	22	GC	D05116	27		D02458		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D40882J

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
D40882P		W3576	R1	PLUG-								
D40882J	29		0029	22	GA	D41702J	2		AE0404	07	001-099	
D40882J	31		0030	20	GA	GD03408	ST..	E			001-099	
D40882J	30		0031	22	GA	D41702J	3		AE0404	07	001-099	
D40882J	28		3001B	22	GC	D41702J	6		AE0404	07	001-099	
D40882J	26		3001R	22	GC	D41702J	5		AE0404	07	001-099	
D40882J	27		3001Y	22	GC	D41702J	7		AE0404	07	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section D40882P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41180J		W4224	R2A	RECPT-							
D41180P	9		0045	20	GA	D40164P	9		AA1715	06	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section D41180J

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41498J		W3572	L1	RCPT-							
D41498P	7		0175	20	GA	D05690	9		M10654		009-099
D41498P	1		0176	20	GA	D05690	10		M10654		009-099

SPARE WIRE LIST

D280N032

91-21-12

Section D41498J

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From		Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41714J			W3516	R1	RCPT-							
D41714P	8			0308	20	GA	D41716J	8		D41716P		001-099
D41714P	8			0308	20	GA	D41716J	8		D41716P		001-099
D41714P	11			0311	20	GA	D41716J	11		D41716P		001-099
D41714P	11			0311	20	GA	D41716J	11		D41716P		001-099
D41714P	12			0312	20	GA	D41716J	12		D41716P		001-099
D41714P	12			0312	20	GA	D41716J	12		D41716P		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D41714J

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41714P			W3514	R1	PLUG-							
D41714J		8		0308	20	GA	D40376P	8		AP0034	11	001-099
D41714J		9		0309	20	GA	D40376P	9		AP0034	11	001-099
D41714J		12		0312	20	GA	D40376P	12		AP0034	11	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D41714P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41716P		W3516	R1	PLUG-							
D41716J	8		0308	20	GA	D41714P	8		D41714J		001-099
D41716J	11		0311	20	GA	D41714P	11		D41714J		001-099
D41716J	12		0312	20	GA	D41714P	12		D41714J		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D41716P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41735J			W3135	R2	RCPT-							
I	D41735P	9		0013	20	GA	D00309	CAP	Y	M00242		001-099
I	D41735P	9		0013	20	GA	D00309	CAP	Y	M00242		001-099
I	D41735P	10		0014	20	GA	D00309	CAP	Y	M00242		001-099
I	D41735P	10		0014	20	GA	D00309	CAP	Y	M00242		001-099
I	D41735P	11		0015	20	GA	D00309	CAP	Y	M00242		001-099
I	D41735P	11		0015	20	GA	D00309	CAP	Y	M00242		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D41735J

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith		Pos	Bundle	Sep	Description		To					
From												
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41735P			W2665	R2	PLUG-							
D41735J	9			0009	20	GA	D42059P	9		AE0302	03	001-099
D41735J	9			0009	20	GA	D42059P	9		AE0302	03	001-099
D41735J	10			0010	20	GA	D42059P	10		AE0302	03	001-099
D41735J	10			0010	20	GA	D42059P	10		AE0302	03	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D41735P

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41814J			W3616	R1	RCPT-							
D41814P	8		0308		20	GA	D41816J	8		D41816P		001-099
D41814P	8		0308		20	GA	D41816J	8		D41816P		001-099
D41814P	12		0312		20	GA	D41816J	12		D41816P		001-099
D41814P	12		0312		20	GA	D41816J	12		D41816P		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D41814J

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
D41814P		W3614	R1	PLUG-								
D41814J	8		0308	20	GA	D40476P	8		AP0034	15	001-099	
D41814J	9		0309	20	GA	D40476P	9		AP0034	15	001-099	
D41814J	12		0312	20	GA	D40476P	12		AP0034	15	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section D41814P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
D41816P			W3616	R1	PLUG-							
D41816J		8		0308	20	GA	D41814P	8		D41814J		001-099
D41816J		8		0308	20	GA	D41814P	8		D41814J		001-099
D41816J		12		0312	20	GA	D41814P	12		D41814J		001-099
D41816J		12		0312	20	GA	D41814P	12		D41814J		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section D41816P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
D42052P		W3576	R1	PLUG-							
D42052J	11		0072	24 GK	D41474P	29		AP0034	16	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section D42052P

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
GALLEY 2A			W3644	R1								
D01660		9		0059	22	GA	D40664P	13		AP0032	02	001-099
D01660		10		0060	22	GA	D40664P	14		AP0032	02	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section GALLEY 2A

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
K00124			W1260	L*	RELAY-AIR/GND,SYS 1							
D00582	3			5644	24	GK	D41497J	3		AP0036	12	115-199
D00582	5			5645	24	GK	GD01674	DC..	2			115-199

SPARE WIRE LIST

D280N032

91-21-12

Section K00124

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
K00140			W1260	L*	RELAY-AIR/GND,SYS 1							
D00584		1		2007B	24	GL	D41612J	45		AP0036	28	115-199
D00584		13		2007R	24	GL	D41612J	27		AP0036	28	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section K00140

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
K00200		W1270	R*	RELAY-AIR/GND,SYS 2								
D00610	9		2004B	24	GL	D41728J	CAP	Y	AP0037	24	115-199	
D00610	11		2004R	24	GL	D41728J	CAP	Y	AP0037	24	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section K00200

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
K00419			W1260	L*	RELAY-PARKING BRAKE CLOSE SENSE							
D02768		1		5646	24	GK	D41497J	4		AP0036	12	115-199
D02768		2		5647	24	GK	GD01674	DC..	2			115-199

SPARE WIRE LIST

D280N032

91-21-12

Section K00419

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
K10126		W1260	L*	RELAY-OPEN DISAGREE,L								
D02158	7		0397	22	GK	GD01684	DC..	2			115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section K10126

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
L00809			W3632	R2								
D06854		1	VY	0713	16	GA	D06910	13	16	M10919		001-006
D06854		1	VY	0713	16	GA	D07994	13	16	M11030		007-099
D06856		1	VG	0753	20	GA	GD03936	DC..	E			001-099

SPARE WIRE LIST

D280N032

91-21-12

Section L00809

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
L823		W3632	R2									
D06916	1	VY	0711	16	GA	D06910	11	16	M10919		001-006	
D06916	1	VY	0711	16	GA	D07994	11	16	M11030		007-099	
D06918	1	VG	0751	20	GA	GD04014	DC..	E			001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section L823

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
L824		W3632	R2									
D06920	1	VY	0712	16	GA	D06910	12	16	M10919		001-006	
D06920	1	VY	0712	16	GA	D07994	12	16	M11030		007-099	
D06922	1	VG	0752	20	GA	GD04014	DC..	E			001-099	

SPARE WIRE LIST

D280N032

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details

91-21-12

Section L824

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M00001		W2080	A*	PNL-APU CONTROL(SEE YRD++++)								
D03576	CAP	Y	0032	20	GA	D40602P	7		AE0402	19	001-099	
D03576	CAP	Y	0033	20	GA	D41868P	9		AE0503	01	001-099	
D03576	CAP	Y	0035	20	GA	D40602P	8		AE0402	19	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section M00001

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00013			W2066	L*	PNL-CABIN ALTITUDE CONT							
D02344	CAP	Y	0508		20	GA	D40874P	44		AP0036	17	115-199
D02344	CAP	Y	0509		20	GA	D40874P	45		AP0036	17	115-199
D02344	CAP	Y	0539		20	GA	D40584P	55		AE0402	47	115-199
M00013			W2078	S*	PNL-CABIN ALTITUDE CONT							
D02346	CAP	Y	0410		20	GA	D41844P	29		AE0402	20	115-199
D02346	CAP	Y	0411		20	GA	D41844P	30		AE0402	20	115-199
D02346	CAP	Y	0412		20	GA	D41844P	31		AE0402	20	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00013

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M00019		W2078	S*	PNL-CABIN PRESSURIZATION								
D02696	CAP	Y	0365	20	GA	D41414P	32		AP0033	26	115-199	
D02696	CAP	Y	0366	20	GA	D41414P	33		AP0033	26	115-199	
D02696	CAP	Y	0367	20	GA	D41414P	34		AP0033	26	115-199	
D02696	CAP	Y	0368	20	GA	D41414P	35		AP0033	26	115-199	
D02696	CAP	Y	0369	20	GA	D41414P	36		AP0033	26	115-199	
D02696	CAP	Y	0389	20	GA	D40570P	32		AP0037	06	115-199	
D02696	CAP	Y	0390	20	GA	D40570P	33		AP0037	06	115-199	
D02696	CAP	Y	0391	20	GA	D40570P	34		AP0037	06	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M00019

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00033			W2351	N2	PNL-FLIGHT RECORDER/SERVICE INTERPHONE							
D00471	12			0055	24	GK	D41541P	51		AE0403	23	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section M00033

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00051		W2351	N2	PNL-PILOTS CALL							
D00333	50		0045	24	GK	D41541P	17		AE0403	23	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00051

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00056		W2064	L*	PNL-ANTI-COLLISION & LANDING LTS CONT							
D03505	CAP	Y	0177	20	GA	D41410P	26		AP0033	06	001-099
D03505	CAP	Y	0178	20	GA	D40582P	30		AP0036	25	001-099
D03505	CAP	Y	0179	20	GA	D40582P	31		AP0036	25	001-099
D03505	CAP	Y	0188	20	GA	D41852P	15		AP0037	10	001-099
D03505	CAP	Y	0189	20	GA	D41852P	16		AP0037	10	001-099
M00056		W2072	R*	PNL-ANTI-COLLISION & LANDING LTS CONT							
D03507	CAP	Y	0130	20	GA	D40594P	19		AP0037	02	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section M00056

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith		Pos	Bundle	Sep	Description		To					
From												
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00076			W2331	N2	CONT DISP UNIT-FLT MGMT COMPUTER,L							
D00171	CAP	Y	5004B		24	G2	D41081P	13		AE0201	25	115-199
D00171	CAP	Y	5004B		24	G2	D41081P	13		AE0201	25	115-199
D00171	CAP	Y	5004R		24	G2	D41081P	12		AE0201	25	115-199
D00171	CAP	Y	5004R		24	G2	D41081P	12		AE0201	25	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00076

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To				Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		
I	M00077			W2333	N2	CONT DISP UNIT-FMCS, R (34-0414)							
I	D00175		CAP	Y	5004B	24	G2	D41083P	13		AE0202	05	115-199
I	D00175		CAP	Y	5004R	24	G2	D41083P	12		AE0202	05	115-199
I	D00175		DED		5004Z			D41083P	14		AE0202	05	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00077

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M00090		W2041	L*	PNL-MODE CONT,AUTO FLT CONT SYS(SB22A49)							
D00037	CAP	Y	0027	22 GA	D40629P	27		AP0001	08	115-199	
M00090		W2051	R2	PNL-MODE CONT,AUTO FLT CONT SYS(SB22A49)							
D00077	CAP	Y	0023	22 GA	D40631P	14		AP0003	08	115-199	
D00077	CAP	Y	0024	22 GA	D40631P	15		AP0003	08	115-199	
M00090		W2061	C2	PNL-MODE CONT,AUTO FLT CONT SYS(SB22A49)							
D00057	9		0009	22 GA	D40633P	7		AP0001	06	115-199	
D00057	10		0010	22 GA	D40633P	8		AP0001	06	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M00090

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00091			W2041	L*	CONT PNL-VOR,LEFT							
D00259		CAP	Y	0029	22	GA	D40629P	35		AP0001	08	115-199
D00259		CAP	Y	0030	22	GA	D40629P	36		AP0001	08	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00091

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description							
Equip	Term	Type	Wire No.	GA	TY	To Equip	Term	Type	Matewith	Pos	Effectivity
M00092		W2051	R2	CONT PNL-VOR,RIGHT							
D00261	CAP	Y	0026	22	GA	D40631P	37		AP0003	08	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00092

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00093			W2323	R2	CONT PNL-EFIS,F/O							
D00097	14			0028	24	GK	D41077P	34		AE0202	32	002

SPARE WIRE LIST

D280N032

91-21-12

Section M00093

Page 1 End

May 17/2006



757-200 WIRING DIAGRAM MANUAL

From Matewith		Pos	Bundle	Sep	Description		To				
From											
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00138			W1433	N2	UNIT-DIGITAL FLIGHT DATA ACQUISITION						
I	D00011D	F14		5040B	24	G2	D41361J	18	AE0303	36	115-199
I	D00011D	F14		5040B	24	G2	D41361J	18	AE0303	36	115-199
I	D00011D	E14		5040R	24	G2	D41361J	17	AE0303	36	115-199
I	D00011D	E14		5040R	24	G2	D41361J	17	AE0303	36	115-199
I	D00011D	DED		5040Z			D41361J		AE0303	36	115-199
I	D00011D	DED		5040Z			D41361J		AE0303	36	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00138

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00147			W1175	C2	COMPUTER-GROUND PROXIMITY							
D00433B	D01		5072B		24	G2	D41433J	18		AE0203	03	115-199
D00433B	C01		5072R		24	G2	D41433J	19		AE0203	03	115-199
D00433B	DED		5072Z				D41433J			AE0203	03	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00147

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00241			W3133	L2	ANTENNA COUPLER-HF COMM,L							
D00307	CAP	Y	0013		20	GA	D41733J	9				001-099
D00307	CAP	Y	0014		20	GA	D41733J	10				001-099
D00307	CAP	Y	0015		20	GA	D41733J	11				001-099

SPARE WIRE LIST

D280N032

91-21-12

Section M00241

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00242			W3135	R2	ANTENNA COUPLER-HF COMM,R							
D00309		CAP	Y	0013	20	GA	D41735P	9		D41735J		001-099
D00309		CAP	Y	0013	20	GA	D41735J	9				115-199
D00309		CAP	Y	0014	20	GA	D41735P	10		D41735J		001-099
D00309		CAP	Y	0014	20	GA	D41735J	10				115-199
D00309		CAP	Y	0015	20	GA	D41735P	11		D41735J		001-099
D00309		CAP	Y	0015	20	GA	D41735J	11				115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00242

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith		Pos	Bundle	Sep	Description		To					
From												
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00269			W2021	N2	ANTENNA-FLAT PLATE - WXR							
I D00167	CAP	Y	2506B		22	GF	D00473	CAP	Y	D00477		001-099
I D00167	CAP	Y	2506B		22	GF	D00473	CAP	Y	D00477		001-099
D00167	CAP	Y	2506B		22	GF	D00473	CAP	Y	D00477		115-199
D00167	CAP	Y	2506R		22	GF	D00473	CAP	Y	D00477		001-099
I D00167	CAP	Y	2506R		22	GF	D00473	CAP	Y	D00477		001-099
D00167	CAP	Y	2506R		22	GF	D00473	CAP	Y	D00477		115-199
D00167	DED		2506Z				D00473	DED		D00477		001-099
I D00167	DED		2506Z				D00473	DED		D00477		001-099
D00167	DED		2506Z				D00473	DED		D00477		115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00269

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M00726		W3326	N2	ASSEMBLY-HARNESS,L MAIN TANK								
D02788	13		4501AA	20	4K	D41192J	14		AW1333	02	115-199	
D02788	14		4501WV	20	4K	D41192J	15		AW1333	02	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M00726

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description			To					
Equip	Term	Type	Wire No.	GA	TY		Equip	Term	Type	Matewith	Pos	Effectivity
M00727		W3462	N2	ASSEMBLY-HARNESS,R MAIN TANK								
D02814	13		4501AA	20	4K		D41196J	14		AW2333	04	115-199
D02814	14		4501WV	20	4K		D41196J	15		AW2333	04	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M00727

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00732			W3632	R2	POWER SUPPLY-EMERGENCY LTS							
D00070		CAP	Y	0040	20	GA	D40454J	5		AA0409	03	ALL
D00070		CAP	Y	0041	20	GA	D40454J	6		AA0409	03	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section M00732

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M00733		W3532	R2	POWER SUPPLY-EMERGENCY LTS								
D00072	CAP	Y	0040	20	GA	D40354J	5		AA0409	09	ALL	
D00072	CAP	Y	0041	20	GA	D40354J	6		AA0409	09	ALL	

SPARE WIRE LIST

D280N032

91-21-12

Section M00733

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00736			W3634	R2	POWER SUPPLY-EMERGENCY LTS							
D00078	CAP	Y	0040		20	GA	D40456J	5		AA0409	05	ALL
D00078	CAP	Y	0041		20	GA	D40456J	6		AA0409	05	ALL

SPARE WIRE LIST

D280N032

91-21-12

Section M00736

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description								To		
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity			
M00737		W3534	R2	POWER SUPPLY-EMERGENCY LTS										
D00080		Y	0040	20	GA	D40356J	5		AA0409	06	ALL			
D00080	CAP	Y	0041	20	GA	D40356J	6		AA0409	06	ALL			

SPARE WIRE LIST

D280N032

91-21-12

Section M00737

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M00968			W0069	N2	TEST PLUG							
D00761		13		5001B	24	G2	D40003J	11		AP0061	04	001-099
D00761		12		5001R	24	G2	D40003J	10		AP0061	04	001-099
D00761				5001Z			D40003J	7		AP0061	04	001-099
D00761		7		5003B	24	G2	D40003J	17		AP0061	04	001-099
D00761		6		5003R	24	G2	D40003J	16		AP0061	04	001-099
D00761				5003Z			D40003J	33		AP0061	04	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section M00968

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10013		W3572	L1	MODULE-LAV B,FWD,L(SEE YRJ++++)								
D00044	12		0089	20	GA	D41120J	10		AA0409	01	115-199	
D00044	25		0092	20	GA	D40496P	13		AP0037	21	115-199	
D00044	26		0093	20	GA	D40496P	14		AP0037	21	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M10013

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10014			W3672	R1	MODULE-LAV C,MID,L(SEE YRK++++)							
D00046		24		0117	20	GA	D41302P	24		AP0037	21	001-099
D00046		24		0117	20	GA	D41302P	24		AP0037	15	115-199
D00046		CAP	Y	0118	20	GA	D41302P	25		AP0037	21	001-099
D00046		25		0118	20	GA	D41302P	25		AP0037	15	115-199
D00046		CAP	Y	0119	20	GA	D41302P	26		AP0037	21	001-099
D00046		26		0119	20	GA	D41302P	26		AP0037	15	115-199
D00046		10		0175	20	GA	D40494J	8		AA0409	04	001-099
D00046		25		2004B	24	GL	D00048	25		M10015		001-099
D00046		26		2004R	24	GL	D00048	26		M10015		001-099

SPARE WIRE LIST

D280N032

91-21-12

Section M10014

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10015		W3672	R1	MODULE-LAV D,MID,R(SEE YRL++++)								
D00048	31		0114	20	GA	D41302P	29		AP0037	21	001-099	
D00048	31		0114	20	GA	D41302P	29		AP0037	15	115-199	
D00048	32		0115	20	GA	D41302P	30		AP0037	21	001-099	
D00048	32		0115	20	GA	D41302P	30		AP0037	15	115-199	
D00048	33		0116	20	GA	D41302P	31		AP0037	21	001-099	
D00048	33		0116	20	GA	D41302P	31		AP0037	15	115-199	
D00048	24		0182	24	GK	SP01266		9			001-099	
D00048	25		2004B	24	GL	D00046	25		M10014		001-099	
D00048	26		2004R	24	GL	D00046	26		M10014		001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section M10015

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
From					GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
Equip		Term	Type	Wire No.								
M10023			W2070	R*	PANEL-WINDSHIELD CLEARANCE(SEE YPP++++)							
D03520		CAP	Y	0449	20	GA	D41412P	23		AP0033	30	001-099
D03520		CAP	Y	0449	20	GA	D41412P	23		AP0033	10	115-199
D03520		CAP	Y	0450	20	GA	D41412P	24		AP0033	30	001-099
D03520		CAP	Y	0450	20	GA	D41412P	24		AP0033	10	115-199
D03520		CAP	Y	0451	20	GA	D41412P	25		AP0033	10	115-199
D03520		CAP	Y	0465	20	GA	D41058P	43		AE0402	22	115-199
D03520		CAP	Y	0466	20	GA	D41058P	44		AE0402	22	115-199
D03520		CAP	Y	0533	22	GA	D41856P	34		AP0037	33	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section M10023

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10050		W2066	L*	PANEL-HYDRAULICS(SEE YQT++++)								
D03544	CAP	Y	0532	20	GA	D40584P	6		AE0402	47	ALL	
D03544	CAP	Y	0533	20	GA	D40584P	7		AE0402	47	ALL	
M10050		W2070	R*	PANEL-HYDRAULICS(SEE YQT++++)								
D03546	CAP	Y	0114	22	GA	D41856P	50		AP0037	33	ALL	
D03546	CAP	Y	0414	20	GA	D41860P	25		AP0037	11	ALL	
D03546	CAP	Y	0421	20	GA	D40608P	21		AP0036	06	115-199	
D03546	CAP	Y	0422	20	GA	D40608P	CAP	Y	AP0036	06	115-199	
D03546	CAP	Y	0429	20	GA	D40608P	29		AP0036	06	115-199	
D03546	CAP	Y	0441	20	GA	D41412P	9		AP0033	10	115-199	
D03546	CAP	Y	0442	20	GA	D41412P	10		AP0033	30	001-099	
D03546	CAP	Y	0442	20	GA	D41412P	10		AP0033	10	115-199	
D03546	CAP	Y	0461	20	GA	D41058P	CAP	Y	AE0402	22	115-199	
D03546	CAP	Y	0462	20	GA	D41058P	40		AE0402	22	115-199	
M10050		W2078	S*	PANEL-HYDRAULICS(SEE YQT++++)								
D03548	CAP	Y	0402	20	GA	D41844P	21		AE0402	04	001-099	
D03548	CAP	Y	0402	20	GA	D41844P	21		AE0402	20	115-199	
D03548	CAP	Y	0403	20	GA	D41844P	22		AE0402	04	001-099	
D03548	CAP	Y	0403	20	GA	D41844P	22		AE0402	20	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M10050

Page 1 End

Dec 18/2007



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To						
From					GA	TY							
Equip	Term	Type	Wire No.				Equip	Term	Type	Matewith	Pos	Effectivity	
M10054			W2066	L*	PANEL-FUEL QTY (KG)(MR69018-002)								
D03510	38			0270	24	GK	D40996P	8		AE0304	21	115-199	
D03510	38			0270	24	GK	D40996P	8		AE0304	21	115-199	
D03510	25			0277	24	GK	D40996P	15		AE0304	21	115-199	
D03510	25			0277	24	GK	D40996P	15		AE0304	21	115-199	
D03510	CAP	Y		0529	20	GA	D41854P	25		AP0037	47	115-199	
D03510	CAP	Y		0529	20	GA	D41854P	25		AP0037	47	115-199	
D03510	32			2001B	24	GL	D40996P	4		AE0304	21	115-199	
D03510	32			2001B	24	GL	D40996P	4		AE0304	21	115-199	
D03510	16			2001R	24	GL	D40996P	24		AE0304	21	115-199	
D03510	16			2001R	24	GL	D40996P	24		AE0304	21	115-199	
D03510	12			2005B	24	GL	D40996P	5		AE0304	21	115-199	
D03510	12			2005B	24	GL	D40996P	5		AE0304	21	115-199	
D03510	11			2005R	24	GL	D40996P	7		AE0304	21	115-199	
D03510	11			2005R	24	GL	D40996P	7		AE0304	21	115-199	
D03510	29			2006B	24	GL	D40996P	21		AE0304	21	115-199	
D03510	29			2006B	24	GL	D40996P	21		AE0304	21	115-199	
D03510	13			2006R	24	GL	D40996P	6		AE0304	21	115-199	
D03510	13			2006R	24	GL	D40996P	6		AE0304	21	115-199	
D03510	10			2007B	24	GL	D40996P	13		AE0304	21	115-199	
D03510	10			2007B	24	GL	D40996P	13		AE0304	21	115-199	
D03510	24			2007R	24	GL	D40996P	16		AE0304	21	115-199	
D03510	24			2007R	24	GL	D40996P	16		AE0304	21	115-199	
D03510	20			2008B	24	GL	D40996P	CAP	Y	AE0304	21	115-199	
D03510	20			2008B	24	GL	D40996P	CAP	Y	AE0304	21	115-199	
D03510	39			2008R	24	GL	D40996P	CAP	Y	AE0304	21	115-199	
D03510	39			2008R	24	GL	D40996P	CAP	Y	AE0304	21	115-199	
D03510	19			2009B	24	GL	D40996P	CAP	Y	AE0304	21	115-199	
D03510	19			2009B	24	GL	D40996P	CAP	Y	AE0304	21	115-199	
D03510	18			2009R	24	GL	D40996P	CAP	Y	AE0304	21	115-199	
D03510	18			2009R	24	GL	D40996P	CAP	Y	AE0304	21	115-199	
D03584	CAP	Y		0540	20	GA	D41170J	4		AP0003	03	115-199	
D03584	CAP	Y		0540	20	GA	D41170J	4		AP0003	03	115-199	
D03584	CAP	Y		0541	20	GA	D41834J	6		AP0003	04	115-199	
D03584	CAP	Y		0541	20	GA	D41834J	6		AP0003	04	115-199	
D06872	CAP	Y		0529	20	GA	D41854P	25		AP0037	47	001-099	
D06872	CAP	Y		0540	20	GA	D41170J	4		AP0003	03	001-099	
D06872	CAP	Y		0541	20	GA	D41834J	6		AP0003	04	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section M10054

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith		Pos	Bundle	Sep	Description		To					Pos	Effectivity
From		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
Equip													
M10054			W2070	R*	PANEL-FUEL QTY (KG)(MR69018-002)								
D03536		38		0086	24	GK	D41876P	5		AE0304		10	115-199
D03536		38		0086	24	GK	D41876P	5		AE0304		10	115-199
D03536		20		2001B	24	GL	D41876P	CAP	Y	AE0304		10	115-199
D03536		20		2001B	24	GL	D41876P	CAP	Y	AE0304		10	115-199
D03536		39		2001R	24	GL	D41876P	6		AE0304		10	115-199
D03536		39		2001R	24	GL	D41876P	6		AE0304		10	115-199
D03536		19		2002B	24	GL	D41876P	CAP	Y	AE0304		10	115-199
D03536		19		2002B	24	GL	D41876P	CAP	Y	AE0304		10	115-199
D03536		18		2002R	24	GL	D41876P	CAP	Y	AE0304		10	115-199
D03536		18		2002R	24	GL	D41876P	CAP	Y	AE0304		10	115-199
D03536		32		2003B	24	GL	D41876P	11		AE0304		10	115-199
D03536		32		2003B	24	GL	D41876P	11		AE0304		10	115-199
D03536		16		2003R	24	GL	D41876P	10		AE0304		10	115-199
D03536		16		2003R	24	GL	D41876P	10		AE0304		10	115-199
D03536		10		2008B	24	GL	D41876P	13		AE0304		10	115-199
D03536		10		2008B	24	GL	D41876P	13		AE0304		10	115-199
D03536		24		2008R	24	GL	D41876P	12		AE0304		10	115-199
D03536		24		2008R	24	GL	D41876P	12		AE0304		10	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10054

Page 2 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

	From	Matewith	Pos	Bundle	Sep	Description		To	Term	Type	Matewith	Pos	Effectivity
	Equip		Term	Type	Wire No.	GA	TY	Equip					
I	M10055			W2066	L*	PANEL-FUEL CONTROL (SB 28A0105)							
	D03512		CAP	Y	0553	22	GA	D41870P	30		AP0033	23	115-199
I	M10055			W2070	R*	PANEL-FUEL CONTROL (SB 28A0105)							
I	D03514		CAP	Y	0439	20	GA	D41412P	7		AP0033	30	001-099
I	D03514		14		0439	20	GA	D41412P	7		AP0033	10	115-199
I	M10055			W2078	S*	PANEL-FUEL CONTROL (SB 28A0105)							
	D03516		CAP	Y	0407	20	GA	D41844P	26		AE0402	20	115-199
	D03516		CAP	Y	0408	20	GA	D41844P	27		AE0402	20	115-199
	D03516		CAP	Y	0409	20	GA	D41844P	28		AE0402	20	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10055

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith		Pos	Bundle	Sep	Description		To					Pos	Effectivity
From		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
M10056			W2066	L*	PANEL-LIGHTING CONTROL,L (SEE YSN++++)								
D03503		CAP	Y	0528	20	GA	D41854P	24		AP0037	47	001-099	
D03503		CAP	Y	0528	20	GA	D41854P	24		AP0037	47	001-099	
D03503		CAP	Y	0528	20	GA	D41854P	24		AP0037	47	115-199	
D03503		CAP	Y	0534	20	GA	D40584P	46		AE0402	47	001-099	
D03503		CAP	Y	0534	20	GA	D40584P	46		AE0402	47	001-099	
D03503		CAP	Y	0535	20	GA	D40584P	47		AE0402	47	001-099	
D03503		CAP	Y	0535	20	GA	D40584P	47		AE0402	47	001-099	
M10056			W2078	S*	PANEL-LIGHTING CONTROL,LEFT								
D03501		CAP	Y	0352	20	GA	D41850P	50		AP0036	14	115-199	
D03501		CAP	Y	0358	20	GA	D41414P	25		AP0033	26	115-199	
D03501		CAP	Y	0359	20	GA	D41414P	26		AP0033	26	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M10056

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10057			W2070	R*	MODULE-LIGHTING CONTROL,R (SEE YSP++++)							
D03532		CAP	Y	0417	20	GA	D41860P	28		AP0037	11	115-199
D03532		CAP	Y	0418	20	GA	D41860P	29		AP0037	11	115-199
D03532		CAP	Y	0446	20	GA	D41412P	19		AP0033	10	115-199
D03532		CAP	Y	0447	20	GA	D41412P	21		AP0033	10	115-199
D03532		CAP	Y	0448	20	GA	D41412P	22		AP0033	10	115-199
D03532		CAP	Y	0467	20	GA	D41058P	45		AE0402	22	115-199
D03532		CAP	Y	0468	20	GA	D41058P	50		AE0402	22	115-199
D03532		22		0800	20	GA	D41058P	CAP	Y	AE0402	22	115-199
D03532		21	18	0803	18	GA	D41058P	38	18	AE0402	22	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10057

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description	To						
Equip	Term	Type	Wire No.	GA TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10063		W2066	L*	PANEL-ELECTRICAL (SEE YTH++++)							
D03500	CAP	Y	0534	20 GA	D40584P	46		AE0402	47	115-199	
D03500	CAP	Y	0535	20 GA	D40584P	47		AE0402	47	115-199	
M10063		W2070	R*	PANEL-ELECTRICAL (SEE YTH++++)							
D03502	18		0019	20 GA	D40802J	1		AP0005	31	115-199	
D03502	CAP	Y	0415	20 GA	D41860P	26		AP0037	11	115-199	
D03502	CAP	Y	0416	20 GA	D41860P	27		AP0037	11	ALL	
D03502	CAP	Y	0424	20 GA	D40608P	24		AP0036	06	115-199	
D03502	CAP	Y	0425	20 GA	D40608P	25		AP0036	06	115-199	
D03502	CAP	Y	0443	20 GA	D41412P	11		AP0033	10	115-199	
D03502	CAP	Y	0444	20 GA	D41412P	16		AP0033	10	115-199	
D03502	CAP	Y	0445	20 GA	D41412P	17		AP0033	10	115-199	
D03502	CAP	Y	0463	20 GA	D41058P	CAP	Y	AE0402	22	ALL	
D03502	CAP	Y	0464	20 GA	D41058P	22		AE0402	22	001-099	
D03502	CAP	Y	0464	20 GA	D41058P	42		AE0402	22	115-199	
M10063		W2078	S*	PANEL-ELECTRICAL (SEE YTH++++)							
D03504	CAP	Y	0404	20 GA	D41844P	23		AE0402	20	115-199	
D03504	CAP	Y	0405	20 GA	D41844P	24		AE0402	20	115-199	
D03504	CAP	Y	0406	20 GA	D41844P	25		AE0402	20	115-199	
M10063		W2080	A*	PANEL-ELECTRICAL (SEE YTH++++)							
D03506	CAP	Y	0032	20 GA	D40602P	7		AE0402	19	115-199	
D03506	CAP	Y	0033	20 GA	D41868P	9		AE0503	01	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M10063

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10140			W2075	L2	PNL-TRANSPONDER CONTROL							
D00255		19		0009	24	GK	D41525P	1		AE0303	06	115-199
M10140			W2077	R2	PNL-TRANSPONDER CONTROL							
D00257		17		0007	22	GA	D41527P	7		AE0302	28	115-199
D00257		19		0009	24	GK	D41527P	1		AE0302	28	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10140

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10191		W2070	R*	PNL-GEN FIELD AND HYD (SEE YQZ++++)								
D03710	6		0092	20	GA	GD00617	DC..	2			115-199	
D03710	6		0092	20	GA	GD00617	DC..	2			115-199	
D03710	CAP	Y	0104	24	GK	D40598P	30		AE0502	26	001-003	
D03710	CAP	Y	0104	24	GK	D40598P	30		AE0502	26	001-003	
D03710	CAP	Y	0104	24	GK	D40598P	30		AE0502	26	004-099	
D03710	5		0104	24	GK	D40598P	30		AE0502	26	115-199	
D03710	5		0104	24	GK	D40598P	30		AE0502	26	115-199	
M10191		W2080	A*	PNL-GEN FIELD AND HYD (SEE YQZ++++)								
D03714	CAP	Y	0036	20	GA	D40602P	11		AE0402	19	001-003, 115-199	
D03714	CAP	Y	0036	20	GA	D40602P	11		AE0402	19	001-003, 115-199	
D03714	CAP	Y	0036	20	GA	D40602P	11		AE0402	19	004-099	
D03714	CAP	Y	0037	20	GA	D41868P	11		AE0503	01	115-199	
D03714	CAP	Y	0037	20	GA	D41868P	11		AE0503	01	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M10191

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10193			W2066	L*	PNL-AIR CONDITIONING CONTROL (YNR++++)							
D03556		34		0246	24	GK	D41854P	31		AP0037	47	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10193

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10250			W2072	R*	PNL-YAW DAMPER(SEE YPJ++++)							
D03513	CAP	Y	0121		20	GA	D40594P	30		AP0037	02	ALL
D03513	CAP	Y	0122		20	GA	D40594P	31		AP0037	02	ALL
D03513	CAP	Y	0123		20	GA	D40594P	32		AP0037	02	115-199
D03513	CAP	Y	0124		20	GA	D40594P	33		AP0037	02	115-199
D03513	14		0132		22	GA	D40594P	45		AP0037	02	115-199
D03513	13		0133		22	GA	D40594P	39		AP0037	02	115-199
D03513	2		0134		22	GA	D40594P	40		AP0037	02	115-199
D03513	1		0135		22	GA	D40594P	41		AP0037	02	115-199
D03513	15		0136		22	GA	D40594P	43		AP0037	02	115-199
M10250			W2078	S*	PNL-YAW DAMPER(SEE YPJ++++)							
D03511	11		0346		22	GA	D41850P	44		AP0036	14	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10250

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10259		W2066	L*	PNL-BLEED AIR (SEE YNN++++)								
D03538	14		0241	24	GK	D40800J	55		AP0005	16	ALL	
D03538	CAP	Y	0508	20	GA	D40874P	44		AP0036	17	001-099	
D03538	CAP	Y	0509	20	GA	D40874P	45		AP0036	17	001-099	
D03538	CAP	Y	0511	20	GA	D40874P	47		AP0036	17	ALL	
D03538	CAP	Y	0530	20	GA	D41854P	26		AP0037	47	115-199	
D03538	CAP	Y	0537	20	GA	D40584P	53		AE0402	47	ALL	
D03538	CAP	Y	0539	20	GA	D40584P	55		AE0402	47	001-099	
M10259		W2070	R*	PNL-BLEED AIR (SEE YNN++++)								
D03540	CAP	Y	0419	20	GA	D41860P	CAP	Y	AP0037	11	001-002, 115-199	
D03540	CAP	Y	0419	20	GA	D41860P	30		AP0037	11	003-099	
D03540	CAP	Y	0426	20	GA	D40608P	CAP	Y	AP0036	06	115-199	
D03540	CAP	Y	0453	20	GA	D41412P	27		AP0033	10	115-199	
D03540	CAP	Y	0454	20	GA	D41412P	28		AP0033	30	001-099	
D03540	CAP	Y	0454	20	GA	D41412P	28		AP0033	10	115-199	
D03540	CAP	Y	0469	20	GA	D41058P	51		AE0402	22	115-199	
D03540	CAP	Y	0470	20	GA	D41058P	52		AE0402	22	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M10259

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To							
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity		
M10321		W3576	R1	FWD ENTRY LIGHT ASSY-									
D03438	11		0052	22	GA	D03456	CAP	Y	AA0360	03	115-199		

SPARE WIRE LIST

D280N032

91-21-12

Section M10321

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10324			W2080	A*	PNL-AUX PWR UNIT START (SEE YQL++++)							
D03576	CAP	Y	0034		20	GA	D41868P	10		AE0503	01	115-199
D03576	CAP	Y	0035		20	GA	D40602P	8		AE0402	19	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10324

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10394			W2072	R*	PANEL-ANNUNCIATOR							
D03566	2		0016		24	GK	D40594P	44		AP0037	02	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10394

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10396			W2064	L*	PANEL-LIGHTING ANTI-COLLISION							
D03505	CAP	Y	0176		20	GA	D41410P	25		AP0033	06	115-199
D03505	CAP	Y	0177		20	GA	D41410P	26		AP0033	06	115-199
D03505	CAP	Y	0178		20	GA	D40582P	30		AP0036	25	115-199
D03505	CAP	Y	0179		20	GA	D40582P	31		AP0036	25	115-199
D03505	CAP	Y	0188		20	GA	D41852P	15		AP0037	10	115-199
D03505	CAP	Y	0189		20	GA	D41852P	16		AP0037	10	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10396

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10397		W2078	S*	PANEL-ANTI-ICE (SEE YAQ++++)								
D03528	CAP	Y	0353	20	GA	D41850P	51		AP0036	14	115-199	
D03528	CAP	Y	0354	20	GA	D41850P	52		AP0036	14	115-199	
D03528	CAP	Y	0360	20	GA	D41414P	27		AP0033	26	115-199	
D03528	CAP	Y	0361	20	GA	D41414P	28		AP0033	26	115-199	
D03528	CAP	Y	0362	20	GA	D41414P	29		AP0033	26	115-199	
D03528	CAP	Y	0363	20	GA	D41414P	30		AP0033	26	115-199	
D03528	CAP	Y	0364	20	GA	D41414P	31		AP0033	26	115-199	
D03528	CAP	Y	0387	20	GA	D40570P	30		AP0037	06	ALL	
D03528	CAP	Y	0388	20	GA	D40570P	31		AP0037	06	ALL	
M10397		W2156	S*	PANEL-ANTI-ICE (SEE YAQ++++)								
D03530	CAP	Y	0132	16	GA	D41060P	21		AP0036	24	115-199	
D03530	CAP	Y	0141	20	GA	D41858P	22		AP0037	43	115-199	
D03530	CAP	Y	0143	20	GA	D41858P	24		AP0037	43	115-199	
D03530	CAP	Y	0144	20	GA	D41858P	25		AP0037	43	ALL	
D03530	CAP	Y	0146	20	GA	D41060P	30		AP0036	24	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M10397

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10398			W2066	L*	PANEL-TEST PANEL(SEE YPH++++)							
D03702	CAP	Y	0094		22	GA	D40972P	2		AP0050	03	ALL
D03702	CAP	Y	0505		20	GA	D40874P	41		AP0036	17	ALL
D03702	CAP	Y	0531		20	GA	D41854P	27		AP0037	47	ALL
D03702	CAP	Y	0538		20	GA	D40584P	54		AE0402	47	ALL
M10398			W2070	R*	PANEL-TEST PANEL(SEE YPH++++)							
D03704	CAP	Y	0423		20	GA	D40608P	23		AP0036	06	115-199
D03704	CAP	Y	0451		20	GA	D41412P	25		AP0033	30	001-099
D03704	CAP	Y	0456		20	GA	D41412P	30		AP0033	30	001-099
D03704	CAP	Y	0456		20	GA	D41412P	30		AP0033	10	115-199
D03704	CAP	Y	0457		20	GA	D41412P	CAP	Y	AP0033	10	115-199
D03704	CAP	Y	0471		20	GA	D41058P	53		AE0402	22	115-199
D03704	CAP	Y	0472		20	GA	D41058P	19		AE0402	22	001-099
D03704	CAP	Y	0472		20	GA	D41058P	54		AE0402	22	115-199
D03704	CAP	Y	0473		20	GA	D41058P	55		AE0402	22	115-199

SPARE WIRE LIST

D280N032

91-21-12

Section M10398

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10401		W2078	S*	PANEL-SQUIB TEST(SEE YQM++++)								
D03734	CAP	Y	0356	20	GA	D41850P	54		AP0036	14	ALL	
D03734	CAP	Y	0370	20	GA	D41414P	37		AP0033	26	115-199	
D03734	CAP	Y	0371	20	GA	D41414P	38		AP0033	26	ALL	
D03734	CAP	Y	0372	20	GA	D41414P	39		AP0033	26	ALL	
D03734	CAP	Y	0392	20	GA	D40570P	35		AP0037	06	ALL	
D03734	CAP	Y	0393	20	GA	D40570P	36		AP0037	06	ALL	
D03734	CAP	Y	0394	20	GA	D40570P	37		AP0037	06	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section M10401

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10654			W3572	L1	MODULE-LAV S. MID FWD L(SEE YRT++++)							
D05690	12			0089	20	GA	D41120J	CAP	Y	AA0409	01	001-099
D05690	25			0092	20	GA	D40496P	13		AP0037	15	001-099
D05690	9			0175	20	GA	D05896	7		D05928		001-008
D05690	9			0175	20	GA	D41498P	7		D41498J		009-099
D05690	10			0176	20	GA	D05896	1		D05928		001-008
D05690	10			0176	20	GA	D41498P	1		D41498J		009-099

SPARE WIRE LIST

D280N032

91-21-12

Section M10654

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M10680		W3672	R1									
D07156	2		0247	22	GA	SP00544		9			001-099	
D07156	3		0248	22	GA	SP00546		9			001-099	
D07156	4		0249	20	GA	GD01451	DC..	E			001-099	
D07156	6		0250	20	GA	SP01908		9			001-099	
D07156	8		0251	20	GA	GD03264	DC..	E			001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section M10680

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
M10919			W3632	R2	POWER SUPPLY-EMERGENCY LIGHTS							
D06910		11	16	0711	16	GA	D06916	1	VY	L823		001-006
D06910		12	16	0712	16	GA	D06920	1	VY	L824		001-006
D06910		13	16	0713	16	GA	D06854	1	VY	L00809		001-006

SPARE WIRE LIST

D280N032

91-21-12

Section M10919

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
M11030		W3632	R2	POWER SUPPLY-EMERGENCY LIGHTS								
D07994	11	16	0711	16	GA	D06916	1	VY	L823		007-099	
D07994	12	16	0712	16	GA	D06920	1	VY	L824		007-099	
D07994	13	16	0713	16	GA	D06854	1	VY	L00809		007-099	

SPARE WIRE LIST

D280N032

91-21-12

Section M11030

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
N10013			W2311	N2	IND-EICAS UPPER DISPLAY UNIT							
D00325		CAP	Y	2509T	24	BV	D41069P	25		AE0402	05	001-099
D00325		CAP	Y	2509W	24	BV	D41069P	26		AE0402	05	001-099
D00325		DED		2509Z			D41069P	27		AE0402	05	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section N10013

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
N10014		W2313	N2	IND-EICAS LOWER DISPLAY UNIT								
D00327	CAP	Y	2509T	24	BV	D41071P	25		AE0402	37	001-099	
D00327	CAP	Y	2509W	24	BV	D41071P	26		AE0402	37	001-099	
D00327	DED		2509Z			D41071P	27		AE0402	37	001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section N10014

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
SPEAKER			W3802	N1								
D01241	3			0845	22	GA	D40410P	5		AP0037	26	001-099
SPEAKER			W3806	N1								
D01245	3			0816	22	GA	D40414P	19		D40414J		ALL

SPARE WIRE LIST

D280N032

91-21-12

Section SPEAKER

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
TB0190		W1115	S*	TERMINAL BLOCK TRACK- 14 POS.									
TB0190X	A001	BJ	0440		22	GA	D40503J	24		AP0010	03	001, 003-099	
TB0190X	A001	BJ	0440		22	GA	D40503J	24		AP0010	03	002	
TB0190X	D002	BJ	2002B		22	GB	D40503J	20		AP0010	03	001, 003-099	
TB0190X	D002	BJ	2002B		22	GB	D40503J	20		AP0010	03	002	
TB0190X	C002	BJ	2002R		22	GB	D40503J	19		AP0010	03	001, 003-099	
TB0190X	C002	BJ	2002R		22	GB	D40503J	19		AP0010	03	002	

SPARE WIRE LIST

D280N032

91-21-12

Section TB0190

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
TB0192			W1115	S*	TERMINAL BLOCK TRACK- 10 POS.							
TB0192Y		A002	BJ	0438	22	GA	D40503J	11		AP0010	03	001, 003-099
TB0192Y		A002	BJ	0438	22	GA	D40503J	11		AP0010	03	002
TB0192Y		A001	BJ	0439	22	GA	D40503J	10		AP0010	03	001, 003-099
TB0192Y		A001	BJ	0439	22	GA	D40503J	10		AP0010	03	002

SPARE WIRE LIST

D280N032

91-21-12

Section TB0192

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
TB0203		W1173	R2									
TB0203Z	105	BJ	5078B	24	G2	D41881J	16		AE0202	11	115-199	
TB0203Z	106	BJ	5078R	24	G2	D41881J	17		AE0202	11	115-199	
TB0203Z	105	BJ	5125B	24	G2	D41881J	34		AE0202	11	115-199	
TB0203Z	106	BJ	5125R	24	G2	D41881J	33		AE0202	11	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section TB0203

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
TB0207		W1275	N2	TERMINAL BLOCK TRACK- 124 POS.								
TB0207Y	C100	BJ	6494	24	GK	D41867J	51		AE0402	01	115-199	
TB0207Y	C083	BJ	6495	24	GK	D41879J	54		AE0402	38	115-199	

SPARE WIRE LIST

D280N032

91-21-12

Section TB0207

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip	Term	Type	Wire No.		GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
TS5082			W2447	R*	XDCR UNITS-F/O WHL CMD							
D00631		11		2013B	22	GB	D41771P	29		AE0401	11	001-099
D00631		12		2013R	22	GB	D41771P	30		AE0401	11	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section TS5082

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From	Matewith	Pos	Bundle	Sep	Description		To					
Equip		Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity
W3054			W3050	S2								
TB0025K		G006	1	0007	20	HL	D40162P	22		AC0393	02	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section W3054

Page 1 End

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description			To					
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith		Pos	Effectivity
UNK		W0002	N2									
S10172	7	1A	0115	24	GK	D40836J	33		AP0301		04	115-199
UNK		W0003	R*									
GD01248	DC..	2	0223	20	GA	D42174P	7		AP0301		02	001-099
UNK		W0010	S2									
D40850J	45		0030	22	GA	S00507	5	1A				ALL
D40850J	46		0031	22	GA	S00507	6	1A				ALL
S00507	5	1A	0030	22	GA	D40850J	45					ALL
S00507	6	1A	0031	22	GA	D40850J	46					ALL
UNK		W0012	S2									
D40854J	45		0030	22	GA	S00508	5	1A				ALL
D40854J	46		0031	22	GA	S00508	6	1A				ALL
S00508	5	1A	0030	22	GA	D40854J	45					ALL
S00508	6	1A	0031	22	GA	D40854J	46					ALL
UNK		W0530	N2									
D42052P	5		0005	22	GK	D04628	5		D04616			001-099
D42052P	10		0010	22	GK	D04628	10		D04616			115-199
UNK		W1032	S2									
D01796B	CAP	Y	0336	22	GA	D41676J	9		AE0604		28	115-199
UNK		W1163	L2									
TB0141Z	4	BJ	0418	24	GK	D41371J	17		AE0403		14	115-199
UNK		W1173	R2									
GD01914	ST..	2	5078Z			D41881J	18		AE0202		11	001-099
GD01916	ST..	2	5078Z			D41881J	18		AE0202		11	115-199
GD01916	ST..	2	5125Z			D41881J	32		AE0202		11	115-199
TB0203Z	105	BJ	5078B	24	G2	D41881J	16		AE0202		11	001-099
TB0203Z	106	BJ	5078R	24	G2	D41881J	17		AE0202		11	001-099
UNK		W1175	C2									
D00085A	B09		0008	24	GK	D41567J	35		AE0203		13	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section UNK

Page 1

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
UNK		W1175	C2	(continued)						
GD02112	ST..	2	0260	20 GA	D41433J			AE0203	03	115-199
UNK		W1230	R*							
TB0046Y	C006	BJ	0084	20 GA	D42006J	14		AP0033	16	115-199
TB0046Y	C005	BJ	0085	20 GA	D41718J	1		AP0033	29	115-199
TB0046Y	C005	BJ	0086	22 GA	D41718J	2		AP0033	29	115-199
TB0046Y	C005	BJ	0151	22 GA	D41718J	CAP	Y	AP0033	29	115-199
UNK		W1260	L*							
GD01674	DC..	2	5645	24 GK	D00582	5		K00124		115-199
GD01674	DC..	2	5647	24 GK	D02768	2		K00419		115-199
GD01684	DC..	2	0397	22 GK	D02158	7		K10126		115-199
UNK		W1275	N2							
D00319D	C15		6126	24 GK	D41317J	45		AE0402	07	001-099
D00321D	C15		6127	24 GK	D41317J	45		AE0402	07	001-099
UNK		W1433	N2							
GD01947	ST..	2	0160	20 GA	D41361J			AE0303	36	115-199
UNK		W2010	C1							
TB5006	CAP	Y	0004	18 GA	D40298P	4		AP0006	02	ALL
TB5006	CAP	Y	0005	16 GA	D40298P	5		AP0006	02	ALL
UNK		W2028	S2							
D41250J	13		0017R	20 QA	D40316J	2		AT1883	02	001-002
D41250J	14		0018R	20 QA	D40316J	1		AT1883	02	001-099
UNK		W2048	S2							
D41254J	3		0003R	20 QA	D40318J	2		AT1883	04	001-002
D41254J	4		0004R	20 QA	D40318J	5		AT1883	04	001-099
UNK		W2066	L*							
TB0112X	B015	BJ	0579	22 GA	D41864P	35		AE0501	22	001-099
TB0112X	A015	BJ	0580	22 GA	D41864P	36		AE0501	22	001-099

SPARE WIRE LIST

D280N032

91-21-12

Section UNK

Page 2

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From Equip	Pos Term	Bundle Type	Sep Wire No.	Description GA TY	To Equip	Term	Type	Matewith	Pos	Effectivity
UNK		W2070	R*							
GD00617	DC..	2	0092	20 GA	D03710	6		M10191		115-199
UNK		W2152	L1							
SP01104	CAP	Y	0022	18 GA	D40388J	N		AC0393	03	115-199
SP01108	CAP	Y	0023	18 GA	D40388J	O		AC0393	03	115-199
UNK		W2156	S*							
TB0058Y	CAP	Y	0176	22 GA	D40808J	30		AP0005	34	115-199
TB0115X	C016	BJ	0151	22 GA	D40808J	13		AP0005	34	115-199
TB0115X	C015	BJ	0152	22 GA	D40808J	14		AP0005	34	115-199
UNK		W2331	N2							
GD01100	ST..	E	5004Z		D41081P	14		AE0201	25	115-199
UNK		W2353	L2							
D41101J	11		0008	22 GA	D41741P	11		AE0302	38	ALL
D41101J	12		0009	22 GA	D41741P	12		AE0302	38	ALL
D41101J	13		0010	22 GA	D41741P	13		AE0302	38	ALL
UNK		W2626	S2							
D41250P	14		0014R	22 QA	D40218P	14		AP0054	04	001-099
UNK		W2628	S2							
D41254P	4		0058R	20 QA	D40220P	5		AP0054	10	001-099
UNK		W2663	L2							
D41733P	9		0009	20 GA	D42033P	9		AE0403	09	001-099
D41733P	9		0009	20 GA	D41799P	9		AE0603	11	115-199
D41733P	10		0010	20 GA	D42033P	10		AE0403	09	001-099
D41733P	10		0010	20 GA	D41799P	10		AE0603	11	115-199
UNK		W2665	R2							
D41735P	9		0009	20 GA	D41813P	9		AE0603		115-199
D41735P	10		0010	20 GA	D41813P	10		AE0603		115-199

SPARE WIRE LIST

D280N032

91-21-12

Section UNK

Page 3

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To						
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith	Pos	Effectivity	
UNK		W2822	N2									
S00428	3	C	0002	20	HA	D40104P	6		AT1883	01	115-199	
UNK		W3050	S2									
TB0225K	A003	1	0008	20	HL	D40162P	8		AC0393	02	001-099	
UNK		W3052	L1									
S10361	CAP	Y	0030	18	HL	D40388P	O		AC0393	03	115-199	
S10361	CAP	Y	0031	18	HL	D40388P	N		AC0393	03	115-199	
UNK		W3133	L2									
D41733J	9		0013	20	GA	D00307	CAP	Y	M00241		001-099	
D41733J	10		0014	20	GA	D00307	CAP	Y	M00241		001-099	
D41733J	11		0015	20	GA	D00307	CAP	Y	M00241		001-099	
UNK		W3135	R2									
D41735J	9		0013	20	GA	D00309	CAP	Y	M00242		115-199	
D41735J	10		0014	20	GA	D00309	CAP	Y	M00242		115-199	
D41735J	11		0015	20	GA	D00309	CAP	Y	M00242		115-199	
UNK		W3426	N2									
GD00433	ST..	E	2512Z			D40328J	S/R		AW2333	03	ALL	
GD00443	ST..	E	2501Z			D40330J	S/R		AW2333	01	ALL	
GD00443	ST..	E	2502Z			D40330J	S/R		AW2333	01	ALL	
GD00443	ST..	E	2503Z			D40330J	S/R		AW2333	01	ALL	
GD00443	ST..	E	2504Z			D40330J	S/R		AW2333	01	ALL	
GD02609	ST..	E	1011Z			D40330J	S/R		AW2333	01	115-199	
GD02609	ST..	E	1015Z			D40330J	S/R		AW2333	01	115-199	
GD02609	ST..	E	2507Z			D40330J	S/R		AW2333	01	115-199	
GD02609	ST..	E	2516Z			D40330J	S/R		AW2333	01	115-199	
GD02609	ST..	E	2519Z			D40330J	S/R		AW2333	01	115-199	
UNK		W3572	L1									
SP01266		9	0177	24	GK	D40496P	18		AP0037	15	001-099	
UNK		W3576	R1									
GD03408	ST..	E	0030	20	GA	D40882J	31		D40882P		001-099	

SPARE WIRE LIST

D280N032

91-21-12

Section UNK

Page 4

Oct 09/2008



757-200 WIRING DIAGRAM MANUAL

From Matewith From	Pos	Bundle	Sep	Description		To					Pos	Effectivity
Equip	Term	Type	Wire No.	GA	TY	Equip	Term	Type	Matewith			
UNK		W3632	R2									
GD03936	DC..	E	0753	20	GA	D06856	1	VG	L00809			001-099
GD04014	DC..	E	0751	20	GA	D06918	1	VG	L823			001-099
GD04014	DC..	E	0752	20	GA	D06922	1	VG	L824			001-099
UNK		W3672	R1									
GD01451	DC..	E	0249	20	GA	D07156	4		M10680			001-099
GD03264	DC..	E	0251	20	GA	D07156	8		M10680			001-099
SP00544		9	0247	22	GA	D07156	2		M10680			001-099
SP00546		9	0248	22	GA	D07156	3		M10680			001-099
SP01266		9	0182	24	GK	D00048	24		M10015			001-099
SP01908		9	0250	20	GA	D07156	6		M10680			001-099
UNK		W3802	N1									
D01241	3		0845	22	GA	D40410P	5		AP0037	26		115-199
UNK		W4206	R2A									
GD03073	ST..	E	YAAC			D41394J	S/R		AC0880	12		001-099
UNK		W4210	S2									
TB0116Y	C006	BJ	0135	22	GA	D41958P	53		AP0036	13		001-099
UNK		W4218	R2A									
D41180J	9		0045	22	GA	D41828P	10		AE0503	10		115-199

SPARE WIRE LIST

D280N032

91-21-12

Section UNK

Page 5 End

Oct 09/2008