



767 MAINTENANCE PLANNING DATA

APPENDIX A. COMPONENT CHANGE ITEMS

A. COMPONENT CHANGE ITEMS.....	A.0-3
B. COMPONENT CHANGE ITEM INFORMATION	A.1-1



767 MAINTENANCE PLANNING DATA

THIS PAGE INTENTIONALLY LEFT BLANK



767 MAINTENANCE PLANNING DATA

A. COMPONENT CHANGE ITEMS

This section lists selected items for which Component Change Task Cards have been created. This list of items (starting on A.1-1) represents candidate components that can be tracked as part of an operator's reliability program. This list is not all inclusive and is only intended as a starting point to assist the operator in developing a component reliability tracking program.

These items were extracted from the 767 Component Removal Report, which contains component reliability information based on the consolidated component reliability monitoring programs of three major U.S. operators. Items included are those with less than 10,000 flight hours mean time between unscheduled removals (MTBUR). Excluded from this list are low value items (switches, sensors, relays, circuit breakers, etc.), units for which a discard/replace task exists in the MPD, and units which require only simple procedures (e.g. black box replacement) and require little or no testing (e.g. Built-In-Test-Equipment, BITE).



767 MAINTENANCE PLANNING DATA

THIS PAGE INTENTIONALLY LEFT BLANK



767 MAINTENANCE PLANNING DATA

B. COMPONENT CHANGE ITEM INFORMATION

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
21-25-01-4A	21-R01	125 126	NOTE 1251 821	PASS	ALL	00.7	REPLACE THE RECIRCULATION AIR FAN. ACCESS NOTE: SPECIAL ACCESS 1251 REQUIRES REMOVAL OF FORWARD CARGO COMPARTMENT AFT WALL PANELS. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.
21-31-03-2C	21-R02	165	NOTE 1651 811	ALL	ALL	01.2	REPLACE THE CABIN PRESSURE OUTFLOW VALVE. ACCESS NOTE: SPECIAL ACCESS 1651 REQUIRES REMOVAL OF BULK CARGO COMPARTMENT AFT WALL PANELS. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.
21-31-05-4A	21-R03	165	NOTE 1651 811 822	NOTE	ALL	00.4	REPLACE THE OUTFLOW VALVE ACTUATOR AC MOTOR. AIRPLANE NOTE: APPLICABLE TO 767-200/300 AIRPLANES. ACCESS NOTE: SPECIAL ACCESS 1651 REQUIRES REMOVAL OF BULK CARGO COMPARTMENT AFT WALL PANELS. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
21-58-18-2B	21-R04	122	NOTE 1221 821	NOTE	ALL	01.3	<p>REPLACE THE AVIONICS COOLING REFRIGERATION UNIT.</p> <p>AIRPLANE NOTE: AIRPLANES WITH ACUR.</p> <p>ACCESS NOTE: SPECIAL ACCESS 1221 REQUIRES REMOVAL OF THE FORWARD CARGO COMPARTMENT RIGHT SIDEWALL PANELS.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES.</p>
21-61-07-4A	21-R05	135	193FL	PASS	ALL	00.5	<p>REPLACE THE TRIM AIR MODULATING VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
22-33-01-4A	22-R01	410 420	416ER 426ER	NOTE	ALL	01.0	<p>REPLACE THE POWER LEVER ANGLE TRANSDUCER.</p> <p>AIRPLANE NOTE: AIRPLANES WITHOUT FULL AUTHORITY ELECTRONIC PROPULSION CONTROL SYSTEMS.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
24-11-01-4A	24-R01	411 421		NOTE	ALL	03.3	<p>REPLACE THE INTEGRATED DRIVE GENERATOR.</p> <p>AIRPLANE NOTE: THIS TASK IS APPLICABLE TO ALL AIRPLANE MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
26-11-02-4A	26-R01	410 420	413AL 414AR 415AL 416AR 417AL 418AR 423AL 424AR 425AL 426AR 427AL 428AR	ALL	NOTE	01.2	<p>REPLACE THE ENGINE FIRE AND OVERHEAT DETECTOR ELEMENT.</p> <p>ENGINE NOTE: THIS TASK IS APPLICABLE TO THE 4000, 7R4, 80A AND 80C ENGINES.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
27-51-01-4A	27-R01	119	119AL	ALL	ALL	01.2	<p>REPLACE THE FLAP/SLAT ELECTRONICS UNIT.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
28-21-12-4A	28-R01	500 600	1004 551TB 561FB 651TB 661FB	ALL	ALL	00.8	<p>REPLACE THE FUELING SHUTOFF VALVE CONTROL UNIT.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
29-11-03-4A	29-R01	195	NOTE 1004 195RL 195SL	NOTE	ALL	02.4	<p>REPLACE THE SYSTEM C AIR DRIVEN PUMP.</p> <p>AIRPLANE NOTE: THIS TASK IS APPLICABLE TO ALL AIRPLANE MODELS EXCEPT THE 767-400ER.</p> <p>ACCESS NOTE: SPECIAL ACCESS 1004 REQUIRES ACCESSING THE LANDING GEAR THROUGH THE WHEEL WELL DOORS PER MM REF 32-00-15.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
29-11-05-4A	29-R02	410 420	414AR 416AR 418AR 424AR 426AR 428AR	ALL	ALL	00.8	<p>REPLACE THE ENGINE-DRIVEN HYDRAULIC PUMP (EDP).</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
29-11-30-4A	29-R03	195	195TL	NOTE	ALL	00.5	<p>REPLACE THE ADP PRESSURE REGULATOR AND SHUTOFF VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p> <p>AIRPLANE NOTE: THIS TASK IS APPLICABLE TO ALL AIRPLANE MODELS EXCEPT THE 767-400ER.</p>
31-41-02-4B	31-R01	119	119AL	NOTE	ALL	01.0	<p>REPLACE THE EICAS COMPUTER.</p> <p>AIRPLANE NOTE: THIS TASK IS APPLICABLE TO ALL AIRPLANE MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
32-32-13-4A	32-R01	143 144	NOTE 1004	ALL	ALL	00.5	<p>REPLACE THE MAIN LANDING GEAR DOOR LATCH ACTUATOR.</p> <p>ACCESS NOTE: SPECIAL ACCESS 1004 REQUIRES OPENING OF THE LANDING GEAR WHEEL WELL DOORS AND INSTALLING SAFETY LOCKS IN ACCORDANCE WITH MAINTENANCE MANUAL PROCEDURE 32-00-15.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
32-32-18-4A	32-R02	731 741	NOTE 1004	NOTE	ALL	01.0	<p>REPLACE THE MAIN LANDING GEAR TRUCK POSITIONER.</p> <p>ACCESS NOTE: SPECIAL ACCESS 1004 REQUIRES OPENING OF THE LANDING GEAR WHEEL WELL DOORS AND INSTALLING SAFETY LOCKS IN ACCORDANCE WITH MAINTENANCE MANUAL PROCEDURE 32-00-15.</p> <p>AIRPLANE NOTE: THIS TASK IS APPLICABLE TO ALL AIRPLANE MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
32-41-08-4A	32-R03	731 741	NOTE 1004	NOTE	ALL	02.1	<p>REPLACE THE MAIN LANDING GEAR WHEEL BRAKES.</p> <p>AIRPLANE NOTE: APPLICABLE TO AIRPLANES WITH STEEL BRAKES.</p> <p>ACCESS NOTE: SPECIAL ACCESS 1004 REQUIRES OPENING OF THE LANDING GEAR WHEEL WELL DOORS AND INSTALLING SAFETY LOCKS IN ACCORDANCE WITH MAINTENANCE MANUAL PROCEDURE 32-00-15.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
32-42-01-4A	32-R04	119	119AL	ALL	ALL	01.5	<p>REPLACE THE ANTISKID/AUTOBRAKE CONTROL UNIT.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
32-45-01-4A	32-R05	731 741	NOTE 1004	NOTE	ALL	01.2	<p>REPLACE THE MAIN GEAR WHEEL AND TIRE.</p> <p>ACCESS NOTE: SPECIAL ACCESS 1004 REQUIRES OPENING OF THE LANDING GEAR WHEEL WELL DOORS AND INSTALLING SAFETY LOCKS IN ACCORDANCE WITH MAINTENANCE MANUAL PROCEDURE 32-00-15.</p> <p>AIRPLANE NOTE: THIS TASK IS APPLICABLE TO ALL AIRPLANE MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
32-45-02-4A	32-R06	711	NOTE 1004	ALL	ALL	01.4	<p>REPLACE THE NOSE GEAR WHEEL AND TIRE.</p> <p>ACCESS NOTE: SPECIAL ACCESS 1004 REQUIRES OPENING OF THE LANDING GEAR WHEEL WELL DOORS AND INSTALLING SAFETY LOCKS IN ACCORDANCE WITH MAINTENANCE MANUAL PROCEDURE 32-00-15.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
34-53-01-4A	34-R02	119	119AL	ALL	ALL	00.4	<p>REPLACE THE ATC TRANSPONDER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
36-11-07-4A	36-R01	410 420	415AL 425AL	ALL	ALL	01.2	<p>REPLACE THE HIGH PRESSURE SHUTOFF VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
36-11-08-4A	36-R02	411 421	415AL 417AL 425AL 427AL	ALL	ALL	00.5	<p>REPLACE THE HIGH PRESSURE CONTROLLER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
36-11-09-2A	36-R03	434 444	434AL 444AL	ALL	ALL	02.2	<p>REPLACE THE AIR SUPPLY PRESSURE REGULATING AND SHUTOFF VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
38-32-01-4A	38-R01	200		PASS	ALL	01.5	<p>REPLACE THE TOILET ASSEMBLY.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
49-11-01-4A	49-R01	315 316	315AL 316AR	NOTE	ALL	02.6	<p>REPLACE THE AUXILIARY POWER UNIT (APU).</p> <p>AIRPLANE NOTE: APPLICABLE TO ALL MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
49-15-06-4A	49-R02	314	312AR	NOTE	ALL	01.3	<p>REPLACE THE APU AIR INTAKE DOOR ACTUATOR.</p> <p>AIRPLANE NOTE: APPLICABLE TO ALL MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
49-31-01-4A	49-R03	315 316	315AL 316AR	NOTE	ALL	00.4	<p>REPLACE THE APU FUEL CONTROL UNIT.</p> <p>AIRPLANE NOTE: APPLICABLE TO ALL MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
49-41-01-4A	49-R04	315 316	315AL 316AR	NOTE	ALL	00.9	<p>REPLACE THE APU STARTER.</p> <p>AIRPLANE NOTE: APPLICABLE TO ALL MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
49-41-03-4A	49-R05	315 316	315AL 316AR	NOTE	ALL	00.9	<p>REPLACE THE APU IGNITION UNIT.</p> <p>AIRPLANE NOTE: APPLICABLE TO ALL MODELS EXCEPT THE 767-ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
49-52-02-4A	49-R06	315 316	315AL 316AR	NOTE	ALL	01.2	<p>REPLACE THE APU INLET GUIDE VANE ACTUATOR.</p> <p>AIRPLANE NOTE: APPLICABLE TO ALL MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
49-53-01-4A	49-R07	315 316	315AL 316AR	NOTE	ALL	01.0	<p>REPLACE THE APU SURGE VALVE.</p> <p>AIRPLANE NOTE: APPLICABLE TO ALL MODELS EXCEPT THE 767-400ER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
D71-00-02-4A	71-R02	410 420	411ER 413 414 421ER 423 424	ALL	524	15.9	<p>REPLACE THE POWER PLANT.</p> <p>NOTE: TASK CARDS 24-003-02 AND 36-005-02 TO BE ACCOMPLISHED AT ENGINE CHANGE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D73-21-06-4A	73-R10	411 421	413 423	ALL	524	01.8	<p>REPLACE THE FUEL METERING UNIT (FMU).</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D73-21-09-4A	73-R08	411 421	413 423	ALL	524	01.3	<p>REPLACE THE FULL AUTHORITY FUEL CONTROLLER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D73-21-11-4A	73-R09	113	113AL	ALL	524	00.8	<p>REPLACE THE THRUST LEVER ANGLE (TLA) RESOLVER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D73-31-01-4A	73-R07	411 421	413 423	ALL	524	01.0	<p>REPLACE THE FUEL FLOW TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D74-11-01-4A	74-R07	411 421	413 423	ALL	524	00.8	<p>REPLACE THE HIGH ENERGY IGNITION UNIT.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
D75-33-06-4A	75-R04	411 421	411KL 421KL	ALL	524	01.1	<p>REPLACE THE INTERMEDIATE PRESSURE COMPRESSOR BLEED VALVE CONTROL UNIT.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D76-11-09-4A	76-R03	113 114 211 212	113AL	ALL	524	02.0	<p>REPLACE THE ENGINE FUEL CONTROL MODULE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D77-12-02-4A	77-R05	120	119AL	ALL	524	00.5	<p>REPLACE THE ENGINE SPEED CARD.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D77-12-03-4A	77-R04	411 421	413 423	ALL	524	00.7	<p>REPLACE THE HP TACHOMETER GENERATOR.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D79-31-01-4A	79-R05	411 421	413 423	ALL	524	00.8	<p>REPLACE THE OIL QUANTITY TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
D79-32-01-4A	79-R06	411 421	413 423	ALL	524	00.6	<p>REPLACE THE OIL PRESSURE TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
D80-11-01-4A	80-R05	411 421	413 414 423 424	ALL	524	01.1	REPLACE THE PNEUMATIC STARTER. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.
D80-11-04-4A	80-R06	411 421	414 424	ALL	524	00.8	REPLACE THE START VALVE. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.
G71-00-02-4A	71-R04	410 420 430 440	413AL 414AR 415AL 416AR 417AL 418AR 423AL 424AR 425AL 426AR 427AL 428AR 431AL 441AR	ALL	80A	15.6	REPLACE THE POWER PLANT. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.
G73-21-07-4A	73-R11	411 421	413AL 423AL	ALL	80A	01.1	REPLACE THE ELECTRONIC ENGINE CONTROL (POWER MANAGEMENT CONTROL). THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.
G73-31-01-4A	73-R12	411 421	414AR 416AR 418AR 424AR 426AR 428AR	ALL	80A	01.3	REPLACE THE FUEL FLOW TRANSMITTER. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
G74-11-01-2A	74-R10	411 421	413AL 423AL	ALL	80A	00.8	<p>REPLACE THE IGNITION EXCITER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
G74-21-02-4A	74-R13	411 421	414AR 416AR 418AR 424AR 426AR 428AR	ALL	80A	00.7	<p>REPLACE THE IGNITER PLUG.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
G77-12-01-4A	77-R09	411 421	414AR 416AR 418AR 424AR 426AR 428AR	ALL	80A	00.6	<p>REPLACE THE N1 FAN TACHOMETER TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
G77-31-03-4A	77-R06	119	119AL	ALL	80A	00.3	<p>REPLACE THE AIRBORNE VIBRATION MONITOR SIGNAL CONDITIONER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
G79-31-01-4A	79-R07	411 421	414AR 424AR	ALL	80A	00.8	<p>REPLACE THE OIL QUANTITY TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
G79-32-01-4A	79-R08	411 421	413AL 415AL 417AL 423AL 425AL 427AL	ALL	80A	00.8	<p>REPLACE THE OIL PRESSURE TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
G79-33-01-4A	79-R09	411 421	413AL 415AL 417AL 423AL 425AL 427AL	ALL	80A	00.6	<p>REPLACE THE LOW OIL PRESSURE WARNING SWITCH.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
G80-11-01-4A	80-R07	411 421	413AL 414AR 415AL 416AR 417AL 418AR 423AL 424AR 425AL 426AR 427AL 428AR	ALL	80A	00.9	<p>REPLACE THE PNEUMATIC STARTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
G80-11-02-4A	80-R08	411 421	413AL 414AR 415AL 416AR 417AL 418AR 423AL 424AR 425AL 426AR 427AL 428AR	ALL	80A	00.6	<p>REPLACE THE STARTER VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
H71-00-02-4A	71-R08	410 420 430 440	413AL 414AR 415AL 416AR 417AL 418AR 423AL 424AR 425AL 426AR 427AL 428AR 431AL 441AR	NOTE	80C	15.6	<p>REPLACE THE POWERPLANT.</p> <p>AIRPLANE NOTE: AIRPLANE WITHOUT FULL AUTHORITY ELECTRONIC PROPULSION CONTROL SYSTEM.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H73-21-07-4A	73-R13	411 421	413AL 423AL	NOTE	80C	00.5	<p>REPLACE THE ELECTRONIC ENGINE CONTROL (POWER MANAGEMENT CONTROL).</p> <p>AIRPLANE NOTE: AIRPLANES WITHOUT FULL AUTHORITY ELECTRONIC PROPULSION CONTROL SYSTEM.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H73-31-01-4A	73-R14	411 421	414AR 416AR 424AR 426AR	ALL	80C	01.3	<p>REPLACE THE FUEL FLOW TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H74-11-01-4A	74-R14	411 421	413AL 423AL	ALL	80C	00.8	<p>REPLACE THE IGNITION EXCITER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
H74-21-02-4A	74-R17	411 421	414AR 416AR 424AR 426AR	ALL	80C	00.7	<p>REPLACE THE IGNITER PLUG.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H77-12-01-4A	77-R07	411 421	414AR 416AR 424AR 426AR	ALL	80C	00.5	<p>REPLACE THE N1 FAN SHAFT SPEED SENSOR.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H77-31-03-4A	77-R08	119	119AL	ALL	80C	00.3	<p>REPLACE THE AIRBORNE VIBRATION MONITOR SIGNAL CONDITIONER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H79-31-01-4A	79-R10	411 421	414AR 424AR	ALL	80C	00.8	<p>REPLACE THE OIL QUANTITY TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H79-32-01-4A	79-R11	411 421	413AL 415AL 423AL 425AL	ALL	80C	00.8	<p>REPLACE THE OIL PRESSURE TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H79-33-01-4A	79-R12	411 421	413AL 415AL 423AL 425AL	ALL	80C	00.7	<p>REPLACE THE LOW OIL PRESSURE WARNING SWITCH.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
H80-11-01-4A	80-R09	411 421	413AL 415AL 423AL 425AL	ALL	80C	00.9	<p>REPLACE THE PNEUMATIC STARTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
H80-11-02-4A	80-R10	411 421	413AL 414AR 415AL 416AR 423AL 424AR 425AL 426AR	ALL	80C	00.6	<p>REPLACE THE PNEUMATIC START VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N71-00-02-4A	71-R03	410 420	413AL 414AR 415AL 416AR 417AL 418AR 423AL 424AR 425AL 426AR 427AL 428AR	ALL	4000	08.9	<p>REMOVE THE POWER PLANT.</p> <p>NOTE: TASK CARDS 24-003-01 AND 36-005-01 TO BE ACCOMPLISHED AT ENGINE CHANGE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N71-00-02-4B	71-R09	410 420	413AL 414AR 415AL 416AR 417AL 418AR 423AL 424AR 425AL 426AR 427AL	ALL	4000	07.0	<p>REPLACE THE POWER PLANT.</p> <p>NOTE: TASK CARDS 24-003-01 AND 36-005-01 TO BE ACCOMPLISHED AT ENGINE CHANGE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
N73-21-04-4A	73-R03	410 420	414AR 424AR	ALL	4000	00.5	<p>REPLACE THE ELECTRONIC ENGINE CONTROL (EEC).</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N73-21-05-4A	73-R06	410 420	412AR 413AL 414AR 415AL 416AR 422AR 423AL 424AR 425AL 426AR	ALL	4000	00.5	<p>REPLACE THE N2 EEC ALTERNATOR.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N73-21-06-4A	73-R05	410 420	412AR 414AR 416AR 422AR 424AR 426AR	ALL	4000	00.5	<p>REPLACE THE N1 SPEED TRANSDUCER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N73-31-01-4A	73-R04	410 420	416AR 426AR	ALL	4000	00.9	<p>REPLACE THE FUEL FLOW TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N74-11-01-4A	74-R04	410 420	415AL 416AR 425AL 426AR	ALL	4000	00.7	<p>REPLACE THE IGNITION EXCITER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
N74-21-01-4A	74-R05	410 420	415AL 416AR 417AL 418AR 425AL 426AR 427AL 428AR	ALL	4000	00.7	<p>REPLACE THE EXCITER-TO-IGNITER PLUG CABLE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N74-21-02-4A	74-R06	410 420	417AL 418AR 427AL 428AR	ALL	4000	00.4	<p>REPLACE THE IGNITER PLUG.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N75-23-02-4A	75-R02	410	413AL 415AL	ALL	4000	00.8	<p>REPLACE THE ENGINE 1 NACELLE ZONE VENTILATION SHUTOFF VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N75-23-02-4B	75-R05	420	423AL 425AL	ALL	4000	00.8	<p>REPLACE THE ENGINE 2 NACELLE ZONE VENTILATION SHUTOFF VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N75-32-01-4A	75-R03	410 420	413AL 415AL 423AL 425AL	ALL	4000	00.7	<p>REPLACE THE INTERCOMPRESSOR (2.5) BLEED ACTUATOR.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N76-11-09-2A	76-R02	113 114 211 212	113AL	ALL	4000	02.0	<p>REPLACE THE ENGINE FUEL CONTROL MODULE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
N77-12-01-4A	77-R03	120	119AL	ALL	4000	00.5	<p>REPLACE THE ENGINE SPEED CARD.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N79-31-01-4A	79-R03	410 420	417AL 427AL	ALL	4000	00.7	<p>REPLACE THE OIL QUANTITY TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N79-32-01-4A	79-R04	410 420	414AR 416AR 424AR 426AR	ALL	4000	00.8	<p>REPLACE THE OIL PRESSURE TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N80-11-01-4A	80-R03	410 420	417AL 418AR 427AL 428AR	ALL	4000	00.7	<p>REPLACE THE PNEUMATIC STARTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
N80-11-02-4A	80-R04	410 420	418AR 428AR	ALL	4000	00.5	<p>REPLACE THE STARTER CONTROL VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
P71-00-02-4A	71-R01	410 420	413AL 414AR 415AL 416AR 417AL 418AR 423AL 424AR 425AL 426AR 427AL 428AR	ALL	7R4	15.9	<p>REPLACE THE POWER PLANT.</p> <p>NOTE: TASK CARDS 24-003-01 AND 36-005-01 TO BE ACCOMPLISHED AT ENGINE CHANGE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P73-21-07-4A	73-R01	410 420	414AR 424AR	ALL	7R4	00.5	<p>REPLACE THE ELECTRONIC ENGINE CONTROL (EEC).</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P73-31-01-4A	73-R02	410 420	416AR 426AR	ALL	7R4	00.9	<p>REPLACE THE FUEL FLOW TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P74-11-01-4A	74-R01	410 420	415AL 416AR 425AL 426AR	ALL	7R4	00.7	<p>REPLACE THE IGNITION EXCITER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P74-21-01-4A	74-R02	410 420	415AL 416AR 417AL 418AR 425AL 426AR 427AL 428AR	ALL	7R4	00.7	<p>REPLACE THE EXCITER-TO-IGNITER PLUG CABLE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
P74-21-02-4A	74-R03	410 420	417AL 418AR 427AL 428AR	ALL	7R4	00.4	<p>REPLACE THE IGNITER PLUG.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P75-23-02-4A	75-R01	410 420	413AL 415AL 423AL 425AL	ALL	7R4	00.8	<p>REPLACE THE NACELLE ZONE VENTILATION SHUTOFF VALVE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P76-11-06-4A	76-R01	410 420	414AR 416AR 424AR 426AR	ALL	7R4	02.0	<p>REPLACE THE ENGINE AREA PUSH-PULL CABLE.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P77-12-01-4A	77-R01	410 420	414AR 424AR	ALL	7R4	00.5	<p>REPLACE THE N1 TACHOMETER TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P77-12-02-4A	77-R02	410 420	413AL 415AL 423AL 425AL	ALL	7R4	00.5	<p>REPLACE THE N2 TACHOMETER TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>
P79-31-01-4A	79-R01	410 420	417AL 427AL	ALL	7R4	00.7	<p>REPLACE OIL QUANTITY TRANSMITTER.</p> <p>THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.</p>

D622T001



767 MAINTENANCE PLANNING DATA

MPD/MM REFERENCE	CARD NUMBER	ZONE	ACCESS	APPLICABILITY		LABOR HOURS	767 COMPONENT CHANGE ITEMS
				APL	ENG		TASK DESCRIPTION
P79-32-01-4A	79-R02	410 420	414AR 416AR 424AR 426AR	ALL	7R4	00.8	REPLACE THE OIL PRESSURE TRANSMITTER. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.
P80-11-01-4A	80-R01	410 420	417AL 418AR 427AL 428AR	ALL	7R4	00.7	REPLACE THE PNEUMATIC STARTER. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.
P80-11-02-2A	80-R02	410 420	418AR 428AR	ALL	7R4	00.5	REPLACE THE STARTER CONTROL VALVE. THIS CARD IS NOT A SCHEDULED MAINTENANCE TASK. IT IS A COMPONENT CHANGE CARD AND IT IS PROVIDED FOR OPERATOR CONVENIENCE DURING UNSCHEDULED MAINTENANCE ACTIVITIES. SEE APPENDIX A OF THE 767 MAINTENANCE PLANNING DATA (MPD) DOCUMENT, D622T001, FOR A DESCRIPTION OF THE COMPONENT CHANGE CARDS.

D622T001