



767 MAINTENANCE PLANNING DATA

APPENDIX E. MPD/MRB/TASK CARD CROSS-REFERENCE INDEXES

A. SCOPE	E.0-2
B. NOTES	E.0-2
C. APPLICABILITY	E.0-2
D. PAGE FORMAT	E.0-3
E. TASKS SORTED BY MPD ITEM NUMBER	E.1-1
F. TASKS SORTED BY MRB ITEM NUMBER	E.2-1
G. TASKS SORTED BY TASK CARD ITEM NUMBER	E.3-1



767 MAINTENANCE PLANNING DATA

A. SCOPE

This appendix to the MPD includes cross-reference indexes to the MRB, MPD, and Task Card Numbers. These indexes are sorted by MRB Item No., MPD Item No., and Task Card No. These cross-reference indexes provide an easy method of locating a task in any one of these three documents (MPD/MRB/Task Cards).

B. NOTES

This appendix is arranged into three sections. The first section is sorted by MPD Item No., the second section by MRB Item No. and the last section by Task Card No.

C. APPLICABILITY

The listings of MPD and MRB Item Numbers and Task Card Numbers in this document include all items for the entire 767 fleet (i.e., it is not configured to a specific operator's fleet); accordingly, certain MPD and MRB Item Numbers and Task Card Numbers do not apply to a specific operator's fleet. Since operators only receive task cards that apply to their fleet configuration, they will not receive all of the task cards listed in the cross-reference indexes. An operator should refer to the configured Task Card Indexes 1 through 5 issued with each task card revision to identify applicable MPD/MRB tasks.



767 MAINTENANCE PLANNING DATA

D. PAGE FORMAT

COLUMN	EXPLANATION												
MPD ITEM NUMBER	MPD Item Number for this task as listed in the Boeing 767 MPD. Tasks with more than one MPD item number list all applicable references in this column.												
MRB ITEM NUMBER	MRB Item Number for this task as listed in the 767 FAA MRB Report. Tasks with no MRB reference are non-MRB items.												
CARD NUMBER	Task Card Number for this task as listed in the set of Boeing 767 AC Task Cards provided to each customer. Some cards shown here may not be applicable to specific airplane/engine configurations; i.e., the cards listed apply to the entire 767 fleet of airplanes.												
RELATED TASK	Task Card Number of a related Task Card. A related Task Card Code is followed by the related Task Card Number.												
RELATED TASK CODE	<table><tr><th>RELATED TASK CODE</th><th>DESCRIPTION</th></tr><tr><td>A-</td><td>Perform AFTER related task.</td></tr><tr><td>B-</td><td>Perform BEFORE related task.</td></tr><tr><td>W-</td><td>Perform WITH related task.</td></tr><tr><td>P-</td><td>Task PRECLUDED by performing related task.</td></tr><tr><td>G-</td><td>Task is GROUPED with other systems tasks which are accomplished at the same time.</td></tr></table>	RELATED TASK CODE	DESCRIPTION	A-	Perform AFTER related task.	B-	Perform BEFORE related task.	W-	Perform WITH related task.	P-	Task PRECLUDED by performing related task.	G-	Task is GROUPED with other systems tasks which are accomplished at the same time.
RELATED TASK CODE	DESCRIPTION												
A-	Perform AFTER related task.												
B-	Perform BEFORE related task.												
W-	Perform WITH related task.												
P-	Task PRECLUDED by performing related task.												
G-	Task is GROUPED with other systems tasks which are accomplished at the same time.												
TASK	The type of task performed.												
TITLE	A short description of the item for which the task is performed.												



767 MAINTENANCE PLANNING DATA

THIS PAGE INTENTIONALLY LEFT BLANK



767 MAINTENANCE PLANNING DATA

E. TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-11-03-3A			G-28-007-01-1	DRAIN	LEFT WING TANK FUEL SUMPS
12-11-03-3A			G-28-007-01-2	DRAIN	RIGHT WING TANK FUEL SUMPS
12-11-03-3B			G-28-012-01-1	CHECK/INSP	LEFT FUEL TANKS MICROBIAL GROWTH
12-11-03-3B			G-28-012-01-2	CHECK/INSP	RIGHT FUEL TANKS MICROBIAL GROWTH
12-12-02-3A		78-120-01-1		SERVICE	THRUST REVERSER HYD COWL OPENING SYS
12-12-02-3A		78-120-01-2		SERVICE	THRUST REVERSER HYD COWL OPENING SYS
12-12-02-3A		78-219-01-1		SERVICE	THRUST REVERSER HYD COWL OPENING SYS
12-12-02-3A		78-219-01-2		SERVICE	THRUST REVERSER HYD COWL OPENING SYS
12-12-02-3A		78-420-01-1		SERVICE	T/R HYD COWL OPENING POWER UNIT
12-12-02-3A		78-420-01-2		SERVICE	T/R HYD COWL OPENING POWER UNIT
12-13-01-3A		79-111-01-1		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-111-01-2		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-111-02-1		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-111-02-2		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-209-01-1		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-209-01-2		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-209-02-1		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-209-02-2		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-309-01-1		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-309-01-2		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-309-02-1		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-309-02-2		SERVICE	ENGINE OIL LEVEL
12-13-01-3A		79-409-01-1		SERVICE	ENGINE 1 OIL LEVEL
12-13-01-3A		79-409-01-2		SERVICE	ENGINE 2 OIL LEVEL
12-13-01-3A		79-409-02-1		SERVICE	ENGINE 1 OIL LEVEL

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-13-01-3A		79-409-02-2		SERVICE	ENGINE 2 OIL LEVEL
12-13-01-3A		79-506-01-1		SERVICE	ENGINE 1 OIL LEVEL
12-13-01-3A		79-506-01-2		SERVICE	ENGINE 2 OIL LEVEL
12-13-02-3A		79-508-01-1		CHECK/INSP	ENGINE 1 STARTER OIL
12-13-02-3A		79-508-01-2		CHECK/INSP	ENGINE 2 STARTER OIL
12-13-02-3A		80-208-01-1		CHECK/INSP	ENGINE 1 STARTER OIL
12-13-02-3A		80-208-01-2		CHECK/INSP	ENGINE 2 STARTER OIL
12-13-02-3A		80-209-01-1		CHECK/INSP	ENGINE 1 STARTER OIL
12-13-02-3A		80-209-01-2		CHECK/INSP	ENGINE 2 STARTER OIL
12-13-02-3A	80-309	80-309-01-1		CHECK/INSP	ENGINE 1 STARTER OIL
12-13-02-3A	80-309	80-309-01-2		CHECK/INSP	ENGINE 2 STARTER OIL
12-13-02-3A		80-310-01-1		CHECK/INSP	ENGINE 1 STARTER OIL
12-13-02-3A		80-310-01-2		CHECK/INSP	ENGINE 2 STARTER OIL
12-13-02-3A		80-311-01-1		CHECK/INSP	ENGINE 1 STARTER OIL
12-13-02-3A		80-311-01-2		CHECK/INSP	ENGINE 2 STARTER OIL
12-13-02-3A		80-312-01-1		CHECK/INSP	ENGINE 1 STARTER OIL
12-13-02-3A		80-312-01-2		CHECK/INSP	ENGINE 2 STARTER OIL
12-13-02-3A	80-501	80-501-01-1		SERVICE	ENGINE 1 STARTER OIL
12-13-02-3A	80-501	80-501-01-2		SERVICE	ENGINE 2 STARTER OIL
12-13-03-3A	24-001	24-001-01-1		SERVICE	ENGINE 1 IDG OIL LEVEL
12-13-03-3A	24-001	24-001-01-2		SERVICE	ENGINE 2 IDG OIL LEVEL
12-13-03-3A	24-001	24-001-09-1		SERVICE	ENGINE 1 IDG OIL LEVEL
12-13-03-3A	24-001	24-001-09-2		SERVICE	ENGINE 2 IDG OIL LEVEL
12-13-03-3A		24-001-11-1		SERVICE	ENGINE 1 IDG OIL LEVEL
12-13-03-3A		24-001-11-2		SERVICE	ENGINE 2 IDG OIL LEVEL
12-13-03-3A		24-015-02-1		SERVICE	ENGINE 1 IDG OIL LEVEL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-2



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-13-03-3A		24-015-02-2		SERVICE	ENGINE 2 IDG OIL LEVEL
12-13-03-3A	24-015	24-015-03-1		SERVICE	ENGINE 1 IDG OIL LEVEL
12-13-03-3A	24-015	24-015-03-2		SERVICE	ENGINE 2 IDG OIL LEVEL
12-13-03-3B		24-017-01-1	W-24-016-01-1	REPLACE	ENGINE 1 IDG OIL CHANGE
12-13-03-3B		24-017-01-2	W-24-016-01-2	REPLACE	ENGINE 2 IDG OIL CHANGE
12-13-03-3B		24-017-03-1	W-24-016-02-1	REPLACE	ENGINE 1 IDG OIL CHANGE
12-13-03-3B		24-017-03-2	W-24-016-02-2	REPLACE	ENGINE 2 IDG OIL CHANGE
12-13-03-3B		24-017-06-1	W-24-016-03-1	SERVICE	ENGINE 1 IDG OIL CHANGE
12-13-03-3B		24-017-06-2	W-24-016-03-2	SERVICE	ENGINE 2 IDG OIL CHANGE
12-13-03-3B		24-017-07-1	W-24-016-C1-1	SERVICE	ENGINE 1 IDG OIL CHANGE
12-13-03-3B		24-017-07-2	W-24-016-C1-2	SERVICE	ENGINE 2 IDG OIL CHANGE
12-13-03-3B		24-017-08-1	W-24-016-C2-1	REPLACE	ENGINE 1 IDG OIL CHANGE
12-13-03-3B		24-017-08-2	W-24-016-C2-2	REPLACE	ENGINE 2 IDG OIL CHANGE
12-13-03-3C	24-001	24-001-02-1		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C	24-001	24-001-02-2		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C	24-001	24-001-10-1		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C	24-001	24-001-10-2		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C		24-016-10-1		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C		24-016-10-2		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C		24-016-11-1		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C		24-016-11-2		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C	24-016	24-016-12-1		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-03-3C	24-016	24-016-12-2		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
12-13-04-3A	49-021	49-021-01		SERVICE	APU OIL LEVEL
12-13-04-3A			G-49-021-02	SERVICE	APU OIL LEVEL
12-13-04-3A			G-49-021-03	SERVICE	APU OIL LEVEL

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-13-04-3A		49-021-04		SERVICE	APU OIL LEVEL
12-13-05-3A	29-005	29-005-01		CHECK/INSP	SYS C HYDRAULIC ADP OIL LEVEL
12-13-05-3B	29-026	29-026-01		CHECK/INSP	SYS C HYDRAULIC ADP OIL LEVEL
12-13-06-3A		27-053-01		SERVICE	STABILIZER TRIM BALL-SCREW ACTUATOR
12-13-07-3A		78-319-01-1		SERVICE	THRUST REVERSER HYD COWL OPENING SYS
12-13-07-3A		78-319-01-2		SERVICE	THRUST REVERSER HYD COWL OPENING SYS
12-13-08-3A		27-071-01		SERVICE	ALT TE FLAP POWER DRIVE MOTOR
12-15-01-3A		32-048-01-1		CHECK/INSP	MAIN GEAR SHOCK STRUT
12-15-01-3A		32-048-01-2		CHECK/INSP	MAIN GEAR SHOCK STRUT
12-15-01-3B	32-046	32-046-51-1		SERVICE	MAIN GEAR SHOCK STRUT
12-15-01-3B	32-046	32-046-51-2		SERVICE	MAIN GEAR SHOCK STRUT
12-15-02-3A		32-048-02		CHECK/INSP	NOSE GEAR SHOCK STRUT
12-15-03-3B	32-029	32-029-04	W-32-029-01	SERVICE	TIRE PRESSURE
12-15-03-3B		32-029-08	W-32-029-07	SERVICE	TIRE PRESSURE
12-15-04-3A	32-028	32-028-01		SERVICE	PARKING BRAKE ACCUMULATOR
12-15-04-3A		32-028-02		SERVICE	PARKING BRAKE ACCUMULATOR
12-15-05-3A	32-040	32-040-51		CHECK/INSP	TAIL SKID POP-UP INDICATOR
12-15-09-3A		32-040-05-1		SERVICE	LEFT BRAKE SURGE ACCUMULATOR
12-15-09-3A		32-040-05-2		SERVICE	RIGHT BRAKE SURGE ACCUMULATOR
12-21-04-3A 12-21-04-3B	12-002-C1			LUBRICATE	ELEVATOR PCA'S & HINGES
12-21-04-3A	12-002		G-12-002-C1	LUBRICATE	ELEVATOR POWER CONTROL ACTUATORS
12-21-04-3B	12-002		G-12-002-C1	LUBRICATE	ELEVATOR HINGES
12-21-05-3A 12-21-05-3B	12-003-C1			LUBRICATE	STABILIZER TRIM CONTROL SYSTEM
12-21-05-3A			G-12-003-C1	LUBRICATE	H STAB TRIM ACTUATOR ATTACH GIMBALS
12-21-05-3A	27-027		G-12-003-C1	LUBRICATE	STAB TRIM ACTUATOR ATTACHMENT GIMBAL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-4



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-05-3B			G-12-003-C1	LUBRICATE	H STAB TRIM ACTUATOR BALL NUT/SCREW
12-21-05-3B	27-029		G-12-003-C1	LUBRICATE	STAB TRIM ACTUATOR BALL NUT & SCREW
12-21-05-3C		12-003-03		LUBRICATE	STAB TRIM CONTROL MODULE ROD ENDS
12-21-06-3A 12-21-06-3B	12-004-C1			LUBRICATE	RUDDER PCA'S & HINGES
12-21-06-3A	12-004		G-12-004-C1	LUBRICATE	RUDDER HINGES
12-21-06-3B	12-004		G-12-004-C1	LUBRICATE	RUDDER POWER CONTROL ACTUATORS
12-21-07-3A 12-21-07-3B	12-005-C1-1			LUBRICATE	L OUTBOARD AILERON PCA'S & HINGES
12-21-07-3A 12-21-07-3B	12-005-C1-2			LUBRICATE	R OUTBOARD AILERON PCA'S & HINGES
12-21-07-3A			G-12-005-C1-1	LUBRICATE	OUTBOARD AILERON HINGES - LEFT
12-21-07-3A			G-12-005-C1-2	LUBRICATE	OUTBOARD AILERON HINGES - RIGHT
12-21-07-3B			G-12-005-C1-1	LUBRICATE	OUTBD AILERON PCA'S - LEFT
12-21-07-3B			G-12-005-C1-2	LUBRICATE	OUTBD AILERON PCA'S - RIGHT
12-21-07-3C 12-21-07-3D	12-006-C1-1			LUBRICATE	LEFT INBOARD AILERON PCA'S & HINGES
12-21-07-3C 12-21-07-3D	12-006-C1-2			LUBRICATE	RIGHT INBOARD AILERON PCA'S & HINGES
12-21-07-3C			G-12-006-C1-1	LUBRICATE	INBOARD AILERON HINGES - LEFT
12-21-07-3C			G-12-006-C1-2	LUBRICATE	INBOARD AILERON HINGES - RIGHT
12-21-07-3D			G-12-006-C1-1	LUBRICATE	LEFT INBD AILERON PCA'S
12-21-07-3D			G-12-006-C1-2	LUBRICATE	RIGHT INBD AILERON PCA'S
12-21-07-3E		12-006-03		LUBRICATE	LH LCCA TORQUE TUBE ASSEMBLY
12-21-08-3A 12-21-08-3B	12-007-C1-1			LUBRICATE	L OUTBD SLAT MAIN/AUX TRACK ROLLERS
12-21-08-3A 12-21-08-3B	12-007-C1-2			LUBRICATE	R OUTBD SLAT MAIN/AUX TRACK ROLLERS
12-21-08-3A		12-007-C1-3		LUBRICATE	L OUTBD SLAT AUX TRACK ROLLERS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-08-3A		12-007-C1-4		LUBRICATE	R OUTBD SLAT AUX TRACK ROLLERS
12-21-08-3A			G-12-007-C1-1	LUBRICATE	L OUTBD LE SLAT MAIN TRACK ROLLERS
12-21-08-3A			G-12-007-C1-2	LUBRICATE	R OUTBD LE SLAT MAIN TRACK ROLLERS
12-21-08-3B			G-12-007-C1-1	LUBRICATE	L OUTBD LE SLAT AUX TRACK ROLLERS
12-21-08-3B			G-12-007-C1-2	LUBRICATE	R OUTBD LE SLAT AUX TRACK ROLLERS
12-21-08-3B 12-21-08-3E	27-050		G-12-007-C1 G-12-009-01	LUBRICATE	LE SLAT LINKAGES
12-21-08-3C 12-21-08-3D	12-008-C1-1			LUBRICATE	L INBD SLAT MAIN/AUX TRACK ROLLERS
12-21-08-3C 12-21-08-3D	12-008-C1-2			LUBRICATE	R INBD SLAT MAIN/AUX TRACK ROLLERS
12-21-08-3C			G-12-008-C1-1	LUBRICATE	L INBD LE SLAT MAIN TRACK ROLLERS
12-21-08-3C			G-12-008-C1-2	LUBRICATE	R INBD LE SLAT MAIN TRACK ROLLERS
12-21-08-3D			G-12-008-C1-1	LUBRICATE	LEFT INBD LE SLAT AUX TRACK ROLLERS
12-21-08-3D			G-12-008-C1-2	LUBRICATE	RIGHT INBD LE SLAT AUX TRACK ROLLERS
12-21-08-3E		12-009-01-1		LUBRICATE	LEFT INBD LE SLAT SIDE BRACE LINK
12-21-08-3E		12-009-01-2		LUBRICATE	RIGHT INBD LE SLAT SIDE BRACE LINK
12-21-08-3F		12-010-01-1		LUBRICATE	LEFT LE SLAT DRIVE SHAFT COUPLINGS
12-21-08-3F		12-010-01-2		LUBRICATE	RIGHT LE SLAT DRIVE SHAFT COUPLINGS
12-21-08-3F	27-048		G-12-010-01	LUBRICATE	LE SLAT DRIVE SHAFT COUPLINGS
12-21-08-3G		12-008-03-1		LUBRICATE	L OUTBD LE SLAT TRK HOUSE/DRAIN TUBE
12-21-08-3H	27-063	27-063-02		LUBRICATE	LE SLAT SKEW DETECTION SYSTEM
12-21-08-3I		27-047-02		SERVICE	LE SLAT ALTERNATE DRIVE MOTORS
12-21-08-3J	27-068	27-068-01		SERVICE	LE SLAT DRIVE OFFSET GEARBOX
12-21-08-3K		12-008-03-2		LUBRICATE	R OUTBD LE SLAT TRK HOUSE/DRAIN TUBE
12-21-09-3A 12-21-09-3I	12-011-C1-1			LUBRICATE	LEFT TE FLAP DRIVE SHAFT COUPLINGS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-6



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-09-3A 12-21-09-3I	12-011-C1-2			LUBRICATE	RIGHT TE FLAP DRIVE SHAFT COUPLINGS
12-21-09-3A			G-12-011-C1-1	LUBRICATE	LEFT TE FLAP DRIVE SHAFT COUPLINGS
12-21-09-3A			G-12-011-C1-2	LUBRICATE	RIGHT TE FLAP DRIVE SHAFT COUPLINGS
12-21-09-3A	27-038		G-12-011-01	LUBRICATE	TE FLAP DRIVE SHAFT COUPLINGS
12-21-09-3B 12-21-09-3C	12-012-C1-1			LUBRICATE	L OUTBD TE FLAP DRIVE LINK/ROLLERS
12-21-09-3B 12-21-09-3C	12-012-C1-2			LUBRICATE	R OUTBD TE FLAP DRIVE LINK/ROLLERS
12-21-09-3B			G-12-012-C1-1	LUBRICATE	LEFT OUTBD TE FLAP DRIVE LINKAGES
12-21-09-3B			G-12-012-C1-2	LUBRICATE	RIGHT OUTBD TE FLAP DRIVE LINKAGES
12-21-09-3B 12-21-09-3G 12-21-09-3H	27-039		G-12-012-01	LUBRICATE	TE FLAP DRIVE LINKAGES
12-21-09-3C			G-12-012-C1-1	LUBRICATE	L OUTBD TE FLAP DEFLECTION ROLLERS
12-21-09-3C			G-12-012-C1-2	LUBRICATE	R OUTBD TE FLAP DEFLECTION ROLLERS
12-21-09-3D 12-21-09-3E 12-21-09-3F	12-013-C1-1			LUBRICATE	L INBD TE FLAP AFT FLAP MECHANISM
12-21-09-3D 12-21-09-3E 12-21-09-3F	12-013-C1-2			LUBRICATE	R INBD TE FLAP AFT FLAP MECHANISM
12-21-09-3D			G-12-013-C1-1	LUBRICATE	LEFT INBD TE AFT FLAP DRIVE MECH
12-21-09-3D			G-12-013-C1-2	LUBRICATE	RIGHT INBD TE AFT FLAP DRIVE MECH
12-21-09-3E			G-12-013-C1-1	LUBRICATE	L INBD TE AFT FLAP INBD EXT HINGE
12-21-09-3E			G-12-013-C1-2	LUBRICATE	R INBD TE AFT FLAP INBD EXT HINGE
12-21-09-3F			G-12-013-C1-1	LUBRICATE	L INB TE AFT FLAP DEFLECTION ROLLERS
12-21-09-3F			G-12-013-C1-2	LUBRICATE	R INB TE AFT FLAP DEFLECTION ROLLERS
12-21-09-3G		12-014-01-1		LUBRICATE	L INBD TE FLAP DRIVE LINKAGE NO. 3
12-21-09-3G		12-014-01-2		LUBRICATE	R INBD TE FLAP DRIVE LINKAGE NO. 6

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-09-3H		12-014-02-1		LUBRICATE	L INBD TE FLAP DRIVE LINKAGES NO. 4
12-21-09-3H		12-014-02-2		LUBRICATE	R INBD TE FLAP DRIVE LINKAGE NO. 5
12-21-09-3I			G-12-011-C1-1	LUBRICATE	LEFT TE OFFSET TEE GEARBOX
12-21-09-3I			G-12-011-C1-2	LUBRICATE	RIGHT TE OFFSET TEE GEARBOX
12-21-09-3J	27-067	27-067-01		SERVICE	TE FLAP DRIVE ROTARY ACTUATOR OIL
12-21-10-3A 12-21-10-3B	12-015-C1-1			LUBRICATE	L INBD SPOILER HINGES & PCA'S
12-21-10-3A 12-21-10-3B	12-015-C1-2			LUBRICATE	R INBD SPOILER HINGES & PCA'S
12-21-10-3A			G-12-015-C1-1	LUBRICATE	L INBD SPOILER HINGES & PCA ROD ENDS
12-21-10-3A			G-12-015-C1-2	LUBRICATE	R INBD SPOILER HINGES & PCA ROD END
12-21-10-3B			G-12-015-C1-1	LUBRICATE	L INBD SPOILER PCA TRUNNION BRACKETS
12-21-10-3B			G-12-015-C1-2	LUBRICATE	R INBD SPOILER PCA TRUNNION BRACKETS
12-21-10-3C 12-21-10-3D	12-016-C1-1			LUBRICATE	L OUTBOARD SPOILER PCA'S AND HINGES
12-21-10-3C 12-21-10-3D	12-016-C1-2			LUBRICATE	R OUTBOARD SPOILER PCA'S AND HINGES
12-21-10-3C			G-12-016-C1-1	LUBRICATE	LEFT OUTBOARD SPOILER HINGES
12-21-10-3C			G-12-016-C1-2	LUBRICATE	RIGHT OUTBOARD SPOILER HINGES
12-21-10-3D			G-12-016-C1-1	LUBRICATE	L OUTBD SPOILER PCA
12-21-10-3D			G-12-016-C1-2	LUBRICATE	R OUTBD SPOILER PCA
12-21-11-3A		12-016-03-1		LUBRICATE	LEFT MAIN LANDING GEAR BEAM
12-21-11-3A		12-016-03-2		LUBRICATE	RIGHT MAIN LANDING GEAR BEAM
12-21-11-3A		12-016-04-1		LUBRICATE	LEFT MAIN LANDING GEAR BEAM
12-21-11-3A		12-016-04-2		LUBRICATE	RIGHT MAIN LANDING GEAR BEAM
12-21-11-3A		12-016-05-1		LUBRICATE	LEFT MAIN LANDING GEAR BEAM
12-21-11-3A		12-016-05-2		LUBRICATE	RIGHT MAIN LANDING GEAR BEAM
12-21-11-3A		12-016-06-1		LUBRICATE	LEFT MAIN LANDING GEAR BEAM

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-8



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-11-3A		12-016-06-2		LUBRICATE	RIGHT MAIN LANDING GEAR BEAM
12-21-12-3A 12-21-12-3B 12-21-12-3C 12-21-12-3D	12-017-C1			LUBRICATE	NOSE GEAR ACTUATOR AND DRAG STRUT
12-21-12-3A			G-12-017-C1	LUBRICATE	NOSE GEAR ACTUATOR SUPPORT BEAM
12-21-12-3B			G-12-017-C1	LUBRICATE	NOSE GEAR RETRACT ACTUATOR
12-21-12-3B	32-018		G-12-017-C1	LUBRICATE	NOSE GEAR RETRACT ACTUATOR
12-21-12-3C			G-12-017-C1	LUBRICATE	NOSE GEAR UPPER DRAG STRUT
12-21-12-3D			G-12-017-C1	LUBRICATE	NOSE GEAR LOWER DRAG STRUT
12-21-12-3E 12-21-12-3F 12-21-12-3G 12-21-12-3H 12-21-12-3I 12-21-12-3J	12-018-C1			LUBRICATE	NOSE GEAR LOCK AND STEERING LINKAGES
12-21-12-3E			G-12-018-C1	LUBRICATE	NOSE GEAR LOCK CRANK
12-21-12-3F			G-12-018-C1	LUBRICATE	NOSE GEAR FWD LOCK LINK
12-21-12-3G			G-12-018-C1	LUBRICATE	NOSE GEAR AFT LOCK LINK
12-21-12-3H	12-018		G-12-018-C1	LUBRICATE	NOSE GEAR STEERING ARM LOCK LINK
12-21-12-3H	32-031		G-12-018-C1	LUBRICATE	N WHEEL STEERING MECH CONTROL PATH
12-21-12-3I			G-12-018-C1	LUBRICATE	NOSE GEAR LOCK ACTUATOR
12-21-12-3J			G-12-018-C1	LUBRICATE	NOSE WHEEL STEERING MECHANISM
12-21-12-3K 12-21-12-3L 12-21-12-3M	12-019-C1			LUBRICATE	N GEAR TRUNNION/STEER COLLAR & LINKS
12-21-12-3K			G-12-019-C1	LUBRICATE	NOSE GEAR TRUNNION BEARINGS
12-21-12-3K	32-034		G-12-020-C1	LUBRICATE	NOSE WHEEL STEERING ACTUATOR
12-21-12-3L			G-12-019-C1	LUBRICATE	NOSE WHEEL STEERING COLLAR
12-21-12-3M			G-12-019-C1	LUBRICATE	NOSE GEAR TORSION LINKS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-12-3N 12-21-12-3O 12-21-12-3P	12-020-C1			LUBRICATE	N GEAR STEERING ACT/NUT & TOW FITING
12-21-12-3N			G-12-020-C1	LUBRICATE	STEERING ACTUATOR ROD END & TRUNNION
12-21-12-3O			G-12-020-C1	LUBRICATE	NOSE GEAR FWD TOW FITTING
12-21-12-3P			G-12-020-C1	LUBRICATE	NOSE GEAR STEERING NUT & GLAND NUT
12-21-13-3A 12-21-13-3B 12-21-13-3C	12-021-C1			LUBRICATE	N GEAR DOORS & OPERATING MECHANISM
12-21-13-3A			G-12-021-C1	LUBRICATE	N GEAR FWD DOOR OPERATING MECHANISM
12-21-13-3B			G-12-021-C1	LUBRICATE	NOSE GEAR FWD & AFT DOOR HINGES
12-21-13-3C			G-12-021-C1	LUBRICATE	NOSE GEAR AFT DOOR OPERATOR STRUT
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F	12-022-C1-1			LUBRICATE	L GEAR SIDE/Drag BRACE / JURY STRUT
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F	12-022-C1-2			LUBRICATE	RT GEAR SIDE/Drag BRACE / JURY STRUT
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F	12-022-C2-1			LUBRICATE	L GEAR SIDE/Drag BRACE / JURY STRUT
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F	12-022-C2-2			LUBRICATE	RT GEAR SIDE/Drag BRACE / JURY STRUT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-10



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3I 12-21-14-3P	12-022-C3-1			LUBRICATE	L MAIN LANDING GEAR--UPPER END
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3I 12-21-14-3P	12-022-C3-2			LUBRICATE	R MAIN LANDING GEAR--UPPER END
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3I 12-21-14-3P	12-022-C4-1			LUBRICATE	L MAIN LANDING GEAR--UPPER END
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3I 12-21-14-3P	12-022-C4-2			LUBRICATE	R MAIN LANDING GEAR--UPPER END
12-21-14-3A			G-12-022-C1-1 G-12-022-C2-1	LUBRICATE	LEFT MAIN GEAR SIDE BRACE
12-21-14-3A			G-12-022-C1-2 G-12-022-C2-2	LUBRICATE	RIGHT MAIN GEAR SIDE BRACE
12-21-14-3A			G-12-022-C3-1 G-12-022-C4-1	LUBRICATE	LEFT MAIN GEAR SIDE BRACE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-14-3A			G-12-022-C3-1 G-12-022-C4-2	LUBRICATE	RIGHT MAIN GEAR SIDE BRACE
12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3G 12-21-14-3H 12-21-14-3I 12-21-14-3L 12-21-14-3M 12-21-14-3P 12-21-14-3S 12-21-14-3T	32-045		G-12-022-C3 G-12-022-C4 G-12-023-C3 G-12-023-C4 G-12-024-C3 G-12-024-C4	LUBRICATE	MAIN LANDING GEAR ASSEMBLY
12-21-14-3B			G-12-022-C1-1 G-12-022-C2-1	LUBRICATE	LEFT MAIN GEAR SIDE BRACE LOCK LINK
12-21-14-3B			G-12-022-C1-2 G-12-022-C2-2	LUBRICATE	RIGHT MAIN GEAR SIDE BRACE LOCK LINK
12-21-14-3B			G-12-022-C3-1 G-12-022-C4-1	LUBRICATE	LEFT MAIN GEAR SIDE BRACE LOCK LINK
12-21-14-3B			G-12-022-C3-2 G-12-022-C4-2	LUBRICATE	RIGHT MAIN GEAR SIDE BRACE LOCK LINK
12-21-14-3C			G-12-022-C1-1 G-12-022-C2-1	LUBRICATE	LEFT GEAR SIDE BRACE LOCK ACTUATOR
12-21-14-3C			G-12-022-C1-2 G-12-022-C2-2	LUBRICATE	RIGHT GEAR SIDE BRACE LOCK ACTUATOR
12-21-14-3C			G-12-022-C3-1 G-12-022-C4-1	LUBRICATE	LEFT GEAR SIDE BRACE LOCK ACTUATOR
12-21-14-3C			G-12-022-C3-2 G-12-022-C4-2	LUBRICATE	RIGHT GEAR SIDE BRACE LOCK ACTUATOR
12-21-14-3C	32-009		G-12-022-C1 G-12-022-C2 G-12-022-C3	LUBRICATE	MAIN GEAR SIDE BRACE LOCK ACTUATOR
12-21-14-3D			G-12-022-C1-1 G-12-022-C2-1	LUBRICATE	LEFT GEAR DRAG BRACE LOCK ACTUATOR

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-12



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-14-3D			G-12-022-C1-2 G-12-022-C2-2	LUBRICATE	RIGHT GEAR DRAG BRACE LOCK ACTUATOR
12-21-14-3D			G-12-022-C3-1 G-12-022-C4-1	LUBRICATE	LEFT GEAR DRAG BRACE LOCK ACTUATOR
12-21-14-3D			G-12-022-C3-2 G-12-022-C4-2	LUBRICATE	RIGHT GEAR DRAG BRACE LOCK ACTUATOR
12-21-14-3D	32-011		G-12-022-C1 G-12-022-C2 G-12-022-C3	LUBRICATE	MAIN GEAR DRAG BRACE LOCK ACTUATOR
12-21-14-3E			G-12-022-C1-1 G-12-022-C2-1	LUBRICATE	LEFT MAIN GEAR DRAG BRACE
12-21-14-3E			G-12-022-C1-2 G-12-022-C2-2	LUBRICATE	RIGHT MAIN GEAR DRAG BRACE
12-21-14-3E			G-12-022-C3-1 G-12-022-C4-1	LUBRICATE	LEFT MAIN GEAR DRAG BRACE
12-21-14-3E			G-12-022-C3-2 G-12-022-C4-2	LUBRICATE	RIGHT MAIN GEAR DRAG BRACE
12-21-14-3F			G-12-022-C1-1 G-12-022-C2-1	LUBRICATE	LEFT MAIN GEAR JURY STRUT
12-21-14-3F			G-12-022-C1-2 G-12-022-C2-2	LUBRICATE	RIGHT MAIN GEAR JURY STRUT
12-21-14-3F			G-12-022-C3-1 G-12-022-C4-1	LUBRICATE	LEFT MAIN GEAR JURY STRUT
12-21-14-3F			G-12-022-C3-2 G-12-022-C4-2	LUBRICATE	RIGHT MAIN GEAR JURY STRUT
12-21-14-3G		12-023-C1-1	W-12-023-03-1	LUBRICATE	LEFT MAIN GEAR PIVOT PIN
12-21-14-3G		12-023-C1-2	W-12-023-03-2	LUBRICATE	RIGHT MAIN GEAR PIVOT PIN
12-21-14-3G 12-21-14-3L 12-21-14-3S	12-023-C3-1			LUBRICATE	L PIVOT PIN/BRAKE RODS AND HOUSING
12-21-14-3G 12-21-14-3L 12-21-14-3S	12-023-C3-2			LUBRICATE	R PIVOT PIN/BRAKE RODS AND HOUSING

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-14-3G 12-21-14-3L 12-21-14-3S	12-023-C4-1			LUBRICATE	L PIVOT PIN/BRAKE RODS AND HOUSING
12-21-14-3G 12-21-14-3L 12-21-14-3S	12-023-C4-2			LUBRICATE	R PIVOT PIN/BRAKE RODS AND HOUSING
12-21-14-3G			G-12-023-C1-1 G-12-023-C2-1	LUBRICATE	LEFT MAIN GEAR TRUCK PIVOT PIN
12-21-14-3G			G-12-023-C1-2 G-12-023-C2-2	LUBRICATE	RIGHT MAIN GEAR TRUCK PIVOT PIN
12-21-14-3G			G-12-023-C3-1 G-12-023-C4-1	LUBRICATE	LEFT MAIN GEAR TRUCK PIVOT PIN
12-21-14-3G			G-12-023-C3-2 G-12-023-C4-2	LUBRICATE	RIGHT MAIN GEAR TRUCK PIVOT PIN
12-21-14-3H		12-023-02-1		LUBRICATE	L MAIN GEAR TORSION LINKS/UPLOCK FTG
12-21-14-3H		12-023-02-2		LUBRICATE	R MAIN GEAR TORSION LINKS/UPLOCK FTG
12-21-14-3H		12-023-04-1		LUBRICATE	L MAIN GEAR TORSION LINKS/UPLOCK FTG
12-21-14-3H		12-023-04-2		LUBRICATE	R MAIN GEAR TORSION LINKS/UPLOCK FTG
12-21-14-3H 12-21-14-3M 12-21-14-3T	12-024-C3-1			LUBRICATE	L MAIN LANDING GEAR--LOWER END
12-21-14-3H 12-21-14-3M 12-21-14-3T	12-024-C3-2			LUBRICATE	R MAIN LANDING GEAR--LOWER END
12-21-14-3H 12-21-14-3M 12-21-14-3T	12-024-C4-1			LUBRICATE	L MAIN LANDING GEAR--LOWER END
12-21-14-3H 12-21-14-3M 12-21-14-3T	12-024-C4-2			LUBRICATE	R MAIN LANDING GEAR--LOWER END
12-21-14-3H			G-12-024-C3-1 G-12-024-C4-1	LUBRICATE	L MAIN GEAR TORSION LINKS/UPLOCK FTG
12-21-14-3H			G-12-024-C3-2 G-12-024-C4-2	LUBRICATE	R MAIN GEAR TORSION LINKS/UPLOCK FTG

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-14



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-14-3I			G-12-022-C3-1 G-12-022-C4-1	LUBRICATE	LEFT MLG RETRACT ACTUATOR
12-21-14-3I			G-12-022-C3-2 G-12-022-C4-2	LUBRICATE	RIGHT MLG RETRACT ACTUATOR
12-21-14-3I 12-21-14-3K 12-21-14-3M 12-21-14-3N 12-21-14-3O 12-21-14-3P	12-024-C1-1			LUBRICATE	LEFT MAIN GEAR
12-21-14-3I 12-21-14-3K 12-21-14-3M 12-21-14-3N 12-21-14-3O 12-21-14-3P	12-024-C1-2			LUBRICATE	RIGHT MAIN GEAR
12-21-14-3I 12-21-14-3K 12-21-14-3M 12-21-14-3N 12-21-14-3O 12-21-14-3P	12-024-C2-1			LUBRICATE	LEFT MAIN GEAR
12-21-14-3I 12-21-14-3K 12-21-14-3M 12-21-14-3N 12-21-14-3O 12-21-14-3P	12-024-C2-2			LUBRICATE	RIGHT MAIN GEAR
12-21-14-3I			G-12-024-C1-1 G-12-024-C2-1	LUBRICATE	LEFT MLG RETRACT ACTUATOR
12-21-14-3I			G-12-024-C1-2 G-12-024-C2-2	LUBRICATE	RIGHT MLG RETRACT ACTUATOR
12-21-14-3I	32-007		G-12-024-01	LUBRICATE	MAIN GEAR RETRACT ACTUATOR
12-21-14-3K			G-12-024-C1-1 G-12-024-C2-1	LUBRICATE	LEFT MAIN GEAR BRAKE SLEEVES
12-21-14-3K			G-12-024-C1-2 G-12-024-C2-2	LUBRICATE	RIGHT MAIN GEAR BRAKE SLEEVES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-14-3L		12-023-C2-1	W-12-023-03-1	LUBRICATE	LEFT MAIN GEAR BRAKE RODS
12-21-14-3L		12-023-C2-2	W-12-023-03-2	LUBRICATE	RIGHT MAIN GEAR BRAKE RODS
12-21-14-3L			G-12-023-C3-1 G-12-023-C4-1	LUBRICATE	LEFT MAIN GEAR BRAKE RODS
12-21-14-3L			G-12-023-C3-2 G-12-023-C4-2	LUBRICATE	RIGHT MAIN GEAR BRAKE RODS
12-21-14-3L			G-12-023-C1-1 G-12-023-C2-1	LUBRICATE	LEFT MAIN GEAR BRAKE RODS
12-21-14-3L			G-12-023-C1-2 G-12-023-C2-2	LUBRICATE	RIGHT MAIN GEAR BRAKE RODS
12-21-14-3M			G-12-024-C1-1 G-12-024-C2-1	LUBRICATE	LEFT MAIN GEAR TRUCK POSITIONER
12-21-14-3M			G-12-024-C1-2 G-12-024-C2-2	LUBRICATE	RIGHT MAIN GEAR TRUCK POSITIONER
12-21-14-3M			G-12-024-C3-1 G-12-024-C4-1	LUBRICATE	LEFT MAIN GEAR TRUCK POSITIONER
12-21-14-3M			G-12-024-C3-2 G-12-024-C4-2	LUBRICATE	RIGHT MAIN GEAR TRUCK POSITIONER
12-21-14-3M	32-016		G-12-024-C1 G-12-024-C2	LUBRICATE	MAIN GEAR TRUCK POSITIONER
12-21-14-3N			G-12-024-C1-1 G-12-024-C2-1	LUBRICATE	L MAIN GEAR SHOCK STRUT GLAND NUT
12-21-14-3N			G-12-024-C1-2 G-12-024-C2-2	LUBRICATE	R MAIN GEAR SHOCK STRUT GLAND NUT
12-21-14-3O			G-12-024-C1-1 G-12-024-C2-1	LUBRICATE	L MLG HYDRAULIC LINE SUPPORT BRACE
12-21-14-3O			G-12-024-C1-2 G-12-024-C2-2	LUBRICATE	R MLG HYDRAULIC LINE SUPPORT BRACE
12-21-14-3P			G-12-022-C3-1 G-12-022-C4-1	LUBRICATE	LEFT MLG SHOCK STRUT TRUNNION
12-21-14-3P			G-12-022-C3-2 G-12-022-C4-2	LUBRICATE	RIGHT MLG SHOCK STRUT TRUNNION
12-21-14-3P			G-12-024-C1-1 G-12-024-C2-1	LUBRICATE	LEFT MLG SHOCK STRUT TRUNNION

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-16



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-14-3P			G-12-024-C1-2 G-12-024-C2-2	LUBRICATE	RIGHT MLG SHOCK STRUT TRUNNION
12-21-14-3Q		12-023-03-1	W-12-023-C1-1	LUBRICATE	LEFT MAIN GEAR TORQUE ARM
12-21-14-3Q		12-023-03-2	W-12-023-C1-2	LUBRICATE	RIGHT MAIN GEAR TORQUE ARM
12-21-14-3Q		12-023-05-1	W-12-023-C1-1	LUBRICATE	LEFT MAIN GEAR TORQUE ARM
12-21-14-3Q		12-023-05-2	W-12-023-C1-2	LUBRICATE	RIGHT MAIN GEAR TORQUE ARM
12-21-14-3R		12-024-09-1		LUBRICATE	LEFT MAIN GEAR AFT TRUNNION BUSHING
12-21-14-3R		12-024-09-2		LUBRICATE	R MAIN GEAR AFT TRUNNION BUSHING
12-21-14-3R		12-024-10-1		LUBRICATE	LEFT MAIN GEAR AFT TRUNNION BUSHING
12-21-14-3R		12-024-10-2		LUBRICATE	R MAIN GEAR AFT TRUNNION BUSHING
12-21-14-3S			G-12-023-C3-1 G-12-023-C4-1	LUBRICATE	L MAIN GEAR BRAKE HOUSING
12-21-14-3S			G-12-023-C3-2 G-12-023-C4-2	LUBRICATE	R MAIN GEAR BRAKE HOUSING
12-21-14-3T			G-12-024-C3-1 G-12-024-C4-1	LUBRICATE	L MAIN LANDING GEAR TRUCK BEAM
12-21-14-3T			G-12-024-C3-2 G-12-024-C4-2	LUBRICATE	R MAIN LANDING GEAR TRUCK BEAM
12-21-15-3A 12-21-15-3B 12-21-15-3C 12-21-15-3D	12-025-C1-1			LUBRICATE	L MAIN GEAR DOOR/ROLLER/HOOK/LINKAGE
12-21-15-3A 12-21-15-3B 12-21-15-3C 12-21-15-3D	12-025-C1-2			LUBRICATE	R MAIN GEAR DOOR/ROLLER/HOOK/LINKAGE
12-21-15-3A 12-21-15-3B 12-21-15-3C 12-21-15-3D	12-025-C2-1			LUBRICATE	L MAIN GEAR DOOR/ROLLER/HOOK/LINKAGE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-15-3A 12-21-15-3B 12-21-15-3C 12-21-15-3D	12-025-C2-2			LUBRICATE	R MAIN GEAR DOOR/ROLLER/HOOK/LINKAGE
12-21-15-3A 12-21-15-3B 12-21-15-3C	12-025-C3-1			LUBRICATE	L MAIN GEAR DOOR AND HINGES
12-21-15-3A 12-21-15-3B 12-21-15-3C	12-025-C3-2			LUBRICATE	R MAIN GEAR DOOR AND HINGES
12-21-15-3A 12-21-15-3B 12-21-15-3C	12-025-C4-1			LUBRICATE	L MAIN GEAR DOOR AND HINGES
12-21-15-3A 12-21-15-3B 12-21-15-3C	12-025-C4-2			LUBRICATE	R MAIN GEAR DOOR AND HINGES
12-21-15-3A			G-12-025-C1-1 G-12-025-C2-1 G-12-025-C3-1 G-12-025-C4-1	LUBRICATE	LEFT MLG DOOR & DOOR UPLOCK ROLLER
12-21-15-3A			G-12-025-C1-2 G-12-025-C2-2 G-12-025-C3-2 G-12-025-C4-2	LUBRICATE	RIGHT MLG DOOR & DOOR UPLOCK ROLLER
12-21-15-3A	32-005		G-12-025-C1 G-12-025-C2 G-12-025-C3 G-12-025-C4	LUBRICATE	MAIN GEAR DOOR UPLOCK ROLLER BEARING
12-21-15-3A	32-013		G-12-025-C1 G-12-025-C2 G-12-025-C3 G-12-025-C4	LUBRICATE	MAIN GEAR DOOR ACTUATOR & LINKAGE
12-21-15-3A	32-053		G-12-025-C3 G-12-025-C4	LUBRICATE	MAIN LANDING GEAR DOOR AND HINGES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-18



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-15-3B			G-12-025-C1-1 G-12-025-C2-1 G-12-025-C3-1 G-12-025-C4-1	LUBRICATE	LEFT MLG DOOR UPLOCK HOOK BEARING
12-21-15-3B			G-12-025-C1-2 G-12-025-C2-2 G-12-025-C3-2 G-12-025-C4-2	LUBRICATE	RIGHT MLG DOOR UPLOCK HOOK BEARING
12-21-15-3B	32-006		G-12-025-C1 G-12-025-C2 G-12-025-C3 G-12-025-C4	LUBRICATE	DOOR LATCH HOOK BEARING
12-21-15-3C			G-12-025-C1-1 G-12-025-C2-1 G-12-025-C3-1 G-12-025-C4-1	LUBRICATE	LEFT MLG TRUNNION DOOR LINKAGE
12-21-15-3C			G-12-025-C1-2 G-12-025-C2-2 G-12-025-C3-2 G-12-025-C4-2	LUBRICATE	RIGHT MLG TRUNNION DOOR LINKAGE
12-21-15-3D			G-12-025-C1-1 G-12-025-C2-1	LUBRICATE	LEFT MLG DRAG BRACE DOOR LINKAGE
12-21-15-3D			G-12-025-C1-2 G-12-025-C2-2	LUBRICATE	RIGHT MLG DRAG BRACE DOOR LINKAGE
12-21-16-3A		12-040-01		LUBRICATE	TAIL SKID LEVER MECHANISM
12-21-16-3A	32-039		G-12-040-01	LUBRICATE	TAIL SKID LEVER MECHANISM
12-21-17-3A 12-21-17-3B	12-044-C1-1			LUBRICATE	LEFT WHEEL WELL SPHERICAL BEARINGS
12-21-17-3A 12-21-17-3B	12-044-C1-2			LUBRICATE	RIGHT WHEEL WELL SPHERICAL BEARINGS
12-21-17-3A			G-12-044-C1-1	LUBRICATE	LEFT WHEEL WELL SPHERICAL BEARINGS
12-21-17-3A			G-12-044-C1-2	LUBRICATE	RIGHT WHEEL WELL SPHERICAL BEARINGS
12-21-17-3B			G-12-044-C1-1	LUBRICATE	LEFT SUPPORT SPHERICAL BEARING
12-21-17-3B			G-12-044-C1-2	LUBRICATE	RIGHT SUPPORT SPHERICAL BEARING

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-18-3A 12-21-18-3B	12-026-C1			LUBRICATE	ENTRY/SERVICE DOORS
12-21-18-3A 12-21-18-3B	12-026-C2			LUBRICATE	ENTRY/SERVICE DOORS
12-21-18-3A			G-12-026-C1	LUBRICATE	FWD ROLLER GUIDE ENTRY/SERVICE DOOR
12-21-18-3A	12-059		G-12-061-C1	LUBRICATE	CREW ENTRY DOOR ROLLER PIN
12-21-18-3A	52-007		G-12-026-01	LUBRICATE	ENTRY/SERVICE DOOR ROLLER PIN
12-21-18-3B			G-12-026-C1	LUBRICATE	ENTRY/SERVICE DOOR ROLLER TRACKS
12-21-18-3B	12-060		G-12-061-C1	LUBRICATE	CREW ENTRY DOOR ROLLER TRACKS
12-21-18-3B 12-21-18-3A	12-061-C1			LUBRICATE	CREW ENTRY DOOR
12-21-19-3A		12-001-01	W-25-020-01	LUBRICATE	OFF-WING ESCAPE SYSTEM
12-21-20-3A 12-21-20-3B 12-21-20-3C	12-027-C1			LUBRICATE	OVERWING ESCAPE HATCH
12-21-20-3A 12-21-20-3B 12-21-20-3C	12-027-C2			LUBRICATE	OVERWING ESCAPE HATCH
12-21-20-3A 12-21-20-3B 12-21-20-3C	12-027-C3			LUBRICATE	OVERWING ESCAPE HATCH
12-21-20-3A			G-12-027-C1	LUBRICATE	ESCAPE HATCH MECH NEEDLE BEARINGS
12-21-20-3A			G-12-027-C2	LUBRICATE	ESCAPE HATCH MECH NEEDLE BEARINGS
12-21-20-3A			G-12-027-C3	LUBRICATE	ESCAPE HATCH MECH NEEDLE BEARINGS
12-21-20-3A	52-013		G-12-027-C3	LUBRICATE	OVERWING ESCAPE HATCH MECHANISM
12-21-20-3B			G-12-027-C1	LUBRICATE	ESCAPE HATCH MECH BELLCRANK ROLLERS
12-21-20-3B			G-12-027-C2	LUBRICATE	ESCAPE HATCH MECH BELLCRANK ROLLERS
12-21-20-3B			G-12-027-C3	LUBRICATE	ESCAPE HATCH MECH BELLCRANK ROLLERS
12-21-20-3C			G-12-027-C1	LUBRICATE	ESCAPE HATCH PRESSURE STOPS
12-21-20-3C			G-12-027-C2	LUBRICATE	ESCAPE HATCH PRESSURE STOPS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-20



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-20-3C			G-12-027-C3	LUBRICATE	ESCAPE HATCH PRESSURE STOPS
12-21-21-3A		12-043-01		LUBRICATE	EMERGENCY EXIT DOORS
12-21-21-3A	52-035		G-12-043-01	LUBRICATE	EMERGENCY EXIT DOORS
12-21-22-3A 12-21-22-3B 12-21-22-3C 12-21-22-3D	12-028-C1			LUBRICATE	STD AFT CARGO DOOR MECHANISM
12-21-22-3A			G-12-028-C1	LUBRICATE	STD FWD/AFT CARGO DOOR LATCH ROLLER
12-21-22-3A	52-017		G-12-028-C1	LUBRICATE	STD FWD/AFT CARGO DOOR LATCH ROLLERS
12-21-22-3B 12-21-22-3A 12-21-22-3C 12-21-22-3D	12-028-C3			LUBRICATE	STD FORWARD CARGO DOOR MECHANISM
12-21-22-3B			G-12-028-C1	LUBRICATE	STD FWD/AFT CARGO DR HINGE ASSEMBLY
12-21-22-3C			G-12-028-C1	LUBRICATE	STD FWD/AFT CARGO VEN DOOR MECHANISM
12-21-22-3D			G-12-028-C1	LUBRICATE	STD FWD/AFT CARGO DR LIFT/LATCH MECH
12-21-22-3E 12-21-22-3K 12-21-22-3L	12-028-C2			LUBRICATE	AFT CARGO DOOR STOPS & HOOK ROLLERS
12-21-22-3E			G-12-028-C2	LUBRICATE	STD FWD/AFT CARGO DOOR STOPS
12-21-22-3F 12-21-22-3G 12-21-22-3I 12-21-22-3J	12-029-C1			LUBRICATE	LARGE FWD CARGO DOOR
12-21-22-3F 12-21-22-3G 12-21-22-3H 12-21-22-3I 12-21-22-3J 12-21-22-3M 12-21-22-3P	12-046-C1			LUBRICATE	LARGE AFT CARGO DOOR
12-21-22-3F	12-046		G-12-046-C1	LUBRICATE	LARGE AFT CARGO DOOR LIFT ARMS
12-21-22-3F	12-061		G-12-029-C1	LUBRICATE	LARGE FWD CARGO DOOR LIFT ARMS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-22-3G	12-047		G-12-046-C1	LUBRICATE	LARGE AFT CARGO DOOR MAIN LATCH CAMS
12-21-22-3G	12-062		G-12-029-C1	LUBRICATE	LARGE CARGO DOOR MAIN LATCH CAMS
12-21-22-3H 12-21-22-3P	12-029-C2			LUBRICATE	LARGE CARGO DR HOOK SHAFT AND VENTS
12-21-22-3H	12-048		G-12-046-C1	LUBRICATE	LGE AFT CRGO DOOR PULL-IN HOOK SHAFT
12-21-22-3H	12-063		G-12-029-C2	LUBRICATE	LARGE CARGO DOOR PULL-IN HOOK SHAFT
12-21-22-3I	12-049		G-12-046-C1	LUBRICATE	LGE AFT CARGO DOOR LATCH LOCK HANDLE
12-21-22-3I	12-064		G-12-029-C1	LUBRICATE	LARGE CARGO DOOR LATCH LOCK HANDLE
12-21-22-3J	12-050		G-12-046-C1	LUBRICATE	LGE AFT CRGO DR DRIVE SHAFT COUPLING
12-21-22-3J	12-065		G-12-029-C1	LUBRICATE	LARGE CARGO DR DRIVE SHAFT COUPLINGS
12-21-22-3K 12-21-22-3E 12-21-22-3L	12-028-C4			LUBRICATE	STD FWD CRGO DR STOPS & HOOK ROLLERS
12-21-22-3K			G-12-028-C2	LUBRICATE	CARGO DOOR HOOK ROLLER ATTACH BOLTS
12-21-22-3L			G-12-028-C2	LUBRICATE	FWD/AFT CARGO DOOR HINGE ACTUATORS
12-21-22-3M	12-051		G-12-046-C1	LUBRICATE	LARGE AFT CARGO DOOR HINGE/HINGE PIN
12-21-22-3M	12-066	12-066-51		LUBRICATE	LARGE FWD CARGO DOOR HINGE/HINGE PIN
12-21-22-3P	12-052		G-12-046-C1	LUBRICATE	LRGE AFT CRGO DR VENT DOOR PUSH RODS
12-21-22-3P	12-067		G-12-029-C2	LUBRICATE	LARGE CARGO DOOR
12-21-23-3A	12-053		G-12-058-C1	LUBRICATE	MAIN DECK CARGO DR VENT DR PUSH RODS
12-21-23-3A 12-21-23-3B 12-21-23-3C 12-21-23-3D 12-21-23-3E	12-058-C1			LUBRICATE	MAIN DECK CARGO DOOR
12-21-23-3B	12-054		G-12-058-C1	LUBRICATE	MAIN DECK CARGO DOOR LATCH CAMS
12-21-23-3C	12-055		G-12-058-C1	LUBRICATE	MAIN DECK CRGO DR PULL-IN HOOK SHAFT
12-21-23-3D	12-056		G-12-058-C1	LUBRICATE	MAIN DECK CARGO DOOR LATCH LOCK
12-21-23-3E	12-057		G-12-058-C1	LUBRICATE	MAIN DECK CARGO DOOR HINGE MECHANISM

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-22



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-24-3A 12-21-24-3B	12-030-C1			LUBRICATE	BULK CARGO DR PRES STOP/LATCH ROLLER
12-21-24-3A			G-12-030-C1	LUBRICATE	BULK CARGO DR PRESS STOP PINS/PLATES
12-21-24-3B			G-12-030-C1	LUBRICATE	BULK CARGO DOOR LATCH ROLLERS
12-21-25-3A		12-045-01		LUBRICATE	THRUST REVERSER LATCH LEVER
12-21-27-3A		12-034-01		LUBRICATE	FWD EQUIPMENT BAY ACCESS DOOR
12-21-27-3B		12-035-01		LUBRICATE	E/E BAY ACCESS DOOR
12-21-27-3C		12-036-01		LUBRICATE	ECS BAY ACCESS DOORS
12-21-27-3D		12-037-01		LUBRICATE	AIR DRIVEN PUMP ACCESS DOOR
12-21-27-3E 12-21-27-3F 12-21-27-3G	12-038-C1			LUBRICATE	EXTERIOR SERVICE ACCESS DOORS
12-21-27-3E 12-21-27-3F 12-21-27-3G	12-038-C2			LUBRICATE	EXTERIOR SERVICE ACCESS DOORS
12-21-27-3E			G-12-038-C1	LUBRICATE	FAIRING PRESS RELIEF ACCESS DOOR
12-21-27-3F			G-12-038-C1	LUBRICATE	GROUND AIR SUPPLY ACCESS DOORS
12-21-27-3G			G-12-038-C1	LUBRICATE	HYDRAULIC RESERVOIR FILL ACCESS DOOR
12-21-30-3A		12-031-01		LUBRICATE	RAT DEPLOYMENT SYSTEM
12-21-30-3A	29-014		G-12-031-01	LUBRICATE	RAT DEPLOYMENT SYSTEM
12-21-32-3A		12-032-01-1		LUBRICATE	LEFT WING NACELLE ATTACH FITTINGS
12-21-32-3A		12-032-01-2		LUBRICATE	RIGHT WING NACELLE ATTACH FITTINGS
12-21-32-3A		12-032-02-1		LUBRICATE	LEFT WING NACELLE ATTACH FITTINGS
12-21-32-3A		12-032-02-2		LUBRICATE	RIGHT WING NACELLE ATTACH FITTINGS
12-21-33-3A 12-21-33-3B 12-21-33-3C	12-033-C1			LUBRICATE	CONTAINERIZED CARGO HANDLING SYSTEM
12-21-33-3A			G-12-033-C1 G-12-033-C2	LUBRICATE	ROLLOUT STOP SHAFTS & PINS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-21-33-3A 12-21-33-3B	25-007		G-12-033-C1 G-12-033-C2	LUBRICATE	ROLLOUT STOP SHAFT/CAM FOLLOWER/PAWL
12-21-33-3B 12-21-33-3A	12-033-C2			LUBRICATE	CONTAINERIZED CARGO HANDLING SYSTEM
12-21-33-3B			G-12-033-C1 G-12-033-C2	LUBRICATE	ROLLOUT STOP CAM FOLLOWER
12-21-33-3C			G-12-033-C1	LUBRICATE	CARGO LATERAL GUIDE CAM FOLLOWERS
12-21-33-3C	25-008		G-12-033-C1	LUBRICATE	LATERAL GUIDE CAM FOLLOWERS
12-21-34-3A		12-039-01		LUBRICATE	NO. 2 SLIDING WINDOW - FLIGHT DECK
12-21-35-3A		12-041-01-1		LUBRICATE	L T/R BALLSCREW ACTUATOR NUTS
12-21-35-3A		12-041-01-2		LUBRICATE	R T/R BALLSCREW ACTUATOR NUTS
12-21-35-3A	78-321		G-12-041-01	LUBRICATE	T/R BALLSCREW ACTUATOR NUTS
12-21-36-3A		12-042-01-1		LUBRICATE	L T/R ROTARY FLEXIBLE DRIVE SHAFTS
12-21-36-3A		12-042-01-2		LUBRICATE	R T/R ROTARY FLEXIBLE DRIVE SHAFTS
12-21-36-3A	78-320		G-12-042-01	LUBRICATE	T/R ROTARY FLEXIBLE DRIVE SHAFTS
12-22-02-3A	80-101	80-101-01-1		REPLACE	STARTER OIL CHANGE
12-22-02-3A	80-101	80-101-01-2		REPLACE	STARTER OIL CHANGE
12-22-02-3A		80-105-01-1		REPLACE	ENGINE 1 STARTER
12-22-02-3A		80-105-01-2		REPLACE	ENGINE 2 STARTER
12-22-02-3A	80-401	80-401-01-1		REPLACE	ENGINE 1 STARTER OIL
12-22-02-3A	80-401	80-401-01-2		REPLACE	ENGINE 2 STARTER OIL
12-22-02-3A		80-406-01-1		REPLACE	ENGINE 1 STARTER
12-22-02-3A		80-406-01-2		REPLACE	ENGINE 2 STARTER
12-22-02-3A	80-503	80-503-01-1		REPLACE	ENGINE 1 STARTER OIL
12-22-02-3A	80-503	80-503-01-2		REPLACE	ENGINE 2 STARTER OIL
12-22-02-3B	80-201	80-201-01-1		REPLACE	ENGINE 1 STARTER OIL CHANGE
12-22-02-3B	80-201	80-201-01-2		REPLACE	ENGINE 2 STARTER OIL CHANGE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-24



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
12-22-02-3B		80-206-01-1		REPLACE	ENGINE 1 STARTER OIL
12-22-02-3B		80-206-01-2		REPLACE	ENGINE 2 STARTER OIL
12-22-02-3C	80-301	80-301-01-1		REPLACE	ENGINE 1 STARTER OIL CHANGE
12-22-02-3C	80-301	80-301-01-2		REPLACE	ENGINE 2 STARTER OIL CHANGE
12-22-02-3C		80-306-01-1		REPLACE	ENGINE 1 STARTER OIL
12-22-02-3C		80-306-01-2		REPLACE	ENGINE 2 STARTER OIL
12-22-04-3A		29-025-52		SERVICE	SYS C HYDRAULIC ADP OIL CHANGE
20-20-02-6A		20-001-01		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-02		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-03		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-04		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-11		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-12		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-13		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-14		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-21		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-22		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-23		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A		20-001-24		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6A 20-20-02-6B 20-20-02-6C 20-20-02-6D 20-20-02-6E 20-20-02-6F 20-20-02-6G 20-20-02-6H 20-20-02-6I 20-20-02-6K	27-001		G-27-001	CHECK/INSP	FLIGHT CONTROL CABLES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
20-20-02-6A 20-20-02-6B 20-20-02-6C 20-20-02-6D 20-20-02-6H	32-001		G-32-001	CHECK/INSP	LANDING GEAR CONTROL CABLES
20-20-02-6A 20-20-02-6B 20-20-02-6J	76-101		G-76-101	CHECK/INSP	THRUST CONTROL CABLES
20-20-02-6A	76-201		G-76-201	CHECK/INSP	THRUST CONTROL CABLES
20-20-02-6A	76-301		G-76-301	CHECK/INSP	THRUST CONTROL CABLES
20-20-02-6B		20-002-01		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-02		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-03		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-04		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-11		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-12		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-13		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-14		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-21		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-22		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-23		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6B		20-002-24		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6C		20-003-01		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6C		20-003-11		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6C		20-003-21		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6D		20-004-01-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-01-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-02-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-26



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
20-20-02-6D		20-004-02-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-03-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-03-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-04-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-04-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-11-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-11-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-12-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-12-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-13-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-13-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-14-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-14-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-21-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-21-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-22-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-22-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-23-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-23-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-24-1		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6D		20-004-24-2		CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-20-02-6E		20-005-01		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6E		20-005-02		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6E		20-005-03		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6E		20-005-11		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6E		20-005-12		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
20-20-02-6E		20-005-13		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6E		20-005-21		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6E		20-005-22		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6E		20-005-23		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6F		20-006-01		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6F		20-006-02		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6F		20-006-03		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6F		20-006-11		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6F		20-006-12		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6F		20-006-13		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6F		20-006-21		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6F		20-006-22		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6F		20-006-23		CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-20-02-6G		20-007-01		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-02		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-03		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-04		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-05		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-06		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-07		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-08		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-11		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-12		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-13		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-14		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-21		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-28



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
20-20-02-6G		20-007-22		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-23		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6G		20-007-24		CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-20-02-6H		20-008-02		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-03		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-04		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-05		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-11		CHECK/INSP	CONTROL CABLE TURNS - CREW CABIN
20-20-02-6H		20-008-12		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-13		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-14		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-15		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-21		CHECK/INSP	CONTROL CABLE TURNS - CREW CABIN
20-20-02-6H		20-008-22		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-23		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-24		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-25		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6H		20-008-26		CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-20-02-6I		20-009-01		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-02		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-03		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-04		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-11		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-12		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-13		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-14		CHECK/INSP	CONTROL CABLES - PROTECTED

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
20-20-02-6I		20-009-21		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-22		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-23		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6I		20-009-24		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-01-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-01-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-02-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-02-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-03-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-03-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-11-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-11-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-12-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-12-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-21-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-21-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-22-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6J		20-010-22-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6K		20-011-01-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6K		20-011-01-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6K		20-011-11-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6K		20-011-11-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6K		20-011-21-1		CHECK/INSP	CONTROL CABLES - PROTECTED
20-20-02-6K		20-011-21-2		CHECK/INSP	CONTROL CABLES - PROTECTED
20-55-40-6A		20-012-01		SPCL DETAIL	RADIO ALTIMETER COAX CABLE
20-55-42-6A		20-013-01		SPCL DETAIL	L/HIRF FEATURES ON FCC, DCU,AND YSM

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-30



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
20-55-42-6A			G-20-013-03	SPCL DETAIL	L/HIRF FEATURES ON FCC, DCU, AND YSM
20-55-46-6A		20-014-01		SPCL DETAIL	DATA CONCENTRATOR UNIT (DCU) L/WING
20-55-47-6A		20-015-01		SPCL DETAIL	DATA CONCENTRATOR UNIT (DCU) R/WING
20-55-54-6A	28-AWL	28-AWL-18-1		FUNCTIONAL	FQIS WIRING AND BONDING
20-55-54-6A	28-AWL	28-AWL-18-2		FUNCTIONAL	FQIS WIRING AND BONDING
20-60-03-2B		20-012-02		CHECK/INSP	INSPECT EWIS
20-60-03-2D		20-047-01		CHECK/INSP	CENTER AUXILIARY TANKS LH
20-60-03-2E		20-048-01		CHECK/INSP	MAIN TANK LH
20-60-03-2F		20-049-01		CHECK/INSP	MAIN FUEL TANK LEFT HAND SIDE
20-60-03-2G		20-050-01		CHECK/INSP	SURGE TANK LEFT HAND SIDE
20-60-03-2I		20-053-01		CHECK/INSP	CENTER AUXILIARY TANKS RH
20-60-03-2J		20-054-01		CHECK/INSP	MAIN TANK RH
20-60-03-2K		20-055-01		CHECK/INSP	MAIN FUEL TANK RH
20-60-03-2L		20-056-01		CHECK/INSP	SURGE TANK RH
21-21-10-5A	21-032	21-032-50		OPERATIONAL	OPERATIONALLY CHECK THE AVS SYSTEM
21-21-10-5A		21-032-51		OPERATIONAL	OPERATIONALLY CHECK THE AVS SYSTEM
21-23-05-2A	21-002	21-002-01		CLEAN	RETURN AIR GRILLES/LOUVERS
21-23-05-2A		21-002-02		CLEAN	RETURN AIR GRILLES
21-23-05-2A		21-002-03		CLEAN	RETURN AIR GRILLES/LOUVERS
21-23-05-2A		21-002-07		CLEAN	RETURN AIR GRILLES/LOUVERS
21-23-05-2A		21-044-01		CLEAN	RETURN AIR GRILLES
21-23-05-2A		21-044-02		CLEAN	RETURN AIR GRILLES
21-23-05-2A		21-052-01		CLEAN	RETURN AIR GRILLES
21-23-05-2B	53-001	53-001-01		OPERATIONAL	RETURN AIR GRILLE LOUVERS
21-23-05-2B		53-001-02		OPERATIONAL	RETURN AIR GRILLE LOUVERS
21-23-20-5A		21-051-01		OPERATIONAL	MAIN DECK AIR DISTRIBUTION SHUTOFF

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
21-23-20-5A	21-051	21-051-02		OPERATIONAL	MAIN DECK AIR DISTRIBUTION SHUTOFF
21-25-02-4A	21-003		G-21-003-01	REPLACE	RECIRCULATION AIR PREFILTERS
21-25-02-4A		21-003-02		REPLACE	RECIRCULATION AIR PREFILTERS
21-25-02-4A		21-003-03		REPLACE	RECIRCULATION AIR PREFILTERS
21-25-02-4A		21-003-04		REPLACE	RECIRCULATION AIR PREFILTERS
21-25-02-4A		21-003-05		REPLACE	RECIRCULATION AIR PREFILTERS
21-25-02-4B		21-004-01		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4B	21-004		G-21-004-01	REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4B		21-004-02		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4B		21-004-03		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4B		21-004-04		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4D	21-030		G-21-030-01	REPLACE	RECIRCULATION AIR FILTERS
21-25-02-4D		21-030-01		REPLACE	RECIRCULATION AIR FILTERS
21-25-02-4D		21-030-02		REPLACE	RECIRCULATION AIR FILTERS
21-25-02-4D		21-030-03		REPLACE	RECIRCULATION AIR FILTERS
21-25-02-4D		21-030-04		REPLACE	RECIRCULATION AIR FILTERS
21-25-02-4D		21-030-06		REPLACE	RECIRCULATION AIR FILTERS
21-25-02-4D		21-030-07		REPLACE	RECIRCULATION AIR FILTERS
21-25-02-4D		21-030-08		REPLACE	RECIRCULATION AIR FILTERS
21-25-02-4E	21-031		G-21-031-24	REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4E		21-031-25		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4E		21-031-26		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4E		21-031-27		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4E		21-031-28		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4F		21-004-05		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4F		21-004-06		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-32



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
21-25-02-4F		21-004-07		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4F		21-004-08		REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-25-02-4F	21-004		G-21-004-09	REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-26-03-4A	21-006	21-006-01		REPLACE	GALLEY VENTILATION FILTERS
21-26-03-4A		21-006-02		REPLACE	GALLEY VENTILATION FILTERS
21-26-03-4A		21-006-03		REPLACE	GALLEY VENTILATION FILTERS
21-26-03-4A		21-006-06		REPLACE	GALLEY VENTILATION FILTERS
21-26-03-4A		21-006-08		REPLACE	GALLEY VENTILATION FILTERS
21-26-03-4A		21-006-10		REPLACE	GALLEY VENTILATION FILTERS
21-26-03-4A		21-045-01		REPLACE	GALLEY VENTILATION FILTERS
21-26-03-4A	21-054	21-054-01		REPLACE	GALLEY VENTILATION FILTERS
21-26-30-5A		21-056-01		OPERATIONAL	CABIN SMOKING AREA EXHAUST VALVE
21-31-00-5A	21-009	21-009-01	A-21-007-C1	OPERATIONAL	CABIN PRESSURE OUTFLOW VALVE
21-31-00-5A		21-009-04	A-21-007-C4	OPERATIONAL	CABIN PRESSURE OUTFLOW VALVE
21-31-03-2A 21-31-03-2B	21-007-C1	B-21-009-01		CLEAN/INSP	CABIN PRESSURE OUTFLOW VALVE
21-31-03-2A 21-31-03-2B	21-007-C4	B-21-009-04		CLEAN/INSP	CABIN PRESSURE OUTFLOW VALVE
21-31-03-2A	21-007		G-21-007-C1 G-21-007-C2 G-21-007-C3	CHECK/INSP	CABIN PRESSURE OUTFLOW VALVE
21-31-03-2B	21-008		G-21-007-C1 G-21-007-C2 G-21-007-C3	CLEAN	CABIN PRESSURE OUTFLOW VALVE
21-32-01-5A	21-010	21-010-01		FUNCTIONAL	POSITIVE PRESSURE RELIEF VALVES
21-32-01-5A		21-010-02		FUNCTIONAL	POSITIVE PRESSURE RELIEF VALVES
21-32-02-4A	21-011	21-011-01	B-21-010-01	REPLACE	POSITIVE PRESS RELIEF VALVE FILTERS
21-32-02-4A		21-011-02	B-21-010-02	REPLACE	POSITIVE PRESS RELIEF VALVE FILTERS
21-33-00-5A	21-012	21-012-01		FUNCTIONAL	CABIN ALTITUDE WARNING SWITCH

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
21-33-00-5A		21-012-04		FUNCTIONAL	CABIN ALTITUDE WARNING SWITCH
21-43-00-5A	21-013	21-013-01	W-26-010-XX	OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-43-00-5A		21-013-04	W-26-010-XX	OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-43-00-5A		21-013-09	W-26-010-XX	OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-43-00-5A	21-031	21-031-51		OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-43-00-5B	21-014	21-014-01		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-43-00-5B		21-014-04		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-43-00-5B	21-014	21-014-08		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-43-00-5B		21-014-10		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-43-00-5B		21-043-02		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-43-00-5C	21-013	21-013-03		OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-44-00-5A	21-013	21-013-02	W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-44-00-5A		21-013-05	W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HTG SHUTOFF VALVES
21-44-00-5A		21-013-10	W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HTG SHUTOFF VALVES
21-44-00-5A	21-013	21-013-11		OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-44-00-5A	21-053	21-053-01	W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-44-00-5B	21-014	21-014-02		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-44-00-5B		21-014-05		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-44-00-5B		21-014-11		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-44-00-5B		21-014-12		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-44-00-5B	21-053	21-053-02		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-44-00-5C	21-013	21-013-06		OPERATIONAL	AFT CARGO HEATING SHUTOFF VALVE
21-44-00-5D	21-014	21-014-06		FUNCTIONAL	AFT CARGO TEMPERATURE SWITCHES
21-51-00-5A 21-51-00-5B	21-015-C1			OPERATIONAL	PACK TEMPERATURE CONTROLLERS
21-51-00-5A 21-51-00-5B	21-015-C2			OPERATIONAL	PACK TEMPERATURE CONTROLLERS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-34



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
21-51-00-5A 21-51-00-5B	21-015-C3			OPERATIONAL	PACK TEMPERATURE CONTROLLERS
21-51-00-5A 21-51-00-5B	21-015-C4			OPERATIONAL	PACK TEMPERATURE CONTROLLERS
21-51-00-5A	21-015		G-21-015-C1	OPERATIONAL	PACK TEMPERATURE CONTROLLERS
21-51-00-5B	21-016		G-21-015-C1	OPERATIONAL	STANDBY PACK TEMPERATURE CONTROLLER
21-51-00-5C		21-029-01		OPERATIONAL	PACK HIGH FLOW INHIBIT SYSTEM
21-51-00-5C		21-029-02		OPERATIONAL	PACK HIGH FLOW INHIBIT SYSTEM
21-51-00-5C		21-029-03		OPERATIONAL	PACK HIGH FLOW INHIBIT SYSTEM
21-51-00-5C		21-029-04		OPERATIONAL	PACK HIGH FLOW INHIBIT SYSTEM
21-51-00-5D		21-035-01	A-21-015-C1	OPERATIONAL	PACK LOW LIMIT CONTROL VALVE
21-51-00-5D		21-035-02	A-21-015-C1	OPERATIONAL	PACK LOW LIMIT CONTROL VALVE
21-51-01-2A		21-047-01		OPERATIONAL	CHECK THE ASCTU FLOW CNTRL TR MOTOR
21-51-02-7A	21-017	21-017-01		CLEAN	COOLING PACK HEAT EXCHANGERS
21-51-11-2A		21-036-01		OPERATIONAL	PACK LOW LIMIT VALVE PNEUMATIC CHECK
21-51-15-6A	21-001	21-001-01		CHECK/INSP	CABIN AIR SUPPLY CHECK VALVE
21-51-15-6A		21-001-02		CHECK/INSP	CABIN AIR SUPPLY CHECK VALVE
21-51-18-2A	21-019	21-019-01		FUNCTIONAL	PACK OVERHEAT SWITCH
21-51-19-2A	21-018	21-018-01		FUNCTIONAL	COMPRESSOR OUTLET OVERHEAT SWITCH
21-51-22-4A		21-033-01		FUNCTIONAL	CATALYTIC (OZONE) CONVERTERS
21-51-22-4A		21-033-05		FUNCTIONAL	CATALYTIC (OZONE) CONVERTERS
21-51-22-4A		21-033-2		FUNCTIONAL	CATALYTIC (OZONE) CONVERTERS
21-51-22-4B	21-033	21-033-07		RESTORE	CATALYTIC (OZONE) CONVERTERS
21-51-31-4A	21-035	21-035-51		CLEAN	AIR CONDITIONING PACK HEAT EXCHANGR
21-51-31-4B	21-034	21-034-51		FUNCTIONAL	CHECK THE AC PACK HX FOR LEAKAGE.
21-53-05-6A		21-046-01		OPERATIONAL	WATER SPRAY NOZZLES
21-53-05-6A		21-046-04		OPERATIONAL	WATER SPRAY NOZZLES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
21-58-00-5A 21-58-00-5B	21-020-CM			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C1			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C2			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C3			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C4			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C5			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C6			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C6			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C7			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-C9			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A	21-020		G-21-020-C1	OPERATIONAL	MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-02			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-05			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A	21-020		G-21-020-10	OPERATIONAL	MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-11			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5A 21-58-00-5B	21-020-12			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-58-00-5B	21-022		G-21-020-C1	OPERATIONAL	E/E COOLING OVERRIDE VALVE
21-58-00-5B	21-022		G-21-020-C9	OPERATIONAL	E/E COOLING OVERRIDE VALVE
21-58-00-5C		21-020-03		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-36



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
21-58-00-5C		21-020-06		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-01		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-02		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-03		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-04		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-05		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-06		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-06		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-07		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-09		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-10		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-12		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5C		21-031-13		FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-58-00-5D		21-020-04		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-020-07		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D	21-026	21-026-51		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-52		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-53		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-54		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-55		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D	21-026	21-026-56		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-56		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-57		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-59		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-60		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-00-5D		21-026-61		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
21-58-00-5D		21-026-62		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-58-02-6A	21-021	21-021-01	B-21-024-01	CHECK/INSP	E/E COOLING SUP/EXH FAN CHECK VALVES
21-58-02-6A		21-021-02	B-21-024-02	CHECK/INSP	E/E COOLING SUP/EXH FAN CHECK VALVES
21-58-06-7A		21-041-01		CLEAN/INSP	E/E COOLING SUPPLY AND EXHAUST FANS
21-58-06-7A		21-041-02		CLEAN/INSP	E/E COOLING SUPPLY AND EXHAUST FANS
21-58-16-2A		21-039-01		CLEAN	E/E COOLING FWD RACK TEMP SENSOR
21-58-17-2A		21-037-01		CLEAN	E/E COOLING LOW FLOW DETECTORS
21-58-17-2A		21-037-02		CLEAN	E/E COOLING LOW FLOW DETECTORS
21-58-18-2A		21-032-01		CHECK/INSP	ACRU EVAPORATOR AND HEAT EXCHANGERS
21-58-21-4A	21-023	21-023-01		FUNCTIONAL	E/E COOLING SKIN TEMPERATURE SENSOR
21-58-21-4A		21-023-02		FUNCTIONAL	E/E COOLING SKIN TEMPERATURE SENSOR
21-58-22-2A	21-024	21-024-01	A-21-021-01	CHECK/INSP	E/E COOLING SYSTEM CONICAL SCREENS
21-58-26-2A		21-038-01		CLEAN	E/E COOLING OVERHEAT SWITCH
21-58-26-2A		21-038-02		CLEAN	E/E COOLING OVERHEAT SWITCH
21-58-27-2A		21-040-01		CLEAN	E/E COOLING SUPPLY TEMP BULB
21-58-30-2A	21-029	21-029-51		CLEAN	FWD E/E COOLING AIR CLEANER
21-58-30-2A		21-029-52		CLEAN	FWD E/E COOLING AIR CLEANER
21-58-32-2A	21-028	21-028-51	B-21-034-01	OPERATIONAL	INSTRUMENT COOLING (ELECT) MONITORS
21-58-34-2A	21-027	21-027-51		OPERATIONAL	E/E COOLING LOW FLOW MONITOR SYSTEM
21-58-34-2A		21-027-52		OPERATIONAL	E/E COOLING LOW FLOW MONITOR SYSTEM
21-58-52-2A		21-036-50		CLEAN/INSP	INSPECT/CLEAN IFE COOLING SCREEN
21-58-52-2A		21-036-51		CLEAN/INSP	INSPECT/CLEAN IFE COOLING SCREEN
21-61-00-5A	21-025	21-025-01	W-21-025-C1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-00-5A		21-025-04	W-21-025-C4	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-00-5A		21-025-05	W-21-025-05	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-00-5A		21-025-09	W-21-025-C9	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-38



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
21-61-00-5A		21-025-10	W-21-025-D1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-00-5A		21-049-01	W-21-049-C1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-00-5A		21-055-01	W-21-055-C1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-01-4A		21-025-C1	W-21-025-01	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-01-4A		21-025-C4	W-21-025-04	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-01-4A		21-025-C5	W-21-025-05	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-01-4A		21-025-C9	W-21-025-09	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-01-4A		21-025-D1	W-21-025-10	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-01-4A		21-049-C1	W-21-049-01	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-01-4A		21-055-C1	W-21-055-01	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-61-05-6A		21-043-01		CHECK/INSP	TRIM AIR SUPPLY CHECK VALVES
21-61-09-4A		21-005-01		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-02		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A	21-005		G-21-005-03	REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-04		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-05		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-08		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-09		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-10		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-11		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-12		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-61-09-4A		21-005-13		REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-71-01-7A		21-042-01		CLEAN	FLIGHT COMPARTMENT HUMIDIFIER
22-10-00-5A	22-003		G-33-004-C1 G-33-004-C2	OPERATIONAL	A/P DISC ANNUNCIATOR INDICATOR
22-10-00-5B	22-004		G-33-004-C1 G-33-004-C2	OPERATIONAL	AUTOPILOT ANNUNCIATOR INDICATOR

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
22-12-00-A	22-001		P-06-047-01	CHECK/INSP	ELEVATOR AUTOPILOT SERVO LINKAGES
22-13-00-A	22-002		P-06-056-01	CHECK/INSP	DIRECTIONAL AUTOPILOT SERVO LINKAGES
22-21-03-2A		22-008-01		OPERATIONAL	YAW DAMPER SERVO SOLENOID VALVE
22-32-00-5A	22-007		G-33-004-C1 G-33-004-C2	OPERATIONAL	A/T DISC ANNUNCIATOR INDICATOR
23-24-00-5A	23-006	23-006-01		OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-24-00-5A		23-006-01		OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-24-00-5A		23-006-01		OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-24-00-5A		23-006-02		OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-24-01-2A	23-007	23-007-01		REPLACE	EMERGENCY LOCATOR TRANSMITTER
23-31-00-5A	23-001	23-001-01		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-02		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-04		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-05		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-06		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-07		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-08		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-09		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-10		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-11		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-12		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A		23-001-13		FUNCTIONAL	SPEAKER SYSTEM
23-31-00-5A	23-001	23-001-14		FUNCTIONAL	SPEAKER SYSTEM
23-61-01-2A	23-002	23-002-01		FUNCTIONAL	STATIC DISCHARGERS
23-71-00-5A	23-003	23-003-01		OPERATIONAL	VOICE RECORDER - SELF TEST
23-71-00-5A		23-003-02		OPERATIONAL	VOICE RECORDER - SELF TEST

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-40



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
23-71-00-5A		23-003-03		OPERATIONAL	VOICE RECORDER - SELF TEST
23-71-00-5B	23-004	23-004-01		FUNCTIONAL	VOICE RECORDER - 4 CHANNEL OPERATION
23-71-00-5B		23-004-02		FUNCTIONAL	VOICE RECORDER - 4 CHANNEL OPERATION
23-71-00-5B		23-004-03		FUNCTIONAL	VOICE RECORDER - 4 CHANNEL OPERATION
23-71-03-2B	23-005	23-005-02		RESTORE	VOICE RECORDER ULB
23-71-03-2C	23-005	23-005-03		OPERATIONAL	VOICE DATA RECORDER ULB
24-11-00-A	75-104		P-06-069-01	CHECK/INSP	IDG COOLING SYSTEM TUBES & HOSES
24-11-00-A	75-209		P-06-084-01	CHECK/INSP	IDG COOLING SYSTEM TUBES & HOSES
24-11-00-A	75-309		P-06-084-01	CHECK/INSP	IDG COOLING SYSTEM TUBES & HOSES
24-11-00-A	75-401		P-06-145-01	CHECK/INSP	IDG COOLING SYSTEM TUBES AND HOSES
24-11-00-5A		24-015-51		OPERATIONAL	BUS TIE BREAKER
24-11-00-5A		24-015-52		OPERATIONAL	BUS TIE BREAKER
24-11-00-5A		24-015-53		OPERATIONAL	BUS TIE BREAKER
24-11-00-5A			G-24-015-54	OPERATIONAL	BUS TIE BREAKER
24-11-00-5A		24-015-55		OPERATIONAL	BUS TIE BREAKER
24-11-01-6A		24-003-01		OPERATIONAL	IDG DISCONNECT
24-11-01-6A		24-003-02		OPERATIONAL	IDG DISCONNECT
24-11-01-6A	24-003		G-24-003-03	OPERATIONAL	IDG DISCONNECT
24-11-01-6A		24-003-04		OPERATIONAL	IDG DISCONNECT
24-11-01-6A		24-003-05		OPERATIONAL	IDG DISCONNECT
24-11-01-6A		24-003-06		OPERATIONAL	IDG DISCONNECT
24-11-02-2A		24-016-C1-1	W-24-017-07-1	REPLACE	ENGINE 1 IDG FILTER ELEMENTS
24-11-02-2A		24-016-C1-2	W-24-017-07-2	REPLACE	ENGINE 2 IDG FILTER ELEMENTS
24-11-02-2A		24-016-C2-1	W-24-017-08-1	REPLACE	ENGINE 1 IDG FILTER ELEMENTS
24-11-02-2A		24-016-C2-2	W-24-017-08-2	REPLACE	ENGINE 2 IDG FILTER ELEMENTS
24-11-02-2A		24-016-01-1	W-24-017-01-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
24-11-02-2A		24-016-01-2	W-24-017-01-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A		24-016-02-1	W-24-017-03-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A		24-016-02-2	W-24-017-03-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A		24-016-03-1	W-24-017-06-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A		24-016-03-2	W-24-017-06-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A			G-24-016-C1-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A			G-24-016-C1-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A	24-017		G-24-016-C2-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A	24-017		G-24-016-C2-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-11-02-2A			G-24-016-C1-1	REPLACE	ENGINE 1 IDG CHARGE FILTER ELEMENT
24-11-02-2A			G-24-016-C1-2	REPLACE	ENGINE 2 IDG CHARGE FILTER ELEMENT
24-11-02-2A	24-018		G-24-016-C2-1	REPLACE	ENGINE 1 IDG CHARGE FILTER ELEMENT
24-11-02-2A	24-018		G-24-016-C2-2	REPLACE	ENGINE 2 IDG CHARGE FILTER ELEMENT
24-11-03-6A	24-002	24-002-01-1		CHECK/INSP	ENGINE 1 IDG QAD COUPLING
24-11-03-6A	24-002	24-002-01-2		CHECK/INSP	ENGINE 2 IDG QAD COUPLING
24-11-04-B	75-105		P-06-069-01	CHECK/INSP	IDG AIR/OIL HEAT EXCHANGER
24-11-04-B	75-210		P-06-084-01	CHECK/INSP	IDG AIR/OIL HEAT EXCHANGER
24-11-04-B	75-310		P-06-084-01	CHECK/INSP	IDG AIR/OIL HEAT EXCHANGER
24-11-04-B	75-402		P-06-145-01	CHECK/INSP	IDG AIR/OIL HEAT EXCHANGER
24-11-07-A	75-106		P-06-069-01	CHECK/INSP	IDG AIR SHUTOFF VALVE
24-11-07-A	75-211		P-06-084-01	CHECK/INSP	IDG AIR SHUTOFF VALVE
24-11-07-A	75-311		P-06-084-01	CHECK/INSP	IDG AIR SHUTOFF VALVE
24-11-07-A			P-06-145-01	CHECK/INSP	IDG AIR SHUTOFF VALVE
24-11-07-B		24-013-01-1		CHECK/INSP	IDG AIR SHUTOFF VALVE - ENGINE 1
24-11-07-B		24-013-01-2		CHECK/INSP	IDG AIR SHUTOFF VALVE - ENGINE 2
24-11-07-B		24-013-02-1		CHECK/INSP	IDG AIR SHUTOFF VALVE - ENGINE 1

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-42



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
24-11-07-B		24-013-02-2		CHECK/INSP	IDG AIR SHUTOFF VALVE - ENGINE 2
24-11-07-B		24-013-03-1		CHECK/INSP	ENGINE 1 IDG AIR SHUTOFF VALVE
24-11-07-B		24-013-03-2		CHECK/INSP	ENGINE 2 IDG AIR SHUTOFF VALVE
24-11-07-B		24-013-05-1		CHECK/INSP	IDG AIR SHUTOFF VALVE ENGINE 1
24-11-07-B		24-013-05-2		CHECK/INSP	IDG AIR SHUTOFF VALVE ENGINE 2
24-11-07-2A		24-020-01-1		REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-01-2		REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-02-1		REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-02-2		REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-03-1		REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-03-2		REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-04-1		REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-04-2		REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-05-1		REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-11-07-2A		24-020-05-2		REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-22-00-5A	24-004	24-004-01		OPERATIONAL	BUS POWER CONTROL UNIT (BPCU)
24-22-00-5A		24-004-03		OPERATIONAL	BUS POWER CONTROL UNIT (BPCU)
24-22-00-5A		24-004-05		FUNCTIONAL	BUS POWER CONTROL UNIT (BPCU)
24-22-00-5A	24-004	24-004-06		OPERATIONAL	BUS POWER CONTROL UNIT (BPCU)
24-22-00-5B			G-24-004-01	OPERATIONAL	BUS TIE BREAKER
24-22-00-5B	24-005		G-24-005-02	OPERATIONAL	BUS TIE BREAKER
24-22-00-5B			G-24-004-03	OPERATIONAL	BUS TIE BREAKER
24-22-00-5B			G-24-004-05	OPERATIONAL	BUS TIE BREAKER
24-22-00-5B			G-24-004-06	OPERATIONAL	BUS TIE BREAKER
24-22-00-5C		24-015-01		OPERATIONAL	AUTOLAND DC TIE
24-22-00-5C		24-015-61		OPERATIONAL	AUTOLAND DC TIE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
24-22-00-5C		24-015-62		OPERATIONAL	AUTOLAND DC TIE
24-22-00-5C			G-24-015-63	OPERATIONAL	AUTOLAND DC TIE
24-22-00-5C		24-015-64		OPERATIONAL	AUTOLAND DC TIE
24-25-00-5A		24-013-51		OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-25-00-5A	24-013		G-24-013-52	OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-25-00-5A		24-013-53		OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-25-00-5A		24-013-54		OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-25-00-5A		24-013-55		OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-25-00-5A		24-013-56		OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-25-00-5A		24-013-57		OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-25-00-5B		24-014-51		FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-25-00-5B	24-014		G-24-014-52	FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-25-00-5B		24-014-53		FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-25-00-5B		24-014-54		FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-25-00-5B		24-014-56		FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-25-00-5B		24-014-57		FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-25-00-5B		24-014-59		FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-30-00-5A 24-30-00-5C	24-007-C1			OPERATIONAL	BATTERY CHARGER & CURRENT MONITOR
24-30-00-5A 24-30-00-5C	24-007-C2			OPERATIONAL	BATTERY CHARGER & CURRENT MONITOR
24-30-00-5A 24-30-00-5C	24-007-C3			OPERATIONAL	BATTERY CHARGER & CURRENT MONITOR
24-30-00-5A 24-30-00-5C	24-007-C4			OPERATIONAL	BATTERY CHARGER & CURRENT MONITOR
24-30-00-5A	24-007		G-24-007-C1 G-24-007-C4	OPERATIONAL	MAIN & APU BATTERY CHARGER
24-30-00-5B 24-30-00-5D	24-009-C1			OPERATIONAL	DC TIE CONTROL UNIT & DC TIE RELAY

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-44



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
24-30-00-5B 24-30-00-5D	24-009-C2			OPERATIONAL	DC TIE CONTROL UNIT & DC TIE RELAY
24-30-00-5B 24-30-00-5D	24-009-C3			OPERATIONAL	DC TIE CONTROL UNIT & DC TIE RELAY
24-30-00-5B 24-30-00-5D	24-009-C4			OPERATIONAL	DC TIE CONTROL UNIT & DC TIE RELAY
24-30-00-5B	24-009		G-24-009-C1 G-24-009-C4	OPERATIONAL	DC TIE RELAY
24-30-00-5C	24-011		G-24-007-C1 G-24-007-C4	OPERATIONAL	BATTERY CURRENT MONITOR
24-30-00-5D	24-012		G-24-009-C1 G-24-009-C4	OPERATIONAL	DC TIE CONTROL UNIT (DTCU)
24-31-01-4A		24-006-01		RESTORE	MAIN BATTERY
24-31-01-4A	24-006		G-24-006-02	RESTORE	MAIN BATTERY
24-31-01-4A		24-006-03		RESTORE	MAIN BATTERY
24-31-01-4A		24-006-05		RESTORE	MAIN BATTERY
24-31-01-4A		24-006-06		RESTORE	MAIN BATTERY
24-31-04-4A		24-008-01		RESTORE	APU BATTERY
24-31-04-4A	24-008		G-24-008-02	RESTORE	APU BATTERY
24-31-04-4A		24-008-03		RESTORE	APU BATTERY
24-31-04-4A		24-008-05		RESTORE	APU BATTERY
24-31-04-4A		24-008-06		RESTORE	APU BATTERY
24-31-05-4A		24-031-01		CLEAN	APU BATTERY CHARGER
24-31-05-4A			G-24-031-02	CLEAN	APU BATTERY CHARGER
24-31-05-4A		24-031-03		CLEAN	APU BATTERY CHARGER
24-31-05-4A		24-031-05		CLEAN	APU BATTERY CHARGER
24-31-05-4A		24-031-06		CLEAN	APU BATTERY CHARGER
24-33-00-6A		24-010-01		OPERATIONAL	STANDBY POWER SYSTEM
24-33-00-6A		24-010-03		OPERATIONAL	STANDBY POWER SYSTEM

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
24-33-00-6A		24-010-05	B-24-007-C3	OPERATIONAL	STANDBY POWER SYSTEM
24-33-00-6A			G-24-010-09	OPERATIONAL	STANDBY POWER SYSTEM
24-33-00-6A		24-010-12		OPERATIONAL	STANDBY POWER SYSTEM
24-33-00-6B		24-010-02		FUNCTIONAL	STANDBY POWER SYSTEM
24-33-00-6B		24-010-04	B-24-007-C1	FUNCTIONAL	STANDBY POWER SYSTEM
24-33-00-6B		24-010-06		FUNCTIONAL	STANDBY POWER SYSTEM
24-33-00-6B			G-24-010-11	FUNCTIONAL	STANDBY POWER SYSTEM
24-33-00-6B		24-010-14		FUNCTIONAL	STANDBY POWER SYSTEM
24-33-00-6C		24-010-06		OPERATIONAL	STANDBY POWER SYSTEM
24-33-00-6C		24-010-07	B-24-007-C1	OPERATIONAL	STANDBY POWER SYSTEM
24-33-00-6C		24-010-08		OPERATIONAL	STANDBY POWER SYSTEM
24-33-00-6C	24-010		G-24-010-10	OPERATIONAL	STANDBY POWER SYSTEM
24-33-00-6C		24-010-13		OPERATIONAL	STANDBY POWER SYSTEM
24-41-02-2B		24-041-03		CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
24-41-02-2B		24-041-07		CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
24-41-02-2B		24-041-08		CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
24-41-02-2B			G-24-041-10	CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
24-41-02-2B		24-041-12		CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
24-50-00-5A		24-014-01		OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
24-50-00-5A			G-24-014-02	OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
24-50-00-5A		24-014-55		OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
24-50-00-5A		24-014-58		OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
24-50-00-5A		24-014-60		OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
25-11-00-6A	25-002	25-002-01		OPERATIONAL	CREW SEAT HARNESS/INERTIA REEL
25-11-00-6B	25-001	25-001-01		OPERATIONAL	CREW SEAT ADJUSTMENT/LOCK MECHANISM
25-11-00-6C	25-044	25-044-01		OPERATIONAL	SUPERNUMERARY SEATS RESTRAINT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-46



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
25-21-01-A		56-BCY-90-1		CHECK/INSP	PASSENGER COMPARTMENT WINDOWS
25-25-00-A	25-003	25-003-01		OPERATIONAL	PASSENGER SEAT BELTS
25-25-01-A	25-004	25-004-01		CHECK/INSP	PASSENGER SEATS - FLOOR ATTACHMENT
25-25-03-6A	25-005	25-005-01		OPERATIONAL	ATTENDANT SEATS RESTRAINT
25-31-00-A		25-038-01		CLEAN	GALLEY OVEN
25-31-00-6A		25-034-01		CHECK/INSP	GALLEY WASTE ENCLOSURES
25-33-03-7A		25-032-01		CLEAN	GALLEY CHILLER CONDENSER AIR FILTERS
25-41-00-6A	25-006	25-006-01	W-26-014-01	CHECK/INSP	LAVATORY WASTE COMPARTMENT DOORS
25-41-00-6B		25-040-01		CHECK/INSP	LAVATORY FLOORS
25-41-00-6C		25-039-01		CHECK/INSP	LAVATORY LOWER EXTERIOR WALLS
25-52-00-6A		25-035-01		CHECK/INSP	CARGO COMPARTMENT LININGS
25-52-00-6A		25-035-02		CHECK/INSP	CARGO COMPARTMENT LININGS
25-53-00-A	25-009		P-06-008-01	CHECK/INSP	CARGO LATERAL RESTRAINT COMPONENTS
25-53-00-B	25-010		P-06-008-01	CHECK/INSP	CARGO LONGITUDINAL RESTRAINT COMPNTS
25-53-00-5A		25-BCY-90-1		OPERATIONAL	CONTAINERIZED HANDLING SYSTEM
25-53-00-5B		25-BCY-91-1		OPERATIONAL	CONTAINERIZED HANDLING SYSTEM
25-58-00-A	25-038		P-06-175-01	CHECK/INSP	M/D CARGO HANDLING & RESTRAINT SYS
25-59-00-A	25-037		P-06-182-01	CHECK/INSP	MAIN DECK CARGO LINING
25-61-01-2A	25-011	25-011-01	W-52-014-01	CHECK/INSP	OFF-WING EMERGENCY EXIT ASSIST STRAP
25-61-02-A	25-012	25-012-01		CHECK/INSP	FLIGHT COMPARTMENT ESCAPE ROPES
25-61-03-2A	25-041	25-041-01		REPLACE	EMERGENCY ESCAPE DESCENT DEVICES
25-61-03-2A			G-PARKED	REPLACE	EMERGENCY ESCAPE DESCENT DEVICES
25-62-00-A	25-013	25-013-01		CHECK/INSP	LIFE JACKETS (IF INSTALLED)
25-62-00-A	25-013	25-013-02		CHECK/INSP	LIFE JACKETS (IF INSTALLED)
25-62-00-B	25-014	25-014-01		RESTORE	LIFE RAFT (IF INSTALLED)
25-62-00-B	25-014	25-014-03		RESTORE	LIFE RAFT (IF INSTALLED)

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
25-62-00-C		25-014-02		CHECK/INSP	LIFE RAFT INFLATION BOTTLE
25-62-00-C		25-014-04		CHECK/INSP	LIFE RAFT INFLATION BOTTLE
25-63-00-B	25-016	25-016-01		FUNCTIONAL	EMERGENCY LOCATOR TRANSMITTER
25-63-00-B		25-016-02		FUNCTIONAL	EMERGENCY LOCATOR TRANSMITTER
25-63-01-2A	25-017	25-017-01		OPERATIONAL	EMERGENCY EVACUATION SIGNAL SYSTEM
25-63-02-2A		25-033-01		REPLACE	POWER MEGAPHONE BATTERIES
25-63-02-2C	25-015	25-015-01		OPERATIONAL	POWER MEGAPHONE
25-64-00-A	25-018	25-018-01		CHECK/INSP	DETACHABLE EMERGENCY EQUIPMENT
25-64-00-A	25-018	25-018-02		CHECK/INSP	DETACHABLE EMERGENCY EQUIPMENT
25-64-00-B	25-032	25-032-51		REPLACE	EMERGENCY ESCAPE BREATHING DEVICES
25-65-00-2A	25-043	25-043-03	W-26-015-01	OPERATIONAL	OFF-WING SLIDE BOTTLE SQUIBS
25-65-00-2A		25-043-04	W-26-015-01	OPERATIONAL	OFF-WING SLIDE BOTTLE SQUIBS
25-65-00-5A	25-031	25-031-01		OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-65-00-5A		25-031-03		OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-65-00-5A		25-031-04		OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-65-00-5A		25-031-05		OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-65-00-6A	25-019	25-019-01	W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-65-00-6A		25-019-02	W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-65-00-6A		25-019-03	W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-65-00-6A		25-019-04	W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-65-01-4A	25-020	25-020-01	W-12-001-01	RESTORE	OFF-WING EVACUATION RAMP/SLIDE PACK
25-65-02-2A	25-034	25-034-05		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-65-02-4A		25-034-02		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-65-02-4A		25-034-03		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-65-02-4A		25-034-04		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-65-02-4A		25-034-51		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-48



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
25-65-02-4B	25-042	25-042-01		REPLACE	OFF-WING SLIDE BOTTLE SQUIB
25-65-02-4B		25-042-02		REPLACE	OFF-WING SLIDE BOTTLE SQUIB
25-65-02-6A	25-021	25-021-01		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-65-02-6A		25-021-02		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-65-02-6A		25-021-03		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-65-02-6A		25-021-04		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-65-04-4A	25-022	25-022-01	A-25-023-01	OPERATIONAL	OFF-WING SLIDE ACTUATION CABLES
25-65-05-4A		25-020-02		RESTORE	OFF-WING EVACUATION RAMP/SLIDE PACK
25-65-07-6A	25-025	25-025-01	A-25-023-02	CHECK/INSP	OFF-WING COMPARTMENT DOOR INTEGRATOR
25-65-08-A		25-023-01	B-25-022-01	CHECK/INSP	OFF-WING COMPARTMENT DOOR/DOOR LATCH
25-65-08-A	25-023	25-023-01	B-25-022-01	CHECK/INSP	OFF-WING COMPARTMENT DOOR/DOOR LATCH
25-65-10-A	25-023	25-023-02	W-25-023-01	CHECK/INSP	OFF-WING COMP DOOR OPENING ACTUATORS
25-65-10-4A	25-024	25-024-01	W-25-023-02	REPLACE	OFF-WING COMP DOOR OPENING ACTUATORS
25-65-10-4B		25-036-01		CHECK/INSP	OFF-WING COMP DOOR OPENING ACTUATORS
25-65-11-A	25-023	25-023-03	W-25-023-01	CHECK/INSP	OFF-WING COMPT DOOR LATCH ACTUATOR
25-65-11-4A	25-024	25-024-02	W-25-023-03	REPLACE	OFF-WING COMPT DOOR LATCH ACTUATOR
25-65-17-4A	25-026	25-026-01		RESTORE	OFF-WING ESCAPE SYSTEM BATTERIES
25-65-19-4A	25-027	25-027-01-1		RESTORE	L OFF-WING SPOILER OVERRIDE ACTUATOR
25-65-19-4A	25-027	25-027-01-2		RESTORE	R OFF-WING SPOILER OVERRIDE ACTUATOR
25-65-20-4A		25-027-02-1		RESTORE	L OFF-WING SPOILER OVERRIDE ACTUATOR
25-65-20-4A		25-027-02-2		RESTORE	R OFF-WING SPOILER OVERRIDE ACTUATOR
25-66-00-5A		25-031-02		OPERATIONAL	ENTRY/SERVICE DOOR ESCAPE SLIDE SYS
25-66-00-5A		25-031-14		OPERATIONAL	ENTRY/SERVICE DOOR ESCAPE SLIDE SYS
25-66-00-5B		25-031-07		OPERATIONAL	EMER EXIT DOOR ESCAPE SLIDE SYSTEM
25-66-01-4A	25-029	25-029-01	W-25-029-03	RESTORE	ENTRY/SERVICE DOOR ESCAPE SLIDE
25-66-01-4B		25-035-51	W-25-029-01	CHECK/INSP	ENTRY/SERVICE DOOR ESC SLIDE BOTTLES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
25-66-02-6A	25-028	25-028-01		CHECK/INSP	ENTRY/SERVICE DOOR ESC SLIDE BOTTLES
25-66-03-A	25-030	25-030-01		CHECK/INSP	ENTRY/SERVICE DOOR SLIDE DEPLOY MECH
25-66-10-4A	25-029	25-029-02		RESTORE	EMER EXIT DOOR ESCAPE SLIDE
25-66-10-4B		25-033-61	W-25-029-02	CHECK/INSP	EMER EXIT DOOR ESCAPE SLIDE BOTTLE
25-66-10-6A	25-028	25-028-02		CHECK/INSP	EMER EXIT DOOR ESCAPE SLIDE BOTTLES
26-10-00-6A	26-015	26-015-51		OPERATIONAL	FIRE/OVERHEAT LOGIC/TEST SYSTEM
26-10-00-6A	26-015	26-015-54		OPERATIONAL	FIRE/OVERHEAT LOGIC/TEST SYSTEM
26-10-00-6B		26-020-01		OPERATIONAL	FIRE DETECTION SYSTEM FAIL LIGHT
26-10-00-6B		26-020-04		OPERATIONAL	FIRE DETECTION SYSTEM FAIL LIGHT
26-10-00-6B			G-26-20-04	OPERATIONAL	FIRE DETECTION SYSTEM FAIL LIGHT
26-13-00-5A		26-018-51		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A	26-018		G-26-018-52	OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-53		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-54		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-55		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-56		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-57		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-58		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-59		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-60		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-61		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-62		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-63		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-64		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-65		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-13-00-5A		26-018-66		OPERATIONAL	LAVATORY SMOKE DETECTORS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-50



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
26-13-00-5A		26-018-67		OPERATIONAL	LAVATORY SMOKE DETECTORS
26-14-00-A	26-025	26-025-01		CHECK/INSP	SMOKE DETECTOR SAMPLING ORIFICES
26-14-00-5C		26-026-C1		OPERATIONAL	VACUUM EJECTOR AND PRESSURE SWITCH
26-14-00-5C		26-026-C2		OPERATIONAL	VACUUM EJECTOR AND PRESSURE SWITCH
26-14-00-5C	26-026		G-26-026-C1	OPERATIONAL	SMOKE DETECTOR VACUUM EJECTOR
26-14-00-5D	26-028		G-26-026-C1	OPERATIONAL	VACUUM PRESSURE SWITCH
26-14-00-5E		26-027-C1		OPERATIONAL	MAIN DECK CARGO SMOKE DETECTION
26-14-00-5E		26-027-C2		OPERATIONAL	MAIN DECK CARGO SMOKE DETECTION
26-14-00-5E	26-027		G-26-027-C1	OPERATIONAL	SMOKE DETECTOR SAMPLING TUBE ORIFICE
26-14-00-5F	26-029		G-26-027-C1	OPERATIONAL	SMOKE DETECTOR SAMPLING TUBES
26-14-20-5A		26-022-01		OPERATIONAL	CREW REST AREA SMOKE DETECTOR
26-14-20-5A		26-022-04	W-26-022-05	OPERATIONAL	CREW REST AREA SMOKE DETECTOR
26-14-20-5B		26-022-03		OPERATIONAL	CREW REST AREA SMOKE DETECTOR
26-14-20-5B		26-022-05		OPERATIONAL	CREW REST AREA SMOKE DETECTOR
26-15-00-5A		26-022-02		OPERATIONAL	APU FIRE DETECTION GRND LOGIC SYSTEM
26-16-00-A		26-019-51		CHECK/INSP	CRGO SMOKE DET AIR SAMPLING ORIFICES
26-16-00-A	26-019		G-26-019-54	CHECK/INSP	CRGO SMOKE DET AIR SAMPLING ORIFICES
26-16-00-A		26-019-55		CHECK/INSP	CRGO SMOKE DET AIR SAMPLING ORIFICES
26-16-00-A		26-019-56		CHECK/INSP	CRGO SMOKE DET AIR SAMPLING ORIFICES
26-16-00-B	26-031	26-031-01		CHECK/INSP	SMOKE DETECTOR SAMPLING ORIFICES
26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D	26-001-C1			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D	26-001-C2			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D	26-001-C3			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D	26-001-C4			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D	26-001-C5			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-16-00-5A	26-001		G-26-001-C1 G-26-001-C2 G-26-001-C3 G-26-001-C4	OPERATIONAL	NO. 2 CARGO SMOKE DETECTOR BLOWER
26-16-00-5B	26-002		G-26-001-C1 G-26-001-C2 G-26-001-C3 G-26-001-C4	OPERATIONAL	CARGO SMOKE DETECTOR BLOWERS
26-16-00-5C	26-003		G-26-001-C1 G-26-001-C2 G-26-001-C3 G-26-001-C4	OPERATIONAL	CARGO SMOKE DET PLENUM PRESS SWITCH
26-16-00-5D	26-020		G-26-001-C1 G-26-001-C2 G-26-001-C3 G-26-001-C4	OPERATIONAL	CARGO SMOKE DET AIR SAMPLING TUBES
26-16-00-5E		26-030-C1		OPERATIONAL	LOWER LOBE CARGO SMOKE DETECTION
26-16-00-5E		26-030-C2		OPERATIONAL	LOWER LOBE CARGO SMOKE DETECTION
26-16-00-5E		26-030-C3		OPERATIONAL	LOWER LOBE CARGO SMOKE DETECTION
26-16-00-5E	26-030		G-26-030-C1	OPERATIONAL	SMOKE DETECTOR SAMPLING ORIFICES
26-16-00-5F	26-032		G-26-030-C1	OPERATIONAL	SMOKE DETECTOR SAMPLING TUBES
26-16-00-5G	26-034	26-034-01		OPERATIONAL	CARGO DETECTOR HEATERS/CONTROLLERS
26-16-00-5G		26-034-02		OPERATIONAL	CARGO DETECTOR HEATERS/CONTROLLERS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-52



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
26-16-00-7A		26-033-01		RESTORE	CLEAN CARGO SMOKE DET HEATER TUBES
26-16-05-2A		26-017-01		OPERATIONAL	CRGO SMOKE DET FAN ISOLATION FLAPPER
26-16-05-2A			G-26-017-04	OPERATIONAL	CRGO SMOKE DET FAN ISOLATION FLAPPER
26-16-05-2A		26-017-05		OPERATIONAL	CRGO SMOKE DET FAN ISOLATION FLAPPER
26-17-00-5A		26-021-01		OPERATIONAL	WHEEL WELL FIRE DETECTION SYSTEM
26-21-00-5A	26-006	26-006-01	W-26-012-XX	OPERATIONAL	ENG FIRE EXT BOTTLE PRESSURE SWITCH
26-21-00-5A	26-006	26-006-02-1		OPERATIONAL	ENG 1 FIRE EXT BOTTLE PRESS SWITCH
26-21-00-5A	26-006	26-006-02-2		OPERATIONAL	ENG 2 FIRE EXT BOTTLE PRESS SWITCH
26-21-01-6A	26-004	26-004-01		OPERATIONAL	ENGINE FIRE SWITCHES
26-21-01-6A	26-004	26-004-02		OPERATIONAL	ENGINE FIRE SWITCHES
26-21-03-4A	26-005	26-005-01		REPLACE	ENG FIRE EXT BOTTLE SQUIB CARTRIDGES
26-21-03-4A	26-005	26-005-02		REPLACE	ENG FIRE EXT BOTTLE SQUIB CARTRIDGES
26-21-03-4A	26-005	26-005-03-1		REPLACE	ENGINE 1 FIRE EXT BOTTLE SQUIB CART
26-21-03-4A	26-005	26-005-03-2		REPLACE	ENGINE 2 FIRE EXT BOTTLE SQUIB CART
26-21-03-4B		26-021-51		CHECK/INSP	ENGINE FIRE EXTINGUISHER BOTTLE
26-21-03-4B		26-021-52-1		CHECK/INSP	ENGINE 1 FIRE EXTINGUISHER BOTTLE
26-21-03-4B		26-021-52-2		CHECK/INSP	ENGINE 2 FIRE EXTINGUISHER BOTTLE
26-21-04-6A		26-015-01		OPERATIONAL	SQUIB TEST CONTROL PANEL
26-21-04-6A		26-015-03		OPERATIONAL	SQUIB TEST CONTROL PANEL
26-21-04-6A		26-015-04		OPERATIONAL	SQUIB TEST CONTROL PANEL
26-21-04-6B		26-015-02		OPERATIONAL	SQUIB TEST CONTROL PANEL
26-22-00-5A	26-009	26-009-01		OPERATIONAL	APU FIRE EXT BOTTLE PRESSURE SWITCH
26-22-00-5A		26-009-02		OPERATIONAL	APU FIRE EXT BOTTLE PRESSURE SWITCH
26-22-00-5A		26-009-03		OPERATIONAL	APU FIRE EXT BOTTLE PRESSURE SWITCH
26-22-01-6A	26-007	26-007-01		OPERATIONAL	APU FIRE SWITCH
26-22-01-6A		26-007-02		OPERATIONAL	APU FIRE SWITCH

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
26-22-01-6A		26-007-03		OPERATIONAL	APU FIRE SWITCH
26-22-02-4A	26-008	26-008-01		REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-22-02-4A	26-008	26-008-02		REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-22-02-4A		26-008-03		REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-22-02-4A		26-008-04		REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-22-02-4B		26-022-51		CHECK/INSP	APU FIRE EXTINGUISHER BOTTLE
26-22-02-4B		26-022-52		CHECK/INSP	APU FIRE EXTINGUISHER BOTTLE
26-22-02-4B		26-022-53		CHECK/INSP	APU FIRE EXTINGUISHER BOTTLE
26-23-00-5A		26-012-01	W-26-006-01	OPERATIONAL	CARGO FIRE EXT BTL PRESSURE SWITCHES
26-23-00-5A	26-012		G-26-012-04	OPERATIONAL	CARGO FIRE EXT BTL PRESSURE SWITCHES
26-23-00-5A		26-012-05	W-26-006-01	OPERATIONAL	CARGO FIRE EXT BTL PRESSURE SWITCHES
26-23-00-5B		26-017-55		FUNCTIONAL	CARGO FIRE EXT DISCHARGE SYSTEM
26-23-00-5B	26-017		G-26-017-58	FUNCTIONAL	CARGO FIRE EXT DISCHARGE SYSTEM
26-23-00-5B		26-017-59		FUNCTIONAL	CARGO FIRE EXT DISCHARGE SYSTEM
26-23-01-6A		26-010-01		OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-23-01-6A	26-010		G-26-010-04	OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-23-01-6A		26-010-05		OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-23-01-6A		26-010-06		OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-23-01-6A		26-010-07		OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-23-02-4A	26-011	26-011-01		REPLACE	CARGO FIRE EXT BOTTLE (KIDDE) SQUIB
26-23-02-4A		26-011-02		REPLACE	CARGO FIRE EXT BOTTLE (HTL) SQUIB
26-23-02-4A	26-011		G-26-011-05	REPLACE	CARGO FIRE EXT BOTTLE (HTL) SQUIB
26-23-02-4A		26-011-06		REPLACE	CARGO FIRE EXT BOTTLE (HTL) SQUIB
26-23-02-4B		26-023-51		CHECK/INSP	CARGO FIRE EXTINGUISHER BOTTLE
26-23-02-4B			G-26-023-54	CHECK/INSP	CARGO FIRE EXTINGUISHER BOTTLE
26-23-02-4B		26-023-55		CHECK/INSP	CARGO FIRE EXTINGUISHER BOTTLE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-54



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
26-23-03-6A	26-016	26-016-51		OPERATIONAL	CARGO FIRE EXT BOTTLE RELAYS
26-23-06-4A	26-035	26-035-01		REPLACE	FLOW VALVE SQUIB CARTRIDGES
26-24-01-2A	26-014	26-014-01	W-25-006-01	CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-24-01-2A		26-014-02	W-25-006-01	CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-24-01-2B		26-014-51		CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-24-01-2B		26-014-52		CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-26-02-6A	26-013	26-013-01		CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-26-02-6A		26-013-04		CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-26-02-6A		26-013-12		CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-26-02-6A		26-013-13		CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-26-02-6B		26-013-08		CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-26-02-6B		26-024-01		CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-26-03-6A	26-013	26-013-02		CHECK/INSP	PORTABLE WATER FIRE EXTINGUISHERS
26-26-03-6A		26-013-06		CHECK/INSP	PORTABLE WATER FIRE EXTINGUISHERS
26-26-03-6B		26-013-09		CHECK/INSP	PORTABLE WATER FIRE EXTINGUISHERS
27-00-00-A		27-052-01		CHECK/INSP	WING FLIGHT CONTROL SURFACES
27-02-00-6A	27-073	27-073-01		FUNCTIONAL	ELEVATOR SURFACE FREEPLAY
27-02-00-6B	27-076	27-076-01		FUNCTIONAL	RUDDER SURFACE FREEPLAY
27-11-00-A	27-002		P-06-003-01	CHECK/INSP	AILERON MECHANICAL CONTROL PATH
27-11-00-B	27-006		P-06-017-01	CHECK/INSP	AILERON CONTROL OVERRIDE MECHANISM
27-11-00-C	27-005		P-06-016-01	CHECK/INSP	FEEL, CENTERING AND TRIM MECHANISM
27-11-00-D	27-004		P-06-003-01	CHECK/INSP	AILERON CONTROL INPUT CONNECTIONS
27-11-00-E		27-064-01-1		CHECK/INSP	L WING-LATERAL CNTRL SYSTEM BEARINGS
27-11-00-E		27-064-01-2		CHECK/INSP	R WING-LATERAL CNTRL SYSTEM BEARINGS
27-11-00-5A	27-003	27-003-01	W-27-010-01	OPERATIONAL	AILERON POWER CONTROL ACTUATOR
27-11-36-4A	27-007	27-007-01		OPERATIONAL	DUAL AILERON CONTROL OVERRIDE SYSTEM

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
27-21-00-A	27-011		P-06-056-01	CHECK/INSP	YAW DAMPER, RUDDER RATIO CHANGER
27-21-00-B	27-014		P-06-056-01	CHECK/INSP	RUDDER RATIO CHANGER BUS ROD
27-21-00-C	27-008		P-06-056-01	CHECK/INSP	RUDDER FEEL, CENTERING AND TRIM MECH
27-21-00-D	27-009		P-06-003-01	CHECK/INSP	RUDDER MECHANICAL CONTROL PATH
27-21-00-E	27-012		P-06-056-01	CHECK/INSP	RUDDER TRIM ACTUATOR
27-21-00-F	27-013		P-06-056-01	CHECK/INSP	RUDDER RATIO CHANGER
27-21-00-G	22-006		P-06-056-01	CHECK/INSP	YAW DAMPER BIAS POGO LINKAGE
27-21-00-H	22-005		P-06-056-01	CHECK/INSP	YAW DAMPER - MECHANICAL LINKAGE
27-21-00-5A	27-010	27-010-01	W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-21-00-5A		27-010-02	W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-21-00-5A		27-010-03	W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-21-00-5A		27-010-04	W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-21-00-5A		27-010-52	W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-21-00-5B		27-015-01	W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-21-00-5B		27-015-04	W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-21-00-5B	27-015		G-27-015-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-21-00-5B		27-015-06	W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-21-00-5B		27-015-07	W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-21-00-5B		27-015-56	W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-21-00-5C	27-058	27-058-52		OPERATIONAL	RUDDER PEDAL POGO RODS
27-21-23-2A		27-058-01		CLEAN	RUDDER TRIM KNOB
27-23-51-2A	27-060	27-060-01	W-27-059-01	FUNCTIONAL	RUDDER HYDRAULIC RATE FUSES
27-31-00-A	27-020		P-06-047-01	CHECK/INSP	ELEVATOR NEUTRAL SHIFT MECHANISM
27-31-00-B	27-019		P-06-047-01	CHECK/INSP	ELEVATOR FEEL & CENTERING MECHANISM
27-31-00-C	27-016		P-06-003-01	CHECK/INSP	ELEVATOR MECHANICAL CONTROL PATH
27-31-00-5A	27-017	27-017-01		OPERATIONAL	ELEVATOR DUAL CONTROL PATH OVERRIDE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
27-31-00-5B	27-018	27-018-01	W-27-010-01	OPERATIONAL	ELEVATOR POWER CONTROL ACTUATOR
27-31-00-5C	27-021	27-021-01		OPERATIONAL	ELEVATOR NEUTRAL SHIFT MECHANISM
27-31-00-5D	27-079	27-079-01		FUNCTIONAL	ELEVATOR PCA MIS-RIG
27-31-07-4A	27-078	27-078-01		FUNCTIONAL	ELEVATOR PCA INPUT CONTROL ROD
27-31-20-4A	27-057	27-057-51		OPERATIONAL	ELEVATOR FEEL SHIFT
27-31-68-2A	27-059	27-059-01	W-27-060-01	FUNCTIONAL	ELEVATOR HYDRAULIC RATE FUSES
27-32-00-5A	27-022	27-022-01		OPERATIONAL	STALL WARNING SYSTEM
27-32-00-5A		27-022-02		OPERATIONAL	STALL WARNING SYSTEM
27-32-00-5A		27-022-03		OPERATIONAL	STALL WARNING SYSTEM
27-32-00-5A		27-022-04		OPERATIONAL	STALL WARNING SYSTEM
27-32-00-5A	27-070	27-070-01		OPERATIONAL	STALL WARNING SYSTEM AND TAI
27-41-00-5A	27-023	27-023-01		OPERATIONAL	MANUAL-MECH HORZ STAB TRIM CONTROL
27-41-00-5B	27-024	27-024-01		FUNCTIONAL	STABILIZER TRIM POSITION TRANSMITTER
27-41-00-5C	27-025	27-025-01		OPERATIONAL	STAB TRIM CNTRL COL CUTOFF SWITCHES
27-41-00-5D	27-026	27-026-01		OPERATIONAL	STAB TRIM CUTOUT (PEDESTAL) SWITCHES
27-41-00-5E	29-024	29-024-01		FUNCTIONAL	STABILIZER TRIM RATE RELIEF VALVE
27-41-00-5F	27-052	27-052-51		OPERATIONAL	ALTERNATE HORIZ STAB TRIM SYSTEM
27-41-00-5G	27-054	27-054-51		OPERATIONAL	STABILIZER TRIM SECONDARY BRAKES
27-41-00-5H	27-055	27-055-51		OPERATIONAL	STAB TRIM OVERRIDE WITH SPLIT COLUMN
27-41-10-B	27-028	27-028-01		CHECK/INSP	STAB TRIM ACTUATOR ATTACHMENT GIMBAL
27-41-10-6A	27-077	27-077-01		FUNCTIONAL	STAB TRIM BALLSCREW AND BALLNUTS
27-41-10-6B	27-030	27-030-01		CHECK/INSP	STAB TRIM ACTUATOR BALLSCREW/NUT
27-51-00-A	27-032		P-06-011-01	CHECK/INSP	FLAP/SLAT MECHANICAL CONTROL PATH
27-51-00-B	27-040		P-06-016-01	CHECK/INSP	TE FLAP DRIVE SYSTEM COMPONENTS
27-51-00-5A	27-036	27-036-01		OPERATIONAL	ALT TE FLAP POWER DRIVE SYSTEM
27-51-00-5A	27-036	27-036-51		OPERATIONAL	ALT TE FLAP POWER DRIVE SYSTEM

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
27-51-00-5B	27-037	27-037-01		OPERATIONAL	TE FLAP FAILURE PROTECTION SYSTEM
27-51-00-5C	27-042	27-042-01		OPERATIONAL	TE FLAP ASYMMETRY PROTECTION SYSTEM
27-51-00-5D	27-033	27-033-01		OPERATIONAL	FLAP/SLAT ELECTRONICS UNIT (FSEU)
27-51-00-5F	27-053	27-053-51		FUNCTIONAL	TE FLAP LOAD ALLEVIATION SYSTEM
27-51-00-5G	27-064	27-064-51		OPERATIONAL	TE FLAP LOAD RELIEF ACTUATOR/RELAY
27-51-00-5H	27-065	27-065-51		FUNCTIONAL	TE FLAP LOAD RELIEF SYSTEM
27-51-00-5I	27-066	27-066-01-1		FUNCTIONAL	TE FLAP DRIVE NO-BACK BRAKES
27-51-00-5I	27-066	27-066-01-2		FUNCTIONAL	TE FLAP DRIVE NO-BACK BRAKES
27-51-30-A	27-035		P-06-017-01	CHECK/INSP	TE FLAP LOAD ALLEVIATION MECHANISM
27-51-30-B	27-034		P-06-017-01	CHECK/INSP	TE FLAP LOAD ALLEVIATION INPUT CONN
27-51-41-A	27-041		P-06-121-01	CHECK/INSP	TE FLAP DRIVE SHAFT SAFETY STRAPS
27-51-48-2A		27-054-01	W-27-046-01	OPERATIONAL	TE FLAP/LE SLAT SHUTOFF VALVE MODULE
27-51-48-2A	27-054		G-27-054-01	OPERATIONAL	TE FLAP/LE SLAT SHUTOFF VALVE MODULE
27-51-48-2A			G-27-054-01	OPERATIONAL	TE FLAP/LE SLAT SHUTOFF VALVE MODULE
27-62-00-5A	27-045	27-045-01		OPERATIONAL	AUTO SPEEDBRAKE
27-81-00-2A		27-063-01-1		CHECK/INSP	LE AND KRUEGER FLAP ROTARY ACTUATORS
27-81-00-2A		27-063-01-2		CHECK/INSP	LE AND KRUEGER FLAP ROTARY ACTUATORS
27-81-00-5A	27-043	27-043-01		OPERATIONAL	LE SLAT FAILURE PROTECTION SYSTEM
27-81-00-5A	27-043	27-043-51		OPERATIONAL	LE SLAT FAILURE PROTECTION SYSTEM
27-81-00-5B	27-044	27-044-01	A-27-043-01	OPERATIONAL	LE SLAT ASYMMETRY PROTECTION SYSTEM
27-81-00-5C	27-047	27-047-01	B-27-043-01	OPERATIONAL	LE SLAT ALTERNATE DRIVE SYSTEM
27-81-00-6A	27-046		G-27-054-01	OPERATIONAL	TE FLAP/LE SLAT INHIBIT SYSTEM
27-81-20-2B	27-069	27-069-01-1		FUNCTIONAL	LE SLAT DRIVE NOBACK BRAKES
27-81-20-2B	27-069	27-069-01-2		FUNCTIONAL	LE SLAT DRIVE NOBACK BRAKES
27-81-20-2C		27-055-01-1		FUNCTIONAL	LE SLAT RETRACT/EXTEND STOP GAPS -L
27-81-20-2C		27-055-01-2		FUNCTIONAL	LE SLAT RETRACT/EXTEND STOP GAPS -R

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-58



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
27-81-24-A	27-049		P-06-011-01	CHECK/INSP	LE SLAT DRIVE SYSTEM COMPONENTS
27-81-24-B	27-051		P-06-099-01	CHECK/INSP	LE SLAT DRIVE SHAFT SAFETY STRAPS
27-81-42-4A	27-061	27-061-01		OPERATIONAL	LE SLAT SKEW DETECTION SYSTEM
27-81-42-4B	27-062	27-062-02		CHECK/INSP	LE SLAT SKEW DETECTION SYSTEM
28-00-00-2A	28-020	28-020-02		CHECK/INSP	IN-TANK TUBING - LEFT MAIN FUEL TANK
28-00-00-2B	28-020	28-020-03		CHECK/INSP	IN-TANK TUBING - RT MAIN FUEL TANK
28-00-00-2C	28-020	28-020-04		CHECK/INSP	IN-TANK TUBING - CTR AUX FUEL TANK
28-11-00-A	28-001		P-06-115-01	CHECK/INSP	BAFFLE FLAPPER CHECK VALVES
28-11-04-6A	28-018	28-018-03		FUNCTIONAL	OVERWING FILL PORT - L/H WING
28-11-04-6A	28-018	28-018-04		FUNCTIONAL	OVERWING FILL PORT - R/H WING
28-13-00-A	28-003		P-06-114-01	CHECK/INSP	FUEL VENT FLOAT DRAIN VALVES
28-13-00-B	28-002		P-06-114-01	CHECK/INSP	FUEL VENT FLOAT VALVES
28-13-04-2A		28-010-01-1		FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE - L
28-13-04-2A		28-010-01-2		FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE - R
28-13-04-2B	28-004	28-004-01-1		OPERATIONAL	SURGE TANK PRESSURE RELIEF VALVE - L
28-13-04-2B	28-004	28-004-01-2		OPERATIONAL	SURGE TANK PRESSURE RELIEF VALVE - R
28-13-04-6A	28-021	28-021-03		FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE-L
28-13-04-6A	28-021	28-021-04		FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE-R
28-21-01-6A	28-023	28-023-01		FUNCTIONAL	FUELING ADAPTER L/H WING
28-21-01-6A	28-024	28-024-01		FUNCTIONAL	FUELING ADAPTER R/H WING
28-21-12-6A	28-022	28-022-01		FUNCTIONAL	FUELING SHUTOFF VALVES L/H WING
28-21-12-6A	28-022	28-022-02		FUNCTIONAL	FUELING SHUTOFF VALVES R/H WING
28-22-00-D		28-017-01-1		CHECK/INSP	LEFT BOOST, OVERRIDE/JTSN PUMPS
28-22-00-D		28-017-01-1		CHECK/INSP	LEFT BOOST, OVERRIDE/JTSN PUMPS
28-22-00-D		28-017-01-2		CHECK/INSP	RIGHT BOOST, OVERRIDE/JTSN PUMPS
28-22-00-D		28-017-01-2		CHECK/INSP	RIGHT BOOST, OVERRIDE/JTSN PUMPS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
28-22-00-5B		28-009-01		OPERATIONAL	FUEL CROSSFEED VALVE
28-22-00-5C	28-010	28-010-51		OPERATIONAL	CENTER AUX TANK FUEL SCAVENGE SYSTEM
28-22-00-5D	28-011	28-011-51		OPERATIONAL	CTR AUX TANK SCAVENGE SHUTOFF VALVE
28-22-00-5E	28-012	28-012-01		OPERATIONAL	ENG FUEL SPAR SHUTOFF VALVE BATTERY
28-22-00-5F	28-AWL	28-AWL-20-1		FUNCTIONAL	CTR AUX TANK FUEL PUMP AUTO SHUTOFF
28-22-00-5G	28-018	28-018-02		OPERATIONAL	ENGINE FUEL SUCTION FEED SYSTEM
28-22-00-5H	28-AWL	28-AWL-27-1		OPERATIONAL	BOOST/OVERRIDE-JETTISON PUMP GFI
28-22-00-5H	28-AWL	28-AWL-28-1		FUNCTIONAL	CENTER TANK FUEL PUMP UNCOMMANDED-ON
28-22-03-6A	28-026	28-026-01		FUNCTIONAL	FUEL BOOST PUMP MOTOR HOUSING BOND
28-22-03-6A	28-026	28-026-02		FUNCTIONAL	FUEL BOOST PUMP MOTOR HOUSING BOND
28-22-05-6A	28-026	28-026-03		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-22-05-6A	28-026	28-026-04		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-22-05-6A		28-026-05		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-22-05-6A		28-026-06		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-22-05-6A		28-026-07		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-22-05-6A		28-026-08		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-22-05-6A		28-026-09		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-22-05-6A		28-026-10		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-22-07-4A		28-017-01		RESTORE	REPLACE STRUT COUPLING O-RINGS
28-22-07-4A		28-018-01		RESTORE	REPLACE STRUT COUPLING O-RINGS
28-22-07-4A		28-019-01		RESTORE	REPLACE STRUT COUPLING O-RINGS
28-22-07-4A		28-020-01		RESTORE	REPLACE STRUT COUPLING O-RINGS
28-22-07-4A		28-021-01		RESTORE	REPLACE STRUT COUPLING O-RINGS
28-22-08-7A	28-005	28-005-01-1		CLEAN	AUTO SUMPING MOTIVE FLOW SCREENS - L
28-22-08-7A	28-005	28-005-01-2		CLEAN	AUTO SUMPING MOTIVE FLOW SCREENS - R
28-22-11-6A	28-027	28-027-01		FUNCTIONAL	FUEL SHUTOFF VALVE BOND

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-60



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
28-22-11-6A	28-027	28-027-02		FUNCTIONAL	FUEL SHUTOFF VALVE BOND
28-22-12-6A	28-028	28-028-01		FUNCTIONAL	FUEL CROSSFEED VALVE BOND
28-22-15-6A	28-025	28-025-01		CHECK/INSP	LEFT MAIN TANK FUEL BOOST PUMPS
28-22-15-6A	28-025	28-025-02		CHECK/INSP	RIGHT MAIN TANK FUEL BOOST PUMPS
28-22-15-6A	28-025	28-025-03		CHECK/INSP	OVERRIDE/JETTISON FUEL PUMP WIRING
28-22-15-6A	28-025	28-025-04		CHECK/INSP	OVERRIDE/JETTISON FUEL PUMP WIRING
28-22-16-4A	28-014	28-014-01		RESTORE	ENG FUEL SPAR SHUTOFF VALVE BATTERY
28-25-00-5A	28-006	28-006-01		FUNCTIONAL	APU FUEL SUPPLY LINE SHROUD
28-25-01-6A	28-029	28-029-01		FUNCTIONAL	APU DC FUEL PUMP MOTOR HOUSING BOND
28-25-02-6A	28-030	28-030-01		FUNCTIONAL	APU FUEL SHUTOFF VALVE BOND
28-25-04-6A	28-031	28-031-01		FUNCTIONAL	APU FUEL ISOLATION VALVE BOND
28-26-11-6A	28-032	28-032-01		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND
28-26-11-6A	28-032	28-032-02		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND
28-26-11-6A	28-032	28-032-03		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND
28-31-00-5A	28-013	28-013-01		OPERATIONAL	FUEL JETTISON SYSTEM
28-31-00-5A	28-015	28-015-01		OPERATIONAL	FUEL JETTISON SYSTEM - LOW CAPACITY
28-31-00-5A	28-016	28-016-01		OPERATIONAL	FUEL JETTISON SYSTEM - FULL CAPACITY
28-31-04-6A	28-034	28-034-01		FUNCTIONAL	JETTISON TRANSFER VALVE BOND
28-31-04-6A	28-034	28-034-02		FUNCTIONAL	JETTISON TRANSFER VALVE BOND
28-31-05-6A	28-033	28-033-01		FUNCTIONAL	JETTISON NOZZLE VALVE BOND
28-31-05-6A	28-033	28-033-02		FUNCTIONAL	JETTISON NOZZLE VALVE BOND
28-41-09-6A	28-035	28-035-01		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-41-09-6A	28-035	28-035-02		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-41-09-6A	28-035	28-035-03		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-41-09-6A	28-035	28-035-04		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-41-09-6A	28-036	28-036-01		CHECK/INSP	FQIS IN-TANK COMPONENTS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
28-41-09-6A	28-036	28-036-02		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-41-09-6A	28-036	28-036-03		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-41-09-6A	28-036	28-036-04		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-41-24-2A	28-037	28-037-01		CHECK/INSP	DENSITOMETER HSP CHECK/INSPECTION
28-41-24-6A	28-038	28-038-01		FUNCTIONAL	DENSITOMETER HSP BOND CHECK
29-11-00-A	29-012		P-06-005-01	CHECK/INSP	HYDRAULIC SYSTEM - FLUID LEAKS
29-11-00-5A	29-010	29-010-01		OPERATIONAL	ADP SPEED TOPPING SHUTDOWN CIRCUITRY
29-11-00-6A 29-11-00-6E	29-001-C1-1			CHECK/INSP	SYS L EDP/ACMP PRESS & RETURN FILTER
29-11-00-6A 29-11-00-6E	29-001-C1-2			CHECK/INSP	SYS R EDP/ACMP PRESS & RETURN FILTER
29-11-00-6A	29-001		G-29-001-C1-1	CHECK/INSP	SYS L HYD EDP & ACMP PRESS FILTERS
29-11-00-6A	29-001		G-29-001-C1-2	CHECK/INSP	SYS R HYD EDP & ACMP PRESS FILTERS
29-11-00-6B	29-004	29-004-01-1	W-29-001-C1-1	CHECK/INSP	SYS L HYD EDP/ACMP CASE DRAIN FILTER
29-11-00-6B	29-004	29-004-01-2	W-29-001-C1-2	CHECK/INSP	SYS R HYD EDP/ACMP CASE DRAIN FILTER
29-11-00-6C 29-11-00-6E	29-006-C1			CHECK/INSP	SYS C ACMP/ADP PRESS & RETURN FILTER
29-11-00-6C	29-006		G-29-006-C1	CHECK/INSP	SYS C HYD ACMP & ADP PRESS FILTERS
29-11-00-6D	29-009	29-009-01	W-29-005-01	CHECK/INSP	SYS C HYD ACMP/ADP CASE DRAIN FILTER
29-11-00-6E	29-011		G-29-001-C1-1	CHECK/INSP	SYS L HYD RETURN FILTER MODULE
29-11-00-6E	29-011		G-29-001-C1-2	CHECK/INSP	SYS R HYD RETURN FILTER MODULE
29-11-00-6E	29-011		G-29-006-C1	CHECK/INSP	SYS C HYD RETURN FILTER MODULE
29-11-00-6F	29-003	29-003-01		FUNCTIONAL	HYDRAULIC SYSTEMS (INTERNAL LEAKAGE)
29-11-00-6G	29-003	29-003-02		FUNCTIONAL	ELEVATOR AND RUDDER PCA'S
29-11-07-4A	29-013	29-013-01		OPERATIONAL	ISOLATED ACMP SUPPLY SHUTOFF VALVE
29-11-08-4A	29-013	29-013-02		OPERATIONAL	ISOLATED ACMP PRESSURE SHUTOFF VALVE
29-11-25-4A	29-002	29-002-01-1		CLEAN	SYS L HYD RESERVOIR PRESS AIR FILTER

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-62



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
29-11-25-4A	29-002	29-002-01-2		CLEAN	SYS R HYD RESERVOIR PRESS AIR FILTER
29-11-26-4A	29-007	29-007-01		CLEAN	SYS C HYD RESERVOIR PRESS AIR FILTER
29-11-27-6A	28-AWL	28-AWL-05-1		FUNCTIONAL	HYDRAULIC LINE FUEL TANK PENETRATION
29-11-27-6A	28-AWL	28-AWL-05-2		FUNCTIONAL	HYDRAULIC LINE FUEL TANK PENETRATION
29-11-28-5A	29-028	29-028-01		OPERATIONAL	SYST. C RESERVOIR PRESS. S-O VALVE
29-11-31-4A	29-027	29-027-02		REPLACE	SYS C HYDRAULIC ADP GEARBOX FILTER
29-21-00-5A	29-015	29-015-01	B-29-018-01	OPERATIONAL	AUTO & MANUAL RAT DEPLOYMENT SYSTEMS
29-21-11-4A	29-018	29-018-01	A-29-015-01	CHECK/INSP	RAT CHECKOUT MODULE FILTERS
29-21-19-4A		29-020-01		DISCARD	RAM AIR TURBINE ISOLATION CHK VALVE
29-22-00-5A	29-021	29-021-01		OPERATIONAL	POWER TRANSFER UNIT (PTU) SYSTEM
29-22-00-5B	29-022	29-022-01		FUNCTIONAL	PTU SYSTEM RETURN COMPENSATOR MODULE
29-22-03-4A	29-023	29-023-01		CHECK/INSP	PTU CASE DRAIN FILTER
29-33-00-5A		29-019-01		OPERATIONAL	HYDRAULIC RESERVOIR QUANTITY - L,R,C
29-33-00-5A		29-019-02		OPERATIONAL	HYDRAULIC RESERVOIR QUANTITY - L,R,C
30-11-03-4A	30-001	30-001-01-1	W-30-002-01-1	FUNCTIONAL	LEFT WING TAI TEMPERATURE SWITCH
30-11-03-4A	30-001	30-001-01-2	W-30-002-01-2	FUNCTIONAL	RIGHT WING TAI TEMPERATURE SWITCH
30-11-04-4A	30-002	30-002-01-1	W-30-001-01-1	FUNCTIONAL	LEFT WING TAI PRESSURE SWITCH
30-11-04-4A	30-002	30-002-01-2	W-30-001-01-2	FUNCTIONAL	RIGHT WING TAI PRESSURE SWITCH
30-21-00-A	30-004		P-06-077-01	CHECK/INSP	ENGINE INLET TAI DUCTING
30-21-00-A	30-004		P-06-092-01	CHECK/INSP	ENGINE INLET TAI DUCTING
30-21-00-A	30-004		P-06-148-01	CHECK/INSP	ENGINE INLET TAI DUCTING
30-21-00-A	30-004		P-06-160-01	CHECK/INSP	ENGINE INLET TAI DUCTING
30-21-00-5A	30-003	30-003-01-1		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-21-00-5A	30-003	30-003-01-2		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-21-00-5A	30-003	30-003-02-1		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-21-00-5A	30-003	30-003-02-2		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
30-21-00-5A	30-003	30-003-03-1		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-21-00-5A	30-003	30-003-03-2		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-21-00-5A	30-003	30-003-05-1		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-21-00-5A	30-003	30-003-05-2		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-21-05-4A	30-003	30-003-04-1		FUNCTIONAL	ENGINE 1 TAI PNEUMATIC RELIEF VALVE
30-21-05-4A	30-003	30-003-04-2		FUNCTIONAL	ENGINE 2 TAI PNEUMATIC RELIEF VALVE
30-31-00-A	30-005		G-33-004-C1 G-33-004-C2 G-33-004-C3 G-33-004-C4	OPERATIONAL	PITOT STATIC PROBE HEAT ANNUNCIATOR
30-81-00-5A		30-007-01		OPERATIONAL	PRIMARY ICE DETECTION SYSTEM
31-31-01-2A		31-001-01		OPERATIONAL	FLIGHT DATA RECORDER PARAMETERS
31-31-01-2A	31-001		G-31-001-07	OPERATIONAL	FLIGHT DATA RECORDER PARAMETERS
31-31-01-4A		31-001-06	W-31-001-01	OPERATIONAL	FLIGHT DATA RECORDER PARAMETERS
31-31-02-2B	31-002	31-002-02		RESTORE	DIGITAL FLIGHT DATA RECORDER ULB
31-31-02-2C	31-002	31-002-03		OPERATIONAL	FLIGHT DATA RECORDER ULB
31-41-00-2A	31-007	31-007-01		OPERATIONAL	EICAS MAINTENANCE MESSAGES
31-41-01-4A		31-009-01		CLEAN/INSP	EICAS DISPLAY UNIT AIR INLET SCREEN
31-41-02-4A	31-008	31-008-01		OPERATIONAL	RIGHT EICAS COMPUTER
31-51-00-5A	31-003		G-33-004-C1 G-33-004-C2 G-33-004-C3 G-33-004-C4	OPERATIONAL	MASTER CAUTION/WARNING LIGHTS
31-51-00-5B		27-031-02		OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-51-00-5B		27-031-03		OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-51-00-5B			G-31-51-00-5B	OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-51-00-5B		31-051-01		OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-51-00-5B		31-051-02		OPERATIONAL	TAKE-OFF WARNING SYSTEM

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-64



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
31-51-00-5B		31-051-03		OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-51-00-5C		31-052-01		OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-51-04-4A	31-004	31-004-01		OPERATIONAL	WARNING ELECTRONICS UNIT CARD MODULE
31-63-00-2A	31-050	31-050-01		OPERATIONAL	EICAS MAINTENANCE MESSAGES
32-11-01-A	32-044	32-044-51		RESTORE	MAIN LANDING GEAR (LEFT OR RIGHT)
32-11-01-C		32-049-01-1		CHECK/INSP	LEFT MLG AFT TRUNNION INSPECTION
32-11-01-C		32-049-01-2		CHECK/INSP	RIGHT MLG AFT TRUNNION INSPECTION
32-11-01-4A		32-045-01-1		REPLACE	LEFT MAIN LANDING GEAR
32-11-01-4A		32-045-01-2		REPLACE	RIGHT MAIN LANDING GEAR
32-11-01-4A		32-045-02-1		REPLACE	LEFT MAIN LANDING GEAR
32-11-01-4A		32-045-02-2		REPLACE	RIGHT MAIN LANDING GEAR
32-11-01-4A		32-045-03-1		REPLACE	LEFT MAIN LANDING GEAR
32-11-01-4A		32-045-03-2		REPLACE	RIGHT MAIN LANDING GEAR
32-11-01-4A		32-045-04-1		REPLACE	LEFT MAIN LANDING GEAR
32-11-01-4A		32-045-04-2		REPLACE	RIGHT MAIN LANDING GEAR
32-11-01-4A		32-045-05-1		REPLACE	LEFT MAIN LANDING GEAR
32-11-01-4A		32-045-05-2		REPLACE	RIGHT MAIN LANDING GEAR
32-11-01-4A		32-045-06-1		REPLACE	LEFT MAIN LANDING GEAR
32-11-01-4A		32-045-06-2		REPLACE	RIGHT MAIN LANDING GEAR
32-11-20-A		32-046-05-1	W-32-046-06-1	RESTORE	BRAKE ROD BOLT
32-11-20-A		32-046-05-2	W-32-046-06-2	RESTORE	BRAKE ROD BOLT
32-11-20-B		32-046-06-1	W-32-046-05-1	CHECK/INSP	BRAKE ROD BOLT BUSHINGS
32-11-20-B		32-046-06-2	W-32-046-05-2	CHECK/INSP	BRAKE ROD BOLT BUSHINGS
32-12-01-A	32-014		P-06-016-01	CHECK/INSP	MAIN LANDING GEAR DOOR AND HINGES
32-21-01-A	32-043	32-043-01		RESTORE	NOSE LANDING GEAR
32-21-01-4A	32-044	32-044-01		REPLACE	NOSE LANDING GEAR

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
32-21-09-A	32-003		P-06-004-01	CHECK/INSP	NOSE GEAR LOCK SPRINGS
32-22-02-A	32-020		P-06-004-01	CHECK/INSP	NOSE GEAR DOOR OPERATING MECHANISM
32-31-00-A	32-004		P-06-016-01	CHECK/INSP	MAIN/NOSE GEAR MECH CONTROL PATH
32-31-00-5A		32-047-51		OPERATIONAL	LANDING GEAR CONTROL ELEC CIRCUITS
32-31-00-5A	32-047	32-047-52		OPERATIONAL	LANDING GEAR CONTROL ELEC CIRCUITS
32-32-01-A	32-008		P-06-120-01	CHECK/INSP	MAIN LANDING GEAR RETRACT ACTUATOR
32-32-02-A	32-010		P-06-131-01	CHECK/INSP	MAIN GEAR SIDE BRACE LOCK ACTUATOR
32-32-02-B	32-012		P-06-131-01	CHECK/INSP	MAIN GEAR DRAG BRACE LOCK ACTUATOR
32-32-03-A	32-002		P-06-131-01	CHECK/INSP	MAIN GEAR SIDE BRACE LOCK SPRINGS
32-32-05-A	32-002		P-06-131-01	CHECK/INSP	MAIN GEAR JURY STRUT SPRINGS
32-32-06-A	32-014		P-06-016-01	CHECK/INSP	MLG-DOOR OPERATED SEQUENCE VALVE
32-32-09-A	32-014		P-06-016-01	CHECK/INSP	MLG-GEAR OPERATED SEQUENCE VALVE
32-32-12-A	32-014		P-06-016-01	CHECK/INSP	MAIN GEAR DOOR ACTUATOR & LINKAGE
32-32-13-A	32-015		P-06-016-01	CHECK/INSP	MAIN LANDING GEAR DOOR LATCH SPRINGS
32-32-13-B	32-014		P-06-016-01	CHECK/INSP	MAIN GEAR DOOR LATCH ACTUATOR
32-32-14-A	32-014		P-06-016-01	CHECK/INSP	MAIN GEAR DOOR UPLOCK MECHANISM
32-32-18-A	32-017		P-06-131-01	CHECK/INSP	MAIN GEAR TRUCK POSITIONER
32-32-19-5A		32-046-02-1		FUNCTIONAL	TRUCK POSITIONER HYDRAULIC FUSES
32-32-19-5A		32-046-02-2		FUNCTIONAL	TRUCK POSITIONER HYDRAULIC FUSES
32-34-01-A	32-019		P-06-004-01	CHECK/INSP	NOSE GEAR RETRACT ACTUATOR
32-35-00-5A	32-021	32-021-01		OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-35-00-5A		32-021-02		OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-35-00-5A		32-048-51		OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-35-00-5A	32-048	32-048-52		OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-35-00-5B		32-049-51		OPERATIONAL	DOWN LOCK SPRINGS AND RELEASE HOOKS
32-35-00-5B	32-049	32-049-52		OPERATIONAL	DOWN LOCK SPRINGS AND RELEASE HOOKS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-66



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
32-35-01-A	32-014		P-06-016-01	CHECK/INSP	ALTERNATE EXTEND SYS FLUID SUPPLY
32-41-00-A	32-023		P-06-016-01	CHECK/INSP	HYD BRAKE MECHANICAL CONTROL PATH
32-41-00-2A	32-026	32-026-01		OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-41-00-2A		32-026-02		OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-41-00-2A		32-026-03		OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-41-00-2A		32-026-04		OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-41-00-5A	32-025	32-025-01		OPERATIONAL	ALTERNATE BRAKE SYSTEM/SELECTOR VALV
32-41-00-5A		32-025-02		OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-41-00-5A		32-025-03		OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-41-00-5A		32-025-04		OPERATIONAL	ALT BRAKE SYSTEM/SELECTOR VALVE
32-41-00-5A		32-025-05		OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-41-00-5A		32-025-06		OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-41-00-5A		32-025-07		OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-41-00-5B		32-040-01		OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-41-00-5B		32-040-02		OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-41-00-5B		32-040-03		OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-41-00-5B		32-040-04		OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-41-00-5B		32-040-05		OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-41-00-5B		32-040-06		OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-41-00-5B		32-040-07		OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-41-05-4A	32-038	32-038-01		OPERATIONAL	ACCUMULATOR ISOLATION VALVE
32-41-08-6A	32-024	32-024-01-1		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-41-08-6A	32-024	32-024-01-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-41-08-6A		32-024-02-1		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-41-08-6A		32-024-02-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-41-08-6A		32-024-03-1		CHECK/INSP	LEFT MAIN GEAR BRAKES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
32-41-08-6A		32-024-03-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-41-08-6A		32-024-04-1		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-41-08-6A		32-024-04-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-41-08-6A		32-024-05-1		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-41-08-6A		32-024-05-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-41-08-6A		32-051-01-1		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-41-08-6A		32-051-01-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-41-08-6A	32-051	32-051-02-1		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-41-08-6A	32-051	32-051-02-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-42-00-5A		32-037-01		FUNCTIONAL	ANTI-SKID/AUTOBRAKE CONTROL UNIT
32-42-00-5A		32-037-02		FUNCTIONAL	ANTI-SKID/AUTOBRAKE CONTROL UNIT
32-44-00-A	32-027		P-06-016-01	CHECK/INSP	PARKING BRAKE MECH CONTROL PATH
32-44-00-5A	32-050	32-050-01		FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-44-00-5A		32-050-02		FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-44-00-5A		32-050-03		FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-44-00-5A		32-050-04		FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-44-00-5A		32-050-05		FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-44-00-5A		32-050-06		FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-45-00-A		32-029-02		CHECK/INSP	NOSE AND MAIN GEAR TIRES AND WHEELS
32-45-03-6A	32-030	32-030-01	W-32-029-01	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-45-03-6A		32-030-02	W-32-029-05	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-45-03-6A		32-030-03	W-32-029-06	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-45-03-6A		32-030-04	W-32-029-05	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-45-03-6A		32-030-05	W-32-029-07	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-45-04-6A	32-029	32-029-01	W-32-030-01	CHECK/INSP	MAIN & NOSE GEAR TIRES
32-45-04-6A		32-029-05	W-32-030-02	CHECK/INSP	MAIN & NOSE GEAR TIRES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-68



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
32-45-04-6A		32-029-06	W-32-030-03	CHECK/INSP	MAIN & NOSE GEAR TIRES
32-45-04-6A		32-029-07	W-32-030-05	CHECK/INSP	MAIN & NOSE GEAR TIRES
32-45-05-A		32-046-01		CHECK/INSP	NLG SPIN BRAKE SPRING ARM
32-51-00-A	32-032		P-06-004-01	CHECK/INSP	N WHEEL STEERING MECH CONTROL PATH
32-51-02-A	32-033		P-06-004-01	CHECK/INSP	RUDDER PEDAL NOSE WHEEL STEERING
32-51-02-B	32-035	32-035-01		CHECK/INSP	CENTERING & RUDDER INTERCONNECT MECH
32-61-00-5A	32-042	32-042-51		OPERATIONAL	TAIL SKID WARNING PSEU BITE TEST
32-61-00-5B	32-041	32-041-51		OPERATIONAL	TAIL SKID WARNING SYSTEM
32-71-04-5A		32-041-01		FUNCTIONAL	TAIL SKID HYDRAULIC FUSE
32-71-08-6A	32-052	32-052-01		CHECK/INSP	TAIL SKID POP-UP INDICATOR
33-16-00-5A 22-10-00-5A 22-10-00-5B 22-32-00-5A 30-31-00-A 31-51-00-5A 34-16-00-5A	33-004-C1			OPERATIONAL	MASTER DIM & TEST
33-16-00-5A 22-10-00-5A 22-10-00-5B 22-32-00-5A 30-31-00-A 31-51-00-5A 34-16-00-5A	33-004-C2			OPERATIONAL	MASTER DIM & TEST
33-16-00-5A 30-31-00-A 31-51-00-5A	33-004-C3			OPERATIONAL	MASTER DIM & TEST
33-16-00-5A 30-31-00-A 31-51-00-5A	33-004-C4			OPERATIONAL	MASTER DIM & TEST
33-16-00-5A			G-33-004-C1 G-33-004-C2 G-33-004-C3 G-33-004-C4	OPERATIONAL	MASTER DIM & TEST SWITCH

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
33-35-00-2A	33-008	33-008-01		OPERATIONAL	CREW WARNING CARGO LIGHTS
33-51-00-5A	33-001	33-001-01	W-33-001-02	OPERATIONAL	EMERGENCY LIGHTS
33-51-00-5B		33-006-01	W-33-001-01	OPERATIONAL	EMERGENCY LIGHTS
33-51-00-5D		33-009-01		OPERATIONAL	EMERGENCY LIGHTS
33-51-02-2A	33-002	33-002-01		FUNCTIONAL	SELF-ILLUMINATED EXIT SIGNS
33-51-07-2A	33-003	33-003-01	W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-51-07-2A		33-003-02	W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-51-07-2A		33-003-03	W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-51-07-2A		33-003-04	W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-51-07-2B		33-003-06		FUNCTIONAL	EMERGENCY LIGHT POWER SUPPLIES
33-51-07-2B	33-003	33-003-09		FUNCTIONAL	EMERGENCY LIGHT POWER SUPPLIES
33-51-07-2C		33-003-07		OPERATIONAL	EXIT MARKER DIODES
33-51-07-2C	33-003	33-003-10		OPERATIONAL	EXIT MARKER DIODES
33-51-07-2D		33-003-08	W-33-003-06	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-51-07-2D	33-003	33-003-11	W-33-003-06	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
34-11-00-3A 34-11-00-3B 34-11-00-3C 34-11-00-3D	34-001-C1			DRAIN	PITOT-STATIC SYSTEMS
34-11-00-3A	34-001		G-34-001-C1	DRAIN	PITOT-STATIC SYSTEM
34-11-00-3B	34-002		G-34-001-C1	DRAIN	ALTERNATE STATIC SYSTEM
34-11-00-3C	34-003		G-34-001-C1	DRAIN	AUXILIARY PITOT SYSTEM
34-11-00-3D			G-34-001-C1	OPERATIONAL	AUXILIARY STATIC SYSTEM
34-11-00-5A	34-004	34-004-01	A-34-001-C1	FUNCTIONAL	ALTERNATE STATIC LINE LEAK CHECK
34-11-00-5A		34-007-04	A-34-001-C1	FUNCTIONAL	ALTERNATE STATIC LINE LEAK CHECK
34-11-00-5B	34-007	34-007-01	A-34-001-C1	FUNCTIONAL	STBY AIRSPEED INDICATOR AUX PITOT
34-11-00-5B		34-007-03	A-34-001-C1	FUNCTIONAL	STBY AIRSPEED INDICATOR AUX PITOT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-70



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
34-11-01-4A		34-013-02		REPLACE	PITOT-STATIC SYSTEM PROBES (RVSM)
34-12-00-6A	34-013	34-013-51		OPERATIONAL	AIR DATA COMPUTER
34-13-00-5A 34-13-00-5B	34-005-C1			FUNCTIONAL	AIR DATA STANDBY INSTRUMENTS
34-13-00-5A	34-005		G-34-005-C1	FUNCTIONAL	STANDBY ALTIMETER
34-13-00-5B	34-006		G-34-005-C1	FUNCTIONAL	STANDBY AIRSPEED INDICATOR
34-16-00-5A	34-008		G-33-004-C1 G-33-004-C2	OPERATIONAL	ALT ALERT INDICATOR ANNUNCIATOR
34-22-00-5A	34-009	34-009-01	A-34-010-01	OPERATIONAL	INSTRUMENT SOURCE SELECT SWITCHING
34-22-00-5B	34-010	34-010-01	B-34-009-01	OPERATIONAL	CENTER EFIS SYMBOL GENERATOR
34-24-03-5A	34-015	34-015-01		CHECK/INSP	INTEGRATED STANDBY FLIGHT DISPLAY
34-24-04-4A	34-016	34-016-03		REPLACE	INTEGRATED STANDBY FLIGHT DISPLAY
34-26-00-5A	34-014	34-014-02		OPERATIONAL	ADIRU COMPUTERS
34-46-00-5A		34-011-01		OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-46-00-5A		34-011-02		OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-46-00-5A		34-011-03		OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-46-00-5A		34-011-04		OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-46-00-5A	34-011		G-34-011-05	OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-46-00-5A		34-011-09		OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-46-00-5A		34-011-12		OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-53-00-5A	34-012	34-012-01		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-53-00-5A		34-012-02		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-53-00-5A		34-012-03		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-53-00-5A		34-012-04		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-53-00-5A		34-012-05		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-53-00-5A		34-012-06		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-53-00-5A		34-012-07		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
34-61-00-2A		34-016-01		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-02		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-04		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-06		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-07		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-08		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-09		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-10		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-11		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-12		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-61-00-2A		34-016-13		SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
35-00-00-A		35-011-51		CHECK/INSP	PORTABLE OXYGEN BOTTLES
35-00-00-6A	35-006	35-006-01		CHECK/INSP	PASSENGER CHEMICAL OXYGEN GENERATORS
35-00-00-6B	35-009	35-009-01		CHECK/INSP	PORTABLE CHEMICAL OXYGEN GENERATORS
35-11-00-A	35-001		G-35-001-C1	CHECK/INSP	CREW OXYGEN SYSTEM PRESSURE
35-11-00-B	35-014	35-014-01		FUNCTIONAL	CREW OXYGEN MASK/REGULATOR
35-11-00-C		35-015-01		CHECK/INSP	CREW OXYGEN CYLINDER
35-11-00-5A 35-11-00-A	35-001-C1			CHECK/INSP	CREW OXYGEN SYSTEM PRESSURE/CYLINDER
35-11-00-5A	35-002		G-35-001-C1	CHECK/INSP	CREW OXYGEN PRESS TRANSDUCER/INDCATR
35-11-00-5B	35-003	35-003-01		OPERATIONAL	CREW OXYGEN LOW PRESSURE LINE
35-11-00-5C	35-013	35-013-01		OPERATIONAL	CREW OXYGEN MASK/REGULATOR
35-21-00-5A 35-21-00-5B	35-004-C1			FUNCTIONAL	PASS OXY DOOR LATCH AND ALT PRESS SW
35-21-00-5A	35-004		G-35-004-C1	FUNCTIONAL	ALTITUDE PRESSURE SWITCH - PASS OXY
35-21-00-5B	35-005		G-35-004-C1	OPERATIONAL	PASS OXY DOOR LATCHES-MANUAL SWITCH
35-21-04-4A	35-007	35-007-01		REPLACE	PASSENGER CHEMICAL OXYGEN GENERATORS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-72



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
35-21-05-6A	35-012	35-012-01	B-35-004-C1	CHECK/INSP	PASSENGER OXYGEN MASKS
35-31-00-A	35-010	35-010-01		REPLACE	PORTABLE CHEMICAL OXYGEN GENERATORS
35-31-01-6C	35-008	35-008-01		CHECK/INSP	PORTABLE OXYGEN BOTTLES
36-00-24-5A		36-BCY-90-1		OPERATIONAL	PNEUMATIC SYSTEM TEST - LEFT ENGINE
36-00-24-5A		36-BCY-90-2		OPERATIONAL	PNEUMATIC SYSTEM TEST - LEFT ENGINE
36-11-00-5A	36-002	36-002-01		FUNCTIONAL	AIR SUPPLY DISTRIBUTION
36-11-00-5A		36-002-02		FUNCTIONAL	AIR SUPPLY DISTRIBUTION
36-11-00-5B	36-003	36-003-01		OPERATIONAL	CENTER ISOLATION VALVE
36-11-00-5B		36-003-02		OPERATIONAL	CENTER ISOLATION VALVE
36-11-01-6A	36-001		P-06-073-01	CHECK/INSP	FAN AIR INLET DUCTING - ENGINE
36-11-01-6A	36-001		P-06-088-01	CHECK/INSP	FAN AIR INLET DUCTING - ENGINE
36-11-01-6A	36-001		P-06-144-01	CHECK/INSP	ENGINE FAN AIR INLET DUCTING
36-11-01-6C	36-011	36-011-05-1		CHECK/INSP	ENG 1 INTERMEDIATE PRESSURE DUCT
36-11-01-6C	36-011	36-011-05-2		CHECK/INSP	ENG 2 INTERMEDIATE PRESSURE DUCT
36-11-05-6A	36-004	36-004-01		CHECK/INSP	ISOLATION BYPASS CHECK VALVES
36-11-06-6A	36-005	36-005-01-1		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-11-06-6A	36-005	36-005-01-2		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-11-06-6A	36-005	36-005-02-1		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-11-06-6A	36-005	36-005-02-2		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-11-06-6B		36-011-60-1		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-11-06-6B		36-011-60-2		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-11-06-6B	36-011	36-011-62-1		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-11-06-6B	36-011	36-011-62-2		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-11-07-A	36-006		P-06-069-01	CHECK/INSP	H.P. SHUTOFF VALVE SENSE LINE
36-11-07-A	36-006		P-06-084-01	CHECK/INSP	H.P. SHUTOFF VALVE SENSE LINE
36-11-07-A	36-006		P-06-145-01	CHECK/INSP	HP SHUTOFF VALVE SENSE LINE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
36-11-08-4B		36-011-51-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-51-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-53-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-53-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-54-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-54-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-55-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-55-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-56-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-56-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-57-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-57-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-58-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-58-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-61-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-61-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-61-3		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-61-4		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-63-1		REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-11-08-4B		36-011-63-2		REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-11-09-2B		36-012-01-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-01-2		REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-11-09-2B		36-012-02-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-02-2		REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-11-09-2B		36-012-03-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-03-2		REPLACE	ENGINE 2 PRSOV AIR FILTERS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-74



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
36-11-09-2B		36-012-03-3		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-03-4		REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-11-09-2B		36-012-04-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-04-2		REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-11-09-2B		36-012-06-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-06-2		REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-11-09-2B		36-012-08-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-08-2		REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-11-09-2B		36-012-09-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-09-2		REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-11-09-2B		36-012-10-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-10-2		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-11-1		REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-11-09-2B		36-012-11-2		REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-11-11-6A	36-007	36-007-01		CHECK/INSP	APU AIR SUPPLY CHECK VALVE
36-11-16-4A		36-013-01-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-01-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-03-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-03-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-04-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-04-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-05-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-05-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-07-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-07-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-08-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
36-11-16-4A		36-013-08-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-09-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-013-09-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A			G-36-013-10-1	REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A			G-36-013-10-2	REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-015-01-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-015-01-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-015-02-1		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-4A		36-015-02-2		REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-11-16-5A	36-008	36-008-01		OPERATIONAL	AIR SUPPLY BITE MODULE
36-11-16-5B		36-008-02		OPERATIONAL	AIR SUPPLY PRECOOLING SYSTEM
36-11-18-A	36-010		P-06-084-01	CHECK/INSP	PRESSURE REGULATING VALVE SENSE LINE
36-11-19-4B		36-014-01-1		REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-014-01-2		REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-014-02-1		REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-014-02-2		REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-016-01-1		REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-016-01-2		REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-017-01-1		REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-017-01-2		REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-017-02-1		REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-11-19-4B		36-017-02-2		REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-22-00-5A	36-009	36-009-01-1		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-22-00-5A		36-009-02-1		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-22-00-5A		36-009-03-1		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-22-00-5B	36-009	36-009-01-2		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-76



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
36-22-00-5B		36-009-02-2		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-22-00-5B		36-009-03-2		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-22-01-4A		36-009-10-1		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-22-01-4A		36-009-10-2		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-23-00-5A		36-018-01		OPERATIONAL	AIR SUPPLY ASCTU BITE DISPLAY
36-23-00-5A	36-018	36-018-2		OPERATIONAL	AIR SUPPLY ASCTU BITE DISPLAY
38-10-00-2A	38-001	38-001-01		DISINFECT	POTABLE WATER SYSTEM
38-10-00-2A		38-001-02		DISINFECT	POTABLE WATER SYSTEM
38-10-00-5A		38-010-01		FUNCTIONAL	PRESSURE ACTUATED COMPRESSOR SWITCH
38-10-60-A	38-008	38-008-51	W-38-001-04	CHECK/INSP	POTABLE WATER TANK AND SUPPLY LINE
38-10-60-2A	38-001	38-001-04	W-38-001-03	DISINFECT	POTABLE WATER SYSTEM
38-11-01-2A		38-012-01		CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-11-01-2A		38-012-02		CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-11-01-2A		38-012-03		CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-11-01-2A		38-012-04		CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-11-01-2A		38-012-06		CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-11-01-2A		38-012-07		CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-11-01-2A		38-012-08		CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-11-01-2A		38-012-09		CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-15-02-4A 38-15-02-4B	38-002	38-002-C1		REPLACE	POTABLE WATER SYSTEM AIR FILTERS
38-15-02-4A	38-002		G-38-002-C1	REPLACE	WTR TANK COMPRESSOR AIR INLET FILTER
38-15-02-4B	38-003		G-38-002-C1	REPLACE	POT WTR ENG BLEED AIR INLINE FILTERS
38-15-02-4C		38-006-01		REPLACE	POT WATER PRESSURIZATION AIR FILTER
38-15-06-2A		38-011-01		FUNCTIONAL	WATER TANK PRESSURE RELIEF VALVE
38-32-00-A	38-007		P-06-007-01	CHECK/INSP	RINSE/DRAIN LINES AND WASTE TANK

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
38-32-00-5A	38-004	38-004-01		OPERATIONAL	VACUUM WATER BREAKS
38-32-00-5A		38-004-02		OPERATIONAL	VACUUM WATER BREAKS
38-32-00-5D		38-016-01		OPERATIONAL	WASTE TANK DRAIN VALVES
38-32-00-5D		38-016-02		OPERATIONAL	WASTE TANK DRAIN VALVES
38-32-00-5D		38-016-03		OPERATIONAL	WASTE TANK DRAIN VALVES
38-32-03-4A		38-013-01		RESTORE	WASTE TANK DRAIN VALVE SEALS
38-32-03-4A		38-013-02		RESTORE	WASTE TANK DRAIN VALVE SEALS
38-32-03-4A		38-013-03		RESTORE	WASTE TANK DRAIN VALVE SEALS
38-32-06-4A		38-008-01		REPLACE	VACUUM BLOWER AIR FILTERS
38-32-11-2A		38-009-01		CHECK/INSP	WASTE TANK LEVEL SENSORS/SEPARATOR
38-32-11-2A		38-009-04		CHECK/INSP	WASTE TANK LEVEL SENSORS/SEPARATOR
38-32-17-2A		38-014-01		CLEAN/INSP	WASTE TANK RINSE NOZZLES
38-32-18-2A		38-015-01		REPLACE	WASTE TANK RINSE LINE FILTERS
38-32-60-5A	38-006	38-006-51		OPERATIONAL	SERVICE PANEL WASTE DRAIN FTG SEAL
38-33-00-5B	38-005	38-005-02		OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-33-00-5B		38-005-05		OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-33-00-5B		38-005-06		OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-33-00-5C	38-005	38-005-01		OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
49-11-00-5A		49-063-01		OPERATIONAL	APU FIRE SHUTDOWN SYSTEM
49-11-00-5A		49-063-02		OPERATIONAL	APU FIRE SHUTDOWN SYSTEM
49-11-01-A	49-061	49-061-51		SPCL DETAIL	CONTAINMENT SYSTEM (POWER SECTION)
49-11-01-B	49-063	49-063-51		SPCL DETAIL	CONTAINMENT SYSTEM (LOAD COMPRESSOR)
49-13-00-6A	49-018		P-06-049-01	CHECK/INSP	APU AFT MOUNT BRACKETS
49-13-00-6B	49-002		P-06-049-01	CHECK/INSP	APU VIBRATION ISOLATOR MOUNTS
49-13-00-6C	49-003		P-06-049-01	CHECK/INSP	APU MOUNT TUBULAR SUPPORTS
49-13-00-6D	49-004		P-06-049-01	CHECK/INSP	APU FWD MOUNT BRACKETS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-78



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
49-13-00-6E	49-005		P-06-049-01	CHECK/INSP	APU MOUNT CONE BOLT NUTS
49-14-00-6A	49-039		P-06-049-01	CHECK/INSP	APU IGV ACTUATOR ELECTRICAL HARNESS
49-14-00-6B	49-044		P-06-049-01	CHECK/INSP	SURGE VALVE ELECTRICAL HARNESS
49-14-00-6C	49-045		P-06-049-01	CHECK/INSP	DIFFERENTIAL PRESS TRANSDUCER WIRING
49-14-00-6D	49-047		P-06-049-01	CHECK/INSP	COMPRESSOR INLET TEMPERATURE SENSOR
49-14-00-6E	49-058		P-06-049-01	CHECK/INSP	APU LOW OIL LEVEL SWITCH WIRING
49-14-00-6F	49-031		P-06-049-01	CHECK/INSP	FUEL CTRL/FLOW DIVIDER ELECT HARNESS
49-14-00-6G	49-034		P-06-049-01	CHECK/INSP	IGNITION UNIT ELECTRICAL HARNESS
49-14-00-6H	49-037		P-06-049-01	CHECK/INSP	COOLING FAN ISOLATION VALVE SWITCH
49-14-00-6I	49-043		P-06-049-01	CHECK/INSP	APU TOTAL PRESSURE TRANSDUCER
49-14-00-6J	49-050		P-06-049-01	CHECK/INSP	APU OIL TEMPERATURE SENSOR
49-14-00-6K	49-048		P-06-049-01	CHECK/INSP	APU INLET PRESSURE SENSOR
49-14-00-6L	49-052		P-06-049-01	CHECK/INSP	APU EGT THERMOCOUPLE HARNESS
49-15-01-4A	49-009		P-06-049-01	CHECK/INSP	APU AIR INTAKE DUCT & DUCT JOINTS
49-15-01-4B	49-008	49-008-01		CHECK/INSP	APU AIR INTAKE DUCT - INTERNAL
49-15-03-6A	49-001		P-06-049-01	CHECK/INSP	APU INTAKE PLENUM MOUNT ATTACH POINT
49-15-03-6B	49-010		P-06-049-01	CHECK/INSP	APU AIR INTAKE PLENUM - EXTERNAL
49-15-03-6C	49-011		P-06-049-01	CHECK/INSP	APU AIR INTAKE PLENUM - INTERNAL
49-15-05-6A	49-006		P-06-048-01	CHECK/INSP	APU AIR INTAKE DOOR TO ACTUATOR
49-15-05-6B	49-007		P-06-048-01	CHECK/INSP	APU AIR INTAKE DOOR HINGE
49-16-00-A	49-013	49-013-01		CHECK/INSP	APU DRAIN MAST
49-16-00-6B	49-012		P-06-049-01	CHECK/INSP	APU DRAIN LINES, CONNECTIONS & MAST
49-16-02-7A	49-060	49-060-51		FUNCTIONAL	COMBUSTOR DRAIN VALVE
49-21-00-A	49-019	49-019-01		REPLACE	APU TURBINE DISKS
49-21-00-B	49-062	49-062-51		REPLACE	1ST & 2ND STAGE COMPRESSOR IMPELLER
49-21-00-C	49-064	49-064-51		REPLACE	APU LOAD COMPRESSOR IMPELLER

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
49-21-00-6A	49-015		P-06-049-01	CHECK/INSP	APU GEARBOX
49-21-00-6B	49-016		P-06-049-01	CHECK/INSP	APU GEARCASE MOUNTS
49-21-00-6C	49-017		P-06-049-01	CHECK/INSP	APU EXHAUST CASE EXTERIOR
49-21-00-6D	49-020		P-06-049-01	CHECK/INSP	APU INSULATION BLANKET/HEAT SHIELD
49-21-00-6E	49-030		P-06-049-01	CHECK/INSP	GEARBOX PRESSURIZATION PLUMBING
49-21-00-6F	49-027		P-06-049-01	CHECK/INSP	LABYRINTH SEAL PNEUMATIC PLUMBING
49-21-00-6G	49-026		P-06-049-01	CHECK/INSP	APU COMPARTMENT PLUMBING/COMPONENTS
49-21-00-6H	49-033		P-06-049-01	CHECK/INSP	APU FUEL SYSTEM PLUMBING/COMPONENTS
49-21-00-6I	49-035		P-06-049-01	CHECK/INSP	COOLING FAN ISOLATION VALVE PLUMBING
49-21-00-6J	49-040		P-06-049-01	CHECK/INSP	APU IGV ACTUATOR AND PLUMBING
49-21-00-6K	49-041		P-06-049-01	CHECK/INSP	APU SURGE VALVE PLUMBING
49-21-00-6L	49-042		P-06-049-01	CHECK/INSP	APU TOTAL PRESSURE SENSOR/PLUMBING
49-21-00-6M	49-046		P-06-049-01	CHECK/INSP	VARIABLE VOLUME VALVE CHAMBER
49-27-00-A	49-028	49-028-01		FUNCTIONAL	GEARBOX SHUTOFF VALVE
49-27-00-B	49-029	49-029-01		FUNCTIONAL	GEARBOX PRESSURE REGULATING VALVE
49-27-00-C	49-051	49-051-01		FUNCTIONAL	GENERATOR OIL FLTR DIFF PRESS SWITCH
49-27-03-4A 49-27-03-4B	49-023-C1			REPLACE	APU OIL PRESS & GEN SCAVENGE FILTERS
49-27-03-4A	49-023		G-49-023-C1	REPLACE	APU OIL PRESSURE FILTER ELEMENT
49-27-03-4B	49-025		G-49-023-C1	REPLACE	APU GENERATOR SCAVENGE FILTER
49-27-03-6A 49-27-03-6B	49-024-C1		CHECK/INSP	APU/GEN FILTER DIFF PRESS INDICATORS	
49-27-03-6A	49-024		G-49-024-C1	CHECK/INSP	SCAVENGE FILTER DIFF PRESS INDICATOR
49-27-03-6B	49-022		G-49-024-C1	CHECK/INSP	OIL PRESS FILTER DIFF PRESS INDICATR
49-27-04-6A 49-27-04-6B	49-014-C1			CHECK/INSP	APU MAGNETIC CHIP DETECTORS
49-27-04-6A	49-014		G-49-014-C1	CHECK/INSP	APU GEARBOX MAGNETIC CHIP DETECTOR

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-80



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
49-27-04-6B	49-059		G-49-014-C1	CHECK/INSP	APU MAGNETIC CHIP DETECTORS
49-27-09-A		49-061-01		CHECK/INSP	APU FIREWALL
49-27-09-6A		49-064-01		CHECK/INSP	APU OIL COOLER
49-31-00-A	49-032	49-032-01		CHECK/INSP	APU LP FUEL FILTER DIFF PRESS IND
49-41-01-6A		49-062-01		CHECK/INSP	APU STARTER MOTOR BRUSH WEAR
49-51-00-A	49-036		P-06-049-01	CHECK/INSP	APU COOLING FAN DUCTING
49-51-01-A	49-038		P-06-049-01	CHECK/INSP	OIL COOLING AIR EXHAUST DUCT
49-53-06-2A		49-060-01		REPLACE	APU SURGE VALVE FILTER ELEMENT
49-61-05-2A	49-049	49-049-01		OPERATIONAL	APU CONTROL UNIT (ECU)
49-81-01-2A	49-055		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT
49-81-01-2B	49-056		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT INTERIOR & SUPPORT
49-81-01-2C	49-057		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT INSULATION BLANKET
49-81-01-2D	49-054		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT V-BAND CLAMP
49-81-01-2E	49-053		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT V-BAND CLAMP
51-41-00-2A		51-001-01		CHECK/INSP	FUSELAGE DRAIN VALVES
52-09-01-2A	52-012		P-06-138-01	CHECK/INSP	FWD/AFT ENTRY/SERVICE DOOR SEALS
52-09-01-2A	52-012		P-06-138-01	CHECK/INSP	MID-CABIN ENTRY/SERVICE DOOR SEALS
52-09-02-4A	52-025		P-06-133-01	CHECK/INSP	BULK CARGO DOOR SEALS
52-09-02-4B	52-022		P-06-134-01 P-06-136-01	CHECK/INSP	FWD/AFT CARGO DOOR SEALS
52-09-06-4A	52-037		P-06-173-01-1 P-06-173-01-2	CHECK/INSP	EMERGENCY EXIT DOOR SEALS
52-09-07-A	52-037		P-06-184-01	CHECK/INSP	MAIN DECK CARGO DOOR SEAL
52-09-07-A			P-06-184-01	CHECK/INSP	MAIN DECK CARGO DOOR SEAL
52-11-00-5A	52-001	52-001-01		OPERATIONAL	ENTRY/SERVICE DOOR UPLATCH MECHANISM
52-11-00-5A	52-001	52-001-02		OPERATIONAL	ENTRY/SERVICE DOOR UPLATCH MECHANISM
52-11-00-5A		52-001-03		OPERATIONAL	ENTRY/SERVICE DOOR UPLATCH MECHANISM

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
52-11-00-6A	52-011		P-06-038-01	CHECK/INSP	ENTRY DOOR LATCH PIN MECHANISM
52-11-06-A	52-008		P-06-038-01	CHECK/INSP	ENTRY/SERVICE DOOR TRACK SYSTEM
52-11-16-A	52-004		P-06-039-01	CHECK/INSP	ENTRY/SERVICE DOOR COUNTERBALANCE
52-11-16-B	52-005		P-06-039-01	CHECK/INSP	COUNTERBALANCE CABLES/PULLEYS
52-11-21-2A	52-006	52-006-01		CHECK/INSP	COUNTERBALANCE LOAD LIMITER
52-11-21-2A	52-006	52-006-02		CHECK/INSP	COUNTERBALANCE LOAD LIMITER
52-11-25-A	52-002	52-002-01		CHECK/INSP	ENTRY/SERVICE DOOR HANDLE MECHANISM
52-11-25-A	52-002	52-002-02		CHECK/INSP	ENTRY/SERVICE DOOR HANDLE MECHANISM
52-11-25-C	56-001		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR
52-11-31-A	52-010	52-010-01		CHECK/INSP	ENTRY DOOR SPRING HYDRAULIC SNUBBER
52-11-31-A	52-010	52-010-02		CHECK/INSP	ENTRY DOOR SPRING HYDRAULIC SNUBBER
52-11-33-A	52-009	52-009-01		CHECK/INSP	ENTRY/SERVICE DOOR LATCH MECHANISM
52-11-33-A	52-009	52-009-02		CHECK/INSP	ENTRY/SERVICE DOOR LATCH MECHANISM
52-11-34-A	52-003		P-06-039-01	CHECK/INSP	CEILING PANEL LATCH MECHANISM
52-11-34-A	52-003		P-06-039-01	CHECK/INSP	CEILING PANEL LATCH MECHANISM
52-12-00-A	52-051		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR CEILING PANEL
52-12-10-A	52-053		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR TRACK SYSTEM
52-12-21-A	52-052		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR COUNTERBALANCE
52-12-25-6A	52-041	52-041-01		CHECK/INSP	CREW ENTRY DOOR HANDLE MECHANISM
52-12-32-A	52-054		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR LATCH MECHANISM
52-12-32-B	52-055		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR LATCH SPRING
52-12-32-C	52-056		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR LATCH PIN
52-21-01-2A	52-014	52-014-01		OPERATIONAL	OVERWING ESCAPE HATCHES
52-21-02-2A		52-074-01		FUNCTIONAL	SELF-ILLUMINATED O/H PULL HANDLE
52-22-01-5A	52-036	52-036-01		OPERATIONAL	EMERGENCY EXIT DOOR MECHANISMS
52-32-00-A	52-046		P-06-185-01	CHECK/INSP	MAIN DECK CARGO DOOR HINGE MECHANISM

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-82



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
52-32-03-2A	52-043	52-043-01		REPLACE	MAIN DECK CARGO DOOR LIFT MECHANISM
52-32-04-A	52-042		P-06-185-01	CHECK/INSP	MAIN DECK CARGO DOOR LIFT MECHANISM
52-32-05-5A		52-047-C1		OPERATIONAL	MAIN DECK CARGO DOOR
52-32-05-5A	52-047		G-52-047-C1	OPERATIONAL	MAIN DECK CARGO DOOR MANUAL DRIVE
52-32-05-5B	52-050		G-52-047-C1	FUNCTIONAL	MAIN DECK CARGO DOOR LATCH/HOOK
52-32-05-5C	52-049		G-52-047-C1	OPERATIONAL	MAIN DECK CARGO DOOR POWER UNIT
52-32-08-A	52-044		P-06-185-01	CHECK/INSP	MAIN DECK CARGO DOOR LATCH/HOOK
52-32-08-B	52-045		P-06-185-01	CHECK/INSP	MAIN DECK CARGO DOOR LATCH LOCK
52-32-12-5A	52-048	52-048-01		FUNCTIONAL	MAIN DECK CARGO DOOR RATCHET BRAKE
52-33-00-A	52-068		P-06-135-01	CHECK/INSP	LARGE FWD CARGO DOOR LATCH LOCK
52-33-00-B	52-070		P-06-135-01	CHECK/INSP	LARGE FWD CARGO DOOR HINGE MECHANISM
52-33-00-5A		52-027-01		OPERATIONAL	LARGE FWD CARGO DOOR OPERATING MECH
52-33-00-5B	52-066	52-066-01	W-52-027-01	OPERATIONAL	LARGE FWD CARGO DOOR NO-BACK BRAKES
52-33-00-5C 52-33-00-5D 52-33-00-5E	52-060-C1			OPERATIONAL	LARGE FORWARD CARGO DOOR
52-33-00-5C	52-060		G-52-060-C1	OPERATIONAL	LARGE FWD CARGO DOOR MANUAL DRIVE
52-33-00-5D	52-062		G-52-060-C1	OPERATIONAL	LARGE FWD CARGO DOOR POWER UNIT
52-33-00-5E	52-064		G-52-060-C1	FUNCTIONAL	LARGE FWD CARGO DOOR LATCH/HOOK
52-33-06-5A	52-072	52-072-01		FUNCTIONAL	FWD LG CARGO DOOR LATCH LOCK HANDLE
52-34-00-5A		52-026-01		OPERATIONAL	FWD CARGO DOOR OPERATING MECHANISM
52-34-02-A	52-016		P-06-009-01	CHECK/INSP	FWD/AFT CARGO DOOR HINGE POWER UNIT
52-34-03-A	52-020		P-06-135-01	CHECK/INSP	CARGO DOOR HINGE ROTARY ACTUATOR
52-34-04-A	52-015		P-06-008-01	CHECK/INSP	FWD/AFT CARGO DOOR HINGE MECHANISM
52-34-10-A	52-019		P-06-135	CHECK/INSP	CARGO DOOR LIFT/LATCH POWER UNIT
52-34-12-A	52-018		P-06-135-01	CHECK/INSP	CARGO DOOR LIFT/LATCH MECHANISM
52-34-12-B	52-021		P-06-135-01	CHECK/INSP	FWD/AFT CARGO DOOR LATCH BUNGEE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
52-34-12-C		52-028-01		CHECK/INSP	CARGO DOOR ACTUATION/LATCH COMPONENTS
52-34-23-A	52-030		P-06-009-01	CHECK/INSP	LARGE CARGO DOOR LIFT PWR DRIVE UNIT
52-34-27-A	52-031		P-06-135-02	CHECK/INSP	LARGE CARGO DOOR ROTARY ACTUATOR
52-34-28-A	52-032		P-06-135-02	CHECK/INSP	LARGE CARGO DOOR LIFT DRIVE MECH
52-34-35-A	52-033		P-06-135-02	CHECK/INSP	LARGE CARGO DOOR LATCH/HOOK ACTUATOR
52-34-36-A	52-034		P-06-135-02	CHECK/INSP	LARGE CARGO DOOR LATCH/HOOK MECH
52-35-00-5A	52-027	52-027-02		OPERATIONAL	AFT CARGO DOOR OPERATING MECHANISM
52-36-02-A	52-024		P-06-027-01	CHECK/INSP	BULK CARGO DOOR BALANCE MECHANISM
52-36-02-6A		52-038-01		CHECK/INSP	BULK CARGO DOOR BALANCE MECHANISM
52-36-05-A	52-023		P-06-132-01	CHECK/INSP	BULK CARGO DOOR MECHANISM
52-37-00-A	52-069		P-06-137-01	CHECK/INSP	LARGE AFT CARGO DOOR LATCH LOCK
52-37-00-B	52-071		P-06-137-01	CHECK/INSP	LARGE AFT CARGO DOOR HINGE MECHANISM
52-37-00-5A	52-067	52-067-01		OPERATIONAL	LARGE AFT CARGO DOOR NO-BACK BRAKES
52-37-00-5C 52-37-00-5D 52-37-00-5E	52-061-C1			OPERATIONAL	AFT LOWER LOBE LARGE CARGO DOOR
52-37-00-5C	52-061		G-52-061-C1	OPERATIONAL	LARGE AFT CARGO DOOR MANUAL DRIVE
52-37-00-5D	52-063		G-52-061-C1	OPERATIONAL	LARGE AFT CARGO DOOR POWER UNIT
52-37-00-5E	52-065		G-52-061-C1	FUNCTIONAL	LARGE AFT CARGO DOOR LATCH/HOOK
52-37-06-5A	52-073	52-073-01		FUNCTIONAL	AFT LG CARGO DOOR LATCH LOCK HANDLE
52-51-00-A	52-074		P-06-037-01	CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-00-5A		52-078-01		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5A		52-078-02		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5A		52-078-03		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5A		52-078-04		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5A			G-52-078-05	OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5A		52-078-06		OPERATIONAL	FLIGHT DECK SECURITY DOOR

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-84



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
52-51-00-5B		52-081-04		FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5B			G-52-081-05	FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5B		52-081-06		FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5B		52-081-07		FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5B		52-081-08		FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5B		52-081-09		FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5C		52-077-06		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5C		52-077-07		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5C		52-077-09		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5C			G-52-077-10	OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5C		52-077-11		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-00-5C		52-077-12		OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-51-05-6A		52-079-01		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-05-6A		52-079-02		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-05-6A		52-079-03		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-05-6A			G-52-079-07	CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-07-4A		52-075-01		REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-51-07-4A		52-075-02		REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-51-07-4A		52-075-03		REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-51-07-4A		52-075-04		REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-51-07-4A			G-52-075-05	REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-51-07-4A		52-075-06		REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-51-14-6A		52-076-01		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-14-6A		52-076-03		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-14-6A		52-076-04		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-14-6A			G-52-076-05	CHECK/INSP	FLIGHT DECK SECURITY DOOR

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
52-51-14-6B		52-080-01		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-14-6B		52-080-02		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-14-6B		52-080-03		CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-51-14-6B			G-52-080-05	CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-71-00-5A		52-035-01		OPERATIONAL	FWD/E&E BAY, BULK CARGO DOOR WARNING
52-71-02-2A	52-058	52-058-01		FUNCTIONAL	LARGE FWD CARGO DOOR WARNING SYSTEM
52-71-03-2A	52-059	52-059-01		FUNCTIONAL	LARGE AFT CARGO DOOR WARNING SYSTEM
52-71-09-2A	52-057	52-057-01		FUNCTIONAL	MAIN DECK CARGO DOOR WARNING SYSTEM
53-53-01-A		53-003-01-1	W-12-044-C1-1	CHECK/INSP	AFT W/W BULKHEAD SPHERICAL BEARING
53-53-01-A		53-003-01-2	W-12-044-C1-2	CHECK/INSP	AFT W/W BULKHEAD SPHERICAL BEARING
54-51-00-2D		54-002-01-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-01-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-02-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-02-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-03-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-03-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-04-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-04-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-05-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-05-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-06-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-06-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-07-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-07-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-08-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-08-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
54-51-00-2D		54-002-09-1		FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-51-00-2D		54-002-09-2		FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
56-11-04-4A	56-001	56-001-01		OPERATIONAL	NO. 2 OPENING WINDOW HANDLE
57-00-00-A		57-004-01-1		REPLACE	L MAIN LDG GEAR SUPPORT STRUCTURE
57-00-00-A		57-004-01-2		REPLACE	R MAIN LDG GEAR SUPPORT STRUCTURE
57-00-00-A		57-004-02-1		REPLACE	L MAIN LDG GEAR SUPPORT STRUCTURE
57-00-00-A		57-004-02-2		REPLACE	R MAIN LDG GEAR SUPPORT STRUCTURE.
57-00-00-B		57-005-01-1		REPLACE	L MLG RETRACT ACTUATOR FTG AND PIN
57-00-00-B		57-005-01-2		REPLACE	R MLG RETRACT ACTUATOR FTG AND PIN
57-25-01-A		57-002-01		CHECK/INSP	WING VORTEX GENERATOR
57-53-01-A		57-003-01		CHECK/INSP	OUTBOARD FLAP VORTEX GENERATORS
D71-00-00-B	71-517		P-06-161-01	CHECK/INSP	ENGINE AND ENGINE COMPONENTS
D71-11-01-A	71-512		P-06-157-01	CHECK/INSP	NOSE COWL INTAKE LIP & INNER BARREL
D71-11-01-B	71-513		P-06-157-01	CHECK/INSP	ENGINE NOSE COWL OUTER SKIN
D71-11-01-C	71-516		P-06-157-01	CHECK/INSP	ENGINE NOSE COWL ACOUSTIC PANELS
D71-11-01-D	71-518		P-06-161-01	CHECK/INSP	ENGINE NOSE COWL & FAN CASE FLANGES
D71-11-01-E		71-543-01-1		CHECK/INSP	ENGINE 1 NOSE COWL ACOUSTIC LINERS
D71-11-01-E		71-543-01-2		CHECK/INSP	ENGINE 2 NOSE COWL ACOUSTIC LINERS
D71-11-02-A	71-514		P-06-157-01	CHECK/INSP	ENGINE HINGED COWL PANELS
D71-11-02-B	71-515		P-06-157-01	CHECK/INSP	ENGINE HINGED COWL PANEL LATCHES
D71-11-02-C	71-529		P-06-163-01	CHECK/INSP	HINGED COWL PANEL HINGES/LATCH STR
D71-11-02-D	71-530		P-06-163-01	CHECK/INSP	HINGED COWL PANEL LATCHES/STRUCTURE
D71-11-02-E	71-531		P-06-163-01	CHECK/INSP	HINGED COWL PANEL AND SEALS
D71-11-02-F	71-532		P-06-163-01	CHECK/INSP	HINGED COWL PANEL PRESS RELIEF DOORS
D71-11-02-G	71-533		P-06-163-01	CHECK/INSP	HINGED COWL PANEL HOLD OPEN RODS
D71-11-02-H	71-534		P-06-163-01	CHECK/INSP	LIGHTNING CONTACTOR STRIPS/BONDING

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
D71-21-01-A		71-537-01-1		CHECK/INSP	ENGINE 1 FRONT ENGINE MOUNT
D71-21-01-A		71-537-01-2		CHECK/INSP	ENGINE 2 FRONT ENGINE MOUNT
D71-21-01-B		71-540-01-1		DISCARD	FRONT MOUNT PYLON MOUNTING BRACKET
D71-21-01-B		71-540-01-2		DISCARD	FRONT MOUNT PYLON MOUNTING BRACKET
D71-21-01-C		71-541-01-1		DISCARD	ENGINE 1 FRONT MOUNT LINK/PINS
D71-21-01-C		71-541-01-2		DISCARD	ENGINE 2 FRONT MOUNT LINK/PINS
D71-21-01-D		71-539-01-1		DISCARD	ENG 1 FRONT MOUNT CENTER THRUST LINK
D71-21-01-D		71-539-01-2		DISCARD	ENG 2 FRONT MOUNT CENTER THRUST LINK
D71-21-01-6A		71-501-C1-1		CHECK/INSP	ENGINE 1 FRONT MOUNT
D71-21-01-6A		71-501-C1-2		CHECK/INSP	ENGINE 2 FRONT MOUNT
D71-21-01-6A	71-501		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
D71-21-01-6A	71-501		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
D71-21-01-6B	71-502		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
D71-21-01-6B	71-502		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
D71-21-01-6C	71-505		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
D71-21-01-6C	71-505		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
D71-21-01-6D	71-508		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
D71-21-01-6D	71-508		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
D71-21-01-6E	71-510		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
D71-21-01-6E	71-510		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
D71-21-02-A		71-536-01-1		CHECK/INSP	ENGINE 1 REAR ENGINE MOUNT
D71-21-02-A		71-536-01-2		CHECK/INSP	ENGINE 2 REAR ENGINE MOUNT
D71-21-02-B		71-538-01-1		DISCARD	ENGINE 1 REAR MOUNT PYLON BRACKET
D71-21-02-B		71-538-01-2		DISCARD	ENGINE 2 REAR MOUNT PYLON BRACKET
D71-21-02-6A		71-502-C1-1		CHECK/INSP	ENGINE 1 REAR MOUNT
D71-21-02-6A		71-502-C1-2		CHECK/INSP	ENGINE 2 REAR MOUNT

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
D71-21-02-6A	71-503		G-71-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
D71-21-02-6A	71-503		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
D71-21-02-6B	71-504		G-71-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
D71-21-02-6B	71-504		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
D71-21-02-6C	71-506		G-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
D71-21-02-6C	71-506		G-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
D71-21-02-6D	71-507		G-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
D71-21-02-6D	71-507		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
D71-21-02-6E	71-509		G-71-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
D71-21-02-6E	71-509		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
D71-21-02-6F	71-511		G-71-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
D71-21-02-6F	71-511		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
D71-31-01-A	71-519		P-06-161-01	CHECK/INSP	FIREWALL ASSEMBLY (FORWARD SURFACE)
D71-71-00-A	71-521		P-06-161-01	CHECK/INSP	ENGINE DRAINS TANK
D71-71-00-B	71-526		P-06-159-01 P-06-162-01	CHECK/INSP	ENGINE ZONE 2 DRAIN PIPE EXIT
D71-71-00-C	71-527		P-06-159-01 P-06-162-01	CHECK/INSP	ENGINE TURBINE DRAIN OUTLET
D71-71-01-A	71-520		P-06-161-01	CHECK/INSP	ENGINE DRAIN PIPES
D71-71-01-A	71-535	71-535-01		OPERATIONAL	ENGINE DRAIN LINES
D71-71-01-B	71-522		P-06-161-01	CHECK/INSP	FUEL PUMP & GOVERNOR DRAIN PIPE EXIT
D71-71-01-C	71-523		P-06-161-01	CHECK/INSP	ENGINE FMU OVERBOARD DRAIN PIPE EXIT
D71-71-01-D	71-524		P-06-161-01	CHECK/INSP	DRAINS SUMP O/BOARD DRAIN PIPE EXIT
D71-71-01-D	71-528		P-06-159-01 P-06-162-01	CHECK/INSP	CORE ENGINE ZONE 4B FAIRING DRAINS
D71-71-01-E	71-525		P-06-161-01	CHECK/INSP	SCUPPER DRAIN PIPE INLET/OUTLET
D72-00-00-2A	72-506		G-72-506-C1-1	BORESCOPE	ENG 1 COMBUSTION LINER/FUEL NOZZLES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
D72-00-00-2A	72-506		G-72-506-C1-2	BORESCOPE	ENG 2 COMBUSTION LINER/FUEL NOZZLES
D72-00-00-2B	72-508		G-72-506-C1-1	BORESCOPE	ENG 1 HP TURBINE NOZZLE GUIDE VANES
D72-00-00-2B	72-508		G-72-506-C1-2	BORESCOPE	ENG 2 HP TURBINE NOZZLE GUIDE VANES
D72-00-00-2C	72-510		G-72-506-C1-1	BORESCOPE	ENGINE 1 HP TURBINE BLADES
D72-00-00-2C	72-510		G-72-506-C1-2	BORESCOPE	ENGINE 2 HP TURBINE BLADES
D72-00-00-6A		72-506-C1-1		BORESCOPE	ENGINE 1 COMBUSTION LINER/HP TURBINE
D72-00-00-6A		72-506-C2-1		BORESCOPE	ENGINE 1 COMBUSTION LINER/HP TURBINE
D72-00-00-6B		72-506-C1-2		BORESCOPE	ENGINE 2 COMBUSTION LINER/HP TURBINE
D72-00-00-6B		72-506-C2-2		BORESCOPE	ENGINE 2 COMBUSTION LINER/HP TURBINE
D72-00-06-4A	72-518		P-06-161-01	CHECK/INSP	EXTERNAL GEARBOX SUSPENSION LINKS
D72-00-06-4B	72-519		P-06-161-01	CHECK/INSP	EXTERNAL GEARBOX-MOUNTED ACCESSORIES
D72-02-01-6A	72-521	72-521-01-1		CHECK/INSP	ENGINE 1 CORE-MOUNTED P2.5 PIPING
D72-02-01-6A	72-521	72-521-01-2		CHECK/INSP	ENGINE 2 CORE-MOUNTED P2.5 PIPING
D72-03-00-A		72-525-01-1		CHECK/INSP	ENGINE 1 COMPRESSOR FAIRINGS
D72-03-00-A		72-525-01-2		CHECK/INSP	ENGINE 2 COMPRESSOR FAIRINGS
D72-03-00-6A	72-516		P-06-159-01 P-06-162-01	CHECK/INSP	CORE FAIRINGS/INTERSERVICE PANELS
D72-03-00-6B	72-517		P-06-159-01 P-06-162-01	CHECK/INSP	PRESSURE RELIEF DOORS
D72-30-00-A	72-515		P-06-157-01 P-06-159-01	CHECK/INSP	FAN TRACK AND COLD STREAM DUCT
D72-30-01-A	72-507	72-507		REPLACE	HP COMPRESSOR ROTOR SHAFT ASSEMBLY
D72-31-01-6A	72-520		P-06-159-01	CHECK/INSP	LP COMPRESSOR OUTLET GUIDE VANES
D72-31-02-A	72-502	72-502		REPLACE	LP COMPRESSOR (FAN) BLADES
D72-31-04-A	72-501	72-501		REPLACE	LP COMPRESSOR (FAN) SHAFT AND DISC
D72-31-04-6A	72-514		P-06-157-01	CHECK/INSP	ENGINE LP COMPRESSOR ROTOR BLADES
D72-33-00-A	72-504	72-504		REPLACE	IP COMPRESSOR REAR STUB SHAFT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-90



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
D72-33-01-A	72-505	72-505		REPLACE	IC DISC STAGE 1 TO 7 ASSEMBLIES
D72-33-02-6A	72-503	72-503-01-1		CHECK/INSP	ENGINE 1 "A" FRAME ATTACHMENT POINTS
D72-33-02-6B	72-503	72-503-01-2		CHECK/INSP	ENGINE 2 "A" FRAME ATTACHMENT POINTS
D72-40-00-A	72-509	72-509		REPLACE	HP TURBINE DISC
D72-50-00-A	72-511	72-511		REPLACE	IP TURBINE SHAFT
D72-51-03-A	72-512	72-512		REPLACE	IP, LP1, LP2 AND LP3 TURBINE DISCS
D72-51-03-B	72-513	72-513		REPLACE	LP TURBINE SHAFT
D73-11-00-A	73-504		P-06-161-01	CHECK/INSP	ENGINE FUEL SUPPLY SYSTEM COMPONENTS
D73-11-00-B	73-506		P-06-162-01	CHECK/INSP	FUEL SUPPLY SYSTEM ACCESSORIES
D73-11-02-4A	73-501	73-501-01-1		REPLACE	ENGINE 1 LOW PRESSURE FUEL FILTER
D73-11-02-4B	73-501	73-501-01-2		REPLACE	ENGINE 2 LOW PRESSURE FUEL FILTER
D73-21-00-5A	73-507		P-06-162-01	CHECK/INSP	FUEL CONT SYSTEM P3.0 SIGNAL PIPING
D73-21-04-3A		73-509-01-1		CHECK/INSP	ENGINE 1 FAFC WATER TRAPS
D73-21-04-3A		73-509-01-2		CHECK/INSP	ENGINE 2 FAFC WATER TRAPS
D73-21-09-4A	73-505		P-06-161-01	CHECK/INSP	FULL AUTHORITY FUEL CONTROL/WIRING
D73-21-09-5A	73-502	73-502-01-1		OPERATIONAL	ENGINE 1 FAFC
D73-21-09-5B	73-502	73-502-01-2		OPERATIONAL	ENGINE 2 FAFC
D73-21-17-6A	73-503	73-503-01-1	W-06-160-01-1	CHECK/INSP	P2.0/T2.0 SENSOR, TUBE AND WIRING
D73-21-17-6A	73-503	73-503-01-2	W-60-160-01-2	CHECK/INSP	P2.0/T2.0 SENSOR, TUBE AND WIRING
D74-00-00-5A	74-501	74-501-01-1		OPERATIONAL	HIGH ENERGY IGNITION UNIT-10 JOULES
D74-00-00-5A	74-505	74-505-01-1		OPERATIONAL	ENGINE 1 TAI IGNITION ENGINE 1
D74-00-00-5B	74-502	74-502-01-1		OPERATIONAL	ENG 1 CONTINUOUS IGNITION (4 JOULES)
D74-00-00-5C	74-503	74-503-01-1		OPERATIONAL	ENGINE 1 STANDBY IGNITION
D74-00-00-5D	74-504	74-504-01-1		OPERATIONAL	ENGINE 1 APPROACH/LANDING IGNITION
D74-00-00-5E	74-501	74-501-01-2		OPERATIONAL	HIGH ENERGY IGNITION UNIT-10 JOULES
D74-00-00-5E	74-505	74-505-01-2		OPERATIONAL	ENGINE 2 TAI IGNITION

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
D74-00-00-5F	74-502	74-502-01-2		OPERATIONAL	ENG 2 CONTINUOUS IGNITION (4 JOULES)
D74-00-00-5G	74-503	74-503-01-2		OPERATIONAL	ENGINE 2 STANDBY IGNITION
D74-00-00-5H	74-504	74-504-01-2		OPERATIONAL	ENGINE 2 APPROACH/LANDING IGNITION
D74-11-01-6A		74-507-01-1		CHECK/INSP	ENG 1 HE IGNITION EXCITER UNIT CASE
D74-11-01-6B		74-507-01-2		CHECK/INSP	ENG 2 HE IGNITION EXCITER UNIT CASE
D74-21-02-6A	74-506	74-506-01-1		CHECK/INSP	ENGINE 1 IGNITOR PLUGS
D74-21-02-6A		74-506-02-1		CHECK/INSP	ENGINE 1 IGNITOR PLUGS
D74-21-02-6B	74-506	74-506-01-2		CHECK/INSP	ENGINE 2 IGNITER PLUGS
D74-21-02-6B		74-506-02-2		CHECK/INSP	ENGINE 2 IGNITER PLUGS
D75-21-00-A	75-501		P-06-159-01 P-06-162-01	CHECK/INSP	ENGINE RADIAL DRIVE FAIRINGS
D75-21-00-B	75-502		P-06-159-01 P-06-162-01 P-06-165-01	CHECK/INSP	INTERSERVICES AND PYLON SPLITTER
D75-21-00-C	75-504		P-06-157-01	CHECK/INSP	ENGINE ZONE 1 VENTILATION INLET
D75-21-00-D	75-505		P-06-163-01	CHECK/INSP	ENGINE ZONE 1 VENTILATION EXITS
D75-21-00-D	75-506		P-06-159-01 P-06-162-01	CHECK/INSP	ENGINE COMBUSTION FAIRINGS
D75-21-00-E		75-507-01-1		CHECK/INSP	ENGINE 1 CABIN AIR OFFTAKE DUCTING
D75-21-00-E		75-517-01-2		CHECK/INSP	ENGINE 2 CABIN AIR OFFTAKE DUCTING
D75-33-12-A	75-503		P-06-161-01	CHECK/INSP	ENGINE P2.5 PIPING
D77-35-00-B		77-505-01-1		OPERATIONAL	ENGINE 1 PIMU FAULT MESSAGES
D77-35-00-B		77-505-01-2		OPERATIONAL	ENGINE 2 PIMU FAULT MESSAGES
D77-35-00-2A	77-501	77-501-01-1		OPERATIONAL	ENGINE 1 PIMU FAULT MESSAGES
D77-35-00-2A	77-501	77-501-01-2		OPERATIONAL	ENGINE 2 PIMU FAULT MESSAGES
D77-35-00-2B	77-503	77-503-01-1		OPERATIONAL	ENGINE 1 EEC CATEGORY 2 FAULTS
D77-35-00-2B	77-503	77-503-01-2		OPERATIONAL	ENGINE 2 EEC CATEGORY 2 FAULTS
D77-41-00-5A	77-502	77-502-01		OPERATIONAL	STANDBY ENGINE INDICATOR

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-92



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
D78-11-00-6A	78-505		P-06-157-01 P-06-159-01	CHECK/INSP	ENGINE INTEGRATED NOZZLE ASSEMBLY
D78-11-00-6B	78-506		P-06-157-01 P-06-159-01	CHECK/INSP	ENGINE INA PROPULSION NOZZLE
D78-11-01-4A	78-507		P-06-159-01	CHECK/INSP	ENGINE EXHAUST FORCED MIXER
D78-11-03-6A	78-504		P-06-159-01	CHECK/INSP	ENGINE EXHAUST CONE
D78-30-00-A D78-30-00-B	78-514-C1-1			OPERATIONAL	ENG 1 T/R G/BOX LOCK AND AIRMOTOR BK
D78-30-00-A D78-30-00-B	78-514-C1-2			OPERATIONAL	ENG 2 T/R G/BOX LOCK AND AIRMOTOR BK
D78-30-00-A	78-514		G-78-514-C1-1	OPERATIONAL	ENG 1 T/R GEARBOX LOCKS
D78-30-00-A	78-514		G-78-514-C1-2	OPERATIONAL	ENG 2 T/R GEARBOX LOCKS
D78-30-00-B	78-515		G-78-514-C1-1	OPERATIONAL	ENG 1 THRUST REVERSER AIRMOTOR BRAKE
D78-30-00-B	78-515		G-78-514-C1-2	OPERATIONAL	ENG 2 THRUST REVERSER AIRMOTOR BRAKE
D78-31-00-2A	78-501	78-501-01-1		CHECK/INSP	ENG 1 T/R SCREWJACK/BALLNUT HOUSING
D78-31-00-2A	78-501	78-501-01-2		CHECK/INSP	ENG 2 T/R SCREWJACK/BALLNUT HOUSING
D78-31-00-6A	78-508		P-06-159-01 P-06-164-01	CHECK/INSP	ENGINE THRUST REVERSER PANELS
D78-31-00-6B	78-510		P-06-165-01	CHECK/INSP	TRANSLATING COWL AND FORWARD SEAL
D78-31-00-6C	78-511		P-06-164-01	CHECK/INSP	ENGINE T/R CASCADE INLET FAIRING
D78-31-00-6D	78-512		P-06-165-01	CHECK/INSP	BLOCKER DOORS/ATTACHMENT FEATURES
D78-31-00-6E	78-513		P-06-165-01	CHECK/INSP	ENGINE THRUST REVERSER CORONA
D78-31-08-A		78-523-01-1		CHECK/INSP	ENGINE 1 T/R SCREWJACK BALLNUT HSNB
D78-31-08-A		78-523-01-2		CHECK/INSP	ENGINE 2 T/R SCREWJACK BALLNUT HSNB
D78-31-09-6A	78-509		P-06-165-01	CHECK/INSP	ENGINE THRUST REVERSER CASCADE VANES
D78-31-16-6A	78-502	78-502-01-1		OPERATIONAL	ENGINE 1 AIR MOTOR FEEDBACK CABLE
D78-31-16-6A	78-502	78-502-01-2		OPERATIONAL	ENGINE 2 AIR MOTOR FEEDBACK CABLE
D78-36-00-5A	78-503	78-503-01-1		OPERATIONAL	ENGINE 1 T/R DISAGREEMENT CIRCUIT

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
D78-36-00-5B	78-517		G-78-516-C1	OPERATIONAL	THRUST REVERSER RELAY MODULE
D78-36-00-5C	78-516		G-78-516-C1	OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
D78-36-00-5D	78-503	78-503-01-2		OPERATIONAL	ENGINE 2 T/R DISAGREEMENT CIRCUIT
D78-36-00-5E D78-36-00-5C	78-516-C1-1			OPERATIONAL	T/R AIR/GND RELAY AND RELAY MODULE
D78-36-00-5F D78-36-00-5C	78-516-C1-2			OPERATIONAL	T/R AIR/GND RELAY AND RELAY MODULE
D79-00-00-6A	79-501	79-501-01-1		CHECK/INSP	ENGINE 1 MAGNETIC CHIP DETECTOR
D79-00-00-6A	79-501	79-501-01-2		CHECK/INSP	ENGINE 2 MAGNETIC CHIP DETECTOR
D79-21-00-A	79-504		P-06-161-01	CHECK/INSP	LUBRICATION SYSTEM ACCESSORIES
D79-21-05-6A	79-505	79-505-01-1		CHECK/INSP	ENG 1 CORE-MOUNTED LUBE COMPONENTS
D79-21-05-6A	79-505	79-505-01-2		CHECK/INSP	ENG 2 CORE-MOUNTED LUBE COMPONENTS
D79-21-07-4A	79-502	79-502-01-1		REPLACE	ENGINE 1 LUBRICATION PRESSURE FILTER
D79-21-07-4B	79-502	79-502-01-2		REPLACE	ENGINE 2 LUBRICATION PRESSURE FILTER
D79-21-08-4A	79-503	79-503-01-1		REPLACE	ENGINE 1 LUBRICATION SCAVENGE FILTER
D79-21-08-4B	79-503	79-503-01-2		REPLACE	ENGINE 2 LUBRICATION SCAVENGE FILTER
D80-11-00-6A	80-504		P-06-161-01	CHECK/INSP	ENGINE STARTER DUCTING AND CLAMPS
D80-11-01-6A	80-502	80-502-01-1		CHECK/INSP	ENGINE 1 STARTER CHIP DETECTOR
D80-11-01-6A	80-502	80-502-01-2		CHECK/INSP	ENGINE 2 STARTER CHIP DETECTOR
G71-00-00-6A	71-201		P-06-085-01	CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
G71-00-00-6B	71-202		P-06-087-01	CHECK/INSP	FAN COWL/CORE COWL HINGES
G71-00-00-6C	71-203		P-06-087-01	CHECK/INSP	FAN COWL/CORE COWL LATCHES
G71-00-00-6D	71-204		P-06-084-01	CHECK/INSP	INLET COWL AND FAN CASE FLANGES
G71-00-00-6E	71-205		P-06-084-01	CHECK/INSP	INLET COWL ATTACH BOLTS
G71-00-00-6F	71-207		P-06-091-01	CHECK/INSP	INTERNAL SURFACE OF THE CORE COWLS
G71-00-00-6G	71-208		P-06-086-01	CHECK/INSP	COWLING PRESSURE RELIEF DOORS
G71-00-00-6I	71-210		P-06-084-01	CHECK/INSP	AFT MOUNT STRUT/ENGINE ATTACH BOLTS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-94



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
G71-00-00-6J	71-211		P-06-084-01	CHECK/INSP	AFT MOUNT UPPER FITTING
G71-00-00-6K	71-212		P-06-084-01	CHECK/INSP	AFT MOUNT LOWER FITTING
G71-00-00-6L	71-213		P-06-084-01	CHECK/INSP	AFT MOUNT LINK
G71-00-00-6M	71-214		P-06-084-01	CHECK/INSP	DRAIN LINES
G71-00-00-6N	71-215		P-06-084-01	CHECK/INSP	L.P. RECOUP DRAIN LINES
G71-00-00-6O	71-216		P-06-084-01	CHECK/INSP	COMBUSTION CHAMBER DRAIN LINE
G71-00-00-6P	71-217	71-217-01-1		CHECK/INSP	STRUT DRAIN INLETS - ENG 1
G71-00-00-6P	71-217	71-217-01-2		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
G71-00-00-6Q	71-218		P-06-084-01	CHECK/INSP	FORWARD LOWER ENGINE MOUNT LINKS
G71-00-00-6R	71-219		P-06-084-01	CHECK/INSP	FWD LWR ENG MOUNT CENTER SWAY LINK
G71-00-00-6S	71-220		P-06-084-01	CHECK/INSP	FORWARD LWR ENGINE MOUNT SIDE LINKS
G71-00-00-6T	71-221		P-06-084-01	CHECK/INSP	FWD LWR ENGINE MOUNT ATTACH BOLTS
G71-00-00-6U	71-222		P-06-084-01	CHECK/INSP	FWD ENG MOUNT FAN FRAME STRUT LUGS
G71-11-03-4P	71-209	71-209-01-1		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - L
G71-11-03-4P	71-209	71-209-01-2		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - R
G71-11-10-2A		71-225-01-1		OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 1
G71-11-10-2A		71-225-01-2		OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 2
G71-21-00-A		71-226-01-1		CHECK/INSP	ENGINE 1 SPHERICAL BEARING
G71-21-00-A		71-226-01-2		CHECK/INSP	ENGINE 2 SPHERICAL BEARING
G72-00-00-6A G72-00-00-6B	72-207-C1-1			BORESCOPE	COMBUSTION LINER AND HPT BLADES
G72-00-00-6A G72-00-00-6B	72-207-C1-2			BORESCOPE	COMBUSTION LINER AND HPT BLADES
G72-00-00-6A	72-207		G-72-207-C1-1	BORESCOPE	BORESCOPE OF COMBUSTOR SECTION ENG 1
G72-00-00-6A	72-207		G-72-207-C1-2	BORESCOPE	BORESCOPE OF COMBUSTOR SECTION ENG 2
G72-00-00-6B	72-208		G-72-207-C1-1	BORESCOPE	STAGE 1 AND 2 HPT BLADES - ENG 1
G72-00-00-6B	72-208		G-72-207-C1-2	BORESCOPE	STAGE 1 AND 2 HPT BLADES - ENG 2

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
G72-21-00-A	72-203	72-203		REPLACE	FAN ROTOR & LP COMPRESSOR SECTION
G72-31-00-A	72-206	72-206		REPLACE	HPC DISKS/SPOOLS/SHAFT AND CDP SEAL
G72-31-02-6A	72-201		P-06-083-01	CHECK/INSP	FAN ROTOR BLADES
G72-31-02-6C	72-202	72-202-01-1	W-06-083-01	CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 1
G72-31-02-6C	72-202	72-202-01-2	W-06-083-01	CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 2
G72-33-04-6A	72-204		P-06-083-01	CHECK/INSP	FAN & LP COMPRESSOR FLOW PATH
G72-50-00-A	72-209	72-209		REPLACE	H.P. TURBINE DISKS,DIFFUSER,SPACER
G72-52-01-A	72-211	72-211		REPLACE	LP TURBINE DISKS/SHAFT
G72-53-01-6A	72-210		P-06-084-01	CHECK/INSP	AFT LOWER ENGINE MOUNT LUGS
G72-61-01-6A	72-213		P-06-084-01	CHECK/INSP	ACCESSORY GEAR MOUNTS
G72-61-01-6B	72-214		P-06-084-01	CHECK/INSP	ACCESSORY GEARBOX CASE/MOUNT BOSSES
G73-00-00-6A	73-202		P-06-084-01	CHECK/INSP	FUEL SYSTEM PIPING AND COMPONENTS
G73-00-00-6B	73-204		P-06-084-01	CHECK/INSP	FUEL FLOW TRANSMITTER
G73-00-00-6C	73-205		P-06-084-01	CHECK/INSP	FUEL FILTER DIFF PRESSURE SWITCH
G73-11-02-2A	73-203	73-203-01-1		REPLACE	FUEL FILTER ELEMENT - ENG 1
G73-11-02-2A	73-203	73-203-01-2		REPLACE	FUEL FILTER ELEMENT - ENG 2
G73-21-06-6A	73-206	73-206-51-1		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
G73-21-06-6A	73-206	73-206-51-2		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
G73-21-06-6A		73-206-52-1		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
G73-21-06-6A		73-206-52-2		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
G73-21-06-6A		73-206-53-1		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
G73-21-06-6A		73-206-53-2		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
G73-21-06-6A		73-206-54-1		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
G73-21-06-6A		73-206-54-2		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
G73-21-06-6A		73-206-55-1		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
G73-21-06-6A		73-206-55-2		OPERATIONAL	FLIGHT-IDLE SELECT SOLENOID - ENG 2

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-96



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
G73-21-07-5A	73-207	73-207-51-1		OPERATIONAL	FAIL-FIXED SOLENOID CIRCUIT - ENG 1
G73-21-07-5A	73-207	73-207-51-2		OPERATIONAL	FAIL-FIXED SOLENOID CIRCUIT - ENG 2
G73-34-00-5A		73-206-01-1		FUNCTIONAL	FUEL FILTER BYPASS WARNING SYSTEM -L
G73-34-00-5A		73-206-01-2		FUNCTIONAL	FUEL FILTER BYPASS WARNING SYSTEM -R
G74-00-00-5A	74-201	74-201-01-1		FUNCTIONAL	IGNITION SYSTEM - ENG 1
G74-00-00-5A	74-201	74-201-01-2		FUNCTIONAL	IGNITION SYSTEM - ENG 2
G74-00-00-5B		74-202-01		OPERATIONAL	IGNITION CONTROL SYSTEMS
G75-00-00-6A	75-201		P-06-084-01	CHECK/INSP	SUMP PRESSURIZING TUBING
G75-00-00-6B	75-202		P-06-084-01	CHECK/INSP	11TH STAGE TUBING
G75-00-00-6C	75-203		P-06-084-01	CHECK/INSP	7TH STAGE TUBING
G75-00-00-6D	75-204		P-06-084-01	CHECK/INSP	RAM AIR SCOOP
G75-00-00-6E	75-205		P-06-084-01	CHECK/INSP	IGNITION COOLING TUBING
G75-00-00-6F	75-206		P-06-084-01	CHECK/INSP	CDP SIGNAL TUBE
G75-00-00-6G	75-207		P-06-084-01	CHECK/INSP	7TH STAGE SIGNAL LINE
G75-00-00-6H	75-208		P-06-084-01	CHECK/INSP	JET EDUCTOR
G75-31-03-6A	73-201		P-06-084-01	CHECK/INSP	VSV MECH LINKAGE & FEEDBACK CABLES
G75-32-02-6A	73-201		P-06-084-01	CHECK/INSP	VBV MECH LINKAGE & FEEDBACK CABLES
G76-11-00-6A	76-203		P-06-084-01	CHECK/INSP	ENGINE AREA PUSH-PULL CABLE SYSTEM
G76-11-00-6B	76-202		P-06-092-01	CHECK/INSP	STRUT AREA PUSH-PULL CABLE SYSTEM
G76-11-00-6C	76-204		P-06-084-01	CHECK/INSP	ENG CONDITION CONTROL MOTOR ACTUATOR
G76-11-00-6D	76-205		P-06-084-01	CHECK/INSP	ENG CONDITION CONTROL MOTOR ACTUATOR
G77-00-00-6A	77-201		P-06-084-01	CHECK/INSP	EEC (PMC) GENERATOR CABLE
G77-00-00-6B	77-202		P-06-084-01	CHECK/INSP	EGT THERMOCOUPLE CONNECTORS & JCT BX
G77-00-00-6C	77-203		P-06-084-01	CHECK/INSP	EXPOSED EGT THERMOCOUPLE HARNESS
G77-00-00-6D	77-204	77-204-01		OPERATIONAL	STANDBY ENGINE INDICATOR
G78-00-00-6A	71-206		P-06-088-01	CHECK/INSP	T/R INNER COWL INSULATION AND SEALS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
G78-00-00-6B	78-201		P-06-084-01	CHECK/INSP	TURBINE EXHAUST SLEEVE AND PLUG
G78-00-00-6C	78-202		P-06-084-01	CHECK/INSP	TURBINE EXHAUST SLEEVE SPRING SEALS
G78-00-00-6D	78-203		P-06-084-01	CHECK/INSP	TURBINE EXHAUST HONEYCOMB SLEEVES
G78-00-00-6E	78-204		P-06-089-01	CHECK/INSP	FAN DUCT COWL & THRUST REVERSER
G78-00-00-6F	78-206		P-06-088-01	CHECK/INSP	THRUST REVERSER HYDRAULIC TUBING
G78-00-00-6G	78-208		P-06-088-01	CHECK/INSP	FAN DUCT TENSION LATCHES
G78-00-00-6H	78-209		P-06-088-01	CHECK/INSP	FAN DUCT V-GROOVE LATCH BANDS
G78-00-00-6I	78-210		P-06-088-01	CHECK/INSP	FAN DUCT COWL & THRUST REV HINGES
G78-00-00-6J	78-211	78-211-01-1		CHECK/INSP	LOUVERED EXHAUST DOOR HINGES/LATCHES
G78-00-00-6J	78-211	78-211-01-2		CHECK/INSP	LOUVERED EXHAUST DOOR HINGES/LATCHES
G78-00-00-6K	78-212		P-06-088-01	CHECK/INSP	THRUST REVERSER FAN FLOW PATH
G78-00-00-6L	78-213		P-06-097-01	CHECK/INSP	THRUST REVERSER ISOLATION VALVE
G78-00-00-6M	78-214		P-06-089-01	CHECK/INSP	THRUST REVERSER STOW SENSORS
G78-00-00-6N	78-215		P-06-088-01	CHECK/INSP	THRUST REVERSER FEEDBACK LINKAGE
G78-00-00-6O	78-216		P-06-088-01	CHECK/INSP	THRUST REVERSER UNLOCK SENSORS
G78-00-00-6P	78-217		P-06-088-01	CHECK/INSP	THRUST REVERSER DEPLOY SENSOR
G78-00-00-6Q	78-218		P-06-097-01	CHECK/INSP	ISOLATION VALVE PRESSURE SWITCH
G78-00-00-6R		78-219-51-1		CHECK/INSP	NACELLE/STRUT FIRE/DRAINAGE SEALS -L
G78-00-00-6R		78-219-51-2		CHECK/INSP	NACELLE/STRUT FIRE/DRAINAGE SEALS -R
G78-00-00-6S	78-212	78-212-02-1		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS
G78-00-00-6S	78-212	78-212-02-2		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS
G78-00-00-6T G78-00-00-6U	78-220-C1-1			CHECK/INSP	ENG 1 T/R BULL-NOSE SEAL AND FAIRING
G78-00-00-6T G78-00-00-6U	78-220-C1-2			CHECK/INSP	ENG 2 T/R BULL-NOSE SEAL AND FAIRING
G78-00-00-6T			G-78-220-C1-1	CHECK/INSP	ENG 1 THRUST REVERSER BULL-NOSE SEAL
G78-00-00-6T			G-78-220-C1-2	CHECK/INSP	ENG 2 THRUST REVERSER BULL-NOSE SEAL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-98



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
G78-00-00-6U			G-78-220-C1-1	CHECK/INSP	ENG 1 T/R BULL-NOSE FAIRING
G78-00-00-6U			G-78-220-C1-2	CHECK/INSP	ENG 2 T/R BULL-NOSE FAIRING
G78-11-00-6A	72-212		P-06-084-01	CHECK/INSP	EXHAUST PLUG/SLEEVE ATTACHMENT
G78-31-00-5A G78-31-00-5B	78-224-C1-1			OPERATIONAL	ENG 1 T/R LOCKING HYDRAULIC ACTUATOR
G78-31-00-5A G78-31-00-5B	78-224-C1-2			OPERATIONAL	ENG 2 T/R LOCKING HYDRAULIC ACTUATOR
G78-31-00-5A	78-224		G-78-224-C1-1	OPERATIONAL	ENG 1 T/R UPPER LOCKING HYD ACTRS
G78-31-00-5A	78-224		G-78-224-C1-2	OPERATIONAL	ENG 2 T/R UPPER LOCKING HYD ACTRS
G78-31-00-5B	78-225		G-78-224-C1-1	OPERATIONAL	ENG 1 T/R CENTER LOCKING HYD ACTRS
G78-31-00-5B	78-225		G-78-224-C1-2	OPERATIONAL	ENG 2 T/R CENTER LOCKING HYD ACTRS
G78-31-11-6A	78-205		P-06-089-01	CHECK/INSP	TRACKS, LINERS AND SLIDERS
G78-31-13-6B		78-237-01-1		CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
G78-31-13-6B		78-237-01-2		CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
G78-31-16-6A	78-207		P-06-089-01	CHECK/INSP	CASCADE VANES
G78-31-20-2A		78-220-01-1		CLEAN	HYDRAULIC COWL OPENING PUMP FILTER
G78-31-20-2A		78-220-01-2		CLEAN	HYDRAULIC COWL OPENING PUMP FILTER
G78-34-07-A G78-34-07-B	78-223-C1-1			FUNCTIONAL	ENG 1 T/R SYNC LOCK AND CIRCUITRY
G78-34-07-A G78-34-07-B	78-223-C1-2			FUNCTIONAL	ENG 2 T/R SYNC LOCK AND CIRCUITRY
G78-34-07-A	78-223		G-78-223-C1-1	OPERATIONAL	ENG 1 THRUST REVERSER SYNC-LOCK
G78-34-07-A	78-223		G-78-223-C1-2	OPERATIONAL	ENG 2 THRUST REVERSER SYNC-LOCK
G78-34-07-B	78-220		G-78-223-C1-1	FUNCTIONAL	ENG 1 T/R SYNC LOCK CONTROL CIRCUIT
G78-34-07-B	78-220		G-78-223-C1-2	FUNCTIONAL	ENG 2 T/R SYNC LOCK CONTROL CIRCUIT
G78-36-00-5A		78-222-01-1		OPERATIONAL	T/R DISAGREEMENT CIRCUIT - L ENGINE
G78-36-00-5B		78-222-01-2		OPERATIONAL	T/R DISAGREEMENT CIRCUIT - R ENGINE
G78-36-00-5C	78-221	78-221-52		OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
G78-36-07-5A	78-222	78-222-51		OPERATIONAL	THRUST REVERSER RELAY MODULE
G79-00-00-6A	79-202		P-06-084-01	CHECK/INSP	EXPOSED LUBRICATION SYSTEM PIPING
G79-00-00-6B	79-203		P-06-084-01	CHECK/INSP	OIL QUANTITY TRANSMITTER AND WIRING
G79-00-00-6C	79-204		P-06-084-01	CHECK/INSP	OIL PRESSURE TRANSMITTER
G79-00-00-6D	79-205		P-06-084-01	CHECK/INSP	LOW OIL PRESSURE WARNING SWITCH
G79-00-00-6E	79-206		P-06-084-01	CHECK/INSP	OIL TEMPERATURE BULB
G79-00-00-6F	79-207		P-06-084-01	CHECK/INSP	OIL FILTER DIFFERENTIAL PRESS SWITCH
G79-21-04-4A	79-201	79-201-01-1		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 1
G79-21-04-4A	79-201	79-201-01-2		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 2
G79-21-05-2A	72-205	72-205-01-1		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 1
G79-21-05-2A	72-205	72-205-01-2		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 2
G79-21-07-4A		79-208-01-1		REPLACE	LUBE FILTER ELEMENT - ENG 1
G79-21-07-4A		79-208-01-2		REPLACE	LUBE FILTER ELEMENT - ENG 2
G79-35-00-5A		79-210-01-1		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM - L
G79-35-00-5A		79-210-01-2		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM - R
G80-11-00-6A	80-203		P-06-084-01	CHECK/INSP	START SYSTEM DUCTING AND CLAMPS
G80-11-01-6A	80-202	80-202-01-1		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 1
G80-11-01-6A	80-202	80-202-01-2		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 2
G80-11-04-2A		80-204-01-1		RESTORE	START VALVE FILTER - ENG 1
G80-11-04-2A		80-204-01-2		RESTORE	START VALVE FILTER - ENG 2
H71-00-00-6A	71-301		P-06-085-01	CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
H71-00-00-6B	71-302		P-06-087-01	CHECK/INSP	FAN COWL/CORE COWL HINGES
H71-00-00-6C	71-303		P-06-087-01	CHECK/INSP	FAN COWL/CORE COWL LATCHES
H71-00-00-6D	71-304		P-06-084-01	CHECK/INSP	INLET COWL AND FAN CASE FLANGES
H71-00-00-6E	71-305		P-06-084-01	CHECK/INSP	INLET COWL ATTACH BOLTS
H71-00-00-6F	71-307		P-06-091-01	CHECK/INSP	INTERNAL SURFACE OF THE CORE COWLS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-100



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
H71-00-00-6G	71-308		P-06-086-01	CHECK/INSP	COWLING PRESSURE RELIEF DOORS
H71-00-00-6I	71-310		P-06-084-01	CHECK/INSP	AFT MOUNT STRUT/ENGINE ATTACH BOLTS
H71-00-00-6J	71-311		P-06-084-01	CHECK/INSP	AFT MOUNT UPPER FITTING
H71-00-00-6K	71-312		P-06-084-01	CHECK/INSP	AFT MOUNT LOWER FITTING
H71-00-00-6L	71-313		P-06-084-01	CHECK/INSP	AFT MOUNT LINK
H71-00-00-6M	71-314		P-06-084-01	CHECK/INSP	DRAIN LINES
H71-00-00-6O	71-316		P-06-084-01	CHECK/INSP	COMBUSTION CHAMBER DRAIN LINE
H71-00-00-6P	71-317	71-317-01-1		CHECK/INSP	STRUT DRAIN INLETS - ENG 1
H71-00-00-6P	71-317	71-317-01-2		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
H71-00-00-6Q	71-318		P-06-084-01	CHECK/INSP	FORWARD LOWER ENGINE MOUNT LINKS
H71-00-00-6S	71-320		P-06-084-01	CHECK/INSP	FORWARD LWR ENGINE MOUNT SIDE LINKS
H71-00-00-6U	71-322		P-06-084-01	CHECK/INSP	FWD ENG MOUNT FAN FRAME STRUT LUGS
H71-11-01-A		71-327-C1-1		BORESCOPE	ENGINE 1 ANTI-ICE TUBE LINK ASSEMBLY
H71-11-01-A		71-327-C1-2		BORESCOPE	ENGINE 2 ANTI-ICE TUBE LINK ASSEMBLY
H71-11-01-A			G-71-327-C1-1	BORESCOPE	ENGINE 1 ANTI-ICE TUBE LINK ASSEMBLY
H71-11-01-A			G-71-327-C1-2	BORESCOPE	ENGINE 2 ANTI-ICE TUBE LINK ASSEMBLY
H71-11-01-B			G-71-327-C1-1	BORESCOPE	ENGINE 1 ANTI-ICE AIR DEFLECTORS
H71-11-01-B			G-71-327-C1-2	BORESCOPE	ENGINE 2 ANTI-ICE AIR DEFLECTORS
H71-11-11-2A		71-325-01-1		OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 1
H71-11-11-2A		71-325-01-2		OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 2
H71-21-00-A		71-326-01-1		CHECK/INSP	ENGINE 1 SPHERICAL BEARING
H71-21-00-A		71-326-01-2		CHECK/INSP	ENGINE 2 SPHERICAL BEARING
H71-21-01-A	71-323	71-323-51		DISCARD	FWD ENG MNT THRUST LINKS AND BOLTS
H71-71-00-6B		71-329-01-1		CHECK/INSP	ENGINE 1 STRUT DRAINS
H71-71-00-6B		71-329-01-2		CHECK/INSP	ENGINE 2 STRUT DRAINS
H71-71-00-6B		71-329-02-1		CHECK/INSP	ENGINE 1 STRUT DRAINS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
H71-71-00-6B		71-329-02-2		CHECK/INSP	ENGINE 2 STRUT DRAINS
H72-00-00-6A H72-00-00-6B	72-307-C1-1			BORESCOPE	COMBUSTION LINER AND HPT BLADES
H72-00-00-6A H72-00-00-6B	72-307-C1-2			BORESCOPE	COMBUSTION LINER AND HPT BLADES
H72-00-00-6A	72-307		G-72-307-C1-1	BORESCOPE	BORESCOPE OF COMBUSTOR SECTION ENG 1
H72-00-00-6A	72-307		G-72-307-C1-2	BORESCOPE	BORESCOPE OF COMBUSTOR SECTION ENG 2
H72-00-00-6B	72-308		G-72-307-C1-1	BORESCOPE	STAGE 1 AND 2 HPT BLADES - ENG 1
H72-00-00-6B	72-308		G-72-307-C1-2	BORESCOPE	STAGE 1 AND 2 HPT BLADES - ENG 2
H72-30-00-A	72-303	72-303		REPLACE	FAN ROTOR & LP COMPRESSOR SECTION
H72-30-00-B	72-306	72-306		REPLACE	HPC DISKS/SPOOLS/SHAFT AND CDP SEAL
H72-31-02-6A	72-301		P-06-083-01	CHECK/INSP	FAN ROTOR BLADES
H72-31-02-6C	72-302	72-302-01-1		CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 1
H72-31-02-6C	72-302	72-302-01-2		CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 2
H72-32-00-6A	72-304		P-06-083-01	CHECK/INSP	FAN & LP COMPRESSOR FLOW PATH
H72-50-00-A	72-309	72-309		REPLACE	H.P. TURBINE DISKS,DIFFUSER,SPACER
H72-50-00-B	72-311	72-311		REPLACE	LP TURBINE DISKS/SHAFT
H72-50-00-6A	72-310		P-06-084-01	CHECK/INSP	AFT LOWER ENGINE MOUNT LUGS
H72-60-00-A	72-315		P-06-084-01	CHECK/INSP	ACCESSORY GEARBOX CLEVISSES AND BOLTS
H72-60-00-B	72-313		P-06-084-01	CHECK/INSP	ACCESSORY GEARBOX MOUNTS
H72-60-00-C	72-314		P-06-084-01	CHECK/INSP	ACCESSORY GEARBOX CASE/MOUNT BOSSES
H73-11-02-4A	73-303	73-303-01-1		REPLACE	FUEL FILTER ELEMENT - ENG 1
H73-11-02-4A	73-303	73-303-01-2		REPLACE	FUEL FILTER ELEMENT - ENG 2
H73-11-06-A	73-302		P-06-084-01	CHECK/INSP	FUEL SYSTEM PIPING AND COMPONENTS
H73-21-00-A	76-305		P-06-084-01	CHECK/INSP	MAIN ENGINE CONTROL SWITCH WIRING
H73-21-01-6A	76-304		P-06-084-01	CHECK/INSP	ENGINE MAIN CONTROL
H73-31-01-A	73-304		P-06-084-01	CHECK/INSP	FUEL FLOW TRANSMITTER

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-102



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
H73-34-00-5A		73-306-01-1		FUNCTIONAL	FUEL FILTER BYPASS WARNING SYSTEM -L
H73-34-00-5A		73-306-01-2		FUNCTIONAL	FUEL FILTER BYPASS WARNING SYSTEM -R
H73-34-01-A	73-305		P-06-084-01	CHECK/INSP	FUEL FILTER DIFF PRESSURE SWITCH
H74-00-00-5A	74-301	74-301-01-1		FUNCTIONAL	IGNITION SYSTEM - ENG 1
H74-00-00-5A	74-301	74-301-01-2		FUNCTIONAL	IGNITION SYSTEM - ENG 2
H74-00-00-5A		74-301-02-1		FUNCTIONAL	ENGINE 1 IGNITION SYSTEM
H74-00-00-5A		74-301-02-2		FUNCTIONAL	ENGINE 2 IGNITION SYSTEM
H74-00-00-5A		74-301-03-1		FUNCTIONAL	ENGINE 1 IGNITION SYSTEM
H74-00-00-5A		74-301-03-2		FUNCTIONAL	ENGINE 2 IGNITION SYSTEM
H74-00-00-5A		74-301-04-1		FUNCTIONAL	ENGINE 1 IGNITION SYSTEM
H74-00-00-5A		74-301-04-2		FUNCTIONAL	ENGINE 2 IGNITION SYSTEM
H74-00-00-5B		74-302-01		OPERATIONAL	IGNITION CONTROL SYSTEMS
H74-00-00-5B		74-302-02		OPERATIONAL	IGNITION CONTROL SYSTEMS
H74-00-00-5B		74-302-03		OPERATIONAL	IGNITION CONTROL SYSTEMS
H74-00-00-5B		74-302-04		OPERATIONAL	IGNITION CONTROL SYSTEMS
H75-00-00-6A	75-301		P-06-084-01	CHECK/INSP	SUMP PRESSURIZING TUBING
H75-00-00-6B	75-302		P-06-084-01	CHECK/INSP	11TH STAGE TUBING
H75-00-00-6C	75-303		P-06-084-01	CHECK/INSP	7TH STAGE TUBING
H75-00-00-6E	75-305		P-06-084-01	CHECK/INSP	IGNITION COOLING TUBING
H75-00-00-6F	75-306		P-06-084-01	CHECK/INSP	CDP SIGNAL TUBE
H75-24-00-A	75-312		P-06-084-01	CHECK/INSP	LPT/HPT CASE COOLING PIPING
H75-31-03-6A	73-301		P-06-084-01	CHECK/INSP	VSV MECH LINKAGE & FEEDBACK CABLES
H75-32-02-6A	73-301		P-06-084-01	CHECK/INSP	VBV MECH LINKAGE & FEEDBACK CABLES
H76-11-00-6A	76-303		P-06-084-01	CHECK/INSP	ENGINE AREA PUSH-PULL CABLE SYSTEM
H76-11-00-6B	76-302		P-06-092-01	CHECK/INSP	STRUT AREA PUSH-PULL CABLE SYSTEM
H77-00-00-6A	77-301		P-06-084-01	CHECK/INSP	EEC (PMC) GENERATOR CABLE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
H77-00-00-6B	77-302		P-06-084-01	CHECK/INSP	EGT THERMOCOUPLE CONNECTORS & JCT BX
H77-00-00-6C	77-303		P-06-084-01	CHECK/INSP	EXPOSED EGT THERMOCOUPLE HARNESS
H77-35-00-2A	77-305	77-305-01		OPERATIONAL	PIMU FAULT MESSAGES
H77-35-00-2B	77-306	77-306-01		OPERATIONAL	EEC CATEGORY 2 FAULTS
H77-41-00-5A	77-304	77-304-01		OPERATIONAL	STANDBY ENGINE INDICATOR
H78-00-00-A	78-324		P-06-088-01	CHECK/INSP	T/R FIRE PROTECTION BLANKETS
H78-00-00-B	78-312	78-312-02-1		CHECK/INSP	THRUST REVERSER BLOCKER DOORS
H78-00-00-B	78-312	78-312-02-2		CHECK/INSP	THRUST REVERSER BLOCKER DOORS
H78-00-00-6A	71-306		P-06-088-01	CHECK/INSP	T/R INNER COWL INSULATION AND SEALS
H78-00-00-6B	78-301		P-06-084-01	CHECK/INSP	TURBINE EXHAUST SLEEVE AND PLUG
H78-00-00-6C	78-302		P-06-084-01	CHECK/INSP	TURBINE EXHAUST SLEEVE SPRING SEALS
H78-00-00-6D	78-303		P-06-084-01	CHECK/INSP	TURBINE EXHAUST HONEYCOMB SLEEVES
H78-00-00-6E	78-304		P-06-089-01	CHECK/INSP	FAN DUCT COWL & THRUST REVERSER
H78-00-00-6G	78-308		P-06-088-01	CHECK/INSP	FAN DUCT TENSION LATCHES
H78-00-00-6I	78-310		P-06-088-01	CHECK/INSP	FAN DUCT COWL & THRUST REV HINGES
H78-00-00-6K	78-312		P-06-088-01	CHECK/INSP	THRUST REVERSER FAN FLOW PATH
H78-00-00-6R		78-319-51-1		CHECK/INSP	NACELLE/STRUT FIRE/DRAINAGE SEALS -L
H78-00-00-6R		78-319-51-2		CHECK/INSP	NACELLE/STRUT FIRE/DRAINAGE SEALS -R
H78-00-00-6T H78-00-00-6U	78-330-C1-1			CHECK/INSP	ENG 1 T/R BULL-NOSE SEAL AND FAIRING
H78-00-00-6T H78-00-00-6U	78-330-C1-2			CHECK/INSP	ENG 2 T/R BULL-NOSE SEAL AND FAIRING
H78-00-00-6T	78-330		G-78-330-C1-1	CHECK/INSP	ENG 1 THRUST REVERSER BULL-NOSE SEAL
H78-00-00-6T	78-330		G-78-330-C1-2	CHECK/INSP	ENG 2 THRUST REVERSER BULL-NOSE SEAL
H78-00-00-6U			G-78-330-C1-1	CHECK/INSP	ENG 1 T/R BULL-NOSE FAIRING
H78-00-00-6U			G-78-330-C1-2	CHECK/INSP	ENG 2 T/R BULL-NOSE FAIRING
H78-11-00-6A	72-312		P-06-084-01	CHECK/INSP	EXHAUST PLUG/SLEEVE ATTACHMENT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-104



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
H78-31-00-A	78-322	78-322-01-1		CHECK/INSP	L T/R BALLSCREW ACTUATOR ATTACH PT
H78-31-00-A	78-322	78-322-01-2		CHECK/INSP	R T/R BALLSCREW ACTUATOR ATTACH PT
H78-31-00-B	78-325		P-06-087-01	CHECK/INSP	T/R STOW/NOT-STOWED SWITCHES & WIRES
H78-31-00-C	78-326		P-06-087-01	CHECK/INSP	T/R DEPLOY/NOT DEPLOYED SWITCHES
H78-31-11-6A	78-305		P-06-089-01	CHECK/INSP	TRACKS, LINERS AND SLIDERS
H78-31-14-6A		78-323-02-1	W-78-323-03-1	CHECK/INSP	ENGINE 1 T/R BLOCKER DOOR HINGES
H78-31-14-6A		78-323-02-2	W-78-323-03-2	CHECK/INSP	ENGINE 2 T/R BLOCKER DOOR HINGES
H78-31-15-6A	78-323		G-78-323-01-1	CHECK/INSP	L T/R BLOCKER DOOR HINGES & LINKS
H78-31-15-6A	78-323		G-78-323-01-2	CHECK/INSP	R T/R BLOCKER DOOR HINGES & LINKS
H78-31-16-6A	78-307		P-06-089-01	CHECK/INSP	CASCADE VANES
H78-31-21-A	78-331	78-331-51-1		OPERATIONAL	T/R CENTER DRIVE UNIT CONE BRAKE
H78-31-21-A	78-331	78-331-51-2		OPERATIONAL	T/R CENTER DRIVE UNIT CONE BRAKE
H78-34-00-5A		78-333-01-1		FUNCTIONAL	ENG 1 DIRECTIONAL PILOT VALVE LEAK
H78-34-00-5A		78-333-01-2		FUNCTIONAL	ENG 2 DIRECTIONAL PILOT VALVE LEAK
H78-34-01-2A		78-332-01-1		CLEAN	ENG 1 DIRECTIONAL PILOT VALVE FILTER
H78-34-01-2A		78-332-01-2		CLEAN	ENG 2 DIRECTIONAL PILOT VALVE FILTER
H78-34-07-A	78-332	78-332-51-1		OPERATIONAL	ENGINE 1 T/R ACTUATION SYSTEM BRAKE
H78-34-07-A	78-332	78-332-51-2		OPERATIONAL	ENGINE 2 T/R ACTUATION SYSTEM BRAKE
H78-34-07-B		78-342-01-1		REPLACE	ENGINE 1 T/R ACTUATION SYSTEM BRAKE
H78-34-07-B		78-342-01-2		REPLACE	ENGINE 2 T/R ACTUATION SYSTEM BRAKE
H78-36-00-5A	78-327	78-327-01-1		FUNCTIONAL	ENG 1 T/R PNEUMATIC PRESSURE SWITCH
H78-36-00-5A		78-327-01-3		FUNCTIONAL	ENG 1 T/R PNEUMATIC PRESSURE SWITCH
H78-36-00-5B	78-327	78-327-01-2		FUNCTIONAL	ENG 2 T/R PNEUMATIC PRESSURE SWITCH
H78-36-00-5B		78-327-01-4		FUNCTIONAL	ENG 2 T/R PNEUMATIC PRESSURE SWITCH
H78-36-00-5C	78-329	78-329-01-1		OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES
H78-36-00-5C		78-329-01-3		OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
H78-36-00-5D	78-329	78-329-01-2		OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES
H78-36-00-5D		78-329-01-4		OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES
H78-36-00-5E H78-36-00-5I H78-36-00-5G	78-327-C1-1			FUNCTIONAL	ENG 1 T/R INDICATION CIRCUIT CHECK
H78-36-00-5E H78-36-00-5G H78-36-00-5I	78-327-C1-3			FUNCTIONAL	ENG 1 T/R INDICATION CIRCUIT CHECK
H78-36-00-5E	78-328		G-78-327-C1-1	OPERATIONAL	ENGINE 1 T/R DISAGREEMENT CIRCUIT
H78-36-00-5F H78-36-00-5J H78-36-00-5H	78-327-C1-2			FUNCTIONAL	ENG 2 T/R INDICATION CIRCUIT CHECK
H78-36-00-5F H78-36-00-5H H78-36-00-5J	78-327-C1-4			FUNCTIONAL	ENG 2 T/R INDICATION CIRCUIT CHECK
H78-36-00-5F	78-328		G-78-327-C1-2	OPERATIONAL	ENG 2 T/R DISAGREEMENT CIRCUIT
H78-36-00-5G	78-333		G-78-327-C1-1	OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
H78-36-00-5H	78-327		G-78-327-C1-2	OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
H78-36-00-5I	78-334		G-78-327-C1-1	OPERATIONAL	THRUST REVERSER RELAY MODULE
H78-36-00-5J	78-000		G-78-327-C1-2	OPERATIONAL	THRUST REVERSER RELAY MODULE
H79-00-00-6A	79-302		P-06-084-01	CHECK/INSP	EXPOSED LUBRICATION SYSTEM PIPING
H79-00-00-6B	79-303		P-06-084-01	CHECK/INSP	OIL QUANTITY TRANSMITTER AND WIRING
H79-00-00-6C	79-304		P-06-084-01	CHECK/INSP	OIL PRESSURE TRANSMITTER
H79-00-00-6D	79-305		P-06-084-01	CHECK/INSP	LOW OIL PRESSURE WARNING SWITCH
H79-00-00-6E	79-306		P-06-084-01	CHECK/INSP	OIL TEMPERATURE BULB
H79-00-00-6F	79-307		P-06-084-01	CHECK/INSP	OIL FILTER DIFFERENTIAL PRESS SWITCH
H79-21-04-4A	79-301	79-301-01-1		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 1
H79-21-04-4A	79-301	79-301-01-2		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 2
H79-21-05-2A	72-305	72-305-01-1		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 1

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-106



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
H79-21-05-2A	72-305	72-305-01-2		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 2
H79-21-07-4A		79-308-01-1		REPLACE	LUBE FILTER ELEMENT - ENG 1
H79-21-07-4A		79-308-01-2		REPLACE	LUBE FILTER ELEMENT - ENG 2
H79-35-00-5A		79-310-01-1		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM - L
H79-35-00-5A		79-310-01-2		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM - R
H80-11-00-6A	80-303		P-06-084-01	CHECK/INSP	START SYSTEM DUCTING AND CLAMPS
H80-11-01-6A	80-302	80-302-01-1		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 1
H80-11-01-6A	80-302	80-302-01-2		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 2
H80-11-04-2A		80-304-01-1		RESTORE	START VALVE FILTER - ENG 1
H80-11-04-2A		80-304-01-2		RESTORE	START VALVE FILTER - ENG 2
N71-00-00-B	71-403		P-06-146-01	CHECK/INSP	FAN COWL/CORE COWL LATCHES
N71-00-00-C	71-404		P-06-145-01	CHECK/INSP	INLET COWL FLANGE & FAN CASE FLANGE
N71-00-00-D	71-405		P-06-145-01	CHECK/INSP	INLET COWL ATTACH BOLTS
N71-00-00-E	71-406	71-406-01-1	W-06-147-01-1	CHECK/INSP	EXTERNAL SURFACE OF THE CORE COWLS
N71-00-00-E	71-406	71-406-01-2	W-06-147-01-2	CHECK/INSP	EXTERNAL SURFACE OF THE CORE COWLS
N71-00-00-F	71-407		P-06-149-01	CHECK/INSP	INTERNAL SURFACE OF THE CORE COWLS
N71-00-00-G	71-408	71-408-01-1	W-06-149-01	CHECK/INSP	CORE COWL PRESSURE RELIEF DOORS
N71-00-00-G	71-408	71-408-01-2	W-06-149-01	CHECK/INSP	CORE COWL PRESSURE RELIEF DOORS
N71-00-00-H	71-402		P-06-146-01	CHECK/INSP	FAN COWL/CORE COWL HINGES
N71-00-00-N	71-418		P-06-145-01	CHECK/INSP	ENGINE DRAIN LINES
N71-00-00-O	71-419		P-06-145-01	CHECK/INSP	DRAIN COLLECTOR SEAL
N71-00-00-6A	71-421	71-421-01-1		CHECK/INSP	STRUT 1 DRAIN INLETS
N71-00-00-6A	71-421	71-421-01-2		CHECK/INSP	STRUT 2 DRAIN INLETS
N71-11-00-A	71-409	71-409-01-1		CHECK/INSP	LEFT INLET COWL ACOUSTIC PANELS
N71-11-00-A	71-409	71-409-01-2		CHECK/INSP	RIGHT INLET COWL ACOUSTIC PANELS
N71-11-01-A	71-401	71-401-01-1		CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N71-11-01-A	71-401	71-401-01-2		CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
N71-11-10-2A		71-424-01-1		OPERATIONAL	ENGINE 1 COWL HOLD-OPEN RODS
N71-11-10-2A		71-424-01-2		OPERATIONAL	ENGINE 2 COWL HOLD-OPEN RODS
N71-21-00-A	71-410	71-410-01-1	W-06-145-01	CHECK/INSP	ENG 1 FORWARD ENG MOUNT COMPONENTS
N71-21-00-A	71-410	71-410-01-2	W-06-145-01	CHECK/INSP	ENG 2 FORWARD ENG MOUNT COMPONENTS
N71-21-00-B	71-416	71-416-01-1	W-06-145-01	CHECK/INSP	ENGINE 1 AFT ENGINE MOUNT COMPONENTS
N71-21-00-B	71-416	71-416-01-2	W-06-145-01	CHECK/INSP	ENGINE 2 AFT ENGINE MOUNT COMPONENTS
N71-21-00-6A		71-416-02-1		FUNCTIONAL	ENG 1 AFT MOUNT COMPONENTS.
N71-21-00-6A		71-416-02-2		FUNCTIONAL	ENG 2 AFT MOUNT COMPONENTS.
N71-71-00-A	71-413	71-413-01		OPERATIONAL	ENGINE DRAIN LINES
N71-71-00-6A	71-412	71-412-01-1		CHECK/INSP	ENGINE 1 ENGINE DRAIN SYSTEM
N71-71-00-6A	71-412	71-412-01-2		CHECK/INSP	ENGINE 2 ENGINE DRAIN SYSTEM
N71-71-00-6B		71-425-01-1		CHECK/INSP	ENGINE 1 STRUT DRAINS
N71-71-00-6B		71-425-01-2		CHECK/INSP	ENGINE 2 STRUT DRAINS
N72-00-00-C	72-424	72-424		REPLACE	TURBINE SHAFT COUPLING
N72-00-00-E		72-436-01-1		BORESCOPE	ENGINE 1 HPT STAGE 1 BLADES
N72-00-00-E		72-436-01-2		BORESCOPE	ENGINE 2 HPT STAGE 1 BLADES
N72-00-00-6A N72-00-00-6B N72-00-00-6C	72-410-C1-1			BORESCOPE	COMBUSTION LINER/HP AND LP TURBINES
N72-00-00-6A N72-00-00-6B N72-00-00-6C	72-410-C1-2			BORESCOPE	COMBUSTION LINER/HP AND LP TURBINES
N72-00-00-6A N72-00-00-6B N72-00-00-6C	72-410-C2-1			BORESCOPE	COMBUSTION LINER/HP AND LP TURBINES
N72-00-00-6A N72-00-00-6B N72-00-00-6C	72-410-C2-2			BORESCOPE	COMBUSTION LINER/HP AND LP TURBINES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-108



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N72-00-00-6A	72-410		G-72-410-C1-1	BORESCOPE	COMBUSTION LINER AND 1ST STAGE VANES
N72-00-00-6A	72-410		G-72-410-C1-2	BORESCOPE	COMBUSTION LINER AND 1ST STAGE VANES
N72-00-00-6B	72-412		G-72-410-C1-1	BORESCOPE	STAGE 1 AND 2 HP TURBINE BLADES
N72-00-00-6B	72-412		G-72-410-C1-2	BORESCOPE	STAGE 1 AND 2 HP TURBINE BLADES
N72-00-00-6C	72-428		G-72-410-C1-1	BORESCOPE	ENGINE 1 STAGE 3 LP TURBINE VANES
N72-00-00-6C	72-428		G-72-410-C1-2	BORESCOPE	ENGINE 2 STAGE 3 LP TURBINE VANES
N72-30-00-A	72-403	72-403		REPLACE	FAN HUB
N72-30-00-B	72-405	72-405		REPLACE	LOW PRESSURE COMPRESSOR DRUM ROTOR
N72-30-00-C	72-409	72-409		REPLACE	HPC COMPRESSOR COMPONENTS
N72-30-00-D	72-427	72-427-01-1	W-06-145-01	CHECK/INSP	ENGINE 1 FRONT MOUNT THRUST BRACKETS
N72-30-00-D	72-427	72-427-01-2	W-06-145-01	CHECK/INSP	ENGINE 2 FRONT MOUNT THRUST BRACKETS
N72-31-01-6A	72-402	72-402-01-1		CHECK/INSP	EXTERNAL PORTION OF INLET CONE
N72-31-01-6A	72-402	72-402-01-2		CHECK/INSP	EXTERNAL PORTION OF INLET CONE
N72-31-02-6A	72-401	72-401-01-1		CHECK/INSP	ENGINE 1 FAN ROTOR BLADES
N72-31-02-6A	72-401	72-401-01-2		CHECK/INSP	ENGINE 2 FAN ROTOR BLADES
N72-31-02-6A		72-401-02-1		CHECK/INSP	ENGINE 2 FAN ROTOR BLADES
N72-31-02-6A		72-401-02-2		CHECK/INSP	ENGINE 1 FAN ROTOR BLADES
N72-31-02-6B		72-433-01-1	W-72-401-01-1	LUBRICATE	ENG 1 FAN BLADE PART-SPAN SHROUD
N72-31-02-6B		72-433-01-2	W-72-401-01-2	LUBRICATE	ENG 2 FAN BLADE PART-SPAN SHROUD
N72-31-02-6B		72-433-02-1	W-72-401-01-1	LUBRICATE	ENG 1 FAN BLADE PART-SPAN SHROUD
N72-31-02-6B		72-433-02-2	W-72-401-01-2	LUBRICATE	ENG 2 FAN BLADE PART-SPAN SHROUD
N72-31-03-6A	72-426	72-426-01-1		CHECK/INSP	ENGINE 1 FAN EXIT FAIRING
N72-31-03-6A	72-426	72-426-01-2		CHECK/INSP	ENGINE 2 FAN EXIT FAIRING
N72-31-04-6A	72-404	72-404-01-1		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES
N72-31-04-6A	72-404	72-404-01-2		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES
N72-31-05-A	72-404	72-404-02-1		CHECK/INSP	1.6 STAGE COMPRESSOR ROTOR BLADES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N72-31-05-A	72-404	72-404-02-2		CHECK/INSP	1.6 STAGE COMPRESSOR ROTOR BLADES
N72-33-01-A	72-425	72-425-01-1		CHECK/INSP	ENGINE 1 FRONT FAN CASE
N72-33-01-A	72-425	72-425-01-2		CHECK/INSP	ENGINE 2 FRONT FAN CASE
N72-33-01-6A	72-406	72-406-01-1		CHECK/INSP	FAN CASE RING SEGMENTS (RUBSTRIPS)
N72-33-01-6A	72-406	72-406-01-2		CHECK/INSP	FAN CASE RING SEGMENTS (RUBSTRIPS)
N72-33-02-A	72-407	72-407-02-1		CHECK/INSP	ENGINE 1 FAN EXIT REAR CASE ASSEMBLY
N72-33-02-A	72-407	72-407-02-2		CHECK/INSP	ENGINE 2 FAN EXIT REAR CASE ASSEMBLY
N72-33-02-6A	72-407	72-407-01-1		CHECK/INSP	FAN EXIT CASE AND VANES ASSEMBLY
N72-33-02-6A	72-407	72-407-01-2		CHECK/INSP	FAN EXIT CASE AND VANES ASSEMBLY
N72-34-03-6A	72-407	72-407-03-1		CHECK/INSP	ENGINE 1 FAN EXIT LINER SEGMENTS
N72-34-03-6A	72-407	72-407-03-2		CHECK/INSP	ENGINE 2 FAN EXIT LINER SEGMENTS
N72-35-00-A		72-434-01-1		CHECK/INSP	ENGINE 1 HPC VARIABLE STATOR VANES
N72-35-00-A		72-434-01-2		CHECK/INSP	ENGINE 2 HPC VARIABLE STATOR VANES
N72-35-00-B		72-435-01-1		CHECK/INSP	ENGINE 1 HPC ROTOR BLADE LOCKS
N72-35-00-B		72-435-01-2		CHECK/INSP	ENGINE 2 HPC ROTOR BLADE LOCKS
N72-50-00-A	72-413	72-413		REPLACE	HP TURBINE ROTATING COMPONENTS
N72-50-00-B	72-415	72-415		REPLACE	LP TURBINE ROTATING COMPONENTS
N72-50-00-D	72-418	72-418-01-1	W-06-145-01	CHECK/INSP	ENGINE 1 TURBINE EXHAUST CASE RAILS
N72-50-00-D	72-418	72-418-01-2	W-06-145-01	CHECK/INSP	ENGINE 2 TURBINE EXHAUST CASE RAILS
N72-53-01-6A	72-414	72-414-01-1		CHECK/INSP	6TH STAGE TURBINE VANES AND BLADES
N72-53-01-6A	72-414	72-414-01-2		CHECK/INSP	6TH STAGE TURBINE VANES AND BLADES
N72-54-01-2A		72-431-02-1		CLEAN/INSP	ENG 1 NUMBER 4 BEARING COMPARTMENT
N72-54-01-2A		72-431-02-2		CLEAN/INSP	ENG 2 NUMBER 4 BEARING COMPARTMENT
N72-61-01-6A	72-420	72-420-01-1	W-06-145-01	CHECK/INSP	ENGINE 1 MAIN GEARBOX HOUSING
N72-61-01-6A	72-420	72-420-01-2	W-06-145-01	CHECK/INSP	ENGINE 2 MAIN GEARBOX HOUSING
N72-62-01-6A	72-422	72-422-51-1	W-06-145-01	CHECK/INSP	ENGINE 1 ANGLE GEARBOX HOUSING

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-110



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N72-62-01-6A	72-422	72-422-51-2	W-06-145-01	CHECK/INSP	ENGINE 2 ANGLE GEARBOX HOUSING
N73-00-00-B	73-403	73-403-01-1		CHECK/INSP	FUEL LINES, MANIFOLDS AND COMPONENTS
N73-00-00-B	73-403	73-403-01-2		CHECK/INSP	FUEL LINES, MANIFOLDS AND COMPONENTS
N73-11-02-4A	73-401	73-401-01-1		REPLACE	ENGINE 1 FUEL PUMP FILTER ELEMENT
N73-11-02-4B	73-401	73-401-01-2		REPLACE	ENGINE 2 FUEL PUMP FILTER ELEMENT
N73-21-03-A	77-401		P-06-145-01	CHECK/INSP	PT2/TT2 PROBE, WIRING AND TUBING
N73-21-10-A	79-407		P-06-145-01	CHECK/INSP	EEC OIL TEMP THERMOCOUPLE PROBE
N73-21-15-5A		73-406-01-1		OPERATIONAL	ENGINE 1 SUPPLEMENTAL CONTROL UNIT
N73-21-15-5A		73-406-01-2		OPERATIONAL	ENGINE 2 SUPPLEMENTAL CONTROL UNIT
N73-31-01-A	73-404		P-06-145-01	CHECK/INSP	FUEL FLOW TRANSMITTER
N73-34-01-4A		73-405-01-1		FUNCTIONAL	FUEL PUMP FILTER DIFF PRESS SWITCH
N73-34-01-4B		73-405-01-2		FUNCTIONAL	FUEL PUMP FILTER DIFF PRESS SWITCH
N74-00-00-5A		74-402-01-1	W-74-406-01-1	OPERATIONAL	ENGINE 1 IGNITION SYSTEM
N74-00-00-5A		74-402-01-2	W-74-406-01-2	OPERATIONAL	ENGINE 2 IGNITION SYSTEM
N74-00-00-5B	74-403	74-403-01		OPERATIONAL	IGNITION CONTROL SYSTEM
N74-00-00-5C		74-406-01-1	W-74-402-01-1	OPERATIONAL	ENGINE 1 CONTINUOUS IGNITION SYSTEM
N74-00-00-5C		74-406-01-2	W-74-402-01-2	OPERATIONAL	ENGINE 2 CONTINUOUS IGNITION SYSTEM
N74-11-01-6A	74-405	74-405-01-1		CHECK/INSP	ENGINE 1 IGNITION EXCITER
N74-11-01-6B	74-405	74-405-01-2		CHECK/INSP	ENGINE 2 IGNITION EXCITER
N74-21-01-6A	74-404	74-404-01-1	W-74-405-01-1	CHECK/INSP	ENGINE 1 IGNITER PLUG CABLES
N74-21-01-6A	74-404	74-404-01-2	W-74-405-01-2	CHECK/INSP	ENGINE 2 IGNITER PLUG CABLES
N74-21-02-A		74-407-01-1		CHECK/INSP	ENGINE 1 IGNITOR PLUG TIP WEAR
N74-21-02-A		74-407-01-2		CHECK/INSP	ENGINE 2 IGNITOR PLUG TIP WEAR
N74-21-02-6A	74-401	74-401-01-1	W-74-405-01-1	CHECK/INSP	ENGINE 1 IGNITER PLUGS
N74-21-02-6A	74-401	74-401-01-2	W-74-405-01-2	CHECK/INSP	ENGINE 2 IGNITER PLUGS
N75-23-00-5A		75-410-01-1		OPERATIONAL	ENGINE COOLING BAROMETRIC SWITCH

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N75-23-00-5B		75-410-01-2		OPERATIONAL	ENGINE COOLING BAROMETRIC SWITCH
N75-24-00-A	75-405		G-75-404-01-1	CHECK/INSP	ENGINE 1 TCC AIR SHUTOFF VALVES
N75-24-00-A	75-405		G-75-404-01-2	CHECK/INSP	ENGINE 2 TCC AIR SHUTOFF VALVES
N75-24-00-6A N75-24-00-A	75-404	75-404-01-1		OPERATIONAL	ENGINE 1 TURBINE CASE COOLING
N75-24-00-6A N75-24-00-A	75-404	75-404-01-2		OPERATIONAL	ENGINE 2 TURBINE CASE COOLING
N75-24-00-6B		75-412-01-1		CHECK/INSP	ENGINE 1 TCA SOLENOID VALVE
N75-24-00-6B		75-412-01-2		CHECK/INSP	ENGINE 2 TCA SOLENOID VALVE
N75-24-02-A	75-407	75-407-01-1		CHECK/INSP	ENGINE 1 TCA AIR SUPPLY DUCTS
N75-24-02-A	75-407	75-407-01-2		CHECK/INSP	ENGINE 2 TCA AIR SUPPLY DUCTS
N75-31-00-A	75-408		P-06-145-01	CHECK/INSP	VARIABLE STATOR LINKAGE
N75-32-00-A	75-409		P-06-145-01	CHECK/INSP	COMPRESSOR CONTROL SYSTEM PLUMBING
N75-32-00-6A	75-406	75-406-01-1		CHECK/INSP	2.5 BLEED VALVE-TO-ACTUATOR LINKAGE
N75-32-00-6A	75-406	75-406-01-2		CHECK/INSP	2.5 BLEED VALVE-TO-ACTUATOR LINKAGE
N75-33-00-6A N75-33-00-6B	75-411-C1-1			CHECK/INSP	ENG 1 TCA AND TRC VALVE INDICATORS
N75-33-00-6A N75-33-00-6B	75-411-C1-2			CHECK/INSP	ENG 2 TCA AND TRC VALVE INDICATORS
N75-33-00-6A			G-75-411-C1-1	CHECK/INSP	ENGINE 1 TCA VALVE INDICATOR
N75-33-00-6A			G-75-411-C1-2	CHECK/INSP	ENGINE 2 TCA VALVE INDICATOR
N75-33-00-6B			G-75-411-C1-1	CHECK/INSP	ENGINE 1 TRC VALVE INDICATOR
N75-33-00-6B			G-75-411-C1-2	CHECK/INSP	ENGINE 2 TRC VALVE INDICATOR
N75-33-00-6C		75-414-01-1		CHECK/INSP	ENGINE 1 TCA VALVE INDICATOR
N75-33-00-6C		75-414-01-2		CHECK/INSP	ENGINE 2 TCA VALVE INDICATOR
N75-33-05-A		75-415-01-1		REPLACE	ENGINE 1 PS3 AIR FILTERS
N75-33-05-A		75-415-01-2		REPLACE	ENGINE 2 PS3 AIR FILTERS
N77-11-01-A	77-402		P-06-145-01	CHECK/INSP	PT 4.95 PROBES AND TUBING

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-112



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N77-21-00-A	77-403		P-06-145-01	CHECK/INSP	EGT THERMOCOUPLE PROBES & CABLES
N77-21-03-A	77-404		P-06-145-01	CHECK/INSP	THERMOCOUPLE JUNCTION BOX
N77-35-00-2A	77-405	77-405-01		OPERATIONAL	PIMU FAULT MESSAGES
N77-35-00-2B	77-406	77-406-01		OPERATIONAL	EEC CATEGORY 2 FAULTS
N77-41-01-4A	77-407	77-407-01		OPERATIONAL	STANDBY ENGINE INDICATOR
N78-00-00-6B		78-426-01-1		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
N78-00-00-6B		78-426-01-2		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
N78-00-00-6B		78-426-02-1		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
N78-00-00-6B		78-426-02-2		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
N78-00-00-6C N78-00-00-6D	78-405-C1-1			CHECK/INSP	FAN DUCT BULL-NOSE SEAL AND FAIRING
N78-00-00-6C N78-00-00-6D	78-405-C1-2			CHECK/INSP	FAN DUCT BULL-NOSE SEAL AND FAIRING
N78-00-00-6C	78-405		G-78-405-C1-1	CHECK/INSP	ENGINE 1 FAN DUCT BULL-NOSE SEAL
N78-00-00-6C	78-405		G-78-405-C1-2	CHECK/INSP	ENGINE 2 FAN DUCT BULL-NOSE SEAL
N78-00-00-6C N78-00-00-6D	78-426-02-3			CHECK/INSP	FAN DUCT BULL-NOSE SEAL AND FAIRING
N78-00-00-6C N78-00-00-6D	78-426-02-4			CHECK/INSP	FAN DUCT BULL-NOSE SEAL AND FAIRING
N78-00-00-6D	78-422		G-78-405-C1-1	CHECK/INSP	ENGINE 1 FAN DUCT BULL-NOSE FAIRING
N78-00-00-6D	78-422		G-78-405-C1-2	CHECK/INSP	ENGINE 2 FAN DUCT BULL-NOSE FAIRING
N78-11-00-A	78-401		P-06-145-01	CHECK/INSP	TURBINE EXHAUST SLEEVE AND PLUG
N78-11-00-B	78-402		P-06-145-01	CHECK/INSP	TURBINE EXHAUST SLEEVE SPRING SEALS
N78-11-00-C	78-403		P-06-145-01	CHECK/INSP	TURBINE EXHAUST HONEYCOMB SLEEVES
N78-31-00-A	78-404		P-06-153-01	CHECK/INSP	THRUST REVERSER STRUCTURE
N78-31-00-B	78-406		P-06-144-01	CHECK/INSP	THRUST REVERSER HYDRAULIC TUBING
N78-31-00-C	78-413		P-06-144-01	CHECK/INSP	THRUST REVERSER FAN FLOW PATH
N78-31-00-D	78-410		P-06-144-01	CHECK/INSP	FAN DUCT COWL/THRUST REVERSER HINGE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N78-31-00-E	78-411		P-06-144-01	CHECK/INSP	C-DUCT LATCH ACCESS DOORS
N78-31-00-F	78-412		P-06-144-01	CHECK/INSP	FAN AIR EXIT NOZZLE
N78-31-00-G	78-425		P-06-144-01	CHECK/INSP	FAN DUCT COWL AND T/R HOLD OPEN RODS
N78-31-00-5A	78-429	78-429-03-1		FUNCTIONAL	CENTER LOCKING HYDRAULIC ACTUATOR
N78-31-00-5A	78-429	78-429-03-2		FUNCTIONAL	CENTER LOCKING HYDRAULIC ACTUATOR
N78-31-02-A	78-409		P-06-144-01	CHECK/INSP	FAN DUCT V-GROOVE LATCH BANDS
N78-31-04-A	78-408		P-06-144-01	CHECK/INSP	FAN DUCT TENSION LATCHES
N78-31-06-A	78-424		P-06-144-01	CHECK/INSP	T/R HYD COWL OPENING ACTR ATTACHMENT
N78-31-08-A	78-423		P-06-144-01	CHECK/INSP	T/R HYD COWL OPENING ACTR FLEX HOSES
N78-31-10-A	78-427		P-06-144-01	CHECK/INSP	THRUST REVERSER TRANSLATING SLEEVES
N78-31-11-6A	78-434		P-06-074-01	CHECK/INSP	THRUST REVERSER TRACKS/LINERS/SLIDER
N78-31-11-6B		78-431-02-1		CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
N78-31-11-6B		78-431-02-2		CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
N78-31-11-6B		78-437-01-1		CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
N78-31-11-6B		78-437-01-2		CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
N78-31-14-6B	78-407	78-407-01-1		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS
N78-31-14-6B	78-407	78-407-01-2		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS
N78-31-16-6B	78-435		P-06-074-01	CHECK/INSP	THRUST REVERSER CASCADE VANES
N78-31-20-2A		78-421-01-1		CLEAN	T/R HYD COWL OPENING POWER UNIT
N78-31-20-2A		78-421-01-2		CLEAN	T/R HYD COWL OPENING POWER UNIT
N78-34-00-A	78-415		P-06-153-01	CHECK/INSP	T/R AUTO-RESTOW PROXIMITY SENSORS
N78-34-00-B	78-416		P-06-144-01	CHECK/INSP	THRUST REVERSER POSITION LVDT
N78-34-00-C		78-436-51-1		FUNCTIONAL	ENG 1 THRUST REVERSER HEALTH CHECK
N78-34-00-C		78-436-51-2		FUNCTIONAL	ENG 2 THRUST REVERSER HEALTH CHECK
N78-34-01-A	78-419		P-06-148-01	CHECK/INSP	T/R DIRECTIONAL CONTROL VALVE
N78-34-05-A	78-414		P-06-154-01	CHECK/INSP	THRUST REVERSER ISOLATION VALVE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-114



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N78-34-13-A N78-34-13-B	78-431-C1-1			FUNCTIONAL	ENG 1 T/R SYNC LOCK AND CIRCUITRY
N78-34-13-A N78-34-13-B	78-431-C1-2			FUNCTIONAL	ENG 2 T/R SYNC LOCK AND CIRCUITRY
N78-34-13-A	78-431		G-78-431-C1-1	OPERATIONAL	ENG 1 THRUST REVERSER SYNC-LOCK
N78-34-13-A	78-431		G-78-431-C1-2	OPERATIONAL	ENG 2 THRUST REVERSER SYNC-LOCK
N78-34-13-B	78-430		G-78-431-C1-1	FUNCTIONAL	ENG 1 T/R SYNC LOCK CONTROL CIRCUIT
N78-34-13-B	78-430		G-78-431-C1-2	FUNCTIONAL	ENG 2 T/R SYNC LOCK CONTROL CIRCUIT
N78-36-00-A	78-417		P-06-144-01	CHECK/INSP	T/R ACTUATOR LOCK PROXIMITY SENSORS
N78-36-00-B	78-418		P-06-144-01	CHECK/INSP	THRUST REVERSER DEPLOY SENSORS
N78-36-00-5A		78-436-01-1		OPERATIONAL	ENGINE 1 T/R DISAGREEMENT CIRCUIT
N78-36-00-5A		78-436-01-2		OPERATIONAL	ENGINE 2 T/R DISAGREEMENT CIRCUIT
N78-36-00-5B		78-432-52		OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
N78-36-03-5A	78-433	78-433-01		OPERATIONAL	THRUST REVERSER RELAY MODULE
N79-00-00-6A	79-401	79-401-01-1		CHECK/INSP	ENGINE 1 OIL SYSTEM TUBING
N79-00-00-6A	79-401	79-401-01-2		CHECK/INSP	ENGINE 2 OIL SYSTEM TUBING
N79-21-01-A	79-402	79-402-01-1		CHECK/INSP	ENGINE 1 FUEL/OIL COOLER
N79-21-01-A	79-402	79-402-01-2		CHECK/INSP	ENGINE 2 FUEL OIL COOLER
N79-21-05-4A		79-403-01-1		REPLACE	ENGINE 1 MAIN OIL FILTER ELEMENT
N79-21-05-4A		79-403-01-2		REPLACE	ENGINE 2 MAIN OIL FILTER ELEMENT
N79-21-05-4A		79-403-02-1		REPLACE	ENGINE 1 MAIN OIL FILTER ELEMENT
N79-21-05-4A		79-403-02-2		REPLACE	ENGINE 2 MAIN OIL FILTER ELEMENT
N79-21-10-6A	72-408		G-79-411-C1-1	CHECK/INSP	ENGINE 1 ANGLE GEARBOX CHIP DETECTOR
N79-21-10-6A	72-408		G-79-411-C1-2	CHECK/INSP	ENGINE 2 ANGLE GEARBOX CHIP DETECTOR

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N79-21-10-6A N79-21-10-6B N79-21-10-6C N79-21-10-6D N79-21-10-6E N79-21-10-6F	79-411-C1-1			CHECK/INSP	ENGINE 1 MAGNETIC CHIP DETECTORS
N79-21-10-6A N79-21-10-6B N79-21-10-6C N79-21-10-6D N79-21-10-6E N79-21-10-6F	79-411-C1-2			CHECK/INSP	ENGINE 2 MAGNETIC CHIP DETECTORS
N79-21-10-6B	72-430		G-79-411-C1-1	CHECK/INSP	NO. 1, 1.5 AND 2 BRG MAG CHIP DET
N79-21-10-6B	72-430		G-79-411-C1-2	CHECK/INSP	NO. 1, 1.5 AND 2 BRG MAG CHIP DET
N79-21-10-6C	72-411		G-79-411-C1-1	CHECK/INSP	NO. 3 BEARING MAGNETIC CHIP DETECTOR
N79-21-10-6C	72-411		G-79-411-C1-2	CHECK/INSP	NO. 3 BEARING MAGNETIC CHIP DETECTOR
N79-21-10-6D	72-417		G-79-411-C1-1	CHECK/INSP	NO. 4 BEARING MAGNETIC CHIP DETECTOR
N79-21-10-6D	72-417		G-79-413-C1-2	CHECK/INSP	NO. 4 BEARING MAGNETIC CHIP DETECTOR
N79-21-10-6E	72-419		G-79-411-C1-1	CHECK/INSP	ENG 1 MAIN GEARBOX MAG CHIP DETECTOR
N79-21-10-6E	72-419		G-79-411-C1-2	CHECK/INSP	ENG 2 MAIN GEARBOX MAG CHIP DETECTOR
N79-21-10-6F			G-79-411-C1-1	CHECK/INSP	ENGINE 1 OIL TANK MAG CHIP DETECTOR
N79-21-10-6F			G-79-411-C1-2	CHECK/INSP	ENGINE 2 OIL TANK MAG CHIP DETECTOR
N79-31-01-A	79-404		P-06-145-01	CHECK/INSP	OIL QUANTITY TRANSMITTER AND WIRING
N79-32-01-A	79-405		P-06-145-01	CHECK/INSP	OIL PRESSURE TRANSMITTER AND WIRING
N79-33-01-A	79-406		P-06-145-01	CHECK/INSP	LOW OIL PRESSURE WARNING SWITCH
N79-35-00-5A	79-409	79-409-51-1		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM
N79-35-00-5A	79-409	79-409-51-2		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM
N79-35-01-A			P-06-145-01	CHECK/INSP	OIL FILTER DIFFERENTIAL PRESS SWITCH
N79-35-01-4A		79-412-01-1		DISCARD	ENG OIL FILTER DIFF PRESS SWITCH
N79-35-01-4A		79-412-01-2		DISCARD	ENG OIL FILTER DIFF PRESS SWITCH

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-116



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
N80-11-00-A	80-404		P-06-145-01	CHECK/INSP	START SYSTEM DUCTING/CLAMPS/QUAD
N80-11-01-6A	80-402	80-402-01-1		CHECK/INSP	ENG 1 STARTER MAGNETIC CHIP DETECTOR
N80-11-01-6A	80-402	80-402-01-2		CHECK/INSP	ENG 2 STARTER MAGNETIC CHIP DETECTOR
N80-11-04-2A		80-403-01-1		CLEAN	ENG 1 STARTER CONTROL VALVE FILTER
N80-11-04-2A		80-403-01-2		CLEAN	ENG 2 STARTER CONTROL VALVE FILTER
P71-00-00-6A	71-101		P-06-070-01	CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
P71-00-00-6B	71-102		P-06-072-01	CHECK/INSP	FAN COWL/CORE COWL HINGES
P71-00-00-6C	71-103		P-06-072-01	CHECK/INSP	FAN COWL/CORE COWL LATCHES
P71-00-00-6D	71-104		P-06-069-01	CHECK/INSP	INLET COWL FLANGE & FAN CASE FLANGE
P71-00-00-6E	71-105		P-06-069-01	CHECK/INSP	INLET COWL ATTACH BOLTS
P71-00-00-6F	71-107		P-06-076-01	CHECK/INSP	INTERNAL SURFACE OF THE CORE COWLS
P71-00-00-6G	71-108		P-06-071-01	CHECK/INSP	COWLING PRESSURE RELIEF DOORS
P71-00-00-6H	71-109	71-109-01-1		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - L
P71-00-00-6H	71-109	71-109-01-2		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - R
P71-00-00-6I	71-110		P-06-069-01	CHECK/INSP	FORWARD MOUNT THRUST LINKS
P71-00-00-6J	71-111		P-06-069-01	CHECK/INSP	FORWARD MOUNT EVENER BAR
P71-00-00-6K	71-112		P-06-069-01	CHECK/INSP	FORWARD MOUNT BOLTS
P71-00-00-6L	71-113		P-06-069-01	CHECK/INSP	FORWARD MOUNT CENTER ATTACHMENT
P71-00-00-6M	71-114		P-06-069-01	CHECK/INSP	FORWARD MOUNT PLATFORM FITTING
P71-00-00-6N	71-115		P-06-069-01	CHECK/INSP	AFT MOUNT STRUT/ENGINE ATTACH BOLTS
P71-00-00-6O	71-116		P-06-069-01	CHECK/INSP	AFT MOUNT HANGER
P71-00-00-6P	71-117		P-06-069-01	CHECK/INSP	AFT MOUNT TANGENTIAL/CENTER LINKS
P71-00-00-6Q	71-118		P-06-069-01	CHECK/INSP	DRAIN LINES
P71-00-00-6R	71-119		P-06-069-01	CHECK/INSP	OVERBOARD DRAIN SEAL
P71-00-00-6S	71-120		P-06-069-01	CHECK/INSP	COMBUSTION CHAMBER DRAIN LINE
P71-00-00-6T	71-121	71-121-01-1		CHECK/INSP	STRUT DRAIN INLETS - ENG 1

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
P71-00-00-6T	71-121	71-121-01-2		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
P71-11-10-2A		71-124-01-1		OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 1
P71-11-10-2A		71-124-01-2		OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 2
P71-21-00-6A		71-BCY-90-1		CHECK/INSP	ENGINE 1 MOUNTS
P71-21-00-6A		71-BCY-90-2		CHECK/INSP	ENGINE 2 MOUNTS
P72-00-00-C	72-104	72-104-02-1		CHECK/INSP	1.5 STAGE COMPRESSOR ROTOR BLADES -L
P72-00-00-C	72-104	72-104-02-2		CHECK/INSP	1.5 STAGE COMPRESSOR ROTOR BLADES -R
P72-00-00-6A P72-00-00-6B	72-110-C1-1			BOREScope	COMBUST LINER/1ST STAGE BLADE/VANE
P72-00-00-6A P72-00-00-6B	72-110-C1-2			BOREScope	COMBUST LINER/1ST STAGE BLADE/VANE
P72-00-00-6A	72-110		G-72-110-C1-1	BOREScope	COMBUSTION LINER, TURBINE GUIDE VANE
P72-00-00-6A	72-110		G-72-110-C1-2	BOREScope	COMBUSTION LINER, TURBINE GUIDE VANE
P72-00-00-6B	72-112		G-72-110-C1-1	BOREScope	FIRST STAGE (HP) TURBINE BLADES - L
P72-00-00-6B	72-112		G-72-110-C1-2	BOREScope	FIRST STAGE (HP) TURBINE BLADES - R
P72-31-01-2A	72-102		P-06-068-01	CHECK/INSP	EXTERNAL PORTION OF INLET CONE
P72-31-02-6A	72-101		P-06-068-01	CHECK/INSP	FAN ROTOR BLADES
P72-31-03-A	72-103	72-103		REPLACE	FAN DISK
P72-32-00-A	72-105	72-105		REPLACE	FRONT COMPRESSOR ROTOR DISKS
P72-32-02-6A	72-104	72-104-01-1		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES -L
P72-32-02-6A	72-104	72-104-01-2		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES -R
P72-33-02-6A	72-106		P-06-068-01	CHECK/INSP	FAN CASE RING SEGMENTS (RUBSTRIPS)
P72-33-03-6A	72-107		P-06-069-01	CHECK/INSP	FAN EXIT CASE AND VANES ASSEMBLY
P72-33-04-6A	72-107		P-06-069-01	CHECK/INSP	FAN EXIT REAR CASE ASSEMBLY
P72-33-05-2A	72-107		P-06-069-01	CHECK/INSP	SOUND ABSORBING LINER (FRONT OUTER)
P72-33-06-2A	72-107		P-06-069-01	CHECK/INSP	SOUND ABSORBING LINER (REAR INNER)
P72-35-00-A	72-109	72-109		REPLACE	REAR COMPRESSOR DRIVE ROTOR DISKS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-118



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
P72-51-01-A	72-113	72-113		REPLACE	HP TURBINE DISK
P72-51-01-6A	72-114		P-06-068-01	CHECK/INSP	6TH STAGE TURBINE BLADES
P72-52-00-A	72-115	72-115		REPLACE	LP TURBINE DISKS
P72-53-01-6A	72-116		P-06-069-01	CHECK/INSP	TURBINE EXHAUST CASE ATTACH FLANGE
P72-53-01-6B	72-118		P-06-069-01	CHECK/INSP	TURBINE EXHAUST CASE STRUTS
P72-61-01-6A	72-120		P-06-069-01	CHECK/INSP	MAIN GEARBOX MOUNTS
P72-61-01-6B	72-121		P-06-069-01	CHECK/INSP	MAIN GEARBOXES
P72-61-03-2A	79-104	79-104-01-1		REPLACE	MAIN OIL FILTER ELEMENT - ENG 1
P72-61-03-2A	79-104	79-104-01-2		REPLACE	MAIN OIL FILTER ELEMENT - ENG 2
P72-62-01-6A	72-120		P-06-069-01	CHECK/INSP	ANGLE GEARBOX MOUNTS
P72-62-01-6B	72-121		P-06-069-01	CHECK/INSP	ANGLE GEARBOXES
P73-00-00-6A	73-102		P-06-069-01	CHECK/INSP	PS4, TT2 SENSORS AND TUBING
P73-00-00-6B	73-103		P-06-069-01	CHECK/INSP	FUEL LINES AND COMPONENTS
P73-00-00-6C	73-104		P-06-069-01	CHECK/INSP	FUEL FILTER DIFF PRESSURE SWITCH
P73-00-00-6D	73-105		P-06-069-01	CHECK/INSP	FUEL HEATER AND EXTERNAL PLUMBING
P73-00-00-6E	73-106		P-06-069-01	CHECK/INSP	FUEL HTR AIR SHUTOFF SOLENOID VALVE
P73-00-00-6F	73-107		P-06-069-01	CHECK/INSP	FUEL FLOW TRANSMITTER
P73-00-00-6G	77-101		P-06-069-01	CHECK/INSP	PT2/TT2 PROBE, WIRING AND TUBING
P73-11-02-4A	73-101	73-101-01-1		REPLACE	FUEL PUMP FILTER ELEMENT - ENG 1
P73-11-02-4A	73-101	73-101-01-2		REPLACE	FUEL PUMP FILTER ELEMENT - ENG 2
P73-14-00-5A		73-111-01-1		OPERATIONAL	ENGINE FUEL DEICING SYSTEM - ENG 1
P73-14-00-5A		73-111-01-2		OPERATIONAL	ENGINE FUEL DEICING SYSTEM - ENG 2
P73-14-03-4A		73-112-01-1		FUNCTIONAL	FUEL FILTER DIFF PRESSURE SWITCH -L
P73-14-03-4A		73-112-01-2		FUNCTIONAL	FUEL FILTER DIFF PRESSURE SWITCH -R
P73-21-04-4A		73-BCY-91-1		REPLACE	ENGINE 1 PT2/TT2 SENSOR
P73-21-04-4A		73-BCY-91-2		REPLACE	ENGINE 2 PT2/TT2 SENSOR

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
P73-21-07-2A		73-BCY-90-1		CHECK/INSP	ENGINE 1 EEC AND ENGINE WIRING
P73-21-07-2A		73-BCY-90-2		CHECK/INSP	ENGINE 2 EEC AND ENGINE WIRING
P73-21-07-5A	73-109	73-109-01-1		OPERATIONAL	EEC TRIM UNLOCK SOLENOID - ENG 1
P73-21-07-5A	73-109	73-109-01-2		OPERATIONAL	EEC TRIM UNLOCK SOLENOID - ENG 2
P74-00-00-5A	74-102	74-102-01-1		FUNCTIONAL	1 AND "2" IGNITION SYSTEMS - ENG 1
P74-00-00-5A	74-102	74-102-01-2		FUNCTIONAL	1 AND "2" IGNITION SYSTEMS - ENG 2
P74-00-00-5B		74-103-01	A-74-102-01	OPERATIONAL	IGNITION CONTROL SYSTEMS
P74-21-02-6A	74-101	74-101-01-1	W-74-R03	CHECK/INSP	IGNITER PLUGS - ENG 1
P74-21-02-6A	74-101	74-101-01-2	W-74-R03	CHECK/INSP	IGNITER PLUGS - ENG 2
P75-00-00-6A	75-101		P-06-069-01	CHECK/INSP	STATOR VANE ANTI-ICE VALVE
P75-00-00-6B	75-103		P-06-069-01	CHECK/INSP	STATOR VANE ANTI-ICE VALVE DUCTING
P75-00-00-6C	75-107		P-06-069-01	CHECK/INSP	EXT ACCESSORIES COOLING SYSTEM INLET
P75-00-00-6D	75-108		P-06-069-01	CHECK/INSP	NACELLE ZONE VENTILATION S/O VALVE
P75-00-00-6E	75-109		P-06-069-01	CHECK/INSP	TCC MODULATING VALVE
P75-00-00-6F	75-110		P-06-069-01	CHECK/INSP	TCC CONTROL TUBING
P75-00-00-6G	75-111		P-06-069-01	CHECK/INSP	TCC/TCA AIR SUPPLY DUCT
P75-00-00-6H	75-112		P-06-069-01	CHECK/INSP	ENGINE VANE & BLEED CONTROL
P75-00-00-6I	75-113		P-06-069-01	CHECK/INSP	STATOR VANE ACTUATOR
P75-00-00-6J	75-114		P-06-069-01	CHECK/INSP	VARIABLE STATOR LINKAGE
P75-00-00-6K	75-115		P-06-069-01	CHECK/INSP	3.5 BLEED VALVE AND TUBING
P75-00-00-6L	75-116		P-06-069-01	CHECK/INSP	STATOR VANE AND BLEED CONTROL SYSTEM
P75-00-00-6M	75-117		P-06-069-01	CHECK/INSP	3.0 BLEED ACTUATOR & FEED BACK CABLE
P75-00-00-6N	75-118		P-06-069-01	CHECK/INSP	3.5 BLEED CONTROL VALVE
P75-00-00-6O	75-119		P-06-069-01	CHECK/INSP	3.5 BLEED OVERRIDE CONTROL VALVE
P75-00-00-6P	75-120		P-06-069-01	CHECK/INSP	MACH PROBE LINES & PROBE HEATER
P75-00-00-6Q	78-112		P-06-073-01	CHECK/INSP	3.5 BLEED VALVE EXHAUST SEALS/DUCTS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-120



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
P75-11-02-2A	75-102	75-102-01-1		CLEAN	STATOR VANE ANTI-ICE VALVE STRAINER
P75-11-02-2A	75-102	75-102-01-2		CLEAN	STATOR VANE ANTI-ICE VALVE STRAINER
P75-23-00-5A		75-121-01-1		OPERATIONAL	ENGINE COOLING BAROMETRIC SWITCH -L
P75-23-00-5A		75-121-01-2		OPERATIONAL	ENGINE COOLING BAROMETRIC SWITCH -R
P75-32-05-6A		75-123-01-1		OPERATIONAL	BLD SYSTEM PUSH-PULL FEEDBACK CABLE
P75-32-05-6A		75-123-01-2		OPERATIONAL	BLD SYSTEM PUSH-PULL FEEDBACK CABLE
P76-11-00-A	76-103		P-06-069-01	CHECK/INSP	ENGINE AREA PUSH-PULL CABLE SYSTEM
P76-11-00-B	76-102		P-06-077-01	CHECK/INSP	STRUT AREA PUSH-PULL CABLE SYSTEM
P76-11-00-C	76-104		P-06-069-01	CHECK/INSP	FUEL CONDITION CONT MOTOR ACTUATOR
P76-11-00-D	76-105		P-06-069-01	CHECK/INSP	FUEL CONDITION CONT MOTOR ACTUATOR
P77-00-00-6A	77-103		P-06-069-01	CHECK/INSP	EGT THERMOCOUPLE PROBES & CABLES
P77-11-01-6A	77-102		P-06-069-01	CHECK/INSP	PT7 PROBES AND TUBING
P77-31-00-5A		77-BCY-90-1		OPERATIONAL	AVM SYSTEM
P77-41-00-5A	77-104	77-104-01		OPERATIONAL	STANDBY ENGINE INDICATOR
P78-00-00-H	78-111	78-111-01-1		CHECK/INSP	LOUVERED EXHAUST DOOR - ENG 1
P78-00-00-H	78-111	78-111-01-2		CHECK/INSP	LOUVERED EXHAUST DOOR - ENG 2
P78-00-00-6A	71-106		P-06-073-01	CHECK/INSP	THRUST REVERSER INNER COWL
P78-00-00-6B	78-101		P-06-069-01	CHECK/INSP	TURBINE EXHAUST SLEEVE AND PLUG
P78-00-00-6C	78-102		P-06-069-01	CHECK/INSP	TURBINE EXHAUST SLEEVE SPRING SEALS
P78-00-00-6D	78-103		P-06-069-01	CHECK/INSP	TURBINE EXHAUST HONEYCOMB SLEEVES
P78-00-00-6E	78-104		P-06-074-01	CHECK/INSP	FAN DUCT COWL & THRUST REVERSER
P78-00-00-6F	78-106		P-06-073-01	CHECK/INSP	THRUST REVERSER HYDRAULIC TUBING
P78-00-00-6G	78-108		P-06-073-01	CHECK/INSP	FAN DUCT TENSION LATCHES
P78-00-00-6H	78-109		P-06-073-01	CHECK/INSP	FAN DUCT V-GROOVE LATCH BANDS
P78-00-00-6I	78-110		P-06-073-01	CHECK/INSP	FAN DUCT COWL & THRUST REVERSE HINGE
P78-00-00-6K	78-113		P-06-073-01	CHECK/INSP	THRUST REVERSER FAN FLOW PATH

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
P78-00-00-6L	78-114		P-06-082-01	CHECK/INSP	THRUST REVERSER ISOLATION VALVE
P78-00-00-6M	78-115		P-06-074-01	CHECK/INSP	THRUST REVERSER STOW SENSORS
P78-00-00-6N	78-116		P-06-073-01	CHECK/INSP	THRUST REVERSER FEEDBACK LINKAGE
P78-00-00-6O	78-117		P-06-073-01	CHECK/INSP	THRUST REVERSER UNLOCK SENSORS
P78-00-00-6P	78-118		P-06-073-01	CHECK/INSP	THRUST REVERSER DEPLOY SENSORS
P78-00-00-6Q	78-119		P-06-082-01	CHECK/INSP	ISOLATION VALVE PRESSURE SWITCH
P78-00-00-6R	78-120	78-120-51-1		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
P78-00-00-6R	78-120	78-120-51-2		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
P78-00-00-6T P78-00-00-6U	78-121-C1-1			CHECK/INSP	ENG 1 T/R BULL-NOSE SEAL AND FAIRING
P78-00-00-6T P78-00-00-6U	78-121-C1-2			CHECK/INSP	ENG 2 T/R BULL-NOSE SEAL AND FAIRING
P78-00-00-6T			G-78-121-C1-1	CHECK/INSP	ENG 1 THRUST REVERSER BULL-NOSE SEAL
P78-00-00-6T			G-78-121-C1-2	CHECK/INSP	ENG 2 THRUST REVERSER BULL-NOSE SEAL
P78-00-00-6U			G-78-121-C1-1	CHECK/INSP	ENG 1 T/R BULL-NOSE FAIRING
P78-00-00-6U			G-78-121-C1-2	CHECK/INSP	ENG 2 T/R BULL-NOSE FAIRING
P78-31-00-5A	78-122		G-78-137-C1-1	OPERATIONAL	ENG 1 T/R UPPER LOCKING HYD ACTRS
P78-31-00-5A	78-122		G-78-137-C1-2	OPERATIONAL	ENG 2 T/R UPPER LOCKING HYD ACTRS
P78-31-00-5A P78-31-00-5B	78-137-C1-1			OPERATIONAL	ENG 1 T/R LOCKING HYDRAULIC ACTUATOR
P78-31-00-5A P78-31-00-5B	78-137-C1-2			OPERATIONAL	ENG 2 T/R LOCKING HYDRAULIC ACTUATOR
P78-31-00-5B		78-BCY-90-1		OPERATIONAL	THRUST REVERSER
P78-31-00-5B		78-BCY-90-2		OPERATIONAL	THRUST REVERSER
P78-31-00-5B	78-123		G-78-137-C1-1	OPERATIONAL	ENG 1 T/R CENTER LOCKING HYD ACTRS
P78-31-00-5B	78-123		G-78-137-C1-2	OPERATIONAL	ENG 2 T/R CENTER LOCKING HYD ACTRS
P78-31-11-6A	78-105		P-06-074-01	CHECK/INSP	THRUST REVERSER TRACKS/LINERS/SLIDER
P78-31-14-6A		78-134-01-1		CHECK/INSP	ENG 1 THRUST REVERSER BLOCKER DOORS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-122



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
P78-31-14-6A		78-134-01-2		CHECK/INSP	ENG 2 THRUST REVERSER BLOCKER DOORS
P78-31-14-6B	78-113	78-113-02-1		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS
P78-31-14-6B	78-113	78-113-02-2		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS
P78-31-16-6A	78-107		P-06-074-01	CHECK/INSP	THRUST REVERSER CASCADE VANES
P78-31-20-2A		78-121-01-1		RESTORE	L T/R HYDRAULIC COWL OPENING FILTER
P78-31-20-2A		78-121-01-2		RESTORE	R T/R HYDRAULIC COWL OPENING FILTER
P78-34-07-A P78-34-07-B	78-121-C2-1			FUNCTIONAL	ENG 1 T/R SYNC LOCK AND CIRCUITRY
P78-34-07-A P78-34-07-B	78-121-C2-2			FUNCTIONAL	ENG 2 T/R SYNC LOCK AND CIRCUITRY
P78-34-07-A	78-121		G-78-121-C2-1	OPERATIONAL	ENG 1 THRUST REVERSER SYNC-LOCK
P78-34-07-A	78-121		G-78-121-C2-2	OPERATIONAL	ENG 2 THRUST REVERSER SYNC-LOCK
P78-34-07-B	78-124		G-78-121-C2-1	FUNCTIONAL	ENG 1 T/R SYNC LOCK CONTROL CIRCUIT
P78-34-07-B	78-124		G-78-121-C2-2	FUNCTIONAL	ENG 2 T/R SYNC LOCK CONTROL CIRCUIT
P78-36-00-5A		78-123-01-1		OPERATIONAL	T/R DISAGREEMENT CIRCUIT - L ENGINE
P78-36-00-5A		78-123-01-2		OPERATIONAL	T/R DISAGREEMENT CIRCUIT - R ENGINE
P78-36-00-5C	78-125	78-125-51		OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
P78-36-07-5A	78-126	78-126-51		OPERATIONAL	THRUST REVERSER RELAY MODULE
P79-00-00-6A	79-101		P-06-069-01	CHECK/INSP	ENGINE OIL TANK
P79-00-00-6B	79-102		P-06-069-01	CHECK/INSP	OIL SYSTEM TUBING
P79-00-00-6C	79-103		P-06-069-01	CHECK/INSP	GEARBOX OIL SYSTEM INTERFACES
P79-00-00-6D	79-105		P-06-069-01	CHECK/INSP	ENGINE FUEL/OIL COOLER
P79-00-00-6E	79-106		P-06-069-01	CHECK/INSP	OIL QUANTITY TRANSMITTER AND WIRING
P79-00-00-6F	79-107		P-06-069-01	CHECK/INSP	OIL PRESSURE TRANSMITTER AND WIRING
P79-00-00-6G	79-108		P-06-069-01	CHECK/INSP	LOW OIL PRESSURE WARNING SWITCH
P79-00-00-6H	79-109		P-06-069-01	CHECK/INSP	OIL TEMPERATURE BULB
P79-00-00-6I	79-110		P-06-069-01	CHECK/INSP	OIL FILTER DIFFERENTIAL PRESS SWITCH

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
P79-21-03-2A	72-108		G-79-113-C1-1	CHECK/INSP	ANGLE GEARBOX CHIP DETECTOR - ENG 1
P79-21-03-2A	72-108		G-79-113-C1-2	CHECK/INSP	ANGLE GEARBOX CHIP DETECTOR - ENG 2
P79-21-03-2A P79-21-03-2B P79-21-03-2C P79-21-03-2D	79-113-C1-1			CHECK/INSP	ENGINE MAGNETIC DRAIN PLUGS - ENG 1
P79-21-03-2A P79-21-03-2B P79-21-03-2C P79-21-03-2D	79-113-C1-2			CHECK/INSP	ENGINE MAGNETIC DRAIN PLUGS - ENG 2
P79-21-03-2B	72-111		G-79-113-C1-1	CHECK/INSP	NO. 3 BEARING MAGNETIC CHIP DETECTOR
P79-21-03-2B	72-111		G-79-113-C1-2	CHECK/INSP	NO. 3 BEARING MAGNETIC CHIP DETECTOR
P79-21-03-2C	72-117		G-79-113-C1-1	CHECK/INSP	NO. 4 BEARING MAGNETIC CHIP DETECTOR
P79-21-03-2C	72-117		G-79-113-C1-2	CHECK/INSP	NO. 4 BEARING MAGNETIC CHIP DETECTOR
P79-21-03-2D	72-119		G-79-113-C1-1	CHECK/INSP	FULL FLOW MASTER CHIP DETECTOR ENG 1
P79-21-03-2D	72-119		G-79-113-C1-2	CHECK/INSP	FUEL FLOW MASTER CHIP DETECTOR ENG 2
P79-35-00-5A		79-112-01-1		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM -L
P79-35-00-5A		79-112-01-2		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM -R
P79-35-01-4A		79-114-01-1		DISCARD	ENG OIL FILTER DIFF PRESS SWITCH
P79-35-01-4A		79-114-01-2		DISCARD	ENG OIL FILTER DIFF PRESS SWITCH
P80-11-00-6A	80-104		P-06-069-01	CHECK/INSP	START SYSTEM DUCTING AND CLAMPS
P80-11-01-6A	80-102	80-102-01-1		CHECK/INSP	STARTER CHIP DETECTOR - ENG 1
P80-11-01-6A	80-102	80-102-01-2		CHECK/INSP	STARTER CHIP DETECTOR - ENG 2
P80-11-04-2A	80-103	80-103-01-1		CLEAN	STARTER CONTROL VALVE FILTER - ENG 1
P80-11-04-2A	80-103	80-103-01-2		CLEAN	STARTER CONTROL VALVE FILTER - ENG 2
0600-100-01Z	0600-100-01Z	06-001-01		GEN VISUAL	LOWER HALF OF FUSELAGE - EXTERIOR
0600-111-01Z	0600-111-01Z	06-002-01		GEN VISUAL	RADOME
0600-113-01Z 0600-114-01Z	0600-113-01Z 0600-114-01Z	06-003-01		GEN VISUAL	AREAS FORWARD OF NLG WHEEL WELL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-124



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-115-01Z 0600-116-01Z	0600-115-01Z 0600-116-01Z	06-004-01		GEN VISUAL	NOSE LANDING GEAR WHEEL WELL
0600-117-01Z 0600-118-01Z	0600-117-01Z 0600-118-01Z	06-005-01		GEN VISUAL	AREAS OUTBD AND ABOVE NLG WHEEL WELL
0600-119-01Z	0600-119-01Z	06-006-01		GEN VISUAL	MAIN EQUIPMENT CENTER
0600-119-02Z	0600-119-02Z	06-007-01		GEN VISUAL	MAIN EQUIPMENT CENTER
0600-121-01Z 0600-122-01Z	0600-121-01Z 0600-122-01Z	06-008-01		GEN VISUAL	FORWARD CARGO COMPARTMENT
0600-121-02Z 0600-122-02Z	0600-121-02Z 0600-122-02Z	06-009-01		GEN VISUAL	FORWARD CARGO COMPARTMENT
0600-123-01Z 0600-124-01Z	0600-123-01Z 0600-124-01Z	06-010-01		GEN VISUAL	AREAS BELOW FWD CARGO COMPARTMENT
0600-125-01Z 0600-126-01Z	0600-125-01Z 0600-126-01Z	06-011-01		GEN VISUAL	AREAS AFT OF FWD CARGO COMPARTMENT
0600-131-01Z 0600-132-01Z	0600-131-01Z 0600-132-01Z	06-012-01		GEN VISUAL	AREAS ABOVE WING CENTER SECTION
0600-131-02Z 0600-132-02Z	0600-131-02Z 0600-132-02Z	06-012-02		GEN VISUAL	AREAS ABOVE WING CENTER SECTION
0600-133-01Z 0600-134-01Z	0600-133-01Z 0600-134-01Z	06-013-01		GEN VISUAL	WING CENTER SECTION
0600-133-01Z 0600-134-01Z	0600-133-01Z 0600-134-01Z	06-013-02		GEN VISUAL	WING CENTER SECTION
0600-135-01Z 0600-136-01Z	0600-135-01Z 0600-136-01Z	06-014-01		GEN VISUAL	ENVIRONMENTAL CONTROL SYSTEM BAYS
0600-141-01Z 0600-142-01Z	0600-141-01Z 0600-142-01Z	06-015-01		GEN VISUAL	AREAS ABOVE MLG WHEEL WELL
0600-141-02Z 0600-142-02Z	0600-141-02Z 0600-142-02Z	06-015-02		GEN VISUAL	AREAS ABOVE MLG WHEEL WELL
0600-143-01Z	0600-143-01Z	06-016-01		GEN VISUAL	LEFT MAIN WHEEL WELL
0600-144-01Z	0600-144-01Z	06-017-01		GEN VISUAL	RIGHT MAIN WHEEL WELL
0600-151-01Z 0600-152-01Z	0600-151-01Z 0600-152-01Z	06-018-01		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-151-02Z 0600-152-02Z	0600-151-02Z 0600-152-02Z	06-019-01		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT
0600-151-03Z 0600-152-03Z	0600-151-03Z 0600-152-03Z	06-020-01		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT
0600-153-01Z	0600-153-01Z	06-021-01		GEN VISUAL	AFT CARGO COMPARTMENT - LEFT
0600-153-02Z	0600-153-02Z	06-022-01		GEN VISUAL	AFT CARGO COMPARTMENT - LEFT
0600-154-01Z	0600-154-01Z	06-023-01		GEN VISUAL	AFT CARGO COMPARTMENT - RIGHT
0600-154-02Z	0600-154-02Z	06-024-01		GEN VISUAL	AFT CARGO COMPARTMENT - RIGHT
0600-155-01Z 0600-156-01Z	0600-155-01Z 0600-156-01Z	06-025-01		GEN VISUAL	AREAS BELOW AFT CARGO COMPARTMENT
0600-161-01Z	0600-161-01Z	06-026-01		GEN VISUAL	BULK CARGO COMPARTMENT - LEFT
0600-161-02Z	0600-161-02Z	06-027-01		GEN VISUAL	BULK CARGO COMPARTMENT - LEFT
0600-162-01Z	0600-162-01Z	06-028-01		GEN VISUAL	BULK CARGO COMPARTMENT - RIGHT
0600-162-02Z	0600-162-02Z	06-029-01		GEN VISUAL	BULK CARGO COMPARTMENT - RIGHT
0600-163-01Z 0600-164-01Z	0600-163-01Z 0600-164-01Z	06-030-01		GEN VISUAL	AREAS BELOW BULK CARGO COMPARTMENT
0600-165-01Z 0600-166-01Z	0600-165-01Z 0600-166-01Z	06-031-01		GEN VISUAL	AREAS AFT OF BULK CARGO COMPARTMENT
0600-191-01Z 0600-193-01Z	0600-191-01Z 0600-193-01Z	06-032-01		GEN VISUAL	WING TO BODY FAIRINGS - FWD LEFT
0600-192-01Z 0600-194-01Z	0600-192-01Z 0600-194-01Z	06-033-01		GEN VISUAL	WING TO BODY FAIRINGS - FWD RIGHT
0600-195-01Z 0600-197-01Z	0600-195-01Z 0600-197-01Z	06-034-01		GEN VISUAL	WING TO BODY FAIRINGS - AFT LEFT
0600-196-01Z 0600-198-01Z	0600-196-01Z 0600-198-01Z	06-035-01		GEN VISUAL	WING TO BODY FAIRINGS - AFT RIGHT
0600-200-01Z	0600-200-01Z	06-036-01		GEN VISUAL	UPPER HALF OF FUSELAGE-EXTERIOR
0600-211-01Z 0600-212-01Z	0600-211-01Z 0600-212-01Z	06-037-01		GEN VISUAL	CONTROL CABIN
0600-221-01Z 0600-222-01Z	0600-221-01Z 0600-222-01Z	06-038-01		GEN VISUAL	PASSENGER CABIN-SECTION 41

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-126



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-221-02Z 0600-222-02Z	0600-221-02Z 0600-222-02Z	06-175-01		GEN VISUAL	MAIN CARGO DECK - SECTION 41
0600-221-03Z 0600-222-03Z	0600-221-03Z 0600-222-03Z	06-176-01		GEN VISUAL	***AREAS AROUND CREW ENTRY DOOR
0600-223-01Z 0600-224-01Z	0600-223-01Z 0600-224-01Z	06-039-01		GEN VISUAL	AREA ABOVE CEILING PASS CABIN-SEC 41
0600-223-02Z 0600-224-02Z	0600-223-02Z 0600-224-02Z	06-177-01		GEN VISUAL	AREA ABOVE CEILING - SECTION 41
0600-231-01Z 0600-232-01Z	0600-231-01Z 0600-232-01Z	06-040-01		GEN VISUAL	PASSENGER CABIN - SECTION 43
0600-231-02Z 0600-232-02Z	0600-231-02Z 0600-232-02Z	06-178-01		GEN VISUAL	MAIN CARGO DECK - SECTION 43
0600-233-01Z 0600-234-01Z	0600-233-01Z 0600-234-01Z	06-041-01		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 43
0600-233-02Z 0600-234-02Z	0600-233-02Z 0600-234-02Z	06-179-01		GEN VISUAL	AREA ABOVE CEILING - SECTION 43
0600-241-01Z 0600-242-01Z	0600-241-01Z 0600-242-01Z	06-042-01		GEN VISUAL	PASSENGER CABIN-SECTION 45
0600-241-02Z 0600-242-02Z	0600-241-02Z 0600-242-02Z	06-180-01		GEN VISUAL	MAIN CARGO DECK - SECTION 45
0600-243-01Z 0600-244-01Z	0600-243-01Z 0600-244-01Z	06-043-01		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 45
0600-243-02Z 0600-244-02Z	0600-243-02Z 0600-244-02Z	06-181-01		GEN VISUAL	AREA ABOVE CEILING - SECTION 45
0600-251-01Z 0600-252-01Z	0600-251-01Z 0600-252-01Z	06-044-01		GEN VISUAL	PASSENGER CABIN - SECTION 46
0600-251-02Z 0600-252-02Z	0600-251-02Z 0600-252-02Z	06-182-01		GEN VISUAL	MAIN CARGO DECK - SECTION 46
0600-253-01Z 0600-254-01Z	0600-253-01Z 0600-254-01Z	06-045-01		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 46
0600-253-02Z 0600-254-02Z	0600-253-02Z 0600-254-02Z	06-183-01		GEN VISUAL	AREA ABOVE CEILING - SECTION 46
0600-311-01Z 0600-312-01Z	0600-311-01Z 0600-312-01Z	06-046-01		GEN VISUAL	AREAS AFT OF PRESS B/H TO BS 1725.5

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-311-02Z 0600-312-02Z	0600-311-02Z 0600-312-02Z	06-046-02		GEN VISUAL	AREAS AFT OF PRESS B/H TO BS 1725.5
0600-313-01Z	0600-313-01Z	06-047-01		GEN VISUAL	STABILIZER TORSION BOX COMPT-LEFT
0600-314-01Z	0600-314-01Z	06-048-01		GEN VISUAL	STABILIZER TORSION BOX COMPT-RIGHT
0600-315-01Z 0600-316-01Z	0600-315-01Z 0600-316-01Z	06-049-01		GEN VISUAL	APU COMPARTMENT
0600-315-02Z 0600-316-02Z	0600-315-02Z 0600-316-02Z	06-050-01		GEN VISUAL	APU COMPARTMENT
0600-321-01Z	0600-321-01Z	06-051-01		GEN VISUAL	VERT STAB - REMOVABLE LEADING EDGE
0600-322-01Z	0600-322-01Z	06-052-01		GEN VISUAL	VERT STAB-AUX SPAR TO FRONT SPAR
0600-322-02Z	0600-322-02Z	06-053-01		GEN VISUAL	VERT STAB - AUX SPAR TO FRONT SPAR
0600-323-01Z	0600-323-01Z	06-054-01		GEN VISUAL	VERT STAB - FRONT SPAR TO REAR SPAR
0600-323-02Z	0600-323-02Z	06-055-01		GEN VISUAL	VERT STAB - FRONT SPAR TO REAR SPAR
0600-324-01Z	0600-324-01Z	06-056-01		GEN VISUAL	VERT STAB-REAR SPAR TO TRAILING EDGE
0600-324-02Z	0600-324-02Z	06-057-01		EX SURVEILL	VERT STAB-REAR SPAR TO TRAILING EDGE
0600-325-01Z	0600-325-01Z	06-058-01		GEN VISUAL	RUDDER
0600-326-01Z	0600-326-01Z	06-059-01		GEN VISUAL	VERT STABILIZER-TIP
0600-331-01Z 0600-341-01Z	0600-331-01Z 0600-341-01Z	06-060-01		GEN VISUAL	HORIZONTAL STAB CENTER SECTION
0600-331-02Z 0600-341-02Z	0600-331-02Z 0600-341-02Z	06-061-01		GEN VISUAL	HORIZONTAL STAB CENTER SECTION
0600-334-01Z 0600-344-01Z	0600-334-01Z 0600-344-01Z	06-062-01		GEN VISUAL	HORZ STAB-FRONT TO REAR SPAR
0600-335-01Z 0600-345-01Z	0600-335-01Z 0600-345-01Z	06-063-01		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
0600-335-02Z 0600-345-02Z	0600-335-02Z 0600-345-02Z	06-064-01		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
0600-335-03Z 0600-345-03Z	0600-335-03Z 0600-345-03Z	06-065-01		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
0600-338-01Z 0600-348-01Z	0600-338-01Z 0600-348-01Z	06-067-01		GEN VISUAL	HORIZONTAL STABILIZER-TIP

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-128



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-410-01Z	0600-410-01Z	06-157-01-1		GEN VISUAL	ENGINE 1
0600-410-02Z	0600-410-02Z	06-159-01-1		GEN VISUAL	ENGINE 1
0600-411-01Z	0600-411-01Z	06-068-01-1		GEN VISUAL	ENGINE 1
0600-411-01Z	0600-411-01Z	06-083-01-1		GEN VISUAL	ENGINE 1
0600-411-01Z	0600-411-01Z	06-161-01-1		GEN VISUAL	ENGINE 1 INSTALLATION
0600-411-02Z	0600-411-02Z	06-069-01-1		GEN VISUAL	ENGINE 1
0600-411-02Z	0600-411-02Z	06-084-01-1		GEN VISUAL	ENGINE 1
0600-411-02Z	0600-411-02Z	06-145-01-1	W-79-401-01-1	GEN VISUAL	ENGINE 1
0600-411-02Z	0600-411-02Z	06-162-01-1		GEN VISUAL	ENGINE 1
0600-412-01Z	0600-412-01Z	06-070-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-01Z	0600-412-01Z	06-085-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-01Z	0600-412-01Z	06-160-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-02Z	0600-412-02Z	06-071-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-02Z	0600-412-02Z	06-086-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-02Z	0600-412-02Z	06-152-01-1		GEN VISUAL	ENGINE 1 NOSE COWL
0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z	06-072-01-1		GEN VISUAL	FAN COWL PANELS - ENGINE 1
0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z	06-087-01-1		GEN VISUAL	FAN COWL PANELS - ENGINE 1
0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z	06-146-01-1		GEN VISUAL	ENGINE 1 FAN COWL PANELS
0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z	06-163-01-1		GEN VISUAL	HINGED COWL INNER FACE - ENGINE 1
0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z	06-073-01-1		GEN VISUAL	THRUST REVERSERS - ENGINE 1
0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z	06-088-01-1		GEN VISUAL	THRUST REVERSERS - ENGINE 1
0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z	06-144-01-1		GEN VISUAL	ENGINE 1 THRUST REVERSERS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z	06-164-01-1		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 1
0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z	06-074-01-1		GEN VISUAL	THRUST REVERSERS - ENGINE 1
0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z	06-089-01-1		GEN VISUAL	THRUST REVERSERS - ENGINE 1
0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z	06-153-01-1		GEN VISUAL	ENGINE 1 THRUST REVERSERS
0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z	06-165-01-1		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 1
0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z	06-075-01-1		GEN VISUAL	CORE COWL PANELS - ENGINE 1
0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z	06-090-01-1		GEN VISUAL	CORE COWL PANELS - ENGINE 1
0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z	06-147-01-1		GEN VISUAL	ENGINE 1 CORE COWL PANELS
0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z	06-076-01-1		GEN VISUAL	CORE COWL PANELS - ENGINE 1
0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z	06-091-01-1		GEN VISUAL	CORE COWL PANELS - ENGINE 1
0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z	06-149-01-1		GEN VISUAL	ENGINE 1 CORE COWL PANELS
0600-420-01Z	0600-420-01Z	06-157-01-2		GEN VISUAL	ENGINE 2
0600-420-02Z	0600-420-02Z	06-159-01-2		GEN VISUAL	ENGINE 2
0600-421-01Z	0600-421-01Z	06-068-01-2		GEN VISUAL	ENGINE 2
0600-421-01Z	0600-421-01Z	06-083-01-2		GEN VISUAL	ENGINE 2
0600-421-01Z	0600-421-01Z	06-161-01-2		GEN VISUAL	ENGINE 2 INSTALLATION
0600-421-02Z	0600-421-02Z	06-069-01-2		GEN VISUAL	ENGINE 2
0600-421-02Z	0600-421-02Z	06-084-01-2		GEN VISUAL	ENGINE 2
0600-421-02Z	0600-421-02Z	06-145-01-2	W-79-401-01-2	GEN VISUAL	ENGINE 2
0600-421-02Z	0600-421-02Z	06-162-01-2		GEN VISUAL	ENGINE 2

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-130



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-422-01Z	0600-422-01Z	06-070-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-01Z	0600-422-01Z	06-085-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-01Z	0600-422-01Z	06-160-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-02Z	0600-422-02Z	06-071-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-02Z	0600-422-02Z	06-086-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-02Z	0600-422-02Z	06-152-01-2		GEN VISUAL	ENGINE 2 NOSE COWL
0600-423-01Z 0600-424-01Z	0600-423-01Z 0600-424-01Z	06-072-01-2		GEN VISUAL	FAN COWL PANELS - ENGINE 2
0600-423-01Z 0600-424-01Z	0600-423-01Z 0600-424-01Z	06-087-01-2		GEN VISUAL	FAN COWL PANELS - ENGINE 2
0600-423-01Z 0600-424-01Z	0600-423-01Z 0600-424-01Z	06-146-01-2		GEN VISUAL	ENGINE 2 FAN COWL PANELS
0600-423-01Z 0600-424-01Z	0600-423-01Z 0600-424-01Z	06-163-01-2		GEN VISUAL	HINGED COWL INNER FACE - ENGINE 2
0600-425-01Z 0600-426-01Z	0600-425-01Z 0600-426-01Z	06-073-01-2		GEN VISUAL	THRUST REVERSERS - ENGINE 2
0600-425-01Z 0600-426-01Z	0600-425-01Z 0600-426-01Z	06-088-01-2		GEN VISUAL	THRUST REVERSERS - ENGINE 2
0600-425-01Z 0600-426-01Z	0600-425-01Z 0600-426-01Z	06-144-01-2		GEN VISUAL	ENGINE 2 THRUST REVERSERS
0600-425-01Z 0600-426-01Z	0600-425-01Z 0600-426-01Z	06-164-01-2		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 2
0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z	06-074-01-2		GEN VISUAL	THRUST REVERSERS - ENGINE 2
0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z	06-089-01-2		GEN VISUAL	THRUST REVERSERS - ENGINE 2
0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z	06-153-01-2		GEN VISUAL	ENGINE 2 THRUST REVERSERS
0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z	06-165-01-2		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 2
0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z	06-075-01-2		GEN VISUAL	CORE COWL PANELS - ENGINE 2

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z	06-090-01-2		GEN VISUAL	CORE COWL PANELS - ENGINE 2
0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z	06-147-01-2		GEN VISUAL	ENGINE 2 CORE COWL PANELS
0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z	06-076-01-2		GEN VISUAL	CORE COWL PANELS - ENGINE 2
0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z	06-091-01-2		GEN VISUAL	CORE COWL PANELS - ENGINE 2
0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z	06-149-01-2		GEN VISUAL	ENGINE 2 CORE COWL PANELS
0600-430-01Z	0600-430-01Z	06-158-01-1	W-06-157-01-1	GEN VISUAL	STRUT 1
0600-430-02Z	0600-430-02Z	06-166-01-1		GEN VISUAL	STRUT NO. 1
0600-431-01Z	0600-431-01Z	06-077-01-1		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 1
0600-431-01Z	0600-431-01Z	06-092-01-1		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 1
0600-431-01Z	0600-431-01Z	06-148-01-1		GEN VISUAL	STRUT 1 FWD NACELLE STRUT FAIRING
0600-431-01Z	0600-431-01Z	06-167-01-1		GEN VISUAL	FORWARD FAIRING - STRUT 1
0600-432-01Z	0600-432-01Z	06-078-01-1		GEN VISUAL	FORWARD TORQUE BOX - STRUT 1
0600-432-01Z	0600-432-01Z	06-093-01-1		GEN VISUAL	FORWARD TORQUE BOX - STRUT 1
0600-432-01Z	0600-432-01Z	06-156-01-1		GEN VISUAL	STRUT 1 FORWARD TORQUE BOX
0600-432-01Z	0600-432-01Z	06-168-01-1		GEN VISUAL	UPPER STRUCTURE - STRUT 1
0600-433-01Z	0600-433-01Z	06-079-01-1		GEN VISUAL	UNDERWING FAIRING - STRUT 1
0600-433-01Z	0600-433-01Z	06-094-01-1		GEN VISUAL	UNDERWING FAIRING - STRUT 1
0600-433-01Z	0600-433-01Z	06-150-01-1		GEN VISUAL	STRUT 1 UNDERWING FAIRING
0600-433-01Z	0600-433-01Z	06-169-01-1		GEN VISUAL	MID STRUCTURE - STRUT 1
0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z	06-080-01-1		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 1
0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z	06-095-01-1		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 1
0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z	06-151-01-1		GEN VISUAL	STRUT 1 MID AND AFT TORQUE BOXES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-132



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-434-01Z	0600-434-01Z	06-170-01-1		GEN VISUAL	AFT FAIRING - STRUT 1
0600-435-01Z	0600-435-01Z	06-081-01-1		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 1
0600-435-01Z	0600-435-01Z	06-096-01-1		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 1
0600-435-01Z	0600-435-01Z	06-155-01-1		GEN VISUAL	STRUT 1 CORE COWL SKIRT FAIRINGS
0600-437-01Z	0600-437-01Z	06-082-01-1		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 1
0600-437-01Z	0600-437-01Z	06-097-01-1		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 1
0600-437-01Z	0600-437-01Z	06-154-01-1		GEN VISUAL	STRUT 1 AFT NACELLE STRUT FAIRINGS
0600-440-01Z	0600-440-01Z	06-158-01-2	W-06-157-01-2	GEN VISUAL	STRUT 2
0600-440-02Z	0600-440-02Z	06-166-01-2		GEN VISUAL	STRUT NO. 2
0600-441-01Z	0600-441-01Z	06-077-01-2		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 2
0600-441-01Z	0600-441-01Z	06-092-01-2		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 2
0600-441-01Z	0600-441-01Z	06-148-01-2		GEN VISUAL	STRUT 2 FWD NACELLE STRUT FAIRING
0600-441-01Z	0600-441-01Z	06-167-01-2		GEN VISUAL	FORWARD FAIRING - STRUT 2
0600-442-01Z	0600-442-01Z	06-078-01-2		GEN VISUAL	FORWARD TORQUE BOX - STRUT 2
0600-442-01Z	0600-442-01Z	06-093-01-2		GEN VISUAL	FORWARD TORQUE BOX - STRUT 2
0600-442-01Z	0600-442-01Z	06-156-01-2		GEN VISUAL	STRUT 2 FORWARD TORQUE BOX
0600-442-01Z	0600-442-01Z	06-168-01-2		GEN VISUAL	UPPER STRUCTURE - STRUT 2
0600-443-01Z	0600-443-01Z	06-079-01-2		GEN VISUAL	UNDERWING FAIRING - STRUT 2
0600-443-01Z	0600-443-01Z	06-094-01-2		GEN VISUAL	UNDERWING FAIRING - STRUT 2
0600-443-01Z	0600-443-01Z	06-150-01-2		GEN VISUAL	STRUT 2 UNDERWING FAIRING
0600-443-01Z	0600-443-01Z	06-169-01-2		GEN VISUAL	MID STRUCTURE - STRUT 2
0600-444-01Z 0600-446-01Z	0600-444-01Z 0600-446-01Z	06-080-01-2		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 2
0600-444-01Z 0600-446-01Z	0600-444-01Z 0600-446-01Z	06-095-01-2		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 2
0600-444-01Z 0600-446-01Z	0600-444-01Z 0600-446-01Z	06-151-01-2		GEN VISUAL	STRUT 2 MID AND AFT TORQUE BOXES

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-444-01Z	0600-444-01Z	06-170-01-2		GEN VISUAL	AFT FAIRING - STRUT 2
0600-445-01Z	0600-445-01Z	06-081-01-2		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 2
0600-445-01Z	0600-445-01Z	06-096-01-2		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 2
0600-445-01Z	0600-445-01Z	06-155-01-2		GEN VISUAL	STRUT 2 CORE COWL SKIRT FAIRINGS
0600-447-01Z	0600-447-01Z	06-082-01-2		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 2
0600-447-01Z	0600-447-01Z	06-097-01-2		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 2
0600-447-01Z	0600-447-01Z	06-154-01-2		GEN VISUAL	STRUT 2 AFT NACELLE STRUT FAIRINGS
0600-511-01Z	0600-511-01Z	06-098-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD
0600-511-02Z	0600-511-02Z	06-099-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD
0600-511-03Z	0600-511-03Z	06-100-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD
0600-512-01Z	0600-512-01Z	06-101-01-1		GEN VISUAL	INBOARD SLAT (NO. 6) - LEFT WING
0600-513-01Z	0600-513-01Z	06-144-01		GEN VISUAL	KRUEGER FLAP - LEFT WING
0600-521-01Z	0600-521-01Z	06-102-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - OUTBOARD
0600-521-02Z	0600-521-02Z	06-103-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - OUTBOARD
0600-522-01Z	0600-522-01Z	06-104-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 5) - LEFT WING
0600-522-02Z	0600-522-02Z	06-105-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 5) - LEFT WING
0600-523-01Z	0600-523-01Z	06-106-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 4) - LEFT WING
0600-523-02Z	0600-523-02Z	06-107-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 4) - LEFT WING
0600-524-01Z	0600-524-01Z	06-108-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 3) - LEFT WING
0600-524-02Z	0600-524-02Z	06-109-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 3) - LEFT WING
0600-525-01Z	0600-525-01Z	06-110-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 2) - LEFT WING
0600-525-02Z	0600-525-02Z	06-111-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 2) - LEFT WING
0600-526-01Z	0600-526-01Z	06-112-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 1) - LEFT WING
0600-526-02Z	0600-526-02Z	06-113-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 1) - LEFT WING
0600-531-01Z	0600-531-01Z	06-114-01-1		GEN VISUAL	CENTER AUXILIARY TANK - LEFT WING
0600-532-01Z	0600-532-01Z	06-115-01-1		GEN VISUAL	MAIN TANK (INBD OF RIB 10)-LEFT WING

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-134



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-533-01Z	0600-533-01Z	06-116-01-1		GEN VISUAL	DRY BAY - INBOARD LEFT WING
0600-541-01Z	0600-541-01Z	06-117-01-1		GEN VISUAL	MAIN TANK (OB OF RIB 10) - LEFT WING
0600-542-01Z	0600-542-01Z	06-118-01-1		GEN VISUAL	SURGE TANK - LEFT WING
0600-544-01Z	0600-544-01Z	06-119-01-1		GEN VISUAL	WING TIP - LEFT WING
0600-551-01Z	0600-551-01Z	06-120-01-1		GEN VISUAL	REAR SPAR TO MLG SUPPORT BEAM-L WING
0600-552-01Z	0600-552-01Z	06-121-01-1	W-06-123-01-1	GEN VISUAL	L MLG SUPT BEAM & REAR SPAR TO TE
0600-555-01Z	0600-555-01Z	06-122-01-1		GEN VISUAL	INBOARD TRAILING EDGE FLAP - L WING
0600-556-01Z	0600-556-01Z	06-123-01-1	W-06-121-01-1	GEN VISUAL	INBOARD AILERON - LEFT WING
0600-561-01Z	0600-561-01Z	06-124-01-1	W-06-125-01-1	GEN VISUAL	REAR SPAR TO WING TE - LEFT WING
0600-567-01Z	0600-567-01Z	06-125-01-1	W-06-124-01-1	GEN VISUAL	OUTBOARD AILERON - LEFT WING
0600-567-02Z	0600-567-02Z	06-126-01-1		GEN VISUAL	OUTBOARD AILERON - LEFT WING
0600-571-01Z	0600-571-01Z	06-127-01-1		GEN VISUAL	OB FLAP SUPPORT FAIRING - L IB FLAP
0600-572-01Z	0600-572-01Z	06-128-01-1		GEN VISUAL	IB FLAP SUPPORT FAIRING - L OB FLAP
0600-573-01Z	0600-573-01Z	06-129-01-1		GEN VISUAL	OB FLAP SUPPORT FAIRING - L OB FLAP
0600-611-01Z	0600-611-01Z	06-098-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD
0600-611-02Z	0600-611-02Z	06-099-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD
0600-611-03Z	0600-611-03Z	06-100-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD
0600-612-01Z	0600-612-01Z	06-101-01-2		GEN VISUAL	INBOARD SLAT (NO. 7) - RIGHT WING
0600-613-01Z	0600-613-01Z	06-144-02		GEN VISUAL	KRUEGER FLAP - RIGHT WING
0600-621-01Z	0600-621-01Z	06-102-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - OUTBOARD
0600-621-02Z	0600-621-02Z	06-103-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - OUTBOARD
0600-622-01Z	0600-622-01Z	06-104-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 8) - RIGHT WING
0600-622-02Z	0600-622-02Z	06-105-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 8) - RIGHT WING
0600-623-01Z	0600-623-01Z	06-106-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 9) - RIGHT WING
0600-623-02Z	0600-623-02Z	06-107-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 9) - RIGHT WING
0600-624-01Z	0600-624-01Z	06-108-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 10) - RIGHT WING

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-624-02Z	0600-624-02Z	06-109-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 10) - RIGHT WING
0600-625-01Z	0600-625-01Z	06-110-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 11) - RIGHT WING
0600-625-02Z	0600-625-02Z	06-111-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 11) - RIGHT WING
0600-626-01Z	0600-626-01Z	06-112-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 12) - RIGHT WING
0600-626-02Z	0600-626-02Z	06-113-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 12) - RIGHT WING
0600-631-01Z	0600-631-01Z	06-114-01-2		GEN VISUAL	CENTER AUXILIARY TANK - RIGHT WING
0600-632-01Z	0600-632-01Z	06-115-01-2		GEN VISUAL	MAIN TANK(INBD OF RIB 10)-RIGHT WING
0600-633-01Z	0600-633-01Z	06-116-01-2		GEN VISUAL	DRY BAY - INBOARD RIGHT WING
0600-641-01Z	0600-641-01Z	06-117-01-2		GEN VISUAL	MAIN TANK (OB OF RIB 10)- RIGHT WING
0600-642-01Z	0600-642-01Z	06-118-01-2		GEN VISUAL	SURGE TANK - RIGHT WING
0600-644-01Z	0600-644-01Z	06-119-01-2		GEN VISUAL	WING TIP - RIGHT WING
0600-651-01Z	0600-651-01Z	06-120-01-2		GEN VISUAL	REAR SPAR TO MLG SUPPORT BEAM-R WING
0600-652-01Z	0600-652-01Z	06-121-01-2	W-06-123-01-2	GEN VISUAL	R MLG SUPT BEAM & REAR SPAR TO TE
0600-655-01Z	0600-655-01Z	06-122-01-2		GEN VISUAL	INBOARD TRAILING EDGE FLAP - R WING
0600-656-01Z	0600-656-01Z	06-123-01-2	W-06-121-01-2	GEN VISUAL	INBOARD AILERON - RIGHT WING
0600-661-01Z	0600-661-01Z	06-124-01-2	W-06-125-01-2	GEN VISUAL	REAR SPAR TO WING TE - RIGHT WING
0600-667-01Z	0600-667-01Z	06-125-01-2	W-06-124-01-2	GEN VISUAL	OUTBOARD AILERON - RIGHT WING
0600-667-02Z	0600-667-02Z	06-126-01-2		GEN VISUAL	OUTBOARD AILERON - RIGHT WING
0600-671-01Z	0600-671-01Z	06-127-01-2		GEN VISUAL	OB FLAP SUPPORT FAIRING - R IB FLAP
0600-672-01Z	0600-672-01Z	06-128-01-2		GEN VISUAL	IB FLAP SUPPORT FAIRING - R OB FLAP
0600-673-01Z	0600-673-01Z	06-129-01-2		GEN VISUAL	OB FLAP SUPPORT FAIRING - R OB FLAP
0600-711-01Z	0600-711-01Z	06-130-01		GEN VISUAL	NOSE LANDING GEAR
0600-731-01Z	0600-731-01Z	06-131-01-1		GEN VISUAL	LEFT MAIN LANDING GEAR
0600-741-01Z	0600-741-01Z	06-131-01-2		GEN VISUAL	RIGHT MAIN LANDING GEAR
0600-811-01Z	0600-811-01Z	06-132-01		GEN VISUAL	BULK CARGO COMPARTMENT DOOR
0600-811-02Z	0600-811-02Z	06-133-01		GEN VISUAL	BULK CARGO COMPARTMENT DOOR

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-136



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-821-01Z	0600-821-01Z	06-134-01		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR
0600-821-02Z	0600-821-02Z	06-135-01		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR
0600-821-02Z	0600-821-02Z	06-135-02		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR
0600-822-01Z	0600-822-01Z	06-136-01		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
0600-822-02Z	0600-822-02Z	06-137-01		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
0600-822-02Z	0600-822-02Z	06-187-01		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
0600-831-01Z	0600-831-01Z	06-138-01		GEN VISUAL	PASS CABIN DOOR - FORWARD ENTRY
0600-831-01Z	0600-831-01Z	06-188-01		GEN VISUAL	CREW ENTRY DOOR - FORWARD ENTRY
0600-832-01Z	0600-832-01Z	06-139-01-1		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
0600-832-01Z 0600-834-01Z	0600-832-01Z 0600-834-01Z	06-139-02-1		GEN VISUAL	OVERWING EMERGENCY EXITS - LEFT
0600-832-02Z	0600-832-02Z	06-140-01-1		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
0600-832-02Z 0600-834-02Z	0600-832-02Z 0600-834-02Z	06-140-02-1		GEN VISUAL	OVERWING EMERGENCY EXITS - LEFT
0600-833-01Z	0600-833-01Z	06-141-01		GEN VISUAL	PASSENGER CABIN DOOR - AFT ENTRY
0600-834-01Z	0600-834-01Z	06-139-03-1		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
0600-834-02Z	0600-834-02Z	06-140-03-1		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
0600-835-01Z	0600-835-01Z	06-141-02		GEN VISUAL	PASS CABIN DOOR - CENTER ENTRY
0600-836-01Z	0600-836-01Z	06-173-01-1		GEN VISUAL	EMERGENCY EXIT DOOR - LEFT
0600-836-02Z	0600-836-02Z	06-174-01-2		GEN VISUAL	EMERGENCY EXIT DOOR - LEFT
0600-838-01Z	0600-838-01Z	06-184-01		GEN VISUAL	MAIN DECK CARGO COMPARTMENT DOOR
0600-838-02Z	0600-838-02Z	06-185-01		GEN VISUAL	MAIN DECK CARGO COMPARTMENT DOOR
0600-841-01Z	0600-841-01Z	06-142-01		GEN VISUAL	PASSENGER CABIN DOOR-FORWARD SERVICE
0600-842-01Z	0600-842-01Z	06-139-01-2		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
0600-842-01Z 0600-844-01Z	0600-842-01Z 0600-844-01Z	06-139-02-2		GEN VISUAL	OVERWING EMERGENCY EXITS - RIGHT
0600-842-02Z	0600-842-02Z	06-140-01-2		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
0600-842-02Z 0600-844-02Z	0600-842-02Z 0600-844-02Z	06-140-02-2		GEN VISUAL	OVERWING EMERGENCY EXITS - RIGHT
0600-843-01Z	0600-843-01Z	06-143-01		GEN VISUAL	PASSENGER CABIN DOOR - AFT SERVICE
0600-844-01Z	0600-844-01Z	06-139-03-2		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
0600-844-02Z	0600-844-02Z	06-140-03-2		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
0600-845-01Z	0600-845-01Z	06-143-02		GEN VISUAL	PASS CABIN DOOR - CENTER SERVICE
0600-846-01Z	0600-846-01Z	06-173-01-2		GEN VISUAL	EMERGENCY EXIT DOOR - RIGHT
0600-846-02Z	0600-846-02Z	06-174-01-1		GEN VISUAL	EMERGENCY EXIT DOOR - RIGHT
27-696-00	27-696-00	27-696-00		SPCL DETAIL	STABILIZER TRIM ACTUATOR
27-698-00	27-698-00	27-698-00		SPCL DETAIL	STABILIZER TRIM ACTUATOR
32-400-00	32-400-00	32-400-00		GEN VISUAL	NOSE LANDING GEAR
32-402-00	32-402-00	32-402-00		GEN VISUAL	NOSE LANDING GEAR ASSEMBLY
32-404-00	32-404-00	32-404-00		DETAILED EX	NOSE LANDING GEAR ASSEMBLY
32-406-00	32-406-00	32-406-00		GEN VISUAL	NOSE LANDING GEAR DOOR ASSEMBLY
32-408-00	32-408-00	32-408-00		GEN VISUAL	NOSE LG FWD AND AFT DOOR ASSEMBLY
32-410-00	32-410-00	32-410-00		RESTORE	LEFT MAIN LG AND COMPONENTS
32-412-00	32-412-00	32-412-00		GEN VISUAL	LEFT MAIN LANDING GEAR ASSEMBLY
32-414-00	32-414-00	32-414-00		DETAILED EX	LEFT MAIN LANDING GEAR ASSEMBLY
32-416-00	32-416-00	32-416-00		GEN VISUAL	LEFT MAIN LANDING GEAR ASSEMBLY
32-418-00	32-418-00	32-418-00		GEN VISUAL	LEFT MAIN LANDING GEAR BODY DOOR
32-420-00	32-420-00	32-420-00		GEN VISUAL	LEFT MAIN LANDING GEAR DOOR
32-422-00	32-422-00	32-422-00		DETAILED EX	L MAIN GEAR DOOR CENTER HINGE BEAM
32-424-00	32-424-00	32-424-00		RESTORE	RIGHT MAIN LANDING GEAR ASSEMBLY
32-426-00	32-426-00	32-426-00		GEN VISUAL	RIGHT MAIN LANDING GEAR ASSEMBLY
32-428-00	32-428-00	32-428-00		DETAILED EX	RIGHT MAIN LANDING GEAR ASSEMBLY
32-430-00	32-430-00	32-430-00		GEN VISUAL	RIGHT MAIN LANDING GEAR ASSEMBLY

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-138



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
32-432-00	32-432-00	32-432-00		GEN VISUAL	RIGHT MAIN LANDING GEAR BODY DOOR
32-434-00	32-434-00	32-434-00		GEN VISUAL	R MAIN LANDING GEAR DOOR ASSEMBLY
32-436-00	32-436-00	32-436-00		DETAILED EX	R MAIN GEAR DOOR CENTER HINGE BEAM
52-400-00	52-400-00	52-400-00		GEN VISUAL	BULK CARGO COMPARTMENT DOOR STOPS
52-402-00	52-402-00	52-402-00		GEN VISUAL	BULK CARGO COMPARTMENT DOOR
52-406-00	52-406-00	52-406-00		GEN VISUAL	FWD CARGO COMPARTMENT DOOR
52-408-00	52-408-00	52-408-00		GEN VISUAL	CARGO DOOR STOPS
52-410-00	52-410-00	52-410-00		GEN VISUAL	AFT CARGO DOOR
52-412-00	52-412-00	52-412-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-414-00	52-414-00	52-414-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-416-00	52-416-00	52-416-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-418-00	52-418-00	52-418-00		GEN VISUAL	OVERWING EMERGENCY EXIT HATCH
52-420-00	52-420-00	52-420-00		GEN VISUAL	EMERGENCY EXIT DOOR
52-422-00	52-422-00	52-422-00		GEN VISUAL	EMERGENCY EXIT DOOR
52-424-00	52-424-00	52-424-00		GEN VISUAL	CREW ENTRY DOOR
52-426-00	52-426-00	52-426-00		GEN VISUAL	CREW ENTRY DOORS
52-428-00	52-428-00	52-428-00		GEN VISUAL	CREW ENTRY DOOR
52-430-00	52-430-00	52-430-00		GEN VISUAL	MAIN DECK CARGO DOOR
52-432-00	52-432-00	52-432-00		SPCL DETAIL	STANDARD CARGO DOOR - FWD AND AFT
52-434-00	52-434-00	52-434-00		SPCL DETAIL	FWD LARGE CARGO DOOR
52-436-00	52-436-00	52-436-00		SPCL DETAIL	FWD LARGE CARGO DOOR
52-438-00	52-438-00	52-438-00		SPCL DETAIL	FWD LARGE CARGO DOOR
52-440-00	52-440-00	52-440-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-441-00	52-441-00	52-441-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-442-00	52-442-00	52-442-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-444-00	52-444-00	52-444-00		SPCL DETAIL	MAIN DECK CARGO DOOR

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
52-446-00	52-446-00	52-446-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-448-00	52-448-00	52-448-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-450-00	52-450-00	52-450-00		SPCL DETAIL	AFT LARGE CARGO DOOR
52-452-00	52-452-00	52-452-00		SPCL DETAIL	AFT LARGE CARGO DOOR
52-454-00	52-454-00	52-454-00		SPCL DETAIL	AFT LARGE CARGO DOOR
53-400-00	53-400-00	53-400-00		GEN VISUAL	BODY FLOOR BEAMS BELOW LAVS/GALLEYS
53-402-00	53-402-00	53-402-00		GEN VISUAL	CARGO FLOOR STRUCTURE
53-404-00	53-404-00	53-404-00		DETAILED IN	CARGO DOOR CUTOUTS
53-406-00	53-406-00	53-406-00		GEN VISUAL	BODY EXTERNAL SKIN
53-408-00	53-408-00	53-408-00		DETAILED EX	LARGE FWD CARGO DOOR HINGES
53-410-00	53-410-00	53-410-00		GEN VISUAL	LWR BODY SKIN AT ANTENNA LOCATIONS
53-412-00	53-412-00	53-412-00		DETAILED EX	DOOR STOPS AND CUTOUTS
53-414-00	53-414-00	53-414-00		DETAILED IN	BODY STA. 132.5 BULKHEAD
53-416-00	53-416-00	53-416-00		GEN VISUAL	FUSELAGE LOWER LOBE
53-418-00	53-418-00	53-418-00		DETAILED IN	FWD EQUIP BAY ACCESS DOOR CUTOUT
53-420-00	53-420-00	53-420-00		GEN VISUAL	FUSELAGE EXTERIOR SURFACE
53-428-00	53-428-00	53-428-00		GEN VISUAL	NOSE LANDING GEAR WHEEL WELL
53-430-00	53-430-00	53-430-00		GEN VISUAL	AREA OUTBD & ABOVE NOSE WHEELWELL
53-432-00	53-432-00	53-432-00		DETAILED IN	BULKHEAD AND NOSE LANDING GEAR W/W
53-438-00	53-438-00	53-438-00		DETAILED IN	BODY FLOOR BEAM - STA 287
53-440-00	53-440-00	53-440-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-442-00	53-442-00	53-442-00		DETAILED IN	FWD ENTRY/SERVICE DOOR CUTOUTS
53-444-00	53-444-00	53-444-00		GEN VISUAL	MAIN EQUIPMENT CENTER ACCESS DOOR
53-446-00	53-446-00	53-446-00		DETAILED IN	MAIN EQUIPMENT CENTER
53-448-00	53-448-00	53-448-00		GEN VISUAL	MAIN EQUIPMENT CENTER ACCESS DOOR
53-450-00	53-450-00	53-450-00		DETAILED IN	BODY FLOOR BEAMS - STA 287 TO 347

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-140



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-452-00	53-452-00	53-452-00		GEN VISUAL	FUSELAGE LOWER LOBE
53-454-00	53-454-00	53-454-00		GEN VISUAL	LOWER LOBE INTERIOR - RIGHT
53-456-00	53-456-00	53-456-00		DETAILED IN	FORWARD CARGO DOOR LOWER SILL
53-458-00	53-458-00	53-458-00		DETAILED IN	FWD CARGO COMPARTMENT DOOR CUTOUT
53-460-00	53-460-00	53-460-00		DETAILED IN	BODY BELOW FWD CARGO COMPART FLOOR
53-462-00	53-462-00	53-462-00		DETAILED IN	BODY BELOW FWD CARGO FLOOR/STA 434
53-464-00	53-464-00	53-464-00		DETAILED IN	BODY BELOW FWD CARGO FLOOR
53-472-00	53-472-00	53-472-00		DETAILED IN	FWD LARGE CARGO DOOR CUTOUT
53-474-00	53-474-00	53-474-00		GEN VISUAL	AREA AFT OF FWD CARGO COMPARTMENT
53-476-00	53-476-00	53-476-00		GEN VISUAL	AREA AFT OF FWD CARGO COMPARTMENT
53-478-00	53-478-00	53-478-00		DETAILED IN	KEEL BEAM EXTENSION 738.5 - 785.9
53-480-00	53-480-00	53-480-00		DETAILED IN	BODY STA 785.9 BULKHEAD INNER CHORD
53-482-00	53-482-00	53-482-00		GEN VISUAL	FRONT SPAR BULKHEAD BELOW FLOOR
53-494-00	53-494-00	53-494-00		GEN VISUAL	INTERIOR FUSELAGE INSPECTION
53-496-00	53-496-00	53-496-00		DETAILED IN	WING CENTER SECTION UPPER SURFACE
53-502-00	53-502-00	53-502-00		GEN VISUAL	KEEL BEAM & WING CENTER SECTION
53-504-00	53-504-00	53-504-00		DETAILED IN	WING CENTER SECTION TENSION FITTING
53-506-00	53-506-00	53-506-00		GEN VISUAL	LOWER LOBE INTERIOR
53-508-00	53-508-00	53-508-00		DETAILED IN	BELOW FLOOR STRUCT - STA 955 TO 1065
53-510-00	53-510-00	53-510-00		DETAILED IN	BELOW FLOOR STRUCT - STA 955 TO 1065
53-518-00	53-518-00	53-518-00		GEN VISUAL	MAIN LANDING GEAR WHEEL WELL STRUCT
53-520-00	53-520-00	53-520-00		DETAILED IN	TRANSVERSE BEAMS
53-522-00	53-522-00	53-522-00		DETAILED IN	MAIN LANDING GEAR DOOR UPLOCK
53-524-00	53-524-00	53-524-00		DETAILED IN	REAR SPAR BULKHEAD AT WHEEL WELL
53-526-00	53-526-00	53-526-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-528-00	53-528-00	53-528-00		DETAILED IN	REAR SPAR AT KEEL BEAM

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-530-00	53-530-00	53-530-00		GEN VISUAL	MAIN LANDING GEAR WHEEL WELL STRUCT
53-532-00	53-532-00	53-532-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-534-00	53-534-00	53-534-00		DETAILED IN	MAIN LANDING GEAR DOOR UPLOCK
53-536-00	53-536-00	53-536-00		DETAILED IN	REAR SPAR BULKHEAD AT WHEEL WELL
53-538-00	53-538-00	53-538-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-540-00	53-540-00	53-540-00		GEN VISUAL	KEEL BEAM - AFT SECTION
53-542-00	53-542-00	53-542-00		GEN VISUAL	BODY FWD OF AFT CARGO COMPARTMENT
53-544-00	53-544-00	53-544-00		DETAILED IN	BODY FWD OF AFT CARGO COMPARTMENT
53-548-00	53-548-00	53-548-00		DETAILED IN	BODY FWD OF AFT CARGO COMPARTMENT
53-550-00	53-550-00	53-550-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-552-00	53-552-00	53-552-00		GEN VISUAL	CARGO COMPARTMENT
53-554-00	53-554-00	53-554-00		DETAILED IN	AFT CARGO DOOR LOWER SILL
53-556-00	53-556-00	53-556-00		DETAILED IN	AFT CARGO COMPARTMENT DOOR CUTOUT
53-558-00	53-558-00	53-558-00		DETAILED IN	BODY BELOW AFT CARGO COMPART FLOOR
53-560-00	53-560-00	53-560-00		DETAILED IN	BODY BELOW AFT CARGO FLOOR/STA 1307
53-562-00	53-562-00	53-562-00		DETAILED IN	FRAME UPPER CHORDS AT NUT PLATE
53-564-00	53-564-00	53-564-00		GEN VISUAL	FUSELAGE EXTERIOR SURFACE
53-572-00	53-572-00	53-572-00		GEN VISUAL	BULK CARGO COMPARTMENT
53-574-00	53-574-00	53-574-00		DETAILED IN	BULK CARGO DOOR LOWER SILL
53-576-00	53-576-00	53-576-00		DETAILED IN	AFT ENTRY/SERVICE DOOR CUTOUTS
53-578-00	53-578-00	53-578-00		GEN VISUAL	LOWER LOBE INTERIOR - RIGHT
53-582-00	53-582-00	53-582-00		DETAILED IN	AFT ENTRY/SERVICE DOOR CUTOUTS
53-584-00	53-584-00	53-584-00		DETAILED IN	BULK CARGO COMPARTMENT FLOOR & BELOW
53-586-00	53-586-00	53-586-00		DETAILED IN	LOWER LOBE INTERIOR BODY SKIN
53-588-00	53-588-00	53-588-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-590-00	53-590-00	53-590-00		GEN VISUAL	LOWER LOBE INTERIOR - LEFT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-142



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-592-00	53-592-00	53-592-00		DETAILED IN	BODY BELOW FLOOR-REAR PRESSURE DOME
53-594-00	53-594-00	53-594-00		GEN VISUAL	FUSELAGE EXTERIOR
53-602-00	53-602-00	53-602-00		GEN VISUAL	UPPER WING/SIDE OF BODY SPLICE
53-606-00	53-606-00	53-606-00		DETAILED IN	OVERWING LONGERON
53-608-00	53-608-00	53-608-00		GEN VISUAL	UPPER WING/SIDE OF BODY SPLICE
53-610-00	53-610-00	53-610-00		GEN VISUAL	WING LWR SURFACE BL 62 -FAIRING EDGE
53-612-00	53-612-00	53-612-00		DETAILED IN	OVERWING LONGERON
53-614-00	53-614-00	53-614-00		GEN VISUAL	WING LWR SURF BL 62 - FAIRING EDGE
53-616-00	53-616-00	53-616-00		DETAILED IN	LWR SIDE OF BODY SPLICE PLATES
53-618-00	53-618-00	53-618-00		DETAILED IN	LWR WING SURFACE AT REAR SPAR CHORD
53-620-00	53-620-00	53-620-00		DETAILED IN	WING LWR REAR SPAR SPLICE FITTING
53-622-00	53-622-00	53-622-00		DETAILED IN	BL 70 UNDERWING LONGERON FITTING
53-624-00	53-624-00	53-624-00		GEN VISUAL	WING LWR SURFACE BL 62 -FAIRING EDGE
53-626-00	53-626-00	53-626-00		DETAILED IN	LWR SIDE OF BODY SPLICE PLATES
53-628-00	53-628-00	53-628-00		DETAILED IN	LWR WING SURFACE AT REAR SPAR CHORD
53-630-00	53-630-00	53-630-00		DETAILED IN	WING LWR REAR SPAR SPLICE FITTING
53-632-00	53-632-00	53-632-00		DETAILED IN	BL 70 UNDERWING LONGERON FITTING
53-634-00	53-634-00	53-634-00		GEN VISUAL	WING-TO-BODY FAIRING
53-636-00	53-636-00	53-636-00		GEN VISUAL	SKIN UNDER WING/BODY AFT FAIRING
53-638-00	53-638-00	53-638-00		GEN VISUAL	SKIN UNDER WING/BODY AFT L FAIRING
53-640-00	53-640-00	53-640-00		GEN VISUAL	SKIN UNDER WING/BODY AFT R FAIRING
53-642-00	53-642-00	53-642-00		GEN VISUAL	STRUCTURE FWD LAVS, GALLEYS & DOORS
53-644-00	53-644-00	53-644-00		GEN VISUAL	STRUCTURE CTR & AFT GAL, LAV & DOORS
53-646-00	53-646-00	53-646-00		GEN VISUAL	SEAT TRACKS
53-648-00	53-648-00	53-648-00		GEN VISUAL	BODY EXTERNAL SKIN
53-650-00	53-650-00	53-650-00		DETAILED EX	DOOR STOPS AND CUTOUTS

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-652-00	53-652-00	53-652-00		GEN VISUAL	MAIN DECK DOOR & HATCH INTERIORS
53-654-00	53-654-00	53-654-00		GEN VISUAL	CONTROL CABIN WINDSHIELD STRUCTURE
53-656-00	53-656-00	53-656-00		GEN VISUAL	CONTROL CABIN FLOOR STRUCTURE
53-662-00	53-662-00	53-662-00		GEN VISUAL	FUSELAGE UPPER LOBE INT STRUCTURE
53-664-00	53-664-00	53-664-00		DETAILED IN	FLIGHT DECK SECURITY DOOR
53-666-00	53-666-00	53-666-00		DETAILED IN	FWD ENTRY/SERVICE DOOR LOWER SILL
53-668-00	53-668-00	53-668-00		DETAILED IN	CREW ENTRY DOOR LOWER SILL
53-670-00	53-670-00	53-670-00		GEN VISUAL	CARGO FLOOR STRUCTURE - SHEAR WEB
53-674-00	53-674-00	53-674-00		DETAILED IN	FWD ENTRY/SERVICE DOOR LOWER SILL
53-678-00	53-678-00	53-678-00		GEN VISUAL	UPPER LOBE INTERIOR
53-682-00	53-682-00	53-682-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-684-00	53-684-00	53-684-00		DETAILED IN	MID-CABIN ENTRY/SVC DOOR LOWER SILL
53-686-00	53-686-00	53-686-00		DETAILED IN	MAIN DECK CARGO DOOR CUTOUT SILL
53-688-00	53-688-00	53-688-00		GEN VISUAL	MID ENTRY/SERVICE DOOR CUTOUTS
53-690-00	53-690-00	53-690-00		GEN VISUAL	MAIN DECK CARGO DOOR CUTOUT
53-692-00	53-692-00	53-692-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-694-00	53-694-00	53-694-00		DETAILED IN	MID-CABIN ENTRY/SVC DOOR LOWER SILL
53-696-00	53-696-00	53-696-00		GEN VISUAL	MID ENTRY/SERVICE DOOR CUTOUTS
53-698-00	53-698-00	53-698-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-700-00	53-700-00	53-700-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-704-00	53-704-00	53-704-00		GEN VISUAL	FUSELAGE UPPER LOBE INT
53-706-00	53-706-00	53-706-00		GEN VISUAL	PASS CABIN ABOVE CEILING 785-1065
53-710-00	53-710-00	53-710-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-712-00	53-712-00	53-712-00		DETAILED IN	AFT ENTRY/SERVICE DOOR LOWER SILL
53-714-00	53-714-00	53-714-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-716-00	53-716-00	53-716-00		DETAILED IN	AFT ENTRY/SERVICE DOOR LOWER SILL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-144



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-718-00	53-718-00	53-718-00		GEN VISUAL	LARGE AFT CARGO DOOR CUTOUT
53-720-00	53-720-00	53-720-00		IN SURVEILL	FUSELAGE UPPER LOBE INT
53-726-00	53-726-00	53-726-00		DETAILED IN	AFT BODY, STA. 1702 - 1725.5
53-728-00	53-728-00	53-728-00		DETAILED IN	H STABILIZER TRIM ACTUATOR SUPPORT
53-730-00	53-730-00	53-730-00		GEN VISUAL	EXT SECTION 48, LEFT SIDE
53-732-00	53-732-00	53-732-00		DETAILED IN	AFT PRESSURE BULKHEAD - STA 1582
53-734-00	53-734-00	53-734-00		CHECK/INSP	VERTICAL STABILIZER ATTACH BOLT
53-740-00	53-740-00	53-740-00		GEN VISUAL	EXT OF SECTION 48, RIGHT SIDE
53-746-00	53-746-00	53-746-00		DETAILED IN	H STABILIZER PIVOT FITTINGS
53-748-00	53-748-00	53-748-00		DETAILED IN	BODY LONGERONS AT HORIZ STAB CUTOUT
53-750-00	53-750-00	53-750-00		GEN VISUAL	SECTION 48 EXTERIOR - LEFT
53-756-00	53-756-00	53-756-00		GEN VISUAL	SECTION 48 EXTERIOR - RIGHT
53-758-00	53-758-00	53-758-00		GEN VISUAL	APU COMPARTMENT EXTERNAL SURFACE
53-762-00	53-762-00	53-762-00		GEN VISUAL	SECTION 48 EXTERIOR
53-778-12	53-778-12	53-778-12		DETAILED IN	BODY STA 1809.5 BHD OUTBD CHORD
53-778-14	53-778-14	53-778-14		SPCL DETAIL	BODY STA 1809.5 BHD OUTBD CHORD
53-778-16	53-778-16	53-778-16		SPCL DETAIL	HORIZONTAL STABILIZER PIVOT FITTINGS
53-778-18	53-778-18	53-778-18		SPCL DETAIL	HORIZONTAL STABILIZER PIVOT PINS
53-778-20	53-778-20	53-778-20		DETAILED EX	BODY STA 1809.5 BHD OUTBD CHORD
53-780-00	53-780-00	53-780-00		SPCL DETAIL	BODY STA 1809.5 BHD OUTBD CHORD
53-780-02	53-780-02	53-780-02		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-780-04	53-780-04	53-780-04		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-780-06	53-780-06	53-780-06		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-780-08	53-780-08	53-780-08		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-780-10	53-780-10	53-780-10		SPCL DETAIL	H STABILIZ TRIM ACTUATOR
53-780-12	53-780-12	53-780-12		SPCL DETAIL	EMERGENCY EXIT DOOR CUTOUT

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-780-14	53-780-14	53-780-14		SPCL DETAIL	EMERGENCY EXIT DOOR CUTOUT
53-780-16	53-780-16	53-780-16		SPCL DETAIL	AFT ENTRY/SERVICE DOOR CUTOUT
53-780-18	53-780-18	53-780-18		SPCL DETAIL	AFT ENTRY/SERVICE DOOR CUTOUT
53-780-20	53-780-20	53-780-20		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-00	53-782-00	53-782-00		DETAILED IN	OVERWING EMERGENCY EXIT CUTOUT
53-782-02	53-782-02	53-782-02		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-04	53-782-04	53-782-04		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-06	53-782-06	53-782-06		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-08	53-782-08	53-782-08		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-10	53-782-10	53-782-10		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-12	53-782-12	53-782-12		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-14	53-782-14	53-782-14		DETAILED IN	OVERWING EMERGENCY EXIT CUTOUT
53-782-16	53-782-16	53-782-16		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-18	53-782-18	53-782-18		SPCL DETAIL	OVERWING EMERGENCY EXIT CUTOUT
53-782-20	53-782-20	53-782-20		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-784-00	53-784-00	53-784-00		SPCL DETAIL	OVERWING EMERGENCY EXIT CUTOUT
53-784-02	53-784-02	53-784-02		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-04	53-784-04	53-784-04		DETAILED IN	DUAL OVERWING EMERGENCY EXIT
53-784-06	53-784-06	53-784-06		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-08	53-784-08	53-784-08		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-10	53-784-10	53-784-10		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-12	53-784-12	53-784-12		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-14	53-784-14	53-784-14		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-16	53-784-16	53-784-16		SPCL DETAIL	PASS CABIN BODY STA 955.1 BLKHD
53-784-18	53-784-18	53-784-18		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-784-20	53-784-20	53-784-20		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-146



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-786-00	53-786-00	53-786-00		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-786-02	53-786-02	53-786-02		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-786-04	53-786-04	53-786-04		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-786-06	53-786-06	53-786-06		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-786-08	53-786-08	53-786-08		GEN VISUAL	CROWN SKIN STRINGERS
53-786-10	53-786-10	53-786-10		SPCL DETAIL	MID-CABIN ENTRY/SERVICE DOOR CUTOUT
53-786-12	53-786-12	53-786-12		SPCL DETAIL	MID-CABIN ENTRY/SERVICE DOOR CUTOUT
53-786-14	53-786-14	53-786-14		SPCL DETAIL	MID-CABIN ENTRY/SERVICE DOOR CUTOUT
53-786-16	53-786-16	53-786-16		GEN VISUAL	FRAMES
53-786-18	53-786-18	53-786-18		SPCL DETAIL	CROWN SKIN CIRC SPLICES
53-786-20	53-786-20	53-786-20		SPCL DETAIL	CROWN SKIN CIRC SPLICES
53-788-00	53-788-00	53-788-00		SPCL DETAIL	FWD ENTRY/SERVICE DOOR CUTOUT
53-788-02	53-788-02	53-788-02		SPCL DETAIL	SKIN LONGITUDINAL LAP SPLICES
53-788-04	53-788-04	53-788-04		GEN VISUAL	FRAMES, LONGITUDINAL SKIN LAP SPLICE
53-788-06	53-788-06	53-788-06		SPCL DETAIL	SKIN LONGITUDINAL LAP SPLICES
53-788-08	53-788-08	53-788-08		DETAILED IN	CABIN WINDOW NO. 1 SILL
53-788-10	53-788-10	53-788-10		SPCL DETAIL	CABIN WINDOW NO. 2 POST
53-788-12	53-788-12	53-788-12		SPCL DETAIL	CABIN WINDOW NO. 1 POST
53-788-14	53-788-14	53-788-14		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-788-16	53-788-16	53-788-16		SPCL DETAIL	BULK CARGO DOOR CUTOUT
53-788-18	53-788-18	53-788-18		SPCL DETAIL	BULK CARGO DOOR CUTOUT
53-788-20	53-788-20	53-788-20		SPCL DETAIL	BULK CARGO DOOR CUTOUT
53-790-00	53-790-00	53-790-00		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-02	53-790-02	53-790-02		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-04	53-790-04	53-790-04		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-06	53-790-06	53-790-06		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-790-08	53-790-08	53-790-08		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-10	53-790-10	53-790-10		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-12	53-790-12	53-790-12		SPCL DETAIL	AFT CARGO DOOR CUTOUT LWR MAIN SILL
53-790-14	53-790-14	53-790-14		SPCL DETAIL	AFT CARGO DOOR CUTOUT UPR MAIN SILL
53-790-16	53-790-16	53-790-16		DETAILED IN	AFT CARGO DOOR CUTOUT
53-790-18	53-790-18	53-790-18		SPCL DETAIL	AFT CARGO DOOR CUTOUT
53-790-20	53-790-20	53-790-20		SPCL DETAIL	EMERGENCY EXIT DOOR CUTOUT
53-792-00	53-792-00	53-792-00		SPCL DETAIL	EMERGENCY EXIT DOOR CUTOUT
53-792-02	53-792-02	53-792-02		SPCL DETAIL	BODY STA 1065 BULKHEAD
53-792-04	53-792-04	53-792-04		SPCL DETAIL	BODY STA 1065 BULKHEAD
53-792-06	53-792-06	53-792-06		SPCL DETAIL	BODY STA 1065 BULKHEAD
53-792-08	53-792-08	53-792-08		SPCL DETAIL	TRANSVERSE BEAM AT MAIN WHEEL WELL
53-792-10	53-792-10	53-792-10		SPCL DETAIL	STA 1043 SPLICE AT LNG GEAR FITTING
53-792-12	53-792-12	53-792-12		SPCL DETAIL	BODY STA 808-933 FRAME AT STUB BEAM
53-792-14	53-792-14	53-792-14		SPCL DETAIL	BODY STA 955.1 BULKHEAD INNER FLANGE
53-792-16	53-792-16	53-792-16		SPCL DETAIL	BODY STA 808-933 FRAME AT STUB BEAM
53-792-18	53-792-18	53-792-18		SPCL DETAIL	LARGE FWD CARGO DOOR LATCH
53-792-20	53-792-20	53-792-20		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-00	53-794-00	53-794-00		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-02	53-794-02	53-794-02		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-04	53-794-04	53-794-04		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-06	53-794-06	53-794-06		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-08	53-794-08	53-794-08		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-10	53-794-10	53-794-10		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-12	53-794-12	53-794-12		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-14	53-794-14	53-794-14		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-148



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
53-794-16	53-794-16	53-794-16		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-18	53-794-18	53-794-18		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-20	53-794-20	53-794-20		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-796-00	53-796-00	53-796-00		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-796-02	53-796-02	53-796-02		SPCL DETAIL	FWD CARGO DOOR CUTOUT
53-796-04	53-796-04	53-796-04		SPCL DETAIL	FWD CARGO DOOR CUTOUT
53-796-06	53-796-06	53-796-06		DETAILED IN	FWD CARGO DOOR CUTOUT
53-796-08	53-796-08	53-796-08		SPCL DETAIL	FWD CARGO DOOR CUTOUT
53-796-10	53-796-10	53-796-10		SPCL DETAIL	BODY STA 287 BULKHEAD
53-796-12	53-796-12	53-796-12		GEN VISUAL	MAIN EQUIPMENT CENTER DOOR CUTOUT
53-796-14	53-796-14	53-796-14		SPCL DETAIL	BODY STA 287 BULKHEAD
53-796-16	53-796-16	53-796-16		SPCL DETAIL	FWD ENTRY/SERVICE DOOR CUTOUT
53-796-18	53-796-18	53-796-18		SPCL DETAIL	BODY STA 287 BULKHEAD
53-796-20	53-796-20	53-796-20		SPCL DETAIL	BODY STA 287 BULKHEAD
53-798-00	53-798-00	53-798-00		SPCL DETAIL	BODY STA 287 BULKHEAD
53-798-02	53-798-02	53-798-02		SPCL DETAIL	BODY STA 287 BULKHEAD
53-798-04	53-798-04	53-798-04		SPCL DETAIL	NOSE WHEEL WELL SIDE PANEL BEAM
53-798-06	53-798-06	53-798-06		SPCL DETAIL	NOSE WHEEL WELL SIDE PANEL BEAM
53-798-08	53-798-08	53-798-08		DETAILED IN	NOSE WHEEL WELL SIDE PANEL VER BEAMS
53-798-10	53-798-10	53-798-10		SPCL DETAIL	FORWARD EQUIPMENT BAY DOOR CUTOUT
53-798-12	53-798-12	53-798-12		SPCL DETAIL	NOSE WHEEL WELL CANTED BULKHEAD
53-798-14	53-798-14	53-798-14		SPCL DETAIL	NOSE WHEEL WELL CANTED BULKHEAD
53-798-16	53-798-16	53-798-16		SPCL DETAIL	SKIN LONGITUDINAL LAP SPLICES
53-798-18	53-798-18	53-798-18		GEN VISUAL	FRAMES, LONGTDNAL SKIN LAP SPLICES
53-798-20	53-798-20	53-798-20		SPCL DETAIL	SKIN LONGITUDINAL LAP SPLICES
54-400-00	54-400-00	54-400-00		GEN VISUAL	POWERPLANT STRUT -#1 (GE)

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
54-402-00	54-402-00	54-402-00		GEN VISUAL	POWERPLANT STRUT - #1 (P&W)
54-404-00	54-404-00	54-404-00		GEN VISUAL	POWER PLANT STRUT - #1
54-406-00	54-406-00	54-406-00		GEN VISUAL	NACELLE STRUT NO. 1
54-408-00	54-408-00	54-408-00		GEN VISUAL	NO. 1 NACELLE STRUT
54-410-00	54-410-00	54-410-00		DETAILED EX	NACELLE STRUT NO. 1
54-412-00	54-412-00	54-412-00		DETAILED IN	STRUT 1 LOWER SPAR AND ENGINE MOUNTS
54-414-00	54-414-00	54-414-00		DETAILED IN	STRUT 1
54-416-00	54-416-00	54-416-00		GEN VISUAL	STRUT 1
54-418-00	54-418-00	54-418-00		GEN VISUAL	POWERPLANT STRUT - #1 (RR CONFIGURA
54-422-00	54-422-00	54-422-00		GEN VISUAL	STRUT 1
54-424-00	54-424-00	54-424-00		DETAILED IN	NACELLE STRUT NO. 1 FWD UPPER SPAR
54-426-00	54-426-00	54-426-00		GEN VISUAL	NACELLE STRUT NO. 1 - FWD TORQUE BOX
54-428-00	54-428-00	54-428-00		DETAILED IN	NACELLE STRUT NO. 1 - FWD TORQUE BOX
54-430-00	54-430-00	54-430-00		GEN VISUAL	STRUT 1 UPPER SPAR
54-432-00	54-432-00	54-432-00		DETAILED IN	STRUT 1 UPPER LINK
54-434-00	54-434-00	54-434-00		DETAILED IN	STRUT 1 UPPER LINK
54-436-00	54-436-00	54-436-00		DETAILED IN	NACELLE STRUT NO. 1 MID-SPAR FITTING
54-438-00	54-438-00	54-438-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
54-440-00	54-440-00	54-440-00		DETAILED IN	NACELLE STRUT NO. 1 MID-SPAR FITTING
54-442-00	54-442-00	54-442-00		DETAILED IN	STRUT 1 TORQUE BOX
54-444-00	54-444-00	54-444-00		GEN VISUAL	STRUT 1 AFT TORQUE BOX
54-446-00	54-446-00	54-446-00		GEN VISUAL	NACELLE STRUT 1-MID & AFT TORQUE BOX
54-448-00	54-448-00	54-448-00		DETAILED IN	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-450-00	54-450-00	54-450-00		DETAILED IN	STRUT 1 AFT TORQUE BOX
54-452-00	54-452-00	54-452-00		DETAILED IN	STRUT 1 AFT TORQUE BOX
54-458-00	54-458-00	54-458-00		DETAILED IN	NACELLE STRUT NO. 1 MID SPAR FITTING

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-150



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
54-460-00	54-460-00	54-460-00		DETAILED IN	NACELLE STRUT NO. 1 MID SPAR FITTING
54-462-00	54-462-00	54-462-00		DETAILED IN	LEFT NACELLE STRUT MID SPAR FITTING
54-464-00	54-464-00	54-464-00		DETAILED IN	LEFT NACELLE STRUT MID SPAR FITTING
54-466-00	54-466-00	54-466-00		GEN VISUAL	LEFT NACELLE STRUT/WING LWR SURFACE
54-468-00	54-468-00	54-468-00		DETAILED IN	LEFT NACELLE STRUT/WING LWR SURFACE
54-470-00	54-470-00	54-470-00		GEN VISUAL	POWERPLANT STRUT - #2 (GE CONFIGURAT
54-472-00	54-472-00	54-472-00		GEN VISUAL	POWERPLANT STRUT - #2
54-474-00	54-474-00	54-474-00		GEN VISUAL	POWERPLANT STRUT - #2
54-476-00	54-476-00	54-476-00		GEN VISUAL	NACELLE STRUT NO. 2
54-478-00	54-478-00	54-478-00		GEN VISUAL	NACELLE STRUT NO. 2
54-480-00	54-480-00	54-480-00		DETAILED EX	NACELLE STRUT NO. 2
54-482-00	54-482-00	54-482-00		DETAILED IN	STRUT 2 LOWER SPAR AND ENGINE MOUNTS
54-484-00	54-484-00	54-484-00		DETAILED IN	STRUT 2
54-486-00	54-486-00	54-486-00		GEN VISUAL	STRUT 2
54-488-00	54-488-00	54-488-00		GEN VISUAL	POWERPLANT STRUT - #2
54-492-00	54-492-00	54-492-00		GEN VISUAL	STRUT 2 SKIN
54-494-00	54-494-00	54-494-00		DETAILED IN	NACELLE STRUT NO. 2 FWD UPPER SPAR
54-496-00	54-496-00	54-496-00		GEN VISUAL	NACELLE STRUT NO. 2 -FWD TORQUE BOX
54-498-00	54-498-00	54-498-00		DETAILED IN	NACELLE STRUT NO. 2 FWD TORQUE BOX
54-500-00	54-500-00	54-500-00		GEN VISUAL	STRUT 2 UPPER SPAR
54-502-00	54-502-00	54-502-00		DETAILED IN	NACELLE STRUT NO. 2 -FWD TORQUE BOX
54-504-00	54-504-00	54-504-00		DETAILED IN	STRUT 2 UPPER LINK
54-506-00	54-506-00	54-506-00		DETAILED IN	NACELLE STRUT NO. 2 MID-SPAR FITTING
54-508-00	54-508-00	54-508-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
54-510-00	54-510-00	54-510-00		DETAILED IN	NACELLE STRUT NO. 2 MID-SPAR FITTING
54-512-00	54-512-00	54-512-00		DETAILED IN	NACELLE STRUT NO. 2 AFT UPPER SPAR

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
54-514-00	54-514-00	54-514-00		GEN VISUAL	NACELLE STRUT NO. 2 MID SPAR FITTING
54-520-00	54-520-00	54-520-00		DETAILED IN	STRUT 2 AFT TORQUE BOX
54-522-00	54-522-00	54-522-00		DETAILED IN	STRUT 2 AFT TORQUE BOX
54-524-00	54-524-00	54-524-00		GEN VISUAL	NACELLE STRUT MID & AFT TORQUE BOX
54-526-00	54-526-00	54-526-00		DETAILED IN	NO. 2 STRUT AFT ENG MOUNT BULKHEAD
54-528-00	54-528-00	54-528-00		DETAILED IN	NACELLE STRUT NO.2 -MID SPAR FITTING
54-530-00	54-530-00	54-530-00		DETAILED IN	NACELLE STRUT NO. 2 MID SPAR FITTING
54-532-00	54-532-00	54-532-00		DETAILED IN	RIGHT NACELLE STRUT MID SPAR FITTING
54-534-00	54-534-00	54-534-00		DETAILED IN	RIGHT NACELLE STRUT MID SPAR FITTING
54-536-00	54-536-00	54-536-00		GEN VISUAL	RIGHT NACELLE STRUT/WING LWR SURFACE
54-538-00	54-538-00	54-538-00		DETAILED IN	RIGHT NACELLE STRUT/WING LWR SURFACE
54-578-04	54-578-04	54-578-04		SPCL DETAIL	STRUT NO. 2 SIDE LOAD FITTINGS
54-578-06	54-578-06	54-578-06		DETAILED IN	STRUT NO 2 SIDE LOAD LINKS
54-578-08	54-578-08	54-578-08		DETAILED IN	STRUT NO 2 SIDE LOAD LINKS
54-578-10	54-578-10	54-578-10		DETAILED IN	STRUT NO 2 SIDE LOAD LINKS
54-578-12	54-578-12	54-578-12		DETAILED IN	STRUT NO 2 SIDE LOAD LINKS
54-578-14	54-578-14	54-578-14		DETAILED IN	STRUT NO 2 MIDSPAR FITTING
54-578-16	54-578-16	54-578-16		DETAILED IN	STRUT NO 2 MIDSPAR FITTING
54-578-18	54-578-18	54-578-18		DETAILED IN	STRUT NO 2 MIDSPAR FITTING
54-578-20	54-578-20	54-578-20		DETAILED IN	STRUT NO 2 MIDSPAR FITTING
54-580-00	54-580-00	54-580-00		DETAILED IN	STRUT NO 2 DIAGONAL BRACE FITTING
54-580-02	54-580-02	54-580-02		DETAILED IN	STRUT NO 2 DIAGONAL BRACE FITTING
54-580-04	54-580-04	54-580-04		DETAILED IN	STRUT NO 2 DIAGONAL BRACE FITTING
54-580-06	54-580-06	54-580-06		DETAILED IN	STRUT NO. 2 DIAGONAL BRACE FITTING
54-580-08	54-580-08	54-580-08		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-580-10	54-580-10	54-580-10		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-152



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
54-580-12	54-580-12	54-580-12		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-580-14	54-580-14	54-580-14		SPCL DETAIL	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-580-16	54-580-16	54-580-16		SPCL DETAIL	NACELLE STRUT NO. 2 SIDE SKIN
54-580-18	54-580-18	54-580-18		SPCL DETAIL	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-580-20	54-580-20	54-580-20		SPCL DETAIL	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-582-00	54-582-00	54-582-00		SPCL DETAIL	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-582-02	54-582-02	54-582-02		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR CHORD
54-582-04	54-582-04	54-582-04		DETAILED IN	STRUT NO 2 AFT UPPER SPAR FITTING
54-582-06	54-582-06	54-582-06		DETAILED IN	STRUT NO. 2 LOWER SPAR CHORD
54-582-08	54-582-08	54-582-08		DETAILED IN	STRUT NO 2 DIAGONAL BRACE FITTING
54-582-10	54-582-10	54-582-10		SPCL DETAIL	NACELLE STRUT NO. 2 LOWER SPAR
54-582-12	54-582-12	54-582-12		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR CHORD
54-582-14	54-582-14	54-582-14		DETAILED IN	STRUT NO. 2 LOWER SPAR CHORD
54-582-16	54-582-16	54-582-16		DETAILED IN	STRUT NO 2 SIDE LINK FITTING
54-582-18	54-582-18	54-582-18		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR CHORD
54-582-20	54-582-20	54-582-20		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR FITTING
54-584-00	54-584-00	54-584-00		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-584-02	54-584-02	54-584-02		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-584-04	54-584-04	54-584-04		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-584-06	54-584-06	54-584-06		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-584-08	54-584-08	54-584-08		SPCL DETAIL	NACELLE STRUT NO. 2 FWD ENGINE MOUNT
54-584-10	54-584-10	54-584-10		DETAILED IN	NACELLE STRUT NO. 2 SIDESKIN
54-584-12	54-584-12	54-584-12		GEN VISUAL	STRUT NO. 2 MID BULKHEAD LINK FTG
54-584-14	54-584-14	54-584-14		DETAILED IN	STRUT NO. 2 MID BULKHEAD LINK FTG
54-584-16	54-584-16	54-584-16		DETAILED IN	STRUT NO. 2 FORWARD UPPER SPAR
54-584-18	54-584-18	54-584-18		SPCL DETAIL	NACELLE STRUT NO. 2 FWD UPPER SPAR

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
54-584-20	54-584-20	54-584-20		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-586-00	54-586-00	54-586-00		DETAILED IN	NACELLE STRUT NO. 2 FWD MIDSPAR
54-586-02	54-586-02	54-586-02		SPCL DETAIL	NACELLE STRUT NO. 2 FWD MIDSPAR
54-586-04	54-586-04	54-586-04		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR CHORD
54-586-06	54-586-06	54-586-06		SPCL DETAIL	NACELLE STRUT NO. 2 MID SPAR CHORD
54-586-08	54-586-08	54-586-08		SPCL DETAIL	NACELLE STRUT NO. 2 MID SPAR CHORD
54-586-10	54-586-10	54-586-10		SPCL DETAIL	NACELLE STRUT NO. 2 MID SPAR CHORD
54-586-12	54-586-12	54-586-12		SPCL DETAIL	NACELLE STRUT NO. 2 MID SPAR CHORD
54-586-14	54-586-14	54-586-14		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-586-16	54-586-16	54-586-16		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-586-18	54-586-18	54-586-18		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-586-20	54-586-20	54-586-20		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-588-00	54-588-00	54-588-00		DETAILED IN	STRUT NO. 2 TO WING ATTACHMENTS
54-588-02	54-588-02	54-588-02		SPCL DETAIL	NACELLE STRUT NO. 2 LOWER SPAR CHORD
54-588-04	54-588-04	54-588-04		SPCL DETAIL	STRUT NO. 1 SIDE LOAD FITTINGS
54-588-06	54-588-06	54-588-06		DETAILED IN	STRUT NO 1 SIDE LOAD LINKS
54-588-08	54-588-08	54-588-08		DETAILED IN	STRUT NO 1 SIDE LOAD LINKS
54-588-10	54-588-10	54-588-10		DETAILED IN	STRUT NO 1 SIDE LOAD LINKS
54-588-12	54-588-12	54-588-12		DETAILED IN	STRUT NO 1 SIDE LOAD LINKS
54-588-14	54-588-14	54-588-14		DETAILED IN	STRUT NO 1 MIDSPAR FITTING
54-588-16	54-588-16	54-588-16		DETAILED IN	STRUT NO 1 MIDSPAR FITTING
54-588-18	54-588-18	54-588-18		DETAILED IN	STRUT NO 1 MIDSPAR FITTING
54-588-20	54-588-20	54-588-20		DETAILED IN	STRUT NO 1 MIDSPAR FITTING
54-590-00	54-590-00	54-590-00		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-590-02	54-590-02	54-590-02		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-590-04	54-590-04	54-590-04		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-154



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
54-590-06	54-590-06	54-590-06		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-590-08	54-590-08	54-590-08		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-590-10	54-590-10	54-590-10		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-590-12	54-590-12	54-590-12		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-590-14	54-590-14	54-590-14		SPCL DETAIL	NACELLE STRUT NO. 1 AFT UPPER SPAR
54-590-16	54-590-16	54-590-16		SPCL DETAIL	NACELLE STRUT NO. 1 SIDE SKIN
54-590-18	54-590-18	54-590-18		SPCL DETAIL	NACELLE STRUT NO. 1 AFT UPPER SPAR
54-590-20	54-590-20	54-590-20		SPCL DETAIL	NACELLE STRUT NO. 1 AFT UPPER SPAR
54-592-00	54-592-00	54-592-00		SPCL DETAIL	NACELLE STRUT NO. 1 AFT UPPER SPAR
54-592-02	54-592-02	54-592-02		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR CHORD
54-592-04	54-592-04	54-592-04		DETAILED IN	STRUT NO 1 AFT UPPER SPAR FITTING
54-592-06	54-592-06	54-592-06		DETAILED IN	STRUT NO. 1 LOWER SPAR CHORD
54-592-08	54-592-08	54-592-08		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-592-10	54-592-10	54-592-10		SPCL DETAIL	NACELLE STRUT NO. 1 LOWER SPAR
54-592-12	54-592-12	54-592-12		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR CHORD
54-592-14	54-592-14	54-592-14		DETAILED IN	STRUT NO. 1 LOWER SPAR CHORD
54-592-16	54-592-16	54-592-16		DETAILED IN	STRUT NO 1 SIDE LINK FITTING
54-592-18	54-592-18	54-592-18		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR CHORD
54-592-20	54-592-20	54-592-20		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR FITTING
54-594-00	54-594-00	54-594-00		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-594-02	54-594-02	54-594-02		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-594-04	54-594-04	54-594-04		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-594-06	54-594-06	54-594-06		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-594-08	54-594-08	54-594-08		SPCL DETAIL	NACELLE STRUT NO. 1 FWD ENGINE MOUNT
54-594-10	54-594-10	54-594-10		DETAILED IN	NACELLE STRUT NO. 1 SIDESKIN
54-594-12	54-594-12	54-594-12		GEN VISUAL	STRUT NO. 1 MID BULKHEAD LINK FTG

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
54-594-14	54-594-14	54-594-14		DETAILED IN	STRUT NO. 1 MID BULKHEAD LINK FTG
54-594-16	54-594-16	54-594-16		DETAILED IN	STRUT NO. 1 FORWARD UPPER SPAR
54-594-18	54-594-18	54-594-18		SPCL DETAIL	NACELLE STRUT NO. 1 FWD UPPER SPAR
54-594-20	54-594-20	54-594-20		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-596-00	54-596-00	54-596-00		DETAILED IN	NACELLE STRUT NO. 1 FWD MIDSPAR
54-596-02	54-596-02	54-596-02		SPCL DETAIL	NACELLE STRUT NO. 1 FWD MIDSPAR
54-596-04	54-596-04	54-596-04		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR CHORD
54-596-06	54-596-06	54-596-06		SPCL DETAIL	NACELLE STRUT NO. 1 MID SPAR CHORD
54-596-08	54-596-08	54-596-08		SPCL DETAIL	NACELLE STRUT NO. 1 MID SPAR CHORD
54-596-10	54-596-10	54-596-10		SPCL DETAIL	NACELLE STRUT NO. 1 MID SPAR CHORD
54-596-12	54-596-12	54-596-12		SPCL DETAIL	NACELLE STRUT NO. 1 MID SPAR CHORD
54-596-14	54-596-14	54-596-14		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-596-16	54-596-16	54-596-16		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-596-18	54-596-18	54-596-18		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-596-20	54-596-20	54-596-20		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-598-00	54-598-00	54-598-00		DETAILED IN	STRUT NO. 1 T0 WING ATTACHMENTS
54-598-02	54-598-02	54-598-02		SPCL DETAIL	NACELLE STRUT NO. 1 LOWER SPAR CHORD
54-598-06	54-598-06	54-598-06		SPCL DETAIL	STRUT NO. 2 AFT ENGINE MOUNT
54-598-08	54-598-08	54-598-08		SPCL DETAIL	STRUT NO. 2 AFT ENGINE MOUNT
54-598-10	54-598-10	54-598-10		DETAILED IN	STRUT NO. 2 FORWARD ENGINE MOUNT
54-598-12	54-598-12	54-598-12		SPCL DETAIL	STRUT NO. 2 FORWARD ENGINE MOUNT
54-598-14	54-598-14	54-598-14		SPCL DETAIL	STRUT NO. 1 AFT ENGINE MOUNT
54-598-16	54-598-16	54-598-16		SPCL DETAIL	STRUT NO. 1 AFT ENGINE MOUNT
54-598-18	54-598-18	54-598-18		DETAILED IN	STRUT NO. 1 FORWARD ENGINE MOUNT
54-598-20	54-598-20	54-598-20		SPCL DETAIL	STRUT NO. 1 FORWARD ENGINE MOUNT
55-400-00	55-400-00	55-400-00		GEN VISUAL	VERTICAL STAB REMOVABLE LEADING EDGE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
55-401-00	55-401-00	55-401-00		GEN VISUAL	VERTICAL STABILIZER EXTERIOR
55-402-00	55-402-00	55-402-00		GEN VISUAL	VERTICAL STAB REMOVABLE LEADING EDGE
55-404-00	55-404-00	55-404-00		GEN VISUAL	VERT STAB AUX SPAR TO FRONT SPAR
55-406-00	55-406-00	55-406-00		DETAILED	VERT STAB FIXED LEADING EDGE
55-408-00	55-408-00	55-408-00		GEN VISUAL	VERT STAB AUX SPAR TO FRONT SPAR
55-410-00	55-410-00	55-410-00		GEN VISUAL	VERT STAB FRONT SPAR TO REAR SPAR
55-412-00	55-412-00	55-412-00		DETAILED IN	VERT STAB FIN-TO-BODY FITTINGS
55-414-00	55-414-00	55-414-00		GEN VISUAL	VERTICAL STABILIZER INSPAR STRUCTURE
55-416-00	55-416-00	55-416-00		GEN VISUAL	VERT STAB FRONT SPAR TO REAR SPAR
55-418-00	55-418-00	55-418-00		DETAILED EX	VERTICAL STABILIZER INSPAR STRUCTURE
55-420-00	55-420-00	55-420-00		GEN VISUAL	VERTICAL STABILIZER TRAILING EDGE
55-422-00	55-422-00	55-422-00		GEN VISUAL	RUDDER
55-424-00	55-424-00	55-424-00		DETAILED EX	RUDDER
55-426-00	55-426-00	55-426-00		DETAILED EX	RUDDER
55-428-00	55-428-00	55-428-00		SPCL DETAIL	RUDDER
55-430-00	55-430-00	55-430-00		GEN VISUAL	VERTICAL STABILIZER TIP
55-432-00	55-432-00	55-432-00		GEN VISUAL	HORIZONTAL STABILIZER EXT - LEFT
55-434-00	55-434-00	55-434-00		GEN VISUAL	HORIZ STABILIZER CENTER SECTION
55-444-00	55-444-00	55-444-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-446-00	55-446-00	55-446-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-448-00	55-448-00	55-448-00		GEN VISUAL	HORIZONTAL STAB FIXED LEADING EDGE
55-450-00	55-450-00	55-450-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE - LWR
55-452-00	55-452-00	55-452-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE-UPPER
55-454-00	55-454-00	55-454-00		GEN VISUAL	HORIZ STAB FRONT TO REAR SPAR L & R
55-456-00	55-456-00	55-456-00		GEN VISUAL	HORIZ STAB OUTBOARD SECTION
55-458-00	55-458-00	55-458-00		GEN VISUAL	HORIZ STAB UPPER OUTBOARD SURFACE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
55-460-00	55-460-00	55-460-00		GEN VISUAL	HORIZ STAB LOWER OUTBOARD SURFACE
55-462-00	55-462-00	55-462-00		DETAILED EX	HORIZ/STAB UPPER OUTBOARD SURFACE
55-464-00	55-464-00	55-464-00		GEN VISUAL	HORIZ STAB TRAILING EDGE
55-466-00	55-466-00	55-466-00	W-06-063-01	GEN VISUAL	HORIZ STAB TRAILING EDGE
55-468-00	55-468-00	55-468-00		GEN VISUAL	HORIZ STAB TRAIL EDGE UPPER SURFACE
55-470-00	55-470-00	55-470-00		GEN VISUAL	LEFT ELEVATOR INTERIOR
55-472-00	55-472-00	55-472-00		GEN VISUAL	LEFT ELEVATOR - INBOARD/OUTBOARD
55-474-00	55-474-00	55-474-00		DETAILED EX	ELEVATOR SPAR & HINGE FITTINGS
55-478-00	55-478-00	55-478-00		GEN VISUAL	LEFT ELEVATOR - INBOARD/OUTBOARD
55-480-00	55-480-00	55-480-00		DETAILED EX	ELEVATOR - OUTBOARD
55-484-00	55-484-00	55-484-00		SPCL DETAIL	ELEVATOR SPAR & ADJACENT STRUCTURE
55-486-00	55-486-00	55-486-00		GEN VISUAL	HORIZONTAL STABILIZER TIP
55-488-00	55-488-00	55-488-00		GEN VISUAL	HORIZONTAL STABILIZER EXT - RIGHT
55-490-00	55-490-00	55-490-00		DETAILED IN	HORIZ STABILIZER CENTER SECTION
55-492-00	55-492-00	55-492-00		DETAILED EX	HORIZ STAB JACKSCREW FITTING
55-494-00	55-494-00	55-494-00		DETAILED EX	HORIZONTAL STABILIZER PIVOT FITTINGS
55-496-00	55-496-00	55-496-00		DETAILED EX	HORIZ STAB CENTER SECTION REAR SPAR
55-498-00	55-498-00	55-498-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-500-00	55-500-00	55-500-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-502-00	55-502-00	55-502-00		GEN VISUAL	HORIZONTAL STAB FIXED LEADING EDGE
55-504-00	55-504-00	55-504-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE-UPPER
55-506-00	55-506-00	55-506-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE - LWR
55-508-00	55-508-00	55-508-00		GEN VISUAL	HORIZ STAB CAVITY
55-510-00	55-510-00	55-510-00		GEN VISUAL	HORIZ STAB OUTBOARD SECTION
55-512-00	55-512-00	55-512-00		GEN VISUAL	HORIZ STAB LOWER OUTBOARD SURFACE
55-514-00	55-514-00	55-514-00		GEN VISUAL	HORIZ STAB UPPER OUTBOARD SURFACE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-158



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
55-516-00	55-516-00	55-516-00		DETAILED EX	HORIZ/STAB UPPER OUTBOARD SURFACE
55-518-00	55-518-00	55-518-00		GEN VISUAL	HORIZ STAB INTERIOR CAVITY
55-520-00	55-520-00	55-520-00	W-06-063-01	GEN VISUAL	HORIZ STAB TRAILING EDGE
55-522-00	55-522-00	55-522-00		GEN VISUAL	HORIZ STAB TRAIL EDGE UPPER SURFACE
55-524-00	55-524-00	55-524-00		GEN VISUAL	RIGHT ELEVATOR INTERIOR
55-526-00	55-526-00	55-526-00		GEN VISUAL	RIGHT ELEVATOR - INBOARD/OUTBOARD
55-528-00	55-528-00	55-528-00		DETAILED EX	RIGHT ELEVATOR SPAR & HINGE FITTINGS
55-532-00	55-532-00	55-532-00		GEN VISUAL	RIGHT ELEVATOR - INBOARD/OUTBOARD
55-538-00	55-538-00	55-538-00		SPCL DETAIL	ELEVATOR SPAR & ADJACENT STRUCTURE
55-540-00	55-540-00	55-540-00		GEN VISUAL	HORIZONTAL STABILIZER TIP
55-550-00	55-550-00	55-550-00		SPCL DETAIL	HORIZONTAL STABILIZER PIVOT FITTINGS
55-552-00	55-552-00	55-552-00		SPCL DETAIL	HORIZ STAB PIVOT FITTING ATTACHMENTS
55-554-00	55-554-00	55-554-00		SPCL DETAIL	HORIZ STAB PIVOT FITTING ATTACHMENTS
55-556-00	55-556-00	55-556-00		SPCL DETAIL	HORIZ STAB PIVOT FITTING ATTACHMENTS
55-558-00	55-558-00	55-558-00		SPCL DETAIL	HORIZ STAB CTR SECTION REAR SPAR
55-560-00	55-560-00	55-560-00		SPCL DETAIL	HORIZ STAB CTR SECTION UPPER SKIN
55-562-00	55-562-00	55-562-00		SPCL DETAIL	HORIZ STAB JACKSCREW ATTACH
55-564-00	55-564-00	55-564-00		SPCL DETAIL	HORIZ STAB JACKSCREW ATTACHMENTS
57-400-00	57-400-00	57-400-00		GEN VISUAL	WING CENTER SECTION
57-402-00	57-402-00	57-402-00		DETAILED IN	WING CENTER SECTION LWR SURF SPLICE
57-404-00	57-404-00	57-404-00		DETAILED IN	WING CENTER SECTION REAR SPAR CHORD
57-406-00	57-406-00	57-406-00		DETAILED IN	WING CENTER SECT SIDE OF BODY SPLICE
57-408-00	57-408-00	57-408-00		DETAILED IN	WING CENTER SECTION REAR SPAR WEB
57-410-00	57-410-00	57-410-00		DETAILED IN	WING CTR SECT SIDE OF BODY RIB WEB
57-412-00	57-412-00	57-412-00		DETAILED IN	WING CENTER SECTION LOWER SURF BL 70
57-414-00	57-414-00	57-414-00		GEN VISUAL	WING CTR SECT FUEL TANK DRY BAY AREA

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-416-00	57-416-00	57-416-00		DETAILED IN	WING CENTER SECT FUEL TANK WET BAY
57-418-00	57-418-00	57-418-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-420-00	57-420-00	57-420-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-422-00	57-422-00	57-422-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-424-00	57-424-00	57-424-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-426-00	57-426-00	57-426-00		DETAILED IN	WING CENTER SECTION LOWER SURF BL 70
57-428-00	57-428-00	57-428-00		GEN VISUAL	WING CENTER SECTION
57-458-00	57-458-00	57-458-00		GEN VISUAL	WING CENTER SECTION LOWER
57-460-00	57-460-00	57-460-00		GEN VISUAL	INBOARD FLAP SUPPORT STRUCTURE
57-464-00	57-464-00	57-464-00		GEN VISUAL	WING EXTERIOR - LEFT
57-466-00	57-466-00	57-466-00		GEN VISUAL	WING EXTERIOR - LEFT
57-468-00	57-468-00	57-468-00		GEN VISUAL	NACELLE STRUT NO. 1 AFT UPPER SPAR
57-470-00	57-470-00	57-470-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
57-472-00	57-472-00	57-472-00		GEN VISUAL	SLAT 6 LINK BRACE & ACTUATOR SUPPORT
57-474-00	57-474-00	57-474-00		GEN VISUAL	LEFT WING FIXED LE STRUCTURES
57-476-00	57-476-00	57-476-00		GEN VISUAL	LEFT WING FIXED LE STRUCTURE
57-478-00	57-478-00	57-478-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
57-480-00	57-480-00	57-480-00		GEN VISUAL	LE SLATS INTERIOR STRUCTURE
57-482-00	57-482-00	57-482-00		GEN VISUAL	LEFT SLAT/NACELLE SEAL KREUGER FLAP
57-486-00	57-486-00	57-486-00		GEN VISUAL	LEADING EDGE EXTERIOR - LEFT
57-488-00	57-488-00	57-488-00		GEN VISUAL	NO. 4 SLAT MAIN & AUXILIARY TRACKS
57-504-00	57-504-00	57-504-00		GEN VISUAL	LEFT WING INSPAR LWR SURFACE, EXT
57-506-00	57-506-00	57-506-00		GEN VISUAL	LEFT WING INSPAR LWR SURFACE
57-508-00	57-508-00	57-508-00		GEN VISUAL	LEFT WING INSPAR UPPER SURFACE
57-510-00	57-510-00	57-510-00		DETAILED EX	LEFT WING INSPAR UPPER SURFACE
57-512-00	57-512-00	57-512-00		DETAILED EX	LEFT WING INSPAR LWR SURFACE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-160



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-514-00	57-514-00	57-514-00		DETAILED EX	LEFT WING INSPAR UPPER SURFACE
57-516-00	57-516-00	57-516-00		DETAILED IN	L WING LWR SURFACE SPANWISE SPLICE
57-518-00	57-518-00	57-518-00		DETAILED IN	L WING LWR SURF ACCESS HOLE CUTOUTS
57-520-00	57-520-00	57-520-00		DETAILED IN	L WING LWR SURFACE/SIDE OF BOX RIB
57-522-00	57-522-00	57-522-00		DETAILED IN	L WING REAR SPAR WEB & LOWER CHORD
57-524-00	57-524-00	57-524-00		DETAILED IN	L WING REAR SPAR LWR CHORD & RIB 1&3
57-526-00	57-526-00	57-526-00		DETAILED IN	LEFT WING SIDE OF BODY RIB WEB
57-528-00	57-528-00	57-528-00		DETAILED IN	SIDE OF BODY RIB LOWER CHORD CUTOUTS
57-530-00	57-530-00	57-530-00		GEN VISUAL	LEFT WING MAIN TANK
57-532-00	57-532-00	57-532-00		DETAILED IN	LEFT MLG TRUNNION BACKUP STRUCTURE
57-534-00	57-534-00	57-534-00		DETAILED IN	LEFT MLG BEAM BACKUP STRUCTURE
57-536-00	57-536-00	57-536-00		DETAILED IN	L WING NACELLE STRUT SUPPORT BACKUP
57-538-00	57-538-00	57-538-00		DETAILED IN	LEFT WING LWR SPAR CHORDS
57-540-00	57-540-00	57-540-00		DETAILED IN	L WING LWR SPANWISE SPLICE STRINGERS
57-542-00	57-542-00	57-542-00		DETAILED IN	L WING LWR SURF ACCESS HOLE CUTOUTS
57-544-00	57-544-00	57-544-00		DETAILED IN	NACELLE STRUT NO. 1 BACKUP STRUCTURE
57-546-00	57-546-00	57-546-00		DETAILED IN	L WING SPANWISE SPLICE STRINGER L-15
57-548-00	57-548-00	57-548-00		DETAILED IN	L WING FRONT SPAR LWR CHORD, RIB 7&9
57-550-00	57-550-00	57-550-00		GEN VISUAL	LEFT WING INBOARD DRY BAY
57-552-00	57-552-00	57-552-00		DETAILED IN	L TE FLAP SUPPORT BACKUP STRUCTURE
57-554-00	57-554-00	57-554-00		GEN VISUAL	LEFT WING OUTBOARD DRY BAY
57-556-00	57-556-00	57-556-00		GEN VISUAL	LEFT WING OUTBOARD DRY BAY
57-558-00	57-558-00	57-558-00		GEN VISUAL	WING TIP & OUTBD SIDE OF WBL 929 RIB
57-560-00	57-560-00	57-560-00		SPCL DETAIL	WING TIP RIB & OUTBD SIDE OF RIB 36
57-564-00	57-564-00	57-564-00		GEN VISUAL	L WING TE SUPPORT STRUCT & REAR SPAR
57-566-00	57-566-00	57-566-00		DETAILED IN	UPPER WING/SIDE OF BODY SPLICE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-568-00	57-568-00	57-568-00		GEN VISUAL	LEFT WING TRAILING EDGE
57-570-00	57-570-00	57-570-00		GEN VISUAL	L MAIN GEAR DRAG BRACE & MLG BEAM
57-572-00	57-572-00	57-572-00		GEN VISUAL	LEFT WING TRAILING EDGE
57-576-00	57-576-00	57-576-00		GEN VISUAL	LEFT WING SPOILERS
57-578-00	57-578-00	57-578-00		GEN VISUAL	LEFT WING INBD TE FLAP BOX
57-580-00	57-580-00	57-580-00		GEN VISUAL	LEFT WING INBD TE FLAP BOX
57-582-00	57-582-00	57-582-00		SPCL DETAIL	LEFT INBOARD TE FLAP TORQUE TUBE
57-584-00	57-584-00	57-584-00		SPCL DETAIL	LEFT WING INBOARD TE FLAP BOX
57-586-00	57-586-00	57-586-00		GEN VISUAL	LEFT WING INBOARD TE FLAP
57-588-00	57-588-00	57-588-00		GEN VISUAL	LEFT INBOARD AILERON INTERIOR
57-590-00	57-590-00	57-590-00		GEN VISUAL	LEFT INBOARD AILERON
57-592-00	57-592-00	57-592-00		GEN VISUAL	LEFT INBOARD AILERON
57-594-00	57-594-00	57-594-00		DETAILED EX	LEFT INBOARD AILERON
57-596-00	57-596-00	57-596-00		GEN VISUAL	WING TE SUPPORT STRUCTURE/REAR SPAR
57-598-00	57-598-00	57-598-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP BOX
57-600-00	57-600-00	57-600-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP BOX
57-602-00	57-602-00	57-602-00		SPCL DETAIL	LEFT WING OUTBOARD TE FLAP BOX
57-604-00	57-604-00	57-604-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-606-00	57-606-00	57-606-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-608-00	57-608-00	57-608-00		SPCL DETAIL	LEFT WING OUTBOARD TE FLAP BOX
57-610-00	57-610-00	57-610-00		GEN VISUAL	LEFT OUTBOARD AILERON
57-612-00	57-612-00	57-612-00		DETAILED EX	LEFT OUTBOARD AILERON
57-614-00	57-614-00	57-614-00		DETAILED EX	OUTBD AILERON SPAR, HINGES, ACTUATOR
57-616-00	57-616-00	57-616-00		GEN VISUAL	LEFT WING INBOARD TE FLAP
57-618-00	57-618-00	57-618-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-620-00	57-620-00	57-620-00		GEN VISUAL	WING EXTERIOR - RIGHT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-162



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-622-00	57-622-00	57-622-00		GEN VISUAL	WING EXTERIOR - RIGHT
57-624-00	57-624-00	57-624-00		GEN VISUAL	NACELLE STRUT NO. 2 AFT UPPER SPAR
57-626-00	57-626-00	57-626-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
57-628-00	57-628-00	57-628-00		GEN VISUAL	SLAT 7 LINK BRACE & ACTUATOR SUPPORT
57-634-00	57-634-00	57-634-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
57-636-00	57-636-00	57-636-00		GEN VISUAL	RIGHT WING LE SLATS - INTERIOR
57-638-00	57-638-00	57-638-00		GEN VISUAL	RIGHT SLAT/NACELLE SEAL KREUGER FLAP
57-642-00	57-642-00	57-642-00		GEN VISUAL	LEADING EDGE EXTERIOR - RIGHT
57-646-00	57-646-00	57-646-00		GEN VISUAL	NO. 9 SLAT MAIN & AUXILIARY TRACKS
57-648-00	57-648-00	57-648-00		GEN VISUAL	RIGHT WING FIXED LE STRUCTURE
57-650-00	57-650-00	57-650-00		GEN VISUAL	RIGHT WING FIXED LE STRUCTURE
57-662-00	57-662-00	57-662-00		GEN VISUAL	RIGHT WING INSPAR LWR SURFACE, EXT
57-664-00	57-664-00	57-664-00		GEN VISUAL	RIGHT WING INSPAR LWR SURFACE
57-666-00	57-666-00	57-666-00		GEN VISUAL	RIGHT WING INSPAR UPPER SURFACE
57-668-00	57-668-00	57-668-00		DETAILED EX	RIGHT WING INSPAR UPPER SURFACE
57-670-00	57-670-00	57-670-00		DETAILED EX	RIGHT WING INSPAR LWR SURFACE
57-672-00	57-672-00	57-672-00		DETAILED EX	RIGHT WING INSPAR UPPER SURFACE
57-674-00	57-674-00	57-674-00		DETAILED IN	R WING LWR SURFACE SPANWISE SPLICE
57-676-00	57-676-00	57-676-00		DETAILED IN	R WING LWR SURF ACCESS HOLE CUTOUTS
57-678-00	57-678-00	57-678-00		DETAILED IN	R WING LWR SURFACE/SIDE OF BODY RIB
57-680-00	57-680-00	57-680-00		DETAILED IN	R WING REAR SPAR WEB & LOWER CHORD
57-682-00	57-682-00	57-682-00		DETAILED IN	R WING REAR SPAR LWR CHORD RIB 1&3
57-684-00	57-684-00	57-684-00		DETAILED IN	RIGHT WING SIDE OF BODY RIB WEB
57-686-00	57-686-00	57-686-00		DETAILED IN	SIDE OF BODY RIB LOWER CHORD CUTOUTS
57-688-00	57-688-00	57-688-00		GEN VISUAL	RIGHT WING MAIN TANK
57-690-00	57-690-00	57-690-00		DETAILED IN	RIGHT MLG TRUNNION BACKUP STRUCTURE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-692-00	57-692-00	57-692-00		DETAILED IN	RIGHT MLG BEAM BACKUP STRUCTURE
57-694-00	57-694-00	57-694-00		DETAILED IN	R WING NACELLE STRUT SUPPORT BACKUP
57-696-00	57-696-00	57-696-00		DETAILED IN	RIGHT WING LWR SPAR CHORDS
57-698-00	57-698-00	57-698-00		DETAILED IN	R WING LWR SPANWISE SPLICE STRINGERS
57-700-00	57-700-00	57-700-00		DETAILED IN	R WING LWR SURF ACCESS HOLE CUTOUTS
57-702-00	57-702-00	57-702-00		DETAILED IN	NACELLE STRUT NO. 2 BACKUP STRUCTURE
57-704-00	57-704-00	57-704-00		DETAILED IN	R WING SPANWISE SPLICE STRINGER L-15
57-706-00	57-706-00	57-706-00		DETAILED IN	R WING FRONT SPAR LWR CHORD, RIB 7&9
57-708-00	57-708-00	57-708-00		GEN VISUAL	RIGHT WING INBOARD DRY BAY
57-710-00	57-710-00	57-710-00		DETAILED IN	R TE FLAP SUPPORT BACKUP STRUCTURE
57-712-00	57-712-00	57-712-00		GEN VISUAL	RIGHT WING OUTBOARD DRY BAY
57-714-00	57-714-00	57-714-00		GEN VISUAL	RIGHT WING OUTBOARD DRY BAY
57-716-00	57-716-00	57-716-00		GEN VISUAL	WING TIP & OUTBD SIDE OF WBL 929 RIB
57-718-00	57-718-00	57-718-00		SPCL DETAIL	WING TIP RIB & OUTBD SIDE OF RIB 36
57-722-00	57-722-00	57-722-00		GEN VISUAL	R WING TE SUPPORT STRUCT & REAR SPAR
57-724-00	57-724-00	57-724-00		DETAILED IN	UPPER WING/SIDE OF BODY SPLICE
57-726-00	57-726-00	57-726-00		GEN VISUAL	RIGHT WING TRAILING EDGE
57-728-00	57-728-00	57-728-00		GEN VISUAL	R MAIN GEAR DRAG BRACE MLG BEAM
57-730-00	57-730-00	57-730-00		GEN VISUAL	RIGHT WING TRAILING EDGE
57-734-00	57-734-00	57-734-00		GEN VISUAL	RIGHT WING SPOILERS
57-736-00	57-736-00	57-736-00		GEN VISUAL	RIGHT WING INBD TE FLAP BOX
57-738-00	57-738-00	57-738-00		GEN VISUAL	RIGHT WING INBD TE FLAP BOX
57-740-00	57-740-00	57-740-00		SPCL DETAIL	RIGHT INBOARD TE FLAP TORQUE TUBE
57-742-00	57-742-00	57-742-00		SPCL DETAIL	RIGHT WING INBOARD TE FLAP BOX
57-744-00	57-744-00	57-744-00		GEN VISUAL	RIGHT WING INBOARD TE FLAPS
57-746-00	57-746-00	57-746-00		GEN VISUAL	RIGHT INBOARD AILERON INTERIOR

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-164



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-748-00	57-748-00	57-748-00		GEN VISUAL	RIGHT INBOARD AILERON
57-750-00	57-750-00	57-750-00		GEN VISUAL	RIGHT INBOARD AILERON
57-752-00	57-752-00	57-752-00		DETAILED EX	RIGHT INBOARD AILERON
57-754-00	57-754-00	57-754-00		GEN VISUAL	R WING TE SUPPORT STRUC & REAR SPAR
57-756-00	57-756-00	57-756-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP BOX
57-758-00	57-758-00	57-758-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP BOX
57-760-00	57-760-00	57-760-00		SPCL DETAIL	RIGHT WING OUTBOARD TE FLAP BOX
57-762-00	57-762-00	57-762-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
57-764-00	57-764-00	57-764-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
57-766-00	57-766-00	57-766-00		SPCL DETAIL	RIGHT WING OUTBOARD TE FLAP BOX
57-768-00	57-768-00	57-768-00		GEN VISUAL	RIGHT OUTBOARD AILERON
57-770-00	57-770-00	57-770-00		DETAILED EX	RIGHT OUTBOARD AILERON
57-772-00	57-772-00	57-772-00		DETAILED EX	OUTBD AILERON SPAR, HINGES, ACTUATOR
57-774-00	57-774-00	57-774-00		GEN VISUAL	RIGHT WING INBOARD TE FLAP
57-776-00	57-776-00	57-776-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
57-786-10	57-786-10	57-786-10		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-12	57-786-12	57-786-12		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-14	57-786-14	57-786-14		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-16	57-786-16	57-786-16		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-18	57-786-18	57-786-18		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-20	57-786-20	57-786-20		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-787-00	57-787-00	57-787-00		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-787-02	57-787-02	57-787-02		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-787-04	57-787-04	57-787-04		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-06	57-787-06	57-787-06		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-08	57-787-08	57-787-08		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-787-10	57-787-10	57-787-10		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-12	57-787-12	57-787-12		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-14	57-787-14	57-787-14		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-16	57-787-16	57-787-16		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-18	57-787-18	57-787-18		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-20	57-787-20	57-787-20		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-00	57-788-00	57-788-00		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-02	57-788-02	57-788-02		DETAILED IN	RIGHT WING TRAILING EDGE INBD FLAP
57-788-04	57-788-04	57-788-04		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-788-06	57-788-06	57-788-06		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-08	57-788-08	57-788-08		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-10	57-788-10	57-788-10		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-12	57-788-12	57-788-12		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-14	57-788-14	57-788-14		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-16	57-788-16	57-788-16		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-18	57-788-18	57-788-18		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-20	57-788-20	57-788-20		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-789-00	57-789-00	57-789-00		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-789-02	57-789-02	57-789-02		SPCL DETAIL	R WING FWD TRUNNION SIDELOAD STRAP
57-789-04	57-789-04	57-789-04		SPCL DETAIL	R WING FWD TRUNNION SIDELOAD FTG
57-789-06	57-789-06	57-789-06		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-789-08	57-789-08	57-789-08		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-789-10	57-789-10	57-789-10		SPCL DETAIL	R WING REAR SPAR LWR CHORD AND SKIN
57-789-12	57-789-12	57-789-12		SPCL DETAIL	R WING FRONT SPAR LWR CHORD AND SKIN
57-789-14	57-789-14	57-789-14		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-789-16	57-789-16	57-789-16		SPCL DETAIL	R WING FRONT SPAR LWR CHORD AND SKIN

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-166



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-789-18	57-789-18	57-789-18		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-789-20	57-789-20	57-789-20		DETAILED IN	RIGHT WING INSPAR LOWER SURFACE
57-789-34	57-789-34	57-789-34		DETAILED IN	RIGHT WING TRAILING EDGE INBD FLAP
57-789-36	57-789-36	57-789-36		SPCL DETAIL	WING TRAILING EDGE INBD FLAP
57-789-38	57-789-38	57-789-38		DETAILED IN	LEFT WING TRAILING EDGE INBD FLAP
57-789-40	57-789-40	57-789-40		DETAILED IN	WING TRAILING EDGE INBD FLAP
57-790-00	57-790-00	57-790-00		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-790-02	57-790-02	57-790-02		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-790-04	57-790-04	57-790-04		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-790-06	57-790-06	57-790-06		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-790-08	57-790-08	57-790-08		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-790-10	57-790-10	57-790-10		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-790-12	57-790-12	57-790-12		SPCL DETAIL	RIGHT WING REAR SPAR LWR CHORD/SKIN
57-790-14	57-790-14	57-790-14		SPCL DETAIL	R WING REAR SPAR LOWER CHORD/SKIN
57-790-16	57-790-16	57-790-16		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-790-18	57-790-18	57-790-18		SPCL DETAIL	R WING REAR SPAR LWR CHORD AND SKIN
57-790-20	57-790-20	57-790-20		DETAILED EX	RIGHT WING INSPAR LOWER SURFACE
57-790-22	57-790-22	57-790-22		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-790-24	57-790-24	57-790-24		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-790-28	57-790-28	57-790-28		SPCL DETAIL	WING TRAILING EDGE INBD FLAP
57-790-32	57-790-32	57-790-32		SPCL DETAIL	WING TRAILING EDGE INBD FLAP
57-790-34	57-790-34	57-790-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-790-36	57-790-36	57-790-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-790-38	57-790-38	57-790-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-790-40	57-790-40	57-790-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-791-00	57-791-00	57-791-00		SPCL DETAIL	RIGHT WING INSPAR UPPER SURFACE

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-791-02	57-791-02	57-791-02		SPCL DETAIL	R WING FRONT SPAR LWR CHORD AND SKIN
57-791-04	57-791-04	57-791-04		SPCL DETAIL	R WING INBD LOWER SPLICE STRINGER
57-791-06	57-791-06	57-791-06		SPCL DETAIL	R WING FRONT SPAR LWR CHORD AND SKIN
57-791-08	57-791-08	57-791-08		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-791-10	57-791-10	57-791-10		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-791-12	57-791-12	57-791-12		SPCL DETAIL	RIGHT WING SPAR LOWER CHORD/SKIN
57-791-14	57-791-14	57-791-14		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-791-16	57-791-16	57-791-16		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-791-18	57-791-18	57-791-18		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-791-20	57-791-20	57-791-20		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-791-22	57-791-22	57-791-22		DETAILED IN	RIGHT WING TRAILING EDGE INBD FLAP
57-791-24	57-791-24	57-791-24		DETAILED IN	LEFT WING TRAILING EDGE INBD FLAP
57-791-26	57-791-26	57-791-26		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-791-28	57-791-28	57-791-28		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-791-30	57-791-30	57-791-30		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-791-32	57-791-32	57-791-32		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-791-34	57-791-34	57-791-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-791-36	57-791-36	57-791-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-791-38	57-791-38	57-791-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-791-40	57-791-40	57-791-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-00	57-792-00	57-792-00		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-02	57-792-02	57-792-02		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-04	57-792-04	57-792-04		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-06	57-792-06	57-792-06		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-08	57-792-08	57-792-08		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-10	57-792-10	57-792-10		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-168



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-792-12	57-792-12	57-792-12		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-14	57-792-14	57-792-14		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-16	57-792-16	57-792-16		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-18	57-792-18	57-792-18		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-20	57-792-20	57-792-20		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-22	57-792-22	57-792-22		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-24	57-792-24	57-792-24		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-26	57-792-26	57-792-26		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-28	57-792-28	57-792-28		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-30	57-792-30	57-792-30		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-32	57-792-32	57-792-32		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-34	57-792-34	57-792-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-36	57-792-36	57-792-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-38	57-792-38	57-792-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-40	57-792-40	57-792-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-00	57-793-00	57-793-00		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-02	57-793-02	57-793-02		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-04	57-793-04	57-793-04		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-06	57-793-06	57-793-06		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-08	57-793-08	57-793-08		DETAILED IN	LEFT WING TRAILING EDGE INBD FLAP
57-793-10	57-793-10	57-793-10		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-793-12	57-793-12	57-793-12		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-14	57-793-14	57-793-14		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-16	57-793-16	57-793-16		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-18	57-793-18	57-793-18		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-20	57-793-20	57-793-20		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-793-22	57-793-22	57-793-22		GEN VISUAL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-24	57-793-24	57-793-24		GEN VISUAL	LEFT WING TRAILING EDGE INBD FLAP
57-793-26	57-793-26	57-793-26		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-28	57-793-28	57-793-28		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-30	57-793-30	57-793-30		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-32	57-793-32	57-793-32		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-34	57-793-34	57-793-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-36	57-793-36	57-793-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-38	57-793-38	57-793-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-40	57-793-40	57-793-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-00	57-794-00	57-794-00		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-02	57-794-02	57-794-02		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-04	57-794-04	57-794-04		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-06	57-794-06	57-794-06		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-08	57-794-08	57-794-08		SPCL DETAIL	L WING FWD TRUNNION SIDELOAD STRAP
57-794-10	57-794-10	57-794-10		SPCL DETAIL	L WING FWD TRUNNION SIDELOAD FTG
57-794-12	57-794-12	57-794-12		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-794-14	57-794-14	57-794-14		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-794-16	57-794-16	57-794-16		SPCL DETAIL	L WING REAR SPAR LWR CHORD AND SKIN
57-794-18	57-794-18	57-794-18		SPCL DETAIL	L WING FRONT SPAR LWR CHORD AND SKIN
57-794-20	57-794-20	57-794-20		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-794-22	57-794-22	57-794-22		DETAILED IN	RIGHT WING TRAILING EDGE INBD FLAP
57-794-24	57-794-24	57-794-24		DETAILED IN	LEFT WING TRAILING EDGE INBD FLAP
57-794-26	57-794-26	57-794-26		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-794-28	57-794-28	57-794-28		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-30	57-794-30	57-794-30		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-170



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-794-32	57-794-32	57-794-32		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-34	57-794-34	57-794-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-794-36	57-794-36	57-794-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-38	57-794-38	57-794-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-794-40	57-794-40	57-794-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-795-00	57-795-00	57-795-00		SPCL DETAIL	L WING FRONT SPAR LWR CHORD AND SKIN
57-795-02	57-795-02	57-795-02		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-795-04	57-795-04	57-795-04		DETAILED IN	LEFT WING INSPAR LOWER SURFACE
57-795-06	57-795-06	57-795-06		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-795-08	57-795-08	57-795-08		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-795-10	57-795-10	57-795-10		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-795-12	57-795-12	57-795-12		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-795-14	57-795-14	57-795-14		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-795-16	57-795-16	57-795-16		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-795-18	57-795-18	57-795-18		SPCL DETAIL	LEFT WING REAR SPAR LOWER CHORD/SKIN
57-795-20	57-795-20	57-795-20		SPCL DETAIL	L WING REAR SPAR LOWER CHORD/SKIN
57-795-22	57-795-22	57-795-22		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-795-24	57-795-24	57-795-24		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-795-26	57-795-26	57-795-26		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-795-28	57-795-28	57-795-28		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-795-30	57-795-30	57-795-30		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-795-32	57-795-32	57-795-32		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-795-34	57-795-34	57-795-34		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-795-36	57-795-36	57-795-36		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-795-38	57-795-38	57-795-38		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-795-40	57-795-40	57-795-40		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-796-00	57-796-00	57-796-00		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-796-02	57-796-02	57-796-02		SPCL DETAIL	L WING REAR SPAR LWR CHORD AND SKIN
57-796-04	57-796-04	57-796-04		DETAILED EX	LEFT WING INSPAR LOWER SURFACE
57-796-06	57-796-06	57-796-06		SPCL DETAIL	LEFT WING INSPAR UPPER SURFACE
57-796-08	57-796-08	57-796-08		SPCL DETAIL	L WING FRONT SPAR LWR CHORD AND SKIN
57-796-10	57-796-10	57-796-10		SPCL DETAIL	L WING INBD LOWER SPLICE STRINGER
57-796-12	57-796-12	57-796-12		SPCL DETAIL	L WING FRONT SPAR LWR CHORD AND SKIN
57-796-14	57-796-14	57-796-14		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-796-16	57-796-16	57-796-16		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-796-18	57-796-18	57-796-18		SPCL DETAIL	LEFT WING SPAR LOWER CHORD/SKIN
57-796-20	57-796-20	57-796-20		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-796-22	57-796-22	57-796-22		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-24	57-796-24	57-796-24		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-26	57-796-26	57-796-26		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-28	57-796-28	57-796-28		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-30	57-796-30	57-796-30		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-32	57-796-32	57-796-32		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-34	57-796-34	57-796-34		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-36	57-796-36	57-796-36		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-38	57-796-38	57-796-38		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-40	57-796-40	57-796-40		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-00	57-797-00	57-797-00		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-02	57-797-02	57-797-02		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-04	57-797-04	57-797-04		DETAILED IN	INBOARD FLAP SUPPORT STRUCTURE
57-797-06	57-797-06	57-797-06		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-08	57-797-08	57-797-08		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.1-172



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-797-10	57-797-10	57-797-10		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-12	57-797-12	57-797-12		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-14	57-797-14	57-797-14		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-16	57-797-16	57-797-16		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-18	57-797-18	57-797-18		SPCL DETAIL	WING CTR SECTION LWR SURFACE
57-797-20	57-797-20	57-797-20		SPCL DETAIL	WING CTR SECT REAR SPAR LWR CHORD
57-797-22	57-797-22	57-797-22		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-24	57-797-24	57-797-24		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-26	57-797-26	57-797-26		DETAILED IN	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-28	57-797-28	57-797-28		DETAILED IN	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-30	57-797-30	57-797-30		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-32	57-797-32	57-797-32		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-34	57-797-34	57-797-34		DETAILED IN	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-36	57-797-36	57-797-36		DETAILED IN	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-38	57-797-38	57-797-38		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-40	57-797-40	57-797-40		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-00	57-798-00	57-798-00		SPCL DETAIL	W CTR REAR SPAR CHORD AND SKIN
57-798-02	57-798-02	57-798-02		DETAILED IN	W CTR FRONT SPAR CHORD AND SKIN
57-798-04	57-798-04	57-798-04		DETAILED IN	W CTR TYPICAL STRINGER AND SKIN
57-798-06	57-798-06	57-798-06		DETAILED EX	WING CENTER SECTION LOWER SURFACE
57-798-08	57-798-08	57-798-08		SPCL DETAIL	WING CTR SECTION FUEL TANK WET BAY
57-798-10	57-798-10	57-798-10		SPCL DETAIL	WING CENTER SECTION FUEL TANK
57-798-12	57-798-12	57-798-12		SPCL DETAIL	WING CTR SECTION FUEL TANK WET BAY
57-798-14	57-798-14	57-798-14		SPCL DETAIL	WING CENTER SECTION FUEL TANK
57-798-16	57-798-16	57-798-16		SPCL DETAIL	WING CTR SECTION FUEL TANK WET BAY
57-798-18	57-798-18	57-798-18		SPCL DETAIL	WING CTR SECTION FUEL TANK WET BAY

D622T001



767 MAINTENANCE PLANNING DATA

MPD ITEM NUMBER	MRB ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.1 SORTED BY MPD - CARD
					TITLE
57-798-20	57-798-20	57-798-20		DETAILED IN	W CTR SPLICE STRINGER/SKIN
57-798-22	57-798-22	57-798-22		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-24	57-798-24	57-798-24		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-26	57-798-26	57-798-26		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-28	57-798-28	57-798-28		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-30	57-798-30	57-798-30		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-32	57-798-32	57-798-32		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-34	57-798-34	57-798-34		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-36	57-798-36	57-798-36		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-38	57-798-38	57-798-38		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-40	57-798-40	57-798-40		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
71-600-00	71-600-00	71-600-00		DETAILED IN	NO. 1 POWERPLANT
71-602-00	71-602-00	71-602-00		GEN VISUAL	NO. 1 POWERPLANT
71-604-00	71-604-00	71-604-00		DETAILED IN	NO. 2 POWERPLANT
71-606-00	71-606-00	71-606-00		GEN VISUAL	NO. 2 POWERPLANT

D622T001



767 MAINTENANCE PLANNING DATA

F. TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
21-001	21-51-15-6A	21-001-01		CHECK/INSP	CABIN AIR SUPPLY CHECK VALVE
21-002	21-23-05-2A	21-002-01		CLEAN	RETURN AIR GRILLES/LOUVERS
21-003	21-25-02-4A		G-21-003-01	REPLACE	RECIRCULATION AIR PREFILTERS
21-004	21-25-02-4B		G-21-004-01	REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-004	21-25-02-4F		G-21-004-09	REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-005	21-61-09-4A		G-21-005-03	REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-006	21-26-03-4A	21-006-01		REPLACE	GALLEY VENTILATION FILTERS
21-007	21-31-03-2A		G-21-007-C1 G-21-007-C2 G-21-007-C3	CHECK/INSP	CABIN PRESSURE OUTFLOW VALVE
21-008	21-31-03-2B		G-21-007-C1 G-21-007-C2 G-21-007-C3	CLEAN	CABIN PRESSURE OUTFLOW VALVE
21-009	21-31-00-5A	21-009-01	A-21-007-C1	OPERATIONAL	CABIN PRESSURE OUTFLOW VALVE
21-010	21-32-01-5A	21-010-01		FUNCTIONAL	POSITIVE PRESSURE RELIEF VALVES
21-011	21-32-02-4A	21-011-01	B-21-010-01	REPLACE	POSITIVE PRESS RELIEF VALVE FILTERS
21-012	21-33-00-5A	21-012-01		FUNCTIONAL	CABIN ALTITUDE WARNING SWITCH
21-013	21-43-00-5A	21-013-01	W-26-010-XX	OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-013	21-43-00-5C	21-013-03		OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-013	21-44-00-5A	21-013-02	W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-013	21-44-00-5A	21-013-11		OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-013	21-44-00-5C	21-013-06		OPERATIONAL	AFT CARGO HEATING SHUTOFF VALVE
21-014	21-43-00-5B	21-014-01		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-014	21-43-00-5B	21-014-08		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-014	21-44-00-5B	21-014-02		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-014	21-44-00-5D	21-014-06		FUNCTIONAL	AFT CARGO TEMPERATURE SWITCHES
21-015	21-51-00-5A		G-21-015-C1	OPERATIONAL	PACK TEMPERATURE CONTROLLERS
21-016	21-51-00-5B		G-21-015-C1	OPERATIONAL	STANDBY PACK TEMPERATURE CONTROLLER
21-017	21-51-02-7A	21-017-01		CLEAN	COOLING PACK HEAT EXCHANGERS
21-018	21-51-19-2A	21-018-01		FUNCTIONAL	COMPRESSOR OUTLET OVERHEAT SWITCH
21-019	21-51-18-2A	21-019-01		FUNCTIONAL	PACK OVERHEAT SWITCH
21-020	21-58-00-5A		G-21-020-C1	OPERATIONAL	MANIFOLD INTERCONNECT VALVE

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
21-020	21-58-00-5A		G-21-020-10	OPERATIONAL	MANIFOLD INTERCONNECT VALVE
21-021	21-58-02-6A	21-021-01	B-21-024-01	CHECK/INSP	E/E COOLING SUP/EXH FAN CHECK VALVES
21-022	21-58-00-5B		G-21-020-C1	OPERATIONAL	E/E COOLING OVERRIDE VALVE
21-022	21-58-00-5B		G-21-020-C9	OPERATIONAL	E/E COOLING OVERRIDE VALVE
21-023	21-58-21-4A	21-023-01		FUNCTIONAL	E/E COOLING SKIN TEMPERATURE SENSOR
21-024	21-58-22-2A	21-024-01	A-21-021-01	CHECK/INSP	E/E COOLING SYSTEM CONICAL SCREENS
21-025	21-61-00-5A	21-025-01	W-21-025-C1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-026	21-58-00-5D	21-026-51		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026	21-58-00-5D	21-026-56		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-027	21-58-34-2A	21-027-51		OPERATIONAL	E/E COOLING LOW FLOW MONITOR SYSTEM
21-028	21-58-32-2A	21-028-51	B-21-034-01	OPERATIONAL	INSTRUMENT COOLING (ELECT) MONITORS
21-029	21-58-30-2A	21-029-51		CLEAN	FWD E/E COOLING AIR CLEANER
21-030	21-25-02-4D		G-21-030-01	REPLACE	RECIRCULATION AIR FILTERS
21-031	21-25-02-4E		G-21-031-24	REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-031	21-43-00-5A	21-031-51		OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-032	21-21-10-5A	21-032-50		OPERATIONAL	OPERATIONALLY CHECK THE AVS SYSTEM
21-033	21-51-22-4B	21-033-07		RESTORE	CATALYTIC (OZONE) CONVERTERS
21-034	21-51-31-4B	21-034-51		FUNCTIONAL	CHECK THE AC PACK HX FOR LEAKAGE.
21-035	21-51-31-4A	21-035-51		CLEAN	AIR CONDITIONING PACK HEAT EXCHANGR
21-051	21-23-20-5A	21-051-02		OPERATIONAL	MAIN DECK AIR DISTRIBUTION SHUTOFF
21-053	21-44-00-5A	21-053-01	W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-053	21-44-00-5B	21-053-02		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-054	21-26-03-4A	21-054-01		REPLACE	GALLEY VENTILATION FILTERS
22-001	22-12-00-A		P-06-047-01	CHECK/INSP	ELEVATOR AUTOPILOT SERVO LINKAGES
22-002	22-13-00-A		P-06-056-01	CHECK/INSP	DIRECTIONAL AUTOPILOT SERVO LINKAGES
22-003	22-10-00-5A		G-33-004-C1 G-33-004-C2	OPERATIONAL	A/P DISC ANNUNCIATOR INDICATOR
22-004	22-10-00-5B		G-33-004-C1 G-33-004-C2	OPERATIONAL	AUTOPILOT ANNUNCIATOR INDICATOR
22-005	27-21-00-H		P-06-056-01	CHECK/INSP	YAW DAMPER - MECHANICAL LINKAGE
22-006	27-21-00-G		P-06-056-01	CHECK/INSP	YAW DAMPER BIAS POGO LINKAGE
22-007	22-32-00-5A		G-33-004-C1 G-33-004-C2	OPERATIONAL	A/T DISC ANNUNCIATOR INDICATOR
23-001	23-31-00-5A	23-001-01		FUNCTIONAL	SPEAKER SYSTEM
23-001	23-31-00-5A	23-001-14		FUNCTIONAL	SPEAKER SYSTEM

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-2



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
23-002	23-61-01-2A	23-002-01		FUNCTIONAL	STATIC DISCHARGERS
23-003	23-71-00-5A	23-003-01		OPERATIONAL	VOICE RECORDER - SELF TEST
23-004	23-71-00-5B	23-004-01		FUNCTIONAL	VOICE RECORDER - 4 CHANNEL OPERATION
23-005	23-71-03-2B	23-005-02		RESTORE	VOICE RECORDER ULB
23-005	23-71-03-2C	23-005-03		OPERATIONAL	VOICE DATA RECORDER ULB
23-006	23-24-00-5A	23-006-01		OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-007	23-24-01-2A	23-007-01		REPLACE	EMERGENCY LOCATOR TRANSMITTER
24-001	12-13-03-3A	24-001-01-1		SERVICE	ENGINE 1 IDG OIL LEVEL
24-001	12-13-03-3A	24-001-01-2		SERVICE	ENGINE 2 IDG OIL LEVEL
24-001	12-13-03-3A	24-001-09-1		SERVICE	ENGINE 1 IDG OIL LEVEL
24-001	12-13-03-3A	24-001-09-2		SERVICE	ENGINE 2 IDG OIL LEVEL
24-001	12-13-03-3C	24-001-02-1		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-001	12-13-03-3C	24-001-02-2		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-001	12-13-03-3C	24-001-10-1		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-001	12-13-03-3C	24-001-10-2		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-002	24-11-03-6A	24-002-01-1		CHECK/INSP	ENGINE 1 IDG QAD COUPLING
24-002	24-11-03-6A	24-002-01-2		CHECK/INSP	ENGINE 2 IDG QAD COUPLING
24-003	24-11-01-6A		G-24-003-03	OPERATIONAL	IDG DISCONNECT
24-004	24-22-00-5A	24-004-01		OPERATIONAL	BUS POWER CONTROL UNIT (BPCU)
24-004	24-22-00-5A	24-004-06		OPERATIONAL	BUS POWER CONTROL UNIT (BPCU)
24-005	24-22-00-5B		G-24-005-02	OPERATIONAL	BUS TIE BREAKER
24-006	24-31-01-4A		G-24-006-02	RESTORE	MAIN BATTERY
24-007	24-30-00-5A		G-24-007-C1 G-24-007-C4	OPERATIONAL	MAIN & APU BATTERY CHARGER
24-008	24-31-04-4A		G-24-008-02	RESTORE	APU BATTERY
24-009	24-30-00-5B		G-24-009-C1 G-24-009-C4	OPERATIONAL	DC TIE RELAY
24-010	24-33-00-6C		G-24-010-10	OPERATIONAL	STANDBY POWER SYSTEM
24-011	24-30-00-5C		G-24-007-C1 G-24-007-C4	OPERATIONAL	BATTERY CURRENT MONITOR
24-012	24-30-00-5D		G-24-009-C1 G-24-009-C4	OPERATIONAL	DC TIE CONTROL UNIT (DTCU)
24-013	24-25-00-5A		G-24-013-52	OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-014	24-25-00-5B		G-24-014-52	FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-015	12-13-03-3A	24-015-03-1		SERVICE	ENGINE 1 IDG OIL LEVEL

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
24-015	12-13-03-3A	24-015-03-2		SERVICE	ENGINE 2 IDG OIL LEVEL
24-016	12-13-03-3C	24-016-12-1		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-016	12-13-03-3C	24-016-12-2		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-017	24-11-02-2A		G-24-016-C2-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT
24-017	24-11-02-2A		G-24-016-C2-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-018	24-11-02-2A		G-24-016-C2-1	REPLACE	ENGINE 1 IDG CHARGE FILTER ELEMENT
24-018	24-11-02-2A		G-24-016-C2-2	REPLACE	ENGINE 2 IDG CHARGE FILTER ELEMENT
25-001	25-11-00-6B	25-001-01		OPERATIONAL	CREW SEAT ADJUSTMENT/LOCK MECHANISM
25-002	25-11-00-6A	25-002-01		OPERATIONAL	CREW SEAT HARNESS/INERTIA REEL
25-003	25-25-00-A	25-003-01		OPERATIONAL	PASSENGER SEAT BELTS
25-004	25-25-01-A	25-004-01		CHECK/INSP	PASSENGER SEATS - FLOOR ATTACHMENT
25-005	25-25-03-6A	25-005-01		OPERATIONAL	ATTENDANT SEATS RESTRAINT
25-006	25-41-00-6A	25-006-01	W-26-014-01	CHECK/INSP	LAVATORY WASTE COMPARTMENT DOORS
25-007	12-21-33-3A 12-21-33-3B		G-12-033-C1 G-12-033-C2	LUBRICATE	ROLLOUT STOP SHAFT/CAM FOLLOWER/PAWL
25-008	12-21-33-3C		G-12-033-C1	LUBRICATE	LATERAL GUIDE CAM FOLLOWERS
25-009	25-53-00-A		P-06-008-01	CHECK/INSP	CARGO LATERAL RESTRAINT COMPONENTS
25-010	25-53-00-B		P-06-008-01	CHECK/INSP	CARGO LONGITUDINAL RESTRAINT COMPNTS
25-011	25-61-01-2A	25-011-01	W-52-014-01	CHECK/INSP	OFF-WING EMERGENCY EXIT ASSIST STRAP
25-012	25-61-02-A	25-012-01		CHECK/INSP	FLIGHT COMPARTMENT ESCAPE ROPES
25-013	25-62-00-A	25-013-01		CHECK/INSP	LIFE JACKETS (IF INSTALLED)
25-013	25-62-00-A	25-013-02		CHECK/INSP	LIFE JACKETS (IF INSTALLED)
25-014	25-62-00-B	25-014-01		RESTORE	LIFE RAFT (IF INSTALLED)
25-014	25-62-00-B	25-014-03		RESTORE	LIFE RAFT (IF INSTALLED)
25-015	25-63-02-2C	25-015-01		OPERATIONAL	POWER MEGAPHONE
25-016	25-63-00-B	25-016-01		FUNCTIONAL	EMERGENCY LOCATOR TRANSMITTER
25-017	25-63-01-2A	25-017-01		OPERATIONAL	EMERGENCY EVACUATION SIGNAL SYSTEM
25-018	25-64-00-A	25-018-01		CHECK/INSP	DETACHABLE EMERGENCY EQUIPMENT
25-018	25-64-00-A	25-018-02		CHECK/INSP	DETACHABLE EMERGENCY EQUIPMENT
25-019	25-65-00-6A	25-019-01	W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-020	25-65-01-4A	25-020-01	W-12-001-01	RESTORE	OFF-WING EVACUATION RAMP/SLIDE PACK
25-021	25-65-02-6A	25-021-01		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-022	25-65-04-4A	25-022-01	A-25-023-01	OPERATIONAL	OFF-WING SLIDE ACTUATION CABLES
25-023	25-65-08-A	25-023-01	B-25-022-01	CHECK/INSP	OFF-WING COMPARTMENT DOOR/DOOR LATCH
25-023	25-65-10-A	25-023-02	W-25-023-01	CHECK/INSP	OFF-WING COMP DOOR OPENING ACTUATORS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-4



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
25-023	25-65-11-A	25-023-03	W-25-023-01	CHECK/INSP	OFF-WING COMPT DOOR LATCH ACTUATOR
25-024	25-65-10-4A	25-024-01	W-25-023-02	REPLACE	OFF-WING COMP DOOR OPENING ACTUATORS
25-024	25-65-11-4A	25-024-02	W-25-023-03	REPLACE	OFF-WING COMPT DOOR LATCH ACTUATOR
25-025	25-65-07-6A	25-025-01	A-25-023-02	CHECK/INSP	OFF-WING COMPARTMENT DOOR INTEGRATOR
25-026	25-65-17-4A	25-026-01		RESTORE	OFF-WING ESCAPE SYSTEM BATTERIES
25-027	25-65-19-4A	25-027-01-1		RESTORE	L OFF-WING SPOILER OVERRIDE ACTUATOR
25-027	25-65-19-4A	25-027-01-2		RESTORE	R OFF-WING SPOILER OVERRIDE ACTUATOR
25-028	25-66-02-6A	25-028-01		CHECK/INSP	ENTRY/SERVICE DOOR ESC SLIDE BOTTLES
25-028	25-66-10-6A	25-028-02		CHECK/INSP	EMER EXIT DOOR ESCAPE SLIDE BOTTLES
25-029	25-66-01-4A	25-029-01	W-25-029-03	RESTORE	ENTRY/SERVICE DOOR ESCAPE SLIDE
25-029	25-66-10-4A	25-029-02		RESTORE	EMER EXIT DOOR ESCAPE SLIDE
25-030	25-66-03-A	25-030-01		CHECK/INSP	ENTRY/SERVICE DOOR SLIDE DEPLOY MECH
25-031	25-65-00-5A	25-031-01		OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-032	25-64-00-B	25-032-51		REPLACE	EMERGENCY ESCAPE BREATHING DEVICES
25-034	25-65-02-2A	25-034-05		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-037	25-59-00-A		P-06-182-01	CHECK/INSP	MAIN DECK CARGO LINING
25-038	25-58-00-A		P-06-175-01	CHECK/INSP	M/D CARGO HANDLING & RESTRAINT SYS
25-041	25-61-03-2A	25-041-01		REPLACE	EMERGENCY ESCAPE DESCENT DEVICES
25-042	25-65-02-4B	25-042-01		REPLACE	OFF-WING SLIDE BOTTLE SQUIB
25-043	25-65-00-2A	25-043-03	W-26-015-01	OPERATIONAL	OFF-WING SLIDE BOTTLE SQUIBS
25-044	25-11-00-6C	25-044-01		OPERATIONAL	SUPERNUMERARY SEATS RESTRAINT
26-001	26-16-00-5A		G-26-001-C1 G-26-001-C2 G-26-001-C3 G-26-001-C4	OPERATIONAL	NO. 2 CARGO SMOKE DETECTOR BLOWER
26-002	26-16-00-5B		G-26-001-C1 G-26-001-C2 G-26-001-C3 G-26-001-C4	OPERATIONAL	CARGO SMOKE DETECTOR BLOWERS
26-003	26-16-00-5C		G-26-001-C1 G-26-001-C2 G-26-001-C3 G-26-001-C4	OPERATIONAL	CARGO SMOKE DET PLENUM PRESS SWITCH
26-004	26-21-01-6A	26-004-01		OPERATIONAL	ENGINE FIRE SWITCHES
26-004	26-21-01-6A	26-004-02		OPERATIONAL	ENGINE FIRE SWITCHES
26-005	26-21-03-4A	26-005-01		REPLACE	ENG FIRE EXT BOTTLE SQUIB CARTRIDGES

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
26-005	26-21-03-4A	26-005-02		REPLACE	ENG FIRE EXT BOTTLE SQUIB CARTRIDGES
26-005	26-21-03-4A	26-005-03-1		REPLACE	ENGINE 1 FIRE EXT BOTTLE SQUIB CART
26-005	26-21-03-4A	26-005-03-2		REPLACE	ENGINE 2 FIRE EXT BOTTLE SQUIB CART
26-006	26-21-00-5A	26-006-01	W-26-012-XX	OPERATIONAL	ENG FIRE EXT BOTTLE PRESSURE SWITCH
26-006	26-21-00-5A	26-006-02-1		OPERATIONAL	ENG 1 FIRE EXT BOTTLE PRESS SWITCH
26-006	26-21-00-5A	26-006-02-2		OPERATIONAL	ENG 2 FIRE EXT BOTTLE PRESS SWITCH
26-007	26-22-01-6A	26-007-01		OPERATIONAL	APU FIRE SWITCH
26-008	26-22-02-4A	26-008-01		REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-008	26-22-02-4A	26-008-02		REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-009	26-22-00-5A	26-009-01		OPERATIONAL	APU FIRE EXT BOTTLE PRESSURE SWITCH
26-010	26-23-01-6A		G-26-010-04	OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-011	26-23-02-4A	26-011-01		REPLACE	CARGO FIRE EXT BOTTLE (KIDDE) SQUIB
26-011	26-23-02-4A		G-26-011-05	REPLACE	CARGO FIRE EXT BOTTLE (HTL) SQUIB
26-012	26-23-00-5A		G-26-012-04	OPERATIONAL	CARGO FIRE EXT BTL PRESSURE SWITCHES
26-013	26-26-02-6A	26-013-01		CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-013	26-26-03-6A	26-013-02		CHECK/INSP	PORTABLE WATER FIRE EXTINGUISHERS
26-014	26-24-01-2A	26-014-01	W-25-006-01	CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-015	26-10-00-6A	26-015-51		OPERATIONAL	FIRE/OVERHEAT LOGIC/TEST SYSTEM
26-015	26-10-00-6A	26-015-54		OPERATIONAL	FIRE/OVERHEAT LOGIC/TEST SYSTEM
26-016	26-23-03-6A	26-016-51		OPERATIONAL	CARGO FIRE EXT BOTTLE RELAYS
26-017	26-23-00-5B		G-26-017-58	FUNCTIONAL	CARGO FIRE EXT DISCHARGE SYSTEM
26-018	26-13-00-5A		G-26-018-52	OPERATIONAL	LAVATORY SMOKE DETECTORS
26-019	26-16-00-A		G-26-019-54	CHECK/INSP	CRGO SMOKE DET AIR SAMPLING ORIFICES
26-020	26-16-00-5D		G-26-001-C1 G-26-001-C2 G-26-001-C3 G-26-001-C4	OPERATIONAL	CARGO SMOKE DET AIR SAMPLING TUBES
26-025	26-14-00-A	26-025-01		CHECK/INSP	SMOKE DETECTOR SAMPLING ORIFICES
26-026	26-14-00-5C		G-26-026-C1	OPERATIONAL	SMOKE DETECTOR VACUUM EJECTOR
26-027	26-14-00-5E		G-26-027-C1	OPERATIONAL	SMOKE DETECTOR SAMPLING TUBE ORIFICE
26-028	26-14-00-5D		G-26-026-C1	OPERATIONAL	VACUUM PRESSURE SWITCH
26-029	26-14-00-5F		G-26-027-C1	OPERATIONAL	SMOKE DETECTOR SAMPLING TUBES
26-030	26-16-00-5E		G-26-030-C1	OPERATIONAL	SMOKE DETECTOR SAMPLING ORIFICES
26-031	26-16-00-B	26-031-01		CHECK/INSP	SMOKE DETECTOR SAMPLING ORIFICES
26-032	26-16-00-5F		G-26-030-C1	OPERATIONAL	SMOKE DETECTOR SAMPLING TUBES

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
26-034	26-16-00-5G	26-034-01		OPERATIONAL	CARGO DETECTOR HEATERS/CONTROLLERS
26-035	26-23-06-4A	26-035-01		REPLACE	FLOW VALVE SQUIB CARTRIDGES
27-001	20-20-02-6A 20-20-02-6B 20-20-02-6C 20-20-02-6D 20-20-02-6E 20-20-02-6F 20-20-02-6G 20-20-02-6H 20-20-02-6I 20-20-02-6K		G-27-001	CHECK/INSP	FLIGHT CONTROL CABLES
27-002	27-11-00-A		P-06-003-01	CHECK/INSP	AILERON MECHANICAL CONTROL PATH
27-003	27-11-00-5A	27-003-01	W-27-010-01	OPERATIONAL	AILERON POWER CONTROL ACTUATOR
27-004	27-11-00-D		P-06-003-01	CHECK/INSP	AILERON CONTROL INPUT CONNECTIONS
27-005	27-11-00-C		P-06-016-01	CHECK/INSP	FEEL, CENTERING AND TRIM MECHANISM
27-006	27-11-00-B		P-06-017-01	CHECK/INSP	AILERON CONTROL OVERRIDE MECHANISM
27-007	27-11-36-4A	27-007-01		OPERATIONAL	DUAL AILERON CONTROL OVERRIDE SYSTEM
27-008	27-21-00-C		P-06-056-01	CHECK/INSP	RUDDER FEEL, CENTERING AND TRIM MECH
27-009	27-21-00-D		P-06-003-01	CHECK/INSP	RUDDER MECHANICAL CONTROL PATH
27-010	27-21-00-5A	27-010-01	W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-011	27-21-00-A		P-06-056-01	CHECK/INSP	YAW DAMPER, RUDDER RATIO CHANGER
27-012	27-21-00-E		P-06-056-01	CHECK/INSP	RUDDER TRIM ACTUATOR
27-013	27-21-00-F		P-06-056-01	CHECK/INSP	RUDDER RATIO CHANGER
27-014	27-21-00-B		P-06-056-01	CHECK/INSP	RUDDER RATIO CHANGER BUS ROD
27-015	27-21-00-5B		G-27-015-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-016	27-31-00-C		P-06-003-01	CHECK/INSP	ELEVATOR MECHANICAL CONTROL PATH
27-017	27-31-00-5A	27-017-01		OPERATIONAL	ELEVATOR DUAL CONTROL PATH OVERRIDE
27-018	27-31-00-5B	27-018-01	W-27-010-01	OPERATIONAL	ELEVATOR POWER CONTROL ACTUATOR
27-019	27-31-00-B		P-06-047-01	CHECK/INSP	ELEVATOR FEEL & CENTERING MECHANISM
27-020	27-31-00-A		P-06-047-01	CHECK/INSP	ELEVATOR NEUTRAL SHIFT MECHANISM
27-021	27-31-00-5C	27-021-01		OPERATIONAL	ELEVATOR NEUTRAL SHIFT MECHANISM
27-022	27-32-00-5A	27-022-01		OPERATIONAL	STALL WARNING SYSTEM
27-023	27-41-00-5A	27-023-01		OPERATIONAL	MANUAL-MECH HORZ STAB TRIM CONTROL
27-024	27-41-00-5B	27-024-01		FUNCTIONAL	STABILIZER TRIM POSITION TRANSMITTER
27-025	27-41-00-5C	27-025-01		OPERATIONAL	STAB TRIM CNTRL COL CUTOFF SWITCHES

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
27-026	27-41-00-5D	27-026-01		OPERATIONAL	STAB TRIM CUTOUT (PEDESTAL) SWITCHES
27-027	12-21-05-3A		G-12-003-C1	LUBRICATE	STAB TRIM ACTUATOR ATTACHMENT GIMBAL
27-028	27-41-10-B	27-028-01		CHECK/INSP	STAB TRIM ACTUATOR ATTACHMENT GIMBAL
27-029	12-21-05-3B		G-12-003-C1	LUBRICATE	STAB TRIM ACTUATOR BALL NUT & SCREW
27-030	27-41-10-6B	27-030-01		CHECK/INSP	STAB TRIM ACTUATOR BALLSCREW/NUT
27-032	27-51-00-A		P-06-011-01	CHECK/INSP	FLAP/SLAT MECHANICAL CONTROL PATH
27-033	27-51-00-5D	27-033-01		OPERATIONAL	FLAP/SLAT ELECTRONICS UNIT (FSEU)
27-034	27-51-30-B		P-06-017-01	CHECK/INSP	TE FLAP LOAD ALLEVIATION INPUT CONN
27-035	27-51-30-A		P-06-017-01	CHECK/INSP	TE FLAP LOAD ALLEVIATION MECHANISM
27-036	27-51-00-5A	27-036-01		OPERATIONAL	ALT TE FLAP POWER DRIVE SYSTEM
27-036	27-51-00-5A	27-036-51		OPERATIONAL	ALT TE FLAP POWER DRIVE SYSTEM
27-037	27-51-00-5B	27-037-01		OPERATIONAL	TE FLAP FAILURE PROTECTION SYSTEM
27-038	12-21-09-3A		G-12-011-01	LUBRICATE	TE FLAP DRIVE SHAFT COUPLINGS
27-039	12-21-09-3B 12-21-09-3G 12-21-09-3H		G-12-012-01	LUBRICATE	TE FLAP DRIVE LINKAGES
27-040	27-51-00-B		P-06-016-01	CHECK/INSP	TE FLAP DRIVE SYSTEM COMPONENTS
27-041	27-51-41-A		P-06-121-01	CHECK/INSP	TE FLAP DRIVE SHAFT SAFETY STRAPS
27-042	27-51-00-5C	27-042-01		OPERATIONAL	TE FLAP ASYMMETRY PROTECTION SYSTEM
27-043	27-81-00-5A	27-043-01		OPERATIONAL	LE SLAT FAILURE PROTECTION SYSTEM
27-043	27-81-00-5A	27-043-51		OPERATIONAL	LE SLAT FAILURE PROTECTION SYSTEM
27-044	27-81-00-5B	27-044-01	A-27-043-01	OPERATIONAL	LE SLAT ASYMMETRY PROTECTION SYSTEM
27-045	27-62-00-5A	27-045-01		OPERATIONAL	AUTO SPEEDBRAKE
27-046	27-81-00-6A		G-27-054-01	OPERATIONAL	TE FLAP/LE SLAT INHIBIT SYSTEM
27-047	27-81-00-5C	27-047-01	B-27-043-01	OPERATIONAL	LE SLAT ALTERNATE DRIVE SYSTEM
27-048	12-21-08-3F		G-12-010-01	LUBRICATE	LE SLAT DRIVE SHAFT COUPLINGS
27-049	27-81-24-A		P-06-011-01	CHECK/INSP	LE SLAT DRIVE SYSTEM COMPONENTS
27-050	12-21-08-3B 12-21-08-3E		G-12-007-C1 G-12-009-01	LUBRICATE	LE SLAT LINKAGES
27-051	27-81-24-B		P-06-099-01	CHECK/INSP	LE SLAT DRIVE SHAFT SAFETY STRAPS
27-052	27-41-00-5F	27-052-51		OPERATIONAL	ALTERNATE HORIZ STAB TRIM SYSTEM
27-053	27-51-00-5F	27-053-51		FUNCTIONAL	TE FLAP LOAD ALLEVIATION SYSTEM
27-054	27-41-00-5G	27-054-51		OPERATIONAL	STABILIZER TRIM SECONDARY BRAKES
27-054	27-51-48-2A		G-27-054-01	OPERATIONAL	TE FLAP/LE SLAT SHUTOFF VALVE MODULE
27-055	27-41-00-5H	27-055-51		OPERATIONAL	STAB TRIM OVERRIDE WITH SPLIT COLUMN

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
27-057	27-31-20-4A	27-057-51		OPERATIONAL	ELEVATOR FEEL SHIFT
27-058	27-21-00-5C	27-058-52		OPERATIONAL	RUDDER PEDAL POGO RODS
27-059	27-31-68-2A	27-059-01	W-27-060-01	FUNCTIONAL	ELEVATOR HYDRAULIC RATE FUSES
27-060	27-23-51-2A	27-060-01	W-27-059-01	FUNCTIONAL	RUDDER HYDRAULIC RATE FUSES
27-061	27-81-42-4A	27-061-01		OPERATIONAL	LE SLAT SKEW DETECTION SYSTEM
27-062	27-81-42-4B	27-062-02		CHECK/INSP	LE SLAT SKEW DETECTION SYSTEM
27-063	12-21-08-3H	27-063-02		LUBRICATE	LE SLAT SKEW DETECTION SYSTEM
27-064	27-51-00-5G	27-064-51		OPERATIONAL	TE FLAP LOAD RELIEF ACTUATOR/RELAY
27-065	27-51-00-5H	27-065-51		FUNCTIONAL	TE FLAP LOAD RELIEF SYSTEM
27-066	27-51-00-5I	27-066-01-1		FUNCTIONAL	TE FLAP DRIVE NO-BACK BRAKES
27-066	27-51-00-5I	27-066-01-2		FUNCTIONAL	TE FLAP DRIVE NO-BACK BRAKES
27-067	12-21-09-3J	27-067-01		SERVICE	TE FLAP DRIVE ROTARY ACTUATOR OIL
27-068	12-21-08-3J	27-068-01		SERVICE	LE SLAT DRIVE OFFSET GEARBOX
27-069	27-81-20-2B	27-069-01-1		FUNCTIONAL	LE SLAT DRIVE NOBACK BRAKES
27-069	27-81-20-2B	27-069-01-2		FUNCTIONAL	LE SLAT DRIVE NOBACK BRAKES
27-070	27-32-00-5A	27-070-01		OPERATIONAL	STALL WARNING SYSTEM AND TAI
27-073	27-02-00-6A	27-073-01		FUNCTIONAL	ELEVATOR SURFACE FREEPLAY
27-076	27-02-00-6B	27-076-01		FUNCTIONAL	RUDDER SURFACE FREEPLAY
27-077	27-41-10-6A	27-077-01		FUNCTIONAL	STAB TRIM BALLSCREW AND BALLNUTS
27-078	27-31-07-4A	27-078-01		FUNCTIONAL	ELEVATOR PCA INPUT CONTROL ROD
27-079	27-31-00-5D	27-079-01		FUNCTIONAL	ELEVATOR PCA MIS-RIG
28-AWL	20-55-54-6A	28-AWL-18-1		FUNCTIONAL	FQIS WIRING AND BONDING
28-AWL	20-55-54-6A	28-AWL-18-2		FUNCTIONAL	FQIS WIRING AND BONDING
28-AWL	28-22-00-5F	28-AWL-20-1		FUNCTIONAL	CTR AUX TANK FUEL PUMP AUTO SHUTOFF
28-AWL	28-22-00-5H	28-AWL-27-1		OPERATIONAL	BOOST/OVERRIDE-JETTISON PUMP GFI
28-AWL	28-22-00-5H	28-AWL-28-1		FUNCTIONAL	CENTER TANK FUEL PUMP UNCOMMANDED-ON
28-AWL	29-11-27-6A	28-AWL-05-1		FUNCTIONAL	HYDRAULIC LINE FUEL TANK PENETRATION
28-AWL	29-11-27-6A	28-AWL-05-2		FUNCTIONAL	HYDRAULIC LINE FUEL TANK PENETRATION
28-001	28-11-00-A		P-06-115-01	CHECK/INSP	BAFFLE FLAPPER CHECK VALVES
28-002	28-13-00-B		P-06-114-01	CHECK/INSP	FUEL VENT FLOAT VALVES
28-003	28-13-00-A		P-06-114-01	CHECK/INSP	FUEL VENT FLOAT DRAIN VALVES
28-004	28-13-04-2B	28-004-01-1		OPERATIONAL	SURGE TANK PRESSURE RELIEF VALVE - L
28-004	28-13-04-2B	28-004-01-2		OPERATIONAL	SURGE TANK PRESSURE RELIEF VALVE - R
28-005	28-22-08-7A	28-005-01-1		CLEAN	AUTO SUMPING MOTIVE FLOW SCREENS - L
28-005	28-22-08-7A	28-005-01-2		CLEAN	AUTO SUMPING MOTIVE FLOW SCREENS - R

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
28-006	28-25-00-5A	28-006-01		FUNCTIONAL	APU FUEL SUPPLY LINE SHROUD
28-010	28-22-00-5C	28-010-51		OPERATIONAL	CENTER AUX TANK FUEL SCAVENGE SYSTEM
28-011	28-22-00-5D	28-011-51		OPERATIONAL	CTR AUX TANK SCAVENGE SHUTOFF VALVE
28-012	28-22-00-5E	28-012-01		OPERATIONAL	ENG FUEL SPAR SHUTOFF VALVE BATTERY
28-013	28-31-00-5A	28-013-01		OPERATIONAL	FUEL JETTISON SYSTEM
28-014	28-22-16-4A	28-014-01		RESTORE	ENG FUEL SPAR SHUTOFF VALVE BATTERY
28-015	28-31-00-5A	28-015-01		OPERATIONAL	FUEL JETTISON SYSTEM - LOW CAPACITY
28-016	28-31-00-5A	28-016-01		OPERATIONAL	FUEL JETTISON SYSTEM - FULL CAPACITY
28-018	28-11-04-6A	28-018-03		FUNCTIONAL	OVERWING FILL PORT - L/H WING
28-018	28-11-04-6A	28-018-04		FUNCTIONAL	OVERWING FILL PORT - R/H WING
28-018	28-22-00-5G	28-018-02		OPERATIONAL	ENGINE FUEL SUCTION FEED SYSTEM
28-020	28-00-00-2A	28-020-02		CHECK/INSP	IN-TANK TUBING - LEFT MAIN FUEL TANK
28-020	28-00-00-2B	28-020-03		CHECK/INSP	IN-TANK TUBING - RT MAIN FUEL TANK
28-020	28-00-00-2C	28-020-04		CHECK/INSP	IN-TANK TUBING - CTR AUX FUEL TANK
28-021	28-13-04-6A	28-021-03		FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE-L
28-021	28-13-04-6A	28-021-04		FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE-R
28-022	28-21-12-6A	28-022-01		FUNCTIONAL	FUELING SHUTOFF VALVES L/H WING
28-022	28-21-12-6A	28-022-02		FUNCTIONAL	FUELING SHUTOFF VALVES R/H WING
28-023	28-21-01-6A	28-023-01		FUNCTIONAL	FUELING ADAPTER L/H WING
28-024	28-21-01-6A	28-024-01		FUNCTIONAL	FUELING ADAPTER R/H WING
28-025	28-22-15-6A	28-025-01		CHECK/INSP	LEFT MAIN TANK FUEL BOOST PUMPS
28-025	28-22-15-6A	28-025-02		CHECK/INSP	RIGHT MAIN TANK FUEL BOOST PUMPS
28-025	28-22-15-6A	28-025-03		CHECK/INSP	OVERRIDE/JETTISON FUEL PUMP WIRING
28-025	28-22-15-6A	28-025-04		CHECK/INSP	OVERRIDE/JETTISON FUEL PUMP WIRING
28-026	28-22-03-6A	28-026-01		FUNCTIONAL	FUEL BOOST PUMP MOTOR HOUSING BOND
28-026	28-22-03-6A	28-026-02		FUNCTIONAL	FUEL BOOST PUMP MOTOR HOUSING BOND
28-026	28-22-05-6A	28-026-03		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-026	28-22-05-6A	28-026-04		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-027	28-22-11-6A	28-027-01		FUNCTIONAL	FUEL SHUTOFF VALVE BOND
28-027	28-22-11-6A	28-027-02		FUNCTIONAL	FUEL SHUTOFF VALVE BOND
28-028	28-22-12-6A	28-028-01		FUNCTIONAL	FUEL CROSSFEED VALVE BOND
28-029	28-25-01-6A	28-029-01		FUNCTIONAL	APU DC FUEL PUMP MOTOR HOUSING BOND
28-030	28-25-02-6A	28-030-01		FUNCTIONAL	APU FUEL SHUTOFF VALVE BOND
28-031	28-25-04-6A	28-031-01		FUNCTIONAL	APU FUEL ISOLATION VALVE BOND
28-032	28-26-11-6A	28-032-01		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
28-032	28-26-11-6A	28-032-02		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND
28-032	28-26-11-6A	28-032-03		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND
28-033	28-31-05-6A	28-033-01		FUNCTIONAL	JETTISON NOZZLE VALVE BOND
28-033	28-31-05-6A	28-033-02		FUNCTIONAL	JETTISON NOZZLE VALVE BOND
28-034	28-31-04-6A	28-034-01		FUNCTIONAL	JETTISON TRANSFER VALVE BOND
28-034	28-31-04-6A	28-034-02		FUNCTIONAL	JETTISON TRANSFER VALVE BOND
28-035	28-41-09-6A	28-035-01		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-035	28-41-09-6A	28-035-02		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-035	28-41-09-6A	28-035-03		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-035	28-41-09-6A	28-035-04		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-036	28-41-09-6A	28-036-01		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-036	28-41-09-6A	28-036-02		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-036	28-41-09-6A	28-036-03		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-036	28-41-09-6A	28-036-04		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-037	28-41-24-2A	28-037-01		CHECK/INSP	DENSITOMETER HSP CHECK/INSPECTION
28-038	28-41-24-6A	28-038-01		FUNCTIONAL	DENSITOMETER HSP BOND CHECK
29-001	29-11-00-6A		G-29-001-C1-1	CHECK/INSP	SYS L HYD EDP & ACMP PRESS FILTERS
29-001	29-11-00-6A		G-29-001-C1-2	CHECK/INSP	SYS R HYD EDP & ACMP PRESS FILTERS
29-002	29-11-25-4A	29-002-01-1		CLEAN	SYS L HYD RESERVOIR PRESS AIR FILTER
29-002	29-11-25-4A	29-002-01-2		CLEAN	SYS R HYD RESERVOIR PRESS AIR FILTER
29-003	29-11-00-6F	29-003-01		FUNCTIONAL	HYDRAULIC SYSTEMS (INTERNAL LEAKAGE)
29-003	29-11-00-6G	29-003-02		FUNCTIONAL	ELEVATOR AND RUDDER PCA'S
29-004	29-11-00-6B	29-004-01-1	W-29-001-C1-1	CHECK/INSP	SYS L HYD EDP/ACMP CASE DRAIN FILTER
29-004	29-11-00-6B	29-004-01-2	W-29-001-C1-2	CHECK/INSP	SYS R HYD EDP/ACMP CASE DRAIN FILTER
29-005	12-13-05-3A	29-005-01		CHECK/INSP	SYS C HYDRAULIC ADP OIL LEVEL
29-006	29-11-00-6C		G-29-006-C1	CHECK/INSP	SYS C HYD ACMP & ADP PRESS FILTERS
29-007	29-11-26-4A	29-007-01		CLEAN	SYS C HYD RESERVOIR PRESS AIR FILTER
29-008			G-29-003	FUNCTIONAL	COMBINED WITH 29-003
29-009	29-11-00-6D	29-009-01	W-29-005-01	CHECK/INSP	SYS C HYD ACMP/ADP CASE DRAIN FILTER
29-010	29-11-00-5A	29-010-01		OPERATIONAL	ADP SPEED TOPPING SHUTDOWN CIRCUITRY
29-011	29-11-00-6E		G-29-001-C1-1	CHECK/INSP	SYS L HYD RETURN FILTER MODULE
29-011	29-11-00-6E		G-29-001-C1-2	CHECK/INSP	SYS R HYD RETURN FILTER MODULE
29-011	29-11-00-6E		G-29-006-C1	CHECK/INSP	SYS C HYD RETURN FILTER MODULE
29-012	29-11-00-A		P-06-005-01	CHECK/INSP	HYDRAULIC SYSTEM - FLUID LEAKS
29-013	29-11-07-4A	29-013-01		OPERATIONAL	ISOLATED ACMP SUPPLY SHUTOFF VALVE

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
29-013	29-11-08-4A	29-013-02		OPERATIONAL	ISOLATED ACMP PRESSURE SHUTOFF VALVE
29-014	12-21-30-3A		G-12-031-01	LUBRICATE	RAT DEPLOYMENT SYSTEM
29-015	29-21-00-5A	29-015-01	B-29-018-01	OPERATIONAL	AUTO & MANUAL RAT DEPLOYMENT SYSTEMS
29-016			G-29-015	OPERATIONAL	COMBINED WITH 29-015
29-017			G-29-015	OPERATIONAL	COMBINED WITH 29-015
29-018	29-21-11-4A	29-018-01	A-29-015-01	CHECK/INSP	RAT CHECKOUT MODULE FILTERS
29-019			G-29-019	OPERATIONAL	UNASSIGNED
29-020			G-29-020	FUNCTIONAL	UNASSIGNED
29-021	29-22-00-5A	29-021-01		OPERATIONAL	POWER TRANSFER UNIT (PTU) SYSTEM
29-022	29-22-00-5B	29-022-01		FUNCTIONAL	PTU SYSTEM RETURN COMPENSATOR MODULE
29-023	29-22-03-4A	29-023-01		CHECK/INSP	PTU CASE DRAIN FILTER
29-024	27-41-00-5E	29-024-01		FUNCTIONAL	STABILIZER TRIM RATE RELIEF VALVE
29-026	12-13-05-3B	29-026-01		CHECK/INSP	SYS C HYDRAULIC ADP OIL LEVEL
29-027	29-11-31-4A	29-027-02		REPLACE	SYS C HYDRAULIC ADP GEARBOX FILTER
29-028	29-11-28-5A	29-028-01		OPERATIONAL	SYST. C RESERVOIR PRESS. S-O VALVE
30-001	30-11-03-4A	30-001-01-1	W-30-002-01-1	FUNCTIONAL	LEFT WING TAI TEMPERATURE SWITCH
30-001	30-11-03-4A	30-001-01-2	W-30-002-01-2	FUNCTIONAL	RIGHT WING TAI TEMPERATURE SWITCH
30-002	30-11-04-4A	30-002-01-1	W-30-001-01-1	FUNCTIONAL	LEFT WING TAI PRESSURE SWITCH
30-002	30-11-04-4A	30-002-01-2	W-30-001-01-2	FUNCTIONAL	RIGHT WING TAI PRESSURE SWITCH
30-003	30-21-00-5A	30-003-01-1		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-003	30-21-00-5A	30-003-01-2		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-003	30-21-00-5A	30-003-02-1		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-003	30-21-00-5A	30-003-02-2		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-003	30-21-00-5A	30-003-03-1		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-003	30-21-00-5A	30-003-03-2		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-003	30-21-00-5A	30-003-05-1		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-003	30-21-00-5A	30-003-05-2		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-003	30-21-05-4A	30-003-04-1		FUNCTIONAL	ENGINE 1 TAI PNEUMATIC RELIEF VALVE
30-003	30-21-05-4A	30-003-04-2		FUNCTIONAL	ENGINE 2 TAI PNEUMATIC RELIEF VALVE
30-004	30-21-00-A		P-06-077-01	CHECK/INSP	ENGINE INLET TAI DUCTING
30-004	30-21-00-A		P-06-092-01	CHECK/INSP	ENGINE INLET TAI DUCTING
30-004	30-21-00-A		P-06-148-01	CHECK/INSP	ENGINE INLET TAI DUCTING
30-004	30-21-00-A		P-06-160-01	CHECK/INSP	ENGINE INLET TAI DUCTING

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-12



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
30-005	30-31-00-A		G-33-004-C1 G-33-004-C2 G-33-004-C3 G-33-004-C4	OPERATIONAL	PITOT STATIC PROBE HEAT ANNUNCIATOR
31-001	31-31-01-2A		G-31-001-07	OPERATIONAL	FLIGHT DATA RECORDER PARAMETERS
31-002	31-31-02-2B	31-002-02		RESTORE	DIGITAL FLIGHT DATA RECORDER ULB
31-002	31-31-02-2C	31-002-03		OPERATIONAL	FLIGHT DATA RECORDER ULB
31-003	31-51-00-5A		G-33-004-C1 G-33-004-C2 G-33-004-C3 G-33-004-C4	OPERATIONAL	MASTER CAUTION/WARNING LIGHTS
31-004	31-51-04-4A	31-004-01		OPERATIONAL	WARNING ELECTRONICS UNIT CARD MODULE
31-005			G-31-004	OPERATIONAL	COMBINED WITH 31-004
31-006			G-31-004	OPERATIONAL	COMBINED WITH 31-004
31-007	31-41-00-2A	31-007-01		OPERATIONAL	EICAS MAINTENANCE MESSAGES
31-008	31-41-02-4A	31-008-01		OPERATIONAL	RIGHT EICAS COMPUTER
31-050	31-63-00-2A	31-050-01		OPERATIONAL	EICAS MAINTENANCE MESSAGES
32-001	20-20-02-6A 20-20-02-6B 20-20-02-6C 20-20-02-6D 20-20-02-6H		G-32-001	CHECK/INSP	LANDING GEAR CONTROL CABLES
32-002	32-32-03-A		P-06-131-01	CHECK/INSP	MAIN GEAR SIDE BRACE LOCK SPRINGS
32-002	32-32-05-A		P-06-131-01	CHECK/INSP	MAIN GEAR JURY STRUT SPRINGS
32-003	32-21-09-A		P-06-004-01	CHECK/INSP	NOSE GEAR LOCK SPRINGS
32-004	32-31-00-A		P-06-016-01	CHECK/INSP	MAIN/NOSE GEAR MECH CONTROL PATH
32-005	12-21-15-3A		G-12-025-C1 G-12-025-C2 G-12-025-C3 G-12-025-C4	LUBRICATE	MAIN GEAR DOOR UPLOCK ROLLER BEARING
32-006	12-21-15-3B		G-12-025-C1 G-12-025-C2 G-12-025-C3 G-12-025-C4	LUBRICATE	DOOR LATCH HOOK BEARING
32-007	12-21-14-3I		G-12-024-01	LUBRICATE	MAIN GEAR RETRACT ACTUATOR
32-008	32-32-01-A		P-06-120-01	CHECK/INSP	MAIN LANDING GEAR RETRACT ACTUATOR

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
32-009	12-21-14-3C		G-12-022-C1 G-12-022-C2 G-12-022-C3	LUBRICATE	MAIN GEAR SIDE BRACE LOCK ACTUATOR
32-010	32-32-02-A		P-06-131-01	CHECK/INSP	MAIN GEAR SIDE BRACE LOCK ACTUATOR
32-011	12-21-14-3D		G-12-022-C1 G-12-022-C2 G-12-022-C3	LUBRICATE	MAIN GEAR DRAG BRACE LOCK ACTUATOR
32-012	32-32-02-B		P-06-131-01	CHECK/INSP	MAIN GEAR DRAG BRACE LOCK ACTUATOR
32-013	12-21-15-3A		G-12-025-C1 G-12-025-C2 G-12-025-C3 G-12-025-C4	LUBRICATE	MAIN GEAR DOOR ACTUATOR & LINKAGE
32-014	32-12-01-A		P-06-016-01	CHECK/INSP	MAIN LANDING GEAR DOOR AND HINGES
32-014	32-32-06-A		P-06-016-01	CHECK/INSP	MLG-DOOR OPERATED SEQUENCE VALVE
32-014	32-32-09-A		P-06-016-01	CHECK/INSP	MLG-GEAR OPERATED SEQUENCE VALVE
32-014	32-32-12-A		P-06-016-01	CHECK/INSP	MAIN GEAR DOOR ACTUATOR & LINKAGE
32-014	32-32-13-B		P-06-016-01	CHECK/INSP	MAIN GEAR DOOR LATCH ACTUATOR
32-014	32-32-14-A		P-06-016-01	CHECK/INSP	MAIN GEAR DOOR UPLOCK MECHANISM
32-014	32-35-01-A		P-06-016-01	CHECK/INSP	ALTERNATE EXTEND SYS FLUID SUPPLY
32-015	32-32-13-A		P-06-016-01	CHECK/INSP	MAIN LANDING GEAR DOOR LATCH SPRINGS
32-016	12-21-14-3M		G-12-024-C1 G-12-024-C2	LUBRICATE	MAIN GEAR TRUCK POSITIONER
32-017	32-32-18-A		P-06-131-01	CHECK/INSP	MAIN GEAR TRUCK POSITIONER
32-018	12-21-12-3B		G-12-017-C1	LUBRICATE	NOSE GEAR RETRACT ACTUATOR
32-019	32-34-01-A		P-06-004-01	CHECK/INSP	NOSE GEAR RETRACT ACTUATOR
32-020	32-22-02-A		P-06-004-01	CHECK/INSP	NOSE GEAR DOOR OPERATING MECHANISM
32-021	32-35-00-5A	32-021-01		OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-022			G-32-021	OPERATIONAL	COMBINED WITH 32-021
32-023	32-41-00-A		P-06-016-01	CHECK/INSP	HYD BRAKE MECHANICAL CONTROL PATH
32-024	32-41-08-6A	32-024-01-1		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-024	32-41-08-6A	32-024-01-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-025	32-41-00-5A	32-025-01		OPERATIONAL	ALTERNATE BRAKE SYSTEM/SELECTOR VALV
32-026	32-41-00-2A	32-026-01		OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-027	32-44-00-A		P-06-016-01	CHECK/INSP	PARKING BRAKE MECH CONTROL PATH
32-028	12-15-04-3A	32-028-01		SERVICE	PARKING BRAKE ACCUMULATOR
32-029	12-15-03-3B	32-029-04	W-32-029-01	SERVICE	TIRE PRESSURE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-14



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
32-029	32-45-04-6A	32-029-01	W-32-030-01	CHECK/INSP	MAIN & NOSE GEAR TIRES
32-030	32-45-03-6A	32-030-01	W-32-029-01	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-031	12-21-12-3H		G-12-018-C1	LUBRICATE	N WHEEL STEERING MECH CONTROL PATH
32-032	32-51-00-A		P-06-004-01	CHECK/INSP	N WHEEL STEERING MECH CONTROL PATH
32-033	32-51-02-A		P-06-004-01	CHECK/INSP	RUDDER PEDAL NOSE WHEEL STEERING
32-034	12-21-12-3K		G-12-020-C1	LUBRICATE	NOSE WHEEL STEERING ACTUATOR
32-035	32-51-02-B	32-035-01		CHECK/INSP	CENTERING & RUDDER INTERCONNECT MECH
32-036			G-32-036	OPERATIONAL	ITEM DELETED
32-037			G-32-037	FUNCTIONAL	ITEM DELETED
32-038	32-41-05-4A	32-038-01		OPERATIONAL	ACCUMULATOR ISOLATION VALVE
32-039	12-21-16-3A		G-12-040-01	LUBRICATE	TAIL SKID LEVER MECHANISM
32-040	12-15-05-3A	32-040-51		CHECK/INSP	TAIL SKID POP-UP INDICATOR
32-041	32-61-00-5B	32-041-51		OPERATIONAL	TAIL SKID WARNING SYSTEM
32-042	32-61-00-5A	32-042-51		OPERATIONAL	TAIL SKID WARNING PSEU BITE TEST
32-043	32-21-01-A	32-043-01		RESTORE	NOSE LANDING GEAR
32-044	32-11-01-A	32-044-51		RESTORE	MAIN LANDING GEAR (LEFT OR RIGHT)
32-044	32-21-01-4A	32-044-01		REPLACE	NOSE LANDING GEAR
32-045	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3G 12-21-14-3H 12-21-14-3I 12-21-14-3L 12-21-14-3M 12-21-14-3P 12-21-14-3S 12-21-14-3T		G-12-022-C3 G-12-022-C4 G-12-023-C3 G-12-023-C4 G-12-024-C3 G-12-024-C4	LUBRICATE	MAIN LANDING GEAR ASSEMBLY
32-046	12-15-01-3B	32-046-51-1		SERVICE	MAIN GEAR SHOCK STRUT
32-046	12-15-01-3B	32-046-51-2		SERVICE	MAIN GEAR SHOCK STRUT
32-047	32-31-00-5A	32-047-52		OPERATIONAL	LANDING GEAR CONTROL ELEC CIRCUITS
32-048	32-35-00-5A	32-048-52		OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-049	32-35-00-5B	32-049-52		OPERATIONAL	DOWN LOCK SPRINGS AND RELEASE HOOKS
32-050	32-44-00-5A	32-050-01		FUNCTIONAL	PARKING BRAKE SYSTEM TEST

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
32-051	32-41-08-6A	32-051-02-1		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-051	32-41-08-6A	32-051-02-2		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-052	32-71-08-6A	32-052-01		CHECK/INSP	TAIL SKID POP-UP INDICATOR
32-053	12-21-15-3A		G-12-025-C3 G-12-025-C4	LUBRICATE	MAIN LANDING GEAR DOOR AND HINGES
33-001	33-51-00-5A	33-001-01	W-33-001-02	OPERATIONAL	EMERGENCY LIGHTS
33-002	33-51-02-2A	33-002-01		FUNCTIONAL	SELF-ILLUMINATED EXIT SIGNS
33-003	33-51-07-2A	33-003-01	W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-003	33-51-07-2B	33-003-09		FUNCTIONAL	EMERGENCY LIGHT POWER SUPPLIES
33-003	33-51-07-2C	33-003-10		OPERATIONAL	EXIT MARKER DIODES
33-003	33-51-07-2D	33-003-11	W-33-003-06	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-008	33-35-00-2A	33-008-01		OPERATIONAL	CREW WARNING CARGO LIGHTS
34-001	34-11-00-3A		G-34-001-C1	DRAIN	PITOT-STATIC SYSTEM
34-002	34-11-00-3B		G-34-001-C1	DRAIN	ALTERNATE STATIC SYSTEM
34-003	34-11-00-3C		G-34-001-C1	DRAIN	AUXILIARY PITOT SYSTEM
34-004	34-11-00-5A	34-004-01	A-34-001-C1	FUNCTIONAL	ALTERNATE STATIC LINE LEAK CHECK
34-005	34-13-00-5A		G-34-005-C1	FUNCTIONAL	STANDBY ALTIMETER
34-006	34-13-00-5B		G-34-005-C1	FUNCTIONAL	STANDBY AIRSPEED INDICATOR
34-007	34-11-00-5B	34-007-01	A-34-001-C1	FUNCTIONAL	STBY AIRSPEED INDICATOR AUX PITOT
34-008	34-16-00-5A		G-33-004-C1 G-33-004-C2	OPERATIONAL	ALT ALERT INDICATOR ANNUNCIATOR
34-009	34-22-00-5A	34-009-01	A-34-010-01	OPERATIONAL	INSTRUMENT SOURCE SELECT SWITCHING
34-010	34-22-00-5B	34-010-01	B-34-009-01	OPERATIONAL	CENTER EFIS SYMBOL GENERATOR
34-011	34-46-00-5A		G-34-011-05	OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-012	34-53-00-5A	34-012-01		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-013	34-12-00-6A	34-013-51		OPERATIONAL	AIR DATA COMPUTER
34-014			G-34-014	FUNCTIONAL	UNASSIGNED
34-014	34-26-00-5A	34-014-02		OPERATIONAL	ADIRU COMPUTERS
34-015			G-34-015	FUNCTIONAL	UNASSIGNED
34-015	34-24-03-5A	34-015-01		CHECK/INSP	INTEGRATED STANDBY FLIGHT DISPLAY
34-016			G-34-016	FUNCTIONAL	UNASSIGNED
34-016	34-24-04-4A	34-016-03		REPLACE	INTEGRATED STANDBY FLIGHT DISPLAY
34-017			G-34-017	FUNCTIONAL	UNASSIGNED
34-018			G-34-018	FUNCTIONAL	UNASSIGNED
35-001	35-11-00-A		G-35-001-C1	CHECK/INSP	CREW OXYGEN SYSTEM PRESSURE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-16



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
35-002	35-11-00-5A		G-35-001-C1	CHECK/INSP	CREW OXYGEN PRESS TRANSDUCER/INDCATR
35-003	35-11-00-5B	35-003-01		OPERATIONAL	CREW OXYGEN LOW PRESSURE LINE
35-004	35-21-00-5A		G-35-004-C1	FUNCTIONAL	ALTITUDE PRESSURE SWITCH - PASS OXY
35-005	35-21-00-5B		G-35-004-C1	OPERATIONAL	PASS OXY DOOR LATCHES-MANUAL SWITCH
35-006	35-00-00-6A	35-006-01		CHECK/INSP	PASSENGER CHEMICAL OXYGEN GENERATORS
35-007	35-21-04-4A	35-007-01		REPLACE	PASSENGER CHEMICAL OXYGEN GENERATORS
35-008	35-31-01-6C	35-008-01		CHECK/INSP	PORTABLE OXYGEN BOTTLES
35-009	35-00-00-6B	35-009-01		CHECK/INSP	PORTABLE CHEMICAL OXYGEN GENERATORS
35-010	35-31-00-A	35-010-01		REPLACE	PORTABLE CHEMICAL OXYGEN GENERATORS
35-012	35-21-05-6A	35-012-01	B-35-004-C1	CHECK/INSP	PASSENGER OXYGEN MASKS
35-013	35-11-00-5C	35-013-01		OPERATIONAL	CREW OXYGEN MASK/REGULATOR
35-014	35-11-00-B	35-014-01		FUNCTIONAL	CREW OXYGEN MASK/REGULATOR
36-001	36-11-01-6A		P-06-073-01	CHECK/INSP	FAN AIR INLET DUCTING - ENGINE
36-001	36-11-01-6A		P-06-088-01	CHECK/INSP	FAN AIR INLET DUCTING - ENGINE
36-001	36-11-01-6A		P-06-144-01	CHECK/INSP	ENGINE FAN AIR INLET DUCTING
36-002	36-11-00-5A	36-002-01		FUNCTIONAL	AIR SUPPLY DISTRIBUTION
36-003	36-11-00-5B	36-003-01		OPERATIONAL	CENTER ISOLATION VALVE
36-004	36-11-05-6A	36-004-01		CHECK/INSP	ISOLATION BYPASS CHECK VALVES
36-005	36-11-06-6A	36-005-01-1		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-005	36-11-06-6A	36-005-01-2		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-005	36-11-06-6A	36-005-02-1		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-005	36-11-06-6A	36-005-02-2		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-006	36-11-07-A		P-06-069-01	CHECK/INSP	H.P. SHUTOFF VALVE SENSE LINE
36-006	36-11-07-A		P-06-084-01	CHECK/INSP	H.P. SHUTOFF VALVE SENSE LINE
36-006	36-11-07-A		P-06-145-01	CHECK/INSP	HP SHUTOFF VALVE SENSE LINE
36-007	36-11-11-6A	36-007-01		CHECK/INSP	APU AIR SUPPLY CHECK VALVE
36-008	36-11-16-5A	36-008-01		OPERATIONAL	AIR SUPPLY BITE MODULE
36-009	36-22-00-5A	36-009-01-1		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-009	36-22-00-5B	36-009-01-2		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-010	36-11-18-A		P-06-084-01	CHECK/INSP	PRESSURE REGULATING VALVE SENSE LINE
36-011	36-11-01-6C	36-011-05-1		CHECK/INSP	ENG 1 INTERMEDIATE PRESSURE DUCT
36-011	36-11-01-6C	36-011-05-2		CHECK/INSP	ENG 2 INTERMEDIATE PRESSURE DUCT
36-011	36-11-06-6B	36-011-62-1		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-011	36-11-06-6B	36-011-62-2		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-018	36-23-00-5A	36-018-2		OPERATIONAL	AIR SUPPLY ASCTU BITE DISPLAY

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
38-001	38-10-00-2A	38-001-01		DISINFECT	POTABLE WATER SYSTEM
38-001	38-10-60-2A	38-001-04	W-38-001-03	DISINFECT	POTABLE WATER SYSTEM
38-002	38-15-02-4A 38-15-02-4B	38-002-C1		REPLACE	POTABLE WATER SYSTEM AIR FILTERS
38-002	38-15-02-4A		G-38-002-C1	REPLACE	WTR TANK COMPRESSOR AIR INLET FILTER
38-003	38-15-02-4B		G-38-002-C1	REPLACE	POT WTR ENG BLEED AIR INLINE FILTERS
38-004	38-32-00-5A	38-004-01		OPERATIONAL	VACUUM WATER BREAKS
38-005	38-33-00-5B	38-005-02		OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-005	38-33-00-5C	38-005-01		OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-006	38-32-60-5A	38-006-51		OPERATIONAL	SERVICE PANEL WASTE DRAIN FTG SEAL
38-007	38-32-00-A		P-06-007-01	CHECK/INSP	RINSE/DRAIN LINES AND WASTE TANK
38-008	38-10-60-A	38-008-51	W-38-001-04	CHECK/INSP	POTABLE WATER TANK AND SUPPLY LINE
49-001	49-15-03-6A		P-06-049-01	CHECK/INSP	APU INTAKE PLENUM MOUNT ATTACH POINT
49-002	49-13-00-6B		P-06-049-01	CHECK/INSP	APU VIBRATION ISOLATOR MOUNTS
49-003	49-13-00-6C		P-06-049-01	CHECK/INSP	APU MOUNT TUBULAR SUPPORTS
49-004	49-13-00-6D		P-06-049-01	CHECK/INSP	APU FWD MOUNT BRACKETS
49-005	49-13-00-6E		P-06-049-01	CHECK/INSP	APU MOUNT CONE BOLT NUTS
49-006	49-15-05-6A		P-06-048-01	CHECK/INSP	APU AIR INTAKE DOOR TO ACTUATOR
49-007	49-15-05-6B		P-06-048-01	CHECK/INSP	APU AIR INTAKE DOOR HINGE
49-008	49-15-01-4B	49-008-01		CHECK/INSP	APU AIR INTAKE DUCT - INTERNAL
49-009	49-15-01-4A		P-06-049-01	CHECK/INSP	APU AIR INTAKE DUCT & DUCT JOINTS
49-010	49-15-03-6B		P-06-049-01	CHECK/INSP	APU AIR INTAKE PLENUM - EXTERNAL
49-011	49-15-03-6C		P-06-049-01	CHECK/INSP	APU AIR INTAKE PLENUM - INTERNAL
49-012	49-16-00-6B		P-06-049-01	CHECK/INSP	APU DRAIN LINES, CONNECTIONS & MAST
49-013	49-16-00-A	49-013-01		CHECK/INSP	APU DRAIN MAST
49-014	49-27-04-6A		G-49-014-C1	CHECK/INSP	APU GEARBOX MAGNETIC CHIP DETECTOR
49-015	49-21-00-6A		P-06-049-01	CHECK/INSP	APU GEARBOX
49-016	49-21-00-6B		P-06-049-01	CHECK/INSP	APU GEARCASE MOUNTS
49-017	49-21-00-6C		P-06-049-01	CHECK/INSP	APU EXHAUST CASE EXTERIOR
49-018	49-13-00-6A		P-06-049-01	CHECK/INSP	APU AFT MOUNT BRACKETS
49-019	49-21-00-A	49-019-01		REPLACE	APU TURBINE DISKS
49-020	49-21-00-6D		P-06-049-01	CHECK/INSP	APU INSULATION BLANKET/HEAT SHIELD
49-021	12-13-04-3A	49-021-01		SERVICE	APU OIL LEVEL
49-022	49-27-03-6B		G-49-024-C1	CHECK/INSP	OIL PRESS FILTER DIFF PRESS INDICATR
49-023	49-27-03-4A		G-49-023-C1	REPLACE	APU OIL PRESSURE FILTER ELEMENT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-18



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
49-024	49-27-03-6A		G-49-024-C1	CHECK/INSP	SCAVENGE FILTER DIFF PRESS INDICATOR
49-025	49-27-03-4B		G-49-023-C1	REPLACE	APU GENERATOR SCAVENGE FILTER
49-026	49-21-00-6G		P-06-049-01	CHECK/INSP	APU COMPARTMENT PLUMBING/COMPONENTS
49-027	49-21-00-6F		P-06-049-01	CHECK/INSP	LABYRINTH SEAL PNEUMATIC PLUMBING
49-028	49-27-00-A	49-028-01		FUNCTIONAL	GEARBOX SHUTOFF VALVE
49-029	49-27-00-B	49-029-01		FUNCTIONAL	GEARBOX PRESSURE REGULATING VALVE
49-030	49-21-00-6E		P-06-049-01	CHECK/INSP	GEARBOX PRESSURIZATION PLUMBING
49-031	49-14-00-6F		P-06-049-01	CHECK/INSP	FUEL CTRL/FLOW DIVIDER ELECT HARNESS
49-032	49-31-00-A	49-032-01		CHECK/INSP	APU LP FUEL FILTER DIFF PRESS IND
49-033	49-21-00-6H		P-06-049-01	CHECK/INSP	APU FUEL SYSTEM PLUMBING/COMPONENTS
49-034	49-14-00-6G		P-06-049-01	CHECK/INSP	IGNITION UNIT ELECTRICAL HARNESS
49-035	49-21-00-6I		P-06-049-01	CHECK/INSP	COOLING FAN ISOLATION VALVE PLUMBING
49-036	49-51-00-A		P-06-049-01	CHECK/INSP	APU COOLING FAN DUCTING
49-037	49-14-00-6H		P-06-049-01	CHECK/INSP	COOLING FAN ISOLATION VALVE SWITCH
49-038	49-51-01-A		P-06-049-01	CHECK/INSP	OIL COOLING AIR EXHAUST DUCT
49-039	49-14-00-6A		P-06-049-01	CHECK/INSP	APU IGV ACTUATOR ELECTRICAL HARNESS
49-040	49-21-00-6J		P-06-049-01	CHECK/INSP	APU IGV ACTUATOR AND PLUMBING
49-041	49-21-00-6K		P-06-049-01	CHECK/INSP	APU SURGE VALVE PLUMBING
49-042	49-21-00-6L		P-06-049-01	CHECK/INSP	APU TOTAL PRESSURE SENSOR/PLUMBING
49-043	49-14-00-6I		P-06-049-01	CHECK/INSP	APU TOTAL PRESSURE TRANSDUCER
49-044	49-14-00-6B		P-06-049-01	CHECK/INSP	SURGE VALVE ELECTRICAL HARNESS
49-045	49-14-00-6C		P-06-049-01	CHECK/INSP	DIFFERENTIAL PRESS TRANSDUCER WIRING
49-046	49-21-00-6M		P-06-049-01	CHECK/INSP	VARIABLE VOLUME VALVE CHAMBER
49-047	49-14-00-6D		P-06-049-01	CHECK/INSP	COMPRESSOR INLET TEMPERATURE SENSOR
49-048	49-14-00-6K		P-06-049-01	CHECK/INSP	APU INLET PRESSURE SENSOR
49-049	49-61-05-2A	49-049-01		OPERATIONAL	APU CONTROL UNIT (ECU)
49-050	49-14-00-6J		P-06-049-01	CHECK/INSP	APU OIL TEMPERATURE SENSOR
49-051	49-27-00-C	49-051-01		FUNCTIONAL	GENERATOR OIL FLTR DIFF PRESS SWITCH
49-052	49-14-00-6L		P-06-049-01	CHECK/INSP	APU EGT THERMOCOUPLE HARNESS
49-053	49-81-01-2E		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT V-BAND CLAMP
49-054	49-81-01-2D		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT V-BAND CLAMP
49-055	49-81-01-2A		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT
49-056	49-81-01-2B		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT INTERIOR & SUPPORT
49-057	49-81-01-2C		P-06-049-01	CHECK/INSP	APU EXHAUST DUCT INSULATION BLANKET
49-058	49-14-00-6E		P-06-049-01	CHECK/INSP	APU LOW OIL LEVEL SWITCH WIRING

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
49-059	49-27-04-6B		G-49-014-C1	CHECK/INSP	APU MAGNETIC CHIP DETECTORS
49-060	49-16-02-7A	49-060-51		FUNCTIONAL	COMBUSTOR DRAIN VALVE
49-061	49-11-01-A	49-061-51		SPCL DETAIL	CONTAINMENT SYSTEM (POWER SECTION)
49-062	49-21-00-B	49-062-51		REPLACE	1ST & 2ND STAGE COMPRESSOR IMPELLER
49-063	49-11-01-B	49-063-51		SPCL DETAIL	CONTAINMENT SYSTEM (LOAD COMPRESSOR)
49-064	49-21-00-C	49-064-51		REPLACE	APU LOAD COMPRESSOR IMPELLER
52-001	52-11-00-5A	52-001-01		OPERATIONAL	ENTRY/SERVICE DOOR UPLATCH MECHANISM
52-001	52-11-00-5A	52-001-02		OPERATIONAL	ENTRY/SERVICE DOOR UPLATCH MECHANISM
52-002	52-11-25-A	52-002-01		CHECK/INSP	ENTRY/SERVICE DOOR HANDLE MECHANISM
52-002	52-11-25-A	52-002-02		CHECK/INSP	ENTRY/SERVICE DOOR HANDLE MECHANISM
52-003	52-11-34-A		P-06-039-01	CHECK/INSP	CEILING PANEL LATCH MECHANISM
52-003	52-11-34-A		P-06-039-01	CHECK/INSP	CEILING PANEL LATCH MECHANISM
52-004	52-11-16-A		P-06-039-01	CHECK/INSP	ENTRY/SERVICE DOOR COUNTERBALANCE
52-005	52-11-16-B		P-06-039-01	CHECK/INSP	COUNTERBALANCE CABLES/PULLEYS
52-006	52-11-21-2A	52-006-01		CHECK/INSP	COUNTERBALANCE LOAD LIMITER
52-006	52-11-21-2A	52-006-02		CHECK/INSP	COUNTERBALANCE LOAD LIMITER
52-007	12-21-18-3A		G-12-026-01	LUBRICATE	ENTRY/SERVICE DOOR ROLLER PIN
52-008	52-11-06-A		P-06-038-01	CHECK/INSP	ENTRY/SERVICE DOOR TRACK SYSTEM
52-009	52-11-33-A	52-009-01		CHECK/INSP	ENTRY/SERVICE DOOR LATCH MECHANISM
52-009	52-11-33-A	52-009-02		CHECK/INSP	ENTRY/SERVICE DOOR LATCH MECHANISM
52-010	52-11-31-A	52-010-01		CHECK/INSP	ENTRY DOOR SPRING HYDRAULIC SNUBBER
52-010	52-11-31-A	52-010-02		CHECK/INSP	ENTRY DOOR SPRING HYDRAULIC SNUBBER
52-011	52-11-00-6A		P-06-038-01	CHECK/INSP	ENTRY DOOR LATCH PIN MECHANISM
52-012	52-09-01-2A		P-06-138-01	CHECK/INSP	FWD/AFT ENTRY/SERVICE DOOR SEALS
52-012	52-09-01-2A		P-06-138-01	CHECK/INSP	MID-CABIN ENTRY/SERVICE DOOR SEALS
52-013	12-21-20-3A		G-12-027-C3	LUBRICATE	OVERWING ESCAPE HATCH MECHANISM
52-014	52-21-01-2A	52-014-01		OPERATIONAL	OVERWING ESCAPE HATCHES
52-015	52-34-04-A		P-06-008-01	CHECK/INSP	FWD/AFT CARGO DOOR HINGE MECHANISM
52-016	52-34-02-A		P-06-009-01	CHECK/INSP	FWD/AFT CARGO DOOR HINGE POWER UNIT
52-017	12-21-22-3A		G-12-028-C1	LUBRICATE	STD FWD/AFT CARGO DOOR LATCH ROLLERS
52-018	52-34-12-A		P-06-135-01	CHECK/INSP	CARGO DOOR LIFT/LATCH MECHANISM
52-019	52-34-10-A		P-06-135	CHECK/INSP	CARGO DOOR LIFT/LATCH POWER UNIT
52-020	52-34-03-A		P-06-135-01	CHECK/INSP	CARGO DOOR HINGE ROTARY ACTUATOR
52-021	52-34-12-B		P-06-135-01	CHECK/INSP	FWD/AFT CARGO DOOR LATCH BUNGEE

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
52-022	52-09-02-4B		P-06-134-01 P-06-136-01	CHECK/INSP	FWD/AFT CARGO DOOR SEALS
52-023	52-36-05-A		P-06-132-01	CHECK/INSP	BULK CARGO DOOR MECHANISM
52-024	52-36-02-A		P-06-027-01	CHECK/INSP	BULK CARGO DOOR BALANCE MECHANISM
52-025	52-09-02-4A		P-06-133-01	CHECK/INSP	BULK CARGO DOOR SEALS
52-027	52-35-00-5A	52-027-02		OPERATIONAL	AFT CARGO DOOR OPERATING MECHANISM
52-028			G-52-028	CHECK/INSP	UNASSIGNED
52-030	52-34-23-A		P-06-009-01	CHECK/INSP	LARGE CARGO DOOR LIFT PWR DRIVE UNIT
52-031	52-34-27-A		P-06-135-02	CHECK/INSP	LARGE CARGO DOOR ROTARY ACTUATOR
52-032	52-34-28-A		P-06-135-02	CHECK/INSP	LARGE CARGO DOOR LIFT DRIVE MECH
52-033	52-34-35-A		P-06-135-02	CHECK/INSP	LARGE CARGO DOOR LATCH/HOOK ACTUATOR
52-034	52-34-36-A		P-06-135-02	CHECK/INSP	LARGE CARGO DOOR LATCH/HOOK MECH
52-035	12-21-21-3A		G-12-043-01	LUBRICATE	EMERGENCY EXIT DOORS
52-036	52-22-01-5A	52-036-01		OPERATIONAL	EMERGENCY EXIT DOOR MECHANISMS
52-037	52-09-06-4A		P-06-173-01-1 P-06-173-01-2	CHECK/INSP	EMERGENCY EXIT DOOR SEALS
52-037	52-09-07-A		P-06-184-01	CHECK/INSP	MAIN DECK CARGO DOOR SEAL
52-041	52-12-25-6A	52-041-01		CHECK/INSP	CREW ENTRY DOOR HANDLE MECHANISM
52-042	52-32-04-A		P-06-185-01	CHECK/INSP	MAIN DECK CARGO DOOR LIFT MECHANISM
52-043	52-32-03-2A	52-043-01		REPLACE	MAIN DECK CARGO DOOR LIFT MECHANISM
52-044	52-32-08-A		P-06-185-01	CHECK/INSP	MAIN DECK CARGO DOOR LATCH/HOOK
52-045	52-32-08-B		P-06-185-01	CHECK/INSP	MAIN DECK CARGO DOOR LATCH LOCK
52-046	52-32-00-A		P-06-185-01	CHECK/INSP	MAIN DECK CARGO DOOR HINGE MECHANISM
52-047	52-32-05-5A		G-52-047-C1	OPERATIONAL	MAIN DECK CARGO DOOR MANUAL DRIVE
52-048	52-32-12-5A	52-048-01		FUNCTIONAL	MAIN DECK CARGO DOOR RATCHET BRAKE
52-049	52-32-05-5C		G-52-047-C1	OPERATIONAL	MAIN DECK CARGO DOOR POWER UNIT
52-050	52-32-05-5B		G-52-047-C1	FUNCTIONAL	MAIN DECK CARGO DOOR LATCH/HOOK
52-051	52-12-00-A		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR CEILING PANEL
52-052	52-12-21-A		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR COUNTERBALANCE
52-053	52-12-10-A		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR TRACK SYSTEM
52-054	52-12-32-A		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR LATCH MECHANISM
52-055	52-12-32-B		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR LATCH SPRING
52-056	52-12-32-C		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR LATCH PIN
52-057	52-71-09-2A	52-057-01		FUNCTIONAL	MAIN DECK CARGO DOOR WARNING SYSTEM
52-058	52-71-02-2A	52-058-01		FUNCTIONAL	LARGE FWD CARGO DOOR WARNING SYSTEM

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
52-059	52-71-03-2A	52-059-01		FUNCTIONAL	LARGE AFT CARGO DOOR WARNING SYSTEM
52-060	52-33-00-5C		G-52-060-C1	OPERATIONAL	LARGE FWD CARGO DOOR MANUAL DRIVE
52-061	52-37-00-5C		G-52-061-C1	OPERATIONAL	LARGE AFT CARGO DOOR MANUAL DRIVE
52-062	52-33-00-5D		G-52-060-C1	OPERATIONAL	LARGE FWD CARGO DOOR POWER UNIT
52-063	52-37-00-5D		G-52-061-C1	OPERATIONAL	LARGE AFT CARGO DOOR POWER UNIT
52-064	52-33-00-5E		G-52-060-C1	FUNCTIONAL	LARGE FWD CARGO DOOR LATCH/HOOK
52-065	52-37-00-5E		G-52-061-C1	FUNCTIONAL	LARGE AFT CARGO DOOR LATCH/HOOK
52-066	52-33-00-5B	52-066-01	W-52-027-01	OPERATIONAL	LARGE FWD CARGO DOOR NO-BACK BRAKES
52-067	52-37-00-5A	52-067-01		OPERATIONAL	LARGE AFT CARGO DOOR NO-BACK BRAKES
52-068	52-33-00-A		P-06-135-01	CHECK/INSP	LARGE FWD CARGO DOOR LATCH LOCK
52-069	52-37-00-A		P-06-137-01	CHECK/INSP	LARGE AFT CARGO DOOR LATCH LOCK
52-070	52-33-00-B		P-06-135-01	CHECK/INSP	LARGE FWD CARGO DOOR HINGE MECHANISM
52-071	52-37-00-B		P-06-137-01	CHECK/INSP	LARGE AFT CARGO DOOR HINGE MECHANISM
52-072	52-33-06-5A	52-072-01		FUNCTIONAL	FWD LG CARGO DOOR LATCH LOCK HANDLE
52-073	52-37-06-5A	52-073-01		FUNCTIONAL	AFT LG CARGO DOOR LATCH LOCK HANDLE
52-074	52-51-00-A		P-06-037-01	CHECK/INSP	FLIGHT DECK SECURITY DOOR
53-001	21-23-05-2B	53-001-01		OPERATIONAL	RETURN AIR GRILLE LOUVERS
56-001	52-11-25-C		P-06-176-01	CHECK/INSP	CREW ENTRY DOOR
56-001	56-11-04-4A	56-001-01		OPERATIONAL	NO. 2 OPENING WINDOW HANDLE
71-101	P71-00-00-6A		P-06-070-01	CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
71-102	P71-00-00-6B		P-06-072-01	CHECK/INSP	FAN COWL/CORE COWL HINGES
71-103	P71-00-00-6C		P-06-072-01	CHECK/INSP	FAN COWL/CORE COWL LATCHES
71-104	P71-00-00-6D		P-06-069-01	CHECK/INSP	INLET COWL FLANGE & FAN CASE FLANGE
71-105	P71-00-00-6E		P-06-069-01	CHECK/INSP	INLET COWL ATTACH BOLTS
71-106	P78-00-00-6A		P-06-073-01	CHECK/INSP	THRUST REVERSER INNER COWL
71-107	P71-00-00-6F		P-06-076-01	CHECK/INSP	INTERNAL SURFACE OF THE CORE COWLS
71-108	P71-00-00-6G		P-06-071-01	CHECK/INSP	COWLING PRESSURE RELIEF DOORS
71-109	P71-00-00-6H	71-109-01-1		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - L
71-109	P71-00-00-6H	71-109-01-2		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - R
71-110	P71-00-00-6I		P-06-069-01	CHECK/INSP	FORWARD MOUNT THRUST LINKS
71-111	P71-00-00-6J		P-06-069-01	CHECK/INSP	FORWARD MOUNT EVENER BAR
71-112	P71-00-00-6K		P-06-069-01	CHECK/INSP	FORWARD MOUNT BOLTS
71-113	P71-00-00-6L		P-06-069-01	CHECK/INSP	FORWARD MOUNT CENTER ATTACHMENT
71-114	P71-00-00-6M		P-06-069-01	CHECK/INSP	FORWARD MOUNT PLATFORM FITTING
71-115	P71-00-00-6N		P-06-069-01	CHECK/INSP	AFT MOUNT STRUT/ENGINE ATTACH BOLTS

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
71-116	P71-00-00-6O		P-06-069-01	CHECK/INSP	AFT MOUNT HANGER
71-117	P71-00-00-6P		P-06-069-01	CHECK/INSP	AFT MOUNT TANGENTIAL/CENTER LINKS
71-118	P71-00-00-6Q		P-06-069-01	CHECK/INSP	DRAIN LINES
71-119	P71-00-00-6R		P-06-069-01	CHECK/INSP	OVERBOARD DRAIN SEAL
71-120	P71-00-00-6S		P-06-069-01	CHECK/INSP	COMBUSTION CHAMBER DRAIN LINE
71-121	P71-00-00-6T	71-121-01-1		CHECK/INSP	STRUT DRAIN INLETS - ENG 1
71-121	P71-00-00-6T	71-121-01-2		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
71-201	G71-00-00-6A		P-06-085-01	CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
71-202	G71-00-00-6B		P-06-087-01	CHECK/INSP	FAN COWL/CORE COWL HINGES
71-203	G71-00-00-6C		P-06-087-01	CHECK/INSP	FAN COWL/CORE COWL LATCHES
71-204	G71-00-00-6D		P-06-084-01	CHECK/INSP	INLET COWL AND FAN CASE FLANGES
71-205	G71-00-00-6E		P-06-084-01	CHECK/INSP	INLET COWL ATTACH BOLTS
71-206	G78-00-00-6A		P-06-088-01	CHECK/INSP	T/R INNER COWL INSULATION AND SEALS
71-207	G71-00-00-6F		P-06-091-01	CHECK/INSP	INTERNAL SURFACE OF THE CORE COWLS
71-208	G71-00-00-6G		P-06-086-01	CHECK/INSP	COWLING PRESSURE RELIEF DOORS
71-209	G71-11-03-4P	71-209-01-1		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - L
71-209	G71-11-03-4P	71-209-01-2		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - R
71-210	G71-00-00-6I		P-06-084-01	CHECK/INSP	AFT MOUNT STRUT/ENGINE ATTACH BOLTS
71-211	G71-00-00-6J		P-06-084-01	CHECK/INSP	AFT MOUNT UPPER FITTING
71-212	G71-00-00-6K		P-06-084-01	CHECK/INSP	AFT MOUNT LOWER FITTING
71-213	G71-00-00-6L		P-06-084-01	CHECK/INSP	AFT MOUNT LINK
71-214	G71-00-00-6M		P-06-084-01	CHECK/INSP	DRAIN LINES
71-215	G71-00-00-6N		P-06-084-01	CHECK/INSP	L.P. RECOUP DRAIN LINES
71-216	G71-00-00-6O		P-06-084-01	CHECK/INSP	COMBUSTION CHAMBER DRAIN LINE
71-217	G71-00-00-6P	71-217-01-1		CHECK/INSP	STRUT DRAIN INLETS - ENG 1
71-217	G71-00-00-6P	71-217-01-2		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
71-218	G71-00-00-6Q		P-06-084-01	CHECK/INSP	FORWARD LOWER ENGINE MOUNT LINKS
71-219	G71-00-00-6R		P-06-084-01	CHECK/INSP	FWD LWR ENG MOUNT CENTER SWAY LINK
71-220	G71-00-00-6S		P-06-084-01	CHECK/INSP	FORWARD LWR ENGINE MOUNT SIDE LINKS
71-221	G71-00-00-6T		P-06-084-01	CHECK/INSP	FWD LWR ENGINE MOUNT ATTACH BOLTS
71-222	G71-00-00-6U		P-06-084-01	CHECK/INSP	FWD ENG MOUNT FAN FRAME STRUT LUGS
71-301	H71-00-00-6A		P-06-085-01	CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
71-302	H71-00-00-6B		P-06-087-01	CHECK/INSP	FAN COWL/CORE COWL HINGES
71-303	H71-00-00-6C		P-06-087-01	CHECK/INSP	FAN COWL/CORE COWL LATCHES
71-304	H71-00-00-6D		P-06-084-01	CHECK/INSP	INLET COWL AND FAN CASE FLANGES

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
71-305	H71-00-00-6E		P-06-084-01	CHECK/INSP	INLET COWL ATTACH BOLTS
71-306	H78-00-00-6A		P-06-088-01	CHECK/INSP	T/R INNER COWL INSULATION AND SEALS
71-307	H71-00-00-6F		P-06-091-01	CHECK/INSP	INTERNAL SURFACE OF THE CORE COWLS
71-308	H71-00-00-6G		P-06-086-01	CHECK/INSP	COWLING PRESSURE RELIEF DOORS
71-309			G-71-309	OPERATIONAL	UNASSIGNED
71-310	H71-00-00-6I		P-06-084-01	CHECK/INSP	AFT MOUNT STRUT/ENGINE ATTACH BOLTS
71-311	H71-00-00-6J		P-06-084-01	CHECK/INSP	AFT MOUNT UPPER FITTING
71-312	H71-00-00-6K		P-06-084-01	CHECK/INSP	AFT MOUNT LOWER FITTING
71-313	H71-00-00-6L		P-06-084-01	CHECK/INSP	AFT MOUNT LINK
71-314	H71-00-00-6M		P-06-084-01	CHECK/INSP	DRAIN LINES
71-315			G-71-315	OPERATIONAL	ITEM DELETED
71-316	H71-00-00-6O		P-06-084-01	CHECK/INSP	COMBUSTION CHAMBER DRAIN LINE
71-317	H71-00-00-6P	71-317-01-1		CHECK/INSP	STRUT DRAIN INLETS - ENG 1
71-317	H71-00-00-6P	71-317-01-2		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
71-318	H71-00-00-6Q		P-06-084-01	CHECK/INSP	FORWARD LOWER ENGINE MOUNT LINKS
71-319			G-71-319	OPERATIONAL	UNASSIGNED
71-320	H71-00-00-6S		P-06-084-01	CHECK/INSP	FORWARD LWR ENGINE MOUNT SIDE LINKS
71-321			G-71-321	OPERATIONAL	UNASSIGNED
71-322	H71-00-00-6U		P-06-084-01	CHECK/INSP	FWD ENG MOUNT FAN FRAME STRUT LUGS
71-323	H71-21-01-A	71-323-51		DISCARD	FWD ENG MNT THRUST LINKS AND BOLTS
71-401	N71-11-01-A	71-401-01-1		CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
71-401	N71-11-01-A	71-401-01-2		CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
71-402	N71-00-00-H		P-06-146-01	CHECK/INSP	FAN COWL/CORE COWL HINGES
71-403	N71-00-00-B		P-06-146-01	CHECK/INSP	FAN COWL/CORE COWL LATCHES
71-404	N71-00-00-C		P-06-145-01	CHECK/INSP	INLET COWL FLANGE & FAN CASE FLANGE
71-405	N71-00-00-D		P-06-145-01	CHECK/INSP	INLET COWL ATTACH BOLTS
71-406	N71-00-00-E	71-406-01-1	W-06-147-01-1	CHECK/INSP	EXTERNAL SURFACE OF THE CORE COWLS
71-406	N71-00-00-E	71-406-01-2	W-06-147-01-2	CHECK/INSP	EXTERNAL SURFACE OF THE CORE COWLS
71-407	N71-00-00-F		P-06-149-01	CHECK/INSP	INTERNAL SURFACE OF THE CORE COWLS
71-408	N71-00-00-G	71-408-01-1	W-06-149-01	CHECK/INSP	CORE COWL PRESSURE RELIEF DOORS
71-408	N71-00-00-G	71-408-01-2	W-06-149-01	CHECK/INSP	CORE COWL PRESSURE RELIEF DOORS
71-409	N71-11-00-A	71-409-01-1		CHECK/INSP	LEFT INLET COWL ACOUSTIC PANELS
71-409	N71-11-00-A	71-409-01-2		CHECK/INSP	RIGHT INLET COWL ACOUSTIC PANELS
71-410	N71-21-00-A	71-410-01-1	W-06-145-01	CHECK/INSP	ENG 1 FORWARD ENG MOUNT COMPONENTS
71-410	N71-21-00-A	71-410-01-2	W-06-145-01	CHECK/INSP	ENG 2 FORWARD ENG MOUNT COMPONENTS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-24



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
71-411			G-71-411	OPERATIONAL	UNASSIGNED
71-412	N71-71-00-6A	71-412-01-1		CHECK/INSP	ENGINE 1 ENGINE DRAIN SYSTEM
71-412	N71-71-00-6A	71-412-01-2		CHECK/INSP	ENGINE 2 ENGINE DRAIN SYSTEM
71-413	N71-71-00-A	71-413-01		OPERATIONAL	ENGINE DRAIN LINES
71-414			G-71-414	OPERATIONAL	UNASSIGNED
71-415			G-71-415	OPERATIONAL	UNASSIGNED
71-416	N71-21-00-B	71-416-01-1	W-06-145-01	CHECK/INSP	ENGINE 1 AFT ENGINE MOUNT COMPONENTS
71-416	N71-21-00-B	71-416-01-2	W-06-145-01	CHECK/INSP	ENGINE 2 AFT ENGINE MOUNT COMPONENTS
71-417			G-71-417	OPERATIONAL	UNASSIGNED
71-418	N71-00-00-N		P-06-145-01	CHECK/INSP	ENGINE DRAIN LINES
71-419	N71-00-00-O		P-06-145-01	CHECK/INSP	DRAIN COLLECTOR SEAL
71-420			G-71-420	OPERATIONAL	UNASSIGNED
71-421	N71-00-00-6A	71-421-01-1		CHECK/INSP	STRUT 1 DRAIN INLETS
71-421	N71-00-00-6A	71-421-01-2		CHECK/INSP	STRUT 2 DRAIN INLETS
71-501	D71-21-01-6A		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
71-501	D71-21-01-6A		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
71-502	D71-21-01-6B		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
71-502	D71-21-01-6B		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
71-503	D71-21-02-6A		G-71-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
71-503	D71-21-02-6A		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
71-504	D71-21-02-6B		G-71-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
71-504	D71-21-02-6B		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
71-505	D71-21-01-6C		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
71-505	D71-21-01-6C		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
71-506	D71-21-02-6C		G-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
71-506	D71-21-02-6C		G-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
71-507	D71-21-02-6D		G-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
71-507	D71-21-02-6D		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
71-508	D71-21-01-6D		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
71-508	D71-21-01-6D		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
71-509	D71-21-02-6E		G-71-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT
71-509	D71-21-02-6E		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
71-510	D71-21-01-6E		G-71-501-C1-1	CHECK/INSP	ENGINE 1 FRONT MOUNT
71-510	D71-21-01-6E		G-71-501-C1-2	CHECK/INSP	ENGINE 2 FRONT MOUNT
71-511	D71-21-02-6F		G-71-502-C1-1	CHECK/INSP	ENGINE 1 REAR MOUNT

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
71-511	D71-21-02-6F		G-71-502-C1-2	CHECK/INSP	ENGINE 2 REAR MOUNT
71-512	D71-11-01-A		P-06-157-01	CHECK/INSP	NOSE COWL INTAKE LIP & INNER BARREL
71-513	D71-11-01-B		P-06-157-01	CHECK/INSP	ENGINE NOSE COWL OUTER SKIN
71-514	D71-11-02-A		P-06-157-01	CHECK/INSP	ENGINE HINGED COWL PANELS
71-515	D71-11-02-B		P-06-157-01	CHECK/INSP	ENGINE HINGED COWL PANEL LATCHES
71-516	D71-11-01-C		P-06-157-01	CHECK/INSP	ENGINE NOSE COWL ACOUSTIC PANELS
71-517	D71-00-00-B		P-06-161-01	CHECK/INSP	ENGINE AND ENGINE COMPONENTS
71-518	D71-11-01-D		P-06-161-01	CHECK/INSP	ENGINE NOSE COWL & FAN CASE FLANGES
71-519	D71-31-01-A		P-06-161-01	CHECK/INSP	FIREWALL ASSEMBLY (FORWARD SURFACE)
71-520	D71-71-01-A		P-06-161-01	CHECK/INSP	ENGINE DRAIN PIPES
71-521	D71-71-00-A		P-06-161-01	CHECK/INSP	ENGINE DRAINS TANK
71-522	D71-71-01-B		P-06-161-01	CHECK/INSP	FUEL PUMP & GOVERNOR DRAIN PIPE EXIT
71-523	D71-71-01-C		P-06-161-01	CHECK/INSP	ENGINE FMU OVERBOARD DRAIN PIPE EXIT
71-524	D71-71-01-D		P-06-161-01	CHECK/INSP	DRAINS SUMP O/BOARD DRAIN PIPE EXIT
71-525	D71-71-01-E		P-06-161-01	CHECK/INSP	SCUPPER DRAIN PIPE INLET/OUTLET
71-526	D71-71-00-B		P-06-159-01 P-06-162-01	CHECK/INSP	ENGINE ZONE 2 DRAIN PIPE EXIT
71-527	D71-71-00-C		P-06-159-01 P-06-162-01	CHECK/INSP	ENGINE TURBINE DRAIN OUTLET
71-528	D71-71-01-D		P-06-159-01 P-06-162-01	CHECK/INSP	CORE ENGINE ZONE 4B FAIRING DRAINS
71-529	D71-11-02-C		P-06-163-01	CHECK/INSP	HINGED COWL PANEL HINGES/LATCH STR
71-530	D71-11-02-D		P-06-163-01	CHECK/INSP	HINGED COWL PANEL LATCHES/STRUCTURE
71-531	D71-11-02-E		P-06-163-01	CHECK/INSP	HINGED COWL PANEL AND SEALS
71-532	D71-11-02-F		P-06-163-01	CHECK/INSP	HINGED COWL PANEL PRESS RELIEF DOORS
71-533	D71-11-02-G		P-06-163-01	CHECK/INSP	HINGED COWL PANEL HOLD OPEN RODS
71-534	D71-11-02-H		P-06-163-01	CHECK/INSP	LIGHTNING CONTACTOR STRIPS/BONDING
71-535	D71-71-01-A	71-535-01		OPERATIONAL	ENGINE DRAIN LINES
72-101	P72-31-02-6A		P-06-068-01	CHECK/INSP	FAN ROTOR BLADES
72-102	P72-31-01-2A		P-06-068-01	CHECK/INSP	EXTERNAL PORTION OF INLET CONE
72-103	P72-31-03-A	72-103		REPLACE	FAN DISK
72-104	P72-00-00-C	72-104-02-1		CHECK/INSP	1.5 STAGE COMPRESSOR ROTOR BLADES -L
72-104	P72-00-00-C	72-104-02-2		CHECK/INSP	1.5 STAGE COMPRESSOR ROTOR BLADES -R
72-104	P72-32-02-6A	72-104-01-1		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES -L
72-104	P72-32-02-6A	72-104-01-2		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES -R

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
72-105	P72-32-00-A	72-105		REPLACE	FRONT COMPRESSOR ROTOR DISKS
72-106	P72-33-02-6A		P-06-068-01	CHECK/INSP	FAN CASE RING SEGMENTS (RUBSTRIPS)
72-107	P72-33-03-6A		P-06-069-01	CHECK/INSP	FAN EXIT CASE AND VANES ASSEMBLY
72-107	P72-33-04-6A		P-06-069-01	CHECK/INSP	FAN EXIT REAR CASE ASSEMBLY
72-107	P72-33-05-2A		P-06-069-01	CHECK/INSP	SOUND ABSORBING LINER (FRONT OUTER)
72-107	P72-33-06-2A		P-06-069-01	CHECK/INSP	SOUND ABSORBING LINER (REAR INNER)
72-108	P79-21-03-2A		G-79-113-C1-1	CHECK/INSP	ANGLE GEARBOX CHIP DETECTOR - ENG 1
72-108	P79-21-03-2A		G-79-113-C1-2	CHECK/INSP	ANGLE GEARBOX CHIP DETECTOR - ENG 2
72-109	P72-35-00-A	72-109		REPLACE	REAR COMPRESSOR DRIVE ROTOR DISKS
72-110	P72-00-00-6A		G-72-110-C1-1	BORESCOPE	COMBUSTION LINER, TURBINE GUIDE VANE
72-110	P72-00-00-6A		G-72-110-C1-2	BORESCOPE	COMBUSTION LINER, TURBINE GUIDE VANE
72-111	P79-21-03-2B		G-79-113-C1-1	CHECK/INSP	NO. 3 BEARING MAGNETIC CHIP DETECTOR
72-111	P79-21-03-2B		G-79-113-C1-2	CHECK/INSP	NO. 3 BEARING MAGNETIC CHIP DETECTOR
72-112	P72-00-00-6B		G-72-110-C1-1	BORESCOPE	FIRST STAGE (HP) TURBINE BLADES - L
72-112	P72-00-00-6B		G-72-110-C1-2	BORESCOPE	FIRST STAGE (HP) TURBINE BLADES - R
72-113	P72-51-01-A	72-113		REPLACE	HP TURBINE DISK
72-114	P72-51-01-6A		P-06-068-01	CHECK/INSP	6TH STAGE TURBINE BLADES
72-115	P72-52-00-A	72-115		REPLACE	LP TURBINE DISKS
72-116	P72-53-01-6A		P-06-069-01	CHECK/INSP	TURBINE EXHAUST CASE ATTACH FLANGE
72-117	P79-21-03-2C		G-79-113-C1-1	CHECK/INSP	NO. 4 BEARING MAGNETIC CHIP DETECTOR
72-117	P79-21-03-2C		G-79-113-C1-2	CHECK/INSP	NO. 4 BEARING MAGNETIC CHIP DETECTOR
72-118	P72-53-01-6B		P-06-069-01	CHECK/INSP	TURBINE EXHAUST CASE STRUTS
72-119	P79-21-03-2D		G-79-113-C1-1	CHECK/INSP	FULL FLOW MASTER CHIP DETECTOR ENG 1
72-119	P79-21-03-2D		G-79-113-C1-2	CHECK/INSP	FUEL FLOW MASTER CHIP DETECTOR ENG 2
72-120	P72-61-01-6A		P-06-069-01	CHECK/INSP	MAIN GEARBOX MOUNTS
72-120	P72-62-01-6A		P-06-069-01	CHECK/INSP	ANGLE GEARBOX MOUNTS
72-121	P72-61-01-6B		P-06-069-01	CHECK/INSP	MAIN GEARBOXES
72-121	P72-62-01-6B		P-06-069-01	CHECK/INSP	ANGLE GEARBOXES
72-201	G72-31-02-6A		P-06-083-01	CHECK/INSP	FAN ROTOR BLADES
72-202	G72-31-02-6C	72-202-01-1	W-06-083-01	CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 1
72-202	G72-31-02-6C	72-202-01-2	W-06-083-01	CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 2
72-203	G72-21-00-A	72-203		REPLACE	FAN ROTOR & LP COMPRESSOR SECTION
72-204	G72-33-04-6A		P-06-083-01	CHECK/INSP	FAN & LP COMPRESSOR FLOW PATH
72-205	G79-21-05-2A	72-205-01-1		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 1
72-205	G79-21-05-2A	72-205-01-2		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 2

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
72-206	G72-31-00-A	72-206		REPLACE	HPC DISKS/SPOOLS/SHAFT AND CDP SEAL
72-207	G72-00-00-6A		G-72-207-C1-1	BORESCOPE	BORESCOPE OF COMBUSTOR SECTION ENG 1
72-207	G72-00-00-6A		G-72-207-C1-2	BORESCOPE	BORESCOPE OF COMBUSTOR SECTION ENG 2
72-208	G72-00-00-6B		G-72-207-C1-1	BORESCOPE	STAGE 1 AND 2 HPT BLADES - ENG 1
72-208	G72-00-00-6B		G-72-207-C1-2	BORESCOPE	STAGE 1 AND 2 HPT BLADES - ENG 2
72-209	G72-50-00-A	72-209		REPLACE	H.P. TURBINE DISKS,DIFFUSER,SPACER
72-210	G72-53-01-6A		P-06-084-01	CHECK/INSP	AFT LOWER ENGINE MOUNT LUGS
72-211	G72-52-01-A	72-211		REPLACE	LP TURBINE DISKS/SHAFT
72-212	G78-11-00-6A		P-06-084-01	CHECK/INSP	EXHAUST PLUG/SLEEVE ATTACHMENT
72-213	G72-61-01-6A		P-06-084-01	CHECK/INSP	ACCESSORY GEAR MOUNTS
72-214	G72-61-01-6B		P-06-084-01	CHECK/INSP	ACCESSORY GEARBOX CASE/MOUNT BOSSES
72-301	H72-31-02-6A		P-06-083-01	CHECK/INSP	FAN ROTOR BLADES
72-302	H72-31-02-6C	72-302-01-1		CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 1
72-302	H72-31-02-6C	72-302-01-2		CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 2
72-303	H72-30-00-A	72-303		REPLACE	FAN ROTOR & LP COMPRESSOR SECTION
72-304	H72-32-00-6A		P-06-083-01	CHECK/INSP	FAN & LP COMPRESSOR FLOW PATH
72-305	H79-21-05-2A	72-305-01-1		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 1
72-305	H79-21-05-2A	72-305-01-2		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 2
72-306	H72-30-00-B	72-306		REPLACE	HPC DISKS/SPOOLS/SHAFT AND CDP SEAL
72-307	H72-00-00-6A		G-72-307-C1-1	BORESCOPE	BORESCOPE OF COMBUSTOR SECTION ENG 1
72-307	H72-00-00-6A		G-72-307-C1-2	BORESCOPE	BORESCOPE OF COMBUSTOR SECTION ENG 2
72-308	H72-00-00-6B		G-72-307-C1-1	BORESCOPE	STAGE 1 AND 2 HPT BLADES - ENG 1
72-308	H72-00-00-6B		G-72-307-C1-2	BORESCOPE	STAGE 1 AND 2 HPT BLADES - ENG 2
72-309	H72-50-00-A	72-309		REPLACE	H.P. TURBINE DISKS,DIFFUSER,SPACER
72-310	H72-50-00-6A		P-06-084-01	CHECK/INSP	AFT LOWER ENGINE MOUNT LUGS
72-311	H72-50-00-B	72-311		REPLACE	LP TURBINE DISKS/SHAFT
72-312	H78-11-00-6A		P-06-084-01	CHECK/INSP	EXHAUST PLUG/SLEEVE ATTACHMENT
72-313	H72-60-00-B		P-06-084-01	CHECK/INSP	ACCESSORY GEARBOX MOUNTS
72-314	H72-60-00-C		P-06-084-01	CHECK/INSP	ACCESSORY GEARBOX CASE/MOUNT BOSSES
72-315	H72-60-00-A		P-06-084-01	CHECK/INSP	ACCESSORY GEARBOX CLEVISES AND BOLTS
72-401	N72-31-02-6A	72-401-01-1		CHECK/INSP	ENGINE 1 FAN ROTOR BLADES
72-401	N72-31-02-6A	72-401-01-2		CHECK/INSP	ENGINE 2 FAN ROTOR BLADES
72-402	N72-31-01-6A	72-402-01-1		CHECK/INSP	EXTERNAL PORTION OF INLET CONE
72-402	N72-31-01-6A	72-402-01-2		CHECK/INSP	EXTERNAL PORTION OF INLET CONE
72-403	N72-30-00-A	72-403		REPLACE	FAN HUB

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
72-404	N72-31-04-6A	72-404-01-1		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES
72-404	N72-31-04-6A	72-404-01-2		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES
72-404	N72-31-05-A	72-404-02-1		CHECK/INSP	1.6 STAGE COMPRESSOR ROTOR BLADES
72-404	N72-31-05-A	72-404-02-2		CHECK/INSP	1.6 STAGE COMPRESSOR ROTOR BLADES
72-405	N72-30-00-B	72-405		REPLACE	LOW PRESSURE COMPRESSOR DRUM ROTOR
72-406	N72-33-01-6A	72-406-01-1		CHECK/INSP	FAN CASE RING SEGMENTS (RUBSTRIPS)
72-406	N72-33-01-6A	72-406-01-2		CHECK/INSP	FAN CASE RING SEGMENTS (RUBSTRIPS)
72-407	N72-33-02-A	72-407-02-1		CHECK/INSP	ENGINE 1 FAN EXIT REAR CASE ASSEMBLY
72-407	N72-33-02-A	72-407-02-2		CHECK/INSP	ENGINE 2 FAN EXIT REAR CASE ASSEMBLY
72-407	N72-33-02-6A	72-407-01-1		CHECK/INSP	FAN EXIT CASE AND VANES ASSEMBLY
72-407	N72-33-02-6A	72-407-01-2		CHECK/INSP	FAN EXIT CASE AND VANES ASSEMBLY
72-407	N72-34-03-6A	72-407-03-1		CHECK/INSP	ENGINE 1 FAN EXIT LINER SEGMENTS
72-407	N72-34-03-6A	72-407-03-2		CHECK/INSP	ENGINE 2 FAN EXIT LINER SEGMENTS
72-408	N79-21-10-6A		G-79-411-C1-1	CHECK/INSP	ENGINE 1 ANGLE GEARBOX CHIP DETECTOR
72-408	N79-21-10-6A		G-79-411-C1-2	CHECK/INSP	ENGINE 2 ANGLE GEARBOX CHIP DETECTOR
72-409	N72-30-00-C	72-409		REPLACE	HPC COMPRESSOR COMPONENTS
72-410	N72-00-00-6A		G-72-410-C1-1	BORESCOPE	COMBUSTION LINER AND 1ST STAGE VANES
72-410	N72-00-00-6A		G-72-410-C1-2	BORESCOPE	COMBUSTION LINER AND 1ST STAGE VANES
72-411	N79-21-10-6C		G-79-411-C1-1	CHECK/INSP	NO. 3 BEARING MAGNETIC CHIP DETECTOR
72-411	N79-21-10-6C		G-79-411-C1-2	CHECK/INSP	NO. 3 BEARING MAGNETIC CHIP DETECTOR
72-412	N72-00-00-6B		G-72-410-C1-1	BORESCOPE	STAGE 1 AND 2 HP TURBINE BLADES
72-412	N72-00-00-6B		G-72-410-C1-2	BORESCOPE	STAGE 1 AND 2 HP TURBINE BLADES
72-413	N72-50-00-A	72-413		REPLACE	HP TURBINE ROTATING COMPONENTS
72-414	N72-53-01-6A	72-414-01-1		CHECK/INSP	6TH STAGE TURBINE VANES AND BLADES
72-414	N72-53-01-6A	72-414-01-2		CHECK/INSP	6TH STAGE TURBINE VANES AND BLADES
72-415	N72-50-00-B	72-415		REPLACE	LP TURBINE ROTATING COMPONENTS
72-416			G-72-416	OPERATIONAL	UNASSIGNED
72-417	N79-21-10-6D		G-79-411-C1-1	CHECK/INSP	NO. 4 BEARING MAGNETIC CHIP DETECTOR
72-417	N79-21-10-6D		G-79-413-C1-2	CHECK/INSP	NO. 4 BEARING MAGNETIC CHIP DETECTOR
72-418	N72-50-00-D	72-418-01-1	W-06-145-01	CHECK/INSP	ENGINE 1 TURBINE EXHAUST CASE RAILS
72-418	N72-50-00-D	72-418-01-2	W-06-145-01	CHECK/INSP	ENGINE 2 TURBINE EXHAUST CASE RAILS
72-419	N79-21-10-6E		G-79-411-C1-1	CHECK/INSP	ENG 1 MAIN GEARBOX MAG CHIP DETECTOR
72-419	N79-21-10-6E		G-79-411-C1-2	CHECK/INSP	ENG 2 MAIN GEARBOX MAG CHIP DETECTOR
72-420	N72-61-01-6A	72-420-01-1	W-06-145-01	CHECK/INSP	ENGINE 1 MAIN GEARBOX HOUSING
72-420	N72-61-01-6A	72-420-01-2	W-06-145-01	CHECK/INSP	ENGINE 2 MAIN GEARBOX HOUSING

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
72-421			G-72-421	CHECK/INSP	UNASSIGNED
72-422	N72-62-01-6A	72-422-51-1	W-06-145-01	CHECK/INSP	ENGINE 1 ANGLE GEARBOX HOUSING
72-422	N72-62-01-6A	72-422-51-2	W-06-145-01	CHECK/INSP	ENGINE 2 ANGLE GEARBOX HOUSING
72-424	N72-00-00-C	72-424		REPLACE	TURBINE SHAFT COUPLING
72-425	N72-33-01-A	72-425-01-1		CHECK/INSP	ENGINE 1 FRONT FAN CASE
72-425	N72-33-01-A	72-425-01-2		CHECK/INSP	ENGINE 2 FRONT FAN CASE
72-426	N72-31-03-6A	72-426-01-1		CHECK/INSP	ENGINE 1 FAN EXIT FAIRING
72-426	N72-31-03-6A	72-426-01-2		CHECK/INSP	ENGINE 2 FAN EXIT FAIRING
72-427	N72-30-00-D	72-427-01-1	W-06-145-01	CHECK/INSP	ENGINE 1 FRONT MOUNT THRUST BRACKETS
72-427	N72-30-00-D	72-427-01-2	W-06-145-01	CHECK/INSP	ENGINE 2 FRONT MOUNT THRUST BRACKETS
72-428	N72-00-00-6C		G-72-410-C1-1	BORESCOPE	ENGINE 1 STAGE 3 LP TURBINE VANES
72-428	N72-00-00-6C		G-72-410-C1-2	BORESCOPE	ENGINE 2 STAGE 3 LP TURBINE VANES
72-429			G-72-429	OPERATIONAL	UNASSIGNED
72-430	N79-21-10-6B		G-79-411-C1-1	CHECK/INSP	NO. 1, 1.5 AND 2 BRG MAG CHIP DET
72-430	N79-21-10-6B		G-79-411-C1-2	CHECK/INSP	NO. 1, 1.5 AND 2 BRG MAG CHIP DET
72-501	D72-31-04-A	72-501		REPLACE	LP COMPRESSOR (FAN) SHAFT AND DISC
72-502	D72-31-02-A	72-502		REPLACE	LP COMPRESSOR (FAN) BLADES
72-503	D72-33-02-6A	72-503-01-1		CHECK/INSP	ENGINE 1 "A" FRAME ATTACHMENT POINTS
72-503	D72-33-02-6B	72-503-01-2		CHECK/INSP	ENGINE 2 "A" FRAME ATTACHMENT POINTS
72-504	D72-33-00-A	72-504		REPLACE	IP COMPRESSOR REAR STUB SHAFT
72-505	D72-33-01-A	72-505		REPLACE	IC DISC STAGE 1 TO 7 ASSEMBLIES
72-506	D72-00-00-2A		G-72-506-C1-1	BORESCOPE	ENG 1 COMBUSTION LINER/FUEL NOZZLES
72-506	D72-00-00-2A		G-72-506-C1-2	BORESCOPE	ENG 2 COMBUSTION LINER/FUEL NOZZLES
72-507	D72-30-01-A	72-507		REPLACE	HP COMPRESSOR ROTOR SHAFT ASSEMBLY
72-508	D72-00-00-2B		G-72-506-C1-1	BORESCOPE	ENG 1 HP TURBINE NOZZLE GUIDE VANES
72-508	D72-00-00-2B		G-72-506-C1-2	BORESCOPE	ENG 2 HP TURBINE NOZZLE GUIDE VANES
72-509	D72-40-00-A	72-509		REPLACE	HP TURBINE DISC
72-510	D72-00-00-2C		G-72-506-C1-1	BORESCOPE	ENGINE 1 HP TURBINE BLADES
72-510	D72-00-00-2C		G-72-506-C1-2	BORESCOPE	ENGINE 2 HP TURBINE BLADES
72-511	D72-50-00-A	72-511		REPLACE	IP TURBINE SHAFT
72-512	D72-51-03-A	72-512		REPLACE	IP, LP1, LP2 AND LP3 TURBINE DISCS
72-513	D72-51-03-B	72-513		REPLACE	LP TURBINE SHAFT
72-514	D72-31-04-6A		P-06-157-01	CHECK/INSP	ENGINE LP COMPRESSOR ROTOR BLADES
72-515	D72-30-00-A		P-06-157-01 P-06-159-01	CHECK/INSP	FAN TRACK AND COLD STREAM DUCT

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
72-516	D72-03-00-6A		P-06-159-01 P-06-162-01	CHECK/INSP	CORE FAIRINGS/INTERSERVICE PANELS
72-517	D72-03-00-6B		P-06-159-01 P-06-162-01	CHECK/INSP	PRESSURE RELIEF DOORS
72-518	D72-00-06-4A		P-06-161-01	CHECK/INSP	EXTERNAL GEARBOX SUSPENSION LINKS
72-519	D72-00-06-4B		P-06-161-01	CHECK/INSP	EXTERNAL GEARBOX-MOUNTED ACCESSORIES
72-520	D72-31-01-6A		P-06-159-01	CHECK/INSP	LP COMPRESSOR OUTLET GUIDE VANES
72-521	D72-02-01-6A	72-521-01-1		CHECK/INSP	ENGINE 1 CORE-MOUNTED P2.5 PIPING
72-521	D72-02-01-6A	72-521-01-2		CHECK/INSP	ENGINE 2 CORE-MOUNTED P2.5 PIPING
73-101	P73-11-02-4A	73-101-01-1		REPLACE	FUEL PUMP FILTER ELEMENT - ENG 1
73-101	P73-11-02-4A	73-101-01-2		REPLACE	FUEL PUMP FILTER ELEMENT - ENG 2
73-102	P73-00-00-6A		P-06-069-01	CHECK/INSP	PS4, TT2 SENSORS AND TUBING
73-103	P73-00-00-6B		P-06-069-01	CHECK/INSP	FUEL LINES AND COMPONENTS
73-104	P73-00-00-6C		P-06-069-01	CHECK/INSP	FUEL FILTER DIFF PRESSURE SWITCH
73-105	P73-00-00-6D		P-06-069-01	CHECK/INSP	FUEL HEATER AND EXTERNAL PLUMBING
73-106	P73-00-00-6E		P-06-069-01	CHECK/INSP	FUEL HTR AIR SHUTOFF SOLENOID VALVE
73-107	P73-00-00-6F		P-06-069-01	CHECK/INSP	FUEL FLOW TRANSMITTER
73-108			G-73-108	OPERATIONAL	ITEM DELETED
73-109	P73-21-07-5A	73-109-01-1		OPERATIONAL	EEC TRIM UNLOCK SOLENOID - ENG 1
73-109	P73-21-07-5A	73-109-01-2		OPERATIONAL	EEC TRIM UNLOCK SOLENOID - ENG 2
73-110			G-73-110	OPERATIONAL	ITEM DELETED
73-201	G75-31-03-6A		P-06-084-01	CHECK/INSP	VSV MECH LINKAGE & FEEDBACK CABLES
73-201	G75-32-02-6A		P-06-084-01	CHECK/INSP	VBV MECH LINKAGE & FEEDBACK CABLES
73-202	G73-00-00-6A		P-06-084-01	CHECK/INSP	FUEL SYSTEM PIPING AND COMPONENTS
73-203	G73-11-02-2A	73-203-01-1		REPLACE	FUEL FILTER ELEMENT - ENG 1
73-203	G73-11-02-2A	73-203-01-2		REPLACE	FUEL FILTER ELEMENT - ENG 2
73-204	G73-00-00-6B		P-06-084-01	CHECK/INSP	FUEL FLOW TRANSMITTER
73-205	G73-00-00-6C		P-06-084-01	CHECK/INSP	FUEL FILTER DIFF PRESSURE SWITCH
73-206	G73-21-06-6A	73-206-51-1		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
73-206	G73-21-06-6A	73-206-51-2		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
73-207	G73-21-07-5A	73-207-51-1		OPERATIONAL	FAIL-FIXED SOLENOID CIRCUIT - ENG 1
73-207	G73-21-07-5A	73-207-51-2		OPERATIONAL	FAIL-FIXED SOLENOID CIRCUIT - ENG 2
73-301	H75-31-03-6A		P-06-084-01	CHECK/INSP	VSV MECH LINKAGE & FEEDBACK CABLES
73-301	H75-32-02-6A		P-06-084-01	CHECK/INSP	VBV MECH LINKAGE & FEEDBACK CABLES
73-302	H73-11-06-A		P-06-084-01	CHECK/INSP	FUEL SYSTEM PIPING AND COMPONENTS

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
73-303	H73-11-02-4A	73-303-01-1		REPLACE	FUEL FILTER ELEMENT - ENG 1
73-303	H73-11-02-4A	73-303-01-2		REPLACE	FUEL FILTER ELEMENT - ENG 2
73-304	H73-31-01-A		P-06-084-01	CHECK/INSP	FUEL FLOW TRANSMITTER
73-305	H73-34-01-A		P-06-084-01	CHECK/INSP	FUEL FILTER DIFF PRESSURE SWITCH
73-401	N73-11-02-4A	73-401-01-1		REPLACE	ENGINE 1 FUEL PUMP FILTER ELEMENT
73-401	N73-11-02-4B	73-401-01-2		REPLACE	ENGINE 2 FUEL PUMP FILTER ELEMENT
73-402			G-73-402	OPERATIONAL	UNASSIGNED
73-403	N73-00-00-B	73-403-01-1		CHECK/INSP	FUEL LINES, MANIFOLDS AND COMPONENTS
73-403	N73-00-00-B	73-403-01-2		CHECK/INSP	FUEL LINES, MANIFOLDS AND COMPONENTS
73-404	N73-31-01-A		P-06-145-01	CHECK/INSP	FUEL FLOW TRANSMITTER
73-501	D73-11-02-4A	73-501-01-1		REPLACE	ENGINE 1 LOW PRESSURE FUEL FILTER
73-501	D73-11-02-4B	73-501-01-2		REPLACE	ENGINE 2 LOW PRESSURE FUEL FILTER
73-502	D73-21-09-5A	73-502-01-1		OPERATIONAL	ENGINE 1 FAFC
73-502	D73-21-09-5B	73-502-01-2		OPERATIONAL	ENGINE 2 FAFC
73-503	D73-21-17-6A	73-503-01-1	W-06-160-01-1	CHECK/INSP	P2.0/T2.0 SENSOR, TUBE AND WIRING
73-503	D73-21-17-6A	73-503-01-2	W-60-160-01-2	CHECK/INSP	P2.0/T2.0 SENSOR, TUBE AND WIRING
73-504	D73-11-00-A		P-06-161-01	CHECK/INSP	ENGINE FUEL SUPPLY SYSTEM COMPONENTS
73-505	D73-21-09-4A		P-06-161-01	CHECK/INSP	FULL AUTHORITY FUEL CONTROL/WIRING
73-506	D73-11-00-B		P-06-162-01	CHECK/INSP	FUEL SUPPLY SYSTEM ACCESSORIES
73-507	D73-21-00-5A		P-06-162-01	CHECK/INSP	FUEL CONT SYSTEM P3.0 SIGNAL PIPING
74-101	P74-21-02-6A	74-101-01-1	W-74-R03	CHECK/INSP	IGNITER PLUGS - ENG 1
74-101	P74-21-02-6A	74-101-01-2	W-74-R03	CHECK/INSP	IGNITER PLUGS - ENG 2
74-102	P74-00-00-5A	74-102-01-1		FUNCTIONAL	1 AND "2" IGNITION SYSTEMS - ENG 1
74-102	P74-00-00-5A	74-102-01-2		FUNCTIONAL	1 AND "2" IGNITION SYSTEMS - ENG 2
74-201	G74-00-00-5A	74-201-01-1		FUNCTIONAL	IGNITION SYSTEM - ENG 1
74-201	G74-00-00-5A	74-201-01-2		FUNCTIONAL	IGNITION SYSTEM - ENG 2
74-301	H74-00-00-5A	74-301-01-1		FUNCTIONAL	IGNITION SYSTEM - ENG 1
74-301	H74-00-00-5A	74-301-01-2		FUNCTIONAL	IGNITION SYSTEM - ENG 2
74-302			G-74-302	OPERATIONAL	UNASSIGNED
74-401	N74-21-02-6A	74-401-01-1	W-74-405-01-1	CHECK/INSP	ENGINE 1 IGNITER PLUGS
74-401	N74-21-02-6A	74-401-01-2	W-74-405-01-2	CHECK/INSP	ENGINE 2 IGNITER PLUGS
74-402			G-74-402	OPERATIONAL	UNASSIGNED
74-403	N74-00-00-5B	74-403-01		OPERATIONAL	IGNITION CONTROL SYSTEM
74-404	N74-21-01-6A	74-404-01-1	W-74-405-01-1	CHECK/INSP	ENGINE 1 IGNITER PLUG CABLES
74-404	N74-21-01-6A	74-404-01-2	W-74-405-01-2	CHECK/INSP	ENGINE 2 IGNITER PLUG CABLES

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
74-405	N74-11-01-6A	74-405-01-1		CHECK/INSP	ENGINE 1 IGNITION EXCITER
74-405	N74-11-01-6B	74-405-01-2		CHECK/INSP	ENGINE 2 IGNITION EXCITER
74-406			G-74-406	OPERATIONAL	UNASSIGNED
74-501	D74-00-00-5A	74-501-01-1		OPERATIONAL	HIGH ENERGY IGNITION UNIT-10 JOULES
74-501	D74-00-00-5E	74-501-01-2		OPERATIONAL	HIGH ENERGY IGNITION UNIT-10 JOULES
74-502	D74-00-00-5B	74-502-01-1		OPERATIONAL	ENG 1 CONTINUOUS IGNITION (4 JOULES)
74-502	D74-00-00-5F	74-502-01-2		OPERATIONAL	ENG 2 CONTINUOUS IGNITION (4 JOULES)
74-503	D74-00-00-5C	74-503-01-1		OPERATIONAL	ENGINE 1 STANDBY IGNITION
74-503	D74-00-00-5G	74-503-01-2		OPERATIONAL	ENGINE 2 STANDBY IGNITION
74-504	D74-00-00-5D	74-504-01-1		OPERATIONAL	ENGINE 1 APPROACH/LANDING IGNITION
74-504	D74-00-00-5H	74-504-01-2		OPERATIONAL	ENGINE 2 APPROACH/LANDING IGNITION
74-505	D74-00-00-5A	74-505-01-1		OPERATIONAL	ENGINE 1 TAI IGNITION ENGINE 1
74-505	D74-00-00-5E	74-505-01-2		OPERATIONAL	ENGINE 2 TAI IGNITION
74-506	D74-21-02-6A	74-506-01-1		CHECK/INSP	ENGINE 1 IGNITOR PLUGS
74-506	D74-21-02-6B	74-506-01-2		CHECK/INSP	ENGINE 2 IGNITER PLUGS
75-101	P75-00-00-6A		P-06-069-01	CHECK/INSP	STATOR VANE ANTI-ICE VALVE
75-102	P75-11-02-2A	75-102-01-1		CLEAN	STATOR VANE ANTI-ICE VALVE STRAINER
75-102	P75-11-02-2A	75-102-01-2		CLEAN	STATOR VANE ANTI-ICE VALVE STRAINER
75-103	P75-00-00-6B		P-06-069-01	CHECK/INSP	STATOR VANE ANTI-ICE VALVE DUCTING
75-104	24-11-00-A		P-06-069-01	CHECK/INSP	IDG COOLING SYSTEM TUBES & HOSES
75-105	24-11-04-B		P-06-069-01	CHECK/INSP	IDG AIR/OIL HEAT EXCHANGER
75-106	24-11-07-A		P-06-069-01	CHECK/INSP	IDG AIR SHUTOFF VALVE
75-107	P75-00-00-6C		P-06-069-01	CHECK/INSP	EXT ACCESSORIES COOLING SYSTEM INLET
75-108	P75-00-00-6D		P-06-069-01	CHECK/INSP	NACELLE ZONE VENTILATION S/O VALVE
75-109	P75-00-00-6E		P-06-069-01	CHECK/INSP	TCC MODULATING VALVE
75-110	P75-00-00-6F		P-06-069-01	CHECK/INSP	TCC CONTROL TUBING
75-111	P75-00-00-6G		P-06-069-01	CHECK/INSP	TCC/TCA AIR SUPPLY DUCT
75-112	P75-00-00-6H		P-06-069-01	CHECK/INSP	ENGINE VANE & BLEED CONTROL
75-113	P75-00-00-6I		P-06-069-01	CHECK/INSP	STATOR VANE ACTUATOR
75-114	P75-00-00-6J		P-06-069-01	CHECK/INSP	VARIABLE STATOR LINKAGE
75-115	P75-00-00-6K		P-06-069-01	CHECK/INSP	3.5 BLEED VALVE AND TUBING
75-116	P75-00-00-6L		P-06-069-01	CHECK/INSP	STATOR VANE AND BLEED CONTROL SYSTEM
75-117	P75-00-00-6M		P-06-069-01	CHECK/INSP	3.0 BLEED ACTUATOR & FEED BACK CABLE
75-118	P75-00-00-6N		P-06-069-01	CHECK/INSP	3.5 BLEED CONTROL VALVE
75-119	P75-00-00-6O		P-06-069-01	CHECK/INSP	3.5 BLEED OVERRIDE CONTROL VALVE

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
75-120	P75-00-00-6P		P-06-069-01	CHECK/INSP	MACH PROBE LINES & PROBE HEATER
75-201	G75-00-00-6A		P-06-084-01	CHECK/INSP	SUMP PRESSURIZING TUBING
75-202	G75-00-00-6B		P-06-084-01	CHECK/INSP	11TH STAGE TUBING
75-203	G75-00-00-6C		P-06-084-01	CHECK/INSP	7TH STAGE TUBING
75-204	G75-00-00-6D		P-06-084-01	CHECK/INSP	RAM AIR SCOOP
75-205	G75-00-00-6E		P-06-084-01	CHECK/INSP	IGNITION COOLING TUBING
75-206	G75-00-00-6F		P-06-084-01	CHECK/INSP	CDP SIGNAL TUBE
75-207	G75-00-00-6G		P-06-084-01	CHECK/INSP	7TH STAGE SIGNAL LINE
75-208	G75-00-00-6H		P-06-084-01	CHECK/INSP	JET EDUCTOR
75-209	24-11-00-A		P-06-084-01	CHECK/INSP	IDG COOLING SYSTEM TUBES & HOSES
75-210	24-11-04-B		P-06-084-01	CHECK/INSP	IDG AIR/OIL HEAT EXCHANGER
75-211	24-11-07-A		P-06-084-01	CHECK/INSP	IDG AIR SHUTOFF VALVE
75-301	H75-00-00-6A		P-06-084-01	CHECK/INSP	SUMP PRESSURIZING TUBING
75-302	H75-00-00-6B		P-06-084-01	CHECK/INSP	11TH STAGE TUBING
75-303	H75-00-00-6C		P-06-084-01	CHECK/INSP	7TH STAGE TUBING
75-304			G-75-304	OPERATIONAL	UNASSIGNED
75-305	H75-00-00-6E		P-06-084-01	CHECK/INSP	IGNITION COOLING TUBING
75-306	H75-00-00-6F		P-06-084-01	CHECK/INSP	CDP SIGNAL TUBE
75-307			G-75-307	OPERATIONAL	UNASSIGNED
75-308			G-75-308	OPERATIONAL	UNASSIGNED
75-309	24-11-00-A		P-06-084-01	CHECK/INSP	IDG COOLING SYSTEM TUBES & HOSES
75-310	24-11-04-B		P-06-084-01	CHECK/INSP	IDG AIR/OIL HEAT EXCHANGER
75-311	24-11-07-A		P-06-084-01	CHECK/INSP	IDG AIR SHUTOFF VALVE
75-312	H75-24-00-A		P-06-084-01	CHECK/INSP	LPT/HPT CASE COOLING PIPING
75-401	24-11-00-A		P-06-145-01	CHECK/INSP	IDG COOLING SYSTEM TUBES AND HOSES
75-402	24-11-04-B		P-06-145-01	CHECK/INSP	IDG AIR/OIL HEAT EXCHANGER
75-403			G-75-403	CHECK/INSP	UNASSIGNED
75-404	N75-24-00-6A N75-24-00-A	75-404-01-1		OPERATIONAL	ENGINE 1 TURBINE CASE COOLING
75-404	N75-24-00-6A N75-24-00-A	75-404-01-2		OPERATIONAL	ENGINE 2 TURBINE CASE COOLING
75-405	N75-24-00-A		G-75-404-01-1	CHECK/INSP	ENGINE 1 TCC AIR SHUTOFF VALVES
75-405	N75-24-00-A		G-75-404-01-2	CHECK/INSP	ENGINE 2 TCC AIR SHUTOFF VALVES
75-406	N75-32-00-6A	75-406-01-1		CHECK/INSP	2.5 BLEED VALVE-TO-ACTUATOR LINKAGE
75-406	N75-32-00-6A	75-406-01-2		CHECK/INSP	2.5 BLEED VALVE-TO-ACTUATOR LINKAGE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-34



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
75-407	N75-24-02-A	75-407-01-1		CHECK/INSP	ENGINE 1 TCA AIR SUPPLY DUCTS
75-407	N75-24-02-A	75-407-01-2		CHECK/INSP	ENGINE 2 TCA AIR SUPPLY DUCTS
75-408	N75-31-00-A		P-06-145-01	CHECK/INSP	VARIABLE STATOR LINKAGE
75-409	N75-32-00-A		P-06-145-01	CHECK/INSP	COMPRESSOR CONTROL SYSTEM PLUMBING
75-501	D75-21-00-A		P-06-159-01 P-06-162-01	CHECK/INSP	ENGINE RADIAL DRIVE FAIRINGS
75-502	D75-21-00-B		P-06-159-01 P-06-162-01 P-06-165-01	CHECK/INSP	INTERSERVICES AND PYLON SPLITTER
75-503	D75-33-12-A		P-06-161-01	CHECK/INSP	ENGINE P2.5 PIPING
75-504	D75-21-00-C		P-06-157-01	CHECK/INSP	ENGINE ZONE 1 VENTILATION INLET
75-505	D75-21-00-D		P-06-163-01	CHECK/INSP	ENGINE ZONE 1 VENTILATION EXITS
75-506	D75-21-00-D		P-06-159-01 P-06-162-01	CHECK/INSP	ENGINE COMBUSTION FAIRINGS
76-101	20-20-02-6A 20-20-02-6B 20-20-02-6J		G-76-101	CHECK/INSP	THRUST CONTROL CABLES
76-102	P76-11-00-B		P-06-077-01	CHECK/INSP	STRUT AREA PUSH-PULL CABLE SYSTEM
76-103	P76-11-00-A		P-06-069-01	CHECK/INSP	ENGINE AREA PUSH-PULL CABLE SYSTEM
76-104	P76-11-00-C		P-06-069-01	CHECK/INSP	FUEL CONDITION CONT MOTOR ACTUATOR
76-105	P76-11-00-D		P-06-069-01	CHECK/INSP	FUEL CONDITION CONT MOTOR ACTUATOR
76-201	20-20-02-6A		G-76-201	CHECK/INSP	THRUST CONTROL CABLES
76-202	G76-11-00-6B		P-06-092-01	CHECK/INSP	STRUT AREA PUSH-PULL CABLE SYSTEM
76-203	G76-11-00-6A		P-06-084-01	CHECK/INSP	ENGINE AREA PUSH-PULL CABLE SYSTEM
76-204	G76-11-00-6C		P-06-084-01	CHECK/INSP	ENG CONDITION CONTROL MOTOR ACTUATOR
76-205	G76-11-00-6D		P-06-084-01	CHECK/INSP	ENG CONDITION CONTROL MOTOR ACTUATOR
76-301	20-20-02-6A		G-76-301	CHECK/INSP	THRUST CONTROL CABLES
76-302	H76-11-00-6B		P-06-092-01	CHECK/INSP	STRUT AREA PUSH-PULL CABLE SYSTEM
76-303	H76-11-00-6A		P-06-084-01	CHECK/INSP	ENGINE AREA PUSH-PULL CABLE SYSTEM
76-304	H73-21-01-6A		P-06-084-01	CHECK/INSP	ENGINE MAIN CONTROL
76-305	H73-21-00-A		P-06-084-01	CHECK/INSP	MAIN ENGINE CONTROL SWITCH WIRING
77-101	P73-00-00-6G		P-06-069-01	CHECK/INSP	PT2/TT2 PROBE, WIRING AND TUBING
77-102	P77-11-01-6A		P-06-069-01	CHECK/INSP	PT7 PROBES AND TUBING
77-103	P77-00-00-6A		P-06-069-01	CHECK/INSP	EGT THERMOCOUPLE PROBES & CABLES
77-104	P77-41-00-5A	77-104-01		OPERATIONAL	STANDBY ENGINE INDICATOR
77-201	G77-00-00-6A		P-06-084-01	CHECK/INSP	EEC (PMC) GENERATOR CABLE

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
77-202	G77-00-00-6B		P-06-084-01	CHECK/INSP	EGT THERMOCOUPLE CONNECTORS & JCT BX
77-203	G77-00-00-6C		P-06-084-01	CHECK/INSP	EXPOSED EGT THERMOCOUPLE HARNESS
77-204	G77-00-00-6D	77-204-01		OPERATIONAL	STANDBY ENGINE INDICATOR
77-301	H77-00-00-6A		P-06-084-01	CHECK/INSP	EEC (PMC) GENERATOR CABLE
77-302	H77-00-00-6B		P-06-084-01	CHECK/INSP	EGT THERMOCOUPLE CONNECTORS & JCT BX
77-303	H77-00-00-6C		P-06-084-01	CHECK/INSP	EXPOSED EGT THERMOCOUPLE HARNESS
77-304	H77-41-00-5A	77-304-01		OPERATIONAL	STANDBY ENGINE INDICATOR
77-305	H77-35-00-2A	77-305-01		OPERATIONAL	PIMU FAULT MESSAGES
77-306	H77-35-00-2B	77-306-01		OPERATIONAL	EEC CATEGORY 2 FAULTS
77-401	N73-21-03-A		P-06-145-01	CHECK/INSP	PT2/TT2 PROBE, WIRING AND TUBING
77-402	N77-11-01-A		P-06-145-01	CHECK/INSP	PT 4.95 PROBES AND TUBING
77-403	N77-21-00-A		P-06-145-01	CHECK/INSP	EGT THERMOCOUPLE PROBES & CABLES
77-404	N77-21-03-A		P-06-145-01	CHECK/INSP	THERMOCOUPLE JUNCTION BOX
77-405	N77-35-00-2A	77-405-01		OPERATIONAL	PIMU FAULT MESSAGES
77-406	N77-35-00-2B	77-406-01		OPERATIONAL	EEC CATEGORY 2 FAULTS
77-407	N77-41-01-4A	77-407-01		OPERATIONAL	STANDBY ENGINE INDICATOR
77-501	D77-35-00-2A	77-501-01-1		OPERATIONAL	ENGINE 1 PIMU FAULT MESSAGES
77-501	D77-35-00-2A	77-501-01-2		OPERATIONAL	ENGINE 2 PIMU FAULT MESSAGES
77-502	D77-41-00-5A	77-502-01		OPERATIONAL	STANDBY ENGINE INDICATOR
77-503	D77-35-00-2B	77-503-01-1		OPERATIONAL	ENGINE 1 EEC CATEGORY 2 FAULTS
77-503	D77-35-00-2B	77-503-01-2		OPERATIONAL	ENGINE 2 EEC CATEGORY 2 FAULTS
78-000	H78-36-00-5J		G-78-327-C1-2	OPERATIONAL	THRUST REVERSER RELAY MODULE
78-101	P78-00-00-6B		P-06-069-01	CHECK/INSP	TURBINE EXHAUST SLEEVE AND PLUG
78-102	P78-00-00-6C		P-06-069-01	CHECK/INSP	TURBINE EXHAUST SLEEVE SPRING SEALS
78-103	P78-00-00-6D		P-06-069-01	CHECK/INSP	TURBINE EXHAUST HONEYCOMB SLEEVES
78-104	P78-00-00-6E		P-06-074-01	CHECK/INSP	FAN DUCT COWL & THRUST REVERSER
78-105	P78-31-11-6A		P-06-074-01	CHECK/INSP	THRUST REVERSER TRACKS/LINERS/SLIDER
78-106	P78-00-00-6F		P-06-073-01	CHECK/INSP	THRUST REVERSER HYDRAULIC TUBING
78-107	P78-31-16-6A		P-06-074-01	CHECK/INSP	THRUST REVERSER CASCADE VANES
78-108	P78-00-00-6G		P-06-073-01	CHECK/INSP	FAN DUCT TENSION LATCHES
78-109	P78-00-00-6H		P-06-073-01	CHECK/INSP	FAN DUCT V-GROOVE LATCH BANDS
78-110	P78-00-00-6I		P-06-073-01	CHECK/INSP	FAN DUCT COWL & THRUST REVERSE HINGE
78-111	P78-00-00-H	78-111-01-1		CHECK/INSP	LOUVERED EXHAUST DOOR - ENG 1
78-111	P78-00-00-H	78-111-01-2		CHECK/INSP	LOUVERED EXHAUST DOOR - ENG 2
78-112	P75-00-00-6Q		P-06-073-01	CHECK/INSP	3.5 BLEED VALVE EXHAUST SEALS/DUCTS

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
78-113	P78-00-00-6K		P-06-073-01	CHECK/INSP	THRUST REVERSER FAN FLOW PATH
78-113	P78-31-14-6B	78-113-02-1		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS
78-113	P78-31-14-6B	78-113-02-2		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS
78-114	P78-00-00-6L		P-06-082-01	CHECK/INSP	THRUST REVERSER ISOLATION VALVE
78-115	P78-00-00-6M		P-06-074-01	CHECK/INSP	THRUST REVERSER STOW SENSORS
78-116	P78-00-00-6N		P-06-073-01	CHECK/INSP	THRUST REVERSER FEEDBACK LINKAGE
78-117	P78-00-00-6O		P-06-073-01	CHECK/INSP	THRUST REVERSER UNLOCK SENSORS
78-118	P78-00-00-6P		P-06-073-01	CHECK/INSP	THRUST REVERSER DEPLOY SENSORS
78-119	P78-00-00-6Q		P-06-082-01	CHECK/INSP	ISOLATION VALVE PRESSURE SWITCH
78-120	P78-00-00-6R	78-120-51-1		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
78-120	P78-00-00-6R	78-120-51-2		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
78-121	P78-34-07-A		G-78-121-C2-1	OPERATIONAL	ENG 1 THRUST REVERSER SYNC-LOCK
78-121	P78-34-07-A		G-78-121-C2-2	OPERATIONAL	ENG 2 THRUST REVERSER SYNC-LOCK
78-122	P78-31-00-5A		G-78-137-C1-1	OPERATIONAL	ENG 1 T/R UPPER LOCKING HYD ACTRS
78-122	P78-31-00-5A		G-78-137-C1-2	OPERATIONAL	ENG 2 T/R UPPER LOCKING HYD ACTRS
78-123	P78-31-00-5B		G-78-137-C1-1	OPERATIONAL	ENG 1 T/R CENTER LOCKING HYD ACTRS
78-123	P78-31-00-5B		G-78-137-C1-2	OPERATIONAL	ENG 2 T/R CENTER LOCKING HYD ACTRS
78-124	P78-34-07-B		G-78-121-C2-1	FUNCTIONAL	ENG 1 T/R SYNC LOCK CONTROL CIRCUIT
78-124	P78-34-07-B		G-78-121-C2-2	FUNCTIONAL	ENG 2 T/R SYNC LOCK CONTROL CIRCUIT
78-125	P78-36-00-5C	78-125-51		OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
78-126	P78-36-07-5A	78-126-51		OPERATIONAL	THRUST REVERSER RELAY MODULE
78-201	G78-00-00-6B		P-06-084-01	CHECK/INSP	TURBINE EXHAUST SLEEVE AND PLUG
78-202	G78-00-00-6C		P-06-084-01	CHECK/INSP	TURBINE EXHAUST SLEEVE SPRING SEALS
78-203	G78-00-00-6D		P-06-084-01	CHECK/INSP	TURBINE EXHAUST HONEYCOMB SLEEVES
78-204	G78-00-00-6E		P-06-089-01	CHECK/INSP	FAN DUCT COWL & THRUST REVERSER
78-205	G78-31-11-6A		P-06-089-01	CHECK/INSP	TRACKS, LINERS AND SLIDERS
78-206	G78-00-00-6F		P-06-088-01	CHECK/INSP	THRUST REVERSER HYDRAULIC TUBING
78-207	G78-31-16-6A		P-06-089-01	CHECK/INSP	CASCADE VANES
78-208	G78-00-00-6G		P-06-088-01	CHECK/INSP	FAN DUCT TENSION LATCHES
78-209	G78-00-00-6H		P-06-088-01	CHECK/INSP	FAN DUCT V-GROOVE LATCH BANDS
78-210	G78-00-00-6I		P-06-088-01	CHECK/INSP	FAN DUCT COWL & THRUST REV HINGES
78-211	G78-00-00-6J	78-211-01-1		CHECK/INSP	LOUVERED EXHAUST DOOR HINGES/LATCHES
78-211	G78-00-00-6J	78-211-01-2		CHECK/INSP	LOUVERED EXHAUST DOOR HINGES/LATCHES
78-212	G78-00-00-6K		P-06-088-01	CHECK/INSP	THRUST REVERSER FAN FLOW PATH
78-212	G78-00-00-6S	78-212-02-1		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
78-212	G78-00-00-6S	78-212-02-2		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS
78-213	G78-00-00-6L		P-06-097-01	CHECK/INSP	THRUST REVERSER ISOLATION VALVE
78-214	G78-00-00-6M		P-06-089-01	CHECK/INSP	THRUST REVERSER STOW SENSORS
78-215	G78-00-00-6N		P-06-088-01	CHECK/INSP	THRUST REVERSER FEEDBACK LINKAGE
78-216	G78-00-00-6O		P-06-088-01	CHECK/INSP	THRUST REVERSER UNLOCK SENSORS
78-217	G78-00-00-6P		P-06-088-01	CHECK/INSP	THRUST REVERSER DEPLOY SENSOR
78-218	G78-00-00-6Q		P-06-097-01	CHECK/INSP	ISOLATION VALVE PRESSURE SWITCH
78-220	G78-34-07-B		G-78-223-C1-1	FUNCTIONAL	ENG 1 T/R SYNC LOCK CONTROL CIRCUIT
78-220	G78-34-07-B		G-78-223-C1-2	FUNCTIONAL	ENG 2 T/R SYNC LOCK CONTROL CIRCUIT
78-221	G78-36-00-5C	78-221-52		OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
78-222	G78-36-07-5A	78-222-51		OPERATIONAL	THRUST REVERSER RELAY MODULE
78-223	G78-34-07-A		G-78-223-C1-1	OPERATIONAL	ENG 1 THRUST REVERSER SYNC-LOCK
78-223	G78-34-07-A		G-78-223-C1-2	OPERATIONAL	ENG 2 THRUST REVERSER SYNC-LOCK
78-224	G78-31-00-5A		G-78-224-C1-1	OPERATIONAL	ENG 1 T/R UPPER LOCKING HYD ACTRS
78-224	G78-31-00-5A		G-78-224-C1-2	OPERATIONAL	ENG 2 T/R UPPER LOCKING HYD ACTRS
78-225	G78-31-00-5B		G-78-224-C1-1	OPERATIONAL	ENG 1 T/R CENTER LOCKING HYD ACTRS
78-225	G78-31-00-5B		G-78-224-C1-2	OPERATIONAL	ENG 2 T/R CENTER LOCKING HYD ACTRS
78-301	H78-00-00-6B		P-06-084-01	CHECK/INSP	TURBINE EXHAUST SLEEVE AND PLUG
78-302	H78-00-00-6C		P-06-084-01	CHECK/INSP	TURBINE EXHAUST SLEEVE SPRING SEALS
78-303	H78-00-00-6D		P-06-084-01	CHECK/INSP	TURBINE EXHAUST HONEYCOMB SLEEVES
78-304	H78-00-00-6E		P-06-089-01	CHECK/INSP	FAN DUCT COWL & THRUST REVERSER
78-305	H78-31-11-6A		P-06-089-01	CHECK/INSP	TRACKS, LINERS AND SLIDERS
78-306			G-78-306	OPERATIONAL	UNASSIGNED
78-307	H78-31-16-6A		P-06-089-01	CHECK/INSP	CASCADE VANES
78-308	H78-00-00-6G		P-06-088-01	CHECK/INSP	FAN DUCT TENSION LATCHES
78-309			G-78-309	OPERATIONAL	UNASSIGNED
78-310	H78-00-00-6I		P-06-088-01	CHECK/INSP	FAN DUCT COWL & THRUST REV HINGES
78-311			G-78-311	OPERATIONAL	UNASSIGNED
78-312	H78-00-00-B	78-312-02-1		CHECK/INSP	THRUST REVERSER BLOCKER DOORS
78-312	H78-00-00-B	78-312-02-2		CHECK/INSP	THRUST REVERSER BLOCKER DOORS
78-312	H78-00-00-6K		P-06-088-01	CHECK/INSP	THRUST REVERSER FAN FLOW PATH
78-313			G-78-313	OPERATIONAL	UNASSIGNED
78-314			G-78-314	OPERATIONAL	UNASSIGNED
78-315			G-78-315	OPERATIONAL	UNASSIGNED
78-316			G-78-316	OPERATIONAL	UNASSIGNED

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
78-317			G-78-317	OPERATIONAL	UNASSIGNED
78-318			G-78-318	OPERATIONAL	UNASSIGNED
78-320	12-21-36-3A		G-12-042-01	LUBRICATE	T/R ROTARY FLEXIBLE DRIVE SHAFTS
78-321	12-21-35-3A		G-12-041-01	LUBRICATE	T/R BALLSCREW ACTUATOR NUTS
78-322	H78-31-00-A	78-322-01-1		CHECK/INSP	L T/R BALLSCREW ACTUATOR ATTACH PT
78-322	H78-31-00-A	78-322-01-2		CHECK/INSP	R T/R BALLSCREW ACTUATOR ATTACH PT
78-323	H78-31-15-6A		G-78-323-01-1	CHECK/INSP	L T/R BLOCKER DOOR HINGES & LINKS
78-323	H78-31-15-6A		G-78-323-01-2	CHECK/INSP	R T/R BLOCKER DOOR HINGES & LINKS
78-324	H78-00-00-A		P-06-088-01	CHECK/INSP	T/R FIRE PROTECTION BLANKETS
78-325	H78-31-00-B		P-06-087-01	CHECK/INSP	T/R STOW/NOT-STOWED SWITCHES & WIRES
78-326	H78-31-00-C		P-06-087-01	CHECK/INSP	T/R DEPLOY/NOT DEPLOYED SWITCHES
78-327	H78-36-00-5A	78-327-01-1		FUNCTIONAL	ENG 1 T/R PNEUMATIC PRESSURE SWITCH
78-327	H78-36-00-5B	78-327-01-2		FUNCTIONAL	ENG 2 T/R PNEUMATIC PRESSURE SWITCH
78-327	H78-36-00-5H		G-78-327-C1-2	OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
78-328	H78-36-00-5E		G-78-327-C1-1	OPERATIONAL	ENGINE 1 T/R DISAGREEMENT CIRCUIT
78-328	H78-36-00-5F		G-78-327-C1-2	OPERATIONAL	ENG 2 T/R DISAGREEMENT CIRCUIT
78-329	H78-36-00-5C	78-329-01-1		OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES
78-329	H78-36-00-5D	78-329-01-2		OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES
78-330	H78-00-00-6T		G-78-330-C1-1	CHECK/INSP	ENG 1 THRUST REVERSER BULL-NOSE SEAL
78-330	H78-00-00-6T		G-78-330-C1-2	CHECK/INSP	ENG 2 THRUST REVERSER BULL-NOSE SEAL
78-331	H78-31-21-A	78-331-51-1		OPERATIONAL	T/R CENTER DRIVE UNIT CONE BRAKE
78-331	H78-31-21-A	78-331-51-2		OPERATIONAL	T/R CENTER DRIVE UNIT CONE BRAKE
78-332	H78-34-07-A	78-332-51-1		OPERATIONAL	ENGINE 1 T/R ACTUATION SYSTEM BRAKE
78-332	H78-34-07-A	78-332-51-2		OPERATIONAL	ENGINE 2 T/R ACTUATION SYSTEM BRAKE
78-333	H78-36-00-5G		G-78-327-C1-1	OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
78-334	H78-36-00-5I		G-78-327-C1-1	OPERATIONAL	THRUST REVERSER RELAY MODULE
78-401	N78-11-00-A		P-06-145-01	CHECK/INSP	TURBINE EXHAUST SLEEVE AND PLUG
78-402	N78-11-00-B		P-06-145-01	CHECK/INSP	TURBINE EXHAUST SLEEVE SPRING SEALS
78-403	N78-11-00-C		P-06-145-01	CHECK/INSP	TURBINE EXHAUST HONEYCOMB SLEEVES
78-404	N78-31-00-A		P-06-153-01	CHECK/INSP	THRUST REVERSER STRUCTURE
78-405	N78-00-00-6C		G-78-405-C1-1	CHECK/INSP	ENGINE 1 FAN DUCT BULL-NOSE SEAL
78-405	N78-00-00-6C		G-78-405-C1-2	CHECK/INSP	ENGINE 2 FAN DUCT BULL-NOSE SEAL
78-406	N78-31-00-B		P-06-144-01	CHECK/INSP	THRUST REVERSER HYDRAULIC TUBING
78-407	N78-31-14-6B	78-407-01-1		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS
78-407	N78-31-14-6B	78-407-01-2		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
78-408	N78-31-04-A		P-06-144-01	CHECK/INSP	FAN DUCT TENSION LATCHES
78-409	N78-31-02-A		P-06-144-01	CHECK/INSP	FAN DUCT V-GROOVE LATCH BANDS
78-410	N78-31-00-D		P-06-144-01	CHECK/INSP	FAN DUCT COWL/THRUST REVERSER HINGE
78-411	N78-31-00-E		P-06-144-01	CHECK/INSP	C-DUCT LATCH ACCESS DOORS
78-412	N78-31-00-F		P-06-144-01	CHECK/INSP	FAN AIR EXIT NOZZLE
78-413	N78-31-00-C		P-06-144-01	CHECK/INSP	THRUST REVERSER FAN FLOW PATH
78-414	N78-34-05-A		P-06-154-01	CHECK/INSP	THRUST REVERSER ISOLATION VALVE
78-415	N78-34-00-A		P-06-153-01	CHECK/INSP	T/R AUTO-RESTOW PROXIMITY SENSORS
78-416	N78-34-00-B		P-06-144-01	CHECK/INSP	THRUST REVERSER POSITION LVDT
78-417	N78-36-00-A		P-06-144-01	CHECK/INSP	T/R ACTUATOR LOCK PROXIMITY SENSORS
78-418	N78-36-00-B		P-06-144-01	CHECK/INSP	THRUST REVERSER DEPLOY SENSORS
78-419	N78-34-01-A		P-06-148-01	CHECK/INSP	T/R DIRECTIONAL CONTROL VALVE
78-420			G-78-420	SERVICE	UNASSIGNED
78-421			G-78-421	CLEAN	UNASSIGNED
78-422	N78-00-00-6D		G-78-405-C1-1	CHECK/INSP	ENGINE 1 FAN DUCT BULL-NOSE FAIRING
78-422	N78-00-00-6D		G-78-405-C1-2	CHECK/INSP	ENGINE 2 FAN DUCT BULL-NOSE FAIRING
78-423	N78-31-08-A		P-06-144-01	CHECK/INSP	T/R HYD COWL OPENING ACTR FLEX HOSES
78-424	N78-31-06-A		P-06-144-01	CHECK/INSP	T/R HYD COWL OPENING ACTR ATTACHMENT
78-425	N78-31-00-G		P-06-144-01	CHECK/INSP	FAN DUCT COWL AND T/R HOLD OPEN RODS
78-426			G-78-426	CHECK/INSP	UNASSIGNED
78-427	N78-31-10-A		P-06-144-01	CHECK/INSP	THRUST REVERSER TRANSLATING SLEEVES
78-429	N78-31-00-5A	78-429-03-1		FUNCTIONAL	CENTER LOCKING HYDRAULIC ACTUATOR
78-429	N78-31-00-5A	78-429-03-2		FUNCTIONAL	CENTER LOCKING HYDRAULIC ACTUATOR
78-430	N78-34-13-B		G-78-431-C1-1	FUNCTIONAL	ENG 1 T/R SYNC LOCK CONTROL CIRCUIT
78-430	N78-34-13-B		G-78-431-C1-2	FUNCTIONAL	ENG 2 T/R SYNC LOCK CONTROL CIRCUIT
78-431	N78-34-13-A		G-78-431-C1-1	OPERATIONAL	ENG 1 THRUST REVERSER SYNC-LOCK
78-431	N78-34-13-A		G-78-431-C1-2	OPERATIONAL	ENG 2 THRUST REVERSER SYNC-LOCK
78-433	N78-36-03-5A	78-433-01		OPERATIONAL	THRUST REVERSER RELAY MODULE
78-434	N78-31-11-6A		P-06-074-01	CHECK/INSP	THRUST REVERSER TRACKS/LINERS/SLIDER
78-435	N78-31-16-6B		P-06-074-01	CHECK/INSP	THRUST REVERSER CASCADE VANES
78-501	D78-31-00-2A	78-501-01-1		CHECK/INSP	ENG 1 T/R SCREWJACK/BALLNUT HOUSING
78-501	D78-31-00-2A	78-501-01-2		CHECK/INSP	ENG 2 T/R SCREWJACK/BALLNUT HOUSING
78-502	D78-31-16-6A	78-502-01-1		OPERATIONAL	ENGINE 1 AIR MOTOR FEEDBACK CABLE
78-502	D78-31-16-6A	78-502-01-2		OPERATIONAL	ENGINE 2 AIR MOTOR FEEDBACK CABLE
78-503	D78-36-00-5A	78-503-01-1		OPERATIONAL	ENGINE 1 T/R DISAGREEMENT CIRCUIT

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
78-503	D78-36-00-5D	78-503-01-2		OPERATIONAL	ENGINE 2 T/R DISAGREEMENT CIRCUIT
78-504	D78-11-03-6A		P-06-159-01	CHECK/INSP	ENGINE EXHAUST CONE
78-505	D78-11-00-6A		P-06-157-01 P-06-159-01	CHECK/INSP	ENGINE INTEGRATED NOZZLE ASSEMBLY
78-506	D78-11-00-6B		P-06-157-01 P-06-159-01	CHECK/INSP	ENGINE INA PROPULSION NOZZLE
78-507	D78-11-01-4A		P-06-159-01	CHECK/INSP	ENGINE EXHAUST FORCED MIXER
78-508	D78-31-00-6A		P-06-159-01 P-06-164-01	CHECK/INSP	ENGINE THRUST REVERSER PANELS
78-509	D78-31-09-6A		P-06-165-01	CHECK/INSP	ENGINE THRUST REVERSER CASCADE VANES
78-510	D78-31-00-6B		P-06-165-01	CHECK/INSP	TRANSLATING COWL AND FORWARD SEAL
78-511	D78-31-00-6C		P-06-164-01	CHECK/INSP	ENGINE T/R CASCADE INLET FAIRING
78-512	D78-31-00-6D		P-06-165-01	CHECK/INSP	BLOCKER DOORS/ATTACHMENT FEATURES
78-513	D78-31-00-6E		P-06-165-01	CHECK/INSP	ENGINE THRUST REVERSER CORONA
78-514	D78-30-00-A		G-78-514-C1-1	OPERATIONAL	ENG 1 T/R GEARBOX LOCKS
78-514	D78-30-00-A		G-78-514-C1-2	OPERATIONAL	ENG 2 T/R GEARBOX LOCKS
78-515	D78-30-00-B		G-78-514-C1-1	OPERATIONAL	ENG 1 THRUST REVERSER AIRMOTOR BRAKE
78-515	D78-30-00-B		G-78-514-C1-2	OPERATIONAL	ENG 2 THRUST REVERSER AIRMOTOR BRAKE
78-516	D78-36-00-5C		G-78-516-C1	OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
78-517	D78-36-00-5B		G-78-516-C1	OPERATIONAL	THRUST REVERSER RELAY MODULE
79-101	P79-00-00-6A		P-06-069-01	CHECK/INSP	ENGINE OIL TANK
79-102	P79-00-00-6B		P-06-069-01	CHECK/INSP	OIL SYSTEM TUBING
79-103	P79-00-00-6C		P-06-069-01	CHECK/INSP	GEARBOX OIL SYSTEM INTERFACES
79-104	P72-61-03-2A	79-104-01-1		REPLACE	MAIN OIL FILTER ELEMENT - ENG 1
79-104	P72-61-03-2A	79-104-01-2		REPLACE	MAIN OIL FILTER ELEMENT - ENG 2
79-105	P79-00-00-6D		P-06-069-01	CHECK/INSP	ENGINE FUEL/OIL COOLER
79-106	P79-00-00-6E		P-06-069-01	CHECK/INSP	OIL QUANTITY TRANSMITTER AND WIRING
79-107	P79-00-00-6F		P-06-069-01	CHECK/INSP	OIL PRESSURE TRANSMITTER AND WIRING
79-108	P79-00-00-6G		P-06-069-01	CHECK/INSP	LOW OIL PRESSURE WARNING SWITCH
79-109	P79-00-00-6H		P-06-069-01	CHECK/INSP	OIL TEMPERATURE BULB
79-110	P79-00-00-6I		P-06-069-01	CHECK/INSP	OIL FILTER DIFFERENTIAL PRESS SWITCH
79-201	G79-21-04-4A	79-201-01-1		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 1
79-201	G79-21-04-4A	79-201-01-2		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 2
79-202	G79-00-00-6A		P-06-084-01	CHECK/INSP	EXPOSED LUBRICATION SYSTEM PIPING
79-203	G79-00-00-6B		P-06-084-01	CHECK/INSP	OIL QUANTITY TRANSMITTER AND WIRING

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
79-204	G79-00-00-6C		P-06-084-01	CHECK/INSP	OIL PRESSURE TRANSMITTER
79-205	G79-00-00-6D		P-06-084-01	CHECK/INSP	LOW OIL PRESSURE WARNING SWITCH
79-206	G79-00-00-6E		P-06-084-01	CHECK/INSP	OIL TEMPERATURE BULB
79-207	G79-00-00-6F		P-06-084-01	CHECK/INSP	OIL FILTER DIFFERENTIAL PRESS SWITCH
79-301	H79-21-04-4A	79-301-01-1		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 1
79-301	H79-21-04-4A	79-301-01-2		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 2
79-302	H79-00-00-6A		P-06-084-01	CHECK/INSP	EXPOSED LUBRICATION SYSTEM PIPING
79-303	H79-00-00-6B		P-06-084-01	CHECK/INSP	OIL QUANTITY TRANSMITTER AND WIRING
79-304	H79-00-00-6C		P-06-084-01	CHECK/INSP	OIL PRESSURE TRANSMITTER
79-305	H79-00-00-6D		P-06-084-01	CHECK/INSP	LOW OIL PRESSURE WARNING SWITCH
79-306	H79-00-00-6E		P-06-084-01	CHECK/INSP	OIL TEMPERATURE BULB
79-307	H79-00-00-6F		P-06-084-01	CHECK/INSP	OIL FILTER DIFFERENTIAL PRESS SWITCH
79-401	N79-00-00-6A	79-401-01-1		CHECK/INSP	ENGINE 1 OIL SYSTEM TUBING
79-401	N79-00-00-6A	79-401-01-2		CHECK/INSP	ENGINE 2 OIL SYSTEM TUBING
79-402	N79-21-01-A	79-402-01-1		CHECK/INSP	ENGINE 1 FUEL/OIL COOLER
79-402	N79-21-01-A	79-402-01-2		CHECK/INSP	ENGINE 2 FUEL OIL COOLER
79-404	N79-31-01-A		P-06-145-01	CHECK/INSP	OIL QUANTITY TRANSMITTER AND WIRING
79-405	N79-32-01-A		P-06-145-01	CHECK/INSP	OIL PRESSURE TRANSMITTER AND WIRING
79-406	N79-33-01-A		P-06-145-01	CHECK/INSP	LOW OIL PRESSURE WARNING SWITCH
79-407	N73-21-10-A		P-06-145-01	CHECK/INSP	EEC OIL TEMP THERMOCOUPLE PROBE
79-409	N79-35-00-5A	79-409-51-1		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM
79-409	N79-35-00-5A	79-409-51-2		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM
79-501	D79-00-00-6A	79-501-01-1		CHECK/INSP	ENGINE 1 MAGNETIC CHIP DETECTOR
79-501	D79-00-00-6A	79-501-01-2		CHECK/INSP	ENGINE 2 MAGNETIC CHIP DETECTOR
79-502	D79-21-07-4A	79-502-01-1		REPLACE	ENGINE 1 LUBRICATION PRESSURE FILTER
79-502	D79-21-07-4B	79-502-01-2		REPLACE	ENGINE 2 LUBRICATION PRESSURE FILTER
79-503	D79-21-08-4A	79-503-01-1		REPLACE	ENGINE 1 LUBRICATION SCAVENGE FILTER
79-503	D79-21-08-4B	79-503-01-2		REPLACE	ENGINE 2 LUBRICATION SCAVENGE FILTER
79-504	D79-21-00-A		P-06-161-01	CHECK/INSP	LUBRICATION SYSTEM ACCESSORIES
79-505	D79-21-05-6A	79-505-01-1		CHECK/INSP	ENG 1 CORE-MOUNTED LUBE COMPONENTS
79-505	D79-21-05-6A	79-505-01-2		CHECK/INSP	ENG 2 CORE-MOUNTED LUBE COMPONENTS
80-101	12-22-02-3A	80-101-01-1		REPLACE	STARTER OIL CHANGE
80-101	12-22-02-3A	80-101-01-2		REPLACE	STARTER OIL CHANGE
80-102	P80-11-01-6A	80-102-01-1		CHECK/INSP	STARTER CHIP DETECTOR - ENG 1
80-102	P80-11-01-6A	80-102-01-2		CHECK/INSP	STARTER CHIP DETECTOR - ENG 2

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
80-103	P80-11-04-2A	80-103-01-1		CLEAN	STARTER CONTROL VALVE FILTER - ENG 1
80-103	P80-11-04-2A	80-103-01-2		CLEAN	STARTER CONTROL VALVE FILTER - ENG 2
80-104	P80-11-00-6A		P-06-069-01	CHECK/INSP	START SYSTEM DUCTING AND CLAMPS
80-105			G-80-105	REPLACE	UNASSIGNED
80-201	12-22-02-3B	80-201-01-1		REPLACE	ENGINE 1 STARTER OIL CHANGE
80-201	12-22-02-3B	80-201-01-2		REPLACE	ENGINE 2 STARTER OIL CHANGE
80-202	G80-11-01-6A	80-202-01-1		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 1
80-202	G80-11-01-6A	80-202-01-2		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 2
80-203	G80-11-00-6A		P-06-084-01	CHECK/INSP	START SYSTEM DUCTING AND CLAMPS
80-204			G-80-204	RESTORE	UNASSIGNED
80-205			G-80-205	OPERATIONAL	UNASSIGNED
80-206			G-80-206	REPLACE	UNASSIGNED
80-207			G-80-207	OPERATIONAL	UNASSIGNED
80-208			G-80-208	CHECK/INSP	UNASSIGNED
80-301	12-22-02-3C	80-301-01-1		REPLACE	ENGINE 1 STARTER OIL CHANGE
80-301	12-22-02-3C	80-301-01-2		REPLACE	ENGINE 2 STARTER OIL CHANGE
80-302	H80-11-01-6A	80-302-01-1		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 1
80-302	H80-11-01-6A	80-302-01-2		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 2
80-303	H80-11-00-6A		P-06-084-01	CHECK/INSP	START SYSTEM DUCTING AND CLAMPS
80-304			G-80-304	RESTORE	UNASSIGNED
80-305			G-80-305	OPERATIONAL	UNASSIGNED
80-306			G-80-306	REPLACE	UNASSIGNED
80-307			G-80-307	OPERATIONAL	UNASSIGNED
80-308			G-80-308	OPERATIONAL	UNASSIGNED
80-309	12-13-02-3A	80-309-01-1		CHECK/INSP	ENGINE 1 STARTER OIL
80-309	12-13-02-3A	80-309-01-2		CHECK/INSP	ENGINE 2 STARTER OIL
80-401	12-22-02-3A	80-401-01-1		REPLACE	ENGINE 1 STARTER OIL
80-401	12-22-02-3A	80-401-01-2		REPLACE	ENGINE 2 STARTER OIL
80-402	N80-11-01-6A	80-402-01-1		CHECK/INSP	ENG 1 STARTER MAGNETIC CHIP DETECTOR
80-402	N80-11-01-6A	80-402-01-2		CHECK/INSP	ENG 2 STARTER MAGNETIC CHIP DETECTOR
80-404	N80-11-00-A		P-06-145-01	CHECK/INSP	START SYSTEM DUCTING/CLAMPS/QUAD
80-501	12-13-02-3A	80-501-01-1		SERVICE	ENGINE 1 STARTER OIL
80-501	12-13-02-3A	80-501-01-2		SERVICE	ENGINE 2 STARTER OIL
80-502	D80-11-01-6A	80-502-01-1		CHECK/INSP	ENGINE 1 STARTER CHIP DETECTOR
80-502	D80-11-01-6A	80-502-01-2		CHECK/INSP	ENGINE 2 STARTER CHIP DETECTOR

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
80-503	12-22-02-3A	80-503-01-1		REPLACE	ENGINE 1 STARTER OIL
80-503	12-22-02-3A	80-503-01-2		REPLACE	ENGINE 2 STARTER OIL
80-504	D80-11-00-6A		P-06-161-01	CHECK/INSP	ENGINE STARTER DUCTING AND CLAMPS
0600-100-01Z	0600-100-01Z	06-001-01		GEN VISUAL	LOWER HALF OF FUSELAGE - EXTERIOR
0600-111-01Z	0600-111-01Z	06-002-01		GEN VISUAL	RADOME
0600-113-01Z 0600-114-01Z	0600-113-01Z 0600-114-01Z	06-003-01		GEN VISUAL	AREAS FORWARD OF NLG WHEEL WELL
0600-115-01Z 0600-116-01Z	0600-115-01Z 0600-116-01Z	06-004-01		GEN VISUAL	NOSE LANDING GEAR WHEEL WELL
0600-117-01Z 0600-118-01Z	0600-117-01Z 0600-118-01Z	06-005-01		GEN VISUAL	AREAS OUTBD AND ABOVE NLG WHEEL WELL
0600-119-01Z	0600-119-01Z	06-006-01		GEN VISUAL	MAIN EQUIPMENT CENTER
0600-119-02Z	0600-119-02Z	06-007-01		GEN VISUAL	MAIN EQUIPMENT CENTER
0600-121-01Z 0600-122-01Z	0600-121-01Z 0600-122-01Z	06-008-01		GEN VISUAL	FORWARD CARGO COMPARTMENT
0600-121-02Z 0600-122-02Z	0600-121-02Z 0600-122-02Z	06-009-01		GEN VISUAL	FORWARD CARGO COMPARTMENT
0600-123-01Z 0600-124-01Z	0600-123-01Z 0600-124-01Z	06-010-01		GEN VISUAL	AREAS BELOW FWD CARGO COMPARTMENT
0600-125-01Z 0600-126-01Z	0600-125-01Z 0600-126-01Z	06-011-01		GEN VISUAL	AREAS AFT OF FWD CARGO COMPARTMENT
0600-131-01Z 0600-132-01Z	0600-131-01Z 0600-132-01Z	06-012-01		GEN VISUAL	AREAS ABOVE WING CENTER SECTION
0600-131-02Z 0600-132-02Z	0600-131-02Z 0600-132-02Z	06-012-02		GEN VISUAL	AREAS ABOVE WING CENTER SECTION
0600-133-01Z 0600-134-01Z	0600-133-01Z 0600-134-01Z	06-013-01		GEN VISUAL	WING CENTER SECTION
0600-133-01Z 0600-134-01Z	0600-133-01Z 0600-134-01Z	06-013-02		GEN VISUAL	WING CENTER SECTION
0600-135-01Z 0600-136-01Z	0600-135-01Z 0600-136-01Z	06-014-01		GEN VISUAL	ENVIRONMENTAL CONTROL SYSTEM BAYS
0600-141-01Z 0600-142-01Z	0600-141-01Z 0600-142-01Z	06-015-01		GEN VISUAL	AREAS ABOVE MLG WHEEL WELL
0600-141-02Z 0600-142-02Z	0600-141-02Z 0600-142-02Z	06-015-02		GEN VISUAL	AREAS ABOVE MLG WHEEL WELL
0600-143-01Z	0600-143-01Z	06-016-01		GEN VISUAL	LEFT MAIN WHEEL WELL
0600-144-01Z	0600-144-01Z	06-017-01		GEN VISUAL	RIGHT MAIN WHEEL WELL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-44



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-151-01Z 0600-152-01Z	0600-151-01Z 0600-152-01Z	06-018-01		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT
0600-151-02Z 0600-152-02Z	0600-151-02Z 0600-152-02Z	06-019-01		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT
0600-151-03Z 0600-152-03Z	0600-151-03Z 0600-152-03Z	06-020-01		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT
0600-153-01Z	0600-153-01Z	06-021-01		GEN VISUAL	AFT CARGO COMPARTMENT - LEFT
0600-153-02Z	0600-153-02Z	06-022-01		GEN VISUAL	AFT CARGO COMPARTMENT - LEFT
0600-154-01Z	0600-154-01Z	06-023-01		GEN VISUAL	AFT CARGO COMPARTMENT - RIGHT
0600-154-02Z	0600-154-02Z	06-024-01		GEN VISUAL	AFT CARGO COMPARTMENT - RIGHT
0600-155-01Z 0600-156-01Z	0600-155-01Z 0600-156-01Z	06-025-01		GEN VISUAL	AREAS BELOW AFT CARGO COMPARTMENT
0600-161-01Z	0600-161-01Z	06-026-01		GEN VISUAL	BULK CARGO COMPARTMENT - LEFT
0600-161-02Z	0600-161-02Z	06-027-01		GEN VISUAL	BULK CARGO COMPARTMENT - LEFT
0600-162-01Z	0600-162-01Z	06-028-01		GEN VISUAL	BULK CARGO COMPARTMENT - RIGHT
0600-162-02Z	0600-162-02Z	06-029-01		GEN VISUAL	BULK CARGO COMPARTMENT - RIGHT
0600-163-01Z 0600-164-01Z	0600-163-01Z 0600-164-01Z	06-030-01		GEN VISUAL	AREAS BELOW BULK CARGO COMPARTMENT
0600-165-01Z 0600-166-01Z	0600-165-01Z 0600-166-01Z	06-031-01		GEN VISUAL	AREAS AFT OF BULK CARGO COMPARTMENT
0600-191-01Z 0600-193-01Z	0600-191-01Z 0600-193-01Z	06-032-01		GEN VISUAL	WING TO BODY FAIRINGS - FWD LEFT
0600-192-01Z 0600-194-01Z	0600-192-01Z 0600-194-01Z	06-033-01		GEN VISUAL	WING TO BODY FAIRINGS - FWD RIGHT
0600-195-01Z 0600-197-01Z	0600-195-01Z 0600-197-01Z	06-034-01		GEN VISUAL	WING TO BODY FAIRINGS - AFT LEFT
0600-196-01Z 0600-198-01Z	0600-196-01Z 0600-198-01Z	06-035-01		GEN VISUAL	WING TO BODY FAIRINGS - AFT RIGHT
0600-200-01Z	0600-200-01Z	06-036-01		GEN VISUAL	UPPER HALF OF FUSELAGE-EXTERIOR
0600-211-01Z 0600-212-01Z	0600-211-01Z 0600-212-01Z	06-037-01		GEN VISUAL	CONTROL CABIN
0600-221-01Z 0600-222-01Z	0600-221-01Z 0600-222-01Z	06-038-01		GEN VISUAL	PASSENGER CABIN-SECTION 41
0600-221-02Z 0600-222-02Z	0600-221-02Z 0600-222-02Z	06-175-01		GEN VISUAL	MAIN CARGO DECK - SECTION 41
0600-221-03Z 0600-222-03Z	0600-221-03Z 0600-222-03Z	06-176-01		GEN VISUAL	***AREAS AROUND CREW ENTRY DOOR

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-223-01Z 0600-224-01Z	0600-223-01Z 0600-224-01Z	06-039-01		GEN VISUAL	AREA ABOVE CEILING PASS CABIN-SEC 41
0600-223-02Z 0600-224-02Z	0600-223-02Z 0600-224-02Z	06-177-01		GEN VISUAL	AREA ABOVE CEILING - SECTION 41
0600-231-01Z 0600-232-01Z	0600-231-01Z 0600-232-01Z	06-040-01		GEN VISUAL	PASSENGER CABIN - SECTION 43
0600-231-02Z 0600-232-02Z	0600-231-02Z 0600-232-02Z	06-178-01		GEN VISUAL	MAIN CARGO DECK - SECTION 43
0600-233-01Z 0600-234-01Z	0600-233-01Z 0600-234-01Z	06-041-01		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 43
0600-233-02Z 0600-234-02Z	0600-233-02Z 0600-234-02Z	06-179-01		GEN VISUAL	AREA ABOVE CEILING - SECTION 43
0600-241-01Z 0600-242-01Z	0600-241-01Z 0600-242-01Z	06-042-01		GEN VISUAL	PASSENGER CABIN-SECTION 45
0600-241-02Z 0600-242-02Z	0600-241-02Z 0600-242-02Z	06-180-01		GEN VISUAL	MAIN CARGO DECK - SECTION 45
0600-243-01Z 0600-244-01Z	0600-243-01Z 0600-244-01Z	06-043-01		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 45
0600-243-02Z 0600-244-02Z	0600-243-02Z 0600-244-02Z	06-181-01		GEN VISUAL	AREA ABOVE CEILING - SECTION 45
0600-251-01Z 0600-252-01Z	0600-251-01Z 0600-252-01Z	06-044-01		GEN VISUAL	PASSENGER CABIN - SECTION 46
0600-251-02Z 0600-252-02Z	0600-251-02Z 0600-252-02Z	06-182-01		GEN VISUAL	MAIN CARGO DECK - SECTION 46
0600-253-01Z 0600-254-01Z	0600-253-01Z 0600-254-01Z	06-045-01		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 46
0600-253-02Z 0600-254-02Z	0600-253-02Z 0600-254-02Z	06-183-01		GEN VISUAL	AREA ABOVE CEILING - SECTION 46
0600-311-01Z 0600-312-01Z	0600-311-01Z 0600-312-01Z	06-046-01		GEN VISUAL	AREAS AFT OF PRESS B/H TO BS 1725.5
0600-311-02Z 0600-312-02Z	0600-311-02Z 0600-312-02Z	06-046-02		GEN VISUAL	AREAS AFT OF PRESS B/H TO BS 1725.5
0600-313-01Z	0600-313-01Z	06-047-01		GEN VISUAL	STABILIZER TORSION BOX COMPT-LEFT
0600-314-01Z	0600-314-01Z	06-048-01		GEN VISUAL	STABILIZER TORSION BOX COMPT-RIGHT
0600-315-01Z 0600-316-01Z	0600-315-01Z 0600-316-01Z	06-049-01		GEN VISUAL	APU COMPARTMENT
0600-315-02Z 0600-316-02Z	0600-315-02Z 0600-316-02Z	06-050-01		GEN VISUAL	APU COMPARTMENT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-46



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-321-01Z	0600-321-01Z	06-051-01		GEN VISUAL	VERT STAB - REMOVABLE LEADING EDGE
0600-322-01Z	0600-322-01Z	06-052-01		GEN VISUAL	VERT STAB-AUX SPAR TO FRONT SPAR
0600-322-02Z	0600-322-02Z	06-053-01		GEN VISUAL	VERT STAB - AUX SPAR TO FRONT SPAR
0600-323-01Z	0600-323-01Z	06-054-01		GEN VISUAL	VERT STAB - FRONT SPAR TO REAR SPAR
0600-323-02Z	0600-323-02Z	06-055-01		GEN VISUAL	VERT STAB - FRONT SPAR TO REAR SPAR
0600-324-01Z	0600-324-01Z	06-056-01		GEN VISUAL	VERT STAB-REAR SPAR TO TRAILING EDGE
0600-324-02Z	0600-324-02Z	06-057-01		EX SURVEILL	VERT STAB-REAR SPAR TO TRAILING EDGE
0600-325-01Z	0600-325-01Z	06-058-01		GEN VISUAL	RUDDER
0600-326-01Z	0600-326-01Z	06-059-01		GEN VISUAL	VERT STABILIZER-TIP
0600-331-01Z	0600-331-01Z	06-060-01		GEN VISUAL	HORIZONTAL STAB CENTER SECTION
0600-341-01Z	0600-341-01Z				
0600-331-02Z	0600-331-02Z	06-061-01		GEN VISUAL	HORIZONTAL STAB CENTER SECTION
0600-341-02Z	0600-341-02Z				
0600-334-01Z	0600-334-01Z	06-062-01		GEN VISUAL	HORZ STAB-FRONT TO REAR SPAR
0600-344-01Z	0600-344-01Z				
0600-335-01Z	0600-335-01Z	06-063-01		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
0600-345-01Z	0600-345-01Z				
0600-335-02Z	0600-335-02Z	06-064-01		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
0600-345-02Z	0600-345-02Z				
0600-335-03Z	0600-335-03Z	06-065-01		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
0600-345-03Z	0600-345-03Z				
0600-338-01Z	0600-338-01Z	06-067-01		GEN VISUAL	HORIZONTAL STABILIZER-TIP
0600-348-01Z	0600-348-01Z				
0600-410-01Z	0600-410-01Z	06-157-01-1		GEN VISUAL	ENGINE 1
0600-410-02Z	0600-410-02Z	06-159-01-1		GEN VISUAL	ENGINE 1
0600-411-01Z	0600-411-01Z	06-068-01-1		GEN VISUAL	ENGINE 1
0600-411-01Z	0600-411-01Z	06-083-01-1		GEN VISUAL	ENGINE 1
0600-411-01Z	0600-411-01Z	06-161-01-1		GEN VISUAL	ENGINE 1 INSTALLATION
0600-411-02Z	0600-411-02Z	06-069-01-1		GEN VISUAL	ENGINE 1
0600-411-02Z	0600-411-02Z	06-084-01-1		GEN VISUAL	ENGINE 1
0600-411-02Z	0600-411-02Z	06-145-01-1	W-79-401-01-1	GEN VISUAL	ENGINE 1
0600-411-02Z	0600-411-02Z	06-162-01-1		GEN VISUAL	ENGINE 1
0600-412-01Z	0600-412-01Z	06-070-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-01Z	0600-412-01Z	06-085-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-01Z	0600-412-01Z	06-160-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-02Z	0600-412-02Z	06-071-01-1		GEN VISUAL	NOSE COWL - ENGINE 1

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-412-02Z	0600-412-02Z	06-086-01-1		GEN VISUAL	NOSE COWL - ENGINE 1
0600-412-02Z	0600-412-02Z	06-152-01-1		GEN VISUAL	ENGINE 1 NOSE COWL
0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z	06-072-01-1		GEN VISUAL	FAN COWL PANELS - ENGINE 1
0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z	06-087-01-1		GEN VISUAL	FAN COWL PANELS - ENGINE 1
0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z	06-146-01-1		GEN VISUAL	ENGINE 1 FAN COWL PANELS
0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z	06-163-01-1		GEN VISUAL	HINGED COWL INNER FACE - ENGINE 1
0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z	06-073-01-1		GEN VISUAL	THRUST REVERSERS - ENGINE 1
0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z	06-088-01-1		GEN VISUAL	THRUST REVERSERS - ENGINE 1
0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z	06-144-01-1		GEN VISUAL	ENGINE 1 THRUST REVERSERS
0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z	06-164-01-1		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 1
0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z	06-074-01-1		GEN VISUAL	THRUST REVERSERS - ENGINE 1
0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z	06-089-01-1		GEN VISUAL	THRUST REVERSERS - ENGINE 1
0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z	06-153-01-1		GEN VISUAL	ENGINE 1 THRUST REVERSERS
0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z	06-165-01-1		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 1
0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z	06-075-01-1		GEN VISUAL	CORE COWL PANELS - ENGINE 1
0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z	06-090-01-1		GEN VISUAL	CORE COWL PANELS - ENGINE 1
0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z	06-147-01-1		GEN VISUAL	ENGINE 1 CORE COWL PANELS
0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z	06-076-01-1		GEN VISUAL	CORE COWL PANELS - ENGINE 1
0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z	06-091-01-1		GEN VISUAL	CORE COWL PANELS - ENGINE 1
0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z	06-149-01-1		GEN VISUAL	ENGINE 1 CORE COWL PANELS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-48



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-420-01Z	0600-420-01Z	06-157-01-2		GEN VISUAL	ENGINE 2
0600-420-02Z	0600-420-02Z	06-159-01-2		GEN VISUAL	ENGINE 2
0600-421-01Z	0600-421-01Z	06-068-01-2		GEN VISUAL	ENGINE 2
0600-421-01Z	0600-421-01Z	06-083-01-2		GEN VISUAL	ENGINE 2
0600-421-01Z	0600-421-01Z	06-161-01-2		GEN VISUAL	ENGINE 2 INSTALLATION
0600-421-02Z	0600-421-02Z	06-069-01-2		GEN VISUAL	ENGINE 2
0600-421-02Z	0600-421-02Z	06-084-01-2		GEN VISUAL	ENGINE 2
0600-421-02Z	0600-421-02Z	06-145-01-2	W-79-401-01-2	GEN VISUAL	ENGINE 2
0600-421-02Z	0600-421-02Z	06-162-01-2		GEN VISUAL	ENGINE 2
0600-422-01Z	0600-422-01Z	06-070-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-01Z	0600-422-01Z	06-085-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-01Z	0600-422-01Z	06-160-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-02Z	0600-422-02Z	06-071-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-02Z	0600-422-02Z	06-086-01-2		GEN VISUAL	NOSE COWL - ENGINE 2
0600-422-02Z	0600-422-02Z	06-152-01-2		GEN VISUAL	ENGINE 2 NOSE COWL
0600-423-01Z	0600-423-01Z	06-072-01-2		GEN VISUAL	FAN COWL PANELS - ENGINE 2
0600-424-01Z	0600-424-01Z				
0600-423-01Z	0600-423-01Z	06-087-01-2		GEN VISUAL	FAN COWL PANELS - ENGINE 2
0600-424-01Z	0600-424-01Z				
0600-423-01Z	0600-423-01Z	06-146-01-2		GEN VISUAL	ENGINE 2 FAN COWL PANELS
0600-424-01Z	0600-424-01Z				
0600-423-01Z	0600-423-01Z	06-163-01-2		GEN VISUAL	HINGED COWL INNER FACE - ENGINE 2
0600-424-01Z	0600-424-01Z				
0600-425-01Z	0600-425-01Z	06-073-01-2		GEN VISUAL	THRUST REVERSERS - ENGINE 2
0600-426-01Z	0600-426-01Z				
0600-425-01Z	0600-425-01Z	06-088-01-2		GEN VISUAL	THRUST REVERSERS - ENGINE 2
0600-426-01Z	0600-426-01Z				
0600-425-01Z	0600-425-01Z	06-144-01-2		GEN VISUAL	ENGINE 2 THRUST REVERSERS
0600-426-01Z	0600-426-01Z				
0600-425-01Z	0600-425-01Z	06-164-01-2		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 2
0600-426-01Z	0600-426-01Z				
0600-425-02Z	0600-425-02Z	06-074-01-2		GEN VISUAL	THRUST REVERSERS - ENGINE 2
0600-426-02Z	0600-426-02Z				
0600-425-02Z	0600-425-02Z	06-089-01-2		GEN VISUAL	THRUST REVERSERS - ENGINE 2
0600-426-02Z	0600-426-02Z				
0600-425-02Z	0600-425-02Z	06-153-01-2		GEN VISUAL	ENGINE 2 THRUST REVERSERS
0600-426-02Z	0600-426-02Z				

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z	06-165-01-2		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 2
0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z	06-075-01-2		GEN VISUAL	CORE COWL PANELS - ENGINE 2
0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z	06-090-01-2		GEN VISUAL	CORE COWL PANELS - ENGINE 2
0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z	06-147-01-2		GEN VISUAL	ENGINE 2 CORE COWL PANELS
0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z	06-076-01-2		GEN VISUAL	CORE COWL PANELS - ENGINE 2
0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z	06-091-01-2		GEN VISUAL	CORE COWL PANELS - ENGINE 2
0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z	06-149-01-2		GEN VISUAL	ENGINE 2 CORE COWL PANELS
0600-430-01Z	0600-430-01Z	06-158-01-1	W-06-157-01-1	GEN VISUAL	STRUT 1
0600-430-02Z	0600-430-02Z	06-166-01-1		GEN VISUAL	STRUT NO. 1
0600-431-01Z	0600-431-01Z	06-077-01-1		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 1
0600-431-01Z	0600-431-01Z	06-092-01-1		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 1
0600-431-01Z	0600-431-01Z	06-148-01-1		GEN VISUAL	STRUT 1 FWD NACELLE STRUT FAIRING
0600-431-01Z	0600-431-01Z	06-167-01-1		GEN VISUAL	FORWARD FAIRING - STRUT 1
0600-432-01Z	0600-432-01Z	06-078-01-1		GEN VISUAL	FORWARD TORQUE BOX - STRUT 1
0600-432-01Z	0600-432-01Z	06-093-01-1		GEN VISUAL	FORWARD TORQUE BOX - STRUT 1
0600-432-01Z	0600-432-01Z	06-156-01-1		GEN VISUAL	STRUT 1 FORWARD TORQUE BOX
0600-432-01Z	0600-432-01Z	06-168-01-1		GEN VISUAL	UPPER STRUCTURE - STRUT 1
0600-433-01Z	0600-433-01Z	06-079-01-1		GEN VISUAL	UNDERWING FAIRING - STRUT 1
0600-433-01Z	0600-433-01Z	06-094-01-1		GEN VISUAL	UNDERWING FAIRING - STRUT 1
0600-433-01Z	0600-433-01Z	06-150-01-1		GEN VISUAL	STRUT 1 UNDERWING FAIRING
0600-433-01Z	0600-433-01Z	06-169-01-1		GEN VISUAL	MID STRUCTURE - STRUT 1
0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z	06-080-01-1		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 1
0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z	06-095-01-1		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 1
0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z	06-151-01-1		GEN VISUAL	STRUT 1 MID AND AFT TORQUE BOXES
0600-434-01Z	0600-434-01Z	06-170-01-1		GEN VISUAL	AFT FAIRING - STRUT 1
0600-435-01Z	0600-435-01Z	06-081-01-1		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 1

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-50



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-435-01Z	0600-435-01Z	06-096-01-1		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 1
0600-435-01Z	0600-435-01Z	06-155-01-1		GEN VISUAL	STRUT 1 CORE COWL SKIRT FAIRINGS
0600-437-01Z	0600-437-01Z	06-082-01-1		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 1
0600-437-01Z	0600-437-01Z	06-097-01-1		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 1
0600-437-01Z	0600-437-01Z	06-154-01-1		GEN VISUAL	STRUT 1 AFT NACELLE STRUT FAIRINGS
0600-440-01Z	0600-440-01Z	06-158-01-2	W-06-157-01-2	GEN VISUAL	STRUT 2
0600-440-02Z	0600-440-02Z	06-166-01-2		GEN VISUAL	STRUT NO. 2
0600-441-01Z	0600-441-01Z	06-077-01-2		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 2
0600-441-01Z	0600-441-01Z	06-092-01-2		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 2
0600-441-01Z	0600-441-01Z	06-148-01-2		GEN VISUAL	STRUT 2 FWD NACELLE STRUT FAIRING
0600-441-01Z	0600-441-01Z	06-167-01-2		GEN VISUAL	FORWARD FAIRING - STRUT 2
0600-442-01Z	0600-442-01Z	06-078-01-2		GEN VISUAL	FORWARD TORQUE BOX - STRUT 2
0600-442-01Z	0600-442-01Z	06-093-01-2		GEN VISUAL	FORWARD TORQUE BOX - STRUT 2
0600-442-01Z	0600-442-01Z	06-156-01-2		GEN VISUAL	STRUT 2 FORWARD TORQUE BOX
0600-442-01Z	0600-442-01Z	06-168-01-2		GEN VISUAL	UPPER STRUCTURE - STRUT 2
0600-443-01Z	0600-443-01Z	06-079-01-2		GEN VISUAL	UNDERWING FAIRING - STRUT 2
0600-443-01Z	0600-443-01Z	06-094-01-2		GEN VISUAL	UNDERWING FAIRING - STRUT 2
0600-443-01Z	0600-443-01Z	06-150-01-2		GEN VISUAL	STRUT 2 UNDERWING FAIRING
0600-443-01Z	0600-443-01Z	06-169-01-2		GEN VISUAL	MID STRUCTURE - STRUT 2
0600-444-01Z	0600-444-01Z	06-080-01-2		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 2
0600-446-01Z	0600-446-01Z				
0600-444-01Z	0600-444-01Z	06-095-01-2		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 2
0600-446-01Z	0600-446-01Z				
0600-444-01Z	0600-444-01Z	06-151-01-2		GEN VISUAL	STRUT 2 MID AND AFT TORQUE BOXES
0600-446-01Z	0600-446-01Z				
0600-444-01Z	0600-444-01Z	06-170-01-2		GEN VISUAL	AFT FAIRING - STRUT 2
0600-445-01Z	0600-445-01Z	06-081-01-2		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 2
0600-445-01Z	0600-445-01Z	06-096-01-2		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 2
0600-445-01Z	0600-445-01Z	06-155-01-2		GEN VISUAL	STRUT 2 CORE COWL SKIRT FAIRINGS
0600-447-01Z	0600-447-01Z	06-082-01-2		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 2
0600-447-01Z	0600-447-01Z	06-097-01-2		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 2
0600-447-01Z	0600-447-01Z	06-154-01-2		GEN VISUAL	STRUT 2 AFT NACELLE STRUT FAIRINGS
0600-511-01Z	0600-511-01Z	06-098-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD
0600-511-02Z	0600-511-02Z	06-099-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD
0600-511-03Z	0600-511-03Z	06-100-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-512-01Z	0600-512-01Z	06-101-01-1		GEN VISUAL	INBOARD SLAT (NO. 6) - LEFT WING
0600-513-01Z	0600-513-01Z	06-144-01		GEN VISUAL	KRUEGER FLAP - LEFT WING
0600-521-01Z	0600-521-01Z	06-102-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - OUTBOARD
0600-521-02Z	0600-521-02Z	06-103-01-1		GEN VISUAL	L WING LE TO FRONT SPAR - OUTBOARD
0600-522-01Z	0600-522-01Z	06-104-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 5) - LEFT WING
0600-522-02Z	0600-522-02Z	06-105-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 5) - LEFT WING
0600-523-01Z	0600-523-01Z	06-106-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 4) - LEFT WING
0600-523-02Z	0600-523-02Z	06-107-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 4) - LEFT WING
0600-524-01Z	0600-524-01Z	06-108-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 3) - LEFT WING
0600-524-02Z	0600-524-02Z	06-109-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 3) - LEFT WING
0600-525-01Z	0600-525-01Z	06-110-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 2) - LEFT WING
0600-525-02Z	0600-525-02Z	06-111-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 2) - LEFT WING
0600-526-01Z	0600-526-01Z	06-112-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 1) - LEFT WING
0600-526-02Z	0600-526-02Z	06-113-01-1		GEN VISUAL	OUTBOARD SLAT (NO. 1) - LEFT WING
0600-531-01Z	0600-531-01Z	06-114-01-1		GEN VISUAL	CENTER AUXILIARY TANK - LEFT WING
0600-532-01Z	0600-532-01Z	06-115-01-1		GEN VISUAL	MAIN TANK (INBD OF RIB 10)-LEFT WING
0600-533-01Z	0600-533-01Z	06-116-01-1		GEN VISUAL	DRY BAY - INBOARD LEFT WING
0600-541-01Z	0600-541-01Z	06-117-01-1		GEN VISUAL	MAIN TANK (OB OF RIB 10) - LEFT WING
0600-542-01Z	0600-542-01Z	06-118-01-1		GEN VISUAL	SURGE TANK - LEFT WING
0600-544-01Z	0600-544-01Z	06-119-01-1		GEN VISUAL	WING TIP - LEFT WING
0600-551-01Z	0600-551-01Z	06-120-01-1		GEN VISUAL	REAR SPAR TO MLG SUPPORT BEAM-L WING
0600-552-01Z	0600-552-01Z	06-121-01-1	W-06-123-01-1	GEN VISUAL	L MLG SUPT BEAM & REAR SPAR TO TE
0600-555-01Z	0600-555-01Z	06-122-01-1		GEN VISUAL	INBOARD TRAILING EDGE FLAP - L WING
0600-556-01Z	0600-556-01Z	06-123-01-1	W-06-121-01-1	GEN VISUAL	INBOARD AILERON - LEFT WING
0600-561-01Z	0600-561-01Z	06-124-01-1	W-06-125-01-1	GEN VISUAL	REAR SPAR TO WING TE - LEFT WING
0600-567-01Z	0600-567-01Z	06-125-01-1	W-06-124-01-1	GEN VISUAL	OUTBOARD AILERON - LEFT WING
0600-567-02Z	0600-567-02Z	06-126-01-1		GEN VISUAL	OUTBOARD AILERON - LEFT WING
0600-571-01Z	0600-571-01Z	06-127-01-1		GEN VISUAL	OB FLAP SUPPORT FAIRING - L IB FLAP
0600-572-01Z	0600-572-01Z	06-128-01-1		GEN VISUAL	IB FLAP SUPPORT FAIRING - L OB FLAP
0600-573-01Z	0600-573-01Z	06-129-01-1		GEN VISUAL	OB FLAP SUPPORT FAIRING - L OB FLAP
0600-611-01Z	0600-611-01Z	06-098-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD
0600-611-02Z	0600-611-02Z	06-099-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD
0600-611-03Z	0600-611-03Z	06-100-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD
0600-612-01Z	0600-612-01Z	06-101-01-2		GEN VISUAL	INBOARD SLAT (NO. 7) - RIGHT WING
0600-613-01Z	0600-613-01Z	06-144-02		GEN VISUAL	KRUEGER FLAP - RIGHT WING

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-621-01Z	0600-621-01Z	06-102-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - OUTBOARD
0600-621-02Z	0600-621-02Z	06-103-01-2		GEN VISUAL	R WING LE TO FRONT SPAR - OUTBOARD
0600-622-01Z	0600-622-01Z	06-104-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 8) - RIGHT WING
0600-622-02Z	0600-622-02Z	06-105-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 8) - RIGHT WING
0600-623-01Z	0600-623-01Z	06-106-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 9) - RIGHT WING
0600-623-02Z	0600-623-02Z	06-107-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 9) - RIGHT WING
0600-624-01Z	0600-624-01Z	06-108-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 10) - RIGHT WING
0600-624-02Z	0600-624-02Z	06-109-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 10) - RIGHT WING
0600-625-01Z	0600-625-01Z	06-110-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 11) - RIGHT WING
0600-625-02Z	0600-625-02Z	06-111-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 11) - RIGHT WING
0600-626-01Z	0600-626-01Z	06-112-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 12) - RIGHT WING
0600-626-02Z	0600-626-02Z	06-113-01-2		GEN VISUAL	OUTBOARD SLAT (NO. 12) - RIGHT WING
0600-631-01Z	0600-631-01Z	06-114-01-2		GEN VISUAL	CENTER AUXILIARY TANK - RIGHT WING
0600-632-01Z	0600-632-01Z	06-115-01-2		GEN VISUAL	MAIN TANK(INBD OF RIB 10)-RIGHT WING
0600-633-01Z	0600-633-01Z	06-116-01-2		GEN VISUAL	DRY BAY - INBOARD RIGHT WING
0600-641-01Z	0600-641-01Z	06-117-01-2		GEN VISUAL	MAIN TANK (OB OF RIB 10)- RIGHT WING
0600-642-01Z	0600-642-01Z	06-118-01-2		GEN VISUAL	SURGE TANK - RIGHT WING
0600-644-01Z	0600-644-01Z	06-119-01-2		GEN VISUAL	WING TIP - RIGHT WING
0600-651-01Z	0600-651-01Z	06-120-01-2		GEN VISUAL	REAR SPAR TO MLG SUPPORT BEAM-R WING
0600-652-01Z	0600-652-01Z	06-121-01-2	W-06-123-01-2	GEN VISUAL	R MLG SUPT BEAM & REAR SPAR TO TE
0600-655-01Z	0600-655-01Z	06-122-01-2		GEN VISUAL	INBOARD TRAILING EDGE FLAP - R WING
0600-656-01Z	0600-656-01Z	06-123-01-2	W-06-121-01-2	GEN VISUAL	INBOARD AILERON - RIGHT WING
0600-661-01Z	0600-661-01Z	06-124-01-2	W-06-125-01-2	GEN VISUAL	REAR SPAR TO WING TE - RIGHT WING
0600-667-01Z	0600-667-01Z	06-125-01-2	W-06-124-01-2	GEN VISUAL	OUTBOARD AILERON - RIGHT WING
0600-667-02Z	0600-667-02Z	06-126-01-2		GEN VISUAL	OUTBOARD AILERON - RIGHT WING
0600-671-01Z	0600-671-01Z	06-127-01-2		GEN VISUAL	OB FLAP SUPPORT FAIRING - R IB FLAP
0600-672-01Z	0600-672-01Z	06-128-01-2		GEN VISUAL	IB FLAP SUPPORT FAIRING - R OB FLAP
0600-673-01Z	0600-673-01Z	06-129-01-2		GEN VISUAL	OB FLAP SUPPORT FAIRING - R OB FLAP
0600-711-01Z	0600-711-01Z	06-130-01		GEN VISUAL	NOSE LANDING GEAR
0600-731-01Z	0600-731-01Z	06-131-01-1		GEN VISUAL	LEFT MAIN LANDING GEAR
0600-741-01Z	0600-741-01Z	06-131-01-2		GEN VISUAL	RIGHT MAIN LANDING GEAR
0600-811-01Z	0600-811-01Z	06-132-01		GEN VISUAL	BULK CARGO COMPARTMENT DOOR
0600-811-02Z	0600-811-02Z	06-133-01		GEN VISUAL	BULK CARGO COMPARTMENT DOOR
0600-821-01Z	0600-821-01Z	06-134-01		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR
0600-821-02Z	0600-821-02Z	06-135-01		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
0600-821-02Z	0600-821-02Z	06-135-02		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR
0600-822-01Z	0600-822-01Z	06-136-01		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
0600-822-02Z	0600-822-02Z	06-137-01		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
0600-822-02Z	0600-822-02Z	06-187-01		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
0600-831-01Z	0600-831-01Z	06-138-01		GEN VISUAL	PASS CABIN DOOR - FORWARD ENTRY
0600-831-01Z	0600-831-01Z	06-188-01		GEN VISUAL	CREW ENTRY DOOR - FORWARD ENTRY
0600-832-01Z	0600-832-01Z	06-139-01-1		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
0600-832-01Z	0600-832-01Z	06-139-02-1		GEN VISUAL	OVERWING EMERGENCY EXITS - LEFT
0600-834-01Z	0600-834-01Z				
0600-832-02Z	0600-832-02Z	06-140-01-1		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
0600-832-02Z	0600-832-02Z	06-140-02-1		GEN VISUAL	OVERWING EMERGENCY EXITS - LEFT
0600-834-02Z	0600-834-02Z				
0600-833-01Z	0600-833-01Z	06-141-01		GEN VISUAL	PASSENGER CABIN DOOR - AFT ENTRY
0600-834-01Z	0600-834-01Z	06-139-03-1		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
0600-834-02Z	0600-834-02Z	06-140-03-1		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
0600-835-01Z	0600-835-01Z	06-141-02		GEN VISUAL	PASS CABIN DOOR - CENTER ENTRY
0600-836-01Z	0600-836-01Z	06-173-01-1		GEN VISUAL	EMERGENCY EXIT DOOR - LEFT
0600-836-02Z	0600-836-02Z	06-174-01-2		GEN VISUAL	EMERGENCY EXIT DOOR - LEFT
0600-838-01Z	0600-838-01Z	06-184-01		GEN VISUAL	MAIN DECK CARGO COMPARTMENT DOOR
0600-838-02Z	0600-838-02Z	06-185-01		GEN VISUAL	MAIN DECK CARGO COMPARTMENT DOOR
0600-841-01Z	0600-841-01Z	06-142-01		GEN VISUAL	PASSENGER CABIN DOOR-FORWARD SERVICE
0600-842-01Z	0600-842-01Z	06-139-01-2		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
0600-842-01Z	0600-842-01Z	06-139-02-2		GEN VISUAL	OVERWING EMERGENCY EXITS - RIGHT
0600-844-01Z	0600-844-01Z				
0600-842-02Z	0600-842-02Z	06-140-01-2		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
0600-842-02Z	0600-842-02Z	06-140-02-2		GEN VISUAL	OVERWING EMERGENCY EXITS - RIGHT
0600-844-02Z	0600-844-02Z				
0600-843-01Z	0600-843-01Z	06-143-01		GEN VISUAL	PASSENGER CABIN DOOR - AFT SERVICE
0600-844-01Z	0600-844-01Z	06-139-03-2		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
0600-844-02Z	0600-844-02Z	06-140-03-2		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
0600-845-01Z	0600-845-01Z	06-143-02		GEN VISUAL	PASS CABIN DOOR - CENTER SERVICE
0600-846-01Z	0600-846-01Z	06-173-01-2		GEN VISUAL	EMERGENCY EXIT DOOR - RIGHT
0600-846-02Z	0600-846-02Z	06-174-01-1		GEN VISUAL	EMERGENCY EXIT DOOR - RIGHT
32-400-00	32-400-00	32-400-00		GEN VISUAL	NOSE LANDING GEAR
32-402-00	32-402-00	32-402-00		GEN VISUAL	NOSE LANDING GEAR ASSEMBLY

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-54



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
32-404-00	32-404-00	32-404-00		DETAILED EX	NOSE LANDING GEAR ASSEMBLY
32-406-00	32-406-00	32-406-00		GEN VISUAL	NOSE LANDING GEAR DOOR ASSEMBLY
32-408-00	32-408-00	32-408-00		GEN VISUAL	NOSE LG FWD AND AFT DOOR ASSEMBLY
32-410-00	32-410-00	32-410-00		RESTORE	LEFT MAIN LG AND COMPONENTS
32-412-00	32-412-00	32-412-00		GEN VISUAL	LEFT MAIN LANDING GEAR ASSEMBLY
32-414-00	32-414-00	32-414-00		DETAILED EX	LEFT MAIN LANDING GEAR ASSEMBLY
32-416-00	32-416-00	32-416-00		GEN VISUAL	LEFT MAIN LANDING GEAR ASSEMBLY
32-418-00	32-418-00	32-418-00		GEN VISUAL	LEFT MAIN LANDING GEAR BODY DOOR
32-420-00	32-420-00	32-420-00		GEN VISUAL	LEFT MAIN LANDING GEAR DOOR
32-422-00	32-422-00	32-422-00		DETAILED EX	L MAIN GEAR DOOR CENTER HINGE BEAM
32-424-00	32-424-00	32-424-00		RESTORE	RIGHT MAIN LANDING GEAR ASSEMBLY
32-426-00	32-426-00	32-426-00		GEN VISUAL	RIGHT MAIN LANDING GEAR ASSEMBLY
32-428-00	32-428-00	32-428-00		DETAILED EX	RIGHT MAIN LANDING GEAR ASSEMBLY
32-430-00	32-430-00	32-430-00		GEN VISUAL	RIGHT MAIN LANDING GEAR ASSEMBLY
32-432-00	32-432-00	32-432-00		GEN VISUAL	RIGHT MAIN LANDING GEAR BODY DOOR
32-434-00	32-434-00	32-434-00		GEN VISUAL	R MAIN LANDING GEAR DOOR ASSEMBLY
32-436-00	32-436-00	32-436-00		DETAILED EX	R MAIN GEAR DOOR CENTER HINGE BEAM
52-400-00	52-400-00	52-400-00		GEN VISUAL	BULK CARGO COMPARTMENT DOOR STOPS
52-402-00	52-402-00	52-402-00		GEN VISUAL	BULK CARGO COMPARTMENT DOOR
52-406-00	52-406-00	52-406-00		GEN VISUAL	FWD CARGO COMPARTMENT DOOR
52-408-00	52-408-00	52-408-00		GEN VISUAL	CARGO DOOR STOPS
52-410-00	52-410-00	52-410-00		GEN VISUAL	AFT CARGO DOOR
52-412-00	52-412-00	52-412-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-414-00	52-414-00	52-414-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-416-00	52-416-00	52-416-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-418-00	52-418-00	52-418-00		GEN VISUAL	OVERWING EMERGENCY EXIT HATCH
52-420-00	52-420-00	52-420-00		GEN VISUAL	EMERGENCY EXIT DOOR
52-422-00	52-422-00	52-422-00		GEN VISUAL	EMERGENCY EXIT DOOR
52-424-00	52-424-00	52-424-00		GEN VISUAL	CREW ENTRY DOOR
52-426-00	52-426-00	52-426-00		GEN VISUAL	CREW ENTRY DOORS
52-428-00	52-428-00	52-428-00		GEN VISUAL	CREW ENTRY DOOR
52-430-00	52-430-00	52-430-00		GEN VISUAL	MAIN DECK CARGO DOOR
53-400-00	53-400-00	53-400-00		GEN VISUAL	BODY FLOOR BEAMS BELOW LAVS/GALLEYS
53-402-00	53-402-00	53-402-00		GEN VISUAL	CARGO FLOOR STRUCTURE
53-404-00	53-404-00	53-404-00		DETAILED IN	CARGO DOOR CUTOUTS

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
53-406-00	53-406-00	53-406-00		GEN VISUAL	BODY EXTERNAL SKIN
53-408-00	53-408-00	53-408-00		DETAILED EX	LARGE FWD CARGO DOOR HINGES
53-410-00	53-410-00	53-410-00		GEN VISUAL	LWR BODY SKIN AT ANTENNA LOCATIONS
53-412-00	53-412-00	53-412-00		DETAILED EX	DOOR STOPS AND CUTOUTS
53-414-00	53-414-00	53-414-00		DETAILED IN	BODY STA. 132.5 BULKHEAD
53-416-00	53-416-00	53-416-00		GEN VISUAL	FUSELAGE LOWER LOBE
53-418-00	53-418-00	53-418-00		DETAILED IN	FWD EQUIP BAY ACCESS DOOR CUTOUT
53-420-00	53-420-00	53-420-00		GEN VISUAL	FUSELAGE EXTERIOR SURFACE
53-428-00	53-428-00	53-428-00		GEN VISUAL	NOSE LANDING GEAR WHEEL WELL
53-430-00	53-430-00	53-430-00		GEN VISUAL	AREA OUTBD & ABOVE NOSE WHEELWELL
53-432-00	53-432-00	53-432-00		DETAILED IN	BULKHEAD AND NOSE LANDING GEAR W/W
53-438-00	53-438-00	53-438-00		DETAILED IN	BODY FLOOR BEAM - STA 287
53-440-00	53-440-00	53-440-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-442-00	53-442-00	53-442-00		DETAILED IN	FWD ENTRY/SERVICE DOOR CUTOUTS
53-444-00	53-444-00	53-444-00		GEN VISUAL	MAIN EQUIPMENT CENTER ACCESS DOOR
53-446-00	53-446-00	53-446-00		DETAILED IN	MAIN EQUIPMENT CENTER
53-448-00	53-448-00	53-448-00		GEN VISUAL	MAIN EQUIPMENT CENTER ACCESS DOOR
53-450-00	53-450-00	53-450-00		DETAILED IN	BODY FLOOR BEAMS - STA 287 TO 347
53-452-00	53-452-00	53-452-00		GEN VISUAL	FUSELAGE LOWER LOBE
53-454-00	53-454-00	53-454-00		GEN VISUAL	LOWER LOBE INTERIOR - RIGHT
53-456-00	53-456-00	53-456-00		DETAILED IN	FORWARD CARGO DOOR LOWER SILL
53-458-00	53-458-00	53-458-00		DETAILED IN	FWD CARGO COMPARTMENT DOOR CUTOUT
53-460-00	53-460-00	53-460-00		DETAILED IN	BODY BELOW FWD CARGO COMPART FLOOR
53-462-00	53-462-00	53-462-00		DETAILED IN	BODY BELOW FWD CARGO FLOOR/STA 434
53-464-00	53-464-00	53-464-00		DETAILED IN	BODY BELOW FWD CARGO FLOOR
53-472-00	53-472-00	53-472-00		DETAILED IN	FWD LARGE CARGO DOOR CUTOUT
53-474-00	53-474-00	53-474-00		GEN VISUAL	AREA AFT OF FWD CARGO COMPARTMENT
53-476-00	53-476-00	53-476-00		GEN VISUAL	AREA AFT OF FWD CARGO COMPARTMENT
53-478-00	53-478-00	53-478-00		DETAILED IN	KEEL BEAM EXTENSION 738.5 - 785.9
53-480-00	53-480-00	53-480-00		DETAILED IN	BODY STA 785.9 BULKHEAD INNER CHORD
53-482-00	53-482-00	53-482-00		GEN VISUAL	FRONT SPAR BULKHEAD BELOW FLOOR
53-494-00	53-494-00	53-494-00		GEN VISUAL	INTERIOR FUSELAGE INSPECTION
53-496-00	53-496-00	53-496-00		DETAILED IN	WING CENTER SECTION UPPER SURFACE
53-502-00	53-502-00	53-502-00		GEN VISUAL	KEEL BEAM & WING CENTER SECTION
53-504-00	53-504-00	53-504-00		DETAILED IN	WING CENTER SECTION TENSION FITTING

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-56



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
53-506-00	53-506-00	53-506-00		GEN VISUAL	LOWER LOBE INTERIOR
53-508-00	53-508-00	53-508-00		DETAILED IN	BELOW FLOOR STRUCT - STA 955 TO 1065
53-510-00	53-510-00	53-510-00		DETAILED IN	BELOW FLOOR STRUCT - STA 955 TO 1065
53-518-00	53-518-00	53-518-00		GEN VISUAL	MAIN LANDING GEAR WHEEL WELL STRUCT
53-520-00	53-520-00	53-520-00		DETAILED IN	TRANSVERSE BEAMS
53-522-00	53-522-00	53-522-00		DETAILED IN	MAIN LANDING GEAR DOOR UPLOCK
53-524-00	53-524-00	53-524-00		DETAILED IN	REAR SPAR BULKHEAD AT WHEEL WELL
53-526-00	53-526-00	53-526-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-528-00	53-528-00	53-528-00		DETAILED IN	REAR SPAR AT KEEL BEAM
53-530-00	53-530-00	53-530-00		GEN VISUAL	MAIN LANDING GEAR WHEEL WELL STRUCT
53-532-00	53-532-00	53-532-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-534-00	53-534-00	53-534-00		DETAILED IN	MAIN LANDING GEAR DOOR UPLOCK
53-536-00	53-536-00	53-536-00		DETAILED IN	REAR SPAR BULKHEAD AT WHEEL WELL
53-538-00	53-538-00	53-538-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-540-00	53-540-00	53-540-00		GEN VISUAL	KEEL BEAM - AFT SECTION
53-542-00	53-542-00	53-542-00		GEN VISUAL	BODY FWD OF AFT CARGO COMPARTMENT
53-544-00	53-544-00	53-544-00		DETAILED IN	BODY FWD OF AFT CARGO COMPARTMENT
53-548-00	53-548-00	53-548-00		DETAILED IN	BODY FWD OF AFT CARGO COMPARTMENT
53-550-00	53-550-00	53-550-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-552-00	53-552-00	53-552-00		GEN VISUAL	CARGO COMPARTMENT
53-554-00	53-554-00	53-554-00		DETAILED IN	AFT CARGO DOOR LOWER SILL
53-556-00	53-556-00	53-556-00		DETAILED IN	AFT CARGO COMPARTMENT DOOR CUTOUT
53-558-00	53-558-00	53-558-00		DETAILED IN	BODY BELOW AFT CARGO COMPART FLOOR
53-560-00	53-560-00	53-560-00		DETAILED IN	BODY BELOW AFT CARGO FLOOR/STA 1307
53-562-00	53-562-00	53-562-00		DETAILED IN	FRAME UPPER CHORDS AT NUT PLATE
53-564-00	53-564-00	53-564-00		GEN VISUAL	FUSELAGE EXTERIOR SURFACE
53-572-00	53-572-00	53-572-00		GEN VISUAL	BULK CARGO COMPARTMENT
53-574-00	53-574-00	53-574-00		DETAILED IN	BULK CARGO DOOR LOWER SILL
53-576-00	53-576-00	53-576-00		DETAILED IN	AFT ENTRY/SERVICE DOOR CUTOUTS
53-578-00	53-578-00	53-578-00		GEN VISUAL	LOWER LOBE INTERIOR - RIGHT
53-582-00	53-582-00	53-582-00		DETAILED IN	AFT ENTRY/SERVICE DOOR CUTOUTS
53-584-00	53-584-00	53-584-00		DETAILED IN	BULK CARGO COMPARTMENT FLOOR & BELOW
53-586-00	53-586-00	53-586-00		DETAILED IN	LOWER LOBE INTERIOR BODY SKIN
53-588-00	53-588-00	53-588-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-590-00	53-590-00	53-590-00		GEN VISUAL	LOWER LOBE INTERIOR - LEFT

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
53-592-00	53-592-00	53-592-00		DETAILED IN	BODY BELOW FLOOR-REAR PRESSURE DOME
53-594-00	53-594-00	53-594-00		GEN VISUAL	FUSELAGE EXTERIOR
53-602-00	53-602-00	53-602-00		GEN VISUAL	UPPER WING/SIDE OF BODY SPLICE
53-606-00	53-606-00	53-606-00		DETAILED IN	OVERWING LONGERON
53-608-00	53-608-00	53-608-00		GEN VISUAL	UPPER WING/SIDE OF BODY SPLICE
53-610-00	53-610-00	53-610-00		GEN VISUAL	WING LWR SURFACE BL 62 -FAIRING EDGE
53-612-00	53-612-00	53-612-00		DETAILED IN	OVERWING LONGERON
53-614-00	53-614-00	53-614-00		GEN VISUAL	WING LWR SURF BL 62 - FAIRING EDGE
53-616-00	53-616-00	53-616-00		DETAILED IN	LWR SIDE OF BODY SPLICE PLATES
53-618-00	53-618-00	53-618-00		DETAILED IN	LWR WING SURFACE AT REAR SPAR CHORD
53-620-00	53-620-00	53-620-00		DETAILED IN	WING LWR REAR SPAR SPLICE FITTING
53-622-00	53-622-00	53-622-00		DETAILED IN	BL 70 UNDERWING LONGERON FITTING
53-624-00	53-624-00	53-624-00		GEN VISUAL	WING LWR SURFACE BL 62 -FAIRING EDGE
53-626-00	53-626-00	53-626-00		DETAILED IN	LWR SIDE OF BODY SPLICE PLATES
53-628-00	53-628-00	53-628-00		DETAILED IN	LWR WING SURFACE AT REAR SPAR CHORD
53-630-00	53-630-00	53-630-00		DETAILED IN	WING LWR REAR SPAR SPLICE FITTING
53-632-00	53-632-00	53-632-00		DETAILED IN	BL 70 UNDERWING LONGERON FITTING
53-634-00	53-634-00	53-634-00		GEN VISUAL	WING-TO-BODY FAIRING
53-636-00	53-636-00	53-636-00		GEN VISUAL	SKIN UNDER WING/BODY AFT FAIRING
53-638-00	53-638-00	53-638-00		GEN VISUAL	SKIN UNDER WING/BODY AFT L FAIRING
53-640-00	53-640-00	53-640-00		GEN VISUAL	SKIN UNDER WING/BODY AFT R FAIRING
53-642-00	53-642-00	53-642-00		GEN VISUAL	STRUCTURE FWD LAVS, GALLEYS & DOORS
53-644-00	53-644-00	53-644-00		GEN VISUAL	STRUCTURE CTR & AFT GAL, LAV & DOORS
53-646-00	53-646-00	53-646-00		GEN VISUAL	SEAT TRACKS
53-648-00	53-648-00	53-648-00		GEN VISUAL	BODY EXTERNAL SKIN
53-650-00	53-650-00	53-650-00		DETAILED EX	DOOR STOPS AND CUTOUTS
53-652-00	53-652-00	53-652-00		GEN VISUAL	MAIN DECK DOOR & HATCH INTERIORS
53-654-00	53-654-00	53-654-00		GEN VISUAL	CONTROL CABIN WINDSHIELD STRUCTURE
53-656-00	53-656-00	53-656-00		GEN VISUAL	CONTROL CABIN FLOOR STRUCTURE
53-662-00	53-662-00	53-662-00		GEN VISUAL	FUSELAGE UPPER LOBE INT STRUCTURE
53-664-00	53-664-00	53-664-00		DETAILED IN	FLIGHT DECK SECURITY DOOR
53-666-00	53-666-00	53-666-00		DETAILED IN	FWD ENTRY/SERVICE DOOR LOWER SILL
53-668-00	53-668-00	53-668-00		DETAILED IN	CREW ENTRY DOOR LOWER SILL
53-670-00	53-670-00	53-670-00		GEN VISUAL	CARGO FLOOR STRUCTURE - SHEAR WEB
53-674-00	53-674-00	53-674-00		DETAILED IN	FWD ENTRY/SERVICE DOOR LOWER SILL

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
53-678-00	53-678-00	53-678-00		GEN VISUAL	UPPER LOBE INTERIOR
53-682-00	53-682-00	53-682-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-684-00	53-684-00	53-684-00		DETAILED IN	MID-CABIN ENTRY/SVC DOOR LOWER SILL
53-686-00	53-686-00	53-686-00		DETAILED IN	MAIN DECK CARGO DOOR CUTOUT SILL
53-688-00	53-688-00	53-688-00		GEN VISUAL	MID ENTRY/SERVICE DOOR CUTOUTS
53-690-00	53-690-00	53-690-00		GEN VISUAL	MAIN DECK CARGO DOOR CUTOUT
53-692-00	53-692-00	53-692-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-694-00	53-694-00	53-694-00		DETAILED IN	MID-CABIN ENTRY/SVC DOOR LOWER SILL
53-696-00	53-696-00	53-696-00		GEN VISUAL	MID ENTRY/SERVICE DOOR CUTOUTS
53-698-00	53-698-00	53-698-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-700-00	53-700-00	53-700-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-704-00	53-704-00	53-704-00		GEN VISUAL	FUSELAGE UPPER LOBE INT
53-706-00	53-706-00	53-706-00		GEN VISUAL	PASS CABIN ABOVE CEILING 785-1065
53-710-00	53-710-00	53-710-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-712-00	53-712-00	53-712-00		DETAILED IN	AFT ENTRY/SERVICE DOOR LOWER SILL
53-714-00	53-714-00	53-714-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-716-00	53-716-00	53-716-00		DETAILED IN	AFT ENTRY/SERVICE DOOR LOWER SILL
53-718-00	53-718-00	53-718-00		GEN VISUAL	LARGE AFT CARGO DOOR CUTOUT
53-720-00	53-720-00	53-720-00		IN SURVEILL	FUSELAGE UPPER LOBE INT
53-726-00	53-726-00	53-726-00		DETAILED IN	AFT BODY, STA. 1702 - 1725.5
53-728-00	53-728-00	53-728-00		DETAILED IN	H STABILIZER TRIM ACTUATOR SUPPORT
53-730-00	53-730-00	53-730-00		GEN VISUAL	EXT SECTION 48, LEFT SIDE
53-732-00	53-732-00	53-732-00		DETAILED IN	AFT PRESSURE BULKHEAD - STA 1582
53-734-00	53-734-00	53-734-00		CHECK/INSP	VERTICAL STABILIZER ATTACH BOLT
53-740-00	53-740-00	53-740-00		GEN VISUAL	EXT OF SECTION 48, RIGHT SIDE
53-746-00	53-746-00	53-746-00		DETAILED IN	H STABILIZER PIVOT FITTINGS
53-748-00	53-748-00	53-748-00		DETAILED IN	BODY LONGERONS AT HORIZ STAB CUTOUT
53-750-00	53-750-00	53-750-00		GEN VISUAL	SECTION 48 EXTERIOR - LEFT
53-756-00	53-756-00	53-756-00		GEN VISUAL	SECTION 48 EXTERIOR - RIGHT
53-758-00	53-758-00	53-758-00		GEN VISUAL	APU COMPARTMENT EXTERNAL SURFACE
53-762-00	53-762-00	53-762-00		GEN VISUAL	SECTION 48 EXTERIOR
54-400-00	54-400-00	54-400-00		GEN VISUAL	POWERPLANT STRUT -#1 (GE)
54-402-00	54-402-00	54-402-00		GEN VISUAL	POWERPLANT STRUT - #1 (P&W)
54-404-00	54-404-00	54-404-00		GEN VISUAL	POWER PLANT STRUT - #1
54-406-00	54-406-00	54-406-00		GEN VISUAL	NACELLE STRUT NO. 1

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
54-408-00	54-408-00	54-408-00		GEN VISUAL	NO. 1 NACELLE STRUT
54-410-00	54-410-00	54-410-00		DETAILED EX	NACELLE STRUT NO. 1
54-412-00	54-412-00	54-412-00		DETAILED IN	STRUT 1 LOWER SPAR AND ENGINE MOUNTS
54-414-00	54-414-00	54-414-00		DETAILED IN	STRUT 1
54-416-00	54-416-00	54-416-00		GEN VISUAL	STRUT 1
54-418-00	54-418-00	54-418-00		GEN VISUAL	POWERPLANT STRUT - #1 (RR CONFIGURA
54-422-00	54-422-00	54-422-00		GEN VISUAL	STRUT 1
54-424-00	54-424-00	54-424-00		DETAILED IN	NACELLE STRUT NO. 1 FWD UPPER SPAR
54-426-00	54-426-00	54-426-00		GEN VISUAL	NACELLE STRUT NO. 1 - FWD TORQUE BOX
54-428-00	54-428-00	54-428-00		DETAILED IN	NACELLE STRUT NO. 1 - FWD TORQUE BOX
54-430-00	54-430-00	54-430-00		GEN VISUAL	STRUT 1 UPPER SPAR
54-432-00	54-432-00	54-432-00		DETAILED IN	STRUT 1 UPPER LINK
54-434-00	54-434-00	54-434-00		DETAILED IN	STRUT 1 UPPER LINK
54-436-00	54-436-00	54-436-00		DETAILED IN	NACELLE STRUT NO. 1 MID-SPAR FITTING
54-438-00	54-438-00	54-438-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
54-440-00	54-440-00	54-440-00		DETAILED IN	NACELLE STRUT NO. 1 MID-SPAR FITTING
54-442-00	54-442-00	54-442-00		DETAILED IN	STRUT 1 TORQUE BOX
54-444-00	54-444-00	54-444-00		GEN VISUAL	STRUT 1 AFT TORQUE BOX
54-446-00	54-446-00	54-446-00		GEN VISUAL	NACELLE STRUT 1-MID & AFT TORQUE BOX
54-448-00	54-448-00	54-448-00		DETAILED IN	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-450-00	54-450-00	54-450-00		DETAILED IN	STRUT 1 AFT TORQUE BOX
54-452-00	54-452-00	54-452-00		DETAILED IN	STRUT 1 AFT TORQUE BOX
54-458-00	54-458-00	54-458-00		DETAILED IN	NACELLE STRUT NO. 1 MID SPAR FITTING
54-460-00	54-460-00	54-460-00		DETAILED IN	NACELLE STRUT NO. 1 MID SPAR FITTING
54-462-00	54-462-00	54-462-00		DETAILED IN	LEFT NACELLE STRUT MID SPAR FITTING
54-464-00	54-464-00	54-464-00		DETAILED IN	LEFT NACELLE STRUT MID SPAR FITTING
54-466-00	54-466-00	54-466-00		GEN VISUAL	LEFT NACELLE STRUT/WING LWR SURFACE
54-468-00	54-468-00	54-468-00		DETAILED IN	LEFT NACELLE STRUT/WING LWR SURFACE
54-470-00	54-470-00	54-470-00		GEN VISUAL	POWERPLANT STRUT - #2 (GE CONFIGURAT
54-472-00	54-472-00	54-472-00		GEN VISUAL	POWERPLANT STRUT - #2
54-474-00	54-474-00	54-474-00		GEN VISUAL	POWERPLANT STRUT - #2
54-476-00	54-476-00	54-476-00		GEN VISUAL	NACELLE STRUT NO. 2
54-478-00	54-478-00	54-478-00		GEN VISUAL	NACELLE STRUT NO. 2
54-480-00	54-480-00	54-480-00		DETAILED EX	NACELLE STRUT NO. 2
54-482-00	54-482-00	54-482-00		DETAILED IN	STRUT 2 LOWER SPAR AND ENGINE MOUNTS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-60



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
54-484-00	54-484-00	54-484-00		DETAILED IN	STRUT 2
54-486-00	54-486-00	54-486-00		GEN VISUAL	STRUT 2
54-488-00	54-488-00	54-488-00		GEN VISUAL	POWERPLANT STRUT - #2
54-492-00	54-492-00	54-492-00		GEN VISUAL	STRUT 2 SKIN
54-494-00	54-494-00	54-494-00		DETAILED IN	NACELLE STRUT NO. 2 FWD UPPER SPAR
54-496-00	54-496-00	54-496-00		GEN VISUAL	NACELLE STRUT NO. 2 -FWD TORQUE BOX
54-498-00	54-498-00	54-498-00		DETAILED IN	NACELLE STRUT NO. 2 FWD TORQUE BOX
54-500-00	54-500-00	54-500-00		GEN VISUAL	STRUT 2 UPPER SPAR
54-502-00	54-502-00	54-502-00		DETAILED IN	NACELLE STRUT NO. 2 -FWD TORQUE BOX
54-504-00	54-504-00	54-504-00		DETAILED IN	STRUT 2 UPPER LINK
54-506-00	54-506-00	54-506-00		DETAILED IN	NACELLE STRUT NO. 2 MID-SPAR FITTING
54-508-00	54-508-00	54-508-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
54-510-00	54-510-00	54-510-00		DETAILED IN	NACELLE STRUT NO. 2 MID-SPAR FITTING
54-512-00	54-512-00	54-512-00		DETAILED IN	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-514-00	54-514-00	54-514-00		GEN VISUAL	NACELLE STRUT NO. 2 MID SPAR FITTING
54-520-00	54-520-00	54-520-00		DETAILED IN	STRUT 2 AFT TORQUE BOX
54-522-00	54-522-00	54-522-00		DETAILED IN	STRUT 2 AFT TORQUE BOX
54-524-00	54-524-00	54-524-00		GEN VISUAL	NACELLE STRUT MID & AFT TORQUE BOX
54-526-00	54-526-00	54-526-00		DETAILED IN	NO. 2 STRUT AFT ENG MOUNT BULKHEAD
54-528-00	54-528-00	54-528-00		DETAILED IN	NACELLE STRUT NO.2 -MID SPAR FITTING
54-530-00	54-530-00	54-530-00		DETAILED IN	NACELLE STRUT NO. 2 MID SPAR FITTING
54-532-00	54-532-00	54-532-00		DETAILED IN	RIGHT NACELLE STRUT MID SPAR FITTING
54-534-00	54-534-00	54-534-00		DETAILED IN	RIGHT NACELLE STRUT MID SPAR FITTING
54-536-00	54-536-00	54-536-00		GEN VISUAL	RIGHT NACELLE STRUT/WING LWR SURFACE
54-538-00	54-538-00	54-538-00		DETAILED IN	RIGHT NACELLE STRUT/WING LWR SURFACE
55-400-00	55-400-00	55-400-00		GEN VISUAL	VERTICAL STAB REMOVABLE LEADING EDGE
55-401-00	55-401-00	55-401-00		GEN VISUAL	VERTICAL STABILIZER EXTERIOR
55-402-00	55-402-00	55-402-00		GEN VISUAL	VERTICAL STAB REMOVABLE LEADING EDGE
55-404-00	55-404-00	55-404-00		GEN VISUAL	VERT STAB AUX SPAR TO FRONT SPAR
55-406-00	55-406-00	55-406-00		DETAILED	VERT STAB FIXED LEADING EDGE
55-408-00	55-408-00	55-408-00		GEN VISUAL	VERT STAB AUX SPAR TO FRONT SPAR
55-410-00	55-410-00	55-410-00		GEN VISUAL	VERT STAB FRONT SPAR TO REAR SPAR
55-412-00	55-412-00	55-412-00		DETAILED IN	VERT STAB FIN-TO-BODY FITTINGS
55-414-00	55-414-00	55-414-00		GEN VISUAL	VERTICAL STABILIZER INSPAR STRUCTURE
55-416-00	55-416-00	55-416-00		GEN VISUAL	VERT STAB FRONT SPAR TO REAR SPAR

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
55-418-00	55-418-00	55-418-00		DETAILED EX	VERTICAL STABILIZER INSPAR STRUCTURE
55-420-00	55-420-00	55-420-00		GEN VISUAL	VERTICAL STABILIZER TRAILING EDGE
55-422-00	55-422-00	55-422-00		GEN VISUAL	RUDDER
55-424-00	55-424-00	55-424-00		DETAILED EX	RUDDER
55-426-00	55-426-00	55-426-00		DETAILED EX	RUDDER
55-428-00	55-428-00	55-428-00		SPCL DETAIL	RUDDER
55-430-00	55-430-00	55-430-00		GEN VISUAL	VERTICAL STABILIZER TIP
55-432-00	55-432-00	55-432-00		GEN VISUAL	HORIZONTAL STABILIZER EXT - LEFT
55-434-00	55-434-00	55-434-00		GEN VISUAL	HORIZ STABILIZER CENTER SECTION
55-444-00	55-444-00	55-444-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-446-00	55-446-00	55-446-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-448-00	55-448-00	55-448-00		GEN VISUAL	HORIZONTAL STAB FIXED LEADING EDGE
55-450-00	55-450-00	55-450-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE - LWR
55-452-00	55-452-00	55-452-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE-UPPER
55-454-00	55-454-00	55-454-00		GEN VISUAL	HORIZ STAB FRONT TO REAR SPAR L & R
55-456-00	55-456-00	55-456-00		GEN VISUAL	HORIZ STAB OUTBOARD SECTION
55-458-00	55-458-00	55-458-00		GEN VISUAL	HORIZ STAB UPPER OUTBOARD SURFACE
55-460-00	55-460-00	55-460-00		GEN VISUAL	HORIZ STAB LOWER OUTBOARD SURFACE
55-462-00	55-462-00	55-462-00		DETAILED EX	HORIZ/STAB UPPER OUTBOARD SURFACE
55-464-00	55-464-00	55-464-00		GEN VISUAL	HORIZ STAB TRAILING EDGE
55-466-00	55-466-00	55-466-00	W-06-063-01	GEN VISUAL	HORIZ STAB TRAILING EDGE
55-468-00	55-468-00	55-468-00		GEN VISUAL	HORIZ STAB TRAIL EDGE UPPER SURFACE
55-470-00	55-470-00	55-470-00		GEN VISUAL	LEFT ELEVATOR INTERIOR
55-472-00	55-472-00	55-472-00		GEN VISUAL	LEFT ELEVATOR - INBOARD/OUTBOARD
55-474-00	55-474-00	55-474-00		DETAILED EX	ELEVATOR SPAR & HINGE FITTINGS
55-478-00	55-478-00	55-478-00		GEN VISUAL	LEFT ELEVATOR - INBOARD/OUTBOARD
55-480-00	55-480-00	55-480-00		DETAILED EX	ELEVATOR - OUTBOARD
55-484-00	55-484-00	55-484-00		SPCL DETAIL	ELEVATOR SPAR & ADJACENT STRUCTURE
55-486-00	55-486-00	55-486-00		GEN VISUAL	HORIZONTAL STABILIZER TIP
55-488-00	55-488-00	55-488-00		GEN VISUAL	HORIZONTAL STABILIZER EXT - RIGHT
55-490-00	55-490-00	55-490-00		DETAILED IN	HORIZ STABILIZER CENTER SECTION
55-492-00	55-492-00	55-492-00		DETAILED EX	HORIZ STAB JACKSCREW FITTING
55-494-00	55-494-00	55-494-00		DETAILED EX	HORIZONTAL STABILIZER PIVOT FITTINGS
55-496-00	55-496-00	55-496-00		DETAILED EX	HORIZ STAB CENTER SECTION REAR SPAR
55-498-00	55-498-00	55-498-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-62



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
55-500-00	55-500-00	55-500-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-502-00	55-502-00	55-502-00		GEN VISUAL	HORIZONTAL STAB FIXED LEADING EDGE
55-504-00	55-504-00	55-504-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE-UPPER
55-506-00	55-506-00	55-506-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE - LWR
55-508-00	55-508-00	55-508-00		GEN VISUAL	HORIZ STAB CAVITY
55-510-00	55-510-00	55-510-00		GEN VISUAL	HORIZ STAB OUTBOARD SECTION
55-512-00	55-512-00	55-512-00		GEN VISUAL	HORIZ STAB LOWER OUTBOARD SURFACE
55-514-00	55-514-00	55-514-00		GEN VISUAL	HORIZ STAB UPPER OUTBOARD SURFACE
55-516-00	55-516-00	55-516-00		DETAILED EX	HORIZ/STAB UPPER OUTBOARD SURFACE
55-518-00	55-518-00	55-518-00		GEN VISUAL	HORIZ STAB INTERIOR CAVITY
55-520-00	55-520-00	55-520-00	W-06-063-01	GEN VISUAL	HORIZ STAB TRAILING EDGE
55-522-00	55-522-00	55-522-00		GEN VISUAL	HORIZ STAB TRAIL EDGE UPPER SURFACE
55-524-00	55-524-00	55-524-00		GEN VISUAL	RIGHT ELEVATOR INTERIOR
55-526-00	55-526-00	55-526-00		GEN VISUAL	RIGHT ELEVATOR - INBOARD/OUTBOARD
55-528-00	55-528-00	55-528-00		DETAILED EX	RIGHT ELEVATOR SPAR & HINGE FITTINGS
55-532-00	55-532-00	55-532-00		GEN VISUAL	RIGHT ELEVATOR - INBOARD/OUTBOARD
55-538-00	55-538-00	55-538-00		SPCL DETAIL	ELEVATOR SPAR & ADJACENT STRUCTURE
55-540-00	55-540-00	55-540-00		GEN VISUAL	HORIZONTAL STABILIZER TIP
57-400-00	57-400-00	57-400-00		GEN VISUAL	WING CENTER SECTION
57-402-00	57-402-00	57-402-00		DETAILED IN	WING CENTER SECTION LWR SURF SPLICE
57-404-00	57-404-00	57-404-00		DETAILED IN	WING CENTER SECTION REAR SPAR CHORD
57-406-00	57-406-00	57-406-00		DETAILED IN	WING CENTER SECT SIDE OF BODY SPLICE
57-408-00	57-408-00	57-408-00		DETAILED IN	WING CENTER SECTION REAR SPAR WEB
57-410-00	57-410-00	57-410-00		DETAILED IN	WING CTR SECT SIDE OF BODY RIB WEB
57-412-00	57-412-00	57-412-00		DETAILED IN	WING CENTER SECTION LOWER SURF BL 70
57-414-00	57-414-00	57-414-00		GEN VISUAL	WING CTR SECT FUEL TANK DRY BAY AREA
57-416-00	57-416-00	57-416-00		DETAILED IN	WING CENTER SECT FUEL TANK WET BAY
57-418-00	57-418-00	57-418-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-420-00	57-420-00	57-420-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-422-00	57-422-00	57-422-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-424-00	57-424-00	57-424-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-426-00	57-426-00	57-426-00		DETAILED IN	WING CENTER SECTION LOWER SURF BL 70
57-428-00	57-428-00	57-428-00		GEN VISUAL	WING CENTER SECTION
57-458-00	57-458-00	57-458-00		GEN VISUAL	WING CENTER SECTION LOWER
57-460-00	57-460-00	57-460-00		GEN VISUAL	INBOARD FLAP SUPPORT STRUCTURE

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
57-464-00	57-464-00	57-464-00		GEN VISUAL	WING EXTERIOR - LEFT
57-466-00	57-466-00	57-466-00		GEN VISUAL	WING EXTERIOR - LEFT
57-468-00	57-468-00	57-468-00		GEN VISUAL	NACELLE STRUT NO. 1 AFT UPPER SPAR
57-470-00	57-470-00	57-470-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
57-472-00	57-472-00	57-472-00		GEN VISUAL	SLAT 6 LINK BRACE & ACTUATOR SUPPORT
57-474-00	57-474-00	57-474-00		GEN VISUAL	LEFT WING FIXED LE STRUCTURES
57-476-00	57-476-00	57-476-00		GEN VISUAL	LEFT WING FIXED LE STRUCTURE
57-478-00	57-478-00	57-478-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
57-480-00	57-480-00	57-480-00		GEN VISUAL	LE SLATS INTERIOR STRUCTURE
57-482-00	57-482-00	57-482-00		GEN VISUAL	LEFT SLAT/NACELLE SEAL KREUGER FLAP
57-486-00	57-486-00	57-486-00		GEN VISUAL	LEADING EDGE EXTERIOR - LEFT
57-488-00	57-488-00	57-488-00		GEN VISUAL	NO. 4 SLAT MAIN & AUXILIARY TRACKS
57-504-00	57-504-00	57-504-00		GEN VISUAL	LEFT WING INSPAR LWR SURFACE, EXT
57-506-00	57-506-00	57-506-00		GEN VISUAL	LEFT WING INSPAR LWR SURFACE
57-508-00	57-508-00	57-508-00		GEN VISUAL	LEFT WING INSPAR UPPER SURFACE
57-510-00	57-510-00	57-510-00		DETAILED EX	LEFT WING INSPAR UPPER SURFACE
57-512-00	57-512-00	57-512-00		DETAILED EX	LEFT WING INSPAR LWR SURFACE
57-514-00	57-514-00	57-514-00		DETAILED EX	LEFT WING INSPAR UPPER SURFACE
57-516-00	57-516-00	57-516-00		DETAILED IN	L WING LWR SURFACE SPANWISE SPLICE
57-518-00	57-518-00	57-518-00		DETAILED IN	L WING LWR SURF ACCESS HOLE CUTOUTS
57-520-00	57-520-00	57-520-00		DETAILED IN	L WING LWR SURFACE/SIDE OF BOX RIB
57-522-00	57-522-00	57-522-00		DETAILED IN	L WING REAR SPAR WEB & LOWER CHORD
57-524-00	57-524-00	57-524-00		DETAILED IN	L WING REAR SPAR LWR CHORD & RIB 1&3
57-526-00	57-526-00	57-526-00		DETAILED IN	LEFT WING SIDE OF BODY RIB WEB
57-528-00	57-528-00	57-528-00		DETAILED IN	SIDE OF BODY RIB LOWER CHORD CUTOUTS
57-530-00	57-530-00	57-530-00		GEN VISUAL	LEFT WING MAIN TANK
57-532-00	57-532-00	57-532-00		DETAILED IN	LEFT MLG TRUNNION BACKUP STRUCTURE
57-534-00	57-534-00	57-534-00		DETAILED IN	LEFT MLG BEAM BACKUP STRUCTURE
57-536-00	57-536-00	57-536-00		DETAILED IN	L WING NACELLE STRUT SUPPORT BACKUP
57-538-00	57-538-00	57-538-00		DETAILED IN	LEFT WING LWR SPAR CHORDS
57-540-00	57-540-00	57-540-00		DETAILED IN	L WING LWR SPANWISE SPLICE STRINGERS
57-542-00	57-542-00	57-542-00		DETAILED IN	L WING LWR SURF ACCESS HOLE CUTOUTS
57-544-00	57-544-00	57-544-00		DETAILED IN	NACELLE STRUT NO. 1 BACKUP STRUCTURE
57-546-00	57-546-00	57-546-00		DETAILED IN	L WING SPANWISE SPLICE STRINGER L-15
57-548-00	57-548-00	57-548-00		DETAILED IN	L WING FRONT SPAR LWR CHORD, RIB 7&9

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.2-64



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
57-550-00	57-550-00	57-550-00		GEN VISUAL	LEFT WING INBOARD DRY BAY
57-552-00	57-552-00	57-552-00		DETAILED IN	L TE FLAP SUPPORT BACKUP STRUCTURE
57-554-00	57-554-00	57-554-00		GEN VISUAL	LEFT WING OUTBOARD DRY BAY
57-556-00	57-556-00	57-556-00		GEN VISUAL	LEFT WING OUTBOARD DRY BAY
57-558-00	57-558-00	57-558-00		GEN VISUAL	WING TIP & OUTBD SIDE OF WBL 929 RIB
57-560-00	57-560-00	57-560-00		SPCL DETAIL	WING TIP RIB & OUTBD SIDE OF RIB 36
57-564-00	57-564-00	57-564-00		GEN VISUAL	L WING TE SUPPORT STRUCT & REAR SPAR
57-566-00	57-566-00	57-566-00		DETAILED IN	UPPER WING/SIDE OF BODY SPLICE
57-568-00	57-568-00	57-568-00		GEN VISUAL	LEFT WING TRAILING EDGE
57-570-00	57-570-00	57-570-00		GEN VISUAL	L MAIN GEAR DRAG BRACE & MLG BEAM
57-572-00	57-572-00	57-572-00		GEN VISUAL	LEFT WING TRAILING EDGE
57-576-00	57-576-00	57-576-00		GEN VISUAL	LEFT WING SPOILERS
57-578-00	57-578-00	57-578-00		GEN VISUAL	LEFT WING INBD TE FLAP BOX
57-580-00	57-580-00	57-580-00		GEN VISUAL	LEFT WING INBD TE FLAP BOX
57-582-00	57-582-00	57-582-00		SPCL DETAIL	LEFT INBOARD TE FLAP TORQUE TUBE
57-584-00	57-584-00	57-584-00		SPCL DETAIL	LEFT WING INBOARD TE FLAP BOX
57-586-00	57-586-00	57-586-00		GEN VISUAL	LEFT WING INBOARD TE FLAP
57-588-00	57-588-00	57-588-00		GEN VISUAL	LEFT INBOARD AILERON INTERIOR
57-590-00	57-590-00	57-590-00		GEN VISUAL	LEFT INBOARD AILERON
57-592-00	57-592-00	57-592-00		GEN VISUAL	LEFT INBOARD AILERON
57-594-00	57-594-00	57-594-00		DETAILED EX	LEFT INBOARD AILERON
57-596-00	57-596-00	57-596-00		GEN VISUAL	WING TE SUPPORT STRUCTURE/REAR SPAR
57-598-00	57-598-00	57-598-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP BOX
57-600-00	57-600-00	57-600-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP BOX
57-602-00	57-602-00	57-602-00		SPCL DETAIL	LEFT WING OUTBOARD TE FLAP BOX
57-604-00	57-604-00	57-604-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-606-00	57-606-00	57-606-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-608-00	57-608-00	57-608-00		SPCL DETAIL	LEFT WING OUTBOARD TE FLAP BOX
57-610-00	57-610-00	57-610-00		GEN VISUAL	LEFT OUTBOARD AILERON
57-612-00	57-612-00	57-612-00		DETAILED EX	LEFT OUTBOARD AILERON
57-614-00	57-614-00	57-614-00		DETAILED EX	OUTBD AILERON SPAR, HINGES, ACTUATOR
57-616-00	57-616-00	57-616-00		GEN VISUAL	LEFT WING INBOARD TE FLAP
57-618-00	57-618-00	57-618-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-620-00	57-620-00	57-620-00		GEN VISUAL	WING EXTERIOR - RIGHT
57-622-00	57-622-00	57-622-00		GEN VISUAL	WING EXTERIOR - RIGHT

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
57-624-00	57-624-00	57-624-00		GEN VISUAL	NACELLE STRUT NO. 2 AFT UPPER SPAR
57-626-00	57-626-00	57-626-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
57-628-00	57-628-00	57-628-00		GEN VISUAL	SLAT 7 LINK BRACE & ACTUATOR SUPPORT
57-634-00	57-634-00	57-634-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
57-636-00	57-636-00	57-636-00		GEN VISUAL	RIGHT WING LE SLATS - INTERIOR
57-638-00	57-638-00	57-638-00		GEN VISUAL	RIGHT SLAT/NACELLE SEAL KREUGER FLAP
57-642-00	57-642-00	57-642-00		GEN VISUAL	LEADING EDGE EXTERIOR - RIGHT
57-646-00	57-646-00	57-646-00		GEN VISUAL	NO. 9 SLAT MAIN & AUXILIARY TRACKS
57-648-00	57-648-00	57-648-00		GEN VISUAL	RIGHT WING FIXED LE STRUCTURE
57-650-00	57-650-00	57-650-00		GEN VISUAL	RIGHT WING FIXED LE STRUCTURE
57-662-00	57-662-00	57-662-00		GEN VISUAL	RIGHT WING INSPAR LWR SURFACE, EXT
57-664-00	57-664-00	57-664-00		GEN VISUAL	RIGHT WING INSPAR LWR SURFACE
57-666-00	57-666-00	57-666-00		GEN VISUAL	RIGHT WING INSPAR UPPER SURFACE
57-668-00	57-668-00	57-668-00		DETAILED EX	RIGHT WING INSPAR UPPER SURFACE
57-670-00	57-670-00	57-670-00		DETAILED EX	RIGHT WING INSPAR LWR SURFACE
57-672-00	57-672-00	57-672-00		DETAILED EX	RIGHT WING INSPAR UPPER SURFACE
57-674-00	57-674-00	57-674-00		DETAILED IN	R WING LWR SURFACE SPANWISE SPLICE
57-676-00	57-676-00	57-676-00		DETAILED IN	R WING LWR SURF ACCESS HOLE CUTOUTS
57-678-00	57-678-00	57-678-00		DETAILED IN	R WING LWR SURFACE/SIDE OF BODY RIB
57-680-00	57-680-00	57-680-00		DETAILED IN	R WING REAR SPAR WEB & LOWER CHORD
57-682-00	57-682-00	57-682-00		DETAILED IN	R WING REAR SPAR LWR CHORD RIB 1&3
57-684-00	57-684-00	57-684-00		DETAILED IN	RIGHT WING SIDE OF BODY RIB WEB
57-686-00	57-686-00	57-686-00		DETAILED IN	SIDE OF BODY RIB LOWER CHORD CUTOUTS
57-688-00	57-688-00	57-688-00		GEN VISUAL	RIGHT WING MAIN TANK
57-690-00	57-690-00	57-690-00		DETAILED IN	RIGHT MLG TRUNNION BACKUP STRUCTURE
57-692-00	57-692-00	57-692-00		DETAILED IN	RIGHT MLG BEAM BACKUP STRUCTURE
57-694-00	57-694-00	57-694-00		DETAILED IN	R WING NACELLE STRUT SUPPORT BACKUP
57-696-00	57-696-00	57-696-00		DETAILED IN	RIGHT WING LWR SPAR CHORDS
57-698-00	57-698-00	57-698-00		DETAILED IN	R WING LWR SPANWISE SPLICE STRINGERS
57-700-00	57-700-00	57-700-00		DETAILED IN	R WING LWR SURF ACCESS HOLE CUTOUTS
57-702-00	57-702-00	57-702-00		DETAILED IN	NACELLE STRUT NO. 2 BACKUP STRUCTURE
57-704-00	57-704-00	57-704-00		DETAILED IN	R WING SPANWISE SPLICE STRINGER L-15
57-706-00	57-706-00	57-706-00		DETAILED IN	R WING FRONT SPAR LWR CHORD, RIB 7&9
57-708-00	57-708-00	57-708-00		GEN VISUAL	RIGHT WING INBOARD DRY BAY
57-710-00	57-710-00	57-710-00		DETAILED IN	R TE FLAP SUPPORT BACKUP STRUCTURE

D622T001



767 MAINTENANCE PLANNING DATA

MRB ITEM NUMBER	MPD ITEM NUMBER	CARD NUMBER	RELATED TASK	TASK	767 APPENDIX E.2 SORTED BY MRB - MPD - CARD
					TITLE
57-712-00	57-712-00	57-712-00		GEN VISUAL	RIGHT WING OUTBOARD DRY BAY
57-714-00	57-714-00	57-714-00		GEN VISUAL	RIGHT WING OUTBOARD DRY BAY
57-716-00	57-716-00	57-716-00		GEN VISUAL	WING TIP & OUTBD SIDE OF WBL 929 RIB
57-718-00	57-718-00	57-718-00		SPCL DETAIL	WING TIP RIB & OUTBD SIDE OF RIB 36
57-722-00	57-722-00	57-722-00		GEN VISUAL	R WING TE SUPPORT STRUCT & REAR SPAR
57-724-00	57-724-00	57-724-00		DETAILED IN	UPPER WING/SIDE OF BODY SPLICE
57-726-00	57-726-00	57-726-00		GEN VISUAL	RIGHT WING TRAILING EDGE
57-728-00	57-728-00	57-728-00		GEN VISUAL	R MAIN GEAR DRAG BRACE MLG BEAM
57-730-00	57-730-00	57-730-00		GEN VISUAL	RIGHT WING TRAILING EDGE
57-734-00	57-734-00	57-734-00		GEN VISUAL	RIGHT WING SPOILERS
57-736-00	57-736-00	57-736-00		GEN VISUAL	RIGHT WING INBD TE FLAP BOX
57-738-00	57-738-00	57-738-00		GEN VISUAL	RIGHT WING INBD TE FLAP BOX
57-740-00	57-740-00	57-740-00		SPCL DETAIL	RIGHT INBOARD TE FLAP TORQUE TUBE
57-742-00	57-742-00	57-742-00		SPCL DETAIL	RIGHT WING INBOARD TE FLAP BOX
57-744-00	57-744-00	57-744-00		GEN VISUAL	RIGHT WING INBOARD TE FLAPS
57-746-00	57-746-00	57-746-00		GEN VISUAL	RIGHT INBOARD AILERON INTERIOR
57-748-00	57-748-00	57-748-00		GEN VISUAL	RIGHT INBOARD AILERON
57-750-00	57-750-00	57-750-00		GEN VISUAL	RIGHT INBOARD AILERON
57-752-00	57-752-00	57-752-00		DETAILED EX	RIGHT INBOARD AILERON
57-754-00	57-754-00	57-754-00		GEN VISUAL	R WING TE SUPPORT STRUC & REAR SPAR
57-756-00	57-756-00	57-756-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP BOX
57-758-00	57-758-00	57-758-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP BOX
57-760-00	57-760-00	57-760-00		SPCL DETAIL	RIGHT WING OUTBOARD TE FLAP BOX
57-762-00	57-762-00	57-762-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
57-764-00	57-764-00	57-764-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
57-766-00	57-766-00	57-766-00		SPCL DETAIL	RIGHT WING OUTBOARD TE FLAP BOX
57-768-00	57-768-00	57-768-00		GEN VISUAL	RIGHT OUTBOARD AILERON
57-770-00	57-770-00	57-770-00		DETAILED EX	RIGHT OUTBOARD AILERON
57-772-00	57-772-00	57-772-00		DETAILED EX	OUTBD AILERON SPAR, HINGES, ACTUATOR
57-774-00	57-774-00	57-774-00		GEN VISUAL	RIGHT WING INBOARD TE FLAP
57-776-00	57-776-00	57-776-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
71-600-00	71-600-00	71-600-00		DETAILED IN	NO. 1 POWERPLANT
71-602-00	71-602-00	71-602-00		GEN VISUAL	NO. 1 POWERPLANT
71-604-00	71-604-00	71-604-00		DETAILED IN	NO. 2 POWERPLANT
71-606-00	71-606-00	71-606-00		GEN VISUAL	NO. 2 POWERPLANT

D622T001



767 MAINTENANCE PLANNING DATA

THIS PAGE INTENTIONALLY LEFT BLANK



767 MAINTENANCE PLANNING DATA

G. TASKS SORTED BY TASK CARD ITEM NUMBER

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-001-01	0600-100-01Z	0600-100-01Z		GEN VISUAL	LOWER HALF OF FUSELAGE - EXTERIOR
06-002-01	0600-111-01Z	0600-111-01Z		GEN VISUAL	RADOME
06-003-01	0600-113-01Z 0600-114-01Z	0600-113-01Z 0600-114-01Z		GEN VISUAL	AREAS FORWARD OF NLG WHEEL WELL
06-004-01	0600-115-01Z 0600-116-01Z	0600-115-01Z 0600-116-01Z		GEN VISUAL	NOSE LANDING GEAR WHEEL WELL
06-005-01	0600-117-01Z 0600-118-01Z	0600-117-01Z 0600-118-01Z		GEN VISUAL	AREAS OUTBD AND ABOVE NLG WHEEL WELL
06-006-01	0600-119-01Z	0600-119-01Z		GEN VISUAL	MAIN EQUIPMENT CENTER
06-007-01	0600-119-02Z	0600-119-02Z		GEN VISUAL	MAIN EQUIPMENT CENTER
06-008-01	0600-121-01Z 0600-122-01Z	0600-121-01Z 0600-122-01Z		GEN VISUAL	FORWARD CARGO COMPARTMENT
06-009-01	0600-121-02Z 0600-122-02Z	0600-121-02Z 0600-122-02Z		GEN VISUAL	FORWARD CARGO COMPARTMENT
06-009-02	0600-121-02Z 0600-122-02Z	0600-121-02Z 0600-122-02Z		IN SURVEILL	FORWARD CARGO COMPARTMENT
06-010-01	0600-123-01Z 0600-124-01Z	0600-123-01Z 0600-124-01Z		GEN VISUAL	AREAS BELOW FWD CARGO COMPARTMENT
06-011-01	0600-125-01Z 0600-126-01Z	0600-125-01Z 0600-126-01Z		GEN VISUAL	AREAS AFT OF FWD CARGO COMPARTMENT
06-012-01	0600-131-01Z 0600-132-01Z	0600-131-01Z 0600-132-01Z		GEN VISUAL	AREAS ABOVE WING CENTER SECTION
06-012-02	0600-131-02Z 0600-132-02Z	0600-131-02Z 0600-132-02Z		GEN VISUAL	AREAS ABOVE WING CENTER SECTION
06-013-01	0600-133-01Z 0600-134-01Z	0600-133-01Z 0600-134-01Z		GEN VISUAL	WING CENTER SECTION
06-013-02	0600-133-01Z 0600-134-01Z	0600-133-01Z 0600-134-01Z		GEN VISUAL	WING CENTER SECTION
06-014-01	0600-135-01Z 0600-136-01Z	0600-135-01Z 0600-136-01Z		GEN VISUAL	ENVIRONMENTAL CONTROL SYSTEM BAYS
06-015-01	0600-141-01Z 0600-142-01Z	0600-141-01Z 0600-142-01Z		GEN VISUAL	AREAS ABOVE MLG WHEEL WELL

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-015-02	0600-141-02Z 0600-142-02Z	0600-141-02Z 0600-142-02Z		GEN VISUAL	AREAS ABOVE MLG WHEEL WELL
06-016-01	0600-143-01Z	0600-143-01Z		GEN VISUAL	LEFT MAIN WHEEL WELL
06-017-01	0600-144-01Z	0600-144-01Z		GEN VISUAL	RIGHT MAIN WHEEL WELL
06-018-01	0600-151-01Z 0600-152-01Z	0600-151-01Z 0600-152-01Z		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT
06-019-01	0600-151-02Z 0600-152-02Z	0600-151-02Z 0600-152-02Z		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT
06-019-02	0600-151-02Z 0600-152-02Z	0600-151-02Z 0600-152-02Z		IN SURVEILL	AREAS FWD OF AFT CARGO COMPARTMENT
06-020-01	0600-151-03Z 0600-152-03Z	0600-151-03Z 0600-152-03Z		GEN VISUAL	AREAS FWD OF AFT CARGO COMPARTMENT
06-020-02	0600-151-03Z 0600-152-03Z	0600-151-03Z 0600-152-03Z		IN SURVEILL	AREAS FWD OF AFT CARGO COMPARTMENT
06-021-01	0600-153-01Z	0600-153-01Z		GEN VISUAL	AFT CARGO COMPARTMENT - LEFT
06-022-01	0600-153-02Z	0600-153-02Z		GEN VISUAL	AFT CARGO COMPARTMENT - LEFT
06-022-02	0600-153-02Z	0600-153-02Z		IN SURVEILL	AFT CARGO COMPARTMENT - LEFT
06-023-01	0600-154-01Z	0600-154-01Z		GEN VISUAL	AFT CARGO COMPARTMENT - RIGHT
06-024-01	0600-154-02Z	0600-154-02Z		GEN VISUAL	AFT CARGO COMPARTMENT - RIGHT
06-024-02	0600-154-02Z	0600-154-02Z		IN SURVEILL	AFT CARGO COMPARTMENT - RIGHT
06-025-01	0600-155-01Z 0600-156-01Z	0600-155-01Z 0600-156-01Z		GEN VISUAL	AREAS BELOW AFT CARGO COMPARTMENT
06-026-01	0600-161-01Z	0600-161-01Z		GEN VISUAL	BULK CARGO COMPARTMENT - LEFT
06-027-01	0600-161-02Z	0600-161-02Z		GEN VISUAL	BULK CARGO COMPARTMENT - LEFT
06-027-02	0600-161-02Z	0600-161-02Z		IN SURVEILL	BULK CARGO COMPARTMENT - LEFT
06-028-01	0600-162-01Z	0600-162-01Z		GEN VISUAL	BULK CARGO COMPARTMENT - RIGHT
06-029-01	0600-162-02Z	0600-162-02Z		GEN VISUAL	BULK CARGO COMPARTMENT - RIGHT
06-029-02	0600-162-02Z	0600-162-02Z		IN SURVEILL	BULK CARGO COMPARTMENT - RIGHT
06-030-01	0600-163-01Z 0600-164-01Z	0600-163-01Z 0600-164-01Z		GEN VISUAL	AREAS BELOW BULK CARGO COMPARTMENT
06-031-01	0600-165-01Z 0600-166-01Z	0600-165-01Z 0600-166-01Z		GEN VISUAL	AREAS AFT OF BULK CARGO COMPARTMENT
06-032-01	0600-191-01Z 0600-193-01Z	0600-191-01Z 0600-193-01Z		GEN VISUAL	WING TO BODY FAIRINGS - FWD LEFT
06-033-01	0600-192-01Z 0600-194-01Z	0600-192-01Z 0600-194-01Z		GEN VISUAL	WING TO BODY FAIRINGS - FWD RIGHT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-2



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-034-01	0600-195-01Z 0600-197-01Z	0600-195-01Z 0600-197-01Z		GEN VISUAL	WING TO BODY FAIRINGS - AFT LEFT
06-035-01	0600-196-01Z 0600-198-01Z	0600-196-01Z 0600-198-01Z		GEN VISUAL	WING TO BODY FAIRINGS - AFT RIGHT
06-036-01	0600-200-01Z	0600-200-01Z		GEN VISUAL	UPPER HALF OF FUSELAGE-EXTERIOR
06-037-01	0600-211-01Z 0600-212-01Z	0600-211-01Z 0600-212-01Z		GEN VISUAL	CONTROL CABIN
06-038-01	0600-221-01Z 0600-222-01Z	0600-221-01Z 0600-222-01Z		GEN VISUAL	PASSENGER CABIN-SECTION 41
06-039-01	0600-223-01Z 0600-224-01Z	0600-223-01Z 0600-224-01Z		GEN VISUAL	AREA ABOVE CEILING PASS CABIN-SEC 41
06-040-01	0600-231-01Z 0600-232-01Z	0600-231-01Z 0600-232-01Z		GEN VISUAL	PASSENGER CABIN - SECTION 43
06-041-01	0600-233-01Z 0600-234-01Z	0600-233-01Z 0600-234-01Z		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 43
06-042-01	0600-241-01Z 0600-242-01Z	0600-241-01Z 0600-242-01Z		GEN VISUAL	PASSENGER CABIN-SECTION 45
06-043-01	0600-243-01Z 0600-244-01Z	0600-243-01Z 0600-244-01Z		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 45
06-044-01	0600-251-01Z 0600-252-01Z	0600-251-01Z 0600-252-01Z		GEN VISUAL	PASSENGER CABIN - SECTION 46
06-045-01	0600-253-01Z 0600-254-01Z	0600-253-01Z 0600-254-01Z		GEN VISUAL	AREA ABOVE PASS CABIN CEILING-SEC 46
06-046-01	0600-311-01Z 0600-312-01Z	0600-311-01Z 0600-312-01Z		GEN VISUAL	AREAS AFT OF PRESS B/H TO BS 1725.5
06-046-02	0600-311-02Z 0600-312-02Z	0600-311-02Z 0600-312-02Z		GEN VISUAL	AREAS AFT OF PRESS B/H TO BS 1725.5
06-047-01	0600-313-01Z	0600-313-01Z		GEN VISUAL	STABILIZER TORSION BOX COMPT-LEFT
06-048-01	0600-314-01Z	0600-314-01Z		GEN VISUAL	STABILIZER TORSION BOX COMPT-RIGHT
06-049-01	0600-315-01Z 0600-316-01Z	0600-315-01Z 0600-316-01Z		GEN VISUAL	APU COMPARTMENT
06-050-01	0600-315-02Z 0600-316-02Z	0600-315-02Z 0600-316-02Z		GEN VISUAL	APU COMPARTMENT
06-051-01	0600-321-01Z	0600-321-01Z		GEN VISUAL	VERT STAB - REMOVABLE LEADING EDGE
06-052-01	0600-322-01Z	0600-322-01Z		GEN VISUAL	VERT STAB-AUX SPAR TO FRONT SPAR
06-053-01	0600-322-02Z	0600-322-02Z		GEN VISUAL	VERT STAB - AUX SPAR TO FRONT SPAR
06-054-01	0600-323-01Z	0600-323-01Z		GEN VISUAL	VERT STAB - FRONT SPAR TO REAR SPAR

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-055-01	0600-323-02Z	0600-323-02Z		GEN VISUAL	VERT STAB - FRONT SPAR TO REAR SPAR
06-056-01	0600-324-01Z	0600-324-01Z		GEN VISUAL	VERT STAB-REAR SPAR TO TRAILING EDGE
06-057-01	0600-324-02Z	0600-324-02Z		EX SURVEILL	VERT STAB-REAR SPAR TO TRAILING EDGE
06-058-01	0600-325-01Z	0600-325-01Z		GEN VISUAL	RUDDER
06-059-01	0600-326-01Z	0600-326-01Z		GEN VISUAL	VERT STABILIZER-TIP
06-060-01	0600-331-01Z 0600-341-01Z	0600-331-01Z 0600-341-01Z		GEN VISUAL	HORIZONTAL STAB CENTER SECTION
06-061-01	0600-331-02Z 0600-341-02Z	0600-331-02Z 0600-341-02Z		GEN VISUAL	HORIZONTAL STAB CENTER SECTION
06-062-01	0600-334-01Z 0600-344-01Z	0600-334-01Z 0600-344-01Z		GEN VISUAL	HORZ STAB-FRONT TO REAR SPAR
06-063-01	0600-335-01Z 0600-345-01Z	0600-335-01Z 0600-345-01Z		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
06-064-01	0600-335-02Z 0600-345-02Z	0600-335-02Z 0600-345-02Z		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
06-065-01	0600-335-03Z 0600-345-03Z	0600-335-03Z 0600-345-03Z		GEN VISUAL	HORZ STAB-REAR SPAR TO STAB TE
06-067-01	0600-338-01Z 0600-348-01Z	0600-338-01Z 0600-348-01Z		GEN VISUAL	HORIZONTAL STABILIZER-TIP
06-068-01-1	0600-411-01Z	0600-411-01Z		GEN VISUAL	ENGINE 1
06-068-01-2	0600-421-01Z	0600-421-01Z		GEN VISUAL	ENGINE 2
06-069-01-1	0600-411-02Z	0600-411-02Z		GEN VISUAL	ENGINE 1
06-069-01-2	0600-421-02Z	0600-421-02Z		GEN VISUAL	ENGINE 2
06-070-01-1	0600-412-01Z	0600-412-01Z		GEN VISUAL	NOSE COWL - ENGINE 1
06-070-01-2	0600-422-01Z	0600-422-01Z		GEN VISUAL	NOSE COWL - ENGINE 2
06-071-01-1	0600-412-02Z	0600-412-02Z		GEN VISUAL	NOSE COWL - ENGINE 1
06-071-01-2	0600-422-02Z	0600-422-02Z		GEN VISUAL	NOSE COWL - ENGINE 2
06-072-01-1	0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z		GEN VISUAL	FAN COWL PANELS - ENGINE 1
06-072-01-2	0600-423-01Z 0600-424-01Z	0600-423-01Z 0600-424-01Z		GEN VISUAL	FAN COWL PANELS - ENGINE 2
06-073-01-1	0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z		GEN VISUAL	THRUST REVERSERS - ENGINE 1
06-073-01-2	0600-425-01Z 0600-426-01Z	0600-425-01Z 0600-426-01Z		GEN VISUAL	THRUST REVERSERS - ENGINE 2
06-074-01-1	0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z		GEN VISUAL	THRUST REVERSERS - ENGINE 1

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-074-01-2	0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z		GEN VISUAL	THRUST REVERSERS - ENGINE 2
06-075-01-1	0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z		GEN VISUAL	CORE COWL PANELS - ENGINE 1
06-075-01-2	0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z		GEN VISUAL	CORE COWL PANELS - ENGINE 2
06-076-01-1	0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z		GEN VISUAL	CORE COWL PANELS - ENGINE 1
06-076-01-2	0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z		GEN VISUAL	CORE COWL PANELS - ENGINE 2
06-077-01-1	0600-431-01Z	0600-431-01Z		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 1
06-077-01-2	0600-441-01Z	0600-441-01Z		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 2
06-078-01-1	0600-432-01Z	0600-432-01Z		GEN VISUAL	FORWARD TORQUE BOX - STRUT 1
06-078-01-2	0600-442-01Z	0600-442-01Z		GEN VISUAL	FORWARD TORQUE BOX - STRUT 2
06-079-01-1	0600-433-01Z	0600-433-01Z		GEN VISUAL	UNDERWING FAIRING - STRUT 1
06-079-01-2	0600-443-01Z	0600-443-01Z		GEN VISUAL	UNDERWING FAIRING - STRUT 2
06-080-01-1	0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 1
06-080-01-2	0600-444-01Z 0600-446-01Z	0600-444-01Z 0600-446-01Z		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 2
06-081-01-1	0600-435-01Z	0600-435-01Z		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 1
06-081-01-2	0600-445-01Z	0600-445-01Z		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 2
06-082-01-1	0600-437-01Z	0600-437-01Z		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 1
06-082-01-2	0600-447-01Z	0600-447-01Z		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 2
06-083-01-1	0600-411-01Z	0600-411-01Z		GEN VISUAL	ENGINE 1
06-083-01-2	0600-421-01Z	0600-421-01Z		GEN VISUAL	ENGINE 2
06-084-01-1	0600-411-02Z	0600-411-02Z		GEN VISUAL	ENGINE 1
06-084-01-2	0600-421-02Z	0600-421-02Z		GEN VISUAL	ENGINE 2
06-085-01-1	0600-412-01Z	0600-412-01Z		GEN VISUAL	NOSE COWL - ENGINE 1
06-085-01-2	0600-422-01Z	0600-422-01Z		GEN VISUAL	NOSE COWL - ENGINE 2
06-086-01-1	0600-412-02Z	0600-412-02Z		GEN VISUAL	NOSE COWL - ENGINE 1
06-086-01-2	0600-422-02Z	0600-422-02Z		GEN VISUAL	NOSE COWL - ENGINE 2
06-087-01-1	0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z		GEN VISUAL	FAN COWL PANELS - ENGINE 1
06-087-01-2	0600-423-01Z 0600-424-01Z	0600-423-01Z 0600-424-01Z		GEN VISUAL	FAN COWL PANELS - ENGINE 2

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-088-01-1	0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z		GEN VISUAL	THRUST REVERSERS - ENGINE 1
06-088-01-2	0600-425-01Z 0600-426-01Z	0600-425-01Z 0600-426-01Z		GEN VISUAL	THRUST REVERSERS - ENGINE 2
06-089-01-1	0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z		GEN VISUAL	THRUST REVERSERS - ENGINE 1
06-089-01-2	0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z		GEN VISUAL	THRUST REVERSERS - ENGINE 2
06-090-01-1	0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z		GEN VISUAL	CORE COWL PANELS - ENGINE 1
06-090-01-2	0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z		GEN VISUAL	CORE COWL PANELS - ENGINE 2
06-091-01-1	0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z		GEN VISUAL	CORE COWL PANELS - ENGINE 1
06-091-01-2	0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z		GEN VISUAL	CORE COWL PANELS - ENGINE 2
06-092-01-1	0600-431-01Z	0600-431-01Z		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 1
06-092-01-2	0600-441-01Z	0600-441-01Z		GEN VISUAL	FWD NACELLE STRUT FAIRING - STRUT 2
06-093-01-1	0600-432-01Z	0600-432-01Z		GEN VISUAL	FORWARD TORQUE BOX - STRUT 1
06-093-01-2	0600-442-01Z	0600-442-01Z		GEN VISUAL	FORWARD TORQUE BOX - STRUT 2
06-094-01-1	0600-433-01Z	0600-433-01Z		GEN VISUAL	UNDERWING FAIRING - STRUT 1
06-094-01-2	0600-443-01Z	0600-443-01Z		GEN VISUAL	UNDERWING FAIRING - STRUT 2
06-095-01-1	0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 1
06-095-01-2	0600-444-01Z 0600-446-01Z	0600-444-01Z 0600-446-01Z		GEN VISUAL	MID AND AFT TORQUE BOXES - STRUT 2
06-096-01-1	0600-435-01Z	0600-435-01Z		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 1
06-096-01-2	0600-445-01Z	0600-445-01Z		GEN VISUAL	CORE COWL SKIRT FAIRINGS - STRUT 2
06-097-01-1	0600-437-01Z	0600-437-01Z		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 1
06-097-01-2	0600-447-01Z	0600-447-01Z		GEN VISUAL	AFT NACELLE STRUT FAIRINGS - STRUT 2
06-098-01-1	0600-511-01Z	0600-511-01Z		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD
06-098-01-2	0600-611-01Z	0600-611-01Z		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD
06-099-01-1	0600-511-02Z	0600-511-02Z		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD
06-099-01-2	0600-611-02Z	0600-611-02Z		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD
06-100-01-1	0600-511-03Z	0600-511-03Z		GEN VISUAL	L WING LE TO FRONT SPAR - INBOARD
06-100-01-2	0600-611-03Z	0600-611-03Z		GEN VISUAL	R WING LE TO FRONT SPAR - INBOARD

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-6



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-101-01-1	0600-512-01Z	0600-512-01Z		GEN VISUAL	INBOARD SLAT (NO. 6) - LEFT WING
06-101-01-2	0600-612-01Z	0600-612-01Z		GEN VISUAL	INBOARD SLAT (NO. 7) - RIGHT WING
06-102-01-1	0600-521-01Z	0600-521-01Z		GEN VISUAL	L WING LE TO FRONT SPAR - OUTBOARD
06-102-01-2	0600-621-01Z	0600-621-01Z		GEN VISUAL	R WING LE TO FRONT SPAR - OUTBOARD
06-103-01-1	0600-521-02Z	0600-521-02Z		GEN VISUAL	L WING LE TO FRONT SPAR - OUTBOARD
06-103-01-2	0600-621-02Z	0600-621-02Z		GEN VISUAL	R WING LE TO FRONT SPAR - OUTBOARD
06-104-01-1	0600-522-01Z	0600-522-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 5) - LEFT WING
06-104-01-2	0600-622-01Z	0600-622-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 8) - RIGHT WING
06-105-01-1	0600-522-02Z	0600-522-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 5) - LEFT WING
06-105-01-2	0600-622-02Z	0600-622-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 8) - RIGHT WING
06-106-01-1	0600-523-01Z	0600-523-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 4) - LEFT WING
06-106-01-2	0600-623-01Z	0600-623-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 9) - RIGHT WING
06-107-01-1	0600-523-02Z	0600-523-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 4) - LEFT WING
06-107-01-2	0600-623-02Z	0600-623-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 9) - RIGHT WING
06-108-01-1	0600-524-01Z	0600-524-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 3) - LEFT WING
06-108-01-2	0600-624-01Z	0600-624-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 10) - RIGHT WING
06-109-01-1	0600-524-02Z	0600-524-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 3) - LEFT WING
06-109-01-2	0600-624-02Z	0600-624-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 10) - RIGHT WING
06-110-01-1	0600-525-01Z	0600-525-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 2) - LEFT WING
06-110-01-2	0600-625-01Z	0600-625-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 11) - RIGHT WING
06-111-01-1	0600-525-02Z	0600-525-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 2) - LEFT WING
06-111-01-2	0600-625-02Z	0600-625-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 11) - RIGHT WING
06-112-01-1	0600-526-01Z	0600-526-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 1) - LEFT WING
06-112-01-2	0600-626-01Z	0600-626-01Z		GEN VISUAL	OUTBOARD SLAT (NO. 12) - RIGHT WING
06-113-01-1	0600-526-02Z	0600-526-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 1) - LEFT WING
06-113-01-2	0600-626-02Z	0600-626-02Z		GEN VISUAL	OUTBOARD SLAT (NO. 12) - RIGHT WING
06-114-01-1	0600-531-01Z	0600-531-01Z		GEN VISUAL	CENTER AUXILIARY TANK - LEFT WING
06-114-01-2	0600-631-01Z	0600-631-01Z		GEN VISUAL	CENTER AUXILIARY TANK - RIGHT WING
06-115-01-1	0600-532-01Z	0600-532-01Z		GEN VISUAL	MAIN TANK (INBD OF RIB 10)-LEFT WING
06-115-01-2	0600-632-01Z	0600-632-01Z		GEN VISUAL	MAIN TANK(INBD OF RIB 10)-RIGHT WING
06-116-01-1	0600-533-01Z	0600-533-01Z		GEN VISUAL	DRY BAY - INBOARD LEFT WING
06-116-01-2	0600-633-01Z	0600-633-01Z		GEN VISUAL	DRY BAY - INBOARD RIGHT WING
06-117-01-1	0600-541-01Z	0600-541-01Z		GEN VISUAL	MAIN TANK (OB OF RIB 10) - LEFT WING
06-117-01-2	0600-641-01Z	0600-641-01Z		GEN VISUAL	MAIN TANK (OB OF RIB 10)- RIGHT WING
06-118-01-1	0600-542-01Z	0600-542-01Z		GEN VISUAL	SURGE TANK - LEFT WING

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-118-01-2	0600-642-01Z	0600-642-01Z		GEN VISUAL	SURGE TANK - RIGHT WING
06-119-01-1	0600-544-01Z	0600-544-01Z		GEN VISUAL	WING TIP - LEFT WING
06-119-01-2	0600-644-01Z	0600-644-01Z		GEN VISUAL	WING TIP - RIGHT WING
06-120-01-1	0600-551-01Z	0600-551-01Z		GEN VISUAL	REAR SPAR TO MLG SUPPORT BEAM-L WING
06-120-01-2	0600-651-01Z	0600-651-01Z		GEN VISUAL	REAR SPAR TO MLG SUPPORT BEAM-R WING
06-121-01-1	0600-552-01Z	0600-552-01Z	W-06-123-01-1	GEN VISUAL	L MLG SUPT BEAM & REAR SPAR TO TE
06-121-01-2	0600-652-01Z	0600-652-01Z	W-06-123-01-2	GEN VISUAL	R MLG SUPT BEAM & REAR SPAR TO TE
06-122-01-1	0600-555-01Z	0600-555-01Z		GEN VISUAL	INBOARD TRAILING EDGE FLAP - L WING
06-122-01-2	0600-655-01Z	0600-655-01Z		GEN VISUAL	INBOARD TRAILING EDGE FLAP - R WING
06-123-01-1	0600-556-01Z	0600-556-01Z	W-06-121-01-1	GEN VISUAL	INBOARD AILERON - LEFT WING
06-123-01-2	0600-656-01Z	0600-656-01Z	W-06-121-01-2	GEN VISUAL	INBOARD AILERON - RIGHT WING
06-124-01-1	0600-561-01Z	0600-561-01Z	W-06-125-01-1	GEN VISUAL	REAR SPAR TO WING TE - LEFT WING
06-124-01-2	0600-661-01Z	0600-661-01Z	W-06-125-01-2	GEN VISUAL	REAR SPAR TO WING TE - RIGHT WING
06-125-01-1	0600-567-01Z	0600-567-01Z	W-06-124-01-1	GEN VISUAL	OUTBOARD AILERON - LEFT WING
06-125-01-2	0600-667-01Z	0600-667-01Z	W-06-124-01-2	GEN VISUAL	OUTBOARD AILERON - RIGHT WING
06-126-01-1	0600-567-02Z	0600-567-02Z		GEN VISUAL	OUTBOARD AILERON - LEFT WING
06-126-01-2	0600-667-02Z	0600-667-02Z		GEN VISUAL	OUTBOARD AILERON - RIGHT WING
06-127-01-1	0600-571-01Z	0600-571-01Z		GEN VISUAL	OB FLAP SUPPORT FAIRING - L IB FLAP
06-127-01-2	0600-671-01Z	0600-671-01Z		GEN VISUAL	OB FLAP SUPPORT FAIRING - R IB FLAP
06-128-01-1	0600-572-01Z	0600-572-01Z		GEN VISUAL	IB FLAP SUPPORT FAIRING - L OB FLAP
06-128-01-2	0600-672-01Z	0600-672-01Z		GEN VISUAL	IB FLAP SUPPORT FAIRING - R OB FLAP
06-129-01-1	0600-573-01Z	0600-573-01Z		GEN VISUAL	OB FLAP SUPPORT FAIRING - L OB FLAP
06-129-01-2	0600-673-01Z	0600-673-01Z		GEN VISUAL	OB FLAP SUPPORT FAIRING - R OB FLAP
06-130-01	0600-711-01Z	0600-711-01Z		GEN VISUAL	NOSE LANDING GEAR
06-131-01-1	0600-731-01Z	0600-731-01Z		GEN VISUAL	LEFT MAIN LANDING GEAR
06-131-01-2	0600-741-01Z	0600-741-01Z		GEN VISUAL	RIGHT MAIN LANDING GEAR
06-132-01	0600-811-01Z	0600-811-01Z		GEN VISUAL	BULK CARGO COMPARTMENT DOOR
06-133-01	0600-811-02Z	0600-811-02Z		GEN VISUAL	BULK CARGO COMPARTMENT DOOR
06-134-01	0600-821-01Z	0600-821-01Z		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR
06-135-01	0600-821-02Z	0600-821-02Z		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR
06-135-02	0600-821-02Z	0600-821-02Z		GEN VISUAL	FORWARD CARGO COMPARTMENT DOOR
06-136-01	0600-822-01Z	0600-822-01Z		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
06-137-01	0600-822-02Z	0600-822-02Z		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
06-138-01	0600-831-01Z	0600-831-01Z		GEN VISUAL	PASS CABIN DOOR - FORWARD ENTRY
06-139-01-1	0600-832-01Z	0600-832-01Z		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-139-01-2	0600-842-01Z	0600-842-01Z		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
06-139-02-1	0600-832-01Z 0600-834-01Z	0600-832-01Z 0600-834-01Z		GEN VISUAL	OVERWING EMERGENCY EXITS - LEFT
06-139-02-2	0600-842-01Z 0600-844-01Z	0600-842-01Z 0600-844-01Z		GEN VISUAL	OVERWING EMERGENCY EXITS - RIGHT
06-139-03-1	0600-834-01Z	0600-834-01Z		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
06-139-03-2	0600-844-01Z	0600-844-01Z		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
06-140-01-1	0600-832-02Z	0600-832-02Z		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
06-140-01-2	0600-842-02Z	0600-842-02Z		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
06-140-02-1	0600-832-02Z 0600-834-02Z	0600-832-02Z 0600-834-02Z		GEN VISUAL	OVERWING EMERGENCY EXITS - LEFT
06-140-02-2	0600-842-02Z 0600-844-02Z	0600-842-02Z 0600-844-02Z		GEN VISUAL	OVERWING EMERGENCY EXITS - RIGHT
06-140-03-1	0600-834-02Z	0600-834-02Z		GEN VISUAL	OVERWING EMERGENCY EXIT - LEFT
06-140-03-2	0600-844-02Z	0600-844-02Z		GEN VISUAL	OVERWING EMERGENCY EXIT - RIGHT
06-141-01	0600-833-01Z	0600-833-01Z		GEN VISUAL	PASSENGER CABIN DOOR - AFT ENTRY
06-141-02	0600-835-01Z	0600-835-01Z		GEN VISUAL	PASS CABIN DOOR - CENTER ENTRY
06-142-01	0600-841-01Z	0600-841-01Z		GEN VISUAL	PASSENGER CABIN DOOR-FORWARD SERVICE
06-143-01	0600-843-01Z	0600-843-01Z		GEN VISUAL	PASSENGER CABIN DOOR - AFT SERVICE
06-143-02	0600-845-01Z	0600-845-01Z		GEN VISUAL	PASS CABIN DOOR - CENTER SERVICE
06-144-01-1	0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z		GEN VISUAL	ENGINE 1 THRUST REVERSERS
06-144-01-2	0600-425-01Z 0600-426-01Z	0600-425-01Z 0600-426-01Z		GEN VISUAL	ENGINE 2 THRUST REVERSERS
06-144-01	0600-513-01Z	0600-513-01Z		GEN VISUAL	KRUEGER FLAP - LEFT WING
06-144-02	0600-613-01Z	0600-613-01Z		GEN VISUAL	KRUEGER FLAP - RIGHT WING
06-145-01-1	0600-411-02Z	0600-411-02Z	W-79-401-01-1	GEN VISUAL	ENGINE 1
06-145-01-2	0600-421-02Z	0600-421-02Z	W-79-401-01-2	GEN VISUAL	ENGINE 2
06-146-01-1	0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z		GEN VISUAL	ENGINE 1 FAN COWL PANELS
06-146-01-2	0600-423-01Z 0600-424-01Z	0600-423-01Z 0600-424-01Z		GEN VISUAL	ENGINE 2 FAN COWL PANELS
06-147-01-1	0600-417-01Z 0600-418-01Z	0600-417-01Z 0600-418-01Z		GEN VISUAL	ENGINE 1 CORE COWL PANELS
06-147-01-2	0600-427-01Z 0600-428-01Z	0600-427-01Z 0600-428-01Z		GEN VISUAL	ENGINE 2 CORE COWL PANELS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-148-01-1	0600-431-01Z	0600-431-01Z		GEN VISUAL	STRUT 1 FWD NACELLE STRUT FAIRING
06-148-01-2	0600-441-01Z	0600-441-01Z		GEN VISUAL	STRUT 2 FWD NACELLE STRUT FAIRING
06-149-01-1	0600-417-02Z 0600-418-02Z	0600-417-02Z 0600-418-02Z		GEN VISUAL	ENGINE 1 CORE COWL PANELS
06-149-01-2	0600-427-02Z 0600-428-02Z	0600-427-02Z 0600-428-02Z		GEN VISUAL	ENGINE 2 CORE COWL PANELS
06-150-01-1	0600-433-01Z	0600-433-01Z		GEN VISUAL	STRUT 1 UNDERWING FAIRING
06-150-01-2	0600-443-01Z	0600-443-01Z		GEN VISUAL	STRUT 2 UNDERWING FAIRING
06-151-01-1	0600-434-01Z 0600-436-01Z	0600-434-01Z 0600-436-01Z		GEN VISUAL	STRUT 1 MID AND AFT TORQUE BOXES
06-151-01-2	0600-444-01Z 0600-446-01Z	0600-444-01Z 0600-446-01Z		GEN VISUAL	STRUT 2 MID AND AFT TORQUE BOXES
06-152-01-1	0600-412-02Z	0600-412-02Z		GEN VISUAL	ENGINE 1 NOSE COWL
06-152-01-2	0600-422-02Z	0600-422-02Z		GEN VISUAL	ENGINE 2 NOSE COWL
06-153-01-1	0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z		GEN VISUAL	ENGINE 1 THRUST REVERSERS
06-153-01-2	0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z		GEN VISUAL	ENGINE 2 THRUST REVERSERS
06-154-01-1	0600-437-01Z	0600-437-01Z		GEN VISUAL	STRUT 1 AFT NACELLE STRUT FAIRINGS
06-154-01-2	0600-447-01Z	0600-447-01Z		GEN VISUAL	STRUT 2 AFT NACELLE STRUT FAIRINGS
06-155-01-1	0600-435-01Z	0600-435-01Z		GEN VISUAL	STRUT 1 CORE COWL SKIRT FAIRINGS
06-155-01-2	0600-445-01Z	0600-445-01Z		GEN VISUAL	STRUT 2 CORE COWL SKIRT FAIRINGS
06-156-01-1	0600-432-01Z	0600-432-01Z		GEN VISUAL	STRUT 1 FORWARD TORQUE BOX
06-156-01-2	0600-442-01Z	0600-442-01Z		GEN VISUAL	STRUT 2 FORWARD TORQUE BOX
06-157-01-1	0600-410-01Z	0600-410-01Z		GEN VISUAL	ENGINE 1
06-157-01-2	0600-420-01Z	0600-420-01Z		GEN VISUAL	ENGINE 2
06-158-01-1	0600-430-01Z	0600-430-01Z	W-06-157-01-1	GEN VISUAL	STRUT 1
06-158-01-2	0600-440-01Z	0600-440-01Z	W-06-157-01-2	GEN VISUAL	STRUT 2
06-159-01-1	0600-410-02Z	0600-410-02Z		GEN VISUAL	ENGINE 1
06-159-01-2	0600-420-02Z	0600-420-02Z		GEN VISUAL	ENGINE 2
06-160-01-1	0600-412-01Z	0600-412-01Z		GEN VISUAL	NOSE COWL - ENGINE 1
06-160-01-2	0600-422-01Z	0600-422-01Z		GEN VISUAL	NOSE COWL - ENGINE 2
06-161-01-1	0600-411-01Z	0600-411-01Z		GEN VISUAL	ENGINE 1 INSTALLATION
06-161-01-2	0600-421-01Z	0600-421-01Z		GEN VISUAL	ENGINE 2 INSTALLATION
06-162-01-1	0600-411-02Z	0600-411-02Z		GEN VISUAL	ENGINE 1
06-162-01-2	0600-421-02Z	0600-421-02Z		GEN VISUAL	ENGINE 2

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-10



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-163-01-1	0600-413-01Z 0600-414-01Z	0600-413-01Z 0600-414-01Z		GEN VISUAL	HINGED COWL INNER FACE - ENGINE 1
06-163-01-2	0600-423-01Z 0600-424-01Z	0600-423-01Z 0600-424-01Z		GEN VISUAL	HINGED COWL INNER FACE - ENGINE 2
06-164-01-1	0600-415-01Z 0600-416-01Z	0600-415-01Z 0600-416-01Z		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 1
06-164-01-2	0600-425-01Z 0600-426-01Z	0600-425-01Z 0600-426-01Z		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 2
06-165-01-1	0600-415-02Z 0600-416-02Z	0600-415-02Z 0600-416-02Z		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 1
06-165-01-2	0600-425-02Z 0600-426-02Z	0600-425-02Z 0600-426-02Z		GEN VISUAL	THRUST REVERSER UNIT - ENGINE 2
06-166-01-1	0600-430-02Z	0600-430-02Z		GEN VISUAL	STRUT NO. 1
06-166-01-2	0600-440-02Z	0600-440-02Z		GEN VISUAL	STRUT NO. 2
06-167-01-1	0600-431-01Z	0600-431-01Z		GEN VISUAL	FORWARD FAIRING - STRUT 1
06-167-01-2	0600-441-01Z	0600-441-01Z		GEN VISUAL	FORWARD FAIRING - STRUT 2
06-168-01-1	0600-432-01Z	0600-432-01Z		GEN VISUAL	UPPER STRUCTURE - STRUT 1
06-168-01-2	0600-442-01Z	0600-442-01Z		GEN VISUAL	UPPER STRUCTURE - STRUT 2
06-169-01-1	0600-433-01Z	0600-433-01Z		GEN VISUAL	MID STRUCTURE - STRUT 1
06-169-01-2	0600-443-01Z	0600-443-01Z		GEN VISUAL	MID STRUCTURE - STRUT 2
06-170-01-1	0600-434-01Z	0600-434-01Z		GEN VISUAL	AFT FAIRING - STRUT 1
06-170-01-2	0600-444-01Z	0600-444-01Z		GEN VISUAL	AFT FAIRING - STRUT 2
06-173-01-1	0600-836-01Z	0600-836-01Z		GEN VISUAL	EMERGENCY EXIT DOOR - LEFT
06-173-01-2	0600-846-01Z	0600-846-01Z		GEN VISUAL	EMERGENCY EXIT DOOR - RIGHT
06-174-01-1	0600-846-02Z	0600-846-02Z		GEN VISUAL	EMERGENCY EXIT DOOR - RIGHT
06-174-01-2	0600-836-02Z	0600-836-02Z		GEN VISUAL	EMERGENCY EXIT DOOR - LEFT
06-175-01	0600-221-02Z 0600-222-02Z	0600-221-02Z 0600-222-02Z		GEN VISUAL	MAIN CARGO DECK - SECTION 41
06-176-01	0600-221-03Z 0600-222-03Z	0600-221-03Z 0600-222-03Z		GEN VISUAL	***AREAS AROUND CREW ENTRY DOOR
06-177-01	0600-223-02Z 0600-224-02Z	0600-223-02Z 0600-224-02Z		GEN VISUAL	AREA ABOVE CEILING - SECTION 41
06-178-01	0600-231-02Z 0600-232-02Z	0600-231-02Z 0600-232-02Z		GEN VISUAL	MAIN CARGO DECK - SECTION 43
06-179-01	0600-233-02Z 0600-234-02Z	0600-233-02Z 0600-234-02Z		GEN VISUAL	AREA ABOVE CEILING - SECTION 43

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
06-180-01	0600-241-02Z 0600-242-02Z	0600-241-02Z 0600-242-02Z		GEN VISUAL	MAIN CARGO DECK - SECTION 45
06-181-01	0600-243-02Z 0600-244-02Z	0600-243-02Z 0600-244-02Z		GEN VISUAL	AREA ABOVE CEILING - SECTION 45
06-182-01	0600-251-02Z 0600-252-02Z	0600-251-02Z 0600-252-02Z		GEN VISUAL	MAIN CARGO DECK - SECTION 46
06-183-01	0600-253-02Z 0600-254-02Z	0600-253-02Z 0600-254-02Z		GEN VISUAL	AREA ABOVE CEILING - SECTION 46
06-184-01	0600-838-01Z	0600-838-01Z		GEN VISUAL	MAIN DECK CARGO COMPARTMENT DOOR
06-185-01	0600-838-02Z	0600-838-02Z		GEN VISUAL	MAIN DECK CARGO COMPARTMENT DOOR
06-187-01	0600-822-02Z	0600-822-02Z		GEN VISUAL	AFT CARGO COMPARTMENT DOOR
06-188-01	0600-831-01Z	0600-831-01Z		GEN VISUAL	CREW ENTRY DOOR - FORWARD ENTRY
12-001-01	12-21-19-3A		W-25-020-01	LUBRICATE	OFF-WING ESCAPE SYSTEM
12-002-C1	12-21-04-3A 12-21-04-3B			LUBRICATE	ELEVATOR PCA'S & HINGES
12-003-C1	12-21-05-3A 12-21-05-3B			LUBRICATE	STABILIZER TRIM CONTROL SYSTEM
12-003-03	12-21-05-3C			LUBRICATE	STAB TRIM CONTROL MODULE ROD ENDS
12-004-C1	12-21-06-3A 12-21-06-3B			LUBRICATE	RUDDER PCA'S & HINGES
12-005-C1-1	12-21-07-3A 12-21-07-3B			LUBRICATE	L OUTBOARD AILERON PCA'S & HINGES
12-005-C1-2	12-21-07-3A 12-21-07-3B			LUBRICATE	R OUTBOARD AILERON PCA'S & HINGES
12-006-C1-1	12-21-07-3C 12-21-07-3D			LUBRICATE	LEFT INBOARD AILERON PCA'S & HINGES
12-006-C1-2	12-21-07-3C 12-21-07-3D			LUBRICATE	RIGHT INBOARD AILERON PCA'S & HINGES
12-006-03	12-21-07-3E			LUBRICATE	LH LCCA TORQUE TUBE ASSEMBLY
12-007-C1-1	12-21-08-3A 12-21-08-3B			LUBRICATE	L OUTBD SLAT MAIN/AUX TRACK ROLLERS
12-007-C1-2	12-21-08-3A 12-21-08-3B			LUBRICATE	R OUTBD SLAT MAIN/AUX TRACK ROLLERS
12-007-C1-3	12-21-08-3A			LUBRICATE	L OUTBD SLAT AUX TRACK ROLLERS
12-007-C1-4	12-21-08-3A			LUBRICATE	R OUTBD SLAT AUX TRACK ROLLERS
12-008-C1-1	12-21-08-3C 12-21-08-3D			LUBRICATE	L INBD SLAT MAIN/AUX TRACK ROLLERS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-12



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
12-008-C1-2	12-21-08-3C 12-21-08-3D			LUBRICATE	R INBD SLAT MAIN/AUX TRACK ROLLERS
12-008-03-1	12-21-08-3G			LUBRICATE	L OUTBD LE SLAT TRK HOUSE/DRAIN TUBE
12-008-03-2	12-21-08-3K			LUBRICATE	R OUTBD LE SLAT TRK HOUSE/DRAIN TUBE
12-009-01-1	12-21-08-3E			LUBRICATE	LEFT INBD LE SLAT SIDE BRACE LINK
12-009-01-2	12-21-08-3E			LUBRICATE	RIGHT INBD LE SLAT SIDE BRACE LINK
12-010-01-1	12-21-08-3F			LUBRICATE	LEFT LE SLAT DRIVE SHAFT COUPLINGS
12-010-01-2	12-21-08-3F			LUBRICATE	RIGHT LE SLAT DRIVE SHAFT COUPLINGS
12-011-C1-1	12-21-09-3A 12-21-09-3I			LUBRICATE	LEFT TE FLAP DRIVE SHAFT COUPLINGS
12-011-C1-2	12-21-09-3A 12-21-09-3I			LUBRICATE	RIGHT TE FLAP DRIVE SHAFT COUPLINGS
12-012-C1-1	12-21-09-3B 12-21-09-3C			LUBRICATE	L OUTBD TE FLAP DRIVE LINK/ROLLERS
12-012-C1-2	12-21-09-3B 12-21-09-3C			LUBRICATE	R OUTBD TE FLAP DRIVE LINK/ROLLERS
12-013-C1-1	12-21-09-3D 12-21-09-3E 12-21-09-3F			LUBRICATE	L INBD TE FLAP AFT FLAP MECHANISM
12-013-C1-2	12-21-09-3D 12-21-09-3E 12-21-09-3F			LUBRICATE	R INBD TE FLAP AFT FLAP MECHANISM
12-014-01-1	12-21-09-3G			LUBRICATE	L INBD TE FLAP DRIVE LINKAGE NO. 3
12-014-01-2	12-21-09-3G			LUBRICATE	R INBD TE FLAP DRIVE LINKAGE NO. 6
12-014-02-1	12-21-09-3H			LUBRICATE	L INBD TE FLAP DRIVE LINKAGES NO. 4
12-014-02-2	12-21-09-3H			LUBRICATE	R INBD TE FLAP DRIVE LINKAGE NO. 5
12-015-C1-1	12-21-10-3A 12-21-10-3B			LUBRICATE	L INBD SPOILER HINGES & PCA'S
12-015-C1-2	12-21-10-3A 12-21-10-3B			LUBRICATE	R INBD SPOILER HINGES & PCA'S
12-016-C1-1	12-21-10-3C 12-21-10-3D			LUBRICATE	L OUTBOARD SPOILER PCA'S AND HINGES
12-016-C1-2	12-21-10-3C 12-21-10-3D			LUBRICATE	R OUTBOARD SPOILER PCA'S AND HINGES
12-016-03-1	12-21-11-3A			LUBRICATE	LEFT MAIN LANDING GEAR BEAM
12-016-03-2	12-21-11-3A			LUBRICATE	RIGHT MAIN LANDING GEAR BEAM
12-016-04-1	12-21-11-3A			LUBRICATE	LEFT MAIN LANDING GEAR BEAM

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
12-016-04-2	12-21-11-3A			LUBRICATE	RIGHT MAIN LANDING GEAR BEAM
12-016-05-1	12-21-11-3A			LUBRICATE	LEFT MAIN LANDING GEAR BEAM
12-016-05-2	12-21-11-3A			LUBRICATE	RIGHT MAIN LANDING GEAR BEAM
12-016-06-1	12-21-11-3A			LUBRICATE	LEFT MAIN LANDING GEAR BEAM
12-016-06-2	12-21-11-3A			LUBRICATE	RIGHT MAIN LANDING GEAR BEAM
12-017-C1	12-21-12-3A 12-21-12-3B 12-21-12-3C 12-21-12-3D			LUBRICATE	NOSE GEAR ACTUATOR AND DRAG STRUT
12-018-C1	12-21-12-3E 12-21-12-3F 12-21-12-3G 12-21-12-3H 12-21-12-3I 12-21-12-3J			LUBRICATE	NOSE GEAR LOCK AND STEERING LINKAGES
12-019-C1	12-21-12-3K 12-21-12-3L 12-21-12-3M			LUBRICATE	N GEAR TRUNNION/STEER COLLAR & LINKS
12-020-C1	12-21-12-3N 12-21-12-3O 12-21-12-3P			LUBRICATE	N GEAR STEERING ACT/NUT & TOW FITING
12-021-C1	12-21-13-3A 12-21-13-3B 12-21-13-3C			LUBRICATE	N GEAR DOORS & OPERATING MECHANISM
12-022-C1-1	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F			LUBRICATE	L GEAR SIDE/DRAG BRACE / JURY STRUT
12-022-C1-2	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F			LUBRICATE	RT GEAR SIDE/DRAG BRACE / JURY STRUT

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-14



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
12-022-C2-1	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F			LUBRICATE	L GEAR SIDE/Drag BRACE / JURY STRUT
12-022-C2-2	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F			LUBRICATE	RT GEAR SIDE/Drag BRACE / JURY STRUT
12-022-C3-1	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3I 12-21-14-3P			LUBRICATE	L MAIN LANDING GEAR--UPPER END
12-022-C3-2	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3I 12-21-14-3P			LUBRICATE	R MAIN LANDING GEAR--UPPER END
12-022-C4-1	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3I 12-21-14-3P			LUBRICATE	L MAIN LANDING GEAR--UPPER END

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
12-022-C4-2	12-21-14-3A 12-21-14-3B 12-21-14-3C 12-21-14-3D 12-21-14-3E 12-21-14-3F 12-21-14-3I 12-21-14-3P			LUBRICATE	R MAIN LANDING GEAR--UPPER END
12-023-C1-1	12-21-14-3G		W-12-023-03-1	LUBRICATE	LEFT MAIN GEAR PIVOT PIN
12-023-C1-2	12-21-14-3G		W-12-023-03-2	LUBRICATE	RIGHT MAIN GEAR PIVOT PIN
12-023-C2-1	12-21-14-3L		W-12-023-03-1	LUBRICATE	LEFT MAIN GEAR BRAKE RODS
12-023-C2-2	12-21-14-3L		W-12-023-03-2	LUBRICATE	RIGHT MAIN GEAR BRAKE RODS
12-023-C3-1	12-21-14-3G 12-21-14-3L 12-21-14-3S			LUBRICATE	L PIVOT PIN/BRAKE RODS AND HOUSING
12-023-C3-2	12-21-14-3G 12-21-14-3L 12-21-14-3S			LUBRICATE	R PIVOT PIN/BRAKE RODS AND HOUSING
12-023-C4-1	12-21-14-3G 12-21-14-3L 12-21-14-3S			LUBRICATE	L PIVOT PIN/BRAKE RODS AND HOUSING
12-023-C4-2	12-21-14-3G 12-21-14-3L 12-21-14-3S			LUBRICATE	R PIVOT PIN/BRAKE RODS AND HOUSING
12-023-02-1	12-21-14-3H			LUBRICATE	L MAIN GEAR TORSION LINKS/UPLOCK FTG
12-023-02-2	12-21-14-3H			LUBRICATE	R MAIN GEAR TORSION LINKS/UPLOCK FTG
12-023-03-1	12-21-14-3Q		W-12-023-C1-1	LUBRICATE	LEFT MAIN GEAR TORQUE ARM
12-023-03-2	12-21-14-3Q		W-12-023-C1-2	LUBRICATE	RIGHT MAIN GEAR TORQUE ARM
12-023-04-1	12-21-14-3H			LUBRICATE	L MAIN GEAR TORSION LINKS/UPLOCK FTG
12-023-04-2	12-21-14-3H			LUBRICATE	R MAIN GEAR TORSION LINKS/UPLOCK FTG
12-023-05-1	12-21-14-3Q		W-12-023-C1-1	LUBRICATE	LEFT MAIN GEAR TORQUE ARM
12-023-05-2	12-21-14-3Q		W-12-023-C1-2	LUBRICATE	RIGHT MAIN GEAR TORQUE ARM
12-024-C1-1	12-21-14-3I 12-21-14-3K 12-21-14-3M 12-21-14-3N 12-21-14-3O 12-21-14-3P			LUBRICATE	LEFT MAIN GEAR

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
12-024-C1-2	12-21-14-3I 12-21-14-3K 12-21-14-3M 12-21-14-3N 12-21-14-3O 12-21-14-3P			LUBRICATE	RIGHT MAIN GEAR
12-024-C2-1	12-21-14-3I 12-21-14-3K 12-21-14-3M 12-21-14-3N 12-21-14-3O 12-21-14-3P			LUBRICATE	LEFT MAIN GEAR
12-024-C2-2	12-21-14-3I 12-21-14-3K 12-21-14-3M 12-21-14-3N 12-21-14-3O 12-21-14-3P			LUBRICATE	RIGHT MAIN GEAR
12-024-C3-1	12-21-14-3H 12-21-14-3M 12-21-14-3T			LUBRICATE	L MAIN LANDING GEAR--LOWER END
12-024-C3-2	12-21-14-3H 12-21-14-3M 12-21-14-3T			LUBRICATE	R MAIN LANDING GEAR--LOWER END
12-024-C4-1	12-21-14-3H 12-21-14-3M 12-21-14-3T			LUBRICATE	L MAIN LANDING GEAR--LOWER END
12-024-C4-2	12-21-14-3H 12-21-14-3M 12-21-14-3T			LUBRICATE	R MAIN LANDING GEAR--LOWER END
12-024-09-1	12-21-14-3R			LUBRICATE	LEFT MAIN GEAR AFT TRUNNION BUSHING
12-024-09-2	12-21-14-3R			LUBRICATE	R MAIN GEAR AFT TRUNNION BUSHING
12-024-10-1	12-21-14-3R			LUBRICATE	LEFT MAIN GEAR AFT TRUNNION BUSHING
12-024-10-2	12-21-14-3R			LUBRICATE	R MAIN GEAR AFT TRUNNION BUSHING
12-025-C1-1	12-21-15-3A 12-21-15-3B 12-21-15-3C 12-21-15-3D			LUBRICATE	L MAIN GEAR DOOR/ROLLER/HOOK/LINKAGE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
12-025-C1-2	12-21-15-3A 12-21-15-3B 12-21-15-3C 12-21-15-3D			LUBRICATE	R MAIN GEAR DOOR/ROLLER/HOOK/LINKAGE
12-025-C2-1	12-21-15-3A 12-21-15-3B 12-21-15-3C 12-21-15-3D			LUBRICATE	L MAIN GEAR DOOR/ROLLER/HOOK/LINKAGE
12-025-C2-2	12-21-15-3A 12-21-15-3B 12-21-15-3C 12-21-15-3D			LUBRICATE	R MAIN GEAR DOOR/ROLLER/HOOK/LINKAGE
12-025-C3-1	12-21-15-3A 12-21-15-3B 12-21-15-3C			LUBRICATE	L MAIN GEAR DOOR AND HINGES
12-025-C3-2	12-21-15-3A 12-21-15-3B 12-21-15-3C			LUBRICATE	R MAIN GEAR DOOR AND HINGES
12-025-C4-1	12-21-15-3A 12-21-15-3B 12-21-15-3C			LUBRICATE	L MAIN GEAR DOOR AND HINGES
12-025-C4-2	12-21-15-3A 12-21-15-3B 12-21-15-3C			LUBRICATE	R MAIN GEAR DOOR AND HINGES
12-026-C1	12-21-18-3A 12-21-18-3B			LUBRICATE	ENTRY/SERVICE DOORS
12-026-C2	12-21-18-3A 12-21-18-3B			LUBRICATE	ENTRY/SERVICE DOORS
12-027-C1	12-21-20-3A 12-21-20-3B 12-21-20-3C			LUBRICATE	OVERWING ESCAPE HATCH
12-027-C2	12-21-20-3A 12-21-20-3B 12-21-20-3C			LUBRICATE	OVERWING ESCAPE HATCH
12-027-C3	12-21-20-3A 12-21-20-3B 12-21-20-3C			LUBRICATE	OVERWING ESCAPE HATCH

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-18



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
12-028-C1	12-21-22-3A 12-21-22-3B 12-21-22-3C 12-21-22-3D			LUBRICATE	STD AFT CARGO DOOR MECHANISM
12-028-C2	12-21-22-3E 12-21-22-3K 12-21-22-3L			LUBRICATE	AFT CARGO DOOR STOPS & HOOK ROLLERS
12-028-C3	12-21-22-3B 12-21-22-3A 12-21-22-3C 12-21-22-3D			LUBRICATE	STD FORWARD CARGO DOOR MECHANISM
12-028-C4	12-21-22-3K 12-21-22-3E 12-21-22-3L			LUBRICATE	STD FWD CRGO DR STOPS & HOOK ROLLERS
12-029-C1	12-21-22-3F 12-21-22-3G 12-21-22-3I 12-21-22-3J			LUBRICATE	LARGE FWD CARGO DOOR
12-029-C2	12-21-22-3H 12-21-22-3P			LUBRICATE	LARGE CARGO DR HOOK SHAFT AND VENTS
12-030-C1	12-21-24-3A 12-21-24-3B			LUBRICATE	BULK CARGO DR PRES STOP/LATCH ROLLER
12-031-01	12-21-30-3A			LUBRICATE	RAT DEPLOYMENT SYSTEM
12-032-01-1	12-21-32-3A			LUBRICATE	LEFT WING NACELLE ATTACH FITTINGS
12-032-01-2	12-21-32-3A			LUBRICATE	RIGHT WING NACELLE ATTACH FITTINGS
12-032-02-1	12-21-32-3A			LUBRICATE	LEFT WING NACELLE ATTACH FITTINGS
12-032-02-2	12-21-32-3A			LUBRICATE	RIGHT WING NACELLE ATTACH FITTINGS
12-033-C1	12-21-33-3A 12-21-33-3B 12-21-33-3C			LUBRICATE	CONTAINERIZED CARGO HANDLING SYSTEM
12-033-C2	12-21-33-3B 12-21-33-3A			LUBRICATE	CONTAINERIZED CARGO HANDLING SYSTEM
12-034-01	12-21-27-3A			LUBRICATE	FWD EQUIPMENT BAY ACCESS DOOR
12-035-01	12-21-27-3B			LUBRICATE	E/E BAY ACCESS DOOR
12-036-01	12-21-27-3C			LUBRICATE	ECS BAY ACCESS DOORS
12-037-01	12-21-27-3D			LUBRICATE	AIR DRIVEN PUMP ACCESS DOOR

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
12-038-C1	12-21-27-3E 12-21-27-3F 12-21-27-3G			LUBRICATE	EXTERIOR SERVICE ACCESS DOORS
12-038-C2	12-21-27-3E 12-21-27-3F 12-21-27-3G			LUBRICATE	EXTERIOR SERVICE ACCESS DOORS
12-039-01	12-21-34-3A			LUBRICATE	NO. 2 SLIDING WINDOW - FLIGHT DECK
12-040-01	12-21-16-3A			LUBRICATE	TAIL SKID LEVER MECHANISM
12-041-01-1	12-21-35-3A			LUBRICATE	L T/R BALLSCREW ACTUATOR NUTS
12-041-01-2	12-21-35-3A			LUBRICATE	R T/R BALLSCREW ACTUATOR NUTS
12-042-01-1	12-21-36-3A			LUBRICATE	L T/R ROTARY FLEXIBLE DRIVE SHAFTS
12-042-01-2	12-21-36-3A			LUBRICATE	R T/R ROTARY FLEXIBLE DRIVE SHAFTS
12-043-01	12-21-21-3A			LUBRICATE	EMERGENCY EXIT DOORS
12-044-C1-1	12-21-17-3A 12-21-17-3B			LUBRICATE	LEFT WHEEL WELL SPHERICAL BEARINGS
12-044-C1-2	12-21-17-3A 12-21-17-3B			LUBRICATE	RIGHT WHEEL WELL SPHERICAL BEARINGS
12-045-01	12-21-25-3A			LUBRICATE	THRUST REVERSER LATCH LEVER
12-046-C1	12-21-22-3F 12-21-22-3G 12-21-22-3H 12-21-22-3I 12-21-22-3J 12-21-22-3M 12-21-22-3P			LUBRICATE	LARGE AFT CARGO DOOR
12-058-C1	12-21-23-3A 12-21-23-3B 12-21-23-3C 12-21-23-3D 12-21-23-3E			LUBRICATE	MAIN DECK CARGO DOOR
12-061-C1	12-21-18-3B 12-21-18-3A			LUBRICATE	CREW ENTRY DOOR
12-066-51	12-21-22-3M	12-066		LUBRICATE	LARGE FWD CARGO DOOR HINGE/HINGE PIN
20-001-01	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-02	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-03	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-04	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-20



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
20-001-11	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-12	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-13	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-14	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-21	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-22	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-23	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-001-24	20-20-02-6A			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-002-01	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-02	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-03	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-04	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-11	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-12	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-13	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-14	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-21	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-22	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-23	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-002-24	20-20-02-6B			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-003-01	20-20-02-6C			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-003-11	20-20-02-6C			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-003-21	20-20-02-6C			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-004-01-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-01-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-02-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-02-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-03-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-03-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-04-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-04-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-11-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-11-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-12-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-12-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
20-004-13-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-13-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-14-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-14-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-21-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-21-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-22-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-22-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-23-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-23-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-24-1	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-004-24-2	20-20-02-6D			CHECK/INSP	CONTROL CABLES - EXPOSED/UNPROTECTED
20-005-01	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-005-02	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-005-03	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-005-11	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-005-12	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-005-13	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-005-21	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-005-22	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-005-23	20-20-02-6E			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-006-01	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-006-02	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-006-03	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-006-11	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-006-12	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-006-13	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-006-21	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-006-22	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-006-23	20-20-02-6F			CHECK/INSP	CONTROL CABLE TURNS - LWR FUSELAGE
20-007-01	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-02	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-03	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-04	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-05	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
20-007-06	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-07	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-08	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-11	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-12	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-13	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-14	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-21	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-22	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-23	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-007-24	20-20-02-6G			CHECK/INSP	CONTROL CABLES - STRAIGHT RUNS
20-008-02	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-03	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-04	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-05	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-11	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - CREW CABIN
20-008-12	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-13	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-14	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-15	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-21	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - CREW CABIN
20-008-22	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-23	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-24	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-25	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-008-26	20-20-02-6H			CHECK/INSP	CONTROL CABLE TURNS - UPPER FUSELAGE
20-009-01	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-02	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-03	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-04	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-11	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-12	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-13	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-14	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-21	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
20-009-22	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-23	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-009-24	20-20-02-6I			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-01-1	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-01-2	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-02-1	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-02-2	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-03-1	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-03-2	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-11-1	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-11-2	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-12-1	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-12-2	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-21-1	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-21-2	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-22-1	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-010-22-2	20-20-02-6J			CHECK/INSP	CONTROL CABLES - PROTECTED
20-011-01-1	20-20-02-6K			CHECK/INSP	CONTROL CABLES - PROTECTED
20-011-01-2	20-20-02-6K			CHECK/INSP	CONTROL CABLES - PROTECTED
20-011-11-1	20-20-02-6K			CHECK/INSP	CONTROL CABLES - PROTECTED
20-011-11-2	20-20-02-6K			CHECK/INSP	CONTROL CABLES - PROTECTED
20-011-21-1	20-20-02-6K			CHECK/INSP	CONTROL CABLES - PROTECTED
20-011-21-2	20-20-02-6K			CHECK/INSP	CONTROL CABLES - PROTECTED
20-012-01	20-55-40-6A			SPCL DETAIL	RADIO ALTIMETER COAX CABLE
20-012-02	20-60-03-2B			CHECK/INSP	INSPECT EWIS
20-013-01	20-55-42-6A			SPCL DETAIL	L/HIRF FEATURES ON FCC, DCU, AND YSM
20-014-01	20-55-46-6A			SPCL DETAIL	DATA CONCENTRATOR UNIT (DCU) L/WING
20-015-01	20-55-47-6A			SPCL DETAIL	DATA CONCENTRATOR UNIT (DCU) R/WING
20-047-01	20-60-03-2D			CHECK/INSP	CENTER AUXILIARY TANKS LH
20-048-01	20-60-03-2E			CHECK/INSP	MAIN TANK LH
20-049-01	20-60-03-2F			CHECK/INSP	MAIN FUEL TANK LEFT HAND SIDE
20-050-01	20-60-03-2G			CHECK/INSP	SURGE TANK LEFT HAND SIDE
20-053-01	20-60-03-2I			CHECK/INSP	CENTER AUXILIARY TANKS RH
20-054-01	20-60-03-2J			CHECK/INSP	MAIN TANK RH
20-055-01	20-60-03-2K			CHECK/INSP	MAIN FUEL TANK RH

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-24



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
20-056-01	20-60-03-2L			CHECK/INSP	SURGE TANK RH
21-001-01	21-51-15-6A	21-001		CHECK/INSP	CABIN AIR SUPPLY CHECK VALVE
21-001-02	21-51-15-6A			CHECK/INSP	CABIN AIR SUPPLY CHECK VALVE
21-002-01	21-23-05-2A	21-002		CLEAN	RETURN AIR GRILLES/LOUVERS
21-002-02	21-23-05-2A			CLEAN	RETURN AIR GRILLES
21-002-03	21-23-05-2A			CLEAN	RETURN AIR GRILLES/LOUVERS
21-002-07	21-23-05-2A			CLEAN	RETURN AIR GRILLES/LOUVERS
21-003-02	21-25-02-4A			REPLACE	RECIRCULATION AIR PREFILTERS
21-003-03	21-25-02-4A			REPLACE	RECIRCULATION AIR PREFILTERS
21-003-04	21-25-02-4A			REPLACE	RECIRCULATION AIR PREFILTERS
21-003-05	21-25-02-4A			REPLACE	RECIRCULATION AIR PREFILTERS
21-004-01	21-25-02-4B			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-004-02	21-25-02-4B			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-004-03	21-25-02-4B			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-004-04	21-25-02-4B			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-004-05	21-25-02-4F			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-004-06	21-25-02-4F			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-004-07	21-25-02-4F			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-004-08	21-25-02-4F			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-005-01	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-02	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-04	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-05	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-08	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-09	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-10	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-11	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-12	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-005-13	21-61-09-4A			REPLACE	CABIN ZONE TEMPERATURE SENSOR FILTER
21-006-01	21-26-03-4A	21-006		REPLACE	GALLEY VENTILATION FILTERS
21-006-02	21-26-03-4A			REPLACE	GALLEY VENTILATION FILTERS
21-006-03	21-26-03-4A			REPLACE	GALLEY VENTILATION FILTERS
21-006-06	21-26-03-4A			REPLACE	GALLEY VENTILATION FILTERS
21-006-08	21-26-03-4A			REPLACE	GALLEY VENTILATION FILTERS
21-006-10	21-26-03-4A			REPLACE	GALLEY VENTILATION FILTERS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
21-007-C1	21-31-03-2A 21-31-03-2B		B-21-009-01	CLEAN/INSP	CABIN PRESSURE OUTFLOW VALVE
21-007-C4	21-31-03-2A 21-31-03-2B		B-21-009-04	CLEAN/INSP	CABIN PRESSURE OUTFLOW VALVE
21-009-01	21-31-00-5A	21-009	A-21-007-C1	OPERATIONAL	CABIN PRESSURE OUTFLOW VALVE
21-009-04	21-31-00-5A		A-21-007-C4	OPERATIONAL	CABIN PRESSURE OUTFLOW VALVE
21-010-01	21-32-01-5A	21-010		FUNCTIONAL	POSITIVE PRESSURE RELIEF VALVES
21-010-02	21-32-01-5A			FUNCTIONAL	POSITIVE PRESSURE RELIEF VALVES
21-011-01	21-32-02-4A	21-011	B-21-010-01	REPLACE	POSITIVE PRESS RELIEF VALVE FILTERS
21-011-02	21-32-02-4A		B-21-010-02	REPLACE	POSITIVE PRESS RELIEF VALVE FILTERS
21-012-01	21-33-00-5A	21-012		FUNCTIONAL	CABIN ALTITUDE WARNING SWITCH
21-012-04	21-33-00-5A			FUNCTIONAL	CABIN ALTITUDE WARNING SWITCH
21-013-01	21-43-00-5A	21-013	W-26-010-XX	OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-013-02	21-44-00-5A	21-013	W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-013-03	21-43-00-5C	21-013		OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-013-04	21-43-00-5A		W-26-010-XX	OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-013-05	21-44-00-5A		W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HTG SHUTOFF VALVES
21-013-06	21-44-00-5C	21-013		OPERATIONAL	AFT CARGO HEATING SHUTOFF VALVE
21-013-09	21-43-00-5A		W-26-010-XX	OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-013-10	21-44-00-5A		W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HTG SHUTOFF VALVES
21-013-11	21-44-00-5A	21-013		OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-014-01	21-43-00-5B	21-014		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-014-02	21-44-00-5B	21-014		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-014-04	21-43-00-5B			FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-014-05	21-44-00-5B			FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-014-06	21-44-00-5D	21-014		FUNCTIONAL	AFT CARGO TEMPERATURE SWITCHES
21-014-08	21-43-00-5B	21-014		FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-014-10	21-43-00-5B			FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-014-11	21-44-00-5B			FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-014-12	21-44-00-5B			FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-015-C1	21-51-00-5A 21-51-00-5B			OPERATIONAL	PACK TEMPERATURE CONTROLLERS
21-015-C2	21-51-00-5A 21-51-00-5B			OPERATIONAL	PACK TEMPERATURE CONTROLLERS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
21-015-C3	21-51-00-5A 21-51-00-5B			OPERATIONAL	PACK TEMPERATURE CONTROLLERS
21-015-C4	21-51-00-5A 21-51-00-5B			OPERATIONAL	PACK TEMPERATURE CONTROLLERS
21-017-01	21-51-02-7A	21-017		CLEAN	COOLING PACK HEAT EXCHANGERS
21-018-01	21-51-19-2A	21-018		FUNCTIONAL	COMPRESSOR OUTLET OVERHEAT SWITCH
21-019-01	21-51-18-2A	21-019		FUNCTIONAL	PACK OVERHEAT SWITCH
21-020-CM	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C1	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C2	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C3	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C4	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C5	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C6	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C6	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C7	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-C9	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-02	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-03	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-020-04	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-020-05	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-020-06	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-020-07	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-020-11	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
21-020-12	21-58-00-5A 21-58-00-5B			OPERATIONAL	OVERRIDE/MANIFOLD INTERCONNECT VALVE
21-021-01	21-58-02-6A	21-021	B-21-024-01	CHECK/INSP	E/E COOLING SUP/EXH FAN CHECK VALVES
21-021-02	21-58-02-6A		B-21-024-02	CHECK/INSP	E/E COOLING SUP/EXH FAN CHECK VALVES
21-023-01	21-58-21-4A	21-023		FUNCTIONAL	E/E COOLING SKIN TEMPERATURE SENSOR
21-023-02	21-58-21-4A			FUNCTIONAL	E/E COOLING SKIN TEMPERATURE SENSOR
21-024-01	21-58-22-2A	21-024	A-21-021-01	CHECK/INSP	E/E COOLING SYSTEM CONICAL SCREENS
21-025-C1	21-61-01-4A		W-21-025-01	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-C4	21-61-01-4A		W-21-025-04	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-C5	21-61-01-4A		W-21-025-05	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-C9	21-61-01-4A		W-21-025-09	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-D1	21-61-01-4A		W-21-025-10	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-01	21-61-00-5A	21-025	W-21-025-C1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-04	21-61-00-5A		W-21-025-C4	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-05	21-61-00-5A		W-21-025-05	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-09	21-61-00-5A		W-21-025-C9	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-025-10	21-61-00-5A		W-21-025-D1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-026-51	21-58-00-5D	21-026		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-52	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-53	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-54	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-55	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-56	21-58-00-5D	21-026		OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-56	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-57	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-59	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-60	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-61	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-026-62	21-58-00-5D			OPERATIONAL	E/E COOLING SYSTEM EQUIP COOL TEST
21-027-51	21-58-34-2A	21-027		OPERATIONAL	E/E COOLING LOW FLOW MONITOR SYSTEM
21-027-52	21-58-34-2A			OPERATIONAL	E/E COOLING LOW FLOW MONITOR SYSTEM
21-028-51	21-58-32-2A	21-028	B-21-034-01	OPERATIONAL	INSTRUMENT COOLING (ELECT) MONITORS
21-029-01	21-51-00-5C			OPERATIONAL	PACK HIGH FLOW INHIBIT SYSTEM
21-029-02	21-51-00-5C			OPERATIONAL	PACK HIGH FLOW INHIBIT SYSTEM
21-029-03	21-51-00-5C			OPERATIONAL	PACK HIGH FLOW INHIBIT SYSTEM

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-28



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
21-029-04	21-51-00-5C			OPERATIONAL	PACK HIGH FLOW INHIBIT SYSTEM
21-029-51	21-58-30-2A	21-029		CLEAN	FWD E/E COOLING AIR CLEANER
21-029-52	21-58-30-2A			CLEAN	FWD E/E COOLING AIR CLEANER
21-030-01	21-25-02-4D			REPLACE	RECIRCULATION AIR FILTERS
21-030-02	21-25-02-4D			REPLACE	RECIRCULATION AIR FILTERS
21-030-03	21-25-02-4D			REPLACE	RECIRCULATION AIR FILTERS
21-030-04	21-25-02-4D			REPLACE	RECIRCULATION AIR FILTERS
21-030-06	21-25-02-4D			REPLACE	RECIRCULATION AIR FILTERS
21-030-07	21-25-02-4D			REPLACE	RECIRCULATION AIR FILTERS
21-030-08	21-25-02-4D			REPLACE	RECIRCULATION AIR FILTERS
21-031-01	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-02	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-03	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-04	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-05	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-06	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-06	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-07	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-09	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-10	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-12	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-13	21-58-00-5C			FUNCTIONAL	E/E COOLING SYSTEM DIFF PRESS SWITCH
21-031-25	21-25-02-4E			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-031-26	21-25-02-4E			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-031-27	21-25-02-4E			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-031-28	21-25-02-4E			REPLACE	RECIRC AIR HIGH EFFICIENCY FILTERS
21-031-51	21-43-00-5A	21-031		OPERATIONAL	FWD CARGO HEATING SHUTOFF VALVE
21-032-01	21-58-18-2A			CHECK/INSP	ACRU EVAPORATOR AND HEAT EXCHANGERS
21-032-50	21-21-10-5A	21-032		OPERATIONAL	OPERATIONALLY CHECK THE AVS SYSTEM
21-032-51	21-21-10-5A			OPERATIONAL	OPERATIONALLY CHECK THE AVS SYSTEM
21-033-01	21-51-22-4A			FUNCTIONAL	CATALYTIC (OZONE) CONVERTERS
21-033-05	21-51-22-4A			FUNCTIONAL	CATALYTIC (OZONE) CONVERTERS
21-033-07	21-51-22-4B	21-033		RESTORE	CATALYTIC (OZONE) CONVERTERS
21-033-2	21-51-22-4A			FUNCTIONAL	CATALYTIC (OZONE) CONVERTERS
21-034-51	21-51-31-4B	21-034		FUNCTIONAL	CHECK THE AC PACK HX FOR LEAKAGE.

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
21-035-01	21-51-00-5D		A-21-015-C1	OPERATIONAL	PACK LOW LIMIT CONTROL VALVE
21-035-02	21-51-00-5D		A-21-015-C1	OPERATIONAL	PACK LOW LIMIT CONTROL VALVE
21-035-51	21-51-31-4A	21-035		CLEAN	AIR CONDITIONING PACK HEAT EXCHANGR
21-036-01	21-51-11-2A			OPERATIONAL	PACK LOW LIMIT VALVE PNEUMATIC CHECK
21-036-50	21-58-52-2A			CLEAN/INSP	INSPECT/CLEAN IFE COOLING SCREEN
21-036-51	21-58-52-2A			CLEAN/INSP	INSPECT/CLEAN IFE COOLING SCREEN
21-037-01	21-58-17-2A			CLEAN	E/E COOLING LOW FLOW DETECTORS
21-037-02	21-58-17-2A			CLEAN	E/E COOLING LOW FLOW DETECTORS
21-038-01	21-58-26-2A			CLEAN	E/E COOLING OVERHEAT SWITCH
21-038-02	21-58-26-2A			CLEAN	E/E COOLING OVERHEAT SWITCH
21-039-01	21-58-16-2A			CLEAN	E/E COOLING FWD RACK TEMP SENSOR
21-040-01	21-58-27-2A			CLEAN	E/E COOLING SUPPLY TEMP BULB
21-041-01	21-58-06-7A			CLEAN/INSP	E/E COOLING SUPPLY AND EXHAUST FANS
21-041-02	21-58-06-7A			CLEAN/INSP	E/E COOLING SUPPLY AND EXHAUST FANS
21-042-01	21-71-01-7A			CLEAN	FLIGHT COMPARTMENT HUMIDIFIER
21-043-01	21-61-05-6A			CHECK/INSP	TRIM AIR SUPPLY CHECK VALVES
21-043-02	21-43-00-5B			FUNCTIONAL	FWD CARGO OVERHEAT TEMP SWITCH
21-044-01	21-23-05-2A			CLEAN	RETURN AIR GRILLES
21-044-02	21-23-05-2A			CLEAN	RETURN AIR GRILLES
21-045-01	21-26-03-4A			REPLACE	GALLEY VENTILATION FILTERS
21-046-01	21-53-05-6A			OPERATIONAL	WATER SPRAY NOZZLES
21-046-04	21-53-05-6A			OPERATIONAL	WATER SPRAY NOZZLES
21-047-01	21-51-01-2A			OPERATIONAL	CHECK THE ASCTU FLOW CNTRL TR MOTOR
21-049-C1	21-61-01-4A		W-21-049-01	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-049-01	21-61-00-5A		W-21-049-C1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-051-01	21-23-20-5A			OPERATIONAL	MAIN DECK AIR DISTRIBUTION SHUTOFF
21-051-02	21-23-20-5A	21-051		OPERATIONAL	MAIN DECK AIR DISTRIBUTION SHUTOFF
21-052-01	21-23-05-2A			CLEAN	RETURN AIR GRILLES
21-053-01	21-44-00-5A	21-053	W-26-010-XX	OPERATIONAL	AFT/BULK CARGO HEATING SHUTOFF VALVE
21-053-02	21-44-00-5B	21-053		FUNCTIONAL	AFT/BULK CARGO OVERHEAT TEMP SWITCH
21-054-01	21-26-03-4A	21-054		REPLACE	GALLEY VENTILATION FILTERS
21-055-C1	21-61-01-4A		W-21-055-01	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-055-01	21-61-00-5A		W-21-055-C1	FUNCTIONAL	ZONE DUCT OVERHEAT SWITCH
21-056-01	21-26-30-5A			OPERATIONAL	CABIN SMOKING AREA EXHAUST VALVE
22-008-01	22-21-03-2A			OPERATIONAL	YAW DAMPER SERVO SOLENOID VALVE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
23-001-01	23-31-00-5A	23-001		FUNCTIONAL	SPEAKER SYSTEM
23-001-02	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-04	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-05	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-06	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-07	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-08	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-09	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-10	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-11	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-12	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-13	23-31-00-5A			FUNCTIONAL	SPEAKER SYSTEM
23-001-14	23-31-00-5A	23-001		FUNCTIONAL	SPEAKER SYSTEM
23-002-01	23-61-01-2A	23-002		FUNCTIONAL	STATIC DISCHARGERS
23-003-01	23-71-00-5A	23-003		OPERATIONAL	VOICE RECORDER - SELF TEST
23-003-02	23-71-00-5A			OPERATIONAL	VOICE RECORDER - SELF TEST
23-003-03	23-71-00-5A			OPERATIONAL	VOICE RECORDER - SELF TEST
23-004-01	23-71-00-5B	23-004		FUNCTIONAL	VOICE RECORDER - 4 CHANNEL OPERATION
23-004-02	23-71-00-5B			FUNCTIONAL	VOICE RECORDER - 4 CHANNEL OPERATION
23-004-03	23-71-00-5B			FUNCTIONAL	VOICE RECORDER - 4 CHANNEL OPERATION
23-005-02	23-71-03-2B	23-005		RESTORE	VOICE RECORDER ULB
23-005-03	23-71-03-2C	23-005		OPERATIONAL	VOICE DATA RECORDER ULB
23-006-01	23-24-00-5A	23-006		OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-006-01	23-24-00-5A			OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-006-01	23-24-00-5A			OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-006-02	23-24-00-5A			OPERATIONAL	EMERGENCY LOCATOR TRANSMITTER
23-007-01	23-24-01-2A	23-007		REPLACE	EMERGENCY LOCATOR TRANSMITTER
24-001-01-1	12-13-03-3A	24-001		SERVICE	ENGINE 1 IDG OIL LEVEL
24-001-01-2	12-13-03-3A	24-001		SERVICE	ENGINE 2 IDG OIL LEVEL
24-001-02-1	12-13-03-3C	24-001		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-001-02-2	12-13-03-3C	24-001		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-001-09-1	12-13-03-3A	24-001		SERVICE	ENGINE 1 IDG OIL LEVEL
24-001-09-2	12-13-03-3A	24-001		SERVICE	ENGINE 2 IDG OIL LEVEL
24-001-10-1	12-13-03-3C	24-001		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-001-10-2	12-13-03-3C	24-001		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
24-001-11-1	12-13-03-3A			SERVICE	ENGINE 1 IDG OIL LEVEL
24-001-11-2	12-13-03-3A			SERVICE	ENGINE 2 IDG OIL LEVEL
24-002-01-1	24-11-03-6A	24-002		CHECK/INSP	ENGINE 1 IDG QAD COUPLING
24-002-01-2	24-11-03-6A	24-002		CHECK/INSP	ENGINE 2 IDG QAD COUPLING
24-003-01	24-11-01-6A			OPERATIONAL	IDG DISCONNECT
24-003-02	24-11-01-6A			OPERATIONAL	IDG DISCONNECT
24-003-04	24-11-01-6A			OPERATIONAL	IDG DISCONNECT
24-003-05	24-11-01-6A			OPERATIONAL	IDG DISCONNECT
24-003-06	24-11-01-6A			OPERATIONAL	IDG DISCONNECT
24-004-01	24-22-00-5A	24-004		OPERATIONAL	BUS POWER CONTROL UNIT (BPCU)
24-004-03	24-22-00-5A			OPERATIONAL	BUS POWER CONTROL UNIT (BPCU)
24-004-05	24-22-00-5A			FUNCTIONAL	BUS POWER CONTROL UNIT (BPCU)
24-004-06	24-22-00-5A	24-004		OPERATIONAL	BUS POWER CONTROL UNIT (BPCU)
24-006-01	24-31-01-4A			RESTORE	MAIN BATTERY
24-006-03	24-31-01-4A			RESTORE	MAIN BATTERY
24-006-05	24-31-01-4A			RESTORE	MAIN BATTERY
24-006-06	24-31-01-4A			RESTORE	MAIN BATTERY
24-007-C1	24-30-00-5A 24-30-00-5C			OPERATIONAL	BATTERY CHARGER & CURRENT MONITOR
24-007-C2	24-30-00-5A 24-30-00-5C			OPERATIONAL	BATTERY CHARGER & CURRENT MONITOR
24-007-C3	24-30-00-5A 24-30-00-5C			OPERATIONAL	BATTERY CHARGER & CURRENT MONITOR
24-007-C4	24-30-00-5A 24-30-00-5C			OPERATIONAL	BATTERY CHARGER & CURRENT MONITOR
24-008-01	24-31-04-4A			RESTORE	APU BATTERY
24-008-03	24-31-04-4A			RESTORE	APU BATTERY
24-008-05	24-31-04-4A			RESTORE	APU BATTERY
24-008-06	24-31-04-4A			RESTORE	APU BATTERY
24-009-C1	24-30-00-5B 24-30-00-5D			OPERATIONAL	DC TIE CONTROL UNIT & DC TIE RELAY
24-009-C2	24-30-00-5B 24-30-00-5D			OPERATIONAL	DC TIE CONTROL UNIT & DC TIE RELAY
24-009-C3	24-30-00-5B 24-30-00-5D			OPERATIONAL	DC TIE CONTROL UNIT & DC TIE RELAY

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-32



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
24-009-C4	24-30-00-5B 24-30-00-5D			OPERATIONAL	DC TIE CONTROL UNIT & DC TIE RELAY
24-010-01	24-33-00-6A			OPERATIONAL	STANDBY POWER SYSTEM
24-010-02	24-33-00-6B			FUNCTIONAL	STANDBY POWER SYSTEM
24-010-03	24-33-00-6A			OPERATIONAL	STANDBY POWER SYSTEM
24-010-04	24-33-00-6B		B-24-007-C1	FUNCTIONAL	STANDBY POWER SYSTEM
24-010-05	24-33-00-6A		B-24-007-C3	OPERATIONAL	STANDBY POWER SYSTEM
24-010-06	24-33-00-6B			FUNCTIONAL	STANDBY POWER SYSTEM
24-010-06	24-33-00-6C			OPERATIONAL	STANDBY POWER SYSTEM
24-010-07	24-33-00-6C		B-24-007-C1	OPERATIONAL	STANDBY POWER SYSTEM
24-010-08	24-33-00-6C			OPERATIONAL	STANDBY POWER SYSTEM
24-010-12	24-33-00-6A			OPERATIONAL	STANDBY POWER SYSTEM
24-010-13	24-33-00-6C			OPERATIONAL	STANDBY POWER SYSTEM
24-010-14	24-33-00-6B			FUNCTIONAL	STANDBY POWER SYSTEM
24-013-01-1	24-11-07-B			CHECK/INSP	IDG AIR SHUTOFF VALVE - ENGINE 1
24-013-01-2	24-11-07-B			CHECK/INSP	IDG AIR SHUTOFF VALVE - ENGINE 2
24-013-02-1	24-11-07-B			CHECK/INSP	IDG AIR SHUTOFF VALVE - ENGINE 1
24-013-02-2	24-11-07-B			CHECK/INSP	IDG AIR SHUTOFF VALVE - ENGINE 2
24-013-03-1	24-11-07-B			CHECK/INSP	ENGINE 1 IDG AIR SHUTOFF VALVE
24-013-03-2	24-11-07-B			CHECK/INSP	ENGINE 2 IDG AIR SHUTOFF VALVE
24-013-05-1	24-11-07-B			CHECK/INSP	IDG AIR SHUTOFF VALVE ENGINE 1
24-013-05-2	24-11-07-B			CHECK/INSP	IDG AIR SHUTOFF VALVE ENGINE 2
24-013-51	24-25-00-5A			OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-013-53	24-25-00-5A			OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-013-54	24-25-00-5A			OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-013-55	24-25-00-5A			OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-013-56	24-25-00-5A			OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-013-57	24-25-00-5A			OPERATIONAL	HYDRAULIC MOTOR GENERATOR (HMG)
24-014-01	24-50-00-5A			OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
24-014-51	24-25-00-5B			FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-014-53	24-25-00-5B			FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-014-54	24-25-00-5B			FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-014-55	24-50-00-5A			OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
24-014-56	24-25-00-5B			FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-014-57	24-25-00-5B			FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
24-014-58	24-50-00-5A			OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
24-014-59	24-25-00-5B			FUNCTIONAL	HYDRAULIC MOTOR GENERATOR SYSTEM
24-014-60	24-50-00-5A			OPERATIONAL	INSTRUMENT BUS VOLTAGE SENSING UNIT
24-015-01	24-22-00-5C			OPERATIONAL	AUTOLAND DC TIE
24-015-02-1	12-13-03-3A			SERVICE	ENGINE 1 IDG OIL LEVEL
24-015-02-2	12-13-03-3A			SERVICE	ENGINE 2 IDG OIL LEVEL
24-015-03-1	12-13-03-3A	24-015		SERVICE	ENGINE 1 IDG OIL LEVEL
24-015-03-2	12-13-03-3A	24-015		SERVICE	ENGINE 2 IDG OIL LEVEL
24-015-51	24-11-00-5A			OPERATIONAL	BUS TIE BREAKER
24-015-52	24-11-00-5A			OPERATIONAL	BUS TIE BREAKER
24-015-53	24-11-00-5A			OPERATIONAL	BUS TIE BREAKER
24-015-55	24-11-00-5A			OPERATIONAL	BUS TIE BREAKER
24-015-61	24-22-00-5C			OPERATIONAL	AUTOLAND DC TIE
24-015-62	24-22-00-5C			OPERATIONAL	AUTOLAND DC TIE
24-015-64	24-22-00-5C			OPERATIONAL	AUTOLAND DC TIE
24-016-C1-1	24-11-02-2A		W-24-017-07-1	REPLACE	ENGINE 1 IDG FILTER ELEMENTS
24-016-C1-2	24-11-02-2A		W-24-017-07-2	REPLACE	ENGINE 2 IDG FILTER ELEMENTS
24-016-C2-1	24-11-02-2A		W-24-017-08-1	REPLACE	ENGINE 1 IDG FILTER ELEMENTS
24-016-C2-2	24-11-02-2A		W-24-017-08-2	REPLACE	ENGINE 2 IDG FILTER ELEMENTS
24-016-01-1	24-11-02-2A		W-24-017-01-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT
24-016-01-2	24-11-02-2A		W-24-017-01-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-016-02-1	24-11-02-2A		W-24-017-03-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT
24-016-02-2	24-11-02-2A		W-24-017-03-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-016-03-1	24-11-02-2A		W-24-017-06-1	REPLACE	ENGINE 1 IDG SCAVENGE FILTER ELEMENT
24-016-03-2	24-11-02-2A		W-24-017-06-2	REPLACE	ENGINE 2 IDG SCAVENGE FILTER ELEMENT
24-016-10-1	12-13-03-3C			CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-016-10-2	12-13-03-3C			CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-016-11-1	12-13-03-3C			CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-016-11-2	12-13-03-3C			CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-016-12-1	12-13-03-3C	24-016		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-016-12-2	12-13-03-3C	24-016		CHECK/INSP	IDG SCAVENGE FILTER DIFF PRESS INDIC
24-017-01-1	12-13-03-3B		W-24-016-01-1	REPLACE	ENGINE 1 IDG OIL CHANGE
24-017-01-2	12-13-03-3B		W-24-016-01-2	REPLACE	ENGINE 2 IDG OIL CHANGE
24-017-03-1	12-13-03-3B		W-24-016-02-1	REPLACE	ENGINE 1 IDG OIL CHANGE
24-017-03-2	12-13-03-3B		W-24-016-02-2	REPLACE	ENGINE 2 IDG OIL CHANGE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-34



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
24-017-06-1	12-13-03-3B		W-24-016-03-1	SERVICE	ENGINE 1 IDG OIL CHANGE
24-017-06-2	12-13-03-3B		W-24-016-03-2	SERVICE	ENGINE 2 IDG OIL CHANGE
24-017-07-1	12-13-03-3B		W-24-016-C1-1	SERVICE	ENGINE 1 IDG OIL CHANGE
24-017-07-2	12-13-03-3B		W-24-016-C1-2	SERVICE	ENGINE 2 IDG OIL CHANGE
24-017-08-1	12-13-03-3B		W-24-016-C2-1	REPLACE	ENGINE 1 IDG OIL CHANGE
24-017-08-2	12-13-03-3B		W-24-016-C2-2	REPLACE	ENGINE 2 IDG OIL CHANGE
24-020-01-1	24-11-07-2A			REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-01-2	24-11-07-2A			REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-02-1	24-11-07-2A			REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-02-2	24-11-07-2A			REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-03-1	24-11-07-2A			REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-03-2	24-11-07-2A			REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-04-1	24-11-07-2A			REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-04-2	24-11-07-2A			REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-05-1	24-11-07-2A			REPLACE	L IDG HEAT EXCH AIR S/O VALVE FILTER
24-020-05-2	24-11-07-2A			REPLACE	R IDG HEAT EXCH AIR S/O VALVE FILTER
24-031-01	24-31-05-4A			CLEAN	APU BATTERY CHARGER
24-031-03	24-31-05-4A			CLEAN	APU BATTERY CHARGER
24-031-05	24-31-05-4A			CLEAN	APU BATTERY CHARGER
24-031-06	24-31-05-4A			CLEAN	APU BATTERY CHARGER
24-041-03	24-41-02-2B			CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
24-041-07	24-41-02-2B			CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
24-041-08	24-41-02-2B			CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
24-041-12	24-41-02-2B			CHECK/INSP	EXTERNAL POWER RECEPTACLE PINS
25-BCY-90-1	25-53-00-5A			OPERATIONAL	CONTAINERIZED HANDLING SYSTEM
25-BCY-91-1	25-53-00-5B			OPERATIONAL	CONTAINERIZED HANDLING SYSTEM
25-001-01	25-11-00-6B	25-001		OPERATIONAL	CREW SEAT ADJUSTMENT/LOCK MECHANISM
25-002-01	25-11-00-6A	25-002		OPERATIONAL	CREW SEAT HARNESS/INERTIA REEL
25-003-01	25-25-00-A	25-003		OPERATIONAL	PASSENGER SEAT BELTS
25-004-01	25-25-01-A	25-004		CHECK/INSP	PASSENGER SEATS - FLOOR ATTACHMENT
25-005-01	25-25-03-6A	25-005		OPERATIONAL	ATTENDANT SEATS RESTRAINT
25-006-01	25-41-00-6A	25-006	W-26-014-01	CHECK/INSP	LAVATORY WASTE COMPARTMENT DOORS
25-011-01	25-61-01-2A	25-011	W-52-014-01	CHECK/INSP	OFF-WING EMERGENCY EXIT ASSIST STRAP
25-012-01	25-61-02-A	25-012		CHECK/INSP	FLIGHT COMPARTMENT ESCAPE ROPES
25-013-01	25-62-00-A	25-013		CHECK/INSP	LIFE JACKETS (IF INSTALLED)

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
25-013-02	25-62-00-A	25-013		CHECK/INSP	LIFE JACKETS (IF INSTALLED)
25-014-01	25-62-00-B	25-014		RESTORE	LIFE RAFT (IF INSTALLED)
25-014-02	25-62-00-C			CHECK/INSP	LIFE RAFT INFLATION BOTTLE
25-014-03	25-62-00-B	25-014		RESTORE	LIFE RAFT (IF INSTALLED)
25-014-04	25-62-00-C			CHECK/INSP	LIFE RAFT INFLATION BOTTLE
25-015-01	25-63-02-2C	25-015		OPERATIONAL	POWER MEGAPHONE
25-016-01	25-63-00-B	25-016		FUNCTIONAL	EMERGENCY LOCATOR TRANSMITTER
25-016-02	25-63-00-B			FUNCTIONAL	EMERGENCY LOCATOR TRANSMITTER
25-017-01	25-63-01-2A	25-017		OPERATIONAL	EMERGENCY EVACUATION SIGNAL SYSTEM
25-018-01	25-64-00-A	25-018		CHECK/INSP	DETACHABLE EMERGENCY EQUIPMENT
25-018-02	25-64-00-A	25-018		CHECK/INSP	DETACHABLE EMERGENCY EQUIPMENT
25-019-01	25-65-00-6A	25-019	W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-019-02	25-65-00-6A		W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-019-03	25-65-00-6A		W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-019-04	25-65-00-6A		W-S53-066-01	CHECK/INSP	OFF-WING SLIDE INFLATION HOSE ASSY
25-020-01	25-65-01-4A	25-020	W-12-001-01	RESTORE	OFF-WING EVACUATION RAMP/SLIDE PACK
25-020-02	25-65-05-4A			RESTORE	OFF-WING EVACUATION RAMP/SLIDE PACK
25-021-01	25-65-02-6A	25-021		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-021-02	25-65-02-6A			CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-021-03	25-65-02-6A			CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-021-04	25-65-02-6A			CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-022-01	25-65-04-4A	25-022	A-25-023-01	OPERATIONAL	OFF-WING SLIDE ACTUATION CABLES
25-023-01	25-65-08-A		B-25-022-01	CHECK/INSP	OFF-WING COMPARTMENT DOOR/DOOR LATCH
25-023-01	25-65-08-A	25-023	B-25-022-01	CHECK/INSP	OFF-WING COMPARTMENT DOOR/DOOR LATCH
25-023-02	25-65-10-A	25-023	W-25-023-01	CHECK/INSP	OFF-WING COMP DOOR OPENING ACTUATORS
25-023-03	25-65-11-A	25-023	W-25-023-01	CHECK/INSP	OFF-WING COMPT DOOR LATCH ACTUATOR
25-024-01	25-65-10-4A	25-024	W-25-023-02	REPLACE	OFF-WING COMP DOOR OPENING ACTUATORS
25-024-02	25-65-11-4A	25-024	W-25-023-03	REPLACE	OFF-WING COMPT DOOR LATCH ACTUATOR
25-025-01	25-65-07-6A	25-025	A-25-023-02	CHECK/INSP	OFF-WING COMPARTMENT DOOR INTEGRATOR
25-026-01	25-65-17-4A	25-026		RESTORE	OFF-WING ESCAPE SYSTEM BATTERIES
25-027-01-1	25-65-19-4A	25-027		RESTORE	L OFF-WING SPOILER OVERRIDE ACTUATOR
25-027-01-2	25-65-19-4A	25-027		RESTORE	R OFF-WING SPOILER OVERRIDE ACTUATOR
25-027-02-1	25-65-20-4A			RESTORE	L OFF-WING SPOILER OVERRIDE ACTUATOR
25-027-02-2	25-65-20-4A			RESTORE	R OFF-WING SPOILER OVERRIDE ACTUATOR
25-028-01	25-66-02-6A	25-028		CHECK/INSP	ENTRY/SERVICE DOOR ESC SLIDE BOTTLES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-36



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
25-028-02	25-66-10-6A	25-028		CHECK/INSP	EMER EXIT DOOR ESCAPE SLIDE BOTTLES
25-029-01	25-66-01-4A	25-029	W-25-029-03	RESTORE	ENTRY/SERVICE DOOR ESCAPE SLIDE
25-029-02	25-66-10-4A	25-029		RESTORE	EMER EXIT DOOR ESCAPE SLIDE
25-030-01	25-66-03-A	25-030		CHECK/INSP	ENTRY/SERVICE DOOR SLIDE DEPLOY MECH
25-031-01	25-65-00-5A	25-031		OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-031-02	25-66-00-5A			OPERATIONAL	ENTRY/SERVICE DOOR ESCAPE SLIDE SYS
25-031-03	25-65-00-5A			OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-031-04	25-65-00-5A			OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-031-05	25-65-00-5A			OPERATIONAL	OFF-WING ESCAPE SLIDE SYSTEM
25-031-07	25-66-00-5B			OPERATIONAL	EMER EXIT DOOR ESCAPE SLIDE SYSTEM
25-031-14	25-66-00-5A			OPERATIONAL	ENTRY/SERVICE DOOR ESCAPE SLIDE SYS
25-032-01	25-33-03-7A			CLEAN	GALLEY CHILLER CONDENSER AIR FILTERS
25-032-51	25-64-00-B	25-032		REPLACE	EMERGENCY ESCAPE BREATHING DEVICES
25-033-01	25-63-02-2A			REPLACE	POWER MEGAPHONE BATTERIES
25-033-61	25-66-10-4B		W-25-029-02	CHECK/INSP	EMER EXIT DOOR ESCAPE SLIDE BOTTLE
25-034-01	25-31-00-6A			CHECK/INSP	GALLEY WASTE ENCLOSURES
25-034-02	25-65-02-4A			CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-034-03	25-65-02-4A			CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-034-04	25-65-02-4A			CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-034-05	25-65-02-2A	25-034		CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-034-51	25-65-02-4A			CHECK/INSP	OFF-WING SLIDE INFLATION BOTTLE
25-035-01	25-52-00-6A			CHECK/INSP	CARGO COMPARTMENT LININGS
25-035-02	25-52-00-6A			CHECK/INSP	CARGO COMPARTMENT LININGS
25-035-51	25-66-01-4B		W-25-029-01	CHECK/INSP	ENTRY/SERVICE DOOR ESC SLIDE BOTTLES
25-036-01	25-65-10-4B			CHECK/INSP	OFF-WING COMP DOOR OPENING ACTUATORS
25-038-01	25-31-00-A			CLEAN	GALLEY OVEN
25-039-01	25-41-00-6C			CHECK/INSP	LAVATORY LOWER EXTERIOR WALLS
25-040-01	25-41-00-6B			CHECK/INSP	LAVATORY FLOORS
25-041-01	25-61-03-2A	25-041		REPLACE	EMERGENCY ESCAPE DESCENT DEVICES
25-042-01	25-65-02-4B	25-042		REPLACE	OFF-WING SLIDE BOTTLE SQUIB
25-042-02	25-65-02-4B			REPLACE	OFF-WING SLIDE BOTTLE SQUIB
25-043-03	25-65-00-2A	25-043	W-26-015-01	OPERATIONAL	OFF-WING SLIDE BOTTLE SQUIBS
25-043-04	25-65-00-2A		W-26-015-01	OPERATIONAL	OFF-WING SLIDE BOTTLE SQUIBS
25-044-01	25-11-00-6C	25-044		OPERATIONAL	SUPERNUMERARY SEATS RESTRAINT

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
26-001-C1	26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-001-C2	26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-001-C3	26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-001-C4	26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-001-C5	26-16-00-5A 26-16-00-5B 26-16-00-5C 26-16-00-5D			OPERATIONAL	CARGO SMOKE DETECTORS/BLOWERS/RELAYS
26-004-01	26-21-01-6A	26-004		OPERATIONAL	ENGINE FIRE SWITCHES
26-004-02	26-21-01-6A	26-004		OPERATIONAL	ENGINE FIRE SWITCHES
26-005-01	26-21-03-4A	26-005		REPLACE	ENG FIRE EXT BOTTLE SQUIB CARTRIDGES
26-005-02	26-21-03-4A	26-005		REPLACE	ENG FIRE EXT BOTTLE SQUIB CARTRIDGES
26-005-03-1	26-21-03-4A	26-005		REPLACE	ENGINE 1 FIRE EXT BOTTLE SQUIB CART
26-005-03-2	26-21-03-4A	26-005		REPLACE	ENGINE 2 FIRE EXT BOTTLE SQUIB CART
26-006-01	26-21-00-5A	26-006	W-26-012-XX	OPERATIONAL	ENG FIRE EXT BOTTLE PRESSURE SWITCH
26-006-02-1	26-21-00-5A	26-006		OPERATIONAL	ENG 1 FIRE EXT BOTTLE PRESS SWITCH
26-006-02-2	26-21-00-5A	26-006		OPERATIONAL	ENG 2 FIRE EXT BOTTLE PRESS SWITCH
26-007-01	26-22-01-6A	26-007		OPERATIONAL	APU FIRE SWITCH
26-007-02	26-22-01-6A			OPERATIONAL	APU FIRE SWITCH
26-007-03	26-22-01-6A			OPERATIONAL	APU FIRE SWITCH
26-008-01	26-22-02-4A	26-008		REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-008-02	26-22-02-4A	26-008		REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-008-03	26-22-02-4A			REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-008-04	26-22-02-4A			REPLACE	APU FIRE EXT BOTTLE SQUIB CARTRIDGES
26-009-01	26-22-00-5A	26-009		OPERATIONAL	APU FIRE EXT BOTTLE PRESSURE SWITCH

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-38



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
26-009-02	26-22-00-5A			OPERATIONAL	APU FIRE EXT BOTTLE PRESSURE SWITCH
26-009-03	26-22-00-5A			OPERATIONAL	APU FIRE EXT BOTTLE PRESSURE SWITCH
26-010-01	26-23-01-6A			OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-010-05	26-23-01-6A			OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-010-06	26-23-01-6A			OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-010-07	26-23-01-6A			OPERATIONAL	CARGO FIRE EXT ARMED SWITCHES
26-011-01	26-23-02-4A	26-011		REPLACE	CARGO FIRE EXT BOTTLE (KIDDE) SQUIB
26-011-02	26-23-02-4A			REPLACE	CARGO FIRE EXT BOTTLE (HTL) SQUIB
26-011-06	26-23-02-4A			REPLACE	CARGO FIRE EXT BOTTLE (HTL) SQUIB
26-012-01	26-23-00-5A		W-26-006-01	OPERATIONAL	CARGO FIRE EXT BTL PRESSURE SWITCHES
26-012-05	26-23-00-5A		W-26-006-01	OPERATIONAL	CARGO FIRE EXT BTL PRESSURE SWITCHES
26-013-01	26-26-02-6A	26-013		CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-013-02	26-26-03-6A	26-013		CHECK/INSP	PORTABLE WATER FIRE EXTINGUISHERS
26-013-04	26-26-02-6A			CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-013-06	26-26-03-6A			CHECK/INSP	PORTABLE WATER FIRE EXTINGUISHERS
26-013-08	26-26-02-6B			CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-013-09	26-26-03-6B			CHECK/INSP	PORTABLE WATER FIRE EXTINGUISHERS
26-013-12	26-26-02-6A			CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-013-13	26-26-02-6A			CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS
26-014-01	26-24-01-2A	26-014	W-25-006-01	CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-014-02	26-24-01-2A		W-25-006-01	CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-014-51	26-24-01-2B			CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-014-52	26-24-01-2B			CHECK/INSP	LAV WASTE COMPT FIRE EXTINGUISHERS
26-015-01	26-21-04-6A			OPERATIONAL	SQUIB TEST CONTROL PANEL
26-015-02	26-21-04-6B			OPERATIONAL	SQUIB TEST CONTROL PANEL
26-015-03	26-21-04-6A			OPERATIONAL	SQUIB TEST CONTROL PANEL
26-015-04	26-21-04-6A			OPERATIONAL	SQUIB TEST CONTROL PANEL
26-015-51	26-10-00-6A	26-015		OPERATIONAL	FIRE/OVERHEAT LOGIC/TEST SYSTEM
26-015-54	26-10-00-6A	26-015		OPERATIONAL	FIRE/OVERHEAT LOGIC/TEST SYSTEM
26-016-51	26-23-03-6A	26-016		OPERATIONAL	CARGO FIRE EXT BOTTLE RELAYS
26-017-01	26-16-05-2A			OPERATIONAL	CRGO SMOKE DET FAN ISOLATION FLAPPER
26-017-05	26-16-05-2A			OPERATIONAL	CRGO SMOKE DET FAN ISOLATION FLAPPER
26-017-55	26-23-00-5B			FUNCTIONAL	CARGO FIRE EXT DISCHARGE SYSTEM
26-017-59	26-23-00-5B			FUNCTIONAL	CARGO FIRE EXT DISCHARGE SYSTEM
26-018-51	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
26-018-53	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-54	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-55	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-56	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-57	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-58	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-59	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-60	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-61	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-62	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-63	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-64	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-65	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-66	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-018-67	26-13-00-5A			OPERATIONAL	LAVATORY SMOKE DETECTORS
26-019-51	26-16-00-A			CHECK/INSP	CRGO SMOKE DET AIR SAMPLING ORIFICES
26-019-55	26-16-00-A			CHECK/INSP	CRGO SMOKE DET AIR SAMPLING ORIFICES
26-019-56	26-16-00-A			CHECK/INSP	CRGO SMOKE DET AIR SAMPLING ORIFICES
26-020-01	26-10-00-6B			OPERATIONAL	FIRE DETECTION SYSTEM FAIL LIGHT
26-020-04	26-10-00-6B			OPERATIONAL	FIRE DETECTION SYSTEM FAIL LIGHT
26-021-01	26-17-00-5A			OPERATIONAL	WHEEL WELL FIRE DETECTION SYSTEM
26-021-51	26-21-03-4B			CHECK/INSP	ENGINE FIRE EXTINGUISHER BOTTLE
26-021-52-1	26-21-03-4B			CHECK/INSP	ENGINE 1 FIRE EXTINGUISHER BOTTLE
26-021-52-2	26-21-03-4B			CHECK/INSP	ENGINE 2 FIRE EXTINGUISHER BOTTLE
26-022-01	26-14-20-5A			OPERATIONAL	CREW REST AREA SMOKE DETECTOR
26-022-02	26-15-00-5A			OPERATIONAL	APU FIRE DETECTION GRND LOGIC SYSTEM
26-022-03	26-14-20-5B			OPERATIONAL	CREW REST AREA SMOKE DETECTOR
26-022-04	26-14-20-5A		W-26-022-05	OPERATIONAL	CREW REST AREA SMOKE DETECTOR
26-022-05	26-14-20-5B			OPERATIONAL	CREW REST AREA SMOKE DETECTOR
26-022-51	26-22-02-4B			CHECK/INSP	APU FIRE EXTINGUISHER BOTTLE
26-022-52	26-22-02-4B			CHECK/INSP	APU FIRE EXTINGUISHER BOTTLE
26-022-53	26-22-02-4B			CHECK/INSP	APU FIRE EXTINGUISHER BOTTLE
26-023-51	26-23-02-4B			CHECK/INSP	CARGO FIRE EXTINGUISHER BOTTLE
26-023-55	26-23-02-4B			CHECK/INSP	CARGO FIRE EXTINGUISHER BOTTLE
26-024-01	26-26-02-6B			CHECK/INSP	PORTABLE HALON FIRE EXTINGUISHERS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
26-025-01	26-14-00-A	26-025		CHECK/INSP	SMOKE DETECTOR SAMPLING ORIFICES
26-026-C1	26-14-00-5C			OPERATIONAL	VACUUM EJECTOR AND PRESSURE SWITCH
26-026-C2	26-14-00-5C			OPERATIONAL	VACUUM EJECTOR AND PRESSURE SWITCH
26-027-C1	26-14-00-5E			OPERATIONAL	MAIN DECK CARGO SMOKE DETECTION
26-027-C2	26-14-00-5E			OPERATIONAL	MAIN DECK CARGO SMOKE DETECTION
26-030-C1	26-16-00-5E			OPERATIONAL	LOWER LOBE CARGO SMOKE DETECTION
26-030-C2	26-16-00-5E			OPERATIONAL	LOWER LOBE CARGO SMOKE DETECTION
26-030-C3	26-16-00-5E			OPERATIONAL	LOWER LOBE CARGO SMOKE DETECTION
26-031-01	26-16-00-B	26-031		CHECK/INSP	SMOKE DETECTOR SAMPLING ORIFICES
26-033-01	26-16-00-7A			RESTORE	CLEAN CARGO SMOKE DET HEATER TUBES
26-034-01	26-16-00-5G	26-034		OPERATIONAL	CARGO DETECTOR HEATERS/CONTROLLERS
26-034-02	26-16-00-5G			OPERATIONAL	CARGO DETECTOR HEATERS/CONTROLLERS
26-035-01	26-23-06-4A	26-035		REPLACE	FLOW VALVE SQUIB CARTRIDGES
27-003-01	27-11-00-5A	27-003	W-27-010-01	OPERATIONAL	AILERON POWER CONTROL ACTUATOR
27-007-01	27-11-36-4A	27-007		OPERATIONAL	DUAL AILERON CONTROL OVERRIDE SYSTEM
27-010-01	27-21-00-5A	27-010	W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-010-02	27-21-00-5A		W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-010-03	27-21-00-5A		W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-010-04	27-21-00-5A		W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-010-52	27-21-00-5A		W-27-018-01	FUNCTIONAL	RUDDER POWER CONTROL ACTUATOR
27-015-01	27-21-00-5B		W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-015-04	27-21-00-5B		W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-015-06	27-21-00-5B		W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-015-07	27-21-00-5B		W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-015-56	27-21-00-5B		W-27-003-01	OPERATIONAL	RUDDER RATIO CHANGER BYPASS VALVE
27-017-01	27-31-00-5A	27-017		OPERATIONAL	ELEVATOR DUAL CONTROL PATH OVERRIDE
27-018-01	27-31-00-5B	27-018	W-27-010-01	OPERATIONAL	ELEVATOR POWER CONTROL ACTUATOR
27-021-01	27-31-00-5C	27-021		OPERATIONAL	ELEVATOR NEUTRAL SHIFT MECHANISM
27-022-01	27-32-00-5A	27-022		OPERATIONAL	STALL WARNING SYSTEM
27-022-02	27-32-00-5A			OPERATIONAL	STALL WARNING SYSTEM
27-022-03	27-32-00-5A			OPERATIONAL	STALL WARNING SYSTEM
27-022-04	27-32-00-5A			OPERATIONAL	STALL WARNING SYSTEM
27-023-01	27-41-00-5A	27-023		OPERATIONAL	MANUAL-MECH HORZ STAB TRIM CONTROL
27-024-01	27-41-00-5B	27-024		FUNCTIONAL	STABILIZER TRIM POSITION TRANSMITTER
27-025-01	27-41-00-5C	27-025		OPERATIONAL	STAB TRIM CNTRL COL CUTOFF SWITCHES

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
27-026-01	27-41-00-5D	27-026		OPERATIONAL	STAB TRIM CUTOUT (PEDESTAL) SWITCHES
27-028-01	27-41-10-B	27-028		CHECK/INSP	STAB TRIM ACTUATOR ATTACHMENT GIMBAL
27-030-01	27-41-10-6B	27-030		CHECK/INSP	STAB TRIM ACTUATOR BALLSCREW/NUT
27-031-02	31-51-00-5B			OPERATIONAL	TAKE-OFF WARNING SYSTEM
27-031-03	31-51-00-5B			OPERATIONAL	TAKE-OFF WARNING SYSTEM
27-033-01	27-51-00-5D	27-033		OPERATIONAL	FLAP/SLAT ELECTRONICS UNIT (FSEU)
27-036-01	27-51-00-5A	27-036		OPERATIONAL	ALT TE FLAP POWER DRIVE SYSTEM
27-036-51	27-51-00-5A	27-036		OPERATIONAL	ALT TE FLAP POWER DRIVE SYSTEM
27-037-01	27-51-00-5B	27-037		OPERATIONAL	TE FLAP FAILURE PROTECTION SYSTEM
27-042-01	27-51-00-5C	27-042		OPERATIONAL	TE FLAP ASYMMETRY PROTECTION SYSTEM
27-043-01	27-81-00-5A	27-043		OPERATIONAL	LE SLAT FAILURE PROTECTION SYSTEM
27-043-51	27-81-00-5A	27-043		OPERATIONAL	LE SLAT FAILURE PROTECTION SYSTEM
27-044-01	27-81-00-5B	27-044	A-27-043-01	OPERATIONAL	LE SLAT ASYMMETRY PROTECTION SYSTEM
27-045-01	27-62-00-5A	27-045		OPERATIONAL	AUTO SPEEDBRAKE
27-047-01	27-81-00-5C	27-047	B-27-043-01	OPERATIONAL	LE SLAT ALTERNATE DRIVE SYSTEM
27-047-02	12-21-08-3I			SERVICE	LE SLAT ALTERNATE DRIVE MOTORS
27-052-01	27-00-00-A			CHECK/INSP	WING FLIGHT CONTROL SURFACES
27-052-51	27-41-00-5F	27-052		OPERATIONAL	ALTERNATE HORIZ STAB TRIM SYSTEM
27-053-01	12-13-06-3A			SERVICE	STABILIZER TRIM BALL-SCREW ACTUATOR
27-053-51	27-51-00-5F	27-053		FUNCTIONAL	TE FLAP LOAD ALLEVIATION SYSTEM
27-054-01	27-51-48-2A		W-27-046-01	OPERATIONAL	TE FLAP/LE SLAT SHUTOFF VALVE MODULE
27-054-51	27-41-00-5G	27-054		OPERATIONAL	STABILIZER TRIM SECONDARY BRAKES
27-055-01-1	27-81-20-2C			FUNCTIONAL	LE SLAT RETRACT/EXTEND STOP GAPS -L
27-055-01-2	27-81-20-2C			FUNCTIONAL	LE SLAT RETRACT/EXTEND STOP GAPS -R
27-055-51	27-41-00-5H	27-055		OPERATIONAL	STAB TRIM OVERRIDE WITH SPLIT COLUMN
27-057-51	27-31-20-4A	27-057		OPERATIONAL	ELEVATOR FEEL SHIFT
27-058-01	27-21-23-2A			CLEAN	RUDDER TRIM KNOB
27-058-52	27-21-00-5C	27-058		OPERATIONAL	RUDDER PEDAL POGO RODS
27-059-01	27-31-68-2A	27-059	W-27-060-01	FUNCTIONAL	ELEVATOR HYDRAULIC RATE FUSES
27-060-01	27-23-51-2A	27-060	W-27-059-01	FUNCTIONAL	RUDDER HYDRAULIC RATE FUSES
27-061-01	27-81-42-4A	27-061		OPERATIONAL	LE SLAT SKEW DETECTION SYSTEM
27-062-02	27-81-42-4B	27-062		CHECK/INSP	LE SLAT SKEW DETECTION SYSTEM
27-063-01-1	27-81-00-2A			CHECK/INSP	LE AND KRUEGER FLAP ROTARY ACTUATORS
27-063-01-2	27-81-00-2A			CHECK/INSP	LE AND KRUEGER FLAP ROTARY ACTUATORS
27-063-02	12-21-08-3H	27-063		LUBRICATE	LE SLAT SKEW DETECTION SYSTEM

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
27-064-01-1	27-11-00-E			CHECK/INSP	L WING-LATERAL CNTRL SYSTEM BEARINGS
27-064-01-2	27-11-00-E			CHECK/INSP	R WING-LATERAL CNTRL SYSTEM BEARINGS
27-064-51	27-51-00-5G	27-064		OPERATIONAL	TE FLAP LOAD RELIEF ACTUATOR/RELAY
27-065-51	27-51-00-5H	27-065		FUNCTIONAL	TE FLAP LOAD RELIEF SYSTEM
27-066-01-1	27-51-00-5I	27-066		FUNCTIONAL	TE FLAP DRIVE NO-BACK BRAKES
27-066-01-2	27-51-00-5I	27-066		FUNCTIONAL	TE FLAP DRIVE NO-BACK BRAKES
27-067-01	12-21-09-3J	27-067		SERVICE	TE FLAP DRIVE ROTARY ACTUATOR OIL
27-068-01	12-21-08-3J	27-068		SERVICE	LE SLAT DRIVE OFFSET GEARBOX
27-069-01-1	27-81-20-2B	27-069		FUNCTIONAL	LE SLAT DRIVE NOBACK BRAKES
27-069-01-2	27-81-20-2B	27-069		FUNCTIONAL	LE SLAT DRIVE NOBACK BRAKES
27-070-01	27-32-00-5A	27-070		OPERATIONAL	STALL WARNING SYSTEM AND TAI
27-071-01	12-13-08-3A			SERVICE	ALT TE FLAP POWER DRIVE MOTOR
27-073-01	27-02-00-6A	27-073		FUNCTIONAL	ELEVATOR SURFACE FREEPLAY
27-076-01	27-02-00-6B	27-076		FUNCTIONAL	RUDDER SURFACE FREEPLAY
27-077-01	27-41-10-6A	27-077		FUNCTIONAL	STAB TRIM BALLSCREW AND BALLNUTS
27-078-01	27-31-07-4A	27-078		FUNCTIONAL	ELEVATOR PCA INPUT CONTROL ROD
27-079-01	27-31-00-5D	27-079		FUNCTIONAL	ELEVATOR PCA MIS-RIG
27-696-00	27-696-00	27-696-00		SPCL DETAIL	STABILIZER TRIM ACTUATOR
27-698-00	27-698-00	27-698-00		SPCL DETAIL	STABILIZER TRIM ACTUATOR
28-AWL-05-1	29-11-27-6A	28-AWL		FUNCTIONAL	HYDRAULIC LINE FUEL TANK PENETRATION
28-AWL-05-2	29-11-27-6A	28-AWL		FUNCTIONAL	HYDRAULIC LINE FUEL TANK PENETRATION
28-AWL-18-1	20-55-54-6A	28-AWL		FUNCTIONAL	FQIS WIRING AND BONDING
28-AWL-18-2	20-55-54-6A	28-AWL		FUNCTIONAL	FQIS WIRING AND BONDING
28-AWL-20-1	28-22-00-5F	28-AWL		FUNCTIONAL	CTR AUX TANK FUEL PUMP AUTO SHUTOFF
28-AWL-27-1	28-22-00-5H	28-AWL		OPERATIONAL	BOOST/OVERRIDE-JETTISON PUMP GFI
28-AWL-28-1	28-22-00-5H	28-AWL		FUNCTIONAL	CENTER TANK FUEL PUMP UNCOMMANDED-ON
28-004-01-1	28-13-04-2B	28-004		OPERATIONAL	SURGE TANK PRESSURE RELIEF VALVE - L
28-004-01-2	28-13-04-2B	28-004		OPERATIONAL	SURGE TANK PRESSURE RELIEF VALVE - R
28-005-01-1	28-22-08-7A	28-005		CLEAN	AUTO SUMPING MOTIVE FLOW SCREENS - L
28-005-01-2	28-22-08-7A	28-005		CLEAN	AUTO SUMPING MOTIVE FLOW SCREENS - R
28-006-01	28-25-00-5A	28-006		FUNCTIONAL	APU FUEL SUPPLY LINE SHROUD
28-009-01	28-22-00-5B			OPERATIONAL	FUEL CROSSFEED VALVE
28-010-01-1	28-13-04-2A			FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE - L
28-010-01-2	28-13-04-2A			FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE - R
28-010-51	28-22-00-5C	28-010		OPERATIONAL	CENTER AUX TANK FUEL SCAVENGE SYSTEM

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
28-011-51	28-22-00-5D	28-011		OPERATIONAL	CTR AUX TANK SCAVENGE SHUTOFF VALVE
28-012-01	28-22-00-5E	28-012		OPERATIONAL	ENG FUEL SPAR SHUTOFF VALVE BATTERY
28-013-01	28-31-00-5A	28-013		OPERATIONAL	FUEL JETTISON SYSTEM
28-014-01	28-22-16-4A	28-014		RESTORE	ENG FUEL SPAR SHUTOFF VALVE BATTERY
28-015-01	28-31-00-5A	28-015		OPERATIONAL	FUEL JETTISON SYSTEM - LOW CAPACITY
28-016-01	28-31-00-5A	28-016		OPERATIONAL	FUEL JETTISON SYSTEM - FULL CAPACITY
28-017-01-1	28-22-00-D			CHECK/INSP	LEFT BOOST, OVERRIDE/JTSN PUMPS
28-017-01-1	28-22-00-D			CHECK/INSP	LEFT BOOST, OVERRIDE/JTSN PUMPS
28-017-01-2	28-22-00-D			CHECK/INSP	RIGHT BOOST, OVERRIDE/JTSN PUMPS
28-017-01-2	28-22-00-D			CHECK/INSP	RIGHT BOOST, OVERRIDE/JTSN PUMPS
28-017-01	28-22-07-4A			RESTORE	REPLACE STRUT COUPLING O-RINGS
28-018-01	28-22-07-4A			RESTORE	REPLACE STRUT COUPLING O-RINGS
28-018-02	28-22-00-5G	28-018		OPERATIONAL	ENGINE FUEL SUCTION FEED SYSTEM
28-018-03	28-11-04-6A	28-018		FUNCTIONAL	OVERWING FILL PORT - L/H WING
28-018-04	28-11-04-6A	28-018		FUNCTIONAL	OVERWING FILL PORT - R/H WING
28-019-01	28-22-07-4A			RESTORE	REPLACE STRUT COUPLING O-RINGS
28-020-01	28-22-07-4A			RESTORE	REPLACE STRUT COUPLING O-RINGS
28-020-02	28-00-00-2A	28-020		CHECK/INSP	IN-TANK TUBING - LEFT MAIN FUEL TANK
28-020-03	28-00-00-2B	28-020		CHECK/INSP	IN-TANK TUBING - RT MAIN FUEL TANK
28-020-04	28-00-00-2C	28-020		CHECK/INSP	IN-TANK TUBING - CTR AUX FUEL TANK
28-021-01	28-22-07-4A			RESTORE	REPLACE STRUT COUPLING O-RINGS
28-021-03	28-13-04-6A	28-021		FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE-L
28-021-04	28-13-04-6A	28-021		FUNCTIONAL	SURGE TANK PRESSURE RELIEF VALVE-R
28-022-01	28-21-12-6A	28-022		FUNCTIONAL	FUELING SHUTOFF VALVES L/H WING
28-022-02	28-21-12-6A	28-022		FUNCTIONAL	FUELING SHUTOFF VALVES R/H WING
28-023-01	28-21-01-6A	28-023		FUNCTIONAL	FUELING ADAPTER L/H WING
28-024-01	28-21-01-6A	28-024		FUNCTIONAL	FUELING ADAPTER R/H WING
28-025-01	28-22-15-6A	28-025		CHECK/INSP	LEFT MAIN TANK FUEL BOOST PUMPS
28-025-02	28-22-15-6A	28-025		CHECK/INSP	RIGHT MAIN TANK FUEL BOOST PUMPS
28-025-03	28-22-15-6A	28-025		CHECK/INSP	OVERRIDE/JETTISON FUEL PUMP WIRING
28-025-04	28-22-15-6A	28-025		CHECK/INSP	OVERRIDE/JETTISON FUEL PUMP WIRING
28-026-01	28-22-03-6A	28-026		FUNCTIONAL	FUEL BOOST PUMP MOTOR HOUSING BOND
28-026-02	28-22-03-6A	28-026		FUNCTIONAL	FUEL BOOST PUMP MOTOR HOUSING BOND
28-026-03	28-22-05-6A	28-026		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-026-04	28-22-05-6A	28-026		FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
28-026-05	28-22-05-6A			FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-026-06	28-22-05-6A			FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-026-07	28-22-05-6A			FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-026-08	28-22-05-6A			FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-026-09	28-22-05-6A			FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-026-10	28-22-05-6A			FUNCTIONAL	OVERRIDE/JETTISON PUMP HOUSING BOND
28-027-01	28-22-11-6A	28-027		FUNCTIONAL	FUEL SHUTOFF VALVE BOND
28-027-02	28-22-11-6A	28-027		FUNCTIONAL	FUEL SHUTOFF VALVE BOND
28-028-01	28-22-12-6A	28-028		FUNCTIONAL	FUEL CROSSFEED VALVE BOND
28-029-01	28-25-01-6A	28-029		FUNCTIONAL	APU DC FUEL PUMP MOTOR HOUSING BOND
28-030-01	28-25-02-6A	28-030		FUNCTIONAL	APU FUEL SHUTOFF VALVE BOND
28-031-01	28-25-04-6A	28-031		FUNCTIONAL	APU FUEL ISOLATION VALVE BOND
28-032-01	28-26-11-6A	28-032		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND
28-032-02	28-26-11-6A	28-032		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND
28-032-03	28-26-11-6A	28-032		FUNCTIONAL	DEFUELING VALVE ACTUATOR BOND
28-033-01	28-31-05-6A	28-033		FUNCTIONAL	JETTISON NOZZLE VALVE BOND
28-033-02	28-31-05-6A	28-033		FUNCTIONAL	JETTISON NOZZLE VALVE BOND
28-034-01	28-31-04-6A	28-034		FUNCTIONAL	JETTISON TRANSFER VALVE BOND
28-034-02	28-31-04-6A	28-034		FUNCTIONAL	JETTISON TRANSFER VALVE BOND
28-035-01	28-41-09-6A	28-035		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-035-02	28-41-09-6A	28-035		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-035-03	28-41-09-6A	28-035		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-035-04	28-41-09-6A	28-035		CHECK/INSP	FQIS IN-TANK WIRE HARNESS SUPPORT
28-036-01	28-41-09-6A	28-036		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-036-02	28-41-09-6A	28-036		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-036-03	28-41-09-6A	28-036		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-036-04	28-41-09-6A	28-036		CHECK/INSP	FQIS IN-TANK COMPONENTS
28-037-01	28-41-24-2A	28-037		CHECK/INSP	DENSITOMETER HSP CHECK/INSPECTION
28-038-01	28-41-24-6A	28-038		FUNCTIONAL	DENSITOMETER HSP BOND CHECK
29-001-C1-1	29-11-00-6A 29-11-00-6E			CHECK/INSP	SYS L EDP/ACMP PRESS & RETURN FILTER
29-001-C1-2	29-11-00-6A 29-11-00-6E			CHECK/INSP	SYS R EDP/ACMP PRESS & RETURN FILTER
29-002-01-1	29-11-25-4A	29-002		CLEAN	SYS L HYD RESERVOIR PRESS AIR FILTER
29-002-01-2	29-11-25-4A	29-002		CLEAN	SYS R HYD RESERVOIR PRESS AIR FILTER

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
29-003-01	29-11-00-6F	29-003		FUNCTIONAL	HYDRAULIC SYSTEMS (INTERNAL LEAKAGE)
29-003-02	29-11-00-6G	29-003		FUNCTIONAL	ELEVATOR AND RUDDER PCA'S
29-004-01-1	29-11-00-6B	29-004	W-29-001-C1-1	CHECK/INSP	SYS L HYD EDP/ACMP CASE DRAIN FILTER
29-004-01-2	29-11-00-6B	29-004	W-29-001-C1-2	CHECK/INSP	SYS R HYD EDP/ACMP CASE DRAIN FILTER
29-005-01	12-13-05-3A	29-005		CHECK/INSP	SYS C HYDRAULIC ADP OIL LEVEL
29-006-C1	29-11-00-6C 29-11-00-6E			CHECK/INSP	SYS C ACMP/ADP PRESS & RETURN FILTER
29-007-01	29-11-26-4A	29-007		CLEAN	SYS C HYD RESERVOIR PRESS AIR FILTER
29-009-01	29-11-00-6D	29-009	W-29-005-01	CHECK/INSP	SYS C HYD ACMP/ADP CASE DRAIN FILTER
29-010-01	29-11-00-5A	29-010		OPERATIONAL	ADP SPEED TOPPING SHUTDOWN CIRCUITRY
29-013-01	29-11-07-4A	29-013		OPERATIONAL	ISOLATED ACMP SUPPLY SHUTOFF VALVE
29-013-02	29-11-08-4A	29-013		OPERATIONAL	ISOLATED ACMP PRESSURE SHUTOFF VALVE
29-015-01	29-21-00-5A	29-015	B-29-018-01	OPERATIONAL	AUTO & MANUAL RAT DEPLOYMENT SYSTEMS
29-018-01	29-21-11-4A	29-018	A-29-015-01	CHECK/INSP	RAT CHECKOUT MODULE FILTERS
29-019-01	29-33-00-5A			OPERATIONAL	HYDRAULIC RESERVOIR QUANTITY - L,R,C
29-019-02	29-33-00-5A			OPERATIONAL	HYDRAULIC RESERVOIR QUANTITY - L,R,C
29-020-01	29-21-19-4A			DISCARD	RAM AIR TURBINE ISOLATION CHK VALVE
29-021-01	29-22-00-5A	29-021		OPERATIONAL	POWER TRANSFER UNIT (PTU) SYSTEM
29-022-01	29-22-00-5B	29-022		FUNCTIONAL	PTU SYSTEM RETURN COMPENSATOR MODULE
29-023-01	29-22-03-4A	29-023		CHECK/INSP	PTU CASE DRAIN FILTER
29-024-01	27-41-00-5E	29-024		FUNCTIONAL	STABILIZER TRIM RATE RELIEF VALVE
29-025-52	12-22-04-3A			SERVICE	SYS C HYDRAULIC ADP OIL CHANGE
29-026-01	12-13-05-3B	29-026		CHECK/INSP	SYS C HYDRAULIC ADP OIL LEVEL
29-027-02	29-11-31-4A	29-027		REPLACE	SYS C HYDRAULIC ADP GEARBOX FILTER
29-028-01	29-11-28-5A	29-028		OPERATIONAL	SYST. C RESERVOIR PRESS. S-O VALVE
30-001-01-1	30-11-03-4A	30-001	W-30-002-01-1	FUNCTIONAL	LEFT WING TAI TEMPERATURE SWITCH
30-001-01-2	30-11-03-4A	30-001	W-30-002-01-2	FUNCTIONAL	RIGHT WING TAI TEMPERATURE SWITCH
30-002-01-1	30-11-04-4A	30-002	W-30-001-01-1	FUNCTIONAL	LEFT WING TAI PRESSURE SWITCH
30-002-01-2	30-11-04-4A	30-002	W-30-001-01-2	FUNCTIONAL	RIGHT WING TAI PRESSURE SWITCH
30-003-01-1	30-21-00-5A	30-003		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-003-01-2	30-21-00-5A	30-003		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-003-02-1	30-21-00-5A	30-003		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-003-02-2	30-21-00-5A	30-003		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-003-03-1	30-21-00-5A	30-003		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-003-03-2	30-21-00-5A	30-003		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-46



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
30-003-04-1	30-21-05-4A	30-003		FUNCTIONAL	ENGINE 1 TAI PNEUMATIC RELIEF VALVE
30-003-04-2	30-21-05-4A	30-003		FUNCTIONAL	ENGINE 2 TAI PNEUMATIC RELIEF VALVE
30-003-05-1	30-21-00-5A	30-003		FUNCTIONAL	ENGINE 1 INLET TAI PRESSURE SWITCH
30-003-05-2	30-21-00-5A	30-003		FUNCTIONAL	ENGINE 2 INLET TAI PRESSURE SWITCH
30-007-01	30-81-00-5A			OPERATIONAL	PRIMARY ICE DETECTION SYSTEM
31-001-01	31-31-01-2A			OPERATIONAL	FLIGHT DATA RECORDER PARAMETERS
31-001-06	31-31-01-4A		W-31-001-01	OPERATIONAL	FLIGHT DATA RECORDER PARAMETERS
31-002-02	31-31-02-2B	31-002		RESTORE	DIGITAL FLIGHT DATA RECORDER ULB
31-002-03	31-31-02-2C	31-002		OPERATIONAL	FLIGHT DATA RECORDER ULB
31-004-01	31-51-04-4A	31-004		OPERATIONAL	WARNING ELECTRONICS UNIT CARD MODULE
31-007-01	31-41-00-2A	31-007		OPERATIONAL	EICAS MAINTENANCE MESSAGES
31-008-01	31-41-02-4A	31-008		OPERATIONAL	RIGHT EICAS COMPUTER
31-009-01	31-41-01-4A			CLEAN/INSP	EICAS DISPLAY UNIT AIR INLET SCREEN
31-050-01	31-63-00-2A	31-050		OPERATIONAL	EICAS MAINTENANCE MESSAGES
31-051-01	31-51-00-5B			OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-051-02	31-51-00-5B			OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-051-03	31-51-00-5B			OPERATIONAL	TAKE-OFF WARNING SYSTEM
31-052-01	31-51-00-5C			OPERATIONAL	TAKE-OFF WARNING SYSTEM
32-021-01	32-35-00-5A	32-021		OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-021-02	32-35-00-5A			OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-024-01-1	32-41-08-6A	32-024		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-024-01-2	32-41-08-6A	32-024		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-024-02-1	32-41-08-6A			CHECK/INSP	LEFT MAIN GEAR BRAKES
32-024-02-2	32-41-08-6A			CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-024-03-1	32-41-08-6A			CHECK/INSP	LEFT MAIN GEAR BRAKES
32-024-03-2	32-41-08-6A			CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-024-04-1	32-41-08-6A			CHECK/INSP	LEFT MAIN GEAR BRAKES
32-024-04-2	32-41-08-6A			CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-024-05-1	32-41-08-6A			CHECK/INSP	LEFT MAIN GEAR BRAKES
32-024-05-2	32-41-08-6A			CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-025-01	32-41-00-5A	32-025		OPERATIONAL	ALTERNATE BRAKE SYSTEM/SELECTOR VALV
32-025-02	32-41-00-5A			OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-025-03	32-41-00-5A			OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-025-04	32-41-00-5A			OPERATIONAL	ALT BRAKE SYSTEM/SELECTOR VALVE
32-025-05	32-41-00-5A			OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
32-025-06	32-41-00-5A			OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-025-07	32-41-00-5A			OPERATIONAL	ALTERNATE BRAKE SELECTOR VALVE
32-026-01	32-41-00-2A	32-026		OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-026-02	32-41-00-2A			OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-026-03	32-41-00-2A			OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-026-04	32-41-00-2A			OPERATIONAL	ANTISKID MODULE HYDRAULIC FUSES
32-028-01	12-15-04-3A	32-028		SERVICE	PARKING BRAKE ACCUMULATOR
32-028-02	12-15-04-3A			SERVICE	PARKING BRAKE ACCUMULATOR
32-029-01	32-45-04-6A	32-029	W-32-030-01	CHECK/INSP	MAIN & NOSE GEAR TIRES
32-029-02	32-45-00-A			CHECK/INSP	NOSE AND MAIN GEAR TIRES AND WHEELS
32-029-04	12-15-03-3B	32-029	W-32-029-01	SERVICE	TIRE PRESSURE
32-029-05	32-45-04-6A		W-32-030-02	CHECK/INSP	MAIN & NOSE GEAR TIRES
32-029-06	32-45-04-6A		W-32-030-03	CHECK/INSP	MAIN & NOSE GEAR TIRES
32-029-07	32-45-04-6A		W-32-030-05	CHECK/INSP	MAIN & NOSE GEAR TIRES
32-029-08	12-15-03-3B		W-32-029-07	SERVICE	TIRE PRESSURE
32-030-01	32-45-03-6A	32-030	W-32-029-01	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-030-02	32-45-03-6A		W-32-029-05	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-030-03	32-45-03-6A		W-32-029-06	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-030-04	32-45-03-6A		W-32-029-05	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-030-05	32-45-03-6A		W-32-029-07	CHECK/INSP	MAIN AND NOSE GEAR WHEELS
32-035-01	32-51-02-B	32-035		CHECK/INSP	CENTERING & RUDDER INTERCONNECT MECH
32-037-01	32-42-00-5A			FUNCTIONAL	ANTI-SKID/AUTOBRAKE CONTROL UNIT
32-037-02	32-42-00-5A			FUNCTIONAL	ANTI-SKID/AUTOBRAKE CONTROL UNIT
32-038-01	32-41-05-4A	32-038		OPERATIONAL	ACCUMULATOR ISOLATION VALVE
32-040-01	32-41-00-5B			OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-040-02	32-41-00-5B			OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-040-03	32-41-00-5B			OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-040-04	32-41-00-5B			OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-040-05-1	12-15-09-3A			SERVICE	LEFT BRAKE SURGE ACCUMULATOR
32-040-05-2	12-15-09-3A			SERVICE	RIGHT BRAKE SURGE ACCUMULATOR
32-040-05	32-41-00-5B			OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-040-06	32-41-00-5B			OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-040-07	32-41-00-5B			OPERATIONAL	AUTOMATIC GEAR RETRACTION BRAKE
32-040-51	12-15-05-3A	32-040		CHECK/INSP	TAIL SKID POP-UP INDICATOR
32-041-01	32-71-04-5A			FUNCTIONAL	TAIL SKID HYDRAULIC FUSE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-48



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
32-041-51	32-61-00-5B	32-041		OPERATIONAL	TAIL SKID WARNING SYSTEM
32-042-51	32-61-00-5A	32-042		OPERATIONAL	TAIL SKID WARNING PSEU BITE TEST
32-043-01	32-21-01-A	32-043		RESTORE	NOSE LANDING GEAR
32-044-01	32-21-01-4A	32-044		REPLACE	NOSE LANDING GEAR
32-044-51	32-11-01-A	32-044		RESTORE	MAIN LANDING GEAR (LEFT OR RIGHT)
32-045-01-1	32-11-01-4A			REPLACE	LEFT MAIN LANDING GEAR
32-045-01-2	32-11-01-4A			REPLACE	RIGHT MAIN LANDING GEAR
32-045-02-1	32-11-01-4A			REPLACE	LEFT MAIN LANDING GEAR
32-045-02-2	32-11-01-4A			REPLACE	RIGHT MAIN LANDING GEAR
32-045-03-1	32-11-01-4A			REPLACE	LEFT MAIN LANDING GEAR
32-045-03-2	32-11-01-4A			REPLACE	RIGHT MAIN LANDING GEAR
32-045-04-1	32-11-01-4A			REPLACE	LEFT MAIN LANDING GEAR
32-045-04-2	32-11-01-4A			REPLACE	RIGHT MAIN LANDING GEAR
32-045-05-1	32-11-01-4A			REPLACE	LEFT MAIN LANDING GEAR
32-045-05-2	32-11-01-4A			REPLACE	RIGHT MAIN LANDING GEAR
32-045-06-1	32-11-01-4A			REPLACE	LEFT MAIN LANDING GEAR
32-045-06-2	32-11-01-4A			REPLACE	RIGHT MAIN LANDING GEAR
32-046-01	32-45-05-A			CHECK/INSP	NLG SPIN BRAKE SPRING ARM
32-046-02-1	32-32-19-5A			FUNCTIONAL	TRUCK POSITIONER HYDRAULIC FUSES
32-046-02-2	32-32-19-5A			FUNCTIONAL	TRUCK POSITIONER HYDRAULIC FUSES
32-046-05-1	32-11-20-A		W-32-046-06-1	RESTORE	BRAKE ROD BOLT
32-046-05-2	32-11-20-A		W-32-046-06-2	RESTORE	BRAKE ROD BOLT
32-046-06-1	32-11-20-B		W-32-046-05-1	CHECK/INSP	BRAKE ROD BOLT BUSHINGS
32-046-06-2	32-11-20-B		W-32-046-05-2	CHECK/INSP	BRAKE ROD BOLT BUSHINGS
32-046-51-1	12-15-01-3B	32-046		SERVICE	MAIN GEAR SHOCK STRUT
32-046-51-2	12-15-01-3B	32-046		SERVICE	MAIN GEAR SHOCK STRUT
32-047-51	32-31-00-5A			OPERATIONAL	LANDING GEAR CONTROL ELEC CIRCUITS
32-047-52	32-31-00-5A	32-047		OPERATIONAL	LANDING GEAR CONTROL ELEC CIRCUITS
32-048-01-1	12-15-01-3A			CHECK/INSP	MAIN GEAR SHOCK STRUT
32-048-01-2	12-15-01-3A			CHECK/INSP	MAIN GEAR SHOCK STRUT
32-048-02	12-15-02-3A			CHECK/INSP	NOSE GEAR SHOCK STRUT
32-048-51	32-35-00-5A			OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-048-52	32-35-00-5A	32-048		OPERATIONAL	MAIN/NOSE GEAR ALT EXTEND SYSTEM
32-049-01-1	32-11-01-C			CHECK/INSP	LEFT MLG AFT TRUNNION INSPECTION
32-049-01-2	32-11-01-C			CHECK/INSP	RIGHT MLG AFT TRUNNION INSPECTION

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
32-049-51	32-35-00-5B			OPERATIONAL	DOWN LOCK SPRINGS AND RELEASE HOOKS
32-049-52	32-35-00-5B	32-049		OPERATIONAL	DOWN LOCK SPRINGS AND RELEASE HOOKS
32-050-01	32-44-00-5A	32-050		FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-050-02	32-44-00-5A			FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-050-03	32-44-00-5A			FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-050-04	32-44-00-5A			FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-050-05	32-44-00-5A			FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-050-06	32-44-00-5A			FUNCTIONAL	PARKING BRAKE SYSTEM TEST
32-051-01-1	32-41-08-6A			CHECK/INSP	LEFT MAIN GEAR BRAKES
32-051-01-2	32-41-08-6A			CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-051-02-1	32-41-08-6A	32-051		CHECK/INSP	LEFT MAIN GEAR BRAKES
32-051-02-2	32-41-08-6A	32-051		CHECK/INSP	RIGHT MAIN GEAR BRAKES
32-052-01	32-71-08-6A	32-052		CHECK/INSP	TAIL SKID POP-UP INDICATOR
32-400-00	32-400-00	32-400-00		GEN VISUAL	NOSE LANDING GEAR
32-402-00	32-402-00	32-402-00		GEN VISUAL	NOSE LANDING GEAR ASSEMBLY
32-404-00	32-404-00	32-404-00		DETAILED EX	NOSE LANDING GEAR ASSEMBLY
32-406-00	32-406-00	32-406-00		GEN VISUAL	NOSE LANDING GEAR DOOR ASSEMBLY
32-408-00	32-408-00	32-408-00		GEN VISUAL	NOSE LG FWD AND AFT DOOR ASSEMBLY
32-410-00	32-410-00	32-410-00		RESTORE	LEFT MAIN LG AND COMPONENTS
32-412-00	32-412-00	32-412-00		GEN VISUAL	LEFT MAIN LANDING GEAR ASSEMBLY
32-414-00	32-414-00	32-414-00		DETAILED EX	LEFT MAIN LANDING GEAR ASSEMBLY
32-416-00	32-416-00	32-416-00		GEN VISUAL	LEFT MAIN LANDING GEAR ASSEMBLY
32-418-00	32-418-00	32-418-00		GEN VISUAL	LEFT MAIN LANDING GEAR BODY DOOR
32-420-00	32-420-00	32-420-00		GEN VISUAL	LEFT MAIN LANDING GEAR DOOR
32-422-00	32-422-00	32-422-00		DETAILED EX	L MAIN GEAR DOOR CENTER HINGE BEAM
32-424-00	32-424-00	32-424-00		RESTORE	RIGHT MAIN LANDING GEAR ASSEMBLY
32-426-00	32-426-00	32-426-00		GEN VISUAL	RIGHT MAIN LANDING GEAR ASSEMBLY
32-428-00	32-428-00	32-428-00		DETAILED EX	RIGHT MAIN LANDING GEAR ASSEMBLY
32-430-00	32-430-00	32-430-00		GEN VISUAL	RIGHT MAIN LANDING GEAR ASSEMBLY
32-432-00	32-432-00	32-432-00		GEN VISUAL	RIGHT MAIN LANDING GEAR BODY DOOR
32-434-00	32-434-00	32-434-00		GEN VISUAL	R MAIN LANDING GEAR DOOR ASSEMBLY
32-436-00	32-436-00	32-436-00		DETAILED EX	R MAIN GEAR DOOR CENTER HINGE BEAM
33-001-01	33-51-00-5A	33-001	W-33-001-02	OPERATIONAL	EMERGENCY LIGHTS
33-002-01	33-51-02-2A	33-002		FUNCTIONAL	SELF-ILLUMINATED EXIT SIGNS
33-003-01	33-51-07-2A	33-003	W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-50



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
33-003-02	33-51-07-2A		W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-003-03	33-51-07-2A		W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-003-04	33-51-07-2A		W-33-001-01	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-003-06	33-51-07-2B			FUNCTIONAL	EMERGENCY LIGHT POWER SUPPLIES
33-003-07	33-51-07-2C			OPERATIONAL	EXIT MARKER DIODES
33-003-08	33-51-07-2D		W-33-003-06	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-003-09	33-51-07-2B	33-003		FUNCTIONAL	EMERGENCY LIGHT POWER SUPPLIES
33-003-10	33-51-07-2C	33-003		OPERATIONAL	EXIT MARKER DIODES
33-003-11	33-51-07-2D	33-003	W-33-003-06	RESTORE	EMERGENCY LIGHT POWER SUPPLIES
33-004-C1	33-16-00-5A 22-10-00-5A 22-10-00-5B 22-32-00-5A 30-31-00-A 31-51-00-5A 34-16-00-5A			OPERATIONAL	MASTER DIM & TEST
33-004-C2	33-16-00-5A 22-10-00-5A 22-10-00-5B 22-32-00-5A 30-31-00-A 31-51-00-5A 34-16-00-5A			OPERATIONAL	MASTER DIM & TEST
33-004-C3	33-16-00-5A 30-31-00-A 31-51-00-5A			OPERATIONAL	MASTER DIM & TEST
33-004-C4	33-16-00-5A 30-31-00-A 31-51-00-5A			OPERATIONAL	MASTER DIM & TEST
33-006-01	33-51-00-5B		W-33-001-01	OPERATIONAL	EMERGENCY LIGHTS
33-008-01	33-35-00-2A	33-008		OPERATIONAL	CREW WARNING CARGO LIGHTS
33-009-01	33-51-00-5D			OPERATIONAL	EMERGENCY LIGHTS
34-001-C1	34-11-00-3A 34-11-00-3B 34-11-00-3C 34-11-00-3D			DRAIN	PITOT-STATIC SYSTEMS
34-004-01	34-11-00-5A	34-004	A-34-001-C1	FUNCTIONAL	ALTERNATE STATIC LINE LEAK CHECK

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
34-005-C1	34-13-00-5A 34-13-00-5B			FUNCTIONAL	AIR DATA STANDBY INSTRUMENTS
34-007-01	34-11-00-5B	34-007	A-34-001-C1	FUNCTIONAL	STBY AIRSPEED INDICATOR AUX PITOT
34-007-03	34-11-00-5B		A-34-001-C1	FUNCTIONAL	STBY AIRSPEED INDICATOR AUX PITOT
34-007-04	34-11-00-5A		A-34-001-C1	FUNCTIONAL	ALTERNATE STATIC LINE LEAK CHECK
34-009-01	34-22-00-5A	34-009	A-34-010-01	OPERATIONAL	INSTRUMENT SOURCE SELECT SWITCHING
34-010-01	34-22-00-5B	34-010	B-34-009-01	OPERATIONAL	CENTER EFIS SYMBOL GENERATOR
34-011-01	34-46-00-5A			OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-011-02	34-46-00-5A			OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-011-03	34-46-00-5A			OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-011-04	34-46-00-5A			OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-011-09	34-46-00-5A			OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-011-12	34-46-00-5A			OPERATIONAL	GROUND PROXIMITY WARNING SYSTEM
34-012-01	34-53-00-5A	34-012		FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-012-02	34-53-00-5A			FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-012-03	34-53-00-5A			FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-012-04	34-53-00-5A			FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-012-05	34-53-00-5A			FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-012-06	34-53-00-5A			FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-012-07	34-53-00-5A			FUNCTIONAL	AIR TRAFFIC CONTROL SYSTEM (ATC)
34-013-02	34-11-01-4A			REPLACE	PITOT-STATIC SYSTEM PROBES (RVSM)
34-013-51	34-12-00-6A	34-013		OPERATIONAL	AIR DATA COMPUTER
34-014-02	34-26-00-5A	34-014		OPERATIONAL	ADIRU COMPUTERS
34-015-01	34-24-03-5A	34-015		CHECK/INSP	INTEGRATED STANDBY FLIGHT DISPLAY
34-016-01	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-02	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-03	34-24-04-4A	34-016		REPLACE	INTEGRATED STANDBY FLIGHT DISPLAY
34-016-04	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-06	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-07	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-08	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-09	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-10	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-11	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
34-016-12	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-52



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
34-016-13	34-61-00-2A			SERVICE	FLIGHT MANAGEMENT COMPUTER DATA BASE
35-001-C1	35-11-00-5A 35-11-00-A			CHECK/INSP	CREW OXYGEN SYSTEM PRESSURE/CYLINDER
35-003-01	35-11-00-5B	35-003		OPERATIONAL	CREW OXYGEN LOW PRESSURE LINE
35-004-C1	35-21-00-5A 35-21-00-5B			FUNCTIONAL	PASS OXY DOOR LATCH AND ALT PRESS SW
35-006-01	35-00-00-6A	35-006		CHECK/INSP	PASSENGER CHEMICAL OXYGEN GENERATORS
35-007-01	35-21-04-4A	35-007		REPLACE	PASSENGER CHEMICAL OXYGEN GENERATORS
35-008-01	35-31-01-6C	35-008		CHECK/INSP	PORTABLE OXYGEN BOTTLES
35-009-01	35-00-00-6B	35-009		CHECK/INSP	PORTABLE CHEMICAL OXYGEN GENERATORS
35-010-01	35-31-00-A	35-010		REPLACE	PORTABLE CHEMICAL OXYGEN GENERATORS
35-011-51	35-00-00-A			CHECK/INSP	PORTABLE OXYGEN BOTTLES
35-012-01	35-21-05-6A	35-012	B-35-004-C1	CHECK/INSP	PASSENGER OXYGEN MASKS
35-013-01	35-11-00-5C	35-013		OPERATIONAL	CREW OXYGEN MASK/REGULATOR
35-014-01	35-11-00-B	35-014		FUNCTIONAL	CREW OXYGEN MASK/REGULATOR
35-015-01	35-11-00-C			CHECK/INSP	CREW OXYGEN CYLINDER
36-BCY-90-1	36-00-24-5A			OPERATIONAL	PNEUMATIC SYSTEM TEST - LEFT ENGINE
36-BCY-90-2	36-00-24-5A			OPERATIONAL	PNEUMATIC SYSTEM TEST - LEFT ENGINE
36-002-01	36-11-00-5A	36-002		FUNCTIONAL	AIR SUPPLY DISTRIBUTION
36-002-02	36-11-00-5A			FUNCTIONAL	AIR SUPPLY DISTRIBUTION
36-003-01	36-11-00-5B	36-003		OPERATIONAL	CENTER ISOLATION VALVE
36-003-02	36-11-00-5B			OPERATIONAL	CENTER ISOLATION VALVE
36-004-01	36-11-05-6A	36-004		CHECK/INSP	ISOLATION BYPASS CHECK VALVES
36-005-01-1	36-11-06-6A	36-005		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-005-01-2	36-11-06-6A	36-005		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-005-02-1	36-11-06-6A	36-005		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-005-02-2	36-11-06-6A	36-005		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-007-01	36-11-11-6A	36-007		CHECK/INSP	APU AIR SUPPLY CHECK VALVE
36-008-01	36-11-16-5A	36-008		OPERATIONAL	AIR SUPPLY BITE MODULE
36-008-02	36-11-16-5B			OPERATIONAL	AIR SUPPLY PRECOOLING SYSTEM
36-009-01-1	36-22-00-5A	36-009		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-009-01-2	36-22-00-5B	36-009		FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-009-02-1	36-22-00-5A			FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-009-02-2	36-22-00-5B			FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-009-03-1	36-22-00-5A			FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
36-009-03-2	36-22-00-5B			FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-009-10-1	36-22-01-4A			FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-009-10-2	36-22-01-4A			FUNCTIONAL	AIR SUPPLY THERMAL OVERTEMP SWITCH
36-011-05-1	36-11-01-6C	36-011		CHECK/INSP	ENG 1 INTERMEDIATE PRESSURE DUCT
36-011-05-2	36-11-01-6C	36-011		CHECK/INSP	ENG 2 INTERMEDIATE PRESSURE DUCT
36-011-51-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-51-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-53-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-53-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-54-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-54-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-55-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-55-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-56-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-56-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-57-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-57-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-58-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-58-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-60-1	36-11-06-6B			CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-011-60-2	36-11-06-6B			CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-011-61-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-61-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-61-3	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-61-4	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-011-62-1	36-11-06-6B	36-011		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 1
36-011-62-2	36-11-06-6B	36-011		CHECK/INSP	AIR SUPPLY IP CHECK VALVE - ENGINE 2
36-011-63-1	36-11-08-4B			REPLACE	ENGINE 1 HP CONTROLLER AIR FILTER
36-011-63-2	36-11-08-4B			REPLACE	ENGINE 2 HP CONTROLLER AIR FILTER
36-012-01-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-01-2	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-012-02-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-02-2	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-012-03-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-03-2	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-54



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
36-012-03-3	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-03-4	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-012-04-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-04-2	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-012-06-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-06-2	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-012-08-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-08-2	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-012-09-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-09-2	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-012-10-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-10-2	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-11-1	36-11-09-2B			REPLACE	ENGINE 1 PRSOV AIR FILTERS
36-012-11-2	36-11-09-2B			REPLACE	ENGINE 2 PRSOV AIR FILTERS
36-013-01-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-01-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-03-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-03-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-04-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-04-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-05-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-05-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-07-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-07-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-08-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-08-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-09-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-013-09-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-014-01-1	36-11-19-4B			REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-014-01-2	36-11-19-4B			REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-014-02-1	36-11-19-4B			REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-014-02-2	36-11-19-4B			REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-015-01-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-015-01-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-015-02-1	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
36-015-02-2	36-11-16-4A			REPLACE	FAN AIR MODULATING VALVE AIR FILTER
36-016-01-1	36-11-19-4B			REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-016-01-2	36-11-19-4B			REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-017-01-1	36-11-19-4B			REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-017-01-2	36-11-19-4B			REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-017-02-1	36-11-19-4B			REPLACE	ENGINE 1 PRV CONTROLLER AIR FILTER
36-017-02-2	36-11-19-4B			REPLACE	ENGINE 2 PRV CONTROLLER AIR FILTER
36-018-01	36-23-00-5A			OPERATIONAL	AIR SUPPLY ASCTU BITE DISPLAY
36-018-2	36-23-00-5A	36-018		OPERATIONAL	AIR SUPPLY ASCTU BITE DISPLAY
38-001-01	38-10-00-2A	38-001		DISINFECT	POTABLE WATER SYSTEM
38-001-02	38-10-00-2A			DISINFECT	POTABLE WATER SYSTEM
38-001-04	38-10-60-2A	38-001	W-38-001-03	DISINFECT	POTABLE WATER SYSTEM
38-002-C1	38-15-02-4A 38-15-02-4B	38-002		REPLACE	POTABLE WATER SYSTEM AIR FILTERS
38-004-01	38-32-00-5A	38-004		OPERATIONAL	VACUUM WATER BREAKS
38-004-02	38-32-00-5A			OPERATIONAL	VACUUM WATER BREAKS
38-005-01	38-33-00-5C	38-005		OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-005-02	38-33-00-5B	38-005		OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-005-05	38-33-00-5B			OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-005-06	38-33-00-5B			OPERATIONAL	SENSOR CONTROL AND LOGIC MODULES
38-006-01	38-15-02-4C			REPLACE	POT WATER PRESSURIZATION AIR FILTER
38-006-51	38-32-60-5A	38-006		OPERATIONAL	SERVICE PANEL WASTE DRAIN FTG SEAL
38-008-01	38-32-06-4A			REPLACE	VACUUM BLOWER AIR FILTERS
38-008-51	38-10-60-A	38-008	W-38-001-04	CHECK/INSP	POTABLE WATER TANK AND SUPPLY LINE
38-009-01	38-32-11-2A			CHECK/INSP	WASTE TANK LEVEL SENSORS/SEPARATOR
38-009-04	38-32-11-2A			CHECK/INSP	WASTE TANK LEVEL SENSORS/SEPARATOR
38-010-01	38-10-00-5A			FUNCTIONAL	PRESSURE ACTUATED COMPRESSOR SWITCH
38-011-01	38-15-06-2A			FUNCTIONAL	WATER TANK PRESSURE RELIEF VALVE
38-012-01	38-11-01-2A			CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-012-02	38-11-01-2A			CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-012-03	38-11-01-2A			CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-012-04	38-11-01-2A			CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-012-06	38-11-01-2A			CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-012-07	38-11-01-2A			CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-012-08	38-11-01-2A			CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-56



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
38-012-09	38-11-01-2A			CHECK/INSP	POTABLE WATER TANK SUPPORT FITTINGS
38-013-01	38-32-03-4A			RESTORE	WASTE TANK DRAIN VALVE SEALS
38-013-02	38-32-03-4A			RESTORE	WASTE TANK DRAIN VALVE SEALS
38-013-03	38-32-03-4A			RESTORE	WASTE TANK DRAIN VALVE SEALS
38-014-01	38-32-17-2A			CLEAN/INSP	WASTE TANK RINSE NOZZLES
38-015-01	38-32-18-2A			REPLACE	WASTE TANK RINSE LINE FILTERS
38-016-01	38-32-00-5D			OPERATIONAL	WASTE TANK DRAIN VALVES
38-016-02	38-32-00-5D			OPERATIONAL	WASTE TANK DRAIN VALVES
38-016-03	38-32-00-5D			OPERATIONAL	WASTE TANK DRAIN VALVES
49-008-01	49-15-01-4B	49-008		CHECK/INSP	APU AIR INTAKE DUCT - INTERNAL
49-013-01	49-16-00-A	49-013		CHECK/INSP	APU DRAIN MAST
49-014-C1	49-27-04-6A 49-27-04-6B			CHECK/INSP	APU MAGNETIC CHIP DETECTORS
49-019-01	49-21-00-A	49-019		REPLACE	APU TURBINE DISKS
49-021-01	12-13-04-3A	49-021		SERVICE	APU OIL LEVEL
49-021-04	12-13-04-3A			SERVICE	APU OIL LEVEL
49-023-C1	49-27-03-4A 49-27-03-4B			REPLACE	APU OIL PRESS & GEN SCAVENGE FILTERS
49-024-C1	49-27-03-6A 49-27-03-6B			CHECK/INSP	APU/GEN FILTER DIFF PRESS INDICATORS
49-028-01	49-27-00-A	49-028		FUNCTIONAL	GEARBOX SHUTOFF VALVE
49-029-01	49-27-00-B	49-029		FUNCTIONAL	GEARBOX PRESSURE REGULATING VALVE
49-032-01	49-31-00-A	49-032		CHECK/INSP	APU LP FUEL FILTER DIFF PRESS IND
49-049-01	49-61-05-2A	49-049		OPERATIONAL	APU CONTROL UNIT (ECU)
49-051-01	49-27-00-C	49-051		FUNCTIONAL	GENERATOR OIL FLTR DIFF PRESS SWITCH
49-060-01	49-53-06-2A			REPLACE	APU SURGE VALVE FILTER ELEMENT
49-060-51	49-16-02-7A	49-060		FUNCTIONAL	COMBUSTOR DRAIN VALVE
49-061-01	49-27-09-A			CHECK/INSP	APU FIREWALL
49-061-51	49-11-01-A	49-061		SPCL DETAIL	CONTAINMENT SYSTEM (POWER SECTION)
49-062-01	49-41-01-6A			CHECK/INSP	APU STARTER MOTOR BRUSH WEAR
49-062-51	49-21-00-B	49-062		REPLACE	1ST & 2ND STAGE COMPRESSOR IMPELLER
49-063-01	49-11-00-5A			OPERATIONAL	APU FIRE SHUTDOWN SYSTEM
49-063-02	49-11-00-5A			OPERATIONAL	APU FIRE SHUTDOWN SYSTEM
49-063-51	49-11-01-B	49-063		SPCL DETAIL	CONTAINMENT SYSTEM (LOAD COMPRESSOR)
49-064-01	49-27-09-6A			CHECK/INSP	APU OIL COOLER

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
49-064-51	49-21-00-C	49-064		REPLACE	APU LOAD COMPRESSOR IMPELLER
51-001-01	51-41-00-2A			CHECK/INSP	FUSELAGE DRAIN VALVES
52-001-01	52-11-00-5A	52-001		OPERATIONAL	ENTRY/SERVICE DOOR UPLATCH MECHANISM
52-001-02	52-11-00-5A	52-001		OPERATIONAL	ENTRY/SERVICE DOOR UPLATCH MECHANISM
52-001-03	52-11-00-5A			OPERATIONAL	ENTRY/SERVICE DOOR UPLATCH MECHANISM
52-002-01	52-11-25-A	52-002		CHECK/INSP	ENTRY/SERVICE DOOR HANDLE MECHANISM
52-002-02	52-11-25-A	52-002		CHECK/INSP	ENTRY/SERVICE DOOR HANDLE MECHANISM
52-006-01	52-11-21-2A	52-006		CHECK/INSP	COUNTERBALANCE LOAD LIMITER
52-006-02	52-11-21-2A	52-006		CHECK/INSP	COUNTERBALANCE LOAD LIMITER
52-009-01	52-11-33-A	52-009		CHECK/INSP	ENTRY/SERVICE DOOR LATCH MECHANISM
52-009-02	52-11-33-A	52-009		CHECK/INSP	ENTRY/SERVICE DOOR LATCH MECHANISM
52-010-01	52-11-31-A	52-010		CHECK/INSP	ENTRY DOOR SPRING HYDRAULIC SNUBBER
52-010-02	52-11-31-A	52-010		CHECK/INSP	ENTRY DOOR SPRING HYDRAULIC SNUBBER
52-014-01	52-21-01-2A	52-014		OPERATIONAL	OVERWING ESCAPE HATCHES
52-026-01	52-34-00-5A			OPERATIONAL	FWD CARGO DOOR OPERATING MECHANISM
52-027-01	52-33-00-5A			OPERATIONAL	LARGE FWD CARGO DOOR OPERATING MECH
52-027-02	52-35-00-5A	52-027		OPERATIONAL	AFT CARGO DOOR OPERATING MECHANISM
52-028-01	52-34-12-C			CHECK/INSP	CARGO DOOR ACTUATION/LATCH CMONENTS
52-035-01	52-71-00-5A			OPERATIONAL	FWD/E&E BAY, BULK CARGO DOOR WARNING
52-036-01	52-22-01-5A	52-036		OPERATIONAL	EMERGENCY EXIT DOOR MECHANISMS
52-038-01	52-36-02-6A			CHECK/INSP	BULK CARGO DOOR BALANCE MECHANISM
52-041-01	52-12-25-6A	52-041		CHECK/INSP	CREW ENTRY DOOR HANDLE MECHANISM
52-043-01	52-32-03-2A	52-043		REPLACE	MAIN DECK CARGO DOOR LIFT MECHANISM
52-047-C1	52-32-05-5A			OPERATIONAL	MAIN DECK CARGO DOOR
52-048-01	52-32-12-5A	52-048		FUNCTIONAL	MAIN DECK CARGO DOOR RATCHET BRAKE
52-057-01	52-71-09-2A	52-057		FUNCTIONAL	MAIN DECK CARGO DOOR WARNING SYSTEM
52-058-01	52-71-02-2A	52-058		FUNCTIONAL	LARGE FWD CARGO DOOR WARNING SYSTEM
52-059-01	52-71-03-2A	52-059		FUNCTIONAL	LARGE AFT CARGO DOOR WARNING SYSTEM
52-060-C1	52-33-00-5C 52-33-00-5D 52-33-00-5E			OPERATIONAL	LARGE FORWARD CARGO DOOR
52-061-C1	52-37-00-5C 52-37-00-5D 52-37-00-5E			OPERATIONAL	AFT LOWER LOBE LARGE CARGO DOOR
52-066-01	52-33-00-5B	52-066	W-52-027-01	OPERATIONAL	LARGE FWD CARGO DOOR NO-BACK BRAKES

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
52-067-01	52-37-00-5A	52-067		OPERATIONAL	LARGE AFT CARGO DOOR NO-BACK BRAKES
52-072-01	52-33-06-5A	52-072		FUNCTIONAL	FWD LG CARGO DOOR LATCH LOCK HANDLE
52-073-01	52-37-06-5A	52-073		FUNCTIONAL	AFT LG CARGO DOOR LATCH LOCK HANDLE
52-074-01	52-21-02-2A			FUNCTIONAL	SELF-ILLUMINATED O/H PULL HANDLE
52-075-01	52-51-07-4A			REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-075-02	52-51-07-4A			REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-075-03	52-51-07-4A			REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-075-04	52-51-07-4A			REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-075-06	52-51-07-4A			REPLACE	FLIGHT DECK DOOR STRIKE ASSEMBLY
52-076-01	52-51-14-6A			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-076-03	52-51-14-6A			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-076-04	52-51-14-6A			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-077-06	52-51-00-5C			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-077-07	52-51-00-5C			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-077-09	52-51-00-5C			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-077-11	52-51-00-5C			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-077-12	52-51-00-5C			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-078-01	52-51-00-5A			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-078-02	52-51-00-5A			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-078-03	52-51-00-5A			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-078-04	52-51-00-5A			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-078-06	52-51-00-5A			OPERATIONAL	FLIGHT DECK SECURITY DOOR
52-079-01	52-51-05-6A			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-079-02	52-51-05-6A			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-079-03	52-51-05-6A			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-080-01	52-51-14-6B			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-080-02	52-51-14-6B			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-080-03	52-51-14-6B			CHECK/INSP	FLIGHT DECK SECURITY DOOR
52-081-04	52-51-00-5B			FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-081-06	52-51-00-5B			FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-081-07	52-51-00-5B			FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-081-08	52-51-00-5B			FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-081-09	52-51-00-5B			FUNCTIONAL	FLIGHT DECK SECURITY DOOR
52-400-00	52-400-00	52-400-00		GEN VISUAL	BULK CARGO COMPARTMENT DOOR STOPS
52-402-00	52-402-00	52-402-00		GEN VISUAL	BULK CARGO COMPARTMENT DOOR

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
52-406-00	52-406-00	52-406-00		GEN VISUAL	FWD CARGO COMPARTMENT DOOR
52-408-00	52-408-00	52-408-00		GEN VISUAL	CARGO DOOR STOPS
52-410-00	52-410-00	52-410-00		GEN VISUAL	AFT CARGO DOOR
52-412-00	52-412-00	52-412-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-414-00	52-414-00	52-414-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-416-00	52-416-00	52-416-00		GEN VISUAL	ENTRY & GALLEY SERVICE DOORS
52-418-00	52-418-00	52-418-00		GEN VISUAL	OVERWING EMERGENCY EXIT HATCH
52-420-00	52-420-00	52-420-00		GEN VISUAL	EMERGENCY EXIT DOOR
52-422-00	52-422-00	52-422-00		GEN VISUAL	EMERGENCY EXIT DOOR
52-424-00	52-424-00	52-424-00		GEN VISUAL	CREW ENTRY DOOR
52-426-00	52-426-00	52-426-00		GEN VISUAL	CREW ENTRY DOORS
52-428-00	52-428-00	52-428-00		GEN VISUAL	CREW ENTRY DOOR
52-430-00	52-430-00	52-430-00		GEN VISUAL	MAIN DECK CARGO DOOR
52-432-00	52-432-00	52-432-00		SPCL DETAIL	STANDARD CARGO DOOR - FWD AND AFT
52-434-00	52-434-00	52-434-00		SPCL DETAIL	FWD LARGE CARGO DOOR
52-436-00	52-436-00	52-436-00		SPCL DETAIL	FWD LARGE CARGO DOOR
52-438-00	52-438-00	52-438-00		SPCL DETAIL	FWD LARGE CARGO DOOR
52-440-00	52-440-00	52-440-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-441-00	52-441-00	52-441-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-442-00	52-442-00	52-442-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-444-00	52-444-00	52-444-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-446-00	52-446-00	52-446-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-448-00	52-448-00	52-448-00		SPCL DETAIL	MAIN DECK CARGO DOOR
52-450-00	52-450-00	52-450-00		SPCL DETAIL	AFT LARGE CARGO DOOR
52-452-00	52-452-00	52-452-00		SPCL DETAIL	AFT LARGE CARGO DOOR
52-454-00	52-454-00	52-454-00		SPCL DETAIL	AFT LARGE CARGO DOOR
53-001-01	21-23-05-2B	53-001		OPERATIONAL	RETURN AIR GRILLE LOUVERS
53-001-02	21-23-05-2B			OPERATIONAL	RETURN AIR GRILLE LOUVERS
53-003-01-1	53-53-01-A		W-12-044-C1-1	CHECK/INSP	AFT W/W BULKHEAD SPHERICAL BEARING
53-003-01-2	53-53-01-A		W-12-044-C1-2	CHECK/INSP	AFT W/W BULKHEAD SPHERICAL BEARING
53-400-00	53-400-00	53-400-00		GEN VISUAL	BODY FLOOR BEAMS BELOW LAVS/GALLEYS
53-402-00	53-402-00	53-402-00		GEN VISUAL	CARGO FLOOR STRUCTURE
53-404-00	53-404-00	53-404-00		DETAILED IN	CARGO DOOR CUTOUTS
53-406-00	53-406-00	53-406-00		GEN VISUAL	BODY EXTERNAL SKIN
53-408-00	53-408-00	53-408-00		DETAILED EX	LARGE FWD CARGO DOOR HINGES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-60



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
53-410-00	53-410-00	53-410-00		GEN VISUAL	LWR BODY SKIN AT ANTENNA LOCATIONS
53-412-00	53-412-00	53-412-00		DETAILED EX	DOOR STOPS AND CUTOUTS
53-414-00	53-414-00	53-414-00		DETAILED IN	BODY STA. 132.5 BULKHEAD
53-416-00	53-416-00	53-416-00		GEN VISUAL	FUSELAGE LOWER LOBE
53-418-00	53-418-00	53-418-00		DETAILED IN	FWD EQUIP BAY ACCESS DOOR CUTOUT
53-420-00	53-420-00	53-420-00		GEN VISUAL	FUSELAGE EXTERIOR SURFACE
53-428-00	53-428-00	53-428-00		GEN VISUAL	NOSE LANDING GEAR WHEEL WELL
53-430-00	53-430-00	53-430-00		GEN VISUAL	AREA OUTBD & ABOVE NOSE WHEELWELL
53-432-00	53-432-00	53-432-00		DETAILED IN	BULKHEAD AND NOSE LANDING GEAR W/W
53-438-00	53-438-00	53-438-00		DETAILED IN	BODY FLOOR BEAM - STA 287
53-440-00	53-440-00	53-440-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-442-00	53-442-00	53-442-00		DETAILED IN	FWD ENTRY/SERVICE DOOR CUTOUTS
53-444-00	53-444-00	53-444-00		GEN VISUAL	MAIN EQUIPMENT CENTER ACCESS DOOR
53-446-00	53-446-00	53-446-00		DETAILED IN	MAIN EQUIPMENT CENTER
53-448-00	53-448-00	53-448-00		GEN VISUAL	MAIN EQUIPMENT CENTER ACCESS DOOR
53-450-00	53-450-00	53-450-00		DETAILED IN	BODY FLOOR BEAMS - STA 287 TO 347
53-452-00	53-452-00	53-452-00		GEN VISUAL	FUSELAGE LOWER LOBE
53-454-00	53-454-00	53-454-00		GEN VISUAL	LOWER LOBE INTERIOR - RIGHT
53-456-00	53-456-00	53-456-00		DETAILED IN	FORWARD CARGO DOOR LOWER SILL
53-458-00	53-458-00	53-458-00		DETAILED IN	FWD CARGO COMPARTMENT DOOR CUTOUT
53-460-00	53-460-00	53-460-00		DETAILED IN	BODY BELOW FWD CARGO COMPART FLOOR
53-462-00	53-462-00	53-462-00		DETAILED IN	BODY BELOW FWD CARGO FLOOR/STA 434
53-464-00	53-464-00	53-464-00		DETAILED IN	BODY BELOW FWD CARGO FLOOR
53-472-00	53-472-00	53-472-00		DETAILED IN	FWD LARGE CARGO DOOR CUTOUT
53-474-00	53-474-00	53-474-00		GEN VISUAL	AREA AFT OF FWD CARGO COMPARTMENT
53-476-00	53-476-00	53-476-00		GEN VISUAL	AREA AFT OF FWD CARGO COMPARTMENT
53-478-00	53-478-00	53-478-00		DETAILED IN	KEEL BEAM EXTENSION 738.5 - 785.9
53-480-00	53-480-00	53-480-00		DETAILED IN	BODY STA 785.9 BULKHEAD INNER CHORD
53-482-00	53-482-00	53-482-00		GEN VISUAL	FRONT SPAR BULKHEAD BELOW FLOOR
53-494-00	53-494-00	53-494-00		GEN VISUAL	INTERIOR FUSELAGE INSPECTION
53-496-00	53-496-00	53-496-00		DETAILED IN	WING CENTER SECTION UPPER SURFACE
53-502-00	53-502-00	53-502-00		GEN VISUAL	KEEL BEAM & WING CENTER SECTION
53-504-00	53-504-00	53-504-00		DETAILED IN	WING CENTER SECTION TENSION FITTING
53-506-00	53-506-00	53-506-00		GEN VISUAL	LOWER LOBE INTERIOR
53-508-00	53-508-00	53-508-00		DETAILED IN	BELOW FLOOR STRUCT - STA 955 TO 1065

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
53-510-00	53-510-00	53-510-00		DETAILED IN	BELOW FLOOR STRUCT - STA 955 TO 1065
53-518-00	53-518-00	53-518-00		GEN VISUAL	MAIN LANDING GEAR WHEEL WELL STRUCT
53-520-00	53-520-00	53-520-00		DETAILED IN	TRANSVERSE BEAMS
53-522-00	53-522-00	53-522-00		DETAILED IN	MAIN LANDING GEAR DOOR UPLOCK
53-524-00	53-524-00	53-524-00		DETAILED IN	REAR SPAR BULKHEAD AT WHEEL WELL
53-526-00	53-526-00	53-526-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-528-00	53-528-00	53-528-00		DETAILED IN	REAR SPAR AT KEEL BEAM
53-530-00	53-530-00	53-530-00		GEN VISUAL	MAIN LANDING GEAR WHEEL WELL STRUCT
53-532-00	53-532-00	53-532-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-534-00	53-534-00	53-534-00		DETAILED IN	MAIN LANDING GEAR DOOR UPLOCK
53-536-00	53-536-00	53-536-00		DETAILED IN	REAR SPAR BULKHEAD AT WHEEL WELL
53-538-00	53-538-00	53-538-00		DETAILED IN	TRANSVERSE BEAMS AT MAIN WHEEL WELLS
53-540-00	53-540-00	53-540-00		GEN VISUAL	KEEL BEAM - AFT SECTION
53-542-00	53-542-00	53-542-00		GEN VISUAL	BODY FWD OF AFT CARGO COMPARTMENT
53-544-00	53-544-00	53-544-00		DETAILED IN	BODY FWD OF AFT CARGO COMPARTMENT
53-548-00	53-548-00	53-548-00		DETAILED IN	BODY FWD OF AFT CARGO COMPARTMENT
53-550-00	53-550-00	53-550-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-552-00	53-552-00	53-552-00		GEN VISUAL	CARGO COMPARTMENT
53-554-00	53-554-00	53-554-00		DETAILED IN	AFT CARGO DOOR LOWER SILL
53-556-00	53-556-00	53-556-00		DETAILED IN	AFT CARGO COMPARTMENT DOOR CUTOUT
53-558-00	53-558-00	53-558-00		DETAILED IN	BODY BELOW AFT CARGO COMPART FLOOR
53-560-00	53-560-00	53-560-00		DETAILED IN	BODY BELOW AFT CARGO FLOOR/STA 1307
53-562-00	53-562-00	53-562-00		DETAILED IN	FRAME UPPER CHORDS AT NUT PLATE
53-564-00	53-564-00	53-564-00		GEN VISUAL	FUSELAGE EXTERIOR SURFACE
53-572-00	53-572-00	53-572-00		GEN VISUAL	BULK CARGO COMPARTMENT
53-574-00	53-574-00	53-574-00		DETAILED IN	BULK CARGO DOOR LOWER SILL
53-576-00	53-576-00	53-576-00		DETAILED IN	AFT ENTRY/SERVICE DOOR CUTOUTS
53-578-00	53-578-00	53-578-00		GEN VISUAL	LOWER LOBE INTERIOR - RIGHT
53-582-00	53-582-00	53-582-00		DETAILED IN	AFT ENTRY/SERVICE DOOR CUTOUTS
53-584-00	53-584-00	53-584-00		DETAILED IN	BULK CARGO COMPARTMENT FLOOR & BELOW
53-586-00	53-586-00	53-586-00		DETAILED IN	LOWER LOBE INTERIOR BODY SKIN
53-588-00	53-588-00	53-588-00		GEN VISUAL	FUSELAGE LOWER LOBE INTERIOR
53-590-00	53-590-00	53-590-00		GEN VISUAL	LOWER LOBE INTERIOR - LEFT
53-592-00	53-592-00	53-592-00		DETAILED IN	BODY BELOW FLOOR-REAR PRESSURE DOME
53-594-00	53-594-00	53-594-00		GEN VISUAL	FUSELAGE EXTERIOR

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-62



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
53-602-00	53-602-00	53-602-00		GEN VISUAL	UPPER WING/SIDE OF BODY SPLICE
53-606-00	53-606-00	53-606-00		DETAILED IN	OVERWING LONGERON
53-608-00	53-608-00	53-608-00		GEN VISUAL	UPPER WING/SIDE OF BODY SPLICE
53-610-00	53-610-00	53-610-00		GEN VISUAL	WING LWR SURFACE BL 62 -FAIRING EDGE
53-612-00	53-612-00	53-612-00		DETAILED IN	OVERWING LONGERON
53-614-00	53-614-00	53-614-00		GEN VISUAL	WING LWR SURF BL 62 - FAIRING EDGE
53-616-00	53-616-00	53-616-00		DETAILED IN	LWR SIDE OF BODY SPLICE PLATES
53-618-00	53-618-00	53-618-00		DETAILED IN	LWR WING SURFACE AT REAR SPAR CHORD
53-620-00	53-620-00	53-620-00		DETAILED IN	WING LWR REAR SPAR SPLICE FITTING
53-622-00	53-622-00	53-622-00		DETAILED IN	BL 70 UNDERWING LONGERON FITTING
53-624-00	53-624-00	53-624-00		GEN VISUAL	WING LWR SURFACE BL 62 -FAIRING EDGE
53-626-00	53-626-00	53-626-00		DETAILED IN	LWR SIDE OF BODY SPLICE PLATES
53-628-00	53-628-00	53-628-00		DETAILED IN	LWR WING SURFACE AT REAR SPAR CHORD
53-630-00	53-630-00	53-630-00		DETAILED IN	WING LWR REAR SPAR SPLICE FITTING
53-632-00	53-632-00	53-632-00		DETAILED IN	BL 70 UNDERWING LONGERON FITTING
53-634-00	53-634-00	53-634-00		GEN VISUAL	WING-TO-BODY FAIRING
53-636-00	53-636-00	53-636-00		GEN VISUAL	SKIN UNDER WING/BODY AFT FAIRING
53-638-00	53-638-00	53-638-00		GEN VISUAL	SKIN UNDER WING/BODY AFT L FAIRING
53-640-00	53-640-00	53-640-00		GEN VISUAL	SKIN UNDER WING/BODY AFT R FAIRING
53-642-00	53-642-00	53-642-00		GEN VISUAL	STRUCTURE FWD LAVS, GALLEYS & DOORS
53-644-00	53-644-00	53-644-00		GEN VISUAL	STRUCTURE CTR & AFT GAL, LAV & DOORS
53-646-00	53-646-00	53-646-00		GEN VISUAL	SEAT TRACKS
53-648-00	53-648-00	53-648-00		GEN VISUAL	BODY EXTERNAL SKIN
53-650-00	53-650-00	53-650-00		DETAILED EX	DOOR STOPS AND CUTOUTS
53-652-00	53-652-00	53-652-00		GEN VISUAL	MAIN DECK DOOR & HATCH INTERIORS
53-654-00	53-654-00	53-654-00		GEN VISUAL	CONTROL CABIN WINDSHIELD STRUCTURE
53-656-00	53-656-00	53-656-00		GEN VISUAL	CONTROL CABIN FLOOR STRUCTURE
53-662-00	53-662-00	53-662-00		GEN VISUAL	FUSELAGE UPPER LOBE INT STRUCTURE
53-664-00	53-664-00	53-664-00		DETAILED IN	FLIGHT DECK SECURITY DOOR
53-666-00	53-666-00	53-666-00		DETAILED IN	FWD ENTRY/SERVICE DOOR LOWER SILL
53-668-00	53-668-00	53-668-00		DETAILED IN	CREW ENTRY DOOR LOWER SILL
53-670-00	53-670-00	53-670-00		GEN VISUAL	CARGO FLOOR STRUCTURE - SHEAR WEB
53-674-00	53-674-00	53-674-00		DETAILED IN	FWD ENTRY/SERVICE DOOR LOWER SILL
53-678-00	53-678-00	53-678-00		GEN VISUAL	UPPER LOBE INTERIOR
53-682-00	53-682-00	53-682-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
53-684-00	53-684-00	53-684-00		DETAILED IN	MID-CABIN ENTRY/SVC DOOR LOWER SILL
53-686-00	53-686-00	53-686-00		DETAILED IN	MAIN DECK CARGO DOOR CUTOUT SILL
53-688-00	53-688-00	53-688-00		GEN VISUAL	MID ENTRY/SERVICE DOOR CUTOUTS
53-690-00	53-690-00	53-690-00		GEN VISUAL	MAIN DECK CARGO DOOR CUTOUT
53-692-00	53-692-00	53-692-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-694-00	53-694-00	53-694-00		DETAILED IN	MID-CABIN ENTRY/SVC DOOR LOWER SILL
53-696-00	53-696-00	53-696-00		GEN VISUAL	MID ENTRY/SERVICE DOOR CUTOUTS
53-698-00	53-698-00	53-698-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-700-00	53-700-00	53-700-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-704-00	53-704-00	53-704-00		GEN VISUAL	FUSELAGE UPPER LOBE INT
53-706-00	53-706-00	53-706-00		GEN VISUAL	PASS CABIN ABOVE CEILING 785-1065
53-710-00	53-710-00	53-710-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-712-00	53-712-00	53-712-00		DETAILED IN	AFT ENTRY/SERVICE DOOR LOWER SILL
53-714-00	53-714-00	53-714-00		GEN VISUAL	FUSELAGE UPPER LOBE INTERIOR
53-716-00	53-716-00	53-716-00		DETAILED IN	AFT ENTRY/SERVICE DOOR LOWER SILL
53-718-00	53-718-00	53-718-00		GEN VISUAL	LARGE AFT CARGO DOOR CUTOUT
53-720-00	53-720-00	53-720-00		IN SURVEILL	FUSELAGE UPPER LOBE INT
53-726-00	53-726-00	53-726-00		DETAILED IN	AFT BODY, STA. 1702 - 1725.5
53-728-00	53-728-00	53-728-00		DETAILED IN	H STABILIZER TRIM ACTUATOR SUPPORT
53-730-00	53-730-00	53-730-00		GEN VISUAL	EXT SECTION 48, LEFT SIDE
53-732-00	53-732-00	53-732-00		DETAILED IN	AFT PRESSURE BULKHEAD - STA 1582
53-734-00	53-734-00	53-734-00		CHECK/INSP	VERTICAL STABILIZER ATTACH BOLT
53-740-00	53-740-00	53-740-00		GEN VISUAL	EXT OF SECTION 48, RIGHT SIDE
53-746-00	53-746-00	53-746-00		DETAILED IN	H STABILIZER PIVOT FITTINGS
53-748-00	53-748-00	53-748-00		DETAILED IN	BODY LONGERONS AT HORIZ STAB CUTOUT
53-750-00	53-750-00	53-750-00		GEN VISUAL	SECTION 48 EXTERIOR - LEFT
53-756-00	53-756-00	53-756-00		GEN VISUAL	SECTION 48 EXTERIOR - RIGHT
53-758-00	53-758-00	53-758-00		GEN VISUAL	APU COMPARTMENT EXTERNAL SURFACE
53-762-00	53-762-00	53-762-00		GEN VISUAL	SECTION 48 EXTERIOR
53-778-12	53-778-12	53-778-12		DETAILED IN	BODY STA 1809.5 BHD OUTBD CHORD
53-778-14	53-778-14	53-778-14		SPCL DETAIL	BODY STA 1809.5 BHD OUTBD CHORD
53-778-16	53-778-16	53-778-16		SPCL DETAIL	HORIZONTAL STABILIZER PIVOT FITTINGS
53-778-18	53-778-18	53-778-18		SPCL DETAIL	HORIZONTAL STABILIZER PIVOT PINS
53-778-20	53-778-20	53-778-20		DETAILED EX	BODY STA 1809.5 BHD OUTBD CHORD
53-780-00	53-780-00	53-780-00		SPCL DETAIL	BODY STA 1809.5 BHD OUTBD CHORD

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
53-780-02	53-780-02	53-780-02		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-780-04	53-780-04	53-780-04		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-780-06	53-780-06	53-780-06		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-780-08	53-780-08	53-780-08		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-780-10	53-780-10	53-780-10		SPCL DETAIL	H STABILIZ TRIM ACTUATOR
53-780-12	53-780-12	53-780-12		SPCL DETAIL	EMERGENCY EXIT DOOR CUTOUT
53-780-14	53-780-14	53-780-14		SPCL DETAIL	EMERGENCY EXIT DOOR CUTOUT
53-780-16	53-780-16	53-780-16		SPCL DETAIL	AFT ENTRY/SERVICE DOOR CUTOUT
53-780-18	53-780-18	53-780-18		SPCL DETAIL	AFT ENTRY/SERVICE DOOR CUTOUT
53-780-20	53-780-20	53-780-20		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-00	53-782-00	53-782-00		DETAILED IN	OVERWING EMERGENCY EXIT CUTOUT
53-782-02	53-782-02	53-782-02		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-04	53-782-04	53-782-04		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-06	53-782-06	53-782-06		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-08	53-782-08	53-782-08		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-10	53-782-10	53-782-10		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-12	53-782-12	53-782-12		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-14	53-782-14	53-782-14		DETAILED IN	OVERWING EMERGENCY EXIT CUTOUT
53-782-16	53-782-16	53-782-16		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-782-18	53-782-18	53-782-18		SPCL DETAIL	OVERWING EMERGENCY EXIT CUTOUT
53-782-20	53-782-20	53-782-20		SPCL DETAIL	OVERWING EMERGENCY EXIT
53-784-00	53-784-00	53-784-00		SPCL DETAIL	OVERWING EMERGENCY EXIT CUTOUT
53-784-02	53-784-02	53-784-02		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-04	53-784-04	53-784-04		DETAILED IN	DUAL OVERWING EMERGENCY EXIT
53-784-06	53-784-06	53-784-06		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-08	53-784-08	53-784-08		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-10	53-784-10	53-784-10		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-12	53-784-12	53-784-12		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-14	53-784-14	53-784-14		SPCL DETAIL	DUAL OVERWING EMERGENCY EXIT
53-784-16	53-784-16	53-784-16		SPCL DETAIL	PASS CABIN BODY STA 955.1 BLKHD
53-784-18	53-784-18	53-784-18		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-784-20	53-784-20	53-784-20		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-786-00	53-786-00	53-786-00		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-786-02	53-786-02	53-786-02		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-786-04	53-786-04	53-786-04		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
53-786-06	53-786-06	53-786-06		SPCL DETAIL	MAIN DECK CARGO DOOR CUTOUT
53-786-08	53-786-08	53-786-08		GEN VISUAL	CROWN SKIN STRINGERS
53-786-10	53-786-10	53-786-10		SPCL DETAIL	MID-CABIN ENTRY/SERVICE DOOR CUTOUT
53-786-12	53-786-12	53-786-12		SPCL DETAIL	MID-CABIN ENTRY/SERVICE DOOR CUTOUT
53-786-14	53-786-14	53-786-14		SPCL DETAIL	MID-CABIN ENTRY/SERVICE DOOR CUTOUT
53-786-16	53-786-16	53-786-16		GEN VISUAL	FRAMES
53-786-18	53-786-18	53-786-18		SPCL DETAIL	CROWN SKIN CIRC SPLICES
53-786-20	53-786-20	53-786-20		SPCL DETAIL	CROWN SKIN CIRC SPLICES
53-788-00	53-788-00	53-788-00		SPCL DETAIL	FWD ENTRY/SERVICE DOOR CUTOUT
53-788-02	53-788-02	53-788-02		SPCL DETAIL	SKIN LONGITUDINAL LAP SPLICES
53-788-04	53-788-04	53-788-04		GEN VISUAL	FRAMES, LONGITUDINAL SKIN LAP SPLICE
53-788-06	53-788-06	53-788-06		SPCL DETAIL	SKIN LONGITUDINAL LAP SPLICES
53-788-08	53-788-08	53-788-08		DETAILED IN	CABIN WINDOW NO. 1 SILL
53-788-10	53-788-10	53-788-10		SPCL DETAIL	CABIN WINDOW NO. 2 POST
53-788-12	53-788-12	53-788-12		SPCL DETAIL	CABIN WINDOW NO. 1 POST
53-788-14	53-788-14	53-788-14		SPCL DETAIL	AFT PRESSURE DOME BS 1582
53-788-16	53-788-16	53-788-16		SPCL DETAIL	BULK CARGO DOOR CUTOUT
53-788-18	53-788-18	53-788-18		SPCL DETAIL	BULK CARGO DOOR CUTOUT
53-788-20	53-788-20	53-788-20		SPCL DETAIL	BULK CARGO DOOR CUTOUT
53-790-00	53-790-00	53-790-00		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-02	53-790-02	53-790-02		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-04	53-790-04	53-790-04		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-06	53-790-06	53-790-06		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-08	53-790-08	53-790-08		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-10	53-790-10	53-790-10		SPCL DETAIL	AFT CARGO DOOR CUTOUT STRUCTURE
53-790-12	53-790-12	53-790-12		SPCL DETAIL	AFT CARGO DOOR CUTOUT LWR MAIN SILL
53-790-14	53-790-14	53-790-14		SPCL DETAIL	AFT CARGO DOOR CUTOUT UPR MAIN SILL
53-790-16	53-790-16	53-790-16		DETAILED IN	AFT CARGO DOOR CUTOUT
53-790-18	53-790-18	53-790-18		SPCL DETAIL	AFT CARGO DOOR CUTOUT
53-790-20	53-790-20	53-790-20		SPCL DETAIL	EMERGENCY EXIT DOOR CUTOUT
53-792-00	53-792-00	53-792-00		SPCL DETAIL	EMERGENCY EXIT DOOR CUTOUT
53-792-02	53-792-02	53-792-02		SPCL DETAIL	BODY STA 1065 BULKHEAD
53-792-04	53-792-04	53-792-04		SPCL DETAIL	BODY STA 1065 BULKHEAD
53-792-06	53-792-06	53-792-06		SPCL DETAIL	BODY STA 1065 BULKHEAD
53-792-08	53-792-08	53-792-08		SPCL DETAIL	TRANSVERSE BEAM AT MAIN WHEEL WELL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-66



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
53-792-10	53-792-10	53-792-10		SPCL DETAIL	STA 1043 SPLICE AT LNG GEAR FITTING
53-792-12	53-792-12	53-792-12		SPCL DETAIL	BODY STA 808-933 FRAME AT STUB BEAM
53-792-14	53-792-14	53-792-14		SPCL DETAIL	BODY STA 955.1 BULKHEAD INNER FLANGE
53-792-16	53-792-16	53-792-16		SPCL DETAIL	BODY STA 808-933 FRAME AT STUB BEAM
53-792-18	53-792-18	53-792-18		SPCL DETAIL	LARGE FWD CARGO DOOR LATCH
53-792-20	53-792-20	53-792-20		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-00	53-794-00	53-794-00		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-02	53-794-02	53-794-02		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-04	53-794-04	53-794-04		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-06	53-794-06	53-794-06		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-08	53-794-08	53-794-08		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-10	53-794-10	53-794-10		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-12	53-794-12	53-794-12		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-14	53-794-14	53-794-14		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-16	53-794-16	53-794-16		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-18	53-794-18	53-794-18		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-794-20	53-794-20	53-794-20		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-796-00	53-796-00	53-796-00		SPCL DETAIL	LARGE FWD CARGO DOOR CUTOUT
53-796-02	53-796-02	53-796-02		SPCL DETAIL	FWD CARGO DOOR CUTOUT
53-796-04	53-796-04	53-796-04		SPCL DETAIL	FWD CARGO DOOR CUTOUT
53-796-06	53-796-06	53-796-06		DETAILED IN	FWD CARGO DOOR CUTOUT
53-796-08	53-796-08	53-796-08		SPCL DETAIL	FWD CARGO DOOR CUTOUT
53-796-10	53-796-10	53-796-10		SPCL DETAIL	BODY STA 287 BULKHEAD
53-796-12	53-796-12	53-796-12		GEN VISUAL	MAIN EQUIPMENT CENTER DOOR CUTOUT
53-796-14	53-796-14	53-796-14		SPCL DETAIL	BODY STA 287 BULKHEAD
53-796-16	53-796-16	53-796-16		SPCL DETAIL	FWD ENTRY/SERVICE DOOR CUTOUT
53-796-18	53-796-18	53-796-18		SPCL DETAIL	BODY STA 287 BULKHEAD
53-796-20	53-796-20	53-796-20		SPCL DETAIL	BODY STA 287 BULKHEAD
53-798-00	53-798-00	53-798-00		SPCL DETAIL	BODY STA 287 BULKHEAD
53-798-02	53-798-02	53-798-02		SPCL DETAIL	BODY STA 287 BULKHEAD
53-798-04	53-798-04	53-798-04		SPCL DETAIL	NOSE WHEEL WELL SIDE PANEL BEAM
53-798-06	53-798-06	53-798-06		SPCL DETAIL	NOSE WHEEL WELL SIDE PANEL BEAM
53-798-08	53-798-08	53-798-08		DETAILED IN	NOSE WHEEL WELL SIDE PANEL VER BEAMS
53-798-10	53-798-10	53-798-10		SPCL DETAIL	FORWARD EQUIPMENT BAY DOOR CUTOUT
53-798-12	53-798-12	53-798-12		SPCL DETAIL	NOSE WHEEL WELL CANTED BULKHEAD

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
53-798-14	53-798-14	53-798-14		SPCL DETAIL	NOSE WHEEL WELL CANTED BULKHEAD
53-798-16	53-798-16	53-798-16		SPCL DETAIL	SKIN LONGITUDINAL LAP SPLICES
53-798-18	53-798-18	53-798-18		GEN VISUAL	FRAMES, LONGTDNAL SKIN LAP SPLICES
53-798-20	53-798-20	53-798-20		SPCL DETAIL	SKIN LONGITUDINAL LAP SPLICES
54-002-01-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-01-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-002-02-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-02-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-002-03-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-03-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-002-04-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-04-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-002-05-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-05-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-002-06-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-06-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-002-07-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-07-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-002-08-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-08-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-002-09-1	54-51-00-2D			FUNCTIONAL	ENGINE 1 STRUT DRAIN LEAK TEST
54-002-09-2	54-51-00-2D			FUNCTIONAL	ENGINE 2 STRUT DRAIN LEAK TEST
54-400-00	54-400-00	54-400-00		GEN VISUAL	POWERPLANT STRUT -#1 (GE)
54-402-00	54-402-00	54-402-00		GEN VISUAL	POWERPLANT STRUT - #1 (P&W)
54-404-00	54-404-00	54-404-00		GEN VISUAL	POWER PLANT STRUT - #1
54-406-00	54-406-00	54-406-00		GEN VISUAL	NACELLE STRUT NO. 1
54-408-00	54-408-00	54-408-00		GEN VISUAL	NO. 1 NACELLE STRUT
54-410-00	54-410-00	54-410-00		DETAILED EX	NACELLE STRUT NO. 1
54-412-00	54-412-00	54-412-00		DETAILED IN	STRUT 1 LOWER SPAR AND ENGINE MOUNTS
54-414-00	54-414-00	54-414-00		DETAILED IN	STRUT 1
54-416-00	54-416-00	54-416-00		GEN VISUAL	STRUT 1
54-418-00	54-418-00	54-418-00		GEN VISUAL	POWERPLANT STRUT - #1 (RR CONFIGURA
54-422-00	54-422-00	54-422-00		GEN VISUAL	STRUT 1
54-424-00	54-424-00	54-424-00		DETAILED IN	NACELLE STRUT NO. 1 FWD UPPER SPAR
54-426-00	54-426-00	54-426-00		GEN VISUAL	NACELLE STRUT NO. 1 - FWD TORQUE BOX

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-68



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
54-428-00	54-428-00	54-428-00		DETAILED IN	NACELLE STRUT NO. 1 - FWD TORQUE BOX
54-430-00	54-430-00	54-430-00		GEN VISUAL	STRUT 1 UPPER SPAR
54-432-00	54-432-00	54-432-00		DETAILED IN	STRUT 1 UPPER LINK
54-434-00	54-434-00	54-434-00		DETAILED IN	STRUT 1 UPPER LINK
54-436-00	54-436-00	54-436-00		DETAILED IN	NACELLE STRUT NO. 1 MID-SPAR FITTING
54-438-00	54-438-00	54-438-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
54-440-00	54-440-00	54-440-00		DETAILED IN	NACELLE STRUT NO. 1 MID-SPAR FITTING
54-442-00	54-442-00	54-442-00		DETAILED IN	STRUT 1 TORQUE BOX
54-444-00	54-444-00	54-444-00		GEN VISUAL	STRUT 1 AFT TORQUE BOX
54-446-00	54-446-00	54-446-00		GEN VISUAL	NACELLE STRUT 1-MID & AFT TORQUE BOX
54-448-00	54-448-00	54-448-00		DETAILED IN	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-450-00	54-450-00	54-450-00		DETAILED IN	STRUT 1 AFT TORQUE BOX
54-452-00	54-452-00	54-452-00		DETAILED IN	STRUT 1 AFT TORQUE BOX
54-458-00	54-458-00	54-458-00		DETAILED IN	NACELLE STRUT NO. 1 MID SPAR FITTING
54-460-00	54-460-00	54-460-00		DETAILED IN	NACELLE STRUT NO. 1 MID SPAR FITTING
54-462-00	54-462-00	54-462-00		DETAILED IN	LEFT NACELLE STRUT MID SPAR FITTING
54-464-00	54-464-00	54-464-00		DETAILED IN	LEFT NACELLE STRUT MID SPAR FITTING
54-466-00	54-466-00	54-466-00		GEN VISUAL	LEFT NACELLE STRUT/WING LWR SURFACE
54-468-00	54-468-00	54-468-00		DETAILED IN	LEFT NACELLE STRUT/WING LWR SURFACE
54-470-00	54-470-00	54-470-00		GEN VISUAL	POWERPLANT STRUT - #2 (GE CONFIGURAT
54-472-00	54-472-00	54-472-00		GEN VISUAL	POWERPLANT STRUT - #2
54-474-00	54-474-00	54-474-00		GEN VISUAL	POWERPLANT STRUT - #2
54-476-00	54-476-00	54-476-00		GEN VISUAL	NACELLE STRUT NO. 2
54-478-00	54-478-00	54-478-00		GEN VISUAL	NACELLE STRUT NO. 2
54-480-00	54-480-00	54-480-00		DETAILED EX	NACELLE STRUT NO. 2
54-482-00	54-482-00	54-482-00		DETAILED IN	STRUT 2 LOWER SPAR AND ENGINE MOUNTS
54-484-00	54-484-00	54-484-00		DETAILED IN	STRUT 2
54-486-00	54-486-00	54-486-00		GEN VISUAL	STRUT 2
54-488-00	54-488-00	54-488-00		GEN VISUAL	POWERPLANT STRUT - #2
54-492-00	54-492-00	54-492-00		GEN VISUAL	STRUT 2 SKIN
54-494-00	54-494-00	54-494-00		DETAILED IN	NACELLE STRUT NO. 2 FWD UPPER SPAR
54-496-00	54-496-00	54-496-00		GEN VISUAL	NACELLE STRUT NO. 2 -FWD TORQUE BOX
54-498-00	54-498-00	54-498-00		DETAILED IN	NACELLE STRUT NO. 2 FWD TORQUE BOX
54-500-00	54-500-00	54-500-00		GEN VISUAL	STRUT 2 UPPER SPAR
54-502-00	54-502-00	54-502-00		DETAILED IN	NACELLE STRUT NO. 2 -FWD TORQUE BOX

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
54-504-00	54-504-00	54-504-00		DETAILED IN	STRUT 2 UPPER LINK
54-506-00	54-506-00	54-506-00		DETAILED IN	NACELLE STRUT NO. 2 MID-SPAR FITTING
54-508-00	54-508-00	54-508-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
54-510-00	54-510-00	54-510-00		DETAILED IN	NACELLE STRUT NO. 2 MID-SPAR FITTING
54-512-00	54-512-00	54-512-00		DETAILED IN	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-514-00	54-514-00	54-514-00		GEN VISUAL	NACELLE STRUT NO. 2 MID SPAR FITTING
54-520-00	54-520-00	54-520-00		DETAILED IN	STRUT 2 AFT TORQUE BOX
54-522-00	54-522-00	54-522-00		DETAILED IN	STRUT 2 AFT TORQUE BOX
54-524-00	54-524-00	54-524-00		GEN VISUAL	NACELLE STRUT MID & AFT TORQUE BOX
54-526-00	54-526-00	54-526-00		DETAILED IN	NO. 2 STRUT AFT ENG MOUNT BULKHEAD
54-528-00	54-528-00	54-528-00		DETAILED IN	NACELLE STRUT NO.2 -MID SPAR FITTING
54-530-00	54-530-00	54-530-00		DETAILED IN	NACELLE STRUT NO. 2 MID SPAR FITTING
54-532-00	54-532-00	54-532-00		DETAILED IN	RIGHT NACELLE STRUT MID SPAR FITTING
54-534-00	54-534-00	54-534-00		DETAILED IN	RIGHT NACELLE STRUT MID SPAR FITTING
54-536-00	54-536-00	54-536-00		GEN VISUAL	RIGHT NACELLE STRUT/WING LWR SURFACE
54-538-00	54-538-00	54-538-00		DETAILED IN	RIGHT NACELLE STRUT/WING LWR SURFACE
54-578-04	54-578-04	54-578-04		SPCL DETAIL	STRUT NO. 2 SIDE LOAD FITTINGS
54-578-06	54-578-06	54-578-06		DETAILED IN	STRUT NO 2 SIDE LOAD LINKS
54-578-08	54-578-08	54-578-08		DETAILED IN	STRUT NO 2 SIDE LOAD LINKS
54-578-10	54-578-10	54-578-10		DETAILED IN	STRUT NO 2 SIDE LOAD LINKS
54-578-12	54-578-12	54-578-12		DETAILED IN	STRUT NO 2 SIDE LOAD LINKS
54-578-14	54-578-14	54-578-14		DETAILED IN	STRUT NO 2 MIDSPAR FITTING
54-578-16	54-578-16	54-578-16		DETAILED IN	STRUT NO 2 MIDSPAR FITTING
54-578-18	54-578-18	54-578-18		DETAILED IN	STRUT NO 2 MIDSPAR FITTING
54-578-20	54-578-20	54-578-20		DETAILED IN	STRUT NO 2 MIDSPAR FITTING
54-580-00	54-580-00	54-580-00		DETAILED IN	STRUT NO 2 DIAGONAL BRACE FITTING
54-580-02	54-580-02	54-580-02		DETAILED IN	STRUT NO 2 DIAGONAL BRACE FITTING
54-580-04	54-580-04	54-580-04		DETAILED IN	STRUT NO 2 DIAGONAL BRACE FITTING
54-580-06	54-580-06	54-580-06		DETAILED IN	STRUT NO. 2 DIAGONAL BRACE FITTING
54-580-08	54-580-08	54-580-08		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-580-10	54-580-10	54-580-10		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-580-12	54-580-12	54-580-12		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-580-14	54-580-14	54-580-14		SPCL DETAIL	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-580-16	54-580-16	54-580-16		SPCL DETAIL	NACELLE STRUT NO. 2 SIDE SKIN
54-580-18	54-580-18	54-580-18		SPCL DETAIL	NACELLE STRUT NO. 2 AFT UPPER SPAR

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-70



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
54-580-20	54-580-20	54-580-20		SPCL DETAIL	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-582-00	54-582-00	54-582-00		SPCL DETAIL	NACELLE STRUT NO. 2 AFT UPPER SPAR
54-582-02	54-582-02	54-582-02		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR CHORD
54-582-04	54-582-04	54-582-04		DETAILED IN	STRUT NO 2 AFT UPPER SPAR FITTING
54-582-06	54-582-06	54-582-06		DETAILED IN	STRUT NO. 2 LOWER SPAR CHORD
54-582-08	54-582-08	54-582-08		DETAILED IN	STRUT NO 2 DIAGONAL BRACE FITTING
54-582-10	54-582-10	54-582-10		SPCL DETAIL	NACELLE STRUT NO. 2 LOWER SPAR
54-582-12	54-582-12	54-582-12		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR CHORD
54-582-14	54-582-14	54-582-14		DETAILED IN	STRUT NO. 2 LOWER SPAR CHORD
54-582-16	54-582-16	54-582-16		DETAILED IN	STRUT NO 2 SIDE LINK FITTING
54-582-18	54-582-18	54-582-18		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR CHORD
54-582-20	54-582-20	54-582-20		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR FITTING
54-584-00	54-584-00	54-584-00		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-584-02	54-584-02	54-584-02		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-584-04	54-584-04	54-584-04		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-584-06	54-584-06	54-584-06		SPCL DETAIL	STRUT NO. 2 AFT ENG MOUNT BULKHEAD
54-584-08	54-584-08	54-584-08		SPCL DETAIL	NACELLE STRUT NO. 2 FWD ENGINE MOUNT
54-584-10	54-584-10	54-584-10		DETAILED IN	NACELLE STRUT NO. 2 SIDESKIN
54-584-12	54-584-12	54-584-12		GEN VISUAL	STRUT NO. 2 MID BULKHEAD LINK FTG
54-584-14	54-584-14	54-584-14		DETAILED IN	STRUT NO. 2 MID BULKHEAD LINK FTG
54-584-16	54-584-16	54-584-16		DETAILED IN	STRUT NO. 2 FORWARD UPPER SPAR
54-584-18	54-584-18	54-584-18		SPCL DETAIL	NACELLE STRUT NO. 2 FWD UPPER SPAR
54-584-20	54-584-20	54-584-20		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-586-00	54-586-00	54-586-00		DETAILED IN	NACELLE STRUT NO. 2 FWD MIDSPAR
54-586-02	54-586-02	54-586-02		SPCL DETAIL	NACELLE STRUT NO. 2 FWD MIDSPAR
54-586-04	54-586-04	54-586-04		SPCL DETAIL	NACELLE STRUT NO. 2 MIDSPAR CHORD
54-586-06	54-586-06	54-586-06		SPCL DETAIL	NACELLE STRUT NO. 2 MID SPAR CHORD
54-586-08	54-586-08	54-586-08		SPCL DETAIL	NACELLE STRUT NO. 2 MID SPAR CHORD
54-586-10	54-586-10	54-586-10		SPCL DETAIL	NACELLE STRUT NO. 2 MID SPAR CHORD
54-586-12	54-586-12	54-586-12		SPCL DETAIL	NACELLE STRUT NO. 2 MID SPAR CHORD
54-586-14	54-586-14	54-586-14		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-586-16	54-586-16	54-586-16		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-586-18	54-586-18	54-586-18		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-586-20	54-586-20	54-586-20		SPCL DETAIL	ENG 2 FWD MOUNT BULKHEAD FITTINGS
54-588-00	54-588-00	54-588-00		DETAILED IN	STRUT NO. 2 T0 WING ATTACHMENTS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
54-588-02	54-588-02	54-588-02		SPCL DETAIL	NACELLE STRUT NO. 2 LOWER SPAR CHORD
54-588-04	54-588-04	54-588-04		SPCL DETAIL	STRUT NO. 1 SIDE LOAD FITTINGS
54-588-06	54-588-06	54-588-06		DETAILED IN	STRUT NO 1 SIDE LOAD LINKS
54-588-08	54-588-08	54-588-08		DETAILED IN	STRUT NO 1 SIDE LOAD LINKS
54-588-10	54-588-10	54-588-10		DETAILED IN	STRUT NO 1 SIDE LOAD LINKS
54-588-12	54-588-12	54-588-12		DETAILED IN	STRUT NO 1 SIDE LOAD LINKS
54-588-14	54-588-14	54-588-14		DETAILED IN	STRUT NO 1 MIDSPAR FITTING
54-588-16	54-588-16	54-588-16		DETAILED IN	STRUT NO 1 MIDSPAR FITTING
54-588-18	54-588-18	54-588-18		DETAILED IN	STRUT NO 1 MIDSPAR FITTING
54-588-20	54-588-20	54-588-20		DETAILED IN	STRUT NO 1 MIDSPAR FITTING
54-590-00	54-590-00	54-590-00		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-590-02	54-590-02	54-590-02		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-590-04	54-590-04	54-590-04		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-590-06	54-590-06	54-590-06		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-590-08	54-590-08	54-590-08		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-590-10	54-590-10	54-590-10		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-590-12	54-590-12	54-590-12		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-590-14	54-590-14	54-590-14		SPCL DETAIL	NACELLE STRUT NO. 1 AFT UPPER SPAR
54-590-16	54-590-16	54-590-16		SPCL DETAIL	NACELLE STRUT NO. 1 SIDE SKIN
54-590-18	54-590-18	54-590-18		SPCL DETAIL	NACELLE STRUT NO. 1 AFT UPPER SPAR
54-590-20	54-590-20	54-590-20		SPCL DETAIL	NACELLE STRUT NO. 1 AFT UPPER SPAR
54-592-00	54-592-00	54-592-00		SPCL DETAIL	NACELLE STRUT NO. 1 AFT UPPER SPAR
54-592-02	54-592-02	54-592-02		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR CHORD
54-592-04	54-592-04	54-592-04		DETAILED IN	STRUT NO 1 AFT UPPER SPAR FITTING
54-592-06	54-592-06	54-592-06		DETAILED IN	STRUT NO. 1 LOWER SPAR CHORD
54-592-08	54-592-08	54-592-08		DETAILED IN	STRUT NO 1 DIAGONAL BRACE FITTING
54-592-10	54-592-10	54-592-10		SPCL DETAIL	NACELLE STRUT NO. 1 LOWER SPAR
54-592-12	54-592-12	54-592-12		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR CHORD
54-592-14	54-592-14	54-592-14		DETAILED IN	STRUT NO. 1 LOWER SPAR CHORD
54-592-16	54-592-16	54-592-16		DETAILED IN	STRUT NO 1 SIDE LINK FITTING
54-592-18	54-592-18	54-592-18		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR CHORD
54-592-20	54-592-20	54-592-20		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR FITTING
54-594-00	54-594-00	54-594-00		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-594-02	54-594-02	54-594-02		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-594-04	54-594-04	54-594-04		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
54-594-06	54-594-06	54-594-06		SPCL DETAIL	STRUT NO. 1 AFT ENG MOUNT BULKHEAD
54-594-08	54-594-08	54-594-08		SPCL DETAIL	NACELLE STRUT NO. 1 FWD ENGINE MOUNT
54-594-10	54-594-10	54-594-10		DETAILED IN	NACELLE STRUT NO. 1 SIDESKIN
54-594-12	54-594-12	54-594-12		GEN VISUAL	STRUT NO. 1 MID BULKHEAD LINK FTG
54-594-14	54-594-14	54-594-14		DETAILED IN	STRUT NO. 1 MID BULKHEAD LINK FTG
54-594-16	54-594-16	54-594-16		DETAILED IN	STRUT NO. 1 FORWARD UPPER SPAR
54-594-18	54-594-18	54-594-18		SPCL DETAIL	NACELLE STRUT NO. 1 FWD UPPER SPAR
54-594-20	54-594-20	54-594-20		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-596-00	54-596-00	54-596-00		DETAILED IN	NACELLE STRUT NO. 1 FWD MIDSPAR
54-596-02	54-596-02	54-596-02		SPCL DETAIL	NACELLE STRUT NO. 1 FWD MIDSPAR
54-596-04	54-596-04	54-596-04		SPCL DETAIL	NACELLE STRUT NO. 1 MIDSPAR CHORD
54-596-06	54-596-06	54-596-06		SPCL DETAIL	NACELLE STRUT NO. 1 MID SPAR CHORD
54-596-08	54-596-08	54-596-08		SPCL DETAIL	NACELLE STRUT NO. 1 MID SPAR CHORD
54-596-10	54-596-10	54-596-10		SPCL DETAIL	NACELLE STRUT NO. 1 MID SPAR CHORD
54-596-12	54-596-12	54-596-12		SPCL DETAIL	NACELLE STRUT NO. 1 MID SPAR CHORD
54-596-14	54-596-14	54-596-14		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-596-16	54-596-16	54-596-16		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-596-18	54-596-18	54-596-18		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-596-20	54-596-20	54-596-20		SPCL DETAIL	ENG 1 FWD MOUNT BULKHEAD FITTINGS
54-598-00	54-598-00	54-598-00		DETAILED IN	STRUT NO. 1 T0 WING ATTACHMENTS
54-598-02	54-598-02	54-598-02		SPCL DETAIL	NACELLE STRUT NO. 1 LOWER SPAR CHORD
54-598-06	54-598-06	54-598-06		SPCL DETAIL	STRUT NO. 2 AFT ENGINE MOUNT
54-598-08	54-598-08	54-598-08		SPCL DETAIL	STRUT NO. 2 AFT ENGINE MOUNT
54-598-10	54-598-10	54-598-10		DETAILED IN	STRUT NO. 2 FORWARD ENGINE MOUNT
54-598-12	54-598-12	54-598-12		SPCL DETAIL	STRUT NO. 2 FORWARD ENGINE MOUNT
54-598-14	54-598-14	54-598-14		SPCL DETAIL	STRUT NO. 1 AFT ENGINE MOUNT
54-598-16	54-598-16	54-598-16		SPCL DETAIL	STRUT NO. 1 AFT ENGINE MOUNT
54-598-18	54-598-18	54-598-18		DETAILED IN	STRUT NO. 1 FORWARD ENGINE MOUNT
54-598-20	54-598-20	54-598-20		SPCL DETAIL	STRUT NO. 1 FORWARD ENGINE MOUNT
55-400-00	55-400-00	55-400-00		GEN VISUAL	VERTICAL STAB REMOVABLE LEADING EDGE
55-401-00	55-401-00	55-401-00		GEN VISUAL	VERTICAL STABILIZER EXTERIOR
55-402-00	55-402-00	55-402-00		GEN VISUAL	VERTICAL STAB REMOVABLE LEADING EDGE
55-404-00	55-404-00	55-404-00		GEN VISUAL	VERT STAB AUX SPAR TO FRONT SPAR
55-406-00	55-406-00	55-406-00		DETAILED	VERT STAB FIXED LEADING EDGE
55-408-00	55-408-00	55-408-00		GEN VISUAL	VERT STAB AUX SPAR TO FRONT SPAR

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
55-410-00	55-410-00	55-410-00		GEN VISUAL	VERT STAB FRONT SPAR TO REAR SPAR
55-412-00	55-412-00	55-412-00		DETAILED IN	VERT STAB FIN-TO-BODY FITTINGS
55-414-00	55-414-00	55-414-00		GEN VISUAL	VERTICAL STABILIZER INSPAR STRUCTURE
55-416-00	55-416-00	55-416-00		GEN VISUAL	VERT STAB FRONT SPAR TO REAR SPAR
55-418-00	55-418-00	55-418-00		DETAILED EX	VERTICAL STABILIZER INSPAR STRUCTURE
55-420-00	55-420-00	55-420-00		GEN VISUAL	VERTICAL STABILIZER TRAILING EDGE
55-422-00	55-422-00	55-422-00		GEN VISUAL	RUDDER
55-424-00	55-424-00	55-424-00		DETAILED EX	RUDDER
55-426-00	55-426-00	55-426-00		DETAILED EX	RUDDER
55-428-00	55-428-00	55-428-00		SPCL DETAIL	RUDDER
55-430-00	55-430-00	55-430-00		GEN VISUAL	VERTICAL STABILIZER TIP
55-432-00	55-432-00	55-432-00		GEN VISUAL	HORIZONTAL STABILIZER EXT - LEFT
55-434-00	55-434-00	55-434-00		GEN VISUAL	HORIZ STABILIZER CENTER SECTION
55-444-00	55-444-00	55-444-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-446-00	55-446-00	55-446-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-448-00	55-448-00	55-448-00		GEN VISUAL	HORIZONTAL STAB FIXED LEADING EDGE
55-450-00	55-450-00	55-450-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE - LWR
55-452-00	55-452-00	55-452-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE-UPPER
55-454-00	55-454-00	55-454-00		GEN VISUAL	HORIZ STAB FRONT TO REAR SPAR L & R
55-456-00	55-456-00	55-456-00		GEN VISUAL	HORIZ STAB OUTBOARD SECTION
55-458-00	55-458-00	55-458-00		GEN VISUAL	HORIZ STAB UPPER OUTBOARD SURFACE
55-460-00	55-460-00	55-460-00		GEN VISUAL	HORIZ STAB LOWER OUTBOARD SURFACE
55-462-00	55-462-00	55-462-00		DETAILED EX	HORIZ/STAB UPPER OUTBOARD SURFACE
55-464-00	55-464-00	55-464-00		GEN VISUAL	HORIZ STAB TRAILING EDGE
55-466-00	55-466-00	55-466-00	W-06-063-01	GEN VISUAL	HORIZ STAB TRAILING EDGE
55-468-00	55-468-00	55-468-00		GEN VISUAL	HORIZ STAB TRAIL EDGE UPPER SURFACE
55-470-00	55-470-00	55-470-00		GEN VISUAL	LEFT ELEVATOR INTERIOR
55-472-00	55-472-00	55-472-00		GEN VISUAL	LEFT ELEVATOR - INBOARD/OUTBOARD
55-474-00	55-474-00	55-474-00		DETAILED EX	ELEVATOR SPAR & HINGE FITTINGS
55-478-00	55-478-00	55-478-00		GEN VISUAL	LEFT ELEVATOR - INBOARD/OUTBOARD
55-480-00	55-480-00	55-480-00		DETAILED EX	ELEVATOR - OUTBOARD
55-484-00	55-484-00	55-484-00		SPCL DETAIL	ELEVATOR SPAR & ADJACENT STRUCTURE
55-486-00	55-486-00	55-486-00		GEN VISUAL	HORIZONTAL STABILIZER TIP
55-488-00	55-488-00	55-488-00		GEN VISUAL	HORIZONTAL STABILIZER EXT - RIGHT
55-490-00	55-490-00	55-490-00		DETAILED IN	HORIZ STABILIZER CENTER SECTION

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
55-492-00	55-492-00	55-492-00		DETAILED EX	HORIZ STAB JACKSCREW FITTING
55-494-00	55-494-00	55-494-00		DETAILED EX	HORIZONTAL STABILIZER PIVOT FITTINGS
55-496-00	55-496-00	55-496-00		DETAILED EX	HORIZ STAB CENTER SECTION REAR SPAR
55-498-00	55-498-00	55-498-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-500-00	55-500-00	55-500-00		GEN VISUAL	HORIZ STAB REMOVABLE LEADING EDGE
55-502-00	55-502-00	55-502-00		GEN VISUAL	HORIZONTAL STAB FIXED LEADING EDGE
55-504-00	55-504-00	55-504-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE-UPPER
55-506-00	55-506-00	55-506-00		GEN VISUAL	HORIZ STAB FIXED LEADING EDGE - LWR
55-508-00	55-508-00	55-508-00		GEN VISUAL	HORIZ STAB CAVITY
55-510-00	55-510-00	55-510-00		GEN VISUAL	HORIZ STAB OUTBOARD SECTION
55-512-00	55-512-00	55-512-00		GEN VISUAL	HORIZ STAB LOWER OUTBOARD SURFACE
55-514-00	55-514-00	55-514-00		GEN VISUAL	HORIZ STAB UPPER OUTBOARD SURFACE
55-516-00	55-516-00	55-516-00		DETAILED EX	HORIZ/STAB UPPER OUTBOARD SURFACE
55-518-00	55-518-00	55-518-00		GEN VISUAL	HORIZ STAB INTERIOR CAVITY
55-520-00	55-520-00	55-520-00	W-06-063-01	GEN VISUAL	HORIZ STAB TRAILING EDGE
55-522-00	55-522-00	55-522-00		GEN VISUAL	HORIZ STAB TRAIL EDGE UPPER SURFACE
55-524-00	55-524-00	55-524-00		GEN VISUAL	RIGHT ELEVATOR INTERIOR
55-526-00	55-526-00	55-526-00		GEN VISUAL	RIGHT ELEVATOR - INBOARD/OUTBOARD
55-528-00	55-528-00	55-528-00		DETAILED EX	RIGHT ELEVATOR SPAR & HINGE FITTINGS
55-532-00	55-532-00	55-532-00		GEN VISUAL	RIGHT ELEVATOR - INBOARD/OUTBOARD
55-538-00	55-538-00	55-538-00		SPCL DETAIL	ELEVATOR SPAR & ADJACENT STRUCTURE
55-540-00	55-540-00	55-540-00		GEN VISUAL	HORIZONTAL STABILIZER TIP
55-550-00	55-550-00	55-550-00		SPCL DETAIL	HORIZONTAL STABILIZER PIVOT FITTINGS
55-552-00	55-552-00	55-552-00		SPCL DETAIL	HORIZ STAB PIVOT FITTING ATTACHMENTS
55-554-00	55-554-00	55-554-00		SPCL DETAIL	HORIZ STAB PIVOT FITTING ATTACHMENTS
55-556-00	55-556-00	55-556-00		SPCL DETAIL	HORIZ STAB PIVOT FITTING ATTACHMENTS
55-558-00	55-558-00	55-558-00		SPCL DETAIL	HORIZ STAB CTR SECTION REAR SPAR
55-560-00	55-560-00	55-560-00		SPCL DETAIL	HORIZ STAB CTR SECTION UPPER SKIN
55-562-00	55-562-00	55-562-00		SPCL DETAIL	HORIZ STAB JACKSCREW ATTACH
55-564-00	55-564-00	55-564-00		SPCL DETAIL	HORIZ STAB JACKSCREW ATTACHMENTS
56-BCY-90-1	25-21-01-A			CHECK/INSP	PASSENGER COMPARTMENT WINDOWS
56-001-01	56-11-04-4A	56-001		OPERATIONAL	NO. 2 OPENING WINDOW HANDLE
57-002-01	57-25-01-A			CHECK/INSP	WING VORTEX GENERATOR
57-003-01	57-53-01-A			CHECK/INSP	OUTBOARD FLAP VORTEX GENERATORS
57-004-01-1	57-00-00-A			REPLACE	L MAIN LDG GEAR SUPPORT STRUCTURE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-004-01-2	57-00-00-A			REPLACE	R MAIN LDG GEAR SUPPORT STRUCTURE
57-004-02-1	57-00-00-A			REPLACE	L MAIN LDG GEAR SUPPORT STRUCTURE
57-004-02-2	57-00-00-A			REPLACE	R MAIN LDG GEAR SUPPORT STRUCTURE.
57-005-01-1	57-00-00-B			REPLACE	L MLG RETRACT ACTUATOR FTG AND PIN
57-005-01-2	57-00-00-B			REPLACE	R MLG RETRACT ACTUATOR FTG AND PIN
57-400-00	57-400-00	57-400-00		GEN VISUAL	WING CENTER SECTION
57-402-00	57-402-00	57-402-00		DETAILED IN	WING CENTER SECTION LWR SURF SPLICE
57-404-00	57-404-00	57-404-00		DETAILED IN	WING CENTER SECTION REAR SPAR CHORD
57-406-00	57-406-00	57-406-00		DETAILED IN	WING CENTER SECT SIDE OF BODY SPLICE
57-408-00	57-408-00	57-408-00		DETAILED IN	WING CENTER SECTION REAR SPAR WEB
57-410-00	57-410-00	57-410-00		DETAILED IN	WING CTR SECT SIDE OF BODY RIB WEB
57-412-00	57-412-00	57-412-00		DETAILED IN	WING CENTER SECTION LOWER SURF BL 70
57-414-00	57-414-00	57-414-00		GEN VISUAL	WING CTR SECT FUEL TANK DRY BAY AREA
57-416-00	57-416-00	57-416-00		DETAILED IN	WING CENTER SECT FUEL TANK WET BAY
57-418-00	57-418-00	57-418-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-420-00	57-420-00	57-420-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-422-00	57-422-00	57-422-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-424-00	57-424-00	57-424-00		DETAILED IN	WING CTR SECTION FUEL TANK WET BAY
57-426-00	57-426-00	57-426-00		DETAILED IN	WING CENTER SECTION LOWER SURF BL 70
57-428-00	57-428-00	57-428-00		GEN VISUAL	WING CENTER SECTION
57-458-00	57-458-00	57-458-00		GEN VISUAL	WING CENTER SECTION LOWER
57-460-00	57-460-00	57-460-00		GEN VISUAL	INBOARD FLAP SUPPORT STRUCTURE
57-464-00	57-464-00	57-464-00		GEN VISUAL	WING EXTERIOR - LEFT
57-466-00	57-466-00	57-466-00		GEN VISUAL	WING EXTERIOR - LEFT
57-468-00	57-468-00	57-468-00		GEN VISUAL	NACELLE STRUT NO. 1 AFT UPPER SPAR
57-470-00	57-470-00	57-470-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
57-472-00	57-472-00	57-472-00		GEN VISUAL	SLAT 6 LINK BRACE & ACTUATOR SUPPORT
57-474-00	57-474-00	57-474-00		GEN VISUAL	LEFT WING FIXED LE STRUCTURES
57-476-00	57-476-00	57-476-00		GEN VISUAL	LEFT WING FIXED LE STRUCTURE
57-478-00	57-478-00	57-478-00		DETAILED IN	NACELLE STRUT NO. 1 UPPER LINK
57-480-00	57-480-00	57-480-00		GEN VISUAL	LE SLATS INTERIOR STRUCTURE
57-482-00	57-482-00	57-482-00		GEN VISUAL	LEFT SLAT/NACELLE SEAL KREUGER FLAP
57-486-00	57-486-00	57-486-00		GEN VISUAL	LEADING EDGE EXTERIOR - LEFT
57-488-00	57-488-00	57-488-00		GEN VISUAL	NO. 4 SLAT MAIN & AUXILIARY TRACKS
57-504-00	57-504-00	57-504-00		GEN VISUAL	LEFT WING INSPAR LWR SURFACE, EXT

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-506-00	57-506-00	57-506-00		GEN VISUAL	LEFT WING INSPAR LWR SURFACE
57-508-00	57-508-00	57-508-00		GEN VISUAL	LEFT WING INSPAR UPPER SURFACE
57-510-00	57-510-00	57-510-00		DETAILED EX	LEFT WING INSPAR UPPER SURFACE
57-512-00	57-512-00	57-512-00		DETAILED EX	LEFT WING INSPAR LWR SURFACE
57-514-00	57-514-00	57-514-00		DETAILED EX	LEFT WING INSPAR UPPER SURFACE
57-516-00	57-516-00	57-516-00		DETAILED IN	L WING LWR SURFACE SPANWISE SPLICE
57-518-00	57-518-00	57-518-00		DETAILED IN	L WING LWR SURF ACCESS HOLE CUTOUTS
57-520-00	57-520-00	57-520-00		DETAILED IN	L WING LWR SURFACE/SIDE OF BOX RIB
57-522-00	57-522-00	57-522-00		DETAILED IN	L WING REAR SPAR WEB & LOWER CHORD
57-524-00	57-524-00	57-524-00		DETAILED IN	L WING REAR SPAR LWR CHORD & RIB 1&3
57-526-00	57-526-00	57-526-00		DETAILED IN	LEFT WING SIDE OF BODY RIB WEB
57-528-00	57-528-00	57-528-00		DETAILED IN	SIDE OF BODY RIB LOWER CHORD CUTOUTS
57-530-00	57-530-00	57-530-00		GEN VISUAL	LEFT WING MAIN TANK
57-532-00	57-532-00	57-532-00		DETAILED IN	LEFT MLG TRUNNION BACKUP STRUCTURE
57-534-00	57-534-00	57-534-00		DETAILED IN	LEFT MLG BEAM BACKUP STRUCTURE
57-536-00	57-536-00	57-536-00		DETAILED IN	L WING NACELLE STRUT SUPPORT BACKUP
57-538-00	57-538-00	57-538-00		DETAILED IN	LEFT WING LWR SPAR CHORDS
57-540-00	57-540-00	57-540-00		DETAILED IN	L WING LWR SPANWISE SPLICE STRINGERS
57-542-00	57-542-00	57-542-00		DETAILED IN	L WING LWR SURF ACCESS HOLE CUTOUTS
57-544-00	57-544-00	57-544-00		DETAILED IN	NACELLE STRUT NO. 1 BACKUP STRUCTURE
57-546-00	57-546-00	57-546-00		DETAILED IN	L WING SPANWISE SPLICE STRINGER L-15
57-548-00	57-548-00	57-548-00		DETAILED IN	L WING FRONT SPAR LWR CHORD, RIB 7&9
57-550-00	57-550-00	57-550-00		GEN VISUAL	LEFT WING INBOARD DRY BAY
57-552-00	57-552-00	57-552-00		DETAILED IN	L TE FLAP SUPPORT BACKUP STRUCTURE
57-554-00	57-554-00	57-554-00		GEN VISUAL	LEFT WING OUTBOARD DRY BAY
57-556-00	57-556-00	57-556-00		GEN VISUAL	LEFT WING OUTBOARD DRY BAY
57-558-00	57-558-00	57-558-00		GEN VISUAL	WING TIP & OUTBD SIDE OF WBL 929 RIB
57-560-00	57-560-00	57-560-00		SPCL DETAIL	WING TIP RIB & OUTBD SIDE OF RIB 36
57-564-00	57-564-00	57-564-00		GEN VISUAL	L WING TE SUPPORT STRUCT & REAR SPAR
57-566-00	57-566-00	57-566-00		DETAILED IN	UPPER WING/SIDE OF BODY SPLICE
57-568-00	57-568-00	57-568-00		GEN VISUAL	LEFT WING TRAILING EDGE
57-570-00	57-570-00	57-570-00		GEN VISUAL	L MAIN GEAR DRAG BRACE & MLG BEAM
57-572-00	57-572-00	57-572-00		GEN VISUAL	LEFT WING TRAILING EDGE
57-576-00	57-576-00	57-576-00		GEN VISUAL	LEFT WING SPOILERS
57-578-00	57-578-00	57-578-00		GEN VISUAL	LEFT WING INBD TE FLAP BOX

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-580-00	57-580-00	57-580-00		GEN VISUAL	LEFT WING INBD TE FLAP BOX
57-582-00	57-582-00	57-582-00		SPCL DETAIL	LEFT INBOARD TE FLAP TORQUE TUBE
57-584-00	57-584-00	57-584-00		SPCL DETAIL	LEFT WING INBOARD TE FLAP BOX
57-586-00	57-586-00	57-586-00		GEN VISUAL	LEFT WING INBOARD TE FLAP
57-588-00	57-588-00	57-588-00		GEN VISUAL	LEFT INBOARD AILERON INTERIOR
57-590-00	57-590-00	57-590-00		GEN VISUAL	LEFT INBOARD AILERON
57-592-00	57-592-00	57-592-00		GEN VISUAL	LEFT INBOARD AILERON
57-594-00	57-594-00	57-594-00		DETAILED EX	LEFT INBOARD AILERON
57-596-00	57-596-00	57-596-00		GEN VISUAL	WING TE SUPPORT STRUCTURE/REAR SPAR
57-598-00	57-598-00	57-598-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP BOX
57-600-00	57-600-00	57-600-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP BOX
57-602-00	57-602-00	57-602-00		SPCL DETAIL	LEFT WING OUTBOARD TE FLAP BOX
57-604-00	57-604-00	57-604-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-606-00	57-606-00	57-606-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-608-00	57-608-00	57-608-00		SPCL DETAIL	LEFT WING OUTBOARD TE FLAP BOX
57-610-00	57-610-00	57-610-00		GEN VISUAL	LEFT OUTBOARD AILERON
57-612-00	57-612-00	57-612-00		DETAILED EX	LEFT OUTBOARD AILERON
57-614-00	57-614-00	57-614-00		DETAILED EX	OUTBD AILERON SPAR, HINGES, ACTUATOR
57-616-00	57-616-00	57-616-00		GEN VISUAL	LEFT WING INBOARD TE FLAP
57-618-00	57-618-00	57-618-00		GEN VISUAL	LEFT WING OUTBOARD TE FLAP
57-620-00	57-620-00	57-620-00		GEN VISUAL	WING EXTERIOR - RIGHT
57-622-00	57-622-00	57-622-00		GEN VISUAL	WING EXTERIOR - RIGHT
57-624-00	57-624-00	57-624-00		GEN VISUAL	NACELLE STRUT NO. 2 AFT UPPER SPAR
57-626-00	57-626-00	57-626-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
57-628-00	57-628-00	57-628-00		GEN VISUAL	SLAT 7 LINK BRACE & ACTUATOR SUPPORT
57-634-00	57-634-00	57-634-00		DETAILED IN	NACELLE STRUT NO. 2 UPPER LINK
57-636-00	57-636-00	57-636-00		GEN VISUAL	RIGHT WING LE SLATS - INTERIOR
57-638-00	57-638-00	57-638-00		GEN VISUAL	RIGHT SLAT/NACELLE SEAL KREUGER FLAP
57-642-00	57-642-00	57-642-00		GEN VISUAL	LEADING EDGE EXTERIOR - RIGHT
57-646-00	57-646-00	57-646-00		GEN VISUAL	NO. 9 SLAT MAIN & AUXILIARY TRACKS
57-648-00	57-648-00	57-648-00		GEN VISUAL	RIGHT WING FIXED LE STRUCTURE
57-650-00	57-650-00	57-650-00		GEN VISUAL	RIGHT WING FIXED LE STRUCTURE
57-662-00	57-662-00	57-662-00		GEN VISUAL	RIGHT WING INSPAR LWR SURFACE, EXT
57-664-00	57-664-00	57-664-00		GEN VISUAL	RIGHT WING INSPAR LWR SURFACE
57-666-00	57-666-00	57-666-00		GEN VISUAL	RIGHT WING INSPAR UPPER SURFACE

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-78



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-668-00	57-668-00	57-668-00		DETAILED EX	RIGHT WING INSPAR UPPER SURFACE
57-670-00	57-670-00	57-670-00		DETAILED EX	RIGHT WING INSPAR LWR SURFACE
57-672-00	57-672-00	57-672-00		DETAILED EX	RIGHT WING INSPAR UPPER SURFACE
57-674-00	57-674-00	57-674-00		DETAILED IN	R WING LWR SURFACE SPANWISE SPLICE
57-676-00	57-676-00	57-676-00		DETAILED IN	R WING LWR SURF ACCESS HOLE CUTOUTS
57-678-00	57-678-00	57-678-00		DETAILED IN	R WING LWR SURFACE/SIDE OF BODY RIB
57-680-00	57-680-00	57-680-00		DETAILED IN	R WING REAR SPAR WEB & LOWER CHORD
57-682-00	57-682-00	57-682-00		DETAILED IN	R WING REAR SPAR LWR CHORD RIB 1&3
57-684-00	57-684-00	57-684-00		DETAILED IN	RIGHT WING SIDE OF BODY RIB WEB
57-686-00	57-686-00	57-686-00		DETAILED IN	SIDE OF BODY RIB LOWER CHORD CUTOUTS
57-688-00	57-688-00	57-688-00		GEN VISUAL	RIGHT WING MAIN TANK
57-690-00	57-690-00	57-690-00		DETAILED IN	RIGHT MLG TRUNNION BACKUP STRUCTURE
57-692-00	57-692-00	57-692-00		DETAILED IN	RIGHT MLG BEAM BACKUP STRUCTURE
57-694-00	57-694-00	57-694-00		DETAILED IN	R WING NACELLE STRUT SUPPORT BACKUP
57-696-00	57-696-00	57-696-00		DETAILED IN	RIGHT WING LWR SPAR CHORDS
57-698-00	57-698-00	57-698-00		DETAILED IN	R WING LWR SPANWISE SPLICE STRINGERS
57-700-00	57-700-00	57-700-00		DETAILED IN	R WING LWR SURF ACCESS HOLE CUTOUTS
57-702-00	57-702-00	57-702-00		DETAILED IN	NACELLE STRUT NO. 2 BACKUP STRUCTURE
57-704-00	57-704-00	57-704-00		DETAILED IN	R WING SPANWISE SPLICE STRINGER L-15
57-706-00	57-706-00	57-706-00		DETAILED IN	R WING FRONT SPAR LWR CHORD, RIB 7&9
57-708-00	57-708-00	57-708-00		GEN VISUAL	RIGHT WING INBOARD DRY BAY
57-710-00	57-710-00	57-710-00		DETAILED IN	R TE FLAP SUPPORT BACKUP STRUCTURE
57-712-00	57-712-00	57-712-00		GEN VISUAL	RIGHT WING OUTBOARD DRY BAY
57-714-00	57-714-00	57-714-00		GEN VISUAL	RIGHT WING OUTBOARD DRY BAY
57-716-00	57-716-00	57-716-00		GEN VISUAL	WING TIP & OUTBD SIDE OF WBL 929 RIB
57-718-00	57-718-00	57-718-00		SPCL DETAIL	WING TIP RIB & OUTBD SIDE OF RIB 36
57-722-00	57-722-00	57-722-00		GEN VISUAL	R WING TE SUPPORT STRUCT & REAR SPAR
57-724-00	57-724-00	57-724-00		DETAILED IN	UPPER WING/SIDE OF BODY SPLICE
57-726-00	57-726-00	57-726-00		GEN VISUAL	RIGHT WING TRAILING EDGE
57-728-00	57-728-00	57-728-00		GEN VISUAL	R MAIN GEAR DRAG BRACE MLG BEAM
57-730-00	57-730-00	57-730-00		GEN VISUAL	RIGHT WING TRAILING EDGE
57-734-00	57-734-00	57-734-00		GEN VISUAL	RIGHT WING SPOILERS
57-736-00	57-736-00	57-736-00		GEN VISUAL	RIGHT WING INBD TE FLAP BOX
57-738-00	57-738-00	57-738-00		GEN VISUAL	RIGHT WING INBD TE FLAP BOX
57-740-00	57-740-00	57-740-00		SPCL DETAIL	RIGHT INBOARD TE FLAP TORQUE TUBE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-742-00	57-742-00	57-742-00		SPCL DETAIL	RIGHT WING INBOARD TE FLAP BOX
57-744-00	57-744-00	57-744-00		GEN VISUAL	RIGHT WING INBOARD TE FLAPS
57-746-00	57-746-00	57-746-00		GEN VISUAL	RIGHT INBOARD AILERON INTERIOR
57-748-00	57-748-00	57-748-00		GEN VISUAL	RIGHT INBOARD AILERON
57-750-00	57-750-00	57-750-00		GEN VISUAL	RIGHT INBOARD AILERON
57-752-00	57-752-00	57-752-00		DETAILED EX	RIGHT INBOARD AILERON
57-754-00	57-754-00	57-754-00		GEN VISUAL	R WING TE SUPPORT STRUC & REAR SPAR
57-756-00	57-756-00	57-756-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP BOX
57-758-00	57-758-00	57-758-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP BOX
57-760-00	57-760-00	57-760-00		SPCL DETAIL	RIGHT WING OUTBOARD TE FLAP BOX
57-762-00	57-762-00	57-762-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
57-764-00	57-764-00	57-764-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
57-766-00	57-766-00	57-766-00		SPCL DETAIL	RIGHT WING OUTBOARD TE FLAP BOX
57-768-00	57-768-00	57-768-00		GEN VISUAL	RIGHT OUTBOARD AILERON
57-770-00	57-770-00	57-770-00		DETAILED EX	RIGHT OUTBOARD AILERON
57-772-00	57-772-00	57-772-00		DETAILED EX	OUTBD AILERON SPAR, HINGES, ACTUATOR
57-774-00	57-774-00	57-774-00		GEN VISUAL	RIGHT WING INBOARD TE FLAP
57-776-00	57-776-00	57-776-00		GEN VISUAL	RIGHT WING OUTBOARD TE FLAP
57-786-10	57-786-10	57-786-10		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-12	57-786-12	57-786-12		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-14	57-786-14	57-786-14		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-16	57-786-16	57-786-16		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-18	57-786-18	57-786-18		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-786-20	57-786-20	57-786-20		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-787-00	57-787-00	57-787-00		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-787-02	57-787-02	57-787-02		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-787-04	57-787-04	57-787-04		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-06	57-787-06	57-787-06		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-08	57-787-08	57-787-08		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-10	57-787-10	57-787-10		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-12	57-787-12	57-787-12		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-14	57-787-14	57-787-14		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-16	57-787-16	57-787-16		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-18	57-787-18	57-787-18		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-787-20	57-787-20	57-787-20		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-788-00	57-788-00	57-788-00		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-02	57-788-02	57-788-02		DETAILED IN	RIGHT WING TRAILING EDGE INBD FLAP
57-788-04	57-788-04	57-788-04		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-788-06	57-788-06	57-788-06		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-08	57-788-08	57-788-08		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-10	57-788-10	57-788-10		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-12	57-788-12	57-788-12		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-14	57-788-14	57-788-14		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-16	57-788-16	57-788-16		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-18	57-788-18	57-788-18		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-788-20	57-788-20	57-788-20		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-789-00	57-789-00	57-789-00		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-789-02	57-789-02	57-789-02		SPCL DETAIL	R WING FWD TRUNNION SIDELOAD STRAP
57-789-04	57-789-04	57-789-04		SPCL DETAIL	R WING FWD TRUNNION SIDELOAD FTG
57-789-06	57-789-06	57-789-06		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-789-08	57-789-08	57-789-08		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-789-10	57-789-10	57-789-10		SPCL DETAIL	R WING REAR SPAR LWR CHORD AND SKIN
57-789-12	57-789-12	57-789-12		SPCL DETAIL	R WING FRONT SPAR LWR CHORD AND SKIN
57-789-14	57-789-14	57-789-14		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-789-16	57-789-16	57-789-16		SPCL DETAIL	R WING FRONT SPAR LWR CHORD AND SKIN
57-789-18	57-789-18	57-789-18		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-789-20	57-789-20	57-789-20		DETAILED IN	RIGHT WING INSPAR LOWER SURFACE
57-789-34	57-789-34	57-789-34		DETAILED IN	RIGHT WING TRAILING EDGE INBD FLAP
57-789-36	57-789-36	57-789-36		SPCL DETAIL	WING TRAILING EDGE INBD FLAP
57-789-38	57-789-38	57-789-38		DETAILED IN	LEFT WING TRAILING EDGE INBD FLAP
57-789-40	57-789-40	57-789-40		DETAILED IN	WING TRAILING EDGE INBD FLAP
57-790-00	57-790-00	57-790-00		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-790-02	57-790-02	57-790-02		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-790-04	57-790-04	57-790-04		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-790-06	57-790-06	57-790-06		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-790-08	57-790-08	57-790-08		SPCL DETAIL	R WING OUTBOARD REAR SPAR
57-790-10	57-790-10	57-790-10		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-790-12	57-790-12	57-790-12		SPCL DETAIL	RIGHT WING REAR SPAR LWR CHORD/SKIN
57-790-14	57-790-14	57-790-14		SPCL DETAIL	R WING REAR SPAR LOWER CHORD/SKIN
57-790-16	57-790-16	57-790-16		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-790-18	57-790-18	57-790-18		SPCL DETAIL	R WING REAR SPAR LWR CHORD AND SKIN
57-790-20	57-790-20	57-790-20		DETAILED EX	RIGHT WING INSPAR LOWER SURFACE
57-790-22	57-790-22	57-790-22		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-790-24	57-790-24	57-790-24		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-790-28	57-790-28	57-790-28		SPCL DETAIL	WING TRAILING EDGE INBD FLAP
57-790-32	57-790-32	57-790-32		SPCL DETAIL	WING TRAILING EDGE INBD FLAP
57-790-34	57-790-34	57-790-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-790-36	57-790-36	57-790-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-790-38	57-790-38	57-790-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-790-40	57-790-40	57-790-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-791-00	57-791-00	57-791-00		SPCL DETAIL	RIGHT WING INSPAR UPPER SURFACE
57-791-02	57-791-02	57-791-02		SPCL DETAIL	R WING FRONT SPAR LWR CHORD AND SKIN
57-791-04	57-791-04	57-791-04		SPCL DETAIL	R WING INBD LOWER SPLICE STRINGER
57-791-06	57-791-06	57-791-06		SPCL DETAIL	R WING FRONT SPAR LWR CHORD AND SKIN
57-791-08	57-791-08	57-791-08		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-791-10	57-791-10	57-791-10		SPCL DETAIL	R WING OUTBOARD LOWER STRINGERS
57-791-12	57-791-12	57-791-12		SPCL DETAIL	RIGHT WING SPAR LOWER CHORD/SKIN
57-791-14	57-791-14	57-791-14		SPCL DETAIL	RIGHT WING INSPAR LOWER SURFACE
57-791-16	57-791-16	57-791-16		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-791-18	57-791-18	57-791-18		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-791-20	57-791-20	57-791-20		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-791-22	57-791-22	57-791-22		DETAILED IN	RIGHT WING TRAILING EDGE INBD FLAP
57-791-24	57-791-24	57-791-24		DETAILED IN	LEFT WING TRAILING EDGE INBD FLAP
57-791-26	57-791-26	57-791-26		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-791-28	57-791-28	57-791-28		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-791-30	57-791-30	57-791-30		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-791-32	57-791-32	57-791-32		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-791-34	57-791-34	57-791-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-791-36	57-791-36	57-791-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-791-38	57-791-38	57-791-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-791-40	57-791-40	57-791-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-00	57-792-00	57-792-00		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-02	57-792-02	57-792-02		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-04	57-792-04	57-792-04		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-06	57-792-06	57-792-06		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-82



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-792-08	57-792-08	57-792-08		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-792-10	57-792-10	57-792-10		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-12	57-792-12	57-792-12		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-14	57-792-14	57-792-14		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-16	57-792-16	57-792-16		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-18	57-792-18	57-792-18		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-20	57-792-20	57-792-20		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-22	57-792-22	57-792-22		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-24	57-792-24	57-792-24		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-26	57-792-26	57-792-26		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-28	57-792-28	57-792-28		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-30	57-792-30	57-792-30		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-32	57-792-32	57-792-32		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-34	57-792-34	57-792-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-36	57-792-36	57-792-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-792-38	57-792-38	57-792-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-792-40	57-792-40	57-792-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-00	57-793-00	57-793-00		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-02	57-793-02	57-793-02		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-04	57-793-04	57-793-04		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-06	57-793-06	57-793-06		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-08	57-793-08	57-793-08		DETAILED IN	LEFT WING TRAILING EDGE INBD FLAP
57-793-10	57-793-10	57-793-10		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-793-12	57-793-12	57-793-12		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-14	57-793-14	57-793-14		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-16	57-793-16	57-793-16		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-18	57-793-18	57-793-18		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-20	57-793-20	57-793-20		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-22	57-793-22	57-793-22		GEN VISUAL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-24	57-793-24	57-793-24		GEN VISUAL	LEFT WING TRAILING EDGE INBD FLAP
57-793-26	57-793-26	57-793-26		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-28	57-793-28	57-793-28		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-30	57-793-30	57-793-30		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-32	57-793-32	57-793-32		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-34	57-793-34	57-793-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-793-36	57-793-36	57-793-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-793-38	57-793-38	57-793-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-793-40	57-793-40	57-793-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-00	57-794-00	57-794-00		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-02	57-794-02	57-794-02		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-04	57-794-04	57-794-04		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-06	57-794-06	57-794-06		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-08	57-794-08	57-794-08		SPCL DETAIL	L WING FWD TRUNNION SIDELOAD STRAP
57-794-10	57-794-10	57-794-10		SPCL DETAIL	L WING FWD TRUNNION SIDELOAD FTG
57-794-12	57-794-12	57-794-12		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-794-14	57-794-14	57-794-14		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-794-16	57-794-16	57-794-16		SPCL DETAIL	L WING REAR SPAR LWR CHORD AND SKIN
57-794-18	57-794-18	57-794-18		SPCL DETAIL	L WING FRONT SPAR LWR CHORD AND SKIN
57-794-20	57-794-20	57-794-20		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-794-22	57-794-22	57-794-22		DETAILED IN	RIGHT WING TRAILING EDGE INBD FLAP
57-794-24	57-794-24	57-794-24		DETAILED IN	LEFT WING TRAILING EDGE INBD FLAP
57-794-26	57-794-26	57-794-26		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-794-28	57-794-28	57-794-28		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-30	57-794-30	57-794-30		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-794-32	57-794-32	57-794-32		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-34	57-794-34	57-794-34		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-794-36	57-794-36	57-794-36		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-794-38	57-794-38	57-794-38		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-794-40	57-794-40	57-794-40		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-795-00	57-795-00	57-795-00		SPCL DETAIL	L WING FRONT SPAR LWR CHORD AND SKIN
57-795-02	57-795-02	57-795-02		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-795-04	57-795-04	57-795-04		DETAILED IN	LEFT WING INSPAR LOWER SURFACE
57-795-06	57-795-06	57-795-06		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-795-08	57-795-08	57-795-08		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-795-10	57-795-10	57-795-10		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-795-12	57-795-12	57-795-12		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-795-14	57-795-14	57-795-14		SPCL DETAIL	L WING OUTBOARD REAR SPAR
57-795-16	57-795-16	57-795-16		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-795-18	57-795-18	57-795-18		SPCL DETAIL	LEFT WING REAR SPAR LOWER CHORD/SKIN
57-795-20	57-795-20	57-795-20		SPCL DETAIL	L WING REAR SPAR LOWER CHORD/SKIN

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-84



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-795-22	57-795-22	57-795-22		SPCL DETAIL	RIGHT WING TRAILING EDGE INBD FLAP
57-795-24	57-795-24	57-795-24		SPCL DETAIL	LEFT WING TRAILING EDGE INBD FLAP
57-795-26	57-795-26	57-795-26		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-795-28	57-795-28	57-795-28		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-795-30	57-795-30	57-795-30		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-795-32	57-795-32	57-795-32		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-795-34	57-795-34	57-795-34		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-795-36	57-795-36	57-795-36		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-795-38	57-795-38	57-795-38		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-795-40	57-795-40	57-795-40		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-00	57-796-00	57-796-00		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-796-02	57-796-02	57-796-02		SPCL DETAIL	L WING REAR SPAR LWR CHORD AND SKIN
57-796-04	57-796-04	57-796-04		DETAILED EX	LEFT WING INSPAR LOWER SURFACE
57-796-06	57-796-06	57-796-06		SPCL DETAIL	LEFT WING INSPAR UPPER SURFACE
57-796-08	57-796-08	57-796-08		SPCL DETAIL	L WING FRONT SPAR LWR CHORD AND SKIN
57-796-10	57-796-10	57-796-10		SPCL DETAIL	L WING INBD LOWER SPLICE STRINGER
57-796-12	57-796-12	57-796-12		SPCL DETAIL	L WING FRONT SPAR LWR CHORD AND SKIN
57-796-14	57-796-14	57-796-14		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-796-16	57-796-16	57-796-16		SPCL DETAIL	L WING OUTBOARD LOWER STRINGERS
57-796-18	57-796-18	57-796-18		SPCL DETAIL	LEFT WING SPAR LOWER CHORD/SKIN
57-796-20	57-796-20	57-796-20		SPCL DETAIL	LEFT WING INSPAR LOWER SURFACE
57-796-22	57-796-22	57-796-22		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-24	57-796-24	57-796-24		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-26	57-796-26	57-796-26		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-28	57-796-28	57-796-28		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-30	57-796-30	57-796-30		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-32	57-796-32	57-796-32		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-34	57-796-34	57-796-34		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-36	57-796-36	57-796-36		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-796-38	57-796-38	57-796-38		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-796-40	57-796-40	57-796-40		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-00	57-797-00	57-797-00		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-02	57-797-02	57-797-02		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-04	57-797-04	57-797-04		DETAILED IN	INBOARD FLAP SUPPORT STRUCTURE
57-797-06	57-797-06	57-797-06		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-797-08	57-797-08	57-797-08		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-10	57-797-10	57-797-10		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-12	57-797-12	57-797-12		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-14	57-797-14	57-797-14		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-16	57-797-16	57-797-16		SPCL DETAIL	INBOARD FLAP SUPPORT STRUCTURE
57-797-18	57-797-18	57-797-18		SPCL DETAIL	WING CTR SECTION LWR SURFACE
57-797-20	57-797-20	57-797-20		SPCL DETAIL	WING CTR SECT REAR SPAR LWR CHORD
57-797-22	57-797-22	57-797-22		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-24	57-797-24	57-797-24		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-26	57-797-26	57-797-26		DETAILED IN	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-28	57-797-28	57-797-28		DETAILED IN	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-30	57-797-30	57-797-30		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-32	57-797-32	57-797-32		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-34	57-797-34	57-797-34		DETAILED IN	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-36	57-797-36	57-797-36		DETAILED IN	LEFT WING TRAILING EDGE OUTBD FLAP
57-797-38	57-797-38	57-797-38		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-797-40	57-797-40	57-797-40		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-00	57-798-00	57-798-00		SPCL DETAIL	W CTR REAR SPAR CHORD AND SKIN
57-798-02	57-798-02	57-798-02		DETAILED IN	W CTR FRONT SPAR CHORD AND SKIN
57-798-04	57-798-04	57-798-04		DETAILED IN	W CTR TYPICAL STRINGER AND SKIN
57-798-06	57-798-06	57-798-06		DETAILED EX	WING CENTER SECTION LOWER SURFACE
57-798-08	57-798-08	57-798-08		SPCL DETAIL	WING CTR SECTION FUEL TANK WET BAY
57-798-10	57-798-10	57-798-10		SPCL DETAIL	WING CENTER SECTION FUEL TANK
57-798-12	57-798-12	57-798-12		SPCL DETAIL	WING CTR SECTION FUEL TANK WET BAY
57-798-14	57-798-14	57-798-14		SPCL DETAIL	WING CENTER SECTION FUEL TANK
57-798-16	57-798-16	57-798-16		SPCL DETAIL	WING CTR SECTION FUEL TANK WET BAY
57-798-18	57-798-18	57-798-18		SPCL DETAIL	WING CTR SECTION FUEL TANK WET BAY
57-798-20	57-798-20	57-798-20		DETAILED IN	W CTR SPLICE STRINGER/SKIN
57-798-22	57-798-22	57-798-22		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-24	57-798-24	57-798-24		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-26	57-798-26	57-798-26		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-28	57-798-28	57-798-28		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-30	57-798-30	57-798-30		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-32	57-798-32	57-798-32		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-34	57-798-34	57-798-34		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
57-798-36	57-798-36	57-798-36		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
57-798-38	57-798-38	57-798-38		SPCL DETAIL	RIGHT WING TRAILING EDGE OUTBD FLAP
57-798-40	57-798-40	57-798-40		SPCL DETAIL	LEFT WING TRAILING EDGE OUTBD FLAP
71-BCY-90-1	P71-21-00-6A			CHECK/INSP	ENGINE 1 MOUNTS
71-BCY-90-2	P71-21-00-6A			CHECK/INSP	ENGINE 2 MOUNTS
71-109-01-1	P71-00-00-6H	71-109		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - L
71-109-01-2	P71-00-00-6H	71-109		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - R
71-121-01-1	P71-00-00-6T	71-121		CHECK/INSP	STRUT DRAIN INLETS - ENG 1
71-121-01-2	P71-00-00-6T	71-121		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
71-124-01-1	P71-11-10-2A			OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 1
71-124-01-2	P71-11-10-2A			OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 2
71-209-01-1	G71-11-03-4P	71-209		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - L
71-209-01-2	G71-11-03-4P	71-209		CHECK/INSP	INLET COWL PRESSURE RELIEF DOORS - R
71-217-01-1	G71-00-00-6P	71-217		CHECK/INSP	STRUT DRAIN INLETS - ENG 1
71-217-01-2	G71-00-00-6P	71-217		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
71-225-01-1	G71-11-10-2A			OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 1
71-225-01-2	G71-11-10-2A			OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 2
71-226-01-1	G71-21-00-A			CHECK/INSP	ENGINE 1 SPHERICAL BEARING
71-226-01-2	G71-21-00-A			CHECK/INSP	ENGINE 2 SPHERICAL BEARING
71-317-01-1	H71-00-00-6P	71-317		CHECK/INSP	STRUT DRAIN INLETS - ENG 1
71-317-01-2	H71-00-00-6P	71-317		CHECK/INSP	STRUT DRAIN INLETS - ENG 2
71-323-51	H71-21-01-A	71-323		DISCARD	FWD ENG MNT THRUST LINKS AND BOLTS
71-325-01-1	H71-11-11-2A			OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 1
71-325-01-2	H71-11-11-2A			OPERATIONAL	COWL HOLD-OPEN RODS - ENGINE 2
71-326-01-1	H71-21-00-A			CHECK/INSP	ENGINE 1 SPHERICAL BEARING
71-326-01-2	H71-21-00-A			CHECK/INSP	ENGINE 2 SPHERICAL BEARING
71-327-C1-1	H71-11-01-A			BORESCOPE	ENGINE 1 ANTI-ICE TUBE LINK ASSEMBLY
71-327-C1-2	H71-11-01-A			BORESCOPE	ENGINE 2 ANTI-ICE TUBE LINK ASSEMBLY
71-329-01-1	H71-71-00-6B			CHECK/INSP	ENGINE 1 STRUT DRAINS
71-329-01-2	H71-71-00-6B			CHECK/INSP	ENGINE 2 STRUT DRAINS
71-329-02-1	H71-71-00-6B			CHECK/INSP	ENGINE 1 STRUT DRAINS
71-329-02-2	H71-71-00-6B			CHECK/INSP	ENGINE 2 STRUT DRAINS
71-401-01-1	N71-11-01-A	71-401		CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
71-401-01-2	N71-11-01-A	71-401		CHECK/INSP	EXTERNAL PORTIONS OF INLET COWL
71-406-01-1	N71-00-00-E	71-406	W-06-147-01-1	CHECK/INSP	EXTERNAL SURFACE OF THE CORE COWLS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
71-406-01-2	N71-00-00-E	71-406	W-06-147-01-2	CHECK/INSP	EXTERNAL SURFACE OF THE CORE COWLS
71-408-01-1	N71-00-00-G	71-408	W-06-149-01	CHECK/INSP	CORE COWL PRESSURE RELIEF DOORS
71-408-01-2	N71-00-00-G	71-408	W-06-149-01	CHECK/INSP	CORE COWL PRESSURE RELIEF DOORS
71-409-01-1	N71-11-00-A	71-409		CHECK/INSP	LEFT INLET COWL ACOUSTIC PANELS
71-409-01-2	N71-11-00-A	71-409		CHECK/INSP	RIGHT INLET COWL ACOUSTIC PANELS
71-410-01-1	N71-21-00-A	71-410	W-06-145-01	CHECK/INSP	ENG 1 FORWARD ENG MOUNT COMPONENTS
71-410-01-2	N71-21-00-A	71-410	W-06-145-01	CHECK/INSP	ENG 2 FORWARD ENG MOUNT COMPONENTS
71-412-01-1	N71-71-00-6A	71-412		CHECK/INSP	ENGINE 1 ENGINE DRAIN SYSTEM
71-412-01-2	N71-71-00-6A	71-412		CHECK/INSP	ENGINE 2 ENGINE DRAIN SYSTEM
71-413-01	N71-71-00-A	71-413		OPERATIONAL	ENGINE DRAIN LINES
71-416-01-1	N71-21-00-B	71-416	W-06-145-01	CHECK/INSP	ENGINE 1 AFT ENGINE MOUNT COMPONENTS
71-416-01-2	N71-21-00-B	71-416	W-06-145-01	CHECK/INSP	ENGINE 2 AFT ENGINE MOUNT COMPONENTS
71-416-02-1	N71-21-00-6A			FUNCTIONAL	ENG 1 AFT MOUNT COMPONENTS.
71-416-02-2	N71-21-00-6A			FUNCTIONAL	ENG 2 AFT MOUNT COMPONENTS.
71-421-01-1	N71-00-00-6A	71-421		CHECK/INSP	STRUT 1 DRAIN INLETS
71-421-01-2	N71-00-00-6A	71-421		CHECK/INSP	STRUT 2 DRAIN INLETS
71-424-01-1	N71-11-10-2A			OPERATIONAL	ENGINE 1 COWL HOLD-OPEN RODS
71-424-01-2	N71-11-10-2A			OPERATIONAL	ENGINE 2 COWL HOLD-OPEN RODS
71-425-01-1	N71-71-00-6B			CHECK/INSP	ENGINE 1 STRUT DRAINS
71-425-01-2	N71-71-00-6B			CHECK/INSP	ENGINE 2 STRUT DRAINS
71-501-C1-1	D71-21-01-6A			CHECK/INSP	ENGINE 1 FRONT MOUNT
71-501-C1-2	D71-21-01-6A			CHECK/INSP	ENGINE 2 FRONT MOUNT
71-502-C1-1	D71-21-02-6A			CHECK/INSP	ENGINE 1 REAR MOUNT
71-502-C1-2	D71-21-02-6A			CHECK/INSP	ENGINE 2 REAR MOUNT
71-535-01	D71-71-01-A	71-535		OPERATIONAL	ENGINE DRAIN LINES
71-536-01-1	D71-21-02-A			CHECK/INSP	ENGINE 1 REAR ENGINE MOUNT
71-536-01-2	D71-21-02-A			CHECK/INSP	ENGINE 2 REAR ENGINE MOUNT
71-537-01-1	D71-21-01-A			CHECK/INSP	ENGINE 1 FRONT ENGINE MOUNT
71-537-01-2	D71-21-01-A			CHECK/INSP	ENGINE 2 FRONT ENGINE MOUNT
71-538-01-1	D71-21-02-B			DISCARD	ENGINE 1 REAR MOUNT PYLON BRACKET
71-538-01-2	D71-21-02-B			DISCARD	ENGINE 2 REAR MOUNT PYLON BRACKET
71-539-01-1	D71-21-01-D			DISCARD	ENG 1 FRONT MOUNT CENTER THRUST LINK
71-539-01-2	D71-21-01-D			DISCARD	ENG 2 FRONT MOUNT CENTER THRUST LINK
71-540-01-1	D71-21-01-B			DISCARD	FRONT MOUNT PYLON MOUNTING BRACKET
71-540-01-2	D71-21-01-B			DISCARD	FRONT MOUNT PYLON MOUNTING BRACKET

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
71-541-01-1	D71-21-01-C			DISCARD	ENGINE 1 FRONT MOUNT LINK/PINS
71-541-01-2	D71-21-01-C			DISCARD	ENGINE 2 FRONT MOUNT LINK/PINS
71-543-01-1	D71-11-01-E			CHECK/INSP	ENGINE 1 NOSE COWL ACOUSTIC LINERS
71-543-01-2	D71-11-01-E			CHECK/INSP	ENGINE 2 NOSE COWL ACOUSTIC LINERS
71-600-00	71-600-00	71-600-00		DETAILED IN	NO. 1 POWERPLANT
71-602-00	71-602-00	71-602-00		GEN VISUAL	NO. 1 POWERPLANT
71-604-00	71-604-00	71-604-00		DETAILED IN	NO. 2 POWERPLANT
71-606-00	71-606-00	71-606-00		GEN VISUAL	NO. 2 POWERPLANT
72-103	P72-31-03-A	72-103		REPLACE	FAN DISK
72-104-01-1	P72-32-02-6A	72-104		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES -L
72-104-01-2	P72-32-02-6A	72-104		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES -R
72-104-02-1	P72-00-00-C	72-104		CHECK/INSP	1.5 STAGE COMPRESSOR ROTOR BLADES -L
72-104-02-2	P72-00-00-C	72-104		CHECK/INSP	1.5 STAGE COMPRESSOR ROTOR BLADES -R
72-105	P72-32-00-A	72-105		REPLACE	FRONT COMPRESSOR ROTOR DISKS
72-109	P72-35-00-A	72-109		REPLACE	REAR COMPRESSOR DRIVE ROTOR DISKS
72-110-C1-1	P72-00-00-6A P72-00-00-6B			BORESCOPE	COMBUST LINER/1ST STAGE BLADE/VANE
72-110-C1-2	P72-00-00-6A P72-00-00-6B			BORESCOPE	COMBUST LINER/1ST STAGE BLADE/VANE
72-113	P72-51-01-A	72-113		REPLACE	HP TURBINE DISK
72-115	P72-52-00-A	72-115		REPLACE	LP TURBINE DISKS
72-202-01-1	G72-31-02-6C	72-202	W-06-083-01	CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 1
72-202-01-2	G72-31-02-6C	72-202	W-06-083-01	CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 2
72-203	G72-21-00-A	72-203		REPLACE	FAN ROTOR & LP COMPRESSOR SECTION
72-205-01-1	G79-21-05-2A	72-205		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 1
72-205-01-2	G79-21-05-2A	72-205		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 2
72-206	G72-31-00-A	72-206		REPLACE	HPC DISKS/SPOOLS/SHAFT AND CDP SEAL
72-207-C1-1	G72-00-00-6A G72-00-00-6B			BORESCOPE	COMBUSTION LINER AND HPT BLADES
72-207-C1-2	G72-00-00-6A G72-00-00-6B			BORESCOPE	COMBUSTION LINER AND HPT BLADES
72-209	G72-50-00-A	72-209		REPLACE	H.P. TURBINE DISKS,DIFFUSER,SPACER
72-211	G72-52-01-A	72-211		REPLACE	LP TURBINE DISKS/SHAFT
72-302-01-1	H72-31-02-6C	72-302		CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 1
72-302-01-2	H72-31-02-6C	72-302		CHECK/INSP	LP COMPRESSOR ROTOR BLADES - ENG 2

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
72-303	H72-30-00-A	72-303		REPLACE	FAN ROTOR & LP COMPRESSOR SECTION
72-305-01-1	H79-21-05-2A	72-305		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 1
72-305-01-2	H79-21-05-2A	72-305		CHECK/INSP	MAGNETIC CHIP DETECTOR - ENG 2
72-306	H72-30-00-B	72-306		REPLACE	HPC DISKS/SPOOLS/SHAFT AND CDP SEAL
72-307-C1-1	H72-00-00-6A H72-00-00-6B			BORESCOPE	COMBUSTION LINER AND HPT BLADES
72-307-C1-2	H72-00-00-6A H72-00-00-6B			BORESCOPE	COMBUSTION LINER AND HPT BLADES
72-309	H72-50-00-A	72-309		REPLACE	H.P. TURBINE DISKS,DIFFUSER,SPACER
72-311	H72-50-00-B	72-311		REPLACE	LP TURBINE DISKS/SHAFT
72-401-01-1	N72-31-02-6A	72-401		CHECK/INSP	ENGINE 1 FAN ROTOR BLADES
72-401-01-2	N72-31-02-6A	72-401		CHECK/INSP	ENGINE 2 FAN ROTOR BLADES
72-401-02-1	N72-31-02-6A			CHECK/INSP	ENGINE 2 FAN ROTOR BLADES
72-401-02-2	N72-31-02-6A			CHECK/INSP	ENGINE 1 FAN ROTOR BLADES
72-402-01-1	N72-31-01-6A	72-402		CHECK/INSP	EXTERNAL PORTION OF INLET CONE
72-402-01-2	N72-31-01-6A	72-402		CHECK/INSP	EXTERNAL PORTION OF INLET CONE
72-403	N72-30-00-A	72-403		REPLACE	FAN HUB
72-404-01-1	N72-31-04-6A	72-404		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES
72-404-01-2	N72-31-04-6A	72-404		CHECK/INSP	1ST STAGE COMPRESSOR STATOR VANES
72-404-02-1	N72-31-05-A	72-404		CHECK/INSP	1.6 STAGE COMPRESSOR ROTOR BLADES
72-404-02-2	N72-31-05-A	72-404		CHECK/INSP	1.6 STAGE COMPRESSOR ROTOR BLADES
72-405	N72-30-00-B	72-405		REPLACE	LOW PRESSURE COMPRESSOR DRUM ROTOR
72-406-01-1	N72-33-01-6A	72-406		CHECK/INSP	FAN CASE RING SEGMENTS (RUBSTRIPS)
72-406-01-2	N72-33-01-6A	72-406		CHECK/INSP	FAN CASE RING SEGMENTS (RUBSTRIPS)
72-407-01-1	N72-33-02-6A	72-407		CHECK/INSP	FAN EXIT CASE AND VANES ASSEMBLY
72-407-01-2	N72-33-02-6A	72-407		CHECK/INSP	FAN EXIT CASE AND VANES ASSEMBLY
72-407-02-1	N72-33-02-A	72-407		CHECK/INSP	ENGINE 1 FAN EXIT REAR CASE ASSEMBLY
72-407-02-2	N72-33-02-A	72-407		CHECK/INSP	ENGINE 2 FAN EXIT REAR CASE ASSEMBLY
72-407-03-1	N72-34-03-6A	72-407		CHECK/INSP	ENGINE 1 FAN EXIT LINER SEGMENTS
72-407-03-2	N72-34-03-6A	72-407		CHECK/INSP	ENGINE 2 FAN EXIT LINER SEGMENTS
72-409	N72-30-00-C	72-409		REPLACE	HPC COMPRESSOR COMPONENTS
72-410-C1-1	N72-00-00-6A N72-00-00-6B N72-00-00-6C			BORESCOPE	COMBUSTION LINER/HP AND LP TURBINES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-90



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
72-410-C1-2	N72-00-00-6A N72-00-00-6B N72-00-00-6C			BORESCOPE	COMBUSTION LINER/HP AND LP TURBINES
72-410-C2-1	N72-00-00-6A N72-00-00-6B N72-00-00-6C			BORESCOPE	COMBUSTION LINER/HP AND LP TURBINES
72-410-C2-2	N72-00-00-6A N72-00-00-6B N72-00-00-6C			BORESCOPE	COMBUSTION LINER/HP AND LP TURBINES
72-413	N72-50-00-A	72-413		REPLACE	HP TURBINE ROTATING COMPONENTS
72-414-01-1	N72-53-01-6A	72-414		CHECK/INSP	6TH STAGE TURBINE VANES AND BLADES
72-414-01-2	N72-53-01-6A	72-414		CHECK/INSP	6TH STAGE TURBINE VANES AND BLADES
72-415	N72-50-00-B	72-415		REPLACE	LP TURBINE ROTATING COMPONENTS
72-418-01-1	N72-50-00-D	72-418	W-06-145-01	CHECK/INSP	ENGINE 1 TURBINE EXHAUST CASE RAILS
72-418-01-2	N72-50-00-D	72-418	W-06-145-01	CHECK/INSP	ENGINE 2 TURBINE EXHAUST CASE RAILS
72-420-01-1	N72-61-01-6A	72-420	W-06-145-01	CHECK/INSP	ENGINE 1 MAIN GEARBOX HOUSING
72-420-01-2	N72-61-01-6A	72-420	W-06-145-01	CHECK/INSP	ENGINE 2 MAIN GEARBOX HOUSING
72-422-51-1	N72-62-01-6A	72-422	W-06-145-01	CHECK/INSP	ENGINE 1 ANGLE GEARBOX HOUSING
72-422-51-2	N72-62-01-6A	72-422	W-06-145-01	CHECK/INSP	ENGINE 2 ANGLE GEARBOX HOUSING
72-424	N72-00-00-C	72-424		REPLACE	TURBINE SHAFT COUPLING
72-425-01-1	N72-33-01-A	72-425		CHECK/INSP	ENGINE 1 FRONT FAN CASE
72-425-01-2	N72-33-01-A	72-425		CHECK/INSP	ENGINE 2 FRONT FAN CASE
72-426-01-1	N72-31-03-6A	72-426		CHECK/INSP	ENGINE 1 FAN EXIT FAIRING
72-426-01-2	N72-31-03-6A	72-426		CHECK/INSP	ENGINE 2 FAN EXIT FAIRING
72-427-01-1	N72-30-00-D	72-427	W-06-145-01	CHECK/INSP	ENGINE 1 FRONT MOUNT THRUST BRACKETS
72-427-01-2	N72-30-00-D	72-427	W-06-145-01	CHECK/INSP	ENGINE 2 FRONT MOUNT THRUST BRACKETS
72-431-02-1	N72-54-01-2A			CLEAN/INSP	ENG 1 NUMBER 4 BEARING COMPARTMENT
72-431-02-2	N72-54-01-2A			CLEAN/INSP	ENG 2 NUMBER 4 BEARING COMPARTMENT
72-433-01-1	N72-31-02-6B		W-72-401-01-1	LUBRICATE	ENG 1 FAN BLADE PART-SPAN SHROUD
72-433-01-2	N72-31-02-6B		W-72-401-01-2	LUBRICATE	ENG 2 FAN BLADE PART-SPAN SHROUD
72-433-02-1	N72-31-02-6B		W-72-401-01-1	LUBRICATE	ENG 1 FAN BLADE PART-SPAN SHROUD
72-433-02-2	N72-31-02-6B		W-72-401-01-2	LUBRICATE	ENG 2 FAN BLADE PART-SPAN SHROUD
72-434-01-1	N72-35-00-A			CHECK/INSP	ENGINE 1 HPC VARIABLE STATOR VANES
72-434-01-2	N72-35-00-A			CHECK/INSP	ENGINE 2 HPC VARIABLE STATOR VANES
72-435-01-1	N72-35-00-B			CHECK/INSP	ENGINE 1 HPC ROTOR BLADE LOCKS
72-435-01-2	N72-35-00-B			CHECK/INSP	ENGINE 2 HPC ROTOR BLADE LOCKS

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
72-436-01-1	N72-00-00-E			BORESCOPE	ENGINE 1 HPT STAGE 1 BLADES
72-436-01-2	N72-00-00-E			BORESCOPE	ENGINE 2 HPT STAGE 1 BLADES
72-501	D72-31-04-A	72-501		REPLACE	LP COMPRESSOR (FAN) SHAFT AND DISC
72-502	D72-31-02-A	72-502		REPLACE	LP COMPRESSOR (FAN) BLADES
72-503-01-1	D72-33-02-6A	72-503		CHECK/INSP	ENGINE 1 "A" FRAME ATTACHMENT POINTS
72-503-01-2	D72-33-02-6B	72-503		CHECK/INSP	ENGINE 2 "A" FRAME ATTACHMENT POINTS
72-504	D72-33-00-A	72-504		REPLACE	IP COMPRESSOR REAR STUB SHAFT
72-505	D72-33-01-A	72-505		REPLACE	IC DISC STAGE 1 TO 7 ASSEMBLIES
72-506-C1-1	D72-00-00-6A			BORESCOPE	ENGINE 1 COMBUSTION LINER/HP TURBINE
72-506-C1-2	D72-00-00-6B			BORESCOPE	ENGINE 2 COMBUSTION LINER/HP TURBINE
72-506-C2-1	D72-00-00-6A			BORESCOPE	ENGINE 1 COMBUSTION LINER/HP TURBINE
72-506-C2-2	D72-00-00-6B			BORESCOPE	ENGINE 2 COMBUSTION LINER/HP TURBINE
72-507	D72-30-01-A	72-507		REPLACE	HP COMPRESSOR ROTOR SHAFT ASSEMBLY
72-509	D72-40-00-A	72-509		REPLACE	HP TURBINE DISC
72-511	D72-50-00-A	72-511		REPLACE	IP TURBINE SHAFT
72-512	D72-51-03-A	72-512		REPLACE	IP, LP1, LP2 AND LP3 TURBINE DISCS
72-513	D72-51-03-B	72-513		REPLACE	LP TURBINE SHAFT
72-521-01-1	D72-02-01-6A	72-521		CHECK/INSP	ENGINE 1 CORE-MOUNTED P2.5 PIPING
72-521-01-2	D72-02-01-6A	72-521		CHECK/INSP	ENGINE 2 CORE-MOUNTED P2.5 PIPING
72-525-01-1	D72-03-00-A			CHECK/INSP	ENGINE 1 COMPRESSOR FAIRINGS
72-525-01-2	D72-03-00-A			CHECK/INSP	ENGINE 2 COMPRESSOR FAIRINGS
73-BCY-90-1	P73-21-07-2A			CHECK/INSP	ENGINE 1 EEC AND ENGINE WIRING
73-BCY-90-2	P73-21-07-2A			CHECK/INSP	ENGINE 2 EEC AND ENGINE WIRING
73-BCY-91-1	P73-21-04-4A			REPLACE	ENGINE 1 PT2/TT2 SENSOR
73-BCY-91-2	P73-21-04-4A			REPLACE	ENGINE 2 PT2/TT2 SENSOR
73-101-01-1	P73-11-02-4A	73-101		REPLACE	FUEL PUMP FILTER ELEMENT - ENG 1
73-101-01-2	P73-11-02-4A	73-101		REPLACE	FUEL PUMP FILTER ELEMENT - ENG 2
73-109-01-1	P73-21-07-5A	73-109		OPERATIONAL	EEC TRIM UNLOCK SOLENOID - ENG 1
73-109-01-2	P73-21-07-5A	73-109		OPERATIONAL	EEC TRIM UNLOCK SOLENOID - ENG 2
73-111-01-1	P73-14-00-5A			OPERATIONAL	ENGINE FUEL DEICING SYSTEM - ENG 1
73-111-01-2	P73-14-00-5A			OPERATIONAL	ENGINE FUEL DEICING SYSTEM - ENG 2
73-112-01-1	P73-14-03-4A			FUNCTIONAL	FUEL FILTER DIFF PRESSURE SWITCH -L
73-112-01-2	P73-14-03-4A			FUNCTIONAL	FUEL FILTER DIFF PRESSURE SWITCH -R
73-203-01-1	G73-11-02-2A	73-203		REPLACE	FUEL FILTER ELEMENT - ENG 1
73-203-01-2	G73-11-02-2A	73-203		REPLACE	FUEL FILTER ELEMENT - ENG 2

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-92



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
73-206-01-1	G73-34-00-5A			FUNCTIONAL	FUEL FILTER BYPASS WARNING SYSTEM -L
73-206-01-2	G73-34-00-5A			FUNCTIONAL	FUEL FILTER BYPASS WARNING SYSTEM -R
73-206-51-1	G73-21-06-6A	73-206		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
73-206-51-2	G73-21-06-6A	73-206		OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
73-206-52-1	G73-21-06-6A			OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
73-206-52-2	G73-21-06-6A			OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
73-206-53-1	G73-21-06-6A			OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
73-206-53-2	G73-21-06-6A			OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
73-206-54-1	G73-21-06-6A			OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
73-206-54-2	G73-21-06-6A			OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 2
73-206-55-1	G73-21-06-6A			OPERATIONAL	FLIGHT IDLE SELECT SOLENOID - ENG 1
73-206-55-2	G73-21-06-6A			OPERATIONAL	FLIGHT-IDLE SELECT SOLENOID - ENG 2
73-207-51-1	G73-21-07-5A	73-207		OPERATIONAL	FAIL-FIXED SOLENOID CIRCUIT - ENG 1
73-207-51-2	G73-21-07-5A	73-207		OPERATIONAL	FAIL-FIXED SOLENOID CIRCUIT - ENG 2
73-303-01-1	H73-11-02-4A	73-303		REPLACE	FUEL FILTER ELEMENT - ENG 1
73-303-01-2	H73-11-02-4A	73-303		REPLACE	FUEL FILTER ELEMENT - ENG 2
73-306-01-1	H73-34-00-5A			FUNCTIONAL	FUEL FILTER BYPASS WARNING SYSTEM -L
73-306-01-2	H73-34-00-5A			FUNCTIONAL	FUEL FILTER BYPASS WARNING SYSTEM -R
73-401-01-1	N73-11-02-4A	73-401		REPLACE	ENGINE 1 FUEL PUMP FILTER ELEMENT
73-401-01-2	N73-11-02-4B	73-401		REPLACE	ENGINE 2 FUEL PUMP FILTER ELEMENT
73-403-01-1	N73-00-00-B	73-403		CHECK/INSP	FUEL LINES, MANIFOLDS AND COMPONENTS
73-403-01-2	N73-00-00-B	73-403		CHECK/INSP	FUEL LINES, MANIFOLDS AND COMPONENTS
73-405-01-1	N73-34-01-4A			FUNCTIONAL	FUEL PUMP FILTER DIFF PRESS SWITCH
73-405-01-2	N73-34-01-4B			FUNCTIONAL	FUEL PUMP FILTER DIFF PRESS SWITCH
73-406-01-1	N73-21-15-5A			OPERATIONAL	ENGINE 1 SUPPLEMENTAL CONTROL UNIT
73-406-01-2	N73-21-15-5A			OPERATIONAL	ENGINE 2 SUPPLEMENTAL CONTROL UNIT
73-501-01-1	D73-11-02-4A	73-501		REPLACE	ENGINE 1 LOW PRESSURE FUEL FILTER
73-501-01-2	D73-11-02-4B	73-501		REPLACE	ENGINE 2 LOW PRESSURE FUEL FILTER
73-502-01-1	D73-21-09-5A	73-502		OPERATIONAL	ENGINE 1 FAFC
73-502-01-2	D73-21-09-5B	73-502		OPERATIONAL	ENGINE 2 FAFC
73-503-01-1	D73-21-17-6A	73-503	W-06-160-01-1	CHECK/INSP	P2.0/T2.0 SENSOR, TUBE AND WIRING
73-503-01-2	D73-21-17-6A	73-503	W-60-160-01-2	CHECK/INSP	P2.0/T2.0 SENSOR, TUBE AND WIRING
73-509-01-1	D73-21-04-3A			CHECK/INSP	ENGINE 1 FAFC WATER TRAPS
73-509-01-2	D73-21-04-3A			CHECK/INSP	ENGINE 2 FAFC WATER TRAPS
74-101-01-1	P74-21-02-6A	74-101	W-74-R03	CHECK/INSP	IGNITER PLUGS - ENG 1

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
74-101-01-2	P74-21-02-6A	74-101	W-74-R03	CHECK/INSP	IGNITER PLUGS - ENG 2
74-102-01-1	P74-00-00-5A	74-102		FUNCTIONAL	1 AND "2" IGNITION SYSTEMS - ENG 1
74-102-01-2	P74-00-00-5A	74-102		FUNCTIONAL	1 AND "2" IGNITION SYSTEMS - ENG 2
74-103-01	P74-00-00-5B		A-74-102-01	OPERATIONAL	IGNITION CONTROL SYSTEMS
74-201-01-1	G74-00-00-5A	74-201		FUNCTIONAL	IGNITION SYSTEM - ENG 1
74-201-01-2	G74-00-00-5A	74-201		FUNCTIONAL	IGNITION SYSTEM - ENG 2
74-202-01	G74-00-00-5B			OPERATIONAL	IGNITION CONTROL SYSTEMS
74-301-01-1	H74-00-00-5A	74-301		FUNCTIONAL	IGNITION SYSTEM - ENG 1
74-301-01-2	H74-00-00-5A	74-301		FUNCTIONAL	IGNITION SYSTEM - ENG 2
74-301-02-1	H74-00-00-5A			FUNCTIONAL	ENGINE 1 IGNITION SYSTEM
74-301-02-2	H74-00-00-5A			FUNCTIONAL	ENGINE 2 IGNITION SYSTEM
74-301-03-1	H74-00-00-5A			FUNCTIONAL	ENGINE 1 IGNITION SYSTEM
74-301-03-2	H74-00-00-5A			FUNCTIONAL	ENGINE 2 IGNITION SYSTEM
74-301-04-1	H74-00-00-5A			FUNCTIONAL	ENGINE 1 IGNITION SYSTEM
74-301-04-2	H74-00-00-5A			FUNCTIONAL	ENGINE 2 IGNITION SYSTEM
74-302-01	H74-00-00-5B			OPERATIONAL	IGNITION CONTROL SYSTEMS
74-302-02	H74-00-00-5B			OPERATIONAL	IGNITION CONTROL SYSTEMS
74-302-03	H74-00-00-5B			OPERATIONAL	IGNITION CONTROL SYSTEMS
74-302-04	H74-00-00-5B			OPERATIONAL	IGNITION CONTROL SYSTEMS
74-401-01-1	N74-21-02-6A	74-401	W-74-405-01-1	CHECK/INSP	ENGINE 1 IGNITER PLUGS
74-401-01-2	N74-21-02-6A	74-401	W-74-405-01-2	CHECK/INSP	ENGINE 2 IGNITER PLUGS
74-402-01-1	N74-00-00-5A		W-74-406-01-1	OPERATIONAL	ENGINE 1 IGNITION SYSTEM
74-402-01-2	N74-00-00-5A		W-74-406-01-2	OPERATIONAL	ENGINE 2 IGNITION SYSTEM
74-403-01	N74-00-00-5B	74-403		OPERATIONAL	IGNITION CONTROL SYSTEM
74-404-01-1	N74-21-01-6A	74-404	W-74-405-01-1	CHECK/INSP	ENGINE 1 IGNITER PLUG CABLES
74-404-01-2	N74-21-01-6A	74-404	W-74-405-01-2	CHECK/INSP	ENGINE 2 IGNITER PLUG CABLES
74-405-01-1	N74-11-01-6A	74-405		CHECK/INSP	ENGINE 1 IGNITION EXCITER
74-405-01-2	N74-11-01-6B	74-405		CHECK/INSP	ENGINE 2 IGNITION EXCITER
74-406-01-1	N74-00-00-5C		W-74-402-01-1	OPERATIONAL	ENGINE 1 CONTINUOUS IGNITION SYSTEM
74-406-01-2	N74-00-00-5C		W-74-402-01-2	OPERATIONAL	ENGINE 2 CONTINUOUS IGNITION SYSTEM
74-407-01-1	N74-21-02-A			CHECK/INSP	ENGINE 1 IGNITOR PLUG TIP WEAR
74-407-01-2	N74-21-02-A			CHECK/INSP	ENGINE 2 IGNITOR PLUG TIP WEAR
74-501-01-1	D74-00-00-5A	74-501		OPERATIONAL	HIGH ENERGY IGNITION UNIT-10 JOULES
74-501-01-2	D74-00-00-5E	74-501		OPERATIONAL	HIGH ENERGY IGNITION UNIT-10 JOULES
74-502-01-1	D74-00-00-5B	74-502		OPERATIONAL	ENG 1 CONTINUOUS IGNITION (4 JOULES)

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
74-502-01-2	D74-00-00-5F	74-502		OPERATIONAL	ENG 2 CONTINUOUS IGNITION (4 JOULES)
74-503-01-1	D74-00-00-5C	74-503		OPERATIONAL	ENGINE 1 STANDBY IGNITION
74-503-01-2	D74-00-00-5G	74-503		OPERATIONAL	ENGINE 2 STANDBY IGNITION
74-504-01-1	D74-00-00-5D	74-504		OPERATIONAL	ENGINE 1 APPROACH/LANDING IGNITION
74-504-01-2	D74-00-00-5H	74-504		OPERATIONAL	ENGINE 2 APPROACH/LANDING IGNITION
74-505-01-1	D74-00-00-5A	74-505		OPERATIONAL	ENGINE 1 TAI IGNITION ENGINE 1
74-505-01-2	D74-00-00-5E	74-505		OPERATIONAL	ENGINE 2 TAI IGNITION
74-506-01-1	D74-21-02-6A	74-506		CHECK/INSP	ENGINE 1 IGNITOR PLUGS
74-506-01-2	D74-21-02-6B	74-506		CHECK/INSP	ENGINE 2 IGNITER PLUGS
74-506-02-1	D74-21-02-6A			CHECK/INSP	ENGINE 1 IGNITOR PLUGS
74-506-02-2	D74-21-02-6B			CHECK/INSP	ENGINE 2 IGNITER PLUGS
74-507-01-1	D74-11-01-6A			CHECK/INSP	ENG 1 HE IGNITION EXCITER UNIT CASE
74-507-01-2	D74-11-01-6B			CHECK/INSP	ENG 2 HE IGNITION EXCITER UNIT CASE
75-102-01-1	P75-11-02-2A	75-102		CLEAN	STATOR VANE ANTI-ICE VALVE STRAINER
75-102-01-2	P75-11-02-2A	75-102		CLEAN	STATOR VANE ANTI-ICE VALVE STRAINER
75-121-01-1	P75-23-00-5A			OPERATIONAL	ENGINE COOLING BAROMETRIC SWITCH -L
75-121-01-2	P75-23-00-5A			OPERATIONAL	ENGINE COOLING BAROMETRIC SWITCH -R
75-123-01-1	P75-32-05-6A			OPERATIONAL	BLD SYSTEM PUSH-PULL FEEDBACK CABLE
75-123-01-2	P75-32-05-6A			OPERATIONAL	BLD SYSTEM PUSH-PULL FEEDBACK CABLE
75-404-01-1	N75-24-00-6A N75-24-00-A	75-404		OPERATIONAL	ENGINE 1 TURBINE CASE COOLING
75-404-01-2	N75-24-00-6A N75-24-00-A	75-404		OPERATIONAL	ENGINE 2 TURBINE CASE COOLING
75-406-01-1	N75-32-00-6A	75-406		CHECK/INSP	2.5 BLEED VALVE-TO-ACTUATOR LINKAGE
75-406-01-2	N75-32-00-6A	75-406		CHECK/INSP	2.5 BLEED VALVE-TO-ACTUATOR LINKAGE
75-407-01-1	N75-24-02-A	75-407		CHECK/INSP	ENGINE 1 TCA AIR SUPPLY DUCTS
75-407-01-2	N75-24-02-A	75-407		CHECK/INSP	ENGINE 2 TCA AIR SUPPLY DUCTS
75-410-01-1	N75-23-00-5A			OPERATIONAL	ENGINE COOLING BAROMETRIC SWITCH
75-410-01-2	N75-23-00-5B			OPERATIONAL	ENGINE COOLING BAROMETRIC SWITCH
75-411-C1-1	N75-33-00-6A N75-33-00-6B			CHECK/INSP	ENG 1 TCA AND TRC VALVE INDICATORS
75-411-C1-2	N75-33-00-6A N75-33-00-6B			CHECK/INSP	ENG 2 TCA AND TRC VALVE INDICATORS
75-412-01-1	N75-24-00-6B			CHECK/INSP	ENGINE 1 TCA SOLENOID VALVE
75-412-01-2	N75-24-00-6B			CHECK/INSP	ENGINE 2 TCA SOLENOID VALVE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
75-414-01-1	N75-33-00-6C			CHECK/INSP	ENGINE 1 TCA VALVE INDICATOR
75-414-01-2	N75-33-00-6C			CHECK/INSP	ENGINE 2 TCA VALVE INDICATOR
75-415-01-1	N75-33-05-A			REPLACE	ENGINE 1 PS3 AIR FILTERS
75-415-01-2	N75-33-05-A			REPLACE	ENGINE 2 PS3 AIR FILTERS
75-507-01-1	D75-21-00-E			CHECK/INSP	ENGINE 1 CABIN AIR OFFTAKE DUCTING
75-517-01-2	D75-21-00-E			CHECK/INSP	ENGINE 2 CABIN AIR OFFTAKE DUCTING
77-BCY-90-1	P77-31-00-5A			OPERATIONAL	AVM SYSTEM
77-104-01	P77-41-00-5A	77-104		OPERATIONAL	STANDBY ENGINE INDICATOR
77-204-01	G77-00-00-6D	77-204		OPERATIONAL	STANDBY ENGINE INDICATOR
77-304-01	H77-41-00-5A	77-304		OPERATIONAL	STANDBY ENGINE INDICATOR
77-305-01	H77-35-00-2A	77-305		OPERATIONAL	PIMU FAULT MESSAGES
77-306-01	H77-35-00-2B	77-306		OPERATIONAL	EEC CATEGORY 2 FAULTS
77-405-01	N77-35-00-2A	77-405		OPERATIONAL	PIMU FAULT MESSAGES
77-406-01	N77-35-00-2B	77-406		OPERATIONAL	EEC CATEGORY 2 FAULTS
77-407-01	N77-41-01-4A	77-407		OPERATIONAL	STANDBY ENGINE INDICATOR
77-501-01-1	D77-35-00-2A	77-501		OPERATIONAL	ENGINE 1 PIMU FAULT MESSAGES
77-501-01-2	D77-35-00-2A	77-501		OPERATIONAL	ENGINE 2 PIMU FAULT MESSAGES
77-502-01	D77-41-00-5A	77-502		OPERATIONAL	STANDBY ENGINE INDICATOR
77-503-01-1	D77-35-00-2B	77-503		OPERATIONAL	ENGINE 1 EEC CATEGORY 2 FAULTS
77-503-01-2	D77-35-00-2B	77-503		OPERATIONAL	ENGINE 2 EEC CATEGORY 2 FAULTS
77-505-01-1	D77-35-00-B			OPERATIONAL	ENGINE 1 PIMU FAULT MESSAGES
77-505-01-2	D77-35-00-B			OPERATIONAL	ENGINE 2 PIMU FAULT MESSAGES
78-BCY-90-1	P78-31-00-5B			OPERATIONAL	THRUST REVERSER
78-BCY-90-2	P78-31-00-5B			OPERATIONAL	THRUST REVERSER
78-111-01-1	P78-00-00-H	78-111		CHECK/INSP	LOUVERED EXHAUST DOOR - ENG 1
78-111-01-2	P78-00-00-H	78-111		CHECK/INSP	LOUVERED EXHAUST DOOR - ENG 2
78-113-02-1	P78-31-14-6B	78-113		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS
78-113-02-2	P78-31-14-6B	78-113		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS
78-120-01-1	12-12-02-3A			SERVICE	THRUST REVERSER HYD COWL OPENING SYS
78-120-01-2	12-12-02-3A			SERVICE	THRUST REVERSER HYD COWL OPENING SYS
78-120-51-1	P78-00-00-6R	78-120		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
78-120-51-2	P78-00-00-6R	78-120		CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
78-121-C1-1	P78-00-00-6T P78-00-00-6U			CHECK/INSP	ENG 1 T/R BULL-NOSE SEAL AND FAIRING

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
78-121-C1-2	P78-00-00-6T P78-00-00-6U			CHECK/INSP	ENG 2 T/R BULL-NOSE SEAL AND FAIRING
78-121-C2-1	P78-34-07-A P78-34-07-B			FUNCTIONAL	ENG 1 T/R SYNC LOCK AND CIRCUITRY
78-121-C2-2	P78-34-07-A P78-34-07-B			FUNCTIONAL	ENG 2 T/R SYNC LOCK AND CIRCUITRY
78-121-01-1	P78-31-20-2A			RESTORE	L T/R HYDRAULIC COWL OPENING FILTER
78-121-01-2	P78-31-20-2A			RESTORE	R T/R HYDRAULIC COWL OPENING FILTER
78-123-01-1	P78-36-00-5A			OPERATIONAL	T/R DISAGREEMENT CIRCUIT - L ENGINE
78-123-01-2	P78-36-00-5A			OPERATIONAL	T/R DISAGREEMENT CIRCUIT - R ENGINE
78-125-51	P78-36-00-5C	78-125		OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
78-126-51	P78-36-07-5A	78-126		OPERATIONAL	THRUST REVERSER RELAY MODULE
78-134-01-1	P78-31-14-6A			CHECK/INSP	ENG 1 THRUST REVERSER BLOCKER DOORS
78-134-01-2	P78-31-14-6A			CHECK/INSP	ENG 2 THRUST REVERSER BLOCKER DOORS
78-137-C1-1	P78-31-00-5A P78-31-00-5B			OPERATIONAL	ENG 1 T/R LOCKING HYDRAULIC ACTUATOR
78-137-C1-2	P78-31-00-5A P78-31-00-5B			OPERATIONAL	ENG 2 T/R LOCKING HYDRAULIC ACTUATOR
78-211-01-1	G78-00-00-6J	78-211		CHECK/INSP	LOUVERED EXHAUST DOOR HINGES/LATCHES
78-211-01-2	G78-00-00-6J	78-211		CHECK/INSP	LOUVERED EXHAUST DOOR HINGES/LATCHES
78-212-02-1	G78-00-00-6S	78-212		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS
78-212-02-2	G78-00-00-6S	78-212		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS
78-219-01-1	12-12-02-3A			SERVICE	THRUST REVERSER HYD COWL OPENING SYS
78-219-01-2	12-12-02-3A			SERVICE	THRUST REVERSER HYD COWL OPENING SYS
78-219-51-1	G78-00-00-6R			CHECK/INSP	NACELLE/STRUT FIRE/DRAINAGE SEALS -L
78-219-51-2	G78-00-00-6R			CHECK/INSP	NACELLE/STRUT FIRE/DRAINAGE SEALS -R
78-220-C1-1	G78-00-00-6T G78-00-00-6U			CHECK/INSP	ENG 1 T/R BULL-NOSE SEAL AND FAIRING
78-220-C1-2	G78-00-00-6T G78-00-00-6U			CHECK/INSP	ENG 2 T/R BULL-NOSE SEAL AND FAIRING
78-220-01-1	G78-31-20-2A			CLEAN	HYDRAULIC COWL OPENING PUMP FILTER
78-220-01-2	G78-31-20-2A			CLEAN	HYDRAULIC COWL OPENING PUMP FILTER
78-221-52	G78-36-00-5C	78-221		OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
78-222-01-1	G78-36-00-5A			OPERATIONAL	T/R DISAGREEMENT CIRCUIT - L ENGINE
78-222-01-2	G78-36-00-5B			OPERATIONAL	T/R DISAGREEMENT CIRCUIT - R ENGINE
78-222-51	G78-36-07-5A	78-222		OPERATIONAL	THRUST REVERSER RELAY MODULE

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
78-223-C1-1	G78-34-07-A G78-34-07-B			FUNCTIONAL	ENG 1 T/R SYNC LOCK AND CIRCUITRY
78-223-C1-2	G78-34-07-A G78-34-07-B			FUNCTIONAL	ENG 2 T/R SYNC LOCK AND CIRCUITRY
78-224-C1-1	G78-31-00-5A G78-31-00-5B			OPERATIONAL	ENG 1 T/R LOCKING HYDRAULIC ACTUATOR
78-224-C1-2	G78-31-00-5A G78-31-00-5B			OPERATIONAL	ENG 2 T/R LOCKING HYDRAULIC ACTUATOR
78-237-01-1	G78-31-13-6B			CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
78-237-01-2	G78-31-13-6B			CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
78-312-02-1	H78-00-00-B	78-312		CHECK/INSP	THRUST REVERSER BLOCKER DOORS
78-312-02-2	H78-00-00-B	78-312		CHECK/INSP	THRUST REVERSER BLOCKER DOORS
78-319-01-1	12-13-07-3A			SERVICE	THRUST REVERSER HYD COWL OPENING SYS
78-319-01-2	12-13-07-3A			SERVICE	THRUST REVERSER HYD COWL OPENING SYS
78-319-51-1	H78-00-00-6R			CHECK/INSP	NACELLE/STRUT FIRE/DRAINAGE SEALS -L
78-319-51-2	H78-00-00-6R			CHECK/INSP	NACELLE/STRUT FIRE/DRAINAGE SEALS -R
78-322-01-1	H78-31-00-A	78-322		CHECK/INSP	L T/R BALLSCREW ACTUATOR ATTACH PT
78-322-01-2	H78-31-00-A	78-322		CHECK/INSP	R T/R BALLSCREW ACTUATOR ATTACH PT
78-323-02-1	H78-31-14-6A		W-78-323-03-1	CHECK/INSP	ENGINE 1 T/R BLOCKER DOOR HINGES
78-323-02-2	H78-31-14-6A		W-78-323-03-2	CHECK/INSP	ENGINE 2 T/R BLOCKER DOOR HINGES
78-327-C1-1	H78-36-00-5E H78-36-00-5I H78-36-00-5G			FUNCTIONAL	ENG 1 T/R INDICATION CIRCUIT CHECK
78-327-C1-2	H78-36-00-5F H78-36-00-5J H78-36-00-5H			FUNCTIONAL	ENG 2 T/R INDICATION CIRCUIT CHECK
78-327-C1-3	H78-36-00-5E H78-36-00-5G H78-36-00-5I			FUNCTIONAL	ENG 1 T/R INDICATION CIRCUIT CHECK
78-327-C1-4	H78-36-00-5F H78-36-00-5H H78-36-00-5J			FUNCTIONAL	ENG 2 T/R INDICATION CIRCUIT CHECK
78-327-01-1	H78-36-00-5A	78-327		FUNCTIONAL	ENG 1 T/R PNEUMATIC PRESSURE SWITCH
78-327-01-2	H78-36-00-5B	78-327		FUNCTIONAL	ENG 2 T/R PNEUMATIC PRESSURE SWITCH
78-327-01-3	H78-36-00-5A			FUNCTIONAL	ENG 1 T/R PNEUMATIC PRESSURE SWITCH
78-327-01-4	H78-36-00-5B			FUNCTIONAL	ENG 2 T/R PNEUMATIC PRESSURE SWITCH
78-329-01-1	H78-36-00-5C	78-329		OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-98



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
78-329-01-2	H78-36-00-5D	78-329		OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES
78-329-01-3	H78-36-00-5C			OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES
78-329-01-4	H78-36-00-5D			OPERATIONAL	T/R STOW/NOT-STOWED SWITCHES & WIRES
78-330-C1-1	H78-00-00-6T H78-00-00-6U			CHECK/INSP	ENG 1 T/R BULL-NOSE SEAL AND FAIRING
78-330-C1-2	H78-00-00-6T H78-00-00-6U			CHECK/INSP	ENG 2 T/R BULL-NOSE SEAL AND FAIRING
78-331-51-1	H78-31-21-A	78-331		OPERATIONAL	T/R CENTER DRIVE UNIT CONE BRAKE
78-331-51-2	H78-31-21-A	78-331		OPERATIONAL	T/R CENTER DRIVE UNIT CONE BRAKE
78-332-01-1	H78-34-01-2A			CLEAN	ENG 1 DIRECTIONAL PILOT VALVE FILTER
78-332-01-2	H78-34-01-2A			CLEAN	ENG 2 DIRECTIONAL PILOT VALVE FILTER
78-332-51-1	H78-34-07-A	78-332		OPERATIONAL	ENGINE 1 T/R ACTUATION SYSTEM BRAKE
78-332-51-2	H78-34-07-A	78-332		OPERATIONAL	ENGINE 2 T/R ACTUATION SYSTEM BRAKE
78-333-01-1	H78-34-00-5A			FUNCTIONAL	ENG 1 DIRECTIONAL PILOT VALVE LEAK
78-333-01-2	H78-34-00-5A			FUNCTIONAL	ENG 2 DIRECTIONAL PILOT VALVE LEAK
78-342-01-1	H78-34-07-B			REPLACE	ENGINE 1 T/R ACTUATION SYSTEM BRAKE
78-342-01-2	H78-34-07-B			REPLACE	ENGINE 2 T/R ACTUATION SYSTEM BRAKE
78-405-C1-1	N78-00-00-6C N78-00-00-6D			CHECK/INSP	FAN DUCT BULL-NOSE SEAL AND FAIRING
78-405-C1-2	N78-00-00-6C N78-00-00-6D			CHECK/INSP	FAN DUCT BULL-NOSE SEAL AND FAIRING
78-407-01-1	N78-31-14-6B	78-407		CHECK/INSP	ENG 1 T/R BLOCKER DOORS/COMPONENTS
78-407-01-2	N78-31-14-6B	78-407		CHECK/INSP	ENG 2 T/R BLOCKER DOORS/COMPONENTS
78-420-01-1	12-12-02-3A			SERVICE	T/R HYD COWL OPENING POWER UNIT
78-420-01-2	12-12-02-3A			SERVICE	T/R HYD COWL OPENING POWER UNIT
78-421-01-1	N78-31-20-2A			CLEAN	T/R HYD COWL OPENING POWER UNIT
78-421-01-2	N78-31-20-2A			CLEAN	T/R HYD COWL OPENING POWER UNIT
78-426-01-1	N78-00-00-6B			CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
78-426-01-2	N78-00-00-6B			CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
78-426-02-1	N78-00-00-6B			CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
78-426-02-2	N78-00-00-6B			CHECK/INSP	NACELLE/STRUT FIRE & DRAINAGE SEALS
78-426-02-3	N78-00-00-6C N78-00-00-6D			CHECK/INSP	FAN DUCT BULL-NOSE SEAL AND FAIRING
78-426-02-4	N78-00-00-6C N78-00-00-6D			CHECK/INSP	FAN DUCT BULL-NOSE SEAL AND FAIRING
78-429-03-1	N78-31-00-5A	78-429		FUNCTIONAL	CENTER LOCKING HYDRAULIC ACTUATOR

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
78-429-03-2	N78-31-00-5A	78-429		FUNCTIONAL	CENTER LOCKING HYDRAULIC ACTUATOR
78-431-C1-1	N78-34-13-A N78-34-13-B			FUNCTIONAL	ENG 1 T/R SYNC LOCK AND CIRCUITRY
78-431-C1-2	N78-34-13-A N78-34-13-B			FUNCTIONAL	ENG 2 T/R SYNC LOCK AND CIRCUITRY
78-431-02-1	N78-31-11-6B			CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
78-431-02-2	N78-31-11-6B			CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
78-432-52	N78-36-00-5B			OPERATIONAL	T/R AIR/GND INDICATION INHIBIT RELAY
78-433-01	N78-36-03-5A	78-433		OPERATIONAL	THRUST REVERSER RELAY MODULE
78-436-01-1	N78-36-00-5A			OPERATIONAL	ENGINE 1 T/R DISAGREEMENT CIRCUIT
78-436-01-2	N78-36-00-5A			OPERATIONAL	ENGINE 2 T/R DISAGREEMENT CIRCUIT
78-436-51-1	N78-34-00-C			FUNCTIONAL	ENG 1 THRUST REVERSER HEALTH CHECK
78-436-51-2	N78-34-00-C			FUNCTIONAL	ENG 2 THRUST REVERSER HEALTH CHECK
78-437-01-1	N78-31-11-6B			CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
78-437-01-2	N78-31-11-6B			CHECK/INSP	THRUST REVERSER AUX. TRACK LINER
78-501-01-1	D78-31-00-2A	78-501		CHECK/INSP	ENG 1 T/R SCREWJACK/BALLNUT HOUSING
78-501-01-2	D78-31-00-2A	78-501		CHECK/INSP	ENG 2 T/R SCREWJACK/BALLNUT HOUSING
78-502-01-1	D78-31-16-6A	78-502		OPERATIONAL	ENGINE 1 AIR MOTOR FEEDBACK CABLE
78-502-01-2	D78-31-16-6A	78-502		OPERATIONAL	ENGINE 2 AIR MOTOR FEEDBACK CABLE
78-503-01-1	D78-36-00-5A	78-503		OPERATIONAL	ENGINE 1 T/R DISAGREEMENT CIRCUIT
78-503-01-2	D78-36-00-5D	78-503		OPERATIONAL	ENGINE 2 T/R DISAGREEMENT CIRCUIT
78-514-C1-1	D78-30-00-A D78-30-00-B			OPERATIONAL	ENG 1 T/R G/BOX LOCK AND AIRMOTOR BK
78-514-C1-2	D78-30-00-A D78-30-00-B			OPERATIONAL	ENG 2 T/R G/BOX LOCK AND AIRMOTOR BK
78-516-C1-1	D78-36-00-5E D78-36-00-5C			OPERATIONAL	T/R AIR/GND RELAY AND RELAY MODULE
78-516-C1-2	D78-36-00-5F D78-36-00-5C			OPERATIONAL	T/R AIR/GND RELAY AND RELAY MODULE
78-523-01-1	D78-31-08-A			CHECK/INSP	ENGINE 1 T/R SCREWJACK BALLNUT HSNG
78-523-01-2	D78-31-08-A			CHECK/INSP	ENGINE 2 T/R SCREWJACK BALLNUT HSNG
79-104-01-1	P72-61-03-2A	79-104		REPLACE	MAIN OIL FILTER ELEMENT - ENG 1
79-104-01-2	P72-61-03-2A	79-104		REPLACE	MAIN OIL FILTER ELEMENT - ENG 2
79-111-01-1	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-111-01-2	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-111-02-1	12-13-01-3A			SERVICE	ENGINE OIL LEVEL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-100



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
79-111-02-2	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-112-01-1	P79-35-00-5A			FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM -L
79-112-01-2	P79-35-00-5A			FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM -R
79-113-C1-1	P79-21-03-2A P79-21-03-2B P79-21-03-2C P79-21-03-2D			CHECK/INSP	ENGINE MAGNETIC DRAIN PLUGS - ENG 1
79-113-C1-2	P79-21-03-2A P79-21-03-2B P79-21-03-2C P79-21-03-2D			CHECK/INSP	ENGINE MAGNETIC DRAIN PLUGS - ENG 2
79-114-01-1	P79-35-01-4A			DISCARD	ENG OIL FILTER DIFF PRESS SWITCH
79-114-01-2	P79-35-01-4A			DISCARD	ENG OIL FILTER DIFF PRESS SWITCH
79-201-01-1	G79-21-04-4A	79-201		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 1
79-201-01-2	G79-21-04-4A	79-201		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 2
79-208-01-1	G79-21-07-4A			REPLACE	LUBE FILTER ELEMENT - ENG 1
79-208-01-2	G79-21-07-4A			REPLACE	LUBE FILTER ELEMENT - ENG 2
79-209-01-1	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-209-01-2	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-209-02-1	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-209-02-2	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-210-01-1	G79-35-00-5A			FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM - L
79-210-01-2	G79-35-00-5A			FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM - R
79-301-01-1	H79-21-04-4A	79-301		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 1
79-301-01-2	H79-21-04-4A	79-301		REPLACE	OIL SCAVENGE FILTER ELEMENT - ENG 2
79-308-01-1	H79-21-07-4A			REPLACE	LUBE FILTER ELEMENT - ENG 1
79-308-01-2	H79-21-07-4A			REPLACE	LUBE FILTER ELEMENT - ENG 2
79-309-01-1	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-309-01-2	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-309-02-1	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-309-02-2	12-13-01-3A			SERVICE	ENGINE OIL LEVEL
79-310-01-1	H79-35-00-5A			FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM - L
79-310-01-2	H79-35-00-5A			FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM - R
79-401-01-1	N79-00-00-6A	79-401		CHECK/INSP	ENGINE 1 OIL SYSTEM TUBING
79-401-01-2	N79-00-00-6A	79-401		CHECK/INSP	ENGINE 2 OIL SYSTEM TUBING
79-402-01-1	N79-21-01-A	79-402		CHECK/INSP	ENGINE 1 FUEL/OIL COOLER

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
79-402-01-2	N79-21-01-A	79-402		CHECK/INSP	ENGINE 2 FUEL OIL COOLER
79-403-01-1	N79-21-05-4A			REPLACE	ENGINE 1 MAIN OIL FILTER ELEMENT
79-403-01-2	N79-21-05-4A			REPLACE	ENGINE 2 MAIN OIL FILTER ELEMENT
79-403-02-1	N79-21-05-4A			REPLACE	ENGINE 1 MAIN OIL FILTER ELEMENT
79-403-02-2	N79-21-05-4A			REPLACE	ENGINE 2 MAIN OIL FILTER ELEMENT
79-409-01-1	12-13-01-3A			SERVICE	ENGINE 1 OIL LEVEL
79-409-01-2	12-13-01-3A			SERVICE	ENGINE 2 OIL LEVEL
79-409-02-1	12-13-01-3A			SERVICE	ENGINE 1 OIL LEVEL
79-409-02-2	12-13-01-3A			SERVICE	ENGINE 2 OIL LEVEL
79-409-51-1	N79-35-00-5A	79-409		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM
79-409-51-2	N79-35-00-5A	79-409		FUNCTIONAL	OIL FILTER BYPASS WARNING SYSTEM
79-411-C1-1	N79-21-10-6A N79-21-10-6B N79-21-10-6C N79-21-10-6D N79-21-10-6E N79-21-10-6F			CHECK/INSP	ENGINE 1 MAGNETIC CHIP DETECTORS
79-411-C1-2	N79-21-10-6A N79-21-10-6B N79-21-10-6C N79-21-10-6D N79-21-10-6E N79-21-10-6F			CHECK/INSP	ENGINE 2 MAGNETIC CHIP DETECTORS
79-412-01-1	N79-35-01-4A			DISCARD	ENG OIL FILTER DIFF PRESS SWITCH
79-412-01-2	N79-35-01-4A			DISCARD	ENG OIL FILTER DIFF PRESS SWITCH
79-501-01-1	D79-00-00-6A	79-501		CHECK/INSP	ENGINE 1 MAGNETIC CHIP DETECTOR
79-501-01-2	D79-00-00-6A	79-501		CHECK/INSP	ENGINE 2 MAGNETIC CHIP DETECTOR
79-502-01-1	D79-21-07-4A	79-502		REPLACE	ENGINE 1 LUBRICATION PRESSURE FILTER
79-502-01-2	D79-21-07-4B	79-502		REPLACE	ENGINE 2 LUBRICATION PRESSURE FILTER
79-503-01-1	D79-21-08-4A	79-503		REPLACE	ENGINE 1 LUBRICATION SCAVENGE FILTER
79-503-01-2	D79-21-08-4B	79-503		REPLACE	ENGINE 2 LUBRICATION SCAVENGE FILTER
79-505-01-1	D79-21-05-6A	79-505		CHECK/INSP	ENG 1 CORE-MOUNTED LUBE COMPONENTS
79-505-01-2	D79-21-05-6A	79-505		CHECK/INSP	ENG 2 CORE-MOUNTED LUBE COMPONENTS
79-506-01-1	12-13-01-3A			SERVICE	ENGINE 1 OIL LEVEL
79-506-01-2	12-13-01-3A			SERVICE	ENGINE 2 OIL LEVEL
79-508-01-1	12-13-02-3A			CHECK/INSP	ENGINE 1 STARTER OIL

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
79-508-01-2	12-13-02-3A			CHECK/INSP	ENGINE 2 STARTER OIL
80-101-01-1	12-22-02-3A	80-101		REPLACE	STARTER OIL CHANGE
80-101-01-2	12-22-02-3A	80-101		REPLACE	STARTER OIL CHANGE
80-102-01-1	P80-11-01-6A	80-102		CHECK/INSP	STARTER CHIP DETECTOR - ENG 1
80-102-01-2	P80-11-01-6A	80-102		CHECK/INSP	STARTER CHIP DETECTOR - ENG 2
80-103-01-1	P80-11-04-2A	80-103		CLEAN	STARTER CONTROL VALVE FILTER - ENG 1
80-103-01-2	P80-11-04-2A	80-103		CLEAN	STARTER CONTROL VALVE FILTER - ENG 2
80-105-01-1	12-22-02-3A			REPLACE	ENGINE 1 STARTER
80-105-01-2	12-22-02-3A			REPLACE	ENGINE 2 STARTER
80-201-01-1	12-22-02-3B	80-201		REPLACE	ENGINE 1 STARTER OIL CHANGE
80-201-01-2	12-22-02-3B	80-201		REPLACE	ENGINE 2 STARTER OIL CHANGE
80-202-01-1	G80-11-01-6A	80-202		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 1
80-202-01-2	G80-11-01-6A	80-202		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 2
80-204-01-1	G80-11-04-2A			RESTORE	START VALVE FILTER - ENG 1
80-204-01-2	G80-11-04-2A			RESTORE	START VALVE FILTER - ENG 2
80-206-01-1	12-22-02-3B			REPLACE	ENGINE 1 STARTER OIL
80-206-01-2	12-22-02-3B			REPLACE	ENGINE 2 STARTER OIL
80-208-01-1	12-13-02-3A			CHECK/INSP	ENGINE 1 STARTER OIL
80-208-01-2	12-13-02-3A			CHECK/INSP	ENGINE 2 STARTER OIL
80-209-01-1	12-13-02-3A			CHECK/INSP	ENGINE 1 STARTER OIL
80-209-01-2	12-13-02-3A			CHECK/INSP	ENGINE 2 STARTER OIL
80-301-01-1	12-22-02-3C	80-301		REPLACE	ENGINE 1 STARTER OIL CHANGE
80-301-01-2	12-22-02-3C	80-301		REPLACE	ENGINE 2 STARTER OIL CHANGE
80-302-01-1	H80-11-01-6A	80-302		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 1
80-302-01-2	H80-11-01-6A	80-302		CHECK/INSP	STARTER MAGNETIC CHIP DETECTOR ENG 2
80-304-01-1	H80-11-04-2A			RESTORE	START VALVE FILTER - ENG 1
80-304-01-2	H80-11-04-2A			RESTORE	START VALVE FILTER - ENG 2
80-306-01-1	12-22-02-3C			REPLACE	ENGINE 1 STARTER OIL
80-306-01-2	12-22-02-3C			REPLACE	ENGINE 2 STARTER OIL
80-309-01-1	12-13-02-3A	80-309		CHECK/INSP	ENGINE 1 STARTER OIL
80-309-01-2	12-13-02-3A	80-309		CHECK/INSP	ENGINE 2 STARTER OIL
80-310-01-1	12-13-02-3A			CHECK/INSP	ENGINE 1 STARTER OIL
80-310-01-2	12-13-02-3A			CHECK/INSP	ENGINE 2 STARTER OIL
80-311-01-1	12-13-02-3A			CHECK/INSP	ENGINE 1 STARTER OIL
80-311-01-2	12-13-02-3A			CHECK/INSP	ENGINE 2 STARTER OIL

D622T001



767 MAINTENANCE PLANNING DATA

CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK	TASK	767 APPENDIX E.3 SORTED BY CARD - MPD - MRB
					TITLE
80-312-01-1	12-13-02-3A			CHECK/INSP	ENGINE 1 STARTER OIL
80-312-01-2	12-13-02-3A			CHECK/INSP	ENGINE 2 STARTER OIL
80-401-01-1	12-22-02-3A	80-401		REPLACE	ENGINE 1 STARTER OIL
80-401-01-2	12-22-02-3A	80-401		REPLACE	ENGINE 2 STARTER OIL
80-402-01-1	N80-11-01-6A	80-402		CHECK/INSP	ENG 1 STARTER MAGNETIC CHIP DETECTOR
80-402-01-2	N80-11-01-6A	80-402		CHECK/INSP	ENG 2 STARTER MAGNETIC CHIP DETECTOR
80-403-01-1	N80-11-04-2A			CLEAN	ENG 1 STARTER CONTROL VALVE FILTER
80-403-01-2	N80-11-04-2A			CLEAN	ENG 2 STARTER CONTROL VALVE FILTER
80-406-01-1	12-22-02-3A			REPLACE	ENGINE 1 STARTER
80-406-01-2	12-22-02-3A			REPLACE	ENGINE 2 STARTER
80-501-01-1	12-13-02-3A	80-501		SERVICE	ENGINE 1 STARTER OIL
80-501-01-2	12-13-02-3A	80-501		SERVICE	ENGINE 2 STARTER OIL
80-502-01-1	D80-11-01-6A	80-502		CHECK/INSP	ENGINE 1 STARTER CHIP DETECTOR
80-502-01-2	D80-11-01-6A	80-502		CHECK/INSP	ENGINE 2 STARTER CHIP DETECTOR
80-503-01-1	12-22-02-3A	80-503		REPLACE	ENGINE 1 STARTER OIL
80-503-01-2	12-22-02-3A	80-503		REPLACE	ENGINE 2 STARTER OIL

D622T001

AUG 2009

BOEING PROPRIETARY - Copyright (c) - Unpublished Work - See title page for details

Page E.3-104