

AIRBORNE AUXILIARY POWER-GENERAL

 BOEING
767
PARTS CATALOG (MAINTENANCE)

NON-ILLUSTRATED FIGURE

THE ITEMS REFLECTED IN THIS FIGURE ARE INTENTIONALLY
NON-ILLUSTRATED. THEY ARE REFERENCED TO EITHER A
NEXT HIGHER OR NEXT LOWER ASSEMBLY/INSTALLATION FIGURE.

V 48000101 SHT 1 REV 000

SYSTEM INSTL-AUX PWR
FIGURE 1

49-00-01-01

HXL
DEC 22/06

49-00-01-01
PAGE 0



767

PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1					
- 1	350T0000-1		SYSTEM INSTL-AUX PWR SYSTEM INSTL-AUX PWR VARIABLE DRAWING REF: 350T0900-618		1
- 5	351T0100-29		.AUX POWER UNIT INSTL-SYS VARIABLE DRAWING REF: 351T0100-5005 351T0100-5006 FOR DETAILS SEE: 49-11-00-01		1
- 10	352T0100-1		.SUPPORT INSTL- FOR DETAILS SEE: 49-13-01-01		1
- 15	353T0100-16		.PORT AND DOOR INSTL-AUX PWR SYS INTAKE		1
- 15	353T0100-5		.PORT AND DOOR INSTL-INTAKE VARIABLE DRAWING REF: 353T0100-5001 353T0100-5002 353T0100-5003 FOR DETAILS SEE: 49-15-05-01		1
- 20	353T0200-6		.DUCT INSTL-APU SYS INTAKE FOR DETAILS SEE: 49-15-01-01		1
- 20	353T0200-3		.DUCT INSTL-INTAKE FOR DETAILS SEE: 49-15-01-01		1
- 25	354T0100-2		.RING INSTL-SPRT FOR DETAILS SEE: 49-81-03-01		1
- 30	354T0200-1		.DUCT INSTL-EXH FOR DETAILS SEE: 49-81-01-01		1
- 35	355T1100-1		.PORT INSTL-COOLING AIR DISCH FOR DETAILS SEE: 49-51-51-01		1
- 40	355T3200-1		.DUCT INSTL-COMPRESSED AIR FOR DETAILS SEE: 49-52-51-01		1
- 45	355T4000-1		.HOSE INSTL-FUEL FOR DETAILS SEE: 28-25-52-01		1
- 50	355T5100-1		.DETECTOR INSTL-FIRE BASIC FOR DETAILS SEE: 26-15-02-01		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

- ITEM NOT ILLUSTRATED

49-00-01-01

HXL

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

49-00-01
FIG. 01
PAGE 1
DEC 22/07

BOEING
 767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1					
- 55	355T5300-1		.EXTINGUISHER INSTL-FIRE FOR DETAILS SEE: 26-22-51-01		1
- 60	356T0100-1		.MAST INSTL-DRAIN FOR DETAILS SEE: 49-16-01-01		1
- 65	356T0300-1		.DRAIN INSTL-PLENUM FOR DETAILS SEE: 49-16-03-01		1
- 80	351T0150-1		.OIL AND MARKER INSTL-APU FOR DETAILS SEE: 11-25-01-01	163999	1
- 80	351T0150-11		.OIL AND MARKER INSTL-APU FOR DETAILS SEE: 11-25-01-01	155162	1
- 95	351T0350-2		.ACCESSORY INSTL-AUX PWR SYS OIL QTY XMTR FOR DETAILS SEE: 49-94-00-01		1
- 100	351T0350-7		.ACCESSORY INSTL-AUX POWER SYS NO FUEL MANIFOLD DRAIN TANK FOR DETAILS SEE: 49-94-04-01		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

- ITEM NOT ILLUSTRATED

HXL

49-00-01-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

49-00-01
 FIG. 01
 PAGE 2
 DEC 22/08