

SECTION 45

 BOEING
767
PARTS CATALOG (MAINTENANCE)

NON-ILLUSTRATED FIGURE

THE ITEMS REFLECTED IN THIS FIGURE ARE INTENTIONALLY
NON-ILLUSTRATED. THEY ARE REFERENCED TO EITHER A
NEXT HIGHER OR NEXT LOWER ASSEMBLY/INSTALLATION FIGURE.

SECTION 45 ASSY
FIGURE 8

53-50-00-08

HXL
DEC 22/06

53-50-00-08
PAGE 0

BOEING
 767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
8			SECTION 45 ASSY		
- 1	145T0000-010		SECTION 45 ASSY- VARIABLE DRAWING REF: 145T0000-5011 145T0001-618 145T0001-5097 145T0001-5133 145T0001-5141 FOR NHA SEE: 53-00-00-08		RF
- 5	100T1481-80		.INTEGRATION INSTL-KEEL BEAM TO WING STUB AND PRESSURE DECK VARIABLE DRAWING REF: 100T1481-85 FOR DETAILS SEE: 53-52-01-02	163163	1
- 5	100T1481-88		.INTEGRATION INSTL-KEEL BEAM TO WING STUB AND PRESSURE DECK VARIABLE DRAWING REF: 100T1481-85 FOR DETAILS SEE: 53-52-01-02	155162 164999	1
- 10	140T2810-37		.HOSE INSTL-DRAIN FOR DETAILS SEE: 51-41-01-01		1
- 15	140T2813-3		.VALVE INSTL-DRAIN 767-200 AND 767-300 POSITION DATA: SECT. 45 FOR DETAILS SEE: 51-41-01-04		1
- 35	145T0086-1		.BULKHEAD INTEGRATION-WHL WELL POSITION DATA: AFT VARIABLE DRAWING REF: 145T0086-2 FOR DETAILS SEE: 53-53-56-01		1
- 40	145T2620-32		.LOBE ASSY-WHL WELL BHD POSITION DATA: LWR AFT VARIABLE DRAWING REF: 145T2620-5016 145T2620-7001 FOR DETAILS SEE: 53-53-56-05		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

- ITEM NOT ILLUSTRATED

HXL

53-50-00-08

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-00
 FIG. 08
 PAGE 1
 DEC 22/07

BOEING
 767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
8					
- 40	145T2620-33		.LOBE ASSY-WHL WELL BHD VARIABLE POSITION DATA: LWR AFT FOR DETAILS SEE: 53-53-56-05		1
- 45	140T0705-7		.STRUCTURE INTEGRATION- FAIRING SPRT UNDERWING POSITION DATA: LH SIDE VARIABLE DRAWING REF: 140T0705-5015 140T0705-7001 FOR DETAILS SEE: 53-51-61-01		1
- 50	140T0705-8		.STRUCTURE INTEGRATION- FAIRING SPRT. UNDERWING POSITION DATA: RH SIDE VARIABLE DRAWING REF: 140T0705-5016 140T0705-7002 FOR DETAILS SEE: 53-51-61-01		1
- 65	145T0010-37		.MONOCOQUE INTEGRATION- POSITION DATA: SECT. 45 VARIABLE DRAWING REF: 145T0010-5026 145T0010-7002 FOR DETAILS SEE: 53-00-59-05		1
- 150	145T0042-11		.WINDOW INTEGRATION-PASS. FOR DETAILS SEE: 56-21-01-12E		1
- 155	145T0050-37		.FLOOR SYSTEM INTEGRATION- VARIABLE DRAWING REF: 145T0050-5029		1
- 160	145T5201-33		..TRACK INSTL-SEAT FOR DETAILS SEE: 53-01-03-21		1
- 175	145T5700-15		..SUPPORT INSTL-LAV STRUCT POSITION DATA: SECT. 45 FOR DETAILS SEE: 25-41-03-17A		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

- ITEM NOT ILLUSTRATED

HXL

53-50-00-08

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-00
 FIG. 08
 PAGE 2
 APR 22/09

BOEING
 767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7 NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
8				
- 180	145T5701-9	..SUPPORT INSTL-LAV POSITION DATA: SECT. 45 FOR DETAILS SEE: 53-51-54-05		1
- 185	145T5701-10	..SUPPORT INSTL-LAV POSITION DATA: SECT. 45 FOR DETAILS SEE: 53-51-54-05		1
- 205	145T0100-28	.PANEL ASSY-CROWN POSITION DATA: STA 785.9 TO STA 1065 VARIABLE DRAWING REF: 145T0100-5066 145T0100-7003 FOR DETAILS SEE: 53-55-53-02		1
- 210	145T0300-21	.PANEL ASSY- POSITION DATA: S-8L TO WING STA 785.9 TO STA 1065 L VARIABLE DRAWING REF: 145T0300-5060 145T0300-7005 FOR DETAILS SEE: 53-55-52-01		1
- 215	145T0400-21	.PANEL ASSY- POSITION DATA: S-8R TO WING STA 785.9 TO STA 1065 R VARIABLE DRAWING REF: 145T0400-5060 145T0400-7005 FOR DETAILS SEE: 53-55-51-01		1
- 230	145T5200-47	.TRACK INSTL-SEAT PRESSURE DECK POSITION DATA: SECT. 45 BL 11.00 BL 33.00 AND BL 54.75 FOR DETAILS SEE: 53-01-03-20	163163	1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE				

— ITEM NOT ILLUSTRATED

HXL

53-50-00-08

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-00
 FIG. 08
 PAGE 3
 DEC 22/07

BOEING
 767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7 NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
8				
- 230	145T5200-69	.TRACK INSTL-SEAT PRESSURE DECK POSITION DATA: SECT. 45 BL 11.00 BL 33.00 AND BL 54.75 FOR DETAILS SEE: 53-01-03-20	155162	1
- 230	145T5200-81	.TRACK INSTL-SEAT PRESSURE DECK POSITION DATA: SECT. 45 BL 11.00 BL 33.00 AND BL 54.75 FOR DETAILS SEE: 53-01-03-20	164999	1
- 240	145T5223-2	.TRACK INSTL-SEAT POSITION DATA: BS 20.00 STA 782.50 TO STA 1070.45 FOR DETAILS SEE: 53-01-03-23		1
- 260	145T5831-2	.PANEL INSTL-FLOOR SAS POSITION DATA: SECT. 45 VARIABLE DRAWING REF: 145T5831-5003 FOR DETAILS SEE: 53-01-02-43	155163	1
- 260	145T5831-4	.PANEL INSTL-FLOOR SAS POSITION DATA: SECT. 45 VARIABLE DRAWING REF: 145T5831-5005 FOR DETAILS SEE: 53-01-02-43	164999	1
- 265	145T6000-5	.HATCH INSTL-ESCAPE HATCH OVERWING FOR DETAILS SEE: 52-21-01-01		1
- 270	145T6000-6	.HATCH INSTL-ESCAPE HATCH OVERWING FOR DETAILS SEE: 52-21-01-01		1
- 275	145T6000-7	.HATCH INSTL-ESCAPE HATCH OVERWING VARIABLE DRAWING REF: 145T6000-5015 FOR DETAILS SEE: 52-21-01-01		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE				

— ITEM NOT ILLUSTRATED

HXL

53-50-00-08

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-00
 FIG. 08
 PAGE 4
 DEC 22/07

BOEING
 767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
8					
- 280	145T6000-8		.HATCH INSTL-ESCAPE HATCH OVERWING VARIABLE DRAWING REF: 145T6000-5016 FOR DETAILS SEE: 52-21-01-01		1
- 285	145T6080-5		.STEP INSTL-ESCAPE HATCH OVERWING POSITION DATA: LH FOR DETAILS SEE: 52-21-01-02		1
- 290	145T6080-6		.STEP INSTL-ESCAPE HATCH OVERWING POSITION DATA: RH FOR DETAILS SEE: 52-21-01-02		1
- 295	149T7200-11		.STRUCTURE ASSY-FAIRING SPRT UNDERWING POSITION DATA: LH VARIABLE DRAWING REF: 149T7200-5082 149T7200-7001 FOR DETAILS SEE: 53-36-56-01		1
- 300	149T7200-12		.STRUCTURE ASSY-FAIRING SPRT UNDERWING POSITION DATA: RH VARIABLE DRAWING REF: 149T7200-5056 149T7200-7002 FOR DETAILS SEE: 53-36-56-01		1
- 315	140T6001-1		.FAIRING INTEGRATION- POSITION DATA: OVERWING LH REWORK DRAWING REF: 140T6001-5 FOR DETAILS SEE: 53-52-01-01		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

— ITEM NOT ILLUSTRATED

HXL

53-50-00-08

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-00
 FIG. 08
 PAGE 5
 DEC 22/07




767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
8 - 320	140T6001-2		. FAIRING INTEGRATION- POSITION DATA: OVERWING RH REWORK DRAWING REF: 140T6001-6 FOR DETAILS SEE: 53-52-01-01		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					



- ITEM NOT ILLUSTRATED

HXL



53-50-51-01

BOEING
767
PARTS CATALOG (MAINTENANCE)



V 53505101 SHT 2 REV 202

DECK INSTL-PRESSURE
FIGURE 1 (SHEET 2)

53-50-51-01

HXL
DEC 22/06

53-50-51-01
PAGE 0A



767

PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1			DECK INSTL-PRESSURE		
- 1	145T8750-77		DECK INSTL-PRESSURE VARIABLE DRAWING REF: 145T8750-147 145T8750-5026 145T8750-5035 FOR NHA SEE: 53-52-01-02		RF
5	145T8750-141		.DECK ASSY- POSITION DATA: LH		1
6	145T8750-145		.DECK ASSY-VARIABLE POSITION DATA: LH		1
- 10	145T8750-142		.DECK ASSY- POSITION DATA: RH		1
- 11	145T8750-146		.DECK ASSY-VARIABLE POSITION DATA: RH		1
27	NAS6703-14		..BOLT-		1
28	AN960C10L		..WASHER-		2
29	BRH10C3		..NUT- SUPPLIER CODE: V52828 SPECIFICATION NUMBER: BACN10JC3C OPTIONAL PART: T6C1032J V11815 97-02 V80539 101LH9075-3W V72962 VN303B02 V92215 NS202101S02 V80539 H31-3BAC V15653		1
30	BACB28AK03-090		..BUSHING-		1
31	145T8788-12		..BRACKET ASSY- POSITION DATA: RH SIDE		1
32	145T8788-11		..BRACKET ASSY- POSITION DATA: LH SIDE		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

- ITEM NOT ILLUSTRATED

HXL

53-50-51-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-51
FIG. 01
PAGE 1
DEC 22/07



767

PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1					
33	HL1012AZ6-6		ATTACHING PARTS ..BOLT SUPPLIER CODE: V97928 SPECIFICATION NUMBER: BACB30NX6K6 OPTIONAL PART: HL12VAZ6-6 V73197 HL12VAZ6-6 V92215 HL12VAZ6-6 V97928 L802-6K6 V06725 HL12VAZ6-6 V56878 HL1012AZ6-6 V0PTK6 HL1012AZ6-6 V06725 HL1012AZ6-6 V06950 HL1012AZ6-6 V17446 HL1012AZ6-6 V56878 HL1012AZ6-6 V60516 HL1012AZ6-6 V73197		4
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

— ITEM NOT ILLUSTRATED

HXL

53-50-51-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-51
FIG. 01
PAGE 2
DEC 22/07

BOEING
 767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1					
34	HL1187-6		..COLLAR SUPPLIER CODE: V5M902 SPECIFICATION NUMBER: BACC30X6 OPTIONAL PART: HL87-6 V92215 HL87-6 V73197 HL1187-6 V56878 HL1187-6 V92215 HL87-6 V56878 HL1187-6 V73197 -----*-----		4
35	BACB28AM06B014A		...BUSHING-		1
40	BACB28AP04P014		...BUSHING-		1
42	BACB28W5B014		...BUSHING-		2
46	145T8788-10		...BRACKET- POSITION DATA: RH SIDE USED ON: 145T8788-12		1
51	145T8788-9		...BRACKET- POSITION DATA: LH SIDE USED ON: 145T8788-11		1
60	145T8710-25		..INTERCOSTAL INSTL- POSITION DATA: LH SIDE		1
- 65	145T8710-28		..INTERCOSTAL INSTL- POSITION DATA: RH SIDE		1
81	BACG20ZD1275		...GROMMET-		2
85	145T8711-23		..INTERCOSTAL INSTL- POSITION DATA: LH SIDE		1
- 90	145T8711-24		..INTERCOSTAL INSTL- POSITION DATA: RH SIDE		1
108	BACG20ZD1275		...GROMMET-		2
110	145T8712-19		..INTERCOSTAL INSTL- POSITION DATA: LH SIDE		1
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

- ITEM NOT ILLUSTRATED

HXL

53-50-51-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-51
 FIG. 01
 PAGE 3
 DEC 22/07

BOEING
 767
PARTS CATALOG (MAINTENANCE)

FIG ITEM	PART NUMBER	1 2 3 4 5 6 7	NOMENCLATURE	EFFECT FROM TO	UNITS PER ASSY
1					
- 115	145T8712-20		..INTERCOSTAL INSTL- POSITION DATA: RH SIDE		1
132	BACG20ZC1275		...GROMMET		2
135	284T0546-3		..SUPPORT INSTL-MAIN WHL WELL POSITION DATA: LH SIDE VARIABLE DRAWING REF: 284T0546-5009 FOR DETAILS SEE: 53-51-52-01		1
- 140	284T0546-4		..SUPPORT INSTL-MAIN WHL WELL POSITION DATA: RH SIDE VARIABLE DRAWING REF: 284T0546-5010 FOR DETAILS SEE: 53-51-52-01		1
170	145T8720-45		.TRANSBEAM ASSY-VARIABLE		1
172	BACG20ZE0795		..GROMMET-		2
177	BACG20ZD0870		..GROMMET-		2
179	NAS1368N16A		..GROMMET		2
181	NAS1368N16B		..GROMMET		2
185	145T8721-53		.TRANSBEAM ASSY-		1
185	145T8721-55		.TRANSBEAM ASSY-VARIABLE		1
210	NAS1368N16B		..GROMMET		4
212	BACG20ZD790		..GROMMET-		1
214	BACG20ZF790		..GROMMET-		1
216	BACG20ZF800		..GROMMET-		1
217	BACG20ZE0385		..GROMMET		2
219	BACG20ZE0790		..GROMMET		3
220	145T8722-52		.TRANSBEAM ASSY-		1
220	145T8722-54		.TRANSBEAM ASSY-VARIABLE		1
230	BACG20ZE0770		..GROMMET-		2
232	BACG20ZE0780		..GROMMET-		2
240	NAS1368N16A		..GROMMET		4
245	NAS1368N16C		..GROMMET		2
ILLUSTRATION ITEMS NOT ON PARTS LIST ARE NOT APPLICABLE					

- ITEM NOT ILLUSTRATED

HXL

53-50-51-01

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

53-50-51
 FIG. 01
 PAGE 4
 AUG 22/09