

EQUIPMENT LIST



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			AP0900	1	Jan 21/2005	B00300 cont.		
	1 thru 23	Aug 05/2009	AP1000	1	Mar 09/2006		2	Jan 21/2005
	24	BLANK	AP1100	1	Jan 21/2005	B00400	1	Jan 21/2005
AC0500	1	Jan 21/2005	AP1400	1	Jan 21/2005		2	Mar 09/2006
AC0600	1	Jan 21/2005	AP1500	1	Jan 21/2005		3	Mar 09/2006
AC0700	1	Jan 21/2005	AV1800	1	Jan 21/2005	B09000	1	Jan 21/2005
AC1100	1	Mar 09/2006	AW0300	1	Jan 21/2005	C00000	1	Jan 21/2005
AC1200	1	Jan 21/2005	AW0400	1	Jan 21/2005		2	Jan 21/2005
AC1300	1	Jan 21/2005	AW0600	1	Jan 21/2005		3	Jan 21/2005
AC1400	1	Jan 21/2005	AW0900	1	Jan 21/2005		4	Jan 21/2005
AC1500	1	Jan 21/2005	B00000	1	Jan 21/2005	C00100	1	Jan 21/2005
AE0100	1	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
AE0200	1	Jan 21/2005		3	Jan 21/2005	C00300	1	Jan 21/2005
	2	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
AE0300	1	Jan 21/2005		5	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005		6	Jan 21/2005		4	Jan 21/2005
AF0100	1	Jan 21/2005		7	Jan 21/2005	R C00400	1	Aug 05/2009
AF0200	1	Mar 09/2006	B00100	1	Jan 21/2005		2	Jan 21/2005
AL0200	1	Jan 21/2005		2	Jan 21/2005	C00500	1	Jan 21/2005
AL0900	1	Jan 21/2005		3	Mar 09/2006		2	Jan 21/2005
AL1000	1	Jan 21/2005		4	Jan 21/2005		3	Jan 21/2005
AP0000	1	Jan 21/2005		5	Jan 21/2005		4	Jan 21/2005
AP0200	1	Jan 21/2005		6	Jan 21/2005		5	Jan 21/2005
AP0300	1	Jan 21/2005	B00200	1	Jan 21/2005		6	Jan 21/2005
AP0400	1	Jan 21/2005		2	Jan 21/2005	C00600	1	Jan 21/2005
AP0600	1	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
AP0700	1	Jan 21/2005		4	Jan 21/2005		3	Jan 21/2005
AP0800	1	Jan 21/2005	B00300	1	Jan 21/2005		4	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 1
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
C00600 cont.	5	Jan 21/2005	C01200 cont.	4	Jan 21/2005	D00000 cont.	6	Jan 21/2005
	6	Jan 21/2005		5	Jan 21/2005	D00100	1	Jan 21/2005
C00700	1	Jan 21/2005	C01300	1	Jan 21/2005		2	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005		3	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005		4	Jan 21/2005
	4	Jan 21/2005		4	Jan 21/2005		5	Jan 21/2005
C00800	1	Jan 21/2005	C01400	1	Mar 09/2006		6	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005	D00200	1	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
	4	Jan 21/2005		4	Jan 21/2005		3	Jun 06/2008
	5	Jan 21/2005	C01500	1	Jan 21/2005		4	Jun 06/2008
R C00900	1	Aug 05/2009		2	Jan 21/2005		5	Jun 06/2008
	2	Feb 06/2009	C01700	1	Jan 21/2005		6	Jun 06/2008
C01000	1	Jan 21/2005	C04000	1	Jan 21/2005	D00300	1	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005	C04100	1	Jan 21/2005		3	Jan 21/2005
	4	Jan 21/2005	C04200	1	Jan 21/2005		4	Jan 21/2005
	5	Jan 21/2005		2	Jan 21/2005		5	Jan 21/2005
C01100	1	Jan 21/2005	C04400	1	Jan 21/2005		6	Jan 21/2005
	2	Jan 21/2005	C07000	1	Jan 21/2005		7	Jan 21/2005
	3	Jan 21/2005	R C09000	1	Aug 05/2009		8	Jan 21/2005
	4	Jan 21/2005	R	2	Aug 05/2009		9	Jan 21/2005
	5	Aug 15/2007	D00000	1	Mar 14/2007	D00400	1	Jan 21/2005
	6	May 20/2005		2	Jan 21/2005		2	Jan 21/2005
C01200	1	Jan 21/2005		3	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005		4	Jan 21/2005		4	Jan 21/2005
	3	Jan 21/2005		5	Jan 21/2005		5	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 2
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D00400 cont.			D00800 cont.			D01200 cont.		
	6	Jan 21/2005		3	Jan 21/2005		6	Jan 21/2005
	7	Jan 21/2005		4	Jan 21/2005		7	Jan 21/2005
	8	Jan 21/2005		5	Jan 21/2005		8	Jan 21/2005
	9	Jan 21/2005		6	Jan 21/2005			
	10	Jan 21/2005		7	Jan 21/2005	D01300	1	Jan 21/2005
	11	Jan 21/2005		8	Jan 21/2005		2	May 20/2005
	12	Jan 21/2005		9	Jan 21/2005		3	May 20/2005
D00500	1	Jan 21/2005	D00900	1	Jan 21/2005		4	May 20/2005
	2	Jan 21/2005		2	Jan 21/2005	D01400	1	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
	4	Jan 21/2005		4	Jan 21/2005		3	Jan 21/2005
	5	Jan 21/2005	D01000	1	Jan 21/2005		4	Jan 21/2005
	6	Jan 21/2005		2	Jan 21/2005		5	Jan 21/2005
D00600	1	Jan 21/2005		3	Jan 21/2005		6	Jan 21/2005
	2	Jan 21/2005		4	Jan 21/2005	D01500	1	Jan 21/2005
	3	Jan 21/2005		5	Jan 21/2005		2	Jan 21/2005
	4	Jan 21/2005	D01100	1	Jan 21/2005		3	Jan 21/2005
	5	Jan 21/2005		2	Jan 21/2005		4	Jan 21/2005
	6	Jan 21/2005		3	Jan 21/2005		5	Jan 21/2005
	7	Jan 21/2005		4	Jan 21/2005		6	Jan 21/2005
	8	Jan 21/2005		5	Jan 21/2005		7	Jan 21/2005
D00700	1	Jan 21/2005		6	Jan 21/2005		8	Jan 21/2005
	2	Jan 21/2005	D01200	1	Jan 21/2005		9	Jan 21/2005
	3	Jan 21/2005		2	Jan 21/2005		10	Jan 21/2005
	4	Jan 21/2005		3	Jan 21/2005	D01600	1	Jan 21/2005
D00800	1	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
	2	Jan 21/2005		5	Jan 21/2005		3	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 3
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D01600 cont.			D02100 cont.			D02400 cont.		
	4	Jan 21/2005		2	Jan 21/2005		3	Jan 21/2005
	5	Jan 21/2005		3	Jan 21/2005		4	Jan 21/2005
D01700	1	Jan 21/2005		4	Jan 21/2005		5	Jan 21/2005
	2	Jan 21/2005		5	Jan 21/2005		6	Jan 21/2005
	3	Jan 21/2005		6	Jan 21/2005		7	Jan 21/2005
	4	Jan 21/2005		7	Jan 21/2005		8	Jan 21/2005
D01800	1	Jan 21/2005	D02200	1	Jan 21/2005	D02500	1	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005		3	Jan 21/2005
	4	Jan 21/2005		4	Jan 21/2005		4	Jan 21/2005
	5	Jan 21/2005		5	Jan 21/2005		5	Jan 21/2005
D01900	1	Jan 21/2005		6	Jan 21/2005	D02600	1	Jan 21/2005
	2	Jan 21/2005		7	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005		8	Jan 21/2005		3	Jan 21/2005
	4	Jan 21/2005	D02300	1	Jan 21/2005		4	Jan 21/2005
	5	Jan 21/2005		2	Jan 21/2005		5	Jan 21/2005
	6	Jan 21/2005		3	Jan 21/2005		6	Jan 21/2005
	7	Jan 21/2005		4	Jan 21/2005		7	Jan 21/2005
	8	Jan 21/2005		5	Jan 21/2005		8	Jan 21/2005
D02000	1	Jan 21/2005		6	Jan 21/2005	D02700	1	Jan 21/2005
	2	Jan 21/2005		7	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005		8	Jan 21/2005		3	Jan 21/2005
	4	Jan 21/2005		9	Jan 21/2005		4	Jan 21/2005
	5	Jan 21/2005		10	Jan 21/2005		5	Jan 21/2005
	6	Jan 21/2005		11	Jan 21/2005	D02800	1	Jan 21/2005
	7	Jan 21/2005	D02400	1	Jan 21/2005		2	Jan 21/2005
D02100	1	Jan 21/2005		2	Jan 21/2005		3	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 4
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D02800 cont.			D03300 cont.			D04000 cont.		
	4	Jan 21/2005		2	Jan 21/2005		4	Aug 15/2007
	5	Jan 21/2005		3	Jan 21/2005		5	Aug 15/2007
	6	Jan 21/2005		4	Jan 21/2005		6	Aug 15/2007
D02900	1	Jan 21/2005		5	Jan 21/2005		7	Jun 06/2008
	2	Jan 21/2005		6	Jan 21/2005		8	Jun 06/2008
	3	Jan 21/2005		7	Jan 21/2005		9	Jun 06/2008
	4	Jan 21/2005		8	Jan 21/2005		10	Jun 06/2008
	5	Jan 21/2005	D03400	1	Jan 21/2005		11	Jun 06/2008
	6	Jan 21/2005		2	Jan 21/2005	D04100	1	Jan 21/2005
D03000	1	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
	2	Jan 21/2005		4	Jan 21/2005		3	Jan 21/2005
	3	Jan 21/2005	D03500	1	Jan 21/2005		4	Jan 21/2005
	4	Jan 21/2005		2	Jan 21/2005		5	Jan 21/2005
D03100	1	Jan 21/2005		3	Jan 21/2005		6	Jan 21/2005
	2	Jan 21/2005	D03600	1	Jan 21/2005		7	Jan 21/2005
	3	May 20/2005		2	Jan 21/2005		8	Jan 21/2005
	4	May 20/2005		3	May 20/2005	D04200	1	Jan 21/2005
	5	May 20/2005	D03700	1	Jan 21/2005		2	Jan 21/2005
	6	May 20/2005		2	Jan 21/2005		3	Jan 21/2005
D03200	1	Jan 21/2005	D03800	1	Jan 21/2005		4	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005		5	Jan 21/2005
	3	Jan 21/2005	D03900	1	Jan 21/2005		6	Jan 21/2005
	4	Jan 21/2005		2	Jan 21/2005		7	Jan 21/2005
	5	Jan 21/2005		3	Jan 21/2005		8	Jan 21/2005
	6	Jan 21/2005	D04000	1	Jan 21/2005		9	Jan 21/2005
	7	Jan 21/2005		2	Aug 15/2007		10	Jan 21/2005
D03300	1	Jan 21/2005		3	Aug 15/2007		11	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 5
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D04200 cont.			D04600	1	Jan 21/2005	D04900 cont.		
	12	Jan 21/2005		2	Jan 21/2005		5	Jan 21/2005
	13	Jan 21/2005		3	Jan 21/2005		6	Jan 21/2005
D04300	1	Jan 21/2005		4	Jan 21/2005		7	Jan 21/2005
	2	Jan 21/2005		5	Jan 21/2005		8	Jan 21/2005
	3	Jan 21/2005		6	Jan 21/2005		9	Jan 21/2005
	4	Jan 21/2005		7	Jan 21/2005	D05000	1	Jan 21/2005
	5	Jan 21/2005		8	Jan 21/2005		2	Jan 21/2005
	6	Jan 21/2005		9	Mar 09/2006		3	Jan 21/2005
	7	Jan 21/2005	D04700	1	Mar 09/2006		4	Mar 09/2006
	8	Jan 21/2005		2	Jan 21/2005		5	Mar 09/2006
	9	Jan 21/2005		3	Jan 21/2005		6	Mar 09/2006
D04400	1	Jan 21/2005		4	Jan 21/2005		7	Mar 09/2006
	2	Jan 21/2005		5	Jan 21/2005		8	Mar 09/2006
	3	Jan 21/2005		6	Jan 21/2005		9	Mar 09/2006
	4	Jan 21/2005		7	Jan 21/2005		10	Mar 09/2006
	5	Jan 21/2005		8	Jan 21/2005		11	Mar 09/2006
	6	Jan 21/2005		9	Jan 21/2005	D05100	1	Jan 21/2005
	7	Jan 21/2005	D04800	1	Jan 21/2005		2	Jan 21/2005
	8	Jan 21/2005		2	Jan 21/2005		3	Jan 21/2005
D04500	1	Jan 21/2005		3	Mar 14/2007		4	Jan 21/2005
	2	Jan 21/2005		4	Jan 21/2005		5	Jan 21/2005
	3	Jan 21/2005		5	Jan 21/2005		6	Jan 21/2005
	4	Jan 21/2005		6	Jan 21/2005		7	Jan 21/2005
	5	Jan 21/2005	D04900	1	Jan 21/2005		8	Jan 21/2005
	6	Jan 21/2005		2	Jan 21/2005		9	Mar 09/2006
	7	Jan 21/2005		3	Jan 21/2005		10	Mar 09/2006
	8	Jan 21/2005		4	Jan 21/2005		11	Mar 09/2006

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 6
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date		
D05200	1	Jan 21/2005	D05500 cont.	3	Jan 21/2005	D05900 cont.	3	Jan 21/2005		
	2	Jan 21/2005		4	Jan 21/2005		4	Jan 21/2005		
	3	Jan 21/2005		5	Jan 21/2005		5	Jan 21/2005		
	4	Jan 21/2005		6	Jan 21/2005		6	Jan 21/2005		
	5	Jan 21/2005		7	Jan 21/2005		7	Jan 21/2005		
	6	Jan 21/2005		8	Jan 21/2005		D06000	1	Jan 21/2005	
	7	Jan 21/2005		D05600	1			Jan 21/2005	2	Jan 21/2005
	8	Jan 21/2005			2			Jan 21/2005	3	Jan 21/2005
	D05300	1	Jan 21/2005	3	Jan 21/2005		4	Jan 21/2005		
2		Jan 21/2005	4	Mar 09/2006	5	Jan 21/2005				
3		Jan 21/2005	5	Mar 09/2006	6	Jan 21/2005				
4		Jan 21/2005	6	Mar 09/2006	7	Jan 21/2005				
5		Jan 21/2005	7	Mar 09/2006	8	Jan 21/2005				
6		Jan 21/2005	D05700	1	Jan 21/2005	9	Jan 21/2005			
7		Jan 21/2005		2	Jan 21/2005	D06100	1	Jan 21/2005		
8		Jan 21/2005	3	Jan 21/2005	2		Jan 21/2005			
D05400	1	Jan 21/2005	4	Jan 21/2005	3		Jan 21/2005			
	2	Jan 21/2005	5	Jan 21/2005	4	Jan 21/2005				
	3	Jan 21/2005	6	Jan 21/2005	5	Jan 21/2005				
	4	Jan 21/2005	D05800	1	Jan 21/2005	6	Jan 21/2005			
	5	Jan 21/2005		2	Jan 21/2005	7	Jan 21/2005			
	6	Jan 21/2005	3	Jan 21/2005	8	Jan 21/2005				
	7	Jan 21/2005	4	Jan 21/2005	9	Jan 21/2005				
	8	Jan 21/2005	5	Jan 21/2005	10	Jan 21/2005				
	9	Jan 21/2005	6	Jan 21/2005	11	Jan 21/2005				
D05500	1	Jan 21/2005	D05900	1	Jan 21/2005	D06200	1	Jan 21/2005		
	2	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005		

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 7
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D06200 cont.			D06700 cont.			D08200	1	Jan 21/2005
	3	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	4	Jan 21/2005	D06800	1	Jan 21/2005	D08300	1	Jan 21/2005
	5	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	6	Jan 21/2005		3	Jan 21/2005		3	Jan 21/2005
	7	Jan 21/2005		4	Jan 21/2005		4	Jan 21/2005
	8	Jan 21/2005		5	Jan 21/2005	D08500	1	Jan 21/2005
	9	Jan 21/2005	D06900	1	Jan 21/2005	D08600	1	Jan 21/2005
	10	Jan 21/2005		2	Jan 21/2005	D08700	1	Jan 21/2005
	11	Jan 21/2005		3	Jan 21/2005	D09000	1	Jan 21/2005
	12	Jan 21/2005	D07000	1	Jan 21/2005		2	Mar 09/2006
	13	Jan 21/2005	D07100	1	Jan 21/2005		3	Jan 21/2005
D06300	1	Jan 21/2005		2	Jan 21/2005		4	Jan 21/2005
	2	Jan 21/2005	D07500	1	Jan 21/2005		5	Jan 21/2005
	3	Jan 21/2005	D07900	1	Jan 21/2005		6	Jan 21/2005
	4	Jan 21/2005		2	Jan 21/2005	D09100	1	Jan 21/2005
	5	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
D06400	1	Jan 21/2005	D08000	1	Jan 21/2005	D09200	1	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005	D09300	1	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005	D10000	1	Jan 21/2005
	4	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
D06500	1	Jan 21/2005		5	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005	D08100	1	Jan 21/2005	D10100	1	Jan 21/2005
D06600	1	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	2	Jan 21/2005		3	Jan 21/2005		3	Jan 21/2005
	3	Jan 21/2005		4	Jan 21/2005		4	Jan 21/2005
	4	Jan 21/2005		5	Jan 21/2005	D10200	1	Jan 21/2005
D06700	1	Jan 21/2005		6	Jan 21/2005		2	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 8
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D10300	1	Jan 21/2005	D11500	1	Jan 21/2005	D13300 cont.		
	2	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
D10400	1	Jan 21/2005	D11600	1	Feb 06/2009		3	Jan 21/2005
	2	Jan 21/2005		2	Feb 06/2009		4	Jan 21/2005
D10500	1	Jan 21/2005		3	Feb 06/2009	D13400	1	Jan 21/2005
	2	Jan 21/2005	D11700	1	Jan 21/2005		2	Jan 21/2005
D10600	1	Jan 21/2005		2	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005		3	Jan 21/2005		4	Jan 21/2005
	3	Jan 21/2005	D11800	1	Jan 21/2005		5	Jan 21/2005
D10700	1	Jan 21/2005		2	Jan 21/2005		6	Jan 21/2005
	2	Jan 21/2005		3	Jan 21/2005	D13500	1	Jan 21/2005
	3	Jan 21/2005	D11900	1	Jan 21/2005		2	Jan 21/2005
D10800	1	Jan 21/2005	D12000	1	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005		4	Jan 21/2005
D10900	1	Jan 21/2005	D12100	1	Jan 21/2005	D13600	1	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005	D13700	1	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005	D13800	1	Jan 21/2005
D11000	1	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
D11100	1	Jan 21/2005	D12200	1	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005	D13900	1	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
	4	Jan 21/2005	D12300	1	Jan 21/2005		3	Jan 21/2005
D11200	1	Jan 21/2005	D13000	1	Jan 21/2005	D15800	1	Jan 21/2005
	2	Jan 21/2005	D13100	1	Jan 21/2005	D17000	1	Jan 21/2005
	3	Jan 21/2005	D13200	1	Jan 21/2005	D20000	1	Jan 21/2005
	4	Jan 21/2005		2	Jan 21/2005	D20100	1	Jan 21/2005
D11300	1	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
D11400	1	Jan 21/2005	D13300	1	Jan 21/2005	D20500	1	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 9
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
D21100	1	Jan 21/2005	K00000	1	Feb 06/2009	K00600 cont.		
D21200	1	Jan 21/2005		2	Feb 06/2009		2	Feb 06/2009
D23100	1	Mar 09/2006		3	Feb 06/2009		3	Feb 06/2009
D30000	1	Jan 21/2005		4	Feb 06/2009	K00700	1	Feb 06/2009
D31100	1	Feb 06/2009		5	Feb 06/2009		2	Feb 06/2009
D72000	1	Feb 06/2009	K00100	1	Feb 06/2009		3	Feb 06/2009
D90000	1	Feb 06/2009		2	Feb 06/2009		4	Feb 06/2009
	2	Feb 06/2009		3	Feb 06/2009	K00800	1	Feb 06/2009
	3	Feb 06/2009		4	Feb 06/2009		2	Feb 06/2009
	4	Feb 06/2009		5	Feb 06/2009		3	Feb 06/2009
	5	Feb 06/2009	K00200	1	Feb 06/2009		4	Feb 06/2009
	6	Feb 06/2009		2	Feb 06/2009		5	Feb 06/2009
	7	Feb 06/2009		3	Feb 06/2009	K00900	1	Feb 06/2009
	8	Feb 06/2009		4	Feb 06/2009		2	Feb 06/2009
D96100	1	Feb 06/2009		5	Feb 06/2009		3	Feb 06/2009
E001	1	Feb 06/2009	K00300	1	Feb 06/2009	K01000	1	Feb 06/2009
E002	1	Feb 06/2009		2	Feb 06/2009		2	Feb 06/2009
E003	1	Feb 06/2009		3	Feb 06/2009	K01100	1	Feb 06/2009
E005	1	Feb 06/2009		4	Feb 06/2009		2	Feb 06/2009
E006	1	Feb 06/2009	K00400	1	Feb 06/2009	K01200	1	Feb 06/2009
E007	1	Feb 06/2009		2	Feb 06/2009		2	Feb 06/2009
E008	1	Feb 06/2009		3	Feb 06/2009		3	Feb 06/2009
E009	1	Feb 06/2009	K00500	1	Feb 06/2009		4	Feb 06/2009
E010	1	Feb 06/2009		2	Feb 06/2009	K01300	1	Feb 06/2009
E011	1	Feb 06/2009		3	Feb 06/2009	K02000	1	Feb 06/2009
E090	1	Feb 06/2009		4	Feb 06/2009		2	Feb 06/2009
G00000	1	Feb 06/2009		5	Feb 06/2009		3	Feb 06/2009
J00000	1	Feb 06/2009	K00600	1	Feb 06/2009	K02100	1	Feb 06/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 10
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
K02100 cont.			L00100 cont.			L00200 cont.		
	2	Feb 06/2009		8	Jan 21/2005		22	Jan 21/2005
	3	Feb 06/2009		9	Jan 21/2005	L00300	1	Jan 21/2005
	4	Feb 06/2009		10	Jan 21/2005		2	Jan 21/2005
	5	Feb 06/2009		11	Jan 21/2005		3	Mar 09/2006
	6	Feb 06/2009		12	Jan 21/2005		4	Jan 21/2005
	7	Feb 06/2009		13	Jan 21/2005		5	Jan 21/2005
K02200	1	Feb 06/2009	L00200	1	Jan 21/2005		6	Jan 21/2005
K02300	1	Feb 06/2009		2	Jan 21/2005		7	Mar 09/2006
K09000	1	Feb 06/2009		3	Jan 21/2005		8	Mar 09/2006
K10100	1	Feb 06/2009		4	Jan 21/2005		9	Jan 21/2005
K10200	1	Feb 06/2009		5	Jan 21/2005		10	Jan 21/2005
K10300	1	Feb 06/2009		6	Jan 21/2005		11	Mar 09/2006
K10400	1	Feb 06/2009		7	Jan 21/2005		12	Jan 21/2005
R K10600	1	Aug 05/2009		8	Jan 21/2005		13	Jan 21/2005
L00000	1	Mar 09/2006		9	Jan 21/2005		14	Jan 21/2005
	2	Jan 21/2005		10	Jan 21/2005		15	Jan 21/2005
	3	Jan 21/2005		11	Jan 21/2005		16	Jan 21/2005
	4	Jan 21/2005		12	Jan 21/2005		17	Jan 21/2005
	5	Jan 21/2005		13	Jan 21/2005	L00400	1	Jan 21/2005
	6	Jan 21/2005		14	Jan 21/2005		2	Jan 21/2005
L00100	1	Mar 09/2006		15	Jan 21/2005		3	Jan 21/2005
	2	Mar 09/2006		16	Jan 21/2005		4	Jan 21/2005
	3	Jan 21/2005		17	Jan 21/2005		5	Jan 21/2005
	4	Jan 21/2005		18	Jan 21/2005		6	Jan 21/2005
	5	Jan 21/2005		19	Jan 21/2005		7	Jan 21/2005
	6	Jan 21/2005		20	Jan 21/2005		8	Jan 21/2005
	7	Jan 21/2005		21	Jan 21/2005		9	Mar 09/2006

A = Added, R = Revised, D = Deleted, O = Overflow



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
L00400 cont.			L00700 cont.			L01200	1	Jan 21/2005
	10	Mar 09/2006		6	Jan 21/2005		2	Jan 21/2005
L00500	1	Jan 21/2005		7	Jan 21/2005	L03400	1	Jan 21/2005
	2	Jan 21/2005		8	Jan 21/2005	L09000	1	Jan 21/2005
	3	Jan 21/2005		9	Mar 09/2006	M00000	1	Jan 21/2005
	4	Jan 21/2005		10	Jan 21/2005		2	Jan 21/2005
	5	Jan 21/2005	L00800	1	Jan 21/2005		3	Jan 21/2005
	6	Jan 21/2005		2	Jan 21/2005		4	Jan 21/2005
	7	Jan 21/2005		3	Jan 21/2005		5	Mar 09/2006
	8	Jan 21/2005		4	Jan 21/2005		6	Jan 21/2005
	9	Jan 21/2005		5	Jan 21/2005		7	Jan 21/2005
	10	Jan 21/2005	L00900	1	Jan 21/2005	M00100	1	Mar 14/2007
	11	Jan 21/2005		2	Mar 09/2006		2	Mar 14/2007
	12	Jan 21/2005		3	Mar 09/2006		3	Aug 15/2007
L00600	1	Jan 21/2005		4	Mar 09/2006		4	Aug 15/2007
	2	Jan 21/2005		5	Jan 21/2005		5	Jun 06/2008
	3	Jan 21/2005	L01000	1	Jan 21/2005		6	Jun 06/2008
	4	Jan 21/2005		2	Jan 21/2005		7	Jun 06/2008
	5	Jan 21/2005		3	Jan 21/2005		8	Jun 06/2008
	6	Mar 09/2006	L01100	1	Jan 21/2005		9	Jun 06/2008
	7	Jan 21/2005		2	Jan 21/2005		10	Jun 06/2008
	8	Sep 04/2008		3	Jan 21/2005	M00200	1	Mar 14/2007
	9	Jan 21/2005		4	Jan 21/2005		2	Jun 06/2008
L00700	1	Jan 21/2005		5	Jan 21/2005		3	Mar 14/2007
	2	Jan 21/2005		6	Jan 21/2005		4	Mar 14/2007
	3	Jan 21/2005		7	Jan 21/2005		5	Mar 14/2007
	4	Jan 21/2005		8	Mar 09/2006		6	Mar 14/2007
	5	Jan 21/2005		9	Jan 21/2005		7	Mar 14/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 12
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
M00200 cont.			M00600 cont.			M00900 cont.		
	8	Mar 14/2007		4	Mar 14/2007		7	Mar 14/2007
M00300	1	Mar 14/2007		5	Mar 14/2007		8	Mar 14/2007
	2	Mar 14/2007		6	Mar 14/2007	M01000	1	Mar 14/2007
	3	Mar 14/2007		7	Mar 14/2007		2	Mar 14/2007
	4	Mar 14/2007		8	Mar 14/2007		3	Mar 14/2007
	5	Mar 14/2007	M00700	1	Mar 14/2007		4	Mar 14/2007
	6	Mar 14/2007		2	Mar 14/2007		5	Mar 14/2007
	7	Mar 14/2007		3	Mar 14/2007		6	Mar 14/2007
	8	Mar 14/2007		4	Mar 14/2007		7	Mar 14/2007
	9	Mar 14/2007		5	Mar 14/2007		8	Mar 14/2007
	10	Mar 14/2007		6	Mar 14/2007		9	Mar 14/2007
M00400	1	Mar 14/2007		7	Mar 14/2007	M01100	1	Mar 14/2007
	2	Mar 14/2007		8	Mar 14/2007		2	Mar 14/2007
	3	Mar 14/2007		9	Mar 14/2007		3	Mar 14/2007
M00500	1	Mar 14/2007		10	Mar 14/2007		4	Mar 14/2007
	2	Mar 14/2007	M00800	1	Mar 14/2007		5	Mar 14/2007
	3	Mar 14/2007		2	Mar 14/2007	M01200	1	Mar 14/2007
	4	Mar 14/2007		3	Mar 14/2007		2	Mar 14/2007
	5	Mar 14/2007		4	Mar 14/2007		3	Mar 14/2007
	6	Mar 14/2007		5	Mar 14/2007		4	Mar 14/2007
	7	Mar 14/2007		6	Mar 14/2007	M01300	1	Mar 14/2007
	8	Mar 14/2007	M00900	1	Mar 14/2007		2	Mar 14/2007
	9	Mar 14/2007		2	Mar 14/2007		3	Mar 14/2007
	10	Mar 14/2007		3	Mar 14/2007	M01400	1	Mar 14/2007
M00600	1	Mar 14/2007		4	Mar 14/2007		2	Mar 14/2007
	2	Mar 14/2007		5	Mar 14/2007	M01500	1	Mar 14/2007
	3	Mar 14/2007		6	Mar 14/2007		2	Mar 14/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 13
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
M01500 cont.			M10000	1	Mar 14/2007	P015	1	Mar 14/2007
	3	Mar 14/2007		2	Mar 14/2007	P016	1	Mar 14/2007
M01600	1	Mar 14/2007	M10100	1	Mar 14/2007	P017	1	Mar 14/2007
	2	Mar 14/2007	M10200	1	Mar 14/2007	P019	1	Mar 14/2007
	3	Mar 14/2007		2	Mar 14/2007	P021	1	Mar 14/2007
	4	Mar 14/2007	M10300	1	Mar 14/2007	P022	1	Mar 14/2007
	5	Mar 14/2007	M10400	1	Mar 14/2007	P023	1	Mar 14/2007
	6	Mar 14/2007		2	Mar 14/2007	P024	1	Mar 14/2007
	7	Mar 14/2007		3	Mar 14/2007	P025	1	Mar 14/2007
	8	Mar 14/2007	M10700	1	Mar 14/2007	P027	1	Mar 14/2007
M01700	1	Mar 14/2007	M11200	1	Mar 14/2007	P028	1	Mar 14/2007
	2	Mar 14/2007	M12000	1	Mar 14/2007	P030	1	Mar 14/2007
	3	Mar 14/2007	N00000	1	Mar 14/2007	P031	1	Mar 14/2007
	4	Mar 14/2007		2	Mar 14/2007	P032	1	Mar 14/2007
	5	Mar 14/2007		3	Mar 14/2007	P033	1	Mar 14/2007
M01800	1	Mar 14/2007	N00100	1	Mar 14/2007	P034	1	Mar 14/2007
	2	Mar 14/2007	N10000	1	Mar 14/2007	P035	1	Mar 14/2007
M01900	1	Mar 14/2007	P001	1	Mar 14/2007	P036	1	Mar 14/2007
	2	Mar 14/2007	P003	1	Mar 14/2007	P037	1	Mar 14/2007
M02100	1	Mar 14/2007	P005	1	Mar 14/2007	P039	1	Mar 14/2007
M03100	1	Mar 14/2007	P006	1	Mar 14/2007	P040	1	Mar 14/2007
M06800	1	Mar 14/2007	P007	1	Mar 14/2007	P043	1	Mar 14/2007
M07100	1	Feb 06/2009	P008	1	Mar 14/2007	P044	1	Mar 14/2007
M07200	1	Mar 14/2007	P009	1	Mar 14/2007	P049	1	Mar 14/2007
M09000	1	Mar 14/2007	P010	1	Mar 14/2007	P050	1	Mar 14/2007
	2	Mar 14/2007	P011	1	Mar 14/2007	P051	1	Mar 14/2007
	3	Mar 14/2007	P013	1	Mar 14/2007	P054	1	Mar 14/2007
	4	Mar 14/2007	P014	1	Mar 14/2007	P055	1	Mar 14/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 14
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
P056	1	Mar 14/2007	R00200 cont.			R10100	1	Mar 14/2007
P058	1	Mar 14/2007		5	Mar 14/2007	S00000	1	Mar 14/2007
P059	1	Mar 14/2007	R00300	1	Mar 14/2007		2	Mar 14/2007
P061	1	Mar 14/2007		2	Mar 14/2007		3	Mar 14/2007
P065	1	Mar 14/2007		3	Mar 14/2007		4	Mar 14/2007
P070	1	Mar 14/2007		4	Mar 14/2007		5	Mar 14/2007
P071	1	Mar 14/2007	R00400	1	Mar 14/2007	S00100	1	Mar 14/2007
P072	1	Mar 14/2007		2	Mar 14/2007		2	Mar 14/2007
P073	1	Mar 14/2007		3	Mar 14/2007		3	Mar 14/2007
P078	1	Mar 14/2007		4	Mar 14/2007		4	Mar 14/2007
QD0000	1	Mar 14/2007		5	Mar 14/2007		5	Mar 14/2007
	2	Mar 14/2007		6	Mar 14/2007	S00200	1	Mar 14/2007
QD6700	1	Mar 14/2007		7	Mar 14/2007		2	Mar 14/2007
R00000	1	Mar 14/2007		8	Mar 14/2007		3	Mar 14/2007
	2	Mar 14/2007	R00500	1	Mar 14/2007		4	Mar 14/2007
	3	Mar 14/2007		2	Mar 14/2007		5	Mar 14/2007
	4	Mar 14/2007		3	Mar 14/2007		6	Mar 14/2007
	5	Mar 14/2007		4	Mar 14/2007		7	Mar 14/2007
R00100	1	Mar 14/2007		5	Mar 14/2007		8	Mar 14/2007
	2	Mar 14/2007	R00600	1	Mar 14/2007		9	Mar 14/2007
	3	Mar 14/2007		2	Mar 14/2007		10	Mar 14/2007
	4	Mar 14/2007		3	Mar 14/2007		11	Mar 14/2007
	5	Mar 14/2007		4	Mar 14/2007		12	Mar 14/2007
	6	Mar 14/2007		5	Mar 14/2007		13	Mar 14/2007
R00200	1	Mar 14/2007	R00700	1	Mar 14/2007		14	Mar 14/2007
	2	Mar 14/2007	R00800	1	Mar 14/2007	S00300	1	Mar 14/2007
	3	Mar 14/2007	R09000	1	Mar 14/2007		2	Jun 06/2008
	4	Mar 14/2007	R10000	1	Mar 14/2007		3	Jun 06/2008

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 15
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
S00300 cont.			S10500	1	Mar 14/2007	TB0100 cont.		
	4	Jun 06/2008	T00100	1	Mar 14/2007		10	Mar 14/2007
	5	Jun 06/2008		2	Mar 14/2007		11	Mar 14/2007
	6	Jun 06/2008		3	Mar 14/2007		12	Mar 14/2007
S00400	1	Mar 14/2007	T00200	1	Mar 14/2007		13	Mar 14/2007
	2	Mar 14/2007	T00600	1	Mar 14/2007		14	Mar 14/2007
	3	Mar 14/2007	T00800	1	Mar 14/2007		15	Mar 14/2007
	4	Mar 14/2007	T01500	1	Mar 14/2007		16	Mar 14/2007
S00500	1	Mar 14/2007	T10000	1	Mar 14/2007	TB0200	1	Mar 14/2007
	2	Mar 14/2007	TB0000	1	Mar 14/2007		2	Mar 14/2007
	3	Mar 14/2007		2	Mar 14/2007		3	Mar 14/2007
	4	Mar 14/2007		3	Mar 14/2007		4	Mar 14/2007
S00600	1	Mar 14/2007		4	Mar 14/2007		5	Mar 14/2007
	2	Mar 14/2007		5	Mar 14/2007		6	Mar 14/2007
	3	Mar 14/2007		6	Mar 14/2007		7	Mar 14/2007
	4	Mar 14/2007		7	Mar 14/2007		8	Mar 14/2007
S00700	1	Mar 14/2007		8	Mar 14/2007		9	Mar 14/2007
S00800	1	Mar 14/2007		9	Mar 14/2007		10	Mar 14/2007
	2	Mar 14/2007		10	Mar 14/2007		11	Mar 14/2007
	3	Mar 14/2007	TB0100	1	Mar 14/2007		12	Mar 14/2007
S00900	1	Mar 14/2007		2	Mar 14/2007		13	Mar 14/2007
S01500	1	Mar 14/2007		3	Mar 14/2007	TB0300	1	Mar 14/2007
S01600	1	Mar 14/2007		4	Mar 14/2007		2	Mar 14/2007
	2	Mar 14/2007		5	Mar 14/2007		3	Mar 14/2007
S02300	1	Mar 14/2007		6	Mar 14/2007		4	Mar 14/2007
S09000	1	Mar 14/2007		7	Mar 14/2007	TB0400	1	Mar 14/2007
S10100	1	Mar 14/2007		8	Mar 14/2007		2	Mar 14/2007
S10200	1	Mar 14/2007		9	Mar 14/2007	TB5000	1	Mar 14/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 16
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
TB5100	1	Mar 14/2007	V00000 cont.			O YAS+	1	Aug 05/2009
TB9000	1	Mar 14/2007		6	Mar 14/2007	YASK00	1	Mar 14/2007
TS0000	1	Mar 14/2007		7	Mar 14/2007	YASL00	1	Mar 14/2007
	2	Mar 14/2007	V00100	1	Mar 14/2007	YASS00	1	Mar 14/2007
	3	Mar 14/2007		2	Mar 14/2007	O YAY+	1	Aug 05/2009
TS0100	1	Mar 14/2007		3	Mar 14/2007	YAYK00	1	Mar 14/2007
	2	Mar 14/2007		4	Mar 14/2007	YAYL00	1	Mar 14/2007
	3	Mar 14/2007		5	Mar 14/2007	YAYS00	1	Mar 14/2007
TS0200	1	Mar 14/2007	V00300	6	Mar 14/2007	O YAZ+	1	Aug 05/2009
	2	Mar 14/2007		1	Feb 06/2009	YAZK00	1	Mar 14/2007
	3	Mar 14/2007		2	Feb 06/2009	YAZL00	1	Mar 14/2007
TS0300	1	Mar 14/2007		3	Feb 06/2009		2	Mar 14/2007
	2	Mar 14/2007	O YA3+	1	Aug 05/2009	YAZS00	1	Mar 14/2007
	3	Mar 14/2007	YA3L00	1	Mar 14/2007	O YB1+	1	Aug 05/2009
	4	Mar 14/2007		2	Mar 14/2007	YB1L00	1	Mar 14/2007
TS0400	1	Mar 14/2007	YA3S00	1	Mar 14/2007	YB1S00	1	Mar 14/2007
	2	Mar 14/2007	O YA9+	1	Aug 05/2009	O YB2+	1	Aug 05/2009
TS0500	1	Mar 14/2007	YA9L00	1	Mar 14/2007	YB2C	1	Mar 14/2007
	2	Mar 14/2007		2	Mar 14/2007	YB2S00	1	Mar 14/2007
	3	Mar 14/2007	YA9S00	1	Mar 14/2007	O YB3+	1	Aug 05/2009
TS0600	1	Mar 14/2007	O YAA+	1	Aug 05/2009	YB3K00	1	Mar 14/2007
TS5000	1	Mar 14/2007	YAAS00	1	Mar 14/2007		2	Mar 14/2007
TS5100	1	Mar 14/2007	YAAV00	1	Mar 14/2007	YB3M00	1	Mar 14/2007
V00000	1	Mar 14/2007	O YAL+	1	Aug 05/2009		2	Mar 14/2007
	2	Mar 14/2007	YALS00	1	Mar 14/2007	O YB4+	1	Aug 05/2009
	3	Mar 14/2007	O YAR+	1	Aug 05/2009	YB4S00	1	Mar 14/2007
	4	Mar 14/2007	YARJ00	1	Mar 14/2007	YB4V00	1	Mar 14/2007
	5	Mar 14/2007	YARS00	1	Mar 14/2007	O YB5+	1	Aug 05/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 17
Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
YB5S00	1	Mar 14/2007	YBHS00	1	Mar 14/2007	YBOT00	1	Mar 14/2007
YB5V00	1	Mar 14/2007		2	Mar 14/2007	○ YBP+	1	Aug 05/2009
○ YB6+	1	Aug 05/2009	○ YBI+	1	Aug 05/2009	YBPB00	1	Mar 14/2007
YB6V00	1	Mar 14/2007	YBIK00	1	Mar 14/2007	YBPC00	1	Mar 14/2007
○ YB7+	1	Aug 05/2009	YBIN00	1	Mar 14/2007		2	Mar 14/2007
YB7K00	1	Mar 14/2007	YBIS00	1	Mar 14/2007	YBPD00	1	Mar 14/2007
YB7M00	1	Mar 14/2007		2	Mar 14/2007		2	Mar 14/2007
YB7S00	1	Mar 14/2007		3	Mar 14/2007	YBPD	1	Mar 14/2007
○ YB8+	1	Aug 05/2009	○ YBM+	1	Aug 05/2009	YBPK00	1	Mar 14/2007
YB8K00	1	Mar 14/2007	YBMM00	1	Mar 14/2007	YBPL00	1	Mar 14/2007
YB8M00	1	Mar 14/2007	YBMP00	1	Mar 14/2007	YBPM00	1	Mar 14/2007
YB8S00	1	Mar 14/2007		2	Mar 14/2007	YBPP00	1	Mar 14/2007
○ YBA+	1	Aug 05/2009	YBMS00	1	Mar 14/2007	YBPS00	1	Mar 14/2007
YBAL00	1	Mar 14/2007	YBMT	1	Mar 14/2007	YBPT00	1	Mar 14/2007
YBAS00	1	Mar 14/2007	YBMV00	1	Mar 14/2007	○ YBQ+	1	Aug 05/2009
○ YBF+	1	Aug 05/2009	○ YBN+	1	Aug 05/2009	YQB00	1	Mar 14/2007
YBFL00	1	Mar 14/2007	YBNS00	1	Mar 14/2007	YBQC00	1	Mar 14/2007
	2	Mar 14/2007	○ YBO+	1	Aug 05/2009		2	Mar 14/2007
YBFN00	1	Mar 14/2007	YBOB00	1	Mar 14/2007	YBQD00	1	Mar 14/2007
YBFR00	1	Mar 14/2007	YBOC00	1	Mar 14/2007		2	Mar 14/2007
YBFS00	1	Mar 14/2007		2	Mar 14/2007	YBQK00	1	Mar 14/2007
	2	Mar 14/2007	YBOD00	1	Mar 14/2007	YBQL00	1	Mar 14/2007
	3	Mar 14/2007		2	Mar 14/2007	YBQM00	1	Mar 14/2007
○ YBG+	1	Aug 05/2009	YBOK00	1	Mar 14/2007	YBQP00	1	Mar 14/2007
YBGC	1	Mar 14/2007	YBOL00	1	Mar 14/2007	YBQS00	1	Mar 14/2007
YBGM00	1	Mar 14/2007	YBOM00	1	Mar 14/2007	YBQT00	1	Mar 14/2007
○ YBH+	1	Aug 05/2009	YBOP00	1	Mar 14/2007	○ YBS+	1	Aug 05/2009
YBHK00	1	Mar 14/2007	YBOS00	1	Mar 14/2007	○ YBT+	1	Aug 05/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 18
Aug 05/2009

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
YBTS00	1	Mar 14/2007	YCFV00	1	Mar 14/2007	YCPD00	1	Mar 14/2007
○ YBU+	1	Aug 05/2009	○ YCG+	1	Aug 05/2009	YCPK00	1	Mar 14/2007
YBUS00	1	Mar 14/2007	YCGC	1	Mar 14/2007	YCPM00	1	Mar 14/2007
○ YBV+	1	Aug 05/2009	YCGD00	1	Mar 14/2007	YCPP00	1	Mar 14/2007
YBVT	1	Mar 14/2007	YCGK00	1	Mar 14/2007			
○ YBW+	1	Aug 05/2009	YCGM00	1	Mar 14/2007			
YBWM00	1	Mar 14/2007	YCGR	1	Mar 14/2007			
○ YBX+	1	Aug 05/2009	YCGS00	1	Mar 14/2007			
YBXV00	1	Mar 14/2007	YCGV00	1	Mar 14/2007			
○ YBY+	1	Aug 05/2009	○ YCL+	1	Aug 05/2009			
YBYV00	1	Mar 14/2007	YCLK00	1	Mar 14/2007			
○ YBZ+	1	Aug 05/2009	YCLL00	1	Mar 14/2007			
YBZV00	1	Mar 14/2007	YCLS00	1	Mar 14/2007			
○ YCC+	1	Aug 05/2009		2	Mar 14/2007			
YCCB00	1	Mar 14/2007		3	Mar 14/2007			
YCCC	1	Mar 14/2007		4	Mar 14/2007			
YCCD00	1	Mar 14/2007	○ YCO+	1	Aug 05/2009			
YCCK00	1	Mar 14/2007	YCOL00	1	Mar 14/2007			
YCCM00	1	Mar 14/2007	YCOS00	1	Mar 14/2007			
YCCR	1	Mar 14/2007	○ YCP+	1	Aug 05/2009			
YCCS00	1	Mar 14/2007	YCPB00	1	Mar 14/2007			
YCCV00	1	Mar 14/2007	YCPC00	1	Mar 14/2007			
○ YCF+	1	Aug 05/2009	YCPD00	1	Mar 14/2007			
YCFV00	1	Mar 14/2007	YCPK00	1	Mar 14/2007			
YCFD00	1	Mar 14/2007	YCPM00	1	Mar 14/2007			
YCFK00	1	Mar 14/2007	YCPN00	1	Mar 14/2007			
YCFM00	1	Mar 14/2007	YCPQ00	1	Mar 14/2007			
YCFR	1	Mar 14/2007						

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

 Page 19
 Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
YCZL00	1	Mar 14/2007	YDLL00 cont.			YDWK00	1	Mar 14/2007
	2	Mar 14/2007		2	Mar 14/2007	YDWS00	1	Mar 14/2007
	3	Mar 14/2007		3	Mar 14/2007		2	Mar 14/2007
YCZS00	1	Mar 14/2007		4	Mar 14/2007		3	Mar 14/2007
	2	Mar 14/2007	O YDM+	1	Aug 05/2009		4	Mar 14/2007
	3	Mar 14/2007	YDMS00	1	Mar 14/2007	O YEC+	1	Aug 05/2009
O YDA+	1	Aug 05/2009		2	Mar 14/2007	YECC	1	Mar 14/2007
YDAL00	1	Mar 14/2007	O YDN+	1	Aug 05/2009	YECD00	1	Mar 14/2007
	2	Mar 14/2007	YDNK00	1	Mar 14/2007	YECK00	1	Mar 14/2007
YDAS00	1	Mar 14/2007	YDNL00	1	Mar 14/2007	YECM00	1	Mar 14/2007
O YDB+	1	Aug 05/2009		2	Mar 14/2007	YECR	1	Mar 14/2007
YDBS00	1	Mar 14/2007	YDNS00	1	Mar 14/2007	YECS00	1	Mar 14/2007
O YDE+	1	Aug 05/2009		2	Mar 14/2007	YECV00	1	Mar 14/2007
O YDH+	1	Aug 05/2009	YDOK00	1	Mar 14/2007	O YEE+	1	Aug 05/2009
YDHS00	1	Mar 14/2007	YDOL00	1	Mar 14/2007	YEEC	1	Mar 14/2007
O YDI+	1	Aug 05/2009	YDOS00	1	Mar 14/2007	YEED00	1	Mar 14/2007
YDIL00	1	Mar 14/2007		2	Mar 14/2007	YEEK00	1	Mar 14/2007
YDIS00	1	Mar 14/2007	O YDP+	1	Aug 05/2009	YEEM00	1	Mar 14/2007
O YDJ+	1	Aug 05/2009	YDPS00	1	Mar 14/2007	YEER	1	Mar 14/2007
YDJK00	1	Mar 14/2007	O YDQ+	1	Aug 05/2009	YEES00	1	Mar 14/2007
YDJL00	1	Mar 14/2007	YDQS00	1	Mar 14/2007	YEEV00	1	Mar 14/2007
YDJS00	1	Mar 14/2007	O YDS+	1	Aug 05/2009	O YEG+	1	Aug 05/2009
	2	Mar 14/2007	YDSK00	1	Mar 14/2007	YEGL00	1	Mar 14/2007
	3	Mar 14/2007	YDSL00	1	Mar 14/2007		2	Mar 14/2007
	4	Mar 14/2007	YDSS00	1	Mar 14/2007	O YEH+	1	Aug 05/2009
	5	Mar 14/2007	O YDU+	1	Aug 05/2009	YEHS00	1	Mar 14/2007
O YDL+	1	Aug 05/2009	YDUS00	1	Mar 14/2007	O YEI+	1	Aug 05/2009
YDLL00	1	Mar 14/2007	O YDW+	1	Aug 05/2009	YEIS00	1	Mar 14/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 20
Aug 05/2009

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
O YEJ+	1	Aug 05/2009	YFBB00	1	Mar 14/2007	YGAB00	1	Mar 14/2007
YEJL00	1	Mar 14/2007	O YFD+	1	Aug 05/2009	YGBR	1	Mar 14/2007
O YEK+	1	Aug 05/2009	YFDB00	1	Mar 14/2007	O YGI+	1	Aug 05/2009
YEKL00	1	Mar 14/2007	O YFE+	1	Aug 05/2009	YGIL00	1	Mar 14/2007
O YEN+	1	Aug 05/2009	YFEB00	1	Mar 14/2007	YGIS00	1	Mar 14/2007
YENS00	1	Mar 14/2007	O YFF+	1	Aug 05/2009	O YGK+	1	Aug 05/2009
YEOB00	1	Mar 14/2007	YFFB00	1	Mar 14/2007	YGKM00	1	Mar 14/2007
O YER+	1	Aug 05/2009	O YFG+	1	Aug 05/2009	O YGL+	1	Aug 05/2009
YERK00	1	Mar 14/2007	YFGB00	1	Mar 14/2007	YGLM00	1	Mar 14/2007
YERL00	1	Mar 14/2007	O YFH+	1	Aug 05/2009	O YGM+	1	Aug 05/2009
YERS00	1	Mar 14/2007	YFHB00	1	Mar 14/2007	YGMM00	1	Mar 14/2007
O YEU+	1	Aug 05/2009	O YFI+	1	Aug 05/2009	O YGT+	1	Aug 05/2009
YEUM00	1	Mar 14/2007	YFIB00	1	Mar 14/2007	YGTC	1	Mar 14/2007
YEUT	1	Mar 14/2007	O YFJ+	1	Aug 05/2009	YGTD00	1	Mar 14/2007
O YEV+	1	Aug 05/2009	YFJB00	1	Mar 14/2007	YGTK00	1	Mar 14/2007
YEVN00	1	Mar 14/2007	O YFU+	1	Aug 05/2009	YGTM00	1	Mar 14/2007
YEVN00	1	Mar 14/2007	YFUB00	1	Mar 14/2007	YGTR	1	Mar 14/2007
O YEW+	1	Aug 05/2009	O YFV+	1	Aug 05/2009	YGTS00	1	Mar 14/2007
YEWB00	1	Mar 14/2007	YFVB00	1	Mar 14/2007	YGTV00	1	Mar 14/2007
O YEX+	1	Aug 05/2009	O YFW+	1	Aug 05/2009	O YHG+	1	Aug 05/2009
YEXB00	1	Mar 14/2007	YFWB00	1	Mar 14/2007	YHGS00	1	Mar 14/2007
O YEY+	1	Aug 05/2009	O YFX+	1	Aug 05/2009	O YHI+	1	Aug 05/2009
YEYB00	1	Mar 14/2007	YFXB00	1	Mar 14/2007	YHIL00	1	Mar 14/2007
O YEZ+	1	Aug 05/2009	O YFY+	1	Aug 05/2009	YHIS00	1	Mar 14/2007
YEZB00	1	Mar 14/2007	YFYB00	1	Mar 14/2007	YHQM00	1	Mar 14/2007
O YFA+	1	Aug 05/2009	O YFZ+	1	Aug 05/2009	O YHW+	1	Aug 05/2009
YFAB00	1	Mar 14/2007	YFZB00	1	Mar 14/2007	YHWS00	1	Mar 14/2007
O YFB+	1	Aug 05/2009	O YGA+	1	Aug 05/2009	O YHY+	1	Aug 05/2009

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

 Page 21
 Aug 05/2009



EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
YHYB00	1	Mar 14/2007	YIBC	1	Mar 14/2007	YIFB00	1	Mar 14/2007
YHYC	1	Mar 14/2007	YIBD00	1	Mar 14/2007	YIFC00	1	Mar 14/2007
YHYD00	1	Mar 14/2007	YIBK00	1	Mar 14/2007	YIFD00	1	Mar 14/2007
YHYK00	1	Mar 14/2007	YIBM00	1	Mar 14/2007	YIFK00	1	Mar 14/2007
YHYM00	1	Mar 14/2007	YIBR	1	Mar 14/2007	YIFL00	1	Mar 14/2007
YHYR	1	Mar 14/2007	YIBS00	1	Mar 14/2007	YIFM00	1	Mar 14/2007
YHYS00	1	Mar 14/2007	YIBV00	1	Mar 14/2007	YIFP00	1	Mar 14/2007
YHYV00	1	Mar 14/2007	O YIC+	1	Aug 05/2009	YIFS00	1	Mar 14/2007
O YHZ+	1	Aug 05/2009	YICB00	1	Mar 14/2007	YIFT00	1	Mar 14/2007
YHZB00	1	Mar 14/2007	YICC	1	Mar 14/2007	O YIH+	1	Aug 05/2009
YHZC	1	Mar 14/2007	YICD00	1	Mar 14/2007	YIHL00	1	Mar 14/2007
YHZD00	1	Mar 14/2007	YICK00	1	Mar 14/2007	YIHS00	1	Mar 14/2007
YHZK00	1	Mar 14/2007	YICM00	1	Mar 14/2007	O YII+	1	Aug 05/2009
YHZM00	1	Mar 14/2007	YICR	1	Mar 14/2007	YIIS00	1	Mar 14/2007
YHZR	1	Mar 14/2007	YICS00	1	Mar 14/2007	YIIV00	1	Mar 14/2007
YHZS00	1	Mar 14/2007	YICV00	1	Mar 14/2007	O YIJ+	1	Aug 05/2009
YHZV00	1	Mar 14/2007	O YID+	1	Aug 05/2009	YIJS00	1	Mar 14/2007
O YIA+	1	Aug 05/2009	YIDB00	1	Mar 14/2007	YIJV00	1	Mar 14/2007
YIAB00	1	Mar 14/2007	YIDC	1	Mar 14/2007	O YIL+	1	Aug 05/2009
YIAC	1	Mar 14/2007	YIDD00	1	Mar 14/2007	YILS00	1	Mar 14/2007
YIAD00	1	Mar 14/2007	YIDK00	1	Mar 14/2007	O YIN+	1	Aug 05/2009
YIAK00	1	Mar 14/2007	YIDM00	1	Mar 14/2007	YINK00	1	Mar 14/2007
YIAM00	1	Mar 14/2007	YIDR	1	Mar 14/2007	YINL00	1	Mar 14/2007
YIAR	1	Mar 14/2007	YIDS00	1	Mar 14/2007	YINS00	1	Mar 14/2007
YIAS00	1	Mar 14/2007	YIDV00	1	Mar 14/2007	O YIP+	1	Aug 05/2009
YIAV00	1	Mar 14/2007	O YIE+	1	Aug 05/2009	YIPS00	1	Mar 14/2007
O YIB+	1	Aug 05/2009	YIES00	1	Mar 14/2007	O YIS+	1	Aug 05/2009
YIBB00	1	Mar 14/2007	O YIF+	1	Aug 05/2009	YISS00	1	Mar 14/2007

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 22
Aug 05/2009

EQUIPMENT LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
	YITS00	1	Mar 14/2007					
O	YJE+	1	Aug 05/2009					
	YJEL00	1	Mar 14/2007					
	YJES00	1	Mar 14/2007					
	YKYM00	1	Mar 07/2008					
	YKYS00	1	Mar 07/2008					

A = Added, R = Revised, D = Deleted, O = Overflow

EQUIPMENT LIST

D280T132

EFFECTIVE PAGES

Page 23
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC0506		PAC1019-505 PANEL-P35 FWD CARGO DISC	284T0687 31967	1	91-04-11 0466/158/R067	050-099
AC0506		PAC1019-505 PANEL-P35 FWD CARGO DISC	284T0687 31967	1	91-04-11 0470/157/R075	150-199, 275-299

EQUIPMENT LIST

D280T132

Section AC0500

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC0604		284T0926-1 PANEL-E5-1 DISC	284T0921 81205	1	91-04-11 0654/190/R075	ALL
AC0606		284T0926-2 PANEL-E5-2 DISC	284T0921 81205	1	91-04-11 0654/180/R088	050-099
AC0606		284T0926-2 PANEL-E5-2 DISC	284T0921 81205	1	91-04-11 0654/180/R070	150-199, 275-299
AC0608		284T0926-9 PANEL-E5-3 DISC	284T0921 81205	1	91-04-11 0654/170/R085	050-099
AC0608		284T0926-9 PANEL-E5-3 DISC	284T0921 81205	1	91-04-11 0654/170/R070	150-199, 275-299

EQUIPMENT LIST

D280T132

Section AC0600
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC0701		287T4150-187 PANEL-LEFT SIDE WING BODY DISC	287T4320 81205	1	91-04-12 0752/150/L080	050-099, 275-299
AC0701		287T4150-173 PANEL-LEFT SIDE WING BODY DISC	287T4320 81205	1	91-04-12 0752/150/L080	150-199
AC0702		287T4150-186 PANEL-RIGHT SIDE WING BODY DISC	287T4320 81205	1	91-04-12 0752/160/R090	050-099, 275-299
AC0702		287T4150-174 PANEL-RIGHT SIDE WING BODY DISC	287T4320 81205	1	91-04-12 0752/160/R090	150-154, 162-163
AC0702		287T4150-174 PANEL-RIGHT SIDE WING BODY DISC	287T4320 81205	1	91-04-12 0780/180/R068	155-157, 164-199

EQUIPMENT LIST

D280T132

Section AC0700

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC1102	9	284T1323 BRACKET - E9-1 SHELF	284T1307 81205	1	91-04-15 1197+132/180/R080	150, 153-155, 162-165
AC1102		284T1323 BRACKET - E9-1 SHELF	81205	1	23-25-13 1197/180/R080	150, 153-155, 162-165
AC1102		284T1323 BRACKET - E9-1 SHELF	284T1307 81205	1	91-04-15 1197+132/180/R080	156-157, 166-199, 277-299
AC1104		284T1323-4 BRACKET - E9-1 SHELF	284T1307 81205	1	91-04-15 1197+132/168/R080	167-199

EQUIPMENT LIST

D280T132

Section AC1100
Page 1 End
Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC1201		287T4150-48 BRACKET-AFT CARGO COMPT SIDEWALL DISC	287T4602 81205	1	91-04-11 1246/157/L073	ALL

EQUIPMENT LIST

D280T132

Section AC1200

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC1304		PAC1019-505 PANEL-P39 AFT CARGO DISC	284T0688 31967	1	91-04-11 1267/157/R067	ALL

EQUIPMENT LIST

D280T132

Section AC1300
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC1402		287T4150-85 PANEL-E6 AND P49 DISC	287T4609 81205	1	91-04-11 1417/190/R080	ALL

EQUIPMENT LIST

D280T132

Section AC1400

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AC1501		287T4150-146 BRACKET-AFT CARGO SIDEWALL DISCONNECT	287T4609 81205	1	91-04-11 1529/171/L072	ALL

EQUIPMENT LIST

D280T132

Section AC1500
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0102		253T5537-2 BRACKET-P10 DISC FWD	253T5500 81205	1	91-04-26 0169/210/R010	ALL
AE0104		253T5537-3 BRACKET-P10 DISC AFT	253T5500 81205	1	91-04-26 0172/210/R010	ALL
AE0105		287T4146-19 BRACKET-CLM FRC DCR TS15 DISC	141T2910 81205	1	91-04-27 0175/184/L025	ALL
AE0106		287T4146-20 BRACKET-CLM FRC DCR TS14 DISC	141T2910 81205	1	91-04-27 0175/184/R025	ALL
AE0107		287T4146-118 BRACKET-LVDT P10 DISC	141T2910 81205	1	91-04-26 0175/175/L010	ALL
AE0108		287T4146-240 BRACKET-SWITCHBACK DISC	141T2110 81205	1	91-04-27 0137/188/0000	ALL

EQUIPMENT LIST

D280T132

Section AE0100

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0202		285T0296-57 PANEL-P50 CARD FILE DISC	285T0006 81205	1	91-04-23 0287/159/R030	ALL
AE0203		284T0372-1 PANEL-P33 RIGHT SIDE MISC EQUIPMENT DISC	284T1016 81205	1	91-04-21 296/165/L010	ALL
AE0204		284T0176-15 PANEL-P34 APU EXT PWR DISC	284T0175 81205	1	91-04-21 0287/155/R015	ALL
AE0207		284T0372-1 PANEL-P33 LEFT SIDE DISC	284T1016 81205	1	91-04-21 0296/185/L024	ALL
AE0208		285T0061-41 PANEL-P51 WARNING ELEC DISC	285T0007 81205	1	91-04-23 0266/151/R028	050-099
AE0208		285T0061-45 PANEL-P51 WARNING ELEC DISC	285T0007 81205	1	91-04-23 0266/151/R028	150-199, 275-299
AE0209		284T1013-2 PANEL-P36 DISCONNECT	284T1042 81205	1	91-04-22 0289/176/L065	ALL
AE0217		253T1150-5 BRACKET-CLM FRC DCR TS16	253T1149 81205	1	91-04-27 0210/194/L023	ALL
AE0218		284T1019-2 PANEL-P37 DISCONNECT	284T1020 81205	1	91-04-22 0292/169/R068	ALL
AE0219		284T1057-3 PANEL-E8 DISCONNECT RIGHT	284T1068 81205	1	91-04-23 0242/169/L058	ALL
AE0220		284T1070-2 PANEL-E3-1 DISCONNECT	284T1073 81205	1	91-04-23 0290/152/R058	ALL
AE0221		284T1032-23 PANEL-E8 DISCONNECT LEFT	284T0972 81205	1	91-04-23 0241/173/L050	ALL
AE0222		284T1066 PANEL-P6 BOTTOM	284T1039 81205	1	91-04-42 0221/207/R043	ALL
AE0223		284T1013-2 PANEL-P36 BOTTOM	284T1042 81205	1	91-04-22 0293/152/L063	ALL
AE0224		284T1019-2 PANEL-P37 BOTTOM	284T1020 81205	1	91-04-22 0280/159/R064	ALL
AE0225		284T1167-1 PANEL-P65 HYD GEN PWR DISC	284T1168 81205	1	91-04-23 0225/165/L055	ALL
AE0226		285T0508-1 PANEL-P54 CARD FILE	285T0509 81205	1	91-04-23 0236/157/R028	ALL

EQUIPMENT LIST

D280T132

Section AE0200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0227		284T8702-3 PANEL-P87 DISCONNECT	284T8704 81205	1	91-04-22 0300/130/L009	ALL

EQUIPMENT LIST

D280T132

Section AE0200

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0303		284T0767-1 SHELF-E1-1 DISC	284T1611 81205	1	91-04-24 0344/190/L047	ALL
AE0305		141T2200-71 STNCH-LEFT SIDE OUTBD CARGO DISC	141T2200 81205	1	91-04-24 0355/125/L038	ALL
AE0306		141T2200-70 STNCH-RIGHT SIDE INBD CARGO DISC	141T2200 81205	1	91-04-24 0355/125/R013	ALL
AE0307		284T0718-6 BRACKET-E1 AND E2 EQUIP CTR DISC	284T0717 81205	1	91-04-24 0350/157/0000	ALL
AE0308		284T0767-2 SHELF-E2-1 DISC	284T1621 81205	1	91-04-24 0344/190/R043	ALL
AE0311		284T0173-5 PANEL-P31 GEN PWR LEFT SIDE DISC	284T0171 81205	1	91-04-21 0341/143/L066	ALL
AE0312		284T0174-5 PANEL-P32 GEN PWR RIGHT SIDE DISC	284T0172 81205	1	91-04-21 0345/150/R075	ALL
AE0313		284T0385-13 SHELF-E1-2 DISC	284T1612 81205	1	91-04-24 0344/180/L047	ALL
AE0314		284T0385-14 SHELF-E2-2 DISC	284T1622 81205	1	91-04-24 0344/180/R043	ALL
AE0315		284T0385-13 SHELF-E1-3 DISC	284T1613 81205	1	91-04-24 0344/169/L047	ALL
AE0316		284T0385-14 SHELF-E2-3 DISC	284T1623 81205	1	91-04-24 0344/169/R043	ALL
AE0317		141T2200-70 STNCH-LEFT SIDE INBD CARGO DISC	141T2200 81205	1	91-04-24 0355/125/L013	ALL
AE0319		284T0307-28 STNCH-LEFT SIDE AFT DISC	284T0304 81205	1	91-04-24 0347/130/L048	ALL
AE0320		141T2200-118 STNCH-RIGHT SIDE OUTBD CARGO DISC	141T2200 81205	1	91-04-24 0355/125/R038	ALL
AE0321		284T0385-13 SHELF-E1-4 DISC	284T1614 81205	1	91-04-24 0344/149/L047	ALL
AE0322		284T0307-27 STNCH-RIGHT SIDE AFT DISC	284T0304 81205	1	91-04-24 0347/160/R044	ALL
AE0323		284T0385-13 SHELF-E1-5 DISC	284T1615 81205	1	91-04-24 0344/139/L047	ALL

EQUIPMENT LIST

D280T132

Section AE0300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AE0324		284T0385-14 SHELF-E2-5 DISC	284T1625 81205	1	91-04-24 0344/139/R043	ALL
AE0325	9	287T4146-280 SHELF-E1-3 TCAS ANT DISC (SB 34-0091)	287T4116 81205	1	91-04-27 0352/158/L025	150-152
AE0325		287T4146-292 SHELF-E1-3 TCAS ANT DISC	287T4116 81205	1	91-04-27 0352/158/L025	050-099, 153-199, 277-299
AE0326	9	287T4146-293 TCAS DISC. LOWER ANT. (SB 34-0091)	287T4116 81205	1	91-04-27 0399/108/R008	150-152, 275-276
AE0326		287T4146-293 TCAS DISC. LOWER ANT.	287T4116 81205	1	91-04-27 0399/108/R008	050-099, 153-199, 277-299

EQUIPMENT LIST

D280T132

Section AE0300

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AF0111		287T4150-9 PANEL-P5 LEFT SIDE DISC	287T4103 81205	1	91-04-43 0194/275/L002	ALL
AF0112		287T4150-9 PANEL-P5 RIGHT SIDE DISC	287T4103 81205	1	91-04-43 0194/275/R002	ALL
AF0113		233T2229-2 PANEL-P1-3 DISCONNECT	233T2228 81205	1	91-04-41 0140/234/L015	ALL
AF0116		233N2213-13 PANEL-P3-1 DISCONNECT	233T2228 81205	1	91-04-41 0140/234/R015	ALL
AF0117		233T2320-43 PANEL-P7 DISCONNECT LEFT SIDE	233T2321 81205	1	91-04-41 0151/259/L021	ALL
AF0118		233T2320-44 PANEL-P7 DISCONNECT RIGHT SIDE	233T2321 81205	0	91-04-41 0151/259/R021	ALL
AF0119		287T4150-143 PANEL-P1 DISCONNECT	287T4103 81205	1	91-04-41 0149/210/L040	ALL
AF0120		287T4150-144 PANEL-P3 DISCONNECT	287T4103 81205	1	91-04-41 0149/210/R040	ALL

EQUIPMENT LIST

D280T132

Section AF0100
Page 1 End
Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AF0201		233T5226-54 PANEL-P11 LEFT SIDE DISC	233T5216 81205	1	91-04-42 0212/280/L020	ALL
AF0203		233T5226-35 PANEL-P11 LEFT SIDE DISC	233T5216 81205	1	91-04-42 0206/280/L010	ALL
AF0204		287T4150-188 PANEL-P61 PNL DISCONNECT	287T4103 81205	1	91-04-43 0234/250/R050	ALL
AF0232		284T1054 PANEL-P6 DISCONNECT	284T1039 81205	1	91-04-42 0221/215/R043	ALL

EQUIPMENT LIST

D280T132

Section AF0200

Page 1 End

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AL0201		284T0742-35 PANEL-P40 DISC	284T0742 81205	1	91-04-61 0265/188/0000	050-099, 155-199, 277-299
AL0201		284T0744-4 PANEL-P40 DISC	284T0742 81205	1	91-04-61 0265/188/0000	150-154, 275-276
AL0202		287T4150-217 PANEL-NOSE WHEEL WELL DISC	287T4129 81205	1	91-04-61 0287/152/R025	050-099, 155-199, 277-299
AL0202		287T4150-41 PANEL-NOSE WHEEL WELL DISC	287T4129 81205	1	91-04-61 0287/152/R025	150-154, 275-276

EQUIPMENT LIST

D280T132

Section AL0200
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AL0901		287T4509-17 PANEL-LEFT SIDE SPOILER DISC	100T1430 81205	1	91-04-62 0977/178/L092	ALL
AL0902		287T4509-18 PANEL-RIGHT SIDE SPOILER DISC	100T1430 81205	1	91-04-62 0977/178/R092	ALL

EQUIPMENT LIST

D280T132

Section AL0900
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AL1001		287T4150-95 PANEL-LEFT SIDE FWD OUTBD DISC	287T4504 81205	1	91-04-62 0999/193/L057	ALL
AL1002		287T4150-96 PANEL-RIGHT SIDE FWD OUTBD DISC	287T4504 81205	1	91-04-62 0999/193/R057	ALL
AL1003		287T4150-177 PANEL-LEFT SIDE FWD INBD DISC	287T4504 81205	1	91-04-62 0999/193/L047	ALL
AL1004		287T4150-178 PANEL-RIGHT SIDE FWD INBD DISC	287T4504 81205	1	91-04-62 0999/193/R047	ALL
AL1005		287T4150-103 PANEL-LEFT SIDE AFT OUTBD DISC	287T4504 81205	1	91-04-62 1043/193/L057	ALL
AL1006		287T4150-104 PANEL-RIGHT SIDE AFT OUTBD DISC	287T4504 81205	1	91-04-62 1043/190/R058	ALL
AL1007		287T4150-125 PANEL-LEFT SIDE AFT INBD DISC	287T4504 81205	1	91-04-62 1043/193/L047	ALL
AL1008		287T4150-126 PANEL-RIGHT SIDE AFT INBD DISC	287T4504 81205	1	91-04-62 1043/193/R047	ALL
AL1009		287T4505-105 PANEL-LEFT FWD OUTBD COVER DISC	287T4504 81205	1	91-04-62 0999/193/L064	ALL
AL1010		287T4505-72 PANEL-RIGHT FWD OUTBD COVER DISC	287T4504 81205	1	91-04-62 0999/193/R064	ALL
AL1011		287T4505-67 PANEL-LEFT FWD INBD COVER DISC	287T4504 81205	1	91-04-62 0999/193/L039	ALL
AL1012		287T4505-68 PANEL-RIGHT FWD INBD COVER DISC	287T4504 81205	1	91-04-62 0999/193/R039	ALL

EQUIPMENT LIST

D280T132

Section AL1000
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0001		287T4150-10 PANEL-CONTROLLER VIDEO DISC	413T1153 81205	1	91-03-91 1130/283/L067	050-099
AP0001		287T4150-10 PANEL-CONTROLLER VIDEO DISC	284T0807 81205	1	91-04-71 0255/258/R006	150-199, 275-299
AP0002		287T4150-206 PANEL-VIDEO CONTROLLER DISC	284T0807 81205	1	91-04-71 0447/243/L055	050-099, 150-199
AP0003		287T4150-11 PANEL-VIDEO TAPE REPRODUCER DISC	413T1174 81205	1	91-03-91 1130/283/L067	050-099

EQUIPMENT LIST

D280T132

Section AP0000

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0202		287T4150-207 PANEL-VIDEO CLOSET DISC	284T0807 81205	1	91-04-71 0255/281/R017	275
AP0205		287T4150-211 PANEL DISC-FLIGHT CREW REST	287T4173 81205	1	91-04-71 0245/285/L014	050-099, 162-199, 276-299

EQUIPMENT LIST

D280T132

Section AP0200
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0301		287T4156-7 BRACKET-L S LWR CEILING DISC	412T3001 81205	1	91-04-71 0315/283/L007	275-299
AP0301B		287T4156-64 BRACKET-L S LWR CEILING DISC	412T3122 81205	1	91-04-71 0289/283/0000	ALL
AP0305	9	287T4150-211 PANEL-VTR DISC (C MTO 230540)	287T4334 81205	1	91-04-71 0455/268/L084	050-099
AP0307		287T4150-212 PANEL-VIDEO TAPE REPRODUCER DISC	287T4173 81205	1	91-04-71 0380/315/L008	050-099, 150-199

EQUIPMENT LIST

D280T132

Section AP0300

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0401		284T1152-1 PANEL-P19 FWD LTG DISC	285T0019 81205	1	91-04-71 0385/310/L025	050-099
AP0401		PAC1017-503 PANEL-P19 FWD LTG DISC	285T0019 31967	1	91-04-71 0385/310/L025	150-199, 275-299
AP0403		284T1152-1 PANEL-P19 AFT LTG DISC	285T0019 81205	1	91-04-71 0412/310/L025	050-099
AP0403		PAC1017-503 PANEL-P19 AFT LTS DISC	285T0019 31967	1	91-04-71 0412/310/L025	150-199, 275-299
AP0405		287T4150-211 PANEL-VIDEO TAPE REPRODUCER DISC	287T4334 81205	1	91-04-71 0455/268/L084	050-099, 150-199

EQUIPMENT LIST

D280T132

Section AP0400
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0604		287T4150-207 PANEL MID FWD CEILING DISC	287T4334 81205	1	91-04-71 654+74/280/R018	280-299

EQUIPMENT LIST

D280T132

Section AP0600

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0701		413T3003-1 BRACKET-RETRACTABLE OVHD CLOSET	00000000 81205	2	91-04-71 MULTI/ /	150-199
AP0703		287T4150-163 PNL-MID CABIN CEILING DISC	287T4520 81205	1	91-04-72 0796/292/L005	275-299

EQUIPMENT LIST

D280T132

Section AP0700
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0802D		287T4150-157 PNL-MID CABIN CEILING DISC	287T4520 81205	1	91-04-72 0871/293/R005	150-199, 275-299
AP0802E		287T4150-163 PANEL-MID CABIN CEILING DISC	287T4520 81205	1	91-04-72 0840/292/L005	050-099
AP0810A		287T4150-192 PNL-MID CABIN GALLEY DISC, FWD	287T4520 81205	1	91-04-72 0815/290/R005	150-199, 275-299

EQUIPMENT LIST

D280T132

Section AP0800

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP0901		287T4150-163 PANEL-MID CABIN CEILING DISC (GALLEY)	287T4520 81205	1	91-04-72 0922/292/L005	150-199
AP0902		287T4150-194 PNL-MID CABIN GALLEY DISC, AFT	287T4520 81205	1	91-04-72 0927/290/R005	150-199, 275-299

EQUIPMENT LIST

D280T132

Section AP0900
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP1001	9	284T1322-3 BRACKET - E10 SHELF	284T1318 81205	1	91-04-72 1070/294/L014	150, 153-155, 162-165
AP1001		284T1322-3 BRACKET - E10 SHELF	81205	1	23-25-12 1070/294/L014	150, 153-155, 162-165
AP1001		284T1322-3 BRACKET - E10 SHELF	284T1318 81205	1	91-04-72 1070/294/L014	156-157, 166-199, 277-299
AP1003		PAC1018-501 PANEL-P25 AFT LTG DISC	285T0009 81205	1	91-04-72 1043/310/L025	ALL
AP1005		PAC1018-501 PANEL-P25 FWD LTG DISC	285T0009 81205	1	91-04-72 1021/310/L025	ALL

EQUIPMENT LIST

D280T132

Section AP1000

Page 1 End

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP1101		284T1322-3 BRACKET - E11 SHELF	284T1318 81205	1	91-04-72 1158/294/L014	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section AP1100
Page 1 End
Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP1401		287T4150-119 BRACKET-L S AFT LWR CEILING DISC	287T4604 81205	1	91-04-73 1450/285/L024	ALL
AP1402		287T4150-120 BRACKET-R S AFT LWR CEILING DISC	287T4604 81205	1	91-04-73 1450/285/R024	ALL
AP1404		287T4150-206 PANEL AFT FWD CENTER CEILING DISC	287T4622 81205	1	91-04-71 1438/290/R005	280-299

EQUIPMENT LIST

D280T132

Section AP1400

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AP1501		287T4150-21 PANEL-TAIL DISC	287T4604 81205	1	91-04-73 1550/310/0000	ALL
AP1503		287T4623-1 PANEL-AFT LEFT ATTEND PNL PARTITION DISC	412T3121 81205	1	91-04-73 1544/283/L029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section AP1500
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AV1801		148T8402-21 PANEL-APU DISC	148T8402 81205	1	91-04-91 1832/230/R030	ALL

EQUIPMENT LIST

D280T132

Section AV1800

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW0305		311T3640-85 PANEL-STRUT FWD FW LEFT SIDE DISC	311T3640 81205	2	91-04-83 NR172/125/	ALL
AW0306		311T3640-55 PANEL-STRUT RIGHT SIDE FANCASE FW DISC	311T3640 81205	2	91-04-83 NR174/133/	ALL
AW0307		311T3640-3 PANEL-STRUT FWD FW FRONT DISC	311T3640 81205	2	91-04-83 N0164/130/	ALL
AW0309		311T3510-149 PANEL-STRUT LEFT SIDE FANCASE FWD DISC	311T3510 81205	2	91-04-83 NL110/148/	ALL
AW0310		311T3510-42 PANEL-STRUT RIGHT SIDE FANCASE/COWL DISC	311T3510 81205	2	91-04-83 NL120/150/	ALL
AW0311		311T3510-41 PANEL-STRUT LEFT COWL DISC	311T3510 81205	2	91-04-83 NL120/148/	ALL
AW0312		322U4800 FANCASE-P&W/PW400	322U4800 81205	1	73-21-11 N0103/147/L012	ALL
AW0319		114T6205-5 PANEL-LEFT WING/STRUT DISC	114T6204 81205	1	91-04-81 L0345/14/LE	ALL
AW0320		114T6205-6 PANEL-RIGHT WING/STRUT DISC	114T6204 81205	1	91-04-82 R0345/14/LE	ALL
AW0321		311T3080-75 PANEL-LEFT SIDE WING/SAILBOAT DISC	311T3000 81205	1	91-04-81 NL233/160/	050-099, 275-299
AW0322		311T3080-76 PANEL-RIGHT SIDE WING/SAILBOAT DISC	311T3000 81205	1	91-04-82 NR233/160/	050-099, 275-299

EQUIPMENT LIST

D280T132

Section AW0300

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW0403		114T2230-15 PANEL-L WING FRONT SIDE OUTBD RIB SEAL	114T2230 81205	1	91-04-81 L0416/14/LE	ALL
AW0404		114T2230-15 PANEL-R WING FRONT SIDE OUTBD RIB SEAL	114T2230 81205	1	91-04-82 R0416/14/LE	ALL

EQUIPMENT LIST

D280T132

Section AW0400

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW0601		344T0030-27 PANEL-P28 REFUELING DISC	344T0021 81205	1	91-04-81 L0673/14/FS	ALL

EQUIPMENT LIST

D280T132

Section AW0600
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
AW0901		287T1011-3 PANEL-L WING TIP DISC	112T5360 81205	1	91-04-81 L1140/12/TIP	ALL
AW0902		287T1011-4 PANEL-RIGHT WING TIP DISC	112T5360 81205	1	91-04-82 R1140/12/TIP	ALL

EQUIPMENT LIST

D280T132

Section AW0900

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00001		S222T100-102 SPEAKER-COCKPIT,CAPT	232T4211 54473	1	23-51-11 0159/234/L036	ALL
B00002		S222T100-102 SPEAKER-COCKPIT,F/O	232T4211 54473	1	23-51-21 0159/234/0036	ALL
B00003		64300-000 MIC/HEADSET-BOOM,CAPT	232T4210 28856	1	23-51-11 P015-00/ /	ALL
B00004		64300-000 MIC/HEADSET-BOOM,F/O	232T4210 28856	1	23-51-21 P016-00/ /	ALL
B00006		63999-001 HAND MIC-FIRST OBSERVER	232T4210 22711	1	23-51-41 P061-00/ /	050-099
B00006		63999-001 HAND MIC-FIRST OBSERVER	232T4210 28856	1	23-51-41 P017-00/ /	150-199, 275-299
B00007		HD410-1K HEADPHONE-FIRST OBSERVER	232T4210 SENN	1	23-51-41 P061-00/ /	150-199
B00010	1	S210T170-37 FAN-FORWARD RACK SUPPLY,1	217T1011 81205	1	21-58-14 0402/179/L078	ALL
B00010	2	S210T170-27 FAN-FORWARD RACK SUPPLY,1	217T1011 81205	1	21-58-14 0402/179/L078	ALL
B00012	1	S210T170-37 FAN-FORWARD RACK EXHAUST	217T1012 81205	1	21-58-15 0370/185/R070	ALL
B00012	2	S210T170-27 FAN-FORWARD RACK EXHAUST	217T1012 81205	1	21-58-15 0370/185/R070	ALL
B00013		S210T130-64 FAN-RECIRC,LEFT	214T5001 81205	1	21-25-11 0762/131/L044	ALL
B00014		S210T130-64 FAN-RECIRC,RIGHT	214T5001 81205	1	21-25-21 0752/131/R044	ALL
B00015		60B00027-5 FAN-AFT EQUIP/LAV/GALLEY VENT,NO.1	214T3019 81205	1	21-26-11 1551/149/R013	ALL
B00016		60B00027-5 FAN-AFT EQUIP/LAV/GALLEY VENT,NO.2	214T3019 81205	1	21-26-11 1551/153/R035	ALL
B00017	9	S332T011-21 BOTTLE-FEXT,1 (SB 26-0047)	303T1010 81205	1	26-21-11 0658/155/R073	150-154
B00017		S332T011-21 BOTTLE-FEXT,1	303T1010 81205	1	26-21-11 0708/155/R073	050-099

EQUIPMENT LIST

D280T132

Section B00000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00017		S332T011-21 BOTTLE-FEXT,1	303T1010 81205	1	26-21-11 0659/169/R073	155-199, 275-299
B00018	9	S332T011-21 BOTTLE-FEXT,2 (SB 26-0047)	303T1010 81205	1	26-21-11 0671/155/R073	150-154
B00018		S332T011-21 BOTTLE-FEXT,2	303T1010 81205	1	26-21-11 0715/155/R073	050-099
B00018		S332T011-21 BOTTLE-FEXT,2	303T1010 81205	1	26-21-11 0671/169/R073	155-199, 275-299
B00019	9	S453T201-34 FEXT BTL 1-CAR CMPT,LWR LOBE(SB 26-0047)	453T2501 81205	1	26-23-11 0654+77/155/R073	150-154
B00019		S453T201-33 FEXT BTL 1-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-11 0666/174/R076	050-099
B00019		S453T201-34 FEXT BTL 1-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-11 0654+77/167/R073	155-199
B00019		S453T201-34 FEXT BTL 1-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-11 0654+77/157/R073	275-299
B00020	9	S453T201-35 FEXT BTL 2-CAR COMPT LWR,LOBE(SB26-0047)	453T2501 81205	1	26-23-12 0654+55/158/R073	150-154
B00020		S453T201-28 FEXT BTL 2-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-12 0666/161/R067	050-099
B00020		S453T201-35 FEXT BTL 2-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-12 0654+55/158/R073	155-199
B00020		S453T201-35 FEXT BTL 2-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-12 0654+55/157/R073	275-278
B00020		S453T201-34 FEXT BTL 2-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-12 0654+55/167/R073	280-299
B00025		S332T011-2 BOTTLE-APU FEXT 1	355T5300 81205	1	26-22-21 1821/200/R040	050-099, 150-199
B00025		S332T011-7 BOTTLE-APU FEXT 1	355T5300 81205	1	26-22-21 1821/200/R040	275-276
B00025		S332T011-21 BOTTLE-APU FEXT 1	355T5300 81205	1	26-22-21 1821/200/R040	277-299
B00026		S233T912-1 PROBE-PITOT/STATIC,CAPT	233T9120 04274	1	30-31-11 0201/212/	ALL

EQUIPMENT LIST

D280T132

Section B00000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00027		S233T912-2 PROBE-PITOT/STATIC,R AUX	233T9120 04274	1	30-31-13 0201/182/R065	ALL
B00028		S233T912-2 PROBE-PITOT/STATIC,F/O	233T9120 04274	1	30-31-21 0201/212/	ALL
B00029		S233T912-1 PROBE-PITOT/STATIC,L AUX	233T9120 04274	1	30-31-23 0201/182/	ALL
B00030		2831-2 HEATER-FOOT,CAPT AIR SUPPLY	214T1011 98085	1	21-45-11 0135/181/L013	ALL
B00031		2831-1 HEATER-SHOULDER,CAPT AIR SUPPLY	214T1011 98085	1	21-45-11 0213/195/L063	ALL
B00032		2831-2 HEATER-FOOT,F/O AIR SUPPLY	214T1011 98085	1	21-45-11 0135/177/R013	ALL
B00033		2831-1 HEATER-SHOULDER,F/O AIR SUPPLY	214T1011 98085	1	21-45-11 0166/182/R039	050-099, 162-199, 280-299
B00033		2831-1 HEATER-SHOULDER,F/O AIR SUPPLY	214T1011 98085	1	21-45-11 0176/190/R048	150-157, 275-278
B00035	9	141T4800-21 WINDOW 1-LEFT (SB 30-0027)	141T0011 329250	1	30-41-11 0154/268/L020	ALL
B00035		141T4800-1 WINDOW 1-LEFT	141T0011 329250	1	30-41-11 0154/268/L020	ALL
B00036		141T0012-5003 WINDOW 2-LEFT	141T0012 81670	1	30-41-12 / /	ALL
B00037		141T4820-1 WINDOW 3-LEFT	141T0013 81670	1	30-41-12 / /	ALL
B00038	9	141T4800-21 WINDOW 1-RIGHT (SB 30-0027)	141T0011 329250	1	30-41-12 0154/ /	ALL
B00038		141T4800-2 WINDOW 1-RIGHT	141T0011 329250	1	30-41-12 0154/ /	ALL
B00039		141T0012-5004 WINDOW 2-RIGHT	141T0012 81670	1	30-41-11 / /	ALL
B00040		141T4820-2 WINDOW 3-RIGHT	141T0013 81670	1	30-41-11 / /	ALL
B00041		417T2093-8 (HEATER)-FWD DRAIN MAST	417T2028 81205	1	30-71-11 0641/116/L036	050-099

EQUIPMENT LIST

D280T132

Section B00000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00041		417T2093-2 (HEATER)-FWD DRAIN MAST	417T2028 81205	1	30-71-11 0665/116/L036	150-199
B00041		10-61434-6 (HEATER)-FWD DRAIN MAST	417T2028 81205	1	30-71-11 0665/116/L036	275-299
B00042		417T2093-1 (HEATER)-AFT DRAIN MAST	417T2029 81205	1	30-71-11 1406/111/R025	050-099
B00042		10-61434-5 (HEATER)-AFT DRAIN MAST	417T2029 81205	1	30-71-11 1410/111/R028	150-199, 275-299
B00043		2372-26 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0315/188/L075	ALL
B00044		10-60795-1 HEATER-AFT DRAIN PIPE GASKET	417T1323 81205	1	30-71-23 1575/140/L002	ALL
B00056		S222T100-202 LOUDSPEAKER-AURAL WRN,CAPT	232T4211 81205	1	31-51-31 FLTDK/ /OVHD	ALL
B00057		S222T100-202 LOUDSPEAKER-AURAL WARN,F/O	232T4211 81205	1	31-51-32 FLTDK/ /OVHD	ALL
B00060		430-M1 HORN-GROUND CREW CALL	284T0227 80252	1	23-43-11 0276/154/R025	050-099, 150-199, 275-278
B00060		10-62239-1 HORN-GROUND CREW CALL	284T0227 81205	1	23-43-11 0276/154/R025	280-299
B00061		285N0412-3 HANDSET	284T4201 81205	8	23-42-11 MULTI/ /	050-099, 162-199
B00061		285N0412-3 HANDSET	417T6003 81205	1	23-42-11 FLT DK/ /	150-157, 275-276
B00061		285N0412-3 HANDSET	417T6003 81205	6	23-42-11 MULTI/ /	277-299
B00066		S283T012-17 CABLE ASSY-ANTI-COLL LT,WING TIP	284T0224 81205	2	33-44-21 MULTI/ /	ALL
B00067		S283T012-19 CABLE ASSY-ANTI-COLL LT,UPR	284T0232 81205	1	33-44-11 0555/320/0000	ALL
B00068	9	S283T012-34 CABLE ASSY-ANTI-COLL LT,LWR (SB 33A0075)	284T0232 81205	1	33-44-11 0860/108/0000	050-099, 153-199, 275-299
B00068	9	S283T012-33 CABLE ASSY-ANTI-COLL LT,LWR (SB 33A0075)	284T0232 81205	1	33-44-11 0860/108/0000	150-152

EQUIPMENT LIST

D280T132

Section B00000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00068	8	S283T012-29 CABLE ASSY-ANTI-COLL LT,LWR (SB 33-0030)	284T0232 81205	1	33-44-11 0860/108/0000	150-152
B00068		S283T012-29 CABLE ASSY-ANTI-COLL LT,LWR	284T0232 81205	1	33-44-11 0860/108/0000	050-099, 153-199, 275-299
B00069		S222T101-101 SPEAKER-PSU	400T0001 81205	40	23-31-15 MULTI/ /	050-099
B00069		S222T101-101 SPEAKER-PSU	400T0001 81205	54	23-31-15 MULTI/ /	150-199
B00069		S222T101-101 SPEAKER-PSU	400T0001 81205	63	23-31-15 MULTI/ /	275-299
B00070		10-62232-01 SPEAKER-GALLEY,FWD	411T3126 81205	1	23-31-14 0292/280/R025	ALL
B00072		S222T101-201 SPEAKER-ATTEND,FWD,L	411T3026 81205	1	23-31-14 0420/280/L040	050-099
B00073		S222T101-201 SPEAKER-ATTEND,FWD,R	411T3126 81205	1	23-31-14 0322/280/006	050-099
B00074		S222T101-201 SPEAKER-ATTEND,MID,L	411T3030 81205	1	23-31-14 0810/280/L020	050-099
B00075		S222T101-201 SPEAKER-ATTEND,MID,R	417T3015 81205	1	23-31-14 0810/280/R020	050-099
B00076		S222T101-201 SPEAKER-ATTEND,AFT,L	411T3027 81205	1	23-31-14 1531/280/L023	050-099
B00077		S222T101-201 SPEAKER-ATTEND,AFT,R	411T3027 81205	1	23-31-14 1531/280/R023	050-099
B00078		HD410-1K HEADPHONE-SECOND OBSERVER	233T4210 SENN	1	23-51-41 P063-00/ /	050-099
B00078		HD410-1K HEADPHONE-SECOND OBSERVER	232T4210 SENN	1	23-51-41 P018-00/ /	150-199
B00087		2372-26 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-24 1560/176/L065	050-099
B00087		2372-26 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/176/L065	150-199
B00087		2372-16 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/176/L065	275-299

EQUIPMENT LIST

D280T132

Section B00000

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00088		3043-110-16-80 HEATER TAPE-DRAIN LINE	417T2036 98085	1	30-71-23 1565/156/R040	ALL
B00089		10-61901-19 HEATER BLANKET-WATER TANK, FWD	417T2092 81205	1	30-71-24 1556/171/R027	050-099, 150-199
B00090		2372-24 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0273/191/L075	ALL
B00091		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2033 14604	1	30-71-21 0290/190/L065	050-099
B00091		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2033 14604	1	30-71-21 0290/191/L065	150-199
B00091		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2033 14604	1	30-71-21 0290/191/L075	275-278
B00091		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2033 14604	1	30-71-21 0290/190/L075	280-299
B00092		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2077 14604	1	30-71-22 1021/194/L060	050-099, 275-278
B00092		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2077 14604	1	30-71-22 1021/196/L056	150-199
B00092		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2077 14604	1	30-71-22 1021/196/L060	280-299
B00093		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2036 98085	1	30-71-24 1483/129/R022	050-099
B00093		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2036 98085	1	30-71-23 1480/131/R020	150-199
B00093		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2036 98085	1	30-71-23 1480/129/R022	275-278
B00093		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2036 98085	1	30-71-23 1483/129/R022	280-299
B00095	9	3051-110-35-350 HEATER TAPE-WATER SPLY LINE (SB 30A0018)	417T2036 98085	1	30-71-24 1097/188/L072	150-152
B00095		3051-110-23-216 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1097/188/L072	050-099
B00095		3051-110-35-350 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-24 1097/188/L072	150-199

EQUIPMENT LIST

D280T132

Section B00000

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00096		3043-110-20-140 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 1090/197/L071	050-099
B00096		S417N204-40 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 1087/197/L071	150-199
B00096		3051-110-23-216 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 1090/185/L071	275-299
B00097		2372-24 HEATER TAPE-DRAIN LINE	417T2033 98085	1	30-71-21 0275/192/L075	ALL
B00098		3043-110-20-140 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/176/L065	050-099
B00098		3043-110-20-140 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-24 1560/176/L065	150-199
B00099		3043-110-20-140 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/180/R065	050-099
B00099		3034-110-20-140 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-24 1560/180/R065	150-199

EQUIPMENT LIST

D280T132

Section B00000
Page 7 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00100		2372-26 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-24 1560/158/R042	050-099
B00100		2372-26 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/158/R042	150-199, 275-278
B00100		2372-6 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/158/R042	280-299
B00101		3043-110-8-5-59 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/180/R065	275-276
B00102		2372-26 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/180/R065	050-099, 150-199
B00102		2372-19 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/180/R065	275-276
B00102		2372-14 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/180/R065	277-299
B00103		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2034 98085	1	30-71-21 0630/163/L070	050-099
B00104		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2036 14604	1	30-71-23 1351/170/L070	050-099
B00104		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2036 14604	1	30-71-24 1351/170/L070	150-199
B00105		10-61901-20 CONTROLLER-HEATER BLANKET,WATER TANK	417T2092 81205	1	30-71-24 1574/165/R030	050-099, 150-199
B00107		2372-2 HEATER TAPE-DRAIN LINE	417T2033 98085	1	30-71-21 0322/189/L075	ALL
B00108		3043-110-20-140 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 1090/197/L071	050-099
B00108		S417N204-40 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 1087/197/L071	150-199
B00108		3043-110-25-112 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 1090/197/L071	275-299
B00109		2372-17 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0246/201/R067	ALL
B00110		3051-110-8-8-88 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-24 1498/135/R021	050-099

EQUIPMENT LIST

D280T132

Section B00100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00110		3051-110-8-8-88 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1498/135/R021	150-199
B00110		3043-110-26-182 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1384/118/R022	275-276
B00110		3051-110-8-8-88 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1384/118/R022	277-278
B00110		3043-110-8-8-88 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1384/118/R022	280-299
B00111		3043-110-12-60 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-21 0632/143/L075	050-099
B00112		3043-110-40-280 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/176/L065	050-099, 150-199, 277-299
B00112		3043-110-30-210 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1560/158/R042	275-276
B00113		3043-110-16-80 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-21 0632/143/L075	050-099
B00114		3043-110-6-30 HEATER TAPE-WATER SUPPLY LINE	417T2105 98085	1	30-71-22 0786/183/L007	050-099
B00115		2372-3 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-21 0639/136/L068	050-099
B00115		5417N HEATER TAPE-WATER SUPPLY LINE	417T2105 81205	1	30-71-22 0786/178/L059	275-276, 280-299
B00115		S417N204-40 HEATER TAPE-WATER SUPPLY LINE	417T2105 81205	1	30-71-22 0786/178/L059	277-278
B00116		3043-110-6-30 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0786/187/R020	275-299
B00118		2372-21 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0255/199/L075	ALL
B00119		3051-110-7-1-71 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-21 0639/138/L068	050-099, 150-199, 275-276
B00119		S417N204-76 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-21 0639/138/L068	277-278
B00119		S415N204-76 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-21 0639/138/L068	280-299

EQUIPMENT LIST

D280T132

Section B00100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00120		2372-5 HEATER TAPE-DRAIN LINE	417T2034 98085	1	30-71-21 0639/143/L075	050-099
B00120		2372-5 HEATER TAPE-DRAIN LINE	417T2034 98085	1	30-71-21 0654+121/143/L065	150-199
B00120		2372-5 HEATER TAPE-DRAIN LINE	417T2034 98085	1	30-71-21 0654+121/143/L075	275-276
B00120		2372-5 HEATER TAPE-DRAIN LINE	417T2034 98085	1	30-71-21 0661/143/L075	277-299
B00122		9643 HORN-APU FIRE WARNING	284T0719 80252	1	26-15-12 P040-00/ /	ALL
B00123		606707-1 FAN-VENT,BULK	214T6005 70210	1	21-26-21 1450/195/R035	ALL
B00125		129-6-M06 TEE-COAXIAL CONNECTOR	284T0122 91836	1	34-55-11 SHELF/E02/02	ALL
B00126		10-61901-17 HEATER BLANKET-WATER TANK,MID	417T2092 14346	1	30-71-24 1565/171/R027	050-099, 150-199
B00127		10-61901-18 HEATER BLANKET-WATER TANK,AFT	417T2092 14346	1	30-71-24 1583/161/R033	050-099, 150-199
B00128		60B00027-5 FAN-GASPER	214T4053 81205	1	21-24-11 0619/305/R030	050-099
B00128		60B00027-5 FAN-GASPER	214T4053 81205	1	21-24-11 0686/305/L030	150-199
B00129		FHN20G FUSEHOLDER-EP INTERLOCK	284T0175 96906	1	24-41-11 P034-00/ /	ALL
B00129 T		322001 FUSE-EP INTERLOCK	284T0175 75915	1	24-41-11 P034-00/ /	ALL
B00130		FHN20G FUSEHOLDER-EP INTERLOCK	284T0175 96906	1	24-41-11 P034-00/ /	ALL
B00130 T		322001 FUSE-EP INTERLOCK	284T0175 75915	1	24-41-11 P034-00/ /	ALL
B00131		3043-110-12-60 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0764/178/L062	050-099
B00132	9	S417N204 HEATER TAPE-WATER SPLY LINE (SB 30A0018)	417T2036 98085	1	30-71-23 1365/160/L072	150-152

EQUIPMENT LIST

D280T132

Section B00100

Page 3

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00132		S417N204-44 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1365/160/L072	050-099
B00132		3051-110-23-216 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1365/160/L072	150-199
B00133		2372-26 HEATER TAPE-DRAIN LINE	417T2033 98085	1	30-71-21 0303/190/L075	ALL
B00135		3043-110-7-6-49 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0786/178/L059	050-099
B00136		63999-001 HAND MIC-CAPT	232T4210 28856	1	23-51-11 0172/207/L032	ALL
B00137		63999-001 HAND MIC-F/O	232T4210 28856	1	23-51-21 0172/207/R032	ALL
B00138		S332T011-7 BOTTLE-APU FIRE EXT 2	355T5300 81205	1	26-22-21 / /	275-276
B00138		S332T011-21 BOTTLE-APU FIRE EXT 2	355T5300 81205	1	26-22-21 / /	277-299
B00139		S222T102-101 CHIME-ATTENDANT,FWD CTR	411T3026 54473	1	23-42-12 0315/280/R023	150-157
B00139		S222T102-101 CHIME-ATTENDANT,FWD CTR	411T3026 54473	1	23-42-12 0325/280/R025	162-199
B00139		S222T102-101 CHIME-ATTENDANT,FWD CTR	411T3026 54473	1	23-42-12 0312/280/R020	275-299
B00144		S222T102-101 CHIME-ATTENDANT,FWD LEFT	411T3026 54473	1	23-42-12 0290/280/L045	150-199
B00144		S222T102-101 CHIME-ATTENDANT,FWD LEFT	411T3026 54473	1	23-42-12 0321/280/L006	275-299
B00145		S222T102-101 CHIME-ATTENDANT,MID RIGHT	411T3030 54473	1	23-42-12 0944/280/R019	150-199
B00145		S222T102-101 CHIME-ATTENDANT,MID RIGHT	411T3030 54473	1	23-42-12 0821/280/R017	275-299
B00146		S222T102-101 CHIME-ATTENDANT,MID LEFT	411T3030 54473	1	23-42-12 0944/280/L019	150-199
B00146		S222T102-101 CHIME-ATTENDANT,MID LEFT	411T3030 54473	1	23-42-12 0821/280/L017	275-299

EQUIPMENT LIST

D280T132

Section B00100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00147		S222T102-101 CHIME-ATTENDANT,AFT RIGHT	411T3027 54473	1	23-42-12 1504/280/R025	150-199
B00147		S222T102-101 CHIME-ATTENDANT,AFT RIGHT	411T3027 54473	1	23-42-12 1513/280/R025	275-276, 280-299
B00147		S222T102-101 CHIME-ATTENDANT,AFT RIGHT	411T3027 54473	1	23-42-12 1533/280/R025	277-278
B00148		S222T102-101 CHIME-ATTENDANT,AFT LEFT	411T3027 54473	1	23-42-12 1504/280/L025	150-199
B00148		S222T102-101 CHIME-ATTENDANT,AFT LEFT	411T3027 54473	1	23-42-12 1504/280/L033	275-278
B00148		S222T102-101 CHIME-ATTENDANT,AFT LEFT	411T3027 54473	1	23-42-12 1513/280/L025	280-299
B00149		S417T202-3 HEATER-WATER FILL CONNECTION	417T2091 81205	1	30-71-23 1390/113/L004	050-099, 275-299
B00149		S417T202-3 HEATER-WATER FILL CONNECTION	417T2091 81205	1	30-71-23 1389/117/L005	150-199
B00151		3043-110-26-182 HEATER TAPE-WATER SUPPLY LINE	417T2103 98085	1	30-71-22 1074/180/L070	050-099
B00151		S417N204-44 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 1087/197/L071	150-199
B00158		2372-5 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-24 1498/135/R021	050-099
B00158		2372-5 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1498/135/R021	150-199, 277-299
B00158		3043-110-40-280 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1384/118/R022	275-276
B00159		3043-110-6-30 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0786/197/L056	050-099
B00159		S417N204-45 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0784/197/L060	150-199
B00159		2372-18 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0786/197/L056	275-299
B00160		3043-110-6-30 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0786/194/L056	050-099

EQUIPMENT LIST

D280T132

Section B00100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00160		S417N204-42 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0784/197/L062	150-199
B00160		2372-9 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0786/197/L056	275-299
B00161		S417N204-42 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0784/197/L062	150-199
B00163		64300-000 MIC/HEADSET-BOOM,FIRST OBSERVER	233T4210 28856	1	23-51-41 P061-00/ /	050-099
B00163		64300-000 MIC/HEADSET-BOOM,FIRST OBSERVER	232T4210 28856	1	23-51-41 P061-00/ /	275-299
B00164		2653-4 HEATER TAPE-WATER SUPPLY LINE	417T2105 98085	1	30-71-22 0772/172/L062	050-099
B00164		2372-5 HEATER TAPE-WATER SUPPLY LINE	417T2105 98085	1	30-71-22 0764/178/L062	275-299

EQUIPMENT LIST

D280T132

Section B00100
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00205		2372-23 HEATER TAPE-WATER SUPPLY LINE	417T2105 98085	1	30-71-22 0786/183/L007	050-099
B00212		S417T202-4 HEATER-SERVICE FITTING,WASTE TANK	417T1323 81205	1	30-71-23 1570/140/R003	ALL
B00213		S417T202-4 HEATER-SERVICE FITTING,WASTE TANK	417T1323 81205	1	30-71-23 1575/141/R003	ALL
B00229		S222T101-101 SPEAKER-GALLEY,AFT L	411T3127 81205	1	23-31-14 1564/280/L018	050-099, 150-199, 275-278
B00229		10-62232-01 SPEAKER-GALLEY,AFT L	411T3127 81205	1	23-31-14 1564/280/L018	280-299
B00229	1	10-62232-01 SPEAKER-GALLEY,AFT L	411T3127 81205	1	23-31-14 1564/280/L018	280-299
B00229	2	S222T101-101 SPEAKER-GALLEY,AFT L	411T3127 81205	1	23-31-14 1564/280/L018	280-299
B00230		S222T101-101 SPEAKER-GALLEY,AFT R	411T3027 81205	1	23-31-14 1564/280/R018	050-099, 150-199, 275-278
B00230	1	10-62232-01 SPEAKER-GALLEY,AFT R	411T3027 81205	1	23-31-14 1564/280/R018	280-299
B00230	2	S222T101-101 SPEAKER-GALLEY,AFT R	411T3027 81205	1	23-31-14 1564/280/R018	280-299
B00231		S453T201-34 FEXT BTL 2A-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-12 0687/154/R066	050-099
B00231		S453T201-28 FEXT BTL 2A-CARGO COMPT,LWR LOBE	453T2501 81205	1	26-23-12 0654+33/163/R076	155-199, 275-299
B00233		2372-26 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1546/185/R065	ALL
B00234		2372-19 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0786/197/R060	050-099
B00234		2372-17 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0786/197/R060	275-299
B00235		S222T101-101 SPEAKER-CEILING,AFT L	411T3127 81205	1	23-31-14 1531/280/L027	150-199
B00235		S222T101-101 SPEAKER-CEILING,AFT L	411T3027 81205	1	23-31-14 1531/280/L023	275-299

EQUIPMENT LIST

D280T132

Section B00200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00236		S222T101-101 SPEAKER-CEILING,AFT R	411T3027 81205	1	23-31-14 1531/280/R023	280-299
B00237		3051-110-7-1-71 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1540/158/R062	ALL
B00238	9	2831-37 HEATER-FWD DOOR AREA,LEFT (SB 25-0113)	214T2007 98085	1	21-45-21 0362/288/L041	150-154
B00238		2831-2 HEATER-FWD DOOR AREA,LEFT	214T2007 98085	1	21-45-21 0362/288/L041	050-099, 150-156, 162-166, 275-276
B00238		2831-37 HEATER-FWD DOOR AREA,LEFT	214T2007 98085	1	21-45-21 0362/288/L041	157, 167-199, 277- 299
B00239	9	2831-37 HEATER-FWD DOOR AREA,RIGHT (SB 25-0113)	214T2007 98085	1	21-45-21 0362/288/R041	150-154
B00239	9	3401-01 HEATER-FWD DOOR AREA,RIGHT (SB 21-0139)	214T9028 98085	0	21-45-21 0362/288/R041	275-299
B00239		2831-2 HEATER-FWD DOOR AREA,RIGHT	214T2007 98085	1	21-45-21 0362/288/R041	050-099, 150-156, 162-166
B00239		2831-37 HEATER-FWD DOOR AREA,RIGHT	214T2007 98085	1	21-45-21 0362/288/R041	157, 167-199
B00240		S414N201 SEAT-ATTENDANT,MID	414T2500 53637	1	23-42-11 MULTI/ /	050-099, 150-199
B00241	9	2372-20 HEATER TAPE WATER FILL LINE (SB 30-0024)	417T2036 98085	1	30-71-23 1389/120/0000	150-199, 275-299
B00241		2372-26 HEATER TAPE WATER FILL LINE	417T2036 98085	1	30-71-23 1390/121/R020	ALL
B00243		S222T101-101 SPEAKER-CEILING,MID	411T3030 81205	1	23-31-14 0940/280/0000	150-199
B00243		S222T101-101 SPEAKER-CEILING,MID	411T3030 81205	1	23-31-14 0820/280/L020	275-299
B00246		S222T101-101 SPEAKER-CEILING,FWD L	411T3126 81205	1	23-31-14 0373/280/L036	275-299
B00256		3043-110-6-30 HEATER TAPE-DRAIN LINE	417T2105 98095	1	30-71-22 0786/187/R020	275-299
B00260		3043-110-11-2-67 HEATER TAPE-DRAIN LINE	417T2034 98085	1	30-71-21 0674/138/R067	150-199

EQUIPMENT LIST

D280T132

Section B00200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00264		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2034 14604	1	30-71-21 0658/138/L066	150-199
B00264		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2061 14604	1	30-71-21 0654+121/138/L075	275-299
B00269		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2033 14604	1	30-71-21 0252/205/R075	050-099
B00269		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2033 14604	1	30-71-21 0252/208/R075	150-199
B00269		3100-101-3 THERMOSTAT-CONTROL,HEATER TAPE	417T2033 14604	1	30-71-21 0255/205/R072	275-299
B00270		2372-26 HEATER TAPE-SUPPLY LINE	417T2033 98085	1	30-71-21 0246/201/R067	050-099, 150-199
B00283		141T6665 HEATER-L FWD DR VIEWPORT	141T6100 81205	1	30-46-11 0317/247/L094	ALL
B00284		141T6665 HEATER-R FWD DR VIEWPORT	141T6100 81205	1	30-46-11 0317/247/R094	ALL
B00285		141T6665 HEATER-L AFT DR VIEWPORT	141T6100 81205	1	30-46-11 1510/247/L096	ALL
B00286		141T6665 HEATER-R AFT DR VIEWPORT	141T6100 81205	1	30-46-11 1510/247/R096	ALL
B00289		S222T101-101 SPEAKER-CEILING,FWD L	411T3126 81205	1	23-31-14 0291/280/L021	ALL
B00292		S222T101-101 SPEAKER-CEILING,FWD R	411T3226 81205	1	23-31-14 0415/280/R040	050-099
B00292		S222T101-101 SPEAKER-CEILING,FWD R	411T3126 81205	1	23-31-14 0415/280/R040	150-157
B00292		S222T101-101 SPEAKER-CEILING,FWD R	411T3226 81205	1	23-31-14 0440/280/R040	162-199
B00293		S222T101-101 SPEAKER-CEILING,FWD L	411T3126 81205	1	23-31-14 0415/280/L035	150-157
B00293		S222T101-101 SPEAKER-CEILING,FWD L	411T3226 81205	1	23-31-14 0440/280/L035	162-199
B00294		ME555HST2131-43CC HANDMIC - PASS ADRS	284T4208 HOLMB	1	23-31-11 PURSER/STA/	050-099, 150-199

EQUIPMENT LIST

D280T132

Section B00200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00297	9	129-6-M06 TCAS SUPPRESSION COAX-T (SB 34-0091)	284T0123 91836	1	34-45-11 SHELF/E02/03	150-152
B00297		129-6-M06 TCAS SUPPRESSION COAX-T	284T0123 91836	1	34-45-11 SHELF/E02/03	ALL

EQUIPMENT LIST

D280T132

Section B00200
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00346		3051-110-8-8-88 HEATER TAPE	417T2033 98085	1	30-71-21 315/188/L075	050-099
B00346		3043-110-8-8-88 HEATER TAPE	417T2033 98085	1	30-71-21 315/188/L075	150-199
B00347		3043-110-6-30 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0246/192/L063	050-099, 155-199
B00347		3051-110-7-1-71 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0246/192/L063	150-154
B00350		3051-110-8-8-88 HEATER TAPE	417T2034 98085	1	30-71-21 0687/163/L072	150-199
B00351		3051-110-35-350 HEATER TAPE	417T2034 98085	1	30-71-21 0687/163/L072	150-199
B00353		2372-17 HEATER TAPE	417T2034 98085	1	30-71-21 0654+66/159/L072	150-199
B00356		10-61901-22 HEATER BLANKET,CENTER-WATER TANK	417T2092 14346	1	30-71-24 1450/178/R076	050-099, 150-199
B00357		10-61901-23 HEATER BLANKET,AFT-WATER TANK	417T2092 14346	1	30-71-24 1450/178/R076	050-099, 150-199
B00358		10-61901-24 HEATER BLANKET,FWD-WATER TANK	417T2092 14346	1	30-71-24 1450/178/R076	050-099, 150-199
B00359		10-61901-25 CONTROLLER-HEATER BLANKET,WATER TANK	417T2092 14346	1	30-71-24 1450/178/R076	050-099, 150-199
B00363		2372-18 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0402/176/L070	050-099
B00363		2372-18 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0401/176/L070	150-199
B00364		2372-8 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0402/176/L070	050-099
B00364		2372-8 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0401/176/L070	150-199
B00365		2372-8 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0402/176/L070	050-099
B00365		2372-8 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0401/176/L070	150-199

EQUIPMENT LIST

D280T132

Section B00300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00366		3043-110-11-2-67 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0408/192/L069	050-099, 150-199
B00367		3043-110-20-140 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0784/178/L060	150-199
B00368		3043-110-20-140 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0784/187/0000	150-199
B00369		2372-5 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0786/178/L059	150-199
B00370		2372-3 HEATER TAPE-WATER SUPPLY LINE	417T2105 98085	1	30-71-22 0784/174/L062	150-199
B00371		3051-110-23-216 HEATER TAPE-DRAIN LINE	417T2025 98085	1	30-71-22 0784/186/0000	150-199
B00372		2372-5 HEATER TAPE-WATER SUPPLY	417T2105 98085	1	30-71-22 0786/178/L059	050-099
B00372		3051-110-23-216 HEATER TAPE-WATER SUPPLY	417T2025 98085	1	30-71-22 0784/186/L062	150-199
B00373		2372-19 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-21 0654+64/195/L067	150-199
B00374		S417N204-43 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-21 0674/162/L072	150-199
B00375		S417N204-41 HEATER TAPE-WATER SUPPLY LINE	417T2034 98085	1	30-71-22 0674/194/L062	150-199
B00376		S222T102-101 CHIME-ATTENDANT PURSER	411T3027 54473	1	23-42-12 0438/280/L034	150-199
B00377		S210T130-73 FAN-CARGO VENT,FWD	00000000 70210	1	21-26-31 0693/188/L084	ALL
B00378		S210N701-10 FAN-CGO GND EXH	00000000 70210	1	21-26-31 689/117/R005	050-099
B00378		S210N701-10 FAN-CGO GND EXH	00000000 70210	1	21-26-31 0654+28/117/R005	150-199, 275-299

EQUIPMENT LIST

D280T132

Section B00300

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00406	9	10-60911-66 L ESC HATCH HTR BLKT NO.1 (SB 25-0113)	284T8001 98085	1	21-45-22 0871/230/L089	150-154, 275
B00406		10-60911-66 L ESC HATCH HTR BLKT NO.1	284T8001 98085	1	21-45-22 0872/245/L095	050-099, 155-199, 276-299
B00407	9	10-60911-66 L ESC HATCH HTR BLKT NO.2 (SB 25-0113)	284T8001 98085	1	21-45-22 0915/230/L089	150-154, 275
B00407		10-60911-66 L ESC HATCH HTR BLKT NO.2	284T8001 98085	1	21-45-22 0916/245/L095	155-199, 276-299
B00408	9	10-60911-66 R ESC HATCH HTR BLKT NO.1 (SB 25-0113)	284T8001 98085	1	21-45-22 0871/230/R089	150-154, 275
B00408		10-60911-66 R ESC HATCH HTR BLKT NO.1	284T8001 98085	1	21-45-22 0872/245/R095	050-099, 155-199, 276-299
B00409	9	10-60911-66 R ESC HATCH HTR BLKT NO.2 (SB 25-0113)	284T8001 98085	1	21-45-22 0915/230/R089	150-154, 275
B00409		10-60911-66 R ESC HATCH HTR BLKT NO.2	284T8001 98085	1	21-45-22 0916/245/R095	155-199, 276-299
B00411		3043-110-6-30 HEATER TAPE-WATER SUPPLY LINE	417T2025 98085	1	30-71-22 0786/184/L023	275-299
B00412		3043-110-13-39 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0764/178/L062	275-299
B00413		3043-110-6-21 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0786/178/L059	275-299
B00414		3043-110-13-39 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0786/187/R020	275-299
B00415		3043-110-6-30 HEATER TAPE-WATER SUPPLY LINE	417T2033 98085	1	30-71-21 0246/192/L063	050-099, 155-199
B00416		2100-24 SWITCH	413T3290 91929	1	23-42-11 0255/235/L009	050-099, 162-199
B00417		2100-24 SWITCH	413T3290 91929	1	23-42-11 0255/263/L009	050-099, 162-199
B00418		TDH-8127-3002 RELAY	413T3285 58657	1	23-42-11 0250/275/L010	050-099, 162-199
B00419		TDH-8127-3002 RELAY	413T3285 58657	1	23-42-11 0250/276/L010	050-099, 162-199

EQUIPMENT LIST

D280T132

Section B00400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00420		S222T102-101 CHIME	413T3280 54473	1	23-42-12 0260/279/L012	050-099, 162-199
B00421		3043-110-6-30 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 0786/197/R060	050-099
B00422		3043-110-9-54 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 1072/180/L060	050-099
B00423		2372-11 HEATER TAPE-DRAIN LINE	417T2105 98085	1	30-71-22 1097/188/L072	050-099
B00424		2372-11 HEATER TAPE-WATER SUPPLY LINE	417T2105 98085	1	30-71-22 1097/175/L072	050-099
B00425		S417N204-45 HEATER TAPE-WATER SUPPLY LINE	417T2036 98085	1	30-71-23 1300/164/L072	277-299
B00426		035148 FLT DK CREW REST SUPPLY FAN	214T2059 82877	1	21-66-11 0612/173/L079	050-099, 162-199
B00427		2831-34 HEATER-FWD CABIN CREW REST	214T2058 98085	1	21-66-11 0434/299/L013	050-099, 162-199
B00428		2831-35 HEATER-FWD CABIN CREW REST	214T0001 98085	1	21-66-21 0455/298/R012	050-099, 162-199
B00429	9	2831-35 HEATER-AFT LH CABIN CREW REST	214T0006 98085	1	21-66-31 1428/300/L012	150, 152-157
B00429		2831-35 HEATER-AFT LH CABIN CREW REST	214T0006 98085	1	21-66-31 1428/300/L012	050-099, 162-199
B00430	9	2831-35 HEATER-AFT RH CABIN CREW REST	214T0006 98085	1	21-66-41 1408/300/R012	150, 152-157
B00430		2831-35 HEATER-AFT RH CABIN CREW REST	214T0006 98085	1	21-66-41 1408/300/R012	050-099, 162-199
B00431	9	035147 AFT RH CABIN CREW REST SUPPLY FAN	214T0006 82877	1	21-66-41 1398/298/R012	150, 152-157
B00431		035147 AFT RH CABIN CREW REST SUPPLY FAN	214T0006 82877	1	21-66-41 1398/298/R012	050-099, 162-199
B00432		035147 FWD CABIN CREW REST SUPPLY FAN	214T0001 82877	1	21-66-21 0481/298/R012	050-099, 162-199
B00433	9	035147 AFT LH CABIN CREW REST SUPPLY FAN	214T0006 82877	1	21-66-31 1398/298/L012	150, 152-157

EQUIPMENT LIST

D280T132

Section B00400

Page 2

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B00433		035147 AFT LH CABIN CREW REST SUPPLY FAN	214T0006 82877	1	21-66-31 1398/298/L012	050-099, 150, 152-199
B00467	9	035369500 FAN-LEFT AFT DOOR AREA (SB 21-0111)	214T2006 82877	1	21-45-24 1467/306/L029	050-099, 150-199, 275-277
B00467		035369500 FAN-LEFT AFT DOOR AREA	214T2006 82877	1	21-45-24 1467/306/L029	278-299
B00468	9	035369500 FAN-RIGHT AFT DOOR AREA (SB 21-0111)	214T2006 82877	1	21-45-24 1467/306/R029	050-099, 150-199, 275-277
B00468		035369500 FAN-RIGHT AFT DOOR AREA	214T2006 82877	1	21-45-24 1467/306/R029	278-299
B00469	9	2831-37 HEATER-LEFT AFT DOOR AREA (SB 21-0111)	214T2006 98085	1	21-45-24 1467/304/L037	050-099, 150-199, 275-277
B00469		2831-37 HEATER-LEFT AFT DOOR AREA	214T2006 98085	1	21-45-24 1467/304/L037	278-299
B00470	9	2831-37 HEATER-RIGHT AFT DOOR AREA (SB 21-0111)	214T2006 98085	1	21-45-24 1467/304/R037	050-099, 150-199, 275-277
B00470		2831-37 HEATER-RIGHT AFT DOOR AREA	214T2006 98085	1	21-45-24 1467/304/R037	278-299
B00480	9	3800-32-3 THERMO-CONT,WATER FILL LINE (SB 30-0024)	417T2036 98085	1	30-71-23 1390/121/R020	ALL

EQUIPMENT LIST

D280T132

Section B00400

Page 3 End

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
B09009	9	CUSTOMER CTU COOLING FAN	CUSTOMER CUST	1	23-19-11 412 E90-/90/	150, 152-199

EQUIPMENT LIST

D280T132

Section B09000
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00001		BACC18Z2R CB-AIR DATA AOA SENSOR,L	233T5111 81205	1	34-12-11 P011-01/ /A011	ALL
C00002		BACC18Z2R CB-AIR DATA BARO CORRECTION,L	233T5111 81205	1	34-12-11 P011-01/ /A012	ALL
C00003		BACC18Z2R CB-AIR DATA AOA SENSOR,R	233T5111 81205	1	34-12-21 P011-04/ /F031	ALL
C00004		BACC18Z2R CB-AIR DATA BARO CORRECTION,R	233T5111 81205	1	34-12-21 P011-04/ /F032	ALL
C00005		BACC18U05 CB-APU HOURMETER	284T0997 81205	1	49-72-11 P006-05/ /H028	ALL
C00010		BACC18Z2R CB-DRIVE CONTROL	284T0687 81205	1	25-53-11 P035-00/ /B010	150-199, 275-299
C00011		BACC18Z2R CB-DRIVE CONTROL	284T3901 81205	1	25-53-21 P039-00/ /B010	150-199, 275-299
C00012		BACC18Z7R CB-FWD CARGO EXT LT	284T0687 81205	1	33-31-61 P035-00/ /D008	ALL
C00015		BACC18Z5R CB-FWD CARGO EXT LIGHTS	284T0687 81205	1	33-31-61 P035-00/ /D009	ALL
C00016		BACC18Z7R CB-FWD CAR. DR LTS	284T0687 81205	1	33-31-61 P035-00/ /D006	ALL
C00017		BACC18Z7R CB-AFT CAR. DR LTS	284T0687 81205	1	33-31-61 P039-00/ /D006	ALL
C00018		BACC18Z7R CB-FWD CAR. EXT LT	284T0687 81205	1	33-31-61 P035-00/ /D007	ALL
C00019		BACC18Z7R CB-AFT CAR. EXT LT	284T0687 81205	1	33-31-61 P039-00/ /D007	ALL
C00020		BACC18Z3R CB-APU START	284T1149 81205	1	49-61-11 P049-00/ /C003	ALL
C00021		BACC18Z10R CB-FWD A CARGO COMPT LTS	284T0687 81205	1	33-37-11 P035-00/ /D003	ALL
C00022		BACC18Z10R CB-FWD B CARGO COMPT LTS	284T0687 81205	1	33-37-11 P035-00/ /D004	ALL
C00023		BACC18Z7R CB-FWD CARGO DOOR LT	284T0687 81205	1	33-37-11 P035-00/ /D005	ALL

EQUIPMENT LIST

D280T132

Section C00000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00024		BACC18Z3R CB-BULK CARGO EXT LIGHTS	284T0688 81205	1	33-31-61 P039-00/ /D008	050-099, 150-199
C00025		BACC18Z5R CB-AFT CARGO EXT LIGHTS	284T0688 81205	1	33-31-61 P039-00/ /D009	ALL
C00036		BACC18AC7 CB-PDU 1L/6L	284T0688 81205	1	25-53-21 P039-00/ /C002	050-099
C00037		BACC18AC7 CB-PDU 2L/4L/8L	284T0688 81205	1	25-53-21 P039-00/ /C004	050-099
C00038		BACC18AC7 CB-PDU 3L/5L	284T0688 81205	1	25-53-21 P039-00/ /C006	050-099
C00039		BACC18AC7 CB-PDU 7L/9L	284T0688 81205	1	25-53-21 P039-00/ /C009	050-099
C00040		BACC18AC7 CB-PDU 1R/6R	284T0688 81205	1	25-53-21 P039-00/ /B002	050-099
C00041		BACC18AC7 CB-PDU 2R/4R/8R	284T0688 81205	1	25-53-21 P039-00/ /B004	050-099
C00042		BACC18AC7 CB-PDU 3R/5R/6C	284T0688 81205	1	25-53-21 P039-00/ /B006	050-099
C00043		BACC18AC7 CB-PDU 7R/9R	284T0688 81205	1	25-53-21 P039-00/ /B008	050-099
C00045		BACC18Z2R CB-LAT GUIDES	284T0687 81205	1	25-53-11 P035-00/ /D002	ALL
C00046		BACC18Z2R CB-ACTR,LAT GUIDES	284T3901 81205	1	25-53-21 P039-00/ /D002	ALL
C00049		BACC18Z2R CB-ROLLOUT STOPS/CTR GUIDES	284T3501 81205	1	25-53-11 P035-00/ /D001	ALL
C00050		BACC18Z2R CB-ACTR,ROLLOUT STOPS/CTR GUIDES	284T3901 81205	1	25-53-21 P039-00/ /D001	050-099, 150-199
C00053		10-60806-1025 CB-LEFT PDU/GUIDES	284T3501 81205	1	25-53-11 P035-00/ /A006	ALL
C00054		10-60806-1025 CB-RIGHT PDU	284T3501 81205	1	25-53-11 P035-00/ /A009	ALL
C00055		10-60806-1025 CB-LEFT PDU/GUIDES	284T3901 81205	1	25-53-21 P039-00/ /A006	ALL

EQUIPMENT LIST

D280T132

Section C00000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00056		10-60806-1025 CB-RIGHT PDU	284T3901 81205	1	25-53-21 P039-00/ /A009	ALL
C00060		BACC18Z1R CB-BLOWER 1 SMOKE DET FWD CAR.	284T0687 81205	1	26-16-21 P035-00/ /A001	ALL
C00061		BACC18Z1R CB-BLOWER 2 SMOKE DET FWD CAR.	284T0687 81205	1	26-16-21 P035-00/ /A002	ALL
C00062		BACC18Z1R CB-BLOWER 1 SMOKE DET AFT CAR.	284T0687 81205	1	26-16-21 P035-00/ /A003	ALL
C00063		BACC18Z1R CB-BLOWER 2 SMOKE DET AFT CAR.	284T0687 81205	1	26-16-21 P035-00/ /A004	ALL
C00064		BACC18Z5R CB-AFT CARGO DOOR LT	284T0688 81205	1	33-37-21 P039-00/ /D005	ALL
C00065		BACC18Z10R CB-AFT A CARGO COMPT LTS	284T0688 81205	1	33-37-21 P039-00/ /D003	ALL
C00066		BACC18Z10R CB-AFT B CARGO COMPT LTS	284T0688 81205	1	33-37-21 P039-00/ /D004	ALL
C00070		BACC18Z02R CB-L TANK DEFUEL VALVE	284T0187 81205	1	28-26-11 P036-00/ /E005	ALL
C00071		BACC18Z02R CB-R TANK DEFUEL VALVE	284T0187 81205	1	28-26-11 P036-00/ /E006	ALL
C00075		BACC18Z2R CB-CONTROL SWITCH	284T3901 81205	1	25-53-21 P039-00/ /C010	ALL
C00076		BACC18Z2R CB-CONTROL SWITCH	284T0687 81205	1	25-53-11 P035-00/ /C010	ALL
C00077		BACC18Z2R CB-CONTROL SWITCH	284T0687 81205	1	25-53-11 P035-00/ /D010	ALL
C00078		BACC18Z2R CB-DRIVE CONTROL	284T0688 81205	1	25-53-21 P039-00/ /D010	050-099
C00078		BACC18Z3R CB-DRIVE CONTROL	284T3901 81205	1	25-53-21 P039-00/ /D010	150-199, 275-299
C00081		BACC18AC7 CB-PDU 1R/8R/11R	284T0687 81205	1	25-53-11 P035-00/ /B002	050-099
C00082		BACC18AC7 CB-PDU 2R/6R/10R	284T0687 81205	1	25-53-11 P035-00/ /B004	050-099

EQUIPMENT LIST

D280T132

Section C00000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00083		BACC18AC7 CB-PDU 3R/5R/9R	284T0687 81205	1	25-53-11 P035-00/ /B006	050-099
C00084		BACC18AC7 CB-PDU 4R/7R/8C	284T0687 81205	1	25-53-11 P035-00/ /B008	050-099
C00085		BACC18AC7 CB-PDU 1L/8L/11L	284T0687 81205	1	25-53-11 P035-00/ /C002	050-099
C00086		BACC18AC7 CB-PDU 2L/6L/10L	284T0687 81205	1	25-53-11 P035-00/ /C004	050-099
C00087		BACC18AC7 CB-PDU 3L/5L/9L	284T0687 81205	1	25-53-11 P035-00/ /C006	050-099
C00088		BACC18AC7 CB-PDU 4L/7L/5C	284T0687 81205	1	25-53-11 P035-00/ /C008	050-099
C00089		BACC18AC2 CB-TRU FAN	284T1149 81205	1	24-32-41 P049-00/ /D003	275-299
C00094	9	BACC18Z02R CB-FUELING PANEL LIGHT (SB 28-0031)	284T3601 81205	1	28-21-11 P036-00/ /E006	050-099, 150-156, 162-166, 275-276
C00094		BACC18Z02R CB-FUELING PANEL LIGHT	284T0187 81205	1	28-21-11 P036-00/ /E007	157, 167-199
C00094		BACC18Z02R CB-FUELING PANEL LIGHT	284T0187 81205	1	28-21-11 P036-00/ /D002	277-299

EQUIPMENT LIST

D280T132

Section C00000
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00102		BACC18Z2R CB-SECONDARY IND LT,L2 PILOTS	284T0997 81205	1	33-16-12 P006-05/ /L030	ALL
C00103		BACC18Z2R CB-SECONDARY IND LT,L3 PILOTS	284T0997 81205	1	33-16-12 P006-05/ /L032	ALL
C00104		BACC18Z2R CB-SECONDARY IND LT,L PILOTS AUTOBRIGHT	284T0997 81205	1	33-16-12 P006-05/ /L029	ALL
C00106		BACC18Z2R CB-SECONDARY IND LT,R2 PILOTS	284T0997 81205	1	33-16-12 P006-05/ /K029	ALL
C00107		BACC18Z2R CB-SECONDARY IND LT,R3 PILOTS	284T0997 81205	1	33-16-12 P006-05/ /K032	ALL
C00108		BACC18Z2R CB-SECONDARY IND LT,R PILOTS AUTOBRIGHT	284T0997 81205	1	33-16-12 P006-05/ /K028	ALL
C00109		BACC18Z2R CB-SECONDARY IND LT,BAT.1 PILOTS	284T0997 81205	1	33-16-12 P006-05/ /J026	ALL
C00110		BACC18Z2R CB-SECONDARY IND LT,BAT.2 PILOTS	284T0997 81205	1	33-16-12 P006-05/ /J029	ALL
C00112		BACC18Z2R CB-SEC IND LT,BAT. PILOTS AUTOBRIGHT	284T0997 81205	1	33-16-12 P006-05/ /J031	ALL
C00116		BACC18Z2R CB-SECONDARY,IND LT L1 RT SIDE PNL	284T0997 81205	1	33-16-22 P006-05/ /L028	ALL
C00117		BACC18Z2R CB-SECONDARY,IND LT L2 RT SIDE PNL	284T0997 81205	1	33-16-22 P006-05/ /L031	ALL
C00119		BACC18Z2R CB-SECONDARY,IND LT R1 RT SIDE PNL	284T0997 81205	1	33-16-22 P006-05/ /K027	ALL
C00120		BACC18Z2R CB-SECONDARY,IND LT R2 RT SIDE PNL	284T0997 81205	1	33-16-22 P006-05/ /K030	ALL
C00122		BACC18Z2R CB-SECONDARY,IND LT BAT.1 RT SIDE PNL	284T0997 81205	1	33-16-22 P006-05/ /J027	ALL
C00123		BACC18Z2R CB-SECONDARY,IND LT BAT.2 RT SIDE PNL	284T0997 81205	1	33-16-22 P006-05/ /J030	ALL
C00125		BACC18Z1R CB-BUS POWER CONTROL UNIT IND LT	284T0997 81205	1	33-16-22 P006-05/ /H026	ALL
C00158		BACC18AC7 CB-PDU 1R/5R/10R	284T3901 81205	1	25-53-21 P039-00/ /B002	150-199, 275-299

EQUIPMENT LIST

D280T132

Section C00100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00159		BACC18AC7 CB-PDU 2R/6R/12R/9C	284T3901 81205	1	25-53-21 P039-00/ /B004	150-199, 275-299
C00160		BACC18AC7 CB-PDU 3R/7R/9R	284T3901 81205	1	25-53-21 P039-00/ /B006	150-199, 275-299
C00161		BACC18AC7 CB-PDU 4R/8R/11R	284T3901 81205	1	25-53-21 P039-00/ /B009	150-199, 275-299
C00162		BACC18AC7 CB-PDU 1L/5L/10L	284T3901 81205	1	25-53-21 P039-00/ /D002	150-199, 275-299
C00163		BACC18AC7 CB-PDU 2L/6L/12L	284T3901 81205	1	25-53-21 P039-00/ /C004	150-199, 275-299
C00164		BACC18AC7 CB-PDU 3L/7L/9L	284T3901 81205	1	25-53-21 P039-00/ /D006	150-199, 275-299
C00165		BACC18AC7 CB-PDU 4L/8L/11L	284T3901 81205	1	25-53-21 P039-00/ /D009	150-199, 275-299
C00166		BACC18AC7 CB-PDU 1R/4R/7R/13R	284T3501 81205	1	25-53-11 P035-00/ /B002	150-199, 275-299
C00167		BACC18AC7 CB-PDU 2R/8R/10R/14R	284T3501 81205	1	25-53-11 P035-00/ /B004	150-199, 275-299
C00168		BACC18AC7 CB-PDU 3R/5R/6R/11R	284T3501 81205	1	25-53-11 P035-00/ /B006	150-199, 275-299
C00169		BACC18AC7 CB-PDU 5C/9R/12R	284T3501 81205	1	25-53-11 P035-00/ /B009	150-199, 275-299
C00170		BACC18AC7 CB-PDU 1L/4L/7L/13L	284T3501 81205	1	25-53-11 P035-00/ /C002	150-199, 275-299
C00171		BACC18AC7 CB-PDU 2L/8L/10L/14L	284T3501 81205	1	25-53-11 P035-00/ /C004	150-199, 275-299
C00172		BACC18AC7 CB-PDU 3L/5L/6L/11L	284T3501 81205	1	25-53-11 P035-00/ /C006	150-199, 275-299
C00173		BACC18AC7 CB-PDU 8C/9L/12L	284T3501 81205	1	25-53-11 P035-00/ /C009	150-199, 275-299

EQUIPMENT LIST

D280T132

Section C00100
Page 2 End
Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00301		BACC18AC7 CB-MAIN BAT. CHGR	284T0189 81205	1	24-31-11 P033-00/ /E002	ALL
C00302		BACC18AC7 CB-CHARGER,APU BAT.	284T0189 81205	1	24-31-41 P033-00/ /E005	ALL
C00303		10-60806-1035 CB-TRU APU START	284T0172 81205	1	24-32-41 P032-00/ /	275-299
C00304		BACC18AC3 CB-GND HDLG TRU	284T0175 81205	1	24-54-61 P034-00/ /M003	ALL
C00306		10-60806-1050 CB-EXT PWR GND SVCE BUS	284T0175 81205	1	24-51-52 P034-00/ /C010	ALL
C00307		BACC18AE15 CB-115V AC BUS RIGHT SECT 2	284T0997 81205	1	24-51-21 P006-04/ /A024	ALL
C00308		BACC18AE15 CB-115V AC BUS LEFT SECT 2	284T0997 81205	1	24-51-11 P006-03/ /A018	ALL
C00309		10-60806-1025 CB-115V AC GND HDLG BUS	284T0175 81205	1	24-51-61 P034-00/ /B019	ALL
C00310		10-60806-1050 CB-115V AC BUS LEFT SECT 4	284T0171 81205	1	24-51-12 P031-00/ /	ALL
C00311		10-60806-1050 CB-UTILITY BUS LEFT	284T0171 81205	1	24-51-13 P031-00/ /	ALL
C00312		10-60806-1020 CB-TRU,LEFT	284T0997 81205	1	24-32-11 P006-03/ /C018	ALL
C00313		BACC18AE25 CB-115V AC BUS LEFT SECT 1	284T0997 81205	1	24-51-11 P006-03/ /C015	ALL
C00314		BACC18AC10 CB-PASS. SERVICE OUTLETS	284T0997 81205	1	25-29-11 P006-04/ /L024	ALL
C00315		10-60806-1050 CB-UTILITY BUS RIGHT	284T0172 81205	1	24-51-23 P032-00/ /	ALL
C00316		10-60806-1050 CB-GND SVCE BUS	284T0172 81205	1	24-51-52 P032-00/ /	ALL
C00317		10-60806-1050 CB-115V AC BUS RIGHT SECT 4	284T0172 81205	1	24-51-22 P032-00/ /	ALL
C00318		10-60806-1020 CB-TRU,RIGHT	284T0997 81205	1	24-32-11 P006-04/ /C024	ALL

EQUIPMENT LIST

D280T132

Section C00300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00319		BACC18AE25 CB-115V AC BUS RIGHT SECT 1	284T0997 81205	1	24-51-21 P006-04/ /C021	ALL
C00320		BACC18AC3 CB-EXT PWR BPCU	284T0175 81205	1	24-41-11 P034-00/ /M006	ALL
C00321	9	BACC18AE25 CB-GND SERVICE BUS DISTR-P6 (SB 78-0062)	284T0189 81205	1	24-51-52 P033-00/ /B007	ALL
C00321		10-60806-1025 CB-GROUND SERVICE BUS DISTR-P6	284T0189 81205	1	24-51-52 P033-00/ /B007	ALL
C00322		10-60806-1050 CB-APU GND SVCE BUS	284T0175 81205	1	24-51-52 P034-00/ /B016	ALL
C00323		BACC18AE15 CB-ALT FLAP PWR	284T0997 81205	1	27-51-11 P006-04/ /D024	ALL
C00324		BACC18AC3 CB-ALT SLAT INBD PWR	284T0997 81205	1	27-81-11 P006-04/ /D021	ALL
C00325		BACC18AC10 CB-ALT SLAT OUTBD PWR	284T0997 81205	1	27-81-21 P006-04/ /F024	ALL
C00326		10-60806-1020 CB-115V AC L XFR BUS	284T0997 81205	1	24-51-14 P006-03/ /D015	ALL
C00327		BACC18AC10 CB-115V AC R XFR BUS	284T0997 81205	1	24-51-24 P006-03/ /F018	ALL
C00328		10-60806-1050 CB-115V AC BUS L SECT 3	284T0997 81205	1	24-51-11 P006-03/ /A015	ALL
C00329		10-60806-1050 CB-115V AC BUS RIGHT SECT 3	284T0997 81205	1	24-51-21 P006-04/ /A021	ALL
C00331		10-60806-1015 CB-EQUIP COOL FAN SPLY 1	284T0997 81205	1	21-58-14 P006-03/ /H018	ALL
C00333		10-60806-1010 CB-EQUIP COOL AFT FAN 1	284T0189 81205	1	21-26-11 P033-00/ /B001	ALL
C00334		10-60806-1010 CB-EQUIP COOL AFT FAN 2	284T0187 81205	1	21-26-11 P036-00/ /G004	ALL
C00335		10-60806-1015 CB-EQUIP COOL FAN FWD EXH	284T0997 81205	1	21-58-15 P006-04/ /H021	ALL
C00336		10-60806-1025 CB-RECIRC FAN,LEFT	284T0187 81205	1	21-25-11 P036-00/ /F002	ALL

EQUIPMENT LIST

D280T132

Section C00300

Page 2

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00337		10-60806-1025 CB-RECIRC FAN,RIGHT	284T0188 81205	1	21-25-21 P037-00/ /G004	ALL
C00340		BACC18AC5 CB-HF COMM,LEFT	233T5111 81205	1	23-11-11 P011-02/ /G008	ALL
C00341		BACC18AC5 CB-HF COMM,RIGHT	233T5111 81205	1	23-11-21 P011-05/ /G035	ALL
C00342		BACC18AC10 CB-GASPER FAN	284T0187 81205	1	21-24-11 P036-00/ /E002	050-099, 150-199
C00343		BACC18AC5 CB-FWD DR AREA HTR-PWR	284T0187 81205	1	21-45-21 P036-00/ /A002	050-099, 150-156, 162-166, 275-276
C00343		BACC18AC7 CB-FWD DR AREA HTR-PWR	284T0187 81205	1	21-45-21 P036-00/ /A002	157, 167-199, 277- 299
C00344		BACC18AC5 CB-CARGO VENT FAN,BULK	284T0188 81205	1	21-26-21 P037-00/ /E006	ALL
C00350		10-60806-1050 CB-CARGO HDLG-FWD	284T0175 81205	1	25-53-11 P034-00/ /A016	ALL
C00351		10-60806-1050 CB-CARGO HDLG-AFT	284T3400 81205	1	25-53-21 P034-00/ /B019	ALL
C00354		BACC18AC5 CB-SEAT,CAPTAIN	284T0997 81205	1	25-11-11 P006-03/ /H015	ALL
C00355		BACC18AC5 CB-SEAT,FIRST OFFICER	284T0997 81205	1	25-11-21 P006-04/ /J021	ALL
C00358		BACC18AC5 CB-CARGO VENT FAN,FWD (INOP)	284T0188 81205	1	21-26-31 P037-00/ /J003	050-099, 150-199
C00358		10-60806-1005 CB-CARGO VENT FAN,FWD (INOP)	284T0188 81205	1	21-26-31 P037-00/ /C007	275-299
C00359	9	BACC18AC5 CB-CARGO GND EXH FAN (TO 210210)	284T0188 81205	1	21-26-31 P037-00/ /J006	150
C00359		BACC18AC5 CB-CARGO GND EXH FAN	284T0188 81205	1	21-26-31 P037-00/ /J006	050-099, 151-199
C00359		10-60806-1005 CB-CARGO GND EXH FAN	284T0188 81205	1	21-26-31 P037-00/ /C004	275-299
C00360		BACC18AC7 CB-CARGO DOOR,FWD	284T0175 81205	1	52-34-11 P034-00/ /J007	ALL

EQUIPMENT LIST

D280T132

Section C00300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00361		BACC18AC7 CB-CARGO DOOR,AFT	284T0175 81205	1	52-35-11 P034-00/ /J010	ALL
C00363		BACC18AC3 CB-ENTRY DR,FWD	284T0189 81205	1	52-11-11 P033-00/ /F006	ALL
C00366		BACC18AC10 CB-FUEL BOOST PUMP,L AFT	284T0997 81205	1	28-22-11 P006-03/ /G015	ALL
C00368		BACC18AC10 CB-FUEL BOOST PUMP,R FWD	284T0997 81205	1	28-22-11 P006-03/ /G018	ALL
C00369		BACC18AE15 CB-FUEL OVRD PUMP,LEFT	284T0997 81205	1	28-22-12 P006-03/ /F015	ALL
C00370		BACC18AE15 CB-FUEL OVRD PUMP,RIGHT	284T0997 81205	1	28-22-12 P006-04/ /F021	ALL
C00371		BACC18AC10 CB-FUEL BOOST PUMP,R AFT	284T0997 81205	1	28-22-11 P006-04/ /G021	ALL
C00372		BACC18AC10 CB-FUEL BOOST PUMP,L FWD	284T0997 81205	1	28-22-11 P006-04/ /G024	ALL
C00375		10-60806-1015 CB-FUEL JTSN PUMP-LEFT (INOP)	284T0187 81205	1	28-31-21 P036-00/ /F004	050-099, 155-199, 277-299
C00376		10-60806-1015 CB-FUEL JTSN PUMP-RIGHT (INOP)	284T0188 81205	1	28-31-21 P037-00/ /F004	050-099, 155-199, 276-299
C00379	9	BACC18AC10 CB-AFT DOOR AREA HEATER PWR (SB 21-0111)	284T8703 81205	1	21-45-24 P087-00/ /B003	050-099, 150-199, 275-277
C00379		BACC18AC10 CB-AFT DOOR AREA HEATER POWER	284T8703 81205	1	21-45-24 P087-00/ /B003	278-299
C00388		10-60806-1020 CB-VACUUM BLOWER LAV SYSTEM 2	284T0188 81205	1	38-32-11 P037-00/ /G007	ALL
C00389		10-60806-1020 CB-VACUUM BLOWER LAV SYSTEM 1	284T0187 81205	1	38-32-11 P036-00/ /F007	ALL
C00391		BACC18AE25 CB-WINDOW HT NO.1,LEFT	284T0187 81205	1	30-41-11 P036-00/ /L005	ALL
C00392		BACC18AE25 CB-WINDOW HT NO.1,RIGHT	284T0188 81205	1	30-41-12 P037-00/ /D002	ALL
C00397		BACC18AC7 CB-AIR COMPRESSOR,WATER SYSTEM	284T0189 81205	1	38-15-11 P033-00/ /H006	ALL

EQUIPMENT LIST

D280T132

Section C00300
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00400		BACC18AC5 CB-FLT DK CREW REST HEAT	284T0187 81205	1	21-66-11 P036-00/ /C004	050-099, 162-199
C00401		BACC18AC2 CB-FLT DK CREW REST FAN	284T0187 81205	1	21-66-11 P036-00/ /C007	050-099, 162-199
C00402		BACC18AC5 CB-FWD CABIN CREW REST HEAT CONT	284T0188 81205	1	21-66-21 P037-00/ /B004	050-099, 162-199
C00403	9	BACC4518AC5 CB-AFT LH CABIN CREW REST HEAT	81205	1	21-66-31 P036-00/ /C007	150, 152-157
C00403		BACC18AC5 CB-AFT LH CABIN CREW REST HEAT	284T0187 81205	1	21-66-31 P036-00/ /B004	050-099, 162-199
■ C00404	9	BACC18AC5 CB-AFT RH CABIN CREW REST HEAT	81205	1	21-66-41 P037-00/ /B007	150, 152-157
■ C00404	9	BACC18AC5 CB-AFT RH CABIN CREW REST HEAT	284T0188 81205	1	21-66-41 P037-00/ /B007	150, 152-157
C00404		BACC18AC5 CB-AFT RH CABIN CREW REST HEAT	284T0188 81205	1	21-66-41 P037-00/ /B007	050-099, 162-199
C00405		BACC18AC2 CB-FWD CABIN CREW REST FAN	284T0188 81205	1	21-66-21 P037-00/ /C004	050-099, 162-199
C00406	9	BACC18AC2 CB-AFT LH CABIN CREW REST FAN	81205	1	21-66-31 P036-00/ /C004	150, 152-157
C00406		BACC18AC2 CB-AFT LH CABIN CREW REST FAN	284T0187 81205	1	21-66-31 P036-00/ /B001	050-099, 162-199
C00407	9	BACC18AC2 CB-AFT RH CABIN CREW REST FAN	81205	1	21-55-41 P037-00/ /C007	150, 152-157
C00407	9	BACC18AC2 CB-AFT RH CABIN CREW REST FAN	284T0188 81205	1	21-66-41 P037-00/ /C004	150, 152-157
C00407		BACC18AC2 CB-AFT RH CABIN CREW REST FAN	284T0188 81205	1	21-66-41 P037-00/ /C007	050-099, 162-199
C00408	9	BACC18AC2 CB-L AFT DOOR AREA FAN PWR (SB 21-0111)	284T8703 81205	1	21-45-24 P087-00/ /B004	050-099, 150-199, 275-277
C00408		BACC18AC2 CB-LEFT AFT DOOR AREA FAN POWER	284T8703 81205	1	21-45-24 P087-00/ /B004	278-299
C00409	9	BACC18AC2 CB-R AFT DOOR AREA FAN PWR (SB 21-0111)	284T8703 81205	1	21-45-24 P087-00/ /A001	050-099, 150-199, 275-277

EQUIPMENT LIST

D280T132

Section C00400

Page 1

Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00409		BACC18AC2 CB-RIGHT AFT DOOR AREA FAN POWER	284T8703 81205	1	21-45-24 P087-00/ /A001	278-299

EQUIPMENT LIST

D280T132

Section C00400
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00501		BACC18Z2R CB-TMC AC	233T5111 81205	1	22-31-11 P011-01/ /F014	ALL
C00506	9	BACC18Z7R CB-SATCOM (MTO-238591/2/3)	233T5100 81205	1	23-25-11 P011-02/ /H008	150, 153-155, 162- 165, 167-199
C00506	9	BACC18Z7R CB-SATCOM (INOP) (MTO-238591/2/3)	233T5100 81205	1	23-25-11 P011-02/ /H008	156-157, 166
C00506		BACC18Z7R CB-SATCOM (INOP)	233T5111 81205	1	23-25-11 P011-02/ /H008	156-157, 166
C00506		BACC18Z7R CB-SATCOM	233T5100 81205	1	23-25-11 P011-02/ /H008	277-299
C00507		BACC18X15 CB-PSUD MID,C	284T0189 81205	1	23-34-17 P033-00/ /A005	280-299
C00512		BACC18Z5R CB-TMC SERVO	233T5111 81205	1	22-31-12 P011-01/ /F016	ALL
C00513		BACC18Z2R CB-FLT CONT CMPTR PWR,LEFT	233T5111 81205	1	22-11-11 P011-01/ /E017	ALL
C00514		BACC18Z2R CB-FLT CONT CMPTR PWR,R	233T5111 81205	1	22-11-21 P011-04/ /E035	ALL
C00515		BACC18Z2R CB-FLT CONT CMPTR PWR,C	233T5111 81205	1	22-11-31 P011-04/ /E020	ALL
C00516		BACC18Z2R CB-MODE CONT PNL,LEFT	233T5111 81205	1	22-11-12 P011-01/ /E016	ALL
C00517		BACC18Z2R CB-MODE CONT PNL,R	233T5111 81205	1	22-11-22 P011-04/ /E034	ALL
C00520		BACC18Z2R CB-MAINT CONT DSPL	233T5111 81205	1	22-41-12 P011-03/ /U009	ALL
C00521		BACC18Z2R CB-AUTO FLIGHT WARN	233T5111 81205	1	22-11-32 P011-01/ /A017	ALL
C00522		BACC18Z5R CB-FLT CONT CMPTR SERVO,LEFT	233T5111 81205	1	22-11-12 P011-01/ /E018	ALL
C00523		BACC18Z5R CB-FLT CONT CMPTR SERVO,RIGHT	233T5111 81205	1	22-11-22 P011-04/ /E036	ALL
C00524		BACC18Z5R CB-FLT CONT CMPTR SERVO,C	233T5111 81205	1	22-11-32 P011-04/ /E021	ALL

EQUIPMENT LIST

D280T132

Section C00500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00525		BACC18Z5R CB-TMC DC	233T5111 81205	1	22-31-12 P011-01/ /F015	ALL
C00530		BACC18Z10R CB-PSUD FWD,L	284T0187 81205	1	23-34-16 P036-00/ /J003	ALL
C00531		BACC18X15 CB-PSUD FWD,C	284T0189 81205	1	23-34-11 P033-00/ /A004	050-099
C00531		BACC18X15 CB-PSUD FWD,C	284T0189 81205	1	23-34-17 P033-00/ /A004	150-199, 275-299
C00532		BACC18Z5R CB-VOICE RECORDER	233T5111 81205	1	23-71-11 P011-05/ /H034	ALL
C00533		BACC18Z10R CB-PSUD FWD,R	284T0187 81205	1	23-34-15 P036-00/ /J001	ALL
C00534		BACC18Z2R CB-ANNCT,PRE-RECD	284T0187 81205	1	23-31-12 P036-00/ /J007	ALL
C00535		BACC18Z7R CB-PSUD AFT,L	284T0187 81205	1	23-34-18 P036-00/ /J004	050-099
C00535		BACC18Z10R CB-PSUD AFT,L	284T0187 81205	1	23-34-18 P036-00/ /J004	150-199
C00535		BACC18Z10R CB-PSUD AFT,L	284T0187 81205	1	23-34-11 P036-00/ /J004	275-299
C00536		BACC18X15 CB-PSUD AFT,C	284T0189 81205	1	23-34-11 P033-00/ /A003	050-099, 275-299
C00536		BACC18X15 CB-PSUD AFT,C	284T0189 81205	1	23-34-19 P033-00/ /A003	150-199
C00538	9	SAS CB ACARS, DC PWR	CUSTOMER 81205	0	23-22-11 P006-01/ /G5	150, 152-166, 275-299
C00538		BACC18Z1R CB-ACARS,DC PWR (INOP)	284T0997 81205	1	23-22-11 P006-01/ /G005	050-099, 151, 275-299
C00538		BACC18Z1R CB-ACARS,DC PWR	284T0997 81205	1	23-22-11 P006-01/ /G005	167-199
C00539		BACC18Z02R CB-SELCAL	233T5111 81205	1	23-21-11 P011-02/ /G003	ALL
C00540		BACC18Z5R CB-VIDEO PROJECTION	233T5111 81205	1	23-32-11 P011-06/ /T034	ALL

EQUIPMENT LIST

D280T132

Section C00500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00541		BACC18Z7R CB-PSUD AFT,R	284T0187 81205	1	23-34-18 P036-00/ /J002	050-099
C00541		BACC18Z10R CB-PSUD AFT,R	284T0187 81205	1	23-34-18 P036-00/ /J002	150-199
C00541		BACC18Z10R CB-PSUD AFT,R	284T0187 81205	1	23-34-11 P036-00/ /J002	275-299
C00542		BACC18Z2R CB-CTD,FWD	284T0188 81205	1	23-34-11 P037-00/ /K001	050-099
C00542		BACC18Z5R CB-CTD,FWD	284T0188 81205	1	23-34-11 P037-00/ /K001	150-199, 275-299
C00543		BACC18Z5R CB-CTD,AFT	284T0188 81205	1	23-34-11 P037-00/ /K002	ALL
C00544		BACC18Z10R CB-VHF COMM,LEFT	233T5111 81205	1	23-12-11 P011-01/ /C003	ALL
C00545		BACC18Z10R CB-VHF COMM,RIGHT	233T5111 81205	1	23-12-21 P011-05/ /G031	ALL
C00546		BACC18Z2R CB-MUX/TAPE REPRO	284T0187 81205	1	23-34-11 P036-00/ /J005	ALL
C00547		BACC18Z2R CB-PASS. ENTMT/SERVICE CONT	233T5111 81205	1	23-34-11 P011-03/ /T008	ALL
C00548		BACC18Z7R CB-PASS. ADRS	233T5111 81205	1	23-31-11 P011-04/ /C022	ALL
C00549		BACC18Z5R CB-VIDEO PROJECTOR,FWD	284T0188 81205	1	23-32-11 P037-00/ /K005	050-099, 150-199
C00550		BACC18Z5R CB-VIDEO PROJECTOR,MID	284T0188 81205	1	23-32-11 P037-00/ /K006	050-099, 150-199
C00551		BACC18Z5R CB-CAB/SERVICE INTPH	233T5111 81205	1	23-42-11 P011-04/ /C023	ALL
C00555		BACC18Z5R CB-VIDEO PROJECTOR,AFT	284T0188 81205	1	23-32-11 P037-00/ /K007	050-099, 150-199
C00556		BACC18Z10R CB-VHF COMM,CENTER	233T5111 81205	1	23-12-31 P011-02/ /G004	ALL
C00559	9	SAS CB ACARS, AC	CUSTOMER 81205	0	23-22-11 P011-02/ /G6	150, 152-166, 275-299

EQUIPMENT LIST

D280T132

Section C00500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00559		BACC18Z02R CB-ACARS,MGMT UNIT AC (INOP)	233T5111 81205	1	23-22-11 P011-02/ /G006	050-099, 151, 275- 299
C00559		BACC18Z02R CB-ACARS,MGMT UNIT AC	233T5111 81205	1	23-22-11 P011-02/ /G006	167-199
C00560		BACC18Z2R CB-GND CALL	233T5111 81205	1	23-43-11 P011-05/ /H032	ALL
C00561		BACC18Z3R CB-FLT REC AC	233T5111 81205	1	31-31-11 P011-02/ /J007	ALL
C00563		BACC18Z2R CB-CLOCK TIME BASE,L	284T0997 81205	1	31-25-11 P006-01/ /G003	ALL
C00565		BACC18Z2R CB-WARN ELECT A	233T5111 81205	1	31-51-11 P011-05/ /J034	ALL
C00566		BACC18Z2R CB-WARN ELECT B	233T5111 81205	1	31-51-12 P011-01/ /B018	ALL
C00567		BACC18Z2R CB-SPEAKER,AURAL WARN, L	233T5111 81205	1	31-51-11 P011-01/ /B016	ALL
C00568		BACC18Z2R CB-SPEAKER,AURAL WARN, R	233T5111 81205	1	31-51-12 P011-05/ /H035	ALL
C00569		BACC18Z3R CB-ACMS AC	233T5111 81205	1	31-35-11 P011-02/ /J004	ALL
C00571		BACC18Z2R CB-PRINTER (COLLARED & INOP)	233T5111 81205	1	31-36-11 P011-02/ /J001	ALL
C00573		BACC18Z2R CB-CLOCK IND,L	233T5111 81205	1	31-25-11 P011-01/ /B017	ALL
C00574		BACC18Z2R CB-CLOCK IND,R	233T5111 81205	1	31-25-11 P011-05/ /J036	ALL
C00576		BACC18Z2R CB-CLOCK TIME BASE,R	284T0997 81205	1	31-25-11 P006-01/ /G004	ALL
C00578		BACC18Z2R CB-FLT REC DC	233T5111 81205	1	31-31-11 P011-02/ /J008	ALL
C00580		BACC18Z2R CB-IAS MACH,L (INOP)	233T5100 81205	1	34-13-11 P011-01/ /E001	050-099, 153-199, 275-299
C00580		BACC18Z2R CB-IAS MACH,L	233T5111 81205	1	34-13-11 P011-01/ /E001	150-152

EQUIPMENT LIST

D280T132

Section C00500

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00581		BACC18Z2R CB-IAS MACH,R (INOP)	233T5100 81205	1	34-13-21 P011-04/ /E022	050-099, 153-199, 275-299
C00581		BACC18Z2R CB-IAS MACH,R	233T5111 81205	1	34-13-21 P011-04/ /E022	150-152
C00582		BACC18Z02R CB-DME,LEFT	233T5111 81205	1	34-55-11 P011-01/ /E011	ALL
C00583		BACC18Z02R CB-DME,RIGHT	233T5111 81205	1	34-55-21 P011-04/ /E032	ALL
C00584		BACC18Z2R CB-ALTIMETER,L	233T5111 81205	1	34-13-11 P011-01/ /E002	ALL
C00585		BACC18Z2R CB-ALTIMETER,R	233T5111 81205	1	34-13-21 P011-04/ /E023	ALL
C00586		BACC18Z2R CB-VSI,LEFT	233T5111 81205	1	34-22-82 P011-01/ /E005	ALL
C00587		BACC18Z2R CB-VSI,RIGHT	233T5111 81205	1	34-22-92 P011-04/ /E026	ALL
C00588		BACC18Z2R CB-HSI,LEFT	233T5111 81205	1	34-22-16 P011-01/ /E006	ALL
C00589		BACC18Z2R CB-HSI,RIGHT	233T5111 81205	1	34-22-26 P011-04/ /E027	ALL
C00591		BACC18Z2R CB-STANDBY ALTIMETER VIBRATOR	233T5111 81205	1	34-13-11 P011-01/ /A008	ALL
C00592		BACC18Z02R CB-GND PROX	233T5111 81205	1	34-46-11 P011-01/ /F004	ALL
C00593		BACC18Z2R CB-ADI,LEFT	233T5111 81205	1	34-22-16 P011-01/ /E003	ALL
C00594		BACC18Z2R CB-ADI,RIGHT	233T5111 81205	1	34-22-26 P011-04/ /E024	ALL
C00595		BACC18Z02R CB-VOR/MKR,LEFT	233T5111 81205	1	34-51-11 P011-01/ /A001	ALL
C00596		BACC18Z02R CB-VOR,RIGHT	233T5111 81205	1	34-51-21 P011-04/ /E033	ALL
C00597		BACC18Z2R CB-FMCS CDU,LEFT	233T5111 81205	1	34-61-11 P011-01/ /E008	ALL

EQUIPMENT LIST

D280T132

Section C00500

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00598		BACC18Z2R CB-FMCS CDU,RIGHT	233T5111 81205	1	34-61-21 P011-04/ /E029	ALL
C00599		BACC18Z5R CB-WX RADAR,RIGHT	233T5111 81205	1	34-43-22 P011-04/ /F023	ALL

EQUIPMENT LIST

D280T132

Section C00500
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00600		BACC18Z02R CB-RAD ALTM,LEFT	233T5111 81205	1	34-33-11 P011-01/ /F005	ALL
C00601		BACC18Z02R CB-RAD ALTM,RIGHT	233T5111 81205	1	34-33-21 P011-04/ /F026	ALL
C00602		BACC18Z02R CB-RAD ALTM,CENTER	233T5111 81205	1	34-33-31 P011-04/ /F020	ALL
C00603		BACC18Z02R CB-ILS,L	233T5100 81205	1	34-31-11 P011-01/ /E010	ALL
C00604		BACC18Z2R CB-STDBY ILS INDICATOR	233T5111 81205	1	34-24-11 P011-01/ /A009	ALL
C00605		BACC18Z02R CB-ILS,R	233T5100 81205	1	34-31-21 P011-04/ /E031	ALL
C00606		BACC18Z02R CB-ILS,C	233T5100 81205	1	34-31-31 P011-01/ /A002	ALL
C00607		BACC18Z02R CB-ADF,L	233T5111 81205	1	34-57-11 P011-01/ /F006	ALL
C00609		BACC18Z5R CB-FMCS COMPUTER,LEFT	233T5111 81205	1	34-61-11 P011-01/ /E009	ALL
C00610		BACC18Z5R CB-FMCS COMPUTER,RIGHT	233T5111 81205	1	34-61-21 P011-04/ /E030	ALL
C00611		BACC18Z2R CB-IRS,LEFT	233T5111 81205	1	34-21-11 P011-01/ /F001	ALL
C00612		BACC18Z2R CB-IRS,RIGHT	233T5111 81205	1	34-21-21 P011-04/ /F022	ALL
C00613		BACC18Z2R CB-IRS,CENTER	233T5111 81205	1	34-21-31 P011-04/ /F021	ALL
C00614		BACC18Z10R CB-IRS,LEFT	284T0997 81205	1	34-21-11 P006-01/ /D003	ALL
C00615		BACC18Z5R CB-WX RADAR,LEFT	233T5111 81205	1	34-43-12 P011-01/ /F002	ALL
C00616	9	BACC18Z5R CB-ATC,LEFT (SB 24-0069)	233T5100 81205	1	34-53-11 P011-01/ /F007	050-099, 150-155, 162-165
C00616	9	BACC18Z02R CB-ATC,LEFT (SB 24-0069)	233T5100 81205	1	34-53-11 P011-01/ /F007	275-276

EQUIPMENT LIST

D280T132

Section C00600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00616		BACC18Z5R CB-ATC,LEFT	233T5100 81205	1	34-53-11 P011-01/ /F007	156-157, 166-199
C00616		BACC18Z5R CB-ATC,LEFT	233T5111 81205	1	34-53-11 P011-01/ /F007	277-299
C00617	9	BACC18Z5R CB-ATC,RIGHT (SB 34-0082)	233T5100 81205	1	34-53-21 P011-01/ /F028	150-154
C00617		BACC18Z5R CB-ATC,RIGHT	233T5111 81205	1	34-53-21 P011-04/ /F028	050-099, 155-199, 275-299
C00619		BACC18Z5R CB-STBY ATT INDICATOR	233T5111 81205	1	34-24-11 P011-01/ /A005	ALL
C00620		BACC18Z10R CB-IRS,RIGHT	284T0997 81205	1	34-21-21 P006-01/ /D005	ALL
C00621		BACC18Z10R CB-IRS,CENTER	284T0997 81205	1	34-21-31 P006-01/ /D004	ALL
C00622		BACC18Z2R CB-EFIS DISPLAY SWITCHING,LEFT	233T5111 81205	1	34-22-16 P011-01/ /A007	ALL
C00623		BACC18Z2R CB-EFIS DISPLAY SWITCHING,RIGHT	233T5111 81205	1	34-22-26 P011-04/ /F024	ALL
C00625		BACC18Z1R CB-AIR DATA COMPUTER,L	233T5111 81205	1	34-12-11 P011-01/ /A010	ALL
C00626		BACC18Z1R CB-AIR DATA COMPUTER,R	233T5111 81205	1	34-12-21 P011-04/ /F030	ALL
C00627	9	BACC18Z5R CB-DATA LOADER (SB 31-0031)	233T5100 81205	1	34-61-15 P011-05/ /G024	150-154
C00627		BACC18Z5R CB-DATA LOADER	233T5111 81205	1	31-32-15 P011-05/ /G024	050-099, 155-199, 275-299
C00628	9	BACC18Z5R CB-TCAS (INOP) (SB 34-0091)	233T5100 81205	1	34-45-11 P011-01/ /F012	150-152, 275-276
C00628		BACC18Z5R CB-TCAS (INOP)	233T5111 81205	1	34-45-11 P011-01/ /F012	050-099, 153-199, 277-299
C00630		BACC18Z2R CB-FMCS DATA BASE LOADER	284T0189 81205	1	34-61-15 P033-00/ /A007	150-154
C00632		BACC18Z02R CB-ADF,R	233T5111 81205	1	34-57-21 P011-01/ /A003	ALL

EQUIPMENT LIST

D280T132

Section C00600

Page 2

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00633		BACC18Z2R CB-EFIS CONTROL PANEL,LEFT	233T5111 81205	1	34-22-16 P011-01/ /E004	ALL
C00634		BACC18Z2R CB-EFIS CONTROL PANEL,RIGHT	233T5111 81205	1	34-22-26 P011-04/ /E025	ALL
C00635		BACC18Z2R CB-RDMI,LEFT	233T5111 81205	1	34-22-81 P011-01/ /A006	ALL
C00636		BACC18Z2R CB-RDMI,RIGHT	233T5111 81205	1	34-22-91 P011-04/ /F025	ALL
C00637		BACC18Z2R CB-EFIS SYMBOL GENERATOR,LEFT	233T5111 81205	1	34-22-16 P011-01/ /F008	ALL
C00638		BACC18Z2R CB-EFIS SYMBOL GENERATOR,RIGHT	233T5111 81205	1	34-22-26 P011-04/ /F029	ALL
C00639		BACC18Z2R CB-EFIS SYMBOL GENERATOR,CENTER	233T5111 81205	1	34-22-36 P011-01/ /F009	ALL
C00644		BACC18Z2R CB-FLT AMPL,CAPT OBS,DUAL PWR INTPH	233T5111 81205	1	23-51-11 P011-04/ /C025	ALL
C00645		BACC18Z2R CB-FLT AMPL,CAPT OBS,DUAL PWR INTPH	233T5111 81205	1	23-51-11 P011-05/ /G029	ALL
C00646		BACC18Z2R CB-F/O,DUAL PWR INTPH	233T5111 81205	1	23-51-21 P011-04/ /C026	ALL
C00647		BACC18Z2R CB-F/O,DUAL PWR INTPH	233T5111 81205	1	23-51-21 P011-05/ /G030	ALL
C00651		BACC18Z2R CB-EQUIPMENT COOLING OUTBD VALVES	233T5111 81205	1	21-58-13 P011-03/ /P013	ALL
C00652		BACC18Z2R CB-CARGO HEAT VALVE,BULK	284T0187 81205	1	21-44-21 P036-00/ /L001	ALL
C00653		BACC18Z2R CB-LEFT PACK FLOW CONT	233T5111 81205	1	21-51-11 P011-01/ /A013	ALL
C00654		BACC18Z2R CB-EQUIP COOLING SUPPLY FAN 1	233T5111 81205	1	21-58-14 P011-03/ /P011	ALL
C00656		BACC18Z2R CB-EQUIP COOL OVHT/SMOKE/VALVE IND	233T5111 81205	1	21-58-11 P011-06/ /P021	ALL
C00658		BACC18Z2R CB-CABIN ALT CONTROL SELECT	233T5111 81205	1	21-31-11 P011-01/ /B015	ALL

EQUIPMENT LIST

D280T132

Section C00600

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00660		BACC18Z2R CB-CABIN RECIRC FAN,L	233T5111 81205	1	21-25-11 P011-03/ /R014	ALL
C00661		BACC18Z2R CB-CABIN RECIRC FAN,R	233T5111 81205	1	21-25-21 P011-06/ /R023	ALL
C00662		BACC18Z5R CB-AUXILIARY HEATERS,CAPT,HIGH	284T0187 81205	1	21-45-11 P036-00/ /H001	ALL
C00663		BACC18Z5R CB-AUXILIARY HEATERS,CAPT,LOW	284T0187 81205	1	21-45-11 P036-00/ /H002	ALL
C00664	9	BACC18Z2R CB-CARGO GND EXH B/U VLV (TO 210210)	284T0187 81205	1	21-28-11 P036-00/ /E004	150
C00664		BACC18Z2R CB-CARGO GND EXH B/U VLV	284T0187 81205	1	21-28-11 P036-00/ /E004	050-099, 151-199, 275-299
C00665	9	BACC18Z2R CB-CARGO GND EXH VLV (TO 210210)	284T0188 81205	1	21-28-11 P037-00/ /E003	150
C00665		BACC18Z2R CB-CARGO GND EXH VLV	284T0188 81205	1	21-28-11 P037-00/ /E003	050-099, 151-199, 275-299
C00666	9	BACC18Z2R CB-CARGO A/C SOV (TO 210210)	284T0188 81205	1	21-28-11 P037-00/ /E004	150
C00666		BACC18Z2R CB-CARGO A/C SOV	284T0188 81205	1	21-28-11 P037-00/ /E004	050-099, 151-199, 275-299
C00667		BACC18Z2R CB-ZONE CONTROLLER	233T5111 81205	1	21-61-51 P011-03/ /R015	ALL
C00668		BACC18Z2R CB-AUX ZONE CONTROLLER	233T5111 81205	1	21-61-51 P011-03/ /R011	ALL
C00669	9	MS3320-7-5 CB-SATCOM HGA (MTO-238591/2/3)	233T5100 76374	1	23-25-11 P011-02/ /H009	150, 153-199
C00670		BACC18Z2R CB-TRIM AIR	233T5100 81205	1	21-61-51 P011-03/ /C033	050-099
C00670		BACC18Z2R CB-TRIM AIR	233T5111 81205	1	21-61-51 P011-04/ /C033	150-199, 275-299
C00672		BACC18Z2R CB-ACMS SENSOR	233T5111 81205	1	31-31-15 P011-02/ /J006	ALL
C00673		BACC18Z3R CB-LEFT PACK AUTO PWR	233T5111 81205	1	21-53-11 P011-03/ /N010	ALL

EQUIPMENT LIST

D280T132

Section C00600

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00674		BACC18Z3R CB-RIGHT PACK AUTO PWR	233T5111 81205	1	21-53-21 P011-06/ /N019	ALL
C00676		BACC18Z2R CB-AFT EXH FAN 1 AC AVBLE	284T0189 81205	1	21-26-11 P033-00/ /D006	156-157, 166-199, 277-299
C00677		BACC18Z2R CB-GASPER FAN CONTROL	233T5111 81205	1	21-24-11 P011-03/ /R017	050-099, 150-199
C00678	9	BACC18Z5R CB-HTR BLKT (INOP) (SB 25A0285)	284T0187 81205	1	21-45-22 P036-00/ /H003	050-099, 155-199, 276-278
C00678	9	BACC18Z5R CB-HTR BLKT (SB 25-0113)	284T0187 81205	1	21-45-22 P036-00/ /H003	150-154, 275
C00678		BACC18Z5R CB-HTR BLKT	284T0187 81205	1	21-45-22 P036-00/ /H003	050-099, 155-199, 276-299
C00679		BACC18Z2R CB-EQUIP COOL OVERRIDE	233T5111 81205	1	21-58-16 P011-04/ /C019	ALL
C00680		BACC18Z2R CB-FWD DR AREA HTR-CONT	233T5100 81205	1	21-45-21 P011-03/ /R012	150-154, 275
C00682		BACC18Z2R CB-CARGO HEAT OVERRIDE,BULK	233T5111 81205	1	21-44-21 P011-06/ /N027	ALL
C00683		BACC18Z7R CB-CABIN ALTITUDE CONTROL MANUAL	233T5111 81205	1	21-31-31 P011-01/ /B014	ALL
C00684		BACC18Z2R CB-CARGO HEAT CONTROL VALVE,AFT	284T0187 81205	1	21-44-11 P036-00/ /L003	ALL
C00685		BACC18Z2R CB-CARGO HEAT OVERRIDE,FWD	233T5111 81205	1	21-43-11 P011-06/ /R021	ALL
C00686		BACC18Z5R CB-CABIN ALT CONTROL AUTO 1	233T5111 81205	1	21-31-11 P011-03/ /P015	ALL
C00687		BACC18Z2R CB-EQUIPMENT COOLING EXHAUST FAN FWD	233T5111 81205	1	21-58-15 P011-06/ /P022	ALL
C00688		BACC18Z2R CB-EQUIPMENT COOLING STANDBY	233T5111 81205	1	21-58-12 P011-01/ /B008	ALL
C00689		BACC18Z2R CB-CARGO HEAT CONTROL,BULK	233T5111 81205	1	21-44-21 P011-06/ /N026	ALL
C00690		BACC18Z2R CB-CARGO HEAT CONTROL,AFT	233T5111 81205	1	21-44-11 P011-06/ /R020	ALL

EQUIPMENT LIST

D280T132

Section C00600

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00691		BACC18Z2R CB-CARGO HEAT OVERRIDE,AFT	233T5111 81205	1	21-44-11 P011-06/ /R022	ALL
C00692	9	BACC18Z2R CB-DOOR HEAT CONT (SB 25-0113)	233T5100 81205	1	21-45-21 P011-03/ /R012	150-154, 275
C00692		BACC18Z2R CB-DOOR HEAT CONT	233T5111 81205	1	21-45-21 P011-03/ /R012	050-099, 155-199, 276-299
C00693	9	BACC18Z2R CB-CARGO A/C & VENT CONT (TO 210210)	233T5100 81205	1	21-26-31 P011-06/ /P020	150
C00693		BACC18Z2R CB-CARGO A/C & VENT CONT	233T5111 81205	1	21-26-31 P011-06/ /P020	050-099, 275-299
C00693		BACC18Z2R CB-CARGO A/C & VENT CONT (INOP)	233T5100 81205	1	21-26-31 P011-06/ /P020	151-199
C00694	9	BACC18Z2R CB-CARGO EXH VLV (TO 210210)	233T5100 81205	1	21-28-11 P011-03/ /C020	150
C00694		BACC18Z2R CB-CARGO EXH VLV	233T5100 81205	1	21-28-11 P011-04/ /C020	050-099, 275-299
C00694		BACC18Z2R CB-CARGO EXH VLV (INOP)	233T5100 81205	1	21-28-11 P011-04/ /C020	151-199
C00696		BACC18Z2R CB-CARGO HEAT CONTROL VALVE,FWD	284T0187 81205	1	21-43-11 P036-00/ /L002	ALL
C00697		BACC18Z2R CB-CARGO HEAT CONTROL,FWD	233T5111 81205	1	21-43-11 P011-06/ /R019	ALL
C00699		BACC18Z5R CB-AUXILIARY HEATERS,F/O,HIGH	284T0188 81205	1	21-45-11 P037-00/ /H001	ALL

EQUIPMENT LIST

D280T132

Section C00600
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00700		BACC18Z5R CB-AUXILIARY HEATERS,F/O,LOW	284T0188 81205	1	21-45-11 P037-00/ /H002	ALL
C00701		BACC18Z5R CB-CABIN ALT CONTROL AUTO. 2	233T5111 81205	1	21-31-21 P011-06/ /P023	ALL
C00702		BACC18Z2R CB-LEFT PACK AUTO CONT	233T5111 81205	1	21-53-11 P011-03/ /N011	ALL
C00703		BACC18Z2R CB-RIGHT PACK AUTO CONT	233T5111 81205	1	21-53-21 P011-06/ /N020	ALL
C00704		BACC18Z2R CB-RIGHT PACK FLOW CONT	233T5111 81205	1	21-51-21 P011-04/ /A026	ALL
C00705		BACC18Z2R CB-EQUIPMENT COOLING AFT FAN EXH 2	233T5111 81205	1	21-26-11 P011-03/ /P010	ALL
C00706		BACC18Z2R CB-EQUIPMENT COOLING AFT FAN EXH 1	233T5111 81205	1	21-26-11 P011-06/ /P019	ALL
C00707		BACC18Z2R CB-EQUIP COOL AFT FAN 1	284T0175 81205	1	21-26-11 P034-00/ /L008	ALL
C00709		BACC18Z2R CB-PACK FLOW INDICATION	233T5100 81205	1	21-52-41 P011-03/ /N017	ALL
C00711		BACC18Z2R CB-EQUIP COOL GND WARN	284T0997 81205	1	21-58-11 P006-01/ /D006	ALL
C00724	9	BACC18Z2R CB-HF/SAT AUDIO SW (MTO-238591/2/3)	233T5100 81205	1	23-25-14 P011-02/ /H007	150, 153-155, 162-165
C00724	9	BACC18Z2R CB-HF/SAT AUDIO SW(INOP)(MTO-238591/2/3)	233T5100 81205	1	23-25-14 P011-02/ /H007	156-157, 166-199
C00724		BACC18Z2R CB-HF/SAT AUDIO SW (INOP)	233T5100 81205	1	23-25-14 P011-02/ /H007	156-157, 166-199
C00724		BACC18Z2R CB-HF/SAT AUDIO SW (INOP)	233T5111 81205	1	23-25-14 P011-02/ /H007	277-299
C00725		BACC18Z2R CB-FMS SW, L	233T5111 81205	1	34-61-16 P011-01/ /B001	ALL
C00726		BACC18Z2R CB-FMS SW, R	233T5111 81205	1	34-61-26 P011-04/ /F033	ALL
C00730		BACC18Z10R CB-MID CABIN SERVICE OUTLETS	284T0997 81205	1	25-29-11 P006-04/ /J023	ALL

EQUIPMENT LIST

D280T132

Section C00700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00731		BACC18Z10R CB-SVCE OUTLETS	284T0189 81205	1	25-29-11 P033-00/ /D007	ALL
C00732		BACC18Z5R CB-SVCE OUTLET-DC	233T5111 81205	1	25-29-11 P011-06/ /U030	ALL
C00734		BACC18Z5R CB-LAV SHAVERS	284T0187 81205	1	25-42-11 P036-00/ /D001	ALL
C00737		BACC18Z5R CB-AFT GALLEYS	233T5100 81205	1	25-31-21 P011-03/ /U007	050-099, 150-199
C00737		BACC18Z7R CB-AFT GALLEYS	233T5100 81205	1	25-31-21 P011-03/ /U007	275-276
C00740		BACC18Z5R CB-FWD GALLEY PWR	233T5111 81205	1	25-31-11 P011-06/ /U033	050-099, 150-199, 275-276
C00740		BACC18Z7R CB-FWD GALLEY PWR	233T5111 81205	1	25-31-11 P011-06/ /U033	277-299
C00741		BACC18Z7R CB-R AFT GALLEY	233T5100 81205	1	25-31-31 P011-03/ /U008	277-299
C00742		BACC18Z7R CB-L AFT GALLEY	233T5111 81205	1	25-31-21 P011-03/ /U007	277-299
C00746		BACC18Z7R CB-CONT-CARGO HDLG-FWD	284T3400 81205	1	25-53-11 P034-00/ /J002	ALL
C00747		BACC18Z7R CB-CONT-CARGO HDLG-AFT	284T3400 81205	1	25-53-21 P034-00/ /J003	ALL
C00748		BACC18Z5R CB-EVAC SIGNAL	284T0997 81205	1	25-63-11 P006-01/ /F002	ALL
C00749		BACC18Z2R CB-CHILLER SHUTDOWN CONT	284T0997 81205	1	25-33-11 P006-01/ /B007	050-099, 155-199, 277-299
C00763		BACC18Z2R CB-FIRE DET ALTN PWR,L ENG	233T5111 81205	1	26-11-11 P011-05/ /K030	ALL
C00764		BACC18Z2R CB-FIRE DET ALTN PWR,R ENG	233T5111 81205	1	26-11-21 P011-05/ /K031	ALL
C00765		BACC18Z2R CB-FIRE DET ALTN PWR,APU	233T5111 81205	1	26-15-11 P011-05/ /K032	ALL
C00766		BACC18Z2R CB-FIRE DET ALTN PWR,CARGO	233T5111 81205	1	26-16-11 P011-05/ /K033	ALL

EQUIPMENT LIST

D280T132

Section C00700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00767		BACC18Z2R CB-OVHT DET ALTN PWR,L ENG	233T5111 81205	1	26-11-12 P011-05/ /K034	ALL
C00768		BACC18Z2R CB-OVHT DET ALTN PWR,R ENG	233T5111 81205	1	26-11-22 P011-05/ /K035	ALL
C00769		BACC18Z3R CB-WW FIRE/DUCT LEAK	233T5111 81205	1	26-17-11 P011-01/ /B010	ALL
C00770		BACC18Z2R CB-SMOKE DETECTORS	233T5100 81205	1	26-13-11 P011-05/ /K036	050-099, 150-199
C00772		BACC18Z2R CB-CAR. FIRE DET 1	233T5111 81205	1	26-16-11 P011-04/ /B026	ALL
C00773		BACC18Z5R CB-FEXT BTL 2,CARGO	284T0997 81205	1	26-23-12 P006-01/ /H006	ALL
C00774		BACC18Z2R CB-FIRE DETECTION L ENGINE 1	233T5111 81205	1	26-11-11 P011-04/ /B020	ALL
C00775		BACC18Z2R CB-FIRE DETECTION R ENGINE 1	233T5111 81205	1	26-11-21 P011-04/ /B022	ALL
C00776		BACC18Z2R CB-FIRE DETECTION APU 1	233T5111 81205	1	26-15-11 P011-04/ /B024	ALL
C00778		BACC18Z7R CB-FIRE EXTINGUISHING ENG L BTL 1	284T0997 81205	1	26-21-11 P006-01/ /H001	ALL
C00779		BACC18Z7R CB-FIRE EXTINGUISHING ENG R BTL 1	284T0997 81205	1	26-21-11 P006-01/ /H003	ALL
C00780		BACC18Z7R CB-APU FIRE EXT 1	284T0997 81205	1	26-22-21 P006-01/ /G001	ALL
C00781		BACC18Z5R CB-FEXT BTL 1,CARGO	284T0997 81205	1	26-23-11 P006-01/ /H005	ALL
C00782		BACC18Z7R CB-APU FIRE EXT 2	284T0997 81205	1	26-22-21 P006-01/ /G002	275-299
C00783		BACC18Z2R CB-FIRE DETECTION L ENGINE 2	233T5111 81205	1	26-11-11 P011-04/ /B021	ALL
C00784		BACC18Z2R CB-FIRE DETECTION R ENGINE 2	233T5111 81205	1	26-11-21 P011-04/ /B023	ALL
C00785		BACC18Z2R CB-FIRE DETECTION APU 2	233T5111 81205	1	26-15-11 P011-04/ /B025	ALL

EQUIPMENT LIST

D280T132

Section C00700

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00786		BACC18Z7R CB-FIRE EXTINGUISHING ENG L BTL 2	284T0997 81205	1	26-21-11 P006-01/ /H002	ALL
C00787		BACC18Z7R CB-FIRE EXTINGUISHING ENG R BTL 2	284T0997 81205	1	26-21-11 P006-01/ /H004	ALL
C00788		BACC18Z2R CB-CAR. FIRE DET 2	233T5111 81205	1	26-16-11 P011-04/ /B027	ALL
C00789		BACC18Z2R CB-OVERHEAT DETECT L ENGINE 1	233T5111 81205	1	26-11-12 P011-04/ /B029	ALL
C00790		BACC18Z2R CB-OVERHEAT DETECT L ENGINE 2	233T5111 81205	1	26-11-12 P011-04/ /B030	ALL
C00791		BACC18Z2R CB-OVERHEAT DETECT R ENGINE 1	233T5111 81205	1	26-11-22 P011-04/ /B031	ALL
C00792		BACC18Z2R CB-OVERHEAT DETECT R ENGINE 2	233T5111 81205	1	26-11-22 P011-04/ /B032	ALL
C00793		BACC18Z02R CB-FIRE SWITCH UNLOCK	233T5111 81205	1	26-11-11 P011-04/ /B019	ALL
C00794		BACC18Z2R CB-CARGO FIRE DET FAN AC	233T5111 81205	1	26-16-21 P011-06/ /U036	ALL
C00795		BACC18Z1R CB-CARGO FIRE DET FAN DC	233T5111 81205	1	26-16-21 P011-06/ /U035	ALL
C00796		BACC18Z3R CB-APU REMOTE FIRE IND	233T5111 81205	1	26-15-12 P011-04/ /B034	ALL
C00799		BACC18Z2R CB-WHEEL WELL FIRE IND	233T5111 81205	1	26-17-11 P011-04/ /B033	ALL

EQUIPMENT LIST

D280T132

Section C00700
Page 4 End
Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00800		BACC18Z2R CB-BUS TIE ENABLE	284T0997 81205	1	24-41-11 P006-01/ /C004	ALL
C00801		BACC18Z2R CB-DC VOLT SENSE,LEFT	284T0997 81205	1	24-32-11 P006-02/ /C012	ALL
C00802		BACC18Z2R CB-DC VOLT SENSE,RIGHT	284T0997 81205	1	24-32-11 P006-02/ /G011	ALL
C00803		BACC18Z3R CB-BPCU SECONDARY	233T5111 81205	1	24-41-11 P011-06/ /T032	ALL
C00804		BACC18Z7R CB-LEFT GEN CONT UNIT	284T0997 81205	1	24-11-11 P006-01/ /B001	ALL
C00805		BACC18Z7R CB-RIGHT GEN CONT UNIT	284T0997 81205	1	24-11-21 P006-01/ /B002	ALL
C00806		BACC18Z7R CB-CONT UNIT,APU GEN	284T0997 81205	1	24-22-41 P006-01/ /B003	ALL
C00807		BACC18Z7R CB-GEN DRIVE DISC,L	284T0997 81205	1	24-11-11 P006-01/ /B005	ALL
C00808		BACC18Z7R CB-GEN DRIVE DISC,R	284T0997 81205	1	24-11-21 P006-01/ /B006	ALL
C00809		BACC18Z7R CB-CONT UNIT,BUS POWER	284T0997 81205	1	24-41-11 P006-01/ /B004	ALL
C00811		BACC18Z2R CB-STBY BUS-DC	233T5111 81205	1	24-33-11 P011-01/ /D002	ALL
C00813		BACC18R75C CB-INV PWR-BAT.	284T0997 81205	1	24-33-11 P006-02/ /J012	ALL
C00814		BACC18Z2R CB-BAT. XFER CONT	284T0997 81205	1	24-33-11 P006-01/ /D002	ALL
C00815		BACC18Z2R CB-APU GEN VOLTMETER	284T0175 81205	1	24-28-11 P034-00/ /M008	ALL
C00816		BACC18Z2R CB-EXT PWR VOLTMETER	284T0175 81205	1	24-28-11 P034-00/ /M009	ALL
C00817		BACC18Z2R CB-INVERTER VOLT SENSE	284T0997 81205	1	24-28-11 P006-03/ /L016	ALL
C00818		BACC18Z2R CB-LEFT GEN VOLTMETER	284T0171 81205	1	24-28-11 P031-00/ /	ALL

EQUIPMENT LIST

D280T132

Section C00800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00819		BACC18Z2R CB-RIGHT GEN VOLTMETER	284T0172 81205	1	24-28-11 P032-00/ /	ALL
C00820		BACC18Z2R CB-APU BAT. OVHT PROT	284T1149 81205	1	24-31-41 P049-00/ /B004	ALL
C00821		BACC18Z2R CB-APU BAT. DC VOLT	284T1149 81205	1	24-31-41 P049-00/ /B003	ALL
C00822		BACC18Z2R CB-UTILITY BUS L	233T5111 81205	1	24-51-13 P011-03/ /T004	ALL
C00823		BACC18Z2R CB-UTILITY BUS,R	233T5111 81205	1	24-51-23 P011-06/ /T031	ALL
C00824		BACC18Z1R CB-CAT. III BUS ISOL LEFT	233T5111 81205	1	24-51-31 P011-03/ /T003	ALL
C00825		BACC18Z1R CB-CAT. III BUS ISOL RIGHT	233T5111 81205	1	24-51-31 P011-06/ /T030	ALL
C00826		BACC18Z1R CB-CAT. III BUS ISOL BAT.	233T5111 81205	1	24-51-31 P011-01/ /D006	ALL
C00827		BACC18Z2R CB-BAT. OVHT PROT	284T0997 81205	1	24-31-11 P006-01/ /D001	ALL
C00828		BACC18Z2R CB-STBY PWR CONT	284T0997 81205	1	24-33-11 P006-01/ /A005	ALL
C00829		BACC18X25 CB-BAT. BUS DISTR	284T0997 81205	1	24-54-71 P006-01/ /A001	ALL
C00830		BACC18X50 CB-HYD GEN 28 VDC PWR	284T0997 81205	1	24-31-11 P006-02/ /G012	ALL
C00831		BACC18R100C CB-GND HDLG BUS EXT PWR PH A	284T0175 81205	1	24-51-61 P034-00/ /D009	ALL
C00832		BACC18R100C CB-GND HDLG BUS EXT PWR PH B	284T0175 81205	1	24-51-61 P034-00/ /D010	ALL
C00833		BACC18R100C CB-GND HDLG BUS EXT PWR PH C	284T0175 81205	1	24-51-61 P034-00/ /D011	ALL
C00834		BACC18R100C CB-GND HDLG BUS APU PWR PH A	284T0175 81205	1	24-51-61 P034-00/ /B012	ALL
C00835		BACC18R100C CB-GND HDLG BUS APU PWR PH B	284T0175 81205	1	24-51-61 P034-00/ /B013	ALL

EQUIPMENT LIST

D280T132

Section C00800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00836		BACC18R100C CB-GND HDLG BUS APU PWR PH C	284T0175 81205	1	24-51-61 P034-00/ /B014	ALL
C00837		BACC18Z2R CB-IDG VALVE,LEFT ENG	233T5111 81205	1	24-11-11 P011-02/ /M004	ALL
C00838		BACC18Z2R CB-IDG VALVE,RIGHT ENG	233T5111 81205	1	24-11-21 P011-05/ /M031	ALL
C00839		BACC18X35 CB-MEDICAL OUTLETS (INOP)	284T0997 81205	1	25-29-12 P006-02/ /G013	ALL
C00843		BACC18Z2R CB-28V AC BUS L XFR	284T0997 81205	1	24-51-14 P006-03/ /K018	ALL
C00844		BACC18Z2R CB-28V AC BUS R XFR	284T0997 81205	1	24-51-24 P006-04/ /J024	ALL
C00845		BACC18Z2R CB-HYD GEN DC VOLT SENSE	284T1168 81205	1	24-25-13 P065-00/ /	ALL
C00846		BACC18Z2R CB-HYD GEN AC VOLT SENSE	284T1168 81205	1	24-25-13 P065-00/ /	ALL
C00847		BACC18Z2R CB-L AC BUS SENSE	233T5111 81205	1	24-25-11 P011-03/ /R004	ALL
C00848		BACC18Z2R CB-R AC BUS SENSE	233T5111 81205	1	24-25-11 P011-06/ /R031	ALL
C00853		BACC18Z2R CB-GROUND SVCE LOAD CONT	233T5111 81205	1	24-51-52 P011-06/ /T029	ALL
C00865		BACC18Z2R CB-TRU APU START CONTROL	233T5111 81205	1	24-32-41 P011-06/ /T035	275-299
C00868		BACC18R75C CB-APU BAT. CHGR	284T1149 81205	1	24-31-41 P049-00/ /E004	ALL
C00869		BACC18X15 CB-APU BAT. BUS	284T1149 81205	1	24-31-41 P049-00/ /E003	ALL
C00870		BACC18X20 CB-GND SERVICE BUS,SECT 2	284T0189 81205	1	24-51-52 P033-00/ /D001	ALL
C00871	1	BACC18Z10R CB-GND SERVICE XFMR	284T0189 81205	1	24-53-51 P033-00/ /D002	ALL
C00871	2	BACC18X10 CB-GND SERVICE XFMR	284T0189 81205	1	24-53-51 P033-00/ /D002	ALL

EQUIPMENT LIST

D280T132

Section C00800

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00872		BACC18X25 CB-DC STBY	284T0997 81205	1	24-33-11 P006-01/ /A002	ALL
C00874		BACC18Z10R CB-AC STBY BUS PWR	284T0997 81205	1	24-33-11 P006-03/ /J017	ALL
C00875		BACC18Z5R CB-INVERTER-CTR BUS ISLN PWR	284T0997 81205	1	24-51-31 P006-03/ /L015	ALL
C00876		BACC18Z5R CB-CTR BUS AC	284T0997 81205	1	24-51-31 P006-03/ /J018	ALL
C00877		BACC18Z5R CB-28V AC BUS LEFT	284T0997 81205	1	24-53-11 P006-03/ /J019	ALL
C00878		BACC18Z5R CB-28V AC BUS RIGHT	284T0997 81205	1	24-53-21 P006-04/ /J025	ALL
C00879		BACC18Z2R CB-DC BUS TIE CONT	284T0997 81205	1	24-32-11 P006-01/ /A006	ALL
C00880		BACC18Z10R CB-C BUS CONT	284T0997 81205	1	24-51-31 P006-01/ /G007	050-099, 155-199, 277-299
C00880		BACC18Z2R CB-C BUS CONT	284T0997 81205	1	24-51-31 P006-01/ /G007	150-154, 275-276
C00881		BACC18R100C CB-DC TIE,LEFT	284T0997 81205	1	24-32-11 P006-02/ /D010	ALL
C00882		BACC18X50 CB-DC BUS L SECT 1	284T0997 81205	1	24-54-11 P006-02/ /D009	ALL
C00883		BACC18X25 CB-DC BUS L SECT 2	284T0997 81205	1	24-54-11 P006-02/ /D008	ALL
C00884		BACC18Z10R CB-CTR BUS PWR	284T0997 81205	1	24-51-31 P006-02/ /C010	ALL
C00885		BACC18X50 CB-INVERTER PWR-TRU	284T0997 81205	1	24-33-11 P006-02/ /D011	ALL
C00886		BACC18X50 CB-BAT. BUS PWR-TRU	284T0997 81205	1	24-33-11 P006-02/ /D012	ALL
C00887		BACC18Z2R CB-BAT. BUS CONT	284T0997 81205	1	24-33-11 P006-02/ /C011	ALL
C00889		BACC18R100C CB-DC TIE,RIGHT	284T0997 81205	1	24-32-11 P006-02/ /G010	ALL

EQUIPMENT LIST

D280T132

Section C00800

Page 4

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00890		BACC18X50 CB-DC BUS R SECT 2	284T0997 81205	1	24-54-21 P006-02/ /G008	ALL
C00891		BACC18X50 CB-DC BUS R SECT 1	284T0997 81205	1	24-54-21 P006-02/ /G009	ALL
C00892		BACC18Z2R CB-STBY BUS-AC	233T5111 81205	1	24-33-11 P011-01/ /D001	ALL
C00896		BACC18R100C CB-MAIN BAT. CHARGER	284T0997 81205	1	24-31-11 P006-02/ /J009	ALL
C00897		BACC18X50 CB-HOT BAT. BUS	284T0997 81205	1	24-54-72 P006-02/ /J010	ALL
C00898		BACC18X50 CB-BAT. BUS PWR	284T0997 81205	1	24-33-11 P006-02/ /J011	ALL
C00899		BACC18Z10R CB-CTR BUS DC	284T0997 81205	1	24-51-31 P006-02/ /J013	150-154, 275-276

EQUIPMENT LIST

D280T132

Section C00800

Page 5 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00901		S281T004-1 CB-LEFT GEN	284T0171 81205	1	24-22-11 P031-00/ /	ALL
C00902		S281T004-1 CB-LEFT BUS TIE	284T0171 81205	1	24-22-12 P031-00/ /	ALL
C00903		S281T004-1 CB-RIGHT GEN	284T0172 81205	1	24-22-21 P032-00/ /	ALL
C00904		S281T004-1 CB-RIGHT BUS TIE	284T0172 81205	1	24-22-22 P032-00/ /	ALL
C00905		S281T004-1 CB-AUX PWR	284T0175 81205	1	24-22-41 P034-00/ /	ALL
C00906		BACC18Z5R CB-HYD GEN CONT	284T0997 81205	1	24-25-11 P006-01/ /A007	ALL
C00915		BACC18Z2R CB-FLT DK CREW REST VLV CONT	284T0187 81205	1	21-66-11 P036-00/ /D002	050-099, 162-199
C00916		BACC18Z2R CB-FLT DK CREW REST HEAT CONT	284T0187 81205	1	21-66-11 P036-00/ /D003	050-099, 162-199
C00917		BACC18Z2R CB-FLT DK CREW REST FAN CONT	284T0187 81205	1	21-66-11 P036-00/ /D004	050-099, 162-199
C00918		BACC18Z2R CB-FWD CABIN CREW REST TEMP CONT	284T0188 81205	1	21-66-21 P037-00/ /H004	050-099, 162-199
C00919	9	BACC18Z2R CB-AFT LH CABIN CREW REST TEMP CONT	81205	1	21-66-31 P036-00/ /L005	150, 152-157
C00919		BACC18Z2R CB-AFT LH CABIN CREW REST TEMP CONT	284T0187 81205	1	21-66-31 P036-00/ /D006	050-099, 162-199
█ C00920	9	BACC18Z2R CB-AFT RH CABIN CREW REST TEMP CONT	284T0188 81205	1	21-66-41 P037-00/ /H005	150, 152-157
█ C00920	9	BACC18Z2R CB-AFT RH CABIN CREW REST TEMP CONT	81205	1	21-66-41 P037-00/ /K004	150, 152-157
C00920		BACC18Z2R CB-AFT RH CABIN CREW REST TEMP CONT	284T0188 81205	1	21-66-41 P037-00/ /H005	050-099, 162-199
C00921		BACC18Z2R CB-FWD CABIN CREW REST FAN CONT	284T0188 81205	1	21-66-21 P037-00/ /D006	050-099, 162-199
C00922	9	BACC18Z2R CB-AFT LH CABIN CREW REST FAN CONT	81205	1	21-66-31 P036-00/ /L004	150, 152-157

EQUIPMENT LIST

D280T132

Section C00900

Page 1

Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C00922		BACC18Z2R CB-AFT LH CABIN CREW REST FAN CONT	284T0187 81205	1	21-66-31 P036-00/ /D005	050-099, 162-199
C00923	9	BACC18Z2R CB-AFT RH CANIN CREW REST FAN CONT	81205	1	21-66-41 P037-00/ /K002	150, 152-157
C00923	9	BACC18Z2R CB-AFT RH CABIN CREW REST FAN CONT	284T0188 81205	1	21-66-41 P037-00/ /D007	150, 152-157
C00923		BACC18Z2R CB-AFT RH CABIN CREW REST FAN CONT	284T0188 81205	1	21-66-41 P037-00/ /D007	050-099, 162-199

EQUIPMENT LIST

D280T132

Section C00900

Page 2 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01001		BACC18Z2R CB-SLATS POSITION IND	233T5111 81205	1	27-88-11 P011-01/ /C010	ALL
C01002		BACC18Z2R CB-STAB. TRIM POSITION IND,LEFT	233T5111 81205	1	27-48-11 P011-02/ /H010	ALL
C01005		BACC18Z2R CB-RUDDER POSITION	233T5111 81205	1	27-28-11 P011-02/ /K016	ALL
C01008		BACC18Z2R CB-L FLAP POS IND	233T5111 81205	1	27-58-11 P011-02/ /J015	ALL
C01009		BACC18Z2R CB-STAB. TRIM POSITION IND,RIGHT	233T5111 81205	1	27-48-11 P011-05/ /H019	ALL
C01010		BACC18Z5R CB-STAB TRIM ALTN	233T5111 81205	1	27-41-31 P011-04/ /A036	050-099, 155-199, 275-299
C01011		BACC18Z2R CB-TAIL,L-FLT CONT SHUTOFF	233T5111 81205	1	27-23-11 P011-02/ /H017	ALL
C01012		BACC18Z2R CB-TAIL,R-FLT CONT SHUTOFF	233T5111 81205	1	27-23-11 P011-05/ /H027	ALL
C01013		BACC18Z2R CB-TAIL,C-FLT CONT SHUTOFF	233T5111 81205	1	27-23-11 P011-02/ /H018	ALL
C01014		BACC18Z2R CB-WING,L-FLT CONT SHUTOFF	233T5111 81205	1	27-13-11 P011-02/ /H015	ALL
C01015		BACC18Z2R CB-WING,R-FLT CONT SHUTOFF	233T5111 81205	1	27-13-11 P011-05/ /H026	ALL
C01016		BACC18Z2R CB-WING,C-FLT CONT SHUTOFF	233T5111 81205	1	27-13-11 P011-02/ /H016	ALL
C01017		BACC18Z5R CB-STAB. TRIM,CONT,LEFT	233T5111 81205	1	27-41-11 P011-02/ /H011	ALL
C01018		BACC18Z2R CB-STAB TRIM CONTROL,RIGHT	233T5111 81205	1	27-41-21 P011-05/ /H020	ALL
C01019		BACC18Z2R CB-FLAP SHUTOFF	233T5111 81205	1	27-51-31 P011-02/ /J014	ALL
C01020		BACC18Z2R CB-SLAT SHUTOFF	233T5111 81205	1	27-81-31 P011-02/ /H014	ALL
C01021		BACC18Z2R CB-FLAP/SLAT POSITION IND	233T5111 81205	1	27-58-11 P011-01/ /C004	ALL

EQUIPMENT LIST

D280T132

Section C01000

Page 1

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01022		BACC18Z2R CB-FLAP LOAD RELIEF	233T5111 81205	1	27-51-51 P011-02/ /J013	ALL
C01023		BACC18Z5R CB-AUTO. SPEED BRAKE	233T5111 81205	1	27-62-11 P011-02/ /G011	ALL
C01024		BACC18Z7R CB-STICK NUDGER	233T5111 81205	1	27-32-31 P011-02/ /K010	ALL
C01025		BACC18Z2R CB-FSEU CONT 1	233T5111 81205	1	27-51-61 P011-01/ /C016	ALL
C01026		BACC18Z5R CB-AILERON LOCKOUT,LEFT	233T5111 81205	1	27-11-12 P011-01/ /C017	ALL
C01027		BACC18Z5R CB-TE FLAPS ALT CONT	233T5111 81205	1	27-51-11 P011-05/ /J024	ALL
C01028		BACC18Z5R CB-INBD SLATS ALT CONT	233T5111 81205	1	27-81-11 P011-05/ /H023	ALL
C01029		BACC18Z5R CB-OUTBD SLAT,ALT CONT	233T5111 81205	1	27-81-21 P011-05/ /H024	ALL
C01030		BACC18Z5R CB-AILERON LOCKOUT,RIGHT	233T5111 81205	1	27-11-22 P011-01/ /C018	ALL
C01031		BACC18Z2R CB-RUDDER RATIO	233T5111 81205	1	27-21-12 P011-02/ /G010	ALL
C01033		BACC18Z2R CB-RUDDER TRIM	233T5111 81205	1	27-21-11 P011-01/ /C005	ALL
C01034		BACC18Z2R CB-RUDDER TRIM POS	233T5111 81205	1	27-28-13 P011-02/ /K017	ALL
C01035		BACC18Z2R CB-AILERON TRIM	233T5111 81205	1	27-11-11 P011-02/ /K015	ALL
C01036		BACC18Z2R CB-FSEU CONT 3	233T5111 81205	1	27-51-61 P011-05/ /G023	ALL
C01037		BACC18Z1R CB-FSEU SENSOR 1	233T5111 81205	1	27-51-61 P011-01/ /C015	ALL
C01038		BACC18Z2R CB-FSEU POS SENSOR 3	233T5111 81205	1	27-51-61 P011-05/ /G022	ALL
C01039		BACC18Z5R CB-STICK SHAKER,LEFT	233T5111 81205	1	27-32-21 P011-01/ /C011	ALL

EQUIPMENT LIST

D280T132

Section C01000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01040		BACC18Z5R CB-FUEL QTY REFUEL	284T0175 81205	1	28-41-12 P034-00/ /L002	ALL
C01041		BACC18Z5R CB-FUELING CONTROL	284T0175 81205	1	28-21-11 P034-00/ /L003	ALL
C01042		BACC18Z7R CB-DEFUELING VALVES	284T0175 81205	1	28-26-11 P034-00/ /L004	ALL
C01043		BACC18Z5R CB-FUELING CONTROL	284T0997 81205	1	28-21-11 P006-01/ /E005	ALL
C01044		BACC18Z7R CB-DEFUEL VALVES	284T0997 81205	1	28-26-11 P006-01/ /E007	ALL
C01045		BACC18Z5R CB-FUELING QTY	284T0997 81205	1	28-41-12 P006-01/ /E004	ALL
C01046		BACC18Z5R CB-FUELING VALVES	284T0997 81205	1	28-21-13 P006-01/ /E006	ALL
C01047		BACC18Z5R CB-FUELING VALVES	284T0175 81205	1	28-21-13 P034-00/ /L005	ALL
C01048		BACC18Z2R CB-FUEL QTY #1	233T5111 81205	1	28-41-12 P011-04/ /C034	ALL
C01049		BACC18Z2R CB-FUEL PUMP,LEFT CTR	233T5111 81205	1	28-22-12 P011-02/ /M015	ALL
C01050		BACC18Z2R CB-FUEL PUMP,RIGHT CTR	233T5111 81205	1	28-22-12 P011-05/ /M024	ALL
C01051		BACC18Z02R CB-FUEL CROSSFEED VALVE	233T5100 81205	1	28-22-31 P011-04/ /D036	ALL
C01052		BACC18Z3R CB-FUEL DC PUMP CONT	233T5111 81205	1	28-25-11 P011-04/ /D035	ALL
C01053		BACC18Z2R CB-FUEL QTY #2	233T5111 81205	1	28-41-12 P011-05/ /M019	ALL
C01054		BACC18Z2R CB-FUEL PUMP-R FWD/L AFT	233T5111 81205	1	28-22-11 P011-02/ /M016	ALL
C01055		BACC18Z2R CB-FUEL PUMP-L FWD/R AFT	233T5111 81205	1	28-22-11 P011-05/ /M025	ALL
C01058		BACC18Z7R CB-FUEL DC PUMP PWR	233T5111 81205	1	28-25-11 P011-04/ /D034	ALL

EQUIPMENT LIST

D280T132

Section C01000

Page 3

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01061		BACC18Z02R CB-L SPAR FUEL VALVE	284T0997 81205	1	28-22-21 P006-01/ /E001	ALL
C01062		BACC18Z02R CB-R SPAR FUEL VALVE	284T0997 81205	1	28-22-21 P006-01/ /E002	ALL
C01063		BACC18Z02R CB-APU FUEL VALVE	284T0997 81205	1	28-25-21 P006-01/ /E003	ALL
C01065	9	BACC18Z2R CB-FUEL JTSN CONT-LEFT (SB 28-0030)	233T5100 81205	1	28-31-11 P011-02/ /M013	051-099
C01065		BACC18Z2R CB-FUEL JTSN CONT-LEFT	233T5111 81205	1	28-31-11 P011-02/ /M013	050, 155-199, 277-299
C01065		BACC18Z2R CB-FUEL JTSN CONT-LEFT (INOP)	233T5100 81205	1	28-31-11 P011-02/ /M013	276
C01066	9	BACC18Z2R CB-FUEL JTSN CONT-RIGHT (SB 28-0030)	233T5100 81205	1	28-31-11 P011-05/ /M022	051-099
C01066		BACC18Z2R CB-FUEL JTSN CONT-RIGHT	233T5111 81205	1	28-31-11 P011-05/ /M022	050, 155-199, 277-299
C01066		BACC18Z2R CB-FUEL JTSN CONT-RIGHT (INOP)	233T5100 81205	1	28-31-11 P011-05/ /M022	276
C01067	9	BACC18Z2R CB-JTSN NOZZLE VALVE-LEFT (SB 28-0030)	233T5100 81205	1	28-31-12 P011-02/ /M014	051-099
C01067		BACC18Z2R CB-JTSN NOZZLE VALVE-LEFT	233T5111 81205	1	28-31-12 P011-02/ /M014	050, 155-199, 277-299
C01067		BACC18Z2R CB-JTSN NOZZLE VALVE-LEFT (INOP)	233T5100 81205	1	28-31-12 P011-02/ /M014	276
C01068	9	BACC18Z2R CB-JTSN NOZZLE VALVE-RIGHT (SB 28-0030)	233T5100 81205	1	28-31-12 P011-05/ /M023	051-099
C01068		BACC18Z2R CB-JTSN NOZZLE VALVE-RIGHT	233T5111 81205	1	28-31-12 P011-05/ /M023	050, 155-199, 277-299
C01068		BACC18Z2R CB-JTSN NOZZLE VALVE-RIGHT (INOP)	233T5100 81205	1	28-31-12 P011-05/ /M023	276
C01069	9	BACC18Z02R CB-FWD FUEL CROSSFEED VALVE (SB 28-0034)	233T5100 81205	1	28-22-31 P011-05/ /M020	ALL
C01070	9	BACC18Z02R CB-AFT FUEL CROSSFEED VALVE (SB 28-0034)	233T5100 81205	1	28-22-31 P011-05/ /M021	ALL

EQUIPMENT LIST

D280T132

Section C01000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01071	9	BACC18Z1R CB-CROSSFEED INDICATION (SB 28-0034)	233T5100 81205	1	28-22-31 P011-04/ /D036	ALL
C01073	1	BACC18Z10R CB-WATER HEATERS LAV 1/2 (INOP)	284T0188 81205	1	38-13-11 P037-00/ /H006	050-099, 150-199
C01080		BACC18Z3R CB-HYD SYS L PRESS.	233T5111 81205	1	29-31-11 P011-02/ /L017	ALL
C01081		BACC18Z3R CB-HYD SYS R PRESS.	233T5111 81205	1	29-31-11 P011-05/ /L026	ALL
C01082		BACC18Z3R CB-HYD SYS CTR PRESS	233T5111 81205	1	29-31-11 P011-02/ /L018	ALL
C01084		BACC18Z2R CB-HYD ELEC PUMP,L	233T5111 81205	1	29-11-12 P011-05/ /L025	ALL
C01085		BACC18Z5R CB-ELEC HYD PUMP C1	233T5111 81205	1	29-11-31 P011-02/ /L015	ALL
C01086		BACC18Z2R CB-ELEC HYD PUMP C2	233T5111 81205	1	29-11-31 P011-05/ /L024	ALL
C01087		BACC18Z2R CB-HYD ELEC PUMP,R	233T5111 81205	1	29-11-22 P011-02/ /L016	ALL
C01088		BACC18X35 CB-RAM AIR TURBINE POWER	284T0997 81205	1	29-21-31 P006-02/ /J008	ALL
C01089		BACC18Z2R CB-RAM AIR TURBINE MANUAL CONTROL	284T0997 81205	1	29-21-31 P006-01/ /C001	ALL
C01090		BACC18Z5R CB-HYDR PTU CONT	233T5111 81205	1	29-11-14 P011-02/ /L010	ALL
C01095		BACC18Z2R CB-HYD L ENG PUMP DEPRESS	233T5111 81205	1	29-11-11 P011-02/ /L014	ALL
C01096		BACC18Z2R CB-HYD R ENG PUMP DEPRESS	233T5111 81205	1	29-11-21 P011-05/ /L023	ALL
C01097		BACC18Z3R CB-ENG HYD PUMP L SUPPLY	233T5111 81205	1	29-11-11 P011-04/ /D029	ALL
C01098		BACC18Z3R CB-ENG HYD PUMP R SUPPLY	233T5111 81205	1	29-11-21 P011-04/ /D030	ALL
C01099		BACC18Z3R CB-AIR HYD PUMP	233T5111 81205	1	29-11-32 P011-04/ /D031	ALL

EQUIPMENT LIST

D280T132

Section C01000
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01100		BACC18Z2R CB-RAM AIR TURBINE AUTOMATIC CONTROL	284T0997 81205	1	29-21-31 P006-01/ /C002	ALL
C01101		BACC18Z3R CB-HYD QTY	233T5111 81205	1	29-33-11 P011-05/ /L020	ALL
C01110		BACC18Z5R CB-PITOT PROBE HT,CAPT PHASE A	284T0997 81205	1	30-31-11 P006-03/ /K014	150-199, 275-299
C01111		BACC18Z5R CB-PITOT PROBE HT,CAPT PHASE B	284T0997 81205	1	30-31-11 P006-03/ /K015	150-199, 275-299
C01112		BACC18Z5R CB-PITOT PROBE HT,R AUX PHASE B	284T0997 81205	1	30-31-13 P006-03/ /K016	150-199, 275-299
C01113		BACC18Z5R CB-PITOT PROBE HT,R AUX PHASE C	284T0997 81205	1	30-31-13 P006-03/ /K017	150-199, 275-299
C01114		BACC18Z5R CB-PITOT PROBE HT,L AUX PHASE B	284T0997 81205	1	30-31-23 P006-04/ /K021	ALL
C01115		BACC18Z5R CB-PITOT PROBE HT,L AUX PHASE C	284T0997 81205	1	30-31-23 P006-04/ /K020	ALL
C01116		BACC18Z5R CB-PITOT PROBE HT,F/O PHASE A	284T0997 81205	1	30-31-21 P006-04/ /K023	ALL
C01117		BACC18Z5R CB-PITOT PROBE HT,F/O PHASE B	284T0997 81205	1	30-31-21 P006-04/ /K022	ALL
C01118	9	BACC18Z5R CB-L ICE DETECTOR (SB 30-0017)	233T5100 81205	1	30-81-01 P011-03/ /T014	150-154
C01118		BACC18Z5R CB-L ICE DETECTOR	233T5111 81205	1	30-81-11 P011-03/ /T014	050-099, 155-199
C01119	9	BACC18Z5R CB-R ICE DETECTOR (SB 30-0017)	233T5100 81205	1	30-81-01 P011-06/ /T023	150-154
C01119		BACC18Z5R CB-R ICE DETECTOR	233T5111 81205	1	30-81-11 P011-06/ /T023	050-099, 155-199
C01120		BACC18Z2R CB-PROBE HEAT IND,LEFT	233T5111 81205	1	30-31-11 P011-01/ /A015	ALL
C01121		BACC18Z2R CB-PROBE HEAT IND,RIGHT	233T5111 81205	1	30-31-21 P011-04/ /A028	ALL
C01122		BACC18Z5R CB-ENGINE PROBE HEAT,LEFT	284T0997 81205	1	30-34-11 P006-03/ /L019	ALL

EQUIPMENT LIST

D280T132

Section C01100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01123		BACC18Z5R CB-ENGINE PROBE HEAT,RIGHT	284T0997 81205	1	30-34-21 P006-04/ /K025	ALL
C01124		BACC18Z7R CB-WINDOW HT NO.2,LEFT	284T0188 81205	1	30-41-12 P037-00/ /E001	ALL
C01125		BACC18Z7R CB-WINDOW HT NO.2,RIGHT	284T0187 81205	1	30-41-11 P036-00/ /H006	ALL
C01126		BACC18Z7R CB-WINDOW HT NO.3,LEFT	284T0188 81205	1	30-41-12 P037-00/ /E002	ALL
C01127		BACC18Z7R CB-WINDOW HT NO.3,RIGHT	284T0187 81205	1	30-41-11 P036-00/ /H007	ALL
C01128		BACC18Z2R CB-WINDOW HEAT TEST	233T5111 81205	1	30-41-11 P011-03/ /T015	ALL
C01130		BACC18Z2R CB-HEATER,DOOR WINDOW	233T5111 81205	1	30-46-11 P011-06/ /U032	ALL
C01132		BACC18Z2R CB-WING ANTI-ICE	233T5111 81205	1	30-11-11 P011-04/ /A031	ALL
C01133		BACC18Z5R CB-PROBE HT,L AOA	284T0997 81205	1	30-32-11 P006-03/ /L017	150-199, 275-299
C01136	9	BACC18Z2R CB-RAIN REPELLENT,R (INOP) (SB 30-0028)	233T5100 81205	1	30-43-11 P011-03/ /T012	050-099, 150-199
C01136		BACC18Z2R CB-RAIN REPELLENT,RIGHT	233T5100 81205	1	30-43-11 P011-03/ /T012	275-299
C01138		BACC18Z5R CB-TAT PROBE HEAT,LEFT	284T0997 81205	1	30-33-11 P006-03/ /L018	ALL
C01140	9	BACC18Z3R CB-ANTI-ICE ALT,R ENG (SB 30-0017)	233T5100 81205	1	30-21-11 P011-04/ /A030	150-154
C01140		BACC18Z3R CB-ANTI-ICE ALT,R ENG	233T5111 81205	1	30-21-11 P011-04/ /A030	050-099, 155-199
C01140		BACC18Z2R CB-ANTI-ICE ALT,R ENG	233T5111 81205	1	30-21-11 P011-04/ /A030	150-154, 275-299
C01141		BACC18Z5R CB-PROBE HT,R AOA	284T0997 81205	1	30-32-21 P006-04/ /K024	ALL
C01142		BACC18Z7R CB-DRAIN MAST HEATING,FLIGHT	284T0189 81205	1	30-71-11 P033-00/ /A002	ALL

EQUIPMENT LIST

D280T132

Section C01100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01143		BACC18Z10R CB-WINDSHIELD WIPER,LEFT	233T5111 81205	1	30-42-11 P011-03/ /T013	ALL
C01144		BACC18Z10R CB-WINDSHIELD WIPER,RIGHT	233T5111 81205	1	30-42-11 P011-06/ /T022	ALL
C01145	9	BACC18Z2R CB-RAIN REPELLENT,L (INOP) (SB 30-0028)	233T5100 81205	1	30-43-11 P011-06/ /T021	050-099, 150-199
C01145		BACC18Z2R CB-RAIN REPELLENT,LEFT	233T5100 81205	1	30-43-11 P011-06/ /T021	275-299
C01147	9	BACC18Z3R CB-ENGINE ANTI-ICE,L (SB 30-0017)	233T5100 81205	1	30-21-11 P011-01/ /A016	150-154
C01147		BACC18Z3R CB-ENGINE ANTI-ICE,L	233T5111 81205	1	30-21-11 P011-01/ /A016	050-099, 155-199
C01147		BACC18Z2R CB-ENGINE ANTI-ICE,L	233T5100 81205	1	30-21-11 P011-01/ /A016	150-154, 275-299
C01148	9	BACC18Z3R CB-ENGINE ANTI-ICE,R (SB 30-0017)	233T5100 81205	1	30-21-11 P011-06/ /T019	150-154
C01148		BACC18Z3R CB-ENGINE ANTI-ICE,R	233T5111 81205	1	30-21-11 P011-06/ /T019	050-099, 155-199
C01148		BACC18Z2R CB-ENGINE ANTI-ICE,R	233T5111 81205	1	30-21-11 P011-06/ /T019	150-154, 275-299
C01149		BACC18Z5R CB-HEATERS,FWD WATER LINE	284T0189 81205	1	30-71-21 P033-00/ /F001	050-099, 276-299
C01149		BACC18Z7R CB-HEATERS,FWD WATER LINE	284T0189 81205	1	30-71-21 P033-00/ /F001	150-199
C01149		BACC18Z5R CB-HEATERS,FWD WATER LINE	284T0188 81205	1	30-71-21 P037-00/ /J001	275
C01150		BACC18Z5R CB-HEATERS 1,MID WATER LINE	284T0189 81205	1	30-71-22 P033-00/ /G001	050-099, 150-199, 276-299
C01150		BACC18Z5R CB-HEATERS 1,MID WATER LINE	284T0188 81205	1	30-71-22 P037-00/ /J002	275
C01151		BACC18Z5R CB-HEATERS 1,AFT WATER LINE	284T0189 81205	1	30-71-23 P033-00/ /G005	050-099, 276-299
C01151		BACC18Z7R CB-HEATERS 1,AFT WATER LINE	284T0189 81205	1	30-71-23 P033-00/ /G005	150-199

EQUIPMENT LIST

D280T132

Section C01100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01151		BACC18Z5R CB-HEATERS 1,AFT WATER LINE	284T0188 81205	1	30-71-23 P037-00/ /J006	275
C01154		BACC18X15 CB-HEATER,POTABLE WATER TANK	284T0175 81205	1	30-71-24 P034-00/ /P010	050-099, 150-199
C01155		BACC18Z5R CB-HEATERS 3,MID WATER LINE	284T0189 81205	1	30-71-22 P033-00/ /G003	050-099, 276-299
C01155		BACC18Z7R CB-HEATERS 3,MID WATER LINE	284T0189 81205	1	30-71-21 P033-00/ /G003	150-199
C01155		BACC18Z5R CB-HEATERS 3,MID WATER LINE	284T0188 81205	1	30-71-22 P037-00/ /J004	275
C01156		BACC18Z5R CB-HEATERS 2,AFT WATER LINE	284T0189 81205	1	30-71-23 P033-00/ /G006	050-099, 276-299
C01156		BACC18Z7R CB-HEATERS 2,AFT WATER LINE	284T0189 81205	1	30-71-23 P033-00/ /G006	150-199
C01156		BACC18Z5R CB-HEATERS 2,AFT WATER LINE	284T0188 81205	1	30-71-23 P037-00/ /J007	275
C01157		BACC18Z5R CB-HEATERS 2,MID WATER LINE	284T0189 81205	1	30-71-22 P033-00/ /G002	050-099, 150-199, 276-299
C01157		BACC18Z5R CB-HEATERS 2,MID WATER LINE	284T0188 81205	1	30-71-22 P037-00/ /J003	275
C01158		BACC18Z5R CB-HEATERS 4,MID WATER LINE	284T0189 81205	1	30-71-22 P033-00/ /G004	050-099, 276-299
C01158		BACC18Z7R CB-HEATERS 4,MID WATER LINE	284T0188 81205	1	30-71-22 P033-00/ /G004	150-199
C01158		BACC18Z5R CB-HEATERS 4,MID WATER LINE	284T0188 81205	1	30-71-22 P037-00/ /J005	275
C01165		BACC18Z2R CB-DRAIN MAST HEATING,GND	284T0189 81205	1	30-71-11 P033-00/ /A001	ALL
C01166		BACC18Z5R CB-HEATERS 3,AFT WATER LINE	284T0189 81205	1	30-71-24 P033-00/ /G007	050-099
C01166		BACC18Z7R CB-HEATERS 3,AFT WATER LINE	284T0189 81205	1	30-71-24 P033-00/ /G007	150-199
C01166		BACC18Z5R CB-HEATERS 3 AFT WATER LINE	284T0188 81205	1	30-71-23 P037-00/ /H004	275

EQUIPMENT LIST

D280T132

Section C01100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01166		BACC18Z5R CB-HEATERS 3,AFT WATER LINE	284T0189 81205	1	30-71-23 P033-00/ /G007	276-299
C01167		BACC18Z10R CB-HEATER,GALLEY WATER LINE	284T0175 81205	1	30-71-25 P034-00/ /P008	050-099, 150-199
C01170		BACC18Z2R CB-LDG GR POS AIR/GND SYS 2	233T5111 81205	1	32-09-12 P011-06/ /U023	ALL
C01171		BACC18Z1R CB-LDG GR,ANTISKID 1-5	233T5111 81205	1	32-42-11 P011-03/ /U018	ALL
C01172		BACC18Z1R CB-LDG GR,ANTISKID 4-8	233T5111 81205	1	32-42-11 P011-06/ /U027	ALL
C01173		BACC18Z02R CB-AUTOBRKS ANTISKID TEST/IND 2	233T5111 81205	1	32-42-12 P011-06/ /U021	ALL
C01174		BACC18Z2R CB-LANDING GEAR LEVER LOCK	233T5111 81205	1	32-31-11 P011-06/ /U020	ALL
C01175		BACC18Z2R CB-LDG GR POS AIR/GND SYS 1	233T5111 81205	1	32-09-11 P011-04/ /C030	ALL
C01176		BACC18Z02R CB-AUTOBRKS ANTISKID TEST/IND 1	233T5111 81205	1	32-42-11 P011-03/ /U012	ALL
C01177		BACC18Z5R CB-LDG GR ALTN EXT LATCH RST	233T5111 81205	1	32-35-11 P011-03/ /U014	ALL
C01178		BACC18Z2R CB-PROX SW TEST	233T5111 81205	1	32-09-21 P011-06/ /T036	ALL
C01179		BACC18Z2R CB-PARKING BRAKE VALVE	284T0997 81205	1	32-44-11 P006-01/ /F004	ALL
C01180		BACC18Z3R CB-BRAKE PRESS.	233T5111 81205	1	32-41-11 P011-06/ /U022	ALL
C01181		BACC18Z2R CB-BRAKE TEMP	233T5111 81205	1	32-46-11 P011-03/ /U016	ALL
C01182		BACC18Z2R CB-AIR/GND SYS 1	233T5111 81205	1	32-09-11 P011-03/ /U015	ALL
C01183		BACC18Z1R CB-LDG GR,ANTISKID 2-6	233T5111 81205	1	32-42-11 P011-04/ /C031	ALL
C01184		BACC18Z1R CB-LDG GR,ANTISKID 3-7	233T5111 81205	1	32-42-11 P011-04/ /C032	ALL

EQUIPMENT LIST

D280T132

Section C01100

Page 5

Aug 15/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01185		BACC18Z2R CB-TAIL SKID CONT	233T5111 81205	1	32-71-11 P011-06/ /U026	150-199, 275-299
C01186	9	BACC18Z2R CB-TIRE PRESS IND 1 (SB 32-0085)	233T5100 81205	1	32-45-11 P011-03/ /U017	275-276
C01186		BACC18Z2R CB-TIRE PRESS IND 1	233T5111 81205	1	32-45-11 P011-03/ /U017	050-099, 155-199, 277-299
C01186		BACC18Z2R CB-TIRE PRESS IND 1 (INOP)	233T5100 81205	1	32-45-11 P011-03/ /U017	150-154
C01187	9	BACC18Z2R CB-TIRE PRESS IND 2 (SB 32-0085)	284T0175 81205	1	32-45-11 P034-00/ /M011	275-276
C01187		BACC18Z2R CB-TIRE PRESS IND 2	284T0175 81205	1	32-45-11 P034-00/ /M011	050-099, 155-199, 277-299
C01187		BACC18Z2R CB-TIRE PRESS IND 2 (INOP)	284T0175 81205	1	32-45-11 P034-00/ /M011	150-154
C01190	9	BACC18AD2 CB-ADC SOURCE SELECT RLY-L (SB 34A0332)	284T0997 81205	1	34-12-61 P006-05/ /J032	ALL
C01191	9	BACC18AD2 CB-ADC SOURCE SELECT RLY-R (SB 34A0332)	284T0997 81205	1	34-12-62 P006-05/ /J033	ALL
C01192		BACC18Z5R CB-POSITION LIGHT, LEFT	233T5111 81205	1	33-43-11 P011-06/ /S028	ALL
C01193		BACC18Z5R CB-POSITION LIGHT, RIGHT	233T5111 81205	1	33-43-11 P011-06/ /S030	ALL
C01194		BACC18Z2R CB-LAV CALL/SMOKE DET SYS	233T5111 81205	1	33-25-11 P011-06/ /P034	275-299
C01195	9	BACC18AC7 CB-R. FWD DR AREA HTR-PWR (SB 21-0139)	284T1351 81073	1	21-45-21 P037-00/ /B004	275-299

EQUIPMENT LIST

D280T132

Section C01100
Page 6 End
May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01200		BACC18Z5R CB-3,IND LTS	233T5111 81205	1	33-16-12 P011-04/ /A035	ALL
C01202		BACC18Z2R CB-WING LANDING LIGHTS DIM CONTROL	233T5111 81205	1	33-42-11 P011-06/ /N031	ALL
C01203		BACC18Z5R CB-NIGHT LTS,FWD	233T5100 81205	1	33-21-21 P011-06/ /R032	050-099
C01203		BACC18Z5R CB-NIGHT LTS,FWD	233T5111 81205	1	33-21-21 P011-06/ /R032	150-199, 280-299
C01203		BACC18Z2R CB-NIGHT LTS,FWD	233T5111 81205	1	33-21-21 P011-06/ /R032	275-278
C01204		BACC18Z1R CB-NIGHT LTS,AFT PASS.	284T0188 81205	1	33-21-21 P037-00/ /L007	ALL
C01205		BACC18Z3R CB-NLG WW SVCE LTS	284T3300 81205	1	33-31-11 P033-00/ /J004	ALL
C01206		BACC18Z3R CB-MN GEAR WW SVCE LTS	284T0189 81205	1	33-31-11 P033-00/ /J005	ALL
C01207		BACC18Z2R CB-INDIRECT CLG LTS CONT	284T0189 81205	1	33-21-11 P033-00/ /L002	ALL
C01209		BACC18Z7R CB-FWD CARGO COMPT LTS	284T0175 81205	1	33-37-11 P034-00/ /S010	ALL
C01210		BACC18Z7R CB-AFT CARGO COMPT LTS	284T0175 81205	1	33-37-21 P034-00/ /S011	ALL
C01211		BACC18X15 CB-FWD IND CLG/GLY LTS	284T0189 81205	1	33-21-11 P033-00/ /L001	ALL
C01212		BACC18Z2R CB-PORT. EMER LT CHGR	233T5111 81205	1	33-51-11 P011-01/ /B006	ALL
C01213		BACC18Z5R CB-LIGHTS,FLIGHT DECK DOME	284T0189 81205	1	33-11-14 P033-00/ /K007	ALL
C01215		BACC18Z5R CB-LIGHTS,LAVATORY SERVICE	284T0175 81205	1	33-26-11 P034-00/ /S004	275-299
C01216		BACC18Z2R CB-ATTEND. LIGHT CONT	233T5100 81205	1	33-21-11 P011-06/ /P033	050-099, 150-199
C01219		BACC18X15 CB-INDIRECT CLG LTS, AFT INBD	284T0189 81205	1	33-21-12 P033-00/ /L003	ALL

EQUIPMENT LIST

D280T132

Section C01200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01220		BACC18Z5R CB-DIRECT CEILING LTS,FWD	284T0189 81205	1	33-22-41 P033-00/ /L005	ALL
C01221		BACC18Z1R CB-AFT DIRECT CEILING LTS	284T0189 81205	1	33-22-42 P033-00/ /L006	050-099
C01221		BACC18Z2R CB-AFT DIRECT CEILING LTS	284T0189 81205	1	33-22-42 P033-00/ /L006	150-199
C01221		BACC18Z5R CB-AFT DIRECT CEILING LTS	284T0189 81205	1	33-22-42 P033-00/ /L006	275-299
C01222		BACC18X15 CB-INDIRECT CLG LTS,AFT OUTBOARD	284T0189 81205	1	33-21-12 P033-00/ /L004	ALL
C01223		BACC18Z2R CB-CALL SYSTEM,LAV	233T5111 81205	1	33-25-11 P011-06/ /P034	050-099, 150-199
C01225		BACC18Z5R CB-ANTI-COLL LTS,RED	233T5111 81205	1	33-44-11 P011-06/ /N034	ALL
C01226		BACC18Z5R CB-ANTI-COLL LTS,WHITE	233T5111 81205	1	33-44-21 P011-03/ /N007	ALL
C01227		BACC18Z5R CB-WING ILLUM LIGHTS	233T5111 81205	1	33-41-11 P011-06/ /N035	ALL
C01229		BACC18Z2R CB-LIGHTS,CLOSET	284T0189 81205	1	33-22-21 P033-00/ /H004	ALL
C01232		BACC18Z2R CB-LIGHTING CONTROL RLY,5KVA INSTR	233T5111 81205	1	33-13-16 P011-03/ /S005	ALL
C01237		BACC18Z2R CB-INSTR & PNL LTS,CAPT	233T5111 81205	1	33-13-11 P011-03/ /P002	ALL
C01238		BACC18Z2R CB-CREW REST LIGHTS	233T5100 81205	1	33-22-33 P011-06/ /S031	050-099, 162-199
C01239		BACC18Z2R CB-INSTR & PNL LTS,F/O	233T5111 81205	1	33-13-13 P011-06/ /P028	ALL
C01240		BACC18Z2R CB-GLARESHIELD INSTR & PNL LTS	233T5111 81205	1	33-13-17 P011-06/ /P030	ALL
C01241		BACC18Z5R CB-OVHD INSTR & PNL LTS	233T5111 81205	1	33-13-16 P011-03/ /P003	ALL
C01242		BACC18Z5R CB-AISLE STAND INSTR & PNL LTS	233T5111 81205	1	33-13-18 P011-03/ /P001	ALL

EQUIPMENT LIST

D280T132

Section C01200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01244		BACC18Z5R CB-OVHD CB INSTR & PNL LIGHT	233T5111 81205	1	33-13-19 P011-03/ /P004	ALL
C01246		BACC18Z2R CB-STBY INSTR LTS	233T5111 81205	1	33-13-11 P011-01/ /B007	ALL
C01247		BACC18Z7R CB-NOSE GEAR LDG LT,L	233T5111 81205	1	33-42-11 P011-03/ /N003	ALL
C01248		BACC18Z7R CB-NOSE GEAR LDG LT,R	233T5111 81205	1	33-42-11 P011-03/ /N004	ALL
C01249		BACC18Z7R CB-WING LDG LT,L	233T5111 81205	1	33-42-11 P011-03/ /N005	ALL
C01250		BACC18Z7R CB-WING LDG LT,R	233T5111 81205	1	33-42-11 P011-06/ /N032	ALL
C01251		BACC18Z2R CB-MAP LIGHTS	233T5111 81205	1	33-14-11 P011-06/ /P031	ALL
C01252		BACC18Z2R CB-LTS,CHART	233T5111 81205	1	33-14-21 P011-03/ /P008	ALL
C01253		BACC18Z5R CB-S/BELT SIGN	284T0189 81205	1	33-24-11 P033-00/ /J001	050-099
C01253		BACC18Z7R CB-S/BELT SIGN	284T0189 81205	1	33-24-11 P033-00/ /J001	150-199, 275-299
C01254		BACC18Z2R CB-PASS. SIGN CONT	233T5111 81205	1	33-24-11 P011-03/ /P009	ALL
C01255		BACC18Z02R CB-ENTRY/ATTENDANT LTS,AFT	284T0189 81205	1	33-22-11 P033-00/ /K005	ALL
C01256		BACC18Z1R CB-APU/TAIL COMPT LT	284T0175 81205	1	33-31-31 P034-00/ /S003	ALL
C01257		BACC18Z10R CB-ELEC EQUIP CTR LIGHTS	284T0189 81205	1	33-31-41 P033-00/ /K006	ALL
C01258		BACC18Z5R CB-LAV SIGNS	284T0189 81205	1	33-24-11 P033-00/ /H001	ALL
C01259		BACC18Z2R CB-LIGHTS CONTROL,NOSE GEAR	233T5111 81205	1	33-42-11 P011-03/ /N001	ALL
C01260		BACC18Z5R CB-S/BELT NO SMOKE SIGNS	284T0189 81205	1	33-24-11 P033-00/ /J002	050-099

EQUIPMENT LIST

D280T132

Section C01200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01260		BACC18Z7R CB-S/BELT NO SMOKE SIGNS	284T0189 81205	1	33-24-11 P033-00/ /J002	150-199, 275-299
C01262		BACC18Z5R CB-GALLEY LTS	284T0189 81205	1	33-27-11 P033-00/ /L007	ALL
C01263		BACC18Z10R CB-FWD SIDEWALL/GLY LTS	284T0189 81205	1	33-21-31 P033-00/ /K001	050-099
C01263		BACC18X15 CB-FWD SIDEWALL/GLY LTS	284T0189 81205	1	33-21-31 P033-00/ /K001	150-199, 275-299
C01265		BACC18Z10R CB-SIDEWALL LTS AFT	284T0189 81205	1	33-21-31 P033-00/ /K002	050-099
C01265		BACC18X15 CB-SIDEWALL LTS AFT	284T0189 81205	1	33-21-31 P033-00/ /K002	150-199, 275-299
C01266		BACC18Z2R CB-SIDEWALL LTS CONTROL	284T0189 81205	1	33-21-31 P033-00/ /K003	ALL
C01269		BACC18Z7R CB-ENTRY/ATTENDANT LTS,FWD	284T0189 81205	1	33-22-11 P033-00/ /K004	050-099, 150-199, 280-299
C01269		BACC18Z5R CB-ENTRY/ATTENDANT LTS,FWD	284T0189 81205	1	33-22-11 P033-00/ /K004	275-278
C01273		BACC18Z5R CB-R1,IND LTS	233T5111 81205	1	33-16-12 P011-06/ /R028	ALL
C01274		BACC18Z5R CB-R2,IND LTS	233T5111 81205	1	33-16-12 P011-06/ /R029	ALL
C01275		BACC18Z5R CB-LOGO LIGHTS,L	284T0188 81205	1	33-45-11 P037-00/ /L005	ALL
C01276		BACC18Z2R CB-RUNWAY TURNOFF LT,L	233T5111 81205	1	33-42-21 P011-03/ /N006	ALL
C01277		BACC18Z2R CB-RUNWAY TURNOFF LT,R	233T5111 81205	1	33-42-21 P011-06/ /N033	ALL
C01278		BACC18Z5R CB-LOGO LIGHTS,L	284T0189 81205	1	33-45-11 P033-00/ /J006	ALL
C01279		BACC18Z5R CB-LOGO LIGHTS,R	284T0189 81205	1	33-45-11 P033-00/ /J007	ALL
C01280		BACC18Z5R CB-EMER LTS/OFF WG ESC R	233T5111 81205	1	33-51-11 P011-06/ /P036	ALL

EQUIPMENT LIST

D280T132

Section C01200

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01281		BACC18Z2R CB-LIGHTS,UTILITY	233T5111 81205	1	33-14-31 P011-06/ /P032	ALL
C01282		BACC18Z5R CB-LOGO LIGHTS,R	284T0188 81205	1	33-45-11 P037-00/ /L006	ALL
C01283		BACC18Z2R CB-MAIN PNL FLOOD LT	233T5111 81205	1	33-11-11 P011-01/ /B004	ALL
C01284		BACC18Z5R CB-R3,IND LTS	233T5111 81205	1	33-16-12 P011-06/ /R030	ALL
C01287		BACC18Z2R CB-AISLE STAND FLOOD LT	233T5111 81205	1	33-11-13 P011-01/ /B005	ALL
C01289		BACC18Z2R CB-FLOOD LT STBY CONT	233T5111 81205	1	33-11-11 P011-03/ /P005	ALL
C01290		BACC18Z7R CB-LAV LTS & WTR LINE HTRS, SYS 1	284T0175 81205	1	33-26-11 P034-00/ /S004	050-099, 150-199
C01291		BACC18Z7R CB-LAV LTS & WTR LINE HTRS, SYS 2	284T0175 81205	1	33-26-11 P034-00/ /S005	050-099, 150-199
C01293		BACC18Z5R CB-L1,IND LTS	233T5111 81205	1	33-16-12 P011-03/ /R001	ALL
C01296		BACC18Z5R CB-NO SMOKE SIGN	284T0189 81205	1	33-24-11 P033-00/ /J003	050-099
C01296		BACC18Z7R CB-NO SMOKE SIGN	284T0189 81205	1	33-24-11 P033-00/ /J003	150-199, 275-299
C01297		BACC18Z5R CB-L2,IND LTS	233T5111 81205	1	33-16-12 P011-03/ /R002	ALL
C01298		BACC18Z5R CB-L3,IND LTS	233T5111 81205	1	33-16-12 P011-03/ /R003	ALL

EQUIPMENT LIST

D280T132

Section C01200

Page 5 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01300		BACC18Z2R CB-AIR COND COMPT LIGHTS	284T0175 81205	1	33-31-21 P034-00/ /S002	ALL
C01302		BACC18Z5R CB-EMER LTS/OFF WG ESC L	233T5111 81205	1	33-51-11 P011-06/ /P035	ALL
C01303		BACC18Z3R CB-EMER LTS/OFF WG ESC,L ALTERNATE	233T5111 81205	1	33-51-11 P011-04/ /A019	ALL
C01306		BACC18Z5R CB-1,IND LTS	233T5111 81205	1	33-16-12 P011-04/ /A033	ALL
C01307		BACC18Z2R CB-TEST,IND LTS	233T5111 81205	1	33-16-11 P011-04/ /A032	ALL
C01308		BACC18Z5R CB-2,IND LTS	233T5111 81205	1	33-16-12 P011-04/ /A034	ALL
C01309		BACC18Z2R CB-DIM CONT,IND LTS	233T5111 81205	1	33-16-11 P011-03/ /R005	ALL
C01310		BACC18Z3R CB-EMER LTS/OFF WG ESC,R ALTERNATE	233T5111 81205	1	33-51-11 P011-04/ /A020	ALL
C01312		BACC18Z5R CB-TAXI LIGHT-L	233T5111 81205	1	33-42-21 P011-03/ /N008	ALL
C01313		BACC18Z5R CB-TAXI LIGHT,R	233T5111 81205	1	33-42-21 P011-03/ /N009	ALL
C01316		BACC18Z3R CB-MIRROR LTS LAV SYS 1	233T5111 81205	1	33-26-11 P011-03/ /R009	ALL
C01317		BACC18Z3R CB-MIRROR LTS LAV SYS 2	233T5111 81205	1	33-26-11 P011-06/ /R036	ALL
C01318		BACC18Z5R CB-LTS,LAVATORY SYS 1	233T5111 81205	1	33-26-21 P011-03/ /R007	ALL
C01319		BACC18Z5R CB-LTS,LAVATORY SYS 2	233T5111 81205	1	33-26-21 P011-06/ /R034	ALL
C01320		BACC18Z2R CB-OXYGEN PRESSURE	233T5111 81205	1	35-11-13 P011-06/ /U029	ALL
C01321		BACC18Z7R CB-PASS. OXY,LEFT	233T5111 81205	1	35-21-12 P011-04/ /A021	ALL
C01322		BACC18Z7R CB-PASS. OXY,RIGHT	233T5111 81205	1	35-21-13 P011-04/ /A023	ALL

EQUIPMENT LIST

D280T132

Section C01300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01323		BACC18Z2R CB-PASS. OXY CONT	233T5111 81205	1	35-21-11 P011-04/ /A024	ALL
C01324		BACC18Z7R CB-PASS. OXY,CENTER	233T5111 81205	1	35-21-14 P011-04/ /A022	ALL
C01325		BACC18Z2R CB-PASS. OXY,MANUAL DEPLOY	233T5111 81205	1	35-21-11 P011-04/ /A025	ALL
C01330		BACC18Z2R CB-AIR SUPPLY ISOLATION VALVE POWER,LEFT	233T5111 81205	1	36-11-11 P011-03/ /S012	ALL
C01331		BACC18Z2R CB-AIR SUPPLY ISLN VALVE POWER,RIGHT	233T5111 81205	1	36-11-21 P011-06/ /S021	ALL
C01332		BACC18Z2R CB-AIR SUPPLY DUCT PRESS. IND,LEFT	233T5111 81205	1	36-21-11 P011-03/ /S016	ALL
C01333		BACC18Z2R CB-AIR SUPPLY APU BLEED CONTROL	233T5111 81205	1	36-11-41 P011-06/ /S024	ALL
C01334		BACC18Z2R CB-AIR SUPPLY ISOLATION VALVE CONT,LEFT	233T5111 81205	1	36-11-11 P011-01/ /A014	ALL
C01335		BACC18Z2R CB-AIR SUPPLY ISOLATION VALVE CONT,RIGHT	233T5111 81205	1	36-11-21 P011-06/ /S022	ALL
C01336		BACC18Z2R CB-AIR SUPPLY APU BLEED POWER	233T5111 81205	1	36-11-41 P011-06/ /S023	ALL
C01337		BACC18Z2R CB-AIR SUPPLY ISOLATION VALVE POWER,CTR	233T5111 81205	1	36-11-31 P011-03/ /S014	ALL
C01338		BACC18Z2R CB-AIR SUPPLY ISOLATION VALVE CONT,CTR	233T5111 81205	1	36-11-31 P011-03/ /S015	ALL
C01339		BACC18Z5R CB-AIR SUPPLY ENG BLEED CONT,LEFT	233T5111 81205	1	36-11-51 P011-03/ /S011	ALL
C01340		BACC18Z5R CB-AIR SUPPLY ENG BLEED CONT,RIGHT	233T5111 81205	1	36-11-52 P011-06/ /S020	ALL
C01341		BACC18Z2R CB-AIR SUPPLY BITE	284T0187 81205	1	36-23-11 P036-00/ /L007	ALL
C01342		BACC18Z2R CB-AIR SUPPLY DUCT PRESS. IND,RIGHT	233T5111 81205	1	36-21-11 P011-06/ /S025	ALL
C01343		BACC18Z2R CB-AIR SUPPLY ENG BLEED IND,LEFT	233T5111 81205	1	36-11-51 P011-03/ /S010	ALL

EQUIPMENT LIST

D280T132

Section C01300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01344		BACC18Z2R CB-AIR SUPPLY ENG BLEED IND,RIGHT	233T5111 81205	1	36-11-52 P011-06/ /S019	ALL
C01345		BACC18Z2R CB-AIR SUPPLY ISLN VALVE CONT ALT,RIGHT	233T5111 81205	1	36-11-21 P011-04/ /A027	ALL
C01350		BACC18Z5R CB-PRESSURE REGULATING VALVE CONT,LEFT	233T5100 81205	1	36-11-61 P011-03/ /N014	050-099, 155-156, 162-166
C01351		BACC18Z5R CB-PRESSURE REGULATING VALVE CONT,RIGHT	233T5100 81205	1	36-11-62 P011-06/ /N023	050-099, 155-156, 162-166
C01353		BACC18Z2R CB-POTABLE WATER/ENTRY LTS	233T5111 81205	1	38-15-11 P011-06/ /U028	ALL
C01354		BACC18Z2R CB-POTABLE WATER/ENTRY LTS	284T0175 81205	1	38-15-11 P034-00/ /P011	ALL
C01365		BACC18X15 CB-WATER HEATERS LAV SYSTEM 1	284T0187 81205	1	38-13-11 P036-00/ /D007	ALL
C01366		BACC18X15 CB-WATER HEATERS LAV SYSTEM 2	284T0188 81205	1	38-13-11 P037-00/ /H007	ALL
C01367		BACC18Z5R CB-FLUSH CONTROL LAV SYSTEM 1	233T5111 81205	1	38-32-11 P011-03/ /R008	050-099, 275-299
C01367		BACC18Z7R CB-FLUSH CONTROL LAV SYSTEM 1	233T5100 81205	1	38-32-11 P011-03/ /R008	150-199
C01368		BACC18Z5R CB-FLUSH CONTROL LAV SYSTEM 2	233T5111 81205	1	38-32-11 P011-06/ /R035	ALL
C01371		BACC18Z2R CB-VACUUM S/O VALVE, LAV SYS 1 (INOP)	233T5111 81205	1	38-32-14 P011-03/ /R006	ALL
C01372		BACC18Z2R CB-VACUUM S/O VALVE, LAV SYS 2 (INOP)	233T5111 81205	1	38-32-14 P011-06/ /R033	ALL
C01373	1	BACC18Z10R CB-WATER HEATERS LAV SYSTEM 1/2 (INOP)	284T0188 81205	1	38-13-11 P037-00/ /H006	050-099, 150-199
C01373	2	BACC18X10 CB-WATER HEATERS LAV SYSTEM 1/2 (INOP)	284T0188 81205	1	24-51-23 P037-00/ /H006	050-099, 150-199
C01374	9	BACC18Z5R CB-LAV FLUSH CONT SYS 1 (SB 38-0035)	284T0175 81205	1	38-32-11 P034-00/ /N010	275-276
C01374		BACC18Z5R CB-LAV FLUSH CONT SYS 1	284T0175 81205	1	38-32-11 P034-00/ /N010	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section C01300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01375	9	BACC18Z5R CB-LAV FLUSH CONT SYS 2 (SB 38-0035)	284T0175 81205	1	38-32-11 P034-00/ /N011	275-276
C01375		BACC18Z5R CB-LAV FLUSH CONT SYS 2	284T0175 81205	1	38-32-11 P034-00/ /N011	156-157, 166-199, 277-299
C01383		BACC18Z7R CB-APU PRIME CONTROL	284T1149 81205	1	49-61-11 P049-00/ /C002	ALL
C01385		BACC18Z5R CB-APU INLET DOOR ACTR	284T1149 81205	1	49-15-11 P049-00/ /C004	ALL
C01391		BACC18Z7R CB-APU ALTN CONTROL	233T5111 81205	1	49-61-11 P011-04/ /B035	ALL

EQUIPMENT LIST

D280T132

Section C01300

Page 4 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01400		BACC18Z2R CB-DR LOCK,FLT DECK	233T5111 81205	1	52-51-11 P011-03/ /T005	ALL
C01401		BACC18Z2R CB-EEC DISCRETES ALT,R ENG	233T5100 81205	1	73-21-17 P011-04/ /A029	ALL
C01402		BACC18Z2R CB-ENTRY DR CONT,FWD	233T5111 81205	1	52-11-12 P011-03/ /T006	ALL
C01403		BACC18Z2R CB-CONT-DOOR-CARGO	284T0175 81205	1	52-34-12 P034-00/ /J004	ALL
C01404		BACC18Z2R CB-EEC DISCRETES,LEFT ENGINE	233T5100 81205	1	73-21-17 P011-01/ /D017	ALL
C01405		BACC18Z2R CB-EEC DISCRETES,RIGHT ENGINE	233T5111 81205	1	73-21-17 P011-05/ /M032	ALL
C01406		BACC18Z2R CB-DOOR INDICATION	233T5111 81205	1	52-71-11 P011-06/ /T033	ALL
C01408		BACC18Z2R CB-CONT-DOOR-FWD ENTRY	284T0175 81205	1	52-11-12 P034-00/ /J005	ALL
C01412		BACC18Z02R CB-FUEL TEMP	233T5100 81205	1	28-43-11 P011-02/ /M012	ALL
C01415		BACC18Z1R CB-FUEL PRESS.,LEFT ENG	233T5111 81205	1	73-33-11 P011-02/ /M007	ALL
C01416		BACC18Z1R CB-FUEL PRESS.,RIGHT ENG	233T5111 81205	1	73-33-11 P011-05/ /M034	ALL
C01419		BACC18Z2R CB-L ENG FUEL CONT VLV & EEC CH B RST	233T5111 81205	1	76-11-11 P011-04/ /D025	ALL
C01420		BACC18Z2R CB-R ENG FUEL CONT VLV & EEC CH B RST	233T5111 81205	1	76-11-11 P011-04/ /D026	ALL
C01422		BACC18Z5R CB-EEC GND TEST-L	284T0175 81205	1	73-21-11 P034-00/ /P002	150-154
C01423		BACC18Z5R CB-EEC GND TEST-R	284T0175 81205	1	73-21-11 P034-00/ /P003	150-154
C01426		BACC18Z2R CB-ENGINE SPEED SENSE L2	233T5111 81205	1	73-21-18 P011-01/ /D015	ALL
C01427		BACC18Z2R CB-ENGINE SPEED SENSE R2	233T5111 81205	1	73-21-18 P011-01/ /D016	ALL

EQUIPMENT LIST

D280T132

Section C01400

Page 1

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01428		BACC18Z2R CB-ENGINE SPEED SENSE L1	233T5111 81205	1	73-21-18 P011-04/ /D023	ALL
C01429		BACC18Z2R CB-ENGINE SPEED SENSE R1	233T5111 81205	1	73-21-18 P011-04/ /D024	ALL
C01430		BACC18Z2R CB-IGNITION 1,LEFT ENG	233T5111 81205	1	74-31-11 P011-02/ /M001	ALL
C01431		BACC18Z2R CB-IGNITION 2,LEFT ENG	233T5111 81205	1	74-31-11 P011-05/ /M028	ALL
C01432		BACC18Z2R CB-IGNITION 1,RIGHT ENG	233T5111 81205	1	74-31-21 P011-02/ /M002	ALL
C01433		BACC18Z2R CB-IGNITION 2,RIGHT ENG	233T5111 81205	1	74-31-21 P011-05/ /M029	ALL
C01434		BACC18Z5R CB-STANDBY IGNITION 1	233T5111 81205	1	74-31-11 P011-01/ /D007	ALL
C01435		BACC18Z5R CB-STANDBY IGNITION 2	233T5111 81205	1	74-31-11 P011-01/ /D008	ALL
C01439		BACC18Z1R CB-BUS POWER SENSE,LEFT ENG	233T5111 81205	1	74-31-11 P011-02/ /M009	ALL
C01440		BACC18Z1R CB-BUS POWER SENSE,RIGHT ENG	233T5111 81205	1	74-31-11 P011-05/ /M036	ALL
C01449		BACC18Z2R CB-L ENG NAC VENT VALVE	233T5111 81205	1	75-23-11 P011-02/ /K009	ALL
C01450		BACC18Z2R CB-R ENG NAC VENT VALVE	233T5111 81205	1	75-23-11 P011-05/ /L035	ALL
C01457		BACC18Z2R CB-R ENG IDLE CONTROL	233T5111 81205	1	73-21-19 P011-05/ /M033	ALL
C01458		BACC18Z2R CB-L ENG IDLE CONTROL	233T5111 81205	1	73-21-19 P011-02/ /M006	ALL
C01459		BACC18Z3R CB-ENGINE IDLE CONTROL	284T0175 09922	1	73-21-19 P034-00/ /L001	ALL
C01460	9	BACC18Z7R CB-EEC/SCU PWR-L ENG (SB 76-026)	233T5100 81205	1	73-21-11 P011-02/ /L007	150-154, 275-276
C01460		BACC18Z7R CB-EEC/SCU PWR-L ENG	233T5100 81205	1	73-21-11 P011-02/ /L007	050-099, 155-199, 277-299

EQUIPMENT LIST

D280T132

Section C01400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01461	9	BACC18Z7R CB-EEC/SCU PWR-R ENG (SB 76-026)	233T5100 81205	1	73-21-11 P011-05/ /K028	150-154, 275-276
C01461		BACC18Z7R CB-EEC/SCU PWR-R ENG	233T5100 81205	1	73-21-11 P011-05/ /K028	050-099, 155-199, 277-299
C01462		BACC18Z1R CB-L ENG EEC CHAN A RST	233T5100 81205	1	73-21-11 P011-04/ /C027	ALL
C01463		BACC18Z1R CB-R ENG EEC CHAN A RST	233T5100 81205	1	73-21-11 P011-04/ /C028	ALL
C01464		BACC18Z2R CB-ENG VIB MONITOR	233T5111 81205	1	77-31-11 P011-02/ /K001	ALL
C01465		BACC18Z3R CB-PERF SOL-L ENG-CHAN A	233T5111 81205	1	73-21-20 P011-02/ /L003	ALL
C01466		BACC18Z3R CB-PERF SOL-L ENG-CHAN B	233T5111 81205	1	73-21-20 P011-02/ /L004	ALL
C01467		BACC18Z3R CB-PERF SOL-R ENG-CHAN A	233T5111 81205	1	73-21-20 P011-05/ /L030	ALL
C01468		BACC18Z3R CB-PERF SOL-R ENG-CHAN B	233T5111 81205	1	73-21-20 P011-05/ /L031	ALL
C01474		BACC18Z1R CB-PIMU,L ENG	284T0189 81205	1	77-35-11 P033-00/ /D004	ALL
C01475		BACC18Z1R CB-PIMU,R ENG	284T0189 81205	1	77-35-11 P033-00/ /D005	ALL
C01478		BACC18Z1R CB-T/R IND ALT,R ENG	233T5111 81205	1	78-36-21 P011-04/ /D032	ALL
C01479	9	BACC18Z5R CB-T/R CONT ALT,R ENG (SB 78-0051FAA)	233T5100 81205	1	78-34-21 P011-04/ /D033	050-099, 150-156, 162-166, 275-276
C01479		BACC18Z2R CB-T/R CONT ALT,R ENG	233T5100 81205	1	78-34-21 P011-04/ /D033	157, 167-199, 277- 299
C01480		BACC18Z1R CB-T/R IND,LEFT ENG	233T5111 81205	1	78-36-11 P011-01/ /D013	ALL
C01481		BACC18Z1R CB-T/R IND,RIGHT ENG	233T5111 81205	1	78-36-21 P011-05/ /L032	ALL
C01482	9	BACC18Z5R CB-T/R CONT,L ENG (SB 78-0051)	233T5100 81205	1	78-34-11 P011-01/ /D014	050-099, 150-156, 162-166, 275-276

EQUIPMENT LIST

D280T132

Section C01400

Page 3

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01482		BACC18Z2R CB-T/R CONT,L ENG	233T5100 81205	1	78-34-11 P011-01/ /D014	157, 167-199, 277- 299
C01483	9	BACC18Z5R CB-T/R CONT,R ENG (SB 78-0051FAA)	233T5100 81205	1	78-34-21 P011-05/ /L033	050-099, 150-156, 162-166, 275-276
C01483		BACC18Z2R CB-T/R CONT,R ENG	233T5100 81205	1	78-34-21 P011-05/ /L033	157, 167-199, 277- 299
C01486		BACC18Z2R CB-DC BUS PWR SENSE RIGHT	233T5111 81205	1	78-34-21 P011-05/ /M030	ALL
C01493		BACC18Z2R CB-T/L INTERLOCK,L ENG	233T5111 81205	1	78-36-11 P011-04/ /C035	ALL
C01494		BACC18Z2R CB-T/L INTERLOCK,R ENG ALTN	233T5111 81205	1	78-36-21 P011-04/ /C036	ALL
C01495		BACC18Z2R CB-T/L INTERLOCK,R ENG	233T5111 81205	1	78-36-21 P011-05/ /L029	ALL
C01498		BACC18Z1R CB-OIL PRESS. EICAS REF,LEFT ENGINE	233T5111 81205	1	79-32-11 P011-02/ /L009	ALL
C01499		BACC18Z1R CB-OIL PRESS. EICAS REF,RIGHT ENGINE	233T5111 81205	1	79-32-11 P011-05/ /L036	ALL

EQUIPMENT LIST

D280T132

Section C01400

Page 4 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01510		BACC18Z02R CB-ENGINE START,LEFT CONT	233T5111 81205	1	80-11-11 P011-04/ /D019	ALL
C01511		BACC18Z02R CB-ENGINE START,RIGHT CONT	233T5111 81205	1	80-11-21 P011-04/ /D020	ALL
C01512		BACC18Z1R CB-APU ENGINE START/ECS DISCRETE	233T5111 81205	1	80-11-11 P011-04/ /B036	ALL
C01521		BACC18Z2R CB-FSEU CONT 2	233T5111 81205	1	27-51-61 P011-02/ /G016	ALL
C01522		BACC18Z2R CB-R FLAP POS IND	233T5111 81205	1	27-58-11 P011-02/ /J016	ALL
C01523		BACC18Z2R CB-FLAP/STAB POS SENSING L	233T5111 81205	1	27-58-21 P011-02/ /J017	ALL
C01524		BACC18Z2R CB-FSEU SENSOR 2	233T5111 81205	1	27-51-61 P011-02/ /G015	ALL
C01525		BACC18Z1R CB-FLAP/STAB POS SENSING C	233T5111 81205	1	27-58-21 P011-01/ /C014	ALL
C01526		BACC18Z2R CB-FLAP/STAB POS SENSING R	233T5111 81205	1	27-58-21 P011-05/ /J026	ALL
C01528		BACC18Z5R CB-SHUT OFF VALVE,STAB TRIM,LEFT	233T5111 81205	1	27-41-11 P011-01/ /C012	ALL
C01529		BACC18Z5R CB-SHUT OFF VALVE,STAB TRIM,C	233T5111 81205	1	27-41-21 P011-01/ /C013	ALL
C01531		BACC18Z2R CB-FLT CONT ELEK 1R-DC	233T5111 81205	1	27-09-11 P011-02/ /G018	ALL
C01532		BACC18Z2R CB-FLT CONT ELEK 2R-DC	233T5111 81205	1	27-09-11 P011-05/ /G027	ALL
C01533		BACC18Z2R CB-FLT CONT ELEK 2L-DC	233T5111 81205	1	27-09-11 P011-01/ /C009	ALL
C01534		BACC18Z2R CB-FLT CONT ELEK 1L-DC	233T5111 81205	1	27-09-11 P011-01/ /C007	ALL
C01535		BACC18Z2R CB-FLT CONT ELEK 2R-AC	233T5111 81205	1	27-09-11 P011-05/ /G026	ALL
C01536		BACC18Z2R CB-FLT CONT ELEK 1R-AC	233T5111 81205	1	27-09-11 P011-02/ /G017	ALL

EQUIPMENT LIST

D280T132

Section C01500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01537		BACC18Z2R CB-FLT CONT ELEK 2L-AC	233T5111 81205	1	27-09-11 P011-01/ /C008	ALL
C01538		BACC18Z2R CB-FLT CONT ELEK 1L-AC	233T5111 81205	1	27-09-11 P011-01/ /C006	ALL
C01548		BACC18Z5R CB-STICK SHAKER,RIGHT	233T5111 81205	1	27-32-21 P011-05/ /J022	ALL
C01550		BACC18Z5R CB-VIDEO CONT CTR-AC	284T0188 81205	1	23-32-11 P037-00/ /K006	275-299
C01551		BACC18AD7 CB-VIDEO 1 AC	284T0188 81205	1	23-32-31 P037-00/ /L001	275-299
C01552		BACC18AD7 CB-VIDEO 2 AC	284T0188 81205	1	23-32-41 P037-00/ /L002	275-299
C01553		BACC18AD7 CB-VIDEO 3 AC	284T0188 81205	1	23-32-51 P037-00/ /L003	275-299
C01554		BACC18AD7 CB-VIDEO 4 AC	284T0188 81205	1	23-32-61 P037-00/ /L004	275-299
C01560		BACC18Z2R CB-YAW DAMPER,LEFT	233T5111 81205	1	22-21-11 P011-01/ /A018	ALL
C01561		BACC18Z2R CB-YAW DAMPER,RIGHT	233T5111 81205	1	22-21-21 P011-04/ /F034	ALL
C01575	9	BACC18Z2R CB-GR POS AIR/GND SYS 2 ALT(SB78-051FAA)	233T5100 81205	1	32-09-12 P011-04/ /C029	050-099, 150-156, 162-166, 275-276
C01575		BACC18Z2R CB-GR POS AIR/GND SYS 2 ALT (RR41033-23)	233T5100 81205	1	32-09-12 P011-04/ /C029	157
C01575		BACC18Z2R CB-GR POS AIR/GND SYS 2 ALT (RR41033-24)	233T5100 81205	1	32-09-12 P011-04/ /C029	167-199
C01575		BACC18Z2R CB-GR POS AIR/GND SYS 2 ALT (RR41034-20)	233T5100 81205	1	32-09-12 P011-04/ /C029	277-278
C01575		BACC18Z2R CB-GR POS AIR/GND SYS 2 ALT (RR41034-21)	233T5100 81205	1	32-09-12 P011-04/ /C029	280-299
C01576	9	BACC18Z7R CB-T/R SSL CONTROL, L ENG (SB 78-0062)	233T5100 81205	1	78-34-11 P011-01/ /D018	ALL
C01577	9	BACC18Z7R CB-T/R SSL CONTROL, R ENG (SB 78-0062)	233T5100 81205	1	78-34-21 P011-04/ /D021	ALL

EQUIPMENT LIST

D280T132

Section C01500

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C01722	9	MS3320-2-5 CB-TERRAIN DISPLAY (MTO-340961)	CUSTOMER CUST	1	34-46-11 P011-01/ /E007	150, 152-199, 275- 299

EQUIPMENT LIST

D280T132

Section C01700
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04019		BACC18Z2R CB-ZONE TEMP IND	233T5111 81205	1	21-65-11 P011-03/ /R016	ALL
C04025	9	BACC18Z2R CB-FWD CARGO DUCT OVHT/INOP (TO 210210)	233T5216 81205	1	21-61-81 P011-06/ /N022	150
C04025		BACC18Z2R CB-FWD CARGO DUCT OVHT/INOP	233T5111 81205	1	21-61-81 P011-06/ /N022	050-099, 275-299
C04025		BACC18Z2R CB-FWD CARGO DUCT OVHT/INOP (INOP)	233T5216 81205	1	21-61-81 P011-06/ /N022	151-199
C04026		BACC18Z2R CB-AUX FWD ZONE DUCT OVHT	233T5111 81205	1	21-61-61 P011-02/ /H005	ALL
C04027		BACC18Z2R CB-AUX MID ZONE DUCT OVHT	233T5111 81205	1	21-61-71 P011-02/ /H006	ALL
C04028		BACC18Z2R CB-MID ZONE DUCT OVHT/INOP	233T5111 81205	1	21-61-41 P011-06/ /R026	ALL
C04029		BACC18Z2R CB-F/D ZONE DUCT OVHT/INOP	233T5111 81205	1	21-61-11 P011-06/ /R024	ALL
C04030		BACC18Z2R CB-FWD ZONE DUCT OVHT/INOP	233T5111 81205	1	21-61-21 P011-06/ /R025	ALL
C04031		BACC18Z2R CB-AFT ZONE DUCT OVHT/INOP	233T5111 81205	1	21-61-31 P011-06/ /R027	ALL
C04036		BACC18Z2R CB-L PACK PWR STBY	233T5111 81205	1	21-51-13 P011-06/ /N024	ALL
C04037		BACC18Z2R CB-L PACK CONT STBY	233T5111 81205	1	21-51-13 P011-06/ /N025	ALL
C04038		BACC18Z2R CB-R PACK PWR STBY	233T5111 81205	1	21-51-23 P011-03/ /N015	ALL
C04039		BACC18Z2R CB-R PACK CONT STBY	233T5111 81205	1	21-51-23 P011-03/ /N016	ALL
C04078		BACC18Z2R CB-EICAS,L CMPTR	233T5111 81205	1	31-41-11 P011-02/ /J002	ALL
C04079		BACC18Z2R CB-EICAS,R CMPTR	233T5111 81205	1	31-41-11 P011-05/ /J029	ALL
C04081		BACC18Z2R CB-EICAS UPPER DSPL	233T5111 81205	1	31-41-11 P011-02/ /J003	ALL

EQUIPMENT LIST

D280T132

Section C04000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04082		BACC18Z2R CB-EICAS LOWER DSPL	233T5111 81205	1	31-41-11 P011-05/ /J030	ALL
C04094		BACC18Z2R CB-EICAS DISPLAY SELECT	233T5111 81205	1	31-41-11 P011-05/ /J032	ALL
C04097		BACC18Z2R CB-BAT. CUR. MON PWR	284T0997 81205	1	24-34-11 P006-01/ /A004	ALL
C04099		BACC18Z2R CB-AILERON POSITION,L	233T5111 81205	1	27-18-11 P011-02/ /K014	ALL

EQUIPMENT LIST

D280T132

Section C04000
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04100		BACC18Z2R CB-AILERON POSITION,R	233T5111 81205	1	27-18-11 P011-05/ /K023	ALL
C04101		BACC18Z2R CB-ELEVATOR POSITION,L	233T5111 81205	1	27-38-11 P011-02/ /K013	ALL
C04102		BACC18Z2R CB-ELEVATOR POSITION,R	233T5111 81205	1	27-38-11 P011-05/ /K022	ALL
C04126		BACC18Z2R CB-ENG START LOAD SHED RESET	233T5111 81205	1	24-51-71 P011-03/ /T002	ALL
C04153		BACC18Z2R CB-ENGINE STBY IND	233T5111 81205	1	73-21-14 P011-04/ /D028	ALL
C04180	9	BACC18Z2R CB-FWD CARGO TEMP CONT (TO 210210)	233T5216 81205	1	21-61-81 P011-06/ /N021	150
C04180		BACC18Z2R CB-FWD CARGO TEMP CONT	233T5111 81205	1	21-61-81 P011-06/ /N021	050-099, 275-299
C04180		BACC18Z2R CB-FWD CARGO TEMP CONT (INOP)	233T5216 81205	1	21-61-81 P011-06/ /N021	151-199
C04181		BACC18Z2R CB-AUX FWD ZONE TEMP CONT	233T5111 81205	1	21-61-61 P011-02/ /H002	ALL
C04182		BACC18Z2R CB-AUX MID ZONE TEMP CONT	233T5111 81205	1	21-61-71 P011-02/ /H003	ALL
C04183		BACC18Z2R CB-MID ZONE TEMP CONT VALVE CLOSE	233T5111 81205	1	21-61-41 P011-06/ /P026	ALL
C04184		BACC18Z2R CB-F/D ZONE TEMP CONT MAN.	233T5111 81205	1	21-61-11 P011-06/ /P024	ALL
C04185		BACC18Z2R CB-FWD ZONE TEMP CONT VALVE CLOSE	233T5111 81205	1	21-61-21 P011-06/ /P025	ALL
C04186		BACC18Z2R CB-AFT ZONE TEMP CONT VALVE CLOSE	233T5111 81205	1	21-61-31 P011-06/ /P027	ALL
C04189		BACC18Z2R CB-E1CAS,DISPLAY SWITCHING	233T5111 81205	1	31-41-17 P011-05/ /J031	ALL

EQUIPMENT LIST

D280T132

Section C04100

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04205		BACC18Z2R CB-CABIN ALTIMETER	233T5111 81205	1	21-33-21 P011-01/ /B013	ALL
C04206		BACC18Z2R CB-CABIN DIFFERENTIAL PRESSURE IND	233T5111 81205	1	21-33-21 P011-01/ /B012	ALL
C04217		BACC18Z2R CB-BAT VM/STBY BUS OFF LT	284T0997 81205	1	24-33-11 P006-01/ /G006	ALL
C04221		BACC18Z2R CB-AIR SUPPLY DUCT PRESSURE IND PWR	233T5111 81205	1	36-21-11 P011-03/ /S017	ALL
C04226		BACC18Z5R CB-F/O INSTR TRANSFER ALTN BUS PH A	233T5111 81205	1	24-51-43 P011-03/ /S007	ALL
C04227		BACC18Z5R CB-CAPT INSTR TRANSFER ALTN BUS PH A	233T5111 81205	1	24-51-42 P011-06/ /S034	ALL
C04228		BACC18Z5R CB-F/O INSTR TRANSFER ALTN BUS PH B	233T5111 81205	1	24-51-43 P011-03/ /S008	ALL
C04229		BACC18Z5R CB-CAPT INSTR TRANSFER ALTN BUS PH B	233T5111 81205	1	24-51-42 P011-06/ /S035	ALL
C04230		BACC18Z5R CB-F/O INSTR TRANSFER ALTN BUS PH C	233T5111 81205	1	24-51-43 P011-03/ /S009	ALL
C04231		BACC18Z5R CB-CAPT INSTR TRANSFER ALTN BUS PH C	233T5111 81205	1	24-51-42 P011-06/ /S036	ALL
C04248		BACC18Z7R CB-LDG GR ALTN EXT MOTOR	284T0997 81205	1	32-35-11 P006-01/ /F006	ALL
C04264		BACC18Z5R CB-CAPT PRIM INSTR BUS PH A	284T0997 81205	1	24-51-42 P006-03/ /J014	ALL
C04265		BACC18Z5R CB-CAPT PRIM INSTR BUS PH B	284T0997 81205	1	24-51-42 P006-03/ /J015	ALL
C04266		BACC18Z5R CB-CAPT PRIM INSTR BUS PH C	284T0997 81205	1	24-51-42 P006-03/ /J016	ALL
C04267		BACC18Z5R CB-F/O PRIM INSTR BUS PH A	284T0997 81205	1	24-51-43 P006-04/ /L020	ALL
C04268		BACC18Z5R CB-F/O PRIM INSTR BUS PH B	284T0997 81205	1	24-51-43 P006-04/ /L021	ALL
C04269		BACC18Z5R CB-F/O PRIM INSTR BUS PH C	284T0997 81205	1	24-51-43 P006-04/ /L022	ALL

EQUIPMENT LIST

D280T132

Section C04200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04280		BACC18Z2R CB-GLARESHIELD FLOODLIGHT	233T5111 81205	1	33-11-13 P011-03/ /P007	ALL

EQUIPMENT LIST

D280T132

Section C04200

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C04423	9	BACC18Z02R CB-ATC ANTENNA SW (SB 34-0082)	233T5100 81205	1	34-53-13 P011-01/ /F011	150-154
C04423		BACC18Z02R CB-ATC ANTENNA SW	233T5111 81205	1	34-53-13 P011-01/ /F011	050-099, 277-278
C04423		BACC18Z02R CB-ATC ANTENNA SW	233T5111 81205	1	34-53-11 P011-01/ /F011	155-199, 275-276, 280-299

EQUIPMENT LIST

D280T132

Section C04400
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C07001	9	MS3320-2-5 CB-2.5AMP SATCOM DC	233T5100 76374	1	23-25-20 P011-020/ /H009	150, 153-199

EQUIPMENT LIST

D280T132

Section C07000

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
C09000	9	2TC14-1 CB RADVR (MTO-230718)	CUSTOMER 82647	1	23-32-21 P37/ /D005	150, 152-199
C09001	9	2TC14-1 CB RADVR (MTO-230718)	CUSTOMER CUST	1	23-32-21 P037-00/ /D005	150, 152-157, 164-199
C09001	9	MS3320-2-5 CB-2.5 AMP SATCOM DC (MTO-238591/2/3)	233T5100 76374	1	23-25-20 P011-02/ /H009	162-163
C09001	9	TBD CB-FWD ZONAL DRYER (CI#6421)	PR210298 CUST	1	21-73-11 0433/300/L019	275-299
C09002	9	2TC14-1 CB RADVR (MTO-230718)	CUSTOMER 82647	1	23-32-21 P37/ /D005	150, 152-199
C09002	9	TBD CB-MID ZONAL DRYER (CI#6421)	PR210298 CUST	1	21-73-11 0433/300/L019	275-299
C09003	9	TBD CB-AFT ZONAL DRYER (CI#6421)	PR210298 CUST	1	21-73-11 0433/300/L019	275-299
C09004	9	TBD CB-FWD ZONAL DRYER (CI#6421)	PR210298 CUST	1	21-73-11 433/300/L019	275-299
C09005	9	TBD CB-MID ZONAL DRYER (CI#6421)	PR210298 CUST	1	21-73-11 0433/300/L019	275-299
C09006	9	TBD CB-AFT ZONAL DRYER (CI#6421)	PR210298 CUST	1	21-73-11 433/300/L019	275-299
C09007	9	MS3320-2-5 CB-TERR DISPL (MTO-340961)	CUSTOMER TBD	1	34-46-13 P011-01/ /	150, 152-199, 275-299
█ C09033	9	BACC18AC10 TRU-PASSENGER SEAT 28V DC (MTO 240500)	CUSTOMER 81205	1	25-25-23 P036-00/ /	150, 153-199
█ C09034	9	CUSTOMER CB-PASSENGER SEAT PWR (MTO 240500)	CUSTOMER CUST	1	25-25-23 SHELF/E02/06	150, 153-199
█ C09035	9	CUSTOMER CB-PASSENGER SEAT PWR (MTO 240500)	CUSTOMER CUST	1	25-25-23 SHELF/E02/06	150, 153-199
█ C09036	9	CUSTOMER CB-PASSENGER SEAT PWR (MTO 240500)	CUSTOMER CUST	1	25-25-23 SHELF/E02/06	150, 153-199
█ C09037	9	CUSTOMER CB-PASSENGER SEAT PWR (MTO 240500)	CUSTOMER CUST	1	25-25-24 SHELF/E02/06	150, 153-199
█ C09038	9	CUSTOMER CB-PASSENGER SEAT PWR (MTO 240500)	CUSTOMER CUST	1	25-25-24 SHELF/E02/06	150, 153-199

EQUIPMENT LIST

D280T132

Section C09000

Page 1

Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
■ C09039	9	CUSTOMER CB-PASSENGER SEAT PWR (MTO 240500)	CUSTOMER CUST	1	25-25-24 SHELF/E02/06	150, 153-199
C09040	9	CUSTOMER CB-PASSENGER TELEPHONE-AC (MTO_230695)	CUSTOMER CUST	1	23-19-11 P036-00/ /	150
C09040	9	CUSTOMER CB-PASSENGER TELEPHONE-AC (MTO_230596)	CUSTOMER CUST	1	23-19-11 P036-00/ /	152-199
C09041	9	CUSTOMER CB-PASSENGER TELEPHONE-DC (MTO-230695)	CUSTOMER CUST	1	23-19-11 P006-02/ /	150
C09041	9	CUSTOMER CB-PASSENGER TELEPHONE-DC (MTO-230596)	CUSTOMER CUST	1	23-19-11 P006-02/ /	152-199
■ C09042	9	CUSTOMER CB-EMPOWER SYSTEM (EAD 89-0704-00)	CUSTOMER CUST	1	25-25-23 P036-00/ /	150, 153, 157, 165-199

EQUIPMENT LIST

D280T132

Section C09000

Page 2 End

Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00001		KN-59-330-M06 PLUG-COAX,HF L COUPLER,ANT.	91836	1	23-11-11 F 282/ /LE	050-099, 150-154, 162-164, 275-276
D00001		KN-59-220 PLUG-COAX,HF L COUPLER,ANT.	91836	1	23-11-11 F 282/ /LE	155-157, 165-199, 277-299
D00002		5262I OUTLET-SVCE	417T5009 74545	1	25-29-11 0290/210/L090	ALL
D00003		KN-59-330-M06 PLUG-COAX,HF R COUPLER,ANT.	91836	1	23-11-21 F 271/ /LE	050-099, 150-154, 162-164, 275
D00003		KN-59-220 PLUG-COAX,HF R COUPLER,ANT.	91836	1	23-11-21 F 271/ /LE	155-157, 165-199, 276-299
D00004		5262I OUTLET-SVCE	417T5009 74545	1	25-29-11 1537/213/L090	ALL
D00005		KD-59-186-M06 PLUG-COAX,VHF-L ANT.	91836	1	23-12-11 0667/319/0000	050-099
D00005		KD-59-186-M06 PLUG-COAX,VHF-L ANT.	91836	1	23-12-11 0654+33/319/0000	150-199, 275-299
D00006		5258 OUTLET-SVCE	284T0721 74545	1	25-29-11 0300/170/R003	ALL
D00007		KD-59-164 PLUG-COAX	91836	1	23-12-21 0513/102/0000	ALL
D00007 V		289T0126-11701 I.D. TAPE TEXT AS BELOW	81205	1	23-12-21 / /	275-276
D00008		5258 OUTLET-SVCE	284T0997 74545	1	25-29-11 P006-02/ /	ALL
D00009		KD-59-186-M06 PLUG-COAX,VHF-C ANT.	91836	1	23-12-31 1320/102/0000	050-099
D00009		KD-59-186-M06 PLUG-COAX,VHF-C ANT.	91836	1	23-12-31 1197+99/102/0000	150-199, 275-299
D00010		7487 OUTLET-SVCE	284T0997 74545	1	25-29-11 P006-02/ /	ALL
D00011		KD-59-202-M06 PLUG-COAX,D LOC,ILS L	91836	1	34-31-11 0126/179/L005	ALL
D00013		KD-59-202-M06 PLUG-COAX,D LOC,ILS C+R	91836	1	34-31-11 0126/214/L007	ALL

EQUIPMENT LIST

D280T132

Section D00000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00015		KD-59-202-M06 PLUG-COAX,D LOC,ILS C+R	91836	1	34-31-31 0126/214/0000	ALL
D00017		KD-59-202-M06 PLUG-COAX,D G/S,ILS L	91836	1	34-31-31 0126/167/0000	ALL
D00019		KD-59-202-M06 PLUG-COAX,D G/S,ILS C+R	91836	1	34-31-31 0126/171/0000	ALL
D00020		52621 OUTLET-SVCE	417T5009 74545	1	25-29-11 1090/210/L090	050-099
D00020		52621 OUTLET-SVCE	417T5009 74545	1	25-29-11 0992/210/L090	150-199
D00020		52621 OUTLET-SVCE	417T5009 74545	1	25-29-11 1005/210/L090	275-299
D00021		KD-59-202-M06 PLUG-COAX,DUAL G/S IRS C+R	91836	1	34-31-31 0126/171/L005	ALL
D00022		BACC63BP18A14SNL PLUG-STRUT	81205	1	36-11-51 NL210/150/L005	ALL
D00022 T		BACC10KE18 CLAMP-	81205	1	36-11-51 / /	ALL
D00023		KA-59-185 PLUG-COAX,ANT.,RAD ALTM XMTR L	91836	1	34-33-11 0577/107/L007	ALL
D00025		KA-59-185 PLUG-COAX,ANT.,RAD ALTM RCVR L	91836	1	34-33-11 0621/107/L007	ALL
D00027		KA-59-185 PLUG-COAX,ANT.,RAD ALTM XMTR R	91836	1	34-33-21 0577/107/R007	ALL
D00029		KA-59-185 PLUG-COAX,ANT.,RAD ALTM RCVR R	91836	1	34-33-21 0621/107/R007	ALL
D00030		BACC63BP16A10SNL PLUG-STRUT	13556	1	36-23-11 NR210/150/R005	ALL
D00030 T		BACC10KD16 CLAMP-	81205	1	36-23-11 / /	ALL
D00031		KA-59-185 PLUG-COAX,ANT.,RAD ALTM XMTR C	91836	1	34-33-31 0577/107/0000	ALL
D00033		KA-59-185 PLUG-COAX,ANT.,RAD ALTM RCVR C	91836	1	34-33-31 0621/107/0000	ALL

EQUIPMENT LIST

D280T132

Section D00000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00034		BACC63BP12A3SNL PLUG-	81205	1	29-31-11 L0429/14/ET	ALL
D00034 T		BACC10KD12 CLAMP-	81205	1	29-31-11 / /	ALL
D00035		KD-19-105-M06 RCPT-COAX,VOR L	91836	1	34-51-11 FSS 430/633/FS	050-099, 150-154, 162-164, 275-276
D00035		KD-19-66 RCPT-COAX,VOR L	91836	1	34-51-11 FSS 430/633/FS	155-157, 165-199, 277-299
D00036		BACC63BP12R3S10L PLUG-	81205	1	29-32-11 NL264/170/	ALL
D00036 T		BACC10KD12 CLAMP-	81205	1	29-32-11 / /	ALL
D00037		KD-19-105-M06 RCPT-COAX,VOR R	91836	1	34-51-21 FSS 430/630/FS	050-099, 150-154, 162-164, 275-276
D00037		KD-19-66 RCPT-COAX,VOR R	91836	1	34-51-21 FSS 430/630/FS	155-157, 165-199, 277-299
D00038		BACC63BP14R7SNL PLUG-	81205	1	29-33-11 NL250/150/	ALL
D00038 T		BACC10KD14 CLAMP-	81205	1	29-33-11 / /	ALL
D00041	1	796-19-9 PLUG-COAX,ATC R,BOTTOM	91836	1	34-53-21 0448/108/0000	050-099, 150-152
D00041	1	796-19-9 PLUG-COAX,ATC R,BOTTOM	91836	1	34-53-13 0448/108/0000	153-199, 275-299
D00041	2	KD-59-193-M06 PLUG-COAX,ATC R,BOTTOM	91836	1	34-53-21 0448/108/0000	050-099, 150-152
D00041	2	KD-59-193-M06 PLUG-COAX,ATC R,BOTTOM	91836	1	34-53-13 0448/108/0000	153-199, 275-299
D00045	1	795-30-9 PLUG-COAX,ATC R, TOP	91836	1	34-53-21 0448/320/0000	050-099
D00045	1	795-30-9 PLUG-COAX,ATC R, TOP	91836	1	34-53-13 0448/320/0000	150-199, 275-299
D00045	2	KD-59-180-M06 PLUG-COAX,ATC R, TOP	91836	1	34-53-21 0448/320/0000	050-099

EQUIPMENT LIST

D280T132

Section D00000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00045	2	KD-59-180-M06 PLUG-COAX,ATC R,TOP	91836	1	34-53-13 0448/320/0000	150-199, 275-299
D00047		KD-59-180-M06 PLUG-COAX,ANT.,DME L	91836	1	34-55-11 0564/114/R003	050-099
D00047		KD-59-180-M06 PLUG-COAX,ANT.,DME L	91836	1	34-55-11 0564/107/R003	150-199, 275-299
D00048		BACC63BP12R3S10L PLUG-	81205	1	29-32-11 NR264/154/	ALL
D00048 T		BACC10KD12 CLAMP-	81205	1	29-32-11 / /	ALL
D00049		KD-59-180-M06 PLUG-COAX,ANT.,DME R	91836	1	34-55-21 0665/106/0000	050-099
D00049		KD-59-180-M06 PLUG-COAX,ANT.,DME R	91836	1	34-55-21 0654+11/106/0000	150-199, 275-299
D00051		C0909A20N16SN-494 PLUG-ANT.,ADF L	13556	1	34-57-11 1115/319/0000	ALL
D00052		BACC63BP12R3S6L PLUG-	81205	1	29-11-12 NL300/150/	ALL
D00052 T		BACC10KD12 CLAMP-	81205	1	29-11-12 / /	ALL
D00054		BACC63BP12R3S8L PLUG-	81205	1	29-11-12 NL255/170/	ALL
D00054 T		BACC10KD12 CLAMP-	81205	1	29-11-12 / /	ALL
D00056		BACC63BP12R3S8L PLUG-	81205	1	29-11-12 NL245/155/	ALL
D00056 T		BACC10KD12 CLAMP-	81205	1	29-11-12 / /	ALL
D00058		BACC63BP12A3SNL PLUG-	81205	1	29-31-11 R0430/14/TE	ALL
D00058 T		BACC10KD12 CLAMP-	81205	1	29-31-11 / /	ALL
D00060		BACC63BP14R7SNL PLUG-	81205	1	29-33-11 NR250/140/	ALL

EQUIPMENT LIST

D280T132

Section D00000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00060 T		BACC10KD14 CLAMP-	81205	1	29-33-11 / /	ALL
D00064		BACC63BP18A14SNL PLUG-STRUT	81205	1	36-11-52 NL210/150/L005	ALL
D00064 T		BACC10KE18 CLAMP-	81205	1	36-11-52 / /	ALL
D00068		BACC63BP16A10SNL PLUG-STRUT	13556	1	36-23-21 NR210/150/L5 D	ALL
D00068 T		BACC10KD16 CLAMP-	81205	1	36-23-21 / /	ALL
D00072		BACC63BP12R3S6L PLUG-	81205	1	29-11-22 NR295/170/	ALL
D00072 T		BACC10KD12 CLAMP-	81205	1	29-11-22 / /	ALL
D00074		BACC63BP12R3S8L PLUG-	81205	1	29-11-22 NR250/150/	ALL
D00074 T		BACC10KD12 CLAMP-	81205	1	29-11-22 / /	ALL
D00076		BACC63BP12R3S8L PLUG-	81205	1	29-11-22 NR255/150/	ALL
D00076 T		BACC10KD12 CLAMP-	81205	1	29-11-22 / /	ALL
D00082		BACS16X3A RELAY SOCKET-	81205	1	33-22-42 P025-00/ /	ALL
D00083		KD-59-161 PLUG-COAX,ANT.,MKR BCN	91836	1	34-32-11 0680/102/0	050-099
D00083		KD-59-161 PLUG-COAX,ANT.,MKR BCN	91836	1	34-32-11 0654+33/102/0000	150-199, 275-299
D00084		BACS16X3A RELAY SOCKET-	81205	1	33-22-42 P025-00/ /	ALL
D00085		KPSE06F16-26S PLUG-	71468	1	23-11-11 F 282/ /LE	ALL
D00086		BACS16X3A RELAY SOCKET-	81205	1	33-22-42 P025-00/ /	275-299

EQUIPMENT LIST

D280T132

Section D00000

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00087		KPSE06F16-26S PLUG-	71468	1	23-11-21 F 271/ /LE	ALL
D00090		BACS16W3 RELAY SOCKET-	81205	1	33-27-11 P025-00/ /	050-099, 150-199
D00090		BACS16X3A RELAY SOCKET-	81205	1	33-27-11 P025-00/ /	275-299
D00092		BACS16X3A RELAY SOCKET-	81205	1	33-21-11 P019-00/ /	ALL
D00094		BACS16X3A RELAY SOCKET-	81205	1	33-21-11 P019-00/ /	ALL
D00096		BACS16X3A RELAY SOCKET-	81205	1	33-21-11 P019-00/ /	275-299

EQUIPMENT LIST

D280T132

Section D00000

Page 6 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00100		BACS16X3A RELAY SOCKET-	81205	1	33-21-11 P019-00/ /	275-299
D00101		BACC45FT18A31S PLUG-	81205	1	34-13-11 P001-01/ /	ALL
D00103		BACC45FT16A24S PLUG-	81205	1	31-25-11 P001-03/ /	ALL
D00104		BACS16W3 RELAY SOCKET-	81205	1	33-21-31 P019-00/ /	ALL
D00106		BACS16W3 RELAY SOCKET-	81205	1	33-21-31 P019-00/ /	ALL
D00107		DPXBMB-67-33S-0001 PLUG-P1-2	71468	1	34-22-14 P001-02/ /	ALL
D00107 T		233T2313-3 CONNECTOR PLATE ASSY	81205	1	34-22-14 / /	ALL
D00108		BACS16X2A RELAY SOCKET-P19	81205	1	33-22-11 P019-00/ /	050-099
D00108		BACS16X2A RELAY SOCKET	81205	1	33-22-11 P019-00/ /	150-199, 275-299
D00109		DPXBMB-67-33S-0002 PLUG-P1-2	71468	1	34-22-15 P001-02/ /	ALL
D00109 T		233T2313-1 CONNECTOR PLATE ASSY	81205	1	34-22-15 / /	ALL
D00111		BACC45FT20A41S PLUG-	81205	1	34-13-11 P001-03/ /	ALL
D00113	9	BACC45FT20A41S PLUG- (MTO 340652)	81205	1	34-22-82 P001-03/ /	050-099, 150-152, 155-199, 275-299
D00113		CUSTOMER PLUG-	81205	1	34-22-82 P001-03/ /	050-099, 153-154
D00117		BACC63BN12-12SN PLUG-	81205	1	34-12-11 0192/202/L075	ALL
D00117 T		BACC10GH12 CLAMP-	81205	1	34-12-11 / /	ALL
D00121		BACC63BN12-12S6 PLUG-	81205	1	34-12-11 0192/202/L075	ALL

EQUIPMENT LIST

D280T132

Section D00100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00121 T		BACC10GH12 CLAMP-	81205	1	34-12-11 / /	ALL
D00123		BACC63BN12-12SN PLUG-	81205	1	34-12-21 0192/202/R075	ALL
D00123 T		BACC10GH12 CLAMP-	81205	1	34-12-21 / /	ALL
D00127		BACC63BN12-12S6 PLUG-	81205	1	34-12-21 0192/202/R075	ALL
D00127 T		BACC10GH12 CLAMP-	81205	1	34-12-21 / /	ALL
D00130		BACS16W3 RELAY SOCKET-	81205	1	33-21-12 P025-00/ /	ALL
D00132		BACS16W3 RELAY SOCKET-	81205	1	33-21-12 P025-00/ /	ALL
D00133		BACC45FN12-12S RCPT-	81205	1	22-11-11 AE0106/ /	050-099
D00133		BACC45FN12-12S RCPT-	81205	1	31-31-25 AE0106/ /	150-199
D00134		BACS16AH1 RELAY SOCKET-	81205	1	35-21-11 P019-00/ /	ALL
D00135		BACC45FN12-12S RCPT-	81205	1	22-11-11 AE0105/ /	050-099
D00135		BACC45FN12-12S RCPT-	81205	1	31-31-25 AE0105/ /	150-199
D00136		BACS16W1 RELAY SOCKET-	81205	1	35-21-11 P019-00/ /	ALL
D00137		BACC45FN12-12S RCPT-	81205	1	22-11-11 AE0217/ /	050-099
D00137		BACC45FN12-12S RCPT-	81205	1	31-31-25 AE0217/ /	150-199
D00138		BACS16W1 RELAY SOCKET-	81205	1	35-21-11 P019-00/ /	ALL
D00140		BACS16AH1 RELAY SOCKET-	81205	1	35-21-11 P019-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00142		BACS16W1 RELAY SOCKET-	81205	1	35-21-11 P019-00/ /	ALL
D00144		BACS16W1 RELAY SOCKET-	81205	1	35-21-11 P019-00/ /	ALL
D00146		BACC45FN8-2S RCPT-	81205	1	35-21-12 0429/270/L075	050-099
D00146		BACC45FN8-2S RCPT-	81205	1	35-21-12 0427/270/L075	150-199, 275-278
D00146		BACC45FN8-2S RCPT-	81205	1	35-21-12 0428/270/L073	280-299
D00148		BACC45FN8-2S RCPT-	81205	1	35-21-12 0493/270/L075	050-099, 150-199, 275-278
D00148		BACC45FN8-2S RCPT-	81205	1	35-21-12 0494/270/L073	280-299
D00150		BACC45FN8-2S RCPT-	81205	1	35-21-12 0522/270/L075	050-099, 150-199, 275-278
D00150		BACC45FN8-2S RCPT-	81205	1	35-21-12 0523/270/L073	280-299
D00152		BACC45FN8-2S RCPT-	81205	1	35-21-12 0551/270/L075	050-099, 150-199, 275-278
D00152		BACC45FN8-2S RCPT-	81205	1	35-21-12 0552/270/L073	280-299
D00154		BACC45FN8-2S RCPT-	81205	1	35-21-12 0581/270/L075	050-099, 150-199, 275-278
D00154		BACC45FN8-2S RCPT-	81205	1	35-21-12 0582/270/L073	280-299
D00155		BACC45FT14A15S6 PLUG-P8 ILS L CONT PNL	81205	1	34-31-11 P008-00/ /	ALL
D00156		BACC45FT12A12P6 PLUG-	81205	34	33-24-14 MULTI/ /	050-099
D00156		BACC45FT12A12P6 PLUG-	81205	60	33-24-14 MULTI/ /	150-157
D00156		BACC45FT12A12P6 PLUG-	81205	45	33-24-14 MULTI/ /	162-199

EQUIPMENT LIST

D280T132

Section D00100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00156		BACC45FT10A5P6 PLUG-	81205	1	33-24-14 MULTI/ /	275
D00156		BACC45FT10A5P6 PLUG-	81205	60	33-24-14 MULTI/ /	276
D00156		BACC45FT10A5P6 PLUG-	81205	57	33-24-14 MULTI/ /	277-278
D00156		BACC45FT10A5P6 PLUG-	81205	39	33-24-14 MULTI/ /	280-299
D00157		BACC45FT18A31S PLUG-P55	81205	1	34-22-18 P055-00/ /	ALL
D00158		BACC45FT12A12P6 PLUG-	81205	27	23-31-15 MULTI/ /	050-099
D00158		BACC45FT12A12P6 PLUG-	81205	45	23-31-15 MULTI/ /	150-157
D00158		BACC45FT12A12P6 PLUG-	81205	31	23-31-15 MULTI/ /	162-199
D00158		BACC45FT10A5P6 PLUG-	81205	45	23-31-15 MULTI/ /	275-276
D00158		BACC45FT10A5P6 PLUG-	81205	61	23-31-15 MULTI/ /	277-278
D00158		BACC45FT10A5P6 PLUG-	81205	38	23-31-15 MULTI/ /	280-299
D00159		BACC45FT18A31S PLUG-P55	81205	1	34-51-21 P055-00/ /	ALL
D00160		BACC45FT12A12P6 PLUG-	81205	5	23-31-15 0401/280/L005	050-099
D00160		BACC45FT12A12P6 PLUG-	81205	6	23-31-15 0401/280/L005	162-199
D00160		BACC45FT10A5P6 PLUG-	81205	9	23-31-15 0401/280/L005	280-299
D00161		BACC63BP16R10SNL PLUG-	81205	12	27-61-13 MULTI/ /	ALL
D00161 T		BACC10KD16 CLAMP-	81205	12	27-61-13 / /	ALL

EQUIPMENT LIST

D280T132

Section D00100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00162		BACC45FT12A12P6 PLUG-	81205	8	33-24-14 MULTI/270/R072	050-099, 162-199
D00162		BACC45FT12A12P6 PLUG-	81205	2	33-24-14 MULTI/270/R072	150-157
D00162		BACC45FT10A5P6 PLUG-	81205	3	33-24-14 MULTI/270/R072	275-276
D00162		BACC45FT10A5P6 PLUG-	81205	6	33-24-14 MULTI/270/R072	277-278
D00162		BACC45FT10A5P6 PLUG-	81205	9	33-24-14 MULTI/270/R072	280-299
D00168		BACC45FS10C5S PLUG-	81205	1	33-24-11 0390/305/L030	050-099
D00168		BACC45FS10C5S RCPT-	81205	1	33-24-11 0390/305/L030	150-199, 275-299
D00170		BACC45FT16A24S PLUG-	81205	1	33-51-11 1384/204/R094	ALL
D00175		BACC63BP18R31S8L PLUG-	81205	1	27-58-21 1730/180/L020	050-099
D00175		BACC63BP18A31S6L PLUG-	81205	1	27-58-21 1730/180/L020	150-199, 275-299
D00175 T		BACC10KD18 CLAMP-	81205	1	27-58-21 / /	ALL
D00179		BACC63BP22R19S6L PLUG-	81205	1	22-11-11 F 085/ /RS	ALL
D00179 T		BACC10KD22 CLAMP-	81205	1	22-11-11 / /	ALL
D00181		BACC63BP22R19SNL PLUG-	81205	1	22-11-11 1820/240/L020	ALL
D00181 T		BACC10HG22 CLAMP-	81205	1	22-11-11 / /	ALL
D00185		BACC63BP22R19SNL PLUG-	81205	1	22-11-11 L0250/12/RS	ALL
D00185 T		BACC10HG22 CLAMP-	81205	1	22-11-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D00100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00187		BACC63BP22R19S6L PLUG-	81205	1	22-11-31 F 085/ /RS	ALL
D00187 T		BACC10KD22 CLAMP-	81205	1	22-11-31 / /	ALL
D00189		BACC63BP22A19SNL PLUG-	81205	1	22-11-31 1820/250/R020	ALL
D00189 T		BACC10HG22A CLAMP-	81205	1	22-11-31 / /	ALL
D00192		BACC45FT12-12P PLUG-	81205	2	33-27-11 MULTI/288/025	162-199
D00193		BACC63BP22R19SNL PLUG-	81205	1	22-11-31 R0232/12/TE	ALL
D00193 T		BACC10KD22 CLAMP-	81205	1	22-11-31 / /	ALL
D00195		BACC63BP22R19S6L PLUG-	81205	1	22-11-21 F 092/ /RS	ALL
D00195 T		BACC10KD22 CLAMP-	81205	1	22-11-21 / /	ALL
D00197		BACC63BP22R19SNL PLUG-	81205	1	22-11-21 1820/250/R030	ALL
D00197 T		BACC10KD22 CLAMP-	81205	1	22-11-21 / /	ALL

EQUIPMENT LIST

D280T132

Section D00100

Page 6 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00201		BACC63BP22R19SNL PLUG-	81205	1	22-11-21 L0254/12/RS	ALL
D00201 T		BACC10KD22 CLAMP-	81205	1	22-11-21 / /	ALL
D00202		BACC45FN8-2S RCPT-	81205	1	35-21-14 0372/280/L005	050-099, 276-299
D00202		BACC45FN8-2S RCPT-	81205	1	35-21-14 0373/280/L005	150-199, 275
D00203		KPSE06F16-26S PLUG-	71468	1	22-31-11 0167/200/0000	050-099
D00203		KPSE06F16-26S PLUG-	71468	1	22-31-11 0156/194/0000	150-199, 275-299
D00205		DPXBMB-67-33S-0002 PLUG	71468	1	31-41-11 P002-00/ /	ALL
D00206		BACC45FN8-2S RCPT-	81205	1	35-21-14 0320/280/L011	275-299
D00207		DPXBMB-67-33S-0002 PLUG	71468	1	31-41-11 P002-00/ /	ALL
D00209		BACC45FT20A41S6 PLUG-	81205	1	31-41-11 P009-00/ /	ALL
D00210		BACC45FT12C12S PLUG-	81205	1	33-13-11 0153/210/0000	ALL
D00212		10-60450-5 RELAY SOCKET-	81205	1	33-13-11 0153/211/L007	ALL
D00216		BACC45FT16A24S PLUG-	81205	1	34-24-11 P001-03/ /	ALL
D00216 T		C0900-246-16-A02 CLOCKING DEVICE	13556	1	34-24-11 P001-03/ /	050-099, 155-199, 275-299
D00218		BACC63BN10-5SN PLUG-	81205	1	34-13-11 P001-03/ /	ALL
D00218 T		BACC10GH10 CLAMP-	81205	1	34-13-11 / /	ALL
D00220		BACC45FT10B5S6 PLUG-	81205	1	34-13-11 P001-03/ /	ALL

EQUIPMENT LIST

D280T132

Section D00200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00223		BACC63BP14R15S7L PLUG	81205	1	27-41-11 1720/285/L005	150-154
D00223 T		BACC10KD14 CLAMP	81205	1	27-41-11 / /	150-154
D00224		BACC45FT20A41S PLUG-	81205	1	32-42-12 P001-03/ /	ALL
D00225		BACC63BP18R31S8L PLUG-	81205	1	27-58-21 1725/188/L030	050-099
D00225		BACC63BP18R31S6L PLUG-	81205	1	27-58-21 1735/185/L030	150-154
D00225		BACC63BP18R31S6L PLUG-	81205	1	27-58-21 1725/188/L030	155-199, 275-299
D00225 T		BACC10KD18 CLAMP-	81205	1	27-58-21 / /	ALL
D00227		BACC63BP10R5SNL PLUG	81205	1	27-41-11 1720/280/L007	150-154
D00227 T		BACC10KD10 CLAMP	81205	1	27-41-11 / /	150-154
D00229		BACC63BP14R15SNL PLUG	81205	1	27-41-11 1720/285/L005	150-154
D00229 T		BACC10KD14 CLAMP	81205	1	27-41-11 / /	150-154
D00231		BACC63BP14R7SNL PLUG-	81205	1	27-21-12 F 126/ /RS	ALL
D00231 T		BACC10KE14 CLAMP-	81205	1	27-21-12 / /	ALL
D00232		BACC45FT16B24S PLUG-P3-1	81205	1	32-31-11 P003-01/ /	ALL
D00233		BACC63BP16R10SNL PLUG	81205	1	22-21-21 F 158/ /RS	ALL
D00233 T		BACC10KD16 CABLE CLAMP-	81205	1	22-21-21 / /	ALL
D00237		BACC63BP14R15S7L PLUG	81205	1	27-41-21 1725/280/R005	150-154

EQUIPMENT LIST

D280T132

Section D00200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00237 T		BACC10KD14 CLAMP	81205	1	27-41-21 / /	150-154
D00238		BACC45FT12A12S7 PLUG-	81205	1	32-41-11 P003-01/ /	ALL
D00239		BACC63BP18R31S8L PLUG-	81205	1	27-58-21 1735/180/L007	050-099
D00239		BACC63BP18R31S6L PLUG-	81205	1	27-58-21 1735/180/L007	150-199, 275-299
D00239 T		BACC10KD18 CLAMP-	81205	1	27-58-21 / /	050-099, 155-199, 275-299
D00239 T		BACC10KD18 CLAMP-	81205	1	27-41-21 / /	150-154
D00240		BACC45FT12A12S PLUG-	81205	1	27-58-11 P003-01/ /	ALL
D00241		BACC63BP10R5SNL PLUG	81205	1	27-41-21 1725/280/R007	150-154
D00241 T		BACC10KE10 CLAMP	81205	1	27-41-21 / /	150-154
D00243		BACC63BP12R3SNL PLUG-	81205	1	27-21-12 F 126/ /RS	ALL
D00243 T		BACC10KD12 CLAMP-	81205	1	27-21-22 / /	ALL
D00245		BACC63BP16R10SNL PLUG	81205	1	22-21-11 F 158/ /RS	ALL
D00245 T		BACC10KD16 CABLE CLAMP-	81205	1	22-21-11 / /	ALL
D00247		BACC63BP14R15SNL PLUG	81205	1	27-41-21 1725/280/R005	150-154
D00247 T		BACC10KD14 CLAMP	81205	1	27-41-21 / /	150-154
D00248		BACC66F11C98AA01 PLUG-ARINC 600	81205	1	24-22-11 SHELF/E01/02	ALL
D00248 V		-10201 I.D. TAPE - TEXT AS BELOW	81205	1	24-22-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D00200

Page 3

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00248A		PARTAOFD00248 PLUG-		0	24-22-11 / /	ALL
D00248AV		-10202 I.D. TAPE - TEXT AS BELOW	81205	1	24-22-11 / /	ALL
D00248B		PARTBOFD00248 PLUG-		0	24-22-11 / /	ALL
D00248C		PARTCOFD00248 PLUG-		0	24-22-11 / /	ALL
D00252		BACC45FT20A41S PLUG-P31	81205	1	24-22-11 P031-00/ /	ALL
D00253		BACC45FT20A41S PLUG-	81205	1	23-51-11 P008-00/ /	ALL
D00254		BACC45FT20A41S PLUG-P31	81205	1	24-22-12 P031-00/ /	ALL
D00255		BACC45FT20A41S PLUG-	81205	1	23-51-21 0187/220/0000	ALL
D00256		BACC66F11C98AA01 PLUG-	81205	1	24-22-12 SHELF/E02/04	ALL
D00256 V		-10101 I.D. TAPE - TEXT AS BELOW	81205	1	24-22-12 / /	ALL
D00256A		PARTAOFD00256 PLUG-PART OF D00256		0	24-22-12 / /	ALL
D00256AV		-10102 I.D. TAPE - TEXT AS BELOW	81205	1	24-22-12 / /	ALL
D00256B		PARTBOFD00256 PLUG-PART OF D00256		0	24-22-12 / /	ALL
D00256C		PARTCOFD00256 PLUG-PART OF D00256		0	24-22-12 / /	ALL
D00257		BACC45FT18A31S PLUG-	81205	1	23-51-11 P008-00/ /	ALL
D00258		BACC45FT12A12S PLUG-	81205	1	33-21-14 1086/290/L056	050-099
D00258		BACC45FT12A12S PLUG-	81205	1	33-21-14 996/290/L056	150-199

EQUIPMENT LIST

D280T132

Section D00200

Page 4

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00258		BACC45FT12A12S PLUG-	81205	1	33-21-14 1042/290/L056	275-299
D00259		BACC45FT18A31S PLUG-	81205	1	23-51-21 P008-00/ /	ALL
D00260		BACC45FT20A41S PLUG-P32	81205	1	24-22-21 P032-00/ /	ALL
D00261		BACC45FT12A12S PLUG-	81205	1	23-51-11 0164/225/L036	ALL
D00262		BACC45FT20A41S PLUG-P32	81205	1	24-22-22 P032-00/ /	ALL
D00263		BACC45FT12A12S PLUG-	81205	1	23-51-21 0199/234/R036	ALL
D00264		BACC66F11C98AA01 PLUG-	81205	1	24-22-41 SHELF/E02/04	ALL
D00264A		PARTAOFD00264 PLUG-PART OF D00264		0	24-22-41 / /	ALL
D00264B		PARTBOFD00264 PLUG-PART OF D00264		0	24-22-41 / /	ALL
D00264C		PARTCOFD00264 PLUG-PART OF D00264		0	24-22-41 / /	ALL
D00268		BACC45FT20-41S PLUG-P34	81205	1	24-22-41 P034-00/ /	ALL
D00270		BACC45FT12A12S PLUG-	81205	1	33-21-14 1168/290/L056	050-099
D00270		BACC45FT12A12S PLUG-	81205	1	33-21-14 1130/290/L056	150-199, 275-299
D00273		DPXBMB-57-33S-0001 PLUG-E7	71468	1	23-71-11 1562/287/L030	ALL
D00274		BACC45FT20-41S7 PLUG-P34	81205	1	24-41-11 P034-00/ /	ALL
D00276		BACC45FT12A12S PLUG-	81205	1	33-21-14 1256/290/L056	050-099
D00276		BACC45FT12A12S PLUG-	81205	1	33-21-14 1262/290/L056	150-199

EQUIPMENT LIST

D280T132

Section D00200

Page 5

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00276		BACC45FT12A12S PLUG-	81205	1	33-21-14 1270/290/L056	275-299
D00278		BACC66F11C99AA01 PLUG-	81205	1	24-41-12 SHELF/E02/04	ALL
D00278A		PARTAOFD00278 PLUG-PART OF D00278		0	24-41-11 / /	ALL
D00278B		PARTBOFD00278 PLUG-PART OF D00278		0	21-58-17 / /	ALL
D00278C		PARTCOFD00278 PLUG-PART OF D00278		0	24-41-11 / /	ALL
D00280		BACC45FT10A5P PLUG-P31	81205	1	24-23-11 P031-00/ /	ALL
D00282		BACC45FT10A5P PLUG-P31	81205	1	24-23-12 P031-00/ /	ALL
D00284		BACC45FT10B5P PLUG-P32	81205	1	24-23-11 P032-00/ /	ALL
D00286		BACC45FT10B5P PLUG-P32	81205	1	24-23-12 P032-00/ /	ALL
D00288		BACC45FT10-5P PLUG-P34	81205	1	24-23-12 P034-00/ /	ALL
D00290		BACC45FT10-5P PLUG-P34	81205	1	24-23-12 P034-00/ /	ALL
D00296		BACC45FT12A12S PLUG-	81205	1	33-21-14 1342/290/L056	050-099
D00296		BACC45FT12A12S PLUG-	81205	1	33-21-14 1350/290/L056	150-199, 275-299
D00298		BACC45FT14-12S PLUG-E6-1	81205	1	24-31-41 SHELF/E06/01	ALL
D00299		BACC45FT14A7S PLUG-	81205	1	34-12-11 0143/228/L028	ALL

EQUIPMENT LIST

D280T132

Section D00200

Page 6 End

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00300		MS25182-2 PLUG-E6	96906	1	24-31-41 SHELF/E06/	ALL
D00302		BACC45FT12-12P PLUG-E6-1	81205	1	24-31-41 SHELF/E06/01	ALL
D00303		BACC45FT16A24S7 PLUG-ATC CONT PNL L	81205	1	34-53-11 P008-00/ /	ALL
D00304		BACC45FT10-5P PLUG-P6	81205	1	24-23-11 P006-00/ /	ALL
D00305		BACC45FT16A24S8 PLUG-ATC CONT PNL R	81205	1	34-53-11 P008-00/ /	ALL
D00306		BACC45FT10B5P PLUG-P32	81205	1	24-23-11 P032-00/ /	ALL
D00307	1	DPX2MB-57S00S-33-0001 PLUG-	71468	1	31-31-11 1542/287/L030	ALL
D00307	2	DPX2MA-57S57S-33-0001 PLUG-	71468	1	31-31-11 1542/287/L030	ALL
D00307A		PARTAOFD00307 PLUG-PART OF D00307		0	31-31-11 / /	ALL
D00310		BACC45FT10-5P PLUG-P6	81205	1	24-23-11 P006-00/ /	ALL
D00312		BACC45FT10B5P PLUG-P31	81205	1	24-23-11 P031-00/ /	ALL
D00314		BACC45FT10-5P PLUG-P34	81205	1	24-23-11 P034-00/ /	ALL
D00316		BACC63BP18S14SNL PLUG-	81205	1	24-21-41 1851/229/L005	ALL
D00316 T		BACC10KB18 CLAMP-	81205	1	24-21-41 / /	ALL
D00318		BACC45FT12A12S PLUG-	81205	1	33-21-14 1382/295/L056	050-099, 162-199
D00318		BACC45FT12A12S PLUG-	81205	1	33-21-14 1422/295/L056	150-157, 275-299
D00320		BACC45FT14A12S PLUG-	81205	1	24-31-11 SHELF/E03/03	ALL

EQUIPMENT LIST

D280T132

Section D00300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00321		KPSE06E12-10S PLUG-	71468	1	31-31-13 0974/160/L001	ALL
D00321 T		710DA012M1212-62A ADAPTER-90 DEGREES	06324	1	31-31-13 //	ALL
D00323		BACC66H21C04AA01 PLUG-ARINC 600	81205	1	34-61-11 SHELF/E02/02	ALL
D00323A		PARTAOFD00323 PLUG-PART OF D00323		0	34-61-11 //	ALL
D00323B		PARTBOFD00323 PLUG-PART OF D00323		0	34-61-11 //	ALL
D00323C		PARTCOFD00323 PLUG-PART OF D00323		0	34-61-11 //	ALL
D00324		BACC45FT14-12S PLUG-	81205	1	24-33-11 P006-00/	ALL
D00326		BACS16X1A RELAY SOCKET	81205	1	49-15-11 P049-00/	ALL
D00327		BACC66K31C01AA01 PLUG-ARINC 600	81205	1	31-31-11 SHELF/E02/03	ALL
D00327A		PARTAOFD00327 PLUG-PART OF D00327		0	31-31-11 //	ALL
D00327B		PARTBOFD00327 PLUG-PART OF D00327		0	31-31-11 //	ALL
D00327C		PARTCOFD00327 PLUG-PART OF D00327		0	31-31-11 //	ALL
D00327D		PARTDOFD00327 PLUG-PART OF D00327		0	31-31-11 //	ALL
D00327E		PARTEOFD00327 PLUG-PART OF D00327		0	31-31-11 //	ALL
D00327F		PARTFOFD00327 PLUG-PART OF D00327		0	31-31-11 //	ALL
D00328		BACS16W1 RELAY SOCKET-P6	81205	1	24-51-31 P006-00/	ALL
D00329		BACC66F11C02AC01 PLUG-ARINC 600	81205	1	34-51-11 SHELF/E02/02	ALL

EQUIPMENT LIST

D280T132

Section D00300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00329A		PARTAOFD00329 PLUG-PART OF D00329		0	34-51-11 //	ALL
D00329B		PARTBOFD00329 PLUG-PART OF D00329		0	34-51-11 //	ALL
D00329C		PARTCOFD00329 PLUG-PART OF D00329		0	34-51-11 //	ALL
D00329CT		BACC47EU2 CONTACT-E2-2 COAX,MKR,BCN-L	59610	1	34-32-11 SHELF/E02/02	ALL
D00329CU		BACC47EU2 CONTACT-E2-2 COAX,VOR-L	59610	1	34-51-11 //	ALL
D00331		BACC66H123C05AF01 PLUG-ARINC 600	81205	1	34-53-11 SHELF/E02/02	ALL
D00331A		PARTAOFD00331 PLUG-PART OF D00331		0	34-53-11 //	ALL
D00331AT		BACC47EN1 CONTACT-E2-2 COAX,ATC	59610	1	34-53-13 //	ALL
D00331B		PARTBOFD00331 PLUG-PART OF D00331		0	34-53-11 //	ALL
D00331BT		BACC47EN1 CONTACT-E2-2 COAX,ATC	59610	1	34-53-13 //	050-099, 155-199, 275-299
D00331C		PARTCOFD00331 PLUG-PART OF D00331		0	34-53-11 //	ALL
D00331CT		BACC47EU2 CONTACT-E2-2 COAX,ATC-L	59610	1	34-53-11 //	ALL
D00333		BACC66H125C03AF01 PLUG-ARINC 600	81205	1	34-55-11 SHELF/E02/02	ALL
D00333A		PARTAOFD00333 PLUG-PART OF D00333		0	34-55-11 //	ALL
D00333B		PARTBOFD00333 PLUG-PART OF D00333		0	34-55-11 //	ALL
D00333BT		BACC47EN1 CONTACT-E2-2 COAX,DME-L	59610	1	34-55-11 //	ALL
D00333C		PARTCOFD00333 PLUG-PART OF D00333		0	34-55-11 //	ALL

EQUIPMENT LIST

D280T132

Section D00300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00333CT		BACC47EU2 CONTACT-E2-2 COAX,DME-L	59610	1	34-55-11 / /	ALL
D00340		BACS16W1 RELAY SOCKET-P36	81205	1	28-41-12 P036-00/ /	ALL
D00341		BACC63BP14R15S8L PLUG	81205	1	27-41-11 1720/280/L007	150-154
D00341 T		BACC10KD14 CLAMP	81205	1	27-41-11 / /	150-154
D00342		BACS16W1 RELAY SOCKET-P33	81205	1	24-31-11 P033-00/ /	ALL
D00344		BACS16W1 RELAY SOCKET-P6	81205	1	24-51-31 P006-00/ /	ALL
D00345		BACC63BP14R15S8L PLUG	81205	1	27-41-21 1725/280/R007	150-154
D00345 T		BACC10KD14 CLAMP	81205	1	27-41-21 / /	150-154
D00348		SO-1048-8308 RELAY SOCKET-P6	35344	1	34-21-11 P006-00/ /	ALL
D00351		BACC66H21C02AA01 PLUG-ARINC 600	81205	1	34-12-21 SHELF/E02/03	ALL
D00351A		PARTAOFD00351 PLUG-PART OF D00351		0	34-12-22 / /	ALL
D00351B		PARTBOFD00351 PLUG-PART OF D00351		0	34-12-22 / /	ALL
D00351C		PARTCOFD00351 PLUG-PART OF D00351		0	34-12-22 / /	ALL
D00352		BACC63BP12A3SNL PLUG-	81205	1	29-11-32 1175/148/L080	ALL
D00352 T		BACC10KD12 CLAMP-	81205	1	29-11-32 / /	ALL
D00353		BACC66H21C04AA01 PLUG-ARINC 600	81205	1	34-61-21 SHELF/E02/03	ALL
D00353A		PARTAOFD00353 PLUG-PART OF D00353		0	34-61-21 / /	ALL

EQUIPMENT LIST

D280T132

Section D00300

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00353B		PARTBOFD00353 PLUG-PART OF D00353		0	34-61-21 //	ALL
D00353C		PARTCOFD00353 PLUG-PART OF D00353		0	34-61-21 //	ALL
D00356		BACS16X1A RELAY SOCKET-P6	81205	1	24-51-31 P006-00/	ALL
D00357		BACC66F11C02AC01 PLUG-ARINC 600	81205	1	34-51-21 SHELF/E02/03	ALL
D00357A		PARTAOFD00357 PLUG-PART OF D00357		0	34-51-21 //	ALL
D00357B		PARTBOFD00357 PLUG-PART OF D00357		0	34-51-21 //	ALL
D00357C		PARTCOFD00357 PLUG-PART OF D00357		0	34-51-21 //	ALL
D00357CT		BACC47EU2 CONTACT-E2-3 COAX,VOR-R	59610	1	34-51-21 //	ALL
D00358		BACC45FT18A8S PLUG-	81205	1	24-32-11 SHELF/E03/02	ALL
D00359		BACC66H123C05AF01 PLUG-ARINC 600	81205	1	34-53-21 SHELF/E02/03	ALL
D00359A		PARTAOFD00359 PLUG-PART OF D00359		0	34-53-21 //	ALL
D00359AT		BACC47EN1 CONTACT-E2-3 COAX, ATC	59610	1	34-53-13 //	ALL
D00359B		PARTBOFD00359 PLUG-PART OF D00359		0	34-53-21 //	ALL
D00359BT		BACC47EN1 CONTACT-E2-3 COAX,ATC-R	59610	1	34-53-21 //	050-099, 150-154
D00359BT		BACC47EN1 CONTACT-E2-3 COAX,ATC-R	59610	1	34-53-13 //	155-199, 275-299
D00359C		PARTCOFD00359 PLUG-PART OF D00359		0	34-53-21 //	ALL
D00359CT		BACC47EU2 CONTACT-E2-3 COAX,ATC-R	59610	1	34-53-21 //	ALL

EQUIPMENT LIST

D280T132

Section D00300

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00360		BACC45FT18A8S PLUG-	81205	1	24-32-11 SHELF/E03/02	ALL
D00361		BACC66H25C03AF01 PLUG-ARINC 600	81205	1	34-55-21 SHELF/E02/03	050-099, 150-199, 280-299
D00361		BACC66H125C03AF01 PLUG-ARINC 600	81205	1	34-55-21 SHELF/E02/03	275-278
D00361A		PARTAOFD00361 PLUG-PART OF D00361		0	34-55-21 / /	ALL
D00361B		PARTBOFD00361 PLUG-PART OF D00361		0	34-55-21 / /	ALL
D00361BT		BACC47EN1 CONTACT-E2-3 COAX,DME-R	59610	1	34-55-21 / /	ALL
D00361C		PARTCOFD00361 PLUG-PART OF D00361		0	34-55-21 / /	ALL
D00361CT		BACC47EU2 CONTACT-E2-3 COAX,DME-R	59610	1	34-55-21 / /	ALL
D00362		BACC45FT14A4P PLUG-	81205	1	24-33-11 SHELF/E03/02	ALL
D00364		BACC45FT12A12P PLUG-	81205	1	24-31-11 0287/123/R005	ALL
D00366		MS25182-2 PLUG-	96906	1	24-31-11 0286/126/R010	ALL
D00367		BACC66H21C06AA01 PLUG-ARINC 600	81205	1	34-21-11 SHELF/E01/06	ALL
D00367A		PARTAOFD00367 PLUG-PART OF D00367		0	34-21-11 / /	ALL
D00367B		PARTBOFD00367 PLUG-PART OF D00367		0	34-21-11 / /	ALL
D00367C		PARTCOFD00367 PLUG-PART OF D00367		0	34-21-11 / /	ALL
D00369		BACC66H21C06AA01 PLUG-ARINC600	81205	1	34-21-31 SHELF/E01/06	ALL
D00369A		PARTAOFD00369 PLUG-PART OF D00369		0	34-21-31 / /	ALL

EQUIPMENT LIST

D280T132

Section D00300

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00369B		PARTBOFD00369 PLUG-PART OF D00369		0	34-21-31 //	ALL
D00369C		PARTCOFD00369 PLUG-PART OF D00369		0	34-21-31 //	ALL
D00370		BACC45FT12A12S PLUG-	81205	1	33-21-14 1142/280/L020	050-099
D00370		BACC45FT12A12S PLUG-	81205	1	33-21-14 1136/290/L020	150-199, 275-299
D00371		BACC66H21C06AA01 PLUG-ARINC 600	81205	1	34-21-21 SHELF/E01/06	ALL
D00371A		PARTAOFD00371 PLUG-PART OF D00371		0	34-21-21 //	ALL
D00371B		PARTBOFD00371 PLUG-PART OF D00371		0	34-21-21 //	ALL
D00371C		PARTCOFD00371 PLUG-PART OF D00371		0	34-21-21 //	ALL
D00372		AN3114-1B RCPT-EXT PWR	284T0390 96906	1	24-41-11 P030-00/ /	ALL
D00373		BACC66K31C11AA01 PLUG-	81205	1	34-22-24 SHELF/E01/05	ALL
D00373A		PARTAOFD00373 PLUG-PART OF D00373		0	34-22-24 //	ALL
D00373B		PARTBOFD00373 PLUG-PART OF D00373		0	34-22-24 //	ALL
D00373C		PARTCOFD00373 PLUG-PART OF D00373		0	34-22-24 //	ALL
D00373D		PARTDOFD00373 PLUG-PART OF D00373		0	34-22-24 //	ALL
D00373E		PARTEOFD00373 PLUG-PART OF D00373		0	34-22-24 //	ALL
D00373F		PARTFOFD00373 PLUG-PART OF D00373		0	34-22-24 //	ALL
D00376		BACC45FT10-5P PLUG-P34	81205	1	24-41-11 P034-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00300

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00377		BACC66F11C51AC01 PLUG-ARINC-600	81205	1	34-31-21 SHELF/E01/05	ALL
D00377A		PARTAOFD00377 PLUG-PART OF D00377		0	34-31-21 / /	ALL
D00377B		PARTBOFD00377 PLUG-PART OF D00377		0	34-31-21 / /	ALL
D00377C		PARTCOFD00377 PLUG-PART OF D00377		0	34-31-21 / /	ALL
D00377CT		BACC47EH1 CONTACT-E1-5 COAX,ILS-RT	81205	1	34-31-21 / /	ALL
D00377CU		BACC47EH1 CONTACT-E1-5 COAX,ILS-RT	81205	1	34-31-21 / /	ALL
D00378		BACC45FT16B24S PLUG-P32	81205	1	25-31-11 P032-00/ /	ALL
D00380		BACC45FT12A12S PLUG-	81205	1	33-21-14 1274/280/L020	050-099
D00380		BACC45FT12A12S PLUG-	81205	1	33-21-14 1357/295/L020	150-199
D00380		BACC45FT12A12S PLUG-	81205	1	33-21-14 1274/290/L020	275-299
D00381		BACC66H21C07AA01 PLUG-ARINC-600	81205	1	22-11-21 SHELF/E01/05	ALL
D00381A		PARTAOFD00381 PLUG-PART OF D00381		0	22-11-22 / /	ALL
D00381B		PARTBOFD00381 PLUG-PART OF D00381		0	22-11-22 / /	ALL
D00381C		PARTCOFD00381 PLUG-PART OF D00381		0	22-11-21 / /	ALL
D00388		BACC45FT12A12S PLUG-	81205	1	33-21-14 1406/280/L005	050-099
D00388		BACC45FT12A12S PLUG-	81205	1	33-21-14 1400/290/L020	150-199, 275-299
D00390		BACC45FT16B24S PLUG-P31	81205	1	25-31-21 P031-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00300

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00391		BACC66H24C12AA01 PLUG-	81205	1	34-43-11 0140/160/0000	050-099, 150-199
D00391		BACC66H24C12AA01 PLUG-	81205	1	34-43-11 0140/160/R011	275-299
D00391A		PARTAOFD00391 PLUG-PART OF D00391		0	34-43-12 / /	ALL
D00391AV	1	317-1641-000 WAVEGUIDE INSERT	71468	1	34-43-12 0140/160/0000	ALL
D00391AV	2	C-0600-RG67-W001 WAVEGUIDE INSERT	55104	1	34-43-12 0140/160/0000	ALL
D00391B		PARTBOFD00391 PLUG-PART OF D00391		0	34-43-11 / /	ALL
D00391C		PARTCOFD00391 PLUG-PART OF D00391		0	34-43-12 / /	ALL
D00392		BACC45FT16B24S PLUG-P31	81205	1	25-31-31 P031-00/ /	275-299
D00393		BACC66H24C12AA01 PLUG-	81205	1	34-43-21 0164/160/R040	ALL
D00393A		PARTAOFD00393 PLUG-PART OF D00393		0	34-43-22 / /	ALL
D00393AV	1	317-1641-000 WAVEGUIDE INSERT	71468	1	34-43-22 0164/160/R040	ALL
D00393AV	2	C-0600-RG67-W001 WAVEGUIDE INSERT	55104	1	34-43-22 0164/160/R040	ALL
D00393B		PARTBOFD00393 PLUG-PART OF D00393		0	34-43-21 / /	ALL
D00393C		PARTCOFD00393 PLUG-PART OF D00393		0	34-43-21 / /	ALL
D00395		KPSE06F18-32S PLUG-	71468	1	34-43-12 P008-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00300
Page 9 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00401		BACC66H123C01AD01 PLUG-ARINC 600	81205	1	34-33-11 SHELF/E05/01	ALL
D00401A		PARTAOFD00401 PLUG-PART OF D00401		0	34-33-11 / /	ALL
D00401AT		BACC47EN1 CONTACT-E5-1 COAX, LRRR-LRCVR	59610	1	34-33-11 0620/170/R070	ALL
D00401B		PARTBOFD00401 PLUG-PART OF D00401		0	34-33-11 / /	ALL
D00401BT		BACC47EN1 CONTACT-E5-1 COAX, LRRR-LXMTR	59610	1	34-33-11 0620/170/R070	ALL
D00401C		PARTCOFD00401 PLUG-PART OF D00401		0	34-33-11 / /	ALL
D00402		BACS16W1 RELAY SOCKET-E6-1	81205	1	24-31-41 SHELF/E06/	ALL
D00403		BACC66H123C01AD01 PLUG-ARINC 600	81205	1	34-33-21 SHELF/E05/01	ALL
D00403A		PARTAOFD00403 PLUG-PART OF D00403		0	34-33-21 / /	ALL
D00403AT		BACC47EN1 CONTACT-E5-1 COAX, LRRR-R RCVR	59610	1	34-33-21 0620/170/R070	050-099
D00403AT		BACC47EN1 CONTACT-E5-1 COAX, LRRR-RRCVR	59610	1	34-33-21 0620/170/R070	150-199, 275-299
D00403B		PARTBOFD00403 PLUG-PART OF D00403		0	34-33-21 / /	ALL
D00403BT		BACC47EN1 CONTACT-E5-1 COAX, LRRR-RRCVR	59610	1	34-33-21 0620/170/R070	050-099
D00403BT		BACC47EN1 CONTACT-E5-1 COAX, LRRR-RXMTR	59610	1	34-33-21 0620/170/R070	150-199, 275-299
D00403C		PARTOFD00403 PLUG-PART OF D00403		0	34-33-21 / /	050-099
D00403C		PARTCOFD00403 PLUG-PART OF D00403		0	34-33-21 / /	150-199, 275-299
D00405		BACC66H123C01AD01 PLUG-ARINC 600	81205	1	34-33-31 SHELF/E05/01	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00405A		PARTAOFD00405 PLUG-PART OF D00405		0	34-33-31 / /	ALL
D00405AT		BACC47EN1 CONTACT-E5-1 COAX, LRRRA-CRCVR	59610	1	34-33-31 0620/170/R070	050-099
D00405AT		BACC47EN1 CONTACT-E5-1 COAX, LRRRA-C RCVR	59610	1	34-33-31 0620/170/R070	150-199, 275-299
D00405B		PARTBOFD00405 PLUG-PART OF D00405		0	34-33-31 / /	ALL
D00405BT		BACC47EN1 CONTACT-E5-1 COAX, LRRRA-CXMTR	59610	1	34-33-31 0620/170/R070	050-099
D00405BT		BACC47EN1 CONTACT-E5-1 COAX, LRRRA-C XMTR	59610	1	34-33-31 0620/170/R070	150-199, 275-299
D00405C		PARTCOFD00405 PLUG-PART OF D00405		0	34-33-31 / /	ALL
D00407		BACC45FT16A24S PLUG-P8	81205	1	23-12-11 P008-00/ /	ALL
D00408		BACC66H21C15AA01 PLUG-E6-1	81205	1	49-61-11 SHELF/E06/- 01	ALL
D00408A		PARTAOFD00408 PLUG-PART OF D00408		0	49-14-11 / /	ALL
D00408B		PARTBOFD00408 PLUG-PART OF D00408		0	49-14-11 / /	ALL
D00408C		PARTCOFD00408 PLUG-PART OF D00408		0	49-14-11 / /	ALL
D00409		BACC45FT16A24S PLUG-P8	81205	1	23-12-21 P008-00/ /	ALL
D00411		BACC45FT16A24S PLUG-	81205	1	23-12-31 P008-00/ /	ALL
D00413		BACC66K31C11AA01 PLUG-ARINC 600	81205	1	34-22-34 SHELF/E01/04	ALL
D00413A		PARTAOFD00413 PLUG-PART OF D00413		0	34-22-35 / /	ALL
D00413B		PARTBOFD00413 PLUG-PART OF D00413		0	34-22-36 / /	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00413C		PARTCOFD00413 PLUG-PART OF D00413		0	34-22-36 / /	ALL
D00413D		PARTDOFD00413 PLUG-PART OF D00413		0	34-22-34 / /	ALL
D00413E		PARTEOFD00413 PLUG-PART OF D00413		0	34-22-34 / /	ALL
D00413F		PARTFOFD00413 PLUG-PART OF D00413		0	34-22-36 / /	ALL
D00416		BACS16W1 RELAY SOCKET-P32	81205	1	24-22-22 P032-00/ /	ALL
D00417		BACC66F11C51AC01 PLUG-ARINC-600	81205	1	34-31-31 SHELF/E01/04	ALL
D00417A		PARTAOFD00417 PLUG-PART OF D00417		0	34-31-31 / /	ALL
D00417B		PARTBOFD00417 PLUG-PART OF D00417		0	34-31-31 / /	ALL
D00417C		PARTCOFD00417 PLUG-PART OF D00417		0	34-31-31 / /	ALL
D00417CT		BACC47EH1 CONTACT-E1-4 COAX,ILS-CTR	81205	1	34-31-31 / /	ALL
D00417CU		BACC47EH1 CONTACT-E1-4 COAX,ILS-CTR	81205	1	34-31-31 / /	ALL
D00418		BACC63BN14-7SN PLUG-	81205	1	36-11-31 0962/158/L020	ALL
D00418 T		710ES012M1412-62A ADAPTER-	06324	1	36-11-31 / /	ALL
D00419		BACC45FT20A41S8 PLUG-P61	81205	1	31-41-13 P061-00/ /	ALL
D00420		BACC45FT12A12S PLUG-	81205	1	33-21-14 1266/280/L020	050-099
D00420		BACC45FT12A12S PLUG-	81205	1	33-21-14 1266/290/L020	150-199, 275-299
D00421		BACC66H21C07AA01 PLUG-ARINC-600	81205	1	22-11-31 SHELF/E01/04	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00421A		PARTAOFD00421 PLUG-PART OF D00421		0	22-11-32 //	ALL
D00421B		PARTBOFD00421 PLUG-PART OF D00421		0	22-11-32 //	ALL
D00421C		PARTCOFD00421 PLUG-PART OF D00421		0	22-11-31 //	ALL
D00422		BACS16W1 RELAY SOCKET-P31	81205	1	24-22-12 P031-00/ /	ALL
D00423		BACC66H21C02AA01 PLUG-ARINC-600	81205	1	34-12-11 SHELF/E01/03	ALL
D00423A		PARTAOFD00423 PLUG-PART OF D00423		0	34-12-11 //	ALL
D00423B		PARTBOFD00423 PLUG-PART OF D00423		0	34-12-11 //	ALL
D00423C		PARTCOFD00423 PLUG-PART OF D00423		0	34-12-11 //	ALL
D00424		BACC45FT12A12S PLUG-	81205	1	33-21-14 0922/294/L020	050-099
D00425		BACC66K31C11AA01 PLUG-	81205	1	34-22-14 SHELF/E01/02	ALL
D00425A		PARTAOFD00425 PLUG-PART OF D00425		0	34-22-14 //	ALL
D00425B		PARTBOFD00425 PLUG-PART OF D00425		0	34-22-16 //	ALL
D00425C		PARTCOFD00425 PLUG-PART OF D00425		0	34-22-16 //	ALL
D00425D		PARTDOFD00425 PLUG-PART OF D00425		0	34-22-14 //	ALL
D00425E		PARTEOFD00425 PLUG-PART OF D00425		0	34-22-14 //	ALL
D00425F		PARTFOFD00425 PLUG-PART OF D00425		0	34-22-16 //	ALL
D00426		BACC45FT12A12S PLUG-	81205	1	33-21-13 0909/290/L056	050-099

EQUIPMENT LIST

D280T132

Section D00400

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00427		BACC66H21C21AA01 PLUG-ARINC-600	81205	1	22-31-11 SHELF/E01/03	ALL
D00427A		PARTAOFD00427 PLUG-PART OF D00427		0	22-31-12 //	ALL
D00427B		PARTBOFD00427 PLUG-PART OF D00427		0	22-31-11 //	ALL
D00427C		PARTCOFD00427 PLUG-PART OF D00427		0	22-31-11 //	ALL
D00428		BACS16AF1 PLUG-P37	81205	1	28-25-11 P037-00/	ALL
D00429		BACC66F11C51AC01 PLUG-ARINC-710	81205	1	34-31-11 SHELF/E01/03	ALL
D00429A		PARTAOFD00429 PLUG-PART OF D00429		0	34-31-11 //	ALL
D00429B		PARTBOFD00429 PLUG-PART OF D00429		0	34-31-11 //	ALL
D00429C		PARTCOFD00429 PLUG-PART OF D00429		0	34-31-11 //	ALL
D00429CT		BACC47EH1 CONTACT-E1-3 COAX ILS-L	81205	1	34-31-11 //	ALL
D00429CU		BACC47EH1 CONTACT-E1-3 COAX,ILS-L	81205	1	34-31-11 //	ALL
D00430		BACS16W5 PLUG-P37	81205	1	28-25-11 P037-00/	ALL
D00432		BACC63BP10R5SNL PLUG-	81205	1	27-31-11 1725/250/L050	ALL
D00432 T		BACC10KD10 CLAMP-	81205	1	27-23-11 //	ALL
D00433		BACC66H21C07AA01 PLUG-ARINC-600	81205	1	22-11-11 SHELF/E01/03	ALL
D00433A		PARTAOFD00433 PLUG-PART OF D00433		0	22-11-12 //	ALL
D00433B		PARTBOFD00433 PLUG-PART OF D00433		0	22-11-12 //	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00433C		PARTCOFD00433 PLUG-PART OF D00433		0	22-11-11 //	ALL
D00434		BACS16X3A RELAY SOCKET-P6	81205	1	24-33-11 P006-00/	ALL
D00435		BACC66F11C08AA01 PLUG-ARINC-600	81205	1	34-46-11 SHELF/E01/05	ALL
D00435A		PARTAOFD00435 PLUG-PART OF D00435		0	34-46-11 //	ALL
D00435B		PARTBOFD00435 PLUG-PART OF D00435		0	34-46-11 //	ALL
D00435C		PARTCOFD00435 PLUG-PART OF D00435		0	34-46-11 //	ALL
D00438		BACS16X1A RELAY SOCKET-P6	81205	1	24-33-11 P006-00/	ALL
D00439		BACC66F11C04AC01 PLUG-ARINC 600	81205	1	23-12-11 SHELF/E02/05	ALL
D00439A		PARTAOFD00439 PLUG-PART OF D00439		0	23-12-11 //	ALL
D00439B		PARTBOFD00439 PLUG-PART OF D00439		0	23-12-11 //	ALL
D00439C		PARTCOFD00439 PLUG-PART OF D00439		0	23-12-11 //	ALL
D00439CT		BACC47EU2 CONTACT-COAX,E2-5,VHF-L	81205	1	23-12-11 //	ALL
D00440		BACC45FT12-12S PLUG-P6	81205	1	24-33-11 P006-00/	ALL
D00441		BACC66F11C03AA01 PLUG-ARINC 600	81205	1	23-21-11 SHELF/E02/05	ALL
D00441A		PARTAOFD00441 PLUG-PART OF D00441		0	23-21-11 //	ALL
D00441B		PARTBOFD00441 PLUG-PART OF D00441		0	23-21-11 //	ALL
D00441C		PARTCOFD00441 PLUG-PART OF D00441		0	23-21-11 //	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00443		BACC66F11C04AC01 PLUG-ARINC 600	81205	1	23-12-21 SHELF/E02/05	ALL
D00443A		PARTAOFD00443 PLUG-PART OF D00443		0	23-12-21 //	ALL
D00443B		PARTBOFD00443 PLUG-PART OF D00443		0	23-12-21 //	ALL
D00443C		PARTCOFD00443 PLUG-PART OF D00443		0	23-12-21 //	ALL
D00443CT		BACC47EU2 CONTACT-COAX,E2-5,VHF-R	59610	1	23-12-21 //	ALL
D00445		BACC66F11C04AC01 PLUG-ARINC 600	81205	1	23-12-31 SHELF/E02/05	ALL
D00445A		PARTAOFD00445 PLUG-PART OF D00445		0	23-12-31 //	ALL
D00445B		PARTBOFD00445 PLUG-PART OF D00445		0	23-12-31 //	ALL
D00445C		PARTCOFD00445 PLUG-PART OF D00445		0	23-12-31 //	ALL
D00445CT		BACC47EU2 CONTACT-COAX,E2-5,VHF-C	59610	1	23-12-31 //	ALL
D00446		BACC45FT18A8S PLUG-	81205	1	21-58-14 0398/187/L075	ALL
D00447		BACC66H21C09AA01 PLUG-ARINC 600	81205	1	23-22-11 SHELF/E02/05	050-099
D00447		BACC66H21C09AA01 PLUG-ARINC 600	81205	1	23-22-11 SHELF/E02/-05	151, 275-299
D00447A	9	CUSTOMER-71 PLUG	CUST	1	23-22-11 SHELF/E02/-05	150, 152-199
D00447A		PARTAOFD00447 PLUG-PART OF D00447		0	23-22-11 //	050-099
D00447A		PARTAOFD00447 PLUG-PART OF D00447	81205	1	23-22-11 SHELF/E02/-05	151, 275-299
D00447B	9	CUSTOMER-71 PLUG	CUST	1	23-22-11 SHELF/E02/-05	150, 152-199

EQUIPMENT LIST

D280T132

Section D00400

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00447B		PARTBOFD00447 PLUG-PART OF D00447		0	23-22-11 / /	050-099
D00447B		PARTBOFD00447 PLUG-PART OF D00447	81205	1	23-22-11 SHELF/E02/-05	151, 275-299
D00447C	9	CUSTOMER-71 PLUG-PART OF D00447	CUST	1	23-22-11 SHELF/E02/-05	150, 152-199
D00447C		PARTCOFD00447 PLUG-PART OF D00447		0	23-22-11 / /	050-099
D00447C		PARTCOFD00447 PLUG-PART OF D00447	81205	1	23-22-11 SHELF/E02/-05	151, 275-299
D00447D	9	CUSTOMER-71 PLUG-ARINC 600(BACC66H21C09AA01)(D00447)	81205	1	23-22-11 SHELF/E02/-05	150, 152-166
D00448		BACC45FT18C8S PLUG-	81205	1	21-25-11 0750/124/L044	ALL
D00449		DPXB32-33S-0001 PLUG-	71468	1	23-34-17 SHELF/E02/05	050-099
D00449		DPXB32-33S-0001 PLUG-	71468	1	23-34-14 SHELF/E02/05	150-199, 275-299
D00450		BACC45FT14A7S PLUG-	81205	1	21-26-11 1551/149/R013	ALL
D00451		DPXBMB-67-33S-0001 PLUG-	71468	1	23-34-17 SHELF/E02/05	050-099
D00451		DPXBMB-67-33S-0001 PLUG-	71468	1	23-34-14 SHELF/E02/05	150-199, 275-299
D00454		BACC45FT18A8S PLUG-	81205	1	21-25-21 0752/131/R030	ALL
D00455		BACC66F11C07AA01 PLUG-	81205	1	23-31-11 SHELF/E02/05	ALL
D00455A		PARTAOFD00455 PLUG-PART OF D00455		0	23-31-11 / /	ALL
D00455B		PARTBOFD00455 PLUG-PART OF D00455		0	23-31-11 / /	ALL
D00455C		PARTCOFD00455 PLUG-PART OF D00455		0	23-31-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00456		BACC45FT14A7S PLUG-	81205	1	21-26-11 1551/153/R035	ALL
D00459		BACC66F11C14AA01 PLUG-	81205	1	23-42-11 SHELF/E02/05	ALL
D00459A		PARTAOFD00459 PLUG-PART OF D00459		0	23-42-11 //	ALL
D00459B		PARTBOFD00459 PLUG-PART OF D00459		0	23-42-11 //	ALL
D00459C		PARTCOFD00459 PLUG-PART OF D00459		0	23-42-11 //	ALL
D00462		BACC66F11C07AA01 PLUG-ARINC 600	81205	1	21-31-11 SHELF/E01/02	ALL
D00462A		PARTAOFD00462 PLUG-PART OF D00462		0	21-31-11 //	ALL
D00463		BACC66F11C05AA01 PLUG-ARINC 600	81205	1	34-57-11 SHELF/E05/01	ALL
D00463A		PARTAOFD00463 PLUG-PART OF D00463		0	34-57-11 //	ALL
D00463B		PARTBOFD00463 PLUG-PART OF D00463		0	34-57-11 //	ALL
D00463C		PARTCOFD00463 PLUG-PART OF D00463		0	34-57-11 //	ALL
D00464		BACC63BP12R3S8L PLUG-	81205	1	29-11-32 1060/180/L005	ALL
D00464 T		710AS011M1209-62A ADAPTER-	06324	1	29-11-32 //	ALL
D00465		BACC45FT20D41S PLUG-L FLT MNG COMPUTER CONT DSPL UNIT	81205	1	34-61-11 P009-00/ /	ALL
D00466		BACC63BP12R3S8L PLUG-	81205	1	29-11-32 1060/180/L005	ALL
D00466 T		710AS011M1209-62A ADAPTER-	06324	1	29-11-32 //	ALL
D00467		BACC45FT20D41S PLUG-R FLT MNG COMPUTER CONT DSPL UNIT	81205	1	34-61-21 P009-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00468		000300-1560 RELAY SOCKET	05574	1	30-32-21 P033-00/ /	ALL
D00469		BACC45FT20B41S PLUG-P10	81205	1	34-22-14 P010-00/ /	ALL
D00471		BACC45FT20A41S PLUG-P10	81205	1	34-22-24 P010-00/ /	ALL
D00474		BACC63BP12R3S6L PLUG-	81205	1	29-11-31 0981/157/R005	ALL
D00474 T		710AA011M1209-62A ADAPTER-90 DEGREES	06324	1	29-11-31 / /	ALL
D00475		BACC45FT18A31S PLUG-P55	81205	1	22-11-12 P055-00/ /	ALL
D00476		BACC63BP12R3S6L PLUG-	81205	1	29-11-31 1025/157/R005	ALL
D00476 T		710AA011M1209-62A ADAPTER-90 DEGREES	06324	1	29-11-31 / /	ALL
D00477		BACC45FT18A31S7 PLUG-P55	81205	1	22-11-12 P055-00/ /	ALL
D00478		BACC63BP12R3S6L PLUG-	81205	1	29-11-32 1002/152/R006	ALL
D00478 T		710AS011M1209-62A ADAPTER-	06324	1	29-11-32 / /	ALL
D00479		BACC45FT18A31S6 PLUG-P55	81205	1	22-11-32 P055-00/ /	ALL
D00480		BACC63BW24C22S PLUG-	81205	1	29-11-12 NL255/155/	ALL
D00481		KM-59-20 PLUG-COAX	91836	1	23-34-17 SHELF/E02/05	050-099
D00481		KM-59-20 PLUG-COAX	91836	1	23-34-14 SHELF/E02/05	150-199, 275-299
D00482		BACC63BW24C22S PLUG-	81205	1	29-11-31 0999/145/R005	ALL
D00483		KPSE06F10-6S PLUG-	71468	1	34-43-12 0140/160/R020	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00484		BACC63BW24C22S PLUG-	81205	1	29-11-31 1043/145/R005	ALL
D00486		BACC63BW24C22S PLUG-	81205	1	29-11-22 NR270/155/	ALL
D00488		BACC63BP18A14SNL PLUG-	81205	1	29-11-32 1125/141/L083	ALL
D00488 T		BACC10KD18 CLAMP-	81205	1	29-11-32 / /	ALL
D00489		MS3475W22-55S PLUG-WX RADAR ANT.	96906	1	34-43-22 126/198/L007	ALL
D00489 T		380AA001NF2212H BACKSHELL	06324	1	34-43-22 132/ /	050-099, 154-199, 275-299
D00489 T		380AA001NF2220H BACKSHELL	06324	1	34-43-22 132/ /	150-153
D00490		BACC45FT12A12S PLUG-P5	81205	1	21-61-11 P005-00/ /	ALL
D00491		MS3475W22-55S PLUG-WX RADAR ANT	96906	1	34-43-12 126/198/0000	ALL
D00491 T		G4993-2212-1-5N BACKSHELL	0324	1	34-43-12 132/ /	ALL
D00492		BACC45FT12A12S PLUG-P5	81205	1	21-61-21 P005-00/ /	ALL
D00493		BACC45FT16A24S PLUG-	81205	1	31-31-11 P061-00/ /	ALL
D00494	1	BACC63BW14SC5S PLUG-	81205	1	29-11-11 NL230/155/	ALL
D00494	2	BACC63CE14SA5S PLUG-	81205	1	29-11-11 NL230/155/	ALL
D00495		KPSE06F18-32SW PLUG-	71468	1	34-43-22 P008-00/ /	ALL
D00496	1	BACC63BW14SC5S PLUG-	81205	1	29-11-21 NR240/155/	ALL
D00496	2	BACC63CE14SA5S PLUG-	81205	1	29-11-21 NR240/155/	ALL

EQUIPMENT LIST

D280T132

Section D00400

Page 11

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00497		BACC45FT10A5S PLUG-	81205	1	23-34-13 0310/195/R045	050-099
D00497		BACC45FT10A5S PLUG-	81205	1	23-34-15 0310/195/R045	150-199, 275-299
D00498		BACC45FM12C3S PLUG-	81205	1	29-32-11 NL255/150/	ALL
D00499		BACC45FT10A5P PLUG-	81205	1	23-34-13 0310/195/R045	050-099
D00499		BACC45FT10A5P PLUG-	81205	1	23-34-15 0310/195/R045	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D00400
Page 12 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00500		BACC45FM12C3S PLUG-	81205	1	29-32-11 NR250/145/	ALL
D00500 T		MS27291-2 CLAMP-	96906	1	29-32-11 / /	ALL
D00501		BACC45FT10A5S PLUG-	81205	1	23-34-13 0310/195/R045	050-099
D00501		BACC45FT10A5S PLUG-	81205	1	23-34-17 0310/195/R045	150-199, 275-299
D00502		BACC63BP18R14SNL PLUG-	81205	1	49-15-11 1738/290/R035	ALL
D00502 T		BACC10KD18 CLAMP-	81205	1	49-15-11 / /	ALL
D00503		BACC45FT10A5P PLUG-	81205	1	23-34-17 0310/195/R045	ALL
D00504		BACC45FS10A5S8 PLUG-	81205	1	21-44-21 1514/170/R067	ALL
D00505		BACC45FT10A5S PLUG-	81205	1	23-34-13 0310/195/R045	050-099
D00505		BACC45FT10A5S PLUG-	81205	1	23-34-16 0310/195/R045	150-199, 275-299
D00506		878239-02 PLUG-	71468	1	26-15-11 1845/242/R005	ALL
D00507		BACC45FT10A5P PLUG-	81205	1	23-34-13 0310/195/R045	ALL
D00508		878239-02 PLUG-	71468	1	26-15-11 1844/202/L006	ALL
D00509		BACC45FT14A15S PLUG-	81205	1	23-34-12 0310/195/R045	ALL
D00510		878238-02 PLUG-	33525	1	26-15-11 1844/202/L006	ALL
D00511		BACC45FT10A5S PLUG-	81205	1	23-34-15 0320/195/R045	ALL
D00512		878238-02 PLUG-	33525	1	26-15-11 1845/242/R005	ALL

EQUIPMENT LIST

D280T132

Section D00500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00513		BACC45FT10A5P PLUG-	81205	1	23-34-16 0320/195/R045	050-099
D00513		BACC45FT10A5P PLUG-	81205	1	23-34-15 0320/195/R045	150-199, 275-299
D00514		878238-02 PLUG	33525	1	26-15-11 1910/238/L018	ALL
D00515		BACC45FT10A5S PLUG-	81205	1	23-34-15 0320/195/R045	050-099
D00515		BACC45FT10A5S PLUG-	81205	1	23-34-17 0320/195/R045	150-199, 275-299
D00516		878238-02 PLUG	33525	1	26-15-11 1898/214/L006	ALL
D00517		BACC45FT10A5P PLUG-	81205	1	23-34-15 0320/195/R045	050-099
D00517		BACC45FT10A5P PLUG-	81205	1	23-34-17 0320/195/R045	150-199, 275-299
D00518		878239-02 PLUG	33525	1	26-15-11 1910/238/L031	ALL
D00519		BACC45FT10A5S PLUG-	81205	1	23-34-14 0320/195/R045	050-099
D00519		BACC45FT10A5S PLUG-	81205	1	23-34-16 0320/195/R045	150-199, 275-299
D00520		878239-02 PLUG	33525	1	26-15-11 1898/202/L006	ALL
D00521		BACC45FT10A5P PLUG-	81205	1	23-34-14 0320/195/R045	050-099
D00521		BACC45FT10A5P PLUG-	81205	1	23-34-16 0320/195/R045	150-199, 275-299
D00523		BACC45FT14A15S PLUG-	81205	1	23-34-12 0320/195/R045	ALL
D00524		BACC45FS10A5S PLUG-	81205	1	21-44-21 1514/170/R067	ALL
D00525		KM-59-41 PLUG-COAXIAL	91836	1	23-34-17 0305/195/R035	ALL

EQUIPMENT LIST

D280T132

Section D00500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00527		KM-59-41 PLUG-COAXIAL	91836	1	23-34-17 0305/195/R035	ALL
D00529		KM-59-41 PLUG-COAXIAL	91836	1	23-34-17 0305/195/R035	ALL
D00531		KM-59-41 PLUG-COAXIAL	91836	1	23-34-17 0305/195/R035	050-099
D00531		KM-59-41 PLUG-COAXIAL	91836	1	23-34-14 0305/195/R035	150-199, 275-299
D00533		BACC45FT14A15S PLUG-	81205	1	23-34-14 0305/195/R035	ALL
D00535		KM-59-41 PLUG-COAXIAL	91836	1	23-34-14 0305/195/R035	ALL
D00539		KM-59-41 PLUG-COAXIAL	91836	1	23-34-18 0310/195/R035	050-099
D00539		KM-59-41 PLUG-COAXIAL	91836	1	23-34-15 0310/195/R035	150-199, 275-299
D00541		KM-59-41 PLUG-COAXIAL	91836	1	23-34-18 0310/195/R035	050-099
D00541		KM-59-41 PLUG-COAXIAL	91836	1	23-34-17 0310/195/R035	150-199, 275-299
D00542		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL
D00543		KM-59-41 PLUG-COAXIAL	91836	1	23-34-18 0310/195/R035	050-099
D00543		KM-59-41 PLUG-COAXIAL	91836	1	23-34-16 0310/195/R035	150-199, 275-299
D00544		BACC45FT18-8S PLUG-	81205	1	21-58-15 0370/155/R070	ALL
D00545		BACC45FT14A15S PLUG-	81205	1	23-34-14 0310/195/R035	ALL
D00546		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL
D00547		KM-59-41 PLUG-COAXIAL	91836	1	23-34-14 0310/195/R035	ALL

EQUIPMENT LIST

D280T132

Section D00500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00548		BACC45FT12A12S PLUG-P5	81205	1	33-13-16 P005-00/ /	ALL
D00549		BACC45FT20A41S PLUG	81205	1	23-51-41 0217/225/R050	ALL
D00550		BACC45FT12A12S PLUG-P5	81205	1	33-13-16 P005-00/ /	ALL
D00551		BACC45FT18A31S PLUG-P61	81205	1	23-51-41 P061-00/ /	ALL
D00552		BACC45FM12-3S RCPT-	81205	1	29-32-11 1010/170/0010	ALL
D00552 T		710ES012M1209-62A ADAPTER-	06324	1	29-32-11 / /	ALL
D00554		BACC63BP12R3SNL PLUG-	81205	1	29-31-11 0965/171/R010	ALL
D00554 T		710AS011M1209-62A ADAPTER-	06324	1	29-31-11 / /	ALL
D00556		BACC63BP14R7SNL PLUG-	81205	1	29-33-11 1010/170/0010	ALL
D00556 T		710AA011M1412-62A ADAPTER-90 DEGREE	06324	1	29-33-11 / /	ALL
D00557		BACC45FT16A24S PLUG-P61	81205	1	23-51-41 P061-00/ /	ALL
D00558		BACC45FT12A12S PLUG-	81205	1	33-13-16 P005-00/ /	ALL
D00560		BACC63BN14C7SN PLUG-	81205	1	36-11-41 1825/220/L024	ALL
D00562		BACC45FT14D7S PLUG-	81205	1	30-42-11 0142/237/L006	ALL
D00564		BACC45FT10A5S PLUG-	81205	1	30-43-11 0137/232/L013	ALL
D00566		BACC45FS10A5S6 PLUG-	81205	1	21-44-21 1513/173/R064	ALL
D00568		BACC63BW10SLC4S PLUG-	81205	1	30-31-13 0201/182/R065	ALL

EQUIPMENT LIST

D280T132

Section D00500

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00570		BACC45FT14D7S PLUG-	81205	1	30-42-11 0142/237/R006	ALL
D00572		BACC45FT10A5S PLUG-	81205	1	30-43-11 0137/230/R013	ALL
D00574		BACC63BW10SLC4S PLUG	81205	1	30-31-21 0201/212/R069	ALL
D00576		BACC45FT14A7S PLUG-	81205	1	21-44-21 1365/172/L075	ALL
D00578		BACS16X1A RELAY SOCKET-P36	81205	1	52-11-12 P036-00/ /	ALL
D00582		BACS16X1A RELAY SOCKET-	81205	1	21-44-21 P36/ /	050-099
D00582		BACS16X1A RELAY SOCKET-	81205	1	21-44-21 P036-00/ /	150-199, 275-299
D00584		BACC45FT12-12S PLUG-	81205	1	33-11-11 P007-00/ /	ALL
D00586		BACC45FT10A5S PLUG-	81205	1	33-11-11 P007-00/ /	ALL
D00588		BACC45FT12-12S PLUG-	81205	1	33-11-11 P007-00/ /	ALL
D00589		BACC45FN12-12S RCPT-	81205	1	27-61-15 0219/202/L021	ALL
D00590		BACC63CD32-17S RCPT-A2	81205	1	25-31-21 1559/282/L062	050-099, 150-199
D00590		BACC63CD32-17S RCPT-A2 GALLEY	81205	1	25-31-21 1559/282/L062	275-278
D00590		BACC63CD32-17S RCPT-A2 GALLEY	81205	1	25-31-21 1559/283/L062	280-299
D00591		BACC45FN12-12S RCPT-	81205	1	27-61-14 0219/202/L021	ALL
D00592		BACC45FM14-15S RCPT-	81205	1	25-31-21 1559/282/L062	050-099, 150-199
D00592		BACC45FN14-15S RCPT-A2 GALLEY	81205	1	25-31-21 1559/282/L062	275-278

EQUIPMENT LIST

D280T132

Section D00500

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00592		BACC45FN14-15S RCPT-A2 GALLEY	81205	1	25-31-21 1557/284/L062	280-299
D00593		BACC45FN12-12S RCPT-	81205	1	27-61-16 0219/202/L021	ALL
D00594		BACC63CD32-17S RCPT-A3	81205	1	25-31-31 1562/281/R065	050-099, 150-199
D00594		BACC63CD24-22S RCPT-A3 GALLEY	81205	1	25-31-31 1562/281/R065	275-278
D00594		BACC63CD24-22S RCPT-A3 GALLEY	81205	1	25-31-31 1559/282/R062	280-299
D00595		BACC45FN12-12S RCPT-	81205	1	27-61-17 0219/205/R040	ALL
D00596		BACC45FM12-12S RCPT-	81205	1	25-31-31 1562/281/R065	050-099, 150-199
D00596		BACC45FN12-12S RCPT-A3 GALLEY	81205	1	25-31-31 1562/281/R065	275-278
D00596		BACC45FN12-12S RCPT-A3 GALLEY	81205	1	25-31-31 1557/284/R062	280-299
D00597		BACC45FN12-12S RCPT-	81205	1	27-61-13 0223/202/R021	ALL
D00598		BACS16AF1 RELAY SOCKET-P36	81205	1	32-09-11 P036-00/ /	ALL
D00599		BACC45FN12-12S RCPT-	81205	1	27-61-18 0228/202/R021	ALL

EQUIPMENT LIST

D280T132

Section D00500
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00600		BACS16W1 RELAY SOCKET-P33	81205	1	29-11-22 P033-00/ /	ALL
D00601		BACC45FT14A15S8 PLUG-P8 ILS R CONT PNL	81205	1	34-31-21 P008-00/ /	ALL
D00602		BACS16X1A RELAY SOCKET-P33	81205	1	29-11-22 P033-00/ /	ALL
D00603		BACC45FT14A15S7 PLUG-	81205	1	34-31-31 P008-00/ /	ALL
D00604		BACS16X1A RELAY SOCKET-P33	81205	1	29-11-22 P033-00/ /	ALL
D00605		MB6R-3 RCPT-	09922	1	23-34-15 0423/210/R090	050-099, 150-157, 276-299
D00605		MB6R-3 RCPT-	09922	1	23-34-13 0472/210/R090	162-199
D00605		MB6R-3 RCPT-	09922	1	23-34-15 0383/210/R090	275
D00605 T		KIT700-43 COAX CONTACT-	09922	1	23-34-15 / /	050-099
D00605 T		KIT700-43 COAX CONTACT-	09922	1	23-34-13 / /	150-199, 275-299
D00605 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-15 / /	050-099
D00605 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-13 / /	150-199, 275-299
D00606		BACC45FT14D7S PLUG-	81205	1	21-44-21 1360/180/L075	ALL
D00607		MB6R-3 RCPT-	09922	1	23-34-17 0588/197/L011	050-099, 162-199
D00607		MB6R-3 RCPT-	09922	1	23-34-17 0434/197/L011	150-157, 275-299
D00607 T		KIT700-43 COAX CONTACT-	09922	1	23-34-17 / /	050-099
D00607 T		KIT700-43 COAX CONTACT-	09922	1	23-34-13 / /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D00600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00607	U	204A121-3-01 SHRINK BOOT-	06090	1	23-34-17 / /	050-099
D00607	U	204A121-3-01 SHRINK BOOT-	06090	1	23-34-13 / /	150-199, 275-299
D00608		BACC45FT18A31S PLUG-	81205	1	21-26-21 1450/195/R040	ALL
D00609		MB6R-3 RCPT-	09922	1	23-34-16 0503/210/L090	050-099
D00609		MB6R-3 RCPT-	09922	1	23-34-13 0472/210/L090	150-199
D00609		MB6R-3 RCPT-	09922	1	23-34-13 0383/210/L090	275
D00609		MB6R-3 RCPT-	09922	1	23-34-16 0423/210/L090	276-299
D00609	T	KIT700-43 COAX CONTACT-	09922	1	23-34-13 / /	ALL
D00609	U	204A121-3-01 SHRINK BOOT-	06090	1	23-34-13 / /	ALL
D00612		BACC45FT12-12S PLUG-	81205	1	38-32-11 1566/160/L029	050-099, 155, 162-165
D00612		BACC45FT12A12S PLUG-	81205	1	38-32-11 1566/160/L029	150-154
D00612		BACC45FT16A24S PLUG-	81205	1	38-32-11 1568/160/L029	156-157, 166-199, 277-299
D00612		BACC45FT16A24S PLUG-	81205	1	38-32-11 1566/160/L029	275-276
D00614		BACS16W1 RELAY SOCKET-	81205	1	29-11-12 P037-00/ /	ALL
D00616		BACS16X1A RELAY SOCKET-	81205	1	29-11-12 P037-00/ /	ALL
D00617		MB6R-3 RCPT-	09922	1	23-34-16 0915/205/R090	050-099
D00617		MB6R-3 RCPT-	09922	1	23-34-15 731/205/R090	150-199

EQUIPMENT LIST

D280T132

Section D00600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00617		MB6R-3 RCPT-	09922	1	23-34-15 0476/205/R090	275-278
D00617		MB6R-3 RCPT-	09922	1	23-34-15 0474/205/R090	280-299
D00617 T		KIT700-43 COAX CONTACT-	09922	1	23-34-16 / /	ALL
D00617 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-16 / /	050-099, 275-299
D00617 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-16 731/205/R090	150-199
D00618		BACS16X1A RELAY SOCKET-	81205	1	29-11-12 P037-00/ /	ALL
D00619		MB6R-3 RCPT-	09922	1	23-34-17 1005/198/L015	050-099
D00619		MB6R-3 RCPT-	09922	1	23-34-17 0596/198/L011	150-199, 275-299
D00619 T		KIT700-43 COAX CONTACT-	09922	1	23-34-15 / /	ALL
D00619 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-15 / /	ALL
D00621		MB6R-3 RCPT-	09922	1	23-34-14 0915/205/L090	050-099
D00621		MB6R-3 RCPT-	09922	1	23-34-16 0731/205/L090	150-199
D00621		MB6R-3 RCPT-	09922	1	23-34-16 0476/205/L090	275-278
D00621		MB6R-3 RCPT-	09922	1	23-34-16 0474/205/L090	280-299
D00621 T		KIT700-43 COAX CONTACT-	09922	1	23-34-14 / /	ALL
D00621 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-14 / /	ALL
D00624		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00600

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00628		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL
D00630		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL
D00631		MB6R-3 RCPT	09922	1	23-34-19 1153/195/L011	050-099
D00631		MB6R-3 RCPT	09922	1	23-34-19 1005/195/L011	150-199
D00631		MB6R-3 RCPT	09922	1	23-34-19 980/195/L011	275-278
D00631		MB6R-3 RCPT	09922	1	23-34-19 0980/195/L011	280-299
D00631 T		KIT700-43 COAX CONTACT-	09922	1	23-34-19 / /	ALL
D00631 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-19 / /	ALL
D00633		BACC45FT12A12S PLUG-	81205	1	22-14-11 P001-03/ /	ALL
D00635		BACC45FT12A12S PLUG-	81205	1	22-14-21 P003-01/ /	ALL
D00636		KPSE06F10-6S PLUG-P5	71468	1	25-63-11 P005-00/ /	ALL
D00638		BACC45FN14-15S RCPT-	81205	1	25-53-17 0569/120/R048	ALL
D00640		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D00641		BACC66H125C10AD01 PLUG-ARINC 600	81205	1	23-11-11 SHELF/E02/06	ALL
D00641A		PARTAOFD00641 PLUG-PART OF D00641		0	23-11-11 / /	ALL
D00641B		PARTBOFD00641 PLUG-PART OF D00641		0	23-11-11 / /	ALL
D00641BT		BACC47EN1 CONTACT-COAX,E2-6,HF-L	59610	1	23-11-11 SHELF/E02/06	ALL

EQUIPMENT LIST

D280T132

Section D00600

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00641C		PARTCOFD00641 PLUG-PART OF D00641		0	23-11-11 / /	ALL
D00642		CA270-8 PLUG-	71468	1	33-13-11 0167/257/0000	ALL
D00643		BACC66H125C10AD01 PLUG-ARINC 600	81205	1	23-11-21 SHELF/E02/06	ALL
D00643A		PARTAOFD00643 PLUG-PART OF D00643		0	23-11-21 / /	ALL
D00643B		PARTBOFD00643 PLUG-PART OF D00643		0	23-11-21 / /	ALL
D00643BT		BACC47EN1 CONTACT-COAX,E2-6,HF-R	59610	1	23-11-21 SHELF/E02/06	ALL
D00643C		PARTCOFD00643 PLUG-PART OF D00643		0	23-11-21 / /	ALL
D00644		BACC45FS10A5S8 PLUG-	81205	1	21-58-11 0387/120/L020	ALL
D00645		BACC45FT22A55S6 PLUG-	81205	1	34-22-81 P001-01/ /	ALL
D00646		BACC45FT14C7S PLUG-	81205	1	21-44-11 1358/172/L075	ALL
D00647		BACC45FT22A55S6 PLUG-	81205	1	34-22-91 P003-01/ /	ALL
D00648		BACC45FS10A5S8 PLUG-	81205	1	21-44-11 1251/123/L001	ALL
D00652		BACC45FT14A15S PLUG-	81205	1	21-58-12 0440/120/L020	050-099
D00652		BACC45FT14A15S PLUG-	81205	1	21-58-12 418/120/L020	150-199, 275-278
D00652		BACC45FT14A15S PLUG-	81205	1	21-58-12 440/120/L020	280-299
D00654		BACC45FT12A12S PLUG-	81205	1	21-58-13 0478/107/L010	ALL
D00660		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00600

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00665		BACC66H21C19AA01 PLUG-	81205	1	27-41-11 SHELF/E01/01	ALL
D00665A		PARTAOFD00665 PLUG-PART A OF D00665		0	27-41-11 //	ALL
D00665B		PARTBOFD00665 PLUG-PART B OF D00665		0	27-41-11 //	ALL
D00665C		PARTCOFD00665 PLUG-PART C OF D00665		0	27-41-11 //	ALL
D00666		BACS16X1A RELAY SOCKET-	81205	1	32-42-11 P037-00/	ALL
D00667		BACC66H21C19AA01 PLUG-	81205	1	27-41-21 SHELF/E02/01	ALL
D00667A		PARTAOFD00667 PLUG-PART A OF D00667		0	27-41-21 //	ALL
D00667B		PARTBOFD00667 PLUG-PART B OF D00667		0	27-41-21 //	ALL
D00667C		PARTCOFD00667 PLUG-PART C OF D00667		0	27-41-21 //	ALL
D00668	1	BACC63BP10C20SN PLUG-	13556	1	21-51-21 0810/123/R035	ALL
D00668	2	48-06R10-20S PLUG-	02660	1	21-51-21 0810/123/R035	ALL
D00668	3	CN0966-10A20SN-000 PLUG-	13556	1	21-51-21 0810/123/R035	ALL
D00668 T	1	BACC10KD10 CLAMP-	81205	1	21-51-21 //	ALL
D00668 T	2	BACC10GH10 CLAMP-	81205	1	21-51-21 //	ALL
D00670		CN0966-10A20SN-000 PLUG-	13556	1	21-51-11 0805/122/L027	ALL
D00670 T		BACC10KD10 CLAMP-	81205	1	21-51-11 //	ALL
D00674		BACC63BP16R24SNL PLUG-	81205	1	21-53-11 0839/121/L060	ALL

EQUIPMENT LIST

D280T132

Section D00600

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00674 T		BACC10KD16 CLAMP-	81205	1	21-53-11 / /	ALL
D00676		BACC63BP14R15SNL PLUG-	81205	1	21-53-11 0875/120/L045	ALL
D00676 T		BACC10KD14 CLAMP-	81205	1	21-53-11 / /	ALL
D00678		BACC63BP12R12SNL PLUG-	81205	1	21-53-11 0879/130/L040	ALL
D00678 T		BACC10KD12 CLAMP-	81205	1	21-53-11 / /	ALL
D00680		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0805/124/L030	275-299
D00680	1	BACC63BW12SC3S PLUG-	81205	1	21-52-31 0805/124/L030	050-099, 150-199
D00680	2	FH3406D PLUG-	28680	1	21-52-31 0805/124/L030	050-099, 150-199
D00680 T	2	BACC10GL12 CLAMP-	81205	1	21-52-31 / /	050-099, 150-199
D00682		BACC63BP16R24SNL PLUG-	81205	1	21-53-11 0935/119/L035	ALL
D00682 T		BACC10KD16 CLAMP-	81205	1	21-53-11 / /	ALL
D00688		CN0966-10A20SN-000 PLUG-	13556	1	21-51-12 0879/125/L040	ALL
D00688 T		BACC10KD10 CLAMP-	81205	1	21-51-12 / /	ALL
D00690		BACC45FN14-15S RCPT-	81205	1	25-53-17 0588/120/R048	ALL
D00692		BACS16X1A RELAY SOCKET-E6-1	81205	1	38-15-11 P049-00/ /	ALL
D00694		BACS16X1A RELAY SOCKET-E6-1	81205	1	21-44-11 P049-00/ /	ALL
D00695		PT06E-8-2S-SR- PLUG-	77820	1	27-32-11 0180/190/L015	ALL

EQUIPMENT LIST

D280T132

Section D00600

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00696		BACC63BP12R12SNL PLUG-	81205	1	21-52-41 0845/123/L060	ALL
D00696 T		BACC10KD12 CLAMP-	81205	1	21-52-41 / /	ALL
D00697		BACC45FT12A12S PLUG-	81205	1	31-51-31 0200/280/0000	ALL
D00698		BACC63BP14R15SNL PLUG-	81205	1	21-61-11 0823/113/L015	ALL
D00698 T		BACC10KD14 CLAMP-	81205	1	21-61-11 / /	ALL
D00699		BACC45FT12A12S PLUG-	81205	1	31-51-31 0200/280/R020	ALL

EQUIPMENT LIST

D280T132

Section D00600
Page 8 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00700		BACC63BP14R15SNL PLUG-	81205	1	21-61-31 0827/118/L015	050-099
D00700		BACC63BP14R15SNL PLUG-	81205	1	21-61-31 0823/120/L015	150-199, 275-299
D00700 T		BACC10KD14 CLAMP-	81205	1	21-61-31 / /	ALL
D00702		BACC63BP10R5S10L PLUG-	81205	1	21-61-51 0869/120/L010	050-099
D00702		BACC63BP10R5S6L PLUG-	81205	1	21-61-51 0869/120/L010	150-199, 275-299
D00702 T		BACC10KD10 CLAMP-	81205	1	21-61-51 / /	ALL
D00704		BACC45FT12B12S7 PLUG-	81205	1	21-31-11 1550/148/L049	ALL
D00706		BACC45FT14D7S PLUG-	81205	1	21-44-11 1358/180/L075	ALL
D00708		BACC45FS10A5S6 PLUG-	81205	1	21-44-11 1251/123/R001	ALL
D00710		BACC63BP14R15SNL PLUG-	81205	1	21-61-21 0823/129/L015	050-099
D00710		BACC63BP14R15SNL PLUG-	81205	1	21-61-21 0823/127/L015	150-199, 275-299
D00710 T		BACC10KD14 CLAMP-	81205	1	21-61-21 / /	ALL
D00711		BACC45FT18A31S PLUG-	81205	1	34-13-21 P003-01/ /	ALL
D00712		10-60450-5 RELAY SOCKET-	81205	1	38-15-11 P049-00/ /	ALL
D00715		BACC45FT20A41S PLUG-	81205	1	34-13-21 P003-03/ /	ALL
D00716		BACS16W3 RELAY SOCKET	81205	1	74-31-11 P011-00/ /	ALL
D00717	9	BACC45FT20A41S PLUG- (MTO 340652)	81205	1	34-22-92 P003-03/ /	150-152, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section D00700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00717		CUSTOMER PLUG-	81205	1	34-22-92 P003-03/ /	050-099, 153-154
D00718		BACC63BP16A24SNL PLUG-	81205	1	21-53-21 0836/121/R032	ALL
D00718 T		BACC10KD16 CLAMP-	81205	1	21-53-21 / /	ALL
D00719		BACC45FT16A24S PLUG-	81205	1	31-25-11 P003-03/ /	ALL
D00722		BACC63BP14A15SNL PLUG-	81205	1	21-53-21 0869/126/R043	ALL
D00722 T		BACC10KD14 CLAMP-	81205	1	21-53-21 / /	ALL
D00723		BACC63BN12C12S7 PLUG	81205	1	22-21-11 P005-00/ /	ALL
D00724		BACC63BP12R12SNL PLUG-	81205	1	21-53-21 0875/124/R043	ALL
D00724 T		BACC10KD12 CLAMP-	81205	1	21-53-21 / /	ALL
D00725		BACC45FT14A15S7 PLUG-	81205	1	22-21-21 P005-00/ /	ALL
D00726		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0807/126/R026	ALL
D00728		BACC63BP16A24SNL PLUG-	81205	1	21-53-21 0935/115/R043	ALL
D00728 T		BACC10KD16 CLAMPS-	81205	1	21-53-21 / /	ALL
D00731		KPSE06F20-41S PLUG-P5	71468	1	23-71-11 P005-00/ /	ALL
D00733		BACC45FT14A15S9 PLUG-	81205	1	23-11-11 P005-00/ /	ALL
D00734		BACC63BP12R12SNL PLUG-	81205	1	21-52-41 0870/123/R064	ALL
D00734 T		BACC10KD12 CLAMP-	81205	1	21-52-41 / /	ALL

EQUIPMENT LIST

D280T132

Section D00700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00735		BACC45FT22D55S PLUG-	81205	1	23-42-11 P005-00/ /	ALL
D00736	1	BACC63BP10C20SN PLUG-	13556	1	21-51-22 0890/124/R044	ALL
D00736	2	CN0966-10A20SN-000 PLUG-	13556	1	21-51-22 0890/124/R044	ALL
D00736 T		BACC10KD10 CLAMP-	81205	1	21-51-22 / /	ALL
D00737		BACC45FT14A15S9 PLUG-P5	81205	1	23-11-21 P005-00/ /	ALL
D00739		BACC45FT18A31S PLUG-IRS-L SEL PNL	81205	1	34-21-11 P005-00/ /	ALL
D00741		BACC45FT18D31S6 PLUG-IRS-R SEL PNL	81205	1	34-21-21 P005-00/ /	ALL
D00742		BACC63BP12B3SNL PLUG-STRUT	81205	1	30-21-11 NL180/160/L8 D	ALL
D00742 T		BACC10KB12 CLAMP-	81205	1	30-21-11 / /	ALL
D00743		BACC45FT18D31S7 PLUG-IRS-C, SEL PNL	81205	1	34-21-31 P005-00/ /	ALL
D00744		BACC45FT10D5S PLUG-	81205	1	21-31-11 1550/148/L049	050-099
D00744		BACC45FT10D5S PLUG-	81205	1	21-31-31 1550/148/L049	150-199, 275-299
D00745		BACC66H21C17AA01 PLUG-	81205	1	22-41-11 SHELF/E01/02	ALL
D00745A		PARTAOFD00745 PLUG-PART OF D00745		0	22-41-11 / /	ALL
D00745B		PARTBOFD00745 PLUG-PART OF D00745		0	22-41-11 / /	ALL
D00745C		PARTCOFD00745 PLUG-PART OF D00745		0	22-41-11 / /	ALL
D00746		BACC63BP10R5S10L PLUG-	81205	1	21-51-11 0852/123/L060	050-099

EQUIPMENT LIST

D280T132

Section D00700

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00746		BACC63BP10R5S8L PLUG-	81205	1	21-51-11 0852/123/L060	150-199, 275-299
D00746 T		BACC10KD10 CLAMP-	81205	1	21-51-11 / /	ALL
D00748		BACC63BP10R5S6L PLUG-	81205	1	21-51-11 0852/123/L060	ALL
D00748 T		BACC10KD10 CLAMP-	81205	1	21-51-11 / /	ALL
D00752		KPSE06F10-6S PLUG-	71468	1	35-11-13 0245/170/R060	ALL
D00754		BACC45FT12A12S PLUG-	81205	1	33-21-13 1002/294/L020	050-099
D00754		BACC45FT12A12S PLUG-	81205	1	33-21-13 0835/295/L020	150-199
D00754		BACC45FT12A12S PLUG-	81205	1	33-21-13 0916/294/L020	275-299
D00756		BACC45FT12A12S PLUG-	81205	1	33-21-14 1002/294/L020	050-099
D00756		BACC45FT12A12S PLUG-	81205	1	33-21-14 1004/295/L020	150-199, 275-299
D00758		BACC63BP12B3SNL PLUG-STRUT	81205	1	30-21-11 NL180/160/L008	ALL
D00758 T		BACC10KB12 CLAMP-	81205	1	30-21-11 / /	ALL
D00770		BACC66F11C23AA01 PLUG-	81205	1	21-61-11 SHELF/E03/01	ALL
D00770A		PARTAOFD00770 PLUG-PART OF D00770		0	21-61-31 / /	ALL
D00770B		PARTBOFD00770 PLUG-PART OF D00770		0	21-61-31 / /	ALL
D00770C		PARTCOFD00770 PLUG-PART OF D00770		0	21-61-51 / /	ALL
D00792		10-60450-5 RELAY SOCKET-	81205	1	30-11-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00700
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00800		BACS16W3 RELAY SOCKET	81205	1	74-31-11 P011-00/ /	ALL
D00803		BACC45FM14C7S RCPT-	81205	1	27-21-12 F 089/ /RS	ALL
D00805		BACC45FM14C7S RCPT-	81205	1	27-21-22 F 118/ /TE	ALL
D00807		DPXBMB-67-33S-0001 PLUG-P3-2	71468	1	34-22-24 P003-02/ /	ALL
D00807 T		233T2313-3 CONNECTOR PLATE ASSY	81205	1	34-22-24 / /	ALL
D00808		BACC45FT22A32S PLUG-	81205	1	33-26-11 0320/280/L060	050-099
D00808		BACC45FT22A32S PLUG-	81205	1	33-26-11 282/277/L056	150-199, 275-299
D00809		DPXBMB-67-33S-0002 PLUG-P3-2	71468	1	34-22-25 P003-02/ /	ALL
D00809 T		233T2313-1 CONNECTOR PLATE ASSY	81205	1	34-22-24 / /	ALL
D00810		BACC45FT22A32S PLUG-	81205	1	23-31-14 0839/278/L060	050-099
D00810		BACC45FT22A32S PLUG	81205	1	38-32-11 0654+121/ /L060	150-199
D00810		BACC45FT22A32S PLUG-	81205	1	33-26-11 0833/280/L060	275-299
D00811		DDMAF78S RCPT-	71468	1	31-51-12 0265/180/R036	ALL
D00812		BACC45FT22A32S PLUG	81205	1	23-31-14 0839/278/R050	050-099
D00812		BACC45FT22A32S PLUG-	81205	1	33-26-11 0654+121/280/R050	150-199
D00812		BACC45FT22A32S PLUG-	81205	1	33-26-11 0833/278/R060	275-299
D00813		DDMAF78S RCPT-	71468	1	31-51-12 0265/180/R036	ALL

EQUIPMENT LIST

D280T132

Section D00800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00814		BACC45FT22A32S PLUG-	81205	1	33-26-21 1446/280/L060	ALL
D00815		BACC65L66 RCPT-	81205	1	31-51-21 0265/180/R036	ALL
D00815 U		BACC47EM1 KEYING PLUG-	81205	2	31-51-21 / /	ALL
D00816		BACC45FT22A32S PLUG-	81205	1	33-26-21 1463/280/R050	050-099
D00816		BACC45FT22A32S PLUG-	81205	1	33-26-21 1442/280/R060	150-199
D00816		BACC45FT22A32S PLUG-	81205	1	33-26-21 1442/277/R058	275-299
D00817		BACC65L66 RCPT-	81205	1	31-51-32 0265/180/R036	ALL
D00817 U		BACC47EM1 KEYING PLUG-	81205	2	31-51-32 / /	ALL
D00818		BACC45FT12A12S PLUG-	81205	1	25-53-11 P024-00/ /	ALL
D00819		BACC65L66 RCPT-	81205	1	31-51-41 0265/160/R036	ALL
D00819 U		BACC47EM1 KEYING PLUG-	81205	2	31-51-41 / /	ALL
D00820		BACC45FS14C15S PLUG-	81205	1	25-53-11 P024-00/ /	050-099
D00820		BACC63BP14R15SNL PLUG-	81205	1	25-53-11 P024-00/ /	150-199, 275-299
D00820 T		BACC10KD14 CLAMP-	81205	1	25-53-11 / /	150-199, 275-299
D00821		BACC65L66 RCPT-	81205	1	34-16-11 0265/180/R036	ALL
D00821 U		BACC47EM1 KEYING PLUG-	81205	2	34-16-11 / /	ALL
D00822		BACC45FT12A12S PLUG-P27	81205	1	25-53-21 P027-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00823		BACC65L66 RCPT-	81205	1	27-32-11 0265/160/R034	ALL
D00823 U		BACC47EM1 KEYING PLUG-	81205	2	27-32-11 / /	ALL
D00824		BACC45FS14C15S PLUG-P27	81205	1	25-53-21 P027-00/ /	050-099
D00824		BACC63BP14R15SNL PLUG-P27	81205	1	25-53-21 P027-00/ /	150-199, 275-299
D00824 T		BACC10KD14 CLAMP-	81205	1	25-53-21 / /	150-199, 275-299
D00825		BACC66H21C20AA01 PLUG-	81205	1	27-61-11 SHELF/E01/01	ALL
D00825A		PARTAOFD00825 PLUG-PART A OF D00825		0	27-61-11 / /	ALL
D00825B		PARTBOFD00825 PLUG-PART B OF D00825		0	27-61-11 / /	ALL
D00825C		PARTCOFD00825 PLUG-PART C OF D00825		0	27-61-11 / /	ALL
D00827		BACC66H21C20AA01 PLUG-	81205	1	27-61-11 SHELF/E01/01	ALL
D00827A		PARTAOFD00827 PLUG-PART A OF D00827		0	27-61-11 / /	ALL
D00827B		PARTBOFD00827 PLUG-PART B OF D00827		0	27-61-11 / /	ALL
D00827C		PARTCOFD00827 PLUG-PART C OF D00827		0	27-61-11 / /	ALL
D00829		BACC66H21C20AA01 PLUG-	81205	1	27-61-11 SHELF/E01/01	ALL
D00829A		PARTAOFD00829 PLUG-PART A OF D00829		0	27-61-11 / /	ALL
D00829B		PARTBOFD00829 PLUG-PART B OF D00829		0	27-61-11 / /	ALL
D00829C		PARTCOFD00829 PLUG-PART C OF D00829		0	27-61-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D00800

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00831		BACC66H21C20AA01 PLUG-	81205	1	27-61-11 SHELF/E02/01	ALL
D00831A		PARTAOFD00831 PLUG-PART A OF D00831		0	27-61-11 //	ALL
D00831B		PARTBOFD00831 PLUG-PART B OF D00831		0	27-61-11 //	ALL
D00831C		PARTCOFD00831 PLUG-PART C OF D00831		0	27-61-11 //	ALL
D00832		BACC45FT14A12S8 PLUG-P5	81205	1	30-42-11 P005-00/	ALL
D00833		BACC66H21C20AA01 PLUG-	81205	1	27-61-17 SHELF/E02/01	ALL
D00833A		PARTAOFD00833 PLUG-PART A OF D00833		0	27-61-11 //	ALL
D00833B		PARTBOFD00833 PLUG-PART B OF D00833		0	27-61-11 //	ALL
D00833C		PARTCOFD00833 PLUG-PART C OF D00833		0	27-61-11 //	ALL
D00835		BACC66H21C20AA01 PLUG-	81205	1	27-61-18 SHELF/E02/01	ALL
D00835A		PARTAOFD00835 PLUG-PART A OF D00835		0	27-61-11 //	ALL
D00835B		PARTBOFD00835 PLUG-PART B OF D00835		0	27-61-11 //	ALL
D00835C		PARTCOFD00835 PLUG-PART C OF D00835		0	27-61-11 //	ALL
D00836		BACC45FT20A41S6 PLUG-	81205	1	26-11-11 P008-00/	ALL
D00837		BACC45FN16-24S RCPT-P21	81205	1	23-31-12 0280/240/L060	ALL
D00837P	9	CUSTOMER PLUG-P21	81205	1	23-31-11 P21/	050-099
D00838		BACC45FT12A12S7 PLUG-P5	81205	1	35-21-11 P005-00/	ALL

EQUIPMENT LIST

D280T132

Section D00800

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00840		BACC45FT14A15S6 PLUG-P5	81205	1	33-11-13 P005-00/ /	ALL
D00842		BACC45FT14A15S8 PLUG-P5	81205	1	33-13-17 P005-00/ /	ALL
D00846		BACC45FT20A41S7 PLUG-	81205	1	26-15-11 P008-00/ /	ALL
D00848		BACC45FT12A12S PLUG-P5	81205	1	74-31-11 P005-00/ /	ALL
D00849		XLR-5-13N RCPT-P8	71468	1	23-42-11 P008-00/ /	ALL
D00850		BACC45FT12A12S7 PLUG-P5	81205	1	74-31-21 P005-00/ /	ALL
D00851		XLR-5-31 RCPT-	71468	1	23-42-11 0835/243/R010	050-099
D00851		XLR-5-31 RCPT-	71468	1	23-42-11 0920/260/0000	150-199
D00851		XLR-5-31 RCPT-	71468	1	23-42-11 0801/243/L014	275-299
D00851 T		G62044 CLAMP	06324	1	23-42-11 / /	ALL
D00852		BACC45FT16A24S PLUG-P5	81205	1	74-31-21 P005-00/ /	ALL
D00853		XLR-5-31 RCPT-	71468	1	23-42-11 1537/243/R056	ALL
D00853 T		G62044 CLAMP	06324	1	23-42-11 / /	ALL
D00854		BACC45FT14A15S PLUG-P5	81205	1	33-24-11 P005-00/ /	ALL
D00855		XLR-5-31 RCPT-	71468	1	23-42-11 1537/260/L060	050-099
D00855		XLR-5-31 RCPT-	71468	1	23-42-11 1537/243/L060	150-199, 275-299
D00855 T		G62044 CLAMP	06324	1	23-42-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D00800

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00856		BACC45FT16A24S9 PLUG-P5	81205	1	33-42-11 P005-00/ /	ALL
D00857		BACC45FN10-5S PLUG-	81205	1	23-42-11 0360/280/R 60	050-099, 150-199
D00857		BACC45FN10-5S RCPT-	81205	1	23-42-11 AP0301B/ /	275-299
D00858		BACC45FT16A24S PLUG-P5	81205	1	33-41-11 P005-00/ /	ALL
D00859		XLR-5-31 RCPT-	71468	1	23-42-11 0284/240/L060	ALL
D00859 T		G62044 CLAMP	06324	1	23-42-11 / /	ALL
D00860		BACC45FT18D31S10 PLUG-P5	81205	1	33-16-11 P005-00/ /	ALL
D00861		XLR-4-31 RCPT-	71468	1	23-51-11 0172/207/L032	ALL
D00861 T		G62044 BACKSHELL	06324	1	23-51-11 0172/207/L032	ALL
D00862		BACC45FT20A41S PLUG-	81205	1	26-11-21 P008-00/ /	ALL
D00863		XLR-4-31 RCPT-	71468	1	23-51-21 0172/207/R032	ALL
D00863 T		G62044 BACKSHELL	06324	1	23-51-21 0172/207/R032	ALL
D00864		BACC45FT18A31S6 PLUG-	81205	1	26-11-11 P008-00/ /	ALL
D00866		BACC45FT18A31S7 PLUG-	81205	1	26-16-11 P008-00/ /	ALL
D00868		BACC45FT16A24S PLUG-P5	81205	1	33-51-11 P005-00/ /	ALL
D00869		BACC63BN12-12SN PLUG-P55	81205	1	34-55-11 P055-00/ /	050-099
D00869		BACC63BN12C12SN PLUG-P55	81205	1	34-55-11 P055-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D00800

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00869 T		BACC10GH12 CLAMP-	81205	1	34-55-11 / /	050-099
D00871		BACC63BN12-12SN PLUG-P55	81205	1	34-51-21 P055-00/ /	ALL
D00871 T		BACC10KD12 CLAMP-	81205	1	34-51-21 / /	ALL
D00872		WB1240 PLUG-	81323	1	30-41-12 0212/268/L060	ALL
D00872 T		0712 CAP-	81323	1	30-41-12 / /	ALL
D00874	9	BACC45FT18D31S9 PLUG-P5 (SB 25-0325)	81205	1	33-16-11 P005-00/ /	151, 162, 166-199
D00874	9	BACC45FT18D31S9 PLUG-P5 (SB 25-0325)	81205	1	33-16-11 / /	152, 154, 276-299
D00874	9	BACC45FT18D31S9 PLUG-P5	81205	1	33-16-11 P005-00/ /	156
D00874	9	BACC45FT18D31S9 PLUG-P5 (SB 25-0332)	81205	1	33-16-11 / /	275
D00874		BACC45FT18D31S8 PLUG-P5	81205	1	33-16-11 P005-00/ /	050-099, 150-151, 153, 155, 157, 163- 165
D00875		BACC65L114 PLUG-	81205	1	31-41-17 SHELF/E08/	ALL
D00876		BACC45FT18A31S9 PLUG-P5	81205	1	30-41-11 P005-00/ /	ALL
D00877		BACC65L114 PLUG-	81205	1	31-41-17 SHELF/E08/	ALL
D00878		BACC45FT20A41S7 PLUG-P5	81205	1	30-41-12 P005-00/ /	ALL
D00881		BACC66K33C54AA01 PLUG-	81205	1	31-41-12 SHELF/E08/01	ALL
D00881A		PARTAOFD00881 PLUG-PART A OF D00881		0	31-41-12 / /	ALL

EQUIPMENT LIST

D280T132

Section D00800

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00881B		PARTBOFD00881 PLUG-PART B OF D00881		0	31-41-12 //	ALL
D00881C		PARTCOFD00881 PLUG-PART C OF D00881		0	31-41-12 //	ALL
D00881D		PARTDOFD00881 PLUG-PART D OF D00881		0	31-41-12 //	ALL
D00881E		PARTEOFD00881 PLUG-PART E OF D00881		0	31-41-12 //	ALL
D00881F		PARTFOFD00881 PLUG-PART F OF D00881		0	31-41-12 //	ALL
D00883		BACC66K33C54AA01 PLUG-	81205	1	31-41-12 SHELF/E08/02	ALL
D00883A		PARTAOFD00883 PLUG-PART A OF D00883		0	31-41-12 //	ALL
D00883B		PARTBOFD00883 PLUG-PART B OF D00883		0	31-41-12 //	ALL
D00883C		PARTCOFD00883 PLUG-PART C OF D00883		0	31-41-12 //	ALL
D00883D		PARTDOFD00883 PLUG-PART D OF D00883		0	31-41-12 //	ALL
D00883E		PARTEOFD00883 PLUG-PART E OF D00883		0	31-41-12 //	ALL
D00883F		PARTFOFD00883 PLUG-PART F OF D00883		1	31-41-12 //	ALL
D00884		BACC45FT14A12S6 PLUG-P5	81205	1	30-42-11 P005-00/ /	ALL
D00886		BACC45FT12A12S6 PLUG-P5	81205	1	74-31-11 P005-00/ /	ALL
D00888		BACC45FT16A24S9 PLUG-P5	81205	1	30-21-11 P005-00/ /	050-099, 150-199
D00888		BACC45FT14A15S PLUG-P5	81205	1	30-21-11 P005-00/ /	275-299
D00888 U		289T0181-10301 M/W TAPE- TEXT AS BELOW	81205	1	30-21-11 //	150-154

EQUIPMENT LIST

D280T132

Section D00800

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00890		BACC45FT16A24S8 PLUG-P5	81205	1	30-21-11 P005-00/ /	050-099, 150-199
D00890		BACC45FT14A15S7 PLUG-P5	81205	1	30-21-11 P005-00/ /	275-299
D00890 U		289T0181-10401 M/W TAPE- TEXT AS BELOW	81205	1	30-21-11 / /	150-154
D00892		WB1240 PLUG-	81323	1	30-41-11 0212/268/R060	ALL
D00892 T		0712 CAP-	81323	1	30-41-11 / /	ALL
D00894		BACC45FT22-19S PLUG-	81205	1	24-51-42 P006-00/ /	ALL
D00896		BACC45FT12A12S PLUG-P5	81205	1	33-13-16 P005-00/ /	ALL
D00898		BACC45FT12A12S PLUG-P5	81205	1	33-13-16 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D00800

Page 9 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00904		BACC63CE32-17S RCPT-F1	81205	1	25-31-11 360/280/R060	050-099
D00904		BACC63CE32-17S PLUG-F3	81205	1	25-31-11 360/280/R060	150-199
D00904		BACC63CD32-17S RCPT-F1 GALLEY	81205	1	25-31-11 264/283/R055	275-278
D00904		BACC63CD32-17S RCPT-F1 GALLEY	81205	1	25-31-11 260/280/R055	280-299
D00906		BACC45FS14-15S PLUG-F1	81205	1	25-31-11 0355/279/R060	050-099
D00906		BACC45FS14-15S PLUG-F1	81205	1	25-31-11 0360/280/R060	150-199
D00906		BACC45FN12-12S RCPT-F1 GALLEY	81205	1	25-31-11 0264/283/R055	275-278
D00906		BACC45FN12-12S RCPT-F1 GALLEY	81205	1	25-31-11 0260/280/R055	280-299
D00910		BACC45FN10-5S RCPT-	81205	1	25-11-11 0172/208/L034	ALL
D00912		BACC45FN10-5S RCPT-	81205	1	25-11-21 0172/208/R034	ALL
D00914		BACS16W1 RELAY SOCKET-	81205	1	30-11-11 P033-00/ /	ALL
D00916		BACC63BP12R3SNL PLUG-	81205	1	29-11-12 NL255/155/	ALL
D00916 T		BACC10KD12 CLAMP-	81205	1	29-11-12 / /	ALL
D00918		BACC63BP12R3SNL PLUG-	81205	1	29-11-31 0999/145/R005	ALL
D00918 T		710AA011M1209-62A ADAPTER-90 DEGREE	06324	1	29-11-31 / /	ALL
D00920		BACC63BP12R3SNL PLUG-	81205	1	29-11-31 1043/145/R005	ALL
D00920 T		710AA011M1209-62A ADAPTER-90 DEGREES	06324	1	29-11-31 / /	ALL

EQUIPMENT LIST

D280T132

Section D00900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00922		BACC63BP12R3SNL PLUG-	81205	1	29-11-22 NR265/155/	ALL
D00922 T		BACC10KD12 CLAMP-	81205	1	29-11-22 / /	ALL
D00926		BACC45FT12A12S PLUG-	81205	1	33-21-35 0967/288/R056	275-299
D00928		BACC45FT14B7S PLUG-	81205	1	27-58-21 P036-00/ /	ALL
D00930		BACS16X3A RELAY SOCKET-	81205	1	28-22-11 P033-00/ /	ALL
D00934		BACC45FN8-2S RCPT-	81205	1	35-21-12 0262/287/L070	ALL
D00936		BACC45FN8-2S RCPT-	81205	1	35-21-12 0298/280/L035	ALL
D00938		BACC45FN8-2S RCPT-	81205	1	35-21-12 345/280/L048	280-299
D00940		BACC45FN8-2S RCPT-	81205	1	35-21-12 0397/270/L075	275-278
D00940		BACC45FN8-2S RCPT-	81205	1	35-21-12 0398/270/L073	280-299
D00942		35303-68 PLUG-	73168	1	26-17-11 AL1011/ /	ALL
D00944		35303-68 PLUG-	73168	1	26-17-11 AL1011/ /	ALL
D00946		35303-64 PLUG-	73168	1	26-17-11 1021/185/R050	050-099
D00946		35303-68 PLUG-	73168	1	26-17-11 1021/185/R050	150-199, 275-299
D00948		35303-64 PLUG-	73168	1	26-17-11 1021/185/R050	050-099
D00948		35303-68 PLUG-	73168	1	26-17-11 1021/185/R050	150-199, 275-299
D00952		BACC45FN8-2S RCPT-	81205	1	35-21-13 0375/270/R073	275-278

EQUIPMENT LIST

D280T132

Section D00900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00952		BACC45FN8-2S RCPT-	81205	1	35-21-13 0395/270/R073	280-299
D00958		BACC66F11C16AA01 PLUG-E3-1-ARINC-600	81205	1	21-51-12 SHELF/E03/01	050-099, 150-156, 162-166, 275-276
D00958		BACC66F11C88AA01 PLUG-E3-1-ARINC-600	81205	1	21-51-12 SHELF/E03/01	157, 167-199, 277- 299
D00958A		PARTAOFD00958 PLUG-PART OF D00958		0	21-51-12 / /	ALL
D00958B		PARTBOFD00958 PLUG-PART OF D00958		0	21-51-12 / /	ALL
D00958C		PARTCOFD00958 PLUG-PART OF D00958		0	21-53-11 / /	ALL
D00964		BACC45FS10A5S6 PLUG-	81205	1	35-21-11 0395/305/L030	ALL
D00976		BACS16W1 RELAY SOCKET-	81205	1	21-44-21 P037-00/ /	ALL
D00978		BACC45FN8-2S RCPT-	81205	1	35-21-14 659/280/L005	050-099
D00978		BACC45FN8-2S RCPT-	81205	1	35-21-14 0654+011/280/L005	150-199
D00978		BACC45FN8-2S RCPT-	81205	1	35-21-14 0654+006/280/L005	275-299
D00980		BACC45FN8-2S RCPT-	81205	1	35-21-14 690/280/L005	050-099
D00980		BACC45FN8-2S RCPT-	81205	1	35-21-14 0654+040/280/L005	150-199
D00980		BACC45FN8-2S RCPT-	81205	1	35-21-14 0654+037/280/L005	275-299
D00982		BACC45FN8-2S RCPT-	81205	1	35-21-14 0845/280/L002	150-199
D00982		BACC45FN8-2S RCPT-	81205	1	35-21-14 0852/280/L002	275-299
D00984		BACC45FN8-2S RCPT-	81205	1	35-21-14 0870/280/L005	050-099

EQUIPMENT LIST

D280T132

Section D00900

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D00984		BACC45FN8-2S RCPT-	81205	1	35-21-14 870/280/L005	150-199
D00984		BACC45FN8-2S RCPT-	81205	1	35-21-14 AP0703/280/L5	275-278
D00984		BACC45FN8-2S RCPT-	81205	1	35-21-14 0883/280/L005	280-299
D00986		BACC45FN8-2S RCPT-	81205	1	35-21-14 0917/280/L005	050-099, 275-299
D00998		BACS16X1A RELAY SOCKET-P49	81205	1	24-32-41 P049-00/ /	275-299

EQUIPMENT LIST

D280T132

Section D00900

Page 4 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01000		10-60450-5 RELAY SOCKET-P49	81205	1	24-32-41 P049-00/ /	275-299
D01002		BACC45FN8-2S RCPT-	81205	1	35-21-13 429/270/R073	150-157
D01002		BACC45FN8-2S RCPT-	81205	1	35-21-13 0405/270/R073	275-299
D01004		BACC45FN8-2S RCPT-	81205	1	35-21-13 0727/270/R073	050-099
D01004		BACC45FN8-2S RCPT-	81205	1	35-21-13 0737/270/R073	150-199
D01004		BACC45FN8-2S RCPT-	81205	1	35-21-13 0712/270/R073	275-278
D01004		BACC45FN8-2S RCPT-	81205	1	35-21-13 0714/270/R073	280-299
D01006		000300-1560 RELAY SOCKET-P37	05574	1	21-44-21 P037-00/ /	ALL
D01008		BACS16X1A RELAY SOCKET-P49	81205	1	24-32-41 P049-00/ /	275-299
D01010	1	BACC63BW10SL-4S PLUG-	81205	1	30-31-11 0200/212/L069	ALL
D01010	2	BACC63CE10SL-4S PLUG-	81205	1	30-31-11 0200/212/L069	ALL
D01010 T	1	BACC10GL12 CLAMP-	81205	1	30-31-11 / /	ALL
D01010 T	2	BACC10HV12 CLAMP-	81205	1	30-31-11 / /	ALL
D01012		BACC63BW10SLC4S PLUG	81205	1	30-31-23 0201/182/L068	050-099, 155-157, 165-199, 277-299
D01012		BACC63BW10SL-4S PLUG	81205	1	30-31-23 0201/182/L068	150-154, 162-164, 275-276
D01018		BACC45FN8-2S RCPT-	81205	1	35-21-12 1146/270/L073	050-099
D01018		BACC45FN8-2S RCPT-	81205	1	35-21-12 1159/270/L073	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D01000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01020		BACC45FN8-2S RCPT-	81205	1	35-21-12 1175/270/L073	050-099
D01020		BACC45FN8-2S RCPT-	81205	1	35-21-12 1189/270/L073	150-199, 275-299
D01022		BACC45FN8-2S RCPT-	81205	1	35-21-12 1204/270/L073	ALL
D01024		BACC45FN8-2S RCPT-	81205	1	35-21-12 1234/270/L073	ALL
D01026		BACC45FN8-2S RCPT-	81205	1	35-21-12 1263/270/L073	ALL
D01028		BACC45FN8-2S RCPT-	81205	1	35-21-12 1292/270/L073	ALL
D01030		BACC45FN8-2S RCPT-	81205	1	35-21-12 1322/270/L073	ALL
D01032		BACC45FN8-2S RCPT-	81205	1	35-21-12 1351/270/L073	ALL
D01034		BACC45FN8-2S RCPT-	81205	1	35-21-12 1380/270/L073	ALL
D01036		BACC45FN8-2S RCPT-	81205	1	35-21-12 1406/270/L073	050-099
D01036		BACC45FN8-2S RCPT-	81205	1	35-21-12 1410/270/L073	150-199, 275-299
D01038		BACC45FN8-2S RCPT-	81205	1	35-21-12 1436/270/L073	050-099
D01038		BACC45FN8-2S RCPT-	81205	1	35-21-12 1428/270/L073	150-199, 275-299
D01040		BACC45FN8-2S RCPT-	81205	1	35-21-12 1506/280/L030	150-199, 275-299
D01042		BACC45FN8-2S RCPT-	81205	1	35-21-14 1025/280/L005	ALL
D01044		BACC45FN8-2S RCPT-	81205	1	35-21-12 0434/270/L075	050-099
D01044		BACC45FN8-2S RCPT-	81205	1	35-21-12 0444/270/L075	150-199

EQUIPMENT LIST

D280T132

Section D01000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01044		BACC45FN8-2S RCPT-	81205	1	35-21-12 456/270/L075	275-278
D01044		BACC45FN8-2S RCPT-	81205	1	35-21-12 445/270/L073	280-299
D01046		BACC45FN8-2S RCPT-	81205	1	35-21-13 0463/270/R073	ALL
D01048		BACC45FN8-2S RCPT-	81205	1	35-21-13 0493/270/R073	ALL
D01050		BACC45FN8-2S RCPT-	81205	1	35-21-13 0522/270/R073	ALL
D01052		BACC45FN8-2S RCPT-	81205	1	35-21-13 0551/270/R073	ALL
D01054		BACC45FN8-2S RCPT-	81205	1	35-21-13 0581/270/R073	ALL
D01056		BACC45FN8-2S RCPT-	81205	1	35-21-13 0610/270/R073	ALL
D01058		BACC45FN8-2S RCPT-	81205	1	35-21-13 0639/270/R073	050-099, 150-199, 275-278
D01058		BACC45FN8-2S RCPT-	81205	1	35-21-13 0630/270/R073	280-299
D01060		BACC45FN8-2S RCPT-	81205	1	35-21-13 0669/270/R073	050-099
D01060		BACC45FN8-2S RCPT-	81205	1	35-21-13 0656/270/R073	275-278
D01060		BACC45FN8-2S RCPT-	81205	1	35-21-13 0665/270/R073	280-299
D01062		BACC45FN8-2S RCPT-	81205	1	35-21-13 0698/270/R073	050-099
D01062		BACC45FN8-2S RCPT-	81205	1	35-21-13 0700/270/R073	150-199
D01062		BACC45FN8-2S RCPT-	81205	1	35-21-13 0682/270/R073	275-278
D01062		BACC45FN8-2S RCPT-	81205	1	35-21-13 0684/270/R073	280-299

EQUIPMENT LIST

D280T132

Section D01000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01067E	9	DBM5W5SA197 PLUG	81205	1	25-25-23 270/ /	150, 153, 157, 165- 199
D01067F	9	DBU-25P-K87-F0 PLUG	81205	1	25-25-23 270/ /	150, 153, 157, 165- 199
D01068		BACC45FT12A12S PLUG-P5	81205	1	21-61-31 P005-00/ /	ALL
D01074		BACS16X3A RELAY SOCKET-P49	81205	1	24-32-41 P049-00/ /	275-299
D01076		MS3106E24-11S PLUG-E6	96906	1	24-32-41 P049-00/ /	275-276
D01076		BACC63CE24A11S PLUG-E6	96906	1	24-32-41 P049-00/ /	277-299
D01080		BACC45FT16B24S PLUG-	81205	1	33-51-21 0577/203/L092	050-099
D01080		BACC45FT16A24S PLUG-	81205	1	33-51-21 0511/203/L092	150-199
D01080		BACC45FT16A24S PLUG-	81205	1	33-51-21 0467/203/L092	275-299
D01082		BACC45FT16A24S PLUG-	81205	1	25-65-11 0880/208/R090	050-099
D01082		BACC45FT16A24S PLUG-	81205	1	25-65-11 1032/208/R90	150-199
D01082		BACC45FT16A24S PLUG-	81205	1	25-65-11 0966/210/R080	275-299
D01084		BACC45FT16A24S PLUG-	81205	1	33-51-13 0511/203/L092	050-099
D01084		BACC45FT16A24S PLUG-	81205	1	33-51-13 0489/203/L092	150-199
D01084		BACC45FT16A24S PLUG-	81205	1	33-51-13 0445/203/L092	275-299
D01086		BACC45FT16A24S PLUG-	81205	1	25-65-11 0880/208/L090	050-099
D01086		BACC45FT16A24S PLUG-	81205	1	25-65-11 1010/208/L090	150-199

EQUIPMENT LIST

D280T132

Section D01000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01086		BACC45FT16A24S PLUG-	81205	1	25-65-11 0975/210/L090	275-299
D01088		BACC45FT16A24S PLUG-	81205	1	33-51-13 0922/203/L092	050-099
D01088		BACC45FT16A24S PLUG-	81205	1	33-51-13 1032/203/L092	150-199
D01088		BACC45FT16A24S PLUG-	81205	1	33-51-13 0988/203/L092	275-299
D01090		BACS16X1A RELAY SOCKET-	81205	1	28-21-12 P036-00/ /	ALL
D01094		BACC45FN8-2S RCPT-	81205	1	35-21-13 0757/270/R073	050-099
D01094		BACC45FN8-2S RCPT-	81205	1	35-21-13 0742/270/R073	275-278
D01094		BACC45FN8-2S RCPT-	81205	1	35-21-13 0743/270/R073	280-299
D01096		BACC45FN8-2S RCPT-	81205	1	35-21-13 0787/270/R073	050-099
D01096		BACC45FN8-2S RCPT-	81205	1	35-21-13 0798/270/R073	150-199, 275-278
D01096		BACC45FN8-2S RCPT-	81205	1	35-21-13 0800/270/R073	280-299
D01098		BACC45FN8-2S RCPT-	81205	1	35-21-13 830/270/R073	150-199

EQUIPMENT LIST

D280T132

Section D01000
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01100		BACC45FN8-2S RCPT-	81205	1	35-21-13 0840/270/R073	050-099
D01100		BACC45FN8-2S RCPT-	81205	1	35-21-13 0845/270/R073	275-299
D01102		BACC45FN8-2S RCPT-	81205	1	35-21-13 0875/270/R073	ALL
D01104		BACC45FN8-2S RCPT-	81205	1	35-21-13 0893/270/R073	050-099
D01104		BACC45FN8-2S RCPT-	81205	1	35-21-13 0896/270/R073	150-199, 275-299
D01106		BACC45FN8-2S RCPT-	81205	1	35-21-13 0926/270/R073	ALL
D01108		BACC45FN8-2S RCPT-	81205	1	35-21-13 0940/270/R073	050-099
D01108		BACC45FN8-2S RCPT-	81205	1	35-21-13 969/270/R073	150-199
D01108		BACC45FN8-2S RCPT-	81205	1	35-21-13 0955/270/R073	275-299
D01110		BACC45FN8-2S RCPT-	81205	1	35-21-13 0970/270/R073	050-099
D01110		BACC45FN8-2S RCPT-	81205	1	35-21-13 0983/270/R073	275-299
D01112		BACC45FN8-2S RCPT-	81205	1	35-21-13 0999/279/R073	050-099
D01112		BACC45FN8-2S RCPT-	81205	1	35-21-13 1013/270/R073	150-199, 275-299
D01114		BACC45FN8-2S RCPT-	81205	1	35-21-12 1043/270/L073	275-299
D01116		BACC45FN8-2S RCPT-	81205	1	35-21-12 1047/270/L073	050-099
D01116		BACC45FN8-2S RCPT-	81205	1	35-21-12 1071/270/L073	150-199, 275-299
D01118		BACC45FN8-2S RCPT-	81205	1	35-21-12 1097/270/L073	050-099

EQUIPMENT LIST

D280T132

Section D01100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01118		BACC45FN8-2S RCPT-	81205	1	35-21-12 1101/270/L073	150-199, 275-299
D01120		BACC45FN8-2S RCPT-	81205	1	35-21-12 1116/270/L073	050-099
D01120		BACC45FN8-2S RCPT-	81205	1	35-21-12 1131/270/L073	150-199, 275-299
D01122		BACC45FT16A24S PLUG-	81205	1	33-51-21 0555/203/R092	050-099
D01122		BACC45FT16A24S PLUG-	81205	1	33-51-21 0555/206/R090	150-199
D01122		BACC45FT16A24S PLUG-	81205	1	33-51-21 0423/206/R090	275-299
D01124		BACC63BP14A7SNL PLUG-	81205	1	25-65-11 L0330/14/ET	ALL
D01124 T		BACC10KD14 CLAMP	81205	1	25-65-11 / /	ALL
D01126		BACC45FT16A24S PLUG-	81205	1	33-51-12 1010/203/R092	ALL
D01128		KPSE06F10-6S PLUG-	71468	1	25-65-11 1153/170/R080	ALL
D01130		KPSE06F10-6S PLUG-	71468	1	25-65-11 1153/170/L080	ALL
D01134		BACC45FN8-2S RCPT-	81205	1	35-21-12 0463/270/L075	050-099, 150-199, 275-278
D01134		BACC45FN8-2S RCPT-	81205	1	35-21-12 0464/270/L073	280-299
D01136		BACC45FT8B3S PLUG-	81205	1	26-16-21 0352/184/L067	ALL
D01138		BACC45FT8D3S PLUG-	81205	1	26-16-21 352/163/L067	ALL
D01140		BACC45FT8D3S PLUG-	81205	1	26-16-21 1406/137/L071	ALL
D01142		BACC45FT8D3S PLUG-	81205	1	26-16-21 1406/137/L071	ALL

EQUIPMENT LIST

D280T132

Section D01100
Page 2
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01144		BACC45FN8-2S RCPT-	81205	1	35-21-12 0610/270/L075	050-099, 150-199, 275-278
D01144		BACC45FN8-2S RCPT-	81205	1	35-21-12 0611/270/L073	280-299
D01146		BACC45FN8-2S RCPT-	81205	1	35-21-12 0639/270/L075	050-099, 150-199, 275-278
D01146		BACC45FN8-2S RCPT-	81205	1	35-21-12 0640/270/L073	280-299
D01148		BACC45FN8-2S RCPT-	81205	1	35-21-12 0669/270/L075	050-099
D01148		BACC45FN8-2S RCPT-	81205	1	35-21-12 0656/270/L075	275-278
D01148		BACC45FN8-2S RCPT-	81205	1	35-21-12 0666/270/L073	280-299
D01150		BACC45FN8-2S RCPT-	81205	1	35-21-12 0698/270/L075	050-099
D01150		BACC45FN8-2S RCPT-	81205	1	35-21-12 0700/270/L075	150-199
D01150		BACC45FN8-2S RCPT-	81205	1	35-21-12 0682/270/L073	275-299
D01152		BACC45FN8-2S RCPT-	81205	1	35-21-12 0727/270/L075	050-099
D01152		BACC45FN8-2S RCPT-	81205	1	35-21-12 0737/270/L075	150-199
D01152		BACC45FN8-2S RCPT-	81205	1	35-21-12 0712/270/L073	275-278
D01152		BACC45FN8-2S RCPT-	81205	1	35-21-12 0714/270/L073	280-299
D01154		BACC45FN8-2S RCPT-	81205	1	35-21-12 0757/270/L075	050-099
D01154		BACC45FN8-2S RCPT-	81205	1	35-21-12 0742/270/L073	275-278
D01154		BACC45FN8-2S RCPT-	81205	1	35-21-12 0743/270/L073	280-299

EQUIPMENT LIST

D280T132

Section D01100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01156		BACC45FN8-2S RCPT-	81205	1	35-21-12 0786/270/L075	050-099
D01156		BACC45FN8-2S RCPT-	81205	1	35-21-12 801/270/L073	150-199
D01156		BACC45FN8-2S RCPT-	81205	1	35-21-12 0797/270/L073	275-278
D01156		BACC45FN8-2S RCPT-	81205	1	35-21-12 0800/270/L073	280-299
D01158		BACC45FN8-2S RCPT-	81205	1	35-21-12 830/270/L073	150-199
D01160		BACC45FN8-2S RCPT-	81205	1	35-21-12 0840/270/L075	050-099
D01160		BACC45FN8-2S RCPT-	81205	1	35-21-12 0845/270/L073	275-299
D01162		BACC63BN14C7SN PLUG-	81205	1	36-11-11 0946/127/L065	ALL
D01164		BACC45FT12A12S PLUG-P61	81205	1	25-65-11 P061-00/ /	ALL
D01166		BACC63BP14A7SNL PLUG-	81205	1	25-65-12 R0344/12/TE	ALL
D01166 T		BACC10KD14 CLAMP-	81205	1	25-65-12 / /	ALL
D01172		BACS16X1A RELAY SOCKET-P36	81205	1	32-42-11 P036-00/ /	ALL
D01174		BACC66F11C19AA01 PLUG-E3-1	81205	1	21-52-41 SHELF/E03/01	ALL
D01174A		PARTAOFD01174 PLUG-PART OF D01174		0	21-52-41 / /	ALL
D01174B		PARTBOFD01174 PLUG-PART OF D01174		0	21-52-41 / /	ALL
D01174C		PARTCOFD01174 PLUG-PART OF D01174		0	21-52-41 / /	ALL
D01176		BACC45FN18-31S RCPT-	81205	1	38-14-11 P022-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D01100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01176		BACC45FN16-24S RCPT-P22	81205	1	38-14-11 P022-00/ /	150-154
D01176		BACC45FN18-31S RCPT-P22	81205	1	38-14-11 P022-00/ /	155-199, 275-299
D01178		BACS16AF1 RELAY SOCKET-	81205	1	26-17-11 P037-00/ /	ALL
D01180		BACC45FN8-2S RCPT-	81205	1	35-21-12 0875/270/L075	050-099
D01180		BACC45FN8-2S RCPT-	81205	1	35-21-12 859/270/L073	150-199
D01180		BACC45FN8-2S RCPT-	81205	1	35-21-12 0875/270/L073	275-299
D01182		BACC45FN8-2S RCPT-	81205	1	35-21-12 0893/270/L075	050-099
D01182		BACC45FN8-2S RCPT-	81205	1	35-21-12 889/270/L073	150-199
D01182		BACC45FN8-2S RCPT-	81205	1	35-21-12 0896/270/L073	275-299
D01184		BACC45FN8-2S RCPT-	81205	1	35-21-12 0926/270/L075	050-099
D01184		BACC45FN8-2S RCPT-	81205	1	35-21-12 919/270/L073	150-199
D01184		BACC45FN8-2S RCPT-	81205	1	35-21-12 0926/270/L073	275-299
D01186		BACC45FN8-2S RCPT-	81205	1	35-21-12 0940/270/L075	050-099
D01186		BACC45FN8-2S RCPT-	81205	1	35-21-12 969/270/L073	150-199
D01186		BACC45FN8-2S RCPT-	81205	1	35-21-12 0955/270/L073	275-299
D01188		BACC45FN8-2S RCPT-	81205	1	35-21-12 0970/270/L075	050-099
D01188		BACC45FN8-2S RCPT-	81205	1	35-21-12 0983/270/L073	275-299

EQUIPMENT LIST

D280T132

Section D01100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01190		BACC45FN8-2S RCPT-	81205	1	35-21-12 0999/270/L075	050-099
D01190		BACC45FN8-2S RCPT-	81205	1	35-21-12 1007/270/L073	150-199
D01190		BACC45FN8-2S RCPT-	81205	1	35-21-12 1013/270/L073	275-299
D01192		BACC45FN8-2S RCPT-	81205	1	35-21-14 0396/280/L005	ALL
D01194		BACC45FN8-2S RCPT-	81205	1	35-21-14 0427/280/L005	ALL
D01196		BACC45FN8-2S RCPT-	81205	1	35-21-14 0453/280/L005	ALL
D01198		BACC45FN8-2S RCPT-	81205	1	35-21-14 0480/280/L005	ALL

EQUIPMENT LIST

D280T132

Section D01100
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01200		BACC45FN8-2S RCPT-	81205	1	35-21-14 0504/280/L005	ALL
D01202		BACC45FN8-2S RCPT-	81205	1	35-21-14 0528/280/L005	ALL
D01204		BACC45FN8-2S RCPT-	81205	1	35-21-14 0559/280/L005	ALL
D01205		280T1000-1 RECP-MOA PER DWG REF BACC45FN20-28S	81205	1	23-32-11 AP0002/ /	050-099, 150-199
D01206		BACC45FN8-2S RCPT-	81205	1	35-21-14 0585/280/L005	ALL
D01207		280T1000-2 RECP-MOA PER DWG REF BACC45FN20-28S6	81205	1	23-32-13 AP0002/ /	050-099, 150-199
D01208		BACC45FN8-2S RCPT-	81205	1	35-21-14 0612/280/L005	ALL
D01209		280T1000-9 RECP-MOA PER DWG REF BACC45FN20-28S7	81205	1	23-32-12 AP0002/250/R009	050-099, 150-199
D01210		BACC45FN8-2S RCPT-	81205	1	35-21-14 636/280/L005	050-099
D01210		BACC45FN8-2S RCPT-	81205	1	35-21-14 0636/280/L005	150-199, 275-299
D01212		BACC45FN14-12S RCPT-	81205	1	25-53-14 0403/122/L029	ALL
D01214		BACC45FN14-12S RCPT-	81205	1	25-53-14 0403/122/R029	ALL
D01216		BACC45FN14-12S RCPT-	81205	1	25-53-14 0442/122/L029	050-099
D01216		BACC45FN14-12S RCPT-	81205	1	25-53-12 706/122/L029	150-199, 275-299
D01218		BACC45FN14-12S RCPT-	81205	1	25-53-14 0442/122/R029	050-099
D01218		BACC45FN14-12S RCPT-	81205	1	25-53-12 0442/122/R029	150-199, 275-299
D01219		KA-59-392-M06 PLUG-COAXIAL	91836	1	23-32-13 FIN 295/ /	050-099, 150-154, 162-164, 275-276

EQUIPMENT LIST

D280T132

Section D01200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01219		KA-59-277 PLUG-COAXIAL	91836	1	23-32-13 FIN 295/ /	155-157, 165-199, 277-299
D01220		BACC45FN14-12S RCPT-	81205	1	25-53-14 0517/122/R009	050-099
D01220		BACC45FN14-12S RCPT-	81205	1	25-53-12 0474/122/L029	150-199, 275-299
D01221		BACC63BP10R5SNL PLUG-	81205	1	23-32-13 F 295/ /0000	ALL
D01221 T		BACC10KD10 CLAMP-	81205	1	23-32-13 / /	ALL
D01222		BACC45FN14-12S RCPT-	81205	1	25-53-14 0474/122/R029	050-099
D01222		BACC45FN14-12S RCPT-	81205	1	25-53-12 0474/122/R029	150-199, 275-299
D01224		BACC45FN14-12S RCPT-	81205	1	25-53-14 0530/122/L029	050-099
D01224		BACC45FN14-12S RCPT-	81205	1	25-53-12 0579/122/R009	150-199, 275-299
D01226		BACC45FN14-12S RCPT-	81205	1	25-53-14 0639/122/R029	050-099
D01226		BACC45FN14-12S RCPT-	81205	1	25-53-12 0517/122/R009	150-199, 275-299
D01228		BACC45FN14-12S RCPT-	81205	1	25-53-14 0579/122/R009	050-099
D01228		BACC45FN14-12S RCPT-	81205	1	25-53-12 502/122/L029	150-199, 275-299
D01230		BACC45FN14-12S RCPT-	81205	1	25-53-14 0517/122/R029	050-099
D01230		BACC45FN14-12S RCPT-	81205	1	25-53-12 502/122/R030	150-199, 275-299
D01231		BACC45FT12D12S PLUG-	81205	1	23-32-13 1125/280/0000	050-099
D01231		BACC45FT12A12S PLUG	81205	1	23-32-11 1070/280/0000	150-199

EQUIPMENT LIST

D280T132

Section D01200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01232		BACC45FN14-12S RCPT-	81205	1	25-53-14 0579/122/L029	050-099
D01232		BACC45FN14-12S RCPT-	81205	1	25-53-12 0578/122/L021	150-199, 275-299
D01233		KC-59-660-M06 PLUG-COAXIAL	91836	1	23-32-13 1125/280/0000	050-099
D01233		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 1070/280/0000	150-199
D01234		BACC45FN14-12S RCPT-	81205	1	25-53-14 0596/122/R029	050-099
D01234		BACC45FN14-12S RCPT-	81205	1	25-53-12 0517/122/R036	150-199, 275-299
D01235		KA-39-94-M06 PLUG-COAXIAL	91836	1	23-32-13 F 295/ /FS	ALL
D01236		BACC45FN14-12S RCPT-	81205	1	25-53-14 0579/122/R029	050-099
D01236		BACC45FN14-12S RCPT-	81205	1	25-53-12 0639/122/R038	150-199, 275-299
D01237		KA-59-304 PLUG-COAXIAL	91836	1	23-32-13 F 395/ /FS	ALL
D01238		BACC45FN14-12S RCPT-	81205	1	25-53-14 0558/122/L029	050-099
D01238		BACC45FN14-12S RCPT-	81205	1	25-53-12 0596/122/L029	150-199, 275-299
D01239		KA-39-94-M06 PLUG-COAXIAL	91836	1	23-32-13 F 295/ /FS	ALL
D01240		BACC45FN14-12S RCPT-	81205	1	25-53-14 0569/122/R029	050-099
D01240		BACC45FN14-12S RCPT-	81205	1	25-53-12 0596/122/R010	150-199, 275-299
D01241		KA-59-304 PLUG-COAXIAL	91836	1	23-32-13 F 395/ /FS	ALL
D01242		BACC45FN14-12S RCPT-	81205	1	25-53-14 0639/122/L029	050-099

EQUIPMENT LIST

D280T132

Section D01200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01242		BACC45FN14-12S RCPT-	81205	1	25-53-12 0661/122/L029	150-199, 275-299
D01243		KA-59-304 PLUG-COAXIAL	91836	1	23-32-13 F 295/ /FS	ALL
D01244		BACC45FN14-12S RCPT-	81205	1	25-53-14 0530/122/R029	050-099
D01244		BACC45FN14-12S RCPT-	81205	1	25-53-14 654+121/122/R029	150-199, 275-299
D01245		KA-59-304 PLUG-COAXIAL	91836	1	23-32-13 F 333/ /FS	ALL
D01246		BACC45FN14-12S RCPT-	81205	1	25-53-14 0502/122/L029	050-099
D01246		BACC45FN14-12S RCPT-	81205	1	25-53-12 0517/122/L020	150-199, 275-299
D01247		KA-59-304 PLUG-COAXIAL	91836	1	23-32-13 F 295/ /FS	ALL
D01248		BACC45FN14-12S RCPT-	81205	1	25-53-14 0502/122/R029	050-099
D01248		BACC45FN14-12S RCPT-	81205	1	25-53-12 0530/122/R029	150-199, 275-299
D01249		KA-59-304 PLUG-COAXIAL	91836	1	23-32-13 F 333/ /FS	ALL
D01250		BACC45FN14-12S RCPT-	81205	1	25-53-14 0683/122/L029	050-099
D01250		BACC45FN14-12S RCPT-	81205	1	25-53-12 559/122/L029	150-199, 275-299
D01251		BACC66H21C31AA01 PLUG-	81205	1	27-09-11 SHELF/E01/01	ALL
D01251A		PARTAOFD01251 PLUG-PART A OF D01251		0	27-09-11 / /	ALL
D01251B		PARTBOFD001251 PLUG-PART B OF D01251		0	27-09-11 / /	ALL
D01251C		PARTCOFD01251 PLUG-PART C OF D01251		0	27-09-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D01200

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01252		BACC45FN14-12S RCPT-	81205	1	25-53-14 0683/122/R029	050-099
D01252		BACC45FN14-12S RCPT-	81205	1	25-53-12 559/122/R029	150-199, 275-299
D01253		BACC66H21C31AA01 PLUG-	81205	1	27-09-11 SHELF/E01/01	ALL
D01253A		PARTAOFD01253 PLUG-PART A OF D01253		0	27-09-11 //	ALL
D01253B		PARTBOFD01253 PLUG-PART B OF D01253		0	27-09-11 //	ALL
D01253C		PARTCOFD01253 PLUG-PART C OF D01253		0	27-09-11 //	ALL
D01254		BACC63BP14A7SNL PLUG-	81205	1	28-26-11 L0333/14/RS	ALL
D01254 T		BACC10KD14 CLAMP-	81205	1	28-26-11 //	ALL
D01255		BACC66H21C31AA01 PLUG-	81205	1	27-09-11 SHELF/E02/01	ALL
D01255A		PARTAOFD01255 PLUG-PART A OF D01255		0	27-09-11 //	ALL
D01255B		PARTBOFD01255 PLUG-PART B OF D01255		0	27-09-11 //	ALL
D01255C		PARTCOFD01255 PLUG-PART C OF D01255		0	27-09-11 //	ALL
D01256		BACC63BP14A7SNL PLUG-	81205	1	28-26-11 R0333/12/RS	ALL
D01256 T		BACC10KD14 CLAMP-	81205	1	28-26-11 //	ALL
D01257		BACC66H21C31AA01 PLUG-	81205	1	27-09-11 SHELF/E02/01	ALL
D01257A		PARTAOFD01257 PLUG-PART A OF D01257		0	27-09-11 //	ALL
D01257B		PARTBOFD01257 PLUG-PART B OF D01257		0	27-09-11 //	ALL

EQUIPMENT LIST

D280T132

Section D01200

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01257C		PARTCOFD01257 PLUG-PART C OF D01257		0	27-09-11 //	ALL
D01259		BACC66H21C11AA01 PLUG-	81205	1	22-21-11 SHELF/E01/01	ALL
D01259A		PARTAOFD01259 PLUG-PART A OF D01259		0	22-21-11 //	ALL
D01259B		PARTBOFD01259 PLUG-PART B OF D01259		0	22-21-11 //	ALL
D01259C		PARTCOFD01259 PLUG-PART C OF D01259		0	22-21-11 //	ALL
D01260		BACC45FN14-12S RCPT-	81205	1	25-53-14 0474/122/L029	050-099
D01261		BACC66H21C11AA01 PLUG-	81205	1	22-21-21 SHELF/E02/01	ALL
D01261A		PARTAOFD01261 PLUG-PART A OF D01261		0	22-21-21 //	ALL
D01261B		PARTBOFD01261 PLUG-PART B OF D01261		0	22-21-21 //	ALL
D01261C		PARTCOFD01261 PLUG-PART C OF D01261		0	22-21-21 //	ALL
D01262		BACC45FT12-12S PLUG-	81205	1	38-32-11 1573/165/L030	050-099, 155, 162-165
D01262		BACC45FT12A12S PLUG-	81205	1	38-32-11 1573/165/L030	150-154
D01262		BACC45FT16A24S PLUG-	81205	1	38-32-11 1573/165/L030	156-157, 166-199, 275-299
D01263		BACC66F11C21AA01 PLUG-	81205	1	27-21-12 SHELF/E01/01	ALL
D01263A		PARTAOFD01263 PLUG-PART A OF D01263		0	27-21-12 //	ALL
D01263B		PARTBOFD01263 PLUG-PART B OF D01263		0	27-21-12 //	ALL
D01263C		PARTCOFD01263 PLUG-PART C OF D01263		0	27-21-12 //	ALL

EQUIPMENT LIST

D280T132

Section D01200
Page 6
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01264		BACS16AG1 RELAY SOCKET	81205	1	49-15-11 P049-00/ /	ALL
D01265		BACC66F11C21AA01 PLUG-	81205	1	27-21-22 SHELF/E02/01	ALL
D01265A		PARTAOFD01265 PLUG-PART A OF D01265		0	27-21-22 / /	ALL
D01265B		PARTBOFD01265 PLUG-PART B OF D01265		0	27-21-22 / /	ALL
D01265C		PARTCOFD01265 PLUG-PART C OF D01265		0	27-21-22 / /	ALL
D01266		BACC45FT18A8S PLUG-	81205	1	38-32-11 1570/185/L040	ALL
D01268		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL
D01270		BACC63BP10A5SNL PLUG-ALT PRESS. SW	81205	1	38-32-11 1629/171/R047	ALL
D01270 T		BACC10KD10 CLAMP-	81205	1	38-32-11 / /	ALL
D01272		BACC63BP10R5S10L PLUG-	81205	1	21-51-21 0870/123/R064	050-099
D01272		BACC63BP10R5S8L PLUG-	81205	1	21-51-21 0870/123/R064	150-199, 275-299
D01272 T		BACC10KD10 CLAMP-	81205	1	21-51-21 / /	ALL
D01274		BACC45FN14-12S RCPT-	81205	1	25-53-14 0517/122/L029	050-099
D01276		BACC63BP10R5SNL PLUG-	81205	1	21-51-21 0870/123/R064	ALL
D01276 T		BACC10KE10 CLAMP-	81205	1	21-51-21 / /	ALL
D01278		BACC63BP10R5S6L PLUG-	81205	1	21-51-21 0870/123/R064	ALL
D01278 T		BACC10KD10 CLAMP-	81205	1	21-51-21 / /	ALL

EQUIPMENT LIST

D280T132

Section D01200

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01280		BACC45FN14-12S RCPT-	81205	1	25-53-14 0596/122/L029	050-099
D01282		BACC63BN14C7SN PLUG-	81205	1	36-11-21 0946/127/R048	ALL
D01284		BACS16W1 RCPT-P35	81205	1	25-53-14 P035-00/ /	050-099
D01284		BACS16AG1 RCPT-	81205	1	25-53-16 P035-00/ /	150-199, 275-299
D01288		BACS16W1 RCPT-P35	81205	1	25-53-14 P035-00/ /	050-099
D01288		BACS16W1 PLUG	81205	1	25-53-16 P035-00/ /	150-199, 275-299
D01290		BACC45FT10A5S PLUG-	81205	1	38-15-11 1560/192/R042	ALL
D01294		BACC45FT10A5S PLUG-	81205	1	38-15-11 1550/190/R040	ALL
D01296		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0883/119/R038	ALL

EQUIPMENT LIST

D280T132

Section D01200
Page 8 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01302		BACC45FT18A31S PLUG-P5	81205	1	21-64-11 P005-00/ /	ALL
D01310		BACC45FT22A55S7 PLUG-P5	81205	1	24-22-21 P005-00/ /	ALL
D01312		BACC45FT16A24S8 PLUG-P5	81205	1	29-11-22 P005-00/ /	ALL
D01314		BACS16AH1 RCPT-P35	81205	1	25-53-14 P035-00/ /	050-099
D01316		BACC45FT22A55S8 PLUG-P5	81205	1	36-11-31 P005-00/ /	ALL
D01324		BACC45FT18A31S PLUG-P5	81205	1	21-31-11 P005-00/ /	ALL
D01326		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0882/129/R038	ALL
D01328		BACC45FT12A12S PLUG-P5	81205	1	21-58-11 P005-00/ /	ALL
D01330		BACC45FT18A31S8 PLUG-P5	81205	1	28-22-11 P005-00/ /	ALL
D01331		KA-59-392-M06 PLUG-E2-2 COAX,ATC-L	91836	1	34-53-11 AE0314/ /	ALL
D01333		KA-59-392-M06 PLUG-E2-2 COAX,DME-L	91836	1	34-55-11 AE0314/ /	ALL
D01335		KA-59-392-M06 PLUG-E2-3 COAX,ATC-R	91836	1	34-53-21 AE0316/ /	050-099, 150-199, 277-299
D01335		KA-59-392-M06 PLUG-E2-2 COAX,ATC-R	91836	1	34-53-21 AE0314/ /	275-276
D01336		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0878/119/R040	ALL
D01337		KA-59-392-M06 PLUG-E2-3 COAX,DME-R	91836	1	34-55-21 AE0314/ /	ALL
D01337 T		KA-99-125-M06 TEE-ADAPTER E2-2	91836	1	34-55-21 / /	ALL
D01338		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0883/119/L039	ALL

EQUIPMENT LIST

D280T132

Section D01300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01342		BACC45FT20A41S7 PLUG-P5	81205	1	21-51-21 P005-00/ /	ALL
D01344		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0882/129/L039	150-199, 275-299
D01344	1	BACC63BW12SC3S PLUG-	81205	1	21-52-31 0882/129/L039	050-099
D01344	2	FH3406D PLUG-	28680	1	21-52-31 0882/129/L039	050-099
D01344 T	2	BACC10GL12 CLAMP-	81205	1	21-52-31 / /	050-099
D01346		BACC45FT16A10S PLUG-P5	81205	1	24-11-11 P005-00/ /	ALL
D01347		BACS16X1A RELAY SOCKET-	81205	1	23-34-11 P033-00/ /	ALL
D01348		BACC45FT22A55S9 PLUG-P5	81205	1	36-11-21 P005-00/ /	ALL
D01352		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0878/119/L037	150-199, 275-299
D01352	1	BACC63BW12SC3S PLUG-	81205	1	21-52-31 0878/119/L037	050-099
D01352	2	FH3406D PLUG-	28680	1	21-52-31 0878/119/L037	050-099
D01352 T	2	BACC10GL12 CLAMP-	81205	1	21-52-31 / /	050-099
D01353		BACC45FT14A15S PLUG-	81205	1	23-51-11 0176/222/L040	ALL
D01355		BACC45FT14A15S PLUG-	81205	1	23-51-21 0188/222/R050	ALL
D01356		BACS16X1A RELAY SOCKET-	81205	1	38-32-11 P36/ /	050-099
D01356		BACS16X1A RELAY SOCKET-	81205	1	38-32-11 P036-00/ /	150-155, 162-165, 275-276
D01358		BACC45FT14A15S PLUG-P5	81205	1	21-65-11 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D01300
Page 2
May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01359		BACC45FT14A15S PLUG-	81205	1	23-51-21 0204/220/L050	ALL
D01360		BACC45FT16A24S6 PLUG-P5	81205	1	29-11-12 P005-00/ /	ALL
D01363		BACC45FT14A15S PLUG-	81205	1	22-14-11 P001-03/ /	ALL
D01364		BACC45FN16-24S7 RCPT-SWITCH PACK	81205	1	78-34-11 AE0108/ /	ALL
D01365		BACC45FT14A15S PLUG-	81205	1	22-14-21 P003-01/ /	ALL
D01366		BACC45FT14A15S6 PLUG-P5	81205	1	21-58-11 P005-00/ /	ALL
D01370		BACC45FT16A24S6 PLUG-P5	81205	1	24-22-41 P005-00/ /	ALL
D01371		BACC66H21C14AA01 PLUG-ARINC-600	81205	1	34-24-11 SHELF/E01/04	ALL
D01371A		PARTAOFD01371 PLUG-PART OF D01371		0	34-24-11 / /	ALL
D01371B		PARTBOFD01371 PLUG PART OF D01371		0	34-24-11 / /	ALL
D01371C		PARTCOFD01371 PLUG-PART OF D01371		0	34-24-11 / /	ALL
D01373		MS3126F10-6S PLUG-	81205	1	23-51-11 0164/225/L036	ALL
D01374		BACC45FT18A31S7 PLUG-P5	81205	1	28-42-11 P005-00/ /	ALL
D01375		MS3126F10-6S PLUG-	81205	1	23-51-31 0240/220/R030	ALL
D01377		MS3126F10-6S PLUG-P61	81205	1	23-51-41 P061-00/ /	050-099, 150-166, 275-277
D01377		MS3126E10-6S PLUG-P61	81205	1	23-51-41 P061-00/ /	167-199, 278-299
D01381		BACC65L66 RCPT-	81205	1	27-32-21 0265/160/R034	ALL

EQUIPMENT LIST

D280T132

Section D01300

Page 3

May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01381	U	BACC47EM1 KEYING PLUG-	81205	2	27-32-21 / /	ALL
D01382		BACC45FT22A55S6 PLUG-P5	81205	1	24-11-11 P005-00/ /	ALL
D01384		BACC45FT16A24S7 PLUG-P5	81205	1	28-22-31 P005-00/ /	ALL
D01386		BACC45FT14A7S PLUG-	81205	1	21-24-11 0619/305/R030	050-099
D01386		BACC45FT14A7S PLUG-	81205	1	21-24-11 0686/305/L030	150-199
D01388		BACS16W1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D01390		BACS16X1A RCPT-P35	81205	1	25-53-17 P035-00/ /	050-099
D01390		BACS16X1A RCPT-35	81205	1	25-53-17 P035-00/ /	150-199, 275-299
D01394		BACC45FT18A31S6 PLUG-P5	81205	1	49-61-11 P005-00/ /	ALL
D01396		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL
D01399		PT06E-8-2S-SR- PLUG	77820	1	27-32-21 0165/190/R040	ALL

EQUIPMENT LIST

D280T132

Section D01300
Page 4 End
May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01404		BACC45FN16-24S8 RCPT-SWITCH PACK	81205	1	78-34-21 AE0108/ /	ALL
D01406		BACC45FT18A31S PLUG-P5	81205	1	29-11-32 P005-00/ /	ALL
D01408		BACC45FT12A12S PLUG-P5	81205	1	21-31-31 P005-00/ /	ALL
D01415		C0909A20N16SN-494 PLUG-ADF R ANTENNA	13556	1	34-57-21 1165/320/0000	ALL
D01419		BACC66F11C05AA01 PLUG-R ADF	81205	1	34-57-21 SHELF/E05/01	050-099
D01419		BACC66F11C05AA01 PLUG-	81205	1	34-57-21 E5-1/ /	150-199, 275-299
D01419B		PARTOFD01419 PLUG-PART OF D01419		0	34-57-21 / /	050-099
D01419B		PARTBOFD01419 PLUG PART OF D01419		0	34-57-21 / /	150-199, 275-299
D01419C		PARTOFD01419 PLUG-PART OF D01419		0	34-57-21 / /	050-099
D01419C		PARTCOFD01419 PLUG PART OF D01419		0	34-57-21 / /	150-199, 275-299
D01421		BACC45FT22A55S PLUG-E2-3	81205	1	31-31-16 AE0316/POS/09	ALL
D01423		BACC45FT22-55S RCPT-E2-2	81205	1	34-53-12 SHELF/E02/02	050-099
D01423		BACC45FT22-55S RCPT-E2-2	81205	1	34-53-11 SHELF/E02/02	150-199, 275-299
D01424		BACC45FS12A3S PLUG-L ENG SQUIB	81205	1	26-21-11 703/156/R 70	050-099
D01424		BACC45FS12A3S PLUG-L ENG SQUIB	81205	1	26-21-11 654+126/156/R 70	155-199, 275-299
D01425		BACC45FT22A55S RCPT-E2-3	81205	1	34-53-22 AE0316/ /	ALL
D01426		BACC45FS12A3S PLUG-L ENG SQUIB	81205	1	26-21-11 0715/156/R070	050-099

EQUIPMENT LIST

D280T132

Section D01400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01426		BACC45FS12A3S PLUG-L ENG SQUIB	81205	1	26-21-11 654+138/156/R070	155-199, 275-299
D01427		BACC45FT22-55S PLUG-E2-5	81205	1	23-21-12 AE0324/ /	ALL
D01428		BACC45FS10A5S7 PLUG-PRESS SW	81205	1	26-21-11 702/168/R 68	050-099
D01428		BACC45FS10A5S7 PLUG-PRESS SW	81205	1	26-21-11 654+125/168/R 68	155-199, 275-299
D01429		BACC45FT22-55S PLUG-E2-5	81205	1	23-22-13 AE0324/ /	ALL
D01430		BACC45FS10A5S10 PLUG-R ENG SQUIB	81205	1	26-21-11 703/156/R 76	050-099
D01430		BACC45FS10A5S10 PLUG-R ENG SQUIB	81205	1	26-21-11 654+126/156/R 76	155-199, 275-299
D01431		BACC45FT12A12S6 PLUG-P61	81205	1	23-41-11 P061-00/ /	ALL
D01432		BACC45FS10A5S10 PLUG-R ENG SQUIB	81205	1	26-21-11 0715/156/R076	050-099
D01432		BACC45FS10A5S10 PLUG-R ENG SQUIB	81205	1	26-21-11 654+138/156/R076	155-199, 275-299
D01433		BACC65L66 RCPT	81205	1	31-51-42 0265/169/R034	ALL
D01433 U		BACC47EM1 KEYING PLUG-	81205	2	31-51-42 / /	ALL
D01434		BACC45FS10A5S7 PLUG-PRESS SW	81205	1	26-21-11 0714/168/R068	050-099
D01434		BACC45FS10A5S7 PLUG-PRESS SW	81205	1	26-21-11 654+137/168/R068	155-199, 275-299
D01436		CN0986-08A03SN-000 PLUG-SQUIB	13556	1	26-22-21 1821/200/R040	050-099, 150-199
D01436		BACC63BP10A5S10L PLUG-SQUIB	81205	1	26-22-21 1821/200/R040	275-299
D01436 T		MS27291-13 CLAMP-	96906	1	26-22-21 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D01400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01436 T		BACC10KD10 CLAMP-	81205	1	26-22-21 / /	275-299
D01438		BACC63BP10A5SNL PLUG-PRESSURE SW	81205	1	26-22-21 1821/200/R040	050-099, 150-199
D01438		BACC63BP10A5S7L PLUG-PRESSURE SW	81205	1	26-22-21 1821/200/R040	275-299
D01438 T		BACC10KD10 CLAMP-	81205	1	26-22-21 / /	ALL
D01440		BACC45FT8A3S PLUG-FWD SQUIB	81205	1	26-23-11 662/150/R 69	050-099
D01440		BACC45FT8A3S PLUG-FWD SQUIB	81205	1	26-23-11 0654+74/147/R069	155-199, 275-299
D01441		KD-59-180-M06 PLUG-COAX	91836	1	34-53-13 331/131/R043	ALL
D01442		BACC45FT10A5S PLUG-AFT SQUIB	81205	1	26-23-11 668/150/R 69	050-099
D01442		BACC45FT10A5S PLUG-AFT SQUIB	81205	1	26-23-11 0654+80/147/R069	155-199, 275-299
D01444		BACC45FS10A5S PLUG-	81205	1	26-16-21 0351/173/L071	ALL
D01445		BACC45FN14-15S RCPT-	81205	1	31-31-11 P061-00/ /	ALL
D01446		BACC45FS10A5S PLUG-	81205	1	26-16-21 1406/158/L070	ALL
D01447		BACC45FN16-24S7 RCPT-	81205	1	22-41-13 P006-05/ /	ALL
D01448		BACC45FS10A5S PLUG-PRESS SW	81205	1	26-23-11 663/165/R 74	050-099
D01448		BACC45FS10A5S PLUG-PRESS SW	81205	1	26-23-11 0654+84/152/R070	155-199, 275-299
D01450		BACC45FT8A3S PLUG-FWD SQUIB	81205	1	26-23-12 662/166/R 80	050-099
D01450		BACC45FT8A3S PLUG-FWD SQUIB	81205	1	26-23-12 0654+52/146/R069	155-199, 275-299

EQUIPMENT LIST

D280T132

Section D01400

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01452		BACC45FT10A5S PLUG-AFT SQUIB	81205	1	26-23-12 668/166/R 80	050-099
D01452		BACC45FT10A5S PLUG-AFT SQUIB	81205	1	26-23-12 0654+58/147/R069	155-199, 275-299
D01454		BACC45FS10A5S PLUG-PRESS SW.	81205	1	26-23-12 663/179/R 81	050-099
D01454		BACC45FS10A5S PLUG-PRESS SW	81205	1	26-23-12 0654+62/152/R070	155-199, 275-299
D01456		BACC45FT12A12S6 PLUG-	81205	1	26-16-11 0349/184/L067	ALL
D01458		BACC45FT12A12S PLUG-	81205	1	26-16-11 1402/163/L071	ALL
D01460		35303-68 PLUG-	73168	1	26-18-21 0952/132/R017	ALL
D01462		BACC45FT12A12S PLUG-	81205	1	26-16-11 352/184/L067	050-099, 150-155, 162-165, 275-276
D01462		BACC45FT12A12S6 PLUG-	81205	1	26-16-11 352/184/L067	156-157, 166-199, 277-299
D01464		BACC45FT12A12S PLUG-	81205	1	26-16-11 1406/163/L071	ALL
D01466		BACC45FT10A5S PLUG-	81205	1	52-11-11 0298/293/L021	ALL
D01468		BACC45FN14-12S RCPT-	81205	1	25-53-24 1139/122/L029	050-099
D01468		BACC45FN14-12S RCPT-	81205	1	25-53-24 1142/122/L029	150-199, 275-299
D01469		BACC45FN18B31S RCPT-	81205	1	76-11-11 P010-00/ /	ALL
D01470		BACC45FN14-12S RCPT-	81205	1	25-53-24 1139/122/R029	050-099
D01470		BACC45FN14-12S RCPT-	81205	1	25-53-24 1142/122/R029	150-199, 275-299
D01471		BACC45FN18B31S7 RCPT-	81205	1	76-11-11 P010-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D01400

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01472		BACC45FN14-12S RCPT-	81205	1	25-53-24 1183/122/L029	050-099
D01472		BACC45FN14-12S RCPT-	81205	1	25-53-24 1187/122/L029	150-199, 275-299
D01473		BACC45FN12B12S RCPT-	81205	1	22-12-21 P010-00/ /	ALL
D01474		BACC45FN14-12S RCPT-	81205	1	25-53-24 1183/122/R029	050-099
D01474		BACC45FN14-12S RCPT-	81205	1	25-53-24 1187/122/R029	150-199, 275-299
D01475		BACC45FN12B12S9 RCPT-	81205	1	22-12-31 P010-00/ /	ALL
D01476		BACC45FN14-12S RCPT-	81205	1	25-53-24 1227/122/L029	050-099
D01476		BACC45FN14-12S RCPT-	81205	1	25-53-24 1197+33/122/L029	150-199, 275-299
D01477		BACC45FN14B15S RCPT-	81205	1	22-12-11 P010-00/ /	ALL
D01478		BACC45FN14-12S RCPT-	81205	1	25-53-24 1227/122/R029	050-099
D01478		BACC45FN14-12S RCPT-	81205	1	25-53-24 1197+33/122/R029	150-199, 275-299
D01479		BACC45FN12C12S RCPT-	81205	1	27-62-11 P010-00/ /	ALL
D01480		BACC45FN14-12S RCPT-	81205	1	25-53-24 1266/122/L029	050-099
D01480		BACC45FN14-12S RCPT-	81205	1	25-53-24 1197+77/122/L029	150-199, 275-299
D01482		BACC45FN14-12S RCPT-	81205	1	25-53-24 1266/122/R029	050-099
D01482		BACC45FN14-12S RCPT-	81205	1	25-53-24 1197+77/122/R029	150-199, 275-299
D01484		BACC45FN14-12S RCPT-	81205	1	25-53-24 1294/122/L029	050-099

EQUIPMENT LIST

D280T132

Section D01400

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01484		BACC45FN14-12S RCPT-	81205	1	25-53-22 1197+121/122/L029	150-199, 275-299
D01486		BACC45FN14-12S RCPT-	81205	1	25-53-24 1294/122/R029	050-099
D01486		BACC45FN14-12S RCPT-	81205	1	25-53-22 1197+121/122/R029	150-199, 275-299
D01487		BACC65L66 RCPT-	81205	1	31-51-31 0265/180/R034	ALL
D01487 U		BACC47EM1 KEYING PLUG-	81205	2	31-51-31 / /	ALL
D01488		BACC45FN14-12S RCPT-	81205	1	25-53-24 1308/122/L029	050-099
D01488		BACC45FN14-12S RCPT-	81205	1	25-53-24 1230/122/L029	150-199, 275-299
D01489		BACC65L66 RCPT	81205	1	31-51-33 0265/180/R034	ALL
D01489 U		BACC47EM1 KEYING PLUG-	81205	2	31-51-33 / /	ALL
D01490		BACC45FN14-12S RCPT-	81205	1	25-53-26 1308/122/R009	050-099
D01492		BACC45FN14-12S RCPT-	81205	1	25-53-24 1308/122/R029	050-099
D01492		BACC45FN14-12S RCPT-	81205	1	25-53-24 1230/122/R029	150-199, 275-299
D01494		BACC45FN14-12S RCPT-	81205	1	25-53-21 1322/122/L029	050-099
D01494		BACC45FN14-12S RCPT-	81205	1	25-53-21 1266/122/L029	150-199, 275-299
D01496		BACC45FN14-12S RCPT-	81205	1	25-53-24 1322/122/R029	050-099
D01496		BACC45FN14-12S RCPT-	81205	1	25-53-24 1266/122/R029	150-199, 275-299
D01498		BACC45FN14-12S RCPT-	81205	1	25-53-24 1350/122/L029	050-099

EQUIPMENT LIST

D280T132

Section D01400

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01498		BACC45FN14-12S RCPT-	81205	1	25-53-24 1294/122/L029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D01400

Page 7 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01500		BACC45FN14-12S RCPT-	81205	1	25-53-24 1350/122/R029	050-099
D01500		BACC45FN14-12S RCPT-	81205	1	25-53-24 1294/122/R029	150-199, 275-299
D01502		BACC45FN14-12S RCPT-	81205	1	25-53-24 1384/122/L029	050-099
D01502		BACC45FN14-12S RCPT-	81205	1	25-53-24 1308/122/L020	150-199, 275-299
D01503		SO-1064-007 SOCKET-	35344	1	31-51-11 0265/150/R034	ALL
D01504		BACC45FN14-12S RCPT-	81205	1	25-53-24 1384/122/R029	050-099
D01504		BACC45FN14-12S RCPT-	81205	1	25-53-24 1308/122/R029	150-199, 275-299
D01505		SO-1064-007 SOCKET-	35344	1	31-51-12 0265/150/R034	ALL
D01506		35303-68 PLUG-	73168	1	26-18-31 0962/150/L010	ALL
D01508		35303-68 PLUG-	73168	1	26-18-31 1830/213/L083	ALL
D01510		35303-68 PLUG-	73168	1	26-18-31 1147/148/L083	ALL
D01512		35303-68 PLUG-	73168	1	26-18-31 1190/180/L070	ALL
D01514		BACC63BP16R10SNL PLUG-	81205	1	27-81-21 L0150/14/LE	050-099
D01514		BACC63BP16A10SNL PLUG-	81205	1	27-81-21 L0150/14/LE	150-166, 275-277
D01514		BACC63BP16B10SNL PLUG-	81205	1	27-81-21 L0150/14/LE	167-199, 278-299
D01514 T		BACC10KD16 CLAMP-	81205	1	27-81-21 / /	050-099, 150-166, 275-277
D01514 T		BACC10KA16 CLAMP-	81205	1	27-81-21 / /	167-199, 278-299

EQUIPMENT LIST

D280T132

Section D01500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01516		BACC63BP16A10SNL PLUG-	81205	1	27-81-11 R0143/14/LE	050-099, 150-166, 275-277
D01516		BACC63BP16B10SNL PLUG-	81205	1	27-81-11 R0143/14/LE	167-199, 278-299
D01516 T		BACC10KD16 CLAMP-	81205	1	27-81-11 / /	050-099, 150-166, 275-277
D01516 T		BACC10KA16 CLAMP-	81205	1	27-81-11 / /	167-199, 278-299
D01518		BACS16AH1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D01518		BACS16AH1 PLUG	81205	1	25-53-14 P035-000/ /	150-199, 275-299
D01520		BACC45FT12-12S PLUG-P11	81205	1	33-13-19 P011-00/ /	ALL
D01522		BACC63BP18R8SNL PLUG-	81205	1	27-81-21 L0150/14/LE	ALL
D01522 T		BACC10KD18 CLAMP-	81205	1	27-81-21 / /	ALL
D01524		BACC63BP18R8SNL PLUG-	81205	1	27-81-11 R0143/14/LE	ALL
D01524 T		BACC10KD18 CLAMP-	81205	1	27-81-11 / /	ALL
D01526		BACS16AG1 RELAY SOCKET-	81205	1	27-62-11 P033-00/ /	ALL
D01528		BACC63BP14R7SNL PLUG-	81205	1	27-81-31 R140/14/LE	ALL
D01528 T		BACC10KD14 CLAMP-	81205	1	27-81-31 / /	ALL
D01530		BACC63BN10C5SN PLUG-	81205	1	28-42-11 L0294/14/RS	ALL
D01532		BACC63BN10C5SN PLUG-	81205	1	28-42-11 R0297/14/RS	ALL
D01534	1	BACC63BP16D10SNL PLUG-	81205	1	28-41-21 L0287/14/TE	ALL

EQUIPMENT LIST

D280T132

Section D01500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01534	2	BACC63BP16B10SNL PLUG-	81205	1	28-41-21 L0287/14/TE	ALL
D01534	3	BACC63BP16A10SNL PLUG-	81205	1	28-41-21 L0287/14/TE	ALL
D01534 T	1	BACC10KA16 CLAMP-	81205	1	28-41-21 / /	ALL
D01534 T	2	BACC10KA16 CLAMP-	81205	1	28-41-21 / /	ALL
D01534 T	3	BACC10KD16 CLAMP-	81205	1	28-41-21 / /	ALL
D01536	1	BACC63BP16D10SNL PLUG-	81205	1	28-41-22 R0287/14/TE	ALL
D01536	2	BACC63BP16B10SNL PLUG-	81205	1	28-41-22 R0287/14/TE	ALL
D01536	3	BACC63BP16A10SNL PLUG-	81205	1	28-41-22 R0287/14/TE	ALL
D01536 T	1	BACC10KA16 CLAMP-	81205	1	28-41-22 / /	ALL
D01536 T	2	BACC10KA16 CLAMP-	81205	1	28-41-22 / /	ALL
D01536 T	3	BACC10KD16 CLAMP-	81205	1	28-41-22 / /	ALL
D01538		BACC63BN10C5SNL PLUG-	81205	1	28-42-11 L0297/14/RS	ALL
D01540		BACC63BP14A7SNL PLUG-	81205	1	28-22-11 R0274/12/MS	ALL
D01540 T		BACC10KD14 CLAMP-	81205	1	28-22-11 / /	ALL
D01542		BACC63BP14A7SNL PLUG-	81205	1	28-22-11 L0274/12/MS	ALL
D01542 T		BACC10KD14 CLAMP-	81205	1	28-22-11 / /	ALL
D01544		BACC63BP14A7SNL PLUG-	81205	1	28-22-31 0954/156/L029	050-099, 155-199, 276-299

EQUIPMENT LIST

D280T132

Section D01500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01544		BACC63BP14A7SNL PLUG-	81205	1	28-22-31 0954/170/L029	150-154, 275
D01544 T		BACC10KD14 CLAMP-	81205	1	28-22-31 / /	150-154, 275
D01544 U		710AS011M1412-62A ADAPTER	06324	1	28-22-31 0954/170/L029	050-099, 155-199, 276-299
D01544 V		-11301 MATE WITH TAPE TEXT AS BELOW	06090	1	28-22-31 / /	276
D01546		BACC45FM18C14S PLUG-	81205	1	27-58-21 1090/131/L085	ALL
D01548		BACC45FM18C14S RCPT-	81205	1	27-51-41 1090/131/R085	ALL
D01550		BACC63BP14A7SNL PLUG-	81205	1	28-22-11 L0280/ /	ALL
D01550 T		BACC10KD14 CLAMP-	81205	1	28-22-11 / /	ALL
D01552		BACC63BP14A3SNL PLUG-L TANK BUSSING UNIT	81205	1	28-41-21 L0403/14/TE	050-099, 150-156, 162-166, 275-276
D01552		BACC63BP14A3SNL PLUG- L TANK BUSSING UNIT	81205	1	28-41-21 L0403/14/TE	157, 167-199, 277- 299
D01552 T	1	S2408-13-8 CLAMP-	07418	1	28-41-21 / /	ALL
D01552 T	2	BACC10KD14 CLAMP-	81205	1	28-41-21 / /	ALL
D01554		BACC63BP14A7SNL PLUG-	81205	1	28-22-21 L0327/12/RS	ALL
D01554 T		BACC10KD14 CLAMP-	81205	1	28-22-21 / /	ALL
D01560		BACC63BP14A3SNL PLUG-	81205	1	28-41-22 R0411/14/RS	ALL
D01560 T	1	S2408-13-8 CLAMP-	07418	1	28-41-22 / /	ALL
D01560 T	2	BACC10KD14 CLAMP-	81205	1	28-41-22 / /	ALL

EQUIPMENT LIST

D280T132

Section D01500

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01562		BACC63BP12R3SNL PLUG-	81205	1	21-51-21 0879/124/R044	ALL
D01562 T		BACC10KD12 CLAMP-	81205	1	21-51-21 / /	ALL
D01564		BACC63BP14A7SNL PLUG-	81205	1	28-25-21 L0288/14/RS	ALL
D01564 T		BACC10KD14 CLAMP-	81205	1	28-25-21 / /	ALL
D01566		BACC63BN10C5SN PLUG-	81205	1	28-42-21 L0273/12/RS	ALL
D01568		BACC63BP10R5SNL PLUG-	81205	1	21-51-22 0867/123/R044	ALL
D01568 T		BACC10KD10 CLAMP-	81205	1	21-51-22 / /	ALL
D01569		BACC45FT10D5S PLUG	81205	16	23-34-13 MULTI/ /	050-099
D01569		BACC45FT10D5S PLUG	81205	41	23-34-13 MULTI/ /	162-199
D01569		BACC45FT10D5S PLUG	81205	102	23-34-13 MULTI/ /	275-276
D01570		BACC63BP14A4SNL PLUG-	81205	1	28-25-11 L0278/14/RS	ALL
D01570 T		BACC10KD14 CLAMP-	81205	1	28-25-11 / /	ALL
D01571		BACC45FT10D5S PLUG	81205	16	23-34-13 MULTI/ /	050-099
D01571		BACC45FT10D5S PLUG	81205	41	23-34-13 MULTI/ /	162-199
D01571		BACC45FT10D5S PLUG	81205	102	23-34-13 MULTI/ /	275-276
D01572		BACC63BP14A7SNL PLUG-	81205	1	28-22-21 R0325/12/RS	ALL
D01572 T		BACC10KD14 CLAMP-	81205	1	28-22-21 / /	ALL

EQUIPMENT LIST

D280T132

Section D01500

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01573		BACC45FT10D5S PLUG	81205	18	23-34-13 MULTI/ /	050-099
D01573		BACC45FT10D5S PLUG	81205	57	23-34-13 MULTI/ /	150-157
D01573		BACC45FT10D5S PLUG	81205	17	23-34-13 MULTI/ /	162-199
D01573		BACC45FT10D5S PLUG	81205	19	23-34-13 MULTI/ /	275-276
D01573		BACC45FT10D5S PLUG	81205	114	23-34-13 MULTI/ /	277-278
D01573		BACC45FT10D5S PLUG	81205	111	23-34-13 MULTI/ /	280-299
D01574		BACC63BP16A10SNL PLUG-	81205	1	27-13-11 L0430/12/TE	ALL
D01574 T		BACC10KD16 CLAMP-	81205	1	27-13-11 / /	ALL
D01575		BACC45FT10D5S PLUG	81205	18	23-34-13 MULTI/ /	050-099
D01575		BACC45FT10D5S PLUG	81205	57	23-34-13 MULTI/ /	150-157
D01575		BACC45FT10D5S PLUG	81205	17	23-34-13 MULTI/ /	162-199
D01575		BACC45FT10D5S PLUG	81205	19	23-34-13 MULTI/ /	275-276
D01575		BACC45FT10D5S PLUG	81205	114	23-34-13 MULTI/ /	277-278
D01575		BACC45FT10D5S PLUG	81205	111	23-34-13 MULTI/ /	280-299
D01576		BACC63BP12R3SNL PLUG-	81205	1	21-51-11 0879/138/L050	ALL
D01576 T		BACC10KD12 CLAMP-	81205	1	21-51-11 / /	ALL
D01577		BACC45FT10D5S PLUG	81205	28	23-34-13 MULTI/ /	050-099

EQUIPMENT LIST

D280T132

Section D01500

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01577		BACC45FT10D5S PLUG	81205	34	23-34-13 MULTI/ /	150-157
D01577		BACC45FT10D5S PLUG	81205	11	23-34-13 MULTI/ /	162-199
D01577		BACC45FT10D5S PLUG	81205	38	23-34-13 MULTI/ /	275-276
D01577		BACC45FT10D5S PLUG	81205	5	23-34-13 MULTI/ /	277-278
D01577		BACC45FT10D5S PLUG	81205	22	23-34-13 MULTI/ /	280-299
D01578		BACC45FM18C14S RCPT-	81205	1	27-51-41 L0400/12/TE	ALL
D01579		BACC45FT10D5S PLUG	81205	28	23-34-13 MULTI/ /	050-099
D01579		BACC45FT10D5S PLUG	81205	34	23-34-13 MULTI/ /	150-157
D01579		BACC45FT10D5S PLUG	81205	11	23-34-13 MULTI/ /	162-199
D01579		BACC45FT10D5S PLUG	81205	38	23-34-13 MULTI/ /	275-276
D01579		BACC45FT10D5S PLUG	81205	5	23-34-13 MULTI/ /	277-278
D01579		BACC45FT10D5S PLUG	81205	22	23-34-13 MULTI/ /	280-299
D01581		BACC45FT10D5S PLUG	81205	6	23-34-13 MULTI/ /	050-099, 277-278
D01581		BACC45FT10D5S PLUG	81205	4	23-34-13 MULTI/ /	162-199
D01581		BACC45FT10D5S PLUG	81205	1	23-34-13 MULTI/ /	275-276
D01581		BACC45FT10D5S PLUG	81205	2	23-34-13 MULTI/ /	280-299
D01582		BACC63BP20A16SNL PLUG-L TANK HARNESS ASSEMBLY	81205	1	28-41-21 L0406/14/TE	050-099, 150-156, 162-166, 275-276

EQUIPMENT LIST

D280T132

Section D01500

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01582		BACC63BP20A16SNL PLUG- L TANK HARNESS ASSEMBLY	81205	1	28-41-21 L0406/14/TE	157, 167-199, 277-299
D01582	T	BACC10KD20 CLAMP-	81205	1	28-41-21 / /	ALL
D01583		BACC45FT10D5S PLUG	81205	6	23-34-13 MULTI/ /	050-099, 277-278
D01583		BACC45FT10D5S PLUG	81205	4	23-34-13 MULTI/ /	162-199
D01583		BACC45FT10D5S PLUG	81205	1	23-34-13 MULTI/ /	275-276
D01583		BACC45FT10D5S PLUG	81205	2	23-34-13 MULTI/ /	280-299
D01584		BACC63BP20A16SNL PLUG-	81205	1	28-41-22 R0407/14/RS	ALL
D01584	T	BACC10KD20 CLAMP-	81205	1	28-41-22 / /	ALL
D01585		BACC45FT10D5S PLUG	81205	2	23-34-13 MULTI/ /	050-099, 162-199, 277-278
D01585		BACC45FT10D5S PLUG	81205	4	23-34-13 MULTI/ /	150-157
D01585		BACC45FT10D5S PLUG	81205	3	23-34-13 MULTI/ /	275-276
D01585		BACC45FT10D5S PLUG	81205	1	23-34-13 MULTI/ /	280-299
D01586		BACC63BN10C5SN PLUG-	81205	1	27-18-11 L0534/12/TE	ALL
D01587		BACC45FT10D5S PLUG	81205	2	23-34-13 MULTI/ /	050-099, 162-199, 277-278
D01587		BACC45FT10D5S PLUG	81205	4	23-34-13 MULTI/ /	150-157
D01587		BACC45FT10D5S PLUG	81205	3	23-34-13 MULTI/ /	275-276
D01587		BACC45FT10D5S PLUG	81205	1	23-34-13 MULTI/ /	280-299

EQUIPMENT LIST

D280T132

Section D01500

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01588		BACC63BN10C5SN PLUG-	81205	1	27-18-11 R0534/12/TE	ALL
D01589		BACC45FT10D5S PLUG	81205	1	23-34-13 MULTI/ /	150-199
D01590		BACC63BP10R5SNL PLUG-	81205	1	21-51-12 0879/123/L040	ALL
D01590 T		BACC10KD10 CLAMP-	81205	1	21-51-12 / /	ALL
D01591		BACC45FT10D5S PLUG	81205	1	23-34-13 MULTI/ /	150-199
D01592		BACC45FT12-12S PLUG-P11	81205	1	33-13-19 P011-00/ /	ALL
D01594		BACC63BP14R7SNL PLUG-	81205	1	30-11-11 L0405/12/LE	ALL
D01594 T		BACC10KD14 CLAMP-	81205	1	30-11-11 / /	ALL
D01596		BACC63BP14A7SNL PLUG-	81205	1	30-11-11 R0400/14/LE	ALL
D01596 T		BACC10KD14 CLAMP-	81205	1	30-11-11 / /	ALL
D01597		BACC45FT10D5S PLUG-	81205	8	23-34-13 MULTI/ /	050-099
D01597		BACC45FT10D5S PLUG-	81205	13	23-34-13 MULTI/ /	150-157
D01597		BACC45FT10D5S PLUG-	81205	14	23-34-13 MULTI/ /	162-199
D01597		BACC45FT10D5S PLUG-	81205	4	23-34-13 MULTI/ /	277-278
D01597		BACC45FT10D5S PLUG-	81205	9	23-34-13 MULTI/ /	280-299
D01598	1	BACC63BP10R5S7L PLUG-	81205	1	21-51-11 0852/123/L060	ALL
D01598	2	BACC45FS10C5S7 PLUG-	81205	1	21-51-11 0852/123/L060	ALL

EQUIPMENT LIST

D280T132

Section D01500

Page 9

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01598 T	1	BACC10KD10 CLAMP-	81205	1	21-51-11 / /	ALL
D01599		BACC45FT10D5S PLUG-	81205	8	23-34-13 MULTI/ /	050-099
D01599		BACC45FT10D5S PLUG-	81205	13	23-34-13 MULTI/ /	150-157
D01599		BACC45FT10D5S PLUG-	81205	14	23-34-13 MULTI/ /	162-199
D01599		BACC45FT10D5S PLUG-	81205	4	23-34-13 MULTI/ /	277-278
D01599		BACC45FT10D5S PLUG-	81205	9	23-34-13 MULTI/ /	280-299

EQUIPMENT LIST

D280T132

Section D01500
Page 10 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01600		BACC45FT12-12S PLUG-P11	81205	1	33-13-19 P011-00/ /	ALL
D01602	1	BACC63BP10R5S7L PLUG-	81205	1	21-51-21 0896/123/R064	ALL
D01602	2	BACC45FS10C5S7 PLUG-	81205	1	21-51-21 0896/123/R064	ALL
D01602 T	1	BACC10KD10 CLAMP-	81205	1	21-51-21 / /	ALL
D01608		BACS16X1A RCPT-P35	81205	1	25-53-17 P035-00/ /	ALL
D01612		BACS16W1 RELAY SOCKET-P36	81205	1	32-09-11 P036-00/ /	ALL
D01614		BACC63BN10C5SN PLUG-	81205	1	28-21-13 L0346/12/RS	ALL
D01616		BACC63BN10C5SN PLUG-	81205	1	28-21-13 R0347/12/RS	ALL
D01618		BACC63BN10C5SN PLUG-	81205	1	28-21-13 L0631/14/RS	ALL
D01620		BACC63BN10C5SN PLUG-	81205	1	28-21-13 R0631/14/	ALL
D01622		BACC63BP16A10SNL PLUG-	81205	1	28-41-11 P028-00/ /	ALL
D01622 T		BACC10KE16 CLAMP-	81205	1	28-41-11 / /	ALL
D01624		BACC63BP16A10SNL PLUG-	81205	1	28-41-11 P028-00/ /	ALL
D01624 T		BACC10KE16 CLAMP-	81205	1	28-41-11 / /	ALL
D01626		BACC63BP16A10SNL PLUG-	81205	1	28-41-11 P028-00/ /	ALL
D01626 T		BACC10KE16 CLAMP-	81205	1	28-41-11 / /	ALL
D01629		BACC45FT16A24S6 PLUG-ADF L,CONT PNL	81205	1	34-57-11 P008-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D01600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01630		BACC45FM18C14S RCPT-	81205	1	27-51-41 L0803/12/RS	ALL
D01631		BACC45FT16A24S9 PLUG-PNL,CONT.,ADF-R	81205	1	34-57-21 P008-00/ /	ALL
D01632		BACC45FM18C14S RCPT-	81205	1	27-51-41 R0804/14/TE	ALL
D01634		BACC63BP14A7SNL PLUG-	81205	1	27-11-12 L0995/14/RS	ALL
D01634 T		BACC10KD14 CLAMP-	81205	1	27-11-12 / /	ALL
D01635		KPSE06F10-6S PLUG-	71468	1	31-31-15 0331/180/L048	ALL
D01636		BACC63BP14A7SNL PLUG-	81205	1	27-11-22 R0990/12/RS	ALL
D01636 T		BACC10KD14 CLAMP-	81205	1	27-11-22 / /	ALL
D01638		BACC63BN10B5SN PLUG-	81205	1	27-18-11 L1089/12/RS	ALL
D01640		BACC63BN10B5SN PLUG-	81205	1	27-18-11 R1085/14/TE	ALL
D01644		BACS16AG1 RELAY SOCKET-	81205	1	31-31-12 P037-00/ /	ALL
D01646		BACC45FN24A61S RCPT-	81205	1	52-11-12 P021-00/ /	050-099
D01646		BACC45FN24A61S RCPT-	81205	1	33-27-11 P021-00/ /	150-199
D01646		BACC45FN24A61S RCPT-	81205	1	52-11-12 0284/240/L060	275-299
D01648		BACC45FT16A24S PLUG-	81205	1	33-51-21 1345/203/L093	ALL
D01650		BACC45FN24-61S RCPT-P22	81205	1	33-22-31 1541/250/R060	050-099
D01650		BACC45FN24-61S RCPT-P22	81205	1	33-22-31 P022-00/ /	150-199

EQUIPMENT LIST

D280T132

Section D01600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01650		BACC45FN24-61S RCPT-P22	81205	1	33-22-31 1540/253/R054	275-299
D01651		BACC45FT16A24S PLUG-	81205	1	23-32-11 0447/245/L080	050-099, 150-199
D01651		BACC45FT16A24S PLUG-	81205	1	23-32-11 0255/255/L010	275-299
D01652		BACC45FT16A24S PLUG-	81205	1	33-51-13 1360/203/L092	ALL
D01653		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 0447/245/L080	050-099, 150-199
D01653		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 0255/255/L010	275-299
D01655		BACC45FT12A12S6 PLUG-	81205	1	23-32-12 P005-00/ /	ALL
D01656		WB0710 PLUG-	81323	1	30-41-11 0154/268/L020	ALL
D01656 T		0712 CAP-	81323	1	30-41-11 / /	ALL
D01658		WB0710 PLUG-	81323	1	30-41-11 0154/268/L020	ALL
D01658 T		0712 CAP-	81323	1	30-41-11 / /	ALL
D01660		WB0710 PLUG-	81323	1	30-41-11 0154/268/L020	ALL
D01660 T		0712 CAP-	81323	1	30-41-11 / /	ALL
D01662		WB1240 PLUG-	81323	1	30-41-11 0212/268/R060	ALL
D01662 T		0712 CAP-	81323	1	30-41-11 / /	ALL
D01666		WB0710 PLUG-	81323	1	30-41-12 0154/268/R020	ALL
D01666 T		0712 CAP-	81323	1	30-41-12 / /	ALL

EQUIPMENT LIST

D280T132

Section D01600

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01668		WB0710 PLUG-	81323	1	30-41-12 0154/268/R020	ALL
D01668 T		0712 CAP-	81323	1	30-41-12 / /	ALL
D01669		BACC45FT18A31S PLUG-	81205	1	22-31-12 P003-01/ /	ALL
D01670		WB0710 PLUG-	81323	1	30-41-12 0154/268/R020	ALL
D01670 T		0712 CAP-	81323	1	30-41-12 / /	ALL
D01671		BACS16X1A PLUG-	81205	1	23-31-12 SHELF/E02/05	275-299
D01672		WB1240 PLUG-	81323	1	30-41-12 0212/268/L060	ALL
D01672 T		0712 CAP-	81323	1	30-41-12 / /	ALL
D01673		BACC45FT16A24S PLUG-	81205	1	23-32-11 0447/245/L080	050-099, 150-199
D01673		BACC45FT16A24S PLUG-	81205	1	23-32-11 0255/262/L010	275-299
D01675		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 0447/245/L080	050-099, 150-199
D01675		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 0255/262/L010	275-299
D01678		BACC45FT14A15S7 PLUG-P5	81205	1	52-71-11 P005-00/ /	ALL
D01684		BACS16X1A RELAY SOCKET-	81205	1	25-53-14 P035-00/ /	ALL
D01685		BACC45FN10-5S RCPT-	81205	1	31-31-15 0175/202/L011	ALL
D01686		BACS16X1A RELAY SOCKET-	81205	1	25-53-14 P035-00/ /	ALL
D01687		BACC45FN10-5S6 RCPT-	81205	1	31-31-15 0213/190/L043	ALL

EQUIPMENT LIST

D280T132

Section D01600

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01689		BACC45FN10-5S7 RCPT-	81205	1	31-31-15 0180/197/L020	ALL
D01697		DPXBMA-D32C4-33S-0001 PLUG-	71468	1	23-32-11 447/245/L 80	050-099, 150-199
D01697 T		249-1634-000 CONTACT-COAX (5024A1314)	71468	1	23-32-11 / /	050-099, 150-199
D01697 U		249-1632-000 CONTACT-COAX (BA5903)	71468	1	23-32-13 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D01600
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01706		BACC63BP12S3SNL PLUG-	81205	1	32-46-11 WHEEL/01/L GR	ALL
D01708		BACC63BP12S3SNL PLUG-	81205	1	32-46-11 WHEEL/03/R GR	ALL
D01710		BACC63BP12S3SNL PLUG-	81205	1	32-46-11 WHEEL/02/L GR	ALL
D01712		BACC63BP12S3SNL PLUG-	81205	1	32-46-11 WHEEL/04/R GR	ALL
D01714		BACC63BP12S3SNL PLUG-	81205	1	32-46-11 WHEEL/05/L GR	ALL
D01716		BACC63BP12S3SNL PLUG-	81205	1	32-46-11 WHEEL/07/R GR	ALL
D01718		BACC63BP12S3SNL PLUG-	81205	1	32-46-11 WHEEL/06/L GR	ALL
D01720		BACC63BP12S3SNL PLUG-	81205	1	32-46-11 WHEEL/08/R GR	ALL
D01721		BACC63BP14R7SNL PLUG-	81205	1	27-32-31 1815/268/L020	ALL
D01721 T		BACC10KE14 CLAMP-	81205	1	27-32-31 / /	ALL
D01722		BACS16W1 RELAY SOCKET-P37	81205	1	36-11-51 P033-00/ /	ALL
D01723		BACS16W1 RELAY SOCKET-	81205	1	34-61-15 P036-00/ /	ALL
D01724		BACS16W1 RELAY SOCKET-	81205	1	36-11-52 P037-00/ /	ALL
D01725		BACS16W1 RELAY SOCKET-P37	81205	1	34-61-25 P037-00/ /	ALL
D01726		BACS16W1 RELAY SOCKET-P37	81205	1	36-11-41 P037-00/ /	ALL
D01735		BACC66H21C50A001 PLUG-E2-2	71468	1	31-35-16 SHELF/E02/02	ALL
D01735A		PARTAOFD01735 PLUG-PART OF D01735	81205	1	31-35-16 / /	ALL

EQUIPMENT LIST

D280T132

Section D01700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01735B		PARTBOFD01735 PLUG-PART OF D01735	81205	1	31-35-16 / /	050-099
D01735C		PARTCOFD01735 PLUG-PART OF D01735	81025	1	31-35-16 / /	ALL
D01736		BACS16W1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D01746J		BACC63BV12S3SN RCPT-	81205	1	32-61-11 J00003/LWR/L GR	ALL
D01746P		BACC63BP12B3PNL PLUG - VENDOR PIGTAIL	287T6104 81205	1	32-61-11 / /	ALL
D01748J		BACC63BV12S3SN RCPT-	81205	1	32-61-11 J00003/LWR/L GR	ALL
D01748P		BACC63BP12B3PNL PLUG - VENDOR PIGTAIL	287T6104 81205	1	32-61-11 / /	ALL
D01750J		BACC63BV12S3S7 RCPT-	81205	1	32-61-11 J00003/LWR/L GR	ALL
D01750P		BACC63BP12B3P7L PLUG - VENDOR PIGTAIL	287T6104 81205	1	32-61-11 / /	ALL
D01752J		BACC63BV12S3S7 RCPT-	81205	1	32-61-11 J00003/LWR/L GR	ALL
D01752P		BACC63BP12B3P7L PLUG - VENDOR PIGTAIL	287T6104 81205	1	32-61-11 / /	ALL
D01754J		BACC63BV12S3SN RCPT-	81205	1	32-09-11 NOSE/ /GEAR	ALL
D01754P		BACC63BP12B3PNL PLUG PROX SNSR-NOSE GEAR NOT CPRS,SYS 1	287T6205 81205	1	32-09-11 NOSE-/ /GEAR	ALL
D01756J		BACC63BV12S3SN RCPT-	81205	1	32-09-12 NOSE/ /GEAR	ALL
D01756P		BACC63BP12B3PNL PLUG PROX SNSR-NOSE GEAR NOT CPRS,SYS 2	287T6205 81205	1	32-09-12 NOSE/ /GEAR	ALL
D01758		BACS16X3A RELAY SOCKET-P19	81205	1	33-22-41 P019-00/ /	050-099
D01758		BACS16X3A RELAY SOCKET-	81205	1	33-22-41 P019-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D01700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01760		BACC45FT12-12S PLUG-	81205	1	33-22-41 0287/290/L070	ALL
D01762		BACC45FT12A12S PLUG-	81205	1	33-22-41 0336/288/R006	050-099
D01762		BACC45FT12A12S PLUG-	81205	1	33-22-41 0330/288/R006	150-199, 275-299
D01764		BACC45FT12A12S PLUG-	81205	1	33-22-41 0336/288/L006	050-099
D01764		BACC45FT12A12S PLUG-	81205	1	33-22-41 0330/288/L006	150-199, 275-299
D01766		BACC45FT12A12S PLUG-	81205	1	33-22-41 0336/288/0000	050-099
D01766		BACC45FT12A12S PLUG-	81205	1	33-22-41 0330/288/0000	150-199, 275-299
D01768		BACC45FT12A12S PLUG	81205	1	33-22-42 0821/284/L004	275-299
D01769		BACC66H21C01AA01 PLUG	71468	1	31-35-11 E002/02/	ALL
D01769A		PARTAOFD01769 PLUG- PART OF D01769		0	31-35-11 / /	ALL
D01769B		PARTBOFD01769 PLUG- PART OF D01769		0	31-35-11 / /	ALL
D01769C		PARTCOFD01769 PLUG- PART OFD01769		0	31-35-11 / /	ALL
D01770		BACC45FT12A12S PLUG	81205	1	33-22-42 0821/284/L008	275-299
D01776		BACC45FT12A12S PLUG-P5	81205	1	21-33-21 P005-00/ /	ALL
D01778		BACC45FT12A12S6 PLUG-P5	81205	1	21-33-21 P005-00/ /	ALL
D01784		BACS16X1A RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D01786		BACS16X1A RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D01700

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01790		BACC45FT12-12S PLUG-P11	81205	1	33-13-19 P011-00/ /	ALL
D01793		BACS16AG1 RELAY SOCKET-P36	81205	1	31-31-13 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D01700
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01800		35303-68 PLUG-	73168	1	26-18-11 0952/132/L034	ALL
D01804		BACS16X1A RELAY SOCKET-	81205	1	27-62-11 P033-00/ /	ALL
D01806		BACS16X1A RELAY SOCKET-	81205	1	27-62-11 P033-00/ /	ALL
D01830		BACC45FT18A14S PLUG-P8	81205	1	27-11-11 P008-00/ /	ALL
D01832		BACC45FT12A12S PLUG-P8	81205	1	27-28-13 P008-00/ /	ALL
D01834		BACS16X1A RELAY SOCKET-E6	81205	1	49-41-11 P049-00/ /	ALL
D01836		BACC66H21C08AA01 PLUG-	81205	1	27-51-11 SHELF/E02/04	050-099, 150-166, 277
D01836		BACC66H21C48AA01 PLUG-	81205	1	27-51-11 SHELF/E02/04	167-199, 275-276, 278-299
D01836A		PARTAOFD01836 PLUG-PART OF D01836		0	27-51-31 / /	ALL
D01836B		PARTBOFD01836 PLUG-PART OF D01836		0	27-51-11 / /	ALL
D01840		FRF6E10SL-3S01 PLUG	71468	1	36-22-21 NR269/146/	050-099, 150-199
D01840		FRF6E10SL-3S01 PLUG	71468	1	36-22-21 NR 269/146/	275-299
D01842		FRF6E10SL-3S01 PLUG	71468	1	36-22-21 NR269/146/	050-099, 150-199
D01842		FRF6E10SL-3S01 PLUG	71468	1	36-22-21 NR 269/146/	275-299
D01850		BACC63CE12SA3S PLUG-	81205	1	21-44-22 1518/169/R055	050-099
D01850		BACC63CE12SA3S PLUG-	81205	1	21-44-22 1513/170/R064	150-199
D01854		BACC45FN8-2S RCPT-	81205	1	35-21-14 716/280/L005	050-099

EQUIPMENT LIST

D280T132

Section D01800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01854		BACC45FN8-2S RCPT-	81205	1	35-21-14 0654+063/280/L005	275-299
D01855		BACC45FT10D5S PLUG	81205	1	23-34-18 624/150/R066	050-099, 278-299
D01855		BACC45FT10A5S PLUG	81205	1	23-34-18 624/150/R066	150-199, 275-277
D01856		BACC45FN8-2S RCPT-	81205	1	35-21-14 0743/280/L005	050-099
D01856		BACC45FN8-2S RCPT-	81205	1	35-21-14 0654+090/280/L005	275-299
D01857		BACC45FT10D5S PLUG-	81205	1	23-34-18 0624/150/R066	050-099, 278-299
D01857		BACC45FT10A5S PLUG-	81205	1	23-34-18 0624/150/R066	150-199, 275-277
D01858		BACC63BN10C5SN PLUG-	81205	1	27-38-11 RSS 127/12/TE	ALL
D01859		BACC45FT10D5P PLUG-	81205	1	23-34-18 0624/150/R066	ALL
D01860		BACC63BN10C5SN PLUG-	81205	1	27-38-11 RSS 127/12/TE	ALL
D01861		BACC45FT10D5P PLUG-	81205	1	23-34-18 624/150/R066	ALL
D01862		BACC45FT12A12P6 PLUG-	81205	6	23-31-15 MULTI/ /	050-099
D01862		BACC45FT12A12P6 PLUG-	81205	30	23-31-15 MULTI/ /	150-157
D01862		BACC45FT12A12P6 PLUG-	81205	9	23-31-15 MULTI/ /	162-199
D01863		BACC45FT14D15S PLUG-	81205	1	23-34-11 0624/150/R066	ALL
D01865		BACC45FT10A5P PLUG-	81205	1	23-34-19 624/150/R066	050-099, 150-199, 275-277
D01865		BACC45FT10D5P PLUG-	81205	1	23-34-19 624/150/R066	278-299

EQUIPMENT LIST

D280T132

Section D01800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01866		BACC63BP16R10SNL PLUG-	81205	1	27-23-11 1654/260/R035	ALL
D01866 T		BACC10KD16 CLAMP-	81205	1	27-23-11 / /	ALL
D01867		BACC45FT10D5S PLUG	81205	1	23-34-19 0624/150/R066	050-099, 278-299
D01867		BACC45FT10A5S PLUG	81205	1	23-34-19 0624/150/R066	150-199, 275-277
D01868		BACC65L41 RCPT-	81205	1	21-51-21 P050-00/ /	ALL
D01868 U		BACC47EM1 KEYING PLUG-	81205	2	21-51-21 / /	ALL
D01869		BACC45FT14A15S PLUG-	81205	1	23-34-11 627/160/R070	050-099, 150-199, 275-277
D01869		BACC45FT14D15S PLUG-	81205	1	23-34-11 627/160/R070	278-299
D01870		BACC65L41 RCPT-	81205	1	21-53-12 P050-00/ /	ALL
D01870 U		BACC47EM1 KEYING PLUG-	81205	2	21-53-12 / /	ALL
D01871		KM-59-41 PLUG-COAXIAL	91836	1	23-34-14 627/160/R070	ALL
D01872		BACC65L41 RCPT-	81205	1	21-61-51 P050-00/ /	ALL
D01872 U		BACC47EM1 KEYING PLUG-	81205	2	21-58-11 / /	ALL
D01873		KM-59-41 PLUG-COAXIAL	91836	1	23-34-18 627/160/R070	ALL
D01874		BACC65L41 RCPT-	81205	1	21-25-21 P050-00/ /	ALL
D01874 U		BACC47EM1 KEYING PLUG-	81205	2	21-25-21 / /	ALL
D01875		KM-59-41 PLUG-COAXIAL	91386	1	23-34-19 627/160/R070	ALL

EQUIPMENT LIST

D280T132

Section D01800

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01876		BACC65L66 RCPT-	81205	1	36-11-52 P050-00/ /	ALL
D01876 U		BACC47EM1 KEYING PLUG-	81205	2	36-11-52 / /	ALL
D01877		KM-59-41 PLUG-C0AXIAL	91836	1	23-34-18 0627/160/R070	ALL
D01879		BACC45FT22C55S PLUG-	81205	1	23-34-14 296/147/R 21	ALL
D01880		BACC45FN8A2S RCPT-	81205	1	35-21-12 0346/236/L050	275-299
D01881		BACS16X1A RELAY SOCKET	81205	1	23-34-12 P033-00/ /	050-099
D01881		BACS16X1A RELAY SOCKET-	81205	1	23-34-12 P033-00/ /	150-199, 275-299
D01882		BACC65L41 RCPT-	81205	1	28-21-12 P050-00/ /	ALL
D01882 U		BACC47EM1 KEYING PLUG-	81205	2	28-21-12 / /	ALL
D01883		MB6R-3 RCPT-	09922	1	23-34-18 1105/210/R090	050-099
D01883		MB6R-3 RCPT-	09922	1	23-34-18 989/210/R090	150-199, 275-278
D01883		MB6R-3 RCPT-	09922	1	23-34-18 0989/210/R090	280-299
D01883 T		KIT700-43 COAX CONTACT	09922	1	23-34-18 / /	ALL
D01883 U		204A121-3-01 SHRINK BOOT	06090	1	23-34-18 / /	ALL
D01885		MB6R-3 RCPT	81205	1	23-34-18 1105/210/L090	050-099
D01885		MB6R-3 RCPT	81205	1	23-34-18 0980/210/L090	150-199, 275-278
D01885		MB6R-3 RCPT	81205	1	23-34-18 0989/210/L090	280-299

EQUIPMENT LIST

D280T132

Section D01800

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01885 T		KIT700-43 COAX CONTACT	09922	1	23-34-18 / /	ALL
D01885 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-18 / /	ALL
D01886		BACC65L66 RCPT-	81205	1	36-11-51 P050-00/ /	ALL
D01886 U		BACC47EM1 KEYING PLUG-	81205	2	36-11-51 / /	ALL
D01887		KM-59-41 PLUG-COAXIAL	91836	1	23-34-14 0310/195/R035	ALL
D01888		BACC63BP16R10SNL PLUG-	81205	1	27-23-11 1702/255/L070	ALL
D01888 T		BACC10KE16 CLAMP-	81205	1	27-23-11 / /	ALL
D01890		BACC63BP16R10SNL PLUG-	81205	1	27-23-11 1656/235/L065	ALL
D01890 T		BACC10KD16 CLAMP-	81205	1	27-23-11 / /	ALL
D01892		BACC63BN10C5SN PLUG-	81205	1	27-28-11 FSS 170/ /TE	ALL
D01894		BACC63BP18A14S9L PLUG-	81205	1	27-21-11 FSS 118/ /TE	050-099
D01894		BACC63BP18R14SNL PLUG-	81205	1	27-21-11 FSS 118/ /TE	150-154, 162-165, 275-276
D01894		BACC63BP18A14SNL PLUG-	81205	1	27-21-11 FSS 118/ /TE	155-157, 166-199, 277-299
D01894 T		BACC10KD18 CLAMP-	81205	1	27-21-11 / /	ALL
D01898	1	CWC02-2006 PLUG-	71771	1	30-41-11 0154/268/L020	ALL
D01898	2	WB1230 PLUG-	81323	1	30-41-11 0154/268/L020	ALL
D01898 T	2	1235 CAP-	81323	1	30-41-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D01800

Page 5 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01900	1	CWC02-2006 PLUG-	71771	1	30-41-11 0154/268/L020	ALL
D01900	2	WB1230 PLUG-	81323	1	30-41-11 0154/268/L020	ALL
D01900 T	2	1235 CAP-	81323	1	30-41-11 / /	ALL
D01902	1	CWC02-2006 PLUG-	71771	1	30-41-11 0175/268/R056	ALL
D01902	2	WB1230 PLUG-	81323	1	30-41-11 0175/268/R056	ALL
D01902 T	2	1235 CAP-	81323	1	30-41-11 / /	ALL
D01904	1	CWC02-2006 PLUG-	71771	1	30-41-11 0175/268/R056	ALL
D01904	2	WB1230 PLUG-	81323	1	30-41-11 0175/268/R056	ALL
D01904 T	2	1235 CAP-	81323	1	30-41-11 / /	ALL
D01906	1	CWC02-2010 PLUG-	71771	1	30-41-11 0175/268/R056	ALL
D01906	2	WB1220 PLUG-	81323	1	30-41-11 0175/268/R056	ALL
D01906 T	2	1225 CAP-	81323	1	30-41-11 / /	ALL
D01908	1	CWC02-2006 PLUG-	71771	1	30-41-11 0212/268/R060	ALL
D01908	2	WB1230 PLUG-	81323	1	30-41-11 0212/268/R060	ALL
D01908 T	2	1235 CAP-	81323	1	30-41-11 / /	ALL
D01910	1	CWC02-2006 PLUG-	71771	1	30-41-11 0212/268/R060	ALL
D01910	2	WB1230 PLUG-	81323	1	30-41-11 0212/268/R060	ALL

EQUIPMENT LIST

D280T132

Section D01900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01910 T	2	1235 CAP-	81323	1	30-41-11 / /	ALL
D01912	1	CWC02-2006 PLUG-	71771	1	30-41-12 0154/268/R020	ALL
D01912	2	WB1230 PLUG-	81323	1	30-41-12 0154/268/R020	ALL
D01912 T	2	1235 CAP-	81323	1	30-41-12 / /	ALL
D01914	1	CWC02-2006 PLUG-	71771	1	30-41-12 0154/268/R020	ALL
D01914	2	WB1230 PLUG-	81323	1	30-41-12 0154/268/R020	ALL
D01914 T	2	1235 CAP-	81323	1	30-41-12 / /	ALL
D01916	1	CWC02-2006 PLUG-	71771	1	30-41-12 0196/264/L046	ALL
D01916	2	WB1230 PLUG-	81323	1	30-41-12 0196/264/L046	ALL
D01916 T	2	1235 CAP-	81323	1	30-41-12 / /	ALL
D01918	1	CWC02-2006 PLUG-	71771	1	30-41-12 0196/264/L046	ALL
D01918	2	WB1230 PLUG-	81323	1	30-41-12 0196/264/L046	ALL
D01918 T	2	1235 CAP-	81323	1	30-41-12 / /	ALL
D01920	1	CWC02-2010 PLUG-	71771	1	30-41-12 0196/264/L046	ALL
D01920	2	WB1220 PLUG-	81323	1	30-41-12 0196/264/L046	ALL
D01920 T	2	1225 CAP-	81323	1	30-41-12 / /	ALL
D01921		BACC63BP12B3SNL PLUG	81205	1	31-31-22 1043/183/R 77	ALL

EQUIPMENT LIST

D280T132

Section D01900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01921 T		710AS011M1209-62A ADP	06324	1	31-31-22 1042/181/R 78	ALL
D01922	1	CWC02-2006 PLUG-	71771	1	30-41-12 0212/268/L035	ALL
D01922	2	WB1230 PLUG-	81323	1	30-41-12 0212/268/L035	ALL
D01922 T	2	1235 CAP-	81323	1	30-41-12 / /	ALL
D01923		BACC63BP12B3SNL PLUG	81205	1	31-31-22 1041/188/L084	ALL
D01923 T		710AS011M1209-62A ADP	06324	1	31-31-22 1041/188/L084	ALL
D01924	1	CWC02-2006 PLUG-	71771	1	30-41-12 0212/268/L060	ALL
D01924	2	WB1230 PLUG-	81323	1	30-41-12 0212/268/L060	ALL
D01924 T	2	1235 CAP-	81323	1	30-41-12 / /	ALL
D01926		BACS16X1A RELAY SOCKET-	81205	1	27-81-11 P037-00/ /	ALL
D01927		280U0013-1 PLUG- MOA PER DWG REF:BACC45FT18-8S	81205	1	23-32-13 255/268/L 10	275-299
D01928		BACC45FT14A15S6 PLUG-P61	81205	1	26-21-11 P061-00/ /	ALL
D01929		BACC45FT18-31S PLUG	81205	1	23-32-11 255/268/L 10	275-299
D01930		BACC45FT14A15S7 PLUG-P61	81205	1	26-21-11 P061-00/ /	ALL
D01931		BACC45FT22-55S PLUG	81205	1	23-32-11 255/268/L 10	275-299
D01933		BACC45FT20-41S PLUG	81205	1	23-32-11 255/268/L 10	275-299
D01934J		BACC45FM12C3S RCPT-	81205	1	32-61-12 1010/175/R068	ALL

EQUIPMENT LIST

D280T132

Section D01900

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01934P		BACC63BP12A3PNL PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-12 / /	ALL
D01935	9	RM3P32C2S67S32C2S-0001 PLUG PLATE ASSY	71468	1	23-32-21 SHELF/E01/04	150, 152-199
D01935		DSX2H23S27S0001 PLUG PLATE ASSY	71468	1	23-32-21 SHELF/E01/-4	050-099, 151, 275-299
D01935A	9	PARTAOFD01935 PLUG PART OF D01935	71468	1	23-32-21 SHELF/E01/04	150, 152-199
D01935A		PARTAOFD01935 PLUG PART OF D01935		0	23-32-21 / /	050-099, 151, 275-299
D01935B	9	PARTBOFD01935 PLUG PART OF D01935	71468	1	23-32-21 SHELF/E01/04	150, 152-199
D01935B		PARTBOFD01935 PLUG PART OF D01935		0	23-32-21 / /	050-099, 151, 275-299
D01935C	9	PARTCOFD01935 PLUG PART OF D01935	71468	1	23-32-21 SHELF/E01/04	150, 152-199
D01937		BACC45FT12A12S PLUG-MODAL SUPPRESSION ACCELEROMETER	81205	1	22-21-11 1512/195/L70	150-199, 275-299
D01938J		BACC45FM12C3S7 RCPT-	81205	1	32-61-11 999/193/L064	ALL
D01938P		BACC63BP12A3P7L PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-11 / /	ALL
D01939		BACC45FT12A12S PLUG-MODAL SUPPRESSION ACCELEROMETER	81205	1	22-21-21 1518/195/R70	150-199, 275-299
D01941		DAMA11W1S PLUG	71468	1	23-32-54 864/260/R 70	280-299
D01941 T		DA20961 JUNCTION SHELL	71468	1	23-32-54 864/260/R 70	280-299
D01941 U		D110278 LATCH	71468	2	23-32-54 / /	280-299
D01941 V		DMA43716-6 COAX CONTACT PIN	81205	1	23-32-54 864/260/R 70	280-299
D01942J		BACC45FM12C3S7 RCPT-	81205	1	32-61-12 999/193/R064	ALL

EQUIPMENT LIST

D280T132

Section D01900

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01942P		BACC63BP12A3P7L PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-11 / /	ALL
D01943		DAMA11W1S PLUG	71468	1	23-32-54 864/260/L 70	280-299
D01943 T		DA20961 JUNCTION SHELL	71468	1	23-32-54 864/260/L 70	280-299
D01943 U		D110278 LATCH	71468	2	23-32-54 / /	280-299
D01943 V		DMA43716-6 COAX CONTACT - PIN	71468	1	23-32-54 864/260/L 70	280-299
D01946J		BACC45FM12C3S RCPT-	81205	1	32-61-11 1000/190/L068	ALL
D01946P		BACC63BP12A3PNL PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-11 / /	ALL
D01948		BACS16X1A RELAY SOCKET-	81205	1	33-42-21 P036-00/ /	ALL
D01950J		BACC45FM12C3S9 RCPT-	81205	1	32-61-13 0280/160/R023	ALL
D01950P		BACC63BP12A3P9L PLUG - VENDOR PIGTAIL	287T6205 81205	1	32-61-13 / /	ALL
D01952J		BACC63BV12S3S6 RCPT-	81205	1	32-61-13 AL0202/ /	ALL
D01952P		BACC63BP12B3P6L PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-13 0280/120/R025	ALL
D01954J		BACC45FM12C3S RCPT-	81205	1	32-61-13 0170/150/L022	ALL
D01954P		BACC63BP12A3PNL PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-13 0183/120/L025	ALL
D01956J		BACC45FM12C3S7 RCPT-	81205	1	32-61-13 0280/160/R023	ALL
D01956P		BACC63BP12A3P7L PLUG - VENDOR PIGTAIL	287T6205 81205	1	32-61-13 / /	ALL
D01958J		BACC63BV12B3S8 RCPT	81205	1	32-61-13 280/160/R023	ALL

EQUIPMENT LIST

D280T132

Section D01900

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01958JK		BACC10KA12 CLAMP	81205	1	32-61-13 280/160/R023	050-099
D01958P		BACC63BP12B3P8L PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-13 / /	ALL
D01960J		BACC45FM12C3S7 RCPT-	81205	1	32-61-13 0170/164/L002	ALL
D01960P		BACC63BP12A3P7L PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-13 / /	ALL
D01962		BACC45FN14-15S RCPT-	81205	1	25-53-15 0478/124/L027	050-099
D01962		BACC45FN14-15S RCPT-	81205	1	25-53-15 0485/124/L033	150-199, 275-299
D01964		BACC45FN14-15S RCPT-	81205	1	25-53-16 0478/124/L001	050-099
D01964		BACC45FN14-15S RCPT-	81205	1	25-53-16 0485/124/L003	150-199, 275-299
D01966		BACC45FN14-15S RCPT-	81205	1	25-53-15 0485/124/R025	050-099
D01966		BACC45FN14-15S RCPT-	81205	1	25-53-15 0485/124/R033	150-199, 275-299
D01968		BACC45FN14-15S RCPT-	81205	1	25-53-15 0530/124/L034	050-099
D01968		BACC45FN14-15S RCPT-	81205	1	25-53-15 0546/124/L032	150-199, 275-299
D01970		BACC45FN14-15S RCPT-	81205	1	25-53-15 0546/124/L003	050-099
D01970		BACC45FN14-15S RCPT-	81205	1	25-53-15 0546/124/R003	150-199, 275-299
D01972		BACC45FN14-15S RCPT-	81205	1	25-53-15 0546/124/R029	050-099
D01972		BACC45FN14-15S RCPT-	81205	1	25-53-15 546/124/R025	150-199, 275-299
D01974		BACC45FN14-15S RCPT-	81205	1	25-53-16 0504/124/L011	ALL

EQUIPMENT LIST

D280T132

Section D01900

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01976		BACC45FN14-15S RCPT-	81205	1	25-53-16 0530/124/R006	050-099
D01976		BACC45FN14-15S RCPT-	81205	1	25-53-16 0530/124/L010	150-199, 275-299
D01978		BACC45FN14-15S RCPT-	81205	1	25-53-16 0504/124/R014	050-099
D01978		BACC45FN14-15S RCPT-	81205	1	25-53-16 0504/124/R003	150-199, 275-299
D01980		BACC45FN14-15S RCPT-	81205	1	25-53-16 0530/124/R014	050-099
D01980		BACC45FN14-15S RCPT-	81205	1	25-53-16 0530/124/R003	150-199, 275-299
D01982		BACC45FT12A12S PLUG-	81205	1	33-21-33 0622/288/R056	050-099, 150-165, 167-199, 275-278
D01982		BACC45FT12A12S PLUG-	81205	1	33-21-33 0622/295/R056	166
D01982		BACC45FT12A12S PLUG-	81205	1	33-21-33 0625/289/R056	280-299
D01983		BACS16X1A RELAY SOCKET	81205	1	36-11-61 P036-00/ /	050-099, 275-276
D01983		BACS16X1A RLY SKT	81205	1	36-11-61 P036-00/ /	150-156, 162-166
D01984		BACC45FT12A12S PLUG-	81205	1	33-21-34 1275/290/L056	050-099, 150-165, 167-199, 275-299
D01984		BACC45FT12A12S PLUG-	81205	1	33-21-34 1275/295/L056	166
D01986		BACC45FT12A12S PLUG-	81205	1	33-21-34 1363/290/L056	050-099, 150-165, 167-199, 275-299
D01986		BACC45FT12A12S PLUG-	81205	1	33-21-34 1363/295/L056	166
D01988		BACC45FT12A12S PLUG-	81205	1	33-21-34 1099/290/L056	050-099
D01988		BACC45FT12A12S PLUG-	81205	1	33-21-34 1006/290/L056	150-199

EQUIPMENT LIST

D280T132

Section D01900

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D01988		BACC45FT12A12S PLUG-	81205	1	33-21-34 1055/290/L056	275-299
D01989		BACS16X1A RELAY SOCKET	81205	1	36-11-61 P036-00/ /	050-099, 275-276
D01989		BACS16X1A RLY SKT	81205	1	36-11-61 P036-00/ /	150-156, 162-166
D01991		BACS16X1A RELAY SOCKET	81205	1	36-11-61 P036-00/ /	050-099, 275-276
D01991		BACS16X1A RLY SKT	81205	1	36-11-61 P036-00/ /	150-156, 162-166
D01992		BACC63BP12R3SNL PLUG-	81205	1	32-41-11 1050/120/R005	ALL
D01992 T		710AA011M1209-62A ADAPTER-90 DEGREES	06324	1	32-41-11 / /	ALL
D01993		BACS16X1A RELAY SOCKET	81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166, 275-276
D01994		BACC45FT10A5S8 PLUG-	81205	1	52-34-11 0548/130/R058	050-099
D01994		BACC45FT10A5S8 PLUG-	81205	1	52-34-11 D0504/183/R084	150-199, 275-299
D01996		BACC45FT14A7S PLUG-	81205	1	52-34-11 0548/130/R058	ALL
D01998		BACC45FT10A5S PLUG-	81205	1	52-35-11 1300/200/R089	ALL
D01999		BACS16X1A RELAY SOCKET	81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166, 275-276

EQUIPMENT LIST

D280T132

Section D01900

Page 8 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02000		BACC45FT10A5S PLUG-	81205	1	52-35-11 DR 190/170/R080	ALL
D02001		BACS16X1A RELAY SOCKET	81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166, 275-276
D02002		BACC45FT12A12S PLUG-	81205	1	33-21-34 0923/290/L056	050-099
D02002		BACC45FT12A12S PLUG-	81205	1	33-21-34 0908/288/L056	150-165, 167-199
D02002		BACC45FT12A12S PLUG-	81205	1	33-21-34 0908/295/L056	166
D02002		BACC45FT12A12S PLUG-	81205	1	33-21-34 0880/290/L056	275-299
D02004		BACC45FT12A12S PLUG-	81205	1	33-21-34 1187/290/L056	050-099
D02004		BACC45FT12A12S PLUG-	81205	1	33-21-34 1143/290/L056	150-199, 275-299
D02006		BACC45FT12A12S PLUG-	81205	1	33-21-34 1391/295/L056	050-099, 162-199
D02006		BACC45FT12A12S PLUG-	81205	1	33-21-34 1428/295/L056	150-157, 275-299
D02008		BACC45FT12A12S PLUG-	81205	1	33-21-33 842/288/R056	150-165, 167-199
D02008		BACC45FT12A12S PLUG-	81205	1	33-21-33 842/295/R056	166
D02010		BACC45FT12A12S PLUG-	81205	1	33-21-35 0879/280/R056	050-099
D02010		BACC45FT12A12S PLUG-	81205	1	33-21-35 0923/288/R056	150-165, 167-199
D02010		BACC45FT12A12S PLUG-	81205	1	33-21-35 0923/295/R056	166
D02010		BACC45FT12A12S PLUG-	81205	1	33-21-35 0961/288/R056	275-299
D02012		BACC63BP12R3SNL PLUG-	81205	1	32-42-11 WHEEL/01/L GR	ALL

EQUIPMENT LIST

D280T132

Section D02000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02012	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02014		BACC63BP12R3SNL PLUG-	81205	1	32-42-11 WHEEL/02/L GR	ALL
D02014	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02016		BACC63BP12R3SNL PLUG-	81205	1	32-42-11 WHEEL/05/L GR	ALL
D02016	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02018		BACC63BP12R3SNL PLUG-	81205	1	32-42-11 WHEEL/06/L GR	ALL
D02018	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02020		BACC63BP12R3SNL PLUG-	81205	1	32-42-11 WHEEL/03/R GR	ALL
D02020	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02022		BACC63BP12R3SNL PLUG-	81205	1	32-42-11 WHEEL/04/R GR	ALL
D02022	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02024		BACC63BP12R3SNL PLUG-	81205	1	32-42-11 WHEEL/07/R GR	ALL
D02024	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02026		BACC63BP12R3SNL PLUG-	81205	1	32-42-11 WHEEL/08/R GR	ALL
D02026	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02028		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 L0345/12/TE	ALL
D02028	T	BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D02000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02030		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 L0345/12/TE	ALL
D02030 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02031		BACC45FT12A12S PLUG	81205	1	23-32-11 599/308/R 36	050-099
D02031		BACC45FT12A12S PLUG-	81205	1	23-32-13 621/308/R 36	150-199
D02032		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 L0345/12/TE	ALL
D02032 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02033		KC-59-585-M06 PLUG-COAXIAL	81205	1	23-32-13 599/308/R 36	050-099
D02033		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 621/308/R 36	150-199
D02034		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 L0345/12/TE	ALL
D02034 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02035		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 599/308/R 36	050-099, 150-199
D02036		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 R0345/12/ET	ALL
D02036 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02037		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 599/308/R 36	150-199
D02038		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 R0365/12/TE	ALL
D02038 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02039		MS3126F14-12P PLUG	91836	1	23-32-11 599/308/R 36	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D02000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02040		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 R0365/12/ET	ALL
D02040 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02041		MS3126F14-12P PLUG	91836	1	23-32-11 599/308/R 36	150-199
D02042		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 R0365/12/TE	ALL
D02042 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02043		BACC45FT12A12S PLUG	81205	1	23-32-11 1186/308/R 36	150-199
D02044		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 L0345/12/TE	ALL
D02044 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	155-157, 166-199, 277-299
D02045		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 1186/308/R 36	150-199
D02046		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 L0345/12/TE	ALL
D02046 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02047		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 1186/308/R035	150-199
D02048		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 R0420/12/ET	ALL
D02048 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL
D02049		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 1186/308/R036	150-199
D02050		BACC63BP12A3SNL PLUG-	81205	1	32-42-11 R0350/14/TE	ALL
D02050 T		BACC10KD12 CLAMP-	81205	1	32-42-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D02000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02051		MS3126F14-12P PLUG	91836	1	23-32-11 1186/308/R036	150-199
D02052		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 716/280/L005	050-099
D02052		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0654+063/280/L005	275-299
D02053		MS3126F14-12P PLUG	91836	1	23-32-11 1186/308/R036	150-199
D02054		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 743/280/L005	050-099
D02054		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0654+090/280/L005	275-299
D02056		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0768/280/L005	150-199
D02056		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 0768/280/L005	275-299
D02058		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0790/280/L005	150-199
D02064		BACC63BP10A5S10L PLUG-SQUIB	81205	1	26-22-21 1820/200/L025	275-299
D02064 T		BACC10KD10 CLAMP-	81205	1	26-22-21 / /	275-299
D02066		BACC63BP10A5S7L PLUG-PRESSURE SW	81205	1	26-22-21 1820/200/L025	275-299
D02066 T		BACC10KD10 CLAMP-	81205	1	26-22-21 / /	275-299
D02070		BACC63BP18R8SNL PLUG-	81205	1	33-43-11 R1140/12/TIP	ALL
D02070 T		BACC10KD18 CLAMP-	81205	1	33-43-11 / /	ALL
D02071		BACC45FT12-12S PLUG	81205	1	23-32-52 996/280/R 38	275-299
D02073		BACC45FT12-12S PLUG	81205	1	23-32-52 0996/280/L038	275-299

EQUIPMENT LIST

D280T132

Section D02000

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02074		BACC63BP18R8SNL PLUG-	81205	1	33-43-11 L1150/12/TIP	ALL
D02074 T		BACC10KD18 CLAMP-	81205	1	33-43-11 / /	ALL
D02075		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-52 0996/280/R038	275-299
D02077		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-52 996/280/L 38	275-299
D02078		BACC63BP14R4SNL PLUG-	81205	1	33-43-11 L1140/12/TIP	ALL
D02078 T		BACC10KD14 CLAMP-	81205	1	33-43-11 / /	ALL
D02080		BACC63BP14R4SNL PLUG-	81205	1	33-43-11 R1140/12/TIP	ALL
D02080 T		BACC10KD14 CLAMP-	81205	1	33-43-11 / /	ALL
D02082		BACC63BP14R4SNL PLUG-	81205	1	33-43-11 L1165/12/TIP	ALL
D02082 T		BACC10KD14 CLAMP-	81205	1	33-43-11 / /	ALL
D02083		BACC45FT16A24S PLUG	81205	1	73-21-11 PANEL/5/	ALL
D02084		BACC63BP14R4SNL PLUG-	81205	1	33-43-11 R1165/12/TIP	ALL
D02084 T		BACC10KD14 CLAMP-	81205	1	33-43-11 / /	ALL
D02085		BACC45FT16A24S7 PLUG	81205	1	73-21-11 PANEL/5/	ALL
D02087		BACC63BP16A10SNL PLUG	81205	1	29-11-14 1723/274/R044	ALL
D02087 T		BACC10KD16 CLAMP	81205	1	29-11-14 / /	ALL
D02088		BACS16X1A RELAY SOCKET-	81205	1	27-51-51 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D02000

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02089		BACC63BP16A10SNL PLUG	81205	1	29-11-14 1704/286/L034	ALL
D02089 T		BACC10KD16 CLAMP	81205	1	29-11-14 1704/286/L030	ALL
D02094		BACC45FT12A12S PLUG-	81205	1	33-21-35 1099/288/R056	050-099
D02094		BACC45FT12A12S PLUG-	81205	1	33-21-35 1055/288/R056	150-165, 167-199, 275-299
D02094		BACC45FT12A12S PLUG-	81205	1	33-21-35 1055/295/R056	166
D02096		BACC45FT12A12S PLUG-	81205	1	33-21-35 1187/288/R056	050-099
D02096		BACC45FT12A12S PLUG-	81205	1	33-21-35 1143/288/R056	150-165, 167-199, 275-299
D02096		BACC45FT12A12S PLUG-	81205	1	33-21-35 1143/295/R056	166
D02098		BACC45FT12A12S PLUG-	81205	1	33-21-35 1275/284/R056	050-099, 150-165, 167-199, 275-299
D02098		BACC45FT12A12S PLUG-	81205	1	33-21-35 1275/295/R056	166

EQUIPMENT LIST

D280T132

Section D02000
Page 7 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02100		BACC45FT12A12S PLUG-	81205	1	33-21-35 1363/288/R056	050-099, 150-165, 167-199, 275-299
D02100		BACC45FT12A12S PLUG-	81205	1	33-21-35 1363/295/R056	166
D02103		DAMA11W1S PLUG	71468	1	23-32-33 0386/260/L070	275-299
D02103 T		DA20961 JUNCTION SHELL	71468	1	23-32-33 0386/260/L070	275-299
D02103 U		D110278 LATCH	71468	2	23-32-33 / /	275-299
D02103 V		DMA43716-6 COAX CONTACT PIN	71468	1	23-32-33 0386/260/L070	275-299
D02107		DAMA11W1S PLUG	71468	1	23-32-33 386/260/R 70	275-299
D02107 T		DA20961 JUNCTION SHELL	71468	1	23-32-33 / /	275-299
D02107 U		D110278 LATCH	71468	2	23-32-33 / /	275-299
D02107 V		DMA43716-6 COAX CONTACT	71468	1	23-32-33 / /	275-299
D02110		BACC45FT12A12S PLUG-	81205	1	33-21-33 0439/288/R056	050-099
D02110		BACC45FT12A12S PLUG-	81205	1	33-21-33 0446/288/R056	150, 153-157
D02110		BACC45FT12A12S PLUG-	81205	1	33-21-33 0440/288/R056	151-152, 162-165, 167-199, 275-278
D02110		BACC45FT12A12S PLUG-	81205	1	33-21-33 0440/295/R056	166
D02110		BACC45FT12A12S PLUG-	81205	1	33-21-33 0430/291/R056	280-299
D02112		BACC45FT14A7S PLUG-	81205	1	33-42-21 0764/140/L070	ALL
D02114		BACC45FT14A7S PLUG-	81205	1	33-42-21 0764/165/R070	ALL

EQUIPMENT LIST

D280T132

Section D02100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02118		BACC63BP12A3S6L PLUG-	86168	1	78-34-11 NL260/155/	ALL
D02118 T		BACC10KD12 CLAMP-	81205	1	78-34-11 / /	ALL
D02118 U		BACC47CP2T CONTACT SOCKET	81205	3	78-34-11 / /	ALL
D02120	1	BACC63BP12A3S6L PLUG-	81205	1	78-34-21 NR255/160/	ALL
D02120	2	CN0966-12A03S6-000 PLUG-	86168	1	78-34-21 NR255/160/	ALL
D02120 T		BACC10KD12 CLAMP-	81205	1	78-34-21 / /	ALL
D02120 U		BACC47CP2T CONTACT SOCKET	81205	3	78-34-11 / /	ALL
D02132		10-60450-5 RELAY SOCKET	81205	1	21-24-11 P036-00/ /	050-099, 150-199
D02134		BACC63BP12A3SNL PLUG-	81205	1	78-36-11 NL260/155/	ALL
D02134 T		BACC10KE12 CLAMP-	81205	1	78-36-11 / /	ALL
D02138		BACC63BP12A3SNL PLUG-	81205	1	78-36-21 NR255/160/	ALL
D02138 T		BACC10KD12 CLAMP-	81205	1	78-36-21 / /	ALL
D02142		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0882/119/R030	ALL
D02144		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0882/119/L047	150-199, 275-299
D02144	1	BACC63BW12SC3S PLUG-	81205	1	21-52-31 0882/119/L047	050-099
D02144	2	FH3406D PLUG-	28680	1	21-52-31 0882/119/L047	050-099
D02144 T	2	BACC10GL12 CLAMP-	81205	1	21-52-31 / /	050-099

EQUIPMENT LIST

D280T132

Section D02100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02152		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0871/124/L056	150-199, 275-299
D02152	1	BACC63BW12SC3S PLUG-	81205	1	21-52-31 0871/124/L056	050-099
D02152	2	FH3406D PLUG-	28680	1	21-52-31 0871/124/L056	050-099
D02152 T	2	BACC10GL12 CLAMP-	81205	1	21-52-31 / /	050-099
D02154		BACC63CE12SA3S PLUG-	81205	1	21-52-31 0870/130/R055	ALL
D02156		BACS16W3 PLUG-P11	81205	1	74-31-11 P011-00/ /	ALL
D02158		BACS16W3 PLUG-P11	81205	1	74-31-11 P011-00/ /	ALL
D02160		BACC65L66 RCPT-	81205	1	73-21-11 P050-00/ /	ALL
D02160 U		BACC47EM1 KEYING PLUG-	81205	2	73-21-11 / /	ALL
D02162		BACC65L66 RCPT-	81205	1	73-21-11 P050-00/ /	ALL
D02163		DAMA11W1S PLUG	71468	1	23-32-34 0472/260/0	275-276
D02163		DAMA11W1S PLUG	71468	1	23-32-34 0376/260/0	277-278
D02163		DAMA11W1S PLUG	71468	1	23-32-34 0524/258/R005	280-299
D02163 T		DA20961 JUNCTION SHELL	71468	1	23-32-34 472/260/0	275-278
D02163 T		DA20961 JUNCTION SHELL	71468	1	23-32-34 522/260/R 70	280-299
D02163 U		D110278 LATCH	71468	2	23-32-34 / /	275-299
D02163 V		DMA43716-6 COAX CONTACT PIN	81205	1	23-32-34 472/260/0	275-278

EQUIPMENT LIST

D280T132

Section D02100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02163 V		DMA43716-6 COAX CONTACT - PIN	81205	1	23-32-34 522/260/R 70	280-299
D02164		BACC45FT12A12S PLUG-	81205	1	33-21-32 0534/290/L065	050-099, 150-165, 167-199, 275-278
D02164		BACC45FT12A12S PLUG-	81205	1	33-21-32 0534/295/L065	166
D02164		BACC45FT12A12S PLUG-	81205	1	33-21-32 0537/290/L056	280-299
D02164 V		289T0183-10201 I.D.TAPE TEXT AS BELOW	81205	1	33-21-32 0534/290/L065	162-163
D02165		BACC45FT12-12S PLUG	81205	1	23-32-34 376/260/0	275-278
D02165		DAMA11W1S PLUG	71468	1	23-32-34 378/258/R005	280-299
D02165 T		DA20961 JUNCTION SHELL	71468	1	23-32-34 376/260/00	280-299
D02165 U		D110278 LATCH	71468	2	23-32-34 //	280-299
D02165 V		DMA43716-6 COAX CONTACT - PIN	71468	1	23-32-34 376/260/00	280-299
D02166		BACC66K31C03AA01 PLUG-	81205	1	27-88-11 SHELF/E01/02	ALL
D02166A		PARTAOFD02166 PLUG-PART OF D02166		0	32-42-11 //	ALL
D02166B		PARTBOFD02166 PLUG-PART OF D02166		0	32-42-11 //	ALL
D02166C		PARTCOFD02166 PLUG-PART OF D02166		0	27-51-51 //	ALL
D02166D		PARTDOFD02166 PLUG-PART OF D02166		0	31-51-59 //	ALL
D02166E		PARTEOFD02166 PLUG-PART OF D02166		0	31-51-59 //	ALL
D02166F		PARTFOFD02166 PLUG-PART OF D02166		0	27-88-11 //	ALL

EQUIPMENT LIST

D280T132

Section D02100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02167		BACC45FT12-12S PLUG	81205	1	23-32-43 555/295/R043	280-299
D02168		BACC45FT12A12S PLUG-	81205	1	33-21-32 0622/290/L065	050-099, 150-165, 167-199, 275-278
D02168		BACC45FT12A12S PLUG-	81205	1	33-21-32 0622/295/L065	166
D02168		BACC45FT12A12S PLUG-	81205	1	33-21-32 0625/289/L056	280-299
D02169		DAMA11W1S PLUG	71468	1	23-32-43 543/260/0	275-278
D02169		BACC45FT12-12S PLUG	81205	1	23-32-43 555/295/L036	280-299
D02169 T		DA20961 JUNCTION SHELL	71468	1	23-32-43 543/260/0	275-278
D02169 U		D110278 LATCH	71468	2	23-32-43 / /	275-278
D02169 V		DMA43716-6 COAX CONTACT PIN	71468	1	23-32-43 543/260/0	275-278
D02170		BACC45FT12A12S PLUG-	81205	1	33-21-32 0710/290/L065	050-099
D02170		BACC45FT12A12S PLUG-	81205	1	33-21-32 0738/288/L056	150-165, 167-199
D02170		BACC45FT12A12S PLUG-	81205	1	33-21-32 0738/295/L056	166
D02170		BACC45FT12A12S PLUG-	81205	1	33-21-32 0660/290/L065	275-278
D02170		BACC45FT12A12S PLUG-	81205	1	33-21-32 0681/284/L056	280-299
D02171		BACC45FT12-12S PLUG	81205	1	23-32-62 1392/280/R 38	275-299
D02173		BACC45FT12-12S PLUG	81205	1	23-32-62 1392/280/L 38	275-299
D02176		BACC65L41 RCPT-	81205	1	21-58-15 AE0202/ /	ALL

EQUIPMENT LIST

D280T132

Section D02100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02176	U	BACC47EM1 KEYING PLUG-	81205	2	21-58-15 / /	ALL
D02177		KC-59-585-M06 PLUG	91836	1	23-32-34 376/260/0	275-278
D02178		BACC45FT18B14S6 PLUG-A4 AFT GALLEY	81205	1	25-31-21 1507/280/L004	275-278
D02178		BACC45FT18C14S PLUG-A4 AFT GALLEY	81205	1	25-31-21 1507/280/L004	280-299
D02179		KC-59-585-M06 PLUG- COAXIAL	91836	1	23-32-43 555/295/R043	280-299
D02181		KC-59-585-M06 PLUG- COAXIAL	91836	1	23-32-43 555/295/L036	280-299
D02183		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-62 1392/280/R 38	275-299
D02185		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-62 1392/280/L 38	275-299
D02187		MS3126F10-6S PLUG -RF SWITCH	91836	1	34-53-13 331/136/R042	ALL
D02189		KA-59-353-M06 PLUG-COAX	91836	1	34-53-13 331/132/R042	050-099
D02189		KA-59-353-M06 PLUG-COAX	91836	1	34-53-13 331/136/R042	150-199, 275-299
D02190		BACC63BP12R3S9L PLUG-	81205	1	32-42-12 1045/188/L082	ALL
D02190	T	710AS011M1209-62A ADAPTER-	06324	1	32-42-12 / /	ALL
D02191		KN-59-329-M06 PLUG	91836	1	34-53-13 331/136/R042	ALL
D02192		BACC63BP12R3S9L PLUG-	81205	1	32-42-12 1045/188/R082	ALL
D02192	T	710AS011M1209-62A ADAPTER-	06324	1	32-42-12 / /	ALL
D02193		KD-59-180-M06 PLUG-COAX	91836	1	34-53-13 331/136/R042	ALL

EQUIPMENT LIST

D280T132

Section D02100

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02194		BACC63BP16A10SNL PLUG-	81205	1	32-44-11 1030/177/R092	ALL
D02194 T		710AS011M1612-62A ADAPTER-	06324	1	32-44-11 / /	ALL
D02195		MS3126F10-6S PLUG -RF SWITCH	91836	1	34-53-13 331/131/R043	ALL
D02196		BACC63BP12R3S6L PLUG-	81205	1	32-42-12 0965/175/R003	ALL
D02196 T		710AS011M1209-62A ADAPTER-	06324	1	32-42-12 / /	ALL
D02197		KA-59-353-M06 PLUG-COAX	91836	1	34-53-13 331/131/43	ALL
D02198		BACC63BP12R3S7L PLUG-	81205	1	32-42-12 0965/175/R003	ALL
D02198 T		710AA011M1209-62A ADAPTER-90 DEGREES	06324	1	32-42-12 / /	ALL
D02199		KN-59-329-M06 PLUG-COAX	91836	1	34-53-13 331/131/R043	ALL

EQUIPMENT LIST

D280T132

Section D02100

Page 7 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02200		BACC63BP12R3SNL PLUG-	81205	1	32-42-12 0965/175/R003	ALL
D02200 T		710AS011M1209-62A ADAPTER-	06324	1	32-42-12 / /	ALL
D02202		BACC63BP12R3SNL PLUG-	81205	1	32-42-12 0965/175/R003	ALL
D02202 T		710AA011M1209-62A ADAPTER-90 DEGREES	06324	1	32-42-12 / /	ALL
D02204J		BACC63BV12S3SN RCPT-	81205	1	32-61-12 J00004/LWR/R GR	ALL
D02204P		BACC63BP12B3PNL PLUG - VENDOR PIGTAIL	287T6104 81205	1	32-61-12 / /	ALL
D02206J		BACC63BV12S3SN RCPT-	81205	1	32-61-12 J00004/LWR/R GR	ALL
D02206P		BACC63BP12B3PNL PLUG - VENDOR PIGTAIL	287T6104 81205	1	32-61-12 / /	ALL
D02207		BACC63BP16A10S6L PLUG	81205	1	27-41-11 1720/280/L007	050-099, 155-199, 275-299
D02207 T		BACC10KD16 CLAMP	81205	1	27-41-11 / /	050-099, 155-199, 275-299
D02208J		BACC63BV12S3S7 RCPT-	81205	1	32-61-12 J00004/LWR/R GR	ALL
D02208P		BACC63BP12B3P7L PLUG - VENDOR PIGTAIL	287T6104 81205	1	32-61-12 / /	ALL
D02209		BACC63BP16A10SNL PLUG	81205	1	27-41-11 1720/285/L005	050-099, 155-199, 275-299
D02209 T		BACC10KD16 CLAMP	81205	1	27-41-11 / /	050-099, 155-199, 275-299
D02210J		BACC63BV12S3S7 RCPT-	81205	1	32-61-12 J00004/LWR/R GR	ALL
D02210P		BACC63BP12B3P7L PLUG - VENDOR PIGTAIL	287T6104 81205	1	32-61-12 / /	ALL
D02211		BACC63BP14A15SNL PLUG	81205	1	27-41-11 1720/285/L005	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section D02200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02211	T	BACC10KD14 CLAMP	81205	1	27-41-11 / /	050-099, 155-199, 275-299
D02212		BACC63BP16R10SNL PLUG-	81205	1	29-21-32 0987/170/R010	ALL
D02212	T	710AS011M1612-62A ADAPTER	06324	1	29-21-32 0991/170/0002	ALL
D02213		BACC63BP10A5SNL PLUG	81205	1	27-41-11 1720/280/L007	050-099, 155-199, 275-299
D02213	T	BACC10KD10 CLAMP	81205	1	27-41-11 / /	050-099, 155-199, 275-299
D02214		BACC63BP16R10SNL PLUG-	81205	1	29-21-32 1010/150/R005	ALL
D02214	T	710AS011M1612-62A ADAPTER-	06324	1	29-21-32 / /	ALL
D02215		BACC63BP16A10S6L PLUG	81205	1	27-41-21 1725/280/R007	050-099, 155-199, 275-299
D02215	T	BACC10KD16 CLAMP	81205	1	27-41-21 / /	050-099, 155-199, 275-299
D02216		BACC63BP12R3S10L PLUG-	81205	1	29-32-11 1045/180/L005	ALL
D02216	T	710AS011M1209-62A ADAPTER-	06324	1	29-32-11 / /	ALL
D02217		BACC63BP16A10SNL PLUG	81205	1	27-41-21 1725/280/R005	050-099, 155-199, 275-299
D02217	T	BACC10KD16 CLAMP	81205	1	27-41-21 1725/280/R005	050-099, 155-199, 275-299
D02218		BACC63BP14R7SNL PLUG-	81205	1	29-33-11 1129/123/R065	ALL
D02218	T	BACC10KD14 CLAMP-	81205	1	29-33-11 / /	ALL
D02219		BACC63BP14A15SNL PLUG	81205	1	27-41-21 1725/280/R005	050-099, 155-199, 275-299
D02219	T	BACC10KD14 CLAMP	81205	1	27-41-21 1725/280/R005	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section D02200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02220		BACC63BP12A3SNL PLUG-	81205	1	29-33-11 1129/123/R065	ALL
D02220 T		BACC10KD12 CLAMP-	81205	1	29-33-11 / /	ALL
D02221		BACC63BP10A5SNL PLUG	81205	1	27-41-21 1725/280/R007	050-099, 155-199, 275-299
D02221 T		BACC10KE10 CLAMP	81205	1	27-41-21 1725/280/R7	050-099, 155-199, 275-299
D02222		BACC66F11C75AA01 PLUG-ARINC 600	81205	1	32-46-11 SHELF/E02/04	ALL
D02222A		PARTAOFD02222 PLUG-PART OF D02222		0	32-46-11 / /	ALL
D02222B		PARTBOFD02222 PLUG-PART OF D02222		0	32-46-11 / /	ALL
D02223		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 480/280/0	050-099
D02223		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 455/280/0	150-199
D02224J		BACC45FM12C3S RCPT-	81205	1	32-61-13 0180/149/R022	ALL
D02224P		BACC63BP12A3PNL PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-13 0175/161/R022	ALL
D02225		BACC45FT12A12S PLUG	81205	1	23-32-11 480/280/0	050-099
D02225		BACC45FT12A12S PLUG	81205	1	23-32-11 455/280/0	150-199
D02226J		BACC45FM12C3S8 RCPT-	81205	1	32-61-13 0170/150/R015	ALL
D02226P		BACC63BP12A3P8L PLUG - VENDOR PIGTAIL	287T4142 81205	1	32-61-13 0188/120/0000	ALL
D02227		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 605/280/0	150-199
D02228		BACC63BP12R3S6L PLUG-	81205	1	32-41-11 1030/180/L005	ALL

EQUIPMENT LIST

D280T132

Section D02200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02228	T	710AA011M1209-62A ADAPTER-90 DEGREES	06324	1	32-41-11 1030/180/L005	ALL
D02229		BACC45FT12A12S PLUG	81205	1	23-32-11 605/280/0	150-199
D02231		KC-59-585-M06 PLUG-COAXIAL	81205	1	23-32-13 915/280/0000	050-099
D02231		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 660/280/0	150-199
D02233		BACC45FT12A12S PLUG	81205	1	23-32-13 915/280/0000	050-099
D02233		BACC45FT12A12S PLUG	81205	1	23-32-11 660/280/0	150-199
D02235		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 815/280/0	150-199
D02236		BACC45FT12B12S7 PLUG-P10	81205	1	27-48-11 P010-00/ /	ALL
D02237		BACC45FT12A12S PLUG	81205	1	23-32-11 815/280/0	150-199
D02238		BACC45FT12B12S7 PLUG-P10	81205	1	27-48-11 P010-00/ /	ALL
D02239		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 0447/245/L080	151-152
D02239		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 255/245/L 10	280-299
D02241		BACC45FT16A24S PLUG-	81205	1	23-32-11 0447/245/L 80	050-099, 150-199
D02241		BACC45FT16A24S PLUG-	81205	1	23-32-11 255/245/L 80	280-299
D02243		BACC45FT20A41S PLUG	81205	1	23-32-21 0447/245/L080	050-099, 150-199
D02243		BACC45FT20A41S PLUG	81205	1	23-32-21 0245/267/L012	275-299
D02245		BACC45FT12A12S PLUG	81205	1	23-32-11 731/308/R 38	150-199

EQUIPMENT LIST

D280T132

Section D02200

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02246		BACC65L41 RCPT-	81205	1	29-11-32 P050-00/ /	ALL
D02246 U		BACC47EM1 KEYING PLUG-	81205	2	29-11-32 / /	ALL
D02247		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 731/308/R 38	150-199
D02249		MS3126F14-12P PLUG	91836	1	23-32-11 730/308/R 36	150-199
D02251		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 730/308/R 36	150-199
D02252		BACS16W4 RELAY SOCKET-	81205	1	29-11-32 P036-00/ /	ALL
D02253		MS3126F14-12P PLUG	91836	1	23-32-11 731/308/R 36	150-199
D02254		BACS16W1 RELAY SOCKET-P19	81205	1	33-24-11 P019-00/ /	050-099
D02254		BACS16W1 RELAY SOCKET-	81205	1	33-24-11 P019-00/ /	150-199, 275-299
D02255		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 736/308/R 36	150-199
D02256		BACS16W1 RELAY SOCKET-P19	81205	1	33-24-11 P019-00/ /	050-099
D02256		BACS16W1 RELAY SOCKET-	81205	1	33-24-11 P019-00/ /	150-199, 275-299
D02257		KC-59-660-M06 RECP	91836	1	23-32-21 SHELF/E01/-4	050-099, 151-199, 275-299
D02257		KC-59-585-M06 RECP	91836	1	23-32-21 SHELF/E01/-4	150
D02259		KC-59-411 PLUG	91836	1	23-32-21 SHELF/E01/-4	ALL
D02261		BACC65L66 PLUG	81205	1	31-41-35 P051/ /	ALL
D02263J		BACC45FN12A12S RCPT	81205	1	27-41-31 P010-00/ /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section D02200

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02264		BACC63BP12A3S6L PLUG-	81205	1	27-62-11 L0349/14/TE	ALL
D02264 T		BACC10KD12 CLAMP-	81205	1	27-62-11 / /	ALL
D02265J		BACC45FN12A12S7 RCPT	81205	1	27-41-31 P10/ /	050-099, 155-199, 275-299
D02266		BACC63BP12A3S6L PLUG-	81205	1	27-62-11 R0349/14/RS	ALL
D02266 T		BACC10KD12 CLAMP-	81205	1	27-62-11 / /	ALL
D02267		582589-1 PLUG	00779	1	23-31-11 SHELF/E02/05	050-099, 150-199
D02267 V		582507-1 CONTACT-KEYING PIN	00779	1	23-31-11 SHELF/E02/05	050-099, 150-199
D02268		BACS16X1A RELAY SOCKET-P36	81205	1	27-51-31 P036-00/ /	ALL
D02269		582589-1 PLUG	00779	1	23-31-13 SHELF/E02/05	050-099, 150-199
D02269 V		582507-1 CONTACT-KEYING PIN	00779	1	23-31-11 SHELF/E02/05	050-099, 150-199
D02270		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D02271		582589-1 PLUG	00779	1	23-31-11 SHELF/E02/05	050-099, 150-199
D02271 V		582507-1 CONTACT-KEYING PIN	00779	1	23-31-11 SHELF/E02/05	050-099, 150-199
D02272		BACS16AF1 RELAY SOCKET-	81205	1	27-58-11 P033-00/ /	ALL
D02273		BACC45FT14C15S PLUG	81205	1	23-31-11 425/245/L 50	050-099
D02273		BACC45FT14C15S PLUG	81205	1	23-31-11 447/245/L050	150-199
D02275		SO-1064-007 RELAY SOCKET	LEACH	0	34-61-16 E02-2/ /	ALL

EQUIPMENT LIST

D280T132

Section D02200

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02276		BACC45FN8-2S RCPT-	81205	1	35-21-13 0444/270/R073	050-099
D02276		BACC45FN8-2S RCPT-	81205	1	35-21-13 449/270/R073	150-199
D02276		BACC45FN8-2S RCPT-	81205	1	35-21-13 0434/270/R073	275-299
D02277		SO-1064-007 RELAY SOCKET	LEACH	1	34-61-26 E02-3/ /	ALL
D02278		10-60450-5 RELAY SOCKET-	81205	1	27-81-11 P037-00/ /	ALL
D02279		SO-1064-007 RELAY SOCKET	LEACH	0	34-61-16 E02-2/ /	ALL
D02280		10-60450-5 RELAY SOCKET-	81205	1	27-81-11 P037-00/ /	ALL
D02281		SO-1064-007 RELAY SOCKET	LEACH	1	34-61-26 E02-3/ /	ALL
D02282		10-60450-5 RELAY SOCKET-	81205	1	27-81-11 P037-00/ /	ALL
D02283		SO-1064-007 RELAY SOCKET	LEACH	1	34-61-26 E02-3/ /	ALL
D02284		BACS16X1A RELAY SOCKET-P36	81205	1	27-81-31 P036-00/ /	ALL
D02285		BACS16W1A RELAY SOCKET		1	34-22-38 E01-4/ /	ALL
D02286		BACC63BP16A10SNL PLUG-	81205	1	27-13-11 R0432/12/TE	ALL
D02286 T		BACC10KD16 CLAMP-	81205	1	27-13-11 / /	ALL
D02287		BACC45FT20D41S6 LEFT FMC CTRL DISPL UNIT	81205	1	34-61-16 P009-00/ /	ALL
D02289		BACC45FT20D41S6 RIGHT FMC CDU	81205	1	34-61-26 P009/ /	ALL
D02291		BACC63BP12B3SNL PLUG-R BREAK PRESS SW	81205	1	31-31-22 1037/188/R 84	ALL

EQUIPMENT LIST

D280T132

Section D02200

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02291	T	710AS011M1209-62A ADAPTER	06324	1	31-31-22 1037/188/R 84	ALL
D02292		BACC63BN10-5SN PLUG-	81205	1	27-11-11 0955/162/L070	ALL
D02292	T	710ES012M1009-62A ADAPTER-	06324	1	27-11-11 / /	ALL
D02293		BACC63BP12B3SNL PLUG-LEFT ALT BREAK	81205	1	31-31-22 1027/188/L084	ALL
D02293	T	710AS011M1209-62A ADAPTER	06324	1	31-31-22 1027/185/L084	ALL
D02294		BACC63BP14A7SNL PLUG-	81205	1	27-81-11 R0140/14/LE	ALL
D02294	T	BACC10KE14 CLAMP-	81205	1	27-81-11 / /	ALL
D02296		BACC63BP14A7S7L RCPT-	81205	1	27-81-21 L0150/14/LE	050-099, 150-199, 275-276, 278-299
D02296		BACC63BP14R7SNL RCPT-	81205	1	27-81-21 L0150/14/LE	277
D02296	T	BACC10KE14 CLAMP-	81205	1	27-81-21 / /	ALL
D02298		BACC63BP14A7SNL RCPT-	81205	1	27-81-31 L0150/14/LE	050-099, 162-199, 276-299
D02298		BACC63BP14R7SNL RCPT-	81205	1	27-81-31 L0150/14/LE	150-157, 275
D02298	T	BACC10KE14 CLAMP-	81205	1	27-81-31 / /	050-099, 162-199, 276-299
D02298	T	BACC10KD14 CLAMP-	81205	1	27-81-31 / /	150-157, 275

EQUIPMENT LIST

D280T132

Section D02200

Page 8 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02300		BACC63BP16R10SNL PLUG-	81205	1	27-13-11 1065/163/L013	ALL
D02300 T		710AS011M1612-62A ADAPTER-	06324	1	27-13-11 / /	ALL
D02301		MS3126F20-41S PLUG MULTI-INPUT PRINTER	81205	1	31-36-11 P008-00/ /	ALL
D02304		BACC63BP14R7SNL PLUG-	81205	1	27-51-31 1065/180/R050	ALL
D02304 T		710AA011M1412-62A ADAPTER-90 DEGREES	06324	1	27-51-31 / /	ALL
D02306		BACC63BN14-7SN PLUG-	81205	1	27-51-51 1065/176/R020	ALL
D02306 T		710EA012M1412-62A ADAPTER-90 DEGREES	06324	1	27-51-51 / /	ALL
D02310		BACC63BP16R10SNL PLUG-	81205	1	27-51-11 1065/144/R030	050-099, 150-166, 275-277
D02310		BACC63BP16B10SNL PLUG-	81205	1	27-51-11 1065/144/R030	167-199, 278-299
D02310 T		710AA011M1612-62A ADAPTER-90 DEGREES	06324	1	27-51-11 / /	ALL
D02312		BACC63BP18R8SNL PLUG-	81205	1	27-51-11 1065/170/R028	ALL
D02312 T		710AA011M1816-62A ADAPTER-90 DEGREES	06324	1	27-51-11 / /	ALL
D02314		BACC45FN14-15S RCPT-	81205	1	25-53-17 0505/124/R048	ALL
D02316		BACC45FN14-15S RCPT-	81205	1	25-53-17 0527/120/R048	ALL
D02317		DAMA11W1P PLUG	71468	1	23-32-31 401/310/R 25	275-299
D02317 T		D110278 LATCH	71468	2	23-32-31 / /	275-299
D02317 U		DA20961 JUNCTION SHELL	71468	1	23-32-31 / /	275-299

EQUIPMENT LIST

D280T132

Section D02300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02317	V	DMA43717-6 COAX CONTACT	71468	1	23-32-31 / /	275-299
D02318		BACC45FN14-15S RCPT-	81205	1	25-53-25 1277/122/L032	ALL
D02319		DAMA11W1P PLUG	71468	1	23-32-31 401/310/R 25	275-299
D02319	T	D110278 LATCH	71468	2	23-32-31 / /	275-299
D02319	U	DA20961 JUNCTION SHELL	71468	1	23-32-31 / /	275-299
D02319	V	DMA43717-7 COAX CONTACT PIN	71468	1	23-32-31 / /	275-299
D02320		BACC45FN14-15S RCPT-	81205	1	25-53-21 1277/122/L040	ALL
D02322		BACC45FN14-15S RCPT-	81205	1	25-53-25 1277/122/R032	ALL
D02323		M24308-2-3F RECP-	71468	1	23-32-31 401/310/R 25	275-278
D02323		M24308-2-3F RECP	71468	1	23-32-31 401/310/R 25	280-299
D02323	T	DB20962 JUNCTION SHELL	71468	1	23-32-31 401/310/R 25	275-299
D02323	U	D110278 LATCH	71468	2	23-32-31 / /	275-299
D02324		BACC45FN14-15S RCPT-	81205	1	25-53-25 1339/122/L032	ALL
D02325		BACC45FT12-12S PLUG	81205	1	23-32-31 410/295/L 38	275-299
D02326		BACC45FN14-15S RCPT-	81205	1	25-53-25 1339/122/R005	ALL
D02327		BACC45FT12-12S PLUG	81205	1	23-32-31 382/295/R 38	275-276
D02327		BACC45FT12-12S PLUG	81205	1	23-32-31 410/295/R 38	277-299

EQUIPMENT LIST

D280T132

Section D02300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02328		BACC45FN14-15S RCPT-	81205	1	25-53-25 1339/122/R032	ALL
D02329		DAMA11W1P PLUG	71468	1	23-32-32 401/310/R 25	275-299
D02329 T		D110278 LATCH	71468	2	23-32-32 / /	275-299
D02329 U		DA20961 JUNCTION SHELL	71468	1	23-32-32 401/310/R 25	275-278
D02329 U		DA20961 JUNCTION SHELL	71468	1	23-32-32 / /	280-299
D02329 V		DMA43717-6 COAX CONTACT PIN	71468	1	23-32-32 401/310/R 25	275-278
D02329 V		DMA43717-6 COAX CONTACT	71468	1	23-32-32 / /	280-299
D02330		BACC45FN14-15S RCPT-	81205	1	25-53-26 1290/122/L012	ALL
D02331		DAMA11W1P PLUG	71468	1	23-32-32 401/310/R 25	275-299
D02331 T		D110278 LATCH	71468	2	23-32-32 / /	275-299
D02331 U		DA20961 JUNCTION SHELL	71468	1	23-32-32 401/310/R 25	275-278
D02331 U		DA20961 JUNCTION SHELL	71468	1	23-32-32 / /	280-299
D02331 V		DMA43717-6 COAX CONTACT PIN	71468	1	23-32-32 401/310/R 25	275-278
D02331 V		DMA43717-6 COAX CONTACT	71468	1	23-32-32 / /	280-299
D02332		BACC45FN14-15S RCPT-	81205	1	25-53-26 1324/122/L040	ALL
D02334		BACC45FN14-15S RCPT-	81205	1	25-53-26 1290/122/R004	ALL
D02336		BACC45FN14-15S RCPT-	81205	1	25-53-26 1324/122/R014	ALL

EQUIPMENT LIST

D280T132

Section D02300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02337		BACC45FT12-12S PLUG	81205	1	23-32-32 0650/295/L 38	275-278
D02337		DAMA11W1S PLUG	71468	1	23-32-32 541/253/L 65	280-299
D02337 T		DA20961 JUNCTION SHELL	71468	1	23-32-32 / /	280-299
D02337 U		D110278 LATCH	71468	2	23-32-32 / /	280-299
D02337 V		DMA43716-6 COAX CONTACT	71468	1	23-32-32 / /	280-299
D02338		BACC45FN14-15S RCPT-	81205	1	25-53-27 1292/122/R048	050-099, 150-199
D02339		DAMA11W1P PLUG	71468	1	23-32-33 401/310/R 25	275-299
D02339 T		D110278 LATCH	71468	2	23-32-33 / /	275-299
D02339 U		DA20961 JUNCTION SHELL	71468	1	23-32-33 / /	275-299
D02339 V		DMA43717-6 COAX CONTACT	71468	1	23-32-33 / /	275-299
D02340		BACC45FN14-15S RCPT-	81205	1	25-53-27 1324/122/R048	050-099, 150-199
D02341		DAMA11W1P PLUG	71468	1	23-32-33 401/310/R 25	275-299
D02341 T		D110278 LATCH	71468	2	23-32-33 / /	275-299
D02341 U		DA20961 JUNCTION SHELL	71468	1	23-32-33 / /	275-299
D02341 V		DMA43717-6 COAX CONTACT	71468	1	23-32-33 / /	275-299
D02347		DAMA11W1P PLUG	71468	1	23-32-34 401/310/R 25	275-299
D02347 T		D110278 LATCH	71468	2	23-32-34 / /	275-299

EQUIPMENT LIST

D280T132

Section D02300

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02347	U	DA20961 JUNCTION SHELL	71468	1	23-32-34 401/310/R 25	275-299
D02347	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-34 401/310/R 25	275-299
D02349		DAMA11W1P PLUG	71468	1	23-32-34 401/310/R 25	275-299
D02349	T	D110278 LATCH	71468	2	23-32-34 / /	275-299
D02349	U	DA20961 JUNCTION SHELL	71468	1	23-32-34 401/310/R 25	275-299
D02349	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-34 401/310/R 25	275-299
D02351		M24308-4-3F PLUG	71468	1	23-32-41 401/310/R 25	275-299
D02351	T	DB20962 JUNCTION SHELL	71468	1	23-32-41 401/310/R 25	275-299
D02351	U	D110278 LATCH	71468	2	23-32-41 / /	275-299
D02352		BACC63BW24-22S PLUG-	81205	1	29-21-31 1160/129/R080	150-154, 275
D02352	1	BACC63BW24C22S PLUG-	81205	1	29-21-31 1160/129/R080	050-099, 155-199, 276-299
D02352	2	BACC63CE24A22S PLUG-	81205	1	29-21-31 1160/129/R080	050-099, 155-199, 276-299
D02352	T	BACC10GL24 CLAMP-	81205	1	29-21-31 / /	150-154, 275
D02354		BACC63BP14R7SNL PLUG-	81205	1	29-21-31 1175/129/R075	ALL
D02354	T	BACC10KD14 CLAMP	81205	1	29-21-31 / /	050-099
D02354	T	BACC10KD14 CLAMP	81205	1	29-21-31 1155/129/R075	150-199, 275-299
D02355		DAMA11W1P PLUG	71468	1	23-32-41 731/310/R 25	275-299

EQUIPMENT LIST

D280T132

Section D02300

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02355	T	D110278 LATCH	71468	2	23-32-41 / /	275-299
D02355	U	DA20961 JUNCTION SHELL	71468	1	23-32-41 / /	275-299
D02355	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-41 / /	275-278
D02355	V	DMA43717-6 COAX CONTACT	71468	1	23-32-41 / /	280-299
D02356		BACC63BP12R3SNL PLUG-	81205	1	29-21-31 1060/140/R005	ALL
D02356	T	710AS011M1209-62A ADAPTER-	06324	1	29-21-31 / /	ALL
D02357		DAMA11W1P PLUG	71468	1	23-32-41 731/310/R 25	275-278
D02357		DAMA11W1P PLUG	71468	1	23-32-41 728/315/R015	280-299
D02357	T	D110278 LATCH	71468	2	23-32-41 / /	275-299
D02357	U	DA20961 JUNCTION SHELL	71468	1	23-32-41 / /	275-278
D02357	U	DA20961 JUNCTION SHELL	71468	1	23-32-41 731/310/R 25	280-299
D02357	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-41 / /	275-278
D02357	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-41 731/310/R 25	280-299
D02358		BACC63BP12R3S6L PLUG-	81205	1	29-21-31 1055/140/R045	ALL
D02358	T	710AS011M1209-62A ADAPTER-	06324	1	29-21-31 / /	ALL
D02361		M24308-2-3F RECP	71468	1	23-32-41 731/310/R 25	275-299
D02361	T	DB20962 JUNCTION SHELL	71468	1	23-32-41 731/310/R 25	275-299

EQUIPMENT LIST

D280T132

Section D02300

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02361	U	D110278 LATCH	71468	2	23-32-41 / /	275-299
D02363		BACC45FT12-12S PLUG	81205	1	23-32-41 654+75/295/L 38	275-278
D02363		BACC45FT12-12S PLUG	81205	1	23-32-41 654+103/289/L033	280-299
D02365		BACC45FT12-12S PLUG	81205	1	23-32-41 654+75/295/R 38	275-278
D02365		BACC45FT12-12S PLUG	81205	1	23-32-41 654+103/290/R044	280-299
D02366		BACC63BP10R5SNL PLUG-	81205	1	21-33-11 0327/180/R045	ALL
D02366	T	BACC10KD10 CLAMP-	81205	1	21-33-11 / /	ALL
D02367		DAMA11W1P PLUG	71468	1	23-32-42 731/310/R 25	275-278
D02367		DAMA11W1P PLUG	71468	1	23-32-42 735/315/R 15	280-299
D02367	T	D110278 LATCH	71468	2	23-32-42 / /	275-299
D02367	U	DA20961 JUNCTION SHELL	71468	1	23-32-42 731/310/R 25	275-278
D02367	U	DA20961 JUNCTION SHELL	71468	1	23-32-42 / /	280-299
D02367	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-42 731/310/R 25	275-278
D02367	V	DMA43717-6 COAX CONTACT	71468	1	23-32-42 / /	280-299
D02369		DAMA11W1P PLUG	71468	1	23-32-42 731/310/R 25	275-278
D02369		DAMA11W1P PLUG	71468	1	23-32-42 735/314/R020	280-299
D02369	T	D110278 LATCH	71468	2	23-32-42 / /	275-299

EQUIPMENT LIST

D280T132

Section D02300

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02369 U		DA20961 JUNCTION SHELL	71468	1	23-32-42 731/310/R 25	275-278
D02369 U		DA20961 JUNCTION SHELL	71468	1	23-32-42 / /	280-299
D02369 V		DMA43717-6 COAX CONTACT PIN	71468	1	23-32-42 731/310/R 25	275-278
D02369 V		DMA43717-6 COAX CONTACT	71468	1	23-32-42 / /	280-299
D02372		BACC66F11C31AA01 PLUG-ARINC 600	81205	1	32-42-11 SHELF/E01/01	ALL
D02372A		PARTAOFD02372 PLUG-PART OF D02372		0	32-42-11 / /	ALL
D02372B		PARTBOFD02372 PLUG-PART OF D02372		0	32-42-11 / /	ALL
D02375		DAMA11W1S PLUG	71468	1	23-32-42 858/260/L 70	275-278
D02375		DAMA11W1S PLUG	71468	1	23-32-42 654+74/253/L 64	280-299
D02375 T		DA20961 JUNCTION SHELL	71468	1	23-32-42 858/260/L 70	275-278
D02375 T		DA20961 JUNCTION SHELL	71468	1	23-32-42 / /	280-299
D02375 U		D110278 LATCH	71468	2	23-32-42 / /	275-299
D02375 V		DMA43716-6 COAX CONTACT PIN	71468	1	23-32-42 858/260/L 70	275-278
D02375 V		DMA43716-6 COAX CONTACT	71468	1	23-32-42 / /	280-299
D02377		DAMA11W1P PLUG	71468	1	23-32-43 731/310/R 25	275-278
D02377		DAMA11W1P PLUG	71468	1	23-32-43 728/309/R020	280-299
D02377 T		D110278 LATCH	71468	2	23-32-43 / /	275-299

EQUIPMENT LIST

D280T132

Section D02300

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02377 U		DA20961 JUNCTION SHELL	71468	1	23-32-43 731/310/R 25	275-278
D02377 U		DA20961 JUNCTION SHELL	71468	1	23-32-43 / /	280-299
D02377 V		DMA43717-6 COAX CONTACT PIN	71468	1	23-32-43 731/310/R 25	275-278
D02377 V		DMA43717-6 COAX CONTACT	71468	1	23-32-43 / /	280-299
D02378		BACC66F11C13AA01 PLUG-	81205	1	36-23-11 SHELF/E03/01	050-099, 150-155, 162-165, 275-276
D02378		BACC66F11C49AA01 PLUG-	81205	1	36-23-11 SHELF/E03/01	156-157, 166-199, 277-299
D02378A		PARTAOFD02378 PLUG-PART OF D02378		0	36-23-21 / /	ALL
D02378B		PARTBOFD02378 PLUG-PART OF D02378		0	36-23-21 / /	ALL
D02378C		PARTCOFD02378 PLUG-PART OF D02378		0	36-23-11 / /	ALL
D02379		DAMA11W1P PLUG	71468	1	23-32-43 728/309/R020	280-299
D02379 T		D110278 LATCH	71468	2	23-32-43 / /	280-299
D02379 U		DA20961 JUNCTION SHELL	71468	1	23-32-43 / /	280-299
D02379 V		DMA43717-6 COAX CONTACT	71468	1	23-32-43 / /	280-299
D02382		BACC63BP10R5S8L PLUG-	81205	1	30-11-11 R0449/14/LE	275-299
D02382 T	1	BACC10KD10 CLAMP-	81205	1	30-11-11 / /	275-299
D02384		BACC63BP10R5S8L PLUG-	81205	1	30-11-11 L0449/14/LE	155, 275-299
D02384 T		BACC10KD10 CLAMP-	81205	1	30-11-11 / /	155, 275-299

EQUIPMENT LIST

D280T132

Section D02300

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02385		DAMA11W1P PLUG	71468	1	23-32-51 1032/310/R 25	275-299
D02385 T		D110278 LATCH	71468	2	23-32-51 / /	275-299
D02385 U		DA20961 JUNCTION SHELL	71468	1	23-32-51 / /	275-299
D02385 V		DMA43717-6 COAX CONTACT	71468	1	23-32-51 / /	275-299
D02386		BACC63BP10R5SNL PLUG-	81205	1	30-11-11 R0449/14/LE	ALL
D02386 T		BACC10KD10 CLAMP-	81205	1	30-11-11 / /	ALL
D02387		DAMA11W1P PLUG	71468	1	23-32-51 1032/310/R 25	275-299
D02387 T		D110278 LATCH	71468	2	23-32-51 / /	275-299
D02387 U		DA20961 JUNCTION SHELL	71468	1	23-32-51 / /	275-299
D02387 V		DMA43717-6 COAX CONTACT	71468	1	23-32-51 / /	275-299
D02388		BACC63BP10R5SNL PLUG-	81205	1	30-11-11 L0449/14/LE	ALL
D02388 T		BACC10KD10 CLAMP-	81205	1	30-11-11 / /	ALL
D02391		M24308-2-3F RECP	71468	1	23-32-51 1032/310/R 25	275-299
D02391 T		DB20962 JUNCTION SHELL	71468	1	23-32-51 1032/310/R 25	275-299
D02391 U		D110278 LATCH	71468	2	23-32-51 / /	275-299
D02393		BACC45FT12-12S PLUG	81205	1	23-32-51 866/280/L 38	275-299
D02395		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-51 866/280/L 38	275-299

EQUIPMENT LIST

D280T132

Section D02300

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02397		BACC45FT12-12S PLUG	81205	1	23-32-51 866/280/R 38	275-299
D02399		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-51 866/280/R 38	275-299

EQUIPMENT LIST

D280T132

Section D02300
Page 11 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02401		DAMA11W1P PLUG	71468	1	23-32-52 1032/310/R 25	275-299
D02401 T		D110278 LATCH	71468	2	23-32-52 / /	275-299
D02401 U		DA20961 JUNCTION SHELL	71468	1	23-32-52 / /	275-299
D02401 V		DMA43717-6 COAX CONTACT	71468	1	23-32-52 / /	275-299
D02403		DAMA11W1P PLUG	71468	1	23-32-52 1032/310/R 25	275-299
D02403 T		D110278 LATCH	71468	2	23-32-52 / /	275-299
D02403 U		DA20961 JUNCTION SHELL	71468	1	23-32-52 / /	275-299
D02403 V		DMA43717-6 COAX CONTACT	71468	1	23-32-52 / /	275-299
D02409		DAMA11W1P PLUG	71468	1	23-32-53 1032/310/R 25	275-299
D02409 T		D110278 LATCH	71468	2	23-32-53 / /	275-299
D02409 U		DA20961 JUNCTION SHELL	71468	1	23-32-53 / /	275-299
D02409 V		DMA43717-6 COAX CONTACT	71468	1	23-32-53 / /	275-299
D02411		DAMA11W1P PLUG	71468	1	23-32-53 1032/310/R 25	275-299
D02411 T		D110278 LATCH	71468	2	23-32-53 / /	275-299
D02411 U		DA20961 JUNCTION SHELL	71468	1	23-32-53 / /	275-299
D02411 V		DMA43717-6 COAX CONTACT	71468	1	23-32-53 / /	275-299
D02413		M24308-4-3F PLUG	71468	1	23-32-61 1032/310/R 25	275-299

EQUIPMENT LIST

D280T132

Section D02400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02413	T	DB20962 JUNCTION SHELL	71468	1	23-32-61 1032/310/R 25	275-299
D02413	U	D110278 LATCH	71468	2	23-32-61 / /	275-299
D02414		BACS16W1 RELAY SOCKET-	81205	1	76-11-11 P037-00/ /	ALL
D02417		BACC45FT12-12S PLUG	81205	1	23-32-53 1172/280/L 38	275-299
D02418		BACS16W1 RELAY SOCKET-P33	81205	1	27-62-11 P033-00/ /	ALL
D02419		DAMA11W1P PLUG	71468	1	23-32-54 1032/310/R 25	280-299
D02419	T	D110278 LATCH	71468	2	23-32-54 / /	280-299
D02419	U	DA20961 JUNCTION SHELL	71468	1	23-32-54 1032/310/R 25	280-299
D02419	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-54 1032/310/R 25	280-299
D02420		BACS16W1 RELAY SOCKET-	81205	1	27-62-11 P033-00/ /	ALL
D02421		DAMA11W1P PLUG	71468	1	23-32-54 1032/310/R 25	280-299
D02421	T	D110278 LATCH	71468	2	23-32-54 / /	280-299
D02421	U	DA20961 JUNCTION SHELL	71468	1	23-32-54 1032/310/R 25	280-299
D02421	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-54 1032/310/R 25	280-299
D02424		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0372/280/L005	050-099
D02424		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0373/280/L005	150-199
D02424		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 0373/280/L005	275

EQUIPMENT LIST

D280T132

Section D02400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02424		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 0372/280/L005	276-299
D02426		BACC45FT16A24S PLUG-	81205	1	33-11-11 0154/213/R006	ALL
D02427		DAMA11W1P PLUG	71468	1	23-32-61 1362/310/R 25	275-299
D02427 T		D110278 LATCH	71468	2	23-32-61 / /	275-299
D02427 U		DA20961 JUNCTION SHELL	71468	1	23-32-61 / /	275-299
D02427 V		DMA43717-6 COAX CONTACT	71468	1	23-32-61 / /	275-299
D02429		DAMA11W1P PLUG	71468	1	23-32-61 1362/310/R 25	275-299
D02429 T		D110278 LATCH	71468	2	23-32-61 / /	275-299
D02429 U		DA20961 JUNCTION SHELL	71468	1	23-32-61 / /	275-299
D02429 V		DMA43717-6 COAX CONTACT	71468	1	23-32-61 / /	275-299
D02430		BACS16W1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D02430		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D02432		BACS16W1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D02432		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D02433		M24308-2-3F RECP	71468	1	23-32-61 1362/310/R 25	275-299
D02433 T		DB20962 JUNCTION SHELL	71468	1	23-32-61 1362/310/R 25	275-299
D02433 U		D110278 LATCH	71468	2	23-32-61 / /	275-299

EQUIPMENT LIST

D280T132

Section D02400

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02434		BACS16W1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D02434		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D02435		BACC45FT12-12S PLUG	81205	1	23-32-61 1206/280/L 38	275-299
D02436		BACS16W1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D02436		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D02437		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-61 1217/280/L 38	275-299
D02438		BACS16W1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02439		BACC45FT12-12S PLUG	81205	1	23-32-61 1217/280/R 38	275-299
D02440		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D02441		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-61 1217/280/R 38	275-299
D02442		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D02443		DAMA11W1P PLUG	71468	1	23-32-62 1362/310/R 25	275-299
D02443 T		D110278 LATCH	71468	2	23-32-62 / /	275-299
D02443 U		DA20961 JUNCTION SHELL	71468	1	23-32-62 / /	275-299
D02443 V		DMA43717-6 COAX CONTACT	71468	1	23-32-62 / /	275-299
D02444		BACS16AF1 PLUG-	81205	1	25-53-13 P035-00/ /	ALL
D02445		DAMA11W1P PLUG	71468	1	23-32-62 1362/310/R 25	275-299

EQUIPMENT LIST

D280T132

Section D02400

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02445 T		D110278 LATCH	71468	2	23-32-62 / /	275-299
D02445 U		DA20961 JUNCTION SHELL	71468	1	23-32-62 / /	275-299
D02445 V		DMA43717-6 COAX CONTACT	71468	1	23-32-62 / /	275-299
D02446		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02448		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02450		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02452		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02454		BACS16W1 PLUG-	81205	1	25-53-16 P035-00/ /	ALL
D02456		BACS16W1 PLUG-	81205	1	25-53-16 P035-00/ /	ALL
D02458		BACS16W1 PLUG-	81205	1	25-53-15 P035-00/ /	ALL
D02460		BACS16W1 PLUG-	81205	1	25-53-15 P035-00/ /	ALL
D02462		BACS16X1A RCPT-P35	81205	1	25-53-17 P035-00/ /	ALL
D02463		BKAE-67405-54-40 PLUG ARINC-600	71468	1	34-45-12 SHELF/E01/03	050-099, 150-199, 277-278
D02463		BKAE-67405-54-01 PLUG ARINC-600	71468	1	34-45-12 SHELF/E01/03	275-276, 280-299
D02463 V		289T0241-10401 I.D. TAPE TEXT AS BELOW	71468	1	34-45-12 E1-3/ /	153-154
D02463A		PARTAOFD02463 PLUG PART A OF D02463		0	34-45-12 / /	ALL
D02463AT		320-1066-015 CONTACT E1-3 SHELF COAX,TCAS	71468	1	34-45-11 / /	050-099, 150-152, 155-199, 277-299

EQUIPMENT LIST

D280T132

Section D02400

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02463AU		320-1066-015 CONTACT E1-3 SHELF COAX,TCAS	71468	1	34-45-11 //	050-099, 150-152, 155-199, 277-299
D02463AV		320-1066-015 CONTACT E1-3 SHELF COAX,TCAS	71468	1	34-45-11 //	050-099, 150-152, 155-199, 277-299
D02463AW		320-1066-015 CONTACT E1-3 SHELF COAX,TCAS	71468	1	34-45-11 //	050-099, 150-152, 155-199, 277-299
D02463B		PARTBOFD02463 PLUG PART B OF D02463		0	34-45-12 //	ALL
D02463BT		320-1066-015 CONTACT E1-3 SHELF COAX,TCAS	71468	4	34-45-11 //	050-099, 150-199, 277-299
D02463C		PARTCOFD02463 PLUG PART C OF D02463		0	34-45-12 //	ALL
D02463CT		BACC47EU2 CONTACT E1-3 SHELF COAX,TCAS	59610	1	34-45-11 //	050-099, 150-199, 277-299
D02463D		PARTDOFD02463 PLUG PART D OF D02463		0	34-45-12 //	ALL
D02463E		PARTEOFD02463 PLUG PART E OF D02463		0	34-45-12 //	ALL
D02463F		PARTFOFD02463 PLUG PART F OF D02463		0	34-45-12 //	ALL
D02464		BACS16X1A RCPT-P35	81205	1	25-53-17 P035-00/ /	ALL
D02465		KA-59-439-M06 PLUG	91836	1	34-45-11 380/315/0	050-099, 150-199, 277-299
D02466		BACS16AG1 PLUG-	81205	1	25-53-11 P035-00/ /	ALL
D02467		KA-59-439-M06 PLUG	91836	1	34-45-11 399/102/0000	050-099, 150-199, 277-299
D02468		BACS16AH1 PLUG-	81205	1	25-53-15 P035-00/ /	050-099
D02470		BACS16AH1 PLUG-	81205	1	25-53-15 P035-00/ /	050-099
D02472		BACS16AH1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D02400

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02476		BACS16AH1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02478		BACS16AH1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02483		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-31 0410/295/L038	275-299
D02484		BACS16AH1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02485		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-31 0382/295/R038	275-276
D02485		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-31 0410/295/R038	277-299
D02487		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-32 0650/295/L 38	275-278
D02488		BACS16AH1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02489		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-32 563/295/R 38	275-278
D02490		BACS16AH1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02491		BACC45FT12-12S PLUG	81205	1	23-32-32 563/295/R 38	275-278
D02491		DAMA11W1S PLUG	71468	1	23-32-32 541/254/R 73	280-299
D02491 T		DA20961 JUNCTION SHELL	71468	1	23-32-32 / /	280-299
D02491 U		D110278 LATCH	71468	2	23-32-32 / /	280-299
D02491 V		DMA43716-6 COAX CONTACT	71468	1	23-32-32 / /	280-299
D02492		BACS16AH1 PLUG-	81205	1	25-53-14 P035-00/ /	ALL
D02493		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-41 654+75/295/L 38	275-278

EQUIPMENT LIST

D280T132

Section D02400

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02493		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-41 654+103/289/L033	280-299
D02494		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D02495		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-41 654+75/295/R 38	275-278
D02495		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-41 654+103/290/R044	280-299
D02496		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	050-099
D02497		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-53 1172/280/L 38	275-299
D02499		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-53 1172/280/R 38	275-299

EQUIPMENT LIST

D280T132

Section D02400
Page 8 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02501		BACC45FT12-12S PLUG	81205	1	23-32-53 1172/280/R 38	275-299
D02502		10-60450-5 PLUG-	81205	1	52-34-11 P035-00/ /	ALL
D02504		10-60450-5 PLUG-	81205	1	52-34-11 P035-00/ /	ALL
D02506		BACS16W1 PLUG-	81205	1	52-34-11 P035-00/ /	ALL
D02508		BACS16W1 PLUG-	81205	1	52-34-11 P035-00/ /	ALL
D02510		10-60450-5 RELAY SOCKET-	81205	1	52-35-11 P039-00/ /	ALL
D02512		10-60450-5 RELAY SOCKET-	81205	1	52-35-11 P039-00/ /	ALL
D02513		DAMA11W1S PLUG	71468	1	23-32-42 858/260/R 70	275-278
D02513		DAMA11W1S PLUG	71468	1	23-32-42 654+74/254/R073	280-299
D02513 T		D110278 LATCH	71468	2	23-32-42 / /	275-299
D02513 U		DA20961 JUNCTION SHELL	71468	1	23-32-42 858/260/R 70	275-278
D02513 U		DA20961 JUNCTION SHELL	71468	1	23-32-42 / /	280-299
D02513 V		DMA43716-6 COAX CONTACT PIN	71468	1	23-32-42 858/260/R 70	275-278
D02513 V		DMA43716-6 COAX CONTACT	71468	1	23-32-42 / /	280-299
D02514		10-60450-5 RELAY SOCKET-	81205	1	52-35-11 P039-00/ /	ALL
D02516		BACS16W1 RELAY SOCKET-	81205	1	52-35-11 P039-00/ /	ALL
D02517		MS3126F16-26S PLUG	96906	1	23-31-12 PURSER/STA/	150-199

EQUIPMENT LIST

D280T132

Section D02500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02518		BACS16W1 RELAY SOCKET-	81205	1	52-35-11 P039-00/ /	ALL
D02519		BACC45FT22C55S PLUG-	81205	1	23-34-14 296/147/R 21	050-099, 150-199
D02520		BACS16AF1 PLUG-	81205	1	26-16-21 P035-00/ /	ALL
D02522		BACS16AF1 PLUG-	81205	1	26-16-21 P035-00/ /	ALL
D02524		BACS16AH1 PLUG-	81205	1	26-16-21 P035-00/ /	ALL
D02526		BACS16AH1 PLUG-	81205	1	26-16-21 P035-00/ /	ALL
D02528		10-60450-5 PLUG-	81205	1	33-37-11 P035-00/ /	ALL
D02529		KA-59-439-M06 PLUG	91836	1	34-45-11 380/315/0	050-099, 150-199, 277-299
D02530		BACS16AG1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02531		KA-59-439-M06 PLUG	91836	1	34-45-11 380/315/0	050-099, 150-199, 277-299
D02532		BACS16AG1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02533		KA-59-439-M06 PLUG	91836	1	34-45-11 380/315/0	050-099, 150-199, 277-299
D02534		BACS16W1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	050-099
D02535	9	CUSTOMER RECP-P21	81205	1	23-31-11 P21/ /	050-099
D02536		BACS16W1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	050-099
D02538		BACS16W1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	050-099
D02539		KA-59-392-M06 PLUG-E2-3 COAX	91836	1	34-45-11 AE0316/ /	050-099, 150-199, 277-299

EQUIPMENT LIST

D280T132

Section D02500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02540		BACS16AG1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	050-099
D02541		KA-59-392-M06 PLUG	91836	1	34-53-21 AE0316/ /	ALL
D02542		BACS16AG1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	050-099
D02543		KA-59-392-M06 PLUG	91836	1	34-53-21 ***/ /	ALL
D02544		BACS16AF1 RELAY SOCKET-	81205	1	25-53-23 P039-00/ /	ALL
D02546		BACS16AG1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02548		BACS16AG1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02550		BACS16AG1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02552		BACS16AG1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02554		BACS16W1 RELAY SOCKET-	81205	1	25-53-26 P039-00/ /	ALL
D02555		BACS16W1 PLUG-	81205	1	23-34-13 SHELF/E02/05	275-299
D02556		BACS16W1 RELAY SOCKET-	81205	1	25-53-26 P039-00/ /	ALL
D02557		BACS16X1 PLUG-	81205	1	23-34-13 SHELF/E02/05	275-299
D02558		BACS16W1 RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	ALL
D02560		BACS16W1 RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	ALL
D02562		BACS16X1A RELAY-SOCKET	81205	1	25-53-27 P039-00/ /	050-099
D02562		BACS16X1A RELAY SOCKET	81205	1	25-53-27 P039-00/ /	150-199

EQUIPMENT LIST

D280T132

Section D02500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02564		BACS16X1A RELAY-SOCKET	81205	1	25-53-27 P039-00/ /	050-099
D02564		BACS16X1A RELAY SOCKET	81205	1	25-53-27 P039-00/ /	150-199
D02566		BACS16AG1 RELAY SOCKET-	81205	1	25-53-21 P039-00/ /	ALL
D02567		BACC45FT16-24S PLUG	81205	1	23-31-12 0345/272/L 60	275-299
D02568		BACS16AH1 RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	050-099
D02569		MB12R-6 RECP-	02660	6	33-51-14 MULTI/ /	050-099
D02569		MB12R-6 RECP-	02660	8	33-51-14 MULTI/ /	150-199
D02570		BACS16AH1 RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	050-099
D02571		48-7191 RECP-	02660	6	33-51-14 MULTI/ /	050-099
D02571		48-7191 RECP-	02660	8	33-51-14 MULTI/ /	150-199
D02572		BACS16AH1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02573		48-7190 PLUG-	02660	6	33-51-14 MULTI/ /	050-099
D02573		48-7190 PLUG-	02660	8	33-51-14 MULTI/ /	150-199
D02575		KM-59-41 PLUG-COAXIAL	91836	1	23-34-15 0305/195/R035	050-099, 162-199
D02576		BACS16AH1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02577		MS27473T18A53P PLUG-DATA LOADER CTL PANEL	96906	1	34-61-15 P0061-00/ /	ALL
D02578		BACS16AH1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D02500

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02579		BACC45FT16A24S PLUG-DATA LOADER CTL PANEL	81205	1	34-61-15 P0061-00/ /	050-099
D02579		BACC45FT16A24S PLUG-DATA LOADER CTL PANEL	81205	0	34-61-15 P0061-00/ /	150-199, 275-299
D02580		BACS16AH1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02581		BACC45FT16A24S6 PLUG-DATA LOADER CTL PANEL	81205	1	34-61-15 P0061-00/ /	ALL
D02582		BACS16AH1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	050-099
D02583		MS27473T18A53S PLUG-AIRBORNE DATA LOADER	96906	1	34-61-15 P0061-00/ /	ALL
D02584		BACS16AH1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	050-099
D02588		BACS16AH1 RELAY SOCKET-	81205	1	25-53-24 P039-00/ /	ALL
D02589		MB12R-6 RECP-	02660	13	33-51-16 MULTI/ /	050-099
D02589		MB12R-6 RECP-	02660	15	33-51-16 MULTI/ /	150-199

EQUIPMENT LIST

D280T132

Section D02500

Page 5 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02603		BACC45FT10A5S PLUG	81205	1	21-66-11 290/283/L 12	050-099, 162-199
D02604		BACC63BW12S-3S PLUG-	81205	1	21-65-11 0661/303/L013	050-099
D02604		BACC63CE12S-3S PLUG-	81205	1	21-65-11 0654+008/303/L013	150-199, 275-278
D02604		BACC63BW12S-3S PLUG-	81205	1	21-65-11 0654+008/303/L013	280-299
D02605		BACC45FT14D15S PLUG	81205	1	21-66-11 271/284/L012	050-099, 162-199
D02607		MS3126F10-6S PLUG	96906	1	21-66-11 253/261/L 13	050-099, 162-199
D02608		BACC63CE12S-3S PLUG-	81205	1	21-65-11 0267/185/L070	ALL
D02610		BACC45FT16A24S PLUG-	81205	1	33-51-21 1428/203/R092	050-099, 162-199
D02610		BACC45FT16A24S PLUG-	81205	1	33-51-21 1406/203/R092	150-157, 275-299
D02611		XLR-5-31 RCPT	71468	1	23-42-11 251/246/L 14	050-099, 162-199
D02611 T		G62044 CLAMP	06324	1	23-42-11 0251/246/L014	050-099, 162-199
D02613		KA-59-439-M06 PLUG	91836	1	34-45-11 399/102/0000	050-099, 150-199, 277-299
D02615		KA-59-439-M06 PLUG	91836	1	34-45-11 399/102/0000	050-099, 150-199, 277-299
D02617		KA-59-439-M06 PLUG	91836	1	34-45-11 399/102/0000	050-099, 150-199, 277-299
D02619		DAMA11W1P PLUG	71468	1	23-32-44 735/310/R 15	280-299
D02619 T		D110278 LATCH	71468	2	23-32-44 / /	280-299
D02619 U		DA20961 JUNCTION SHELL	71468	1	23-32-44 731/310/R 25	280-299

EQUIPMENT LIST

D280T132

Section D02600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02619	V	DMA43717-6 COAX CONTACT PIN	71468	1	23-32-44 731/310/R 25	280-299
D02621		DAMA11W1P PLUG	71468	1	23-32-44 731/310/R 25	280-299
D02621	T	D110278 LATCH	71468	2	23-32-44 / /	280-299
D02621	U	DA20961 JUNCTION SHELL	71468	1	23-32-44 731/310/R 25	280-299
D02621	V	DMA43717-7 COAX CONTACT PIN	71468	1	23-32-44 731/310/R 25	280-299
D02628		10-60450-5 RELAY SOCKET-	81205	1	33-37-21 P039-00/ /	ALL
D02630		BACS16X1A RELAY SOCKET-	81205	1	33-37-21 P039-00/ /	ALL
D02631		DAMA11W1S PLUG	71468	1	23-32-44 655/257/R005	280-299
D02631	T	DA20961 JUNCTION SHELL	71468	1	23-32-44 0654+120/260/0000	280-299
D02631	U	D110278 LATCH	71468	2	23-32-44 / /	280-299
D02631	V	DMA43716-6 COAX CONTACT - PIN	71468	1	23-32-44 0654+120/260/0000	280-299
D02632		BACS16X1A PLUG-P35	81205	1	33-37-11 P035-00/ /	ALL
D02633		DAMA11W1S PLUG	71468	1	23-32-44 866/260/00	280-299
D02633	T	DA20961 JUNCTION SHELL	71468	1	23-32-44 866/260/00	280-299
D02633	U	D110278 LATCH	71468	2	23-32-44 / /	280-299
D02633	V	DMA43716-6 COAX CONTACT - PIN	71468	1	23-32-44 866/260/00	280-299
D02645		BACS16X1A PLUG-	81205	1	23-34-13 SHELF/E02/05	050-099

EQUIPMENT LIST

D280T132

Section D02600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02647	9	CUSTOMER PLUG	CUST	1	23-32-21 SHELF/E09/-01	152
D02647		BACC66H21CO4AB01 PLUG	81205	1	23-25-11 SHELF/E09/-01	150, 153-199, 277-299
D02647A	9	PARTAOFD02647 PLUG-PART OF D02647	CUST	0	23-32-21 SHELF/E09/-01	152
D02647A		PARTAOFD02647 PLUG-PART OF D02647		0	23-25-11 SHELF/E09/-01	150, 153-199, 277-299
D02647B		PARTBOFD02647 PLUG-PART OF D02647		0	23-25-11 SHELF/E09/-01	150, 153-199, 277-299
D02647C		PARTCOFD02647 PLUG-PART OF D02647		0	23-25-11 SHELF/E09/-01	150, 153-199, 277-299
D02647CT		249-2108-000 CONTACT E09-01 COAX, SATCOM	71468	1	23-25-12 SHELF/E09/-01	150, 153-199, 277-299
D02647CU		249-2108-000 CONTACT E9-1 COAX, SATCOM	71468	1	23-25-12 SHELF/E09/-01	277-299
D02649		BKAC2-V155M-30003 PLUG	91836	1	23-25-12 SHELF/E09/-01	150, 153-199, 277-299
D02649A		PARTAOFD02649 PLUG-PART OF D02649		0	23-25-12 SHELF/E09/-01	150, 153-199, 277-299
D02649AT		349-0005-000 CONTACT E9-1 COAX, SATCOM	71468	1	23-25-12 SHELF/E09/-01	150, 153-199, 277-299
D02649B		PARTBOFD02649 PLUG-PART OF D02649		0	23-25-12 SHELF/E09/-01	150, 153-199, 277-299
D02649BT		349-0005-000 CONTACT E9-1 COAX, SATCOM	71468	1	23-25-12 SHELF/E09/-01	277-299
D02649C		PARTCOFD02649 PLUG-PART OF D02649		0	23-25-12 SHELF/E09/-01	150, 153-199, 277-299
D02649CT		249-2108-000 CONTACT E09-01 COAX, SATCOM	71468	1	23-25-12 SHELF/E09/-01	150, 153-199, 277-299
D02649CU		249-2108-000 CONTACT E9-1 COAX, SATCOM	71468	1	23-25-12 SHELF/E09/-01	277-299
D02650		BACC45FT16A10S PLUG-	81205	1	25-33-11 1560/190/R030	ALL

EQUIPMENT LIST

D280T132

Section D02600

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02651		BKAC2-V155M-30008 PLUG	91836	1	23-25-12 SHELF/E10/	150, 153-199, 277-299
D02651A		PARTAOFD02651 PLUG-PART OF D02651		0	23-25-12 SHELF/E10/	150, 153-155, 162-165
D02651A		PARTAOFD02651 PLUG-PART OF D02651		0	23-25-12 / /	156-157, 166-199, 277-299
D02651AT		349-0005-000 CONTACT E10 COAX, SATCOM	71468	1	23-25-12 SHELF/E10/	150, 153-199, 277-299
D02651B		PARTBOFD02651 PLUG-PART OF D02651		0	23-25-12 / /	150, 153-199, 277-299
D02651BT		BACC47EN2 CONTACT E10 SHELF COAX, SATCOM	81205	1	23-25-16 SHELF 10/ /	156-157, 166-199, 277-299
D02651C		PARTCOFD02651 PLUG-PART OF D02651		0	23-25-12 / /	150, 153-199, 277-299
D02652		BACC45FT16D10S PLUG-	81205	1	25-33-11 1540/190/R050	ALL
D02653		BKAC2-V155M-30008 PLUG	91836	1	23-25-11 SHELF/E11/	156-157, 166-199, 277-299
D02653A		PARTA0FD02653 PLUG-PART OF D02653		0	23-25-11 / /	156-157, 166-199, 277-299
D02653AT		349-0005-000 CONTACT E11 COAX, SATCOM	71468	1	23-25-11 SHELF/E11/	156-157, 166-199, 277-299
D02653B		PARTB0FD02653 PLUG-PART OF D02653		0	23-25-11 / /	156-157, 166-199, 277-299
D02653BT		BACC47EN2 CONTACT E11 COAX, SATCOM	81205	1	23-25-11 SHELF/E11/	156-157, 166-199, 277-299
D02653C		PARTC0FD02653 PLUG-PART OF D02653		0	23-25-11 / /	156-157, 166-199, 277-299
D02654		BACC45FT16A10S PLUG-	81205	1	25-33-11 0256/175/R050	ALL
D02655		KA-59-251 PLUG	91836	1	23-25-11 1125/294/L014	277-299
D02656		BACC45FN16-10P RCPT-A2	81205	1	25-33-11 1559/282/L062	ALL

EQUIPMENT LIST

D280T132

Section D02600

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02657		KA-59-251 PLUG	91836	1	23-25-12 1125/294/L016	277-299
D02658		BACC45FN16-10P RCPT-A3	81205	1	25-33-11 1558/280/R062	ALL
D02659		KA-59-251 PLUG	91836	1	23-25-12 1125/294/L016	277-299
D02660		BACC45FN16-10P RCPT-F1	81205	1	25-33-11 0260/290/R060	ALL
D02661		KA-59-251 PLUG	91836	1	23-25-11 1125/294/L016	156-157, 166-199, 277-299
D02662		BACC63BN14C7SN PLUG-	81205	1	33-31-31 1831/242/R038	ALL
D02663		KA-59-251 PLUG	91836	1	23-25-16 1125/294/L016	277-299
D02664		BACC45FS14C7S PLUG-	81205	1	33-44-11 0565/294/L026	ALL
D02665		KA-59-251 PLUG	91836	1	23-25-12 1125/294/L016	150, 153-199, 277- 299
D02666		BACC63BP14R7SNL PLUG-	81205	1	33-44-11 0950/129/R024	ALL
D02666 T		710AS011M1412-62A CONDUIT ADAPTER	06324	1	33-44-11 / /	050-099, 153-199, 275-299
D02666 T		710AS011M1412-62A CONDUIT ADAPTER	81205	1	33-44-11 / /	150-152
D02667		KN-59-183 PLUG	91836	1	23-25-17 M 1125/294/L016	150, 153-199, 277- 299
D02669		KN-59-183 PLUG	91836	1	23-25-17 1125/294/L016	150, 153-199, 277- 299
D02670		BACC63BP14A7SNL PLUG-STRUT	81205	1	30-21-11 NL205/150/R3	ALL
D02670 T		BACC10KD14 CLAMP-	81205	1	30-21-11 / /	ALL
D02671		KA-39-100-M06 PLUG	91836	1	23-25-17 1125/294/L016	150, 153-199, 277- 299

EQUIPMENT LIST

D280T132

Section D02600

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02672		BACC65L66 RCPT-	81205	1	27-58-21 P050-00/ /	ALL
D02672 U		BACC47EM1 KEYING PLUG-	81205	2	27-58-21 / /	ALL
D02673		KN-59-329-M06 PLUG	91836	1	23-25-17 1125/294/L016	150, 153-199, 277-299
D02674		BACC65L66 RCPT-	81205	1	27-58-21 P050-00/ /	ALL
D02674 U		BACC47EM1 KEYING PLUG-	81205	2	27-58-21 / /	ALL
D02675		1203-4-9 PLUG	91836	1	23-25-17 1125/294/L016	150, 153-199, 277-299
D02676		BACC65L66 RCPT-	81205	1	27-58-21 AE0202/ /	ALL
D02676 U		BACC47EM1 KEYING PLUG-	81205	2	27-58-21 / /	ALL
D02677		MS3126F12-8S PLUG-		1	23-25-17 1070/300/L016	150, 153-155, 162-165
D02677		MS3126F12-8S PLUG		1	23-25-17 1125/284/L016	156-157, 166-199, 277-299
D02678		BACC45FT16A24S PLUG-	81205	1	33-11-11 0156/220/R008	ALL
D02679		126-14-5 PLUG	91836	1	23-25-11 1197+32/310/L010	167-199
D02681		KA-59-251 PLUG	91836	1	23-25-11 1197+32/310/L010	156-157, 166-199, 277-299
D02683		KN-59-329-M06 PLUG	91836	1	23-25-11 1197+32/310/L010	156-157, 166-199, 277-299
D02685		MS3126F12-10S PLUG	96906	1	23-25-11 1197+32/310/L010	156-157, 166-199, 277-299
D02687		KN-59-329-M06 PLUG	91836	1	23-25-17 1109/289/L054	150, 153-199
D02688		BACC45FT12C12S PLUG-	81205	1	33-13-11 0150/210/L010	ALL

EQUIPMENT LIST

D280T132

Section D02600

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02689		MS3126F16-26S PLUG		1	23-25-17 1109/285/R68	150, 153-199, 277-299
D02690		BACC45FT12A12S PLUG-	81205	1	33-21-11 0432/290/L065	275-278
D02690		BACC45FT12A12S PLUG-	81205	1	33-21-11 0433/290/L065	280-299
D02691		KN-59-329-M06 PLUG	91836	1	23-25-17 1109/289/L054	150, 153-199
D02692		BACC45FT12A12S PLUG-	81205	1	33-21-11 0521/290/L065	050-099, 150-199, 275-278
D02692		BACC45FT12A12S PLUG-	81205	1	33-21-11 0517/290/L056	280-299
D02693		MS3126F16-26S PLUG		1	23-25-17 1109/287/L072	150, 153-199, 277-299
D02694		BACC45FT12A12S PLUG-	81205	1	33-21-14 0609/290/L056	050-099
D02694		BACC45FT12A12S PLUG-	81205	1	33-21-11 0622/290/L065	150-199, 275-278
D02694		BACC45FT12A12S PLUG-	81205	1	33-21-11 0606/289/L056	280-299
D02695	9	CUSTOMER-1 PLUG P-5	CUST	1	23-25-14 P005-00/ /	150, 153-155, 162-165
D02695		BACC45FT14A15S6 PLUG P-5	81205	1	23-25-14 P005-00/ /	156-157, 166-199, 277-299
D02696		BACC45FT12A12S PLUG-	81205	1	33-21-14 0697/290/L056	050-099
D02696		BACC45FT12A12S PLUG-	81205	1	33-21-13 0654+084/295/L056	150-199
D02696		BACC45FT12A12S PLUG-	81205	1	33-21-13 0741/290/L065	275-278
D02696		BACC45FT12A12S PLUG-	81205	1	33-21-13 0667/290/L056	280-299
D02697		BACS16W1A PLUG-E2-6	81205	1	23-25-14 SHELF/E02/-06	150, 153-199, 277-299

EQUIPMENT LIST

D280T132

Section D02600

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02698		BACC45FT12A12S PLUG-	81205	1	33-21-13 0785/290/L056	050-099
D02698		BACC45FT12A12S PLUG-	81205	1	33-21-13 1014/295/L056	150-199
D02698		BACC45FT12A12S PLUG-	81205	1	33-21-13 0754/290/L056	275-299
D02699		BACS16W1A PLUG-E2-6	81205	1	23-25-14 SHELF/E02/-06	150, 153-199, 277- 299

EQUIPMENT LIST

D280T132

Section D02600

Page 8 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02700		BACC45FT12A12S PLUG-	81205	1	33-21-13 0868/290/L056	050-099
D02700		BACC45FT12A12S PLUG-	81205	1	33-21-13 0910/295/L056	150-199
D02700		BACC45FT12A12S PLUG-	81205	1	33-21-13 0872/290/L056	275-299
D02701		BACC45FT22-55S PLUG	81205	1	23-25-15 SHELF/E09/-01	150, 153-199, 277-299
D02703		KN-59-329-M06 PLUG	91836	1	23-25-17 1109/289/L054	150, 153-199
D02704		BACC66F11C10AA01 PLUG-	81205	1	29-33-11 SHELF/E02/04	ALL
D02704A		PARTAOFD02704 PLUG-PART OF D02704		0	29-33-11 / /	ALL
D02704B		PARTBOFD02704 PLUG-PART OF D02704		0	29-33-11 / /	ALL
D02705		KA-59-251 PLUG	91836	1	23-25-17 1109/289/L054	150, 153-199, 277-299
D02706		BACC66H21C40AA01 PLUG-	81205	1	28-21-11 SHELF/E02/04	050-099
D02706		BACC66H21C40AA01 PLUG-	81205	1	28-41-11 SHELF/E02/04	150-199, 275-299
D02706A		PARTAOFD02706 PLUG-PART OF D02706		0	28-41-11 / /	ALL
D02706B		PARTBOFD02706 PLUG-PART OF D02706		0	28-41-11 / /	ALL
D02706C		PARTCOFD02706 PLUG-PART OF D02706		0	28-41-11 / /	ALL
D02706CT		249-2203-000 CONTACT-COAX	71468	4	28-41-11 / /	050-099
D02707		KN-59-329-M06 PLUG	91836	1	23-25-17 1109/289/L054	150, 153-199, 277-299
D02708		BACC66F11C10AA01 PLUG-	81205	1	77-31-11 SHELF/E02/04	ALL

EQUIPMENT LIST

D280T132

Section D02700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02708A		PARTAOFD02708 PLUG-PART OF D02708	81205	0	77-31-11 / /	ALL
D02708B		PARTBOFD02708 PLUG-PART OF D02708		0	77-31-11 / /	ALL
D02708C		PARTCOFD02708 PLUG-PART OF D02708		0	77-31-11 / /	ALL
D02709		MS3126F12-10S PLUG		1	23-25-17 1109/289/L054	150, 153-199, 277-299
D02711		KN-59-329-M06 PLUG	91836	1	23-25-17 1109/289/L054	150, 153-199
D02712		BACC66F11C07AA01 PLUG-	81205	1	21-31-21 SHELF/E02/04	ALL
D02712A		PARTAOFD02712 PLUG-PART OF D02712		0	21-31-21 / /	ALL
D02713		KA-59-251 PLUG	91836	1	23-25-17 1109/289/R054	150, 153-199, 277-299
D02715		KN-59-329-M06 PLUG	91836	1	23-25-17 1109/289/R054	150, 153-199, 277-299
D02717		MS3126F12-10S PLUG-		1	23-25-17 1109/289/R54	150, 153-155, 162-165
D02717		MS3126F12-10S PLUG		1	23-25-17 1109/289/R54	156-157, 166-199, 277-299
D02719		BACC66F11C12AA01 PLUG	81205	1	23-25-16 SHELF/E09/01	167-199
D02719A		PARTAOFDO2719 PLUG-PART OF DO2719		0	23-25-16 SHELF/E09/01	167-199
D02719B		PARTBOFDO2719 PLUG-PART OF DO2719		0	23-25-16 SHELF/E09/01	167-199
D02719C		PARTCOFDO2719 PLUG-PART OF DO2719		0	23-25-16 SHELF/E09/01	167-199
D02734		BACC45FT12A12S PLUG-	81205	1	33-21-13 0998/290/L056	050-099
D02734		BACC45FT12A12S PLUG-	81205	1	33-21-13 0829/295/L056	150-199

EQUIPMENT LIST

D280T132

Section D02700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02734		BACC45FT12A12S PLUG-	81205	1	33-21-13 0952/290/L056	275-299
D02736		BACC45FT12A12S PLUG-	81205	1	33-21-11 0481/294/L020	275-278
D02736		BACC45FT12A12S PLUG-	81205	1	33-21-11 0478/294/L020	280-299
D02740		BACC45FT12A12S PLUG-	81205	1	33-21-11 0490/294/L020	050-099
D02740		BACC45FT12A12S PLUG-	81205	1	33-21-11 0490/294/L019	150-199, 275-278
D02740		BACC45FT12A12S PLUG-	81205	1	33-21-11 0492/294/L020	280-299
D02746		BACC45FT16A24S PLUG-	81205	1	33-51-11 0533/203/R092	050-099, 150-199
D02746		BACC45FT16A24S PLUG-	81205	1	33-51-11 0401/203/R092	275-299
D02748		BACC45FT12A12S PLUG-	81205	1	33-21-14 0613/294/L020	050-099
D02748		BACC45FT12A12S PLUG-	81205	1	33-21-11 0613/294/L020	150-199, 275-278
D02748		BACC45FT12A12S PLUG-	81205	1	33-21-11 0618/294/L020	280-299
D02750		BACC45FT12A12S PLUG-	81205	1	33-21-14 0621/294/L020	050-099
D02750		BACC45FT12A12S PLUG-	81205	1	33-21-13 654+99/280/L019	150-199
D02750		BACC45FT12A12S PLUG-	81205	1	33-21-13 0734/280/L019	275-278
D02752		BACC63BP14R7SNL RCPT-	81205	1	33-44-21 L1150/12/TIP	ALL
D02752 T		BACC10KD14 CLAMP-	81205	1	33-44-21 / /	ALL
D02758		BACC45FT12A12S PLUG-	81205	1	33-21-11 0708/294/L020	050-099

EQUIPMENT LIST

D280T132

Section D02700

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02758		BACC45FT12A12S PLUG-	81205	1	33-21-13 1048/295/L020	150-199
D02758		BACC45FT12A12S PLUG-	81205	1	33-21-13 0747/294/L020	275-278
D02758		BACC45FT12A12S PLUG-	81205	1	33-21-13 0750/294/L020	280-299
D02760		BACC63BP14A7SNL PLUG-STRUT	81205	1	30-21-11 NL205/150/R3	ALL
D02760 T		BACC10KD14 CLAMP-	81205	1	30-21-11 / /	ALL
D02762		BACC63BN14C7SN PLUG	81205	1	21-43-11 771/120/R 15	ALL
D02764		BACC63BN14C7SN PLUG-	81205	1	21-43-11 0940/128/R014	ALL
D02766		BACC45FS10A5S6 PLUG-	81205	1	21-43-11 0632/123/R003	ALL
D02767		KA-59-251 PLUG	91836	1	23-25-16 1030/310/L015	277-299
D02768		BACC45FS10C5S8 PLUG-	81205	1	21-43-11 0632/123/L003	ALL
D02769		KN-59-329-M06 PLUG	91836	1	23-25-16 1081/294/L014	156-157, 166-199, 277-299
D02770		BACC63BP10R5SNL PLUG-	81205	1	21-51-11 0852/123/L060	ALL
D02770 T		BACC10KD10 CLAMP-	81205	1	21-51-11 / /	ALL
D02771		MS3126F12-10S PLUG	96906	1	23-25-16 1017/310/L015	156-157, 166-199, 277-299
D02772		BACC45FT12A12S PLUG-	81205	1	33-16-12 0210/167/R030	ALL
D02773		MS3126F14-12P PLUG	91468	1	23-32-11 621/308/R 36	050-099
D02773 T		450DA001N14 BACKSHELL ASSY.	91468	1	23-32-11 621/308/R 36	050-099

EQUIPMENT LIST

D280T132

Section D02700

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02774		BACC45FT12A12S6 PLUG-	81205	1	33-16-12 0210/167/R030	ALL
D02775		KC-59-660-M06 PLUG-COAXIAL	91468	1	23-32-13 621/308/R 36	050-099
D02776		BACC45FT12A12S7 PLUG-	81205	1	33-16-12 0210/167/R030	ALL
D02778		BACC45FT12A12S8 PLUG-	81205	1	33-16-12 0210/167/R030	ALL
D02780		BACC45FT12A12S9 PLUG-	81205	1	33-16-12 0210/167/R030	ALL
D02782		BACC45FT14A15S PLUG-	81205	1	33-16-12 0210/167/R030	ALL
D02792		BACC63BP10R5SNL PLUG-	81205	1	21-51-12 0826/115/L011	ALL
D02792 T		BACC10KD10 CLAMP-	81205	1	21-51-12 / /	ALL
D02794		CN0966-10A20SN-000 PLUG-	13556	1	21-51-12 0745/169/L010	050-099, 150-199, 275-278
D02794		CN0966-10A20SN-000 PLUG-	13556	1	21-51-12 720/169/L010	280-299
D02794 T		BACC10KD10 CLAMP-	81205	1	21-51-12 / /	ALL
D02796		BACC45FT10-5S PLUG-	81205	1	21-61-21 MULTI/268/0000	050-099, 280-299
D02796		BACC45FT10-5S PLUG-	81205	1	21-61-21 MULTI/283/0000	150-199, 275-278
D02798		BACC63BN10B5SN PLUG-	81205	1	28-21-13 L0274/14/RS	ALL

EQUIPMENT LIST

D280T132

Section D02700
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02800		BACC63BN10C5SN PLUG-	81205	1	28-21-13 R0274/14/RS	ALL
D02802		BACC63BP18A8SNL PLUG-	81205	1	28-22-12 L0271/12/MS	ALL
D02802 T		BACC10KD18 CLAMP-	81205	1	28-22-12 / /	ALL
D02804		BACC63BP18A8SNL PLUG-	81205	1	28-22-12 R0257/ /	ALL
D02804 T		BACC10KD18 CLAMP-	81205	1	28-22-12 / /	ALL
D02806		BACC63BN10C5SN PLUG-	81205	1	28-42-12 L0258/14/RS	ALL
D02808		BACC63BN10C5SN PLUG-	81205	1	28-42-12 R0257/ /	ALL
D02812		BACC63BP14A3SNL PLUG-	81205	1	28-41-23 L0246/14/RS	ALL
D02812 T		BACC10KE14 CLAMP-	81205	1	28-41-23 / /	ALL
D02814		BACC63BP14A3SNL PLUG-	81205	1	28-41-23 R0230/14/TE	ALL
D02814 T		BACC10KE14 CLAMP-	81205	1	28-41-23 / /	ALL
D02816		BACC63BP14A7SNL PLUG-	81205	1	28-41-23 L0246/14/RS	ALL
D02816 T		BACC10KD14 CLAMP-	81205	1	28-41-23 / /	ALL
D02817		SO-1064-007 RELAY SOCKET	LEACH	1	34-61-17 E02-2/ /	157, 167-199, 275-299
D02817 V		-10401 I. D. TAPE TEXT AS BELOW	85480	1	34-61-17 E02-2/ /	275-276
D02818		BACC63BP14A7SNL PLUG-	81205	1	28-41-23 R0235/14/TE	ALL
D02818 T		BACC10KD14 CLAMP-	81205	1	28-41-23 / /	ALL

EQUIPMENT LIST

D280T132

Section D02800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02819		SO-1064-007 RELAY SOCKET	LEACH	1	34-61-27 E02-3/ /	157, 167-199, 275-299
D02819 V		-10601 I. D. TAPE TEXT AS BELOW	LEACH	1	34-61-27 E02-3/ /	275-276
D02820	1	BACC63BP16D10SNL PLUG-	81205	1	28-41-23 R0250/14/RS	ALL
D02820	2	BACC63BP16B10SNL PLUG-	81205	1	28-41-23 R0250/14/RS	ALL
D02820	3	BACC63BP16A10SNL PLUG-	81205	1	28-41-23 R0250/14/RS	ALL
D02820 T	1	BACC10KA16 CLAMP-	81205	1	28-41-23 / /	ALL
D02820 T	2	BACC10KA16 CLAMP-	81205	1	28-41-23 / /	ALL
D02820 T	3	BACC10KD16 CLAMP-	81205	1	28-41-22 / /	ALL
D02822		BACC63BN10C5SN PLUG-	81205	1	28-42-11 R0294/14/RS	ALL
D02824		CN0966-10A20SN-000 PLUG-	13556	1	21-51-12 0859/125/L040	ALL
D02824 T		BACC10KD10 CLAMP-	81205	1	21-51-12 / /	ALL
D02826		CN0966-10A20SN-000 PLUG-	13556	1	21-51-22 0745/169/R010	050-099
D02826	1	BACC63BP10C20SN PLUG-	13556	1	21-51-22 0745/169/R010	150-199, 275-299
D02826	2	R071010A20SN-000 PLUG-	13556	1	21-51-22 0745/169/R010	150-199, 275-278
D02826	2	CN0966-10A20SN-000 PLUG-	13556	1	21-51-22 0745/169/R010	280-299
D02826	3	CN0966-10A20SN-000 PLUG-	13556	1	21-51-22 0745/169/R010	150-199, 275-278
D02826 T		BACC10KD10 CLAMP-	81205	1	21-51-22 / /	ALL

EQUIPMENT LIST

D280T132

Section D02800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02828		BACC45FT10-5S PLUG-	81205	1	21-61-31 MULTI/283/0000	ALL
D02830	1	BACC63BP10C20SN PLUG-	13556	1	21-51-22 0859/125/R050	ALL
D02830	2	CN0966-10A20SN-000 PLUG-	13556	1	21-51-22 0859/125/R050	ALL
D02830 T		BACC10KD10 CLAMP	81205	1	21-51-22 / /	ALL
D02832		BACC65L41 RCPT-	81205	1	26-11-11 P054-00/ /	ALL
D02832 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-11 / /	ALL
D02834		BACC65L41 RCPT-	81205	1	26-11-12 P054-00/ /	ALL
D02834 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-12 / /	ALL
D02836		BACC65L41 RCPT-	81205	1	26-15-11 P054-00/ /	ALL
D02836 U		BACC47EM1 KEYING PLUG-	81205	2	26-15-11 / /	ALL
D02838		BACC65L41 RCPT-	81205	1	26-11-11 P054-00/ /	ALL
D02838 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-11 / /	ALL
D02840		BACC65L41 RCPT-	81205	1	26-11-12 P054-00/ /	ALL
D02840 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-12 / /	ALL
D02842		BACC65L66 RCPT-	81205	1	26-17-11 P054-00/ /	ALL
D02842 U		BACC47EM1 KEYING PLUG-	81205	2	26-17-11 / /	ALL
D02845		SO-1057-8912 RELAY SOCKET	35344	1	23-34-11 P033/ /	280-299

EQUIPMENT LIST

D280T132

Section D02800

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02846		BACC65L41 RCPT-	81205	1	26-11-21 P054-00/ /	ALL
D02846 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-21 / /	ALL
D02848		BACC65L41 RCPT-	81205	1	26-11-22 P054-00/ /	ALL
D02848 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-22 / /	ALL
D02850		BACC65L41 RCPT-	81205	1	26-15-11 P054-00/ /	ALL
D02850 U		BACC47EM1 KEYING PLUG-	81205	2	26-15-11 / /	ALL
D02852		BACC65L41 RCPT-	81205	1	26-11-21 P054-00/ /	ALL
D02852 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-21 / /	ALL
D02854		BACC65L41 RCPT-	81205	1	26-11-22 P054-00/ /	ALL
D02854 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-22 / /	ALL
D02860		BACC45FT12A12S PLUG-	81205	1	33-22-42 1455/284/L043	275-299
D02862		BACC45FT12A12S PLUG-	81205	1	33-22-42 1455/284/L037	275-299
D02864		BACC45FT12A12S PLUG-	81205	1	33-22-42 1455/284/R037	275-299
D02866		BACC45FT12A12S PLUG-	81205	1	33-22-42 1520/280/0000	050-099
D02868		BACC45FT12A12S PLUG-	81205	1	33-22-42 1520/280/0000	050-099
D02874		BACC45FT12A12S PLUG-	81205	1	33-27-11 0281/280/R035	ALL
D02876		BACC45FT12A12S PLUG-	81205	1	33-27-11 0281/280/R035	ALL

EQUIPMENT LIST

D280T132

Section D02800

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02878		BACC45FT12A12S PLUG-	81205	1	33-27-11 1576/284/L014	ALL
D02880		BACC45FT12A12S PLUG-	81205	1	33-22-42 1576/284/R14	050-099
D02880		BACC45FT12A12S PLUG-	81205	1	33-27-11 1576/284/R014	150-199, 275-299
D02882		BACC45FT12A12S PLUG-	81205	1	33-27-11 1567/284/R32	050-099
D02882		BACC45FT12A12S PLUG-	81205	1	33-27-11 1567/284/R032	150-199, 275-299
D02884		BACC45FT12A12S PLUG-	81205	1	33-22-42 1567/284/L032	050-099
D02884		BACC45FT12A12S PLUG-	81205	1	33-27-11 1567/284/L032	150-199, 275-299
D02886		BACS16W1 RELAY SOCKET-	81205	1	21-58-13 P036-00/ /	ALL
D02888		BACC45FT14A15S PLUG-P5	81205	1	30-32-11 P005-00/ /	ALL
D02889	9	CUSTOMER PLUG	CUST	1	23-22-12 P008-00/ /	275-278
D02889	9	CUSTOMER PLUG	CUST	1	23-22-12 E002-05/ /	280-299
D02889		BACS16AG1 RELAY SOCKET-E2-5	81205	1	23-22-12 SHELF/E02/05	277-278
D02890		BACC45FT14A15S9 PLUG-P5	81205	1	27-11-12 P005-00/ /	ALL
D02891		BACC45FT12-12S PLUG P8 PANEL	81205	1	23-22-12 P008-00/ /	275-299
D02892		BACS16X3A RELAY SOCKET-	81205	1	33-27-11 P019-00/ /	ALL
D02894		BACS16X3A RELAY SOCKET-	81205	1	33-27-11 P019-00/ /	ALL
D02896		BACS16W3 RELAY SOCKET-	81205	1	33-27-11 P025-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D02800

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02896		BACS16X3A RELAY SOCKET-	81205	1	33-27-11 P025-00/ /	275-299
D02898	1	DPX2DA-26S7S-33B-1401 PLUG-E2-1	71468	1	30-41-12 SHELF/E02/01	ALL
D02898	2	CE9307-18 PLUG-E2-1	71468	1	30-41-12 SHELF/E02/01	ALL
D02898 T		-10401 I.D. TAPE - TEXT AS BELOW	81205	1	30-41-12 / /	150-154, 275-276
D02898A		PARTAOFD02898 PLUG-PART OF D02898		0	30-41-12 / /	ALL
D02898B		PARTBOFD02898 PLUG-PART OF D02898		0	30-41-12 / /	ALL

EQUIPMENT LIST

D280T132

Section D02800
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02904		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D02910		BACS16W1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D02912		BACS16AF1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D02913		KC-59-585-M06 PLUG- COAXIAL	91836	1	23-32-34 383/229/L003	280-299
D02914		BACS16AF1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D02915		DAMA11W1P PLUG	71468	1	23-32-34 401/310/R 25	280-299
D02915 T		D110278 LATCH	71468	2	23-32-34 / /	280-299
D02915 U		DA20961 JUNCTION SHELL	71468	1	23-32-34 401/310/R 25	280-299
D02915 V		DMA43717-6 COAX CONTACT PIN	71468	1	23-32-34 401/310/R 25	280-299
D02916	1	DPX2DA-26S7S-33B-1401 PLUG-	71468	1	30-41-11 SHELF/E01/02	ALL
D02916	2	CE9307-18 PLUG-	71468	1	30-41-11 SHELF/E01/02	ALL
D02916 T		-10301 I.D. TAPE - TEXT AS BELOW	81205	1	30-41-11 / /	150-154, 275-276
D02916A		PARTAOFD02916 PLUG PART OF D02916		0	30-41-11 / /	ALL
D02916B		PARTBOFD02916 PLUG PART OF D02916		0	30-41-11 / /	ALL
D02917		BACC45FT12-12S PLUG	81205	1	23-32-34 383/229/L003	280-299
D02918		BACS16X1A RELAY SOCKET-	81205	1	27-81-21 P037-00/ /	ALL
D02920		BACS16AG1 RELAY SOCKET-	81205	1	28-26-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D02900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02922		BACS16AG1 RELAY SOCKET-	81205	1	28-26-11 P036-00/ /	ALL
D02926		BACS16X1A RELAY SOCKET-	81205	1	28-26-11 P036-00/ /	ALL
D02928		BACS16X1A RELAY SOCKET-	81205	1	28-26-11 P036-00/ /	ALL
D02932		BACC45FT12A12S PLUG-	81205	1	33-22-11 0329/286/L005	050-099
D02932		BACC45FT12A12S PLUG-	81205	1	33-22-11 0320/282/L006	150-199
D02932		BACC45FT12A12S PLUG-	81205	1	33-22-11 0360/286/L045	275-299
D02938		BACC45FT12A12S PLUG-	81205	1	33-21-33 0710/288/R056	050-099
D02938		BACC45FT12A12S PLUG-	81205	1	33-21-33 0754/288/R056	150-165, 167-199, 275-278
D02938		BACC45FT12A12S PLUG-	81205	1	33-21-33 0754/295/R056	166
D02938		BACC45FT12A12S PLUG-	81205	1	33-21-33 0757/289/R056	280-299
D02940		BACC45FT12A12S PLUG-	81205	1	33-21-32 0798/290/L056	050-099
D02940		BACC45FT12A12S PLUG-	81205	1	33-21-32 0842/288/L056	150-165, 167-199
D02940		BACC45FT12A12S PLUG-	81205	1	33-21-32 0842/295/L056	166
D02940		BACC45FT12A12S PLUG-	81205	1	33-21-32 0793/290/L056	275-299
D02942		BACC45FT12A12S PLUG-	81205	1	33-21-34 0879/290/L056	050-099
D02942		BACC45FT12A12S PLUG-	81205	1	33-21-34 0923/288/L056	150-165, 167-199
D02942		BACC45FT12A12S PLUG-	81205	1	33-21-34 0923/295/L056	166

EQUIPMENT LIST

D280T132

Section D02900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02942		BACC45FT12A12S PLUG-	81205	1	33-21-34 0961/290/L056	275-299
D02944		BACC45FT12A12S PLUG-	81205	1	33-21-34 1011/290/L056	050-099
D02944		BACC45FT12A12S PLUG-	81205	1	33-21-35 1011/288/R056	150-165, 167-199
D02944		BACC45FT12A12S PLUG-	81205	1	33-21-35 1011/295/R056	166
D02944		BACC45FT12A12S PLUG-	81205	1	33-21-34 0967/290/L056	275-299
D02946		BACC45FT12A12S PLUG-	81205	1	33-21-32 0446/290/L065	050-099, 150-165, 167-199, 275-299
D02946		BACC45FT12A12S PLUG-	81205	1	33-21-32 0446/295/L056	166
D02948		BACC45FT12A12S PLUG-	81205	1	33-21-33 0446/288/R056	050-099, 275-278
D02948		BACC45FT12A12S PLUG-	81205	1	33-21-33 528/288/R056	150-165
D02948		BACC45FT12A12S PLUG-	81205	1	33-21-33 446/295/R056	166
D02948		BACC45FT12A12S PLUG-	81205	1	33-21-33 446/288/R056	167-199
D02948		BACC45FT12A12S PLUG-	81205	1	33-21-33 0448/289/R056	280-299
D02948 V		289T0183-10101 I.D.TAPE TEXT AS BELOW	81205	1	33-21-33 528/288/R056	162-163
D02950		BACC45FT12A12S PLUG-	81205	1	33-21-33 0534/288/R056	050-099, 150-165, 167-199, 275-278
D02950		BACC45FT12A12S PLUG-	81205	1	33-21-33 0534/295/R056	166
D02950		BACC45FT12A12S PLUG-	81205	1	33-21-33 0537/289/R056	280-299
D02960		BACC45FT10A5S PLUG-	81205	1	21-45-11 0135/181/L013	ALL

EQUIPMENT LIST

D280T132

Section D02900

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02962		BACC45FT10A5S PLUG-	81205	1	21-45-11 0213/195/L063	ALL
D02964		BACC45FT10A5S PLUG-	81205	1	21-45-11 0135/185/R013	ALL
D02966		BACC45FT10A5S PLUG-	81205	1	21-45-11 0166/182/R039	ALL
D02968		BACC45FT10A5S PLUG-	81205	1	25-63-11 0289/225/R080	050-099
D02968		BACC45FT10-5S PLUG-	81205	1	25-63-11 289/275/R080	150-199
D02968		BACC45FT10-5S PLUG-	81205	1	25-63-11 284/225/R085	275-299
D02970		BACC45FT10A5S PLUG-	81205	1	25-63-11 0284/253/L053	050-099
D02970		BACC45FT10A5S PLUG-	81205	1	25-63-11 0291/275/L080	150-199
D02970		BACC45FT10A5S PLUG-	81205	1	25-63-11 0291/225/L085	275-299
D02972		BACC45FT10-5S PLUG-	81205	1	25-63-11 0834/260/R018	050-099
D02972		BACC45FT10-5S PLUG-	81205	1	25-63-11 0917/260/L018	150-199
D02972		BACC45FT10-5S PLUG-	81205	1	25-63-11 0801/260/L018	275-299
D02974		BACC45FT10A5S PLUG-	81205	1	25-63-11 1540/253/R054	050-099
D02974		BACC45FT10A5S PLUG-	81205	1	25-63-11 1541/253/R080	150-199
D02974		BACC45FT10A5S PLUG-	81205	1	25-63-11 1541/253/R054	275-299
D02976		BACC45FT10A5S PLUG-	81205	1	25-63-11 1542/253/L054	050-099
D02976		BACC45FT10A5S PLUG-	81205	1	25-63-11 1541/253/L080	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D02900

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02978		BACC45FT12A12S PLUG-	81205	1	33-21-13 0772/294/L020	050-099
D02978		BACC45FT12A12S PLUG-	81205	1	33-21-13 0911/295/L020	150-199
D02978		BACC45FT12A12S PLUG-	81205	1	33-21-13 0879/294/L020	275-299
D02984		BACC45FN8-2S RCPT-	81205	1	35-21-14 1049/280/L005	ALL
D02985		BACS16AF1 RELAY SOCKET -	81205	1	28-22-31 P033-00/ /	ALL
D02985 U		-10601 I.D. TAPE - TEXT AS BELOW	81205	1	28-22-31 / /	150-199, 275-299
D02986		BACC45FN8-2S RCPT-	81205	1	35-21-14 1080/280/L005	ALL
D02987		BACS16AF1 RELAY SOCKET -	81205	1	28-22-31 P033-00/ /	ALL
D02987 U		-10601 I.D. TAPE - TEXT AS BELOW	81205	1	28-22-31 / /	157, 167-199, 277-299
D02988		BACC45FN8-2S RCPT-	81205	1	35-21-14 1106/280/L005	ALL
D02990		BACC45FN8-2S RCPT-	81205	1	35-21-14 1133/280/L005	ALL
D02992		BACC45FN8-2S RCPT-	81205	1	35-21-14 1157/280/L005	ALL
D02994		BACC45FN8-2S RCPT-	81205	1	35-21-14 1181/280/L005	ALL
D02995		KA-59-353-M06 PLUG	91836	1	23-25-11 1197+33/320/L010	167-199
D02996		BACC45FN8-2S RCPT-	81205	1	35-21-14 1211/280/L005	050-099
D02996		BACC45FN8-2S RCPT-	81205	1	35-21-14 1197+015/280/L005	150-199, 275-299
D02998		BACC45FN8-2S RCPT-	81205	1	35-21-14 1237/280/L005	050-099

EQUIPMENT LIST

D280T132

Section D02900

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D02998		BACC45FN8-2S RCPT-	81205	1	35-21-14 1197+041/280/L005	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D02900
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03000		BACC45FN8-2S RCPT-	81205	1	35-21-14 1264/280/L005	050-099
D03000		BACC45FN8-2S RCPT-	81205	1	35-21-14 1197+068/280/L005	150-199, 275-299
D03002		BACC45FN8-2S RCPT-	81205	1	35-21-14 1289/280/L005	ALL
D03004		BACC45FN8-2S RCPT-	81205	1	35-21-14 1313/280/L005	ALL
D03006		BACC45FN8-2S RCPT-	81205	1	35-21-14 1344/280/L005	ALL
D03008		BACC45FN8-2S RCPT-	81205	1	35-21-14 1370/280/L000	ALL
D03010		BACC45FN8-2S RCPT-	81205	1	35-21-14 1397/280/L005	ALL
D03012		BACC45FN8-2S RCPT-	81205	1	35-21-14 1421/280/L005	ALL
D03014		BACC45FN8-2S RCPT-	81205	1	35-21-14 1454/280/L005	050-099
D03014		BACC45FN8-2S RCPT-	81205	1	35-21-14 1450/280/L005	150-199, 275-299
D03016		BACC45FN8-2S RCPT-	81205	1	35-21-13 1043/270/R073	275-299
D03018		BACC45FN8-2S RCPT-	81205	1	35-21-13 1047/270/R073	050-099
D03018		BACC45FN8-2S RCPT-	81205	1	35-21-13 1071/270/R073	150-199, 275-299
D03020		BACC45FN8-2S RCPT-	81205	1	35-21-13 1097/270/R073	050-099
D03020		BACC45FN8-2S RCPT-	81205	1	35-21-13 1101/270/R073	150-199, 275-299
D03022		BACC45FN8-2S RCPT-	81205	1	35-21-13 1116/270/R073	050-099
D03022		BACC45FN8-2S RCPT-	81205	1	35-21-13 1131/270/R073	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D03000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03024		BACC45FN8-2S RCPT-	81205	1	35-21-13 1146/270/R073	050-099
D03024		BACC45FN8-2S RCPT-	81205	1	35-21-13 1159/270/R073	150-199, 275-299
D03026		BACC45FN8-2S RCPT-	81205	1	35-21-13 1175/270/R073	050-099
D03026		BACC45FN8-2S RCPT-	81205	1	35-21-13 1189/270/R073	150-199, 275-299
D03028		BACC45FN8-2S RCPT-	81205	1	35-21-13 1204/270/R073	ALL
D03030		BACC45FN8-2S RCPT-	81205	1	35-21-13 1234/270/R073	ALL
D03032		BACC45FN8-2S RCPT-	81205	1	35-21-13 1263/270/R073	ALL
D03034		BACC45FN8-2S RCPT-	81205	1	35-21-13 1292/270/R073	ALL
D03036		BACC45FN8-2S RCPT-	81205	1	35-21-13 1322/270/R073	ALL
D03038		BACC45FN8-2S RCPT-	81205	1	35-21-13 1351/270/R073	ALL
D03040		BACC45FN8-2S RCPT-	81205	1	35-21-13 1380/270/R073	ALL
D03042		BACC45FN8-2S RCPT-	81205	1	35-21-13 1410/270/R073	ALL
D03044		BACC45FN8-2S RCPT-	81205	1	35-21-13 1428/270/R073	ALL
D03050		BACC66F11C16AA01 PLUG-	81205	1	21-51-22 SHELF/E03/01	050-099, 150-156, 162-166, 275-276
D03050		BACC66F11C88AA01 PLUG-	81205	1	21-51-22 SHELF/E03/01	157, 167-199, 277- 299
D03050A		PARTAOFD03050 PLUG-PART OF D03050		0	21-51-22 / /	ALL
D03050B		PARTBOFD03050 PLUG-PART OF D03050		0	21-51-22 / /	ALL

EQUIPMENT LIST

D280T132

Section D03000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03050C		PARTCOFD03050 PLUG- PART OF D03050		0	21-53-21 / /	ALL
D03056		BACC63BP16A10S6L PLUG-	81205	1	28-21-11 AW0601/ /	ALL
D03056 T		BACC10KE16 CLAMP-	81205	1	28-41-11 / /	050-099, 150-156, 162-166, 275-276
D03056 T		BACC10KE16 CLAMP-	81205	1	28-21-11 / /	157, 167-199, 277- 299
D03058		BACC45FT12A12S PLUG-	81205	1	21-58-16 0190/165/R033	ALL
D03060		BACC45FT14A15S PLUG-	81205	1	21-58-16 0390/160/L080	ALL
D03062		BACC63BN14C7SN PLUG-	81205	1	33-31-21 0843/114/L010	ALL
D03064		BACC45FT12A12S PLUG-	81205	1	21-58-16 0386/187/R073	ALL
D03066		BACC45FT10A5S PLUG-	81205	1	21-58-11 0374/120/L030	ALL
D03068		BACC45FT10A5S PLUG-	81205	1	21-58-11 0190/178/R041	ALL
D03072		BACC63CE10SL-3S PLUG-STRUT	81205	1	75-23-11 NL155/155/R3	ALL
D03072 T		BACC10HW12 CLAMP	81205	1	75-23-11 NL155/155/R3	ALL
D03074		BACC45FS10A5S8 PLUG-	81205	1	21-58-12 0410/167/L090	ALL
D03076		BACC45FT14A15S PLUG-	81205	1	21-58-12 0505/160/L075	050-099
D03076		BACC45FT14A15S PLUG-	81205	1	21-58-12 0511/160/L075	150-199, 275-299
D03082		BACC45FT10A5S PLUG-	81205	1	33-21-33 0741/266/L081	050-099
D03082		BACC45FT10A5S PLUG	81205	1	33-21-33 0741/266/L080	150-199, 275-278

EQUIPMENT LIST

D280T132

Section D03000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03082		BACC45FT10A5S PLUG	81205	1	33-21-33 0726/266/L081	280-299
D03084		BACC45FT10A5S PLUG-	81205	1	33-21-32 0770/250/L075	050-099
D03084		BACC45FT10A5S PLUG-	81205	1	33-21-32 0785/250/L075	150-199, 275-278
D03084		BACC45FT10A5S PLUG-	81205	1	33-21-32 0770/266/L081	280-299
D03086		BACC45FT10A5S PLUG-	81205	1	33-21-33 0827/266/L080	150-199
D03088		BACC45FT10A5S PLUG-	81205	1	33-21-32 0939/266/L081	050-099
D03088		BACC45FT10A5S PLUG-	81205	1	33-21-34 0912/266/L081	150-199, 275-299
D03090		BACC45FT10A5S PLUG-	81205	1	33-21-34 0895/266/L081	050-099
D03090		BACC45FT10A5S PLUG-	81205	1	33-21-34 0954/266/L081	275-299
D03092		BACC45FT10A5S PLUG-	81205	1	33-21-34 0983/266/L081	050-099
D03092		BACC45FT10A5S PLUG-	81205	1	33-21-35 1000/266/L081	150-199
D03092		BACC45FT10A5S PLUG-	81205	1	33-21-34 1000/266/L081	275-299
D03094		BACC45FT10A5S PLUG-	81205	1	33-21-34 1042/266/L081	150-199, 275-299
D03096		BACC45FT10A5S PLUG-	81205	1	33-21-34 0866/266/L081	050-099
D03096		BACC45FT10A5S PLUG-	81205	1	33-21-34 0871/266/L081	150-199, 275-299
D03098		BACC45FT10A5S PLUG-	81205	1	33-21-33 0391/266/L081	275-299

EQUIPMENT LIST

D280T132

Section D03000
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03100		BACC45FT10A5S PLUG-	81205	1	33-21-32 0418/266/L081	ALL
D03102		BACC45FT10A5S PLUG-	81205	1	33-21-33 0466/266/R081	050-099
D03102		BACC45FT10A5S PLUG-	81205	1	33-21-33 0477/266/L081	150-157, 275-278
D03102		BACC45FT10A5S PLUG-	81205	1	33-21-32 477/266/L080	162-163
D03102		BACC45FT10A5S PLUG-	81205	1	33-21-32 0477/266/L081	164-199
D03102		BACC45FT10A5S PLUG-	81205	1	33-21-33 0462/266/L081	280-299
D03102 V		289T0183-10202 I.D.TAPE TEXT AS BELOW	81205	1	33-21-32 477/266/L080	162-163
D03104		BACC45FT10A5S PLUG-	81205	1	33-21-32 0506/266/L081	ALL
D03106		BACC45FT10A5S PLUG-	81205	1	33-21-33 0550/266/L081	050-099, 150-199, 275-278
D03106		BACC45FT10A5S PLUG-	81205	1	33-21-33 0555/266/L081	280-299
D03108		BACC45FT10A5S PLUG-	81205	1	33-21-32 0594/266/L081	050-099, 280-299
D03108		BACC45FT10A5S PLUG-	81205	1	33-21-32 0607/266/L081	150-199, 275-278
D03110		BACC45FT10A5S PLUG-	81205	1	33-21-33 0638/266/L081	050-099, 280-299
D03110		BACC45FT10A5S PLUG-	81205	1	33-21-33 0653/266/L081	150-199, 275-278
D03112		BACC45FT10A5S PLUG-	81205	1	33-21-32 0682/266/L081	050-099, 150-199, 275-278
D03112		BACC45FT10A5S PLUG-	81205	1	33-21-32 0682/266/L085	280-299
D03114		BACC45FT10A5S PLUG-	81205	1	33-21-33 0760/266/R081	050-099

EQUIPMENT LIST

D280T132

Section D03100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03114		BACC45FT10A5S PLUG-	81205	1	33-21-33 0741/266/R081	150-199, 275-278
D03114		BACC45FT10A5S PLUG-	81205	1	33-21-33 0756/266/R081	280-299
D03116		BACC45FT10A5S PLUG-	81205	1	33-21-32 0785/266/R080	050-099, 150-199, 275-278
D03116		BACC45FT10A5S PLUG-	81205	1	33-21-32 0780/266/R085	280-299
D03118		BACC45FT10A5S PLUG-	81205	1	33-21-33 0827/266/R081	150-199
D03120		BACC45FT10A5S PLUG-	81205	1	33-21-34 0925/266/R081	050-099
D03120		BACC45FT10A5S PLUG-	81205	1	33-21-35 0912/266/R081	150-199, 275-299
D03122		BACC45FT10A5S PLUG-	81205	1	33-21-35 0969/266/R081	050-099
D03122		BACC45FT10A5S PLUG-	81205	1	33-21-35 0954/266/R081	275-278
D03122		BACC45FT10A5S PLUG-	81205	1	33-21-35 0954/266/R080	280-299
D03124		BACC45FT10A5S PLUG-	81205	1	33-21-34 1000/266/R081	050-099
D03124		BACC45FT10A5S PLUG-	81205	1	33-21-35 1000/266/R081	150-199, 275-278
D03124		BACC45FT10A5S PLUG-	81205	1	33-21-35 1000/266/R080	280-299
D03126		BACC45FT10A5S PLUG-	81205	1	33-21-35 1042/266/R081	150-165, 167-199, 275-299
D03126		BACC45FT10A5S PLUG-	81205	1	33-21-35 1040/266/R081	166
D03128		BACC45FT10A5S PLUG-	81205	1	33-21-34 0881/266/R081	050-099
D03128		BACC45FT10A5S PLUG-	81205	1	33-21-34 0871/266/R081	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D03100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03129		BACC45FT22A55S PLUG	81205	1	34-12-61 325/155/L049	ALL
D03130		BACC45FT10A5S PLUG-	81205	1	33-21-34 1088/266/R081	050-099
D03130		BACC45FT10A5S PLUG-	81205	1	33-21-35 1088/266/R081	150-199, 275-299
D03131		BACC45FT22A55S PLUG	81205	1	34-12-62 325/155/R045	ALL
D03132		BACC45FT10A5S PLUG-	81205	1	33-21-35 1145/284/R081	050-099
D03132		BACC45FT10A5S PLUG-	81205	1	33-21-35 1130/266/R081	150-165, 167-199, 275-299
D03132		BACC45FT10A5S PLUG-	81205	1	33-21-35 1128/266/R081	166
D03134		BACC45FT10A5S PLUG-	81205	1	33-21-35 1189/284/R081	050-099
D03134		BACC45FT10A5S PLUG-	81205	1	33-21-35 1176/266/R081	150-199, 275-299
D03136		BACC45FT10A5S PLUG-	81205	1	33-21-31 1233/284/R081	050-099
D03136		BACC45FT10A5S PLUG-	81205	1	33-21-35 1218/266/R081	150-165, 167-199, 275-299
D03136		BACC45FT10A5S PLUG-	81205	1	33-21-35 1216/266/R081	166
D03138		BACC45FT10A5S PLUG-	81205	1	33-21-34 1427/266/R081	ALL
D03140		BACC45FT10A5S PLUG-	81205	1	33-21-35 1277/284/R081	050-099
D03140		BACC45FT10A5S PLUG-	81205	1	33-21-35 1264/266/R081	150-199, 275-299
D03142		BACC45FT10A5S PLUG-	81205	1	33-21-31 1321/284/R081	050-099
D03142		BACC45FT10A5S PLUG-	81205	1	33-21-35 1304/266/R081	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D03100

Page 3

May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03144		BACC45FT10A5S PLUG-	81205	1	33-21-35 1365/284/R081	050-099
D03144		BACC45FT10A5S PLUG-	81205	1	33-21-35 1352/266/R081	150-199, 275-299
D03146		BACC45FT10A5S PLUG-	81205	1	33-21-31 1409/266/R081	050-099
D03146		BACC45FT10A5S PLUG-	81205	1	33-21-35 1392/266/R081	150-199, 275-299
D03148		BACC45FT12D12S PLUG-	81205	1	21-31-21 1550/148/L049	ALL
D03150		BACC45FT10A5S PLUG-	81205	1	33-21-34 1071/266/L081	050-099
D03150		BACC45FT10A5S PLUG-	81205	1	33-21-34 1088/266/L081	150-199, 275-299
D03152		BACC45FT10A5S PLUG-	81205	1	33-21-35 1128/266/L080	050-099
D03152		BACC45FT10A5S PLUG-	81205	1	33-21-34 1130/266/L081	150-199, 275-299
D03154		BACC45FT10A5S PLUG-	81205	1	33-21-34 1166/265/L081	050-099
D03154		BACC45FT10A5S PLUG-	81205	1	33-21-34 1176/265/L081	150-199, 275-299
D03156		BACC45FT10A5S PLUG-	81205	1	33-21-34 1203/265/L081	050-099
D03156		BACC45FT10A5S PLUG-	81205	1	33-21-34 1218/266/L081	150-199, 275-299
D03158		BACC45FT10A5S PLUG-	81205	1	33-21-34 1423/266/L081	050-099
D03158		BACC45FT10A5S PLUG-	81205	1	33-21-34 1438/266/L081	150-199, 275-299
D03160		BACC45FT10A5S PLUG-	81205	1	33-21-34 1253/280/L081	050-099
D03160		BACC45FT10A5S PLUG-	81205	1	33-21-34 1262/266/L081	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D03100

Page 4

May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03162		BACC45FT10A5S PLUG-	81205	1	33-21-34 1291/266/L081	050-099
D03162		BACC45FT10A5S PLUG-	81205	1	33-21-34 1304/266/L081	150-199, 275-299
D03164		BACC45FT10A5S PLUG-	81205	1	33-21-34 1345/265/L081	ALL
D03166		BACC45FT10A5S PLUG-	81205	1	33-21-34 1379/266/L081	050-099
D03166		BACC45FT10A5S PLUG-	81205	1	33-21-34 1392/266/L081	150-199, 275-299
D03174		BACS16W3 RELAY SOCKET-	81205	1	33-45-11 P037-00/ /	050-099
D03174		BACS16W3 RLY SKT	81205	1	33-45-11 P037-00/ /	150-199, 275-299
D03176		BACS16W3 RELAY SOCKET	81205	1	33-45-11 P037-00/ /	ALL
D03180		BACC45FT10A5S PLUG-	81205	1	33-21-33 0389/266/R080	275-278
D03180		BACC45FT10A5S PLUG-	81205	1	33-21-33 0389/266/R081	280-299
D03182		BACC45FT10A5S PLUG-	81205	1	33-21-33 0448/266/R081	050-099
D03182		BACC45FT10A5S PLUG-	81205	1	33-21-33 0433/266/R080	150, 153-157
D03182		BACC45FT10A5S PLUG-	81205	1	33-21-33 0433/266/R081	151-152, 162-199
D03182		BACC45FT10A5S PLUG-	81205	1	33-21-31 0433/266/R081	275-278
D03182		BACC45FT10A5S PLUG-	81205	1	33-21-31 0449/266/R081	280-299
D03184		BACC45FT10A5S PLUG-	81205	1	33-21-33 0492/266/R081	050-099
D03184		BACC45FT10A5S PLUG-	81205	1	33-21-33 0477/266/R081	150-199, 275-278

EQUIPMENT LIST

D280T132

Section D03100

Page 5

May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03184		BACC45FT10A5S PLUG-	81205	1	33-21-33 0493/266/R081	280-299
D03186		BACC45FT10A5S PLUG-	81205	1	33-21-32 0540/266/R081	ALL
D03188		BACC45FT10A5S PLUG-	81205	1	33-21-33 0580/266/R081	050-099, 150-199, 275-278
D03188		BACC45FT10A5S PLUG-	81205	1	33-21-33 0581/266/R081	280-299
D03190		BACC45FT10A5S PLUG-	81205	1	33-21-32 0628/266/R081	050-099
D03190		BACC45FT10A5S PLUG-	81205	1	33-21-32 0607/266/R081	150-199, 275-278
D03190		BACC45FT10A5S PLUG-	81205	1	33-21-32 0625/266/R081	280-299
D03192		BACC45FT10A5S PLUG-	81205	1	33-21-33 0668/266/R081	050-099
D03192		BACC45FT10A5S PLUG-	81205	1	33-21-33 0653/266/R081	150-199, 275-278
D03192		BACC45FT10A5S PLUG-	81205	1	33-21-33 0654+15/266/R081	280-299
D03194		BACC45FT10A5S PLUG-	81205	1	33-21-32 0710/266/R081	050-099, 150-199, 275-278
D03194		BACC45FT10A5S PLUG-	81205	1	33-21-32 0713/268/R085	280-299
D03196		BACC45FT12D12S PLUG-	81205	1	21-31-11 1550/140/L040	ALL

EQUIPMENT LIST

D280T132

Section D03100
Page 6 End
May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03200		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0397/270/L073	275-299
D03202		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0397/270/R073	275-299
D03206		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0429/270/L073	050-099, 150-199
D03206		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0427/270/L073	275-299
D03208		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0449/270/L073	050-099, 150-199
D03208		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0456/270/L073	275-299
D03210		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0463/270/L073	050-099
D03210		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0463/270/073	150-199
D03210		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0463/270/073	275-299
D03212		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0493/270/L073	050-099, 150-199
D03212		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0493/270/L073	275-299
D03214		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0522/270/L073	050-099, 150-199
D03214		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0522/270/L073	275-299
D03216		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0551/270/L073	050-099, 150-199
D03216		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0551/270/L073	275-299
D03218		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0581/270/L073	050-099, 150-199
D03218		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0581/270/L073	275-299

EQUIPMENT LIST

D280T132

Section D03200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03220		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0610/270/L073	050-099, 150-199
D03220		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0610/270/L073	275-299
D03222		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0639/270/L073	050-099, 150-199
D03222		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0639/270/L073	275-299
D03224		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0669/270/L073	050-099
D03224		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0656/270/L073	275-278
D03224		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0665/270/L073	280-299
D03226		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0698/270/L073	050-099
D03226		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0700/270/L073	150-199
D03226		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0682/270/L073	275-278
D03226		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0692/270/L073	280-299
D03228		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0727/270/L073	050-099
D03228		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0737/270/L073	150-199
D03228		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0712/270/L073	275-278
D03228		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0713/270/L073	280-299
D03230		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0757/270/L073	050-099
D03230		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0742/270/L073	275-278

EQUIPMENT LIST

D280T132

Section D03200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03230		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0741/270/L073	280-299
D03232		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0786/270/L073	050-099
D03232		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0801/270/L073	150-199
D03232		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0797/270/L073	275-278
D03232		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0798/270/L073	280-299
D03234		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0831/270/L073	150-199
D03236		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0859/270/L073	150-199
D03238		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0875/270/L073	050-099
D03238		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0889/270/L073	150-199
D03238		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0879/270/L073	275-299
D03240		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0893/270/L073	050-099
D03240		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0919/270/L073	150-199
D03240		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0893/270/L073	275-299
D03242		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0923/270/L073	050-099
D03242		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0926/270/L073	275-299
D03244		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0940/270/L073	050-099
D03244		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0955/270/L073	275-299

EQUIPMENT LIST

D280T132

Section D03200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03246		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0970/270/L073	050-099
D03246		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1007/270/L073	150-199
D03246		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0983/270/L073	275-299
D03248		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0999/270/L073	050-099
D03248		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1028/270/L073	150-199
D03248		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1013/270/L073	275-299
D03250		BACC63CE10SL-3S PLUG-STRUT	81205	1	75-23-11 NL155/155/R3	ALL
D03250 T		BACC10HW12 CLAMP	81205	1	75-23-11 NL155/155/R3	050-099, 150-199
D03250 T		BACC10HW12 CLAMP	81205	1	75-23-11 / /	275-299
D03252		SO-1057-8912 PLUG-	35344	1	24-33-11 P006-00/ /	ALL
D03260		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0396/280/L005	050-099, 150-199
D03260		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 0396/280/L005	275
D03260		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 396/280/L005	276-299
D03262		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0427/280/L005	050-099, 150-199
D03262		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 0427/280/L005	275-299
D03264		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0453/280/L005	050-099, 150-199
D03264		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 0453/280/L005	275-299

EQUIPMENT LIST

D280T132

Section D03200

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03266		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0480/280/L005	050-099, 150-199
D03266		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 0480/280/L005	275-299
D03268		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0504/280/L005	050-099, 150-199
D03268		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0504/280/L005	275-299
D03270		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0528/280/L005	050-099, 150-199
D03270		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0528/280/L005	275
D03270		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 528/280/L005	276-299
D03272		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0559/280/L005	050-099, 150-199
D03272		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0559/280/L005	275-299
D03274		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0585/280/L005	050-099, 150-199
D03274		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0585/280/L005	275-299
D03276		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0612/280/L005	050-099, 150-199
D03276		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0612/280/L005	275-299
D03278		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0636/280/L005	050-099
D03278		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 636/280/L005	150-199
D03278		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0636/280/L005	275-299
D03280		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 659/280/L005	050-099

EQUIPMENT LIST

D280T132

Section D03200

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03280		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 654+06/280/L005	150-199
D03280		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0654+006/280/L005	275-299
D03282		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 690/280/L005	050-099
D03282		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 654+37/280/L005	150-199
D03282		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0654+037/280/L005	275-299
D03286		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0893/280/L005	050-099
D03286		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0820/280/L005	150-199
D03286		BACC45FN10A5S6 RECPT	81205	1	33-24-13 893/280/L 5	280-299
D03288		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0917/280/L005	050-099
D03288		BACC45FN10A5S6 RCPT	81205	1	33-24-13 0915/280/L005	275-299
D03290		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0948/280/L005	050-099
D03290		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0946/280/L005	275-299
D03292		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0974/280/L005	050-099
D03292		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0972/280/L005	275-299
D03294		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1001/280/L005	050-099
D03294		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1009/280/L005	150-199
D03294		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1000/280/L005	275-299

EQUIPMENT LIST

D280T132

Section D03200

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03296		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1025/280/L005	050-099, 150-199
D03296		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1025/280/L005	275-299
D03298		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1049/280/L005	050-099, 150-199
D03298		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1049/280/L005	275-299

EQUIPMENT LIST

D280T132

Section D03200

Page 7 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03300		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1080/280/L005	050-099, 150-199
D03300		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1080/280/L005	275-299
D03302		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1106/280/L005	050-099, 150-199
D03302		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1106/280/L005	275-299
D03304		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0429/270/R073	150-157
D03304		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0427/270/R073	275-299
D03306		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0449/270/R070	050-099, 150-199
D03306		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0456/270/R070	275-278
D03306		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0456/270/R073	280-299
D03308		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0463/270/R070	050-099, 150-199
D03308		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0463/270/R070	275-278
D03308		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0463/270/R073	280-299
D03310		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0493/270/R070	050-099, 150-199
D03310		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0493/270/R070	275-278
D03310		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0493/270/R073	280-299
D03312		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0522/270/R070	050-099, 150-199
D03312		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0522/270/R070	275-278

EQUIPMENT LIST

D280T132

Section D03300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03312		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0522/270/R073	280-299
D03314		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0551/270/R070	050-099, 150-199
D03314		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0551/270/R070	275-278
D03314		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0551/270/R073	280-299
D03316		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0581/270/R070	050-099, 150-199
D03316		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0581/270/R070	275-278
D03316		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0581/270/R073	280-299
D03318		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0610/270/R070	050-099, 150-199
D03318		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0610/270/R070	275-278
D03318		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0610/270/R073	280-299
D03320		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0639/270/R070	050-099, 150-199
D03320		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0639/270/R070	275-278
D03320		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0630/270/R074	280-299
D03322		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0669/270/R070	050-099
D03322		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0656/270/R070	275-278
D03322		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0665/270/R074	280-299
D03324		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0698/270/R070	050-099

EQUIPMENT LIST

D280T132

Section D03300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03324		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 700/270/R070	150-199
D03324		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0682/270/R070	275-278
D03324		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0683/270/R073	280-299
D03326		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0727/270/R070	050-099
D03326		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 737/270/R070	150-199
D03326		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0712/270/R070	275-278
D03326		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0713/270/R073	280-299
D03328		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0757/270/R070	050-099
D03328		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0742/270/R070	275-278
D03328		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0741/270/R073	280-299
D03330		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0786/270/R070	050-099
D03330		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0801/270/R070	150-199
D03330		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0797/270/R070	275-278
D03330		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0797/270/R073	280-299
D03332		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 831/270/R070	150-199
D03336		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0875/270/R073	050-099
D03336		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0859/270/R073	150-199

EQUIPMENT LIST

D280T132

Section D03300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03336		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0879/270/R073	275-299
D03338		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0893/270/R073	050-099
D03338		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0889/270/R073	150-199
D03338		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0893/270/R073	275-299
D03340		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0926/270/R073	050-099
D03340		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0919/270/R073	150-199
D03340		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0926/270/R073	275-299
D03342		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0940/270/R073	050-099
D03342		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0955/270/R073	275-299
D03344		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0970/270/R073	050-099
D03344		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1007/270/R073	150-199
D03344		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0983/270/R073	275-299
D03346		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0999/270/R073	050-099
D03346		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1028/270/R073	150-199
D03346		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1013/270/R073	275-299
D03348		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1055/270/L073	150-199
D03348		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1043/270/L073	275-299

EQUIPMENT LIST

D280T132

Section D03300

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03350		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1071/270/L073	150-199
D03350		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1071/270/L073	275-299
D03352		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1097/270/L073	050-099
D03352		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1101/270/L073	150-199
D03352		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1101/270/L073	275-299
D03354		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1116/270/L073	050-099
D03354		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1131/270/L073	150-199
D03354		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1131/270/L073	275-299
D03356		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1146/270/L073	050-099
D03356		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1159/270/L073	150-199
D03356		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1159/270/L073	275-299
D03358		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1175/270/L073	050-099
D03358		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1189/270/L073	150-199
D03358		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1189/270/L073	275-299
D03360		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1204/270/L073	050-099, 150-199
D03360		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1204/270/L073	275-299
D03362		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1234/270/L073	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D03300

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03362		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1234/270/L073	275-299
D03364		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1273/270/L073	050-099
D03364		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1263/270/L073	150-199
D03364		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1263/270/L073	275-299
D03366		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1292/270/L073	050-099, 150-199
D03366		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1292/270/L073	275-299
D03368		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1322/270/L073	050-099, 150-199
D03368		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1322/270/L073	275-299
D03370		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1351/270/L073	050-099, 150-199
D03370		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1351/270/L073	275-299
D03372		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1380/270/L073	050-099
D03372		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1387/270/L073	150-199
D03372		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1380/270/L073	275-299
D03374		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1410/270/L073	050-099
D03374		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1406/270/L073	150-199
D03374		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1410/270/L073	275-299
D03376		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1428/270/L073	050-099

EQUIPMENT LIST

D280T132

Section D03300

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03376		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1436/270/L073	150-199
D03376		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1427/270/L073	275-299
D03378		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1133/280/L005	050-099, 150-199
D03378		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1133/280/L005	275-299
D03380		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1157/280/L005	050-099, 150-199
D03380		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1157/280/L005	275-299
D03382		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1171/280/L005	050-099
D03382		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1181/280/L005	150-199
D03382		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1181/280/L005	275-299
D03384		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1212/280/L005	050-099
D03384		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1197+015/280/L005	150-199
D03384		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1197+015/280/L005	275-299
D03386		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1238/280/L005	050-099
D03386		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1197+041/280/L005	150-199
D03386		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1197+041/280/L005	275-299
D03388		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1265/280/L005	050-099
D03388		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1197+068/280/L005	150-199

EQUIPMENT LIST

D280T132

Section D03300

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03388		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1197+068/280/L005	275-299
D03390		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1289/280/L005	050-099, 150-199
D03390		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1289/280/L005	275-299
D03392		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1313/280/L005	050-099, 150-199
D03392		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1313/280/L005	275-299
D03394		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1344/280/L005	050-099, 150-199
D03394		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1344/280/L005	275-299
D03396		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1370/280/L005	050-099, 150-199
D03396		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1370/280/L005	275-299
D03398		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1397/280/L005	050-099, 150-199
D03398		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1397/280/L005	275-299

EQUIPMENT LIST

D280T132

Section D03300

Page 8 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03400		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1421/280/L005	050-099, 150-199
D03400		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 1421/280/L005	275-299
D03402		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1454/280/L005	050-099
D03402		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1449/280/L005	150-199
D03402		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 1450/280/L005	275-299
D03404		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1489/280/L005	050-099
D03404		BACC45FN10-5S6 RCPT-	81205	1	33-24-13 1465/280/L005	275-299
D03412		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1055/270/R073	150-199
D03412		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1043/270/R073	275-299
D03414		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1071/270/R073	150-199
D03414		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1071/270/R073	275-299
D03416		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1097/270/R073	050-099
D03416		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1101/270/R073	150-199
D03416		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1101/270/R073	275-299
D03418		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1116/270/R073	050-099
D03418		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1131/270/R073	150-199
D03418		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1131/270/R073	275-299

EQUIPMENT LIST

D280T132

Section D03400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03420		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1146/270/R073	050-099
D03420		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1159/270/R073	150-199
D03420		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1159/270/R073	275-299
D03422		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1175/270/R073	050-099
D03422		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1189/270/R073	150-199
D03422		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1189/270/R073	275-299
D03424		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1204/270/R073	050-099, 150-199
D03424		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1204/270/R073	275-299
D03426		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1234/270/R073	050-099, 150-199
D03426		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1234/270/R073	275-299
D03428		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1273/270/R073	050-099
D03428		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1263/270/R073	150-199
D03428		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1263/270/R073	275-299
D03430		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1292/270/R073	050-099, 150-199
D03430		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1292/270/R073	275-299
D03432		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1322/270/R073	050-099, 150-199
D03432		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1322/270/R073	275-299

EQUIPMENT LIST

D280T132

Section D03400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03434		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1351/270/R073	050-099, 150-199
D03434		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1351/270/R073	275-299
D03436		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1380/270/R073	050-099
D03436		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1387/270/R073	150-199
D03436		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1380/270/R073	275-299
D03438		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1410/270/R073	050-099
D03438		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1406/270/R073	150-199
D03438		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1410/270/R073	275-299
D03440		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1428/270/R073	050-099
D03440		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1436/270/R073	150-199
D03440		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1427/270/R073	275-299
D03446		BACC45FT12A12S PLUG-	81205	1	38-14-11 1569/186/R031	050-099
D03446		BACC45FT12A12S PLUG-	81205	1	38-14-11 1570/186/R031	150-199, 275-299
D03448		BACC45FT16A24S6 PLUG-P31	81205	1	29-11-22 P031-00/ /	ALL
D03450		BACC45FT16B24S6 PLUG-P31	81205	1	29-11-31 P031-00/ /	ALL
D03452		BACC45FT16B24S6 PLUG-P32	81205	1	29-11-12 P032-00/ /	ALL
D03454		BACC45FT16B24S6 PLUG-P32	81205	1	29-11-31 P032-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D03400

Page 3

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03466		BACC63BP14R7SNL RCPT-	81205	1	33-44-21 R1140/12/TIP	ALL
D03466 T		BACC10KD14 CLAMP-	81205	1	33-44-21 / /	ALL
D03474		BACS16X1A RELAY SOCKET-	81205	1	36-11-11 P036-00/ /	ALL
D03476		BACS16X1A RELAY SOCKET-	81205	1	36-11-11 P036-00/ /	ALL
D03478		BACS16X1A RELAY SOCKET-	81205	1	36-11-31 P036-00/ /	ALL
D03480		BACS16X1A RELAY SOCKET-	81205	1	36-11-31 P036-00/ /	ALL
D03482		BACS16X1A RELAY SOCKET	81205	1	21-53-11 P036-00/ /	ALL
D03484		BACS16X1A RELAY SOCKET	81205	1	21-53-11 P036-00/ /	ALL
D03486		BACS16X1A RELAY SOCKET	81205	1	21-53-11 P036-00/ /	ALL
D03488		BACS16X1A RELAY SOCKET	81205	1	21-53-11 P036-00/ /	ALL
D03490		BACS16X1A RELAY SOCKET	81205	1	21-53-11 P036-00/ /	ALL
D03492		BACS16W1A RELAY SOCKET-	81205	1	78-34-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D03400

Page 4 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03500		BACS16X1A RELAY SOCKET-	81205	1	28-21-13 P036-00/ /	ALL
D03502		BACS16X1A RELAY SOCKET-	81205	1	28-21-13 P036-00/ /	ALL
D03504		BACS16W1 RELAY SOCKET-	81205	1	21-53-11 P036-00/ /	ALL
D03506		BACS16W1 RELAY SOCKET	81205	1	21-53-11 P036-00/ /	ALL
D03510		BACS16W1 RELAY SOCKET-	81205	1	32-09-13 P033-00/ /	ALL
D03512		BACS16W1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D03514		BACS16AF1 RELAY SOCKET	81205	1	32-09-11 P036-00/ /	ALL
D03516		BACS16AF1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D03524		BACS16X1A RELAY SOCKET-	81205	1	29-11-32 P036-00/ /	ALL
D03526		BACS16W1 RELAY SOCKET-	81205	1	80-11-11 P036-00/ /	ALL
D03528		BACS16X1A RELAY SOCKET-	81205	1	78-34-11 P036-00/ /	ALL
D03530		BACS16W1 PLUG-	81205	1	76-11-11 P036-00/ /	ALL
D03532		BACS16AF1 RELAY SOCKET	81205	1	32-09-11 P036-00/ /	ALL
D03534		BACS16AF1 RELAY SOCKET	81205	1	32-09-11 P036-00/ /	ALL
D03536		BACS16W1 RELAY SOCKET	81205	1	32-09-11 P036-00/ /	ALL
D03538		BACS16W1 RELAY SOCKET-	81205	1	28-21-11 P036-00/ /	ALL
D03540		BACS16X1A RELAY SOCKET-	81205	1	28-21-12 P036-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D03500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03540		BACS16X1A RELAY SOCKET-	81205	1	28-21-13 P036-00/ /	150-199, 275-299
D03542		BACS16X1A RELAY SOCKET-	81205	1	28-21-13 P036-00/ /	ALL
D03544		BACS16X1A RELAY SOCKET-	81205	1	28-21-13 P036-00/ /	ALL
D03546		BACS16X1A RELAY SOCKET	81205	1	21-53-11 P036-00/ /	ALL
D03548		BACS16W5 RELAY SOCKET-	81205	1	28-21-13 P036-00/ /	050-099
D03548		BACS16W5 RELAY SOCKET-	81205	1	28-21-12 P036-00/ /	150-199, 275-299
D03554		BACS16AF1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D03556		BACS16X2A RELAY SOCKET-P19	81205	1	33-21-21 P019-00/ /	050-099
D03556		BACS16X2A RELAY SOCKET-	81205	1	33-21-21 P019-00/ /	150-199, 275-299
D03558		BACS16W3 RELAY SOCKET-P19	81205	1	33-22-41 P019-00/ /	050-099
D03558		BACS16W3 RELAY SOCKET-	81205	1	33-22-41 P019-00/ /	150-199, 275-299
D03560		BACS16W1 RELAY SOCKET-P19	81205	1	33-24-11 P019-00/ /	050-099
D03560		BACS16W1 RELAY SOCKET-	81205	1	33-24-11 P019-00/ /	150-199, 275-299
D03562		BACS16X1A RELAY SOCKET-	81205	1	28-21-13 P036-00/ /	ALL
D03566		BACS16X1A RELAY SOCKET-	81205	1	21-44-11 P036-00/ /	ALL
D03568		BACS16X1A RELAY SOCKET-	81205	1	21-43-11 P036-00/ /	ALL
D03572		BACS16X1A RELAY SOCKET-P19	81205	1	33-51-21 P019-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D03500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03572		BACS16X1A RELAY SOCKET-	81205	1	33-51-21 P019-00/ /	150-199, 275-299
D03574		BACS16X1A RELAY SOCKET-P19	81205	1	33-51-21 P019-00/ /	050-099
D03574		BACS16X1A RELAY SOCKET-	81205	1	33-51-21 P019-00/ /	150-199, 275-299
D03578		BACS16X1A RELAY SOCKET-	81205	1	21-58-12 P036-00/ /	ALL
D03586		BACS16W1A RELAY SOCKET-	81205	1	21-58-13 P036-00/ /	ALL
D03594		BACS16W1 RELAY SOCKET-	81205	1	28-21-11 P036-00/ /	ALL
D03596		BACS16W1 RELAY SOCKET-	81205	1	21-58-16 P036-00/ /	ALL
D03598		BACC63BP10A5SNL PLUG-ALT PRESS. SW	81205	1	38-32-11 1629/171/R047	ALL
D03598 T		BACC10KD10 CLAMP-	81205	1	38-32-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D03500
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03602		10-60450-5 RELAY SOCKET-P19	81205	1	52-11-11 P019-00/ /	050-099
D03602		10-60450-5 RELAY SOCKET-	81205	1	52-11-11 P019-00/ /	150-199, 275-299
D03604		BACS16W1 RELAY SOCKET-P19	81205	1	52-11-11 P019-00/ /	050-099
D03604		BACS16W1 RELAY SOCKET-	81205	1	52-11-11 P019-00/ /	150-199, 275-299
D03606		BACS16W1 RELAY SOCKET-P19	81205	1	52-11-11 P019-00/ /	050-099
D03606		BACS16W1 RELAY SOCKET-	81205	1	52-11-11 P019-00/ /	150-199, 275-299
D03608		BACS16X3A RELAY SOCKET-	81205	1	33-21-21 P025-00/ /	ALL
D03610		BACS16AF1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D03612		BACS16AF1 RELAY SOCKET	81205	1	32-09-11 P036-00/ /	ALL
D03614		BACS16AF1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D03620		BACS16AF1 RELAY SOCKET-	81205	1	32-44-11 P036-00/ /	ALL
D03622		BACS16X1A RELAY SOCKET-	81205	1	76-11-21 P036-00/ /	ALL
D03626		BACS16X1A RELAY SOCKET-	81205	1	29-11-32 P036-00/ /	ALL
D03640		BACC45FT14A7S PLUG-	81205	1	33-21-21 P025-00/ /	ALL
D03642		BACC45FT14A7S PLUG-	81205	1	33-22-11 P025-00/ /	ALL
D03648		BACS16W1 RELAY SOCKET-P49	81205	1	36-11-41 P049-00/ /	ALL
D03650		BACS16W1 RELAY SOCKET-P49	81205	1	36-11-41 P049-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D03600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03652		BACS16AF1 RELAY SOCKET-P49	81205	1	36-11-41 P049-00/ /	ALL
D03654		BACS16X1A RELAY SOCKET-P33	81205	1	21-53-21 P033-00/ /	ALL
D03656		BACS16X1A RELAY SOCKET-P33	81205	1	21-53-21 P033-00/ /	ALL
D03658		BACS16X1A REALY SOCKET-P33	81205	1	21-53-21 P033-00/ /	ALL
D03660		BACS16X1A RELAY SOCKET-P33	81205	1	21-53-21 P033-00/ /	ALL
D03662		BACS16X1A RELAY SOCKET-P33	81205	1	21-53-21 P033-00/ /	ALL
D03664		BACS16X1A RELAY SOCKET-P33	81205	1	21-53-21 P033-00/ /	ALL
D03666		BACS16X1A RELAY SOCKET-	81205	1	36-11-21 P037-00/ /	ALL
D03668		BACS16X1A RELAY SOCKET-	81205	1	36-11-21 P037-00/ /	ALL
D03670		BACS16W1A RELAY SOCKET-	81205	1	78-34-21 P037-00/ /	ALL
D03674		BACS16W1 RELAY SOCKET-P33	81205	1	21-53-21 P033-00/ /	ALL
D03676		BACS16W1 RELAY SOCKET-P33	81205	1	21-53-21 P033-00/ /	ALL
D03678		BACS16W1 RELAY SOCKET-	81205	1	21-61-11 P037-00/ /	ALL
D03680		BACS16X1A RELAY SOCKET-	81205	1	21-43-11 P037-00/ /	ALL
D03684		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03686		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03688		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D03600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03690		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03691J		BACC45FN16-24P8 RCPT-E1-3	81205	1	34-12-61 AE0319/ /	ALL
D03691P	9	BACC45FT16A24S8 PLUG-E1-3	81205	1	34-12-61 AE0319/ /	ALL
D03692		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03693J		BACC45FN16-24P8 RCPT-E2-3	81205	1	34-12-62 AE0322/ /	ALL
D03693P		BACC45FT16A24S8 PLUG-E2-3	81205	1	34-12-62 AE0322/ /	ALL
D03694		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03695	9	BACC63BP10A5SN PLUG	81205	1	27-89-11 1080/OB/L	050-099, 151
D03695 T	9	BACC10KD10 CLAMP-	81205	1	27-89-11 / /	050-099, 151
D03696		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03697	9	BACC63BP10A5SN PLUG	81205	1	27-89-11 1080/OB/R	050-099, 151
D03697 T	9	BACC10KD10 CLAMP-	81205	1	27-89-11 / /	050-099, 151
D03698		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D03600

Page 3 End

May 20/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03700		BACS16AF1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03702		BACS16W1 RELAY SOCKET-	81205	1	80-11-21 P037-00/ /	ALL
D03704		BACS16X1A RELAY SOCKET-	81205	1	78-34-21 P037-00/ /	ALL
D03708		BACS16W1 RELAY SOCKET-	81205	1	49-61-11 P037-00/ /	ALL
D03712		BACS16W1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03714		BACS16W1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03716		BACS16W1 RELAY SOCKET-	81205	1	21-61-21 P037-00/ /	ALL
D03722		BACC45FT12D12S PLUG-	81205	1	33-13-13 0150/210/R032	ALL
D03726		10-60450-5 RELAY SOCKET-	81205	1	28-25-11 P037-00/ /	ALL
D03728		BACS16W1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D03730		BACS16W1 RELAY SOCKET-	81205	1	32-09-11 P037-00/ /	ALL
D03732		BACC45FT12A12S PLUG-	81205	1	33-13-17 P002-00/ /	ALL
D03734		BACC45FT12A12S PLUG-	81205	1	33-13-18 0189/199/L050	ALL
D03736		BACC45FT12A12S PLUG-	81205	1	33-13-18 P008-00/ /	ALL
D03738		BACC65L41 RCPT-	81205	1	21-53-22 P050-00/ /	ALL
D03738 U		BACC47EM1 KEYING PLUG-	81205	2	21-53-22 / /	ALL
D03742		BACC65L41 RCPT-	81205	1	21-25-11 P050-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D03700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03742	U	BACC47EM1 KEYING PLUG-	81205	2	21-25-11 / /	ALL
D03744		BACS16AG1 RELAY SOCKET-	81205	1	49-61-11 P037-00/ /	ALL
D03748		BACS16X3A RELAY SOCKET	81205	1	30-71-24 P037-00/ /	050-099, 150-199
D03750		BACS16W1 RELAY SOCKET-	81205	1	49-61-11 P037-00/ /	ALL
D03752		BACS16X1A RELAY SOCKET-	81205	1	76-11-21 P037-00/ /	ALL
D03754		BACS16W1 RELAY SOCKET-	81205	1	21-61-31 P037-00/ /	ALL
D03756		BACC45FT12A12S PLUG-	81205	1	33-13-18 0189/205/L045	ALL
D03762		BACC45FT12A12S PLUG-	81205	1	21-45-11 0162/230/R048	ALL
D03768		BACC45FT12A12S PLUG-	81205	1	33-11-13 0155/222/R008	ALL
D03772		BACS16AG1 RELAY SOCKET-	81205	1	28-25-21 P037-00/ /	ALL
D03780		BACC45FT12A12S PLUG-	81205	1	21-45-11 0162/230/L032	ALL
D03788		BACS16X1A RELAY SOCKET-	81205	1	21-58-21 P037-00/ /	ALL
D03792		BACC63BD14S-6S RELAY SOCKET-	81205	1	26-15-12 0280/175/R028	ALL

EQUIPMENT LIST

D280T132

Section D03700

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03812		BACC45FN8-2S RCPT-	81205	1	35-21-13 1473/285/R050	150-199, 275-299
D03814		BACC45FN8-2S RCPT-	81205	1	35-21-13 1510/280/R030	ALL
D03818		BACC45FT18A8S PLUG-	81205	1	38-32-11 1551/181/L035	ALL
D03824		BACC45FT10-5S PLUG-	81205	1	21-61-21 0661/302/L012	050-099
D03824		BACC45FT10-5S PLUG-	81205	1	21-61-21 0654+007/302/L012	150-199
D03824		BACC45FT10-5S PLUG-	81205	1	21-61-21 0654+008/300/L013	275-278
D03824		BACC45FT10-5S PLUG-	81205	1	21-61-21 0654+007/302/L014	280-299
D03826		BACC45FT10-5S PLUG-	81205	1	21-61-31 0770/305/L017	ALL
D03828		C48-06R10-20S PLUG-	13556	1	21-61-11 0261/185/L070	ALL
D03830		BACC45FT10-5S PLUG-	81205	1	21-61-11 0190/268/L019	ALL
D03832		BACC45FN8-2S RCPT-	81205	1	35-21-14 1489/280/L005	050-099
D03832		BACC45FN8-2S RCPT-	81205	1	35-21-14 1465/280/L005	275-299
D03834		BACC45FN8-2S RCPT-	81205	1	35-21-12 1473/285/L050	050-099
D03834		BACC45FN8-2S RCPT-	81205	1	35-21-12 1473/280/L050	150-199, 275-299
D03838		BACC45FT10-5S PLUG-	81205	1	21-61-11 0259/185/L070	ALL
D03842		BACC45FT18A31S6 PLUG-P5	81205	1	21-43-11 P005-00/ /	ALL
D03846		BACC45FT12A12S7 PLUG-P61	81205	1	21-44-21 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D03800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03892		BACC45FT12A12S PLUG-P5	81205	1	36-21-11 P005-00/ /	ALL
D03896		BACC45FT14A15S9 PLUG-P5	81205	1	28-43-11 P005-00/ /	ALL
D03898		BACC45FT20A39S6 PLUG-P5	81205	1	28-41-11 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D03800
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03900		BACC45FT20A39S PLUG-P5	81205	1	28-41-11 P005-00/ /	ALL
D03902		BACC45FT12A12S8 PLUG-P5	81205	1	29-11-12 P005-00/ /	ALL
D03904		BACC45FT12A12S9 PLUG-P5	81205	1	29-11-11 P005-00/ /	ALL
D03906		BACS16AG1 RELAY SOCKET-	81205	1	27-58-11 P033-00/ /	ALL
D03908		BACS16X1A RELAY SOCKET-P33	81205	1	27-51-11 P033-00/ /	ALL
D03910		000300-1560 RELAY SOCKET-P33	05574	1	30-31-21 P033-00/ /	ALL
D03916		000300-1560 RELAY SOCKET-	05574	1	30-32-11 P033-00/ /	ALL
D03924		000300-1560 RELAY SOCKET-	05574	1	30-34-11 P033-00/ /	ALL
D03938		000300-1560 RELAY SOCKET-P33	05574	1	30-31-21 P033-00/ /	ALL
D03942		000300-1560 RELAY SOCKET-	05574	1	30-33-11 P033-00/ /	ALL
D03946		000300-1560 RELAY SOCKET-	05574	1	30-34-21 P033-00/ /	ALL
D03948		000300-1560 RELAY SOCKET-	05574	1	30-31-11 P033-00/ /	ALL
D03952		000300-1560 RELAY SOCKET-	05574	1	30-31-13 P033-00/ /	ALL
D03964		BACS16W3 RELAY SOCKET-P33	81205	1	30-71-21 P033-00/ /	ALL
D03966		BACS16X3A RELAY SOCKET-P33	81205	1	30-71-21 P033-00/ /	ALL
D03968		BACS16W3 RELAY SOCKET-P33	81205	1	30-71-21 P033-00/ /	050-099
D03968		BACS16W3A RELAY SOCKET-P33	81205	1	30-71-22 P033-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D03900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03972		BACS16W3 RELAY SOCKET-P33	81205	1	30-71-21 P033-00/ /	ALL
D03980		BACS16AG1 RELAY SOCKET	81205	1	27-62-11 P033-00/ /	ALL
D03982		C48-06R10-20S-102- PLUG-	13556	1	21-61-31 0770/302/L017	050-099
D03982		C48-06R10-20S-102- PLUG-	13556	1	21-61-31 0770/305/L017	150-199, 275-299
D03984		C48-06R10-20S PLUG-	13556	1	21-61-21 0661/300/L015	050-099
D03984		C48-06R10-20S PLUG-	13556	1	21-61-21 654+8/303/L013	150-199, 275-278
D03984		C48-06R10-20S PLUG-	13556	1	21-61-21 654+7/302/L012	280-299
D03986		BACC63BP14A7SNL PLUG-	81205	1	28-22-11 R0280/ /	ALL
D03986 T		BACC10KD14 CLAMP-	81205	1	28-22-11 / /	ALL
D03988		BACC63BP12R12SNL PLUG-	81205	1	21-64-11 0823/113/L015	ALL
D03988 T		BACC10KE12 CLAMP-	81205	1	21-61-11 / /	050-099, 153-199, 275-299
D03988 T		BACC10KD12 CLAMP-	81205	1	21-61-11 / /	150-152
D03990		BACC63BP12R12SNL PLUG-	81205	1	21-64-11 0834/129/L015	050-099
D03990		BACC63BP12R12SNL PLUG-	81205	1	21-64-11 0827/129/L015	150-199, 275-299
D03990 T		BACC10KD12 CLAMP-	81205	1	21-61-21 / /	ALL
D03992		BACC63BP12R12SNL PLUG-	81205	1	21-64-11 0834/118/L015	050-099
D03992		BACC63BP12R12SNL PLUG-	81205	1	21-64-11 0827/118/L015	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D03900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D03992	T	BACC10KD12 CLAMP-	81205	1	21-61-31 / /	ALL
D03994		BACC63BW12S-3S PLUG-	81205	1	21-65-11 0770/305/L018	ALL
D03996		BACC63BW12S-3S PLUG-	81205	1	21-65-11 MULTI/283/0000	ALL
D03998		BACC63CE12S-3S PLUG-	81205	1	21-65-11 MULTI/268/0000	050-099, 280-299
D03998		BACC63CE12S-3S PLUG-	81205	1	21-65-11 MULTI/281/0000	150-199, 275-278

EQUIPMENT LIST

D280T132

Section D03900
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04001J		KD-19-105-M06 RCPT-E2-6 COAX,HF L	91836	1	23-11-11 AE0322/ /	ALL
D04001P		KD-59-164 PLUG-COAX-E2-6	91836	1	23-11-11 AE0322/ /	ALL
D04002J		BACC45FN16-24P7 RCPT-P54	81205	1	26-17-11 AE0226/ /	ALL
D04002P		BACC45FT16-24S7 PLUG-P54	81205	1	26-17-11 AE0226/ /	ALL
D04003J		KD-19-105-M06 RCPT-COAX,HF L	91836	1	23-11-11 AP1501/ /	050-099, 150-154, 162-164, 275-276
D04003J		KD-19-66 RCPT-COAX,HF L	91836	1	23-11-11 AP1501/ /	155-157, 165-199, 277-299
D04003P		KD-59-186-M06 PLUG-COAX,HF L	91836	1	23-11-11 AP1501/ /	ALL
D04004J		BACC45FN18-31S8 RCPT-P37	81205	1	21-51-21 AE0218/ /	ALL
D04004P		BACC45FT18-31P8 PLUG-P37	81205	1	21-51-21 AE0218/ /	ALL
D04005J		KN-19-198-M06 RCPT-E2-6 COAX,HF R	91836	1	23-11-21 AE0322/ /	ALL
D04005P		KN-59-220 PLUG-E2-6 COAX	91836	1	23-11-21 AE0322/ /	ALL
D04006J		BACC45FN22-32S7 RCPT-P6	81205	1	24-11-11 AF0232/ /	ALL
D04006P		BACC45FT22-32P7 PLUG-P6	81205	1	24-11-11 AF0232/ /	ALL
D04007J		KN-19-198-M06 RCPT-COAX,HF R	91836	1	23-11-21 AP1501/ /	ALL
D04007P		KN-59-330-M06 PLUG-COAX,HF R	91836	1	23-11-21 AP1501/ /	050-099, 150-154, 162-164, 275-276
D04007P		KN-59-220 PLUG-COAX,HF R	91836	1	23-11-21 AP1501/ /	155-157, 165-199, 277-299
D04008J		BACC45FN22-32S8 RCPT-P6	81205	1	22-23-11 AF0232/ /	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04008P		BACC45FT22-32P8 PLUG-P6	81205	1	24-34-11 AF0232/ /	ALL
D04009J		KN-19-198-M06 RCPT-E2-5 COAX,VHF L	91836	1	23-12-11 AE0322/ /	ALL
D04009P		KN-59-331-M06 PLUG-COAX-E2-5,VHF-L	91836	1	23-12-11 AE0322/ /	ALL
D04010J		BACC45FN22-32S RCPT-P6	81205	1	22-23-31 AF0232/ /	ALL
D04010P		BACC45FT22-32P PLUG-P6	81205	1	28-21-13 AF0232/ /	ALL
D04011J		KN-19-198-M06 RCPT-COAX,VHF L	91836	1	23-12-11 0667/319/0000	050-099
D04011J		KN-19-198-M06 RCPT-COAX,VHF L	91836	1	23-12-11 0654+33/319/0000	150-199, 275-299
D04011P		KN-59-330-M06 PLUG-COAX,VHF L	91836	1	23-12-11 0667/319/0000	050-099
D04011P		KN-59-330-M06 PLUG-COAX,VHF L	91836	1	23-12-11 0654+33/319/0000	150-199, 275-299
D04012J		BACC45FN22-55P8 RCPT-P32	81205	1	25-31-11 AE0312/ /	ALL
D04012P		BACC45FT22A55S8 PLUG-P32	81205	1	25-31-11 AE0312/ /	ALL
D04013J		KA-19-195-M06 RCPT-E2-5 COAX,VHF R	91836	1	23-12-21 AE0322/ /	ALL
D04013P		KA-59-392-M06 PLUG-E2-5 COAX,VHF-R	91836	1	23-12-21 AE0322/ /	ALL
D04016P		FRF6-36-5S01-747 PLUG-APU FIREWALL	71468	1	24-21-41 AV1801/ /	050-099, 150-155, 162-199, 275-278
D04016PQ		G63292 CLAMP-	06324	1	24-21-41 / /	050-099, 150-155, 162-199, 275-278
D04017J		KD-19-105-M06 RCPT-COAX,VHF-C	91836	1	23-12-31 AE0322/ /	ALL
D04017P		KD-59-185-M06 PLUG-COAX,E2-5,VHF-C	91836	1	23-12-31 AE0322/ /	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 2

Aug 15/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04018J		BACC63BT24-30S8 RCPT-APU FWD	81205	1	24-21-41 AV1801/ /	ALL
D04018JK		BACC10KA24 CLAMP-	81205	1	24-21-41 / /	ALL
D04018P		BACC63BR24-30P8L PLUG-APU FIREWALL	81205	1	24-21-41 AV1801/ /	ALL
D04018PQ		BACC10KA24 CLAMP-	81205	1	24-21-41 / /	ALL
D04019J		KN-19-198-M06 RCPT-COAX,VHF-C	91836	1	23-12-31 1317/131/L067	050-099
D04019J		KN-19-198-M06 RCPT-COAX,VHF-C	91836	1	23-12-31 1197+98/131/L067	150-199, 275-299
D04019P		KN-59-330-M06 PLUG-COAX,VHF-C	91836	1	23-12-31 1317/131/L067	050-099
D04019P		KN-59-330-M06 PLUG-COAX,VHF-C	91836	1	23-12-31 1197+98/131/L067	150-199, 275-299
D04020J		BACC63BT16-10SN RCPT-APU FIREWALL DISC	81205	1	26-15-11 AV1801/ /	ALL
D04020JK		BACC10KA16 CLAMP-	81205	1	26-15-11 / /	ALL
D04020P		BACC63BR16-10PNL PLUG-APU FIREWALL	81205	1	26-15-11 AV1801/ /	ALL
D04020PQ		BACC10KA16 CLAMP-	81205	1	26-15-11 / /	ALL
D04022J		BACC63BT14-7S7 RCPT-	81205	1	23-41-11 AV1801/ /	ALL
D04022JK		BACC10KA14 CLAMP-	81205	1	23-41-11 / /	ALL
D04022P		BACC63BR14-7P7L PLUG-APU FIREWALL	81205	1	23-41-11 AV1801/ /	ALL
D04022PQ		BACC10KA14 CLAMP-	81205	1	23-41-11 / /	ALL
D04024J		BACC63BT24-30S RCPT-APU FWD	81205	1	49-14-11 AV1801/ /	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 3

Aug 15/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04024JK		BACC10KA24 CLAMP-	81205	1	49-14-11 / /	ALL
D04024P		BACC63BR24-30PNL PLUG-APU FWD	351T0300 81205	1	49-27-11 AV1801/ /	150-199, 275-299
D04026J		BACC45FN16-10S RCPT-P34	81205	1	24-51-61 AE0204/ /	ALL
D04026P		BACC45FT16-10P PLUG-P34	81205	1	24-21-41 AE0204/ /	ALL
D04028J		BACC45FN22-55S RCPT-P34	81205	1	24-23-12 AE0204/ /	ALL
D04028P		BACC45FT22-55P PLUG-P34	81205	1	24-22-41 AE0204/ /	ALL
D04030J		BACC63CN2842S RCPT-APU FWD	81205	1	49-14-11 AV1801/ /	ALL
D04030JK		BACC10KA28 CLAMP-	81205	1	49-14-11 / /	ALL
D04034J		BACC45FN22A55S9 RCPT-E2-4	81205	1	24-11-21 AE0320/ /	ALL
D04034P		BACC45FT22A55P9 PLUG-	81205	1	24-11-21 AE0320/ /	ALL
D04036J		BACC45FN22-19S6 RCPT-E2-4	81205	1	24-21-21 AE0320/ /	ALL
D04036P		BACC45FT22A19P6 PLUG-	81205	1	24-11-21 AE0320/ /	ALL
D04038J		BACC45FN16-24S6 RCPT-P32	81205	1	24-23-12 AE0312/ /	ALL
D04038P		BACC45FT16-24P6 PLUG-P32	81205	1	24-23-12 AE0312/ /	ALL
D04039J		KA-19-216-M06 RCPT-COAX,L ILS G/S FWD PRESS BLKHD	91836	1	34-31-11 132/189/L 8	ALL
D04039P		KA-59-438-M06 RCPT- COAX,D G/S,ILS LFWD PRESS BLKHD	91836	1	34-31-11 132/189/L 8	ALL
D04040J		BACC45FN22-55S6 RCPT-E6	81205	1	24-21-41 AC1402/ /	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 4

Aug 15/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04040P		BACC45FT22-55P6 PLUG-E6	81205	1	24-34-11 AC1402/ /	ALL
D04042J		BACC45FN16-24P6 RCPT-P33	81205	1	24-31-11 AE0203/ /	ALL
D04042P		BACC45FT16-24S6 PLUG-P33	81205	1	24-31-11 AE0203/ /	ALL
D04043J	1	KC-19-129 RCPT-FWD PRESS BLKHDL ILS LOC	91836	1	34-31-11 132/189/L 8	ALL
D04043J	2	KC-19-256 RCPT-FWD PRESS BLKHDL ILS LOC	91836	1	34-31-11 132/189/L 8	ALL
D04043J	3	KC-19-31 RCPT-FWD PRESS BLKHDL ILS LOC	91836	1	34-31-11 132/189/L 8	ALL
D04043P		KC-59-259 PLUG-COAX,L ILS LOC,FWD PRESS BLKHD	91836	1	34-31-11 132/189/L 8	ALL
D04044J		BACC45FN20-16P7 RCPT-E6	81205	1	24-21-41 AC1402/ /	ALL
D04044P		BACC45FT20-16S7 PLUG-E6	81205	1	24-21-41 AC1402/ /	ALL
D04045J		KC-19-256 RCPT-COAX,E1-3,L ILS LOC	91836	1	34-31-11 SHELF/E01/03	ALL
D04045P		KC-59-259 PLUG-E1-3L ILS LOC COAX	91836	1	34-31-11 SHELF/E01/03	ALL
D04046J		BACC45FN18-31P7 RCPT-E6	81205	1	24-22-41 AC1402/ /	ALL
D04046P		BACC45FT18-31S7 PLUG-E6	81205	1	24-34-11 AC1402/ /	ALL
D04047J		KA-19-143 RCPT-COAX,E1-3 ,L ILS G/S	91836	1	34-31-11 SHELF/E01/03	ALL
D04047P		KA-59-438-M06 PLUG-COAX,L ILS G/S,E1-3	91836	1	34-31-11 SHELF/E01/03	ALL
D04048J		BACC45FN22-55S6 RCPT-E2-4	81205	1	24-22-41 AE0307/ /	ALL
D04048P		BACC45FT22A55P6 PLUG-E2-4	81205	1	24-22-41 AE0307/ /	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 5

Aug 15/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04049J		KC-19-256 RCPT-COAX,E1-5 COAX,R ILS LOC	91836	1	34-31-21 SHELF/E01/05	ALL
D04049P		KC-59-259 PLUG-COAX,E1-5,R ILS LOC	91836	1	34-31-21 SHELF/E01/05	ALL
D04051J		KA-19-143 RCPT-COAX,E1-5 R,ILS G/S	91836	1	34-31-21 SHELF/E01/05	ALL
D04051P		KA-59-438-M06 PLUG-COAX,E1-5,R ILS G/S	91836	1	34-31-21 SHELF/E01/05	ALL
D04052J		BACC45FN12-12S8 RCPT-P31	81205	1	24-23-12 AE0311/ /	ALL
D04052P		BACC45FT12-12P8 PLUG-P31	81205	1	24-23-12 AE0311/ /	ALL
D04053J		KA-19-216-M06 RCPT-COAX,FWD PRESS BLKHD,R ILS G/S	91836	1	34-31-21 132/201/L 8	ALL
D04053P		KA-59-438-M06 PLUG-COAX,FWD PRESS BLKHD,R ILS G/S	91836	1	34-31-21 132/201/L 8	ALL
D04054J		BACC45FN22-55P RCPT-P31	81205	1	24-22-11 AE0311/ /	ALL
D04054P		BACC45FT22-55S PLUG-P31	81205	1	24-22-11 AE0311/ /	ALL
D04055J	1	KC-19-129 RCPT-COAX,FWD PRESS BLKHD,R ILS LOC	91836	1	34-31-21 132/201/L 8	ALL
D04055J	2	KC-19-256 RCPT-COAX,FWD PRESS BLKHD,R ILS LOC	91836	1	34-31-21 132/201/L 8	ALL
D04055J	3	KC-19-31 RCPT-COAX,FWD PRESS BLKHD,R ILS LOC	91836	1	34-31-21 132/201/L 8	ALL
D04055P		KC-59-259 PLUG-COAX,FWD PRESS BLKHD,R ILS LOC	91836	1	34-31-21 132/201/L 8	ALL
D04056J		BACC45FN16-24P6 RCPT-P37	81205	1	24-22-41 AE0218/ /	ALL
D04056P		BACC45FT16-24S6 PLUG-P37	81205	1	24-22-41 AE0218/ /	ALL
D04057J		KA-19-143 RCPT-COAX,E1-4 ,C ILS G/S	91836	1	34-31-31 SHELF/E01/	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 6

Aug 15/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04057P		KA-59-438-M06 PLUG-E1-4,COAX,C ILS G/S	91836	1	34-31-31 SHELF/E01/	ALL
D04058 V		-10204 I.D. TAPE - TEXT AS BELOW	81205	1	24-11-11 / /	ALL
D04058J		BACC45FN22-55S9 RCPT-E1-2	81205	1	24-11-11 AE0319/ /	ALL
D04058P		BACC45FT22A55P9 PLUG-E1-2	81205	1	24-11-11 AE0319/ /	ALL
D04059J		KC-19-256 RCPT-COAX,E1-4 ,C ILS LOC	91836	1	34-31-31 SHELF/E01/04	ALL
D04059P		KC-59-259 PLUG-COAX,E1-4,C ILS LOC	91836	1	34-31-31 SHELF/E01/04	ALL
D04060J		BACC45FN22-19S7 RCPT-E1-2	81205	1	24-11-11 AE0319/ /	ALL
D04060P		BACC45FT22A19P7 PLUG-E1-2	81205	1	24-11-11 AE0319/ /	ALL
D04061J		KA-19-216-M06 RCPT-COAX,FWD PRESS BLKHD,C ILS G/S	91836	1	34-31-31 132/195/L 8	ALL
D04061P		KA-59-438-M06 PLUG-COAX,FWD PRESS BLKHD,C ILS G/S	91836	1	34-31-31 132/195/L 8	ALL
D04062J		BACC45FN20-16P7 RCPT-P32	81205	1	25-31-11 AE0312/ /	ALL
D04062P		BACC45FT20-16S7 PLUG-P32	81205	1	25-31-11 AE0312/ /	ALL
D04063J	1	KC-19-129 RCPT-COAX,FWD PRESS BLKHD,C ILS LOC	91836	1	34-31-31 132/195/L 8	ALL
D04063J	2	KC-19-256 RCPT-COAX,FWD PRESS BLKHD,C ILS LOC	91836	1	34-31-31 132/195/L 8	ALL
D04063J	3	KC-19-31 RCPT-COAX,FWD PRESS BLKHD,C ILS LOC	91836	1	34-31-31 132/195/L 8	ALL
D04063P		KC-59-259 PLUG-COAX,FWD PRESS BLKHD,C ILS LOC	91836	1	34-31-31 132/195/L 8	ALL
D04068J		BACC45FN14-12S7 RCPT-P31	81205	1	25-31-21 AE0311/ /	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 7

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04068P		BACC45FT14-12P7 PLUG-P31	81205	1	25-31-21 AE0311/ /	ALL
D04069J		KA-19-198-M06 RCPT-E2-2 COAX,MKR BCN	91836	1	34-32-11 AE0322/ /	ALL
D04069P		KA-59-392-M06 PLUG-E2-2 COAX,MKR,BCN-L	91836	1	34-32-11 AE0322/ /	ALL
D04071J		KA-19-198-M06 RCPT-COAX,MKR BCN	91836	1	34-32-11 0698/106/0000	050-099
D04071J		KA-19-198-M06 RCPT-COAX,MKR BCN	91836	1	34-32-11 0654+44/106/0000	150-199, 275-299
D04071P		KA-59-277 PLUG-COAX,MKR BCN	91836	1	34-32-11 704/102/0000	050-099
D04071P		KA-59-277 PLUG-COAX,MKR BCN	91836	1	34-32-11 0654+44/106/0000	150-199, 275-299
D04072J		BACC45FN20-41P RCPT-E2-4	81205	1	24-21-41 AE0322/ /	ALL
D04072P		BACC45FT20A41S PLUG-E2-4	81205	1	24-21-41 AE0322/ /	ALL
D04073J		KN-19-198-M06 RCPT-COAX,VOR L	91836	1	34-51-11 AE0322/ /	ALL
D04073P		KN-59-331-M06 PLUG-E2-2 COAX,VOR-L	91836	1	34-51-11 AE0322/ /	ALL
D04074J		BACC45FN18-14S7 RCPT-E2-4	81205	1	24-21-41 AE0322/ /	ALL
D04074P		BACC45FT18A14P7 PLUG-E2-4	81205	1	24-21-41 AE0322/ /	ALL
D04075J		KN-19-198-M06 PLUG-COAX,VOR L	91836	1	34-51-11 AP1501/ /	050-099, 150-154, 162-164, 275-276
D04075J		KN-19-162 PLUG-COAX,VOR L	91836	1	34-51-11 AP1501/ /	155-157, 165-199, 277-299
D04075P		KN-59-330-M06 RCPT-COAX,VOR L	91836	1	34-51-11 AP1501/ /	ALL
D04077J		KD-19-105-M06 RCPT-COAX,VOR R	91836	1	34-51-21 AE0322/ /	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 8

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04077P		KD-59-185-M06 PLUG-E2-3 COAX,VOR-R	91836	1	34-51-21 AE0322/ /	ALL
D04078 V		-10103 I.D. TAPE - TEXT AS BELOW	81205	1	24-23-11 / /	ALL
D04078J		BACC45FN16-24S RCPT-32-4	81205	1	24-23-11 AE0320/ /	050-099
D04078J		BACC45FN16-24S RCPT-E2-4	81205	1	24-23-11 AE0320/ /	150-199, 275-299
D04078P		BACC45FT16A24P PLUG-E2-4	81205	1	24-23-11 AE0320/ /	ALL
D04079J		KN-19-198-M06 PLUG-COAX,VOR R	91836	1	34-51-21 AP1501/ /	050-099, 150-154, 162-164, 275-276
D04079J		KN-19-162 PLUG-COAX,VOR R	91836	1	34-51-21 AP1501/ /	155-157, 165-199, 277-299
D04079P		KN-59-330-M06 RCPT-COAX,VOR R	91836	1	34-51-21 AP1501/ /	ALL
D04080J		BACC45FN20-39S6 RCPT-P31	81205	1	24-21-11 AE0311/ /	ALL
D04080P		BACC45FT20-39P6 PLUG-P31	81205	1	24-21-11 AE0311/ /	ALL
D04081J		KN-19-195-M06 RECPT-COAX,ATC BOTTOM E2-2	91836	1	34-53-13 AE0322/ /	ALL
D04081P		KN-59-329-M06 PLUG-E2-2 COAX,ATC	91836	1	34-53-13 AE0322/ /	ALL
D04082J		BACC45FN22-55P RCPT-E6	81205	1	49-14-11 AC1402/ /	ALL
D04082P		BACC45FT22-55S PLUG-E6	81205	1	49-14-11 AC1402/ /	ALL
D04085J		KN-19-195-M06 RECPT-E2-3 COAX,ATC BOTTOM E2-3	91836	1	34-53-13 AE0322/ /	ALL
D04085P		KN-59-329-M06 PLUG-E2-3 COAX,ATC	91836	1	34-53-21 AE0322/ /	050-099
D04085P		KN-59-329-M06 PLUG-E2-3 COAX,ATC	91836	1	34-53-13 AE0322/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D04000

Page 9

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04086J		BACC45FN18-8S6 RCPT-P6	81205	1	24-51-11 AF0232/ /	ALL
D04086P		BACC45FT18-8P6 PLUG-P6	81205	1	24-51-11 AF0232/ /	ALL
D04087J		KN-19-195-M06 RCPT-COAX,ATC R,BOTTOM	91836	1	34-53-13 0454/112/R007	ALL
D04087P		KN-59-329-M06 PLUG-COAX,ATC R,BOTTOM	91836	1	34-53-21 0454/112/R007	050-099, 150-152
D04087P		KN-59-329-M06 PLUG-COAX,ATC R,BOTTOM	91836	1	34-53-13 0454/112/R007	153-199, 275-299
D04088J		BACC63CD24-22S RCPT-P6	81205	1	24-51-11 AF0232/ /	ALL
D04088P		BACC63BW24-22P PLUG-P6	81205	1	24-51-11 AF0232/ /	ALL
D04090J		BACC45FN18-8S8 RCPT-P6	81205	1	24-51-21 AF0232/ /	ALL
D04090P		BACC45FT18-8P8 PLUG-P6	81205	1	24-51-21 AF0232/ /	ALL
D04092J		BACC63CD24-22S RCPT-P6	81205	1	24-51-21 AF0232/ /	ALL
D04092P		BACC63BW24-22P PLUG-P6	81205	1	24-51-21 AF0232/ /	ALL
D04093J		KN-19-195-M06 PLUG-COAX,ATC-E2-2	91836	1	34-53-13 AE0322/ /	ALL
D04093P		KN-59-329-M06 PLUG-COAX,ATC-E2-2	91836	1	34-53-13 AE0322/ /	ALL
D04094J		BACC63CD24-22SW RCPT-P6	81205	1	24-54-71 AF0232/ /	ALL
D04094P		BACC63BW24-22PW PLUG-P6	81205	1	24-54-71 AF0232/ /	ALL
D04096J		BACC45FN20-25S6 RCPT-P6	81205	1	24-51-31 AF0232/ /	ALL
D04096P		BACC45FT20-25P6 PLUG-P6	81205	1	24-51-31 AF0232/ /	ALL

EQUIPMENT LIST

D280T132

Section D04000

Page 10

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04097J		KN-19-195-M06 RECPT-E2-3 COAX,ATC TOP E2-3	91836	1	34-53-13 AE0322/ /	ALL
D04097P		KN-59-329-M06 PLUG-COAX,ATC-E2-3	91836	1	34-53-13 AE0322/ /	ALL
D04099J		KN-19-196-M06 RCPT-COAX,ATC R,TOP PROD.BRK	91836	1	34-53-13 0448/320/0000	ALL
D04099P		KN-59-329-M06 PLUG-COAX,ATC R,TOP PROD.BRK	91836	1	34-53-13 0448/320/0000	ALL

EQUIPMENT LIST

D280T132

Section D04000
Page 11 End
Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04101J		KN-19-195-M06 RCPT-E2-2 COAX,DME L	91836	1	34-55-11 AE0322/ /	ALL
D04101P		KN-59-329-M06 PLUG-E2-2 COAX	91836	1	34-55-11 AE0322/ /	ALL
D04103J		KN-19-195-M06 RCPT-COAX,DME L	91836	1	34-55-11 0570/110/0000	ALL
D04103P		KN-59-329-M06 PLUG-COAX,DME L	91836	1	34-55-11 0570/110/0000	050-099
D04103P		KN-59-329-M06 PLUG-COAX,DME L	91836	1	34-55-11 0570/114/0000	150-199, 275-299
D04105J		KD-19-104-M06 RCPT-E2-3 COAX,DME R	91836	1	34-55-21 AE0322/ /	ALL
D04105P		KD-59-180-M06 PLUG-E2-3 COAX,DME	91836	1	34-55-21 AE0322/ /	ALL
D04107J		KN-19-195-M06 RCPT-COAX,DME R	91836	1	34-55-21 0665/107/0000	050-099
D04107J		KN-19-195-M06 RCPT-COAX,DME R	91836	1	34-55-21 654+21/107/0000	150-199, 275-299
D04107P		KN-59-329-M06 PLUG-COAX,DME R	91836	1	34-55-21 0665/107/0000	050-099
D04107P		KN-59-329-M06 PLUG-COAX,DME R	91836	1	34-55-21 0654+22/107/0000	150-199, 275-299
D04109J		BACC45FN16-24P9 RCPT-E5-1	81205	1	34-57-11 AC0604/ /	ALL
D04109P		BACC45FT16A24S9 PLUG-E5-1	81205	1	34-57-11 AC0604/ /	ALL
D04110J		BACC45FN20-41S9 RCPT-E2-4	81205	1	24-22-12 AE0306/ /	ALL
D04110P		BACC45FT20A41P9 PLUG-E2-4	81205	1	24-22-12 AE0306/ /	ALL
D04112J		BACC45FN22-55S9 RCPT-P34	81205	1	24-22-41 AE0204/ /	ALL
D04112P		BACC45FT22-55P9 PLUG-P34	81205	1	24-22-41 AE0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D04100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04113J		BACC45FN12-12P8 RCPT-E5-1	81205	1	34-57-21 AC0604/ /	ALL
D04113P		BACC45FT12A12S8 PLUG-E5-1	81205	1	34-57-21 AC0604/ /	ALL
D04114J		BACC45FN16-10S8 RCPT-E2-4	81205	1	24-21-41 AE0307/ /	ALL
D04114P		BACC45FT16A10P8 PLUG-E2-4	81205	1	24-21-41 AE0307/ /	ALL
D04116J		BACC45FN14-4S8 RCPT-P6	81205	1	24-32-11 AE0222/ /	ALL
D04116P		BACC45FT14-4P8 PLUG-P6	81205	1	24-32-11 AE0222/ /	ALL
D04118J		BACC45FN10-5P6 RCPT-P6	81205	1	24-34-11 AE0222/ /	ALL
D04118P		BACC45FT10-5S6 PLUG-P6	81205	1	24-34-11 AE0222/ /	ALL
D04120J		BACC45FN14-4S8 RCPT-P6	81205	1	24-32-11 AE0222/ /	ALL
D04120P		BACC45FT14-4P8 PLUG-P6	81205	1	24-32-11 AE0222/ /	ALL
D04121J		BACC45FN10-5S RCPT-	81205	1	23-42-11 1510/283/L030	050-099, 150-199
D04121P		BACC45FT10-5P PLUG-	81205	1	23-42-11 1510/283/L030	050-099, 150-199
D04122J		BACC45FN10-5P RCPT-P6	81205	1	24-34-11 AE0222/ /	ALL
D04122P		BACC45FT10-5S PLUG-P6	81205	1	24-34-11 AE0222/ /	ALL
D04123J		BACC45FN10-5S RCPT-	81205	1	23-42-11 1510/283/R030	050-099, 150-199
D04123P		BACC45FT10-5P PLUG-	81205	1	23-42-11 1510/283/R030	050-099, 150-199
D04124J		BACC45FN14-4S7 RCPT-P6	81205	1	24-33-11 AF0232/ /	ALL

EQUIPMENT LIST

D280T132

Section D04100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04124P		BACC45FT14-4P7 PLUG-P6	81205	1	24-33-11 AF0232/ /	ALL
D04126J		BACC45FN16-24S6 RCPT-P6	81205	1	24-34-11 AF0232/ /	ALL
D04126P		BACC45FT16-24P6 PLUG-P6	81205	1	24-31-11 AF0232/ /	ALL
D04128J		BACC45FN14-4S8 RCPT-P33	81205	1	24-31-11 AE0203/ /	ALL
D04128P		BACC45FT14-4P8 PLUG-P33	81205	1	24-31-11 AE0203/ /	ALL
D04130J		BACC45FN14-4S9 RCPT-E6	81205	1	24-31-41 AC1402/ /	ALL
D04130P		BACC45FT14-4P9 PLUG-E6	81205	1	24-31-41 AC1402/ /	ALL
D04131J		BACC45FN12-12S RCPT-	81205	1	27-61-15 AE0107/ /	ALL
D04131P		BACC45FT12C12P PLUG-	81205	1	27-61-15 AE0107/ /	ALL
D04133J		BACC45FN12-12S6 RCPT-	81205	1	27-61-14 AE0107/ /	ALL
D04133P		BACC45FT12C12P6 PLUG-	81205	1	27-61-14 AE0107/ /	ALL
D04134J		BACC45FN14-4S7 RCPT-P33	81205	1	24-31-41 AE0203/ /	ALL
D04134P		BACC45FT14-4P7 PLUG-P33	81205	1	24-31-41 AE0203/ /	ALL
D04135J		BACC45FN12-12S7 RCPT-	81205	1	27-61-16 AE0107/ /	ALL
D04135P		BACC45FT12C12P7 PLUG-	81205	1	27-61-16 AE0107/ /	ALL
D04137J		BACC45FN14-15S RCPT-	81205	1	27-61-17 AE0107/ /	ALL
D04137P		BACC45FT14C15P PLUG-	81205	1	27-61-17 AE0107/ /	ALL

EQUIPMENT LIST

D280T132

Section D04100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04138J		FRF0-36-5S-747 RCPT-APU FIREWALL	71468	1	49-41-11 AV1801/ /	ALL
D04138JK		G6652-36 CLAMP-	06324	1	49-41-11 / /	ALL
D04138P		FRF6-36-5P01-747 PLUG-APU FIREWALL	71468	1	49-41-11 AV1801/ /	ALL
D04138PQ		G63292 CLAMP-	06324	1	49-41-11 / /	ALL
D04139J		BACC45FN14-15S6 RCPT-	81205	1	27-61-13 AE0107/ /	ALL
D04139P		BACC45FT14C15P6 PLUG-	81205	1	27-61-13 AE0107/ /	ALL
D04141J		BACC45FN14-15S7 RCPT-	81205	1	27-61-18 AE0107/ /	ALL
D04141P		BACC45FT14C15P7 PLUG-	81205	1	27-61-18 AE0107/ /	ALL
D04147J		BACC45FN22-55S8 RCPT-RMI-LP1 PNL	81205	1	31-25-11 AF0119/ /	ALL
D04147P		BACC45FT22-55P8 PLUG-P1	81205	1	31-25-11 AF0119/ /	ALL
D04148J		BACC63BT14B7S6 RCPT-ENGINE FIREWALL,LH	81205	1	26-11-21 AW0305/ /	ALL
D04148JK		BACC10KA14 CLAMP-	81205	1	26-11-21 / /	ALL
D04150J		BACC63BT16B10S7 RCPT-ENGINE FIREWALL,RH	81205	1	36-23-21 AW0306/ /	ALL
D04150JK		BACC10KA16 CLAMP-	81205	1	36-23-21 / /	ALL
D04151J		BACC45FN20-41P RCPT-E2-2	81205	1	34-32-11 AE0306/ /	ALL
D04151P		BACC45FT20A41S PLUG-E2-2	81205	1	34-61-11 AE0306/ /	ALL
D04153J		BACC45FN16-24P RCPT-ADF-L	81205	1	34-22-81 AC0604/ /	050-099

EQUIPMENT LIST

D280T132

Section D04100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04153J		BACC45FN14-15P RCPT-ADF-L	81205	1	34-22-81 AC0604/ /	150-199, 275-299
D04153P		BACC45FT16A24S PLUG-E5-1	81205	1	34-22-81 AC0604/ /	050-099
D04153P		BACC45FT14A15S PLUG-E5-1	81205	1	34-22-12 AC0604/ /	150-199, 275-299
D04154J		BACC63BT14B7S6 RCPT-ENGINE FIREWALL,LH	81205	1	26-11-11 AW0305/ /	ALL
D04154JK		BACC10KA14 CLAMP-	81205	1	26-11-11 / /	ALL
D04154P		BACC63BR14B7P6L PLUG-ENGINE FIREWALL,L/H	81205	2	75-11-11 AW0305/ /	ALL
D04154PQ		BACC10KA14 CLAMP-	81205	2	26-11-11 / /	ALL
D04156J		BACC63BT16B10S7 RCPT-ENGINE FIREWALL,RH	81205	1	36-23-11 AW0306/ /	ALL
D04156JK		BACC10KA16 CLAMP-	81205	1	36-23-11 / /	ALL
D04156P		BACC63BR16B10P7L PLUG-ENGINE FIREWALL,RH	81205	2	36-23-11 AW0306/ /	ALL
D04156PQ		BACC10KA16 CLAMP-	81205	2	36-23-11 / /	ALL
D04160J		BACC63BV14F7S6 RCPT-LH COWL	81205	1	78-34-11 AW0311/ /	050-099, 150-166, 275-299
D04160JK		BACC10KD14 CLAMP-	96906	1	78-34-11 / /	050-099, 150-155, 163-165, 275-276
D04160JK		BACC10KD14 CLAMP-	81205	1	78-34-11 / /	156-162, 166, 277- 299
D04162J		BACC63BV14F7SN RCPT-RH COWL	81205	1	78-34-11 AW0310/ /	050-099, 150-166, 275-299
D04162JK		BACC10KD14 CLAMP-	81205	1	78-34-11 / /	050-099, 150-166, 275-299
D04163J		BACC45FN14-15S RCPT-P1	81205	1	34-22-82 AF0119/ /	ALL

EQUIPMENT LIST

D280T132

Section D04100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04163P		BACC45FT14-15P PLUG-P1	81205	1	34-13-11 AF0119/ /	ALL
D04164J		BACC63BV16F10SN RCPT-RH COWL T/R	81205	1	78-36-21 AW0310/ /	ALL
D04164JK		BACC10KD16 CLAMP-	81205	1	78-36-21 / /	ALL
D04165J		BACC45FN20-25S7 RCPT-P11	81205	1	34-22-82 AF0201/ /	ALL
D04165P		BACC45FT20A25P7 PLUG-P11	81205	1	34-22-82 AF0201/ /	ALL
D04166J		BACC63BV22F19SN RCPT-LH COWL T/R	81205	1	78-31-21 AW0311/ /	ALL
D04166JK		BACC10KD22 CLAMP-	81205	1	78-31-21 / /	ALL
D04167J		BACC45FN22-55S7 RCPT-P1	81205	1	22-14-11 AF0119/ /	ALL
D04167P		BACC45FT22-55P7 PLUG-P1	81205	1	22-14-11 AF0119/ /	ALL
D04168J		BACC45FM14C7P7 RCPT-R WING/SAILBOAT	81205	1	29-11-22 AW0322/ /	ALL
D04168P		BACC63BP14R7S7L PLUG-R WING/STRUT	81205	1	29-11-22 AW0322/ /	ALL
D04168PQ		BACC10KD14 CLAMP-	81205	1	29-11-22 / /	ALL
D04169J		BACC45FN20-41P9 RCPT-	81205	1	34-13-11 AE0319/ /	ALL
D04169P		BACC45FT20A41S9 PLUG-E1-3	81205	1	34-13-11 AE0319/ /	ALL
D04170J		BACC45FM22C19P6 RCPT-R WING/SAILBOAT	81205	1	78-34-21 AW0322/ /	ALL
D04170P		BACC63BP22A19S6L PLUG-R STRUT/SAILBOAT	81205	1	78-34-21 AW0322/ /	ALL
D04170PQ		BACC10KD22 CLAMP-	81205	1	78-34-21 / /	ALL

EQUIPMENT LIST

D280T132

Section D04100

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04171J		BACC45FN16-24S6 RCPT-P1	81205	1	34-13-21 AF0119/ /	ALL
D04171P		BACC45FT16-24P6 PLUG-P1	81205	1	34-22-91 AF0119/ /	ALL
D04173J		BACC45FN16-24S7 RCPT-P1	81205	1	34-22-81 AF0119/ /	ALL
D04173P		BACC45FT16-24P7 PLUG-P1	81205	1	34-22-81 AF0119/ /	ALL
D04175J		BACC45FN18-31P6 RCPT-	81205	1	34-22-82 AE0319/ /	ALL
D04175P		BACC45FT18A31S6 PLUG-E1-4	81205	1	34-22-82 AE0319/ /	ALL
D04180J		BACC63BV14F7S6 RCPT-LH COWL	81205	1	30-21-11 AW0311/ /	050-099, 150-199, 275-278
D04180JK		BACC10KD14 CLAMP-	96906	1	30-21-11 / /	050-099, 150-155, 163-165, 275-276
D04180JK		BACC10KD14 CLAMP-	81205	1	30-21-11 / /	156-162, 166-199, 277-278
D04180P		BACC63BP14C7P6 PLUG-LH COWL	81205	2	78-34-11 80/0/R022	ALL
D04180PQ		BACC10KD14 CLAMP-	81205	2	78-34-11 / /	ALL
D04182J		BACC63BV14F7SN RCPT-RH COWL	81205	1	78-34-11 AW0310/ /	050-099, 150-199, 275-278
D04182JK		BACC10KD14 CLAMP-	96906	1	78-34-11 / /	050-099, 150-155, 163-165, 275-276
D04182JK		BACC10KD14 CLAMP-	81205	1	78-34-11 / /	156-162, 166-199, 277-278
D04182P		BACC63BP14C7PN PLUG-RH COWL	81205	2	78-34-11 0/0/R000	ALL
D04182PQ		BACC10KD14 CLAMP-	81205	2	78-34-11 / /	ALL
D04185J		BACC45FN20-25S9 RCPT-P11	81205	1	27-11-22 AF0201/ /	ALL

EQUIPMENT LIST

D280T132

Section D04100

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04185P		BACC45FT20A25P9 PLUG-P11	81205	1	27-11-22 AF0201/ /	ALL
D04187J		BACC45FN24-57S RCPT-P11	81205	1	24-11-11 AF0203/ /	ALL
D04187P		BACC45FT24A57P PLUG-P11	81205	1	27-41-21 AF0203/ /	ALL
D04189J		BACC45FN24-57S RCPT-P11	81205	1	27-09-11 AF0201/ /	ALL
D04189P		BACC45FT24A57P PLUG-P11	81205	1	27-09-11 AF0201/ /	ALL
D04192J		BACC63BV22F19SN RCPT-LH COWL T/R	81205	1	78-31-11 AW0311/ /	ALL
D04192JK		BACC10KD22 CLAMP-	81205	1	78-31-11 / /	ALL
D04192P		BACC63BP22C19PNL PLUG-LH COWL	81205	2	78-31-11 AW0311/ /	ALL
D04192PQ		BACC10KD22 CLAMP-	81205	2	78-31-11 / /	ALL
D04193J		BACC45FN24-57S7 RCPT-P11	81205	1	27-09-13 AF0201/ /	ALL
D04193P		BACC45FT24A57P7 PLUG-P11	81205	1	27-09-13 AF0201/ /	ALL
D04194J		BACC63BV16F10SN RCPT-RH COWL T/R	81205	1	78-31-11 AW0310/ /	ALL
D04194JK		BACC10KD16 CLAMP-	96906	1	78-31-11 / /	050-099, 150-199
D04194JK		BACC10KD16 CLAMP-	81205	1	78-31-11 / /	275-299
D04194P		BACC63BP16C10PNL PLUG-RH COWL	81205	2	78-31-11 AW0310/ /	ALL
D04194PQ		BACC10KD16 CLAMP-	81205	2	78-31-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D04100

Page 8 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04200J		BACC63BT14B7S RCPT-ENGINE FIREWALL,LH	81205	1	26-11-11 AW0305/ /	ALL
D04200JK		BACC10KA14 CLAMP-	81205	1	26-11-11 / /	ALL
D04200P		BACC63BR14B7PNL PLUG-ENGINE FIREWALL,LH	81205	2	26-11-11 AW0305/ /	ALL
D04200PQ		BACC10KA14 CLAMP-	81205	2	26-11-11 / /	ALL
D04201J		BACC45FN10-5S8 RCPT-E1-6	81205	1	34-21-11 AE0305/ /	ALL
D04201P		BACC45FT10A5P8 PLUG-	81205	1	34-21-11 AE0305/ /	ALL
D04202J		BACC63BV28F42SN RCPT-L WING/STRUT	81205	1	78-34-11 AW0319/ /	ALL
D04202JK		BACC10KD28 CLAMP-	81205	1	78-34-11 AW0319/ /	ALL
D04202P		BACC63BP28C42PNL PLUG-L WING/STRUT	81205	1	78-34-11 AW0319/ /	050-099, 150-199, 275-278
D04202PQ		BACC10KD28 CLAMP-	81205	1	78-34-11 / /	050-099, 150-199, 275-278
D04203J		BACC45FN10-5S RCPT-E1-5	81205	1	34-46-11 AE0305/ /	ALL
D04203P		BACC45FT10A5P PLUG-E1-5	81205	1	34-46-11 AE0305/ /	ALL
D04204J		BACC63BV22F19SN RCPT-L WING/STRUT	81205	1	26-11-11 AW0319/ /	ALL
D04204JK		BACC10KD22 CLAMP	81205	1	26-11-11 AW0319/ /	ALL
D04204P		BACC63BP22C19PNL PLUG-L WING/STRUT	81205	1	76-11-11 AW0319/ /	ALL
D04204PQ		BACC10KD22 CLAMP-	81205	1	76-11-11 / /	ALL
D04205J		BACC45FN10-5S RCPT-E1-4	81205	1	34-22-36 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04205P		BACC45FT10A5P PLUG-E1-4	81205	1	34-22-36 AE0305/ /	ALL
D04206J		BACC63BV24A30S8 RCPT-L WING/STRUT	81205	1	36-11-11 AW0319/ /	ALL
D04206JK		BACC10KD24 CLAMP-	81205	1	36-11-11 / /	ALL
D04206P		BACC63BP24A30P8L PLUG-L WING/STRUT	81205	1	36-22-11 AW0319/ /	ALL
D04206PQ		BACC10KD24 CLAMP-	81205	1	36-22-11 / /	ALL
D04207J		BACC45FN20-28S8 RCPT-E1-3	81205	1	22-11-11 AE0305/ /	ALL
D04207P		BACC45FT20A28P8 PLUG-E1-3	81205	1	22-11-11 AE0305/ /	ALL
D04208J		BACC63BT24B30S6 RCPT-ENGINE FIREWALL,LH	81205	1	36-11-61 AW0305/ /	ALL
D04208JK		BACC10KA24 CLAMP-	81205	1	36-11-61 / /	ALL
D04208P		BACC63BR24D30P6L PLUG-ENGINE FIREWALL,LH	81205	2	36-11-61 AW0305/ /	ALL
D04208PQ		BACC10KA24 CLAMP-	81205	2	36-11-61 / /	ALL
D04211J		BACC45FN12-12S8 RCPT-E2-6	81205	1	23-11-11 AE0306/ /	ALL
D04211P		BACC45FT12A12P8 PLUG-E2-6	81205	1	23-11-11 AE0306/ /	ALL
D04212J		BACC63BV24F30S9 RCPT-L WING/STRUT	81205	1	36-13-11 AW0319/ /	ALL
D04212JK		BACC10KD24 CLAMP-	81205	1	36-13-11 / /	ALL
D04212P		BACC63BP24C30P9L PLUG-L WING/STRUT	81205	1	78-36-11 AW0319/ /	ALL
D04212PQ		BACC10KD24 CLAMP-	81205	1	78-36-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04213J		BACC45FN14-12S6 RCPT-E2-5	81205	1	23-21-11 AE0306/ /	ALL
D04213P		BACC45FT14A12P6 PLUG-E2-5	81205	1	23-21-11 AE0306/ /	ALL
D04214J		BACC63BV24F30S7 RCPT-L WING/STRUT	81205	1	77-12-11 AW0319/ /	ALL
D04214JK		BACC10KD24 CLAMP-	81205	1	77-12-11 / /	ALL
D04214P		BACC63BP24C30P7L PLUG-L WING/STRUT	81205	1	78-36-11 AW0319/ /	ALL
D04214PQ		BACC10KD24 CLAMP-	81205	1	78-36-11 / /	ALL
D04215J		BACC45FN12-12S7 RCPT-E2-3	81205	1	31-31-11 AE0306/ /	ALL
D04215P		BACC45FT12A12P7 PLUG-E2-3	81205	1	31-31-11 AE0306/ /	ALL
D04216J		BACC63BT24B30S8 RCPT-ENGINE FIREWALL,LH	81205	1	24-11-11 AW0305/ /	050-099, 150-199, 275-278
D04216JK		BACC10KA24 CLAMP-	81205	1	24-11-11 / /	050-099, 150-199, 275-278
D04216P		BACC63BR24B30P8L PLUG-ENGINE FIREWALL LH	81205	2	24-11-11 AW0305/ /	ALL
D04216PQ		BACC10KA24 CLAMP-	81205	2	24-11-11 / /	ALL
D04217J		BACC45FN14-15S RCPT-E2-2	81205	1	34-61-11 AE0306/ /	ALL
D04217P		BACC45FT14A15P PLUG-E2-2	81205	1	34-61-11 AE0306/ /	ALL
D04218J		BACC45FM14C7S6 RCPT-L WING/STRUT	81205	1	26-11-11 AW0319/ /	ALL
D04218P		BACC63BP14A7P6L PLUG-L WING/STRUT	81205	1	26-11-11 AW0319/ /	ALL
D04218PQ		BACC10KD14 CLAMP-	81205	1	26-11-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04219J		BACC45FN12-12S RCPT-E5-3	81205	1	23-31-12 AC0608/ /	ALL
D04220J		BACC63BT22B19S RCPT-ENGINE FIREWALL,FWD	81205	1	76-11-11 AW0307/ /	ALL
D04220JK		BACC10KA22 CLAMP-	81205	1	76-11-11 / /	ALL
D04223J		BACC45FN10-5S RCPT-E5-1	81205	1	34-33-11 AC0604/ /	ALL
D04223P		BACC45FT10A5P PLUG-E5-1	81205	1	34-33-11 AC0604/ /	ALL
D04224J		BACC63BV28F42S6 RCPT-STRUT/FANCASE RH	81205	1	73-21-11 AW0310/POS/01	ALL
D04224JK		BACC10KD28 CLAMP-	81205	1	73-21-11 / /	ALL
D04224P		BACC63BP28C42P6L PLUG-STRUT/FANCASE	81205	2	73-21-11 AW0310/ /	050-099, 155-199, 277-299
D04224P		BACC63BP28C42P6L PLUG-STRUT/FANCASE	81205	2	73-21-11 AW0312/ /	150-154, 275-276
D04224PQ		BACC10KD28 CLAMP-	81205	2	73-21-11 / /	ALL
D04225J		BACC45FN12A12S8 RCPT-E1-4	81205	1	22-11-32 AE0307/ /	ALL
D04225P		BACC45FT12A12P8 PLUG-E1-4	81205	1	22-11-32 AE0307/ /	ALL
D04227J		BACC45FN14-12S RCPT-E2-5	81205	1	23-12-11 AE0307/ /	ALL
D04227P		BACC45FT14A12P PLUG-E2-5	81205	1	23-12-11 AE0307/ /	ALL
D04228J		BACC63BT14B7S7 RCPT-ENGINE FIREWALL,LH	81205	1	26-11-11 AW0305/ /	ALL
D04228JK		BACC10KA14 CLAMP-	81205	1	26-11-11 / /	ALL
D04228P		BACC63BR14B7P7L PLUG-ENGINE FIREWALL,LH	81205	2	26-11-11 AW0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04228PQ		BACC10KA14 CLAMP-	81205	2	26-11-11 / /	ALL
D04229J		BACC45FN16-24S8 RCPT-E2-2	81205	1	31-35-12 AE0306/ /	050-099, 150-154, 275-299
D04229J		BACC45FN16-24S8 RCPT-E2-2	81205	1	31-35-12 355/125/R 13	155-199
D04229P		BACC45FT16A24P8 PLUG -E2-2	81205	1	34-45-14 AE0306/ /	050-099
D04229P		BACC45FT16A24P8 PLUG -E2-2	81205	1	31-35-12 AE0306/ /	150-199, 275-299
D04230J		BACC63BT22B19S RCPT-ENGINE FIREWALL,FWD	81205	1	76-11-11 AW0307/ /	ALL
D04230JK		BACC10KA22 CLAMP-	81205	1	76-11-11 / /	ALL
D04230P		BACC63BR22B19PNL PLUG-ENGINE FIREWALL,FWD	81205	2	76-11-11 AW0307/ /	ALL
D04230PQ		BACC10KA22 CLAMP-	81205	2	76-11-11 / /	ALL
D04232J		BACC63BT28B42S RCPT-ENGINE FIREWALL,LH	81205	1	71-01-11 AW0305/ /	050-099, 150-199, 275-278
D04232JK		BACC10KA28 CLAMP-	81205	1	71-01-11 / /	050-099, 150-199, 275-278
D04232P		BACC63BR28B42PNL PLUG-ENGINE FIREWALL,LH	81205	2	71-01-11 AW0305/ /	ALL
D04232PQ		BACC10KA28 CLAMP-	81205	2	71-01-11 / /	ALL
D04233J		BACC45FN10-5S7 RCPT-E2-2	81205	1	34-51-11 AE0307/ /	ALL
D04233P		BACC45FT10A5P7 PLUG-E2-2	81205	1	34-51-11 AE0307/ /	ALL
D04234J		BACC63BV28F42SN RCPT-L WING/STRUT	81205	1	73-21-11 AW0319/ /	ALL
D04234JK		BACC10KD28 CLAMP-	81205	1	73-21-11 AW0319/ /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04234P		BACC63BP28C42PNL PLUG-L WING/STRUT	81205	1	73-21-11 AW0319/ /	ALL
D04234PQ		BACC10KD28 CLAMP-	81205	1	73-21-11 / /	ALL
D04236J		BACC63BT14B7S RCPT-ENGINE FIREWALL,LH	81205	1	26-11-11 AW0305/ /	ALL
D04236JK		BACC10KA14 CLAMP-	81205	1	26-11-11 / /	ALL
D04238J		BACC63BV22F19SN RCPT-R WING/STRUT	81205	1	26-11-21 AW0320/ /	ALL
D04238JK		BACC10KD22 CLAMP	81205	1	26-11-21 AW0320/ /	ALL
D04238P		BACC63BP22C19PNL PLUG-R WING/STRUT	81205	1	76-11-11 AW0320/ /	ALL
D04238PQ		BACC10KD22 CLAMP-	81205	1	76-11-11 / /	ALL
D04239J		BACC45FN12-12S6 RCPT-E1-3	81205	1	22-31-12 AE0319/ /	ALL
D04239P		BACC45FT12A12P6 PLUG-E1-3	81205	1	22-31-12 AE0319/ /	ALL
D04240J		BACC63BT28B42S RCPT-ENGINE FIREWALL,LH	81205	1	71-01-11 AW0307/ /	050-099, 150-166, 275-299
D04240JK		BACC10KA28 CLAMP-	81205	1	71-01-11 / /	050-099, 150-166, 275-299
D04241J		BACC45FN20-25S8 RCPT-E1-4	81205	1	22-11-32 AE0319/ /	ALL
D04241P		BACC45FT20A25P8 PLUG-E1-4	81205	1	22-11-32 AE0319/ /	ALL
D04242J		BACC63BV28F42SN RCPT-R WING/STRUT	81205	1	78-34-11 AW0320/ /	ALL
D04242JK		BACC10KD28 CLAMP-	81205	1	78-34-11 AW0320/ /	050-099, 150-199
D04242JK		BACC10KD28 CLAMP-	81205	1	78-34-11 / /	275-299

EQUIPMENT LIST

D280T132

Section D04200

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04242P		BACC63BP28C42PNL PLUG-R WING/STRUT	81205	1	78-34-11 AW0320/ /	050-099, 150-166, 275-299
D04242PQ		BACC10KD28 CLAMP-	81205	1	78-34-11 / /	050-099, 150-166, 275-299
D04244J		BACC63BV28F42SN RCPT-R WING/STRUT	81205	1	73-21-11 AW0320/ /	ALL
D04244JK		BACC10KD28 CLAMP-	81205	1	73-21-11 AW0320/ /	ALL
D04244P		BACC63BP28C42PNL PLUG-R WING/STRUT	81205	1	73-21-11 AW0320/ /	ALL
D04244PQ		BACC10KD28 CLAMP-	81205	1	73-21-11 / /	ALL
D04245J		BACC45FN10-5S6 RCPT-E1-6	81205	1	34-21-21 AE0317/ /	ALL
D04245P		BACC45FT10A5P6 PLUG-	81205	1	34-21-21 AE0317/ /	ALL
D04246J		BACC63BV28F42S6 RCPT-STRUT FANCASE RH	81205	1	73-21-11 AW0310/POS/01	ALL
D04246JK		BACC10KD28 CLAMP-	81205	1	73-21-11 / /	ALL
D04247J		BACC45FN20-28S7 RCPT-E1-5	81205	1	22-11-21 AE0317/ /	ALL
D04247P		BACC45FT20A28P7 PLUG-E1-5	81205	1	22-11-21 AE0317/ /	ALL
D04248J		BACC63BV24A30S8 RCPT-R WING/STRUT	81205	1	36-22-11 AW0320/ /	ALL
D04248JK		BACC10KD24 CLAMP-	81205	1	36-22-11 / /	ALL
D04248P		BACC63BP24A30P8L PLUG-R WING/STRUT	81205	1	36-22-11 AW0320/ /	ALL
D04248PQ		BACC10KD24 CLAMP-	81205	1	36-22-11 / /	ALL
D04251J		BACC45FN14-12S8 RCPT-E2-5	81205	1	23-12-21 AE0320/ /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04251P		BACC45FT14A12P8 PLUG-E2-5	81205	1	23-12-21 AE0320/ /	ALL
D04252J		BACC63BV24F30S9 RCPT-R WING/STRUT	81205	1	78-36-21 AW0320/ /	ALL
D04252JK		BACC10KD24 CLAMP-	81205	1	78-36-21 / /	ALL
D04252P		BACC63BP24C30P9L PLUG-R WING/STRUT	81205	1	78-36-21 AW0320/ /	ALL
D04252PQ		BACC10KD24 CLAMP-	81205	1	78-36-21 / /	ALL
D04253J		BACC45FN16-24S6 RCPT-E2-3	81205	1	34-12-21 AE0320/ /	ALL
D04253P		BACC45FT16A24P6 PLUG-E2-3	81205	1	34-61-21 AE0320/ /	ALL
D04254J		BACC63BV24F30S7 RCPT-R WING/STRUT	81205	1	78-36-21 AW0320/ /	ALL
D04254JK		BACC10KD24 CLAMP-	81205	1	78-36-21 / /	ALL
D04254P		BACC63BP24C30P7L PLUG-R WING/STRUT	81205	1	78-36-21 AW0320/ /	ALL
D04254PQ		BACC10KD24 CLAMP-	81205	1	78-36-21 / /	ALL
D04255J		BACC45FN14A12S7 RCPT-E2-6	81205	1	23-11-21 AE0320/ /	ALL
D04255P		BACC45FT14A12P7 PLUG-E2-6	81205	1	23-11-21 AE0320/ /	ALL
D04256J		BACC63BT14B7S7 RCPT-ENGINE FIREWALL,LH	81205	1	26-11-21 AW0305/ /	ALL
D04256JK		BACC10KA14 CLAMP-	81205	1	26-11-21 / /	ALL
D04257J		BACC45FN10-5P RCPT-E2-1	81205	1	27-09-11 AE0308/ /	ALL
D04257P		BACC45FT10A5S PLUG-E2-1	81205	1	27-41-21 AE0308/ /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04258J		BACC63BT24B30S6 RCPT-ENGINE FIREWALL,LH	81205	1	36-13-21 AW0305/ /	ALL
D04258JK		BACC10KA24 CLAMP-	81205	1	36-13-21 / /	ALL
D04259J		BACC45FN14-12S RCPT-E5-1	81205	1	34-33-21 AC0604/ /	ALL
D04259P		BACC45FT14A12P PLUG-E5-1	81205	1	34-33-21 AC0604/ /	ALL
D04263J		BACC45FN20-25S8 RCPT-P3	81205	1	34-22-91 AF0120/ /	ALL
D04263P		BACC45FT20-25P8 PLUG-P3	81205	1	22-14-11 AF0120/ /	ALL
D04264J		BACC45FM14C7S6 RCPT-R WING/STRUT	81205	1	26-11-21 AW0320/ /	ALL
D04264P		BACC63BP14A7P6L PLUG-R WING/STRUT	81205	1	26-11-21 AW0320/ /	ALL
D04264PQ		BACC10KD14 CLAMP-	81205	1	26-11-21 / /	ALL
D04266J		BACC63BT24B30S8 RCPT-ENGINE FIREWALL,LH	81205	1	24-11-21 AW0305/ /	050-099, 150-166, 275-299
D04266JK		BACC10KA24 CLAMP-	81205	1	24-11-21 / /	050-099, 150-166, 275-299
D04267J		BACC45FN10-5S9 RCPT-P1	81205	1	34-22-81 AF0119/ /	ALL
D04267P		BACC45FT10-5P9 PLUG-P1	81205	1	34-22-81 AF0119/ /	ALL
D04268J		BACC45FM22C19S7 RCPT-	81205	1	28-42-11 AL1002/ /	050-099, 280-299
D04268J		BACC45FM22C19S7 RCPT-	81205	1	28-41-21 AL1002/ /	150-199, 275-278
D04268P		BACC63BP22A19P7L PLUG-R WING RS/BODY	81205	1	28-41-22 AL1002/ /	050-099, 150-156, 162-166, 275-276
D04268P		BACC63BP22A19P7L PLUG-R WING RS/BODY	81205	1	28-41-22 AL1002/ /	157, 167-199, 277- 299

EQUIPMENT LIST

D280T132

Section D04200

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04268PQ		BACC10KD22 CLAMP-	81205	1	28-41-22 / /	ALL
D04271J		BACC45FN22-55S7 RCPT-P11	81205	1	22-11-11 AF0203/ /	050-099, 153-199, 277-299
D04271J		BACC45FN22-32S7 RCPT-P11	81205	1	22-11-11 AF0203/ /	150-152, 275-276
D04271P		BACC45FT22A55P7 PLUG-P11	81205	1	27-41-11 AF0203/ /	050-099, 153-199, 277-299
D04271P		BACC45FT22A32P7 PLUG-P11	81205	1	27-41-11 AF0203/ /	150-152, 275-276
D04272J		BACC63BV24A30S6 RCPT-R WING RS/BODY	81205	1	27-58-11 AL1002/ /	ALL
D04272JK		BACC10KD24 CLAMP-	81205	1	27-58-11 / /	ALL
D04272P		BACC63BP24A30P6L PLUG-R WING RS/BODY	81205	1	27-18-11 AL1002/ /	ALL
D04272PQ		BACC10KD24 CLAMP-	81205	1	27-18-11 / /	ALL
D04273J		BACC45FN20-39S6 RCPT-P11	81205	1	23-11-11 AF0201/ /	ALL
D04273P		BACC45FT20A39P6 PLUG-P11	81205	1	27-09-11 AF0201/ /	ALL
D04278J		BACC45FM22C19S9 RCPT-R FWD OUTBD PANEL	81205	1	32-42-11 AL1002/ /	ALL
D04278P		BACC63BP22A19P9L PLUG-R WING RS/BODY	81205	1	32-42-11 AL1002/ /	ALL
D04278PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	ALL
D04280J		BACC45FM14C7P7 RCPT-L WING/SAILBOAT	81205	1	29-11-12 AW0321/ /	ALL
D04280P		BACC63BP14R7S7L PLUG-L WING/SAILBOAT	81205	1	29-11-12 AW0321/ /	ALL
D04280PQ		BACC10KD14 CLAMP-	81205	1	29-11-12 / /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04281J		BACC45FN10-5S9 RCPT-E1-2	81205	1	34-22-16 AE0305/ /	ALL
D04281P		BACC45FT10A5P9 PLUG-	81205	1	34-22-16 AE0305/ /	ALL
D04282J		BACC45FN18-14P8 RCPT-P19	81205	1	25-24-11 AP0401/ /	050-099
D04282J		BACC45FN18-14P8 RCPT-	81205	1	25-24-11 AP0401/ /	150, 152-199
D04282J		BACC45FN16-10P8 RCPT-	81205	1	25-24-11 AP0401/ /	151, 275-299
D04282P		BACC45FT18-14S8 PLUG-P19	81205	1	38-13-11 AP0401/ /	050-099, 150, 152-199
D04282P		BACC45FT16-10S8 PLUG-P19	81205	1	38-13-11 AP0401/ /	151, 275-299
D04283J		BACC45FN22-55P RCPT-P1-1	81205	1	33-13-11 P001-01/ /	ALL
D04283P		BACC45FT22A55S PLUG-P1-1	81205	1	34-22-91 P001-01/ /	ALL
D04284J		BACC45FN20-39S RCPT-P37	81205	1	28-22-11 AE0218/ /	ALL
D04284P		BACC45FT20-39P PLUG-	81205	1	28-22-11 AE0218/ /	ALL
D04285J		BACC45FN22-55P8 RCPT-P1-3	81205	1	33-16-13 AF0113/ /	ALL
D04285JK		NEP-24 CAP-CONDUCTIVE (ESD PROTECTION)	ORN51	1	33-16-13 AF0113/ /	167-199, 278-299
D04285P		BACC45FT22A55S8 PLUG-P1-3	81205	1	22-14-11 AF0113/ /	ALL
D04286		CUSTOMER PLUG	CUST	1	28-31-12 AE0204/ /	051-099
D04286J		BACC45FN20-28S6 RCPT-P61	81205	1	28-22-11 AF0204/ /	ALL
D04286P		BACC45FT20-28P6 PLUG-P61	81205	1	28-22-11 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 11

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04287J		BACC45FN16-24P7 RCPT-P1	81205	1	34-22-17 P001-01/ /	ALL
D04287P		BACC45FT16A24S7 PLUG-P1-1	81205	1	34-22-17 P001-01/ /	ALL
D04288J		BACC45FN20-28P7 RCPT-	81205	1	21-43-11 AE0209/ /	ALL
D04288P		BACC45FT20-28S7 PLUG-P36	81205	1	30-41-11 AE0209/ /	ALL
D04290J		BACC45FN24-61P9 RCPT-	81205	1	33-21-11 AP0401/ /	050-099, 150-199
D04290J		BACC45FN22-55P9 RCPT-	81205	1	33-21-11 AP0401/ /	275-299
D04290P		BACC45FT24-61S9 PLUG-P19	81205	1	33-22-21 AP0401/ /	050-099, 150-199
D04290P		BACC45FT22-55S9 PLUG-P19	81205	1	33-22-21 AP0401/ /	275-299
D04292 V		-10302 I.D. TAPE - TEXT AS BELOW	81205	1	30-41-11 AE0305/ /	150-154, 275-276
D04292J		BACC45FN22-32S9 RCPT-E1-2	81205	1	30-41-11 AE0305/ /	ALL
D04292P		BACC45FT22A32P9 PLUG-E1-2	81205	1	30-41-11 AE0305/ /	ALL
D04293J		BACC45FN10A5S8 RCPT-E1-6	81205	1	34-21-31 AE0307/ /	ALL
D04293P		BACC45FT10A5P8 PLUG-E1-6	81205	1	34-21-31 AE0307/ /	ALL
D04294 U		-10201 I.D. TAPE - TEXT AS BELOW	81205	1	30-41-12 AE0320/ /	150-154, 275-276
D04294J		BACC45FN22-32P7 RCPT-E2-1	81205	1	30-41-12 AE0320/ /	ALL
D04294P		BACC45FT22A32S7 PLUG-E2-1	81205	1	30-41-12 AE0320/ /	ALL
D04296J		BACC45FN24-57S9 RCPT-P37	81205	1	28-22-11 AE0218/ /	ALL

EQUIPMENT LIST

D280T132

Section D04200

Page 12

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04296P		BACC45FT24-57P9 PLUG-P37	81205	1	30-41-12 AE0218/ /	ALL

EQUIPMENT LIST

D280T132

Section D04200
Page 13 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04300J		BACC45FM22C19S7 RCPT-	81205	1	32-42-11 AL1002/ /	ALL
D04300P		BACC63BP22R19P7L PLUG-R WING/BODY RS DISC	81205	1	32-42-11 AL1002/ /	ALL
D04300PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	ALL
D04301J		BACC45FN16-24P7 RCPT-P51	81205	1	27-32-11 AE0208/ /	050-099, 150-199
D04301J		BACC45FN12-12P7 RCPT-P51	81205	1	27-32-11 AE0208/ /	275-299
D04301P		BACC45FT16-24S7 PLUG-P51	81205	1	27-32-11 AE0208/ /	050-099, 150-199
D04301P		BACC45FT12-12S7 PLUG-P51	81205	1	27-32-11 AE0208/ /	275-299
D04302J		BACC45FM22C19S8 RCPT-	81205	1	30-21-11 AL1001/ /	ALL
D04302P		BACC63BP22R19P8L PLUG-	81205	1	32-42-11 AL1001/ /	ALL
D04302PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	ALL
D04303J		BACC45FN12-12P8 RCPT-P51	81205	1	31-51-21 AE0208/ /	ALL
D04303P		BACC45FT12-12S8 PLUG-P51	81205	1	22-14-21 AE0208/ /	ALL
D04304J		BACC45FN20-28S RCPT-P35	81205	1	33-31-61 AC0506/ /	ALL
D04304P		BACC45FT20-28P PLUG-P35	81205	1	33-37-11 AC0506/ /	ALL
D04305J		BACC45FN18-31P8 RCPT-E1-4	81205	1	22-14-11 AE0307/ /	050-099
D04305J		BACC45FN16-24P8 RCPT-E1-4	81205	1	22-14-11 AE0307/ /	150-199
D04305J		BACC45FN12-12P8 RCPT-E1-4	81205	1	22-14-11 AE0307/ /	275-299

EQUIPMENT LIST

D280T132

Section D04300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04305P		BACC45FT18A31S8 PLUG-E1-4	81205	1	22-14-11 AE0307/ /	050-099
D04305P		BACC45FT16A24S8 PLUG-E1-4	81205	1	22-14-11 AE0307/ /	150-199
D04305P		BACC45FT12A12S8 PLUG-E1-4	81205	1	22-14-11 AE0307/ /	275-299
D04306J		BACC45FN16B24S RCPT-	81205	1	52-34-13 0480/190/R080	ALL
D04306P		BACC45FT16-24P PLUG-	81205	1	52-34-11 0479/191/R081	ALL
D04309J		BACC45FN12-12P6 RCPT-E1-3	81205	1	34-12-11 AE0319/ /	ALL
D04309P		BACC45FT12A12S6 PLUG-E1-3	81205	1	34-12-11 AE0319/ /	ALL
D04312J		BACC45FN20-39S RCPT-P39	81205	1	33-31-61 AC1304/ /	ALL
D04312P		BACC45FT20-39P PLUG-P39	81205	1	33-37-21 AC1304/ /	ALL
D04314J		BACC45FN16A24P RCPT-	81205	1	52-35-13 DR 216/180/R087	ALL
D04314P		BACC45FT16-24S PLUG-	81205	1	52-35-13 DR 216/180/R087	ALL
D04316J		BACC45FM18C14S7 RCPT-	81205	1	29-21-31 AL1008/ /	ALL
D04316P		BACC63BP18R14P7L PLUG-	81205	1	29-21-31 AL1008/ /	ALL
D04316PQ		BACC10KD18 CLAMP-	81205	1	29-21-31 / /	ALL
D04317J		BACC45FN12-12P8 RCPT-	81205	1	34-12-21 AE0322/ /	ALL
D04317P		BACC45FT12A12S8 PLUG-E2-3	81205	1	34-12-21 AE0322/ /	ALL
D04318J		BACC45FM22C19S8 RCPT-	81205	1	28-42-11 AL1001/ /	ALL

EQUIPMENT LIST

D280T132

Section D04300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04318P		BACC63BP22R19P8L PLUG-L WING/BODY RS DISC	81205	1	32-42-11 AL1001/ /	ALL
D04318PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	ALL
D04320J		BACC45FN14-3P9 RCPT-E2-4	81205	1	28-41-23 AE0307/ /	ALL
D04320JK	1	S2407-12-9 ADP	07418	1	28-41-23 / /	ALL
D04320JK	2	MS27291-3 ADP	81205	1	28-41-23 / /	ALL
D04320P		BACC45FT14C3S9 PLUG-E2-4	81205	1	28-41-23 AE0307/ /	ALL
D04321J		BACC45FN10-5S RCPT-P3	81205	1	22-14-21 AF0120/ /	ALL
D04321P		BACC45FT10-5P PLUG-P3	81205	1	22-14-21 AF0120/ /	ALL
D04323J		BACC45FN14-15S8 RCPT-E1-3	81205	1	22-14-11 AE0305/ /	ALL
D04323P		BACC45FT14A15P8 PLUG-E1-3	81205	1	22-14-11 AE0305/ /	ALL
D04325J		BACC45FN16-24P8 RCPT-E1-5	81205	1	27-32-11 AE0317/ /	ALL
D04325P		BACC45FT16A24S8 PLUG-E1-5	81205	1	27-32-11 AE0317/ /	ALL
D04326J		BACC45FN24-43S6 RCPT-P19	81205	1	25-24-11 AP0403/ /	050-099
D04326J		BACC45FN24-43S6 RCPT-	81205	1	25-24-11 AP0403/ /	150-199
D04326J		BACC45FN20-39S6 RCPT-	81205	1	25-24-11 AP0403/ /	275-299
D04326P		BACC45FT24-43P6 PLUG-P19	81205	1	33-26-11 AP0403/ /	050-099, 150-199
D04326P		BACC45FT20-39P6 PLUG-P19	81205	1	33-26-11 AP0403/ /	275-299

EQUIPMENT LIST

D280T132

Section D04300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04330J		BACC63BY24-22S RCPT-P33	81205	1	24-51-52 AE0203/ /	ALL
D04330P		BACC63BW24-22P PLUG-P33	81205	1	24-51-52 AE0203/ /	ALL
D04331J		BACC45FN18-31S7 RCPT E2-4 SHELF	81205	1	34-12-61 AE0307/ /	050-099
D04331J		BACC45FN18-31S7 RCPT E2-4 SHELF	81205	1	31-41-35 AE0307/ /	150-199, 275-299
D04331P		BACC45FT18A31P7 PLUG-E2-4	81205	1	21-31-21 AE0307/ /	050-099, 275-299
D04331P		BACC45FT18A31P7 PLUG-E2-4	81205	1	31-41-35 AE0307/ /	150-199
D04333J		BACC45FN16-24P6 RCPT-E1-4 SHELF	81205	1	34-12-61 AE0307/ /	ALL
D04333P		BACC45FT16A24S6 PLUG-E1-4	81205	1	22-11-32 AE0307/ /	ALL
D04337J		BACC45FN18-31P9 RCPT-E1-3	81205	1	22-11-11 AE0319/ /	050-099, 150-199
D04337P		BACC45FT18A31S9 PLUG-E1-3	81205	1	22-11-11 AE0319/ /	050-099, 150-199
D04338J		BACC45FN18-31S RCPT-P36	81205	1	30-21-11 AE0209/ /	ALL
D04338P		BACC45FT18-31P PLUG-P36	81205	1	30-21-11 AE0209/ /	ALL
D04339J		BACC45FN16-24S9 RCPT-E2-3	81205	1	22-41-11 AE0320/ /	ALL
D04339P		BACC45FT16A24P9 PLUG-E2-3	81205	1	22-41-11 AE0320/ /	ALL
D04340J		BACC45FN18-31S8 RCPT-P37	81205	1	30-11-11 AE0218/ /	ALL
D04340P		BACC45FT18-31P8 PLUG-P37	81205	1	30-21-11 AE0218/ /	ALL
D04342J		BACC63BV24F30S6 RCPT-L WING/STRUT	81205	1	24-11-11 AW0319/ /	ALL

EQUIPMENT LIST

D280T132

Section D04300

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04342JK		BACC10KD24 CLAMP-	81205	1	24-11-11 / /	ALL
D04342P		BACC63BP24A30P6L PLUG-L WING/STRUT	81205	1	24-11-11 AW0319/ /	050-099, 150-199, 275-278
D04342PQ		BACC10KD24 CLAMP-	81205	1	24-11-11 / /	050-099, 150-199, 275-278
D04343J		BACC45FN20-41P8 RCPT-E2-3	81205	1	31-31-20 AE0307/ /	ALL
D04343P		BACC45FT20A41S8 PLUG-E2-3	81205	1	31-35-13 AE0307/ /	ALL
D04344J		BACC63BV24F30S6 RCPT-R WING/STRUT	81205	1	24-11-21 AW0320/ /	ALL
D04344JK		BACC10KD24 CLAMP-	81205	1	24-11-21 / /	ALL
D04344P		BACC63BP24A30P6L PLUG-R WING/STRUT	81205	1	24-11-21 AW0320/ /	050-099, 150-166, 275-299
D04344PQ		BACC10KD24 CLAMP-	81205	1	24-11-21 / /	050-099, 150-166, 275-299
D04345J		BACC45FN18-31P7 RCPT-E1-5	81205	1	22-11-21 AE0319/ /	050-099, 275-299
D04345J		BACC45FN12-12P7 RCPT-E1-5	81205	1	22-11-21 AE0319/ /	150-199
D04345P		BACC45FT18A31S7 PLUG-E1-5	81205	1	22-11-21 AE0319/ /	050-099, 275-299
D04345P		BACC45FT12A12S7 PLUG-E1-5	81205	1	22-11-21 AE0319/ /	150-199
D04346J		BACC45FN22-55S RCPT-P37	81205	1	32-41-11 AE0218/ /	ALL
D04346P		BACC45FT22-55P PLUG-	81205	1	32-41-11 AE0218/ /	ALL
D04347J		BACC45FN24-61P RCPT-P51	81205	1	27-32-11 AE0208/ /	ALL
D04347P		BACC45FT24-61S PLUG-P51 WARNING ELEX UNIT	81205	1	27-32-11 AE0208/ /	050-099

EQUIPMENT LIST

D280T132

Section D04300

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04347P		BACC45FT24A61S PLUG-P51 WARNING ELEX UNIT	81205	1	27-32-11 AE0208/ /	150-199, 275-299
D04349J		BACC45FN24-61P6 RCPT-P51	81205	1	27-32-11 AE0208/ /	ALL
D04349P		BACC45FT24A61S6 PLUG-P51 WARNING ELEX UNIT	81205	1	27-32-11 AE0208/ /	ALL
D04351J		BACC45FN16-24S RCPT-E1-3	81205	1	22-13-11 AE0305/ /	ALL
D04351P		BACC45FT16A24P PLUG-E1-3	81205	1	22-13-11 AE0305/ /	ALL
D04353J		BACC45FN20-41P9 RCPT-E1-1	81205	1	22-21-11 AE0303/ /	ALL
D04353P		BACC45FT20A41S9 PLUG-E1-1	81205	1	22-21-11 AE0303/ /	ALL
D04355J		BACC45FN22-55P RCPT-E1-4	81205	1	22-22-11 AE0307/ /	050-099, 150-199
D04355J		BACC45FN16-24P9 RCPT-E1-4	81205	1	22-22-11 AE0307/ /	275-299
D04355P		BACC45FT22A55S PLUG-E1-4	81205	1	22-11-31 AE0307/ /	050-099, 150-199
D04355P		BACC45FT16A24S9 PLUG-E1-4	81205	1	22-11-31 AE0307/ /	275-299
D04357J		BACC45FN20-41P RCPT-E1-1	81205	1	22-22-11 AE0303/ /	050-099, 150-199
D04357J		BACC45FN16-24P RCPT-E1-1	81205	1	22-22-11 AE0303/ /	275-299
D04357P		BACC45FT20A41S PLUG-E1-1	81205	1	22-22-11 AE0303/ /	050-099, 150-199
D04357P		BACC45FT16A24S PLUG-E1-1	81205	1	22-22-11 AE0303/ /	275-299
D04361J		BACC45FN18-31S RCPT-E1-5	81205	1	22-21-21 AE0317/ /	ALL
D04361P		BACC45FT18A31P PLUG-E1-5	81205	1	22-21-21 AE0317/ /	ALL

EQUIPMENT LIST

D280T132

Section D04300

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04363J		BACC45FN22-55P6 RCPT-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D04363P		BACC45FT22A55S6 PLUG-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D04365J		BACC45FN22-55P7 RCPT-	81205	1	22-11-12 AE0319/ /	ALL
D04365P		BACC45FT22A55S7 PLUG-E1-3	81205	1	22-11-12 AE0319/ /	ALL
D04367J		BACC45FN20-41P6 RCPT-E1-3	81205	1	22-32-12 AE0319/ /	ALL
D04367P		BACC45FT20A41S6 PLUG-E1-3	81205	1	22-32-12 AE0319/ /	ALL
D04369J		BACC45FN18-31P9 RCPT-	81205	1	22-11-22 AE0319/ /	ALL
D04369P		BACC45FT18A31S9 PLUG-E1-5	81205	1	22-11-22 AE0319/ /	ALL
D04371J		BACC45FN22-55P RCPT-E1-2	81205	1	34-22-35 AE0319/ /	ALL
D04371P		BACC45FT22A55S PLUG-	81205	1	34-22-35 AE0319/ /	ALL
D04373J		BACC45FN18-31P9 RCPT-E2-2	81205	1	34-55-11 AE0306/ /	ALL
D04373P		BACC45FT18A31S9 PLUG-E2-2	81205	1	34-51-11 AE0306/ /	ALL
D04377J		BACC45FN18-31P6 RCPT-E2-3	81205	1	34-51-21 AE0320/ /	ALL
D04377P		BACC45FT18A31S6 PLUG-E2-3	81205	1	34-51-21 AE0320/ /	ALL
D04378J		BACC63BV24R30PN RCPT-R WING OUTBD RIB SEAL	81205	1	27-88-22 AW0404/ /	ALL
D04378JK		BACC10HF24 CLAMP-	81205	1	27-88-22 / /	ALL
D04378P		BACC63BP24R30SNL PLUG-R WING OUTBD RIB SEAL	81205	1	27-88-22 AW0404/ /	ALL

EQUIPMENT LIST

D280T132

Section D04300

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04378PQ		BACC10KE24 CLAMP-90 DEGREE	81205	1	27-88-22 / /	ALL
D04379J		BACC45FN22-55S6 RCPT-E1-3 AFDS-L	81205	1	22-11-11 AE0305/ /	ALL
D04379P		BACC45FT22A55P6 PLUG-E1-3	81205	1	22-11-11 AE0305/ /	ALL
D04380J		BACC45FM14C7P6 RCPT-R WING FS/OUTBD RIB SEAL	81205	1	30-11-11 AW0404/ /	ALL
D04380P		BACC63BP14A7S6L PLUG-R WING FS/OUTBD RIB SEAL	81205	1	29-11-21 AW0404/ /	ALL
D04380PQ		BACC10KD14 CLAMP-	81205	1	29-11-21 AW0404/ /	050-099, 150-199
D04380PQ		BACC10KD14 CLAMP-	81205	1	29-11-21 / /	275-299
D04381J		BACC45FN20-41S7 RCPT-E1-4	81205	1	22-11-31 AE0307/ /	ALL
D04381P		BACC45FT20A41P7 PLUG-E1-4	81205	1	22-11-31 AE0307/ /	ALL
D04383J		BACC45FN18-31P6 RCPT-E1-3	81205	1	22-11-11 AE0305/ /	ALL
D04383P		BACC45FT18A31S6 PLUG-E1-3	81205	1	22-11-11 AE0305/ /	ALL
D04385J		BACC45FN22-55S6 RCPT-E1-5	81205	1	22-11-21 AE0317/ /	ALL
D04385P		BACC45FT22A55P6 PLUG-E1-5	81205	1	22-11-21 AE0317/ /	ALL
D04387J		BACC45FN22-55P7 RCPT-E1-4	81205	1	34-22-35 AE0319/ /	ALL
D04387P		BACC45FT22A55S7 PLUG-E1-4	81205	1	34-22-35 AE0319/ /	ALL
D04391J		BACC45FN22-55S7 RCPT-P3	81205	1	22-14-21 AF0120/ /	ALL
D04391P		BACC45FT22-55P7 PLUG-P3	81205	1	22-14-21 AF0120/ /	ALL

EQUIPMENT LIST

D280T132

Section D04300

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04393J		BACC45FN22-55P9 RCPT-E1-5	81205	1	22-14-21 AE0317/ /	ALL
D04393P		BACC45FT22A55S9 PLUG-E1-5	81205	1	22-14-21 AE0317/ /	ALL
D04397J		BACC45FN10-5S RCPT-	81205	1	23-42-11 AP0301B/ /	050-099
D04397J		BACC45FN10-5S RCPT	81205	1	23-34-13 AP0301B/ /	150-199
D04397P		BACC45FT10-5P PLUG-	81205	1	23-42-11 AP0301B/ /	050-099
D04397P		BACC45FT10-5P PLUG-	81205	1	23-42-11 AP0301/ /	150-199
D04398J		BACC45FN14-7S7 RCPT-L WING FS/BODY	81205	1	24-11-11 AC0701/ /	ALL
D04398P		BACC45FT14-7P7 PLUG-L WING FS/BODY	81205	1	24-21-11 AC0701/ /	ALL

EQUIPMENT LIST

D280T132

Section D04300

Page 9 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04400J		BACC45FN14-7S6 RCPT-R WING FS/BODY	81205	1	24-11-21 AC0702/ /	050-099, 150-154, 162-163, 275-276
D04400J		BACC45FN14-7S6 RCPT-R WING FS/BODY	81205	1	24-11-21 785/181/R68	155-157, 164-199, 277-299
D04400P		BACC45FT14-7P6 PLUG-R WING FS/BODY	81205	1	24-11-21 AC0702/ /	050-099, 150-154, 162-163, 275-276
D04400P		BACC45FT14-7P6 PLUG-	81205	1	24-11-21 785/181/R 68	155-157, 164-199, 277-299
D04402J		BACC45FM18C14S RCPT-L WING RS/BODY	81205	1	27-13-11 AL1007/ /	ALL
D04402P		BACC63BP18R14PNL PLUG-L WING RS/BODY	81205	1	27-13-11 AL1007/ /	ALL
D04402PQ		BACC10KD18 CLAMP-	81205	1	27-13-11 / /	ALL
D04404J		BACC45FM12C3P RCPT-L WING/SAILBOAT	81205	1	29-11-11 AW0321/ /	ALL
D04404P		BACC63BP12A3SNL PLUG-L WING/SAILBOAT	81205	1	29-11-11 AW0321/ /	ALL
D04404PQ		BACC10KD12 CLAMP-	81205	1	29-11-11 AW0321/ /	ALL
D04405J		BACC45FN16-24S8 RCPT-E1-4	81205	1	22-11-31 AE0307/ /	ALL
D04405P		BACC45FT16A24P8 PLUG-E1-4	81205	1	22-11-31 AE0307/ /	ALL
D04406J		BACC45FM12C3P RCPT-R WING/SAILBOAT	81205	1	29-11-21 AW0322/ /	ALL
D04406P		BACC63BP12A3SNL PLUG-R WING/SAILBOAT	81205	1	29-11-21 AW0322/ /	ALL
D04406PQ		BACC10KD12 CLAMP-	81205	1	29-11-11 AW0322/ /	ALL
D04408J		BACC45FM18C14S RCPT-	81205	1	28-22-11 AL1003/ /	ALL
D04408P		BACC63BP18A14PNL PLUG-L WING RS/BODY	81205	1	28-22-11 AL1003/ /	ALL

EQUIPMENT LIST

D280T132

Section D04400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04408PQ		BACC10KD18 CLAMP-	81205	1	28-22-11 / /	ALL
D04409J		BACC45FN14-15P6 RCPT-E1-4	81205	1	34-31-31 AE0319/ /	ALL
D04409P		BACC45FT14A15S6 PLUG-E1-4	81205	1	34-31-31 AE0319/ /	ALL
D04410J		BACC45FM14C7S RCPT-	81205	1	28-22-11 AL1004/ /	ALL
D04410P		BACC63BP14A7PNL PLUG-R WING RS/BODY	81205	1	28-22-11 AL1004/ /	ALL
D04410PQ		BACC10KD14 CLAMP-	81205	1	28-22-11 / /	ALL
D04412J		BACC45FN14-7P RCPT-P37	81205	1	27-81-11 AE0224/ /	ALL
D04412P		BACC45FT14-7S PLUG-P37	81205	1	27-81-11 AE0224/ /	ALL
D04414J		BACC45FM18C14S9 RCPT-	81205	1	28-41-21 AL1001/ /	ALL
D04414P		BACC63BP18A14P9L PLUG-L WING RS/BODY	81205	1	28-41-21 AL1001/ /	ALL
D04414PQ		BACC10KD18 CLAMP-	81205	1	28-41-21 / /	ALL
D04415J		BACC45FN16-24P6 RCPT-E5-1	81205	1	34-33-11 AC0604/ /	ALL
D04415P		BACC45FT16A24S6 PLUG-E5-1	81205	1	34-33-11 AC0604/ /	ALL
D04416J		BACC45FM22C19S8 RCPT-R WING RS/BODY	81205	1	27-51-41 AL1002/ /	ALL
D04416P		BACC63BP22A19P8L PLUG-R WING RS/BODY	81205	1	27-51-41 AL1002/ /	ALL
D04416PQ		BACC10KD22 CLAMP-	81205	1	27-51-41 / /	ALL
D04417J		BACC45FN16-24P6 RCPT-E1-3	81205	1	22-12-11 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D04400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04417P		BACC45FT16A24S6 PLUG-E1-3	81205	1	22-12-11 AE0305/ /	ALL
D04418J		BACC45FM22C19S8 RCPT-	81205	1	28-41-23 AL1002/ /	ALL
D04418P		BACC63BP22A19P8L PLUG-R WING RS/BODY	81205	1	28-41-22 AL1002/ /	ALL
D04418PQ		BACC10KD22 CLAMP-	81205	1	28-41-22 / /	ALL
D04419J		BACC45FN12-12P7 RCPT-E5-1	81205	1	22-12-31 AC0604/ /	ALL
D04419P		BACC45FT12A12S7 PLUG-E5-1	81205	1	22-12-31 AC0604/ /	ALL
D04420J		BACC45FN14-7S7 RCPT-L WING FS/BODY	81205	1	27-81-21 AC0701/ /	ALL
D04420P		BACC45FT14-7P7 PLUG-L WING FS/BODY	81205	1	27-81-21 AC0701/ /	ALL
D04421J		BACC45FN12-12S9 RCPT-E1-4	81205	1	22-12-31 AE0307/ /	ALL
D04421P		BACC45FT12A12P9 PLUG-E1-4	81205	1	22-12-31 AE0307/ /	ALL
D04422J		BACC45FN14-7S6 RCPT-R WING FS/BODY	81205	1	27-81-11 AC0702/ /	ALL
D04422P		BACC45FT14-7P6 PLUG-R WING FS/BODY	81205	1	27-81-11 AC0702/ /	ALL
D04423J		BACC45FN16-24P6 RCPT-E5-1	81205	1	22-12-21 AC0604/ /	ALL
D04423P		BACC45FT16A24S6 PLUG-E5-1	81205	1	22-12-21 AC0604/ /	ALL
D04426J		BACC45FM14C4S RCPT-RH WING TIP ASSY	81205	1	33-43-11 AW0902/ /	ALL
D04426P		BACC63BP14R4PNL PLUG-R WING TIP	81205	1	33-43-11 AW0902/ /	ALL
D04426PQ		BACC10KD14 CLAMP-	81205	1	33-43-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D04400

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04428J		BACC45FM14C4S6 RCPT-RH WING TIP ASSY	81205	1	33-43-11 AW0902/ /	ALL
D04428P		BACC63BP14R4P6L PLUG-R WING TIP	81205	1	33-43-11 AW0902/ /	ALL
D04428PQ		BACC10KD14 CLAMP-	81205	1	33-43-11 / /	ALL
D04429J		BACC45FN16-24S8 RCPT-E2-2	81205	1	34-61-11 AE0306/ /	ALL
D04429P		BACC45FT16A24P8 PLUG-E2-2	81205	1	34-61-11 AE0306/ /	ALL
D04430J		BACC45FM14C4S RCPT-LH WING TIP ASSY	81205	1	33-43-11 AW0901/ /	ALL
D04430P		BACC63BP14R4PNL PLUG-L WING TIP	81205	1	33-43-11 AW0901/ /	ALL
D04430PQ		BACC10KD14 CLAMP-	81205	1	33-43-11 / /	ALL
D04432J		BACC45FM14C4S6 RCPT-LH WING TIP ASSY	81205	1	33-43-11 AW0901/ /	ALL
D04432P		BACC63BP14R4P6L PLUG-L WING TIP	81205	1	33-43-11 AW0901/ /	ALL
D04432PQ		BACC10KD14 CLAMP-	81205	1	33-43-11 / /	ALL
D04433J		BACC45FN16-24P7 RCPT-FMC R,CDU	81205	1	34-61-21 AE0322/ /	ALL
D04433P		BACC45FT16A24S7 PLUG-E2-3	81205	1	34-61-21 AE0322/ /	ALL
D04434J		BACC63BV24R30P6 RCPT-L WING OUTBD RIB SEAL	81205	1	27-88-12 AW0403/ /	ALL
D04434JK		BACC10HF24 CLAMP	81205	1	27-88-12 / /	ALL
D04434P		BACC63BP24A30S6L PLUG-L WING OUTBD RIB SEAL	81205	1	27-88-12 AW0403/ /	ALL
D04434PQ		BACC10KE24 CLAMP-	81205	1	27-88-12 / /	ALL

EQUIPMENT LIST

D280T132

Section D04400

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04438J		BACC45FM14C7P RCPT-L WING FS/OUTBD RIB SEAL	81205	1	30-11-11 AW0403/ /	ALL
D04438P		BACC63BP14R7SNL PLUG-L WING OUTBD RIB SEAL	81205	1	30-11-11 AW0403/ /	ALL
D04438PQ		BACC10KD14 CLAMP-	81205	1	30-11-11 / /	ALL
D04442J		BACC63BV24A30PN RCPT-L WING FS/OUTBD RIB SEAL	81205	1	28-21-11 AW0403/ /	ALL
D04442JK		BACC10KE24 CLAMP-	81205	1	28-21-11 / /	ALL
D04442P		BACC63BP24A30SNL PLUG-OUTBD RIB SEAL DISC	81205	1	28-21-11 AW0403/ /	ALL
D04442PQ		BACC10KD24 CLAMP-	81205	1	28-21-11 / /	ALL
D04444J		BACC63BV24A30P6 RCPT-L WING FS/OUTBD RIB SEAL	81205	1	28-21-11 AW0403/ /	ALL
D04444JK		BACC10KE24 CLAMP-	81205	1	28-21-11 / /	ALL
D04444P		BACC63BP24A30S6L PLUG-OUTBD RIB SEAL DISC	81205	1	26-11-11 AW0403/ /	ALL
D04444PQ		BACC10KD24 CLAMP-	81205	1	26-11-11 / /	ALL
D04445J		BACC45FN16-24S8 RCPT-E2-2	81205	1	34-61-14 AE0306/ /	ALL
D04445P		BACC45FT16A24P8 PLUG-E2-2	81205	1	34-61-14 AE0306/ /	ALL
D04447J		BACC45FN16-24S RCPT-E1-5	81205	1	31-35-13 AE0317/ /	ALL
D04447P		BACC45FT16A24P PLUG-E1-5	81205	1	31-31-19 AE0317/ /	ALL
D04448J		BACC45FN16-24S6 RCPT-E2-4	81205	1	28-41-21 AE0306/ /	ALL
D04448P		BACC45FT16A24P6 PLUG-E2-4	81205	1	28-41-21 AE0306/ /	ALL

EQUIPMENT LIST

D280T132

Section D04400

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04449J		BACC45FN16-24P7 RCPT-E2-3	81205	1	31-35-13 AE0320/ /	ALL
D04449P		BACC45FT16A24S7 PLUG-E2-3	81205	1	31-31-19 AE0320/ /	ALL
D04455J		BACC45FN16-24P9 RCPT-E1-5	81205	1	22-32-11 AE0317/ /	ALL
D04455P		BACC45FT16A24S9 PLUG-E1-5	81205	1	22-32-11 AE0317/ /	ALL
D04457J		BACC45FN22-55S RCPT-E1-3	81205	1	22-14-31 AE0305/ /	ALL
D04457P		BACC45FT22A55P PLUG-E1-3	81205	1	22-14-31 AE0305/ /	ALL
D04466J		BACC45FN14-3P7 RCPT-	81205	1	28-41-21 AE0306/ /	ALL
D04466JK	1	S2407-12-9 CLAMP	07418	1	28-41-21 / /	ALL
D04466JK	2	MS27291-3 CLAMP	96906	1	28-41-21 / /	ALL
D04466P		BACC45FT14C3S7 PLUG-E2-4	81205	1	28-41-21 AE0306/ /	ALL
D04473J		BACC45FN14-15P RCPT-	81205	1	22-11-21 AP1501/ /	ALL
D04473P		BACC45FT14-15S PLUG-	81205	1	22-11-21 AP1501/ /	ALL
D04474J		BACC45FM22C19P6 RCPT-L WING/SAILBOAT	81205	1	78-34-11 AW0321/ /	ALL
D04474P		BACC63BP22A19S6L PLUG-L WING/SAILBOAT	81205	1	78-34-11 AW0321/ /	ALL
D04474PQ		BACC10KD22 CLAMP-	81205	1	78-34-11 / /	ALL
D04475J		BACC45FN16-24P9 RCPT-	81205	1	22-11-11 AP1501/ /	ALL
D04475P		BACC45FT16-24S9 PLUG	81205	1	22-11-11 AP1501/ /	ALL

EQUIPMENT LIST

D280T132

Section D04400

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04477J		BACC45FN12-12P RCPT-	81205	1	27-41-11 AP1501/ /	ALL
D04477P		BACC45FT12-12S PLUG-	81205	1	27-41-11 AP1501/ /	ALL
D04479J		BACC45FN12-12P6 RCPT-	81205	1	27-41-21 AP1501/310/0	050-099, 155-199, 275-299
D04479J		BACC45FN12-12P6 RCPT-	81205	1	27-41-21 AP1501/ /	150-154
D04479P		BACC45FT12-12S6 PLUG-	81205	1	27-41-21 AP1501/ /	ALL
D04481J		BACC45FN14-15P8 RCPT-	81205	1	22-11-31 AP1501/ /	ALL
D04481P		BACC45FT14-15S8 PLUG-	81205	1	22-11-31 AP1501/ /	ALL
D04482J		BACC63CC22-55S8 RCPT-L WING FS/BODY	81205	1	79-31-11 AC0701/ /	050-099
D04482J		BACC63CC22-55S8 RCPT-L WING FS/BODY	81205	1	78-36-11 AC0701/ /	150-199, 275-299
D04482JK		BACC10KD22 BACKSHELL-CLAMP	81205	1	77-21-11 / /	050-099
D04482JK		BACC10KD22 CLAMP	81205	1	78-36-11 AC0701/ /	150-199, 275-299
D04482P		BACC63CB22-55P8 PLUG-L WING FS/BODY	81205	1	78-36-11 AC0701/ /	ALL
D04482PQ		BACC10KD22 CLAMP	81205	1	78-36-11 / /	ALL
D04484J		BACC63CC22-55S7 RCPT-LH DISC PNL	81205	1	30-21-11 AC0701/ /	ALL
D04484P		BACC63CB22-55P7 PLUG-L WING FS/BODY	81205	1	36-23-11 AC0701/ /	ALL
D04484PQ		BACC10KD22 CLAMP	81205	1	36-23-11 AC0701/ /	ALL
D04484PR		-1101 MATE/WITH TAPE TEXT AS BELOW	85480	1	36-23-11 / /	050-099, 150-155, 162-165, 275-276

EQUIPMENT LIST

D280T132

Section D04400

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04486J		BACC63CC22-55SN RCPT-L WING FS/BODY	81205	1	27-88-12 AC0701/ /	050-099
D04486J		BACC63CC22-55SN RCPT-L WING FS/BODY	81205	1	77-12-12 AC0701/ /	150-199, 275-299
D04486JK		BACC10KD22 CLAMP	81205	1	27-88-12 AC0701/ /	050-099
D04486JK		BACC10KD22 CLAMP	81205	1	77-12-12 AC0701/ /	150-199, 275-299
D04486P		BACC63CB22-55PN PLUG-L WING FS/BODY	81205	1	27-88-12 AC0701/ /	ALL
D04486PQ		BACC10KD22 CLAMP	81205	1	27-88-12 / /	ALL
D04493J		BACC45FN18-31S RCPT-E5-3	81205	1	23-31-12 AC0608/ /	050-099, 150-154, 162-164

EQUIPMENT LIST

D280T132

Section D04400

Page 8 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04500J		BACC45FN22-55P9 RCPT-E3-1	81205	1	21-53-11 290/152/R58	050-099, 150-199
D04500J		BACC45FN22-55P9 RCPT-E3-1	81205	1	21-53-11 AE0220/ /	275-299
D04500P		BACC45FT22-55S9 PLUG-E3-1	81205	1	21-53-11 AE0220/ /	ALL
D04501J		BACC45FN12-12S7 RCPT-P1	81205	1	22-11-32 AF0119/ /	ALL
D04501P		BACC45FT12-12P7 PLUG-P1	81205	1	22-11-32 AF0119/ /	ALL
D04502J		BACC45FN18-31S6 RCPT-E3-1	81205	1	36-23-11 AE0220/ /	ALL
D04502P		BACC45FT18-31P6 PLUG-E3-1	81205	1	21-58-11 AE0220/ /	ALL
D04504J		BACC45FN22-55S8 RCPT-E3-1	81205	1	21-58-15 AE0220/ /	ALL
D04504P		BACC45FT22-55P8 PLUG-E3-1	81205	1	21-58-13 AE0220/ /	ALL
D04505J		BACC45FN22-55P9 RCPT-E2-3	81205	1	34-12-21 AE0322/ /	ALL
D04505P		BACC45FT22A55S9 PLUG-E2-3	81205	1	34-61-21 AE0322/ /	ALL
D04507J		BACC45FN12-12P9 RCPT-P51	81205	1	27-32-11 AE0208/ /	ALL
D04507P		BACC45FT12-12S9 PLUG-P51	81205	1	31-51-21 AE0208/ /	ALL
D04509J		BACC45FN14-15P RCPT-P51	81205	1	27-32-11 AE0208/ /	ALL
D04509P		BACC45FT14-15S PLUG-P51 WARN ELEX UNIT	81205	1	27-32-11 AE0208/ /	ALL
D04511J		BACC45FN18-31P6 RCPT-P51	81205	1	27-32-11 AE0208/ /	ALL
D04511P		BACC45FT18-31S6 PLUG-P51	81205	1	27-32-11 AE0208/ /	ALL

EQUIPMENT LIST

D280T132

Section D04500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04513J		BACC45FN16-24P7 RCPT-P1-3	81205	1	22-14-11 AF0113/ /	ALL
D04513JK		NEP-18 CAP-CONDUCTIVE (ESD PROTECTION)	ORN51	1	22-14-11 AF0113/ /	167-199, 278-299
D04513P		BACC45FT16A24S7 PLUG-P1-3	81205	1	22-14-11 AF0113/ /	ALL
D04515J		BACC45FN16-24P7 RCPT-P3-1	81205	1	33-16-15 AF0116/ /	ALL
D04515P		BACC45FT16A24S7 PLUG-P3-1	81205	1	33-16-15 AF0116/ /	ALL
D04517J		BACC45FN16-24S6 RCPT-E1-5	81205	1	34-22-28 AE0305/125/L38	ALL
D04517P		BACC45FT16A24P6 PLUG-E1-5	81205	1	34-22-28 AE0305/ /	ALL
D04519J		BACC45FN14-15P8 RCPT-	81205	1	22-11-11 AP1501/ /	ALL
D04519P		BACC45FT14-15S8 PLUG-	81205	1	22-11-11 AP1501/ /	ALL
D04523J		BACC45FN14-15P6 RCPT-	81205	1	22-11-31 AP1501/ /	ALL
D04523P		BACC45FT14-15S6 PLUG-	81205	1	22-11-31 AP1501/ /	ALL
D04524J		BACC63CC22-55S9 RCPT-L WING FS/BODY	81205	1	73-31-11 AC0701/ /	ALL
D04524JK		BACC10KD22 CLAMP	81205	1	79-32-11 / /	050-099
D04524JK		BACC10KD22 CLAMP	81205	1	73-31-11 AC0701/ /	150-199, 275-299
D04524P		BACC63CB22-55P9 PLUG-L WING FS/BODY	81205	1	71-51-11 AC0701/ /	ALL
D04524PQ		BACC10KD22 CLAMP	81205	1	71-51-11 AC0701/ /	ALL
D04525J		BACC45FN18-31S9 RCPT-E1-5	81205	1	22-41-11 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D04500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04525P		BACC45FT18A31P9 PLUG-E1-5	81205	1	34-46-11 AE0305/ /	ALL
D04527J		BACC45FN14-15P9 RCPT-	81205	1	22-11-21 AP1501/ /	ALL
D04527P		BACC45FT14-15S9 PLUG-	81205	1	22-11-21 AP1501/ /	ALL
D04528J		BACC63CC20-41S6 RCPT-L WING FS/BODY	81205	1	73-21-13 AC0701/ /	ALL
D04528JK		BACC10KD20 CLAMP-L WING FS/BODY	81205	1	73-21-13 AC0701/ /	050-099
D04528JK		BACC10KD20 CLAMP	81205	1	77-11-11 / /	150-199, 275-299
D04528P		BACC63CB20-41P6 PLUG-L WING FS/BODY	81205	1	73-21-11 AC0701/ /	ALL
D04528PQ		BACC10KD20 CLAMP	81205	1	73-21-11 AC0701/ /	ALL
D04529J		BACC45FN16-24S6 RCPT-E1-5	81205	1	22-11-22 AE0317/ /	ALL
D04529P		BACC45FT16A24P6 PLUG-E1-5	81205	1	22-11-21 AE0317/ /	ALL
D04531J		BACC45FN14-15P RCPT-	81205	1	22-11-11 AP1501/ /	ALL
D04531P		BACC45FT14-15S PLUG-	81205	1	27-41-11 AP1501/ /	ALL
D04532J		BACC45FN10-5S6 RCPT-L WING FS/BODY	81205	1	27-81-31 AC0701/ /	ALL
D04532P		BACC45FT10-5P6 PLUG-L WING FS/BODY	81205	1	27-81-31 AC0701/ /	ALL
D04533J		BACC45FN14-15P7 RCPT-	81205	1	22-11-21 AP1501/310/0	050-099, 155-199, 275-299
D04533J		BACC45FN14-15P7 RCPT-	81205	1	22-11-21 AP1501/ /	150-154
D04533P		BACC45FT14-15S7 PLUG-	81205	1	27-41-21 AP1501/ /	ALL

EQUIPMENT LIST

D280T132

Section D04500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04536J		BACC45FN18-31S RCPT-	81205	1	28-42-11 AC0701/ /	ALL
D04536P		BACC45FT18C31P PLUG-L WING FS/BODY	81205	1	29-11-12 AC0701/ /	ALL
D04538J		BACC45FM18C11S9 RCPT-	81205	1	28-41-22 AL1002/ /	ALL
D04538P		BACC63BP18A11P9L PLUG-R WING RS/BODY	81205	1	28-41-22 AL1002/ /	ALL
D04538PQ		BACC10KD18 CLAMP-	81205	1	28-41-22 / /	ALL
D04540J		BACC45FN24-61S8 RCPT-	81205	1	28-26-11 AC0701/ /	ALL
D04540P		BACC45FT24-61P8 PLUG-L WING FS/BODY	81205	1	28-21-11 AC0701/ /	ALL
D04541J		BACC45FN20-25S RCPT-P61	81205	1	22-11-32 AF0204/ /	ALL
D04541P		BACC45FT20-25P PLUG-P61	81205	1	22-11-32 AF0204/ /	ALL
D04542J		BACC45FN18-14S9 RCPT	81205	1	26-11-11 AC0701/ /	ALL
D04542P		BACC45FT18-14P9 PLUG-L WING FS/BODY	81205	1	26-11-11 AC0701/ /	ALL
D04543J		BACC45FN20-25S RCPT-E1-4	81205	1	22-11-32 AE0307/ /	ALL
D04543P		BACC45FT20A25P PLUG-E1-4	81205	1	22-11-32 AE0307/ /	ALL
D04545J		BACC45FN16-24S6 RCPT-E1-2	81205	1	34-22-18 AE0317/125/L13	050-099
D04545J		BACC45FN16-24S6 RCPT-	81205	1	34-22-18 AE0317/ /	150-199, 275-299
D04545P		BACC45FT16A24P6 PLUG-E1-2	81205	1	34-22-18 AE0317/ /	ALL
D04546J		BACC45FN16-10S RCPT-	81205	1	26-11-11 AC0701/ /	ALL

EQUIPMENT LIST

D280T132

Section D04500

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04546P		BACC45FT16-10P PLUG-L WING FRONT SPAR / BODY	81205	1	26-11-11 AC0701/ /	ALL
D04550J		BACC63CC16-24S6 RCPT-L WING FS/BODY	81205	1	24-11-11 AC0701/ /	ALL
D04550P		BACC63CB16-24P6 PLUG-L WING FS/BODY	81205	1	24-11-11 AC0701/ /	050-099
D04550P		BACC63CB16-24P6 PLUG-L WING FS/BODY	81205	1	79-34-11 AC0701/ /	150-199, 275-299
D04550PQ		BACC10KD16 CLAMP	81205	1	24-11-11 / /	050-099
D04550PQ		BACC10KD16 CLAMP	81205	1	79-34-11 AC0701/ /	150-199, 275-299
D04551J		BACC45FN16-24P RCPT-	81205	1	22-11-12 AE0102/ /	ALL
D04551P		BACC45FT16-24S PLUG-P10	81205	1	22-11-12 AE0102/ /	ALL
D04553J		BACC45FN12-12P6 RCPT-	81205	1	22-11-32 AE0104/ /	ALL
D04553P		BACC45FT12-12S6 PLUG-P10 QUADRANT STAND	81205	1	22-12-31 AE0104/ /	ALL
D04555J		BACC45FN12-12P RCPT-	81205	1	22-11-22 AE0104/ /	ALL
D04555P		BACC45FT12-12S PLUG-P10 QUADRANT STAND	81205	1	22-12-21 AE0104/ /	ALL
D04556J		BACC45FN16-24S RCPT-P3	81205	1	33-11-11 AF0120/ /	ALL
D04556P		BACC45FT16-24P PLUG-	81205	1	33-11-11 AF0120/ /	ALL
D04559J		BACC45FN16-24P9 RCPT-	81205	1	27-21-12 AP1501/ /	ALL
D04559P		BACC45FT16-24S9 PLUG-	81205	1	27-21-12 AP1501/ /	ALL
D04560J		BACC45FN16-24S6 RCPT-P3	81205	1	33-13-11 AF0120/ /	ALL

EQUIPMENT LIST

D280T132

Section D04500

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04560P		BACC45FT16-24P6 PLUG-	81205	1	33-16-13 AF0120/ /	ALL
D04565J		BACC45FN12-12P RCPT-E1-2	81205	1	27-58-21 AE0319/ /	ALL
D04565P		BACC45FT12A12S PLUG-E1-2	81205	1	27-58-21 AE0319/ /	ALL
D04567J		BACC45FN16-24P8 RCPT-	81205	1	27-21-22 AP1501/ /	ALL
D04567P		BACC45FT16-24S8 PLUG-	81205	1	27-21-22 AP1501/ /	ALL
D04571J		280T1000-18 RECP-MOA PER DWG REF BACC45FN20-28S8	81205	1	23-32-21 AE0317/ /	050-099
D04571J		280T1000-18 RECP-MOA PER DWG REF BACC45FN20-28S8	81205	1	23-32-21 AE0317/ /	150-199, 275-299
D04571P		280T1000-19 PLUG MOA PER DWG REF BACC45FT20-28P8	81205	1	23-32-21 AE0317/ /	ALL
D04571PQ		MS27291-14 CLAMP-	81205	1	23-32-21 / /	ALL
D04575J		BACC45FN12-12P7 RCPT-E5-1 ADF L	81205	1	34-57-11 AC0604/ /	ALL
D04575P		BACC45FT12A12S7 PLUG-E5-1	81205	1	34-57-11 AC0604/ /	ALL
D04576J		280T1002-1 RCPT-SHORTING	287T4103 81205	1	33-13-12 P002-00/ /	050-099
D04577J		BACC45FN12-12P6 RCPT-E5-1	81205	1	34-57-21 AC0604/ /	ALL
D04577P		BACC45FT12A12S6 PLUG-E5-1	81205	1	34-57-21 AC0604/ /	ALL
D04579J		BACC45FN12-12P8 RCPT-E5-1	81205	1	23-51-13 AC0604/ /	ALL
D04579P		BACC45FT12A12S8 PLUG-E5-1	81205	1	23-51-13 AC0604/ /	ALL
D04580J		280T1002-1 RCPT-SHORTING	233T2222 81205	1	33-16-14 P001-03/ /	ALL

EQUIPMENT LIST

D280T132

Section D04500

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04580P		BACC45FT22D55S PLUG-P1-3	81205	1	33-16-33 AF0113/ /	ALL
D04581J		BACC45FN12-12S8 RCPT-E2-5	81205	1	23-51-13 AE0306/ /	ALL
D04581P		BACC45FT12A12P8 PLUG-E2-5	81205	1	23-51-13 AE0306/ /	ALL
D04586J		280T1002-1 RCPT-SHORTING	233T2222 81205	1	33-16-14 P001-03/ /	ALL
D04586P		BACC45FT22D55S PLUG-P1-3	81205	1	33-16-13 AF0113/ /	ALL
D04590J		BACC63BV24R30S7 RCPT-L WING RS/BODY	81205	1	27-11-11 AL1001/ /	ALL
D04590JK		BACC10KD24 CLAMP-	81205	1	27-11-11 / /	ALL
D04590P		BACC63BP24A30P7L PLUG-L WING RS/BODY	81205	1	27-58-11 AL1001/ /	ALL
D04590PQ		BACC10KD24 CLAMP-	81205	1	27-58-11 / /	ALL
D04591J		BACC45FN18-31P RCPT-E1-3	81205	1	22-11-12 AE0319/ /	ALL
D04591P		BACC45FT18A31S PLUG-E1-3	81205	1	22-11-12 AE0319/ /	ALL
D04593J		BACC45FN12-12P9 RCPT-E1-4	81205	1	22-11-32 AE0319/ /	ALL
D04593P		BACC45FT12A12S9 PLUG-E1-4	81205	1	22-11-32 AE0319/ /	ALL
D04594J		BACC45FM22C19S7 RCPT-	81205	1	28-22-11 AL1001/ /	ALL
D04594P		BACC63BP22A19P7L PLUG-L WING RS/BODY	81205	1	28-41-21 AL1001/ /	ALL
D04594PQ		BACC10KD22 CLAMP-	81205	1	28-41-21 / /	ALL
D04595J		BACC45FN16-24P RCPT-E1-5	81205	1	22-11-22 AE0317/ /	ALL

EQUIPMENT LIST

D280T132

Section D04500

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04595P		BACC45FT16A24S PLUG-E1-5	81205	1	22-11-22 AE0317/ /	ALL
D04597J		BACC45FN14-15P7 RCPT-P51	81205	1	31-51-31 AE0208/ /	ALL
D04597P		BACC45FT14-15S7 PLUG-P51	81205	1	34-16-11 AE0208/ /	ALL
D04598J		BACC45FM22C19S7 RCPT-	81205	1	30-21-11 AL1003/ /	ALL
D04598P		BACC63BP22A19P7L PLUG-L WING RS/BODY	81205	1	32-42-11 AL1003/ /	ALL
D04598PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	ALL
D04599J		BACC45FN18-31P9 RCPT-E2-5	81205	1	23-71-11 AE0322/ /	ALL
D04599P		BACC45FT18A31S9 PLUG-E2-5	81205	1	23-71-11 AE0322/ /	ALL

EQUIPMENT LIST

D280T132

Section D04500

Page 8 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04600J		BACC45FM18C14S6 RCPT-L WING RS/BODY	81205	1	28-22-11 AL1003/ /	ALL
D04600P		BACC63BP18A14P6L PLUG-L WING RS/BODY	81205	1	28-22-11 AL1003/ /	ALL
D04600PQ		BACC10KD18 CLAMP-	81205	1	28-22-11 / /	ALL
D04601J		BACC45FN20-41S RCPT-E2-5	81205	1	23-51-11 AE0322/ /	ALL
D04601P		BACC45FT20A41P PLUG-E2-5	81205	1	23-51-11 AE0322/ /	ALL
D04602J		BACC45FM22C19S6 RCPT-	81205	1	28-21-21 AL1001/ /	ALL
D04602P		BACC63BP22A19P6L PLUG-L WING RS/BODY	81205	1	28-21-21 AL1001/ /	ALL
D04602PQ		BACC10KD22 CLAMP-	81205	1	28-21-21 / /	ALL
D04603J		BACC45FN20-41S6 RCPT-E2-5	81205	1	23-51-21 AE0322/ /	ALL
D04603P		BACC45FT20A41P6 PLUG-E2-5	81205	1	23-51-21 AE0322/ /	ALL
D04607J		BACC45FN20-41S7 RCPT-E2-5	81205	1	23-51-41 AE0322/ /	ALL
D04607P		BACC45FT20A41P7 PLUG-E2-5	81205	1	23-51-31 AE0322/ /	050-099
D04607P		BACC45FT20A41P7 PLUG-E2-5	81205	1	23-51-41 AE0322/ /	150-199, 275-299
D04610J		BACC63BV24R30S6 RCPT-L WING RS/BODY	81205	1	27-51-41 AL1001/ /	ALL
D04610JK		BACC10KD24 CLAMP-	81205	1	27-51-41 / /	ALL
D04610P		BACC63BP24A30P6L PLUG-L WING RS/BODY	81205	1	27-51-41 AL1001/ /	ALL
D04610PQ		BACC10KD24 CLAMP-	81205	1	27-51-41 / /	ALL

EQUIPMENT LIST

D280T132

Section D04600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04612J		BACC45FM18C14S9 RCPT-L WING RS/BODY	81205	1	27-51-41 AL1001/ /	ALL
D04612P		BACC63BP18A14P9L PLUG-L WING RS/BODY	81205	1	27-51-41 AL1001/ /	ALL
D04612PQ		BACC10KD18 CLAMP-	81205	1	27-51-41 / /	ALL
D04613J		BACC45FN14-15S8 RCPT-E2-5	81205	1	23-41-11 AE0307/ /	ALL
D04613P		BACC45FT14A15P8 PLUG-E2-5	81205	1	23-41-11 AE0307/ /	ALL
D04615J		BACC45FN14-15P6 RCPT-E2-5	81205	1	23-42-11 AE0307/ /	ALL
D04615P		BACC45FT14A15S6 PLUG-E2-5	81205	1	23-42-11 AE0307/ /	ALL
D04616J		BACC63CC22-55S9 RCPT-R WING FS/BODY	81205	1	74-31-21 AC0702/ /	ALL
D04616JK		BACC10KD22 CLAMP	81205	1	79-31-11 / /	050-099
D04616JK		BACC10KD22 CLAMP	81205	1	74-31-21 AC0702/ /	150-199, 275-299
D04616P		BACC63CB22-55P9 PLUG-R WING FS/BODY	81205	1	78-36-21 AC0702/ /	ALL
D04616PQ		BACC10KD22 CLAMP	81205	1	78-36-21 / /	ALL
D04620J		BACC45FN14-12S9 RCPT-	81205	1	21-43-11 AC0702/ /	ALL
D04620P		BACC45FT14-12P9 PLUG-	81205	1	21-43-11 AC0702/ /	ALL
D04622J		BACC63CC22-55S7 RCPT-R WING FS/BODY	81205	1	22-33-11 AC0702/ /	050-099
D04622J		BACC63CC22-55S7 RCPT-R WING FS/BODY	81205	1	73-14-11 AC0702/ /	150-199, 275-299
D04622JK		BACC10KD22 CLAMP	81205	1	79-32-11 / /	050-099

EQUIPMENT LIST

D280T132

Section D04600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04622JK		BACC10KD22 CLAMP	81205	1	73-14-11 AC0702/ /	150-199, 275-299
D04622P		BACC63CB22-55P7 PLUG-R WING FS/BODY	81205	1	34-12-22 AC0702/ /	ALL
D04622PQ		BACC10KD22 CLAMP	81205	1	34-12-22 AC0702/ /	050-099, 150-199
D04622PQ		BACC10KD22 CLAMP	81205	1	34-12-22 / /	275-299
D04624J		BACC63CC20-41S8 RCPT-R WING FS/BODY	81205	1	22-33-11 AC0702/ /	ALL
D04624JK		BACC10KD20 CLAMP-R WING FS/BODY	81205	1	22-33-11 AC0702/ /	050-099
D04624JK		BACC10KD20 CLAMP	81205	1	22-33-11 AC0702/ /	150-199, 275-299
D04624P		BACC63CB20-41P8 PLUG-R WING FS/BODY	81205	1	73-21-11 AC0702/ /	ALL
D04624PQ		BACC10KD20 CLAMP	81205	1	73-21-11 AC0702/ /	ALL
D04625J		BACC45FN22-55P8 RCPT E2-5	81205	1	23-31-12 AE0307/ /	ALL
D04625P		BACC45FT22A55S8 PLUG E2-5	81205	1	23-31-12 AE0307/ /	ALL
D04626J		BACC45FN12-12S8 RCPT-R WING FS/BODY	81205	1	27-81-31 AC0702/ /	ALL
D04626P		BACC45FT12-12P8 PLUG-R WING FS/BODY	81205	1	27-81-31 AC0702/ /	ALL
D04628J		BACC45FN18-31S6 RCPT-R WING FS/BODY	81205	1	27-88-22 AC0702/ /	ALL
D04628P		BACC45FT18-31P6 PLUG-R WING FS/BODY	81205	1	27-88-22 AC0702/ /	ALL
D04629J		BACC45FN16-24P9 RCPT-E2-5	81205	1	23-42-11 AE0307/ /	ALL
D04629P		BACC45FT16A24S9 PLUG-E2-5	81205	1	23-42-11 AE0307/ /	ALL

EQUIPMENT LIST

D280T132

Section D04600

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04630J		BACC63CC16-24S7 RCPT-R WING FS/BODY	81205	1	24-11-21 AC0702/ /	050-099, 150-154, 162-163, 275-276
D04630J		BACC63CC16-24S7 RCPT-R WING FS/BODY	81205	1	24-11-21 785/181/R68	155-157, 164-199, 277-299
D04630P		BACC63CB16-24P7 PLUG-R WING FS/BODY	81205	1	24-11-21 AC0702/ /	050-099
D04630P		BACC63CB16-24P7 PLUG-R WING FS/BODY	81205	1	79-34-11 AC0702/ /	150-154, 162-163, 275-276
D04630P		BACC63CB16-24P7 PLUG-	81205	1	79-34-11 785/181/R 68	155-157, 164-199, 277-299
D04630PQ		BACC10KD16 CLAMP	81205	1	24-11-21 AC0702/ /	050-099
D04630PQ		BACC10KD16 CLAMP	81205	1	79-34-11 AC0702/ /	150-154, 162-163, 275-276
D04630PQ		BACC10KD16 CLAMP	81205	1	79-34-11 785/181/R 68	155-157, 164-199, 277-299
D04632J		BACC63CC16-24SN RCPT-R WING FS/BODY	81205	1	80-11-21 AC0702/ /	050-099, 150-199
D04632J		BACC63CC16-24SN RCPT-R WING FS/BODY	81205	1	76-11-11 AC0702/ /	275-299
D04632JK		BACC10KD16 CLAMP	81205	1	80-11-21 / /	050-099
D04632P		BACC63CB16-24PN PLUG-R WING FS/BODY	81205	1	73-14-11 AC0702/ /	ALL
D04632PQ		BACC10KD16 CLAMP	81205	1	73-14-11 / /	ALL
D04633J		BACC45FN18-31P RCPT-E2-5	81205	1	23-71-11 AE0306/ /	ALL
D04633P		BACC45FT18A31S PLUG-E2-5	81205	1	23-71-11 AE0306/ /	ALL
D04634J		BACC63CC16-24S8 RCPT-L WING FS/BODY	81205	1	80-11-11 AC0701/ /	ALL
D04634JK		BACC10KD16 CLAMP	81205	1	80-11-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D04600

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04634P		BACC63CB16-24P8 PLUG-L WING FS/BODY	81205	1	73-14-11 AC0701/ /	050-099
D04634P		BACC63CB16-24P8 PLUG-L WING FS/BODY	81205	1	76-11-11 AC0701/ /	150-199, 275-299
D04634PQ		BACC10KD16 CLAMP	81205	1	73-14-11 / /	050-099
D04634PQ		BACC10KD16 CLAMP	81205	1	76-11-11 AC0701/ /	150-199, 275-299
D04636J		BACC45FN12-12S9 RCPT-	81205	1	21-43-11 AC0702/ /	ALL
D04636P		BACC45FT12-12P9 PLUG-	81205	1	21-43-11 AC0702/ /	ALL
D04638J		BACC45FN14C3P7 RCPT-E2-4	81205	1	28-41-22 AE0320/ /	ALL
D04638P		BACC45FT14C3S7 PLUG-E2-4	81205	1	28-41-22 AE0320/ /	ALL
D04644J		BACC45FN24-61S8 RCPT-P61	81205	1	21-51-11 AF0204/ /	ALL
D04644P		BACC45FT24-61P8 PLUG-P61	81205	1	26-17-11 AF0204/ /	ALL
D04646J		BACC45FN24-61P RCPT-P37	81205	1	21-61-11 AE0218/ /	ALL
D04646P		BACC45FT24-61S PLUG-P37	81205	1	21-61-31 AE0218/ /	ALL
D04647J		BACC45FN18-31P9 RCPT-E2-5	81205	1	23-31-14 AE0307/ /	050-099, 162-199
D04647J		BACC45FN16-24P9 RCPT-E2-5	81205	1	23-31-14 AE0307/ /	150-157, 275-299
D04647P		BACC45FT18A31S9 PLUG-E2-5	81205	1	23-31-14 AE0307/ /	050-099, 162-199
D04647P		BACC45FT16A24S9 PLUG-E2-5	81205	1	23-31-14 AE0307/ /	150-157, 275-299
D04650J		BACC45FN24-61S9 RCPT-P61	81205	1	21-51-21 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D04600

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04650P		BACC45FT24-61P9 PLUG-P61	81205	1	21-33-11 AF0204/ /	ALL
D04652J		BACC45FM18C14S7 RCPT-	81205	1	28-21-21 AL1006/ /	ALL
D04652P		BACC63BP18A14P7L PLUG-R WING RS/BODY	81205	1	28-22-21 AL1006/ /	ALL
D04652PQ		BACC10KD18 CLAMP-	81205	1	28-22-21 / /	ALL
D04653J		BACC45FN12-12P RCPT-E2-6	81205	1	23-11-11 AE0306/ /	ALL
D04653P		BACC45FT12A12S PLUG-E2-6	81205	1	23-11-11 AE0306/ /	ALL
D04654J		BACC63BV16A10S8 RCPT-	81205	1	28-42-11 AL1003/ /	ALL
D04654JK		BACC10KD16 CLAMP	81205	1	28-42-11 AL1003/ /	ALL
D04654P		BACC63BP16R10P8L PLUG-	81205	1	32-61-11 AL1003/ /	ALL
D04654PQ		BACC10KD16 CLAMP-	81205	1	32-61-11 / /	ALL
D04656J		BACC45FN20-41S8 RCPT-E1-1	81205	1	32-42-11 AE0317/ /	ALL
D04656P		BACC45FT20A41P8 PLUG-E1-1	81205	1	32-42-11 AE0317/ /	ALL
D04657J		BACC45FN12-12P9 RCPT-E2-6	81205	1	23-11-21 AE0322/ /	ALL
D04657P		BACC45FT12A12S9 PLUG-E2-6	81205	1	23-11-21 AE0322/ /	ALL
D04658J		BACC45FN20-39S7 RCPT-E1-2	81205	1	32-09-12 AE0317/ /	ALL
D04658P		BACC45FT20A39P7 PLUG-E1-2	81205	1	32-61-11 AE0317/ /	ALL
D04662J		BACC45FN22-55S6 RCPT-	81205	1	28-22-11 AE0223/ /	ALL

EQUIPMENT LIST

D280T132

Section D04600

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04662P		BACC45FT22-55P6 PLUG-P36	81205	1	28-22-11 AE0223/ /	ALL
D04667J		BACC45FN22-55S7 RCPT-E2-3	81205	1	34-12-22 AE0320/ /	ALL
D04667P		BACC45FT22A55P7 PLUG-E2-3	81205	1	34-61-24 AE0320/ /	ALL
D04669J		BACC45FN10-5S6 RCPT-MID CABIN PARTITION	81205	1	23-42-11 AP0802E/ /	050-099
D04669J		BACC45FN10-5S6 RCPT	81205	1	23-42-11 AP0901/ /	150-199
D04669J		BACC45FN10-5S6 RCPT-MID CABIN PARTITION	81205	1	23-42-11 AP0703/ /	275-299
D04669P		BACC45FT10-5P6 PLUG-	81205	1	23-42-11 AP0802E/ /	050-099
D04669P		BACC45FT10-5P6 PLUG-	81205	1	23-42-11 AP0901/ /	150-199
D04669P		BACC45FT10-5P6 PLUG-	81205	1	23-42-11 AP0703/ /	275-299
D04672J		BACC45FN24-61P RCPT-	81205	1	26-17-11 AE0209/ /	ALL
D04672P		BACC45FT24-61S PLUG-P36	81205	1	26-17-11 AE0209/ /	ALL
D04674J		BACC45FN12-12S8 RCPT-E1-1	81205	1	26-17-11 AE0305/ /	050-099
D04674J		BACC45FN14-15S8 RCPT-E1-1	81205	1	26-17-11 AE0305/ /	150-199, 275-299
D04674P		BACC45FT12A12P8 PLUG-E1-1	81205	1	32-42-11 AE0305/ /	050-099
D04674P		BACC45FT14A15P8 PLUG-E1-1	81205	1	32-42-11 AE0305/ /	150-199, 275-299
D04675J		BACC45FM18C14S RCPT-R WW FWD OUTBD	81205	1	22-11-31 AL1002/ /	ALL
D04675P		BACC63BP18R14PNL PLUG-R WW FWD OUTBD	81205	1	22-11-31 AL1002/ /	ALL

EQUIPMENT LIST

D280T132

Section D04600

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04675PQ		BACC10KD18 CLAMP-	81205	1	22-11-31 / /	ALL
D04676J		BACC45FN22-55S8 RCPT-E1-2	81205	1	26-17-11 AE0305/ /	ALL
D04676P		BACC45FT22A55P8 PLUG-E1-2	81205	1	21-58-11 AE0305/ /	ALL
D04677J		BACC45FM18C14S7 RCPT-L S FWD INBD PNL	81205	1	22-11-22 AL1003/ /	ALL
D04677P		BACC63BP18R14P7L PLUG-L WW FWD INBD	81205	1	22-11-21 AL1003/ /	ALL
D04677PQ		BACC10KD18 CLAMP-	81205	1	22-11-21 / /	ALL
D04679J		BACC45FN12-12P RECP-E2-3	81205	1	27-32-21 AE0320/ /	ALL
D04679P		BACC45FT12A12S PLUG-E2-3	81205	1	27-32-21 AEO320/ /	ALL
D04681 V		289T0126-11202 I.D. TAPE TEXT AS BELOW	81205	1	34-45-12 / /	275-276
D04681J		BACC45FN16-24S9 RECP-E2-2	81205	1	34-45-12 AE0306/ /	050-099, 150-152, 277-299
D04681J		BACC45FN16-24S9 RECP-E2-2	81205	1	31-36-11 AE0306/ /	153-154, 275-276
D04681J		BACC45FN16-24S9 RECP-E2-2	81205	1	34-45-12 355/125/R 13	155-199
D04681P		BACC45FT16A24P9 PLUG-E2-2	81205	1	34-45-12 AE0306/ /	050-099, 150-152
D04681P		BACC45FT16A24P9 PLUG	81205	1	34-45-12 AE0306/ /	153-199
D04681P		BACC45FT16A24P9 PLUG E02-2	81205	1	34-45-12 AE0306/ /	275-299
D04683J		BACC45FN20-41S RCPT-E1-3	81205	1	34-12-32 AE0317/ /	ALL
D04683P		BACC45FT20A41P PLUG-E1-3	81205	1	22-32-11 AE0317/ /	ALL

EQUIPMENT LIST

D280T132

Section D04600

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04695J		BACC45FN14-15S7 RCPT-E2-2	81205	1	34-53-11 AE0306/ /	050-099, 150-156, 162-166, 275-276
D04695J		BACC45FN16-24S7 RCPT-E2-2	81205	1	34-53-11 AE0306/ /	157, 167-199, 277- 299
D04695P		BACC45FT14A15P7 PLUG-E2-2	81205	1	34-53-11 AE0306/ /	050-099, 150-156, 162-166, 275-276
D04695P		BACC45FT16A24P7 PLUG-E2-2	81205	1	34-53-11 AE0306/ /	157, 167-199, 277- 299
D04697 U		289T0126-12401 I.D. TAPE TEXT AS BELOW	81205	1	34-53-21 / /	275-276
D04697J		BACC45FN14-15P6 RCPT-ATC TRANS R	81205	1	34-53-21 AE0322/ /	050-099, 150-152, 155-156, 162-166, 275-276
D04697J		BACC45FN12-12P6 RCPT-ATC TRANS R	81205	1	34-53-21 AE0322/ /	153-154
D04697J		BACC45FN16-24P6 RCPT-ATC TRANS R	81205	1	34-53-21 AE0322/ /	157, 167-199, 277- 299
D04697P		BACC45FT14A15S6 PLUG-E2-3	81205	1	34-53-21 AE0322/ /	050-099, 150-152, 155-156, 162-166, 275-276
D04697P		BACC45FT12A12S6 PLUG-E2-3	81205	1	34-53-21 AE0322/ /	153-154
D04697P		BACC45FT16A24S6 PLUG-E2-3	81205	1	34-53-21 AE0322/ /	157, 167-199, 277- 299
D04698J		BACC45FN12-12S6 RCPT-	81205	1	21-31-11 AC0701/ /	ALL
D04698P		BACC45FT12-12P6 PLUG-	81205	1	21-31-31 AC0701/ /	ALL
D04699J		BACC45FN18-31P RCPT-IRS-L	81205	1	34-21-11 AE0319/ /	ALL
D04699P		BACC45FT18A31S PLUG-	81205	1	34-21-11 AE0319/ /	ALL

EQUIPMENT LIST

D280T132

Section D04600

Page 9 End

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04704J		BACC45FN14-12S8 RCPT-P1 L FWD PNL DISC	81205	1	30-43-11 AF0119/ /	ALL
D04704P		BACC45FT14-12P8 PLUG-P1 FWD DISC PANEL	81205	1	30-42-11 AF0119/ /	ALL
D04705J		BACC45FN18-31P7 RCPT-E1-4	81205	1	34-12-11 AE0307/ /	ALL
D04705P		BACC45FT18A31S7 PLUG-E1-4	81205	1	34-12-41 AE0307/ /	ALL
D04706J		BACC45FN14-12S RCPT-P3FWD DISC PANEL	81205	1	30-43-11 AF0120/ /	ALL
D04706P		BACC45FT14-12P PLUG-P3FWD DISC PANEL	81205	1	30-42-11 AF0120/ /	ALL
D04707J		BACC45FN22-55P RCPT-	81205	1	31-31-11 AF0204/ /	ALL
D04707P		BACC45FT22-55S PLUG-P61	81205	1	31-31-11 AF0204/ /	050-099, 150-154, 275-299
D04707P		BACC45FT22-55S PLUG-P61	81205	1	31-31-11 234/250/R 50	155-199
D04708J		BACC45FN24-61S9 RCPT-P61	81205	1	28-42-11 AF0204/ /	ALL
D04708P		BACC45FT24-61P9 PLUG-P61	81205	1	28-42-11 AF0204/ /	ALL
D04709J		BACC45FN20-28S6 RCPT-P36	81205	1	23-31-13 AE0209/ /	ALL
D04709P		BACC45FT20-28P6 RCPT-P36	81205	1	23-31-13 AE0209/ /	ALL
D04710J		BACC45FN22-55S7 RCPT-P61	81205	1	21-31-21 AF0204/ /	ALL
D04710P		BACC45FT22-55P7 PLUG-P61	81205	1	27-62-11 AF0204/ /	ALL
D04711J		BACC45FN20-41P RCPT-E2-3	81205	1	31-31-13 AE0306/ /	ALL
D04711P		BACC45FT20A41S PLUG-E2-3	81205	1	31-31-11 AE0306/ /	ALL

EQUIPMENT LIST

D280T132

Section D04700

Page 1

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04714J		BACC45FN24-61S RCPT-P61	81205	1	27-58-11 AF0204/ /	ALL
D04714P		BACC45FT24-61P PLUG-P61	81205	1	27-11-11 AF0204/ /	ALL
D04716J		BACC45FN18-31P9 RCPT-P36	81205	1	21-58-16 AE0223/ /	ALL
D04716P		BACC45FT18-31S9 PLUG-P36	81205	1	28-41-22 AE0223/ /	050-099, 280-299
D04716P		BACC45FT18-31S9 PLUG-P36	81205	1	28-41-12 AE0223/ /	150-199, 275-278
D04717J		BACC45FN16-24S RCPT-E2-2	81205	1	34-22-18 AE0306/ /	ALL
D04717P		BACC45FT16A24P PLUG-E2-2	81205	1	34-61-15 AE0306/ /	ALL
D04718J		BACC45FN20-28S6 RCPT-P61	81205	1	27-18-11 AF0204/ /	ALL
D04718P		BACC45FT20-28P6 PLUG-P61	81205	1	27-51-31 AF0204/ /	ALL
D04719J		BACC45FN22-55P9 RCPT-E1-6	81205	1	31-51-60 AE0305/ /	ALL
D04719P		BACC45FT22A55S9 PLUG-	81205	1	34-21-11 AE0305/ /	ALL
D04720J		BACC45FN20-41S7 RCPT-P61	81205	1	74-31-11 AF0204/ /	ALL
D04720P		BACC45FT20-41P7 PLUG-P61	81205	1	73-31-11 AF0204/ /	ALL
D04721J		BACC45FN16-24S9 RCPT-E2-2	81205	1	22-41-11 AE0306/ /	ALL
D04721P		BACC45FT16A24P9 PLUG-E2-2	81205	1	34-46-11 AE0306/ /	050-099
D04721P		BACC45FT16A24P9 PLUG E2-2	81205	1	34-46-11 AE0306/ /	150-199, 275-299
D04725J		BACC45FN22-55P RCPT-E2-3	81205	1	31-31-11 AE0322/ /	050-099, 150-154, 275-299

EQUIPMENT LIST

D280T132

Section D04700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04725J		BACC45FN22-55P RCPT-E2-3	81205	1	31-31-11 347/160/R 44	155-199
D04725P		BACC45FT22A55S PLUG-E2-3	81205	1	31-31-11 AE0322/ /	ALL
D04726J		BACC45FN24-61S RCPT-P61	81205	1	21-53-22 AF0204/ /	ALL
D04726P		BACC45FT24-61P PLUG-P61	81205	1	26-17-11 AF0204/ /	ALL
D04727J		BACC45FM18C14S RCPT-L WW FWD INBD	81205	1	31-31-13 AL1003/ /	ALL
D04727P		BACC63BP18R14PNL PLUG-L WW FWD INBD	81205	1	31-31-13 AL1003/ /	ALL
D04727PQ		BACC10KD18 CLAMP-	81205	1	31-31-13 / /	ALL
D04729J		BACC45FN14-15P7 RCPT-E2-3	81205	1	31-31-13 AE0307/ /	ALL
D04729P		BACC45FT14A15S7 PLUG-E2-3	81205	1	31-31-11 AE0307/ /	ALL
D04730J		BACC45FN16-10S9 RCPT-P61	81205	1	27-23-11 AF0204/ /	ALL
D04730P		BACC45FT16-10P9 PLUG-P61	81205	1	27-23-11 AF0204/ /	ALL
D04731J		BACC45FN14-15P9 RCPT-E2-3	81205	1	31-31-15 AE0307/ /	050-099
D04731J		BACC45FN16-24P9 RCPT-E2-3	81205	1	31-31-15 AE0307/ /	150-199, 275-299
D04731P		BACC45FT14A15S9 PLUG-E2-3	81205	1	31-31-15 AE0307/ /	050-099
D04731P		BACC45FT16A24S9 PLUG-E2-3	81205	1	31-31-15 AE0307/ /	150-199, 275-299
D04732J		BACC45FN20-41S6 RCPT-P61	81205	1	74-31-11 AF0204/ /	ALL
D04732P		BACC45FT20-41P6 PLUG-P61	81205	1	74-31-11 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D04700

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04734J		BACC45FN12-12S6 PLUG	81205	1	73-21-13 0139/194/L010	ALL
D04735J		BACC45FN22-55S7 RCPT-E2-2	81205	1	23-51-12 AE0306/ /	050-099, 150-154, 275-299
D04735J		BACC45FN22-55S7 RCPT-E2-2	81205	1	23-51-12 355/125/R 13	155-199
D04735P		BACC45FT22A55P7 PLUG-E2-2	81205	1	34-61-12 AE0306/ /	ALL
D04736J		BACC45FN12-12S6 RECP	81205	1	73-21-13 139/194/R 10	ALL
D04737J		BACC45FN22-55S RCPT-E2-5	81205	1	23-51-12 AE0306/ /	050-099, 275-299
D04737J		BACC45FN20-41S RCPT-E2-5	81205	1	23-51-12 AE0306/ /	150-154
D04737J		BACC45FN22-55S RCPT-E2-5	81205	1	23-51-12 355/125/R 13	155-199
D04737P		BACC45FT22A55P PLUG-E2-5	81205	1	23-51-12 AE0306/ /	050-099, 155-199, 275-299
D04737P		BACC45FT20A41P PLUG-E2-5	81205	1	23-51-12 AE0306/ /	150-154
D04738J		BACC45FN22-55S7 RCPT-P61	81205	1	32-42-12 AF0204/ /	ALL
D04738P		BACC45FT22-55P7 PLUG-P61	81205	1	32-42-12 AF0204/ /	ALL
D04741J		BACC45FN16-24P9 RCPT-E2-3	81205	1	31-31-11 AE0307/ /	ALL
D04741P		BACC45FT16A24S9 PLUG-E2-3	81205	1	31-31-11 AE0307/ /	ALL
D04743J		BACC45FN16-24S9 RCPT-P36	81205	1	34-12-31 AE0209/ /	ALL
D04743P		BACC45FT16-24P9 PLUG-P36	81205	1	34-12-11 AE0209/ /	ALL
D04744J		BACC63BV24A30PN RCPT-P28	81205	1	28-21-11 AW0601/ /	ALL

EQUIPMENT LIST

D280T132

Section D04700

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04744JK		BACC10GH24 CLAMP-	81205	1	28-21-11 / /	ALL
D04744P		BACC63BP24A30SNL PLUG-P28	81205	1	28-21-11 AW0601/ /	ALL
D04744PQ		BACC10KD24 CLAMP-	81205	1	28-21-11 / /	ALL
D04745J		BACC45FN16-24S RCPT-P37	81205	1	34-12-61 AE0224/ /	ALL
D04745P		BACC45FT16-24P PLUG-P37	81205	1	32-42-11 AE0224/ /	ALL
D04746J		BACC63BV24A30P7 RCPT-P28	81205	1	28-21-11 AW0601/ /	ALL
D04746JK		BACC10GH24 CLAMP-	81205	1	28-21-11 / /	ALL
D04746P		BACC63BP24A30S7L PLUG-P28	81205	1	28-21-11 AW0601/ /	ALL
D04746PQ		BACC10KD24 CLAMP-	81205	1	28-21-11 / /	ALL
D04751J		BACC45FN12-12P9 PLUG-E1-2	81205	1	23-22-11 AE0307/ /	ALL
D04751P		BACC45FT12A12S9 PLUG-E1-2	81205	1	23-22-11 AE0307/ /	ALL
D04753J		BACC45FN14-4S9 RCPT-E1-6	81205	1	34-21-11 AE0319/ /	ALL
D04753P		BACC45FT14A4P9 PLUG-	81205	1	34-21-11 AE0319/ /	ALL
D04754J		BACC45FN20-41S8 RCPT-P61	81205	1	74-31-21 AF0204/ /	ALL
D04754P		BACC45FT20-41P8 PLUG-P61	81205	1	29-11-11 AF0204/ /	ALL
D04756J		BACC45FN20-41S RCPT-P61	81205	1	80-11-21 AF0204/ /	ALL
D04756P		BACC45FT20-41P PLUG-P61	81205	1	73-21-18 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D04700

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04757J		BACC45FN18-31P7 RCPT-IRS-C	81205	1	34-21-31 AE0319/ /	ALL
D04757P		BACC45FT18A31S7 PLUG-E1-6	81205	1	34-21-31 AE0319/ /	ALL
D04758J		BACC45FN22-55S9 RCPT-P61	81205	1	27-51-11 AF0204/ /	ALL
D04758P		BACC45FT22-55P9 PLUG-P61	81205	1	27-58-21 AF0204/ /	ALL
D04760J		BACC45FN22-55S8 RCPT-P61	81205	1	27-51-11 AF0204/ /	ALL
D04760P		BACC45FT22-55P8 PLUG-P61	81205	1	73-35-11 AF0204/ /	ALL
D04761J		BACC45FN18-31P RCPT-IRS-R	81205	1	34-21-21 AE0319/ /	ALL
D04761P		BACC45FT18A31S PLUG-	81205	1	34-21-21 AE0319/ /	ALL
D04765J		BACC45FN18-31P RCPT-E2-3	81205	1	31-35-11 AE0306/ /	ALL
D04765P		BACC45FT18A31S PLUG E2-3	81205	1	31-31-11 AE0306/ /	ALL
D04766J		BACC45FN24-61S8 RCPT-P61	81205	1	21-25-21 AF0204/ /	ALL
D04766P		BACC45FT24-61P8 PLUG-P61	81205	1	32-09-12 AF0204/ /	ALL
D04767J		BACC45FN22-55S6 RCPT-E2-3	81205	1	34-61-25 AE0320/ /	ALL
D04767P		BACC45FT22A55P6 PLUG-	81205	1	34-61-22 AE0320/ /	ALL
D04768J		BACC45FN16-24S8 RCPT-E2-4	81205	1	21-31-21 AE0320/ /	ALL
D04768P		BACC45FT16A24P8 PLUG-E2-4	81205	1	21-31-21 AE0320/ /	ALL
D04769J		BACC45FN22-55P9 RCPT-E1-6	81205	1	22-32-11 AE0317/ /	ALL

EQUIPMENT LIST

D280T132

Section D04700

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04769P		BACC45FT22A55S9 PLUG-	81205	1	34-21-21 AE0317/ /	ALL
D04770J		BACC45FM14C7S RCPT-WHEEL WELL	81205	1	32-42-12 AL1006/ /	ALL
D04770P		BACC63BP14R7PNL PLUG-R WING/BODY RS DISC	81205	1	32-42-12 AL1006/ /	ALL
D04770PQ		BACC10KD14 CLAMP-	81205	1	32-42-12 / /	ALL
D04771J		BACC45FN12-12P RCPT-E2-2	81205	1	31-35-11 AE0322/ /	275-299
D04772J		BACC45FN14-15S7 RCPT-P61	81205	1	32-42-11 AF0204/ /	ALL
D04772P		BACC45FT14-15P7 PLUG-P61	81205	1	32-42-11 AF0204/ /	ALL
D04773J		BACC45FN14-4S6 RCPT-	81205	1	34-21-31 AE0307/ /	ALL
D04773P		BACC45FT14A4P6 PLUG-E1-6	81205	1	34-21-31 AE0307/ /	ALL
D04774		CUSTOMER PLUG	CUST	1	28-31-12 AF0204/ /	051-099
D04774J		BACC45FN22-55S9 RCPT-P61	81205	1	80-11-11 AF0204/ /	ALL
D04774P		BACC45FT22-55P9 PLUG-P61	81205	1	32-44-11 AF0204/ /	ALL
D04776J		BACC45FN14-7S RCPT-P61	81205	1	25-31-21 AF0204/ /	ALL
D04776P		BACC45FT14-7P PLUG-P61	81205	1	24-51-13 AF0204/ /	ALL
D04778J		BACC45FN22-55S8 RCPT-P61	81205	1	24-11-11 AF0204/ /	ALL
D04778P		BACC45FT22-55P8 PLUG-P61	81205	1	24-11-11 AF0204/ /	ALL
D04781J		BACC45FN22-55S9 RCPT-E1-3	81205	1	34-12-12 AE0305/ /	050-099, 150-154, 275-299

EQUIPMENT LIST

D280T132

Section D04700

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04781J		BACC45FN22-55S9 RCPT-E1-3	81205	1	34-12-12 355/125/L 36	155-199
D04781P		BACC45FT22A55P9 PLUG-E1-3	81205	1	34-12-12 AE0305/ /	ALL
D04783J		BACC45FN14-15P7 RCPT-	81205	1	22-21-11 AP1501/ /	ALL
D04783P		BACC45FT14-15S7 PLUG-	81205	1	22-21-11 AP1501/ /	ALL
D04787J		BACC45FN12-12P RCPT-HF L	81205	1	23-11-11 AE0306/ /	ALL
D04787P		BACC45FT12A12S PLUG-E2-6	81205	1	23-11-11 AE0306/ /	ALL
D04789J		BACC45FN12-12P6 RCPT-E2-6	81205	1	23-11-21 AE0320/ /	ALL
D04789P		BACC45FT12A12S6 PLUG-E2-6	81205	1	23-11-21 AE0320/ /	ALL
D04791J		BACC45FN16-24P6 RCPT-E2-2	81205	1	34-61-14 AE0306/ /	050-099, 155-199, 275-299
D04791J		BACC45FN20-39P6 RCPT-E2-2	81205	1	34-61-14 AE0306/ /	150-154
D04791P		BACC45FT16A24S6 PLUG-E2-2	81205	1	34-61-14 AE0306/ /	050-099, 155-199, 275-299
D04791P		BACC45FT20A39S6 PLUG-E2-2	81205	1	34-61-14 AE0306/ /	150-154
D04793J		BACC45FN16-24P7 RCPT-E1-5	81205	1	22-14-31 AE0317/ /	ALL
D04793P		BACC45FT16A24S7 PLUG-E1-5	81205	1	22-33-11 AE0317/ /	ALL
D04794J		BACC45FN22-55S7 RCPT-P61	81205	1	24-22-21 AF0204/ /	ALL
D04794P		BACC45FT22-55P7 PLUG-P61	81205	1	24-11-21 AF0204/ /	ALL
D04796J		BACC45FN22-55S6 RCPT-P61	81205	1	49-61-11 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D04700

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04796P		BACC45FT22-55P6 PLUG-P61	81205	1	24-22-41 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D04700
Page 9 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04801J		BACC45FN16-24P8 RCPT-P33	81205	1	34-12-12 AE0207/ /	ALL
D04801P		BACC45FT16-24S8 PLUG-P33	81205	1	34-12-12 AE0207/ /	ALL
D04802J		BACC45FN20-39P9 RCPT-	81205	1	33-42-21 AE0209/ /	ALL
D04802P		BACC45FT20-39S9 PLUG-P36	81205	1	33-42-21 AE0209/ /	ALL
D04803J		BACC45FN14-15P RCPT-P33	81205	1	34-12-22 AE0203/ /	ALL
D04803P		BACC45FT14-15S PLUG-P33	81205	1	34-12-12 AE0203/ /	ALL
D04804J		BACC45FN20-41P6 RCPT-E2-4	81205	1	28-41-22 AE0320/ /	ALL
D04804P		BACC45FT20A41S6 PLUG-E2-4	81205	1	28-41-22 AE0320/ /	ALL
D04805J		BACC45FN22-55S8 RCPT-E1-5	81205	1	34-61-24 AE0317/ /	ALL
D04805P		BACC45FT22A55P8 PLUG-E1-5	81205	1	34-22-29 AE0317/ /	ALL
D04807J		BACC45FM18C14S RCPT-L WW FWD OUTBD	81205	1	22-11-11 AL1001/ /	ALL
D04807P		BACC63BP18R14PNL PLUG-L WW FWD OUTBD	81205	1	22-11-11 AL1001/ /	ALL
D04807PQ		BACC10KD18 CLAMP-	81205	1	22-11-11 / /	ALL
D04809J		BACC45FN16-24P RCPT-	81205	1	34-61-23 AE0202/ /	ALL
D04809P		BACC45FT16-24S PLUG-P50 CARD FILE,ELECTRICAL SYSTEMS	81205	1	34-61-13 AE0202/ /	ALL
D04811J		BACC45FN22-55S RCPT-E2-3	81205	1	31-31-13 AE0320/ /	ALL
D04811P		BACC45FT22A55P PLUG-E2-3	81205	1	31-31-13 AE0320/ /	ALL

EQUIPMENT LIST

D280T132

Section D04800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04813J		BACC45FN22-55S8 RCPT-E2-5	81205	1	23-51-12 AE0320/ /	050-099, 157, 167-199, 277-299
D04813J		BACC45FN20-41S8 RCPT-E2-5	81205	1	23-51-12 AE0320/ /	150-156, 162-166, 275-276
D04813P		BACC45FT22A55P8 PLUG-E2-5	81205	1	23-51-12 AE0320/ /	050-099, 157, 167-199, 277-299
D04813P		BACC45FT20A41P8 PLUG-E2-5	81205	1	23-51-12 AE0320/ /	150-156, 162-166, 275-276
D04815J		BACC45FN14-15P7 RCPT-	81205	1	22-14-31 347/130/L 48	ALL
D04815P		BACC45FT14A15S7 PLUG-	81205	1	22-14-31 AE0319/ /	ALL
D04819J		BACC45FN22-55P RCPT-E2-3	81205	1	31-51-21 AE0320/ /	ALL
D04819P		BACC45FT22A55S PLUG-E2-3	81205	1	34-16-11 AE0320/ /	ALL
D04821J		BACC45FN22-55S8 RCPT-E2-3	81205	1	34-22-28 AE0320/ /	ALL
D04821P		BACC45FT22A55P8 PLUG-E2-3	81205	1	34-61-22 AE0320/ /	ALL
D04825J		BACC45FN12-12P7 RCPT-	81205	1	23-11-11 AP1501/ /	ALL
D04825P		BACC45FT12-12S7 PLUG-	81205	1	23-11-11 AP1501/ /	ALL
D04827J		BACC45FN12-12P8 RCPT-	81205	1	23-11-21 AP1501/ /	ALL
D04827P		BACC45FT12-12S8 PLUG-	81205	1	23-11-21 AP1501/ /	ALL
D04829J		BACC45FN14-15S7 RCPT-WX-L TO EFI-R,E1-5	81205	1	34-43-11 AE0319/ /	ALL
D04829P		BACC45FT14A15P7 PLUG-E1-5	81205	1	34-43-11 AE0319/ /	ALL
D04831J		BACC45FN20-41S8 RCPT-E1-3	81205	1	34-61-12 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D04800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04831P		BACC45FT20A41P8 PLUG-E1-3	81205	1	22-13-11 AE0305/ /	ALL
D04839J		KN-19-198-M06 JACK-COAX,HF L	91836	1	23-11-11 F 282/ /LE	050-099, 150-154, 162-164, 275-276
D04839J		KN-19-162 JACK-COAX,HF L	91836	1	23-11-11 F 282/ /LE	155-157, 165-199, 277-299
D04839P		KN-59-332-M06 PLUG-COAX,HF L	91836	1	23-11-11 F 282/ /LE	050-099, 150-154, 162-164, 275-276
D04839P		KN-59-263 PLUG-COAX,HF L	91836	1	23-11-11 F 282/ /LE	155-157, 165-199, 277-299
D04841J		KN-19-198-M06 JACK-COAX,HF R	91836	1	23-11-21 F 271/ /LE	050-099, 150-154, 162-164, 275-276
D04841J		KN-19-162 JACK-COAX,HF R	91836	1	23-11-21 F 271/ /LE	155-157, 165-199, 277-299
D04841P		KN-59-332-M06 PLUG-COAX,HF R	91836	1	23-11-21 F 276/ /LE	050-099, 150-154, 162-164, 275
D04841P		KN-59-263 PLUG-COAX,HF R	91836	1	23-11-21 F 276/ /LE	155-157, 165-199, 276-299
D04843J		BACC45FN12-12P8 RCPT-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D04843P		BACC45FT12A12S8 PLUG-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D04849J		BACC45FN14-15S6 RCPT-WX-R TO EFI-R,E1-5	81205	1	34-43-21 AE0319/ /	ALL
D04849P		BACC45FT14A15P6 PLUG-E1-5	81205	1	34-43-21 AE0319/ /	ALL
D04852J		BACC45FN18-31S7 RCPT-P61	81205	1	26-17-11 AF0204/ /	ALL
D04852P		BACC45FT18-31P7 PLUG-P61	81205	1	76-11-11 AF0204/ /	ALL
D04853J		BACC45FN22-55S6 RCPT-E1-5	81205	1	22-14-21 AE0305/ /	ALL
D04853P		BACC45FT22A55P6 PLUG-E1-5	81205	1	22-14-21 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D04800

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04854J		BACC45FN22-32S6 RCPT-P61	81205	1	29-11-32 AF0204/ /	ALL
D04854P		BACC45FT22-32P6 PLUG-P61	81205	1	28-26-11 AF0204/ /	ALL
D04855J		BACC45FN22-55S9 RCPT-E1-3	81205	1	22-14-21 AE0305/ /	ALL
D04855P		BACC45FT22A55P9 PLUG-E1-3	81205	1	22-14-21 AE0305/ /	ALL
D04856J		BACC45FN24-43P7 RCPT-P36	81205	1	29-11-32 AE0209/ /	ALL
D04856P		BACC45FT24-43S7 PLUG-P36	81205	1	28-21-11 AE0209/ /	ALL
D04857J		BACC45FN22-55S6 RCPT-E1-5	81205	1	22-14-11 AE0317/ /	ALL
D04857P		BACC45FT22A55P6 PLUG-E1-5	81205	1	22-14-11 AE0317/ /	ALL
D04859J		BACC45FN20-41S6 RCPT-E1-3	81205	1	22-14-11 AE0317/ /	ALL
D04859P		BACC45FT20A41P6 PLUG-E1-3	81205	1	22-14-11 AE0317/ /	ALL
D04860J		BACC45FN14-12S8 RCPT-P34	81205	1	28-41-12 AE0204/ /	ALL
D04860P		BACC45FT14-12P8 PLUG-P34	81205	1	52-71-11 AE0204/ /	ALL
D04862J		BACC45FN16-24S6 RCPT-E2-4	81205	1	32-46-11 AE0306/ /	ALL
D04862P		BACC45FT16A24P6 PLUG-E2-4	81205	1	32-46-11 AE0306/ /	ALL
D04865J		BACC45FN12-12S6 RCPT-E5-3	81205	1	31-35-11 AC0608/ /	275-299
D04867J		BACC45FN16-24S8 RCPT-P7	81205	1	34-22-15 AF0117/ /	ALL
D04867P		BACC45FT16-24P8 PLUG-	81205	1	34-22-15 AF0117/ /	ALL

EQUIPMENT LIST

D280T132

Section D04800

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04868J		BACC45FN14-15S6 RCPT-E2-2	81205	1	31-51-55 AE0306/ /	ALL
D04868P		BACC45FT14A15P6 PLUG-E2-2	81205	1	31-51-21 AE0306/ /	ALL
D04869J		BACC45FN16-24S7 RCPT-P7	81205	1	34-22-25 AF0118/ /	ALL
D04869P		BACC45FT16-24P7 PLUG-	81205	1	34-22-25 AF0118/ /	ALL
D04870J		BACC45FN22-55S8 RCPT-P61	81205	1	21-44-21 AF0204/ /	ALL
D04870P		BACC45FT22-55P8 PLUG-P61	81205	1	28-42-11 AF0204/ /	ALL
D04873J		BACC45FN16-24S9 RCPT-E1-5	81205	1	22-41-11 AE0317/ /	ALL
D04873P		BACC45FT16A24P9 PLUG-E1-5	81205	1	22-41-11 AE0317/ /	ALL
D04874J		BACC45FN12-12S8 RCPT-E1-1	81205	1	32-42-11 AE0307/ /	ALL
D04874P		BACC45FT12A12P8 PLUG-E1-1	81205	1	32-42-11 AE0307/ /	ALL
D04875J		BACC45FN20-41S9 RCPT-E1-2	81205	1	22-41-11 AE0317/ /	ALL
D04875P		BACC45FT20A41P9 PLUG-E1-2	81205	1	34-22-18 AE0317/ /	ALL
D04879J		BACC45FN12-12P7 RCPT-E1-3	81205	1	22-34-11 AE0317/ /	ALL
D04879P		BACC45FT12A12S7 PLUG-E1-3	81205	1	22-14-11 AE0317/ /	ALL
D04881J		BACC45FN14-15S9 RCPT-E1-4	81205	1	22-24-11 AE0307/ /	ALL
D04881P		BACC45FT14A15P9 PLUG-E1-4	81205	1	22-12-31 AE0307/ /	ALL
D04883J		BACC45FN18-31S9 RCPT-E1-5	81205	1	22-24-21 AE0317/ /	ALL

EQUIPMENT LIST

D280T132

Section D04800

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04883P		BACC45FT18A31P9 PLUG-E1-5	81205	1	22-24-21 AE0317/ /	ALL
D04885J		BACC45FN14-15P8 RCPT-	81205	1	22-12-31 AE0202/ /	ALL
D04885P		BACC45FT14-15S8 PLUG-P50	81205	1	22-12-31 AE0202/ /	ALL
D04887J		BACC45FN20-41P6 RCPT-	81205	1	22-32-12 AE0202/ /	ALL
D04887P		BACC45FT20-41S6 PLUG-P50	81205	1	22-24-11 AE0202/ /	ALL
D04889 U		289T0241-11401 I.D. TAPE TEXT AS BELOW	81205	1	34-43-11 / /	153-154
D04889 V		289T0241-11501 I.D. TAPE TEXT AS BELOW		1	34-45-14 E1-2/ /	153-154
D04889J		BACC45FN16-24P9 RCPT-WX-L TO EFI-L-E1-2	81205	1	34-43-11 AE0319/ /	ALL
D04889P		BACC45FT16A24S9 PLUG-	81205	1	34-43-11 AE0319/ /	050-099, 150-152, 155-199, 275-299
D04889P		BACC45FT16A24S9 PLUG-E1-2	81205	1	34-45-14 AE0319/ /	153-154
D04893J		BACC45FN22-55S6 RCPT-P3	81205	1	22-14-11 AF0120/ /	ALL
D04893P		BACC45FT22-55P6 PLUG-P3	81205	1	22-14-11 AF0120/ /	ALL
D04895J		BACC45FN12-12S6 RCPT-E1-3	81205	1	22-32-12 AE0317/ /	ALL
D04895P		BACC45FT12A12P6 PLUG-E1-3	81205	1	22-32-12 AE0317/ /	ALL
D04899J		BACC45FN18-31S8 RCPT-E2-3	81205	1	34-61-14 AE0320/ /	ALL
D04899P		BACC45FT18A31P8 PLUG-E2-3	81205	1	34-61-14 AE0320/ /	ALL

EQUIPMENT LIST

D280T132

Section D04800

Page 6 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04901J		BACC45FN10-5P RCPT-	81205	1	34-22-37 AE0319/ /	ALL
D04901P		BACC45FT10A5S PLUG-E1-4	81205	1	34-22-37 AE0319/ /	ALL
D04904J		BACC45FN24-61S RCPT-	81205	1	21-51-11 AE0209/ /	ALL
D04904P		BACC45FT24-61P PLUG-P36	81205	1	21-51-11 AE0209/ /	ALL
D04906J		BACC45FN22-32P7 RCPT-P36	81205	1	21-58-14 AE0209/ /	ALL
D04906P		BACC45FT22-32S7 PLUG-P36	81205	1	32-42-11 AE0209/ /	ALL
D04908J		BACC45FN16-24P RCPT-	81205	1	32-42-11 AE0305/ /	ALL
D04908P		BACC45FT16-24S PLUG-E1-1	81205	1	32-42-11 AE0305/ /	ALL
D04908PQ		BACC10GH16 CLAMP-	81205	1	32-42-11 / /	ALL
D04912J		BACC45FN16-24S8 RCPT-E1-2	81205	1	21-31-11 AE0305/ /	ALL
D04912P		BACC45FT16A24P8 PLUG-	81205	1	21-31-11 AE0305/ /	ALL
D04913J		BACC45FN22-55P RCPT-E1-4	81205	1	22-12-31 AE0307/ /	ALL
D04913P		BACC45FT22A55S PLUG-E1-4	81205	1	22-12-31 AE0307/ /	ALL
D04915J		BACC45FN20-41P6 RCPT-E1-2	81205	1	22-12-31 AE0307/ /	050-099, 150-199
D04915J		BACC45FN18-31P6 RCPT-E1-2	81205	1	22-12-31 AE0307/ /	275-299
D04915P		BACC45FT20A41S6 PLUG-E1-2	81205	1	34-22-18 AE0307/ /	050-099, 150-199
D04915P		BACC45FT18A31S6 PLUG-E1-2	81205	1	34-22-18 AE0307/ /	275-299

EQUIPMENT LIST

D280T132

Section D04900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04916J		BACC45FN16-24P6 RCPT-E2-4	81205	1	29-33-11 AE0320/ /	ALL
D04916P		BACC45FT16A24S6 PLUG-E2-4	81205	1	28-41-23 AE0320/ /	ALL
D04917J		BACC63BV22F55SN RCPT-PRESS BLKHD	81205	1	34-43-12 132/189/R019	ALL
D04917P		BACC63BP22C55PNL PLUG-PRESS.BLKHD	81205	1	34-43-12 132/189/R019	ALL
D04917PQ		G4993-2212-1-5N BACKSHELL	06324	1	34-43-12 132/ /	ALL
D04918J		BACC45FN22-32P6 RCPT-	81205	1	21-43-11 AE0209/ /	ALL
D04918P		BACC45FT22-32S6 PLUG-P36	81205	1	21-43-11 AE0209/ /	ALL
D04919J		BACC63BV22F55SN RCPT-PRESS BLKHD	81205	1	34-43-22 132/189/R022	ALL
D04919P		BACC63BP22C55PNL PLUG-PRESS. BLKHD	81205	1	34-43-22 132/189/R022	ALL
D04919PQ		G4993-2212-1-5N BACKSHELL	06324	1	34-43-22 132/ /	ALL
D04920J		BACC45FN22-12S7 RCPT-P36	81205	1	27-25-11 AE0209/ /	ALL
D04920P		BACC45FT22-12P7 PLUG-P36	81205	1	21-25-11 AE0209/ /	ALL
D04922J		BACC45FN20-25S7 RCPT-P37	81205	1	21-25-21 AE0218/ /	ALL
D04922P		BACC45FT20-25P7 PLUG-P37	81205	1	21-25-21 AE0218/ /	ALL
D04923J		BACC45FN22-55S RCPT-E1-2	81205	1	31-31-13 AE0305/ /	ALL
D04923P		BACC45FT22A55P PLUG-	81205	1	34-22-14 AE0305/ /	ALL
D04924J		BACC45FN20-25S RCPT-P37	81205	1	21-53-21 AE0218/ /	ALL

EQUIPMENT LIST

D280T132

Section D04900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04924P		BACC45FT20-25P PLUG-P37	81205	1	21-53-21 AE0218/ /	ALL
D04926J		BACC45FN18-31S7 RCPT-P34	81205	1	25-53-11 AE0204/ /	ALL
D04926P		BACC45FT18-31P7 PLUG-P34	81205	1	25-53-11 AE0204/ /	ALL
D04927J		BACC45FN14-12P9 RCPT-E2-5	81205	1	23-12-11 AE0307/ /	ALL
D04927P		BACC45FT14A12S9 PLUG-E2-5	81205	1	23-12-11 AE0307/ /	ALL
D04928J		BACC45FN20-25S9 RCPT-P33	81205	1	25-29-11 AE0203/ /	ALL
D04928P		BACC45FT20-25P9 PLUG-P33	81205	1	25-29-11 AE0203/ /	ALL
D04929J		BACC45FN14-12P9 RCPT-E2-5	81205	1	23-12-21 AE0322/ /	ALL
D04929P		BACC45FT14A12S9 PLUG-E2-5	81205	1	23-12-21 AE0322/ /	ALL
D04930J		BACC45FN16-24S7 RCPT-E1-1	81205	1	30-21-11 AE0305/ /	ALL
D04930P		BACC45FT16A24P7 PLUG-E1-1	81205	1	32-42-11 AE0305/ /	ALL
D04931J		BACC45FN14-12P6 RCPT-E2-5	81205	1	23-12-31 AE0306/ /	ALL
D04931P		BACC45FT14A12S6 PLUG E2-5	81205	1	23-12-31 AE0306/ /	050-099
D04931P		BACC45FT14A12S6 PLUG-E2-5	81205	1	23-12-31 AE0306/ /	150-199, 275-299
D04932J		BACC45FN24-57S6 RCPT-	81205	1	30-21-11 AE0209/ /	ALL
D04932P		BACC45FT24-57P6 PLUG-P36	81205	1	30-21-11 AE0209/ /	ALL
D04934J		BACC45FN18-31S8 RCPT-P37	81205	1	29-11-31 AE0218/ /	ALL

EQUIPMENT LIST

D280T132

Section D04900

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04934P		BACC45FT18-31P8 PLUG-P37	81205	1	29-11-31 AE0218/ /	ALL
D04936J		BACC45FN12-12P6 RCPT-	81205	1	32-42-11 AE0305/ /	ALL
D04936P		BACC45FT12A12S6 PLUG-E1-1	81205	1	32-42-11 AE0305/ /	ALL
D04938J		BACC45FN20-28S8 RCPT-P61	81205	1	26-11-11 AF0204/ /	ALL
D04938P		BACC45FT20-28P8 PLUG-P61	81205	1	26-11-11 AF0204/ /	ALL
D04940J		BACC45FN24-57S9 RCPT-P61	81205	1	28-41-11 AF0204/ /	ALL
D04940P		BACC45FT24-57P9 PLUG-P61	81205	1	26-11-21 AF0204/ /	ALL
D04941J		BACC45FN16-24S7 RCPT-E1-3	81205	1	31-31-14 AE0305/ /	ALL
D04941P		BACC45FT16A24P7 PLUG-E1-3	81205	1	31-31-14 AE0305/ /	ALL
D04942J		BACC45FN24-43S9 RCPT-P36	81205	1	28-21-11 AE0209/ /	050-099, 150-156, 162-166, 275-276
D04942J		BACC45FN24-61S9 RCPT-P36	81205	1	28-21-11 AE0209/ /	157, 167-199, 277- 299
D04942P		BACC45FT24-43P9 PLUG-	81205	1	28-21-11 AE0209/ /	050-099, 150-156, 162-166, 275-276
D04942P		BACC45FT24-61P9 PLUG-	81205	1	28-21-11 AE0209/ /	157, 167-199, 277- 299
D04943J		BACC45FN18-31S7 RCPT-E2-3	81205	1	31-31-14 AE0322/ /	ALL
D04943P		BACC45FT18A31P7 PLUG-E2-E	81205	1	31-31-14 AE0322/ /	ALL
D04944J		BACC45FN20-41P6 RCPT-	81205	1	28-41-11 AE0307/ /	ALL
D04944P		BACC45FT20A41S6 PLUG-E2-4	81205	1	28-41-11 AE0307/ /	ALL

EQUIPMENT LIST

D280T132

Section D04900

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04945J		BACC45FN10-5P RCPT-E2-1	81205	1	27-09-11 AE0308/ /	ALL
D04945P		BACC45FT10A5S PLUG-E2-1	81205	1	27-09-11 AE0308/ /	ALL
D04946J		BACC45FM18C14S9 RCPT-	81205	1	29-21-32 AL1004/ /	ALL
D04946P		BACC63BP18R14P9L PLUG-R WING/BODY RS DISC	81205	1	29-33-11 AL1004/ /	ALL
D04946PQ		BACC10KD18 CLAMP-	81205	1	29-33-11 / /	ALL
D04948J		BACC45FN22-55P6 RCPT-P37	81205	1	26-15-12 AE0218/ /	ALL
D04948P		BACC45FT22-55S6 PLUG-P37	81205	1	26-16-21 AE0218/ /	ALL
D04950J		BACC63BV24A30S7 RCPT-NOSE WHEEL WELL	81205	1	26-22-21 AL0202/ /	050-099, 155-199, 275-299
D04950J		BACC63BV22A19S7 RCPT-NOSE WHEEL WELL	81205	1	26-22-21 AL0202/ /	150-154
D04950JK		BACC10KD24 CLAMP	81205	1	26-22-21 AL0202/ /	050-099, 155-199, 275-299
D04950JK		BACC10KD22 CLAMP	81205	1	26-22-21 AL0202/ /	150-154
D04950P		BACC63BP24A30P7L PLUG-NOSE WW DISC	81205	1	26-16-11 AL0202/ /	050-099, 155-199, 275-299
D04950P		BACC63BP22A19P7L PLUG-	81205	1	26-16-11 AL0202/ /	150-154
D04952J		BACC45FN22-55S RCPT-P61	81205	1	26-21-11 AF0204/ /	ALL
D04952P		BACC45FT22-55P PLUG-P61	81205	1	26-11-21 AF0204/ /	ALL
D04953J		BACC45FN16-24P6 RCPT-E2-5	81205	1	23-41-11 AE0307/ /	ALL
D04953P		BACC45FT16A24S6 PLUG-E2-5	81205	1	23-41-11 AE0307/ /	ALL

EQUIPMENT LIST

D280T132

Section D04900

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04954J		BACC45FM22C19S RCPT-R WING/BODY RS	81205	1	32-41-11 AL1004/ /	ALL
D04954P		BACC63BP22R19PNL PLUG-R WING/BODY RS	81205	1	32-41-11 AL1004/ /	ALL
D04954PQ		BACC10KD22 CLAMP-	81205	1	32-41-11 / /	ALL
D04955J		BACC45FN16-24S9 RCPT-P61	81205	1	23-41-11 AF0204/ /	ALL
D04955P		BACC45FT16-24P9 PLUG-P4	81205	1	23-41-11 AF0204/ /	ALL
D04957J		BACC45FN22-55P7 RCPT E2-5	81205	1	23-22-11 AE0322/ /	277-278
D04957P		BACC45FT22A55S7 PLUG E2-5	81205	1	23-22-11 AE0322/ /	277-278
D04958J		BACC45FN14-15S RCPT-P37	81205	1	29-21-31 AE0218/ /	ALL
D04958P		BACC45FT14-15P RCPT-P37	81205	1	29-21-31 AE0218/ /	ALL
D04960J		BACC45FN12-12P RCPT-E2-4	81205	1	29-33-11 AE0306/ /	ALL
D04960P		BACC45FT12A12S PLUG-E2-4	81205	1	21-31-21 AE0306/ /	ALL
D04962J		BACC45FN24-43S7 RCPT-P37	81205	1	28-42-11 AE0218/ /	ALL
D04962P		BACC45FT24-43P7 PLUG-P37	81205	1	28-42-11 AE0218/ /	ALL
D04963J		BACC45FN14-15S RCPT-E2-5	81205	1	23-31-12 AE0320/ /	ALL
D04963P		BACC45FT14A15P PLUG-E2-5	81205	1	23-31-12 AE0320/ /	ALL
D04965J		BACC45FN22-55S RCPT-P3	81205	1	34-12-21 AF0120/ /	ALL
D04965P		BACC45FT22-55P PLUG-P3	81205	1	34-12-21 AF0120/ /	ALL

EQUIPMENT LIST

D280T132

Section D04900

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04966J		BACC45FN18-14P7 RCPT-P5	81205	1	30-43-11 AF0111/ /	ALL
D04966P		BACC45FT18-14S7 PLUG-P5	81205	1	30-42-11 AF0111/ /	ALL
D04967J		BACC45FN16-24P9 RCPT-E5-1	81205	1	34-33-21 AC0604/ /	050-099
D04967J		BACC45FN14-15P9 RCPT-E5-1	81205	1	34-33-21 AC0604/ /	150-199, 275-299
D04967P		BACC45FT16A24S9 PLUG-E5-1	81205	1	34-22-91 AC0604/ /	050-099
D04967P		BACC45FT14A15S9 PLUG-E5-1	81205	1	34-33-21 AC0604/ /	150-199, 275-299
D04968J		BACC45FN18-31P6 RCPT-P5	81205	1	30-21-11 AF0111/ /	ALL
D04968P		BACC45FT18-31S6 PLUG-P5	81205	1	30-21-11 AF0111/ /	ALL
D04969J		BACC45FN20-41P7 RCPT-E1-6	81205	1	22-13-31 AE0307/ /	ALL
D04969P		BACC45FT20A41S7 PLUG-E1-6	81205	1	34-22-18 AE0307/ /	ALL
D04970J		BACC45FN18-14P6 RCPT-P5	81205	1	30-43-11 AF0112/ /	ALL
D04970P		BACC45FT18-14S6 PLUG-P5	81205	1	30-42-11 AF0112/ /	ALL
D04972J		BACC45FN18-31P RCPT-P5	81205	1	30-21-11 AF0112/ /	ALL
D04972P		BACC45FT18-31S PLUG-P5	81205	1	33-42-11 AF0112/ /	ALL
D04978J		BACC45FN22-55P6 RCPT-	81205	1	21-25-11 AE0202/ /	ALL
D04978P		BACC45FT22-55S6 PLUG-	81205	1	21-25-11 AE0202/ /	ALL
D04981J		BACC45FN14-15P8 RCPT-MODAL SUPPRESSION ACCELEROMETER	81205	1	22-21-11 SHELF/E01/01	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D04900

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04981P		BACC45FT14A15S8 PLUG-MODAL SUPPRESSION ACCELEROMETER	81205	1	22-21-11 AE0303/ /	150-199, 275-299
D04982J		BACC45FN18-31S RCPT-P7	81205	1	33-11-11 AF0117/ /	ALL
D04982P		BACC45FT18-31P PLUG-	81205	1	33-11-11 AF0117/ /	ALL
D04983J		BACC45FN12-12P6 RCPT-MODAL SUPPRESSION ACCELEROMETER	81205	1	22-21-21 SHELF/E02/01	150-199, 275-299
D04983P		BACC45FT12A12S6 PLUG-MODAL SUPPRESSION ACCELEROMETER	81205	1	22-21-21 SHELF/E02/01	150-199, 275-278
D04983P		BACC45FT12A12S6 PLUG-MODAL SUPPRESSION ACCELEROMETER	81205	1	22-21-21 AE308/ /	280-299
D04984J		BACC45FN18-31S6 RCPT-P7	81205	1	33-11-11 AF0118/ /	ALL
D04984P		BACC45FT18A31P6 PLUG-	81205	1	33-11-11 AF0118/ /	ALL
D04986J		BACC45FN20-25S9 RCPT-P61	81205	1	33-11-14 AF0204/ /	ALL
D04986P		BACC45FT20-25P9 PLUG-P61	81205	1	33-11-13 AF0204/ /	ALL
D04988J		BACC45FM18C14S7 RCPT-	81205	1	32-44-11 AL1007/ /	ALL
D04988P		BACC63BP18R14P7L PLUG-	81205	1	32-41-11 AL1007/ /	ALL
D04988PQ		BACC10KD18 CLAMP-	81205	1	32-41-11 / /	ALL
D04990J		BACC45FN18-31S8 RCPT-P61	81205	1	29-21-32 AF0204/ /	ALL
D04990P		BACC45FT18-31P8 PLUG-P61	81205	1	33-13-18 AF0204/ /	ALL
D04992J		BACC45FN22-55S RCPT-P36	81205	1	29-11-32 AE0209/ /	ALL
D04992P		BACC45FT22-55P PLUG-	81205	1	28-25-21 AE0209/ /	ALL

EQUIPMENT LIST

D280T132

Section D04900

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D04994J		BACC45FN18-31S6 RCPT-P61	81205	1	33-13-13 AF0204/ /	ALL
D04994P		BACC45FT18-31P6 PLUG-P61	81205	1	33-13-13 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D04900
Page 9 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05000J		BACC45FN20-39S9 RCPT-P11	81205	1	21-58-11 AF0203/ /	ALL
D05000P		BACC45FT20-39P9 PLUG-P11	81205	1	21-31-11 AF0203/ /	ALL
D05001J		BACC45FN20-41P7 RCPT-E2-5	81205	1	23-42-11 AE0322/ /	ALL
D05001P		BACC45FT20A41S7 PLUG-E2-5	81205	1	23-42-11 AE0322/ /	ALL
D05006J		BACC45FN20-39S8 RCPT-P11	81205	1	30-11-11 AF0203/ /	ALL
D05006P		BACC45FT20-39P8 PLUG-P11	81205	1	21-43-11 AF0203/ /	ALL
D05009J		MTC100-JH2-R12-AD RCPT-SHELL	06090	1	22-14-31 AE0219/ /	ALL
D05009JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	22-14-31 E8/ /	ALL
D05009JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	22-14-31 E8/ /	ALL
D05009P		MTC100-JH2-P12-AD PLUG-SHELL	06090	1	31-41-16 AE0219/ /	ALL
D05009PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	31-41-16 / /	ALL
D05009PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	31-41-16 / /	ALL
D05010J		BACC45FN18-31S RCPT-P11	81205	1	26-16-11 AF0201/ /	ALL
D05010P		BACC45FT18-31P PLUG-P11	81205	1	33-11-13 AF0201/ /	ALL
D05011J		MTC100-JH2-R12-BA RCPT-SHELL	06090	1	34-53-11 AE0219/ /	ALL
D05011JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	34-53-11 E8/ /	ALL
D05011JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	34-53-11 E8/ /	ALL

EQUIPMENT LIST

D280T132

Section D05000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05011P		MTC100-JH2-P12-BA PLUG-SHELL	06090	1	34-61-14 AE0219/ /	ALL
D05011PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	34-61-14 / /	ALL
D05011PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	34-61-14 / /	ALL
D05012J		BACC45FN16-24S6 RCPT-P11	81205	1	74-31-11 AF0203/ /	ALL
D05012P		BACC45FT16-24P6 PLUG-P11	81205	1	21-33-21 AF0203/ /	ALL
D05014J		BACC45FN16-24S6 RCPT-P7	81205	1	31-25-11 AF0117/ /	ALL
D05014P		BACC45FT16-24P6 PLUG-	81205	1	31-25-11 AF0117/ /	ALL
D05016J		BACC45FN10-5S7 RCPT-P7	81205	1	31-25-11 AF0117/ /	ALL
D05016P		BACC45FT10-5P7 PLUG-	81205	1	33-14-11 AF0117/ /	ALL
D05018J		BACC45FN10-5S8 RCPT-P7	81205	1	31-25-11 AF0118/ /	ALL
D05018P		BACC45FT10-5P8 PLUG-	81205	1	33-14-21 AF0118/ /	ALL
D05020J		BACC45FN16-24S RCPT-P7	81205	1	31-25-11 AF0118/ /	ALL
D05020P		BACC45FT16A24P PLUG-	81205	1	31-25-11 AF0118/ /	ALL
D05022J		BACC63BV24S30S6 RCPT-	81205	1	32-42-11 J00003/LWR/L GR	050-099, 155-199, 275-299
D05022J		BACC63BV18S14S6 RCPT-	81205	1	32-42-11 J00003/LWR/L GR	150-154
D05022P		BACC63BP24S30P6L PLUG-	81205	1	32-42-11 J00003/LWR/L GR	050-099, 155-199, 275-299
D05022P		BACC63BP18S14P6L PLUG-	81205	1	32-42-11 J00003/LWR/L GR	150-154

EQUIPMENT LIST

D280T132

Section D05000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05024J		BACC63BV24B30P6 RCPT-	81205	1	32-42-11 J00001/UPR/L GR	050-099, 155-199, 275-299
D05024J		BACC63BV22S19P6 RCPT-	81205	1	32-42-11 J00001/UPR/L GR	150-154
D05024P		BACC63BP24A30S6L PLUG-	81205	1	32-42-11 J00001/UPR/L GR	050-099, 155-199, 275-299
D05024P		BACC63BP22A19S6L PLUG-	81205	1	32-42-11 J00001/UPR/L GR	150-154
D05024PQ		BACC10KD24 CLAMP-	81205	1	32-42-11 / /	050-099, 155-199, 275-299
D05024PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	150-154
D05026J		BACC63BV24B30PN RCPT-	81205	1	32-42-11 J00001/UPR/L GR	050-099, 155-199, 275-299
D05026J		BACC63BV22S19PN RCPT-	81205	1	32-42-11 J00001/UPR/L GR	150-154
D05026P		BACC63BP24A30SNL PLUG-	81205	1	32-42-11 J00001/UPR/L GR	050-099, 155-199, 275-299
D05026P		BACC63BP22A19SNL PLUG-	81205	1	32-42-11 J00001/UPR/L GR	150-154
D05026PQ		BACC10KD24 CLAMP-	81205	1	32-42-11 / /	050-099, 155-199, 275-299
D05026PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	150-154
D05028J		BACC63BV24S30SN RCPT-	81205	1	32-42-11 J00003/LWR/L GR	050-099, 155-199, 275-299
D05028J		BACC63BV18S14SN RCPT-	81205	1	32-42-11 J00003/LWR/L GR	150-154
D05028P		BACC63BP24S30PNL PLUG-	81205	1	32-42-11 J00003/LWR/L GR	050-099, 155-199, 275-299
D05028P		BACC63BP18S14PNL PLUG-	81205	1	32-42-11 J00003/LWR/L GR	150-154
D05029J		BACC45FN14-15S9 RCPT-E2-5	81205	1	23-31-13 AE0306/ /	050-099

EQUIPMENT LIST

D280T132

Section D05000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05029J		BACC45FN16-24S9 RCPT-E2-5	81205	1	23-31-13 AE0306/ /	150-199, 275-299
D05029P		BACC45FT14A15P9 PLUG-E2-5	81205	1	23-31-13 AE0306/ /	050-099
D05029P		BACC45FT16A24P9 PLUG-E2-5	81205	1	23-31-13 AE0306/ /	150-199, 275-299
D05030J		BACC63BV24B30P6 RCPT-	81205	1	32-42-11 J00002/UPR/R GR	ALL
D05030P		BACC63BP24D30S6 PLUG-	81205	1	32-42-11 J00002/UPR/R GR	ALL
D05030PQ		BACC10KA24 CLAMP-	81205	1	32-42-11 / /	ALL
D05032J		BACC63BV24S30S6 RCPT-	81205	1	32-42-11 J00004/LWR/R GR	050-099, 155-199, 275-299
D05032J		BACC63BV24B30S6 RCPT-	81205	1	32-42-11 J00004/LWR/R GR	150-154
D05032P		BACC63BP24S30P6L PLUG-	81205	1	32-42-11 J00004/LWR/R GR	050-099, 155-199, 275-299
D05032P		BACC63BP24B30P6 PLUG-	81205	1	32-42-11 J00004/LWR/R GR	150-154
D05034J		BACC63BV24B30PN RCPT-	81205	1	32-42-11 J00002/UPR/R GR	050-099, 155-199, 275-299
D05034J		BACC63BV22S19PN RCPT-	81205	1	32-42-11 J00002/UPR/R GR	150-154
D05034P		BACC63BP24A30SNL PLUG-	81205	1	32-42-11 J00002/UPR/R GR	050-099
D05034P		BACC63BP22A19SNL PLUG-	81205	1	32-42-12 J00002/UPR/R GR	150-154
D05034P		BACC63BP24A30SNL PLUG-	81205	1	32-42-12 J00002/UPR/R GR	155-199, 275-299
D05034PQ		BACC10KD24 CLAMP-	81205	1	32-42-11 / /	050-099, 155-199, 275-299
D05034PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	150-154

EQUIPMENT LIST

D280T132

Section D05000

Page 4

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05035J		BACC45FN20-41P9 RCPT-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D05035P		BACC45FT20A41S9 PLUG-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D05036J		BACC63BV24S30SN RCPT-	81205	1	32-42-11 J00004/LWR/R GR	050-099, 155-199, 275-299
D05036J		BACC63BV18S14SN RCPT-	81205	1	32-42-11 J00004/LWR/R GR	150-154
D05036P		BACC63BP24S30PNL PLUG-	81205	1	32-42-11 J00004/LWR/R GR	050-099, 155-199, 275-299
D05036P		BACC63BP18S14PNL PLUG-	81205	1	32-42-11 J00004/LWR/R GR	150-154
D05037J		BACC45FN14-12P7 RCPT-P37	81205	1	27-11-22 AE0218/ /	ALL
D05037P		BACC45FT14-12S7 PLUG-P37	81205	1	27-11-22 AE0218/ /	ALL
D05040J	1	BACC63BV22A12S6 RCPT-NOSE WW DISC	81205	1	32-61-13 AL0202/ /	ALL
D05040J	2	BACC45FM22-12S6 RCPT-NOSE WW DISC	81205	1	32-61-13 AL0202/ /	ALL
D05040JK	1	BACC10KD22 CLAMP STRAIGHT SADDLE	81205	1	32-61-13 AL0202/ /	ALL
D05040JK	2	MS27291-6 CLAMP STRAIGHT SADDLE	81205	1	32-61-13 AL0202/ /	ALL
D05040P		BACC63BP22A12P6L PLUG-NOSE WW DISC	81205	1	32-61-14 AL0202/ /	ALL
D05042J		BACC45FN22-55S7 RCPT-P61	81205	1	26-11-11 AF0204/ /	ALL
D05042P		BACC45FT22-55P7 PLUG-P61	81205	1	26-21-11 AF0204/ /	ALL
D05043J		BACC45FN16-24P8 RCPT-P3-3	81205	1	34-22-81 P003-03/ /	ALL
D05043P		BACC45FT16A24S8 PLUG-P3-3	81205	1	34-22-81 P003-03/ /	ALL

EQUIPMENT LIST

D280T132

Section D05000

Page 5

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05044J		BACC45FM14C7S8 RCPT-	81205	1	26-17-11 AL1003/ /	ALL
D05044P		BACC63BP14R7P8L PLUG-	81205	1	26-17-11 AL1003/ /	ALL
D05044PQ		BACC10KD14 CLAMP-	81205	1	26-17-11 / /	ALL
D05045J		BACC45FN22-55P6 RCPT-P3-3	81205	1	33-16-15 P003-03/ /	ALL
D05045P		BACC45FT22A55S6 PLUG-P3-3	81205	1	34-22-12 P003-03/ /	ALL
D05048J		BACC45FN22-55S RCPT-	81205	1	21-51-11 AC0701/ /	ALL
D05048P		BACC45FT22-55P PLUG-	81205	1	21-51-11 AC0701/ /	ALL
D05051J		MTC100-JH2-R12-DB RCPT-SHELL	06090	1	22-21-11 AE0219/ /	ALL
D05051JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	22-21-11 E8/ /	ALL
D05051JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	22-21-11 E8/ /	ALL
D05051P		MTC100-JH2-P12-DB PLUG-SHELL	06090	1	22-21-11 AE0219/ /	ALL
D05051PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	22-21-11 / /	ALL
D05051PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	22-21-11 / /	ALL
D05052J		BACC45FN22-32S6 RCPT-P37	81205	1	28-22-31 AE0224/ /	ALL
D05052P		BACC45FT22-32P6 PLUG-P37	81205	1	28-22-31 AE0224/ /	ALL
D05054J		BACC45FN14-12S RCPT-E6-1	81205	1	49-15-11 AC1402/ /	ALL
D05054P		BACC45FT14-12P PLUG-E6	81205	1	49-61-11 AC1402/ /	ALL

EQUIPMENT LIST

D280T132

Section D05000

Page 6

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05055J		BACC45FN20-41P RCPT-E8	81205	1	31-41-12 AE0221/ /	ALL
D05055P		BACC45FT20A41S PLUG-E8	81205	1	31-41-13 AE0221/ /	ALL
D05056J		BACC45FN18-31S7 RCPT-	81205	1	21-53-21 AC0702/ /	ALL
D05056P		BACC45FT18A31P7 PLUG-	81205	1	21-51-22 AC0702/ /	ALL
D05057J		BACC45FN20-41P6 RCPT-E8	81205	1	31-41-12 AE0221/ /	ALL
D05057P		BACC45FT20A41S6 PLUG-E8	81205	1	31-41-13 AE0221/ /	ALL
D05058J		BACC45FN16-24S9 RCPT-LH DISC PNL	81205	1	21-51-11 AC0701/ /	ALL
D05058P		BACC45FT16-24P9 PLUG-	81205	1	21-51-11 AC0701/ /	ALL
D05060J		BACC45FN16-24S8 RCPT-	81205	1	21-31-31 AE0209/ /	050-099, 150, 152-199
D05060J		BACC45FN12-12S8 RCPT-	81205	1	21-31-31 AE0209/ /	151, 275-299
D05060P		BACC45FT16-24P8 PLUG-P36	81205	1	28-22-11 AE0209/ /	050-099, 150, 152-199
D05060P		BACC45FT12-12P8 PLUG-P36	81205	1	28-22-11 AE0209/ /	151, 275-299
D05061J		MTC100-JH2-R12-DD RCPT-SHELL	06090	1	34-21-31 AE0219/ /	ALL
D05061JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	34-21-31 E8/ /	ALL
D05061JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	34-21-31 E8/ /	ALL
D05061P		MTC100-JH2-P12-DD PLUG-	06090	1	22-14-31 242/169/L 58	ALL
D05061PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	22-14-31 / /	ALL

EQUIPMENT LIST

D280T132

Section D05000

Page 7

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05061PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	22-14-31 / /	ALL
D05062J		BACC45FN20-28S7 RCPT-P61	81205	1	21-44-11 AF0204/ /	ALL
D05062P		BACC45FT20-28P7 PLUG-P61	81205	1	21-43-11 AF0204/ /	ALL
D05063J		MTC100-JH2-R12-AA RCPT-SHELL	06090	1	22-21-21 AE0219/ /	ALL
D05063JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	22-21-21 E8/ /	ALL
D05063JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	22-21-21 E8/ /	ALL
D05063P		MTC100-JH2-P12-AA PLUG-SHELL,E8	06090	1	22-21-21 AE0219/ /	ALL
D05063PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	22-21-21 / /	ALL
D05063PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	22-21-21 / /	ALL
D05064J		BACC45FN20-39S RCPT-P61	81205	1	30-41-11 AF0204/ /	ALL
D05064P		BACC45FT20-39P PLUG-P61	81205	1	30-41-11 AF0204/ /	ALL
D05065J		BACC45FN18-31S9 RCPT-E2-3	81205	1	22-21-21 AE0320/ /	ALL
D05065P		BACC45FT18A31P9 PLUG-E2-3	81205	1	22-21-21 AE0320/ /	ALL
D05066J		BACC45FN16-24P7 RCPT-E1-1	81205	1	32-42-11 AE0317/ /	ALL
D05066P		BACC45FT16A24S7 PLUG-E1-1	81205	1	32-42-11 AE0317/ /	ALL
D05068J		BACC45FN24-61S9 RCPT-P37	81205	1	26-17-11 AE0218/ /	ALL
D05068P		BACC45FT24-61P9 PLUG-	81205	1	26-17-11 AE0218/ /	ALL

EQUIPMENT LIST

D280T132

Section D05000

Page 8

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05070J		BACC45FN20-39P7 RCPT-P25	81205	1	25-24-11 AP1005/ /	050-099
D05070J		BACC45FN20-39P7 RCPT-	81205	1	25-24-11 AP1005/ /	150-199, 275-299
D05070P		BACC45FT20-39S7 PLUG-P25	81205	1	38-32-11 AP1005/ /	ALL
D05072J		BACC45FN16-10S7 RCPT-P19	81205	1	21-24-11 AP0403/ /	050-099
D05072J		BACC45FN16-10S7 RCPT-	81205	1	25-24-11 AP0403/ /	150-199
D05072P		BACC45FT16-10P7 PLUG-P19	81205	1	21-24-11 AP0403/ /	050-099
D05072P		BACC45FT16-10P7 PLUG-P19	81205	1	25-24-11 AP0403/ /	150-199
D05076J		BACC45FN20-41S RCPT-	81205	1	33-41-11 AP0403/ /	ALL
D05076P		BACC45FT20-41P PLUG-P19	81205	1	33-41-11 AP0403/ /	ALL
D05078J		BACC45FN20-41P8 RCPT-P25	81205	1	33-51-11 AP1005/ /	050-099
D05078J		BACC45FN20-41P8 RCPT-	81205	1	33-51-11 AP1005/ /	150-199, 275-299
D05078P		BACC45FT20-41S8 PLUG-P25	81205	1	33-51-11 AP1005/ /	ALL
D05079J		BACC45FN18-31P8 RCPT-E1-4	81205	1	34-22-35 AE0319/ /	ALL
D05079P		BACC45FT18A31S8 PLUG-E1-4	81205	1	34-22-35 AE0319/ /	ALL
D05080J		BACC45FN16-24P7 RCPT-P25	81205	1	21-51-22 AP1005/ /	050-099
D05080J		BACC45FN16-24P7 RCPT-	81205	1	21-51-22 AP1005/ /	150-199, 275-299
D05080P		BACC45FT16-24S7 PLUG-P25	81205	1	21-51-22 AP1005/ /	ALL

EQUIPMENT LIST

D280T132

Section D05000

Page 9

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05081J		BACC45FN22-55P RCPT-E1-5	81205	1	34-22-24 AE0319/ /	ALL
D05081P		BACC45FT22A55S PLUG-E1-5	81205	1	34-22-24 AE0319/ /	ALL
D05082J		BACC45FN18-31S7 RCPT-	81205	1	21-51-22 AP0403/ /	ALL
D05082P		BACC45FT18-31P7 PLUG-P19	81205	1	21-51-22 AP0403/ /	ALL
D05084J		BACC45FN16-24S6 RCPT-P25	81205	1	33-51-11 AP1003/ /	050-099
D05084J		BACC45FN16-24S6 RCPT-	81205	1	33-51-11 AP1003/ /	150-199, 275-299
D05084P		BACC45FT16-24P6 PLUG-P25	81205	1	33-51-11 AP1003/ /	ALL
D05085J		BACC45FN22-55P9 RCPT-E1-5	81205	1	34-22-25 AE0319/ /	ALL
D05085P		BACC45FT22A55S9 PLUG-E1-5	81205	1	34-22-24 AE0319/ /	ALL
D05086J		BACC45FN16-24S9 RCPT-P25	81205	1	21-51-22 AP1003/ /	050-099
D05086J		BACC45FN18-31S9 RCPT-	81205	1	21-51-22 AP1003/ /	150-199
D05086J		BACC45FN16-24S9 RCPT-	81205	1	21-51-22 AP1003/ /	275-299
D05086P		BACC45FT16-24P9 PLUG-P25	81205	1	21-51-22 AP1003/ /	050-099, 275-299
D05086P		BACC45FT18-31P9 PLUG-P25	81205	1	21-51-22 AP1003/ /	150-199
D05088J		BACC45FN22-55P RCPT-	81205	1	33-21-21 AP0401/ /	ALL
D05088P		BACC45FT22-55S PLUG-P19	81205	1	33-21-21 AP0401/ /	ALL
D05090J		BACC45FN22-55S7 RCPT-	81205	1	21-51-22 AP0401/ /	ALL

EQUIPMENT LIST

D280T132

Section D05000

Page 10

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05090P		BACC45FT22-55P7 PLUG-P19	81205	1	33-22-11 AP0401/ /	ALL
D05096J		BACC45FN20-39S9 RCPT-P25	81205	1	33-24-11 AP1003/ /	050-099
D05096J		BACC45FN20-39S9 RCPT-	81205	1	33-24-11 AP1003/ /	150-199
D05096J		BACC45FN22-19S9 RCPT-	81205	1	33-24-11 AP1003/ /	275-299
D05096P		BACC45FT20-39P9 PLUG-P25	81205	1	33-26-21 AP1003/ /	050-099, 150-199
D05096P		BACC45FT22-19P9 PLUG-P25	81205	1	33-26-21 AP1003/ /	275-299
D05097J		BACC45FN20-41S8 RCPT-E1-2	81205	1	34-22-14 AE0319/ /	ALL
D05097P		BACC45FT20A41P8 PLUG-	81205	1	34-22-14 AE0319/ /	ALL
D05098J		BACC45FN18-14S8 RCPT-P33	81205	1	21-58-21 AE0203/ /	ALL
D05098P		BACC45FT18-14P8 PLUG-P33	81205	1	38-13-11 AE0203/ /	ALL

EQUIPMENT LIST

D280T132

Section D05000
Page 11 End
Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05100J		BACC45FN16-10S7 RCPT-P36	81205	1	25-24-11 AE0209/ /	ALL
D05100P		BACC45FT16-10P7 PLUG-P36	81205	1	38-13-11 AE0209/ /	ALL
D05101J		BACC45FN22-55P6 RCPT-E1-2	81205	1	34-22-15 AE0319/ /	ALL
D05101P		BACC45FT22A55S6 PLUG-	81205	1	34-22-15 AE0319/ /	ALL
D05102J		BACC45FN12-12P8 RCPT-E1-2	81205	1	52-71-11 AE0307/ /	ALL
D05102P		BACC45FT12A12S8 PLUG-E1-2	81205	1	52-71-11 AE0307/ /	ALL
D05104J		BACC45FN14-12S RCPT-P25	81205	1	33-24-12 AP1003/ /	050-099
D05104P		BACC45FT14-12P PLUG-P25	81205	1	33-24-12 AP1003/ /	050-099
D05107J		BACC45FN16-24P6 RCPT-P1-3	81205	1	33-16-13 AF0113/ /	ALL
D05107P		BACC45FT16A24S6 PLUG-P1-3	81205	1	22-14-11 AF0113/ /	ALL
D05108J		BACC45FN14-12S RCPT-P25	81205	1	33-24-14 AP1003/ /	050-099
D05108P		BACC45FT14-12P PLUG-P25	81205	1	33-24-14 AP1003/ /	050-099
D05109J		BACC45FN12-12S7 RCPT-E2-5	81205	1	23-22-11 AE0307/ /	ALL
D05109P		BACC45FT12A12P7 PLUG-E2-5	81205	1	23-22-11 AE0307/ /	050-099
D05109P		BACC45FT12A12P7 PLUG-E2-5	81205	1	23-22-13 AE0307/ /	150-199, 275-299
D05110J		BACC45FN24-57S8 RCPT-P19	81205	1	33-21-11 AP0403/ /	050-099
D05110J		BACC45FN24-57S8 RCPT-	81205	1	33-21-11 AP0403/ /	150-199

EQUIPMENT LIST

D280T132

Section D05100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05110J		BACC45FN24-43S8 RCPT-	81205	1	33-21-11 AP0403/ /	275-299
D05110P		BACC45FT24-57P8 PLUG-P19	81205	1	33-26-11 AP0403/ /	050-099, 150-199
D05110P		BACC45FT24-43P8 PLUG-P19	81205	1	33-26-11 AP0403/ /	275-299
D05111J		BACC45FN18-31S6 RCPT-	81205	1	31-41-11 AF0119/ /	ALL
D05111P		BACC45FT18-31P6 PLUG-P1	81205	1	31-41-11 AF0119/ /	ALL
D05112J		BACC45FN22-19P7 RCPT-P25	81205	1	33-21-12 AP1005/ /	050-099
D05112J		BACC45FN20-28P7 RCPT-	81205	1	33-21-12 AP1005/ /	150-199, 275-299
D05112P		BACC45FT22-19S7 PLUG-P25	81205	1	33-26-11 AP1005/ /	050-099
D05112P		BACC45FT20-28S7 PLUG-P25	81205	1	33-26-11 AP1005/ /	150-199, 275-299
D05113J		BACC45FN18-31S8 RCPT-	81205	1	31-41-11 AF0119/ /	ALL
D05113P		BACC45FT18-31P8 PLUG	81205	1	31-41-11 AF0119/ /	ALL
D05114J		BACC45FN24-43S6 RCPT-P19	81205	1	33-21-31 AP0403/ /	050-099
D05114J		BACC45FN24-43S6 RCPT-	81205	1	33-21-31 AP0403/ /	150-199, 275-299
D05114P		BACC45FT24-43P6 PLUG-P19	81205	1	33-26-11 AP0403/ /	ALL
D05115J		BACC45FN18-31S6 RCPT-	81205	1	31-41-14 AF0119/ /	ALL
D05115P		BACC45FT18-31P6 PLUG-P1	81205	1	31-41-14 AF0119/ /	ALL
D05116J		BACC45FN20-39P6 RCPT-P25	81205	1	33-21-35 AP1005/ /	050-099

EQUIPMENT LIST

D280T132

Section D05100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05116J		BACC45FN20-39P6 RCPT-	81205	1	33-21-35 AP1005/ /	150-199
D05116J		BACC45FN22-19P6 RCPT-	81205	1	33-21-35 AP1005/ /	275-299
D05116P		BACC45FT20-39S6 PLUG-P25	81205	1	33-26-11 AP1005/ /	050-099, 150-199
D05116P		BACC45FT22-19S6 PLUG-P25	81205	1	33-26-11 AP1005/ /	275-299
D05117J		BACC45FN18-31S RCPT-	81205	1	31-41-12 AF0119/ /	ALL
D05117P		BACC45FT18-31P PLUG	81205	1	31-41-12 AF0119/ /	ALL
D05118J		BACC45FN18-14S8 RCPT-P25	81205	1	33-21-12 AP1003/ /	050-099
D05118J		BACC45FN18-14S8 RCPT-	81205	1	33-21-12 AP1003/ /	150-199, 275-299
D05118P		BACC45FT18-14P8 PLUG-P25	81205	1	33-22-42 AP1003/ /	ALL
D05120J		BACC45FN18-14S7 RCPT-P25	81205	1	33-21-35 AP1003/ /	050-099
D05120J		BACC45FN18-31S7 RCPT-	81205	1	33-21-35 AP1003/ /	150-199
D05120J		BACC45FN18-14S7 RCPT-	81205	1	33-21-35 AP1003/ /	275-299
D05120P		BACC45FT18-14P7 PLUG-P25	81205	1	33-22-42 AP1003/ /	050-099, 275-299
D05120P		BACC45FT18-31P7 PLUG-P25	81205	1	33-22-42 1043/310/L 25	150-199
D05122J		BACC45FN20-41P9 RCPT-E1-2	81205	1	27-88-11 AE0319/ /	ALL
D05122P		BACC45FT20A41S9 PLUG-E1-2	81205	1	52-71-11 AE0319/ /	ALL
D05124J		BACC45FN22-55S8 RCPT-P61	81205	1	21-65-11 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D05100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05124P		BACC45FT22-55P8 PLUG-61	81205	1	33-21-21 AF0204/ /	ALL
D05126J		BACC45FN12-12S RCPT-	81205	1	52-11-12 AE0223/ /	ALL
D05126P		BACC45FT12-12P PLUG-P36	81205	1	52-11-11 AE0223/ /	ALL
D05130J		BACC45FN22-55S9 RCPT-E1-2	81205	1	52-11-13 AE0317/ /	ALL
D05130P		BACC45FT22A55P9 PLUG-E1-2	81205	1	33-22-11 AE0317/ /	ALL
D05131J		BACC45FN16-24P6 RCPT-E1-1	81205	1	27-61-15 AE0303/ /	ALL
D05131P		BACC45FT16A24S6 PLUG-E1-1	81205	1	27-61-15 AE0303/ /	ALL
D05133J		BACC45FN14-15P RCPT-E1-1	81205	1	27-61-14 AE0303/ /	ALL
D05133P		BACC45FT14A15S PLUG-E1-1	81205	1	27-61-14 AE0303/ /	ALL
D05134J		BACC45FN24-43P7 RCPT-P19	81205	1	33-21-11 AP0401/ /	050-099
D05134J		BACC45FN22-19P7 RCPT-	81205	1	33-21-11 AP0401/ /	150-157, 275-299
D05134J		BACC45FN24-43P7 RCPT-	81205	1	33-21-11 AP0401/ /	162-199
D05134P		BACC45FT24-43S7 PLUG-P19	81205	1	38-13-11 AP0401/ /	050-099, 162-199
D05134P		BACC45FT22-19S7 PLUG-P19	81205	1	38-13-11 AP0401/ /	150-157, 275-299
D05135J		BACC45FN12-12P8 RCPT-E1-1	81205	1	27-61-16 AE0303/ /	ALL
D05135P		BACC45FT12A12S8 PLUG-E1-1	81205	1	27-61-16 AE0303/ /	ALL
D05136J		BACC45FN20-41S RCPT-	81205	1	21-51-21 AC0702/ /	ALL

EQUIPMENT LIST

D280T132

Section D05100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05136P		BACC45FT20A41P PLUG-	81205	1	21-51-21 AC0702/ /	ALL
D05137J		BACC45FN12-12P9 RCPT-E2-1	81205	1	27-61-17 AE0308/ /	ALL
D05137P		BACC45FT12A12S9 PLUG-E2-1	81205	1	27-61-17 AE0308/ /	ALL
D05138J		BACC45FN16-24S8 RCPT-	81205	1	33-21-21 AP0403/ /	ALL
D05138P		BACC45FT16-24P8 PLUG-P19	81205	1	33-26-21 AP0403/ /	ALL
D05139J		BACC45FN14-15P8 RCPT-E2-1	81205	1	27-41-21 AE0308/ /	ALL
D05139P		BACC45FT14A15S8 PLUG-E2-1	81205	1	27-61-13 AE0308/ /	ALL
D05140J		BACC45FN16-24P6 RCPT-E1-2	81205	1	32-61-14 347/130/L 48	ALL
D05140P		BACC45FT16A24S6 PLUG-E1-2	81205	1	32-61-14 AE0319/ /	ALL
D05141J		BACC45FN12-12P7 RCPT-E2-1	81205	1	27-61-18 AE0308/ /	ALL
D05141P		BACC45FT12A12S7 PLUG-E2-1	81205	1	27-61-18 AE0308/ /	ALL
D05144J		BACC45FN16-24P RCPT-P25	81205	1	21-51-22 AP1005/ /	050-099
D05144J		BACC45FN16-24P RCPT-	81205	1	21-51-22 AP1005/ /	150-199
D05144J		BACC45FN12-12P RCPT-	81205	1	21-51-22 AP1005/ /	275-299
D05144P		BACC45FT16-24S PLUG-P25	81205	1	33-26-21 AP1005/ /	050-099, 150-199
D05144P		BACC45FT12-12S PLUG-P25	81205	1	33-26-21 AP1005/ /	275-299
D05148J		BACC45FN22-55S7 RCPT-	81205	1	33-21-21 AP0403/ /	050-099, 275-299

EQUIPMENT LIST

D280T132

Section D05100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05148J		BACC45FN24-57S7 RCPT-	81205	1	33-21-21 AP0403/ /	150, 152-199
D05148J		BACC45FN20-41S7 RCPT-	81205	1	33-21-21 AP0403/ /	151
D05148P		BACC45FT22-55P7 PLUG-P19	81205	1	33-22-31 AP0403/ /	050-099, 275-299
D05148P		BACC45FT24-57P7 PLUG-P19	81205	1	33-22-31 AP0403/ /	150, 152-199
D05148P		BACC45FT20-41P7 PLUG-P19	81205	1	33-22-31 AP0403/ /	151
D05150J		BACC45FN16-24P6 RCPT-P25	81205	1	33-21-21 AP1005/ /	050-099
D05150J		BACC45FN16-24P6 RCPT-	81205	1	33-21-21 AP1005/ /	150-199, 275-299
D05150P		BACC45FT16-24S6 PLUG-25	81205	1	33-22-31 AP1005/ /	ALL
D05151J		BACC45FN16-24S7 RCPT-E2-2	81205	1	31-51-60 AE0307/ /	ALL
D05151P		BACC45FT16A24P7 PLUG-E2-2	81205	1	31-51-60 AE0307/ /	ALL
D05153J		BACC45FN16-24P7 RCPT-E1-6	81205	1	31-51-60 AE0307/ /	ALL
D05153P		BACC45FT16A24S7 PLUG-E1-6	81205	1	34-61-12 AE0307/ /	ALL
D05154J		BACC45FN24-43S8 RCPT-P25	81205	1	33-21-21 AP1003/ /	050-099
D05154J		BACC45FN24-43S8 RCPT-	81205	1	33-21-21 AP1003/ /	150-199, 275-299
D05154P		BACC45FT24-43P8 PLUG-P25	81205	1	33-21-21 AP1003/ /	ALL
D05155J		BACC45FN10-5P RCPT-	81205	1	23-34-13 0510/260/L85	050-099
D05155J		BACC45FN10-5P RCPT-	81205	1	23-34-16 0423/260/L085	150-199, 276-299

EQUIPMENT LIST

D280T132

Section D05100

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05155J		BACC45FN10-5P RCPT-	81205	1	23-34-16 0383/260/L085	275
D05157J		BACC45FN10-5P RCPT-	81205	1	23-34-14 0900/260/L085	050-099
D05157J		BACC45FN10-5P RCPT-	81205	1	23-34-16 690/260/L085	150-199
D05157J		BACC45FN10-5P RCPT-	81205	1	23-34-16 0580/260/L085	275-278
D05159J		BACC45FN10-5P RCPT-	81205	1	23-34-15 0574/260/R085	275-299
D05160J		BACC45FN20-39S7 RCPT-	81205	1	33-24-11 AP0401/ /	ALL
D05160P		BACC45FT20-39P7 PLUG-P19	81205	1	33-26-21 AP0401/ /	ALL
D05161J		BACC45FN10-5P RCPT-	81205	1	23-34-15 0904/315/L015	050-099
D05161J		BACC45FN10-5P RCPT-	81205	1	23-34-17 0646/315/L015	150-199, 275-278
D05162J		BACC45FN14-12S8 RCPT-	81205	1	33-24-11 AP0403/ /	ALL
D05162P		BACC45FT14-12P8 PLUG-P19	81205	1	33-24-13 AP0403/ /	ALL
D05165J		BACC45FN12-12P RCPT-	81205	1	27-11-12 AE0209/ /	ALL
D05165P		BACC45FT12-12S RCPT-P36	81205	1	27-11-12 AE0209/ /	ALL
D05166J		BACC45FN14-12S RCPT-	81205	1	33-24-11 AP0403/ /	ALL
D05166P		BACC45FT14-12P PLUG-P19	81205	1	33-24-14 AP0403/ /	050-099, 150-199, 275-278
D05166P		BACC45FT14-12P PLUG-P19	81205	1	33-24-14 APO403-/-/	280-299
D05167J		BACC45FN12-3P6 RCPT-	81205	1	27-11-11 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D05100

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05167P		BACC45FT12A3S6 PLUG-E1-2	81205	1	27-11-11 AE0305/ /	ALL
D05168J		BACC45FN14-12P8 RCPT-P25	81205	1	33-24-14 AP1005/ /	050-099
D05168P		BACC45FT14-12S8 PLUG-P25	81205	1	33-24-14 AP1005/ /	050-099
D05170J		BACC45FN22-55P6 RCPT-	81205	1	33-21-11 AP0401/ /	050-099, 162-199
D05170J		BACC45FN20-41P6 RCPT-	81205	1	33-21-11 AP0401/ /	150-157, 275-299
D05170P		BACC45FT22-55S6 PLUG-19	81205	1	33-22-21 AP0401/305/L30	050-099
D05170P		BACC45FT20-41S6 PLUG-19	81205	1	33-22-21 AP0401/ /	150-157, 275-299
D05170P		BACC45FT22-55S6 PLUG-19	81205	1	33-22-21 AP0401/ /	162-199
D05172J		BACC45FN16-24S8 RCPT-P33	81205	1	33-22-21 AE0203/ /	ALL
D05172P		BACC45FT16-24P8 PLUG-P33	81205	1	33-22-21 AE0203/ /	ALL
D05178J		BACC45FN18-31P6 RCPT-	81205	1	21-51-12 AP0401/ /	ALL
D05178P		BACC45FT18-31S6 PLUG-P19	81205	1	33-26-21 AP0401/ /	ALL
D05180J		BACC45FN20-41S9 RCPT-P61	81205	1	21-61-21 AF0204/ /	ALL
D05180P		BACC45FT20-41P9 PLUG-P61	81205	1	33-26-21 AF0204/ /	ALL
D05181J		BACC45FN10-5P RCPT-	81205	1	23-34-15 1450/315/L015	050-099
D05181J		BACC45FN10-5P RCPT-	81205	1	23-34-19 1450/315/L015	150-199, 275-299
D05182J		BACC45FN14-12S9 RCPT-	81205	1	33-24-11 AP0403/ /	ALL

EQUIPMENT LIST

D280T132

Section D05100

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05182P		BACC45FT14-12P9 PLUG-P19	81205	1	33-24-12 AP0403/ /	ALL
D05184J		BACC45FN14-12S9 RCPT-P25	81205	1	33-24-12 AP1005/ /	050-099
D05184P		BACC45FT14-12P9 PLUG-P25	81205	1	33-24-12 AP1005/ /	050-099
D05185J		BACC45FN10-5P RCPT-	81205	1	23-34-15 1167/315/L015	050-099
D05185J		BACC45FN10-5P RCPT-	81205	1	23-34-19 1152/315/L015	150-199, 275-278
D05185J		BACC45FN10-5P RCPT-	81205	1	23-34-19 1161/315/L015	280-299
D05186J		BACC45FN18-31S8 RCPT-P61	81205	1	21-31-11 AF0204/ /	ALL
D05186P		BACC45FT18-31P8 PLUG-P61	81205	1	29-21-32 AF0204/ /	ALL
D05187J		BACC45FN14-15S9 RCPT-P11	81205	1	22-11-32 AF0203/ /	ALL
D05187P		BACC45FT14A15P9 PLUG-P11	81205	1	22-11-32 AF0203/ /	ALL
D05188J		BACC45FN16-24P8 RCPT-P37	81205	1	27-11-22 AE0218/ /	ALL
D05188P		BACC45FT16-24S8 PLUG-	81205	1	28-41-11 AE0218/ /	ALL
D05189J		BACC45FN10A5P8 RCPT-E5-1	81205	1	34-33-31 AC0604/ /	ALL
D05189P		BACC45FT10A5S8 PLUG-E5-1	81205	1	34-33-31 AC0604/ /	ALL
D05190J		BACC63BV22F19S8 RCPT-	81205	1	28-42-11 AL1002/ /	ALL
D05190JK		BACC10KD22 CLAMP-	81205	1	27-62-11 AL1002/ /	ALL
D05190P		BACC63BP22C19P8 PLUG-R WING/BODY RS DISC	81205	1	32-42-11 AL1002/ /	ALL

EQUIPMENT LIST

D280T132

Section D05100

Page 9

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05190PQ		BACC10KD22 CLAMP-	81205	1	32-42-11 / /	ALL
D05191J		BACC45FN18-8P6 RCPT-P33	81205	1	23-34-11 AE0207/ /	ALL
D05191P		BACC45FT18-8S6 PLUG-P33	81205	1	23-34-11 AE0207/ /	ALL
D05192J		BACC45FN12-12P6 RCPT-	81205	1	21-53-12 AE0223/ /	ALL
D05192P		BACC45FT12-12S6 PLUG-P36	81205	1	21-53-12 AE0223/ /	ALL
D05193J		BACC45FN16-24P9 RCPT-P33	81205	1	23-34-11 AE0207/ /	050-099, 157, 167- 199, 277-299
D05193J		BACC45FN16-24P9 RCPT-P33	81205	1	23-34-11 P033/ /	150-156, 162-166, 275-276
D05193P		BACC45FT16-24S9 PLUG-P33	81205	1	23-34-11 AE0207/ /	ALL
D05195J		BACC45FN20-25P9 RCPT-P33	81205	1	23-34-11 AE0203/ /	ALL
D05195P		BACC45FT20-25S9 PLUG-P33	81205	1	23-34-11 AE0203/ /	ALL
D05196J		BACC45FN22-55S7 RCPT-	81205	1	28-21-11 AE0307/ /	ALL
D05196P		BACC45FT22A55P7 PLUG-E2-4	81205	1	28-41-11 AE0307/ /	ALL
D05197J		BACC45FN10-5P RCPT-	81205	1	23-34-15 0423/260/R085	050-099, 276-299
D05197J		BACC45FN10-5P RCPT-	81205	1	23-34-15 423/260/R085	150-157
D05197J		BACC45FN10-5P RCPT-	81205	1	23-34-15 0440/260/R085	162-199
D05197J		BACC45FN10-5P RCPT-	81205	1	23-34-15 0383/260/R085	275
D05199J		BACC45FN10-5P RCPT-	81205	1	23-34-13 0460/315/L015	050-099

EQUIPMENT LIST

D280T132

Section D05100

Page 10

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05199J		BACC45FN10-5P RCPT-	81205	1	23-34-17 0375/315/L015	150-152, 275-299
D05199J		BACC45FN10-5P RCPT-	81205	1	23-34-17 0385/315/L015	153-157
D05199J		BACC45FN10-5P RCPT-	81205	1	23-34-17 0460/315/L015	162-199

EQUIPMENT LIST

D280T132

Section D05100
Page 11 End
Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05201J		BACC45FN18-31S8 RCPT-E2-2	81205	1	34-46-11 AE0306/ /	ALL
D05201P		BACC45FT18A31P8 PLUG-E2-2	81205	1	34-61-14 AE0306/ /	ALL
D05202J		BACC45FN16-24P9 RCPT-E2-4	81205	1	27-51-41 AE0306/ /	ALL
D05202P		BACC45FT16A24S9 PLUG-E2-4	81205	1	28-41-11 AE0306/ /	ALL
D05203J		BACC45FN20-41S7 RCPT-E2-2	81205	1	31-51-41 AE0306/ /	ALL
D05203P		BACC45FT20A41P7 PLUG-E2-2	81205	1	31-51-41 AE0306/ /	ALL
D05204J		BACC45FN14-15S RCPT-E2-4	81205	1	21-31-21 AE0320/ /	ALL
D05204P		BACC45FT14A15P PLUG-E2-4	81205	1	21-51-21 AE0320/ /	ALL
D05205J		BACC45FN22-55P6 RCPT-E1-2	81205	1	34-22-18 AE0305/ /	ALL
D05205P		BACC45FT22A55S6 PLUG-	81205	1	22-41-11 AE0305/ /	ALL
D05206J		BACC45FN12-12P RCPT-E2-4	81205	1	24-28-21 AE0307/ /	ALL
D05206P		BACC45FT12A12S PLUG-E2-4	81205	1	24-28-21 AE0307/ /	ALL
D05207J		BACC45FN22-55S8 RCPT-E2-3	81205	1	22-14-11 AE0306/ /	050-099, 150-152, 155-199, 275-299
D05207J		BACC45FN18-31S8 RCPT-E2-3	81205	1	22-14-11 AE0306/ /	153-154
D05207P		BACC45FT22A55P8 PLUG-E2-3	81205	1	31-31-12 AE0306/ /	050-099, 150-152, 155-199, 277-299
D05207P		BACC45FT18A31P8 PLUG-E2-3	81205	1	31-31-12 AE0306/ /	153-154, 275-276
D05209J		BACC45FN16-24P7 RCPT-	81205	1	34-61-13 AE0202/ /	ALL

EQUIPMENT LIST

D280T132

Section D05200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05209P		BACC45FT16-24S7 PLUG-P50 CARD FILE,ELECTRICAL SYSTEMS	81205	1	34-61-13 AE0202/ /	ALL
D05210J		BACC45FN14-15S6 RCPT-	81205	1	32-44-11 AE0307/ /	ALL
D05210P		BACC45FT14-15P6 PLUG-E1-1	81205	1	32-44-11 AE0307/ /	ALL
D05210PQ		BACC10GH14 CLAMP-	81205	1	32-44-11 / /	ALL
D05211J		BACC45FM14C7P6 RCPT-	81205	1	27-61-16 AL1001/ /	ALL
D05211P		BACC63BP14R7S6L PLUG-	81205	1	27-61-16 AL1001/ /	ALL
D05211PQ		BACC10KD14 CLAMP-	81205	1	27-61-16 / /	ALL
D05212J		BACC45FN14-15P9 RCPT-E2-4	81205	1	29-11-12 AE0306/ /	ALL
D05212P		BACC45FT14A15S9 PLUG-E2-4	81205	1	22-15-11 AE0306/ /	ALL
D05213J		BACC45FM14C7P RCPT-	81205	1	27-61-15 AL1005/ /	ALL
D05213P		BACC63BP14R7SNL PLUG-	81205	1	27-61-15 AL1005/ /	ALL
D05213PQ		BACC10KD14 CLAMP-	81205	1	27-61-15 / /	ALL
D05214J		BACC45FN14-15P9 RCPT-P35	81205	1	26-16-21 AC0506/ /	ALL
D05214P		BACC45FT14-15S9 PLUG-P35	81205	1	26-16-21 AC0506/ /	ALL
D05215J		BACC45FM14B7P6 RCPT-	81205	1	27-61-14 AL0901/ /	ALL
D05215P		BACC63BP14R7S6L PLUG-	81205	1	27-61-14 AL0901/ /	ALL
D05215PQ		BACC10KD14 CLAMP-	81205	1	27-61-14 / /	ALL

EQUIPMENT LIST

D280T132

Section D05200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05216J		BACC45FN16-24S8 RCPT-P35	81205	1	25-53-11 AC0506/ /	ALL
D05216P		BACC45FT16-24P8 PLUG-P35	81205	1	25-53-11 AC0506/ /	ALL
D05217J		BACC45FM14B7P7 RCPT-	81205	1	27-61-14 AL0902/ /	ALL
D05217P		BACC63BP14R7S7L PLUG-	81205	1	27-61-14 AL0902/ /	ALL
D05217PQ		BACC10KD14 CLAMP-	81205	1	27-61-14 / /	ALL
D05218J		BACC45FN22-55S6 RCPT-P35	81205	1	25-53-15 AC0506/ /	ALL
D05218P		BACC45FT22-55P6 PLUG-P35	81205	1	25-53-15 AC0506/ /	ALL
D05219J		BACC45FM14C7P RCPT-	81205	1	27-61-15 AL1006/ /	ALL
D05219P		BACC63BP14R7SNL PLUG-	81205	1	27-61-15 AL1006/ /	ALL
D05219PQ		BACC10KD14 CLAMP-	81205	1	27-61-15 / /	ALL
D05220J		BACC45FN20-16S7 RCPT-P35	81205	1	25-53-12 AC0506/ /	ALL
D05220P		BACC45FT20-16P7 PLUG-P35	81205	1	25-53-12 AC0506/ /	ALL
D05221J		BACC45FM14C7P7 RCPT-	81205	1	27-61-16 AL1002/ /	ALL
D05221P		BACC63BP14R7S7L PLUG-	81205	1	27-61-16 AL1002/ /	ALL
D05221PQ		BACC10KD14 CLAMP-	81205	1	27-61-16 / /	ALL
D05222J		BACC45FN18-14S RCPT-P35	81205	1	25-53-12 AC0506/ /	ALL
D05222P		BACC45FT18-14P PLUG-P35	81205	1	25-53-12 AC0506/ /	ALL

EQUIPMENT LIST

D280T132

Section D05200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05223J		BACC45FN16-24P6 REPT-E1-2	81205	1	31-35-13 AE0305/ /	050-099
D05223J		BACC45FN16-24P6 RCPT-E1-2	81205	1	34-22-38 AE0305/ /	150-199, 275-299
D05223P		BACC45FT16A24S6 PLUG-E1-2	81205	1	34-22-38 AE0305/ /	ALL
D05224J		BACC45FN20-41S7 RCPT-P35	81205	1	25-53-14 AC0506/ /	050-099
D05224J		BACC45FN22-55S7 RCPT-P35	81205	1	25-53-14 AC0506/ /	150-199, 275-299
D05224P		BACC45FT20-41P7 PLUG-P35	81205	1	25-53-14 AC0506/ /	050-099
D05224P		BACC45FT22-55P7 PLUG-P35	81205	1	25-53-14 AC0506/ /	150-199, 275-299
D05225J		BACC45FN14-15P8 RCPT-E2-3	81205	1	31-31-15 327/124/0	050-099, 155-199, 276-299
D05225J		BACC45FN14-15P8 RCPT-E2-3	81205	1	31-31-15 AE0307/ /	150-154, 275
D05225P		BACC45FT14A15S8 PLUG- E2-3	81205	1	31-31-18 AE0307/ /	ALL
D05227J		BACC45FN22-55S6 RCPT-E2-3	81205	1	22-14-11 AE0306/ /	050-099, 150-199
D05227J		BACC45FN20-41S6 RCPT-E2-3	81205	1	22-14-11 AE0306/ /	275-299
D05227P		BACC45FT22A55P6 PLUG-E2-3	81205	1	22-14-11 AE0306/ /	050-099, 150-199
D05227P		BACC45FT20A41P6 PLUG-E2-3	81205	1	22-14-11 AE0306/ /	275-299
D05229J		BACC45FN20-41S8 RCPT-E2-3	81205	1	31-31-13 AE0306/ /	ALL
D05229P		BACC45FT20A41P8 PLUG-E2-3	81205	1	31-31-12 AE0306/ /	ALL
D05230J		BACC45FN14-15P6 RCPT-E1-1	81205	1	28-42-11 AE0317/ /	ALL

EQUIPMENT LIST

D280T132

Section D05200

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05230P		BACC45FT14A15S6 PLUG-E1-1	81205	1	32-42-11 AE0317/ /	ALL
D05233J		BACC45FM14B7P RCPT-	81205	1	27-61-13 AL0901/ /	ALL
D05233P		BACC63BP14R7SNL PLUG-	81205	1	27-61-13 AL0901/ /	ALL
D05233PQ		BACC10KD14 CLAMP-	81205	1	27-61-13 / /	ALL
D05235J		BACC45FM14C7P9 RCPT-	81205	1	27-61-17 AL1005/ /	ALL
D05235P		BACC63BP14R7S9L PLUG-	81205	1	27-61-17 AL1005/ /	050-099
D05235P		BACC63BP14R7S9L PLUG-	81205	1	27-61-17 1043/193/L057	150-199, 275-299
D05235PQ		BACC10KD14 CLAMP-	81205	1	27-61-17 / /	ALL
D05237J		BACC45FM14B7P7 RCPT-	81205	1	27-61-18 AL0901/ /	ALL
D05237P		BACC63BP14R7S7L PLUG-1	81205	1	27-61-18 AL0901/ /	050-099
D05237P		BACC63BP14R7S7L PLUG-1	81205	1	27-61-18 0977/178/L092	150-199, 275-299
D05237PQ		BACC10KD14 CLAMP-	81205	1	27-61-18 / /	ALL
D05239J		BACC45FM14B7P RCPT-	81205	1	27-61-18 AL0902/ /	ALL
D05239P		BACC63BP14R7SNL PLUG-2	81205	1	27-61-18 AL0902/ /	050-099
D05239P		BACC63BP14R7SNL PLUG-2	81205	1	27-61-18 0977/178/R092	150-199, 275-299
D05239PQ		BACC10KD14 CLAMP-	81205	1	27-61-18 / /	ALL
D05241J		BACC45FM14C7P9 RCPT-	81205	1	27-61-17 AL1006/ /	ALL

EQUIPMENT LIST

D280T132

Section D05200

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05241P		BACC63BP14R7S9L PLUG-	81205	1	27-61-17 AL1006/ /	050-099
D05241P		BACC63BP14R7S9L PLUG-	81205	1	27-61-17 1043/193/R057	150-199, 275-299
D05241PQ		BACC10KD14 CLAMP-	81205	1	27-61-17 / /	ALL
D05243J		BACC45FM14B7P6 RCPT-	81205	1	27-61-13 AL0902/ /	ALL
D05243P		BACC63BP14R7S6L PLUG-	81205	1	27-61-13 AL0902/ /	ALL
D05243PQ		BACC10KD14 CLAMP	81205	1	27-61-13 / /	ALL
D05247J		BACC45FN22-55S RCPT-E1-3	81205	1	22-14-11 AE0319/ /	ALL
D05247P		BACC45FT22A55P PLUG-E1-3	81205	1	34-21-11 AE0319/ /	ALL
D05250J		BACC45FN16-24S8 RCPT-P39	81205	1	25-53-21 AC1304/ /	ALL
D05250P		BACC45FT16-24P8 PLUG-P39	81205	1	25-53-21 AC1304/ /	ALL
D05251J		BACC45FN10-5P RCPT-	81205	1	23-34-16 0688/265/L085	280-299
D05252J		BACC45FN18-31S6 RCPT-P39	81205	1	25-53-25 AC1304/ /	ALL
D05252P		BACC45FT18-31P6 PLUG-P39	81205	1	25-53-25 AC1304/ /	ALL
D05253J		BACC45FN10-5P RCPT-	81205	1	23-34-17 0686/315/L013	280-299
D05254J		BACC45FN20-16S7 RCPT-P39	81205	1	25-53-22 AC1304/ /	ALL
D05254P		BACC45FT20-16P7 PLUG-P39	81205	1	25-53-22 AC1304/ /	ALL
D05255J		BACC45FN22-55S RCPT-P1	81205	1	22-14-11 AF0119/ /	ALL

EQUIPMENT LIST

D280T132

Section D05200

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05255P		BACC45FT22D55P PLUG-P1	81205	1	22-14-11 AF0119/ /	ALL
D05256J		BACC45FN18-14S RCPT-P39	81205	1	25-53-22 AC1304/ /	ALL
D05256P		BACC45FT18-14P PLUG-P39	81205	1	25-53-22 AC1304/ /	ALL
D05257J		BACC45FN12-12P7 RCPT-E1-5	81205	1	34-46-11 AE0305/ /	ALL
D05257P		BACC45FT12A12S7 PLUG-E1-5	81205	1	34-46-11 AE0305/ /	ALL
D05258J		BACC45FN20-41S7 RCPT-P39	81205	1	25-53-24 AC1304/ /	ALL
D05258P		BACC45FT20-41P7 PLUG-P39	81205	1	25-53-24 AC1304/ /	ALL
D05259J		BACC45FN18-31P7 RCPT-E1-3	81205	1	22-32-11 AE0305/ /	ALL
D05259P		BACC45FT18A31S7 PLUG-E1-3	81205	1	22-31-12 AE0305/ /	ALL
D05266J		BACC45FN16-24P RCPT-P37	81205	1	28-42-11 AE0218/ /	ALL
D05266P		BACC45FT16-24S PLUG-P37	81205	1	28-42-11 AE0218/ /	ALL
D05270J		BACC45FN20-41P9 RCPT-P37	81205	1	28-25-11 AE0218/ /	ALL
D05270P		BACC45FT20-41S9 PLUG-P37	81205	1	28-25-11 AE0218/ /	ALL
D05275J		BACC45FN10-5P RCPT-	81205	1	23-34-15 0684/260/R085	280-299
D05277J		BACC45FN20-41P9 RCPT-	81205	1	73-21-16 AE0202/ /	ALL
D05277P		BACC45FT20-41S9 PLUG-P50	81205	1	22-32-12 AE0202/ /	ALL
D05281J		BACC45FN18-31P RCPT-E1-2	81205	1	27-32-11 AE0307/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D05200

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05281J		BACC45FN14-15P RCPT-E1-2	81205	1	27-32-11 AE0307/ /	275-299
D05281P		BACC45FT18A31S PLUG-E1-2	81205	1	27-32-11 AE0307/ /	050-099, 150-199
D05281P		BACC45FT14A15S PLUG-E1-2	81205	1	27-32-11 AE0307/ /	275-299
D05282J		BACC45FN20-41S6 RCPT-P61	81205	1	21-61-11 AF0204/ /	ALL
D05282P		BACC45FT20-41P6 PLUG-P61	81205	1	21-65-11 AF0204/ /	ALL
D05287		MB6R-3 RCPT-	09922	1	23-34-15 0639/208/R095	280-299
D05287 T		KIT700-43 COAX CONTACT-	09922	1	23-34-15 / /	280-299
D05287 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-15 / /	280-299
D05288J		BACC45FN12-12S8 RCPT-	81205	1	32-42-11 AE0306/ /	ALL
D05288P		BACC45FT12A12P8 PLUG-E2-4	81205	1	32-46-11 AE0306/ /	ALL
D05289		MB6R-3 RCPT-	09922	1	23-34-15 0684/208/R095	280-299
D05289 T		KIT700-43 COAX CONTACT-	09922	1	23-34-15 / /	280-299
D05289 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-15 / /	280-299
D05290J		BACC45FN20-25S8 RCPT-P37	81205	1	33-31-41 AE0218/ /	ALL
D05290P		BACC45FT20-25P8 PLUG-	81205	1	21-58-14 AE0218/ /	ALL
D05292J		BACC45FN12-12P8 RCPT-E2-4	81205	1	32-46-11 AE0320/ /	ALL
D05292P		BACC45FT12A12S8 PLUG-E2-4	81205	1	32-46-11 AE0320/ /	ALL

EQUIPMENT LIST

D280T132

Section D05200

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05293J		BACC45FN16-24P8 RCPT-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D05293P		BACC45FT16A24S8 PLUG-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D05294J		BACC45FN12-12P8 RCPT-E2-4	81205	1	32-46-11 AE0306/ /	ALL
D05294P		BACC45FT12A12S8 PLUG-E2-4	81205	1	32-46-11 AE0306/ /	ALL
D05295		MB6R-3 RCPT-	09922	1	23-34-17 588/198/L 15	150-199
D05295		MB6R-3 RCPT-	09922	1	23-34-17 590/198/L 15	280-299
D05295 T		KIT700-43 COAX CONTACT-	09922	1	23-34-17 / /	150-199, 280-299
D05295 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-17 / /	150-199, 280-299
D05297		MB6R-3 RCPT-	09922	1	23-34-17 698/198/L 15	150-199
D05297		MB6R-3 RCPT-	09922	1	23-34-17 700/198/L 15	280-299
D05297 T		KIT700-43 COAX CONTACT-	09922	1	23-34-17 / /	150-199, 280-299
D05297 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-17 / /	150-199, 280-299

EQUIPMENT LIST

D280T132

Section D05200

Page 9 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05300J		BACC45FN24-61P9 RCPT-	81205	1	71-51-11 AE0209/ /	ALL
D05300P		BACC45FT24-61S9 PLUG-P36	81205	1	71-01-11 AE0209/ /	ALL
D05303J		KM-19-08 RCPT-E2-5 COAXIAL	91836	1	23-34-17 AE0307/ /	050-099
D05303J		KM-19-08 RCPT-E2-5 COAXIAL	91836	1	23-34-14 AE0307/ /	150-199, 275-299
D05303P		KM-59-41 PLUG-E2-5 COAXIAL	91836	1	23-34-17 AE0307/ /	050-099
D05303P		KM-59-41 PLUG-E2-5 COAXIAL	91836	1	23-34-14 AE0307/ /	150-199, 275-299
D05305J		BACC45FN22-55P8 RCPT-P3-1	81205	1	31-51-31 AF0116/ /	ALL
D05305P		BACC45FT22A55S8 PLUG-P3-1	81205	1	31-51-31 AF0116/ /	ALL
D05306J		BACC45FN22-55P8 RCPT-P36	81205	1	78-31-11 AE0209/ /	ALL
D05306P		BACC45FT22-55S8 PLUG-P36	81205	1	74-31-11 AE0209/ /	ALL
D05307J		BACC45FN20-41P7 RCPT-E1-1	81205	1	22-21-11 AE0303/ /	ALL
D05307P		BACC45FT20A41S7 PLUG-E1-1	81205	1	22-21-11 AE0303/ /	ALL
D05308J		BACC45FN20-41P6 RCPT-P36	81205	1	22-33-11 AE0209/ /	ALL
D05308P		BACC45FT20-41S6 PLUG-P36	81205	1	22-33-11 AE0209/ /	ALL
D05309J		BACC45FN18-31P6 RCPT-P3-1	81205	1	33-16-15 AF0116/ /	ALL
D05309P		BACC45FT18A31S6 PLUG-P3-1	81205	1	33-16-15 AF0116/ /	ALL
D05310J		BACC45FN14-12S7 RCPT-	81205	1	27-28-13 AE0209/ /	050-099, 150-154, 162-165, 275-276

EQUIPMENT LIST

D280T132

Section D05300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05310J		BACC45FN14-15S7 RCPT-	81205	1	27-28-13 AE0209/ /	155-157, 166-199, 277-299
D05310P		BACC45FT14-12P7 PLUG-P36	81205	1	27-21-11 AE0209/ /	050-099, 150-154, 162-165, 275-276
D05310P		BACC45FT14-15P7 PLUG-P36	81205	1	27-21-11 AE0209/ /	155-157, 166-199, 277-299
D05311J		BACC45FN18-31P6 RCPT-P61	81205	1	31-41-13 AF0204/ /	ALL
D05311P		BACC45FT18-31S6 PLUG-P61	81205	1	31-41-12 AF0204/ /	ALL
D05312J		BACC45FN14-15S6 RCPT-P36	81205	1	27-38-11 AE0209/ /	ALL
D05312P		BACC45FT14-15P6 PLUG-P36	81205	1	27-23-11 AE0209/ /	ALL
D05313J		BACC45FN10-5S7 RCPT-P36	81205	1	27-09-13 AE0209/ /	ALL
D05313P		BACC45FT10A5P7 PLUG-P36	81205	1	27-09-13 AE0209/ /	ALL
D05315J		BACC45FN12-12P9 RCPT-P36	81205	1	27-61-22 AE0209/ /	ALL
D05315P		BACC45FT12A12S9 PLUG-P36	81205	1	27-09-12 AE0209/ /	ALL
D05316J		BACC45FN24-61P7 RCPT-P37	81205	1	27-81-11 AE0218/ /	ALL
D05316P		BACC45FT24-61S7 PLUG-P37	81205	1	27-81-11 AE0218/ /	ALL
D05317J		BACC45FN12-12P6 RCPT-P37	81205	1	27-61-22 AE0218/ /	ALL
D05317P		BACC45FT12A12S6 RCPT-P37	81205	1	27-61-22 AE0218/ /	ALL
D05318J		BACC45FN16-24S7 RCPT-P37	81205	1	27-23-11 AE0218/ /	050-099, 150, 152- 199
D05318J		BACC45FN14-7S7 RCPT-P37	81205	1	27-23-11 AE0218/ /	151, 275-299

EQUIPMENT LIST

D280T132

Section D05300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05318P		BACC45FT16-24P7 PLUG-P37	81205	1	27-23-11 AE0218/ /	050-099, 150, 152-199
D05318P		BACC45FT14-7P7 PLUG-P37	81205	1	27-23-11 AE0218/ /	151, 275-299
D05319J		BACC45FN10-5S6 RCPT-P37	81205	1	27-61-22 AE0224/ /	ALL
D05319P		BACC45FT10A5P6 PLUG-P37	81205	1	27-61-12 AE0224/ /	ALL
D05322J		BACC45FN14-4S9 RCPT-P33	81205	1	27-51-11 AE0203/ /	ALL
D05322P		BACC45FT14-4P9 PLUG-P33	81205	1	27-51-11 AE0203/ /	ALL
D05323J		BACC45FN16-24P9 RCPT-E1-1	81205	1	22-21-11 AE0303/ /	ALL
D05323P		BACC45FT16A24S9 PLUG-E1-1	81205	1	22-21-21 AE0303/ /	ALL
D05325J		BACC45FN14-12P6 RCPT-E1-1	81205	1	27-09-11 AE0303/ /	ALL
D05325P		BACC45FT14A12S6 PLUG-E1-1	81205	1	27-09-11 AE0303/ /	ALL
D05326J		BACC45FN22-55P RCPT-P37	81205	1	74-31-21 AE0218/ /	ALL
D05326P		BACC45FT22-55S PLUG-P37	81205	1	74-31-21 AE0218/ /	ALL
D05327J		BACC45FN10-5S RCPT-	81205	1	23-42-11 0354/284/L040	150-157, 275-299
D05327P		BACC45FT10-5P PLUG-	81205	1	23-42-11 0354/284/L040	150-157, 275-299
D05328J		BACC45FN20-41P7 RCPT-P37	81205	1	71-51-11 AE0218/ /	ALL
D05328P		BACC45FT20-41S7 PLUG-P37	81205	1	71-51-11 AE0218/ /	ALL
D05329J		BACC45FN10-5S RCPT-	81205	1	23-42-11 0354/284/R040	150-157, 275-299

EQUIPMENT LIST

D280T132

Section D05300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05329P		BACC45FT10-5P PLUG-	81205	1	23-42-11 0354/284/R040	150-157, 275-299
D05330J		BACC45FN16-24P8 RCPT-P37	81205	1	27-51-41 AE0218/ /	ALL
D05330P		BACC45FT16-24S8 PLUG-P37	81205	1	27-51-31 AE0218/ /	ALL
D05331J		BACC45FN12-12S8 RCPT-	81205	1	23-42-11 AP0802E/ /	050-099
D05331J		BACC45FN16-24S RCPT-	81205	1	23-42-12 AP0703/ /	275-299
D05331P		BACC45FT12-12P8 PLUG	81205	1	23-34-13 AP0802E/ /	050-099
D05331P		BACC45FT16-24P PLUG-	81205	1	23-42-12 AP0703/ /	275-299
D05332J		BACC45FN16-24S8 RCPT-P33	81205	1	30-31-21 AE0207/ /	ALL
D05332P		BACC45FT16-24P8 PLUG-P33	81205	1	27-62-11 AE0207/ /	ALL
D05334J		BACC45FN16-24S RCPT-	81205	1	28-42-11 AE0203/ /	ALL
D05334P		BACC45FT16-24P PLUG-P33	81205	1	21-44-21 296/185/L 05	ALL
D05335J		BACC45FN10-5S RCPT-	81205	1	23-42-11 AP1401/ /	275-299
D05335P		BACC45FT10-5P PLUG-	81205	1	23-42-11 AP1401/ /	275-299
D05337J		BACC45FN10-5S RCPT-	81205	1	23-42-11 AP1402/ /	275-299
D05337P		BACC45FT10-5P PLUG-	81205	1	23-42-11 AP1402/ /	275-299
D05340J		BACC45FN12-12S8 RCPT-P34	81205	1	24-27-41 AE0204/ /	ALL
D05340P		BACC45FT12-12P8 PLUG-P34	81205	1	24-27-41 AE0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D05300

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05344J		BACC45FN16-24S RCPT-E1-2	81205	1	30-41-11 AE0305/ /	ALL
D05344P		BACC45FT16A24P PLUG-E1-2	81205	1	21-31-11 AE0305/ /	ALL
D05346J		BACC45FN14-12S6 RCPT-P34	81205	1	21-58-21 AE0204/ /	ALL
D05346P		BACC45FT14-12P6 PLUG-P34	81205	1	33-31-21 AE0204/ /	ALL
D05347J		BACC45FN20-28S8 RCPT-P3	81205	1	33-16-12 AF0120/ /	ALL
D05347P		BACC45FT20-28P8 PLUG-	81205	1	33-16-12 AF0120/ /	ALL
D05348J		BACC45FN20-41P8 RCPT-P36	81205	1	21-53-12 AE0223/ /	ALL
D05348P		BACC45FT20-41S8 PLUG-P36	81205	1	28-42-11 AE0223/ /	ALL
D05350J		BACC45FN16-24P RCPT-E1-1	81205	1	32-42-11 AE0317/ /	ALL
D05350P		BACC45FT16A24S PLUG-E1-1	81205	1	32-42-11 AE0317/ /	ALL
D05352J		BACC45FN24-57S6 RCPT-P37	81205	1	52-11-11 AE0218/ /	ALL
D05352P		BACC45FT24-57P6 PLUG-P37	81205	1	52-11-11 AE0218/ /	ALL
D05353J		BACC45FN10-5S RCPT-	81205	1	23-42-11 1570/283/00	050-099
D05353P		BACC45FT10-5P PLUG	81201	1	33-25-11 1548/283/0000	050-099
D05355		MB6R-3 RCPT-	09922	1	23-34-16 0645/208/L095	280-299
D05355 T		KIT700-43 COAX CONTACT-	09922	1	23-34-16 / /	280-299
D05355 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-16 / /	280-299

EQUIPMENT LIST

D280T132

Section D05300

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05356J		BACC45FN20-39S9 RCPT-P61	81205	1	30-41-12 AF0204/ /	ALL
D05356P		BACC45FT20-39P9 PLUG-P61	81205	1	30-41-12 AF0204/ /	ALL
D05358J		BACC45FM14C7S7 RCPT-	81205	1	29-11-31 AL1004/ /	ALL
D05358P		BACC63BP14R7P7L PLUG-R WING/BODY RS DISC	81205	1	29-11-31 AL1004/ /	ALL
D05358PQ		BACC10KD14 CLAMP-	81205	1	29-11-31 / /	ALL
D05359		MB6R-3 RCPT-	09922	1	23-34-16 0684/208/L095	280-299
D05359 T		KIT700-43 COAX CONTACT-	09922	1	23-34-16 / /	280-299
D05359 U		204A121-3-01 SHRINK BOOT-	06090	1	23-34-16 / /	280-299
D05360J		BACC45FN22-55S9 RCPT-P36	81205	1	21-25-11 AE0209/ /	ALL
D05360P		BACC45FT22-55P9 PLUG-P36	81205	1	21-25-11 AE0209/ /	ALL
D05364J		BACC45FN14-15S7 RCPT-E2-4	81205	1	28-41-12 AE0306/ /	ALL
D05364P		BACC45FT14A15P7 PLUG-E2-4	81205	1	28-41-12 AE0306/ /	ALL
D05365J		BACC45FN14-15S8 RCPT-WX-R TO EFI-L,E1-2	81205	1	34-43-21 AE0319/ /	ALL
D05365P		BACC45FT14A15P8 PLUG-E1-2	81205	1	34-43-21 AE0319/ /	ALL
D05366J		BACC45FN16-24P8 RCPT-P36	81205	1	21-58-16 AE0209/ /	ALL
D05366P		BACC45FT16-24S8 PLUG-P36	81205	1	21-58-16 AE0209/ /	ALL
D05368J		BACC45FN20-39S7 RCPT-E1-2	81205	1	27-88-21 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D05300

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05368P		BACC45FT20A39P7 PLUG-E1-2	81205	1	27-51-31 AE0305/ /	ALL
D05370J		BACC45FN20-41S8 RCPT-E1-2	81205	1	27-88-12 AE0305/ /	ALL
D05370P		BACC45FT20A41P8 PLUG-E1-2	81205	1	27-88-12 AE0305/ /	ALL
D05371J		BACC45FN12-12S7 RCPT-E1-6	81205	1	22-21-11 AE0305/ /	ALL
D05371P		BACC45FT12A12P7 PLUG-	81205	1	22-21-11 AE0305/ /	ALL
D05372J		BACC45FN16-24S6 RCPT-P37	81205	1	27-18-11 AE0218/ /	ALL
D05372P		BACC45FT16-24P6 PLUG-P37	81205	1	27-18-11 AE0218/ /	ALL
D05373J		BACC45FN16-24S8 RCPT-E1-6	81205	1	22-21-21 AE0317/ /	ALL
D05373P		BACC45FT16A24P8 PLUG-	81205	1	22-21-21 AE0317/ /	ALL
D05374J		BACC45FN22-55P8 RCPT-P37	81205	1	21-25-21 AE0224/ /	ALL
D05374P		BACC45FT22-55S8 PLUG-P37	81205	1	21-25-11 AE0224/ /	ALL
D05376J		BACC45FN14-15P9 RCPT-P37	81205	1	29-11-32 AE0224/ /	ALL
D05376P		BACC45FT14-15S9 PLUG-P37	81205	1	26-21-11 AE0224/ /	ALL
D05378J		BACC45FN14-15S8 RCPT-	81205	1	26-21-11 AE0224/ /	ALL
D05378P		BACC45FT14-15P8 PLUG-P37	81205	1	26-21-11 AE0224/ /	ALL
D05383J		BACC45FN16-24P RCPT-E1-3	81205	1	22-32-12 AE0307/ /	ALL
D05383P		BACC45FT16A24S PLUG-E1-3	81205	1	22-32-12 AE0307/ /	ALL

EQUIPMENT LIST

D280T132

Section D05300

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05389J		BACC45FN18-31P6 RCPT-E1-4	81205	1	34-22-34 AE0319/ /	ALL
D05389P		BACC45FT18A31S6 PLUG-E1-4	81205	1	34-22-34 AE0319/ /	ALL
D05391J		BACC45FN12-12S RCPT-E1-3	81205	1	22-24-21 AE0319/ /	ALL
D05391P		BACC45FT12A12P PLUG-E1-3	81205	1	22-24-21 AE0319/ /	ALL
D05393J		BACC45FN12-12S8 RCPT-P3	81205	1	33-16-12 AF0120/ /	ALL
D05393P		BACC45FT12-12P8 PLUG-P3	81205	1	33-16-13 AF0120/ /	ALL
D05395J		BACC45FN20-41S7 RCPT-P3	81205	1	33-13-12 AF0120/ /	ALL
D05395P		BACC45FT20-41P7 PLUG-P3	81205	1	33-16-13 AF0120/ /	ALL
D05397J		BACC45FN12-12P RCPT-E1-6	81205	1	22-21-11 AE0317/ /	ALL
D05397P		BACC45FT12A12S PLUG-E1-6	81205	1	22-21-11 AE0317/ /	ALL
D05399J		BACC45FN18-31S8 RCPT-P3	81205	1	33-13-13 AF0120/ /	ALL
D05399P		BACC45FT18-31P8 PLUG-P3	81205	1	31-51-51 AF0120/ /	ALL

EQUIPMENT LIST

D280T132

Section D05300

Page 8 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05400J		BACC45FN16-24S RCPT-P61	81205	1	21-64-11 AF0204/ /	ALL
D05400P		BACC45FT16-24P PLUG-P61	81205	1	21-31-11 AF0204/ /	ALL
D05402J		BACC45FN18-31S8 RCPT-P61	81205	1	29-32-11 AF0204/ /	050-099
D05402J		BACC45FN14-15S8 RCPT-P61	81205	1	29-32-11 AF0204/ /	150-199, 275-299
D05402P		BACC45FT18-31P8 PLUG-P61	81205	1	21-31-21 AF0204/ /	050-099
D05402P		BACC45FT14-15P8 PLUG-P61	81205	1	21-31-21 AF0204/ /	150-199, 275-299
D05403J		BACC45FN20-41P9 RCPT-E1-1	81205	1	27-09-11 AE0303/ /	ALL
D05403P		BACC45FT20A41S9 PLUG-E1-1	81205	1	27-61-16 AE0303/ /	ALL
D05405J		BACC45FN16-24P9 RCPT-E1-1	81205	1	27-61-15 AE0303/ /	ALL
D05405P		BACC45FT16A24S9 PLUG-E1-1	81205	1	27-61-15 AE0303/ /	ALL
D05406J		BACC45FN20-41S RCPT-P61	81205	1	21-65-11 AF0204/ /	ALL
D05406P		BACC45FT20-41P PLUG-P61	81205	1	21-44-21 AF0204/ /	ALL
D05407J		BACC45FN16-24P RCPT-E2-3	81205	1	22-24-11 AE0320/ /	ALL
D05407P		BACC45FT16A24S PLUG-E2-3	81205	1	22-24-11 AE0320/ /	ALL
D05409J		BACC45FM12C3S8 RCPT-	81205	1	23-41-11 AL1004/ /	ALL
D05409P		BACC63BP12R3P8L PLUG-	81205	1	23-41-11 AL1004/ /	ALL
D05409PQ		BACC10KD12 CLAMP-	81205	1	23-41-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D05400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05410J		BACC45FN20-41S6 RCPT-P61	81205	1	24-34-11 AF0204/ /	ALL
D05410P		BACC45FT20-41P6 PLUG-P61	81205	1	24-28-11 AF0204/ /	ALL
D05411J		BACC45FN14-15P7 RCPT-E1-1	81205	1	27-61-14 AE0303/ /	ALL
D05411P		BACC45FT14A15S7 PLUG-E1-1	81205	1	27-61-14 AE0303/ /	ALL
D05413J		BACC45FN20-41P8 RCPT-E1-1	81205	1	22-21-11 AE0303/ /	ALL
D05413P		BACC45FT20A41S8 PLUG-E1-1	81205	1	22-22-21 AE0303/ /	ALL
D05414J		BACC45FM18C14S RCPT-R WING RS/BODY	81205	1	27-13-11 AL1008/ /	ALL
D05414P		BACC63BP18R14PNL PLUG-R WING RS/BODY	81205	1	27-51-31 AL1008/ /	ALL
D05414PQ		BACC10KD18 CLAMP-	81205	1	27-51-31 / /	ALL
D05415J		BACC45FN16-24S8 RCPT-VOR/DME L	81205	1	33-16-16 AF0119/ /	ALL
D05415P		BACC45FT16-24P8 PLUG-	81205	1	34-22-18 AF0119/ /	ALL
D05416J		BACC45FN22-55S6 RCPT-P61	81205	1	27-13-11 AF0204/ /	ALL
D05416P		BACC45FT22-55P6 PLUG-P61	81205	1	77-11-11 AF0204/ /	ALL
D05417J		BACC45FN16-24S7 RCPT-VOR/DME R	81205	1	34-12-22 AF0120/ /	ALL
D05417P		BACC45FT16-24P7 PLUG-P3	81205	1	34-22-28 AF0120/ /	ALL
D05418J		BACC45FM14C7S8 RCPT-	81205	1	27-51-11 AL1008/ /	ALL
D05418P		BACC63BP14R7P8L PLUG-R WING RS/BODY	81205	1	27-51-11 AL1008/ /	ALL

EQUIPMENT LIST

D280T132

Section D05400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05418PQ		BACC10KD14 CLAMP-	81205	1	27-51-11 / /	ALL
D05419J		BACC45FN16-24S6 RCPT-P1	81205	1	22-14-11 AF0119/ /	ALL
D05419P		BACC45FT16-24P6 PLUG-	81205	1	22-14-11 AF0119/ /	ALL
D05420J		BACC45FM18C8S RCPT-R W/W DISC	81205	1	27-51-11 AL1008/ /	ALL
D05420P		BACC63BP18R8PNL PLUG-R WING RS/BODY	81205	1	27-51-11 AL1008/ /	ALL
D05420PQ		BACC10KD18 CLAMP-	81205	1	27-51-11 / /	ALL
D05421J		BACC45FN18-31S RCPT-	81205	1	23-34-13 AE0307/ /	ALL
D05421P		BACC45FT18A31P PLUG	81205	1	23-34-13 AE0307/ /	ALL
D05423J		BACC45FN16-24S6 RCPT-P3	81205	1	22-14-21 AF0120/ /	ALL
D05423P		BACC45FT16-24P6 PLUG	81205	1	22-14-21 AF0120/ /	ALL
D05425J		BACC45FN12-12P7 RCPT-FMC L,CDU	81205	1	34-61-11 AE0322/ /	ALL
D05425P		BACC45FT12A12S7 PLUG-E2-2	81205	1	34-61-11 AE0322/ /	ALL
D05427J		BACC45FN12-12S7 RCPT-FMC R,CDU	81205	1	34-61-11 AE0306/ /	ALL
D05427P		BACC45FT12A12P7 PLUG-E2-3	81205	1	34-61-11 AE0306/ /	ALL
D05428J		BACC45FN16-24S7 RCPT-E1-2	81205	1	22-33-11 AE0317/ /	ALL
D05428P		BACC45FT16A24P7 PLUG-E1-2	81205	1	78-34-21 AE0317/ /	ALL
D05429J		BACC45FN10-5P RCPT-	81205	1	23-34-15 0900/260/R085	050-099

EQUIPMENT LIST

D280T132

Section D05400

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05429J		BACC45FN10-5P RCPT-	81205	1	23-34-15 690/260/R085	150-199
D05429J		BACC45FN10-5P RCPT-	81205	1	23-34-15 580/260/R085	275-278
D05430J		BACC63CC18-31SN RCPT-E1-2	81205	1	77-31-11 AE0317/ /	050-099, 155-199, 277-299
D05430J		BACC45FN18-31S RCPT-E1-2	81205	1	77-31-11 AE0317/ /	150-154, 275-276
D05430JK		BACC10KD18 BACKSHELL	81205	1	77-31-11 AE0319/ /	050-099
D05430JK		BACC10KD18 CLAMP	81205	1	77-31-11 AE0309/ /	155-157, 164-199
D05430JK		BACC10KD18 BACKSHELL	81205	1	77-31-11 AE0309/ /	162-163
D05430JK		BACC10KD18 BACKSHELL	81205	1	77-31-11 / /	277-299
D05430P		BACC63CB18-31PN PLUG-E1-2	81205	1	78-36-21 AE0317/ /	050-099, 155-199, 277-299
D05430P		BACC45FT18A31P PLUG-E1-2	81205	1	78-36-21 AE0317/ /	150-154, 275-276
D05430PQ		BACC10KD18 CLAMP-E1-2	81205	1	78-36-21 AE0317/ /	050-099, 155-199, 277-299
D05431J		BACC45FN16-24P6 RCPT-P36	81205	1	22-33-11 AE0209/ /	ALL
D05431P		BACC45FT16-24S6 PLUG-P36	81205	1	73-21-14 AE0209/ /	050-099, 155-157, 165-199, 275-299
D05431P		BACC45FT22-55S6 PLUG-P36	81205	1	73-21-14 AE0209/ /	150-154, 162-164
D05433J		BACC45FN22-55P8 RCPT-P36	81205	1	34-12-11 AE0209/ /	ALL
D05433P		BACC45FT22-55S8 PLUG-P36	81205	1	22-23-13 AE0209/ /	ALL
D05434J		BACC45FN18-31P7 RCPT-E1-2	81205	1	27-88-22 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D05400

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05434P		BACC45FT18A31S7 PLUG-E1-2	81205	1	27-88-22 AE0305/ /	ALL
D05435J		BACC45FN22-55P6 RCPT-P37	81205	1	31-31-12 AE0218/ /	ALL
D05435P		BACC45FT22-55S6 PLUG-P37	81205	1	31-31-12 AE0218/ /	ALL
D05436J		BACC45FN14-12P RCPT-TAIL/BODY	81205	1	27-28-11 AP1501/ /	ALL
D05436P		BACC45FT14-12S PLUG-TAIL/BODY	81205	1	27-21-11 AP1501/ /	ALL
D05437J		BACC45FN20-41P6 RCPT-P37	81205	1	73-21-14 AE0218/ /	ALL
D05437P		BACC45FT20-41S6 RCPT-P37	81205	1	22-14-31 AE0218/ /	050-099, 156-157, 166-199, 275-299
D05437P		BACC45FT22-55S6 RCPT-P37	81205	1	22-14-31 AE0218/ /	150-155, 162-165
D05438J		BACC45FN14-15P7 RCPT-TAIL/BODY	81205	1	27-38-11 AP1501/ /	ALL
D05438P		BACC45FT14-15S7 PLUG-TAIL/BODY	81205	1	27-23-11 AP1501/ /	ALL
D05439J		BACC45FN18-31S RCPT-E2-3	81205	1	31-31-11 AE0320/ /	050-099, 275-299
D05439J		BACC45FN22-55S RCPT-E2-3	81205	1	31-31-11 AE0320/ /	150-199
D05439P		BACC45FT18A31P PLUG E2-3	81205	1	31-31-11 AE0320/ /	050-099, 275-299
D05439P		BACC45FT22A55P PLUG E2-3	81205	1	31-31-11 AE0320/ /	150-199
D05440J		BACC45FN14-7P6 RCPT-TAIL/BODY	81205	1	27-23-11 AP1501/ /	ALL
D05440P		BACC45FT14-7S6 PLUG-TAIL/BODY	81205	1	27-23-11 AP1501/ /	ALL
D05448J		BACC45FN14-12S RCPT-P19	81205	1	35-21-12 AP0401/ /	050-099

EQUIPMENT LIST

D280T132

Section D05400

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05448J		BACC45FN14-7S RCPT-P19	81205	1	35-21-12 AP0401/ /	150-199, 275-299
D05448P		BACC45FT14-12P PLUG-P19	81205	1	35-21-12 AP0401/ /	050-099
D05448P		BACC45FT14-7P PLUG-P19	81205	1	35-21-12 AP0401/ /	150-199, 275-299
D05449J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1211/270/R083	050-099
D05449J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1197+014/270/R083	150-199, 275-278
D05449J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1197+08/270/R083	280-299
D05451J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1205/270/R083	050-099
D05451J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1197+008/270/R083	150-199, 275-299
D05453J		BACC45FN18-31S9 RCPT-P1	81205	1	22-14-11 AF0119/ /	ALL
D05453P		BACC45FT18-31P9 PLUG-	81205	1	22-14-11 AF0119/ /	ALL
D05455J		BACC45FN18-31S8 RCPT-E1-4	81205	1	22-14-11 AE0319/ /	ALL
D05455P		BACC45FT18A31P8 PLUG-E1-4	81205	1	22-14-11 AE0319/ /	ALL
D05456J		BACC45FN16-10S9 RCPT-P36	81205	1	38-32-11 AE0209/ /	ALL
D05456P		BACC45FT16-10P9 PLUG-P36	81205	1	38-32-11 AE0209/ /	ALL
D05459J		BACC63BV16A10S6 RECPT-	81205	1	27-61-13 WS 782/ /	ALL
D05459JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-13 WS 782/ /	ALL
D05459P		BACC63BP16R10P6L PLUG-	81205	12	27-61-13 MULTI/ /	ALL

EQUIPMENT LIST

D280T132

Section D05400

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05459PQ		BACC10KD16 CLAMP-	81205	12	27-61-13 / /	ALL
D05461J		BACC63BV16A10S6 RECPT	81205	1	27-61-14 L0709/12/RS	ALL
D05461JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-14 L0709/12/RS	ALL
D05463J		BACC63BV16A10S6 RECPT-	81205	1	27-61-15 L0653/12/RS	ALL
D05463JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-15 L0653/12/RS	ALL
D05465J		BACC63BV16A10S6 RECPT-	81205	1	27-61-16 L0584/12/TE	ALL
D05465JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-16 L0584/12/TE	ALL
D05467J		BACC63BV16A10S6 RECPT-	81205	1	27-61-17 L0430/12/TE	ALL
D05467JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-17 L0430/12/TE	ALL
D05469J		BACC63BV16A10S6 RECPT	81205	1	27-61-18 L0350/12/TE	ALL
D05469JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-18 L0350/12/TE	ALL
D05471J		BACC63BV16A10S6 RECPT-	81205	1	27-61-18 R0350/12/TE	ALL
D05471JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-18 R0350/12/TE	ALL
D05473J		BACC63BV16A10S6 RECPT	81205	1	27-61-17 R0404/12/TE	ALL
D05473JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-17 R0404/12/TE	ALL
D05475J		BACC63BV16A10S6 RECPT	81205	1	27-61-16 R0567/12/RS	ALL
D05475JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-16 R0567/12/RS	ALL

EQUIPMENT LIST

D280T132

Section D05400

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05477J		BACC63BV16A10S6 RECPT	81205	1	27-61-15 R0630/12/TE	ALL
D05477JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-15 R0630/12/TE	ALL
D05479J		BACC63BV16A10S6 RECPT	81205	1	27-61-14 R0688/12/TE	ALL
D05479JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-14 R0688/12/TE	ALL
D05481J		BACC63BV16A10S6 RECPT	81205	1	27-61-13 R0748/12/TE	ALL
D05481JK	1	BACC10KD16 BACKSHELL	81205	1	27-61-13 R0748/12/TE	ALL
D05483J		BACC45FN20-41P RCPT-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D05483P		BACC45FT20A41S PLUG-E2-1	81205	1	27-61-13 AE0308/ /	ALL
D05485J		BACC45FN16-24P9 RCPT-E2-1	81205	1	27-61-17 AE0308/ /	ALL
D05485P		BACC45FT16A24S9 PLUG-E2-1	81205	1	27-61-17 AE0308/ /	050-099
D05485P		BACC45FT16A24S9 PLUG-E2-1	81205	1	27-61-17 344/190/R043	150-199, 275-299
D05487J		BACC45FN14-15P8 RCPT-E2-1	81205	1	27-61-18 AE0308/ /	ALL
D05487P		BACC45FT14A15S8 PLUG-E2-1	81205	1	27-61-18 AE0308/ /	050-099
D05487P		BACC45FT14A15S8 PLUG-E2-1	81205	1	27-61-18 0344/190/R043	150-199, 275-299
D05489J		BACC45FN22-55P7 RCPT-E2-1	81205	1	22-21-21 AE0308/ /	ALL
D05489P		BACC45FT22A55S7 PLUG-E2-1	81205	1	27-21-22 AE0308/ /	ALL
D05491J		BACC45FN10-5P RCPT-	81205	1	23-34-19 1161/315/L015	050-099

EQUIPMENT LIST

D280T132

Section D05400

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05491J		BACC45FN10-5P RCPT-	81205	1	23-34-19 1152/315/L015	150-199, 275-278
D05493J		BACC45FN14-12P RCPT-E1-1	81205	1	27-09-11 AE0303/ /	ALL
D05493P		BACC45FT14A12S PLUG-E1-1	81205	1	27-09-11 AE0303/ /	ALL
D05495J		BACC45FN10-5P RCPT-E1-1	81205	1	27-09-16 AE0303/ /	ALL
D05495P		BACC45FT10A5S PLUG-E1-1	81205	1	27-41-11 AE0303/ /	ALL
D05496J		BACC45FN16-24P6 RCPT-E1-2	81205	1	52-71-14 AE0317/ /	050-099, 150, 152-157
D05496J		BACC45FN12-12P6 RCPT-E1-2	81205	1	52-71-14 AE0317/ /	151, 275-299
D05496J		BACC45FN16-24P6 RCPT-E1-2	5	0	52-71-14 AE0317/ /	162-199
D05496P		BACC45FT16A24S6 PLUG-E1-2	81205	1	52-71-14 AE0317/ /	050-099, 150, 152-199
D05496P		BACC45FT12A12S6 PLUG-E1-2	81205	1	52-71-14 AE0317/ /	151, 275-299
D05497J		BACC45FN16-24P8 RCPT-P36	81205	1	34-61-15 AE0209/ /	ALL
D05497P		BACC45FT16-24S8 PLUG-P36	81205	1	34-61-15 AE0209/ /	ALL
D05498J		BACC45FN22-55S7 RCPT-E1-2	81205	1	52-71-11 AE0317/ /	ALL
D05498P		BACC45FT22A55P7 PLUG-E1-2	81205	1	52-34-13 AE0317/ /	ALL
D05499J		BACC45FN16-24P9 RCPT-	81205	1	34-61-25 AE0218/ /	ALL
D05499P		BACC45FT16-24S9 PLUG-P37	81205	1	34-61-25 AE0218/ /	ALL

EQUIPMENT LIST

D280T132

Section D05400
Page 9 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05501J		BACC45FN10-5P RECP-	81205	1	23-34-16 0574/260/L085	275-278
D05501J		BACC45FN10-5P RECP-	81205	1	23-34-16 0573/265/L085	280-299
D05505J		BACC45FN12-12S7 RCPT-E1-5	81205	1	23-51-13 AE0317/ /	050-099
D05505J		BACC45FN12-12S7 RCPT-E1-5	81205	1	23-51-11 AE0317/ /	150-199, 275-299
D05505P		BACC45FT12A12P7 PLUG-E1-5	81205	1	23-51-13 AE0317/ /	ALL
D05506J		BACC45FN24-61P RCPT-	81205	1	28-42-11 AE0218/ /	ALL
D05506P		BACC45FT24-61S PLUG-P37	81205	1	28-42-11 AE0218/ /	ALL
D05508J		BACC45FM18C8S8 RCPT-	81205	1	28-22-12 AL1004/ /	ALL
D05508P		BACC63BP18A8P8L PLUG-R WING RS/BODY	81205	1	28-22-12 AL1004/ /	ALL
D05508PQ		BACC10KD18 CLAMP-	81205	1	28-22-12 / /	ALL
D05510J		BACC45FM18C14S6 RCPT-	81205	1	29-21-32 AL1004/ /	ALL
D05510P		BACC63BP18R14P6L PLUG-R WING/BODY RS DISC	81205	1	29-21-32 AL1004/ /	ALL
D05510PQ		BACC10KD18 CLAMP-R WING/BODY RS DISC	81205	1	29-21-32 / /	ALL
D05512J		BACC45FM14C7S9 RCPT-	81205	1	28-22-11 AL1002/ /	ALL
D05512P		BACC63BP14A7P9L PLUG-R WING RS/BODY	81205	1	28-22-11 AL1002/ /	ALL
D05512PQ		BACC10KD14 CLAMP-	81205	1	28-22-11 / /	ALL
D05514J		BACC45FM22C19S6 RCPT-R WING RS/BODY	81205	1	27-14-21 AL1002/ /	ALL

EQUIPMENT LIST

D280T132

Section D05500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05514P		BACC63BP22A19P6L PLUG-R WING RS/BODY	81205	1	27-51-41 AL1002/ /	ALL
D05514PQ		BACC10KD22 CLAMP-	81205	1	27-51-41 / /	ALL
D05516J		BACC45FM14C7S RCPT-	81205	1	32-61-12 AL1004/ /	ALL
D05516P		BACC63BP14R7PNL PLUG-	81205	1	32-61-12 AL1004/ /	ALL
D05516PQ		BACC10KD14 CLAMP-	81205	1	32-61-12 / /	ALL
D05517J		BACC45FN18-31S6 RCPT-	81205	1	31-35-14 AE0306/ /	150-199, 275-299
D05518J		BACC45FN14-7S7 RCPT-	81205	1	26-11-21 AC0702/ /	ALL
D05518P		BACC45FT14-7P7 PLUG-R WING FS/BODY	81205	1	26-11-21 AC0702/ /	ALL
D05519J		BACC45FN18-31S7 RCPT-	81205	1	31-35-15 AE0320/ /	150-199, 275-299
D05520J		BACC63BV24A30S6 RCPT-	81205	1	28-26-11 AL1002/ /	ALL
D05520JK		BACC10KD24 CLAMP-	81205	1	28-26-11 / /	ALL
D05520P		BACC63BP24A30P6L PLUG-R WING RS/BODY	81205	1	28-26-11 AL1002/ /	ALL
D05520PQ		BACC10KD24 CLAMP-	81205	1	28-26-11 / /	ALL
D05522J		BACC45FN18-14S8 RCPT-	81205	1	26-11-21 AC0702/ /	ALL
D05522P		BACC45FT18-14P8 PLUG-R WING FRONT SPAR/BODY	81205	1	26-11-21 AC0702/ /	ALL
D05523J		BACC45FN18-31P8 RCPT-	81205	1	34-46-12 AE0319/ /	ALL
D05523P		BACC45FT18A31S8 PLUG-E1-5	81205	1	34-46-12 AE0319/ /	ALL

EQUIPMENT LIST

D280T132

Section D05500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05525J		BACC45FN16-24P RCPT-E1-5	81205	1	31-51-31 AE0305/ /	ALL
D05525P		BACC45FT16A24S PLUG-E1-5	81205	1	31-51-21 AE0305/ /	ALL
D05527J		BACC45FN10-5P RCPT-	81205	1	23-34-17 640/315/L015	275-278
D05527J		BACC45FN10-5P RCPT-	81205	1	23-34-17 639/315/L013	280-299
D05528J		BACC63CC24-61S8 RCPT-R WING BODY DISC	81205	1	30-11-11 AC0702/ /	050-099
D05528J		BACC63CC24-61S8 RCPT-R WING BODY DISC	81205	1	26-18-22 AC0702/ /	150-155, 162-165, 275-276
D05528J		BACC63CC22-55S8 RCPT-R WING BODY DISC	81205	1	26-18-22 AC0702/ /	156-157, 166-199, 277-299
D05528P		BACC63CB24-61P8 PLUG-R WING FS/BODY	81205	1	36-11-62 AC0702/ /	050-099, 150-155, 163-165, 275-276
D05528P		BACC63CB22-55P8 PLUG-R WING FS/BODY	81205	1	36-23-21 AC0702/ /	156-157, 166-199, 277-299
D05528P		BACC63CB24-61P8 PLUG-R WING FS/BODY	81205	1	36-23-21 AC0702/ /	162
D05528PQ		BACC10KD24 CLAMP	81205	1	36-11-62 AC0702/ /	050-099, 150-155, 163-165, 275-276
D05528PQ		BACC10KD22 CLAMP	81205	1	36-23-21 AC0702/ /	156-157, 166-199, 277-299
D05528PR		-11101 MATE/WITH TAPE TEXT AS BELOW	85480	1	36-11-62 / /	050-099, 150-155, 163-165, 275-276
D05529J		BACC45FN12-12S6 RCPT-E1-4	81205	1	22-12-21 AE0317/ /	ALL
D05529P		BACC45FT12A12P6 PLUG-E1-4	81205	1	22-12-21 AE0317/ /	ALL
D05530J		BACC45FN14-12S RCPT-	81205	1	29-11-12 AC0702/ /	ALL
D05530P		BACC45FT14-12P PLUG-R WING FS/BODY	81205	1	29-11-22 AC0702/ /	ALL

EQUIPMENT LIST

D280T132

Section D05500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05531J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1211/270/L083	050-099
D05531J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1197+014/270/L083	150-199, 275-278
D05531J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1197+08/270/L083	280-299
D05533J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1205/270/L083	050-099
D05533J		BACC45FN10-5P RCPT-	81205	1	23-34-18 1197+008/270/L083	150-199, 275-299
D05540J		BACC45FN12-12S9 RCPT-P54	81205	1	26-17-11 AE0226/ /	ALL
D05540P		BACC45FT12-12P9 PLUG-P54	81205	1	26-17-11 AE0226/ /	ALL
D05541J		BACC45FN20-28S9 RCPT-P37	81205	1	23-31-12 AE0224/ /	ALL
D05541P		BACC45FT20-28P9 PLUG-P37	81205	1	23-31-12 AE0224/ /	ALL
D05544J		BACC45FN16-24P7 RCPT-	81205	1	32-61-14 AE0305/ /	ALL
D05544P		BACC45FT16A24S7 PLUG-E1-2	81205	1	21-31-11 AE0305/ /	ALL
D05546J		BACC45FN14-15S7 RCPT-P54	81205	1	26-11-11 AE0226/ /	ALL
D05546P		BACC45FT14-15P7 PLUG-P54	81205	1	26-11-11 AE0226/ /	ALL
D05547J		BACC45FN20-41P7 RCPT-E2-1	81205	1	22-22-21 AE0308/ /	ALL
D05547P		BACC45FT20A41S7 PLUG-E2-1	81205	1	22-22-21 AE0308/ /	ALL
D05548J		BACC45FN14-15S9 RCPT-P54	81205	1	26-11-11 AE0226/ /	ALL
D05548P		BACC45FT14-15P9 PLUG-P54	81205	1	26-11-11 AE0226/ /	ALL

EQUIPMENT LIST

D280T132

Section D05500

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05549J		BACC45FN22-55P6 RCPT-E1-1	81205	1	22-24-11 AE0303/ /	ALL
D05549P		BACC45FT22A55S6 PLUG-E1-1	81205	1	27-21-22 AE0303/ /	ALL
D05551J		BACC45FN14-15S9 RCPT-P1	81205	1	22-14-11 AF0119/ /	ALL
D05551P		BACC45FT14-15P9 PLUG-P1	81205	1	22-14-11 AF0119/ /	ALL
D05552J		BACC45FN24-61P6 RCPT-	81205	1	21-51-21 AE0202/ /	ALL
D05552P		BACC45FT24-61S6 PLUG-P50	81205	1	21-51-21 AE0202/ /	ALL
D05553J		BACC45FN14-15P9 RCPT-E1-4	81205	1	22-14-11 AE0319/ /	ALL
D05553P		BACC45FT14A15S9 PLUG-E1-4	81205	1	22-14-11 AE0319/ /	ALL
D05554J		BACC45FN20-41S RCPT-E1-2	81205	1	30-21-11 AE0305/ /	ALL
D05554P		BACC45FT20A41P PLUG-E1-2	81205	1	32-42-11 AE0305/ /	ALL
D05555J		BACC45FN16-24S8 RCPT-P3	81205	1	22-14-21 AF0120/ /	ALL
D05555P		BACC45FT16-24P8 PLUG-P3	81205	1	22-14-21 AF0120/ /	ALL
D05556J		BACC63BV16A10S6 RCPT-	81205	1	36-11-31 AL1003/ /	ALL
D05556JK		BACC10KD16 CLAMP	81205	1	30-21-11 AL1003/ /	ALL
D05556P		BACC63BP16R10P6L PLUG-	81205	1	32-61-11 AL1003/ /	ALL
D05556PQ		BACC10KD16 CLAMP-	81205	1	32-61-11 / /	ALL
D05557J		BACC45FN16-24P9 RCPT-E1-4	81205	1	34-12-31 AE0307/ /	ALL

EQUIPMENT LIST

D280T132

Section D05500

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05557P		BACC45FT16A24S9 PLUG-E1-4	81205	1	34-12-31 AE0307/ /	ALL
D05558J		BACC45FM18C8S6 RCPT-	81205	1	28-22-12 AL1003/ /	ALL
D05558P		BACC63BP18A8P6L PLUG-L WING RS/BODY	81205	1	28-22-12 AL1003/ /	ALL
D05558PQ		BACC10KD18 CLAMP-	81205	1	28-22-12 / /	ALL
D05561J		BACC45FN12-12S9 RCPT-P37	81205	1	23-32-11 AE0218/ /	ALL
D05561P		BACC45FT12-12P9 PLUG-P37	81205	1	23-32-11 AE0218/ /	050-099, 275-299
D05561P		BACC45FT12-12P9 PLUG-P37	81205	1	23-32-11 292/169/R 68	150-199
D05562J		BACC45FM18C11S RCPT-	81205	1	28-41-21 AL1001/ /	ALL
D05562P		BACC63BP18A11PNL PLUG-L WING RS/BODY	81205	1	28-41-21 AL1001/ /	ALL
D05562PQ		BACC10KD18 CLAMP-	81205	1	28-41-21 / /	ALL
D05566J		BACC45FN20-41P RCPT-E1-2	81205	1	28-42-11 AE0317/ /	050-099, 150-199
D05566J		BACC45FN18-31P RCPT-E1-2	81205	1	28-42-11 AE0317/ /	275-299
D05566P		BACC45FT20A41S PLUG-E1-2	81205	1	32-61-11 AE0317/ /	050-099, 150-199
D05566P		BACC45FT18A31S PLUG-E1-2	81205	1	32-61-11 AE0317/ /	275-299
D05573J		BACC45FN16-24S8 RCPT-E1-5	81205	1	34-46-11 AE0305/ /	ALL
D05573P		BACC45FT16A24P8 PLUG-E1-5	81205	1	34-46-11 AE0305/ /	ALL
D05575J		BACC45FN16-24S7 RCPT-E2-2	81205	1	34-33-21 AE0320/ /	ALL

EQUIPMENT LIST

D280T132

Section D05500

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05575P		BACC45FT16A24P7 PLUG-E2-2	81205	1	34-33-21 AE0320/ /	ALL
D05576J		BACC45FN18-14S8 RCPT-	81205	1	32-61-13 AE0209/ /	ALL
D05576P		BACC45FT18-14P8 PLUG-P36	81205	1	32-61-13 AE0209/ /	ALL
D05581J		BACC45FN18-31P7 RCPT-	81205	1	34-22-17 AE0319/ /	ALL
D05581P		BACC45FT18A31S7 PLUG-	81205	1	34-22-17 AE0319/ /	ALL
D05585J		BACC45FN22-55S RCPT-E1-4	81205	1	31-31-12 AE0305/ /	ALL
D05585P		BACC45FT22A55P PLUG-E1-4	81205	1	31-31-12 AE0305/ /	ALL
D05586J		BACC45FM14C7S6 RCPT-L WW DISC	81205	1	32-42-12 AL1005/ /	ALL
D05586P		BACC63BP14R7P6L PLUG-	81205	1	32-42-12 AL1005/ /	ALL
D05586PQ		BACC10KD14 CLAMP-	81205	1	32-42-12 / /	ALL
D05592J		BACC45FN22-19S7 RCPT-P37	81205	1	32-61-13 AE0218/ /	ALL
D05592P		BACC45FT22-19P7 PLUG-P37	81205	1	32-61-13 AE0218/ /	ALL
D05593J		BACC45FN16-24S9 RCPT-E2-5	81205	1	23-32-11 AE0320/ /	ALL
D05593P		BACC45FT16A24P9 PLUG-E2-5	81205	1	23-32-11 AE0320/ /	ALL
D05597J		KC-19-308-M06 REPT-FWD CLOSET	91836	1	23-32-13 AP0202/ /	275
D05597J		KC-19-308-M06 REPT-FWD CLOSET	91836	1	23-32-13 AP0205/ /	276-299
D05597P		KC-59-557-M06 PLUG	81205	1	23-32-13 AP0202/ /	275

EQUIPMENT LIST

D280T132

Section D05500

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05597P		KC-59-557-M06 PLUG	81205	1	23-32-13 AP0205/ /	276-299
D05598J		BACC45FN20-28S RCPT-R WING BODY DISC	81205	1	33-44-21 AC0702/ /	ALL
D05598P		BACC45FT20-28P PLUG-R WING FS/BODY	81205	1	30-11-11 AC0702/ /	ALL
D05599J		BACC45FN14-7P9 RCPT-	81205	1	23-32-13 AP1501/ /	ALL
D05599P		BACC45FT14-7S9 PLUG-	81205	1	23-32-13 AP1501/ /	ALL

EQUIPMENT LIST

D280T132

Section D05500
Page 8 End
Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05602J		BACC45FN18-14P9 RCPT-P37	81205	1	21-58-15 AE0218/ /	ALL
D05602P		BACC45FT18-14S9 PLUG-P37	81205	1	21-58-15 AE0218/ /	ALL
D05603J		BACC45FN22-55P7 RCPT-E1-2	81205	1	22-41-11 AE0313/ /	ALL
D05603P		BACC45FT22A55S7 PLUG-E1-2	81205	1	22-41-11 AE0313/ /	ALL
D05605J		BACC45FN22-55S6 RCPT-E1-3	81205	1	22-12-11 AE0315/ /	ALL
D05605P		BACC45FT22A55P6 PLUG-E1-3	81205	1	22-23-12 AE0315/ /	ALL
D05607J		BACC45FN16-24P RCPT-E1-4	81205	1	22-12-11 AE0321/ /	ALL
D05607P		BACC45FT16A24S PLUG-E1-4	81205	1	22-12-11 AE0321/ /	ALL
D05608J		BACC45FM18C14S7 RCPT-	81205	1	28-42-11 AL1004/ /	ALL
D05608P		BACC63BP18R14P7L PLUG-	81205	1	32-61-12 AL1004/ /	ALL
D05608PQ		BACC10KD18 CLAMP-	81205	1	32-61-12 / /	ALL
D05609J		BACC45FN14-15S6 RCPT-E1-5	81205	1	34-46-11 AE0323/ /	ALL
D05609P		BACC45FT14A15P6 PLUG-	81205	1	34-46-11 AE0323/ /	ALL
D05612J		BACC45FN24-61P6 RCPT-P37	81205	1	21-51-21 AE0218/ /	ALL
D05612P		BACC45FT24-61S6 PLUG-P37	81205	1	21-51-21 AE0218/ /	ALL
D05613J		BACC45FN16-24P8 RCPT-E1-2	81205	1	22-33-11 AE0313/ /	ALL
D05613P		BACC45FT16A24S8 PLUG-E1-2	81205	1	22-33-11 AE0313/ /	ALL

EQUIPMENT LIST

D280T132

Section D05600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05614J		BACC45FN20-25P8 RCPT-P35	81205	1	25-53-11 AC0506/ /	ALL
D05614P		BACC45FT20-25S8 PLUG-P35	81205	1	25-53-11 AC0506/ /	ALL
D05615J		BACC45FN16-24S7 RCPT E1-3	81205	1	34-22-38 AE0315/ /	ALL
D05615P		BACC45FT16A24P7 PLUG E1-3	81205	1	34-22-38 AE0315/ /	ALL
D05616J		BACC45FN20-25P8 RCPT-P39	81205	1	25-53-21 AC1304/ /	ALL
D05616P		BACC45FT20-25S8 PLUG-P39	81205	1	25-53-21 AC1304/ /	ALL
D05617J		BACC45FN22-55S6 RCPT-E1-4	81205	1	22-14-31 AE0321/ /	ALL
D05617P		BACC45FT22A55P6 PLUG-E1-4	81205	1	22-14-31 AE0321/ /	ALL
D05618J		BACC45FN16-24P9 RCPT-E1-2	81205	1	52-34-12 AE0317/ /	ALL
D05618P		BACC45FT16A24S9 PLUG-E1-2	81205	1	25-53-11 AE0317/ /	ALL
D05619J		BACC45FN20-25P RCPT-E1-5	81205	1	22-13-21 AE0323/ /	ALL
D05619P		BACC45FT20A25S PLUG-E1-6	81205	1	34-22-28 AE0323/ /	ALL
D05622J		BACC45FN22-55S7 RCPT-E2-4	81205	1	27-51-11 AE0320/ /	ALL
D05622P		BACC45FT22A55P7 PLUG-E2-4	81205	1	27-51-11 AE0320/ /	ALL
D05625J		BACC45FN20-41S RCPT-E1-3	81205	1	22-11-12 AE0315/ /	ALL
D05625P		BACC45FT20A41P PLUG-E1-3	81205	1	22-11-12 AE0315/ /	ALL
D05626J		BACC45FN22-55S7 RCPT-E2-4	81205	1	27-51-41 AE0306/ /	ALL

EQUIPMENT LIST

D280T132

Section D05600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05626P		BACC45FT22A55P7 PLUG-E2-4	81205	1	27-51-41 AE0306/ /	ALL
D05627J		BACC45FN16-24P9 RCPT-E1-4	81205	1	22-11-22 AE0321/ /	050-099, 275-299
D05627J		BACC45FN18-31P9 RCPT-E1-4	81205	1	22-11-22 AE0321/ /	150-199
D05627P		BACC45FT16A24S9 PLUG-E1-4	81205	1	22-11-22 AE0321/ /	050-099, 275-299
D05627P		BACC45FT18A31S9 PLUG-E1-4	81205	1	22-11-22 AE0321/ /	150-199
D05629J		BACC45FN12-12P7 RCPT-E1-5	81205	1	34-22-28 AE0323/ /	ALL
D05629P		BACC45FT12A12S7 PLUG-E1-5	81205	1	34-22-28 AE0323/ /	ALL
D05635J		BACC45FN16-24S RCPT-E1-3	81205	1	22-11-12 AE0315/ /	ALL
D05635P		BACC45FT16A24P PLUG-E1-3	81205	1	22-11-12 AE0315/ /	ALL
D05637J		BACC45FN12-12P RCPT-E1-4	81205	1	22-11-22 AE0321/ /	ALL
D05637P		BACC45FT12A12S PLUG-E1-4	81205	1	22-11-22 AE0321/ /	ALL
D05638J		BACC45FN16-24S8 RCPT-E1-2	81205	1	73-21-14 AE0317/ /	ALL
D05638P		BACC45FT16A24P8 PLUG-E1-2	81205	1	74-31-21 AE0317/ /	050-099
D05638P		BACC45FT16A24P8 PLUG-E1-2	81205	1	78-34-21 AE0317/ /	150-199, 275-299
D05644J		BACC45FN20-41P8 RCPT-	81205	1	21-58-11 AE0202/ /	ALL
D05644P		BACC45FT20-41S8 PLUG-P50	81205	1	21-58-15 AE0202/ /	ALL
D05646J		BACC45FN18-31S RCPT-E1-2	81205	1	76-11-11 AE0319/ /	ALL

EQUIPMENT LIST

D280T132

Section D05600

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05646P		BACC45FT18A31P PLUG-E1-2	81205	1	29-11-32 AE0319/ /	ALL
D05647J		BACC45FN12-12S8 RCPT-E1-4	81205	1	34-22-23 AE0321/ /	ALL
D05647P		BACC45FT12A12P8 PLUG-E1-4	81205	1	34-22-23 AE0321/ /	ALL
D05648J		BACC45FN24-57P7 RCPT-P33	81205	1	33-31-11 AE0203/ /	ALL
D05648P		BACC45FT24-57S7 PLUG-P33	81205	1	33-31-11 AE0203/ /	ALL
D05650J		BACC45FN16-24S6 RCPT-P33	81205	1	33-31-41 AE0203/ /	ALL
D05650P		BACC45FT16-24P6 PLUG-P33	81205	1	33-21-21 AE0203/ /	ALL
D05652J		BACC45FN16-24S7 RCPT-P61	81205	1	32-42-12 AF0204/ /	ALL
D05652P		BACC45FT16-24P7 PLUG-P61	81205	1	29-32-11 AF0204/ /	ALL
D05653 U		289T0241-11502 I.D. TAPE TEXT AS BELOW		1	34-45-14 E1-2/ /	153-154
D05653J		BACC45FN18-31P8 RCPT-E1-2	81205	1	34-22-18 AE0313/ /	ALL
D05653P		BACC45FT18A31S8 PLUG-E1-3	81205	1	34-22-18 AE0313/ /	ALL
D05654J		BACC45FN12-12S6 RCPT-	81205	1	21-58-16 AE0209/ /	ALL
D05654P		BACC45FT12-12P6 PLUG-P36	81205	1	21-58-16 AE0209/ /	ALL
D05655J		BACC45FN12-12S8 RCPT-E1-3	81205	1	34-22-38 AE0315/ /	ALL
D05655P		BACC45FT12A12P8 PLUG-E1-3	81205	1	34-22-39 AE0315/ /	ALL
D05656J		BACC45FN22-55S RCPT-P61	81205	1	30-11-11 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D05600

Page 4

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05656P		BACC45FT22-55P PLUG-P61	81205	1	30-11-11 AF0204/ /	ALL
D05658J		BACC45FN22-55P RCPT-	81205	1	21-58-21 AE0223/ /	ALL
D05658P		BACC45FT22-55S PLUG-P36	81205	1	21-26-11 AE0223/ /	ALL
D05660J		BACC45FN18-14S7 RCPT-P37	81205	1	38-13-11 AE0224/ /	ALL
D05660P		BACC45FT18-14P7 PLUG-P37	81205	1	38-13-11 AE0224/ /	ALL
D05662J		BACC45FN16-24S7 RCPT-P33	81205	1	27-58-11 AE0207/ /	ALL
D05662P		BACC45FT16-24P7 PLUG-P33	81205	1	27-51-31 AE0207/ /	ALL
D05664J		BACC45FN22-55P RCPT-P33	81205	1	27-51-51 AE0207/ /	ALL
D05664P		BACC45FT22-55S PLUG-P33	81205	1	27-28-11 AE0207/ /	ALL
D05668J		BACC45FN20-41P RCPT-P33	81205	1	27-81-21 AE0203/ /	ALL
D05668P		BACC45FT20-41S PLUG-P33	81205	1	27-51-11 AE0203/ /	ALL
D05672J		BACC45FN16-24S7 RCPT-P49	81205	1	21-44-11 AC1402/ /	ALL
D05672P		BACC45FT16-24P7 PLUG-P49	81205	1	21-44-11 AC1402/ /	ALL
D05672PQ		289T0184-10102 I.D. TAPE - TEXT AS BELOW	81205	1	38-32-14 / /	275-276
D05676J		BACC45FN14-15P8 RCPT-E2-4	81205	1	24-11-21 AE0322/ /	ALL
D05676P		BACC45FT14A15S8 PLUG-E2-4	81205	1	24-11-21 AE0322/ /	ALL
D05677J		BACC45FN22-55P7 RCPT-E1-4	81205	1	34-22-34 AE0321/ /	ALL

EQUIPMENT LIST

D280T132

Section D05600

Page 5

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05677P		BACC45FT22A55S7 PLUG-E1-4	81205	1	34-22-34 AE0321/ /	ALL
D05678J		BACC45FN12-12P6 RCPT-E2-5	81205	1	23-31-14 AE0320/ /	ALL
D05678P		BACC45FT12A12S6 PLUG-E2-5	81205	1	23-31-14 AE0320/ /	ALL
D05680J		BACC45FN14-4S8 RCPT-	81205	1	22-23-21 AE0307/ /	ALL
D05680P		BACC45FT14A4P8 PLUG-E1-5	81205	1	22-23-21 AE0307/ /	ALL
D05682J		BACC45FN10-5S9 RCPT-P34	81205	1	21-58-17 AE0204/ /	ALL
D05682P		BACC45FT10-5P9 PLUG-P34	81205	1	24-51-61 AE0204/ /	ALL
D05686J		BACC45FN22-55S8 RCPT-E3-1	81205	1	21-58-12 AE0220/ /	ALL
D05686P		BACC45FT22-55P8 PLUG-E3-1	81205	1	21-61-11 AE0220/ /	ALL
D05688J		BACC45FN16-24S6 RCPT-	81205	1	36-11-41 AE0218/ /	ALL
D05688P		BACC45FT16-24P6 RCPT-P37	81205	1	30-71-11 AE0218/ /	050-099, 280-299
D05688P		BACC45FT16-24P6 PLUG-P37	81205	1	30-71-11 AE0218/ /	150-199, 275-278
D05690J		BACC45FN20-39S7 RCPT-P33	81205	1	30-71-22 AE0207/ /	ALL
D05690P		BACC45FT20-39P7 PLUG-P33	81205	1	30-71-22 AE0207/ /	ALL
D05692J		BACC45FN20-39S7 RCPT-P37	81205	1	30-71-24 AE0224/ /	ALL
D05692P		BACC45FT20-39P7 PLUG-P37	81205	1	30-71-24 AE0224/ /	ALL
D05698J		BACC45FM22C12S9 RCPT-	81205	1	28-25-11 AL1005/ /	ALL

EQUIPMENT LIST

D280T132

Section D05600

Page 6

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05698P		BACC63BP22A12P9L PLUG-L WING RS/BODY	81205	1	28-21-21 AL1005/ /	ALL
D05698PQ		BACC10KD22 CLAMP-	81205	1	28-21-21 / /	ALL

EQUIPMENT LIST

D280T132

Section D05600

Page 7 End

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05700J		BACC45FM22C19S7 RCPT-	81205	1	28-21-12 AL1005/ /	ALL
D05700P		BACC63BP22A19P7L PLUG-L WING RS/BODY	81205	1	28-21-12 AL1005/ /	ALL
D05700PQ		BACC10KD22 CLAMP-	81205	1	28-21-12 / /	ALL
D05702J		BACC45FM14C7S8 RCPT-	81205	1	27-11-11 AL1001/ /	ALL
D05702P		BACC63BP14A7P8L PLUG-L WING RS/BODY	81205	1	27-11-11 AL1001/ /	ALL
D05702PQ		BACC10KD14 CLAMP-	81205	1	27-11-11 / /	ALL
D05703J		BACC45FN22-55P6 RCPT-E2-2	81205	1	34-61-11 AE0314/ /	ALL
D05703P		BACC45FT22A55S6 PLUG-E2-2	81205	1	34-61-11 AE0314/ /	ALL
D05705J		BACC45FN16-24P8 RCPT-E2-3	81205	1	34-46-11 AE0316/ /	ALL
D05705P		BACC45FT16A24S8 PLUG-	81205	1	34-46-11 AE0316/ /	ALL
D05706J		BACC45FN18-8P9 RCPT-P49	81205	1	38-32-21 AC1402/ /	ALL
D05706P		BACC45FT18-8S9 PLUG-P49	81205	1	38-32-21 AC1402/ /	ALL
D05706PQ		289T0184-10103 I.D. TAPE - TEXT AS BELOW	81205	1	38-32-14 / /	275-276
D05708J		BACC45FN20-25S RCPT-P11	81205	1	35-21-11 AF0201/ /	ALL
D05708P		BACC45FT20-25P PLUG-P11	81205	1	35-21-11 AF0201/ /	ALL
D05709J		BACC45FN12-12P6 RCPT-E2-5	81205	1	23-11-11 AE0324/ /	050-099, 151-152, 275-276
D05709J		BACC45FN18-31P6 RCPT-E2-5	81205	1	23-11-11 AE0324/ /	150, 153-199, 277- 299

EQUIPMENT LIST

D280T132

Section D05700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05709P		BACC45FT12A12S6 PLUG-E2-6	81205	1	23-11-11 AE0324/ /	050-099, 151-152, 275-276
D05709P		BACC45FT18A31S6 PLUG-E2-6	81205	1	23-11-11 AE0324/ /	150, 153-199, 277- 299
D05710J		BACC45FN20-25P9 RCPT-P19	81205	1	35-21-11 AP0401/ /	ALL
D05710P		BACC45FT20-25S9 PLUG-P19	81205	1	35-21-11 AP0401/ /	ALL
D05712J		BACC63CC12-12S9 RCPT-R WING FS/BODY	81205	1	27-81-11 AC0702/ /	050-099, 275-299
D05712J		BACC63CC12-12S9 RCPT-R WING FS/BODY	81205	1	77-21-11 AC0702/ /	150-199
D05712JK		BACC10KD12 CLAMP	81205	1	27-81-11 / /	ALL
D05712P		BACC63CB12-12P9 PLUG-R WING FS/BODY	81205	1	27-81-11 AC0702/ /	ALL
D05712PQ		BACC10KD12 CLAMP-	81205	1	27-81-11 AC0702/ /	050-099, 150-199
D05712PQ		BACC10KD12 CLAMP-	81205	1	27-81-11 / /	275-299
D05713J		BACC45FN22-55P9 RCPT-E2-2	81205	1	34-61-13 AE0314/ /	ALL
D05713P		BACC45FT22A55S9 PLUG-E2-3	81205	1	34-61-14 AE0314/ /	ALL
D05714J		BACC45FN14-4S9 RCPT-P36	81205	1	21-58-21 AE0209/ /	ALL
D05714P		BACC45FT14-4P9 PLUG-P36	81205	1	33-42-11 AE0209/ /	ALL
D05715J		BACC45FN20-41P RCPT-E2-3	81205	1	31-51-56 AE0316/ /	ALL
D05715P		BACC45FT20A41S PLUG-E2-4	81205	1	31-51-21 AE0316/ /	ALL
D05719J		BACC45FN12-12P9 RCPT-E2-5	81205	1	23-11-21 AE0324/ /	ALL

EQUIPMENT LIST

D280T132

Section D05700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05719P		BACC45FT12A12S9 PLUG-E2-6	81205	1	23-11-21 AE0324/ /	ALL
D05720J		48-7191 RCPT-	02660	1	33-22-21 0470/270/L070	050-099
D05720P		48-7190 PLUG-	02660	1	33-22-21 0470/270/L070	050-099
D05722J		48-7191 RCPT-	02660	1	33-22-21 0470/270/L070	050-099
D05722P		48-7190 PLUG-	02660	1	33-22-21 0470/270/L070	050-099
D05723J		BACC45FN14-15S7 RCPT-E2-2	81205	1	34-61-22 AE0314/ /	ALL
D05723P		BACC45FT14A15P7 PLUG-E2-3	81205	1	34-61-22 AE0314/ /	ALL
D05724J		BACC45FN24-61S6 RCPT-P61	81205	1	21-61-11 AF0204/ /	ALL
D05724P		BACC45FT24-61P6 PLUG-P61	81205	1	21-61-11 AF0204/ /	ALL
D05726J		BACC45FN24-61S RCPT-P61	81205	1	21-61-11 AF0204/ /	ALL
D05726P		BACC45FT24-61P PLUG-P61	81205	1	21-61-11 AF0204/ /	ALL
D05728J		BACC45FN12-3S7 RCPT-P25	81205	1	35-21-13 AP1003/ /	050-099
D05728P		BACC45FT12-3P7 PLUG-P25	81205	1	35-21-13 AP1003/ /	050-099
D05730J		BACC45FN12-3S6 RCPT-P25	81205	1	35-21-14 AP1003/ /	050-099
D05730P		BACC45FT12-3P6 PLUG-P25	81205	1	35-21-14 AP1003/ /	050-099
D05732J		BACC45FN16-24S7 RCPT-P61	81205	1	29-21-32 AF0204/ /	ALL
D05732P		BACC45FT16-24P7 PLUG-P61	81205	1	29-21-32 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D05700

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05733J		BACC45FN22-55P9 RCPT-E2-2	81205	1	31-31-15 AE0314/ /	ALL
D05733P		BACC45FT22A55S9 PLUG-E2-2	81205	1	31-31-15 AE0314/ /	ALL
D05734J		BACC45FN16-24S RCPT-E2-4	81205	1	29-21-32 AE0306/ /	ALL
D05734P		BACC45FT16A24P PLUG-E2-4	81205	1	29-33-11 AE0306/ /	ALL
D05736J		BACC45FN12-3S RCPT-P25	81205	1	35-21-12 AP1003/ /	050-099
D05736P		BACC45FT12-3P PLUG-P25	81205	1	35-21-12 AP1003/ /	050-099
D05738J		BACC45FN12-12S7 RCPT-E3-1	81205	1	21-51-22 AE0220/ /	ALL
D05738P		BACC45FT12-12P7 PLUG-E3-1	81205	1	21-61-31 AE0220/ /	ALL
D05740J		BACC45FN14-3S9 RCPT-	81205	1	35-21-12 AP0403/ /	050-099
D05740J		BACC45FN14-4S9 RCPT-	81205	1	35-21-12 AP0403/ /	150-199, 275-299
D05740P		BACC45FT14-3P9 PLUG-P19	81205	1	35-21-12 AP0403/ /	050-099
D05740P		BACC45FT14-4P9 PLUG-P19	81205	1	35-21-12 AP0403/ /	150-199, 275-299
D05744J		BACC45FN20-39S RCPT-P33	81205	1	25-29-11 AE0203/ /	ALL
D05744P		BACC45FT20-39P PLUG-P33	81205	1	25-29-11 AE0203/ /	ALL
D05746J		BACC45FN12-3S6 RCPT-	81205	1	35-21-13 AP0403/ /	050-099
D05746J		BACC45FN14-4S6 RCPT-	81205	1	35-21-13 AP0403/ /	150-199, 275-299
D05746P		BACC45FT12-3P6 PLUG-P19	81205	1	35-21-13 AP0403/ /	050-099

EQUIPMENT LIST

D280T132

Section D05700

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05746P		BACC45FT14-4P6 PLUG-P19	81205	1	35-21-13 AP0403/ /	150-199, 275-299
D05750J		BACC45FN14-7S9 RCPT-	81205	1	35-21-13 AP0403/ /	050-099
D05750J		BACC45FN14-4S9 RCPT-	81205	1	35-21-13 AP0403/ /	150-199, 275-299
D05750P		BACC45FT14-7P9 PLUG-P19	81205	1	35-21-14 AP0403/ /	050-099
D05750P		BACC45FT14-4P9 PLUG-P19	81205	1	35-21-14 AP0403/ /	150-199, 275-299
D05752J		BACC45FN12-3P9 RCPT-P25	81205	1	35-21-14 AP1005/ /	050-099
D05752P		BACC45FT12-3S9 PLUG-P25	81205	1	35-21-14 AP1005/ /	050-099
D05753J		BACC45FN22-55P8 RCPT E2-2	81205	1	31-31-23 AE0314/ /	ALL
D05753P		BACC45FT22A55S8 PLUG-E2-2	81205	1	31-31-21 AE0314/ /	ALL
D05760J		BACC45FN18-8S6 RCPT-P37	81205	1	38-32-21 AE0218/ /	ALL
D05760P		BACC45FT18-8P6 PLUG-P37	81205	1	38-32-21 AE0218/ /	ALL
D05763J		BACC45FN22-55S8 RCPT-E2-2	81205	1	34-61-25 AE0314/ /	ALL
D05763P		BACC45FT22A55P8 PLUG-E2-2	81205	1	34-61-25 AE0314/ /	ALL
D05764J		BACC45FN14-15S RCPT-P61	81205	1	36-11-52 AF0204/ /	ALL
D05764P		BACC45FT14-15P PLUG-P61	81205	1	36-11-52 AF0204/ /	ALL
D05766J		BACC45FN22-55P9 RCPT-	81205	1	36-11-52 AE0202/ /	ALL
D05766P		BACC45FT22-55S9 PLUG-P50	81205	1	36-11-52 AE0202/ /	ALL

EQUIPMENT LIST

D280T132

Section D05700

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05768J		BACC45FN24-61P8 RCPT-P37	81205	1	36-11-52 AE0218/ /	ALL
D05768P		BACC45FT24-61S8 PLUG-P37	81205	1	36-11-52 AE0218/ /	ALL
D05780J		BACC45FN20-41P7 RCPT-P36	81205	1	36-11-61 AE0209/ /	ALL
D05780P		BACC45FT20-41S7 PLUG-P36	81205	1	36-11-61 AE0209/ /	ALL
D05782J		BACC45FN16-24P RCPT-E3-1	81205	1	36-11-61 AE0220/ /	ALL
D05782P		BACC45FT16-24S PLUG-E3-1	81205	1	36-11-61 AE0220/ /	ALL
D05784J		BACC45FN18-31S8 RCPT-P61	81205	1	33-16-12 AF0204/ /	ALL
D05784P		BACC45FT18-31P8 PLUG-P61	81205	1	33-11-11 AF0204/ /	ALL
D05792J		BACC45FN18-31S6 RCPT-P61	81205	1	33-11-13 AF0204/ /	ALL
D05792P		BACC45FT18-31P6 PLUG-P61	81205	1	33-11-11 AF0204/ /	ALL
D05798J		BACC45FN24-61P RCPT-P33	81205	1	30-34-11 AE0207/ /	ALL
D05798P		BACC45FT24-61S PLUG-P33	81205	1	30-32-11 AE0207/ /	ALL

EQUIPMENT LIST

D280T132

Section D05700

Page 6 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05800J		BACC45FN14-12P8 RCPT-P33	81205	1	30-34-11 AE0203/ /	ALL
D05800P		BACC45FT14-12S8 PLUG-P33	81205	1	28-22-11 AE0203/ /	ALL
D05801J		KA-19-198-M06 RCPT-COAXIAL	91836	1	23-32-13 AP1501/ /	050-099, 150-154, 162-164, 275-276
D05801J		KA-19-143 RCPT-COAXIAL	91836	1	23-32-13 AP1501/ /	155-157, 165-199, 277-299
D05801P		KA-59-392-M06 PLUG-COAXIAL	91836	1	23-32-13 AP1501/ /	ALL
D05802J		BACC45FN22-55S6 RCPT-E3-1	81205	1	36-11-62 AE0220/ /	ALL
D05802P		BACC45FT22-55P6 PLUG-E3-1	81205	1	36-23-21 AE0220/ /	ALL
D05808J		BACC45FN16-10S7 RCPT-P19	81205	1	33-21-11 AP0403/ /	050-099
D05808J		BACC45FN18-8S7 RCPT-	81205	1	33-21-11 AP0403/ /	150-199, 275-299
D05808P		BACC45FT16-10P7 PLUG-P19	81205	1	33-21-13 AP0403/ /	050-099
D05808P		BACC45FT18-8P7 PLUG-P19	81205	1	33-21-13 AP0403/ /	150-199, 275-299
D05809J		BACC45FN16-24S6 RCPT-P1	81205	1	34-22-16 AF0119/ /	ALL
D05809P		BACC45FT16-24P6 PLUG-P1	81205	1	34-22-16 AF0119/ /	ALL
D05810J		BACC45FM14C7P RCPT-P56	81205	1	33-31-11 P056-00/ /	ALL
D05810P		BACC63BP14R7SNL PLUG-P56	81205	1	33-31-11 P056-00/ /	ALL
D05810PQ		710AA011M1412-62A ADAPTER-90 DEGREES	06324	1	33-31-11 / /	ALL
D05813J		BACC45FN16-24S6 RCPT-P1	81205	1	34-22-26 AF0119/ /	ALL

EQUIPMENT LIST

D280T132

Section D05800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05813P		BACC45FT16-24P6 PLUG-P1	81205	1	34-22-26 AF0119/ /	ALL
D05817J		BACC45FN16-24P6 RCPT-E1-5	81205	1	22-23-23 AE0305/ /	ALL
D05817P		BACC45FT16A24S6 PLUG-E1-5	81205	1	22-23-23 AE0305/ /	ALL
D05820J		BACC45FN16-24S9 RCPT-P33	81205	1	30-71-23 AE0203/ /	ALL
D05820P		BACC45FT16-24P9 PLUG-P33	81205	1	30-71-23 AE0203/ /	ALL
D05821J		BACC45FN18-31S8 RCPT-E1-3	81205	1	22-23-12 AE0317/ /	ALL
D05821P		BACC45FT18A31P8 PLUG-E1-3	81205	1	22-23-13 AE0317/ /	ALL
D05822J		BACC45FN18-31S7 RCPT-P37	81205	1	76-11-11 AE0218/ /	ALL
D05822P		BACC45FT18-31P7 PLUG-P37	81205	1	76-11-11 AE0218/ /	ALL
D05824J		BACC45FN16-10S8 RCPT-P49	81205	1	38-15-11 AC1402/ /	ALL
D05824P		BACC45FT16-10P8 PLUG-P49	81205	1	38-15-11 AC1402/ /	ALL
D05827J		BACC45FN14-15P8 RCPT-E1-3	81205	1	34-45-12 AE0305/ /	050-099, 150-152, 277-299
D05827J		BACC45FN14-15P8 RCPT-E1-3	81205	1	34-45-12 355/125/L 36	155-199
D05827P		BACC45FT14A15S8 PLUG-E1-3	81205	1	34-45-14 AE0305/ /	050-099, 150-152, 155-199, 275-299
D05828J		BACC45FN14-4S RCPT-P6	81205	1	22-23-21 AF0232/ /	ALL
D05828P		BACC45FT14-4P PLUG-P6	81205	1	34-21-21 AF0232/ /	ALL
D05832J		BACC45FN22-55P8 RCPT-P36	81205	1	76-11-21 AE0209/ /	ALL

EQUIPMENT LIST

D280T132

Section D05800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05832P		BACC45FT22-55S8 PLUG-P36	81205	1	73-21-11 AE0209/ /	ALL
D05840J		BACC45FN16-24S RCPT-P33	81205	1	30-11-11 AE0203/ /	ALL
D05840P		BACC45FT16-24P PLUG-P33	81205	1	36-11-62 AE0203/ /	ALL
D05842J		BACC45FN20-28S RECP-	81205	1	28-21-11 AE0307/ /	ALL
D05842P		BACC45FT20A28P PLUG-E2-4	81205	1	29-11-32 AE0307/ /	ALL
D05846J		BACC45FN16-24S RCPT-P6	81205	1	24-23-11 AF0232/ /	ALL
D05846P		BACC45FT16-24P PLUG-P6	81205	1	24-11-21 AF0232/ /	ALL
D05848J		BACC45FN16-24S8 RCPT-P6	81205	1	24-23-11 AF0232/ /	ALL
D05848P		BACC45FT16-24P8 PLUG-P6	81205	1	24-23-11 AF0232/ /	ALL
D05850J		BACC63BV24A30S8 RCPT-NOSE WW DISC	81205	1	32-61-13 AL0202/ /	050-099, 155-199, 275-299
D05850J		BACC45FM22C19S8 RCPT-NOSE WW DISC	81205	1	32-61-13 AL0202/ /	150-154
D05850P		BACC63BP24A30P8L PLUG-NOSE WW DISC	81205	1	32-61-13 AL0202/ /	050-099, 155-199, 275-299
D05850P		BACC63BP22A19P8L PLUG-NOSE WW DISC	81205	1	32-61-13 AL0202/ /	150-154
D05852J		BACC45FN12-12P8 RCPT-E2-5	81205	1	23-41-11 AE0322/ /	ALL
D05852P		BACC45FT12A12S8 PLUG-E2-5	81205	1	23-41-11 AE0322/ /	ALL
D05854J		BACC45FN22-32S7 RCPT-P61	81205	1	21-58-16 AF0204/ /	ALL
D05854P		BACC45FT22-32P7 PLUG-P61	81205	1	22-23-11 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D05800

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05858J		BACC45FN18-8S9 RCPT-P6	81205	1	27-51-11 AE0222/ /	ALL
D05858P		BACC45FT18-8P9 PLUG-P6	81205	1	24-51-52 AE0222/ /	ALL
D05860J		BACC45FN22-12S6 RCPT-P33	81205	1	27-51-11 AE0203/ /	ALL
D05860P		BACC45FT22-12P6 PLUG-P33	81205	1	24-51-52 AE0203/ /	ALL
D05861J		BACC45FN16-24S9 RCPT-E2-2	81205	1	34-22-29 AE0320/ /	ALL
D05861P		BACC45FT16A24P9 PLUG-E2-2	81205	1	34-22-29 AE0320/ /	ALL
D05862J		BACC45FN16-10P RCPT-P37	81205	1	27-81-11 AE0218/ /	ALL
D05862P		BACC45FT16-10S PLUG-P37	81205	1	27-51-11 AE0218/ /	ALL
D05867J		BACC45FN18-31S8 RCPT-E1-2	81205	1	22-41-13 AE0319/ /	ALL
D05867P		BACC45FT18A31P8 PLUG-E1-2	81205	1	22-41-13 AE0319/ /	ALL
D05868J		BACC45FN18-14S RCPT-P6	81205	1	27-81-11 AE0222/ /	ALL
D05868P		BACC45FT18-14P PLUG-P6	81205	1	27-81-11 AE0222/ /	ALL
D05870J		BACC45FN12-12S RCPT-	81205	1	30-41-11 0215/270/R046	ALL
D05870P		BACC45FT12C12P PLUG-	81205	1	30-41-11 0215/270/R046	ALL
D05872J		BACC45FN12-12P RCPT-	81205	1	30-41-12 0196/264/L043	ALL
D05872P		BACC45FT12C12S PLUG-	81205	1	30-41-12 0196/264/L043	ALL
D05874J		BACC45FN14-15S RCPT-P49	81205	1	36-11-41 AC1402/ /	ALL

EQUIPMENT LIST

D280T132

Section D05800

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05874P		BACC45FT14-15P PLUG-P49	81205	1	36-11-41 AC1402/ /	ALL
D05878J		BACC45FN14C3P9 RCPT-E2-4	81205	1	28-41-23 AE0320/ /	ALL
D05878P		BACC45FT14C3S9 PLUG-E2-4	81205	1	28-41-23 AE0320/ /	ALL
D05880J		BACC45FM18C11S7 RCPT-	81205	1	28-41-23 AL1002/ /	ALL
D05880P		BACC63BP18A11P7L PLUG-R WING RS/BODY	81205	1	28-41-23 AL1002/ /	ALL
D05880PQ		BACC10KD18 CLAMP-	81205	1	28-41-23 / /	ALL
D05884J		BACC45FM18C11S7 RCPT-	81205	1	28-41-23 AL1001/ /	ALL
D05884P		BACC63BP18A11P7L PLUG-L WING RS/BODY	81205	1	28-41-23 AL1001/ /	ALL
D05884PQ		BACC10KD18 CLAMP-	81205	1	28-41-23 / /	ALL
D05886J		BACC45FN14-15S RCPT-P35	81205	1	33-31-61 AC0506/ /	ALL
D05886P		BACC45FT14-15P PLUG-P35	81205	1	33-31-61 AC0506/ /	ALL
D05888J		BACC45FN14-15S RCPT-P39	81205	1	33-31-61 AC1304/ /	ALL
D05888P		BACC45FT14-15P PLUG-P39	81205	1	33-31-61 AC1304/ /	ALL
D05890J		BACC45FN14-12S9 RCPT-P33	81205	1	28-22-11 AE0207/ /	ALL
D05890P		BACC45FT14-12P9 PLUG-P33	81205	1	28-22-11 AE0207/ /	ALL
D05892J		BACC45FN14-7S RCPT-	81205	1	28-22-11 AE0209/ /	ALL
D05892P		BACC45FT14-7P PLUG-P36	81205	1	28-22-11 AE0209/ /	ALL

EQUIPMENT LIST

D280T132

Section D05800

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05894J		BACC45FN20-25S7 RCPT-P36	81205	1	27-51-31 AE0223/ /	ALL
D05894P		BACC45FT20-25P7 PLUG-P36	81205	1	27-51-31 AE0223/ /	ALL

EQUIPMENT LIST

D280T132

Section D05800
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05904J		BACC45FN10-5S6 RCPT-P49	81205	1	21-31-21 AC1402/ /	ALL
D05904P		BACC45FT10-5P6 PLUG-E6	81205	1	21-31-11 AC1402/ /	ALL
D05906J		BACC45FN20-41S RCPT-P61	81205	1	30-31-21 AF0204/ /	ALL
D05906P		BACC45FT20-41P PLUG-P61	81205	1	30-31-21 AF0204/ /	ALL
D05908J		BACC45FN20-41P6 RCPT-P33	81205	1	30-33-21 AE0203/ /	ALL
D05908P		BACC45FT20-41S6 PLUG-P33	81205	1	30-31-21 AE0203/ /	ALL
D05910J		BACC45FN22-12S7 RCPT-P61	81205	1	28-22-11 AF0204/ /	ALL
D05910P		BACC45FT22-12P7 PLUG-P61	81205	1	30-32-11 AF0204/ /	ALL
D05912J		BACC45FN14-15S8 RCPT-P19	81205	1	33-21-11 AP0403/ /	050-099
D05912J		BACC45FN16-24S8 RCPT-	81205	1	33-21-11 AP0403/ /	150-199, 275-299
D05912P		BACC45FT14-15P8 PLUG-P19	81205	1	33-21-11 AP0403/ /	050-099
D05912P		BACC45FT16-24P8 PLUG-P19	81205	1	33-21-11 AP0403/ /	150-199, 275-299
D05914J		BACC45FN18-14S9 RCPT-P25	81205	1	33-21-13 AP1005/ /	050-099
D05914J		BACC45FN18-14S9 RCPT-	81205	1	33-21-13 AP1005/ /	150-199, 275-299
D05914P		BACC45FT18-14P9 PLUG-P25	81205	1	33-21-11 AP1005/ /	ALL
D05916J		BACC45FN16-10S8 RCPT-P25	81205	1	33-21-13 AP1003/ /	050-099
D05916J		BACC45FN16-10S8 RCPT-	81205	1	33-21-13 AP1003/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D05900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05916P		BACC45FT16-10P8 PLUG-P25	81205	1	33-21-14 AP1003/ /	ALL
D05918J		BACC45FN18-14S9 RCPT-P6	81205	1	28-22-11 AF0232/ /	ALL
D05918P		BACC45FT18-14P9 PLUG-P6	81205	1	28-22-11 AF0232/ /	ALL
D05920J		BACC45FN22-12S6 RCPT-P6	81205	1	24-11-21 AF0232/ /	ALL
D05920P		BACC45FT22-12P6 PLUG-P6	81205	1	28-22-11 AF0232/ /	ALL
D05928J		BACC45FN22-12S7 RCPT-P61	81205	1	21-58-14 AF0204/ /	ALL
D05928P		BACC45FT22-12P7 PLUG-P61	81205	1	28-22-11 AF0204/ /	ALL
D05930J		BACC45FN16-10P7 RCPT-P36	81205	1	21-58-14 AE0223/ /	ALL
D05930P		BACC45FT16-10S7 PLUG-P36	81205	1	28-22-11 AE0223/ /	ALL
D05932J		BACC45FN12-12S6 RCPT-E2-1	81205	1	30-41-12 AE0320/ /	ALL
D05932P		BACC45FT12A12P6 PLUG-E2-1	81205	1	30-41-12 AE0320/ /	ALL
D05934J		BACC45FN22-32S RCPT-P6	81205	1	24-11-11 AF0232/ /	ALL
D05934P		BACC45FT22-32P PLUG-P6	81205	1	28-22-12 AF0232/ /	ALL
D05936J		BACC45FM22C19S RCPT-P40	81205	1	26-22-21 AL0201/ /	ALL
D05936P		BACC45FS22C19P PLUG-P40	81205	1	26-22-21 AL0201/ /	050-099, 275-299
D05936P		BACC63BP22A19PNL PLUG-P40	81205	1	26-22-21 AL0201/ /	150-199
D05936PQ		BACC10KD22 CLAMP-	81205	1	26-22-21 / /	150-154, 156-157, 166-199

EQUIPMENT LIST

D280T132

Section D05900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05938J		BACC45FM22C19S6 RCPT-P40	81205	1	26-22-21 AL0201/ /	050-099, 155-199, 275-299
D05938J		BACC45FM22C19S6 RCPT-P40	81205	1	33-51-21 AL0201/ /	150-154
D05938P		BACC45FS22C19P6 PLUG	81205	1	33-51-21 AL0201/ /	050-099
D05938P		BACC63BP22A19P6L PLUG-P40	81205	1	26-22-21 AL0201/ /	150-154
D05938P		BACC63BP22R19P6L PLUG-P40	81205	1	33-51-21 AL0201/ /	155-199
D05938P		BACC45FS22C19P6 PLUG-P40	81205	1	33-51-21 AL0201/ /	275-276, 280-299
D05938P		BACC63BP22A19P6L PLUG-P40	81205	1	33-51-21 AL0201/ /	277-278
D05938PQ		BACC10KD22 CLAMP-	81205	1	26-22-21 / /	150-154
D05938PQ		BACC10KD22 CLAMP-	81205	1	33-51-21 / /	155-199, 277-278
D05942J		BACC45FN14-7P6 RCPT-TAIL/BODY	81205	1	27-23-11 AP1501/ /	ALL
D05942P		BACC45FT14-7S6 PLUG-TAIL/BODY	81205	1	27-23-11 AP1501/ /	ALL
D05946J		BACC45FN22-55S6 RCPT-P33	81205	1	30-71-22 AE0203/ /	050-099, 150-199
D05946J		BACC45FN18-31S6 RCPT-P33	81205	1	30-71-22 AE0203/ /	275-299
D05946P		BACC45FT22-55P6 PLUG-P33	81205	1	30-71-21 AE0203/ /	050-099, 150-199
D05946P		BACC45FT18-31P6 PLUG-P33	81205	1	30-71-21 AE0203/ /	275-299
D05948J		BACC45FN10-5S RCPT-	81205	1	21-44-11 AC1201/ /	ALL
D05948P		BACC45FT10-5P PLUG-	81205	1	21-44-11 AC1201/ /	ALL

EQUIPMENT LIST

D280T132

Section D05900

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05950J		BACC45FN10-5S6 RCPT-	81205	1	21-44-11 AC1201/ /	ALL
D05950P		BACC45FT10-5P6 PLUG-	81205	1	21-44-11 AC1201/ /	ALL
D05952J		BACC45FN20-25S8 RCPT-P36	81205	1	38-32-11 AE0209/ /	ALL
D05952P		BACC45FT20-25P8 PLUG-P36	81205	1	38-32-11 AE0209/ /	ALL
D05954J		BACC45FN14-12S9 RCPT-	81205	1	33-26-11 AP1003/ /	150-154, 275-299
D05954P		BACC45FT14-12P9 PLUG-P25	81205	1	33-26-11 AP1003/ /	275-299
D05960J		BACC45FN16-10S7 RCPT-P33	81205	1	30-71-21 AE0203/ /	ALL
D05960P		BACC45FT16-10P7 PLUG-P33	81205	1	30-71-21 AE0203/ /	ALL
D05962J		BACC45FN14-12S8 RCPT-P37	81205	1	30-71-21 AE0218/ /	275
D05962P		BACC45FT14-12P8 PLUG-P37	81205	1	30-71-21 AE0218/ /	150-154, 275
D05964J		BACC45FN12C12S RCPT-	81205	1	73-21-13 0139/194/L010	050-099
D05964J		BACC45FN12-12S RCPT-	81205	1	73-21-13 0139/194/L010	150-199, 275-299
D05966J		BACC45FN12-12S RCPT-	81205	1	73-21-13 0138/194/R010	ALL
D05968J		BACC45FN12-12S RCPT-	81205	1	33-24-13 0372/280/L005	050-099
D05968J		BACC45FN12-12S RCPT-	81205	1	33-24-13 0373/280/L005	150-199
D05968J		BACC45FN10-5S RCPT-	81205	1	33-24-13 0373/280/L005	275
D05968J		BACC45FN10-5S RCPT-	81205	1	33-24-13 0372/280/L005	276-299

EQUIPMENT LIST

D280T132

Section D05900

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05968P		BACC45FT12-12P PLUG-	81205	1	33-24-13 0373/280/0000	050-099, 150-199
D05968P		BACC45FT10-5P PLUG-	81205	1	33-24-13 0373/280/0000	275-278
D05968P		BACC45FT10-5P PLUG-	81205	1	33-24-13 0373/280/L005	280-299
D05970J		BACC45FN12-12P RCPT-	81205	1	33-24-13 0504/280/L005	050-099, 150-199
D05970J		BACC45FN10-5P RCPT-	81205	1	33-24-13 0504/280/L005	275-299
D05970P		BACC45FT12-12S PLUG-	81205	1	33-24-13 0504/280/L005	050-099, 150-199
D05970P		BACC45FT10-5S PLUG-	81205	1	33-24-13 0504/280/L005	275-299
D05972J		BACC45FN12-12P RECP-	81205	1	33-24-13 0636/280/L005	050-099
D05972J		BACC45FN12-12P PLUG-	81205	1	33-24-13 0636/280/L005	150-199
D05972J		BACC45FN10-5P RCPT-	81205	1	33-24-13 0636/280/L005	275-299
D05972P		BACC45FT12-12S PLUG-	81205	1	33-24-13 0636/280/L005	050-099, 150-199
D05972P		BACC45FT10-5S PLUG-	81205	1	33-24-13 0636/280/L005	275-299
D05974J		BACC45FN10-5P RCPT-	81205	1	33-24-13 0654+114/280/L005	275-299
D05974P		BACC45FT10-5S PLUG-	81205	1	33-24-13 0654+114/280/L005	275-299
D05976J		BACC45FN12-12P RCPT-	81205	1	33-24-13 0893/280/L005	050-099
D05976P		BACC45FT12-12S PLUG-	81205	1	33-24-13 0893/280/L005	050-099
D05978J		BACC45FN12-12P RCPT-	81205	1	33-24-13 1025/280/L005	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D05900

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05978J		BACC45FN10-5P RCPT-	81205	1	33-24-13 1025/280/L005	275-299
D05978P		BACC45FT12-12S PLUG-	81205	1	33-24-13 1025/280/L005	050-099, 150-199
D05978P		BACC45FT10-5S PLUG-	81205	1	33-24-13 1025/280/L005	275-299
D05980J		BACC45FN12-12P RCPT-	81205	1	33-24-13 1157/280/L005	050-099, 150-199
D05980J		BACC45FN10-5P RCPT-	81205	1	33-24-13 1157/280/L005	275-299
D05980P		BACC45FT12-12S PLUG-	81205	1	33-24-13 1157/280/L005	050-099, 150-199
D05980P		BACC45FT10-5S PLUG-	81205	1	33-24-13 1157/280/L005	275-299
D05982J		BACC45FN12-12P RCPT-	81205	1	33-24-13 1289/280/L005	050-099, 150-199
D05982J		BACC45FN10-5P RCPT-	81205	1	33-24-13 1289/280/L005	275-299
D05982P		BACC45FT12-12S PLUG-	81205	1	33-24-13 1289/280/L005	050-099, 150-199
D05982P		BACC45FT10-5S PLUG-	81205	1	33-24-13 1289/280/L005	275-299
D05984J		BACC45FN12-12P RCPT-	81205	1	33-24-13 1421/280/L005	050-099, 150-199
D05984J		BACC45FN10-5P RCPT-	81205	1	33-24-13 1421/280/L005	275-299
D05984P		BACC45FT12-12S PLUG-	81205	1	33-24-13 1421/280/L005	050-099, 150-199
D05984P		BACC45FT10-5S PLUG-	81205	1	33-24-13 1421/280/L005	275-299
D05988J		BACC45FN22-55S6 RCPT-	81205	1	21-51-11 AC0701/ /	ALL
D05988P		BACC45FT22-55P6 PLUG-	81205	1	21-51-11 AC0701/ /	ALL

EQUIPMENT LIST

D280T132

Section D05900

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D05990J		BACC45FN12-3P RCPT-	81205	1	35-21-14 0372/280/L005	050-099, 276-299
D05990J		BACC45FN12-3P RCPT-	81205	1	35-21-14 0373/280/L005	150-199, 275
D05990P		BACC45FT12-3S PLUG-	81205	1	35-21-14 0373/280/0000	ALL
D05992J		BACC45FN12-3P RCPT-	81205	1	35-21-14 0504/280/L005	ALL
D05992P		BACC45FT12-3S PLUG-	81205	1	35-21-14 0504/280/L005	ALL
D05994J		BACC45FN12-3P RCPT-	81205	1	35-21-14 636/280/L005	050-099
D05994J		BACC45FN12-3P RCPT-	81205	1	35-21-14 0636/280/L005	150-199, 275-299
D05994P		BACC45FT12-3S PLUG-	81205	1	35-21-14 0636/280/L005	ALL
D05996J		BACC45FN12-3P RCPT-	81205	1	35-21-14 0654+114/280/L005	275-299
D05996P		BACC45FT12-3S PLUG-	81205	1	35-21-14 0654+114/280/L005	275-299
D05997J		BACC45FN18-31P8 RCPT-E1-1	81205	1	22-22-11 AE0303/ /	ALL
D05997P		BACC45FT18A31S8 PLUG-E1-1	81205	1	22-21-21 AE0303/ /	ALL
D05998J		BACC45FN12-3P RCPT-	81205	1	35-21-14 0893/280/L005	050-099
D05998P		BACC45FT12-3S PLUG-	81205	1	35-21-14 0893/280/L005	050-099

EQUIPMENT LIST

D280T132

Section D05900
Page 7 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06000J		BACC45FN12-3P RCPT-	81205	1	35-21-14 1025/280/L005	ALL
D06000P		BACC45FT12-3S PLUG-	81205	1	35-21-14 1025/280/L005	ALL
D06002J		BACC45FN12-3P RCPT-	81205	1	35-21-14 1157/280/L005	ALL
D06002P		BACC45FT12-3S PLUG-	81205	1	35-21-14 1157/280/L005	ALL
D06004J		BACC45FN12-3P RCPT-	81205	1	35-21-14 1289/280/L005	ALL
D06004P		BACC45FT12-3S PLUG-	81205	1	35-21-14 1289/280/L005	ALL
D06006J		BACC45FN12-3P RCPT-	81205	1	35-21-14 1421/280/L005	ALL
D06006P		BACC45FT12-3S PLUG-	81205	1	35-21-14 1421/280/L005	ALL
D06012J		BACC45FM18C14S7 RCPT-	81205	1	32-44-11 AL1006/ /	ALL
D06012P		BACC63BP18A14P7L PLUG-	81205	1	32-44-11 AL1006/ /	ALL
D06012PQ		BACC10KD18 CLAMP-	81205	1	32-44-11 / /	ALL
D06023J		BACC45FN12-12P6 RCPT	81205	1	27-41-31 AC1402/190/R80	050-099, 155-199, 275-299
D06023P		BACC45FT12-12S6 PLUG	81205	1	27-41-31 AC1402/ /	050-099, 155-199, 275-299
D06025J		BACC45FN12-12P RCPT	81205	1	27-41-31 AC1402/190/R80	050-099, 155-199, 275-299
D06025P		BACC45FT12-12S PLUG	81205	1	27-41-31 AC1402/ /	050-099, 155-199, 275-299
D06026J		BACC45FN12-12S8 RCPT-	81205	1	25-63-11 AP0802E/ /	050-099
D06026J		BACC45FN12-12S8 RCTP-	81205	0	25-63-11 AP0901/ /	150-199

EQUIPMENT LIST

D280T132

Section D06000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06026J		BACC45FN12-12S7 RCTP-	81205	0	25-63-11 AP0703/ /	275-299
D06026P		BACC45FT12-12P8 PLUG-	81205	1	25-63-11 AP0802E/ /	050-099
D06026P		BACC45FT12-12P8 PLUG-	81205	1	25-63-11 AP0901/ /	150-199
D06026P		BACC45FT12-12P7 PLUG-	81205	1	25-63-11 AP0703/ /	275-299
D06027J		BACC45FN12-12P9 RCPT	81205	1	27-41-31 AC1402/ /	050-099, 155-199, 275-299
D06027P		BACC45FT12-12S9 PLUG	81205	1	27-41-31 1417/190/R 80	050-099, 155-199, 275-299
D06028J		BACC45FN10-5S6 RCPT	81205	1	33-22-31 AP0802E/ /	050-099
D06028J		BACC45FN10-5S6 RCPT-	81205	1	33-22-31 AP0901/ /	150-199
D06028J		BACC45FN10-5S6 RCPT-	81205	1	33-22-31 AP0703/ /	275-299
D06028P		BACC45FT10-5P6 PLUG-	81205	1	33-22-31 AP0802E/ /	050-099
D06028P		BACC45FT10-5P6 PLUG-	81205	1	33-22-31 AP0901/ /	150-199
D06028P		BACC45FT10-5P6 PLUG-	81205	1	33-22-31 AP0703/ /	275-299
D06029J		BACC45FN12-12P RCPT	81205	1	27-41-31 AC1402/ /	050-099, 155-199, 275-299
D06029P		BACC45FT12-12S PLUG	81025	1	27-41-31 1417/190/R 80	050-099, 155-199, 275-299
D06031J		BACC45FN20-41S8 RECP	81205	1	23-31-11 AP0307/ /	050-099, 162-199
D06031J		BACC45FN18-31S8 RECP	81205	1	23-31-11 AP0307/ /	150-157
D06031P		BACC45FT20-41P8 PLUG	81205	1	23-31-11 AP0307/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section D06000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06031P		BACC45FT18-31P8 PLUG	81205	1	23-31-11 AP0307/ /	150-157
D06033J		BACC45FN18-31S6 RCPT-	81205	1	23-42-11 AP0307/ /	050-099
D06033J		BACC45FN18-31S6 RECP	81205	1	23-42-11 AP0307/315/L08	150-199
D06033P		BACC45FT18-31P6 PLUG	81205	1	23-42-11 AP0307/ /	050-099, 150-199
D06035J		BACC45FN20-39S9 RCPT	81205	1	23-32-11 AP0307/ /	050-099
D06035J		BACC45FN20-39S9 RECP	81205	1	23-32-11 AP0307/ /	150-199
D06035P		BACC45FT20-39P9 PLUG	81205	1	23-32-11 AP0307/ /	050-099, 150-199
D06037J		280T1000-2 RECP-MOA PER DWG REF BACC45FN20-28S6	81205	1	23-32-11 AP0307/ /	050-099
D06037J		280T1000-2 RECP-MOA PER DWG REF BACC45FN20-28S6	81205	1	23-32-13 380/315/L 8	150-199
D06037P		280T1000-6 PLUG-MOA PER DWG REF BACC45FT20-28P6	81205	1	23-32-11 AP0307/ /	050-099
D06037P		280T1000-6 PLUG-MOA PER DWG REF BACC45FT20-28P6	81205	1	23-32-21 AP0307/ /	150-199
D06038J		BACC45FN16-24S RCPT-	81205	1	33-22-42 1505/280/R013	050-099
D06038J		BACC45FN16-24S RCPT-	81205	1	33-22-42 1518/283/R011	275-299
D06038P		BACC45FT16-24P PLUG-	81205	1	33-22-42 1518/280/R 11	050-099
D06038P		BACC45FT16-24P PLUG-	81205	1	33-27-11 1518/283/R011	275-299
D06039J		BACC45FN20-41S RECP	81205	1	23-32-21 AP0307/ /	050-099
D06039J		BACC45FN20-41S RECP	81205	1	23-32-21 380/315/L 8	150-199

EQUIPMENT LIST

D280T132

Section D06000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06039P		BACC45FT20-41P PLUG	81205	1	23-32-21 AP0307/ /	050-099, 150-199
D06041J		KC-19-308-M06 RECP	81205	1	23-32-13 AP0307/ /	050-099
D06041J		KC-19-308-M06 RECP	91836	1	23-32-13 AP0307/ /	150-199
D06041P		KC-59-604-M06 PLUG-COAXIAL	91836	1	23-32-13 AP0307/ /	050-099, 150-199
D06042J		BACC45FN16-24S6 RCPT-	81205	1	33-22-42 AP1401/ /	275-299
D06042P		BACC45FT16-24P6 PLUG-	81205	1	33-22-42 AP1401/ /	275-299
D06043J		BACC45FN22-55P7 RECP	81205	1	23-32-11 AP0405/ /	150-199
D06043P		BACC45FT22-55S7 PLUG	81205	1	23-31-11 AP0305/ /	050-099
D06043P		BACC45FT22-55S7 PLUG	81205	1	23-31-11 AP0405/ /	150-199
D06045J		280T1000-15 RECP-MOA PER DWG REF BACC45FN20-28P6	81205	1	23-32-13 AP0305/ /	050-099
D06045J		280T1000-15 RECP-MOA PER DWG REF BACC45FN20-28P6	81205	1	23-32-13 AP0405/ /	150-199
D06045P		280T1000-14 PLUG-MOA PER DWG REF BACC45FT20-28S6	81205	1	23-32-21 AP0305/ /	050-099
D06045P		280T1000-14 PLUG-MOA PER DWG REF BACC45FT20-28S6	81205	1	23-32-21 AP0405/ /	150-199
D06047J		BACC45FN20-39P9 RECP	81205	1	23-32-11 AP0305/ /	050-099
D06047J		BACC45FN20-39P9 RECP	81205	1	23-32-11 AP0405/ /	150-199
D06047P		BACC45FT20-39S9 PLUG	81205	1	23-32-21 AP0305/ /	050-099
D06047P		BACC45FT20-39S9 PLUG	81205	1	23-32-21 AP0405/ /	150-199

EQUIPMENT LIST

D280T132

Section D06000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06049J		KC-19-256 RECP-COAXIAL	91836	1	23-32-13 AP0405/ /	151-152
D06049P		KC-59-604-M06 PLUG-COAXIAL	91836	1	23-32-13 AP0305/ /	050-099
D06049P		KC-59-604-M06 PLUG-COAXIAL	91836	1	23-32-13 AP0405/ /	150-199
D06051J		BACC45FN10-5S RCPT-	81205	1	23-42-11 0639/295/R016	050-099
D06051J		BACC45FN10-5S RECP	81205	1	23-42-11 639/295/R016	150-199
D06051P		BACC45FT10-5P PLUG	81205	1	23-42-11 0639/295/R 16	050-099, 150-199
D06052J		BACC45FN16-24S6 RCPT-	81205	1	33-22-42 AP1402/ /	275-299
D06052P		BACC45FT16-24P6 PLUG-	81205	1	33-22-42 AP1402/ /	275-299
D06053J		BACC45FN10-5S RCPT-	81205	1	23-42-11 0639/295/L016	050-099
D06053J		BACC45FN10-5S RECP	81205	1	23-42-11 639/295/L016	150-199
D06053P		BACC45FT10-5P PLUG	81205	1	23-42-11 0639/295/L 16	050-099, 150-199
D06055J		BACC45FN10-5S RCPT-	81205	1	23-42-11 0860/295/R014	050-099
D06055J		BACC45FN10-5S RECP	81205	1	23-42-11 0860/295/R014	150-154, 156, 162-199
D06055J		BACC45FN10-5S RECP	81205	1	23-42-11 0888/295/R014	277-299
D06055P		BACC45FT10-5P PLUG	81205	1	23-42-11 0860/295/R 14	050-099, 150-154, 156, 162-199
D06055P		BACC45FT10-5P PLUG	81205	1	23-42-11 0888/295/R 14	277-299
D06057J		BACC45FN10-5S RCPT-	81205	1	23-42-11 0860/295/L014	050-099

EQUIPMENT LIST

D280T132

Section D06000

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06057J		BACC45FN10-5S RECP	81205	1	23-42-11 0860/295/L014	150-154, 156, 162- 199
D06057J		BACC45FN10-5S RECP	81205	1	23-42-11 0888/295/L014	277-299
D06057P		BACC45FT10-5P PLUG	81205	1	23-42-11 0860/295/L 14	050-099, 150-154, 156, 162-199
D06057P		BACC45FT10-5P PLUG	81205	1	23-42-11 0888/295/L 14	277-299
D06059J		BACC45FN10-5S RCPT-	81205	1	23-42-11 1197/295/L014	050-099
D06059J		BACC45FN10-5S RECP	81205	1	23-42-11 1197+52/295/L014	150-199
D06059P		BACC45FT10-5P PLUG	81205	1	23-42-11 1204/295/L 14	050-099
D06059P		BACC45FT10-5P PLUG	81205	1	23-42-11 1197+52/295/L 14	150-199
D06061J		BACC45FN10-5S RCPT-	81205	1	23-42-11 1197/295/R014	050-099
D06061J		BACC45FN10-5S RECP	81205	1	23-42-11 1197+52/295/R014	150-199
D06061P		BACC45FT10-5P PLUG	81205	1	23-42-11 1204/295/R 14	050-099
D06061P		BACC45FT10-5P PLUG	81205	1	23-42-11 1197+52/295/R 14	150-199
D06062J		BACC45FN16-24S RCPT-	81205	1	33-22-41 0330/283/L010	ALL
D06062P		BACC45FT16-24P PLUG-	81205	1	33-22-41 0330/283/L010	ALL
D06069J		BACC45FN18-31S7 RCPT	81205	1	23-31-12 AP0202/ /	275
D06069J		BACC45FN18-31S7 RCPT	81205	1	23-22-12 AP0205/ /	276-278
D06069P		BACC45FT18-31P7 PLUG	81205	1	23-22-12 AP0202/ /	275

EQUIPMENT LIST

D280T132

Section D06000

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06069P		BACC45FT18-31P7 PLUG	81205	1	23-22-12 AP0205/ /	276-278
D06074J		BACC45FN18-8S7 RCPT-	81205	1	21-58-14 AE0319/ /	ALL
D06074P		BACC45FT18A8P7 PLUG-	81205	1	21-58-14 AE0319/ /	ALL
D06076J		BACC45FN16-24P7 RCPT-P37	81205	1	21-51-21 AE0218/ /	ALL
D06076P		BACC45FT16-24S7 PLUG-P37	81205	1	21-51-21 AE0218/ /	ALL
D06078J		BACC45FM14-3S RCPT-	81205	1	28-41-23 AL1001/ /	ALL
D06078JK	1	S2407-12-9 ADP	07418	1	28-41-23 / /	ALL
D06078JK	2	MS27291-3 ADP	81205	1	28-41-23 / /	ALL
D06078P		BACC63BP14A3PNL PLUG-L WING RS/BODY	81205	1	28-41-23 AL1001/ /	ALL
D06078PQ	1	S2408-13-8 CLAMP-	07418	1	28-41-23 / /	ALL
D06078PQ	2	BACC10KD14 CLAMP-	81205	1	28-41-23 / /	ALL
D06079J		2971-2-1 RCPT	91836	1	34-45-11 368/315/0	050-099, 150-199, 277-299
D06079P		2975-2-1 PLUG	91836	1	34-45-11 368/315/0	050-099, 150-199, 277-299
D06080J		BACC45FM14C3S RCPT-R FWD OUTBD	81205	1	28-41-23 AL1002/ /	ALL
D06080P		BACC63BP14A3PNL PLUG-R WING RS/BODY	81205	1	28-41-23 AL1002/ /	ALL
D06080PQ	1	S2408-13-8 CLAMP-	07418	1	28-41-23 / /	ALL
D06080PQ	2	BACC10KD14 CLAMP-	81205	1	28-41-23 / /	ALL

EQUIPMENT LIST

D280T132

Section D06000

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06081J		2971-2-6 RCPT	91836	1	34-45-11 368/315/0	050-099, 150-199, 277-299
D06081P		2975-2-6 PLUG	91836	1	34-45-11 368/315/0	050-099, 150-199, 277-299
D06083J		2971-2-11 RCPT	91836	1	34-45-11 373/315/0	050-099, 150-199, 277-299
D06083P		2975-2-11 PLUG	91836	1	34-45-11 368/315/0	050-099, 150-199, 277-299
D06085J		2971-2-16 RCPT	91836	1	34-45-11 373/315/0	050-099, 150-199, 277-299
D06085P		2975-2-16 PLUG	91836	1	34-45-11 368/315/0	050-099, 150-199, 277-299
D06087J		2971-2-1 RCPT	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06087P		2975-2-1 PLUG	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06089J		2971-2-6 RCPT	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06089P		2975-2-6 PLUG	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06091J		2971-2-11 RCPT	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06091P		2975-2-11 PLUG	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06093J		2971-2-16 RCPT	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06093P		2975-2-16 PLUG	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06095J		2431-74-1 RCPT	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06095P		2435-74-1 PLUG	91836	1	34-45-11 AE0325/***/	050-099, 150-199, 277-299
D06096J		48-7191 RCPT-	02660	1	33-21-21 0455/284/R040	275-278

EQUIPMENT LIST

D280T132

Section D06000

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06096J		48-7191 RCPT-	02660	1	33-21-21 0451/286/R051	280-299
D06096P		48-7190 PLUG-	02660	1	33-21-21 0455/284/R040	275-299
D06097J		2431-74-1 RCPT	91836	1	34-45-11 AE0326/ /	050-099, 150-199, 277-299
D06097P		2435-74-1 RCPT	91836	1	34-45-11 AE0326/ /	050-099, 150-199, 277-299
D06098J		BACC45FN12-12P RCPT-	81205	1	33-21-11 0365/284/R025	275-299
D06098P		BACC45FT12-12S PLUG-	81205	1	33-21-11 0365/284/R025	275-278
D06098P		BACC45FT12-12S PLUG-	81205	1	33-21-11 0411/284/R027	280-299
D06099J		280T1000-12 RECP-MOA PER DWG REF BACC45FN20-28S9	71468	1	23-32-11 255/270/R020	275
D06099J		280T1000-12 RECP-MOA PER DWG REF BACC45FN20-28S9	71468	1	23-32-11 244/284/L013	276-278
D06099J		280T1000-23 RECP-MOA PER DWG REF BACC45FN20-28S	71468	1	23-32-11 AP0205/ /	280-299
D06099P		280T1000-10 PLUG-MOA PER DWG REF BACC45FT20-28P9	81205	1	23-32-21 AP0202/ /	275
D06099P		280T1000-10 PLUG-MOA PER DWG REF BACC45FT20-28P9	81205	1	23-32-21 AP0205/ /	276-278
D06099P		280T1000-26 PLUG-MOA PER DWG REF BACC45FT20-28P	81205	1	23-32-21 AP0205/ /	280-299

EQUIPMENT LIST

D280T132

Section D06000

Page 9 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06100J		BACC45FN12-12S RCPT-	81205	1	33-26-21 0383/284/R040	275-299
D06100P		BACC45FT12-12P PLUG-	81205	1	33-26-21 0364/284/R032	275-299
D06102J		48-7191 RCPT-	02660	1	33-21-21 0455/284/R040	275-299
D06102P		48-7190 PLUG-	02660	1	33-21-21 0456/284/R040	275-278
D06102P		48-7190 PLUG-	02660	1	33-21-21 0451/286/R051	280-299
D06103J		BACC45FN16-24S RECPT	81205	1	23-31-12 0352/284/L 49	275-299
D06103P		BACC45FT16-24P PLUG	81205	1	23-31-12 0352/284/L 49	275-299
D06105J		BACC45FN10-5S7 RCPT-	81205	1	23-34-15 AP0307/ /	050-099, 162-199
D06105P		BACC45FT10-5P7 PLUG	81205	1	23-34-15 AP0307/ /	050-099, 162-199
D06106J		BACC63BV18B14SN RCPT-TORQUE LINK	81205	1	32-45-12 0278/072/0000	050-099, 155-199, 275-299
D06106JK		BACC10KA18 CLAMP	81205	1	32-45-12 / /	050-099, 155-199, 275-299
D06106P		BACC63BP18B14PNL PLUG-TORQUE LINK	81205	1	33-42-21 278/72/0	050-099, 155-199, 275-299
D06107J		280T1000-20 RCPT-MOA PER DWG REF BACC45FN20-28S6	81205	1	23-34-15 AP0307/315/L 8	050-099, 162-199
D06107P		280T1000-21 PLUG-MOA PER DWG REF BACC45FT20-28P6	81205	1	23-34-15 AP0307/ /	050-099, 162-199
D06109J		280T1000-20 RECT-MOA PER DWG REF BACC45FN20-28S6	81205	1	23-34-15 AP0205/ /	050-099
D06109J		280T1000-20 RECPT-MOA PER DWG REF BACC45FN20-28S6	81205	1	23-34-15 AP0205/ /	162-199
D06109P		280T1000-21 PLUG	81205	1	23-34-15 AP0205/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section D06100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06110J		BACC45FN12-12P7 RCPT-	81205	1	26-15-11 AC1402/ /	ALL
D06110P		BACC45FT12-12S7 PLUG-	81205	1	26-15-11 AC1402/ /	ALL
D06111J		BACC45FN20-41S8 RECPT	81205	1	23-42-11 AP0205/ /	050-099, 162-199
D06111P		BACC45FT20-41P8 PLUG	81205	1	23-42-11 AP0205/ /	050-099, 162-199
D06112J		BACC45FN12-12P8 RCPT-	81205	1	26-15-11 AC1402/ /	ALL
D06112P		BACC45FT12-12S8 PLUG-	81205	1	26-15-11 AC1402/ /	ALL
D06114J		BACC45FM14C3S9 RCPT-	81205	1	28-21-12 AC0702/ /	ALL
D06114P		BACC63BP14A3P9L PLUG	81205	1	28-21-12 AC0702/ /	ALL
D06114PQ	1	S2408-13-8 CLAMP	07418	1	28-21-12 AC0702/ /	ALL
D06114PQ	2	BACC10KD14 CLAMP	81205	1	28-21-12 AC0702/ /	ALL
D06116J		BACC45FM14C3S9 RCPT-	81205	1	28-21-12 AC0701/ /	ALL
D06116P		BACC63BP14A3P9L PLUG	81205	1	28-21-12 AC0701/ /	ALL
D06116PQ	1	S2408-13-8 CLAMP	07418	1	28-21-12 AC0701/ /	ALL
D06116PQ	2	BACC10KD14 CLAMP	81205	1	28-21-12 AC0701/ /	ALL
D06119J		BACC45FN10-5P9 RCPT-E2-2	81205	1	34-53-13 AE0322/ /	ALL
D06119P		BACC45FT10A5S9 PLUG-E2-2	81205	1	34-53-13 AE0322/ /	ALL
D06123J		BACC45FN22-32S7 RECPT	81205	1	26-13-12 AP0205/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section D06100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06123P		BACC45FT22-32P7 PLUG	81205	1	26-13-12 AP0205/ /	050-099, 162-199
D06125J		BACC45FN20-25S7 RECPT	81205	1	23-34-15 AP0205/ /	050-099
D06125J		BACC45FN20-25S6 RECPT	81205	1	23-34-15 AP0205/ /	162-199
D06125P		BACC45FT20-25P7 PLUG	81205	1	23-34-15 AP0205/ /	050-099
D06125P		BACC45FT20-25P6 PLUG	81205	1	23-34-15 AP0205/ /	162-199
D06127J		2431-74-6 RCPT	91836	1	34-45-11 AE0326/ /	050-099, 150-152, 277-299
D06127J		2431-74-6 RCPT	91836	1	34-45-11 AEO326/ /	153-199
D06127P		2435-74-6 RCPT	91836	1	34-45-11 AE0326/ /	050-099, 150-199, 277-299
D06129J		2431-74-11 RCPT	91836	1	34-45-11 AEO326/ /	050-099, 150-199, 277-299
D06129P		2435-74-11 RCPT	91836	1	34-45-11 AE0326/ /	050-099, 150-199, 277-299
D06131J		2431-74-16 RCPT	91836	1	34-45-11 AE0326/ /	050-099, 150-199, 277-299
D06131P		2435-74-16 RCPT	91836	1	34-45-11 AE0326/ /	050-099, 150-199, 277-299
D06133J		2431-74-6 RCPT	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06133P		2435-74-6 PLUG	91836	1	34-45-11 AE0325/****	050-099, 150-199, 277-299
D06135J		2431-74-11 RCPT	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06135P		2435-74-11 PLUG	91836	1	34-45-11 AE0325/****	050-099, 150-199, 277-299
D06136J		BACC45FN12-12S RCPT-	81205	1	35-21-12 0358/284/L054	275-299

EQUIPMENT LIST

D280T132

Section D06100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06136P		BACC45FT12-12P PLUG-	81205	1	35-21-12 0358/284/L050	275-299
D06137J		2431-74-16 RCPT	91836	1	34-45-11 AE0325/ /	050-099, 150-199, 277-299
D06137P		2435-74-16 PLUG	91836	1	34-45-11 AE0325/***/	050-099, 150-199, 277-299
D06140J		BACC45FN16-24S9 RCPT-E2-4	81205	1	27-51-11 AE0320/ /	ALL
D06140P		BACC45FT16A24P9 PLUG-E2-4	81205	1	27-51-11 AE0320/ /	ALL
D06141 U		289T0241-11201 I.D. TAPE TEXT AS BELOW	71468	1	34-45-14 / /	153-154
D06141 V		289T0241-10403 I.D. TAPE TEXT AS BELOW	81205	1	34-45-14 E1-3/ /	153-154
D06141J		BACC45FN16-24S9 RCPT-E1-3	81205	1	34-45-14 AE0305/ /	050-099, 150-199, 277-299
D06141P		BACC45FT16A24P9 PLUG-E1-3	81205	1	34-45-14 AE0305/ /	ALL
D06143J		BACC45FN18-31P6 RCPT	81205	1	34-45-12 AE0305/ /	050-099, 150-152, 155-199, 275-299
D06143P		BACC45FT18A31S6 PLUG-E1-3	81205	1	34-45-12 AE0305/ /	050-099, 150-152, 155-199, 275-299
D06148J		BACC45FN10-5S RCPT	81205	1	33-22-41 AP0802E/ /	050-099
D06148J		BACC45FN10-5S7 PLUG	81205	1	33-22-42 654+105/285/L005	150-199
D06148J		BACC45FN10-5S8 RCPT	81205	1	33-22-42 AP0703/ /	275-299
D06148P		BACC45FT10-5P PLUG	81205	1	33-22-42 AP0802E/ /	050-099
D06148P		BACC45FT10-5P7 PLUG	81205	1	33-22-42 654+105/285/L005	150-199
D06148P		BACC45FT10-5P8 PLUG	81205	1	33-22-42 AP0703/ /	275-299

EQUIPMENT LIST

D280T132

Section D06100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06149J		BACC45FN20-39S RCPT-E9-1	81205	1	23-25-11 AC1102/ /	150, 153-199, 277-299
D06149P		BACC45FT20A39P PLUG-E9-1	81205	1	23-25-11 AC1102/ /	150, 153-155, 162-165, 277-299
D06149P		BACC45FT20A39P PLUG-E9-1	81205	1	23-25-13 AC1102/ /	156-157, 166-199
D06151J		BACC45FN20-39P RCPT-E2-2	81205	1	23-25-11 AE0306/ /	150, 153-199, 277-299
D06151P	9	BACC45FT20A39S PLUG-E2-2	81205	1	23-25-11 AE0306/ /	150, 153-155, 162-165
D06151P		BACC45FT20A39S PLUG-E2-2	81205	1	23-25-11 AE0306/ /	156-157, 166-199, 277-299
D06152J		BACC45FN20-41P RCPT-P6-5	81205	1	33-11-11 AF0232/ /	ALL
D06152P		BACC45FT20-41S PLUG-P6	81205	1	33-16-12 AF0232/ /	ALL
D06153J		BACC45FN16-24S7 RCPT-E2-6	81205	1	23-25-13 AE0306/ /	150, 153-199, 277-299
D06153P		BACC45FT16A24P7 PLUG-E2-6	81205	1	23-25-13 AE0306/ /	150, 153-199, 277-299
D06154J		BACC45FN18-31P8 RCPT-P6-5	81205	1	33-16-12 AF0232/ /	ALL
D06154P		BACC45FT18-31S8 PLUG-P6	81205	1	33-16-12 AF0232/ /	ALL
D06155J		BACC45FN16-24S9 RCPT-E9-1	81205	1	23-25-11 AC1102/ /	150, 153-199, 277-299
D06155P		BACC45FT16A24P9 PLUG-E9-1	81205	1	23-25-13 AC1102/ /	150, 153-155, 162-165
D06155P		BACC45FT16A24P9 PLUG-	81205	1	23-25-11 AC1102/ /	156-157, 166-199, 277-299
D06156J		BACC45FN20-41P6 RCPT-P6-5	81205	1	33-11-14 AF0232/ /	ALL
D06156P		BACC45FT20-41S6 PLUG-P6	81205	1	33-16-12 AF0232/ /	ALL

EQUIPMENT LIST

D280T132

Section D06100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06157J		BACC45FN16-24S8 RCPT-E2-3	81205	1	23-25-13 AE0322/ /	150, 153-199, 277-299
D06157P		BACC45FT16A24P8 PLUG-E2-3	81205	1	23-25-13 AE0322/ /	150, 153-155, 157-199, 277-299
D06157P		BACC45FT16-24P8 PLUG-E2-3	81205	1	23-25-13 AE0322/ /	156
D06158J		BACC45FN18-31P9 RCPT-P6-5	81205	1	33-11-11 AF0232/ /	ALL
D06158P		BACC45FT18-31S9 PLUG-P6	81205	1	33-16-12 AF0232/ /	ALL
D06159J		BACC45FN16-24S8 RCPT-E2-6	81205	1	23-25-14 AE0320/ /	150, 153-199, 277-299
D06159P		BACC45FT16A24P8 PLUG-E2-6	81205	1	23-25-14 AE0320/ /	150, 153-199, 277-299
D06160J		BACC45FN22-55P7 RCPT-P6-5	81205	1	33-11-11 AF0232/ /	ALL
D06160P		BACC45FT22-55S7 PLUG-P6	81205	1	33-16-12 AF0232/ /	ALL
D06161J		BACC45FN16-24P7 RCPT-E9-1	81205	1	23-25-11 AC1102/180/R80	156-157, 166-199, 277-299
D06161P		BACC45FT16A24S7 PLUG-E9-1	81205	1	23-25-11 AC1102/ /	167-199, 277-299
D06162J		BACC45FN22-55P6 RCPT-P6-5	81205	1	33-11-11 AF0232/ /	ALL
D06162P		BACC45FT22-55S6 PLUG-P6	81205	1	33-16-12 AF0232/ /	ALL
D06163J		BACC45FN16-24S RCPT-E11	81205	1	23-25-11 AP1101-1/169/L14	156-157, 166-199, 277-299
D06163P		BACC45FT16A24P PLUG-E11	81205	1	23-25-11 AP1101/294/L14	156-157, 166-199, 277-299
D06164J		BACC45FN18-31S7 RCPT-P6-5	81205	1	33-16-11 AE0222/ /	ALL
D06164P		BACC45FT18-31P7 PLUG-P6	81205	1	33-16-12 AE0222/ /	ALL

EQUIPMENT LIST

D280T132

Section D06100

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06165J	9	CUSTOMER-1 RECP-E9-1 (C MTO 230591-1)	CUST	1	23-25-13 / /	150, 153-155, 162-165
D06165J	9	CUSTOMER-1 RECEPT	CUST	1	23-32-21 1197/180/R080	152
D06165J		BACC45FN20-41S8 RCPT-E9-1	81205	1	23-25-16 1197+132/180/R80	156-157, 166-199, 277-299
D06165P	9	CUSTOMER-1 PLUG-E9-1 (C MTO 230591-1)	81205	1	23-25-13 1197/180/R080	150, 153-155, 162-165
D06165P	9	CUSTOMER PLUG	CUST	1	23-32-21 1197/180/R080	152
D06165P		BACC45FT20A41P8 PLUG-E9-1	81205	1	23-25-16 AC1102/ /	156-157, 166-199, 277-299
D06166J		BACC45FN18-31S8 RCPT-P6-5	81205	1	33-16-12 AE0222/ /	ALL
D06166P		BACC45FT18-31P8 PLUG-P6	81205	1	33-16-12 AE0222/ /	ALL
D06167J		BACC45FN16-24S RCPT-E10	81205	1	23-25-16 AP1001-1/070/L14	150, 153-199, 277-299
D06167P		BACC45FT16A24P PLUG-E10	81205	1	23-25-16 1070/294/L014	150, 153-155, 162-165
D06167P		BACC45FT16A24P PLUG-E10	81205	1	23-25-16 1070/294/L14	156-157, 166-199, 277-299
D06168J		BACC45FN20-41S6 RCPT-P6-5	81205	1	33-11-11 AE0222/ /	ALL
D06168P		BACC45FT20-41P6 PLUG-P6	81205	1	33-16-12 AE0222/ /	ALL
D06169J		BACC45FN16-24S PLUG	81205	1	23-25-16 1040/310/L015	156-157, 166, 277-299
D06169J		BACC45FN16-24S RECP	81205	1	23-25-16 1040/310/L015	167-199
D06170J		BACC45FN18-31S9 RCPT-P6-5	81205	1	33-11-11 AE0222/ /	ALL
D06170P		BACC45FT18-31P9 PLUG-P6	81205	1	33-16-12 AE0222/ /	ALL

EQUIPMENT LIST

D280T132

Section D06100

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06171J		BACC45FN16-24S6 RCPT-E9-1	81205	1	23-25-17 AC1102/ /	150, 153-199, 277-299
D06171P		BACC45FT16A24P6 PLUG-E9-1	81205	1	23-25-17 AC1102/ /	150, 153-199, 277-299
D06172J		BACC45FN18-31S RCPT-P6-5	81205	1	33-16-11 AF0232/ /	ALL
D06172P		BACC45FT18-31P PLUG-P6	81205	1	33-16-12 AF0232/ /	ALL
D06173J	9	CUSTOMER REPT-E9-1	CUST	1	23-25-14 AC1102/ /	152
D06173J		BACC45FN16-24S RCPT-E9-1	81205	1	23-25-17 AC1102/ /	150, 153-199, 277-299
D06173P		BACC45FT16A24P PLUG-E9-1	81205	1	23-25-17 AC1102/ /	150, 153-199, 277-299
D06174J		BACC45FN16-24S8 RCPT-P6-5	81205	1	33-16-12 AF0232/ /	ALL
D06174P		BACC45FT16-24P8 PLUG-P6	81205	1	33-16-12 AF0232/ /	ALL
D06175J		KA-19-216-M06 JACK	91836	1	23-25-12 AC1102/180/R080	150, 153-199, 277-299
D06175P		KA-59-251 PLUG	91836	1	23-25-12 AC1102/ /	150, 153-199, 277-299
D06175PQ		1800-7 ATTENUATOR-10DB	91836	1	23-25-12 AC1102/ /	150, 153-199, 277-299
D06177J		KC-19-328-M06 RECP	91836	1	23-25-12 AC1102/ /	150, 153-199, 277-299
D06177P		KC-59-383 PLUG	91836	1	23-25-12 AC1102/ /	150, 153-199, 277-299
D06178J		BACC45FN16-24S9 RCPT-P3	81205	1	77-21-11 AF0120/ /	ALL
D06178P		BACC45FT16-24P9 PLUG	81205	1	32-31-11 AF0120/ /	ALL
D06179J		KC-19-328-M06 JACK	91836	1	23-25-11 AP1101/ /	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section D06100

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06179P		KC-59-383 PLUG	91836	1	23-25-11 AP1101/ /	277-299
D06180J		BACC45FN18-31S6 RCPT-P1	81205	1	77-11-11 AF0120/ /	ALL
D06180P		BACC45FT18-31P6 PLUG	81205	1	32-42-12 AF0120/ /	ALL
D06181J		KA-19-213-M06 JACK	91836	1	23-25-11 AP1101/ /	156-157, 166-199, 277-299
D06181P		KA-59-353-M06 PLUG	91836	1	23-25-11 AP1101/ /	156-157, 166-199, 277-299
D06182J		BACC45FN16-24S7 RCPT-P1	81205	1	77-11-11 AF0120/ /	ALL
D06182P		BACC45FT16-24P7 PLUG	81205	1	77-12-12 AF0120/ /	ALL
D06183J		KA-19-213-M06 JACK	91836	1	23-25-17 AP1001/ /	150, 153-155, 162- 165
D06183J		KA-19-213-M06 JACK	91836	1	23-25-16 AP1001/ /	156-157, 166-199, 277-299
D06183P		KA-59-353-M06 PLUG	91836	1	23-25-16 AP1001/294/L014	150, 153-199
D06183P		KA-59-353-M06 PLUG	91836	1	23-25-16 AP1001/294/L14	277-299
D06184J		BACC45FN18-31S RCPT-P1	81205	1	77-11-11 AF0120/ /	ALL
D06184P		BACC45FT18-31P PLUG-	81205	1	73-31-11 AF0120/ /	ALL
D06185P		KA-59-353-M06 PLUG	91836	1	23-25-17 1081/294/L14	277-299
D06186J		BACC45FN22-55S6 RCPT-P1	81205	1	77-12-12 AF0120/ /	ALL
D06186P		BACC45FT22-55P6 PLUG-	81205	1	77-11-11 AF0120/ /	ALL
D06187J		KC-19-328-M06 JACK	91836	1	23-25-12 AP1001/ /	150, 153-199, 277- 299

EQUIPMENT LIST

D280T132

Section D06100

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06187P		KC-59-383 PLUG	91836	1	23-25-12 AP1001/ /	150, 153-199, 277-299
D06188J		BACC45FN10-5S7 RCPT	81205	1	33-22-31 AP0802E/ /	050-099
D06188J		BACC45FN10-5S7 RECPT	81205	1	33-22-31 AP0901/ /	150-199
D06188J		BACC45FN10-5S8 RECPT	81205	1	33-22-31 AP0703/ /	275-299
D06188P		BACC45FT10-5P7 PLUG-	81205	1	33-22-31 AP0802E/ /	050-099
D06188P		BACC45FT10-5P7 PLUG-	81205	1	33-22-31 AP0901/ /	150-199
D06188P		BACC45FT10-5P8 PLUG-	81205	1	33-22-31 AP0703/ /	275-299
D06191J		280T1000-18 RECPT REF: BACC45FN20-28S8	71468	1	23-32-11 500/270/R 73	050-099
D06192J		BACC45FN22-32S7 RCPT-P6	81205	1	28-22-12 AF0232/ /	ALL
D06192P		BACC45FT22-32P7 PLUG-P6	81205	1	28-22-12 AF0232/ /	ALL
D06198J		BACC45FN14-4P RCPT-	81205	1	32-35-11 0240/200/L040	ALL
D06198P		BACC45FT14-4S PLUG-	81205	1	32-35-11 0240/200/L040	ALL
D06199J		BACC45FN22-55S6 RCPT-E2-2	81205	1	34-61-17 AE0314/ /	157, 167-199, 275-299
D06199JK		-10101 I.D. TAPE - TEXT AS BELOW		1	34-61-17 SHELF/E2-/2	275-276
D06199P		BACC45FT22A55P6 PLUG-E2-2	81205	1	34-61-17 AE0314/ /	157, 167-199, 277-299
D06199P		BACC45FT22-55P6 PLUG-E2-2	81205	1	34-61-14 AE0314/ /	275-276
D06199PQ		BACC10GH22 BACKSHELL	81205	1	34-61-14 AEO314/POS/17	275-276

EQUIPMENT LIST

D280T132

Section D06100

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06199PR		-10201 I.D. TAPE - TEXT AS BELOW	85480	1	34-61-14 AEO314/POS/17	275-276

EQUIPMENT LIST

D280T132

Section D06100
Page 11 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06200J		MTC100-JH2-R12-AC RCPT-SHELL	06090	1	21-31-11 AE0219/ /	ALL
D06200JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-31-11 E8/ /	ALL
D06200JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	21-31-11 E8/ /	ALL
D06200P		MTC100-JH2-P12-AC PLUG-E8	06090	1	21-31-11 AE0219/ /	ALL
D06200PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-31-11 / /	ALL
D06200PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	21-31-11 / /	ALL
D06202J		MTC100-JH2-R12-BB RCPT-SHELL	06090	1	21-25-11 AE0219/ /	ALL
D06202JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-25-11 E8/ /	ALL
D06202JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-25-11 E8/ /	ALL
D06202P		MTC100-JH2-P12-BB PLUG-E8	06090	1	21-25-11 AE0219/ /	ALL
D06202PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-25-11 / /	ALL
D06202PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	21-25-11 / /	ALL
D06204J		MTC100-JH2-R12-BA RCPT-SHELL	06090	1	26-17-11 AE0219/ /	ALL
D06204JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	26-17-11 E8/ /	ALL
D06204JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	26-17-11 E8/ /	ALL
D06204P		MTC100-JH2-P12-BA PLUG-E8	06090	1	26-17-11 AE0219/ /	ALL
D06204PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	26-17-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06204PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	26-17-11 / /	ALL
D06206J		MTC100-JH2-R12-BD RCPT-SHELL	06090	1	21-31-21 AE0219/ /	ALL
D06206JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-31-21 E8/ /	ALL
D06206JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	21-31-21 E8/ /	ALL
D06206P		MTC100-JH2-P12-BD PLUG-E8	06090	1	21-31-21 AE0219/ /	ALL
D06206PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-31-21 / /	ALL
D06206PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	21-31-21 / /	ALL
D06208J		MTC100-JH2-R12-BC RCPT-SHELL	06090	1	27-38-11 AE0219/ /	ALL
D06208JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	27-38-11 E8/ /	ALL
D06208JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	27-38-11 E8/ /	ALL
D06208P		MTC100-JH2-P12-BC PLUG-E8	06090	1	27-38-11 AE0219/ /	ALL
D06208PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	27-38-11 / /	ALL
D06208PR		D-659-0004 INSERT BLANK -INSERT B	06090	1	27-38-11 / /	ALL
D06210J		MTC100-JH2-R12-DB RCPT-SHELL	06090	1	21-44-21 AE0219/ /	ALL
D06210JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-44-21 E8/ /	ALL
D06210JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-44-21 E8/ /	ALL
D06210P		MTC100-JH2-P12-DB PLUG-E8	06090	1	21-44-21 AE0219/ /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06210PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-44-21 / /	ALL
D06210PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	21-44-21 / /	ALL
D06212J		MTC100-JH2-R12-AA RCPT-SHELL	06090	1	21-25-11 AE0219/ /	ALL
D06212JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-25-11 E8/ /	ALL
D06212JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-25-11 / /	050-099, 150-154, 275-276
D06212JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-25-11 E8/ /	155-199, 277-299
D06212P		MTC100-JH2-P12-AA PLUG-E8	06090	1	21-25-11 AE0219/ /	ALL
D06212PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-25-11 / /	ALL
D06212PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	21-25-11 / /	ALL
D06214J		MTC100-JH2-R12-AB RCPT-SHELL	06090	1	29-32-11 AE0219/ /	ALL
D06214JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	29-32-11 E8/ /	ALL
D06214JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	29-32-11 E8/ /	ALL
D06214P		MTC100-JH2-P12-AB PLUG-E8	06090	1	29-32-11 AE0219/ /	ALL
D06214PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	29-32-11 / /	ALL
D06214PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	29-32-11 / /	ALL
D06216J		MTC100-JH2-R12-DC RCPT-SHELL	06090	1	24-28-11 AE0219/ /	ALL
D06216JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	24-28-11 E8/ /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06216JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	24-28-11 E8/ /	ALL
D06216P		MTC100-JH2-P12-DC PLUG-E8	06090	1	24-28-11 AE0219/ /	ALL
D06216PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	24-28-11 / /	ALL
D06216PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	24-28-11 / /	ALL
D06218J		MTC100-JH2-R12-CD RCPT-SHELL	06090	1	21-58-16 AE0219/ /	ALL
D06218JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-58-16 E8/ /	ALL
D06218JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-58-16 E8/ /	ALL
D06218P		MTC100-JH2-P12-CD PLUG-E8	06090	1	21-58-16 AE0219/ /	ALL
D06218PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-58-16 / /	ALL
D06218PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	21-58-16 / /	ALL
D06220J		MTC100-JH2-R12-DA RCPT-SHELL	06090	1	26-11-11 AE0219/ /	ALL
D06220JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	26-11-11 E8/ /	ALL
D06220JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	26-11-11 E8/ /	ALL
D06220P		MTC100-JH2-P12-DA PLUG-E8	06090	1	26-11-11 AE0219/ /	ALL
D06220PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	26-11-11 / /	ALL
D06220PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	26-11-11 / /	ALL
D06222J		MTC100-JH2-R12-AD RCPT-SHELL	06090	1	24-27-41 AE0219/ /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06222JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	24-27-41 E8/ /	ALL
D06222JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	24-27-41 E8/ /	ALL
D06222P		MTC100-JH2-P12-AD PLUG-E8	06090	1	24-27-41 AE0219/ /	ALL
D06222PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	24-27-41 / /	ALL
D06222PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	24-27-41 / /	ALL
D06223J		BACC45FN22-55P6 RCPT-E2-3	81205	1	34-61-15 AE0322/ /	ALL
D06223JL		-11301 I. D. TAPE TEXT AS BELOW	85480	1	34-61-15 AE0322/ /	150-154
D06223P		BACC45FT22A55S6 PLUG-E2-3	81205	1	34-61-15 AE0322/ /	ALL
D06223PR		-10701 I. D. TAPE TEXT AS BELOW	85480	1	34-61-15 AE0322/ /	150-154
D06224J		MTC100-JH2-R12-BB RCPT-SHELL	06090	1	27-88-11 AE0219/ /	ALL
D06224JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	27-88-11 E8/ /	ALL
D06224JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	27-88-11 E8/ /	ALL
D06224P		MTC100-JH2-P12-BB PLUG-E8	06090	1	27-88-11 AE0219/ /	ALL
D06224PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	27-88-11 / /	ALL
D06224PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	27-88-11 / /	ALL
D06225J		BACC45FN22-55P9 RCPT-	81205	1	34-61-15 AF0204/ /	050-099
D06225J		BACC45FN22-55P8 RCPT-	81205	1	34-61-15 AF0204/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D06200

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06225P		BACC45FT22A55S9 PLUG-P61	81205	1	34-61-15 AF0204/ /	050-099
D06225P		BACC45FT22A55S8 PLUG-P61	81205	1	34-61-15 AF0204/ /	150-199, 275-299
D06225PR		-11302 I. D. TAPE TEXT AS BELOW	85480	1	34-61-15 AF0204/ /	150-154
D06226J		MTC100-JH2-R12-BC RCPT-SHELL	06090	1	27-51-41 AE0219/ /	ALL
D06226JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	27-51-41 E8/ /	ALL
D06226JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	27-51-41 E8/ /	ALL
D06226P		MTC100-JH2-P12-BC PLUG-E8	06090	1	27-51-41 AE0219/ /	ALL
D06226PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	27-51-41 / /	ALL
D06226PR		D-659-0004 BLANK-INSERT B	06080	1	27-51-41 / /	ALL
D06228J		MTC100-JH2-R12-DC RCPT-SHELL	06090	1	32-61-14 AE0219/ /	ALL
D06228JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	32-61-14 E8/ /	ALL
D06228JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	32-61-14 E8/ /	ALL
D06228P		MTC100-JH2-P12-DC PLUG-E8	06090	1	32-61-14 242/169/L 58	ALL
D06228PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	32-61-14 / /	ALL
D06228PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	32-61-14 / /	ALL
D06230J		MTC100-JH2-R12-DD RCPT-SHELL	06090	1	21-44-21 AE0219/ /	ALL
D06230JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-44-21 E8/ /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06230JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-44-21 E8/ /	ALL
D06230P		MTC100-JH2-P12-DD PLUG-E8	06090	1	21-44-21 242/169/L 58	ALL
D06230PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-44-21 / /	ALL
D06230PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	21-44-21 / /	ALL
D06232J		MTC100-JH2-R12-BD RCPT-SHELL	06090	1	24-11-11 AE0219/ /	ALL
D06232JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	24-11-11 E8/ /	ALL
D06232JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	24-11-11 E8/ /	ALL
D06232P		MTC100-JH2-P12-BD PLUG-E8	06090	1	24-11-11 AE0219/ /	ALL
D06232PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	24-11-11 / /	ALL
D06232PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	24-11-11 / /	ALL
D06234J		MTC100-JH2-R12-AB RCPT-SHELL	06090	1	24-11-21 AE0219/ /	ALL
D06234JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	24-11-21 E8/ /	ALL
D06234JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	24-11-21 E8/ /	ALL
D06234P		MTC100-JH2-P12-AB PLUG-E8	06090	1	24-11-21 AE0219/ /	ALL
D06234PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	24-11-21 / /	ALL
D06234PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	24-11-21 / /	ALL
D06236J		MTC100-JH2-R12-AC RCPT-SHELL	06090	1	21-52-21 AE0219/ /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06236JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-52-21 E8/ /	ALL
D06236JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-52-21 E8/ /	ALL
D06236P		MTC100-JH2-P12-AC PLUG-E8	06090	1	21-52-41 AE0219/ /	ALL
D06236PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-52-41 / /	ALL
D06236PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	21-52-41 / /	ALL
D06237		BACC45FN22-32P RECP-	81208	1	33-26-21 367/278/L058	280-299
D06238J		MTC100-JH2-R12-AD RCPT-SHELL	06090	1	73-31-11 AE0219/ /	ALL
D06238JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	73-31-11 E8/ /	ALL
D06238JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	73-31-11 E8/ /	ALL
D06238P		MTC100-JH2-P12-AD PLUG-E8	06090	1	73-31-11 AE0219/ /	ALL
D06238PQ		MTC100-JA2-S11-T14 SECT A	06090	1	73-31-11 / /	ALL
D06238PR		D-659-0004BLANK SECT B BLANK	06090	1	73-31-11 / /	ALL
D06240J		MTC100-JH2-R12-CA RCPT-SHELL	06090	1	73-31-11 AE0219/ /	ALL
D06240JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	73-31-11 E8/ /	ALL
D06240JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	73-31-11 E8/ /	ALL
D06240P		MTC100-JH2-P12-CA PLUG-E8	06090	1	73-31-11 AE0219/ /	ALL
D06240PQ		MTC100-JA2-S11-T14 SECT A	06090	1	73-31-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06240PR		D-659-0004BLANK SECT B BLANK	06090	1	73-31-11 / /	ALL
D06242J		MTC100-JH2-R12-CA RCPT-SHELL	06090	1	21-26-11 AE0219/ /	ALL
D06242JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-26-11 E8/ /	ALL
D06242JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-26-11 E8/ /	ALL
D06242P		MTC100-JH2-P12-CA PLUG-E8	06090	1	21-58-11 AE0219/ /	ALL
D06242PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	21-58-11 / /	ALL
D06242PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	21-58-11 / /	ALL
D06244J		MTC100-JH2-R12-CC RCPT-SHELL	06090	1	29-31-11 AE0219/ /	ALL
D06244JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	29-31-11 E8/ /	ALL
D06244JL		D-659-0004 INSERT BLANK-INSERT B	06090	1	29-31-11 E8/ /	ALL
D06244P		MTC100-JH2-P12-CC PLUG-E8	06090	1	29-31-11 AE0219/ /	ALL
D06244PQ		MTC100-JA2-S11-T14 INSERT A	06090	1	29-31-11 / /	ALL
D06244PR		D-659-0004 INSERT BLANK-INSERT B	06090	1	29-31-11 / /	ALL
D06246J		MTC100-JH2-R12-CB RCPT-SHELL	06090	1	21-44-21 AE0219/ /	ALL
D06246JK		284T1015-1 CABLE ASSY-INSERT A	81205	1	21-44-21 E8/ /	ALL
D06246JL		284T1015-2 CABLE ASSY-INSERT B	81205	1	21-44-21 E8/ /	ALL
D06246P		MTC100-JH2-P12-CB PLUG-E8	06090	1	36-11-51 AE0219/ /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06246PQ		MTC100-JA2-S11-T14 WAFER-INSERT A	06090	1	36-11-51 / /	ALL
D06246PR		MTC100-JB2-S11-T16 WAFER-INSERT B	06090	1	36-11-51 / /	ALL
D06252J		BACC45FN16-24S7 RCPT-P33	81205	1	21-51-22 AE0203/ /	ALL
D06252P		BACC45FT16-24P7 PLUG-P33	81205	1	21-51-22 AE0203/ /	ALL
D06253J		BACC45FN16-24S RECEPTICLE	81205	1	23-25-15 SHELF/E09/01	167-199
D06254J		BACC45FN12-12S8 RCPT-E8	81205	1	31-41-11 AE0221/ /	ALL
D06254P		BACC45FT12A12P8 PLUG-E8	81205	1	77-21-11 AE0221/ /	ALL
D06256J		BACC45FN12-12S9 RCPT-E8	81205	1	31-41-11 AE0221/ /	ALL
D06256P		BACC45FT12A12P9 PLUG-E8	81205	1	77-21-11 AE0221/ /	ALL
D06258J		BACC45FN22-32S7 RCPT-P61	81205	1	28-22-12 AF0204/ /	ALL
D06258P		BACC45FT22-32P7 PLUG-P61	81205	1	28-22-12 AF0204/ /	ALL
D06260J		BACC45FN22-32S9 RCPT-	81205	1	28-22-12 AE0218/ /	ALL
D06260P		BACC45FT22-32P9 PLUG-P37	81205	1	28-22-12 AE0218/ /	ALL
D06261 U		-10201 I.D. TAPE TEXT AS BELOW	85480	1	22-21-31 / /	275-299
D06261 V		-10201 I.D. TAPE TEXT AS BELOW	85480	1	22-21-31 / /	275-299
D06261J		BACC45FN18-31S8 RCPT-E2-2	81205	0	22-21-31 AEO314/ /	150-199
D06261J		BACC45FN18-31S8 RCPT-E2-2	81205	0	22-21-31 / /	275-299

EQUIPMENT LIST

D280T132

Section D06200

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06261P		BACC45FT18A31P8 PLUG-E2-2	81205	0	22-21-31 AE0314/ /	167-199
D06261P		BACC45FT18A31P8 PLUG-E2-2	81205	0	22-21-31 / /	275-299
D06262J		BACC45FN12-12S6 RCPT-E3-2	81205	1	21-51-13 AE0220/ /	ALL
D06262P		BACC45FT12-12P6 PLUG-E3-1	81205	1	21-51-13 AE0220/ /	ALL
D06264J		BACC45FN12-12S7 RCPT-E3-2	81205	1	21-51-23 AE0220/ /	ALL
D06264P		BACC45FT12-12P7 PLUG-E3-1	81205	1	21-51-23 AE0220/ /	ALL
D06266J		BACC45FN16B24P RCPT-	81205	1	52-34-13 0515/181/R087	050-099
D06266J		BACC45FN16B24P RCPT	81205	1	52-34-13 0515/181/R087	150-199, 275-299
D06266P		BACC45FT16-24S PLUG-	81205	1	52-34-11 0515/181/R087	ALL
D06272J		48-7191 RCPT-	02660	1	33-22-41 0285/282/L040	ALL
D06272P		48-7190 PLUG-	02660	1	33-22-41 0285/282/L040	ALL
D06274J		48-7191-1 RCPT-	02660	1	33-22-41 0285/282/L040	ALL
D06274P		48-7190-1 PLUG-	02660	1	33-22-41 0285/282/L040	ALL
D06278J		BACC45FN16-24S RECP-E1-2	81205	1	77-31-11 AE0317/ /	050-099, 275-299
D06278J		BACC45FN16-24S RCPT-E1-2	81205	1	77-31-11 AE0317/ /	150-199
D06278P		BACC45FT16A24P PLUG-E1-2	81205	1	77-31-11 AE0317/ /	ALL
D06280J		BACC45FM18C14S6 RCPT-R W/W DISC	81205	1	29-11-31 AL1008/ /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 11

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06280P		BACC63BP18A14P6L PLUG-R W/W DISC	81205	1	29-11-31 AL1008/ /	ALL
D06280PQ		BACC10KD18 CLAMP-	81205	1	29-11-31 / /	ALL
D06286J		BACC45FN18-8P RCPT-P36	81205	1	21-58-14 AE0223/ /	ALL
D06286P		BACC45FT18-8S PLUG-	81205	1	21-58-14 AE0223/ /	ALL
D06288J		BACC45FN18-8P RCPT-P37	81205	1	21-58-15 AE0224/ /	ALL
D06288P		BACC45FT18-8S PLUG-	81205	1	21-58-15 AE0224/ /	ALL
D06292J		BACC63BV24F30S8 RCPT-L WING/STRUT	81205	1	77-31-11 AW0319/ /	050-099, 155-199, 277-299
D06292J		BACC63BV24A30S8 RCPT-L WING/STRUT	81205	1	77-31-11 AW0319/ /	150-154, 275-276
D06292JK		BACC10KD24 CLAMP	81205	1	77-31-11 AW0319/ /	ALL
D06292P		BACC63BP24C30P8L PLUG-L WING/STRUT	81205	1	31-35-14 AW0319/ /	050-099, 155-157, 164-199, 277-299
D06292P		BACC63BP24A30P8L PLUG-L WING/STRUT	81205	1	31-35-14 AW0319/POS/05..	150-154, 275-276
D06292P		BACC63BP24C30P8L PLUG-L WING/STRUT	81205	1	31-35-14 AW0319/POS/05..	162-163
D06292PQ		BACC10KD24 CLAMP-	81205	1	31-35-14 / /	050-099, 155-157, 164-199, 277-299
D06292PQ		BACC10KD24 CLAMP-	81205	1	31-35-14 AW0 319/POS/05..	150-154, 162-163, 275-276
D06296J		BACC63BV24F30S8 RCPT-R WING/STRUT	81205	1	77-31-11 AW0320/ /	050-099, 155-199, 277-299
D06296J		BACC63BV24A30S8 RCPT-R WING/STRUT	81205	1	77-31-11 AW0320/ /	150-154, 275-276
D06296JK		BACC10KD24 CLAMP	81205	1	77-31-11 AW0320/ /	ALL

EQUIPMENT LIST

D280T132

Section D06200

Page 12

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06296P		BACC63BP24C30P8L PLUG-R WING/STRUT	81205	1	77-35-11 AW0320/ /	050-099, 155-157, 164-199, 277-299
D06296P		BACC63BP24A30P8L PLUG-R WING/STRUT	81205	1	77-35-11 AW0320/POS/05..	150-154, 275-276
D06296P		BACC63BP24C30P8L PLUG-R WING/STRUT	81205	1	77-35-11 AW0320/POS/05..	162-163
D06296PQ		BACC10KD24 CLAMP-	81205	1	31-35-15 / /	050-099, 155-157, 164-199, 277-299
D06296PQ		BACC10KD24 CLAMP-	81205	1	31-35-15 AW0 320/POS/05..	150-154, 162-163, 275-276
D06298J		BACC45FN18-31S7 RCPT-	81205	1	31-35-15 AC0702/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D06200
Page 13 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06300J		BACC45FN18-31S7 RCPT-	81205	1	31-35-14 AC0701/ /	150-199, 275-299
D06302J		BACC45FN12-12P PLUG-	81205	1	30-71-23 1384/127/L050	050-099
D06302J		BACC45FN10-5P PLUG-	81205	1	30-71-23 1384/127/L050	150-199, 275-299
D06302P		BACC45FT12-12S PLUG-	81205	1	30-71-23 1384/127/L050	050-099
D06302P		BACC45FT10-5S PLUG-	81205	1	30-71-23 1384/127/L050	150-199, 275-299
D06304J		BACC45FN16-24P9 RCPT-	81205	1	30-71-23 AC1402/ /	050-099, 275-299
D06304J		BACC45FN18-14P9 RCPT-	81205	1	30-71-23 AC1402/ /	150-199
D06304P		BACC45FT16-24S9 PLUG-	81205	1	30-71-23 AC1402/ /	050-099, 275-299
D06304P		BACC45FT18-14S9 PLUG-	81205	1	30-71-23 AC1402/ /	150-199
D06306J		BACC45FN20-25P8 RCPT-	81205	1	21-26-11 AC1402/ /	ALL
D06306P		BACC45FT20-25S8 PLUG-	81205	1	21-26-11 AC1402/ /	ALL
D06308J		BACC45FN20-28P RCPT-	81205	1	30-71-23 AC1501/ /	ALL
D06308P		BACC45FT20-28S PLUG-	81205	1	30-71-23 AC1501/ /	ALL
D06310J		BACC45FN16-24P6 RCPT-P36	81205	1	21-58-12 AE0209/ /	ALL
D06310P		BACC45FT16-24S6 PLUG-P36	81205	1	21-58-11 AE0209/ /	ALL
D06312J		BACC45FN14-15S RCPT-	81205	1	21-58-12 AE0319/ /	ALL
D06312P		BACC45FT14A15P PLUG-	81205	1	21-58-12 AE0319/ /	ALL

EQUIPMENT LIST

D280T132

Section D06300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06314J		BACC45FN20-25P6 RCPT-	81205	1	21-31-11 AC1501/ /	ALL
D06314P		BACC45FT20-25S6 PLUG-	81205	1	21-31-11 AC1501/ /	ALL
D06316J		48-7191 RCPT-	02660	1	33-51-21 1568/260/R093	ALL
D06316P		48-7190 PLUG-	02660	1	33-51-21 1568/260/R093	ALL
D06318J		48-7191 RCPT-	02660	1	33-51-21 1568/260/R093	ALL
D06318P		48-7190 PLUG-	02660	1	33-51-21 1568/260/R093	ALL
D06320J		48-7191 RCPT-	02660	1	33-51-21 1568/260/L093	ALL
D06320P		48-7190 PLUG-	02660	1	33-51-21 1568/260/L093	ALL
D06322J		48-7191 RCPT-	02660	1	33-51-21 1568/260/L093	ALL
D06322P		48-7190 PLUG-	02660	1	33-51-21 1568/260/L093	ALL
D06324J		48-7191 RCPT-	02660	1	33-51-21 0357/262/R090	050-099
D06324J		48-7191 RCPT-	02660	1	33-51-21 0357/260/R090	150-199, 275-299
D06324P		48-7190 PLUG-	02660	1	33-51-21 0357/262/R090	050-099
D06324P		48-7190 PLUG-	02660	1	33-51-21 0357/260/R090	150-199, 275-299
D06326J		48-7191 RCPT-	02660	1	33-51-21 0357/262/R090	050-099
D06326J		48-7191 RCPT-	02660	1	33-51-21 0357/260/R090	150-199, 275-299
D06326P		48-7190 PLUG-	02660	1	33-51-21 0357/262/R090	050-099

EQUIPMENT LIST

D280T132

Section D06300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06326P		48-7190 PLUG-	02660	1	33-51-21 0357/260/R090	150-199, 275-299
D06328J		48-7191 RCPT-	02660	1	33-51-21 0357/262/L096	ALL
D06328P		48-7190 PLUG-	02660	1	33-51-21 0357/262/L096	ALL
D06330J		48-7191 RCPT-	02660	1	33-51-21 0357/262/L096	ALL
D06330P		48-7190 PLUG-	02660	1	33-51-21 0357/262/L096	ALL
D06340J		BACC45FM18C14S9 RCPT-	81205	1	32-45-13 AL1003/ /	ALL
D06340P		BACC63BP18R14P9L PLUG-	81205	1	24-51-24 AL1003/ /	050-099
D06340P		BACC63BP18R14P9L PLUG-	81205	1	32-48-11 AL1003/ /	150-199, 275-299
D06340PQ		BACC10KD18 CLAMP	81205	1	32-45-13 AL1003/ /	050-099
D06340PQ		BACC10KD18 CLAMP-	81205	1	32-48-11 / /	150-199, 275-299
D06342J		BACC45FM18C14S7 RCPT-	81205	1	32-45-14 AL1004/ /	ALL
D06342P		BACC63BP18R14P7L PLUG-	81205	1	32-45-14 AL1004/ /	050-099
D06342P		BACC63BP18A14P7L PLUG-R WING/BODY RS DISC	81205	1	32-48-12 AL1004/ /	150-199, 275-299
D06342PQ		BACC10KD18 CLAMP	81205	1	32-45-14 AL1004/ /	050-099
D06342PQ		BACC10KD18 CLAMP-	81205	1	32-48-11 / /	155-199, 275-299
D06348J		BACC45FN10-5P RCPT-P1	81205	1	33-13-11 AF0119/ /	ALL
D06348P		BACC45FT10-5S PLUG-	81205	1	33-13-11 AF0119/ /	ALL

EQUIPMENT LIST

D280T132

Section D06300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06350J		BACC45FN10-5P9 RCPT-P3	81205	1	33-13-13 AF0120/ /	ALL
D06350P		BACC45FT10-5S9 PLUG-	81205	1	33-13-13 AF0120/ /	ALL
D06366J		48-7191-1 RCPT-	02660	1	33-13-11 0150/250/0000	ALL
D06366P		48-7190-1 PLUG-	02660	1	33-13-11 0157/250/0000	ALL
D06368J		48-7191-1 RCPT-	02660	1	33-13-11 0157/250/0000	ALL
D06368P		48-7190-1 PLUG-	02660	1	33-13-11 0150/250/0000	ALL
D06380J		BACC45FN14-12S9 RCPT-P31	81205	1	25-31-31 AE0311/ /	275-299
D06380P		BACC45FT14-12P9 PLUG-P31	81205	1	25-31-31 AE0311/ /	275-299
D06382J		BACC63BV24F30S7 RCPT-R WING/STRUT	81205	1	73-21-13 AW0320/ /	ALL
D06382JK		BACC10KD24 CLAMP	81205	1	73-21-13 / /	ALL
D06382P		BACC63BP24C30P7L PLUG R. WING STRUT	81205	1	73-21-13 AW0320/ /	ALL
D06382PQ		BACC10KD24 CLAMP	81205	1	71-51-12 / /	ALL
D06384J		BACC63BV24F30S7 RCPT-L WING/STRUT	81205	1	30-21-11 AW0319/ /	ALL
D06384JK		BACC10KD24 CLAMP	81205	1	30-21-11 AW0319/ /	ALL
D06384P		BACC63BP24C30P7L PLUG L.WING STRUT	81205	1	30-21-11 AW0319/ /	ALL
D06384PQ		BACC10KD24 CLAMP	81205	1	71-51-12 / /	ALL
D06386J		48-7191 RCPT-	02660	1	33-22-21 0256/310/R006	150-154

EQUIPMENT LIST

D280T132

Section D06300

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06386J		48-7191 RCPT-	02660	1	33-22-21 0266/310/L017	155-157
D06386J		48-7191 RCPT-FWD COAT CLOSET	02660	1	33-22-21 0370/310/L045	275-299
D06386P		48-7190 PLUG-FWD CLOSET	02660	1	33-22-21 256/310/R006	150-154
D06386P		48-7190 PLUG-FWD CLOSET	02660	1	33-22-21 266/310/L017	155-157
D06386P		48-7190 PLUG-FWD CLOSET	02660	1	33-22-21 364/282/L050	275-299
D06388J		48-7191 RCPT-FWD CLOSET	02660	1	33-22-21 256/310/R006	150-154
D06388J		48-7191 RCPT-FWD CLOSET	02660	1	33-22-21 266/310/L017	155-157
D06388J		48-7191 RCPT-FWD CLOSET	02660	1	33-22-21 364/282/L050	275-299
D06388P		48-7190 PLUG-	02660	1	33-22-21 0256/310/R006	150-154
D06388P		48-7190 PLUG-	02660	1	33-22-21 0266/310/L017	155-157
D06388P		48-7190 PLUG-FWD COAT CLOSET	02660	1	33-22-21 0370/310/L045	275-299
D06394J		BACC45FN20-39P RCPT-P49	81205	1	36-11-41 P049-00/ /	ALL
D06394P		BACC45FT20-39S PLUG-P49	81205	1	24-31-41 P049-00/ /	ALL
D06396J		BACC45FN20-39P7 RCPT-P49	81205	1	49-15-11 P049-00/ /	ALL
D06396P		BACC45FT20-39S7 PLUG-P49	81205	1	49-15-11 P049-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D06300
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06402J		BACC45FN14-12P RCPT-P70	81205	1	25-65-11 0865/260/L089	ALL
D06402P		BACC45FT14-12S PLUG-	81205	1	25-65-11 0865/260/L089	ALL
D06404J		BACC45FN16-24P RCPT-P72	81205	1	25-65-11 0909/260/L089	150-199, 275-299
D06404P		BACC45FT16-24S PLUG-	81205	1	25-65-11 0909/260/L089	150-199, 275-299
D06406J		BACC45FN14-12P RCPT-P71	81205	1	25-65-12 0865/260/R089	ALL
D06406P		BACC45FT14-12S PLUG-	81205	1	25-65-12 0865/260/R089	ALL
D06408J		BACC45FN16-24P RCPT-P73	81205	1	25-65-12 0909/260/R089	150-199, 275-299
D06408P		BACC45FT16-24S PLUG-	81205	1	25-65-12 0909/260/R089	150-199, 275-299
D06410J		BACC45FN12-12S8 RCPT-	81205	1	33-51-11 AP0401/ /	ALL
D06410P		BACC45FT12-12P8 PLUG-P19	81205	1	33-51-11 AP0401/ /	ALL
D06412J		BACC45FN12-12S9 RCPT-	81205	1	33-51-11 AP0403/ /	ALL
D06412P		BACC45FT12-12P9 PLUG-P19	81205	1	33-51-11 AP0403/ /	ALL
D06414J		BACC45FN14-15S7 RCPT-	81205	1	33-51-11 AP1003/ /	ALL
D06414P		BACC45FT14-15P7 PLUG-P25	81205	1	33-51-11 AP1003/ /	ALL
D06420J		BACC63BV22F19SN RCPT-ENGINE FANCASE	81205	1	31-35-14 AW0309/ /	ALL
D06420JK		BACC10KD22 CLAMP-	81205	1	31-35-14 / /	ALL
D06422J		BACC63BV22F19SN RCPT-ENGINE FANCASE	81205	1	77-31-11 AW0309/ /	ALL

EQUIPMENT LIST

D280T132

Section D06400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06422JK		BACC10KD22 CLAMP-	81205	1	31-35-15 / /	ALL
D06424J		BACC45FN16-24S6 RCPT-E6	81205	1	49-94-14 AC1402/ /	ALL
D06424P		BACC45FT16-24P6 PLUG - E6	81205	1	49-94-14 AC1402/ /	ALL
D06430J		BACC45FN20-28S9 RCPT-P6	81205	1	24-51-43 AE0222/ /	050-099
D06430J		BACC45FN20-28S9 RCPT-P6	81205	1	24-51-43 AF0232/ /	150-199, 275-299
D06430P		BACC45FT20-28P9 PLUG-P6	81205	1	24-51-43 AE0222/ /	050-099
D06430P		BACC45FT20-28P9 PLUG-P6	81205	1	24-51-43 AF0232/ /	150-199, 275-299
D06442J		BACC45FN12-12S RCPT-P61	81205	1	24-25-11 AF0204/ /	ALL
D06442P		BACC45FT12-12P PLUG-P61	81205	1	24-25-11 AF0204/ /	ALL
D06444J		BACC45FN18-8S6 RCPT-P6	81205	1	24-51-14 AF0232/ /	ALL
D06444P		BACC45FT18-8P6 PLUG-P6	81205	1	24-51-14 AF0232/ /	ALL
D06446J		BACC45FN14-4S RCPT-P6	81205	1	24-51-24 AFO232/ /	050-099
D06446J		BACC45FN14-4S RCPT-P6	81205	1	24-51-24 AF0232/ /	150-199, 275-299
D06446P		BACC45FT14-4P PLUG-P6	81205	1	24-51-24 AF0232/ /	ALL
D06448J		BACC45FN18-8S7 RCPT-P6	81205	1	24-51-14 AF0232/ /	ALL
D06448P		BACC45FT18-8P7 PLUG-P6	81205	1	24-51-14 AF0232/ /	ALL
D06450J		BACC45FN16-10S6 RCPT-P6	81205	1	24-51-24 AE0222/ /	ALL

EQUIPMENT LIST

D280T132

Section D06400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06450P		BACC45FT16-10P6 PLUG-P6	81205	1	24-51-24 AE0222/ /	ALL
D06452J		BACC45FN16-24P6 RECP-P65	81205	1	24-25-11 AE0225/ /	ALL
D06452P		BACC45FT16-24S6 PLUG-P65	81205	1	24-25-11 AE0225/ /	ALL
D06454J		BACC45FN22-12P6 RECP-P65	81205	1	24-51-14 AE0225/ /	ALL
D06454P		BACC45FT22-12S6 PLUG-P65	81205	1	24-51-14 AE0225/ /	ALL
D06456J		BACC45FN20-25P RECP-P65	81205	1	24-51-14 AE0225/ /	ALL
D06456P		BACC45FT20-25S PLUG-P65	81205	1	24-51-14 AE0225/ /	ALL
D06458J		BACC45FN14-4P RECP-P65	81205	1	24-51-24 AE0225/ /	ALL
D06458P		BACC45FT14-4S PLUG-P65	81205	1	24-51-24 AE0225/ /	ALL
D06460J		BACC45FN16-24P8 RECP-P65	81205	1	24-25-11 AE0225/ /	ALL
D06460P		BACC45FT16-24S8 PLUG-P65	81205	1	24-25-12 AE0225/ /	ALL
D06462J		BACC45FN18-8P9 RECP-P65	81205	1	24-25-12 AE0225/ /	ALL
D06462P		BACC45FT18-8S9 PLUG-P65	81205	1	24-25-12 AE0225/ /	ALL
D06464J		BACC45FM16C24P RCPT-MN W/W DISC	81205	1	24-25-12 AL1003/ /	ALL
D06464P		BACC63BP16R24SNL PLUG	81205	1	24-25-12 AL1003/ /	ALL
D06464PQ		BACC10KD16 CLAMP	81205	1	24-25-12 / /	ALL
D06466J		BACC63BV14A4PN RCPT-MN W/W DISC	81205	1	24-25-12 AL1003/ /	050-099, 162-199, 275-299

EQUIPMENT LIST

D280T132

Section D06400

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06466J		BACC45FM14C4P RCPT-MN W/W DISC	81205	1	24-25-12 AL1003/ /	150-157
D06466JK		BACC10KD14 CLAMP-MN W/W DISC	81205	1	24-25-12 AL1003/ /	050-099, 162-199, 275-299
D06466P		BACC63BP14R4SNL PLUG	81205	1	24-25-12 AL1003/ /	ALL
D06466PQ		BACC10KD14 CLAMP	81205	1	24-25-12 / /	ALL
D06468J		BACC63BV18A8PN RCPT-MN W/W DISC	81205	1	24-25-12 AL1003/ /	050-099, 162-199, 275-299
D06468J		BACC45FM18C8P RCPT-MN W/W DISC	81205	1	24-25-12 AL1003/ /	150-157
D06468JK		BACC10KD18 CLMP-MN W/W DISC	81205	1	24-25-12 AL1003/ /	050-099, 162-199, 275-299
D06468P		BACC63BP18A8SNL PLUG-MN W/W DISC	81205	1	24-25-12 AL1003/ /	ALL
D06468PQ		BACC10KD18 CLAMP	81205	1	24-25-12 / /	ALL
D06470J		BACC45FN12-12P RCPT-P36	81205	1	24-25-11 AE0209/ /	ALL
D06470P		BACC45FT12-12S PLUG-P36	81205	1	24-25-13 AE0209/ /	ALL
D06474J		BACC45FN16-10P7 RECP-P65	81205	1	24-51-24 AE0225/ /	ALL
D06474P		BACC45FT16-10S7 PLUG-P65	81205	1	24-51-24 AE0225/ /	ALL
D06476J		BACC45FN14-4P6 RCPT-P33	81205	1	24-51-24 AE0207/ /	ALL
D06476P		BACC45FT14-4S6 PLUG-P33	81205	1	24-51-24 AE0207/ /	ALL
D06482J		BACC45FN16-24S9 RCPT	81205	1	23-42-12 AP0901/ /	150-199
D06482P		BACC45FT16-24P9 PLUG-	81205	1	23-31-14 AP0901/ /	150-199

EQUIPMENT LIST

D280T132

Section D06400
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06514J		BACC45FN12-12S RCPT-	81205	1	33-24-12 0763/269/L074	150-199
D06514J		BACC45FN10-5S RCPT-	81205	1	33-24-12 0675/269/L074	275-278
D06514J		BACC45FN10-5S RCPT-	81205	1	33-24-12 0686/269/L074	280-299
D06514P		BACC45FT12-12P PLUG-	81205	1	33-24-12 0763/269/L074	150-199
D06514P		BACC45FT10-5P PLUG-	81205	1	33-24-12 0675/269/L074	275-278
D06514P		BACC45FT10-5P PLUG-	81205	1	33-24-12 0676/269/L074	280-299
D06516J		BACC45FN12-12S RCPT-	81205	1	33-24-14 0763/269/R074	150-199
D06516J		BACC45FN10-5S RCPT-	81205	1	33-24-14 0675/269/R074	275-278
D06516J		BACC45FN10-5S RCPT-	81205	1	33-24-14 0687/269/R074	280-299
D06516P		BACC45FT12-12P PLUG-	81205	1	33-24-14 0763/269/R074	150-199
D06516P		BACC45FT10-5P PLUG-	81205	1	33-24-14 0675/269/R074	275-278
D06516P		BACC45FT10-5P PLUG-	81205	1	33-24-14 0675/270/R073	280-299
D06578J		BACC63CC22-55SN RECP	81205	1	73-21-12 AC0701/ /	ALL
D06578JK		BACC10KD22 CLAMP	81205	1	73-21-12 AC0701/ /	ALL
D06578P		BACC63CB22-55PN PLUG		1	73-21-14 AC0701/ /	ALL
D06578PQ		BACC10KD22 CLAMP	81205	1	73-21-14 AC0701/ /	ALL
D06580J		BACC63CC22-55SN RECP	81205	1	73-21-12 AC0702/ /	ALL

EQUIPMENT LIST

D280T132

Section D06500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06580JK		BACC10KD22 CLAMP	81205	1	73-21-12 AC0702/ /	ALL
D06580P		BACC63CB22-55PN PLUG	81205	1	73-21-14 AC0702/ /	ALL
D06580PQ		BACC10KD22 CLAMP		1	73-21-14 / /	ALL
D06582J		BACC45FN18-31S9 RCPT-P36	81205	1	24-11-11 AE0209/ /	ALL
D06582P		BACC45FT18-31P9 RECP-P36	81205	1	73-21-14 AE0209/ /	ALL
D06584J		BACC45FN18-31S8 RCPT-P37	81205	1	24-11-21 AE0218/ /	050-099
D06584J		BACC45FN18-31S8 RCPT-P37	81205	1	73-21-11 AE0218/ /	150-199, 275-299
D06584P		BACC45FT18-31P8 PLUG	81205	1	73-21-12 AE0218/ /	ALL
D06586J		BACC45FN18-31S6 RECP	81205	1	24-11-11 AC0701/ /	ALL
D06586P		BACC45FT18-31P6 PLUG-L WING FS/BODY	81205	1	24-11-11 AC0701/ /	ALL
D06588J		BACC45FN18-31S6 PLUG	81205	1	24-11-21 AC0702/ /	050-099, 150-199
D06588J		BACC45FN18-31S6 RECP	81205	1	24-11-21 AC0702/ /	275-299
D06588P		BACC45FT18-31P6 PLUG-R WING/BODY	81205	1	24-11-21 AC0702/ /	ALL
D06594J		BACC45FN18-31P6 RCPT-	81205	1	31-31-22 AE0322/ /	ALL
D06594P		BACC45FT18A31S6 PLUG E2-3	81205	1	31-31-22 AE0322/ /	ALL

EQUIPMENT LIST

D280T132

Section D06500
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06604J		BACC45FN10-5P RCPT-	81205	1	30-46-11 0320/282/L070	ALL
D06604JK		6930-06-023-13 CND ADPTR-	05593	1	30-46-11 0320/282/L070	ALL
D06604P		CN0900-329 PLUG-	13556	1	30-46-11 0320/282/L070	ALL
D06604PQ	1	712-148 CND ADPTR-	06324	1	30-46-11 0320/282/L070	ALL
D06604PQ	2	6930-06-023-13 CND ADPTR-	05593	1	30-46-11 0320/282/L070	ALL
D06606J		BACC45FN10-5P RCPT-	81205	1	30-46-11 0320/282/R070	ALL
D06606JK		6930-06-023-13 CND ADPTR-	05593	1	30-46-11 0320/282/R070	ALL
D06606P		CN0900-329 PLUG-	13556	1	30-46-11 320/282/R070	050-099
D06606P		CN0900-329 PLUG-	13556	1	30-46-11 0320/282/R070	150-199, 275-299
D06606PQ		712-148 CND ADPTR-	06324	1	30-46-11 / /	050-099
D06606PQ	1	712-148 CND ADPTR-	06324	1	30-46-11 / /	150-199, 275-299
D06606PQ	2	6930-06-023-13 CND ADPTR-	05593	1	30-46-11 / /	150-199, 275-299
D06612J		BACC45FN10-5P RCPT-	81205	1	30-46-11 1510/282/L070	ALL
D06612JK		6930-06-023-13 CND ADPTR-	05593	1	30-46-11 1510/282/L070	ALL
D06612P		CN0900-329 PLUG-	13556	1	30-46-11 1510/282/L070	280-299
D06612P	1	CN0900-329 PLUG-	13556	1	30-46-11 1510/282/L070	050-099, 150-199, 275-278
D06612P	2	BACC45FT10-5S PLUG-	81205	1	30-46-11 1510/282/L070	050-099, 150-199, 275-278

EQUIPMENT LIST

D280T132

Section D06600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06612PQ	1	712-148 CND ADPTR-	06324	1	30-46-11 / /	ALL
D06612PQ	2	6930-06-023-13 CND ADPTR-	05593	1	30-46-11 / /	ALL
D06614J		BACC45FN10-5P RCPT-	81205	1	30-46-11 1510/282/R070	ALL
D06614JK		6930-06-023-13 CND ADPTR-	05593	1	30-46-11 1510/282/R070	ALL
D06614P		CN0900-329 PLUG-	13556	1	30-46-11 1510/282/R070	ALL
D06614PQ	1	712-148 CND ADPTR-	06324	1	30-46-11 / /	ALL
D06614PQ	2	6930-06-023-13 CND ADPTR-	05593	1	30-46-11 / /	ALL
D06644J		BACC45FN12-3S6 RCPT-	81205	1	35-21-12 0763/269/L074	150-199
D06644J		BACC45FN12-3S6 RCPT-	81205	1	35-21-12 0675/269/L074	275-278
D06644J		BACC45FN12-3S6 RCPT-	81205	1	35-21-12 0687/269/L074	280-299
D06644P		BACC45FT12-3P6 PLUG-	81205	1	35-21-12 0763/269/L074	150-199
D06644P		BACC45FT12-3P6 PLUG-	81205	1	35-21-12 0675/269/L074	275-278
D06644P		BACC45FT12-3P6 PLUG-	81205	1	35-21-12 0676/269/L074	280-299
D06646J		BACC45FN12-3S6 RCPT-	81205	1	35-21-13 0763/269/R074	150-199
D06646J		BACC45FN12-3S6 RCPT-	81205	1	35-21-13 0675/269/R074	275-278
D06646J		BACC45FN12-3S6 RCPT-	81205	1	35-21-13 0687/269/R074	280-299
D06646P		BACC45FT12-3P6 PLUG-	81205	1	35-21-13 0763/269/R074	150-199

EQUIPMENT LIST

D280T132

Section D06600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06646P		BACC45FT12-3P6 PLUG-	81205	1	35-21-13 0675/269/R074	275-278
D06646P		BACC45FT12-3P6 PLUG-	81205	1	35-21-13 0676/269/R074	280-299
D06650J		BACC45FN12-12S7 RCPT-	81205	1	33-51-12 AP0901/ /	150-199
D06650P		BACC45FT12-12P7 PLUG-	81205	1	33-51-12 AP0901/POS/4	150-199
D06652J		BACC45FN12-12S RCPT-	81205	1	33-51-13 AP0901/ /	150-199
D06652P		BACC45FT12-12P PLUG-	81205	1	33-51-13 AP0901/POS/3	150-199
D06658J		BACC45FN16-24P9 RECPT-P37	81205	1	21-26-31 P037-00/ /	050-099
D06658J		BACC45FN16-24P9 RECPT-P37	81205	1	21-26-31 AE0218/ /	150-199, 275-299
D06658P		BACC45FT16-24S9 PLUG-P37	81205	1	21-26-31 292/169/R68	ALL
D06666J		BACC45FN22-55S RECP	81205	1	23-32-11 AP0202/ /	275
D06666J		BACC45FN22-55S RECP	81205	1	23-32-11 AP0205/ /	276-278
D06666J		BACC45FN22-55S8 RECP	81205	1	23-32-11 AP0205/ /	280-299
D06666P		BACC45FT22-55P PLUG	81205	1	23-32-11 AP0202/ /	275
D06666P		BACC45FT22-55P PLUG	81205	1	23-32-11 AP0205/ /	276-278
D06666P		BACC45FT22-55P8 PLUG	81205	1	23-32-11 AP0205/ /	280-299
D06668J		BACC45FN22-55S6 PLUG	81205	1	23-32-11 AP0202/ /	275
D06668J		BACC45FN22-55S6 PLUG	81205	1	23-32-11 AP0205/ /	276-299

EQUIPMENT LIST

D280T132

Section D06600

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06668P		BACC45FT22-55P6 PLUG	81205	1	23-32-11 AP0202/ /	275
D06668P		BACC45FT22-55P6 PLUG	81205	1	23-32-11 AP0205/ /	276-299

EQUIPMENT LIST

D280T132

Section D06600
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06730		BACC45FN10-5S RECPT	81205	1	23-42-11 0360/280/L 60	050-099, 150-199
D06732J		BACC45FN22-55S8 RCPT-E1-5	81205	1	21-61-51 AE0305/ /	ALL
D06732P		BACC45FT22A55P8 PLUG-E1-5	81205	1	21-61-51 AE0305/ /	ALL
D06734J		BACC45FN22-55S7 RCPT-E1-5	81205	1	21-61-51 355/125/L38	ALL
D06734P		BACC45FT22A55P7 PLUG-E1-5	81205	1	21-61-51 AE0305/ /	ALL
D06736J		BACC45FN18-31S RCPT	81205	1	33-21-12 AP1005/ /	050-099
D06736J		BACC45FN18-31S RECP	81205	1	33-21-12 AP1005/ /	150-199
D06736P		BACC45FT18-31P PLUG	81205	1	33-21-12 AP1005/ /	050-099, 150-199
D06738J		BACC45FN12-12P RCPT	81205	1	33-27-11 411/285/R 38	050-099
D06738J		BACC45FN12-12P RECPT	81205	1	33-27-11 411/285/R038	150-199
D06738P		BACC45FT12-12S PLUG-	81205	1	33-27-11 411/285/R 38	050-099, 150-199
D06740J		BACC45FN12-12P RCPT	81205	1	33-27-11 411/285/L 38	050-099
D06740J		BACC45FN12-12P RECPT	81205	1	33-27-11 411/285/L038	150-199
D06740P		BACC45FT12-12S PLUG-	81205	1	33-27-11 411/285/L038	050-099, 150-199
D06742J		BACC45FN18-31S6 RECP	81205	1	26-13-11 AP1003/ /	050-099, 150-199
D06742P		BACC45FT18-31P6 PLUG-P25	81205	1	33-26-21 AP1003/ /	050-099, 150-199
D06752J		BACC45FN16-24S9 RCPT-E1-5	81205	1	21-61-81 AE0305/ /	ALL

EQUIPMENT LIST

D280T132

Section D06700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06752P		BACC45FT16A24P9 PLUG-E1-5	81205	1	21-61-81 AE0305/ /	ALL
D06754J		BACC45FN16-24P7 RECP-E1-5	81205	1	21-61-81 355/125/L38	ALL
D06754P		BACC45FT16A24S7 PLUG-E1-5	81205	1	21-61-81 AE0305/ /	ALL
D06756J		BACC45FN16-24S7 PLUG-E1-1	81205	1	32-45-13 AE0305/ /	050-099, 150-199
D06756P		BACC45FT16A24P7 PLUG-E1-1	81205	1	32-45-13 AE0305/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D06700
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06802J		BACC45FN18-31P6 RCPT- E2-6	81205	1	32-45-11 AE0306/ /	275-299
D06802P		BACC45FT18A31S6 PLUG-E2-6	81205	1	32-45-11 AE0306/ /	275-299
D06804J		BACC45FN18-31P REPT-E2-6	81205	1	32-45-11 AE0307/ /	275-299
D06804P		BACC45FT18A31S PLUG-E2-6	81205	1	32-45-11 AE0307/ /	275-299
D06806J		BACC45FN18-31P6 RCPT-E2-6	81205	1	32-45-13 AE0306/ /	275-299
D06806P		BACC45FT18A31S6 PLUG-E2-6	81203	1	32-45-13 AE0306/ /	275-299
D06808J		BACC45FN18-31P8 RCPT-E2-6	81205	1	32-45-14 AE0307/ /	275-278
D06808J		BACC45FN18-31P8 RCP-E2-6	81205	1	32-45-14 AE0307/ /	280-299
D06808P		BACC45FT18A31S8 PLUG-E2-6	81205	1	32-45-14 AE0307/ /	275-299
D06810J		48-7164-1S RCPT		1	21-45-22 878/254/L090	050-099, 155-199, 276-299
D06810J		48-7164-1S RCPT	02660	1	21-45-22 872/245/L095	150-154
D06810J		48-7164-1S RCPT	02660	1	21-45-22 878/254/L090	275
D06810P		48-7164-2P PLUG	02660	1	21-45-22 878/254/L090	ALL
D06812J		48-7164-1S RCPT	02660	1	21-45-22 916/245/L095	150-154
D06812J		48-7164-1S RCPT		1	21-45-22 922/254/L090	155-199, 276-299
D06812J		48-7164-1S RCPT	02660	1	21-45-22 922/254/L090	275
D06812P		48-7164-2P PLUG	02660	1	21-45-22 922/254/L090	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D06800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06814J		48-7164-1S RCPT		1	21-45-22 878/254/R090	050-099, 155-199, 276-299
D06814J		48-7164-1S RCPT	02660	1	21-45-22 872/245/R095	150-154
D06814J		48-7164-1S RCPT	02660	1	21-45-22 878/254/R090	275
D06814P		48-7164-2P PLUG	02660	1	21-45-22 878/254/R090	ALL
D06816J		48-7164-1S RCPT	02660	1	21-45-22 916/245/R095	150-154
D06816J		48-7164-1S RCPT		1	21-45-22 922/254/R090	155-199, 276-299
D06816J		48-7164-1S RCPT	02660	1	21-45-22 922/254/R090	275
D06816P		48-7164-2P PLUG	02660	1	21-45-22 922/254/R090	150-199, 275-299
D06834J		48-7191 RCPT-	02660	1	33-51-16 1542/195/R009	275-299
D06834P		48-7190 PLUG-	02660	1	33-51-16 1542/195/R009	275-299
D06836J		48-7191 RCPT-	02660	1	33-51-16 1542/195/R009	275-299
D06836P		48-7190 PLUG-	02660	1	33-51-16 1542/195/R009	275-299
D06842J		48-7191 RCPT-	02660	1	33-51-16 1542/195/L009	275-299
D06842P		48-7190 PLUG-	02660	1	33-51-16 1542/195/L009	275-299
D06844J		48-7191 RCPT-	02660	1	33-51-16 1542/195/L009	275-299
D06844P		48-7190 PLUG-	02660	1	33-51-16 1542/195/L009	275-299
D06858J		48-7191 RCPT	81205	1	33-22-21 654+90/283/R 53	162-199

EQUIPMENT LIST

D280T132

Section D06800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06858P		48-7190 PLUG-	02660	1	33-22-21 654+90/283/R053	162-199
D06860J		48-7191 RCPT-	02660	1	33-22-21 654+90/283/R053	162-199
D06860P		48-7190 PLUG	81205	1	33-22-21 654+90/283/R 53	162-199
D06880J		BACC63BV16A24PN PLUG	81205	1	26-23-11 666/148/R 70	050-099
D06880JK		BACC10HF16A CLAMP	81205	1	26-23-11 666/148/R 70	050-099
D06880P		BACC45FS16-24S PLUG-	81205	1	26-23-11 666/148/R 70	050-099
D06882J		BACC45FN14-15P PLUG	81205	1	26-23-12 658/169/R 81	050-099
D06882JK		MS27291-3 CLAMP	81205	1	26-23-12 658/169/R 81	050-099
D06882P		BACC45FT14-15S PLUG-	81205	1	26-23-12 658/169/R 81	050-099
D06884J		BACC45FN12-12P PLUG	81205	1	26-23-12 697/150/R 70	050-099
D06884JK		MS27291-2 CLAMP	81205	1	26-23-12 696/148/R 70	050-099
D06884P		BACC45FT12-12S PLUG-	81205	1	26-23-12 697/150/R 70	050-099
D06886J		BACC63BV14A7PN PLUG	81205	1	26-21-11 699/155/R 68	050-099
D06886J		BACC63BV14A7PN PLUG	81205	1	26-21-11 654+122/154/R 68	155-199, 275-299
D06886JK		BACC10KD14 CLAMP	81205	1	26-21-11 699/155/R 68	050-099
D06886JK		BACC10HF14A CLAMP	81205	1	26-21-11 654+122/154/R 68	155-199, 275-299
D06886P		BACC45FS14-7S PLUG-	81205	1	26-21-11 699/155/R 68	050-099

EQUIPMENT LIST

D280T132

Section D06800

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06886P		BACC45FS14-7S PLUG-	81205	1	26-21-11 654+122/154/R 68	150-199, 275-299
D06888J		BACC45FN16-24P PLUG	81205	1	26-21-11 721/165/R 68	050-099
D06888J		BACC45FN16C24P PLUG	81205	1	26-21-11 670/165/R 68	155-199, 275-299
D06888JK		MS27291-4 CLAMP	81205	1	26-21-11 721/165/R 68	050-099
D06888P		BACC45FT16-24S PLUG-	81205	1	26-21-11 721/165/R 68	050-099
D06888P		BACC45FT16-24S PLUG-	81205	1	26-21-11 676/165/R 68	150-154
D06888P		BACC45FT16-24S PLUG-	81205	1	26-21-11 670/165/R 68	155-199, 275-299
D06890J		BACC45FN12-12S RCPT	81205	1	23-34-15 260/280/R 15	050-099, 162-199
D06890P		BACC45FT12-12P PLUG	81205	1	23-34-15 260/280/R 15	050-099, 162-199
D06892J		BACC45FN12-12S6 RCPT	81205	1	23-34-15 260/235/R 15	050-099, 162-199
D06892P		BACC45FT12-12P6 PLUG	81205	1	23-34-15 260/235/R 15	050-099, 162-199
D06894J		BACC45FN12C12P PLUG	81205	1	26-23-11 0654+87/149/R071	155-199, 275-299
D06894P		BACC45FT12-12S PLUG-	81205	1	26-23-11 654+87/148/R 70	150-199, 275-299
D06896J		BACC63BV16A24PN PLUG	81205	1	26-23-12 654+67/147/R 70	155-199, 275-299
D06896JK		BACC10HF16A PLUG	81205	1	26-23-12 654+67/147/R 70	155-199, 275-299
D06896P		BACC45FS16-24S PLUG-	81205	1	26-23-12 654+67/147/R 70	150-199, 275-299
D06898J		BACC45FN14C15P PLUG	81205	1	26-23-12 0654+25/147/R070	155-199, 275-299

EQUIPMENT LIST

D280T132

Section D06800

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06898P		BACC45FT14-15S PLUG-	81205	1	26-23-12 654+26/148/R 70	155-199, 280-299
D06898P		BACC45FT14-15S PLUG-	81205	1	26-21-11 654+26/148/R 70	275-278

EQUIPMENT LIST

D280T132

Section D06800

Page 5 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06900J		BACC45FN12-12P RCPT	81205	1	26-13-12 437/275/R075	050-099, 162-199
D06900JK		M83723-60-212AC DUMMY PLUG	96906	1	26-13-12 / /	050-099, 162-199
D06900P		BACC45FT12A12S PLUG-	81205	1	26-13-12 437/275/R055	050-099
D06900P		BACC45FT12-12S PLUG-	81205	1	21-66-21 437/275/R055	162-199
D06902J		BACC45FN12-12P RCPT	81205	3	33-21-31 MULTI- / /	050-099, 162-199
D06902JK		M83723-60-212AC DUMMY PLUG	96906	3	33-21-31 / /	050-099, 162-199
D06904P		BACC45FT12A12S PLUG-	81205	1	33-21-31 1414/280/L050	050-099, 162-199
D06906P		BACC45FT12A12S PLUG-	81205	1	33-21-31 1414/280/R050	050-099, 150, 152-199
D06934J		BACC45FN20-41S RCPT-	81205	1	21-66-11 AE0209/ /	050-099
D06934J		BACC45FN20-41S RCPT-	81205	1	21-45-24 AE0209/ /	150-199, 275-299
D06934P		BACC45FT20-41P PLUG-	81205	1	21-66-11 AE0209/ /	050-099, 162-199
D06934P		BACC45FT20-41P PLUG-P36 PNL	81205	1	21-45-24 AE0209/ /	150-157, 275-277
D06934P		BACC45FT20-41P PLUG-	81205	1	21-45-24 AE0209/ /	278-299
D06936J		BACC45FN14-15S RECP-	81205	1	21-66-11 326/280/L012	050-099, 162-199
D06936P		BACC45FT14-15P PLUG	81205	1	21-66-11 326/280/L 12	050-099, 162-199
D06944J		BACC45FN12A12P8 PLUG-	81205	1	26-16-11 352/184/L067	ALL
D06944P		BACC45FT12-12S8 PLUG-	81205	1	26-16-11 352/184/L067	ALL

EQUIPMENT LIST

D280T132

Section D06900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06946J		BACC45FN12A12P8 PLUG-	81205	1	26-16-11 1406/163/L071	ALL
D06946P		BACC45FT12-12S8 PLUG-	81205	1	26-16-11 1406/163/L067	ALL
D06948J		BACC45FN10A5P PLUG-	81205	1	26-16-21 352/184/L067	ALL
D06948P		BACC45FT10-5S PLUG-	81205	1	26-16-21 352/184/L067	ALL
D06950J		BACC45FN10A5P PLUG-	81205	1	26-16-21 1406/137/L071	ALL
D06950P		BACC45FT10-5S PLUG-	81205	1	26-16-21 1406/163/L067	ALL
D06966J		BACC45FN22-55S7 RCPT-E8	81205	1	27-18-11 AE0221/ /	155-157, 166-199, 277-299
D06966JL		M83723-60-222AC DUST CAP	81205	1	27-18-11 AE0221/ /	155-157, 166-199, 277-299
D06968J		BACC45FN12-12S8 RCPT-E8	81205	1	27-18-11 AE0221/ /	155-157, 166-199, 277-299
D06968P		BACC45FT12A12P8 PLUG-E8	81205	1	27-18-11 AE0221/ /	155-157, 166-199, 277-299
D06970J		BACC45FN12-12S9 RCPT-E8	81205	1	27-18-11 AE0221/ /	155-157, 166-199, 277-299
D06970P		BACC45FT12A12P9 PLUG-E8	81205	1	27-18-11 AE0221/ /	155-157, 166-199, 277-299
D06976J		BACC45FN12-12P RCPT	81205	2	26-13-12 MULTI-/ /	050-099, 150, 152- 199
D06976JK		M83723-60-212AC DUMMY PLUG	96906	2	26-13-12 / /	050-099, 150, 152- 199
D06978J		BACC63BV14A7SN RCPT-	81205	1	27-18-11 AL1002/ /	155-157, 166-199, 277-299
D06978JK		BACC10KD14 CLAMP-	81205	1	27-18-11 AL1002/ /	155-157, 166-199, 277-299
D06978P		BACC63BP14A7PNL PLUG-R WING RS/BODY	81205	1	27-18-11 AL1002/ /	155-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section D06900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D06978PQ		BACC10KD14 CLAMP	81205	1	27-18-11 AL1002/ /	155-157, 166-199, 277-299
D06980J		BACC45FN22-55S6 RCPT-E8	81205	1	27-28-11 AE0221/ /	155-157, 166-199, 277-299
D06980P		BACC45FT22-55P6 PLUG-E8	06090	1	27-28-11 AE0221/ /	155-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section D06900
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07040J		BACC63CC22-19S6 RCPT-R WING FS/BODY	81205	1	78-36-21 AC0702/ /	050-099, 150-199, 275-278
D07040J		BACC63CC22-19S6 RCPT-R WING FS/BODY	81205	1	78-36-21 AC0702/POS/15	280-299
D07040JK		BACC10KD22 CLAMP-	81205	1	78-36-21 / /	050-099, 280-299
D07040JK		BACC10KD22 CLAMP	81205	1	78-36-21 / /	150-199, 275-278
D07040P		BACC63CB22-19P6 PLUG-R WING FS/BODY	81205	1	78-36-21 AC0702/POS/15	050-099, 150-156, 162-166, 275-276
D07040P		BACC63CB22-19P6 PLUG-R WING FS/BODY	81205	1	78-36-21 AC0702/ /	157, 167-199, 277- 299
D07040PQ		BACC10KD22 CLAMP	81205	1	78-36-21 AC0702/ /	ALL
D07082J		BACC45FN10-5S RCPT-	81205	1	33-22-42 1417/314/R032	280-299
D07084J		BACC45FN10-5S6 RCPT-	81205	1	33-22-31 1417/314/R032	280-299
D07086J		BACC45FN10-5S RCPT-	81205	1	33-22-31 1417/314/R032	280-299
D07090P		BACC45FT12A12S8 PLUG	81205	1	23-31-14 AP0604/ /	280-299
D07092J		BACC45FN10-5S7 RCPT-	81205	1	23-31-14 AP1404/ /	280-299
D07096J		BACC45FN16-24S RCPT-	81205	1	33-21-11 628/291/L026	280-299
D07098J		BACC45FN16-24S RCPT-	81205	1	33-21-11 654+108/291/L024	280-299
D07098P		BACC45FT16-24P PLUG-	81205	1	33-21-11 654+108/291/L024	280-299

EQUIPMENT LIST

D280T132

Section D07000

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07100P		BACC45FT16-24P PLUG-	81205	1	33-21-11 0630/291/L024	280-299
D07126J		BACC45FN20-39S RCPT-P87	81205	1	21-45-24 AE0227/ /	278-299
D07126P		BACC45FT20-39P PLUG-	81205	1	21-45-24 AE0227/ /	050-099, 278-299
D07126P		BACC45FT20-39P PLUG-P36 PNL	81205	1	21-45-24 AE0227/ /	150-199, 275-277
D07152 U		-11802 I.D. TAPE - TEXT AS BELOW	81205	1	78-36-11 / /	ALL
D07160 U		-11801 I.D. TAPE - TEXT AS BELOW	81205	1	78-36-11 / /	ALL
D07160 V		289T0234-10701 I.D. TAPE TEXT AS BELOW	81205	1	78-36-11 AE0305/ /	ALL
D07160J		BACC45FN12-12S7 RCPT-E1-4	81205	1	78-36-11 AE0305/ /	ALL
D07160P		BACC45FT12A12P7 PLUG E1-4	81205	1	78-36-11 AE0305/ /	ALL
D07162 U		-12101 I.D. TAPE - TEXT AS BELOW	85408	1	78-36-21 / /	ALL
D07162 V		289T0234-10801 I.D. TAPE TEXT AS BELOW	81205	1	78-36-21 E1-4/ /	ALL
D07162J		BACC45FN12-12S9 RCPT	81205	1	78-36-21 AE0317/ /	ALL
D07162P		BACC45FT12A12P9 PLUG-E1-4	81205	1	78-36-21 E1-4/ /	ALL
D07170J		BACC63BV12F3SN RCPT-RH COWL	81205	1	78-34-11 AW0310/ /	050-099, 150-199, 275-278
D07170JK		BACC10KD12 CLAMP-	81205	1	78-34-11 / /	050-099, 150-199, 275-278
D07170P		BACC63BP12C3PN PLUG-RH COWL	81205	2	78-34-11 0/0/R004	ALL
D07170PQ		BACC10KD12 CLAMP-	81205	2	78-34-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D07100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07172J		BACC63BV12F3S6 RCPT-LH COWL	81205	1	30-21-11 AW0311/ /	050-099, 150-199, 275-278
D07172JK		BACC10KD12 CLAMP-	81205	1	30-21-11 / /	050-099, 150-199, 275-278
D07172P		BACC63BP12C3P6 PLUG-LH COWL	81205	2	78-34-11 79/0/R018	ALL
D07172PQ		BACC10KD12 CLAMP-	81205	2	78-34-11 / /	ALL
D07190J		BACC63BV12F3SN RCPT-RH COWL	81205	1	78-34-21 AW0310/ /	050-099, 150-166, 275-299
D07190JK		BACC10KD12 CLAMP-	81205	1	78-34-21 / /	050-099, 150-166, 275-299
D07192J		BACC63BV12F3S6 RCPT-LH COWL	81205	1	78-34-21 AW0311/ /	050-099, 150-166, 275-299
D07192JK		BACC10KD12 CLAMP-	81205	1	78-34-21 / /	050-099, 150-166, 275-299

EQUIPMENT LIST

D280T132

Section D07100

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07546J		BACC63BV12F3S6 RECP-L WING (SB 27A0140)	81205	1	27-89-11 1098/FS/L	050-099, 150-199, 275-278
D07546J		BACC63BV12F3S6 RECP-L WING	81205	1	27-89-11 1098/FS/	280-299
D07546JK		BACC10HG12C BACKSHELL (SB 27A0140)	81205	1	27-89-11 / /	050-099, 150-199, 275-278
D07546JK		BACC10HG12C BACKSHELL	81205	1	27-89-11 / /	280-299
D07546P	9	BACC63BP12C3P6 PLUG	81205	1	27-89-11 1098/FS/L	050-099, 151
D07546PQ	9	BACC10KE12 BACKSHELL	81205	1	27-89-11 / /	050-099, 151
D07550J		BACC63BV12F3S6 RECP-R-WING (SB 27A0140)	81205	1	27-89-11 1098/FS/R	050-099, 150-199, 275-278
D07550J		BACC63BV12F3S6 RECP-R-WING	81205	1	27-89-11 1098/FS/	280-299
D07550JK		BACC10HG12C BACKSHELL (SB 27A0140)	81205	1	27-89-11 / /	050-099, 150-199, 275-278
D07550JK		BACC10HG12C BACKSHELL	81205	1	27-89-11 / /	280-299
D07550P	9	BACC63BP12C3P6 PLUG	81205	1	27-89-11 1098/FS/R	050-099, 151
D07550PQ	9	BACC10KE12 BACKSHELL	81205	1	27-89-11 / /	050-099, 151

EQUIPMENT LIST

D280T132

Section D07500
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07960J		BACC45FN18-31P9 RCPT-P61	81205	1	21-25-11 AF0204/ /	ALL
D07960P		BACC45FT18-31S9 PLUG-P61	81205	1	27-11-11 AF0204/ /	ALL
D07962J		BACC45FN20-41P9 RCPT-P61	81205	1	36-11-11 AF0204/ /	ALL
D07962P		BACC45FT20-41S9 PLUG-P61	81205	1	27-13-11 AF0204/ /	ALL
D07964J		BACC45FN18-31P6 RCPT-P61	81205	1	27-11-11 AF0204/ /	ALL
D07964P		BACC45FT18-31S6 PLUG-P61	81205	1	73-21-11 AF0204/ /	ALL
D07966J		BACC45FN18-31P8 RCPT-P61	81205	1	29-11-11 AF0204/ /	ALL
D07966P		BACC45FT18-31S8 PLUG-P61	81205	1	75-32-11 AF0204/ /	ALL
D07968J		BACC45FN20-41P RCPT-P61	81205	1	27-13-11 AF0204/ /	ALL
D07968P		BACC45FT20-41S PLUG-P61	81205	1	30-41-11 AF0204/ /	ALL
D07970J		BACC45FN18-31P7 RCPT-P61	81205	1	27-13-11 AF0204/ /	ALL
D07970P		BACC45FT18-31S7 PLUG-P61	81205	1	21-53-22 AF0204/ /	ALL
D07972J		BACC45FN18-31P7 RCPT-P61	81205	1	21-25-21 AF0204/ /	ALL
D07972P		BACC45FT18-31S7 PLUG-P61	81205	1	27-51-11 AF0204/ /	ALL
D07974J		BACC45FN20-41P9 RCPT-P61	81205	1	36-11-21 AF0204/ /	ALL
D07974P		BACC45FT20-41S9 PLUG-P61	81205	1	24-51-23 AF0204/ /	ALL
D07976J		BACC45FN16-24P6 RCPT-P61	81205	1	27-51-11 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D07900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07976P		BACC45FT16-24S6 PLUG-P61	81205	1	73-21-11 AF0204/ /	ALL
D07978J		BACC45FN16-24P8 RCPT-P61	81205	1	29-11-21 AF0204/ /	ALL
D07978P		BACC45FT16-24S8 PLUG-P61	81205	1	32-09-12 AF0204/ /	ALL
D07980J		BACC45FN20-41P RCPT-P61	81205	1	26-11-11 AF0204/ /	ALL
D07980P		BACC45FT20-41S PLUG-P61	81205	1	26-11-11 AF0204/ /	ALL
D07982J		BACC45FN20-41P6 RCPT-P61	81205	1	73-21-18 AF0204/ /	ALL
D07982P		BACC45FT20-41S6 PLUG-P61	81205	1	27-58-11 AF0204/ /	ALL
D07984J		BACC45FN20-41P8 RCPT-P61	81205	1	26-11-11 AF0204/ /	ALL
D07984P		BACC45FT20-41S8 PLUG-P61	81205	1	24-11-31 AF0204/ /	ALL
D07986J		BACC45FN20-41P RCPT-P61	81205	1	33-51-11 AF0204/ /	ALL
D07986P		BACC45FT20-41S PLUG-P61	81205	1	21-53-11 AF0204/ /	ALL
D07988J		BACC45FN18-31P7 RCPT-P61	81205	1	33-16-12 AF0204/ /	ALL
D07988P		BACC45FT18-31S7 PLUG-P61	81205	1	21-58-12 AF0204/ /	ALL
D07990J		BACC45FN22-55P8 RCPT-P54	81205	1	26-11-11 AE0226/ /	ALL
D07990P		BACC45FT22-55S8 PLUG-P54	81205	1	26-11-11 AE0226/ /	ALL
D07992J		BACC45FN16-24P6 RCPT-P54	81205	1	26-11-11 AE0226/ /	ALL
D07992P		BACC45FT16-24S6 PLUG-	81205	1	26-11-11 AE0226/ /	ALL

EQUIPMENT LIST

D280T132

Section D07900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D07994J		BACC45FN22-55P RCPT-P54	81205	1	26-11-21 AE0226/ /	ALL
D07994P		BACC45FT22-55S PLUG-P54	81205	1	26-11-21 AE0226/ /	ALL
D07996J		BACC45FN16-24P RCPT-P54	81205	1	26-11-21 AE0226/ /	ALL
D07996P		BACC45FT16-24S PLUG-P54	81205	1	26-11-21 AE0226/ /	ALL

EQUIPMENT LIST

D280T132

Section D07900

Page 3 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08004J		BACC45FN20-41S6 RCPT-	81205	1	21-51-12 AE0305/ /	ALL
D08004P		BACC45FT20A41P6 PLUG-	81205	1	21-51-12 AE0305/ /	ALL
D08016J		BACC45FN12-12S7 RCPT-P34	81205	1	78-31-11 AE0204/ /	ALL
D08016P		BACC45FT12-12P7 PLUG-P34	81205	1	78-31-11 AE0204/ /	ALL
D08018J		BACC45FN12-12S9 RCPT-P34	81205	1	78-31-21 AE0204/ /	ALL
D08018P		BACC45FT12-12P9 PLUG-P34	81205	1	78-31-21 AE0204/ /	ALL
D08020J		BACC45FN16-24S9 RCPT-E1-2	81205	1	77-31-11 AE0319/ /	ALL
D08020P		BACC45FT16A24P9 PLUG-E1-2	81205	1	31-31-14 AE0319/ /	ALL
D08022J		BACC63CC18-31S8 RCPT-E1-2	81205	1	77-31-11 AE0319/ /	050-099, 155-199, 277-299
D08022J		BACC45FN18-31S8 RCPT-E1-2	81205	1	77-31-11 AE0319/ /	150-154, 275-276
D08022JK		BACC10KD18 BACKSHELL-CLAMP	81205	1	77-31-11 AE0309/ /	050-099
D08022JK		BACC10KD18 CLAMP	81205	1	77-31-11 AE0309/ /	155-157, 164-199
D08022JK		BACC10KD18 BACKSHELL	81205	1	77-31-11 AE0309/ /	162-163
D08022JK		BACC10KD18 CLAMP	81205	1	77-31-11 / /	277-299
D08022P		BACC63CB18-31P8 PLUG-E1-2	81205	1	78-36-11 AE0319/ /	050-099, 155-199, 277-299
D08022P		BACC45FT18A31P8 PLUG-E1-2	81205	1	78-36-11 AE0319/ /	150-154, 275-276
D08022PQ		BACC10KD18 CLAMP-E1-2	81205	1	78-36-11 AE0319/ /	050-099, 155-199, 277-299

EQUIPMENT LIST

D280T132

Section D08000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08024J		BACC45FN20-41S7 RCPT-E2-4	81205	1	27-51-41 AE0306/ /	ALL
D08024P		BACC45FT20A41P7 PLUG-E2-4	81205	1	27-51-41 AE0306/ /	ALL
D08026J		BACC45FN22-55P6 RCPT-P36	81205	1	29-11-32 AE0209/ /	ALL
D08026P		BACC45FT22-55S6 PLUG-P36	81205	1	76-11-11 AE0209/ /	ALL
D08028		CUSTOMER PLUG	CUST	1	28-31-12 AE0202/ /	051-099
D08028J		BACC45FN16-24P9 RCPT-	81205	1	27-58-21 AE0202/ /	ALL
D08028P		BACC45FT16-24S9 PLUG-P50	81205	1	27-58-21 AE0202/ /	ALL
D08030J		BACC45FN22-55P RCPT-	81205	1	73-21-11 AE0202/ /	ALL
D08030P		BACC45FT22-55S PLUG-P50	81205	1	27-51-31 AE0202/ /	ALL
D08032J		BACC45FN24-61P7 RCPT-	81205	1	73-21-11 AE0202/ /	ALL
D08032P		BACC45FT24-61S7 PLUG-P50	81205	1	27-58-21 AE0202/ /	ALL
D08034J		BACC45FN22-55S9 RCPT-E2-4	81205	1	27-51-31 AE0306/ /	ALL
D08034P		BACC45FT22A55P9 PLUG-E2-4	81205	1	27-51-31 AE0306/ /	ALL
D08036J		BACC45FN16-24S6 RCPT-	81205	1	28-21-12 AE0202/ /	ALL
D08036P		BACC45FT16-24P6 PLUG-P50	81205	1	28-21-12 AE0202/ /	ALL
D08038J		BACC45FN12-12S7 RCPT-	81205	1	28-21-12 AE0202/ /	ALL
D08038P		BACC45FT12-12P7 PLUG-50	81205	1	28-21-12 AE0202/ /	ALL

EQUIPMENT LIST

D280T132

Section D08000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08040J		BACC45FN12-12S8 RCPT-E3-1	81205	1	21-53-11 AE0220/ /	ALL
D08040P		BACC45FT12-12P8 PLUG-E3-1	81205	1	21-53-11 AE0220/ /	ALL
D08042J		BACC45FN18-31S7 RCPT-	81205	1	21-53-11 AC0701/ /	ALL
D08042P		BACC45FT18-31P7 PLUG-	81205	1	21-53-11 AC0701/ /	ALL
D08044J		BACC45FN14-12S8 RCPT-	81205	1	21-53-11 AC0701/ /	ALL
D08044P		BACC45FT14-12P8 PLUG-	81205	1	21-53-11 AC0701/ /	ALL
D08046J		BACC45FN16-24S6 RCPT-	81205	1	21-53-12 AC0701/ /	ALL
D08046P		BACC45FT16-24P6 PLUG-	81205	1	21-53-12 AC0701/ /	ALL
D08048J		BACC45FN16-24S6 RCPT-	81205	1	21-53-21 AC0702/ /	ALL
D08048P		BACC45FT16A24P6 PLUG-	81205	1	21-53-21 AC0702/ /	ALL
D08050J		BACC45FN22-55P7 RCPT-E3-1	81205	1	21-53-21 AE0220/ /	050-099, 150-199, 275-278
D08050J		BACC45FN22-55P7 RCPT-E3-1	81205	1	21-53-21 290 E3-1/152/R 58	280-299
D08050P		BACC45FT22-55S7 PLUG-E3-1	81205	1	21-51-22 AE0220/ /	ALL
D08052J		BACC45FN16-24S RCPT-E3-1	81205	1	21-53-21 AE0220/ /	ALL
D08052P		BACC45FT16-24P PLUG-E3-1	81205	1	21-53-21 AE0220/ /	ALL
D08054J		BACC45FN12-12S9 RCPT-P61	81205	1	21-31-31 AF0204/ /	ALL
D08054P		BACC45FT12-12P9 PLUG-P61	81205	1	21-31-31 AF0204/ /	ALL

EQUIPMENT LIST

D280T132

Section D08000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08060J		BACC45FN12-12S RCPT-	81205	1	21-31-31 AC0701/ /	ALL
D08060P		BACC45FT12-12P PLUG-	81205	1	21-31-31 AC0701/ /	ALL
D08064J		BACC45FN14-7P RCPT-P37	81205	1	27-81-21 AE0218/ /	ALL
D08064P		BACC45FT14-7S PLUG-P37	81205	1	27-81-21 AE0218/ /	ALL
D08066J		BACC45FN16-24S8 RCPT-	81205	1	21-53-22 AC0702/ /	ALL
D08066P		BACC45FT16A24P8 PLUG-	81205	1	21-53-22 AC0702/ /	ALL
D08068J		BACC45FN22-55S7 RCPT-	81205	1	36-11-51 AE0202/ /	ALL
D08068P		BACC45FT22-55P7 PLUG-P50	81205	1	21-53-22 AE0202/ /	ALL
D08070J		BACC45FN14-15P9 RCPT-P35	81205	1	52-34-13 AC0506/ /	ALL
D08070P		BACC45FT14-15S9 PLUG-P35	81205	1	52-34-12 AC0506/ /	ALL
D08072J		BACC45FN14-15P9 RCPT-P39	81205	1	52-35-13 AC1304/ /	ALL
D08072P		BACC45FT14-15S9 PLUG-P39	81205	1	52-35-12 AC1304/ /	ALL
D08080J		BACC45FN18-31S RCPT-	81205	1	21-51-12 AP0403/ /	ALL
D08080P		BACC45FT18-31P PLUG-P19	81205	1	21-51-12 AP0403/ /	ALL
D08092J		BACC45FN20-41S9 RCPT-E03-01	81205	1	21-51-12 AE0220/ /	ALL
D08092P		BACC45FT20-41P9 PLUG-E3-1	81205	1	21-58-11 AE0220/ /	ALL
D08094J		BACC45FN10-5P6 RCPT-P19	81205	1	25-63-11 AP0401/ /	050-099

EQUIPMENT LIST

D280T132

Section D08000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08094J		BACC45FN14-7P6 RCPT-P19	81205	1	25-63-11 AP0401/ /	150-199, 275-299
D08094P		BACC45FT10-5S6 PLUG-P19	81205	1	25-63-11 AP0401/ /	050-099
D08094P		BACC45FT14-7S6 PLUG-P19	81205	1	25-63-11 AP0401/ /	150-199, 275-299
D08098J		BACC45FN14-7S6 RCPT-P19	81205	1	25-63-11 AP0403/ /	ALL
D08098P		BACC45FT14-7P6 PLUG-P19	81205	1	25-63-11 AP0403/ /	ALL

EQUIPMENT LIST

D280T132

Section D08000
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08100J		BACC45FN10-5P8 RCPT-P25	81205	1	25-63-11 AP1005/ /	050-099
D08100J		BACC45FN10-5P8 RCPT-	81205	1	25-63-11 AP1005/ /	150-199, 275-299
D08100P		BACC45FT10-5S8 PLUG-P25	81205	1	25-63-11 AP1005/ /	ALL
D08102J		BACC45FN10-5S8 RCPT-P25	81205	1	25-63-11 AP1003/ /	050-099
D08102J		BACC45FN10-5S8 RCPT-	81205	1	25-63-11 AP1003/ /	150-199, 275-299
D08102P		BACC45FT10-5P8 PLUG-P25	81205	1	25-63-11 AP1003/ /	ALL
D08104J		BACC45FN10-5S8 RCPT-P61	81205	1	25-63-11 AF0204/ /	ALL
D08104P		BACC45FT10-5P8 PLUG-P61	81205	1	25-63-11 AF0204/ /	ALL
D08112J		BACC45FN22-55P RCPT-	81205	1	21-51-11 AE0202/ /	ALL
D08112P		BACC45FT22-55S PLUG-P50	81205	1	21-58-14 AE0202/ /	ALL
D08114J		BACC45FN16-24P7 RCPT-	81205	1	76-11-11 AE0104/ /	ALL
D08114P		BACC45FT16-24S7 PLUG-P10	81205	1	76-11-11 AE0104/ /	ALL
D08116J		BACC45FN16-24P6 RCPT-	81205	1	73-21-11 AE0102/ /	ALL
D08116P		BACC45FT16-24S6 PLUG-P10	81205	1	73-21-11 AE0102/ /	ALL
D08118J		BACC45FN18-31P7 RCPT-	81205	1	76-11-11 AE0102/ /	ALL
D08118P		BACC45FT18-31S7 PLUG-P10	81205	1	76-11-11 AE0102/ /	ALL
D08120J		BACC45FN20-41P8 RCPT-	81205	1	32-42-12 AE0102/ /	ALL

EQUIPMENT LIST

D280T132

Section D08100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08120P		BACC45FT20-41S8 PLUG-P10	81205	1	73-21-11 AE0102/ /	ALL
D08124J		48-7191 RCPT-	02660	1	33-22-21 0840/280/0000	050-099
D08124P		48-7190 PLUG-	02660	1	33-22-21 0840/280/0000	050-099
D08126J		48-7191 RCPT-	02660	1	33-22-21 0840/280/0000	050-099
D08126P		48-7190 PLUG-CLOSET LTS	02660	1	33-22-21 0840/280/0000	050-099
D08128J		BACC45FN20-25S6 RCPT-P6	81205	1	24-51-42 AE0222/ /	ALL
D08128P		BACC45FT20-25P6 PLUG-P6	81205	1	24-51-41 AE0222/ /	ALL
D08138		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0654+014/270/L073	150-199
D08138		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0654+014/270/L073	275-278
D08138		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0654+015/270/L073	280-299
D08140		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0654+044/270/L073	150-199
D08140		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0654+044/270/L073	275-299
D08142		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0654+087/270/L073	150-199
D08142		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0654+071/270/L073	275-278
D08142		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0654+073/270/L073	280-299
D08144		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0654+099/270/L073	275-278
D08144		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0654+103/270/L073	280-299

EQUIPMENT LIST

D280T132

Section D08100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08146		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 0771/270/L073	150-199
D08146		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 0771/270/L073	275-299
D08148		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1197+022/270/L073	150-199
D08148		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1197+022/270/L073	275-299
D08150		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1197+050/270/L073	150-199
D08150		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1197+050/270/L073	275-299
D08152		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1197+080/270/L073	150-199
D08152		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1197+080/270/L073	275-299
D08154		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1197+110/270/L073	150-199
D08154		BACC45FN10-5S6 RCPT-	81205	1	33-24-12 1197+110/270/L073	275-299
D08156		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0654+014/270/R070	150-199
D08156		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0654+014/270/R070	275-278
D08156		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0630/270/R074	280-299
D08158		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0654+044/270/R070	150-199
D08158		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0654+044/270/R070	275-278
D08158		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0630/270/R074	280-299
D08160		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 0654+087/270/R070	150-199

EQUIPMENT LIST

D280T132

Section D08100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08160		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0654+071/270/R070	275-278
D08160		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0654+071/270/R074	280-299
D08162		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0654+099/270/R070	275-278
D08162		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 0654+099/270/R074	280-299
D08164		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 771/270/R070	150-199
D08164		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 770/270/R070	275-278
D08164		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 770/270/R073	280-299
D08166		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1197+022/270/R073	150-199
D08166		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1197+022/270/R073	275-299
D08168		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1197+050/270/R073	150-199
D08168		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1197+050/270/R073	275-299
D08170		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1197+080/270/R073	150-199
D08170		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1197+080/270/R073	275-299
D08172		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1197+110/270/R073	150-199
D08172		BACC45FN10-5S6 RCPT-	81205	1	33-24-14 1197+110/270/R073	275-299
D08174		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 0654+114/280/L005	275-299
D08176		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 666/280/L005	275-299

EQUIPMENT LIST

D280T132

Section D08100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08178		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0694/280/L005	150-199
D08178		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 694/280/L005	275-299
D08180		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0716/280/L005	150-199
D08180		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 716/280/L005	275-299
D08182		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0744/280/L005	150-199
D08182		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 744/280/L005	275-299
D08184J		BACC45FN10-5P RCPT-	81205	1	33-24-13 0768/280/L005	275-299
D08184P		BACC45FT10-5S PLUG-	81205	1	33-24-13 768/280/L005	275-299
D08186J		BACC45FN12-12P RCPT-	81205	1	33-24-13 1197+092/280/L005	150-199
D08186J		BACC45FN10-5P RCPT-	81205	1	33-24-13 1197+092/280/L005	275-299
D08186P		BACC45FT12-12S PLUG-	81205	1	33-24-13 1197+092/280/L005	150-199
D08186P		BACC45FT10-5S PLUG-	81205	1	33-24-13 1197+092/280/L005	275-299
D08188		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1197+092/280/L005	150-199
D08188		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1197+092/280/L005	275-299
D08190		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1197+116/280/L005	150-199
D08190		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1197+116/280/L005	275-299
D08192		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1212/280/L005	150-199

EQUIPMENT LIST

D280T132

Section D08100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08192		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1212/280/L005	275-299
D08194		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1238/280/L005	150-199
D08194		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1238/280/L005	275-299
D08196		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 1265/280/L005	150-199
D08196		BACC45FN10A5S6 RCPT-	81205	1	33-24-13 1265/280/L005	275-299
D08198J		BACC45FN12-3P RECP-	81205	1	35-21-14 0768/280/L005	275-299
D08198P		BACC45FT12-3S PLUG-	81205	1	35-21-14 768/280/L005	275-299

EQUIPMENT LIST

D280T132

Section D08100
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08200J		BACC45FN12-3P RCPT-	81205	1	35-21-14 1197+092/280/L005	150-199, 275-299
D08200P		BACC45FT12-3S PLUG-	81205	1	35-21-14 1197+092/280/L005	150-199, 275-299
D08202J		BACC45FN12-12S9 RCPT-E1-2	81205	1	32-71-11 AE0307/ /	150-199, 275-299
D08202P		BACC45FT12A12P9 PLUG E1-2	B1205	1	32-71-11 AE0307/ /	150-199, 275-299
D08204J		BACC45FN12-12S7 RCPT TAIL-DISC	81205	1	32-71-11 AP1501/ /	150-199, 275-299
D08204P		BACC45FT12-12P7 PLUG TAIL-DISC	81205	1	32-71-11 AP1501/ /	150-199, 275-299
D08268J		BACC45FM18C14S RCPT-	81205	1	32-45-13 AL1003/ /	050-099
D08268J		BACC45FM18C14S RCPT-	81205	1	32-48-11 AL1003/ /	150-199, 275-299
D08268P		BACC63BP18R14PNL PLUG-	81205	1	32-45-13 AL1003/ /	050-099
D08268P		BACC63BP18R14PNL PLUG-	81205	1	32-48-11 AL1003/ /	150-199, 275-299
D08268PQ		BACC10KD18 CLAMP	81205	1	32-45-13 AL1003/ /	050-099
D08268PQ		BACC10KD18 CLAMP-	81205	1	32-48-11 / /	155-199, 275-299
D08272J		BACC45FM18C14S9 RCPT-	81205	1	32-45-14 AL1004/ /	050-099, 280-299
D08272J		BACC45FM18C14S9 RCPT-	81205	1	32-48-12 AL1004/ /	150-199, 275-278
D08272P		BACC63BP18R14P9L PLUG-	81205	1	32-45-14 AL1004/ /	050-099
D08272P		BACC63BP18R14P9L PLUG-	81205	1	32-48-12 AL1004/ /	150-199, 275-299
D08272PQ		BACC10KD18 CLAMP	81205	1	32-45-14 AL1004/ /	051-099

EQUIPMENT LIST

D280T132

Section D08200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08272PQ		BACC10KD18 CLAMP-	81205	1	32-45-14 AL1004/ /	155-199, 277-299
D08272PQ		BACC10KD18 CLAMP-	81205	1	32-48-12 / /	275-276

EQUIPMENT LIST

D280T132

Section D08200
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08306J		S345T002-156 RCPT-	81205	1	28-21-12 L0163/ /FS	ALL
D08306JL		BACC10KB14 CLAMP	81205	1	28-21-12 / /	ALL
D08306P		BACC63BP14A7SNL PLUG	81205	1	28-21-12 L0163/ /FS	ALL
D08306PQ		BACC10KD14 CLAMP	81205	1	28-21-12 L0163/ /	ALL
D08308J		S345T002-156 RCPT-	81205	1	28-21-12 R0163/ /FS	ALL
D08308JL		BACC10KB14 CLAMP	81205	1	28-21-12 / /	ALL
D08308P		BACC63BP14A7SNL PLUG	81205	1	28-21-12 R0163/ /FS	ALL
D08308PQ		BACC10KD14 CLAMP	81205	1	28-21-12 R0163/ /	ALL
D08312		BACC63BR18B14SNL PLUG-	81205	2	76-11-11 NR152/080/	ALL
D08312 T		BACC10KB18 CLAMP-	81205	2	76-11-11 / /	ALL
D08314		BACC63BP16A10SNL PLUG-	81205	2	75-23-11 NL144/121/	ALL
D08314 T		BACC10KD16 CLAMP-	81205	2	75-23-11 / /	ALL
D08316J		BACC63BV12B3PN RCPT-FANCASE/INLET COWL	81205	2	30-34-11 NR095/150/	ALL
D08316JK		BACC10KA12 CLAMP	81205	2	30-34-11 NR095/150/	050-099, 150-156, 162-166, 275-276
D08316JK		BACC10KA12 CLAMP	81205	2	30-34-11 / /	157, 167-199, 277- 299
D08316P		BACC63BP12D3SNL PLUG-ENGINE	81205	2	73-21-12 NR100/150/	ALL
D08316PQ		BACC10KB12 CLAMP-	81205	2	73-21-12 / /	ALL

EQUIPMENT LIST

D280T132

Section D08300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08320J		BACC63BV28F42S7 RCPT-STRUT/FANCASE RH	81205	1	71-51-12 AW0310/POS/02	ALL
D08320JK		BACC10KD28 CLAMP	81205	1	71-51-12 / /	ALL
D08320P		BACC63BP28C42P7L PLUG-STRUT/FANCASE RH	81205	2	73-21-11 AW0310/ /	ALL
D08320PQ		BACC10KD28 CLAMP-	81205	2	73-21-11 / /	ALL
D08328J		BACC63BV12B3P6 RCPT FANCASE/INLET COWL M/W VENDOR	81205	2	73-21-12 NR095/150/	ALL
D08328JK		BACC10KB12 CLAMP-	81205	2	73-21-12 NR095/150/	ALL
D08330P		BACC63BP22D19S6L PLUG-ENG (PW4000)	81205	2	73-21-11 NR100/150/	050-099, 155-199, 277-299
D08330P		BACC63BP22D19S6L PLUG-ENG VENDOR BRKT LOWER	81205	2	73-21-11 NR100/150/	150-154, 275-276
D08330PQ		BACC10KA22 CLAMP-	81205	2	73-21-11 / /	ALL
D08332J		BACC63BV12F3P7 RCPT-FANCASE/INLET COWL M/W VENDOR	81205	2	30-34-11 NR095/150/	050-099, 150-156, 162-166, 275-276
D08332J		BACC63BV12F3P7 RCPT-FANCASE/INLET COWL M/W VENDOR	81205	2	73-21-12 NR095/150/	157, 167-199, 277- 299
D08332JK		BACC10KE12 CLAMP	81205	2	30-34-11 NR095/150/	050-099, 150-156, 162-166, 275-276
D08332JK		BACC10KD12 CLAMP	81205	2	30-34-11 / /	157, 167-199, 277- 299
D08334J		BACC63BV28F42S7 RCPT STRUT FANCASE RH	81205	1	71-51-12 AW0310/POS/02	ALL
D08334JK		BACC10KD28 CLAMP	81205	1	71-51-12 / /	ALL
D08336P		BACC63BP22C19PNL PLUG-FANCASE L/H	81205	2	31-35-14 NL113/147/	ALL
D08336PQ		BACC10KD22 CLAMP-	81205	2	31-35-14 / /	ALL

EQUIPMENT LIST

D280T132

Section D08300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08338J		BACC63BV14B7SN RECP M/W VENDOR LVDT	81205	2	78-36-11 15/0/R029	ALL
D08338JK		BACC10KA14 CLAMP	81205	2	71-51-12 / /	ALL
D08340J		BACC63BV14B7SN RECP M/W VENDOR LVDT	81205	2	78-36-11 -63/0/R005	ALL
D08340JK		BACC10KA14 CLAMP	81205	2	71-51-12 / /	ALL
D08342J		BACC63BV14B7SN RECP M/W VENDOR LVDT	81205	2	71-51-12 NL126/ /	ALL
D08342JK		BACC10KA14 CLAMP	81205	2	71-51-12 / /	ALL
D08344J		BACC63BV14B7SN RECP M/W VENDOR LVDT	81205	2	71-51-12 NL 126/ /	ALL
D08344JK		BACC10KA14 CLAMP	81205	2	71-51-12 / /	ALL
D08346P		BACC63BP22D19SNL PLUG - ENGINE	81205	2	73-21-12 NR190/150/	050-099, 155-199, 277-299
D08346P		BACC63BP22D19SNL PLUG - ENGINE VENDOR BRK UPPER	81205	2	73-21-12 NR100/150/	150-154, 275-276
D08346PQ		BACC10KA22 CLAMP	81205	2	73-21-12 NR100/150/	ALL
D08370P		BACC63BP24D30SNL PLUG-ENGINE	81205	2	73-21-11 NR190/150/	ALL
D08370PQ		BACC10KA24 CLAMP	81205	2	73-21-11 NR190/ /	050-099, 155-199, 277-299
D08370PQ		BACC10KA24 CLAMP	81205	2	73-21-11 / /	150-154, 275-276
D08374J		BACC63BV16A24S6 RCPT	81205	1	28-31-11 AL1003/ /	050-099, 155-199, 276-299
D08374JK		BACC10KD16 CLAMP	81205	0	28-31-11 AL1003/ /	050-099
D08374JK		BACC10KD16 CLAMP	81205	1	28-31-11 AL1003/ /	155-199, 276-299

EQUIPMENT LIST

D280T132

Section D08300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08374P		BACC63BP16A24P6L PLUG- R FWD INBD PANEL	81205	1	28-31-11 AL1003/ /	050-099, 155-199, 276-299
D08374PQ		BACC10KD16 CLAMP-	81205	1	28-31-11 / /	050-099, 155-199, 276-299
D08376J		BACC63BV14A15S6 RCPT-R FWD OUTBD PANEL	81205	1	28-31-11 AL1002/ /	050-099, 155-199, 276-299
D08376JK		BACC10KD14 CLAMP	81205	1	28-31-11 AL1002/ /	157, 167-199, 277- 299
D08376P		BACC63BP14A15P6L PLUG- R FWD OUTBD PANEL	81205	1	28-31-11 AL1002/ /	050-099, 155-199, 276-299
D08376PQ		BACC10KD14 CLAMP	81205	1	28-31-11 / /	050-099, 155-199, 276-299

EQUIPMENT LIST

D280T132

Section D08300
Page 4 End
Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08503		2J-1865A JACK-GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 1678/183/R047	ALL
D08505		2J-1865A JACK-GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 1832/215/R020	ALL
D08539		2J-1865A JACK-GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 0287/171/R004	ALL
D08541		2J-1865A JACK-GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 0147/169/L008	ALL
D08543		2J-1865A JACK-P40 GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 P040-00/ /	ALL
D08545		2J-1865A JACK-P40 GROUND SUPPORT EQUIPMENT	7K861	1	23-51-11 P040-00/ /	ALL
D08547		2J-1865A JACK-P35 GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 P035-00/ /	ALL
D08549		2J-1865A JACK-P28 GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 P028-00/ /	ALL
D08553		2J-1865A JACK-GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 0953/115/R035	ALL
D08555		2J-1865A JACK-P39 GROUND SUPPORT EQUIPMENT	7K861	1	23-41-11 P039-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D08500

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08608		BACC45FN12-12S RECPT-P6 L ENG EEC MAINT I/F	81205	1	77-35-11 0243/211/R043	ALL
D08610		BACC45FN12-12S RECPT-P6 R ENG EEC MAINT I/F	81205	1	77-35-11 243/211/R043	050-099
D08610		BACC45FN12-12S RECPT-P6 R ENG EEC MAINT I/F	81205	1	28-41-11 0243/211/R043	150-199
D08610		BACC45FN12-12S RECPT-P6 R ENG EEC MAINT I/F	81205	1	77-35-11 0243/211/R043	275-299
D08614J		BACC45FN14-15S7 RCPT-E2-4	81205	1	28-41-11 AE0320/ /	ALL
D08614P		BACC45FT14-15P7 PLUG-E2-4	81205	1	28-41-11 AE0320/ /	050-099, 150-156, 162-165, 275-276
D08614P		BACC45FT14A15P7 PLUG-E2-4	81205	1	28-41-11 AE0320/ /	157, 166-199, 277- 299
D08680J		BACC45FN16-24S8 RECPT P037	81205	1	21-61-81 P037-00/ /	050-099
D08680J		BACC45FN16-24S8 RECPT-P37	81205	1	21-61-81 AE0218/ /	150-199, 275-299
D08680P		BACC45FT16-24P8 PLUG	81205	1	21-61-81 292/169/R68	ALL
D08686J		BACC45FN14-12S RECP-P32	81205	1	25-31-12 AE0312/ /	050-099, 150-199
D08686P		BACC45FT14-12P PLUG-P32	81205	1	25-31-12 345/150/R75	050-099, 150-199
D08688J		BACC45FN20-39S9 PLUG	81205	1	33-22-41 AP0307/ /	050-099
D08688J		BACC45FN20-39S9 PLUG	81205	1	33-21-11 AP0307/ /	150-199
D08688P		BACC45FT20-39P9 PLUG	81205	1	33-21-11 380/315/L8	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D08600
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D08706J		BACC45FN20-39S7 RECP-	81205	1	26-13-12 AP0307/ /	050-099
D08706J		BACC45FN20-39S7 RCPT	81205	1	21-66-11 AP0307/ /	162-199
D08706P		BACC45FT20-39P7 PLUG	81205	1	26-13-11 AP0307/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section D08700
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09000	9	CUSTOMER RECEPT	CUST	1	25-25-23 E002-06/ /	150, 153-199
D09000	9	CUSTOMER-A PLUG	CUST	1	21-73-11 451/300/L014	275-299
D09001	9	CUSTOMER-A PLUG	CUST	1	21-73-11 931/300/R031	275-278
D09001	9	CUSTOMER-A PLUG	CUST	1	21-73-11 451/300/R031	280-299
D09001J	9	280T1000-4 RECP-MOA REF BACC45FN20-28S9(MTO 230523)	CUST	1	23-32-13 AP0405/ /	150, 153-157
D09001J	9	BACC45FN20-28P RECP (MTO 330348)	CUST	1	23-32-13 AP0405/ /	162-199
D09001P	9	280T1000-5 PLUG-MOA REF BACC45FT20-28P9(MTO 230523)	CUST	1	23-32-13 AP0405/ /	150, 153-157
D09001P	9	BACC45FT20-28S PLUG (MTO 330348)	91836	1	33-22-21 AP0405/ /	162-199
D09002	9	CUSTOMER-A PLUG	CUST	1	21-73-11 1356/300/L010	275-299
D09002J	9	280T1000-24 RECP-MOA REF BACC45FN20-28S8(MTO 230523)	CUST	1	23-32-13 AP0901/ /	150, 153-157
D09002P	9	280T1000-25 PLUG-MOA REF BACC45FT20-28P8(MTO 230523)	CUST	1	23-32-13 AP0901/ /	150, 153-157
D09004	9	MS3126F14-12P PLUG (MTO 230523)	91836	1	23-32-13 621/308/R 36	150, 153-157
D09006	9	KC-59-585-M06 PLUG-COAXIAL (MTO 230523)	91836	1	23-32-13 621/308/R 36	150, 153-157
D09007	9	DAMA11W1S PLUG (DMA11W1S) (MTO 230523)	71468	1	23-32-13 458/295/L69	150, 153-157
D09008	9	DAMA11W1S PLUG (DMA11W1S) (MTO 230523)	91836	1	23-32-13 458/295/R 69	150, 153-157
D09010	9	KC-59-585-M06 PLUG-COAXIAL (MTO 230523)	91836	1	23-32-13 458/295/R 69	150, 153-157
D09015	9	MS3126F14-12P PLUG (MTO 230532)	91836	1	23-32-13 621/308/R 36	162-199

EQUIPMENT LIST

D280T132

Section D09000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09016	9	KC-59-585-M06 PLUG-COAXIAL (MTO 230532)	91836	1	23-32-13 621/308/R 36	162-199
D09017	9	BACC45FT12A12S PLUG (MTO 230532)	81205	1	23-32-13 535/280/R 36	162-199
D09018	9	KC-59-585-M06 PLUG-COAXIAL (MTO 230532)	81205	1	23-32-13 535/280/R 36	162-199
D09019J	9	CUSTOMER RECP		1	23-32-13 850/280/0	050-099
D09019P	9	CUSTOMER PLUG		1	23-32-13 850/280/0	050-099
D09020	9	KC-59-585-M06 PLUG-COAXIAL (MTO 230532)	91836	1	23-32-13 800/295/R 69	162-199
D09024	9	MS3126F14-12P PLUG (MTO 230532)	91836	1	23-32-13 820/308/R 36	162-199
D09026	9	KC-59-585-M06 PLUG-COAXIAL (MTO 230532)	91836	1	23-32-13 820/308/R 36	162-199
D09027	9	DAMA11W1S PLUG (DMA11W1S) (MTO 230532)	71468	1	23-32-13 800/295/L 69	162-199
D09028	9	DAMA11W1S PLUG (DMA11W1S) (MTO 230532)	71468	1	23-32-13 800/295/R 69	162-199
D09047J	9	CUSTOMER RECEPT	CUST	1	25-25-23 356/282/80	150, 153-199
D09048	9	CUSTOMER-A PLUG	CUST	1	25-25-23 E002-06/ /	150, 153-199
D09049J	9	CUSTOMER RECEPT	CUST	1	25-25-23 467/ /	150, 153-199
D09050J	9	CUSTOMER RECEPT	CUST	1	25-25-23 654+29/ /	150, 153-199
D09051J	9	CUSTOMER RECEPT	CUST	1	25-25-23 467/ /	150, 153-199
D09052J	9	CUSTOMER RECEPT	CUST	1	25-25-24 709/ /	150, 153-199
D09053J	9	CUSTOMER RECEPT	CUST	1	25-25-24 705/ /	150, 153-199

EQUIPMENT LIST

D280T132

Section D09000

Page 2

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09054J	9	CUSTOMER RECEPT	CUST	1	25-25-24 709/ /	150, 153-199
D09055J	9	CUSTOMER-1 RECEPT	CUST	1	25-25-23 AE0306/ /	150, 153-199
D09055P	9	CUSTOMER PLUG	CUST	1	25-25-23 AE0306/ /	150, 153-199
D09060J	9	CUSTOMER-A RECP	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09060P	9	CUSTOMER-A PLUG	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09061J	9	CUSTOMER RECP	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09061P	9	CUSTOMER-A PLUG	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09062A	9	CUSTOMER PLUG	CUST	1	23-19-11 0420/170/R074	150, 152-199
D09062B	9	CUSTOMER PLUG	CUST	1	23-19-11 0420/170/R074	150, 152-199
D09062C	9	CUSTOMER PLUG	CUST	1	23-19-11 0420/170/R064	150, 152-199
D09063J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09063P	9	CUSTOMER-AA PLUG	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09064J	9	CUSTOMER RECEPT	CUST	1	23-19-11 654+57R/ /	150, 152-199
D09065J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09065P	9	CUSTOMER-A- PLUG	CUST	1	23-25-14 E090-90/ /	150, 152-199
D09066J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09066P	9	CUSTOMER-AA PLUG	CUST	1	23-19-11 E090-90/ /	150, 152-199

EQUIPMENT LIST

D280T132

Section D09000

Page 3

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09067J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09067P	9	CUSTOMER-AA PLUG	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09068P	9	CUSTOMER PLUG	CUST	1	23-19-11 654+30/304/R051	150, 152-199
D09069P	9	CUSTOMER PLUG	CUST	1	23-19-11 687/304/R051	150, 152-199
D09070P	9	CUSTOMER PLUG	CUST	1	23-19-11 654+30/304/R051	150, 152-199
D09071P	9	CUSTOMER PLUG	CUST	1	23-19-11 654+30/304/R051	150, 152-199
D09072P	9	CUSTOMER PLUG	CUST	1	23-19-11 654+30/304/R051	150, 152-199
D09073J	9	CUSTOMER RECEPT	CUST	1	23-19-11 654+80/22/L90	150, 152-199
D09073P	9	CUSTOMER-1 PLUG	CUST	1	23-19-11 654+180/202/L90	150, 152-199
D09074J	9	CUSTOMER RECEPT	CUST	1	23-19-11 654+29/200/00	150, 152-199
D09074P	9	CUSTOMER-1 PLUG	CUST	1	23-19-11 654+29/200/	150, 152-199
D09075J	9	CUSTOMER RECEPT	CUST	1	23-19-11 654+80/202/R90	150, 152-199
D09075P	9	CUSTOMER-1 PLUG	CUST	1	23-19-11 654+80/202/R90	150, 152-199
D09076P	9	CUSTOMER RECEPT	CUST	1	23-19-11 0687/304/R051	150, 152-199
D09077P	9	CUSTOMER PLUG	CUST	1	23-19-11 687/304/R051	150, 152-199
D09078P	9	CUSTOMER PLUG	CUST	1	23-19-11 687/304/R051	150, 152-199
D09079J	9	CUSTOMER RECPT	CUST	1	23-19-11 688/202/L90	150, 152-199

EQUIPMENT LIST

D280T132

Section D09000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09079P	9	CUSTOMER-1 PLUG	CUST	1	23-19-11 688/202/L90	150, 152-199
D09080J	9	CUSTOMER RECEPT	CUST	1	23-19-11 723/200/000	150, 152-199
D09080P	9	CUSTOMER-1 PLUG	CUST	1	23-19-11 723/200/000	150, 152-199
D09081J	9	CUSTOMER RECEPT	CUST	1	23-19-11 688/202/R90	150, 152-199
D09081P	9	CUSTOMER-1 PLUG	CUST	1	23-19-11 688/202/R90	150, 152-199
D09082A	9	CUSTOMER RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09082B	9	CUSTOMER PLUG	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09082C	9	CUSTOMER RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09083P	9	CUSTOMER PLUG	CUST	1	23-19-11 654+30/304/R051	150, 152-199
D09084P	9	CUSTOMER PLUG	CUST	1	23-19-11 284/286/L72	150, 152-199
D09085P	9	CUSTOMER PLUG	CUST	1	23-19-11 687/304/R051	150, 152-199
D09086P	9	CUSTOMER PLUG	CUST	1	23-19-11 654/119/R15	150, 152-199
D09090	9	TBD PLUG (TD2891) (TO-230607)	CUST	1	23-22-12 196/223/0000	150, 152-199
D09091J	9	CUSTOMER-1 RCPT (MS24264R20B28PN)	81205	1	23-32-21 AP0405/ /	150, 152-199
D09091P	9	MS24266R20B28SN PLUG	81205	1	23-32-21 AP0405/ /	150, 152-199
D09093J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09094J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199

EQUIPMENT LIST

D280T132

Section D09000

Page 5

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09095J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09096J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09097J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09098J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09099J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199

EQUIPMENT LIST

D280T132

Section D09000

Page 6 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09100J	9	CUSTOMER-A RECEPT	CUST	1	23-19-11 E090-90/ /	150, 152-199
D09101P	9	CUSTOMER PLUG	CUST	1	23-19-11 MULTI/ /	150, 152-199
D09102P	9	CUSTOMER PLUG	CUST	1	23-19-11 MULTI/ /	150, 152-199
D09103	9	CUSTOMER PLUG	CUST	1	23-19-11 MULTI/ /	150, 152-199
D09104J	9	CUSTOMER RECEPT	CUST	1	23-19-11 MULTI/ /	150, 152-199
D09104P	9	CUSTOMER-1 PLUG	CUST	1	23-19-11 TBD/ /	150, 152-199
D09105	9	CUSTOMER PLUG	CUST	1	23-19-11 TBD/ /	150, 152-199
D09106	9	CUSTOMER PLUG	CUST	1	23-19-11 TBD/ /	150, 152-199
D09107	9	CUSTOMER PLUG	CUST	1	23-19-11 284/273/L54	150, 152-199
D09108	9	CUSTOMER PLUG	CUST	1	23-19-11 TBD/ /	150, 152-199
D09109	9	CUSTOMER PLUG	CUST	1	23-19-11 265/ /	150, 152-199
D09110J	9	CUSTOMER RECEPT	CUST	1	23-19-11 P061-00/ /	150, 152-199
D09110P	9	CUSTOMER-1 PLUG	CUST	1	23-19-11 P061-00/ /	150, 152-199
D09123J	9	BACC45FN22-55S RCPT-	81205	1	34-46-12 AE0319/ /	150, 152-199, 275-299
D09123P	9	BACC45FT22A55P PLUG	81205	1	34-46-13 AE0319/ /	150, 152-199, 275-299
D09124	9	BACC45FT16A24PN PLUG (D09124P)	81205	1	33-13-13 P003-01/ /	150, 152-199, 275-299
D09125J	9	TFS165-2 RCPT-	CUST	1	34-46-11 AE0325/ /	150, 152-199, 275-299

EQUIPMENT LIST

D280T132

Section D09100

Page 1

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09125P	9	TMS165-1 PLUG	CUST	1	34-46-11 AE0325/ /	150, 152-199, 275- 299
D09126	9	TMS165-1 PLUG	CUST	1	34-46-11 600/319/	150, 152-199, 275- 299
D09127	9	BACS16AF1 RELAY SOCKET	81205	1	34-46-13 E001-05/ /	150, 152-199, 275- 299
D09128	9	BACS16AF1 RELAY SOCKET	81205	1	34-46-13 E001-05/ /	150, 152-199, 275- 299
D09129	9	BACS16AF1 RELAY SOCKET	81205	1	34-46-13 E001-05/ /	150, 152-199, 275- 299
D09130	9	BACS16AF1 RELAY SOCKET	81205	1	34-46-13 E001-05/ /	150, 152-199, 275- 299
D09131	9	BACC45FT16A24PN RECEPT (D09131P)	81205	1	34-46-13 P001-01/ /	150, 152-199, 275- 299

EQUIPMENT LIST

D280T132

Section D09100

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09299J	9	BACC45FN14-4SN RECEPT (MS24264R14B4SN)	81205	1	25-25-23 AE0209/ /	150, 153, 157, 165- 199
D09299P	9	BACC45FT14-4PN PLUG (MS24266R14B4PN)	81205	1	25-25-23 AE0209/ /	150, 153, 157, 165- 199

EQUIPMENT LIST

D280T132

Section D09200
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D09310	9	CUSTOMER-1 PLUG (225395-7)	0L4R8	1	23-32-21 447/245/L80	150, 152-199
D09311	9	CUSTOMER-1 PLUG (MS24266R16B24SN)	81205	1	23-32-21 447/245/L80	150, 152-199
D09312	9	CUSTOMER-1 PLUG (MS24266B24SN)	81205	1	23-32-21 447/245/L80	150, 152-199
D09313	9	CUSTOMER-NC PLUG (MS24266R18B8SN)	81205	1	23-32-21 447/245/L80	150, 152-199
D09314	9	MS27467E13B35S PLUG	81205	1	23-32-21 SHELF/E01/05	150, 152-199

EQUIPMENT LIST

D280T132

Section D09300

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10012		BACS16X1A RELAY SOCKET-	81205	1	27-81-11 P037-00/ /	ALL
D10014		BACS16X1A RELAY SOCKET-	81205	1	27-81-21 P037-00/ /	ALL
D10016		BACS16X1A RELAY SOCKET-	81205	1	27-51-11 P033-00/ /	ALL
D10020		BACC45FN8-2S RCPT-	81205	1	35-21-12 1509/285/L014	050-099
D10032		BACC45FT16A24S PLUG-	81205	1	27-51-11 P003-01/ /	ALL
D10034		BACC45FN8-2S RCPT-	81205	1	35-21-14 0790/280/L005	050-099
D10034		BACC45FN8-2S RCPT-	81205	1	35-21-14 0768/280/L005	150-199, 275-299
D10036		BACC45FN8-2S RCPT-	81205	1	35-21-14 0785/278/0000	150-199
D10036		BACC45FN8-2S RCPT-	81205	1	35-21-14 AP0703/ /	280-299
D10038		BACC45FN8-2S RCPT-	81205	1	35-21-14 AP0802E/ /	050-099
D10038		BACC45FN8-2S RCPT-	81205	1	35-21-14 0816/280/L005	150-199
D10040		BACC45FN8-2S RCPT-	81205	1	35-21-14 0893/280/L005	050-099, 275-299
D10040		BACC45FN8-2S RCPT-	81205	1	35-21-14 893/280/L5	150-199
D10042		BACC45FN8-2S RCPT-	81205	1	35-21-14 0948/280/L005	050-099, 275-299
D10042		BACC45FN8-2S RCPT-	81205	1	35-21-14 0951/280/L005	150-199
D10044		BACC45FN8-2S RCPT-	81205	1	35-21-14 0974/280/L005	050-099, 275-299
D10046		BACC45FN8-2S RCPT-	81205	1	35-21-14 1001/280/L005	050-099, 275-299

EQUIPMENT LIST

D280T132

Section D10000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10050		BACC45FT12A12S PLUG	81205	1	33-21-34 1391/295/R056	050-099, 162-199
D10050		BACC45FT12A12S PLUG	81205	1	33-21-34 1428/295/R056	150-157
D10062		BACC65L66 RCPT-	81205	1	73-21-18 P050-00/ /	ALL
D10062 U		BACC47EM1 KEYING PLUG-	81205	2	73-21-18 / /	ALL
D10064		BACC65L66 RCPT-	81205	1	73-21-18 P050-00/ /	ALL
D10064 U		BACC47EM1 KEYING PLUG-	81205	2	73-21-18 / /	ALL
D10068		BACS16AG1 RELAY SOCKET-P36	81205	1	28-22-12 P036-00/ /	050-099
D10068		BACS16AG1 RELAY SOCKET-P36	81205	1	28-21-15 P036-00/ /	150-199, 275-299
D10074		BACS16AF1 RELAY SOCKET-P37	91663	1	21-58-11 P037-00/ /	ALL
D10078		BACS16AF1 RELAY SOCKET-P37	81205	1	21-26-11 P037-00/ /	ALL
D10088		BACS16AG1 RELAY SOCKET-P37	81205	1	78-36-21 P037-00/ /	ALL
D10090		BACS16AG1 RELAY SOCKET-P37	81205	1	78-36-21 P037-00/ /	ALL
D10092		BACC65L66 RCPT-	81205	1	26-11-11 P054-00/ /	ALL
D10092 U		BACC47EM1 KEYING PLUG-	81205	1	26-11-11 / /	ALL
D10094		BACC65L66 RCPT-	81205	1	26-11-21 P054-00/ /	ALL
D10094 U		BACC47EM1 KEYING PLUG-	81205	2	26-11-21 / /	ALL
D10096		BACC65L66 RCPT-	81205	1	26-15-11 P054-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10096 U		BACC47EM1 KEYING PLUG-	81205	2	26-15-11 / /	ALL
D10098		BACC65L66 RCPT-	81205	1	26-16-11 P054-00/ /	ALL
D10098 U		BACC47EM1 KEYING PLUG-	81205	2	26-16-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D10000
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10100		BACC45FT10D5S6 PLUG-	81205	1	26-21-11 P008-00/ /	ALL
D10102		BACC45FT12D12S7 PLUG-	81205	1	26-21-11 P008-00/ /	ALL
D10104		BACC45FT16A24S PLUG-	81205	1	26-11-11 P008-00/ /	ALL
D10106		BACC45FT12A12S PLUG-	81205	1	26-11-11 P008-00/ /	ALL
D10108		BACC45FT14-7S PLUG-	81205	1	27-51-61 P037-00/ /	ALL
D10110		BACC45FT16A24S7 PLUG-P61	81205	1	27-13-11 P061-00/ /	ALL
D10112		BACC45FT16A24S6 PLUG-P61	81205	1	27-13-11 P061-00/ /	ALL
D10114		BACC45FT16A24S PLUG-	81205	1	27-13-11 P061-00/ /	ALL
D10122		BACC45FT16B24S6 PLUG-	81205	1	77-12-12 P001-03/ /	ALL
D10122 T		C0900-246-16-A01 CLOCKING DEVICE	13556	1	77-12-12 P001-03/ /	050-099, 155-199, 275-299
D10124		BACC45FT16A24S9 PLUG-	81205	1	77-12-12 P001-03/ /	ALL
D10126		BACS16W1 RELAY SOCKET-P36	81205	1	21-44-11 P033-00/ /	ALL
D10128		BACS16AF1 RELAY SOCKET-	81205	1	21-51-13 P033-00/ /	ALL
D10130		BACS16AF1 RELAY SOCKET-P33	81205	1	21-51-21 P033-00/ /	ALL
D10132		BACS16AF1 RELAY SOCKET-	81205	1	21-51-22 P033-00/ /	ALL
D10134		CN0966A10A20SN-000 PLUG-	13556	1	21-51-13 0859/125/L018	ALL
D10134 T		BACC10KD10 CLAMP-	81205	1	21-51-13 / /	ALL

EQUIPMENT LIST

D280T132

Section D10100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10136		CN0966A10A20SN-000 PLUG-	13556	1	21-51-13 0879/124/L034	ALL
D10136 T		BACC10KD10 CLAMP-	81205	1	21-51-13 / /	ALL
D10138		CN0966A10A20SN-000 PLUG-	13556	1	21-51-23 0879/125/R059	ALL
D10138 T		BACC10KD10 CLAMP-	81205	1	21-51-23 / /	ALL
D10140		CN0966A10A20SN-000 PLUG-	13556	1	21-51-23 0879/124/R044	ALL
D10140 T		BACC10KD10 CLAMP-	81205	1	21-51-23 / /	ALL
D10142		BACS16AF1 RELAY SOCKET-	81205	1	21-51-11 P036-00/ /	ALL
D10144		BACC63BP10R5S8L PLUG-	81205	1	36-21-11 0820/130/L090	050-099, 150-199
D10144		BACC63BP10R5S8L PLUG-	81205	1	36-21-11 0783/130/L038	275-299
D10144 T		BACC10KD10 CLAMP-	81205	1	36-21-11 / /	ALL
D10146		BACC63BP10R5S8L PLUG-	81205	1	36-21-11 0790/130/R090	ALL
D10146 T		BACC10KD10 CLAMP-	81205	1	36-21-11 / /	ALL
D10148		BACS16AG1 RELAY SOCKET-P37	81205	1	21-61-21 P037-00/ /	ALL
D10150		BACS16AG1 RELAY SOCKET-P37	81205	1	21-61-21 P037-00/ /	ALL
D10152		BACC66F11C50AA01 PLUG-	81205	1	21-51-23 SHELF/E03/02	ALL
D10152A		PARTAOFD10152 PLUG-PART OF D10152		0	21-51-13 / /	ALL
D10152B		PARTBOFD10152 PLUG-PART OF D10152		0	21-51-23 / /	ALL

EQUIPMENT LIST

D280T132

Section D10100
Page 2
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10152C		PARTCOFD10152 PLUG-PART OF D10152		0	21-51-13 / /	ALL
D10154		BACS16AG1 RELAY SOCKET-	81205	1	21-61-31 P037-00/ /	ALL
D10156		BACS16AG1 RELAY SOCKET-	81205	1	21-61-31 P037-00/ /	ALL
D10158		10-60450-5 RELAY SOCKET-P37	81205	1	30-21-11 P037-00/ /	ALL
D10160		10-60450-5 RELAY SOCKET-	81205	1	30-21-11 P036-00/ /	ALL
D10162		BACS16AG1 RELAY SOCKET-P33	81205	1	78-36-21 P033-00/ /	ALL
D10162 V		289T0247-10505 I.D. TAPE - TEXT AS BELOW		1	78-34-21 P033-00/ /	050-099
D10162 V		289T0247-10505 I.D. TAPE - TEXT AS BELOW		1	78-34-21 P33/ /	150-199, 275-299
D10164		BACS16AG1 RELAY SOCKET-	81205	1	78-36-11 P036-00/ /	ALL
D10166		BACS16AG1 RELAY SOCKET-	81205	1	78-36-11 P036-00/ /	ALL
D10168		BACS16AG1 RELAY SOCKET-	81205	1	78-36-11 P033-00/ /	ALL
D10168 V		289T0247-10605 I.D. TAPE - TEXT AS BELOW		1	78-36-11 P33/ /	050-099
D10168 V		289Y0247-10605 I.D. TAPE - TEXT AS BELOW		1	78-36-11 P33/ /	150-199, 275-299
D10174		BACC45FN10-5S RCPT-	81205	1	33-22-31 832/260/R 12	050-099
D10174		BACC45FN10-5S RCPT-	81205	1	33-22-31 918/260/L 20	150-199
D10174		BACC45FN10-5S RCPT-	81205	1	33-22-31 801/260/L18	275-299
D10176		BACC45FN10-5S RCPT-	81205	1	33-22-31 1540/260/L 54	050-099

EQUIPMENT LIST

D280T132

Section D10100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10176		BACC45FN10-5S RCPT-P59	81205	1	33-22-31 P059-00/ /	150-199, 275-299
D10180		BACC45FT12-12S PLUG-P6	81205	1	24-32-11 P006-00/ /	ALL
D10182		BACC45FT12-12S PLUG-E3	81205	1	24-34-11 SHELF/E03/	ALL
D10184		BACS16W1 RELAY SOCKET	81205	1	30-31-11 P033-00/ /	ALL
D10186		BACS16W1 RELAY SOCKET-	81205	1	30-31-11 P033-00/ /	ALL
D10188		BACS16W1 RELAY SOCKET-	81205	1	30-31-21 P033-00/ /	ALL
D10190		BACS16W1 RELAY SOCKET	81205	1	30-31-21 P033-00/ /	ALL
D10192		BACC45FT10-5S PLUG-	81205	1	21-33-21 0212/195/R080	ALL
D10194		BACS16X1A RELAY SOCKET-P36	81205	1	32-42-11 P036-00/ /	ALL
D10196		BACS16X1A RELAY SOCKET-P36	81205	1	32-42-11 P036-00/ /	ALL
D10198		BACS16X1A RELAY SOCKET-P36	81205	1	32-42-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10100
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10200		BACS16X1A RELAY SOCKET-P36	81205	1	32-42-11 P036-00/ /	ALL
D10202		BACS16X1A RELAY SOCKET-P36	81205	1	32-42-11 P036-00/ /	ALL
D10204		BACC45FT12A12S PLUG-	81205	1	33-13-18 P008-00/ /	ALL
D10210		BACS16X1A RELAY SOCKET-	81205	1	26-15-12 P037-00/ /	ALL
D10216		BACC45FT20A41S PLUG-P5	81205	1	24-33-11 P005-00/ /	ALL
D10220		BACC45FT16A24S PLUG-P5	81205	1	30-11-11 P005-00/ /	050-099, 150-199
D10220		BACC45FT12A12S8 PLUG-P5	81205	1	30-11-11 P005-00/ /	275-299
D10220 U		289T0181-10402 M/W TAPE- TEXT AS BELOW	81205	1	30-11-11 / /	150-154
D10222		BACC45FT18A31S PLUG-P61	81205	1	26-18-11 P061-00/ /	ALL
D10224		BACC45FT16A24S8 PLUG-	81205	1	28-43-11 P061-00/ /	ALL
D10228		BACC45FS14-7S PLUG-	81205	1	32-35-11 0240/200/L040	ALL
D10230		BACS16X1A RELAY SOCKET-	81205	1	30-34-11 P033-00/ /	ALL
D10232		BACS16X1A RELAY SOCKET	81205	1	30-34-21 P033-00/ /	ALL
D10262		BACS16W1 RELAY SOCKET-P6-5	81205	1	80-11-11 P006-00/ /	ALL
D10264		BACS16W1 RELAY SOCKET-P6-5	81205	1	80-11-21 P006-00/ /	ALL
D10266		BACS16W1 RELAY SOCKET-P6-5	81205	1	80-11-11 P006-00/ /	ALL
D10268		BACS16W1 RELAY SOCKET-P6-5	81205	1	80-11-21 P006-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10270		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10272		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10274		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10276		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-21 P006-00/ /	ALL
D10278		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10280		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-21 P006-00/ /	ALL
D10282		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10284		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-21 P006-00/ /	ALL
D10286		BACS16W1 RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10288		BACS16W1 RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10290		BACS16W1 RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10292		BACS16W1 RELAY SOCKET-P6-5	81205	1	33-16-21 P006-00/ /	ALL
D10294		BACS16W1 RELAY SOCKET-P6-5	81205	1	33-16-21 P006-00/ /	ALL
D10296		BACS16W1 RELAY SOCKET-P6-5	81205	1	33-16-21 P006-00/ /	ALL
D10298		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-21 P006-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10200
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10300		BACS16X3A RELAY SOCKET-P6-5	81205	1	33-11-11 P006-00/ /	ALL
D10302		BACS16X3A RELAY SOCKET-P6-5	81205	1	33-11-11 P006-00/ /	ALL
D10306		10-60450-5 RELAY SOCKET-P6-5	81205	1	33-11-15 P006-00/ /	ALL
D10308		10-60450-5 RELAY SOCKET-P6-5	81205	1	33-11-15 P006-00/ /	ALL
D10310		10-60450-5 RELAY SOCKET-P6-5	81205	1	33-11-15 P006-00/ /	ALL
D10314		BACS16AH1 RELAY SOCKET-P36	81205	1	24-51-71 P036-00/ /	ALL
D10316		BACS16AH1 RELAY SOCKET-P36	81205	1	24-51-71 P036-00/ /	ALL
D10318		BACS16W1 RELAY SOCKET-	81205	1	24-51-71 P036-00/ /	ALL
D10320		BACS16AG1 RELAY SOCKET-P19	81205	1	52-51-11 P019-00/ /	050-099
D10320		BACS16AG1 RELAY SOCKET-	81205	1	52-51-11 P019-00/ /	150-199, 275-299
D10336		BACS16AG1 PLUG-	81205	1	32-61-14 SHELF/E01/02	ALL
D10338		BACS16AG1 PLUG-	81205	1	32-61-14 SHELF/E01/02	ALL
D10342		BACS16AF1 RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D10344		BACS16X1A RELAY SOCKET-	81205	1	75-23-11 P037-00/ /	ALL
D10346		BACS16X1A RELAY SOCKET-	81205	1	75-23-11 P036-00/ /	ALL
D10392		BACS16X1A RELAY SOCKET-P37	81205	1	80-11-11 P037-00/ /	ALL
D10394		BACS16X1A RELAY SOCKET-P37	81205	1	80-11-21 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10396		BACC45FT12A12S9 PLUG-P61	81205	1	33-13-21 P061-00/ /	ALL
D10398		BACC45FT12A12S PLUG-P61	81205	1	33-13-21 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10300
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10400		10-60450-5 RELAY SOCKET-	81205	1	33-13-17 0153/220/L008	ALL
D10402		BACS16X3A RELAY SOCKET-	81205	1	33-13-16 P005-00/ /	ALL
D10404		BACS16W3 RELAY SOCKET-P5	81205	1	33-13-16 P005-00/ /	ALL
D10406		BACS16X1A RELAY SOCKET-P6	81205	1	24-34-11 P006-00/ /	ALL
D10408		BACS16X1A RELAY SOCKET-P6	81205	1	24-34-11 P006-00/ /	ALL
D10410		BACS16X1A RELAY SOCKET-P6	81205	1	24-34-11 P006-00/ /	ALL
D10414		BACS16AG1 RELAY SOCKET-	81205	1	29-11-22 P033-00/ /	ALL
D10416		BACS16X1 RELAY SOCKET-	81205	1	21-58-16 P036-00/ /	ALL
D10418		BACS16W5 RELAY SOCKET-	81205	1	21-58-16 P036-00/ /	ALL
D10420		BACS16AG1 RELAY SOCKET-	81205	1	21-58-16 P036-00/ /	ALL
D10422		BACS16W1 RELAY SOCKET-	81205	1	21-58-16 P036-00/ /	ALL
D10424		BACC63BP10R5SNL PLUG-	81205	1	21-58-16 0325/188/0000	050-099
D10424		BACC63BP10R5SNL PLUG-	81205	1	21-58-16 0322/185/0000	150-199, 275-299
D10424 T		BACC10KE10 CLAMP-	81205	1	21-58-16 / /	ALL
D10430		BACS16W3 RELAY SOCKET-P01	81205	1	33-13-11 P001-00/ /	ALL
D10432		10-60450-5 RELAY SOCKET-P6-5	81205	1	33-11-13 P006-00/ /	ALL
D10434		BACC45FT10-5S6 PLUG-	81205	1	29-21-31 0212/195/R065	ALL

EQUIPMENT LIST

D280T132

Section D10400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10436		BACS16X1A RELAY SOCKET-	81205	1	29-11-32 P036-00/ /	ALL
D10454		BACS16X3A RELAY SOCKET-P37	81205	1	27-51-61 P037-00/ /	ALL
D10456		SO-1064-007 RELAY SOCKET-	35344	1	27-32-31 P036-00/ /	ALL
D10458		BACS16X1A RELAY SOCKET-	81205	1	27-32-31 P036-00/ /	ALL
D10460		BACS16W1 RELAY SOCKET-	81205	1	21-44-21 P033-00/ /	ALL
D10462		BACS16W1 RELAY SOCKET-	81205	1	21-58-16 P036-00/ /	ALL
D10468		BACS16X1A RELAY SOCKET-P19	81205	1	52-11-12 P019-00/ /	ALL
D10478		BACS16W1 RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D10492		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0883/280/L005	050-099
D10492		BACC45FN10A5S6 RECPT	81205	1	33-24-13 883/280/L 5	275-299
D10494		BACS16X1A RELAY SOCKET-	81205	1	21-44-21 P033-00/ /	ALL
D10498		BACS16AG1 RELAY SOCKET-	81205	1	73-21-11 P036-00/ /	275

EQUIPMENT LIST

D280T132

Section D10400
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10500		BACC45FT16-24S PLUG-	81205	1	25-65-11 0880/257/L085	050-099
D10500		BACC45FT16-24S PLUG-	81205	1	25-65-11 0915/270/L084	150-199, 275-299
D10502		BACC45FT16-24S PLUG-	81205	1	25-65-11 0880/257/R085	050-099
D10502		BACC45FT16-24S PLUG-	81205	1	25-65-11 0918/257/R085	150-199, 275-299
D10508		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10510		BACS16X1A RELAY SOCKET-P6-5	81205	1	33-16-11 P006-00/ /	ALL
D10512		BACS16AG1 RLY SKT	81205	1	32-61-14 SHELF/E01/02	ALL
D10514		BACS16AG1 RLY SKT	81205	1	32-61-14 SHELF/E01/02	ALL
D10520		SO-1066-10197 RELAY SOCKET-	35344	1	25-33-11 P037-00/ /	050-099
D10520		SO-1066-10197 RELAY SOCKET	81205	1	21-58-16 P037-00/ /	150-154, 275-276
D10526		BACS16AF1 RELAY SOCKET-	81205	1	36-11-51 P033-00/ /	ALL
D10528		BACS16AF1 RELAY SOCKET-P37	81205	1	36-11-52 P037-00/ /	ALL
D10548		BACC45FN8-2S RCPT-	81205	1	35-21-12 1495/280/L032	150-199
D10550		BACS16AF1 RELAY SOCKET-	81205	1	73-21-19 P036-00/ /	275-299
D10552		BACS16AF1 RELAY SOCKET-	81205	1	73-21-19 P037-00/ /	275-299
D10568		BACC45FT22A32S PLUG	81205	1	23-31-14 781/278/0	050-099
D10568		BACC45FT22A32S PLUG-	81205	1	33-26-11 654+76/280/0000	150-199

EQUIPMENT LIST

D280T132

Section D10500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10568		BACC45FT22A32S PLUG-	81205	1	33-26-11 852/280/0000	275-299
D10570		BACC45FT22A32S PLUG	81205	1	23-31-14 1056/278/R060	050-099
D10570		BACC45FT22A32S PLUG	81205	1	33-26-11 984/278/R060	150-199
D10572		BACS16X1A RELAY SOCKET-	81205	1	21-44-11 P049-00/ /	ALL
D10582		BACS16AF1 RELAY SOCKET-P37	81205	1	36-11-41 P37/ /	050-099
D10582		BACS16AF1 RLY SKT	81205	1	49-61-11 P37/ /	162-199, 275-299
D10586		35303-67 RCPT-STRUT	73168	1	26-18-11 L0394/14/FS	ALL
D10590		35303-67 RCPT-	73168	1	26-18-21 R0394/14/FS	ALL
D10592		BACS16AH1 RELAY SOCKET-	81205	1	25-53-15 P035-00/ /	ALL
D10594		BACS16AH1 RELAY SOCKET-	81205	1	25-53-15 P035-00/ /	ALL
D10596		BACS16AH1 RELAY SOCKET-	81205	1	25-53-15 P035-00/ /	ALL
D10598		BACS16AH1 RELAY SOCKET-	81205	1	25-53-15 P035-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10500
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10600		BACS16X1A RELAY SOCKET-	81205	1	25-53-15 P035-00/ /	ALL
D10602		BACS16AH1 RELAY SOCKET-	81205	1	25-53-16 P035-00/ /	ALL
D10604		BACS16AH1 RELAY SOCKET-	81205	1	25-53-16 P035-00/ /	ALL
D10606		BACS16AH1 RELAY SOCKET-	81205	1	25-53-16 P035-00/ /	ALL
D10608		BACS16X1A RELAY SOCKET-	81205	1	25-53-16 P035-00/ /	ALL
D10610		BACS16AH1 RELAY SOCKET-	81205	1	25-53-17 P035-00/ /	ALL
D10612		BACS16AH1 RELAY SOCKET-	81205	1	25-53-17 P035-00/ /	050-099
D10612		BACS16AH1 REALAY SOCKET-	81205	1	25-53-17 P035-00/ /	150-199, 275-299
D10614		BACS16AH1 RELAY SOCKET-	81205	1	25-53-17 P035-00/ /	ALL
D10616		BACS16AH1 RELAY SOCKET-	81205	1	25-53-17 P035-00/ /	ALL
D10620		BACS16AH1 RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	ALL
D10622		BACS16AH1 RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	ALL
D10624		BACS16AH1 RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	ALL
D10626		BACS16AH1 RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	ALL
D10628		BACS16X1A RELAY SOCKET-	81205	1	25-53-25 P039-00/ /	ALL
D10630		BACS16AH1 RELAY SOCKET-	81205	1	25-53-26 P039-00/ /	ALL
D10632		BACS16AH1 RELAY SOCKET-	81205	1	25-53-26 P039-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10634		BACS16AH1 RELAY SOCKET-	81205	1	25-53-26 P039-00/ /	ALL
D10636		BACS16X1A RELAY SOCKET-	81205	1	25-53-26 P039-00/ /	ALL
D10638		BACS16AH1 RELAY SOCKET-	81205	1	25-53-27 P039-00/ /	050-099, 150-199
D10640		BACS16AH1 RELAY SOCKET-	81205	1	25-53-27 P039-00/ /	050-099, 150-199
D10642		BACS16AH1 RELAY SOCKET-	81205	1	25-53-27 P039-00/ /	050-099, 150-199
D10646		BACC45FN8-2S RCPT-	81205	1	35-21-14 0883/280/L005	275-278
D10656		BACC45FT10A5S PLUG-PRESSURE SW.	81205	1	26-23-11 0674/168/R068	050-099
D10656		BACC45FT10D5S PLUG-PRESSURE SW.	81205	1	26-23-11 654+86/171/R066	150-199, 275-299
D10658		BACS16X3A RELAY SOCKET-P6	81205	1	33-13-18 P006-00/ /	ALL
D10664		BACS16W1 PLUG-P37	81205	1	26-23-12 P037-00/ /	150-199, 275-299
D10666		BACS16W1 PLUG-P37	81205	1	26-23-12 P037-00/ /	150-199, 275-299
D10668		SO-1055-8690 PLUG-P37	81205	1	26-23-12 P037-00/ /	150-199, 275-299
D10676		BACC45FT12A12S PLUG	81205	1	33-22-42 0821/284/R008	275-299
D10680		BACC45FT8A3S PLUG-FWD SQUIB	81205	1	26-23-12 684/147/R 69	050-099
D10680		BACC45FT8A3S PLUG-FWD SQUIB	81205	1	26-23-12 0654+30/151/R069	155-199, 275-299
D10682		BACC45FT10A5S PLUG-AFT SQUIB	81205	1	26-23-12 689/147/R 69	050-099
D10682		BACC45FT10A5S PLUG-AFT SQUIB	81205	1	26-23-12 0654+36/151/R069	155-199, 275-299

EQUIPMENT LIST

D280T132

Section D10600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10684		BACC45FS10A5S PLUG-PRESS SW	81205	1	26-23-12 694/152/R 70	050-099
D10684		BACC45FS10A5S PLUG-PRESS SW	81205	1	26-23-12 0654+31/165/R074	155-199, 275-299
D10686		SO-1064-007 RELAY SOCKET-P37	35344	1	21-61-41 P37/ /	ALL
D10688		SO-1064-007 RELAY SOCKET-P37	35344	1	21-61-41 P37/ /	ALL
D10690		BACS16W1 RELAY SOCKET-P37	81205	1	21-61-41 P37/ /	ALL

EQUIPMENT LIST

D280T132

Section D10600

Page 3 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10702		BACC63BP14R15SNL PLUG	81205	1	21-61-41 0823/123/L015	ALL
D10702 T		BACC10KD14 CLAMP	81205	1	21-61-41 / /	ALL
D10704		BACC63BP12R12SNL PLUG	81205	1	21-64-11 0823/123/L015	ALL
D10704 T		BACC10KD12 CLAMP	81205	1	21-64-11 / /	ALL
D10706		BACC45FT12A12S PLUG-P5	81205	1	21-61-41 P005-00/ /	ALL
D10708		C48-06R10-20S-102- PLUG-	13556	1	21-61-41 0770/305/R012	ALL
D10710		BACC45FT10-5S PLUG-	81205	1	21-61-41 MULTI/283/0000	050-099, 275-278
D10710		BACC45FT10-5S PLUG-	81205	1	21-61-41 1030/283/0000	150-199
D10710		BACC45FT10-5S PLUG-	81205	1	21-61-41 MULTI/293/0000	280-299
D10712		BACC45FT10-5S PLUG-	81205	1	21-61-41 0770/305/R012	ALL
D10714		BACC63BW12S-3S PLUG-	81205	1	21-65-11 0770/305/R012	ALL
D10716		BACC63CE12S-3S PLUG-	81205	1	21-65-11 MULTI/283/000	050-099, 275-278
D10716		BACC63CE12S-3S PLUG-	81205	1	21-65-11 1030/283/000	150-199
D10716		BACC63CE12S-3S PLUG-	81205	1	21-65-11 MULTI/293/000	280-299
D10718		BACC45FT16A24S PLUG-	81205	1	33-51-11 0284/204/L053	ALL
D10720		BACC45FT16A24S PLUG-	81205	1	33-51-11 0873/202/R096	ALL
D10722		BACC45FT16A24S PLUG-	81205	1	33-51-11 1540/204/R054	ALL

EQUIPMENT LIST

D280T132

Section D10700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10724		BACS16X3A RELAY SOCKET-P37	81205	1	21-26-11 P037-00/ /	ALL
D10732		BACC45FT16A24S8 PLUG-P61	81205	1	29-21-32 P061-00/ /	ALL
D10734		BACS16AF1 RELAY SOCKET-P19	81205	1	25-65-12 P019-00/ /	050-099
D10734		BACS16AF1 RELAY SOCKET-	81205	1	25-65-12 P019-00/ /	150-199, 275-299
D10736		BACS16AF1 RELAY SOCKET-P19	81205	1	25-65-12 P019-00/ /	050-099
D10736		BACS16AF1 RELAY SOCKET-	81205	1	25-65-12 P019-00/ /	150-199, 275-299
D10738		BACS16X1 RELAY SOCKET-	81205	1	21-45-21 P036-00/ /	ALL
D10740		BACC45FT10A5S PLUG-	81205	1	21-45-21 0362/288/L041	ALL
D10742		BACC45FT10A5S PLUG-		1	21-45-21 0362/288/R041	050-099, 150-199
D10744		BACC45FT22-19S PLUG-	81205	1	24-51-43 P006-00/ /	ALL
D10766		BACS16W3 RELAY SOCKET-	81205	1	33-21-31 P019-00/ /	050-099, 280-299
D10766		BACS16W3 RELAY SOCKET	81205	1	33-21-31 P019-00/ /	150-199, 275-278
D10786		BACS16X3 RELAY SOCKET-P65	81205	1	24-25-11 P065-00/ /	ALL
D10788		BACS16X3 RELAY SOCKET-P65	81205	1	24-25-11 P065-00/ /	ALL
D10790		SO-1064-003 RELAY SOCKET-P65	81205	1	24-25-11 P065-00/ /	ALL
D10792		BACS16X1A RELAY SOCKET-P65	81205	1	24-25-11 P065-00/ /	ALL
D10794		BACS16W2 RELAY SOCKET-P19	81205	1	33-21-21 P019-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D10700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10794		BACS16W2 RELAY SOCKET-	81205	1	33-21-21 P019-00/ /	150-199, 275-299
D10796		BACS16W3 RELAY SOCKET	81205	1	33-22-42 P025-00/ /	050-099
D10796		BACS16W3 RELAY SOCKET-	81205	1	33-22-42 P025-00/ /	150-199, 275-299
D10798		BACS16W2 RELAY SOCKET-	81205	1	33-51-11 P019-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D10700
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10832		BACS16AH1 RELAY SOCKET-P65	81205	1	24-25-11 P065-00/ /	ALL
D10834		BACC63BP16R10SNL RCPT	81205	1	24-25-12 1010/152/L010	ALL
D10834 T		710AS002C1609-62A ADAPTER	06324	1	24-25-12 / /	ALL
D10836		BACC45FS16-24S RELAY SOCKET-P65	81205	1	24-25-12 P065-00/ /	ALL
D10840		BACC63BV20R25PN RCPT	81205	1	24-25-12 0970/150/L010	ALL
D10840 T		710AS002C2016-62A ADAPTER	06324	1	24-25-12 / /	ALL
D10842		BACC63BV14A4PN RCPT-	81205	1	24-25-12 970/150/L10	ALL
D10842 T		710AS011M1412-62A ADAPTER	06324	1	24-25-12 970/150/L10	ALL
D10844		BACC63BP10S5SNL PLUG-	81205	1	24-25-12 0983/151/L008	ALL
D10844 T		710AA011M1009-62A ADAPTER	06324	1	24-25-12 / /	ALL
D10860		BACS16X3A RELAY SOCKET-	81205	1	33-13-16 P005-00/ /	ALL
D10862		BACS16X1 PLUG-P37	81205	1	26-23-12 P037-00/ /	050-099
D10864		BACC45FT10A5S PLUG-PRESS SW.	81205	1	26-23-12 0659/189/R067	050-099
D10864		BACC45FT10A5S PLUG-PRESS SW.	81205	1	26-23-12 654+59/166/R081	150-199, 275-299
D10866		BACC45FT10A5S PLUG-PRESS SW.	81205	1	26-23-12 0675/186/R080	050-099
D10866		BACC45FT10A5S PLUG-PRESS SW.	81205	1	26-23-12 654+81/165/R080	150-199, 275-299
D10872		BACS16AG1 RLY SKT-	81205	1	32-61-14 SHELF/E01/02	ALL

EQUIPMENT LIST

D280T132

Section D10800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10874		BACS16AG1 RLY SKT-	81205	1	32-61-14 SHELF/E01/02	ALL
D10876		BACS16W1A RELAY SOCKET	81205	1	78-34-11 P011/ /	050-099
D10876		BACS16W1A RELAY SOCKET	81205	1	78-34-21 P011/00/	150-199, 275-299
D10878		BACS16W1A RELAY SOCKET	81205	1	73-21-11 P011/00/	ALL
D10888		BACC45FT10-5S PLUG	81205	1	21-44-21 1510/170/L062	275-276
D10890		SO-1064-007 RELAY SOCKET-	35344	1	21-58-16 P036-00/ /	ALL
D10892		SO-1064-007 RELAY SOCKET-	35344	1	21-58-16 P037-00/ /	ALL
D10898		BACS16X2A RELAY SOCKET-P19	81205	1	33-26-21 P019-00/ /	050-099
D10898		BACS16X2 RELAY SOCKET-P19	81205	1	33-26-21 P019-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D10800
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10908		BACC45FT22A32S PLUG-	81205	1	33-26-11 0367/278/L058	275-299
D10922		BACC45FT12A12S PLUG-	81205	1	33-21-32 0440/280/L056	162-165, 167-199
D10922		BACC45FT12A12S PLUG-	81205	1	33-21-32 0440/295/L056	166
D10922 V		289T0183-10203 I.D.TAPE TEXT AS BELOW	81205	1	33-21-32 0440/280/L056	162-163
D10924		BACC45FN10-5P PLUG-F1 GALLEY	81205	1	25-31-11 0264/283/R055	275-278
D10924		BACC45FN10-5P PLUG-F1 GALLEY	81205	1	25-31-11 0260/280/R055	280-299
D10926		BACC45FM12-12S PLUG-F1	81205	1	25-31-11 0260/290/R60	050-099
D10926		BACC45FM12-12S PLUG-F1	81205	1	25-31-11 0260/279/R060	150-199
D10926		BACC45FT10-5S PLUG-F3 GALLEY	81205	1	25-31-11 0362/279/R054	275-278
D10926		BACC45FT10-5S PLUG-F3 GALLEY	81205	1	25-31-11 0362/280/R054	280-299
D10930		BACC63CD24-22S RCPT-F1	81205	1	25-31-11 0260/290/R060	050-099, 150-199
D10930		BACC45FN12-12P6 RCPT-F1	81208	1	25-31-11 261/281/R55	277-278
D10930		BACC45FN12-12P6 RCPT-F1 GALLEY	81205	1	25-31-11 260/280/R055	280-299
D10932		BACC63CE24-22P PLUG-F4	81205	1	25-31-11 0355/283/R055	050-099
D10932		BACC63CE24-22P PLUG-F4	81205	1	25-31-11 0360/279/R62	150-199
D10932		BACC45FT12-12S PLUG-F4 GALLEY	81205	1	25-31-11 360/243/0	277-299
D10940		BACC45FT10A5S PLUG	81205	1	33-22-32 435/275/L 60	050-099

EQUIPMENT LIST

D280T132

Section D10900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10940		BACC45FT10A5S PLUG	81205	1	33-22-31 435/275/L060	150-199
D10950		BACS16W1 RELAY SOCKET-	81205	1	78-36-11 P036-00/ /	ALL
D10958		BACS16W1 RELAY SOCKET	81205	1	75-32-21 P011-00-/ /	ALL
D10964		BACC63BP18B14S6L PLUG-ENG	81205	2	24-11-11 NL184/072/	ALL
D10964 T		BACC10KB18 CLAMP-	81205	2	24-11-11 / /	ALL
D10966		BACC63BP18B14SNL PLUG-ENG	81205	2	24-11-11 NL189/082/	ALL
D10966 T		BACC10KB18 CLAMP-	81205	2	24-11-11 / /	ALL
D10970		BACC63BP14A7SNL PLUG-	81205	2	80-11-11 NL192/072/	ALL
D10970 T		BACC10KE14 CLAMP-	81205	2	80-11-11 / /	ALL
D10974		BACC63BP14B7S7L PLUG-ENGINE	81205	2	79-35-11 NL153/082/	ALL
D10974 T		BACC10KA14 CLAMP-	81205	2	79-35-11 / /	ALL
D10976		FVA6E12S-3S08 PLUG-	71468	2	74-31-11 NR154/090/	ALL
D10978		FVA6E12S-3S08 PLUG-ENGINE	71468	2	74-31-11 NL156/088/	ALL
D10980		MT37K-1203S-714 PLUG-	81205	2	29-11-11 NR178/099/	ALL
D10980 T		BACC10KA12 CLAMP-	81205	2	29-11-11 / /	ALL
D10982		BACC63BP10B5S6L PLUG-	81205	2	79-32-11 NR156/114/	ALL
D10982 T		BACC10KA10 CLAMP	81205	2	79-32-11 NR156/ /	ALL

EQUIPMENT LIST

D280T132

Section D10900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D10984		BACC63BP18B14SNL PLUG-ENGINE	81205	2	36-11-61 NL158/097/	ALL
D10984 T		BACC10KB18 CLAMP-	81205	2	36-11-61 / /	ALL
D10988		BACC63BP14B7S8L PLUG-	81205	2	79-33-11 NL164/072/	ALL
D10988 T		BACC10KB14 CLAMP-	81205	2	79-33-11 / /	ALL
D10992		BACC63BP14B7S6L PLUG-ENG	81205	2	79-31-11 NL169/095/	ALL
D10992 T		BACC10KA14 CLAMP-	81205	2	79-31-11 / /	ALL
D10994		VMCG505M3-01 PLUG-ENG	81205	2	77-31-11 NR105/132/	ALL
D10996		FVF6E14S-7S01 PLUG-	71468	2	73-34-11 NR151/072/	ALL
D10998		BACC63BP10B5S6L PLUG	81205	2	73-33-11 NL160/050/	ALL
D10998 T		BACC10KA10 CLAMP-	81205	2	73-33-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D10900

Page 3 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11000		BACC63BP10B5SNL PLUG-ENGINE	81205	2	73-31-11 NL156/018/	ALL
D11000 T		BACC10KA10 CLAMP-	81205	2	73-31-11 / /	ALL
D11046		D38999-26KC98SN PLUG-ENG	81205	2	24-11-11 NL154/081/	ALL
D11046 T		G8801S13 CLAMP	81205	2	24-11-11 / /	ALL
D11078		BACS16X1A RELAY SOCKET-	81205	1	32-71-11 P036-00/ /	150-199, 275-299
D11080		BACC63BP14R7SNL PLUG- VALVE TAIL SKID	81205	1	32-71-11 1699/190/L050	150-199, 275-299
D11080 T		BACC10KD14 CLAMP-	81205	1	32-71-11 1699/190/L050	150-199, 275-299
D11082		BACS16X3A RLY SOCKET-	81205	1	33-21-12 P025-00/ /	050-099
D11082		BACS16X3A RELAY SOCKET-	81205	1	33-21-12 P025-00/ /	150-199, 275-299
D11084		BACS16X3A RLY SOCKET-	81205	1	33-21-12 P025-00/ /	050-099
D11084		BACS16X3A RELAY SOCKET-	81205	1	33-21-12 P025-00/ /	150-199, 275-299
D11092		BACC45FN14-12S RCPT-	81205	1	25-53-12 0654+77/122/L029	150-199, 275-299
D11094		BACC45FN14-12S RCPT-	81205	1	25-53-12 654+77/122/R029	150-199, 275-299
D11096		BACC45FN14-12S RCPT-	81205	1	25-53-12 0530/122/L029	150-199, 275-299
D11098		BACC45FN14-12S RCPT-	81205	1	25-53-12 654+33/122/R029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D11000
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11100		BACC45FN14-12S RCPT-	81205	1	25-53-22 1322/122/L029	150-199, 275-299
D11102		BACC45FN14-12S RCPT-	81205	1	25-53-22 1322/122/R029	150-199, 275-299
D11104		BACC45FN14-12S RCPT-	81205	1	25-53-22 1308/122/R008	150-199, 275-299
D11106		BACC45FN14-12S RCPT	81205	1	25-53-22 1350/122/L029	150-199, 275-299
D11108		BACC45FN14-12S RCPT-	81205	1	25-53-22 1350/122/R029	150-199, 275-299
D11110		BACC45FN14-12S RCPT-	81205	1	25-53-22 1384/122/L029	150-199, 275-299
D11112		BACC45FN14-12S RCPT-	81205	1	25-53-22 1384/122/R029	150-199, 275-299
D11114		D38999-26KG41PC PLUG-ENG	96906	2	73-21-11 NR119/132/	ALL
D11114 T		G8802S21 CLAMP-	96906	2	73-21-11 / /	050-099, 155-199, 277-299
D11114 T		G8801S21 CLAMP-	96906	2	73-21-11 / /	150-154, 275-276
D11116		BACC63BP14B7SNL PLUG(ENG)	71468	2	36-11-61 NR156/112/	ALL
D11116 T		BACC10KB14 CLAMP-	71468	2	36-11-11 / /	ALL
D11118		BACC45FN8-2S RCPT-	81205	1	35-21-14 0654+114/280/L005	275-299
D11120		BACC45FN8-2S RCPT-	81205	1	35-21-14 666/280/L005	275-299
D11122		BACC45FN8-2S RCPT-	81205	1	35-21-14 0697/280/L005	150-199
D11122		BACC45FN8-2S RCPT-	81205	1	35-21-14 694/280/L005	275-299
D11124		BACC45FN8-2S RCPT-	81205	1	35-21-14 0716/280/L005	150-199

EQUIPMENT LIST

D280T132

Section D11100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11124		BACC45FN8-2S RCPT-	81205	1	35-21-14 716/280/L005	275-299
D11126		BACC45FN8-2S RCPT-	81205	1	35-21-14 0748/280/L005	150-199
D11126		BACC45FN8-2S RCPT-	81205	1	35-21-14 744/280/L005	275-299
D11128		BACC45FN8-2S RCPT-	81205	1	35-21-14 1197+092/280/L005	150-199, 275-299
D11130		BACC45FN8-2S RCPT-	81205	1	35-21-14 1197+116/280/L005	150-199, 275-299
D11132		BACC45FN8-2S RCPT-	81205	1	35-21-14 1212/280/L005	150-199, 275-299
D11134		BACC45FN8-2S RCPT-	81205	1	35-21-14 1238/280/L005	150-199, 275-299
D11136		BACC45FN8-2S RCPT-	81205	1	35-21-14 1265/280/L005	150-199, 275-299
D11146		BACS16AH1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11148		BACS16AH1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11150		BACS16AH1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11158		BACC63BP10B5SNL PLUG	81205	1	36-11-61 L324/P25/FS	ALL
D11158 T		BACC10KA10 CLAMP	81205	1	36-11-61 L324/P25/FS	ALL
D11160		BACC45FT12A12S PLUG-	81205	1	33-21-11 0654+043/295/L056	150-199, 275-278
D11160		BACC45FT12A12S PLUG-	81205	1	33-21-11 0654+044/290/L056	280-299
D11162		BACC45FT12A12S PLUG-	81205	1	33-21-11 0654+050/290/L019	150-199, 275-278
D11164		BACC45FT12A12S PLUG-	81205	1	33-21-11 0654+117/295/L056	150-199, 275-278

EQUIPMENT LIST

D280T132

Section D11100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11164		BACC45FT12A12S PLUG-	81205	1	33-21-11 0654+120/289/L056	280-299
D11166		BACC45FT12A12S PLUG-	81205	1	33-21-11 700/290/L019	150-199
D11166		BACC45FT12A12S PLUG-	81205	1	33-21-11 0654+091/290/L019	275-278
D11166		BACC45FT12A12S PLUG-	81205	1	33-21-11 0654+091/295/L020	280-299
D11168		BACC45FT12A12S PLUG-	81205	1	33-21-11 0660/295/L056	150-199
D11168		BACC45FT12A12S PLUG-	81205	1	33-21-11 0745/289/L056	280-299
D11170		BACC45FT12A12S PLUG-	81205	1	33-21-11 700/290/L019	150-199
D11172		BACC45FT12A12S PLUG-	81205	1	33-21-32 0654+056/290/L056	150-165, 167-199, 275-278
D11172		BACC45FT12A12S PLUG-	81205	1	33-21-32 0654+056/295/L056	166
D11172		BACC45FT12A12S PLUG-	81205	1	33-21-32 0654+062/290/L056	280-299
D11174		BACC45FT10A5S PLUG-	81205	1	33-21-32 0654+088/250/L080	150-199, 275-278
D11174		BACC45FT10A5S PLUG-	81205	1	33-21-32 0654+071/266/L081	280-299
D11176		BACC45FT10A5S PLUG-	81205	1	33-21-32 0654+088/250/R080	150-199, 275-278
D11176		BACC45FT10A5S PLUG-	81205	1	33-21-32 0654+103/266/R081	280-299
D11178		BACC45FT10A5S PLUG-	81205	1	33-21-34 0894/266/L081	150-199, 275-278
D11178		BACC45FT10A5S PLUG-	81205	1	33-21-34 0900/266/L081	280-299
D11180		BACS16AH1 PLUG	81205	1	25-53-24 P039-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D11100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11182		BACS16AH1 PLUG	81205	1	25-53-24 P039-00/ /	150-199, 275-299
D11184		BACS16AH1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11186		BACS16AH1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11188		BACS16AH1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11190		BACS16AG1 PLUG	81205	1	25-53-24 P039-00/ /	150-199, 275-299
D11192		BACS16AG1 PLUG	81205	1	25-53-24 P039-00/ /	150-199, 275-299
D11194		BACS16AG1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11196		BACS16AG1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11198		BACS16W1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D11100
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11200		BACS16AG1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11202		BACS16AG1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11204		BACS16AG1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11206		BACS16AG1 PLUG	81205	1	25-53-23 P039-00/ /	150-199, 275-299
D11208		BACS16AH1 PLUG	81205	1	25-53-24 P039-00/ /	150-199, 275-299
D11212		BACC45FT12A12S PLUG-	81205	1	33-21-14 1197+021/290/L056	150-199, 275-299
D11214		BACC45FT12A12S PLUG-	81205	1	33-21-14 1197+027/290/L020	150-199, 275-299
D11216		BACC45FT12A12S PLUG-	81205	1	33-21-14 1197+110/290/L056	150-199, 275-299
D11218		BACC45FT12A12S PLUG-	81205	1	33-21-14 1197+115/290/L020	150-199
D11218		BACC45FT12A12S PLUG-	81205	1	33-21-14 1197+072/290/L020	275-299
D11220		BACC45FT12A12S PLUG-	81205	1	33-21-33 0654+056/288/R056	150-165, 167-199, 275-278
D11220		BACC45FT12A12S PLUG-	81205	1	33-21-33 0654+056/295/R056	166
D11220		BACC45FT12A12S PLUG-	81205	1	33-21-33 0654+059/289/R056	280-299
D11222		BACC45FT12A12S PLUG-	81205	1	33-21-33 0667/288/R056	275-278
D11222		BACC45FT12A12S PLUG-	81205	1	33-21-33 0680/291/R056	280-299
D11224		BACC45FT10A5S PLUG-	81205	1	33-21-33 0654+043/266/L081	150-199, 275-278
D11224		BACC45FT10A5S PLUG-	81205	1	33-21-33 0654+027/266/L081	280-299

EQUIPMENT LIST

D280T132

Section D11200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11226		BACC45FT10A5S PLUG-	81205	1	33-21-33 0654+043/266/R081	150-199, 275-278
D11226		BACC45FT10A5S PLUG-	81205	1	33-21-33 0654+059/266/R081	280-299
D11228		BACC45FT10A5S PLUG-	81205	1	33-21-33 0666/266/L081	275-278
D11228		BACC45FT10A5S PLUG-	81205	1	33-21-33 0658/266/L082	280-299
D11230		BACC45FT10A5S PLUG-	81205	1	33-21-33 0666/266/R081	275-278
D11230		BACC45FT10A5S PLUG-	81205	1	33-21-33 0670/266/R082	280-299
D11232		BACC45FT12A12S PLUG-	81205	1	33-21-34 1197+034/290/L056	150-165, 167-199, 275-299
D11232		BACC45FT12A12S PLUG-	81205	1	33-21-34 1197+034/295/L056	166
D11234		BACC45FT12A12S PLUG-	81205	1	33-21-34 1197+123/290/L056	150-165, 167-199, 275-299
D11234		BACC45FT12A12S PLUG-	81205	1	33-21-34 1197+123/295/L056	166
D11236		BACC45FT10A5S PLUG-	81205	1	33-21-34 1197+022/266/L081	150-199, 275-299
D11238		BACC45FT10A5S PLUG-	81205	1	33-21-34 1197+066/266/L081	150-199, 275-299
D11240		BACC45FT10A5S PLUG-	81205	1	33-21-34 1197+110/266/L081	150-199, 275-299
D11242		BACC45FT10A5S PLUG-	81205	1	33-21-35 0894/266/R081	150-199, 275-299
D11244		BACC45FT10A5S PLUG-	81205	1	33-21-35 1197+022/266/R081	150-199, 275-299
D11246		BACC45FT10A5S PLUG-	81205	1	33-21-35 1197+066/266/R081	150-199, 275-299
D11248		BACC45FT10A5S PLUG-	81205	1	33-21-35 1197+110/266/R081	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D11200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11250		BACC45FT12-12S PLUG-	81205	1	33-21-35 1197+034/288/R056	150-165, 167-199, 275-299
D11250		BACC45FT12-12S PLUG-	81205	1	33-21-35 1197+034/295/R056	166
D11252		BACC45FT12A12S PLUG-	81205	1	33-21-35 1197+122/288/R056	150-165, 167-199, 275-299
D11252		BACC45FT12A12S PLUG-	81205	1	33-21-35 1197+122/295/R056	166
D11254		BACC45FN8-2S RCPT-	81205	1	35-21-12 0771/270/L073	150-199, 275-278
D11254		BACC45FN8-2S RCPT-	81205	1	35-21-12 0772/270/L073	280-299
D11256		BACC45FN8-2S RCPT-	81205	1	35-21-12 1197+022/270/L073	150-199, 275-299
D11258		BACC45FN8-2S RCPT-	81205	1	35-21-12 1197+050/270/L073	150-199, 275-299
D11260		BACC45FN8-2S RCPT-	81205	1	35-21-12 1197+080/270/L073	150-199, 275-299
D11262		BACC45FN8-2S RCPT-	81205	1	35-21-12 1197+110/270/L073	150-199, 275-299
D11264		BACC45FN8-2S RCPT-	81205	1	35-21-13 0771/270/R073	150-199, 275-278
D11264		BACC45FN8-2S RCPT-	81205	1	35-21-13 0772/270/R073	280-299
D11266		BACC45FN8-2S RCPT-	81205	1	35-21-13 0654+014/270/R073	150-199, 275-278
D11266		BACC45FN8-2S RCPT-	81205	1	35-21-13 630/270/R073	280-299
D11268		BACC45FN8-2S RCPT-	81205	1	35-21-13 0654+044/270/R073	150-199, 275-278
D11268		BACC45FN8-2S RCPT-	81205	1	35-21-13 630/270/R073	280-299
D11270		BACC45FN8-2S RCPT-	81205	1	35-21-13 0654+087/270/R073	150-199

EQUIPMENT LIST

D280T132

Section D11200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11270		BACC45FN8-2S RCPT-	81205	1	35-21-13 0654+071/270/R073	275-299
D11272		BACC45FN8-2S RCPT-	81205	1	35-21-13 0654+099/270/R073	275-299
D11274		BACC45FN8-2S RCPT-	81205	1	35-21-13 1197+022/270/R073	150-199, 275-299
D11276		BACC45FN8-2S RCPT-	81205	1	35-21-13 1197+050/270/R073	150-199, 275-299
D11278		BACC45FN8-2S RCPT-	81205	1	35-21-13 1197+080/270/R073	150-199, 275-299
D11280		BACC45FN8-2S RCPT-	81205	1	35-21-13 1197+110/270/R073	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D11200
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11318		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+014/270/L075	150-199, 275-278
D11318		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+016/270/L073	280-299
D11320		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+044/270/L075	150-199, 275-278
D11320		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+045/270/L073	280-299
D11322		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+087/270/L075	150-199
D11322		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+071/270/L075	275-278
D11322		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+074/270/L073	280-299
D11324		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+099/270/L075	275-278
D11324		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+104/270/L073	280-299
D11352		CN0966A10S20SN-000 PLUG-STRUT	13556	1	71-51-12 AW0319/ /	050-099, 150-199
D11352		CN0966A10S20SN-000 PLUG-STRUT	81205	1	71-51-12 AW0319/ /	275-299
D11352 T		BACC10KA10 CLAMP	81205	1	71-51-12 / /	ALL
D11352 U		BACC47CP-2T CONTACT	81205	2	36-22-11 / /	ALL
D11354		BACC63BP14C7SNL PLUG L. STRUT	81205	1	78-34-11 N 151/157/	050-099, 150-199, 275-278
D11354 T		BACC10KE14 CLAMP	81205	1	71-51-12 / /	050-099, 150-199, 275-278
D11394		BACS16X1A RELAY SOCKET	35344	1	25-33-11 P037-00/ /	153-199

EQUIPMENT LIST

D280T132

Section D11300

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11402		BACC45FT12A12S PLUG-	81205	2	33-22-42 MULTI/288/038	162-199
D11420		BACC63BP12D3SNL PLUG-	81205	2	73-21-12 NR070/145/	ALL
D11420 T		BACC10KB12 CLAMP-	81205	2	73-21-12 / /	ALL
D11434		BACC63BP14D7SNL PLUG-	81205	2	30-34-11 NR070/145/	ALL
D11434 T		BACC10KB14 CLAMP-	81205	2	30-34-11 / /	ALL
D11436		CN0966A10S20SN-000 PLUG	13556	1	36-11-11 MULTI/ /	050-099, 150-199
D11436		CN0966A10S20SN-000 PLUG	81205	1	36-11-11 MULTI/ /	275-299
D11436 T		BACC10KA10 CLAMP	81205	1	71-51-12 / /	ALL
D11436 U		BACC47CP-2T CONTACT	81205	2	30-21-11 / /	ALL
D11438		BACC63BP14C7SNL PLUG R. STRUT	81205	1	78-34-21 N 151/157/	050-099, 150-166, 275-299
D11438 T		BACC10KE14 CLAMP	81205	1	71-51-12 / /	050-099, 150-166, 275-299
D11440		BACC63BP12C3SNL PLUG-EEC.OVERHEAT TEMP SW	81205	1	30-21-11 NR120/148/11	ALL
D11440 T		BACC10KE12 CLAMP	81205	1	30-21-11 NR120/148/11	ALL
D11442		BACC63BP12C3SNL PLUG EEC.OVERHEAT TEMP SW	81205	1	30-21-11 NR120/148/11	ALL
D11442 T		BACC10KE12 CLAMP	81205	1	30-21-11 NR120/148/11	ALL
D11444		BACS16AG1 RELAY SOCKET-	81205	1	27-09-13 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D11400
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11522		BACS16AG1 RELAY SOCKET-P37	81205	1	78-36-21 P037-00/ /	050-099
D11522		BACS16AG1 RELAY SOCKET-P37	81205	1	73-21-11 P037-00/ /	150-199, 275-299
D11536		D38999-26KA98SN PLUG-ENG	81205	2	24-11-11 NL184/072/	ALL
D11536 T		G8801S9 CLAMP	81205	2	24-11-11 / /	ALL
D11538		BACS16AG1 RELAY SOCKET-	81205	1	21-58-12 P036-00/ /	050-099
D11538		BACS16AG1 RELAY SOCKET	81205	1	21-58-12 P036-00/ /	150-199, 275-299
D11540		BACS16AG1 RELAY SOCKET-	81205	1	21-58-12 P036-00/ /	050-099
D11540		BACS16AG1 RELAY SOCKET	81205	1	21-58-12 P036-00/ /	150-199, 275-299
D11542		BACS16AG1 RELAY SOCKET-	81205	1	21-58-12 P036-00/ /	050-099
D11542		BACS16AG1 RELAY SOCKET	81205	1	21-58-12 P036-00/ /	150-199, 275-299
D11544		BACS16AG1 RELAY SOCKET-	81205	1	21-58-12 P036-00/ /	050-099
D11544		BACS16AG1 RELAY SOCKET	81205	1	21-58-12 P036-00/ /	150-199, 275-299
D11546		BACS16AG1 RELAY SOCKET-	81205	1	21-58-12 P036-00/ /	050-099
D11546		BACS16AG1 RELAY SOCKET	81205	1	21-58-12 P036-00/ /	150-199, 275-299
D11548		BACS16AG1 RELAY SOCKET-	81205	1	21-58-12 P036-00/ /	050-099
D11548		BACS16AG1 RELAY SOCKET	81205	1	21-58-12 P036-00/ /	150-199, 275-299
D11550		BACS16AG1 RELAY SOCKET-	81205	1	21-58-12 P036-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D11500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11550		BACS16AG1 RELAY SOCKET	81205	1	21-58-12 P036-00/ /	150-199, 275-299
D11553		M24308-2-4F PLUG-	96906	1	27-32-12 P51/ /	ALL
D11553 T		D110550 JACKSCREW	71468	2	27-32-12 P51/ /	ALL
D11578		BACC45FN14-12S RCPT-	81205	1	25-53-12 579/122/R036	150-199, 275-299
D11580		BACC45FN14-12S RCPT-	81205	1	25-53-12 0706/122/R029	150-199, 275-299
D11598		BACC45FN14-12S RCPT-	81205	1	25-53-12 0442/122/L029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D11500
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11616		BACS16AG1 PLUG-	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11620		BACS16AG1 RELAY SOCKET	81205	1	25-53-16 P035-00/ /	050-099
D11620		BACS16AG1 RCPT-	81205	1	25-53-16 P035-00/ /	150-199, 275-299
D11624		BACS16AF1 RELAY SOCKET	81205	1	25-53-16 P035-00/ /	050-099
D11624		BACS16AF1 RCPT-	81205	1	25-53-16 P035-00/ /	150-199, 275-299
D11626		BACS16AG1 RELAY SOCKET	81205	1	25-53-16 P035-00/ /	050-099
D11626		BACS16AG1 RCPT-	81205	1	25-53-16 P035-00/ /	150-199, 275-299
D11628		BACS16AF1 RELAY SOCKET	81205	1	25-53-16 P035-00/ /	050-099
D11628		BACS16AF1 RCPT-	81205	1	25-53-16 P035-00/ /	150-199, 275-299
D11629		BACS16AG1 RELAY SOCKET-P36	81208	1	28-22-12 P036-00/ /	ALL
D11630		BACS16AG1 RCPT	81205	1	MULTI P03500/ /	050-099
D11630		BACS16AF1 RCPT-	81205	1	MULTI P03500/ /	150-199, 275-299
D11631		BACS16AH1 RELAY SOCKET-P36	81205	1	28-22-12 P036-00/ /	ALL
D11632		BACS16AH1 RCPT	81205	1	MULTI P03500/ /	050-099
D11632		BACS16AH1 RCPT-	81205	1	MULTI P03500/ /	150-199, 275-299
D11638		BACC45FN14-12S RCPT-	81205	1	25-53-12 654+33/122/L029	150-199, 275-299
D11640		BACC45FN14-12S RCPT-	81205	1	25-53-12 0639/122/L029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D11600

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11654		BACS16AG1 RELAY SOCKET	81205	1	78-36-11 P036-00/ /	050-099
D11654		BACS16AG1 RLY SKT	81205	1	78-36-11 P036-00/ /	150-199
D11654		BACS16AG1 RELAY SOCKET	81205	1	78-36-11 P036-00/ /	275-299
D11660		BACS16AF1 RELAY SOCKET	81205	1	25-53-26 P039-00/ /	050-099
D11660		BACS16AF1 RCPT-	81205	1	25-53-26 P039-00/ /	150-199, 275-299
D11662		BACS16AG1 RELAY SOCKET	81205	1	25-53-26 P039-00/ /	050-099
D11662		BACS16AG1 RCPT-	81205	1	25-53-26 P039-00/ /	150-199, 275-299
D11664		BACS16AG1 RELAY SOCKET	81205	1	25-53-26 P039-00/ /	050-099
D11664		BACS16AG1 RCPT-	81205	1	25-53-26 P039-00/ /	150-199, 275-299
D11666		BACS16AG1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11668		BACS16AG1 RELAY SOCKET	81205	1	25-53-26 P039-00/ /	050-099
D11668		BACS16AG1 RCPT-	81205	1	25-53-26 P039-00/ /	150-199, 275-299
D11678		BACS16AG1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11680		BACS16AG1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11682		BACS16AG1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11684		BACS16AG1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11686		D38999-26KG41PN PLUG-	96906	2	73-21-11 NR119/132/	ALL

EQUIPMENT LIST

D280T132

Section D11600

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11686 T		G8801S21 CLAMP-	96906	2	73-21-11 / /	ALL
D11688		48-7191 RCPT-	02660	1	33-51-16 0401/203/R092	275-299
D11690		48-7190 PLUG-	02660	1	33-51-16 0401/203/R092	275-299
D11692		48-7191 RCPT-	02660	1	33-51-16 0877/202/R096	275-299
D11694		48-7190 PLUG-	02660	1	33-51-16 0877/202/R096	275-299
D11696		48-7191 RCPT-	02660	1	33-51-16 1010/202/R092	275-299
D11698		48-7190 PLUG-	02660	1	33-51-16 1010/202/R092	275-299

EQUIPMENT LIST

D280T132

Section D11600

Page 3 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11700		48-7191 RCPT-	02660	1	33-51-16 1406/202/R092	275-299
D11702		48-7190 PLUG-	02660	1	33-51-16 1406/202/R092	275-299
D11704		BACS16AH1 PLUG	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D11706		48-7191 RCPT-	02660	1	33-51-17 0445/203/L092	275-299
D11708		48-7190 PLUG-	02660	1	33-51-17 0445/203/L092	275-299
D11710		48-7191 RCPT-	02660	1	33-51-17 0988/203/L092	275-299
D11712		48-7190 PLUG-	02660	1	33-51-17 0988/203/L092	275-299
D11714		48-7191 RCPT-	02660	1	33-51-17 1362/203/L092	275-299
D11716		48-7190 PLUG-	02660	1	33-51-17 1362/203/L092	275-299
D11718		48-7191 RCPT-	02660	1	33-51-14 0290/205/L085	275-299
D11720		48-7190 PLUG-	02660	1	33-51-14 0290/205/L085	275-299
D11722		48-7191 RCPT-	02660	1	33-51-14 0290/205/R085	275-299
D11724		48-7190 PLUG-	02660	1	33-51-14 0290/205/R085	275-299
D11726		48-7191 RCPT-	02660	1	33-51-14 0857/211/L085	275-299
D11728		48-7190 PLUG-	02660	1	33-51-14 0857/211/L085	275-299
D11730		48-7191 RCPT-	02660	1	33-51-14 0857/211/R085	275-299
D11732		48-7190 PLUG-	02660	1	33-51-14 0857/211/R085	275-299

EQUIPMENT LIST

D280T132

Section D11700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11734		48-7191 RCPT-	02660	1	33-51-14 0901/211/L085	275-299
D11736		48-7190 PLUG-	02660	1	33-51-14 0901/211/L085	275-299
D11738		48-7191 RCPT-	02660	1	33-51-14 0901/211/R085	275-299
D11740		48-7190 PLUG-	02660	1	33-51-14 0901/211/R085	275-299
D11742		48-7191 RCPT-	02660	1	33-51-14 1537/205/L085	275-299
D11744		48-7190 PLUG-	02660	1	33-51-14 1537/205/L085	275-299
D11746		48-7191 RCPT-	02660	1	33-51-14 1537/205/R085	275-299
D11748		48-7190 PLUG-	02660	1	33-51-14 1537/205/R085	275-299
D11750		SO-1064-003 PLUG-P036	81205	1	73-21-11 P036-00/ /	ALL
D11752		SO-1064-003 PLUG-P36	81205	1	73-21-11 P036-00/ /	ALL
D11754		SO-1064-003 PLUG-P37	81205	1	73-21-11 P037-00/ /	ALL
D11756		SO-1064-003 PLUG-P37	81205	1	73-21-11 P037-00/ /	ALL
D11758		BACS16AG1 RELAY SOCKET	81205	1	22-32-13 P033-00/ /	ALL
D11760		BACC45FT12-12S PLUG-	81205	1	33-51-16 1406/200/R092	275-299
D11786		BACC66F11C41AA01 PLUG	81205	1	77-35-11 SHELF/E01/03	ALL
D11786A		PARTAOFD11786 PLUG-PART OF D11786		1	77-35-11 E01/03/	ALL
D11786B		PARTBOFD11786 PLUG-PART OF D11786		1	77-35-11 E01/03/	ALL

EQUIPMENT LIST

D280T132

Section D11700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11786C		PARTCOFD11786 PLUG-PART OF D11786		1	77-35-11 E01/03/	ALL
D11788		BACC66F11C41AA01 PLUG	81205	1	77-35-11 SHELF/E02/04	ALL
D11788A		PARTAOFD11788 PLUG-PART OF D11788		0	77-35-11 / /	ALL
D11788B		PARTBOFD11788 PART B OF D11788		0	77-35-11 / /	ALL
D11788C		PARTCOFD11788 PART C OF D11788		0	77-35-11 / /	ALL
D11792		BACS16AG1 RELAY SOCKET-	81205	1	24-11-11 P036-00/ /	050-099
D11792		BACS16AG1 RLY SKT	81205	1	24-11-11 P036-00/ /	150-199, 275-299
D11796		BACS16AF1 RELAY SOCKET-P37	81205	1	24-11-21 P037-00/ /	ALL
D11798		BACS16AF1 RELAY SOCKET	81205	1	32-09-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D11700
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11800		BACC45FT12A12S PLUG-P61	81205	1	73-21-11 P061-00/ /	ALL
D11802		BACC45FT12A12S6 PLUG-P61	81205	1	73-21-11 P061-00/ /	ALL
D11808		BACS16AG1 SKT-P36	81205	1	21-58-12 P036-00/ /	ALL
D11810		SO-1064-007 SOCKET-RELAY	35344	1	27-41-11 SHELF E0/1/01	050-099
D11810		SO-1064-007 SOCKET-RELAY	35344	1	27-41-11 SHELF/E01/01	150-199, 275-299
D11812		SO-1064-007 SOCKET-RELAY	35344	1	27-41-21 SHELF/E02/01	ALL
D11814		BACS16X3 RELAY SOCKET-P33	81205	1	30-71-21 P033-00/-/	050-099
D11814		BACS16X3 RELAY SOCKET-P33	81205	1	30-71-21 P033-00/ /	150-199, 275-299
D11822		BACC45FT12A12S PLUG	81205	1	23-32-11 1270/280/0	150-199
D11824		KC-59-585-M06 PLUG-COAXIAL	91836	1	23-32-13 1270/280/0	150-199
D11826		BACS16X1A SKT-P36	81205	1	30-21-11 P036-00/-/	050-099
D11826		BACS16X1A SKT-P36	812-5	1	30-21-11 P036-00/ /	150-199, 275-299
D11828		BACS16X1A SKT-P37	B81205	1	30-21-11 P037-00/ /	050-099
D11828		BACS16X1A SKT-P37	81205	1	30-21-11 P037-00/ /	150-199, 275-299
D11830		BACC45FN12D12S PLUG-T/R LEVER INTERLOCK-L	81205	1	78-36-11 154/192/L 03	050-099, 150-199
D11830		BACC45FN12D12S PLUG-T/R LEVER INTERLOCK-L	81205	1	78-36-11 154/192/L003	275-299
D11832		BACC45FN12D12S PLUG-T/R LEVER INTERLOCK-R	81205	1	78-36-21 154/192/R03	ALL

EQUIPMENT LIST

D280T132

Section D11800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11832 T		GTR21-12CD CLAMP	81205	1	78-36-21 154/192/R03	050-099, 150-199, 280-299
D11832 T		GTR21-12CD CLAMP	81205	1	78-36-21 / /	275-278
D11840		BACC45FT20A41S PLUG-A4 AFT GALLEY	81205	1	25-31-21 1507/280/L004	275-278
D11840		BACC45FT20C41S PLUG-A4 AFT GALLEY	81205	1	25-31-21 1504/280/L002	280-299
D11850		BACS16AG1 RELAY SOCKET	81205	1	25-53-16 P035-00/ /	050-099
D11850		BACS16AG1 RCPT-	81205	1	25-53-16 P035-00/ /	150-199, 275-299
D11852		BACS16AG1 RELAY SOCKET	81205	1	25-53-26 P039-00/ /	050-099
D11852		BACS16AG1 RCPT-	81205	1	25-53-26 P039-00/ /	150-199, 275-299
D11872		BACC45FT10A5S PLUG-	81205	1	33-22-31 370/280/0000	050-099
D11872		BACC45FT10A5S PLUG-	81205	1	33-22-31 0370/280/0000	150-199
D11882		BACS16AG1 RELAY SOCKET	03734	1	36-11-51 P036-00/ /	050-099, 275-276
D11882		BACS16AG1 RLY SKT	03734	1	36-11-51 P036-00/ /	150-156, 162-166
D11884		BACS16AG1 RELAY SOCKET	03734	1	36-11-51 P036-00/ /	050-099, 275-276
D11884		BACS16AG1 RLY SKT	03734	1	36-11-51 P036-00/ /	150-156, 162-166
D11886		BACS16AG1 RELAY SOCKET	03734	1	36-11-61 P036-00/ /	050-099, 150-156, 162-166, 275-276
D11888		BACS16AG1 RELAY SOCKET	03734	1	36-11-61 P036-00/ /	050-099
D11888		BACS16AG1 RELAY SOCKET	81205	1	36-11-61 P036-00/ /	150-156, 162-166, 275-276

EQUIPMENT LIST

D280T132

Section D11800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11890		BACS16AG1 RELAY SOCKET	03734	1	36-11-61 P036-00/ /	050-099, 150-156, 162-166, 275-276
D11892		BACS16AG1 RELAY SOCKET	03734	1	36-11-61 P036-00/ /	050-099, 150-156, 162-166, 275-276
D11894		451120-026 RELAY SOCKET	03734	1	36-11-52 P037-00/ /	050-099, 150-155, 162-165
D11894		451120-026 RELAY SOCKET	03734	1	36-11-52 P036-00/ /	156, 166, 275-276
D11896		451120-026 RELAY SOCKET	03734	1	36-11-52 P037-00/ /	050-099, 150-155, 162-165
D11896		451120-026 RELAY SOCKET	03734	1	36-11-52 P036-00/ /	156, 166, 275-276
D11898		451120-026 RELAY SOCKET	03734	1	36-11-62 P037-00/ /	050-099, 150-155, 162-165
D11898		451120-026 RELAY SOCKET	03734	1	36-11-62 P036-00/ /	156, 166, 275-276

EQUIPMENT LIST

D280T132

Section D11800

Page 3 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D11900		451120-026 RELAY SOCKET	03734	1	36-11-62 P037-00/ /	050-099, 150-155, 162-165
D11900		451120-026 RELAY SOCKET	03734	1	36-11-62 P036-00/ /	156, 166, 275-276
D11902		451120-026 RELAY SOCKET	03734	1	36-11-62 P037-00/ /	050-099, 150-155, 162-165
D11902		451120-026 RELAY SOCKET	03734	1	36-11-62 P036-00/ /	156, 166, 275-276
D11904		451120-026 RELAY SOCKET	03734	1	36-11-62 P037-00/ /	050-099, 150-155, 162-165
D11904		451120-026 RELAY SOCKET	03734	1	36-11-62 P036-00/ /	156, 166, 275-276
D11922		BACS16X2 RLY SOCKET	81205	1	33-21-21 P019-00/ /	050-099
D11922		BACS16X2 RELAY SOCKET-	81205	1	33-21-21 P019-00/ /	150-199, 280-299
D11930		BACS16X1 RELAY SOCKET	81205	1	38-32-11 P036-00/ /	050-099, 150-199, 277-299
D11932		BACS16X1 RELAY SOCKET - P49	81205	1	38-32-11 P049-00/ /	050-099, 150-155, 157-165, 277
D11962		BACS16AF1 RELAY SOCKET	81205	1	29-11-14 P033-00/ /	ALL
D11964		BACS16AF1 RELAY SOCKET	81205	1	29-11-14 P033-00/ /	ALL
D11966		BACC45FT10D5S PLUG-	81205	1	38-32-11 1549/185/L040	050-099, 150-199, 277-299
D11968		BACC45FT10D5S PLUG	81205	1	38-32-11 1570/185/L40	050-099, 150-199, 277-299

EQUIPMENT LIST

D280T132

Section D11900
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12002		BACS16X1 RELAY SOCKET	81205	1	30-11-11 P033-00/ /	ALL
D12004		BACS16X1 RELAY SOCKET	81205	1	30-11-11 P033-00/ /	ALL
D12020		BACC45FN12-12S6 RCPT-	81205	1	33-24-12 1451/270/L073	050-099, 150-199
D12022		BACC45FN12-12S6 RCPT-	81205	1	33-24-14 1451/270/R073	050-099, 150-199
D12024		BACC45FN8-2S RCPT-	81205	1	35-21-12 1510/285/L014	050-099
D12024		BACC45FN8-2S RCPT-	81205	1	35-21-12 1451/270/L073	150-199
D12026		BACC45FN8-2S RCPT-	81205	1	35-21-13 1473/285/R050	050-099
D12026		BACC45FN8-2S RCPT-	81205	1	35-21-13 1451/270/R073	150-199
D12034		BACC45FT22-55S PLUG	81205	1	33-21-21 447/250/L 55	050-099, 150-199
D12052		BACC63BP12A12SNL PLUG-	81205	1	21-64-11 0827/118/L015	ALL
D12052 T		BACC10KD12 CLAMP-	81205	1	21-64-11 / /	ALL
D12054		BACC63BP12A12SNL PLUG-	81205	1	21-64-11 0827/129/L015	ALL
D12054 T		BACC10KD12 CLAMP-	81205	1	21-64-11 / /	ALL
D12072		MB12P-1 PLUG	81205	1	33-51-17 349/201/L007	150-199
D12074		MB12P-1 PLUG	81205	1	33-51-17 349/201/L029	050-099, 150-199
D12076		MB12P-1 PLUG	81205	1	33-51-17 1487/201/L65	050-099, 150-199
D12078		MB12P-1 PLUG	81205	1	33-51-17 1484/201/L28	150-199

EQUIPMENT LIST

D280T132

Section D12000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12080		MB12P-1 PLUG	81205	1	33-51-16 1487/201/R057	050-099
D12080		MB12P-1 PLUG	81205	1	33-51-16 1487/201/R 57	150-199
D12082		MB12P-1 PLUG	81205	1	33-51-16 1521/201/R019	050-099
D12082		MB12P-1 PLUG	81205	1	33-51-16 1484/201/R 28	150-199
D12084		BACS16X3A RELAY SOCKET-	81205	1	33-22-42 P025-00/ /	275-299
D12086J		48-7191 RECPT	81205	1	33-22-21 654+120/283/0000	150-199
D12086P		48-7190 PLUG	81205	1	33-22-21 654+120/283/0000	151-152, 162-199
D12088J		48-7191 RECPT	81205	1	33-22-21 654+120/283/0000	151-152, 162-199
D12088P		48-7190 PLUG	81205	1	33-22-21 654+120/283/0000	150-199
D12090		48-7190 RCPT	81205	1	33-22-31 1480/270/L 55	050-099
D12090		48-7190 RECPT	81205	1	33-22-31 1480/270/L55	150-199
D12092		48-7190 PLUG	81205	1	33-22-31 1480/270/L 55	050-099
D12092		48-7191 RECPT	81205	1	33-22-31 1480/270/L55	150-199
D12098		BACC45FT20A41P PLUG-A2 GALLEY	81205	1	25-31-21 1561/282/L062	275-278
D12098		BACC45FT20C41P PLUG-A2 GALLEY	81205	1	25-31-21 1557/280/L050	280-299

EQUIPMENT LIST

D280T132

Section D12000
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12100		BACC45FT18B14P6 PLUG-A2 GALLEY	81205	1	25-31-21 1561/281/L062	275-278
D12100		BACC45FT18C14P PLUG-A2 GALLEY	81205	1	25-31-21 1555/280/L050	280-299
D12102		BACS16X1 RELAY SOCKET	81205	1	21-43-11 P036-00/ /	ALL
D12108		BACC45FT12A12S PLUG-	81205	1	33-27-11 1526/280/L006	275-299
D12110		BACC45FT12A12S PLUG-	81205	1	33-27-11 1526/280/R006	275-299
D12122		BACS16AF1 RELAY SOCKET	81205	1	30-21-11 P036-00/ /	050-099, 150-199
D12124		BACS16AF1 RELAY SOCKET	81205	1	30-21-11 P037-00/ /	050-099, 150-199
D12126		BACS16AG1 RELAY SOCKET	81205	1	30-21-11 P036-00/ /	050-099, 150-199
D12128		BACS16AG1 RELAY SOCKET	81205	1	30-21-11 P037-00/ /	050-099, 150-199
D12130		BACS16AG1 RELAY SOCKET	81205	1	30-21-11 P036-00/ /	050-099, 150-199
D12132		BACS16AG1 RLY SKT	81205	1	30-21-11 P037-00/PNL/	050-099, 150-199
D12134		BACS16AG1 RLY SKT	81205	1	30-21-11 P036-00/PNL/	050-099, 150-199
D12136		BACS16AG1 RLY SKT	81205	1	30-21-11 P037-00/PNL/	050-099, 150-199
D12138		BACC45FT12A12S PLUG	81205	1	30-81-11 208.5/167/L063	050-099
D12138		BACC45FT12A12S PLUG	81205	1	30-81-11 208/167/L063	150-199
D12138 V		289T0181-11501 I.D. SLEEVE TEXT AS BELOW	81205	1	30-81-11 / /	150-154
D12140		BACC45FT12A12S PLUG	81205	1	30-81-11 208/167/R 63	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D12100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12140 V		289T0181-11601 I.D. SLEEVE TEXT AS BELOW	81205	1	30-81-11 / /	150-154
D12142		BACS16AG1 RELAY SOCKET	81205	1	30-81-11 P033-00/ /	050-099, 150-199
D12142 V		-10501 I.D.TAPE - TEXT AS BELOW	81205	1	30-81-11 / /	150-154
D12144		BACS16AG1 RELAY SOCKET	81205	1	30-81-11 P033-00/ /	050-099, 150-199
D12144 V		-10601 I.D.TAPE - TEXT AS BELOW	81205	1	30-81-11 /-/	150-154
D12146		BACS16AG1 RELAY SOCKET	81205	1	30-81-11 P033-00/ /	050-099, 150-199
D12146 V		-10502 I.D.TAPE - TEXT AS BELOW	81205	1	30-81-11 / /	150-154
D12148		BACS16AG1 RELAY SOCKET	81205	1	30-81-11 P033-00/ /	050-099, 150-199
D12148 V		-10602 I.D.TAPE - TEXT AS BELOW	81205	1	30-81-11 /-/	150-154
D12150		BACS16AG1 RELAY SOCKET	81205	1	30-81-11 P033-00/ /	050-099, 150-199
D12150 V		-10503 I.D.TAPE - TEXT AS BELOW	81205	1	30-81-11 / /	150-154
D12152		BACS16AH1 RELAY SOCKET	81205	1	30-11-11 P033-00/ /	050-099, 150-199
D12152 V		-10504 I.D.TAPE - TEXT AS BELOW	81205	1	30-81-11 / /	150-154
D12154		BACS16AG1 RELAY SOCKET	81205	1	30-11-11 P033-00/ /	050-099, 150-199
D12154 V		-10505 I.D.TAPE - TEXT AS BELOW	81205	1	30-81-11 / /	150-154
D12156		BACS16W1A RELAY SOCKET	81205	1	28-31-21 P036-00/ /	050-099, 155-199, 276-299
D12156		BACS16W1A RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275

EQUIPMENT LIST

D280T132

Section D12100

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12158		BACS16W1A RELAY SOCKET-	81205	1	28-31-21 P037-00/ /	050-099, 155-199, 276-299
D12158		BACS16W1A RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275
D12160		BACS16W5 RELAY SOCKET	81205	1	28-31-11 P036-00/ /	050-099, 155-199, 276-299
D12160		BACS16W5 RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275
D12162		BACS16W5 RELAY SOCKET-	81205	1	28-31-11 P037-00/ /	050-099, 155-199, 276-299
D12162		BACS16W5 RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275
D12164		BACS16AG1 RELAY SOCKET	81205	1	28-31-12 P036-00/ /	050-099, 155-199, 276-299
D12164		BACS16AG1 RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275
D12166		BACS16AG1 RELAY SOCKET-	81205	1	28-31-12 P037-00/ /	050-099, 155-199, 276-299
D12166		BACS16AG1 RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275
D12172		BACC45FT12A12S8 PLUG-P5	81205	1	28-31-11 P005-00/ /	050-099, 155-199, 276-299
D12174		BACC45FT12A12S6 PLUG-P5	81205	1	28-31-11 P005-00/ /	050-099, 150-199, 276-299
D12176		BACC45FT12A12S9 PLUG-P5	81205	1	28-31-11 P005-00/ /	050-099, 155-199, 276-299
D12178		BACC45FT12A12S PLUG-P5	81205	1	28-31-11 P005-00/ /	050-099, 155-199, 276-299
D12180		BACC63BP14A7SNL PLUG-	81205	1	28-31-11 L0250/12/RS	050-099, 155-199, 276-299
D12180 T		BACC10KD14 CLAMP	81205	1	28-31-11 / /	050-099, 155-199, 276-299
D12182		BACC63BP14A7SNL PLUG-	81205	1	28-31-11 R0250/12/RS	050-099, 155-199, 276-299

EQUIPMENT LIST

D280T132

Section D12100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12182 T		BACC10KD14 CLAMP	81205	1	28-31-11 / /	050-099, 155-199, 276-299
D12184		BACC63BP14A7SNL PLUG-	81205	1	28-31-12 L0901/12/RS	050-099, 155-199, 276-299
D12184 T		BACC10KD14 CLAMP-	81205	1	28-31-12 / /	050-099, 155-199, 276-299
D12186		BACC63BP14A7SNL PLUG-	81205	1	28-31-12 R0901/12/RS	050-099, 155-199, 276-299
D12186 T		BACC10KD14 CLAMP-	81205	1	28-31-12 / /	050-099, 155-199, 276-299
D12188		BACC63BP18A8SNL PLUG-	81205	1	28-31-21 L0224/14/MS	155-157, 165-199, 277-299
D12188 T		BACC10KD18 CLAMP-	81205	1	28-31-21 / /	155-157, 165-199, 277-299
D12190		BACC63BP18A8SNL PLUG-	81205	1	28-31-21 R0224/14/MS	155-157, 165-199, 277-299
D12190 T		BACC10KD18 CLAMP-	81205	1	28-31-21 / /	155-157, 165-199, 277-299
D12192		BACC63BN10C5SN PLUG-	81205	1	28-42-13 L0257/14/RS	155-157, 165-199, 277-299
D12194		BACC63BN10C5SN PLUG-	81205	1	28-42-13 R0257/14/RS	155-157, 165-199, 277-299

EQUIPMENT LIST

D280T132

Section D12100
Page 4 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12206		BACC45FT12A12S7 PLUG-P5	81205	1	30-81-11 P061-00/ /	050-099
D12206		BACC45FT12A12S7 PLUG-P5	81205	1	30-81-11 P005-00/ /	150-199
D12206 U		289T0181-10302 M/W TAPE- TEXT AS BELOW	81205	1	30-81-11 / /	150-154
D12208		SO-1066-10197 RLY SKT	81205	1	21-61-81 P037-00/PNL/	050-099, 151-199, 275-299
D12210		BACC45FT18B14P PLUG-A2 GALLEY	81205	1	25-31-21 1550/281/L062	275-278
D12210		BACC45FT18C14P6 PLUG-A2 GALLEY	81205	1	25-31-21 1553/280/L050	280-299
D12212		BACC45FT18B14S PLUG-A4 AFT GALLEY	81205	1	25-31-21 1507/280/L004	275-278
D12212		BACC45FT18C14S6 PLUG-A4 AFT GALLEY	81205	1	25-31-21 1504/280/L006	280-299
D12214		BACC45FT10-5S PLUG	81205	1	38-32-11 1567/195/BL 0	156
D12214		BACC45FT10D5S PLUG	81205	1	38-32-11 1567/195/BL 0	157, 166-199, 277- 299
D12214		BACC45FT10D5S PLUG	81205	0	38-32-11 1567/195/00	275-276
D12216		BACC45FT10-5S PLUG	81205	1	38-32-11 1572/195/BL 0	156
D12216		BACC45FT10D5S PLUG	81205	1	38-32-11 1572/195/BL 0	157, 166-199, 277- 299
D12216		BACC45FT10D5S PLUG	81205	1	38-32-11 1572/195/00	275-276
D12218		BACS16X2 RLY SOCKET-	81205	1	33-21-31 P025-00/ /	050-099
D12218		BACS16X2 RELAY SOCKET	81205	1	33-21-31 P025-00/ /	162-199
D12220		BACS16X2 RLY SOCKET-	81205	1	33-21-31 P025-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D12200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12220		BACS16X2 RELAY SOCKET	81205	1	33-21-31 P025-00/ /	162-199
D12222		BACC45FN8-2S RCPT	81205	1	23-34-15 274/242/R 15	050-099, 162-199
D12224		BACC45FN8-2S RCPT	81205	1	35-21-14 274/278/R 15	050-099, 162-199
D12226		BACC45FT10D5S PLUG	81205	1	23-34-15 0252/274/R 10	050-099, 162-199
D12228		MB6P-6 PLUG		1	23-34-15 249/225/L 13	050-099, 162-199
D12230		MB6P-6 PLUG		1	23-34-15 249/225/L 12	050-099, 162-199
D12232		17-20090-1 PLUG	02660	1	23-34-15 0252/274/R 10	050-099, 162-199
D12232 T		17-542-02 LATCH RETAINER	02660	2	23-34-15 / /	050-099, 162-199
D12234		BACS16W5 RELAY SOCKET	81205	1	23-42-11 0250/274/L 10	050-099, 162-199
D12236		BACS16W5 RELAY SOCKET	81205	1	23-42-11 0250/276/L 10	050-099, 162-199
D12240		BACS16AF1 RLY SKT	81205	1	21-26-11 P037-00/PNL/	050-099, 155-199, 276-299
D12240		BACS16AF1 RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275
D12242		BACS16AG1 RLY SKT	81205	1	21-58-14 P037-00/PNL/	050-099, 155-199, 276-299
D12242		BACS16AG1 RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275
D12244		BACS16AF1 RLY SKT	81205	1	21-58-12 P036-00/PNL/	050-099, 155-199, 276-299
D12244		BACS16AF1 RELAY SOCKET	81205	1	28-31-22 P089-00/ /	150-154, 275
D12246		BACS16AG1 SKT	81205	1	73-21-18 P036-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D12200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12246		BACS16AG1 RLY SKT	81205	1	73-21-18 P036-00/ /	150-199, 275-299
D12248		BACS16AG1 RELAY SOCKET-	81205	1	73-21-11 P037-00/ /	050-099
D12248		BACS16AG1 RLY-SKT	81205	1	73-21-18 P037-0-0/ /	150-199, 275-299
D12250		SO-1064-003 SKT	81205	1	73-21-11 P036-00/ /	050-099
D12250		SO-1064-003 RLY SKT	81205	1	73-21-11 P036-00/ /	150-199, 275-299
D12252		SO-1064-003 RELAY SOCKET-	81205	1	73-21-11 P037-00/ /	050-099
D12252		SO-1064-003 RLY-SKT	58657	1	73-21-11 P037-0-0/ /	150-154
D12252		SO-1064-003 RLY-SKT	58657	1	73-21-11 P037-00/ /	155-199, 275-299
D12254		MB12P-1 PLUG	02660	1	33-51-16 0375/201/R044	050-099
D12256		MB12P-1 PLUG	81205	1	33-51-16 1521/201/L019	050-099
D12258		DAMA-15SWS SOCKET-		1	26-13-12 437/275/R055	050-099, 162-199
D12278		BACS16AG1 RELAY SOCKET-	81205	1	21-51-11 P036-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D12200

Page 3 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D12354		DAMA-15SWS SOCKET-		2	26-13-12 MULTI/275/55	050-099, 150, 152-199
D12354 T		DA19977-1 CLAMP		2	26-13-12 MULTI/275/55	150, 152-157
D12354 U		DA51220-1 RETAINER		2	26-13-12 MULTI/275/55	150, 152-157
D12372		BACC45FT12A12S PLUG-	81205	1	33-21-11 0736/289/L056	280-299
D12378		BACC45FT12A12S PLUG-	81205	1	33-21-32 0660/291/L056	280-299
D12380		BACC45FT12A12S PLUG-	81205	1	33-21-32 0654+49/266/L081	280-299
D12382		BACS16X1 RELAY SOCKET-	81205	1	38-32-11 P036-00/ /	275-276
D12392		BACS16X1 RELAY SOCKET - P49	81205	1	38-32-15 P049-00/ /	156, 166
D12392		BACS16X1 RELAY SOCKET - P49	81205	1	38-32-12 P049-00/ /	157, 167-199, 277-299
D12392		BACS16X1 RELAY SOCKET-P49	81205	1	38-32-14 P049-00/ /	275-276
D12392 U		289T0184-10101 I.D. TAPE - TEXT AS BELOW	81205	1	38-32-14 / /	275-276
D12394		BACS16X1 RELAY SOCKET - P49	81205	1	38-32-15 P049-00/ /	156, 166
D12394		BACS16X1 RELAY SOCKET - P49	81205	1	38-32-12 P049-00/ /	157, 167-199, 277-299
D12394		BACS16X1 RELAY SOCKET	81205	1	38-32-11 P036-00/ /	275-276

EQUIPMENT LIST

D280T132

Section D12300
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13021		BACS16W1 PLUG-P37	81205	1	32-09-12 P037-00/ /	050-099
D13021		BACS16W1 PLUG-P37	81205	1	26-23-12 P037-00/ /	150-199, 275-299
D13022		BACC63BP10B5SNL PLUG	81205	1	36-11-62 R324/P25/FS	ALL
D13022 T		BACC10KA10 CLAMP	81205	1	36-11-62 R324/P25/FS	ALL
D13040		BACS16X1 RELAY SOCKET	81205	1	78-36-11 P036-00/ /	050-099
D13040		BACS16X1 RLY SKT	81205	1	78-36-11 P036-00/ /	150-199, 275-299
D13042		BACS16X1 RELAY SOCKET	81205	1	78-36-21 P037-00/ /	050-099
D13042		BACS16X1 RLY SKT	81205	1	78-36-21 P037-00/ /	150-199, 275-299
D13048		BACS16AG1 RELAY SOCKET	81205	1	25-53-14 P035-00/ /	150-199, 275-299
D13050		BACS16AG1 RELAY SOCKET	81205	1	25-53-14 P035-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D13000

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13184		BACS16W1 RELAY SOCKET	81205	1	29-11-14 P033-00/ /	ALL
D13186		BACS16W5 RELAY SOCKET	81205	1	29-11-14 P033-00/ /	ALL
D13188		BACS16AH1 RELAY SOCKET	81205	1	29-11-14 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D13100
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13206		MB12R-6 RECPT	02660	1	33-51-17 0511/201/L092	050-099
D13206		MB12R-6 RECPT	02660	1	33-51-14 0489/203/L092	150-199
D13208		MB12R-6 RECPT	02660	1	33-51-14 0922/201/L092	050-099
D13208		MB12R-6 RECPT	02660	1	33-51-14 1032/201/L092	150-199
D13210		MB12R-6 RECPT	02660	1	33-51-14 1362/201/L092	050-099, 150-199
D13212		MB12P-1 PLUG-	02660	1	33-51-14 0901/211/L085	150-199
D13214		MB12P-1 PLUG-	02660	1	33-51-14 0901/211/R085	150-199
D13216		MB12P-1 PLUG	02660	1	33-51-14 0290/205/L085	050-099, 150-199
D13218		MB12P-1 PLUG	02660	1	33-51-14 0290/205/R085	050-099, 150-199
D13220		MB12P-1 PLUG-	02660	1	33-51-14 0857/211/L085	050-099, 150-199
D13222		MB12P-1 PLUG-	02660	1	33-51-14 0857/211/R085	050-099, 150-199
D13224		MB12P-1 PLUG-	02660	1	33-51-14 1537/203/L085	050-099, 150-199
D13226		MB12P-1 PLUG	81205	1	33-51-14 1537/203/L085	050-099
D13226		MB12P-1 PLUG-	02660	1	33-51-14 1537/203/R085	150-199
D13228		MB12P-1 PLUG	02660	1	33-51-16 0349/201/R092	050-099
D13228		MB12P-1 PLUG	02660	1	33-51-16 0533/201/R092	150-199
D13230		MB12P-1 PLUG	02660	1	33-51-16 1010/202/R092	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D13200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13232		MB12P-1 PLUG	02660	1	33-51-16 0643/201/R092	050-099, 150-199
D13234		MB12P-1 PLUG	02660	1	33-51-16 1208/201/R092	150-199
D13236		MB12P-1 PLUG-	02660	1	33-51-16 1384/200/R092	050-099, 150-199
D13238		MB12R-6 RECPT	81205	1	33-51-16 0533/201/R092	050-099, 150-199
D13240		MB12R-6 RECPT	81205	1	33-51-16 1010/203/R092	050-099, 150-199
D13242		MB12R-6 RECPT	81205	1	33-51-16 0687/201/R092	050-099
D13242		MB12R-6 RECPT	81205	1	33-51-16 0643/201/R092	150-199
D13244		MB12R-6 RECPT	02660	1	33-51-16 1384/201/R092	050-099, 150-199
D13246		MB12R-6 RECPT	02660	1	33-51-16 1208/201/R092	150-199
D13254		MB12R-6 PLUG-	02660	1	33-51-17 0731/201/L092	050-099
D13254		MB12R-6 PLUG-	02660	1	33-51-17 654+058/201/L092	150-199
D13256		MB12R-6 PLUG-	02660	1	33-51-17 1197+33/201/L092	150-199
D13258		MB12P-1 PLUG-	02660	1	33-51-17 0511/203/L092	050-099
D13258		MB12P-1 PLUG-	02660	1	33-51-17 0489/203/L092	150-199
D13260		MB12P-1 PLUG-	02660	1	33-51-17 0922/203/L092	050-099
D13260		MB12P-1 PLUG-	02660	1	33-51-17 1032/203/L092	150-199
D13262		MB12P-1 PLUG-	02660	1	33-51-17 1362/200/L092	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D13200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13264		MB12P-1 PLUG-	02660	1	33-51-17 0731/201/L092	050-099
D13264		MB12P-1 PLUG-	02660	1	33-51-17 654+58/201/L092	150-199
D13266		MB12P-1 PLUG-	02660	1	33-51-17 1197+033/201/L092	150-199
D13272		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0870/280/L005	150-199
D13278		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0893/280/L005	150-199
D13278		BACC45FN10A5S6 RECPT	81205	1	33-24-13 893/280/L 5	275-278

EQUIPMENT LIST

D280T132

Section D13200

Page 3 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13356		BACS16W4 RELAY SOCKET-	81205	1	33-21-11 P019-00/ /	050-099, 150-199
D13358		BACS16W4 RLY SOCKET	81205	1	33-22-41 P019-00/ /	050-099
D13358		BACS16W4 SOCKET-	81205	1	33-21-31 P019-00/ /	150-199
D13360		BACS16W4 RLY SOCKET	81205	1	33-21-31 P019-00/ /	050-099
D13360		BACS16W4 SOCKET-	81205	1	33-21-31 P019-00/ /	150-199
D13362		BACS16W4 RLY SOCKET	81205	1	33-21-31 P019-00/ /	050-099
D13362		BACS16W4 SOCKET-	81205	1	33-21-31 P019-00/ /	150-199
D13364		BACS16W4 RLY SOCKET-	81205	1	33-21-12 P025-00/ /	050-099
D13364		BACS16W4 SOCKET-	81205	1	33-21-12 P025-00/ /	150-199
D13366		BACC66F11C75AA01 PLUG PLATE ASSY-ARINC 600	81205	1	32-45-11 SHELF/E01/04	050-099, 150-199
D13366		BACC66F11C75AA01 PLUG PLATE ASSY-ARINC 600	81205	1	32-45-11 SHELF/E02/06	275-299
D13366A		PARTAOFD13366 PLUG-PART OF D13366		1	32-45-11 SHELF/E01/4	050-099, 150-199
D13366A		PARTAOFD13366 PLUG-PART OF D13366		0	32-45-11 SHELF-E2/06/	275-299
D13366B		PARTBOFD13366 PLUG-PART OF D13366		0	32-45-11 SHELF/E01/4	050-099, 150-199
D13366B		PARTBOFD13366 PLUG-PART OF D13366		0	32-45-11 SHELF-E2/06/	275-299
D13366C		PARTCOFD13366 PLUG-PART OF D13366		0	32-45-11 SHELF-E2/06/	275-299
D13368		BACS16W4 RLY SOCKET-	81205	1	33-21-12 P025-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D13300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13368		BACS16W4 SOCKET-	81205	1	33-21-12 P025-00/ /	150-199
D13370		BACS16X2 RELAY SOCKET-	81205	1	33-21-31 P019-00/ /	050-099
D13370		BACS16X2 SOCKET-	81205	1	33-21-31 P019-00/ /	150-199
D13372		BACS16X2 RELAY SOCKET-	81205	1	33-21-31 P019-00/ /	050-099
D13372		BACS16X2 SOCKET-	81205	1	33-21-31 P019-00/ /	150-199
D13374		BACC63BP10A5S6L PLUG	81205	1	32-45-12 R NOSE/WHL/10	050-099, 155-199, 275-299
D13374 T		BACC10KD10 CLAMP	81205	1	32-45-12 / /	050-099, 155-199, 275-299
D13376		BACC63BP10A5S6L PLUG	81205	1	32-45-12 L NOSE/WHL/09	050-099, 155-199, 275-299
D13376 T		BACC10KD10 CLAMP	81205	1	32-45-12 / /	050-099, 155-199, 275-299
D13378		BACC63BP10A5S6L PLUG	81205	1	32-45-14 R GEAR/WHL/08	050-099, 155-199, 275-299
D13378 T		BACC10KD10 CLAMP-	81205	1	32-45-14 R GEAR/WHL/08	050-099, 155-199, 275-299
D13378 U		G70259T77-35 LANYARD	B1205	1	32-45-14 R GEAR/WHL/08	050-099, 155-199, 275-299
D13380		BACC63BP10A5S6L PLUG	81205	1	32-45-14 R GEAR/WHL/07	050-099, 155-199, 275-299
D13380 T		BACC10KD10 CLAMP-	81205	1	32-45-14 R GEAR/WHL/07	050-099, 155-199, 275-299
D13380 U		G70259T77-35 LANYARD	B1205	1	32-45-14 R GEAR/WHL/07	050-099, 155-199, 275-299
D13382		BACC63BP10A5S6L PLUG	81205	1	32-45-13 L GEAR/WHL/06	050-099, 155-199, 275-299
D13382 T		BACC10KD10 CLAMP-	81205	1	32-45-13 L GEAR/WHL/06	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section D13300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13382 U		G70259T77-35 LANYARD	B1205	1	32-45-13 L GEAR/WHL/06	050-099, 155-199, 275-299
D13384		BACC63BP10A5S6L PLUG	81205	1	32-45-13 L GEAR/WHL/05	050-099, 155-199, 275-299
D13384 T		BACC10KD10 CLAMP-	81205	1	32-45-13 L GEAR/WHL/05	050-099, 155-199, 275-299
D13384 U		G70259T77-35 LANYARD	B1205	1	32-45-13 L GEAR/WHL/05	050-099, 155-199, 275-299
D13386		BACC63BP10A5S6L PLUG	81205	1	32-45-14 R GEAR/WHL/04	050-099, 155-199, 275-299
D13386 T		BACC10KD10 CLAMP-	81205	1	32-45-14 R GEAR/WHL/04	050-099, 155-199, 275-299
D13386 U		G70259T77-35 LANYARD	B1205	1	32-45-14 R GEAR/WHL/04	050-099, 155-199, 275-299
D13388		BACC63BP10A5S6L PLUG	81205	1	32-45-14 R GEAR/WHL/03	050-099, 155-199, 275-299
D13388 T		BACC10KD10 CLAMP-	81205	1	32-45-14 R GEAR/WHL/73	050-099, 155-199, 275-299
D13388 U		G70259T77-35 LANYARD	B1205	1	32-45-14 R GEAR/WHL/03	050-099, 155-199, 275-299
D13390		BACC63BP10A5S6L PLUG	81205	1	32-45-13 L GEAR/WHL/02	050-099, 155-199, 275-299
D13390 T		BACC10KD10 CLAMP-	81205	1	32-45-13 / /	050-099, 155-199, 275-299
D13390 U		G70259T77-35 LANYARD	B1205	1	32-45-13 L GEAR/WHL/02	050-099, 155-199, 275-299
D13392		BACC63BP10A5S6L PLUG	81205	1	32-45-13 L GEAR/WHL/01	050-099, 155-199, 275-299
D13392 T		BACC10KD10 CLAMP-	81205	1	32-45-13 / /	050-099, 155-199, 275-299
D13392 U		G70259T77-35 LANYARD	B1205	1	32-45-13 L GEAR/WHL/02	050-099, 155-199, 275-299
D13394		BACS16W4 RLY SOCKET	81205	1	33-22-42 P025-00/ /	050-099

EQUIPMENT LIST

D280T132

Section D13300

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13394		BACS16W4 RELAY SOCKET-	81205	1	33-22-42 P025-00/ /	150-199
D13396		BACS16AF1 RLY SKT	81205	1	32-09-11 P036-00/PNL/	050-099, 275-276
D13396		BACS16AF1 RLY SKT	81205	1	21-26-31 P036-00/ /	150-156, 162-166
D13396		BACS16AF1 RELAY SOCKET	81205	1	32-09-11 P036-00/ /	157, 167-199, 277-299

EQUIPMENT LIST

D280T132

Section D13300

Page 4 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13400		BACS16X1 RELAY SOCKET-P36	81205	1	21-61-51 P036-00/ /	050-099
D13400	1	BACS16X1 RLY SKT	81205	1	21-51-11 P036-00/ /	150-199, 275-299
D13402		BACS16W1 RLY SKT	81205	1	21-61-61 P036-00/ /	ALL
D13404		BACS16X1 RLY SKT	81205	1	21-61-61 P036-00/ /	ALL
D13406		BACS16AG1 RLY SKT	81205	1	21-61-61 P036-00/ /	ALL
D13408		BACS16W1 RLY SKT	81205	1	21-61-71 P036-00/PNL/	050-099
D13408		BACS16W1 RLY SKT	81205	1	21-61-71 P036-00/ /	150-199, 275-299
D13410		BACS16X1 RLY SKT	81205	1	21-61-71 P036-00/PNL/	050-099
D13410		BACS16X1 RLY SKT	81205	1	21-61-71 P036-00/ /	150-199, 275-299
D13412		BACS16AG1 RLY SKT	81205	1	21-61-71 P036-00/PNL/	050-099
D13412		BACS16AG1 RLY SKT	81205	1	21-61-71 P036-00/ /	150-199, 275-299
D13414		BACC45FT22A32S PLUG-	81205	1	23-31-14 1056/278/L050	050-099
D13414		BACC45FT22A32S PLUG-	81205	1	33-26-11 967/ /L050	150-199
D13416		BACC45FT22A32S PLUG	81205	1	33-26-11 0846/278/R028	150-199
D13418		BACS16AH1 SOCKET RELAY	81205	1	21-58-11 P036-00/ /	ALL
D13422		BACS16W1A RLY SKT	81205	1	21-26-31 P037-00/PNL/	050-099
D13422		BACS16W1A RLY SKT	81205	1	21-26-31 P037-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section D13400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13424		BACS16W1A RLY SKT	81205	1	21-26-31 P037-00/PNL/	050-099
D13424		BACS16W1A RLY SKT	81205	1	21-26-31 P037-00/ /	150-199, 275-299
D13426		BACS16X1A RLY SKT	81205	1	21-28-11 P037-00/PNL/	050-099
D13426		BACS16X1A RLY SKT	81205	1	21-28-11 P037-00/ /	150-199, 275-299
D13428		BACS16X1A RLY SKT	81205	1	21-28-11 P037-00/PNL/	050-099
D13428		BACS16X1A RLY SKT	81205	1	21-28-11 P037-00/ /	150-199, 275-299
D13430		BACS16X1A RLY SKT	81205	1	21-28-11 P037-00/PNL/	050-099
D13430		BACS16X1A RLY SKT	81205	1	21-28-11 P037-00/ /	150-199, 275-299
D13432		BACS16X1A RLY SKT	81205	1	21-28-11 P036-00/PNL/	050-099
D13432		BACS16X1A RLY SKT	81205	1	21-28-11 P036-00/ /	150-199, 275-299
D13438		BACS16X1 RLY SKT	81205	1	21-61-81 P037-00/PNL/	050-099
D13438		BACS16X1 RLY SKT	81205	1	21-61-81 P037-00/ /	150-199, 275-299
D13440		BACS16W1A RLY SKT	81205	1	21-61-81 P037-00/PNL/	050-099
D13440		BACS16W1A RLY SKT	81205	1	21-61-81 P037-00/ /	150-199, 275-299
D13442J		BACC45FN22-55S7 RECP	81205	1	33-24-12 AP0307/ /	050-099
D13442J		BACC45FN22-55S7 RECP	81205	1	33-22-31 AP0307/ /	150-199
D13442P		BACC45FT22-55P7 PLUG	81205	1	33-22-32 380/315/L8	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D13400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13444J		BACC45FN22-55P6 RECP	81205	1	33-21-21 AP0305/ /	050-099
D13444J		BACC45FN22-55P6 RECP	81205	1	33-21-21 AP0405/ /	150-199
D13444P		BACC45FT22-55S6 PLUG	81205	1	33-22-32 458/265/L70	050-099, 150-199
D13446		BACC45FS14-15S PLUG FWD CABIN GALLEY	81205	1	35-31-12 360/280/L60	050-099, 150-199
D13448		BACC63CE32-17S PLUG	81205	1	25-31-12 360/280/L 60	050-099, 150-199
D13450		BACC45FT16B24S RECP-P32	81205	1	25-31-12 P032-00/ /	050-099, 150-199
D13452		CA3108E14S-2SB-F80 PLUG	81205	1	25-29-12 1385/210/L90	050-099
D13452		CA3108E14S-2SB-F80 PLUG	81205	1	25-29-12 1413/210/L90	150-157
D13452		CA3108E14S-2SB-F80 PLUG	81205	1	25-29-12 1379/210/L90	162-199
D13452		CA3108E14S-2SB-F80 PLUG	81205	1	25-29-12 1410/210/L90	275-299
D13454		CA3108E14S-2SB-F80 PLUG	81205	1	25-29-12 509/210/L90	050-099
D13454		CA3108E14S-2SB-F80 PLUG	81205	1	25-29-12 484/210/L90	150-199
D13454		CA3108E14S-2SB-F80 PLUG	81205	1	25-29-12 395/210/L90	275-299
D13456		BACC63CE22-5P PLUG	81205	1	25-29-12 628/160/R 80	ALL
D13458		BACC63CE22-6S PLUG	81205	1	25-29-12 628/160/R 80	ALL
D13460		BACC66F11C43AA01 PLUG ARINC 600	91836	1	21-61-51 SHELF/E01/-05	ALL
D13460A		PARTAOFD13460 PLUG PART OF D13460	91836	1	21-61-51 / /	ALL

EQUIPMENT LIST

D280T132

Section D13400

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13460B		PARTBOFD13460 PLUG PART OF D13460	91836	1	21-61-51 / /	ALL
D13460C		PARTCOFD13460 PLUG PART OF D13460	91836	1	21-61-51 / /	ALL
D13462		BACC45FT10-5S PLUG	81205	1	21-61-61 MULTI/283/000	ALL
D13464		BACC45FT10-5S PLUG	81205	1	21-61-71 MULTI/305/0	050-099
D13464		BACC45FT10-5S PLUG-	81205	1	21-61-71 MULTI/305/0000	150-199, 275-299
D13466		C48-06R10-20S PLUG	13556	1	21-61-61 568/305/L010	050-099
D13466		C48-06R10-20S PLUG	13556	1	21-61-61 0568/305/L010	150-199, 275-278
D13466		C48-06R10-20S PLUG	13556	1	21-61-61 0568/305/L009	280-299
D13466 T		GTR21-10CD CLAMP-	06324	1	21-61-61 568/305/L010	050-099
D13468		C48-06R10-20S PLUG	13556	1	21-61-71 770/307/L 3	050-099
D13468		C48-06R10-20S PLUG	13556	1	21-61-71 0770/307/L003	150-155, 162-165, 275-276
D13468		C48-06R10-20S PLUG	13556	1	21-61-71 765/301/L003	156-157, 166-199, 277-278
D13468		C48-06R10-20S PLUG	13556	1	21-61-71 767/300/L003	280-299
D13468 T		GTR21-10CD BACKSHELL	06324	1	21-61-71 0770/307/L003	050-099
D13468 T		GTR21-10CD BACKSHELL	06324	1	21-61-71 770/307/L003	153-199, 275-299
D13470		BACC45FT10-5S PLUG	81205	1	21-61-61 568/305/L 10	050-099
D13470		BACC45FT10-5S PLUG	13556	1	21-61-61 0568/305/L010	150-199, 275-278

EQUIPMENT LIST

D280T132

Section D13400

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13470		BACC45FT10-5S PLUG	13556	1	21-61-61 0568/305/L012	280-299
D13472		BACC45FT10D5S PLUG	81205	1	21-61-71 770/307/L 3	050-099
D13472		BACC45FT10-5S PLUG	13556	1	21-24-11 0770/307/L003	150-152
D13472		BACC45FT10D5S PLUG	13556	1	21-24-11 0770/307/L003	153-155, 162-165
D13472		BACC45FT10-5S PLUG	13556	1	21-24-11 767/301/L004	156-157, 166-199
D13472		BACC45FT10D5S PLUG	13556	1	21-61-71 0770/307/L003	275-276
D13472		BACC45FT10-5S PLUG	13556	1	21-61-71 767/301/L004	277-278
D13472		BACC45FT10-5S PLUG	13556	1	21-61-71 765/298/L002	280-299
D13474		BACC63CE12S-3S PLUG	81205	1	21-65-11 0568/305/L010	050-099, 150-199, 275-278
D13474		BACC63CE12S-3S PLUG	81205	1	21-65-11 0568/305/L009	280-299
D13476		BACC63BW12SB3S PLUG	81205	1	21-65-11 0770/307/L003	050-099
D13476		BACC63BW12S-3S PLUG	81205	1	21-65-11 764/294/L 15	150-152
D13476		BACC63BW12SB3S PLUG	81205	1	21-65-11 764/294/L 15	153-155, 162-165, 275-276
D13476		BACC63BW12S-3S PLUG	81205	1	21-65-11 767/301/L003	156-157, 166-199, 277-278
D13476		BACC63BW12S-3S PLUG	81205	1	21-65-11 767/300/L003	280-299
D13478		BACC45FT16A24S PLUG-	81205	1	26-13-11 0320/280/L060	050-099
D13478		BACC45FT16A24S PLUG-	81205	1	26-13-11 0287/280/L090	150-199

EQUIPMENT LIST

D280T132

Section D13400

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13480		BACC45FT12A12S PLUG-	81205	1	26-13-11 839/278/L060	050-099
D13480		BACC45FT12A12S PLUG	81205	1	25-42-11 654+121/ /	150-199
D13482		BACC45FT12A12S PLUG	81205	1	25-42-11 781/278/BL00	050-099
D13482		BACC45FT12A12S PLUG	81205	1	25-42-11 654+76/ /BL00	150-199
D13484		BACC45FT12A12S PLUG	81205	1	33-26-21 839/278/R060	050-099
D13484		BACC45FT12A12S PLUG	81205	1	33-26-21 654+121/280/R050	150-199
D13484		BACC45FT12C12S PLUG-	81205	1	SPARE 654+26/280/R064	280-299
D13486		BACC45FT12A12S PLUG-	81205	1	26-13-11 1056/278/L060	050-099
D13486		BACC45FT12A12S PLUG	81205	1	33-26-21 967/280/L050	150-199
D13488		BACC45FT12A12S PLUG	81205	1	25-42-11 970/ /	150-199
D13490		BACC45FT12A12S PLUG	81205	1	26-13-11 1056/278/R060	050-099
D13490		BACC45FT12A12S PLUG	81205	1	25-42-11 967/280/R050	150-199
D13492		BACC45FT12A12S PLUG-	81205	1	33-26-21 1463/280/L060	150-157
D13494		BACC45FT12A12S PLUG-	81205	1	33-26-21 1463/280/R060	150-157
D13496		BACC45FN12-12S6 RCPT-	81205	1	33-24-13 0843/280/L005	150-199

EQUIPMENT LIST

D280T132

Section D13400

Page 6 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13510		MB12P-1 PLUG	02660	1	33-51-16 0426/201/R044	150-199
D13512		MB12P-1 PLUG	02660	1	33-51-16 0351/201/R044	050-099
D13512		MB12P-1 PLUG	02660	1	33-51-16 0375/201/R044	150-199
D13514		MB12P-1 PLUG	02660	1	33-51-16 0342/201/R057	050-099
D13514		MB12P-1 PLUG	02660	1	33-51-16 0351/201/R044	150-199
D13516		MB12P-1 PLUG	02660	1	33-51-16 0349/201/R029	050-099
D13516		MB12P-1 PLUG	02660	1	33-51-16 0342/201/R050	150-199
D13518		MB12P-1 PLUG	02660	1	33-51-16 0349/201/R022	050-099
D13518		MB12P-1 PLUG	02660	1	33-51-16 0349/201/R029	150-199
D13520		MB12P-1 PLUG-	02660	1	33-51-17 415/188/L-40	150-199
D13522		MB12P-1 PLUG-	02660	1	33-51-17 0375/188/L044	050-099
D13522		MB12P-1 PLUG-	02660	1	33-51-17 360/188/L-20	150-199
D13524		MB12P-1 PLUG-	02660	1	33-51-17 0351/188/L010	050-099
D13524		MB12P-1 PLUG-	02660	1	33-51-17 344/188/L-10	150-199
D13526		MB12P-1 PLUG-	02660	1	33-51-17 342/188/L-57	050-099, 150-199
D13528		MB12P20 PLUG	09922	1	33-22-31 450/240/L 55	150-199
D13530		BACS16X1 RLY SKT	81205	1	32-45-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D13500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13532		BACS16AF1 RLY SKT	81205	1	73-21-18 P037-00/PNL/	050-099
D13532		BACS16AF1 RLY SKT	81205	1	73-21-18 P037-00/ /	150-199, 275-299
D13536		BACC45FN8-2S RCPT-	81205	1	35-21-13 1028/270/L073	150-199
D13538		BACC45FN8-2S RCPT-	81205	1	35-21-13 1055/270/L073	150-199
D13540		BACC45FN8-2S RCPT-	81205	1	35-21-13 1028/270/R073	150-199
D13542		BACC45FN8-2S RCPT-	81205	1	35-21-13 1055/270/R073	150-199
D13548		BACC45FN8-2S RCPT-	81205	1	35-21-14 AP0901/ /	150-199
D13550		BACC45FN8-2S RCPT-	81205	1	35-21-14 1001/280/L005	150-199
D13552		BACC45FN16-24P RCPT	81205	1	26-13-12 1559/282/L062	050-099
D13552		BACC45FN16-24P RECT	81205	1	26-13-11 1559/282/L062	150-154
D13552		BACC45FN16-24S RECT	81205	1	26-13-11 1559/282/L062	155-199
D13553		BACC45FT12A12S PLUG-	81205	1	33-27-11 382/284/R 38	050-099, 150-199
D13554		BACC45FT12A12S PLUG-	81205	1	33-27-11 382/284/R 42	050-099, 150-199
D13555		BACC45FT12A12S PLUG-	81205	1	33-27-11 382/284/L042	050-099, 150-199
D13556		BACC45FT12A12S PLUG-	81205	1	33-27-11 382/284/L038	050-099, 150-199
D13558		BACC45FT14A7S PLUG	81205	1	33-22-42 P025-00/ /	050-099
D13558		BACC45FT14A7S PLUG-	81205	1	33-22-42 P025-00/ /	150-199

EQUIPMENT LIST

D280T132

Section D13500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13560		BACC66H21C33AA01 PLUG ARINC 600	91836	1	21-26-31 SHELF/E01/-05	ALL
D13560A		PARTAOFD13560 PLUG PART OF D13560	91836	1	21-26-31 / /	ALL
D13560B		PARTBOFD13560 PLUG PART OF D13560	91836	1	21-26-31 / /	ALL
D13560C		PARTC0FD13560 PLUG PART OF D13560	91836	1	21-26-31 / /	ALL
D13562		BACC45FT12C12S6 PLUG	81205	1	21-28-11 752/145/L 62	ALL
D13564		BACC45FT12C12S6 PLUG	81205	1	21-28-11 395/117/L 25	ALL
D13566		BACC45FT12C12S6 PLUG	81205	1	21-26-31 689/117/L 5	050-099
D13566		BACC45FT12C12S6 RECP	81205	1	21-26-31 654+28/117/L 5	150-199
D13566		BACC45FT12B12S6 PLUG	81205	1	21-26-31 654+28/117/L 5	275-299
D13568		BACC45FT12C12S6 PLUG	81205	1	21-26-31 689/117/0	050-099
D13568		BACC45FT12C12S6 RECP	81205	1	21-26-31 654+28/117/0	150-199
D13568		BACC45FT12B12S6 PLUG	81205	1	21-26-31 654+28/117/0	275-299
D13570		BACC63BP14R15SNL PLUG-	81205	1	21-61-81 786/123/L020	050-099
D13570		BACC63BP14R15SNL PLUG	81205	1	21-61-81 786/123/L 20	150-199, 275-299
D13570 T		BACC10KD14 CLAMP-	81205	1	21-61-81 / /	ALL
D13572		BACC45FT12A12S PLUG-P5	81205	1	21-26-31 P005-00/ /	ALL
D13574		BACC45FT18-31S PLUG	81205	1	21-26-31 693/188/L 84	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D13500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13574		BACC45FT18B31S PLUG	81205	1	21-26-31 693/188/L 84	275-299
D13576		BACC45FT14-7S PLUG	81205	1	21-26-31 689/117/R 5	050-099
D13576		BACC45FT14-7S PLUG	81205	1	21-26-31 654+28/117/R 5	150-199
D13576		BACC45FT14B7S PLUG	81205	1	21-26-31 654+28/117/R 5	275-299
D13578		BACS16AF1 RLY SKT	81205	1	73-21-18 P036-00/PNL/	050-099
D13578		BACS16AF1 RLY SKT	81205	1	73-21-18 P036-00/ /	150-199, 275-299
D13580		BACC63BP14A15SNL PLUG	81205	1	21-61-61 829/120/L 15	ALL
D13580 T		BACC10KD14 CLAMP-	81205	1	21-61-61 / /	ALL
D13582		BACC63BP14A15SNL PLUG	81205	1	21-61-71 829/120/L 15	ALL
D13582 T		BACC10KD14 CLAMP-	81205	1	21-61-71 / /	ALL
D13584	9	BACC45FT12-12S7 PLUG-P5 (SB 21-0083)	81205	1	21-61-81 P005-00/ /	050-099, 150-154, 162-165, 275-276
D13584		BACC45FT12-12S7 PLUG-P5	81205	1	21-61-81 P005-00/ /	155-156, 166
D13584		BACC45FT12A12S7 PLUG-P5	81205	1	21-61-81 P005-00/ /	157, 167-199, 277- 299
D13586		BACC45FT10-5S PLUG	81205	1	21-61-81 590/127/L60	ALL
D13592		C48-06R10-20S PLUG	13556	1	21-61-81 731/163/L075	ALL
D13594		BACC45FS10A5S6 PLUG	81205	1	21-43-11 590/127/L60	ALL
D13596		BACC45FT10-5S PLUG	81205	1	21-43-11 734/163/L 75	ALL

EQUIPMENT LIST

D280T132

Section D13500

Page 4 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13602		BACC63BW12SC3S PLUG	81205	1	21-43-12 590/127/L60	050-099, 150-199, 275-278
D13602		BACC63CE12SA3S PLUG	81205	1	21-43-12 590/127/L60	280-299
D13608		BACC45FN8-2S RCPT-	81205	1	35-21-14 0654+069/280/L005	150-199
D13626		BACS16X1 RELAY SOCKET-	81205	1	73-21-11 P037-00/ /	050-099
D13626		BACS16X1 RLY-SKT	81205	1	73-21-11 P037-0-0/ /	150-154
D13626		BACS16X1 RLY-SKT	81205	1	73-21-11 P037-00/ /	155-199, 275-299
D13628		BACS16X1 SKT	81205	1	73-21-11 P036-00/ /	050-099
D13628		BACS16X1 RLY SKT	81205	1	73-21-11 P036-00/ /	150-199, 275-299
D13634		BACC45FN8-2S RCPT-	81205	1	35-21-12 0654+118/270/L075	150-199
D13648		BACC45FN8-2S RCPT-	81205	1	35-21-13 676/289/R068	150-199

EQUIPMENT LIST

D280T132

Section D13600
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13702		BACC45FT10-5S PLUG-	81205	1	33-22-31 347/260/L055	275-299

EQUIPMENT LIST

D280T132

Section D13700

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13804		BACS16X1 RLY SKT	81205	1	21-45-22 P036-00/PNL/	ALL
D13804 U		-10309 I.D.TAPE TEXT AS BELOW	81205	1	21-45-22 P036-00/PNL/	150-154
D13806		BACS16W1 RLY SKT	81205	1	21-26-31 P037-00/PNL/	ALL
D13824		BACS16W1A RLY-FUEL POSITION,LEFT	81205	1	76-11-11 P036-00/ /	ALL
D13824 U		289T0120-10201 M/W TAPE- TEXT AS BELOW	81205	1	76-11-11 / /	050-099, 150-154, 275-276
D13826		BACS16W1A RLY-FUEL POSITION,RIGHT	81205	1	76-11-11 P037-00/ /	050-099, 150-154, 275-276
D13826		BACS16W1A RLY-FUEL POSITION, RIGHT	81205	1	76-11-11 P037-00/ /	155-199, 277-299
D13826 U		289T0120-10401 M/W TAPE- TEXT AS BELOW	81205	1	76-11-11 / /	050-099
D13826 U		289T0120-10601 M/W TAPE- TEXT AS BELOW	81205	1	76-11-11 / /	150-154, 275-276
D13832		BACC45FN12-12S RECP-	81205	1	33-27-11 410/288/R040	162-199
D13834		BACC45FN12-12S RECP-	81205	1	33-27-11 410/288/L040	162-199
D13836		BACC45FT8-2S PLUG	81205	1	33-27-11 447/278/0000	162-199
D13840		BACS16X1 RELAY SOCKET-P36	81205	1	21-66-11 P36/ /	050-099
D13840		BACS16X1 RELAY SOCKET-P36	81205	1	21-66-11 P036-00/ /	162-199
D13842		BACS16X1 RELAY SOCKET-P36	81205	1	21-66-11 P36/ /	050-099
D13842		BACS16X1 RELAY SOCKET-P36	81205	1	21-66-11 P036-00/ /	162-199
D13844		BACS16W5 RELAY SOCKET-P36	81205	1	21-66-11 P36/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section D13800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13846		BACS16W1 RELAY SOCKET-P36	81205	1	21-66-11 P36/ /	050-099
D13846		BACS16W1 RELAY SOCKET-P36	81205	1	21-66-11 P036-00/ /	162-199
D13848		BACS16X1 RELAY SOCKET-P36	81205	1	21-66-11 P36/ /	050-099, 162-199
D13850		BACS16W5 RELAY SOCKET	81205	1	21-66-21 P037-00/ /	050-099, 162-199
D13852		BACS16W5 RELAY SOCKET-P36	81205	1	21-66-21 P36/ /	050-099, 150, 152-199
D13854		BACS16W5 RELAY SOCKET	81205	1	21-66-21 P037-00/ /	050-099, 150, 152-199
D13856		BACC45FT14-7S PLUG-	81205	1	21-66-11 638/173/L079	050-099, 162-199
D13860		BACC45FT10-5S6 PLUG-	81205	1	21-66-11 612/173/L079	050-099, 162-199
D13868		BACC45FT12-3S PLUG	81205	1	21-66-11 310/279/L012	050-099
D13868		BACC45FT12-3S PLUG	81205	1	21-66-11 384/299/L012	162-199
D13870		BACC45FT10-5S PLUG-	81205	1	21-66-11 434/299/L013	050-099, 162-199
D13872		BACC45FT14-7S PLUG-	81205	1	21-66-11 526/303/L023	050-099, 162-199
D13874		BACC45FT18-14S PLUG-	81205	1	21-66-11 393/294/L015	050-099, 162-199
D13876		BACC45FT22-55S PLUG-	81205	1	21-66-11 393/294/L015	050-099, 162-199
D13878		BACC45FT24-61S PLUG	81205	1	21-66-11 392/296/L018	050-099
D13878		BACC45FT24-61S PLUG	81205	1	21-66-11 393/294/L015	162-199
D13880		BACC45FT10-5S PLUG-	81205	1	21-66-21 441/275/R055	050-099

EQUIPMENT LIST

D280T132

Section D13800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13880		BACC45FT10-5S PLUG-	81205	1	21-66-21 441/267/R063	162-199
D13882		BACC45FT12-3S PLUG-	81205	1	21-66-21 444/291/R032	050-099, 162-199
D13884		BACC45FT10-5S HTR SKT	81205	1	21-66-21 455/291/R12	050-099, 162-199
D13886		MS3126F10-6S PLUG-	96906	1	21-66-21 441/267/R063	050-099, 162-199
D13888		BACC45FT10-5S6 RELAY SOCKET	81205	1	21-66-21 481/289/R12	050-099
D13888		BACC45FT10-5S6 RELAY SOCKET	81205	1	21-66-21 481/298/R12	162-199
D13890		BACC45FT12-3S PLUG-	81205	1	21-66-31 1438/293/L026	050-099, 150, 152-199
D13892		BACC45FT10-5S PLUG-	81205	1	21-66-31 1419/267/L063	050-099
D13892		BACC45FT10-5S PLUG-	81205	1	21-66-31 1419/254/L063	150, 152-199
D13894		BACC45FT10-5S PLUG-	81205	1	21-66-31 1428/300/L012	050-099, 150, 152-199
D13896		BACC45FT10-5S6 PLUG-	81205	1	21-66-31 1389/298/L012	050-099, 150, 152-199
D13898		MS3126F10-6S PLUG-	96906	1	21-66-31 1419/267/L063	050-099, 150, 152-199

EQUIPMENT LIST

D280T132

Section D13800
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13900		BACC45FT12-3S TEMP SENSR CONN	81205	1	21-66-41 1438/293/R26	050-099
D13900		BACC45FT12-3S TEMP SENSR CONN	81205	1	21-66-41 1438/300/R26	150, 152-199
D13902		BACC45FT10-5S TEMP SENSR CONN	81205	1	21-66-41 1419/290/R63	050-099
D13902		BACC45FT10-5S TEMP SENSR CONN	81205	1	21-66-41 1419/290/R63	150, 152-199
D13904		BACC45FT10-5S HTR SKT	81205	1	21-66-41 1428/300/R12	050-099, 150, 152-199
D13906		BACC45FT10-5S6 CREW REST SUPP FAN CONN	81205	1	21-66-41 1398/298/R12	050-099, 150, 152-199
D13908		MS3126F10-6S TEMP SEL CONN	81205	1	21-66-41 1419/267/R63	050-099, 150, 152-199
D13910		BACC45FT18-14S TEMP CONT CONN	81205	1	21-66-21 1428/294/R18	050-099
D13910		BACC45FT18-14S TEMP CONT CONN	81205	1	21-66-41 1428/294/R18	150, 152-199
D13912		BACC45FT22-55S TEMP CONT CONN	81205	1	21-66-41 1428/294/R18	050-099, 150, 152-199
D13914		BACC45FT24-61S TEMP CONT CONN	81205	1	21-66-41 1428/294/R18	050-099, 150, 152-199
D13916		BACC45FT18-14S RLY SKT	81205	1	21-66-21 433/294/R15	050-099, 162-199
D13918		BACC45FT22-55S PLUG-	81205	1	21-66-21 433/294/R015	050-099, 162-199
D13920		BACC45FT24-61S PLUG-	81205	1	21-66-21 433/294/R015	050-099, 162-199
D13922		BACC45FT18-14S PLUG-	81205	1	21-66-21 1445/294/L015	050-099, 150, 152-199
D13924		BACC45FT22-55S PLUG-	81205	1	21-66-21 1445/294/L015	050-099, 150, 152-199
D13926		BACC45FT24-61S PLUG-	81205	1	21-66-21 1445/294/L015	050-099, 150, 152-199

EQUIPMENT LIST

D280T132

Section D13900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13928		48-7191 RCPT-	81205	1	26-13-12 0445/280/R043	164-199
D13930		48-7190 PLUG-	81205	1	26-13-12 1446/280/R043	164-199
D13932		48-7190 PLUG-	81205	1	26-13-12 1446/280/L043	164-199
D13934		BACS16X1 RELAY SOCKET-P6	81205	1	24-51-31 P006-00/ /	ALL
D13934 U		289T0133-10101 M/W TAPE- TEXT AS BELOW	81205	1	24-51-31 / /	150-154, 275-276
D13936		BACS16X3 RELAY SOCKET-P6	81205	1	24-51-31 P006-00/ /	ALL
D13936 U		289T0133-10102 M/W TAPE- TEXT AS BELOW	81205	1	24-51-31 / /	150-154, 275-276
D13940		BACS16W1A RELAY SOCKET	81205	1	25-33-11 P037-00/ /	277-299
D13942		BACC63BP10C5S8L PLUG	81205	1	36-11-61 L324/P25/FS	ALL
D13942 T		BACC10KD10 CLAMP	81205	1	36-11-61 L324/P25/FS	ALL
D13942 V		-11003 MATE/WITH TAPE TEXT AS BELOW	85480	1	36-23-11 / /	050-099, 150-155, 162-165, 275-276
D13944		BACC63BP10C5S8L PLUG	81205	1	36-11-62 R324/P25/FS	ALL
D13944 T		BACC10KD10 CLAMP	81205	1	36-11-62 R324/P25/FS	050-099, 150-157, 163-199, 275-299
D13944 V		-11103 MATE/WITH TAPE TEXT AS BELOW	85480	1	36-11-62 / /	050-099, 150-155, 163-165, 275-276
D13950		48-7190 PLUG-	81205	1	26-13-12 445/280/R043	164-199
D13952		48-7191 RCPT-	81205	1	26-13-12 1446/280/R043	164-199
D13954		48-7191 RCPT-	81205	1	26-13-12 1446/280/L043	164-199

EQUIPMENT LIST

D280T132

Section D13900

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D13964		DAMA-15SWS SOCKET-		1	26-13-12 276/278/R001	050-099, 162-199
D13964 T		DA19977-1 CLAMP		1	26-13-12 276/278/R001	050-099, 162-199
D13964 U		DA51220-1 RETAINER		1	26-13-12 276/278/R001	050-099, 162-199
D13966		48-7191 RCPT	81205	1	26-13-12 336/280/0000	164-199
D13968		48-7190 PLUG	81205	1	26-13-12 336/280/0000	164-199

EQUIPMENT LIST

D280T132

Section D13900
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D15802J		BACC63BV14F7PN RECP-ENGINE(PW4000)	81205	2	73-21-11 NR194/150/	050-099, 155-199, 277-299
D15802J		BACC63BV14F7PN RECP-ENGINE	81205	2	73-21-11 NR194/150/	150-154, 275-276
D15802JK		BACC10KD14 CLAMP	81205	2	73-21-11 / /	ALL
D15802P		BACC63BP14C7SNL PLUG-ENGINE	81205	2	73-21-11 NR190/110/	050-099, 155-199, 277-299
D15802P		BACC63BP14C7SNL PLUG-ENGINE	81205	2	73-21-11 NR194/110/	150-154, 275-276
D15802PQ		BACC10KD14 CLAMP	81205	2	73-21-11 / /	050-099, 155-199, 277-299
D15802PQ		BACC10KD14 CLAMP-	81205	2	73-21-11 / /	150-154, 275-276

EQUIPMENT LIST

D280T132

Section D15800
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D17072J		BACC45FN16-24P6 RECP.	81205	1	28-31-22 P089-00/ /	150-154, 275
D17074J		BACC45FN12-12P RECP.	81205	1	28-31-22 P089-00/ /	150-154, 275
D17076J		BACC45FN18-31P7 RECP.	81205	1	28-31-22 P089-00/ /	150-154, 275
D17078J		BACC45FN12-12P6 RECP.	81205	1	28-31-22 P089-00/ /	150-154, 275
D17080J		BACC45FN12-12P7 RECP.	81205	1	28-31-22 P089-00/ /	150-154, 275

EQUIPMENT LIST

D280T132

Section D17000

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D20032		BACC45FT12A12S PLUG-	81205	1	33-21-13 0741/285/L056	280-299
D20058		BACC63BP14A7SNL PLUG-	81205	1	28-22-31 954/166/L 29	ALL
D20058 U		710AS011M1412-62A ADAPTER	06324	1	28-22-31 954/170/L 29	ALL
D20090		BACS16W1A RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL
D20092		BACS16W1A RELAY SOCKET-	81205	1	32-09-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D20000
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D20100		BACS16W1A RELAY SOCKET-	81205	1	32-09-12 P037-00/ /	ALL
D20102		BACS16W1A RELAY SOCKET-	81205	1	78-34-11 P036-00/ /	ALL
D20104		BACS16W1A RELAY SOCKET-	81205	1	78-34-21 P037-00/ /	ALL
D20110		BACS16AG1 RELAY SOCKET-	81205	1	78-36-11 P033/ /	ALL
D20112		BACS16AG1 RELAY SOCKET-	81205	1	78-36-21 P033/ /	ALL
D20118		BACC63BN14C7S6 PLUG	81205	1	78-34-11 NL284/134/	ALL
D20120		BACC63BN14C7S6 PLUG	81205	1	78-34-21 NR 284/134/	050-099, 150-156, 162-166, 275-276
D20120		BACC63BN14C7S6 PLUG	81205	1	78-34-21 NR284/134/	157, 167-199, 277- 299
D20122		BACC63BP12A3SNL PLUG	81205	1	78-36-11 NL284/134/	ALL
D20122 T		BACC10KD12 CLAMP	81205	1	78-36-11 / /	157, 167-199, 277- 299
D20126		BACC63BP12A3SNL PLUG	81205	1	78-36-11 NR284/134/	ALL
D20126 T		BACC10KE12 CLAMP	81205	1	78-36-21 / /	ALL
D20160		BACC45FN12-12S RCPT-SWITCH PACK	81205	1	78-34-11 AE0108/ /	ALL
D20162		BACC45FN12-12S6 RCPT-SWITCH PACK	81205	1	78-34-21 AE0108/ /	ALL
D20164		BACC66H21C27AA01 PLUG	71468	1	78-36-11 E1-4/ /	ALL
D20164A		PARTAOFD20164 PLUG PART A OF D20164	71468	1	78-36-11 E1-4/ /	ALL
D20164B		PARTBOFD20164 PLUG PART B OF D20164	71468	1	78-36-21 E1-4/ /	ALL

EQUIPMENT LIST

D280T132

Section D20100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D20164C		PARTCOFD20164 PLUG PART C OF D20164	71468	1	78-36-21 E1-4/ /	ALL
D20178		BACS16W5 RELAY SOCKET-P33	81205	1	78-34-21 P033-00/ /	ALL
D20180		BACS16W5 RELAY SOCKET-P33	81205	1	78-34-11 P033-00/ /	ALL
D20186		BACS16X1 RELAY SOCKET-P33	81205	1	78-34-21 P033-00/ /	ALL
D20188		BACS16X1A RELAY SOCKET-P33	81205	1	78-34-11 P033-00/ /	ALL
D20190		BACS16W4 RELAY SOCKET-P33	81205	1	78-34-21 P033-00/ /	ALL
D20192		BACS16W4 RELAY SOCKET-P33	81205	1	78-34-11 P033-00/ /	ALL
D20194		BACC63BP12A3SN PLUG-	81205	2	78-34-11 58/0/R012	ALL
D20194 T		BACC10KD12 CLAMP-	81205	2	78-34-11 / /	ALL
D20196		BACC63BP12A3SN PLUG-	81205	2	78-34-11 -7/0/L006	ALL
D20196 T		BACC10KD12 CLAMP-	81205	2	78-34-11 / /	ALL

EQUIPMENT LIST

D280T132

Section D20100
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D20542		BACS16AF1 RLY SKT	81205	1	73-21-19 P036-00/ /	050-099, 150-199
D20542 V		-10401 I.D. TAPE - TEXT AS BELOW		1	73-21-19 / /	050-099
D20544		BACS16AF1 RLY SKT	81205	1	73-21-19 P037-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section D20500

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D21190		BACS16W1A RLY SKT	81205	1	27-89-11 P037-00/PNL/	ALL
D21192		BACS16W1 RELAY SOCKET-	81205	1	21-45-21 P037-00/ /	275-299
D21198		BACC45FT12-12S PLUG-	81205	1	21-45-21 0362/288/R041	275-299

EQUIPMENT LIST

D280T132

Section D21100
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D21200		CQAMA15S PLUG-	71771	1	21-45-21 0350/225/R095	275-299
D21200 T		CQA-SM BACKSHELL	71771	1	21-45-21 / /	275-299
D21232		BACS16X1A RELAY SOCKET-	81205	1	38-32-11 P036-00/ /	156-157, 166-199, 277-299
D21234		BACS16X1A RELAY SOCKET-	81205	1	38-32-11 P036-00/ /	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section D21200
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D23138		BACS16W1A RELAY SOCKET-	81205	1	27-62-11 P033-00/ /	ALL
D23140		D38999-26FA98SN PLUG-	81205	1	27-62-11 WHEEL/07/R GR	050-099, 151, 155- 199, 275-299
D23140		D38999-26FA98SN PLUG	81205	1	27-62-11 WHEEL/07/R GR	150, 152-154

EQUIPMENT LIST

D280T132

Section D23100
Page 1 End
Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D30003		48-7190-1 PLUG	02660	1	52-51-11 0240/242/L017	050-099, 150-163, 166-199, 275-299
D30009		48-7191-1 RCPT	02660	1	52-51-11 0240/242/L017	050-099, 150-163, 166-199, 275-299
D30011		48-7191 RCPT	02660	1	52-51-11 0240/242/L017	050-099, 150-163, 166-199, 275-299
D30013		48-7190 PLUG	02660	1	52-51-11 0240/242/L017	050-099, 150-163, 166-199, 275-299

EQUIPMENT LIST

D280T132

Section D30000

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D31184		BACS16AG1 RELAY SOCKET-P37	81205	1	28-22-12 P037-00/ /	ALL
D31186		BACS16AH1 RELAY SOCKET-P37	81205	1	28-22-12 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section D31100
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D72026		BACC45FT10A5S PLUG-	81205	1	21-45-24 1467/304/L037	ALL
D72026 V		289T0197-10303 I.D. TAPE TEXT AS BELOW	81205	1	21-45-24 / /	150-199, 275-277
D72028		BACC45FT10A5S PLUG-	81205	1	21-45-24 1464/304/R037	ALL
D72028 V		289T0197-10304 I.D. TAPE TEXT AS BELOW	81205	1	21-45-24 / /	150-199, 275-277
D72030		BACC45FT10A5S6 PLUG-	81205	1	21-45-24 1467/306/L029	ALL
D72032		BACC45FT10A5S6 PLUG-	81205	1	21-45-24 1464/306/L029	050-099, 150-199, 275-277
D72032		BACC45FT10A5S6 PLUG-	81205	1	21-45-24 1464/306/R029	278-299
D72034		BACS16W1 RELAY SOCKET	81205	1	21-45-24 P087-00/ /	278-299
D72042		BACS16X3A RELAY SOCKET-	81205	1	33-22-42 P025-00/ /	280-299
D72046		BACC45FT12C12P7 PLUG-	81205	1	SPARE 654+104/281/L019	280-299
D72048		BACC45FT10-5S PLUG-	81205	1	SPARE 654+28/280/R064	280-299
D72056		BACC45FT12A12S PLUG-	81205	1	33-21-11 0654+050/295/L020	280-299
D72058		BACC45FT12A12S PLUG-	81205	1	33-21-11 0734/295/L020	280-299
D72060		BACC63BP12A3P9L PLUG-	81205	1	27-81-31 1043/193/R029	157, 277
D72060		BACC63BP12A3S6L PLUG-	81205	1	27-81-31 1043/193/R029	167-199, 275-276, 278-299
D72060 T		710AA011M1209-62A ADAPTER-90 DEGREES	06324	1	27-81-31 1043/193/R029	157, 167-199, 277- 299

EQUIPMENT LIST

D280T132

Section D72000

Page 1 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D90001		D38999-26KG41PD PLUG-PW4000 VENDOR# W1P6 (M/W M7198-J6)	00000000 96906	1	71-51-14 NR119/132/	ALL
D90001 T		G9311A21ANF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR119/132/	ALL
D90002		D38999-26KG41PE PLUG-PW4000 VENDOR# W1P7 (M/W M7198-J7)	00000000 96906	1	71-51-14 NR119/132/	ALL
D90002 T		G9311A21ANF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR119/132/	ALL
D90003		D38999-26KG41SA PLUG-PW4000 VENDOR# W1P8 (M/W M7198-J8)	00000000 96906	1	71-51-14 NR119/132/	ALL
D90003 T		G9311A21ANF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR119/132/	ALL
D90004		D38999-26KG41PA PLUG-PW4000 VENDOR# W2P2 (M/W M7198-J2)	00000000 96906	1	71-51-14 / /	ALL
D90004 T		G9311A21ANF-D BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR119/132/	ALL
D90005		D38999-26KG41PB PLUG-PW4000 VENDOR# W2P3 (M/W M7198-J3)	00000000 96906	1	71-51-14 NR119/132/	ALL
D90005 T		G9311A21ANF-D BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR119/132/	ALL
D90006		D38999-26KG41SN PLUG-PW4000 VENDOR# W2P4 (M/W M8198-J4)	00000000 96906	1	71-51-14 NR119/132/	ALL
D90006 T		G9311A21ANF-D BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR119/132/	ALL
D90007		D38999-26KF32SN PLUG-PW4000 VENDOR# W2P33 (M/W M6848-J3)	00000000 96906	1	71-51-14 NR190/110/	ALL
D90007 T		G9311A19ANF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR190/110/	ALL
D90008		D38999-26KF32SA PLUG-PW4000 VENDOR# W2P34 (M/W M6848-J2)	00000000 96906	1	71-51-14 NR190/110/	ALL
D90008 T		G9311A19ANF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR190/110/	ALL
D90011	1	CN0966-14S07SN PLUG-PW4000 VENDOR# W1P10 (M/W V355)	00000000 13556	1	71-51-14 NR190/110/	ALL

EQUIPMENT LIST

D280T132

Section D90000

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D90011	2	ZZY-RC-12D14-07ST PLUG-PW4000 VENDOR# W1P10 (M/W V355)	00000000 13556	1	71-51-14 NR190/110/	ALL
D90011 T		G931S214BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR190/110/	ALL
D90012	1	CN0966-12S03SN PLUG-PW4000 VENDOR# W1P11 (M/W V355)	00000000 13556	1	71-51-14 //	ALL
D90012	2	ZZY-RC-12D12-03ST PLUG-PW4000 VENDOR# W1P11 (M/W V355)	00000000 49367	1	71-51-14 //	ALL
D90012 T		G9312S12BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90013	1	CN0966-14S07SN PLUG-PW4000 VENDOR# W1P12 (M/W V354)	00000000 13556	1	71-51-14 N134/112/L024	ALL
D90013	2	ZZY-RC-12D14-07ST PLUG-PW4000 VENDOR# W1P12 (M/W V354)	00000000 49367	1	71-51-14 N134/112/L024	ALL
D90013 T		G9312S14BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N134/112/L024	ALL
D90015		D38999-26KC98PN PLUG-PW4000 VENDOR# W3P1 (M/W T1519)	00000000 96906	1	71-51-14 //	ALL
D90015 T		G9311S13BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90016		D38999-26KB98PN PLUG-PW4000 VENDOR# W5P6 (M/W T1519)	00000000 96906	1	71-51-14 //	ALL
D90016 T		G9311S11BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90017	1	VN0966-12S03SN PLUG-PW4000 VENDOR# W3P5 (M/W V358)	00000000 13556	1	71-51-14 N150/090/L018	ALL
D90017	2	ZZY-RC-12D12-03ST PLUG-PW4000 VENDOR# W3P5 (M/W V358)	00000000 49367	1	71-51-14 N150/090/L018	ALL
D90017 T		G9312S12BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N150/090/L018	ALL
D90018	1	CN0966-12S03S7 PLUG-PW4000 VENDOR# W5P5 (M/W V358)	00000000 13556	1	71-51-14 N150/090/L018	ALL
D90018	2	ZZY-RC-12D12-03S07T PLUG-PW4000 VENDOR# W5P5 (M/W V358)	00000000 13556	1	71-51-14 N150/090/L018	ALL

EQUIPMENT LIST

D280T132

Section D90000

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D90018	T	G9312S12BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N150/090/L018	ALL
D90019		D38999-26KD19SN PLUG-PW4000 VENDOR# W3P15 (M/W M3105)	00000000 96906	1	71-51-14 N134/079/L008	ALL
D90019	T	387HA020Z115BD BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N134/079/L008	ALL
D90020		FPK-12E18-14ST PLUG-PW4000 VENDOR# W3P17 (M/W V357)	00000000 49367	1	71-51-14 N134/092/L020	ALL
D90020	T	G931SA18BNF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N134/092/L020	ALL
D90021		D38999-26KB98SN PLUG-PW4000 VENDOR# W3P18 (M/W T690)	00000000 96906	1	71-51-14 N161/075/L017	ALL
D90021	T	G9311S11BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N161/075/L017	ALL
D90022		D38999-26KD19SA PLUG-PW4000 VENDOR# W4P2 (M/W M3108)	00000000 96906	1	71-51-14 NR152/080/	ALL
D90022	T	387HA020Z115B BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR152/080/	ALL
D90023		D38999-26KD19SN PLUG-PW4000 VENDOR# W5P1 (M/W M3108)	00000000 96906	1	71-51-14 NR152/080/	ALL
D90023	T	387HA020Z115B BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR152/080/	ALL
D90024		D38999-26KD19SN PLUG-PW4000 VENDOR# W4P3 (M/W M3106)	00000000 96906	1	71-51-14 N141/084/R017	ALL
D90024	T	G9311S15BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N141/084/R017	ALL
D90025		D38999-26KD19SA PLUG-PW4000 VENDOR# W5P7 (M/W M3106)	00000000 96906	1	71-51-14 N141/084/R017	ALL
D90025	T	G9311S15BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N141/084/R017	ALL
D90026	1	CN0966-14S07S7 PLUG-PW4000 VENDOR# W4P4 (M/W V356)	00000000 13556	1	71-51-14 N134/122/R013	ALL
D90026	2	ZZY-RC-12D14-07S07T PLUG-PW4000 VENDOR# W4P4 (M/W V356)	00000000 49367	1	71-51-14 N134/122/R013	ALL

EQUIPMENT LIST

D280T132

Section D90000

Page 3

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D90026 T		G9312S14BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N134/122/R013	ALL
D90027	1	CN0966-14S07S6 PLUG-PW4000 VENDOR# W5P11 (M/W V356)	00000000 13556	1	71-51-14 N134/122/R013	ALL
D90027	2	ZZY-RC-12D14-07S06T PLUG-PW4000 VENDOR# W5P11 (M/W V356)	00000000 49367	1	71-51-14 N134/122/R013	ALL
D90027 T	1	G931S214BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N134/122/R013	ALL
D90027 T	2	G931SB14BNF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N134/122/R013	ALL
D90028		BT06RA-10SL-3S PLUG-PW4000 VENDOR# W4P10 (M/W S1613)	00000000 77820	1	71-51-14 N154/100/R017	ALL
D90028 T	1	G9310B12BNF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N154/100/R017	ALL
D90028 T	2	G9310A12BNF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N154/100/R017	ALL
D90029	1	CN0966-18S14SN PLUG-PW4000 VENDOR# W4P16 (M/W M3107)	00000000 13556	1	71-51-14 N146/113/R015	ALL
D90029	2	ZZY-RC-12D18-14ST PLUG-PW4000 VENDOR# W4P16 (M/W M3107)	00000000 49367	1	71-51-14 N146/113/R015	ALL
D90029 T		G9312A18BNF-D BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N146/113/R015	ALL
D90030	1	CN0966-14S07SN PLUG-PW4000 VENDOR# W4P19 (M/W T688)	00000000 13556	1	71-51-14 N130/076/	ALL
D90030	2	ZZY-RC-12D14-07ST PLUG-PW4000 VENDOR# W4P19 (M/W T688)	00000000 49367	1	71-51-14 N130/076/	ALL
D90030 T		G931S214BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N130/076/	ALL
D90031		BT06RA-14S-7S PLUG-PW4000 VENDOR# W4P21 (M/W S1615)	00000000 77820	1	71-51-14 N162/110/L014	ALL
D90031 T		G9310A14BNF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N162/110/L014	ALL
D90032		D38999-26KA98SN PLUG-PW4000 VENDOR# W4P23 (M/W T688)	00000000 96906	1	71-51-14 N130/076/	ALL

EQUIPMENT LIST

D280T132

Section D90000

Page 4

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D90032	T	G9311S09BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N130/076/	ALL
D90033		D38999-26KB98SN PLUG-PW4000 VENDOR# W5P8 (M/W T1970)	00000000 96906	1	71-51-14 N163/087/R016	ALL
D90033	T	G9311S11BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-15 N163/087/R016	ALL
D90034		BT06RA-10SL-3S PLUG-PW4000 VENDOR# W5P10 (M/W S1614)	00000000 77820	1	71-51-14 N154/109/L015	ALL
D90034	T	G9310A12BNF BACKSHELL-PW4000 VENDOR	00000000 715113	1	71-51-13 N154/109/L015	ALL
D90035		D38999-26KB98SN PLUG-PW4000 VENDOR# W5P13 (M/W T689)	00000000 96906	1	71-51-11 N178/069/R008	ALL
D90035	T	G9311S11BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N178/069/R008	ALL
D90036		D38999-26KE26PN PLUG-PW4000 VENDOR (M/W M7198 J9)	00000000 96906	1	71-51-14 NR119/132/	ALL
D90038		D38999-26KG41PN PLUG-PW4000 VENDOR (M/W M6848 J4)	00000000 96906	1	71-51-14 NR190/110/	ALL
D90040		BACC63BP14C7PNL PLUG-PW4000 VENDOR (M/W D8338J)	00000000 81205	1	71-51-14 NL126/100/	ALL
D90040	T	BACC10HF14C BACKSHELL-PW4000 VENDOR	00000000 81205	1	71-51-44 NL126/100/	ALL
D90041		BACC63BP14C7PNL PLUG-PW4000 VENDOR (M/W D83432J)	00000000 81205	1	71-51-14 NL126/100/	ALL
D90041	T	BACC10HF14C BACKSHELL-PW4000 VENDOR	00000000 81205	1	71-51-14 NL126/100/	ALL
D90042		BACC63BP14C7PNL PLUG-PW4000 VENDOR (M/W D8340J)	00000000 81205	1	71-51-14 NL126/100/	ALL
D90042	T	BACC10HF14C BACKSHELL-PW4000 VENDOR	00000000 81205	1	71-51-14 NL126/100/	ALL
D90043		BACC63BP14C7PNL PLUG-PW4000 VENDOR (M/W D8344J)	00000000 81205	1	71-51-14 NL126/100/	ALL
D90043	T	BACC10HF14C BACKSHELL-PW4000 VENDOR	00000000 81205	1	71-51-14 NL126/100/	ALL

EQUIPMENT LIST

D280T132

Section D90000

Page 5

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D90044		D38999-20KC98PN RCPT-PW4000 VENDOR M/W DV350 (IDG AOC V)	00000000 96906	1	71-51-14 NL154/081/	ALL
D90051J		D38999-20KG41PN RCPT-PW4000 VENDOR# W2J9 (M/W W1P9)	00000000 96906	1	71-51-14 //	ALL
D90051JK		G9311S21ANF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90051P		D38999-26KG41SN PLUG-PW4000 VENDOR# W1P9 (M/W W2J9)	00000000 96906	1	71-51-14 //	ALL
D90051PQ		G9311A21ANF BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90052P	1	CN0966-12S03S6 PLUG-PW4000 VENDOR# W1P13 (M/W D8328J)	00000000 13556	1	71-51-14 NR095/150/	ALL
D90052P	2	ZZY-RC-12D12-03S06T PLUG-PW4000 VENDOR# W1P13 (M/W D8328J)	00000000 49367	1	71-51-14 NR095/150/	ALL
D90052PQ		G9312S12BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR095/150/	ALL
D90053J		D38999-20KH53PN RCPT-PW4000 VENDOR# W3J24 (M/W W1P24)	00000000 96906	1	71-51-14 //	ALL
D90053JK		G65071 BACKSHELL PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90053P		D38999-26KH53SN PLUG-PW4000 VENDOR# W1P24 (M/W W3J24)	00000000 96906	1	71-51-14 //	ALL
D90053PQ		G65071D BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90054J		D38999-20KH53PA RCPT-PW4000 VENDOR# W4J25 (M/W W1P25)	00000000 96906	1	71-51-14 //	ALL
D90054JK		G65071 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90054P		D38999-26KH53SA PLUG-PW4000 VENDOR# W1P25 (M/W W4J25)	00000000 96906	1	71-51-14 //	ALL
D90054PQ		GD65071D BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90055J		CN0967-22S19PN RCPT-PW4000 VENDOR# W1J14 (M/W D8346P)	00000000 13556	1	71-51-14 N109/140/R032	ALL

EQUIPMENT LIST

D280T132

Section D90000

Page 6

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D90055JK		G9312S22BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N109/140/R032	ALL
D90056J		D38999-20KD19PN RCPT-PW4000 VENDOR# W1J35 (M/W W2P35)	00000000 96906	1	71-51-14 //	ALL
D90056JK		G9311S15BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90056P		D38999-26KD19SN PLUG-PW4000 VENDOR# W2P35 (M/W W1J35)	00000000 96906	1	71-51-14 //	ALL
D90056PQ		G9311S15BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90057P	1	CN0966-12S03S7 PLUG-PW4000 VENDOR# W2P13 (M/W D8332J)	00000000 13556	1	71-51-14 NR095/150/	ALL
D90057P	2	ZZY-RC-12D12-03S07T PLUG-PW4000 VENDOR# W2-13 (M/W D8332J)	00000000 49367	1	71-51-14 NR095/150/	ALL
D90057PQ		G9312S12BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 NR095/150/	ALL
D90058J		D38999-20KH53PB RCPT-PW4000 VENDOR# W5J26 (M/W W2P26)	00000000 96906	1	71-51-14 //	ALL
D90058JK		G65071 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90058P		D38999-26KH53SB PLUG-PW4000 VENDOR# W2P26 (M/W W5J26)	00000000 96906	1	71-51-14 //	ALL
D90058PQ		G65071 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90059J		CN0967-22S19P6 RCPT-PW4000 VENDOR# W2J14 (M/W D8330P)	00000000 13556	1	71-51-14 N109/138/R031	ALL
D90059JK		G9312S22BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N109/138/R031	ALL
D90060J		CN0967-24S30PN RCPT-PW4000 VENDOR# W2J32 (M/W D8370P)	00000000 13556	1	71-51-14 N110/143/R025	ALL
D90060JK		G9312S24BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 N110/143/R025	ALL
D90061J		CN0967-16S10SN RCPT-PW4000 VENDOR# W5J12 (M/W W6P12)	00000000 13556	1	71-51-14 //	ALL

EQUIPMENT LIST

D280T132

Section D90000

Page 7

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D90061JK		G9312S16BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90061P		CN0966-16S10PN PLUG-PW4000 VENDOR# W6P12 (M/W W5J12)	00000000 13556	1	71-51-14 //	ALL
D90061PQ		G9312S16BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90062J		D38999-20KF32PN RCPT-PW4000 VENDOR# W8J33 (M/W W2P33)	00000000 96906	1	71-51-14 //	ALL
D90062JK		G9311S19BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL
D90063J		D3899-20KF32PA RCPT-PW4000 VENDOR# W8J34 (M/W W2P34)	00000000 96906	1	71-51-14 //	ALL
D90063JK		G9311S19BNF-3 BACKSHELL-PW4000 VENDOR	00000000 06324	1	71-51-14 //	ALL

EQUIPMENT LIST

D280T132

Section D90000

Page 8 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
D96101J	9	CUSTOMER-1 RCPT-E9-1	CUST	1	23-25-13 AC1102/ /	150, 153-199
D96101P		CUSTOMER PLUG-E9-1		1	23-25-13 AC1102/ /	150, 153-199
D96102P	9	CUSTOMER-AA PLUG	CUST	1	23-25-13 AF0204/ /	150, 153-199

EQUIPMENT LIST

D280T132

Section D96100
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E001-00		284T0400 MAIN EQUIPMENT CTR-E1 RACK	284T0001 81205	1	91-03-00 0330/160/0000	ALL
E001-01		284T0111 SHELF E1-1	284T0600 81205	1	91-03-11 0330/160/0000	ALL
E001-02		284T0112 SHELF E1-2	284T0600 81205	1	91-03-12 0330/160/0000	ALL
E001-03		284T0113 SHELF E1-3	284T0600 81205	1	91-03-13 0330/160/0000	ALL
E001-04		284T0114 SHELF E1-4	284T0600 81205	1	91-03-14 0330/160/0000	ALL
E001-05		284T0115 SHELF E1-5	284T0600 81205	1	91-03-15 0330/160/0000	ALL
E001-06		284T0339 SHELF E1-6	284T0600 81205	1	91-03-16 0330/160/0000	ALL

EQUIPMENT LIST

D280T132

Section E001
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E002-00		284T0400 MAIN EQUIPMENT CTR-E2 RACK	284T0001 81205	1	91-03-00 0330/160/0000	ALL
E002-01		284T0121 SHELF E2-1	284T0600 81205	1	91-03-21 0330/160/0000	ALL
E002-02		284T0122 SHELF E2-2	284T0600 81205	1	91-03-22 0330/160/0000	ALL
E002-03		284T0123 SHELF E2-3	284T0600 81205	1	91-03-23 0330/160/0000	ALL
E002-04		284T0124 SHELF E2-4	284T0600 81205	1	91-03-24 0330/160/0000	ALL
E002-05		284T0125 SHELF E2-5	284T0600 81205	1	91-03-25 0330/160/0000	ALL
E002-06		284T0126 SHELF E2-6	284T0600 81205	1	91-03-26 0330/160/0000	ALL

EQUIPMENT LIST

D280T132

Section E002
Page 1 End
Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E003-00		284T0130 MAIN EQUIPMENT CTR-E3 RACK	284T0001 81205	1	91-03-00 0300/150/R040	ALL
E003-01		284T0131 E3-1 SHELF	284T0134 81205	1	91-03-31 0300/150/R040	ALL
E003-02		284T0132 E3-2 SHELF	284T0134 81205	1	91-03-32 0300/150/R040	ALL

EQUIPMENT LIST

D280T132



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E005-00		284T0150 MID EQUIPMENT CTR-E5 RACK	284T0001 81205	1	91-03-00 0620/170/R070	ALL
E005-01		284T0151 E5-1 SHELF	284T0150 81205	1	91-03-51 0620/170/R070	ALL
E005-02		284T0152 E5-2 SHELF	284T0150 81205	1	91-03-52 0620/170/R070	050-099
E005-03		284T0153 E5-3 SHELF	284T0150 81205	1	91-03-53 0620/170/R070	ALL

EQUIPMENT LIST

D280T132

Section E005
Page 1 End
Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E006-00		284T0406 AFT EQUIPMENT CTR-E6 RACK	284T0001 81205	1	91-03-00 1370/170/R070	ALL
E006-01		284T0161 E6-1 SHELF	284T0406 81205	1	91-03-61 1370/170/R070	ALL
E006-02		284T0162 E6-2 SHELF	284T0406 81205	1	91-03-62 1370/170/R070	050-099

EQUIPMENT LIST

D280T132

Section E006
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E007-00		284T0200 RACK ASSY-RECORDER,VOICE AND FLIGHT	284T0199 81205	1	91-00-00 1562/286/L030	ALL

EQUIPMENT LIST

D280T132

Section E007
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E008-00		284T0971 RACK-EICAS	284T0001 81205	1	91-03-81 0256/160/L055	ALL

EQUIPMENT LIST

D280T132

Section E008
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E009-01		284T1309 E9-1 SHELF	284T1308 81205	1	91-03-02 1197+132/180/R080	277-299

EQUIPMENT LIST

D280T132

Section E009
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E010-00		284T1318-1 SHELF ASSY	284T1295 81205	1	91-03-06 1070/294/L014	277-299

EQUIPMENT LIST

D280T132

Section E010
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E011-00		284T1318-2 SHELF ASSY	284T1295 81205	1	91-03-06 1188/294/L014	277-299

EQUIPMENT LIST

D280T132

Section E011
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
E090-90	9	CUSTOMER EQUIPMENT RACK (MTO230596)	CUSTOMER CUST	1	23-19-11 412R/ /	150, 152-199

EQUIPMENT LIST

D280T132

Section E090
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
G00019	1	60B40161-22 GENERATOR-INTEGRATED DRIVE	332T4210 81205	2	24-11-11 NL187/076/	ALL
G00019	2	60B40161-18 GENERATOR-INTEGRATED DRIVE	332T4210 81205	2	24-11-11 NL187/076/	ALL
G00019	3	60B40161-5 GENERATOR-INTEGRATED DRIVE	332T4210 81205	2	24-11-11 NL187/076/	ALL
G00019Q		S281T001-13 COUPLING-QUICK ATTACH/DETACH	332U4210 81205	2	24-11-11 NL187/076/	ALL

EQUIPMENT LIST

D280T132

Section G00000
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
J00001		287T6107-29 J-BOX-UPPER,LEFT MAIN LANDING GEAR	287T6104 81205	1	91-00-00 1000/165/L180	050-099, 155-199, 277-299
J00001		287T6107-11 J-BOX-UPPER,LEFT MAIN LANDING GEAR	287T6104 81205	1	91-00-00 1000/165/L180	150-154, 275-276
J00002	9	287T6107-38 J-BOX-UP,R MAIN LNDG GEAR (SB 27A0160)	287T6104 81205	1	91-00-00 1000/165/R180	050, 155-199
J00002	9	287T6107-38 J-BOX-UP,R MAIN LNDG GEAR (SB 27A0160)	287T0159 81205	1	27-62-11 1000/165/R180	150-154
J00002	9	287T6107-38 J-BOX-UPR, R MAIN LNDG GEAR (SB 27A0160)	287T0159 81205	1	27-62-11 1000/165/R180	275-276
J00002	9	287T6107-38 J-BOX-UPR, R MAIN LNDG GEAR (SB 27A0160)	287T6104 81205	1	91-00-00 1000/165/R180	277-299
J00002		287T6107-30 J-BOX-UPPER,RIGHT MAIN LANDING GEAR	287T6104 81205	1	91-00-00 1000/165/R180	051-099
J00003		287T6105-7 J-BOX-LOWER,LEFT MAIN LANDING GEAR	287T6104 81205	1	91-00-00 1040/100/L175	050-099, 155-199, 277-299
J00003		287T6105-5 J-BOX-LOWER,LEFT MAIN LANDING GEAR	287T6104 81205	1	91-00-00 1040/100/L175	150-154, 275-276
J00004	9	287T6105-9 J-BOX-LWR,R MAIN LNDG GEAR (SB 27A0160)	287T6104 81205	1	91-00-00 1040/100/R175	050, 155-199
J00004	9	287T6105-9 J-BOX-LWR,R MAIN LNDG GEAR (SB 27A0160)	287T0159 81205	1	27-62-11 1040/100/R175	150, 152-154
J00004	9	287T6105-9 J-BOX-LWR,R MAIN LNDG GEAR (SB 27A0160)	287T6104 81205	1	27-62-11 1040/100/R175	151
J00004	9	287T6105-9 J-BOX-LWR, R MAIN LNDG GR (SB 27A0160)	287T0159 81205	1	27-62-11 1040/100/R175	275-276
J00004	9	287T6105-9 J-BOX-LWR, R MAIN LNDG GR (SB 27A0160)	287T6104 81205	1	91-00-00 1040/100/R175	277-299
J00004		287T6105-7 J-BOX-LOWER,RIGHT MAIN LANDING GEAR	287T6104 81205	1	91-00-00 1040/100/R175	051-099

EQUIPMENT LIST

D280T132

Section J00000

Page 1 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00004		BACR13CG2AB RELAY-OXYGEN CONTROL	284T1900 81205	1	35-21-11 P019-00/ /	ALL
K00006		10-60450-6 RELAY-WATER PRESSURE SYS	284T1149 81205	1	38-15-11 P049-00/ /	ALL
K00007		BACR13CG2AB RELAY-OXY CONT,MANUAL DEPLOY	284T1900 81205	1	35-21-11 P019-00/ /	ALL
K00008		BACR13CG2AB RELAY-OXYGEN DEPLOYED INDICATION	285T0019 81205	1	35-21-11 P019-00/ /	ALL
K00010		BACR13CF2AB RELAY-CLOSED IND,AIR SUPPLY ISLN VALVE,L	284T0187 81205	1	36-11-11 P036-00/ /	ALL
K00015		BACR13CD2 RELAY-FLT REC EFIS I/P SWITCHING	284T0188 81205	1	31-31-12 P037-00/ /	ALL
K00016		BACR13CF2AB RELAY-OPEN IND,AIR SUPPLY ISLN VALVE,L	284T0187 81205	1	36-11-11 P036-00/ /	ALL
K00018		BACR13CF2AB RELAY-OPEN IND,AIR SUPPLY ISLN VALVE,R	284T0188 81205	1	36-11-21 P037-00/ /	ALL
K00019		BACR13CF2AB RELAY-CLOSED IND,AIR SUPPLY ISLN VALVE,R	284T0188 81205	1	36-11-21 P037-00/ /	ALL
K00021		BACR13CF2AB RELAY-CLOSED IND,AIR SUPPLY ISLN VALVE,C	284T0187 81205	1	36-11-31 P036-00/ /	ALL
K00022		BACR13CF2AB RELAY-OPEN IND,AIR SUPPLY ISLN VALVE,C	284T0187 81205	1	36-11-31 P036-00/ /	ALL
K00023		BACR13CG2AB RELAY-APU AIR SUPPLY VALVE CONT	284T1149 81205	1	36-11-41 P049-00/ /	ALL
K00024		BACR13CG2AB RELAY-CLOSED IND,APU AIR SUPPLY VALVE	284T1149 81205	1	36-11-41 P049-00/ /	ALL
K00025		BACR13CE2 RELAY-OPEN IND,APU AIR SUPPLY VALVE	284T1149 81205	1	36-11-41 P049-00/ /	ALL
K00026	9	BACR13CG2A RELAY-T/R STOW,L ENG (SB 78-0062)	284T0187 81205	1	78-34-11 P036-00/ /	ALL
K00027	9	BACR13CG2A RELAY-T/R STOW,R ENG (SB 78-0062)	284T0188 81205	1	78-34-21 P037-00/ /	ALL
K00030		10-60450-6 RELAY-CARGO DOOR LTS ENABLE	284T0687 81205	1	33-37-11 P035-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00000

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00031		10-60450-1 RELAY-CAR. DR HINGE UP,FWD	284T0687 81205	1	52-34-11 P035-00/ /	ALL
K00032		10-60450-1 RELAY-CAR. DR HINGE DN,FWD	284T0687 81205	1	52-34-11 P035-00/ /	ALL
K00033		BACR13CG2A RELAY-CAR. DR UNLATCH,FWD	284T0687 81205	1	52-34-11 P035-00/ /	ALL
K00034		BACR13CG2A RELAY-CAR. DR LATCH,FWD	284T0687 81205	1	52-34-11 P035-00/ /	ALL
K00036		10-60450-1 RELAY-CAR. DR HINGE UP,AFT	284T0688 81205	1	52-35-11 P039-00/ /	ALL
K00037		10-60450-1 RELAY-CAR. DR HINGE DN,AFT	284T0688 81205	1	52-35-11 P039-00/ /	ALL
K00038		BACR13CG2A RELAY-CAR. DR LIFT/LATCH UP,AFT	284T0688 81205	1	52-35-11 P039-00/ /	ALL
K00039		BACR13CG2A RELAY-CAR. DR LIFT/LATCH DN,AFT	284T0688 81205	1	52-35-11 P039-00/ /	ALL
K00040		10-60450-1 RELAY-CAR. DR CONT ARMING,AFT	284T0688 81205	1	52-35-11 P039-00/ /	ALL
K00041	1	600-154-2000 RELAY-TDC,PDU BAY C LDG DLY	284T3901 15420	1	25-53-24 P039-00/ /	ALL
K00041	2	600-154-200M-0 RELAY-TDC,PDU BAY C LDG DLY	284T3901 15420	1	25-53-24 P039-00/ /	ALL
K00042		BACR13CG2AB RELAY-OXYGEN MANUAL DEPLOYED INDICATION	284T1900 81205	1	35-21-11 P019-00/ /	ALL
K00043		BACR13CF2A RELAY-ENTRY DR PWR TRANS,FWD	284T0187 81205	1	52-11-12 P036-00/ /	ALL
K00045		BACR13CF2A RELAY-FUELING VALVE CONT,L AUX TANK	284T0187 81205	1	28-21-11 P036-00/ /	ALL
K00046		BACR13CF2A RELAY-FUELING VALVE CONT,R AUX TANK	284T0187 81205	1	28-21-11 P036-00/ /	ALL
K00049		BACR13CG2AB RELAY-AUTO./MANUAL 1,RIGHT PACK	284T0189 81205	1	21-53-21 P033-00/ /	ALL
K00050		BACR13CG2AB RELAY-AUTO./MANUAL 2,RIGHT PACK	284T0189 81205	1	21-53-21 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00000

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00051		BACR13CF2AB RELAY-MANUAL,EXIT DOOR OPEN,RIGHT PACK	284T0189 81205	1	21-53-22 P033-00/ /	ALL
K00052		BACR13CF2AB RELAY-MANUAL,EXIT DOOR CLOSE,RIGHT PACK	284T0189 81205	1	21-53-22 P033-00/ /	ALL
K00053		BACR13CF2AB RELAY-MANUAL,INLET DOOR OPEN,RIGHT PACK	284T0189 81205	1	21-53-22 P033-00/ /	ALL
K00054		BACR13CF2AB RELAY-MANUAL,INLET DOOR CLOSE,RIGHT PACK	284T0189 81205	1	21-53-22 P033-00/ /	ALL
K00055		BACR13CF2AB RELAY-MANUAL,TEMP CONT VLV OPEN,R PACK	284T0189 81205	1	21-53-22 P033-00/ /	ALL
K00056		BACR13CF2AB RELAY-MANUAL,TEMP CONT VLV CLOSE,R PACK	284T0189 81205	1	21-53-22 P033-00/ /	ALL
K00057		BACR13CG2AB RELAY-AUTO./MANUAL 1,LEFT PACK	284T0187 81205	1	21-53-11 P036-00/ /	ALL
K00058		BACR13CG2AB RELAY-AUTO./MANUAL 2,LEFT PACK	284T0187 81205	1	21-53-11 P036-00/ /	ALL
K00059		BACR13CF2AB RELAY-MANUAL,EXIT DOOR OPEN,LEFT PACK	284T0187 81205	1	21-53-12 P036-00/ /	ALL
K00060		BACR13CF2AB RELAY-MANUAL,EXIT DOOR CLOSE,LEFT PACK	284T0187 81205	1	21-53-12 P036-00/ /	ALL
K00061		BACR13CF2AB RELAY-MANUAL,INLET DOOR OPEN,LEFT PACK	284T0187 81205	1	21-53-12 P036-00/ /	ALL
K00062		BACR13CF2AB RELAY-MANUAL,INLET DOOR CLOSE,LEFT PACK	284T0187 81205	1	21-53-12 P036-00/ /	ALL
K00063		BACR13CF2AB RELAY-MANUAL,TEMP CONT VLV OPEN,L PACK	284T0187 81205	1	21-53-12 P036-00/ /	ALL
K00064		BACR13CF2AB RELAY-MANUAL,TEMP CONT VLV CLOSE,L PACK	284T0187 81205	1	21-53-12 P036-00/ /	ALL
K00069		BACR13CJ1 RELAY-LEFT ENTRY LT,FWD	285T0019 81205	1	33-22-11 P019-00/ /	ALL
K00073	1	600-154-2001 RELAY-TDC,PDU FWD ZONE DLY	284T0688 15420	1	25-53-25 P039-00/ /	050-099
K00073	2	600-154-2000M-0 RELAY-TDC,PDU FWD ZONE DLY	284T0688 15420	1	25-53-25 P039-00/ /	050-099

EQUIPMENT LIST

D280T132

Section K00000

Page 3

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00073	3	600-154-2S-0 RELAY-TDC,PDU FWD ZONE DLY	284T0688 15420	1	25-53-25 P039-00/ /	050-099
K00074	1	600-154-2001 RELAY-TDC,PDU AFT ZONE DLY	284T0688 15420	1	25-53-25 P039-00/ /	050-099
K00074	2	600-154-2000M-0 RELAY-TDC,PDU AFT ZONE DLY	284T0688 15420	1	25-53-25 P039-00/ /	050-099
K00074	3	600-154-2S-0 RELAY-TDC,PDU AFT ZONE DLY	284T0688 15420	1	25-53-25 P039-00/ /	050-099
K00076	1	600-154-2001 RELAY-TDC,PDU FWD ZONE DLY	284T0687 15420	1	25-53-15 P035-00/ /	050-099
K00076	2	600-154-2000M-0 RELAY-TDC,PDU FWD ZONE DLY	284T0687 15420	1	25-53-15 P035-00/ /	050-099
K00076	3	600-154-2S-0 RELAY-TDC,PDU FWD ZONE DLY	284T0687 15420	1	25-53-15 P035-00/ /	050-099
K00077	1	600-154-2001 RELAY-TDC,PDU AFT ZONE DLY	284T0687 15420	1	25-53-15 P035-00/ /	050-099
K00077	2	600-154-2000M-0 RELAY-TDC,PDU AFT ZONE DLY	284T0687 15420	1	25-53-15 P035-00/ /	050-099
K00077	3	600-154-2S-0 RELAY-TDC,PDU AFT ZONE DLY	284T0687 15420	1	25-53-15 P035-00/ /	050-099
K00079		BACR13CJ2 RELAY-GALLEY LTS CONT	285T0019 81205	1	33-27-11 P019-00/ /	ALL
K00081		BACR13CJ2 RELAY-GALLEY LTS CONT	285T0019 81205	1	33-27-11 P019-00/ /	ALL
K00082		KA-D9F-005 RELAY-GALLEY LTS CONT	285T0009 35344	1	33-27-11 P025-00/ /	050-099, 150-199
K00082		BACR13CJ2 RELAY-GALLEY LTS CONT	285T0009 81205	1	33-27-11 P025-00/ /	275-299
K00083		KA-D9F-005 RELAY-GALLEY LTS CONT	285T0009 35344	1	33-27-11 P025-00/ /	050-099, 150-199
K00083		BACR13CJ2 RELAY-GALLEY LTS CONT	285T0009 81205	1	33-27-11 P025-00/ /	275-299
K00087		BACR13CG2A RELAY-AIR/GND NO.1,AUTO. SPEED BRAKE	284T0189 81205	1	27-62-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00000

Page 4

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00088		BACR13CG2A RELAY-AIR/GND NO.2,AUTO. SPEED BRAKE	284T0189 81205	1	27-62-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00000
Page 5 End
Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00101		10-61445-24 RELAY-GND HANDLING	284T0175 74063	1	24-51-61 P034-00/ /	ALL
K00102		10-61445-23 RELAY-TRANSFER,GND SERVICE	284T0172 74063	1	24-51-51 P032-00/ /	ALL
K00103		10-61445-23 RELAY-SELECT,GND SERVICE	284T0175 74063	1	24-51-51 P034-00/ /	ALL
K00104		10-61445-21 RELAY-MAIN BAT.	284T0997 81205	1	24-33-11 P006-01/ /	ALL
K00105		E-308AH RELAY-AC STBY PWR	284T0997 74063	1	24-33-11 P006-01/ /	ALL
K00106		10-61445-21 RELAY-MAIN BAT. TFR	284T0997 81205	1	24-33-11 P006-01/ /	ALL
K00107		BACR13CG2A RELAY-CENTER BUS XFR	284T0997 81205	1	24-51-31 P006-01/ /	ALL
K00108		A-1077DD RELAY-TIE,DC	284T0997 74063	1	24-32-11 P006-02/ /	ALL
K00109		MS27743-6 RELAY-STBY PWR	284T0997 96906	1	24-33-11 P006-01/ /	ALL
K00110		BACR13CF2A RELAY-DC STBY BUS OFF	284T0997 81205	1	24-33-11 P006-01/ /	ALL
K00113		E-311P RELAY-UNDER VOLTAGE SENSE	284T0997 74063	1	24-33-11 P006-01/ /	ALL
K00114		S281T004-2 CONTACTOR-EXTERNAL POWER	284T0175 81205	1	24-41-11 P034-00/ /	ALL
K00115		BACR13CG2A RELAY-MAIN BAT. CHGR	284T0189 81205	1	24-31-11 P033-00/ /	ALL
K00116		BACR13CG2A RELAY-APU BAT. CHGR	284T1149 81205	1	24-31-41 P049-00/ /	ALL
K00117		A-703CD RELAY-CONTACTOR-APU CRANK	284T1149 74063	1	49-41-11 P049-00/ /	ALL
K00119		10-61445-21 RELAY-UTIL BUS,LEFT	284T0171 81205	1	24-51-13 P031-00/ /	ALL
K00120		10-61445-21 RELAY-UTIL BUS,RIGHT	284T0172 81205	1	24-51-23 P032-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00100

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00122		BACR13CF2AB RELAY-ISLN REQUEST	284T0997 81205	1	24-51-31 P006-01/ /	ALL
K00123		BACR13CG2A RELAY-CENTER BUS ISOL	284T0997 81205	1	24-51-31 P006-01/ /	ALL
K00124		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00126		BACR13CG2A RELAY-ELEC HYD PUMP R ON CONTROL	284T0189 81205	1	29-11-22 P033-00/ /	ALL
K00127		BACR13CF2A RELAY-ENG HYD PUMP,R PRESS. SENSE	284T0189 81205	1	29-11-22 P033-00/ /	ALL
K00128	9	BACR13CF2AB RLY-ELC HYD PMP R OFF CNTRL(SL-29-053-A)	284T0189 81205	1	29-11-22 P033-00/ /	ALL
K00128		BACR13CF2A RELAY-ELEC HYD PUMP R OFF CONTROL	284T0189 81205	1	29-11-22 P033-00/ /	ALL
K00130		BACR13CG2A RELAY-ELEC HYD PUMP L ON CONTROL	284T0188 81205	1	29-11-12 P037-00/ /	ALL
K00131		BACR13CF2A RELAY-ENG HYD PUMP,L PRESS. SENSE	284T0188 81205	1	29-11-12 P037-00/ /	ALL
K00134	9	BACR13CF2AB RLY-ELC HYD PMP L OFF CNTRL(SL-29-053-A)	284T0188 81205	1	29-11-12 P037-00/ /	ALL
K00134		BACR13CF2A RELAY-ELEC HYD PUMP L OFF CONTROL	284T0188 81205	1	29-11-12 P037-00/ /	ALL
K00135		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00137		M83726-3-155 RELAY-IRS DC POWER DISCONNECT	284T0997 35344	1	34-21-11 P006-01/ /	ALL
K00138		BACR13CJ2 RELAY-AC STBY BUS OFF	284T0997 81205	1	24-33-11 P006-01/ /	ALL
K00140		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00141		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00142		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00100

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00143		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00144		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00145		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00146		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00147		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00148		BACR13CE2 RELAY-BAT.,AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	050-099, 150-199, 280-299
K00149		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00153		BACR13CF2A RELAY-AIR HYD PUMP OFF CONTROL	284T0187 81205	1	29-11-32 P036-00/ /	ALL
K00158		KA-D9F-005 RELAY-BUS POWER SENSE NO.1,LEFT	233T5216 35344	1	74-31-11 P011-00/ /	ALL
K00159		KA-D9F-005 RELAY-BUS POWER SENSE NO.1,RIGHT	233T5216 35344	1	74-31-11 P011-00/ /	ALL
K00161		MS27751-1 RELAY-LANDING LIGHT DIMMING,L	284T0187 96906	1	33-42-11 P036-00/ /	ALL
K00162		MS27751-1 RELAY-LANDING LIGHT DIMMING,R	284T0188 96906	1	33-42-11 P037-00/ /	ALL
K00163		BACR13CG2A RELAY-FLIGHT RECORDER CONTROL	284T0187 81205	1	80-11-11 P036-00/ /	ALL
K00164		BACR13CG2A RELAY-FLIGHT RECORDER CONTROL	284T0188 81205	1	80-11-21 P037-00/ /	ALL
K00165	9	BACR13CF2A RELAY-T/R UNLOCK (SB 78-0062)	284T0187 81205	1	78-34-11 P036-00/ /	ALL
K00166	9	BACR13CF2A RELAY-T/R UNLOCK (SB 78-0062)	284T0188 81205	1	78-34-21 P037-00/ /	ALL
K00167		BACR13CG2A RELAY-AIR/GROUND BAT,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00100

Page 3

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00168		BACR13CG2A RELAY-FUEL/IGN CONTROL,LEFT	284T0187 81205	1	76-11-11 P036-00/ /	ALL
K00169		BACR13CG2A RELAY-FUEL/IGN CONTROL,RIGHT	284T0188 81205	1	76-11-11 P037-00/ /	ALL
K00170		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1 NOSE	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00172		D-18F RELAY-VACUUM BLOWER	284T0187 74063	1	38-32-11 P036-00/ /	ALL
K00173		D-18F RELAY-VACUUM BLOWER	284T1149 74063	1	38-32-11 P049-00/ /	ALL
K00174		BACR13CF2AB RELAY-WATER SYSTEM 28V PWR	284T1149 81205	1	38-15-11 P049-00/ /	ALL
K00175		BACR13CG2A RELAY-APU FUEL CONTROL	284T0188 81205	1	49-61-11 P037-00/ /	ALL
K00176		BACR13CF2A RELAY-APU INLET DOOR	284T1149 81205	1	49-15-11 P049-00/ /	ALL
K00177		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00178		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00179		BACR13CG2A RELAY-FUELING PWR CONT	284T0187 81205	1	28-21-11 P036-00/ /	ALL
K00180		TD-1047 RELAY-OVERFILL SET	284T0187 35344	1	28-21-12 P036-00/ /	ALL
K00181		BACR13CF2A RELAY-OVERFILL CONT	284T0187 81205	1	28-21-12 P036-00/ /	ALL
K00183		BACR13CF2A RELAY-FUELING VALVE CONT,L OUTBD	284T0187 81205	1	28-21-11 P036-00/ /	ALL
K00184		BACR13CF2A RELAY-FUELING VALVE CONT,L INBD	284T0187 81205	1	28-21-11 P036-00/ /	ALL
K00185		BACR13CF2A RELAY-FUELING VALVE CONT,R INBD	284T0187 81205	1	28-21-11 P036-00/ /	ALL
K00186		BACR13CF2A RELAY-FUELING VALVE CONT,R OUTBD	284T0187 81205	1	28-21-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00100

Page 4

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00187		MS27418-2B RELAY-FUEL BOOST PUMP CONT,L AFT	284T0187 81205	1	28-22-11 P036-00/ /	ALL
K00188		MS27418-2B RELAY-FUEL BOOST PUMP CONT,L FWD	284T0189 96906	1	28-22-11 P033-00/ /	ALL
K00189		MS27418-2B RELAY-FUEL BOOST PUMP CONT,R AFT	284T0188 96906	1	28-22-11 P037-00/ /	ALL
K00190		MS27418-2B RELAY-FUEL BOOST PUMP CONT,R FWD	284T0187 96906	1	28-22-11 P036-00/ /	ALL
K00191		10-60450-1 RELAY-DC FUEL PUMP CONT	284T0188 81205	1	28-25-11 P037-00/ /	ALL
K00192		BACR13CD2 RELAY-APU FUEL VALVE DISAGREE	284T0188 81205	1	28-25-21 P037-00/ /	ALL
K00197		BACR13CF2A RELAY-APU START	284T1149 81205	1	49-41-11 P049-00/ /	ALL
K00199		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00100

Page 5 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00200		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00201		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00202		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00203		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00204		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00205		BACR13CG2A RELAY-MSTR,AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00206		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00207		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00209		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00210		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00211		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00213		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00214		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00215		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2 NOSE	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00216		BACR13CE2 RLY-TRANSFER,FLAPS/REF	284T0189 81205	1	27-58-11 P033-00/ /	ALL
K00217		BACR13CF2A RELAY-EXT,AUTO. SPEED BRAKE	284T0189 81205	1	27-62-11 P033-00/ /	ALL
K00218		BACR13CF2A RELAY-RTR,AUTO. SPEED BRAKE	284T0189 81205	1	27-62-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00200

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00219		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2 NOSE	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00220		BACR13CD2 RELAY-AUTO SPEED BRAKE WRN	284T0189 81205	1	27-62-11 P033-00/ /	ALL
K00221		BACR13CC1 RELAY-EXT,ALT OUTBD SLAT	284T0188 81205	1	27-81-21 P037-00/ /	ALL
K00222		BACR13CC1 RELAY-RTR,ALT OUTBD SLAT	284T0188 81205	1	27-81-21 P037-00/ /	ALL
K00223		BACR13CC1 RELAY-ARM,ALT OUTBD SLAT	284T0188 81205	1	27-81-21 P037-00/ /	ALL
K00224		10-60450-1 RELAY-EXT,ALT INBD SLAT	284T0188 81205	1	27-81-11 P037-00/ /	ALL
K00225		10-60450-1 RELAY-RTR,ALT INBD SLAT	284T0188 81205	1	27-81-11 P037-00/ /	ALL
K00226		10-60450-1 RELAY-ARM,ALT INBD SLAT	284T0188 81205	1	27-81-11 P037-00/ /	ALL
K00227		BACR13CF2A RELAY-CONTROL,SLAT SHUTOFF VALVE	284T0187 81205	1	27-81-31 P036-00/ /	ALL
K00228		BACR13CF2AB RELAY-CARGO HEAT CONTROL,AFT	284T0187 81205	1	21-44-11 P036-00/ /	ALL
K00229		BACR13CF2AB RELAY-CARGO OVERHEAT,AFT	284T1149 81205	1	21-44-11 P049-00/ /	ALL
K00230		BACR13CF2AB RELAY-CARGO HEAT CONTROL,FWD	284T0187 81205	1	21-43-11 P036-00/ /	ALL
K00231		BACR13CF2AB RELAY-CARGO OVERHEAT,FWD	284T0188 81205	1	21-43-11 P037-00/ /	ALL
K00234		MS24184-D1 RELAY-RAM AIR TURBINE RETRACT	284T0660 96906	1	29-21-31 1155/129/R075	ALL
K00235		MS24184-D1 RELAY-RAM AIR TURBINE DEPLOY	284T0660 96906	1	29-21-31 1155/129/R075	ALL
K00236		MS24184-D1 RELAY-RAM AIR TURBINE OVERRIDE	284T0660 96906	1	29-21-31 1155/129/R075	ALL
K00238		BACR13CG2AB RELAY-ZONE DUCT OVERHEAT,FLT DECK	284T0188 81205	1	21-61-11 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00200

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00239		BACR13CG2AB RELAY-ZONE DUCT OVERHEAT,FWD	284T0188 81205	1	21-61-21 P037-00/ /	ALL
K00240		BACR13CG2AB RELAY-ZONE DUCT OVERHEAT,AFT	284T0188 81205	1	21-61-31 P037-00/ /	ALL
K00241		770-540-1 RELAY-CURRENT SENSING,CAPT P/S	284T0189 F0553	1	30-31-11 P033-00/ /	ALL
K00243		770-540-1 RELAY-CURRENT SENSING,R AUX P/S	284T0189 F0553	1	30-31-13 P033-00/ /	ALL
K00245		10-61445-21 RELAY-CARGO HDLG SYS PWR	284T3501 81205	1	25-53-11 P035-00/ /	ALL
K00246		BACR13CD2 RELAY-PDU 1L CONT	284T3501 81205	1	25-53-14 P035-00/ /	ALL
K00247		BACR13CD2 RELAY-PDU 1R CONT	284T3501 81205	1	25-53-14 P035-00/ /	ALL
K00256		BACR13CD2 RELAY-PDU 10L CONT	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00257		BACR13CD2 RELAY-PDU 10R CONT	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00262		BACR13CE2 RELAY-PDU AFT DRIVE	284T3501 81205	1	25-53-13 P035-00/ /	ALL
K00264		BACR13CG2AB RELAY-AFT LATERAL GUIDES DOWN	284T3501 81205	1	25-53-15 P035-00/ /	ALL
K00265		BACR13CG2AB RELAY-LD2 GUIDES DOWN	284T3501 81205	1	25-53-16 P035-00/ /	ALL
K00266		BACR13CG2AB RELAY-FWD LATERAL GUIDES DOWN	284T3501 81205	1	25-53-15 P035-00/ /	ALL
K00267		BACR13CG2AB RELAY-LD3 GUIDES UP	284T3501 81205	1	25-53-16 P035-00/ /	ALL
K00268	1	600-154-1251 RELAY-TDC,BAY A UNL DLY	284T3501 15420	1	25-53-14 P035-00/ /	ALL
K00268	2	600-154-1250M-0 RELAY-TDC,BAY A UNL DLY	284T3501 15420	1	25-53-14 P035-00/ /	ALL
K00270	1	600-154-6000 RELAY-TDC,BAY B UNL DLY	284T0687 15420	1	25-53-14 P035-00/ /	050-099

EQUIPMENT LIST

D280T132

Section K00200

Page 3

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00270	1	600-154-8000 RELAY-TDC,BAY B UNL DLY	284T3501 15420	1	25-53-14 P035-00/ /	150-199, 275-299
K00270	2	600-154-600M-0 RELAY-TDC,BAY B UNL DLY	284T0687 15420	1	25-53-14 P035-00/ /	050-099
K00270	2	600-154-800M-0 RELAY-TDC,BAY B UNL DLY	284T3501 15420	1	25-53-14 P035-00/ /	150-199, 275-299
K00274	1	600-154-2000 RELAY-TDC,BAY E LDG DLY	284T3501 15420	1	25-53-14 P035-00/ /	150-199, 275-299
K00274	2	600-154-200M-0 RELAY-TDC,BAY E LDG DLY	284T3501 15420	1	25-53-14 P035-00/ /	150-199, 275-299
K00275	1	600-154-1251 RELAY-TDC,BAY E UNL DLY	284T3501 15420	1	25-53-14 P035-00/ /	ALL
K00275	2	600-154-1250M-0 RELAY-TDC,BAY E UNL DLY	284T3501 15420	1	25-53-14 P035-00/ /	ALL
K00278		10-61445-21 RELAY-CAR. HDLG SYS PWR	284T3901 81205	1	25-53-21 P039-00/ /	ALL
K00279		BACR13CD2 RELAY-PDU 1L CONT	284T3901 81205	1	25-53-24 P039-00/ /	ALL
K00280		BACR13CD2 RELAY-PDU 1R CONT	284T3901 81205	1	25-53-24 P039-00/ /	ALL
K00281		BACR13CD2 RELAY-PDU 2L CONT	284T3901 81205	1	25-53-24 P039-00/ /	ALL
K00282		BACR13CD2 RELAY-PDU 2R CONT	284T3901 81205	1	25-53-24 P039-00/ /	ALL
K00283		BACR13CD2 RELAY-PDU 3L/4L CONT	284T3901 81205	1	25-53-24 P039-00/ /	ALL
K00284		BACR13CD2 RELAY-PDU 3R/4R CONT	284T3901 81205	1	25-53-24 P039-00/ /	ALL
K00285		BACR13CG2AB RELAY-PDU 5L/7L CONT	284T0688 81205	1	25-53-24 P039-00/ /	050-099
K00286		BACR13CG2AB RELAY-PDU 5R/7R CONT	284T0688 81205	1	25-53-24 P039-00/ /	050-099
K00287		BACR13CD2 RELAY-PDU 8L/9L CONT	284T0688 81205	1	25-53-24 P039-00/ /	050-099

EQUIPMENT LIST

D280T132

Section K00200

Page 4

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00288		BACR13CD2 RELAY-PDU 8R/9R CONT	284T0688 81205	1	25-53-24 P039-00/ /	050-099
K00289		BACR13CG2AB RELAY-PDU 6L/6C/6R CONT	284T0688 81205	1	25-53-24 P039-00/ /	050-099
K00292		BACR13CE2 RELAY-PDU AFT DRIVE	284T3901 81205	1	25-53-23 P039-00/ /	ALL
K00293		BACR13CE2 RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00294		BACR13CG2AB RELAY-AFT LATL GUIDES DOWN	284T3901 81205	1	25-53-25 P039-00/ /	ALL
K00295		BACR13CG2AB RELAY-LD2 GUIDES DN	284T3901 81205	1	25-53-26 P039-00/ /	ALL
K00296		BACR13CG2AB RELAY-FWD LATL GUIDES DN	284T3901 81205	1	25-53-25 P039-00/ /	ALL
K00297		BACR13CG2AB RELAY-LD3 GUIDES UP	284T3901 81205	1	25-53-26 P039-00/ /	ALL
K00298	1	600-154-2501 RELAY-TDC,BAY A UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	ALL
K00298	2	600-154-2500M-0 RELAY-TDC,BAY A UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00200
Page 5 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00300	1	600-154-4000 RELAY-TDC,BAY C UNL DLY	284T0688 15420	1	25-53-24 P039-00/ /	050-099
K00300	1	600-154-2501 RELAY-TDC,BAY C UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00300	2	600-154-400M-0 RELAY-TDC,BAY C UNL DLY	284T0688 15420	1	25-53-24 P039-00/ /	050-099
K00300	2	600-154-2500M-0 RELAY-TDC,BAY C UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00301	1	600-154-4000 RELAY-TDC,BAY D FWD DIR DLY	284T0688 15420	1	25-53-24 P039-00/ /	050-099
K00301	2	600-154-400M-0 RELAY-TDC,BAY D FWD DIR DLY	284T0688 15420	1	25-53-24 P039-00/ /	050-099
K00302	1	600-154-2000 RELAY-TDC,BAY D AFT DIR DLY	284T0688 15420	1	25-53-24 P039-00/ /	050-099
K00302	2	600-154-200M-0 RELAY-TDC,BAY D AFT DIR DLY	284T0688 15420	1	25-53-24 P039-00/ /	050-099
K00303	1	600-154-6000 RELAY-TDC,PDU BAY E UNL DLY	284T0688 15420	1	25-53-24 P039-00/ /	050-099
K00303	1	600-154-4000 RELAY-TDC,PDU BAY E UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00303	2	600-154-600M-0 RELAY-TDC,PDU BAY E UNL DLY	284T0688 15420	1	25-53-24 P039-00/ /	050-099
K00303	2	600-154-400M-0 RELAY-TDC,PDU BAY E UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00304	1	600-154-1251 RELAY-TDC,BAY B UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	ALL
K00304	2	600-154-1250M-0 RELAY-TDC,BAY B UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	ALL
K00310		770-540-1 RELAY-CURRENT SENSING,F/O P/S	284T0189 F0553	1	30-31-21 P033-00/ /	ALL
K00312		770-540-1 RELAY-CURRENT SENSING,L AUX P/S	284T0189 F0553	1	30-31-23 P033-00/ /	ALL
K00315		BACR13CJ2 RELAY-AFT DIRECT CEILING LTS	285T0009 81205	1	33-22-42 P025-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00300

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00316		BACR13CJ2 RELAY-AFT DIRECT CEILING LTS	285T0009 81205	1	33-22-42 P025-00/ /	ALL
K00317		BACR13CJ2 RELAY-AFT DIRECT CEILING LTS	285T0009 81205	1	33-22-42 P025-00/ /	275-299
K00319		TD-1782-2001 RELAY-T/D,WING TAI CONT	284T0189 35344	1	30-11-11 P033-00/ /	ALL
K00321		BACR13CJ2 RELAY-OUTBD INDIRECT CEILING LTS,FWD	285T0019 81205	1	33-21-11 P019-00/ /	ALL
K00322		BACR13CJ2 RELAY-INBD INDIRECT CEILING LTS,FWD	285T0019 81205	1	33-21-11 P019-00/ /	ALL
K00323		BACR13CJ2 RELAY-LT FLEXIBILITY	285T0019 81205	1	33-21-11 P019-00/ /	275-299
K00325		BACR13CJ2 RELAY-LT FLEXIBILITY	285T0019 81205	1	33-21-11 P019-00/ /	275-299
K00327		KA-D9F-005 RELAY-INBD INDIRECT CEILING LTS,AFT	285T0009 35344	1	33-21-12 P025-00/ /	ALL
K00328		KA-D9F-005 RELAY-OUTBD INDIRECT CEILING LTS,AFT	285T0009 35344	1	33-21-12 P025-00/ /	ALL
K00329		MS27418-2B RELAY-FUEL OVRD PUMP CONT,L	284T0187 96906	1	28-22-12 P036-00/ /	ALL
K00330		MS27418-2B RELAY-FUEL OVRD PUMP CONT,R	284T0188 96906	1	28-22-12 P037-00/ /	ALL
K00331		BACR13CE2 RELAY-SMK DET BLO 1 CONT FWD CAR.	284T0687 81205	1	26-16-21 P035-00/ /	ALL
K00332		BACR13CE2 RELAY-SMK DET BLO 1 CONT,AFT CAR.	284T0687 81205	1	26-16-21 P035-00/ /	ALL
K00333		600-154-6002 RELAY-TDC,SMK DET BLO 1 DLY,FWD CAR.	284T0687 15420	1	26-16-21 P035-00/ /	ALL
K00334		600-154-6002 RELAY-TDC,SMK DET BLO 1 DLY,AFT CAR.	284T0687 15420	1	26-16-21 P035-00/ /	ALL
K00336		BACR13CF2AB RELAY-INBOARD SUPPLY VALVE	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K00340		BACR13CG2AB RELAY-OVERBOARD EXHAUST VALVE	284T0187 81205	1	21-58-13 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00300

Page 2

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00343		10-61445-21 RELAY-EQUIP COOLING SUPPLY FAN NO.1	284T0187 81205	1	21-58-14 P036-00/ /	ALL
K00345		10-61445-21 RELAY-FWD EQUIP COOLING EXHAUST FAN	284T0188 81205	1	21-58-15 P037-00/ /	ALL
K00346		10-61445-21 RELAY-AFT EQUIP/LAV/GALLEY VENT FAN 1	284T0188 81205	1	21-26-11 P037-00/ /	ALL
K00347		10-61445-21 RELAY-AFT EQUIP/LAV/GALLEY VENT FAN 2	284T0187 81205	1	21-26-11 P036-00/ /	ALL
K00348		BACR13CF2A RELAY-FAIL PROTECTION & ASYM,INBD SLAT	284T0188 81205	1	27-81-11 P037-00/ /	ALL
K00349		BACR13CF2A RELAY-FAIL PROTECTION & ASYM,OUTBD SLAT	284T0188 81205	1	27-81-21 P037-00/ /	ALL
K00350		BACR13CF2A RELAY-FAIL PROTECTION & ASYM,FLAP	284T0189 81205	1	27-51-11 P033-00/ /	ALL
K00351		BACR13CF2A RELAY-SHUTOFF TE FLAPS	284T0187 81205	1	27-51-31 P036-00/ /	ALL
K00352		BACR13CF2A RELAY-CONTROL FLAP LOAD RELIEF	284T0189 81205	1	27-51-51 P033-00/ /	ALL
K00353		BACR13CD2 RLY-FLAPS INTMD/RETRACT REF	284T0189 81205	1	27-58-11 P033-00/ /	ALL
K00356		BACR13CG2A RELAY-FUEL QTY PWR TRANS	284T0187 81205	1	28-41-12 P036-00/ /	ALL
K00357		BACR13CG2A RLY-FUELING PWR TRANS	284T0187 81205	1	28-21-11 P036-00/ /	ALL
K00358		KA-D9F-005 RELAY-DIRECT LTS CONT	285T0019 35344	1	33-22-41 P019-00/ /	ALL
K00359		10-61445-21 RELAY-EXT,ALTERNATE TE FLAPS	284T0189 81205	1	27-51-11 P033-00/ /	ALL
K00360		10-61445-21 RELAY-RTR,ALTERNATE TE FLAPS	284T0189 81205	1	27-51-11 P033-00/ /	ALL
K00361		10-61445-21 RELAY-ARM,ALTERNATE TE FLAPS	284T0189 81205	1	27-51-11 P033-00/ /	ALL
K00364		KA-D9F-005 RELAY-SIDEWALL LTS	285T0019 35344	1	33-21-31 P019-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00300

Page 3

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00365		KA-D9F-005 RELAY-SIDEWALL LTS	285T0019 35344	1	33-21-31 P019-00/ /	ALL
K00368		BACR13CF2AB RELAY-AFT EXHAUST FAN 1 BUS XFR	284T0188 81205	1	21-26-11 P037-00/ /	ALL
K00369		BACR13CG2AB RELAY-EQUIP COOLING SMOKE CLEARANCE	284T0187 81205	1	21-58-16 P036-00/ /	ALL
K00370		BACR13CF2A RELAY-EMER LTS,RIGHT EXTERNAL	285T0019 81205	1	33-51-21 P019-00/ /	ALL
K00371		BACR13CF2A RELAY-EMER LTS,LEFT EXTERNAL	285T0019 81205	1	33-51-21 P019-00/ /	ALL
K00372		KA-D9F-005 RELAY-HEATERS,WATER LINE	284T0189 35344	1	30-71-21 P033-00/ /	ALL
K00373		BACR13CJ2 RELAY-HEATERS,WATER LINE	284T0189 81205	1	30-71-21 P033-00/ /	ALL
K00374		KA-D9F-005 RELAY-HEATERS,WATER LINE	284T0189 35344	1	30-71-22 P033-00/ /	ALL
K00376		KA-D9F-005 RELAY-HEATERS,WATER LINE	284T0189 35344	1	30-71-23 P033-00/ /	ALL
K00380		TD-1782-2001 RELAY-FWD ENTRY DR UP NO.2	285T0019 35344	1	52-11-12 P019-00/ /	ALL
K00381		BACR13CJ1 RELAY-NIGHT LTS FWD	285T0019 81205	1	33-21-21 P019-00/ /	ALL
K00382		BACR13CJ2 RELAY-NIGHT LTS AFT	285T0009 81205	1	33-21-21 P025-00/ /	ALL
K00383		BACR13CG2A RELAY-SEAT BELT SIGNS	285T0019 81205	1	33-24-11 P019-00/ /	ALL
K00384		BACR13CG2A RELAY-NO SMOKING SIGNS	285T0019 81205	1	33-24-11 P019-00/ /	ALL
K00385		BACR13CG2A RELAY-PASS. SIGNS DECOMPRESSION	285T0019 81205	1	33-24-11 P019-00/ /	ALL
K00396		10-60450-2 RELAY-STANDBY INSTR LTG	233T2402 81205	1	33-13-11 0151/212/L005	ALL
K00398		BACR13CJ2 RELAY-HEATERS,WATER LINE	284T0188 81205	1	30-71-24 P037-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section K00300

Page 4 End

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00400		770-540-1 RELAY-CURRENT SENSING,L AOA PROBE	284T0189 F0553	1	30-32-11 P033-00/ /	ALL
K00401		770-540-1 RELAY-CURRENT SENSING,R AOA PROBE	284T0189 F0553	1	30-32-21 P033-00/ /	ALL
K00402		770-540-1 RELAY-CURRENT SENSING,LEFT ENGINE PROBE	284T0189 F0553	1	30-34-11 P033-00/ /	ALL
K00403		770-540-1 RELAY-CURRENT SENSING,RIGHT ENGINE PROBE	284T0189 F0553	1	30-34-21 P033-00/ /	ALL
K00411		770-540-1 RELAY-CURRENT SENSING,L TAT PROBE	284T0189 F0553	1	30-33-11 P033-00/ /	ALL
K00414		BACR13CG2A RELAY-WING TAI CONT	284T0189 81205	1	30-11-11 P033-00/ /	ALL
K00415		10-61445-21 RELAY-RECIRC FAN,LEFT	284T0187 81205	1	21-25-11 P036-00/ /	ALL
K00416		10-61445-21 RELAY-RECIRC FAN,RIGHT	284T0188 81205	1	21-25-21 P037-00/ /	ALL
K00417		BACR13CG2A RELAY-ENTRY DR UP,FWD NO.1	285T0019 81205	1	52-11-12 P019-00/ /	ALL
K00418		BACR13CG2A RELAY-ENTRY DR DN,FWD	285T0019 81205	1	52-11-12 P019-00/ /	ALL
K00419		BACR13CE2 RELAY-PARK BRAKE CLOSE SENSE	284T0187 81205	1	32-44-11 P036-00/ /	ALL
K00420		083-20229-01 INTERRUPTER-APU HORN	284T0299 95266	1	26-15-12 0280/177/R027	ALL
K00421		BACR13CG2A RELAY-EXTERNAL SHUTDOWN	284T0188 81205	1	49-61-11 P037-00/ /	ALL
K00422		10-60450-6 RELAY-AFT CARGO DOOR LT ENABLE	284T0688 81205	1	33-37-21 P039-00/ /	ALL
K00423		BACR13CF2AB RELAY-AFT CARGO COMPT LTS ENABLE	284T0688 81205	1	33-37-21 P039-00/ /	ALL
K00433		BACR13CF2A RELAY-R IDLE SOLENOID	284T0188 81205	1	73-21-19 P037-00/ /	ALL
K00434		BACR13CF2A RELAY-L IDLE SOLENOID	284T0187 81205	1	73-21-19 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00400

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00435		MS27751-1 RELAY-LIGHTS,NOSE GEAR LANDING	284T0187 96906	1	33-42-11 P036-00/ /	ALL
K00442		BACR13CD2 RELAY-APU FAULT	284T0188 81205	1	49-61-11 P037-00/ /	ALL
K00443		BACR13CF2A RELAY-AIR HYD PUMP ON	284T0187 81205	1	29-11-32 P036-00/ /	ALL
K00449		BACR13CD2 RELAY-L DEFUEL VALVE IND	284T0187 81205	1	28-26-11 P036-00/ /	ALL
K00450		BACR13CD2 RELAY-R DEFUEL VALVE IND	284T0187 81205	1	28-26-11 P036-00/ /	ALL
K00452		BACR13CF2A RELAY-L DEFUEL VALVE CONTROL	284T0187 81205	1	28-26-11 P036-00/ /	ALL
K00453		BACR13CF2A RELAY-R DEFUEL VALVE CONTROL	284T0187 81205	1	28-26-11 P036-00/ /	ALL
K00455	1	600-159-5001 RELAY-TIME DELAY,OXYGEN CONTROL	284T1900 15420	1	35-21-11 P019-00/ /	ALL
K00455	2	600-159-5S-0 RELAY-TIME DELAY,OXYGEN CONTROL	284T1900 15420	1	35-21-11 P019-00/ /	ALL
K00458		BACR13CC1 RLY-PSS PWR,FWD	284T0189 81205	1	23-34-11 P033-00/ /	ALL
K00459		BACR13CC1 RELAY-PSS PWR,AFT	284T0189 81205	1	23-34-11 P033-00/ /	ALL
K00460		BACR13CF2AB RELAY-PES PWR	284T0189 81205	1	23-34-11 P033-00/ /	ALL
K00466	1	600-159-5001 RELAY-TIME DELAY,OXY CONT MANUAL DEPLOY	284T1900 15420	1	35-21-11 P019-00/ /	ALL
K00466	2	600-159-5S-0 RELAY-TIME DELAY,OXY CONT MANUAL DEPLOY	284T1900 15420	1	35-21-11 P019-00/ /	ALL
K00488		BACR13CF2AB RELAY-ROLLOUT HOOK LOCK	284T3501 81205	1	25-53-17 P035-00/ /	ALL
K00489		BACR13CF2AB RELAY-ROLLOUT STOPS DN	284T3501 81205	1	25-53-17 P035-00/ /	ALL
K00490		BACR13CF2AB RELAY-ROLLOUT HOOK LOCK	284T3901 81205	1	25-53-27 P039-00/ /	150-199

EQUIPMENT LIST

D280T132

Section K00400

Page 2

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00491		BACR13CF2AB RELAY-ROLLOUT STOPS	284T3901 81205	1	25-53-27 P039-00/ /	150-199
K00494		BACR13CG2AB RELAY-LEFT BLEED AIR ENGINE START	284T0189 81205	1	36-11-51 P033-00/ /	ALL
K00495		BACR13CG2AB RELAY-RIGHT BLEED AIR ENGINE START	284T0188 81205	1	36-11-52 P037-00/ /	ALL
K00496		BACR13CG2AB RELAY-APU AIR SUPPLY OVERRIDE	284T0188 81205	1	36-11-41 P037-00/ /	ALL
K00497		BACR13CF2AB RELAY-CARGO HEAT FLOW CONTROL,BULK	284T0187 81205	1	21-44-21 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00400

Page 3 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00504		BACR13CG2AB RELAY-CARGO VENT FAN CONTROL,BULK	284T0188 81205	1	21-26-21 P037-00/ /	ALL
K00505		BACR13CE2 RELAY-APU FUEL PUMP TRANS	284T0188 81205	1	28-25-11 P037-00/ /	ALL
K00506		BACR13CD2 RELAY-CAR. DOOR OPEN ENBL	284T3501 81205	1	25-53-11 P035-00/ /	ALL
K00507		BACR13CD2 RELAY-CAR. DOOR OPEN ENBL	284T3901 81205	1	25-53-21 P039-00/ /	ALL
K00510		BACR13CF2A RELAY-IRS SELECT,RIGHT	284T0188 81205	1	32-42-11 P037-00/ /	ALL
K00511		BACR13CF2A RELAY-IRS SELECT,LEFT	284T0187 81205	1	32-42-11 P036-00/ /	ALL
K00512		TD-1047-10S RELAY-L FWD PUMP START	284T0188 35344	1	28-25-11 P037-00/ /	ALL
K00513		BACR13CJ2 RELAY-L FWD PUMP PWR SENSE	284T0189 81205	1	28-22-11 P033-00/ /	ALL
K00514		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00515		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00516		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00517		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00518		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00520		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00522		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00523		BACR13CD2 RELAY-APU ISLN VALVE DISAGREE	284T0188 81205	1	28-25-31 P037-00/ /	ALL
K00524		BACR13CJ2 RELAY-DIRECT LTS CONT	285T0019 81205	1	33-22-41 P019-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00500

Page 1

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00525		10-60450-1 RELAY-GASPER FAN	284T0187 81205	1	21-24-11 P036-00/ /	050-099, 150-199
K00526		BACR13CG2AB RELAY-AUTOLAND,LEFT	284T0171 81205	1	24-51-31 P031-00/ /	ALL
K00527		BACR13CG2AB RELAY-AUTOLAND,RIGHT	284T0172 81205	1	24-51-31 P032-00/ /	ALL
K00528		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00529		BACR13CG2A RELAY-BAT.,AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00542		BACR13CF2AB RELAY-FWD/OUT DRIVE	284T3501 81205	1	25-53-14 P035-00/ /	ALL
K00543		BACR13CF2AB RELAY-AFT/IN DRIVE	284T3501 81205	1	25-53-14 P035-00/ /	ALL
K00544		BACR13CF2AB RELAY-FWD/OUT DRIVE	284T3901 81205	1	25-53-24 P039-00/ /	ALL
K00545		BACR13CF2AB RELAY-AFT/IN DRIVE	284T3901 81205	1	25-53-24 P039-00/ /	ALL
K00546		BACR13CF2A RLY-LAVATORY FLUSH CONTROL	284T0187 81205	1	38-32-12 P036-00/ /	050-099, 150-155, 162-165
K00546		BACR13CF2A RLY-LAVATORY FLUSH CONTROL	284T0187 81205	1	38-32-11 P036-00/ /	156-157, 166-199, 275-299
K00547		BACR13CD2 RELAY-APU INLET DOOR OPEN	284T1149 81205	1	49-15-11 P049-00/ /	ALL
K00550		BACR13CD2 RLY-LDG GEAR TILT PRESS.	284T0189 81205	1	27-62-11 P033-00/ /	ALL
K00551		BACR13CF2A RELAY-TAXI LIGHT,NOSE GEAR	284T0187 81205	1	33-42-21 P036-00/ /	ALL
K00552		BACR13CG2A RELAY-AIR/GROUND,SYS NO.1	284T0189 81205	1	32-09-13 P033-00/ /	ALL
K00553		BACR13CF2AB RELAY-CARGO DOOR NOT CLOSED	284T3501 81205	1	33-37-11 P035-00/ /	ALL
K00554		BACR13CD2 RELAY-FLT REC ADC I/P SWITCHING	284T0188 81205	1	31-31-12 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00500

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00576		BACR13CD2 RELAY-PDU 2R CONT	284T3501 81205	1	25-53-13 P035-00/ /	ALL
K00577		BACR13CD2 RELAY-PDU 2L/3L CONT	284T3501 81205	1	25-53-14 P035-00/ /	ALL
K00578		BACR13CG2AB RELAY-PDU 4R/6R CONT	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00578		BACR13CD2 RELAY-PDU 4R/6R CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00579		BACR13CG2AB RELAY-PDU 4L/6L CONT	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00579		BACR13CD2 RELAY-PDU 4L/6L CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00580		BACR13CG2AB RELAY-PDU 5R/5C/5L CONT	284T3501 81205	1	25-53-14 P035-00/ /	ALL
K00581		BACR13CD2 RELAY-PDU 7R/9R CONT	284T3501 81205	1	25-53-14 P035-00/ /	ALL
K00582		BACR13CG2AB RELAY-PDU 7L/9L CONT	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00582		BACR13CD2 RELAY-PDU 7L/9L CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00583		BACR13CG2AB RELAY-PDU 8R/8C/8L CONT	284T3501 81205	1	25-53-14 P035-00/ /	ALL
K00584		BACR13CD2 RELAY-PDU 11R	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00585		BACR13CD2 RELAY-PDU 11L	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00586		KA-D9F-005 RELAY-PWR TRANSFER,LOGO LTS	284T0188 35344	1	33-45-11 P037-00/ /	ALL
K00587		KA-D9F-005 RELAY-CONTROL,LOGO LIGHT	284T0188 35344	1	33-45-11 P037-00/ /	ALL
K00589	1	600-154-4000 RELAY-TDC,BAY C FWD DIR	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00589	1	600-154-2000 RELAY-TDC,BAY C FWD DIR	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section K00500

Page 3

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00589	2	600-154-400M-0 RELAY-TDC,BAY C FWD DIR	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00589	2	600-154-200M-0 RELAY-TDC,BAY C FWD DIR	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00590	1	600-154-4000 RELAY-TDC,BAY C AFT DIR	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00590	1	600-154-6000 RELAY-TDC,BAY C AFT DIR	284T0687 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00590	2	600-154-400M-0 RELAY-TDC,BAY C AFT DIR	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00590	2	600-154-600M-0 RELAY-TDC,BAY C AFT DIR	284T0687 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00591	1	600-154-2000 RELAY-TDC,BAY D LDG DLY	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00591	1	600-154-4000 RELAY-TDC,BAY D LDG DLY	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00591	2	600-154-200M-0 RELAY-TDC,BAY D LDG DLY	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00591	2	600-154-400M-0 RELAY-TDC,BAY D LDG DLY	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00592	1	600-154-6000 RELAY-TDC,BAY D UNL DLY	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00592	1	600-154-4000 RELAY-TDC,BAY D UNL DLY	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00592	2	600-154-600M-0 RELAY-TDC,BAY D UNL DLY	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00592	2	600-154-400M-0 RELAY-TDC,BAY D UNL DLY	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00593	1	600-154-2000 RELAY-TDC,BAY B LDG DLY	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00593	2	600-154-200M-0 RELAY-TDC,BAY B LDG DLY	284T0687 81205	1	25-53-14 P035-00/ /	050-099
K00595		BACR13CF2AB RELAY-ROLLOUT HOOK LOCK,BAY C	284T3501 81205	1	25-53-17 P035-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00500

Page 4

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00596		BACR13CF2AB RELAY-ROLLOUT STOPS,BAY C	284T3501 81205	1	25-53-17 P035-00/ /	ALL
K00598		X-D4N RELAY-PSU A FAULT	285T0007 35344	1	31-51-11 P051-00/ /	ALL
K00599		X-D4N RELAY-PSU B FAULT	285T0007 35344	1	31-51-12 P051-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00500
Page 5 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00600		BACR13CG2AB RELAY-PALLET SELECT	284T0687 81205	1	25-53-13 P035-00/ /	050-099
K00600		BACR13CD2 RELAY-PALLET SELECT	284T3501 81205	1	25-53-13 P035-00/ /	150-199, 275-299
K00603		KL-X4A-011 RLY-AIR HYD PUMP OVERSPEED MAG LATCH	284T0187 58657	1	29-11-32 P036-00/ /	ALL
K00607		KA-D9F-005 RELAY-BUS POWER SENSE #2,LEFT	233T5216 35344	1	74-31-11 P011-00/ /	ALL
K00608		KA-D9F-005 RELAY-BUS POWER SENSE #2,RIGHT	233T5216 35344	1	74-31-11 P011-00/ /	ALL
K00614		770-540-1 RELAY-CURRENT SNSR,BULK CARGO VENT FAN	284T0188 F0553	1	21-26-21 P037-00/ /	ALL
K00615		BACR13CJ2 RELAY-APU TRU ENABLE	284T1149 81205	1	24-32-41 P049-00/ /	275-299
K00616		BACR13CF2A RELAY-TRU OVERHEAT	284T1149 81205	1	24-32-41 P049-00/ /	275-299
K00617		BACR13CF2A RELAY-APU BAT/TRU SELECT	284T1149 81205	1	24-32-41 P049-00/ /	275-299
K00618		10-61445-21 RELAY-TRU APU START	284T1149 81205	1	24-32-41 P049-00/ /	275-278
K00618		HTC7N-060 RELAY-TRU APU START	284T1149 35344	1	24-32-41 P049-00/ /	280-299
K00619		10-60450-2 RELAY-TRU FAN CONTROL	284T1149 81205	1	24-32-41 P049-00/ /	275-299
K00622		MS27751-1 RELAY-LOAD SHED	284T0189 96906	1	24-51-52 P033-00/ /	ALL
K00623		BACR13CF2A RELAY-FLAP BYPASS VALVE NORMAL	284T0189 81205	1	27-51-11 P033-00/ /	ALL
K00624		BACR13CF2A RELAY-INBOARD SLAT BYPASS VALVE NORMAL	284T0188 81205	1	27-81-11 P037-00/ /	ALL
K00625		BACR13CF2A RELAY-OUTBOARD SLAT BYPASS VALVE NORMAL	284T0188 81205	1	27-81-21 P037-00/ /	ALL
K00626		BACR13CE2 RELAY-EQUIP COOLING TEST	284T0188 81205	1	21-58-11 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00600

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00629		BACR13CE2 RELAY-EQUIP COOL STANDBY	284T0188 81205	1	21-58-14 P037-00/ /	ALL
K00631		BACR13CF2A RELAY-APU REMOTE FIRE INDICATION	284T0188 81205	1	26-15-12 P037-00/ /	ALL
K00632		BACR13CG2A RELAY-DC PUMP AUTO ON	284T0188 81205	1	28-25-31 P037-00/ /	ALL
K00633		BACR13CD2 RELAY-GROUND ENABLE, OVERRIDE PUMPS	284T0187 81205	1	28-22-12 P036-00/ /	ALL
K00634		BACR13CG2AB RELAY-CARGO FIRE OVERRIDE, AFT/BULK	284T0189 81205	1	21-44-11 P033-00/ /	ALL
K00642		BACR13CD2 RELAY-DOOR LOCK POWER SENSING	285T0019 81205	1	52-51-11 P019-00/ /	ALL
K00643		BACR13CG2A RELAY-TEST, L PROBE HT	284T0189 81205	1	30-31-11 P033-00/ /	ALL
K00644		BACR13CG2A RELAY-L PROBE HT	284T0189 81205	1	30-31-11 P033-00/ /	ALL
K00645		BACR13CG2A RELAY-TEST, R PROBE HT	284T0189 81205	1	30-31-21 P033-00/ /	ALL
K00646		BACR13CG2A RELAY-R PROBE HT	284T0189 81205	1	30-31-21 P033-00/ /	ALL
K00648		BACR13CF2A RELAY-PROBE HT L N2	284T0189 81205	1	30-34-11 P033-00/ /	ALL
K00649		TD-1782-2001 RELAY-T/D, R ENG TAI CONT	284T0188 35344	1	30-21-11 P037-00/ /	ALL
K00650		TD-1782-2001 RELAY-T/D, L ENG TAI CONT	284T0187 35344	1	30-21-11 P036-00/ /	ALL
K00651		BACR13CD2 RELAY-GEAR DISAGREE	284T0112 81205	1	32-61-14 SHELF/E01/02	ALL
K00652		BACR13CD2 RELAY-GEAR DOORS	284T0112 81205	1	32-61-14 SHELF/E01/02	ALL
K00665		BACR13CG2A RELAY-L ENG START 1	284T0997 81205	1	80-11-11 P006-05/ /	ALL
K00666		BACR13CG2A RELAY-R ENG START 1	284T0997 81205	1	80-11-21 P006-05/ /	ALL

EQUIPMENT LIST

D280T132

Section K00600

Page 2

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00670		BACR13CF2A RELAY-PROBE HT R N2	284T0189 81205	1	30-34-21 P033-00/ /	ALL
K00671		BACR13CF2AB RELAY-VIDEO/ANNCT	284T0125 81205	1	23-31-12 SHELF/E02/05	275-299
K00676		BACR13CF2A RELAY-NACELLE COOLING VALVE DISAGREE,L	284T0187 81205	1	75-23-11 P036-00/ /	ALL
K00677		BACR13CF2A RELAY-NACELLE COOLING VALVE DISAGREE,R	284T0188 81205	1	75-23-11 P037-00/ /	ALL
K00680		BACR13CF2A RELAY-L ENG START SENSE	284T0188 81205	1	80-11-11 P037-00/ /	ALL
K00681		BACR13CF2A RELAY-R ENG START SENSE	284T0188 81205	1	80-11-21 P037-00/ /	ALL
K00684		BACR13CF2A RELAY-ADP ON DEMAND	284T0187 81205	1	29-11-32 P036-00/ /	ALL
K00693		BACR13CE2 RELAY-WHEEL WELL FIRE IND	284T0188 81205	1	26-17-11 P037-00/ /	ALL
K00694		BACR13CF2AB RELAY-BATTERY CHARGING DETECTION	284T0997 81205	1	24-34-11 P006-01/ /	ALL
K00695		BACR13CF2A RELAY-CHARGER SIGNAL CONTROL	284T0997 81205	1	24-34-11 P006-01/ /	ALL
K00696		BACR13CF2A RELAY-CHARGER SIGNAL CONTROL ENABLE	284T0997 81205	1	24-34-11 P006-01/ /	ALL
K00697		BACR13CF2AB RELAY-EQUIP COOL DIFFERENTIAL	284T0187 81205	1	21-58-16 P036-00/ /	ALL
K00698		TD-1434-00 RELAY-EQUIP COOL PRESS DIFF TIME DELAY	284T0187 35344	1	21-58-16 P036-00/ /	ALL
K00699		BACR13CD2 RELAY-EQUIP COOL OVERHEAT INDICATION	284T0187 81205	1	21-58-16 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00600

Page 3 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00700		M83726-3-155 RELAY-EQUIP COOL OVERHEAT TIME DELAY	284T0187 35344	1	21-58-16 P036-00/ /	ALL
K00701		BACR13CF2AB RELAY-OVERRIDE DIMMING CONTROL	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00702		BACR13CF2AB RELAY-AUTOBRIGHT LEFT/RIGHT CONTROL	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00703		BACR13CF2AB RELAY-PILOTS LEFT DIM CONTROL	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00704		BACR13CF2AB RELAY-RT SIDE PNL LEFT BUS DIM CONTROL	284T0997 81205	1	33-16-21 P006-05/ /	ALL
K00705		BACR13CF2AB RELAY-PILOTS RIGHT DIM CONTROL	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00706		BACR13CF2AB RELAY-RT SIDE PNL RIGHT BUS DIM CONTROL	284T0997 81205	1	33-16-21 P006-05/ /	ALL
K00707		BACR13CF2AB RELAY-PILOTS BATTERY DIM CONTROL	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00708		BACR13CF2AB RELAY-RT SIDE PNL BATTERY BUS DIM CONT	284T0997 81205	1	33-16-21 P006-05/ /	ALL
K00709		BACR13CG2AB RELAY-PILOTS LEFT TEST	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00710		BACR13CG2AB RELAY-PILOTS RIGHT TEST	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00711		BACR13CG2AB RELAY-PILOTS BATTERY TEST	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00712		BACR13CG2AB RELAY-RT SIDE PNL LEFT BUS TEST	284T0997 81205	1	33-16-21 P006-05/ /	ALL
K00713		BACR13CG2AB RELAY-RT SIDE PNL RIGHT BUS TEST	284T0997 81205	1	33-16-21 P006-05/ /	ALL
K00714		BACR13CG2AB RELAY-RT SIDE PNL BATTERY BUS TEST	284T0997 81205	1	33-16-21 P006-05/ /	ALL
K00715		BACR13CF2AB RELAY-BPCU POWER CONTROL	284T0997 81205	1	33-16-22 P006-05/ /	ALL
K00716		BACR13CE2 RELAY-AIR/GND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00700

Page 1

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00717		BACR13CD2 RELAY-FLAP HNDL SENSE	284T0189 81205	1	29-11-22 P033-00/ /	ALL
K00718		BACR13CD2 RELAY-L DRAG BRACE	284T0112 81205	1	32-61-14 SHELF/E01/02	ALL
K00719		BACR13CD2 RELAY-R DRAG BRACE	284T0112 81205	1	32-61-14 SHELF/E01/02	ALL
K00721		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K00726		KA-D9F-005 RELAY-CAPT'S STBY DIMMER CONTROL	233T2402 35344	1	33-13-11 0145/215/L005	ALL
K00727		KA-D9F-005 RELAY-STBY LT,POT OVRD,CAB PR & FUEL QTY	233T4403 35344	1	33-13-16 P005-00/ /	ALL
K00728		10-60450-2 RELAY-STBY LIGHT CONTROL	284T0997 81205	1	33-11-13 P006-05/ /	ALL
K00729		BACR13CG2AB RELAY-CARGO OVERHEAT,BULK	284T0189 81205	1	21-44-21 P033-00/ /	ALL
K00730		BACR13CJ2 RELAY-FSEU FAULT	284T0188 81205	1	27-51-61 P037-00/ /	ALL
K00743		BACR13CJ2 RELAY-CAPT FLOODLIGHT STBY PWR	284T0997 81205	1	33-11-11 P006-05/ /	ALL
K00744		BACR13CJ2 RELAY-F/O FLOODLIGHT STBY PWR	284T0997 81205	1	33-11-11 P006-05/ /	ALL
K00747		10-60450-2 RELAY-CAPT & F/O OVERRIDE	284T0997 81205	1	33-11-15 P006-05/ /	ALL
K00748		10-60450-2 RELAY-F/O OVERRIDE	284T0997 81205	1	33-11-15 P006-05/ /	ALL
K00749		10-60450-2 RELAY-FLOOD,DOME & MD & T OVERRIDE	284T0997 81205	1	33-11-15 P006-05/ /	ALL
K00755		BACR13CJ2 RELAY-OVHD STANDBY	233T4403 81205	1	33-13-16 P005-00/ /	ALL
K00756		10-60450-2 RELAY-GLARESHIELD STANDBY	233T2402 81205	1	33-13-17 0156/217/L003	ALL
K00757		BACR13CG2AB RELAY-FMC-TUNING,L	284T0187 81205	1	34-61-15 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00700

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00758		BACR13CG2AB RELAY-FMC-TUNING,R	284T0188 81205	1	34-61-25 P037-00/ /	ALL
K00759		X-D4N RELAY-STICK NUDGER	284T0187 35344	1	27-32-31 P036-00/ /	ALL
K00760		BACR13CF2AB RELAY-STICK NUDGER	284T0187 81205	1	27-32-31 P036-00/ /	ALL
K00761		BACR13CG2AB RELAY-EQUIP COOL EICAS DISC	284T0187 81205	1	21-58-16 P036-00/ /	ALL
K00762		BACR13CF2AB RELAY-CARGO OVERHEAT ANNUNCIATION,BULK	284T0189 81205	1	21-44-21 P033-00/ /	ALL
K00765		BACR13CF2AB RELAY-CARGO OVERHEAT ANNUNCIATION,AFT	284T1149 81205	1	21-44-11 P049-00/ /	ALL
K00767		BACR13CF2A RELAY-UP ENABLE	285T0019 81205	1	52-11-12 P019-00/ /	ALL
K00771		BACR13CF2AB RELAY-AUTOBRIGHT CONTROL,CH 1	284T0997 81205	1	33-16-11 P006-05/ /	ALL
K00772		BACR13CF2AB RELAY-AUTOBRIGHT CONTROL,CH 2	284T0997 81205	1	33-16-11 P006-05/ /006	ALL
K00774		Y-D4N RELAY-FWD CHILLER LATCH	284T0188 35344	1	25-33-11 P037-00/ /	050-099, 150-154
K00774		Y-D4N RELAY-FWD CHILLER LATCH	284T0188 35344	1	21-58-16 P037-00/ /	275-276
K00777		BACR13CE2 RELAY-LEFT BLEED AIR ENGINE N2	284T0189 81205	1	36-11-51 P033-00/ /	ALL
K00778		BACR13CE2 RELAY-RIGHT BLEED AIR ENGINE N2	284T0188 81205	1	36-11-52 P037-00/ /	ALL
K00785		BACR13CE2 RELAY-TAI IDLE,L ENG	284T0187 81205	1	73-21-19 P036-00/ /	050-099, 275-299
K00786		BACR13CE2 RELAY-TAI IDLE,R ENG	284T0188 81205	1	73-21-19 P037-00/ /	050-099, 275-299
K00793		BACR13CE2 RELAY-APU 95 PERCENT	284T0188 81205	1	49-61-11 P037-00/ /	050-099, 162-199, 275-299
K00794		BACR13CJ2 RELAY-STBY INSTR & PNL LTS	284T0997 81205	1	33-13-18 P006-05/ /	ALL

EQUIPMENT LIST

D280T132

Section K00700

Page 3

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00795	1	TDH-1853-2002 RELAY-TDO,FWD LAT GUIDES UP	284T3501 58657	1	25-53-15 P035-00/ /	ALL
K00795	2	600-159-2002 RELAY-TDO,FWD LAT GUIDES UP	284T3501 15420	1	25-53-15 P035-00/ /	ALL
K00796	1	TDH-1853-2002 RELAY-TDO,FWD LAT GUIDES DN	284T3501 58657	1	25-53-15 P035-00/ /	ALL
K00796	2	600-159-2002 RELAY-TDO,FWD LAT GUIDES DN	284T3501 15420	1	25-53-15 P035-00/ /	ALL
K00797	1	TDH-1853-2002 RELAY-TDO,AFT LAT GUIDES UP	284T3501 58657	1	25-53-15 P035-00/ /	ALL
K00797	2	600-159-2002 RELAY-TDO,AFT LAT GUIDES UP	284T3501 15420	1	25-53-15 P035-00/ /	ALL
K00798	1	TDH-1853-2002 RELAY-TDO,AFT LAT GUIDES DN	284T3501 58657	1	25-53-15 P035-00/ /	ALL
K00798	2	600-159-2002 RELAY-TDO,AFT LAT GUIDES DN	284T3501 15420	1	25-53-15 P035-00/ /	ALL
K00799		BACR13CF2AB RELAY-LAT GUIDES PWR	284T3501 81205	1	25-53-15 P035-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00700

Page 4 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00800	1	TDH-1853-2002 RELAY-TDO,LD3 UP	284T3501 58657	1	25-53-16 P035-00/ /	ALL
K00800	2	600-159-2002 RELAY-TDO,LD3 UP	284T3501 15420	1	25-53-16 P035-00/ /	ALL
K00801	1	TDH-1853-2002 RELAY-TDO,LD2 UP	284T3501 58657	1	25-53-16 P035-00/ /	ALL
K00801	2	600-159-2002 RELAY-TDO,LD2 UP	284T3501 15420	1	25-53-16 P035-00/ /	ALL
K00802	1	TDH-1853-2002 RELAY-TDO,CTR GUIDES ALL DOWN	284T3501 58657	1	25-53-16 P035-00/ /	ALL
K00802	2	600-159-2002 RELAY-TDO,CTR GUIDES ALL DOWN	284T3501 15420	1	25-53-16 P035-00/ /	ALL
K00803		BACR13CF2AB RELAY-CTR GUIDES PWR	284T3501 81205	1	25-53-16 P035-00/ /	ALL
K00804	1	TDH-1853-2002 RELAY-TDO,LD3 UP	284T3901 58657	1	25-53-26 P039-00/ /	ALL
K00804	2	600-159-2002 RELAY-TDO,LD3 UP	284T3901 15420	1	25-53-26 P039-00/ /	ALL
K00805	1	TDH-1853-2002 RELAY-TDO,LD2 UP	284T3901 58657	1	25-53-26 P039-00/ /	ALL
K00805	2	600-159-2002 RELAY-TDO,LD2 UP	284T3901 15420	1	25-53-26 P039-00/ /	ALL
K00806	1	TDH-1853-2002 RELAY-TDO,CTR GUIDES ALL DOWN	284T3901 58657	1	25-53-26 P039-00/ /	ALL
K00806	2	600-159-2002 RELAY-TDO,CTR GUIDES ALL DOWN	284T3901 15420	1	25-53-26 P039-00/ /	ALL
K00807		BACR13CF2AB RELAY-CTR GUIDES PWR	284T3901 81205	1	25-53-26 P039-00/ /	ALL
K00808	1	TDH-1853-2002 RELAY-TDO,ROLLOUT HOOK LOCK	284T3901 58657	1	25-53-27 P039-00/ /	050-099, 150-199
K00808	2	600-159-2002 RELAY-TDO,ROLLOUT HOOK LOCK	284T3901 15420	1	25-53-27 P039-00/ /	050-099, 150-199
K00809	1	TDH-1853-2002 RELAY-TDO,ROLLOUT STOPS UP	284T3901 58657	1	25-53-27 P039-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section K00800

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00809	2	600-159-2002 RELAY-TDO,ROLLOUT STOPS UP	284T3901 15420	1	25-53-27 P039-00/ /	050-099, 150-199
K00810	1	TDH-1853-2002 RELAY-TDO,ROLLOUT STOPS DN	284T3901 58656	1	25-53-27 P039-00/ /	050-099, 150-199
K00810	2	600-159-2002 RELAY-TDO,ROLLOUT STOPS DN	284T3901 15420	1	25-53-27 P039-00/ /	050-099, 150-199
K00812	1	TDH-1853-2002 RELAY-TDO,ROLLOUT HOOK LOCK	284T3501 58657	1	25-53-17 P035-00/ /	ALL
K00812	2	600-159-2002 RELAY-TDO,ROLLOUT HOOK LOCK	284T3501 15420	1	25-53-17 P035-00/ /	ALL
K00813	1	TDH-1853-2002 RELAY-TDO,ROLLOUT STOP UP	284T3501 58657	1	25-53-17 P035-00/ /	ALL
K00813	2	600-159-2002 RELAY-TDO,ROLLOUT STOP UP	284T3501 15420	1	25-53-17 P035-00/ /	ALL
K00814	1	TDH-1853-2002 RELAY-TDO,ROLLOUT STOP DOWN	284T3501 58657	1	25-53-17 P035-00/ /	ALL
K00814	2	600-159-2002 RELAY-TDO,ROLLOUT STOP DOWN	284T3501 15420	1	25-53-17 P035-00/ /	ALL
K00816	1	TDH-1853-2002 RELAY-TDO,FWD LAT GUIDES UP	284T3901 58657	1	25-53-25 P039-00/ /	ALL
K00816	2	600-159-2002 RELAY-TDO,FWD LAT GUIDES UP	284T3901 15420	1	25-53-25 P039-00/ /	ALL
K00817	1	TDH-1853-2002 RELAY-TDO,FWD LAT GUIDES DN	284T3901 58657	1	25-53-25 P039-00/ /	ALL
K00817	2	600-159-2002 RELAY-TDO,FWD LAT GUIDES DN	284T3901 15420	1	25-53-25 P039-00/ /	ALL
K00818	1	TDH-1853-2002 RELAY-TDO,AFT LAT GUIDES UP	284T3901 58657	1	25-53-25 P039-00/ /	ALL
K00818	2	600-159-2002 RELAY-TDO,AFT LAT GUIDES UP	284T3901 15420	1	25-53-25 P039-00/ /	ALL
K00819	1	TDH-1853-2002 RELAY-TDO,AFT LAT GUIDES DN	284T3901 58657	1	25-53-25 P039-00/ /	ALL
K00819	2	600-159-2002 RELAY-TDO,AFT LAT GUIDES DN	284T3901 15420	1	25-53-25 P039-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00800

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00820		BACR13CF2AB RELAY-LAT GUIDES PWR	284T3901 81205	1	25-53-25 P039-00/ /	ALL
K00821	1	TDH-1853-2002 RELAY-TDO,ROLLOUT HOOK LOCK BAY D	284T3501 58657	1	25-53-17 P035-00/ /	ALL
K00821	2	600-159-2002 RELAY-TDO,ROLLOUT HOOK LOCK BAY D	284T3501 15420	1	25-53-17 P035-00/ /	ALL
K00822		BACR13CG2AB RELAY-FWD COMPT LOCK-IN	284T0188 81205	1	26-23-12 P037-00/ /	150-199, 275-299
K00823		BACR13CG2AB RELAY-AFT COMPT LOCK-IN	284T0188 81205	1	26-23-12 P037-00/ /	150-199, 275-299
K00826		TDH-6103-1804 RELAY-TDC,FEXT BTL 2A DISCH	284T0188 58657	1	26-23-12 P037-00/ /	150-199, 275-299
K00831		X-D4N RELAY-MID ZONE AUTO/OFF	284T0188 35344	1	21-61-41 P037-00/ /	ALL
K00832		X-D4N RELAY-MID ZONE INOP	284T0188 35344	1	21-61-41 P037-00/ /	ALL
K00833		BACR13CG2AB RELAY-MID ZONE DUCT OVERHEAT	284T0188 81205	1	21-61-41 P037-00/ /	ALL
K00834		BACR13CD2 RELAY-DFDAU BITE	284T0187 81205	1	31-31-13 P036-00/ /	ALL
K00835		BACR13CJ2 RELAY-AFT EXH FAN 1 AC AVAIL	284T0188 81205	1	21-26-11 P037-00/ /	ALL
K00838		BACR13CE2 RELAY-SQUIB TEST 1	285T0019 81205	1	25-65-12 P019-00/ /	ALL
K00839		BACR13CE2 RELAY-SQUIB TEST 2	285T0019 81205	1	25-65-12 P019-00/ /	ALL
K00840		BACR13CF2AB RELAY-FWD DOOR AREA HEATING	284T0187 81205	1	21-45-21 P036-00/ /	ALL
K00846		KA-D9F-005 RELAY-SIDEWALL WASHLIGHTS	285T0019 35344	1	33-21-31 P019-00/ /	ALL
K00853		BACR13CG2A RELAY-28 VDC R BUS PWR SENSE #1	233T5216 81205	1	78-34-21 P011-00/ /	ALL
K00854		BACR13CG2A RELAY-28 VDC R BUS PWR SENSE #2	233T5216 81205	1	78-34-21 P011-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00800

Page 3

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00858		BACR13CJ2 RELAY-LEFT AC BUS OFF	284T1168 81205	1	24-25-11 P065-00/ /	ALL
K00859		BACR13CJ2 RELAY-RIGHT AC BUS OFF	284T1168 81205	1	24-25-11 P065-00/ /	ALL
K00860		XL-D4N-009 RELAY-HYDRAULIC GENERATOR CONTROL	284T1168 35344	1	24-25-11 P065-00/ /	ALL
K00861		A-1077DD RELAY-HYD GEN 28 VDC POWER	284T1168 74063	1	24-25-12 P065-00/ /	ALL
K00862		HT-C7N-060 RELAY-115 VAC INSTR TRANSFER BUS	284T1168 35344	1	24-25-12 P065-00/ /	ALL
K00863		HT-C7N-060 RELAY-115 VAC L TRANSFER BUS	284T1168 35344	1	24-25-12 P065-00/ /	ALL
K00864		HT-C7N-060 RELAY-115V AC R TRANSFER BUS	284T1168 35344	1	24-25-12 P065-00/ /	ALL
K00865		BACR13CF2AB RELAY-HYDRAULIC GENERATOR ADP COMMAND	284T1168 81205	1	24-25-11 P065-00/ /	ALL
K00866		KA-X9E-004 RELAY-NIGHT LIGHTS FWD,TRANSFER	285T0019 81205	1	33-21-21 P019-00/ /	ALL
K00867		KA-D9F-005 RELAY-DIRECT CEILING LIGHTS,TRANSFER	285T0009 35344	1	33-22-42 P025-00/ /	ALL
K00868		KA-X9E-004 RLY-EMER LIGHTS,ALTERNATE TRANSFER	285T0019 35344	1	33-51-11 P019-00/ /	ALL
K00869		BACR13CJ2 RELAY-LIGHTING CONTROL,5KVA INSTR	233T4403 81205	1	33-13-16 0194/273/R031	ALL
K00873		TDH-1853-1501 RELAY-GENERATOR RESET	284T1168 58657	1	24-25-11 P065-00/ /	ALL
K00874		BACR13CD2 RLY-L SIDE BRACE	284T0112 81205	1	32-61-14 SHELF/E01/02	ALL
K00875		BACR13CD2 RLY-R SIDE BRACE	284T0112 81205	1	32-61-14 SHELF/E01/02	ALL
K00881		BACR13CF2A RELAY-BTL 2A ARMING	284T0188 81205	1	26-23-12 P037-00/ /	050-099
K00886		X-D4N RELAY-AFT EXH FAN 2 SHUTOFF	284T0187 35344	1	21-58-16 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00800

Page 4

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00887		X-D4N RELAY-AFT EXH FAN 1 SHUTOFF	284T0188 35344	1	21-58-16 P037-00/ /	ALL
K00889		BACR13CJ1 RELAY-LAV OCCUPIED SIGN	285T0019 81205	1	33-26-21 P019-00/ /	ALL
K00895		BACR13CG2A RELAY-AIR/GND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K00898		BACR13CG2A RELAY-28 VDC R BUS PWR SENSE #3	233T5216 81205	1	78-34-21 P011-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00800
Page 5 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00902		BACR13CJ2 RELAY-OUTBOARD INDIRECT CEILING LTS	285T0009 81205	1	33-21-12 P025-00/ /	ALL
K00903		BACR13CJ2 RELAY-INBOARD INDIRECT CEILING LTS	285T0009 81205	1	33-21-12 P025-00/ /	ALL
K00904		BACR13CF2A RELAY-LG,DOWN SENSE	284T0187 81205	1	32-71-11 P036-00/ /	150-199, 275-299
K00905	1	600-154-1251 RELAY-TDC,BAY D UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00905	2	600-154-2500M-0 RELAY-TDC,BAY D UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00906	1	600-154-4000 RELAY-TDC,BAY E LDG DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00906	2	600-154-400M-0 RELAY-TDC,BAY E LDG DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00907	1	600-154-2000 RELAY-TDC BAY F AFT DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00907	2	600-154-200M-0 RELAY-TDC BAY F AFT DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00908	1	600-154-6000 RELAY-TDC BAY F FWD DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00908	2	600-154-600M-0 RELAY-TDC BAY F FWD DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00909	1	600-154-8000 RELAY-TDC BAY G UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00909	2	600-154-800M-0 RELAY-TDC BAY G UNL DLY	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00910		BACR13CD2 RELAY-PDU 5L CONT	284T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299
K00911		BACR13CD2 RELAY-PDU 5R CONT	284T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299
K00912		BACR13CD2 RELAY-PDU 6L/7L CONT	284T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299
K00913		BACR13CD2 RELAY-PDU 6R/7R CONT	285T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section K00900

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00914		BACR13CG2AB RELAY-PDU 9L/9C/9R CONT	284T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299
K00915		BACR13CD2 RELAY-PDU 8L/10L	284T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299
K00916		BACR13CD2 RELAY-PDU 8R/10R	284T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299
K00917		BACR13CD2 RELAY-PDU 11L/12L	284T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299
K00918		BACR13CD2 RELAY-PDU 11R/12R	284T3901 81205	1	25-53-24 P039-00/ /	150-199, 275-299
K00923	1	600-154-1251 RELAY-TDC BAY G UNL	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00923	2	600-154-1250M-0 RELAY-TDC BAY G UNL	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00924	1	600-154-2501 RELAY-TDC BAY H UNL	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00924	2	600-154-2500M-0 RELAY-TDC BAY H UNL	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00925	1	600-154-2001 RELAY-TDC, PDU DRIVE DLY	284T3501 15420	1	25-53-14 P035-00/ /	150-199, 275-299
K00925	2	600-154-2000M-0 RELAY-TDC, PDU DRIVE DLY	284T3501 15420	1	25-53-14 P035-00/ /	150-199, 275-299
K00926	1	600-154-2001 RELAY-TDC, PDU DRIVE DLY,AFT COMPT	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00926	2	600-154-2000M-0 RELAY-TDC, PDU DRIVE DLY,AFT COMPT	284T3901 15420	1	25-53-24 P039-00/ /	150-199, 275-299
K00928		BACR13CF2AB RELAY-PES/PSS TEST	284T0189 81205	1	23-34-12 P033-00/ /	150-199, 275-299
K00950		BACR13CD2 RELAY	284T0187	1	27-09-13 P036-00/ /	ALL
K00971		BACR13CD2 RLY-R IDG AIR COOLER VALVE	284T0188 81205	1	24-11-21 P037-00/ /	ALL
K00979		BACR13CD2 RELAY-GENERATOR RESET (SB 24-0037)	284T3501 81205	1	25-53-16 P035-00/ /	050-099, 280-299

EQUIPMENT LIST

D280T132

Section K00900

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K00980		BACR13CD2 RELAY-PALLET MODE	284T3501 81205	1	25-53-14 P035-00/ /	050-099
K00980		BACR13CE2 RELAY-PALLET MODE	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00981		BACR13CD2 RELAY-CTR GUIDES CMD DOWN OVERRIDE	284T3501 81205	1	25-53-16 P035-00/ /	ALL
K00982		BACR13CE2 RELAY-PDU ERECT BRAKE LATCH,BAY C UNL	284T0000 81205	1	25-53-16 P035-00/ /	050-099
K00982		BACR13CE2 RELAY-PDU ERECT BRAKE LATCH,BAY C UNL	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00983		BACR13CE2 RELAY-UNL MODE CKT ENBL	284T3501 81205	1	25-53-16 P035-00/ /	ALL
K00991		BACR13CD2 RELAY-PDU 10L CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00992		BACR13CD2 RELAY-PDU 10R CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00993		BACR13CD2 RELAY-PDU 13L CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00994		BACR13CD2 RELAY-PDU 13R CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00995		BACR13CD2 RELAY-PDU 14L CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00996		BACR13CD2 RELAY-PDU 14R CONT	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K00998		BACR13CD2 RELAY-LD2 TD RESET	284T3901 81205	1	25-53-26 P039-00/ /	ALL
K00999		BACR13CD2 RELAY-CTR GUIDES CMD DOWN OVERRIDE	284T3901 81205	1	25-53-26 P039-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K00900

Page 3 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01000	1	600-154-3001 RELAY-TDC,PDU 5L/8L ROLLER ERECT DELAY	284T3501 15420	1	25-53-14 P035-00/ /	ALL
K01000	2	600-154-3000M-0 RELAY-TDC,PDU 5L/8L ROLLER ERECT DELAY	284T3501 15420	1	25-53-14 P035-00/ /	ALL
K01001		BACR13CE2 RELAY-UNL MODE CKT ENBL	284T3901 81205	1	25-53-26 P039-00/ /	ALL
K01004		BACR13CD2 RELAY-PDU ERECT BRAKE LATCH,BAY F UNL	284T3901 81205	1	25-53-26 P039-00/ /	ALL
K01005		BACR13CD2 RELAY-OVERBOARD EXHAUST VALVE INDICATION	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K01006		BACR13CD2 RELAY-INBOARD SUPPLY VALVE INDICATION	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K01007		BACR13CD2 RELAY-INBOARD SUPPLY VALVE INDICATION	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K01008		BACR13CD2 RELAY-EXHAUST VALVE CLOSED INDICATION	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K01009		BACR13CD2 RELAY-SUPPLY FAN AND EXHAUST FAN CONTROL	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K01010		BACR13CD2 RELAY-EXHAUST FAN CONTROL	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K01011		BACR13CD2 RELAY-EQUIP COOL SMOKE CLEARANCE	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K01031		BACR13CD2 RELAY-L IDG AIR COOLER VALVE	284T0187 81205	1	24-11-11 P036-00/ /	ALL
K01032		BACR13CE2 RELAY-R IDG VALVE FAILURE	284T0188 81205	1	24-11-21 P037-00/ /	ALL
K01033		BACR13CD2 RELAY-L IDG VALVE FAILURE	284T0187 81205	1	24-11-11 P036-00/ /	ALL
K01036		XL-D4N-009 RLY-L ENG EEC RESET-CHAN A	284T0187 45344	1	73-21-11 P036-00/ /	ALL
K01037		XL-D4N-009 RLY-L ENG EEC RESET-CHAN B	284T0187 45344	1	73-21-11 P036-00/ /	ALL
K01038		XL-D4N-009 RLY-R ENG EEC RESET-CHAN A	284T0188 45344	1	73-21-11 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K01000

Page 1

Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01039		XL-D4N-009 RLY-R ENG EEC RESET-CHAN B	284T0188 45344	1	73-21-11 P037-00/ /	ALL
K01040		BACR13CD2 RLY-TRIM ENABLE	284T0189 81205	1	22-32-13 P033-00/ /	ALL
K01043	9	BACR13CE2 RELAY-AIR/GROUND,SYS NO.1 (SB25-0113)	284T0187 81205	1	32-09-11 P036-00/ /	150-154, 275
K01043		BACR13CE2 RELAY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	050-099, 155-199, 276-299
K01064		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2	284T0188 81205	1	32-09-12 P037-00/ /	ALL
K01068		BACR13CD2 RLY-SKIN TEMP SWITCH	284T0187 81205	1	21-58-12 P036-00/ /	ALL
K01069		BACR13CJ2 RELAY-WATER LINE HEATER	284T0189 81205	1	30-71-21 P033-00/ /	ALL
K01070		X-D4N RELAY-TRIM LIMIT SELECT-LEFT	284T0111 35344	1	27-41-11 SHELF/E01/01	ALL
K01071		X-D4N RELAY-TRIM LIMIT SELECT-RIGHT	284T0121 35344	1	27-41-21 SHELF/E02/01	ALL
K01077		BACR13CF2A RLY-L ENG-FANCASE OVERHEAT	284T0187 81205	1	30-21-11 P036-00/ /	ALL
K01078		BACR13CF2A RLY-R ENG-FANCASE OVERHEAT	284T0188 81205	1	30-21-11 P037-00/ /	ALL
K01082		BACR13CD2 RELAY-UNL DSBL	284T3501 81205	1	25-53-16 P035-00/ /	ALL
K01083		BACR13CD2 RELAY-UNL DSBL	284T0688 81205	1	25-53-26 P039-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K01000

Page 2 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01112		BACR13CD2 RELAY-PDU 11L/12L	284T3501 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K01113		BACR13CD2 RELAY-PDU 11R/12R	284T0687 81205	1	25-53-14 P035-00/ /	150-199, 275-299
K01115		BACR13CD2 RELAY-CONTROL L PRSOV AUTO	284T0187 81205	1	36-11-51 P036-00/ /	275-276
K01116		BACR13CD2 RELAY-CONTROL L PRSOV OFF	284T0187 81205	1	36-11-51 P036-00/ /	275-276
K01124		BACR13CD2 RELAY-CONTRLR R HPSOV OFF	284T0188 81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166
K01128		BACR13CF2A RELAY-L ENG BLEED ON	284T0187 81205	1	36-11-61 P036-00/ /	050-099, 150-156, 162-166
K01131		BACR13CF2A RELAY-L ENG COWL LATCH	284T0187 81205	1	36-11-61 P036-00/ /	275-276
K01133		BACR13CF2A RELAY-R ENG BLEED ON	284T0188 81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166
K01136		BACR13CF2A RELAY-R ENG COWL LATCH	284T0188 81205	1	36-11-62 P037-00/ /	275-276
K01137		BACR13CF2A RELAY-R ENG COWL ON	284T0188 81205	1	36-11-62 P037-00/ /	275-276
K01140		BACR13CJ1 RELAY-BUSINESS NIGHT LIGHTS	285T0019 81205	1	33-21-21 P019-00/ /	050-099, 150-199, 280-299
K01145		BACR13CF2A RELAY-VACUUM SHUTOFF VLV,LAV SYS 2	284T1149 81205	1	38-32-14 P049-00/ /	050-099, 150-155, 162-165
K01146		BACR13CF2A RELAY-VACUUM SHUTOFF VLV-LAV SYS 1	284T0187 81205	1	38-32-14 P036-00/ /	050-099, 150-199, 277-299
K01148		BACR13CG2A RELAY-RIGHT SYSTEM SHUTOFF	284T0189 58657	1	29-11-14 P033-00/ /	ALL
K01149		TDH-8127-2002 RELAY-LEFT SYSTEM ISOLATION	284T0189 58657	1	29-11-14 P033-00/ /	ALL
K01150		600-154-4000 RELAY-TIME DELAY	284T0189 15420	1	29-11-14 P033-00/ /	ALL
K01153		BACR13CE2 RELAY-MANUAL TRIM DOWN ARM	284T0189 81205	1	29-11-14 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K01100

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01154		BACR13CE2 RELAY-MANUAL TRIM UP ARM	284T0189 81205	1	29-11-14 P033-00/ /	ALL
K01155		BACR13CF2A RELAY-R WING TAI DISAGREE	284T0189 81205	1	30-11-11 P033-00/ /	ALL
K01156		BACR13CF2A RELAY-L WING TAI DISAGREE	284T0189 81205	1	30-11-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K01100

Page 2 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01200		KL-X4A-011 RELAY-LIGHTING CONTROL,PRIORITY	285T0019 35344	1	33-21-11 P019-00/ /	050-099, 150-199
K01201		KL-X4A-011 RELAY-LIGHTING CONTROL,PRIORITY	285T0019 35344	1	33-21-31 P019-00/ /	050-099, 150-199
K01202		KL-X4A-011 RELAY-LIGHTING CONTROL,PRIORITY	285T0019 35344	1	33-21-31 P019-00/ /	050-099, 150-199
K01203		KL-X4A-011 RELAY-LIGHTING CONTROL,PRIORITY	285T0019 35344	1	33-21-31 P019-00/ /	050-099, 150-199
K01204		KL-X4A-011 RELAY-LIGHTING CONTROL,PRIORITY	285T0009 35344	1	33-21-12 P025-00/ /	050-099, 150-199
K01205		KL-X4A-011 RELAY-LIGHTING CONTROL,PRIORITY	285T0009 35344	1	33-21-12 P025-00/ /	050-099, 150-199
K01206	1	TDH-1852-3002 RELAY-EQUIP COOL VALVE T/D	284T0187 58657	1	21-58-11 P036-00/ /	ALL
K01206	2	600-154-3002 RELAY-EQUIP COOL VALVE T/D	284T0187 15420	1	21-58-11 P036-00/ /	ALL
K01208		BACR13CJ1 RELAY-SIDEWALL WASHLIGHT TURNOFF	285T0019 81205	1	33-21-31 P019-00/ /	151-152, 157
K01209		BACR13CJ1 RELAY-SIDEWALL WASHLIGHT TURNOFF	285T0019 81205	1	33-21-31 P019-00/ /	050-099, 151-152, 157-199
K01210		BACR13CG2A RELAY-CARGO VENT FAN CONTROL,FWD	284T0188 81205	1	21-26-31 P037-00/ /	ALL
K01211		BACR13CG2A RELAY-CGO GND EXH FAN CONTROL	284T0188 81205	1	21-26-31 P037-00/ /	ALL
K01212		BACR13CF2A RELAY-CARGO A/C SOV CONT	284T0188 81205	1	21-28-11 P037-00/ /	ALL
K01213		BACR13CF2A RELAY-CARGO EXH VLV CONT	284T0188 81205	1	21-28-11 P037-00/ /	ALL
K01214		BACR13CF2A RELAY-CARGO GND EXH VLV CONT	284T0188 81205	1	21-28-11 P037-00/ /	ALL
K01215		BACR13CF2A RELAY-CGO GND EXH B/U VLV CONT	284T0187 81205	1	21-28-11 P036-00/ /	ALL
K01218		KL-X4A-011 RLY-LIGHTING CONTROL,PRIORITY	285T0009 35344	1	33-22-42 P025-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section K01200

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01219		BACR13CE2 RLY-AIR/GROUND,SYS NO.1	284T0187 81205	1	32-09-11 P036-00/ /	ALL
K01221		BACR13CF2A RELAY-FWD CARGO AUTO/OFF	284T0188 81205	1	21-61-81 P037-00/ /	ALL
K01222		BACR13CG2A RELAY-FWD CARGO DUCT OVERHEAT	284T0188 81205	1	21-61-81 P037-00/ /	ALL
K01225		BACR13CF2AB RELAY-TIRE PRESS PWR XFER	284T0189 81205	1	32-45-11 P033-00/ /	ALL
K01226		BACR13CE2 RLY-L ENG N2 SPEED	284T0187 81205	1	73-21-18 P036-00/ /	ALL
K01227		BACR13CE2 RLY-R ENG N2 SPEED	284T0188 81205	1	73-21-18 P037-00/ /	ALL
K01249	9	BACR13CF2A RLY-EEC POWER,R ENG (SB 76-0026)	284T3701 81205	1	73-21-11 P037-00/ /	275-276
K01249		BACR13CF2A RLY-EEC POWER,R ENG	284T0188 81205	1	73-21-11 P037-00/ /	050-099, 155-199, 277-299
K01250	9	BACR13CF2A RLY-EEC POWER,L ENG (SB 76-0026)	284T3601 81205	1	73-21-11 P036-00/ /	275-276
K01250		BACR13CF2A RLY-EEC POWER,L ENG	284T0187 81205	1	73-21-11 P036-00/ /	050-099, 155-199, 277-299
K01255	9	BACR13CF2A RLY-ESC HATCH HTR BLKT (SB 25-0113)	284T0187 81205	1	21-45-22 P036-00/ /	150-154
K01255		BACR13CF2A RLY-ESC HATCH HTR BLKT	284T0187 81205	1	21-45-22 P036-00/ /	050-099, 155-199, 275-299
K01257		BACR13CJ2 RELAY-DIR CEIL LTS FLEX	285T0009 81205	1	33-22-42 P025-00/ /	275-299
K01258		BACR13CG2AB RELAY-CHIME OFF	284T0125 81205	1	23-34-13 SHELF/E02/05	275-299
K01259		BACR13CF2AB RELAY-CHIME OFF	284T0125 81205	1	23-34-13 SHELF/E02/05	275-299
K01260	9	BACR13CJ1 RELAY-SIDEWALL WASHLT TRNOFF(MTO 330370)	CUSTOMER 81205	1	33-21-31 P025-00/ /	150-157
K01260		BACR13CJ1 RELAY-SIDEWALL WASHLIGHT TURNOFF	285T0009 81205	1	33-21-31 P025-00/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section K01200

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01261	9	BACR13CJ1 RELAY-SIDEWALL WASHLT TRNOFF(MTO 330370)	CUSTOMER 81205	1	33-21-31 P025-00/ /	150-157
K01261		BACR13CJ1 RELAY-SIDEWALL WASHLIGHT TURNOFF	285T0009 81205	1	33-21-31 P025-00/ /	050-099, 162-199
K01262		BACR13CF2AB RELAY-CALL LIGHT	284T0189 81205	1	23-34-13 SHELF/E02/05	050-099
K01263		BACR13CF2A RELAY-FLT DK CREW REST SHUTOFF VALVE	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
K01264		BACR13CF2A RELAY-FLT DK CREW REST SMK EVAC VLV	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
K01266		TDH-8127-6002 RELAY-FLT DK CREW REST SMK	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
K01267		BACR13CG2A RELAY-FLT DK CREW REST FAN	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
K01268		BACR13CF2A RELAY-CARGO FIRE/CREW REST SMK	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
K01269		TD-1434-00 RELAY-FAN CONT,FWD CABIN CREW REST	284T0188 35344	1	21-66-21 P037-00/ /	050-099, 162-199
K01270	9	TD-1434-00 RELAY-FAN CONT,AFT LH CABIN CREW REST	284T0187 35344	1	21-66-31 P036-00/ /	150, 152-157
K01270		TD-1434-00 RELAY-FAN CONT,AFT LH CABIN CREW REST	284T0187 35344	1	21-66-31 P036-00/ /	050-099, 162-199
K01271	9	TD-1434-00 RELAY-FAN CONT,AFT RH CABIN CREW REST	284T0188 35344	1	21-66-41 P037-00/ /	150, 152-157
K01271		TD-1434-00 RELAY-FAN CONT,AFT RH CABIN CREW REST	284T0188 35344	1	21-66-41 P037-00/ /	050-099, 162-199
K01272		BACR13CE2 RELAY-L FUEL JETTISON FAN SHED	284T0187 81205	1	21-58-12 P036-00/ /	050-099, 155-199, 276-299
K01273		BACR13CD2 RELAY-R FUEL JETTISON FAN SHED NO.2	284T0188 81205	1	21-58-14 P037-00/ /	050-099, 155-199, 276-299
K01274	9	BACR13CD2 RELAY-HIGH ENG SPEED-L (SB 76-026)	284T0187 81205	1	73-21-18 P036-00/ /	150-154, 275-276
K01274		BACR13CD2 RELAY-HIGH ENG SPEED-L	284T0187 81205	1	73-21-18 P036-00/ /	050-099, 155-199, 277-299

EQUIPMENT LIST

D280T132

Section K01200

Page 3

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01275	9	BACR13CD2 RELAY-HIGH ENG SPEED-R (SB 76-026)	284T0188 81205	1	73-21-18 P037-00/ /	150-154, 275-276
K01275		BACR13CD2 RELAY-HIGH ENG SPEED-R	284T0188 81205	1	73-21-18 P037-00/ /	050-099, 155-199, 277-299
K01276	9	XL-D4N-009 RLY-EEC/SCU PWR CTL-L ENG (SB 76-026)	284T0187 35344	1	73-21-11 P036-00/ /	150-154, 275-276
K01276		XL-D4N-009 RELAY-EEC/SCU PWR CONTROL-L ENG	284T0187 35344	1	73-21-11 P036-00/ /	050-099, 155-199, 277-299
K01277	9	XL-D4N-009 RLY-EEC/SCU PWR CTL-R ENG (SB 76-026)	284T0188 35344	1	73-21-11 P037-00/ /	150-154, 275-276
K01277		XL-D4N-009 RELAY-EEC/SCU PWR CONTROL-R ENG	284T0188 35344	1	73-21-11 P037-00/ /	050-099, 155-199, 277-299
K01284		BACR13CD2 RELAY-INTERM. MODE	284T0187 81205	1	21-51-11 P036-00/ /	050-099
K01285		BACR13CF2A RELAY-CHILLER LATCH	284T0188 35344	1	25-33-11 P037-00/ /	153-199
K01285		BACR13CG2A RELAY-CHILLER LATCH	284T0188 35344	1	25-33-11 P037-00/ /	277-299
K01293	9	BACR13CG2A RELAY-FUEL POSITION,LEFT (SB 24-0059)	284T0187 81205	1	76-11-11 P036-00/ /	050-099, 150-154, 275-276
K01293		BACR13CG2A RELAY-FUEL POSITION,LEFT	284T0187 81205	1	76-11-11 P036-00/ /	155-199, 277-299
K01294	9	BACR13CG2A RELAY-FUEL POSITION,RIGHT (SB 24-0059)	284T0188 81205	1	76-11-11 P037-00/ /	050-099, 150-154, 275-276
K01294		BACR13CG2A RELAY-FUEL POSITION,RIGHT	284T0188 81205	1	76-11-11 P037-00/ /	155-199, 277-299

EQUIPMENT LIST

D280T132

Section K01200

Page 4 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K01303	9	X-D4N RLY-SCANNING DME LEFT RDMI (SB 34-0167)	284T0122 LEACH	1	34-61-17 SHELF/E02/02	275-276
K01303		X-D4N RELAY-SCANNING DME LEFT RDMI	284T0122 LEACH	1	34-61-17 SHELF/E02/02	157, 167-199, 277-299
K01304	9	X-D4N RLY-SCANNING DME RIGHT RDMI (SB 34-0167)	284T0123 LEACH	1	34-61-27 SHELF/E02/03	275-276
K01304		X-D4N RELAY-SCANNING DME RIGHT RDMI	284T0123 LEACH	1	34-61-27 SHELF/E02/03	157, 167-199, 277-299
K01305		KC-D4N RELAY-PSS PWR,MID	284T0189 35344	1	23-34-11 P033-00/ /	280-299
K01316	9	BACR13CG2AB RLY-MID/AFT DOOR AREA HTG (SB 21-0111)	284T8703 81205	1	21-45-24 P087-00/ /	050-099, 150-199, 275-277
K01321		BACR13CJ2 RELAY-DIRECT CEIL LTS FLEX	285T0009 81205	1	33-22-42 P025-00/ /	280-299
K01324	9	BACR13CF2A LAVATORY POWER CONTROL RELAY(SB 38-0035)	00000000 81205	1	38-32-11 P036-00/ /	275-276

EQUIPMENT LIST

D280T132

Section K01300
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02044		BACR13CF2A RELAY-T/R INTERLOCK-L	284T0187 81205	1	78-36-11 P036-00/ /	ALL
K02045		BACR13CF2A RELAY-T/R INTERLOCK-R	284T0188 81205	1	78-36-21 P037-00/ /	ALL
K02058		BACR13CF2A RELAY-CARGO AIR COND STATUS	284T0187 81205	1	21-61-51 P036-00/ /	050-099, 162-199, 277-299
K02058		BACR13CF2A RELAY-CARGO AIR COND STATUS	284T0187 81205	1	21-51-11 P036-00/ /	150-157, 275-276
K02059		BACR13CG2A RELAY-AUX FWD ZONE DUCT OVERHEAT	284T0187 81205	1	21-61-61 P036-00/ /	ALL
K02060	9	BACR13CF2A RLY-AUX FWD ZONE AUTO/OFF (SB 21-0070)	284T0187 81205	1	21-61-61 P036-00/ /	150-152
K02060		BACR13CF2A RELAY-AUX FWD ZONE AUTO/OFF	284T0187 81205	1	21-61-61 P036-00/ /	050-099, 153-199, 275-299
K02061		BACR13CD2 RELAY-AUX FWD ZONE INOP	284T0187 81205	1	21-61-61 P036-00/ /	ALL
K02062		BACR13CG2A RELAY-AUX MID ZONE DUCT OVERHEAT	284T0187 81205	1	21-61-71 P036-00/ /	050-099, 151-199, 275-299
K02062		BACR13CG2A RELAY-AUX MID ZONE DUCT OVERHEAT	00000000 81205	1	21-61-71 P036-00/ /	150
K02063	9	BACR13CF2A RLY-AUX MID ZONE AUTO/OFF (SB 21-0070)	284T0187 81205	1	21-61-71 P036-00/ /	150-152
K02063		BACR13CF2A RELAY-AUX MID ZONE AUTO/OFF	284T0187 81205	1	21-61-71 P036-00/ /	050-099, 153-199, 275-299
K02064		BACR13CD2 RELAY-AUX MID ZONE (INOP)	284T0187 81205	1	21-61-71 P036-00/ /	ALL
K02065		X-D4N RELAY-CDU NAV ENABLE, L	284T0122 LEACH	1	34-61-16 SHELF/E02/02	ALL
K02066		X-D4N RELAY-CDU NAV ENABLE, R	284T0123 LEACH	1	34-61-26 SHELF/E02/03	ALL
K02067		X-D4N RELAY-FCC SOURCE SELECT, L	284T0122 LEACH	1	34-61-16 SHELF/E02/02	ALL
K02068		X-D4N RELAY-FCC SOURCE SELECT, R	284T0123 LEACH	1	34-61-26 SHELF/E02/03	ALL

EQUIPMENT LIST

D280T132

Section K02000

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02069		X-D4N RELAY-CAPT & FO BOTH ON SG-C	284T0123 LEACH	1	34-61-26 SHELF/E02/03	ALL
K02070		BACR13CG2AB RELAY-CTR SYM GEN NAV SOURCE SW	284T1614 81205	1	34-22-38 SHELF/E01/04	ALL
K02085		BACR13CF2A RELAY-ANNUNCIATOR DISCONNECT	284T0187 81205	1	21-43-11 P036-00/ /	ALL
K02089		BACR13CG2A RELAY-JETTISON IND, L	284T0187 81205	1	28-31-21 P036-00/ /	050-099, 155-199, 276-299
K02090		BACR13CG2A RELAY-JETTISON IND, R	284T0188 81205	1	28-31-21 P037-00/ /	050-099, 155-199, 276-299
K02091	9	HT-C7N-060 RELAY-L LOAD SHED (SB 28-0027)	284T1351 81205	1	28-31-22 P089-00/ /	150-154, 275-276
K02091		HT-C7N-060 RELAY-L LOAD SHED	284T0187 35344	1	24-51-72 P036-00/ /	050-099, 155-199, 276-299
K02092		HT-C7N-060 RELAY-R LOAD SHED	284T0188 35344	1	24-51-72 P037-00/ /	050-099, 155-199, 276-299
K02093		MS27418-2B RELAY-JETTISON PUMP CONT, L	284T0187 81205	1	28-31-21 P036-00/ /	050-099, 162-164, 276
K02094		MS27418-2B RELAY-JETTISON PUMP CONT, R	284T3701 81205	1	28-31-21 P037-00/ /	050-099, 162-164, 276
K02095		BACR13CD2 RELAY-NOZZLE VLV IND, L	284T0187 81205	1	28-31-12 P036-00/ /	050, 155-199, 277- 299
K02095		BACR13CD2 RELAY-NOZZLE VLV IND, L (PROVISIONAL)	284T0187 81205	1	28-31-12 P036-00/ /	276
K02096		BACR13CD2 RELAY-NOZZLE VLV IND, R	284T0188 81205	1	28-31-12 P037-00/ /	050, 155-199, 277- 299
K02096		BACR13CD2 RELAY-NOZZLE VLV IND, R (PROVISIONAL)	284T0188 81205	1	28-31-12 P037-00/ /	276
K02097		TDH-8120-1002 RELAY-FUEL XFR VLV IND, L	284T0187 81205	1	28-31-11 P036-00/ /	050, 155-199, 277- 299
K02097		TDH-8120-1002 RELAY-FUEL XFR VLV IND, L (PROV)	284T0187 81205	1	28-31-11 P036-00/ /	276
K02098		TDH-8120-1002 RELAY-FUEL XFR VLV IND, R	284T0188 81205	1	28-31-11 P037-00/ /	050, 155-199, 277- 299

EQUIPMENT LIST

D280T132

Section K02000

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02098		TDH-8120-1002 RELAY-FUEL XFR VLV IND, R (PROV)	284T0188 81205	1	28-31-11 P037-00/ /	276

EQUIPMENT LIST

D280T132

Section K02000

Page 3 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02103	9	BACR13CE2 RELAY-L ENG ANTI-ICE CMD (SB 30-0017)	284T0187 81205	1	30-21-11 P036-00/ /	150-154
K02103		BACR13CE2 RELAY-L ENG ANTI-ICE CMD	284T0187 81205	1	30-21-11 P036-00/ /	050-099, 155-199
K02104	9	BACR13CE2 RELAY-R ENG ANTI-ICE CMD (SB 30-0017)	284T0188 81205	1	30-21-11 P037-00/ /	150-154
K02104		BACR13CE2 RELAY-R ENG ANTI-ICE CMD	284T0188 81205	1	30-21-11 P037-00/ /	050-099, 155-199
K02105	9	BACR13CD2 RELAY-L ENG AUTO ANTI-ICE (SB 30-0017)	284T0187 81205	1	30-21-11 P036-00/ /	150-154
K02105		BACR13CD2 RELAY-L ENG AUTO ANTI-ICE	284T0187 81205	1	30-21-11 P036-00/ /	050-099, 155-199
K02106	9	BACR13CD2 RELAY-R ENG AUTO ANTI-ICE (SB 30-0017)	284T0188 81205	1	30-21-11 P037-00/ /	150-154
K02106		BACR13CD2 RELAY-R ENG AUTO ANTI-ICE	284T0188 81205	1	30-21-11 P037-00/ /	050-099, 155-199
K02107	9	BACR13CD2 RELAY-L ENG AUTO DISAGREE (SB 30-0017)	284T0187 81205	1	30-21-11 P036-00/ /	150-154
K02107		BACR13CD2 RELAY-L ENG AUTO DISAGREE	284T0187 81205	1	30-21-11 P036-00/ /	050-099, 155-199
K02108	9	BACR13CD2 RELAY-R ENG AUTO DISAGREE (SB 30-0017)	284T0188 81205	1	30-21-11 P037-00/ /	150-154
K02108		BACR13CD2 RELAY-R ENG AUTO DISAGREE	284T0188 81205	1	30-21-11 P037-00/ /	050-099, 155-199
K02109	9	BACR13CD2 RLY-L ICE DETECTOR ISOLATION(SB 30-0017)	284T0187 81205	1	30-21-11 P036-00/ /	150-154
K02109		BACR13CD2 RELAY-L ICE DETECTOR ISOLATION	284T0187 81205	1	30-21-11 P036-00/ /	050-099, 155-199
K02110	9	BACR13CD2 RLY-WING SW OFF (SB 30-0017)	284T0189 81205	1	30-81-01 P033-00/ /	150-154
K02110		BACR13CD2 RLY-WING SW OFF	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
K02111	9	BACR13CD2 RLY-L ENG SW OFF (SB 30-0017)	284T0189 81205	1	30-81-01 P033-00/ /	150-154

EQUIPMENT LIST

D280T132

Section K02100

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02111		BACR13CD2 RLY-L ENG SW OFF	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
K02112	9	BACR13CD2 RLY-R ENG SW OFF (SB 30-0017)	284T0189 81205	1	30-81-01 P033-00/ /	150-154
K02112		BACR13CD2 RLY-R ENG SW OFF	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
K02113	9	BACR13CD2 RLY-L DET FAIL (SB 30-0017)	284T0189 81205	1	30-81-01 P033-00/ /	150-154
K02113		BACR13CD2 RLY-L DET FAIL	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
K02114	9	BACR13CD2 RLY-R DET FAIL (SB 30-0017)	284T0189 81205	1	30-81-01 P033-00/ /	150-154
K02114		BACR13CD2 RLY-R DET FAIL	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
K02115	9	TDH-1852-7001 RELAY-TIME DELAY WING TAI (SB 30-0017)	284T0189 58657	1	30-11-01 P033-00/ /	150-154
K02115		TDH-1852-7001 RELAY-TIME DELAY WING TAI	284T0189 58657	1	30-11-01 P033-00/ /	050-099, 155-199
K02116	9	BACR13CD2 RELAY-AUTO TEST (SB 30-0017)	284T0189 81205	1	30-11-01 P033-00/ /	150-154
K02116		BACR13CD2 RELAY-AUTO TEST	284T0189 81205	1	30-11-01 P033-00/ /	050-099, 155-199
K02119		BACR13CG2A RELAY-FWD/AFT CGO FIRE DISC	284T0188 81205	1	21-43-11 P037-00/ /	ALL
K02120	9	BACR13CD2 RLY-R ICE DETECTOR ISOLATION(SB 30-0017)	284T0188 81205	1	30-21-11 P037-00/ /	150-154
K02120		BACR13CD2 RELAY-R ICE DETECTOR ISOLATION	284T0188 81205	1	30-21-11 P037-00/ /	050-099, 155-199
K02123		Y-D4N RELAY-32K ALTITUDE	284T0188 81205	1	21-61-81 P037-00/ /	ALL
K02126		BACR13CE2 RELAY-R FUEL JETTISON FAN SHED NO.1	284T0188 81205	1	21-26-11 P037-00/ /	050-099, 155-199, 276-299
K02127		BACR13CJ2 RLY-INV VOLT SENS	284T0997 81205	1	24-51-31 P006-00/ /	050-099, 155-199, 277-299

EQUIPMENT LIST

D280T132

Section K02100

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02128		BACR13CF2AB RLY-CTR BUS ISO INHIBIT	284T0997 81205	1	24-51-31 P006-00/ /	050-099, 155-199, 277-299
K02144	9	BACR13CF2AB RELAY-SENSOR FOUL, SYSTEM 1 (SB 38-0038)	284T1149 81205	1	38-32-15 P049-00/ /	156, 166
K02144	9	BACR13CF2AB RELAY-SENSOR FOUL, SYSTEM 1 (SB 38-0035)	284T1149 81205	1	38-32-01 P036-00/ /	275-276
K02144		BACR13CF2AB RELAY-SENSOR FOUL, SYSTEM 1	284T1149 81205	1	38-32-15 P049-00/ /	157, 167-199, 277- 299
K02145	9	BACR13CF2AB RELAY-SENSOR FOUL, SYSTEM 2 (SB 38-0038)	284T1149 81205	1	38-32-15 P049-00/ /	156, 166
K02145	9	BACR13CF2AB RELAY-SENSOR FOUL, SYSTEM 2 (SB 38-0035)	284T1149 81205	1	38-32-01 P049-00/ /	275-276
K02145		BACR13CF2AB RELAY-SENSOR FOUL, SYSTEM 2	284T1149 81205	1	38-32-15 P049-00/ /	157, 167-199, 277- 299
K02151	9	BACR13CE2 RLY-AFT CROSSFEED VLV DISAGREE SB28-0034	284T0189 81205	1	28-22-31 P033-00/ /	ALL
K02152	9	BACR13CE2 RLY-FWD CROSSFEED VLV DISAGREE SB28-0034	284T0189 81205	1	28-22-31 P033-00/ /	ALL
K02154	9	BACR13CG2A RELAY-AIR/GROUND,SYS NO. 1(SB78-0051FAA)	284T0187 81205	1	32-09-11 P036-00/ /	050-099, 150-156, 162-166, 275-276
K02154		BACR13CG2A RELAY-AIR/GROUND,SYS NO. 1 (RR 41033-23)	284T0187 81205	1	32-09-11 P036-00/ /	157
K02154		BACR13CG2A RELAY-AIR/GROUND,SYS NO. 1 (RR 41033-24)	284T0187 81205	1	32-09-11 P036-00/ /	167-199
K02154		BACR13CG2A RELAY-AIR/GROUND,SYS NO. 1 (RR 41034-20)	284T0187 81205	1	32-09-11 P036-00/ /	277-278
K02154		BACR13CG2A RELAY-AIR/GROUND,SYS NO. 1 (RR 41034-21)	284T0187 81205	1	32-09-11 P036-00/ /	280-299
K02155	9	BACR13CG2A RELAY-AIR/GROUND, SYS NO.1(SB78-0051FAA)	284T0187 81205	1	32-09-11 P036-00/ /	050-099, 150-156, 162-166, 275-276
K02155		BACR13CG2A RELAY-AIR/GROUND, SYS NO.1 (RR 41033-23)	284T0187 81205	1	32-09-11 P036-00/ /	157
K02155		BACR13CG2A RELAY-AIR/GROUND, SYS NO.1 (RR 41033-24)	284T0187 81205	1	32-09-11 P036-00/ /	167-199

EQUIPMENT LIST

D280T132

Section K02100

Page 3

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02155		BACR13CG2A RELAY-AIR/GROUND, SYS NO.1 (RR 41034-20)	284T0187 81205	1	32-09-11 P036-00/ /	277-278
K02155		BACR13CG2A RELAY-AIR/GROUND, SYS NO.1 (RR 41034-21)	284T0187 81205	1	32-09-11 P036-00/ /	280-299
K02157	9	BACR13CG2A RELAY-AIR/GROUND,SYS NO.2(SB78-0051FAA)	284T0188 81205	1	32-09-12 P037-00/ /	050-099, 150-156, 162-166, 275-276
K02157		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2 (RR 41033-23)	284T0188 81205	1	32-09-12 P037-00/ /	157
K02157		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2 (RR 41033-24)	284T0188 81205	1	32-09-12 P037-00/ /	167-199
K02157		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2 (RR 41034-20)	284T0188 81205	1	32-09-12 P037-00/ /	277-278
K02157		BACR13CG2A RELAY-AIR/GROUND,SYS NO.2 (RR 41034-21)	284T0188 81205	1	32-09-12 P037-00/ /	280-299
K02158	9	BACR13CD2 RELAY-L ENG T/R MAINT (SB 78-0051FAA)	284T0189 81205	1	78-36-11 P033-00/ /	050-099, 150-156, 162-166, 275-276
K02158		BACR13CD2 RELAY-L ENG T/R MAINT (RR 41033-23)	284T0189 81205	1	78-36-11 P033-00/ /	157
K02158		BACR13CD2 RELAY-L ENG T/R MAINT (RR 41033-24)	284T0189 81205	1	78-36-11 P033-00/ /	167-199
K02158		BACR13CD2 RELAY-L ENG T/R MAINT (RR 41034-20)	284T0189 81205	1	78-36-11 P033-00/ /	277-278
K02158		BACR13CD2 RELAY-L ENG T/R MAINT (RR 41034-21)	284T0189 81205	1	78-36-11 P033-00/ /	280-299
K02159	9	BACR13CD2 RELAY-R ENG T/R MAINT (SB 78-0051FAA)	284T0189 81205	1	78-36-21 P033-00/ /	050-099, 150-156, 162-166, 275-276
K02159		BACR13CD2 RELAY-R ENG T/R MAINT (RR 41033-23)	284T0189 81205	1	78-36-21 P033-00/ /	157
K02159		BACR13CD2 RELAY-R ENG T/R MAINT (RR 41033-24)	284T0189 81205	1	78-36-21 P033-00/ /	167-199
K02159		BACR13CD2 RELAY-R ENG T/R MAINT (RR 41034-20)	284T0189 81205	1	78-36-21 P033-00/ /	277-278
K02159		BACR13CD2 RELAY-R ENG T/R MAINT (RR 41034-21)	284T0189 81205	1	78-36-21 P033-00/ /	280-299

EQUIPMENT LIST

D280T132

Section K02100

Page 4

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02160	9	BACR13CD2 RLY-L ENG AUTO-RESTOW PRESS(SB78-051FAA)	284T0189 81205	1	78-36-11 P033-00/ /	050-099, 150-156, 162-166, 275-276
K02160		BACR13CD2 RLY-L ENG AUTO-RESTOW PRESS(RR 41033-23)	284T0189 81205	1	78-36-11 P033-00/ /	157
K02160		BACR13CD2 RLY-L ENG AUTO-RESTOW PRESS(RR 41033-24)	284T0189 81205	1	78-36-11 P033-00/ /	167-199
K02160		BACR13CD2 RLY-L ENG AUTO-RESTOW PRESS(RR 41034-20)	284T0189 81205	1	78-36-11 P033-00/ /	277-278
K02160		BACR13CD2 RLY-L ENG AUTO-RESTOW PRESS(RR 41034-21)	284T0189 81205	1	78-36-11 P033-00/ /	280-299
K02161	9	BACR13CD2 RLY-R ENG AUTO-RESTOW PRESS(SB78-051FAA)	284T0189 81205	1	78-36-21 P033-00/ /	050-099, 150-156, 162-166, 275-276
K02161		BACR13CD2 RLY-R ENG AUTO-RESTOW PRESS(RR 41033-23)	284T0189 81205	1	78-36-21 P033-00/ /	157
K02161		BACR13CD2 RLY-R ENG AUTO-RESTOW PRESS(RR 41033-24)	284T0189 81205	1	78-36-21 P033-00/ /	167-199
K02161		BACR13CD2 RLY-R ENG AUTO-RESTOW PRESS(RR 41034-20)	284T0189 81205	1	78-36-21 P033-00/ /	277-278
K02161		BACR13CD2 RLY-R ENG AUTO-RESTOW PRESS(RR 41034-21)	284T0189 81205	1	78-36-21 P033-00/ /	280-299
K02162	9	3SAM6015M2 RLY-L ENG T/R MAINT LATCH(SB 78-0051FAA)	284T0189 81205	1	78-36-11 P033-00/ /	050-099, 150-156, 162-166, 275-276
K02162		3SAM6015M2 RLY-L ENG T/R MAINT LATCH (RR 41033-23)	284T0189 81205	1	78-36-11 P033-00/ /	157
K02162		3SAM6015M2 RLY-L ENG T/R MAINT LATCH (RR 41033-24)	284T0189 81205	1	78-36-11 P033-00/ /	167-199
K02162		3SAM6015M2 RLY-L ENG T/R MAINT LATCH(RR 41034-20)	284T0189 81205	1	78-36-11 P033-00/ /	277-278
K02162		3SAM6015M2 RLY-L ENG T/R MAINT LATCH (RR 41034-21)	284T0189 81205	1	78-36-11 P033-00/ /	280-299
K02163	9	3SAM6015M2 RELAY-R ENG T/R MAINT LATCH(SB78-051FAA)	284T0189 81205	1	78-36-21 P033-00/ /	050-099, 150-156, 162-166, 275-276
K02163		3SAM6015M2 RELAY-R ENG T/R MAINT LATCH(RR 41033-23)	284T0189 81205	1	78-36-21 P033-00/ /	157

EQUIPMENT LIST

D280T132

Section K02100

Page 5

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02163		3SAM6015M2 RLY-R ENG T/R MAINT LATCH (RR 41033-24)	284T0189 81205	1	78-36-21 P033-00/ /	167-199
K02163		3SAM6015M2 RELAY-R ENG T/R MAINT LATCH(RR 41034-20)	284T0189 81205	1	78-36-21 P033-00/ /	277-278
K02163		3SAM6015M2 RELAY-R ENG T/R MAINT LATCH(RR 41034-21)	284T0189 81205	1	78-36-21 P033-00/ /	280-299
K02164	9	BACR13CG2A RLY-L ENG T/R DEPLOY (SB 78-0051FAA)	284T0187 81205	1	78-36-11 P036-00/ /	050-099, 150-156, 162-166, 275-276
K02164		BACR13CG2A RLY-L ENG T/R DEPLOY (RR 41033-23)	284T0187 81205	1	78-36-11 P036-00/ /	157
K02164		BACR13CG2A RLY-L ENG T/R DEPLOY (RR 41033-24)	284T0187 81205	1	78-36-11 P036-00/ /	167-199
K02164		BACR13CG2A RLY-L ENG T/R DEPLOY (RR 41034-20)	284T0187 81205	1	78-36-11 P036-00/ /	277-278
K02164		BACR13CG2A RLY-L ENG T/R DEPLOY (RR 41034-21)	284T0187 81205	1	78-36-11 P036-00/ /	280-299
K02165	9	BACR13CG2A RLY-R ENG T/R DEPLOY (SB 78-0051FAA)	284T0188 81205	1	78-36-21 P037-00/ /	050-099, 150-156, 162-166, 275-276
K02165		BACR13CG2A RLY-R ENG T/R DEPLOY (RR 41033-23)	284T0188 81205	1	78-36-21 P037-00/ /	157
K02165		BACR13CG2A RLY-R ENG T/R DEPLOY (RR 41033-24)	284T0188 81205	1	78-36-21 P037-00/ /	167-199
K02165		BACR13CG2A RLY-R ENG T/R DEPLOY (RR 41034-20)	284T0188 81205	1	78-36-21 P037-00/ /	277-278
K02165		BACR13CG2A RLY-R ENG T/R DEPLOY (RR 41034-21)	284T0188 81205	1	78-36-21 P037-00/ /	280-299
K02181	9	TDH-8120-1002 RELAY-R T/R UPPER ACT UNLK (SB 78-0062)	284T0189 81205	1	78-34-21 P033-00/ /	ALL
K02182	9	TDH-8120-1002 RLY-L T/R UPPER ACT UNLK (SB 78-0062)	284T0189 81205	1	78-34-11 P033-00/ /	ALL
K02185	9	BACR13CF2A RLY-R T/R HIV DELAY (SB 78-0062)	284T0189 81205	1	78-34-21 P033-00/ /	ALL
K02186	9	600-154-2000 RLY-L T/R HIV DELAY (SB 78-0062)	284T0189 81205	1	78-34-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K02100

Page 6

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02187	9	KL-X4A-011 RLY-R T/R SSL CONTROL (SB 78-0062)	284T0189 81205	1	78-34-21 P033-00/ /	ALL
K02188	9	KL-X4A-011 RLY-L T/R SSL CONTROL (SB 78-0062)	284T0189 81205	1	78-34-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K02100
Page 7 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02232	9	BACR13CE2 RLY-CONT IGN IDLE-L ENG (SB 73-0044)	284T3601 81205	1	73-21-19 P036-00/ /	050-099, 150-199
K02233	9	BACR13CE2 RLY-CONT IGN IDLE-R ENG (SB 73-0044)	284T3701 81205	1	73-21-19 P037-00/ /	050-099, 150-199
K02289	9	BACR13CG2A RLY-R.FWD DOOR AREA HEATING (SB 21-0139)	284T1351 81073	1	21-45-21 P037-00/ /	275-299

EQUIPMENT LIST

D280T132

Section K02200

Page 1 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K02307	9	BACR13CG2AB RLY-SLAT SKEW DETN (PROV) (SB 27A0140)	284T1351 97904	1	27-89-11 P037-00/ /	150, 152-199, 275-299
K02307	9	BACR13CG2AB RLY-SLAT SKEW DETECTION (SB 27A0140)	284T3701 97904	1	27-89-11 P037-00/ /	151
K02310	9	BACR13CF2A RELAY-LAVATORY FLUSH CONTROL(SB 38-0054)	284T0187 81205	1	38-32-11 P036-00/ /	156-157, 166-199, 277-299
K02311	9	BACR13CF2A RLY-LAVATORY FLUSH CONTROL (SB 38-0054)	284T0187 81205	1	38-32-11 P036-00/ /	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section K02300
Page 1 End
Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K09035	9	CUSTOMER RELAY-PAX TELEPHONE PWR (MTO 230595)	CUSTOMER CUST	1	23-19-11 P036-00/ /	150
K09035	9	CUSTOMER RELAY-PAX TELEPHONE PWR (MTO 230596)	CUSTOMER CUST	1	23-19-11 P036-00/ /	152-199
K09036	9	BACR13CE2 RLY-TERRAIN DISPLAY (MTO-340961)	CUSTOMER 81205	1	34-46-11 SHELF/E01/05	150, 152-199, 275-299
K09037	9	BACR13CE2 RLY-TERRAIN DISPLAY (MTO-340961)	CUSTOMER 81205	1	34-46-11 SHELF/E01/05	150, 152-199, 275-299
K09038	9	BACR13CE2 RLY-TERRAIN DISPLAY (MTO-340961)	CUSTOMER 81205	1	34-46-11 SHELF/E01/05	150, 152-199, 275-299
K09039	9	BACR13CE2 RLY-TERRAIN DISPLAY (MTO-340961)	CUSTOMER 81205	1	34-46-11 SHELF/E01/05	150, 152-199, 275-299

EQUIPMENT LIST

D280T132

Section K09000

Page 1 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10109	1	TDH-1853-1501 RELAY-UTIL/GALLEY PWR FLT RESET	284T0187 58657	1	24-51-71 P036-00/ /	ALL
K10109	2	600-159-1501 RELAY-UTIL/GALLEY PWR FLT RESET	284T0187 15420	1	24-51-71 P036-00/ /	ALL
K10109	3	600-159-1500M-0 RELAY-UTIL/GALLEY PWR FLT RESET	284T0187 15420	1	24-51-71 P036-00/ /	ALL
K10136		BACR13CG2AB RLY-GALLEY GND LOAD SHED	284T0187 81205	1	24-51-71 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K10100
Page 1 End
Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10229		BACR13CF2A RLY-ANTISKID 1 + 5 FAIL	284T0187 81205	1	32-42-11 P036-00/ /	ALL
K10230		BACR13CF2A RLY-ANTISKID 4 + 8 FAIL	284T0187 81205	1	32-42-11 P036-00/ /	ALL
K10231		BACR13CF2A RLY-ANTISKID 2 + 6 FAIL	284T0187 81205	1	32-42-11 P036-00/ /	ALL
K10232		BACR13CF2A RLY-ANTISKID 3 + 7 FAIL	284T0187 81205	1	32-42-11 P036-00/ /	ALL
K10233		BACR13CF2A RLY-ANTISKID ALTERNATE FAIL	284T0187 81205	1	32-42-11 P036-00/ /	ALL
K10234		BACR13CD2 RLY-L T/R DISAGREE	284T0187 81205	1	78-36-11 P036-00/ /	ALL
K10235		BACR13CD2 RLY-R T/R DISAGREE	284T0188 81205	1	78-36-21 P037-00/ /	ALL
K10236		BACR13CD2 RLY-L T/R HYD ISLN VALVE	284T0187 81205	1	78-36-11 P036-00/ /	ALL
K10237		BACR13CD2 RLY-R T/R HYD ISLN VALVE	284T0188 81205	1	78-36-21 P037-00/ /	ALL
K10247		BACR13CG2A RLY-L ENG START 2	284T0997 81205	1	80-11-11 P006-05/ /	ALL
K10250		BACR13CG2A RLY-R ENG START 2	284T0997 81205	1	80-11-21 P006-05/ /	ALL

EQUIPMENT LIST

D280T132

Section K10200

Page 1 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10312		BACR13CD2 RLY-FWD ZONE AUTO/OFF	284T0188 81205	1	21-61-21 P037-00/ /	ALL
K10313		BACR13CD2 RLY-AFT ZONE AUTO/OFF	284T0188 81205	1	21-61-31 P037-00/ /	ALL
K10315		BACR13CE2 RLY-L PACK AUTO/MANUAL 3	284T0187 81205	1	21-53-11 P036-00/ /	ALL
K10316		BACR13CE2 RLY-R PACK AUTO/MANUAL 3	284T0189 81205	1	21-53-21 P033-00/ /	ALL
K10317		BACR13CE2 RLY-L PACK LOW LIMIT VALVE	284T0189 81205	1	21-51-13 P033-00/ /	ALL
K10318		BACR13CE2 RLY-R PACK LOW LIMIT VALVE	284T0189 81205	1	21-51-23 P033-00/ /	ALL
K10323	9	BACR13CD2 RELAY	284T0125 81205	1	23-22-12 SHELF/E02/05	275-276, 280-299
K10323		BACR13CD2 RELAY	284T0125 81205	1	23-22-12 SHELF/E02/05	277-278
K10358		BACR13CD2 RLY-L T/R ISN DETECT	284T0189 81205	1	78-36-11 P033-00/ /	ALL
K10359		BACR13CD2 RLY - R T/R ISNL DETECT	284T0189 81205	1	78-36-21 P033-00/ /	ALL
K10363		BACR13CD2 RLY-FWD ZONE INOP	284T0188 81205	1	21-61-21 P037-00/ /	ALL
K10364		BACR13CD2 RELAY-AFT ZONE INOP	284T0188 81205	1	21-61-31 P037-00/ /	ALL
K10391	1	TDH-1852-3001 RLY-GND GALLEY LOAD SHED CONTROL	284T0187 58657	1	24-51-71 P036-00/ /	ALL
K10391	2	600-154-3001 RLY-GND GALLEY LOAD SHED CONTROL	284T0187 15420	1	24-51-71 P036-00/ /	ALL
K10391	3	600-154-3000M-0 RLY-GND GALLEY LOAD SHED CONTROL	284T0187 15420	1	24-51-71 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K10300
Page 1 End
Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10446	9	BACR13CG2A RELAY-GEAR TILT-RIGHT GEAR (SB 27A0160)	284T3300 81205	1	27-62-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K10400

Page 1 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
K10690	9	BACR13CD2 RELAY-T/D CONTROL, R (SB 28A0083)	284T3701 81205	1	28-22-12 P037-00/ /	ALL
K10691	9	BACR13CD2 RELAY-T/D CONTROL, L (SB 28A0083)	284T3601 81205	1	28-22-12 P036-00/ /	ALL
K10692	9	TDH-1852-1402 RELAY- AUTO SHUTOFF T/D, R (SB 28A0083)	284T3701 58657	1	28-22-12 P037-00/ /	ALL
K10693	9	TDH-1852-1402 RELAY- AUTO SHUTOFF T/D, L (SB 28A0083)	284T3601 58657	1	28-22-12 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section K10600
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00019		S231T300-1226 LT-AUTOPILOT CAUTION	233T2222 81205	1	22-14-11 P001-03/ /	ALL
L00024		60B50041-2 LT-CLOSET	417T5082 81205	1	33-22-21 0469/254/L064	050-099
L00024 T		1864 LAMP-CLOSET	60B50041 08806	1	33-22-21 / /	050-099
L00028		69B41965-1 LT-CHART,CAPT	232T5008 81205	1	33-14-21 P007-00/ /	ALL
L00028 T		1864 LAMP	69B41965 08805	1	33-14-21 / /	ALL
L00029		69B41965-1 LT-CHART,F/O	232T5008 81205	1	33-14-21 P007-00/ /	ALL
L00029 T		1864 LAMP	69B41965 08805	1	33-14-21 / /	ALL
L00030		S232T500-1 LT-MAP,CAPT OVHD	232T5001 81205	1	33-14-11 0181/265/L019	ALL
L00030 T		1308 LAMP-CAPT MAP	S232T500 08806	1	33-14-11 / /	ALL
L00031		S232T500-1 LT-MAP,F/O OVHD	232T5001 81205	1	33-14-11 0181/265/R019	ALL
L00031 T		1308 LAMP-F/O MAP	S232T500 08806	1	33-14-11 / /	ALL
L00034		34265-8 LT-FLT KIT,CAPT	232T5004 72914	1	33-14-31 0170/227/L045	ALL
L00034 T		313 LAMP	34265000 08805	1	33-14-31 / /	ALL
L00037		34265-8 LT-FLT KIT,F/O	232T5004 72914	1	33-14-31 0165/223/R045	ALL
L00037 T		313 LAMP	34265000 08805	1	33-14-31 / /	ALL
L00038		60B40059-4 LT-DOME,CAPT	232T5003 81205	1	33-11-14 0203/270/L026	ALL
L00038 T		1665 LAMP	60B40059 08805	1	33-11-14 / /	ALL

EQUIPMENT LIST

D280T132

Section L00000

Page 1

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00039		60B40059-4 LT-DOME,F/O	233T5003 81205	1	33-11-14 0203/270/R026	ALL
L00039 T		1665 LAMP	60B40059 08805	1	33-11-14 //	ALL
L00047		60B40059-4 LT-AFT FLT DECK DOME	232T5003 81205	1	33-11-14 0221/280/L026	ALL
L00047 T		1665 LAMP	60B40059 08805	1	33-11-14 //	ALL
L00049		S233T810-1 FLOODLIGHT-INSTR PNL,CAPT	233T8101 81205	1	33-11-11 P007-00/	ALL
L00049 T		5108W LAMP-FLOURESCENT	S233T810 08805	2	33-11-11 //	ALL
L00050		S233T810-10 FLOODLIGHT-INSTR PNL,CTR	233T8101 81205	1	33-11-11 P007-00/	ALL
L00050 T		5108W LAMP-FLOURESCENT	S233T810 08805	1	33-11-11 //	ALL
L00051		S233T810-1 FLOODLIGHT-INSTR PNL,F/O	233T8101 81205	1	33-11-11 P007-00/	ALL
L00051 T		5108W LAMP-FLOURESCENT	S233T810 08805	2	33-11-11 //	ALL
L00054		10-0015-5 LT-NOSE GEAR WHEEL WELL	284T0155 72914	1	33-31-11 0182/176/0000	ALL
L00054 T		3011 LAMP	284T0155 08805	1	33-31-11 //	ALL
L00055		10-0015-5 LIGHT-NOSE GEAR WHEEL WELL	284T0155 72914	1	33-31-11 0261/185/L014	ALL
L00055 T		3011 LAMP	284T0155 08805	1	33-31-11 0261/185/L014	ALL
L00056		10-0015-5 LT-L MAIN WHEEL WELL	284T0628 72914	1	33-31-11 1005/185/L044	ALL
L00056 T		3011 LAMP	284T0628 08805	1	33-31-11 //	ALL
L00057		10-0015-5 LT-L MAIN WHEEL WELL	284T0628 72914	1	33-31-11 1020/185/L044	ALL

EQUIPMENT LIST

D280T132

Section L00000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00057 T		3011 LAMP	284T0628 08805	1	33-31-11 / /	ALL
L00060		S283T008-9 LIGHT-WING ILLUMINATION,R	284T0230 81205	1	33-41-11 0643/207/R098	050-099
L00060		S283T008-90 LIGHT-WING ILLUMINATION,R	284T0230 81205	1	33-41-11 0654+35/207/R098	150-199, 275-299
L00060 T	1	Q4631 LAMP	284T0230 08805	1	33-41-11 / /	ALL
L00060 T	2	Q4631 LAMP	284T0230 S5006	1	33-41-11 / /	ALL
L00061		S283T008-8 LIGHT-WING ILLUMINATION,L	284T0230 81205	1	33-41-11 0643/207/L098	050-099
L00061		S283T008-89 LIGHT-WING ILLUMINATION,L	284T0230 81205	1	33-41-11 0654+35/207/L098	150-199, 275-299
L00061 T	1	Q4631 LAMP	284T0230 08805	1	33-41-11 / /	ALL
L00061 T	2	Q4631 LAMP	284T0230 S5006	1	33-41-11 / /	ALL
L00062		15-0143-7 LIGHT-FUELING PANEL	284T0562 72914	1	28-21-11 FSS0672/12/FS	ALL
L00062 T		1691 LAMP	284T0253 08805	1	28-21-11 / /	ALL
L00063	1	121-563-1005-005 LIGHT-FUELING VALVE,L OUTBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00063	2	121-563-1006-004 LIGHT-FUELING VALVE,L OUTBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00063	3	121-563-1005-001 LIGHT-FUELING VALVE,L OUTBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00064	1	121-563-1005-005 LIGHT-FUELING VALVE,L INBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00064	2	121-563-1006-004 LIGHT-FUELING VALVE,L INBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00064	3	121-563-1005-001 LIGHT-FUELING VALVE,L INBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL

EQUIPMENT LIST

D280T132

Section L00000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00065	1	121-563-1005-005 LIGHT-FUELING VALVE,R INBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00065	2	121-563-1006-004 LIGHT-FUELING VALVE,R INBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00065	3	121-563-1005-001 LIGHT-FUELING VALVE,R INBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00066	1	121-563-1005-005 LIGHT-FUELING VALVE,R OUTBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00066	2	121-563-1006-004 LIGHT-FUELING VALVE,R OUTBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00066	3	121-563-1005-001 LIGHT-FUELING VALVE,R OUTBD	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00067	1	121-563-1005-005 LIGHT-DEFUELING VALVE,LEFT	344T0021 81590	1	28-26-11 P028-00/ /	ALL
L00067	2	121-563-1006-004 LIGHT-DEFUELING VALVE,LEFT	344T0021 81590	1	28-26-11 P028-00/ /	ALL
L00067	3	121-563-1005-001 LIGHT-DEFUELING VALVE,LEFT	344T0021 81590	1	28-26-11 P028-00/ /	ALL
L00068	1	121-563-1005-005 LIGHT-DEFUELING VALVE,RIGHT	344T0021 81590	1	28-26-11 P028-00/ /	ALL
L00068	2	121-563-1006-004 LIGHT-DEFUELING VALVE,RIGHT	344T0021 81590	1	28-26-11 P028-00/ /	ALL
L00068	3	121-563-1005-001 LIGHT-DEFUELING VALVE,RIGHT	344T0021 81590	1	28-26-11 P028-00/ /	ALL
L00072		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0320/188/R029	ALL
L00072 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00073		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0330/188/R044	ALL
L00073 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00074		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0268/193/R040	ALL

EQUIPMENT LIST

D280T132

Section L00000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00074 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00075		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0225/200/R045	ALL
L00075 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00076		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0325/193/L023	ALL
L00076 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00077		15-0143-15 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0329/193/L050	ALL
L00077 T		1691 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00078		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0215/200/L048	ALL
L00078 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00079		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0152/208/R012	ALL
L00079 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00080		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0152/208/L012	ALL
L00080 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00081	1	33-32683-6P1 LIGHT-HOT BUS WARN,EXT PWR	284T0175 29207	1	24-41-11 P034-00/ /	ALL
L00081	2	33-32683-6P4 LIGHT-HOT BUS WARN,EXT PWR	284T0175 29207	1	24-41-11 P034-00/ /	ALL
L00081 T		AIG LAMP	284T0175 29207	1	24-41-11 / /	ALL
L00082	1	13-32480-5 LIGHT-AC CONNECTED	284T0390 29207	1	24-41-12 P030-00/ /	ALL

EQUIPMENT LIST

D280T132

Section L00000

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00082	2	103C1D2F2-C-L1M545T2 LIGHT-AC CONNECTED	284T0390 81590	1	24-41-12 P030-00/ /	ALL
L00082 T		1819 LAMP	284T0390 71744	1	24-41-12 / /	ALL
L00083	1	13-32480-5 LIGHT-PWR NOT IN USE	284T0390 29207	1	24-41-12 P030-00/ /	ALL
L00083	2	103C1D2F2-C-L1M545T2 LIGHT-PWR NOT IN USE	284T0390 81590	1	24-41-12 P030-00/ /	ALL
L00083 T		1819 LAMP	284T0390 71744	1	24-41-12 / /	ALL

EQUIPMENT LIST

D280T132

Section L00000
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00101		S283T012-9 LIGHT-ANTI-COLL,L WING	284T0224 81205	1	33-44-21 L1154/12/TIP	ALL
L00101 T		31-5451-1 LAMP MODULE	284T0224 72914	1	33-44-21 / /	ALL
L00102		S283T012-8 LIGHT-ANTI-COLL,R WING	284T0224 81205	1	33-44-21 R1154/12/TIP	ALL
L00102 T		31-5451-1 LAMP MODULE	284T0224 72914	1	33-44-21 / /	ALL
L00103	1	S283T012-27 LIGHT-ANTI-COLLISION,BODY,UPPER	284T0232 81205	1	33-44-11 0555/320/0000	ALL
L00103	2	S283T012-26 LIGHT-ANTI-COLLISION,BODY,UPPER	284T0232 81205	1	33-44-11 0555/320/0000	ALL
L00103	3	S283T012-23 LIGHT-ANTI-COLLISION,BODY,UPPER	284T0232 81205	1	33-44-11 0555/320/0000	ALL
L00103	4	S283T012-10 LIGHT-ANTI-COLLISION,BODY,UPPER	284T0232 81205	1	33-44-11 0555/320/0000	ALL
L00103 T		31-5241-1 LAMP MODULE	284T0232 72914	1	33-44-11 / /	ALL
L00104	1	S283T012-27 LIGHT-ANTI-COLLISION,BODY,LWR	284T0232 81205	1	33-44-11 0860/107/0000	ALL
L00104	2	S283T012-23 LIGHT-ANTI-COLLISION,BODY,LWR	284T0232 81205	1	33-44-11 0860/107/0000	ALL
L00104	3	S283T012-10 LIGHT-ANTI-COLLISION,BODY,LWR	284T0232 81205	1	33-44-11 0860/107/0000	ALL
L00104 T		31-5241-1 LAMP-MODULE	284T0232 72914	1	33-44-11 / /	ALL
L00105		S283T013-17 LIGHT-POSITION,LEFT REAR	284T0224 81205	1	33-43-11 L1154/12/TIP	ALL
L00105 T		1978X LAMP	284T0224 08805	2	33-43-11 / /	ALL
L00106		S283T013-18 LIGHT-POSITION,RIGHT REAR	284T0224 81205	1	33-43-11 R1154/12/TIP	ALL
L00106 T		1978X LAMP	284T0224 08805	2	33-43-11 / /	ALL

EQUIPMENT LIST

D280T132

Section L00100

Page 1

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00107		S283T013-15 LIGHT-POSITION,LEFT FWD	284T0224 81205	1	33-43-11 L1122/12/TIP	ALL
L00107 T		1978X LAMP	284T0224 08805	2	33-43-11 / /	ALL
L00108		S283T013-16 LIGHT-POSITION,RIGHT FWD	284T0224 81205	1	33-43-11 R1122/12/TIP	ALL
L00108 T		1978X LAMP	284T0224 08805	2	33-43-11 / /	ALL
L00111		Q4559X LAMP-WING LANDING,L	284T0233 08805	1	33-42-11 0738/170/L113	ALL
L00112		Q4559X LAMP-WING LANDING,R	284T0233 08805	1	33-42-11 0738/170/R113	ALL
L00113		Q4559X LAMP-NOSE GEAR LANDING,L	284T0588 08805	1	33-42-11 0263/112/L009	ALL
L00114		Q4559X LAMP-NOSE GEAR LANDING,R	284T0588 08805	1	33-42-11 0263/112/R009	ALL
L00115		4551 LAMP-RWY TURNOFF,L	284T0233 08805	1	33-42-21 0733/170/L106	ALL
L00116		4551 LAMP-RWY TURNOFF,R	284T0233 08805	1	33-42-21 0733/170/R106	ALL
L00117		10-0015-5 LIGHT-R MAIN WHEEL WELL	284T0628 72914	1	33-31-11 1020/185/R044	ALL
L00117 T		3011 LAMP	284T0628 08805	1	33-31-11 / /	ALL
L00118		10-0015-5 LIGHT-R MAIN WHEEL WELL	284T0628 72914	1	33-31-11 1005/185/R044	ALL
L00118 T		3011 LAMP	284T0628 08805	1	33-31-11 / /	ALL
L00119		S231T300-1010 LIGHT-AUTOBRAKE	233T2222 81205	1	32-42-12 P001-03/ /	ALL
L00119 A		MS25237-387 LAMP-28V	233T2222 96906	2	32-42-12 / /	ALL
L00119 D		434-093-001 DIODE/FUSE ASSY	233T2222 81590	1	32-42-12 / /	ALL

EQUIPMENT LIST

D280T132

Section L00100

Page 2

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00122	1	33-32683-6P1 LIGHT-HOT BUS WARN,AC TIE BUS	284T0171 29207	1	24-21-51 P031-00/ /	ALL
L00122	2	33-32683-6P4 LIGHT-HOT BUS WARN,AC TIE BUS	284T0171 29207	1	24-21-51 P031-00/ /	ALL
L00122 T		AIG LAMP	284T0171 29207	1	24-21-51 / /	ALL
L00123	1	33-32683-6P1 LIGHT-HOT BUS WARN,AC TIE BUS	284T0172 29207	1	24-21-51 P032-00/ /	ALL
L00123	2	33-32683-6P4 LIGHT-HOT BUS WARN,AC TIE BUS	284T0172 29207	1	24-21-51 P032-00/ /	ALL
L00123 T		AIG LAMP	284T0172 29207	1	24-21-51 / /	ALL
L00124	1	33-32683-6P1 LIGHT-HOT BUS WARN,AC TIE BUS	284T0175 29207	1	24-21-51 P034-00/ /	ALL
L00124	2	33-32683-6P4 LIGHT-HOT BUS WARN,AC TIE BUS	284T0175 29207	1	24-21-51 P034-00/ /	ALL
L00124 T		AIG LAMP	284T0175 29207	1	24-21-51 / /	ALL
L00125	1	33-32683-6P1 LIGHT-HOT BUS WARN,R 115V AC	284T0172 29207	1	24-21-21 P032-00/ /	ALL
L00125	2	33-32683-6P4 LIGHT-HOT BUS WARN,R 115V AC	284T0172 29207	1	24-21-21 P032-00/ /	ALL
L00125 T		AIG LAMP	284T0172 29207	1	24-21-21 / /	ALL
L00126	1	33-32683-6P1 LT-HOT BUS WARN,R GEN	284T0172 29207	1	24-21-21 P032-00/ /	ALL
L00126	2	33-32683-6P4 LT-HOT BUS WARN,R GEN	284T0172 29207	1	24-21-21 P032-00/ /	ALL
L00126 T		AIG LAMP	284T0172 29207	1	24-21-21 / /	ALL
L00127	1	33-32683-6P1 LIGHT-HOT BUS WARN,L 115V AC	284T0171 29207	1	24-21-11 P031-00/ /	ALL
L00127	2	33-32683-6P4 LIGHT-HOT BUS WARN,L 115V AC	284T0171 29207	1	24-21-11 P031-00/ /	ALL

EQUIPMENT LIST

D280T132

Section L00100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00127 T		AIG LAMP	284T0171 29207	1	24-21-11 / /	ALL
L00128	1	33-32683-6P1 LT-HOT BUS WARN,L GEN	284T0171 29207	1	24-21-11 P031-00/ /	ALL
L00128	2	33-32683-6P4 LT-HOT BUS WARN,L GEN	284T0171 29207	1	24-21-11 P031-00/ /	ALL
L00128 T		AIG LAMP	284T0171 29207	1	24-21-11 / /	ALL
L00131		15-0143-7 LIGHT-AIR COND COMPT	284T0938 72914	1	33-31-21 0858/115/L010	ALL
L00131 T		1691 LAMP	284T0657 08805	1	33-31-21 / /	ALL
L00132		15-0143-7 LIGHT-AIR COND COMPT	284T0938 72914	1	33-31-21 0885/130/L062	ALL
L00132 T		1691 LAMP	284T0657 08805	1	33-31-21 / /	ALL
L00133		15-0143-7 LIGHT-AIR COND COMPT	284T0980 72914	1	33-31-21 0865/118/R062	ALL
L00133 T		1691 LAMP	284T0657 08805	1	33-31-21 / /	ALL
L00134		15-0143-7 LIGHT-AIR COND COMPT	284T0980 72914	1	33-31-21 0917/115/R010	ALL
L00134 T		1691 LAMP	284T0657 08805	1	33-31-21 / /	ALL
L00135	1	33-32683-6P1 LIGHT-HOT BUS WARN,APU GEN	284T0175 29207	1	24-21-41 P034-00/ /	ALL
L00135	2	33-32683-6P4 LIGHT-HOT BUS WARN,APU GEN	284T0175 29207	1	24-21-41 P034-00/ /	ALL
L00135 T		AIG LAMP	284T0175 29207	1	24-21-41 / /	ALL
L00136		S231T300-1224 LIGHT-ALTITUDE ALERT	233T2222 81205	1	34-16-11 P001-03/ /	ALL
L00137		S283T008-10 LIGHT-FORWARD CARGO EXTERIOR	284T0231 81205	1	33-31-61 0648/144/R073	050-099

EQUIPMENT LIST

D280T132

Section L00100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00137		S283T008-10 LIGHT-FORWARD CARGO EXTERIOR	284T0231 81205	1	33-31-61 0639/146/R072	150-199, 275-299
L00137 T		4571 LAMP	284T0213 08805	1	33-31-61 / /	ALL
L00138		S283T008-14 LIGHT-AFT CARGO EXTERIOR	284T0231 81205	1	33-31-61 1384/143/R075	ALL
L00138 T		4571 LAMP	284T0231 08805	1	33-31-61 / /	ALL
L00139		S283T008-11 LIGHT-BULK CARGO EXTERIOR	284T0231 81205	1	33-31-61 1384/143/L075	050-099, 150-199
L00139 T		4571 LAMP	284T0231 08805	1	33-31-61 / /	050-099, 150-199
L00140		S283T008-19 LIGHT-BULK CARGO EXTERIOR	284T0231 81205	1	33-31-61 1491/149/L069	050-099, 150-199
L00140 T		4571 LAMP	284T0231 08805	1	33-31-61 / /	050-099, 150-199
L00145		L5105-AM LIGHT-BAY F OFF	284T0687 81640	1	25-53-13 P035-00/ /	050-099
L00145 T		MS25237-387 LAMP	284T0687 96906	1	25-53-13 / /	050-099
L00149		L5105-AM LIGHT-BAY A OFF	284T0687 81640	1	25-53-13 P035-00/ /	050-099
L00149 T		MS25237-387 LAMP	284T0687 96906	1	25-53-13 / /	050-099
L00157		L5105-AM LIGHT-IND,PDU BAY A-B OFF	284T0688 81640	1	25-53-23 P039-00/ /	050-099
L00157 T		MS25237-387 LAMP	284T0688 96906	1	25-53-23 / /	050-099
L00158		L5105-AM LIGHT-IND,PDU BAY A OFF	284T0688 81640	1	25-53-23 P039-00/ /	050-099
L00158 T		MS25237-387 LAMP	284T0688 96906	1	25-53-23 / /	050-099
L00159		L5105-AM LIGHT-BAY A-B ON	284T0688 81640	1	25-53-23 P039-00/ /	050-099

EQUIPMENT LIST

D280T132

Section L00100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00159	T	MS25237-387 LAMP	284T0688 96906	1	25-53-23 / /	050-099
L00161		15-0188-7 LIGHT-FWD A CARGO COMPT	455T1103 72914	1	33-37-11 0424/194/R035	ALL
L00161	T	3011 LAMP	455T1103 08806	1	33-37-11 / /	ALL
L00162		15-0188-7 LIGHT-FWD A CARGO COMPT	455T1103 72914	1	33-37-11 0422/194/L032	ALL
L00162	T	3011 LAMP	455T1103 08806	1	33-37-11 / /	ALL
L00163		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0489/194/R031	050-099, 275-299
L00163		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0489/193/R029	150-199
L00163	T	3011 LAMP	455T1103 08806	1	33-37-11 / /	ALL
L00164		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0489/194/L030	050-099
L00164		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0489/193/L029	150-199, 275-299
L00164	T	3011 LAMP	455T1103 08806	1	33-37-11 / /	ALL
L00165		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0577/194/R031	050-099, 275-299
L00165		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0577/193/R029	150-199
L00165	T	3011 LAMP	455T1103 08806	1	33-37-11 / /	ALL
L00166		15-0188-7 LIGHT-FWD A CARGO COMPT	455T1103 72914	1	33-37-11 0577/194/L031	050-099
L00166		15-0188-7 LIGHT-FWD A CARGO COMPT	455T1103 72914	1	33-37-11 0577/193/L029	150-199, 275-299
L00166	T	3011 LAMP-	455T1103 08806	1	33-37-11 / /	ALL

EQUIPMENT LIST

D280T132

Section L00100

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00167		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0643/193/R031	050-099, 275-299
L00167		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0643/192/R029	150-199
L00167 T		3011 LAMP-	455T1103 08806	1	33-37-11 / /	ALL
L00168		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0643/193/L031	050-099
L00168		15-0188-7 LIGHT-FWD B CARGO COMPT	455T1103 72914	1	33-37-11 0643/192/L029	150-199, 275-299
L00168 T		3011 LAMP	455T1103 08806	1	33-37-11 / /	ALL
L00169		15-0188-7 LIGHT-FWD A CARGO COMPT	455T1103 72914	1	33-37-11 0709/193/R031	050-099, 275-299
L00169		15-0188-7 LIGHT-FWD A CARGO COMPT	455T1103 72914	1	33-37-11 0709/192/R029	150-199
L00169 T		3011 LAMP	455T1103 08806	1	33-37-11 / /	ALL
L00170		15-0188-7 LIGHT-FWD A CARGO COMPT	455T1103 72914	1	33-37-11 0709/193/L031	050-099, 275-299
L00170		15-0188-7 LIGHT-FWD A CARGO COMPT	455T1103 72914	1	33-37-11 0709/192/L029	150-199
L00170 T		3011 LAMP	455T1103 08806	1	33-37-11 / /	ALL
L00172		284T1005-3 LIGHT-FWD CARGO DOOR	284T0001 81205	1	33-31-61 D0527/141/R065	ALL
L00172 T		4627 LAMP	284T1005 24455	1	33-31-61 / /	ALL
L00173		284T1005-3 LIGHT-FWD CARGO DOOR	284T0001 81205	1	33-31-61 D0569/141/R065	ALL
L00173 T		4627 LAMP	284T1005 24455	1	33-31-61 / /	ALL
L00174	1	121-563-1005-005 LIGHT-FUELING VALVE,L AUX TANK	344T0021 81590	1	28-21-13 P028-00/ /	ALL

EQUIPMENT LIST

D280T132

Section L00100

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00174	2	121-563-1006-004 LIGHT-FUELING VALVE,L AUX TANK	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00174	3	121-563-1005-001 LIGHT-FUELING VALVE,L AUX TANK	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00175	1	121-563-1005-005 LIGHT-FUELING VALVE,R AUX TANK	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00175	2	121-563-1006-004 LIGHT-FUELING VALVE,R AUX TANK	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00175	3	121-563-1005-001 LIGHT-FUELING VALVE,R AUX TANK	344T0021 81590	1	28-21-13 P028-00/ /	ALL
L00178		15-0143-17 LIGHT-TAILCONE COMPT	284T0549 72914	1	33-31-31 1680/255/R059	ALL
L00178 T		2232 LAMP	284T0549 08805	1	33-31-31 / /	ALL
L00179		15-0143-17 LIGHT-TAILCONE COMPT	284T0551 72914	1	33-31-31 1833/242/R034	ALL
L00179 T		2232 LAMP	285T0551 08805	1	33-31-31 / /	ALL
L00180		15-0143-17 LIGHT-APU COMPT	284T0559 72914	1	33-31-31 1834/219/R018	ALL
L00180 T		2232 LAMP	284T0559 08805	1	33-31-31 / /	ALL
L00181		15-0143-17 LIGHT-APU COMPT	284T0559 72914	1	33-31-31 1834/218/L017	ALL
L00181 T		2232 LAMP	284T0559 08805	1	33-31-31 / /	ALL
L00182		S417T501-2 LIGHT-LEFT ENTRY,FWD	417T5091 81205	1	33-22-11 0344/280/L072	ALL
L00182 T		2233 LAMP	01267501 08806	1	33-22-11 / /	ALL
L00183		S417T501-2 LIGHT-RIGHT ENTRY,FWD	417T5091 81205	1	33-22-11 0344/280/R072	ALL
L00183 T		2233 LAMP	01267501 08806	1	33-22-11 / /	ALL

EQUIPMENT LIST

D280T132

Section L00100

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00184		S417T502-8 LIGHT-LEFT ATTENDANT WORK,FWD	411T3126 81205	1	33-22-31 0290/280/L052	ALL
L00184 T		2233 LAMP	411T3026 08806	1	33-22-31 / /	ALL
L00185		S417T502-8 LIGHT-CENTER ATTENDANT WORK,FWD RIGHT	411T3126 81205	1	33-22-31 0318/280/R007	275-299
L00185 T		2233 LAMP	411T3026 08806	1	33-22-31 / /	275-299
L00186		S417T501-2 LIGHT-LEFT ENTRY,AFT	417T5091 81205	1	33-22-11 1532/280/L070	ALL
L00186 T		2233 LAMP	01267501 08806	1	33-22-11 / /	ALL
L00187		S417T501-2 LIGHT-RIGHT ENTRY,AFT	417T5091 81205	1	33-22-11 1537/280/R070	ALL
L00187 T		2233 LAMP	01267501 08806	1	33-22-11 / /	ALL
L00188		10-0330-4 LIGHT-LEFT ATTENDANT WORK,AFT	417T5146 72914	1	33-22-31 1536/277/L066	050-099
L00188		S417T502-8 LIGHT-LEFT ATTENDANT WORK,AFT	411T3027 81205	1	33-22-31 1521/280/L024	150-199, 275-299
L00188 T		2233 LAMP	VENDORS 08806	1	33-22-31 / /	050-099
L00188 T		2233 LAMP	411T3027 08806	1	33-22-31 / /	150-199, 275-299
L00189		10-0330-4 LIGHT-RIGHT ATTENDANT WORK,AFT	417T5146 72914	1	33-22-31 1537/277/R066	050-099
L00189		S417T502-8 LIGHT-RIGHT ATTENDANT WORK,AFT	411T3027 81205	1	33-22-31 1521/280/R024	150-199, 275-299
L00189 T		2233 LAMP	VENDORS 08806	1	33-22-31 / /	050-099
L00189 T		2233 LAMP	411T3027 08806	1	33-22-31 / /	150-199, 275-299
L00190		S417T502-8 LIGHT-CENTER ATTENDANT WORK,FWD LEFT	411T3026 81205	1	33-22-31 0316/280/L007	275-299

EQUIPMENT LIST

D280T132

Section L00100

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00190 T		2233 LAMP	411T3026 08806	1	33-22-31 / /	275-299
L00191		BV03203N-40-BV03202N-40 SOCKET-ENTRY CEILING	417T5052 17023	1	33-22-11 0325/280/L029	ALL
L00191 T		F30T12WWRS LIGHT-ENTRY CEILING	417T5052 08805	1	33-22-11 / /	ALL
L00192		S417T502-8 LIGHT-CENTER ATTENDANT WORK,MID LEFT	411T3030 81205	1	33-22-31 0824/280/L018	050-099
L00192		S417T502-8 LIGHT-CENTER ATTENDANT WORK,MID LEFT	411T3030 81205	1	33-22-31 0927/280/L010	150-199
L00192		S417T502-8 LIGHT-CENTER ATTENDANT WORK,MID LEFT	411T3030 81205	1	33-22-31 0808/280/L010	275-299
L00192 T		2233 LAMP	411T3030 08806	1	33-22-31 / /	ALL
L00193		S417T502-8 LIGHT-CENTER ATTENDANT WORK,MID RIGHT	411T3030 81205	1	33-22-31 0824/280/R018	050-099
L00193		S417T502-8 LIGHT-CENTER ATTENDANT WORK,MID RIGHT	411T3030 81205	1	33-22-31 0927/280/R010	150-199
L00193		S417T502-8 LIGHT-CENTER ATTENDANT WORK,MID RIGHT	411T3030 81205	1	33-22-31 0808/280/R010	275-299
L00193 T		2233 LAMP	411T3030 08806	1	33-22-31 / /	ALL
L00194		855308-9 LIGHT-ATTENDANT CALL,FWD L	411T3126 14889	1	23-42-11 0356/280/L038	050-099, 151-157
L00194		855308-9 LIGHT-ATTENDANT CALL,FWD L	14889	1	23-42-11 0356/280/L038	150
L00194		855308-9 LIGHT-ATTENDANT CALL,FWD L	417T5105 14889	1	23-42-11 0356/280/L038	162-199
L00194		855308-9 LIGHT-ATTENDANT CALL,FWD L	00000000 14889	1	23-42-12 0356/280/L044	275-276, 280-299
L00194		855308-9 LIGHT-ATTENDANT CALL,FWD L	14889	1	23-42-11 0356/280/L043	275-299
L00194 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0356/280/L038	050-099, 162-199

EQUIPMENT LIST

D280T132

Section L00100

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00194 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0356/280/L044	150-157, 275-299
L00194 T		387 LAMP-	417T5092 08806	1	23-42-11 0356/280/L038	050-099, 162-199
L00194 T		387 LAMP-	417T5092 08806	1	23-42-11 0356/280/L044	150-157, 275-299
L00195		855308-9 LT-ATTENDANT CALL,FWD R	411T3126 14889	1	23-42-11 0356/280/R038	050-099, 151-157
L00195		855308-9 LIGHT-ATTENDANT CALL,FWD R	14889	1	23-42-11 0356/280/R038	150
L00195		855308-9 LT-ATTENDANT CALL,FWD R	417T5105 14889	1	23-42-11 0356/280/R038	162-199
L00195		855308-9 LT-ATTENDANT CALL,FWD R	00000000 14889	1	23-42-12 0356/280/R044	275-276, 280-299
L00195		855308-9 LIGHT-ATTENDANT CALL,FWD R	14889	1	23-42-11 0356/280/R043	275-299
L00195 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0356/280/R038	050-099, 162-199
L00195 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0356/280/R028	150-157, 275-299
L00195 T		387 LAMP-	417T5092 08806	1	23-42-11 0356/280/R038	050-099, 162-199
L00195 T		387 LAMP-	417T5092 08806	1	23-42-11 0356/280/R028	150-157, 275-299
L00196		855308-9 LIGHT-ATTEND CALL MID L	14889	1	23-42-11 851/280/L 38	050-099, 150-154, 156, 162-199
L00196		855308-9 LIGHT-ATTENDANT CALL,MID L	417T5092 14889	1	23-42-11 0851/280/L038	155
L00196		855308-9 LIGHT-ATTENDANT CALL,MID L	417T3126 14889	1	23-42-11 0851/280/L038	157
L00196		855308-9 LIGHT-ATTENDANT CALL	14889	1	23-42-11 0888/280/L 38	275-276
L00196		855308-9 LIGHT-ATTENDANT CALL,MID L	417T5105 14889	1	23-42-11 0888/275/L054	275-278

EQUIPMENT LIST

D280T132

Section L00100

Page 11

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00196		855308-9 LIGHT-ATTEND CALL	14889	1	23-42-11 0888/280/L 38	277-299
L00196 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0932/280/L038	050-099
L00196 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0888/280/L035	150-157, 275-299
L00196 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0851/280/L038	162-199
L00196 T		387 LAMP	417T5092 08806	1	23-42-11 0932/280/L038	050-099
L00196 T		387 LAMP	417T5092 08806	1	23-42-11 0888/280/L035	150-157, 275-299
L00196 T		387 LAMP	417T5092 08806	1	23-42-11 0851/280/L038	162-199
L00197		855308-9 LIGHT-ATTENDANT CALL,AFT L	14889	1	23-42-11 1505/280/L032	050-099, 150-199
L00197		855308-9 LIGHT-ATTENDANT CALL,AFT L	00000000 14889	1	23-42-14 1506/280/L033	275-276, 280-299
L00197		855308-9 LIGHT-ATTENDANT CALL,AFT L	14889	1	23-42-11 1471/280/L043	275-299
L00197 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1505/280/L032	050-099, 162-199
L00197 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1472/280/L044	150-157, 275-299
L00197 T		387 LAMP-	417T5092 08806	1	23-42-11 1505/280/L032	050-099, 162-199
L00197 T		387 LAMP-	417T5092 08806	1	23-42-11 1472/280/L044	150-157, 275-299
L00198		855308-9 LIGHT-ATTENDANT CALL,AFT R	14889	1	23-42-11 1505/280/R032	050-099, 150-199
L00198		855308-9 LIGHT-ATTENDANT CALL,AFT R	14889	1	23-42-11 1471/280/R043	275-299
L00198 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1505/280/R032	050-099, 162-199

EQUIPMENT LIST

D280T132

Section L00100

Page 12

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00198 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1472/280/R044	150-157, 275-299
L00198 T		387 LAMP-	417T5092 08806	1	23-42-11 1505/280/R032	050-099, 162-199
L00198 T		387 LAMP-	417T5092 08806	1	23-42-11 1472/280/R044	150-157, 275-299

EQUIPMENT LIST

D280T132

Section L00100
Page 13 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00201		417T5072-30 LIGHT-FWD GALLEY	417T5023 17023	1	33-27-11 0284/280/R035	ALL
L00201 T		55-1239-1 LAMP-FWD GALLEY	417T5023 08805	1	33-27-11 //	ALL
L00202		417T5072-30 LIGHT-FWD GALLEY	417T5023 17023	1	33-27-11 0281/280/R035	ALL
L00202 T		55-1239-1 LAMP-FWD GALLEY	417T5023 08805	1	33-27-11 //	ALL
L00203		417T5072-19 LIGHT-AFT GALLEY	417T5025 17023	1	33-27-11 1578/280/L021	ALL
L00203 T		F30T12-WW-RS LAMP-AFT GALLEY	417T5025 08805	1	33-27-11 //	ALL
L00204		417T5072-38 LIGHT-AFT GALLEY	417T5025 17023	1	33-27-11 1578/280/R021	ALL
L00204 T		F30T12-WW-RS LAMP-AFT GALLEY	417T5025 08805	1	33-27-11 //	ALL
L00205		417T5072-19 LIGHT-AFT GALLEY	417T5025 17023	1	33-27-11 1574/280/L021	ALL
L00205 T		F30T12-WW-RS LAMP-AFT GALLEY	417T5025 08805	1	33-27-11 //	ALL
L00206		417T5072-20 LIGHT-AFT GALLEY	417T5025 17023	1	33-27-11 1574/280/R021	ALL
L00206 T		F30T12-WW-RS LAMP-AFT GALLEY	417T5025 08805	1	33-27-11 //	ALL
L00207		417T5072-17 LIGHT-AFT GALLEY	417T5025 17023	1	33-27-11 1556/280/L035	ALL
L00207 T		F20T12-WW LAMP-AFT GALLEY	417T5025 08805	1	33-27-11 //	ALL
L00208		417T5072-18 LIGHT-AFT GALLEY	417T5025 17023	1	33-27-11 1556/280/R035	ALL
L00208 T		F20T12-WW LAMP-AFT GALLEY	417T5025 08805	1	33-27-11 //	ALL
L00209		417T5072-17 LIGHT-AFT GALLEY	417T5025 17023	1	33-27-11 1556/280/L031	ALL

EQUIPMENT LIST

D280T132

Section L00200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00209 T		F20T12-WW LAMP-AFT GALLEY	417T5025 08805	1	33-27-11 / /	ALL
L00210		417T5072-18 LIGHT-AFT GALLEY	417T5025 17023	1	33-27-11 1556/280/R031	ALL
L00210 T		F20T12-WW LAMP-AFT GALLEY	417T5025 08805	1	33-27-11 / /	ALL
L00211		855308-9 LIGHT-ATTEND CALL MID R	14889	1	23-42-11 851/280/R 38	050-099, 150-154, 156, 162-199
L00211		855308-9 LIGHT-ATTENDANT CALL,MID R	417T5092 14889	1	23-42-11 0851/280/R038	155
L00211		855308-9 LIGHT-ATTENDANT CALL,MID R	417T3126 14889	1	23-42-11 0851/280/R038	157
L00211		855308-9 LIGHT-ATTENDENT CALL	14889	1	23-42-11 0888/280/R 38	275-276
L00211		855308-9 LIGHT-ATTENDANT CALL,MID R	417T5105 14889	1	23-42-11 0888/275/R054	275-278
L00211		855308-9 LIGHT-ATTEND CALL	14889	1	23-42-11 0888/280/R 38	277-299
L00211 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0932/280/R038	050-099
L00211 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0888/280/R035	150-157, 275-299
L00211 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0851/280/R038	162-199
L00211 T		387 LAMP	417T5092 08806	1	23-42-11 0932/280/R038	050-099
L00211 T		387 LAMP	417T5092 08806	1	23-42-11 0888/280/R035	150-157, 275-299
L00211 T		387 LAMP	417T5092 08806	1	23-42-11 0851/280/R038	162-199
L00213		BV03203N-40-BV03202N-40 SOCKET-FLIGHT DECK ENTRY	417T5026 17023	1	33-22-41 0284/283/L030	ALL
L00213 T		F15T12WW LIGHT-FLIGHT DECK ENTRY	417T5026 08805	1	33-22-41 / /	ALL

EQUIPMENT LIST

D280T132

Section L00200

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00215		BV5-01258-BV5-01261 SOCKET-FWD DIRECT CEILING	411T3126 17023	1	33-22-41 0334/280/0000	050-099, 150-199, 275-278
L00215		BV5-01258-BV5-01261 SOCKET-FWD DIRECT CEILING	411T3026 17023	1	33-22-41 0328/280/0000	280-299
L00215 T		5106WW LIGHT-FWD DIRECT CEILING	411T3026 08805	1	33-22-41 / /	050-099, 150-199, 275-278
L00215 T		QE42841 LIGHT-FWD DIRECT CEILING	411T3026 BFE	1	33-22-41 / /	280-299
L00216		BV03203N-40-BV03202N-40 SOCKET-FWD DIRECT CEILING	411T3126 17023	1	33-22-41 0340/280/0000	ALL
L00216 T		F15T12WW LIGHT-FWD DIRECT CEILING	411T3026 08805	1	33-22-41 / /	ALL
L00217		BV03203N-40-BV03202N-40 SOCKET-FWD DIRECT CEILING	411T3126 17023	1	33-22-41 0344/280/0000	ALL
L00217 T		F15T12WW LIGHT-FWD DIRECT CEILING	411T3026 08805	1	33-22-41 / /	ALL
L00218		BV03203N-40-BV03202N-40 SOCKET-FWD DIRECT CEILING	411T3026 17023	1	33-22-41 0331/280/0000	ALL
L00218 T		F15T12WW LIGHT-FWD DIRECT CEILING	411T3026 08805	1	33-22-41 / /	ALL
L00219		BV5-01258-BV5-01261 SOCKET-AFT DIRECT CEILING	411T3127 17023	1	33-22-42 1526/284/L008	050-099
L00219		S417T502-4 SOCKET-AFT DIRECT CEILING	411T3127 81205	1	33-22-42 1502/284/L008	150-199
L00219 T		5106WW LIGHT-AFT DIRECT CEILING	411T3127 08805	1	33-22-42 / /	050-099
L00219 T		2233 LIGHT-AFT DIRECT CEILING	411T3127 08805	1	33-22-42 / /	150-199
L00219 T		5106WW LIGHT-AFT DIRECT CEILING	417T5052 08805	1	33-27-11 / /	275-278
L00220		BV5-01258-BV5-01261 SOCKET-AFT DIRECT CEILING	411T3127 17023	1	33-22-42 1527/284/R020	050-099
L00220		S417T502-4 SOCKET-AFT DIRECT CEILING	411T3127 81205	1	33-22-42 1502/280/0000	150-199

EQUIPMENT LIST

D280T132

Section L00200

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00220	B	BV5-01258-BV5-01261 SOCKET-AFT DIRECT CEILING	417T5058 17023	1	33-22-42 0818/280/0000	275-299
L00220	T	5106WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	050-099
L00220	T	2232 LIGHT-AFT DIRECT CEILING	411T3127 08805	1	33-22-42 / /	150-199
L00220	T	5106WW LIGHT-AFT DIRECT CEILING	417T5052 08805	1	33-27-11 / /	275-299
L00220BT		5106WW LIGHT-AFT DIRECT CEILING	417T5052 08805	1	33-22-42 / /	275-299
L00221		BV03203N-40-BV03202N-40 SOCKET-AFT DIRECT CEILING	411T3027 17023	1	33-22-42 1500/284/000	050-099
L00221	B	BV03203N-40-BV03202N-40 SOCKET-AFT DIRECT CEILING	417T5058 17023	1	33-22-42 0821/280/0000	275-299
L00221	T	F15T12WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	050-099
L00221	T	F15T12WW LIGHT-AFT DIRECT CEILING	417T5052 08805	1	33-27-11 / /	275-299
L00221BT		F15T12WW LIGHT-AFT DIRECT CEILING	417T5052 08805	1	33-22-42 / /	275-299
L00222		BV03203N-40-BV03202N-40 SOCKET-AFT DIRECT CEILING	411T3027 17023	1	33-22-42 1494/284/000	050-099
L00222	B	BV03203N-40-BV03202N-40 SOCKET-AFT DIRECT CEILING	417T5058 17023	1	33-22-42 0824/280/0000	275-299
L00222	T	F15T12WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	050-099
L00222	T	F15T12WW LIGHT-AFT DIRECT CEILING	417T5052 08805	1	33-27-11 / /	275-299
L00222BT		F15T12WW LIGHT-AFT DIRECT CEILING	417T5052 08805	1	33-22-42 / /	275-299
L00223		BV5-01258-BV5-01261 SOCKET-AFT DIRECT CEILING	411T3127 17023	1	33-22-42 1455/284/L039	275-299
L00223	T	5106WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	275-299

EQUIPMENT LIST

D280T132

Section L00200

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00224		BV5-01258-BV5-01261 SOCKET-AFT DIRECT CEILING	411T3127 17023	1	33-22-42 1455/284/R039	275-299
L00224	T	5106WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	275-299
L00225		BV03203N-40-BV03202N-40 SOCKET-AFT DIRECT CEILING	411T3127 17023	1	33-22-42 1455/284/L043	275-299
L00225	T	F15T12WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	275-299
L00226		BV03203N-40-BV03202N-40 SOCKET-AFT DIRECT CEILING	411T3127 17023	1	33-22-42 1455/284/R036	275-299
L00226	T	F15T12WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	275-299
L00227		BV03203N-40-BV03202N-40 SOCKET-AFT DIRECT CEILING	411T3127 17023	1	33-22-42 1455/284/L037	275-299
L00227	T	F15T12WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	275-299
L00228		BV03203N-40-BV03202N-40 SOCKET-AFT DIRECT CEILING	411T3127 17023	1	33-22-42 1455/284/R041	275-299
L00228	T	F15T12WW LIGHT-AFT DIRECT CEILING	411T3027 08805	1	33-22-42 / /	275-299
L00230		S417T502-4 SOCKET-AFT DIRECT CEILING	411T3030 81205	1	33-22-41 0816/280/L010	050-099
L00230		S417T502-4 SOCKET-AFT DIRECT CEILING	411T3030 81205	1	33-22-42 0654+107/280/L010	150-199
L00230	T	2232 LIGHT-AFT DIRECT CEILING	411T3030 08805	1	33-22-41 / /	050-099
L00230	T	2232 LIGHT-AFT DIRECT CEILING	411T3030 08805	1	33-22-42 / /	150-199
L00231		S417T502-4 SOCKET-AFT DIRECT CEILING	411T3030 81205	1	33-22-41 0816/280/R010	050-099
L00231		S417T502-4 SOCKET-AFT DIRECT CEILING	411T3030 81205	1	33-22-42 0654+107/280/R010	150-199
L00231	T	2232 LIGHT-AFT DIRECT CEILING	411T3030 08805	1	33-22-41 / /	050-099

EQUIPMENT LIST

D280T132

Section L00200

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00231 T		2232 LIGHT-AFT DIRECT CEILING	411T3030 08805	1	33-22-42 / /	150-199
L00232		417T5153 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0411/280/L025	275-299
L00232 T		F30T12-WW LAMP	417T5003 08805	1	33-21-11 / /	275-299
L00233		417T5153 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0411/284/R025	275-299
L00233 T		F30T12-WW LAMP	417T5003 08805	1	33-21-11 / /	275-299
L00234		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0499/280/L025	ALL
L00234 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	ALL
L00234 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	ALL
L00235		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0499/280/R025	ALL
L00235 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	ALL
L00235 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	ALL
L00236		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0411/284/L050	275-299
L00236 T		F30T12-WW LAMP	417T5003 08805	1	33-21-11 / /	275-299
L00237		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0411/284/R050	275-299
L00237 T		F30T12-WW LAMP	417T5003 08805	1	33-21-11 / /	275-299
L00238		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0544/284/L050	050-099
L00238		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0499/284/L050	150-199, 275-299

EQUIPMENT LIST

D280T132

Section L00200

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00238 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 //	ALL
L00238 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 //	ALL
L00239		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0499/284/R050	ALL
L00239 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 //	ALL
L00239 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 //	ALL
L00240		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0587/280/L025	050-099, 150-199
L00240		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0587/280/L025	275-299
L00240 T		F40WW LAMP	417T5003 08805	1	33-21-11 //	275-299
L00240 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 //	050-099, 150-199
L00240 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 //	050-099, 150-199
L00241		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0675/280/L025	050-099
L00241		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-13 0680/280/L025	150-199
L00241		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-13 0719/280/L025	275-299
L00241 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 //	050-099
L00241 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 //	150-199, 275-278
L00241 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 //	050-099
L00241 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 //	150-199, 275-278

EQUIPMENT LIST

D280T132

Section L00200

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00242		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0587/280/R025	050-099, 150-199
L00242		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0587/280/R025	275-299
L00242 T		F40WW LAMP	417T5003 08805	1	33-21-11 / /	275-299
L00242 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	050-099, 150-199
L00242 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	050-099, 150-199
L00243		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-11 0675/280/R025	050-099
L00243		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-13 0654+109/280/R025	150-199
L00243		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,FWD	411T3501 81205	1	33-21-13 0719/280/R025	275-299
L00243 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	050-099
L00243 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	150-199, 275-278
L00243 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	050-099
L00243 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	150-199, 275-278
L00244		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0631/284/L050	050-099
L00244		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0587/284/L050	150-199
L00244		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0587/284/L050	275-299
L00244 T		F40WW LAMP	417T5003 08805	1	33-21-11 / /	275-299
L00244 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section L00200

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00244 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	050-099, 150-199
L00245		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0719/284/L050	050-099
L00245		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-13 0680/284/L050	150-199
L00245		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-13 0763/284/L050	275-278
L00245 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	050-099
L00245 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	150-199, 275-278
L00245 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	050-099
L00245 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	150-199, 275-278
L00246		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0587/284/R050	050-099, 150-199
L00246		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0587/284/R050	275-299
L00246 T		F40WW LAMP	417T5003 08805	1	33-21-11 / /	275-299
L00246 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	050-099, 150-199
L00246 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	050-099, 150-199
L00247		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-11 0675/284/R050	050-099
L00247		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-13 0654+109/284/R050	150-199
L00247		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,FWD	417T5038 17023	1	33-21-13 0700/284/R050	275-278
L00247 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	050-099

EQUIPMENT LIST

D280T132

Section L00200

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00247 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	150-199, 275-278
L00247 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	050-099
L00247 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	150-199, 275-278
L00250		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0763/284/L050	050-099
L00250		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 1042/284/L050	150-199
L00250		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0807/284/L050	275-299
L00250 T		55-1239-1 LIGHT-INDIRECT CEILING,MID	417T5003 08805	1	33-21-13 / /	150-199, 275-299
L00250 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	050-099
L00250 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	050-099
L00251		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0763/284/R050	050-099
L00251		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 1042/284/R050	150-199
L00251		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0785/284/R050	275-299
L00251 T		55-1239-1 LIGHT-INDIRECT CEILING,MID	417T5003 08805	1	33-21-13 / /	150-199, 275-299
L00251 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	050-099
L00251 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	050-099
L00252		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5131 17023	1	33-21-13 0847/284/L050	050-099
L00252		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5131 17023	1	33-21-13 0892/284/L050	150-199

EQUIPMENT LIST

D280T132

Section L00200

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00252		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5131 17023	1	33-21-13 0851/284/L050	275-299
L00252 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	ALL
L00252 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	ALL
L00253		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5131 17023	1	33-21-13 0847/284/R050	050-099
L00253		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5131 17023	1	33-21-13 0892/284/R050	150-199
L00253		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5131 17023	1	33-21-13 0848/284/R050	275-299
L00253 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	ALL
L00253 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	ALL
L00254		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0976/284/L050	050-099
L00254		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0807/284/L050	150-199
L00254		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0932/284/L050	275-299
L00254 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	ALL
L00254 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	ALL
L00255		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0976/284/R050	050-099
L00255		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0764/284/R050	150-199
L00255		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0932/284/R050	275-299
L00255 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	ALL

EQUIPMENT LIST

D280T132

Section L00200

Page 11

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00255 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	ALL
L00256		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1064/284/L050	050-099
L00256		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 0976/284/L050	150-199
L00256		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1020/284/L050	275-299
L00256 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00256 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	050-099, 150-199
L00256 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	050-099, 150-199
L00257		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1064/284/R050	050-099
L00257		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 0932/284/R050	150-199
L00257		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1020/284/R050	275-299
L00257 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00257 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	050-099, 150-199
L00257 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	050-099, 150-199
L00258		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1152/284/L050	050-099
L00258		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1108/284/L050	150-199, 275-299
L00258 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	ALL
L00258 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	ALL

EQUIPMENT LIST

D280T132

Section L00200

Page 12

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00259		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1152/284/R050	050-099
L00259		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1108/284/R050	150-199, 275-299
L00259 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	ALL
L00259 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	ALL
L00260		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1240/284/L050	050-099
L00260		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1240/284/L050	150-199
L00260		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1252/284/L050	275-299
L00260 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	150-199, 275-299
L00260 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	050-099
L00260 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	050-099
L00261		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1240/284/R050	050-099
L00261		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1240/284/R050	150-199
L00261		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1252/284/R050	275-299
L00261 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	150-199, 275-299
L00261 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	050-099
L00261 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	050-099
L00262		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0763/280/L025	050-099

EQUIPMENT LIST

D280T132

Section L00200

Page 13

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00262		S417T506-3 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 1042/280/L025	150-199
L00262		S417T506-3 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0785/280/L025	275-299
L00262 T		55-1239-1 LIGHT-INDIRECT CEILING,MID	417T5003 08805	1	33-21-13 / /	150-199, 275-299
L00262 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	050-099
L00262 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	050-099
L00263		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0763/280/R025	050-099
L00263		S417T506-3 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 1042/280/R025	150-199
L00263		S417T506-3 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0785/280/R025	275-299
L00263 T		55-1239-1 LIGHT-INDIRECT CEILING,MID	417T5003 08805	1	33-21-13 / /	150-199, 275-299
L00263 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	050-099
L00263 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	050-099
L00264		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0847/280/L025	050-099
L00264		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0892/280/L025	150-199
L00264		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0848/280/L025	275-299
L00264 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	ALL
L00264 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	ALL
L00265		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0847/280/R025	050-099

EQUIPMENT LIST

D280T132

Section L00200

Page 14

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00265		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0892/280/R025	150-199
L00265		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0848/280/R025	275-299
L00265 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	ALL
L00265 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	ALL
L00266		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0976/280/L025	050-099
L00266		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0807/280/L025	150-199
L00266		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0932/280/L025	275-299
L00266 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	ALL
L00266 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	ALL
L00267		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0976/280/R025	050-099
L00267		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0807/280/R025	150-199
L00267		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0932/280/R025	275-299
L00267 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-13 / /	ALL
L00267 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-13 / /	ALL
L00268		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1064/284/L025	050-099
L00268		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 0976/284/L025	150-199
L00268		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1020/284/L025	275-299

EQUIPMENT LIST

D280T132

Section L00200

Page 15

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00268 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00268 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	050-099, 150-199
L00268 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	050-099, 150-199
L00269		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1064/284/R025	050-099
L00269		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 0976/284/R025	150-199
L00269		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1020/284/R025	275-299
L00269 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00269 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	050-099, 150-199
L00269 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	050-099, 150-199
L00270		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1152/284/L025	050-099
L00270		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1108/284/L025	150-199, 275-299
L00270 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	ALL
L00270 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	ALL
L00271		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1152/284/R025	050-099
L00271		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1108/284/R025	150-199, 275-299
L00271 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	ALL
L00271 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	ALL

EQUIPMENT LIST

D280T132

Section L00200

Page 16

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00272		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1240/284/L025	050-099
L00272		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1240/284/L025	150-199
L00272		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1284/284/L025	275-299
L00272 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	150-199, 275-299
L00272 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	050-099
L00272 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	050-099
L00273		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1240/284/R025	050-099
L00273		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1240/284/R025	150-199
L00273		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1221/284/R025	275-299
L00273 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	150-199, 275-299
L00273 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	050-099
L00273 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	050-099
L00274		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1328/284/L050	ALL
L00274 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	ALL
L00274 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	ALL
L00275		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1328/284/R050	ALL
L00275 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	ALL

EQUIPMENT LIST

D280T132

Section L00200

Page 17

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00275 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	ALL
L00276		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1328/284/L025	ALL
L00276 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	ALL
L00276 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	ALL
L00277		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1328/284/R025	ALL
L00277 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	ALL
L00277 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	ALL
L00278		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1405/284/L050	ALL
L00278 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	050-099, 150-199
L00278 T		F30T12-WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00279		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,AFT	417T5038 17023	1	33-21-14 1405/284/R050	ALL
L00279 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	050-099, 150-199
L00279 T		F30T12-WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00280		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1405/284/L025	050-099, 150-199
L00280		417T5153 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1405/284/L025	275-299
L00280 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	050-099, 150-199
L00280 T		F30T12-WW LAMP	417T5003 08805	1	33-21-14 / /	275-299

EQUIPMENT LIST

D280T132

Section L00200

Page 18

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00281		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1405/284/R025	050-099, 150-199
L00281		417T5153 ASSEMBLY-INDIRECT CEILING LTS,AFT	411T3501 81205	1	33-21-14 1405/284/R025	275-299
L00281 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	050-099, 150-199
L00281 T		F30T12-WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00282		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0910/284/L050	050-099
L00282 T		55-1239-1 LIGHT-INDIRECT CEILING,MID	417T5003 08805	1	33-21-13 / /	050-099
L00283		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS,MID	417T5038 17023	1	33-21-13 0910/284/R050	050-099
L00283 T		55-1239-1 LIGHT-INDIRECT CEILING,MID	417T5003 08805	1	33-21-13 / /	050-099
L00284		S417T506-3 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0910/280/L025	050-099
L00284 T		55-1239-1 LIGHT-INDIRECT CEILING,MID	417T5003 08805	1	33-21-13 / /	050-099
L00285		S417T506-3 ASSEMBLY-INDIRECT CEILING LTS,MID	411T3501 81205	1	33-21-13 0910/280/R025	050-099
L00285 T		55-1239-1 LIGHT-INDIRECT CEILING,MID	417T5003 08805	1	33-21-13 / /	050-099
L00286		10-60091-101 LIGHT ASSY-EMER EXIT,FLT DECK	232T4105 81205	1	33-51-11 0240/270/L032	ALL
L00286 T		1315 LAMPS	232T4105 08805	8	33-51-11 / /	ALL
L00287		S417T504-22 LIGHT-EXIT/THRESHOLD SIGN	417T5106 81205	1	33-51-14 0289/270/R075	050-099, 150-199, 280-299
L00287		S417T504-64 LIGHT-EXIT/THRESHOLD SIGN	417T5106 81205	1	33-51-14 0289/270/R075	275-278
L00287 T		7335 LAMP	417T5106 S 5006	8	33-51-14 / /	ALL

EQUIPMENT LIST

D280T132

Section L00200

Page 19

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00287 U	1	8628 LAMP	417T5106 S 5006	3	33-51-14 / /	ALL
L00287 U	2	OL-628 LAMP	417T5106 S 3774	3	33-51-14 / /	ALL
L00288		S417T500-3 LIGHT-DOOR	417T5104 81205	1	33-51-12 0296/280/R070	ALL
L00288 T		1317 LAMP	417T5037 08805	1	33-51-12 / /	ALL
L00289		S417T500-2 LIGHT-LWRD CEILING	411T3026 81205	1	33-51-12 0334/280/R009	050-099
L00289		S417T500-2 LIGHT-LWRD CEILING	411T3026 81205	1	33-51-12 0329/280/R008	150-199, 275-299
L00289 T		1317 LAMPS	411T3026 08805	1	33-51-12 / /	ALL
L00290		S417T500-2 LIGHT-AISLE	411T3026 81205	1	33-51-12 0357/280/R040	ALL
L00290 T		1317 LAMP	411T3026 08805	1	33-51-12 / /	ALL
L00291		S417T504-94 LT-EXIT SIGN	417T5105 81205	1	33-51-12 0455/280/R038	050-099
L00291		S417T504-114 LT-EXIT SIGN	417T5105 81205	1	33-51-12 0455/280/R038	150-199
L00291		S417T504-72 LT-EXIT SIGN	417T5105 81205	1	33-51-12 0373/280/R038	275-299
L00291 T		7335 LAMP	417T5106 S 5006	8	33-51-12 / /	ALL
L00292		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0445/283/R040	050-099, 150-199
L00292		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0455/283/R040	275-299
L00292 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL
L00293		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0543/283/R040	ALL

EQUIPMENT LIST

D280T132

Section L00200

Page 20

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00293 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL
L00294		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0631/283/R040	050-099, 150-199, 275-278
L00294 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	050-099, 150-199, 275-278
L00295		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0719/283/R040	050-099
L00296		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0808/283/R040	050-099
L00296		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0763/283/R040	150-199
L00296		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0807/283/R040	275-299
L00296 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL
L00297		S417T504-26 LIGHT-OVER WING HATCH,EXIT SIGN	417T5106 81205	1	33-51-14 0872/260/R085	050-099, 150-199, 280-299
L00297		S417T504-67 LIGHT-OVER WING HATCH,EXIT SIGN	417T5106 81205	1	33-51-14 0872/260/R085	275-278
L00297 T		7335 LAMP	417T5106 S 5006	8	33-51-14 / /	ALL
L00298	9	S417T504-28 LIGHT-EXIT SIGN (SB 33-0042)	417T5105 81205	1	33-51-12 0861/280/R040	275-276
L00298		S417T504-164 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0888/280/R038	050-099
L00298		S417T504-71 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0932/280/R038	150-154, 156, 162- 199
L00298		S417T504-71 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0851/280/R038	155, 157
L00298		S417T504-72 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0861/280/R040	275-278
L00298		S417T504-72 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0866/280/R040	280-299

EQUIPMENT LIST

D280T132

Section L00200

Page 21

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00298 T		7335 LAMP	417T5105 S 5006	12	33-51-12 / /	ALL
L00299		S417T504-71 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0354/280/R035	050-099
L00299		S417T504-113 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0354/280/R035	150-199
L00299 T		7335 LAMP	417T5105 S 5006	12	33-51-12 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section L00200
Page 22 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00300		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0932/283/R040	050-099
L00300		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0851/283/R040	150-199
L00300 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	150-199
L00301		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 1020/283/R040	050-099
L00301		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0932/283/R040	150-199
L00301		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 0976/283/R040	275-299
L00301 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL
L00302		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 1108/283/R040	050-099
L00302		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 1064/283/R040	150-199, 275-299
L00302 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL
L00303		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 1196/283/R040	050-099
L00303		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 1152/283/R040	150-199, 275-299
L00303 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL
L00304		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 1284/283/R040	ALL
L00304 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL
L00305		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-12 1372/283/R040	ALL
L00305 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL

EQUIPMENT LIST

D280T132

Section L00300

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00306		S417T504-94 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 1439/280/R038	050-099
L00306		S417T504-70 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 1439/280/R038	150-199
L00306		S417T504-72 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 1443/280/R038	275-299
L00306 T		7335 LAMP	417T5105 S 5006	8	33-51-12 / /	ALL
L00307		S417T500-2 LIGHT-AISLE	411T3027 81205	1	33-51-12 1458/280/R040	050-099, 150-199
L00307		S417T500-2 LIGHT-AISLE	411T3027 81205	1	33-51-12 1471/280/R040	275-299
L00307 T		1317 LAMP	411T3027 08805	1	33-51-12 / /	ALL
L00308		S417T504-22 LIGHT-EXIT/THRESHOLD SIGN	417T5106 81205	1	33-51-14 1538/270/R075	050-099, 150-199, 280-299
L00308		S417T504-64 LIGHT-EXIT/THRESHOLD SIGN	417T5106 81205	1	33-51-14 1538/270/R075	275-278
L00308 T		7335 LAMP	417T5106 S 5006	8	33-51-14 / /	ALL
L00308 U	1	8628 LAMP	417T5106 S 5006	3	33-51-14 / /	ALL
L00308 U	2	OL-628 LAMP	417T5106 S 3774	3	33-51-14 / /	ALL
L00309		S417T500-3 LIGHT-DOOR	417T5104 81205	1	33-51-12 1485/280/R075	ALL
L00309 T		1317 LAMP	417T5104 08805	1	33-51-12 / /	ALL
L00310		S417T500-2 LIGHT-LWRD CEILING	411T3027 81205	1	33-51-12 1522/280/R018	050-099
L00310		S417T500-2 LIGHT-LWRD CEILING	411T3027 81205	1	33-51-12 1496/280/R025	150-199
L00310		S417T500-2 LIGHT-LWRD CEILING	411T3027 81205	1	33-51-12 1522/280/R019	275-299

EQUIPMENT LIST

D280T132

Section L00300

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00310 T		1317 LAMPS	411T3027 08805	1	33-51-12 //	ALL
L00311		S417T504-72 LIGHT-EXIT SIGN/AFT GALLEY	417T5106 81205	1	33-51-12 1539/280/R053	050-099
L00311		S417T504-113 LIGHT-EXIT SIGN/AFT GALLEY	417T5105 81205	1	33-51-12 1485/270/0000	150-199
L00311		S417T504-99 LIGHT-EXIT SIGN/AFT GALLEY	417T5106 81205	1	33-51-12 1543/270/R054	275-278
L00311		S417T504-95 LIGHT-EXIT SIGN/AFT GALLEY	417T5106 81205	1	33-51-12 1543/270/R054	280-299
L00311 T		7335 LAMP	417T5105 S 5006	8	33-51-12 //	ALL
L00312		S417T504-22 LIGHT-EXIT/THRESHOLD SIGN	417T5106 81205	1	33-51-14 0289/270/L075	050-099, 150-199, 280-299
L00312		S417T504-64 LIGHT-EXIT/THRESHOLD SIGN	417T5106 81205	1	33-51-14 0289/270/L075	275-278
L00312 T		7335 LAMP	417T5106 S 5006	8	33-51-14 //	ALL
L00312 U	1	8628 LAMP	417T5106 S 5006	3	33-51-14 //	ALL
L00312 U	2	OL-628 LAMP	417T5106 S 3774	3	33-51-14 //	ALL
L00313		S417T500-3 LIGHT-DOOR	417T5104 81205	1	33-51-13 0296/280/L070	ALL
L00313 T		1317 LAMP	417T5104 08805	1	33-51-13 //	ALL
L00314		S417T500-2 LT-AISLE	411T3026 81205	1	33-51-13 0362/280/L040	ALL
L00314 T		1317 LAMP	411T3026 08805	1	33-51-13 //	ALL
L00315		S417T504-94 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0455/280/L038	050-099
L00315		S417T504-114 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0455/280/L038	150-199

EQUIPMENT LIST

D280T132

Section L00300

Page 3

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00315		S417T504-72 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0373/280/L038	275-299
L00315 T		7335 LAMP	411T5105 S 5006	8	33-51-13 / /	ALL
L00316		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0445/284/L040	050-099, 150-199
L00316		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0455/284/L040	275-299
L00316 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00317		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0543/283/L040	ALL
L00317 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00318		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0631/283/L040	050-099, 150-199, 275-278
L00318 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	050-099, 150-199, 275-278
L00319		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0719/283/L040	050-099
L00320		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0808/283/L040	050-099
L00320		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0763/283/L040	150-199
L00320		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0807/283/L040	275-299
L00320 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00321		S417T500-2 LIGHT-LWRD CEILING	417T3055 81205	1	33-51-12 0863/280/R002	050-099
L00321		S417T500-2 LIGHT-LWRD CEILING	417T3055 81205	1	33-51-12 0935/280/R020	150-154, 156, 162- 199
L00321		S417T500-2 LIGHT-LWRD CEILING	417T3055 81205	1	33-51-12 0877/280/R020	155, 157

EQUIPMENT LIST

D280T132

Section L00300

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00321		S417T500-2 LIGHT-LWRD CEILING	411T3030 81205	1	33-51-12 0870/280/0000	275-278
L00321		S417T500-2 LIGHT-LWRD CEILING	411T3030 81205	1	33-51-12 0875/280/0000	280-299
L00321 T		1317 LAMPS	411T3030 08805	1	33-51-12 / /	ALL
L00322		S417T504-26 LIGHT-OVER WING HATCH,EXIT SIGN	417T5106 81205	1	33-51-14 0872/260/L085	050-099, 150-199, 280-299
L00322		S417T504-67 LIGHT-OVER WING HATCH,EXIT SIGN	417T5106 81205	1	33-51-14 0872/260/L085	275-278
L00322 T		7335 LAMP	417T5106 S 5006	8	33-51-14 / /	ALL
L00323	9	S417T504-28 LIGHT-EXIT SIGN (SB 33-0042)	417T5105 81205	1	33-51-13 0861/280/L040	275-276
L00323		S417T504-164 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0888/280/L038	050-099
L00323		S417T504-71 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0932/280/L038	150-154, 156, 162- 199
L00323		S417T504-71 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0851/280/L038	155, 157
L00323		S417T504-72 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0861/280/L040	275-278
L00323		S417T504-72 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0866/280/L038	280-299
L00323 T		7335 LAMP	417T5105 S 5006	12	33-51-13 / /	ALL
L00324		S417T504-71 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0354/280/L035	050-099
L00324		S417T504-113 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-14 0354/280/L035	150-157
L00324		S417T504-113 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0354/280/L035	162-199
L00324 T		7335 LAMP	417T5105 S 5006	12	33-51-13 / /	050-099

EQUIPMENT LIST

D280T132

Section L00300

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00324	T	7335 LAMP	417T5105 S 5006	12	33-51-14 / /	150-199
L00325		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0932/283/L040	050-099
L00325		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0851/283/L040	150-199
L00325	T	1317 LAMP	411T3501 08805	1	33-51-13 / /	150-199
L00326		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 1020/283/L040	050-099
L00326		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0932/283/L040	150-199
L00326		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 0976/283/L040	275-299
L00326	T	1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00327		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 1108/283/L040	050-099
L00327		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 1064/283/L040	150-199, 275-299
L00327	T	1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00328		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 1196/283/L040	050-099
L00328		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 1152/283/L040	150-199, 275-299
L00328	T	1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00329		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 1284/283/L040	ALL
L00329	T	1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00330		S417T500-2 LIGHT-AISLE	411T3501 81205	1	33-51-13 1372/283/L040	ALL

EQUIPMENT LIST

D280T132

Section L00300

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00330 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00331		S417T504-94 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 1439/280/L038	050-099
L00331		S417T504-70 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 1439/280/L038	150-199
L00331		S417T504-72 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 1443/280/L038	275-299
L00331 T		7335 LAMP	417T5105 S 5006	8	33-51-13 / /	ALL
L00332		S417T500-2 LIGHT-AISLE	411T3127 81205	1	33-51-13 1459/280/L040	050-099, 150-199
L00332		S417T500-2 LIGHT-AISLE	411T3027 81205	1	33-51-13 1469/280/L044	275-299
L00332 T		1317 LAMP	411T3027 08805	1	33-51-13 / /	ALL
L00333		S417T504-22 LIGHT-EXIT/THRESHOLD SIGN	417T5106 81205	1	33-51-14 1538/270/L075	050-099, 150-199, 280-299
L00333		S417T504-64 LIGHT-EXIT/THRESHOLD SIGN	417T5106 81205	1	33-51-14 1538/270/L075	275-278
L00333 T		7335 LAMP	417T5106 S 5006	8	33-51-14 / /	ALL
L00333 U	1	8628 LAMP	417T5106 S 5006	3	33-51-14 / /	ALL
L00333 U	2	OL-628 LAMP	417T5106 S 3774	3	33-51-14 / /	ALL
L00334		S417T500-3 LIGHT-DOOR	417T5104 81205	1	33-51-13 1485/280/L075	ALL
L00334 T		1317 LAMP	417T5104 08805	1	33-51-13 / /	ALL
L00335		S417T504-72 LIGHT-EXIT SIGN	417T5106 81205	1	33-51-13 1539/280/L053	050-099
L00335		S417T504-99 LIGHT-EXIT SIGN	417T5106 81205	1	33-51-13 1543/270/L054	275-278

EQUIPMENT LIST

D280T132

Section L00300

Page 7

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00335		S417T504-95 LIGHT-EXIT SIGN	417T5106 81205	1	33-51-13 1543/270/L054	280-299
L00335 T		7335 LAMP	417T5105 S 5006	8	33-51-13 / /	050-099, 275-299
L00338		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0391/266/L080	275-299
L00338 T		5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-33 / /	275-299
L00339		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0431/266/L080	151-152, 275-299
L00339 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	151-152, 275-299
L00340		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0391/266/R080	275-299
L00340 T		5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-33 / /	275-299
L00341		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0431/266/R080	050-099
L00341		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0431/266/R080	151-152, 162-199, 275-299
L00341 T		5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-33 / /	050-099
L00341 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	151-152, 162-199, 275-299
L00342		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0479/266/L080	150-199, 275-278
L00342		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0462/266/L081	280-299
L00342 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	150-199, 275-299
L00343		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0519/266/L080	ALL
L00343 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	ALL

EQUIPMENT LIST

D280T132

Section L00300

Page 8

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00344		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0490/266/R081	050-099, 150-199, 275-278
L00344		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0493/266/R081	280-299
L00344 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	ALL
L00345		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0519/266/R080	ALL
L00345 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	ALL
L00346		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0565/266/L080	050-099
L00346		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0567/266/L080	150-199, 275-278
L00346		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0555/266/L081	280-299
L00346 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	ALL
L00347		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0607/266/L080	ALL
L00347 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	ALL
L00348		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0565/266/R080	050-099, 150-199, 275-278
L00348		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0581/266/R081	280-299
L00348 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	ALL
L00349		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0607/266/R080	ALL
L00349 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	ALL
L00350		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0655/266/L080	050-099, 150-199, 275-278

EQUIPMENT LIST

D280T132

Section L00300

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00350	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	050-099, 150-199, 275-278
L00351		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0695/266/L080	ALL
L00351	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	ALL
L00352		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0655/266/R080	050-099, 150-199, 275-278
L00352	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	050-099, 150-199, 275-278
L00353		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0695/266/R080	ALL
L00353	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	ALL
L00354		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0743/266/L080	ALL
L00354	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	ALL
L00355		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0743/266/R080	ALL
L00355	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	ALL
L00356		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0785/266/L080	ALL
L00356	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	ALL
L00357		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0785/266/R080	ALL
L00357	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-32 / /	050-099, 275-299
L00357	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	150-199
L00358		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5001 17023	1	33-21-33 0827/266/L080	150-199

EQUIPMENT LIST

D280T132

Section L00300

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00358	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	150-199
L00359		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5001 17023	1	33-21-33 0827/266/R080	150-199
L00359	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-33 / /	150-199
L00360		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 0912/266/L080	050-099
L00360		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 0912/266/L080	150-199, 275-299
L00360	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	050-099
L00360	T	5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	150-199, 275-299
L00361		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 0912/266/R080	050-099
L00361		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 0912/266/R080	150-199, 275-299
L00361	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	050-099
L00361	T	5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-35 / /	150-199, 275-299
L00362		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 0952/266/L080	050-099, 275-299
L00362	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	050-099, 275-299
L00363		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 0952/266/R080	050-099, 275-299
L00363	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	050-099, 275-299
L00364		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1000/266/L080	050-099, 275-299
L00364		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1000/266/L080	150-199

EQUIPMENT LIST

D280T132

Section L00300

Page 11

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00364	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	050-099, 275-299
L00364	T	5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-35 / /	150-199
L00365		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1000/266/R080	050-099
L00365		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1000/266/R080	150-199
L00365		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1000/266/R080	275-299
L00365	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	050-099
L00365	T	5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-35 / /	150-199
L00365	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	275-299
L00366		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1040/266/L080	150-199, 275-299
L00366	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	150-199, 275-299
L00367		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1040/266/R080	150-199, 275-299
L00367	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	150-199, 275-299
L00368		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1088/266/L080	050-099
L00368		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1088/266/L080	150-199, 275-299
L00368	T	5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	050-099
L00368	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	150-199, 275-299
L00369		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1088/266/R080	050-099

EQUIPMENT LIST

D280T132

Section L00300

Page 12

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00369		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1088/266/R080	150-199, 275-299
L00369 T		5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	050-099
L00369 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	150-199, 275-299
L00370		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1128/266/L080	050-099
L00370		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1128/266/L080	150-199, 275-299
L00370 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	050-099
L00370 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	150-199, 275-299
L00371		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1128/266/R080	ALL
L00371 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	ALL
L00372		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1176/266/L080	ALL
L00372 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	ALL
L00373		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1176/266/R080	ALL
L00373 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	ALL
L00374		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1216/266/L080	ALL
L00374 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	ALL
L00375		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1216/266/R080	ALL
L00375 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	ALL

EQUIPMENT LIST

D280T132

Section L00300

Page 13

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00376		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1262/266/L080	ALL
L00376 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	ALL
L00377		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1264/266/R080	ALL
L00377 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	ALL
L00378		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1304/266/L080	ALL
L00378 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	ALL
L00379		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1304/266/R080	ALL
L00379 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	ALL
L00380		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1352/266/L080	ALL
L00380 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	ALL
L00381		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1352/266/R080	ALL
L00381 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	ALL
L00382		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1392/266/L080	ALL
L00382 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	ALL
L00383		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1392/266/R080	ALL
L00383 T		55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-35 / /	ALL
L00384		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 0871/266/L080	ALL

EQUIPMENT LIST

D280T132

Section L00300

Page 14

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00384	T	5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	ALL
L00385		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 0871/266/R080	ALL
L00385	T	5106CW LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	ALL
L00386		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1427/266/L080	050-099
L00386		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1438/266/L080	150-199
L00386		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1427/266/L080	275-299
L00386	T	55-1239-1 LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	050-099
L00386	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	150-199
L00386	T	5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	275-299
L00387		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1454/266/R080	050-099
L00387		BV03203N-40-BV03202N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1438/266/R080	150-199
L00387		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1427/266/R080	275-299
L00387	T	55-1239-1 LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	050-099
L00387	T	55-1239-1 LIGHT-SIDEWALL	417T5001 72914	1	33-21-34 / /	150-199
L00387	T	5106WW LIGHT-SIDEWALL	417T5001 08805	1	33-21-34 / /	275-299
L00388		S283T008-83 LIGHT-LEFT SLIDE GRD ILLUM,FWD DOOR	284T0230 81205	1	33-51-21 0357/262/L090	ALL
L00388	T	767 LAMP	284T0230 08805	1	33-51-21 / /	ALL

EQUIPMENT LIST

D280T132

Section L00300

Page 15

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00389		S283T008-7 LIGHT-FWD OVERWING EGRESS	284T0230 81205	1	33-51-21 0922/211/L098	050-099
L00389		S283T008-53 LIGHT-FWD OVERWING EGRESS	284T0230 81205	1	33-51-21 0894/211/L098	150-199, 275-299
L00389 T		1317 LAMPS	284T0230 08805	2	33-51-21 / /	ALL
L00390		S283T008-13 LIGHT-AFT OVERWING EGRESS	284T0230 81205	1	33-51-21 1098/212/R096	ALL
L00390 T		1317 LAMPS	284T0230 08805	2	33-51-21 / /	ALL
L00391		S283T008-44 LIGHT-RIGHT SLIDE GRD ILLUM,WING	284T0230 81205	1	33-51-21 1230/180/R093	050-099
L00391		S283T008-44 LIGHT-RIGHT SLIDE GRD ILLUM,WING	284T0230 81205	1	33-51-21 1197+33/180/R093	150-199, 275-299
L00391 T		767 LAMP	284T0230 08805	1	33-51-21 / /	ALL
L00392		S283T008-82 LIGHT-RIGHT SLIDE GRD ILLUM,AFT DOOR	284T0230 81205	1	33-51-21 1568/260/R085	ALL
L00392 T		767 LAMP	284T0230 08805	1	33-51-21 / /	ALL
L00393		S283T008-84 LIGHT-RIGHT SLIDE GRD ILLUM,FWD DOOR	284T0230 81205	1	33-51-21 0357/262/R090	ALL
L00393 T		767 LAMP	284T0230 08805	1	33-51-21 / /	ALL
L00394		S283T008-7 LIGHT-FWD OVERWING EGRESS	284T0230 81205	1	33-51-21 0922/211/R098	050-099
L00394		S283T008-53 LIGHT-FWD OVERWING EGRESS	284T0230 81205	1	33-51-21 0894/211/R098	150-199, 275-299
L00394 T		1317 LAMPS	284T0230 08805	2	33-51-21 / /	ALL
L00395		S283T008-13 LIGHT-AFT OVERWING EGRESS	284T0230 81205	1	33-51-21 1098/211/L098	ALL
L00395 T		1317 LAMPS	284T0230 08805	2	33-51-21 / /	ALL

EQUIPMENT LIST

D280T132

Section L00300

Page 16

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00396		S283T008-45 LIGHT-LEFT SLIDE GRD ILLUM,WING	284T0230 81205	1	33-51-21 1230/180/L093	050-099
L00396		S283T008-45 LIGHT-LEFT SLIDE GRD ILLUM,WING	284T0230 81205	1	33-51-21 1197+33/180/L093	150-199, 275-299
L00396 T		767 LAMP	284T0230 08805	1	33-51-21 / /	ALL
L00397		S283T008-81 LIGHT-LEFT SLIDE GRD ILLUM,AFT DOOR	284T0230 81205	1	33-51-21 1568/260/L085	ALL
L00397 T		767 LAMP	284T0230 08805	1	33-51-21 / /	ALL
L00399		S417T508-83 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0455/280/R040	050-099, 150-199
L00399		S417T508-22 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0389/280/R040	275-278
L00399		S417T508-26 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0389/280/R040	280-299
L00399 T		MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5101 96906	8	33-26-21 / /	ALL

EQUIPMENT LIST

D280T132

Section L00300
Page 17 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00401		S417T508-84 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0745/280/0000	050-099
L00401		S417T508-84 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0654+38/280/0000	150-199
L00401		S417T508-25 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0779/280/0000	275-278
L00401		S417T508-119 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0779/280/0000	280-299
L00401 T		MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5101 96906	8	33-26-21 / /	ALL
L00402		S417T508-112 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1075/280/R040	050-099
L00402		60B50040-112 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0986/280/R040	150-199
L00402		S417T508-22 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0892/280/R040	275-278
L00402		S417T508-83 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0888/280/R040	280-299
L00402 T		MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5101 96906	8	33-26-21 / /	ALL
L00403		S417T508-45 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1500/280/0000	050-099
L00403		S417T508-45 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1473/280/0000	150-199
L00403		S417T508-22 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1438/280/R036	275-278
L00403		S417T508-118 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1438/280/R036	280-299
L00403 T		MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5101 96906	8	33-26-21 / /	ALL
L00405		S417T503-7 LIGHT-PASSENGER SIGN	417T3056 81205	51	33-24-12 MULTI/ /	050-099
L00405		S417T503-12 LIGHT-PASSENGER SIGN	417T3056 81205	47	33-24-12 MULTI/ /	150-199

EQUIPMENT LIST

D280T132

Section L00400

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00405		S417T503-7 LIGHT-PASSENGER SIGN	417T3056 81205	63	33-24-12 MULTI/ /	275-299
L00405 T		MS25237-387 LAMP-PASSENGER SIGN LIGHT	10-01004 96906	6	33-24-12 / /	ALL
L00406		855308-9 LIGHT-ATTENDANT CALL, MID L	14889	1	23-42-11 816/280/L0	050-099
L00406		855308-9 LIGHT-ATTENDANT CALL, MID CTR	14889	1	23-42-11 935/280/0000	150-199
L00406		855308-9 LIGHT-ATTENDANT CALL,MID CTR	00000000 14889	1	23-42-13 0833/280/0000	275-276
L00406		855308-9 LIGHT-ATTENDANT CALL,MID CTR	14889	1	23-42-11 0833/280/0000	275-299
L00406 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0816/280/0000	050-099
L00406 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0935/280/0000	162-199
L00406 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-13 0825/280/0000	275-276, 280-299
L00406 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-13 0833/280/0000	277-278
L00406 T		387 LAMP	417T5092 08806	1	23-42-11 0816/280/0000	050-099
L00406 T		387 LAMP	417T5092 08806	1	23-42-11 0935/280/0000	162-199
L00406 T		387 LAMP	417T5092 08806	1	23-42-13 0825/280/0000	275-276, 280-299
L00406 T		387 LAMP	417T5092 08806	1	23-42-13 0833/280/0000	277-278
L00407		855308-9 LIGHT-LAV CALL,MID CTR L	14889	1	33-25-11 0816/280/L001	050-099
L00407		855308-9 LIGHT-LAV CALL, MID CTR L	14889	1	33-25-11 945/280/L001	150-199
L00407		855308-9 LIGHT-LAV CALL,MID CTR L	14889	1	33-25-11 0835/280/L001	275-299

EQUIPMENT LIST

D280T132

Section L00400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00407 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	ALL
L00407 T		387 LAMP-	417T5092 08806	1	33-25-11 / /	ALL
L00408		855308-9 LIGHT-LAV CALL,MID CTR R	48893	1	33-25-11 0816/280/R001	050-099
L00408		855308-9 LIGHT-LAV CALL, MID CTR R	14889	1	33-25-11 945/280/R001	150-199
L00408		855308-9 LIGHT-LAV CALL,MID CTR R	48893	1	33-25-11 0835/280/R001	275-278
L00408		855308-9 LIGHT-LAV CALL,MID CTR R	14889	1	33-25-11 0835/280/R001	280-299
L00408 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	ALL
L00408 T		387 LAMP-	417T5092 08806	1	33-25-11 / /	ALL
L00409		855308-9 LIGHT-MASTER CALL, MID CTR L	14889	1	23-34-13 816/280/L 2	050-099
L00409		855308-9 LIGHT-MASTER CALL, MID CTR L	14889	1	23-34-12 918/280/L014	150-199
L00409		855308-9 LIGHT-MASTER CALL,MID CTR L	14889	1	23-34-12 0835/280/L002	275-278
L00409		855308-9 LIGHT-MASTER CALL,MID CTR L	14889	1	23-34-12 0833/280/L002	280-299
L00409 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199, 275-278
L00409 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00409 T		387 LAMP	417T5092 08806	1	23-34-13 / /	050-099
L00409 T		387 LAMP-	417T5092 08806	1	23-34-13 / /	150-199, 275-278
L00409 T		387 LAMP-	417T6600 08806	1	23-34-13 / /	280-299

EQUIPMENT LIST

D280T132

Section L00400

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00410		855308-9 LIGHT-MASTER MID CTR R	14889	1	23-34-13 816/280/R 2	050-099
L00410		855308-9 LIGHT-MASTER CALL, MID CTR R	14889	1	23-34-12 918/280/L010	150-199
L00410		855308-9 LIGHT-MASTER CALL,MID CTR R	14889	1	23-34-12 0835/280/R002	275-278
L00410		855308-9 LIGHT-MASTER CALL,MID CTR R	14889	1	23-34-12 0833/280/R002	280-299
L00410 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199, 275-278
L00410 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00410 T		387 LAMP	417T5092 08806	1	23-34-13 / /	050-099
L00410 T		387 LAMP-	417T5092 08806	1	23-34-13 / /	150-199, 275-278
L00410 T		387 LAMP-	417T6600 08806	1	23-34-13 / /	280-299
L00411		60B50041-2 LT-CLOSET	417T5082 81205	1	33-22-21 0840/261/L020	050-099
L00411		60B50041-2 LT-CLOSET	417T5082 81205	1	33-22-21 0654+120/262/L021	151-152
L00411 T		1864 LAMP-CLOSET	60B50041 08806	1	33-22-21 / /	050-099, 151-152
L00412		D7520-5 LIGHT-UTILITY,SECOND OBSERVER	232T5004 72914	1	33-14-31 0217/255/L057	ALL
L00412 T		1495X LAMP	D7520000 08805	1	33-14-31 / /	ALL
L00413		10-0428-31 LIGHT-MID ATTENDANT SIGN	417T5129 72914	1	33-24-11 0800/266/R018	050-099
L00413		10-0428-31 LIGHT-MID ATTENDANT SIGN	417T5129 72914	1	33-24-13 0951/270/L005	150-199
L00413		10-0428-29 LIGHT-MID ATTENDANT SIGN	417T5129 72914	1	33-24-11 0838/266/R012	275-278

EQUIPMENT LIST

D280T132

Section L00400

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00413		10-0428-29 LIGHT-MID ATTENDANT SIGN	417T5129 72914	1	33-24-11 0838/266/L025	280-299
L00413 T		10-0291-3 LAMP-MID ATTENDANT SIGN	10-00428 72914	5	33-24-11 / /	050-099, 275-299
L00413 T		10-02913 LAMP-MID ATTENDANT SIGN	10-00428 72914	5	33-24-13 / /	150-199
L00414		S417T503-7 LIGHT-FWD ATTENDANT SIGN	417T5096 81205	1	33-24-12 0356/280/L035	275-299
L00414 T		MS25237-387 LAMP-FWD ATTENDANT SIGN	10-01004 96906	6	33-24-12 / /	275-299
L00415		S417T503-7 LIGHT-AFT ATTENDANT SIGN	417T5096 81205	1	33-24-12 1471/280/L036	050-099, 150-157, 275-299
L00415		S417T503-7 LIGHT-AFT ATTENDANT SIGN	417T5096 81205	1	33-24-12 1490/280/L012	162-199
L00415 T		MS25237-387 LAMP-AFT ATTENDANT SIGN	10-01004 96906	6	33-24-12 / /	ALL
L00416		S417T503-7 LIGHT-AFT ATTENDANT SIGN	417T5096 81205	1	33-24-14 1471/280/R036	050-099, 150-157, 275-299
L00416		S417T503-7 LIGHT-AFT ATTENDANT SIGN	417T5096 81205	1	33-24-14 1490/280/R012	162-199
L00416 T		MS25237-387 LAMP-AFT ATTENDANT SIGN	10-01004 96906	6	33-24-14 / /	ALL
L00419		S417T502-4 SOCKET-AFT DIRECT CEILING	411T3030 81205	1	33-22-42 0935/280/L010	150-199
L00419 T		2233 LIGHT-AFT DIRECT CEILING	411T3030 81205	1	33-22-42 / /	150-199
L00420		S417T502-4 LIGHT-AFT DIRECT CEILING	411T3030 81205	1	33-22-42 0935/280/R010	150-199
L00420 T		2233 LAMP	411T3030 81205	1	33-22-42 / /	150-199
L00422		S417T500-2 LIGHT-LWRD CEILING	411T3127 81205	1	33-51-13 1522/280/L025	050-099
L00422		S417T500-2 LIGHT-LWRD CEILING	411T3127 81205	1	33-51-13 1496/280/L025	150-199

EQUIPMENT LIST

D280T132

Section L00400

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00422		S417T500-2 LIGHT-LWRD CEILING	411T3027 81205	1	33-51-13 1522/280/L019	275-299
L00422 T		1317 LAMP	411T3127 08805	1	33-51-13 / /	050-099, 150-199
L00422 T		1317 LAMP	411T3027 08805	1	33-51-13 / /	275-299
L00425		S417T508-83 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0455/280/L040	050-099, 150-199
L00425		S417T508-22 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0389/280/L040	275-278
L00425		S417T508-242 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0389/280/L040	280-299
L00425 T		MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5101 96906	8	33-26-21 / /	ALL
L00426		S417T508-112 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1075/280/L040	050-099
L00426		60B50040-112 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0986/280/L040	150-199
L00426		S417T508-22 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0892/280/L040	275-278
L00426		S417T508-83 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0888/280/L040	280-299
L00426 T		MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5101 96906	8	33-26-21 / /	ALL
L00432		S283T008-75 LIGHT-LOGO,INBD,L	284T0793 81205	1	33-45-11 SL194/12/FS	ALL
L00432 T	1	Q4631 LAMP-LOGO LIGHT	284T0793 S5006	1	33-45-11 / /	ALL
L00432 T	2	Q4631 LAMP-LOGO LIGHT	284T0793 24455	1	33-45-11 / /	ALL
L00433		S283T008-17 LIGHT-LOGO,OUTBD,L	284T0793 81205	1	33-45-11 SL218/12/FS	ALL
L00433 T	1	Q4631 LAMP-LOGO LIGHT	284T0793 S5006	1	33-45-11 / /	ALL

EQUIPMENT LIST

D280T132

Section L00400

Page 6

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00433 T	2	Q4631 LAMP-LOGO LIGHT	284T0793 24455	1	33-45-11 / /	ALL
L00434		S283T008-76 LIGHT-LOGO,INBD,R	284T0793 81205	1	33-45-11 SR194/12/FS	ALL
L00434 T	1	Q4631 LAMP-LOGO LIGHT	284T0793 S5006	1	33-45-11 / /	ALL
L00434 T	2	Q4631 LAMP-LOGO LIGHT	284T0793 24455	1	33-45-11 / /	ALL
L00435		S283T008-18 LIGHT-LOGO,OUTBD,R	284T0793 81205	1	33-45-11 SR218/12/FS	ALL
L00435 T	1	Q4631 LAMP-LOGO LIGHT	284T0793 S5006	1	33-45-11 / /	ALL
L00435 T	2	Q4631 LAMP-LOGO LIGHT	284T0793 24455	1	33-45-11 / /	ALL
L00436		L5105-AM LT-PALLET MODE	284T0687 81640	1	25-53-13 P035-00/ /	050-099
L00436		L5105-AM LT-PALLET MODE	284T3501 81640	1	25-53-11 P035-00/ /	150-199, 275-299
L00436 T		MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	ALL
L00437		L5105-AM LIGHT-BAY E/F OFF	284T0687 81640	1	25-53-13 P035-00/ /	050-099
L00437 T		MS25237-387 LAMP	284T0687 96906	1	25-53-13 P035-00/ /	050-099
L00438		L5105-AM LIGHT-BAY E/F ON	284T0687 81640	1	25-53-13 P035-00/ /	050-099
L00438 T		MS25237-387 LAMP	284T0687 96906	1	25-53-13 P035-00/ /	050-099
L00455		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0455/283/L040	275-299
L00455 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	275-299
L00456		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0455/280/R040	275-299

EQUIPMENT LIST

D280T132

Section L00400

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00456 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	275-299
L00457		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0629/283/L040	ALL
L00457 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00458		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0629/283/R040	ALL
L00458 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00459		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0807/280/R040	050-099, 275-299
L00459		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0851/280/R040	150-199
L00459 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00460		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0807/280/L040	050-099, 275-299
L00460		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0851/180/L040	150-199
L00460 T		55-1540-1 LAMP-NIGHT LT	417T5085 08806	1	33-21-21 / /	ALL
L00461		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0932/280/R040	050-099
L00461		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1020/280/R040	150-199
L00461		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0976/280/R040	275-299
L00461 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00462		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0932/280/L040	050-099
L00462		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1020/280/L040	150-199

EQUIPMENT LIST

D280T132

Section L00400

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00462		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0976/280/L040	275-299
L00462 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00463		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1108/280/R040	050-099
L00463		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1152/280/R040	150-199, 275-299
L00463 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00464		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1108/280/L040	050-099
L00464		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1152/280/L040	150-199, 275-299
L00464 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00465		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1284/280/R040	050-099
L00465		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1372/280/R040	150-199, 275-299
L00465 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00466		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1284/280/L040	050-099
L00466		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1372/280/L040	150-199, 275-299
L00466 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	ALL
L00474	1	S231T300-2264 LIGHT-L OIL PRESSURE	233T2222 81205	1	79-33-11 P001-03/ /	ALL
L00474	2	S231T300-1264 LIGHT-L OIL PRESSURE	233T2222 81205	1	79-33-11 P001-03/ /	ALL
L00474	3	S231T300-1264 LIGHT-L OIL PRESSURE	233T2222 81205	1	79-33-11 P001-03/ /	ALL

EQUIPMENT LIST

D280T132

Section L00400

Page 9

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00474A		MS25237-387 LAMP-28V,L OIL PRESS	233T2222 96906	2	79-33-11 / /	ALL
L00474D		434-093-001 DIODE/FUSE MODULE-L OIL PRESS.	233T2222 81590	1	79-33-11 / /	ALL
L00475	1	S231T300-2265 LIGHT-R OIL PRESSURE	233T2222 81205	1	79-33-11 P001-03/ /	ALL
L00475	2	S231T300-1265 LIGHT-R OIL PRESSURE	233T2222 81205	1	79-33-11 P001-03/ /	ALL
L00475	3	S231T300-1265 LIGHT-R OIL PRESSURE	233T2222 81205	1	79-33-11 P001-03/ /	ALL
L00475A		MS25237-387 LAMP-28V,R OIL PRESS.	233T2222 96906	2	79-33-11 / /	ALL
L00475D		434-093-001 DIODE/FUSE MODULE-R OIL PRESS.	233T2222 81590	1	79-33-11 / /	ALL
L00481		S233T100-002 LIGHTPLATE-INSTR SOURCE SEL SW,CAPT	233T2200 81205	1	33-13-11 P001-01/ /	ALL
L00482		S233T100-013 LIGHTPLATE-LTG CONT PNL,CAPT	233T2100 81205	1	33-13-17 P007-00/ /	ALL
L00483		S233T100-014 LIGHTPLATE-LTG CONT PNL,F/O	233T2100 81205	1	33-13-17 P007-00/ /	ALL
L00489		S233T100-003 LIGHTPLATE-INSTR SOURCE SEL SW,F/O	233T2100 81205	1	33-13-13 P003-03/ /	ALL
L00491		S233T100-028 LIGHTPLATE-GEAR LEVER	233T2223 81205	1	33-13-13 P003-01/ /	ALL
L00494		S233T100-004 LIGHTPLATE-AUTO BRAKES	233T2222 81205	1	33-13-11 P001-03/ /	050-099
L00494		S233T100-008 LIGHTPLATE-AUTO BRAKES	233T2222 81205	1	33-13-11 P001-03/ /	150-199, 275-299
L00496		S233T100-507 LIGHTPLATE-STAB TRIM CUT-OFF CONTROL	253T5599 81205	1	33-13-18 P010-00/ /	ALL
L00498	9	253T5917-1 LIGHTPLATE-ELEC ENG CONTROL(SB 73-0024)	253T5599 81205	1	33-13-18 P010-00/ /	050-099, 275-299
L00499		S233T100-3006 LIGHTPLATE-ROW 1L	233T5112 81205	1	33-13-19 P011-03/ /	ALL

EQUIPMENT LIST

D280T132

Section L00400
Page 10 End
Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00500		S233T100-3007 LIGHTPLATE-ROW 2L	233T5112 81205	1	33-13-19 P011-03/ /	ALL
L00501		S233T100-3009 LIGHTPLATE-ROW 3L	233T5112 81205	1	33-13-19 P011-03/ /	ALL
L00502		S233T100-3009 LIGHTPLATE-ROW 4L	233T5111 81205	1	33-13-19 P011-03/ /	ALL
L00503		S233T100-3011 LIGHTPLATE-ROW 5L	233T5112 81205	1	33-13-19 P011-03/ /	ALL
L00504		S233T100-3007 LIGHTPLATE-ROW 6L	233T5112 81205	1	33-13-19 P011-03/ /	ALL
L00505		S233T100-3005 LIGHTPLATE-ROW 7L	233T5112 81205	1	33-13-19 P011-03/ /	ALL
L00506		S233T100-3006 LIGHTPLATE-ROW 8L	233T5112 81205	1	33-13-19 P011-02/ /	ALL
L00507		S233T100-3007 LIGHTPLATE-ROW 9L	233T5112 81205	1	33-13-19 P011-02/ /	ALL
L00508		S233T100-3009 LIGHTPLATE-ROW 10L	233T5112 81205	1	33-13-19 P011-02/ /	ALL
L00509		S233T100-3009 LIGHTPLATE-ROW 11L	233T5112 81205	1	33-13-19 P011-02/ /	ALL
L00510		S233T100-3011 LIGHTPLATE-ROW 12L	233T5112 81205	1	33-13-19 P011-02/ /	ALL
L00511		S233T100-3007 LIGHTPLATE-ROW 13L	233T5112 81205	1	33-13-19 P011-02/ /	ALL
L00512		S233T100-3005 LIGHTPLATE-ROW 14L	233T5112 81205	1	33-13-19 P011-02/ /	ALL
L00513		S233T100-3006 LIGHTPLATE-ROW 15L	233T5112 81205	1	33-13-19 P011-01/ /	ALL
L00514		S233T100-3007 LIGHTPLATE-ROW 16L	233T5112 81205	1	33-13-19 P011-01/ /	ALL
L00515		S233T100-3009 LIGHTPLATE-ROW 17L	233T5112 81205	1	33-13-19 P011-01/ /	ALL
L00516		S233T100-3009 LIGHTPLATE-ROW 18L	233T5112 81205	1	33-13-19 P011-01/ /	ALL

EQUIPMENT LIST

D280T132

Section L00500

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00517		S233T100-3011 LIGHTPLATE-ROW 19L	233T5112 81205	1	33-13-19 P011-01/ /	ALL
L00518		S233T100-3007 LIGHTPLATE-ROW 20L	233T5112 81205	1	33-13-19 P011-01/ /	ALL
L00519		S233T100-3005 LIGHTPLATE-ROW 21L	233T5112 81205	1	33-13-19 P011-01/ /	ALL
L00520		S233T100-3006 LIGHTPLATE-ROW 1R	233T5112 81205	1	33-13-19 P011-06/ /	ALL
L00521		S233T100-3008 LIGHTPLATE-ROW 2R	233T5112 81205	1	33-13-19 P011-06/ /	ALL
L00522		S233T100-3010 LIGHTPLATE-ROW 3R	233T5112 81205	1	33-13-19 P011-06/ /	ALL
L00523		S233T100-3010 LIGHTPLATE-ROW 4R	233T5112 81205	1	33-13-19 P011-06/ /	ALL
L00524		S233T100-3012 LIGHTPLATE-ROW 5R	233T5112 81205	1	33-13-19 P011-06/ /	ALL
L00525		S233T100-3008 LIGHTPLATE-ROW 6R	233T5112 81205	1	33-13-19 P011-06/ /	ALL
L00526		S233T100-3001 LIGHTPLATE-ROW 7R	233T5112 81205	1	33-13-19 P011-06/ /	ALL
L00527		S233T100-3006 LIGHTPLATE-ROW 8R	233T5212 81205	1	33-13-19 P011-05/ /	ALL
L00528		S233T100-3008 LIGHTPLATE-ROW 9R	233T5112 81205	1	33-13-19 P011-05/ /	ALL
L00529		S233T100-3010 LIGHTPLATE-ROW 10R	233T5112 81205	1	33-13-19 P011-05/ /	ALL
L00530		S233T100-3010 LIGHTPLATE-ROW 11R	233T5112 81205	1	33-13-19 P011-05/ /	ALL
L00531		S233T100-3012 LIGHTPLATE-ROW 12R	233T5112 81205	1	33-13-19 P011-05/ /	ALL
L00532		S233T100-3008 LIGHTPLATE-ROW 13R	233T5112 81205	1	33-13-19 P011-05/ /	ALL
L00533		S233T100-3001 LIGHTPLATE-ROW 14R	233T5112 81205	1	33-13-19 P011-05/ /	ALL

EQUIPMENT LIST

D280T132

Section L00500

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00534		S233T100-3006 LIGHTPLATE-ROW 15R	233T5112 81205	1	33-13-19 P011-04/ /	ALL
L00535		S233T100-3008 LIGHTPLATE-ROW 16R	233T5112 81205	1	33-13-19 P011-04/ /	ALL
L00536		S233T100-3010 LIGHTPLATE-ROW 17R	233T5112 81205	1	33-13-19 P011-04/ /	ALL
L00537		S233T100-3010 LIGHTPLATE-ROW 18R	233T5112 81205	1	33-13-19 P011-04/ /	ALL
L00538		S233T100-3012 LIGHTPLATE-ROW 19R	233T5112 81205	1	33-13-19 P011-04/ /	ALL
L00539		S233T100-3008 LIGHTPLATE-ROW 20R	233T5112 81205	1	33-13-19 P011-04/ /	ALL
L00540		S233T100-3001 LIGHTPLATE-ROW 21R	233T5112 81205	1	33-13-19 P011-04/ /	ALL
L00541		69-23884-7 LIGHT-APU FIRE	284T0719 72914	1	26-15-12 P040-00/ /	ALL
L00542	9	06-91182-12 LIGHT-FIRE BOTTLES ARMED (SB 26-0066)	284T0719 76854	1	26-22-21 P040-00/ /	050-099, 150-155, 162-165, 275-276
L00542		06-91182-12 LIGHT-FIRE BOTTLES ARMED	284T0719 76854	1	26-22-21 P040-00/ /	156-157, 166-199, 277-299
L00542 T		1864 LAMP	284T0719 08806	1	26-22-21 P040-00/ /	ALL
L00543	9	06-91182-12 LIGHT-NO.1 BOTTLE DISCH (SB 26-0066)	284T0719 76854	1	26-22-21 P040-00/ /	050-099, 150-155, 162-165, 275-276
L00543		06-91182-12 LIGHT-NO.1 BOTTLE DISCHARGED	284T0719 76854	1	26-22-21 P040-00/ /	156-157, 166-199, 277-299
L00543 T		1864 LAMP	284T0719 08806	1	26-22-21 P040-00/ /	ALL
L00544	9	06-91182-12 LIGHT-NO.2 BOTTLE DISCH (SB 26-0066)	284T0720 76854	1	26-22-21 P040-00/ /	275-276
L00544		06-91182-12 LIGHT-NO.2 BOTTLE DISCHARGED	284T0719 76854	1	26-22-21 P040-00/ /	277-299
L00544 T		1864 LAMP	284T0719 08806	1	26-22-21 P040-00/ /	275-299

EQUIPMENT LIST

D280T132

Section L00500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00545		284T1005-2 LIGHT-AFT CARGO DOOR	284T0001 81205	1	33-31-61 D0190/135/R055	ALL
L00545 T		4627 LAMP	284T1005 24455	1	33-31-61 / /	ALL
L00546		455T0212 SILL LIGHT-AFT CARGO DOOR	455T1202 81205	1	33-37-21 D0204/145/R070	ALL
L00546 T		4627 LAMP	455T1202 24455	1	33-37-21 / /	ALL
L00547		284T1005-2 LIGHT-AFT CARGO DOOR	284T0001 81205	1	33-31-61 D0216/135/R055	ALL
L00547 T		4627 LAMP	284T1005 24455	1	33-31-61 / /	ALL
L00548		15-0188-7 LIGHT-AFT A CARGO COMPT	455T1203 72914	1	33-37-21 1164/194/R033	ALL
L00548 T		3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00549		15-0188-7 LIGHT-AFT A CARGO COMPT	455T1203 72914	1	33-37-21 1164/194/L033	ALL
L00549 T		3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00550		15-0188-7 LIGHT-AFT B CARGO COMPT	455T1203 72914	1	33-37-21 1230/194/R033	ALL
L00550 T		3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00551		15-0188-7 LIGHT-AFT B CARGO COMPT	455T1203 72914	1	33-37-21 1230/194/L033	ALL
L00551 T		3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00552		15-0188-7 LIGHT-AFT A CARGO COMPT	455T1203 72914	1	33-37-21 1296/194/R033	ALL
L00552 T		3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00553		15-0188-7 LIGHT-AFT A CARGO COMPT	455T1203 72914	1	33-37-21 1296/194/L033	ALL

EQUIPMENT LIST

D280T132

Section L00500

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00553	T	3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00554		15-0188-7 LIGHT-AFT B CARGO COMPT	455T1203 72914	1	33-37-21 1362/194/R033	ALL
L00554	T	3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00555		15-0188-7 LIGHT-AFT B CARGO COMPT	455T1203 72914	1	33-37-21 1362/194/L033	ALL
L00555	T	3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00556		15-0188-7 LIGHT-AFT A CARGO COMPT	455T1203 72914	1	33-37-21 1430/194/R033	ALL
L00556	T	3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00557		15-0188-7 LIGHT-AFT A CARGO COMPT SILL	455T1205 72914	1	33-37-21 1409/170/L082	ALL
L00557	T	3011 LAMP	455T1205 08806	1	33-37-21 / /	ALL
L00558		15-0188-7 LIGHT-AFT B CARGO COMPT	455T1203 72914	1	33-37-21 1491/194/R033	ALL
L00558	T	3011 LAMP	455T1201 08806	1	33-37-21 / /	ALL
L00560		15-0188-7 LIGHT-AFT B CARGO COMPT	455T1203 72914	1	33-37-21 1491/194/L033	ALL
L00560	T	3011 LAMP	455T1203 08806	1	33-37-21 / /	ALL
L00561		L0060001 LIGHT ASSY-GLARESHIELD FLDT,L	233T8101 51896	1	33-11-13 P007-00/ /	ALL
L00561	T	MS90451-7152 LAMP	L0060001 96906	10	33-11-13 / /	ALL
L00562		L0060002 LIGHT ASSY-GLARESHIELD FLDT,R	233T8101 51896	1	33-11-13 P007-00/ /	ALL
L00562	T	MS90451-7152 LAMP	L0060002 96906	10	33-11-13 / /	ALL

EQUIPMENT LIST

D280T132

Section L00500

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00564		855308-9 LIGHT-LAV CALL,FWD R	417T5105 14889	1	33-25-11 0356/280/R038	050-099, 151-199
L00564		855308-9 LIGHT-LAV CALL,FWD R	14889	1	33-25-11 0356/280/R044	150, 275-299
L00564 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	ALL
L00564 T		387 LAMP-	417T5092 08806	1	33-25-11 / /	ALL
L00565		855308-9 LIGHT-LAV CALL,FWD L	417T5105 14889	1	33-25-11 0356/280/L038	050-099, 151-199
L00565		855308-9 LIGHT-LAV CALL,FWD L	14889	1	33-25-11 0356/280/L038	150, 275-299
L00565 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	ALL
L00565 T		387 LAMP-	417T5092 08806	1	33-25-11 / /	ALL
L00568		855308-9 LIGHT-LAV CALL,AFT R	14889	1	33-25-11 1505/280/R032	050-099, 150-199
L00568		855308-9 LIGHT-LAV CALL,AFT R	14889	1	33-25-11 1473/280/R044	275-299
L00568 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	ALL
L00568 T		387 LAMP-	417T5092 08806	1	33-25-11 / /	ALL
L00569		855308-9 LIGHT-LAV CALL,AFT L	14889	1	33-25-11 1505/280/L033	050-099, 150-199
L00569		855308-9 LIGHT-LAV CALL,AFT L	14889	1	33-25-11 1471/280/L044	275-299
L00569 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	ALL
L00569 T		387 LAMP-	417T5092 08806	1	33-25-11 / /	ALL
L00571	1	33-32683-6P1 LIGHT-HOT BUS WARN,115V AC L	284T0187 29207	1	24-51-12 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section L00500

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00571	2	33-32683-6P4 LIGHT-HOT BUS WARN,115V AC L	284T0187 29207	1	24-51-12 P036-00/ /	ALL
L00571 T		AIG LAMP	284T0187 29207	1	24-51-12 / /	ALL
L00572	1	33-32683-6P1 LIGHT-HOT BUS WARN,UTIL L	284T0187 87034	1	24-51-13 P036-00/ /	ALL
L00572	2	33-32683-6P4 LIGHT-HOT BUS WARN,UTIL L	284T0187 87034	1	24-51-13 P036-00/ /	ALL
L00572 T		AIG LAMP	284T0187 87034	1	24-51-13 / /	ALL
L00573	1	33-32683-6P1 LIGHT-HOT BUS WARN,115V AC R	284T0188 29207	1	24-51-22 P037-00/ /	ALL
L00573	2	33-32683-6P4 LIGHT-HOT BUS WARN,115V AC R	284T0188 29207	1	24-51-22 P037-00/ /	ALL
L00573 T		AIG LAMP	284T0188 29207	1	24-51-22 / /	ALL
L00574	1	33-32683-6P1 LIGHT-HOT BUS WARN,UTIL BUS R	284T0188 29207	1	24-51-23 P037-00/ /	ALL
L00574	2	33-32683-6P4 LIGHT-HOT BUS WARN,UTIL BUS R	284T0188 29207	1	24-51-23 P037-00/ /	ALL
L00574 T		AIG LAMP	284T0188 29207	1	24-51-23 / /	ALL
L00575	1	33-32683-6P1 LIGHT-HOT BUS WRN,115V GND SVCE	284T0189 87034	1	24-51-52 P033-00/ /	ALL
L00575	2	33-32683-6P4 LIGHT-HOT BUS WRN,115V GND SVCE	284T0189 87034	1	24-51-52 P033-00/ /	ALL
L00575 T		AIG LAMP	284T0189 87034	1	24-51-52 / /	ALL
L00576		S233T100-509 LIGHTPLATE-FLAP SETTING	253T5599 81205	1	33-13-18 P010-00/ /	ALL
L00577		S233T100-510 LIGHTPLATE-SPEED BRAKE	253T5599 81205	1	33-13-18 P010-00/ /	ALL
L00579		855308-9 LIGHT-MASTER CALL,FWD L	411T3126 14889	1	23-34-12 0356/280/L038	050-099, 151-157

EQUIPMENT LIST

D280T132

Section L00500

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00579		855308-9 LIGHT-MASTER CALL,FWD L	14889	1	23-34-12 0356/280/L038	150
L00579		855308-9 LIGHT-MASTER CALL,FWD L	411T3126 14889	1	23-34-13 0356/280/L038	162-199
L00579		855308-9 LIGHT-MASTER CALL,FWD L	14889	1	23-34-12 0356/280/L045	275-299
L00579 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199, 275-278
L00579 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00579 T		387 LAMP-	417T5092 08806	1	23-34-13 / /	050-099, 150-199, 275-278
L00579 T		387 LAMP-	417T6600 08806	1	23-34-13 / /	280-299
L00580		855308-9 LIGHT-MASTER CALL,FWD R	411T3126 14889	1	23-34-12 0356/280/R038	050-099, 151-157
L00580		855308-9 LIGHT-MASTER CALL,FWD R	14889	1	23-34-12 0356/280/R038	150
L00580		855308-9 LIGHT-MASTER CALL,FWD R	411T3126 14889	1	23-34-13 0356/280/R038	162-199
L00580		855308-9 LIGHT-MASTER CALL,FWD R	14889	1	23-34-12 0356/280/R045	275-299
L00580 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199, 275-278
L00580 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00580 T		387 LAMP-	417T5092 08806	1	23-34-13 / /	050-099, 150-199, 275-278
L00580 T		387 LAMP-	417T6600 08806	1	23-34-13 / /	280-299
L00581		855308-9 LIGHT-MASTER CALL AFT B/C L	14889	1	23-34-13 851/280/L 38	050-099, 150-154, 156, 162-199
L00581		855308-9 LIGHT-MASTER CALL,MID L	417T5092 14889	1	23-34-13 0851/280/L038	155

EQUIPMENT LIST

D280T132

Section L00500

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00581		855308-9 LIGHT-MASTER CALL,MID L	417T3126 14889	1	23-34-13 0851/280/L038	157
L00581 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199
L00581 T		387 LAMP	417T5092 08806	1	23-34-13 / /	050-099, 150-199
L00582		855308-9 LIGHT-MASTER CALL AFT B/C R	14889	1	23-34-13 851/280/R 38	050-099, 150-154, 156, 162-199
L00582		855308-9 LIGHT-MASTER CALL,MID R	417T5092 14889	1	23-34-13 0851/280/R038	155
L00582		855308-9 LIGHT-MASTER CALL,MID R	417T3126 14889	1	23-34-13 0851/280/R038	157
L00582 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199
L00582 T		387 LAMP	417T5092 08806	1	23-34-13 / /	050-099, 150-199
L00583		855308-9 LIGHT-MASTER CALL,AFT L	14889	1	23-34-12 1505/280/L034	050-099, 150-199
L00583		855308-9 LIGHT-MASTER CALL,AFT L	14889	1	23-34-13 1471/280/L043	275-299
L00583 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199, 275-278
L00583 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00583 T		387 LAMP-	417T5092 08806	1	23-34-13 / /	050-099, 150-199, 275-278
L00583 T		387 LAMP-	417T6600 08806	1	23-34-13 / /	280-299
L00584		855308-9 LIGHT-MASTER CALL,AFT R	14889	1	23-34-12 1505/280/R034	050-099, 150-199
L00584		855308-9 LIGHT-MASTER CALL,AFT R	14889	1	23-34-12 1471/280/R043	275-299
L00584 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199, 275-278

EQUIPMENT LIST

D280T132

Section L00500

Page 9

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00584 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00584 T		387 LAMP-	417T5092 08806	1	23-34-13 / /	050-099, 150-199, 275-278
L00584 T		387 LAMP-	417T6600 08806	1	23-34-13 / /	280-299
L00585		S231T300-2054 LIGHT ASSY-INNER MKR BEACON,CAPT	233T2222 81205	1	34-32-11 P001-03/ /	ALL
L00586		S231T300-2070 LIGHT ASSY-MIDDLE MKR BEACON,CAPT	233T2222 81205	1	34-32-11 P001-03/ /	ALL
L00587		S231T300-2082 LIGHT ASSY-OUTER MKR BEACON,CAPT	233T2222 81205	1	34-32-11 P001-03/ /	ALL
L00588		S231T300-2054 LIGHT ASSY-INNER MKR BEACON,F/O	233T2204 81205	1	34-32-11 P003-03/ /	ALL
L00589		S231T300-2070 LIGHT ASSY-MIDDLE MKR BEACON,F/O	233T2204 81205	1	34-32-11 P003-03/ /	ALL
L00590		S231T300-2082 LIGHT ASSY-OUTER MKR BEACON,F/O	233T2204 81205	1	34-32-11 P003-03/ /	ALL
L00591		S231T300-1225 LIGHT-A/T DISENGAGE	233T2222 81205	1	22-34-11 P001-03/ /	ALL
L00591 A		MS25237-387AS25 LAMP	233T2222 96906	1	22-34-11 / /	ALL
L00591 B		MS25237-387AS25 LAMP	233T2222 96906	1	22-34-11 / /	ALL
L00591 D		434-093-001 DIODE/FUSE MODULE	233T2222 81590	1	22-34-11 / /	ALL
L00592	1	S231T300-2234 LIGHT-PARK BRAKE	253T5200 81205	1	32-44-11 P010-00/ /	ALL
L00592	2	S231T300-1234 LIGHT-PARK BRAKE	253T5200 81205	1	32-44-11 P010-00/ /	ALL
L00592 A		MS25237-387 LAMP-28V	253T5200 96906	2	32-44-11 / /	ALL
L00592 D		434-093-001 DIODE/FUSE ASSY	253T5200 81590	1	32-44-11 / /	ALL

EQUIPMENT LIST

D280T132

Section L00500

Page 10

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00593		10685-1 SOCKET-NIGHT LIGHT	417T5085 72914	1	33-22-41 0282/280/L039	ALL
L00593 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-22-41 / /	ALL
L00594		10685-1 SOCKET-NIGHT LIGHT	417T5085 72914	1	33-22-41 0282/280/L020	ALL
L00594 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-22-41 / /	ALL
L00595		15-0003-2-1495 LIGHT-CONT PNL DSPL,FWD CAR. EXTERIOR	284T0216 72914	1	25-53-11 P024-00/ /	ALL
L00595 T	1	1873 LAMP	284T0216 80368	1	25-53-11 / /	ALL
L00595 T	2	1864 LAMP	284T0216 80368	1	25-53-11 / /	ALL
L00595 T	3	1495X LAMP	284T0216 80368	1	25-53-11 / /	ALL
L00596		15-0003-2-1495 LIGHT-CONT PNL DSPL,AFT CAR. EXTERIOR	284T0216 72914	1	25-53-21 P027-00/ /	ALL
L00596 T	1	1873 LAMP	284T0216 80368	1	25-53-21 / /	ALL
L00596 T	2	1864 LAMP	284T0216 80368	1	25-53-21 / /	ALL
L00596 T	3	1495X LAMP	284T0216 80368	1	25-53-21 / /	ALL
L00597		04-92782-5-1864 LIGHT-CARGO DR OPEN,FWD	284T0923 76854	1	52-34-12 P043-00/ /	ALL
L00597 T		1864 LAMP	284T0923 08806	1	52-34-12 / /	ALL
L00598		04-92782-5-1864 LIGHT-CARGO DR OPEN,AFT	284T0566 76854	1	52-35-12 P044-00/ /	ALL
L00598 T		1864 LAMP	284T0566 08806	1	52-35-12 P044-00/ /	ALL
L00599		04-92782-5-1864 LIGHT-CARGO DR CLOSED,FWD	284T0923 76854	1	52-34-12 P043-00/ /	ALL

EQUIPMENT LIST

D280T132

Section L00500

Page 11

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00599 T		1864 LAMP	284T0923 08806	1	52-34-12 / /	ALL

EQUIPMENT LIST

D280T132

Section L00500
Page 12 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00600		04-92782-5-1864 LIGHT-CARGO DR CLOSED,AFT	284T0566 76854	1	52-35-12 P044-00/ /	ALL
L00600 T		1864 LAMP	284T0566 08806	1	52-35-12 P044-00/ /	ALL
L00602		S231T300-1153 LIGHT-ANNUNCIATOR,BLANK	233T2202 81205	1	33-16-15 P003-00/ /	050-099
L00602A		MS25237-387 LAMP	233T2222 96906	2	33-16-15 / /	050-099
L00602D		434-093-001 DIODE/FUSE ASSY	233T2222 81590	1	33-16-15 / /	050-099
L00603		S231T300-227 ANNUNCIATOR LIGHT INDICATOR-FMC	233T2222 75397	1	34-61-15 P001-03/ /	ALL
L00604		S233T100-508 LIGHTPLATE-FUEL CONTROL	253T5599 81205	1	33-13-18 P010-00/ /	ALL
L00605	1	S231T300-2257 LIGHT-BRAKE SOURCE PRESS.	233T2222 81205	1	32-41-11 P001-03/ /	ALL
L00605	2	S231T300-1257 LIGHT-BRAKE SOURCE PRESS.	233T2222 81205	1	32-41-11 P001-03/ /	ALL
L00605 A		MS25237-387 LAMP-28V	233T2222 96906	2	32-41-11 / /	ALL
L00605 D		434-093-001 DIODE/FUSE ASSY	233T2222 81590	1	32-41-11 / /	ALL
L00607		60B50041-2 LT-CLOSET	417T5082 81205	1	33-22-21 0840/260/R021	050-099
L00607		60B50041-2 LT-CLOSET	417T5082 81205	1	33-22-21 0654+120/258/R021	151-152
L00607 T		1864 LAMP-CLOSET	60B50041 08806	1	33-22-21 / /	050-099, 151-152
L00609		S233T100-015 LIGHT PLATE-RESERVE BRAKE & STRG C-SYS	233T2222 81205	1	33-13-11 P001-03/ /	ALL
L00611		S417T500-2 LIGHT-LWD CEILING	411T3026 81205	1	33-51-13 0334/280/L009	050-099, 150-199
L00611		S417T500-2 LIGHT-LWD CEILING	411T3026 81205	1	33-51-13 0325/280/L009	275-299

EQUIPMENT LIST

D280T132

Section L00600

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00611 T		1317 LAMP	411T3026 08805	1	33-51-13 / /	ALL
L00614		S417T503-7 LIGHT-AFT ATTENDANT SIGN	417T5096 81205	1	33-24-13 1564/280/L007	275-299
L00614 T		MS25237-387 LAMP-AFT ATTENDANT SIGN	10-01004 96906	6	33-24-13 / /	275-299
L00617		455T0252 LIGHT-SILL-BAY C	455T1106 81205	1	33-37-11 D0516/195/R110	ALL
L00617 T		4627 LAMP	455T1102 24455	1	33-37-11 / /	ALL
L00618		455T0252 LIGHT-SILL-BAY D	455T1106 81205	1	33-37-11 D0580/195/R110	ALL
L00618 T		4627 LAMP	455T1102 24455	1	33-37-11 / /	ALL
L00619		L5105-AM LIGHT-BAY A ON	284T0687 81640	1	25-53-13 P035-00/ /	050-099
L00619 T		MS25237-387 LAMP	284T0687 96906	1	25-53-13 / /	050-099
L00621		50-0129-3 LIGHT-TAXI,L	284T0798 72914	1	33-42-21 0263/105/L009	ALL
L00621 T		4554 LAMP-TAXI,L	284T0798 08805	1	33-42-21 0263/105/L009	ALL
L00622		50-0129-1 LIGHT-TAXI,R	284T0798 72914	1	33-42-21 0263/105/R009	ALL
L00622 T		4554 LAMP-TAXI,R	284T0798 08805	1	33-42-21 0263/105/R009	ALL
L00636	9	855308-9 LIGHT-LAV CALL,AFT CTR R	14889	1	33-25-11 1548/280/L007	050-099
L00636		855308-9 LIGHT-LAV CALL,AFT CTR R	14889	1	33-25-11 1553/280/R007	050-099
L00637	9	855308-9 LT-AFT CTR MSTR CALL	14889	1	23-34-12 1548/280/L 6	050-099
L00637 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099

EQUIPMENT LIST

D280T132

Section L00600

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00637 T		387 LAMP	417T5092 08806	1	23-34-13 / /	050-099
L00638	9	855308-9 LIGHT-ATTENDANT CALL,AFT CTR	14889	1	23-42-11 1548/280/0	050-099
L00638 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1553/280/R007	050-099
L00638 T		387 LAMP	417T5092 08806	1	23-42-11 1553/280/R007	050-099
L00642		S283T008-41 LIGHT-OVERWING EGRESS	284T0230 81205	1	33-51-21 0988/211/L098	ALL
L00642 T		1317 LAMPS	284T0230 08805	2	33-51-21 / /	ALL
L00643		S283T008-41 LIGHT-OVERWING EGRESS	284T0230 81205	1	33-51-21 0988/211/R098	ALL
L00643 T		1317 LAMPS	284T0230 08805	2	33-51-21 / /	ALL
L00644		S283T008-42 LIGHT-WING RIGHT SLIDE GRD ILLUM	284T0230 81205	1	33-51-21 1384/180/R098	050-099
L00644		S283T008-42 LIGHT-WING RIGHT SLIDE GRD ILLUM	284T0230 81205	1	33-51-21 1235/180/R098	150-199, 275-299
L00644 T		767 LAMP	284T0230 08805	1	33-51-21 / /	ALL
L00645		S283T008-43 LIGHT-WING LEFT SLIDE GRD ILLUM	284T0230 81205	1	33-51-21 1362/180/L094	050-099
L00645		S283T008-43 LIGHT-WING LEFT SLIDE GRD ILLUM	284T0230 81205	1	33-51-21 1230/180/L094	150-199, 275-299
L00645 T		767 LAMP	284T0230 08805	1	33-51-21 / /	ALL
L00647		S417T511-1 LIGHT-LEFT ATTENDANT WORK,FWD AUX	417T9502 81205	1	33-22-31 0348/275/L052	ALL
L00647 T		1308 LAMP	417T9502 08806	1	33-22-31 / /	ALL
L00648		10-0428-29 LIGHT-FWD ATTENDANT SIGN	417T5129 72914	1	33-24-13 0343/270/0000	275-278

EQUIPMENT LIST

D280T132

Section L00600

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00648		10-0428-29 LIGHT-FWD ATTENDANT SIGN	417T5129 72914	1	33-24-13 0349/277/0000	280-299
L00648 T		387 LAMP-FWD ATTENDANT SIGN	S417N503 08806	5	33-24-13 / /	275-299
L00652		S231T301-2206 LIGHT-LEFT GEAR	233T2223 81205	1	32-61-14 P003-01/ /	ALL
L00653		S231T301-2207 LIGHT-RIGHT GEAR	233T2223 81205	1	32-61-14 P003-01/ /	ALL
L00654		S231T301-2205 LIGHT-NOSE GEAR	233T2223 81205	1	32-61-14 P003-01/ /	ALL
L00655		S417T500-2 LIGHT-LWR CEILING	417T3055 81205	1	33-51-12 0863/280/L002	050-099
L00655		S417T500-2 LIGHT-LWR CEILING	417T3055 81205	1	33-51-13 0935/280/L020	150-154, 156, 162-199
L00655		S417T500-2 LIGHT-LWR CEILING	417T3055 81205	1	33-51-13 0877/280/L020	155, 157
L00655		S417T500-2 LIGHT-LWR CEILING	411T3030 81205	1	33-51-12 0870/280/0000	275-278
L00655		S417T500-2 LIGHT-LWR CEILING	411T3030 81205	1	33-51-12 0875/280/0000	280-299
L00655 T		1317 LAMP	411T3030 08805	1	33-51-13 / /	050-099, 150-199
L00655 T		1317 LAMP	411T3030 08805	1	33-51-12 / /	275-299
L00656		S417T503-7 LIGHT-AFT ATTENDANT SIGN	417T5096 81205	1	33-24-14 1590/280/R008	275-278
L00656		10-0291-29 LIGHT-AFT ATTENDANT SIGN	417T5129 72914	1	33-24-14 1590/280/R008	280-299
L00656 T		MS25237-387 LAMP-AFT ATTENDANT SIGN	10-01004 96906	6	33-24-14 / /	275-278
L00656 T		10-0291-387 LAMP-AFT ATTENDANT SIGN	10-00428 72914	5	33-24-14 / /	280-299
L00657		S231T301-2204 LIGHT-GEAR	233T2223 81205	1	32-61-14 P003-01/ /	ALL

EQUIPMENT LIST

D280T132

Section L00600

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00658		S231T301-2203 LIGHT-DOORS	233T2223 81205	1	32-61-14 P003-01/ /	ALL
L00660		S231T300-2237 LIGHT-TRAILING EDGE	233T2223 81205	1	27-58-31 P003-01/ /	ALL
L00661		S231T300-2213 LIGHT-LEADING EDGE CONFIGURATION	233T2223 81205	1	27-88-11 P003-01/ /	ALL
L00662		S233T100-5004 LIGHT PLATE-CAUTION CANCEL RCL,CTR PNL	233T2222 81205	1	33-13-11 P001-03/ /	ALL
L00663	1	S231T300-2290 LIGHT-BRAKE TEMP	233T2223 81205	1	32-46-11 P003-01/ /	ALL
L00663	2	S231T300-1290 LIGHT-BRAKE TEMP	233T2223 81205	1	32-46-11 P003-01/ /	ALL
L00663 A		MS25237-387 LAMP-28V	233T2223 96906	2	32-46-11 / /	ALL
L00663 D		434-093-001 DIODE/FUSE ASSY	233T2223 81590	1	32-46-11 / /	ALL
L00670		S417T503-7 LIGHT-FWD ATTENDANT SIGN	417T5096 81205	1	33-24-14 0356/280/R035	275-299
L00670 T		MS25237-387 LAMP-FWD ATTENDANT SIGN	10-01004 96906	6	33-24-14 / /	275-299
L00672		15-0129-5 LIGHT-ELEC/ELEX EQUIP CTR	284T0388 72914	1	33-31-41 0263/193/L044	ALL
L00672 T		1665 LAMP	284T0388 08805	1	33-31-41 / /	ALL
L00673		69B41965-1 FLDT-PWR DISTR PNL,FWD	233T4501 81205	1	33-11-16 P061-00/ /	ALL
L00673 T		1864 LAMP	69B41965 08805	1	33-11-16 / /	ALL
L00674		69B41965-1 FLDT-PWR DISTR PNL,AFT	233T4501 81205	1	33-11-16 P061-00/ /	ALL
L00674 T		1864 LAMP	69B41965 08805	1	33-11-16 / /	ALL
L00675		10-0428-31 LIGHT-ATTENDANT SIGN	417T5129 72914	1	33-24-11 0284/266/L058	050-099, 150-199

EQUIPMENT LIST

D280T132

Section L00600

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00675		S417N503-16 LIGHT-ATTENDANT SIGN	417T6600 81205	1	33-24-11 0284/266/L058	275-299
L00675 T		387 LAMP-ATTENDANT SIGN LIGHT	S417N503 08806	5	33-24-11 / /	ALL
L00680	1	S231T300-2294 LIGHT-WHEEL WELL FIRE	233T2223 81205	1	26-17-11 P003-01/ /	ALL
L00680	2	S231T300-1294 LIGHT-WHEEL WELL FIRE	233T2223 81205	1	26-17-11 P003-01/ /	ALL
L00680	3	S231T300-1294 LIGHT-WHEEL WELL FIRE	233T2223 81205	1	26-17-11 P003-01/ /	ALL
L00685	9	855308-9 LIGHT-MASTER CALL,MID-FWD L (SB 33-0042)	417T5105 14889	1	23-34-13 0807/275/L035	275
L00685		855308-9 LIGHT-MASTER CALL,MID-FWD L	417T5105 14889	1	23-34-13 0888/275/L035	275-276
L00685		855308-9 LIGHT-MASTER CALL,MID-FWD L	417T5105 14889	1	23-34-13 0807/275/L035	277-278
L00685		855308-9 LIGHT-MASTER CALL	14889	1	23-34-13 0888/280/L 38	280-299
L00685 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	275-278
L00685 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00685 T		387 LAMP	417T5092 08806	1	23-34-13 / /	275-278
L00685 T		387 LAMP	417T6600 08806	1	23-34-13 / /	280-299
L00686	9	855308-9 LIGHT-MASTER CALL,MID-FWD R (SB 33-0042)	417T5105 14889	1	23-34-13 0807/275/R035	275-276
L00686		855308-9 LIGHT-MASTER CALL,MID-FWD R	417T5105 14889	1	23-34-13 0807/275/R035	275-278
L00686		855308-9 LIGHT-MASTER CALL	14889	1	23-34-13 0888/280/R 38	280-299
L00686 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	275-278

EQUIPMENT LIST

D280T132

Section L00600

Page 6

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00686 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00686 T		387 LAMP	417T5092 08806	1	23-34-13 / /	275-278
L00686 T		387 LAMP	417T6600 08806	1	23-34-13 / /	280-299
L00687		855308-9 LIGHT-ATTENDENT CALL	14889	1	23-34-13 0888/280/L 38	275-276
L00687		855308-9 LIGHT-MASTER CALL,MID-AFT L	417T5105 14889	1	23-34-13 0888/275/L054	275-278
L00687		855308-9 LIGHT-MASTER CALL	14889	1	23-34-13 0888/280/L 38	277-278
L00687		855308-9 LIGHT-MASTER CALL,MID-AFT L	417T6600 14889	1	23-34-13 0807/279/L035	280-299
L00687 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	275-278
L00687 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299
L00687 T		387 LAMP	417T5092 08806	1	23-34-13 / /	275-278
L00687 T		387 LAMP	417T6600 08806	1	23-34-13 / /	280-299
L00688		855308-9 LIGHT-ATTENDENT CALL	14889	1	23-34-13 0888/280/R 38	275-276
L00688		855308-9 LIGHT-MASTER CALL,MID-AFT R	417T5105 14889	1	23-34-13 0888/275/R054	275-278
L00688		855308-9 LIGHT-MASTER CALL	14889	1	23-34-13 0888/280/R 38	277-278
L00688		855308-9 LIGHT-MASTER CALL,MID-AFT R	417T6600 14889	1	23-34-13 0807/279/R035	280-299
L00688 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	275-278
L00688 C		855307-3 LENS-BLUE	417T6600 14889	1	23-34-13 / /	280-299

EQUIPMENT LIST

D280T132

Section L00600

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00688	T	387 LAMP	417T5092 08806	1	23-34-13 / /	275-278
L00688	T	387 LAMP	417T6600 08806	1	23-34-13 / /	280-299
L00689		855308-9 LIGHT-LAV CALL,MID-FWD R	417T5105 14889	1	33-25-11 0631/280/R038	050-099, 150-199
L00689		855308-9 LIGHT-LAV CALL,MID-FWD R	14889	1	33-25-11 631/280/R 38	050-099, 150-199
L00689	C	855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	050-099, 150-199
L00689	T	387 LAMP	417T5092 08806	1	33-25-11 / /	050-099, 150-199
L00690		855308-9 LIGHT-LAV CALL, MID-FWD L	14889	1	33-25-11 631/280/L 38	050-099, 150-199
L00690		855308-9 LIGHT-LAV CALL,MID-FWD L	417T5105 14889	1	33-25-11 0631/280/L038	050-099, 150-199
L00690	C	855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	050-099, 150-199
L00690	T	387 LAMP	417T5092 08806	1	33-25-11 / /	050-099, 150-199
L00694		60B50040-112 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0858/285/L040	050-099
L00694		60B50040-112 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0679/285/L040	150-199
L00694	T	MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5101 96906	8	33-26-21 / /	050-099, 150-199
L00695		60B50040-112 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0858/285/R040	050-099
L00695		60B50040-112 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0679/285/R040	150-199
L00695	T	MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5101 96906	8	33-26-21 / /	050-099, 150-199
L00698		S233T100-33 LIGHTPLATE-MAG/TRUE	233T2223 81205	1	33-13-13 P003-01/ /	ALL

EQUIPMENT LIST

D280T132

Section L00600

Page 8

Sep 04/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00699		S417T504-26 LIGHT-OVER WING HATCH,EXIT SIGN	417T5106 81205	1	33-51-14 0916/260/R085	150-199, 280-299
L00699		S417T504-67 LIGHT-OVER WING HATCH,EXIT SIGN	417T5106 81205	1	33-51-14 0916/260/R085	275-278
L00699 T		7335 LAMP	417T5106 S 5006	8	33-51-14 / /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section L00600

Page 9 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00700		S417T504-26 LIGHT-OVER WING HATCH,EXIT SIGN	417T5106 81205	1	33-51-14 0916/260/L085	150-199, 280-299
L00700		S417T504-67 LIGHT-OVER WING HATCH,EXIT SIGN	417T5106 81205	1	33-51-14 0916/260/L085	275-278
L00700 T		7335 LAMP	417T5106 S 5006	8	33-51-14 / /	150-199, 275-299
L00707		B9735-2-1385 FLDT-AISLE STAND	233T5201 72914	1	33-11-13 0198/271/0000	ALL
L00707 T		1385 LAMP	B9735000 08805	1	33-11-13 / /	ALL
L00714		10-0428-31 LIGHT-AFT ATTENDANT SIGN	417T5129 72914	1	33-24-12 1540/276/L059	050-099, 150-199
L00714 T		10-0291-3 LAMP-AFT ATTENDANT SIGN	10-00428 72914	5	33-24-12 / /	050-099, 150-199
L00716		S231T300-1300 LIGHT-SPEED BRAKES	233T2222 81205	1	31-51-43 P001-03/ /	ALL
L00716 A		MS25237-387 LAMP-28V	233T2222 96906	2	31-51-43 / /	ALL
L00716 D		434-093-001 DIODE/FUSE ASSY	233T2222 81590	1	31-51-43 / /	ALL
L00729		60B50041-2 LIGHT-CLOSET	417T5082 81205	1	33-22-21 0654+90/254/R066	162-199
L00729 T		1864 LAMP-CLOSET	417T5082 08806	1	33-22-21 / /	162-199
L00731		855308-9 LIGHT-MASTER CALL FWD B/C L	14889	1	23-34-13 631/280/L 38	050-099, 150-199
L00731 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199
L00731 T		387 LAMP	417T5092 08806	1	23-34-13 / /	050-099, 150-199
L00732		855308-9 LIGHT-MASTER CALL,FWD B/C R	14889	1	23-34-13 631/280/R 38	050-099, 150-199
L00732 C		855307-3 LENS-BLUE	417T5092 08806	1	23-34-13 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section L00700

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00732 T		387 LAMP-	417T5092 08806	1	23-34-13 / /	050-099, 150-199
L00737		60B50041-2 LIGHT-CLOSET	417T5082 81205	1	33-22-21 0241/281/L003	150-154
L00737		60B50041-2 LIGHT-CLOSET	417T5082 81205	1	33-22-21 0246/258/R008	155-157
L00737		60B50041-2 LIGHT-CLOSET	417T5082 81205	1	33-22-21 0366/274/L066	275-278
L00737 T		55-2253-5 LAMP	S417N311 72914	1	33-22-21 0251/276/L012	150-157, 275-278
L00738		S417N311-5 LIGHT-CLOSET	439T3602 81205	1	33-22-21 0263/276/L012	155-157
L00738		60B50041-2 LIGHT-CLOSET	417T5082 81205	1	33-22-21 0383/274/L066	275-278
L00738 T		1864 LAMP-CLOSET	60B50041 08806	1	33-22-21 / /	155-157, 275-278
L00739		284T1005-3 LIGHT-FWD CARGO DOOR	284T0001 81205	1	33-31-61 D0505/141/R065	ALL
L00739 T		4627 LAMP-	284T1005 24455	1	33-31-61 / /	ALL
L00740		284T1005-3 LIGHT-FWD CARGO DOOR	284T0001 81205	1	33-31-61 D0595/141/R065	ALL
L00740 T		4627 LAMP-	284T1005 24455	1	33-31-61 / /	ALL
L00741		S232T500-1 LIGHT-F/OBS MAP	232T4501 81205	1	33-14-11 P061-00/ /	ALL
L00741 T		1308 LAMP-F/OBS MAP	S232T500 08806	1	33-14-11 / /	ALL
L00745		855308-9 LIGHT-ATTENDANT CALL,FWD CTR R	14889	1	23-42-11 0292/280/R038	050-099, 150-199
L00745 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0292/280/R038	050-099, 162-199
L00745 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 / /	150-157

EQUIPMENT LIST

D280T132

Section L00700

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00745 T		387 LAMP	417T5092 08806	1	23-42-11 0292/280/R038	050-099, 162-199
L00745 T		387 LAMP	417T5092 08806	1	23-42-11 / /	150-157
L00747		855308-9 LIGHT-LAV CALL,FWD CTR R	14889	1	33-25-11 0292/280/R038	050-099, 150-199
L00747 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	050-099, 150-199
L00747 T		387 LAMP	417T5092 08806	1	33-25-11 / /	050-099, 150-199
L00749		10-0428-31 LIGHT-FWD ATTENDANT SIGN (F1 GALLEY)	417T5129 72914	1	33-24-14 0270/284/R052	050-099, 150-199
L00749		10-0428-29 LIGHT-FWD ATTENDANT SIGN (F1 GALLEY)	417T5129 72914	1	33-24-14 0284/270/R022	275-299
L00749 T		387 LAMP	S417N503 08806	5	33-24-14 / /	ALL
L00755		318-630-1025-001 LIGHT-FWD LAV OCCUPIED	232T5011 81590	1	33-26-21 0239/276/L016	050-099, 150-199
L00755		318-630-1025-001 LIGHT-FWD LAV OCCUPIED SB RRB41024-2	232T5011 81205	1	33-26-21 0239/276/L016	275-299
L00755 T		MS25237-387 LAMP	232T5011 96906	2	33-26-21 / /	ALL
L00756		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0654+64/284/L050	150-199, 275-278
L00756 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	150-199, 275-278
L00756 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	150-199, 275-278
L00757		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0654+21/284/R050	150-199, 275-278
L00757 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	150-199, 275-278
L00757 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	150-199, 275-278

EQUIPMENT LIST

D280T132

Section L00700

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00758		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS, FWD	411T3501 81205	1	33-21-11 0654+64/284/L025	150-199, 275-299
L00758 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	150-199, 275-278
L00758 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	150-199, 275-278
L00759		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS, FWD	411T3501 81205	1	33-21-11 0654+21/284/R025	150-199, 275-299
L00759 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-11 / /	150-199, 275-299
L00759 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-11 / /	150-199, 275-299
L00760		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0705/284/L050	150-199, 280-299
L00760		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0654+84/284/L050	275-278
L00760 T		55-1239-1 LIGHT	417T5003 72914	1	33-21-11 / /	150-199
L00760 T		F40WW LIGHT	417T5003 08805	1	33-21-11 / /	275-299
L00761		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0705/284/R050	150-199, 280-299
L00761		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0654+84/284/R050	275-278
L00761 T		55-1239-1 LIGHT	417T5003 72914	1	33-21-11 / /	150-199
L00761 T		F40WW LIGHT	417T5003 08805	1	33-21-11 / /	275-299
L00762		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0705/284/L025	150-199, 280-299
L00762		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0654+84/284/L025	275-278
L00762 T		55-1239-1 LIGHT	417T5003 72914	1	33-21-11 / /	150-199

EQUIPMENT LIST

D280T132

Section L00700

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00762	T	F40WW LIGHT	417T5003 08805	1	33-21-11 / /	275-299
L00763		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0705/284/R025	150-199, 280-299
L00763		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0654+84/284/R025	275-278
L00763	T	55-1239-1 LIGHT	417T5003 72914	1	33-21-11 / /	150-199, 275-299
L00764		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0744/284/L050	150-199, 280-299
L00764	T	55-1239-1 LIGHT	417T5003 72914	1	33-21-11 / /	150-199
L00765		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0744/284/R050	150-199, 280-299
L00765	T	55-1239-1 LIGHT	417T5003 72914	1	33-21-11 / /	150-199
L00766		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0744/284/L025	150-199, 280-299
L00766	T	55-1239-1 LIGHT	417T5003 72914	1	33-21-11 / /	150-199
L00767		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, FWD	417T5038 17023	1	33-21-11 0744/284/R025	150-199, 280-299
L00767	T	55-1239-1 LIGHT	417T5003 72914	1	33-21-11 / /	150-199
L00768		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS, AFT	417T5038 17023	1	33-21-14 1196/284/L050	150-199
L00768		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, AFT	417T5038 17023	1	33-21-14 1196/284/L050	275-299
L00768	T	F40WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00768	T	1 F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	150-199
L00768	T	2 F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	150-199

EQUIPMENT LIST

D280T132

Section L00700

Page 5

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00769		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS, AFT	417T5038 17023	1	33-21-14 1196/284/R050	150-199
L00769		BV03202N-40-BV03203N-40 SOCKET-INDIRECT CEILING LTS, AFT	417T5038 17023	1	33-21-14 1196/284/R050	275-299
L00769 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00769 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	150-199
L00769 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	150-199
L00770		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS, AFT	411T3501 81205	1	33-21-14 1196/284/L025	150-199
L00770		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS, AFT	411T3501 81205	1	33-21-14 1196/284/L025	275-299
L00770 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00770 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	150-199
L00770 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	150-199
L00771		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS, AFT	411T3501 81205	1	33-21-14 1196/284/R025	150-199
L00771		S417T506-2 ASSEMBLY-INDIRECT CEILING LTS, AFT	411T3501 81205	1	33-21-14 1196/284/R025	275-299
L00771 T		F40WW LAMP	417T5003 08805	1	33-21-14 / /	275-299
L00771 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	150-199
L00771 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	150-199
L00772		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS, AFT	417T5038 17023	1	33-21-14 1197+88/284/L050	150-199, 275-299
L00772 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section L00700

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00772 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	150-199, 275-299
L00773		BV03400-40-BV03401-40 SOCKET-INDIRECT CEILING LTS, AFT	417T5038 17023	1	33-21-14 1197+88/284/R050	150-199, 275-299
L00773 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	150-199, 275-299
L00773 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	150-199, 275-299
L00774		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS, AFT	411T3501 81205	1	33-21-14 1197+88/284/L025	150-199, 275-299
L00774 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	150-199, 275-299
L00774 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	150-199, 275-299
L00775		S417T506-1 ASSEMBLY-INDIRECT CEILING LTS, AFT	411T3501 81205	1	33-21-14 1197+88/284/R025	150-199, 275-299
L00775 T	1	F72T12-WW-HO LAMP	417T5003 19816	1	33-21-14 / /	150-199, 275-299
L00775 T	2	F72T12-WW-HO LAMP	417T5003 08805	1	33-21-14 / /	150-199, 275-299
L00776		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-12 0654+66/283/R040	150-199, 275-278
L00776 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	150-199, 275-278
L00777		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-12 0686/283/R040	150-199, 280-299
L00777		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-12 0675/283/R040	275-278
L00777 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL
L00778		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-12 1197+43/283/R040	150-199, 275-299
L00778 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	ALL

EQUIPMENT LIST

D280T132

Section L00700

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00779		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-12 1197+132/283/R040	150-199, 275-299
L00779 T		1317 LAMP	411T3501 08805	1	33-51-12 / /	150-199, 275-299
L00780		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-13 0654+66/283/L040	150-199, 275-278
L00780 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	150-199, 275-278
L00781		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-13 0686/283/L040	150-199, 280-299
L00781		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-13 0675/283/L040	275-278
L00781 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00782		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-13 1197+43/283/L040	150-199, 275-299
L00782 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	ALL
L00783		S417T500-2 LIGHT-AISLE EMERGENCY	411T3501 81205	1	33-51-13 1197+132/283/L040	150-199, 275-299
L00783 T		1317 LAMP	411T3501 08805	1	33-51-13 / /	150-199, 275-299
L00786		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0654+43/266/L080	150-199, 275-278
L00786		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0654+49/266/L080	280-299
L00786 T		55-1239-1 LIGHT	417T5001 72914	1	33-21-33 / /	150-199, 275-278
L00786 T		55-1239-1 LIGHT	417T5001 72914	1	33-21-32 / /	280-299
L00787		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0654+43/266/R080	150-199, 275-278
L00787 T		55-1239-1 LIGHT	417T5001 72914	1	33-21-33 / /	150-199, 275-278

EQUIPMENT LIST

D280T132

Section L00700

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00788		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0654+87/266/L080	150-199, 275-299
L00788 T		55-1239-1 LIGHT	417T5001 72914	1	33-21-32 / /	150-199, 275-299
L00789		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-32 0654+87/266/R080	150-199, 275-299
L00789 T		55-1239-1 LIGHT	417T5001 72914	1	33-21-32 / /	150-199, 275-299
L00790		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0666/266/L080	275-299
L00790 T		5106WW LIGHT	417T5001 08805	1	33-21-33 / /	275-299
L00791		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-33 0666/266/R080	275-299
L00791 T		5106WW LIGHT	417T5001 08805	1	33-21-33 / /	275-299
L00792		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 0894/266/L080	150-199, 275-299
L00792 T		5106WW LIGHT	417T5001 08805	1	33-21-34 / /	150-199, 275-299
L00793		BV5-01258-BV5-01261 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 0894/266/R080	150-199, 275-299
L00793 T		5106WW LIGHT	417T5001 08805	1	33-21-35 / /	150-199, 275-299
L00794		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1197+22/266/L080	150-199, 275-299
L00794 T		55-1239-1 LIGHT	417T5001 72914	1	33-21-34 / /	150-199, 275-299
L00795		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1197+22/266/R080	150-199, 275-299
L00795 T		55-1239-1 LIGHT	417T5001 72914	1	33-21-35 / /	150-199, 275-299
L00796		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1197+66/266/L080	150-199, 275-299

EQUIPMENT LIST

D280T132

Section L00700

Page 9

Mar 09/2006



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00796	T	55-1239-1 LIGHT	417T5001 72914	1	33-21-34 / /	150-199, 275-299
L00797		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1197+66/266/R080	150-199, 275-299
L00797	T	55-1239-1 LIGHT	417T5001 72914	1	33-21-35 / /	150-199, 275-299
L00798		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-34 1197+110/266/L080	150-199, 275-299
L00798	T	55-1239-1 LIGHT	417T5001 72914	1	33-21-34 / /	150-199, 275-299
L00799		BV03202N-40-BV03203N-40 SOCKET-SIDEWALL	417T5031 17023	1	33-21-35 1197+110/266/R080	150-199, 275-299
L00799	T	55-1239-1 LIGHT	417T5001 72914	1	33-21-35 / /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section L00700

Page 10 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00804	1	S231T300-2306 LIGHT-TAIL SKID	233T2223 81205	1	32-71-11 P003-01/ /	150-199, 275-299
L00804	2	S231T300-1306 LIGHT-TAIL SKID	233T2223 81205	1	32-71-11 P003-01/ /	150-199, 275-299
L00804 A		MS25237-387 LAMP-28V	233T2223 96906	2	32-71-11 / /	150-199, 275-299
L00804 D		434-093-001 DIODE/FUSE ASSY	233T2223 81590	1	32-71-11 / /	150-199, 275-299
L00807		S417T508-84 SIGN-LAVATORY OCCUPIED	417T5103 81205	1	33-26-21 0527/278/0000	280-299
L00807 T		MS25237-387 LAMP-LAV OCCUPIED SIGN	417T5103 96906	8	33-26-21 / /	280-299
L00808		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0683/283/R044	150-199
L00808		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0675/280/R040	275-278
L00808 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	150-199, 275-278
L00809		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 654+109/283/L044	150-199
L00809		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 0675/280/L040	275-278
L00809 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	150-199, 275-278
L00810		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1197+132/280/R040	150-199, 275-299
L00810 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	150-199, 275-299
L00811		10685-1 SOCKET-NIGHT LIGHT	411T3501 72914	1	33-21-21 1197+132/280/L040	150-199, 275-299
L00811 T		55-1540-1 LAMP-NIGHT LT	417T5085 72914	1	33-21-21 / /	150-199, 275-299
L00812		L5105-AM LIGHT-BAY B ON	284T3501 81640	1	25-53-13 P035-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section L00800

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00812	T	MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	150-199, 275-299
L00813		L5105-AM LIGHT-BAY C ON	284T3501 81640	1	25-53-13 P035-00/ /	150-199, 275-299
L00813	T	MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	150-199, 275-299
L00814		L5105-AM LIGHT-BAY D ON	284T3501 81640	1	25-53-13 P035-00/ /	150-199, 275-299
L00814	T	MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	150-199, 275-299
L00815		L5105-AM LIGHT-BAY E ON	284T3501 81640	1	25-53-13 P035-00/ /	150-199, 275-299
L00815	T	MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	150-199, 275-299
L00816		L5105-AM LIGHT-BAY F ON	284T3501 81640	1	25-53-13 P035-00/ /	150-199, 275-299
L00816	T	MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	150-199, 275-299
L00817		L5105-AM LIGHT-BAY G ON	284T3501 81640	1	25-53-13 P035-00/ /	150-199, 275-299
L00817	T	MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	150-199, 275-299
L00818		L5105-AM LIGHT-BAY H ON	284T3501 81640	1	25-53-13 P035-00/ /	150-199, 275-299
L00818	T	MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	150-199, 275-299
L00819		L5105-AM LIGHT-BAY A ON	284T3901 81590	1	25-53-23 P039-00/ /	150-199, 275-299
L00819	T	MS25237-387 LAMP	284T3901 96906	1	25-53-23 P039-00/ /	150-199, 275-299
L00820		L5105-AM LIGHT-BAY B ON	284T3901 81590	1	25-53-23 P039-00/ /	150-199, 275-299
L00820	T	MS25237-387 LAMP	284T3901 96906	1	25-53-23 P039-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section L00800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00821		L5105-AM LIGHT-BAY C ON	284T3901 81590	1	25-53-23 P039-00/ /	150-199, 275-299
L00821 T		MS25237-387 LAMP	284T3901 96906	1	25-53-23 P039-00/ /	150-199, 275-299
L00822		L5105-AM LIGHT-BAY D ON	284T3901 81590	1	25-53-23 P039-00/ /	150-199, 275-299
L00822 T		MS25237-387 LAMP	284T3901 96906	1	25-53-23 P039-00/ /	150-199, 275-299
L00823		L5105-AM LIGHT-BAY E ON	284T3901 81590	1	25-53-23 P039-00/ /	150-199, 275-299
L00823 T		MS25237-387 LAMP	284T3901 96906	1	25-53-23 P039-00/ /	150-199, 275-299
L00824		L5105-AM LIGHT-BAY F ON	284T3901 81590	1	25-53-23 P039-00/ /	150-199, 275-299
L00824 T		MS25237-387 LAMP	284T3901 96906	1	25-53-23 P039-00/ /	150-199, 275-299
L00825		L5105-AM LIGHT-BAY G ON	284T3901 81590	1	25-53-23 P039-00/ /	150-199, 275-299
L00825 T		MS25237-387 LAMP	284T3901 96906	1	25-53-23 P039-00/ /	150-199, 275-299
L00826		L5105-AM LIGHT-BAY A ON	284T3501 81640	1	25-53-13 P035-00/ /	150-199, 275-299
L00826 T		MS25237-387 LAMP	284T3501 96906	1	25-53-13 P035-00/ /	150-199, 275-299
L00827		15-0188-7 LIGHT-FWD B CARGO COMPT	286T0000 72914	1	33-37-11 0654+77/192/R029	150-199, 275-299
L00827 T		3011 LAMP	286T0000 08806	1	33-37-11 / /	150-199, 275-299
L00828		15-0188-7 LIGHT-FWD A CARGO COMPT	286T0000 72914	1	33-37-11 0654+77/192/L029	150-199, 275-299
L00828 T		3011 LAMP	286T0000 08806	1	33-37-11 / /	150-199, 275-299
L00829		15-0188-7 LIGHT-AFT A CARGO COMPT	455T1208 72914	1	33-37-21 1197+33/194/L033	150-199

EQUIPMENT LIST

D280T132

Section L00800

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00829 T		3011 LAMP	455T1208 08806	1	33-37-21 / /	150-199
L00830		15-0188-7 LIGHT-AFT A CARGO COMPT	455T1208 72914	1	33-37-21 1197+33/194/R033	150-199
L00830 T		3011 LAMP	455T1208 08806	1	33-37-21 / /	150-199
L00831		15-0188-7 LIGHT-AFT B CARGO COMPT	455T1208 72914	1	33-37-21 1197+99/194/L033	150-199, 275-299
L00831 T		3011 LAMP	455T1208 08806	1	33-37-21 / /	150-199, 275-299
L00832		15-0188-7 LIGHT-AFT B CARGO COMPT	455T1208 72914	1	33-37-21 1197+99/194/R033	150-199, 275-299
L00832 T		3011 LAMP	455T1208 08806	1	33-37-21 / /	150-199, 275-299
L00839		BV03203N-40-BV03202N-40 SOCKET-MID DIRECT CLG LT STA 794 & 902	417T5058 17023	4	33-27-11 0425/ /	162-199
L00840		BV03203N-40-BV03202N-40 SOCKET-MID DIRECT CLG LT STA 794 & 902	417T5058 17023	4	33-27-11 0425/ /	162-199
L00864		855308-9 LIGHT-MASTER CALL,FWD R	14889	1	23-34-13 0292/280/R038	050-099
L00864		855308-9 LIGHT-MASTER CALL,FWD	14889	1	23-34-12 0292/280/R038	150-199
L00864 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199
L00864 T		387 LAMP-	417T5092 08806	1	23-34-13 / /	050-099, 150-199
L00890		S231T300-2308 LIGHT-WINDSHEAR	233T2222 81205	1	34-46-11 P001-03/ /	ALL
L00893		6004-3 LIGHT-E.L. CROSSAISLE EMER, FWD	141T5927 BFE	1	33-51-16 0349/200/R022	050-099
L00893		6004-3 LIGHT-E.L. CROSSAISLE EMER, FWD	141T5927 BFE	1	33-51-16 0349/200/R020	150-199
L00894		6004-3 LIGHT-E.L. CROSSAISLE EMER,FWD	141T5927 BFE	1	33-51-16 0349/200/0000	050-099, 150-199

EQUIPMENT LIST

D280T132

Section L00800

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00895		6004-3 LIGHT-E.L. CROSSAISLE EMER, FWD	141T5927 BFE	1	33-51-17 0349/221/L022	050-099
L00895		6004-3 LIGHT-E.L. CROSSAISLE EMER, FWD	141T5927 BFE	1	33-51-16 0349/221/L011	150-199
L00896		36262 LIGHT-EMER ESCAPE PATH MARKING	417T5172 BFE	16	33-51-16 0643/200/R	050-099, 150-199
L00897		36262 LIGHT-EMER ESCAPE PATH MARKING	417T5172 BFE	16	33-51-17 0654+58/200/L	050-099, 150-199
L00898		36262 LIGHT-EMER ESCAPE PATH MARKING	417T5172 BFE	2	33-51-17 1197+33/200/L	150-199

EQUIPMENT LIST

D280T132

Section L00800
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00900		S417N509-1-11 LIGHT-EMER ESC PATH MARK, FWD CROSSAISLE	417T5172 81205	2	33-51-16 0315/200/L014	275-278
L00900 T		OL-3071BPE-GPL LAMP	00000000 S3774	2	33-51-16 / /	275-278
L00901		36262 LIGHT-EMER ESCAPE PATH MARKING	417T5172 BFE	7	33-51-16 0401/200/R	050-099, 150-199
L00901		S417N509-1-11 LIGHT-EMER ESCAPE PATH MARKING	417T5172 81205	7	33-51-16 0401/200/0000	275-278
L00901 T		OL-3071BPE-GPL LAMP	00000000 S3774	1	33-51-16 / /	275-278
L00902		36262 LIGHT-EMER ESCAPE PATH MARKING	417T5172 BFE	10	33-51-16 1010/200/R	050-099, 150-199
L00902		S417N509-1-11 LIGHT-EMER ESCAPE PATH MARKING	417T5172 81205	12	33-51-16 0873/200/R	275-278
L00902 T		OL-3071BPE-GPL LAMP	00000000 S3774	1	33-51-16 / /	275-278
L00903		36262 LIGHT-EMER ESCAPE PATH MARKING	417T5172 BFE	11	33-51-16 1208/200/R	150-199
L00903		S417N509-1-11 LIGHT-EMER ESCAPE PATH MARKING	417T5172 81205	11	33-51-16 1010/200/R	275-278
L00903 D		81000-22607 LT-EMER ESC PATH	MULTI000 S 5006	2	33-51-16 MULTI/ /	ALL
L00903 T		OL-3071BPE-GPL LAMP	00000000 S3774	1	33-51-16 / /	275-278
L00904		36262 LIGHT-EMER ESCAPE PATH MARKING	417T5172 BFE	9	33-51-16 1384/200/R	050-099, 150-199
L00904		S417N509-1-11 LIGHT-EMER ESCAPE PATH MARKING	417T5172 81205	9	33-51-16 1406/200/R	275-278
L00904 T		OL-3071BPE-GPL LAMP	00000000 S3774	1	33-51-16 / /	275-278
L00905		36367-4 LT-EMER ESC PATH MARKING,MID CROSSAISLE	417T5172 BFE	3	33-51-16 0850/200/0000	050-099
L00905		36367-4 LT-EMER ESC PATH MARKING,MID CROSSAISLE	417T5172 BFE	3	33-51-16 0922/200/0000	150-199

EQUIPMENT LIST

D280T132

Section L00900

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00905		S417N509-1-11 LT-EMER ESC PATH MARKING,MID CROSSAISLE	417T5172 81205	3	33-51-16 0867/200/R018	275-278
L00905 T		OL-3071BPE-GPL LAMP	00000000 S3774	3	33-51-16 / /	275-278
L00908		36262 LIGHT-EMER ESCAPE PATH MARKING	417T5172 BFE	9	33-51-17 0445/200/L	050-099, 150-199
L00908		S417N509-1-11 LIGHT-EMER ESCAPE PATH MARKING	417T5172 81205	9	33-51-17 0445/200/L	275-278
L00908 T		OL-3071BPE-GPL LAMP	417T5172 S3774	1	33-51-17 / /	275-278
L00909		36262 LIGHT-EMER ESC PATH MARK	417T5172 BFE	15	33-51-17 0988/200/L	050-099, 150-199
L00909		S417N509-1-11 LIGHT-EMER ESC PATH MARK	417T5172 81205	15	33-51-17 0988/200/L	275-278
L00909 D		81000-22607 LT-EMER ESC PATH	MULTI000 S 5006	2	33-51-17 MULTI/ /	ALL
L00909 T		OL-3071BPE-GPL LAMP	417T5172 S3774	1	33-51-17 / /	275-278
L00910		36262 LIGHT-EMER ESC PATH MARK	417T5172 BFE	15	33-51-17 1362/200/L	050-099, 150-199
L00910		S417N509-1-11 LIGHT-EMER ESC PATH MARK	417T5172 81205	15	33-51-17 1362/200/L	275-278
L00910 T		OL-3071BPE-GPL LAMP	417T5172 S3774	1	33-51-17 / /	275-278
L00972		5820-63 LIGHT-EXIT IDENTIFIER SIGN	417T5163 BFE	1	33-51-14 0290/205/R085	050-099, 150-199
L00972		S417N510-1 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0291/205/R093	275-278
L00972		S417N510-2007 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0291/205/R093	280-299
L00972 T		OL-3071BPE-GPL LAMP	00000000 S3774	5	33-51-14 / /	275-299
L00973		5820-63 LIGHT-EXIT IDENTIFIER SIGN	417T5163 BFE	1	33-51-14 0857/211/R085	050-099, 150-199

EQUIPMENT LIST

D280T132

Section L00900

Page 2

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00973		S417N510-1 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0859/211/R085	275-278
L00973		S417N510-2008 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0859/211/R085	280-299
L00973 T		OL-3071BPE-GPL LAMP	00000000 S3774	5	33-51-14 / /	275-299
L00974		5820-63 LIGHT-LIGHTED EXIT IDENTIFIER	417T5163 BFE	1	33-51-14 0901/211/R085	150-199
L00974		S417N510-1 LIGHT-LIGHTED EXIT IDENTIFIER	417T5163 81205	1	33-51-14 0903/211/R085	275-278
L00974		S417N510-2008 LIGHT-LIGHTED EXIT IDENTIFIER	417T5163 81205	1	33-51-14 0903/211/R085	280-299
L00974 T		OL-3071BPE-GPL LAMP	00000000 S3774	5	33-51-14 / /	275-299
L00975		5820-63 LIGHT-EXIT IDENTIFIER SIGN	417T5163 BFE	1	33-51-14 1537/205/L085	050-099, 150-199
L00975		S417N510-1 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 1537/205/R085	275-278
L00975		S417N510-2007 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 1537/205/R085	280-299
L00975 T		OL-3071BPE-GPL LAMP	00000000 S3774	5	33-51-14 / /	275-299
L00976		5820-63 LIGHT-EXIT IDENTIFIER SIGN	417T5163 BFE	1	33-51-14 0290/205/L085	050-099, 150-199
L00976		S417N510-1 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0291/205/L093	275-278
L00976		S417N510-2007 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0291/205/L093	280-299
L00976 T		OL-3071BPE-GPL LAMP	00000000 S3774	5	33-51-14 / /	275-299
L00977		5820-63 LIGHT-EXIT IDENTIFIER SIGN	417T5163 BFE	1	33-51-14 0857/211/L085	050-099, 150-199
L00977		S417N510-1 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0859/211/L085	275-278

EQUIPMENT LIST

D280T132

Section L00900

Page 3

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00977		S417N510-2008 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0859/211/L085	280-299
L00977	T	OL-3071BPE-GPL LAMP	00000000 S3774	5	33-51-14 / /	275-299
L00978		5820-63 LIGHT-EXIT IDENTIFIER SIGN	417T5163 BFE	1	33-51-14 0901/211/L085	150-199
L00978		S417N510-1 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0901/211/L085	275-278
L00978		S417N510-2008 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 0901/211/L085	280-299
L00978	T	OL-3071BPE-GPL LAMP	00000000 S3774	5	33-51-14 / /	275-299
L00979		5820-63 LIGHT-EXIT IDENTIFIER SIGN	417T5163 BFE	1	33-51-14 1537/205/L085	050-099, 150-199
L00979		S417N510-1 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 1537/205/L085	275-278
L00979		S417N510-2007 LIGHT-EXIT IDENTIFIER SIGN	417T5163 81205	1	33-51-14 1537/205/L085	280-299
L00979	T	OL-3071BPE-GPL LAMP	00000000 S3774	5	33-51-14 / /	275-299
L00981		S417T510-4 LIGHT-E.L. CROSSAISLE EMER, MID RT	417T5181 81205	1	33-51-16 0880/200/R026	150-199
L00984		6004-3 LIGHT-E.L. CROSSAISLE EMER, AFT RT.	146T5888 BFE	1	33-51-16 1517/200/R012	050-099
L00984		6004-3 LIGHT-E.L. CROSSAISLE EMER, AFT RT.	146T5888 BFE	1	33-51-16 1484/200/R020	150-199
L00984		S417T510-3 LIGHT-E.L. CROSSAISLE EMER, AFT RT.	146T5888 81205	1	33-51-16 1542/200/R017	275-278
L00984		S417T510-3 LIGHT-E.L. CROSSAISLE EMER, AFT RT.	417T5272 81205	1	33-51-16 1542/200/R017	280-299
L00986		6004-3 LIGHT-E.L. CROSSAISLE EMER, AFT LEFT	146T5888 BFE	1	33-51-16 1517/200/L012	050-099
L00986		6004-3 LIGHT-E.L. CROSSAISLE EMER, AFT LEFT	146T5888 BFE	1	33-51-16 1484/200/L020	150-199

EQUIPMENT LIST

D280T132

Section L00900

Page 4

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L00986		S417T510-3 LIGHT-E.L. CROSSAISLE EMER, AFT LEFT	146T5888 81205	1	33-51-16 1542/200/L017	275-278
L00986		S417T510-3 LIGHT-E.L. CROSSAISLE EMER, AFT LEFT	417T5272 81205	1	33-51-16 1542/200/L017	280-299

EQUIPMENT LIST

D280T132

Section L00900

Page 5 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01027		S417T508-22 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1438/280/L036	275-278
L01027		S417T508-118 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1438/280/L036	280-299
L01027 T		MS25237-387 LAMP	417T5101 96906	8	33-26-21 / /	275-299
L01049		S417T504-146 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0807/277/L038	050-099
L01049		S417T504-244 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0807/277/L038	275-278
L01049		S417T504-24A LIGHT-EXIT SIGN	417T5105 81205	1	33-51-13 0807/277/L041	280-299
L01049 T		7335 LAMP	417T5105 S5006	12	33-51-13 / /	050-099, 275-299
L01050		S417T504-146 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0807/277/R038	050-099
L01050		S417T504-244 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0807/283/R038	275-278
L01050		S417T504-244 LIGHT-EXIT SIGN	417T5105 81205	1	33-51-12 0807/283/R041	280-299
L01050 T		7335 LAMP	417T5105 S5006	12	33-51-12 / /	050-099, 275-299
L01052	9	855308-9 LIGHT-ATT CALL,MID L (SB 33-0042)	417T5092 14889	1	23-42-11 0872/281/L038	275-276
L01052		855308-9 LIGHT-ATT CALL,MID L	417T5092 14889	1	23-42-11 0807/280/L035	277-299
L01052 C	9	855307-7 LENS-PINK (SB 33-0042)	417T5092 14889	1	23-42-11 0807/281/L038	275-276
L01052 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0807/281/L038	277-278
L01052 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0807/281/L035	280-299
L01052 T	9	387 LAMP (SB 33-0042)	417T5092 08806	1	23-42-11 0807/281/L038	275-276

EQUIPMENT LIST

D280T132

Section L01000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01052 T		387 LAMP	417T5092 08806	1	23-42-11 0807/281/L038	277-278
L01052 T		387 LAMP	417T5092 08806	1	23-42-11 0807/281/L035	280-299
L01055	9	855308-9 LIGHT-ATT CALL,MID R (SB 33-0042)	417T5092 14889	1	23-42-11 0807/281/R038	275-276
L01055		855308-9 LIGHT-ATT CALL,MID R	417T5092 14889	1	23-42-11 0807/280/R035	277-299
L01055 C	9	855307-7 LENS-PINK (SB 33-0042)	417T5092 14889	1	23-42-11 0807/281/R038	275-276
L01055 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0807/281/R038	277-278
L01055 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0807/281/R040	280-299
L01055 T	9	387 LAMP (SB 33-0042)	417T5092 08806	1	23-42-11 0807/281/R038	275-276
L01055 T		387 LAMP	417T5092 08806	1	23-42-11 0807/281/R038	277-278
L01055 T		387 LAMP	417T5092 08806	1	23-42-11 0807/281/R040	280-299
L01059		S417T502-4 SOCKET-FWD DIRECT CEILING	411T3126 81205	1	33-22-41 0432/280/R036	150-157
L01059 T		2232 LAMP	411T3126 08805	1	33-22-41 / /	150-157
L01060		S417T502-4 SOCKET-FWD DIRECT CEILING	411T3126 81205	1	33-22-41 0432/280/L036	050-099, 150-157
L01060 T		2233 LAMP	411T3126 08805	1	33-22-41 / /	050-099
L01060 T		2232 LAMP	411T3126 08805	1	33-22-41 / /	150-157
L01061		S417T502-4 SOCKET-AFT DIRECT CEILING	411T3127 81205	1	33-22-42 1502/284/0000	150-199
L01061 T		2232 LAMP	411T3127 08805	1	33-22-42 / /	150-199

EQUIPMENT LIST

D280T132

Section L01000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01062		S417T511-1 LIGHT-AFT ATTENDANT WORK,AUX	411T9502 81205	1	33-22-31 1480/270/L055	050-099, 150-199
L01062 T		2233 LAMP	411T3127 08806	1	33-22-31 1494/280/L027	050-099, 150-199
L01069		10-0428-31 LIGHT-FWD ATTENDANT SIGN	417T5129 72914	1	33-24-13 0395/280/0000	050-099, 150-199
L01069 T		10-0291-3 LAMP	10-00428 72914	5	33-24-13 / /	050-099, 150-199
L01074		S417T500-2 LIGHT-EMER CROSSAISLE	417T3055 81205	1	33-51-13 0935/280/L020	157
L01074 T		1317 LAMP	417T3055 08805	1	33-51-13 / /	157
L01075		S417T500-2 LIGHT-EMER CROSSAISLE	417T3055 81205	1	33-51-12 0935/280/R020	157
L01075 T		1317 LAMP	417T3055 08805	1	33-51-12 / /	157
L01087		855308-9 LIGHT-LAV CALL, MID L	14889	1	33-25-11 851/280/L 38	050-099, 150-154, 156, 162-199
L01087 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	150-154, 156, 162- 199
L01087 T		387 LAMP	417T5092 08806	1	33-25-11 / /	150-154, 156, 162- 199
L01088		855308-9 LIGHT-LAV CALL MID R	14889	1	33-25-11 851/280/R 38	050-099, 150-154, 156, 162-199
L01088 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	150-154, 156, 162- 199
L01088 T		387 LAMP	417T5092 08806	1	33-25-11 / /	150-154, 156, 162- 199

EQUIPMENT LIST

D280T132

Section L01000
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01105		S417T508-85 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 1008/280/0000	050-099
L01105		S417T508-85 SIGN-LAVATORY OCCUPIED	417T5101 81205	1	33-26-21 0900/280/0000	150-199
L01105 T		MS25237-387 LAMP	417T5101 96906	8	33-26-21 / /	050-099, 150-199
L01106		417T5072-17 LIGHT-FWD GALLEY	417T5025 17023	1	33-27-11 0382/280/L042	050-099, 150-199
L01106 T		F20T12-WW-RS LAMP-FWD GALLEY	417T5025 08805	1	33-27-11 / /	050-099, 150-199
L01107		417T5072-17 LIGHT-FWD GALLEY	417T5025 17023	1	33-27-11 0382/280/L038	050-099, 150-199
L01107 T		F20T12-WW-RS LAMP-FWD GALLEY	417T5025 08805	1	33-27-11 / /	050-099, 150-199
L01108		417T5072-17 LIGHT-FWD GALLEY	417T5025 17023	1	33-27-11 0382/280/R042	050-099, 150-199
L01108 T		F20T12-WW-RS LAMP-FWD GALLEY	417T5025 08805	1	33-27-11 / /	050-099, 150-199
L01109		417T5072-17 LIGHT-FWD GALLEY	417T5025 17023	1	33-27-11 0382/280/R038	050-099, 150-199
L01109 T		F20T12-WW-RS LAMP-FWD GALLEY	417T5025 08805	1	33-27-11 / /	050-099, 150-199
L01110		S231T300-2153 LIGHT-ANNUNCIATOR, BLANK	233T2202 81205	1	33-16-15 P003-00/ /	050-099
L01114		855308-9 LIGHT-ATTENDANT CALL,FWD RIGHT	00000000 14889	1	23-42-11 0292/280/R038	150-157
L01114 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 / /	150-157
L01114 T		387 LAMP	417T5092 08806	1	23-42-11 / /	150-157
L01115		855308-9 LIGHT-ATTEND CALL FWD AFT L	14889	1	23-42-11 631/280/L 38	050-099, 150-199
L01115 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0631/280/L038	050-099, 162-199

EQUIPMENT LIST

D280T132

Section L01100

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01115 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 / /	150-157
L01115 T		387 LAMP	417T5092 08806	1	23-42-11 0631/280/L038	050-099, 162-199
L01115 T		387 LAMP	417T5092 08806	1	23-42-11 / /	150-157
L01116		855308-9 LIGHT-ATTEND CALL FWD AFT R	14889	1	23-42-11 631/280/R 38	050-099, 150-199
L01116 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 0631/280/R038	050-099, 162-199
L01116 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 / /	150-157
L01116 T		387 LAMP	417T5092 08806	1	23-42-11 0631/280/R038	050-099, 162-199
L01116 T		387 LAMP	417T5092 08806	1	23-42-11 / /	150-157
L01118		855308-9 LIGHT-ATTEND CALL AFT FWD L	14889	1	23-42-11 1196/280/L 38	050-099
L01118		855308-9 LIGHT-ATTEND CALL AFT FWD L	14889	1	23-42-11 1197+44/280/L 38	150-199
L01118 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1196/280/L038	050-099
L01118 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 / /	150-157
L01118 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1197+44/280/L038	162-199
L01118 T		387 LAMP	411T5092 08806	1	23-42-11 1196/280/L038	050-099
L01118 T		387 LAMP	411T5092 08806	1	23-42-11 / /	150-157
L01118 T		387 LAMP	411T5092 08806	1	23-42-11 1197+44/280/L038	162-199
L01119		855308-9 LIGHT-ATTEND CALL AFT FWD R	14889	1	23-42-11 1196/280/R 38	050-099

EQUIPMENT LIST

D280T132

Section L01100

Page 2

Jan 21/2005



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01119		855308-9 LIGHT-ATTEND CALL AFT FWD R	14889	1	23-42-11 1197+44/280/R 38	150-199
L01119 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1196/280/R038	050-099
L01119 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 / /	150-157
L01119 C		855307-7 LENS-PINK	417T5092 14889	1	23-42-11 1197+44/280/R038	162-199
L01119 T		387 LAMP	417T5092 08806	1	23-42-11 1196/280/R038	050-099
L01119 T		387 LAMP	417T5092 08806	1	23-42-11 / /	150-157
L01119 T		387 LAMP	417T5092 08806	1	23-42-11 1197+44/280/R038	162-199
L01122		S417T504-95 LT-EXIT SIGN	417T5105 81205	1	33-51-12 0324/273/0000	150-157
L01122 T		7335 LAMP	411T5105 S5006	8	33-51-12 / /	150-157
L01123		6004-3 LT-AISLE	417T5172 BFE	1	33-51-16 0358/201/R044	050-099, 150-199
L01124		6004-1 LT-AISLE	417T5172 BFE	1	33-51-16 0393/201/R044	050-099, 150-199
L01125		6004-3 LT-EMERGENCY ESCAPE PATH MARKING	417T5172 BFE	1	33-51-16 0433/201/R044	150-199
L01126		6004-3 LT-AISLE	417T5172 BFE	1	33-51-17 0358/201/L044	050-099, 150-199
L01127		6004-1 LT-AISLE	417T5172 BFE	1	33-51-17 0396/201/L044	050-099, 150-199
L01128		6004-3 LT-AISLE	417T5172 BFE	1	33-51-17 0433/201/L044	150-199
L01129		6004-3 LT-AISLE TO EXIT MARKER	417T5172 BFE	1	33-51-16 0340/201/R065	050-099, 150-199
L01130		6004-3 LT-AISLE TO EXIT MARKER	417T5172 BFE	1	33-51-17 0340/201/L065	050-099, 150-199

EQUIPMENT LIST

D280T132

Section L01100

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01131		S417T511-1 LT-ATTND WORK, FWD RIGHT	417T9502 81205	1	33-22-31 0348/275/R052	050-099, 150-199
L01131 T		1308 LAMP	417T9502 08806	1	33-22-31 / /	050-099, 150-199
L01132		S417T504-113 LT-EXIT SIGN	417T5105 81205	1	33-51-13 0336/280/0000	150-157
L01132 T		7335 LAMP	411T5105 S5006	12	33-51-13 / /	150-157
L01133		855308-9 LIGHT-MASTER CALL MID T/C L	14889	1	23-34-12 1196/280/L 38	050-099
L01133		855308-9 LIGHT-MASTER CALL MID T/C L	14889	1	23-34-12 1197+44/280/L 38	150-199
L01133 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199
L01133 T		387 LAMP	417T5092 08806	1	23-34-13 / /	050-099, 150-199
L01134		855308-9 LIGHT-MASTER CALL MID T/C R	14889	1	23-34-13 1196/280/R 38	050-099
L01134		855308-9 LIGHT-MASTER CALL MID T/C R	14889	1	23-34-13 1197+44/280/R 38	150-199
L01134 C		855307-3 LENS-BLUE	417T5092 14889	1	23-34-13 / /	050-099, 150-199
L01134 T		387 LAMP	417T5092 08806	1	23-34-13 / /	050-099, 150-199
L01135		S417T502-4 LT-SOCKET AFT DIRECT CEILING	411T3127 81205	1	33-22-42 1448/280/L040	050-099, 150-199
L01135 T		2233 LAMP	411T3127 08805	1	33-22-42 / /	050-099, 150-199
L01136		S417T502-4 LT-SOCKET AFT DIRECT CEILING	411T3127 81205	1	33-22-42 1448/280/R040	050-099, 150-199
L01136 T		2233 LAMP	411T3127 08805	1	33-22-42 / /	050-099, 150-199
L01137		10-0428-31 LT-PURSER SIGN	417T5129 72914	1	33-24-12 0447/242/L060	050-099, 150-199

EQUIPMENT LIST

D280T132

Section L01100

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01137 T		10-0291-3 LAMP	10-00428 72914	5	33-24-12 / /	050-099, 150-199
L01138		S417T502-8 LT-GALLEY WORK,AFT	411T3127 81205	1	33-27-11 1549/280/R014	150-199
L01138 T		2233 LAMP	411T3127 08806	1	33-27-11 / /	150-199
L01139		S417T502-8 LT-GALLEY WORK,AFT	411T3127 81205	1	33-27-11 1549/280/R006	150-199
L01139 T		2233 LAMP	411T3127 08806	1	33-27-11 / /	150-199
L01140		S417T502-8 LT-GALLEY WORK,AFT	411T3127 81205	1	33-27-11 1549/280/L014	150-199
L01140 T		2233 LAMP	411T3127 08806	1	33-27-11 / /	150-199
L01141		S417T502-8 LT-GALLEY WORK,AFT	411T3127 81205	1	33-27-11 1549/280/L006	150-199
L01141 T		2233 LAMP	411T3127 08806	1	33-27-11 / /	150-199
L01144		60-4271-3-60-4271-4 LT-PURSER WORK	417T5082 72914	1	33-22-32 0447/240/L055	150-199
L01144 T		F013-31K-BCAC LAMP	417T5082 08805	1	33-22-32 0447/240/L055	150-199
L01156		6004-3 LT-AISLE TO EXIT MARKER	417T5172 BFE	1	33-51-16 1487/201/R065	050-099, 150-199
L01157		6004-3 LT-AISLE TO EXIT MARKER	417T5172 BFE	1	33-51-17 1487/201/L065	050-099, 150-199
L01160	9	855308-9 LT-LAV CALL,MID-AFT R (SB 33-0042)	417T5092 14889	1	33-25-11 0888/280/R038	275-276
L01160		855308-9 LIGHT-LAV CALL, MID-AFT R	14889	1	33-25-11 1196/280/R 38	050-099, 150-199
L01160		855308-9 LIGHT-ATTENDENT CALL	14889	1	33-25-11 0888/280/R 38	275-276
L01160		855308-9 LT-LAV CALL,MID-AFT R	417T5105 14889	1	33-25-11 0860/275/R038	275-278

EQUIPMENT LIST

D280T132

Section L01100

Page 5

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01160		855308-9 LIGHT-LAV CALL	14889	1	33-25-11 0888/280/R 38	277-299
L01160 C	9	885307-8 LENS-AMBER (SB 33-0042)	417T5092 14889	1	33-25-11 / /	275-276
L01160 C		885307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	ALL
L01160 T	9	387 LAMP (SB 33-0042)	417T5092 08806	1	33-25-11 / /	275-276
L01160 T		387 LAMP	417T5092 08806	1	33-25-11 / /	ALL
L01161	9	855308-9 LT-LAV CALL,MID-AFT L (SB 33-0042)	417T5092 14889	1	33-25-11 0888/280/L038	275-276
L01161		855308-9 LIGHT-LAV CALL, MID-AFT L	14889	1	33-25-11 1196/280/L038	050-099
L01161		855308-9 LIGHT-LAV CALL, MID-AFT L	14889	1	33-25-11 1197+44/280/L 38	150-199
L01161		855308-9 LIGHT-ATTENDENT CALL	14889	1	33-25-11 0888/280/L 38	275-276
L01161		855308-9 LT-LAV CALL,MID-AFT L	417T5105 14889	1	33-25-11 0860/275/L038	275-278
L01161		855308-9 LIGHT-LAV CALL	14889	1	33-25-11 0888/280/L 38	277-299
L01161 C	9	885307-8 LENS-AMBER (SB 33-0042)	417T5092 14889	1	33-25-11 / /	275-276
L01161 C		885307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	ALL
L01161 T	9	387 LAMP (SB 33-0042)	417T5092 08806	1	33-25-11 / /	275-276
L01161 T		387 LAMP	417T5092 08806	1	33-25-11 / /	ALL
L01165		S233T100-569 LIGHTPLATE-ALTERNATE STAB TRIM	253T0599 81205	1	33-13-18 P010-00/ /	050-099, 155-199, 275-299
L01175		10-0428-29 LT-ATTENDANT SIGN	417T5129 72914	1	33-24-12 0348/260/L055	275-278

EQUIPMENT LIST

D280T132

Section L01100

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01175	T	387 LAMP	S417N503 08806	5	33-24-12 / /	275-278
L01176		BV5-01258-BV5-01261 LT-SOCKET DIRECT CEILING	417T5058 17023	1	33-27-11 1524/280/L008	275-299
L01176	T	5106WW LAMP	417T5058 08805	1	33-27-11 / /	275-299
L01177		BV5-01258-BV5-01261 LT-SOCKET DIRECT CEILING	417T5058 17023	1	33-27-11 1524/280/R008	275-299
L01177	T	5106WW LAMP	417T5058 08805	1	33-27-11 / /	275-299
L01178		BV03203N-40-BV03202N-40 LT-SOCKET DIRECT CEILING	417T5058 17023	1	33-27-11 1526/280/0000	275-299
L01178	T	F15T12WW LAMP	417T5058 08805	1	33-27-11 / /	275-299
L01179		BV03203N-40-BV03202N-40 LT-SOCKET DIRECT CEILING	417T5058 17023	1	33-27-11 1522/280/0000	275-299
L01179	T	F15T12WW LAMP	417T5058 08805	1	33-27-11 / /	275-299
L01180		106402-001 LT-NIGHT	417T5085 17744	1	33-21-21 0460/210/R090	050-099, 162-199
L01180	T	1864 LAMP	417T5085 08806	1	33-21-21 / /	050-099, 162-199
L01181		106402-001 LT-NIGHT	417T5085 17744	1	33-21-21 1442/210/R090	050-099, 162-199
L01181	T	1864 LAMP	417T5085 08806	1	33-21-21 / /	050-099, 162-199
L01182		106402-001 LT-NIGHT	417T5085 17744	1	33-21-21 1442/210/L090	050-099, 162-199
L01182	T	1864 LAMP	417T5085 08806	1	33-21-21 1442/210/L090	050-099, 162-199
L01183		S417T502-8 LT-CREW REST UPPER BUNK RDG	00000000 81205	1	23-34-15 0252/272/R015	050-099
L01183	T	2233 LAMP	00000000 81205	1	23-34-15 / /	050-099

EQUIPMENT LIST

D280T132

Section L01100

Page 7

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01184		S417T502-8 LT-CREW REST LOWER BUNK RDG	00000000 81205	1	23-34-15 0252/242/R015	050-099
L01184 T		2233 LAMP	00000000 81205	1	23-34-15 / /	050-099
L01187		0106402-001 LT-STEP, FLT DK CREW REST	413T3285 TBD	1	33-22-33 0258/232/L012	050-099, 162-199
L01187 T		1864 LAMP-STEP LIGHT	413T3285 08806	1	33-22-33 / /	050-099, 162-199
L01188		S417T502-4 LT-GENERAL ILLUM, FLT DK CREW REST	413T3285 81205	1	33-22-33 0258/274/L012	050-099, 162-199
L01188 T		1327 LAMP-GEN ILLUM LT	413T3285 08806	1	33-22-33 / /	050-099, 162-199
L01189		10-0428-31 LT-FWD ATTEND SIGN CREW REST AREA	417T5129 72914	1	33-24-13 0261/241/R015	050-099, 162-199
L01189 T		10-0291-3 LAMP	10-0428 72914	5	33-24-13 / /	050-099, 162-199
L01190		10-0428-31 LT-FWD ATTEND SIGN CREW REST AREA	417T5129 72914	1	33-24-13 0261/262/R019	050-099, 162-199
L01190 T		10-0291-3 LAMP	10-0428 72914	5	33-24-13 / /	050-099, 162-199
L01191		4100-1 SIGN-LAV OCC CREW REST AREA	417T5101 81205	1	33-26-21 0255/235/L009	050-099, 162-199
L01191 T		MS25237-387 LAMP	00000000 96906	2	33-26-21 / /	050-099, 162-199
L01192		4100-1 SIGN-LAV OCC CREW REST AREA	417T5101 81205	1	33-26-21 0255/263/L009	050-099, 162-199
L01192 T		MS25237-387 LAMP	00000000 96906	2	33-26-21 / /	050-099, 162-199
L01193		S417T500-2 LT-CREW REST AREA EMERGENCY	417T3027 81205	1	33-51-13 0258/223/L012	050-099, 162-199
L01195		855308-9 LT-LAV CALL, MID-AFT FWD L	417T5092 14889	1	33-25-11 0932/280/L038	050-099
L01195 C		855307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	050-099

EQUIPMENT LIST

D280T132

Section L01100

Page 8

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01195 T		387 LAMP	417T5092 08805	1	33-25-11 / /	050-099
L01196		855308-9 LT-LAV CALL, MID AFT FWD R	417T5092 14889	1	33-25-11 0880/280/R001	050-099
L01196 T		387 LAMP	417T5092 08805	1	33-25-11 / /	050-099
L01197		S417T502-8 LT-GALLEY WORK FWD	411T3127 81205	1	33-27-11 0422/280/R038	050-099
L01197 T		2233 LAMP	411T3127 08806	1	33-27-11 / /	050-099
L01198		S417T502-8 LT-GALLEY WORK FWD	411T3127 81205	1	33-27-11 0422/280/R042	050-099
L01198 T		2233 LAMP	411T3127 08806	1	33-27-11 / /	050-099
L01199		S417T504-72 LT-EXIT SIGN	417T5015 81205	1	33-51-12 1565/280/0000	050-099
L01199 T		7335 LAMP	417T5105 S5006	12	33-51-12 / /	050-099

EQUIPMENT LIST

D280T132

Section L01100

Page 9 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01204	9	5-86547-599 LT-FWD TANK SENSOR FOUL (SB 38-0031)	417T1711 29238	1	38-32-11 1572/144/0000	050
L01204	9	5-86547-599 LT-FWD TANK SENSOR FOUL (SB 38-0026)	417T1711 76854	1	38-32-11 1572/144/0000	150-154
L01204	9	5-86547-599 LT-FWD TANK SENSOR FOUL (SB 38-0035)	417T1711 29238	1	38-32-11 1572/144/0000	275-276
L01204		5-86547-599 LT-FWD TANK SENSOR FOUL	417T1711 29238	1	38-32-11 1572/144/0000	051-099, 155-199, 277-299
L01204 T	9	387 LAMP (SB 38-0026)	417T1711 08806	1	38-32-11 / /	050, 150-154, 275- 276
L01204 T		387 LAMP	417T1711 08806	1	38-32-11 / /	051-099, 155-199, 277-299
L01205	9	5-86547-599 LT-AFT TANK SENSOR FOUL (SB 38-0031)	417T1711 29238	1	38-32-11 1572/144/0000	050
L01205	9	5-86547-599 LT-AFT TANK SENSOR FOUL (SB 38-0026)	417T1711 76854	1	38-32-11 1572/144/0000	150-154
L01205	9	5-86547-599 LT-AFT TANK SENSOR FOUL (SB 38-0035)	417T1711 29238	1	38-32-11 1572/144/0000	275-276
L01205		5-86547-599 LT-AFT TANK SENSOR FOUL	417T1711 29238	1	38-32-11 1572/144/0000	051-099, 155-199, 277-299
L01205 T	9	387 LAMP (SB 38-0026)	417T1711 08806	1	38-32-11 / /	050, 150-154, 275- 276
L01205 T		387 LAMP	417T1711 08806	1	38-32-11 / /	051-099, 155-199, 277-299
L01210		P90-90720-1 LIGHT-CREW SMOKE WARNING,FWD RIGHT	411T3126 S5065	1	26-13-12 0445/280/R043	164-199
L01211		P90-90720-1 LIGHT-CREW SMOKE WARNING,CTR	411T3127 S5065	1	26-13-12 0336/280/0000	164-199
L01212		P90-90720-1 LIGHT-CREW SMOKE WARNING,AFT RIGHT	411T3127 S5065	1	26-13-12 1446/280/R043	164-199
L01213		P90-90720-1 LIGHT-CREW SMOKE WARNING, AFT LEFT	411T3127 S5065	1	26-13-12 1446/280/L043	164-199
L01229	9	855308-9 LIGHT-LAV CALL,MID CTR L (SB 33-0042)	417T5105 14889	1	33-25-11 0807/280/L038	275-276

EQUIPMENT LIST

D280T132

Section L01200

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L01229		855308-9 LIGHT-LAV CALL,MID CTR L	417T5105 14889	1	33-25-11 0851/280/L038	155, 157
L01229		855308-9 LIGHT-LAV CALL,MID CTR L	417T5105 14889	1	33-25-11 0807/280/L038	277-299
L01229 C	9	885307-8 LENS-AMBER (SB 33-0042)	417T5092 14889	1	33-25-11 / /	275-276
L01229 C		885307-8 LENS-AMBER	417T5092 14889	1	33-25-11 / /	155, 157, 277-299
L01229 T	9	387 LAMP (SB 33-0042)	418T5092 08806	1	33-25-11 / /	275-276
L01229 T		387 LAMP	418T5092 08806	1	33-25-11 / /	155, 157, 277-299
L01230	9	855308-9 LIGHT-LAV CALL,MID CTR R (SB 33-0042)	417T5105 14889	1	33-25-11 0807/280/R038	275-276
L01230		855308-9 LIGHT-LAV CALL,MID CTR R	417T5105 14889	1	33-25-11 0851/280/R038	155, 157
L01230		855308-9 LIGHT-LAV CALL,MID CTR R	417T5105 14889	1	33-25-11 0807/280/R038	277-299
L01230 C	9	885307-8 LENS-AMBER (SB 33-0042)	417T5092 14889	1	33-25-11 / /	275-276
L01230 C		885307-5 LENS-AMBER	417T5092 14889	1	33-25-11 / /	155, 157, 277-299
L01230 T	9	387 LAMP (SB 33-0042)	417T5092 08806	1	33-25-11 / /	275-276
L01230 T		387 LAMP	417T5092 08806	1	33-25-11 / /	155, 157, 277-278
L01261	1	33-32683-6P1 LIGHT-HOT BUS WARN,115V GND SVCE	284T8703 87034	1	24-51-13 P087-00/ /	278-299
L01261	2	33-32683-6P4 LIGHT-HOT BUS WARN,115V GND SVCE	284T8703 87034	1	24-51-13 P087-00/ /	278-299

EQUIPMENT LIST

D280T132

Section L01200

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L03405 T		387 LAMP	417T6600 08806	1	23-42-11 1552/280/R007	ALL

EQUIPMENT LIST

D280T132

Section L03400
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
L09001	9	60B50041-2 LIGHT-CLOSET (MTO330342B)	CUSTOMER 81205	1	33-22-21 0448/260/L065	150, 153-199
L09002	9	60B50041-2 LIGHT-CLOSET (MTO330342B)	CUSTOMER 81205	1	33-22-21 0435/260/R065	150, 153-157
L09003	9	60B50041-2 LIGHT-CLOSET (MTO330342B)	CUSTOMER 81205	1	33-22-21 0450/260/R065	150, 153-157
L09004	9	60B50041-2 LIGHT-CLOSET (MTO330348)	CUSTOMER 81205	1	33-22-21 0654+120/260/R015	162-199
L09005	9	60B50041-2 LIGHT-CLOSET (MTO330348)	CUSTOMER 81205	1	33-22-21 0654+120/260/L015	162-199
L09006	9	60B50041-2 LIGHT-CLOSET (MTO330348)	CUSTOMER 81205	1	33-22-21 0654+120/260/L015	162-199
L09007	9	CUSTOMER EXIT SIGN LIGHT (PR 00113)	CUSTOMER CUST	1	33-51-14 1510/270/0	150, 152-199
L09009	9	CUSTOMER LIGHTPLATE-CAPT EGPWS SW PNL(MTO-340961)	CUSTOMER CUST	1	33-13-11 P001-01/ /	150, 152-199, 275-299
L09010	9	CUSTOMER LIGHTPLATE-F/O EGPWS SW PNL (MTO-340961)	CUSTOMER CUST	1	33-13-13 P003-01/ /	150, 152-199, 275-299

EQUIPMENT LIST

D280T132

Section L09000

Page 1 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00001	1	233T3232-12 CONT PNL-APU (SEE YAS)	233T3100 81205	1	49-61-11 P005-00/ /	ALL
M00001	2	233T3232-11 CONT PNL-APU (SEE YAS)	233T3100 81205	1	49-61-11 P005-00/ /	ALL
M00001 T		S233T100-6025 LIGHTPLATE-CONT PNL,APU	233T3232 81205	1	33-13-16 P005-00/ /	ALL
M00004		233T4219-1 CONT PNL-CTN+WRN,MSTR	233T4100 81205	1	31-51-33 P004-00/ /	050-099
M00010	1	233T3234-19 PNL-HYD SYS CONTROL (SEE YCY)	233T3100 81205	1	29-11-11 P005-00/ /	ALL
M00010	2	233T3234-14 PNL-HYD SYS CONTROL (SEE YCY)	233T3100 81205	1	29-11-11 P005-00/ /	ALL
M00010	3	233T3234-12 PNL-HYD SYS CONTROL (SEE YCY)	233T3100 81205	1	29-11-11 P005-00/ /	ALL
M00010	4	233T3234-10 PNL-HYD SYS CONTROL (SEE YCY)	233T3100 81205	1	29-11-11 P005-00/ /	ALL
M00010 T		S233T100-1066 LIGHTPLATE-HYD SYS CONTROL	233T3234 81205	1	33-13-16 P005-00/ /	ALL
M00013		S210T160-62 SELECTOR PNL-CAB. PRESS.	233T3100 81205	1	21-31-11 P005-00/ /	ALL
M00014		233T3236-18 CONT PNL-TEMP (SEE YBF)	233T3100 81205	1	21-61-11 P005-00/ /	050-099
M00014		233T3236-16 CONT PNL-TEMP (SEE YBF)	233T3100 81205	1	21-61-11 P005-00/ /	150-199, 275-276
M00014		233T3236-87 CONT PNL-TEMP (SEE YBF)	233T3100 81205	1	21-61-11 P005-00/ /	277-299
M00014 T		S233T100-1056 LIGHTPLATE-TEMP CONTROL PNL	233T3236 81205	1	33-13-16 P005-00/ /	ALL
M00015		233T3237-13 PNL-BLEED AIR SUPPLY (SEE YCZ)	233T3100 81205	1	36-11-11 P005-00/ /	050-099, 150-199, 275-276
M00015		233T3237-27 PNL-BLEED AIR SUPPLY (SEE YCZ)	233T3100 81205	1	36-11-11 P005-00/ /	277-299
M00015 T		S233T100-1051 LIGHTPLATE-PNL,BLEED AIR SUPPLY	233T3237 81205	1	33-13-16 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M00000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00017		233T3236-306 CONT PNL-EQUIPMENT COOLING (SEE YDA)	233T3100 81205	1	21-58-11 P005-00/ /	ALL
M00017 T		S233T100-1062 LIGHTPLATE-CONT PNL,EQUIPMENT COOLING	233T3238 81205	1	33-13-16 P005-00/ /	ALL
M00019		S231N210-14 PNL-CABIN PRESSURE GAUGES	233T3100 81205	1	21-33-21 P005-00/ /	ALL
M00029		233T3239-10 CONT PNL-CARGO HEAT (SEE YDB)	233T3100 81205	1	21-43-11 P005-00/ /	050-099, 150-199, 275-276
M00029		233T3239-14 CONT PNL-CARGO HEAT (SEE YDB)	233T3100 81205	1	21-43-11 P005-00/ /	277-299
M00029 T		S233T100-1069 LIGHTPLATE-CONT PNL,CARGO HEAT	233T3239 81205	1	33-13-16 P005-00/ /	ALL
M00032		233T4246-4 CONT PNL-SQUIB TEST (SEE YA3)	233T4100 81205	1	26-21-11 P061-00/ /	ALL
M00033		233N7508-14 PNL-FLIGHT RECORDER CONTROL (SEE YDS)	233T4100 81205	1	31-31-11 P061-00/ /	ALL
M00040		233T3203-1 TEST PNL-STALL/CONFIG (SEE YA2)	233T3100 81205	1	27-32-11 P005-00/ /	050-099
M00043		233T3210-26 CONT PNL-EMER LTS (SEE YB1)	233T3100 81205	1	33-51-11 P005-00/ /	ALL
M00043 T		S233T100-1077 LIGHTPLATE-CONT PNL EMER LTS	233T3210 81205	1	33-13-16 P005-00/ /	ALL
M00049	9	233T3244-23 CONT PNL-ENG IGN+START (SEE YAY)	SB730044 81205	1	74-31-11 P005-00/ /	ALL
M00049	1	233T3244-9 CONT PNL-ENG IGN+START (SB 73-0044)	233T3100 81205	1	74-31-11 P005-00/ /	275-299
M00049	2	233T3244-6 CONT PNL-ENG IGN+START (SEE YAY)	233T3100 81205	1	74-31-11 P005-00/ /	275-299
M00049	3	233T3244-1 CONT PNL-ENG IGN+START (SEE YAY)	233T3100 81205	1	74-31-11 P005-00/ /	275-299
M00049 T		S233T100-1078 LIGHTPLATE-CONT PNL,ENG IGN & START	233T3244 81205	1	33-13-16 P005-00/ /	ALL
M00050		980-6109-032 CONT PNL-REC,VOICE	233T3100 97896	1	23-71-11 P005-00/ /	050-099, 275-299

EQUIPMENT LIST

D280T132

Section M00000

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00050		980-6109-030 CONT PNL-REC,VOICE	233T3100 97896	1	23-71-11 P005-00/ /	150-199
M00051		285T0024-43 PNL-PILOTS CALL	233T3100 81205	1	23-42-11 P005-00/ /	050-099, 162-199
M00051		285T0024-27 PNL-PILOTS CALL	233T3100 81205	1	23-42-11 P005-00/ /	150-157, 275-299
M00051 T		S233T100-1043 LIGHTPLATE-PNL,PILOTS CALL	285T0024 81205	1	33-13-16 P005-00/ /	150-199, 275-299
M00052		233T3216-10 CONT PNL-SIGNS,PASS. (SEE YB2)	233T3100 81205	1	33-24-11 P005-00/ /	050-099
M00052		23373216-1 CONT PNL-SIGNS,PASS. (SEE YB2)	233T3100 81205	1	33-24-11 P005-00/ /	150-199, 275-299
M00052 T		S233T100-1018 LIGHTPLATE-PNL,SIGNS,PASS.	233T3216 81205	1	33-13-16 P005-00/ /	ALL
M00056		233T3217 MODULE-ANTI-COLL & LDG LT CONT (SEE YCT)	233T3100 81205	1	33-41-11 P005-00/ /	ALL
M00056 T		S233T100-6030 LIGHTPLATE-ANTI-COLL & LDG LT CONT	233T3217 81205	1	33-13-16 P005-00/ /	ALL
M00059	1	S242T101-203 PNL-INERTIAL REFERENCE MODE	233T3103 81205	1	34-21-11 P005-00/ /	ALL
M00059	2	S242T101-202 PNL-INERTIAL REFERENCE MODE	233T3100 81205	1	34-21-11 P005-00/ /	ALL
M00061		G-6031A CONT PNL-EVAC,EMER	233T3100 99837	1	25-63-11 P005-00/ /	ALL
M00063	1	S417T402-4 MODULE-OXYGEN-READING LIGHT,OUTBOARD	417T3052 81205	75	35-21-12 MULTI/ /	ALL
M00063	2	S417T402-3 MODULE-OXYGEN-READING LIGHT,OUTBOARD	417T3052 81205	75	35-21-12 MULTI/ /	ALL
M00064	1	S417T402-4 MODULE-OXYGEN-READING LIGHT,INBOARD	417T3051 81205	32	35-21-14 MULTI/ /	ALL
M00064	2	S417T402-3 MODULE-OXYGEN-READING LIGHT,INBOARD	417T3051 81205	32	35-21-14 MULTI/ /	ALL
M00065	1	S417T402-4 MODULE-OXYGEN,BIN	417T3053 81205	4	35-21-14 MULTI/ /	ALL

EQUIPMENT LIST

D280T132

Section M00000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00065	2	S417T402-3 MODULE-OXYGEN,BIN	417T3053 81205	4	35-21-14 MULTI/ /	ALL
M00070	9	5032-1-5 SEL PNL-AUDIO,CAPTAIN (SB 23-0052)	233T6100 30242	1	23-51-11 P008-00/ /	050-099, 150-154, 162-164, 275-276
M00070		5032-1-5 SEL PNL-AUDIO,CAPTAIN	233T6100 30242	1	23-51-11 P008-00/ /	155-157, 165-199, 277-299
M00070 T		S233T100-530 LIGHTPLATE-SELECT PNL,AUDIO CAPTAIN	285T0022 81205	3	33-13-18 P008-00/ /	050-099, 275-299
M00070 T		S233T100-TBD LIGHTPLATE-SELECT PNL,AUDIO CAPTAIN	285T0022 81205	4	33-13-18 P008-00/ /	150-199
M00071	9	5032-1-5 SEL PNL-AUDIO,FIRST OFFICER (SB 23-0052)	233T6100 30242	1	23-51-21 P008-00/ /	050-099, 153-154, 162-164, 275-276
M00071	9	5032-1-5 SEL PNL-AUDIO,F/O OFFICER (SB 23-0052)	233T6100 30242	1	23-51-21 P008-00/ /	150-152
M00071		5032-1-5 SEL PNL-AUDIO,FIRST OFFICER	233T6100 30242	1	23-51-21 P008-00/ /	155-157, 165-199, 277-299
M00071 T		S233T100-530 LIGHTPLATE-SELECT PNL,AUDIO F/O	285T0022 81205	3	33-13-18 P008-00/ /	050-099, 275-299
M00071 T		S233T100-TBD LIGHTPLATE-SELECT PNL,AUDIO F/O	285T0022 81205	4	33-13-18 P008-00/ /	150-199
M00073		253T5900-52 CONT PNL-FUEL (SEE YAZ)	253T5100 81205	1	76-11-11 P010-00/ /	050-099, 150-155, 162-165, 275-276
M00073		253T5900-52 CONT PNL-FUEL (SEE YAZ)	253T5010 81205	1	76-11-11 P010-00/ /	156-157, 166-199, 277-299
M00074		233T6201-21 CONT PNL-AILERON+RUDDER TRIM (SEE YAR)	233T6100 81205	1	27-11-11 P008-00/ /	ALL
M00074 T		S233T100-528 LIGHTPLATE-CONT,AILERON & RUDDER	233T6201 81205	1	33-13-18 P008-00/ /	ALL
M00075		2041220-0402 CONT PNL-WXR	233T6100 27914	1	34-43-12 P008-00/ /	ALL
M00076		S242T102-130 CONT DISP UNIT-FLT MNG COMPUTER,L	233T6100 81205	1	34-61-11 P009-00/ /	ALL
M00077		S242T102-130 CONT DISP UNIT-FLT MNG COMPUTER,R	233T6100 81205	1	34-61-21 P009-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M00000

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00078	9	G7400-11 CONTROL PANEL-VHF COMM, LEFT	233T6100 99837	1	23-12-11 P008-00/ /	150, 152-199, 275-299
M00078		G7400-03 CONT PNL-VHF COMM,LEFT	233T6100 99837	1	23-12-11 P008-00/ /	050-099
M00078		G6317-03 CONT PNL-VHF COMM,LEFT	233T6100 99837	1	23-12-11 P008-00/ /	151
M00079	9	G7400-11 CONTROL PANEL-VHF COMM, RIGHT	233T6100 99837	1	23-12-21 P008-00/ /	150, 152-199, 275-299
M00079		G7400-03 CONT PNL-VHF COMM,RIGHT	233T6100 99837	1	23-12-21 P008-00/ /	050-099
M00079		G6317-03 CONT PNL-VHF COMM,RIGHT	233T6100 99837	1	23-12-21 P008-00/ /	151
M00080	9	G7400-11 CONTROL PANEL-VHF COMM, CNTR	233T6100 99837	1	23-12-31 P008-00/ /	150, 152-199, 275-299
M00080		G-6317-03 CONT PNL-VHF COMM,CENTER	233T6100 99837	1	23-12-31 P008-00/ /	151
M00081	9	G6992-26 CONT PNL-ATC,DUAL (SEE YEK) (MTO 340652)	CUSTOMER 99837	1	34-53-11 P008-00/ /	050-099, 155-199, 275-299
M00081	9	G6992-26 CONT PNL-ATC,DUAL (SEE YEK) (MTO 340652)	233T6100 99837	1	34-53-11 P008-00/ /	150-154
M00081 T		S233T100-534 LIGHTPLATE-CONT PNL,AIR TRAFFIC,DUAL	285T0026 81205	1	33-13-18 P008-00/ /	050-099
M00082		622-6827-002 CONT PNL-HF COMM,LEFT	233T3100 13499	1	23-11-11 P005-00/ /	ALL
M00083		622-6827-002 CONT PNL-HF COMM,RIGHT	233T3100 13499	1	23-11-21 P005-00/ /	ALL
M00085 T		S233T100-527 LIGHTPLATE-CONT PNL,ADF,L	285T0027 81205	1	33-13-18 P008-00/ /	275-299
M00086 T		S233T100-541-542-553 LIGHTPLATE-CONT PNL, ADF, R	285T0027 81205	1	33-13-18 P008-00/ /	050-099, 275-299
M00087		285T0553-4 CONT PNL-ILS	233T6100 81205	1	34-31-11 P008-00/ /	ALL
M00087 T		S233T100-559 LIGHTPLATE-CONT PNL,ILS	285T0553 81205	1	33-13-18 P008-00/ /	050-099

EQUIPMENT LIST

D280T132

Section M00000

Page 5

Mar 09/2006



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00090	9	S241T100-221 PNL-MODE CONT,AFCS (SB 22A0092)	233T2100 81205	1	22-11-12 P055-00/ /	ALL
M00090 T		S233T100-537 LIGHTPLATE-CONT PNL,AFCS MODE	285T0524 81205	1	33-13-17 P055-00/ /	ALL
M00091		285T0554-5 CONT PNL-VOR,LEFT	233T2100 81205	1	34-51-11 P007-00/ /	280-299
M00091	1	285T0554-5 CONT PNL-VOR,LEFT	233T2100 81205	1	34-51-11 P007-00/ /	050-099, 150-199, 275-278
M00091	2	285T0554-3 CONT PNL-VOR,LEFT	233T2100 81205	1	34-51-11 P007-00/ /	050-099, 150-199, 275-278
M00091 T		S233T100-020 LIGHTPLATE-CONT PNL,VOR,LEFT	285T0021 81205	1	33-13-17 P055-00/ /	ALL
M00092		285T0554-5 CONT PNL-VOR,RIGHT	233T2100 81205	1	34-51-21 P007-00/ /	280-299
M00092	1	285T0554-5 CONT PNL-VOR,RIGHT	233T2100 81205	1	34-51-21 P007-00/ /	050-099, 150-199, 275-278
M00092	2	285T0554-3 CONT PNL-VOR,RIGHT	233T2100 81205	1	34-51-21 P007-00/ /	050-099, 150-199, 275-278
M00092 T		S233T100-021 LIGHTPLATE-CONT PNL,VOR,RIGHT	285T0021 81205	1	33-13-17 P055-00/ /	ALL
M00093		S242T404-304 CONT PNL-EFIS,RIGHT	233T6100 81205	1	34-22-24 P010-00/ /	050-099, 150-155, 162-165, 275-276
M00093		S242T404-344 CONT PNL-EFIS (TCAS COMPATIBLE), RIGHT	233T6100 81205	1	34-22-24 P010-00/ /	156-157, 166-199, 277-299
M00094		S242T404-304 CONT PNL-EFIS,LEFT	233T6100 81205	1	34-22-14 P010-00/ /	050-099, 150-155, 162-165, 275-276
M00094		S242T404-344 CONT PNL-EFIS (TCAS COMPATIBLE), LEFT	233T6100 81205	1	34-22-14 P010-00/ /	156-157, 166-199, 277-299
M00098	9	5032-1-5 SEL PNL-AUDIO,FIRST OBSR (SB 23-0052)	233T4100 30242	1	23-51-41 P061-00/ /	050-099, 150-154, 162-164, 275-276
M00098		5032-1-5 SEL PNL-AUDIO,FIRST OBSERVER	233T4100 30242	1	23-51-41 P061-00/ /	155-157, 165-199, 277-278
M00098		5032-1-2 SEL PNL-AUDIO,FIRST OBSERVER	233T4100 30242	1	23-51-41 P061-00/ /	280-299

EQUIPMENT LIST

D280T132

Section M00000

Page 6

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00098 T		S233T100-TBD LIGHTPLATE-SEL PNL-AUDIO,F/O	233T4100 30242	1	33-13-18 P061-00/ /	150-199

EQUIPMENT LIST

D280T132

Section M00000
Page 7 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00100		S242T210-206 COMPUTER-AIR DATA,L	284T0400 81205	1	34-12-11 SHELF/E01/03	ALL
M00101		S242T210-206 COMPUTER-AIR DATA,R	284T0400 81205	1	34-12-21 SHELF/E02/03	ALL
M00102		S283T001-23 UNIT-ANTISKID/AUTOBRAKE CONTROL	284T0400 81205	1	32-42-11 SHELF/E01/01	050-099, 153-155, 162-165, 275-276
M00102		S283T001-13 UNIT-ANTISKID/AUTOBRAKE CONTROL	284T0400 81205	1	32-42-11 SHELF/E01/01	150-152, 156, 166
M00102		S283T001-25 UNIT-ANTISKID/AUTOBRAKE CONTROL	284T0400 81205	1	32-42-11 SHELF/E01/01	157, 167-199, 277- 299
M00108		285T0001-69 ACCESSORY UNIT-AUDIO	284T0400 81205	1	23-42-11 SHELF/E02/05	ALL
M00112	9	622-7878-201 TRANSPONDER-ATC,LEFT (SB 34-0149)	284T0400 13499	1	34-53-11 SHELF/E02/02	050-099, 155-199
M00112	9	622-7878-201 TRANSPONDER-ATC,LEFT (MTO 340652)	CUSTOMER 13499	1	34-53-11 SHELF/E02/02	150-154
M00112	9	7517800-11006 TRANSPONDER-ATC,LEFT(EOC E34-0358-02)	284T0400 13499	1	34-53-11 SHELF/E02/02	275-299
M00113	9	622-7878-201 TRANSPONDER-ATC,RIGHT (SB 34-0149)	284T0400 13499	1	34-53-21 SHELF/E02/03	050-099, 155-199
M00113	9	622-7878-201 TRANSPONDER-ATC,RIGHT (MTO 340652)	CUSTOMER 13499	1	34-53-21 SHELF/E02/03	150-154
M00113	9	7517800-11006 TRANSPONDER-ATC,RIGHT(EOC E34-0358-02)	284T0400 13499	1	34-53-21 SHELF/E02/03	275-299
M00115		S283T002-9 MONITOR UNIT-BRAKE TEMP	284T0400 81205	1	32-46-11 SHELF/E02/04	ALL
M00116	1	S281T001-41 CONT UNIT-BUS POWER	284T0400 81205	1	24-41-12 SHELF/E02/04	ALL
M00116	2	S281T001-23 CONT UNIT-BUS POWER	284T0400 81205	1	24-41-12 SHELF/E02/04	ALL
M00116	3	S281T001-15 CONT UNIT-BUS POWER	284T0400 81205	1	24-41-12 SHELF/E02/04	ALL
M00118		S210T160-43 CONT UNIT-CABIN PRESSURE,AUTO. 1	284T0400 81205	1	21-31-11 SHELF/E01/02	050-099, 150-166, 275-277

EQUIPMENT LIST

D280T132

Section M00100

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00118		S210T160-63 CONT UNIT-CABIN PRESSURE,AUTO. 1	284T0400 81205	1	21-31-11 SHELF/E01/02	167-199, 278-299
M00119		S210T160-43 CONT UNIT-CABIN PRESSURE,AUTO. 2	284T0400 81205	1	21-31-21 SHELF/E02/04	050-099, 150-166, 275-277
M00119		S210T160-63 CONT UNIT-CABIN PRESSURE,AUTO. 2	284T0400 81205	1	21-31-21 SHELF/E02/04	167-199, 278-299
M00121		S345T002-60 UNIT-FUEL QTY PROCESSOR	284T0400 81205	1	28-21-11 SHELF/E02/04	ALL
M00122	1	S271T455-20 UNIT-HYD QTY MONITOR	284T0400 81205	1	29-33-11 SHELF/E02/04	ALL
M00122	2	S271T455-16 UNIT-HYD QTY MONITOR	284T0400 81205	1	29-33-11 SHELF/E02/04	ALL
M00122	3	S271T455-14 UNIT-HYD QTY MONITOR	284T0400 81205	1	29-33-11 SHELF/E02/04	ALL
M00122	4	S271T455-12 UNIT-HYD QTY MONITOR	284T0400 81205	1	29-33-11 SHELF/E02/04	ALL
M00123		622-4540-001 INTERROGATOR-DME,LEFT	284T0400 13499	1	34-55-11 SHELF/E02/02	ALL
M00124		622-4540-001 INTERROGATOR-DME,RIGHT	284T0400 13499	1	34-55-21 SHELF/E02/03	ALL
M00126		S210T130-69 CONTROLLER-PACK TEMPERATURE,LEFT	284T0130 81205	1	21-51-12 SHELF/E03/01	150-199, 275-299
M00126	1	S210T130-69 CONTROLLER-PACK TEMPERATURE,LEFT	284T0130 81205	1	21-51-12 SHELF/E03/01	050-099
M00126	2	S210T130-57 CONTROLLER-PACK TEMPERATURE,LEFT	284T0130 81205	1	21-51-12 SHELF/E03/01	050-099
M00126	3	S210T130-52 CONTROLLER-PACK TEMPERATURE,LEFT	284T0130 81205	1	21-51-12 SHELF/E03/01	050-099
M00126	4	S210T130-48 CONTROLLER-PACK TEMPERATURE,LEFT	284T0130 81205	1	21-51-12 SHELF/E03/01	050-099
M00127		S210T130-69 CONTROLLER-PACK TEMPERATURE,RIGHT	284T0130 81205	1	21-51-22 SHELF/E03/01	150-199, 275-299
M00127	1	S210T130-69 CONTROLLER-PACK TEMPERATURE,RIGHT	284T0130 81205	1	21-51-22 SHELF/E03/01	050-099

EQUIPMENT LIST

D280T132

Section M00100

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00127	2	S210T130-57 CONTROLLER-PACK TEMPERATURE,RIGHT	284T0130 81205	1	21-51-22 SHELF/E03/01	050-099
M00127	3	S210T130-52 CONTROLLER-PACK TEMPERATURE,RIGHT	284T0130 81205	1	21-51-22 SHELF/E03/01	050-099
M00127	4	S210T130-48 CONTROLLER-PACK TEMPERATURE,RIGHT	284T0130 81205	1	21-51-22 SHELF/E03/01	050-099
M00129	9	S210T120-67 MODULE-BITE,AIR SUPPLY (SB 36-0029)	284T0130 26964	1	36-23-11 SHELF/E03/01	050-099, 150-155, 162-165, 275-276
M00129		S210T120-47 MODULE-BITE,AIR SUPPLY	284T0130 26964	1	36-23-11 SHELF/E03/01	050-099, 150-155, 162-165
M00129		S210T120-67 MODULE-BITE,AIR SUPPLY	284T0130 26964	1	36-23-11 SHELF/E03/01	156-157, 166-199, 277-299
M00132	9	S362A001-1 MONITOR UNIT-ENGINE VIB (SB 77-0023)	284T1300 51057	1	77-31-11 SHELF/E02/04	ALL
M00132		S360N021-750 MONITOR UNIT-ENGINE VIBRATION	284T0400 51057	1	77-31-11 SHELF/E02/04	050-099, 155-199, 277-299
M00132		S360N021-700 MONITOR UNIT-ENGINE VIBRATION	284T0400 51057	1	77-31-11 SHELF/E02/04	275-276
M00133		233T4222-20 PNL-INTERPHONE JACK, F/OBS	233T4100 81205	1	23-51-41 P061-00/ /	ALL
M00134	9	S242T102-455 COMTR-FLT MANAGEMENT,LEFT (SB 34-0544)	284T0400 81205	1	34-61-11 SHELF/E02/02	157
M00134		S242T102-450 COMPUTER-FLIGHT MANAGEMENT,LEFT	284T0400 81205	1	34-61-11 SHELF/E02/02	050-099, 150-154, 162-163, 275-276
M00134		S242T102-451 COMPUTER-FLIGHT MANAGEMENT,LEFT	284T0400 81205	1	34-61-11 SHELF/E02/02	155-157, 164-199, 277-299
M00135	9	S242T102-455 COMPUTER-FLT MANAGEMENT,R (SB 34-0544)	284T0400 81205	1	34-61-21 SHELF/E02/03	157
M00135		S242T102-450 COMPUTER-FLIGHT MANAGEMENT,RIGHT	284T0400 81205	1	34-61-21 SHELF/E02/03	050-099, 150-154, 162-163, 275-276
M00135		S242T102-451 COMPUTER-FLIGHT MANAGEMENT,RIGHT	284T0400 81205	1	34-61-21 SHELF/E02/03	155-157, 164-199, 277-299
M00138		2233000-816-1 UNIT-DIGITAL FLIGHT DATA ACQUISITION	284T1300 98571	1	31-31-11 SHELF/E02/03	050-099, 155-199, 276-299

EQUIPMENT LIST

D280T132

Section M00100

Page 3

Aug 15/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00138		2227000-59 UNIT-DIGITAL FLIGHT DATA ACQUISITION	284T0400 98571	1	31-31-11 SHELF/E02/03	150-154, 275
M00139	9	S241T100-109 COMPUTER-FLIGHT CONTROL,L (SB 22-0038)	284T0400 81205	1	22-11-11 SHELF/E01/03	050-099, 150-156, 162-166, 275-276
M00139		S241T100-108 COMPUTER-FLIGHT CONTROL,LEFT	284T0400 81205	1	22-11-11 SHELF/E01/03	156, 166, 275-276
M00139		S241T100-109 COMPUTER-FLIGHT CONTROL,LEFT	284T0400 81205	1	22-11-11 SHELF/E01/03	157, 167-199, 277- 299
M00140	9	S241T100-109 COMPUTER-FLT CONT,CENTER (SB 22-0038)	284T0400 81205	1	22-11-31 SHELF/E01/04	050-099, 150-156, 162-166, 275-276
M00140		S241T100-108 COMPUTER-FLIGHT CONTROL,CENTER	284T0400 81205	1	22-11-31 SHELF/E01/04	156, 166, 275-276
M00140		S241T100-109 COMPUTER-FLIGHT CONTROL,CENTER	284T0400 81205	1	22-11-31 SHELF/E01/04	157, 167-199, 277- 299
M00141	9	S241T100-109 COMPUTER-FLIGHT CONTROL,R (SB 22-0038)	284T0400 81205	1	22-11-21 SHELF/E01/05	050-099, 150-156, 162-166, 275-276
M00141		S241T100-108 COMPUTER-FLIGHT CONTROL,RIGHT	284T0400 81205	1	22-11-21 SHELF/E01/05	156, 166, 275-276
M00141		S241T100-109 COMPUTER-FLIGHT CONTROL,RIGHT	284T0400 81205	1	22-11-21 SHELF/E01/05	157, 167-199, 277- 299
M00142		60B50012-6 AIR COMPRESSOR-POTABLE WATER	417T2037 81205	1	38-15-11 1546/195/R057	050-099, 275-276
M00142		60B50012-6 AIR COMPRESSOR-POTABLE WATER	417T2037 81205	1	38-15-11 1550/190/R040	150-155, 162-165
M00142		60B50012-8 AIR COMPRESSOR-POTABLE WATER	417T2037 81205	1	38-15-11 1550/190/R040	156-157, 166-199
M00142		60B50012-8 AIR COMPRESSOR-POTABLE WATER	417T2037 81205	1	38-15-11 1546/195/R057	277-299
M00143	5	S281T001-14 CONT UNIT-GENERATOR,APU	284T0400 81205	1	24-22-41 SHELF/E02/04	ALL
M00143	1	S281T001-40 CONT UNIT-GENERATOR,APU	284T0400 81205	1	24-22-41 SHELF/E02/04	ALL
M00143	2	S281T001-32 CONT UNIT-GENERATOR,APU	284T0400 81205	1	24-22-41 SHELF/E02/04	ALL

EQUIPMENT LIST

D280T132

Section M00100

Page 4

Aug 15/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00143	3	S281T001-31 CONT UNIT-GENERATOR,APU	284T0400 81205	1	24-22-41 SHELF/E02/04	ALL
M00143	4	S281T001-24 CONT UNIT-GENERATOR,APU	284T0400 81205	1	24-22-41 SHELF/E02/04	ALL
M00144	1	S281T001-40 CONT UNIT-GENERATOR,LEFT	284T0400 81205	1	24-22-11 SHELF/E01/02	ALL
M00144	2	S281T001-32 CONT UNIT-GENERATOR,LEFT	284T0400 81205	1	24-22-11 SHELF/E01/02	ALL
M00144	3	S281T001-31 CONT UNIT-GENERATOR,LEFT	284T0400 81205	1	24-22-11 SHELF/E01/02	ALL
M00144	4	S281T001-24 CONT UNIT-GENERATOR,LEFT	284T0400 81205	1	24-22-11 SHELF/E01/02	ALL
M00146	9	S281T001-40 CONT UNIT-GENERATOR,RIGHT (SB 24-0080)	284T0400 81205	1	24-11-21 SHELF/E02/04	ALL
M00147	9	S220T102-209 COMPUTER-GROUND PROXIMITY (SL 34-72)	284T0400 81205	1	34-46-11 SHELF/E01/05	050-099, 151
M00147	9	965-0976-020-210-210 COMPUTER-GROUND PROXIMITY (MT0-340961)	CUSTOMER 81205	1	34-46-11 SHELF/E01/05	150, 152-199, 275-299
M00147	8	S220T102-208 COMPUTER-GROUND PROXIMITY (SL 34-72)	284T0400 81205	1	34-46-11 SHELF/E01/05	050-099, 151
M00147	7	S220T102-207 COMPUTER-GROUND PROXIMITY (SL 34-72)	284T0400 81205	1	34-46-11 SHELF/E01/05	050-099, 151
M00148		S242T404-414 SYMBOL GEN-ELEX FLT INSTR SYS,LEFT	284T0400 81205	1	34-22-16 SHELF/E01/02	050-099, 150-156, 162-166, 275-276
M00148		S242T404-420 SYMBOL GEN-ELEX FLT INSTR SYS,LEFT	284T0400 81205	1	34-22-16 SHELF/E01/02	157, 167-199, 277-299
M00149		S242T404-414 SYMBOL GEN-ELEX FLT INSTR SYS,CENTER	284T0400 81205	1	34-22-36 SHELF/E01/04	050-099, 150-156, 162-166, 275-276
M00149		S242T404-420 SYMBOL GEN-ELEX FLT INSTR SYS,CENTER	284T0400 81205	1	34-22-36 SHELF/E01/04	157, 167-199, 277-299
M00150		S242T404-414 SYMBOL GEN-ELEX FLT INSTR SYS,RIGHT	284T0400 81205	1	34-22-26 SHELF/E01/05	050-099, 150-156, 162-166, 275-276
M00150		S242T404-420 SYMBOL GEN-ELEX FLT INSTR SYS,RIGHT	284T0400 81205	1	34-22-26 SHELF/E01/05	157, 167-199, 277-299

EQUIPMENT LIST

D280T132

Section M00100

Page 5

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00152		622-5272-001 XCVR-HF COMM,LEFT	284T0400 13499	1	23-11-11 SHELF/E02/06	ALL
M00153		622-5272-001 XCVR-HF COMM,RIGHT	284T0400 13499	1	23-11-21 SHELF/E02/06	ALL
M00154		S232T303-303 POWER SEAT-CAPTAIN	232T3002 81205	1	25-11-11 0187/223/L021	ALL
M00155		S232T303-304 POWER SEAT-FIRST OFFICER	232T3002 81205	1	25-11-21 0187/223/R021	ALL
M00156		S220T103-108 RECEIVER-ILS,L	284T0400 81205	1	34-31-11 SHELF/E01/03	050-099, 150-199
M00156		2041230-3516 RECEIVER-ILS,L	284T0400 27914	1	34-31-11 SHELF/E01/03	275-299
M00157		S220T103-108 RECEIVER-ILS,C	284T0400 81205	1	34-31-31 SHELF/E01/04	050-099, 150-199
M00157		2041230-3516 RECEIVER-ILS,C	284T0400 27914	1	34-31-31 SHELF/E01/04	275-299
M00158		S220T103-108 RECEIVER-ILS,R	284T0400 81205	1	34-31-21 SHELF/E01/05	050-099, 150-199
M00158		2041230-3516 RECEIVER-ILS,R	284T0400 27914	1	34-31-21 SHELF/E01/05	275-299
M00159	9	S242T101-109 UNIT-INERTIAL REF,LEFT (SB 34-0100)	284T0400 81205	1	34-21-11 SHELF/E01/06	050-099
M00159	9	S242T101-111 UNIT-INERTIAL REF,LEFT (SB 34-0206)	284T0400 81205	1	34-21-11 SHELF/E01/06	150-199
M00159	9	S242T101-111 UNIT-INERTIAL REF,LEFT (SB 34-0202)	284T0400 81205	1	34-21-11 SHELF/E01/06	275-299
M00159	8	S242T101-112 UNIT-INERTIAL REF,LEFT (SB 34-0202)	284T0400 81205	1	34-21-11 SHELF/E01/06	275-299
M00159	7	S242T101-110 UNIT-INERTIAL REF,LEFT (SB 34-0202)	284T0400 81205	1	34-21-11 SHELF/E01/06	275-299
M00159		S242T101-109 UNIT-INERTIAL REFERENCE,LEFT	284T0400 81205	1	34-21-11 SHELF/E01/06	157
M00159	1	S242T101-105 UNIT-INERTIAL REFERENCE,LEFT	284T0400 81205	1	34-21-11 SHELF/E01/06	051-099, 153-156, 275-299

EQUIPMENT LIST

D280T132

Section M00100

Page 6

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00159	2	S242T101-107 UNIT-INERTIAL REFERENCE,LEFT	284T0400 81205	1	34-21-11 SHELF/E01/06	153-156, 275-299
M00160	9	S242T101-109 UNIT-INERTIAL REF,CENTER (SB 34-0100)	284T0400 81205	1	34-21-31 SHELF/E01/06	050-099
M00160	9	S242T101-111 UNIT-INERTIAL REF,CENTER (SB 34-0206)	284T0400 81205	1	34-21-31 SHELF/E01/06	150-199
M00160	9	S242T101-111 UNIT-INERTIAL REF,CENTER (SB 34-0202)	284T0400 81205	1	34-21-31 SHELF/E01/06	275-299
M00160	8	S242T101-112 UNIT-INERTIAL REF,CENTER (SB 34-0202)	284T0400 81205	1	34-21-31 SHELF/E01/06	275-299
M00160	7	S242T101-110 UNIT-INERTIAL REF,CENTER (SB 34-0202)	284T0400 81205	1	34-21-31 SHELF/E01/06	275-299
M00160		S242T101-109 UNIT-INERTIAL REFERENCE,CENTER	284T0400 81205	1	34-21-31 SHELF/E01/06	157
M00160	1	S242T101-105 UNIT-INERTIAL REFERENCE,CENTER	284T0400 81205	1	34-21-31 SHELF/E01/06	153-156, 275-299
M00160	2	S242T101-107 UNIT-INERTIAL REFERENCE,CENTER	284T0400 81205	1	34-21-31 SHELF/E01/06	153-156, 275-299
M00161	9	S242T101-109 UNIT-INERTIAL REF,RIGHT (SB 34-0100)	284T0400 81205	1	34-21-21 SHELF/E01/06	050-099
M00161	9	S242T101-111 UNIT-INERTIAL REF,RIGHT (SB 34-0206)	284T0400 81205	1	34-21-21 SHELF/E01/06	150-199
M00161	9	S242T101-111 UNIT-INERTIAL REF,RIGHT (SB 34-0202)	284T0400 81205	1	34-21-21 SHELF/E01/06	275-299
M00161	8	S242T101-112 UNIT-INERTIAL REF,RIGHT (SB 34-0202)	284T0400 81205	1	34-21-21 SHELF/E01/06	275-299
M00161	7	S242T101-110 UNIT-INERTIAL REF,RIGHT (SB 34-0202)	284T0400 81205	1	34-21-21 SHELF/E01/06	275-299
M00161	1	S242T101-105 UNIT-INERTIAL REFERENCE,RIGHT	284T0400 81205	1	34-21-21 SHELF/E01/06	275-299
M00161	2	S242T101-107 UNIT-INERTIAL REFERENCE,RIGHT	284T0400 81205	1	34-21-21 SHELF/E01/06	275-299
M00162		S283T006-26 ELEX UNIT-PROX SW (SEE YCR)	284T0400 81205	1	32-09-21 SHELF/E01/02	157-199, 275-299

EQUIPMENT LIST

D280T132

Section M00100

Page 7

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00162	1	S283T006-26 ELEX UNIT-PROX SW (SEE YCR)	284T0400 81205	1	32-09-21 SHELF/E01/02	050-099, 150-156
M00162	2	S283T006-27 ELEX UNIT-PROX SW (SEE YCR)	284T0400 81205	1	32-09-21 SHELF/E01/02	050-099, 150-156
M00162	3	S283T006-21 ELEX UNIT-PROX SW (SEE YCR)	284T0400 81205	1	32-09-21 SHELF/E01/02	050-099, 150-156
M00168		S241T100-304 PNL-MAINTENANCE CONTROL & DSPL	284T0400 81205	1	22-41-11 SHELF/E01/02	050-099, 150-155, 162-165, 275-276
M00168		S241T100-305 PNL-MAINTENANCE CONTROL & DSPL	284T0400 81205	1	22-41-11 SHELF/E01/02	156-157, 166-199, 277-299
M00170		RD-AX7002-01 REPRODUCER-TAPE,ENT	284T0400 54473	1	23-34-14 SHELF/E02/05	050-099
M00170		RD-AX7002-01 REPRODUCER-TAPE,ENT	284T0400 54473	1	23-34-11 SHELF/E02/05	150-199
M00170		RD-AX7002-01 REPRODUCER-TAPE,ENT	284T0400 54473	1	23-34-17 SHELF/E02/05	275-299
M00171		S220T111-101 MAIN MULTIPLEXER	284T0400 54473	1	23-34-14 SHELF/E02/05	050-099
M00171		S220T111-101 MAIN MULTIPLEXER	284T0400 54473	1	23-34-11 SHELF/E02/05	150-199
M00171		S220T111-101 MAIN MULTIPLEXER	284T0400 54473	1	23-34-17 SHELF/E02/05	275-299
M00172	9	SAS MANAGEMENT UNIT-ACARS	CUSTOMER 81205	0	23-22-11 SHELF/E02/	150, 152-166, 275- 278
M00172		465-0728-001 MANAGEMENT UNIT-ACARS	284T0400 97896	1	23-22-11 SHELF/E02/05	167-199
M00177		622-5342-101 AMPLIFIER-PASS. ADDRESS	284T0400 13499	1	23-31-11 SHELF/E02/05	050-099, 155-199, 276-299
M00177		622-5342-001 AMPLIFIER-PASS. ADDRESS	284T1300 13499	1	23-31-11 SHELF/E02/05	150-154
M00177		622-5342-001 AMPLIFIER-PASS. ADDRESS	284T0400 13499	1	23-31-11 SHELF/E02/05	275
M00180		NA138-714B DECODER-SELCAL RR41033-14R3	284T0400 89507	1	23-21-11 SHELF/E02/05	050, 162-165

EQUIPMENT LIST

D280T132

Section M00100

Page 8

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00180		NA138-714A DECODER-SELCAL	284T0400 89507	1	23-21-11 SHELF/E02/05	051-099, 150-154, 275-276
M00180		NA138-714B DECODER-SELCAL	284T0400 89507	1	23-21-11 SHELF/E02/05	155-157, 166-199, 277-299
M00183		S241T200-205 COMPUTER-THRUST MANAGEMENT	284T0400 81205	1	22-31-11 SHELF/E01/03	ALL
M00186		S220T104-104 RECEIVER-VOR/MKR,LEFT	284T0400 13499	1	34-51-11 SHELF/E02/02	050-099
M00186		S220T104-104 RECEIVER-VOR/MKR,LEFT	284T0400 81205	1	34-51-11 SHELF/E02/02	150-199
M00186		2041231-3608 RECEIVER-VOR/MKR,LEFT	284T0400 27914	1	34-51-11 SHELF/E02/02	275-299
M00187		S220T104-104 RECEIVER-VOR/MKR,RIGHT	284T0400 81205	1	34-51-21 SHELF/E02/03	050-099, 150-199
M00187		2041231-3608 RECEIVER-VOR/MKR,RIGHT	284T0400 27914	1	34-51-21 SHELF/E02/03	275-299
M00188	9	822-1044-004 XCVR-VHF COMM,LEFT (MTO-230731)	284T0400 13499	1	23-12-11 SHELF/E02/05	150, 152-199, 275- 299
M00188		622-5219-004 XCVR-VHF COMM,LEFT	284T0400 13499	1	23-12-11 SHELF/E02/05	050-099, 151
M00189	9	822-1044-004 XCVR-VHF COMM,RIGHT (MTO-230731)	284T0400 13499	1	23-12-21 SHELF/E02/05	150, 152-199, 275- 299
M00189		622-5219-004 XCVR-VHF COMM,RIGHT	284T0400 13499	1	23-12-21 SHELF/E02/05	050-099, 151
M00190	9	822-1044-004 XCVR-VHF COMM,CENTER (MTO-230731)	284T0400 13499	1	23-12-31 SHELF/E02/05	150, 152-199, 275- 299
M00190		622-5219-004 XCVR-VHF COMM,CENTER	284T0400 13499	1	23-12-31 SHELF/E02/05	050-099, 151
M00191		S283T007-5 CONTROL UNIT-WINDOW HEAT,L FWD & R SIDE	284T0400 19560	1	30-41-11 SHELF/E01/02	157, 167-199, 277- 299
M00191	1	S283T007-3 CONTROL UNIT-WINDOW HEAT,L FWD & R SIDE	284T0400 19560	1	30-41-11 SHELF/E01/02	050-099, 150-156, 162-166, 275-276
M00191	2	S283T007-2 CONTROL UNIT-WINDOW HEAT,L FWD & R SIDE	284T0400 19560	1	30-41-11 SHELF/E01/02	050-099, 150-156, 162-166, 275-276

EQUIPMENT LIST

D280T132

Section M00100

Page 9

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00192		S283T007-5 CONTROL UNIT-WINDOW HEAT,R FWD & L SIDE	284T0400 81205	1	30-41-12 SHELF/E02/01	157, 167-199, 277-299
M00192	1	S283T007-3 CONTROL UNIT-WINDOW HEAT,R FWD & L SIDE	284T0400 81205	1	30-41-12 SHELF/E02/01	050-099, 150-156, 162-166, 275-276
M00192	2	S283T007-2 CONTROL UNIT-WINDOW HEAT,R FWD & L SIDE	284T0400 81205	1	30-41-12 SHELF/E02/01	050-099, 150-156, 162-166, 275-276
M00195		S210T130-68 CONT UNIT-ZONE TEMPERATURE	284T0130 81205	1	21-61-11 SHELF/E03/01	ALL

EQUIPMENT LIST

D280T132

Section M00100
Page 10 End
Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00200		S283T009-2 RECORDER-DIGITAL FLIGHT DATA	284T0198 81205	1	31-31-11 SHELF/E07/00	050-099, 150-199
M00200		980-4700-042 RECORDER-DIGITAL FLIGHT DATA	284T0198 81205	1	31-31-11 SHELF/E07/00	275-299
M00201		980-6005-076 RECORDER-VOICE	284T0198 97896	1	23-71-11 SHELF/E07/00	ALL
M00202		9599-607-14923 RECEIVER-XMTR,RAD,ALTM,LEFT	284T0755 F6170	1	34-33-11 SHELF/E05/01	050-099, 275-299
M00202		9599-607-14923 RECEIVER-XMTR,RAD,ALTM,LEFT	284T0755 81205	1	34-33-11 SHELF/E05/01	150-199
M00203		9599-607-14923 RECEIVER-XMTR,RAD,ALTM,RIGHT	284T0755 F6170	1	34-33-21 SHELF/E05/01	050-099, 275-299
M00203		9599-607-14923 RECEIVER-XMTR,RAD,ALTM,RIGHT	284T0755 81205	1	34-33-21 SHELF/E05/01	150-199
M00204		9599-607-14923 RECEIVER-XMTR,RAD,ALTM,CENTER	284T0755 F6170	1	34-33-31 SHELF/E05/01	050-099, 275-299
M00204		9599-607-14923 RECEIVER-XMTR,RAD,ALTM,CENTER	284T0755 81205	1	34-33-31 SHELF/E05/01	150-199
M00206		S351T020-18 CONT UNIT-AUX POWER	284T0406 81205	1	49-14-11 SHELF/E06/01	050-099, 155-199, 276-299
M00206		S351T020-17 CONT UNIT-AUX POWER	284T0406 81205	1	49-14-11 SHELF/E06/01	150-154, 275
M00207	1	S282T002-6 CHARGER-APU BATTERY	284T0406 81205	1	24-31-41 SHELF/E06/01	ALL
M00208		S282T002-1 BATTERY-AUX POWER UNIT	284T0406 81205	1	24-31-41 SHELF/E06/01	ALL
M00211		S251T411-5 MODULE-STAB. TRIM CONT,LEFT (SEE YB4)	251T4200 81205	1	27-41-11 1726/280/L007	150-154
M00212		S251T411-5 MODULE-STAB. TRIM CONT,RIGHT (SEE YB5)	251T4200 81205	1	27-41-21 1726/280/R007	150-154
M00213		2041217-0415 XCVR-WXR,L	284T0019 27914	1	34-43-11 0140/150/L005	275-278
M00213 T		2041213-0405 MOUNT-XCVR,WXR,L	284T0019 27914	1	34-43-11 0140/150/L005	ALL

EQUIPMENT LIST

D280T132

Section M00200

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00214		2041217-0415 XCVR-WXR,R	284T0020 27914	1	34-43-21 0150/140/R020	050-099, 150-199
M00214		2041217-0415 XCVR-WXR,R	284T0020 29635	1	34-43-21 0140/150/L005	275-299
M00214 T		2041213-0405 MOUNT-XCVR,WXR,R	284T0020 27914	1	34-43-21 0150/140/R020	ALL
M00215		622-5222-102 RECEIVER-ADF,L	284T0755 13499	1	34-57-11 SHELF/E05/01	050-099, 150-199, 275-278
M00215	1	622-5222-102 RECEIVER-ADF,L	284T0755 13499	1	34-57-11 SHELF/E05/01	280-299
M00215	2	622-5222-001 RECEIVER-ADF,L	284T0755 13499	1	34-57-11 SHELF/E05/01	280-299
M00216		622-5222-102 RECEIVER-ADF,R	284T0755 13499	1	34-57-21 SHELF/E05/01	050-099, 150-199, 275-278
M00216	1	622-5222-102 RECEIVER-ADF,R	284T0755 13499	1	34-57-21 SHELF/E05/01	280-299
M00216	2	622-5222-001 RECEIVER-ADF,R	284T0755 13499	1	34-57-21 SHELF/E05/01	280-299
M00217	9	S282T004-28 STATIC INVERTER (SB 24-0160)	SB240160 81205	1	24-33-11 SHELF/E03/02	ALL
M00217	1	S282T004-7 STATIC INVERTER	284T0130 81205	1	24-33-11 SHELF/E03/02	275-299
M00217	2	S282T004-4 STATIC INVERTER	284T0130 81205	1	24-33-11 SHELF/E03/02	275-299
M00218	1	S282T002-6 CHARGER-MAIN BATTERY	284T0130 81205	1	24-31-11 SHELF/E03/03	ALL
M00218	2	S282T002-4 CHARGER-MAIN BATTERY	284T0130 81205	1	24-31-11 SHELF/E03/03	ALL
M00218	3	S282T002-2 CHARGER-MAIN BATTERY	284T0130 81205	1	24-31-11 SHELF/E03/03	ALL
M00223		S282T002-1 BATTERY-MAIN	284T0713 81205	1	24-31-11 0287/120/R010	ALL
M00224		MS91586-7 SHUNT-MAIN BATTERY	284T0713 96906	1	24-31-11 0305/126/R005	ALL

EQUIPMENT LIST

D280T132

Section M00200

Page 2

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00225		S281T003-1 ELCU-FWD GALLEY POWER	284T0172 81205	1	25-31-11 P032-00/ /	275-299
M00226		S281T003-1 ELCU-R AFT GALLEY POWER	284T0171 81205	1	25-31-31 P032-00/ /	275-299
M00227		S281T003-1 ELCU-L AFT GALLEY POWER	284T0171 81205	1	25-31-21 P031-00/ /	275-299
M00228		MS91586-7 SHUNT-CHGR,APU BAT.	284T1149 96906	1	24-31-41 P049-00/ /	ALL
M00229		S253T409-1 SERVOMOTOR GENERATOR-A/T	253T7121 81205	1	22-31-11 UNDER/P10/	ALL
M00231	1	S270T200 PUMP-ELEC HYD,L	271T4540 81205	1	29-11-12 NL274/147/	ALL
M00231	2	S270T201 PUMP-ELEC HYD,L	271T4540 81205	1	29-11-12 NL274/147/	ALL
M00232	1	S270T200 PUMP-ELEC HYD,C1	271T4540 81205	1	29-11-31 0997/145/R004	ALL
M00232	2	S270T201 PUMP-ELEC HYD,C1	271T4540 81205	1	29-11-31 0997/145/R004	ALL
M00233	1	S270T200 PUMP-ELEC HYD,C2	271T4540 81205	1	29-11-31 1041/145/R004	ALL
M00233	2	S270T201 PUMP-ELEC HYD,C2	271T4540 81205	1	29-11-31 1041/145/R004	ALL
M00234	1	S270T200 PUMP-ELEC HYD,R	271T4540 81205	1	29-11-22 NR290/147/	ALL
M00234	2	S270T201 PUMP-ELEC HYD,R	271T4540 81205	1	29-11-22 NR290/147/	ALL
M00235		S271T002 PUMP-AIR HYD,SYS CTR (SEE YBV)	271T4610 81205	1	29-11-32 1161/137/L083	ALL
M00237		S232T601-61 MOTOR-WINDSHIELD WIPER,LEFT	232T6002 72914	1	30-42-11 0137/230/0006	ALL
M00238		S232T601-62 MOTOR-WINDSHIELD WIPER,RIGHT	232T6002 72914	1	30-42-11 0137/230/0006	ALL
M00239		S274T401-4 MODULE-HYD,AUTOBRAKE (SEE YAA)	274T4510 81205	1	32-42-12 0965/175/L003	ALL

EQUIPMENT LIST

D280T132

Section M00200

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00240		C-07202-3 STICK SHAKER-LEFT	253T2127 83326	1	27-32-11 CONT/COL/LKG	ALL
M00241	9	822-0987-003 COUPLER-HF COMM,LEFT (SB 23-0149)	284T0604 13499	1	23-11-11 F 0281/ /FS	050-099, 150-199, 275-278
M00241		792-6140-001 COUPLER-HF COMM,LEFT	284T0604 13499	1	23-11-11 F 0281/ /FS	ALL
M00242		792-6140-001 COUPLER-HF COMM,RIGHT	284T0604 13499	1	23-11-21 F 0270/ /FS	ALL
M00243		DMN27-2 ANTENNA-MARKER BEACON	284T0223 85226	1	34-32-11 0680/102/0000	050-099
M00243		DMN27-2 ANTENNA-MARKER BEACON	284T0223 85226	1	34-32-11 0654+37/107/0000	150-199, 275-299
M00244		174T1103-2 ANTENNA-HF COMM	174T1000 81205	1	23-11-11 F 0281/ /FS	ALL
M00245		DMC50-17 ANTENNA-VHF COMM,LEFT	284T0223 85226	1	23-12-11 0667/319/0000	050-099
M00245		DMC50-17 ANTENNA-VHF COMM,LEFT	284T0223 85226	1	23-12-11 0654+33/319/0000	150-199, 275-299
M00246	9	DMC50-17 ANTENNA-VHF COMM,RIGHT (SB 34-0091)	284T0223 85226	1	23-12-21 0513/106/0000	150-152, 275-276
M00246	9	DMC50-17 ANTENNA-VHF COMM,RIGHT (SB 34-0133)	284T0223 85226	1	23-12-21 0513/106/0000	153-154
M00246		DMC50-17 ANTENNA-VHF COMM,RIGHT	284T0223 85226	1	23-12-21 0513/106/0000	050-099, 153-199, 277-299
M00247		DMC50-17 ANTENNA-VHF COMM,CENTER	284T0223 85226	1	23-12-31 1340/102/0000	ALL
M00248		60B00024-2 ANTENNA-DUAL LOC,L	284T0225 81205	1	34-31-11 0132/179/0000	ALL
M00249		60B00024-2 ANTENNA-DUAL LOC,R & C	284T0225 81205	1	34-31-31 0132/214/0000	ALL
M00250		S-41422 ANTENNA-DUAL G/S,L	284T0225 13691	1	34-31-11 0132/167/0000	ALL
M00251		S-41422 ANTENNA-DUAL G/S,R & C	284T0225 13691	1	34-31-31 0132/171/0000	ALL

EQUIPMENT LIST

D280T132

Section M00200

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00252		S220T112-102 ANTENNA-XMTR,RAD ALTM,LEFT	284T1358 81205	1	34-33-11 0577/108/L014	050-099, 156-157, 166-199, 277-299
M00252	1	S220T112-101 ANTENNA-XMTR,RAD ALTM,LEFT	284T0223 81205	1	34-33-11 0577/107/L007	150-155, 162-165, 275-276
M00252	2	S220T112-102 ANTENNA-XMTR,RAD ALTM,LEFT	284T0223 81205	1	34-33-11 0577/107/L007	150-155, 162-165, 275-276
M00253		S220T112-102 ANTENNA-RCVR,RAD ALTM,LEFT	284T1358 81205	1	34-33-11 0621/108/L014	050-099, 156-157, 166-199, 277-299
M00253	1	S220T112-101 ANTENNA-RCVR,RAD ALTM,LEFT	284T0223 81205	1	34-33-11 0621/107/L007	150-155, 162-165, 275-276
M00253	2	S220T112-102 ANTENNA-RCVR,RAD ALTM,LEFT	284T0223 81205	1	34-33-11 0621/107/L007	150-155, 162-165, 275-276
M00254		S220T112-102 ANTENNA-XMTR,RAD ALTM,RIGHT	284T1358 81205	1	34-33-21 0577/108/R014	050-099, 156-157, 166-199, 277-299
M00254	1	S220T112-101 ANTENNA-XMTR,RAD ALTM,RIGHT	284T0223 81205	1	34-33-21 0577/107/R007	150-155, 162-165, 275-276
M00254	2	S220T112-102 ANTENNA-XMTR,RAD ALTM,RIGHT	284T0223 81205	1	34-33-21 0577/107/R007	150-155, 162-165, 275-276
M00255		S220T112-102 ANTENNA-RCVR,RAD ALTM,RIGHT	284T1358 81205	1	34-33-21 0621/108/R014	050-099, 156-157, 166-199, 277-299
M00255	1	S220T112-101 ANTENNA-RCVR,RAD ALTM,RIGHT	284T0223 81205	1	34-33-21 0621/107/R007	150-155, 162-165, 275-276
M00255	2	S220T112-102 ANTENNA-RCVR,RAD ALTM,RIGHT	284T0223 81205	1	34-33-21 0621/107/R007	150-155, 162-165, 275-276
M00256		S220T112-102 ANTENNA-XMTR,RAD ALTM,CENTER	284T1358 81205	1	34-33-31 0577/107/0000	050-099, 156-157, 166-199, 277-299
M00256	1	S220T112-101 ANTENNA-XMTR,RAD ALTM,CENTER	284T0223 81205	1	34-33-31 0577/107/C000	150-155, 162-165, 275-276
M00256	2	S220T112-102 ANTENNA-XMTR,RAD ALTM,CENTER	284T0223 81205	1	34-33-31 0577/107/C000	150-155, 162-165, 275-276
M00257		S220T112-102 ANTENNA-RCVR,RAD ALTM,CENTER	284T1358 81205	1	34-33-31 0621/107/0000	050-099, 156-157, 166-199, 277-299
M00257	1	S220T112-101 ANTENNA-RCVR,RAD ALTM,CENTER	284T0223 81205	1	34-33-31 0621/107/C000	150-155, 162-165, 275-276

EQUIPMENT LIST

D280T132

Section M00200

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00257	2	S220T112-102 ANTENNA-RCVR,RAD ALTM,CENTER	284T0223 81205	1	34-33-31 0621/107/C000	150-155, 162-165, 275-276
M00258		S220T116-1 ANTENNA-AIR TRAFFIC CONTROL,LEFT	284T0223 81205	1	34-53-11 0418/ /	150-154
M00259	9	S220T116-1 ANTENNA-ATC,RIGHT (SB 34-0082)	284T0223 81205	1	34-53-13 0448/ /	150-154
M00259		S220T116-1 ANTENNA-AIR TRAFFIC CONTROL,RIGHT	284T0223 81205	1	34-53-21 0448/ /	050-099, 150-199
M00259		S220T116-1 ANTENNA-AIR TRAFFIC CONTROL,RIGHT	284T0223 81205	1	34-53-13 0448/108/0000	275-276, 280-299
M00259		S220T116-1 ANTENNA-AIR TRAFFIC CONTROL,RIGHT	284T1378 81205	1	34-53-13 0448/108/0000	277-278
M00261	9	S220T116-1 ANTENNA-ATC,TOP,RIGHT (SB 34-0082)	284T0223 81205	1	34-53-13 0448/ /	150-154
M00261		S220T116-1 ANTENNA-ATC,TOP,RIGHT	284T0223 81205	1	34-53-13 0448/ /	050-099, 155-199, 275-276, 280-299
M00261		S220T116-1 ANTENNA-ATC,TOP,RIGHT	284T1378 81205	1	34-53-13 0448/319/0000	277-278
M00262		S220T114-101 ANTENNA-VOR	284T0565 81205	1	34-51-11 / /	ALL
M00263		S220T116-1 ANTENNA-DME,LEFT	284T0223 81205	1	34-55-11 0555/108/0000	050-099, 150-199, 275-278
M00263		S220T116-1 ANTENNA-DME,LEFT	284T0223 81205	1	34-55-11 0555/ /	280-299
M00264		S220T116-1 ANTENNA-DME,RIGHT	284T0223 81205	1	34-55-21 0665/125/0000	050-099
M00264		S220T116-1 ANTENNA-DME,RIGHT	284T0223 81205	1	34-55-21 0654+11/107/0000	150-199, 275-299
M00265		622-5404-003 ANTENNA-ADF,LEFT	284T0223 13499	1	34-57-11 1122/305/0000	ALL
M00266		622-5404-003 ANTENNA-ADF,R	284T0223 13499	1	34-57-21 1165/305/0000	ALL
M00269		2041446-0402 ANTENNA-FLAT PLATE,WXR	284T0220 27914	1	34-43-12 0132/ /	050-099

EQUIPMENT LIST

D280T132

Section M00200

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00269		2041446-0402 ANTENNA-FLAT PLATE,WXR	284T0220 27914	1	34-43-12 0128/ /	150-199
M00269		2041446-0401 ANTENNA-FLAT PLATE,WXR	284T0220 27914	1	34-43-12 / /	275-299
M00269 T		2041444-0406 MOUNT-ANTENNA,WXR	284T0220 27914	1	34-43-12 0132/ /	050-099
M00269 T		2041444-0406 MOUNT-ANTENNA,WXR	284T0220 27914	1	34-43-12 0128/ /	150-199
M00269 T		2041444-0402 MOUNT-ANTENNA,WXR	284T0220 27914	1	34-43-12 / /	275-299
M00271		S252T401-8 SERVO-ELEVATOR AUTOPILOT,LEFT	251T2100 81205	1	22-11-11 1795/230/L030	ALL
M00272		S252T401-8 SERVO-ELEVATOR AUTOPILOT,CENTER	251T2100 81205	1	22-11-31 1790/230/R012	ALL
M00273		S252T401-8 SERVO-ELEVATOR AUTOPILOT,RIGHT	251T2100 81205	1	22-11-21 1785/230/R030	ALL
M00274		S252T105-6 LCCA-LEFT AUTOPILOT	251T1100 81205	1	22-11-11 L0250/12/RS	ALL
M00275		S252T105-6 LCCA-CENTER AUTOPILOT	251T1100 81205	1	22-11-31 R0233/12/RS	ALL
M00276		S252T105-6 LCCA-RIGHT AUTOPILOT	251T1100 81205	1	22-11-21 L0250/14/RS	ALL
M00277		S252T703-5 SERVO-DIRECTIONAL AUTOPILOT,LEFT	251T3100 81205	1	22-11-11 F046/ /RS	ALL
M00278		S252T703-5 SERVO-DIRECTIONAL AUTOPILOT,CENTER	251T3100 81205	1	22-11-31 F046/ /RS	ALL
M00279		S252T703-5 SERVO-DIRECTIONAL AUTOPILOT,RIGHT	251T3100 81205	1	22-11-21 F046/ /RS	ALL
M00281	1	S281T001-37 GENERATOR-AUX POWER UNIT	351T0300 81205	1	24-21-41 1840/200/0000	ALL
M00281	2	S281T001-6 GENERATOR-AUX POWER UNIT	351T0300 81205	1	24-21-41 1840/200/0000	ALL
M00289		S417T106 LAVATORY FWD (F1) (SEE YCC)	417T1201 81205	1	33-26-11 0262/ /L055	ALL

EQUIPMENT LIST

D280T132

Section M00200

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00299	1	10167-3000-BT MODULE-ELEC HYD PUMP R ON TIME DELAY	284T0189 08719	1	29-11-22 P033-00/ /	ALL
M00299	2	TD-1767-3000 MODULE-ELEC HYD PUMP R ON TIME DELAY	284T0189 58657	1	29-11-22 P033-00/ /	ALL
M00299	3	10167-3000-BT MODULE-ELEC HYD PUMP R ON TIME DELAY	284T0189 08719	1	29-11-22 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M00200
Page 8 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00300	1	10167-1502-BT MODULE-ELEC HYD PUMP R OFF TIME DELAY	284T0189 08719	1	29-11-22 P033-00/ /	ALL
M00300	2	TD-1767-1502 MODULE-ELEC HYD PUMP R OFF TIME DELAY	284T0189 58657	1	29-11-22 P033-00/ /	ALL
M00300	3	10167-15-BT MODULE-ELEC HYD PUMP R OFF TIME DELAY	284T0189 08719	1	29-11-22 P033-00/ /	ALL
M00301	1	10167-3000-BT MODULE-ELEC HYD PUMP L ON TIME DELAY	284T0188 08719	1	29-11-12 P037-00/ /	ALL
M00301	2	TD-1767-3000 MODULE-ELEC HYD PUMP L ON TIME DELAY	284T0188 58657	1	29-11-12 P037-00/ /	ALL
M00301	3	10167-3000-BT MODULE-ELEC HYD PUMP L ON TIME DELAY	284T0188 08719	1	29-11-12 P037-00/ /	ALL
M00302	1	10167-1502-BT MODULE-ELEC HYD PUMP L OFF TIME DELAY	284T0188 08719	1	29-11-12 P037-00/ /	ALL
M00302	2	TD-1767-1502 MODULE-ELEC HYD PUMP L OFF TIME DELAY	284T0188 58657	1	29-11-12 P037-00/ /	ALL
M00302	3	10167-15-BT MODULE-ELEC HYD PUMP L OFF TIME DELAY	284T0188 08719	1	29-11-12 P037-00/ /	ALL
M00303		EP-449-3001 MODULE-ELEC HYD PUMP C1 ON TIME DELAY	284T0171 58657	1	29-11-31 P031-00/ /	ALL
M00304		EP-449-4001 MODULE-ELEC HYD PUMP C2 ON TIME DELAY	284T0172 58657	1	29-11-31 P032-00/ /	ALL
M00305	1	10167-3000-BT MODULE-AIR HYD PUMP ON TIME DELAY	284T0187 08719	1	29-11-32 P036-00/ /	ALL
M00305	2	TD-1767-3000 MODULE-AIR HYD PUMP ON TIME DELAY	284T0187 58657	1	29-11-32 P036-00/ /	ALL
M00305	3	10167-3000-BT MODULE-AIR HYD PUMP ON TIME DELAY	284T0187 08719	1	29-11-32 P036-00/ /	ALL
M00306	1	252T1401-3 ACTR-PWR CONT,OUTBD SPOILER 1	252T1400 81205	1	27-61-13 L0768/14/RS	ALL
M00306	2	252T1401-2 ACTR-PWR CONT,OUTBD SPOILER 1	252T1400 81205	1	27-61-13 L0768/14/RS	ALL
M00306	3	252T1401-1 ACTR-PWR CONT,OUTBD SPOILER 1	252T1400 81205	1	27-61-13 L0768/14/RS	ALL

EQUIPMENT LIST

D280T132

Section M00300

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00307	1	252T1401-3 ACTR-PWR CONT,OUTBD SPOILER 2	252T1400 81205	1	27-61-14 L0707/14/RS	ALL
M00307	2	252T1401-2 ACTR-PWR CONT,OUTBD SPOILER 2	252T1400 81205	1	27-61-14 L0707/14/RS	ALL
M00307	3	252T1401-1 ACTR-PWR CONT,OUTBD SPOILER 2	252T1400 81205	1	27-61-14 L0707/14/RS	ALL
M00308	1	252T1401-3 ACTR-PWR CONT,OUTBD SPOILER 3	252T1400 81205	1	27-61-15 L0647/14/RS	ALL
M00308	2	252T1401-2 ACTR-PWR CONT,OUTBD SPOILER 3	252T1400 81205	1	27-61-15 L0647/14/RS	ALL
M00308	3	252T1401-1 ACTR-PWR CONT,OUTBD SPOILER 3	252T1400 81205	1	27-61-15 L0647/14/RS	ALL
M00309	1	252T1401-3 ACTR-PWR CONT,OUTBD SPOILER 4	252T1400 81205	1	27-61-16 L0586/14/RS	ALL
M00309	2	252T1401-2 ACTR-PWR CONT,OUTBD SPOILER 4	252T1400 81205	1	27-61-16 L0586/14/RS	ALL
M00309	3	252T1401-1 ACTR-PWR CONT,OUTBD SPOILER 4	252T1400 81205	1	27-61-16 L0586/14/RS	ALL
M00310	1	252T1301-3 ACTR-PWR CONT,INBD SPOILER 5	252T1300 81205	1	27-61-17 L0261/14/RS	ALL
M00310	2	252T1301-2 ACTR-PWR CONT,INBD SPOILER 5	252T1300 81205	1	27-61-17 L0261/14/RS	ALL
M00310	3	252T1301-1 ACTR-PWR CONT,INBD SPOILER 5	252T1300 81205	1	27-61-17 L0261/14/RS	ALL
M00311	1	252T1301-3 ACTR-PWR CONT,INBD SPOILER 6	252T1300 81205	1	27-61-18 L0192/14/RS	ALL
M00311	2	252T1301-2 ACTR-PWR CONT,INBD SPOILER 6	252T1300 81205	1	27-61-18 L0192/14/RS	ALL
M00311	3	252T1301-1 ACTR-PWR CONT,INBD SPOILER 6	252T1300 81205	1	27-61-18 L0192/14/RS	ALL
M00312	1	252T1301-3 ACTR-PWR CONT,INBD SPOILER 7	252T1300 81205	1	27-61-18 R0192/14/RS	ALL
M00312	2	252T1301-2 ACTR-PWR CONT,INBD SPOILER 7	252T1300 81205	1	27-61-18 R0192/14/RS	ALL

EQUIPMENT LIST

D280T132

Section M00300

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00312	3	252T1301-1 ACTR-PWR CONT,INBD SPOILER 7	252T1300 81205	1	27-61-18 R0192/14/RS	ALL
M00313	1	S252T303-1 ACTR-PWR CONT,INBD SPOILER 8	252T1300 S4980	1	27-61-17 R0261/14/RS	ALL
M00313	2	252T1301-3 ACTR-PWR CONT,INBD SPOILER 8	252T1300 81205	1	27-61-17 R0261/14/RS	ALL
M00314	1	252T1401-3 ACTR-PWR CONT,OUTBD SPOILER 9	252T1400 81205	1	27-61-16 R0586/14/RS	ALL
M00314	2	252T1401-2 ACTR-PWR CONT,OUTBD SPOILER 9	252T1400 81205	1	27-61-16 R0586/14/RS	ALL
M00314	3	252T1401-1 ACTR-PWR CONT,OUTBD SPOILER 9	252T1400 81205	1	27-61-16 R0586/14/RS	ALL
M00315	1	252T1401-3 ACTR-PWR CONT,OUTBD SPOILER 10	252T1400 81205	1	27-61-15 R0647/14/RS	ALL
M00315	2	252T1401-2 ACTR-PWR CONT,OUTBD SPOILER 10	252T1400 81205	1	27-61-15 R0647/14/RS	ALL
M00315	3	252T1401-1 ACTR-PWR CONT,OUTBD SPOILER 10	252T1400 81205	1	27-61-15 R0647/14/RS	ALL
M00316	1	252T1401-3 ACTR-PWR CONT,OUTBD SPOILER 11	252T1400 81205	1	27-61-14 R0707/14/RS	ALL
M00316	2	252T1401-2 ACTR-PWR CONT,OUTBD SPOILER 11	252T1400 81205	1	27-61-14 R0707/14/RS	ALL
M00316	3	252T1401-1 ACTR-PWR CONT,OUTBD SPOILER 11	252T1400 81205	1	27-61-14 R0707/14/RS	ALL
M00317	1	252T1401-3 ACTR-PWR CONT,OUTBD SPOILER 12	252T1400 81205	1	27-61-13 R0768/14/RS	ALL
M00317	2	252T1401-2 ACTR-PWR CONT,OUTBD SPOILER 12	252T1400 81205	1	27-61-13 R0768/14/RS	ALL
M00317	3	252T1401-1 ACTR-PWR CONT,OUTBD SPOILER 12	252T1400 81205	1	27-61-13 R0768/14/RS	ALL
M00320		S210T130-56 ACTR-RAM AIR EXHAUST DOOR,LEFT	213T3102 81205	1	21-53-11 0935/115/L035	ALL
M00321		S210T130-56 ACTR-RAM AIR EXHAUST DOOR,RIGHT	213T3102 81205	1	21-53-21 0935/115/R043	ALL

EQUIPMENT LIST

D280T132

Section M00300

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00322		S210T130-56 ACTR-RAM AIR INLET DOOR,LEFT	213T3003 81205	1	21-53-11 0836/121/L060	ALL
M00323		S210T130-56 ACTR-RAM AIR INLET L DOOR,RIGHT	213T3003 81205	1	21-53-21 0836/121/R032	ALL
M00324		2156-206 DET 1-SMOKE,FWD CARGO	453T2101 03972	1	26-16-11 0349/179/L070	ALL
M00325		2156-206 DET 2-SMOKE,FWD CARGO	453T2101 03972	1	26-16-11 0352/179/L070	ALL
M00326		2156-204A DET 1-SMOKE,AFT CARGO	453T2201 03972	1	26-16-11 1405/163/L070	ALL
M00327		2156-204A DET 2-SMOKE,AFT CARGO	453T2201 03972	1	26-16-11 1409/163/L070	ALL
M00332		S343T001-14 PUMP-FUEL BOOST,L FWD	343T0002 81205	1	28-22-11 L0280/12/MS	ALL
M00333		S343T001-14 PUMP-FUEL BOOST,L AFT	343T0002 81205	1	28-22-11 L0274/12/MS	ALL
M00334		S343T001-14 PUMP-FUEL BOOST,R FWD	343T0002 81205	1	28-22-11 R0280/12/MS	ALL
M00335		S343T001-14 PUMP-FUEL BOOST,R AFT	343T0002 81205	1	28-22-11 R0274/12/MS	ALL
M00336		60B92403-10 PUMP-FUEL,DC	346T0004 81205	1	28-25-11 L / /	ALL
M00338		S271T455-3 XMTR-HYD SYS L QTY	271T5212 81205	1	29-33-11 NL250/142/	ALL
M00339		S271T455-4 XMTR-HYD SYS CTR QTY	271T0115 81205	1	29-33-11 1009/174/R017	ALL
M00340		S271T455-3 XMTR-HYD SYS R QTY	271T5212 81205	1	29-33-11 NR250/142/	ALL
M00341		S271T451-1 XMTR-HYD SYS L PRESS.	271T1320 81205	1	29-31-11 L0436/002/RS	ALL
M00342		S271T451-1 XMTR-HYD SYS CTR PRESS	271T1320 81205	1	29-31-11 0990/171/R002	ALL
M00343		S271T451-1 XMTR-HYD SYS R PRESS.	271T1320 81205	1	29-31-11 R0436/002/RS	ALL

EQUIPMENT LIST

D280T132

Section M00300

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00344		S270T245-3 XMTR-HYD SYSTEM L TEMP	271T5212 81205	1	29-32-11 NL253/141/	ALL
M00345		S270T245-3 XMTR-HYD SYSTEM CTR TEMP	271T0115 81205	1	29-32-11 1012/173/R013	ALL
M00346		S270T245-3 XMTR-HYD SYSTEM R TEMP	271T5212 81205	1	29-32-11 NR253/141/	ALL
M00347		S451T201-7 PDU 1L-FWD CARGO	451T2003 81205	1	25-53-14 0398/124/L029	050-099, 150-154, 275-276
M00347	1	S451T201-12 PDU 1L-FWD CARGO	451T2003 81205	1	25-53-14 0398/124/L029	150-199, 275-299
M00347	2	S451T201-7 PDU 1L-FWD CARGO	451T2003 81205	1	25-53-14 0398/124/L029	150-199, 275-299
M00348		S451T201-7 PDU 1R-FWD CARGO	451T2003 81205	1	25-53-14 0398/124/R029	050-099, 150-154, 275-276
M00348	1	S451T201-12 PDU 1R-FWD CARGO	451T2003 81205	1	25-53-14 0398/124/R029	150-199, 275-299
M00348	2	S451T201-7 PDU 1R-FWD CARGO	451T2003 81205	1	25-53-14 0398/124/R029	150-199, 275-299
M00373		S451T201-7 PDU 1L-AFT CARGO	451T2002 81205	1	25-53-24 1139/124/L029	050-099
M00373		S451T201-7 PDU 1L-AFT CARGO	451T2002 81205	1	25-53-24 1142/124/L029	150-154, 275-276
M00373	1	S451T201-12 PDU 1L-AFT CARGO	451T2002 81205	1	25-53-24 1142/124/L029	150-199, 275-299
M00374		S451T201-7 PDU 1R-AFT CARGO	451T2002 81205	1	25-53-24 1139/124/R029	050-099
M00374	1	S451T201-12 PDU 1R-AFT CARGO	451T2002 81205	1	25-53-24 1142/124/R029	150-199, 275-299
M00374	2	S451T201-7 PDU 1R-AFT CARGO	451T2002 81205	1	25-53-24 1142/124/R029	150-199, 275-299
M00375		S451T201-7 PDU 2L-AFT CARGO	451T2002 81205	1	25-53-24 1183/124/L029	050-099
M00375		S451T201-7 PDU 2L-AFT CARGO	451T2002 81205	1	25-53-24 1187/124/L029	150-154, 275-276

EQUIPMENT LIST

D280T132

Section M00300

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00375	1	S451T201-12 PDU 2L-AFT CARGO	451T2002 81205	1	25-53-24 1187/124/L029	150-199, 275-299
M00375	2	S451T201-7 PDU 2L-AFT CARGO	451T2002 81205	1	25-53-24 1187/124/L029	150-199, 275-299
M00376		S451T201-7 PDU 2R-AFT CARGO	451T2002 81205	1	25-53-24 1183/124/R029	050-099
M00376	1	S451T201-12 PDU 2R-AFT CARGO	451T2002 81205	1	25-53-24 1187/124/R029	150-199, 275-299
M00376	2	S451T201-7 PDU 2R-AFT CARGO	451T2002 81205	1	25-53-24 1187/124/R029	150-199, 275-299
M00377		S451T201-7 PDU 3L-AFT CARGO	451T2002 81205	1	25-53-24 1227/124/L029	050-099
M00377		S451T201-7 PDU 3L-AFT CARGO	451T2002 81205	1	25-53-24 1197+33/124/L029	150-154, 275-276
M00377	1	S451T201-12 PDU 3L-AFT CARGO	451T2002 81205	1	25-53-24 1197+33/124/L029	150-199, 275-299
M00377	2	S451T201-7 PDU 3L-AFT CARGO	451T2002 81205	1	25-53-24 1197+33/124/L029	150-199, 275-299
M00378		S451T201-7 PDU 3R-AFT CARGO	451T2002 81205	1	25-53-24 1227/124/R029	050-099
M00378		S451T201-7 PDU 3R-AFT CARGO	451T2002 81205	1	25-53-24 1197+33/124/R029	150-154, 275-276
M00378	1	S451T201-12 PDU 3R-AFT CARGO	451T2002 81205	1	25-53-24 1197+33/124/R029	150-199, 275-299
M00378	2	S451T201-7 PDU 3R-AFT CARGO	451T2002 81205	1	25-53-24 1197+33/124/R029	150-199, 275-299
M00379		S451T201-7 PDU 4L-AFT CARGO	451T2002 81205	1	25-53-24 1266/124/L029	050-099
M00379		S451T201-7 PDU 4L-AFT CARGO	451T2002 81205	1	25-53-24 1197+77/124/L029	150-154, 275-276
M00379	1	S451T201-12 PDU 4L-AFT CARGO	451T2002 81205	1	25-53-24 1197+77/124/L029	150-199, 275-299
M00379	2	S451T201-7 PDU 4L-AFT CARGO	451T2002 81205	1	25-53-24 1197+77/124/L029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M00300

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00380		S451T201-7 PDU 4R-AFT CARGO	451T2002 81205	1	25-53-24 1266/124/R029	050-099
M00380		S451T201-7 PDU 4R-AFT CARGO	451T2002 81205	1	25-53-24 1197+77/124/R029	150-154, 275-276
M00380	1	S451T201-12 PDU 4R-AFT CARGO	451T2002 81205	1	25-53-24 1197+77/124/R029	150-199, 275-299
M00380	2	S451T201-7 PDU 4R-AFT CARGO	451T2002 81205	1	25-53-24 1197+77/124/R029	150-199, 275-299
M00381		S451T201-7 PDU 5L-AFT CARGO	451T2002 81205	1	25-53-24 1294/124/L029	050-099
M00381		S451T201-7 PDU 5L-AFT CARGO	451T2002 81205	1	25-53-24 1197+121/124/L029	150-154, 275-276
M00381	1	S451T201-12 PDU 5L-AFT CARGO	451T2002 81205	1	25-53-24 1197+121/124/L029	150-199, 275-299
M00381	2	S451T201-7 PDU 5L-AFT CARGO	451T2002 81205	1	25-53-24 1197+121/124/L029	150-199, 275-299
M00382		S451T201-7 PDU 5R-AFT CARGO	451T2002 81205	1	25-53-24 1294/124/R029	050-099
M00382		S451T201-7 PDU 5R-AFT CARGO	451T2002 81205	1	25-53-24 1197+121/124/R029	150-154, 275-276
M00382	1	S451T201-12 PDU 5R-AFT CARGO	451T2002 81205	1	25-53-24 1197+121/124/R029	150-199, 275-299
M00382	2	S451T201-7 PDU 5R-AFT CARGO	451T2002 81205	1	25-53-24 1197+121/124/R029	150-199, 275-299
M00383		S451T201-7 PDU 6L-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/L021	050-099
M00383		S451T201-7 PDU 6L-AFT CARGO	451T2002 81205	1	25-53-24 1230/124/L029	150-154, 275-276
M00383	1	S451T201-12 PDU 6L-AFT CARGO	451T2002 81205	1	25-53-24 1230/124/L029	150-199, 275-299
M00383	2	S451T201-7 PDU 6L-AFT CARGO	451T2002 81205	1	25-53-24 1230/124/L029	150-199, 275-299
M00384		S451T201-7 PDU 6R-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/R038	050-099

EQUIPMENT LIST

D280T132

Section M00300

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00384		S451T201-7 PDU 6R-AFT CARGO	451T2002 81205	1	25-53-24 1230/124/R029	150-154, 275-276
M00384	1	S451T201-11 PDU 6R-AFT CARGO	451T2002 81205	1	25-53-24 1230/124/R029	150-199, 275-299
M00384	2	S451T201-7 PDU 6R-AFT CARGO	451T2002 81205	1	25-53-24 1230/124/R029	150-199, 275-299
M00385		S451T201-7 PDU 7L-AFT CARGO	451T2002 81205	1	25-53-24 1322/124/L029	050-099
M00385	1	S451T201-12 PDU 7L-AFT CARGO	451T2002 81205	1	25-53-24 1266/124/L029	150-199, 275-299
M00385	2	S451T201-7 PDU 7L-AFT CARGO	451T2002 81205	1	25-53-24 1266/124/L029	150-199, 275-299
M00386		S451T201-7 PDU 7R-AFT CARGO	451T2002 81205	1	25-53-24 1322/124/R029	050-099
M00386	1	S451T201-12 PDU 7R-AFT CARGO	451T2002 81205	1	25-53-24 1266/124/R029	150-199, 275-299
M00386	2	S451T201-7 PDU 7R-AFT CARGO	451T2002 81205	1	25-53-24 1266/124/R029	150-199, 275-299
M00387		S451T201-7 PDU 8L-AFT CARGO	451T2002 81205	1	25-53-24 1350/124/L029	050-099
M00387	1	S451T201-12 PDU 8L-AFT CARGO	451T2002 81205	1	25-53-24 1294/124/L029	150-199, 275-299
M00387	2	S451T201-7 PDU 8L-AFT CARGO	451T2002 81205	1	25-53-24 1294/124/L029	150-199, 275-299
M00388		S451T201-7 PDU 8R-AFT CARGO	451T2002 81205	1	25-53-24 1350/124/R029	050-099
M00388	1	S451T201-12 PDU 8R-AFT CARGO	451T2002 81205	1	25-53-24 1294/124/R029	150-199, 275-299
M00388	2	S451T201-7 PDU 8R-AFT CARGO	451T2002 81205	1	25-53-24 1294/124/R029	150-199, 275-299
M00389		S451T201-7 PDU 9L-AFT CARGO	451T2002 81205	1	25-53-24 1384/124/L029	050-099
M00389	1	S451T201-12 PDU 9L-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/L020	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M00300

Page 8

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00389	2	S451T201-7 PDU 9L-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/L020	150-199, 275-299
M00390		S452T201-3 ACTR 1L-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/L032	050-099, 150-154, 162, 275-276
M00390	1	S452T202-1 ACTR 1L-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/L032	155-157, 163-199, 277-299
M00390	2	S452T201-3 ACTR 1L-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/L032	155-157, 163-199, 277-299
M00391		S452T201-3 ACTR 1R-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/R032	050-099, 150-154, 162, 275-276
M00391	1	S452T202-1 ACTR 1R-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/R032	155-157, 163-199, 277-299
M00391	2	S452T201-3 ACTR 1R-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/R032	155-157, 163-199, 277-299
M00392		S452T201-3 ACTR 1-LD2 GUIDE	452T1201 81205	1	25-53-26 1292/122/L009	050-099, 150-154, 162, 275-276
M00392	1	S452T202-1 ACTR 1-LD2 GUIDE	452T1201 81205	1	25-53-26 1292/122/L009	155-157, 163-199, 277-299
M00392	2	S452T201-3 ACTR 1-LD2 GUIDE	452T1201 81205	1	25-53-26 1292/122/L009	155-157, 163-199, 277-299
M00393		S452T201-3 ACTR 1-LD3 GUIDE	452T1202 81205	1	25-53-26 1292/122/R004	050-099, 150-154, 162, 275-276
M00393	1	S452T202-1 ACTR 1-LD3 GUIDE	452T1202 81205	1	25-53-26 1230/122/R004	155-157, 163-199, 277-299
M00393	2	S452T201-3 ACTR 1-LD3 GUIDE	452T1202 81205	1	25-53-26 1230/122/R004	155-157, 163-199, 277-299
M00394		S452T201-3 ACTR 2L-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/L032	050-099, 150-154, 162, 275-276
M00394	1	S452T202-1 ACTR 2L-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/L032	155-157, 163-199, 277-299
M00394	2	S452T201-3 ACTR 2L-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/L032	155-157, 163-199, 277-299
M00395		S452T201-3 ACTR 2R-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/R032	050-099, 150-154, 162, 275-276

EQUIPMENT LIST

D280T132

Section M00300

Page 9

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00395	1	S452T202-1 ACTR 2R-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/R032	155-157, 163-199, 277-299
M00395	2	S452T201-3 ACTR 2R-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/R032	155-157, 163-199, 277-299

EQUIPMENT LIST

D280T132

Section M00300
Page 10 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00406		S353T010-6 ACTR-APU INLET DOOR	353T0100 81205	1	49-15-11 1738/290/R035	ALL
M00462		60B80050-6 ACTR-LOCKOUT,OUTBD AIL,LEFT	251T1700 81205	1	27-11-12 L0981/12/RS	ALL
M00469		S256T004-12 MOTOR-SLAT DRIVE,OUTBD ALT	256T2710 81205	1	27-81-21 0776/152/L110	ALL
M00470		S250N104-6 XMTR-AILERON POSITION,LEFT INBD	251T1010 81205	1	27-18-11 L0529/ /RS	155-157, 166-199, 277-299
M00470	1	S250N104-6 XMTR-AILERON POSITION,LEFT INBD	251T1010 81205	1	27-18-11 L0529/ /RS	050-099, 150-154, 162-165, 275-276
M00470	2	S250N104-4 XMTR-AILERON POSITION,LEFT INBD	251T1010 81205	1	27-18-11 L0529/ /RS	050-099, 150-154, 162-165, 275-276
M00471		S250N104-6 XMTR-AILERON POSITION,LEFT OUTBD	251T1011 81205	1	27-18-11 L1085/ /RS	155-157, 166-199, 277-299
M00471	1	S250N104-6 XMTR-AILERON POSITION,LEFT OUTBD	251T1011 81205	1	27-18-11 L1085/ /RS	050-099, 150-154, 162-165, 275-276
M00471	2	S250N104-4 XMTR-AILERON POSITION,LEFT OUTBD	251T1011 81205	1	27-18-11 L1085/ /RS	050-099, 150-154, 162-165, 275-276
M00473		S256T007-15 XMTR 1-POSITION,FLAP	256T3650 81205	1	27-51-41 L0803/ /TE	050-099
M00473		S256T007-17 XMTR 1-POSITION,FLAP	256T3650 81205	1	27-51-41 L0803/ /TE	150-199, 275-299
M00475		S256T007-16 XMTR 3-POSITION,FLAP	256T3650 81205	1	27-51-41 L0401/ /TE	050-099, 155-199, 275-299
M00475		S256T007-19 XMTR 3-POSITION,FLAP	256T3650 81205	1	27-51-41 L0401/ /TE	150-154
M00476		S256T007-16 XMTR 4-POSITION,FLAP	256T3650 81205	1	27-51-41 1090/131/L080	050-099
M00476		S256T007-19 XMTR 4-POSITION,FLAP	256T3650 81205	1	27-51-41 1090/131/L080	150-154
M00476		S256T007-20 XMTR 4-POSITION,FLAP	256T3650 81205	1	27-51-41 1090/131/L080	155-199, 275-299
M00479		60B80050-6 ACTR-LOCKOUT,OUTBD AIL,RIGHT	251T1700 81205	1	27-11-22 R0981/12/RS	ALL

EQUIPMENT LIST

D280T132

Section M00400

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00483	1	S256T002-3 XMTR NO.1-PDU POSITION,INBD SLATS	256T2660 81205	1	27-81-31 0775/173/L110	ALL
M00483	2	S256T002-1 XMTR NO.1-PDU POSITION,INBD SLATS	256T2660 81205	1	27-81-31 0775/173/L110	ALL
M00486		S250N104-6 XMTR-AILERON POSITION,RIGHT INBD	251T1010 81205	1	27-18-11 R0529/ /RS	155-157, 166-199, 277-299
M00486	1	S250N104-6 XMTR-AILERON POSITION,RIGHT INBD	251T1010 81205	1	27-18-11 R0529/ /RS	050-099, 150-154, 162-165, 275-276
M00486	2	S250N104-4 XMTR-AILERON POSITION,RIGHT INBD	251T1010 81205	1	27-18-11 R0529/ /RS	050-099, 150-154, 162-165, 275-276
M00487		S250N104-6 XMTR-AILERON POSITION,RIGHT OUTBD	251T1011 81205	1	27-18-11 R1085/ /RS	155-157, 166-199, 277-299
M00487	1	S250N104-6 XMTR-AILERON POSITION,RIGHT OUTBD	251T1011 81205	1	27-18-11 R1085/ /RS	050-099, 150-154, 162-165, 275-276
M00487	2	S250N104-4 XMTR-AILERON POSITION,RIGHT OUTBD	251T1011 81205	1	27-18-11 R1085/ /RS	050-099, 150-154, 162-165, 275-276
M00488		251T1205-5 MOTOR-TRIM,AILERON	251T1118 81205	1	27-11-11 L0959/147/RS	ALL
M00489		S256T007-15 XMTR 8-POSITION,FLAP	256T3650 81205	1	27-51-41 R0803/ /TE	050-099
M00489		S256T007-17 XMTR 8-POSITION,FLAP	256T3650 81205	1	27-51-41 R0803/ /TE	150-199, 275-299
M00492		S256T007-16 XMTR 5-POSITION,FLAP	256T3650 81205	1	27-51-41 1090/131/R080	050-099
M00492		S256T007-19 XMTR 5-POSITION,FLAP	256T3650 81205	1	27-51-41 1090/131/R080	150-154
M00492		S256T007-20 XMTR 5-POSITION,FLAP	256T3650 81205	1	27-51-41 1090/131/R080	155-199, 275-299
M00494		S256T004-5 MOTOR-SLAT DRIVE,INBD ALT	256T2610 81205	1	27-81-11 0775/173/R109	ALL
M00495		S210T120-22 CONTROLLER-HIGH PRESS.	332T3400 81205	2	36-11-61 NL148/082/L017	150-157, 275-299
M00497	1	10167-1502-BT MODULE-AIR HYD PUMP OFF TIME DELAY	284T0187 08719	1	29-11-32 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M00400

Page 2

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00497	2	TD-1767-1502 MODULE-AIR HYD PUMP OFF TIME DELAY	284T0187 58657	1	29-11-32 P036-00/ /	ALL
M00497	3	10167-15-BT MODULE-AIR HYD PUMP OFF TIME DELAY	284T0187 08719	1	29-11-32 P036-00/ /	ALL
M00499		EP-449-5001 MODULE-ELEC HYD PUMP L ON TIME DELAY	284T0188 58657	1	29-11-12 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M00400

Page 3 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00500		EP-449-1501 MODULE-ELEC HYD PUMP R ON TIME DELAY	284T0189 58657	1	29-11-22 P033-00/ /	ALL
M00505		S233T810-13 CONTROL UNIT-FLOODLIGHT,CAPT & CTR PNL	233T2402 81205	1	33-11-11 0152/217/L007	ALL
M00506		S233T810-13 CONTROL UNIT-FLOODLIGHT,F/O	233T2402 81205	1	33-11-11 0152/217/R007	ALL
M00509		S252T704-11 SERVO RIGHT-YAW DAMPER (APL LH SIDE)	251T3700 81205	1	22-21-21 F 108/ /RS	150-199, 275-299
M00509	1	S252T704-11 SERVO RIGHT-YAW DAMPER (APL LH SIDE)	251T3700 81205	1	22-21-21 F 108/ /RS	050-099
M00509	2	S252T704-3 SERVO RIGHT-YAW DAMPER (APL LH SIDE)	251T3700 81205	1	22-21-21 F 108/ /RS	050-099
M00509	3	S252T704-2 SERVO RIGHT-YAW DAMPER (APL LH SIDE)	251T3700 81205	1	22-21-21 F 108/ /RS	050-099
M00509	4	S252T704-1 SERVO RIGHT-YAW DAMPER (APL LH SIDE)	251T3700 81205	1	22-21-21 F 108/ /RS	050-099
M00510		S252T704-11 SERVO LEFT-YAW DAMPER (APL RH SIDE)	251T3700 81205	1	22-21-11 F 108/ /RS	150-199, 275-299
M00510	1	S252T704-11 SERVO LEFT-YAW DAMPER (APL RH SIDE)	251T3700 81205	1	22-21-11 F 108/ /RS	050-099
M00510	2	S252T704-3 SERVO LEFT-YAW DAMPER (APL RH SIDE)	251T3700 81205	1	22-21-11 F 108/ /RS	050-099
M00510	3	S252T704-2 SERVO LEFT-YAW DAMPER (APL RH SIDE)	251T3700 81205	1	22-21-11 F 108/ /RS	050-099
M00510	4	S252T704-1 SERVO LEFT-YAW DAMPER (APL RH SIDE)	251T3700 81205	1	22-21-11 F 108/ /RS	050-099
M00515		S251T320-3 ACTR-RUDDER TRIM	251T3200 81205	1	27-21-11 F 080/ /RS	050-099
M00515		S251T320-2 ACTR-RUDDER TRIM	251T3200 81205	1	27-21-11 F 080/ /RS	150-199, 275-299
M00516		S250N104-6 XMTR-RUDDER POSITION	251T3010 81205	1	27-28-11 / /	155-157, 166-199, 277-299
M00516	1	S250N104-6 XMTR-RUDDER POSITION	251T3010 81205	1	27-28-11 / /	050-099, 150-154, 162-165, 275-276

EQUIPMENT LIST

D280T132

Section M00500

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00516	2	S250N104-4 XMTR-RUDDER POSITION	251T3010 81205	1	27-28-11 / /	050-099, 150-154, 162-165, 275-276
M00517		S250N104-6 XMTR-ELEVATOR POSITION,LEFT INBD	251T2010 81205	1	27-38-11 SL066/014/RS	155-157, 166-199, 277-299
M00517	1	S250N104-6 XMTR-ELEVATOR POSITION,LEFT INBD	251T2010 81205	1	27-38-11 SL066/014/RS	050-099, 150-154, 162-165, 275-276
M00517	2	S250N104-4 XMTR-ELEVATOR POSITION,LEFT INBD	251T2010 81205	1	27-38-11 SL066/014/RS	050-099, 150-154, 162-165, 275-276
M00518		S250N104-6 XMTR-ELEVATOR POSITION,RIGHT INBD	251T2010 81205	1	27-38-11 SR069/014/RS	155-157, 166-199, 277-299
M00518	1	S250N104-6 XMTR-ELEVATOR POSITION,RIGHT INBD	251T2010 81205	1	27-38-11 SR069/014/RS	050-099, 150-154, 162-165, 275-276
M00518	2	S250N104-4 XMTR-ELEVATOR POSITION,RIGHT INBD	251T2010 81205	1	27-38-11 SR069/014/RS	050-099, 150-154, 162-165, 275-276
M00519		S251T440-11 MODULE-POSITION TRANSMITTER,L STAB	251T4400 81205	1	27-58-21 1726/182/L026	050-099
M00519		S251T440-10 MODULE-POSITION TRANSMITTER,L STAB	251T4400 81205	1	27-58-21 1726/182/L026	150-199, 275-299
M00520		S251T440-11 MODULE-POSITION TRANSMITTER,R STAB	251T4400 81205	1	27-58-21 1726/182/R002	050-099
M00520		S251T440-10 MODULE-POSITION TRANSMITTER,R STAB	251T4400 81205	1	27-58-21 1726/182/R002	150-199, 275-299
M00521		S251T440-11 MODULE-POSITION TRANSMITTER,C STAB	251T4400 81205	1	27-58-21 1726/182/L010	050-099
M00521		S251T440-10 MODULE-POSITION TRANSMITTER,C STAB	251T4400 81205	1	27-58-21 1726/182/L010	150-199, 275-299
M00522	9	285T0013-125 MODULE-LEFT YAW DAMPER (SB 22-0062)	284T0400 81205	1	22-21-11 SHELF/E01/01	ALL
M00522	7	285T0013-110 MODULE-LEFT YAW DAMPER	284T0400 81205	1	22-21-11 SHELF/E01/01	ALL
M00522	6	285T0013-108 MODULE-LEFT YAW DAMPER	284T0400 81205	1	22-21-11 SHELF/E01/01	ALL
M00522	5	285T0013-107 MODULE-LEFT YAW DAMPER	284T0400 81205	1	22-21-11 SHELF/E01/01	ALL

EQUIPMENT LIST

D280T132

Section M00500

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00522	1	285T0013-124 MODULE-LEFT YAW DAMPER	284T0400 81205	1	22-21-11 SHELF/E01/01	ALL
M00522	2	285T0013-123 MODULE-LEFT YAW DAMPER	284T0400 81205	1	22-21-11 SHELF/E01/01	ALL
M00522	3	285T0013-122 MODULE-LEFT YAW DAMPER	284T0400 81205	1	22-21-11 SHELF/E01/01	ALL
M00522	4	285T0013-109 MODULE-LEFT YAW DAMPER	284T0400 81205	1	22-21-11 SHELF/E01/01	ALL
M00523	9	285T0013-125 MODULE-RIGHT YAW DAMPER (SB 22-0062)	284T0400 81205	1	22-21-21 SHELF/E02/01	ALL
M00523	7	285T0013-110 MODULE-RIGHT YAW DAMPER	284T0400 81205	1	22-21-21 SHELF/E02/01	ALL
M00523	6	285T0013-108 MODULE-RIGHT YAW DAMPER	284T0400 81205	1	22-21-21 SHELF/E02/01	ALL
M00523	5	285T0013-107 MODULE-RIGHT YAW DAMPER	284T0400 81205	1	22-21-21 SHELF/E02/01	ALL
M00523	1	285T0013-124 MODULE-RIGHT YAW DAMPER	284T0400 81205	1	22-21-21 SHELF/E02/01	ALL
M00523	2	285T0013-123 MODULE-RIGHT YAW DAMPER	284T0400 81205	1	22-21-21 SHELF/E02/01	ALL
M00523	3	285T0013-122 MODULE-RIGHT YAW DAMPER	284T0400 81205	1	22-21-21 SHELF/E02/01	ALL
M00523	4	285T0013-109 MODULE-RIGHT YAW DAMPER	284T0400 81205	1	22-21-21 SHELF/E02/01	ALL
M00524	8	285T0015-109 MODULE LEFT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-11 SHELF/E01/01	ALL
M00524	7	285T0015-110 MODULE LEFT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-11 SHELF/E01/01	ALL
M00524	6	285T0015-111 MODULE LEFT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-11 SHELF/E01/01	ALL
M00524	5	285T0015-107 MODULE LEFT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-11 SHELF/E01/01	ALL
M00524	1	285T0015-116 MODULE LEFT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-11 SHELF/E01/01	ALL

EQUIPMENT LIST

D280T132

Section M00500

Page 3

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00524	2	285T0015-117 MODULE LEFT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-11 SHELF/E01/01	ALL
M00524	3	285T0015-114 MODULE LEFT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-11 SHELF/E01/01	ALL
M00524	4	285T0015-113 MODULE LEFT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-11 SHELF/E01/01	ALL
M00525	8	285T0015-109 MODULE RIGHT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-21 SHELF/E02/01	ALL
M00525	7	285T0015-110 MODULE RIGHT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-21 SHELF/E02/01	ALL
M00525	6	285T0015-111 MODULE RIGHT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-21 SHELF/E02/01	ALL
M00525	5	285T0015-107 MODULE RIGHT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-21 SHELF/E02/01	ALL
M00525	1	285T0015-116 MODULE RIGHT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-21 SHELF/E02/01	ALL
M00525	2	285T0015-117 MODULE RIGHT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-21 SHELF/E02/01	ALL
M00525	3	285T0015-114 MODULE RIGHT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-21 SHELF/E02/01	ALL
M00525	4	285T0015-113 MODULE RIGHT-STAB TRIM/AILERON LOCKOUT	284T0400 81205	1	27-41-21 SHELF/E02/01	ALL
M00528	1	285T0014-104 MODULE LEFT-RUDDER RATIO CHANGER	284T0400 81205	1	27-21-12 SHELF/E01/01	ALL
M00528	2	285T0014-103 MODULE LEFT-RUDDER RATIO CHANGER	284T0400 81205	1	27-21-12 SHELF/E01/01	ALL
M00528	3	285T0014-102 MODULE LEFT-RUDDER RATIO CHANGER	284T0400 81205	1	27-21-12 SHELF/E01/01	ALL
M00529	1	285T0014-104 MODULE RIGHT-RUDDER RATIO CHANGER	284T0400 81205	1	27-21-22 SHELF/E02/01	ALL
M00529	2	285T0014-103 MODULE RIGHT-RUDDER RATIO CHANGER	284T0400 81205	1	27-21-22 SHELF/E02/01	ALL
M00529	3	285T0014-102 MODULE RIGHT-RUDDER RATIO CHANGER	284T0400 81205	1	27-21-22 SHELF/E02/01	ALL

EQUIPMENT LIST

D280T132

Section M00500

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00530	1	285T0012-115 MODULE 1L-SPOILER CONT	284T0400 81205	1	27-61-14 SHELF/E01/01	ALL
M00530	2	285T0012-116 MODULE 1L-SPOILER CONT	284T0400 81205	1	27-61-14 SHELF/E01/01	ALL
M00531	1	285T0012-115 MODULE 2L-SPOILER CONT	284T0400 81205	1	27-61-15 SHELF/E01/01	ALL
M00531	2	285T0012-116 MODULE 2L-SPOILER CONT	284T0400 81205	1	27-61-15 SHELF/E01/01	ALL
M00532	1	285T0012-115 MODULE 3L-SPOILER CONT	284T0400 81205	1	27-61-16 SHELF/E01/01	ALL
M00532	2	285T0012-116 MODULE 3L-SPOILER CONT	284T0400 81205	1	27-61-16 SHELF/E01/01	ALL
M00533	1	285T0012-115 MODULE 1R-SPOILER CONT	284T0400 81205	1	27-61-13 SHELF/E02/01	ALL
M00533	2	285T0012-116 MODULE 1R-SPOILER CONT	284T0400 81205	1	27-61-13 SHELF/E02/01	ALL
M00534	1	285T0012-115 MODULE 2R-SPOILER CONT	284T0400 81205	1	27-61-17 SHELF/E02/01	ALL
M00534	2	285T0012-116 MODULE 2R-SPOILER CONT	284T0400 81205	1	27-61-17 SHELF/E02/01	ALL
M00535	1	285T0012-115 MODULE 3R-SPOILER CONT	284T0400 81205	1	27-61-18 SHELF/E02/01	ALL
M00535	2	285T0012-116 MODULE 3R-SPOILER CONT	284T0400 81205	1	27-61-18 SHELF/E02/01	ALL
M00536		285T0017-104 MODULE 1L-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E01/01	050-099, 155-199, 276-299
M00536	1	285T0017-104 MODULE 1L-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E01/01	150-154, 275
M00536	2	285T0017-103 MODULE 1L-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E01/01	150-154, 275
M00536	3	285T0017-102 MODULE 1L-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E01/01	150-154, 275
M00537		285T0017-104 MODULE 2L-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E01/01	050-099, 155-199, 276-299

EQUIPMENT LIST

D280T132

Section M00500

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00537	1	285T0017-104 MODULE 2L-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E01/01	150-154, 275
M00537	2	285T0017-103 MODULE 2L-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E01/01	150-154, 275
M00537	3	285T0017-102 MODULE 2L-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E01/01	150-154, 275
M00538		285T0017-104 MODULE 1R-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E02/01	050-099, 155-199, 276-299
M00538	1	285T0017-104 MODULE 1R-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E02/01	150-154, 275
M00538	2	285T0017-103 MODULE 1R-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E02/01	150-154, 275
M00538	3	285T0017-102 MODULE 1R-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E02/01	150-154, 275
M00539		285T0017-104 MODULE 2R-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E02/01	050-099, 155-199, 276-299
M00539	1	285T0017-104 MODULE 2R-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E02/01	150-154, 275
M00539	2	285T0017-103 MODULE 2R-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E02/01	150-154, 275
M00539	3	285T0017-102 MODULE 2R-CSEU POWER SUPPLY	284T0400 81205	1	27-09-11 SHELF/E02/01	150-154, 275
M00540	1	10167-3-BT MODULE-TIME DELAY,CTR BUS	284T0997 08719	1	24-51-31 P006-01/ /	ALL
M00540	2	10167-3000-BT MODULE-TIME DELAY,CTR BUS	284T0997 08719	1	24-51-31 P006-01/ /	ALL
M00544	1	S256T002-3 XMTR NO.1-PDU POSITION,OUTBD SLATS	256T2760 81205	1	27-81-31 0776/152/L110	ALL
M00544	2	S256T002-1 XMTR NO.1-PDU POSITION,OUTBD SLATS	256T2760 81205	1	27-81-31 0776/152/L110	ALL
M00545	9	285T0049-53 FLAPS/SLATS ELECTRONIC UNIT (SB 27-0108)	284T0400 81205	1	27-51-61 SHELF/E02/04	050-099, 150-166, 275-277
M00545	1	285T0049-63 FLAPS/SLATS ELECTRONIC UNIT	284T0400 81205	1	27-51-61 SHELF/E02/04	167-199, 278-299

EQUIPMENT LIST

D280T132

Section M00500

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00545	2	285T0049-53 FLAPS/SLATS ELECTRONIC UNIT	284T0400 81205	1	27-51-61 SHELF/E02/04	167-199, 278-299
M00547	1	S256T011-1 DRIVE MOTOR-TE FLAP	256T3110 81205	1	27-51-11 WHEEL/ /WELL	ALL
M00547	2	S256T004-11 DRIVE MOTOR-TE FLAP	256T3110 81205	1	27-51-11 WHEEL/ /WELL	ALL
M00548	9	S256T002-11 XMTR NO.2-PDU POS,OUTBD SLATS(SB27-0108)	256T2660 81205	1	27-81-21 0776/152/L110	050-099, 150-166, 275-277
M00548		S256T002-11 XMTR NO.2-PDU POSITION,OUTBD SLATS	256T2660 81205	1	27-81-21 0776/152/L110	167-199, 278-299
M00549	1	S256T002-3 XMTR NO.2-PDU POSITION,INBD SLATS	256T2760 81205	1	27-81-11 0775/173/R109	ALL
M00549	2	S256T002-1 XMTR NO.2-PDU POSITION,INBD SLATS	256T2760 81205	1	27-81-11 0775/173/R109	ALL
M00555		S452T201-3 ACTR 2M-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/0000	050-099, 150-154, 162, 275-276
M00555	1	S452T202-1 ACTR 2M-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/0000	155-157, 163-199, 277-299
M00555	2	S452T201-3 ACTR 2M-AFT LATL GUIDE	452T2603 81205	1	25-53-25 1339/124/0000	155-157, 163-199, 277-299
M00556		S452T201-3 ACTR 2-LD3 GUIDE	452T1202 81205	1	25-53-26 1324/122/R004	050-099, 150-154, 162, 275-276
M00556		S452T202-1 ACTR 2-LD3 GUIDE	452T1202 81205	1	25-53-26 1324/122/R004	155-157, 163-199, 277-278
M00556	1	S452T202-1 ACTR 2-LD3 GUIDE	452T1202 81205	1	25-53-26 1324/122/R004	155-157, 163-199, 277-278
M00556	2	S452T201-3 ACTR 2-LD3 GUIDE	452T1202 81205	1	25-53-26 1324/122/R004	155-157, 163-199, 277-299
M00557		S452T201-3 ACTR 2-LD2 GUIDE	452T1201 81205	1	25-53-26 1324/122/L009	050-099, 150-154, 162, 275-276
M00557	1	S452T202-1 ACTR 2-LD2 GUIDE	452T1201 81205	1	25-53-26 1324/122/L009	155-157, 163-199, 277-299
M00557	2	S452T201-3 ACTR 2-LD2 GUIDE	452T1201 81205	1	25-53-26 1324/122/L009	155-157, 163-199, 277-299

EQUIPMENT LIST

D280T132

Section M00500

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00558		S452T201-3 ACTR 1M-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/0000	050-099, 150-154, 162, 275-276
M00558	1	S452T202-1 ACTR 1M-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/0000	155-157, 163-199, 277-299
M00558	2	S452T201-3 ACTR 1M-FWD LATL GUIDE	452T2603 81205	1	25-53-25 1277/124/0000	155-157, 163-199, 277-299
M00559		S451T201-7 PDU 9R-AFT CARGO	451T2002 81205	1	25-53-24 1384/124/R029	050-099
M00559	1	S451T201-12 PDU 9R-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/R037	155-156, 162-166
M00559	2	S451T201-7 PDU 9R-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/R037	155-156, 162-166
M00560		S451T201-7 PDU 6C-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/R009	050-099
M00568		S452T201-3 ACTR 1-ROLLOUT STOP	451T1702 81205	1	25-53-27 1292/120/R048	050-099, 150-154, 162
M00568	1	S452T202-1 ACTR 1-ROLLOUT STOP	451T1702 81205	1	25-53-27 1292/120/R048	155-157, 163-199
M00568	2	S452T201-3 ACTR 1-ROLLOUT STOP	451T1702 81205	1	25-53-27 1292/120/R048	155-157, 163-199
M00569		S452T201-3 ACTR 2-ROLLOUT STOP	451T1702 81205	1	25-53-27 1324/120/R048	050-099, 150-155, 162
M00569	1	S452T202-1 ACTR 2-ROLLOUT STOP	451T1702 81205	1	25-53-27 1324/120/R048	156-157, 163-199
M00569	2	S452T201-3 ACTR 2-ROLLOUT STOP	451T1702 81205	1	25-53-27 1324/120/R048	156-157, 163-199
M00570	1	S283T012-25 PWR SUPPLY-ANTI-COLL LT,UPR	284T0232 81205	1	33-44-11 0565/294/L026	ALL
M00570	2	S283T012-22 PWR SUPPLY-ANTI-COLL LT,UPR	284T0232 81205	1	33-44-11 0565/294/L026	ALL
M00571	9	S283T012-25 PWR SUPPLY-ANTI-COLL LT,LWR (SB 33-0030)	284T0232 81205	1	33-44-11 0950/129/R024	150-152
M00571	1	S283T012-25 PWR SUPPLY-ANTI-COLL LT,LWR	284T0232 81205	1	33-44-11 0950/129/R024	050-099, 153-199, 275-299

EQUIPMENT LIST

D280T132

Section M00500

Page 8

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00571	2	S283T012-22 PWR SUPPLY-ANTI-COLL LT,LWR	284T0232 81205	1	33-44-11 0950/129/R024	050-099, 153-199, 275-299
M00576		60B80032-3 ACTR-FLAP LOAD RELIEF	256T1300 81205	1	27-51-51 1067/175/R007	ALL
M00577	1	S253T402-3 ACTR-AUTO. SPEED BRAKE	253T1200 81205	1	27-62-11 P010-00/ /	ALL
M00577	2	S253T402-1 ACTR-AUTO. SPEED BRAKE	253T1200 81205	1	27-62-11 P010-00/ /	ALL
M00586	1	S344T002-5 CONT PC ASSY-FUEL LEVEL SENSOR	284T0049 81205	1	28-21-12 P050-00/ /	ALL
M00586	2	S344T002-4 CONT PC ASSY-FUEL LEVEL SENSOR	284T0049 81205	1	28-21-12 P050-00/ /	ALL
M00588	1	S283T012-25 POWER SUPPLY-ANTI-COLLISION LIGHT,L	284T0224 81205	1	33-44-21 L1128/14/TIP	ALL
M00588	2	S283T012-22 POWER SUPPLY-ANTI-COLLISION LIGHT,L	284T0224 81205	1	33-44-21 L1128/14/TIP	ALL
M00589	1	S283T012-25 POWER SUPPLY-ANTI-COLLISION LIGHT,R	284T0224 81205	1	33-44-21 R1128/14/TIP	ALL
M00589	2	S283T012-22 POWER SUPPLY-ANTI-COLLISION LIGHT,R	284T0224 81205	1	33-44-21 R1128/14/TIP	ALL
M00590	1	285T0096-17 PC ASSY-EEC DISCRETES,L ENGINE	284T0049 81205	1	73-21-11 P050-00/ /	050-099, 150-199, 277-299
M00590	1	285T0096-17 PC ASSY-EEC DISCRETES,L ENGINE	284T0049 81205	1	73-21-17 P050-00/ /	275-276
M00590	2	285T0096-13 PC ASSY-EEC DISCRETES,L ENGINE	284T0049 81205	1	73-21-11 P050-00/ /	050-099, 150-199, 277-299
M00590	2	285T0096-13 PC ASSY-EEC DISCRETES,L ENGINE	284T0049 81205	1	73-21-17 P050-00/ /	275-276
M00591	1	285T0096-17 PC ASSY-EEC DISCRETES,R ENGINE	284T0049 81205	1	73-21-11 P050-00/ /	050-099, 150-199, 277-299
M00591	1	285T0096-17 PC ASSY-EEC DISCRETES,R ENGINE	284T0049 81205	1	73-21-17 P050-00/ /	275-276
M00591	2	285T0096-13 PC ASSY-EEC DISCRETES,R ENGINE	284T0049 81205	1	73-21-11 P050-00/ /	050-099, 150-199, 277-299

EQUIPMENT LIST

D280T132

Section M00500

Page 9

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00591	2	285T0096-13 PC ASSY-EEC DISCRETES,R ENGINE	284T0049 81205	1	73-21-17 P050-00/ /	275-276
M00596		S345T002-27 UNIT-DENSITOMETER,L MAIN TANK	345T0002 81205	1	28-41-21 L WING/ /	ALL
M00597		S345T002-27 UNIT-DENSITOMETER,R MAIN TANK	345T0002 81205	1	28-41-22 R WING/ /	ALL
M00598		S417T102-1 VACUUM BLOWER-LAV	417T1325 81205	1	38-32-11 1570/185/L040	ALL
M00599		S417T102-1 VACUUM BLOWER-LAV	417T1325 81205	1	38-32-11 1551/193/L035	ALL

EQUIPMENT LIST

D280T132

Section M00500
Page 10 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00603	1	S256T002-6 XMTR-FLAP LEVER POSITION NO.2	253T5700 81205	1	27-51-31 P010-00/ /	ALL
M00603	2	S256T002-4 XMTR-FLAP LEVER POSITION NO.2	253T5700 81205	1	27-51-31 P010-00/ /	ALL
M00603	3	S256T002-2 XMTR-FLAP LEVER POSITION NO.2	253T5700 81205	1	27-51-31 P010-00/ /	ALL
M00604	1	S256T002-6 XMTR-FLAP LEVER POSITION NO.1	253T5700 81205	1	27-58-31 P010-00/ /	ALL
M00604	2	S256T002-4 XMTR-FLAP LEVER POSITION NO.1	253T5700 81205	1	27-58-31 P010-00/ /	ALL
M00604	3	S256T002-2 XMTR-FLAP LEVER POSITION NO.1	253T5700 81205	1	27-58-31 P010-00/ /	ALL
M00605		S256T007-7 XMTR-REF SIGNAL,SLATS RETRACTED	284T0189 81205	1	27-58-11 P033-00/ /	ALL
M00606		S256T007-8 XMTR-REF SIGNAL,SLATS INTMD	284T0189 81205	1	27-58-11 P033-00/ /	ALL
M00613	1	S258T711-6 MOTOR-RAM AIR TURBINE GEAR	258T7100 81205	1	29-21-31 1155/129/R075	ALL
M00613	2	S258T711-5 MOTOR-RAM AIR TURBINE GEAR	258T7100 81205	1	29-21-31 1155/129/R075	ALL
M00614		S258T710-10 RAM-AIR TURBINE (SEE YEN)	258T7100 81205	1	29-21-31 1155/129/R075	ALL
M00615	9	285T1104-17 MODULE-STALL WARNING,LEFT (SB 27-0098)	284T0049 81205	1	27-32-11 P051-00/ /	150-152
M00615		285T1104-17 MODULE-STALL WARNING,LEFT	284T0049 81205	1	27-32-11 P051-00/ /	050-099, 153-199, 275-299
M00616		285T0035-10 MODULE-POWER SUPPLY A	284T0049 81205	1	31-51-11 P051-00/ /	050-099, 150-156, 162-166, 275-276
M00616		285T0035-11 MODULE-POWER SUPPLY A	284T0049 81205	1	31-51-11 P051-00/ /	157, 167-199, 277- 299
M00617	9	285T0030-26 MODULE-ALTITUDE ALERT (SB 34-0493)	284T5100 81205	1	34-16-11 P051-00/ /	154, 156
M00617		285T0030-14 MODULE-ALTITUDE ALERT	284T0049 81205	1	34-16-11 P051-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section M00600

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00617		285T0030-16 MODULE-ALTITUDE ALERT	284T0049 81205	1	34-16-11 P051-00/ /	275-299
M00618		285T0032-19 MODULE-MASTER WARNING	284T0049 81205	1	31-51-21 P051-00/ /	ALL
M00619		285T0034-21 MODULE-SIREN OWL AMPLIFIER,RIGHT	284T0049 81205	1	31-51-32 P051-00/ /	050-099, 150-154, 162, 275-276
M00619		285T0034-25 MODULE-SIREN OWL AMPLIFIER,RIGHT	284T0049 81205	1	31-51-32 P051-00/ /	155-157, 163-199, 277-299
M00620		285T0259-19 MODULE-CONFIGURATION WARNING (T/O)	284T0049 81205	1	31-51-41 P051-00/ /	050-099, 155-199, 276-299
M00620		285T0259-17 MODULE-CONFIGURATION WARNING (T/O)	284T0049 81205	1	31-51-41 P051-00/ /	150-154, 275
M00621		285T0035-10 MODULE-POWER SUPPLY B	284T0049 81205	1	31-51-12 P051-00/ /	050-099, 150-156, 162-166, 275-276
M00621		285T0035-11 MODULE-POWER SUPPLY B	284T0049 81205	1	31-51-12 P051-00/ /	157, 167-199, 277- 299
M00626	5	S251T360-3 ACTR-RUDDER RATIO CHANGER	251T3600 81205	1	27-21-12 F089/ /RS	ALL
M00626	1	S251T360-7 ACTR-RUDDER RATIO CHANGER	251T3600 81205	1	27-21-12 F089/ /RS	ALL
M00626	2	S251T360-6 ACTR-RUDDER RATIO CHANGER	251T3600 81205	1	27-21-12 F089/ /RS	ALL
M00626	3	S251T360-5 ACTR-RUDDER RATIO CHANGER	251T3600 81205	1	27-21-12 F089/ /RS	ALL
M00626	4	S251T360-4 ACTR-RUDDER RATIO CHANGER	251T3600 81205	1	27-21-12 F089/ /RS	ALL
M00627		S258T140-4 PDU-ENTRY DR,FWD	258T3000 81205	1	52-11-11 0298/293/L021	ALL
M00628	1	S417T402-4 MODULE OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 0291/280/L033	050-099, 150-199
M00628	1	S417T402-4 MODULE OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 0265/280/L050	275-299
M00628	2	S417T402-3 MODULE OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 0291/280/L033	050-099, 150-199

EQUIPMENT LIST

D280T132

Section M00600

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00628	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 0265/280/L050	275-299
M00629		S140T261-10 PDU-CARGO DR HINGE,FWD	258T5000 81205	1	52-34-11 0504/183/R085	ALL
M00630	2	60B00304-4 ACTUATOR-CARGO DR LATCH,FWD	143T6302 81205	1	52-34-11 0548/130/R058	ALL
M00631	1	S140T261-11 PDU-CARGO DR HINGE,AFT	146T6211 81205	1	52-35-11 1300/200/R089	ALL
M00631	2	S140T261-9 PDU-CARGO DR HINGE,AFT	146T6211 81205	1	52-35-11 1300/200/R089	ALL
M00632	2	S140T260-3 PDU-CARGO DR LIFT/LATCH,AFT	140T2980 81205	1	52-35-11 1310/170/R080	ALL
M00635		S232T200-6 UNIT-DR LOCK,FLT DECK	232T2004 80477	1	52-51-11 0240/242/L017	050-099, 150-154, 156, 162-199
M00635		S232T200-6 UNIT-DR LOCK,FLT DECK	232T2004 80477	1	52-51-11 0260/242/L017	275
M00636		S343T002-8 PUMP-OVERRIDE,FUEL BOOST,L AUX TANK	343T0002 81205	1	28-22-12 L/ /WING	ALL
M00637		S343T002-8 PUMP-OVERRIDE,FUEL BOOST,R AUX TANK	343T0002 81205	1	28-22-12 R/ /WING	ALL
M00638		S345T002-50 CONT UNIT-LOAD SELECT	344T0020 81205	1	28-21-11 P028-00/ /	ALL
M00639		S283T018-25 BALLAST-ENTRY CEILING FLUOR LT	411T3126 81205	1	33-22-11 0329/286/L005	050-099
M00639		S283T018-25 BALLAST-ENTRY CEILING FLUOR LT	411T3126 81205	1	33-22-11 0320/282/L006	150-199
M00639		S283T018-25 BALLAST-ENTRY CEILING FLUOR LT	411T3126 81205	1	33-22-11 0353/286/L049	275-299
M00642		S220T111-201 ZONE MULTIPLEXER-FWD	284T0686 54473	1	23-34-14 0305/195/R025	050-099
M00642		S220T111-201 ZONE MULTIPLEXER-FWD	284T0686 54473	1	23-34-11 0305/195/R025	150-199
M00642		S220T111-201 ZONE MULTIPLEXER-FWD	284T0686 54473	1	23-34-17 0305/195/R025	275-299

EQUIPMENT LIST

D280T132

Section M00600

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00648		S283T018-25 BALLAST-M1 MID-CABIN GALLEY	417T5072 81205	1	33-27-11 0842/284/R006	275-299
M00649		S283T018-25 BALLAST-M1 MID-CABIN GALLEY	417T5072 81205	1	33-27-11 0838/284/R006	275-299
M00650		S283T018-27 BALLAST-FWD GALLEY	417T5072 81205	1	33-27-11 0284/284/R028	ALL
M00651		S283T018-27 BALLAST-FWD GALLEY	417T5072 81205	1	33-27-11 0281/284/R028	ALL
M00652		S283T018-26 BALLAST-AFT GALLEY	417T5072 81205	1	33-27-11 1576/284/L014	ALL
M00653		S283T018-26 BALLAST-AFT GALLEY	417T5072 81205	1	33-27-11 1576/284/R014	ALL
M00654		S283T018-30 BALLAST-AFT GALLEY	417T5072 81205	1	33-27-11 1567/284/R032	ALL
M00655		S283T018-30 BALLAST-AFT GALLEY	417T5072 81205	1	33-27-11 1567/284/L032	ALL
M00656		S283T018-31 BALLAST-FLIGHT DECK ENTRY LT	417T5026 81205	1	33-22-41 0284/283/L048	ALL
M00658		S283T018-33 BALLAST-FWD DIRECT CEILING LTS	417T5058 81205	1	33-22-41 0335/283/R006	050-099, 150-199, 275-278
M00658		S283T018-33 BALLAST-FWD DIRECT CEILING LTS	417T5058 81205	1	33-22-41 0334/283/R006	280-299
M00659		S283T018-31 BALLAST-FWD DIRECT CEILING LTS	417T5058 81205	1	33-22-41 0335/280/L006	050-099, 150-199, 275-278
M00659		S283T018-31 BALLAST-FWD DIRECT CEILING LTS	417T5058 81205	1	33-22-41 0334/280/L006	280-299
M00660		S283T018-32 BALLAST-FWD DIRECT CEILING LTS	417T5058 81205	1	33-22-41 0335/283/0000	050-099, 150-199, 275-278
M00660		S283T018-32 BALLAST-FWD DIRECT CEILING LTS	417T5058 81205	1	33-22-41 0334/280/R006	280-299
M00661		S283T018-34 BALLAST-AFT DIRECT CEILING LTS	417T5058 81205	1	33-22-42 1526/280/L006	050-099
M00662		S283T018-32 BALLAST-AFT DIRECT CEILING LTS	417T5058 81205	1	33-22-42 1526/284/R006	050-099

EQUIPMENT LIST

D280T132

Section M00600

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00663		S283T018-34 BALLAST-AFT DIRECT CEILING LTS	417T5058 81205	1	33-22-42 1461/280/L040	275-299
M00664		S283T018-32 BALLAST-AFT DIRECT CEILING LTS	417T5058 81205	1	33-22-42 1455/280/L034	275-299
M00665		S283T018-32 BALLAST-AFT DIRECT CEILING LTS	417T5058 81205	1	33-22-42 1455/280/R040	275-299
M00669		S283T018-26 BALLAST-INDIRECT CEILING LTS,FWD	417T2578 81205	1	33-21-11 0481/295/L020	275-299
M00670		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T2578 81205	1	33-21-11 0489/295/L020	ALL
M00671		S283T018-26 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0433/295/L056	275-299
M00672		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0521/295/L056	050-099
M00672		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0526/290/L056	150-199, 275-299
M00673		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0615/295/L020	050-099, 150-199
M00673		S283T018-24 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0615/295/L020	275-299
M00674		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0623/295/L020	050-099
M00674		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-13 0654+99/295/L020	150-199
M00674		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-13 0734/295/L020	275-299
M00677		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0609/295/L056	050-099
M00677		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0606/295/L056	150-199
M00677		S283T018-24 BALLAST-INDIRECT CEILING LTS,FWD	417T5081 81205	1	33-21-11 0609/295/L056	275-299
M00678		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	413T1008 81205	1	33-21-11 0697/295/L056	050-099

EQUIPMENT LIST

D280T132

Section M00600

Page 5

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00678		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	413T1008 81205	1	33-21-13 0654+84/295/L056	150-199
M00678		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	413T1008 81205	1	33-21-13 0741/290/L056	275-278
M00678		S283T018-16 BALLAST-INDIRECT CEILING LTS,FWD	413T1008 81205	1	33-21-13 0672/295/L056	280-299
M00681		S332T301-75 CARD-FIRE DET LEFT,LOOP 1	284T0049 81205	1	26-11-11 P054-00/ /	ALL
M00682		S332T301-75 CARD-FIRE DET LEFT,LOOP 2	284T0049 81205	1	26-11-11 P054-00/ /	ALL
M00683		S332T301-75 CARD-FIRE DET RIGHT,LOOP 1	284T0049 81205	1	26-11-21 P054-00/ /	ALL
M00684		S332T301-75 CARD-FIRE DET RIGHT,LOOP 2	284T0049 81205	1	26-11-21 P054-00/ /	ALL
M00685		S332T301-75 CARD-FIRE DET APU,LOOP 1	284T0049 81205	1	26-15-11 P054-00/ /	ALL
M00686		S332T301-75 CARD-FIRE DET APU,LOOP 2	284T0049 81205	1	26-15-11 P054-00/ /	ALL
M00687		S332T301-75 CARD-OVHT DET LEFT,LOOP 1	284T0049 81205	1	26-11-12 P054-00/ /	ALL
M00688		S332T301-75 CARD-OVHT DET LEFT,LOOP 2	284T0049 81205	1	26-11-12 P054-00/ /	ALL
M00689		S332T301-75 CARD-OVHT DET RIGHT,LOOP 1	284T0049 81205	1	26-11-22 P054-00/ /	ALL
M00690		S332T301-75 CARD-OVHT DET RIGHT,LOOP 2	284T0049 81205	1	26-11-22 P054-00/ /	ALL
M00691		S283T004-1 CARD-DUCT LEAK AND WHEEL WELL FIRE	284T5400 81205	1	26-18-11 P054-00/ /	ALL
M00692		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 0785/295/L056	050-099
M00692		S283T018-28 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 1014/295/L056	150-199
M00692		S283T018-28 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 0754/295/L056	275-299

EQUIPMENT LIST

D280T132

Section M00600

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00693		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 0872/295/L056	050-099, 275-299
M00693		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 0910/295/L056	150-199
M00694		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 0998/295/L056	050-099
M00694		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 0829/295/L056	150-199
M00694		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 0952/290/L056	275-299
M00695		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	413T1008 81205	1	33-21-14 1086/295/L056	050-099
M00695		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	413T1008 81205	1	33-21-14 0996/295/L056	150-199
M00695		S283T018-24 BALLAST-INDIRECT CEILING LTS,AFT	413T1008 81205	1	33-21-14 1042/295/L056	275-299
M00696		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	413T1008 81205	1	33-21-14 1174/295/L056	050-099
M00696		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	413T1008 81205	1	33-21-14 1127/295/L056	150-199, 275-299
M00697		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	413T1008 81205	1	33-21-14 1259/295/L056	050-099, 150-199
M00697		S283T018-24 BALLAST-INDIRECT CEILING LTS,AFT	413T1008 81205	1	33-21-14 1270/295/L056	275-299
M00698		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 0708/295/L020	050-099
M00698		S283T018-28 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 1048/295/L020	150-199
M00698		S283T018-28 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 0747/295/L020	275-299
M00699		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 0861/295/L020	050-099
M00699		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 0911/295/L020	150-199

EQUIPMENT LIST

D280T132

Section M00600

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00699		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 0879/295/L020	275-299

EQUIPMENT LIST

D280T132

Section M00600

Page 8 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00700		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 1002/295/L020	050-099
M00700		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 0835/295/L020	150-199
M00700		S283T018-16 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 0916/295/L020	275-299
M00701		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1010/295/L020	050-099
M00701		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1004/295/L020	150-199
M00701		S283T018-24 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1004/295/L020	275-299
M00702		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1142/295/L020	050-099
M00702		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1136/295/L020	150-199, 275-299
M00703		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1266/295/L020	050-099, 150-199
M00703		S283T018-24 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1266/295/L020	275-299
M00704		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	413T1008 81205	1	33-21-14 1350/295/L056	ALL
M00705		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1274/295/L020	050-099, 275-299
M00705		S283T018-16 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1357/295/L020	150-199
M00706		S283T018-24 BALLAST-INDIRECT CEILING LTS AFT	413T1008 81205	1	33-21-14 1422/295/L056	050-099, 150-157
M00706		S283T018-24 BALLAST-INDIRECT CEILING LTS AFT	413T1008 81205	1	33-21-14 1382/295/L056	162-199
M00706		S283T018-26 BALLAST-INDIRECT CEILING LTS AFT	413T1008 81205	1	33-21-14 1422/295/L056	275-299
M00707		S283T018-24 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1406/295/L020	050-099

EQUIPMENT LIST

D280T132

Section M00700

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00707		S283T018-24 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1400/295/L020	150-199
M00707		S283T018-26 BALLAST-INDIRECT CEILING LTS,AFT	417T5081 81205	1	33-21-14 1400/295/L020	275-299
M00708		S283T018-28 BALLAST-INDIRECT CEILING LTS,MID	413T1008 81205	1	33-21-13 0917/295/L056	050-099
M00709		S283T018-28 BALLAST-INDIRECT CEILING LTS,MID	417T5081 81205	1	33-21-13 0922/295/L019	050-099
M00716		033638 BLO 1-SMOKE DET AIR FLOW,FWD CAR.	453T2101 82877	1	26-16-21 0350/165/L066	ALL
M00717		033638 BLO 2-SMOKE DET AIR FLOW,FWD CAR.	453T2101 82877	1	26-16-21 0353/164/L066	ALL
M00718		033638 BLO 1-SMOKE DET AIR FLOW,AFT CAR.	453T2201 82877	1	26-16-21 1405/150/L070	ALL
M00719		033638 BLO 2-SMOKE DET AIR FLOW,AFT CAR.	453T2201 82877	1	26-16-21 1409/150/L070	ALL
M00720		S345T002-27 UNIT-DENSITOMETER,AUX TANK	345T0002 81205	1	28-41-23 WING/ /R	ALL
M00722		S345T002-153 UNIT-BUSSING PLUG,L TANK	345T0002 81205	1	28-41-21 L/ /RS	ALL
M00723		S345T002-153 UNIT-BUSSING PLUG,R TANK	345T0002 81205	1	28-41-22 R/ /RS	ALL
M00724		S345T002-157 UNIT-BUSSING PLUG,L AUX TANK	345T0002 81205	1	28-41-23 L/ /RS	ALL
M00725		S345T002-157 UNIT-BUSSING PLUG,R AUX TANK	345T0002 81205	1	28-41-23 R/ /RS	ALL
M00726		S345T002-170 ASSEMBLY-HARNESS,L TANK	345T0002 81205	1	28-41-21 L/ /	ALL
M00727		S345T002-170 ASSEMBLY-HARNESS,R TANK	345T0002 81205	1	28-41-22 R/ /	ALL
M00728		S345T002-173 ASSEMBLY-HARNESS,L AUX TANK	345T0002 81205	1	28-41-23 L/ /	ALL
M00729		S345T002-174 ASSEMBLY-HARNESS,R AUX TANK	345T0002 81205	1	28-41-23 R/ /	ALL

EQUIPMENT LIST

D280T132

Section M00700

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00730		S283T014-3 POWER SUPPLY-EMER LTS (SEE YEW)	417T5097 81205	1	33-51-11 0533/203/R092	050-099, 150-199
M00730		S283T014-3 POWER SUPPLY-EMER LTS (SEE YEW)	417T5097 81205	1	33-51-11 0401/203/R092	275-299
M00731		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFG)	417T5097 81205	1	33-51-21 0555/203/R092	050-099, 150-199
M00731		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFG)	417T5097 81205	1	33-51-21 0423/203/R092	275-299
M00732		S283T014-3 POWER SUPPLY-EMER LTS (SEE YEX)	417T5097 81205	1	33-51-11 1010/203/R092	ALL
M00733		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFH)	417T5097 81205	1	33-51-21 1428/203/R092	050-099, 162-199
M00733		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFH)	417T5097 81205	1	33-51-21 1406/203/R092	150-157, 275-299
M00734		S283T014-3 POWER SUPPLY-EMER LTS (SEE YEY)	417T5097 81205	1	33-51-11 1384/203/R092	ALL
M00735		S283T014-3 POWER SUPPLY-EMER LTS (SEE YEZ)	417T5097 81205	1	33-51-11 0511/203/L092	050-099
M00735		S283T014-3 POWER SUPPLY-EMER LTS (SEE YEZ)	417T5097 81205	1	33-51-11 0445/203/L092	150-199, 275-299
M00736		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFI)	417T5097 81205	1	33-51-21 0577/203/L092	050-099
M00736		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFI)	417T5097 81205	1	33-51-21 0511/203/L092	150-199
M00736		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFI)	417T5097 81205	1	33-51-21 0467/203/L092	275-299
M00737		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFA)	417T5097 81205	1	33-51-11 0922/203/L092	050-099
M00737		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFA)	417T5097 81205	1	33-51-11 1032/203/L092	150-199
M00737		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFA)	417T5097 81205	1	33-51-11 0988/203/L092	275-299
M00738		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFJ)	417T5097 81205	1	33-51-21 1340/203/L092	ALL

EQUIPMENT LIST

D280T132

Section M00700

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00739		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFB)	417T5097 81205	1	33-51-11 1362/203/L092	ALL
M00744		10-60091-100 MTG PLATE-EXIT LT	232T4105 81205	1	33-51-11 0240/270/L032	ALL
M00745		S283T018-27 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0446/280/L056	151-152
M00745		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0446/290/L056	275-299
M00746		S283T018-33 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0439/280/R056	050-099, 166-199
M00746		S283T018-27 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0446/280/R056	151-152, 157
M00746		S283T018-33 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0446/280/R056	162-165
M00746		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0439/280/R056	275-278
M00746		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0433/280/R056	280-299
M00747	9	S283T183-27 BALLAST-SIDEWALL LTS (SB 33-0046)	413T1008 30242	1	33-21-33 0446/280/R056	162-163
M00747		S283T018-27 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0446/280/R056	050-099, 164-199
M00747		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0446/280/R056	150-157, 275-299
M00748		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0534/280/L056	050-099
M00748		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0534/290/L056	150-199, 275-299
M00749		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0534/280/R056	ALL
M00750		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0622/288/L056	ALL
M00751		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0622/288/R056	050-099, 150-199, 275-278

EQUIPMENT LIST

D280T132

Section M00700

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00752		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0710/288/L056	050-099
M00752		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0738/288/L056	150-199
M00752		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0666/288/L056	275-278
M00752		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0677/288/L056	280-299
M00753		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0798/288/L056	050-099
M00753		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0842/288/L056	150-199
M00753		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0793/288/L056	275-299
M00754		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0842/288/R056	150-199
M00755		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 0879/288/L056	050-099
M00755		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 0923/288/L056	150-199
M00755		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 0961/288/L056	275-299
M00756		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 0879/288/R056	050-099
M00756		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 0923/288/R056	150-199
M00756		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 0961/288/R056	275-299
M00757		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1011/288/L056	050-099
M00757		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1012/288/R056	150-199
M00757		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 0967/288/L056	275-299

EQUIPMENT LIST

D280T132

Section M00700

Page 5

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00758		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 0967/288/R056	275-299
M00759		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1099/288/L056	050-099
M00759		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1006/288/L056	150-199
M00759		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1055/288/L056	275-299
M00760		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1099/288/R056	050-099
M00760		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1050/288/R056	150-199
M00760		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1055/288/R056	275-299
M00761		S283T018-28 BALLAST-SIDEWALL LTS	417T5081 81205	1	33-21-34 1187/288/L056	050-099
M00761		S283T018-28 BALLAST-SIDEWALL LTS	417T5081 81205	1	33-21-34 1143/288/L056	150-199, 275-299
M00762		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1187/288/R056	050-099
M00762		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1143/288/R056	150-199, 275-299
M00763		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1275/288/L056	ALL
M00764		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1275/288/R056	ALL
M00765		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1363/288/L056	ALL
M00766		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1363/288/R056	ALL
M00767		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0710/280/R056	050-099
M00767		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0747/280/R056	150-199

EQUIPMENT LIST

D280T132

Section M00700

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00767		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0754/280/R056	275-299
M00769		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 0923/288/L056	050-099
M00769		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 0908/288/L056	150-199
M00769		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 0880/288/L056	275-299
M00771	9	S283T018-27 BALLAST-SIDEWALL LTS (MTO 330370)	CUSTOMER 81205	1	33-21-34 1391/288/L056	150-157
M00771		S283T018-27 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1428/288/L056	050-099
M00771		S283T018-28 BALLAST-SIDEWALL LTS	417T5081 81205	1	33-21-34 1429/288/L056	150-157
M00771		S283T018-27 BALLAST-SIDEWALL LTS	417T5081 81205	1	33-21-34 1391/288/L056	162-199
M00771		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1428/288/L056	275-299
M00778		A420-066923-00 SOLENOID-DOOR UPLATCH	141T6583 73949	1	52-11-12 0300/277/L070	ALL
M00779		S231T301-1104 MODULE-WARNING DISPLAY,DISCRETE(SEE YEJ)	233T2222 81205	1	33-16-13 P001-03/ /	ALL
M00788	1	S283T019-4 DIMMER CONTROL-INSTR & PNL LTS,CAPT	233T2402 81205	1	33-13-11 0146/217/L007	050-099, 155-199, 275-299
M00788	1	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,CAPT	233T2402 81205	1	33-13-11 0146/217/L007	150-154
M00788	2	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,CAPT	233T2402 81205	1	33-13-11 0146/217/L007	050-099, 155-199, 275-299
M00788	2	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,CAPT	233T2402 81205	1	33-13-11 0146/217/L007	150-154
M00788	3	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,CAPT	233T2402 81205	1	33-13-11 0146/217/L007	050-099, 155-199, 275-299
M00789	1	S283T019-4 DIMMER CONTROL-INSTR & PNL LTS,F/O	233T2402 81205	1	33-13-13 0150/210/R032	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section M00700

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00789	1	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,F/O	233T2402 81205	1	33-13-13 0150/210/R032	150-154
M00789	2	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,F/O	233T2402 81205	1	33-13-13 0150/210/R032	050-099, 155-199, 275-299
M00789	2	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,F/O	233T2402 81205	1	33-13-13 0150/210/R032	150-154
M00789	3	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,F/O	233T2402 81205	1	33-13-13 0150/210/R032	050-099, 155-199, 275-299
M00790	1	S283T019-4 DIMMER CONTROL-CTR INSTR PNL,PILOT	233T2402 81205	1	33-13-11 0148/213/L007	050-099, 155-199, 275-299
M00790	1	S283T019-3 DIMMER CONTROL-CTR INSTR PNL,PILOT	233T2402 81205	1	33-13-11 0148/213/L007	150-154
M00790	2	S283T019-3 DIMMER CONTROL-CTR INSTR PNL,PILOT	233T2402 81205	1	33-13-11 0148/213/L007	050-099, 155-199, 275-299
M00790	2	S283T019-2 DIMMER CONTROL-CTR INSTR PNL,PILOT	233T2402 81205	1	33-13-11 0148/213/L007	150-154
M00790	3	S283T019-2 DIMMER CONTROL-CTR INSTR PNL,PILOT	233T2402 81205	1	33-13-11 0148/213/L007	050-099, 155-199, 275-299
M00791	1	S283T019-4 DIMMER CONTROL-OVHD INST & PNL LTS,FWD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00791	1	S283T019-3 DIMMER CONTROL-OVHD INST & PNL LTS,FWD	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00791	2	S283T019-3 DIMMER CONTROL-OVHD INST & PNL LTS,FWD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00791	2	S283T019-2 DIMMER CONTROL-OVHD INST & PNL LTS,FWD	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00791	3	S283T019-2 DIMMER CONTROL-OVHD INST & PNL LTS,FWD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00792	1	S283T019-4 DIMMER CONTROL-OVHD INSTR & PNL LTS,AFT	233T4403 81205	1	33-13-16 0183/275/R011	050-099, 155-199, 275-299
M00792	1	S283T019-3 DIMMER CONTROL-OVHD INSTR & PNL LTS,AFT	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00792	2	S283T019-3 DIMMER CONTROL-OVHD INSTR & PNL LTS,AFT	233T4403 81205	1	33-13-16 0183/275/R011	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section M00700

Page 8

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00792	2	S283T019-2 DIMMER CONTROL-OVHD INSTR & PNL LTS,AFT	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00792	3	S283T019-2 DIMMER CONTROL-OVHD INSTR & PNL LTS,AFT	233T4403 81205	1	33-13-16 0183/275/R011	050-099, 155-199, 275-299
M00793	1	S283T019-4 DIMMER CONTROL-GLR SHLD INSTR & PNL LTS	233T2400 81205	1	33-13-17 0158/212/0000	050-099, 155-199, 275-299
M00793	1	S283T019-3 DIMMER CONTROL-GLR SHLD INSTR & PNL LTS	233T2400 81205	1	33-13-17 0158/212/0000	150-154
M00793	2	S283T019-3 DIMMER CONTROL-GLR SHLD INSTR & PNL LTS	233T2402 81205	1	33-13-17 0158/212/0000	050-099, 155-199, 275-299
M00793	2	S283T019-2 DIMMER CONTROL-GLR SHLD INSTR & PNL LTS	233T2402 81205	1	33-13-17 0158/212/0000	150-154
M00793	3	S283T019-2 DIMMER CONTROL-GLR SHLD INSTR & PNL LTS	233T2402 81205	1	33-13-17 0158/212/0000	050-099, 155-199, 275-299
M00794	1	S283T019-4 DIMMER CONT-AISLE STAND INST & PNL LTS	284T0773 81205	1	33-13-18 0188/206/L046	050-099, 155-199, 275-299
M00794	1	S283T019-3 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 0188/206/L046	150-154
M00794	2	S283T019-3 DIMMER CONT-AISLE STAND INST & PNL LTS	284T0773 81205	1	33-13-18 0188/206/L046	050-099, 155-199, 275-299
M00794	2	S283T019-2 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 0188/206/L046	150-154
M00794	3	S283T019-2 DIMMER CONT-AISLE STAND INST & PNL LTS	284T0773 81205	1	33-13-18 0188/206/L046	050-099, 155-199, 275-299
M00795	1	S283T019-4 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	050-099, 155-199, 275-299
M00795	1	S283T019-3 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	150-154
M00795	2	S283T019-3 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	050-099, 155-199, 275-299
M00795	2	S283T019-2 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	150-154
M00795	3	S283T019-2 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section M00700

Page 9

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00796	1	S283T019-4 DIMMER CONT-AISLE STAND INST & PNL LTS	284T0773 81205	1	33-13-18 0188/206/L042	050-099, 155-199, 275-299
M00796	1	S283T019-3 DIMMER CONT-AISLE STAND INST & PNL LTS	284T0773 81205	1	33-13-18 0188/206/L042	150-154
M00796	2	S283T019-3 DIMMER CONT-AISLE STAND INST & PNL LTS	284T0773 81205	1	33-13-18 0188/206/L042	050-099, 155-199, 275-299
M00796	2	S283T019-2 DIMMER CONT-AISLE STAND INST & PNL LTS	284T0773 81205	1	33-13-18 0188/206/L042	150-154
M00796	3	S283T019-2 DIMMER CONT-AISLE STAND INST & PNL LTS	284T0773 81205	1	33-13-18 0188/206/L042	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section M00700

Page 10 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00800	1	S283T019-4 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00800	1	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00800	2	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00800	2	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00800	3	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00801	1	S283T019-4 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00801	1	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00801	2	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00801	2	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00801	3	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 275-299
M00802	1	S283T019-4 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 0198/277/R027	050-099, 155-199, 275-299
M00802	1	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00802	2	S283T019-3 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 0198/277/R027	050-099, 155-199, 275-299
M00802	2	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 P005-00/ /	150-154
M00802	3	S283T019-2 DIMMER CONTROL-INSTR & PNL LTS,PLT OVHD	233T4403 81205	1	33-13-16 0198/277/R027	050-099, 155-199, 275-299
M00803	1	S283T019-4 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 P011-00/ /	050-099, 155-199, 275-299
M00803	1	S283T019-3 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 P011-00/ /	150-154

EQUIPMENT LIST

D280T132

Section M00800

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00803	2	S283T019-3 DIMMER CONTROL-OVHD CB PNL LTS	233T4403 81205	1	33-13-19 P011-00/ /	050-099, 155-199, 275-299
M00803	2	S283T019-2 DIMMER CONTROL-OVHD CB PNL LTS	233T4403 81205	1	33-13-19 P011-00/ /	150-154
M00803	3	S283T019-2 DIMMER CONTROL-OVHD CB PNL LTS	233T4403 81205	1	33-13-19 P011-00/ /	050-099, 155-199, 275-299
M00804	1	S283T019-4 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 P011-00/ /	050-099, 155-199, 275-299
M00804	1	S283T019-3 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 P011-00/ /	150-154
M00804	2	S283T019-3 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 P011-00/ /	050-099, 155-199, 275-299
M00804	2	S283T019-2 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 P011-00/ /	150-154
M00804	3	S283T019-2 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 P011-00/ /	050-099, 155-199, 275-299
M00805	1	S283T019-4 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 0216/291/R009	050-099, 155-199, 275-299
M00805	1	S283T019-3 DIMMER CONTROL-OVHD CB PNL LTS	233T4400 81205	1	33-13-19 P011-00/ /	150-154
M00805	2	S283T019-3 DIMMER CONTROL-OVHD CB PNL LTS	233T4403 81205	1	33-13-19 0216/291/R009	050-099, 155-199, 275-299
M00805	2	S283T019-2 DIMMER CONTROL-OVHD CB PNL LTS	233T4403 81205	1	33-13-19 P011-00/ /	150-154
M00805	3	S283T019-2 DIMMER CONTROL-OVHD CB PNL LTS	233T4403 81205	1	33-13-19 0216/291/R009	050-099, 155-199, 275-299
M00815	9	743-0241-001 CONTROL/DISTR UNIT-VIDEO (MTO 230540)	284T0807 S0293	1	23-32-11 GALLEY 3/ /	050-099
M00815		743-0241-001 CONTROL/DISTRIBUTION UNIT-VIDEO	284T0807 S0293	1	23-32-11 0447/245/L080	150-199
M00815		600004-0003 CONTROL/DISTRIBUTION UNIT-VIDEO	284T0807 S0293	1	23-32-11 0255/268/L010	275-299
M00819		700-1117-001 PROJECTOR-VIDEO,AFT	417T1005 S0293	1	23-32-11 1125/280/0000	050-099

EQUIPMENT LIST

D280T132

Section M00800

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00819		700-1117-001 PROJECTOR-VIDEO,AFT	417T1005 S0293	1	23-32-11 1070/280/0000	150-199
M00820		285T0059-4 COUPLER-VIDEO ANTENNA	284T0728 81205	1	23-32-13 F 295/569/FS	ALL
M00838		285T0099-13 MODULE-FLAP/STAB POSITION,L	284T0049 81205	1	27-58-21 P050-00/ /	050-099
M00838		285T0099-15 MODULE-FLAP/STAB POSITION,L	284T0049 81205	1	27-58-21 P050-00/ /	150-154
M00838		285T0099-17 MODULE-FLAP/STAB POSITION,L	284T0049 81205	1	27-58-21 P050-00/ /	155-199, 275-299
M00839		285T0099-13 MODULE-FLAP/STAB POSITION,C	284T0049 81205	1	27-58-21 P050-00/ /	050-099
M00839		285T0099-15 MODULE-FLAP/STAB POSITION,C	284T0049 81205	1	27-58-21 P050-00/ /	150-154
M00839		285T0099-17 MODULE-FLAP/STAB POSITION,C	284T0049 81205	1	27-58-21 P050-00/ /	155-199, 275-299
M00840		285T0099-13 MODULE-FLAP/STAB POSITION,R	284T0049 81205	1	27-58-21 P050-00/ /	050-099
M00840		285T0099-15 MODULE-FLAP/STAB POSITION,R	284T0049 81205	1	27-58-21 P050-00/ /	150-154
M00840		285T0099-17 MODULE-FLAP/STAB POSITION,R	284T0049 81205	1	27-58-21 P050-00/ /	155-199, 275-299
M00843	1	S283T019-4 DIMMER CONTROL-GLARESHIELD FLDT	233T2400 81205	1	33-11-13 0148/217/L008	050-099, 155-199, 275-299
M00843	1	S283T019-3 DIMMER CONTROL-GLARESHIELD FLDT	233T2400 81205	1	33-11-13 0148/217/L008	150-154
M00843	2	S283T019-3 DIMMER CONTROL-GLARESHIELD FLDT	233T2400 81205	1	33-11-13 0148/217/L008	050-099, 155-199, 275-299
M00843	2	S283T019-2 DIMMER CONTROL-GLARESHIELD FLDT	233T2400 81205	1	33-11-13 0148/217/L008	150-154
M00843	3	S283T019-2 DIMMER CONTROL-GLARESHIELD FLDT	233T2400 81205	1	33-11-13 0148/217/L008	050-099, 155-199, 275-299
M00844		284T0215-19 CONT PNL-CARGO HDLG,FWD (SEE YA9)	284T0216 81205	1	25-53-11 P024-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M00800

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00845		284T0215-17 CONT PNL-CARGO HDLG,AFT (SEE YBA)	284T0216 81205	1	25-53-21 P027-00/ /	ALL
M00846		285T0100-2 MATCHING UNIT-HI BAND VIDEO,RIGHT	284T0680 81205	1	23-32-13 F 403/ /FSS	ALL
M00847		285T0100-2 MATCHING UNIT-HI BAND VIDEO,LEFT	284T0680 81205	1	23-32-13 F 403/ /FSS	ALL
M00859	9	285T1115-15 PC ASSY-BLEED AIR CONTROL,L (SB 36-0026)	284T0049 81205	1	36-11-51 P050-00/ /	050-099, 150-156, 162-166
M00859		285T1115-11 PRINTED CIRCUIT ASSY-BLEED AIR CONTROL,L	284T0049 81205	1	36-11-51 P050-00/ /	050-099, 150-156, 162-166, 275-276
M00859		285T1115-15 PRINTED CIRCUIT ASSY-BLEED AIR CONTROL,L	284T0049 81205	1	36-11-51 P050-00/ /	157, 167-199, 277- 299
M00860	9	285T1115-15 PC ASSY-BLEED AIR CONTROL,R (SB 36-0026)	284T0049 81205	1	36-11-52 P050-00/ /	050-099, 150-156, 162-166
M00860		285T1115-11 PRINTED CIRCUIT ASSY-BLEED AIR CONTROL,R	284T0049 81205	1	36-11-52 P050-00/ /	050-099, 150-156, 162-166, 275-276
M00860		285T1115-15 PRINTED CIRCUIT ASSY-BLEED AIR CONTROL,R	284T0049 81205	1	36-11-52 P050-00/ /	157, 167-199, 277- 299
M00861		285T0078-15 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,L	284T0049 81205	1	21-25-11 P050-00/ /	277-299
M00861	1	285T0078-15 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,L	284T0049 81205	1	21-25-11 P050-00/ /	050-099, 150-199, 275-276
M00861	2	285T0078-16 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,L	284T0049 81205	1	21-25-11 P050-00/ /	050-099, 150-199, 275-276
M00862		285T0078-15 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,R	284T0049 81205	1	21-25-21 P050-00/ /	277-299
M00862	1	285T0078-15 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,R	284T0049 81205	1	21-25-21 P050-00/ /	050-099, 150-199, 275-276
M00862	2	285T0078-16 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,R	284T0049 81205	1	21-25-21 P050-00/ /	050-099, 150-199, 275-276
M00864		285T0093-11 PRINTED CIRCUIT ASSY-PACK FLOW CONTROL,R	284T0049 81205	1	21-51-21 P050-00/ /	277-299
M00864	1	285T0093-11 PRINTED CIRCUIT ASSY-PACK FLOW CONTROL,R	284T0049 81205	1	21-51-21 P050-00/ /	050-099, 150-199, 275-276

EQUIPMENT LIST

D280T132

Section M00800

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00864	2	285T0093-8 PRINTED CIRCUIT ASSY-PACK FLOW CONTROL,R	284T0049 81205	1	21-51-21 P050-00/ /	050-099, 150-199, 275-276
M00864	3	285T0093-1 PRINTED CIRCUIT ASSY-PACK FLOW CONTROL,R	284T0049 81205	1	21-51-21 P050-00/ /	050-099, 150-199, 275-276
M00867		285T0095-8 PC ASSY-EQUIPMENT COOLING INDICATION	284T0049 81205	1	21-58-11 P050-00/ /	277-299
M00867	1	285T0095-8 PC ASSY-EQUIPMENT COOLING INDICATION	284T0049 81205	1	21-58-11 P050-00/ /	050-099, 155-199, 276
M00867	1	285T0095-5 PC ASSY-EQUIPMENT COOLING INDICATION	284T0049 81205	1	21-58-11 P050-00/ /	150-154, 275
M00867	2	285T0095-7 PC ASSY-EQUIPMENT COOLING INDICATION	284T0049 81205	1	21-58-11 P050-00/ /	050-099, 150-199, 275-276
M00867	3	285T0095-3 PC ASSY-EQUIPMENT COOLING INDICATION	284T0049 81205	1	21-58-11 P050-00/ /	050-099, 150-199, 275-276
M00881		70-0240-5 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0284/212/R070	050-099, 150-199
M00881		70-0240-5 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0291/225/R085	275-278
M00881		70-0240-5 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0291/225/R095	280-299
M00882		70-0240-2 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0284/253/L053	050-099, 150-199
M00882		70-0240-3 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0291/225/L085	275-278
M00882		70-0240-3 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0291/225/L095	280-299
M00883		70-0240-6 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0834/260/R018	050-099
M00883		70-0240-6 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0917/260/L024	150-199
M00883		70-0240-6 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 0801/253/L010	275-299
M00884		70-0240-6 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 1542/253/L054	ALL

EQUIPMENT LIST

D280T132

Section M00800

Page 5

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00885		70-0240-6 CONT PNL-EVAC,EMER	284T4201 72914	1	25-63-11 1540/253/R054	ALL
M00889		233T7205-11 PNL-JACK,CAPT	233T7100 81205	1	23-51-11 P015-00/ /	ALL
M00890		233T7205-11 PNL-JACK,FIRST OFFICER	233T7100 81205	1	23-51-21 P016-00/ /	ALL
M00892		233T7208-11 PNL-JACK,SECOND OBSERVER	233T7100 81205	1	23-51-21 P063-00/ /	ALL
M00893		519858-4 MOTOR-APU STARTER	351T0300 99193	1	49-41-11 APU/ /	ALL
M00895	1	S281T003-3 ELCU-ELEC HYD PUMP L	284T0172 81205	1	29-11-12 P032-00/ /	ALL
M00895	2	S281T003-2 ELCU-ELEC HYD PUMP L	284T0172 81205	1	29-11-12 P032-00/ /	ALL
M00896	1	S281T003-3 ELCU-ELEC HYD PUMP R	284T0171 81205	1	29-11-22 P031-00/ /	ALL
M00896	2	S281T003-2 ELCU-ELEC HYD PUMP R	284T0171 81205	1	29-11-22 P031-00/ /	ALL
M00897	1	S281T003-3 ELCU-ELEC HYD PUMP C1	284T0171 81205	1	29-11-31 P031-00/ /	ALL
M00897	2	S281T003-2 ELCU-ELEC HYD PUMP C1	284T0171 81205	1	29-11-31 P031-00/ /	ALL
M00898	1	S281T003-3 ELCU-ELEC HYD PUMP C2	284T0172 81205	1	29-11-31 P032-00/ /	ALL
M00898	2	S281T003-2 ELCU-ELEC HYD PUMP C2	284T0172 81205	1	29-11-31 P032-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M00800

Page 6 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00901		233T7210-6 MODULE-HEATER CONTROL,CAPTAIN (SEE YDP)	233T7100 81205	1	21-45-11 P013-00/ /	050-099, 150-199, 275-278
M00901		233T7210-6 MODULE-HEATER CONTROL,CAPTAIN (SEE YDP)	233T7210 81205	1	21-45-11 P013-00/ /	280-299
M00901 T		S233T100-4006 LIGHTPLATE-MDL,HEATER CONT,CAPT	233T7210 81205	1	33-13-11 P013-00/ /	ALL
M00902		233T7210-6 MODULE-HEATER CONTROL,F/O (SEE YDQ)	233T7100 81205	1	21-45-11 P014-00/ /	050-099, 150-199, 275-278
M00902		233T7210-6 MODULE-HEATER CONTROL,F/O (SEE YDQ)	233T7210 81205	1	21-45-11 P014-00/ /	280-299
M00902 T		S233T100-4006 LIGHTPLATE-MDL,HEATER CONT,F/O	233T7210 81205	1	33-13-13 P014-00/ /	ALL
M00903	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 0654+118/280/L060	050-099, 150-199
M00903	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 0848/280/L060	275-299
M00903	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 0654+118/280/L060	050-099, 150-199
M00903	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 0848/280/L060	275-299
M00904	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-13 0654+118/280/R060	050-099, 150-199
M00904	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-13 0848/280/R060	275-299
M00904	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-13 0654+118/280/R060	050-099, 150-199
M00904	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-13 0848/280/R060	275-299
M00905	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 1472/280/L060	275-299
M00905	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-12 1472/280/L060	275-299
M00907	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-12 0291/280/L033	ALL

EQUIPMENT LIST

D280T132

Section M00900

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00907	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-12 0291/280/L033	ALL
M00908	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-14 0324/280/0000	275-299
M00908	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-14 0324/280/0000	275-299
M00909	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-14 0814/280/0000	275-278
M00909	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-14 0808/280/0000	280-299
M00909	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-14 0814/280/0000	275-278
M00909	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-14 0808/280/0000	280-299
M00910	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4204 81205	1	35-21-12 1527/280/L050	150-199
M00910	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4204 81205	1	35-21-12 1527/280/L050	150-199
M00911	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4204 81205	1	35-21-13 1516/280/L032	050-099, 150-199
M00912		233T4228-9 MODULE-BULK CARGO HEAT (SEE YDU)	233T4100 81205	1	21-44-21 P061-00/ /	ALL
M00914		S220T111-501 PSUD-PASS SERVICE UNIT DECODER	417T5504 54473	75	23-34-15 MULTI/ /	050-099
M00914		S220T111-501 PSUD-PASS SERVICE UNIT DECODER	417T5504 54473	100	23-34-13 MULTI/ /	150-152, 155
M00914		S220T111-501 PSUD-PASS SERVICE UNIT DECODER	417T5504 54473	101	23-34-13 MULTI/ /	153-154, 156
M00914		S220T111-501 PSUD-PASS SERVICE UNIT DECODER	417T5504 54473	109	23-34-13 MULTI/ /	157
M00914		S220T111-501 PSUD-PASS SERVICE UNIT DECODER	417T5504 54473	97	23-34-13 MULTI/ /	162-199
M00914		S220T111-501 PSUD-PASS SERVICE UNIT DECODER	417T5504 54473	122	23-34-13 MULTI/ /	275-278

EQUIPMENT LIST

D280T132

Section M00900

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00914		S220T111-501 PSUD-PASS SERVICE UNIT DECODER	417T5504 54473	124	23-34-13 MULTI/ /	280-299
M00914 T		S220T111-801 PLUG-TERMINATION PSU DECODER	417T5504 54473	11	23-34-15 / /	050-099
M00914 T		S220T111-801 PLUG-TERMINATION PSU DECODER	417T5504 54473	11	23-34-13 / /	150-199
M00914 T		S220T111-801 PLUG-TERMINATION PSU DECODER	417T5504 54473	14	23-34-15 / /	275-299
M00915		S220T111-305 SEB-SEAT ELEX BOX	417T5505 54473	73	23-34-15 MULTI/ /	050-099
M00915		S220T111-305 SEB-SEAT ELEX BOX	417T5505 54473	100	23-34-15 MULTI/ /	150-152, 155
M00915		S220T111-305 SEB-SEAT ELEX BOX	417T5505 54473	101	23-34-15 MULTI/ /	153-154, 156
M00915		S220T111-305 SEB-SEAT ELEX BOX	417T5505 54473	109	23-34-15 MULTI/ /	157
M00915		S220T111-305 SEB-SEAT ELEX BOX	417T5505 54473	95	23-34-15 MULTI/ /	162-199
M00915		S220T111-305 SEB-SEAT ELEX BOX	417T5505 54473	124	23-34-13 MULTI/ /	275-276
M00915 T		S220T111-701 PLUG-TERMINATION SEAT ELEC BOX	417T5505 54473	9	23-34-15 MULTI/ /	050-099, 150-199, 275-278
M00915 T		S220T111-701 PLUG-TERMINATION SEAT ELEC BOX	417T5505 54473	10	23-34-13 MULTI/ /	280-299
M00916		11199-4 PROCESSOR-PACK FLOW	284T0130 07148	1	21-52-41 SHELF/E03/01	050-099, 150-199, 275-278
M00916		11194-4 PROCESSOR-PACK FLOW	284T0130 07148	1	21-52-41 SHELF/E03/01	280-299
M00917		S231T110-103 UNIT-STATIC INV/ILS PRCS	284T0400 81205	1	34-24-11 SHELF/E01/04	ALL
M00919	1	10167-2001-BT MODULE-AIR HYD PUMP PRESS. LT TIME DELAY	284T0187 08719	1	29-11-32 P036-00/ /	ALL
M00919	2	TD-1767-2001 MODULE-AIR HYD PUMP PRESS. LT TIME DELAY	284T0187 58657	1	29-11-32 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M00900

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00919	3	10167-2-BT MODULE-AIR HYD PUMP PRESS. LT TIME DELAY	284T0187 08719	1	29-11-32 P036-00/ /	ALL
M00920	1	10167-3001-BT MODULE-HYD SYS R PRESS. LT TIME DELAY	284T0189 08719	1	29-11-22 P033-00/ /	ALL
M00920	2	TD-1767-3001 MODULE-HYD SYS R PRESS. LT TIME DELAY	284T0189 58657	1	29-11-22 P033-00/ /	ALL
M00920	3	10167-3-BT MODULE-HYD SYS R PRESS. LT TIME DELAY	284T0189 08719	1	29-11-22 P033-00/ /	ALL
M00921	1	10167-3001-BT MODULE-HYD SYS L PRESS. LT TIME DELAY	284T0188 08719	1	29-11-12 P037-00/ /	ALL
M00921	2	TD-1767-3001 MODULE-HYD SYS L PRESS. LT TIME DELAY	284T0188 58657	1	29-11-12 P037-00/ /	ALL
M00921	3	10167-3-BT MODULE-HYD SYS L PRESS. LT TIME DELAY	284T0188 08719	1	29-11-12 P037-00/ /	ALL
M00922	1	10167-2001-BT MODULE-HYD SYS CTR PRESS LT TIME DELAY	284T0187 08719	1	29-11-32 P036-00/ /	ALL
M00922	2	TD-1767-2001 MODULE-HYD SYS CTR PRESS LT TIME DELAY	284T0187 58657	1	29-11-32 P036-00/ /	ALL
M00922	3	10167-2-BT MODULE-HYD SYS CTR PRESS LT TIME DELAY	284T0187 08719	1	29-11-32 P036-00/ /	ALL
M00924	1	10167-4001-BT MODULE-ELEC HYD PUMP R PRESS.LT TIME DLY	284T0189 08719	1	29-11-22 P033-00/ /	ALL
M00924	2	TD-1767-4001 MODULE-ELEC HYD PUMP R PRESS.LT TIME DLY	284T0189 58657	1	29-11-22 P033-00/ /	ALL
M00924	3	10167-4-BT MODULE-ELEC HYD PUMP R PRESS.LT TIME DLY	284T0189 08719	1	29-11-22 P033-00/ /	ALL
M00925	1	10167-7501-BT MODULE-ELEC HYD PUMP L PRESS.LT TIME DLY	284T0188 08719	1	29-11-12 P037-00/ /	ALL
M00925	2	TD-1767-7501 MODULE-ELEC HYD PUMP L PRESS.LT TIME DLY	284T0188 58657	1	29-11-12 P037-00/ /	ALL
M00925	3	10167-7-5-BT MODULE-ELEC HYD PUMP L PRESS.LT TIME DLY	284T0188 08719	1	29-11-12 P037-00/ /	ALL
M00930		S220T118-3 WAVEGUIDE-	284T0750 81205	1	34-43-22 / /	ALL

EQUIPMENT LIST

D280T132

Section M00900

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00931		S220T118-4 WAVEGUIDE-	284T0750 81205	1	34-43-12 / /	ALL
M00932		S220T118-5 WAVEGUIDE	284T0750 81205	1	34-43-12 / /	ALL
M00933		MXP147-3 STOWAGE-OXY MASK,CAPT (SEE YGK)	232T8002 53655	1	23-51-11 0164/220/L033	ALL
M00934		MXP147-3 STOWAGE-OXY MASK,F/O (SEE YGL)	232T8002 53655	1	23-51-21 0164/220/R033	ALL
M00936		MXP147-3 STOWAGE-OXY MASK,FIRST OBS (SEE YGM)	232T8002 53655	1	23-51-41 P061-00/ /	ALL
M00937	9	257T1103-14 MDL-LDG GEAR LVR (SEE YBG) (SB 32-0084)	257T1100 81205	1	32-31-11 / /	150-154, 275
M00937		257T1103-9 MODULE-LANDING GEAR LEVER (SEE YBG)	257T1100 81205	1	32-31-11 / /	050-099, 155-199, 276-299
M00938	9	285T1104-17 MODULE-STALL WARNING,RIGHT (SB 27-0098)	284T0049 81205	1	27-32-21 P051-00/ /	150-152
M00938		285T1104-17 MODULE-STALL WARNING,RIGHT	284T0049 81205	1	27-32-21 P051-00/ /	050-099, 153-199, 275-299
M00950		S251T220-8 ELEVATOR FEEL COMPUTER	251T2201 81205	1	27-31-11 1725/244/L047	050-099
M00950	1	S251T220-9 ELEVATOR FEEL COMPUTER	251T2201 81205	1	27-31-11 1725/244/L047	150-199, 275-299
M00952		C-07202-3 STICK SHAKER-RIGHT	253T2127 73326	1	27-32-21 0140/ /	ALL
M00955		S416T208-5 ACTR-SPOILER OVERRIDE,L	252T1700 81205	1	25-65-11 L0352/ /RS	ALL
M00956		S416T208-5 ACTR-SPOILER OVERRIDE,R	252T1700 81205	1	25-65-12 R0352/ /RS	ALL
M00957		S416T208-9 ACTR-WING SLIDE DR LATCH RELEASE,L	416T2822 81205	1	25-65-11 1153/173/L095	ALL
M00958		S416T208-9 ACTR-WING SLIDE DR LATCH RELEASE,R	416T2822 81205	1	25-65-12 1153/173/R095	ALL
M00961		S283T014-3 POWER SUPPLY-OFF WING ESCAPE SYS,L	417T5097 81205	1	25-65-11 0900/208/L090	050-099

EQUIPMENT LIST

D280T132

Section M00900

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00961		S283T014-3 POWER SUPPLY-OFF WING ESCAPE SYS,L	417T5097 81205	1	25-65-11 1010/208/L090	150-199
M00961		S283T014-3 POWER SUPPLY-OFF WING ESCAPE SYS,L	417T5097 81205	1	25-65-11 0966/208/L090	275-299
M00962		S283T014-3 POWER SUPPLY-OFF WING ESCAPE SYS,R	417T5097 81205	1	25-65-12 0900/208/R090	050-099
M00962		S283T014-3 POWER SUPPLY-OFF WING ESCAPE SYS,R	417T5097 81205	1	25-65-12 1032/208/R090	150-199
M00962		S283T014-3 POWER SUPPLY-OFF WING ESCAPE SYS,R	417T5097 81205	1	25-65-12 0966/208/R090	275-299
M00963	1	10167-3001-BT TIME DELAY-AUTO. SPEED BRAKE WRN	284T0189 08719	1	27-62-11 P033-00/ /	ALL
M00963	2	TD-1767-3001 TIME DELAY-AUTO. SPEED BRAKE WRN	284T0189 08719	1	27-62-11 P033-00/ /	ALL
M00963	3	10167-3-BT TIME DELAY-AUTO. SPEED BRAKE WRN	284T0189 08719	1	27-62-11 P033-00/ /	ALL
M00964	9	S417T108 MDL-FWD WASTE TANK LEVEL SNSR	417T1324 81205	1	38-32-11 1568/162/L029	150-154, 275
M00964		0027-0005-4 MDL-FWD WASTE TANK LEVEL SNSR	417T1324 81205	1	38-32-11 1568/162/L029	150-154, 275
M00964		S417T108 MDL-FWD WASTE TANK LEVEL SNSR	417T1324 81205	1	38-32-11 1568/168/L029	156-157, 166-199, 277-299
M00965	9	S417T108 MDL-AFT WASTE TANK LEVEL SNSR	417T1324 81205	1	38-32-11 1576/166/L030	150-154, 275
M00965		S417T108 MDL-AFT WASTE TANK LEVEL SNSR	417T1324 81205	1	38-32-11 1576/166/L030	050-099, 155-199, 276-299
M00965		0027-0005-4 MDL-AFT WASTE TANK LEVEL SNSR	417T1324 81205	1	38-32-11 1576/166/L030	150-154, 275
M00966		254N1185-5 AUTOTHROTTLE ASSY-MICROSWITCH PACK	253T7101 81205	1	78-34-21 0150/188/0000	ALL
M00967	7	S351T020-7 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	ALL
M00967	6	S351T020-9 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	ALL

EQUIPMENT LIST

D280T132

Section M00900

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00967	5	S351T020-11 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	ALL
M00967	1	S351T020-201 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	050-099, 150-154, 162-163
M00967	1	S351T020-203 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	155, 164-165
M00967	1	S351T020-204 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	156-157, 166-199, 277-299
M00967	2	S351T020-200 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	ALL
M00967	3	S351T020-15 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	ALL
M00967	4	S351T020-13 AUXILIARY POWER UNIT (SEE YBM)	351T0300 81205	1	49-14-11 ENG/ /	ALL
M00968		280T1004-8 TEST PLUG-FLIGHT RECORDER SYSTEM	287T0001 81205	1	31-31-11 P061-00/ /	ALL
M00969		285T0100-1 MATCHING UNIT-LO BAND VIDEO,RIGHT	284T0680 81205	1	23-32-13 F 334/ /FSS	ALL
M00970		285T0100-1 MATCHING UNIT-LO BAND VIDEO,LEFT	284T0680 81205	1	23-32-13 F 334/ /FSS	ALL
M00974		280T1003-1 RCPT-SELCAL CODING	284T0125 81205	1	23-21-12 SHELF/E02/05	ALL
M00975		280T1003-1 RCPT-ACARS REGISTRATION ID CODING	284T1625 81205	1	23-22-13 SHELF/E02/05	ALL
M00976		280T1003-1 SHORTING RCPT-DFDAU CODING & A/C IDENT	284T0123 81205	1	31-31-16 SHELF/E02/03	ALL
M00977		280T1003-1 RCPT-SHORTING, L ATC XPDR	284T0122 81205	1	34-53-12 SHELF/E02/02	ALL
M00978		280T1003-1 RCPT-SHORTING, R ATC XPDR	284T0123 81205	1	34-53-22 SHELF/E02/03	ALL
M00983		285T0031-17 MODULE-CONFIG WRN LANDING	284T0049 81205	1	31-51-42 P051-00/ /	ALL
M00985		253T5800-17 ASSY-THRUST LEVER (SEE YBN)	253T5800 81205	1	22-12-11 0171/223/	ALL

EQUIPMENT LIST

D280T132

Section M00900

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M00988	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-12 1495/280/L032	050-099, 150-199
M00988	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-12 1495/280/L032	050-099, 150-199
M00990		285T0078-15 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,C	284T0049 81205	1	21-58-15 P050-00/ /	277-299
M00990	1	285T0078-15 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,C	284T0049 81205	1	21-58-15 P050-00/ /	050-099, 150-199, 275-276
M00990	2	285T0078-16 PRINTED CIRCUIT ASSY-ECS FAN CONTROL,C	284T0049 81205	1	21-58-15 P050-00/ /	050-099, 150-199, 275-276
M00994		233T7213 PNL-APU HOURS INDICATOR	233T4100 81205	1	49-72-11 P061-00/ /	ALL
M00999		285T0034-21 MODULE-SIREN OWL AMPLIFIER,LEFT	284T0049 81205	1	31-51-31 P051-00/ /	050-099, 150-154, 162, 275-276
M00999		285T0034-25 MODULE-SIREN OWL AMPLIFIER,LEFT	284T0049 81205	1	31-51-31 P051-00/ /	155-157, 163-199, 277-299

EQUIPMENT LIST

D280T132

Section M00900

Page 8 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01000		285T0385-5 MODULE-BELL CHIME	284T0049 81205	1	31-51-33 P051-00/ /	050-099, 150-199, 275
M01000		285T0385-6 MODULE-BELL CHIME	284T0049 81205	1	31-51-33 P051-00/ /	276-299
M01004		S451T201-7 PDU 3R-FWD CARGO	451T2003 81205	1	25-53-14 0474/124/R029	050-099
M01004	1	S451T201-12 PDU 3R-FWD CARGO	451T2003 81205	1	25-53-14 0474/124/R029	150-199, 275-299
M01004	2	S451T201-7 PDU 3R-FWD CARGO	451T2003 81205	1	25-53-14 0474/124/R029	150-199, 275-299
M01005		S451T201-7 PDU 3L-FWD CARGO	451T2003 81205	1	25-53-14 0474/124/L029	050-099, 150-154, 275-276
M01005	1	S451T201-11 PDU 3L-FWD CARGO	451T2003 81205	1	25-53-14 0474/124/L029	155-156, 162-166
M01005	1	S451T201-12 PDU 3L-FWD CARGO	451T2003 81205	1	25-53-14 0474/124/L029	157, 167-199, 277- 299
M01005	2	S451T201-7 PDU 3L-FWD CARGO	451T2003 81205	1	25-53-14 0474/124/L029	155-199, 277-299
M01006		S451T201-7 PDU 4R-FWD CARGO	451T2003 81205	1	25-53-14 0502/124/R029	050-099
M01006	1	S451T201-12 PDU 4R-FWD CARGO	451T2003 81205	1	25-53-14 0502/124/R029	150-199, 275-299
M01006	2	S451T201-7 PDU 4R-FWD CARGO	451T2003 81205	1	25-53-14 0502/124/R029	150-199, 275-299
M01007		S451T201-7 PDU 4L-FWD CARGO	451T2003 81205	1	25-53-14 0502/124/L029	050-099
M01007	1	S451T201-12 PDU 4L-FWD CARGO	451T2003 81205	1	25-53-14 0502/124/L029	150-199, 275-299
M01007	2	S451T201-7 PDU 4L-FWD CARGO	451T2003 81205	1	25-53-14 0502/124/L029	150-199, 275-299
M01008		S451T201-7 PDU 5R-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/R036	050-099
M01008	1	S451T201-12 PDU 5R-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/R036	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M01000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01008	2	S451T201-7 PDU 5R-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/R036	150-199, 275-299
M01009		S451T201-7 PDU 5C-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/R009	050-099, 150-154, 275-276
M01009	1	S451T201-11 PDU 5C-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/R009	155-156, 162-166
M01009	1	S451T201-12 PDU 5C-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/R009	157, 167-199, 277- 299
M01009	2	S451T201-7 PDU 5C-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/R009	155-199, 277-299
M01010		S451T201-7 PDU 5L-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/L020	050-099, 150-154, 275-276
M01010	1	S451T201-12 PDU 5L-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/L020	150-199, 275-299
M01010	2	S451T201-7 PDU 5L-FWD CARGO	451T2003 81205	1	25-53-14 0517/124/L020	150-199, 275-299
M01011		S451T201-7 PDU 6R-FWD CARGO	451T2003 81205	1	25-53-14 0530/124/R029	050-099
M01011	1	S451T201-12 PDU 6R-FWD CARGO	451T2003 81205	1	25-53-14 0530/124/R029	150-199, 275-299
M01011	2	S451T201-7 PDU 6R-FWD CARGO	451T2003 81205	1	25-53-14 0530/124/R029	150-199, 275-299
M01012		S451T201-7 PDU 6L-FWD CARGO	451T2003 81205	1	25-53-14 0530/124/L029	050-099
M01012	1	S451T201-12 PDU 6L-FWD CARGO	451T2003 81205	1	25-53-14 0530/124/L029	150-199, 275-299
M01012	2	S451T201-7 PDU 6L-FWD CARGO	451T2003 81205	1	25-53-14 0530/124/L029	150-199, 275-299
M01013		S451T201-7 PDU 7R-FWD CARGO	451T2003 81205	1	25-53-14 0558/124/R029	050-099
M01013	1	S451T201-12 PDU 7R-FWD CARGO	451T2003 81205	1	25-53-14 0558/124/R029	150-199, 275-299
M01013	2	S451T201-7 PDU 7R-FWD CARGO	451T2003 81205	1	25-53-14 0558/124/R029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M01000

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01014		S451T201-7 PDU 7L-FWD CARGO	451T2003 81205	1	25-53-14 0558/124/L029	050-099
M01014	1	S451T201-12 PDU 7L-FWD CARGO	451T2003 81205	1	25-53-14 0558/124/L029	150-199, 275-299
M01014	2	S451T201-7 PDU 7L-FWD CARGO	451T2003 81205	1	25-53-14 0558/124/L029	150-199, 275-299
M01015		S451T201-7 PDU 8R-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/R036	050-099
M01015	1	S451T201-12 PDU 8R-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/R036	150-199, 275-299
M01015	2	S451T201-7 PDU 8R-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/R036	150-199, 275-299
M01016		S451T201-7 PDU 8C-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/R009	050-099, 150-154, 275-276
M01016	1	S451T201-11 PDU 8C-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/R009	155-156, 162-166
M01016	1	S451T201-12 PDU 8C-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/R009	157, 167-199, 277- 299
M01016	2	S451T201-7 PDU 8C-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/R009	155-199, 277-299
M01017		S451T201-7 PDU 8L-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/L020	050-099
M01017	1	S451T201-12 PDU 8L-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/L020	150-199, 275-299
M01017	2	S451T201-7 PDU 8L-FWD CARGO	451T2003 81205	1	25-53-14 0579/124/L020	150-199, 275-299
M01018		S451T201-7 PDU 9R-FWD CARGO	451T2003 81205	1	25-53-14 0596/124/R029	050-099
M01018	1	S451T201-12 PDU 9R-FWD CARGO	451T2003 81205	1	25-53-14 0596/124/R029	150-199, 275-299
M01019		S451T201-7 PDU 9L-FWD CARGO	451T2003 81205	1	25-53-14 0596/124/L029	050-099
M01019	1	S451T201-12 PDU 9L-FWD CARGO	451T2003 81205	1	25-53-14 0596/124/L029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M01000

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01019	2	S451T201-7 PDU 9L-FWD CARGO	451T2003 81205	1	25-53-14 0596/124/L029	150-199, 275-299
M01020		S451T201-7 PDU 10R-FWD CARGO	451T2003 81205	1	25-53-14 0639/124/R029	050-099
M01020	1	S451T201-12 PDU 10R-FWD CARGO	451T2003 81205	1	25-53-14 0641/124/R029	150-199, 275-299
M01020	2	S451T201-7 PDU 10R-FWD CARGO	451T2003 81205	1	25-53-14 0641/124/R029	150-199, 275-299
M01021		S451T201-7 PDU 10L-FWD CARGO	451T2003 81205	1	25-53-14 0639/124/L029	050-099
M01021	1	S451T201-12 PDU 10L-FWD CARGO	451T2003 81205	1	25-53-14 0641/124/L029	150-199, 275-299
M01021	2	S451T201-7 PDU 10L-FWD CARGO	451T2003 81205	1	25-53-14 0641/124/L029	150-199, 275-299
M01022		S451T201-7 PDU 11R-FWD CARGO	451T2003 81205	1	25-53-14 0683/124/R029	050-099
M01023		S451T201-7 PDU 11L-FWD CARGO	451T2003 81205	1	25-53-14 0683/124/L029	050-099
M01024		S452T201-3 ACTR 1R-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0485/124/R025	050-099, 150-154, 162, 275-276
M01024	1	S452T202-1 ACTR 1R-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0481/124/R023	155-157, 163-199, 277-299
M01024	2	S452T201-3 ACTR 1R-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0481/124/R023	155-157, 163-199, 277-299
M01025		S452T201-3 ACTR 1M-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0485/124/L000	050-099, 150-154, 162, 275-276
M01025	1	S452T202-1 ACTR 1M-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0480/127/R004	155-157, 163-199, 277-299
M01025	2	S452T201-3 ACTR 1M-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0480/127/R004	155-157, 163-199, 277-299
M01026		S452T201-3 ACTR 1L-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0485/124/L027	050-099, 150-154, 162, 275-276
M01026	1	S452T202-1 ACTR 1L-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0485/124/L027	155-157, 163-199

EQUIPMENT LIST

D280T132

Section M01000

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01026	1	S452T202-1 ACTR 1L-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0481/124/L023	277-299
M01026	2	S452T201-3 ACTR 1L-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0485/124/L027	155-157, 163-199
M01026	2	S452T201-3 ACTR 1L-FWD LAT GUIDE	452T2603 81205	1	25-53-15 0481/124/L023	277-299
M01027		S452T201-3 ACTR 2R-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0546/124/R029	050-099, 150-154, 162, 275-276
M01027	1	S452T202-1 ACTR 2R-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0550/124/R019	155-157, 163-199, 277-299
M01027	2	S452T201-3 ACTR 2R-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0550/124/R019	155-157, 163-199, 277-299
M01028		S452T201-3 ACTR 2M-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0546/124/L003	050-099, 150-154, 162, 275-276
M01028	1	S452T202-1 ACTR 2M-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0541/122/R002	155-157, 163-199, 277-299
M01028	2	S452T201-3 ACTR 2M-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0541/122/R002	155-157, 163-199, 277-299
M01029		S452T201-3 ACTR 2L-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0546/124/L034	050-099, 150-154, 162, 275-276
M01029	1	S452T202-1 ACTR 2L-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0541/120/L034	155-157, 163-199, 277-299
M01029	2	S452T201-3 ACTR 2L-AFT LAT GUIDE	452T2603 81205	1	25-53-15 0541/120/L034	155-157, 163-199, 277-299
M01030		S452T201-3 ACTR 1-LD2 GUIDE	452T1201 81205	1	25-53-16 0504/124/0000	050-099, 150-154, 162, 275-276
M01030	1	S452T202-1 ACTR 1-LD2 GUIDE	452T1201 81205	1	25-53-16 0501/124/L008	155-157, 163-199, 277-299
M01030	2	S452T201-3 ACTR 1-LD2 GUIDE	452T1201 81205	1	25-53-16 0501/124/L008	155-157, 163-199, 277-299
M01031		S452T201-3 ACTR 2-LD2 GUIDE	452T1201 81205	1	25-53-16 0530/124/0000	050-099, 150-154, 162, 275-276
M01031	1	S452T202-1 ACTR 2-LD2 GUIDE	452T1201 81205	1	25-53-16 0528/124/L010	155-157, 163-199, 277-299

EQUIPMENT LIST

D280T132

Section M01000

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01031	2	S452T201-3 ACTR 2-LD2 GUIDE	452T1201 81205	1	25-53-16 0528/124/L010	155-157, 163-199, 277-299
M01032		S452T201-3 ACTR 1-LD3 GUIDE	452T1202 81205	1	25-53-16 0504/124/R014	050-099, 150-154, 162, 275-276
M01032	1	S452T202-1 ACTR 1-LD3 GUIDE	452T1202 81205	1	25-53-16 0506/122/R001	155-157, 163-199, 277-299
M01032	2	S452T201-3 ACTR 1-LD3 GUIDE	452T1202 81205	1	25-53-16 0506/122/R001	155-157, 163-199, 277-299
M01033		S452T201-3 ACTR 2-LD3 GUIDE	452T1202 81205	1	25-53-16 0530/124/R014	050-099, 150-154, 162, 275-276
M01033	1	S452T202-1 ACTR 2-LD3 GUIDE	452T1202 81205	1	25-53-16 0532/122/R002	155-157, 163-199, 277-299
M01033	2	S452T201-3 ACTR 2-LD3 GUIDE	452T1202 81205	1	25-53-16 0532/122/R002	155-157, 163-199, 277-299
M01034		S452T201-3 ACTR 1-ROLLOUT STOP,BAY C	451T1701 81205	1	25-53-17 0505/120/R048	162
M01036	2	S452T201-3 ACTR 3-ROLLOUT STOP,BAY D	451T1701 81205	1	25-53-17 0569/122/R044	280-299
M01039		S451T201-7 PDU 2R-FWD CARGO	451T2003 81205	1	25-53-14 0442/124/R029	050-099
M01039	1	S451T201-12 PDU 2R-FWD CARGO	451T2003 81205	1	25-53-14 0442/124/R029	150-199, 275-299
M01039	2	S451T201-7 PDU 2R-FWD CARGO	451T2003 81205	1	25-53-14 0442/124/R029	150-199, 275-299
M01040		S451T201-7 PDU 2L-FWD CARGO	451T2003 81205	1	25-53-14 0442/124/L029	050-099
M01040	1	S451T201-12 PDU 2L-FWD CARGO	451T2003 81205	1	25-53-14 0442/124/L029	150-199, 275-299
M01040	2	S451T201-7 PDU 2L-FWD CARGO	451T2003 81205	1	25-53-14 0442/124/L029	150-199, 275-299
M01045	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4206 81205	1	35-21-12 0348/284/L057	050-099, 150-199, 275-278
M01045	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4206 81205	1	35-21-12 0348/284/L057	050-099, 150-199, 275-278

EQUIPMENT LIST

D280T132

Section M01000

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01046		622-6830-001 CONT PNL-ADF,DUAL	233T6100 13499	1	34-57-11 P008-00/ /	ALL
M01046 T	9	S233T100-539-540-552 LIGHTPLATE-CONT PNL,ADF,DUAL(SB 33-0008)	285T0557 81205	1	33-13-18 P008-00/ /	150-199
M01046 T		233T100-539-540-552 LIGHTPLATE-CONT PNL,ADF,DUAL	285T0557 81205	1	33-13-18 P008-00/ /	150-199
M01057	1	S271T002-20 MODULE-AIR HYD PUMP OVERSPEED CONT CARD	284T0049 81205	1	29-11-32 P050-00/ /	ALL
M01057	2	S271T002-16 MODULE-AIR HYD PUMP OVERSPEED CONT CARD	284T0049 81205	1	29-11-32 P050-00/ /	050-099, 150-155, 162-165, 275-276
M01057	3	S271T002-14 MODULE-AIR HYD PUMP OVERSPEED CONT CARD	284T0049 81205	1	29-11-32 P050-00/ /	050-099, 150-155, 162-165, 275-276
M01057	4	S27150012 MODULE-AIR HYD PUMP OVERSPEED CONT CARD	284T0049 81205	1	29-11-32 P050-00/ /	050-099, 150-155, 162-165, 275-276
M01059	9	743-0214-001 VTR-2,VIDEO (MTO 230540)	284T0807 97896	1	23-32-11 GALLEY 3/ /	050-099
M01059		743-0214-001 VTR-2,VIDEO	284T0807 97896	1	23-32-11 0447/245/L080	150-199
M01059		495320-0005 VTR-2,VIDEO	284T0807 62204	1	23-32-11 0255/255/L010	275-276
M01059		495320-0007 VTR-2,VIDEO	284T0807 62204	1	23-32-11 0255/255/L010	277-299
M01062	1	S283T019-4 DIMMER CONTROL-LT PLATES OVHD CB PNL,P11	233T4400 81205	1	33-13-19 0216/290/R015	050-099, 155-199, 275-299
M01062	1	S283T019-3 DIMMER CONTROL-LT PLATES OVHD CB PNL,P11	233T4400 81205	1	33-13-19 P011-00/ /	150-154
M01062	2	S283T019-3 DIMMER CONTROL-LT PLATES OVHD CB PNL,P11	233T4400 81205	1	33-13-19 0216/290/R015	050-099, 155-199, 275-299
M01062	2	S283T019-2 DIMMER CONTROL-LT PLATES OVHD CB PNL,P11	233T4400 81205	1	33-13-19 P011-00/ /	150-154
M01062	3	S283T019-2 DIMMER CONTROL-LT PLATES OVHD CB PNL,P11	233T4400 81205	1	33-13-19 0216/290/R015	050-099, 155-199, 275-299
M01076	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4206 81205	1	35-21-13 0348/280/R059	050-099, 150-199

EQUIPMENT LIST

D280T132

Section M01000

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01076	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4206 81205	1	35-21-13 0348/280/R059	050-099, 150-199
M01079	1	S281N001-2 UNIT-INSTR BUS VOLTAGE SENSE	284T0997 81205	1	24-51-42 P006-04/ /	ALL
M01079	2	S281N001-1 UNIT-INSTR BUS VOLTAGE SENSE	284T0997 81205	1	24-51-42 P006-04/ /	ALL
M01080		S256T005-6 MODULE-CONTROL VALVE,INBD SLAT (SEE YBX)	256T2610 81205	1	27-81-11 0775/173/R109	050-099, 150-166, 275-277
M01080		S256T005-10 MODULE-CONTROL VALVE,INBD SLAT (SEE YBX)	256T2610 81205	1	27-81-11 0775/173/R109	167-199, 278-299
M01081		S256T005-5 MDL-CONTROL VALVE,OUTBD SLAT (SEE YBY)	256T2710 81205	1	27-81-21 0776/152/L110	050-099, 150-166, 275-277
M01081		S256T005-9 MDL-CONTROL VALVE,OUTBD SLAT (SEE YBY)	256T2710 81205	1	27-81-21 0776/152/L110	167-199, 278-299
M01082	9	S256T005-11 MDL-CTL VLV,TE FLAP(SEE YBZ)(SB 27-0096)	256T3110 81205	1	27-51-11 0107/159/R013	050-099, 150, 152- 166
M01082		S256T005-7 MODULE-CONTROL VALVE,TE FLAP (SEE YBZ)	256T3110 81205	1	27-51-11 0107/159/R013	050, 150-166, 275- 277
M01082		S256T005-11 MODULE-CONTROL VALVE,TE FLAP (SEE YBZ)	256T3110 81205	1	27-51-11 0107/159/R013	167-199, 278-299
M01084	1	10167-3000-BT MODULE-LOAD SHED TIME DELAY	284T0189 08719	1	24-51-52 P033-00/ /	ALL
M01084	2	10167-3-BT MODULE-LOAD SHED TIME DELAY	284T0189 08719	1	24-51-52 P033-00/ /	ALL
M01084	3	TD-1767-3000 MODULE-LOAD SHED TIME DELAY	284T0189 08719	1	24-51-52 P033-00/ /	ALL
M01085	9	S283T018-27 BALLAST-SIDEWALL LTS (MTO 330370)	CUSTOMER 81205	1	33-21-34 1428/288/R056	150-157
M01085		S283T018-27 BALLAST-SIDEWALL LTS	417T5081 81205	1	33-21-34 1391/288/R056	050-099
M01085		S283T018-27 BALLAST-SIDEWALL LTS	417T5081 81205	1	33-21-34 1428/288/R056	162-199
M01086	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	2	35-21-14 0930/280/0000	050-099, 150-199

EQUIPMENT LIST

D280T132

Section M01000

Page 8

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01086	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	2	35-21-14 0930/280/0000	050-099, 150-199
M01087	1	233T4240-12 PNL-HYD/GEN FIELD CONT (SEE YDW)	233T4100 81205	1	24-22-11 P061-00/ /	ALL
M01087	2	233T4240-7 PNL-HYD/GEN FIELD CONT (SEE YDW)	233T4100 81205	1	24-22-11 P061-00/ /	ALL
M01088		41SG118-2 XMTR-PRESSURE,AIR SUPPLY DUCT,LEFT	212T3002 02750	1	36-21-11 0783/130/L038	ALL
M01089		41SG118-2 XMTR-PRESSURE,AIR SUPPLY DUCT,RIGHT	212T3002 02750	1	36-21-11 0795/134/R062	ALL
M01092		285T0458-22 PC ASSY-RIGHT N2 ENGINE SPEED	284T0049 81205	1	73-21-18 P050-00/ /	ALL
M01093		285T0458-22 PC ASSY-LEFT N2 ENGINE SPEED	284T0049 81205	1	73-21-18 P050-00/ /	ALL
M01094 T		S233T100-1053 LIGHTPLATE-PNL,FUEL HEAT	233T3231 81205	1	33-13-16 P005-00/ /	050-099, 275-299

EQUIPMENT LIST

D280T132

Section M01000
Page 9 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01102		10S1034A MODULE-400HZ EMI FILTER	285T0007 56289	1	31-51-11 P051-00/ /	ALL
M01103		10S1034A MODULE-400HZ EMI FILTER	285T0007 56289	1	31-51-12 P051-00/ /	ALL
M01104		S257T400-1 MOTOR-LDG GR ALTN EXTENSION	257T3500 81205	1	32-35-11 0240/200/L040	ALL
M01107	1	S283T019-4 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	050-099, 155-199, 275-299
M01107	1	S283T019-3 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	150-154
M01107	2	S283T019-3 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	050-099, 155-199, 275-299
M01107	2	S283T019-2 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	150-154
M01107	3	S283T019-2 DIMMER CONT-AISLE STAND INST & PNL LTS	233T2402 81205	1	33-13-18 P008-00/ /	050-099, 155-199, 275-299
M01108	9	743-0214-001 VTR-1,VIDEO (MTO 230540)	417T7002 97896	1	23-32-11 GALLEY 3/ /	050-099
M01108		743-0214-001 VTR-1,VIDEO	417T7002 97896	1	23-32-11 0447/245/L080	150-199
M01108		495320-0005 VTR-1,VIDEO	284T0807 62204	1	23-32-11 0255/262/L010	275-276
M01108		495320-0007 VTR-1,VIDEO	284T0807 62204	1	23-32-11 0255/262/L010	277-299
M01111		233T3230-40 PNL-ENTERTAINMENT	233T3100 81205	1	23-32-12 P005-00/ /	050-099, 150-199
M01111		233T3230-22 PNL-ENTERTAINMENT	233T3100 81205	1	23-32-12 P005-00/ /	275-299
M01113		743-0163-001 TUNER-TV	284T0807 97896	1	23-32-11 0447/245/L080	150-199
M01129		233T4242-2 MODULE-LTG CONT PNL R SIDE OBS	233T4100 81205	1	33-13-21 P061-00/ /	ALL
M01129 T		S233T100-4006 LIGHTPLATE-MDL,LIGHTING CONT PNL R SIDE	233T4242 81205	1	33-13-21 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M01100

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01130	1	S283T019-4 DIMMER CONTROL-RIGHT SIDE PANEL	233T4403 81205	1	33-13-21 P061-00/ /	050-099, 155-199, 275-299
M01130	1	S283T019-3 DIMMER CONTROL-RIGHT SIDE PANEL	233T4403 81205	1	33-13-21 P061-00/ /	150-154
M01130	2	S283T019-3 DIMMER CONTROL-RIGHT SIDE PANEL	233T4403 81205	1	33-13-21 P061-00/ /	050-099, 155-199, 275-299
M01130	2	S283T019-2 DIMMER CONTROL-RIGHT SIDE PANEL	233T4403 81205	1	33-13-21 P061-00/ /	150-154
M01130	3	S283T019-2 DIMMER CONTROL-RIGHT SIDE PANEL	233T4403 81205	1	33-13-21 P061-00/ /	050-099, 155-199, 275-299
M01134		D51434-1 RECORDER-QUICK ACCESS (SEE YEL)	284T0400 568998	1	31-35-16 SHELF/E02/02	ALL
M01135		284T0498-13 MODULE-OFF-WING ESCAPE SYSTEM,L (SEE YB7)	284T0263 81205	1	25-65-11 0877/257/L089	050-099
M01135		284T0498-14 MODULE-OFF-WING ESCAPE SYSTEM,L (SEE YB7)	284T0263 81205	1	25-65-11 0920/257/L089	150-199, 275-299
M01136		284T0498-13 MODULE-OFF-WING ESCAPE SYSTEM,R(SEE YB8)	284T0263 81205	1	25-65-12 0877/257/R089	050-099
M01136		284T0498-14 MODULE-OFF-WING ESCAPE SYSTEM,R(SEE YB8)	284T0263 81205	1	25-65-12 0920/257/R089	150-199, 275-299
M01139		R-584M54 MODULE-LINEAR ACTUATOR	251T2210 46452	1	27-32-31 1815/268/L020	ALL
M01144	1	CSK21201 LC FILTER	284T0804 12294	1	27-38-11 1760/264/L042	ALL
M01144	2	CSK21169 LC FILTER	284T0804 12294	1	27-38-11 1760/264/L042	ALL
M01145	1	CSK21201 LC FILTER	284T0804 12294	1	27-38-11 1760/264/L042	ALL
M01145	2	CSK21169 LC FILTER	284T0804 12294	1	27-38-11 1760/264/L042	ALL
M01146	1	CSK21201 LC FILTER	284T0804 12294	1	27-38-11 1760/264/L042	ALL
M01146	2	CSK21169 LC FILTER	284T0804 12294	1	27-38-11 1760/264/L042	ALL

EQUIPMENT LIST

D280T132

Section M01100

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01147	1	CSK20201 LC FILTER	284T0804 12294	1	27-38-11 1760/264/L042	ALL
M01147	2	CSK21169 LC FILTER	284T0804 12294	1	27-38-11 1760/264/L042	ALL
M01148	1	TRN-01-010099-01 LC FILTER	284T1105 12294	1	27-18-11 1008/183/R040	ALL
M01148	2	CSK21201 LC FILTER	284T1105 12294	1	27-18-11 1008/183/R040	ALL
M01148	3	CSK21169 LC FILTER	284T1105 12294	1	27-18-11 1008/183/R040	ALL
M01149	1	TRN-01-010099-01 LC FILTER	284T1105 12294	1	27-18-11 1008/183/R040	ALL
M01149	2	CSK21201 LC FILTER	284T1105 12294	1	27-18-11 1008/183/R040	ALL
M01149	3	CSK21169 LC FILTER	284T1105 12294	1	27-18-11 1008/183/R040	ALL
M01150	1	TRN-01-010099-01 LC FILTER	284T1105 12294	1	27-18-11 1008/183/L040	ALL
M01150	2	CSK21201 LC FILTER	284T1105 12294	1	27-18-11 1008/183/L040	ALL
M01150	3	CSK21169 LC FILTER	284T1105 12294	1	27-18-11 1008/183/L040	ALL
M01151	1	TRN-01-010099-01 LC FILTER	284T1105 12294	1	27-18-11 1008/183/L040	ALL
M01151	2	CSK21201 LC FILTER	284T1105 12294	1	27-18-11 1008/183/L040	ALL
M01151	3	CSK21169 LC FILTER	284T1105 12294	1	27-18-11 1008/183/L040	ALL
M01152		10167-2500-BT TIME DELAY-DOOR DOWN	285T0019 08719	1	52-11-12 P019-00/ /	ALL
M01156		S417T106 LAVATORY MID LEFT (M-L) (SEE YCF)	417T1204 81205	1	33-26-11 0833/ /L060	275-299
M01157		S417T106 LAVATORY MID RIGHT (M-R) (SEE YCG)	417T1204 81205	1	33-26-11 0833/ /R060	275-299

EQUIPMENT LIST

D280T132

Section M01100

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01161	1	530750-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0187 08719	1	32-09-11 P036-00/ /	ALL
M01161	2	TD-1982-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0187 08719	1	32-09-11 P036-00/ /	ALL
M01161	3	10167-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0187 08719	1	32-09-11 P036-00/ /	ALL
M01162	1	530750-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0187 08719	1	32-09-11 P036-00/ /	ALL
M01162	2	TD-1982-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0187 08719	1	32-09-11 P036-00/ /	ALL
M01162	3	10167-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0187 08719	1	32-09-11 P036-00/ /	ALL
M01163	1	530750-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0188 08719	1	32-09-12 P037-00/ /	ALL
M01163	2	TD-1982-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0188 08719	1	32-09-12 P037-00/ /	ALL
M01163	3	10167-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0188 08719	1	32-09-12 P037-00/ /	ALL
M01164	1	530750-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0188 08719	1	32-09-12 P037-00/ /	ALL
M01164	2	TD-1982-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0188 08719	1	32-09-12 P037-00/ /	ALL
M01164	3	10167-3000 TIME DELAY-AIR/GROUND RELAY SYSTEM	284T0188 08719	1	32-09-12 P037-00/ /	ALL
M01170	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-14 0654+85/280/L005	050-099, 150-199
M01170	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-14 0654+85/280/L005	050-099, 150-199
M01171	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-14 0961/280/R005	150-199
M01171	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-14 0852/280/0000	275-299
M01171	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-14 0961/280/R005	150-199

EQUIPMENT LIST

D280T132

Section M01100

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01171	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-14 0852/280/0000	275-299
M01177		JLW761-1 GALLEY-F1 FWD (SEE YBO)	415T1145 JAMCO	1	25-31-11 0280/BFE/	050-099, 150-199
M01177		MP761-1 GALLEY-F1 FWD (SEE YBO)	415T1145 JAMCO	1	25-31-11 0280/BFE/	275-299
M01178		JLB763-11 GALLEY-A2 L AFT (SEE YBQ)	415T1145 JAMCO	1	25-31-21 1560/BFE/	050-099, 150-199, 275-276
M01178		MP763-1 GALLEY-A2 L AFT (SEE YBQ)	415T1145 JAMCO	1	25-31-21 1560/BFE/	277-299
M01179		JLB763-11 GALLEY-A3 R AFT (SEE YBP)	415T1145 JAMCO	1	25-31-31 1560/BFE/	050-099, 150-199
M01179		MP763-1 GALLEY-A3 R AFT (SEE YBP)	S415T159 JAMCO	1	25-31-31 1560/BFE/	275-299
M01181		BFE GALLEY-AFT AUX A4 (SEE YCO)	S415T145 BFE	1	25-31-31 1500/BFE/	050-099, 150-199
M01181		MP764-1 GALLEY-AFT AUX A4 (SEE YCO)	S415T159 JAMCO	1	25-31-21 1500/BFE/	275-278
M01181		MP764-1 GALLEY-AFT AUX A4 (SEE YCO)	S415T145 JAMCO	1	25-31-21 1500/BFE/	280-299
M01182		MP765-1 GALLEY-F3 FWD (SEE YCP)	415T1106 JAMCO	1	25-31-11 0348/BFE/R055	275-299
M01186		S417T106 LAVATORY-AFT A-L (SEE YEC)	417T1202 81205	1	33-26-11 1463/ /L060	ALL
M01188		S417T106 LAVATORY-AFT A-R (SEE YEE)	417T1202 81205	1	33-26-11 1463/ /R060	ALL
M01191		S283T018-33 BALLAST-AFT DIRECT CEILING LTS (NIGHT)	417T5058 81205	1	33-22-42 0821/280/L004	275-299
M01192		S283T018-31 BALLAST-AFT DIRECT CEILING LIGHTS	417T5058 81205	1	33-22-42 0821/280/R008	275-299
M01193		S283T018-31 BALLAST-AFT DIRECT CEILING LIGHTS	417T5058 81205	1	33-22-42 0821/280/L008	275-299

EQUIPMENT LIST

D280T132

Section M01100

Page 5 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01200		2232000-02-A UNIT-DATA MANAGEMENT	284T0122 98571	1	31-35-11 SHELF/E02/02	050-099, 155-199, 276-299
M01201 T		S233T100-565 LIGHTPLATE-PNL ASSY,AIDS EVENT/PRINT SW	233T6100 81205	1	33-13-18 P008-00/ /	275-299
M01208		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFD)	417T5097 81205	1	33-51-11 0284/204/L053	ALL
M01209		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFE)	417T5097 81205	1	33-51-11 0877/202/R096	050-099, 150-199
M01209		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFE)	417T5097 81205	1	33-51-11 0873/202/R096	275-299
M01210		S283T014-3 POWER SUPPLY-EMER LTS (SEE YFF)	417T5097 81205	1	33-51-11 1540/204/R054	ALL
M01216		233T4248-10 PNL-RESERVE BRAKE & STEERING (SEE YER)	233T4100 81205	1	29-21-32 P061-00/ /	ALL
M01217	1	S281N001-1 UNIT-F/O INSTR BUS VOLTAGE SENSE	284T0997 81205	1	24-51-43 P006-03/ /	ALL
M01217	2	S281N001-2 UNIT-F/O INSTR BUS VOLTAGE SENSE	284T0997 81205	1	24-51-43 P006-03/ /	ALL
M01225		63178 GENERATOR-HYDRAULIC MOTOR	272T0188 75250	1	24-25-12 / /	ALL
M01226		21428 CONTROL UNIT-GENERATOR,HYDRAULIC	284T1168 75250	1	24-25-12 P065-00/ /	ALL
M01228		10167-5000BT MODULE-TIME DELAY	284T1168 08719	1	24-25-11 P065-00/ /	ALL
M01230		10167-5000BT MODULE-TIME DELAY	284T1168 08719	1	24-25-11 P065-00/ /	ALL
M01247		A826-1 CHILLER-AIR,R AFT	415T6126 BFE	1	25-33-11 1569/BFE/	050-099, 150-199
M01248		A826-1 CHILLER-AIR,L AFT	415T6126 BFE	1	25-33-11 1560/BFE/	050-099, 150-199
M01253		A826-1 CHILLER-AIR,FWD	415T6126 BFE	1	25-33-11 0270/BFE/	050-099, 150-199
M01255	9	KN475329 BALLAST-SIDEWALL LTS MTO 330296	413T1008 CUST	1	33-21-32 0440/295/L056	162-163

EQUIPMENT LIST

D280T132

Section M01200

Page 1

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01255		S283T018-27 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0440/295/L056	164-199
M01257		S283T018-16 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0654+84/295/L056	150-199, 275-299
M01258		S283T018-16 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0654+50/295/L020	150-199, 275-299
M01259		S283T018-28 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0748/295/L056	150-199
M01259		S283T018-24 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0654+117/295/L056	275-278
M01259		S283T018-24 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0738/295/L056	280-299
M01260		S283T018-28 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0700/295/L020	150-199
M01260		S283T018-24 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0654+91/295/L020	275-299
M01261		S283T018-28 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0754/295/L056	150-199
M01261		S283T018-28 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0748/295/L056	280-299
M01262		S283T018-28 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0747/295/L020	150-199
M01262		S283T018-28 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-11 0654+99/295/L020	280-299
M01263		S283T018-16 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-14 1197+18/295/L056	150-199
M01263		S283T018-24 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-14 1197+21/295/L056	275-299
M01264		S283T018-16 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-14 1197+27/295/L020	150-199
M01264		S283T018-24 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-14 1197+27/295/L020	275-299
M01265		S283T018-16 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-14 1197+106/295/L056	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M01200

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01266		S283T018-16 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-14 1197+115/295/L020	150-199
M01266		S283T018-16 BALLAST-INDIRECT CEILING LTS	417T5081 81205	1	33-21-14 1197+72/295/L020	275-299
M01271		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0654+57/280/R056	150-199, 275-278
M01272		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-32 0654+100/290/L056	150-199, 275-299
M01273		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0666/280/R056	275-278
M01273		S283T018-34 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-33 0677/280/R056	280-299
M01274		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1197+34/280/R056	150-199, 275-299
M01275		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1197+34/280/L056	150-199, 275-299
M01276		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-35 1197+123/280/R056	150-199, 275-299
M01277		S283T018-28 BALLAST-SIDEWALL LTS	413T1008 81205	1	33-21-34 1197+123/290/L056	150-199, 275-299
M01289		417T3052-41 MODULE-ATTND WORK LIGHT (SEE YGI)	417T3310 81205	1	33-22-31 0435/277/L060	150-199
M01295	1	S451T201-12 PDU 10L-AFT CARGO	451T2002 81205	1	25-53-24 1322/124/L029	150-199, 275-299
M01295	2	S451T201-7 PDU 10L-AFT CARGO	451T2002 81205	1	25-53-24 1322/124/L029	150-199, 275-299
M01296		S451T201-7 PDU 10R-AFT CARGO	451T2002 81205	1	25-53-24 1322/124/R029	150-154, 275-276
M01296	1	S451T201-11 PDU 10R-AFT CARGO	451T2002 81205	1	25-53-24 1322/124/R029	155-156, 162-166
M01296	1	S451T201-12 PDU 10R-AFT CARGO	451T2002 81205	1	25-53-24 1322/124/R029	157, 167-199, 277-299
M01296	2	S451T201-7 PDU 10R-AFT CARGO	451T2002 81205	1	25-53-24 1322/124/R029	155-199, 277-299

EQUIPMENT LIST

D280T132

Section M01200

Page 3

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01297		S451T201-7 PDU 9C-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/R008	150-154, 275-276
M01297	1	S451T201-11 PDU 9C-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/R008	155-156, 162-166
M01297	1	S451T201-12 PDU 9C-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/R008	157, 167-199, 277-299
M01297	2	S451T201-7 PDU 9C-AFT CARGO	451T2002 81205	1	25-53-24 1308/124/R008	155-199, 277-299
M01298	1	S451T201-11 PDU 11L-AFT CARGO	451T2002 81205	1	25-53-24 1350/124/L029	150-199, 275-299
M01298	2	S451T201-7 PDU 11L-AFT CARGO	451T2002 81205	1	25-53-24 1350/124/L029	150-199, 275-299
M01299	1	S451T201-12 PDU 11R-AFT CARGO	451T2002 81205	1	25-53-24 1350/124/R029	150-199, 275-299
M01299	2	S451T201-7 PDU 11R-AFT CARGO	451T2002 81205	1	25-53-24 1350/124/R029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M01200

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01300	1	S451T201-12 PDU 12L-AFT CARGO	451T2002 81205	1	25-53-24 1384/124/L029	150-199, 275-299
M01300	2	S451T201-7 PDU 12L-AFT CARGO	451T2002 81205	1	25-53-24 1384/124/L029	150-199, 275-299
M01301	1	S451T201-12 PDU 12R-AFT CARGO	451T2002 81205	1	25-53-24 1384/124/R029	150-199, 275-299
M01301	2	S451T201-7 PDU 12R-AFT CARGO	451T2002 81205	1	25-53-24 1384/124/R029	150-199, 275-299
M01306		S220T111-403 DECODER-COLUMN TIMER,AFT	284T0652 54473	1	23-34-11 0650/150/R066	050-099, 150-199
M01306		S220T111-403 DECODER-COLUMN TIMER,AFT	284T0652 54473	1	23-34-14 0650/150/R066	275-299
M01307		S220T111-201 ZONE MULTIPLEXER-AFT	284T0652 54473	1	23-34-11 0627/160/R070	050-099, 150-199
M01307		S220T111-201 ZONE MULTIPLEXER-AFT	284T0652 54473	1	23-34-14 0627/160/R070	275-299
M01307 T		KM89-03-M06 PLUG-TERMINATION 50 OHM M/W (J7)	284T0652 91836	1	23-34-14 SHELF/E05/	ALL
M01308		S220T111-2001 ZONE DRIVER	284T0686 54473	1	23-34-14 0298/147/R021	ALL
M01312		S417T106 LAVATORY-MID CENTER (M-C) (SEE YGT)	417T1233 81205	1	33-26-11 0852/ /0000	275-299
M01319		S220T111-403 DECODER-COLUMN TIMER,FWD	284T0686 54473	1	23-34-11 0310/195/R035	ALL
M01320		S220T111-403 DECODER-COLUMN TIMER,MID	284T0686 54473	1	23-34-11 0320/195/R035	ALL
M01321		S220T111-201 ZONE MULTIPLEXER,MID	284T0686 54473	1	23-34-11 0315/195/R025	ALL
M01325		S283T018-32 BALLAST-MID DIRECT CEILING LIGHT	417T5058 81205	2	33-27-11 0425/ /	162-199
M01330		NO-425 GLIDE SLOPE ANTENNA DIRECTOR BAR	284T0064 26066	1	34-31-21 0118/169/0000	ALL
M01361	1	S451T201-12 PDU 11R-FWD CARGO	451T2003 81205	1	25-53-14 0654+33/124/R029	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M01300

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01361	2	S451T201-7 PDU 11R-FWD CARGO	451T2003 81205	1	25-53-14 0654+033/124/R029	150-199, 275-299
M01362	1	S451T201-12 PDU 11L-FWD CARGO	451T2003 81205	1	25-53-14 0654+33/124/L029	150-199, 275-299
M01362	2	S451T201-7 PDU 11L-FWD CARGO	451T2003 81205	1	25-53-14 0654+33/124/L029	150-199, 275-299
M01363	1	S451T201-12 PDU 12R-FWD CARGO	451T2003 81205	1	25-53-14 0654+77/124/R029	150-199, 275-299
M01363	2	S451T201-7 PDU 12R-FWD CARGO	451T2003 81205	1	25-53-14 0654+77/124/R029	150-199, 275-299
M01364	1	S451T201-12 PDU 12L-FWD CARGO	451T2003 81205	1	25-53-14 0654+77/124/L029	150-199, 275-299
M01364	2	S451T201-7 PDU 12L-FWD CARGO	451T2003 81205	1	25-53-14 0654+77/124/L029	150-199, 275-299
M01365	1	S451T201-12 PDU 13R-FWD CARGO	451T2003 81205	1	25-53-14 0661/124/R029	150-199, 275-299
M01365	2	S451T201-7 PDU 13R-FWD CARGO	451T2003 81205	1	25-53-14 0661/124/R029	150-199, 275-299
M01366	1	S451T201-12 PDU 13L-FWD CARGO	451T2003 81205	1	25-53-14 0661/124/L029	150-199, 275-299
M01366	2	S451T201-7 PDU 13L-FWD CARGO	451T2003 81205	1	25-53-14 0661/124/L029	150-199, 275-299
M01367		S451T201-7 PDU 14R-FWD CARGO	451T2003 81205	1	25-53-14 0706/124/R029	150-154, 275-276
M01367	1	S451T201-11 PDU 14R-FWD CARGO	451T2003 81205	1	25-53-14 0706/124/R029	155-156, 162-166
M01367	1	S451T201-12 PDU 14R-FWD CARGO	451T2003 81205	1	25-53-14 0706/124/R029	157, 167-199, 277-299
M01367	2	S451T201-7 PDU 14R-FWD CARGO	451T2003 81205	1	25-53-14 0706/124/R029	155-199, 277-299
M01368		S451T201-7 PDU 14L-FWD CARGO	451T2003 81205	1	25-53-14 0706/124/L029	150-154, 275-276
M01368	1	S451T201-11 PDU 14L-FWD CARGO	451T2003 81205	1	25-53-14 0706/124/L029	155-156, 162-166

EQUIPMENT LIST

D280T132

Section M01300

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01368	1	S451T201-12 PDU 14L-FWD CARGO	451T2003 81205	1	25-53-14 0706/124/L029	157, 167-199, 277-299
M01368	2	S451T201-7 PDU 14L-FWD CARGO	451T2003 81205	1	25-53-14 0706/124/L029	155-199, 277-299
M01390		233T4253-10 MDL-EEC MAINT CHANNEL SEL (SEE YHG)	233T4100 81205	1	73-21-11 P061-00/ /	050-099, 162-199, 277-299
M01390		233T4253-TBD MDL-EEC MAINT CHANNEL SEL (SEE YHG)	233T4100 81205	1	73-21-11 P061-00/ /	150-157, 275-276
M01393		S283T023-1 INVERTER-E.L. EMER LTS, AFT X AISLE	417T5097 81205	1	33-51-16 1406/200/R092	275-299

EQUIPMENT LIST

D280T132

Section M01300
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01411		285T1111-1 MODULE-WEU BITE	284T5101 81205	1	27-32-12 P051-00/ /	ALL
M01413	9	285T0607-15 UN-PROPULSION I/F & MON-L ENG(SB77-0007)	284T0400 81205	1	77-35-11 SHELF/E01/03	150-154, 275-276
M01413		285T0607-15 UNIT-PROPULSION I/F & MON-L ENG	284T0400 81205	1	77-35-11 SHELF/E01/03	050-099, 155-199, 277-299
M01413		285T0607-9 UNIT-PROPULSION I/F & MON-L ENG	284T0400 81205	1	77-35-11 SHELF/E01/03	150-154, 275-276
M01414	9	285T0607-15 UN-PROPULSION I/F & MON-R ENG(SB77-0007)	284T0400 81205	1	77-35-11 SHELF/E02/04	150-154, 275-276
M01414		285T0607-15 UNIT-PROPULSION I/F & MON-R ENG	284T0400 81205	1	77-35-11 SHELF/E02/04	050-099, 155-199, 277-299
M01414		285T0607-9 UNIT-PROPULSION I/F & MON-R ENG	284T0400 81205	1	77-35-11 SHELF/E02/04	150-154, 275-276
M01432		700-1364-002 MONITOR-13" VIDEO,AFT	417T7037 97896	1	23-32-11 1270/280/0000	150-199
M01440		S253T402-4 T/R LEVER INTERLOCK-L	253T7101 81205	1	78-36-11 0150/196/0000	ALL
M01441		S253T402-4 T/R LEVER INTERLOCK-L	253T7101 81205	1	78-36-11 0150/196/0000	ALL
M01457	9	921005 DIGITAL INTERFACE UNIT (DIU)(MTO 230718)	CUSTOMER ASINC	1	23-32-21 SHELF/E01/04	150, 152-157, 164- 199
M01457		910016-801 DIGITAL INTERFACE UNIT (DIU)	284T0400 ASINC	1	23-32-21 SHELF/E01/04	050-099, 150-199
M01457		910016-1140 DIGITAL INTERFACE UNIT (DIU)	284T0400 ASINC	1	23-32-21 SHELF/E01/04	275-276
M01457		910020-5105 DIGITAL INTERFACE UNIT (DIU)	284T0400 ASINC	1	23-32-21 SHELF/E01/04	277-299
M01458		9000003-1 ACCELEROMETER LEFT-MODAL SUPPRESSION	284T4202 96774	1	22-21-11 1518/195/L072	150-199, 275-299
M01459		9000003-1 ACCELEROMETER RIGHT-MODAL SUPPRESSION	284T4202 96774	1	22-21-21 1518/195/R072	150-199, 275-299
M01460		417T3055-1010 MODULE-ATTND WORK LT (SEE YHI)	417T3318 81205	1	33-22-31 0370/276/0000	050-099, 150-199

EQUIPMENT LIST

D280T132

Section M01400

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01466	1	530740-5000 MODULE-TIME DELAY,C GEN OFF	284T1168	1	24-25-11 P065-00/ /	ALL
M01467	1	530740-5000 MODULE-TIME DELAY,C GEN ON	284T1168	1	24-25-11 P065-00/ /	ALL
M01470	1	530740-5000 MODULE-TIME DELAY,L GEN OFF	284T1168 08719	1	24-25-21 P065-00/ /	ALL
M01470	2	10167-5000BT MODULE-TIME DELAY,L GEN OFF	284T1168 08719	1	24-25-21 P065-00/ /	ALL
M01474	1	530740-5000 MODULE-TIME DELAY,R GEN OFF	284T1168 08719	1	24-25-31 P065-00/ /	ALL
M01474	2	10167-5000BT MODULE-TIME DELAY,R GEN OFF	284T1168 08719	1	24-25-31 P065-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M01400
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01523		RD-AX7308-01 TAPE DECK-PA	284T4201 54473	1	23-31-12 0348/269/L060	275-278
M01523		MAX7308FA TAPE DECK-PA (PROVISIONAL)	284T4201 54473	1	23-31-12 0654+39/269/L060	280-299
M01526		700-1316-002 COAX SIGNAL SPLITTER	284T7003 97896	1	23-32-13 0621/308/R035	050-099, 150-199
M01527		700-1316-002 COAX SIGNAL SPLITTER	284T7003 97896	1	23-32-13 1186/308/R035	150-199
M01552		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-16 0533/201/R092	050-099, 150-199
M01553		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-16 0687/201/R092	050-099
M01553		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-16 0643/201/R092	150-199
M01554		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-16 1010/201/R092	050-099, 150-199
M01555		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-16 1208/201/R092	150-199
M01556		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-16 1384/201/R092	050-099, 150-199
M01557		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-17 0511/201/L092	050-099
M01557		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-17 0489/201/L092	150-199
M01558		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-17 0731/201/L092	050-099
M01558		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-17 0654+55/201/L092	150-199
M01559		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-17 0922/201/L092	050-099
M01559		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-17 1032/201/L092	150-199
M01560		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-17 1197+33/201/L092	150-199

EQUIPMENT LIST

D280T132

Section M01500

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01561		5822-33 POWER SUPPLY-EMER LTS	417T5097 BFE	1	33-51-17 1362/201/L092	050-099, 150-199
M01562		700-1407-002 VIDEO MONITOR	417T7037 97896	1	23-32-13 0442/ /	150-199
M01563		700-1364-002 VIDEO MONITOR	417T7037 97896	1	23-32-13 0605/ /	150-199
M01584		S417T106 LAV MID SIDE-LEFT FWD (MS-LF) (SEE YHY)	417T12XX 81205	1	33-26-11 0839/200/L050	050-099
M01584		S417T106 LAV MID SIDE-LEFT FWD (MS-LF) (SEE YHY)	417T12XX 81205	1	33-26-11 0654+121/200/L050	150-199
M01585		S417T106 LAV MID CENTER-FWD (MC-F) (SEE YHZ)	417T12XX 81205	1	33-26-11 0781/200/0000	050-099
M01585		S417T106 LAV MID CENTER-FWD (MC-F) (SEE YHZ)	417T12XX 81205	1	33-26-11 0654+76/200/0000	150-199
M01586		S417T106 LAV MID SIDE-RIGHT FWD (MS-RF) (SEE YIA)	417T12XX 81205	1	33-26-11 0839/200/R050	050-099
M01586		S417T106 LAV MID SIDE-RIGHT FWD (MS-RF) (SEE YIA)	417T12XX 81205	1	33-26-11 0654+121/200/R050	150-199
M01587		S417T106 LAV MID SIDE-LEFT AFT (MS-LA) (SEE YIB)	417T1204 81205	1	33-26-11 1056/200/L050	050-099
M01587		S417T106 LAV MID SIDE-LEFT AFT (MS-LA) (SEE YIB)	417T1204 81205	1	33-26-11 0967/200/L050	150-199
M01588		S417T106 LAV MID CENTER-AFT (MC-A) (SEE YIC)	417T1204 81205	1	33-26-11 0970/200/0000	150-199
M01589		S417T106 LAV MID SIDE-RIGHT AFT (MS-RA) (SEE YID)	417T1204 81205	1	33-26-11 1056/200/R050	050-099
M01589		S417T106 LAV MID SIDE-RIGHT AFT (MS-RA) (SEE YID)	417T1204 81205	1	33-26-11 0967/200/R050	150-199
M01590	1	S417T402-4 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-13 0958/280/R060	050-099, 150-199
M01590	2	S417T402-3 MODULE-OXYGEN,LAVATORY	417T4202 81205	1	35-21-13 0958/280/R060	050-099, 150-199
M01591	1	S417T402-4 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-12 0958/280/L060	050-099, 150-199

EQUIPMENT LIST

D280T132

Section M01500

Page 2

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01591	2	S417T402-3 MODULE-OXYGEN,FLIGHT ATTENDANT	417T4203 81205	1	35-21-12 0958/280/L060	050-099, 150-199
M01596		DMQ18-2 ELT ANTENNA	284T1240 85226	1	23-24-11 1520/317/L018	050-099, 150-199
M01597		453-0004 TRANSMITTER, EMERGENCY LOCATOR	284T4206 60253	1	23-24-11 1550/304/L037	050-099, 150-199
M01598		S283T018-25 BALLAST-FWD GALLEY	417T5072 81205	1	33-27-11 0382/284/L042	050-099, 150-199
M01599		S283T018-25 BALLAST-FWD GALLEY	417T5072 81205	1	33-27-11 0382/284/L038	050-099, 150-199

EQUIPMENT LIST

D280T132

Section M01500

Page 3 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01600		S283T018-25 BALLAST-FWD GALLEY	417T5072 81205	1	33-27-11 0382/284/R042	050-099, 150-199
M01601		S283T018-25 BALLAST-FWD GALLEY	417T5072 81205	1	33-27-11 0382/284/R038	050-099, 150-199
M01602	9	S283T024-1 TIRE PRESSURE MONITOR UNIT (SB 32-0085)	284T0400 81205	1	32-45-11 SHELF/E02/06	275-276
M01602		S283T024-1 TIRE PRESSURE MONITOR UNIT	284T0400 81205	1	32-45-11 SHELF/E01/04	050-099, 155-199
M01602		S283T024-1 TIRE PRESSURE MONITOR UNIT (PROVISIONAL)	284T0400 81205	1	32-45-11 SHELF/E01/04	150-154
M01602		S283T024-1 TIRE PRESSURE MONITOR UNIT	284T0400 81205	1	32-45-11 SHELF/E02/06	277-299
M01603		MT0240308 FWD MEDICAL OUTLET	417T5009 SAS	1	25-29-12 0509/210/L090	050-099
M01603		MT0240308 FWD MEDICAL OUTLET	417T5009 SAS	1	25-29-12 0490/210/L090	150-199
M01603		MT0240308 FWD MEDICAL OUTLET	417T5009 SAS	1	25-29-12 0395/210/L090	275-299
M01604		MT0240308 AFT MEDICAL OUTLET	417T5009 SAS	1	25-29-12 1385/210/L090	050-099
M01604		MT0240308 AFT MEDICAL OUTLET	417T5009 SAS	1	25-29-12 1413/210/L090	150-157
M01604		MT0240308 AFT MEDICAL OUTLET	417T5009 SAS	1	25-29-12 1379/210/L090	162-199
M01604		MT0240308 AFT MEDICAL OUTLET	417T5009 SAS	1	25-29-12 1410/210/L090	275-299
M01605		KSSU463303 MEDICAL OUTLETS INVERTER-28DC/115-60HZ	BFE00000 BFE	1	25-29-12 0628/160/R080	ALL
M01606		KSSU463304 MEDICAL OUTLETS INVERTER-28DC/220-50HZ	BFE00000 BFE	1	25-29-12 0628/160/R080	ALL
M01607		S252U200 MODULE-STAB TRIM CONT,LEFT (SEE YII)	251T4200 81205	1	27-41-11 1726/280/L007	050-099, 155-199, 275-299
M01608		S252U200 MODULE-STAB TRIM CONT,RIGHT (SEE YIJ)	251T4200 81205	1	27-41-21 1726/280/R007	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section M01600

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01609		S210T130-72 CONTROLLER-AUX ZONE	284T0115 81205	1	21-61-51 SHELF/E01/05	ALL
M01610	9	285T1150-2 CONTLR-PACK FLOW & CARGO A/C(SB 21-0079)	00000000 81205	1	21-28-11 SHELF/E01/05	150-154, 275
M01610	2	285T1150-2 CONTROLLER-PACK FLOW & CARGO A/C	00000000 81205	1	21-28-11 SHELF/E01/05	277-299
M01610	3	285T1150-1 CONTROLLER-PACK FLOW & CARGO A/C	00000000 81205	1	21-28-11 SHELF/E01/05	050-099, 155-199, 276-299
M01611		700-1407-002 VIDEO MONITOR	417T7037 97896	1	23-32-11 0650/280/0000	151-152, 162-199
M01612		700-1364-002 VIDEO MONITOR	417T7037 97896	1	23-32-11 0815/280/0000	151-152, 162-199
M01613		743-0214-001 VTR-3,VIDEO	284T1241 97896	1	23-32-11 0441/220/L090	150-199
M01614	9	914014 CABIN CONT UNIT/MODE SEL SW (MTO 230540)	284T1241 ASINC	1	23-32-21 0447/245/L080	050-099
M01614		914014 CABIN CONTROL UNIT/MODE SELECT SWITCH	284T1241 ASINC	1	23-32-21 0447/245/L080	151-152
M01614		914014 CABIN CONTROL UNIT/MODE SELECT SWITCH	284T1241 ASINC	1	23-32-21 0245/267/L012	275-276
M01614		913002 CABIN CONTROL UNIT/MODE SELECT SWITCH	284T1241 ASINC	1	23-32-21 0245/267/L012	277-299
M01615		700-1316-002 COAX SIGNAL SPLITTER	284T7003 97896	1	23-32-13 0730/308/R036	150-199
M01616		DMU-60-1 ASSY-COAX,ANTENNA,EMERGENCY LOCATOR	284T4206 85226	1	23-24-11 1520/317/L019	050-099, 150-199
M01617		S281T003-1 ELCU-FWD GALLEY POWER A	284T0172 81205	1	25-31-11 P032-00/ /	050-099, 150-199
M01618		S281T003-1 ELCU-FWD GALLEY POWER B	284T0172 81205	1	25-31-12 P032-00/ /	050-099, 150-199
M01619	9	233T3245-7 CONT PNL-FWD CARGO TEMP(YIH)(SB 21-0083)	233T3100 81205	1	21-61-81 P005-00/ /	050-099
M01619	9	233T3245-8 CONT PNL-FWD CARGO TEMP(YIH)(SB 21-0083)	233T3100 81205	1	21-61-81 P005-00/ /	150-152

EQUIPMENT LIST

D280T132

Section M01600

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01619	9	233T3245-7 CONT PNL-FWD CARGO TEMP (YIH)	233T3100 81205	1	21-61-81 P005-00/ /	153-154, 162-165, 275-276
M01619		233T3245-7 CONT PNL-FWD CARGO TEMP (YIH)	233T3100 81205	1	21-61-81 P005-00/ /	155-157, 166-199, 277-299
M01620	9	S283T024-2 UNIT-NOSE WHEEL INTERFACE 10(SB 32-0085)	166T0100 81205	1	32-45-12 RNOSE-/ /10-	275-276
M01620		S283T024-2 UNIT-NOSE WHEEL INTERFACE 10	166T0100 81205	1	32-45-12 RNOSE-/ /10-	050-099, 155-199, 277-299
M01621	9	S283T024-2 UNIT-NOSE WHEEL INTERFACE 9 (SB 32-0085)	166T0100 81205	1	32-45-12 LNOSE-/ /09-	275-276
M01621		S283T024-2 UNIT-NOSE WHEEL INTERFACE 9	166T0100 81205	1	32-45-12 LNOSE-/ /09-	050-099, 155-199, 277-299
M01622	9	S283U006-2 UNIT-WHEEL INTERFACE 8 (SB 32-0085)	165T0100 81205	1	32-45-14 WHEEL-/ /08-	275-276
M01622		S283U006-2 UNIT-WHEEL INTERFACE 8	165T0100 81205	1	32-45-14 WHEEL-/ /08-	050-099, 155-199, 277-299
M01623	9	S283U006-2 UNIT-WHEEL INTERFACE 7 (SB 32-0085)	165T0100 81205	1	32-45-14 WHEEL-/ /07-	275-276
M01623		S283U006-2 UNIT-WHEEL INTERFACE 7	165T0100 81205	1	32-45-14 WHEEL-/ /07-	050-099, 155-199, 277-299
M01624	9	S283U006-2 UNIT-WHEEL INTERFACE 6 (SB 32-0085)	165T0100 81205	1	32-45-13 WHEEL-/ /06-	275-276
M01624		S283U006-2 UNIT-WHEEL INTERFACE 6	165T0100 81205	1	32-45-13 WHEEL-/ /06-	050-099, 155-199, 277-299
M01625	9	S283U006-2 UNIT-WHEEL INTERFACE 5 (SB 32-0085)	165T0100 81205	1	32-45-13 WHEEL-/ /05-	275-276
M01625		S283U006-2 UNIT-WHEEL INTERFACE 5	165T0100 81205	1	32-45-13 WHEEL-/ /05-	050-099, 155-199, 277-299
M01626	9	S283U006-2 UNIT-WHEEL INTERFACE 4 (SB 32-0085)	165T0100 81205	1	32-45-14 WHEEL-/ /04-	275-276
M01626		S283U006-2 UNIT-WHEEL INTERFACE 4	165T0100 81205	1	32-45-14 WHEEL-/ /04-	050-099, 155-199, 277-299
M01627	9	S283U006-2 UNIT-WHEEL INTERFACE 3 (SB 32-0085)	165T0100 81205	1	32-45-14 WHEEL-/ /03-	275-276

EQUIPMENT LIST

D280T132

Section M01600

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01627		S283U006-2 UNIT-WHEEL INTERFACE 3	165T0100 81205	1	32-45-14 WHEEL-/ /03-	050-099, 155-199, 277-299
M01628	9	S283U006-2 UNIT-WHEEL INTERFACE 2 (SB 32-0085)	165T0100 81205	1	32-45-13 WHEEL-/ /02-	275-276
M01628		S283U006-2 UNIT-WHEEL INTERFACE 2	165T0100 81205	1	32-45-13 WHEEL-/ /02-	050-099, 155-199, 277-299
M01629	9	S283U006-2 UNIT-WHEEL INTERFACE 1 (SB 32-0085)	165T0100 81205	1	32-45-13 WHEEL-/ /01-	275-276
M01629		S283U006-2 UNIT-WHEEL INTERFACE 1	165T0100 81205	1	32-45-13 WHEEL-/ /01-	050-099, 155-199, 277-299
M01630		10150F11 GALLEY-F4 FWD (YIF)	415T11XX SELL	1	25-31-41 / /	150-199
M01631		RD-AC1203-5B1 PRINTER-MULTI INPUT	233T6100 54473	1	31-36-11 P008-00/ /	050-099, 155-199, 276-299
M01633		65B47524-10 CARD-PASS ADRS VOL LVL IND	284T0400 81205	1	23-31-11 SHELF/E02/05	050-099, 150-199
M01634		69B47616-5 CARD-PASS ADRS SWITCHING	284T0400 81205	1	23-31-14 SHELF/E02/05	150-199
M01635		69B47616-5 CARD-PASS ADRS SWITCHING	284T0400 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
M01636		S281T003-1 ELCU-AFT GALLEY POWER	284T0171 81205	1	25-31-21 P031-00/ /	050-099, 150-199
M01637		S283U008-16 BALLAST	413T2330 81205	1	33-22-32 0450/240/L055	150-199
M01640		PU90-13000-1 INDICATOR PNL-REMOTE SMOKE DETECTION-FWD	284T4201 S5065	1	26-13-11 0284/260/L060	050-099, 150-154, 162-163
M01640		PU90-13000A1 INDICATOR PNL-REMOTE SMOKE DETECTION-FWD	284T4201 S5065	1	26-13-11 0284/260/L060	155-157, 164-199
M01641		PU90-13000A1 INDICATOR PNL-REMOTE SMOKE DETECTION-AFT	284T4201 S5065	1	26-13-11 1540/260/L060	050-099, 150-199
M01655		417T4206-216 MODULE-MID ATTND (SEE YIL)	417T4106 81205	4	33-22-31 0347/260/L055	275-278
M01655		417T4206-TBD MODULE-MID ATTND (SEE YIL)	417T4106 81205	4	33-22-31 0347/260/L055	280-299

EQUIPMENT LIST

D280T132

Section M01600

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01656		285T0007-30 WEU-CHASSIS	284T0049 81205	1	31-51-11 P051-00/ /	ALL
M01658		600448-0001 VDU-1	284T1246 62204	1	23-32-31 0401/308/R038	275-299
M01659		700-1597-001 MONITOR/PROJ. -1	417T7001 97896	1	23-32-11 0497/250/R070	050-099
M01659		498392-0002 MONITOR/PROJ. -1	417T7037 62204	1	23-32-31 0390/295/L038	275-278
M01659		498392-0002 MONITOR/PROJ. -1	417T7037 62204	1	23-32-31 0410/295/L038	280-299
M01660		498392-0002 MONITOR/PROJ-2	417T7037 62204	1	23-32-31 0390/295/R038	275-278
M01660		498392-0002 MONITOR/PROJ-2	417T7037 62204	1	23-32-31 0410/295/R038	280-299
M01661		600448-0001 VDU-2	284T1246 62204	1	23-32-32 0401/308/R038	275-299
M01662		498392-0002 MONITOR/PROJ. -3	417T7TBD 62204	1	23-32-32 0565/295/L038	275-278
M01662		RD-AV7073 MONITOR/PROJ. -3	417T7037 54473	1	23-32-32 0539/260/L070	280-299
M01663		498392-0002 MONITOR-4	417T7037 62204	1	23-32-32 0565/295/R038	275-278
M01663		RD-AV7073 MONITOR-4	417T7037 54473	1	23-32-32 0539/260/R070	280-299
M01664		600448-0001 VDU-3	284T1246 62204	1	23-32-33 0401/308/R038	275-299
M01665		601585-0001 MONITOR-5	417T7037 62204	1	23-32-33 0362/260/L070	275-276
M01665		RD-AV7073 MONITOR-5	R17T7037 54473	1	23-32-33 0385/260/L070	277-278
M01666		601585-0001 MONITOR-6	417T7037 62204	1	23-32-33 0362/260/R070	275-276
M01666		RD-AV7073 MONITOR-6	417T7037 54473	1	23-32-33 0385/260/R070	277-278

EQUIPMENT LIST

D280T132

Section M01600

Page 5

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01666		RD-AV7073 MONITOR-6	417T7037 54473	1	23-32-33 0386/260/R070	280-299
M01667		600448-0001 VDU-4	284T1246 62204	1	23-32-34 0401/308/R038	275-299
M01668		600958-0001 MONITOR-7	417T7037 62204	1	23-32-34 0350/260/0000	275-278
M01668		RD-AV7073 MONITOR-7	417T7037 54473	1	23-32-34 0376/260/0000	280-299
M01670		600448-0001 VDU-5	284T1246 62204	1	23-32-41 0731/308/R038	275-299
M01671		498392-0002 MONITOR/PROJ. -9	417T7037 62204	1	23-32-41 0695/295/L038	275-278
M01672		498392-0002 MONITOR/PROJ. -10	417T7037 62204	1	23-32-41 0695/295/R038	275-278
M01673		600448-0001 VDU-6	284T1246 62204	1	23-32-42 0731/308/R038	275-299
M01674		601585-0001 MONITOR-11	417T7037 62204	1	23-32-42 0654+120/260/L070	275-276
M01674		RD-AV7073 MONITOR-11	417T7037 54473	1	23-32-42 0858/260/L070	277-278
M01675		601585-0001 MONITOR-12	417T7037 62204	1	23-32-42 0654+120/260/R070	275-276
M01675		RD-AV7073 MONITOR-12	417T7037 54473	1	23-32-42 0858/260/R070	277-278
M01676		600448-0001 VDU-7	284T1246 62204	1	23-32-43 0731/308/R038	275-299
M01677		498392-0002 MONITOR-13	417T7037 62204	1	23-32-43 0563/280/L038	280-299
M01679		600448-0001 VDU-9	284T1246 62204	1	23-32-51 1032/308/R038	275-299
M01680		600958-0001 MONITOR/PROJ-15	417T7037 62204	1	23-32-51 0825/280/L038	275-278
M01680		600958-0001 MONITOR/PROJ-15	417T7037 62204	1	23-32-51 0864/280/L038	280-299

EQUIPMENT LIST

D280T132

Section M01600

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01681		600958-0001 MONITOR/PROJ-16	417T7037 62204	1	23-32-51 0825/280/R038	275-278
M01681		600958-0001 MONITOR/PROJ-16	417T7037 62204	1	23-32-51 0864/280/R038	280-299
M01682		600448-0001 VDU-10	284T1246 62204	1	23-32-52 1032/308/R038	275-299
M01683		498392-0002 MONITOR-17	417T7037 62204	1	23-32-52 0995/280/L038	275-299
M01684		498392-0002 MONITOR-18	417T7037 62204	1	23-32-52 0995/280/R038	275-299
M01685		600448-0001 VDU-11	284T1246 62204	1	23-32-53 1032/308/R038	275-299
M01686		498392-0002 MONITOR-19	417T7037 62204	1	23-32-53 1172/280/L038	275-299
M01687		498392-0002 MONITOR-20	417T7037 62204	1	23-32-53 1172/280/R038	275-299
M01688		600448-0001 VDU-12	284T1528 62204	1	23-32-54 1032/308/R038	280-299
M01689		RD-AV7073 MONITOR-21	417T7037 54473	1	23-32-54 0858/260/L070	280-299
M01690		RD-AV7073 MONITOR-22	417T7037 54473	1	23-32-54 0858/260/R070	280-299
M01691		600448-0001 VDU-13	284T1246 62204	1	23-32-61 1362/308/R038	275-299
M01692		498392-0002 MONITOR-23	417T7037 62204	1	23-32-61 1220/280/L038	275-299
M01693		498392-0002 MONITOR-24	417T7037 62204	1	23-32-61 1220/280/R038	275-278
M01693		498392-0002 MONITOR-24	417T7037 62204	1	23-32-61 1217/280/R038	280-299
M01694		600448-0001 VDU-14	284T1246 62204	1	23-32-62 1362/308/R038	275-299
M01695		498392-0002 MONITOR-25	417T7037 62204	1	23-32-62 1370/280/L038	275-278

EQUIPMENT LIST

D280T132

Section M01600

Page 7

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01695		498392-0002 MONITOR-25	417T7037 62204	1	23-32-62 1392/280/L038	280-299
M01696		498392-0002 MONITOR-26	417T7037 62204	1	23-32-62 1370/280/R038	275-278
M01696		498392-0002 MONITOR-26	417T7037 62204	1	23-32-62 1392/280/R038	280-299
M01697		600927-0001 TERMINATION PLUG M/W M1676 J3	284T1246 62204	1	23-32-43 0731/308/R038	275-278
M01697		600927-0001 TERMINATION PLUG M/W M1711 J3	284T1246 62204	1	23-32-43 0731/308/R038	280-299
M01698		600927-0001 TERMINATION PLUG M/W M1694 J3	284T1246 62204	1	23-32-62 1362/308/R038	275-299

EQUIPMENT LIST

D280T132

Section M01600
Page 8 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01705	9	4066010-904 TCAS PROCESSOR (MTO 340652)	CUSTOMER 56232	1	34-45-11 SHELF/E01/03	050-099, 150-152, 155-199, 275-299
M01705	9	4066010-904 TCAS PROCESSOR (MTO 340652)	284T0113 58960	1	34-45-11 SHELF/E01/03	153-154
M01706	9	7514081-901 TCAS ANTENNA TOP (MTO 340652)	284T1249 58960	1	34-45-11 0380/315/0000	ALL
M01707	9	7514081-901 TCAS ANTENNA BOTTOM (MTO 340652)	284T1249 58960	1	34-45-11 0399/102/0000	ALL
M01708		RD-AX7303 REPRODUCER-BOARDING MUSIC TAPE	284T4208 54473	1	23-31-12 PURSER/STA/	151-199
M01710		S220T111-2001 ZONE DRIVER	284T0686 54473	1	23-34-14 0298/147/R021	050-099, 150-199
M01711		600448-0001 VDU-8	284T1246 62204	1	23-32-44 0731/308/R038	280-299
M01730		S343T002-8 PUMP-FUEL JETTISON, L (PROVISIONAL)	343T0002 81205	1	28-31-21 L0224/014/MS	050-099, 162-164, 276
M01730		S343T002-8 PUMP-FUEL JETTISON, L	343T0002 81205	1	28-31-21 L0224/014/MS	155-157, 165-199, 277-299
M01731		S343T002-8 PUMP-FUEL JETTISON, R (PROVISIONAL)	343T0002 81205	1	28-31-21 R0224/014/MS	050-099, 162-164, 276
M01731		S343T002-8 PUMP-FUEL JETTISON, R	343T0002 81205	1	28-31-21 R0224/014/MS	155-157, 165-199, 277-299
M01733	9	233T3243-12 PNL-FUEL JETTISON (SB 28-0030)	233T3100 81205	1	28-31-11 P005-00/ /	051-099
M01733		233T3243-12 PNL-FUEL JETTISON	233T3100 81205	1	28-31-11 P005-00/ /	050, 162-164
M01733		233T3243-15 PNL-FUEL JETTISON	233T3100 81205	1	28-31-11 P005-00/ /	155-157, 165-199, 277-299
M01733		233T3243-9 PNL-FUEL JETTISON	233T3100 81205	1	28-31-11 P005-00/ /	276
M01734		S283T018-34 BALLAST-DIRECT CEILING LTS	417T5058 81205	1	33-27-11 1526/280/L006	275-299
M01735		S283T018-32 BALLAST-DIRECT CEILING LTS	417T5058 81205	1	33-27-11 1526/280/R006	275-299

EQUIPMENT LIST

D280T132

Section M01700

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01736	9	2230666-01-A AIRBORNE DATA LOADER/RCDR (SB 31-0031)	233T4100 98571	1	34-61-15 P061-00/ /	150-154
M01736		2230666-1 AIRBORNE DATA LOADER/RECORDER	233T4100 98571	1	34-61-15 P061-00/ /	050-099, 276
M01736		2230666-01-A AIRBORNE DATA LOADER/RECORDER	233T4100 98571	1	34-61-15 P061-00/ /	155-199, 277-299
M01737	9	233T4256-1 ABN DATA LDR/RCDR CS (SB 31-0031)	233T4100 81205	1	34-61-15 P061-00/ /	150-154
M01737		233T4256-1 AIRBORNE DATA LOADER/RECORDER CONTROL SW	233T4100 81205	1	34-61-15 P061-00/ /	050-099, 155-199, 275-299
M01739	9	S231T330-2 MODULE-L ICE DETECTOR (SB 30-0017)	233T9180 81205	1	30-81-01 0208.5/167/L063	150-154
M01739		S231T330-2 MODULE-L ICE DETECTOR	233T9180 81205	1	30-81-01 0208.5/167/L063	050-099, 155-199
M01740	9	S231T330-2 MODULE-R ICE DETECTOR (SB 30-0017)	233T9180 81205	1	30-81-01 0208.5/167/R063	150-154
M01740		S231T330-2 MODULE-R ICE DETECTOR	233T9180 81205	1	30-81-01 0208.5/167/R063	050-099, 155-199
M01751	1	S417T402-4 OXY MDL-FLT DECK CREW REST	417T4204 81205	1	35-21-14 0274/278/R015	050-099, 162-199
M01751	2	S417T402-3 OXY MDL-FLT DECK CREW REST	417T4204 81205	1	35-21-14 0274/278/R015	050-099, 162-199
M01752	1	S417T402-4 OXY MDL-FLT DECK CREW REST	417T4204 81205	1	35-21-14 0274/242/R015	050-099, 162-199
M01752	2	S417T402-3 OXY MDL-FLT DECK CREW REST	417T4204 81205	1	35-21-14 0274/242/R015	050-099, 162-199
M01753	9	233T4257-1 MDL-ICE DET SYS TEST (SEE YIS) SB30-0017	233T3100 81205	1	30-81-01 P061-00/ /	150-154
M01753		233T4257-1 MODULE-ICE DETECT SYS TEST (SEE YIS)	233T3100 81205	1	30-81-01 P061-00/ /	050-099, 155-199
M01755		S220T111-501 PSUD-CREW REST	413T3280 81205	1	23-34-15 0252/274/R015	050-099
M01755 T		S220T111-801 PLUG-TERMINATION PSUD	00000000 81205	1	23-34-15 0252/274/R015	050-099

EQUIPMENT LIST

D280T132

Section M01700

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01756		S220T111-305 SEB-CREW REST	413T3285 81205	1	23-34-15 0251/275/L011	050-099
M01757		RD-AX6537 PCU-CREW REST LOWER BUNK	00000000 54473	1	23-34-15 0250/235/R009	050-099
M01758		RD-AX6537 PCU-CREW REST UPPER BUNK	00000000 54473	1	23-34-15 0250/263/R009	050-099
M01761		417T3074 MODULE-CREW REST CONTROL	00000000 81205	3	33-21-31 MULTI/ /	050-099, 162-199
M01764		617852-1 TEMP SELECTOR-FLT DK CREW REST	214T2058 07217	1	21-66-11 0247/250/L014	050-099, 162-199
M01766	9	617852-1 TEMP SELECTOR-AFT LH CABIN CREW REST	284T0187 07217	1	21-66-31 1419/267/L063	150, 152-157
M01766		617852-1 TEMP SELECTOR-AFT LH CABIN CREW REST	284T0187 07217	1	21-66-31 1419/267/L063	050-099, 162-199
M01767	9	617852-1 TEMP SELECTOR-AFT RH CABIN CREW REST	284T0187 07217	1	21-66-41 1419/267/R063	150, 152-157
M01767		617852-1 TEMP SELECTOR-AFT RH CABIN CREW REST	284T0187 07217	1	21-66-41 1419/267/R063	050-099, 162-199
M01768		617852-1 TEMP SELECTOR-FWD CABIN CREW REST	214T0001 07217	1	21-66-21 0441/267/R063	050-099, 162-199
M01769		S210T172-2 CREW REST TEMP CONTROLLER	214T2058 195650	1	21-66-11 0435/294/L016	050-099, 162-199
M01770		S210T172-2 TEMP CONTROLLER-FWD CABIN CREW REST	214T0001 195650	1	21-66-21 0435/294/R016	050-099, 162-199
M01771	9	S210T172-2 TEMP CONTROLLER-AFT LH CREW REST	214T0006 195650	1	21-66-31 1428/294/L018	150, 152-157
M01771		S210T172-2 TEMP CONTROLLER-AFT LH CREW REST	214T0006 195650	1	21-66-31 1428/294/L018	050-099, 162-199
M01772	9	S210T172-2 TEMP CONTROLLER-AFT RH CREW REST	214T0006 195650	1	21-66-41 1428/294/R018	150, 152-157
M01772		S210T172-2 TEMP CONTROLLER-AFT RH CREW REST	214T0006 195650	1	21-66-41 1428/294/R018	050-099, 162-199
M01776		RD-AV7073 MONITOR-28	417T7037 54473	1	23-32-44 0866/260/0000	280-299

EQUIPMENT LIST

D280T132

Section M01700

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01780	9	7516100-19034 SATELLITE DATA UNIT (SDU)	284T1306 58960	1	23-25-11 SHELF/E09/01	150, 153-199
M01780		622-8848-002 SATELLITE DATA UNIT (SDU)	284T1306 13499	1	23-25-11 SHELF/E09/01	167-199
M01781	9	7516240-19034 RADIO FREQUENCY UNIT (RFU)	284T1306 58960	1	23-25-12 SHELF/E09/01	150, 153-199
M01781		622-8849-001 RADIO FREQUENCY UNIT (RFU)	284T1306 13499	1	23-25-12 SHELF/E09/01	167-199
M01782	9	7516250-19034 HIGH POWER AMP (HPA) (MTO-238591/2/3)	284T1331 58960	1	23-25-17 SHELF/E10/	150, 153-166
M01782	9	7516250-19034 HIGH POWER AMP (HPA) (MTO-230592/2/3)	284T1331 58960	1	23-25-17 SHELF/E10/	167-199
M01782		622-8850-001 HIGH POWER AMP (HPA)	284T1331 13499	1	23-25-16 SHELF/E10/	167-199
M01783		622-8850-001 HIGH POWER AMP (HPA)	284T1331 13499	1	23-25-11 SHELF/E11/	167-199
M01784		850-0009-010 RF SPLITTER	284T1331 13499	1	23-25-11 1125/294/L016	167-199
M01786	9	300114-500 RF COMBINER (MTO-238591/2/3)	284T1331 OESR2	1	23-25-12 1125/294/L016	150, 153-166
M01786	9	300114-500 RF COMBINER (MTO-238591/2/3)	284T1331 OESR2	1	23-25-12 1125/294/L016	167-199
M01786		850-0009-010 RF COMBINER	284T1331 13499	1	23-25-11 1125/294/L016	167-199
M01787	9	301706-500 RELAY-HIGH POWER (MTO-238591/2/3)	284T1331 OESR2	1	23-25-17 1070/300/L016	150, 153-199
M01788		100-602073-001 LNA/DIP - TOP HGA	284T1313 90073	1	23-25-16 1030/310/L015	167-199
M01789	9	511610-500 LNA/DIPLEXER ASSEMBLY-PORT	284T1384 OESR2	1	23-25-17 1100/285/L060	150, 153-199
M01790	9	511610-500 LNA-DIPLEXER ASSEMBLY-STBD	284T1384 OESR2	1	23-25-17 1100/285/R060	150, 153-199
M01791		511610-500 LNA/DIP (LGA)	284T1314 13993	1	23-25-11 1197+32/310/L010	167-199

EQUIPMENT LIST

D280T132

Section M01700

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01792		100-602066-001 HIGH GAIN ANTENNA (HGA TOP)	284T1316 90073	1	23-25-16 1037/ /	167-199
M01793	9	513738-506 HIGH GAIN ANTENNA-PORT (MTO-238591/2/3)	284T1385 OESR2	1	23-25-17 1100/280/L079	150, 153-199
M01794	9	513738-506 HIGH GAIN ANTENNA-STBD (MTO-238591/2/3)	284T1385 OESR2	1	23-25-17 1100/280/R079	150, 153-199
M01795	9	513739-504-49 BEAM STEERING UNIT-PORT (MTO-238591/2/3)	284T1384 OESR2	1	23-25-17 1100/277/L075	150, 153-199
M01796	9	513739-504-49 BEAM STEERING UNIT-STBD (MTO-238591/2/3)	284T1384 OESR2	1	23-25-17 1100/277/R075	150, 153-199
M01797		100-602076-001 BEAM STEERING UNIT	284T1306 90073	1	23-25-16 / /	167-199
M01798	9	G7164-03 PNL-HF/SAT SWITCH (MTO-238591/2/3)	233T3100 99837	1	23-25-14 / /	150, 153-155, 162-165
M01798		233T3246-1 PNL-HF/SAT SWITCH	233T3100 81205	1	23-25-14 / /	156-157, 166-199
M01798		233T3246-300 PNL-HF/SAT SWITCH	233T3100 81205	1	23-25-14 / /	277-299
M01799	9	513881-502 CABLE ASSEMBLY-PORT/AFT (MTO-238591/2/3)	284T1312 OESR2	1	23-25-17 1115/275/L078	150, 153-199

EQUIPMENT LIST

D280T132

Section M01700
Page 5 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01800	9	513881-503 CABLE ASSEMBLY-PORT/FWD	284T1312 OESR2	1	23-25-17 1085/275/L078	150, 153-199
M01801	9	513881-503 CABLE ASSEMBLY-STBD/AFT (MTO-238591/2/3)	284T1312 OESR2	1	23-25-17 1115/275/R078	150, 153-199
M01802	9	513881-502 CABLE ASSEMBLY-STBD/FWD (MTO-238591/2/3)	284T1312 OESR2	1	23-25-17 1085/275/R078	150, 153-199
M01803	9	BACR13CG2AB RELAY-HF/SAT-L (MTO-238591/2/3)	284T0400 81205	1	23-25-14 SHELF/E02/06	150, 153-199
M01803		BACR13CG2AB RELAY-HF/SAT-L	284T0400 81205	1	23-25-14 SHELF/E02/06	156-157, 166-199
M01803		BACR13CG2AB RELAY-HF/SAT-L	284T1300 81205	1	23-25-14 SHELF/E02/06	277-299
M01804		511611-500 LOW GAIN ANTENNA (LGA)	284T1317 13993	1	23-25-11 1197+33/320/L010	167-199
M01805	9	BACR13CG2AB RELAY-HF/SAT-R (MTO-238591/2/3)	284T0400 81205	1	23-25-14 SHELF/E02/06	150, 153-199
M01805		BACR13CG2AB RELAY-HF/SAT-R	284T0400 81205	1	23-25-14 SHELF/E02/06	156-157, 166-199
M01805		BACR13CG2AB RELAY-HF/SAT-R	284T1300 81205	1	23-25-14 SHELF/E02/06	277-299
M01834		PU90-419R2 DETECTOR-SMOKE, CABIN CREW REST AREA	00000000 S5065	1	26-13-12 0437/275/R055	050-099, 162-199
M01835	9	280T1003-1 RCPT-SATCOM CODING (MTO-238591/2/3)	284T1308 81205	1	23-25-15 SHELF/E09/	150, 153-155, 162-165
M01835		280T1003-1 RCPT-SATCOM CODING	284T1308 81205	1	23-25-15 SHELF/E09/	156-157, 166-199, 277-299
M01842	9	41SG265-1 XMTR-PRESSURE,AIR (SB 36-0029)	212T3010 02750	1	36-11-61 ISS/326/	050-099, 150-155, 162-165, 275-276
M01842		41SG265-1 XMTR-PRESSURE,AIR	212T3010 02750	1	36-11-61 ISS/326/	156-157, 166-199, 277-299
M01843	9	41SG265-1 XMTR-PRESSURE,AIR (SB 36-0029)	212T3010 02750	1	36-11-62 ISS/326/	050-099, 150-155, 162-165, 275-276
M01843		41SG265-1 XMTR-PRESSURE,AIR	212T3010 02750	1	36-11-62 ISS/326/	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section M01800

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01848		PU90-419 DETECTOR-SMOKE,FLIGHT CREW REST AREA	218T3005 S5065	1	26-13-12 0265/280/L016	050-099, 162-199
M01889		PU90-419 DETECTOR-SMOKE, CABIN CREW REST AREA	218T3005 S5065	2	26-13-12 1450/280/L055	050-099, 162-199
M01889		PU90-419 DETECTOR-SMOKE, CABIN CREW REST AREA	218T3005 S5065	2	26-13-12 1450/280/R055	150, 152-157

EQUIPMENT LIST

D280T132

Section M01800
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01901		S283T018-33 BALLAST-SIDEWALL WASHLIGHT	417T5081 81205	1	33-21-33 0664/295/L056	280-299
M01908		498392-0002 MONITOR/PROJ-14	417T7037 62204	1	23-32-43 0563/280/R038	280-299
M01923		MP766-1 GALLEY-F4 FWD (SEE YIF)	415T1157 JAMCO	1	25-31-11 0360/ /L050	275-276
M01923		MP766-1 GALLEY-F4 FWD (SEE YIF)	415T1157 JAMCO	1	25-31-11 0346/243/0	277-299
M01953		SAS ACARS VOICE/DATA SWITCH	CUSTOMER	0	23-22-11 P008-00/ /	275-299
M01977	9	233T4259-1 MODULE-THRUST REVERSER (SB 78-0051FAA)	233T4100 81205	1	78-36-11 P061-00/ /	050-099, 150-156, 162-166, 275-276
M01977		233T4259-1 MODULE-THRUST REVERSER (RR 41033-23)	233T4100 81205	1	78-36-11 P061-00/ /	157
M01977		233T4259-1 MODULE-THRUST REVERSER (RR 41033-24)	233T4100 81205	1	78-36-11 P061-00/ /	167-199
M01977		233T4259-1 MODULE-THRUST REVERSER (RR 41034-2)	233T4100 81205	1	78-36-11 P061-00/ /	277-278
M01977		233T4259-1 MODULE-THRUST REVERSER (RR 41034-21)	233T4100 81205	1	78-36-11 P061-00/ /	280-299
M01978	9	TD-1982-5001 MDL-TIME DELAY,L T/R RESTOW(SB78-051FAA)	284T0189 35344	1	78-36-11 P033-00/ /	050-099, 150-156, 162-166, 275-276
M01978		TD-1982-5001 MDL-TIME DELAY,L T/R RESTOW(RR 41033-23)	284T0189 35344	1	78-36-11 P033-00/ /	157
M01978		TD-1982-5001 MDL-TIME DELAY,L T/R RESTOW(RR 41033-24)	284T0189 35344	1	78-36-11 P033-00/ /	167-199
M01978		TD-1982-5001 MDL-TIME DELAY,L T/R RESTOW(RR 41034-20)	284T0189 35344	1	78-36-11 P033-00/ /	277-278
M01978		TD-1982-5001 MDL-TIME DELAY,L T/R RESTOW(RR 41034-21)	284T0189 35344	1	78-36-11 P033-00/ /	280-299
M01979	9	TD-1982-5001 MDL-TIME DELAY,R T/R RESTOW(SB78-051FAA)	284T0189 35344	1	78-36-21 P033-00/ /	050-099, 150-156, 162-166, 275-276
M01979		TD-1982-5001 MDL-TIME DELAY,R T/R RESTOW(RR 41033-23)	284T0189 35344	1	78-36-21 P033-00/ /	157

EQUIPMENT LIST

D280T132

Section M01900

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M01979		TD-1982-5001 MDL-TIME DELAY,R T/R RESTOW(RR 41033-24)	284T0189 35344	1	78-36-21 P033-00/ /	167-199
M01979		TD-1982-5001 MDL-TIME DELAY,R T/R RESTOW(RR 41034-20)	284T0189 35344	1	78-36-21 P033-00/ /	277-278
M01979		TD-1982-5001 MDL-TIME DELAY,R T/R RESTOW(RR 41034-21)	284T0189 35344	1	78-36-21 P033-00/ /	280-299
M01987	9	285T0708-3 MODULE-THRUST REVERSER RELAY(SB 78-0062)	284T0400 81205	1	78-36-11 SHELF/E01/05	ALL
M01990	9	TD-1982-2001 TD-L T/R SSL UNLATCH (SB 78-0062)	284T0189 81205	1	78-34-11 P033-00/ /	ALL
M01991	9	TD-1982-2001 TD-R T/R SSL UNLATCH (SB 78-0062)	284T0189 81205	1	78-34-21 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M01900
Page 2 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M02187	9	RF14934 FSEU LC FILTER (SB 27-0131)	284T0009 13619	1	27-51-61 0355/166/R013	ALL
M02188	9	RF14934 FSEU LC FILTER (SB 27-0131)	284T0009 13619	1	27-51-61 0355/155/R013	ALL
M02189	9	RF14934 FSEU LC FILTER (SB 27-0131)	284T0009 13619	1	27-51-61 0355/155/R013	ALL

EQUIPMENT LIST

D280T132

Section M02100

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M03107		PWSUPPLIED TCC AIR VALVE ACTUATOR	VENDORS 81205	2	71-51-14 ENG/ /	ALL
M03108	9	53T335 FUEL METERING UNIT(PW4000) (SB 76-0024)	VENDORS 77445	1	76-11-11 ENG/ /	050, 150-154
M03108		53T335 FUEL METERING UNIT (PW4000)	VENDORS 77445	1	76-11-11 ENG/ /	051-099, 155-199, 277-299
M03108		53T510 FUEL METERING UNIT (PW4000)	VENDORS 77445	1	76-11-11 ENG/ /	275-276

EQUIPMENT LIST

D280T132

Section M03100
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M06848		PWSUPPLIED SCU	VENDORS	1	73-21-11 ENG/ /	050-099, 162-199, 277-299

EQUIPMENT LIST

D280T132

Section M06800

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M07191	9	S210T125-26 CONTROLLER-HIGH PRESS. (SB 36-0053)	332T3400 81205	2	36-11-61 N143/130/0000	ALL
M07191		S210T120-22 CONTROLLER-HIGH PRESS.	332T3400 81205	2	36-11-61 NL148/082/L017	050-099, 162-165
M07191		S210T120-32 CONTROLLER-HIGH PRESS.	332T3400 81205	2	36-11-61 NL148/082/L017	156-157, 166-199, 277-299
M07192		S347T001-12 XMTR-FUEL FLOW,ENGS	284T0000 81205	2	73-31-11 ENG/ /	ALL
M07193		S332T305-8 XMTR-FUEL PRESSURE,ENGS	332T1206 14140	2	73-33-11 NR160/73/15	050-099, 150-199
M07196		50T241 EXCITER-ENG IGN 1	VENDORS 59501	2	74-31-11 ENG/ /	ALL
M07197		50T241 EXCITER-ENG IGN 2	VENDORS 59501	2	74-31-11 ENG/ /	ALL
M07198		GESUPPLIED EEC-ENG (SUPERVISORY)	284T0000 07482	2	73-21-11 ENG/ /	050-099
M07198		PWSUPPLIED EEC-ENG	284T0000 07482	2	73-21-11 ENG/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section M07100
Page 1 End
Feb 06/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M07200	9	S210T120-182 CONTROLLER-PRESS REG (SB 36-0029)	332T4340 73030	2	36-11-61 0209/112/0000	050-099, 150-155, 162-165
M07200		S210T120-182 CONTROLLER-PRESSURE REGULATING	332T4340 73030	2	36-11-61 0209/112/0000	156-157, 166-199, 277-299
M07200	1	S210T120-182 CONTROLLER-PRESSURE REGULATING	332T4340 73030	2	36-11-61 0209/112/0000	050-099, 150-155, 162-165
M07200	2	S210T120-162 CONTROLLER-PRESSURE REGULATING	332T4340 73030	2	36-11-61 0209/112/0000	050-099, 150-155, 162-165
M07200	3	S210T120-142 CONTROLLER-PRESSURE REGULATING	332T4340 73030	2	36-11-61 0209/112/0000	050-099, 150-155, 162-165
M07200	3	S210T120-182 CONTROLLER-PRESSURE REGULATING	332T4340 73030	2	36-11-61 0209/112/0000	275-276
M07202	1	S315T367-4 ACTR-FUEL CONDITIONING CONT,ENG	VENDORS 81205	2	76-11-11 ENG/ /	050, 150-154, 275- 276
M07202	2	S315T367-2 ACTR-FUEL CONDITIONING CONT,ENG	VENDORS 81205	2	76-11-11 ENG/ /	050, 150-154, 275- 276

EQUIPMENT LIST

D280T132

Section M07200

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M09001	9	CUSTOMER MASTER CONTROL UNIT (EAD89-0704-00)	CUSTOMER CUST	1	25-25-24 0270/ /	150, 153, 157, 165-199
M09001	9	700-2004-001 8.6 INCH LCD VIDEO MONITOR (MTO 230524)	CUSTOMER 3Y989	1	23-32-13 0458/235/L069	154-156
M09001T	9	1068808-1 TERM PLUG (EAD89-0704-00)	CUSTOMER CUST	1	25-25-24 0270/ /	150, 153, 157, 165-199
M09002	9	1067806-1-25 POWER SELECT MODULE (EAD89-0704-00)	CUSTOMER CUST	1	25-25-24 0270/ /	150, 153, 157, 165-199
M09002	9	700-2004-001 8.6 INCH LCD VIDEO MONITOR (MTO 230524)	CUSTOMER 3Y989	1	23-32-13 0458/235/R069	154-156
M09003	9	1068820-2 SEAT J BOX (EAD89-0704-00)	CUSTOMER CUST	29	25-25-24 MULTI/ /	150, 153, 157, 165-199
M09003	9	700-2004-001 8.6 INCH LCD VIDEO MONITOR (MTO 230524)	CUSTOMER 3Y989	1	23-32-13 LAV C/AFT/WALL	162-164
M09004	9	CUSTOMER TERM PLUG (EAD89-0704-00)	CUSTOMER CUST	3	25-25-24 MULTI/ /	150, 153, 157, 165-199
M09004	9	700-2004-001 8.6 INCH LCD VIDEO MONITOR (MTO 230524)	CUSTOMER 3Y989	1	23-32-13 LAV D/AFT/WALL	162-164
M09005	9	1068-2 IN-SEAT POWER SUPPLY (EAD89-0704-00)	CUSTOMER CUST	1	25-25-24 MULTI/ /	150, 153, 157, 165-199
M09005	9	700-1590-001 14 INCH CRT VIDEO MONITOR (MTO 230524)	CUSTOMER 3Y989	1	23-32-13 0535/280/0	162-164
M09006	9	1075-2-8 TERM PLUG (EAD89-0704-00)	CUSTOMER CUST	58	25-25-24 MULTI/ /	150, 153, 157, 165-199
M09006	9	700-1117-009 MK VI VIDEO PROJECTOR (MTO 230524)	CUSTOMER 3Y989	1	23-32-13 0723/280/0	154-156
M09007	9	1075-2-8 OUTLET UNIT(EAD89-0704-00)	CUSTOMER CUST	1	25-25-24 MULTI/ /	150, 153, 157, 165-199
M09007	9	913004 AIRSHOW CONTROL UNIT (MTO 230524)	CUSTOMER 70093	1	23-32-13 PURSER/STATION	154-156, 162-164
M09008	9	CUSTOMER PROJECTOR-FWD VIDEO (MTO 230540)	CUSTOMER CUST	1	23-32-01 GALLEY 3/ /	050-099
M09009	9	CUSTOMER PROJECTOR-MID VIDEO (MTO 230540)	CUSTOMER CUST	1	23-32-01 GALLEY 3/ /	050-099

EQUIPMENT LIST

D280T132

Section M09000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M09010	9	CUSTOMER TRU (MTO 240500)	CUSTOMER CUST	1	25-25-23 E002-06/ /	150, 153, 157, 165-199
M09011	9	CUSTOMER SEAT POWER BOX (MTO 240500)	CUSTOMER CUST	12	25-25-23 MULTI/ /	150, 153, 157, 165-199
M09012	9	CUSTOMER GALLEY POWER BOX (MTO 240500)	CUSTOMER CUST	1	25-25-23 / /	150, 153, 157, 165-199
M09020	9	CUSTOMER CABIN TELECOMMUNICATIONS UNIT(MTO-230695)	CUSTOMER CUST	1	23-19-11 412SHELF/E09/90	150
M09020	9	CUSTOMER CABIN TELECOMMUNICATIONS UNIT(MTO-230596)	CUSTOMER CUST	1	23-19-11 412SHELF/E09/90	152-199
M09021	9	CUSTOMER PDU RWD CARGO-CLAIRCOM RACK (MTO-230695)	CUSTOMER CUST	1	23-19-11 0420/170/R064	150
M09021	9	CUSTOMER PDU RWD CARGO-CLAIRCOM RACK (MTO-230596)	CUSTOMER CUST	1	23-19-11 0420/170/R064	152-199
M09022	9	CUSTOMER ZONE TELEPHONE BOX-B (MTO-230695)	CUSTOMER CUST	1	23-19-12 654+30/304/R051	150
M09022	9	CUSTOMER ZONE TELEPHONE BOX-B (MTO-230596)	CUSTOMER CUST	1	23-19-12 654+30/304/R051	152-199
M09023	9	CUSTOMER ZONE TELEPHONE BOX-C (MTO-230695)	CUSTOMER CUST	1	23-19-12 0687/304/R051	150
M09023	9	CUSTOMER ZONE TELEPHONE BOX-C (MTO-230596)	CUSTOMER CUST	1	23-19-12 0687/304/R051	152-199
M09024	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230695)	CUSTOMER CUST	0	23-19-12 0284/286/L072	150
M09024	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230596)	CUSTOMER CUST	0	23-19-12 0284/286/L072	152-199
M09025	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230695)	CUSTOMER CUST	0	23-19-12 0654+119/295/R015	150
M09025	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230596)	CUSTOMER CUST	0	23-19-12 0654+119/295/R015	152-199
M09026	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230695)	CUSTOMER CUST	0	23-19-12 0917/295/R015	150
M09026	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230596)	CUSTOMER CUST	0	23-19-12 0917/295/R015	152-199

EQUIPMENT LIST

D280T132

Section M09000

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M09027	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230695)	CUSTOMER CUST	0	23-19-12 1523/279/R005	150
M09027	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230596)	CUSTOMER CUST	0	23-19-12 1523/279/R005	152-199
M09030	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230695)	CUSTOMER CUST	0	23-19-12 MULTI/ /	150
M09030	9	CUSTOMER SEAT TELEPHONE BOX (MTO-230596)	CUSTOMER CUST	0	23-19-12 MULTI/ /	152-199
M09038	9	CUSTOMER SEAT TELEPHONE BOX TERM PLUG(MTO-230695)	CUSTOMER CUST	1	23-19-12 MULTI/ /	150
M09038	9	CUSTOMER SEAT TELEPHONE BOX TERM PLUG(MTO-230596)	CUSTOMER CUST	1	23-19-12 MULTI/ /	152-199
M09041	9	CUSTOMER HANDSET (MTO-230695)	CUSTOMER CUST	1	23-19-12 0284/273/L054	150
M09041	9	CUSTOMER HANDSET (MTO-230596)	CUSTOMER CUST	1	23-19-12 0284/273/L054	152-199
M09042	9	CUSTOMER HANDSET (MTO-230695)	CUSTOMER CUST	1	23-19-12 654+119/272/R020	150
M09042	9	CUSTOMER HANDSET (MTO-230596)	CUSTOMER CUST	1	23-19-12 654+119/272/R020	152-199
M09043	9	CUSTOMER HANDSET (MTO-230695)	CUSTOMER CUST	1	23-19-12 0917/272/L020	150
M09043	9	CUSTOMER HANDSET (MTO-230596)	CUSTOMER CUST	1	23-19-12 0917/272/L020	152-199
M09044	9	CUSTOMER HANDSET (MTO-230695)	CUSTOMER CUST	1	23-19-12 0917/272/R020	150
M09044	9	CUSTOMER HANDSET (MTO-230596)	CUSTOMER CUST	1	23-19-12 0917/272/R020	152-199
M09045	9	CUSTOMER HANDSET (MTO-230695)	CUSTOMER CUST	1	23-19-12 1510/272/L020	150
M09045	9	CUSTOMER HANDSET (MTO-230596)	CUSTOMER CUST	1	23-19-12 1510/272/L020	152-199
M09046	9	CUSTOMER HANDSET (MTO-230695)	CUSTOMER CUST	1	23-19-12 1510/272/R020	150

EQUIPMENT LIST

D280T132

Section M09000

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M09046	9	CUSTOMER HANDSET (MTO-230596)	CUSTOMER CUST	1	23-19-12 1510/272/R020	152-199
M09047	9	CUSTOMER HANDSET (MTO-230695)	CUSTOMER CUST	1	23-19-12 MULTI/ /	150
M09047	9	CUSTOMER HANDSET (MTO-230596)	CUSTOMER CUST	1	23-19-12 MULTI/ /	152-199
M09048	9	SAS ACARS VOICE/DATA PANEL (MTO-230607)	CUSTOMER	0	23-22-11 P008-00/ /	150, 152-166
M09050	9	915030-00 RADVR (MTO 230718)	CUSTOMER ASINC	1	23-32-21 VCC/ /2	150, 152-157, 164-199
M09053	9	24013-001 PNL-CAPT EGPWS SW (MTO-340961)	CUSTOMER CUST	1	34-46-11 0155/227/L030	150, 152-199, 275-299
M09054	9	24014-001 PNL-F/O EGPWS (MTO-340961)	CUSTOMER CUST	1	34-46-11 0155/227/R015	150, 152-199, 275-299

EQUIPMENT LIST

D280T132

Section M09000

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10023		233N3201-11 CONT PNL-WSHLD WIPER/RAIN REPEL.(SEE YDH	233T3100 81205	1	30-42-11 P005-00/ /	ALL
M10023 T		S233T100-1074 LTPLT CONT-PNL,WSHLD WIPER/RAIN RPLNT	233N3201 81205	1	33-13-16 P005-00/ /	ALL
M10054	9	S345N011-8 PNL-FUEL QTY (SB 31-0208)	233T3100 81205	1	28-41-11 P005-00/ /	153
M10054		S345N011-7 PNL-FUEL QTY	233T3100 81205	1	28-41-11 P005-00/ /	050-099, 150-164, 275-299
M10054		S345N001-001 PNL-FUEL QTY	233T3100 81205	1	28-41-11 P005-00/ /	165-199
M10055	9	233T3235-21 PNL-FUEL MANAGEMENT(SEE YCL)(SB 28-0034)	233T3100 81205	1	28-22-11 P005-00/ /	ALL
M10055	1	233T3235-15 PNL-FUEL MANAGEMENT (SEE YCL)	233T3100 81205	1	28-22-11 P005-00/ /	ALL
M10055	2	233T3235-12 PNL-FUEL MANAGEMENT (SEE YCL)	233T3100 81205	1	28-22-11 P005-00/ /	ALL
M10055	3	233T3235-10 PNL-FUEL MANAGEMENT (SEE YCL)	233T3100 81205	1	28-22-11 P005-00/ /	ALL
M10055 T		S233T100-1060 LIGHTPLATE-PNL FUEL MANAGEMENT	233T3235 81205	1	33-13-16 P005-00/ /	ALL
M10056		233N3214-28 PNL-LIGHTING CONTROL,LEFT (SEE YCW)	233T3103 81205	1	33-42-21 P005-00/ /	050-099, 153-199, 275-299
M10056		233N3214-26 PNL-LIGHTING CONTROL,LEFT (SEE YCW)	233T3103 81205	1	33-42-21 P005-00/ /	150-152
M10056 T		S233T100-6010 LIGHTPLATE-PNL,LIGHTING CONT,LEFT	233N3214 81205	1	33-13-16 P005-00/ /	ALL
M10057	9	233N3221-324 PNL-LTG CONT,R OVHD(SEE YCX)(SB 25-0325)	823T2518 81205	1	33-13-16 P005-00/ /	050-099, 155, 162- 165, 276
M10057	9	233N3221-321 PNL-LTG CONT,R OVHD(SEE YCX)(SB 25-0332)	823T2518 81205	1	33-13-16 P005-00/ /	150-152
M10057	9	233N3221-324 PNL-LTG CONT,R OVHD(SEE YCX)(SB 25-0332)	823T2518 81205	1	33-13-16 P005-00/ /	153-154, 275
M10057	9	233N3221-316 PNL-LTG CONT,R OVHD(SEE YCX)(SB 25-0325)	823T2518 81205	1	33-13-16 P005-00/ /	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section M10000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10057		233N3221 PNL ASSY-LIGHTING CONT,R OVHD (SEE YCX)	233T3100 81205	1	33-13-16 P005-00/ /	ALL
M10057 T	9	S233T100-6069 LIGHTPLATE-PNL LTG CONT,R (SB 25-0325)	823T2518 81205	1	33-13-16 P005-00/ /	050-099, 155-199, 276-299
M10057 T	9	S233T100-6069 LIGHTPLATE-PNL LTG CONT,R (SB 25-0332)	823T2518 81205	1	33-13-16 P005-00/ /	150-154, 275
M10057 T		S233T100-6039 LIGHTPLATE-PNL ASSY LIGHTING CONT,RIGHT	233N3221 81205	1	33-13-16 P005-00/ /	ALL
M10062		233N3211-41 PNL ASSY-STANDBY POWER (SEE YDI)	233T3100 81205	1	24-33-11 P005-00/ /	ALL
M10062 T		S233T100-1072 LIGHTPLATE-PNL ASSY STANDBY POWER	233N3221 81205	1	33-13-16 P005-00/ /	ALL
M10063	5	233N3209-25 PANEL ASSY-ELEC SYS (SEE YDJ)	233T3100 81205	1	24-22-11 P005-00/ /	050-099, 150-199, 275-276
M10063	1	233N3209-28 PANEL ASSY-ELEC SYS (SEE YDJ)	233T3100 81205	1	24-22-11 P005-00/ /	ALL
M10063	2	233N3209-23 PANEL ASSY-ELEC SYS (SEE YDJ)	233T3100 81205	1	24-22-11 P005-00/ /	ALL
M10063	3	233N3209-19 PANEL ASSY-ELEC SYS (SEE YDJ)	233T3100 81205	1	24-22-11 P005-00/ /	ALL
M10063	4	233N3209-14 PANEL ASSY-ELEC SYS (SEE YDJ)	233T3100 81205	1	24-22-11 P005-00/ /	ALL
M10063 T		S233T100-6004 LIGHTPLATE-PNL ASSY,ELEC SYS	233N3209 81205	1	33-13-16 P005-00/ /	ALL
M10078		S231N211-3 MODULE-COMPT TEMP	233T3100 81205	1	21-65-11 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M10000

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10181	9	S242N701-1001 COMPUTER-EICAS,L (SB 31-0100)	284T0970 81205	1	31-41-11 SHELF/E08/01	150, 152-157
M10181	9	S242N701-603 COMPUTER-EICAS,L (SB 31-0033)	284T0970 81205	1	31-41-11 SHELF/E08/01	151, 275-276
M10181		S242N701-603 COMPUTER-EICAS,L	284T0970 81205	1	31-41-11 SHELF/E08/01	050-099, 155-199, 277-299
M10182	9	S242N701-603 COMPUTER-EICAS,R (SB 31-0033)	284T0970 81205	1	31-41-11 SHELF/E08/02	150, 152-154, 275- 276
M10182	9	S242N701-1001 COMPUTER-EICAS,R (SB 31-0100)	284T0970 81205	1	31-41-11 SHELF/E08/02	151
M10182		S242N701-603 COMPUTER-EICAS,R	284T0970 81205	1	31-41-11 SHELF/E08/02	050-099, 155-199, 277-299
M10195		S242N701-206 PNL-EICAS DISPLAY SELECT	233T6100 81205	1	31-41-11 P009-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M10100
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10212	1	S282N001-4 MONITOR-BATTERY CURRENT	284T0713 81205	1	24-31-11 298/121/0	ALL
M10212	2	S282N001-3 MONITOR-BATTERY CURRENT	284T0713 81205	1	24-31-11 298/121/0	ALL
M10212	3	S282N001-2 MONITOR-BATTERY CURRENT	284T0713 81205	1	24-31-11 298/121/0	ALL
M10213		S282N002-2 CONTROL UNIT-DC TIE	284T0997 81205	1	24-32-11 P006-01/ /	ALL
M10224	5	285N0028-16 PC ASSY 1-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-11 P054-00/ /	050-099, 150-199, 275-276
M10224		285N0028-21 PC ASSY 1-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-11 P054-00/ /	277-299
M10224	1	285N0028-21 PC ASSY 1-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-11 P054-00/ /	050-099, 150-199, 275-276
M10224	2	285N0028-20 PC ASSY 1-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-11 P054-00/ /	050-099, 150-199, 275-276
M10224	3	285N0028-10 PC ASSY 1-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-11 P054-00/ /	050-099, 150-199, 275-276
M10224	4	285N0028-17 PC ASSY 1-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-11 P054-00/ /	050-099, 150-199, 275-276
M10250	1	233N3216-20 PNL-YAW DAMPER (SEE YAL)	233T3100 81205	1	22-21-11 P005-00/ /	ALL
M10250	2	233N3216-22 PNL-YAW DAMPER (SEE YAL)	233T3100 81205	1	22-21-11 P005-00/ /	ALL
M10250	3	233N3216-18 PNL-YAW DAMPER (SEE YAL)	233T3100 81205	1	22-21-11 P005-00/ /	ALL
M10250	4	233N3216-14 PNL-YAW DAMPER (SEE YAL)	233T3100 81205	1	22-21-11 P005-00/ /	ALL
M10250 T		S233T100-1075 LIGHTPLATE-PNL,YAW DAMPER	233N3216 81205	1	33-13-16 P005-00/ /	ALL
M10258		S241T200-154 PNL-THRUST MODE SELECT	233T2100 81205	1	22-31-12 P003-01/ /	ALL
M10274	5	285N0028-16 PC ASSY 2-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-21 P054-00/ /	050-099, 150-199, 275-276

EQUIPMENT LIST

D280T132

Section M10200

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10274		285N0028-21 PC ASSY 2-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-21 P054-00/ /	277-299
M10274	1	285N0028-21 PC ASSY 2-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-21 P054-00/ /	050-099, 150-199, 275-276
M10274	2	285N0028-20 PC ASSY 2-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-21 P054-00/ /	050-099, 150-199, 275-276
M10274	3	285N0028-10 PC ASSY 2-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-21 P054-00/ /	050-099, 150-199, 275-276
M10274	4	285N0028-17 PC ASSY 2-FIRE/OVHT,LOGIC TEST	284T0049 81205	1	26-11-21 P054-00/ /	050-099, 150-199, 275-276

EQUIPMENT LIST

D280T132

Section M10200
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10334	1	10167-2001-BT MODULE-L START FAIL DELAY	284T0997 08719	1	80-11-11 P006-05/ /	ALL
M10334	2	10167-2-BT MODULE-L START FAIL DELAY	284T0997 08719	1	80-11-11 P006-05/ /	ALL
M10335	1	10167-2001-BT MODULE-R START FAIL DELAY	284T0997 08719	1	80-11-21 P006-05/ /	ALL
M10335	2	10167-2-BT MODULE-R START FAIL DELAY	284T0997 08719	1	80-11-21 P006-05/ /	ALL
M10372		233N7509-6 PNL-EICAS MAINT	233T4100 81205	1	31-41-13 P061-00/ /	ALL
M10389		S210T130-28 CONTROLLER-PACK STANDBY	284T0130 81205	1	21-51-13 SHELF/E03/02	ALL
M10394		233T3233-19 PANEL-ANNUNCIATOR (SEE YDL)	286T0618 81205	1	30-31-11 P005-00/ /	050-099, 150-155, 162-165, 275-276
M10394		233T3233-35 PANEL-ANNUNCIATOR (SEE YDL)	286T0618 CUST	1	30-31-11 P005-00/ /	156-157, 166-199, 277-299
M10395		233N3212-8 PNL-WINDOW HEAT CONTROL (SEE YDM)	286T0618 81205	1	30-41-11 P005-00/ /	050-099
M10395		233N3212-14 PNL-WINDOW HEAT CONTROL (SEE YDM)	286T0618 81205	1	30-41-11 P005-00/ /	150-199, 275-299
M10395 T		S233T100-1073 LIGHTPLATE-PNL,WINDOW HEAT CONT	233N3212 81205	1	33-13-16 P005-00/ /	ALL
M10397		233T3241-64 CONT PNL-WING AND ENG ANTI-ICE (SEE YDN)	233T3100 81205	1	30-11-11 P005-00/ /	050-099, 155-199
M10397		233T3241-56 CONT PNL-WING AND ENG ANTI-ICE (SEE YDN)	233T3100 81205	1	30-11-11 P005-00/ /	150-154, 275-299
M10397 T		S233T100-1070 LTPLT-CONT PNL,WING AND ENG ANTI-ICE	233T3241 81205	1	33-13-16 P005-00/ /	ALL
M10398		233T4239-26 PNL-TEST (SEE YEI)	233T4100 81205	1	28-43-11 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M10300

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10400	5	285N0028-16 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284T0049 81205	1	26-15-11 P054-00/ /	050-099, 150-199, 275-276
M10400		285N0028-21 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284T0049 81205	1	26-15-11 P054-00/ /	277-299
M10400	1	285N0028-21 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284T0049 81205	1	26-15-11 P054-00/ /	050-099, 150-199, 275-276
M10400	2	285N0028-20 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284T0049 81205	1	26-15-11 P054-00/ /	050-099, 150-199, 275-276
M10400	3	285N0028-10 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284T0049 81205	1	26-15-11 P054-00/ /	050-099, 150-199, 275-276
M10400	4	285N0028-17 PC ASSY 3-FIRE/OVHT,LOGIC/TEST	284T0049 81205	1	26-15-11 P054-00/ /	050-099, 150-199, 275-276
M10403		285T0094-6 PC ASSY-PACK BACKUP TEMP CONT,L	284T0049 81205	1	21-53-12 P050-00/ /	277-299
M10403	1	285T0094-6 PC ASSY-PACK BACKUP TEMP CONT,L	284T0049 81205	1	21-53-12 P050-00/ /	050-099, 150-199, 275-276
M10403	2	285T0094-3 PC ASSY-PACK BACKUP TEMP CONT,L	284T0049 81205	1	21-53-12 P050-00/ /	050-099, 150-199, 275-276
M10404		285T0094-6 PC ASSY-PACK BACKUP TEMP CONT,R	284T0049 81205	0	21-53-22 P050-00/ /	277-299
M10404	1	285T0094-6 PC ASSY-PACK BACKUP TEMP CONT,R	284T0049 81205	0	21-53-22 P050-00/ /	050-099, 150-199, 275-276
M10404	2	285T0094-3 PC ASSY-PACK BACKUP TEMP CONT,R	284T0049 81205	1	21-53-22 P050-00/ /	050-099, 150-199, 275-276
M10417		285T0496-1 MODULE-E1CAS UPPER DISPLAY SWITCHING	284T0970 81205	1	31-41-21 SHELF/E08/00	ALL
M10418		285T0496-1 MODULE-E1CAS LOWER DISPLAY SWITCHING	284T0970 81205	1	31-41-22 SHELF/E08/00	ALL
M10427	5	285N0028-16 CARD 6-FIRE OVHT,LOGIC/TEST	284T0049 81205	1	26-16-11 P054-00/ /	050-099, 150-199, 275-276
M10427		285N0028-21 CARD 6-FIRE OVHT,LOGIC/TEST	284T0049 81205	1	26-16-11 P054-00/ /	277-299
M10427	1	285N0028-21 CARD 6-FIRE OVHT,LOGIC/TEST	284T0049 81205	1	26-16-11 P054-00/ /	050-099, 150-199, 275-276

EQUIPMENT LIST

D280T132

Section M10400

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10427	2	285N0028-20 CARD 6-FIRE OVHT,LOGIC/TEST	284T0049 81205	1	26-16-11 P054-00/ /	050-099, 150-199, 275-276
M10427	3	285N0028-10 CARD 6-FIRE OVHT,LOGIC/TEST	284T0049 81205	1	26-16-11 P054-00/ /	050-099, 150-199, 275-276
M10427	4	285N0028-17 CARD 6-FIRE OVHT,LOGIC/TEST	284T0049 81205	1	26-16-11 P054-00/ /	050-099, 150-199, 275-276
M10439	9	TD-1982-7501 MDL-R T/R ISLN VLV DLY (SB 78-0062)	284T0189 08719	1	78-36-21 P033-00/ /	ALL
M10439	1	10167-2001-BT MODULE-R T/R ISLN VALVE DELAY	284T0189 08719	1	78-36-21 P033-00/ /	157, 167-199, 277- 299
M10439	2	10167-2-BT MODULE-R T/R ISLN VALVE DELAY	284T0189 08719	1	78-36-21 P033-00/ /	157, 167-199, 277- 299
M10439	3	TD-1767-2001 MODULE-R T/R ISLN VALVE DELAY	284T0189 08719	1	78-36-21 P033-00/ /	157, 167-199, 277- 299
M10440	9	TD-1982-7501 MDL-L T/R ISLN VLV DLY (SB 78-0062)	284T0187 08719	1	78-36-11 P036-00/ /	ALL
M10440	1	10167-2001-BT MODULE-L T/R ISLN VALVE DELAY	284T0187 08719	1	78-36-11 P036-00/ /	157, 167-199, 277- 299
M10440	2	10167-2-BT MODULE-L T/R ISLN VALVE DELAY	284T0187 08719	1	78-36-11 P036-00/ /	157, 167-199, 277- 299
M10440	3	TD-1767-2001 MODULE-L T/R ISLN VALVE DELAY	284T0187 08719	1	78-36-11 P036-00/ /	157, 167-199, 277- 299
M10443	9	233N6205-12 CTRL PNL-ENG FIRE (SEE YEG) (SB 26-0064)	233T6100 81205	1	26-11-11 P008-00/ /	050-099, 150-155, 162-165, 275-276
M10443		233N6205-12 CONTROL PNL-ENG FIRE (SEE YEG)	233T6100 81205	1	26-11-11 P008-00/ /	156-157, 166-199, 277-299
M10444		233N6203-138 PNL-APU/CARGO FIRE CONTROL (SEE YDO)	233T6100 81205	1	26-23-11 P008-00/ /	050-099, 153-154
M10444		233N6203-85 PNL-APU/CARGO FIRE CONTROL (SEE YDO)	233T6100 81205	1	26-23-11 P008-00/ /	150-152
M10444		233N6203-146 PNL-APU/CARGO FIRE CONTROL (SEE YDO)	233T6100 81205	1	26-23-11 P008-00/ /	155-199
M10444		233N6203-157 PNL-APU/CARGO FIRE CONTROL (SEE YDO)	233T6100 81205	1	26-23-11 P008-00/ /	275-299

EQUIPMENT LIST

D280T132

Section M10400

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10444	T	S233T100-5501 LIGHTPLATE-PNL,APU/CARGO FIRE CONTROL	233T4241 81205	1	33-13-18 P008-00/ /	ALL
M10445		233T6204-12 PNL-FIRE/OVHT TEST (SEE YEH)	233T6100 81205	1	26-11-11 P008-00/ /	050-099, 150-199
M10445		233T6204-301 PNL-FIRE/OVHT TEST (SEE YEH)	233T6100 81205	1	26-11-11 P008-00/ /	275-299
M10445	T	S233T100-538 LIGHTPLATE-PNL,FIRE/OVHT TEST	233T6204 81205	1	33-13-16 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M10400
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M10727		285N0432-8 CARD-EICAS SIGN CONSOLIDATION	284T0049 81205	1	31-41-35 P051-00/ /	050-099, 162-199, 280-299
M10727	1	285N0432-8 CARD-EICAS SIGN CONSOLIDATION	284T0049 81205	1	31-41-35 P051-00/ /	150-157, 275-278
M10727	2	285N0432-1 CARD-EICAS SIGN CONSOLIDATION	284T0049 81205	1	31-41-35 P051-00/ /	150-157, 275-278
M10761		233T3242-304 CONT PNL-EEC (SEE YHW)	233T3100 81205	1	73-21-11 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section M10700

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M11248	9	S67-1575-133 GPS ANTENNA-RIGHT (MTO-340961)	CUSTOMER CUST	1	34-58-22 0600/319/0000	150, 152-199, 275- 299

EQUIPMENT LIST

D280T132

Section M11200
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
M12093	9	285T0855-5 CHIME MODULE (SB 25-0325)	848T1002 81205	1	52-51-11 0238/273/L015	050-099, 155-199, 276-299
M12093	9	285T0855-5 CHIME MODULE (SB 25-0332)	848T1002 81205	1	52-51-11 0238/273/L015	150-154, 275
M12094	9	285T0852-1 KEYPAD (SB 25-0325)	848T1002 81205	1	52-51-11 0242/258/L018	050-099, 155-199, 276-299
M12094	9	285T0852-1 KEYPAD (SB 25-0332)	848T1002 81205	1	52-51-11 0242/258/L039	150-154, 275
M12095	9	AR4701-1 STRIKE ASSY. (SB 25-0325)	841T3001 81205	1	52-51-11 0240/242/L017	050-099, 155-199, 276-299
M12095	9	AR4701-3 STRIKE ASSY. (SB 25-0332)	841T3001 81205	1	52-51-11 0240/242/L017	150-154, 275
M12096	9	44N00004-3 PRESSURE SENSOR (SB 25-0325)	848T1003 81205	1	52-51-11 0224/275/R025	050-099, 155-199, 276-299
M12096	9	44N00004-3 PRESSURE SENSOR (SB 25-0332)	848T1003 81205	1	52-51-11 0224/275/R025	150-154, 275

EQUIPMENT LIST

D280T132

Section M12000

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00002		S231T120-1 CLOCK-CAPTAIN	233T2100 81205	1	31-25-11 P001-03/ /	ALL
N00003		S242T403-109 IND-RADIO DISTANCE MAGNETIC,LEFT	233T2100 81205	1	34-22-81 P001-01/ /	ALL
N00004		S242T404-511 IND-ELEX ATTD DIR,LEFT	233T2100 81205	1	34-22-14 P001-02/ /	050-099, 162-199, 275-299
N00004	1	S242T404-511 IND-ELEX ATTD DIR,LEFT	233T2100 81205	1	34-22-14 P001-02/ /	150-157
N00004	2	S242T404-510 IND-ELEX ATTD DIR,LEFT	233T2100 81205	1	34-22-14 P001-02/ /	150-157
N00005		S242T404-611 IND-ELEX HORIZ SITUATION,LEFT	233T2100 81205	1	34-22-15 P001-02/ /	050-099, 162-199, 275-299
N00005	1	S242T404-611 IND-ELEX HORIZ SITUATION,LEFT	233T2100 81205	1	34-22-15 P001-02/ /	150-157
N00005	2	S242T404-610 IND-ELEX HORIZ SITUATION,LEFT	233T2100 81205	1	34-22-15 P001-02/ /	150-157
N00008		S231T101-4 ALTIMETER-CAPT	233T2100 81205	1	34-13-11 P001-03/ /	050-099, 150-199
N00008		S231T101-1 ALTIMETER-CAPT	233T2100 81205	1	34-13-11 P001-03/ /	275-299
N00009	9	4067241-862 IND-VERTICAL SPEED,LEFT (MTO 340652)	233T2100 81205	1	34-22-82 P001-03/ /	050-099, 150-152, 155-199, 275-299
N00009	9	4067241-865 IND-VERTICAL SPEED,LEFT (MTO 340652)	233T2100 58960	1	34-22-82 P001-03/ /	153-154
N00009		S231T102-1 IND-VERTICAL SPEED,LEFT	233T2100 81205	1	34-22-82 P001-03/ /	153-154
N00010		S231T231-8 IND-BRAKE PRESSURE	233T2100 81205	1	32-41-11 P003-01/ /	ALL
N00015		S231T280-3 IND-FLAPS POSITION	233T2100 81205	1	27-58-11 P003-01/ /	150-199, 275-299
N00015	1	S231T280-2 IND-FLAPS POSITION	233T2100 81205	1	27-58-11 P003-01/ /	050-099
N00015	2	S231T280-1 IND-FLAPS POSITION	233T2100 81205	1	27-58-11 P003-01/ /	050-099

EQUIPMENT LIST

D280T132

Section N00000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00020	9	H150AKM1-SK IND-ATTITUDE/ILS,STANDBY (MTO 340798)	233T2100 81205	1	34-24-11 P001-03/ /	150-199, 275-299
N00020		S231T110-6 IND-ATTITUDE/ILS,STANDBY	233T2100 81205	1	34-24-11 P001-03/ /	050-099
N00022		S231T112-1 IND-AIRSPEED,STANDBY	233T2100 81205	1	34-13-11 P001-03/ /	ALL
N00023		S231T113-2 ALTIMETER-STANDBY	233T2100 81205	1	34-13-11 P001-03/ /	ALL
N00029		S271T455-17 IND-REMOTE HYD QTY	271T4650 81205	1	29-33-11 1127/121/R056	ALL
N00042		S231T120-1 CLOCK-FIRST OFFICER	233T2100 81205	1	31-25-11 P003-03/ /	ALL
N00043		S242T403-109 IND-RADIO DISTANCE MAGNETIC,RIGHT	233T2100 81205	1	34-22-91 P003-01/ /	ALL
N00044		S242T404-511 IND-ELEX ATTD DIR,RIGHT	233T2100 81205	1	34-22-24 P003-02/ /	050-099, 162-199, 275-299
N00044	1	S242T404-511 IND-ELEX ATTD DIR,RIGHT	233T2100 81205	1	34-22-24 P003-02/ /	150-157
N00044	2	S242T404-510 IND-ELEX ATTD DIR,RIGHT	233T2100 81205	1	34-22-24 P003-02/ /	150-157
N00045		S242T404-611 IND-ELEX HORIZ SITUATION,RIGHT	233T2100 81205	1	34-22-25 P003-02/ /	050-099, 162-199, 275-299
N00045	1	S242T404-611 IND-ELEX HORIZ SITUATION,RIGHT	233T2100 81205	1	34-22-25 P003-02/ /	150-157
N00045	2	S242T404-610 IND-ELEX HORIZ SITUATION,RIGHT	233T2100 81205	1	34-22-25 P003-02/ /	150-157
N00048		S231T101-4 ALTIMETER-F/O	233T2100 81205	1	34-13-21 P003-03/ /	050-099, 150-199
N00048		S231T101-1 ALTIMETER-F/O	233T2100 81205	1	34-13-21 P003-03/ /	275-299
N00049	9	4067241-862 IND-VERTICAL SPEED,RIGHT (MTO 340652)	233T2100 81205	1	34-22-92 P003-03/ /	050-099, 150-152, 155-199, 275-299
N00049	9	4067241-865 IND-VERTICAL SPEED,RIGHT (MTO 340652)	233T2100 58960	1	34-22-92 P003-03/ /	153-154

EQUIPMENT LIST

D280T132

Section N00000

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00049		S231T102-1 IND-VERTICAL SPEED,RIGHT	233T2100 81205	1	34-22-92 P003-03/ /	153-154
N00068		S253T405-11 IND-STAB. POSITION,CAPT	253T5200 81205	1	27-48-11 P010-00/ /	ALL
N00069		S253T405-11 IND-STAB. POSITION,F/O	253T5200 81205	1	27-48-11 P010-00/ /	ALL
N00070		S241T120-1 ANN-AUTOLAND STATUS,CAPT	233T2100 81205	1	22-14-11 P001-03/ /	ALL
N00071		S241T120-1 ANN-AUTOLAND STATUS,F/O	233T2100 81205	1	22-14-21 P003-01/ /	ALL
N00072		S258T710-4 TACHOMETER-RAM AIR TURBINE	258T7200 81205	1	29-21-31 1045/130/R005	ALL
N00083		S231T282-2 IND-RUDDER TRIM	233T6100 81205	1	27-28-13 P008-00/ /	ALL
N00092		S345T002-53 IND-LOAD SELECT,L MAIN TANK	344T0020 81205	1	28-41-11 P028-00/ /	050-099, 150-164, 275-278
N00092		S345N001-010 IND-LOAD SELECT,L MAIN TANK	344T0020 81205	1	28-41-11 P028-00/ /	165-199
N00093		S345T002-53 IND-LOAD SELECT,R MAIN TANK	344T0020 81205	1	28-41-11 P028-00/ /	050-099, 150-164, 275-278
N00093		S345N001-010 IND-LOAD SELECT,R MAIN TANK	344T0020 81205	1	28-41-11 P028-00/ /	165-199
N00094		S345T002-53 IND-LOAD SELECT,AUX TANK	344T0020 81205	1	28-41-11 P028-00/ /	050-099, 150-164, 275-278
N00094		S345N001-010 IND-LOAD SELECT,AUX TANK	344T0020 81205	1	28-41-11 P028-00/ /	165-199
N00099		C5H COMPASS-MAGNETIC,PLT STBY	233T2100 61349	1	33-13-11 0167/257/0000	ALL

EQUIPMENT LIST

D280T132

Section N00000
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N00108		S417T600-4 INDICATOR-WATER QUANTITY	417T2020 81205	1	38-14-11 1373/116/0000	ALL
N00109		56517 IND-APU HOURMETER	233T7213 16476	1	49-72-11 P061-00/ /	ALL
N00114		315-1 TRIP REMINDER	233T2100 28277	1	33-13-13 P003-01/ /	050-099, 275-299
N00121		S345T002-123 IND-LOAD SELECT,AUX TANK	344T0020 81205	1	28-41-11 P041-00/ /	151
N00122		S231T245-3 IND-DUAL DUCT PRESSURE	233T4100 81205	1	36-21-11 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section N00100
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
N10013		S242T404-611 IND-EICAS UPPER DISPLAY	233T2100 81205	1	31-41-11 P002-00/ /	ALL
N10013	1	S242T404-611 IND-EICAS UPPER DISPLAY	233T2100 81205	1	31-41-11 P002-00/ /	150-199
N10013	2	S242T404-610 IND-EICAS UPPER DISPLAY	233T2100 81205	1	31-41-11 P002-00/ /	150-199
N10014		S242T404-611 IND-EICAS LOWER DISPLAY	233T2100 81205	1	31-41-11 P002-00/ /	050-099, 275-299
N10014	1	S242T404-611 IND-EICAS LOWER DISPLAY	233T2100 81205	1	31-41-11 P002-00/ /	150-199
N10014	2	S242T404-610 IND-EICAS LOWER DISPLAY	233T2100 81205	1	31-41-11 P002-00/ /	150-199
N10016		S231N001-6 IND-STANDBY ENGINE	233T2100 81205	1	73-21-14 P001-03/ /	050-099, 150-155, 162-165, 275-276
N10016		S231N001-15 IND-STANDBY ENGINE	233T2100 81205	1	73-21-14 P001-03/ /	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section N10000
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P001-01		233T2200 PNL-CAPT INSTR,L	233T2100 81205	1	91-02-31 0155/227/L030	ALL
P001-02		233T2100 PNL-CAPT INSTR,CTR	233T2100 81205	1	91-02-31 0155/227/L020	ALL
P001-03		233T2222 PNL-CAPT INSTR,R	233T2100 81205	1	91-02-31 0155/227/L015	ALL

EQUIPMENT LIST

D280T132



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P003-01		233T2223 PNL-F/O INSTR,L	235T2100 81205	1	91-02-32 0155/227/R015	ALL
P003-02		233T2100 PNL-F/O INSTR,CTR	233T2100 81205	1	91-02-32 0155/227/R020	ALL
P003-03		233T2204 PNL-F/O INSTR,R	230T0900 81205	1	91-02-32 0155/227/R030	ALL

EQUIPMENT LIST

D280T132

Section P003
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P005-00		233T3100 PNL-PLT OVHD	230T0900 81205	1	91-02-34 0200/280/0000	ALL

EQUIPMENT LIST

D280T132

Section P005
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P006-00		284T0997 PNL-MN PWR DISTR	284T0996 81205	1	91-00-00 0245/220/R030	ALL
P006-01		284T0997 PNL-DC BAT./STBY	284T0996 81205	1	91-02-04 0199/233/R043	ALL
P006-02		284T0997 PNL-DC BUS	284T0996 81205	1	91-02-04 0208/233/R043	ALL
P006-03		284T0997 PNL-AC BUS,LEFT	284T0996 81205	1	91-02-04 0216/233/R043	ALL
P006-04		284T0997 PNL-AC BUS,RIGHT	284T0996 81205	1	91-02-05 0224/233/R043	ALL
P006-05		284T0997 PNL-LIGHTING EQUIPMENT	284T0996 81205	1	91-02-05 0232/233/R043	ALL

EQUIPMENT LIST

D280T132

Section P006
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P007-00		233T2100 PNL-GLARESHIELD	230T0900 81205	1	91-00-00 0165/245/0000	ALL

EQUIPMENT LIST

D280T132

Section P007
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P008-00		233T6100 PNL-ELECTRONICS,AFT	230T0900 81205	1	91-02-35 0196/223/0000	ALL

EQUIPMENT LIST

D280T132

Section P008
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P009-00		233T6100 PNL-ELECTRONICS,FWD	230T0900 81205	1	91-02-36 0167/224/0000	ALL

EQUIPMENT LIST

D280T132

Section P009
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P010-00		253T5200 STAND-QUADRANT	253T5100 81205	1	91-02-37 0140/210/0000	ALL

EQUIPMENT LIST

D280T132

Section P010
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P011-00		233T5216 PNL ASSY-CIRCUIT BREAKER	233T5210 81205	1	91-00-00 0212/280/0000	ALL
P011-01		233T5216 PNL ASSY-CIRCUIT BREAKER	233T5210 81205	1	91-02-11 0200/271/L011	ALL
P011-02		233T5216 PNL ASSY-CIRCUIT BREAKER	233T5210 81205	1	91-02-12 0212/280/L011	ALL
P011-03		233T5216 PNL ASSY-CIRCUIT BREAKER	233T5210 81205	1	91-02-13 0220/286/L011	ALL
P011-04		233T5216 PNL ASSY-CIRCUIT BREAKER	233T5210 81205	1	91-02-14 0200/271/R011	ALL
P011-05		233T5216 PNL ASSY-CIRCUIT BREAKER	233T5210 81205	1	91-02-15 0212/280/R011	ALL
P011-06		233T5216 PNL ASSY-CIRCUIT BREAKER	233T5210 81205	1	91-02-16 0220/286/R011	ALL

EQUIPMENT LIST

D280T132

Section P011
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P013-00		232T1406-41 PNL-CAPT AUX INSTR,FWD	232T1405 81205	1	91-00-00 0162/230/L040	ALL

EQUIPMENT LIST

D280T132

Section P013
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P014-00		232T1406-42 PNL-F/O AUX INSTR,FWD	232T1405 81205	1	91-00-00 0162/230/R040	ALL

EQUIPMENT LIST

D280T132

Section P014
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P015-00		233T7100 PNL-CAPT AUX INSTR	230T0900 81205	1	91-00-00 0188/220/L050	050-099

EQUIPMENT LIST

D280T132

Section P015
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P016-00		233T7100 PNL-F/O AUX INSTR	230T0900 81205	1	91-00-00 0188/220/R050	050-099

EQUIPMENT LIST

D280T132

Section P016
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P017-00		233T7100 PNL-FIRST OBSERVER CSL	230T0900 81205	1	91-00-00 0209/220/L050	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P017
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P019-00		285T0019 PNL-LIGHTING DISTR,FWD	284T0186 81205	1	91-02-76 0400/308/L030	ALL

EQUIPMENT LIST

D280T132

Section P019
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P021-00		417T6008 PNL-ATT,FWD (SEE YBH)	417T6000 81205	1	23-34-12 0284/261/L053	ALL

EQUIPMENT LIST

D280T132

Section P021
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P022-00		417T6010 PNL-ATT,AFT (SEE YBI)	417T6002 81205	1	33-21-12 1540/250/R060	ALL

EQUIPMENT LIST

D280T132

Section P022
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P023-00		284T0905 PNL-XFMR,NOSE GEAR LDG/TAXI LTS	284T6200 81205	1	33-42-11 0273/110/0000	050-099

EQUIPMENT LIST

D280T132

Section P023
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P024-00		284T0216-4 PNL-CARGO HDLG CONT,FWD COMPT	284T0001 81205	1	25-53-11 0470/175/R090	ALL

EQUIPMENT LIST

D280T132

Section P024
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P025-00		285T0009 PNL-LIGHTING DISTR,AFT	284T0192 81205	1	91-02-77 1030/305/L030	ALL

EQUIPMENT LIST

D280T132

Section P025
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P027-00		284T0216-2 PNL-CARGO HDLG CONT,AFT COMPT	284T0001 81205	1	25-53-21 1256/175/R090	050-099
P027-00		284T0216-6 PNL-CARGO HDLG CONT,AFT COMPT	284T0001 81205	1	25-53-21 1256/175/R090	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P027
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P028-00		344T0021-8 PNL-FUELING CONTROL	344T0020 81205	1	28-21-11 L0680/12/FS	ALL

EQUIPMENT LIST

D280T132

Section P028
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P030-00		284T0390 PNL-EXT PWR RCPT	284T0390 81205	1	91-00-00 0300/120/R040	ALL

EQUIPMENT LIST

D280T132

Section P030
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P031-00		284T0171 PNL-GEN PWR,LEFT	284T0633 81205	1	91-00-00 0336/170/L069	ALL

EQUIPMENT LIST

D280T132

Section P031
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P032-00		284T0172 PNL-GEN PWR,RIGHT	284T0633 81205	1	91-00-00 0336/170/R069	ALL

EQUIPMENT LIST

D280T132

Section P032
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P033-00		284T0189 PNL-MISC ELEC EQPT,FWD	284T0594 81205	1	91-02-67 0296/160/L010	ALL

EQUIPMENT LIST

D280T132

Section P033
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P034-00		284T0175 PNL-APU EXT PWR	284T0633 81205	1	91-00-00 0296/160/R018	ALL

EQUIPMENT LIST

D280T132

Section P034
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P035-00		284T0687-67 PNL-CARGO HDLG ACCESS,FWD COMPT	284T0348 81205	1	91-02-78 0478/182/R067	050-099
P035-00		284T0687-84 PNL-CARGO HDLG ACCESS,FWD COMPT	284T0348 81205	1	91-02-78 0478/182/R067	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P035
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P036-00		284T0187 PNL-MISC ELEC EQPT,LEFT	284T0633 81205	1	91-02-71 0314/170/L068	ALL

EQUIPMENT LIST

D280T132

Section P036
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P037-00		284T0188 PNL-MISC ELEC EQPT,RIGHT	284T0633 81205	1	91-02-74 0314/170/R068	ALL

EQUIPMENT LIST

D280T132

Section P037
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P039-00		284T0688-51 PNL-CARGO HDLG ACCESS,AFT COMPT	284T0349 81205	1	91-02-81 1268/182/R067	050-099
P039-00		284T0688-64 PNL-CARGO HDLG ACCESS,AFT COMPT	284T0349 81205	1	91-02-81 1268/182/R067	150-199
P039-00		284T0688-63 PNL-CARGO HDLG ACCESS,AFT COMPT	284T0349 81205	1	91-02-81 1268/182/R067	275-299

EQUIPMENT LIST

D280T132

Section P039
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P040-00		284T0719 PNL-REMOTE CONTROL,APU	284T0719 81205	1	91-02-81 0270/095/0000	ALL

EQUIPMENT LIST

D280T132

Section P040
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P043-00		284T4301-305 CONT PNL-FWD CARGO DR,EXT	284T4300 81205	1	52-34-12 0447/175/R035	ALL

EQUIPMENT LIST

D280T132

Section P043
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P044-00		284T0566-7 CONT PNL-AFT CARGO DR,EXT	284T0271 81205	1	52-35-12 1222/175/R035	050-099
P044-00		284T4401-307 CONT PNL-AFT CARGO DR,EXT	284T4400 81205	1	52-35-12 1200+132/175/R035	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P044
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P049-00		284T1149 PNL-APU AUX	284T0160 81205	1	91-02-84 1362/180/R086	ALL

EQUIPMENT LIST

D280T132

Section P049
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P050-00		285T0006-46 CARD FILE-ELECTRICAL SYSTEMS	284T0049 81205	1	21-25-11 0287/180/R036	050-099, 153-199, 277-299
P050-00		285T0006-44 CARD FILE-ELECTRICAL SYSTEMS	284T0049 81205	1	21-25-11 0287/180/R036	150-152, 275-276

EQUIPMENT LIST

D280T132

Section P050
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P051-00		285T0007 UNIT-WARNING ELECTRONICS	284T0049 81205	1	31-51-11 P051-00/ /	ALL

EQUIPMENT LIST

D280T132

Section P051
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P054-00		285T0509-9 CARD FILE-FIRE DETECTION	284T0049 81205	1	26-11-11 0230/165/R030	ALL

EQUIPMENT LIST

D280T132

Section P054
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P055-00		233T2100 PNL-GLARESHIELD,CENTER	230T0900 81205	1	22-11-12 0130/230/0000	ALL

EQUIPMENT LIST

D280T132

Section P055
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P056-00		284T0554-2 PNL-WHEEL WELL SERVICE,R	284T0550 81205	1	33-31-11 0953/115/R035	ALL

EQUIPMENT LIST

D280T132

Section P056
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P058-00		417T6505-2 PNL-MID ABBR ATT (SEE YBT)	417T6505 81205	1	33-22-31 0918/260/L020	150-199
P058-00		417T6505-3 PNL-MID ABBR ATT (SEE YBT)	417T6505 81205	1	33-22-31 0801/260/L010	275-299

EQUIPMENT LIST

D280T132

Section P058
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P059-00		417T6505-1 PNL-AFT ABBR ATT (SEE YBU)	417T6505 81205	1	33-22-31 1540/260/L054	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P059
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P061-00		233T4100 PNL-SIDE,RIGHT	230T0900 81205	1	91-02-38 0220/260/R036	ALL

EQUIPMENT LIST

D280T132

Section P061
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P065-00		284T1168 PNL-HYDRAULIC GENERATOR POWER	284T1173 81205	1	24-25-11 0220/160/L060	ALL

EQUIPMENT LIST

D280T132

Section P065
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P070-00		284T0501-37 SW PANEL-OFF-WING ESC SYS,LEFT	284T0263 81205	1	25-65-11 0868/258/L089	050-099
P070-00		284T0501-51 SW PANEL-OFF-WING ESC SYS,LEFT	284T0263 81205	1	25-65-11 0868/258/L089	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P070
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P071-00		284T0501-38 SW PANEL-OFF-WING ESC SYS,RIGHT	284T0263 81205	1	25-65-12 0868/258/R089	050-099
P071-00		284T0501-52 SW PANEL-OFF-WING ESC SYS,RIGHT	284T0263 81205	1	25-65-12 0868/258/R089	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P071
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P072-00		284T0501-49 SW PANEL-OFF-WING ESC SYS,LEFT AFT	284T0263 81205	1	25-65-11 0913/258/L089	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P072
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P073-00		284T0501-50 SW PANEL-OFF-WING ESC SYS,RIGHT AFT	284T0263 81205	1	25-65-12 0913/258/R089	150-199, 275-299

EQUIPMENT LIST

D280T132

Section P073
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
P078-00		285T1156-1 PANEL-PURSER LIGHTING/PA (SEE YIE)	284T4208 81205	1	33-21-11 0447/260/L050	150-199

EQUIPMENT LIST

D280T132

Section P078
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
QD0001		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 CAPT/COL/	ALL
QD0002		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 CAPT/COL/	ALL
QD0003		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 CAPT/COL/	ALL
QD0004		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 CAPT/COL/	ALL
QD0005		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 CAPT/COL/	ALL
QD0006		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-11 CAPT/COL/	ALL
QD0007		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-11 CAPT/COL/	ALL
QD0008		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-11 CAPT/COL/	ALL
QD0009		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-11 CAPT/COL/	ALL
QD0010		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 CAPT/COL/	ALL
QD0011		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 CAPT/COL/	ALL
QD0012		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 CAPT/COL/	ALL
QD0013		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 CAPT/COL/	ALL
QD0014		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-32 CAPT/COL/	ALL
QD0015		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 CAPT/COL/	ALL
QD0016		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 CAPT/COL/	ALL
QD0017		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-32 CAPT/COL/	ALL

EQUIPMENT LIST

D280T132

Section QD0000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
QD0018		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 F/O/COL/	ALL
QD0019		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 F/O/COL/	ALL
QD0020		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 F/O/COL/	ALL
QD0021		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 F/O/COL/	ALL
QD0022		TSE-20-01 QUICK DISCONNECT	11139	1	27-41-11 F/O/COL/	ALL
QD0023		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-21 F/O/COL/	ALL
QD0024		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-21 F/O/COL/	ALL
QD0025		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-21 F/O/COL/	ALL
QD0026		TSE-20-01 QUICK DISCONNECT	11139	1	23-51-21 F/O/COL/	ALL
QD0027		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 F/O/COL/	ALL
QD0028		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 F/O/COL/	ALL
QD0029		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 F/O/COL/	ALL
QD0030		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-22 F/O/COL/	ALL
QD0031		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-32 F/O/COL/	ALL
QD0032		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 F/O/COL/	ALL
QD0033		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-12 F/O/COL/	ALL
QD0034		TSE-20-01 QUICK DISCONNECT	11139	1	22-11-32 F/O/COL/	ALL

EQUIPMENT LIST

D280T132

Section QD0000

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
QD6776J		48-7191-1 RCPT-	02660	1	33-13-18 P010-00/ /	050-099
QD6776J		48-7191-1 REPT-	02660	1	33-13-18 P010-00/ /	155-199, 275-299
QD6776P		48-7190-1 PLUG-	02660	1	33-13-18 P010-00/ /	050-099, 155-199, 275-299
QD6780J		48-7191-1 RCPT-	02660	1	33-13-18 P010-00/ /	050-099
QD6780J		48-7191-1 REPT-	02660	1	33-13-18 P010-00/ /	155-199, 275-299
QD6780P		48-7190-1 PLUG-	02660	1	33-13-18 P010-00/ /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section QD6700
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00001		1N1190 DIODE	233T5216 80131	1	24-51-31 P011-00/ /	ALL
R00002		1N1190 DIODE	233T5216 80131	1	24-51-31 P011-00/ /	ALL
R00003		1N1190 DIODE	233T5216 80131	1	24-51-31 0198/275/R012	ALL
R00004		YHLZD-29 DIODE-GCB TRIP ISOL,LEFT	284T0171 09922	1	24-22-11 P031-00/ /	ALL
R00005		YHLZD-29 DIODE-GCB TRIP ISOL,RIGHT	284T0172 09922	1	24-22-21 P032-00/ /	ALL
R00006		YHLZD-29 DIODE-APB TRIP ISOL	284T0175 09922	1	24-22-41 P034-00/ /	ALL
R00007		YHLZD-29 DIODE-BTB TRIP ISOL,LEFT	284T0171 09922	1	24-22-12 P031-00/ /	ALL
R00008		YHLZD-29 DIODE-BTB TRIP ISOL,RIGHT	284T0172 09922	1	24-22-22 P032-00/ /	ALL
R00011		JANTX1N1206A DIODE-APU CONTROL,MAIN	284T1149 96906	1	49-61-11 P049-00/ /	ALL
R00012		JANTX1N1206A DIODE-APU CONTROL,BAT.	284T1149 96906	1	49-61-11 P049-00/ /	ALL
R00019	1	YHLZD-30 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00019	2	YHLZD-9 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00022	1	YHLZD-30 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00022	2	YHLZD-9 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00023	1	YHLZD-30 DIODE-K458 RELAY	284T0189 09922	1	23-34-11 P033-00/ /	ALL
R00023	2	YHLZD-9 DIODE-K458 RELAY	284T0189 09922	1	23-34-11 P033-00/ /	ALL
R00024		RER75F4R02R RESISTOR-AILERON LOCKOUT ACTUATOR	284T0111 81205	1	27-11-12 SHELF/E01/01	ALL

EQUIPMENT LIST

D280T132

Section R00000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00025		RER75F4R02R RESISTOR-AILERON LOCKOUT ACTUATOR	280T0121 81205	1	27-11-22 SHELF/E02/01	ALL
R00026	1	YHLZD-30 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00026	2	YHLZD-9 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00027	1	YHLZD-30 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00027	2	YHLZD-9 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00028	1	YHLZD-30 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00028	2	YHLZD-9 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00029		YHLZD-29 DIODE ASSY-AUTOLAND ISOL,LEFT	284T0171 09922	1	24-51-31 P031-00/ /	ALL
R00030		YHLZD-29 DIODE ASSY-AUTOLAND ISOL,RIGHT	284T0172 09922	1	24-51-31 P032-00/ /	ALL
R00033		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00034		YHLZD-30 DIODE-BURNDY BLOCK	284T0115 09922	1	34-46-12 SHELF/E01/05	ALL
R00035		YHLZD-30 DIODE-ISOLATION	284T0687 09922	1	52-34-12 P035-00/ /	ALL
R00036		YHLZD-30 DIODE-ISOLATION	284T0687 09922	1	25-53-11 P035-00/ /	050-099
R00036		YHLZD-30 DIODE-ISOLATION	284T3501 09922	1	25-53-11 P035-00/ /	150-199, 275-299
R00037		YHLZD-30 DIODE-ISOLATION	284T0688 09922	1	52-35-12 P039-00/ /	ALL
R00038		YHLZD-30 DIODE-ISOLATION	284T0688 09922	1	25-53-21 P039-00/ /	050-099
R00038		YHLZD-30 DIODE-ISOLATION	284T3901 09922	1	25-53-21 P039-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section R00000

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00039	1	YHLZD-30 DIODE-APU DC PUMP CONT	284T0188 09922	1	28-25-11 P037-00/ /	ALL
R00039	2	YHLZD-9 DIODE-APU DC PUMP CONT	284T0188 09922	1	28-25-11 P037-00/ /	ALL
R00040		YHLZD-30 DIODE-AFT CAR. DOOR NOT CLOSED	284T0112 09922	1	33-37-21 SHELF/E01/02	ALL
R00041		YHLZD-30 DIODE-BULK CAR. DOOR NOT CLOSED	284T0112 09922	1	33-37-21 SHELF/E01/02	ALL
R00042	1	YHLZD-30 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00042	2	YHLZD-9 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00043	1	YHLZD-30 DIODE	284T0188 09922	1	29-11-22 P037-00/ /	ALL
R00043	2	YHLZD-9 DIODE	284T0188 09922	1	29-11-22 P037-00/ /	ALL
R00044	1	YHLZD-30 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00044	2	YHLZD-9 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00045	1	YHLZD-30 DIODE	284T0189 09922	1	29-11-12 P033-00/ /	ALL
R00045	2	YHLZD-9 DIODE	284T0189 09922	1	29-11-12 P033-00/ /	ALL
R00058		JANTX1N1206A DIODE-DUAL PWR,INTPH	233T5216 96906	1	23-51-21 P011-00/ /	ALL
R00059		JANTX1N1206A DIODE-DUAL PWR,INTPH	233T5216 96906	1	23-51-11 P011-00/ /	ALL
R00060		JANTX1N1206A DIODE-DUAL PWR,INTPH	233T5216 96906	1	23-51-21 P011-00/ /	ALL
R00061		JANTX1N1206A DIODE-DUAL PWR,INTPH	233T5216 96906	1	23-51-11 P011-00/ /	ALL
R00062	1	YHLZD-30 DIODE	284T0112 09922	1	32-42-11 SHELF/E01/02	ALL

EQUIPMENT LIST

D280T132

Section R00000

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00062	2	YHLZD-9 DIODE	284T0112 09922	1	32-42-11 SHELF/E01/02	ALL
R00063		YHLZD-30 DIODE	284T1612 09922	1	32-71-11 SHELF/E01/02	ALL
R00063	1	YHLZD-30 DIODE	284T0112 09922	1	32-61-11 SHELF/E01/02	ALL
R00063	2	YHLZD-9 DIODE	284T0112 09922	1	32-61-11 SHELF/E01/02	ALL
R00064		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00065	1	YHLZD-30 DIODE-APU SHUTDOWN ISOLATION	284T0188 09922	1	49-61-11 P037-00/ /	ALL
R00065	2	YHLZD-9 DIODE-APU SHUTDOWN ISOLATION	284T0188 09922	1	49-61-11 P037-00/ /	ALL
R00068	1	YHLZD-30 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00068	2	YHLZD-9 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00074		YHLZD-30 DIODE-BURNDY BLOCK	284T0115 09922	1	34-46-12 SHELF/E01/05	150-199, 275-278
R00075		YHLZD-30 DIODE-BURNDY BLOCK	284T0115 09922	1	34-46-12 SHELF/E01/05	150-199, 275-278
R00076		YHLZD-30 DIODE-SELCAL LT ISLN,E2-5	284T0125 09922	1	23-21-11 SHELF/E02/05	ALL
R00077	1	YHLZD-30 DIODE-K494 BLOCKING	284T0189 09922	1	36-11-51 P033-00/ /	ALL
R00077	2	YHLZD-9 DIODE-K494 BLOCKING	284T0189 09922	1	36-11-51 P033-00/ /	ALL
R00078	1	YHLZD-30 DIODE-K495 BLOCKING	284T0188 09922	1	36-11-52 P037-00/ /	ALL
R00078	2	YHLZD-9 DIODE-K495 BLOCKING	284T0188 09922	1	36-11-52 P037-00/ /	ALL
R00086		YHLZD-30 DIODE-CHIME ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	150-199, 275-299

EQUIPMENT LIST

D280T132

Section R00000

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00087		YHLZD-30 DIODE-CHIME ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	150-199, 275-299
R00088		YHLZD-30 DIODE-CHIME ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	150-199, 275-299
R00089		YHLZD-30 DIODE-CHIME ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	150-199, 275-299

EQUIPMENT LIST

D280T132

Section R00000
Page 5 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00108	1	YHLZD-30 DIODE-ISOLATION	284T0188 09922	1	26-16-21 P037-00/ /	ALL
R00108	2	YHLZD-9 DIODE-ISOLATION	284T0188 09922	1	26-16-21 P037-00/ /	ALL
R00109	1	YHLZD-30 DIODE-ISOLATION	284T0188 09922	1	26-16-21 P037-00/ /	ALL
R00109	2	YHLZD-9 DIODE-ISOLATION	284T0188 09922	1	26-16-21 P037-00/ /	ALL
R00110	1	YHLZD-30 DIODE-APU FAULT	284T0175 09922	1	49-61-11 P034-00/ /	ALL
R00110	2	YHLZD-9 DIODE-APU FAULT	284T0175 09922	1	49-61-11 P034-00/ /	ALL
R00111	1	YHLZD-30 DIODE-APU FUEL SHUTOFF	284T0175 09922	1	49-61-11 P034-00/ /	ALL
R00111	2	YHLZD-9 DIODE-APU FUEL SHUTOFF	284T0175 09922	1	49-61-11 P034-00/ /	ALL
R00112		YHLZD-30 DIODE-L RECIRC FAN/CARGO FIRE	285T0006 09922	1	21-25-11 P050-00/ /	ALL
R00113		YHLZD-30 DIODE-R RECIRC FAN/CARGO FIRE	285T0006 09922	1	21-25-11 P050-00/ /	ALL
R00120		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00121		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00122		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00123		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00124		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00125		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00126		YHLZD-9 DIODE-PTT ISLN	284T1625 81205	1	23-31-12 SHELF/E02/05	275-299

EQUIPMENT LIST

D280T132

Section R00100

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00129	1	YHLZD-30 DIODE-	284T0187 09922	1	32-42-11 P036-00/ /	ALL
R00129	2	YHLZD-9 DIODE-	284T0187 09922	1	32-42-11 P036-00/ /	ALL
R00130	1	YHLZD-30 DIODE-	284T0187 09922	1	32-42-11 P036-00/ /	ALL
R00130	2	YHLZD-9 DIODE-	284T0187 09922	1	32-42-11 P036-00/ /	ALL
R00131	1	YHLZD-30 DIODE-APU REMOTE BLOCKING	284T0188 09922	1	26-15-12 P037-00/ /	ALL
R00131	2	YHLZD-9 DIODE-APU REMOTE BLOCKING	284T0188 09922	1	26-15-12 P037-00/ /	ALL
R00132	1	YHLZD-30 DIODE	284T0187 96906	1	29-11-32 P036-00/ /	ALL
R00132	2	YHLZD-9 DIODE	284T0187 96906	1	29-11-32 P036-00/ /	ALL
R00133		YHLZD-30 DIODE-ISOLATION,FWD CARGO DOOR UNLOCKED	284T0112 09922	1	33-37-11 SHELF/E01/02	ALL
R00136		YHLZD-30 DIODE-SOLENOID BLKG,L	233T4100 09922	1	26-11-11 P061-00/ /	ALL
R00137		YHLZD-30 DIODE-FIRE SW LT BLKG,L	233T4100 09922	1	26-11-11 P061-00/ /	ALL
R00138		YHLZD-30 DIODE-FUEL COND SW LT BLKG,L	233T4100 09922	1	26-11-11 P061-00/ /	ALL
R00139		YHLZD-30 DIODE-SOLENOID BLKG,R	233T4100 09922	1	26-11-21 P061-00/ /	ALL
R00140		YHLZD-30 DIODE-FIRE SW LT BLKG,R	233T4100 09922	1	26-11-21 P061-00/ /	ALL
R00141		YHLZD-30 DIODE-FUEL COND SW LT BLKG,R	233T4100 09922	1	26-11-21 P061-00/ /	ALL
R00142		YHLZD-30 DIODE-SOLENOID BLKG,APU	233T4100 09922	1	26-15-11 P061-00/ /	ALL
R00143		YHLZD-30 DIODE-FIRE SW LT BLKG,APU	233T4100 09922	1	26-15-11 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section R00100

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00146		YHLZD-30 DIODE-ISOLATION	284T0687 09922	1	25-53-13 P035-00/ /	050-099
R00146		YHLZD-30 DIODE-ISOLATION	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00147		YHLZD-30 DIODE-ISOLATION	284T0687 09922	1	25-53-13 P035-00/ /	050-099
R00147		YHLZD-30 DIODE-ISOLATION	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00150		YHLZD-30 DIODE-K256 COIL ISOLATION	284T0687 09922	1	25-53-13 P035-00/ /	050-099
R00151		YHLZD-30 DIODE-K257 COIL ISOLATION	284T0687 09922	1	25-53-13 P035-00/ /	050-099
R00152		YHLZD-30 DIODE-K584 COIL ISOLATION	284T0687 09922	1	25-53-13 P035-00/ /	050-099
R00153		YHLZD-30 DIODE-K585 COIL ISOLATION	284T0687 09922	1	25-53-13 P035-00/ /	050-099
R00155		YHLZD-30 DIODE-K279 COIL ISOLATION	284T0688 09922	1	25-53-23 P039-00/ /	050-099
R00155		YHLZD-30 DIODE-K279 COIL ISOLATION	284T3901 09922	1	25-53-23 P039-00/ /	150-199, 275-299
R00156		YHLZD-30 DIODE-K280 COIL ISOLATION	284T0688 09922	1	25-53-23 P039-00/ /	050-099
R00156		YHLZD-30 DIODE-K280 COIL ISOLATION	284T3901 09922	1	25-53-23 P039-00/ /	150-199, 275-299
R00157		YHLZD-30 DIODE-K281 COIL ISOLATION	284T0688 09922	1	25-53-23 P039-00/ /	050-099
R00157		YHLZD-30 DIODE-K281 COIL ISOLATION	284T3901 09922	1	25-53-23 P039-00/ /	150-199, 275-299
R00158		YHLZD-30 DIODE-K282 COIL ISOLATION	284T0688 09922	1	25-53-23 P039-00/ /	050-099
R00158		YHLZD-30 DIODE-K282 COIL ISOLATION	284T3901 09922	1	25-53-23 P039-00/ /	150-199, 275-299
R00159	1	YHLZD-30 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section R00100

Page 3

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00159	2	YHLZD-9 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00160	1	YHLZD-30 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00160	2	YHLZD-9 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00161	1	YHLZD-30 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00161	2	YHLZD-9 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00162	1	YHLZD-30 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00162	2	YHLZD-9 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00163	1	YHLZD-30 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00163	2	YHLZD-9 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00164	1	YHLZD-30 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00164	2	YHLZD-9 DIODE	284T0187 09922	1	29-11-32 P036-00/ /	ALL
R00174	1	YHLZD-30 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00174	2	YHLZD-9 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00175	1	YHLZD-30 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00175	2	YHLZD-9 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00176	1	YHLZD-30 DIODE	284T0124 09922	1	27-88-11 SHELF/E02/04	ALL
R00176	2	YHLZD-9 DIODE	284T0124 09922	1	27-88-11 SHELF/E02/04	ALL

EQUIPMENT LIST

D280T132

Section R00100

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00178	1	YHLZD-30 DIODE	284T0124 09922	1	27-88-11 SHELF/E02/04	ALL
R00178	2	YHLZD-9 DIODE	284T0124 09922	1	27-88-11 SHELF/E02/04	ALL
R00179		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00180		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00181		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00182		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00183		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00184		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00186		YHLZD-30 DIODE-ISOLATION	233T3100 09922	1	36-11-41 P005-00/ /	ALL
R00187		YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	27-58-21 P050-00/ /	050-099, 150-199, 275-276
R00189		YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	27-58-21 P050-00/ /	050-099, 150-199, 275-276
R00191		YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	27-58-21 P050-00/ /	ALL
R00192		YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	27-58-21 P050-00/ /	ALL
R00193		YHLZD-33 DIODE-L ENG FIRE BAT. BUS ISLN	233T5216 09922	1	26-11-11 P011-00/ /	ALL
R00194		YHLZD-33 DIODE-L ENG FIRE RIGHT BUS ISLN	233T5216 09922	1	26-11-11 P011-00/ /	ALL
R00195		YHLZD-33 DIODE-L ENG OVHT BAT. BUS ISLN	233T5216 09922	1	26-11-12 P011-00/ /	ALL
R00196		YHLZD-33 DIODE-L ENG OVHT RIGHT BUS ISLN	233T5216 09922	1	26-11-12 P011-00/ /	ALL

EQUIPMENT LIST

D280T132

Section R00100

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00197		YHLZD-33 DIODE-R ENG FIRE BAT. BUS ISLN	233T5216 09922	1	26-11-21 P011-00/ /	ALL
R00198		YHLZD-33 DIODE-R ENG FIRE RIGHT BUS ISLN	233T5216 09922	1	26-11-21 P011-00/ /	ALL
R00199		YHLZD-33 DIODE-R ENG OVHT BAT. BUS ISLN	233T5216 09922	1	26-11-22 P011-00/ /	ALL

EQUIPMENT LIST

D280T132

Section R00100

Page 6 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00200		YHLZD-33 DIODE-R ENG OVHT RIGHT BUS ISLN	233T5216 09922	1	26-11-22 P011-00/ /	ALL
R00201		YHLZD-33 DIODE-APU FIRE BAT. BUS ISLN	233T5216 09922	1	26-15-11 P011-00/ /	ALL
R00202		YHLZD-33 DIODE-APU FIRE RIGHT BUS ISLN	233T5216 09922	1	26-15-11 P011-00/ /	ALL
R00203		YHLZD-33 DIODE-CARGO SMOKE BUS ISLN	233T5216 81205	1	26-16-11 P011-00/ /	ALL
R00204		YHLZD-33 DIODE-CARGO SMOKE BUS ISLN	233T5216 81205	1	26-16-11 P011-00/ /	ALL
R00205		YHLZD-30 DIODE-K494 BLOCKING	284T1612 09922	1	21-31-11 SHELF/E01/02	ALL
R00206		YHLZD-30 DIODE-K494 BLOCKING	284T1624 09922	1	21-31-21 SHELF/E02/04	ALL
R00207		YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	27-58-21 P050-00/ /	ALL
R00208		YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	27-58-21 P050-00/ /	ALL
R00209		YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	27-58-21 P050-00/ /	ALL
R00210		YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	27-58-21 P050-00/ /	ALL
R00211	1	YHLZD-30 DIODE-FWD ZONE INOP	284T0188 09922	1	21-61-21 P037-00/ /	ALL
R00211	2	YHLZD-9 DIODE-FWD ZONE INOP	284T0188 09922	1	21-61-21 P037-00/ /	ALL
R00212	1	YHLZD-30 DIODE-AFT ZONE INOP	284T0188 09922	1	21-61-31 P037-00/ /	ALL
R00212	2	YHLZD-9 DIODE-AFT ZONE INOP	284T0188 09922	1	21-61-31 P037-00/ /	ALL
R00217		YHLZD-30 DIODE	287T4163 09922	1	32-42-12 P061-00/ /	ALL
R00218		YHLZD-30 DIODE	287T4163 09922	1	32-42-11 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section R00200

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00225		YHLZD-30 DIODE-L STARTER INDICATION	284T0997 09922	1	80-11-11 P006-05/ /	ALL
R00226		YHLZD-30 DIODE-R STARTER INDICATION	284T0997 09922	1	80-11-21 P006-05/ /	ALL
R00227	9	YHLZD-30 DIODE-ISOLATION (SB 78-0062)	284T0112 09922	1	78-34-11 SHELF/E01/02	ALL
R00228		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	78-34-11 SHELF/E01/02	ALL
R00229	9	YHLZD-30 DIODE-ISOLATION (SB 78-0062)	284T0112 09922	1	78-34-21 SHELF/E01/02	ALL
R00230		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	78-34-21 SHELF/E01/02	ALL
R00239	1	YHLZD-30 DIODE-ISOLATION	284T0187 09922	1	36-11-41 P036-00/ /	ALL
R00239	2	YHLZD-9 DIODE-ISOLATION	284T0187 09922	1	36-11-41 P036-00/ /	ALL
R00242	1	YHLZD-30 DIODE-ISOLATION	284T0188 09922	1	36-11-41 P037-00/ /	ALL
R00242	2	YHLZD-9 DIODE-ISOLATION	284T0188 09922	1	36-11-41 P037-00/ /	ALL
R00244	1	YHLZD-30 DIODE-BLOCK	284T0189 09922	1	27-62-11 P033-00/ /	ALL
R00244	2	YHLZD-9 DIODE-BLOCK	284T0189 09922	1	27-62-11 P033-00/ /	ALL
R00246	1	YHLZD-30 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00246	2	YHLZD-9 DIODE	284T0188 09922	1	29-11-12 P037-00/ /	ALL
R00247	1	YHLZD-30 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00247	2	YHLZD-9 DIODE	284T0189 09922	1	29-11-22 P033-00/ /	ALL
R00248	1	YHLZD-30 DIODE-ISOLATION,BTL 2 FWD SQUIB	284T0188 81205	1	26-23-12 P037-00/ /	150-154

EQUIPMENT LIST

D280T132

Section R00200

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00248	2	YHLZD-9 DIODE-ISOLATION,BTL 2 FWD SQUIB	284T0188 81205	1	26-23-12 P037-00/ /	150-154
R00249	1	YHLZD-30 DIODE-ISOLATION,BTL 2 AFT SQUIB	284T0188 81205	1	26-23-12 P037-00/ /	150-154
R00249	2	YHLZD-9 DIODE-ISOLATION,BTL 2 AFT SQUIB	284T0188 81205	1	26-23-12 P037-00/ /	150-154
R00250	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	21-61-41 P037-00/ /	ALL
R00250	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	21-61-41 P037-00/ /	ALL
R00252		YHLZD-30 DIODE-SUPPRESSOR	284T0125 09922	1	23-43-11 SHELF/E02/05	ALL
R00255		YHLZD-30 DIODE-EFI SW ISOLATION	284T1615 09922	1	31-31-19 SHELF/E01/05	ALL
R00256		YHLZD-30 DIODE-IRS SW ISOLATION	284T1615 09922	1	31-31-19 SHELF/E01/05	ALL
R00259	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-45-21 P036-00/ /	ALL
R00259	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-45-21 P036-00/ /	ALL
R00260	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-45-21 P037-00/ /	ALL
R00260	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	21-45-21 P037-00/ /	ALL
R00261	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-45-21 P037-00/ /	ALL
R00261	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	21-45-21 P037-00/ /	ALL
R00262	1	YDLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-45-21 P037-00/ /	ALL
R00262	2	YHLZD-9 DIODE-BLOCKING	284T3701 81205	1	21-45-21 P037-00/ /	ALL
R00267		YHLZD-30 DIODE	284T0123 09922	1	31-31-11 SHELF/E02/03	ALL

EQUIPMENT LIST

D280T132

Section R00200

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00270	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	ALL
R00270	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	ALL
R00271	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	ALL
R00271	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	ALL
R00272	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	050-099, 150-199, 275-276
R00272	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	050-099, 150-199, 275-276
R00273	9	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	150, 152-157
R00273	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	050-099, 150-199, 275-276
R00273	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	21-58-12 P037-00/ /	050-099, 150-199, 275-276
R00276		YHLZD-30 DIODE-BLOCKING	284T0112 09922	1	29-11-32 SHELF/E01/02	ALL
R00281		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00282		YHLZD-30 DIODE-ISOLATION	284T0112 09922	1	32-61-14 SHELF/E01/02	ALL
R00283		YHLZD-30 DIODE-BURNDY BLOCK	284T0115 09922	1	34-46-12 SHELF/E01/05	150-199, 275-278
R00285		YHLZD-30 DIODE-CHIME ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	150-199, 275-299
R00286		YHLZD-30 DIODE-CHIME ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	150-199, 275-299
R00287		YHLZD-30 DIODE-CHIME ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	150-199, 275-299
R00288		YHLZD-30 DIODE ASSY	284T0112 09922	1	32-71-11 SHELF/E01/02	150-199, 275-299

EQUIPMENT LIST

D280T132

Section R00200

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00289		YHLZD-30 DIODE-K283 COIL ISLN	284T3901 09922	1	25-53-23 P039-00/ /	150-199, 275-299
R00290		YHLZD-30 DIODE-K284 COIL ISLN	284T3901 09922	1	25-53-23 P039-00/ /	150-199, 275-299
R00293		YHLZD-30 DIODE-K910 COIL ISLN	284T3901 09922	1	25-53-23 P039-00/ /	150-199, 275-299
R00294		YHLZD-30 DIODE-K911 COIL ISLN	284T3901 09922	1	25-53-23 P039-00/ /	150-199, 275-299
R00297		69B40800-13 DIODE-	284T0187 09922	1	76-11-11 P036-00/ /	ALL
R00298		69B40800-13 DIODE-	284T0188 09922	1	76-11-11 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section R00200
Page 5 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00300	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	25-33-11 P037-00/ /	150-154
R00300	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	25-33-11 P037-00/ /	150-154
R00312		YHLZD-30 DIODE-MASTER CALL ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	050-099
R00313		YHLZD-30 DIODE-MASTER CALL ISLN	284T0125 09922	1	23-34-13 SHELF/E02/05	050-099
R00314	1	YHLZD-30 DIODE	284T0188	1	27-09-13 P037-00/ /	ALL
R00314	2	YHLZD-9 DIODE	284T0188	1	27-09-13 P037-00/ /	ALL
R00317		YHLZD-30 DIODE-ISLN,PDU DRIVE CONT FWD COMPT	284T0687 09922	1	25-53-16 P035-00/ /	ALL
R00318		YHLZD-30 DIODE-ISLN,CTR MODE CMD	284T0687 09922	1	25-53-16 P035-00/ /	050-099
R00318		YHLZD-30 DIODE-ISLN,CTR MODE CMD	284T3501 09922	1	25-53-16 P035-00/ /	150-199, 275-299
R00319		YHLZD-30 DIODE-ISLN,CTR GUIDES CMD FWD COMPT	284T0687 09922	1	25-53-16 P035-00/ /	050-099
R00319		YHLZD-30 DIODE-ISLN,CTR GUIDES CMD FWD COMPT	284T0687 09922	1	25-53-14 P035-00/ /	150-199, 275-299
R00320		YHLZD-30 DIODE-ISLN,AFT LAT GUIDE PALLET MODE	284T0000 81205	1	25-53-15 P035-00/ /	050-099
R00321		YHLZD-30 DIODE-ISLN,AFT LAT GUIDE AUTO CONT	284T0000 81205	1	25-53-15 P035-00/ /	ALL
R00322		YHLZD-30 DIODE-ISLN,PDU DRIVE CONTROL AFT COMPT	284T3901 09922	1	25-53-26 P039-00/ /	050-099
R00322		YHLZD-30 DIODE-ISLN,PDU DRIVE CONTROL AFT COMPT	284T0688 09922	1	25-53-26 P039-00/ /	150-199, 275-299
R00323		YHLZD-30 DIODE-K992 COIL ISLN	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00324		YHLZD-30 DIODE-K991 COIL ISLN	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section R00300

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00325		YHLZD-30 DIODE-K993 COIL ISLN	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00326		YHLZD-30 DIODE-K994 COIL ISLN	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00327		YHLZD-30 DIODE-K995 COIL ISLN	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00328		YHLZD-30 DIODE-K996 COIL ISLN	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00329		YHLZD-30 DIODE-ISLN CTR GUIDES CMD AFT COMPT	284T0688 09922	1	25-53-26 P039-00/ /	050-099
R00329		YHLZD-30 DIODE-ISLN CTR GUIDES CMD AFT COMPT	284T3901 09922	1	25-53-26 P039-00/ /	150-199, 275-299
R00330	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-58-12 P036-00/ /	ALL
R00330	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-58-12 P036-00/ /	ALL
R00331	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-58-12 P036-00/ /	ALL
R00331	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-58-12 P036-00/ /	ALL
R00332		YHLZD-30 DIODE-SLAT RTR ISOLATION	284T0112 09922	1	27-58-11 SHELF/E01/02	ALL
R00333		YHLZD-30 DIODE-IGNITION ISLN,L ENG	284T0112 09922	1	74-31-11 SHELF/E01/02	ALL
R00334		YHLZD-30 DIODE-IGNITION ISLN,R ENG	284T1612 09922	1	74-31-21 SHELF/E01/02	ALL
R00353		YHLZD-30 DIODE-ISLN,BAY C FWD DRIVE	284T0687 09922	1	25-53-14 P035-00/ /	ALL
R00354		YHLZD-30 DIODE-ISLN,BAY D AFT DRIVE	284T0687 09922	1	25-53-14 P035-00/ /	ALL
R00355		YHLZD-30 DIODE-ISLN,BAY D PDU CONT RIGHT	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00356		YHLZD-30 DIODE-ISLN,BAY D PDU CONT LEFT	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section R00300

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00366		YHLZD-30 DIODE-K1112 COIL ISLN	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00367		YHLZD-30 DIODE-K1113 COIL ISLN	284T3501 09922	1	25-53-13 P035-00/ /	150-199, 275-299
R00368		YHLZD-30 DIODE	233T4100 09922	1	26-18-11 P061-00/ /	ALL
R00369		YHLDZ-30 DIODE	233T4100 09922	1	26-18-21 P061-00/ /	ALL
R00372	1	YHLZD-30 DIODE-ISLN EEC OVHT L	284T0187 81205	1	30-21-11 P036-00/ /	ALL
R00372	2	YHLZD-9 DIODE-ISLN EEC OVHT L	284T0187 81205	1	30-21-11 P036-00/ /	ALL
R00373	1	YHLZD-30 DIODE-ISLN EEC OVHT R	284T0188 81205	1	30-21-11 P037-00/ /	ALL
R00373	2	YHLZD-9 DIODE-ISLN EEC OVHT R	284T0188 81205	1	30-21-11 P037-00/ /	ALL
R00375	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	36-11-61 P036-00/ /	050-099, 150-156, 162-166
R00375	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	36-11-61 P036-00/ /	050-099, 150-156, 162-166
R00376	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166
R00376	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166
R00377	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166
R00377	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	36-11-62 P037-00/ /	050-099, 150-156, 162-166
R00378	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	36-11-61 P036-00/ /	050-099, 150-156, 162-166
R00378	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	36-11-61 P036-00/ /	050-099, 150-156, 162-166
R00392		YHLZD-30 DIODE-ISOLATION	285T0019 09922	1	33-25-11 P019-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section R00300

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00393		YHLZD-30 DIODE-ISOLATION	285T0009 09922	1	33-25-11 P025-00/ /	050-099, 150-199
R00394		YHLZD-30 DIODE-ISOLATION	285T0009 09922	1	33-25-11 P025-00/ /	050-099, 150-199
R00395		YHLZD-30 DIODE-ISOLATION	285T0009 09922	1	33-25-11 P025-00/ /	050-099, 150-199
R00397	1	YHLZD-30 DIODE-ISOLATION	284T0188 09922	1	29-11-14 P037-00/ /	ALL
R00397	2	YHLZD-9 DIODE-ISOLATION	284T0188 09922	1	29-11-14 P037-00/ /	ALL
R00398	1	YHLZD-30 DIODE-ISOLATION	284T0188 09922	1	29-11-14 P037-00/ /	ALL
R00398	2	YHLZD-9 DIODE-ISOLATION	284T0188 09922	1	29-11-14 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section R00300
Page 4 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00409		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-11 SHELF/E02/05	050-099, 150-199
R00410		YHLZD-9 DIODE-BLOCKING	284T1625 81205	1	23-31-11 SHELF/E02/05	050-099, 150-199
R00411		YHLZD-9 DIODE-BLOCKING	284T1625 81205	1	23-31-11 SHELF/E02/05	050-099, 150-199
R00412		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-11 SHELF/E02/05	050-099, 150-199
R00413		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
R00414		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-13 SHELF/E02/05	051-099, 151-153
R00415		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
R00416		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-13 SHELF/E02/05	051-099, 151-153
R00417		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
R00418		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-13 SHELF/E02/05	051-099, 151-153
R00428	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-58-11 P036-00/ /	ALL
R00428	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-58-11 P036-00/ /	ALL
R00429		YHLZD-30 DIODE-ISOLATION	285T0009 09922	1	33-25-11 P025-00/ /	050-099, 150-199
R00430		YHLZD-30 DIODE-ISOLATION	285T0009 09922	1	33-25-11 P025-00/ /	050-099, 150-199
R00431		YHLZD-9 DIODE	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
R00432		YHLZD-9 DIODE	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
R00433		YHLZD-9 DIODE	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199

EQUIPMENT LIST

D280T132

Section R00400

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00434		YHLZD-9 DIODE	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
R00435	9	YHLZD-30 DIODE-ISOLATION (SB 34-0091)	285T0006 09922	1	34-45-13 P050-00/ /	150-152, 275-276
R00435	1	YHLZD-9 DIODE-ISOLATION	285T0006 09922	1	34-45-13 P050-00/ /	050-099, 153-156, 162-166
R00435	2	YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	34-45-13 P050-00/ /	050-099, 153-156, 162-166
R00436	9	YHLZD-30 DIODE-ISOLATION (SB 34-0091)	285T0006 09922	1	34-45-13 P050-00/ /	150-152, 275-276
R00436	1	YHLZD-9 DIODE-ISOLATION	285T0006 09922	1	34-45-13 P050-00/ /	050-099, 153-156, 162-166
R00436	2	YHLZD-30 DIODE-ISOLATION	285T0006 09922	1	34-45-13 P050-00/ /	050-099, 153-156, 162-166
R00437		YHLZD-9 DIODE	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
R00438		YHLZD-9 DIODE	284T0125 81205	1	23-31-13 SHELF/E02/05	050-099, 150-199
R00441	1	YHLZD-30 DIODE-BLOCKING,JETTISON L	284T0187 81205	1	28-31-12 P036-00/ /	050-099, 155-199, 276-299
R00441	2	YHLZD-9 DIODE-BLOCKING,JETTISON L	284T0187 81205	1	28-31-12 P036-00/ /	050-099, 155-199, 276-299
R00442	1	YHLZD-30 DIODE-BLOCKING,JETTISON R	284T0188 81205	1	28-31-12 P037-00/ /	050-099, 155-199, 276-299
R00442	2	YHLZD-9 DIODE-BLOCKING,JETTISON R	284T0188 81205	1	28-31-12 P037-00/ /	050-099, 155-199, 276-299
R00445		YHLZD-30 DIODE-L,C EFIS SG ACT PORT SEL ISOL	284T0123 09922	1	34-61-25 SHELF/E02/03	ALL
R00446		YHLZD-30 DIODE-32K BLOCKING	284T0130 81205	1	21-51-12 SHELF/E03/01	ALL
R00447	1	YHLZD-30 DIODE-32K ALT SUPPR	284T0188 09922	1	21-61-81 P037-00/ /	ALL
R00447	2	YHLZD-9 DIODE-32K ALT SUPPR	284T0188 09922	1	21-61-81 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section R00400

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00448	9	YHLZD-30 DIODE ASSY-ISOLATION (SB 30-0017)	284T0142 81205	1	30-81-01 P033-00/ /	150-154
R00448	1	YHLZD-30 DIODE ASSY-ISOLATION	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00448	2	YHLZD-9 DIODE ASSY-ISOLATION	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00449	9	YHLZD-30 DIODE ASSY-WING ISO, L (SB 30-0017)	284T0142 81205	1	30-81-01 P033-00/ /	150-154
R00449	1	YHLZD-30 DIODE ASSY-WING ISO, L	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00449	2	YHLZD-9 DIODE ASSY-WING ISO, L	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00450	9	YHLZD-30 DIODE ASSY-WING ISO, R (SB 30-0017)	284T0142 81205	1	30-81-01 P033-00/ /	150-154
R00450	1	YHLZD-30 DIODE ASSY-WING ISO, R	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00450	2	YHLZD-9 DIODE ASSY-WING ISO, R	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00451	9	YHLZD-30 DIODE ASSY-COWL ISO, L (SB 30-0017)	284T0142 81205	1	30-81-01 P033-00/ /	150-154
R00451	1	YHLZD-30 DIODE ASSY-COWL ISO, L	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00451	2	YHLZD-9 DIODE ASSY-COWL ISO, L	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00452	9	YHLZD-30 DIODE ASSY-COWL ISO, R (SB 30-0017)	284T0142 81205	1	30-81-01 P033-00/ /	150-154
R00452	1	YHLZD-30 DIODE ASSY-COWL ISO, R	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00452	2	YHLZD-9 DIODE ASSY-COWL ISO, R	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00453	9	YHLZD-30 DIO ASSY-L WING ICING DETR (SB 30-0017)	284T0142 81205	1	30-81-01 P033-00/ /	150-154
R00453	1	YHLZD-30 DIODE ASSY-L WING ICING DETECTOR	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199

EQUIPMENT LIST

D280T132

Section R00400

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00453	2	YHLZD-9 DIODE ASSY-L WING ICING DETECTOR	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00454	9	YHLZD-30 DIO ASSY-R WING ICING DETR (SB 30-0017)	284T0142 81205	1	30-81-01 P033-00/ /	150-154
R00454	1	YHLZD-30 DIODE ASSY-R WING ICING DETECTOR	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00454	2	YHLZD-9 DIODE ASSY-R WING ICING DETECTOR	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00455	9	YHLZD-30 DIODE ASSY-TEST (SB 30-0017)	284T0142 81205	1	30-11-01 P033-00/ /	150-154
R00455	1	YHLZD-30 DIODE ASSY-TEST	284T0189 81205	1	30-11-01 P033-00/ /	050-099, 155-199
R00455	2	YHLZD-9 DIODE ASSY-TEST	284T0189 81205	1	30-11-01 P033-00/ /	050-099, 155-199
R00456		YHLZD-30 DIODE-K2068 RELAY ISOL	284T0123 09922	1	34-61-26 SHELF/E02/03	ALL
R00457		YHLZD-30 DIODE-K2069 RELAY ISOL	284T0123 09922	1	34-61-26 SHELF/E02/03	ALL
R00458		YHLZD-30 DIODE-K2066 RELAY ISOL	284T0123 09922	1	34-61-26 SHELF/E02/03	ALL
R00459		YHLZD-30 DIODE-K2067 RELAY ISOL	284T0122 09922	1	34-61-16 SHELF/E02/02	ALL
R00460		YHLZD-30 DIODE-K2065 RELAY ISOL	284T0122 09922	1	34-61-16 SHELF/E02/02	ALL
R00461		YHLZD-30 DIODE-K757 RELAY ISOL	284T0122 09922	1	34-61-15 SHELF/E02/02	ALL
R00462	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00462	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00463	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00463	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section R00400

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00464	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00464	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00465	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00465	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00466	1	YHLZD-30 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00466	2	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199
R00467		YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-21 P036-00/ /	050-099, 162-199
R00468	9	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-41 P036-00/ /	150, 152-157
R00468		YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-21 P036-00/ /	050-099, 162-199
R00469	9	YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-41 P036-00/ /	150, 152-157
R00469		YHLZD-9 DIODE-BLOCKING	284T0187 81205	1	21-66-21 P036-00/ /	050-099, 162-199
R00470	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-26-11 P037-00/ /	050-099, 155-199, 276-299
R00470	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	21-26-11 P037-00/ /	050-099, 155-199, 276-299
R00471	1	YHLZD-30 DIODE-BLOCKING	284T0188 81205	1	21-26-11 P037-00/ /	050-099, 155-199, 276-299
R00471	2	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	21-26-11 P037-00/ /	050-099, 155-199, 276-299
R00472	9	YHLZD-9 DIODE-BLOCKING (SB 23-0032R1)	284T0125 81205	1	23-51-11 SHELF/E02/05	150-152
R00472		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-51-11 SHELF/E02/05	050-099, 153-199, 275-299

EQUIPMENT LIST

D280T132

Section R00400

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00473	9	YHLZD-9 DIODE-BLOCKING (SB 23-0032R1)	284T0125 81205	1	23-51-11 SHELF/E02/05	150-152
R00473		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-51-11 SHELF/E02/05	050-099, 153-199, 275-299
R00474	9	YHLZD-9 DIODE-BLOCKING (SB 23-0032R1)	284T0125 81205	1	23-51-41 SHELF/E02/05	150-152
R00474		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-51-41 SHELF/E02/05	050-099, 153-199, 275-299
R00475		YHLZD-9 DIODE-BLOCKING	284T0125 81205	1	23-31-11 SHELF/E02/05	275
R00476	9	YHLZD-30 DIODE-L AUTO ISOLATION (SB 30-0017)	284T0189 81205	1	30-21-11 P033-00/ /	150-154
R00476	1	YHLZD-30 DIODE-L AUTO ISOLATION	284T0189 81205	1	30-21-11 P033-00/ /	050-099, 155-199
R00476	2	YHLZD-9 DIODE-L AUTO ISOLATION	284T0189 81205	1	30-21-11 P033-00/ /	050-099, 155-199
R00477	9	YHLZD-30 DIODE-R AUTO ISOLATION (SB 30-0017)	284T0189 81205	1	30-21-11 P033-00/ /	150-154
R00477	1	YHLZD-30 DIODE-R AUTO ISOLATION	284T0189 81205	1	30-21-11 P033-00/ /	050-099, 155-199
R00477	2	YHLZD-9 DIODE-R AUTO ISOLATION	284T0189 81205	1	30-21-11 P033-00/ /	050-099, 155-199
R00478	9	YHLZD-30 DIODE-BLOCKING,CGO GND EXH (SB 21-0086)	284T0188 09922	1	21-26-31 P037-00/ /	150-154, 275
R00478	8	YHLZD-9 DIODE-BLOCKING,CGO GND EXH (SB 21-0086)	284T0188 09922	1	21-26-31 P037-00/ /	150-154, 275
R00478	1	YHLZD-30 DIODE-BLOCKING,CGO GND EXH	284T0188 09922	1	21-26-31 P037-00/ /	050-099, 155-199, 276-299
R00478	2	YHLZD-9 DIODE-BLOCKING,CGO GND EXH	284T0188 09922	1	21-26-31 P037-00/ /	050-099, 155-199, 276-299
R00479	9	YHLZD-30 DIODE-BLOCKING,CARGO HT (SB 21-0086)	284T0188 09922	1	21-43-11 P037-00/ /	150-154, 275
R00479	8	YHLZD-9 DIODE-BLOCKING,CARGO HT (SB 21-0086)	284T0188 09922	1	21-43-11 P037-00/ /	150-154, 275

EQUIPMENT LIST

D280T132

Section R00400

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00479	1	YHLZD-30 DIODE-BLOCKING,CARGO HT	284T0188 09922	1	21-43-11 P037-00/ /	050-099, 155-199, 276-299
R00479	2	YHLZD-9 DIODE-BLOCKING,CARGO HT	284T0188 09922	1	21-43-11 P037-00/ /	050-099, 155-199, 276-299
R00481	9	YHLZD-30 DIODE ASSY-COWL ICING ISO, L(SB 30-0017)	284T0189 81205	1	30-81-01 P033-00/ /	150-154
R00481	1	YHLZD-30 DIODE ASSY-COWL ICING ISO, L	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00481	2	YHLZD-9 DIODE ASSY-COWL ICING ISO, L	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00482	9	YHLZD-30 DIODE ASSY-COWL ICING ISO, R(SB 30-0017)	284T0189 81205	1	30-81-01 P033-00/ /	150-154
R00482	1	YHLZD-30 DIODE ASSY-COWL ICING ISO, R	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00482	2	YHLZD-9 DIODE ASSY-COWL ICING ISO, R	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00483	9	YHLZD-30 DIODE ASSY-WING ICING ISO (SB 30-0017)	284T0189 81205	1	30-81-01 P033-00/ /	150-154
R00483	1	YHLZD-30 DIODE ASSY-WING ICING ISO	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00483	2	YHLZD-9 DIODE ASSY-WING ICING ISO	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00486	9	YHLZD-30 DIODE-BLOCKING PRV IND,L (SB 36-0029)	284T0187 81205	1	36-11-61 P036-00/ /	275-276
R00486	1	YHLZD-30 DIODE-BLOCKING PRV IND,L	284T0187 81205	1	36-11-61 P036-00/ /	156, 166
R00486	2	YHLZD-9 DIODE-BLOCKING PRV IND,L	284T0187 81205	1	36-11-61 P036-00/ /	156, 166
R00487	9	YHLZD-30 DIODE-BLOCKING PRV IND,R (SB 36-0029)	284T0188 81205	1	36-11-62 P037-00/ /	275-276
R00487	1	YHLZD-30 DIODE-BLOCKING PRV IND,R	284T0188 81205	1	36-11-62 P037-00/ /	156, 166
R00487	2	YHLZD-9 DIODE-BLOCKING PRV IND,R	284T0188 81205	1	36-11-62 P037-00/ /	156, 166

EQUIPMENT LIST

D280T132

Section R00400

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00488		YHLZD-30 DIODE-ISOLATION	284T0125 09922	1	23-22-12 SHELF/E02/05	167-199
R00490	1	YHLZD-30 DIODE-WING ISO,L	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00490	2	YHLZD-9 DIODE-WING ISO,L	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00491	1	YHLZD-30 DIODE-WING ISO,R	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00491	2	YHLZD-9 DIODE-WING ISO,R	284T0189 81205	1	30-81-01 P033-00/ /	050-099, 155-199
R00499		YHLZD-30 DIODE-CHIME ISOLATION	284T0125 09922	1	23-42-11 SHELF/E02/05	050-099, 162-199

EQUIPMENT LIST

D280T132

Section R00400
Page 8 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00503		26416 DIMMER-LIGHT,CAPT CHART	233T8200 95266	1	33-14-21 P007-00/ /	050-099
R00503		26416 DIMMER-LIGHT,CAPT CHART	233T2100 95266	1	33-14-21 P007-00/ /	150-199, 275-299
R00504		26416 DIMMER-LIGHT,F/O CHART	233T8200 95266	1	33-14-21 P007-00/ /	050-099
R00504		26416 DIMMER-LIGHT,F/O CHART	233T7100 95266	1	33-14-21 P007-00/ /	150-199, 275-299
R00505		26405 RHEOSTAT-MAP LIGHT,CAPT	233T8200 95266	1	33-14-11 P007-00/ /	050-099
R00505		26405 RHEOSTAT-MAP LIGHT,CAPT	233T2100 95266	1	33-14-11 P007-00/ /	150-199, 275-299
R00506		26405 RHEOSTAT-MAP LIGHT,F/O	233T8200 95266	1	33-14-11 P007-00/ /	ALL
R00507		WB04060 POTENTIOMETER-PNL FLDT CONT,CAPT & CTR	233T8200 55578	1	33-11-11 P007-00/ /	ALL
R00508		WB04060 POTENTIOMETER-INSTR PNL FLDT CONTROL,F/O	233T8200 55578	1	33-11-11 P007-00/ /	ALL
R00511	2	WA03923 POTENTIOMETER-CAPT INSTR & PNL LT CONT	233T8200 55578	1	33-13-11 P007-00/ /	ALL
R00512	2	WA03923 POTENTIOMETER-F/O INSTR & PNL LT CONT	233T8200 55578	1	33-13-13 P007-00/ /	ALL
R00515		S210T130-24 SELECTOR-ZONE TEMPERATURE,FLIGHT DECK	233T3100 81205	1	21-61-11 P005-00/ /	ALL
R00516		10-62091-1 SELECTOR-ZONE TEMPERATURE,FORWARD	233T3100 81205	1	21-61-21 P005-00/ /	ALL
R00517		S210T130-24 SELECTOR-ZONE TEMPERATURE,AFT	233T3100 81205	1	21-61-31 P005-00/ /	ALL
R00525		YHLZR-16 RESISTOR-BURNDY BLOCK	284T1614 09922	1	34-43-11 SHELF/E01/04	ALL
R00526		YHLZR-16 RESISTOR-BURNDY BLOCK	284T1614 09922	1	34-43-11 SHELF/E01/04	ALL
R00529		YHLZR-16 RESISTOR-BURNDY BLOCK	284T1614 09922	1	34-43-21 SHELF/E01/04	ALL

EQUIPMENT LIST

D280T132

Section R00500

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00530		YHLZR-16 RESISTOR-BURNDY BLOCK	284T1614 09922	1	34-43-21 SHELF/E01/04	ALL
R00531		YHLZR-17 RESISTOR ASSY-BTB INHIBIT PULLUP	284T0175 09922	1	24-41-11 P034-00/ /	ALL
R00532		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-18 SHELF/E02/03	050-099, 150-199, 275-276
R00532		YHLZR-10 RESISTOR	284T1623 09922	1	31-31-18 SHELF/E02/03	277-299
R00533		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-18 SHELF/E02/03	ALL
R00534		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-18 SHELF/E02/03	050-099, 150-199, 275-276
R00534		YHLZR-10 RESISTOR	284T1623 09922	1	31-31-18 SHELF/E02/03	277-299
R00535		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-18 SHELF/E02/03	050-099, 150-199, 275-276
R00535		YHLZR-10 RESISTOR	284T1623 09922	1	31-31-18 SHELF/E02/03	277-299
R00536		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-18 SHELF/E02/03	050-099, 150-199, 275-276
R00536		YHLZR-10 RESISTOR	284T1623 09922	1	31-31-18 SHELF/E02/03	277-299
R00537		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-18 SHELF/E02/03	050-099, 150-199, 275-276
R00537		YHLZR-10 RESISTOR	284T1623 09922	1	31-31-18 SHELF/E02/03	277-299
R00538		285T0442-1 SUPPRESSOR BLOCK-PTT	284T0125 81205	1	23-51-14 SHELF/E02/05	ALL
R00539		285T0442-1 SUPPRESSOR BLOCK-PTT	284T0125 81205	1	23-51-14 SHELF/E02/05	ALL
R00540		285T0442-1 SUPPRESSOR BLOCK-PTT	284T0125 81205	1	23-51-14 SHELF/E02/05	ALL
R00541		285T0442-1 SUPPRESSOR BLOCK-PTT	284T0125 81205	1	23-51-14 SHELF/E02/05	ALL

EQUIPMENT LIST

D280T132

Section R00500

Page 2

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00542		285T0442-1 SUPPRESSOR BLOCK-PTT	284T0125 81205	1	23-51-14 SHELF/E02/05	ALL
R00543		YHLZR-29 RESISTOR-EGT LOAD	284T1067 09922	1	49-71-11 SHELF/E08/00	ALL
R00550		YHLZR-29 RESISTOR-TACHOMETER LOAD	284T1067 09922	1	49-73-11 SHELF/E08/00	ALL
R00556		RER70F30R1R RESISTOR-AISLE STAND STBY -30 OHMS,20W	284T0997 81205	1	33-11-13 P006-00/ /	ALL
R00557		285T0442-2 RESISTOR-BLOCK ASSY,CAPT'S -287 KOHMS	233T2402 81205	1	33-13-11 P001-00/ /	ALL
R00558		285T0442-3 RESISTOR-BLOCK ASSY,CAPT'S -210 KOHMS	233T2402 81205	1	33-13-11 P001-00/ /	ALL
R00559		285T0442-2 RESISTOR-BLOCK ASSY,STBY CAB PR & FUEL	233T4403 81205	1	33-13-16 P005-00/ /	ALL
R00560		285T0442-3 RESISTOR-BLOCK ASSY,STBY CAB PR & FUEL	233T4403 81205	1	33-13-16 P005-00/ /	ALL
R00561	1	YHLZD-30 DIODE BLOCKING	284T0187 09922	1	21-58-16 P036-00/ /	ALL
R00561	2	YHLZD-9 DIODE BLOCKING	284T0187 09922	1	21-58-16 P036-00/ /	ALL
R00563	1	YHLZD-30 DIODE BLOCKING	284T0187 09922	1	21-58-16 P036-00/ /	ALL
R00563	2	YHLZD-9 DIODE BLOCKING	284T0187 09922	1	21-58-16 P036-00/ /	ALL
R00564	1	YHLZD-30 DIODE BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	ALL
R00564	2	YHLZD-9 DIODE BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	ALL
R00565	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	25-33-11 P037-00/ /	050-099, 150-199, 277-299
R00565	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	275-276
R00565	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	25-33-11 P037-00/ /	050-099, 150-199, 277-299

EQUIPMENT LIST

D280T132

Section R00500

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00565	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	275-276
R00566	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	25-33-11 P037-00/ /	050-099, 150-199, 277-299
R00566	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	275-276
R00566	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	25-33-11 P037-00/ /	050-099, 150-199, 277-299
R00566	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	275-276
R00570		YHLZR-17 RESISTOR-BLOCK	284T0189 09922	1	27-62-11 P033-00/ /	ALL
R00571		10-62091-1 SELECTOR-ZONE TEMPERATURE MID	233T3236 81205	1	21-61-41 P005-00/ /	ALL
R00574		YHLZD-33 DIODE	285T0006 09922	1	73-21-19 P050-00/ /	ALL
R00575		YHLZD-33 DIODE	285T0006 09922	1	73-21-19 P050-00/ /	ALL
R00576		YHLZD-33 DIODE	284T0175 09922	1	73-21-19 P034-00/ /	ALL
R00577		YHLZD-33 DIODE	284T0175 09922	1	73-21-19 P034-00/ /	ALL
R00579	1	YHLZR-44 RESISTOR	284T0123 81205	1	31-31-19 SHELF/E02/03	ALL
R00579	2	69B40800-38 RESISTOR	284T0123 81205	1	31-31-19 SHELF/E02/03	ALL
R00580	1	YHLZR-44 RESISTOR	284T0123 81205	1	31-31-19 SHELF/E02/03	ALL
R00580	2	69B40800-38 RESISTOR	284T0123 81205	1	31-31-19 SHELF/E02/03	ALL
R00581	1	YHLZR-44 RESISTOR	284T0123 81205	1	31-31-19 SHELF/E02/03	ALL
R00581	2	69B40800-38 RESISTOR	284T0123 81205	1	31-31-19 SHELF/E02/03	ALL

EQUIPMENT LIST

D280T132

Section R00500

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00582	1	YHLZR-44 RESISTOR	284T0123 81205	1	31-31-19 SHELF/E02/03	ALL
R00582	2	69B40800-38 RESISTOR	284T0123 81205	1	31-31-19 SHELF/E02/03	ALL
R00583	1	YHLZR-44 RESISTOR	284T0123 81205	1	31-31-21 SHELF/E02/03	ALL
R00583	2	69B40800-38 RESISTOR	284T0123 81205	1	31-31-21 SHELF/E02/03	ALL
R00584	1	YHLZR-44 RESISTOR	284T0123 81205	1	31-31-21 SHELF/E02/03	ALL
R00584	2	69B40800-38 RESISTOR	284T0123 81205	1	31-31-21 SHELF/E02/03	ALL
R00585	1	YHLZR-44 RESISTOR	284T0123 81205	1	31-31-21 SHELF/E02/03	ALL
R00585	2	69B40800-38 RESISTOR	284T0123 81205	1	31-31-21 SHELF/E02/03	ALL
R00586	1	YHLZR-44 RESISTOR	284T0123 81205	1	31-31-21 SHELF/E02/03	ALL
R00586	2	69B40800-38 RESISTOR	284T0123 81205	1	31-31-21 SHELF/E02/03	ALL
R00587		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-26 SHELF/E02/03	050-099, 150-199, 275-276
R00587		YHLZR-10 RESISTOR	284T1623 09922	1	31-31-26 SHELF/E02/03	277-299
R00588		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-26 SHELF/E02/03	ALL
R00590		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-21 SHELF/E02/03	050-099, 150-199, 275-276
R00590		YHLZR-10 RESISTOR	284T1623 09922	1	31-31-21 SHELF/E02/03	277-299
R00591		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-21 SHELF/E02/03	050-099, 150-199, 275-276
R00591		YHLZR-10 RESISTOR	284T1623 09922	1	31-31-21 SHELF/E02/03	277-299

EQUIPMENT LIST

D280T132

Section R00500

Page 5 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00600	1	RWR78S1000FS RESISTOR-TORQUE MOTOR LOAD	284T0187	1	21-51-11 P036-00/ /	050-099
R00600	2	RWR78S1000FR RESISTOR-TORQUE MOTOR LOAD	284T0187	1	21-51-11 P036-00/ /	050-099
R00602	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	150-199, 275-299
R00602	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	150-199, 275-299
R00603	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	150-199, 275-299
R00603	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	150-199, 275-299
R00604	1	YHLZD-30 DIODE-BLOCKING	284T0187 09922	1	21-58-16 P036-00/ /	150-199, 275-299
R00604	2	YHLZD-9 DIODE-BLOCKING	284T0187 09922	1	21-58-16 P036-00/ /	150-199, 275-299
R00605	1	YHLZD-30 DIODE-BLOCKING	284T0187 09922	1	21-58-16 P036-00/ /	150-199, 275-299
R00605	2	YHLZD-9 DIODE-BLOCKING	284T0187 09922	1	21-58-16 P036-00/ /	150-199, 275-299
R00607		YHLZD-30 DIODE-ISOLATION	284T0123 81205	1	31-51-41 SHELF/E02/03	150-199, 275-276
R00607		YHLZD-30 DIODE-ISOLATION	284T1623 81205	1	31-51-41 SHELF/E02/03	277-299
R00608		YHLZD-30 DIODE-ISOLATION	284T0123 81205	1	31-51-41 SHELF/E02/03	150-199, 275-299
R00609		YHLZD-29 DIODE-AUTOBRAKE SUPPRESSION	285T0000 09922	1	32-42-11 P061-00/ /	ALL
R00630	1	YHLZD-30 DIODE-AUX FWD ZONE (INOP)	284T0187 81205	1	21-61-61 P036-00/ /	ALL
R00630	2	YHLZD-9 DIODE-AUX FWD ZONE (INOP)	284T0187 81205	1	21-61-61 P036-00/ /	ALL
R00633	1	YHLZD-30 DIODE-AUX MID ZONE (INOP)	284T0187 81205	1	21-61-71 P036-00/ /	050-099, 275-299

EQUIPMENT LIST

D280T132

Section R00600

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00633	1	YHLZD-30 DIODE-AUX MID ZONE (INOP)	284T0188 81205	1	21-61-71 P036-00/ /	150-199
R00633	2	YHLZD-9 DIODE-AUX MID ZONE (INOP)	284T0187 81205	1	21-61-71 P036-00/ /	050-099, 275-299
R00633	2	YHLZD-9 DIODE-AUX MID ZONE (INOP)	284T0188 81205	1	21-61-71 P036-00/ /	150-199
R00634		10-62091-1 SELECTOR-FWD CARGO TEMP	233T3100 81205	1	21-61-81 P005-00/ /	ALL
R00637		YHLZD-9 DIODE-FWD CARGO INOP/FAULT ISO 3	284T1615 81205	1	21-51-11 SHELF/E01/05	150-199, 275-299
R00637	1	YHLZD-9 DIODE-FWD CARGO INOP/FAULT ISO 3	284T0115 81205	1	21-51-11 SHELF/E01/05	050-099
R00637	2	YHLZD-30 DIODE-FWD CARGO INOP/FAULT ISO 3	284T0115 81205	1	21-51-11 SHELF/E01/05	050-099
R00638		YHLZD-9 DIODE-FWD CARGO INOP	284T1615 81205	1	21-51-11 SHELF/E01/05	150-199, 275-299
R00638	1	YHLZD-9 DIODE-FWD CARGO INOP	284T0115 81205	1	21-51-11 SHELF/E01/05	050-099
R00638	2	YHLZD-30 DIODE-FWD CARGO INOP	284T0115 81205	1	21-51-11 SHELF/E01/05	050-099
R00641	9	YHLZD-30 DIODE-ISOLATION (SB 34-0091)	284T0115 09922	1	34-45-12 SHELF/E01/05	150-152
R00641	9	YHLZD-30 DIODE-ISOLATION (MTO-340961)	284T0115 09922	1	34-45-12 SHELF/E01/05	153-154
R00641	9	YHLZD-30 DIODE-ISOLATION (MTO-340961)	CUSTOMER 09922	1	34-45-12 SHELF/E01/05	155-199, 275-299
R00642	9	YHLZD-30 DIODE-ISOLATION (SB 34-0091)	284T0115 09922	1	34-45-12 SHELF/E01/05	150-152
R00642	9	YHLZD-30 DIODE-ISOLATION (SB 34-0133)	284T0115 09922	1	34-45-12 SHELF/E01/05	153-154
R00642	9	YHLZD-30 DIODE-ISOLATION (MTO-340961)	CUSTOMER 09922	1	34-45-12 SHELF/E01/05	155-199, 275-299
R00643	9	YHLZD-30 DIODE-ISOLATION (SB 34-0091)	284T0115 09922	1	34-45-12 SHELF/E01/05	150-152

EQUIPMENT LIST

D280T132

Section R00600

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00643	9	YHLZD-30 DIODE-ISOLATION (MTO-340961)	284T0115 09922	1	34-45-12 SHELF/E01/05	153-154
R00643		YHLZD-30 DIODE-ISOLATION	284T0115 09922	1	34-45-12 SHELF/E01/05	050-099, 150-152, 155-199, 275-299
R00655		YHLZD-30 DIODE-ISOLATION	284T0125 81205	1	23-31-12 SHELF/E02/05	050-099, 150-199
R00656		69B40800-78 RESISTOR-CGO DUCT TEMP	284T0188 81205	1	21-61-81 P037-00/ /	050-099, 151-199, 275-299
R00657		69B40800-79 RESISTOR-L PACK TEMP	284T0188 81205	1	21-61-81 P037-00/ /	050-099, 151-199, 275-299
R00658		RLR07C51R1FR RESISTOR	96906	1	23-34-15 MISC/ /	050-099, 162-199
R00660		RER75F1000R RESISTOR-TORQUE MOTOR LOAD	284T0187 81205	1	21-51-11 P036-00/ /	050-099
R00664	9	YHLZD-30 DIODE-BLOCKING (SB 21-0106)	284T0188 09922	1	21-58-16 P037-00/ /	153-154
R00664	8	YHLZD-9 DIODE-BLOCKING (SB 21-0106)	284T0188 09922	1	21-58-16 P037-00/ /	153-154
R00664	1	YHLZD-30 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	050-099, 155-199, 277-299
R00664	2	YHLZD-9 DIODE-BLOCKING	284T0188 09922	1	21-58-16 P037-00/ /	050-099, 155-199, 277-299
R00666		YHLZD-30 DIODE-LEFT FMC CREW ALERTNESS ISOL	284T0122 09922	1	34-61-27 SHELF/E02/02	157, 167-199, 277- 299
R00667		YHLZD-30 DIODE-RIGHT FMC CREW ALERTNESS ISOL	284T0123 09922	1	34-61-27 SHELF/E02/03	157, 167-199, 277- 299
R00668		YHLZD-30 DIODE-CREW ALERTNESS LEFT VHF ISOL	284T0125 09922	1	34-61-17 SHELF/E02/05	157, 167-199, 277- 299
R00669		YHLZD-30 DIODE-CREW ALERTNESS RIGHT VHF ISOL	284T0125 09922	1	34-61-17 SHELF/E02/05	157, 167-199, 277- 299
R00670		YHLZD-30 DIODE-CREW ALERTNESS CENTER VHF ISOL	284T0125 09922	1	34-61-17 SHELF/E02/05	157, 167-199, 277- 299
R00671		YHLZD-30 DIODE-CREW ALERTNESS LEFT HF ISOL	284T0125 09922	1	34-61-17 SHELF/E02/05	157, 167-199, 277- 299

EQUIPMENT LIST

D280T132

Section R00600

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00672		YHLZD-30 DIODE-CREW ALERTNESS RIGHT HF ISOL	284T0125 09922	1	34-61-17 SHELF/E02/05	157, 167-199, 277-299
R00673	9	YHLZD-30 DIODE-FUEL JETT ISOL (SB 28-0030)	287T4163 09922	1	28-31-12 P061-00/ /	051-099
R00673		YHLZD-30 DIODE-FUEL JETT ISOL	287T4163 09922	1	28-31-12 P061-00/ /	050, 155-199, 277-299
R00674		YHLZR-15 RESISTOR-L WING PULL-UP	284T0189 81205	1	30-81-11 P033-00/ /	050-099, 155-199
R00675		YHLZR-15 RESISTOR-R WING PULL-UP	284T0189 81205	1	30-81-11 P033-00/ /	050-099, 155-199
R00681		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-17 SHELF/E02/03	155-157, 164-199, 277-299
R00682		YHLZR-10 RESISTOR	284T0123 09922	1	31-31-17 SHELF/E02/03	155-157, 164-199, 277-299
R00686	9	YHLZD-9 DIODE-BLOCKING (SB 21-0103)	284T3601 81205	1	21-23-11 P036-00/ /	150-199, 275-278
R00690	9	YHLZR-17 SYS 1 EICAS SIMULATION RES (SB 38-0035)	00000000 09922	1	38-32-11 P049-00/ /	275-276
R00691	9	YHLZR-17 SYS 2 EICAS SIMULATION RES (SB 38-0035)	00000000 09922	1	38-32-11 P049-00/ /	275-276
R00692		YHLZD-30 DIODE-FMC SW ISOLATION	284T1623 09922	1	31-31-13 SHELF/E02/03	280-299
R00696	9	YHLZD-30 DIODE-L ENG HIV (SB 78-0051FAA)	284T0189 09922	1	78-36-11 P033-00/ /	050-099, 150-156, 162-166, 275-276
R00696		YHLZD-30 DIODE-L ENG HIV (RR 41033-23)	284T0189 09922	1	78-36-11 P033-00/ /	157
R00696		YHLZD-30 DIODE-L ENG HIV (RR 41033-24)	284T0189 09922	1	78-36-11 P033-00/ /	167-199
R00696		YHLZD-30 DIODE-L ENG HIV (RR 41034-20)	284T0189 09922	1	78-36-11 P033-00/ /	277-278
R00696		YHLZD-30 DIODE-L ENG HIV (RR 41034-21)	284T0189 09922	1	78-36-11 P033-00/ /	280-299
R00697	9	YHLZD-30 DIODE-R ENG HIV (SB 78-0051FAA)	284T0189 09922	1	78-36-21 P033-00/ /	050-099, 150-156, 162-166, 275-276

EQUIPMENT LIST

D280T132

Section R00600

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00697		YHLZD-30 DIODE-R ENG HIV (RR 41033-23)	284T0189 09922	1	78-36-21 P033-00/ /	157
R00697		YHLZD-30 DIODE-R ENG HIV (RR 41033-24)	284T0189 09922	1	78-36-21 P033-00/ /	167-199
R00697		YHLZD-30 DIODE-R ENG HIV (RR 41034-20)	284T0189 09922	1	78-36-21 P033-00/ /	277-278
R00697		YHLZD-30 DIODE-R ENG HIV (RR 41034-21)	284T0189 09922	1	78-36-21 P033-00/ /	280-299
R00699	9	YHLZD-30 DIODE-L FMC CREW ALERT ISOL (SB 34-0131)	284T0122 09922	1	34-61-27 SHELF/E02/02	277-299

EQUIPMENT LIST

D280T132

Section R00600
Page 5 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00700	9	YHLZD-30 DIODE-HIV PRESS, L ENG (SB 78-0062)	284T0189 81205	1	78-36-11 P033-00/ /	ALL
R00700	8	YHLZD-9 DIODE-HIV PRESS, L ENG (SB 78-0062)	284T0189 09922	1	78-36-11 P033-00/ /	ALL
R00701	9	YHLZD-30 DIODE-HIV PRESS, R ENG (SB 78-0062)	284T0189 81205	1	78-36-21 P033-00/ /	ALL
R00701	8	YHLZD-9 DIODE-HIV PRESS, R ENG (SB 78-0062)	284T0189 09922	1	78-36-21 P033-00/ /	ALL
R00702	9	1N5557 DIODE-LH SSL, L ENG (SB 78-0062)	284T0189 81205	1	78-34-11 P033-00/ /	ALL
R00703	9	1N5557 DIODE-LH SSL, R ENG (SB 78-0062)	284T0189 81205	1	78-34-21 P033-00/ /	ALL
R00704	9	1N5557 DIODE-RH SSL, L ENG (SB 78-0062)	284T0189 81205	1	78-34-11 P033-00/ /	ALL
R00705	9	1N5557 DIODE-RH SSL, R ENG (SB 78-0062)	284T0189 81205	1	78-34-21 P033-00/ /	ALL
R00734	9	YHLZD-30 DIODE-CONT IGN ISLN (SB 73-0044)	284T3601 09922	1	73-21-19 P036-00/ /	275-299
R00735	9	YHLZD-30 DIODE-CONT IGN ISLN (SB 73-0044)	284T3701 09922	1	73-21-19 P037-00/ /	275-299
R00736	9	YHLZD-30 DIODE-TAI ISLN (SB 73-0044)	284T3601 09922	1	73-21-19 P036-00/ /	275-299
R00737	9	YHLZD-30 DIODE-TAI ISLN (SB 73-0044)	284T3701 09922	1	73-21-19 P037-00/ /	275-299

EQUIPMENT LIST

D280T132

Section R00700

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R00824	9	YHLZD-33 DIODE- APU GEN OFF ISLN (SB 24-0103)	287T4163 09922	1	24-27-41 P061-00/ /	050-099, 150-199, 275-278
R00834		YHLZD-30 DIODE ISOLATION	285T0019 09922	1	33-24-11 P019-00/ /	278
R00835		YHLZD-30 DIODE ISOLATION	285T0019 09922	1	33-24-11 P019-00/ /	278
R00841	9	YHLZD-33 DIODE-SLAT ASYM ISOLATION (SB 27A0140)	00000TBD 09922	1	27-81-21 SHELF/E01/0002	150-199, 275-299
R00842	9	YHLZD-33 DIODE-SLAT RETRACT ISOLATION	284T1612 09922	1	27-32-11 SHELF/E01/0002	150-199, 275-299
R00843	9	YHLZD-33 DIODE-SLAT RETRACT ISOLATION	284T1612 09922	1	27-32-21 SHELF/E01/0002	150-199, 275-299
R00883	9	RWR84S2740FR RES-L IDG VLV IND BURDEN (SB 24-0109)	284T3601 96906	1	24-11-11 P036-00/ /	050, 151
R00884	9	69B40800-106 RES-R IDG VLV IND BURDEN (SB 24-0109)	284T3701 96906	1	24-11-21 P037-00/ /	050, 151

EQUIPMENT LIST

D280T132

Section R00800
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R09001	9	YHLZD-9 DIODE-BLOCKING (MTO 230452A)	284T0149 81205	1	23-31-14 SHELF/E02/05	050-099, 150-155, 162-166
R09035	9	YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	26-17-11 P037/ /	150, 152-199
R09035		YHLZD-9 DIODE-BLOCKING	284T0188 81205	1	26-17-11 P037/ /	150-199
R09036	9	YHLZD-33 DIODE-ISOLATION (MTO-340961)	CUSTOMER 09922	1	34-46-13 SHELF/E01/05	150, 152-199, 275- 299
R09037	9	YHLZD-33 DIODE-ISOLATION (MTO-340961)	CUSTOMER 09922	1	34-46-13 SHELF/E01/05	150, 152-199, 275- 299
R09038	9	YHLZD-33 DIODE-ISOLATION (MTO-340961)	CUSTOMER 09922	1	34-46-13 SHELF/E01/05	150, 152-199, 275- 299
R09039	9	YHLZD-33 DIODE-ISOLATION (MTO-340961)	CUSTOMER 09922	1	34-46-13 SHELF/E01/05	150, 152-199, 275- 299
R09040	9	YHLZD-33 DIODE-ISOLATION (MTO-340961)	CUSTOMER 09922	1	34-46-13 SHELF/E01/05	150, 152-199, 275- 299
R09041	9	YHLZD-33 DIODE-ISOLATION (MTO-340961)	CUSTOMER 09922	1	34-46-13 SHELF/E01/05	150, 152-199, 275- 299

EQUIPMENT LIST

D280T132

Section R09000

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10001	9	YHLZD-30 DIODE-LEFT FMC DME-L SCAN DISCR ISOL	284T0122 09922	1	34-61-17 SHELF/E02/02	275-276
R10001		YHLZD-30 DIODE-LEFT FMC DME-L SCAN DISCR ISOL	284T0122 09922	1	34-61-17 SHELF/E02/02	157, 167-199, 277- 299
R10002	9	YHLZD-30 DIODE-LEFT FMC DME-R SCAN DISCR ISOL	284T0122 09922	1	34-61-17 SHELF/E02/02	275-276
R10002		YHLZD-30 DIODE-LEFT FMC DME-R SCAN DISCR ISOL	284T0122 09922	1	34-61-17 SHELF/E02/02	157, 167-199, 277- 299
R10003	9	YHLZD-30 DIODE-RIGHT FMC DME-R SCAN DISCR ISOL	284T0123 09922	1	34-61-27 SHELF/E02/03	275-276
R10003		YHLZD-30 DIODE-RIGHT FMC DME-R SCAN DISCR ISOL	284T0123 09922	1	34-61-27 SHELF/E02/03	157, 167-199, 277- 299
R10004	9	YHLZD-30 DIODE-RIGHT FMC DME-L SCAN DISCR ISOL	284T0123 09922	1	34-61-27 SHELF/E02/03	275-276
R10004		YHLZD-30 DIODE-RIGHT FMC DME-L SCAN DISCR ISOL	284T0123 09922	1	34-61-27 SHELF/E02/03	157, 167-199, 277- 299
R10076		YHLZD-29 DIODE-APU OFF LIGHT ISLN	284T0161 09922	1	24-27-41 SHELF/E06/01	150-157

EQUIPMENT LIST

D280T132

Section R10000
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
R10111		YHLZR-30 RESISTOR-L IDG OIL TEMP	284T1612 09922	1	24-11-11 SHELF/E01/02	ALL
R10112		YHLZR-30 RESISTOR-R IDG OIL TEMP	284T1624 09922	1	24-11-21 SHELF/E02/04	ALL
R10117	1	YHLZD-30 DIODE-L T/R INDICATION	284T0188 81205	1	78-36-11 P037-00/ /	ALL
R10117	2	YHLZD-9 DIODE-L T/R INDICATION	284T0188 81205	1	78-36-11 P037-00/ /	ALL
R10118	1	YHLZD-30 DIODE-R T/R INDICATION	284T0188 81205	1	78-36-21 P037-00/ /	ALL
R10118	2	YHLZD-9 DIODE-R T/R INDICATION	284T0188 81205	1	78-36-21 P037-00/ /	ALL
R10119		YHLZD-30 DIODE-L START INDICATION	284T0997 81205	1	80-11-11 P006-05/ /	ALL
R10120		YHLZD-30 DIODE-R START INDICATION	284T0997 81205	1	80-11-21 P006-05/ /	ALL

EQUIPMENT LIST

D280T132

Section R10100

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00001		AC-45-0008 SW-F/D INSTR SOURCE SELECT,LEFT	233T2200 91812	1	34-22-17 P001-01/ /	ALL
S00002		AC45-0061 SW-FMC INSTR SOURCE SELECT,LEFT	233T2200 JANCO	1	34-61-16 P001-01/ /	050, 150-154, 275-276
S00002		AC45-0082 SW-FMC INSTR SOURCE SELECT,LEFT	233T2200 JANCO	1	34-61-16 P001-01/ /	051-099, 155-199, 277-299
S00003		S231T290-2001 SW-EFI INSTR SOURCE SELECT,LEFT	233T2204 81205	1	34-22-17 P001-01/ /	ALL
S00004	1	S231T290-4001 SW-IRS INSTR SOURCE SELECT,LEFT	233T2200 81205	1	34-22-82 P001-01/ /	050-099, 153-199, 275-299
S00004	1	S231T290-2001 SW-IRS INSTR SOURCE SELECT,LEFT	233T2200 81205	1	34-22-82 P001-01/ /	150-152
S00004	2	S231T290-5001 SW-IRS INSTR SOURCE SELECT,LEFT	233T2200 81205	1	34-22-82 P001-01/ /	050-099, 153-199, 275-299
S00004	2	S231T290-1001 SW-IRS INSTR SOURCE SELECT,LEFT	233T2200 81205	1	34-22-82 P001-01/ /	150-152
S00006	1	SW43896 SW-AUTOPILOT DISENGAGE,F/O	253T2121 97564	1	22-11-12 0169/238/R028	ALL
S00006	2	721101A1 SW-AUTOPILOT DISENGAGE,F/O	253T2121 97564	1	22-11-12 0169/238/R028	ALL
S00009		AC-45-0008 SW-F/D INSTR SOURCE SELECT,RIGHT	233T2204 91812	1	34-22-27 P003-03/ /	ALL
S00010		AC45-0061 SW-FMC INSTR SOURCE SELECT,RIGHT	233T2204 JANCO	1	34-61-26 P003-03/ /	050, 150-154, 275-276
S00010		AC45-0082 SW-FMC INSTR SOURCE SELECT,RIGHT	233T2204 JANCO	1	34-61-26 P003-03/ /	051-099, 155-199, 277-299
S00011		S231T290-2001 SW-EFI INSTR SOURCE SELECT,RIGHT	233T2204 81205	1	34-22-27 P003-03/ /	ALL
S00012	1	S231T290-4001 SW-IRS INSTR SOURCE SELECT,RIGHT	233T2204 81205	1	34-22-92 P003-03/ /	050-099, 153-199, 275-299
S00012	1	S231T290-2001 SW-IRS INSTR SOURCE SELECT,RIGHT	233T2204 81205	1	34-22-92 P003-03/ /	150-152
S00012	2	S231T290-5001 SW-IRS INSTR SOURCE SELECT,RIGHT	233T2204 81205	1	34-22-92 P003-03/ /	050-099, 153-199, 275-299

EQUIPMENT LIST

D280T132

Section S00000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00012	2	S231T290-1001 SW-IRS INSTR SOURCE SELECT,RIGHT	233T2204 81205	1	34-22-92 P003-03/ /	150-152
S00016		S231T290-2070 SW-LIGHT GND PROX-G/S INHIBIT	233T2222 81205	1	34-46-11 P001-03/ /	ALL
S00021		S210T130-18 SW-DUCT OVHT,FLT DECK ZONE	215T1004 81205	1	21-61-11 0271/185/L070	ALL
S00022		S210T130-18 SW-DUCT OVHT,FWD CABIN ZONE	215T1005 81205	1	21-61-21 0661/303/L013	050-099
S00022		S210T130-18 SW-DUCT OVHT,FWD CABIN ZONE	215T1005 81205	1	21-61-21 0654+08/303/L013	150-199, 275-299
S00023		S210T130-18 SW-DUCT OVHT,AFT CABIN ZONE	215T1005 81205	1	21-61-31 0709/305/L017	050-099
S00023		S210T130-18 SW-DUCT OVHT,AFT CABIN ZONE	215T1005 81205	1	21-61-31 0770/302/R017	150-157, 275-278
S00023		S210T130-18 SW-DUCT OVHT,AFT CABIN ZONE	215T1005 81205	1	21-61-31 0770/302/L017	162-199, 280-299
S00024		S283T022-3 SW-AUTOBRAKE SELECTOR	233T2222 81205	1	32-42-12 P001-03/ /	ALL
S00025		S271T452-1 SW-ELEC HYD PUMP L PRESS.	272T0175 81205	1	29-11-12 NL310/149/	ALL
S00026		S271T452-9 SW-ENG HYD PUMP L PRESS.	271T0068 81205	2	29-11-12 NL265/149/	ALL
S00027		S271T452-9 SW-ELEC HYD PUMP L CONTROL PRESS.	271T0068 81205	2	29-11-12 NL265/149/	ALL
S00028		S271T452-9 SW-AIR HYD PUMP PRESS.	271T0068 81205	2	29-11-32 1056/181/L006	ALL
S00029		S271T452-9 SW-AIR HYD PUMP CONT PRESS.	271T0068 81205	2	29-11-32 1053/180/L006	ALL
S00030		S271T452-1 SW-ELEC HYD PUMP R PRESS.	272T0175 81205	1	29-11-22 NR311/155/	ALL
S00031		S271T452-9 SW-ENG HYD PUMP R PRESS.	271T0068 81205	2	29-11-22 NR265/149/	ALL
S00032		S271T452-9 SW-ELEC HYD PUMP R CONTROL PRESS.	271T0068 81205	2	29-11-22 NR265/149/	ALL

EQUIPMENT LIST

D280T132

Section S00000

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00033		S271T452-1 SW-ELEC HYD PUMP C1 PRESS.	271T4570 81205	1	29-11-31 0982/155/R007	ALL
S00034		S271T452-1 SW-ELEC HYD PUMP C2 PRESS.	271T4570 81205	1	29-11-31 1026/155/R007	ALL
S00035		S271T452-1 SW-HYD SYS CTR PRESS	272T0131 81205	1	29-11-32 1002/150/R006	ALL
S00036		2038827-0505 SW-RF TRANSMISSION LINE	284T0750 27914	1	34-43-12 / /	050-099, 150-199
S00036		2038827-0505 SW-RF TRANSMISSION LINE	284T0750 27914	1	34-43-12 0140/170/0000	275-299
S00037		10-61318-14 SW-FIRE,LEFT ENGINE	233T6100 81205	1	26-11-11 P008-00/ /	050-099, 150-155, 162-165, 275-276
S00037		10-61318-51 SW-FIRE,LEFT ENGINE	233T6100 81205	1	26-11-11 P008-00/ /	156-157, 166-199, 277-299
S00037A		MS-25237-387 LAMP-	10-61318 96906	4	26-11-11 P008-00/ /	ALL
S00038		10-61318-15 SW-FIRE,RIGHT ENGINE	233T6100 81205	1	26-11-21 P008-00/ /	050-099, 150-155, 162-165, 275-276
S00038		10-61318-52 SW-FIRE,RIGHT ENGINE	233T6100 81205	1	26-11-21 P008-00/ /	156-157, 166-199, 277-299
S00038A		MS-25237-387 LAMP-	10-61318 96906	4	26-11-21 P008-00/ /	ALL
S00039		10-61318-16 SW-FIRE,APU	233T6100 81205	1	26-15-11 P008-00/ /	050-099, 150-199
S00039		10-61318-17 SW-FIRE,APU	233T6100 81205	1	26-15-11 P008-00/ /	275-299
S00039A		MS-25237-387 LAMP-	10-61318 96906	4	26-15-11 P008-00/ /	ALL
S00041		3000-46-12 SW-EQUIPMENT COOLING SUPPLY AIR OVERHEAT	215T3001 14604	1	21-58-11 0384/187/L085	ALL
S00042		L18366-12 SW-LIGHT,CLOSET	417T5035 24385	1	33-22-21 0469/252/L049	050-099
S00048		S210T130-25 SW-PACK OVERHEAT,LEFT	213T1001 81205	1	21-51-11 0805/122/L027	050-099, 150-199, 275-278

EQUIPMENT LIST

D280T132

Section S00000

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00048		S210T130-25 SW-PACK OVERHEAT,LEFT	213T1001 81205	1	21-51-11 0819/125/L026	280-299
S00049		S210T130-25 SW-PACK OVERHEAT,RIGHT	213T1001 81205	1	21-51-21 0859/125/R059	ALL
S00064		3000-46-15 SW-TEMP,CARGO OVHT,AFT	215T2002 14604	1	21-44-11 1251/123/R002	050-099, 162-199, 277-299
S00064		3000-46-15 SW-TEMP,CARGO OVHT,AFT	215T2002 14604	1	21-44-11 1251/123/L005	150-157, 275-276
S00067	1	SW43896 SW-AUTOPILOT DISENGAGE,CAPT	253T2121 97564	1	22-11-12 0169/238/L028	ALL
S00067	2	721101A1 SW-AUTOPILOT DISENGAGE,CAPT	253T2121 97564	1	22-11-12 0169/238/L028	ALL
S00070	1	60B92400-7 SW-PRESS.,FUEL BOOST PUMP,L FWD	343T0002 81205	1	28-42-11 L0294/14/RS	ALL
S00070	2	60B92400-3 SW-PRESS.,FUEL BOOST PUMP,L FWD	343T0002 81205	1	28-42-11 L0294/14/RS	ALL
S00071	1	60B92400-7 SW-PRESS.,FUEL BOOST PUMP,L AFT	343T0002 81205	1	28-42-11 LO297/14/RS	ALL
S00071	2	60B92400-3 SW-PRESS.,FUEL BOOST PUMP,L AFT	343T0002 81205	1	28-42-11 LO297/14/RS	ALL
S00072	1	60B92400-7 SW-PRESS.,FUEL BOOST PUMP,R FWD	343T0002 81205	1	28-42-11 R0297/14/RS	ALL
S00072	2	60B92400-3 SW-PRESS.,FUEL BOOST PUMP,R FWD	343T0002 81205	1	28-42-11 R0297/14/RS	ALL
S00073	1	60B92400-7 SW-PRESS.,FUEL BOOST PUMP,R AFT	343T0002 81205	1	28-42-11 R0294/14/RS	ALL
S00073	2	60B92400-3 SW-PRESS.,FUEL BOOST PUMP,R AFT	343T0002 81205	1	28-42-11 R0294/14/RS	ALL
S00074		60B92400-3 SW-PRESS.,DC FUEL PUMP	346T0004 81205	1	28-42-21 L / RS	280-299
S00074	1	60B92400-7 SW-PRESS.,DC FUEL PUMP	346T0004 81205	1	28-42-21 L / RS	ALL
S00074	2	60B92400-3 SW-PRESS.,DC FUEL PUMP	346T0004 81205	1	28-42-21 L / RS	ALL

EQUIPMENT LIST

D280T132

Section S00000

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00075		3000-46-14 SW-THERMAL,CARGO TEMP,AFT	215T2002 14604	1	21-44-11 1251/123/L005	050-099, 150-157, 275-276
S00075		3000-46-14 SW-THERMAL,CARGO TEMP,AFT	215T2002 14604	1	21-44-11 1251/123/L002	162-199, 277-299
S00080		S253T407-1 SW-MAN. STAB. TRIM,CAPT	253T2121 81205	1	27-41-11 CONT/COL/CAPT	ALL
S00081		S253T407-1 SW-MAN. STAB. TRIM,F/O	253T2121 81205	1	27-41-21 CONT/COL/F/O	ALL
S00082		S271T452-19 SW-LEFT METERED PRESS.	274T1300 81205	1	32-42-12 1045/187/L078	ALL
S00083		S271T452-19 SW-RIGHT METERED PRESS.	274T1300 81205	1	32-42-12 1045/187/R078	ALL

EQUIPMENT LIST

D280T132

Section S00000
Page 5 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00119		214C40-1-113 SW-ALTITUDE PRESSURE	284T0186 02750	1	35-21-11 P019-00/TOP/	ALL
S00150	1	S283T006-7 PROX SNSR-CARGO DR UNLATCHED,FWD	284T0259 81205	1	52-34-13 0542/130/R053	ALL
S00150	2	S283T006-10 PROX SNSR-CARGO DR UNLATCHED,FWD	284T0259 81205	1	52-34-13 0542/130/R053	ALL
S00150	3	S283T006-2 PROX SNSR-CARGO DR UNLATCHED,FWD	284T0259 81205	1	52-34-13 0542/130/R053	ALL
S00150	4	S283T006-5 PROX SNSR-CARGO DR UNLATCHED,FWD	284T0259 81205	1	52-34-13 0542/130/R053	ALL
S00151	1	S283T006-7 PROX SNSR-CARGO DR OPEN,FWD	284T0259 81205	1	52-34-13 0479/190/R088	ALL
S00151	2	S283T006-10 PROX SNSR-CARGO DR OPEN,FWD	284T0259 81205	1	52-34-13 0479/190/R088	ALL
S00151	3	S283T006-2 PROX SNSR-CARGO DR OPEN,FWD	284T0259 81205	1	52-34-13 0479/190/R087	ALL
S00151	4	S283T006-5 PROX SNSR-CARGO DR OPEN,FWD	284T0259 81205	1	52-34-13 0479/190/R087	ALL
S00152	1	S283T006-7 PROX SNSR-CARGO DR LATCH RANGE,FWD	284T0259 81205	1	52-34-13 0480/140/R068	ALL
S00152	2	S283T006-10 PROX SNSR-CARGO DR LATCH RANGE,FWD	284T0259 81205	1	52-34-13 0480/140/R068	ALL
S00152	3	S283T006-2 PROX SNSR-CARGO DR LATCH RANGE,FWD	284T0259 81205	1	52-34-13 D0480/140/R068	ALL
S00152	4	S283T006-5 PROX SNSR-CARGO DR LATCH RANGE,FWD	284T0259 81205	1	52-34-13 D0480/140/R068	ALL
S00153	1	S283T006-7 PROX SNSR-CARGO DR HANDLE UNLOCKED,FWD	284T0259 81205	1	52-34-13 0456/130/R060	ALL
S00153	2	S283T006-10 PROX SNSR-CARGO DR HANDLE UNLOCKED,FWD	284T0259 81205	1	52-34-13 0456/130/R060	ALL
S00153	3	S283T006-2 PROX SNSR-CARGO DR HANDLE UNLOCKED,FWD	284T0259 81205	1	52-34-13 0456/130/R060	ALL
S00153	4	S283T006-5 PROX SNSR-CARGO DR HANDLE UNLOCKED,FWD	284T0259 81205	1	52-34-13 0456/130/R060	ALL

EQUIPMENT LIST

D280T132

Section S00100

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00154	1	S283T006-7 PROX SNSR-CARGO DR LATCHED,FWD	284T0259 81205	1	52-34-13 0545/134/R060	ALL
S00154	2	S283T006-10 PROX SNSR-CARGO DR LATCHED,FWD	284T0259 81205	1	52-34-13 0545/134/R060	ALL
S00154	3	S283T006-2 PROX SNSR-CARGO DR LATCHED,FWD	284T0259 81205	1	52-34-13 D0545/134/R060	ALL
S00154	4	S283T006-5 PROX SNSR-CARGO DR LATCHED,FWD	284T0259 81205	1	52-34-13 D0545/134/R060	ALL
S00157	1	S283T006-7 PROX SNSR-CARGO DR LIFT RANGE,AFT	284T0241 81205	1	52-35-13 1303/152/R076	ALL
S00157	2	S283T006-10 PROX SNSR-CARGO DR LIFT RANGE,AFT	284T0241 81205	1	52-35-13 1303/152/R076	ALL
S00157	3	S283T006-2 PROX SNSR-CARGO DR LIFT RANGE,AFT	284T0241 81205	1	52-35-13 1303/152/R076	ALL
S00157	4	S283T006-5 PROX SNSR-CARGO DR LIFT RANGE,AFT	284T0241 81205	1	52-35-13 1303/152/R076	ALL
S00158	1	S283T006-7 PROX SNSR-CARGO DR OPEN,AFT	284T0241 81205	1	52-35-13 1325/198/R094	ALL
S00158	2	S283T006-10 PROX SNSR-CARGO DR OPEN,AFT	284T0241 81205	1	52-35-13 1325/198/R094	ALL
S00158	3	S283T006-2 PROX SNSR-CARGO DR OPEN,AFT	284T0241 81205	1	52-35-13 1325/198/R094	ALL
S00158	4	S283T006-5 PROX SNSR-CARGO DR OPEN,AFT	284T0241 81205	1	52-35-13 1325/198/R094	ALL
S00159	1	S283T006-7 PROX SNSR-CARGO DR DOWN NO.1,AFT	284T0241 81205	1	52-35-13 1344/140/R068	050-099
S00159	2	S283T006-10 PROX SNSR-CARGO DR DOWN NO.1,AFT	284T0241 81205	1	52-35-13 1344/140/R068	050-099
S00159	3	S283T006-2 PROX SNSR-CARGO DR DOWN NO.1,AFT	284T0241 81205	1	52-35-13 1344/140/R068	050-099
S00159	4	S283T006-5 PROX SNSR-CARGO DR DOWN NO.1,AFT	284T0241 81205	1	52-35-13 1344/140/R068	050-099
S00160	1	S283T006-7 PROX SNSR-CARGO DR DOWN NO.2,AFT	284T0241 81205	1	52-35-13 1271/140/R068	ALL

EQUIPMENT LIST

D280T132

Section S00100

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00160	2	S283T006-10 PROX SNSR-CARGO DR DOWN NO.2,AFT	284T0241 81205	1	52-35-13 1271/140/R068	ALL
S00160	3	S283T006-2 PROX SNSR-CARGO DR DOWN NO.2,AFT	284T0241 81205	1	52-35-13 1271/140/R068	ALL
S00160	4	S283T006-5 PROX SNSR-CARGO DR DOWN NO.2,AFT	284T0241 81205	1	52-35-13 1271/140/R068	ALL
S00161	1	S283T006-7 PROX SNSR-CAR. DR CLOSED,AFT	284T0241 81205	1	52-35-13 1303/155/R078	ALL
S00161	2	S283T006-10 PROX SNSR-CAR. DR CLOSED,AFT	284T0241 81205	1	52-35-13 1303/155/R078	ALL
S00161	3	S283T006-2 PROX SNSR-CAR. DR CLOSED,AFT	284T0241 81205	1	52-35-13 1303/155/R078	ALL
S00161	4	S283T006-5 PROX SNSR-CAR. DR CLOSED,AFT	284T0241 81205	1	52-35-13 1303/155/R078	ALL
S00184	1	S283T006-7 PROX SNSR-ENTRY DR HANDLE UP,FWD	284T0248 81205	1	52-11-13 0284/280/L060	ALL
S00184	2	S283T006-10 PROX SNSR-ENTRY DR HANDLE UP,FWD	284T0248 81205	1	52-11-13 0284/280/L060	ALL
S00184	3	S283T006-2 PROX SNSR-ENTRY DR HANDLE UP,FWD	284T0248 81205	1	52-11-13 0284/280/L060	ALL
S00184	4	S283T006-5 PROX SNSR-ENTRY DR HANDLE UP,FWD	284T0248 81205	1	52-11-13 0284/280/L060	ALL
S00185	1	S283T006-7 PROX SNSR-ENTRY DOOR UP,FWD	284T0248 81205	1	52-11-13 0317/305/R006	ALL
S00185	2	S283T006-10 PROX SNSR-ENTRY DOOR UP,FWD	284T0248 81205	1	52-11-13 0317/305/R006	ALL
S00185	3	S283T006-2 PROX SNSR-ENTRY DOOR UP,FWD	284T0248 81205	1	52-11-13 0317/305/R006	ALL
S00185	4	S283T006-5 PROX SNSR-ENTRY DOOR UP,FWD	284T0248 81205	1	52-11-13 0317/305/R006	ALL
S00186	1	S283T006-7 PROX SNSR-ENTRY DOOR DOWN,FWD	284T0248 81205	1	52-11-13 0315/280/L070	ALL
S00186	2	S283T006-10 PROX SNSR-ENTRY DOOR DOWN,FWD	284T0248 81205	1	52-11-13 0315/280/L070	ALL

EQUIPMENT LIST

D280T132

Section S00100

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00186	3	S283T006-2 PROX SNSR-ENTRY DOOR DOWN,FWD	284T0248 81205	1	52-11-13 0315/280/L070	ALL
S00186	4	S283T006-5 PROX SNSR-ENTRY DOOR DOWN,FWD	284T0248 81205	1	52-11-13 0315/280/L070	ALL
S00187	1	S283T006-7 PROX SNSR-UPLATCH RELEASE,FWD	284T0248 81205	1	52-11-13 0292/275/L070	ALL
S00187	2	S283T006-10 PROX SNSR-UPLATCH RELEASE,FWD	284T0248 81205	1	52-11-13 0292/275/L070	ALL
S00187	3	S283T006-2 PROX SNSR-UPLATCH RELEASE,FWD	284T0248 81205	1	52-11-13 0292/275/L070	ALL
S00187	4	S283T006-5 PROX SNSR-UPLATCH RELEASE,FWD	284T0248 81205	1	52-11-13 0292/275/L070	ALL
S00192		284T0484-1 PROX SNSR-L WG DOOR CLOSED	284T0242 81205	1	52-71-12 0872/260/L090	ALL
S00193		284T0484-1 PROX SNSR-R WG DOOR CLOSED	284T0242 81205	1	52-71-12 0872/260/R090	ALL
S00194	1	S283T006-7 PROX SNSR-L FWD ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 0316/276/L080	ALL
S00194	2	S283T006-10 PROX SNSR-L FWD ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 0316/276/L080	ALL
S00194	3	S283T006-2 PROX SNSR-L FWD ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 0316/276/L080	ALL
S00194	4	S283T006-5 PROX SNSR-L FWD ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 0316/276/L080	ALL
S00195	1	S283T006-8 PROX SNSR-L FWD ENTRY DOOR LOCKED	284T0248 81205	1	52-71-11 0312/276/L080	ALL
S00195	2	S283T006-3 PROX SNSR-L FWD ENTRY DOOR LOCKED	284T0248 81205	1	52-71-11 0312/276/L080	ALL
S00196	1	S283T006-7 PROX SNSR-R FWD ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 0322/275/R080	ALL
S00196	2	S283T006-10 PROX SNSR-R FWD ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 0322/275/R080	ALL
S00196	3	S283T006-2 PROX SNSR-R FWD ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 0322/275/R080	ALL

EQUIPMENT LIST

D280T132

Section S00100

Page 4

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00196	4	S283T006-5 PROX SNSR-R FWD ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 0322/275/R080	ALL
S00197	1	S283T006-8 PROX SNSR-R FWD ENTRY DOOR LOCKED	284T0248 81205	1	52-71-11 0320/275/R080	ALL
S00197	2	S283T006-3 PROX SNSR-R FWD ENTRY DOOR LOCKED	284T0248 81205	1	52-71-11 0320/275/R080	ALL
S00198	1	S283T006-7 PROX SNSR-L WG SLIDE DR LOCKED	284T0242 81205	1	52-71-12 1146/171/L093	ALL
S00198	2	S283T006-10 PROX SNSR-L WG SLIDE DR LOCKED	284T0242 81205	1	52-71-12 1146/171/L093	ALL
S00198	3	S283T006-2 PROX SNSR-L WG SLIDE DR LOCKED	284T0242 81205	1	52-71-12 1146/171/L093	ALL
S00198	4	S283T006-5 PROX SNSR-L WG SLIDE DR LOCKED	284T0242 81205	1	52-71-12 1146/171/L093	ALL
S00199	1	S283T006-7 PROX SNSR-R WG SLIDE DR LOCKED	284T0242 81205	1	52-71-12 1146/171/R093	ALL
S00199	2	S283T006-10 PROX SNSR-R WG SLIDE DR LOCKED	284T0242 81205	1	52-71-12 1146/171/R093	ALL
S00199	3	S283T006-2 PROX SNSR-R WG SLIDE DR LOCKED	284T0242 81205	1	52-71-12 1146/171/R093	ALL
S00199	4	S283T006-5 PROX SNSR-R WG SLIDE DR LOCKED	284T0242 81205	1	52-71-12 1146/171/R093	ALL

EQUIPMENT LIST

D280T132

Section S00100

Page 5 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00200		284T0484-1 PROX SNSR-FWD ACCESS. HATCH CLOSED	284T0266 81205	1	52-71-14 0150/160/R013	ALL
S00201	1	S283T006-7 PROX SNSR-ELEC ACCESS. HATCH CLOSED	284T0266 81205	1	52-71-14 0302/135/R020	ALL
S00201	2	S283T006-10 PROX SNSR-ELEC ACCESS. HATCH CLOSED	284T0266 81205	1	52-71-14 0302/135/R020	ALL
S00201	3	S283T006-2 PROX SNSR-ELEC ACCESS. HATCH CLOSED	284T0266 81205	1	52-71-14 0302/135/R020	ALL
S00201	4	S283T006-5 PROX SNSR-ELEC ACCESS. HATCH CLOSED	284T0266 81205	1	52-71-14 0302/135/R020	ALL
S00202	1	S283T006-7 PROX SNSR-L FWD GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 0287/244/L080	ALL
S00202	2	S283T006-10 PROX SNSR-L FWD GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 0287/244/L080	ALL
S00202	3	S283T006-2 PROX SNSR-L FWD GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 0287/244/L080	ALL
S00202	4	S283T006-5 PROX SNSR-L FWD GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 0287/244/L080	ALL
S00203	1	S283T006-7 PROX SNSR-R FWD GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 0287/240/R080	ALL
S00203	2	S283T006-10 PROX SNSR-R FWD GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 0287/240/R080	ALL
S00203	3	S283T006-2 PROX SNSR-R FWD GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 0287/240/R080	ALL
S00203	4	S283T006-5 PROX SNSR-R FWD GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 0287/240/R080	ALL
S00204	1	S283T006-7 PROX SNSR-L AFT ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 1505/274/L080	ALL
S00204	2	S283T006-10 PROX SNSR-L AFT ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 1505/274/L080	ALL
S00204	3	S283T006-2 PROX SNSR-L AFT ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 1505/274/L080	ALL
S00204	4	S283T006-5 PROX SNSR-L AFT ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 1505/274/L080	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00205	1	S283T006-8 PROX SNSR-L AFT ENTRY DOOR LOCKED	284T0248 81205	1	52-71-11 1505/274/L080	ALL
S00205	2	S283T006-3 PROX SNSR-L AFT ENTRY DOOR LOCKED	284T0248 81205	1	52-71-11 1505/274/L080	ALL
S00206	1	S283T006-7 PROX SNSR-R AFT ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 1515/274/R080	ALL
S00206	2	283T006-10 PROX SNSR-R AFT ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 1515/274/R080	ALL
S00206	3	S283T006-2 PROX SNSR-R AFT ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 1515/274/R080	ALL
S00206	4	S283T006-5 PROX SNSR-R AFT ENTRY DOOR CLOSED	284T0248 81205	1	52-71-11 1515/274/R080	ALL
S00207	1	S283T006-8 PROX SNSR-R AFT ENTRY DOOR LOCKED	284T0248 81205	1	52-71-11 1515/274/R080	ALL
S00207	2	S283T006-3 PROX SNSR-R AFT ENTRY DOOR LOCKED	284T0248 81205	1	52-71-11 1515/274/R080	ALL
S00208	1	S283T006-8 PROX SNSR-AFT CARGO DOOR LOCKED	284T0241 81205	1	52-71-13 1275/152/R074	ALL
S00208	2	S283T006-3 PROX SNSR-AFT CARGO DOOR LOCKED	284T0241 81205	1	52-71-13 1275/152/R074	ALL
S00209	1	S283T006-7 PROX SNSR-AFT CARGO DOOR CLOSED	284T0241 81205	1	52-71-13 1324/196/R085	ALL
S00209	2	S283T006-10 PROX SNSR-AFT CARGO DOOR CLOSED	284T0241 81205	1	52-71-13 1324/196/R085	ALL
S00209	3	S283T006-2 PROX SNSR-AFT CARGO DOOR CLOSED	284T0241 81205	1	52-71-13 1324/196/R085	050-099
S00209	4	S283T006-5 PROX SNSR-AFT CARGO DOOR CLOSED	284T0241 81205	1	52-71-13 1324/196/R085	050-099
S00211	1	S283T006-7 PROX SNSR-BULK CARGO DOOR LATCHED	284T0241 81205	1	52-71-13 1460/140/L060	ALL
S00211	2	S283T006-10 PROX SNSR-BULK CARGO DOOR LATCHED	284T0241 81205	1	52-71-13 1460/140/L060	ALL
S00211	3	S283T006-2 PROX SNSR-BULK CARGO DOOR LATCHED	284T0241 81205	1	52-71-13 1460/140/L060	050-099

EQUIPMENT LIST

D280T132

Section S00200

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00211	4	S283T006-5 PROX SNSR-BULK CARGO DOOR LATCHED	284T0241 81205	1	52-71-13 1460/140/L060	050-099
S00212	1	S283T006-7 PROX SNSR-L AFT GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 1540/250/L090	ALL
S00212	2	S283T006-10 PROX SNSR-L AFT GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 1540/250/L090	ALL
S00212	3	S283T006-2 PROX SNSR-L AFT GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 1540/250/L090	ALL
S00212	4	S283T006-5 PROX SNSR-L AFT GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 1540/250/L090	ALL
S00213	1	S283T006-7 PROX SNSR-R AFT GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 1540/250/R090	ALL
S00213	2	S283T006-10 PROX SNSR-R AFT GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 1540/250/R090	ALL
S00213	3	S283T006-2 PROX SNSR-R AFT GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 1540/250/R090	ALL
S00213	4	S283T006-5 PROX SNSR-R AFT GIRT BAR ACTVTD	284T0248 81205	1	52-71-11 1540/250/R090	ALL
S00214	1	S283T006-7 PROX SNSR-FWD CARGO DOOR LOCKED	284T0259 81205	1	52-71-13 0597/125/R052	ALL
S00214	2	S283T006-10 PROX SNSR-FWD CARGO DOOR LOCKED	284T0259 81205	1	52-71-13 0597/125/R052	ALL
S00214	3	S283T006-2 PROX SNSR-FWD CARGO DOOR LOCKED	284T0241 81205	1	52-71-13 D0597/125/R052	ALL
S00214	4	S283T006-5 PROX SNSR-FWD CARGO DOOR LOCKED	284T0241 81205	1	52-71-13 D0597/125/R052	ALL
S00215	1	S283T006-7 PROX SNSR-FWD CARGO DOOR CLOSED	284T0259 81205	1	52-71-13 0550/120/R047	ALL
S00215	2	S283T006-10 PROX SNSR-FWD CARGO DOOR CLOSED	284T0259 81205	1	52-71-13 0550/120/R047	ALL
S00215	3	S283T006-2 PROX SNSR-FWD CARGO DOOR CLOSED	284T0259 81205	1	52-71-13 D0550/120/R047	ALL
S00215	4	S283T006-5 PROX SNSR-FWD CARGO DOOR CLOSED	284T0259 81205	1	52-71-13 D0550/120/R047	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00216		284T0484-1 PROX SNSR-L AFT WING DOOR CLOSED	284T0242 81205	1	52-71-12 0928/260/L090	150-199, 275-299
S00217		284T0484-1 PROX SNSR-R AFT WING DOOR CLOSED	284T0242 81205	1	52-71-12 0928/260/R090	150-199, 275-299
S00218	1	S283T006-7 PROX SNSR-L WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1114/172/L094	050-099, 153-199, 275-299
S00218	1	S283T006-7 PROX SNSR-L WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1113/172/L098	150-152
S00218	2	S283T006-10 PROX SNSR-L WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1114/172/L094	050-099, 153-199, 275-299
S00218	2	S283T006-10 PROX SNSR-L WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1113/172/L098	150-152
S00218	3	S283T006-2 PROX SNSR-L WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1114/172/L094	050-099, 153-199, 275-299
S00218	3	S283T006-2 PROX SNSR-L WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1113/172/L098	150-152
S00218	4	S283T006-5 PROX SNSR-L WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1114/172/L094	050-099, 153-199, 275-299
S00218	4	S283T006-5 PROX SNSR-L WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1113/172/L098	150-152
S00219	1	S283T006-7 PROX SNSR-R WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1114/172/R094	050-099, 153-199, 275-299
S00219	1	S283T006-7 PROX SNSR-R WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1113/172/R098	150-152
S00219	2	S283T006-10 PROX SNSR-R WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1114/172/R094	050-099, 153-199, 275-299
S00219	2	S283T006-10 PROX SNSR-R WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1113/172/R098	150-152
S00219	3	S283T006-2 PROX SNSR-R WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1114/172/R094	050-099, 153-199, 275-299
S00219	3	S283T006-2 PROX SNSR-R WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1113/172/R098	150-152
S00219	4	S283T006-5 PROX SNSR-R WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1114/172/R094	050-099, 153-199, 275-299

EQUIPMENT LIST

D280T132

Section S00200

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00219	4	S283T006-5 PROX SNSR-R WG SLIDE DR LATCHED/CLOSED	284T0242 81205	1	52-71-12 1113/172/R098	150-152
S00232	1	S283T006-10 PROX SNSR-NOSE GEAR DOWN,SYS NO.1	287T4142 81205	1	32-61-13 0276/120/L025	ALL
S00232	2	S283T006-7 PROX SNSR-NOSE GEAR DOWN,SYS NO.1	287T4142 81205	1	32-61-13 0276/120/L025	ALL
S00233	1	S283T006-8 PROX SNSR-NOSE GEAR LOCKED,SYS NO.1	287T6205 81205	1	32-61-13 / /	ALL
S00233	2	S283T006-3 PROX SNSR-NOSE GEAR LOCKED,SYS NO.1	287T6205 81205	1	32-61-13 / /	ALL
S00234	1	S283T006-10 PROX SNSR-LEFT NOSE DOOR CLOSED,SYS NO.1	287T4142 81205	1	32-61-13 0188/120/0000	ALL
S00234	2	S283T006-7 PROX SNSR-LEFT NOSE DOOR CLOSED,SYS NO.1	287T4142 81205	1	32-61-13 0188/120/0000	ALL
S00234	3	S283T006-2 PROX SNSR-LEFT NOSE DOOR CLOSED,SYS NO.1	287T4142 81205	1	32-61-13 0188/120/0000	150-157
S00234	4	S283T006-5 PROX SNSR-LEFT NOSE DOOR CLOSED,SYS NO.1	287T4142 81205	1	32-61-13 0188/120/0000	150-157
S00235	1	S283T006-10 PROX SNSR-RIGHT NOSE DR CLOSED,SYS NO.1	287T4142 81205	1	32-61-13 0188/120/0000	ALL
S00235	2	S283T006-7 PROX SNSR-RIGHT NOSE DR CLOSED,SYS NO.1	287T4142 81205	1	32-61-13 0188/120/0000	ALL
S00235	3	S283T006-2 PROX SNSR-RIGHT NOSE DR CLOSED,SYS NO.1	287T4142 81205	0	32-61-13 0188/120/0000	150-157
S00235	4	S283T006-5 PROX SNSR-RIGHT NOSE DR CLOSED,SYS NO.1	287T4142 81205	1	32-61-13 0188/120/0000	150-157
S00236	1	S283T006-28 PROX SNSR-LEFT SIDE BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-11 / /	ALL
S00236	2	S283T006-8 PROX SNSR-LEFT SIDE BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-11 / /	ALL
S00236	3	S283T006-3 PROX SNSR-LEFT SIDE BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-11 / /	ALL
S00237	1	S283T006-10 PROX SNSR-LEFT DRAG BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-11 / /	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00237	2	S283T006-7 PROX SNSR-LEFT DRAG BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-11 //	ALL
S00237	3	S283T006-2 PROX SNSR-LEFT DRAG BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-11 //	150-157
S00237	4	S283T006-5 PROX SNSR-LEFT DRAG BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-11 //	150-157
S00238	1	S283T006-33 PROX SNSR-LEFT LATCH LOCKED,SYS NO.1	287T4142 81205	1	32-61-11 //	ALL
S00238	2	S283T006-22 PROX SNSR-LEFT LATCH LOCKED,SYS NO.1	287T4142 81205	1	32-61-11 //	ALL
S00238	3	S283T006-5 PROX SNSR-LEFT LATCH LOCKED,SYS NO.1	284T0272 81205	1	32-61-11 //	150-157
S00240	1	S283T006-28 PROX SNSR-RIGHT SIDE BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-12 //	ALL
S00240	2	S283T006-8 PROX SNSR-RIGHT SIDE BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-12 //	ALL
S00240	3	S283T006-3 PROX SNSR-RIGHT SIDE BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-12 //	ALL
S00241	1	S283T006-10 PROX SNSR-RIGHT DRAG BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-12 //	ALL
S00241	2	S283T006-7 PROX SNSR-RIGHT DRAG BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-12 //	ALL
S00241	3	S283T006-2 PROX SNSR-RIGHT DRAG BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-12 //	150-157
S00241	4	S283T006-5 PROX SNSR-RIGHT DRAG BRACE DOWN,SYS NO.1	287T6104 81205	1	32-61-12 //	150-157
S00242	1	S283T006-33 PROX SNSR-RIGHT LATCH LOCKED,SYS NO.1	287T4142 81205	1	32-61-12 //	ALL
S00242	2	S283T006-22 PROX SNSR-RIGHT LATCH LOCKED,SYS NO.1	287T4142 81205	1	32-61-12 //	ALL
S00242	3	S283T006-5 PROX SNSR-RIGHT LATCH LOCKED,SYS NO.1	287T4142 81205	1	32-61-12 //	150-199
S00244	1	S283T006-10 PROX SNSR-NOSE GEAR NOT CPRS,SYS NO.1	287T6205 81205	1	32-09-11 //	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00244	2	S283T006-7 PROX SNSR-NOSE GEAR NOT CPRS,SYS NO.1	287T6205 81205	1	32-09-11 / /	ALL
S00244	3	S283T006-2 PROX SNSR-NOSE GEAR NOT CPRS,SYS NO.1	287T6205 81205	1	32-09-11 / /	150-157
S00244	4	S283T006-5 PROX SNSR-NOSE GEAR NOT CPRS,SYS NO.1	287T6205 81205	1	32-09-11 / /	150-157
S00245	1	S283T006-33 PROX SNSR-LEFT GEAR TILTED,SYS NO.1	287T6104 81205	1	32-09-11 1046/050/L183	ALL
S00245	2	S283T006-10 PROX SNSR-LEFT GEAR TILTED,SYS NO.1	287T6104 81205	1	32-09-11 1046/050/L183	ALL
S00246	1	S283T006-33 PROX SNSR-RIGHT GEAR TILTED,SYS NO.1	287T6104 81205	1	32-09-11 1046/050/R183	ALL
S00246	2	S283T006-10 PROX SNSR-RIGHT GEAR TILTED,SYS NO.1	287T6104 81205	1	32-09-11 1046/050/R183	ALL
S00247	1	S283T006-10 SW-TAIL SKID EXTENDED	284T0805 81205	1	32-71-11 1706/167/L001	150-199, 275-299
S00247	2	S283T006-7 SW-TAIL SKID EXTENDED	284T0805 81205	1	32-71-11 1706/167/L001	150-199, 275-299
S00248	1	S283T006-10 SW-TAIL SKID RETRACTED	284T0805 81205	1	32-71-11 1702/168/L001	150-199, 275-299
S00248	2	S283T006-7 SW-TAIL SKID RETRACTED	284T0805 81205	1	32-71-11 1702/168/L001	150-199, 275-299
S00254	1	S283T006-10 PROX SNSR-NOSE GEAR DOWN,SYS NO.2	287T4142 81205	1	32-61-13 0280/120/R025	ALL
S00254	2	S283T006-7 PROX SNSR-NOSE GEAR DOWN,SYS NO.2	287T4142 81205	1	32-61-13 0280/120/R025	ALL
S00254	3	S283T006-2 PROX SNSR-NOSE GEAR DOWN,SYS NO.2	287T4142 81205	1	32-61-13 0280/120/R025	150-157
S00254	4	S283T006-5 PROX SNSR-NOSE GEAR DOWN,SYS NO.2	287T4142 81205	1	32-61-13 0280/120/R025	150-157
S00255	1	S283T006-8 PROX SNSR-NOSE GEAR LOCKED,SYS NO.2	287T6205 81205	1	32-61-13 / /	ALL
S00255	2	S283T006-3 PROX SNSR-NOSE GEAR LOCKED,SYS NO.2	287T6205 81205	1	32-61-13 / /	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00256	1	S283T006-10 PROX SNSR-LEFT NOSE DR CLOSED,SYS NO.2	287T4142 81205	1	32-61-13 0183/120/L025	ALL
S00256	2	S283T006-7 PROX SNSR-LEFT NOSE DR CLOSED,SYS NO.2	287T4142 81205	1	32-61-13 0183/120/L025	ALL
S00256	3	S283T006-2 PROX SNSR-LEFT NOSE DR CLOSED,SYS NO.2	287T4142 81205	1	32-61-13 0183/120/L025	150-157
S00256	4	S283T006-5 PROX SNSR-LEFT NOSE DR CLOSED,SYS NO.2	287T4142 81205	1	32-61-13 0183/120/L025	150-157
S00257	1	S283T006-10 PROX SNSR-RIGHT NOSE DR CLOSED,SYS NO.2	287T4142 81205	1	32-61-13 0169/148/R025	ALL
S00257	2	S283T006-7 PROX SNSR-RIGHT NOSE DR CLOSED,SYS NO.2	287T4142 81205	1	32-61-13 0169/148/R025	ALL
S00257	3	S283T006-2 PROX SNSR-RIGHT NOSE DR CLOSED,SYS NO.2	287T4142 81205	1	32-61-13 0169/148/R025	150-157
S00257	4	S283T006-5 PROX SNSR-RIGHT NOSE DR CLOSED,SYS NO.2	287T4142 81205	1	32-61-13 0169/148/R025	150-157
S00258	1	S283T006-28 PROX SNSR-LEFT SIDE BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-11 //	ALL
S00258	2	S283T006-8 PROX SNSR-LEFT SIDE BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-11 //	ALL
S00258	3	S283T006-3 PROX SNSR-LEFT SIDE BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-11 //	ALL
S00259	1	S283T006-10 PROX SNSR-LEFT DRAG BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-11 //	ALL
S00259	2	S283T006-7 PROX SNSR-LEFT DRAG BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-11 //	ALL
S00259	3	S283T006-2 PROX SNSR-LEFT DRAG BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-11 //	150-157
S00259	4	S283T006-5 PROX SNSR-LEFT DRAG BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-11 //	150-157
S00260	1	S283T006-33 PROX SNSR-LEFT LATCH LOCKED,SYS NO.2	287T4142 81205	1	32-61-11 //	ALL
S00260	2	S283T006-22 PROX SNSR-LEFT LATCH LOCKED,SYS NO.2	287T4142 81205	1	32-61-11 //	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 8

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00260	3	S283T006-5 PROX SNSR-LEFT LATCH LOCKED,SYS NO.2	287T4142 81205	1	32-61-11 //	150-157, 275-278
S00262	1	S283T006-28 PROX SNSR-RIGHT SIDE BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-12 //	ALL
S00262	2	S283T006-8 PROX SNSR-RIGHT SIDE BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-12 //	ALL
S00263	1	S283T006-10 PROX SNSR-RIGHT DRAG BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-12 //	ALL
S00263	2	S283T006-7 PROX SNSR-RIGHT DRAG BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-12 //	ALL
S00263	3	S283T006-2 PROX SNSR-RIGHT DRAG BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-12 //	150-157
S00263	4	S283T006-5 PROX SNSR-RIGHT DRAG BRACE DOWN,SYS NO.2	287T6104 81205	1	32-61-12 //	150-157
S00264	1	S283T006-33 PROX SNSR-RIGHT LATCH LOCKED,SYS NO.2	287T4142 81205	1	32-61-12 //	ALL
S00264	2	S283T006-22 PROX SNSR-RIGHT LATCH LOCKED,SYS NO.2	287T4142 81205	1	32-61-12 //	ALL
S00264	3	S283T006-5 PROX SNSR-RIGHT LATCH LOCKED,SYS NO.2	287T4142 81205	1	32-61-12 //	150-157
S00266	1	S283T006-10 PROX SNSR-NOSE GEAR NOT CPRS,SYS NO.2	287T6205 81205	1	32-09-12 //	ALL
S00266	2	S283T006-7 PROX SNSR-NOSE GEAR NOT CPRS,SYS NO.2	287T6205 81205	1	32-09-12 //	ALL
S00266	3	S283T006-2 PROX SNSR-NOSE GEAR NOT CPRS,SYS NO.2	287T6205 81205	1	32-09-12 //	150-157
S00266	4	S283T006-5 PROX SNSR-NOSE GEAR NOT CPRS,SYS NO.2	287T6205 81205	1	32-09-12 //	150-157
S00267	1	S283T006-33 PROX SNSR-LEFT GEAR TILTED,SYS NO.2	287T6104 81205	1	32-09-12 1046/050/L183	ALL
S00267	2	S283T006-10 PROX SNSR-LEFT GEAR TILTED,SYS NO.2	284T0270 81205	1	32-09-12 1046/050/L183	ALL
S00268	1	S283T006-33 PROX SNSR-RIGHT GEAR TILTED,SYS NO.2	287T6104 81205	1	32-09-12 1046/050/R183	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 9

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00268	2	S283T006-10 PROX SNSR-RIGHT GEAR TILTED,SYS NO.2	287T6104 81205	1	32-09-12 1046/050/R183	ALL
S00276	1	S283T006-7 SW-PROX,OUTBD,L OUTBD SLAT NO.1	284T0250 81205	1	27-88-12 L1083/14/FS	ALL
S00276	2	S283T006-10 SW-PROX,OUTBD,L OUTBD SLAT NO.1	284T0250 81205	1	27-88-12 L1083/14/FS	ALL
S00276	3	S283T006-2 SW-PROX,OUTBD,L OUTBD SLAT NO.1	284T0250 81205	1	27-88-12 L1083/14/FS	ALL
S00276	4	S283T006-5 SW-PROX,OUTBD,L OUTBD SLAT NO.1	284T0250 81205	1	27-88-12 L1083/14/FS	ALL
S00277	1	S283T006-7 SW-PROX,OUTBD,L OUTBD SLAT NO.2	284T0250 81205	1	27-88-12 L0934/14/FS	ALL
S00277	2	S283T006-10 SW-PROX,OUTBD,L OUTBD SLAT NO.2	284T0250 81205	1	27-88-12 L0934/14/FS	ALL
S00277	3	S283T006-2 SW-PROX,OUTBD,L OUTBD SLAT NO.2	284T0250 81205	1	27-88-12 L0934/14/FS	ALL
S00277	4	S283T006-5 SW-PROX,OUTBD,L OUTBD SLAT NO.2	284T0250 81205	1	27-88-12 L0934/14/FS	ALL
S00278	1	S283T006-7 SW-PROX,OUTBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0779/14/FS	050-099, 280-299
S00278	1	S283T006-10 SW-PROX,OUTBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0779/14/FS	150-199, 275-278
S00278	2	S283T006-10 SW-PROX,OUTBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0779/14/FS	ALL
S00278	3	S283T006-2 SW-PROX,OUTBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0779/14/FS	ALL
S00278	4	S283T006-5 SW-PROX,OUTBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0779/14/FS	ALL
S00279	1	S283T006-7 SW-PROX,OUTBD,L OUTBD SLAT NO.4	284T0250 81205	1	27-88-12 L0629/14/FS	ALL
S00279	2	S283T006-10 SW-PROX,OUTBD,L OUTBD SLAT NO.4	284T0250 81205	1	27-88-12 L0629/14/FS	ALL
S00279	3	S283T006-2 SW-PROX,OUTBD,L OUTBD SLAT NO.4	284T0250 81205	1	27-88-12 L0629/14/FS	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 10

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00279	4	S283T006-5 SW-PROX,OUTBD,L OUTBD SLAT NO.4	284T0250 81205	1	27-88-12 L0629/14/FS	ALL
S00280	1	S283T006-7 SW-PROX,OUTBD,L OUTBD SLAT NO.5	284T0250 81205	1	27-88-12 L0480/14/FS	ALL
S00280	2	S283T006-10 SW-PROX,OUTBD,L OUTBD SLAT NO.5	284T0250 81205	1	27-88-12 L0480/14/FS	ALL
S00280	3	S283T006-2 SW-PROX,OUTBD,L OUTBD SLAT NO.5	284T0250 81205	1	27-88-12 L0480/14/FS	ALL
S00280	4	S283T006-5 SW-PROX,OUTBD,L OUTBD SLAT NO.5	284T0250 81205	1	27-88-12 L0480/14/FS	ALL
S00281	1	S283T006-7 SW-PROX,INBD,L INBD SLAT NO.6	284T0250 81205	1	27-88-12 L0188/14/FS	ALL
S00281	2	S283T006-10 SW-PROX,INBD,L INBD SLAT NO.6	284T0250 81205	1	27-88-12 L0188/14/FS	ALL
S00281	3	S283T006-2 SW-PROX,INBD,L INBD SLAT NO.6	284T0250 81205	1	27-88-12 L0188/14/FS	ALL
S00281	4	S283T006-5 SW-PROX,INBD,L INBD SLAT NO.6	284T0250 81205	1	27-88-12 L0188/14/FS	ALL
S00282	1	S283T006-7 SW-PROX,INBD,L OUTBD SLAT NO.1	284T0250 81205	1	27-88-12 L1025/14/FS	ALL
S00282	2	S283T006-10 SW-PROX,INBD,L OUTBD SLAT NO.1	284T0250 81205	1	27-88-12 L1025/14/FS	ALL
S00282	3	S283T006-2 SW-PROX,INBD,L OUTBD SLAT NO.1	284T0250 81205	1	27-88-12 L1025/14/FS	ALL
S00282	4	S283T006-5 SW-PROX,INBD,L OUTBD SLAT NO.1	284T0250 81205	1	27-88-12 L1025/14/FS	ALL
S00283	1	S283T006-7 SW-PROX,INBD,L OUTBD SLAT NO.2	284T0250 81205	1	27-88-12 L0880/14/FS	ALL
S00283	2	S283T006-10 SW-PROX,INBD,L OUTBD SLAT NO.2	284T0250 81205	1	27-88-12 L0880/14/FS	ALL
S00283	3	S283T006-2 SW-PROX,INBD,L OUTBD SLAT NO.2	284T0250 81205	1	27-88-12 L0880/14/FS	ALL
S00283	4	S283T006-5 SW-PROX,INBD,L OUTBD SLAT NO.2	284T0250 81205	1	27-88-12 L0880/14/FS	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 11

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00284	1	S283T006-7 SW-PROX,INBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0733/14/FS	ALL
S00284	2	S283T006-10 SW-PROX,INBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0733/14/FS	ALL
S00284	3	S283T006-2 SW-PROX,INBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0733/14/FS	ALL
S00284	4	S283T006-5 SW-PROX,INBD,L OUTBD SLAT NO.3	284T0250 81205	1	27-88-12 L0733/14/FS	ALL
S00285	1	S283T006-7 SW-PROX,INBD,L OUTBD SLAT NO.4	284T0250 81205	1	27-88-12 L0581/14/FS	ALL
S00285	2	S283T006-10 SW-PROX,INBD,L OUTBD SLAT NO.4	284T0250 81205	1	27-88-12 L0581/14/FS	ALL
S00285	3	S283T006-2 SW-PROX,INBD,L OUTBD SLAT NO.4	284T0250 81205	1	27-88-12 L0581/14/FS	ALL
S00285	4	S283T006-5 SW-PROX,INBD,L OUTBD SLAT NO.4	284T0250 81205	1	27-88-12 L0581/14/FS	ALL
S00286	1	S283T006-7 SW-PROX,INBD,L OUTBD SLAT NO.5	284T0250 81205	1	27-88-12 L0437/14/FS	ALL
S00286	2	S283T006-10 SW-PROX,INBD,L OUTBD SLAT NO.5	284T0250 81205	1	27-88-12 L0437/14/FS	ALL
S00286	3	S283T006-2 SW-PROX,INBD,L OUTBD SLAT NO.5	284T0250 81205	1	27-88-12 L0437/14/FS	ALL
S00286	4	S283T006-5 SW-PROX,INBD,L OUTBD SLAT NO.5	284T0250 81205	1	27-88-12 L0437/14/FS	ALL
S00287	1	S283T006-7 SW-PROX,OUTBD,L INBD SLAT NO.6	284T0250 81205	1	27-88-12 L0314/14/FS	ALL
S00287	2	S283T006-10 SW-PROX,OUTBD,L INBD SLAT NO.6	284T0250 81205	1	27-88-12 L0314/14/FS	ALL
S00287	3	S283T006-2 SW-PROX,OUTBD,L INBD SLAT NO.6	284T0250 81205	1	27-88-12 L0314/14/FS	ALL
S00287	4	S283T006-5 SW-PROX,OUTBD,L INBD SLAT NO.6	284T0250 81205	1	27-88-12 L0314/14/FS	ALL
S00294	1	S283T006-7 SW-PROX,OUTBD,R OUTBD SLAT NO.12	284T0250 81205	1	27-88-22 R1083/14/FS	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 12

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00294	2	S283T006-10 SW-PROX,OUTBD,R OUTBD SLAT NO.12	284T0250 81205	1	27-88-22 R1083/14/FS	ALL
S00294	3	S283T006-2 SW-PROX,OUTBD,R OUTBD SLAT NO.12	284T0250 81205	1	27-88-22 R1083/14/FS	ALL
S00294	4	S283T006-5 SW-PROX,OUTBD,R OUTBD SLAT NO.12	284T0250 81205	1	27-88-22 R1083/14/FS	ALL
S00295	1	S283T006-7 SW-PROX,OUTBD,R OUTBD SLAT NO.11	284T0250 81205	1	27-88-22 R0934/14/FS	ALL
S00295	2	S283T006-10 SW-PROX,OUTBD,R OUTBD SLAT NO.11	284T0250 81205	1	27-88-22 R0934/14/FS	ALL
S00295	3	S283T006-2 SW-PROX,OUTBD,R OUTBD SLAT NO.11	284T0250 81205	1	27-88-22 R0934/14/FS	ALL
S00295	4	S283T006-5 SW-PROX,OUTBD,R OUTBD SLAT NO.11	284T0250 81205	1	27-88-22 R0934/14/FS	ALL
S00296	1	S283T006-7 SW-PROX,OUTBD,R OUTBD SLAT NO.10	284T0250 81205	1	27-88-22 R0779/14/FS	ALL
S00296	2	S283T006-10 SW-PROX,OUTBD,R OUTBD SLAT NO.10	284T0250 81205	1	27-88-22 R0779/14/FS	ALL
S00296	3	S283T006-2 SW-PROX,OUTBD,R OUTBD SLAT NO.10	284T0250 81205	1	27-88-22 R0779/14/FS	ALL
S00296	4	S283T006-5 SW-PROX,OUTBD,R OUTBD SLAT NO.10	284T0250 81205	1	27-88-22 R0779/14/FS	ALL
S00297	1	S283T006-7 SW-PROX,OUTBD,R OUTBD SLAT NO.9	284T0250 81205	1	27-88-22 R0629/14/FS	ALL
S00297	2	S283T006-10 SW-PROX,OUTBD,R OUTBD SLAT NO.9	284T0250 81205	1	27-88-22 R0629/14/FS	ALL
S00297	3	S283T006-2 SW-PROX,OUTBD,R OUTBD SLAT NO.9	284T0250 81205	1	27-88-22 R0629/14/FS	ALL
S00297	4	S283T006-5 SW-PROX,OUTBD,R OUTBD SLAT NO.9	284T0250 81205	1	27-88-22 R0629/14/FS	ALL
S00298	1	S283T006-7 SW-PROX,OUTBD,R OUTBD SLAT NO.8	284T0250 81205	1	27-88-22 R0480/14/FS	ALL
S00298	2	S283T006-10 SW-PROX,OUTBD,R OUTBD SLAT NO.8	284T0250 81205	1	27-88-22 R0480/14/FS	ALL

EQUIPMENT LIST

D280T132

Section S00200

Page 13

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00298	3	S283T006-2 SW-PROX,OUTBD,R OUTBD SLAT NO.8	284T0250 81205	1	27-88-22 R0480/14/FS	ALL
S00298	4	S283T006-5 SW-PROX,OUTBD,R OUTBD SLAT NO.8	284T0250 81205	1	27-88-22 R0480/14/FS	ALL
S00299	1	S283T006-7 SW-PROX,INBD,R INBD SLAT NO.7	284T0250 81205	1	27-88-22 R0188/14/FS	ALL
S00299	2	S283T006-10 SW-PROX,INBD,R INBD SLAT NO.7	284T0250 81205	1	27-88-22 R0188/14/FS	ALL
S00299	3	S283T006-2 SW-PROX,INBD,R INBD SLAT NO.7	284T0250 81205	1	27-88-22 R0188/14/FS	ALL
S00299	4	S283T006-5 SW-PROX,INBD,R INBD SLAT NO.7	284T0250 81205	1	27-88-22 R0188/14/FS	ALL

EQUIPMENT LIST

D280T132

Section S00200
Page 14 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00300	1	S283T006-7 SW-PROX,INBD,R OUTBD SLAT NO.12	284T0250 81205	1	27-88-22 R1025/14/FS	ALL
S00300	2	S283T006-10 SW-PROX,INBD,R OUTBD SLAT NO.12	284T0250 81205	1	27-88-22 R1025/14/FS	ALL
S00300	3	S283T006-2 SW-PROX,INBD,R OUTBD SLAT NO.12	284T0250 81205	1	27-88-22 R1025/14/FS	ALL
S00300	4	S283T006-5 SW-PROX,INBD,R OUTBD SLAT NO.12	284T0250 81205	1	27-88-22 R1025/14/FS	ALL
S00301	1	S283T006-7 SW-PROX,INBD,R OUTBD SLAT NO.11	284T0250 81205	1	27-88-22 R0880/14/FS	ALL
S00301	2	S283T006-10 SW-PROX,INBD,R OUTBD SLAT NO.11	284T0250 81205	1	27-88-22 R0880/14/FS	ALL
S00301	3	S283T006-2 SW-PROX,INBD,R OUTBD SLAT NO.11	284T0250 81205	1	27-88-22 R0880/14/FS	ALL
S00301	4	S283T006-5 SW-PROX,INBD,R OUTBD SLAT NO.11	284T0250 81205	1	27-88-22 R0880/14/FS	ALL
S00302	1	S283T006-7 SW-PROX,INBD,R OUTBD SLAT NO.10	284T0250 81205	1	27-88-22 R0733/14/FS	ALL
S00302	2	S283T006-10 SW-PROX,INBD,R OUTBD SLAT NO.10	284T0250 81205	1	27-88-22 R0733/14/FS	ALL
S00302	3	S283T006-2 SW-PROX,INBD,R OUTBD SLAT NO.10	284T0250 81205	1	27-88-22 R0733/14/FS	ALL
S00302	4	S283T006-5 SW-PROX,INBD,R OUTBD SLAT NO.10	284T0250 81205	1	27-88-22 R0733/14/FS	ALL
S00303	1	S283T006-7 SW-PROX,INBD,R OUTBD SLAT NO.9	284T0250 81205	1	27-88-22 R0581/14/FS	ALL
S00303	2	S283T006-10 SW-PROX,INBD,R OUTBD SLAT NO.9	284T0250 81205	1	27-88-22 R0581/14/FS	ALL
S00303	3	S283T006-2 SW-PROX,INBD,R OUTBD SLAT NO.9	284T0250 81205	1	27-88-22 R0581/14/FS	ALL
S00303	4	S283T006-5 SW-PROX,INBD,R OUTBD SLAT NO.9	284T0250 81205	1	27-88-22 R0581/14/FS	ALL
S00304	1	S283T006-7 SW-PROX,INBD,R OUTBD SLAT NO.8	284T0250 81205	1	27-88-22 R0437/14/FS	ALL

EQUIPMENT LIST

D280T132

Section S00300

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00304	2	S283T006-10 SW-PROX,INBD,R OUTBD SLAT NO.8	284T0250 81205	1	27-88-22 R0437/14/FS	ALL
S00304	3	S283T006-2 SW-PROX,INBD,R OUTBD SLAT NO.8	284T0250 81205	1	27-88-22 R0437/14/FS	ALL
S00304	4	S283T006-5 SW-PROX,INBD,R OUTBD SLAT NO.8	284T0250 81205	1	27-88-22 R0437/14/FS	ALL
S00305	1	S283T006-7 SW-PROX,OUTBD,R INBD SLAT NO.7	284T0250 81205	1	27-88-22 R0314/14/FS	ALL
S00305	2	S283T006-10 SW-PROX,OUTBD,R INBD SLAT NO.7	284T0250 81205	1	27-88-22 R0314/14/FS	ALL
S00305	3	S283T006-2 SW-PROX,OUTBD,R INBD SLAT NO.7	284T0250 81205	1	27-88-22 R0314/14/FS	ALL
S00305	4	S283T006-5 SW-PROX,OUTBD,R INBD SLAT NO.7	284T0250 81205	1	27-88-22 R0314/14/FS	ALL
S00312		141SM2T2 SW-LEADING EDGE SLAT	253T5150 91929	1	22-32-13 P010-00/ /	ALL
S00315		S271T454-1 SW-ENG HYD PUMP R FILTER MODULE TEMP	271T0068 81205	1	29-32-11 NR266/152/	ALL
S00316		S271T454-1 SW-ENG HYD PUMP L FILTER MODULE TEMP	271T0068 81205	1	29-32-11 NL266/152/	ALL
S00317		S271T454-1 SW-AIR HYD PUMP FILTER MODULE TEMP	271T0068 81205	1	29-32-11 1049/183/L007	ALL
S00319		MS25306-232 SW-R MN WW LT	284T0550 96906	1	33-31-11 0953/115/R035	ALL
S00320		2PB11-H58 SW-CLOCK,CAPT	233T8200 91929	1	31-25-11 P007-00/ /	ALL
S00321		2PB11-H58 SW-CLOCK,F/O	233T8200 91929	1	31-25-11 P007-00/ /	ALL
S00324		MS24658-23D SW-NOSE GEAR WHEEL WELL LT	284T0719 96906	1	33-31-11 P040-00/ /	ALL
S00326		60B40072-5 SW-CARGO HDLG CONTROL,FWD COMPT	284T0216 81205	1	25-53-11 P024-00/175/	050-099
S00326		60B40072-5 SW-CARGO HDLG CONTROL,FWD COMPT	284T0216 81205	1	25-53-11 P024-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section S00300

Page 2

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00327		60B40072-5 SW-CARGO HDLG CONTROL,AFT	284T0216 81205	1	25-53-21 P027-00/ /	050-099
S00327		60B40072-5 SW-CARGO HDLG CONTROL,AFT	284T0216 81205	1	25-53-21 P027-00/ /618	150-199, 275-299
S00330		S271T452-3 SW-HYDRAULIC PRESSURE,T/R	271T5270 81205	1	78-36-11 NL269/148/	ALL
S00331		S271T452-3 SW-HYDRAULIC PRESSURE,T/R	271T5270 81205	1	78-36-21 NR273/148/	ALL
S00332		60B50024-3 SW-WATER PRESSURE CUT-OUT	417T2037 81205	1	38-15-11 1560/196/R042	050-099
S00332		60B50024-3 SW-WATER PRESSURE CUT-OUT	417T2037 81205	1	38-15-11 1560/192/R042	150-199, 275-299
S00333		8AS193 SW-COMPRESSOR INTERLOCK	417T2126 91929	1	38-15-11 1550/247/R077	050-099
S00333		8AS193 SW-COMPRESSOR INTERLOCK	417T2126 91929	1	38-15-11 1546/247/R068	150-199
S00334		10AT96-1 SW-COLUMN FWD,LEFT	253T2144 82647	1	27-41-11 0173/195/L034	ALL
S00335		10AT96-1 SW-COLUMN AFT(ELEV TE UP),LEFT	253T2144 82647	1	27-41-11 0173/195/L034	ALL
S00336		10AT96-1 SW-COLUMN AFT(ELEV TE UP),LEFT	253T2144 82647	1	27-41-11 0173/195/L034	050-099
S00337		10AT96-1 SW-COLUMN FWD,RIGHT	253T2144 82647	1	27-41-21 0173/195/R037	ALL
S00338		10AT96-1 SW-COLUMN AFT(ELEV TE UP),RIGHT	253T2144 82647	1	27-41-21 0173/195/R037	ALL
S00339		10AT96-1 SW-COLUMN AFT(ELEV TE UP),RIGHT	253T2144 82647	1	27-41-21 0173/195/R037	050-099
S00341		S271T462-1 SW-REMOTE HYD QTY SELECT	271T4620 81205	1	29-33-11 1127/120/R060	ALL
S00343		214C40-1-77 SW-ALTITUDE PRESSURE	417T1322 02750	1	38-32-11 1629/171/R047	ALL
S00344		214C40-1-77 SW-ALTITUDE PRESSURE	417T1322 02750	1	38-32-11 1629/171/R048	ALL

EQUIPMENT LIST

D280T132

Section S00300

Page 3

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00345		MS24523-22 SW-FUELING POWER SELECT	344T0021 96906	1	28-21-11 P028-00/ /	ALL
S00346		60B40018-42 SW-FUELING PWR CONT	284T0562 81205	1	28-21-11 FSS0672/12/FS	ALL
S00347		MS25089-1CR SW-OVERFILL RESET	344T0021 96906	1	28-21-12 P028-00/ /	ALL
S00348		1TL82-2 SW-FUELING VALVE CONTROL,L TANK	344T0021 82647	1	28-21-11 P028-00/ /	ALL
S00349		1TL82-2 SW-FUELING VALVE CONTROL,R TANK	344T0021 82647	1	28-21-11 P028-00/ /	ALL
S00350		MS24523-22 SW-DEFUELING VALVE CONTROL,LEFT	344T0021 96906	1	28-26-11 P028-00/ /	ALL
S00351		MS24523-22 SW-DEFUELING VALVE CONTROL,RIGHT	344T0021 96906	1	28-26-11 P028-00/ /	ALL
S00352		60B40018-42 SW-SERVICE PANEL DOOR	417T1323 81205	1	38-32-11 1572/140/L005	ALL
S00353		60B40018-42 SW-SERVICE PANEL DOOR	417T1323 81205	1	38-32-11 1572/140/L005	ALL
S00354		MS25306-232 SW-CAR. DR E/E BAY LT	284T0388 96906	1	33-31-41 0353/160/R040	ALL
S00355		MS25307-232 SW-GND E/E BAY LT	284T0388 96906	1	33-31-41 0303/126/R009	ALL
S00356		MS25306-232 SW-IN FLT E/E BAY LT	284T0388 96906	1	33-31-41 0308/199/L055	ALL
S00357		MS25306-222 SW-FWD E/E BAY LT	284T0388 96906	1	33-31-41 0145/168/0000	ALL
S00358	1	3000-46-29 SW-OVERHEAT,AIR SUPPLY,LEFT	312T3201 97896	1	36-22-11 N 215/151/L010	ALL
S00358	2	975-0172-006 SW-OVERHEAT,AIR SUPPLY,LEFT	312T3201 97896	1	36-22-11 N 215/151/L010	ALL
S00359	1	3000-46-29 SW-OVERHEAT,AIR SUPPLY,RIGHT	312T3201 97896	1	36-22-11 N 215/151/R010	ALL
S00359	2	975-0172-006 SW-OVERHEAT,AIR SUPPLY,RIGHT	312T3201 97896	1	36-22-11 N 215/151/R010	ALL

EQUIPMENT LIST

D280T132

Section S00300

Page 4

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00361		MS25306-222 SW-LEFT AIR COND COMPT LIGHTS	284T0657 96906	1	33-31-21 0863/115/L010	ALL
S00362		MS25306-222 SW-RIGHT AIR COND COMPT LIGHTS	284T0657 96906	1	33-31-21 0863/118/R062	ALL
S00363		3000-46-15 SW-TEMP,CARGO OVHT,FWD	215T2001 14604	1	21-43-11 0633/118/R002	050-099, 150-199, 275-276, 280-299
S00363		3000-46-15 SW-TEMP,CARGO OVHT,FWD	215T2001 14604	1	21-43-11 0634/123/R003	277-278
S00364		3000-46-14 SW-THERMAL,CARGO TEMP,FWD	215T2001 14604	1	21-43-11 0633/118/L002	050-099, 162-199, 280-299
S00364		3000-46-14 SW-THERMAL,CARGO TEMP,FWD	215T2001 14604	1	21-43-11 0634/117/R003	150-157, 275-276
S00364		3000-46-14 SW-THERMAL,CARGO TEMP,FWD	215T2001 14604	1	21-43-11 0634/123/L003	277-278
S00365	1	1EN575-6 SW-RAT. DOWN LIMIT	284T0247 91929	1	29-21-31 1155/129/R075	ALL
S00365	2	1EN61-6 SW-RAT. DOWN LIMIT	284T0247 91929	1	29-21-31 1155/129/R075	ALL
S00366		MS24523-28 SW-RAM AIR TURBINE RETRACT SELECT	258T7200 96906	1	29-21-31 1045/133/R005	ALL
S00367		S271T452-1 SW-RAM AIR TURBINE HYDRAULIC PRESS.	258T7200 81205	1	29-21-31 1055/138/R045	ALL
S00369		1EN61-6 SW-RAT. UP LIMIT	284T0247 91929	1	29-21-31 1155/129/R075	ALL
S00371		10AT97-3 SWITCH-ARMING,AUTO SPEED BRAKE	253T1200 82647	1	27-62-11 P010-00/ /	ALL
S00374		10AT96-2 SW-ENG THRUST REV	253T5400 82647	1	27-62-11 P010-00/ /	ALL
S00379		MS25306-222 SW-BULK CARGO EXTERIOR LIGHTS	284T0196 96906	1	33-31-61 1410/175/L 84	050-099, 150-199
S00383		MS24524-23 SW-PDU,FWD DRIVE BAYS	284T0687 96906	1	25-53-13 P035-00/ /	050-099
S00384		MS27406-1 SW-PDU,AFT DRIVE BAYS	284T0687 96906	1	25-53-13 P035-00/ /	050-099

EQUIPMENT LIST

D280T132

Section S00300

Page 5

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00387		MS24523-23 SW-FWD LATL GUIDES	284T0687 96906	1	25-53-15 P035-00/ /	050-099
S00388		MS24523-23 SW-AFT LATL GUIDES	284T0687 96906	1	25-53-15 P035-00/ /	050-099
S00392		MS27406-1 SW-PDU,FWD DRIVE BAYS	284T0688 96906	1	25-53-23 P039-00/ /	050-099
S00394		MS24523-23 SW-AFT LATL GUIDES	284T0688 96906	1	25-53-25 P039-00/ /	050-099
S00395		MS24523-23 SW-FWD LATL GUIDES	284T0688 96906	1	25-53-25 P039-00/ /	050-099
S00397		S210T130-27 SW-ALTITUDE	213T1002 81205	1	21-51-12 0790/123/L020	050-099, 150-199, 275-278
S00397		S210T130-27 SW-ALTITUDE	213T1002 81205	1	21-51-12 0770/123/L020	280-299
S00398		3000-46-24 SW-OVERHEAT,L WING TAI	218T1001 14604	1	30-11-11 L0440/14/LE	150-154, 275-299
S00399		3000-46-24 SW-OVERHEAT,R WING TAI	218T1001 14604	1	30-11-11 R0440/14/LE	150-154, 275-299

EQUIPMENT LIST

D280T132

Section S00300

Page 6 End

Jun 06/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00400		8G1270 SW-PRESSURE,L WING TAI	218T1001 09049	1	30-11-11 L0440/14/LE	ALL
S00401		8G1270 SW-PRESSURE,R WING TAI	218T1001 09049	1	30-11-11 R0440/14/LE	ALL
S00402	1	8836K4 SW-FWD CAR. COMPT LTS,INT SW	284T0687 27193	1	33-37-11 P035-00/ /	ALL
S00402	2	MS25306-232 SW-FWD CAR. COMPT LTS,INT SW	284T0687 27193	1	33-37-11 P035-00/ /	ALL
S00403		MS24331-3 SW-FWD CAR. COMPT LTS,E/E ACCESS DOOR	284T0388 96906	1	33-37-11 0355/188/R064	ALL
S00410		MS27407-6 SW-ENTRY DOOR CONTROL,FWD	284T0258 96906	1	52-11-12 0280/230/L085	ALL
S00411		MS27406-3 SW-CAR. DR CONT,FWD	284T0687 96906	1	52-34-12 P035-00/ /	ALL
S00413		MS27406-3 SW-CAR. DR CONT,AFT	284T0688 96906	1	52-35-12 P039-00/ /	ALL
S00414		MS27407-3 SW-CAR. DR CONT ARMING,AFT	284T0688 96906	1	52-35-12 P039-00/ /	ALL
S00415		S271T452-1 SW-ALTERNATE VALVE SELECT PRESS.	274T4620 81205	1	32-41-11 1032/184/L003	ALL
S00416		MS25089-1CRL SW-OVERFILL SYS TEST	344T0021 96906	1	28-21-12 P028-00/ /	ALL
S00417		1TL82-2 SW-FUELING VALVE CONT,AUX TANK	344T0021 82647	1	28-21-11 P028-00/ /	ALL
S00418		MS25089-2CR SW-LOAD SET,L TANK	344T0021 96906	1	28-21-11 P028-00/ /	ALL
S00419		MS25089-2CR SW-LOAD SET,R TANK	344T0021 96906	1	28-21-11 P028-00/ /	ALL
S00420		MS25089-2CR SW-LOAD SET,AUX TANK	344T0021 96906	1	28-21-11 P028-00/ /	ALL
S00421		MS25089-2CR SW-TEST,FUELING SHUTOFF SYSTEM	344T0021 96906	1	28-21-11 P028-00/ /	ALL
S00423	1	60B92400-7 SW-PRESS.,FUEL OVRD PUMP,L AUX TANK	343T0002 81205	1	28-42-12 L WING/ /RS	ALL

EQUIPMENT LIST

D280T132

Section S00400

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00423	2	60B92400-3 SW-PRESS.,FUEL OVRD PUMP,L AUX TANK	343T0002 81205	1	28-42-12 L WING/ /RS	ALL
S00424	1	60B92400-7 SW-PRESS.,FUEL OVRD PUMP,R AUX TANK	343T0002 81205	1	28-42-12 R WING/ /RS	ALL
S00424	2	60B92400-3 SW-PRESS.,FUEL OVRD PUMP,R AUX TANK	343T0002 81205	1	28-42-12 R WING/ /RS	ALL
S00426		MS25089-1C SW-FLIGHT DECK CALL	284T0719 81640	1	23-43-11 P040-00/ /	ALL
S00427		MS25306-222 SW-TAILCONE COMPT LT	284T0549 96906	1	33-31-31 1680/185/R048	ALL
S00428		MS25306-222 SW-APU COMPT LTS	284T0559 96906	1	33-31-31 1834/217/R017	ALL
S00429	1	MS25307-232 SW-AFT CAR. COMPT LTS,INT	284T0688 96906	1	33-37-21 P039-00/ /	ALL
S00429	2	8836K4 SW-AFT CAR. COMPT LTS,INT	284T0688 96906	1	33-37-21 P039-00/ /	ALL
S00430	1	8836K4 SW-BULK COMPT LTS	284T0196 27193	1	33-37-21 1410/175/L083	ALL
S00430	2	MS25306-232 SW-BULK COMPT LTS	284T0196 27193	1	33-37-21 1410/175/L083	ALL
S00431		214C40-1-71 SW-CABIN ALTITUDE WARNING	216T1001 02750	1	21-33-11 0331/182/R045	ALL
S00435		MS25306-212 SW-NIGHT LTS FLEXIBILITY STA 631	285T0019 96906	1	33-21-21 P019-00/ /	275-299
S00443		MS25306-222 SW-TAILCONE COMPT LT	284T0551 96906	1	33-31-31 1812/202/R012	ALL
S00452		S271T452-1 SW-PRESS.,L GEAR TILT	272T1248 81205	1	27-62-11 L0348/009/RS	ALL
S00453		S271T452-1 SW-PRESS.,R GEAR TILT	272T1248 81205	1	27-62-11 R0348/009/RS	ALL
S00454		32V92 SW-SMK DET AIR FL PRESS.,FWD	453T2101 09049	1	26-16-21 0351/173/L070	ALL
S00455		32V92 SW-SMK DET AIR FL PRESS.,AFT	453T2201 09049	1	26-16-21 1406/158/L070	ALL

EQUIPMENT LIST

D280T132

Section S00400

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00456		3000-46-14 SW-EQUIPMENT COOLING SKIN TEMPERATURE	215T3001 14604	1	21-58-11 0410/167/L090	150-199, 275-276
S00456		3000-46-14 SW-EQUIPMENT COOLING SKIN TEMPERATURE	215T3001 14604	1	21-58-12 0410/167/L089	277-299
S00457		MS25089-2CR SW-TEST,FUEL INDICATOR	344T0021 96906	1	28-41-11 P028-00/ /	ALL
S00459		MS25008-1 SW-PARK BRAKE	253T3100 96906	1	32-44-11 0151/188/L025	ALL
S00460		60B40018-43 SW-FLIGHT DECK DOOR	232T2009 81205	1	33-22-41 0240/276/L017	ALL
S00466		MS24658-27E SW-EMER LIGHTS TEST	284T0719 96906	1	33-51-21 P040-00/ /	ALL
S00467		214C40-1-71 SW-PRESSURE	284T0186 02750	1	33-24-11 P019-00/TOP/	ALL
S00468		MS25307-232 SW-MN WW LT,L	284T0550 96906	1	33-31-11 0955/115/L035	ALL
S00482	1	S231T290-5001 SW-ADC INSTR SOURCE SELECT,CAPT	233T2200 81205	1	34-12-61 P001-01/ /	050-099
S00482	1	S231T290-2001 SW-ADC INSTR SOURCE SELECT,CAPT	233T2200 81205	1	34-12-61 P001-01/ /	150-152
S00482	1	S231T290-4001 SW-ADC INSTR SOURCE SELECT,CAPT	233T2200 81205	1	34-12-61 P001-01/ /	153-199, 275-299
S00482	2	S231T290-4001 SW-ADC INSTR SOURCE SELECT,CAPT	233T2200 81205	1	34-12-61 P001-01/ /	050-099
S00482	2	S231T290-1001 SW-ADC INSTR SOURCE SELECT,CAPT	233T2200 81205	1	34-12-61 P001-01/ /	150-152
S00482	2	S231T290-5001 SW-ADC INSTR SOURCE SELECT,CAPT	233T2200 81205	1	34-12-61 P001-01/ /	153-199, 275-299
S00483	1	S231T290-5001 SW-ADC INSTR SOURCE SELECT,F/O	233T2204 81205	1	34-12-62 P003-03/ /	050-099
S00483	1	S231T290-2001 SW-ADC INSTR SOURCE SELECT,F/O	233T2204 81205	1	34-12-62 P003-03/ /	150-152
S00483	1	S231T290-4001 SW-ADC INSTR SOURCE SELECT,F/O	233T2204 81205	1	34-12-62 P003-03/ /	153-199, 275-299

EQUIPMENT LIST

D280T132

Section S00400

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00483	2	S231T290-4001 SW-ADC INSTR SOURCE SELECT,F/O	233T2204 81205	1	34-12-62 P003-03/ /	050-099
S00483	2	S231T290-1001 SW-ADC INSTR SOURCE SELECT,F/O	233T2204 81205	1	34-12-62 P003-03/ /	150-152
S00483	2	S231T290-5001 SW-ADC INSTR SOURCE SELECT,F/O	233T2204 81205	1	34-12-62 P003-03/ /	153-199, 275-299
S00484		1HE49 SW-APU FIRE SHUTDOWN	91929	1	49-61-11 P040-00/ /	ALL
S00485		1HE48 SW-APU BOTTLE DISCHARGE	91929	1	26-22-21 P040-00/ /	ALL
S00486		1HE48 SW-APU BOTTLE DISCHARGE	91929	1	26-22-21 P040-00/ /	275-299
S00493		10AT304-1 SW-SPOILER HANDLE POSITION	253T1200 91929	1	31-51-41 P010-00/ /	ALL
S00494		GBC-300-87 SW-BAROMETRIC,LEFT	312T3258 70192	1	75-23-11 STRUT/ /	ALL
S00495		GBC-300-87 SW-BAROMETRIC,RIGHT	312T3258 70192	1	75-23-11 STRUT/ /	ALL
S00498		3000-46-14 SW-THERMAL,CARGO NORM TEMP,BULK	215T2003 14604	1	21-44-21 1514/173/R067	ALL
S00499		3000-46-21 SW-THERMAL,CARGO HIGH TEMP,BULK	215T2003 14604	1	21-44-21 1514/170/R067	ALL

EQUIPMENT LIST

D280T132

Section S00400

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00500		3000-46-15 SW-TEMP,CARGO OVHT,BULK	215T2003 14604	1	21-44-21 1512/173/R067	ALL
S00501	1	1EN575-6 SW-RAT. OVERRIDE LIMIT	284T0247 91929	1	29-21-31 1155/129/R075	ALL
S00501	2	1EN61-6 SW-RAT. OVERRIDE LIMIT	284T0247 91929	1	29-21-31 1155/129/R075	ALL
S00506	1	60B40018-43 SW-APU INLET DOOR OPEN	353T0106 81205	1	49-15-11 1750/283/R032	ALL
S00506	2	60B40018-42 SW-APU INLET DOOR OPEN	353T0106 81205	1	49-15-11 1750/283/R032	ALL
S00507		S231T290-4042 LIGHTED SW-MSTR WRN AND CAUT,CAPT	233T8200 81205	1	31-51-21 P007-00/ /	ALL
S00508		S231T290-4042 LIGHTED SW-MSTR WRN AND CAUT,F/O	233T8200 81205	1	31-51-21 P007-00/ /	ALL
S00510		4TL82-72 SW-CARGO DR CONT ARM,AFT	284T0566 91929	1	52-35-12 P044-00/ /	ALL
S00511		4TL82-72 SW-CARGO DR CONT,FWD	284T0923 91929	1	52-34-12 P043-00/ /	ALL
S00512		4TL82-72 SW-CARGO DR CONT,AFT	284T0566 91929	1	52-35-12 P044-00/ /	ALL
S00513		8836K4 SW-FWD CAR. COMPT LTS,EXT	284T0923 27193	1	33-37-11 P043-00/ /	050-099
S00513		MS25306-232 SW-FWD CAR. COMPT LTS,EXT	284T0923 96906	1	33-37-11 P043-00/ /	150-199, 275-299
S00514	1	MS25306-232 SW-AFT CAR. COMPT LTS,EXT	284T0566 96906	1	33-37-21 P044-00/ /	ALL
S00514	2	8836K4 SW-AFT CAR. COMPT LTS,EXT	284T0566 96906	1	33-37-21 P044-00/ /	ALL
S00515		MS25306-222 SW-CARGO EXT AREA LTS,FWD (LARGE DOOR)	284T0923 96906	1	33-31-61 P043-00/ /	ALL
S00516	1	8836K4 SW-CARGO EXT AREA LIGHTS,AFT	284T0566 96906	1	33-31-61 P044-00/ /	ALL
S00516	2	MS25306-232 SW-CARGO EXT AREA LIGHTS,AFT	284T0566 96906	1	33-31-61 P044-00/ /	ALL

EQUIPMENT LIST

D280T132

Section S00500

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00521		141SM2T2 SW-LEADING EDGE SLAT,LEFT	253T5700 74059	1	22-12-11 P010-00/ /	ALL
S00522		141SM2T2 SW-LEADING EDGE SLAT,RIGHT	253T5700 74059	1	22-12-21 P010-00/ /	ALL
S00523		141SM2T2 SW-LEADING EDGE SLAT,CENTER	253T5700 74059	1	22-12-31 P010-00/ /	ALL
S00524		21SN41-42 SW-ENGINE INLET TAI PRESS.,L	312T1203 02750	1	30-21-11 STRUT/ /	ALL
S00525		21SN41-42 SW-ENGINE INLET TAI PRESS.,R	312T1203 02750	1	30-21-11 STRUT/ /	ALL
S00526		L18366-12 SW-LIGHT,CLOSET	417T5082 24385	1	33-22-21 0840/262/L023	050-099
S00526		L18366-12 SW-LIGHT,CLOSET	417T5082 24385	1	33-22-21 0654+120/262/L023	151-152
S00528		MS24524-23 SW-OFF WING ESCAPE SYS DISABLE,L	284T0501 96906	1	25-65-11 0868/262/L089	050-099
S00529		MS24524-23 SW-OFF WING ESCAPE SYS DISABLE,R	284T0501 96906	1	25-65-12 0868/262/R089	050-099
S00530		MS24524-23 SW-OFF WING ESCAPE SYS AUTO ARM,L	284T0501 96906	1	25-65-11 0869/258/L089	050-099
S00531		MS24524-23 SW-OFF WING ESCAPE SYS AUTO ARM,R	284T0501 96906	1	25-65-12 0869/258/R089	050-099
S00532		MS24524-23 SW-OFF WING ESCAPE SYS AUTO FIRE,L	284T0501 96906	1	25-65-11 0868/258/L089	050-099
S00533		MS24524-23 SW-OFF WING ESCAPE SYS AUTO FIRE,R	284T0501 96906	1	25-65-12 0868/258/R089	050-099
S00538		10AT96-1 SW-STABILIZER TRIM	253T5400 82647	1	27-41-11 P010-00/ /	150-154
S00540		L18366-12 SW-LIGHT,CLOSET	417T5082 24385	1	33-22-21 0840/262/R023	050-099
S00540		L18366-12 SW-LIGHT,CLOSET	417T5082 24385	1	33-22-21 0654+120/262/R023	151-152
S00547	5	S231T290-2075 SW-RESERVE BRAKES & STEERING SELECT	233T2222 81205	1	29-21-32 P001-03/ /	ALL

EQUIPMENT LIST

D280T132

Section S00500

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00547	1	S231T290-4075 SW-RESERVE BRAKES & STEERING SELECT	233T2222 81205	1	29-21-32 P001-03/ /	ALL
S00547	2	S231T290-5075 SW-RESERVE BRAKES & STEERING SELECT	233T2222 81205	1	29-21-32 P001-03/ /	ALL
S00547	3	S231T290-3075 SW-RESERVE BRAKES & STEERING SELECT	233T2222 81205	1	29-21-32 P001-03/ /	ALL
S00547	4	S231T290-1075 SW-RESERVE BRAKES & STEERING SELECT	233T2222 81205	1	29-21-32 P001-03/ /	ALL
S00547 A		MS25237-387 LAMP-28V	233T2222 96906	2	29-21-32 / /	ALL
S00547 B		MS24515-685AS15 LAMP-5V	233T2222 96906	2	29-21-32 / /	ALL
S00547 D		851-30768-823 DIODE/FUSE ASSY	233T2222 96182	1	29-21-32 / /	ALL
S00549	1	C2006-CB SW-INTPH PTT,CAPT	253T2121 78048	1	23-51-11 0170/235/L035	ALL
S00549	2	C2006-RCB SW-INTPH PTT,CAPT	253T2121 78048	1	23-51-11 0170/235/L035	ALL
S00550	1	C2006-CB SW-R/T PTT,CAPT	253T2121 78048	1	23-51-11 0170/235/L035	ALL
S00551		P8-4000003 SW-INT PTT,F/O	253T2121 21645	1	23-51-21 0170/235/R025	ALL
S00551	1	C2006-CB SW-INT PTT,F/O	253T2121 78048	1	23-51-21 0170/235/R025	ALL
S00552		P8-4000003 SW-R/T PTT,F/O	253T2121 21645	1	23-51-21 0170/235/R025	ALL
S00552	1	C2006-CB SW-R/T PTT,F/O	253T2121 78048	1	23-51-21 0170/235/R025	ALL
S00553		8AS193 SW-COMPRESSOR INTERLOCK	417T2021 91929	1	38-15-11 1550/190/R066	ALL
S00555		AR61137-1 SW-L PACK COMPRESSOR OVERHEAT	213T1001 81205	1	21-51-11 0879/124/L034	050-099, 150-199, 275-278
S00555		AR641137-1 SW-L PACK COMPRESSOR OVERHEAT	213T1001 81205	1	21-51-11 0879/124/L034	280-299

EQUIPMENT LIST

D280T132

Section S00500

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00556		641137-1 SW-R PACK COMPRESSOR OVERHEAT	213T1001 81205	1	21-51-21 0879/124/R044	ALL
S00563		MS24525-23 SW-PALLET HDLG	284T3501 96906	1	25-53-13 P035-00/ /	ALL
S00572		MS27408-3E SW-AIR HYD PUMP TEST/RESET	284T0187 96906	1	29-11-32 P036-00/ /	ALL
S00575		10AT96-1 SW-STABILIZER TRIM	253T5400 82647	1	31-31-15 0172/220/L005	150-154
S00591		MS24525-23 SW-ALTERNATE VMO/MMO SELECT	284T0919 96906	1	34-12-12 0328/146/L048	275-299
S00598		AC45-0031 SELECT SW-ALT FLAP POSITION	233T2223 91812	1	27-51-11 P003-01/ /	ALL

EQUIPMENT LIST

D280T132

Section S00500

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00601		S231T290-4001 SW-TE FLAP ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	150-199, 275-299
S00601	1	S231T290-4001 SW-TE FLAP ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	050-099
S00601	2	S231T290-5001 SW-TE FLAP ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	050-099
S00601	3	S231T290-3001 SW-TE FLAP ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	050-099
S00602		S231T290-4001 SW-LE SLAT ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	150-199, 275-299
S00602	1	S231T290-4001 SW-LE SLAT ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	050-099
S00602	2	S231T290-5001 SW-LE SLAT ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	050-099
S00602	3	S231T290-3001 SW-LE SLAT ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	050-099
S00602	4	S231T290-1001 SW-LE SLAT ARM,ALT	233T2223 H6389	1	27-81-11 P003-01/ /	050-099
S00603		S231T290-2057 SW-LIGHT GPWS FLAP OVRD	233T2223 81205	1	34-46-12 P003-01/ /	ALL
S00604		S231T290-2057 SW-GND PROX/CONFIG GEAR OVRD	233T2223 81205	1	31-51-31 P003-01/ /	ALL
S00605		MS24524-23 SW-LDG GR ALTN EXTENSION SELECT	233T2223 96906	1	32-35-11 P003-01/ /	ALL
S00606		MS25011-2 SW-LDG GR ALTN RETR LIMIT	257T3501 96906	1	32-35-11 0240/200/L040	ALL
S00607		MS25011-2 SW-LDG GR ALTN EXT LIMIT	257T3501 96906	1	32-35-11 0240/200/L040	ALL
S00612	9	1TL-187-3 SW-EICAS MAINT ENABLE BYPASS	284T0919 81205	1	31-41-13 0267/158/L060	050-099, 150-155, 162-199, 275-299
S00612		1TL-187-3 SW-EICAS MAINT ENABLE BYPASS	284T0919 81205	1	31-41-13 0267/158/L060	ALL
S00613		75D106 SWITCH-EQUIP COOL DIFF PRESS.	215T3001 09049	1	21-58-16 0325/188/L002	ALL

EQUIPMENT LIST

D280T132

Section S00600

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00614		6510 SW-AIRSPEED	233T9110 07147	1	29-21-31 0212/201/R065	ALL
S00616		64AT34-3D SW-HDG REF	233T2220 91929	1	34-22-36 P003-01/ /	ALL
S00617		MS24524-23 SW-OFF-WING ESCAPE SYS DISABLE,R AFT	284T0501 96906	1	25-65-12 0913/262/R088	150-199, 275-299
S00618		MS24524-23 SW-OFF-WING ESCAPE SYS DISABLE,L AFT	284T0501 96906	1	25-65-11 0913/262/L088	150-199, 275-299
S00619		MS24524-23 SW-OFF-WING ESCAPE SYS DISABLE,R FWD	284T0501 96906	1	25-65-12 0868/262/R088	150-199, 275-299
S00620		MS24524-23 SW-OFF-WING ESCAPE SYS DISABLE,L FWD	284T0501 96906	1	25-65-11 0868/262/L088	150-199, 275-299
S00621		MS24524-23 SW-OFF-WING ESCAPE SYS AUTO ARM,R AFT	284T0501 96906	1	25-65-12 0913/258/R089	150-199, 275-299
S00622		MS24524-23 SW-OFF-WING ESCAPE SYS AUTO ARM,L AFT	284T0501 96906	1	25-65-11 0913/258/L089	150-199, 275-299
S00623		MS24524-23 SW-OFF-WING ESCAPE SYS AUTO ARM,R FWD	284T0501 96906	1	25-65-12 0869/258/R089	150-199, 275-299
S00624		MS24524-23 SW-OFF-WING ESCAPE SYS AUTO ARM,L FWD	284T0501 96906	1	25-65-11 0869/258/L089	150-199, 275-299
S00625		MS24524-23 SW-OFF-WING ESCAPE SYS AUTO FIRE,R AFT	284T0501 96906	1	25-65-12 0912/258/R089	150-199, 275-299
S00626		MS24524-23 SW-OFF-WING ESCAPE SYS AUTO FIRE,L AFT	284T0501 96906	1	25-65-11 0912/258/L089	150-199, 275-299
S00627		MS24524-23 SW-OFF-WING ESCAPE SYS AUTO FIRE,R FWD	284T0501 96906	1	25-65-12 0868/258/R089	150-199, 275-299
S00628		MS24524-23 SW-OFF-WING ESCAPE SYS AUTO FIRE,L FWD	284T0501 96906	1	25-65-11 0869/258/L089	150-199, 275-299
S00629		MS24524-23 SW-OFF-WING ESCAPE SYS BACKUP ARM,R FWD	284T0498 96906	1	25-65-12 0879/258/R090	150-199, 275-299
S00630		MS24524-23 SW-OFF-WING ESCAPE SYS BACKUP ARM,L FWD	284T0498 96906	1	25-65-11 0879/258/L090	150-199, 275-299
S00631		MS24524-23 SW-OFF-WING ESCAPE SYS BACKUP FIRE,R FWD	284T0498 96906	1	25-65-12 0879/258/R089	150-199, 275-299

EQUIPMENT LIST

D280T132

Section S00600

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00632		MS24524-23 SW-OFF-WING ESCAPE SYS BACKUP FIRE,L FWD	284T0498 96906	1	25-65-11 0879/258/L089	150-199, 275-299
S00633		7GR159 SW-PRESSURE,FWD CARGO FEXT DISCH LINE	453T2601 09049	1	26-23-11 0674/168/R068	050-099
S00633		7GR159 SW-PRESSURE,FWD CARGO FEXT DISCH LINE	453T2601 09049	1	26-23-11 0654+88/145/R068	150-154
S00633		7GR159 SW-PRESSURE,FWD CARGO FEXT DISCH LINE	453T2601 09049	1	26-23-11 0654+86/171/R066	155-199, 275-299
S00635		S210T130-18 SW-DUCT OVHT,MID CABIN ZONE	215T1005 81205	1	21-61-41 0709/305/R012	050-099, 150-199, 275-278
S00635		S210T130-18 SW-DUCT OVHT,MID CABIN ZONE	215T1005 81205	1	21-61-41 0770/305/R012	280-299
S00644		L18366-12 SW-LIGHT,CLOSET	417T5082 24385	1	33-22-21 0654+90/252/R053	162-199
S00646		L18366-12 SWITCH-CLOSET LIGHT	417T5035 24385	1	33-22-21 0265/258/L014	150-154
S00646		L18366-12 SWITCH-CLOSET LIGHT	439T3602 91929	1	33-22-21 0251/263/L009	155-157
S00646		L18366-12 SWITCH-CLOSET LIGHT	417T5082 24385	1	33-22-21 0366/257/L050	275-278
S00661		7GR159 SW-FWD CAR FEXT METERED DISCH LINE PRESS	453T2601 09049	1	26-23-12 0659/189/R067	050-099
S00661		7GR159 SW-FWD CAR FEXT METERED DISCH LINE PRESS	453T2601 09049	1	26-23-11 0654+88/144/R068	150-154
S00661		7GR159 SW-FWD CAR FEXT METERED DISCH LINE PRESS	453T2601 09049	1	26-23-12 0654+59/165/R079	155-199, 275-299
S00662		7GR159 SW-AFT CAR FEXT METERED DISCH LINE PRESS	453T2601 09049	1	26-23-12 0675/186/R080	050-099
S00662		7GR159 SW-AFT CAR FEXT METERED DISCH LINE PRESS	453T2601 09049	1	26-23-11 0654+88/146/R068	150-154
S00662		7GR159 SW-AFT CAR FEXT METERED DISCH LINE PRESS	453T2601 09049	1	26-23-12 0654+81/166/R079	155-199, 275-299
S00668		10AT96-2 SW-BRAKE PEDAL POSITION,L	250T0900 82647	1	31-31-22 0140/179/L025	ALL

EQUIPMENT LIST

D280T132

Section S00600

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00669		10AT96-2 SW-BRAKE PEDAL POSITION,R	250T0900 82647	1	31-31-22 0140/179/R025	ALL
S00674		MS24524-26 SWITCH-FLAPPER VALVE RESET	214T6112 81205	1	21-44-21 1510/170/L062	275-276
S00675		25ET120-S SW-BAY A OFF	284T3501 91929	1	25-53-13 P035-00/ /	150-199, 275-299
S00677		25ET120-S SW-BAY F OFF	284T3501 91929	1	25-53-13 P035-00/ /	150-199, 275-299
S00678		25ET120-S SW-BAY G OFF	284T3501 91929	1	25-53-13 P035-00/ /	150-199, 275-299
S00679		25ET120-S SW-BAY H OFF	284T3501 91929	1	25-53-13 P035-00/ /	150-199, 275-299
S00680		25ET120-S SW-BAY A OFF	284T3901 91929	1	25-53-23 P039-00/ /	150-199, 275-299
S00681		25ET120-S SW-BAY B OFF	284T3901 91929	1	25-53-23 P039-00/ /	150-199, 275-299
S00682		25ET120-S SW-BAY C OFF	284T3901 91929	1	25-53-23 P039-00/ /	150-199, 275-299
S00683		25ET120-S SW-BAY D OFF	284T3901 91929	1	25-53-23 P039-00/ /	150-199, 275-299
S00698		25ET120-S SW-BAY E OFF	284T3501 91929	1	25-53-13 P035-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section S00600

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00734	9	S210U122-3 SW-PRESSURE,LEFT (SB 36-0028)	312T2330 02750	1	36-11-61 0269/147/L003	150-152
S00734		S210U122-3 SW-PRESSURE,LEFT	312T2330 02750	1	36-11-61 0269/147/L003	050-099, 155, 162- 165, 276
S00734		211C117-197 SW-PRESSURE,LEFT	312T2330 02750	1	36-11-61 0269/147/L003	153-154, 275
S00734		S210U122-3 SW-PRESSURE,LEFT	212T3716 02750	1	36-11-61 ISS/326/	156-157, 166-199, 277-299
S00735	9	S210U122-3 SW-PRESSURE,RIGHT (SB 36-0028)	312T2330 02750	1	36-11-62 0269/147/L003	150-152
S00735		S210U122-3 SW-PRESSURE,RIGHT	312T2330 02750	1	36-11-62 0269/147/L003	050-099, 155, 162- 165, 276
S00735		211C117-197 SW-PRESSURE,RIGHT	312T2330 02750	1	36-11-62 0269/147/L003	153-154, 275
S00735		S210U122-3 SW-PRESSURE,RIGHT	212T3716 02750	1	36-11-62 ISS/326/	156-157, 166-199, 277-299
S00789		L18366 SW-SIDEWALL WASHLIGHT	417T0TBD 24385	1	33-21-31 0437/275/R055	151-152, 157
S00790		S253T407-2 SW-ALT STAB TRIM	253T5400 82647	1	27-41-31 P010-00/ /	050-099, 155-199, 275-299
S00791		S210T130-18 SW-AUX FWD CAB ZONE DUCT OVHT	215T1005 81205	1	21-61-61 0568/304/L010	ALL
S00792		S210T130-18 SW-AUX MID CABIN ZONE DUCT OVHT	215T1005 81205	1	21-61-71 0770/300/L003	050-099, 150-155, 162-165, 275-276
S00792		S210T130-18 SW-AUX MID CABIN ZONE DUCT OVHT	215T1005 81205	1	21-61-71 0767/301/L004	156-157, 166-199, 277-299
S00793		S210T130-18 SW-DUCT OVHT,FWD CARGO	00000000 81205	1	21-43-11 0734/155/L072	ALL
S00794		3000-46-15 SW-TEMP,CARGO COMPT,FWD	00000000 14604	1	21-43-11 0620/175/L070	050-099, 162-199
S00794		3000-46-15 SW-TEMP,CARGO COMPT,FWD	00000000 14604	1	21-43-11 0660/175/L070	150-157, 275-299

EQUIPMENT LIST

D280T132

Section S00700
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00800		MS25306-212 SW-NIGHT LTS FLEX STA 807	285T0019 96906	1	33-21-21 P019-00/ /	275-299
S00805	1	60B92400-7 SW-PRESS., JETT PUMP, L (PROVISIONAL)	343T0002 81205	1	28-42-13 L0257/14/RS	050-099, 162-164
S00805	1	60B92400-7 SW-PRESS., JETT PUMP, L	343T0002 81205	1	28-42-13 L0257/14/RS	155-157, 165-199, 277-299
S00805	1	60B92400-7 SW-PRESS., JETT PUMP, L (PROVISIONAL)	343T0002 81205	1	28-42-13 L0265/14/RS	276
S00805	2	60B92400-3 SW-PRESS., JETT PUMP, L (PROVISIONAL)	343T0002 81205	1	28-42-13 L0257/14/RS	050-099, 162-164
S00805	2	60B92400-3 SW-PRESS., JETT PUMP, L	343T0002 81205	1	28-42-13 L0257/14/RS	155-157, 165-199, 277-299
S00805	2	60B92400-3 SW-PRESS., JETT PUMP, L (PROVISIONAL)	343T0002 81205	1	28-42-13 L0265/14/RS	276
S00806	1	60B92400-7 SW-PRESS., JETT PUMP, R (PROVISIONAL)	343T0002 81205	1	28-42-13 R0257/14/RS	050-099, 162-164
S00806	1	60B92400-7 SW-PRESS., JETT PUMP, R	343T0002 81205	1	28-42-13 R0257/14/RS	155-157, 165-199, 277-299
S00806	1	60B92400-7 SW-PRESS., JETT PUMP, R (PROVISIONAL)	343T0002 81205	1	28-42-13 R0265/14/RS	276
S00806	2	60B92400-3 SW-PRESS., JETT PUMP, R (PROVISIONAL)	343T0002 81205	1	28-42-13 R0257/14/RS	050-099, 162-164
S00806	2	60B92400-3 SW-PRESS., JETT PUMP, R	343T0002 81205	1	28-42-13 R0257/14/RS	155-157, 165-199, 277-299
S00806	2	60B92400-3 SW-PRESS., JETT PUMP, R (PROVISIONAL)	343T0002 81205	1	28-42-13 R0265/14/RS	276
S00809		2100-23 SW-GENERAL ILLUM LT, FLT DK CREW REST	413T3285 24385	1	33-22-33 0258/262/L012	050-099, 162-199
S00818		L18366 SW-SIDEWALL WASHLIGHT, CCRA	00000000 24385	3	33-21-31 MULTI/270/0055	050-099, 162-199
S00828	9	L18366 SW-SIDEWALL WASHLIGHT, CCRA	24385	4	33-21-31 1440/270/L&R	150, 152-157
S00828		L18366 SW-SIDEWALL WASHLIGHT, CCRA	417T2040 24385	2	33-21-31 1440/270/L&R	050-099, 162-199

EQUIPMENT LIST

D280T132

Section S00800

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00836	9	10AT96-1 SW-COLUMN FWD,RIGHT (SB 27-0102)	253T2144 82647	1	27-41-11 0173/195/R037	050-099, 150-166
S00836		10AT96-1 SW-COLUMN FWD,RIGHT	253T2144 82647	1	27-41-11 0173/195/R037	167-199, 278-299
S00837	9	10AT96-1 SW-COLUMN AFT(ELEV TE UP),R (SB 27-0102)	253T2144 82647	1	27-41-11 0173/195/R037	050-099, 150-166
S00837		10AT96-1 SW-COLUMN AFT(ELEV TE UP),RIGHT	253T2144 82647	1	27-41-11 0173/195/R037	167-199, 278-299
S00838	9	10AT96-1 SW-COLUMN FWD,LEFT (SB 27-0102)	253T2144 82647	1	27-41-11 0173/195/L034	050-099, 150-166
S00838		10AT96-1 SW-COLUMN FWD,LEFT	253T2144 82647	1	27-41-11 0173/195/L034	167-199, 278-299
S00839	9	10AT96-1 SW-COLUMN AFT(ELEV TE UP),L (SB 27-0102)	253T2144 82647	1	27-41-11 0173/195/L034	050-099, 150-166
S00839		10AT96-1 SW-COLUMN AFT(ELEV TE UP),LEFT	253T2144 82647	1	27-41-11 0173/195/L034	167-199, 278-299
S00845		MS25307-232 SW-NIGHT LTS FLEX	285T0019 96906	1	33-21-21 P019-00/ /	280-299
S00846	9	S271T452-1 SW-HYDRAULIC PRESSURE (SB 27-0108)	272T4500 81205	1	27-81-31 1043/193/R029	050-099, 150-166, 275-277
S00846		S271T452-1 SW-HYDRAULIC PRESSURE	272T4500 81205	1	27-81-31 1043/193/R029	167-199, 278-299
S00858	9	S271T452-3 SW-L ENG T/R HIV 1 PRESS (SB 78-0051FAA)	272T0242 81205	1	78-36-11 STRUT/ /	050-099, 150-156, 162-166, 275-276
S00858		S271T452-3 SW-L ENG T/R HIV 1 PRESS (RR 41033-23)	272T0242 81205	1	78-36-11 STRUT/ /	157
S00858		S271T452-3 SW-L ENG T/R HIV 1 PRESS (RR 41033-24)	272T0242 81205	1	78-36-11 STRUT/ /	167-199
S00858		S271T452-3 SW-L ENG T/R HIV 1 PRESS (RR 41034-20)	272T0242 81205	1	78-36-11 STRUT/ /	277-278
S00858		S271T452-3 SW-L ENG T/R HIV 1 PRESS (RR 41034-21)	272T0242 81205	1	78-36-11 STRUT/ /	280-299
S00860	9	S271T452-3 SW-R ENG T/R HIV 1 PRESS (SB 78-0051FAA)	272T0242 81205	1	78-36-21 STRUT/ /	050-099, 150-156, 162-166, 275-276

EQUIPMENT LIST

D280T132

Section S00800

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00860		S271T452-3 SW-R ENG T/R HIV 1 PRESS	272T0242 81205	1	78-36-21 STRUT/ /	157, 167-199, 280- 299
S00860		S271T452-3 SW-R ENG T/R HIV 1 PRESS	272T0242 Q81205	1	78-36-21 STRUT/ /	277-278

EQUIPMENT LIST

D280T132

Section S00800
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S00940	9	3201-01 SW-R.FWD DR HEAT SELECTOR (SB 21-0139)	411T2244 81073	1	21-45-21 0350/225/R095	275-299

EQUIPMENT LIST

D280T132

Section S00900
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01583		S332T004-23 SW-OIL FILTER BY-PASS,ENG	VENDORS 81205	2	79-35-11 ENG/ /	050-099, 150-155, 162-165, 275-276
S01583		S332T004-34 SW-OIL FILTER BY-PASS,ENG	VENDORS 81205	2	79-35-11 ENG/ /	156-157, 166-199, 277-299
S01584		S332T004-22 SW-ENGINE LOW OIL PRESSURE	VENDORS 81205	2	79-33-11 ENG/ /	050-099, 150-154, 162-164, 275-276
S01584		S332T004-33 SW-ENGINE LOW OIL PRESSURE	VENDORS 81205	2	79-33-11 ENG/ /	155-157, 165-199, 277-299
S01585		1B1384 SW-FUEL FILTER BYPASS	VENDORS 77445	2	73-34-11 ENG/ /	ALL

EQUIPMENT LIST

D280T132

Section S01500
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01604		S283T006-7 SW-THRUST REV,LH AUTO. RESTOW	286T3528 81205	2	78-34-11 NL132/087/	ALL
S01605		S283T006-7 SW-THRUST REV,LH AUTO. RESTOW	286T3526 81205	2	78-34-11 NR132/087/	ALL
S01606		975-0612-001 SW-L ENG EEC OVERHEAT TEMP	312T3041 97896	1	30-21-11 NR120/148/11	ALL
S01607	1	S283T006-28 SW-PROX SNSR-LOCK,LH ACTUATOR	286T3530 81205	1	78-36-11 NL118/092/	ALL
S01607	2	S283T006-8 SW-PROX SNSR-LOCK,LH ACTUATOR	286T3530 81205	1	78-36-11 NL118/092/	ALL
S01608	1	S283T006-28 SW-PROX SNSR-LOCK,RH ACTUATOR	286T3532 81205	1	78-36-11 NL118/092/	ALL
S01608	2	S283T006-8 SW-PROX SNSR-LOCK,RH ACTUATOR	286T3532 81205	1	78-36-11 NL118/092/	ALL
S01609	1	S283T006-28 SW-DEPLOY,LH T/R	286T3530 81205	1	78-36-11 NL124/102/	ALL
S01609	2	S283T006-8 SW-DEPLOY,LH T/R	286T3530 81205	1	78-36-11 NL124/102/	ALL
S01610	1	S283T006-28 SW-DEPLOY,RH T/R	286T3532 81205	1	78-36-11 NL124/102/	ALL
S01610	2	S283T006-8 SW-DEPLOY,RH T/R	286T3532 81205	1	78-36-11 NL124/102/	ALL
S01611	1	51G123 SWITCH-IDG HT EX OVERRIDE PRESS	0050A101 77445	2	24-11-11 ENG/ /	ALL
S01611	2	50G900 SWITCH-IDG HT EX OVERRIDE PRESS	0050A101 77445	2	24-11-11 ENG/ /	ALL
S01616		975-0612-001 SW-R ENG EEC OVERHEAT TEMP	312T3041 97896	1	30-21-11 NR120/148/11	ALL
S01631		MS25307-232 SW-INDIRECT CEIL LTS FLEX STA 587	285T0019 96906	1	33-21-11 P019-00/ /	275-299
S01632		MS25307-232 SW-INDIRECT CEIL LTS FLEX STA 654+21	285T0019 96906	1	33-21-11 P019-00/ /	275-299
S01633		MS25307-232 SW-INDIRECT CEIL LTS FLEX STA 654+109	285T0019 96906	1	33-21-11 P019-00/ /	275-299

EQUIPMENT LIST

D280T132

Section S01600

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S01634		MS25307-232 SW-INDIRECT CEIL LTS FLEX STA 719	285T0019 96906	1	33-21-11 P019-00/ /	275-299
S01635		MS25307-232 SW-SIDEWALL LTS FLEX STA 587	285T0019 96906	1	33-21-31 P019-00/ /	275-299
S01636		MS25307-232 SW-SIDEWALL LTS FLEX STA 654+21	285T0019 96906	1	33-21-31 P019-00/ /	275-299
S01637		MS25307-232 SW-SIDEWALL LTS FLEX STA 654+109	285T0019 96906	1	33-21-31 P019-00/ /	275-299
S01638		MS25307-232 SW-SIDEWALL LTS FLEX STA 719	285T0019 96906	1	33-21-31 P019-00/ /	275-299
S01639		MS25306-212 SW-NIGHT LTS FLEX STA 675	285T0019 96906	1	33-21-21 P019-00/ /	275-299
S01640		MS25306-212 SW-DIR CEIL LTS FLEX	285T0019 96906	1	33-22-42 P019-00/ /	275-299

EQUIPMENT LIST

D280T132

Section S01600

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S02313	9	9000910-1 SW-L OB SLAT1 SKEW/LOSS ASY (SB 27A0140)	114T4101 96774	1	27-89-11 R1075-LE/ /	151
S02314	9	9000910-2 SW-R OB SLAT12 SKEW/LOSS AY (SB 27A0140)	114T4101 96774	1	27-89-11 / /	151

EQUIPMENT LIST

D280T132

Section S02300
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S09001	9	2100-3 SW-F/A CONTROL PNL C MTO 230540	CUSTOMER -CUST	1	23-31-12 TBD/ /	050-099
S09001	9	311SM2-T-311SM706-T SWITCH-CLOSET LIGHT(MTO330342B&MTO33048)	CUSTOMER BFE	1	33-22-21 0450/240/L055	150, 153-199
S09002	9	311SM2-T-311SM706-T SWITCH-COATROOM LIGHT (MTO330342B)	CUSTOMER BFE	1	33-22-21 0435/260/R060	150, 153-157
S09003	9	311SM2-T-311SM706T SWITCH-COATROOM LIGHT (MTO330342B)	CUSTOMER BFE	1	33-22-21 0450/260/R060	150, 153-157
S09004	9	59150-040SENSOR-S7150ACTUATOR SWITCH-COATROOM LIGHT (MTO330348)	CUSTOMER BFE	1	33-22-21 0654+120/240/R020	162-199
S09005	9	59150-040SENSOR-57150ACTUATOR SWITCH-COATROOM LIGHT (MTO330348)	CUSTOMER BFE	1	33-22-21 0654+120/240/L020	162-199
S09006	9	59150-040SENSOR-57150ACTUATOR SWITCH-COATROOM LIGHT (MTO330348)	CUSTOMER BFE	1	33-22-21 0654+120/240/L020	162-199
S09011	9	CUSTOMER SW-OFF PASSENGER TELEPHONE (MTO-230695)	CUSTOMER CUST	1	23-19-11 P61/ /	150
S09011	9	CUSTOMER SW-OFF PASSENGER TELEPHONE (MTO-230596)	CUSTOMER CUST	1	23-19-11 P61/ /	152-199
S09012	9	433-673-1006-6044 SW-CAPT TERR (MTO-340961)	CUSTOMER 81590	1	34-46-13 P001-01/ /	150, 152-199, 275-299
S09013	9	433-673-1006-6044 SW-CAPT WXR (MTO-340961)	CUSTOMER 81590	1	34-46-13 P001-01/ /	150, 152-199, 275-299
S09014	9	433-673-1006-6044 SW-F/O TERR (MTO-340961)	CUSTOMER 81590	1	34-46-13 P003-01/ /	150, 152-199, 275-299
S09015	9	433-673-1006-6044 SW-F/O WXR (MTO-340961)	CUSTOMER 81590	1	34-46-13 P003-01/ /	150, 152-199, 275-299
S09016	9	433-673-1006-6121 SW-F/O INOP/OVRD (MTO-340961)	CUSTOMER 81590	1	34-46-13 P003-01/ /	150, 152-199, 275-299
S09017	9	CUSTOMER PED POWER (EAD89-0704-00)	CUSTOMER CUST	1	25-25-24 P078-00/ /	150, 153, 157, 165-199
S09018	9	CUSTOMER PED POWER-MASTER (EAD89-0704-00)	CUSTOMER CUST	1	25-25-24 P061-00/ /	150, 153, 157, 165-199

EQUIPMENT LIST

D280T132

Section S09000

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10170		2PB11H58 SW-EICAS DISPLAY,CANCEL	233T2222 91929	1	31-41-12 P001-03/ /	ALL

EQUIPMENT LIST

D280T132

Section S10100
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10230		2PB11H58 SW-EICAS DISPLAY,RECALL	233T2222 91929	1	31-41-12 P001-03/ /	ALL

EQUIPMENT LIST

D280T132

Section S10200
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
S10563	9	D2-729B003 SW-ATC ANTENNA-TOP (SL-34-82-A)	284T1305 81205	1	34-53-13 0331/132/R043	ALL
S10564	9	D2-729B003 SW-ATC ANTENNA-BOTTOM (SL-34-82 A)	284T1305 81205	1	34-53-13 0331/132/R043	150-199, 275-278
S10564		D2-729B003 SW-ATC ANTENNA-BOTTOM	284T1305 50667	1	34-53-13 SHELF/E02/02	275-278
S10598	9	ELDEC8-527-03 SWITCH-GEAR TILT-RIGHT GEAR (SB 27A0160)	284T0270 08748	1	27-62-11 1046.5/53/183	ALL

EQUIPMENT LIST

D280T132

Section S10500
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00101		S282T001-1 TRU-LEFT	284T0130 81205	1	24-32-11 SHELF/E03/02	ALL
T00102		S282T001-1 TRU-RIGHT	284T0130 81205	1	24-32-11 SHELF/E03/02	ALL
T00103		10-60011-2 XFMR RECT UNIT-GND PWR	284T0175 81205	1	24-54-61 P034-00/ /	ALL
T00105		S281T001-4 DPCT-L GEN	284T0171 81205	1	24-23-11 P031-00/ /	ALL
T00106		S281T001-4 DPCT-L GEN	284T0997 81205	1	24-23-11 P006-03/ /	ALL
T00107		S281T001-4 DPCT-R GEN	284T0172 81205	1	24-23-11 P032-00/ /	ALL
T00108		S281T001-4 DPCT-R GEN	284T0997 81205	1	24-23-11 P006-04/ /	ALL
T00111		S281T001-4 DPCT-APU GEN	284T0175 81205	1	24-23-11 P034-00/ /	ALL
T00112		S281T001-4 DPCT-L TIE BUS	284T0171 81205	1	24-23-12 P031-00/ /	ALL
T00113		S281T001-4 DPCT-R TIE BUS	284T0172 81205	1	24-23-12 P032-00/ /	ALL
T00115		S281T001-4 DPCT-APU TIE BUS	284T0175 81205	1	24-23-12 P034-00/ /	ALL
T00116		S281T001-4 DPCT-EXT PWR TIE BUS	284T0175 81205	1	24-23-12 P034-00/ /	ALL
T00122		S281T001-4 XFMR-CURRENT,GROUND POWER	284T0175 81205	1	24-41-11 P034-00/ /	ALL
T00123		60B40026-14 XFMR-28V AC BUS,LEFT	284T0997 81205	1	24-53-11 P006-03/ /	ALL
T00124		60B40026-14 XFMR-28V AC BUS,RIGHT	284T0997 81205	1	24-53-21 P006-04/ /	ALL
T00126		60B40026-13 XFMR-28V AC BUS,GND SERVICE	284T0189 81205	1	24-53-51 P033-00/ /	ALL
T00127		S281T001-4 XFMR-CURRENT,OVERLAP,LEFT	284T0171 81205	1	24-23-11 P031-00/ /	ALL

EQUIPMENT LIST

D280T132

Section T00100

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00128		S281T001-4 XFMR-CURRENT,OVERLAP,RIGHT	284T0172 81205	1	24-23-11 P032-00/ /	ALL
T00129		60B40026-17 XFMR-WING LANDING LIGHT,L	284T0639 81205	1	33-42-11 0763/148/L073	ALL
T00130		60B40026-17 XFMR-WING LANDING LIGHT,R	284T0639 81205	1	33-42-11 0763/150/R075	050-099
T00130		60B40026-17 XFMR-WING LANDING LIGHT,R	284T0639 81205	1	33-42-11 0763/148/R073	150-199, 275-299
T00131		FT1246 XFMR-POSITION LIGHT,LEFT "A"	284T0224 14752	1	33-43-11 L1128/12/TIP	ALL
T00132		FT1246 XFMR-POSITION LIGHT,RIGHT "A"	284T0224 14752	1	33-43-11 R1128/12/TIP	ALL
T00137		60B40026-20 XFMR-RUNWAY TURNOFF LIGHT,L	284T0639 81205	1	33-42-21 0763/150/L075	ALL
T00138		60B40026-20 XFMR-RUNWAY TURNOFF LIGHT,R	284T0639 81205	1	33-42-21 0766/150/R075	050-099
T00138		60B40026-20 XFMR-RUNWAY TURNOFF LIGHT,R	284T0639 81205	1	33-42-21 0762/150/R074	150-199, 275-299
T00139		10615 XFMR-AIR DATA COMPUTER,LEFT	284T0187 95266	1	34-12-11 P036-00/ /	ALL
T00140		10615 XFMR-AIR DATA COMPUTER,RIGHT	284T0188 95266	1	34-12-21 P037-00/ /	ALL
T00141		60B40026-16 XFMR-WHEEL WELL LIGHT	284T0636 81205	1	33-31-11 0980/192/R055	ALL
T00143		FT1219 XFMR-NOSE GEAR LDG LT,L	284T0905 14752	1	33-42-11 P023-00/ /	ALL
T00144		FT1219 XFMR-NOSE GEAR LDG LT,R	284T0905 14752	1	33-42-11 P023-00/ /	ALL
T00146		60B40026-19 XFMR-AIR COND COMPT LIGHTS	284T0657 81205	1	33-31-21 0843/114/L010	ALL
T00148		60B40026-17 XFMR-FWD CAR. COMPT LTS	284T0687 81205	1	33-37-11 P035-00/ /	ALL
T00149		60B40026-19 XFMR-APU & TAILCONE LTS	284T0551 81205	1	33-31-31 1831/242/R038	ALL

EQUIPMENT LIST

D280T132

Section T00100

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00150		60B40026-19 XFMR-NIGHT LTS	285T0009 81205	1	33-21-21 P025-00/ /	ALL
T00151		60B40026-16 XFMR-AFT CARGO EXT LTS	284T0688 81205	1	33-31-61 P039-00/ /	ALL
T00152		60B40026-17 XFMR-AFT CARGO COMPT LTS	284T0688 81205	1	33-37-21 P039-00/ /	ALL
T00153		60B40026-19 XFMR-POWER,FLAP POS-C	284T0187 81205	1	27-58-21 P036-00/ /	ALL
T00177		60B40026-20 XFMR-ENTRY/ATTENDANT LIGHTS,AFT	285T0009 81205	1	33-22-11 P025-00/ /	ALL
T00180		60B40026-15 XFMR-INDIRECT CEILING LTS,FWD	285T0019 81205	1	33-21-11 P019-00/ /	ALL
T00181		60B40026-15 XFMR-OUTBD INDIRECT CEILING LTS,AFT	285T0009 81205	1	33-21-12 P025-00/ /	ALL
T00182		60B40026-15 XFMR-INBD INDIRECT CEILING LTS,AFT	285T0009 81205	1	33-21-12 P025-00/ /	ALL
T00183		60B40026-15 XFMR-SIDEWALL LTS	285T0019 81205	1	33-21-31 P019-00/ /	ALL
T00184		60B40026-15 XFMR-SIDEWALL LTS	285T0019 81205	1	33-21-31 P019-00/ /	ALL
T00186		284T1174-1 XFMR-FWD CARGO EXT LTS (LARGE)	284T0687 81205	1	33-31-61 P035-00/ /	ALL
T00187		FT1219 XFMR-TAXI LIGHT,L	284T0905 14752	1	33-42-21 P023-00/ /	ALL
T00188		FT1219 XFMR-TAXI LIGHT,R	284T0905 14752	1	33-42-21 P023-00/ /	ALL
T00189		60B40104-2 XFMR RECT-APU START	284T0406 81205	1	24-32-41 SHELF/E06/02	275-299
T00191		60B40026-19 XFMR-POWER,FSEU SENSOR	284T0188 81205	1	27-51-61 P037-00/ /	ALL
T00193		60B40026-16 XFMR-28V AC XFR BUS,LEFT	284T0997 81205	1	24-51-14 P006-03/ /	ALL
T00194		60B40026-16 XFMR-28V AC XFR BUS,RIGHT	284T0997 81205	1	24-51-24 P006-04/ /	ALL

EQUIPMENT LIST

D280T132

Section T00100

Page 3 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00232		0077CC XFMR-VIDEO (PART OF DIU INSTL. TRAY)	284TXXXX ASINC	1	23-32-21 SHELF/E01/04	ALL
T00233		60B40026-20 XFMR-CEILING LTS	285T0009 81205	1	33-22-42 P025-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section T00200
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00675	1	S332T006-13 XMTR-ENGINE OIL QUANTITY	VENDORS 81205	2	79-31-11 ENG/ /	ALL
T00675	2	S332T006-11 XMTR-ENGINE OIL QUANTITY	VENDORS 81205	2	79-31-11 ENG/ /	ALL
T00677		S332T304-1 ACCELEROMETER-ENGINE FAN	332T4420 95411	2	77-31-11 ENG/ /	ALL
T00679		S332T305-8 XMTR-OIL PRESSURE,ENG	VENDORS 81205	2	79-32-11 ENG/ /	ALL
T00688		51A020 TRANSDUCER-EEC SPEED (N1)	50A102PW 77445	4	71-51-14 ENG/ /	ALL
T00689		1A6714 THERMOCOUPLE-NO 3 BEARING OIL TEMP	50A102PW 77445	2	71-51-14 N178/069/R008	ALL
T00690		53T903 THERMOCOUPLE-EEC OIL TEMP	50A102PW 77445	2	79-34-11 N161/075/L017	ALL

EQUIPMENT LIST

D280T132

Section T00600

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T00867		P-WSUPPLIED PROBE-P2/T2 ENG	330T3010 77445	2	73-21-12 70.41/ /	ALL

EQUIPMENT LIST

D280T132

Section T00800
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T01519		50R241AND50R453 ALTERNATOR EEC GENERATOR	50A102PW 77445	4	71-51-14 ENG/ /	ALL

EQUIPMENT LIST

D280T132

Section T01500
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
T10033		S315N401-1 LVDT-L SLEEVE	00000000 81205	2	78-36-11 ENG/ /	ALL
T10035		S315N401-1 LVDT-R SLEEVE	00000000 81205	2	78-36-11 ENG/ /	ALL

EQUIPMENT LIST

D280T132

Section T10000
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0014		BACT44A0460D TB-TRACK,P6	284T0997 81205	1	33-11-11 P006-01/ /	ALL
TB0014F		BACM15C1A MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-01/ /	ALL
TB0014G		BACM15C1B MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-01/ /	ALL
TB0016		BACT44A0460D TB-TRACK,P6	284T0997 81205	1	24-11-11 P006-03/ /	ALL
TB0016F		BACM15C1A MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-03/ /	ALL
TB0016X		BACM15C3A MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-03/ /	ALL
TB0016Y		BACM15C3B MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-03/ /	ALL
TB0016Z		BACM15C3C MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-34-11 P006-03/ /	ALL
TB0018		BACT44A0460D TB-TRACK,P6	284T0997 81205	1	24-11-11 P006-05/ /	ALL
TB0018F		BACM15C1A MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-05/ /	ALL
TB0018X		BACM15C3A MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-05/ /	ALL
TB0018Y		BACM15C3B MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-00/ /	ALL
TB0018Z		BACM15C3C MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	24-11-11 P006-00/ /	ALL
TB0022		BACT44A0460D TB-TRACK,P6	284T0997 81205	1	33-11-11 P006-05/ /	ALL
TB0022D		DIODEBLOCK-REF284T0997- DIODE BLOCK (R10120,R10119,R00225,R00226	284T0997	1	80-11-11 P006-05/ /	ALL
TB0022Y		BACM15C3B MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	33-11-11 P006-05/ /	ALL
TB0022Z		BACM15C3C MDL-TERMINAL BLOCK,P6	286TXXXX 81205	1	33-11-11 P006-05/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0024		284T0914-1 TB-TRACK,P34	284T0175 81205	1	24-11-11 P034-00/ /	ALL
TB0024D		DIODEBLOCK-REF284T0175- DIODE BLOCK (R110,R111,R6)	286TXXXX	1	24-22-41 P034-00/ /	ALL
TB0024F		BACM15C1A MDL-TERMINAL BLOCK,P34	286TXXXX 81205	1	24-11-11 P034-00/ /	ALL
TB0024G		BACM15C1B MDL-TERMINAL BLOCK,P34	286TXXXX 81205	1	52-34-12 P034-00/ /	ALL
TB0024R		RESISTORBLOCK-REF284T0175- RESISTOR BLOCK (R532,R533,R531)	286TXXXX	1	24-41-11 P034-00/ /	ALL
TB0026		AMY4100T-10 TB-TRACK,E6-1	284T0161 09922	1	49-14-11 SHELF/E06/01	ALL
TB0026D		DIODEBLOCK-REF284T0161- DIODE BLOCK (R10076,R185)	284T0161	1	24-27-41 SHELF/E06/01	150-157
TB0026F		BACM15C1A MDL-TERMINAL BLOCK,E6-1	286TXXXX 81205	1	49-14-11 SHELF/E06/01	ALL
TB0026G		BACM15C1B MDL-TERMINAL BLOCK,E6-1	286TXXXX 81205	1	49-14-11 SHELF/E06/01	ALL
TB0026H		BACM15C2A MDL-TERMINAL BLOCK,E6-1	286TXXXX 81205	1	49-14-11 SHELF/E06/01	ALL
TB0026R		RESISTORBLOCK-REF284T0161- RESISTOR BLOCK (R550,R543)	284T0161	1	49-71-11 SHELF/E06/01	ALL
TB0028		BACT44A0640D TB-TRACK,P31	284T0171 81205	1	24-22-11 P031-00/ /	ALL
TB0028D		DIDOEBLOCK-REF284T0189- DIODE BLOCK (R4)	286TXXXX	1	24-22-11 P031-00/ /	ALL
TB0028F		BACM15C1A MDL-TERMINAL BLOCK,P31	286TXXXX 81205	1	24-22-11 P031-00/ /	ALL
TB0028G		BACM15C1B MDL-TERMINAL BLOCK,P31	286TXXXX 81205	1	29-11-32 P031-00/ /	ALL
TB0028Y		BACM15C3B MDL-TERMINAL BLOCK,P31	286T0000 81205	1	25-31-71 P031-00/ /	150-199, 275-299
TB0030		BACT44A0460D TB-TRACK,P31	284T0171 81205	1	29-11-31 P031-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0000

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0030D		DIODEBLOCK-REF284T0171- DIODE BLOCK (R177)	284T0171	1	29-11-31 P031-00/ /	ALL
TB0030F		BACM15C1A MDL-TERMINAL BLOCK,P31	286TXXXX 81205	1	29-11-31 P031-00/ /	ALL
TB0030G		BACM15C1B MDL-TERMINAL BLOCK,P31	286TXXXX 81205	1	24-22-12 P031-00/ /	ALL
TB0030Y		BACM15C3B MDL-TERMINAL BLOCK,P31	286T0000 81205	1	29-11-31 P031-00/ /	ALL
TB0031	9	BACT44A0920D TB-TRACK,P8	TO230607 09922	1	23-22-12 0212/195/L045	150, 152-199
TB0031		BACT44A0920D TB-TRACK,P8	287T4109 09922	1	33-13-18 0212/195/L045	050-099, 151, 275- 299
TB0031F		BACM15C1A MDL-TERMINAL BLOCK,P8	286TXXXX 81205	1	23-51-21 0212/195/L045	ALL
TB0031G		BACM15C1B MDL-TERMINAL BLOCK,P8	286TXXXX 81205	1	33-16-12 0212/195/L045	ALL
TB0031H		BACM15C2A MDL-TERMINAL BLOCK,P8	286T0615 81205	1	33-16-12 0212/195/L045	ALL
TB0031Y		BACM15C3B MDL-TERMINAL BLOCK,P8	286T0615 81205	1	21-58-16 0212/195/L045	ALL
TB0032		BACT44A0460D TB-TRACK,P32	284T0172 81205	1	24-22-21 P032-00/ /	ALL
TB0032D		DIODEBLOCK-REF284T0172- DIODE BLOCK (R5,R8)	284T0172	1	24-22-21 P032-00/ /	ALL
TB0032F		BACM15C1A MDL-TERMINAL BLOCK,P32	286TXXXX 81205	1	24-22-21 P032-00/ /	ALL
TB0032G		BACM15C1B MDL-TERMINAL BLOCK,P32	286TXXXX 81205	1	24-27-11 P032-00/ /	ALL
TB0032Y		BACM15C3B MDL-TERMINAL BLOCK,P32	286TXXXX 81205	1	24-27-21 P032-00/ /	ALL
TB0034		BACT44A0460D TB-TRACK,P32	284T0172 81205	1	24-22-21 P032-00/ /	ALL
TB0034F		BACM15C1A MDL-TERMINAL BLOCK,P32	286TXXXX 81205	1	24-22-21 P032-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0000

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0034G		BACM15C1B MDL-TERMINAL BLOCK,P32	286TXXXX 81205	1	25-31-11 P032-00/ /	ALL
TB0034R		RESISTORBLOCK RESISTOR BLOCK (R551)	284T0172	1	25-31-31 P032-00/ /	050-099, 150-157
TB0064		BACT44B0780D TB-TRACK,P5	287T4101 81205	1	33-13-16 0191/279/R012	ALL
TB0064D		DIODEBLOCK-REF233T3100- DIODE BLOCK (R186)	233T3100	1	36-11-41 0202/280/R008	ALL
TB0064F		BACM15C1A MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-13-16 0200/275/R010	050-099, 156-157, 166-199, 277-299
TB0064G		BACM15C1B MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-13-16 0202/267/R010	ALL
TB0064X		BACM15C3A MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL
TB0064Y		BACM15C3B MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL
TB0064Z		BACM15C3C MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL
TB0066		BACT44B1180D TB-TRACK,P5	287T4101 81205	1	33-13-16 0191/280/R008	ALL
TB0066X		BACM15C3A MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 0202/280/R008	ALL
TB0066Y		BACM15C3B MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 0202/280/R008	ALL
TB0066Z		BACM15C3C MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 0202/280/R008	ALL
TB0068		BACT44B0780D TB-TRACK,P5	287T4101 81205	1	33-13-16 0190/284/L010	ALL
TB0068G		BACM15C1B MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-13-16 P005-00/ /	ALL
TB0068H		BACM15C2A MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-13-16 P005-00/ /	ALL
TB0068X		BACM15C3A MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0000

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0068Y		BACM15C3B MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL
TB0068Z		BACM15C3C MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL
TB0070		BACT44B1180D TB-TRACK,P5	287T4101 81205	1	33-13-16 0190/284/L010	ALL
TB0070F		BACM15C1A MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-13-16 0200/280/0000	ALL
TB0070G		BACM15C1B MDL-TERMINAL BLOCK-P5	286TXXXX 81205	1	33-13-16 P005-00/ /	ALL
TB0070X		BACM15C3A MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL
TB0070Y		BACM15C3B MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL
TB0070Z		BACM15C3C MDL-TERMINAL BLOCK,P5	286TXXXX 81205	1	33-11-11 P005-00/ /	ALL
TB0074		BACT44B0560U TB-TRACK,P36	284T0187 81205	1	91-00-00 P036-00/ /	ALL
TB0074D		DIODEBLOCK-REF284T0187- DIODE BLOCK (R443)	286TXXXX	1	91-00-00 P036-00/ /	050-099, 155-199, 276-299
TB0074F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0074G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0074X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0074Y	9	BACM15C3B MDL-TERMINAL BLOCK,P36 (SB 21-0139)	289T1039 81205	1	21-45-21 P036-00/ /	275-299
TB0074Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	050-099, 150-199
TB0074Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0076		BACT44B0560U TB-TRACK,P36	284T0187 81205	1	91-00-00 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0000

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0076F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0076G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0076X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0076Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0076Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0078		BACT44B0560U TB-TRACK,P36	284T0187 81205	1	91-00-00 P036-00/ /	ALL
TB0078F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0078G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0078X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0078Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0078Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0080		BACT44B0560U TB-TRACK,P36	284T0187 81205	1	91-00-00 P036-00/ /	ALL
TB0080D		DIODEBLOCK-REF284T0187- DIODE BLOCK (R22)	284T0187	1	29-11-32 P036-00/ /	ALL
TB0080F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0080G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0080X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0080Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0000

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0080Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0082		BACT44B0560U TB-TRACK,P37	284T0188 81205	1	91-00-00 P037-00/ /	ALL
TB0082D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R174,R265,R266,R268)	284T0188	1	29-11-12 P037-00/ /	ALL
TB0082F		BACM15C1A MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0082G		BACM15C1B MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0082X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0082Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0082Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0084		BACT44B0560U TB-TRACK,P37	284T0188 81205	1	91-00-00 P037-00/ /	ALL
TB0084F		BACM15C1A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0084G		BACM15C1B MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0084X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0084Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0084Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0086		BACT44B0405U TB-TRACK,P37	284T0188 81205	1	91-00-00 P037-00/ /	ALL
TB0086D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R219)	286TXXXX	1	73-21-11 P037-00/ /	050-099, 150-155, 157-165, 275-276
TB0086F		BACM15C1A MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section TB0000

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0086G		BACM15C1B MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0086X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0086Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0086Z		BACM15C3C MDL-TERMINAL BLOCAK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0088		BACT44B0680U TB-TRACK,P37	284T0188 81205	1	91-00-00 P037-00/ /	ALL
TB0088D	9	DIODEBLOCK-REF284T0188- DIODE BLOCK (MULTI) (SB 24-0070)	286T0188	1	21-61-21 P037-00/ /	153-154
TB0088D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R564,R565,R566)	286T0188	1	21-61-21 P037-00/ /	050-099, 150-152, 155-199, 275-299
TB0088F		BACM15C1A MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0088G		BACM15C1B MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	25-33-11 P037-00/ /	050-099, 150-199, 275-276, 280-299
TB0088H		BACM15C2A MDL-TERMINAL BLOCK	286TXXXX 81205	1	73-21-11 P036-00/ /	ALL
TB0088X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0088Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0088Z		BACM15C3C MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0090		BACT44B1948U TB-TRACK-P33	284T0189 81205	1	91-00-00 P033-00/ /	ALL
TB0090D	9	DIODEBLOCK-REF284T0189- DIODE BLOCK (R490) (SB 30-0017)	284T0189	1	30-11-11 P033-00/ /	150-154
TB0090D	9	DIODEBLOCK-REF284T0189- DIODE BLOCK (R490) (SB 78-0051)	284T0189	1	30-11-11 P033-00/ /	275-276
TB0090D		DIODEBLOCK-REF284T0189- DIODE BLOCK (R490)	284T0189	1	30-11-11 P033-00/ /	050-099, 155-199, 277-299

EQUIPMENT LIST

D280T132

Section TB0000

Page 8

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0090F		BACM15C1A MDL-TERMINAL BLOCK-P33	286T0189 81205	1	91-00-00 P033-00/ /	150-199, 275-299
TB0090G	9	BACM15C1B MDL-TERMINAL BLOCK-P33 (SB 27A0160)	286T1065 81205	1	27-62-11 P033-00/ /	ALL
TB0090H		BACM15C2A MDL-TERMINAL BLOCK-P33	286T0189 81205	1	91-00-00 P033-00/ /	ALL
TB0090X		BACM15C3A MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	150-199, 275-299
TB0090Y		BACM15C3B MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0090Z		BACM15C3C MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0092		BACT44B1948U TB-TRACK-P33-12 POSITIONS	284T0189 81205	1	91-00-00 P033-00/ /	ALL
TB0092F		BACM15C1A MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	150-199, 275-299
TB0092G		BACM15C1B MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	150-199, 275-299
TB0092H		BACM15C2A MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	150-199, 275-299
TB0092X		BACM15C3A MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	150-199, 275-299
TB0092Y		BACM15C3B MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0092Z		BACM15C3C MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0096	9	BACT442150U TB-TRACK,P61 (SB 28-0030)	286T0096 81205	1	33-11-11 P061-00/ /	051-099
TB0096		BACT442150U TB-TRACK,P61	286T0096 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0096D		DIODEBLOCK-REF284T3000- DIODE BLOCK (R136-R143,R167)	284T3000	1	26-11-11 P061-00/ /	ALL
TB0096F		BACM15C1A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0000

Page 9

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0096G		BACM15C1B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0096X		BACM15C3A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0096Y		BACM15C3B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0096Z		BACM15C3C MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0098		BACT442150U TB-TRACK,P61	233T4100 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0098X		BACM15C3A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0098Y		BACM15C3B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0098Z		BACM15C3C MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0000
Page 10 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0100		BACT442150U TB-TRACK,P61	233T4100 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0100D		DIODEBLOCK-REF287T4163- DIODE BLOCK (R368,R369)	286T4163	1	26-18-11 P061-00/ /	ALL
TB0100F		BACM15C1A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	38-32-11 P061-00/ /	155-157, 164-199, 277-299
TB0100G		BACM15C1B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0100X		BACM15C3A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0100Y		BACM15C3B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0100Z		BACM15C3C MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0101		284T0384 TB-TRACK,E1-1	284T1611 09922	1	27-09-11 SHELF/E01/01	ALL
TB0101G		BACM15C1B MDL-TERMINAL BLOCK,E1-1	286TXXXX 81205	50	27-09-11 SHELF/E01/01	ALL
TB0101H		BACM15C2A MDL-TERMINAL BLOCK,E1-1	286TXXXX 81205	25	27-09-11 SHELF/E01/01	ALL
TB0102		BACT442150U TB-TRACK,P61	233T4100 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0102D		DIODEBLOCK-REF287T4163- DIODE BLOCK (R217,R218)	287T4163	1	32-42-11 P061-00/ /	ALL
TB0102F		BACM15C1A MDL-TERMINAL BLOCK,P61	286T0062 81205	1	26-13-11 P061-00/ /	050-099, 150-199
TB0102G		BACM15C1B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0102X		BACM15C3A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0102Y		BACM15C3B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0102Z		BACM15C3C MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0104		BACT442150U TB-TRACK,P61	233T4100 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0104F		BACM15C1A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0104G		BACM15C1B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0104X		BACM15C3A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0104Y		BACM15C3B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0104Z		BACM15C3C MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	150-199, 275-299
TB0105		284T0384-8 TB-TRACK,E1-3	284T1613 09922	1	22-11-11 SHELF/E01/03	ALL
TB0105D	9	BACM15C1A DIODE BLOCK (R738) (SB 34A0332)	289T1127 81205	1	34-12-61 SHELF/E01/03	050-099
TB0105D		DIODEBLOCK-REF284T0113- DIODE BLOCK (R680)	284T0113	1	34-22-33 SHELF/E01/03	150-199, 275-299
TB0105F		BACM15C1A MDL-TERMINAL BLOCK,E1-3	286TXXXX 81205	20	22-14-11 SHELF/E01/03	ALL
TB0105G		BACM15C1B MDL-TERMINAL BLOCK,E1-3	286TXXXX 81205	80	22-11-12 SHELF/E01/03	ALL
TB0105H		BACM15C2A MDL-TERMINAL BLOCK,E1-3	286TXXXX 81205	60	22-11-11 SHELF/E01/03	ALL
TB0105X		BACM15C3A MDL-TERMIAN	286TXXXX 81205	1	32-48-11 SHELF/E01/03	050-099, 275-299
TB0105Y		BACM15C3B MDL-TERMINAL BLOCK,E1-3	286TXXXX 81205	1	31-31-19 SHELF/E01/03	ALL
TB0105Z		BACM15C3B MDL-TERMINAL BLOCK,E1-3	286TXXXX 81205	1	31-31-19 SHELF/E01/03	ALL
TB0106		BACT442150U TB-TRACK,P61	286T0106 81205	1	33-11-11 P061-00/ /	ALL
TB0106G		BACM15C1B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section TB0100

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0106X		BACM15C3A MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0106Y		BACM15C3B MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0106Z		BACM15C3C MDL-TERMINAL BLOCK,P61	286TXXXX 81205	1	33-11-11 P061-00/ /	ALL
TB0108		MTB16E103-43A TB-TRACK,P28	344T0021 14283	1	28-21-11 P028-00/ /	ALL
TB0108L		MRTB16E03-225 MDL-TERMINAL BLOCK,P28	344T0021 14283	1	28-21-11 P028-00/ /	ALL
TB0108M		MRTB16E04-225 MDL-TERMINAL BLOCK,P28	344T0021 14283	2	28-21-11 P028-00/ /	ALL
TB0110		BACT44B1775U TB-TRACK,P35	284T0691 81205	1	25-53-13 P035-00/ /	050-099
TB0110D		DIODEBLOCK-REF284T0687- DIODE BLOCK (R147,R150,R153)	284T0687	3	25-53-13 P035-00/ /	ALL
TB0110G		BACM15C1B MDL-TERMINAL BLOCK,P35	286TXXXX 81205	7	25-53-13 P035-00/ /	ALL
TB0110H		BACM15C2A MDL-TERMINAL BLOCK,P35	286TXXXX 81205	6	25-53-13 P035-00/ /	ALL
TB0110Y		BACM15C3B MDL,TERMINAL BLOCK,P35	286T1066 81205	1	25-53-14 P035-00/ /	150-199, 275-299
TB0110Z		BACM15C3C MDL,TERMINAL BLOCK,P35	286T1066 81205	1	25-53-13 P035-00/ /	ALL
TB0112		BACT44B1050U TB-TRACK,P35	284T0691 81205	1	25-53-14 P035-00/ /	ALL
TB0112D		YHLZD-30 DIODE-ISLN,CTR MODE CMD	284T0687 09922	1	25-53-16 P035-00/ /	ALL
TB0112G		BACM15C1B MDL-TERMINAL BLOCK,P35	286TXXXX 81205	20	25-53-14 P035-00/ /	ALL
TB0112H		BACM15C2A MDL-TERMINAL BLOCK,P35	286TXXXX 81205	5	25-53-14 P035-00/ /	ALL
TB0112Y		BACM15C3B MDL,TERMINAL BLOCK,P35	286T1066 81205	1	25-53-14 P035-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0112Z		BACM15C3C MDL,TERMINAL BLOCK,P35	286T1066 81205	1	25-53-14 P035-00/ /	ALL
TB0114		BACT44B0510U TB-TRACK,P35	284T0690 81205	1	25-53-13 P035-00/ /	ALL
TB0114D		DIODEBLOCK-REF284T0687- DIODE BLOCK (MULTI)	286T0000 81205	1	25-53-14 P035-00/ /	ALL
TB0114F		BACM15C1A MDL-TERMINAL BLOCK,P35	286TXXXX 81205	1	25-53-13 P035-00/ /	150-199, 275-299
TB0114G		BACM15C1B MDL-TERMINAL BLOCK,P35	286TXXXX 81205	13	25-53-11 P035-00/ /	ALL
TB0114H		BACM15C2A MDL-TERMINAL BLOCK,P35	286TXXXX 81205	1	25-53-14 P035-00/ /	ALL
TB0118		BACT44B1775U TB-TRACK,P39	284T0691 81205	1	25-53-21 P039-00/ /	ALL
TB0118D		DIODEBLOCK-REF284T0688- DIODE BLOCK (R155,R157)	284T0688	1	25-53-23 P039-00/ /	ALL
TB0118G		BACM15C1B MDL-TERMINAL BLOCK,P39	286TXXXX 81205	9	25-53-21 P039-00/ /	ALL
TB0118H		BACM15C2A MDL-TERMINAL BLOCK,P39	286TXXXX 81205	6	25-53-21 P039-00/ /	ALL
TB0118Y		BACM15C3B MDL-TERMINAL BLOCK,P51	286T1068 81205	1	25-53-23 P039-00/ /	ALL
TB0118Z		BACM15C3C MDL-TERMINAL BLOCK,P39	286T1068 81205	1	25-53-24 P039-00/ /	ALL
TB0119		284T0384-10 TB-TRACK,E1-5	284T1615 09922	1	22-11-21 SHELF/E01/05	ALL
TB0119D		RESISTORBLOCK-REF284T0115-R34- RESISTOR BLOCK (R34)	284T0115	1	34-46-12 SHELF/E01/05	ALL
TB0119F	9	BACM15C1A TERMINAL BLOCK (MTO-340961)	CUSTOMER 81205	1	34-22-29 SHELF/E01/05	150, 152-199, 275-299
TB0119F		BACM15C1A MDL-TERMINAL BLOCK,E1-5	286TXXXX 81205	1	22-14-21 SHELF/E01/05	ALL
TB0119G		BACM15C1B MDL-TERMINAL BLOCK,E1-5	286TXXXX 81205	1	22-11-22 SHELF/E01/05	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0119H		BACM15C2A MDL-TERMINAL BLOCK,E1-5	286TXXXX 81205	1	22-11-21 SHELF/E01/05	ALL
TB0119X		BACM15C3A MDL-TERMINAL BLOCK,E1-5	286TXXXX 81205	1	31-31-26 SHELF/E01/05	ALL
TB0119Y	9	BACM15C3B TERMINAL BLOCK (MTO-340961)	CUSTOMER 81205	1	34-22-29 SHELF/E01/05	150, 152-199, 275-299
TB0119Y		BACM15C3B MDL-TERMINAL BLOCK,E1-5	286T0109 81205	1	21-61-51 SHELF/E01/05	ALL
TB0119Z		BACM15C3B MDL-TERMINAL BLOCK,E1-5	286TXXXX 81205	1	31-31-19 SHELF/E01/05	ALL
TB0120		BACT44B1050U TB-TRACK,P39	284T0691 81205	1	25-53-24 P039-00/ /	ALL
TB0120D		DIODEBLOCK-REF284T0687- DIODE BLOCK (R155,R156,R157,R158,R290)	286T0000	1	25-53-24 P039-00/ /	050-099, 275-299
TB0120G		BACM15C1B MDL-TERMINAL BLOCK,P39	286TXXXX 81205	20	25-53-24 P039-00/ /	ALL
TB0120H		BACM15C2A MDL-TERMINAL BLOCK,P39	286TXXXX 81205	5	25-53-24 P039-00/ /	ALL
TB0120Y		BACM15C3B MDL-TERMINAL BLOCK,(POS 5)	286T0000 81205	5	25-53-24 P039-00/ /	150-199, 275-299
TB0122		BACT44B0510U TB-TRACK,P39	284T0349 81205	1	25-53-24 P039-00/ /	ALL
TB0122D		DIODEBLOCK-REF284T0687- DIODE BLOCK (R155,R156,R157,R158,R290)	286T0000	1	25-53-24 P039-00/ /	ALL
TB0122F		BACM15C1A MDL-TERMINAL BLOCK,P39	286TXXXX 81205	1	25-53-23 P039-00/ /	150-199, 275-299
TB0122G		BACM15C1B MDL-TERMINAL BLOCK,P39	286TXXXX 81205	13	25-53-21 P039-00/ /	ALL
TB0122H		BACM15C2A MDL-TERMINAL BLOCK,P39	286TXXXX 81205	1	25-53-21 P039-00/ /	ALL
TB0127		284T0384-9 TB-TRACK,E1-4	284T1614 09922	1	22-11-31 SHELF/E01/04	ALL
TB0127F		BACM15C1A MDL-TERMINAL BLOCK,E1-4	286TXXXX 81205	1	22-13-31 SHELF/E01/04	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0127G		BACM15C1B MDL-TERMINAL BLOCK,E1-4	286TXXXX 81205	1	22-11-32 SHELF/E01/04	ALL
TB0127H		BACM15C2A MDL-TERMINAL BLOCK,E1-4	286TXXXX 81205	1	22-11-31 SHELF/E01/04	ALL
TB0127X		BACM15C3A MDL-TERMINAL BLOCK,E1-4	286TXXXX 81205	1	31-35-11 SHELF/E01/04	ALL
TB0127Y		BACM15C3B MDL-TERMINAL BLOCK,E1-4	286TXXXX 81205	1	31-31-22 SHELF/E01/04	ALL
TB0127Z		BACM15C3B MDL-TERMINAL BLOCK,E1-4	286TXXXX 81205	1	31-31-22 SHELF/E01/04	ALL
TB0130		284T0384 TB-TRACK,E1-2	284T1612 09922	1	32-42-11 SHELF/E01/02	ALL
TB0130D		DIODEBLOCK-REF284T0112-R33-R62-R64- DIODE BLOCK (R120-R125,R205,R332-R334)	284T0112	1	34-46-12 SHELF/E01/02	ALL
TB0130F		BACM15C1A MDL-TERMINAL BLOCK,E1-2	286TXXXX 81205	1	32-42-11 SHELF/E01/02	ALL
TB0130G		BACM15C1B MDL-TERMINAL BLOCK,E1-2	286TXXXX 81205	1	32-42-11 SHELF/E01/02	ALL
TB0130H		BACM15C2A MDL-TERMINAL BLOCK,E1-2	286TXXXX 81205	1	32-42-11 SHELF/E01/02	ALL
TB0130R		RESISTORBLOCK-REF284T0112- RESISTOR BLOCK (R10111,R554)	284T1612	1	24-11-11 SHELF/E01/02	ALL
TB0130X		BACM15C3A MDL-TERMINAL BLOCK,E1-2	286TXXXX 81205	1	52-72-11 SHELF/E01/02	ALL
TB0130Y		BACM15C3B MDL-TERMINAL BLOCK, E1-2	286TXXXX 81205	1	32-71-11 SHELF/E01/02	ALL
TB0133		284T0384 TB-TRACK,E2-2	284T1622 09922	1	31-51-51 SHELF/E02/02	ALL
TB0133D	9	DIODEBLOCK DIODE BLOCK (R699) (SB 34-0131)	284T0122	1	34-61-27 SHELF/E02/02	277-299
TB0133D		DIODEBLOCK DIODE BLOCK(R459-R461,R666,R10001,R10002)	284T1622	1	34-61-16 SHELF/E02/02	050-099, 150-199, 275-276
TB0133F		BACM15C1A MDL-TERMINAL BLOCK,E2-2	286TXXXX 81205	1	31-51-51 SHELF/E02/02	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0133G		BACM15C1B MDL-TERMINAL BLOCK,E2-2	286TXXXX 81205	3	31-51-51 SHELF/E02/02	ALL
TB0133H		BACM15C2A MDL-TERMINAL BLOCK,E2-2	286TXXXX 81205	3	31-51-51 SHELF/E02/02	ALL
TB0133X		BACM15C3A MDL-TERMINAL BLOCK,E2-2	286TXXXX 81205	1	34-58-22 SHELF/E02/02	ALL
TB0133Y		BACM15C3B MDL-TERMINAL BLOCK,E2-2	286T0133 81205	1	31-31-25 SHELF/E02/02	ALL
TB0133Z		BACM15C3B MDL-TERMINAL BLOCK,E2-2	286TXXXX 81205	1	31-31-25 SHELF/E02/02	ALL
TB0139		284T0116-1 TB-TRACK,E2-5	284T1625 09922	1	23-21-11 SHELF/E02/05	ALL
TB0139D		DIODEBLOCK-REF284T0125- DIODE BLOCK	284T1625	1	23-21-11 SHELF/E02/05	ALL
TB0139F		BACM15C1A MDL-TERMINAL BLOCK,E2-5	286TXXXX 81205	1	23-21-11 SHELF/E02/05	ALL
TB0139G		BACM15C1B MDL-TERMINAL BLOCK,E2-5	286TXXXX 81205	1	23-22-11 SHELF/E02/05	ALL
TB0139H		BACM15C2A MDL-TERMINAL BLOCK,E2-5	286TXXXX 81205	1	23-11-11 SHELF/E02/05	ALL
TB0139T		RCNETWORKBLOCK-REF284T0125- SUPPRESSOR BLOCK-PTT (R538,R539,R542)	284T1625	1	23-51-14 SHELF/E02/05	ALL
TB0139X		BACM15C3A MDL-TERMINAL BLOCK,E2-5	286TXXXX 81205	1	31-31-26 SHELF/E02/05	ALL
TB0139Y		BACM15C3B MDL-TERMINAL BLOCK,E2-5	286TXXXX 81205	1	31-31-20 SHELF/E02/05	ALL
TB0139Z		BACM15C3C MDL-TERMINAL BLOCK,E2-5	286TXXXX	0	23-12-11 SHELF/E02/05	ALL
TB0141		284T0384 TB-TRACK,E2-1	284T1621 09922	1	27-11-21 SHELF/E02/01	ALL
TB0141F		BACM15C1A MDL-TERMINAL BLOCK,E2-1	286TXXXX 81205	1	30-41-12 SHELF/E02/01	ALL
TB0141G		BACM15C1B MDL-TERMINAL BLOCK,E2-1	286TXXXX 81205	50	27-09-21 SHELF/E02/01	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0141H		BACM15C2A MDL-TERMINAL BLOCK,E2-1	286TXXXX 81205	25	27-09-21 SHELF/E02/01	ALL
TB0141Z	9	BACM15C3B MDL-TERMINAL BLOCK,E2-1 (SB 22-0062)	286TXXXX 81205	1	22-21-31 SHELF/E02/01	275-299
TB0141Z		BACM15C3B MDL-TERMINAL BLOCK,E2-1	286TXXXX 81205	1	22-21-31 SHELF/E02/01	150-199
TB0145		284T0384 TB-TRACK,E2-3	284T1623 09922	1	23-51-12 SHELF/E02/03	ALL
TB0145D		DIODEBLOCK DIODE BLOCK (R267)	284T1623	1	31-31-11 SHELF/E02/03	ALL
TB0145F		BACM15C1A MDL-TERMINAL BLOCK,E2-3	286TXXXX 81205	1	23-51-12 SHELF/E02/03	ALL
TB0145G		BACM15C1B MDL-TERMINAL BLOCK,E2-3	286TXXXX 81205	1	33-31-11 SHELF/E02/03	ALL
TB0145H		BACM15C2A MDL-TERMINAL BLOCK,E2-3	286TXXXX 81205	1	34-12-21 SHELF/E02/03	ALL
TB0145R		RESISTORBLOCK RESISTOR BLOCK	284T1623	1	31-31-11 SHELF/E02/03	ALL
TB0145X		BACM15C3A MDL-TERMINAL BLOCK,E2-3	286TXXXX 81205	1	31-31-26 SHELF/E02/03	ALL
TB0145Y		BACM15C3B MDL-TERMINAL BLOCK,E2-3	286T0145 81205	1	31-31-18 SHELF/E02/03	ALL
TB0145Z		BACM15C3C MDL-TERMINAL BLOCK,E2-3	286TXXXX 81205	1	31-31-18 SHELF/E02/03	ALL
TB0146		BACT44B1350U TB-TRACK,P19	285T0019 81205	1	91-02-76 P019-00/ /	050-099
TB0146		BACT44B1550U TB-TRACK,P19	285T0019 81205	1	91-02-76 P019-00/ /	150-199, 275-299
TB0146F		BACM15C1A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0146G		BACM15C1B MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0146H		BACM15C2A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-22 P019-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 8

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0146X		BACM15C3A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0146Y		BACM15C3B MDL-TERMINAL BLOCK-P19	286TXXXX 81205	1	33-21-11 P019-00/ /	ALL
TB0146Z		BACM15C3C MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0148		BACT44B1350U TB-TRACK,P25	285T0009 81205	1	33-21-21 P025-00/ /	ALL
TB0148D		YHLZD-30 DIODE-ISLN,CTR MOD CMD	284T1106 09922	1	33-25-11 P025-00/ /	050-099, 150-199
TB0148F		BACM15C1A MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-21-22 P025-00/ /	ALL
TB0148G		BACM15C1B MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-21-21 P025-00/ /	ALL
TB0148H		BACM15C2A MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-21-22 P025-00/ /	ALL
TB0148X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	52-11-21 P025-00/ /	ALL
TB0148Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	36-22-11 P025-00/ /	ALL
TB0148Z		BACM15C3C MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-21-21 P025-00/ /	ALL
TB0158		BACT44B0940U TB-TRACK,P50	285T0006 81205	1	21-51-11 P050-00/ /	ALL
TB0158D		DIODEBLOCK-REF284T0049- DIODE BLOCK (R243)	285T5001	1	21-58-11 P050-00/ /	ALL
TB0158F		BACM15C1A MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	21-51-21 P050-00/ /	ALL
TB0158G		BACM15C1B MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	21-51-11 P050-00/ /	ALL
TB0158X		BACM15C3A MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	21-51-21 P050-00/ /	ALL
TB0158Y		BACM15C3B MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	21-51-11 P050-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 9

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0158Z		BACM15C3C MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	21-51-12 P050-00/ /	ALL
TB0160		BACT44B1350U TB-TRACK,P19	285T0019 81205	1	91-02-76 P019-00/ /	050-099
TB0160		BACT44B1550U TB-TRACK,P19	285T0019 81205	1	91-02-76 P019-00/ /	150-199, 275-299
TB0160F		BACM15C1A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0160G		BACM15C1B MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0160H		BACM15C2A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0160X		BACM15C3A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0160Y		BACM15C3B MDL-TERMINAL BLOCK-P19	286TXXXX 81205	1	33-51-11 P019-00/ /	ALL
TB0160Z		BACM15C3C MDL-TERMINAL BLOCK-P19	286TXXXX 81205	1	33-22-42 P019-00/ /	ALL
TB0161		284T0338 TB-TRACK,E1-6	284T0338 09922	1	34-21-11 SHELF/E01/06	ALL
TB0161F		BACM15C1A MDL-TERMINAL BLOCK,E1-6	286T0171 81205	3	34-21-21 SHELF/E01/06	ALL
TB0161G		BACM15C1B MDL-TERMINAL BLOCK,E1-6	286TXXXX 81205	1	34-21-11 SHELF/E01/06	ALL
TB0161H		BACM15C2A MDL-TERMINAL BLOCK,E1-6	286TXXXX 81205	1	34-21-11 SHELF/E01/06	ALL
TB0162		BACT44B1350U TB-TRACK,P25	285T0009 09922	1	33-21-21 P025-00/ /	ALL
TB0162F		BACM15C1A MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-21-21 P025-00/ /	ALL
TB0162G		BACM15C1B MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-21-21 P025-00/ /	ALL
TB0162H		BACM15C2A MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-21-21 P025-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 10

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0162X		BACM15C3A MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-22-42 P025-00/ /	ALL
TB0162Y		BACM15C3B MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-22-42 P025-00/ /	ALL
TB0162Z		BACM15C3C MDL-TERMINAL BLOCK,P25	286TXXXX 81205	1	33-22-42 P025-00/ /	ALL
TB0163		284T0116-4 TB-TRACK,E2-6	284T1626 09922	1	23-11-11 SHELF/E02/06	ALL
TB0163G		BACM15C1B MDL-TERMINAL BLOCK,E2-6	286TXXXX 81205	1	23-11-11 SHELF/E02/06	ALL
TB0164		284T0603 TB-TRACK,E3-1	284T0204 81205	1	21-61-11 SHELF/E03/01	ALL
TB0164F		BACM15C1A MDL-TERMINAL BLOCK,E3-1	286TXXXX 81205	15	21-61-11 SHELF/E03/01	ALL
TB0164X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-61-21 SHELF/E03/01	ALL
TB0164Y		BACM15C3B MDL-TERMINAL BLOCK, E3-1	286TXXXX 81205	1	21-61-51 SHELF/E03/01	ALL
TB0165		284T0151 TB-TRACK,E5-1	284T0151 81205	1	34-33-31 SHELF/E05/01	ALL
TB0165F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	10	34-33-31 SHELF/E05/01	ALL
TB0165G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	10	34-33-31 SHELF/E05/01	ALL
TB0165X		BACM15C3A MDL-TERMINAL BLOCK,E5-1	286TXXXX 81205	1	31-31-26 SHELF/E05/01	ALL
TB0165Y		BACM15C3B MDL-TERMINAL BLOCK,E5-1	286TXXXX 81205	1	31-31-12 SHELF/E05/01	ALL
TB0165Z		BACM15C3B MDL-TERMINAL BLOCK,E5-1	286TXXXX 81205	1	31-31-12 SHELF/E05/01	ALL
TB0166		284T0603 TB-TRACK,E3-1	284T0204 81205	1	21-61-11 SHELF/E03/01	ALL
TB0166D		DIODE-BLOCK-REF284T0131- DIODE BLOCK (R446)	286T0084	1	21-51-12 SHELF/E03/01	050-099, 151-199, 275-299

EQUIPMENT LIST

D280T132

Section TB0100

Page 11

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0166F		BACM15C1A MDL-TERMINAL BLOCK,E3-1	286TXXXX 81205	5	21-61-51 SHELF/E03/01	ALL
TB0166G		BACM15C1B MDL-TERMINAL BLOCK,E3-1	286TXXXX 81205	4	21-51-12 SHELF/E03/01	ALL
TB0166X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-61-11 SHELF/E03/01	ALL
TB0166Y		BACM15C3B MDL-TERMINAL BLOCK,E3-1	286T0084 81205	12	21-51-12 SHELF/E03/01	050-099, 151-199, 275-299
TB0168		284T0603 TB-TRACK,E3-1	284T0204 81205	1	21-61-11 SHELF/E03/01	ALL
TB0168F		BACM15C1A MDL-TERMINAL BLOCK,E3-1	286TXXXX 81205	8	36-23-11 SHELF/E03/01	ALL
TB0168G		BACM15C1B MDL-TERMINAL BLOCK,E3-1	286TXXXX 81205	7	36-11-61 SHELF/E03/01	ALL
TB0168X	9	BACM15C3A MDL-TERMINAL BLOCK,E3-1 (SB 36-0029)	286TXXXX 81205	8	36-23-11 SHELF/E03/01	050-099
TB0168X		BACM15C3A MDL-TERMINAL BLOCK,E3-1	286TXXXX 81205	8	21-51-11 SHELF/E03/01	150-199, 275-299
TB0169G		BACM15C1B MDL-TERMINAL BLOCK,E5-3	286T0000 81205	1	31-31-11 SHELF/E05/03	ALL
TB0170		284T0603 TB-TRACK,E3-1	284T0204 81205	1	21-61-11 SHELF/E03/01	ALL
TB0170F		BACM15C1A MDL-TERMINAL BLOCK,E3-1	286TXXXX 81205	1	21-58-14 SHELF/E03/01	ALL
TB0170G		BACM15C1B MDL-TERMINAL BLOCK,E3-1	286T0084 81205	12	36-11-62 SHELF/E03/01	ALL
TB0174		BACT44B1350U TB-TRACK,P19	285T0019 81205	1	91-02-76 P019-00/ /	050-099
TB0174		BACT44B1550U TB-TRACK,P19	285T0019 81205	1	91-02-76 P019-00/ /	150-199, 275-299
TB0174D		YHLZD-30 DIODE-ISLN,CTR MODE CMD	284T1058 09922	1	33-25-11 P019-00/ /	050-099, 150-199
TB0174F		BACM15C1A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-31 P019-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 12

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0174G		BACM15C1B MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-31 P019-00/ /	ALL
TB0174H		BACM15C2A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-31 P019-00/ /	ALL
TB0174X		BACM15C3A MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	33-21-21 P019-00/ /	ALL
TB0174Y		BACM15C3B MDL-TERMINAL BLOCK-P19	286TXXXX 81205	1	52-11-11 P019-00/ /	ALL
TB0174Z		BACM15C37 MDL-TERMINAL BLOCK,P19	286TXXXX 81205	1	91-00-00 P019-00/ /	ALL
TB0176		284T0384 TB-TRACK,E2-4	284T1624 09922	1	27-51-11 SHELF/E02/04	ALL
TB0176D		DIODEBLOCK-REF284T0124- DIODE BLOCK (R176,R178,R206)	284T1624	1	27-88-11 SHELF/E02/04	ALL
TB0176F		BACM15C1A MDL-TERMINAL BLOCK,E2-4	286TXXXX 81205	1	27-51-11 SHELF/E02/04	ALL
TB0176G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	27-51-11 SHELF/E02/04	ALL
TB0176R		RESISTORBLOCK-REF284T0124- RESISTOR BLOCK (R10112,R00555)	284T1624	1	24-11-21 SHELF/E02/04	ALL
TB0176X		BACM15C3A MDL-TERMINAL BLOCK,E2-4	286TXXXX 81205	1	31-31-22 SHELF/E02/04	ALL
TB0176Z		BACM15C3C MDL-TERMINAL BLOCK	286TXXXX 81205	1	27-51-11 SHELF/E02/04	275-299
TB0178N		MRTB20E09 MDL-TERMINAL BLOCK	286TXXXX 14283	1	34-22-15 P007-00/ /	ALL
TB0180N		MRTB20E09 MDL-TERMINAL BLOCK	286TXXXX 14283	1	34-22-25 P007-00/ /	ALL
TB0182		BACT44B0940U TB-TRACK,P50	285T0006 81205	1	21-58-11 P050-00/ /	ALL
TB0182D		DIODEBLOCK-REF284T0049- DIODE BLOCK (R187-R192,R209-R210)	284T0049	1	27-58-21 P050-00/ /	ALL
TB0182F		BACM15C1A MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	73-21-16 P050-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 13

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0182G		BACM15C1B MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	21-58-11 P050-00/ /	ALL
TB0182H		BACM15C2A MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	27-58-21 P050-00/ /	ALL
TB0182X		BACM15C3A MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	73-21-16 P050-00/ /	ALL
TB0182Y		BACM15C3B MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	21-58-11 P050-00/ /	ALL
TB0182Z		BACM15C3C MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	27-58-21 P050-00/ /	150-199, 275-299
TB0186		BACT44B1428U TB-TRACK,P33	284T0189 81205	1	27-51-11 P033-00/ /	ALL
TB0186D		DIODEBLOCK-REF284T0189- DIODE BLOCK (R161,162,166,172,173,552)	286TXXXX	1	29-11-22 P033-00/ /	ALL
TB0186F		BACM15C1A MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	27-51-11 P033-00/ /	ALL
TB0186G		BACM15C1B MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	27-51-11 P033-00/ /	ALL
TB0186H		BACM15C2A MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	27-51-11 P033-00/ /	ALL
TB0186X		BACM15C3A MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0186Y		BACM15C3B MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0186Z		BACM15C3C MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0188		BACT44B1428U TB-TRACK,P33	284T0623 81205	1	24-31-11 P033-00/ /	ALL
TB0188D	9	DIODEBLOCK-REF-284T0189- DIODE BLOCK (R491) (SB 30-0017)	284T0189	1	30-11-11 P033-00/ /	150-154
TB0188D		DIODEBLOCK-REF-284T0189- DIODE BLOCK (R491)	284T0189	1	30-11-11 P033-00/ /	050-099, 155-199
TB0188F		BACM15C1A MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	24-31-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100
Page 14
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0188G		BACM15C1B MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	24-31-11 P033-00/ /	ALL
TB0188H		BACM15C2A MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	23-34-11 P033-00/ /	ALL
TB0188X		BACM15C3A MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0188Y		BACM15C3B MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0188Z		BACM15C3C MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0190		BACT44B0910U TB-TRACK,P37	284T0188 81205	1	29-21-31 P037-00/ /	ALL
TB0190D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R246)	284T0188	1	29-11-12 P037-00/ /	ALL
TB0190F		BACM15C1A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	7	29-21-31 P037-00/ /	ALL
TB0190G		BACM15C1B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	7	29-21-31 P037-00/ /	ALL
TB0190X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0190Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0190Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	7	91-00-00 P037-00/ /	ALL
TB0192		BACT44B0910U TB-TRACK,P37	284T0622 81205	1	21-53-22 P037-00/ /	ALL
TB0192F		BACM15C1A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	21-53-22 P037-00/ /	ALL
TB0192G		BACM15C1B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	21-53-22 P037-00/ /	ALL
TB0192H		BACM15C2A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	21-53-22 P037-00/ /	ALL
TB0192X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100

Page 15

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0192Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0192Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0196		BACT44B1948U TB-TRACK,P33	284T0623 81205	1	30-71-21 P033-00/ /	ALL
TB0196D		DIODEBLOCK-REF284T0189- DIODE BLOCK (R23,R27,R44,R45,R68,R77)	284T0189	1	29-11-22 P033-00/ /	ALL
TB0196F		BACM15C1A MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	30-71-21 P033-00/ /	ALL
TB0196G		BACM15C1B MDL-TERMIANL BLOCK,P33	286TXXXX 81205	7	30-71-21 P033-00/ /	ALL
TB0196H		BACB15C2A MDL-TERMIANL BLOCK,P33	286TXXXX 81205	7	30-71-22 P033-00/ /	ALL
TB0196X		BACM15C3A MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0196Y		BACM15C3B MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0196Z		BACM15C3C MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0100
Page 16 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0200		BACT44B1948U TB-TRACK,P33	284T0189 81205	1	27-51-51 P033-00/ /	ALL
TB0200D		DIODEBLOCK-REF284T0189- DIODE BLOCK (R244)	284T0189	1	27-62-11 P033-00/ /	ALL
TB0200F		BACM15C1A MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	27-51-51 P033-00/ /	ALL
TB0200G		BACM15C1B MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	27-51-51 P033-00/ /	ALL
TB0200H		BACB15C2A MDL-TERMIANL BLOCK,P33	286TXXXX 81205	7	27-51-52 P033-00/ /	ALL
TB0200R		RESISTORBLOCK-REF284T0189- RESISTOR BLOCK (R570)	284T0189	1	27-62-11 P033-00/ /	ALL
TB0200X		BACM15C3A MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0200Y		BACM15C3B MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0200Z		BACM15C3C MDL-TERMINAL BLOCK-P33	286TXXXX 81205	1	91-00-00 P033-00/ /	ALL
TB0201		284T0019 TB-TRACK	284T0019 81205	1	33-43-11 0139/170/R006	ALL
TB0201F		BACM15C1A MDL-TERMINAL BLOCK	286T0XXX 81205	1	34-43-11 0133/170/R011	ALL
TB0201G		BACM15C1B MDL-TERNINAL BLOCK	284T0019 81205	1	34-43-13 0133/170/R011	050-099
TB0203		284T0020 TB-TRACK	284T0020 81205	1	34-43-13 0164/140/R020	ALL
TB0203F		BACM15C1A MDL-TERMINAL BLOCK	284T0020 81205	1	34-43-21 0164/140/R020	ALL
TB0205		284T0026 TB-TRACK,E1-2	284T1612 09922	1	34-43-11 SHELF/E01/02	ALL
TB0205G		BACM15C1B MDL-TERMINAL BLOCK,E1-2	286TXXXX 81205	1	34-43-11 SHELF/E01/02	ALL
TB0207		BACT44A0580D TB-TRACK	287T4102 81205	1	22-11-12 0163/204/L021	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0207F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	1	22-11-32 0163/204/L021	ALL
TB0207G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	25	22-11-12 0163/204/L021	ALL
TB0209		284T0384-9 TB-TRACK,E1-4	284T1614 09922	1	34-43-11 SHELF/E01/04	ALL
TB0209R		RESISTORBLOCK-REF284T0114- RESISTOR BLOCK (R525,R526,R529,R530)	284T1614	1	34-43-21 SHELF/E01/04	050-099, 150-199
TB0209R		RESISTORBLOCK-REF284T0114- RESISTOR BLOCK (R525,R526)	284T0114	1	34-43-11 SHELF/E01/04	275-299
TB0210		BACT44B0910U TB-TRACK,P37	284T0188 81205	1	32-09-12 P037-00/ /	ALL
TB0210F		BACM15C1A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	7	32-09-12 P037-00/ /	ALL
TB0210G		BACM15C1B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	32-09-12 P037-00/ /	ALL
TB0210H		BACM15C2A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	32-09-12 P037-00/ /	ALL
TB0210X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0210Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0210Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0211		284T0026 TB-TRACK,E1-5	284T1615 09922	1	34-43-21 SHELF/E01/05	ALL
TB0211G		BACM15C1B MDL-TERMINAL BLOCK,E1-5	286TXXXX 81205	1	34-43-21 SHELF/E01/05	ALL
TB0212		BACT44B0910U TB-TRACK,P37	284T0188 81205	1	27-81-21 P037-00/ /	ALL
TB0212F		BACM15C1A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	7	32-09-12 P037-00/ /	ALL
TB0212G		BACM15C1B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	7	27-81-21 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0212H		BACM15C2A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	7	27-81-21 P037-00/ /	ALL
TB0212X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0212Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0212Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0214Z		BACM15C3C MDL-TERMINAL BLOCK,P1	286TXXXX 81205	7	34-22-81 P001-00/ /	ALL
TB0215		BACT44A0700U TB-TRACK,P10	253T5100 81205	1	27-61-12 0200/205/L006	ALL
TB0215F		BACM15C1A MDL-TERMINAL BLOCK,P10	286TXXXX 81205	18	27-61-12 0200/205/L006	ALL
TB0215G		BACM15C1B MDL-TERMINAL BLOCK,P10	286TXXXX 81205	1	27-61-12 0200/205/L006	ALL
TB0216		BACT44B0910U TB-TRACK,P36	284T0187 81205	1	32-09-11 P036-00/ /	ALL
TB0216F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	32-09-11 P036-00/ /	ALL
TB0216G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	32-09-11 P036-00/ /	ALL
TB0216H		BACM15C2A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	32-09-11 P036-00/ /	ALL
TB0216X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0216Y	9	BACM15C3B MDL-TERMINAL BLOCK,P36 (SB 21-0139)	289T1039 81205	1	21-45-21 P036-00/ /	275-299
TB0216Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	050-099, 150-199
TB0216Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0217		BACT44A0400U TB-TRACK,P10	253T5100 81205	1	27-61-13 0200/205/L006	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0217G		BACM15C1B MDL-TERMINAL BLOCK,P10	286TXXXX 81205	1	27-61-13 P010-00/ /	ALL
TB0217H		BACM15C2A MDL-TERMINAL BLOCK,P10	286TXXXX 81205	1	27-61-13 0200/205/L006	ALL
TB0218		BACT44B0910U TB-TRACK,P36	284T0187 81205	1	32-09-11 P036-00/ /	ALL
TB0218F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	32-09-11 P036-00/ /	ALL
TB0218G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	32-09-11 P036-00/ /	ALL
TB0218H		BACM15C2A MDL-TERMINAL BLOCK-P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0218X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0218Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0218Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0219		BACT44A0600U TB-TRACK,P10	253T5200 81205	1	32-42-12 P010-00/ /	ALL
TB0219F		BACM15C1A MDL-TERMINAL BLOCK,P10	286TXXXX 81205	1	32-42-12 P010-00/ /	ALL
TB0219G		BACM15C1B MDL-TERMINAL BLOCK,P10	286TXXXX 81205	1	32-42-12 P010-00/ /	ALL
TB0219H		BACM15C2A MDL-TERMINAL BLOCK,P10	286TXXXX 81205	1	32-42-12 P010-00/ /	ALL
TB0220		BACT44B0910U TB-TRACK,P36	284T0187 81205	1	32-09-11 P036-00/ /	ALL
TB0220F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	32-09-11 P036-00/ /	ALL
TB0220G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	32-09-11 P036-00/ /	ALL
TB0220H		BACM15C2A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	78-34-11 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0220X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0220Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0220Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	150-199, 275-299
TB0222		BACT44B0910U TB-TRACK,P36	284T0187 81205	1	91-00-00 P036-00/ /	ALL
TB0222F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	1	38-12-11 P036-00/ /	150-199, 275-299
TB0222G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0222H		BACM15C2A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0222X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0222Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0222Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0237R		RESISTORBLOCK-REF284T1067- RESISTOR BLOCK (R543,R550)	284T1067	1	49-71-11 SHELF/E08/00	ALL
TB0237X		BACM15C3A MDL-TERMINAL BLOCK,E8 SHELF	286TXXXX 81205	2	21-64-11 SHELF/E08/00	ALL
TB0237Y		BACM15C3B MDL-TERMINAL BLOCK,E8 SHELF	286TXXXX 81205	2	24-34-11 SHELF/E08/00	ALL
TB0237Z		BACM15C3C MDL-TERMINAL BLOCK,E8 SHELF	286TXXXX 81205	3	21-52-11 SHELF/E08/00	ALL
TB0239		BACM15C3B TB-TRACK,E8 SHELF	284T0972 81205	1	31-41-12 SHELF/E08/00	ALL
TB0239X		BACM15C3A MDL-TERMINAL BLOCK,E8 SHELF	286TXXXX 81205	12	31-41-12 SHELF/E08/00	ALL
TB0239Y		BACM15C3B MDL-TERMINAL BLOCK,E8 SHELF	286TXXXX 81205	3	31-41-12 SHELF/E08/00	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0239Z		BACM15C3C MDL-TERMINAL BLOCK,E8 SHELF	286TXXXX 81205	4	31-41-12 SHELF/E08/00	ALL
TB0241		BACT44B0630U TRACK-BURNDY,INBOARD,P1	233T2322 81205	1	31-41-14 0157/232/L032	ALL
TB0241X		BACM15C3A MDL-TERMINAL BLOCK,P1	286TXXXX 81205	1	34-22-81 P001-00/ /	ALL
TB0241Y		BACM15C3B MDL-TERMINAL BLOCK,P1	286TXXXX 81205	1	34-22-81 P001-00/ /	ALL
TB0243		BACT44B0630U TRACK-BURNDY,INBOARD,P3	233T2322 81205	1	31-25-11 0157/232/R032	ALL
TB0243X		BACM15C3A MDL-TERMINAL BLOCK,P3	286TXXXX 81205	1	34-22-91 P003-00/ /	ALL
TB0243Y		BACM15C3B MDL-TERMINAL BLOCK,P3	286TXXXX 81205	1	34-22-91 P003-00/ /	ALL
TB0243Z		BACM15C3C MDL-TERMINAL BLOCK,P3	286TXXXX 81205	7	34-22-91 P003-00/ /	ALL
TB0245		BACT44B0630U TRACK-BURNDY,OUTBOARD,P1	233T2322 81205	1	31-41-14 0157/232/L032	ALL
TB0245Y		BACM15C3B MDL-TERMINAL BLOCK,P1	286TXXXX 81205	1	33-16-12 P001-00/ /	ALL
TB0245Z		BACM15C3C MDL-TERMINAL BLOCK,P1	286TXXXX 81205	1	33-16-12 P001-00/ /	ALL
TB0247		BACT44B0630U TRACK-BURNDY,OUTBOARD,P3	233T2322 81205	1	33-11-11 0157/232/R032	ALL
TB0247X		BACM15C3A MDL-TERMINAL BLOCK,P3	286TXXXX 81205	1	34-12-21 0158/212/R033	ALL
TB0247Y		BACM15C3B MDL-TERMINAL BLOCK,P3	286TXXXX 81205	1	33-11-11 P003-00/ /	ALL
TB0247Z		BACM15C3C MDL-TERMINAL BLOCK,P3	286TXXXX 81205	1	33-13-11 P003-00/ /	ALL
TB0248		BACT44B0770U TB-TRACK,P50	285T0006 81205	1	21-51-11 P050-00/ /	ALL
TB0248D		DIODEBLOCK-REF284T0049- DIODE BLOCK (R112,R113)	284T0049	1	21-25-11 P050-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0248F		BACM15C1A MDL-TERMINAL BLOCK,P50	286T1114 81205	1	31-51-41 P050-00/ /	ALL
TB0248X		BACM15C3A MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	30-34-11 P050-00/ /	ALL
TB0248Y		BACM15C3B MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	21-51-11 P050-00/ /	ALL
TB0248Z		BACM15C3C MDL-TERMINAL BLOCK,P50	286TXXXX 81205	1	73-21-11 P050-00/ /	ALL
TB0249		BACT44B0200U TB-TRACK	233T2317 81205	1	33-13-11 / /	ALL
TB0249R		RESISTORBLOCK-233T2402- RESISTOR BLOCK (R557, R558)	233T2404	1	33-13-11 0154/220/	ALL
TB0250		BACT44B0430U TB-TRACK	284T0187 81205	1	30-21-11 P036-00/ /	ALL
TB0250D		DIODEBLOCK-REF284T0187- DIODE BLOCK	286TXXXX 81205	1	21-58-12 P036-00/ /	ALL
TB0250G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	27-32-31 P036-00/ /	ALL
TB0250H		BACM15C2A MDL-TERMINAL BLOCK	286TXXXX 81205	1	73-21-11 P036-00/ /	ALL
TB0250X		BACM15C3A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0250Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	30-21-11 P036-00/ /	ALL
TB0250Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	21-58-12 P036-00/ /	ALL
TB0252		BACT44B0430U TB-TRACK	284T0187 81205	1	91-00-00 P036-00/ /	ALL
TB0252D		DIODEBLOCK-REF284T0187- DIODE BLOCK (R563)	286TXXXX	1	21-58-16 P036-00/ /	ALL
TB0252F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	25-31-31 P036-00/ /	050-099, 150-199, 275-276, 280-299
TB0252G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	27-32-31 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 7

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0252Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	31-31-11 P036-00/ /	ALL
TB0252Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	21-58-12 P036-00/ /	ALL
TB0253		MS27212-3-3 TS-ELEC PWR FDR P32 TO A4	286T0226 81205	1	25-31-21 1454/314/L032	050-099, 150-199
TB0254		BACT44B0680U TB-TRACK,P37	284T0188 81205	1	91-00-00 P037-00/ /	ALL
TB0254D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R373)	284T0188	1	30-21-11 P037-00/ /	050-099, 150-199
TB0254D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R373)	286TXXXX	1	30-21-11 P037-00/ /	275-299
TB0254F		BACM15C1A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	25-31-11 P037-00/ /	050-099, 150-199
TB0254G		BACM15C1B MDL-TERMINAL BLOCK,P37	286T0192 81205	1	36-11-61 P037-00/ /	ALL
TB0254X		BACM15C3A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	150-199, 275-299
TB0254Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	21-61-21 P037-00/ /	ALL
TB0254Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0255		BACT44A0920D TB-TRACK,P8	287T4109 09922	1	31-36-11 0212/195/L045	ALL
TB0255X		BACM15C3A HI DENS X-BLK,P8	286T0517 81205	7	33-13-18 0212/195/L045	ALL
TB0255Y		BACM15C3B MDL-TERMINAL BLOCK,P8	286T0517 81205	7	23-22-11 0212/195/L045	ALL
TB0257		284T1329 TB-TRACK E9 SHELF	284T1326 81205	1	23-25-11 SHELF/E09/01	156-157, 166-199, 277-299
TB0257F	9	BACM15C1A MDL-TERMINAL BLOCK,E9-1	286TXXXX 81205	20	23-25-13 SHELF/E09/01	150, 153-155, 162- 165
TB0257F		BACM15C1A MDL-TERMINAL BLOCK,E9-1	286TXXXX 81205	20	23-25-13 SHELF/E09/01	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section TB0200

Page 8

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0257G	9	BACM15C1B MDL-TERMINAL BLOCK,E9-1 (MTO 230591)	286TXXXX 81205	80	23-25-17 SHELF/E09/01	150, 153-155, 162-165
TB0257G	9	BACM15C1B T-BLOCK (TO-230718)	CUSTOMER 81205	1	23-32-21 SHELF/E09/01	152
TB0257G		BACM15C1B MDL-TERMINAL BLOCK,E9-1	286TXXXX 81205	80	23-25-17 SHELF/E09/01	156-157, 166-199, 277-299
TB0257H	9	BACM15C2A MDL-TERMINAL BLOCK,E9-1 (MTO 230591)	286TXXXX 81205	60	23-25-11 SHELF/E09/01	150, 153-155, 162-165
TB0257H		BACM15C2A MDL-TERMINAL BLOCK,E9-1	286TXXXX 81205	60	23-25-11 SHELF/E09/01	150, 153-199, 277-299
TB0257Y		BACM15C3B MDL-TERMINAL BLOCK,E9-1	286TXXXX 81205	1	23-25-13 SHELF/E09/01	280-299
TB0257Z		BACM15C3B MDL-TERMINAL BLOCK,E9-1	286TXXXX 81205	1	23-25-11 SHELF/E09/01	277-299
TB0258		BACT44B0310U TB-TRACK,P36	284T0187 81205	1	91-02-70 P036-00/ /	ALL
TB0258D	9	DIODEBLOCK-REF284T3601- DIODE BLOCK (MULTI) (SB 73-0043)	286TXXXX 81205	1	73-21-19 P036-00/ /	275-299
TB0258Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	76-11-11 P036-00/ /	155-199, 277-299
TB0260		BACT44B0310U TB-TRACK,P36	284T0187 81205	1	21-45-21 P036-00/ /	ALL
TB0260D		DIODEBLOCK-REF284T0187- DIODE BLOCK (R262,R272,R273)(SB 36-0029)	286TXXXX	1	21-45-21 P036-00/ /	050-099
TB0260D		DIODEBLOCK-REF284T0187- DIODE BLOCK (R262,R272,R273)	286TXXXX	1	21-45-21 P036-00/ /	150-199, 275-299
TB0260F		BACM15C1A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	91-00-00 P036-00/ /	ALL
TB0260G		BACM15C1B MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	32-09-11 P036-00/ /	ALL
TB0260X		BACM15C3A MDL-TERMINAL BLOCK,P36	286T0000 81205	1	91-00-00 P036-00/ /	ALL
TB0260Y		BACM15C3B MDL-TERMINAL BLOCK,P36	286T0176 81205	1	91-00-00 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 9

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0260Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286T0176 81205	1	91-00-00 P036-00/ /	ALL
TB0262		BACT44B0310U TB-TRACK,P37	248T0188 81205	1	26-23-12 P037-00/ /	ALL
TB0262D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R248,R249)	286TXXXX 81205	1	26-23-12 P037-00/ /	050-099, 150-199
TB0262G		BACM15C1B MDL-TERMINAL BLOCK-P37	286TXXXX 81205	1	26-23-12 P037-00/ /	050-099, 275-299
TB0262G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	33-44-21 P037-00/ /	150-199
TB0262Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	26-23-12 P037-00/ /	ALL
TB0262Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	26-23-12 P037-00/ /	ALL
TB0264		BACT44B0310U TB-TRACK,P37	248T0188 81205	1	26-23-12 P037-00/ /	ALL
TB0264D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R270,R271,R272,R273,R274)	286TXXXX	1	21-45-21 P037-00/ /	050-099
TB0264D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R270,R271,R272,R273,R274)	286TXXXX	1	21-58-12 P037-00/ /	150-199, 275-299
TB0264F		BACM15C1A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	21-58-12 P037-00/ /	ALL
TB0264Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0266		BACT44B1948U TB-TRACK-P33	284T0189 81205	1	21-58-17 P033-00/ /	ALL
TB0266D	9	DIODEBLOCK-REF284T0187- DIODE BLOCK (SB 30-0017)	286T0142	1	30-81-11 P033-00/ /	150-154
TB0266D		DIODEBLOCK-REF284T0189- DIODE BLOCK	286TXXXX	1	21-58-17 P033-00/ /	050-099, 155-199
TB0266R	9	RESISTORBLOCK-REF284T0189- RESISTOR BLOCK (R674,R675) (SB 30-0017)	284T0189	1	30-81-11 P033-00/ /	150-154
TB0266R		RESISTORBLOCK-REF284T0189- RESISTOR BLOCK (R674,R675)	286TXXXX	1	30-81-11 P033-00/ /	050-099, 155-199

EQUIPMENT LIST

D280T132

Section TB0200

Page 10

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0266X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-58-17 P033-00/ /	ALL
TB0266Y	9	BACM15C3B MDL-TERMINAL BLOCK (SB 30-0017)	286T0142 81205	1	30-81-11 P033-00/ /	150-154
TB0266Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-58-17 P033-00/ /	050-099, 155-199
TB0266Z	9	BACM15C3C MDL-TERMINAL BLOCK,P33 (SB 30-0017)	286T0142 81205	1	30-80-11 P033-00/ /	150-154
TB0266Z		BACM15C3C MDL-TERMINAL BLOCK,P33	286T0XXX 81205	1	21-58-17 P033-00/ /	050-099, 155-199
TB0268		BACT44B1948U TB-TRACK-P33	284T0189 81205	1	29-11-22 P033-00/ /	ALL
TB0268D		DIODEBLOCK-REF286T0189- DIODE BLOCK (R263,R264,R269)	284T0189	1	29-11-22 P033-00/ /	ALL
TB0268G		BACM15C1B MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	30-71-21 P033-00/ /	ALL
TB0268X		BACM15C3A MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	27-58-11 P033-00/ /	ALL
TB0268Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	30-11-11 P033-00/ /	050-099
TB0268Y		BACM15C3B MDL-TERMINAL BLOCK	286T0142 81205	1	30-11-11 P033-00/ /	150-199
TB0268Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	29-11-22 P033-00/ /	275-299
TB0268Z	9	BACM15C3C MDL-TERMINAL BLOCK,P33 (SB 30-0017)	286TXXXX 81205	1	30-81-11 P033-00/ /	150-154
TB0268Z		BACM15C3C MDL-TERMINAL BLOCK,P33	286TXXXX 81205	1	29-11-22 P033-00/ /	050-099, 155-199
TB0272		BACT44B0910U TB-TRACK,P36	284T0187 81205	1	25-31-21 P036-00/ /	ALL
TB0272D		DIODEBLOCK-REF284T0187- DIODE BLOCK	284T0187	1	29-11-32 P036-00/ /	ALL
TB0272F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	1	28-41-12 P036-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 11

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0272G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	28-41-12 P036-00/ /	ALL
TB0272H		BACM15C2A MDL-TERMINAL BLOCK	286TXXXX 81205	1	28-41-12 P036-00/ /	ALL
TB0272R		RESISTORBLOCK DIODE BLOCK	284T0187	1	21-51-11 P036-00/ /	ALL
TB0272X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	24-51-71 P036-00/ /	ALL
TB0272Y		BACM15C3B MDL-TERMINAL BLOCK	286T0176 81205	1	28-41-11 P036-00/ /	ALL
TB0272Z		BACM15C3C MDL-TERMINAL BLOCK,P36	286T0176 81205	1	28-41-11 P036-00/ /	ALL
TB0274		BACT44B0910U TB-TRACK,P37	284T0188 81205	1	33-44-21 P037-00/ /	ALL
TB0274D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R314)	284T0188	1	27-09-13 P037-00/ /	ALL
TB0274F		BACM15C1A MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	36-11-41 P037-00/ /	ALL
TB0274G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	33-44-21 P037-00/ /	ALL
TB0274X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-58-14 P037-00/ /	ALL
TB0274Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	78-36-11 P037-00/ /	ALL
TB0274Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	30-71-24 P037-00/ /	ALL
TB0276		BACT44B1870U TB-TRACK,P54	285T0509 81205	1	26-11-11 P054-00/ /	ALL
TB0276Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	5	26-11-11 P054-00/ /	ALL
TB0276Z		BACM15C3C MDL-TERMINAL BLOCK	286TXXXX 81205	5	26-11-11 P054-00/ /	ALL
TB0278		BACT44B0200U TB-TRACK	233T4403 81205	1	33-13-16 0194/295/L029	ALL

EQUIPMENT LIST

D280T132

Section TB0200

Page 12

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0278R		RESISTORBLOCK-REF233T4403- RESISTOR BLOCK (R559,R560)	233T4403	1	33-13-16 0194/295/L029	ALL
TB0286		BACT44A0460D TB-TRACK,P11	233T5206 81205	1	26-11-11 P011-05/ /	ALL
TB0286D		DIODEBLOCK-REF233T5216- DIODE BLOCK	233T5216	1	26-11-11 P011/05/	ALL
TB0288		284T0384 TB-TRACK,E1-2	284T1612 09922	1	91-00-00 SHELF/E01/02	ALL
TB0288D		DIODEBLOCK-REF284T0112- DIODE BLOCK-(R179 THRU R184)	284T1612	1	91-00-00 SHELF/E01/02	ALL
TB0292		BACT44B0300U TB-TRACK,P11	233T5216 81205	1	24-51-31 0200/276/R010	ALL
TB0292F		BACM15C1A MDL-TERMINAL BLOCK,P11	286T0040 81205	8	24-51-31 P011-00/ /	ALL
TB0294		BACT44B0220U TB-TRACK,P49	284T1149 81205	1	49-61-11 P049-00/ /	ALL
TB0294F		BACM15C1A MDL-TERMINAL BLOCK,P49	284T1149 81205	4	49-61-11 P049-00/ /	ALL
TB0294G		BACM15C1B MDL-TERMINAL BLOCK,P49	284T1149 81205	1	38-32-11 P049-00/ /	ALL
TB0294R	9	RESISTORBLOCK-REF284T0398- RESISTOR BLOCK (R690,R691) (SB 38-0034)	284T1149	1	38-32-11 P049-00/ /	275-276
TB0294R		RESISTORBLOCK-REF284T0398- RESISTOR BLOCK (R690,R691)	284T1149	1	38-32-11 P049-00/ /	275-276

EQUIPMENT LIST

D280T132

Section TB0200

Page 13 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0300D		DIODEBLOCK-REF284T1149- DIODE BLOCK (R241)	284T1149	1	24-31-41 P049-00/ /	050-099
TB0300F		BACM15C1A MDL-TERMINAL BLOCK,P49	284T1149 81205	1	24-31-41 P049-00/ /	ALL
TB0300G		BACM15C1B MDL-TERMINAL BLOCK,P49	284T1149 81205	1	24-31-41 P049-00/ /	ALL
TB0300X		BACM15C3A MDL-TERMINAL BLOCK-P49	284T1149 81205	2	91-00-00 P049-00/ /	ALL
TB0300Y		BACM15C3B MDL-TERMINAL BLOCK-P49	284T1149 81205	5	91-00-00 P049-00/ /	ALL
TB0300Z		BACM15C3C MDL-TERMINAL BLOCK-P49	284T1149 81205	2	91-00-00 P049-00/ /	ALL
TB0302		BACT44B1200U TB-TRACK,P36	284T0187 81205	1	21-43-11 P036-00/ /	ALL
TB0302D		DIODEBLOCK-REF284T0187- DIODE BLOCK (R441)	286TXXXX	1	28-31-12 P036-00/ /	050-099, 155-199, 276-299
TB0302F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-25-11 P036-00/ /	ALL
TB0302G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-25-11 P036-00/ /	ALL
TB0302H		BACM15C2A MDL-TERMINAL BLOCK,P36	286TXXXX 81205	1	73-21-11 P036-00/ /	280-299
TB0302R		RESISTORBLOCK DIODE BLOCK	284T3601	1	24-11-11 P036-00/ /	ALL
TB0302X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-43-11 P036-00/ /	ALL
TB0302Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-43-11 P036-00/ /	ALL
TB0302Z		BACM15C3C MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-43-11 P036-00/ /	ALL
TB0304		BACT44B1200U TB-TRACK,P37	284T0188 81205	1	21-44-11 P037-00/ /	ALL
TB0304F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	1	38-32-11 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0300

Page 1

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0304G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	38-32-11 P037-00/ /	ALL
TB0304H		BACM15C2A MDL-TERMINAL BLOCK,P36	286T0188 81205	1	73-21-11 P037-00/ /	ALL
TB0304R		RESISTORBLOCK DIODE BLOCK	284T3701	1	24-11-21 P037-00/ /	ALL
TB0304X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-52-11 P037-00/ /	ALL
TB0304Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-44-11 P037-00/ /	ALL
TB0304Z		BACM15C3C MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-44-11 P037-00/ /	ALL
TB0306		BACT44B0700U TB-TRACK,P35	284T0687 81205	1	25-53-15 P035-00/ /	ALL
TB0306Y		BACM15C3B MDL-TERMINAL BLOCK,P35	286TXXXX 81205	0	25-53-15 P035-00/ /	ALL
TB0306Z		BACM15C3C MDL-TERMINAL BLOCK,P35	286TXXXX 81205	0	25-53-15 P035-00/ /	ALL
TB0307		BACT44A0580D TB-TRACK,CONTROL COLUMN	287T4109 09922	1	22-11-32 0163/204/R021	ALL
TB0307F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	1	22-11-32 0163/204/R021	ALL
TB0307G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	23-51-21 0165/200/R020	ALL
TB0308		BACT44B0700U TB-TRACK,P39	284T0688 81205	1	25-53-25 P039-00/ /	ALL
TB0308Y		BACM15C3B MDL-TERMINAL BLOCK,P39	286TXXXX 81205	0	25-53-25 P039-00/ /	ALL
TB0308Z		BACM15C3C MDL-TERMINAL BLOCK,P39	286TXXXX 81205	0	25-53-25 P039-00/ /	ALL
TB0310		BACM15C3B MDL-TERMINAL BLOCK, P65	286T0000 81205	1	24-25-11 P065-00/ /	ALL
TB0310Y		BACM15C3B MDL-TERMINAL BLOCK,P65	286T0000 81205	1	24-25-11 P065-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0300

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0310Z		BACM15C3C MDL-TERMINAL BLOCK,P65	286T0000 81205	1	24-25-11 P065-00/ /	ALL
TB0314		BACT44B0405U TB-TRACK,P37	284T0622 81205	1	21-33-11 P037-00/ /	050-099, 162-199, 275-299
TB0314X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-36-31 P037-00/ /	ALL
TB0314Y		BACM15C3B MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0314Z		BACM15C3C MDL-TERMINAL BLOCK,P37	286TXXXX 81205	1	91-00-00 P037-00/ /	ALL
TB0318		BACT44B1200U TB-TRACK,P36	284T0187 81205	1	21-43-11 P036-00/ /	ALL
TB0318D	9	DIODEBLOCK-REF284T0187- DIODE BLOCK (R466)		1	21-66-11 P036-00/ /	150, 152-157
TB0318D		DIODEBLOCK-REF284T0187- DIODE BLOCK (R466)	284T0187	1	21-66-11 P036-00/ /	050-099, 162-199
TB0318F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-25-11 P036-00/ /	ALL
TB0318G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-25-11 P036-00/ /	ALL
TB0318H		BACM15C2A MDL-TERMINAL BLOCK	286TXXXX 81205	1	28-41-12 P036-00/ /	ALL
TB0318X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-43-11 P036-00/ /	ALL
TB0318Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-43-11 P036-00/ /	ALL
TB0318Z		BACM15C3C MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-43-11 P036-00/ /	ALL
TB0320		BACT44B1200U TB-TRACK,P37	284T0188 81205	1	32-45-12 P037-00/ /	ALL
TB0320D		DIODEBLOCK-REF284T0188- DIODE BLOCK (R447)	286T0192	1	21-61-81 P037-00/ /	ALL
TB0320F		BACM15C1A MDL-TERMINAL BLOCK	286TXXXX 81205	1	38-32-11 P037-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0300

Page 3

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0320G		BACM15C1B MDL-TERMINAL BLOCK	286TXXXX 81205	1	38-32-11 P037-00/ /	ALL
TB0320R		RESISTORBLOCK-REF284T0188- RESISTOR BLOCK (R656,R657)	284T0192	1	21-61-81 P037-00/ /	ALL
TB0320X		BACM15C3A MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-52-11 P037-00/ /	ALL
TB0320Y		BACM15C3B MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-43-11 P037-00/ /	ALL
TB0320Z		BACM15C3C MDL-TERMINAL BLOCK	286TXXXX 81205	1	21-44-11 P037-00/ /	ALL
TB0322		284T0384 TB-TRACK,E1 FWD LEFT OUTBOARD STANCHION	00000000 09922	1	30-41-11 0331/173/L048	150-199, 275-299
TB0322F		BACM15C1A MDL-TERMINAL BLOCK,E1 FWD L OUTBD STAN	00000000 81205	6	30-41-11 0331/173/L048	150-199, 275-299
TB0324		284T0384 TB-TRACK,E2 FWD RIGHT OUTBOARD STANCHION	00000000 09922	1	30-41-12 0331/173/R044	150-199, 275-299
TB0324F		BACM15C1A MDL-TERMINAL BLOCK,E2 FWD R OUTBD STAN	00000000 81205	16	30-41-12 0331/173/R044	150-199, 275-299
TB0336Y		BACM15C3E MDL-TERMINAL BLOCK, P101	286T2134 81205	1	91-00-00 P101-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0300

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0450	9	BACT44B0400U TB-TRACK,P089 (SB 28-0027)	284T1351 81205	1	28-31-22 220/166/R055	150-154, 275-276
TB0450D	9	DIODEBLOCK DIODE BLOCK (R441)	286T1351 81205	1	28-31-22 P089-00/ /	150-154, 275-276
TB0450G	9	BACM15C1B MDL-TERMINAL BLOCK,P089 (SB 28-0027)	286T1351 81205	1	28-31-22 P089-00/ /	150-154, 275-276
TB0452	9	BACT44B0400U TB-TRACK,P089 (SB 28-0027)	284T1351 81205	1	28-31-22 220/166/R055	150-154, 275-276
TB0452D	9	DIODEBLOCK DIODE BLOCK (R442,R470,R471)(SB 28-0027)	286T1351 81205	1	28-31-22 P089-00/ /	150-154, 275-276
TB0452G	9	BACM15C1B MDL-TERMINAL BLOCK,P089 (SB 28-0027)	286T1351 81205	1	28-31-22 P089-00/ /	150-154, 275-276
TB0454		BACT44B0600U TB-TRACK,P87	284T8703 81205	1	21-45-23 P087-00/ /	278-299
TB0456		BACT44B0700U TB-TRACK,P87	284T8703 81205	1	21-45-23 P087-00/ /	278-299
TB0456Y		BACM15C3B MDL-TERMINAL BLOCK,P87	286TXXXX 81205	1	91-00-00 P087-00/ /	ALL
TB0456Z		BACM15C3C MDL-TERMINAL BLOCK,P87	286TXXXX 81205	1	91-00-00 P087-00/ /	ALL
TB0458D		DIODEBLOCK-REF284T0189- DIODE BLOCK (R700,R702,R704)		1	78-34-11 P033-00/ /	ALL
TB0458X		BACM15C3A MDL-TERMINAL BLOCK-P33		1	78-34-11 P033-00/ /	ALL
TB0458Y		BACM15C3B MDL-TERMINAL BLOCK-P33		1	78-34-11 P033-00/ /	ALL
TB0458Z		BACM15C3C MDL-TERMINAL BLOCK-P33		1	78-34-11 P033-00/ /	ALL
TB0460D		DIODEBLOCK DIODE BLOCK (R701,R703,R705)		1	78-34-21 P033-00/ /	ALL
TB0460X		BACM15C3A MLD-TERMINAL BLOCK-P33		1	78-36-21 P033-00/ /	ALL
TB0460Y		BACM15C3B MDL-TERMINAL BLOCK-P33		1	78-36-21 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0400

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB0460Z		BACM15C3C MDL-TERMINAL BLOCK-P33		1	78-36-21 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB0400

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5002		MS27212-3-3 TS-ELEC PWR L P6	284T0995 96906	1	24-51-11 P006-03/ /	ALL
TB5008		MS27212-2-3 TS-ELEC PWR R P6	284T0995 96906	1	24-32-11 P006-04/ /	ALL
TB5010		MS27212-3-5 TS-ELEC PWR L P6	284T0995 96906	1	24-32-11 P006-02/ /	ALL
TB5012		MS27212-1-3 TS-ELEC PWR R P6	284T0997 96906	1	24-32-11 P006-00/ /	ALL
TB5014		MS27212-4-3-MS27212-4-1 TS-ELEC PWR L P6	284T0997 96906	1	24-32-11 P006-01/ /	ALL
TB5020		MS27212-2-16 TS-GEN PWR BUS L P11-1	233T5216 96906	1	24-54-73 P011-00/280/0000	ALL
TB5022		MS27212-2-16 TS-GEN PWR BUS R P11	233T5216 96906	1	24-54-71 0218/286/R015	ALL
TB5032		MS27212-2-6 TS-LOAD DISTRIBUTION,P31	284T0171 96906	1	24-51-12 P031-00/ /	ALL
TB5034		MS27212-2-6 TS-LOAD DISTRIBUTION,P32	284T0172 96906	1	24-51-22 P032-00/ /	ALL
TB5076		MS27212-1-14 TS-P36	284T0187 96906	1	23-34-11 P036-00/ /	ALL
TB5078		MS27212-1-14 TS-P37	284T0188 96906	1	38-32-11 P037-00/ /	ALL
TB5096		MS27212-2-12 TS-P33	284T0189 96906	1	25-29-11 P033-00/ /	ALL

EQUIPMENT LIST

D280T132

Section TB5000
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB5100		MS27212-2-2 TS-UTIL LIGHT,1ST OBSR	232T5002 96906	1	33-14-31 0223/260/L052	ALL
TB5102		MS27212-2-2 TS-FLT KIT LIGHT,CAPT	232T5002 96906	1	33-14-31 0165/215/L053	ALL
TB5104		MS27212-2-2 TS-FLT KIT LIGHT,F/O	232T5002 96906	1	33-14-31 0164/220/R045	ALL
TB5108		MS27212-2-2 TS-UTIL LIGHT,2ND OBSR	232T5002 96906	1	33-14-31 0262/285/R007	ALL
TB5120		MS27212-2-6 TS-P23	284T0905 96906	1	33-42-11 P023-00/ /	ALL
TB5122		MS27212-2-6 TS-P23	284T0905 96906	1	33-42-21 P023-00/ /	ALL
TB5124		MS27212-2-6 TS-P23	284T0905 96906	1	33-42-11 P023-00/ /	ALL
TB5126		MS27212-2-3 TS-FUEL OVERFILL SHUTOFF CONTROL	344T0053 96906	1	28-21-12 R0990/12/RS	ALL
TB5128		MS27212-2-3 TS-FUEL OVERFILL SHUTOFF CONTROL	344T0053 96906	1	28-21-12 L0990/12/RS	ALL
TB5130		MS27212-2-8 TS-P36	284T0187 96906	1	21-25-11 P036-00/ /	ALL
TB5132		MS27212-2-8 TS-P37	284T0188 96906	1	21-25-21 P037-00/ /	ALL
TB5152		MS27212-2-10 TS-GEN PWR BUS R P11	233T5216 96906	1	24-51-14 P011-00/280/0000	ALL
TB5154		MS27212-2-3 TS-TRANSFER BUS,P65	284T1168 96906	1	24-25-11 P065-00/ /	ALL
TB5196		MS27212-2-6 TS-P87	284T8703 96906	1	21-45-23 P087-00/ /	278-299

EQUIPMENT LIST

D280T132

Section TB5100

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TB9001	9	CUSTOMER TERMINAL BLOCK	286T0000 CUST	1	25-25-23 E006-02/ /	150, 153-199

EQUIPMENT LIST

D280T132

Section TB9000
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0012		S233T913-1 SNSR-ANGLE OF ATTACK,LEFT	233T9130 04274	1	34-12-11 0192/202/L063	ALL
TS0013		S233T913-1 SNSR-ANGLE OF ATTACK,RIGHT	233T9130 04274	1	34-12-21 0192/202/R063	ALL
TS0014	1	10-61072-3 XDCCR-ELEVATOR CONT FORCE,RIGHT	253T2311 81205	1	31-31-25 0177/198/R032	050-099, 150-199
TS0014	2	10-61072-4 XDCCR-ELEVATOR CONT FORCE,RIGHT	253T2311 81205	1	31-31-25 0177/198/R032	050-099, 150-199
TS0015	1	10-61072-3 XDCCR-ELEVATOR CONT FORCE,LEFT	253T2311 81205	1	31-31-25 0177/198/L032	050-099, 150-199
TS0015	2	10-61072-4 XDCCR-ELEVATOR CONT FORCE,LEFT	253T2311 81205	1	31-31-25 0177/198/L032	050-099, 150-199
TS0016	1	10-61072-3 XDCCR-AILERON CONT FORCE	253T1141 81205	1	31-31-25 0177/198/L032	050-099, 150-199
TS0016	2	10-61072-4 XDCCR-AILERON CONT FORCE	253T1141 81205	1	31-31-25 0177/198/L032	050-099, 150-199
TS0028		S283T011-3 ACCELEROMETER-3 AXIS	284T0193 81205	1	31-31-13 0976/166/0000	ALL
TS0035		S253T404-2 XDCCR 1-LIN VAR DISPL,SPD BK	253T1217 81205	1	27-61-15 P010-00/ /	ALL
TS0036		S253T404-2 XDCCR 2-LIN VAR DISPL,SPD BK	253T1217 81205	1	27-61-14 0171/209/0000	ALL
TS0037		S253T404-2 XDCCR 3-LIN VAR DISPL,SPD BK	253T1217 81205	1	27-61-16 0171/209/0000	ALL
TS0039		MS28034-1 BULB-TEMP,PACK OUTLET,L	213T1001 96906	1	21-52-31 0805/124/L030	ALL
TS0040		MS28034-1 BULB-TEMP,PACK OUTLET,R	213T1001 96906	1	21-52-31 0807/124/R023	ALL
TS0041		625928-2 SNSR-TEMP,PACK COMPRESSOR OUTLET,LEFT	213T1001 81205	1	21-51-12 0879/124/L034	ALL
TS0042		625928-2 SNSR-TEMP,PACK COMPRESSOR OUTLET,RIGHT	213T1001 81205	1	21-51-22 0879/124/R044	ALL
TS0051		S332T301-13 DET-FIRE,APU UPPER	355T5100 81205	1	26-15-11 APU/ /	ALL

EQUIPMENT LIST

D280T132

Section TS0000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0052		S332T301-12 DET-FIRE,APU LOWER	355T5100 81205	1	26-15-11 APU/ /	ALL
TS0082		161T1000-83 XDCR-NO.1 ANTISKID	161T1000 81205	1	32-42-11 WHEEL/01/	ALL
TS0083		161T1000-83 XDCR-NO.2 ANTISKID	161T1000 81205	1	32-42-11 WHEEL/02/	ALL
TS0084		161T1000-83 XDCR-NO.5 ANTISKID	161T1000 81205	1	32-42-11 WHEEL/05/	ALL
TS0085		161T1000-83 XDCR-NO.6 ANTISKID	161T1000 81205	1	32-42-11 WHEEL/06/	ALL
TS0086		161T1000-83 XDCR-NO.3 ANTISKID	161T1000 81205	1	32-42-11 WHEEL/03/	ALL
TS0087		161T1000-83 XDCR-NO.4 ANTISKID	161T1000 81205	1	32-42-11 WHEEL/04/	ALL
TS0088		161T1000-83 XDCR-NO.7 ANTISKID	161T1000 81205	1	32-42-11 WHEEL/07/	ALL
TS0089		161T1000-83 XDCR-NO.8 ANTISKID	161T1000 81205	1	32-42-11 WHEEL/08/	ALL
TS0090		S271T451-1 XDCR-HYDRAULIC BRAKE PRESSURE	274T4640 81205	1	32-41-11 1060/125/R003	ALL
TS0091		S283T002-8 SNSR-NO.1 BRAKE TEMP	284T0262 81205	1	32-46-11 WHEEL/01/L GR	ALL
TS0092		S283T002-8 SNSR-NO.2 BRAKE TEMP	284T0262 81205	1	32-46-11 WHEEL/02/L GR	ALL
TS0093		S283T002-8 SNSR-NO.5 BRAKE TEMP	284T0262 81205	1	32-46-11 WHEEL/05/L GR	ALL
TS0094		S283T002-8 SNSR-NO.6 BRAKE TEMP	284T0262 81205	1	32-46-11 WHEEL/06/L GR	ALL
TS0095		S283T002-8 SNSR-NO.3 BRAKE TEMP	284T0262 81205	1	32-46-11 WHEEL/03/R GR	ALL
TS0096		S283T002-8 SNSR-NO.4 BRAKE TEMP	284T0262 81205	1	32-46-11 WHEEL/04/R GR	ALL
TS0097		S283T002-8 SNSR-NO.7 BRAKE TEMP	284T0262 81205	1	32-46-11 WHEEL/07/R GR	ALL

EQUIPMENT LIST

D280T132

Section TS0000

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0098		S283T002-8 SNSR-NO.8 BRAKE TEMP	284T0262 81205	1	32-46-11 WHEEL/08/R GR	ALL

EQUIPMENT LIST

D280T132

Section TS0000
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0100		S210T120-38 TEMP SNSR-FAN AIR,LEFT	312T3201 81205	1	36-23-11 N 205/149/L004	050-099, 150-156, 162-166, 275-276
TS0100		S210T120-48 TEMP SNSR-FAN AIR,LEFT	312T3201 81205	1	36-23-11 N 205/149/L004	157, 167-199, 277- 299
TS0101		S210T120-38 TEMP SNSR-FAN AIR,RIGHT	312T3201 81205	1	36-23-21 N 205/149/R004	150-156, 162-166, 275-276
TS0101		S210T120-48 TEMP SNSR-FAN AIR,RIGHT	312T3201 81205	1	36-23-21 N 205/149/R004	157, 167-199, 277- 299
TS0102		285T0177-1 SNSR-CURRENT,FORWARD RACK SUPPLY FAN 1	284T0187 81205	1	21-58-14 P036-00/ /	ALL
TS0104		11197-5 DETECTOR-COOLING EFFECT,FORWARD RACK	215T3001 07148	1	21-58-11 0374/170/L083	ALL
TS0120		803127-01 XDCCR-PRESS.,OXY	417T4502 07294	1	35-11-13 0251/170/R060	ALL
TS0161		102LA2AG PROBE-TEMP,TOTAL AIR,LEFT	233T9140 04274	1	34-12-11 0143/228/	ALL
TS0163		11197-5 DETECTOR-COOLING EFFECT,FLIGHT DECK	215T3001 07148	1	21-58-11 0190/178/R041	ALL
TS0164		2156-204A DETECTOR-SMOKE,EQUIPMENT COOLING	218T3001 03972	1	21-58-16 0386/187/R073	ALL
TS0167		60B50402-16 XMTR-WATER QUANTITY	417T2017 81205	1	38-14-11 1570/186/R031	ALL
TS0168		57B50 SNSR-FUEL TANK,LEFT	341T0002 35918	1	28-43-11 WS 335/ /	ALL
TS0170	1	S331T002-10 RESOLVER-THRUST LEVER ANGLE,R ENG	253T7510 81205	1	73-21-13 0144/196/R003	ALL
TS0170	2	S331T002-4 RESOLVER-THRUST LEVER ANGLE,R ENG	253T7510 81205	1	73-21-13 0144/196/R003	ALL
TS0170	3	S331T002-1 RESOLVER-THRUST LEVER ANGLE,R ENG	253T7510 81205	1	73-21-13 0144/196/R003	ALL
TS0171	1	S331T002-10 RESOLVER-THRUST LEVER ANGLE,L ENG	253T7510 81205	1	73-21-13 0144/196/L003	ALL
TS0171	2	S331T002-4 RESOLVER-THRUST LEVER ANGLE,L ENG	253T7510 81205	1	73-21-13 0144/196/L003	ALL

EQUIPMENT LIST

D280T132

Section TS0100

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0171	3	S331T002-1 RESOLVER-THRUST LEVER ANGLE,L ENG	253T7510 81205	1	73-21-13 0144/196/L003	ALL
TS0175		S210T130-19 SNSR-TEMP,DUCT AIR,FLT DECK ZONE	215T1004 81205	1	21-61-11 0253/185/L070	050-099
TS0175		S210T130-19 SNSR-TEMP,DUCT AIR,FLT DECK ZONE	215T1004 81205	1	21-61-11 0268/185/L070	150-156, 162-166, 275-276
TS0175		S210T130-75 SNSR-TEMP,DUCT AIR,FLT DECK ZONE	215T1004 81205	1	21-61-11 0268/185/L070	157, 167-199, 277- 299
TS0176		S210T130-21 SNSR-TEMP,ZONE,FLT DECK	215T1001 81205	1	21-61-11 0195/271/L024	ALL
TS0177		S210T130-19 SNSR-TEMP,DUCT AIR,FWD CABIN ZONE	215T1005 81205	1	21-61-21 0661/303/L013	050-099
TS0177		S210T130-19 SNSR-TEMP,DUCT AIR,FWD CABIN ZONE	215T1005 81205	1	21-61-21 0654+08/303/L013	150-156, 162-166, 275-276
TS0177		S210T130-75 SNSR-TEMP,DUCT AIR,FWD CABIN ZONE	215T1005 81205	1	21-61-21 0654+08/303/L013	157, 167-199, 277- 299
TS0178		S210T130-21 SNSR-TEMP,CABIN ZONE,FWD	215T1002 81205	1	21-61-21 0570-640/283/0000	050-099, 150-199, 280-299
TS0178		S210T130-21 SNSR-TEMP,CABIN ZONE,FWD	215T1002 81205	1	21-61-21 0580-640/283/0000	275-278
TS0179		S210T130-19 SNSR-TEMP,DUCT AIR,AFT CABIN ZONE	215T1005 81205	1	21-61-31 0709/305/L017	050-099, 162-166
TS0179		S210T130-19 SNSR-TEMP,DUCT AIR,AFT CABIN ZONE	215T1005 81205	1	21-61-31 0770/305/R017	150-156, 275-276
TS0179		S210T130-75 SNSR-TEMP,DUCT AIR,AFT CABIN ZONE	215T1005 81205	1	21-61-31 0770/305/R017	157, 277-278
TS0179		S210T130-75 SNSR-TEMP,DUCT AIR,AFT CABIN ZONE	215T1005 81205	1	21-61-31 0709/305/L017	167-199
TS0179		S210T130-75 SNSR-TEMP,DUCT AIR,AFT CABIN ZONE	215T1005 81205	1	21-61-31 0770/305/L017	280-299
TS0180		S210T130-21 SNSR-TEMP,CABIN ZONE,AFT	215T1002 81205	1	21-61-31 1270-335/283/0000	ALL
TS0182		MS28034-1 BULB-TEMP,COMPT,FWD	215T1002 96906	1	21-65-11 0580-640/283/0000	050-099, 150-199

EQUIPMENT LIST

D280T132

Section TS0100

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0182		MS28034-1 BULB-TEMP,COMPT,FWD	215T1002 96906	1	21-65-11 0530-640/283/0000	275-278
TS0182		MS28034-1 BULB-TEMP,COMPT,FWD	215T1002 96906	1	21-65-11 +560-640/283/0000	280-299
TS0183		MS28034-1 BULB-TEMP,COMPT,AFT	215T1002 96906	1	21-65-11 1285-335/283/0000	ALL
TS0184		MS28034-1 BULB-TEMP,DUCT,FLT DECK	215T1004 96906	1	21-65-11 0264/185/L070	ALL
TS0185		MS28034-1 BULB-TEMP,DUCT,FWD	215T1005 96906	1	21-65-11 0661/303/L013	050-099
TS0185		MS28034-1 BULB-TEMP,DUCT,FWD	215T1005 96906	1	21-65-11 0654+08/303/L013	150-199, 275-299
TS0186		MS28034-1 BULB-TEMP,DUCT,AFT	215T1005 96906	1	21-65-11 0709/302/L018	050-099
TS0186		MS28034-1 BULB-TEMP,DUCT,AFT	215T1005 96906	1	21-65-11 0770/305/L018	150-199, 275-299
TS0187		S242T404-701 SNSR-EFIS REMOTE LIGHT,LEFT	233T8101 81205	1	34-22-15 P007-00/ /	ALL
TS0188		S242T404-701 SNSR-EFIS REMOTE LIGHT,RIGHT	233T8101 81205	1	34-22-25 P007-00/ /	ALL
TS0192		285T0177-3 SNSR-CURRENT,RECIRC FAN,LEFT	284T0187 81205	1	21-25-11 P036-00/ /	ALL
TS0193		285T0177-3 SNSR-CURRENT,RECIRC FAN,RIGHT	284T0188 81205	1	21-25-21 P037-00/ /	ALL
TS0194		S251T362-2 XDCR-LIN VAR DISPL,RUDDER RATIO CHANGER	251T3600 81205	1	27-21-12 F 089/ /RS	ALL
TS0195		S344T002-7 SNSR-FUEL LEVEL,LEFT SURGE TANK	344T0002 81205	1	28-21-12 0990/012/L080	ALL
TS0196		S344T002-7 SNSR-FUEL LEVEL,RIGHT SURGE TANK	344T0002 81205	1	28-21-12 R/ /RS	ALL
TS0198		624014-1 SNSR-PACK TEMPERATURE,LEFT	213T1001 81205	1	21-51-12 0859/125/L018	ALL
TS0199		624014-1 SNSR-PACK TEMPERATURE,RIGHT	213T1001 81205	1	21-51-22 0859/125/R059	ALL

EQUIPMENT LIST

D280T132

Section TS0100
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0200		S210T130-19 SNSR-MIX MANIFOLD OUTLET TEMP 1	213T4001 81205	1	21-51-12 0768/126/L015	050-099, 150-156, 162-166, 275-276
TS0200		S210T130-75 SNSR-MIX MANIFOLD OUTLET TEMP 1	213T4001 81205	1	21-51-12 0768/126/L015	157, 167-199, 277- 299
TS0201		S210T130-19 SNSR-MIX MANIFOLD OUTLET TEMP 2	213T4001 81205	1	21-51-22 0768/126/R015	050-099, 150-156, 162-166, 275-276
TS0201		S210T130-75 SENSOR-MIX MANIFOLD OUTLET TEMP 2	213T4001 81205	1	21-51-22 0768/126/R015	157, 167-199, 277- 299
TS0202		S283T004-25 SNSR-DET ELEM,LEFT WHEEL WELL	284T0546 81205	1	26-17-11 //	ALL
TS0203		S283T004-26 SNSR-DET ELEM,LEFT WHEEL WELL	284T0546 81205	1	26-17-11 //	ALL
TS0204		S283T004-25 SNSR-DET ELEM,RIGHT WHEEL WELL	284T0546 81205	1	26-17-11 //	ALL
TS0205		S283T004-26 SNSR-DET ELEM,RIGHT WHEEL WELL	284T0546 81205	1	26-17-11 //	ALL
TS0207		S283T004-24 SNSR-DUCT LEAK DET,LEFT STRUT	310T3100 81205	1	26-18-11 NL283/157/0	ALL
TS0208		S283T004-12 SNSR-DUCT LEAK DET,LEFT WING	218T4001 81205	1	26-18-11 //	ALL
TS0209		S283T004-13 SNSR-DUCT LEAK DET,LEFT WING	218T4001 81205	1	26-18-11 //	ALL
TS0210		S283T004-20 SNSR-DUCT LEAK DET,LEFT WING	218T4001 81205	1	26-18-11 //	ALL
TS0211		S283T004-15 SNSR-DUCT LEAK DET,LEFT BODY	218T4002 81205	1	26-18-11 //	ALL
TS0212		S283T004-16 SNSR-DUCT LEAK DET,LEFT BODY	218T4002 81205	1	26-18-11 //	ALL
TS0214		S283T004-24 SNSR-DUCT LEAK DET,RIGHT STRUT	310T3100 81205	1	26-18-21 NR283/157/0	ALL
TS0215		S283T004-12 SNSR-DUCT LEAK DET,RIGHT WING	218T4001 81205	1	26-18-21 //	ALL
TS0216		S283T004-13 SNSR-DUCT LEAK DET,RIGHT WING	218T4001 81205	1	26-18-21 //	ALL

EQUIPMENT LIST

D280T132

Section TS0200

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0217		S283T004-20 SNSR-DUCT LEAK DET,RIGHT WING	218T4001 81205	1	26-18-21 //	ALL
TS0218		S283T004-15 SNSR-DUCT LEAK DET,RIGHT BODY	218T4002 81205	1	26-18-21 //	ALL
TS0219		S283T004-21 SNSR-DUCT LEAK DET,RIGHT BODY	218T4002 81205	1	26-18-21 //	ALL
TS0220		S283T004-21 SNSR-DUCT LEAK DET,L W/W	218T4003 81205	1	26-18-31 //	ALL
TS0221		S283T004-18 SNSR-DUCT LEAK DET,BODY	218T4004 81205	1	26-18-31 //	ALL
TS0222		S283T004-19 SNSR-DUCT LEAK DET,BODY	218T4004 81205	1	26-18-31 //	ALL
TS0223		S283T004-17 SNSR-DUCT LEAK DET,BODY	218T4004 81205	1	26-18-31 //	ALL
TS0224		S283T004-22 SNSR-DUCT LEAK DET,BODY	218T4004 81205	1	26-18-31 //	ALL
TS0225		S283T004-23 SNSR-DUCT LEAK DET,BODY	218T4005 81205	1	26-18-31 //	ALL
TS0226		S283T004-17 SNSR-DUCT LEAK DET,BODY	218T4005 81205	1	26-18-31 //	ALL
TS0227		S283T004-20 SNSR-DUCT LEAK DET,BODY	218T4004 81205	1	26-18-31 1198/279/L068	050-099
TS0227		S283T004-20 SNSR-DUCT LEAK DET,BODY	218T4004 81205	1	26-18-31 1198/179/L068	150-199, 275-299
TS0228		S283T004-28 SNSR-DUCT LEAK DET,ADP	218T4004 81205	1	26-18-31 //	ALL
TS0229		S283T004-12 SNSR-DUCT LEAK DET,L W/W	218T4003 81205	1	26-18-31 //	ALL
TS0230		285T0177-1 SNSR-CURRENT,FWD RACK EXHAUST FAN	284T0188 81205	1	21-58-15 P037-00/ /	ALL
TS0236		975-0304-003 SW, THERMAL	97896	1	26-18-12 NL201/154/	ALL
TS0237		975-0304-003 SW, THERMAL	97896	1	26-18-12 NR213/154/	ALL

EQUIPMENT LIST

D280T132

Section TS0200

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0238		975-0304-003 SW, THERMAL	97896	1	26-18-22 NL201/154/	ALL
TS0239		975-0304-003 SW, THERMAL	97896	1	26-18-22 NR213/154/	ALL
TS0240		S283T004-18 SNSR-DUCT LEAK DET-BODY	218T4004 81205	1	26-18-31 / /	150-199, 275-299
TS0245		285T0177-1 SNSR-CURRENT,AFT EXHAUST FAN 1	284T0188 81205	1	21-26-11 P037-00/ /	ALL
TS0246		285T0177-1 SNSR-CURRENT,AFT EXHAUST FAN 2	284T0187 81205	1	21-26-11 P036-00/ /	ALL
TS0281	1	285T0112-6 SENSOR-AUTOBRIGHT	233T2222 81205	1	33-16-11 P001-03/ /	ALL
TS0281	2	285T0112-4 SENSOR-AUTOBRIGHT	233T2222 81205	1	33-16-11 P001-03/ /	ALL
TS0285		11198-4 SNSR-PACK FLOW,LEFT	213T2001 07148	1	21-52-41 0845/123/L047	ALL
TS0286		11198-4 SNSR-PACK FLOW,RIGHT	213T2001 07148	1	21-52-41 0889/123/R064	ALL
TS0289		285T0177-3 SNSR-CURRENT,GASPER FAN	284T0187 81205	1	21-24-11 P036-00/ /	050-099, 150-199
TS0290		MS28034-1 BULB-TEMP,COMPRESSOR INLET,L PACK	213T1001 96906	1	21-52-31 0883/119/L039	ALL
TS0291		MS28034-1 BULB-TEMP,COMPRESSOR INLET,R PACK	213T1001 96906	1	21-52-31 0883/119/R038	ALL
TS0292		MS28034-1 BULB-TEMP,COMPRESSOR OUTLET,L PACK	213T1001 96906	1	21-52-31 0882/129/L039	ALL
TS0293		MS28034-1 BULB-TEMP,COMPRESSOR OUTLET,R PACK	213T1001 96906	1	21-52-31 0882/129/R038	ALL
TS0294		MS28034-1 BULB-TEMP,TURBINE INLET,L PACK	213T1001 96906	1	21-52-31 0878/119/L037	ALL
TS0295		MS28034-1 BULB-TEMP,TURBINE INLET,R PACK	213T1001 96906	1	21-52-31 0878/119/R040	ALL
TS0297		MS28034-3 SNSR-TEMPERATURE,BULK CARGO	215T2003 96906	1	21-44-22 1512/170/R067	050-099, 150-199

EQUIPMENT LIST

D280T132

Section TS0200

Page 3 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0300		S345T002-128 UNIT-COMPENSATOR,L MAIN TANK	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0301		S345T002-142 UNIT 14-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0302		S345T002-141 UNIT 13-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0303		S345T002-140 UNIT 12-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0304		S345T002-139 UNIT 11-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0305		S345T002-138 UNIT 10-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0306		S345T002-137 UNIT 9-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0307		S345T002-136 UNIT 8-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0308		S345T002-136 UNIT 7-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0309		S345T002-135 UNIT 6-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0310		S345T002-134 UNIT 5-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0311		S345T002-133 UNIT 4-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0312		S345T002-132 UNIT 3-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0313		S345T002-131 UNIT 2-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0314		S345T002-130 UNIT 1-TANK,L MAIN	345T0002 81205	1	28-41-21 WING/ /L	ALL
TS0316		S345T002-146 UNIT 4-TANK,L AUX	345T0002 81205	1	28-41-23 WING/ /L	ALL
TS0317		S345T002-145 UNIT 3-TANK,L AUX	345T0002 81205	1	28-41-23 WING/ /L	ALL

EQUIPMENT LIST

D280T132

Section TS0300

Page 1

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0318		S345T002-144 UNIT 2-TANK,L AUX	345T0002 81205	1	28-41-23 WING/ /L	ALL
TS0319		S345T002-143 UNIT 1-TANK,L AUX	345T0002 81205	1	28-41-23 WING/ /L	ALL
TS0320		S345T002-130 UNIT 5-TANK,L AUX	345T0002 81205	1	28-41-23 WING/ /L	ALL
TS0328		S345T002-128 UNIT-COMPENSATOR,AUX TANK	345T0002 81205	1	28-41-23 WING/ /R	ALL
TS0329		S345T002-143 UNIT 1-TANK,R AUX	345T0002 81205	1	28-41-23 WING/ /R	ALL
TS0330		S345T002-144 UNIT 2-TANK,R AUX	345T0002 81205	1	28-41-23 WING/ /R	ALL
TS0331		S345T002-145 UNIT 3-TANK,R AUX	345T0002 81205	1	28-41-23 WING/ /R	ALL
TS0332		S345T002-146 UNIT 4-TANK,R AUX	345T0002 81205	1	28-41-23 WING/ /R	ALL
TS0334		S345T002-128 UNIT-COMPENSATOR,R MAIN TANK	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0335		S345T002-130 UNIT 1-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0336		S345T002-131 UNIT 2-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0337		S345T002-132 UNIT 3-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0338		S345T002-133 UNIT 4-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0339		S345T002-134 UNIT 5-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0340		S345T002-135 UNIT 6-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0341		S345T002-136 UNIT 7-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0342		S345T002-136 UNIT 8-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL

EQUIPMENT LIST

D280T132

Section TS0300

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0343		S345T002-137 UNIT 9-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0344		S345T002-138 UNIT 10-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0345		S345T002-139 UNIT 11-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0346		S345T002-140 UNIT 12-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0347		S345T002-141 UNIT 13-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0348		S345T002-142 UNIT 14-TANK,R MAIN	345T0002 81205	1	28-41-22 WING/ /R	ALL
TS0350		1122413 SNSR-TEMPERATURE,LEFT PRECOOLER	312T1201 52778	1	36-22-21 NL215/145/0000	ALL
TS0351		1122413 SNSR-TEMPERATURE,RIGHT PRECOOLER	312T1201 52778	1	36-22-21 NR215/145/0000	ALL
TS0353		253T4015-1 TRANSMITTER ASSY-CONTROL POS,AIDS	253T4008 81205	1	31-31-15 0178/202/L016	ALL
TS0354	9	253T4015-5 XMTR ASSY-CONTROL POS,AIDS (SB 31-0040)	253T4009 81205	1	31-31-15 0213/203/L017	050-099, 150-154, 162-163, 275-276
TS0354		253T4015-5 TRANSMITTER ASSY-CONTROL POS,AIDS	253T4009 81205	1	31-31-15 0213/203/L017	155-157, 164-199, 277-299
TS0355		253T4015-3 TRANSMITTER ASSY-CONTROL POS,AIDS	253T4010 81205	1	31-31-15 0191/192/L028	ALL
TS0356		1332AH1 TRANSDUCER-CABIN PRESSURE	284T0919 04274	1	31-31-15 0324/197/L043	ALL
TS0372		S210T130-19 SNSR-TEMP,DUCT,AIR MID CABIN ZONE	215T1005 81205	1	21-61-41 0770/305/R012	050-099, 150-156, 162-166, 275-276
TS0372		S210T130-75 SNSR-TEMP,DUCT,AIR MID CABIN ZONE	215T1005 81205	1	21-61-41 0770/305/R012	157, 167-199, 277- 299
TS0373		S210T130-21 SNSR-TEMP,CABIN ZONE,MID	215T1002 81205	1	21-61-41 1040-100/283/0000	050-099
TS0373		S210T130-21 SNSR-TEMP,CABIN ZONE,MID	215T1002 81205	1	21-61-41 1030/283/0000	150-157

EQUIPMENT LIST

D280T132

Section TS0300

Page 3

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0373		S210T130-21 SNSR-TEMP,CABIN ZONE,MID	215T1002 81205	1	21-61-41 1030/090/0000	162-199
TS0373		S210T130-21 SNSR-TEMP,CABIN ZONE,MID	215T1002 81205	1	21-61-41 1030-090/283/0000	275-299
TS0375		MS28034-1 BULB-TEMP,COMPT,MID	215T1002 96906	1	21-65-11 1030-090/293/0000	050-099
TS0375		MS28034-1 BULB-TEMP,COMPT,MID	215T1002 96906	1	21-65-11 1030/283/0000	150-157
TS0375		MS28034-1 BULB-TEMP,COMPT,MID	215T1002 96906	1	21-65-11 1030/090/0000	162-199
TS0375		MS28034-1 BULB-TEMP,COMPT,MID	215T1002 96906	1	21-65-11 1030-090/283/0000	275-299
TS0376		MS28034-1 BULB-TEMP,DUCT,MID	215T1005 96906	1	21-65-11 0709/302/R012	050-099
TS0376		MS28034-1 BULB-TEMP,DUCT,MID	215T1005 96906	1	21-65-11 0770/305/R012	150-199, 275-299

EQUIPMENT LIST

D280T132

Section TS0300

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0430		MS28034-1 BULB-TEMP,SECONDARY HEAT EXCHANGER OUT,R	213T1001 96906	1	21-52-31 0882/119/R030	ALL
TS0431		MS28034-1 BULB-TEMP,SECONDARY HEAT EXCHANGER OUT,L	213T1001 96906	1	21-52-31 0882/119/L047	ALL
TS0432		MS28034-1 BULB-TEMP,PACK INLET AIR,R	213T2001 96906	1	21-52-31 0870/130/R055	ALL
TS0433		MS28034-1 BULB-TEMP,PACK INLET AIR,L	213T2001 96906	1	21-52-31 0871/124/L056	ALL
TS0451		S271T451-1 XDCR-BRAKE PRESSURE,MAIN,R	272T0194 27113	1	31-31-22 1043/183/R077	ALL
TS0452		S271T451-1 XDCR-BRAKE PRESSURE,MAIN,L	272T0194 27113	1	31-31-22 1041/188/L084	ALL
TS0468		S210T130-19 SNSR-AUX FWD CABIN ZONE DUCT AIR TEMP	00000000 81205	1	21-61-61 0568/304/L010	050-099, 150-156, 162-166, 275-276
TS0468		S210T130-75 SNSR-AUX FWD CABIN ZONE DUCT AIR TEMP	00000000 81205	1	21-61-61 0568/304/L010	157, 167-199, 277- 299
TS0469		S210T130-21 SNSR-AUX FWD CABIN ZONE TEMP	00000000 81205	1	21-61-61 0350-390/283/0000	050-099, 150-199
TS0469		S210T130-21 SNSR-AUX FWD CABIN ZONE TEMP	00000000 81205	1	21-61-61 0400-460/283/0000	275-299
TS0470		S210T130-21 SNSR-AUX MID CABIN ZONE TEMP	00000000 81205	1	21-61-71 0850-890/305/0000	050-099
TS0470		S210T130-21 SNSR-AUX MID CABIN ZONE TEMP	00000000 81205	1	21-61-71 0790-850/283/0000	150-157, 275-276
TS0470		S210T130-21 SNSR-AUX MID CABIN ZONE TEMP	00000000 81205	1	21-61-71 0790-850/305/0000	162-199
TS0470		S210T130-21 SNSR-AUX MID CABIN ZONE TEMP	00000000 81205	1	21-61-71 0700-890/283/0000	277-299
TS0471		MS28034-1 SNSR-AUX FWD DUCT TEMP BULB	215T1005 81205	1	21-65-11 0568/304/L010	ALL
TS0472		MS28034-1 SNSR-AUX MID DUCT TEMP BULB	215T1005 81205	1	21-65-11 0770/307/L003	050-099, 150-155, 162-165, 275-276
TS0472		MS28034-1 SNSR-AUX MID DUCT TEMP BULB	215T1005 81205	1	21-65-11 0767/301/L003	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section TS0400

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0473		S271T451-1 XDCR-BRAKE PRESSURE,ALTERNATE,R	272T0141 27113	1	31-31-22 1037/188/R084	ALL
TS0474		S271T451-1 XDCR-BRAKE PRESSURE,ALTERNATE,L	272T0141 27113	1	31-31-22 1027/188/L084	ALL
TS0476		S210T130-19 SNSR-AUX MID CABIN ZONE DUCT AIR TEMP	00000000 81205	1	21-61-71 0770/307/L003	050-099, 150-155, 162-165, 275-276
TS0476		S210T130-19 SNSR-AUX MID CABIN ZONE DUCT AIR TEMP	00000000 81205	1	21-61-71 0767/300/L003	156, 166, 280-299
TS0476		S210T130-75 SNSR-AUX MID CABIN ZONE DUCT AIR TEMP	00000000 81205	1	21-61-71 0767/300/L003	157, 167-199, 277- 278
TS0493		285T0177-1 SNSR-CURRENT,FWD CARGO VENT FAN	284T0188 81205	1	21-26-31 P037-00/ /	ALL
TS0494		285T0177-1 SNSR-CURRENT,CGO GND EXH FAN	284T0188 81205	1	21-26-31 P037-00/ /	ALL
TS0495		S210T130-19 SNSR-TEMP,DUCT AIR,FWD CARGO	00000000 81205	1	21-61-81 0722/156/L073	050-099, 150-156, 162-166, 275-276
TS0495		S210T130-75 SNSR-TEMP,DUCT AIR,FWD CARGO	00000000 81205	1	21-61-81 0722/156/L073	157, 167-199, 277- 299
TS0496		S210T130-21 SNSR-TEMP,ZONE,FWD CARGO	00000000 81205	1	21-61-81 0620/175/L070	ALL
TS0497		MS28034-3 SNSR-TEMP,FWD CARGO	215T2003 96906	1	21-43-12 0620/175/L070	ALL

EQUIPMENT LIST

D280T132

Section TS0400

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0505	9	S283U006-7 SENSOR-TIRE PRESSURE 1 (SB 32-0085)	165T0100 81205	1	32-45-01 WHEEL-/ /01-	275-276
TS0505		S283U006-7 SENSOR-TIRE PRESSURE 1	165T0100 81205	1	32-45-01 WHEEL-/ /01-	050-099, 155-199, 277-299
TS0506	9	S283U006-7 SENSOR-TIRE PRESSURE 2 (SB 32-0085)	165T0100 81205	1	32-45-01 WHEEL-/ /02-	275-276
TS0506		S283U006-7 SENSOR-TIRE PRESSURE 2	165T0100 81205	1	32-45-01 WHEEL-/ /02-	050-099, 155-199, 277-299
TS0507	9	S283U006-7 SENSOR-TIRE PRESSURE 3 (SB 32-0085)	165T0100 81205	1	32-45-01 WHEEL-/ /03-	275-276
TS0507		S283U006-7 SENSOR-TIRE PRESSURE 3	165T0100 81205	1	32-45-01 WHEEL-/ /03-	050-099, 155-199, 277-299
TS0508	9	S283U006-7 SENSOR-TIRE PRESSURE 4 (SB 32-0085)	165T0100 81205	1	32-45-01 WHEEL-/ /04-	275-276
TS0508		S283U006-7 SENSOR-TIRE PRESSURE 4	165T0100 81205	1	32-45-01 WHEEL-/ /04-	050-099, 155-199, 277-299
TS0509	9	S283U006-7 SENSOR-TIRE PRESSURE 5 (SB 32-0085)	165T0100 81205	1	32-45-01 WHEEL-/ /05-	275-276
TS0509		S283U006-7 SENSOR-TIRE PRESSURE 5	165T0100 81205	1	32-45-01 WHEEL-/ /05-	050-099, 155-199, 277-299
TS0510	9	S283U006-7 SENSOR-TIRE PRESSURE 6 (SB 32-0085)	165T0100 81205	1	32-45-01 WHEEL-/ /06-	275-276
TS0510		S283U006-7 SENSOR-TIRE PRESSURE 6	165T0100 81205	1	32-45-01 WHEEL-/ /06-	050-099, 155-199, 277-299
TS0511	9	S283U006-7 SENSOR-TIRE PRESSURE 7 (SB 32-0085)	165T0100 81205	1	32-45-01 WHEEL-/ /07-	275-276
TS0511		S283U006-7 SENSOR-TIRE PRESSURE 7	165T0100 81205	1	32-45-01 WHEEL-/ /07-	050-099, 155-199, 277-299
TS0512	9	S283U006-7 SENSOR-TIRE PRESSURE 8 (SB 32-0085)	165T0100 81205	1	32-45-01 WHEEL-/ /08-	275-276
TS0512		S283U006-7 SENSOR-TIRE PRESSURE 8	165T0100 81205	1	32-45-01 WHEEL-/ /08-	050-099, 155-199, 277-299
TS0513	9	S283T024-3 SENSOR-TIRE PRESSURE 9 (SB 32-0085)	166T0100 81205	1	32-45-01 LNOSE-/ /09-	275-276

EQUIPMENT LIST

D280T132

Section TS0500

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0513		S283T024-3 SENSOR-TIRE PRESSURE 9	166T0100 81205	1	32-45-01 LNOSE- / /09-	050-099, 155-199, 277-299
TS0514	9	S283T024-3 SENSOR-TIRE PRESSURE 10 (SB 32-0085)	166T0100 81205	1	32-45-01 RNOSE- / /10-	275-276
TS0514		S283T024-3 SENSOR-TIRE PRESSURE 10	166T0100 81205	1	32-45-01 RNOSE- / /10-	050-099, 155-199, 277-299
TS0515		S210T130-21 TEMP SENSOR-FLT DK CREW REST	215T4001 81205	1	21-66-11 0279/279/L012	050-099, 162-199
TS0516		10-60498-3 DUCT SENSOR-FLT DK CREW REST	214T2058 81205	1	21-66-11 0384/299/L012	050-099, 162-199
TS0517	9	10-60498-3 DUCT SENSOR-AFT LH CABIN CREW REST	214T0006 81205	1	21-66-31 1438/293/L026	150, 152-157
TS0517		10-60498-3 DUCT SENSOR-AFT LH CABIN CREW REST	214T0006 81205	1	21-66-31 1438/293/L026	050-099, 162-199
TS0518	9	S210T130-21 TEMP SENSOR-AFT LH CABIN CREW REST	214T0006 81205	1	21-66-31 1419/267/L063	150, 152-157
TS0518		S210T130-21 TEMP SENSOR-AFT LH CABIN CREW REST	214T0006 81205	1	21-66-31 1419/267/L063	050-099, 162-199
TS0519	9	10-60498-3 DUCT SENSOR-AFT RH CABIN CREW REST	214T0006 81205	1	21-66-41 1438/293/R038	150, 152-157
TS0519		10-60498-3 DUCT SENSOR-AFT RH CABIN CREW REST	214T0006 81205	1	21-66-41 1438/293/R038	050-099, 162-199
TS0520	9	S210T130-21 TEMP SENSOR-AFT RH CABIN CREW REST	214T0006 81205	1	21-66-41 1419/267/R063	150, 152-157
TS0520		S210T130-21 TEMP SENSOR-AFT RH CABIN CREW REST	214T0006 81205	1	21-66-41 1419/267/R063	050-099, 162-199
TS0521		10-60498-3 DUCT SENSOR-CABIN CREW REST	214T0001 81205	1	21-66-21 0444/291/R032	050-099, 162-199
TS0522		S210T130-21 TEMP SENSOR-FWD CABIN CREW REST	214T0001 81205	1	21-66-21 0441/267/R063	050-099, 162-199
TS0523		625704-2 TEMP SENSOR-SKIN TEMP	214T2059 81205	1	21-66-11 0547/150/L080	050-099, 162-199
TS0524		285T0177-3 CURRENT SENSOR-FLT DK CREW REST FAN	284T0187 81205	1	21-66-11 P036-00/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section TS0500

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0525		285T0177-3 CURRENT SENSOR-FWD CABIN CREW REST FAN	284T0188 81205	1	21-66-21 P037-00/ /	050-099, 162-199
TS0526	9	285T0177-3 CURRENT SENOR-AFT LH CABIN CREW REST	81205	1	21-66-31 P036-00/ /	150, 152-157
TS0526		285T0177-3 CURRENT SENSOR-AFT LH CABIN CREW REST	284T0187 81205	1	21-66-31 P036-00/ /	050-099, 162-199
TS0527	9	285T0177-3 CURRENT SENSOR-AFT RH CBN CREW REST FAN	81205	1	21-66-41 P037-00/ /	150, 152-157
TS0527	9	285T0177-3 CURRENT SENSOR-AFT RH CBN CREW REST FAN	284T3601 81205	1	21-66-41 P037-00/ /	152-157
TS0527		285T0177-3 CURRENT SENSOR-AFT RH CBN CREW REST FAN	284T0187 81205	1	21-66-41 P037-00/ /	050-099, 162-199

EQUIPMENT LIST

D280T132

Section TS0500
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS0681		S332T101-22 ENG UPR AFT FIRE DET	332T3224 81205	2	26-11-11 ENG/ /	ALL
TS0682		S332T101-21 DET-FIRE,ENG LWR AFT	332T3224 81205	2	26-11-11 ENG/ /	ALL
TS0683		S332T101-38 DET-FIRE,ENG LWR FWD	332T3224 81205	2	26-11-11 ENG/ /	050-099, 162-199, 277-299
TS0684		S332T101-20 DET-OVHT,ENG,UPPER FWD	332T3224 81205	2	26-11-12 ENG/ /	ALL

EQUIPMENT LIST

D280T132

Section TS0600

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5072		S231N210-12 SNSR-DIFFERENTIAL PRESSURE	233T9110 81205	1	21-33-21 0212/195/R080	ALL
TS5081		S251N119-31 XDCR UNIT-CAPT WHL CMD	253T1100 81205	1	27-61-14 0219/202/L021	ALL
TS5082		S251N119-3 XDCR UNIT-F/O WHL CMD	253T1100 81205	1	27-61-13 0219/202/R021	ALL

EQUIPMENT LIST

D280T132

Section TS5000
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
TS5132		624014-1 SNSR-LEFT PACK TEMP 2	213T1001 81205	1	21-51-13 0859/125/L018	ALL
TS5133		625928-2 SNSR-LEFT PACK COMPRESSOR OUTLET TEMP 2	213T1001 81205	1	21-51-13 0879/124/L034	ALL
TS5134		624014-1 SNSR-RIGHT PACK TEMP 2	213T1001 81205	1	21-51-23 0879/125/R059	ALL
TS5135		625928-2 SNSR-RIGHT PACK COMPRESSOR OUTLET TEMP 2	213T1001 81205	1	21-51-23 0879/124/R044	ALL

EQUIPMENT LIST

D280T132

Section TS5100
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00001		S210T130-74 VALVE-TRIM AIR MODULATING,FLT DECK ZONE	213T2001 81205	1	21-61-11 0823/113/L015	156-157, 166-199, 277-299
V00001	1	S210T130-70 VALVE-TRIM AIR MODULATING,FLT DECK ZONE	213T2001 81205	1	21-61-11 0823/113/L015	050-099, 150-155, 162-165, 275-276
V00001	2	S210T130-61 VALVE-TRIM AIR MODULATING,FLT DECK ZONE	213T2001 81205	1	21-61-11 0823/113/L015	050-099, 150-155, 162-165, 275-276
V00001	3	S210T130-34 VALVE-TRIM AIR MODULATING,FLT DECK ZONE	213T2001 81205	1	21-61-11 0823/113/L015	050-099, 150-155, 162-165, 275-276
V00002		S210T130-74 VALVE-TRIM AIR MODULATING,FWD CABIN ZONE	213T2001 81205	1	21-61-21 0827/129/L015	156-157, 166-199, 277-299
V00002	1	S210T130-70 VALVE-TRIM AIR MODULATING,FWD CABIN ZONE	213T2001 81205	1	21-61-21 0827/129/L015	050-099, 150-155, 162-165, 275-276
V00002	2	S210T130-61 VALVE-TRIM AIR MODULATING,FWD CABIN ZONE	213T2001 81205	1	21-61-21 0827/129/L015	050-099, 150-155, 162-165, 275-276
V00002	3	S210T130-34 VALVE-TRIM AIR MODULATING,FWD CABIN ZONE	213T2001 81205	1	21-61-21 0827/129/L015	050-099, 150-155, 162-165, 275-276
V00003		S210T130-74 VALVE-TRIM AIR MODULATING,AFT CABIN ZONE	213T2001 81205	1	21-61-31 0827/118/L015	156-157, 166-199, 277-278
V00003		S210T130-74 VALVE-TRIM AIR MODULATING,AFT CABIN ZONE	213T2001 81205	1	21-61-31 0829/120/L015	280-299
V00003	1	S210T130-70 VALVE-TRIM AIR MODULATING,AFT CABIN ZONE	213T2001 81205	1	21-61-31 0827/118/L015	050-099, 150-155, 162-165, 275-276
V00003	2	S210T130-61 VALVE-TRIM AIR MODULATING,AFT CABIN ZONE	213T2001 81205	1	21-61-31 0827/118/L015	050-099, 150-155, 162-165, 275-276
V00003	3	S210T130-34 VALVE-TRIM AIR MODULATING,AFT CABIN ZONE	213T2001 81205	1	21-61-31 0827/118/L015	050-099, 150-155, 162-165, 275-276
V00004		S210T130-62 VALVE-TRIM AIR PRESSURE REGULATING	213T2001 81205	1	21-61-51 0869/120/L013	ALL
V00006	1	S270T010-15 VALVE-ENG HYD PUMP L SUPPLY SHUTOFF	271T5260 81205	1	29-11-11 NL243/142/	ALL
V00006	2	S270T010-12 VALVE-ENG HYD PUMP L SUPPLY SHUTOFF	271T5260 81205	1	29-11-11 NL243/142/	ALL
V00006	3	S270T010-9 VALVE-ENG HYD PUMP L SUPPLY SHUTOFF	271T5260 81205	1	29-11-11 NL243/142/	ALL

EQUIPMENT LIST

D280T132

Section V00000

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00007	1	S270T010-15 VALVE-ENG HYD PUMP R SUPPLY SHUTOFF	271T5260 81205	1	29-11-21 NR243/142/	ALL
V00007	2	S270T010-12 VALVE-ENG HYD PUMP R SUPPLY SHUTOFF	271T5260 81205	1	29-11-21 NR243/142/	ALL
V00007	3	S270T010-9 VALVE-ENG HYD PUMP R SUPPLY SHUTOFF	271T5260 81205	1	29-11-21 NR243/142/	ALL
V00010		S210T170-44 VALVE-HEAT EXCHANGER SHUTOFF	217T1030 81205	1	21-58-12 0428/117/L013	150-155, 162-165, 275-276
V00010		S210T170-64 VALVE-HEAT EXCHANGER SHUTOFF	217T1030 81205	1	21-58-12 0428/117/L013	156-157, 166-199, 277-299
V00011		S210T170-64 VALVE-HEAT EXCHANGER BYPASS	217T1030 81205	1	21-58-12 0423/177/L075	156-157, 166-199
V00012		S210T170-43 VALVE-OVERBOARD EXHAUST	217T1030 81205	1	21-58-13 0473/116/L004	050-099
V00012		S210T170-43 VALVE-OVERBOARD EXHAUST	217T1030 81205	1	21-58-13 0473/116/R004	150-199, 275-299
V00013		2780536-101 VALVE-CARGO HT FLOW CONT,AFT	214T6003 92003	1	21-44-11 1364/172/L075	050-099, 150-157, 275-299
V00014		2780536-101 VALVE-CARGO HT SHUTOFF,AFT	214T6003 92003	1	21-44-11 1364/180/L075	050-099, 150-157, 275-299
V00015		S210T160-94 VALVE-OUTFLOW,CABIN PRESS. (SEE YBW)	216T1003 81205	1	21-31-11 1550/148/L049	ALL
V00016		S210T130-46 VALVE-FLOW CONTROL AND SHUTOFF,LEFT	213T2001 81205	1	21-51-11 0852/123/L047	050-099
V00016		S210T130-51 VALVE-FLOW CONTROL AND SHUTOFF,LEFT	213T2001 81205	1	21-51-11 0852/123/L047	150-199, 275-278
V00016		S210T130-51 VALVE-FLOW CONTROL AND SHUTOFF,LEFT	213T2001 81205	1	21-51-11 0896/123/L064	280-299
V00017		S210T130-46 VALVE-FLOW CONTROL AND SHUTOFF,RIGHT	213T2001 81205	1	21-51-21 0896/123/R064	050-099
V00017		S210T130-51 VALVE-FLOW CONTROL AND SHUTOFF,RIGHT	213T2001 81205	1	21-51-21 0896/123/R064	150-199, 275-278
V00017		S210T130-51 VALVE-FLOW CONTROL AND SHUTOFF,RIGHT	213T2001 81205	1	21-51-21 0896/183/R064	280-299

EQUIPMENT LIST

D280T132

Section V00000

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00018		S210T130-60 VALVE-TEMPERATURE CONTROL,LEFT	213T1001 81205	1	21-51-12 0875/118/L045	050-099, 150-199, 275-278
V00018		398750-5 VALVE-TEMPERATURE CONTROL,LEFT	213T1001 81205	1	21-51-12 0875/118/L045	280-299
V00019		AR398750-3 VALVE-TEMPERATURE CONTROL,RIGHT	213T1001 81205	1	21-51-22 0875/118/R032	050-099, 150-199, 275-278
V00019		AR398750-5 VALVE-TEMPERATURE CONTROL,RIGHT	213T1001 81205	1	21-51-22 0875/118/R043	280-299
V00020		60B92602-11 VALVE-FUELING SHUTOFF,L TANK OUTBD	344T0002 81205	1	28-21-13 L/ /RS	ALL
V00021		60B92602-11 VALVE-FUELING SHUTOFF,L TANK INBD	344T0002 81205	1	28-21-13 L/ /RS	ALL
V00022		60B92602-11 VALVE-FUELING SHUTOFF,R TANK INBD	344T0002 81205	1	28-21-13 R/ /RS	ALL
V00023		60B92602-11 VALVE-FUELING SHUTOFF,R TANK OUTBD	344T0002 81205	1	28-21-13 R/ /RS	ALL
V00024	1	S343T003-14 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L029/14/RS	050-099, 155-156, 162-164
V00024	1	S343T003-14 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L0246/14/RS	150-154, 275-276
V00024	1	S343T003-39 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L029/14/RS	157, 167-199, 277- 299
V00024	2	S343T003-111 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L029/14/RS	050-099, 155-156, 162-164
V00024	2	S343T003-111 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L0246/14/RS	150-154, 275-276
V00024	2	S343T003-14 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L029/14/RS	157, 167-199, 277- 299
V00024	3	S343T003-1 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L029/14/RS	050-099, 155-156, 162-164
V00024	3	S343T003-1 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L0246/14/RS	150-154, 275-276
V00024	3	S343T003-111 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L029/14/RS	157, 167-199, 277- 299

EQUIPMENT LIST

D280T132

Section V00000

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00024	4	S343T003-1 VALVE ACTUATOR-FUEL CROSSFEED	343T0002 81205	1	28-22-31 L029/14/RS	157, 167-199, 277-299
V00025	1	S343T003-14 VALVE ACTUATOR-FUEL SHUTOFF, L SPAR	343T0002 81205	1	28-22-21 L / RS	050-099, 150-156, 162-164, 275-276
V00025	1	S343T003-39 VALVE ACTUATOR-FUEL SHUTOFF, L SPAR	343T0002 81205	1	28-22-21 L / RS	157, 165-199, 277-299
V00025	2	S343T003-111 VALVE ACTUATOR-FUEL SHUTOFF, L SPAR	343T0002 81205	1	28-22-21 L / RS	050-099, 150-156, 162-164, 275-276
V00025	2	S343T003-14 VALVE ACTUATOR-FUEL SHUTOFF, L SPAR	343T0002 81205	1	28-22-21 L / RS	157, 165-199, 277-299
V00025	3	S343T003-1 VALVE ACTUATOR-FUEL SHUTOFF, L SPAR	343T0002 81205	1	28-22-21 L / RS	050-099, 150-156, 162-164, 275-276
V00025	3	S343T003-111 VALVE ACTUATOR-FUEL SHUTOFF, L SPAR	343T0002 81205	1	28-22-21 L / RS	157, 165-199, 277-299
V00025	4	S343T003-1 VALVE ACTUATOR-FUEL SHUTOFF, L SPAR	343T0002 81205	1	28-22-21 L / RS	157, 165-199, 277-299
V00026	1	S343T003-14 VALVE ACTUATOR-FUEL SHUTOFF, R SPAR	343T0002 81205	1	28-22-21 R / RS	050-099, 150-156, 162-164, 275-276
V00026	1	S343T003-39 VALVE ACTUATOR-FUEL SHUTOFF, R SPAR	343T0002 81205	1	28-22-21 R / RS	157, 165-199, 277-299
V00026	2	S343T003-111 VALVE ACTUATOR-FUEL SHUTOFF, R SPAR	343T0002 81205	1	28-22-21 R / RS	050-099, 150-156, 162-164, 275-276
V00026	2	S343T003-14 VALVE ACTUATOR-FUEL SHUTOFF, R SPAR	343T0002 81205	1	28-22-21 R / RS	157, 165-199, 277-299
V00026	3	S343T003-1 VALVE ACTUATOR-FUEL SHUTOFF, R SPAR	343T0002 81205	1	28-22-21 R / RS	050-099, 150-156, 162-164, 275-276
V00026	3	S343T003-111 VALVE ACTUATOR-FUEL SHUTOFF, R SPAR	343T0002 81205	1	28-22-21 R / RS	157, 165-199, 277-299
V00026	4	S343T003-1 VALVE ACTUATOR-FUEL SHUTOFF, R SPAR	343T0002 81205	1	28-22-21 R / RS	157, 165-199, 277-299
V00027		60B40038-2 VALVE-WSHLD RAIN REPELLENT,LEFT	232T6003 81205	1	30-43-11 / /	ALL
V00028		60B40038-2 VALVE-WSHLD RAIN REPELLENT,RIGHT	232T6003 81205	1	30-43-11 / /	ALL

EQUIPMENT LIST

D280T132

Section V00000

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00029		S283T001-2 VALVE-NO.1 ANTISKID	274T1102 81205	1	32-42-11 L0345/159/MS	ALL
V00030		S283T001-2 VALVE-NO.2 ANTISKID	274T1102 81205	1	32-42-11 L0345/159/MS	ALL
V00031		S283T001-2 VALVE-NO.5 ANTISKID	274T1102 81205	1	32-42-11 L0345/159/MS	ALL
V00032		S283T001-2 VALVE-NO.6 ANTISKID	274T1102 81205	1	32-42-11 L0345/159/MS	ALL
V00033		S283T001-2 VALVE-NO.3 ANTISKID	274T1102 81205	1	32-42-11 R0345/159/MS	ALL
V00034		S283T001-2 VALVE-NO.4 ANTISKID	274T1102 81205	1	32-42-11 R0345/159/MS	ALL
V00035		S283T001-2 VALVE-NO.7 ANTISKID	274T1102 81205	1	32-42-11 R0345/159/MS	ALL
V00036		S283T001-2 VALVE-NO.8 ANTISKID	274T1102 81205	1	32-42-11 R0345/159/MS	ALL
V00037		S283T001-2 VALVE-NO.(1+2) ANTISKID ALTERNATE	274T1100 81205	1	32-42-11 L0345/159/RS	ALL
V00038		S283T001-2 VALVE-NO.(5+6) ANTISKID ALTERNATE	274T1100 81205	1	32-42-11 L0345/159/RS	ALL
V00039		S283T001-2 VALVE-NO.(3+4) ANTISKID ALTERNATE	274T1100 81205	1	32-42-11 R0345/159/RS	ALL
V00040		S283T001-2 VALVE-NO.(7+8) ANTISKID ALTERNATE	274T1100 81205	1	32-42-11 R0345/159/RS	ALL
V00041	1	S270T010-2 VALVE-PARKING BRAKE	274T4630 81205	1	32-44-11 1028/182/R092	ALL
V00041	2	S271N501-3 VALVE-PARKING BRAKE	274T4630 81205	1	32-44-11 1028/182/R092	ALL
V00041	3	S271N501-2 VALVE-PARKING BRAKE	274T4630 81205	1	32-44-11 1028/182/R092	ALL
V00041	4	S271N501-1 VALVE-PARKING BRAKE	274T4630 81205	1	32-44-11 1028/182/R092	ALL
V00042		S210T120-63 VALVE-PRESS.REG AND SHUTOFF,AIR SUPPLY,L	312T3201 81205	1	36-11-51 0210/151/L010	ALL

EQUIPMENT LIST

D280T132

Section V00000

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00043		S210T120-63 VALVE-PRESS.REG AND SHUTOFF,AIR SUPPLY,R	312T3201 81205	1	36-11-52 N 210/151/R010	ALL
V00044		2780539-101 VALVE-AIR SUPPLY ISOLATION,LEFT	212T3002 92003	1	36-11-11 0946/127/L048	ALL
V00045		2780539-101 VALVE-AIR SUPPLY ISOLATION,RIGHT	212T3002 92003	1	36-11-21 0946/127/R048	ALL
V00046		2780539-101 VALVE-AIR SUPPLY ISOLATION,CENTER	212T3003 92003	1	36-11-31 0966/152/L026	ALL
V00047		2780540-102 VALVE-APU AIR SUPPLY SHUTOFF	212T3005 92003	1	36-11-41 1820/220/L024	ALL
V00051		SEEBYV051 VALVE-BYPASS,OUTBD SLAT	00000000 81205	1	27-81-21 / /	ALL
V00052		2780537-104 VALVE-TAI,L WING	218T1001 92003	1	30-11-11 L0377/14/LE	ALL
V00056		SEEBYBV056 VALVE-BYPASS,INBD SLAT	00000000 81205	1	27-81-11 / /	ALL
V00057		2780537-104 VALVE-TAI,R WING	218T1001 92003	1	30-11-11 R0377/14/LE	ALL
V00083		S210T120-41 VALVE-SHUTOFF,HIGH PRESS.	332T3215 81205	2	36-11-61 NL188/116/	150-157, 275-299
V00088		2780536-101 VALVE-CARGO HEAT FLOW CONTROL,FWD	214T6001 92003	1	21-43-11 0771/120/R015	050-099, 162-199
V00088		2780536-101 VALVE-CARGO HEAT FLOW CONTROL,FWD	214T6001 92003	1	21-43-11 0940/128/R014	150-157, 275-299
V00089		2780536-101 VALVE-CARGO HEAT SHUTOFF,FWD	214T6001 92003	1	21-43-11 0935/128/R014	ALL
V00090		S210T170-30 VALVE-MANIFOLD INTERCONNECT	217T2011 81205	1	21-58-16 0195/170/R033	ALL
V00091		S210T170-44 VALVE-INBOARD SUPPLY	217T1030 81205	1	21-58-12 0567/187/L075	150-155, 275-276
V00091		S210T170-64 VALVE-INBOARD SUPPLY	217T1030 81205	1	21-58-12 0567/187/L075	156-157, 166-199, 277-299
V00092		S210T170-64 VALVE-INBOARD EXHAUST	217T1030 81205	1	21-58-12 0472/175/L090	156-157, 166-199

EQUIPMENT LIST

D280T132

Section V00000

Page 6

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00093		S210T170-64 VALVE-ACRU ISOLATION	217T1013 81205	1	21-58-13 0412/130/L000	156-157, 166-199
V00096	1	S343T003-14 VALVE ACTUATOR-APU FUEL SHUTOFF	346T0004 81205	1	28-25-21 L / RS	050-099, 150-156, 162-164, 275-276
V00096	1	S343T003-39 VALVE ACTUATOR-APU FUEL SHUTOFF	346T0004 81205	1	28-25-21 L / RS	157, 165-199, 277- 299
V00096	2	S343T003-111 VALVE ACTUATOR-APU FUEL SHUTOFF	346T0004 81205	1	28-25-21 L / RS	050-099, 150-156, 162-164, 275-276
V00096	2	S343T003-14 VALVE ACTUATOR-APU FUEL SHUTOFF	346T0004 81205	1	28-25-21 L / RS	157, 165-199, 277- 299
V00096	3	S343T003-1 VALVE ACTUATOR-APU FUEL SHUTOFF	346T0004 81205	1	28-25-21 L / RS	050-099, 150-156, 162-164, 275-276
V00096	3	S343T003-111 VALVE ACTUATOR-APU FUEL SHUTOFF	346T0004 81205	1	28-25-21 L / RS	157, 165-199, 277- 299
V00096	4	S343T003-1 VALVE ACTUATOR-APU FUEL SHUTOFF	346T0004 81205	1	28-25-21 L / RS	157, 165-199, 277- 299
V00097	1	S343T003-14 VALVE ACTUATOR-APU FUEL ISOLATION	346T0004 81205	1	28-25-31 L / RS	050-099, 150-156, 162-164, 275-276
V00097	1	S343T003-39 VALVE ACTUATOR-APU FUEL ISOLATION	346T0004 81205	1	28-25-31 L / RS	157, 167-199, 277- 299
V00097	2	S343T003-111 VALVE ACTUATOR-APU FUEL ISOLATION	346T0004 81205	1	28-25-31 L / RS	050-099, 150-156, 162-164, 275-276
V00097	2	S343T003-14 VALVE ACTUATOR-APU FUEL ISOLATION	346T0004 81205	1	28-25-31 L / RS	157, 167-199, 277- 299
V00097	3	S343T003-1 VALVE ACTUATOR-APU FUEL ISOLATION	346T0004 81205	1	28-25-31 L / RS	050-099, 150-156, 162-164, 275-276
V00097	3	S343T003-111 VALVE ACTUATOR-APU FUEL ISOLATION	346T0004 81205	1	28-25-31 L / RS	157, 167-199, 277- 299
V00097	4	S343T003-1 VALVE ACTUATOR-APU FUEL ISOLATION	346T0004 81205	1	28-25-31 L / RS	157, 167-199, 277- 299
V00098		S270T002-3 VALVE-WING SHUTOFF-R	271T1310 81205	1	27-13-11 R0435/146/RS	ALL
V00099		S270T002-3 VALVE-WING SHUTOFF-C	271T1310 81205	1	27-13-11 1065/162/L010	ALL

EQUIPMENT LIST

D280T132

Section V00000
Page 7 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00100		S270T002-3 VALVE-WING SHUTOFF-L	271T1310 81205	1	27-13-11 L0435/146/RS	ALL
V00101		S270T002-3 VALVE-TAIL SHUTOFF-L	271T4810 81205	1	27-23-11 1696/247/L055	ALL
V00102		S270T002-3 VALVE-TAIL SHUTOFF-R	271T4810 81205	1	27-23-11 1657/234/R068	ALL
V00103		S270T002-3 VALVE-TAIL SHUTOFF-C	271T4810 81205	1	27-23-11 1657/234/L068	ALL
V00104		S256T006-10 VALVE-FLAPS & SLATS SHUTOFF (SEE YB6)	256T1400 81205	1	27-51-31 1067/170/R035	ALL
V00105		SEEBZV105 VALVE-BYPASS,TE FLAP	00000000 81205	1	27-51-11 / /	ALL
V00106	1	S271T527-4 VALVE-T/R ISOLATION,L ENG	271T5270 81205	1	78-34-11 NL271/146/	ALL
V00106	2	S271T527-1 VALVE-T/R ISOLATION,L ENG	271T5270 81205	1	78-34-11 NL271/146/	ALL
V00107	1	S271T527-4 VALVE-T/R ISOLATION,R ENG	271T5270 81205	1	78-34-21 NR270/149/	ALL
V00107	2	S271T527-1 VALVE-T/R ISOLATION,R ENG	271T5270 81205	1	78-34-21 NR270/149/	ALL
V00108	1	S343T003-14 VALVE ACTUATOR-DEFUELING, L TANK	344T0002 81205	1	28-26-11 L WING/ /RS	050-099, 150-156, 162-164, 275-276
V00108	1	S343T003-39 VALVE ACTUATOR-DEFUELING, L TANK	344T0002 81205	1	28-26-11 L WING/ /RS	157, 165-199, 277- 299
V00108	2	S343T003-111 VALVE ACTUATOR-DEFUELING, L TANK	344T0002 81205	1	28-26-11 L WING/ /RS	050-099, 150-156, 162-164, 275-276
V00108	2	S343T003-14 VALVE ACTUATOR-DEFUELING, L TANK	344T0002 81205	1	28-26-11 L WING/ /RS	157, 165-199, 277- 299
V00108	3	S343T003-1 VALVE ACTUATOR-DEFUELING, L TANK	344T0002 81205	1	28-26-11 L WING/ /RS	050-099, 150-156, 162-164, 275-276
V00108	3	S343T003-111 VALVE ACTUATOR-DEFUELING, L TANK	344T0002 81205	1	28-26-11 L WING/ /RS	157, 165-199, 277- 299
V00108	4	S343T003-1 VALVE ACTUATOR-DEFUELING, L TANK	344T0002 81205	1	28-26-11 L WING/ /RS	157, 165-199, 277- 299

EQUIPMENT LIST

D280T132

Section V00100

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00109	1	S343T003-14 VALVE ACTUATOR-DEFUELING, R TANK	344T0002 81205	1	28-26-11 R WING/ /RS	050-099, 150-156, 162-164, 275-276
V00109	1	S343T003-39 VALVE ACTUATOR-DEFUELING, R TANK	344T0002 81205	1	28-26-11 R WING/ /RS	157, 165-199, 277- 299
V00109	2	S343T003-111 VALVE ACTUATOR-DEFUELING, R TANK	344T0002 81205	1	28-26-11 R WING/ /RS	050-099, 150-156, 162-164, 275-276
V00109	2	S343T003-14 VALVE ACTUATOR-DEFUELING, R TANK	344T0002 81205	1	28-26-11 R WING/ /RS	157, 165-199, 277- 299
V00109	3	S343T003-1 VALVE ACTUATOR-DEFUELING, R TANK	344T0002 81205	1	28-26-11 R WING/ /RS	050-099, 150-156, 162-164, 275-276
V00109	3	S343T003-111 VALVE ACTUATOR-DEFUELING, R TANK	344T0002 81205	1	28-26-11 R WING/ /RS	157, 165-199, 277- 299
V00109	4	S343T003-1 VALVE ACTUATOR-DEFUELING, R TANK	344T0002 81205	1	28-26-11 R WING/ /RS	157, 165-199, 277- 299
V00110	1	S270T010-14 VALVE-HYD SYS CTR NO 1 ISOLATION	271T4592 81205	1	29-21-32 0990/165/R003	ALL
V00110	2	S270T010-11 VALVE-HYD SYS CTR NO 1 ISOLATION	271T4592 81205	1	29-21-32 0990/165/R003	ALL
V00110	3	S271N501-2 VALVE-HYD SYS CTR NO 1 ISOLATION	271T4592 81205	1	29-21-32 0990/165/R003	ALL
V00110	4	S271N501-2 VALVE-HYD SYS CTR NO 1 ISOLATION	271T4592 81205	1	29-21-32 0990/165/R003	ALL
V00111	1	S270T010-13 VALVE-HYD SYS CTR NO 2 ISOLATION	271T4591 81205	1	29-21-32 1010/154/R006	ALL
V00111	2	S270T010-10 VALVE-HYD SYS CTR NO 2 ISOLATION	271T4591 81205	1	29-21-32 1010/154/R006	ALL
V00112		S210T120-15 VALVE-MODULATING,FAN AIR	312T3204 81205	2	36-23-11 N 185/124/R012	150-157, 275-278
V00115	5	S312T001-3 VALVE-ENGINE INLET TAI,L	312T3203 81205	1	30-21-11 STRUT/ /	ALL
V00115	1	S312T001-8 VALVE-ENGINE INLET TAI,L	312T3203 81205	1	30-21-11 STRUT/ /	ALL
V00115	2	S312T001-7 VALVE-ENGINE INLET TAI,L	312T3203 81205	1	30-21-11 STRUT/ /	ALL

EQUIPMENT LIST

D280T132

Section V00100

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00115	3	S312T001-6 VALVE-ENGINE INLET TAI,L	312T3203 81205	1	30-21-11 STRUT/ /	ALL
V00115	4	S312T001-4 VALVE-ENGINE INLET TAI,L	312T3203 81205	1	30-21-11 STRUT/ /	ALL
V00117	5	S312T001-3 VALVE-ENGINE INLET TAI,R	312T1203 81205	1	30-21-11 STRUT/ /	ALL
V00117	1	S312T001-8 VALVE-ENGINE INLET TAI,R	312T3203 81205	1	30-21-11 STRUT/ /	ALL
V00117	2	S312T001-7 VALVE-ENGINE INLET TAI,R	312T3203 81205	1	30-21-11 STRUT/ /	ALL
V00117	3	S312T001-6 VALVE-ENGINE INLET TAI,R	312T1203 81205	1	30-21-11 STRUT/ /	ALL
V00117	4	S312T001-4 VALVE-ENGINE INLET TAI,R	312T1203 81205	1	30-21-11 STRUT/ /	ALL
V00121		60B92602-11 VALVE-FUELING SHUTOFF,L AUX TANK	344T0002 81205	1	28-21-13 L/ /RS	ALL
V00122		60B92602-11 VALVE-FUELING SHUTOFF,R AUX TANK	344T0002 81205	1	28-21-13 R/ /RS	ALL
V00124		S273T461-1 VALVE-TAIL SKID	273T0104 81205	1	32-71-11 1699/190/50	150-199, 275-299
V00127	1	2780536-101 VALVE-CARGO HEAT FLOW CONT,BULK	214T6003 92003	1	21-44-21 1365/172/L075	050-099, 150-157, 275-299
V00128		2780536-101 VALVE-CARGO HEAT SHUTOFF,BULK	214T6003 92003	1	21-44-21 1355/172/L075	050-099, 150-157, 275-299
V00129	1	S271T002-14 VALVE-PRESS. REGULATOR/SHUT-OFF	212T3006 70210	1	29-11-32 1180/146/L078	ALL
V00129	2	S271T002-4 VALVE-PRESS. REGULATOR/SHUT-OFF	212T3006 70210	1	29-11-32 1180/146/L078	ALL
V00131		AR3289592-1 VALVE-L PACK LOW LIMIT	213T1001 81205	1	21-51-12 0867/123/L034	050-099, 150-199, 275-278
V00131		AR3289696-1 VALVE-L PACK LOW LIMIT	213T1001 81205	1	21-51-12 0867/123/L034	280-299
V00132		AR3289592-1 VALVE-R PACK LOW LIMIT	213T1001 81205	1	21-51-22 0867/123/R044	050-099, 150-199, 275-278

EQUIPMENT LIST

D280T132

Section V00100

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00132		AR3289696-1 VALVE-R PACK LOW LIMIT	213T1001 81205	1	21-51-22 0867/123/R044	280-299
V00140		S210T170-19 VALVE-OVERRIDE	217T1012 81205	1	21-58-16 0395/174/L083	ALL
V00145		S210T130-74 VALVE-TRIM AIR MODULATING MID CABIN ZONE	213T2001 81205	1	21-61-41 0823/123/L015	156-157, 166-199, 277-299
V00145	1	S210T130-70 VALVE-TRIM AIR MODULATING MID CABIN ZONE	213T2001 81205	1	21-61-41 0823/123/L015	050-099, 150-155, 162-165, 275-276
V00145	2	S210T130-61 VALVE-TRIM AIR MODULATING MID CABIN ZONE	213T2001 81205	1	21-61-41 0823/123/L015	050-099, 150-155, 162-165, 275-276
V00145	3	S210T130-34 VALVE-TRIM AIR MODULATING MID CABIN ZONE	213T2001 81205	1	21-61-41 0823/123/L015	050-099, 150-155, 162-165, 275-276
V00147		S270T010-4 VALVE-HYD MTR DRIVEN GEN S/O	272T0189 81205	1	24-25-11 / /	ALL
V00148		60B00311-2 FLAPPER VALVE SOLENOID ASSY	214T6006 81205	1	21-44-21 1510/170/L062	275-276
V00149	1	S270T010-14 VALVE-RIGHT SYSTEM SHUTOFF	272T4800 81205	1	29-11-14 1725/275/R040	ALL
V00149	2	S270T010-11 VALVE-RIGHT SYSTEM SHUTOFF	272T4800 81205	1	29-11-14 1725/275/R040	ALL
V00150	1	S270T010-14 VALVE-LEFT SYSTEM ISOLATION	272T4800 81205	1	29-11-14 1702/288/L030	ALL
V00150	2	S270T010-11 VALVE-LEFT SYSTEM ISOLATION	272T4800 81205	1	29-11-14 1702/288/L030	ALL
V00150	3	S271N501-2 VALVE-LEFT SYSTEM ISOLATION	272T4800 81205	1	29-11-14 1702/288/L030	ALL
V00152	9	S210T130-70 VLV-AUX FWD CABIN ZONE TRIM AIR MOD	00000000 81205	1	21-61-61 0829/120/L015	150-152
V00152		S210T130-61 VLV-AUX FWD CABIN ZONE TRIM AIR MOD	00000000 81205	1	21-61-61 0829/120/L015	050-099, 153-199, 275-299
V00153	9	S210T130-70 VLV-AUX MID CABIN ZONE TRIM AIR MOD	213T2001 81205	1	21-61-71 0829/120/L015	150-152
V00153		S210T130-61 VLV-AUX MID CABIN ZONE TRIM AIR MOD	213T2001 81205	1	21-61-71 0829/120/L015	050-099, 153-155, 275-276

EQUIPMENT LIST

D280T132

Section V00100

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00153		S210T130-74 VLV-AUX MID CABIN ZONE TRIM AIR MOD	213T2001 81205	1	21-61-71 0829/120/L015	156-157, 166-199, 277-299
V00157		S343T003-14 VALVE ACTUATOR-JETTISON NOZZLE,L	344T0002 81205	1	28-31-12 L0901/12/RS	050-099, 155-156, 162-164
V00157		S343T003-14 VALVE ACTUATOR-JETTISON NOZZLE,L (PROV)	344T0002 81205	1	28-31-12 L0901/12/RS	276
V00157	1	S343T003-39 VALVE ACTUATOR-JETTISON NOZZLE,L	344T0002 81205	1	28-31-12 L0901/12/RS	157, 165-199, 277- 299
V00157	2	S343T003-14 VALVE ACTUATOR-JETTISON NOZZLE,L	344T0002 81205	1	28-31-12 L0901/12/RS	157, 165-199, 277- 299
V00158		S343T003-14 VALVE ACTUATOR-JETTISON NOZZLE,R	344T0002 81205	1	28-31-12 R0901/12/RS	050-099, 155-156, 162-164
V00158		S343T003-14 VALVE ACTUATOR-JETTISON NOZZLE,R (PROV)	344T0002 81205	1	28-31-12 R0901/12/RS	276
V00158	1	S343T003-39 VALVE ACTUATOR-JETTISON NOZZLE,R	344T0002 81205	1	28-31-12 R0901/12/RS	157, 165-199, 277- 299
V00158	2	S343T003-14 VALVE ACTUATOR-JETTISON NOZZLE,R	344T0002 81205	1	28-31-12 R0901/12/RS	157, 165-199, 277- 299
V00159		S343T003-14 VALVE ACTUATOR-JETTISON XFR, L	344T0002 81205	1	28-31-11 L0250/12/RS	050-099, 155-156, 162-164
V00159		S343T003-14 VALVE ACTUATOR-JETTISON XFR,L (PROV)	344T0002 81205	1	28-31-11 L0250/12/RS	276
V00159	1	S343T003-39 VALVE ACTUATOR-JETTISON XFR, L	344T0002 81205	1	28-31-11 L0250/12/RS	157, 165-199, 277- 299
V00159	2	S343T003-14 VALVE ACTUATOR-JETTISON XFR, L	344T0002 81205	1	28-31-11 L0250/12/RS	157, 165-199, 277- 299
V00160		S343T003-14 VALVE ACTUATOR-JETTISON XFR, RIGHT	344T0002 81205	1	28-31-11 R0250/14/RS	050-099, 155-156, 162-164
V00160		S343T003-14 VALVE ACTUATOR-JETTISON XFR,R (PROV)	344T0002 81205	1	28-31-11 R0250/14/RS	276
V00160	1	S343T003-39 VALVE ACTUATOR-JETTISON XFR,R	344T0002 81205	1	28-31-11 R0250/14/RS	157, 165-199, 277- 299
V00160	2	S343T003-14 VALVE ACTUATOR-JETTISON XFR,R	344T0002 81205	1	28-31-11 R0250/14/RS	157, 165-199, 277- 299

EQUIPMENT LIST

D280T132

Section V00100

Page 5

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00161		S210T170-19 VALVE-SMOKE EVAC,FLT DK CREW REST	214T3056 81205	1	21-66-11 0266/284/L012	050-099, 162-199
V00162		67-2985-000 VALVE-FLT DK CREW REST SUPPLY	214T2059 89513	1	21-66-11 0638/173/L079	050-099, 162-199
V00163		398116-1-1 VALVE-FLT DK CREW REST MOD	214T2059 07914	1	21-66-11 0526/303/L023	050-099, 162-199
V00167	9	60B00258-5 VALVE-L T/R MOTORIZED HIV(SB 78-0051FAA)	272T0242 81205	1	78-34-11 STRUT/ /	050-099, 150-156, 162-166, 275-276
V00167		60B00258-5 VALVE-L T/R MOTORIZED HIV (RR 41033-23)	272T0242 81205	1	78-34-11 STRUT/ /	157
V00167		60B00258-5 VALVE-L T/R MOTORIZED HIV (RR 41033-24)	272T0242 81205	1	78-34-11 STRUT/ /	167-199
V00167		60B00258-5 VALVE-L T/R MOTORIZED HIV (RR 41034-20)	272T0242 81205	1	78-34-11 STRUT/ /	277-278
V00167		60B00258-5 VALVE-L T/R MOTORIZED HIV (RR 41034-21)	272T0242 81205	1	78-34-11 STRUT/ /	280-299
V00168	9	60B00258-5 VALVE-R T/R MOTORIZED HIV(SB 78-0051FAA)	272T0242 81205	1	78-34-21 STRUT/ /	050-099, 150-156, 162-166, 275-276
V00168		60B00258-5 VALVE-R T/R MOTORIZED HIV (RR 41033-23)	272T0242 81205	1	78-34-21 STRUT/ /	157
V00168		60B00258-5 VALVE-R T/R MOTORIZED HIV (RR 41033-24)	272T0242 81205	1	78-34-21 STRUT/ /	167-199
V00168		60B00258-5 VALVE-R T/R MOTORIZED HIV (RR 41034-20)	272T0242 81205	1	78-34-21 STRUT/ /	277-278
V00168		60B00258-5 VALVE-R T/R MOTORIZED HIV (RR 41034-21)	272T0242 81205	1	78-34-21 STRUT/ /	280-299
V00170	9	S315N370-1 SOL-LH SSL (SB 78-0062)	315T4725 81205	2	78-34-01 / /	ALL
V00171	9	S315N370-1 SOL-RH SSL (SB 78-0062)	315T4725 81205	2	78-34-01 / /	ALL

EQUIPMENT LIST

D280T132

Section V00100
Page 6 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00342		S315N305-1 VALVE-CONTROL,DIRECTIONAL-L	00000000 81205	1	78-34-11 NL/ /	ALL
V00343		S315N305-1 VALVE-CONTROL,DIRECTIONAL-R	00000000 81205	1	78-34-21 NL/ /	ALL
V00347	9	S210T120-141 VALVE-HP SHUTOFF (SB 36-0053)	332T4320 73030	2	36-11-61 NL167/116/M021	ALL
V00347		S210T120-101 VALVE-HP SHUTOFF	332T4320 73030	2	36-11-61 NL167/116/M021	050-099, 150-154, 275-276
V00347		S210T120-111 VALVE-HP SHUTOFF	332T4320 73030	2	36-11-61 NL167/116/M021	155-199, 277-299
V00348		S210T120-115 VALVE-FAN AIR CONTROL	312T3204 773855	2	36-23-11 NL185/124/L012	ALL
V00349	1	60B00256 VALVE-ENG HYD PUMP DEPRESS	332T1080 81205	2	29-11-11 /ENG/	ALL
V00349	2	60B00200 VALVE-ENG HYD PUMP DEPRESS	332T1080 81205	2	29-11-11 /ENG/	ALL
V00350	5	50G982 VALVE ASSY-FAN AIR S/O,IDG OIL COOLER	0050A101 73030	2	24-11-11 ENG/ /	ALL
V00350	1	51G760 VALVE ASSY-FAN AIR S/O,IDG OIL COOLER	0050A101 73030	2	24-11-11 ENG/ /	ALL
V00350	2	51G542 VALVE ASSY-FAN AIR S/O,IDG OIL COOLER	0050A101 73030	2	24-11-11 ENG/ /	ALL
V00350	3	51G294 VALVE ASSY-FAN AIR S/O,IDG OIL COOLER	0050A101 73030	2	24-11-11 ENG/ /	ALL
V00350	4	51G077 VALVE ASSY-FAN AIR S/O,IDG OIL COOLER	0050A101 73030	2	24-11-11 ENG/ /	ALL
V00351		S332T002-1 VALVE-ENGINE STARTER CONTROL	332U2311 81205	2	80-11-11 ENG/ /	ALL
V00352	9	S210T120-141 VALVE-PRESSURE REGULATING (SB 36-0053)	332T4320 73030	2	36-11-61 NL167/116/018	ALL
V00352		S210T120-101 VALVE-PRESSURE REGULATING	332T4320 73030	2	36-11-61 NL167/116/018	050-099, 150-154, 275-276
V00352		S210T120-111 VALVE-PRESSURE REGULATING	332T4320 73030	2	36-11-61 NL167/116/018	155-199, 277-299

EQUIPMENT LIST

D280T132

Section V00300

Page 1

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00353		S315T106-3 VALVE-NACELLE COOLING	00000000 81205	2	75-23-11 ENG/ /	ALL
V00357		PWSUPPLIED VALVE-AIR/OIL HEAT EXCHANGER	VENDORS 81205	1	71-51-14 ENG/ /	ALL
V00379	9	S417T102-4 VAL-VAC SO,LAV SYS 2 (SB 38-027)	417T1325 81205	1	38-32-14 1549/185/L040	050-099, 150-154, 162-164, 275-276
V00379		S417T102-3 VALVE-VACUUM SHUTOFF,LAV SYS 2	417T1325 81205	1	38-32-14 1549/185/L040	050-099, 150-154, 162-164, 275-276
V00379		S417T102-5 VALVE-VACUUM SHUTOFF,LAV SYS 2	417T1325 81205	1	38-32-14 1549/185/L040	155-157, 165-199, 277-299
V00380	9	S417T102-5 VAL-VAC SO,LAV SYS 1 (SB 38-027)	417T1325 81205	1	38-32-14 1570/185/L040	050-099, 150-154, 162-164, 275-276
V00380		S417T102-3 VALVE-VACUUM SHUTOFF,LAV SYS 1	417T1325 81205	1	38-32-14 1570/185/L040	050-099, 150-154, 162-164, 275-276
V00380		S417T102-4 VALVE-VACUUM SHUTOFF,LAV SYS 1	417T1325 81205	1	38-32-14 1570/185/L040	155-157, 165-199, 277-299
V00381		60B40048-1 VALVE-CARGO A/C SHUTOFF	00000000 81205	1	21-28-11 0754/145/L062	ALL
V00382		60B40048-1 VALVE-CARGO EXHAUST	00000000 81205	1	21-28-11 0395/117/L025	ALL
V00383		60B40048-1 VALVE-CARGO GND EXH	00000000 81205	1	21-28-11 0689/117/L005	050-099
V00383		60B40048-1 VALVE-CARGO GND EXH	00000000 81205	1	21-28-11 0654+28/117/L005	150-199, 275-299
V00384		60B40048-1 VALVE-CARGO GND EXH BACKUP	00000000 81205	1	21-28-11 0689/117/0000	050-099
V00384		60B40048-1 VALVE-CARGO GND EXH BACKUP	00000000 81205	1	21-28-11 0654+28/117/0000	150-199, 275-299
V00385		S210T130-74 VALVE-TRIM AIR MODULATING,FWD CARGO	214T6002 81205	1	21-61-81 0786/120/L020	050-099, 150-199, 275-276
V00385		S210T130-70 VALVE-TRIM AIR MODULATING,FWD CARGO	214T6002 81205	1	21-61-81 0786/120/L020	277-299
V00386	9	60B50341-5 V-FWD TANK PRCH CTL (SB 38-0035)	00000000 81205	1	38-32-11 1567/195/0000	275-276

EQUIPMENT LIST

D280T132

Section V00300

Page 2

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
V00386		60B50341-5 VALVE-FWD TANK PRECHARGE CONTROL	417T1323 81205	1	38-32-11 1567/195/0000	156-157, 166-199, 277-299
V00387	9	60B50341-5 V-AFT TANK PRCH CTL (SB 38-0035)	00000000 81205	1	38-32-11 1572/195/0000	275-276
V00387		60B50341-5 VALVE-AFT TANK PRECHARGE CONTROL	417T1323 81205	1	38-32-11 1572/195/0000	156-157, 166-199, 277-299
V00388	9	S343T003-39 VLV ACTR-FWD FUEL CROSSFEED (SB 28-0034)	343T0002 81205	1	28-22-31 0954/166/L029	ALL
V00389	9	S343T003-39 VLV ACTR-AFT FUEL CROSSFEED (SB 28-0034)	343T0002 81205	1	28-22-31 0954/156/L029	ALL

EQUIPMENT LIST

D280T132

Section V00300

Page 3 End

Feb 06/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA3++++		USEM00032 CONT PNL-SQUIB TEST	00000000 81205	0	26-21-11 SCH 26/21/01	ALL

EQUIPMENT LIST

D280T132

Section YA3+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA3L001		116-565-1042-001 LIGHT-CARGO,FWD	00000000 81590	1	26-23-11 //	ALL
YA3L001A		MS25237-387 LAMP	00000000 96906	1	26-23-11 //	ALL
YA3L002		116-565-1042-001 LIGHT-CARGO,AFT	00000000 81590	1	26-23-12 //	050-099, 155-199, 275-299
YA3L002		116-565-1042-001 LIGHT-CARGO,AFT	00000000 81590	1	26-23-11 //	150-154
YA3L002A		MS25237-387 LAMP	00000000 96906	1	26-23-12 //	050-099, 155-199, 275-299
YA3L002A		MS25237-387 LAMP	00000000 96906	1	26-23-11 //	150-154
YA3L003		116-565-1042-001 LIGHT-ENG,L	00000000 81590	1	26-21-11 //	ALL
YA3L004		116-565-1042-001 LIGHT-ENG,R	00000000 81590	1	26-21-11 //	ALL
YA3L005		116-565-1042-001 LIGHT-EMER ESCAPE LEFT	00000000 81590	1	25-65-11 //	ALL
YA3L006		116-565-1042-001 LIGHT-EMER ESCAPE RIGHT	00000000 81590	1	25-65-11 //	ALL
YA3L006A		MS25237-387 LAMP	00000000 96906	1	25-65-11 //	ALL
YA3L007		116-565-1042-001 LIGHT-APU	00000000 81590	1	26-22-21 //	ALL
YA3L008		116-565-1042-001 LIGHT-CARGO, 2A	00000000 81590	1	26-23-12 //	050-099, 155-199, 275-299
YA3L008A		MS25237-387 LAMP	00000000 96906	1	26-23-12 //	050-099, 155-199, 275-299
YA3L03A		MS25237-387 LAMP	00000000	0	26-21-11 //	ALL
YA3L04A		MS25237-387 LAMP	00000000	0	26-21-11 //	ALL
YA3L05A		MS25237-387 LAMP	00000000	1	25-65-11 //	ALL

EQUIPMENT LIST

D280T132

Section YA3L00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA3L06A		MS25237-387 LAMP	00000000	1	25-65-11 / /	ALL
YA3L07A		MS25237-387 LAMP	00000000	0	26-22-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YA3L00
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA3S001		P4-10082-2 SW-TEST 1	00000000 21649	1	26-21-11 / /	ALL
YA3S002		P4-10082-2 SW-TEST 2	00000000 21649	1	26-21-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YA3S00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA9++++		USEM00844 CONT PNL-FWD CAR. HDLG	00000000 81205	0	25-53-11 SCH 25/53/01	ALL

EQUIPMENT LIST

D280T132

Section YA9+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA9L001		L5105-AM LIGHT-LD3 UP	284T0216 81640	1	25-53-16 //	ALL
YA9L002		L5105-AM LIGHT-LD2 UP	284T0216 81640	1	25-53-16 //	ALL
YA9L003		L5105-AM LIGHT-ALL DOWN,CTR GUIDES	284T0216 81640	1	25-53-16 //	ALL
YA9L004		L5105-AM LIGHT-PDU FWD ON	284T0216 81640	1	25-53-13 //	ALL
YA9L005		L5105-AM LIGHT-PDU AFT ON	284T0216 81640	1	25-53-13 //	ALL
YA9L006		L5105-AM LIGHT-ROLLOUT STOP DOWN	284T0216 81640	1	25-53-17 //	ALL
YA9L007		L5105-AM LIGHT-UP,ROLLOUT STOP	284T0216 81640	1	25-53-17 //	ALL
YA9L008		L5105-G3 LIGHT-LOCK,ROLLOUT STOP	284T0216 81640	1	25-53-17 //	ALL
YA9L009		L5105-AM LIGHT-PALLET MODE	284T0216 81640	1	25-53-13 //	ALL
YA9L01A		MS25237-387 LAMP	00000000 96906	1	25-53-16 //	ALL
YA9L02A		MS25237-387 LAMP	00000000 96906	1	25-53-16 //	ALL
YA9L03A		MS25237-387 LAMP	00000000 96906	1	25-53-16 //	ALL
YA9L04A		MS25237-387 LAMP	00000000 96906	1	25-53-13 //	ALL
YA9L05A		MS25237-387 LAMP	00000000 96906	1	25-53-13 //	ALL
YA9L06A		MS25237-387 LAMP	00000000 96906	1	25-53-17 //	ALL
YA9L07A		MS25237-387 LAMP	00000000 96906	1	25-53-17 //	ALL
YA9L08A		MS25237-387 LAMP	00000000 96906	1	25-53-17 //	ALL

EQUIPMENT LIST

D280T132

Section YA9L00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA9L09A		MS25237-387 LAMP	00000000 96906	1	25-53-13 / /	ALL

EQUIPMENT LIST

D280T132

Section YA9L00
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YA9S001		2TL82-10 SW-CENTER GUIDES	284T0216 91929	1	25-53-16 / /	ALL
YA9S002		1TL82-3 SW-POWERED DRIVE UNITS FWD ON,CAR. HDLG	284T0216 91929	1	25-53-13 / /	ALL
YA9S003		2TL82-10 SW-ROLLOUT STOPS	284T0216 91929	1	25-53-17 / /	ALL
YA9S004		MS24523-23 SW-SYS PWR,FWD CAR. HDLG	00000000 96906	1	25-53-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YA9S00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAA++++		USEM00239 MODULE-HYD,AUTOBRAKE	00000000 81205	0	32-42-12 SCH 32/42/00	ALL

EQUIPMENT LIST

D280T132

Section YAA+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAAS001		S271T452-3 SW-AUTOBRAKE CONT VALVE PRESS.	00000000 81205	1	32-42-12 / /	ALL
YAAS002		S271T452-3 SW-AUTOBRAKE SOLENOID VALVE PRESS.	00000000 81205	1	32-42-12 / /	ALL

EQUIPMENT LIST

D280T132

Section YAAS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAAV001	1	10-60811-8 VALVE-AUTOBRAKE SOLENOID	00000000 81205	1	32-42-12 / /	ALL
YAAV001	2	10-60811-9 VALVE-AUTOBRAKE SOLENOID	00000000 81205	1	32-42-12 / /	ALL
YAAV001	3	10-60811-3 VALVE-AUTOBRAKE SOLENOID	00000000 81205	1	32-42-12 / /	ALL
YAAV002		20101460-4 VALVE-AUTOBRAKE PRESSURE CONTROL	S274T401 81873	1	32-42-12 / /	ALL

EQUIPMENT LIST

D280T132

Section YAAV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAL++++		USEM10250 PNL-YAW DAMPER	00000000 81205	0	22-21-11 SCH 22/21/01	ALL

EQUIPMENT LIST

D280T132

Section YAL+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YALS001	5	S231T290-1016 SW-YAW DAMPER,LEFT	233N3216 81205	1	22-21-11 //	ALL
YALS001	1	S231T290-5016 SW-YAW DAMPER,LEFT	233N3216 81205	1	22-21-11 //	ALL
YALS001	2	S231T290-4016 SW-YAW DAMPER,LEFT	233N3216 81205	1	22-21-11 //	ALL
YALS001	3	S231T290-3016 SW-YAW DAMPER,LEFT	233N3216 81205	1	22-21-11 //	ALL
YALS001	4	S231T290-2016 SW-YAW DAMPER,LEFT	233N3216 81205	1	22-21-11 //	ALL
YALS002	5	S231T290-1016 SW-YAW DAMPER,RIGHT	233N3216 81205	1	22-21-21 //	ALL
YALS002	1	S231T290-5016 SW-YAW DAMPER,RIGHT	233N3216 81205	1	22-21-21 //	ALL
YALS002	2	S231T290-4016 SW-YAW DAMPER,RIGHT	233N3216 81205	1	22-21-21 //	ALL
YALS002	3	S231T290-3016 SW-YAW DAMPER,RIGHT	233N3216 81205	1	22-21-21 //	ALL
YALS002	4	S231T290-2016 SW-YAW DAMPER,RIGHT	233N3216 81205	1	22-21-21 //	ALL

EQUIPMENT LIST

D280T132

Section YALS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAR++++		USEM00074 CONT PNL-AILERON & RUDDER TRIM	00000000 81205	0	27-11-11 SCH 27/10/00	ALL

EQUIPMENT LIST

D280T132

Section YAR+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YARJ001		BACC45FN18-14P RCPT-MODULE DISCONNECT	00000000 81205	1	27-11-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YARJ00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YARS001		1TL163-7 SW-AILERON TRIM ARM	00000000 91929	1	27-11-11 / /	ALL
YARS002		2TL163-70 SW-AILERON TRIM CONT	00000000 91929	1	27-11-11 / /	ALL
YARS003		024804-002 SW-RUDDER TRIM CONT	00000000 28277	1	27-21-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YARS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAS++++		USEM00001 CONT PNL-APU	00000000 81205	0	49-61-11 SCH 49/61/00	ALL

EQUIPMENT LIST

D280T132

Section YAS+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YASK001		BACR13CD2 RELAY-APU START	00000000 81205	1	49-61-11 / /	ALL
YASK002		BACR13CD2 RELAY-APU FIRE	00000000 81205	1	49-61-11 / /	ALL
YASK003		TDH-1798-1000 TIME DELAY-FIRE RELAY	00000000 35344	1	49-61-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YASK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YASL01+	1	S231T300-2030 LIGHT INDICATOR-APU FAULT	00000000 81205	1	49-61-11 //	ALL
YASL01+	2	S231T300-1036 LIGHT INDICATOR-APU FAULT	00000000 81205	1	49-61-11 //	ALL
YASL01+	3	S231T300-1036 LIGHT INDICATOR-APU FAULT	00000000 81205	1	49-61-11 //	ALL
YASL01A		MS25237-387 LAMP	00000000 96906	1	49-61-11 //	ALL
YASL01D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	49-61-11 //	ALL
YASL02+	1	S231T300-2122 LIGHT INDICATOR-APU RUN	00000000 81205	1	49-61-11 //	ALL
YASL02+	2	S231T300-1122 LIGHT INDICATOR-APU RUN	00000000 81205	1	49-61-11 //	ALL
YASL02+	3	S231T300-1122 LIGHT INDICATOR-APU RUN	00000000 81205	1	49-61-11 //	ALL
YASL02A		MS25237-387 LAMP	00000000 96906	1	49-61-11 //	ALL
YASL02D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	49-61-11 //	ALL

EQUIPMENT LIST

D280T132

Section YASL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YASS001		AC45-0003 SWITCH-APU START/ON	00000000 91812	1	49-61-11 //	ALL

EQUIPMENT LIST

D280T132

Section YASS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAY++++		USEM00049 CONT PNL-ENG IGN & START	00000000 81205	0	74-31-11 SCH 74/31/00	ALL

EQUIPMENT LIST

D280T132

Section YAY+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAYK001		BACR13CG2A RELAY-L ENG AUTO IGN CONT	00000000 81205	1	74-31-11 / /	ALL
YAYK002		BACR13CG2A RELAY-R ENG AUTO IGN CONT	00000000 81205	1	74-31-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YAYK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAYL01+	1	S231T300-2115 LIGHT IND-VALVE,L ENG STARTER	00000000 81205	1	80-11-11 //	ALL
YAYL01+	2	S231T300-1115 LIGHT IND-VALVE,L ENG STARTER	00000000 81205	1	80-11-11 //	ALL
YAYL01+	3	S231T300-1115 LIGHT IND-VALVE,L ENG STARTER	00000000 81205	1	80-11-11 //	ALL
YAYL01A		MS25237-387 LAMP,28V-L ENG STARTER VALVE LT	00000000 96906	2	80-11-11 //	ALL
YAYL01D		434-093-001 DIODE/FUSE MODULE-L ENG STARTER VALVE LT	00000000 81590	1	80-11-11 //	ALL
YAYL02+	1	S231T300-2115 LIGHT IND-VALVE,R ENG STARTER	00000000 81205	1	80-11-21 //	ALL
YAYL02+	2	S231T300-1115 LIGHT IND-VALVE,R ENG STARTER	00000000 81205	1	80-11-21 //	ALL
YAYL02+	3	S231T300-1115 LIGHT IND-VALVE,R ENG STARTER	00000000 81205	1	80-11-21 //	ALL
YAYL02A		MS25237-387 LAMP,28V-R ENG STARTER VALVE LT	00000000 96906	2	80-11-21 //	ALL
YAYL02D		434-093-001 DIODE/FUSE MODULE-R ENG STARTER VALVE LT	00000000 81590	1	80-11-21 //	ALL

EQUIPMENT LIST

D280T132

Section YAYL00
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAYS001		AC30-0004 SWITCH-L IGN & START CONTROL	00000000 91812	1	74-31-11 //	ALL
YAYS002		AC30-0004 SWITCH-R IGN & START CONTROL	00000000 91812	1	74-31-21 //	ALL
YAYS003		AC45-0010-1 SWITCH-IGNITION SELECT	00000000 91812	1	74-31-11 //	ALL
YAYS004	5	S231T290-2079 SW-RAM AIR TURB	00000000 81205	1	29-21-31 //	ALL
YAYS004	1	S231T290-4079 SW-RAM AIR TURB	00000000 81205	1	29-21-31 //	ALL
YAYS004	2	S231T290-5079 SW-RAM AIR TURB	00000000 81205	1	29-21-31 //	ALL
YAYS004	3	S231T290-3079 SW-RAM AIR TURB	00000000 81205	1	29-21-31 //	ALL
YAYS004	4	S231T290-1079 SW-RAM AIR TURB	00000000 81205	1	29-21-31 //	ALL

EQUIPMENT LIST

D280T132

Section YAYS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAZ++++		USEM00073 CONT PNL-FUEL	00000000 81205	0	76-11-11 SCH 76/11/00	ALL

EQUIPMENT LIST

D280T132

Section YAZ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAZK001		BACR13CD2 RELAY-SPAR VALVE DISAGREE,LEFT	00000000 81205	1	28-22-21 / /	ALL
YAZK002		BACR13CD2 RELAY-SPAR VALVE DISAGREE,RIGHT	00000000 81205	1	28-22-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YAZK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAZL01+	1	S231T300-2109 LIGHT-SPAR VALVE,LEFT	00000000 81205	1	28-22-21 //	ALL
YAZL01+	2	S231T300-1109 LIGHT-SPAR VALVE,LEFT	00000000 81205	1	28-22-21 //	ALL
YAZL01+	3	S231T300-1109 LIGHT-SPAR VALVE,LEFT	00000000 81205	1	28-22-21 //	ALL
YAZL02+	1	S231T300-2034 LIGHT IND-VALVE,L ENG	00000000 81205	1	76-11-11 //	ALL
YAZL02+	2	S231T300-1034 LIGHT IND-VALVE,L ENG	00000000 81205	1	76-11-11 //	ALL
YAZL02+	3	S231T300-1034 LIGHT IND-VALVE,L ENG	00000000 81205	1	76-11-11 //	ALL
YAZL02A		MS25237-387 LAMP,28V-L ENG VALVE LT	00000000 96906	2	76-11-11 //	ALL
YAZL02D		434-093-001 DIODE/FUSE MODULE-L ENG VALVE LT	00000000 81590	1	76-11-11 //	ALL
YAZL03+	1	S231T300-2109 LIGHT-SPAR VALVE,RIGHT	00000000 81205	1	28-22-21 //	ALL
YAZL03+	2	S231T300-1109 LIGHT-SPAR VALVE,RIGHT	00000000 81205	1	28-22-21 //	ALL
YAZL03+	3	S231T300-1109 LIGHT-SPAR VALVE,RIGHT	00000000 81205	1	28-22-21 //	ALL
YAZL04+	1	S231T300-2034 LIGHT IND-VALVE,R ENG	00000000 81205	1	76-11-11 //	ALL
YAZL04+	2	S231T300-1034 LIGHT IND-VALVE,R ENG	00000000 81205	1	76-11-11 //	ALL
YAZL04+	3	S231T300-1034 LIGHT IND-VALVE,R ENG	00000000 81205	1	76-11-11 //	ALL
YAZL04A		MS25237-387 LAMP,28V-R ENG VALVE LT	00000000 96906	2	76-11-11 //	ALL
YAZL04D		434-093-001 DIODE/FUSE MODULE-R ENG VALVE LT	00000000 81590	1	76-11-11 //	ALL
YAZL05+	1	S231T300-2101 LIGHT IND-REV ISLN	00000000 81205	1	78-36-11 //	ALL

EQUIPMENT LIST

D280T132

Section YAZL00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAZL05+	2	S231T300-1101 LIGHT IND-REV ISLN	00000000 81205	1	78-36-11 / /	ALL
YAZL05+	3	S231T300-1101 LIGHT IND-REV ISLN	00000000 81205	1	78-36-11 / /	ALL
YAZL05A		MS25237-387 LAMP,28V-REV ISLN LT	00000000 96906	2	78-36-11 / /	ALL
YAZL05D		434-093-001 DIODE/FUSE MODULE-REV ISLN LT	00000000 81590	1	78-36-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YAZL00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YAZS005		MS24523-23 SW-STAB TRIM,LEFT	00000000 96906	1	27-41-11 //	ALL
YAZS006		MS24523-23 SW-STAB TRIM,RIGHT	00000000 96906	1	27-41-12 //	ALL
YAZS01+		3TL32-3D SWITCH-FUEL CONTROL,LEFT	00000000 91929	1	76-11-11 //	ALL
YAZS01A		MS25237-387 LAMP,28V-L FUEL CONTROL SW	00000000 96906	1	76-11-11 //	ALL
YAZS03+		3TL32-3D SWITCH-FUEL CONTROL,RIGHT	00000000 91929	1	76-11-11 //	ALL
YAZS03A		MS25237-387 LAMP,28V-R FUEL CONTROL SW	00000000 96906	1	76-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YAZS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB1++++		USEM00043 MODULE-EMERGENCY LIGHTS	00000000 81205	0	33-51-11 SCH 33/51/01	ALL

EQUIPMENT LIST

D280T132

Section YB1+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB1L01+	1	S231T290-4113 LT-UNARMED	00000000 81205	1	33-51-11 //	050-099, 153-199, 275-299
YB1L01+	1	S231T290-2113 LT-UNARMED	00000000 81205	1	33-51-11 //	150-152
YB1L01+	2	S231T290-5113 LT-UNARMED	00000000 81205	1	33-51-11 //	050-099, 153-199, 275-299
YB1L01+	2	S231T290-1113 LT-UNARMED	00000000 81205	1	33-51-11 //	150-152
YB1L01A		MS25237-387 LAMP	00000000 96906	2	33-51-11 //	ALL
YB1L01D		434-093-001 DIODE MODULE	00000000 81590	2	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YB1L00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB1S01+		68AT34-1 SW-EMER LIGHTS	00000000 91929	1	33-51-11 //	ALL
YB1S01A		387 LAMP-EMER LTS SW	00000000 08806	2	33-51-11 //	ALL
YB1S02+	1	S231T290-4041 SW-PASSENGER OXYGEN	00000000 81590	1	35-21-11 //	050-099, 153-199, 275-299
YB1S02+	1	S231T290-241 SW-PASSENGER OXYGEN	00000000 96182	1	35-21-11 //	150-152
YB1S02+	2	S231T290-5041 SW-PASSENGER OXYGEN	00000000 96019	1	35-21-11 //	050-099, 153-199, 275-299
YB1S02+	2	S231T290-41 SW-PASSENGER OXYGEN	00000000 96182	1	35-21-11 //	150-152
YB1S02A		387 LAMP-PASSENGER OXY SW	00000000 08806	2	35-21-11 //	ALL
YB1S02D		851-30768-823 MODULE-DIODE/FUSE	00000000 96182	1	35-21-11 //	ALL

EQUIPMENT LIST

D280T132

Section YB1S00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB2++++		USEM00052 CONT PNL-SIGNS,PASS.	00000000 81205	0	33-24-11 SCH 33/24/01	ALL

EQUIPMENT LIST

D280T132

Section YB2+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB2CR01		JANTX1N5618 DIODE-BLOCKING,NSFSB SIGN	00000000 09922	1	33-24-11 P005-00/ /	ALL

EQUIPMENT LIST

D280T132

Section YB2C
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB2S001		AC45-2-N3 SW-FASTEN SEAT BELT	00000000 81205	1	33-24-11 //	ALL
YB2S002		AC45-1-N3 SW-NO SMOKE	00000000 81205	1	33-24-11 //	ALL

EQUIPMENT LIST

D280T132

Section YB2S00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB3++++		USEP00029 PNL-MASTER DIM & TEST,PC CARD FILE	00000000 81205	0	33-16-11 SCH 33/16/01	ALL

EQUIPMENT LIST

D280T132

Section YB3+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB3K001		J-D9B-013 RELAY-L1 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K002		J-D9B-013 RELAY-L2 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K003		J-D9B-013 RELAY-L3 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K004		J-D9B-013 RELAY-R1 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K005		J-D9B-013 RELAY-R2 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K006		J-D9B-013 RELAY-R3 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K007		J-D9B-013 RELAY-BAT.1 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K008		J-D9B-013 RELAY-BAT.2 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K009		J-D9B-013 RELAY-BAT.3 PILOTS DIM	00000000 35344	1	33-16-11 //	ALL
YB3K010		J-D9B-013 RELAY-AUTOBRIGHT BATTERY CONTROL	00000000 35344	1	33-16-11 //	ALL
YB3K011		J-D9B-013 RELAY-L1 R SIDE PNL DIM	00000000 35344	1	33-16-21 //	ALL
YB3K012		J-D9B-013 RELAY-L2 R SIDE PNL DIM	00000000 35344	1	33-16-21 //	ALL
YB3K013		J-D9B-013 RELAY-L3 R SIDE PNL DIM	00000000 35344	1	33-16-21 //	ALL
YB3K014		J-D9B-013 RELAY-R1 R SIDE PNL DIM	00000000 35344	1	33-16-21 //	ALL
YB3K015		J-D9B-013 RELAY-R2 R SIDE PNL DIM	00000000 35344	1	33-16-21 //	ALL
YB3K016		J-D9B-013 RELAY-R3 R SIDE PNL DIM	00000000 35344	1	33-16-21 //	ALL
YB3K017		J-D9B-013 RELAY-BAT.1 R SIDE PNL DIM	00000000 35344	1	33-16-21 //	ALL

EQUIPMENT LIST

D280T132

Section YB3K00

Page 1

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB3K018		J-D9B-013 RELAY-BAT.2 R SIDE PNL DIM	00000000 35344	1	33-16-21 / /	ALL
YB3K019		J-D9B-013 RELAY-BAT.3 R SIDE PNL DIM	00000000 35344	1	33-16-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YB3K00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB3M001	1	285T0097-9 PC ASSY-DIMMER,TYPE I,L1	00000000 81205	1	33-16-11 //	ALL
YB3M001	2	285T0097-6 PC ASSY-DIMMER,TYPE I,L1	00000000 81205	1	33-16-11 //	ALL
YB3M002	1	285T0097-9 PC ASSY-DIMMER,TYPE I,L2	00000000 81205	1	33-16-11 //	ALL
YB3M002	2	285T0097-6 PC ASSY-DIMMER,TYPE I,L2	00000000 81205	1	33-16-11 //	ALL
YB3M003	1	285T0097-9 PC ASSY-DIMMER,TYPE I,L3	00000000 81205	1	33-16-11 //	ALL
YB3M003	2	285T0097-6 PC ASSY-DIMMER,TYPE I,L3	00000000 81205	1	33-16-11 //	ALL
YB3M004	1	285T0097-9 PC ASSY-DIMMER,TYPE I,R1	00000000 81205	1	33-16-11 //	ALL
YB3M004	2	285T0097-6 PC ASSY-DIMMER,TYPE I,R1	00000000 81205	1	33-16-11 //	ALL
YB3M005	1	285T0097-9 PC ASSY-DIMMER,TYPE I,R2	00000000 81205	1	33-16-11 //	ALL
YB3M005	2	285T0097-6 PC ASSY-DIMMER,TYPE I,R2	00000000 81205	1	33-16-11 //	ALL
YB3M006	1	285T0097-9 PC ASSY-DIMMER,TYPE I,R3	00000000 81205	1	33-16-11 //	ALL
YB3M006	2	285T0097-6 PC ASSY-DIMMER,TYPE I,R3	00000000 81205	1	33-16-11 //	ALL
YB3M007	1	285T0097-9 PC ASSY-DIMMER,TYPE I,BAT.1	00000000 81205	1	33-16-11 //	ALL
YB3M007	2	285T0097-6 PC ASSY-DIMMER,TYPE I,BAT.1	00000000 81205	1	33-16-11 //	ALL
YB3M008	1	285T0097-9 PC ASSY-DIMMER,TYPE I,BAT.2	00000000 81205	1	33-16-11 //	ALL
YB3M008	2	285T0097-6 PC ASSY-DIMMER,TYPE I,BAT.2	00000000 81205	1	33-16-11 //	ALL
YB3M009	1	285T0097-9 PC ASSY-DIMMER,TYPE I,BAT.3	00000000 81205	1	33-16-11 //	ALL

EQUIPMENT LIST

D280T132

Section YB3M00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB3M009	2	285T0097-6 PC ASSY-DIMMER,TYPE I,BAT.3	00000000 81205	1	33-16-11 / /	ALL
YB3M010		285T0464 PC ASSY-DIODE,REVERSE CURRENT BLOCKING	00000000 81205	1	33-16-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YB3M00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB4++++		USEM00211 MODULE-STAB. TRIM CONTROL,LEFT	00000000 81205	0	27-41-11 SCH 27/41/01	150-154

EQUIPMENT LIST

D280T132

Section YB4+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB4S001		10-60552-5 SW ASSY-HYDRAULIC PRESSURE	00000000 19156	1	27-41-11 / /	150-154

EQUIPMENT LIST

D280T132

Section YB4S00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB4V001		401-09772-01 VALVE-SOLENOID,ARM,UP	00000000 81205	1	27-41-11 / /	150-154
YB4V002		401-09772-01 VALVE-SOLENOID,CONT,UP	00000000 81205	1	27-41-11 / /	150-154
YB4V003		920129-100 VALVE-MOTOR OPERATED	00000000 81205	1	27-41-11 / /	150-154
YB4V004		401-09772-01 VALVE-SOLENOID,ARM,DOWN	00000000 81205	1	27-41-11 / /	150-154
YB4V005		401-09772-01 VALVE-SOLENOID,CONT,DOWN	00000000 81205	1	27-41-11 / /	150-154

EQUIPMENT LIST

D280T132

Section YB4V00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB5++++		USEM00212 MODULE-STAB. TRIM CONTROL,RIGHT	00000000 81205	0	27-41-21 SCH 27/41/01	150-154

EQUIPMENT LIST

D280T132

Section YB5+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB5S001		10-60552-5 SW ASSY-HYDRAULIC PRESSURE	00000000 19156	1	27-41-21 / /	150-154

EQUIPMENT LIST

D280T132

Section YB5S00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB5V001		401-09772-01 VALVE-SOLENOID,ARM,UP	00000000 81205	1	27-41-21 / /	150-154
YB5V002		401-09772-01 VALVE-SOLENOID,CONT,UP	00000000 81205	1	27-41-21 / /	150-154
YB5V003		920129-100 VALVE-MOTOR OPERATED	00000000 81205	1	27-41-21 / /	150-154
YB5V004		401-09772-01 VALVE-SOLENOID,ARM,DOWN	00000000 81205	1	27-41-21 / /	150-154
YB5V005		401-09772-01 VALVE-SOLENOID,CONT,DOWN	00000000 81205	1	27-41-21 / /	150-154

EQUIPMENT LIST

D280T132

Section YB5V00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB6++++		USEV00104 VALVE-FLAPS & SLATS SHUTOFF	00000000 81205	0	27-51-31 SCH 27/51/31	ALL

EQUIPMENT LIST

D280T132

Section YB6+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB6V001	1	10-60811-8 VALVE-FLAPS & SLATS SHUTOFF	00000000 81205	1	27-51-31 / /	ALL
YB6V001	2	10-60811-9 VALVE-FLAPS & SLATS SHUTOFF	00000000 81205	1	27-51-31 / /	ALL
YB6V002	1	10-60811-8 VALVE-FLAPS & SLATS SHUTOFF	286TXXXX 81205	1	27-81-31 / /	ALL
YB6V002	2	10-60811-9 VALVE-FLAPS & SLATS SHUTOFF	286TXXXX 81205	1	27-81-31 / /	ALL

EQUIPMENT LIST

D280T132

Section YB6V00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB7++++		USEM01135 PANEL-OFF-WING ESCAPE SYS,L	00000000 81205	0	25-65-11 SCH 25/65/01	ALL

EQUIPMENT LIST

D280T132

Section YB7+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB7K001		X-D4L-015 RELAY-SLIDE DOOR SQUIB	00000000 35344	1	25-65-11 / /	ALL
YB7K002		X-D4L-015 RELAY-SPOILER RETRACT	00000000 35344	1	25-65-11 / /	ALL
YB7K003		X-D4L-015 RELAY-TEST,SLIDE DR SQUIB	00000000 35344	1	25-65-11 / /	ALL
YB7K004		X-D4L-015 RELAY-TEST,SPOILER SQUIB	00000000 35344	1	25-65-11 / /	ALL
YB7K005		X-D4L-015 RELAY-SLIDE DR SQUIB TEST 2	00000000 35344	1	25-65-11 / /	150-199, 275-299
YB7K006		X-D4L-015 RELAY-SPOILER SQUIB TEST 2	00000000 35344	1	25-65-11 / /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section YB7K00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB7M001	1	10167-2001-BT TIME DELAY-SLIDE DOOR SQUIB	00000000 08719	1	25-65-11 / /	ALL
YB7M001	2	10167-2-BT TIME DELAY-SLIDE DOOR SQUIB	00000000 08719	1	25-65-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YB7M00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB7S001		MS24524-23 SW-BACK UP ARM L	00000000 96906	1	25-65-11 / /	ALL
YB7S002		MS24524-23 SW-BACK UP FIRE L	00000000 96906	1	25-65-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YB7S00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB8++++		USEM01136 PANEL-OFF-WING ESCAPE SYS,R	00000000 81205	0	25-65-12 SCH 25/65/01	ALL

EQUIPMENT LIST

D280T132

Section YB8+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB8K001		X-D4L-015 RELAY-SLIDE DR SQUIB	00000000 35344	1	25-65-12 //	ALL
YB8K002		X-D4L-015 RELAY-SPOILER RETRACT	00000000 35344	1	25-65-12 //	ALL
YB8K003		X-D4L-015 RELAY-TEST,SLIDE DR SQUIB	00000000 35344	1	25-65-12 //	ALL
YB8K004		X-D4L-015 RELAY-TEST,SPOILER SQUIB	00000000 35344	1	25-65-12 //	ALL
YB8K005		X-D4L-015 RELAY-SLIDE DR SQUIB TEST 2	00000000 35344	1	25-65-12 //	150-199, 275-299
YB8K006		X-D4L-015 RELAY-SPOILER SQUIB TEST 2	00000000 35344	1	25-65-12 //	150-199, 275-299

EQUIPMENT LIST

D280T132

Section YB8K00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB8M001	1	10167-2001-BT TIME DELAY-SLIDE DOOR SQUIB	00000000 08719	1	25-65-12 / /	ALL
YB8M001	2	10167-2-BT TIME DELAY-SLIDE DOOR SQUIB	00000000 08719	1	25-65-12 / /	ALL

EQUIPMENT LIST

D280T132

Section YB8M00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YB8S001		MS24524-23 SW-BACK UP ARM R	00000000 96906	1	25-65-12 / /	ALL
YB8S002		MS24524-23 SW-BACK UP FIRE R	00000000 96906	1	25-65-12 / /	ALL

EQUIPMENT LIST

D280T132

Section YB8S00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBA++++		USEM00845 CONT PNL-AFT CAR. HDLG	284T0216 81205	0	25-53-21 SCH 25/53/01	ALL

EQUIPMENT LIST

D280T132

Section YBA+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBAL001		L5105-AM LIGHT-LD3 UP	284T0216 81640	1	25-53-26 //	ALL
YBAL002		L5105-AM LIGHT-LD2 UP	284T0216 81640	1	25-53-26 //	ALL
YBAL003		L5105-AM LIGHT-ALL DOWN,CTR GUIDES	284T0216 81640	1	25-53-26 //	ALL
YBAL004		L5105-AM LIGHT-PDU FWD ON	284T0216 81640	1	25-53-23 //	ALL
YBAL005		L5105-AM LIGHT-PDU AFT ON	284T0216 81640	1	25-53-23 //	ALL
YBAL006		L5105-AM LIGHT-ROLLOUT STOP DOWN	284T0216 81640	1	25-53-27 //	050-099, 150-199
YBAL007		L5105-AM LIGHT-UP,ROLLOUT STOP	00000000 81640	1	25-53-27 //	050-099, 150-199
YBAL008		L5105-G3 LIGHT-LOCK,ROLLOUT STOP	284T0216 81640	1	25-53-27 //	050-099, 150-199
YBAL01A		MS25237-387 LAMP	00000000 96906	1	25-53-26 //	ALL
YBAL02A		MS25237-387 LAMP	00000000 96906	1	25-53-26 //	ALL
YBAL03A		MS25237-387 LAMP	00000000 96906	1	25-53-26 //	ALL
YBAL04A		MS25237-387 LAMP	00000000 96906	1	25-53-23 //	ALL
YBAL05A		MS25237-387 LAMP	00000000 96906	1	25-53-23 //	ALL
YBAL06A		MS25237-387 LAMP	00000000 96906	1	25-53-27 //	050-099, 150-199
YBAL07A		MS25237-387 LAMP	00000000 96906	1	25-53-27 //	050-099, 150-199
YBAL08A		MS25237-387 LAMP	00000000 96906	1	25-53-27 //	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBAL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBAS001		2TL82-10 SW-CENTER GUIDES	284T0216 91929	1	25-53-26 / /	ALL
YBAS002		1TL82-3 SW-POWERED DRIVE UNITS	284T0216 91929	1	25-53-23 / /	ALL
YBAS003		2TL82-10 SW-ROLLOUT STOPS	284T0216 91929	1	25-53-27 / /	050-099, 150-199
YBAS004		MS24523-23 SW-SYS PWR AFT CARGO HDLG	284T0216 96906	1	25-53-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YBAS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBF++++		USEM00014 CONT PNL-TEMP	00000000 81205	0	21-61-11 SCH 21/61/01	ALL

EQUIPMENT LIST

D280T132

Section YBF+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBFL01+	1	S231T300-2238 LIGHT INDICATOR-FLT DK INOP	00000000 81205	1	21-61-11 //	ALL
YBFL01+	2	S231T300-1238 LIGHT INDICATOR-FLT DK INOP	00000000 81205	1	21-61-11 //	ALL
YBFL01+	3	S231T300-1238 LIGHT INDICATOR-FLT DK INOP	00000000 81205	1	21-61-11 //	ALL
YBFL01A		MS25237-387 LAMP-28V	00000000 96906	2	21-61-11 //	ALL
YBFL01D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-61-11 //	ALL
YBFL02+	1	S231T300-2238 LIGHT INDICATOR-FWD INOP	00000000 81205	1	21-61-11 //	ALL
YBFL02+	2	S231T300-1238 LIGHT INDICATOR-FWD INOP	00000000 81205	1	21-61-11 //	ALL
YBFL02+	3	S231T300-1238 LIGHT INDICATOR-FWD INOP	00000000 81205	1	21-61-11 //	ALL
YBFL02A		MS25237-387 LAMP-28V	00000000 96906	2	21-61-11 //	ALL
YBFL02D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-61-11 //	ALL
YBFL03+	1	S231T300-2238 LIGHT INDICATOR-AFT INOP	00000000 81205	1	21-61-11 //	ALL
YBFL03+	2	S231T300-1238 LIGHT INDICATOR-AFT INOP	00000000 81205	1	21-61-11 //	ALL
YBFL03+	3	S231T300-1238 LIGHT INDICATOR-AFT INOP	00000000 81205	1	21-61-11 //	ALL
YBFL03A		MS25237-387 LAMP-28V	00000000 96906	2	21-61-11 //	ALL
YBFL03D		851-30768-823 DIOD/FUSE ASSEMBLY	00000000 81205	1	21-61-11 //	ALL
YBFL04+	1	S231T300-2238 LIGHT INDICATOR-MID INOP	00000000 81205	1	21-61-11 //	ALL
YBFL04+	2	S231T300-1238 LIGHT INDICATOR-MID INOP	00000000 81205	1	21-61-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBFL00

Page 1

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBFL04+	3	S231T300-1238 LIGHT INDICATOR-MID INOP	00000000 81205	1	21-61-11 / /	ALL
YBFL04A		MS25237-387 LAMP-28V	00000000 96906	2	21-61-11 / /	ALL
YBFL04D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-61-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YBFL00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBFN01+		S231T240-3 IND-FLT DECK TRIM VALVE POSITION	00000000 81205	1	21-61-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YBFN00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBFR002		RJR12FL102M POTENTIOMENT-1K	00000000 96906	1	21-61-11 / /	ALL
YBFR003		RJR12FL503M POTENTIOMETER-50K	00000000 96906	1	21-61-11 / /	ALL
YBFR004		RNC60H1002FS RESISTOR-10K	00000000 96906	1	21-61-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YBFR00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBFS01+		S231T290-4024 SWITCH INDICATOR-TRIM AIR	00000000 81205	1	21-61-11 //	150-199, 275-299
YBFS01+	1	S231T290-4024 SWITCH INDICATOR-TRIM AIR	00000000 81205	1	21-61-11 //	050-099
YBFS01+	2	S231T290-5024 SWITCH INDICATOR-TRIM AIR	00000000 81205	1	21-61-11 //	050-099
YBFS01A		MS24515-685AS15 LAMP-5VAC	00000000 96906	1	21-61-11 //	ALL
YBFS01B		MS25237-387 LAMP-28VDC	00000000 96906	2	21-61-11 //	ALL
YBFS01D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	21-61-11 //	ALL
YBFS02+		S231T290-4016 SWITCH INDICATOR-L RECIRC FAN	00000000 81205	1	21-61-11 //	150-199, 275-299
YBFS02+	1	S231T290-4016 SWITCH INDICATOR-L RECIRC FAN	00000000 81205	1	21-61-11 //	050-099
YBFS02+	2	S231T290-5016 SWITCH INDICATOR-L RECIRC FAN	00000000 81205	1	21-61-11 //	050-099
YBFS02A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	21-61-11 //	ALL
YBFS02B		MS25237-387 LAMP-28VDC	00000000 96906	2	21-61-11 //	ALL
YBFS02D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	21-61-11 //	ALL
YBFS03+		S231T290-4016 SWITCH INDICATOR-R RECIRC FAN	00000000 81205	1	21-61-11 //	150-199, 275-299
YBFS03+	1	S231T290-4016 SWITCH INDICATOR-R RECIRC FAN	00000000 81205	1	21-61-11 //	050-099
YBFS03+	2	S231T290-5016 SWITCH INDICATOR-R RECIRC FAN	00000000 81205	1	21-61-11 //	050-099
YBFS03A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	21-61-11 //	ALL
YBFS03B		MS25237-387 LAMP-28VDC	00000000 96906	2	21-61-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBFS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBFS03D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	21-61-11 //	ALL
YBFS04+		AC45-0022-1 SWITCH-MODE SEL,L PACK	00000000 81205	1	21-61-11 //	ALL
YBFS05+		S231T290-4056 SWITCH INDICATOR-L PACK RESET	00000000 81205	1	21-61-11 //	150-199, 275-299
YBFS05+	1	S231T290-4056 SWITCH INDICATOR-L PACK RESET	00000000 81205	1	21-61-11 //	050-099
YBFS05+	2	S231T290-5056 SWITCH INDICATOR-L PACK RESET	00000000 81205	1	21-61-11 //	050-099
YBFS05A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	21-61-11 //	ALL
YBFS05B		MS25237-387 LAMP-28V	00000000 96906	2	21-61-11 //	ALL
YBFS05D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-61-11 //	ALL
YBFS06+		S231T290-4056 SWITCH INDICATOR-R PACK RESET	00000000 81205	1	21-61-11 //	150-199, 275-299
YBFS06+	1	S231T290-4056 SWITCH INDICATOR-R PACK RESET	00000000 81205	1	21-61-11 //	050-099
YBFS06+	2	S231T290-5056 SWITCH INDICATOR-R PACK RESET	00000000 81205	1	21-61-11 //	050-099
YBFS06A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	21-61-11 //	ALL
YBFS06B		MS25237-387 LAMP-28V	00000000 96906	2	21-61-11 //	ALL
YBFS07+		AC45-0022-1 SWITCH-MODE SEL,R PACK	00000000 81205	1	21-61-11 //	ALL
YBFS08+	1	S231T290-4024 SWITCH INDICATOR-GASPER FAN	00000000 81205	1	21-61-11 //	150-199
YBFS08+	2	S231T290-5024 SWITCH INDICATOR-GASPER FAN	00000000 81205	1	21-61-11 //	150-199
YBFS08A		MS24515-68AS15 LAMP-5VAC	00000000 96906	2	21-61-11 //	150-199

EQUIPMENT LIST

D280T132

Section YBFS00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBFS08B		MS24237-387 LAMP-28V	00000000 96906	2	21-61-11 / /	150-199
YBFS08D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	21-61-11 / /	150-199

EQUIPMENT LIST

D280T132

Section YBFS00
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBG++++		USEM00937 MDL-LANDING GEAR LEVER	00000000 81205	0	32-31-11 SCH 32/31/01	ALL

EQUIPMENT LIST

D280T132

Section YBG+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBGCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	280-299

EQUIPMENT LIST

D280T132

Section YBGC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBGM001		60B80061-7 SOLENOID-LANDING GEAR LEVER	00000000 81205	1	32-31-11 / /	050-099, 155-199, 275-299
YBGM001		60B80061-6 SOLENOID-LANDING GEAR LEVER	00000000 81205	1	32-31-11 / /	150-154

EQUIPMENT LIST

D280T132

Section YBGM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBH++++		USEP021-00 PNL-FORWARD ATTENDANT	00000000 81205	0	33-22-11 SCH 33/22/01	ALL

EQUIPMENT LIST

D280T132

Section YBH+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBHK001		BACR13CF2A RELAY-ENTRY LT	00000000 81205	1	33-22-11 / /	ALL
YBHK002		BACR13CF2A RELAY-ENTRY LT	00000000 81205	1	33-22-11 / /	ALL
YBHK004		BACR13CJ2 RELAY-PASS. CAB. LTS	00000000 81205	1	33-21-11 / /	050-099

EQUIPMENT LIST

D280T132

Section YBHK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBHS007		44-MY-232320 SW-PASSENGER LIGHTS	00000000 60525	1	33-21-11 //	ALL
YBHS013		2100-6 SW-ENTRY DR UP,FWD	00000000 81205	1	52-11-12 //	ALL
YBHS018		2100-6 SW-ENTRY DR DN,FWD	00000000 81205	1	52-11-12 //	ALL
YBHS01+		2100-13 SW-LIGHTS,EMERGENCY	00000000 91929	1	33-51-11 //	ALL
YBHS01A		85 LAMP	00000000 08806	1	33-51-11 //	ALL
YBHS027		2400-1 SW-BUS,GROUND SERVICE	00000000 81205	1	24-51-51 //	ALL
YBHS027A		85 LAMP	00000000 81205	1	24-51-51 //	ALL
YBHS032		44-YY26087 SWITCH-GALLEY LIGHT	00000000 60525	1	33-27-11 P021-00/	050-099, 150-199
YBHS03+		2100-3 SW-LEFT ENTRY CEILING LIGHT	00000000 91929	1	33-22-11 //	ALL
YBHS03A		85 LAMP-LEFT ENTRY CEILING LIGHT SW	00000000 08806	1	33-22-11 //	ALL
YBHS04+		2100-3 SW-ATTEND. LT,CENTER	00000000 91929	1	33-22-31 //	275-299
YBHS04A		85 LAMP	00000000 08806	1	33-22-31 //	275-299
YBHS05+		2100-3 SW-ATTEND. LT,LEFT	00000000 91929	1	33-22-31 //	ALL
YBHS05A		85 LAMP	00000000 08806	1	33-22-31 //	ALL
YBHS25+		2100-3 SW-LEFT,ENTRY LT	00000000 91929	1	33-22-11 //	ALL
YBHS25A		85 LAMP-LEFT ENTRY LT SW	00000000 08806	1	33-22-11 //	ALL
YBHS28+		2400-3 SW-EMERGENCY LIGHT TEST	00000000 91929	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBHS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBHS28A		85 LAMP	00000000 08806	2	33-51-11 / /	ALL
YBHS30+		2100-3 SW-RIGHT,ENTRY LT	00000000 91929	1	33-22-11 / /	ALL
YBHS30A		85 LAMP-RIGHT ENTRY LT SW	00000000 08806	1	33-22-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YBHS00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBI++++		USEP022-00 PNL-AFT ATTENDANT	00000000 81205	0	33-22-11 SCH 33/22/01	ALL

EQUIPMENT LIST

D280T132

Section YBI+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBIK001		BACR13CF2A RELAY-ENTRY LT	00000000 81205	1	33-22-11 //	ALL
YBIK002		BACR13CF2A RELAY-ENTRY LT	00000000 81205	1	33-22-11 //	ALL
YBIK004	9	XL-D4N-009 RLY-SNSR OFF,AFT TANK PRRB11888	00000000 81205	1	38-32-11 //	150-154, 275-276
YBIK004		XL-D4N-009 RLY-SNSR OFF,AFT TANK	00000000 35344	1	38-32-11 //	155, 162-165
YBIK005	9	XL-D4N-009 RLY-SNSR OFF,FWD TANK PRRB11888	00000000 81205	1	38-32-11 //	150-154, 275-276
YBIK005		XL-D4N-009 RLY-SNSR OFF,FWD TANK	00000000 35344	1	38-32-11 //	155, 162-165
YBIK006	9	BACR13CF2AB RLY-FWD TANK PRCH CONT (SB38-0035)	00000000 81205	1	38-32-11 //	275-276
YBIK006		BACR13CF2AB RELAY-FWD TANK PRECHARGE CONTROL	00000000 81205	1	38-32-11 //	156-157, 166-199, 277-299
YBIK007	9	BACR13CF2AB RLY-AFT TANK PRCH CONT (SB 38-0035)	00000000 81205	1	38-32-11 //	275-276
YBIK007		BACR13CF2AB RELAY-AFT TANK PRECHARGE CONTROL	00000000 81205	1	38-32-11 //	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section YBIK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBIN001		S417T600-4 GAGE-WATER QUANTITY	00000000 81205	1	38-14-11 //	ALL
YBIN003	9	S417T600-5 WASTE LEVEL INDICATOR (SB38-0035)	00000000 81205	1	38-32-11 //	275-276
YBIN003		S417T600-5 WASTE LEVEL INDICATOR	00000000 81205	1	38-32-11 //	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section YBIN00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBIS007		44-MY-232320 SW-PASSENGER LIGHTS	00000000 60525	1	33-21-12 / /	ALL
YBIS008		44-YY26087 SWITCH-GALLEY LIGHT	00000000 60525	1	33-27-11 P022-00/ /	050-099, 150-199
YBIS03+		2100-3 SW-ATTEND. LT,CENTER	00000000 91929	1	33-22-31 / /	150-199
YBIS03A		85 LAMP	00000000 08806	1	33-22-31 / /	150-199
YBIS04+		2100-3 SW-ATTEND. LT,RIGHT	00000000 91929	1	33-22-31 / /	050-099, 275-299
YBIS04A		85 LAMP	00000000 08806	1	33-22-31 / /	050-099, 275-299
YBIS05+		2100-3 SW-AFT ATTENDANT WORK LIGHT,L	411T3127 91929	1	33-22-31 1494/280/L027	150-199
YBIS05A		85 LAMP	00000000 08806	1	33-22-31 / /	150-199
YBIS14+	9	2100-1 SW-FWD TANK/SENSOR FOUL	00000000 81205	1	38-32-11 / /	150-154
YBIS14+	9	2100-1 SW-FWD TANK/SENSOR FOUL (SB 38-0035)	00000000 81205	1	38-32-11 / /	275
YBIS14+		2100-1 SW-FWD TANK/SENSOR FOUL	00000000 81205	1	38-32-11 / /	050-099, 155-199, 276-299
YBIS14A	9	85 LAMP-SENSOR FOUL FWD TANK	00000000 08806	1	38-32-11 / /	150-154
YBIS14A	9	85 LAMP-SENSOR FOUL FWD TANK (SB 38-0035)	00000000 08806	1	38-32-11 / /	275
YBIS14A		85 LAMP-SENSOR FOUL FWD TANK	00000000 08806	1	38-32-11 / /	050-099, 155-199, 276-299
YBIS15+	9	2100-1 SW-AFT TANK/SENSOR FOUL	00000000 81205	1	38-32-11 / /	150-154
YBIS15+	9	2100-1 SW-AFT TANK/SENSOR FOUL (SB 38-0035)	00000000 81205	1	38-32-11 / /	275
YBIS15+		2100-1 SW-AFT TANK/SENSOR FOUL	00000000 81205	1	38-32-11 / /	050-099, 155-199, 276-299

EQUIPMENT LIST

D280T132

Section YBIS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBIS15A	9	85 LAMP-SENSOR AFT TANK	00000000 08806	1	38-32-11 //	150-154
YBIS15A	9	85 LAMP-SENSOR AFT TANK (SB 38-0035)	00000000 08806	1	38-32-11 //	275
YBIS15A		85 LAMP-SENSOR AFT TANK	00000000 08806	1	38-32-11 //	050-099, 155-199, 276-299
YBIS16+		2100-1 SW-INOP,CHECK LAV	00000000 81205	1	38-32-11 //	ALL
YBIS16A		85 LAMP-CK LAV INOP SW	00000000 08806	1	38-32-11 //	ALL
YBIS17+		2100-1 SW-INOP,CHECK LAV	00000000 81205	1	38-32-11 //	ALL
YBIS17A		85 LAMP-CK LAV INOP SW	00000000 08806	1	38-32-11 //	ALL
YBIS21+	9	2100-1 SW-SNSR OFF,FWD TANK PRRB11888	00000000 91929	1	38-32-11 //	150-154
YBIS21+	9	2100-2 SW-W TANK LEVEL IND,FWD TANK(SB38-0035)	00000000 81205	1	38-32-11 //	275-276
YBIS21+		2100-13 SW-SNSR OFF,FWD TANK	00000000 81205	1	38-32-11 //	050-099, 155, 162- 165
YBIS21+		2100-2 SW-WASTE TANK LEVEL IND,FWD TANK	00000000 81205	1	38-32-11 //	156-157, 166-199, 277-299
YBIS21A	9	85 LAMP PRRB11888	00000000 08806	1	38-32-11 //	150-154
YBIS21A	9	85 LAMP (SB 38-0035)	00000000 08806	1	38-32-11 //	275-276
YBIS21A		85 LAMP	00000000 08806	1	38-32-11 //	050-099, 155-199, 277-299
YBIS22+	9	2100-1 SW-SNSR OFF,AFT TANK PRRB11888	00000000 91929	1	38-32-11 //	150-154
YBIS22+	9	2100-2 SW-W TANK LEVEL IND,AFT TANK(SB38-0035)	00000000 91929	1	38-32-11 //	275-276
YBIS22+		2100-13 SW-SNSR OFF,AFT TANK	00000000 81205	1	38-32-11 //	050-099, 155, 162- 165

EQUIPMENT LIST

D280T132

Section YBIS00

Page 2

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBIS22+		2100-2 SW-WASTE TANK LEVEL IND,AFT TANK	00000000 81205	1	38-32-11 //	156-157, 166-199, 277-299
YBIS22A	9	85 LAMP PRRB11888	00000000 08806	1	38-32-11 //	150-154
YBIS22A	9	85 LAMP (SB 38-0035)	00000000 08806	1	38-32-11 //	275-276
YBIS22A		85 LAMP	00000000 08806	1	38-32-11 //	050-099, 155-199, 277-299
YBIS25+		2100-3 SW-LEFT,ENTRY LT	00000000 91929	1	33-22-11 //	ALL
YBIS25A		85 LAMP-LEFT ENTRY LT SW	00000000 08806	1	33-22-11 //	ALL
YBIS28+		2400-3 SW-EMERGENCY LIGHT TEST	00000000 91929	1	33-51-11 //	ALL
YBIS28A		85 LAMP	00000000 08806	2	33-51-11 //	ALL
YBIS30+		2100-3 SW-RIGHT,ENTRY LT	00000000 91929	1	33-22-11 //	ALL
YBIS30A		85 LAMP-RIGHT ENTRY LT SW	00000000 08806	1	33-22-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBIS00

Page 3 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBM++++		USEM00967 AUXILIARY POWER UNIT	00000000 81205	0	49-14-11 SCH 49/14/01	ALL

EQUIPMENT LIST

D280T132

Section YBM+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMM001		3888058-1 UNIT-IGNITION	00000000 99193	1	49-14-11 //	ALL
YBMM002		3882550-1 VALVE ASSY-FUEL FLOW DIVIDER SOLENOID	00000000 99193	1	49-14-11 //	150-199, 275-299
YBMM002	1	3882550-2 VALVE ASSY-FUEL FLOW DIVIDER SOLENOID	00000000 99193	1	49-14-11 //	050-099
YBMM002	2	3882550-1 VALVE ASSY-FUEL FLOW DIVIDER SOLENOID	00000000 99193	1	49-14-11 //	050-099
YBMM003	1	3876047-4 SOLENOID-DE-OILING	00000000 99193	1	49-14-11 //	ALL
YBMM003	2	3876047-2 SOLENOID-DE-OILING	00000000 99193	1	49-14-11 //	ALL
YBMM004	1	3882500-9 FUEL CONTL ASSY-FUEL CONTL TORQUE MOTOR	00000000 99193	1	49-14-11 //	ALL
YBMM004	2	3882500-8 FUEL CONTL ASSY-FUEL CONTL TORQUE MOTOR	00000000 99193	1	49-14-11 //	ALL
YBMM004	3	3882500-6 FUEL CONTL ASSY-FUEL CONTL TORQUE MOTOR	00000000 99193	1	49-14-11 //	ALL
YBMM004	4	3882500-5 FUEL CONTL ASSY-FUEL CONTL TORQUE MOTOR	00000000 99193	1	49-14-11 //	ALL
YBMM005	1	979806-8 SURGE CONTROL VALVE-TORQUE MOTOR	00000000 99193	1	49-14-11 //	ALL
YBMM005	2	979806-7 SURGE CONTROL VALVE-TORQUE MOTOR	00000000 99193	1	49-14-11 //	ALL
YBMM005	3	979806-6 SURGE CONTROL VALVE-TORQUE MOTOR	00000000 99193	1	49-14-11 //	ALL
YBMM005	4	979806-5 SURGE CONTROL VALVE-TORQUE MOTOR	00000000 99193	1	49-14-11 //	ALL
YBMM006		3790076-103 IGV ACTR	00000000 99193	1	49-14-11 //	ALL
YBMM007		369949-3 IGNITER	00000000 99193	1	49-14-11 //	ALL
YBMM008		3614400-1 MODULE-APU SURGE SYSTEM	351T0300 99193	1	49-14-11 //	157, 167-199, 277-299

EQUIPMENT LIST

D280T132

Section YBMM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMP0015	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP004	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP004	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP005	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP005	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP006	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP006	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP007		FRF6E12S3S01 CONNECTOR	00000000 06324	1	49-14-11 //	ALL
YBMP009	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP009	2	CN0966-12A03S6-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP011	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP011	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP012	1	ZZYAO-12D14-07S06 CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP012	2	CN0966-14A07S6-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP013	1	ZZYAO-12D14-07S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP013	2	CN0966-14A07SN-000 CONNECTOR	00000000 13445	1	49-14-11 //	ALL
YBMP014	1	ZZYAO-12D14-07S CONNECTOR	00000000 49367	1	49-14-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBMP00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMP014	2	CN0966-14A07SN-000 CONNECTOR	00000000 13445	1	49-14-11 //	ALL
YBMP015	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP015	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP016	1	ZZYAO-12D14-07S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP016	2	CN0966-14A07SN-000 CONNECTOR	00000000 13445	1	49-14-11 //	ALL
YBMP017	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP017	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP018	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP018	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP019	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP019	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP020	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP020	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL
YBMP021		306111-13 CONNECTOR	00000000 ENDOR	1	49-14-11 //	ALL
YBMP025	1	ZZYAO-12D12-03S CONNECTOR	00000000 49367	1	49-14-11 //	ALL
YBMP025	2	CN0966-12A03SN-000 CONNECTOR	00000000 13556	1	49-14-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBMP00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMS001		3876048-2 SW-GENERATOR OIL FILTER DIFF PRESS.	00000000 99193	1	49-14-11 //	ALL
YBMS002		3876024-2 SW-LOW OIL PRESSURE	00000000 99193	1	49-14-11 //	ALL
YBMS003		S351N101-1 SNSR-OIL LEVEL	351T0100 81205	1	49-94-14 //	ALL
YBMS004		397728-4-1 FAN ISOLATION VALVE-FAN VALVE POS SW	00000000 99193	1	49-14-11 //	ALL
YBMS005		3876023-2 SW-OIL TEMP	00000000 99193	1	49-14-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBMS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMTS01		MS28034-3 SNSR-OIL TEMP	00000000 99193	1	49-14-11 //	ALL
YBMTS02		3876084-1 SNSR-DRIVEN COMP PT DISCHARGE	00000000 99193	1	49-14-11 //	ALL
YBMTS03	1	3876085-2 SNSR-DRIVEN COMP DIFF PRESS	00000000 99193	1	49-14-11 //	ALL
YBMTS03	2	3876085-1 SNSR-DRIVEN COMP DIFF PRESS	00000000 99193	1	49-14-11 //	ALL
YBMTS04		3876035-4 SNSR-COMPRESSOR INLET PRESSURE	00000000 99193	1	49-14-11 //	ALL
YBMTS05	1	3876072-2 SNSR-COMP INLET TEMP	00000000 99193	1	49-14-11 //	ALL
YBMTS05	2	3876072-1 SNSR-COMP INLET TEMP	00000000 99193	1	49-14-11 //	ALL
YBMTS06		3876027-3 SNSR-THERMOCOUPLE ASSEMBLY NO.1	00000000 99193	1	49-14-11 //	ALL
YBMTS07		3876027-3 SNSR-THERMOCOUPLE ASSEMBLY NO.2	00000000 99193	1	49-14-11 //	ALL
YBMTS08	1	3876026-3 SNSR-MONOPOLE NO.1	00000000 99193	1	49-14-11 //	ALL
YBMTS08	2	3876026-2 SNSR-MONOPOLE NO.1	00000000 99193	1	49-14-11 //	ALL
YBMTS09	1	3876026-3 SNSR-MONOPOLE NO.2	00000000 99193	1	49-14-11 //	ALL
YBMTS09	2	3876026-2 SNSR-MONOPOLE NO.2	00000000 99193	1	49-14-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBMT

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBMV001	1	3876049-4 VALVE-FUEL SOLENOID	00000000 99193	1	49-14-11 //	ALL
YBMV001	2	3876049-3 VALVE-FUEL SOLENOID	00000000 99193	1	49-14-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBMV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBN++++		USEM00985 ASSY-THRUST LEVER	00000000 81205	0	22-12-11 SCH 22/12/01	ALL

EQUIPMENT LIST

D280T132

Section YBN+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBNS001		MS24547-1 SW-GO AROUND-LEFT NO.1 (S1)	253T5800 96906	1	22-12-11 P010-00/ /	ALL
YBNS002		MS24547-1 SW-GO AROUND-LEFT NO.2 (S2)	253T5800 96906	1	22-12-11 P010-00/ /	ALL
YBNS003		C2006 SW-A/T DISENGAGE-LEFT (S3)	253T5800 78048	1	22-12-11 P010-00/ /	ALL
YBNS004		C2006 SW-A/T DISENGAGE-RIGHT (S4)	253T5800 78048	1	22-12-11 P010-00/ /	ALL
YBNS005		MS24547-1 SW-L T/R CONT	00000000 96906	1	78-34-11 / /	ALL
YBNS006		MS24547-1 SW-R T/R CONT	00000000 96906	1	78-34-21 / /	ALL
YBNS007		MS24547-1 SW-GO AROUND-RIGHT NO.1(S7)	253T5800 96906	1	22-12-21 P010-00/ /	ALL
YBNS008		MS24547-1 SW-GO AROUND-RIGHT NO.2 (S8)	253T5800 96906	1	22-12-21 P010-00/ /	ALL
YBNS009		MS24547-1 SW-GO AROUND-CENTER NO.1 (S9)	253T5800 96906	1	22-12-31 P010-00/ /	ALL
YBNS010		MS24547-1 SW-GO AROUND-CENTER NO.2 (S10)	253T5800 96906	1	22-12-31 P010-00/ /	ALL

EQUIPMENT LIST

D280T132

Section YBNS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBO++++		USEM01177 FORWARD GALLEY F1	10150F11 BFE	0	25-31-01 0354/ /	050-099, 150-199
YBO++++		USEM01177 FORWARD GALLEY	7ZG7620M BFE	0	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBO+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOB001		20420L-3-8 GALLEY WATER LINE THERMOSTAT	00000000 TBD	1	30-71-25 / /	050-099, 150-199
YBOB002		110-6-30 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBOB00
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOC001		BACC18AC15 CB-AIR CHILLER	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YBOC001		BACC18AE15 CB-OVEN NO.1 POWER	00000000 81205	1	25-31-01 0354/ /	275-278
YBOC002		BACC18AC15 CB-OVEN NO.1	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YBOC002		BACC18Z1R CB-OVEN NO 1 CONTROL	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC003		BACC18AC15 CB-OVEN NO.2	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YBOC003		BACC18AE15 CB-OVEN NO 2 POWER	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC004		BACC18Z7R CB-OUTLET	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YBOC004		BACC18Z1R CB-OVEN NO 2 CONTROL	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOC005		BACC18Z2R CB-DC CONT	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YBOC005		BACC18AE15 CB-OVEN NO 3 POWER	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOC006		BACC18Z2R CB-WORKLIGHT	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YBOC006		BACC18Z1R CB-OVEN NO 3 CONTROL	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOC007		BACC18AE15 CB-OVEN NO 4 POWER	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOC008		BACC18Z1R CB-OVEN NO 4 CONTROL	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOC009		BACC18AE15 CB-OVEN NO 5 POWER	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC010		BACC18Z1R CB-OVEN NO 5 CONTROL	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC011		BACC18AE15 CB-AIR CHILLER POWER	7ZG7620M 81205	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOC00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOC012		BACC18Z2R CB-AIR CHILLER CONTROL	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC013		BACC18AC10 CB-COFFEEMAKER 1 POWER	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC014		BACC18Z1R CB-COFFEEMAKER 1 CONTROL	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC015		BACC18AC10 CB-COFFEEMAKER 2 POWER	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC016		BACC18Z1R CB-COFFEEMAKER 2 CONTROL	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC017		BACC18Z2R CB-HOT JUG NO. 2	10140F11 81205	1	25-31-01 0280/ /	275-278
YBOC018		BACC18Z1R CB-WATER BOILER CONTROL	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC019		BACC18AC05 CB-TRASH COMPACTOR	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC020		BACC18Z2R CB-FC GALLEY AC POWER	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC021		BACC18Z7R CB-HOT CUP	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC022		BACC18Z1R CB-COUNTER LIGHT	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC023		BACC18Z1R CB-F2 SPOT LIGHT	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOC024		BACC18Z1R CB-F1 SPOT LIGHT	7ZG7620M 81205	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOC00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOD001P		BACC63CE24A22P PLUG-INTERFACE (AC)	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YBOD001P		BACC63CE32A17P PLUG-AC INTERFACE	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOD002P		BACC45FS12-12P PLUG-INTERFACE (DC)	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YBOD002P		BACC4FT12C12P PLUG-DC INTERFACE	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOD004P		MS24266R16B10SN PLUG-INTERFACE TO CHILLER	10150F11 89709	1	25-31-01 0354/ /	050-099, 150-199
YBOD005P		MS24266R20B25SN PLUG-OVEN 1	10150F11 89709	1	25-31-01 0354/ /	050-099, 150-199
YBOD006P		MS24266R20B25SN PLUG-OVEN 2	10150F11 89709	1	25-31-01 0354/ /	050-099, 150-199
YBOD007P		MS24266R10B5S PLUG-WORK LIGHT	10150F11 89709	1	25-31-01 0354/ /	050-099, 150-199
YBOD008P		BACC63CE10C5P PLUG-CURRENT XFMR	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOD009J		BACF15S RECEPTACLE-OVEN 1 CONTROL MODULE	10150F11 71468	1	25-31-01 0354/ /	050-099, 150-199
YBOD009P		BACC45FT10C5S PLUG-FC INTERFACE	7ZG7620M 81205	1	25-31-01 / /	275-278
YBOD010J		BACF15S RECEPTACLE-OVEN 2 CONTROL MODULE	10150F11 71468	1	25-31-01 0354/ /	050-099, 150-199
YBOD011J		7582-G RECEPTACLE-OUTLET	10150F11 83315	1	25-31-01 0354/ /	050-099, 150-199
YBOD012P		MS24266R20B25S PLUG-OVEN NO 1	7ZG7620M 96906	1	25-31-01 / /	275-278
YBOD013P		MS24266R20B25S PLUG-OVEN NO 2	7ZG7620M 96906	1	25-31-01 / /	275-278
YBOD014P		MS24266R20B25S PLUG-OVEN NO 3	7ZG7620M 96906	1	25-31-01 / /	275-278
YBOD015P		MS24266R20B25S PLUG-OVEN NO 4	7ZG7620M 96906	1	25-31-01 / /	275-278

EQUIPMENT LIST

D280T132

Section YBOD00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOD016P		MS24266R20B25S PLUG-OVEN NO 5	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD017P		MS3126F18-11S PLUG-OVEN CONTROL NO 1	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD018P		MS3126F22-21P PLUG-OVEN CONTROL NO 1	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD019P		MS3126F18-11S PLUG-OVEN CONTROL NO 2	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD020P		MS312F22-21P PLUG-OVEN CONTROL NO 2	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD021P		MS3126F18-11S PLUG-OVEN CONTROL NO 3	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD022P		MS3126F22-21P PLUG-OVEN CONTROL NO 3	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD023P		MS3126F18-11S PLUG-OVEN CONTROL NO 4	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD024P		MS3126F22-21P PLUG-OVEN CONTROL NO 4	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD025P		MS3126F18-11S PLUG-OVEN CONTROL NO 5	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD026P		MS3126F22-21P PLUG-OVEN CONTROL NO 5	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD027P		BACC45FT16C10S PLUG-INTERFACE TO AIR CHILLER	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOD030P		MS24266R16B10S PLUG-COFFEEMAKER NO 1	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD031P		MS24266R16B10S PLUG-COFFEEMAKER NO 2	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD032P		MS24266R16B10S PLUG-WATERBOILER	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD033P		MS24266R14B7S PLUG-TRASH COMPACTOR	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOD034J		16707 RECEPTACLE-HOT CUP	7ZG7620M 71468	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOD00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOK001		MS27222-2 RELAY	10150F11 35344	1	25-31-01 0354/ /	050-099, 150-199
YBOK001		MS27401-24 RELAY-AIR CHILLER	7ZG7620M 96906	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOL001		LH74-1 LAMP-GALLEY POWER ON	7ZG7620M 72619	1	25-31-01 0354/ /	275-278
YBOL002		LH73-1 LAMP-AIR CHILLER OV/HT	7ZG7620M 72619	1	25-31-01 0354/ /	275-278
YBOL003		LH73-1 LAMP-AIR CHILLER ON	7ZG7620M 72619	1	25-31-01 0354/ /	275-278
YBOL004		14-32280-8P6 FEEDER ENERGIZED (LAMP:0LN115-18K)	10150F11 29207	1	25-31-01 0354/ /	050-099, 150-199
YBOL004		LH74-1 LAMP-HOT CUP	7ZG7620M 72619	1	25-31-01 0354/ /	275-278
YBOL005		BR9172-503 WORK LIGHT	10150F11 15086	1	25-31-01 0354/ /	050-099, 150-199
YBOL005		7YE3200A01G02 LAMP-COUNTER	7ZG7620M JAMCO	1	25-31-01 0354/ /	275-278
YBOL006		34265-14 LAMPL-F2 SPOT	7ZG7620M 63367	1	25-31-01 0354/ /	275-278
YBOL007		34265-14 LAMP-F1 SPOT	7ZG7620M 63367	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOM001		72068000 OVENS-1 AND 2	10150F11 SELL	2	25-31-01 0354/ /	050-099, 150-199
YBOM001		DF400 OVEN 1, 2, 3, 4, 5	7ZG7620M JAMCO	5	25-31-01 0354/ /	275-278
YBOM002		DA57-2B COFFEEMAKER 1 AND 2	7ZG7620M JAMCO	2	25-31-01 0354/ /	275-278
YBOM004		DR6-28 WATER BOILER	7ZG7620M JAMCO	1	25-31-01 0354/ /	275-278
YBOM005		DLH581-005 HOT CUP	7ZG7620M JAMCO	1	25-31-01 0354/ /	275-278
YBOM009		3200 TRASH COMPACTOR	7ZG7620M JAMCO	1	25-31-01 0354/ /	275-278
YBOM011		72038000 OVEN CONTROL MODULE (OVENS 1,2)	10150F11 SELL	2	25-31-01 0354/ /	050-099, 150-199
YBOM011		7110-35-0000 OVEN CONTROL UNIT 1, 2, 3, 4,5	7ZG7620M SELL	5	25-31-01 0354/ /	275-278
YBOM020		03344-106 BALLAST	10150F11 15086	1	25-31-01 0354/ /	050-099, 150-199
YBOM021		60B40025-37 BALLAST-COUNTER LIGHT (M002)	7ZG7620M 81205	1	25-31-01 0354/ /	275-278
YBOM022		74404 TIMER-HOT CUP (M001)	7ZG7620M JAMCO	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOP001		2-F-225-0017-00000 ELECTRICAL CONTROL PANEL	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199
YBOP001		BFEPANEL ELECTRICAL CONTROL UNIT	7ZG7620M JAMCO	1	25-31-01 0354/ /	275-278
YBOP002		BFEPANEL SWITCH PANEL	7ZG7620M JAMCO	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOP00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOS001		10HA1C4F3N11R1 SW-AIR CHILLER	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199
YBOS001		MS24523-22 SW-AIR CHILLER	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOS002		10HA1C1F3N1R1 SW-OUTLET	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199
YBOS002		MS24523-22 SW-COUNTER LIGHT	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOS003		3448-1 SW-WORK LIGHT	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199
YBOS003		MS24523-22 SW-F2 SPOT	7ZG7620M 96906	1	25-31-01 0354/ /	275-278
YBOS004		MS24523-22 SW-F1 SPOT	7ZG7620M 96906	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBOT001		60B00010-5 CURRENT TRANSFORMER	7ZG7620M 81205	1	25-31-01 0354/ /	275-278

EQUIPMENT LIST

D280T132

Section YBOT00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBP++++		USEM01179 R AFT GALLEY	10150F31 BFE	0	25-31-02 1540/ /	050-099, 150-199
YBP++++		GALLEY-BFE RIGHT AFT GALLEY (M1179)	7ZG7660 JAMCO	0	25-31-03 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBP+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPB001		20420L-3-8 GALLEY WATER LINE THERMOSTAT	00000000 TBD	1	30-71-25 / /	050-099, 150-199
YBPB002		110-6-21 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199
YBPB003		110-6-21 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199
YBPB004		110-11-2-67 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPB00
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPC001		BACC18AE25 CB-UNIT 7 LH	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC001		BACC18AE10 CB-COFFEEMAKER NO 1 POWER	7ZG7660 81205	1	25-31-03 1540/ /	275-278
YBPC002		BACC18AC15 CB-AIR CHILLER	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC002		BACC18Z1R CB-COFFEEMAKER NO 1 CONTROL	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC003		BACC18AC10 CB-BOILER	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC003		BACC18AE10 CB-COFFEEMAKER NO 2 POWER	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC004		BACC18AC10 CB-COFFEE MAKER	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC004		BACC18Z1R CB-COFFEEMAKER NO 2 CONTROL	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC005		BACC18Z7R CB-HOT CUP	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC005		BACC18AE15 CB-WATER BOILER POWER	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC006		BACC18Z7R CB-HOT JUG NO.1	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC006		BACC18AZ1R CB-WATER BOILER CONTROL	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC007		BACC18Z7R CB-HOT JUG NO.1	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC007		BACC18AC5 CB-TRASH COMPACTOR	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC008		BACC18Z7R CB-WATER HEATER	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC008		BACC18AE15 CB-AIR CHILLER POWER	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC009		BACC18Z2R CB-DC CONTROL-CHILLER	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPC00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPC009		BACC18Z2R CB-AIR CHILLER CONTROL	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC010		BACC18Z2R CB-WORK LIGHT	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC010		BACC18Z7R CB-HOT CUP	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPC011		BACC18Z1R CB-DC CONTROL-BOILER	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC012		BACC18Z1R CB-DC CONTROL-COFFEE MAKER	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPC030		BACC18AC15 CB-OVEN NO.1	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBPC031		BACC18AC15 CB-OVEN NO.2	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBPC032		BACC18Z-2R CB-WORK LIGHT	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPC00
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPD001P		MS24266R16B10SN PLUG-INTERFACE TO CHILLER	10150F31 89709	1	25-31-02 1540/ /	050-099, 150-199
YBPD001P		BACC63CE32A17P PLUG-AC INTERFACE	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPD002J		BACC63CD24-22S RECEPTACLE-INTERFACE UNIT 7	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPD002P		BACC45FT12C12P PLUG-DC INTERFACE	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPD003P		BACC63CE32-17P PLUG-INTERFACE (AC)	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPD004P		BACC45FS12-12P PLUG-INTERFACE (DC)	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPD006P		BACC63BN10-5P PLUG-CURRENT TRANSFORMER	10150F31 81205	1	25-31-02 1540/ /	050-099, 150-199
YBPD007J		CA16707 RECEPTACLE-HOT JUG 1	10150F31 71468	1	25-31-02 1540/ /	050-099, 150-199
YBPD008J		CA16707 RECEPTACLE-HOT JUG 2	10150F31 71468	1	25-31-02 1540/ /	050-099, 150-199
YBPD008P		MS24266R16B10S PLUG-COFFEEMAKER NO 1	7ZG7660M 96906	1	25-31-03 1540/ /	275-278
YBPD009J		FDBA50-8-98SN RECEPTACLE-WATER HEATER	10150F31 11139	1	25-31-02 1540/ /	050-099, 150-199
YBPD009P		MS24266R16B10S PLUG-COFFEEMAKER NO 2	7ZG7660M 96906	1	25-31-03 1540/ /	275-278
YBPD010J		CA16707 RECEPTACLE-HOT CUP	10150F31 71468	1	25-31-02 1540/ /	050-099, 150-199
YBPD010P		MS24266R16B10S PLUG-WATER BOILER	7ZG7660M 96906	1	25-31-03 1540/ /	275-278
YBPD011P		MS24266R10B5S PLUG-WORK LIGHT	10150F31 89709	1	25-31-02 1540/ /	050-099, 150-199
YBPD011P		MS24266R14B7S PLUG-TRASH COMPACTOR	7ZG7660M 96906	1	25-31-03 1540/ /	275-278
YBPD012P		MS24266R16B10SN PLUG-COFFEEMAKER-LH	10150F31 89709	1	25-31-02 1540/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPD00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPD012P		BACC45FT16C10S PLUG-AIR CHILLER	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPD013J		16707 RECEPTACLE-HOT CUP	7ZG7660M 71468	1	25-31-03 / /	275-278
YBPD013P		MS24266R16B10SN PLUG-COFFEEMAKER-RH	10150F31 89709	1	25-31-02 1540/ /	050-099, 150-199
YBPD014P		BACC45FT16C10S PLUG-CURRENT TRANSFORMER	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPD030P		BACC63CE24A22P PLUG-INTERFACE (AC)	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBPD031P		MS24266R20B25SN PLUG-OVEN NO.1	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBPD032P		MS24266R20B25SN PLUG-OVEN NO.2	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBPD033P		S24266R10B5S PLUG-WORK LIGHT	10150F31 81205	1	25-31-02 1585/ /	150-199
YBPD034J		DACF15S RECEPTACLE-OVEN NO.1 CONTROL MODULE	10150F31 71468	1	25-31-02 1585/ /	050-099, 150-199
YBPD035J		DACF15S RECEPTACLE-OVEN NO.2 CONTROL MODULE	10150F31 71468	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPD00
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPD003		LH73-1 LAMP-AIR CHILLER OV/HT	7ZG7660M 96906	1	25-31-03 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBPD
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPK001		MS27222-2 RELAY	10150F31 35344	1	25-31-02 1540/ /	050-099, 150-199
YBPK001		MS27401-24 RELAY-AIR CHILLER	7ZG7660M 96906	1	25-31-03 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBPK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPL001		LH74-1 LAMP-POWER ON	7ZG7660M 72619	1	25-31-03 1540/ /	275-278
YBPL002		LH73-1 LAMP-AIR CHILLER OV/HT	7ZG7660M 72619	1	25-31-03 1540/ /	275-278
YBPL003		14-32280-8P6 FEEDER ENERGIZED (LAMP:0LN115-18K)	10150F31 29207	1	25-31-02 1540/ /	050-099, 150-199
YBPL003		LH73-1 LAMP-AIR CHILLER ON	7ZG7660M 72619	1	25-31-03 1540/ /	275-278
YBPL004		BR9172-503 WORK LIGHT	10150F31 15086	1	25-31-02 1540/ /	050-099, 150-199
YBPL004		LH74-1 LAMP-HOT CUP	7ZG7660M 72619	1	25-31-03 1540/ /	275-278
YBPL005		34265-14 LAMP-SPOT LIGHT A2	7ZG7660M 15086	1	25-31-03 1540/ /	275-278
YBPL006		34265-14 LAMP-SPOT LIGHT A3	7ZG7660M 15086	1	25-31-03 1540/ /	275-278
YBPL030		14-32280-8P6 FEEDER ENERGIZED (LAMP:0LN115-18K)	10150F31 29207	1	25-31-02 1585/ /	050-099, 150-199
YBPL032		BR9172-503 WORK LIGHT	10150F31 15086	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPM002		DA57-2B COFFEEMAKER NO 1 & 2	7ZG7660M JAMCO	2	25-31-03 1540/ /	275-278
YBPM004		DR6-2B WATER BOILER	7ZG7660M JAMCO	1	25-31-03 1540/ /	275-278
YBPM005		DLH581-005 HOT CUP	7ZG7660M JAMCO	1	25-31-03 1540/ /	275-278
YBPM025		3200 TRASH COMPACTOR	7ZG7660M JAMCO	1	25-31-03 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBPM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPP001		2F225-002200000 ELECTRICAL CONTROL PANEL	10150F31 SELL	1	25-31-02 1540/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPP00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPS001		10HA1C4F3N11R1 SW-AIR CHILLER	10150F31 SELL	1	25-31-02 1540/ /	050-099, 150-199
YBPS001		MS24523-22 SW-AIR CHILLER	7ZG7660M 96906	1	25-31-03 1540/ /	275-278
YBPS002		10HA1C1F3N1R1 SW-HOT JUG NO.1	10150F31 SELL	1	25-31-02 1540/ /	050-099, 150-199
YBPS003		10HA1C1F3N1R1 SW-HOT JUG NO.2	10150F31 SELL	1	25-31-02 1540/ /	050-099, 150-199
YBPS004		TEK72180605 SW-WATER HEATER	10150F31 SELL	1	25-31-02 1540/ /	050-099, 150-199
YBPS005		10HA1C1F3N1R1 SW-HOT CUP	10150F31 SELL	1	25-31-02 1540/ /	050-099, 150-199
YBPS005		74404 SW-HOT CUP(M1)	7ZG7660M 79919	1	25-31-03 1540/ /	275-278
YBPS006		3448-1 SW-WORK LIGHT	10150F31 SELL	1	25-31-02 1540/ /	050-099, 150-199
YBPS030		3448-1 SW-WORK LIGHT	10150F31 SELL	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBPT001		2B75-1-A CURRENT TRANSFORMER	10150F31 77820	1	25-31-02 1540/ /	050-099, 150-199
YBPT001		60B00010-5 CURRENT TRANSFORMER	7ZG7660M 81205	1	25-31-03 1540/ /	275-278
YBPT002		03344-106 BALLAST(M1)	10150F31 15086	1	25-31-02 1540/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBPT00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQ++++		GALLEY-BFE LEFT AFT GALLEY (M1178)	7ZG7660M BFE	0	25-31-02 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBQ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQB001		20420L-3-8 GALLEY WATER LINE THERMOSTAT	00000000 TBD	1	30-71-25 / /	050-099, 150-199
YBQB002		110-6-21 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199
YBQB003		110-11-2-67 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBQB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQC001		BACC18AE15 CB-A4 GALLEY OVEN NO 1 POWER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC002		BACC18Z1R CB-AR GALLEY OVEN NO 1 CONTROL	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC003		BACC18AE15 CB-A4 GALLEY OVEN NO 2 POWER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC004		BACC18Z1R CB-A4 GALLEY OVEN NO 2 CONTROL	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC005		BACC18AE15 CB-A4 GALLEY OVEN NO 3 POWER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC006		BACC18Z1R CB-A4 GALLEY OVEN NO 3 CONTROL	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC007		BACC18AE15 CB-A4 GALLEY OVEN NO 4 POWER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC008		BACC18Z1R CB-A4 GALLEY OVEN NO 4 CONTROL	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC009		BACC18AE15 CB-OVEN NO 1 POWER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC010		BACC18Z1R CB-OVEN NO 1 CONTROL	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC011		BACC18AE15 CB-OVEN NO 2 POWER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC012		BACC18Z1R CB-OVEN NO 2 CONTROL	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC013		BACC18AE15 CB-AIR CHILLER POWER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC014		BACC18Z2R CB-AIR CHILLER CONTROL	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC015		BACC18AC10 CB-COFFEEMAKER 3 POWER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC016		BACC18Z1R CB-COFFEEMAKER 3 CONTROL	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC017		BACC18Z1R CB-COUNTER LIGHT	7ZG7660M 81205	1	25-31-02 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBQC00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQC018		BACC18Z1R CB-SPOT LIGHT	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQC020		BACC18AC15 CB-OVEN NO.3	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBQC021		BACC18AC15 CB-OVEN NO.4	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBQC022		BACC18AC15 CB-OVEN NO.5	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBQC023		BACC18Z2R CB-WORK LIGHT	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBQC00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQD001P		BACC63CE24A22P PLUG-AC INTERFACE	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQD002P		BACC45FT14C15P PLUG-DC INTERFACE	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQD009P		MS3126F18-11S PLUG-A4 GALLEY OVEN CONTROL NO 1	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD010P		MS3126F22-21P PLUG-A4 GALLEY OVEN CONTROL NO 1	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD011P		MS3126F18-11S PLUG-A4 GALLEY OVEN CONTROL NO 2	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD012P		MS3126F22-21P PLUG-A4 GALLEY OVEN CONTROL NO 2	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD013P		MS3126F18-11S PLUG-A4 GALLEY OVEN CONTROL NO 3	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD014P		MS3126F22-21P PLUG-A4 GALLEY OVEN CONTROL NO 3	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD015P		MS3126F18-11S PLUG-A4 GALLEY OVEN CONTROL NO 4	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD016P		MS3126F22-21P PLUG-A4 GALLEY OVEN CONTROL NO 4	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD017P		MS3126F18-11S PLUG-OVEN CONTROL NO 1	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD018P		MS3126F22-21P PLUG-OVEN CONTROL NO 1	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD019P		MS3126F18-11S PLUG-OVEN CONTROL NO 2	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD020P		BACC63CE24A22P PLUG-INTERFACE (AC)	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBQD020P		MS3126F22-21P PLUG-OVEN CONTROL NO 2	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD021P		MS24266R20B25SN PLUG-OVEN NO.3	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBQD022P		MS24266R20B25SN PLUG-OVEN NO.4	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBQD00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQD023P		S24266R20B25SN PLUG-OVEN NO.5	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBQD023P		BACC45FT16C10S PLUG-AIR CHILLER INTERFACE	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQD024P		MS24266R10B5S PLUG-WORK LIGHT	10150F31 81205	1	25-31-02 1585/ /	050-099, 150-199
YBQD024P		MS24266R20B25S PLUG-OVEN NO 1	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD025J		DACF15S RECEPTACLE-OVEN NO.3 CONTROL MODULE	10150F31 71468	1	25-31-02 1585/ /	050-099, 150-199
YBQD025P		MS24266R20B25S PLUG-OVEN NO 2	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD026J		DACF15S RECEPTACLE-OVEN NO.4 CONTROL MODULE	10150F31 71468	1	25-31-02 1585/ /	050-099, 150-199
YBQD026P		MS24266R16B10S PLUG-COFFEEMAKER	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD027J		DACF15S RECEPTACLE-OVEN NO.5 CONTROL MODULE	10150F31 71468	1	25-31-02 1585/ /	050-099, 150-199
YBQD027P		BACC63BN10C5P PLUG-CURRENT TRANSFORMER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQD104P		MS24266R20B25S PLUG-A4 GALLEY OVEN NO 1	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD105P		MS24266R20B25S PLUG-A4 GALLEY OVEN NO 2	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD106P		MS24266R20B25S PLUG-A4 GALLEY OVEN NO 3	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQD107P		MS24266R20B25S PLUG-A4 GALLEY OVEN NO 4	7ZG7660M 96906	1	25-31-02 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBQD00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQK001		MS27401-24 RELAY-AIR CHILLER	7ZG7660M 96906	1	25-31-02 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBQK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQL001		LH74-1 LAMP-POWER ON	7ZG7660M 72619	1	25-31-02 1540/ /	275-278
YBQL002		LH73-1 LAMP-AIR CHILLER OV/HT	7ZG7660M 72619	1	25-31-02 1540/ /	275-278
YBQL003		LH73-1 LAMP-AIR CHILLER ON	7ZG7660M 72619	1	25-31-02 1540/ /	275-278
YBQL004		7YE3200A01G01 LAMP-COUNTER LIGHT	7ZG7660M JAMCO	1	25-31-02 1540/ /	275-278
YBQL005		34265-14 LAMP-SPOT LIGHT	7ZG7660M 15086	1	25-31-02 1540/ /	275-278
YBQL006		34265-14 LAMP-SPOT LIGHT	7ZG7660M 15086	1	25-31-02 1540/ /	275-278
YBQL011		BR9172-503 WORK LIGHT	10150F31 15086	1	25-31-02 1585/ /	050-099, 150-199
YBQL012		14-32280-8P6 FEEDER ENERGIZED (LAMP:0LN1215-18K)	10150F31 29207	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBQL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQM001		DF400 OVEN NO 1 & 2,1 & 2 & 3 & 4 GALLEY A4	7ZG7660M JAMCO	6	25-31-02 1540/ /	275-278
YBQM002		DA57-2B COFFEEMAKER	7ZG7660M JAMCO	1	25-31-02 1540/ /	275-278
YBQM011		72038000 OVEN CONTROL MODULE (OVENS 3,4,5)	10150F31 SELL	3	25-31-02 1585/ /	050-099, 150-199
YBQM011		7110-35-0000 OVEN CONTROL UNIT	7ZG7660M JAMCO	6	25-31-02 1540/ /	275-278
YBQM021		60B40025-37 BALLAST-COUNTER LIGHT (M1)	7ZG7660M 81205	1	25-31-02 1540/ /	275-278

EQUIPMENT LIST

D280T132

Section YBQM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQP003		2-F-225-0023-00000 ELECTRICAL CONTROL PANEL	10150F31 SELL	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBQP00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQS001		MS24523-22 SW-AIR CHILLER	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQS002		MS24523-22 SW-COUNTER LIGHT	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQS003		MS24523-22 SW-SPOT LIGHT	7ZG7660M 96906	1	25-31-02 1540/ /	275-278
YBQS010		3448-1 SW-WORK LIGHT	10150F31 SELL	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBQS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBQT001		60B00010-5 CURRENT TRANSFORMER	7ZG7660M 81205	1	25-31-02 1540/ /	275-278
YBQT002		03344-106 BALLAST(M20)	10150F31 15086	1	25-31-02 1585/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YBQT00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBS++++		USEP057-00 PNL-FWD ABBR ATTEND.	00000000 81205	0	33-22-31 SCH 33/22/01	150-199

EQUIPMENT LIST

D280T132

Section YBS+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBT++++		USEP058-00 PNL-MID ABBR ATTEND.	00000000 81205	0	33-22-31 SCH 33/22/01	275-299

EQUIPMENT LIST

D280T132

Section YBT+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBTS01+		2100-3 SW-ATTEND. LT,LEFT	00000000 91929	1	33-22-31 / /	275-299
YBTS01A		85 LAMP-ATTEND. LT LEFT,SW	00000000 08806	1	33-22-31 / /	275-299
YBTS02+		2100-3 SW-ATTEND. LT,RIGHT	00000000 91929	1	33-22-31 / /	275-299
YBTS02A		85 LAMP-ATTEND. LT RIGHT,SW	00000000 08806	1	33-22-31 / /	275-299

EQUIPMENT LIST

D280T132

Section YBTS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBU++++		USEP059-00 PNL-AFT ABBR ATTEND.	00000000 81205	0	33-22-31 SCH 33/22/01	150-199, 275-299

EQUIPMENT LIST

D280T132

Section YBU+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBUS01+		2100-3 SW-ATTEND. LT,LEFT	00000000 91929	1	33-22-31 / /	150-199, 275-299
YBUS01A		85 LAMP-ATTEND. LT LEFT,SW	00000000 08806	1	33-22-31 / /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section YBUS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBV++++		USEM00235 PUMP-AIR HYD,SYS C	00000000 81205	0	29-11-32 SCH 29/11/01	ALL

EQUIPMENT LIST

D280T132

Section YBV+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBVTS01		3501942-2 SNSR-AIR HYD PUMP MONOPOLE	00000000 59364	1	29-11-32 / /	ALL

EQUIPMENT LIST

D280T132

Section YBVT
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBW++++		USEV00015 VALVE-ASSY,CABIN PRESS. OUTFLOW	00000000 81205	0	21-31-11 SCH 21/31/01	ALL

EQUIPMENT LIST

D280T132

Section YBW+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBWM001		2022480-9 ACTR-ASSY,OUTFLOW VALVE	216T1003 70210	1	21-31-11 //	ALL
YBWM002		2022478 MOTOR-AC,OUTFLOW VALVE	00000000 70210	2	21-31-11 //	ALL

EQUIPMENT LIST

D280T132

Section YBWM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBX++++		USEM01080 MODULE-CONTROL VALVE,INBD	00000000 81205	0	27-81-11 SCH 27/81/01	ALL

EQUIPMENT LIST

D280T132

Section YBX+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBXV056		S256T005-4 VALVE-BY-PASS,INBD SLAT	256T2610 81205	1	27-81-11 0775/173/R109	050-099, 150-166, 275-277
YBXV056		S256T005-8 VALVE-BY-PASS,INBD SLAT	256T2610 81205	1	27-81-11 0775/173/R109	167-199, 278-299

EQUIPMENT LIST

D280T132

Section YBXV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBY++++		USEM01081 MODULE-CONTROL VALVE,OUTBD SLAT	00000000 81205	0	27-81-21 SCH 27/81/02	ALL

EQUIPMENT LIST

D280T132

Section YBY+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBYV051		S256T005-4 VALVE-BY-PASS,OUTBD SLAT	256T2710 81205	1	27-81-21 0776/152/L110	050-099, 150-166, 275-278
YBYV051		S256T005-8 VALVE-BY-PASS,OUTBD SLAT	256T2710 81205	1	27-81-21 0776/152/L110	167-199, 280-299

EQUIPMENT LIST

D280T132

Section YBYV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBZ++++		USEM01082 MODULE-CONTROL VALVE,TE FLAP	00000000 81205	0	27-51-11 SCH 27/51/01	ALL

EQUIPMENT LIST

D280T132

Section YBZ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YBZV105	9	S256T005-8 VALVE-BY-PASS,TE FLAP (SB 27-0096)	256T3110 81205	1	27-51-11 0107/159/R013	050-099, 150, 152-166
YBZV105		S256T005-4 VALVE-BY-PASS,TE FLAP	256T3110 81205	1	27-51-11 0107/159/R013	050, 150-166, 275-277
YBZV105		S256T005-8 VALVE-BY-PASS,TE FLAP	256T3110 81205	1	27-51-11 0107/159/R013	167-199, 278-299

EQUIPMENT LIST

D280T132

Section YBZV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCC++++		USEM00289 MODULE-FWD LAVATORY	00000000 81205	0	33-26-11 SCH 33/26/01	ALL

EQUIPMENT LIST

D280T132

Section YCC+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCCB001		3100-101-3 THERMAL SWITCH	S417T106 14604	1	30-71-02 / /	150-199
YCCB002		2372-2 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YCCB003		2372-23 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YCCB004		2372-23 HEATER TAPE-S/O	S417T106 98085	1	30-71-02 / /	150-199
YCCB005		2372-24 HEATER TAPE-TEE	S417T106 98085	1	30-71-02 / /	150-199
YCCB006		2372-2 HEATER TAPE-RINSE	S417T106 98085	1	30-71-02 / /	150-199
YCCB007		2372-2 HEATER TAPE-RINSE	S417T106 98085	1	30-71-02 / /	150-199

EQUIPMENT LIST

D280T132

Section YCCB00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCCCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	ALL
YCCCR02		1N5618 DIODE	00000000 12969	1	33-25-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCCC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCCD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	ALL
YCCD007		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	050-099, 150-199
YCCD007		BR5000-501 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCCD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCCK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	ALL
YCCK002		BACR13CJ2 RELAY (REF K2)	00000000 81205	1	33-26-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YCCK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCCM001		S283T018-34 BALLAST-MIRROR LTS (REF M1)	00000000 81205	1	33-26-11 //	ALL
YCCM002		S283T018-33 BALLAST-MIRROR LTS (REF M2)	00000000 81205	1	33-26-11 //	ALL
YCCM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 //	ALL
YCCM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-12 //	ALL
YCCM011		PU90-419 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 //	050-099, 150-199
YCCM011		PU90-461 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 //	275-299

EQUIPMENT LIST

D280T132

Section YCCM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCCRT01		BS060770-1 DOME LIGHT	00000000 S5065	1	33-26-11 //	ALL
YCCRT01A		2233 LAMP	00000000 08806	1	33-26-11 //	ALL
YCCRT02		BS060780-1 SIGN-RETURN TO SEAT	00000000 S5065	1	33-24-11 //	ALL
YCCRT02A		MS25237-387 LAMP	00000000 96906	8	33-24-11 //	ALL
YCCRT03		BV5-01258-BV5-01261 MIRROR LIGHT	00000000 17023	3	33-26-11 //	ALL
YCCRT03A		5108-WW LAMP (REF RT3)	00000000 08805	3	33-26-11 //	ALL
YCCRT06		P90-90720-1 LT-LAV SMOKE WARNING	417T0106 S5065	1	26-13-11 //	155-157, 164-199

EQUIPMENT LIST

D280T132

Section YCCR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCCS001		10C10B SWITCH-DOOR LATCH	00000000 15438	1	33-26-11 //	ALL
YCCS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-12 //	ALL
YCCS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 //	ALL
YCCS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCCS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCCV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-12 / /	ALL
YCCV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-12 / /	ALL

EQUIPMENT LIST

D280T132

Section YCCV00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCF++++		USEM01156 MODULE-MID LAVATORY	00000000 81205	0	33-26-11 SCH 33/26/01	275-299

EQUIPMENT LIST

D280T132

Section YCF+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCFCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	275-299
YCFCR02		1N5618 DIODE	00000000 12969	1	33-25-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCFC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCFD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	275-299
YCFD007		BR5000-501 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCFD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCFK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	275-299
YCFK002		BACR13CJ2 RELAY	00000000 81205	1	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCFK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCFM004		S283T018-32 BALLAST-MIRROR LTS	00000000 81205	1	33-26-11 / /	275-299
YCFM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	275-299
YCFM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-12 / /	275-299
YCFM011		PU90-461 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCFM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCFRT01		BS060770-1 DOME LIGHT	00000000 S5065	1	33-26-11 / /	275-299
YCFRT01A		2233 LAMP	00000000 08806	1	33-26-11 / /	275-299
YCFRT02		BS060780-1 SIGN-RETURN TO SEAT	00000000 S5065	1	33-24-11 / /	275-299
YCFRT02A		MS25237-387 LAMP	00000000 96906	8	33-24-11 / /	275-299
YCFRT05		BV03202-BV03203 MIRROR LIGHT	00000000 17023	2	33-26-11 / /	275-299
YCFRT05A		F15T12-WW LAMP	00000000 08805	2	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCFR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCFS001		10C10B SWITCH-DOOR LATCH	00000000 15438	1	33-26-11 / /	275-299
YCFS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-12 / /	275-299
YCFS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 71482	1	33-25-11 / /	275-299
YCFS004		920099 SW-ATTENDNAT CALL	00000000 71482	1	33-25-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCFS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCFV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-12 / /	275-299
YCFV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-12 / /	275-299

EQUIPMENT LIST

D280T132

Section YCFV00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCG++++		USEM01157 MODULE-MID LAVATORY	00000000 81205	0	33-26-11 SCH 33/26/01	275-299

EQUIPMENT LIST

D280T132

Section YCG+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCGCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	275-299
YCGCR02		1N5618 DIODE	00000000 12969	1	33-25-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCGC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCGD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	275-299
YCGD007		BR5000-501 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCGD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCGK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	275-299
YCGK002		BACR13CJ2 RELAY	00000000 81205	1	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCGK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCGM004		S283T018-32 BALLAST-MIRROR LTS	00000000 81205	1	33-26-11 / /	275-299
YCGM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	275-299
YCGM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-13 / /	275-299
YCGM011		PU90-461 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCGM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCGRT01		BS060770-1 DOME LIGHT	00000000 S5065	1	33-26-11 / /	275-299
YCGRT01A		2233 LAMP	00000000 08806	1	33-26-11 / /	275-299
YCGRT02		BS060780-1 SIGN-RETURN TO SEAT	00000000 S5065	1	33-24-11 / /	275-299
YCGRT02A		MS25237-387 LAMP	00000000 96906	8	33-24-11 / /	275-299
YCGRT05		BV03202-BV03203 MIRROR LIGHT	00000000 17023	2	33-26-11 / /	275-299
YCGRT05A		F15T12-WW LAMP	00000000 08805	2	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCGR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCGS001		10C10B SWITCH-DOOR LATCH	00000000 15438	1	33-26-11 / /	275-299
YCGS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-13 / /	275-299
YCGS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	275-299
YCGS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YCGS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCGV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-13 / /	275-299
YCGV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-13 / /	275-299

EQUIPMENT LIST

D280T132

Section YCGV00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCL++++		USEM10055 PNL-FUEL MANAGEMENT	00000000 81205	0	28-22-11 SCH 28/22/01	ALL

EQUIPMENT LIST

D280T132

Section YCL+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCLK001		BACR13CD2 RELAY-CROSSFEED VALVE DISAGREEMENT	00000000 81205	1	28-22-31 / /	ALL
YCLK002		BACR13CD2 RELAY-LOW PRESS.,L PUMPS	00000000 81205	1	28-42-31 / /	ALL
YCLK003		BACR13CD2 RELAY-LOW PRESS.,R PUMPS	00000000 81205	1	28-42-31 / /	ALL
YCLK004		BACR13CD2 RELAY-L FWD PUMP PWR TRANS	00000000 81205	1	28-22-11 / /	ALL
YCLK005	1	10167-10-BT BOOST PUMP LIGHT TIME DELAY,R FWD	00000000 08719	1	28-22-11 / /	ALL
YCLK005	2	TD-1767-1002 BOOST PUMP LIGHT TIME DELAY,R FWD	00000000 35344	1	28-22-11 / /	ALL
YCLK006	1	10167-10-BT BOOST PUMP LIGHT TIME DELAY,L FWD	00000000 08719	1	28-22-11 / /	ALL
YCLK006	2	TD-1767-1002 BOOST PUMP LIGHT TIME DELAY,L FWD	00000000 35344	1	28-22-11 / /	ALL
YCLK007	1	10167-10-BT BOOST PUMP LIGHT TIME DELAY,R AFT	00000000 08719	1	28-22-11 / /	ALL
YCLK007	2	TD-1767-1002 BOOST PUMP LIGHT TIME DELAY,R AFT	00000000 35344	1	28-22-11 / /	ALL
YCLK008	1	10167-10-BT BOOST PUMP LIGHT TIME DELAY,L AFT	00000000 08719	1	28-22-11 / /	ALL
YCLK008	2	TD-1767-1002 BOOST PUMP LIGHT TIME DELAY,L AFT	00000000 35344	1	28-22-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YCLK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCLL01+	1	S231T300-2293 LIGHT-FUEL CONFIGURATION	00000000 81205	1	28-41-13 //	ALL
YCLL01+	2	S231T300-1293 LIGHT-FUEL CONFIGURATION	00000000 81205	1	28-41-13 //	ALL
YCLL01+	3	S231T300-1293 LIGHT-FUEL CONFIGURATION	00000000 81205	1	28-41-13 //	ALL
YCLL01A		MS25237-387 LAMP	00000000 96906	1	28-41-13 //	ALL
YCLL01D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	28-41-13 //	ALL

EQUIPMENT LIST

D280T132

Section YCLL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCLS01+	5	S231T290-2026 SW-FUEL BOOST PUMP CONT,R AFT	00000000 81205	1	28-22-11 //	ALL
YCLS01+	1	S231T290-4026 SW-FUEL BOOST PUMP CONT,R AFT	00000000 81205	1	28-22-11 //	ALL
YCLS01+	2	S231T290-5026 SW-FUEL BOOST PUMP CONT,R AFT	00000000 81205	1	28-22-11 //	ALL
YCLS01+	3	S231T290-3026 SW-FUEL BOOST PUMP CONT,R AFT	00000000 81205	1	28-22-11 //	ALL
YCLS01+	4	S231T290-1026 SW-FUEL BOOST PUMP CONT,R AFT	00000000 81205	1	28-22-11 //	ALL
YCLS01A		MS25237-387 LAMP	00000000 96906	1	28-22-11 //	ALL
YCLS01B		MS24515-685AS15 LAMP	00000000 96906	1	28-22-11 //	ALL
YCLS01D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-22-11 //	ALL
YCLS02+	5	S231T290-2026 SW-FUEL BOOST PUMP CONT,L FWD	00000000 81205	1	28-22-11 //	ALL
YCLS02+	1	S231T290-4026 SW-FUEL BOOST PUMP CONT,L FWD	00000000 81205	1	28-22-11 //	ALL
YCLS02+	2	S231T290-5026 SW-FUEL BOOST PUMP CONT,L FWD	00000000 81205	1	28-22-11 //	ALL
YCLS02+	3	S231T290-3026 SW-FUEL BOOST PUMP CONT,L FWD	00000000 81205	1	28-22-11 //	ALL
YCLS02+	4	S231T290-1026 SW-FUEL BOOST PUMP CONT,L FWD	00000000 81205	1	28-22-11 //	ALL
YCLS02A		MS25237-387 LAMP	00000000 96906	1	28-22-11 //	ALL
YCLS02B		MS24515-685AS15 LAMP	00000000 96906	1	28-22-11 //	ALL
YCLS02D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-22-11 //	ALL
YCLS03+	5	S231T290-2022 SW-FUEL OVRD PUMP CONT,R	00000000 81205	1	28-22-12 //	ALL

EQUIPMENT LIST

D280T132

Section YCLS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCLS03+	1	S231T290-4022 SW-FUEL OVRD PUMP CONT,R	00000000 81205	1	28-22-12 //	ALL
YCLS03+	2	S231T290-5022 SW-FUEL OVRD PUMP CONT,R	00000000 81205	1	28-22-12 //	ALL
YCLS03+	3	S231T290-3022 SW-FUEL OVRD PUMP CONT,R	00000000 81205	1	28-22-12 //	ALL
YCLS03+	4	S231T290-1022 SW-FUEL OVRD PUMP CONT,R	00000000 81205	1	28-22-12 //	ALL
YCLS03A		MS25237-387 LAMP	00000000 96906	1	28-22-12 //	ALL
YCLS03B		MS24515-685AS15 LAMP	00000000 96906	1	28-22-12 //	ALL
YCLS03D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-22-12 //	ALL
YCLS04+	5	S231T290-2026 SW-FUEL BOOST PUMP CONT,L AFT	00000000 81205	1	28-22-11 //	ALL
YCLS04+	1	S231T290-4026 SW-FUEL BOOST PUMP CONT,L AFT	00000000 81205	1	28-22-11 //	ALL
YCLS04+	2	S231T290-5026 SW-FUEL BOOST PUMP CONT,L AFT	00000000 81205	1	28-22-11 //	ALL
YCLS04+	3	S231T290-3026 SW-FUEL BOOST PUMP CONT,L AFT	00000000 81205	1	28-22-11 //	ALL
YCLS04+	4	S231T290-1026 SW-FUEL BOOST PUMP CONT,L AFT	00000000 81205	1	28-22-11 //	ALL
YCLS04A		MS25237-387 LAMP	00000000 96906	1	28-22-11 //	ALL
YCLS04B		MS24515-685AS15 LAMP	00000000 96906	1	28-22-11 //	ALL
YCLS04D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-22-11 //	ALL
YCLS05+	5	S231T290-2026 SW-FUEL BOOST PUMP CONT,R FWD	00000000 81205	1	28-22-11 //	ALL
YCLS05+	1	S231T290-4026 SW-FUEL BOOST PUMP CONT,R FWD	00000000 81205	1	28-22-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCLS00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCLS05+	2	S231T290-5026 SW-FUEL BOOST PUMP CONT,R FWD	00000000 81205	1	28-22-11 //	ALL
YCLS05+	3	S231T290-3026 SW-FUEL BOOST PUMP CONT,R FWD	00000000 81205	1	28-22-11 //	ALL
YCLS05+	4	S231T290-1026 SW-FUEL BOOST PUMP CONT,R FWD	00000000 81205	1	28-22-11 //	ALL
YCLS05A		MS25237-387 LAMP	00000000 96906	1	28-22-11 //	ALL
YCLS05B		MS24515-685AS15 LAMP	00000000 96906	1	28-22-11 //	ALL
YCLS05D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-22-11 //	ALL
YCLS06+	5	S231T290-2021 SW-FUEL OVRD PUMP CONT,L	00000000 81205	1	28-22-12 //	ALL
YCLS06+	1	S231T290-4021 SW-FUEL OVRD PUMP CONT,L	00000000 81205	1	28-22-12 //	ALL
YCLS06+	2	S231T290-5021 SW-FUEL OVRD PUMP CONT,L	00000000 81205	1	28-22-12 //	ALL
YCLS06+	3	S231T290-3021 SW-FUEL OVRD PUMP CONT,L	00000000 81205	1	28-22-12 //	ALL
YCLS06+	4	S231T290-1021 SW-FUEL OVRD PUMP CONT,L	00000000 81205	1	28-22-12 //	ALL
YCLS06A		MS25237-387 LAMP	00000000 96906	1	28-22-12 //	ALL
YCLS06B		MS24515-685AS15 LAMP	00000000 96906	1	28-22-12 //	ALL
YCLS06D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-22-12 //	ALL
YCLS07+		S231T290-2038 SW-FUEL CROSSFEED VALVE CONT	00000000 81205	1	28-22-31 //	ALL
YCLS07A		MS25237-387 LAMP	00000000 96906	1	28-22-31 //	ALL
YCLS07B		MS24515-685AS15 LAMP	00000000 96906	1	28-22-31 //	ALL

EQUIPMENT LIST

D280T132

Section YCLS00

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCLS07D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-22-31 / /	ALL

EQUIPMENT LIST

D280T132

Section YCLS00
Page 4 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCO++++		BFE GALLEY-AFT AUX A4 (M01181)	00000000 BFE	0	25-31-31 SCH 25/31/03	050-099, 150-199, 275-276
YCO++++		BFE GALLEY-AFT AUX A4 (M01181)	00000000 BFE	0	25-31-21 SCH 25/31/03	277-278
YCO++++		BFE GALLEY-AFT AUX A4 (M01181)	00000000 BFE	0	25-31-21 SCH 25/31/02	280-299

EQUIPMENT LIST

D280T132

Section YCO+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCOL01+		NH752740-51 LIGHT	00000000 BFE	1	33-27-11 / /	ALL
YCOL01A		6S6DC30V LAMP	00000000 BFE	2	33-27-11 / /	ALL
YCOL02+		NH752740-51 LIGHT	00000000 BFE	1	33-27-11 / /	ALL
YCOL02A		6S6DC30V LAMP	00000000 BFE	2	33-27-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YCOL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCOS001		2AC59 SWITCH	00000000 BFE	1	33-27-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCOS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCP++++		USEM01182 GALLEY-FWD AUX F3 (M1182)	10150F21 BFE	1	25-31-01 / /	050-099, 150-199
YCP++++		GALLEY-BFE GALLEY-FWD AUX F3 (M1182)	00000000	1	25-31-01 / /	275-299

EQUIPMENT LIST

D280T132

Section YCP+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCPB001		20420L-3-8 GALLEY WATER LINE THERMOSTAT	00000000 TBD	1	30-71-25 / /	050-099, 150-199
YCPB002		110-7-6-49 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199
YCPB003		110-6-21 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199
YCPB004		110-6-21 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCPB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGPC020		BACC18AE35 CB-UNIT 1	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC021		BACC18AC15 CB-OVEN NO.1	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC022		BACC18AC15 CB-OVEN NO.2	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC023		BACC18AC10 CB-AIR CHILLER	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC024		BACC18AC10 CB-LH BOILER	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC025		BACC18AC10 CB-MD BOILER	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC026		BACC18AC10 CB-RH BOILER	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC027		BACC18Z-7R CB-WATER HEATER	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC028		BACC18Z7R CB-HOT CUP	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC029		BACC18Z7R CB-HOT JUG	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC030		BACC18Z-1R CB-AC CONTROL	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC031		BACC18Z1R CB-LN COFFEEMAKER CONTROL	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC032		BACC18Z1R CB-MID COFFEEMAKER CONTROL	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC033		BACC18Z1R CB-RH COFFEEMAKER CONTROL	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YGPC034		BACC18Z2R CB-WORKLIGHT	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YGPC00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCPD020J		BACC63CD32-17P RECEPTACLE-INTERFACE (AC)	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YCPD021J		BACC63CD24-22S RECEPTACLE-INTERFACE (AC)	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YCPD022J		BACC45FM14-15P RECEPTACLE-INTERFACE (DC)	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YCPD023P		BACC63BN10-5P PLUG-CURRENT TRANSFORMER	10150F21 81205	1	25-31-01 0354/ /	050-099, 150-199
YCPD025P		MS24266R20B25SN PLUG-OVEN 1	10150F21 89709	1	25-31-01 0354/ /	050-099, 150-199
YCPD026P		MS24266R20B25SN PLUG-OVEN 2	10150F21 89709	1	25-31-01 0354/ /	050-099, 150-199
YCPD027P		MS24266R16B10SN PLUG-LH COFFEEMAKER	10150F21 89709	1	25-31-01 0354/ /	050-099, 150-199
YCPD028P		MS24266R16B10SN PLUG-MID COFFEEMAKER	10150F21 89709	1	25-31-01 0354/ /	050-099, 150-199
YCPD029P		MS24266R16B10SN PLUG-RH COFFEEMAKER	10150F21 89709	1	25-31-01 0354/ /	050-099, 150-199
YCPD031J		CA16707 RECEPTACLE-HOT JUG	10150F21 71468	1	25-31-01 0354/ /	050-099, 150-199
YCPD032J		FDBH50-8-98SN RECEPTACLE-WATER HEATER	10150F21 11139	1	25-31-01 0354/ /	050-099, 150-199
YCPD033J		CA16707 RECEPTACLE-HOT CUP	10150F21 71468	1	25-31-01 0354/ /	050-099, 150-199
YCPD034J		DACF15S RECEPTACLE-OVEN CONTROL MODULE	10150F21 71468	1	25-31-01 0354/ /	050-099, 150-199
YCPD035J		DACF15S RECEPTACLE-OVEN CONTROL MODULE	10150F21 71468	1	25-31-01 0354/ /	050-099, 150-199
YCPD036J		AFD5016-8SNA231 RECEPTACLE-AIR CHILLER	10150F21 11139	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCPD00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCPK020		KA-D9F-005 RELAY-AIR CHILLER	10150F21 35344	1	25-31-01 0354/ /	050-099, 150-199
YCPK021		S401-B1A2 RELAY-SOCKET	10150F21 35344	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCPK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCPL022		33-32682-8P4 IND LT-GALLEY PWR ON (LAMP:A1H)	10150F21 29207	1	25-31-01 0354/ /	050-099, 150-199
YCPL023		BR9172-503 WORK LIGHT	10150F21 15086	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCPL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCPM001		72068000 OVENS-1 AND 2	10150F21 SELL	2	25-31-01 0354/ /	050-099, 150-199
YCPM002		521-1-000-1B COFFEEMAKERS-LEFT, MID,AND RIGHT	10150F21 SELL	3	25-31-01 0354/ /	050-099, 150-199
YCPM004		72180605 WATER HEATER	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199
YCPM005		DLH-581-004 HOT CUP	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199
YCPM010		DLH-105-57 HOT JUG	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199
YCPM011		72038000 OVEN CONTROL MODULE (OVENS 1,2)	10150F21 SELL	2	25-31-01 0354/ /	050-099, 150-199
YCPM016		356-1 AIR CHILLER	10150F21 60299	1	25-31-01 0354/ /	050-099, 150-199
YCPM020		03344-106 BALLAST-WORK LIGHT	10150F21 15086	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCPM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCPP021		Z-F-225-0018-00000 ELECTRICAL CONTROL PANEL	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCPP00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCPS020		10HA1C4F3N11R1 SW-AIR CHILLER	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199
YCPS021		10HA1C1F3N1R1 SW-HOT JUG	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199
YCPS022		10HA1C1F3N1R1 SW-WATER HEATER	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199
YCPS023		10HA1C1F3N1R1 SW-HOT CUP	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199
YCPS024		3448-1 SW-WORK LIGHT	10150F21 SELL	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCPS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCPT020		2B75-1-A CURRENT TRANSFORMER	10150F21 77820	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCPT00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCR++++		USEM00162 PROX SW-ELEX UNIT	00000000 08748	1	32-09-21 SCH 32/09/01	ALL

EQUIPMENT LIST

D280T132

Section YCR+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCRM001		8-535-04 PC ASSY-PROXIMITY (CARD SLOT #1)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM001	1	8-356-06 PC ASSY-PROXIMITY (CARD SLOT #1)	00000000 08748	1	32-09-21 / /	150-154
YCRM001	2	8-356-05 PC ASSY-PROXIMITY (CARD SLOT #1)	00000000 08748	1	32-09-21 / /	150-154
YCRM002		8-535-04 PC ASSY-PROXIMITY (CARD SLOT #2)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM002	1	8-356-06 PC ASSY-PROXIMITY (CARD SLOT #2)	00000000 08748	1	32-09-21 / /	150-154
YCRM002	2	8-356-05 PC ASSY-PROXIMITY (CARD SLOT #2)	00000000 08748	1	32-09-21 / /	150-154
YCRM003		8-535-04 PC ASSY-PROXIMITY (CARD SLOT #3)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM003	1	8-356-06 PC ASSY-PROXIMITY (CARD SLOT #3)	00000000 08748	1	32-09-21 / /	150-154
YCRM003	2	8-356-05 PC ASSY-PROXIMITY (CARD SLOT #3)	00000000 08748	1	32-09-21 / /	150-154
YCRM004		8-535-04 PC ASSY-PROXIMITY (CARD SLOT #4)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM004	1	8-356-06 PC ASSY-PROXIMITY (CARD SLOT #4)	00000000 08748	1	32-09-21 / /	150-154
YCRM004	2	8-356-05 PC ASSY-PROXIMITY (CARD SLOT #4)	00000000 08748	1	32-09-21 / /	150-154
YCRM005		8-640-05 PC ASSY-LOGIC 3 (CARD SLOT #5)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM006	1	8-351-09 PC ASSY-DRIVER (CARD SLOT #6)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM006	1	8-351-07 PC ASSY-DRIVER (CARD SLOT #6)	00000000 08748	1	32-09-21 / /	150-154
YCRM006	2	8-351-08 PC ASSY-DRIVER (CARD SLOT #6)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM006	2	8-351-06 PC ASSY-DRIVER (CARD SLOT #6)	00000000 08748	1	32-09-21 / /	150-154

EQUIPMENT LIST

D280T132

Section YCRM00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCRM006	3	8-351-05 PC ASSY-DRIVER (CARD SLOT #6)	00000000 08748	1	32-09-21 / /	150-154
YCRM007	1	8-351-09 PC ASSY-DRIVER (CARD SLOT #7)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM007	1	8-351-07 PC ASSY-DRIVER (CARD SLOT #7)	00000000 08748	1	32-09-21 / /	150-154
YCRM007	2	8-351-08 PC ASSY-DRIVER (CARD SLOT #7)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM007	2	8-351-06 PC ASSY-DRIVER (CARD SLOT #7)	00000000 08748	1	32-09-21 / /	150-154
YCRM007	3	8-351-05 PC ASSY-DRIVER (CARD SLOT #7)	00000000 08748	1	32-09-21 / /	150-154
YCRM008		8-390-11 PC ASSY-BITE MODULE (CARD SLOT #8)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM008		8-390-06 PC ASSY-BITE MODULE (CARD SLOT #8)	00000000 08748	1	32-09-21 / /	150-154
YCRM009		8-424-02 PC ASSY-LOGIC 2 (CARD SLOT #9)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM009	1	8-424-01 PC ASSY-LOGIC 2 (CARD SLOT #9)	00000000 08748	1	32-09-21 / /	150-154
YCRM009	2	8-392-02 PC ASSY-LOGIC 2 (CARD SLOT #9)	00000000 08748	1	32-09-21 / /	150-154
YCRM010	1	8-351-09 PC ASSY-DRIVER (CARD SLOT #10)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM010	1	8-351-07 PC ASSY-DRIVER (CARD SLOT #10)	00000000 08748	1	32-09-21 / /	150-154
YCRM010	2	8-351-08 PC ASSY-DRIVER (CARD SLOT #10)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM010	2	8-351-06 PC ASSY-DRIVER (CARD SLOT #10)	00000000 08748	1	32-09-21 / /	150-154
YCRM010	3	8-351-05 PC ASSY-DRIVER (CARD SLOT #10)	00000000 08748	1	32-09-21 / /	150-154
YCRM011		8-498-05 PC ASSY-LOGIC 1 (CARD SLOT #11)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YCRM00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCRM012		8-394-03 PC ASSY-AUX DRIVER (CARD SLOT #12)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM012	1	8-394-03 PC ASSY-AUX DRIVER (CARD SLOT #12)	00000000 08748	1	32-09-21 / /	150-154
YCRM012	2	8-394-02 PC ASSY-AUX DRIVER (CARD SLOT #12)	00000000 08748	1	32-09-21 / /	150-154
YCRM013		8-535-02 PC ASSY-PROXIMITY (CARD SLOT #13)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM013	1	8-356-06 PC ASSY-PROXIMITY (CARD SLOT #13)	00000000 08748	1	32-09-21 / /	150-154
YCRM013	2	8-356-05 PC ASSY-PROXIMITY (CARD SLOT #13)	00000000 08748	1	32-09-21 / /	150-154
YCRM014		8-535-02 PC ASSY-PROXIMITY (CARD SLOT #14)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM014	1	8-356-06 PC ASSY-PROXIMITY (CARD SLOT #14)	00000000 08748	1	32-09-21 / /	150-154
YCRM014	2	8-356-05 PC ASSY-PROXIMITY (CARD SLOT #14)	00000000 08748	1	32-09-21 / /	150-154
YCRM015		8-535-02 PC ASSY-PROXIMITY (CARD SLOT #15)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM015	1	8-356-06 PC ASSY-PROXIMITY (CARD SLOT #15)	00000000 08748	1	32-09-21 / /	150-154
YCRM015	2	8-356-05 PC ASSY-PROXIMITY (CARD SLOT #15)	00000000 08748	1	32-09-21 / /	150-154
YCRM016		8-535-02 PC ASSY-PROXIMITY (CARD SLOT #16)	00000000 08748	1	32-09-21 / /	050-099, 155-199, 275-299
YCRM016	1	8-356-06 PC ASSY-PROXIMITY (CARD SLOT #16)	00000000 08748	1	32-09-21 / /	150-154
YCRM016	2	8-356-05 PC ASSY-PROXIMITY (CARD SLOT #16)	00000000 08748	1	32-09-21 / /	150-154

EQUIPMENT LIST

D280T132

Section YCRM00

Page 3 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCSR002	1	3852ABJ504H POTENTIOMETER-PNL LIGHT CONT,F/E	00000000 55578	1	33-13-14 / /	ALL
YCSR002	2	WA03923A POTENTIOMETER-PNL LIGHT CONT,F/E	00000000 55578	1	33-13-14 / /	ALL

EQUIPMENT LIST

D280T132

Section YCSR00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCT++++		USEM00056 MDL-ANTI-COLL & LDG LIGHT CONT	00000000 81205	0	33-41-11 SCH 33/41/01	ALL

EQUIPMENT LIST

D280T132

Section YCT+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCTS002		A3-50 SWITCH-WING LANDING LIGHT,LEFT	00000000 81640	1	33-42-11 //	ALL
YCTS003		A3-50 SWITCH-WING LANDING LIGHT,RIGHT	00000000 81640	1	33-42-11 //	ALL
YCTS004		A3-1207 SWITCH-NOSE GEAR LANDING LIGHT	00000000 81640	1	33-42-11 //	ALL
YCTS01+		S231T290-2012 SWITCH-POSITION LIGHT	00000000 81205	1	33-43-11 //	150-151
YCTS01+		S231T290-4012 SWITCH-POSITION LIGHT	00000000 81205	1	33-43-11 //	275-299
YCTS01+	1	S231T290-4012 SWITCH-POSITION LIGHT	00000000 81205	1	33-43-11 //	050-099, 152-199
YCTS01+	2	S231T290-5012 SWITCH-POSITION LIGHT	00000000 81205	1	33-43-11 //	050-099, 152-199
YCTS01+	3	S231T290-2012 SWITCH-POSITION LIGHT	00000000 81205	1	33-43-11 //	050-099, 152-199
YCTS01A		MS24515-685AS15 LAMP	00000000 96906	2	33-43-11 //	ALL
YCTS01D		851-30768-823 LIGHT SWITCH-DIODE/FUSE ASSY	00000000 96182	1	33-43-11 //	ALL
YCTS05+		S231T290-2012 SWITCH-ANTI COLLISION LIGHT,WHITE	00000000 81205	1	33-44-21 //	150-151, 275-299
YCTS05+	1	S231T290-4012 SWITCH-ANTI-COLLISION LIGHT,WHITE	00000000 81205	1	33-44-21 //	050-099, 152-199
YCTS05+	2	S231T290-5012 SWITCH-ANTI-COLLISION LIGHT,WHITE	00000000 81205	1	33-44-21 //	050-099, 152-199
YCTS05+	3	S231T290-2012 SWITCH-ANTI-COLLISION LIGHT,WHITE	00000000 81205	1	33-44-21 //	152-199
YCTS05A		MS24515-685AS15 LAMP	00000000 96906	2	33-44-21 //	ALL
YCTS05D		851-30768-823 LIGHT SWITCH-DIODE/FUSE ASSY	00000000 96182	1	33-44-21 //	ALL
YCTS06+		S231T290-3012 SWITCH-WING ILLUMINATION LIGHT	00000000 81205	1	33-41-11 //	150-151

EQUIPMENT LIST

D280T132

Section YCTS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCTS06+		S231T290-4012 SWITCH-WING ILLUMINATION	00000000 81205	1	33-41-11 //	275-299
YCTS06+	1	S231T290-4012 SWITCH-WING ILLUMINATION LIGHT	00000000 81205	1	33-41-11 //	050-099, 152-199
YCTS06+	2	S231T290-5012 SWITCH-WING ILLUNINATION LIGHT	00000000 81205	1	33-41-11 //	050-099, 152-199
YCTS06+	3	S231T290-3012 SWITCH-WING ILLUMINATION LIGHT	00000000 81205	1	33-41-11 //	050-099, 152-199
YCTS06+	4	S231T290-2012 SWITCH-WING ILLUMINATION LIGHT	00000000 81205	1	33-41-11 //	050-099, 152-199
YCTS06A		MS24515-685AS15 LAMP	00000000 96906	2	33-41-11 //	ALL
YCTS06D		851-30768-823 LIGHT SWITCH-DIODE/FUSE ASSY	00000000 96182	1	33-41-11 //	ALL
YCTS07+		S231T290-2012 SWITCH-ANTI COLLISION LIGHT,RED	00000000 81205	1	33-44-11 //	150-151
YCTS07+		S231T290-4012 SWITCH-ANTI COLLISION,RED	00000000 81205	1	33-44-11 //	275-299
YCTS07+	1	S231T290-4012 SWITCH-ANTI COLLISION LIGHT,RED	00000000 81205	1	33-44-11 //	050-099, 152-199
YCTS07+	2	S231T290-5012 SWITCH-ANTI-COLLISION LIGHT,RED	00000000 81205	1	33-44-11 //	050-099, 152-199
YCTS07+	3	S231T290-2012 SWITCH-ANTI-COLLISION LIGHT,RED	00000000 81205	1	33-44-11 //	050-099, 152-199
YCTS07A		MS24515-685AS15 LAMP	00000000 96906	2	33-44-11 //	ALL
YCTS07D		851-30768-823 LIGHT SWITCH-DIODE/FUSE ASSY	00000000 96182	1	33-44-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCTS00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCW++++		USEM10056 MDL-PNL LIGHTING CONTROL,LEFT	00000000 81205	0	33-42-21 SCH 33/42/01	ALL

EQUIPMENT LIST

D280T132

Section YCW+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCWR001		WA03924A POT-GLARESHIELD PNL & FLOODLIGHTING CONT	00000000 55578	1	33-11-13 / /	ALL
YCWR002		200-26549-01 POT-AISLE STAND PNL & FLOODLIGHTING CONT	00000000 95266	1	33-11-13 / /	ALL

EQUIPMENT LIST

D280T132

Section YCWR00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCWS001		MS25306-222 SWITCH-RUNWAY TURN OFF LIGHT,L	00000000 96906	1	33-42-21 //	ALL
YCWS002		MS25306-222 SWITCH-RUNWAY TURN OFF LIGHT,R	00000000 96906	1	33-42-21 //	ALL
YCWS004		MS25306-222 SWITCH-TAXI LIGHT	00000000 96906	1	33-42-21 //	ALL
YCWS03+		S231T290-2012 SWITCH-LIGHT OVERRIDE	00000000 81205	1	33-11-13 //	150-151
YCWS03+		S231T290-4012 SWITCH-LIGHT OVERRIDE	00000000 81205	1	33-11-13 //	275-299
YCWS03+	1	S231T290-4012 SWITCH-LIGHT OVERRIDE	00000000 81205	1	33-11-13 //	050-099, 152-199
YCWS03+	2	S231T290-5012 SWITCH-LIGHT OVERRIDE	00000000 81205	1	33-11-13 //	050-099, 152-199
YCWS03+	3	S231T290-2012 SWITCH-LIGHT OVERRIDE	00000000 81205	1	33-11-13 //	050-099, 152-199
YCWS03A		MS24515-685AS15 LAMP	00000000 96906	2	33-11-13 //	ALL
YCWS03D		851-30768-823 LIGHT SWITCH-DIODE/FUSE ASSY	00000000 96182	1	33-11-13 //	ALL

EQUIPMENT LIST

D280T132

Section YCWS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCX++++		USEM10057 MDL-PNL ASSY LIGHTING CONT,RIGHT OVHD	00000000 81205	0	33-13-16 SCH 33/13/01	ALL

EQUIPMENT LIST

D280T132

Section YCX+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCXL001	9	434-674-1031-2373 LIGHT-FLT DK DR LOCK FAIL (SB 25-0325)	823T2518 81590	1	52-51-11 / /	050-099, 155-199, 276-299
YCXL001	9	434-674-1031-2373 LIGHT-FLT DK DR LOCK FAIL (SB 25-0332)	823T2518 81590	1	52-51-11 / /	150-154, 275
YCXL001A	9	MS25237-387 LAMP (SB 25-0325)	823T2518 81205	2	52-51-11 / /	050-099, 155-199, 276-299
YCXL001A	9	MS25237-387 LAMP (SB 25-0332)	823T2518 81205	2	52-51-11 / /	150-154, 275
YCXL002	9	434-674-1031-2374 LIGHT-FLT DK DR AUTO UNLOCK (SB 25-0325)	823T2518 81205	1	52-51-11 / /	050-099, 155-199, 276-299
YCXL002	9	434-674-1031-2374 LIGHT-FLT DK DR AUTO UNLOCK (SB 25-0332)	823T2518 81205	1	52-51-11 / /	150-154, 275
YCXL002A	9	MS25237-387 LAMP (SB 25-0325)	823T2518 81205	2	52-51-11 / /	050-099, 155-199, 276-299
YCXL002A	9	MS25237-387 LAMP (SB 25-0332)	823T2518 81205	2	52-51-11 / /	150-154, 275

EQUIPMENT LIST

D280T132

Section YCXL00

Page 1 End

Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCXR001		200-26550-01 CIRCUIT BREAKER-DIMMER CONT	00000000 95266	1	33-11-16 / /	ALL
YCXR002	1	3852ABJ2504H POTENTIOMETER-OVERHEAD PNL DIMMER	00000000 55578	1	33-13-16 / /	ALL
YCXR002	2	WA03923A POTENTIOMETER-OVERHEAD PNL DIMMER	00000000 55578	1	33-13-16 / /	ALL

EQUIPMENT LIST

D280T132

Section YCXR00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCXS001	9	3600-5993 SW-FLIGHT DECK DOOR (SB 25-0325)	823T2518 81205	1	52-51-11 //	050-099, 155-199, 276-299
YCXS001	9	3600-5993 SW-FLIGHT DECK DOOR (SB 25-0332)	823T2518 81205	1	52-51-11 //	150-154, 275
YCXS001	1	S231T290-4077 SW-DOOR UNLOCKED	00000000 81205	1	52-51-11 //	050-099, 153-154, 156, 162-199, 275
YCXS001	1	S231T290-3077 SW-DOOR UNLOCKED	00000000 81205	1	52-51-11 //	150-152
YCXS001	2	S231T290-5077 SW-DOOR UNLOCKED	00000000 81205	1	52-51-11 //	050-099, 153-154, 156, 162-199, 275
YCXS001	2	S231T290-1077 SW-DOOR UNLOCKED	00000000 81205	1	52-51-11 //	150-152
YCXS001A		MS25237-387 LAMP	00000000 96906	4	52-51-11 //	050-099, 150-154, 156, 162-199, 275
YCXS001D		851-30768-823 DIODE-FUSE ASSY	00000000 96182	1	52-51-11 //	050-099, 150-154, 156, 162-199, 275
YCXS002		2P1311-H58 SWITCH-TEST	00000000 91929	1	33-16-11 //	ALL
YCXS003		AC90-0002-1 SWITCH-IND LIGHTS DIM/BRIGHT CONT	00000000 91812	1	33-16-11 //	ALL
YCXS01+		S231T290-4077 SWITCH-FLIGHT DECK DOOR LOCK/UNLOCK	00000000 81205	1	33-13-16 //	275
YCXS01+	1	S231T290-4077 SWITCH-FLIGHT DECK DOOR LOCK/UNLOCK	00000000 81205	1	33-13-16 //	050-099, 152-154, 156, 162-199
YCXS01+	1	S231T290-3077 SWITCH-FLIGHT DECK DOOR LOCK/UNLOCK	00000000 81205	1	33-13-16 //	150-151
YCXS01+	2	S231T290-5077 SWITCH-FLIGHT DECK DOOR LOCK/UNLOCK	00000000 81205	1	33-13-16 //	050-099, 152-154, 156, 162-199
YCXS01+	2	S231T290-2077 SWITCH-FLIGHT DECK DOOR LOCK/UNLOCK	00000000 81205	1	33-13-16 //	150-151
YCXS01+	3	S231T290-3077 SWITCH-FLIGHT DECK DOOR LOCK/UNLOCK	00000000 81205	1	33-13-16 //	050-099, 152-154, 156, 162-199
YCXS01+	4	S231T290-2077 SWITCH-FLIGHT DECK DOOR LOCK/UNLOCK	00000000 81205	1	33-13-16 //	050-099, 152-154, 156, 162-199

EQUIPMENT LIST

D280T132

Section YCXS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCXS01A		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	33-13-16 / /	050-099, 150-154, 156, 162-199, 275
YCXS01B		MS25237-387 LAMP-28 VOLT	00000000 96906	2	33-13-16 / /	050-099, 150-154, 156, 162-199, 275
YCXS01D		851-30768-823 LIGHT SWITCH-DIODE/FUSE ASSY	00000000 96182	1	33-13-16 / /	050-099, 150-154, 156, 162-199, 275
YCXS04+		S231T290-2012 SWITCH-LOGO LIGHT	00000000 81205	1	33-45-11 / /	150-151
YCXS04+		S231T290-4012 SWITCH-LOGO LIGHT	00000000 81205	1	33-45-11 / /	275-299
YCXS04+	1	S231T290-4012 SWITCH-LOGO LIGHT	00000000 81205	1	33-45-11 / /	050-099, 150-199
YCXS04+	2	S231T290-5012 SWITCH-LOGO LIGHT	00000000 81205	1	33-45-11 / /	050-099, 150-199
YCXS04+	3	S231T290-2012 SWITCH-LOGO LIGHT	00000000 81205	1	33-45-11 / /	050-099, 150-199
YCXS04A		MS24515-685AS15 LAMP-LOGO	00000000 96906	2	33-45-11 / /	050-099, 150-199
YCXS04D		851-30768-823 LIGHT SWITCH-DIODE/FUSE ASSY	00000000 96182	1	33-45-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YCXS00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCXT001		6430A XFMR-DOME LIGHTS DIMMER	00000000 95266	1	33-11-14 / /	ALL

EQUIPMENT LIST

D280T132

Section YCXT00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCY++++		USEM00010 CONT PNL-HYD SYS	00000000 81205	0	29-11-11 SCH 29/11/01	ALL

EQUIPMENT LIST

D280T132

Section YCY+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCYL01+		S231T300-1188 LT IND-HYD SYS L (PRESS)	00000000 81205	1	29-11-12 //	ALL
YCYL01A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-12 //	ALL
YCYL01D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-11-12 //	ALL
YCYL02+	1	S231T300-2188 LT IND-HYD SYS CTR (PRESS)	00000000 81205	1	29-11-32 //	ALL
YCYL02+	2	S231T300-1188 LT IND-HYD SYS CTR (PRESS)	00000000 81205	1	29-11-32 //	ALL
YCYL02A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-32 //	ALL
YCYL02D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-11-32 //	ALL
YCYL03+	1	S231T300-2188 LT IND-HYD SYS R (PRESS)	00000000 81205	1	29-11-22 //	ALL
YCYL03+	2	S231T300-1188 LT IND-HYD SYS R (PRESS)	00000000 81205	1	29-11-22 //	ALL
YCYL03A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-22 //	ALL
YCYL03D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-11-22 //	ALL
YCYL04+	1	S231T300-2086 LT IND-ENG HYD PUMP L OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL04+	2	S231T300-1086 LT IND-ENG HYD PUMP L OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL04A		MS25237-387 LAMP-28V	00000000 96906	2	29-32-11 //	ALL
YCYL04D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-32-11 //	ALL
YCYL05+	1	S231T300-2086 LT IND-ELEC HYD PUMP C1 OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL05+	2	S231T300-1086 LT IND-ELEC HYD PUMP C1 OVHT	00000000 81205	1	29-32-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCYL00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCYL05A		MS25237-387 LAMP-28V	00000000 96906	2	29-32-11 //	ALL
YCYL05D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-32-11 //	ALL
YCYL06+	1	S231T300-2086 LT IND-ENG HYD PUMP R OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL06+	2	S231T300-1086 LT IND-ENG HYD PUMP R OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL06A		MS25237-387 LAMP-28V	00000000 96906	2	29-32-11 //	ALL
YCYL06D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-32-11 //	ALL
YCYL07+	1	S231T300-2089 LT IND-ELEC HYD PUMP L (PRESS)	00000000 81205	1	29-11-12 //	ALL
YCYL07+	2	S231T300-1089 LT IND-ELEC HYD PUMP L (PRESS)	00000000 81205	1	29-11-12 //	ALL
YCYL07A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-12 //	ALL
YCYL07D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-11-12 //	ALL
YCYL08+	1	S231T300-2089 LT IND-AIR HYD PUMP (PRESS)	00000000 81205	1	29-11-32 //	ALL
YCYL08+	2	S231T300-1089 LT IND-AIR HYD PUMP (PRESS)	00000000 81205	1	29-11-32 //	ALL
YCYL08A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-32 //	ALL
YCYL08D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-11-32 //	ALL
YCYL09+	1	S231T300-2089 LT IND-ELEC HYD PUMP R (PRESS)	00000000 81205	1	29-11-22 //	ALL
YCYL09+	2	S231T300-1089 LT IND-ELEC HYD PUMP R (PRESS)	00000000 81205	1	29-11-22 //	ALL
YCYL09A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-22 //	ALL

EQUIPMENT LIST

D280T132

Section YCYL00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCYL09D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-11-22 //	ALL
YCYL10+	1	S231T300-2093 LT IND-L HYD SYS (QTY)	00000000 81205	1	29-33-11 //	ALL
YCYL10+	2	S231T300-1093 LT IND-L HYD SYS (QTY)	00000000 81205	1	29-33-11 //	ALL
YCYL10A		MS25237-387 LAMP-28V	00000000 96906	2	29-33-11 //	ALL
YCYL10D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-33-11 //	ALL
YCYL11+	1	S231T300-2093 LT IND-HYD SYS CTR (QTY)	00000000 81205	1	29-33-11 //	ALL
YCYL11+	2	S231T300-1093 LT IND-HYD SYS CTR (QTY)	00000000 81205	1	29-33-11 //	ALL
YCYL11A		MS25237-387 LAMP-28V	00000000 96906	2	29-33-11 //	ALL
YCYL11D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-33-11 //	ALL
YCYL12+	1	S231T300-2093 LT IND-HYD SYS R (QTY)	00000000 81205	1	29-33-11 //	ALL
YCYL12+	2	S231T300-1093 LT IND-HYD SYS R (QTY)	00000000 81205	1	29-33-11 //	ALL
YCYL12A		MS25237-387 LAMP-28V	00000000 96906	2	29-33-11 //	ALL
YCYL12D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-33-11 //	ALL
YCYL13+	1	S231T300-2086 LT IND-ELEC HYD PUMP C2 OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL13+	2	S231T300-1086 LT IND-ELEC HYD PUMP C2 OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL13A		MS25237-387 LAMP-28V	00000000 96906	2	29-32-11 //	ALL
YCYL13D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-32-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCYL00

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCYL14+	1	S231T300-2086 LT IND-ELEC HYD PUMP L OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL14+	2	S231T300-1086 LT IND-ELEC HYD PUMP L OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL14A		MS25237-387 LAMP-28V	00000000 96906	2	29-32-11 //	ALL
YCYL14D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-32-11 //	ALL
YCYL15+	1	S231T300-2086 LT IND-AIR HYD PUMP OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL15+	2	S231T300-1086 LT IND-AIR HYD PUMP OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL15A		MS25237-387 LAMP-28V	00000000 96906	2	29-32-11 //	ALL
YCYL15D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-32-11 //	ALL
YCYL16+	1	S231T300-2086 LT IND-ELEC HYD PUMP R OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL16+	2	S231T300-1086 LT IND-ELEC HYD PUMP R OVHT	00000000 81205	1	29-32-11 //	ALL
YCYL16A		MS25237-387 LAMP-28V	00000000 96906	2	29-32-11 //	ALL
YCYL16D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-32-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCYL00

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCYS01+	5	S231T290-2020 SW-ENG HYD PUMP L SEL (PRESS)	00000000 81205	1	29-11-12 //	ALL
YCYS01+	1	S231T290-4020 SW-ENG HYD PUMP L SEL (PRESS)	00000000 81205	1	29-11-12 //	ALL
YCYS01+	2	S231T290-5020 SW-ENG HYD PUMP L SEL (PRESS)	00000000 81205	1	29-11-12 //	ALL
YCYS01+	3	S231T290-3020 SW-ENG HYD PUMP L SEL (PRESS)	00000000 81205	1	29-11-12 //	ALL
YCYS01+	4	S231T290-1020 SW-ENG HYD PUMP L SEL (PRESS)	00000000 81205	1	29-11-12 //	ALL
YCYS01A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-12 //	ALL
YCYS01B		MS24515-685AS15 LAMP-5V	00000000 96906	2	29-11-12 //	ALL
YCYS01D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	29-11-12 //	ALL
YCYS02+	5	S231T290-2020 SW-ELEC HYD PUMP C1 SEL (PRESS)	00000000 81205	1	29-11-31 //	ALL
YCYS02+	1	S231T290-4020 SW-ELEC HYD PUMP C1 SEL (PRESS)	00000000 81205	1	29-11-31 //	ALL
YCYS02+	2	S231T290-5020 SW-ELEC HYD PUMP C1 SEL (PRESS)	00000000 81205	1	29-11-31 //	ALL
YCYS02+	3	S231T290-3020 SW-ELEC HYD PUMP C1 SEL (PRESS)	00000000 81205	1	29-11-31 //	ALL
YCYS02+	4	S231T290-1020 SW-ELEC HYD PUMP C1 SEL (PRESS)	00000000 81205	1	29-11-31 //	ALL
YCYS02A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-31 //	ALL
YCYS02B		MS24515-685AS15 LAMP-5V	00000000 96906	2	29-11-31 //	ALL
YCYS02D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	29-11-31 //	ALL
YCYS03+	5	S231T290-2020 SW-ELEC HYD PUMP C2 SEL (PRESS)	00000000 81205	1	29-11-31 //	ALL

EQUIPMENT LIST

D280T132

Section YCYS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCYS03+	1	S231T290-4020 SW-ELEC HYD PUMP C2 SEL (PRESS)	00000000 81205	1	29-11-31 / /	ALL
YCYS03+	2	S231T290-5020 SW-ELEC HYD PUMP C2 SEL (PRESS)	00000000 81205	1	29-11-31 / /	ALL
YCYS03+	3	S231T290-3020 SW-ELEC HYD PUMP C2 SEL (PRESS)	00000000 81205	1	29-11-31 / /	ALL
YCYS03+	4	S231T290-1020 SW-ELEC HYD PUMP C2 SEL (PRESS)	00000000 81205	1	29-11-31 / /	ALL
YCYS03A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-31 / /	ALL
YCYS03B		MS24515-685AS15 LAMP-5V	00000000 96906	2	29-11-31 / /	ALL
YCYS03D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	29-11-31 / /	ALL
YCYS04+	5	S231T290-2020 SW-ENG HYD PUMP R SEL (PRESS)	00000000 81205	1	29-11-22 / /	ALL
YCYS04+	1	S231T290-4020 SW-ENG HYD PUMP R SEL (PRESS)	00000000 81205	1	29-11-22 / /	ALL
YCYS04+	2	S231T290-5020 SW-ENG HYD PUMP R SEL (PRESS)	00000000 81205	1	29-11-22 / /	ALL
YCYS04+	3	S231T290-3020 SW-ENG HYD PUMP R SEL (PRESS)	00000000 81205	1	29-11-22 / /	ALL
YCYS04+	4	S231T290-1020 SW-ENG HYD PUMP R SEL (PRESS)	00000000 81205	1	29-11-22 / /	ALL
YCYS04A		MS25237-387 LAMP-28V	00000000 96906	2	29-11-22 / /	ALL
YCYS04B		MS24515-685AS15 LAMP-5V	00000000 96906	2	29-11-22 / /	ALL
YCYS04D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	29-11-22 / /	ALL
YCYS05+		AC45-0012-1 SW IND-ELEC HYD PUMP L SEL	00000000 74063	1	29-11-12 / /	ALL
YCYS06+		AC45-0007-1 SW IND-AIR HYD PUMP SEL	00000000 74063	1	29-11-32 / /	ALL

EQUIPMENT LIST

D280T132

Section YCYS00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCYS07+		AC45-0008-1 SW IND-ELEC HYD PUMP R SEL	00000000 74063	1	29-11-22 / /	ALL

EQUIPMENT LIST

D280T132

Section YCYS00
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCZ++++		USEM00015 PNL-BLEED AIR SUPPLY	00000000 81205	0	36-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCZ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCZL001	1	S231T300-2272 LIGHT IND-DUCT LEAK,LEFT	286TXXXX 81590	1	26-18-11 //	ALL
YCZL001	2	S231T300-1272-MOD- LIGHT IND-DUCT LEAK,LEFT	286TXXXX 81590	1	26-18-11 //	050-099
YCZL001	3	S231T300-1272 LIGHT IND-DUCT LEAK,LEFT	286TXXXX 81590	1	26-18-11 //	ALL
YCZL002	1	S231T300-2272 LIGHT IND-DUCT LEAK,RIGHT	286TXXXX 81590	1	26-18-21 //	ALL
YCZL002	2	S231T300-1272-MOD- LIGHT IND-DUCT LEAK,RIGHT	286TXXXX 81590	1	26-18-21 //	ALL
YCZL002	3	S231T300-1272 LIGHT IND-DUCT LEAK,RIGHT	286TXXXX 81590	1	26-18-21 //	ALL
YCZL007	1	S231T300-2286 LIGHT IND-DUCT LEAK,BODY	286TXXXX 81590	1	26-18-31 //	ALL
YCZL007	2	S231T300-1286-MOD- LIGHT IND-DUCT LEAK,BODY	286TXXXX 81590	1	26-18-31 //	ALL
YCZL007	3	S231T300-1286 LIGHT IND-DUCT LEAK,BODY	286TXXXX 81590	1	26-18-31 //	ALL
YCZL01+	1	S231T300-2272 LIGHT-INDICATION-DUCT LEAK,LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL01+	2	S231T300-1272 LIGHT-INDICATION-DUCT LEAK,LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL01+	3	S231T300-1272 LIGHT-INDICATION-DUCT LEAK,LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL01A		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZL01D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	36-11-11 //	ALL
YCZL02+	1	S231T300-2272 LIGHT INDICATION-DUCT LEAK,RIGHT	00000000 81205	0	36-11-11 //	ALL
YCZL02+	2	S231T300-1272 LIGHT INDICATION-DUCT LEAK,RIGHT	00000000 81205	0	36-11-11 //	ALL
YCZL02+	3	S231T300-1272 LIGHT INDICATION-DUCT LEAK,RIGHT	00000000 81205	0	36-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCZL00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCZL02A		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZL02D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	36-11-11 //	ALL
YCZL03+	1	S231T300-2272 LIGHT INDICATION-BLEED LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL03+	2	S231T300-1272 LIGHT INDICATION-BLEED LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL03+	3	S231T300-1272 LIGHT INDICATION-BLEED LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL03A		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZL03D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	36-11-11 //	ALL
YCZL04+	1	S231T300-2273 LIGHT-INDICATION,BLEED RIGHT	00000000 81205	0	36-11-11 //	ALL
YCZL04+	2	S231T300-1273 LIGHT-INDICATION,BLEED RIGHT	00000000 81205	0	36-11-11 //	ALL
YCZL04+	3	S231T300-1273 LIGHT-INDICATION,BLEED RIGHT	00000000 81205	0	36-11-11 //	ALL
YCZL04A		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZL04D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	36-11-11 //	ALL
YCZL05+	1	S231T300-2051 LIGHT-INDICATION,HI STAGE LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL05+	2	S231T300-1051 LIGHT-INDICATION,HI STAGE LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL05+	3	S231T300-1051 LIGHT-INDICATION,HI STAGE LEFT	00000000 81205	0	36-11-11 //	ALL
YCZL05A		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZL05D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	36-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCZL00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCZL06+	1	S231T300-2051 LIGHT INDICATION-HI STAGE RIGHT	00000000 81205	0	36-11-11 //	ALL
YCZL06+	2	S231T300-1051 LIGHT INDICATION-HI STAGE RIGHT	00000000 81205	0	36-11-11 //	ALL
YCZL06+	3	S231T300-1051 LIGHT INDICATION-HI STAGE RIGHT	00000000 81205	0	36-11-11 //	ALL
YCZL06A		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZL06D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	36-11-11 //	ALL
YCZL07+	1	S231T300-2051 LIGHT-INDICATION,DUCT LEAK BODY	00000000 81205	0	36-11-11 //	ALL
YCZL07+	2	S231T300-1051 LIGHT-INDICATION,DUCT LEAK BODY	00000000 81205	0	36-11-11 //	ALL
YCZL07+	3	S231T300-1051 LIGHT-INDICATION,DUCT LEAK BODY	00000000 81205	0	36-11-11 //	ALL
YCZL07A		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZL07D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	36-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCZL00
Page 3 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCZS01+		S231T290-4074 SWITCH INDICATION-LEFT ISO VALVE	00000000 81205	1	36-11-11 //	150-199, 275-299
YCZS01+	1	S231T290-4074 SWITCH INDICATION-LEFT ISO VALVE	00000000 81205	1	36-11-11 //	050-099
YCZS01+	2	S231T290-5074 SWITCH INDICATION-LEFT ISO VALVE	00000000 81205	1	36-11-11 //	050-099
YCZS01A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	36-11-11 //	ALL
YCZS01B		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZS01D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	36-11-11 //	ALL
YCZS02+		S231T290-4019 SWITCH INDICATION-CENTER ISO VALVE	00000000 81205	1	36-11-11 //	150-199, 275-299
YCZS02+	1	S231T290-4019 SWITCH INDICATION-CENTER ISO VALVE	00000000 81205	1	36-11-11 //	050-099
YCZS02+	2	S231T290-5019 SWITCH INDICATION-CENTER ISO VALVE	00000000 81205	1	36-11-11 //	050-099
YCZS02A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	36-11-11 //	ALL
YCZS02B		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZS02D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	36-11-11 //	ALL
YCZS03+		S231T290-4074 SWITCH INDICATION-R ISO VALVE	00000000 81205	1	36-11-11 //	150-199, 275-299
YCZS03+	1	S231T290-4074 SWITCH INDICATION-R ISO VALVE	00000000 81205	1	36-11-11 //	050-099
YCZS03+	2	S231T290-5074 SWITCH INDICATION-R ISO VALVE	00000000 81205	1	36-11-11 //	050-099
YCZS03A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	36-11-11 //	ALL
YCZS03B		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCZS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCZS03D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	36-11-11 //	ALL
YCZS04+		S231T290-4030 SWITCH INDICATION-L ENG BLEED	00000000 81205	1	36-11-11 //	150-199, 275-299
YCZS04+	1	S231T290-4030 SWITCH INDICATION-L ENG BLEED	00000000 81205	1	36-11-11 //	050-099
YCZS04+	2	S231T290-5030 SWITCH INDICATION-L ENG BLEED	00000000 81205	1	36-11-11 //	050-099
YCZS04A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	36-11-11 //	ALL
YCZS04B		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZS04D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	36-11-11 //	ALL
YCZS05+		S231T290-4019 SWITCH INDICATION-APU BLEED AIR	00000000 81205	1	36-11-11 //	150-199, 275-299
YCZS05+	1	S231T290-4019 SWITCH INDICATION-APU BLEED AIR	00000000 81205	1	36-11-11 //	050-099
YCZS05+	2	S231T290-5019 SWITCH INDICATION-APU BLEED AIR	00000000 81205	1	36-11-11 //	050-099
YCZS05A		M24515-685AS15 LAMP-5VAC	00000000 81205	2	36-11-11 //	ALL
YCZS05B		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 //	ALL
YCZS05D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	36-11-11 //	ALL
YCZS06+		S231T290-4013 SWITCH INDICATION-R ENG BLEED	00000000 81205	1	36-11-11 //	150-199, 275-299
YCZS06+	1	S231T290-4013 SWITCH INDICATION-R ENG BLEED	00000000 81205	1	36-11-11 //	050-099
YCZS06+	2	S231T290-5013 SWITCH INDICATION-R ENG BLEED	00000000 81205	1	36-11-11 //	050-099
YCZS06A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	36-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YCZS00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YCZS06B		MS25237-387 LAMP-28VDC	00000000 96906	2	36-11-11 / /	ALL
YCZS06D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	36-11-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YCZS00

Page 3 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDA++++		USEM00017 CONT PNL-EQUIPMENT COOLING	00000000 81205	0	21-58-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDA+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDAL01+		S231T300-2274 LIGHT INDICATOR-CABIN ALT	00000000 81590	1	21-33-11 //	ALL
YDAL01A		MS25237-387 LAMP-28VDC	00000000 96906	2	21-33-11 //	ALL
YDAL01D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	21-33-11 //	ALL
YDAL02+	1	S231T300-2086 LIGHT INDICATOR-OVHT	00000000 81590	1	21-58-11 //	ALL
YDAL02+	2	S231T300-1086 LIGHT INDICATOR-OVHT	00000000 81590	1	21-58-11 //	ALL
YDAL02+	3	S231T300-1086 LIGHT INDICATOR-OVHT	00000000 81590	1	21-58-11 //	ALL
YDAL02A		MS25237-387 LAMP-28VDC	00000000 96906	2	21-58-11 //	ALL
YDAL02D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	21-58-11 //	ALL
YDAL03+	1	S231T300-2108 LIGHT INDICATOR-SMOKE	00000000 81590	1	21-58-11 //	ALL
YDAL03+	2	S231T300-1108 LIGHT INDICATOR-SMOKE	00000000 81590	1	21-58-11 //	ALL
YDAL03+	3	S231T300-1108 LIGHT INDICATOR-SMOKE	00000000 81590	1	21-58-11 //	ALL
YDAL03A		MS25237-387 LAMP-28VDC	00000000 96906	2	21-58-11 //	ALL
YDAL03D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	21-58-11 //	ALL
YDAL04+	1	S231T300-2115 LIGHT INDICATION-VALVE	00000000 81590	1	21-58-11 //	ALL
YDAL04+	2	S231T300-1115 LIGHT INDICATION-VALVE	00000000 81590	1	21-58-11 //	ALL
YDAL04+	3	S231T300-1115 LIGHT INDICATION-VALVE	00000000 81590	1	21-58-11 //	ALL
YDAL04A		MS25237-387 LAMP-28VDC	00000000 96906	2	21-58-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDAL00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDAL04D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	21-58-11 //	ALL
YDAL05+	1	S231T300-2297 LIGHT-INDICATION,NO COOLING	00000000 81590	1	21-58-11 //	ALL
YDAL05+	2	S231T300-1297 LIGHT-INDICATION,NO COOLING	00000000 81590	1	21-58-11 //	ALL
YDAL05+	3	S231T300-1297 LIGHT-INDICATION,NO COOLING	00000000 81590	1	21-58-11 //	ALL
YDAL05A		MS25237-387 LAMP-28VDC	00000000 96906	2	21-58-11 //	ALL
YDAL05D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	21-58-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDAL00
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDAS01+		AC45-0005-1 SWITCH-MODE SELECT	00000000 81205	1	21-58-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDAS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDB++++		USEM00029 CONT PNL-CARGO HEAT	00000000 81205	1	21-43-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDB+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDBS01+		S231T290-4071 SWITCH INDICATION-FWD CARGO HEAT	00000000 81205	1	21-43-11 //	ALL
YDBS01A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	21-43-11 //	ALL
YDBS01B		MS25237-387 LAMP-28VDC	00000000 96906	2	21-43-11 //	ALL
YDBS01D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-43-11 //	ALL
YDBS02+		S231T290-4071 SWITCH INDICATION-AFT CARGO HEAT	00000000 81205	1	21-43-11 //	ALL
YDBS02A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	21-43-11 //	ALL
YDBS02B		MS25237-387 LAMP-28VDC	00000000 96906	2	21-43-11 //	ALL
YDBS02D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-43-11 //	ALL
YDBS03+		S231T290-4071 SWITCH INDICATION-BULK CARGO HEAT	00000000 81205	1	21-43-11 //	ALL
YDBS03A		MS24515-685AS15 LAMP-5VAC	00000000 96906	2	21-43-11 //	ALL
YDBS03B		MS25237-387 LAMP-28VDC	00000000 96906	2	21-43-11 //	ALL
YDBS03D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-43-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDBS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDE++++		USEM01094 MODULE-ENG FUEL HEAT	00000000	1	73-14-11 / /	150-157

EQUIPMENT LIST

D280T132

Section YDE+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDH++++		USEM10023 CONT PNL-WINDSHIELD WIPER/RAIN REPELLENT	00000000 81205	0	30-42-11 SCH 30/42/01	ALL

EQUIPMENT LIST

D280T132

Section YDH+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDHS001		S232T601-58 SW-WIPER MOTOR CONTROL	00000000 81205	1	30-42-11 / /	ALL
YDHS002	9	D200011B-01GUB SW-RAIN REPELLENT,L (INOP) (SB 30-0028)	00000000 96182	1	30-43-11 / /	050-099, 150-199
YDHS002		D200011B-01GUB SW-RAIN REPELLENT,L	00000000 96182	1	30-43-11 / /	275-299
YDHS003	9	D200011B-01GUB SW-RAIN REPELLENT,R (INOP) (SB 30-0028)	00000000 96182	1	30-43-11 / /	050-099, 150-199
YDHS003		D200011B-01GUB SW-RAIN REPELLENT,R	00000000 96182	1	30-43-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YDHS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDI++++		USEM10062 PANEL ASSY-STANDBY POWER	00000000 81205	0	24-33-11 SCH 24/33/01	ALL

EQUIPMENT LIST

D280T132

Section YDI+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDIL01+	1	S231T300-2194 LIGHT-INDICATOR	00000000 81590	1	24-33-11 //	ALL
YDIL01+	2	S231T300-1194 LIGHT-INDICATOR	00000000 81590	1	24-33-11 //	ALL
YDIL01A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-33-11 //	ALL
YDIL01D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	24-33-11 //	ALL
YDIL02+	1	S231T300-2195 LIGHT-INDICATOR	00000000 81590	1	24-33-11 //	ALL
YDIL02+	2	S231T300-1195 LIGHT-INDICATOR	00000000 81590	1	24-33-11 //	ALL
YDIL02A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-33-11 //	ALL
YDIL02D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	24-33-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDIL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDIS001		AC45-0036 SWITCH-ROTARY	00000000 91812	1	24-33-11 //	ALL
YDIS02+	5	S231T290-3024 SWITCH-INDICATOR	00000000 81205	1	24-33-11 //	050-099
YDIS02+		S231T290-4024 SWITCH-INDICATOR	00000000 81205	1	24-33-11 //	150-199, 275-299
YDIS02+	1	S231T290-4024 SWITCH-INDICATOR	00000000 81205	1	24-33-11 //	050-099
YDIS02+	2	S231T290-5024 SWITCH-INDICATOR	00000000 81205	1	24-33-11 //	050-099
YDIS02+	3	S231T290-1024 SWITCH-INDICATOR	00000000 81205	1	24-33-11 //	050-099
YDIS02+	4	S231T290-2024 SWITCH-INDICATOR	00000000 81205	1	24-33-11 //	050-099
YDIS02A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-33-11 //	ALL
YDIS02B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-33-11 //	ALL
YDIS02D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-33-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDIS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDJ++++		USEM10063 PANEL ASSY-ELEC SYS	00000000 81205	0	24-22-11 SCH 24/22/01	ALL

EQUIPMENT LIST

D280T132

Section YDJ+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDJK001		BACR13CG2AB RELAY-L UTIL BUS. RESET	00000000 81205	1	24-51-71 / /	ALL
YDJK002		BACR13CG2AB RELAY-R UTIL BUS. RESET	00000000 81205	1	24-51-71 / /	ALL

EQUIPMENT LIST

D280T132

Section YDJK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDJL05+	1	S231T300-2021 LIGHT-INDICATOR	00000000 81205	1	24-27-11 //	ALL
YDJL05+	2	S231T300-1021 LIGHT-INDICATOR	00000000 81205	1	24-27-11 //	ALL
YDJL05A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-27-11 //	ALL
YDJL05D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	24-27-11 //	ALL
YDJL06+	1	S231T300-2021 LIGHT-INDICATOR	00000000 81205	1	24-27-21 //	ALL
YDJL06+	2	S231T300-1021 LIGHT-INDICATOR	00000000 81205	1	24-27-21 //	ALL
YDJL06A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-27-21 //	ALL
YDJL06D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	24-27-21 //	ALL

EQUIPMENT LIST

D280T132

Section YDJL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDJS01+	5	S231T290-1007 SWITCH-INDICATOR	00000000 81205	1	24-11-11 //	ALL
YDJS01+	1	S231T290-5007 SWITCH-INDICATOR	00000000 81205	1	24-11-11 //	ALL
YDJS01+	2	S231T290-4007 SWITCH-INDICATOR	00000000 81205	1	24-11-11 //	ALL
YDJS01+	3	S231T290-3007 SWITCH-INDICATOR	00000000 81205	1	24-11-11 //	ALL
YDJS01+	4	S231T290-2007 SWITCH-INDICATOR	00000000 81205	1	24-11-11 //	ALL
YDJS01A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-11-11 //	ALL
YDJS01D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-11-11 //	ALL
YDJS02+	5	S231T290-1007 SWITCH-INDICATOR	00000000 81205	1	24-11-21 //	ALL
YDJS02+	1	S231T290-5007 SWITCH-INDICATOR	00000000 81205	1	24-11-21 //	ALL
YDJS02+	2	S231T290-4007 SWITCH-INDICATOR	00000000 81205	1	24-11-21 //	ALL
YDJS02+	3	S231T290-3007 SWITCH-INDICATOR	00000000 81205	1	24-11-21 //	ALL
YDJS02+	4	S231T290-2007 SWITCH-INDICATOR	00000000 81205	1	24-11-21 //	ALL
YDJS02A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-11-21 //	ALL
YDJS02D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-11-21 //	ALL
YDJS03+	5	S231T290-1031 SWITCH-INDICATOR	00000000 81205	1	24-22-11 //	ALL
YDJS03+	1	S231T290-5031 SWITCH-INDICATOR	00000000 81205	1	24-22-11 //	ALL
YDJS03+	2	S231T290-4031 SWITCH-INDICATOR	00000000 81205	1	24-22-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDJS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDJS03+	3	S231T290-3031 SWITCH-INDICATOR	00000000 81205	1	24-22-11 //	ALL
YDJS03+	4	S231T290-2031 SWITCH-INDICATOR	00000000 81205	1	24-22-11 //	ALL
YDJS03A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-22-11 //	ALL
YDJS03B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-22-11 //	ALL
YDJS03D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-22-11 //	ALL
YDJS04+	5	S231T290-1031 SWITCH-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDJS04+	1	S231T290-5031 SWITCH-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDJS04+	2	S231T290-4031 SWITCH-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDJS04+	3	S231T290-3031 SWITCH-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDJS04+	4	S231T290-2031 SWITCH-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDJS04A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-22-21 //	ALL
YDJS04B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-22-21 //	ALL
YDJS04D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-22-21 //	ALL
YDJS07+	1	S231T290-4054 SWITCH-INDICATOR	00000000 96182	1	24-51-13 //	ALL
YDJS07+	2	S231T290-5054 SWITCH-INDICATOR	00000000 96182	1	24-51-13 //	ALL
YDJS07+	3	S231T290-1054 SWITCH-INDICATOR	00000000 96182	1	24-51-13 //	ALL
YDJS07+	4	S231T290-3054 SWITCH-INDICATOR	00000000 96182	1	24-51-13 //	ALL

EQUIPMENT LIST

D280T132

Section YDJS00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDJS07A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-51-13 //	ALL
YDJS07D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-51-13 //	ALL
YDJS08+	1	S231T290-4053 SWITCH-INDICATOR	00000000 96182	1	24-51-23 //	ALL
YDJS08+	2	S231T290-5053 SWITCH-INDICATOR	00000000 96182	1	24-51-23 //	ALL
YDJS08+	3	S231T290-1053 SWITCH-INDICATOR	00000000 96182	1	24-51-23 //	ALL
YDJS08+	4	S231T290-3053 SWITCH-INDICATOR	00000000 96182	1	24-51-23 //	ALL
YDJS08A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-51-23 //	ALL
YDJS08D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-51-23 //	ALL
YDJS09+	5	S231T290-1064 SWITCH-INDICATOR	00000000 81205	1	24-22-12 //	ALL
YDJS09+	1	S231T290-5064 SWITCH-INDICATOR	00000000 81205	1	24-22-12 //	ALL
YDJS09+	2	S231T290-4064 SWITCH-INDICATOR	00000000 81205	1	24-22-12 //	ALL
YDJS09+	3	S231T290-3064 SWITCH-INDICATOR	00000000 81205	1	24-22-12 //	ALL
YDJS09+	4	S231T290-2064 SWITCH-INDICATOR	00000000 81205	1	24-22-12 //	ALL
YDJS09A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-22-12 //	ALL
YDJS09B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-22-12 //	ALL
YDJS09D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-22-12 //	ALL
YDJS10+	5	S231T290-1064 SWITCH-INDICATOR	00000000 81205	1	24-22-22 //	ALL

EQUIPMENT LIST

D280T132

Section YDJS00

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDJS10+	1	S231T290-5064 SWITCH-INDICATOR	00000000 81205	1	24-22-22 //	ALL
YDJS10+	2	S231T290-4064 SWITCH-INDICATOR	00000000 81205	1	24-22-22 //	ALL
YDJS10+	3	S231T290-3064 SWITCH-INDICATOR	00000000 81205	1	24-22-22 //	ALL
YDJS10+	4	S231T290-2064 SWITCH-INDICATOR	00000000 81205	1	24-22-22 //	ALL
YDJS10A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-22-22 //	ALL
YDJS10B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-22-22 //	ALL
YDJS10D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-22-22 //	ALL
YDJS11+	5	S231T290-1031 SWITCH-INDICATOR	00000000 81205	1	24-22-41 //	ALL
YDJS11+	1	S231T290-5031 SWITCH-INDICATOR	00000000 81205	1	24-22-41 //	ALL
YDJS11+	2	S231T290-4031 SWITCH-INDICATOR	00000000 81205	1	24-22-41 //	ALL
YDJS11+	3	S231T290-3031 SWITCH-INDICATOR	00000000 81205	1	24-22-41 //	ALL
YDJS11+	4	S231T290-2031 SWITCH-INDICATOR	00000000 81205	1	24-22-41 //	ALL
YDJS11A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-22-41 //	ALL
YDJS11B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-22-41 //	ALL
YDJS11D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	24-22-41 //	ALL
YDJS12+	5	S231T290-1045 SWITCH-INDICATOR	00000000 81205	1	24-41-11 //	ALL
YDJS12+	1	S231T290-5045 SWITCH-INDICATOR	00000000 81205	1	24-41-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDJS00

Page 4

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDJS12+	2	S231T290-4045 SWITCH-INDICATOR	00000000 81205	1	24-41-11 / /	ALL
YDJS12+	3	S231T290-3045 SWITCH-INDICATOR	00000000 81205	1	24-41-11 / /	ALL
YDJS12+	4	S231T290-2045 SWITCH-INDICATOR	00000000 81205	1	24-41-11 / /	ALL
YDJS12A		MS25237-387 LAMP-28 VOLT	00000000 96906	4	24-41-11 / /	ALL
YDJS12D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	2	24-41-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDJS00

Page 5 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDL++++		USEM10394 PANEL-ANNUNCIATOR	00000000 81205	0	30-31-11 SCH 30/31/01	ALL

EQUIPMENT LIST

D280T132

Section YDL+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDLL01+		S231T300-2244 LIGHT-INDICATOR (ENTRY DOOR)	00000000 81205	1	52-71-11 //	ALL
YDLL01A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	52-71-11 //	ALL
YDLL01D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	52-71-11 //	ALL
YDLL02+		S231T300-1245 LIGHT-INDICATOR (EMER DOORS)	00000000 81205	1	52-71-12 //	ALL
YDLL02A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	52-71-12 //	ALL
YDLL02D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	52-71-12 //	ALL
YDLL03+		S231T300-2246 LIGHT-INDICATOR (CARGO DOORS)	00000000 81205	1	52-71-13 //	ALL
YDLL03A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	52-71-13 //	ALL
YDLL03D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	52-71-13 //	ALL
YDLL04+		S231T300-2247 LIGHT-INDICATOR (ACCESS DOORS)	00000000 81205	1	52-71-14 //	ALL
YDLL04A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	52-71-14 //	ALL
YDLL04D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	52-71-14 //	ALL
YDLL05+		S231T300-2259 LIGHT-INDICATOR (CAPT PITOT)	00000000 81205	1	30-31-11 //	ALL
YDLL05A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-31-11 //	ALL
YDLL05D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-31-11 //	ALL
YDLL06+		S231T300-2260 LIGHT-INDICATOR (F/O PITOT)	00000000 81205	1	30-31-21 //	ALL
YDLL06A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-31-21 //	ALL

EQUIPMENT LIST

D280T132

Section YDLL00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDLL06D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-31-21 //	ALL
YDLL07+		S231T300-2202 LIGHT-INDICATOR (L AOA)	00000000 81205	1	30-32-11 //	ALL
YDLL07A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-32-11 //	ALL
YDLL07D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-32-11 //	ALL
YDLL08+		S231T300-2203 LIGHT-INDICATOR (R AOA)	00000000 81205	1	30-32-21 //	ALL
YDLL08A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-32-21 //	ALL
YDLL08D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-32-21 //	ALL
YDLL09+		S231T300-2261 LIGHT-INDICATOR (L AUX PITOT)	00000000 81205	1	30-31-23 //	ALL
YDLL09A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-31-23 //	ALL
YDLL09D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-31-23 //	ALL
YDLL10+		S231T300-2262 LIGHT-INDICATOR (R AUX PITOT)	00000000 81205	1	30-31-13 //	ALL
YDLL10A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-31-13 //	ALL
YDLL10D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-31-13 //	ALL
YDLL11+		S231T300-2112 LIGHT-INDICATOR (TAT)	00000000 81205	1	30-33-11 //	ALL
YDLL11A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-33-11 //	ALL
YDLL11D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-33-11 //	ALL
YDLL12+		S231T300-2092 LIGHT-INDICATOR (R TAT)	00000000 81205	1	30-33-21 //	ALL

EQUIPMENT LIST

D280T132

Section YDLL00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDLL13+		S231T300-1111 LIGHT-INDICATOR (STAB TRIM)	00000000 81205	1	27-41-11 //	ALL
YDLL13A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	27-41-11 //	ALL
YDLL13D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	27-41-11 //	ALL
YDLL14+		S231T300-1110 LIGHT-INDICATOR (SPOILERS)	00000000 81205	1	27-61-12 //	ALL
YDLL14A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	27-61-12 //	ALL
YDLL14D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	27-61-12 //	ALL
YDLL15+		S231T300-2012 LIGHT-INDICATOR (AUTO SPD BRK)	00000000 81205	1	27-62-11 //	ALL
YDLL15A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	27-62-11 //	ALL
YDLL15D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	27-62-11 //	ALL
YDLL17+		S231T300-1267 LIGHT-INDICATOR (UNSHED STAB TRIM)	00000000 81205	1	27-41-11 //	ALL
YDLL17A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	27-41-11 //	ALL
YDLL17D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	27-41-11 //	ALL
YDLL18+		S231T300-1105 LIGHT-INDICATOR (RUDDER RATIO)	00000000 81205	1	27-21-12 //	ALL
YDLL18A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	27-21-12 //	ALL
YDLL18D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	27-21-12 //	ALL
YDLL19+		S231T300-1212 LIGHT-INDICATOR (ANTI SKID)	00000000 81205	1	32-42-11 //	ALL
YDLL19A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	32-42-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDLL00

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDLL19D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	32-42-11 //	ALL
YDLL20+		S231T300-1139 LIGHT-INDICATOR (AIL LOCK)	00000000 81205	1	27-11-12 //	ALL
YDLL20A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	27-11-12 //	ALL
YDLL20D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	27-11-12 //	ALL
YDLL24+	1	S231T300-2296 LIGHT-INDICATOR (ENG EEC PROBE)	00000000 81205	1	30-34-21 //	150-157
YDLL24+	2	S231T300-1296 LIGHT-INDICATOR (ENG EEC PROBE)	00000000 81205	1	30-34-21 //	150-157
YDLL24+	3	S231T300-1296 LIGHT-INDICATOR (ENG EEC PROBE)	00000000 81205	1	30-34-21 //	150-157
YDLL24A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-34-21 //	150-157
YDLL24D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-34-21 //	150-157

EQUIPMENT LIST

D280T132

Section YDLL00
Page 4 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDM++++		USEM10395 PNL-WINDOW HEAT CONTROL	00000000 81205	0	30-41-11 SCH 30/41/01	ALL

EQUIPMENT LIST

D280T132

Section YDM+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDMS01+		S231T290-4016 SW-INDICATOR	00000000 81205	1	30-41-11 //	150-199, 275-299
YDMS01+	1	S231T290-4016 SW-INDICATOR	00000000 81205	1	30-41-11 //	ALL
YDMS01+	2	S231T290-5016 SW-INDICATOR	00000000 81205	1	30-41-11 //	ALL
YDMS01+	3	S231T290-3016 SW-INDICATOR	00000000 81205	1	30-41-11 //	050-099
YDMS01+	4	S231T290-1016 SW-INDICATOR	00000000 81205	1	30-41-11 //	050-099
YDMS01A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-41-11 //	ALL
YDMS01B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	30-41-11 //	ALL
YDMS01D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	30-41-11 //	ALL
YDMS02+		S231T290-4016 SW-INDICATOR	00000000 81205	1	30-41-11 //	150-199, 275-299
YDMS02+	1	S231T290-4016 SW-INDICATOR	00000000 81205	1	30-41-11 //	ALL
YDMS02+	2	S231T290-5016 SW-INDICATOR	00000000 81205	1	30-41-11 //	ALL
YDMS02+	3	S231T290-3016 SW-INDICATOR	00000000 81205	1	30-41-12 //	050-099
YDMS02+	4	S231T290-1016 SW-INDICATOR	00000000 81205	1	30-41-12 //	050-099
YDMS02A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-41-12 //	ALL
YDMS02B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	30-41-12 //	ALL
YDMS02D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	30-41-12 //	ALL
YDMS03+		S231T290-4016 SW-INDICATOR	00000000 81205	1	30-41-11 //	150-199, 275-299

EQUIPMENT LIST

D280T132

Section YDMS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDMS03+	1	S231T290-4016 SW-INDICATOR	00000000 81205	1	30-41-11 //	ALL
YDMS03+	2	S231T290-5016 SW-INDICATOR	00000000 81205	1	30-41-11 //	ALL
YDMS03+	3	S231T290-3016 SW-INDICATOR	00000000 81205	1	30-41-11 //	050-099
YDMS03+	4	S231T290-1016 SW-INDICATOR	00000000 81205	1	30-41-11 //	050-099
YDMS03A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-41-11 //	ALL
YDMS03B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	30-41-11 //	ALL
YDMS03D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	30-41-11 //	ALL
YDMS04+		S231T290-4016 SW-INDICATOR	00000000 81205	1	30-41-11 //	150-199, 275-299
YDMS04+	1	S231T290-4016 SW-INDICATOR	00000000 81205	1	30-41-11 //	ALL
YDMS04+	2	S231T290-5016 SW-INDICATOR	00000000 81205	1	30-41-11 //	ALL
YDMS04+	3	S231T290-3016 SW-INDICATOR	00000000 81205	1	30-41-12 //	050-099
YDMS04+	4	S231T290-1016 SW-INDICATOR	00000000 81205	1	30-41-12 //	050-099
YDMS04A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-41-12 //	ALL
YDMS04B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	30-41-12 //	ALL
YDMS04D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	30-41-12 //	ALL

EQUIPMENT LIST

D280T132

Section YDMS00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDN++++		USEM10397 CONT PNL-WING AND ENG ANTI-ICE	00000000 81205	0	30-11-11 SCH 30/11/01	ALL

EQUIPMENT LIST

D280T132

Section YDN+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDNK01+		BACR13CD2 RELAY-L ENGINE TAI DISAGREE	00000000 81205	1	30-21-11 / /	150-154, 275-299
YDNK02+		BACR13CD2 RELAY-R ENGINE TAI DISAGREE	00000000 81205	1	30-21-11 / /	150-154, 275-299

EQUIPMENT LIST

D280T132

Section YDNK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDNL01+		S231T300-2115 LIGHT-INDICATOR	00000000 81205	1	30-11-11 //	ALL
YDNL01A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-11-11 //	ALL
YDNL01D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-11-11 //	ALL
YDNL02+		S231T300-2115 LIGHT-INDICATOR	00000000 81205	1	30-11-11 //	ALL
YDNL02A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-11-11 //	ALL
YDNL02D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	30-11-11 //	ALL
YDNL03+		S231T300-2115 ANNUNCIATOR - VALVE	233T3241 81205	1	30-21-11 //	050-099, 155-199
YDNL03+		S231T300-2280 LIGHT-INDICATOR (ICING)	00000000 81205	1	30-81-11 //	150-154
YDNL03A		MS25237-387 LAMP-28 VOLT	233T3241 96906	2	30-21-11 //	050-099, 155-199
YDNL03D		851-30768-823 DIODE/FUSE ASSY	233T3241 96182	1	30-21-11 //	050-099, 155-199
YDNL04+		S231T300-2115 ANNUNCIATOR - VALVE	233T3241 81205	1	30-21-11 //	050-099, 155-199
YDNL04A		MS25237-387 LAMP-28 VOLT	233T3241 96906	2	30-21-11 //	050-099, 155-199
YDNL04D		851-30768-823 DIODE/FUSE ASSY	233T3241 96182	1	30-21-11 //	050-099, 155-199
YDNL05+		S231T300-2334 LIGHT-INDICATOR (ICE DET)	233T3241 81205	1	30-81-01 P005-00/ /	050-099, 155-199
YDNL05A		MS25237-387 LAMP-28 VOLT	233T3241 96906	2	30-81-01 P005-00/ /	050-099, 155-199
YDNL05D		434-093-001 DIODE/FUSE MODULE	233T3241 81590	1	30-81-01 P005-00/ /	050-099, 155-199
YDNL06+		S231T300-2280 LIGHT-INDICATOR (ICING)	233T3241 81205	1	30-81-01 P005-00/ /	050-099, 155-199

EQUIPMENT LIST

D280T132

Section YDNL00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDNL06A		MS25237-387 LAMP-28 VOLT	233T3241 96906	2	30-81-01 P005-00/ /	050-099, 155-199
YDNL06D		434-093-001 DIODE/FUSE MODULE	233T3241 81590	1	30-81-01 P005-00/ /	050-099, 155-199

EQUIPMENT LIST

D280T132

Section YDNL00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDNS01+		AC45-0088 SW-INDICATOR	233T3241 81205	1	30-21-11 //	050-099, 155-199
YDNS01+	1	S231T290-4027 SW-INDICATOR	00000000 81205	1	30-21-11 //	150-154, 275-299
YDNS01+	2	S231T290-5027 SW-INDICATOR	00000000 81205	1	30-21-11 //	150-154, 275-299
YDNS01A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-21-11 //	150-154, 275-299
YDNS01B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	30-21-11 //	150-154, 275-299
YDNS01D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	30-21-11 //	150-154, 275-299
YDNS02+		AC45-0088 SW-INDICATOR	233T3241 81205	1	30-21-11 //	050-099, 155-199
YDNS02+	1	S231T290-4027 SW-INDICATOR	00000000 81205	1	30-21-11 //	150-154, 275-299
YDNS02+	2	S231T290-5027 SW-INDICATOR	00000000 81205	1	30-21-11 //	150-154, 275-299
YDNS02A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-21-11 //	150-154, 275-299
YDNS02B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	30-21-11 //	150-154, 275-299
YDNS02D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	30-21-11 //	150-154, 275-299
YDNS03+		AC45-0087 SWITCH	00000000 81205	1	30-11-11 //	050-099, 275-299
YDNS03+		S231T290-4027 SW-INDICATOR	00000000 81205	1	30-11-11 //	150-199
YDNS03+	1	S231T290-4012 SW-INDICATOR	00000000 81205	1	30-11-11 //	050-099, 275-299
YDNS03+	2	S231T290-5012 SW-INDICATOR	00000000 81205	1	30-11-11 //	050-099, 275-299
YDNS03A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	30-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDNS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDNS03B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	30-11-11 / /	ALL
YDNS03D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	30-11-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDNS00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDOK001		BACR13CD2 RELAY-BTL 1 DISCH	00000000 81205	1	26-23-11 / /	ALL
YDOK002		BACR13CD2 RELAY-BTL 2 DISCH	00000000 81205	1	26-23-12 / /	ALL

EQUIPMENT LIST

D280T132

Section YDOK00
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDOL01+		S231T300-2228 LIGHT-APU BTL 1 DISCH	00000000 81205	1	26-22-21 / /	277-299
YDOL01+	1	S231T300-2015 LIGHT-APU BTL 1 DISCH	00000000 81205	1	26-22-21 / /	050-099, 150-199
YDOL01+	1	S231T300-2228 LIGHT-APU BTL 1 DISCH	00000000 81205	1	26-22-21 / /	275-276
YDOL01+	2	S231T300-1015 LIGHT-APU BTL 1 DISCH	00000000 81205	1	26-22-21 / /	050-099, 150-199
YDOL01+	2	S231T300-1228 LIGHT-APU BTL 1 DISCH	00000000 81205	1	26-22-21 / /	275-276
YDOL01+	3	S231T300-1015 LIGHT-APU BTL 1 DISCH	00000000 81205	1	26-22-21 / /	050-099, 150-199
YDOL01+	3	S231T300-1228 LIGHT-APU BTL 1 DISCH	00000000 81205	1	26-22-21 / /	275-276
YDOL01D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	26-22-21 / /	ALL
YDOL02+		S231T300-2229 LIGHT-APU BTL 2 DISCH	00000000 81205	1	26-22-21 / /	277-299
YDOL02+	1	S231T300-2229 LIGHT-APU BTL 2 DISCH	00000000 81205	1	26-22-21 / /	275-276
YDOL02+	2	S231T300-1229 LIGHT-APU BTL 2 DISCH	00000000 81205	1	26-22-21 / /	275-276
YDOL02+	3	S231T300-1229 LIGHT-APU BTL 2 DISCH	00000000 81205	1	26-22-21 / /	275-276
YDOL02D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	26-22-21 / /	275-299

EQUIPMENT LIST

D280T132

Section YDOL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDOS01+		S231T290-4061 SW-FWD CARGO FIRE	00000000 81205	1	26-23-11 //	280-299
YDOS01+	1	S231T290-4061 SW-FWD CARGO FIRE	00000000 81205	1	26-23-11 //	050-099, 153-199, 275-278
YDOS01+	1	S231T290-3061 SW-FWD CARGO FIRE	00000000 81205	1	26-23-11 //	150-152
YDOS01+	2	S231T290-5061 SW-FWD CARGO FIRE	00000000 81205	1	26-23-11 //	050-099, 153-199, 275-278
YDOS01+	2	S231T290-1061 SW-FWD CARGO FIRE	00000000 81205	1	26-23-11 //	150-152
YDOS01A		MS25237-387 LAMP	00000000 96906	2	26-23-11 //	ALL
YDOS01B		MS24515-685A515 LAMP	00000000 96906	2	26-23-11 //	ALL
YDOS01D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	26-23-11 //	ALL
YDOS02+		S231T290-4062 SW-AFT CARGO FIRE	00000000 81205	1	26-23-11 //	280-299
YDOS02+	1	S231T290-4062 SW-AFT CARGO FIRE	00000000 81205	1	26-23-11 //	050-099, 153-199, 275-278
YDOS02+	1	S231T290-3062 SW-AFT CARGO FIRE	00000000 81205	1	26-23-11 //	150-152
YDOS02+	2	S231T290-5062 SW-AFT CARGO FIRE	00000000 81205	1	26-23-11 //	050-099, 153-199, 275-278
YDOS02+	2	S231T290-1062 SW-AFT CARGO FIRE	00000000 81205	1	26-23-11 //	150-152
YDOS02A		MS25237-387 LAMP	00000000 96906	2	26-23-11 //	ALL
YDOS02B		MS24515-685A515 LAMP	00000000 96906	2	26-23-11 //	ALL
YDOS02D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	26-23-11 //	ALL
YDOS03+		S231T290-4060 SW-BTL 1 DISCH	00000000 81205	1	26-23-11 //	280-299

EQUIPMENT LIST

D280T132

Section YDOS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDOS03+	1	S231T290-4060 SW-BTL 1 DISCH	00000000 81205	1	26-23-11 / /	050-099, 153-199, 275-278
YDOS03+	1	S231T290-3060 SW-BTL 1 DISCH	00000000 81205	1	26-23-11 / /	150-152
YDOS03+	2	S231T290-5060 SW-BTL 1 DISCH	00000000 81205	1	26-23-11 / /	050-099, 153-199, 275-278
YDOS03+	2	S231T290-1060 SW-BTL 1 DISCH	00000000 81205	1	26-23-11 / /	150-152
YDOS03A		MS25237-387 LAMP	00000000 96906	2	26-23-11 / /	ALL
YDOS03D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	26-23-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDOS00

Page 2 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDP++++		USEM00901 MODULE-HEATER CONTROL,CAPTAIN	00000000 81205	0	21-45-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDP+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDPS001		102TL2-12A SWITCH-MODE SELECT	00000000 91929	0	21-45-11 / /	ALL
YDPS002		102TL2-12A SWITCH-MODE SELECT	00000000 91929	0	21-45-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDPS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDQ++++		USEM00902 MODULE-HEATER CONTROL,F/O	00000000 81205	0	21-45-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDQ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDQS001		102TL2-12A SWITCH-MODE SELECT	00000000 91929	0	21-45-11 / /	ALL
YDQS002		102TL2-12A SWITCH-MODE SELECT	00000000 91929	0	21-45-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDQS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDS++++		USEM00033 PNL-FLIGHT RECORDER CONTROL	00000000 81205	0	31-31-11 SCH 31/31/01	ALL

EQUIPMENT LIST

D280T132

Section YDS+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDSK001		BACR13CF2A RELAY	00000000 81205	1	31-31-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDSK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDSL01+		S231T300-2269 LIGHT INDICATOR	00000000 81205	1	31-31-11 //	ALL
YDSL01A		MS25237-387 LAMP	00000000 96906	1	31-31-11 //	ALL
YDSL01B		MS25237-387 LAMP	00000000 96906	1	31-31-11 //	ALL
YDSL01D		434-093-001 DIODE/FUSE ASSY	00000000 81590	1	31-31-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDSL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDSS001		MS24658-31N SWITCH	00000000 96906	1	31-31-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDSS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDU++++		USEM00912 MODULE-BULK CARGO HEAT	00000000 81205	1	21-44-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YDU+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDUS01+		AC45-0019-1 SWITCH-MODE SELECT	00000000 81590	1	21-44-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YDUS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDW++++		USEM01087 PNL-HYD/GEN FIELD CONT	00000000 81205	0	27-13-11 SCH 27/13/01	ALL

EQUIPMENT LIST

D280T132

Section YDW+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDWK001	1	600-149-1001 TIMER	233T4240 15420	1	24-11-11 / /	ALL
YDWK001	2	600-1491S0 TIMER	233T4240 15420	1	24-11-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDWK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDWS01+	1	S231T290-3024 SW-INDICATOR	00000000 81205	1	27-13-11 //	ALL
YDWS01+	2	S231T290-1024 SW-INDICATOR	00000000 81205	1	27-13-11 //	ALL
YDWS01A		MS25237-387 LAMP-28 VOLTS	00000000 96906	2	27-13-11 //	ALL
YDWS01B		MS25237-685AS15 LAMP-5 VOLTS	00000000 96906	2	27-13-11 //	ALL
YDWS01D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	27-13-11 //	ALL
YDWS02+		S231T290-2024 SW-INDICATOR	00000000 81205	1	27-23-11 //	ALL
YDWS02A		MS25237-387 LAMP-28 VOLTS	00000000 96906	2	27-23-11 //	ALL
YDWS02B		MS25237-685AS15 LAMP-5 VOLTS	00000000 96906	2	27-23-11 //	ALL
YDWS02D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 96182	1	27-23-11 //	ALL
YDWS03+		S231T290-2024 SW-INDICATOR	00000000 81205	1	27-13-11 //	ALL
YDWS03A		MS25237-387 LAMP-28 VOLTS	00000000 96906	2	27-13-11 //	ALL
YDWS03B		MS25237-685AS15 LAMP-5 VOLTS	00000000 96906	2	27-13-11 //	ALL
YDWS03D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	27-13-11 //	ALL
YDWS04+	1	S231T290-3024 SW-INDICATOR	00000000 81205	1	27-23-11 //	ALL
YDWS04+	2	S231T290-1024 SW-INDICATOR	00000000 81205	1	27-23-11 //	ALL
YDWS04A		MS25237-387 LAMP-28 VOLTS	00000000 96906	2	27-23-11 //	ALL
YDWS04B		MS25237-685AS15 LAMP-5 VOLTS	00000000 96906	2	27-23-11 //	ALL

EQUIPMENT LIST

D280T132

Section YDWS00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDWS04D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	27-23-11 //	ALL
YDWS05+	1	S231T290-3024 SW-INDICATOR	00000000 81205	1	27-13-11 //	ALL
YDWS05+	2	S231T290-1024 SW-INDICATOR	00000000 81205	1	27-13-11 //	ALL
YDWS05A		MS25237-387 LAMP-28 VOLTS	00000000 96906	2	27-13-11 //	ALL
YDWS05B		MS25237-685AS15 LAMP-5 VOLTS	00000000 96906	2	27-13-11 //	ALL
YDWS05D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	27-13-11 //	ALL
YDWS06+	1	S231T290-3024 SW-INDICATOR	00000000 81205	1	27-23-11 //	ALL
YDWS06+	2	S231T290-1024 SW-INDICATOR	00000000 81205	1	27-23-11 //	050-099
YDWS06A		MS25237-387 LAMP-28 VOLTS	00000000 96906	2	27-23-11 //	ALL
YDWS06B		MS25237-685AS15 LAMP-5 VOLTS	00000000 96906	2	27-23-11 //	ALL
YDWS06D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	27-23-11 //	ALL
YDWS07+	5	S231T290-1073 SW-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDWS07+	1	S231T290-5073 SW-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDWS07+	2	S231T290-4073 SW-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDWS07+	3	S231T290-3073 SW-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDWS07+	4	S231T290-2073 SW-INDICATOR	00000000 81205	1	24-22-21 //	ALL
YDWS07A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-22-21 //	ALL

EQUIPMENT LIST

D280T132

Section YDWS00

Page 2

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDWS07B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-22-21 / /	ALL
YDWS07D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	24-22-21 / /	ALL
YDWS08+	5	S231T290-1073 SW-INDICATOR	00000000 81205	1	24-22-41 / /	ALL
YDWS08+	1	S231T290-5073 SW-INDICATOR	00000000 81205	1	24-22-41 / /	ALL
YDWS08+	2	S231T290-4073 SW-INDICATOR	00000000 81205	1	24-22-41 / /	ALL
YDWS08+	3	S231T290-3073 SW-INDICATOR	00000000 81205	1	24-22-41 / /	ALL
YDWS08+	4	S231T290-2073 SW-INDICATOR	00000000 81205	1	24-22-41 / /	ALL
YDWS08A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-22-41 / /	ALL
YDWS08B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-22-41 / /	ALL
YDWS08D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	24-22-41 / /	ALL
YDWS09+	5	S231T290-1073 SW-INDICATOR	00000000 81205	1	24-22-11 / /	ALL
YDWS09+	1	S231T290-5073 SW-INDICATOR	00000000 81205	1	24-22-11 / /	ALL
YDWS09+	2	S231T290-4073 SW-INDICATOR	00000000 81205	1	24-22-11 / /	ALL
YDWS09+	3	S231T290-3073 SW-INDICATOR	00000000 81205	1	24-22-11 / /	ALL
YDWS09+	4	S231T290-2073 SW-INDICATOR	00000000 81205	1	24-22-11 / /	ALL
YDWS09A		MS25237-387 LAMP-28 VOLT	00000000 96906	2	24-22-11 / /	ALL
YDWS09B		MS24515-685AS15 LAMP-5 VOLT	00000000 96906	2	24-22-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDWS00

Page 3

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YDWS09D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	24-22-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YDWS00

Page 4 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEC++++		USEM01186 MODULE-AFT LAVATORY	00000000 81205	1	33-26-11 SCH 33/26/01	275-299

EQUIPMENT LIST

D280T132

Section YEC+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YECCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 //	ALL

EQUIPMENT LIST

D280T132

Section YECC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YECD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	275-299
YECD007		BR5000-501 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YECD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YECK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	ALL
YECK002		BACR13CJ2 RELAY	00000000 81205	1	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YECK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YECM004		S283T018-32 BALLAST-MIRROR LTS	00000000 81205	1	33-26-11 / /	275-299
YECM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	275-299
YECM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-13 / /	275-299
YECM011		PU90-461 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	280-299

EQUIPMENT LIST

D280T132

Section YECM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YECRT01		BS06070-1 DOME LIGHT	00000000 S5065	1	33-26-11 / /	275-299
YECRT01A		2233 LAMP	00000000 08806	1	33-26-11 / /	275-299
YECRT02		BS060780-1 SIGN-RETURN TO SEAT	S417T106 S5065	1	33-24-11 / /	275-299
YECRT02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	275-299
YECRT05		BV03202-BV03203 MIRROR LIGHT	S417T106 17023	2	33-26-11 / /	275-299
YECRT05A		F15T12-WW LAMP	S417T106 08805	2	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YECR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YECS001		10C10B SWITCH-DOOR LATCH	S417T106 15438	1	33-26-11 / /	275-299
YECS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-13 / /	275-299
YECS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	ALL
YECS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YECS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YECV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-13 / /	275-299
YECV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-13 / /	275-299

EQUIPMENT LIST

D280T132

Section YECV00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEE++++		USEM01188 MODULE-AFT LAVATORY	00000000 81205	1	33-26-11 SCH 33/26/01	275-299

EQUIPMENT LIST

D280T132

Section YEE+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEECR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	ALL
YEECR02		1N5618 DIODE	00000000 12969	1	33-25-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YEEC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEED006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	275-299
YEED007		BR5000-501 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YEED00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEEK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	ALL
YEEK002		BACR13CJ2 RELAY	S417T106 81205	1	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YEEK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEEM004		S283T018-32 BALLAST	S417T106 81205	1	33-26-11 / /	275-299
YEEM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	275-299
YEEM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-12 / /	275-299
YEEM011		PU90-461 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YEEM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEERT01		BS060770-1 DOME LIGHT	S417T106 S5065	1	33-26-11 / /	275-299
YEERT01A		2233 LAMP	S417T106 08806	1	33-26-11 / /	275-299
YEERT02		BS060780-1 SIGN-RETURN TO SEAT	S417T106 S5065	1	33-24-11 / /	275-299
YEERT02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	275-299
YEERT05		BV03202-BV03203 MIRROR LIGHT	S417T106 17023	2	33-26-11 / /	275-299
YEERT05A		F15T12-WW LAMP	S417T106 08805	2	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YEER
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEES001		10C10B SWITCH-DOOR LATCH	S417T106 15438	1	33-26-11 / /	275-299
YEES002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-12 / /	275-299
YEES003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	ALL
YEES004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YEES00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEEV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-12 / /	275-299
YEEV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-12 / /	275-299

EQUIPMENT LIST

D280T132

Section YEEV00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEG++++		USEM10443 PNL-ENG FIRE CONTROL	00000000 81205	0	26-21-11 SCH 26/21/01	ALL

EQUIPMENT LIST

D280T132

Section YEG+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEGL01+		S231T300-2056 LIGHT IND-ENG OVHT,L	00000000 81590	1	26-11-12 //	277-299
YEGL01+	1	S231T300-2056 LIGHT IND-ENG OVHT,L	00000000 81590	1	26-11-12 //	050-099, 150-199, 275-276
YEGL01+	2	S231T300-1056 LIGHT IND-ENG OVHT,L	00000000 81590	1	26-11-12 //	050-099, 150-199, 275-276
YEGL01+	3	S231T300-1056 LIGHT IND-ENG OVHT,L	00000000 81590	1	26-11-12 //	050-099, 150-199, 275-276
YEGL01A		MS25237-387 LAMP	00000000 96906	1	26-11-12 //	ALL
YEGL01D		434-093-001 DIODE-FUSE ASSEMBLY	00000000 81590	1	26-11-12 //	ALL
YEGL02+		S231T300-2016 LIGHT IND-ENG BOTTLE NO. 1 DISCHARGED	00000000 81590	1	26-21-11 //	277-299
YEGL02+	1	S231T300-2016 LIGHT IND-ENG BOTTLE NO. 1 DISCHARGED	00000000 81590	1	26-21-11 //	050-099, 150-199, 275-276
YEGL02+	2	S231T300-1016 LIGHT IND-ENG BOTTLE NO. 1 DISCHARGED	00000000 81590	1	26-21-11 //	050-099, 150-199, 275-276
YEGL02+	3	S231T300-1016 LIGHT IND-ENG BOTTLE NO. 1 DISCHARGED	00000000 81590	1	26-21-11 //	050-099, 150-199, 275-276
YEGL02A		MS25237-387 LAMP	00000000 96906	1	26-21-11 //	ALL
YEGL02D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	26-21-11 //	ALL
YEGL03+		S231T300-2017 LIGHT IND-ENG BOTTLE NO. 2 DISCHARGED	00000000 81590	1	26-21-11 //	277-299
YEGL03+	1	S231T300-2017 LIGHT IND-ENG BOTTLE NO. 2 DISCHARGED	00000000 81590	1	26-21-11 //	050-099, 150-199, 275-276
YEGL03+	2	S231T300-1017 LIGHT IND-ENG BOTTLE NO. 2 DISCHARGED	00000000 81590	1	26-21-11 //	050-099, 150-199, 275-276
YEGL03+	3	S231T300-1017 LIGHT IND-ENG BOTTLE NO. 2 DISCHARGED	00000000 81590	1	26-21-11 //	050-099, 150-199, 275-276
YEGL03A		MS25237-387 LAMP	00000000 96906	1	26-21-11 //	ALL

EQUIPMENT LIST

D280T132

Section YEGL00

Page 1

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEGL03D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	26-21-11 //	ALL
YEGL04+		S231T300-2097 LIGHT IND-ENG OVHT,R	00000000 81590	1	26-11-22 //	277-299
YEGL04+	1	S231T300-2097 LIGHT IND-ENG OVHT,R	00000000 81590	1	26-11-22 //	050-099, 150-199, 275-276
YEGL04+	2	S231T300-1097 LIGHT IND-ENG OVHT,R	00000000 81590	1	26-11-22 //	050-099, 150-199, 275-276
YEGL04+	3	S231T300-1097 LIGHT IND-ENG OVHT,R	00000000 81590	1	26-11-22 //	050-099, 150-199, 275-276
YEGL04A		MS25237-387 LAMP	00000000 96906	1	26-11-22 //	ALL
YEGL04D		434-093-001 DIODE/FUSE ASSEMBLY	00000000 81590	1	26-11-22 //	ALL

EQUIPMENT LIST

D280T132

Section YEGL00
Page 2 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEH++++		USEM10445 PNL-FIRE/OVHT TEST	00000000 81205	0	26-11-11 SCH 26/11/01	ALL

EQUIPMENT LIST

D280T132

Section YEH+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEHS001		P4-10082-2 SW-ENG/APU/CARGO FIRE/OVHT TEST	00000000 21649	1	26-11-11 //	ALL
YEHS003		2PB901-T2 SW-WHEEL WELL FIRE TEST	00000000 91929	1	26-17-11 //	ALL
YEHS02+	5	S231T290-2063 SW IND-FAIL LIGHT RESET	00000000 96182	1	26-11-11 //	050-099, 150-199, 275-276
YEHS02+		S231T290-4063 SW IND-FAIL LIGHT RESET	00000000 96182	1	26-11-11 //	277-299
YEHS02+	1	S231T290-4063 SW IND-FAIL LIGHT RESET	00000000 96182	1	26-11-11 //	050-099, 150-199, 275-276
YEHS02+	2	S231T290-5063 SW IND-FAIL LIGHT RESET	00000000 96182	1	26-11-11 //	050-099, 150-199, 275-276
YEHS02+	3	S231T290-3063 SW IND-FAIL LIGHT RESET	00000000 96182	1	26-11-11 //	050-099, 150-199, 275-276
YEHS02+	4	S231T290-1063 SW IND-FAIL LIGHT RESET	00000000 96182	1	26-11-11 //	050-099, 150-199, 275-276
YEHS02A		MS25237-387 LAMP	00000000 96906	1	26-11-11 //	ALL
YEHS02D		851-30768-823 DIODE/FUSE ASSY	00000000 96182	1	26-11-11 //	ALL

EQUIPMENT LIST

D280T132

Section YEHS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEI++++		USEM10398 PNL-MISCELLANEOUS TEST	00000000 81205	0	28-43-11 SCH 26/18/01	ALL

EQUIPMENT LIST

D280T132

Section YEI+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEIS001		64AT22-7 SW-L AIR DATA/L STALL WARN TEST	00000000 91929	1	34-12-12 / /	ALL
YEIS002		64AT22-7 SW-R AIR DATA/R STALL WARN	00000000 91929	1	34-12-12 / /	ALL
YEIS003		64AT22-7 SW-CONFIG T O/LDG TEST	00000000 91929	1	31-51-41 / /	ALL
YEIS004		64AT22-7 SW-GROUND PROX TEST	00000000 91929	1	34-46-12 / /	ALL
YEIS005		68AT22-7 SW-WING ANTI-ICE/WINDOW PROBE HT TEST	00000000 91929	1	30-11-11 / /	ALL
YEIS007		68AT22-7 SW-YAW DMPR L&R TEST	233T4239 91929	1	22-21-11 P061-00/ /	ALL
YEIS008		68AT22-7 SW-EQUIP COOLING TEST/HYD GEN	00000000 91929	1	21-58-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YEIS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEJ++++		USEM00779 MODULE-WARNING DISPLAY,DISCRETE	00000000 81205	0	33-16-13 SCH 33/16/01	ALL

EQUIPMENT LIST

D280T132

Section YEJ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEJL01A		MS25287-387 LAMP	00000000 96906	12	33-16-13 / /	ALL
YEJL01D		434-C93-003 MODULE-DIODE/FUSE	00000000 81590	6	33-16-13 / /	ALL

EQUIPMENT LIST

D280T132

Section YEJL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEK++++		USEM00081 CONT PNL-AIR TRAFFIC,DUAL	00000000 81205	0	34-53-11 SCH 34/53/01	ALL

EQUIPMENT LIST

D280T132

Section YEK+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEKL01+		476-726-1015-007 LIGHT INDICATOR	00000000 81590	1	34-53-11 / /	ALL
YEKL01A		MS25237-387 LAMP	00000000 96906	2	34-53-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YEKL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEN++++		USEM00614 RAM-AIR TURBINE	00000000 81205	0	29-21-31 SCH 29/11/00	150-199, 275-299

EQUIPMENT LIST

D280T132

Section YEN+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YENS001		1HM1 SW-STRUT ANGLE	00000000 91929	1	29-21-31 / /	150-199, 275-299
YENS002		1HM1 SW-RAT CTR LIMIT	00000000 91929	1	29-21-31 / /	150-199, 275-299

EQUIPMENT LIST

D280T132

Section YENS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEOB001		DC600A CASSETTE-QUICK ACCESS RECORDER	284T0122 575301	1	31-35-16 //	ALL

EQUIPMENT LIST

D280T132

Section YEOB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YER++++		USEM01216 PNL-RESERVE BRAKE & STEERING	00000000 81205	0	29-21-32 SCH 29/11/01	ALL

EQUIPMENT LIST

D280T132

Section YER+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YERK01+		BACR13CF2 RELAY-ISOLATION VALVE	00000000 81205	1	29-21-32 / /	ALL
YERK02+		10167-3000-BT MODULE-TIME DELAY	00000000 08719	1	29-21-32 / /	ALL
YERK03+		3SAM6015M2 RELAY-LOW QUANTITY LATCH	00000000 01226	1	29-21-32 / /	ALL
YERK04+		BACR13CJ2 RELAY-POWER SENSE	65B00000 81205	1	29-21-32 / /	ALL
YERK05+		600-154-1002 RELAY-TIME DELAY	65B00000 00000	1	29-21-32 / /	ALL

EQUIPMENT LIST

D280T132

Section YERK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YERL01+	1	S231T300-2301 LT IND-RES BRK & STR ISLN	00000000 81205	1	29-21-32 / /	ALL
YERL01+	2	S231T300-1301 LT IND-RES BRK & STR ISLN	00000000 81205	1	29-21-32 / /	ALL
YERL01A		MS25237-387 LAMP-28V	00000000 96906	2	29-21-32 / /	ALL
YERL01D		434-093-001 DIODE/FUSE MODULE	00000000 81590	1	29-21-32 / /	ALL

EQUIPMENT LIST

D280T132

Section YERL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YERS01+		MS24523-23 SW-RES BRK & STR RESET/DISABLE	00000000 96906	1	29-21-32 / /	ALL

EQUIPMENT LIST

D280T132

Section YERS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEU++++		SEYEUM001-M002-YEUTS01-TS02 MODULE-AFT WASTE TANK LEVEL SNSR(M00965)	00000000 81205	0	38-32-11 SCH 38/30/01	050-099, 150-157, 275-299
YEU++++		SEYEUM001-M002-YEUTS01-TS02 MODULE-AFT WASTE TANK LEVEL SNSR(M00965)	00000000 81205	0	38-32-12 SCH 38/30/01	162-199

EQUIPMENT LIST

D280T132

Section YEU+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEUM001	9	0111-0013 SNSR-CONT & LOGIC PRRB11888	00000000 86831	1	38-32-11 //	150-154, 275
YEUM001		S417T108-2 SENSOR-CONT & LOGIC	00000000 81205	1	38-32-11 //	050-099
YEUM001		S417T108-11 SNSR-CONT & LOGIC	00000000 59885	1	38-32-11 //	150-154, 275
YEUM001		S417T108-2 SNSR-CONT & LOGIC	00000000 81205	1	38-32-11 //	155, 162-165, 276
YEUM001		S417T108-7 SENSOR-CONT & LOGIC	00000000 59885	1	38-32-11 //	156-157, 166-199, 277-299
YEUM002		4081-0007-3 WIRE HARNESS	00000000 86831	1	38-32-11 //	050-099, 150-155, 162-165, 275-276
YEUM002		0174-0005 WIRE HARNESS	00000000 59885	1	38-32-11 //	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section YEUM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEUTS01	9	S417T108-3 LEVEL SNSR A	00000000 81205	1	38-32-11 //	150-154
YEUTS01	9	S417T108-3 LEVEL SNSR A (SB 38-0035)	00000000 81205	1	38-32-11 //	275
YEUTS01		S417T108-3 LEVEL SNSR A	00000000 81205	1	38-32-11 //	050-099, 155-199, 276-299
YEUTS01		0111-0005-4 LEVEL SNSR A	00000000 86831	1	38-32-11 //	150-154, 275
YEUTS02	9	S417T108-3 LEVEL SNSR B	00000000 81205	1	38-32-11 //	150-154
YEUTS02	9	S417T108-3 LEVEL SNSR B (SB 38-0035)	00000000 81205	1	38-32-11 //	275
YEUTS02		S417T108-3 LEVEL SNSR B	00000000 81205	1	38-32-11 //	050-099, 155-199, 276-299
YEUTS02		0111-0005-4 LEVEL SNSR B	00000000 86831	1	38-32-11 //	150-154, 275
YEUTS03	9	S417T108-8 SENSOR-CONTINUOUS LEVEL (SB 38-0035)	00000000 59885	1	38-32-11 //	275-276
YEUTS03		S417T108-8 SENSOR-CONTINUOUS LEVEL	00000000 59885	1	38-32-11 //	050, 156-157, 166- 199, 277-299

EQUIPMENT LIST

D280T132

Section YEUT
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEV++++		SEYEVM001-M002-YEVTS01-TS02 MODULE-FWD WASTE TANK LEVEL SNSR(M00964)	00000000 81205	0	38-32-11 SCH 38/30/01	ALL

EQUIPMENT LIST

D280T132

Section YEV+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEVM001	9	0111-0013 SNSR-CONT & LOGIC PRRB11888	00000000 86831	1	38-32-11 //	150-154, 275
YEVM001	9	S417T108-2 SNSR-CONT & LOGIC	00000000 81205	1	38-32-11 //	276
YEVM001		S417T108-2 SENSOR-CONT & LOGIC	00000000 81205	1	38-32-11 //	050-099
YEVM001		0111-0006-3 SNSR CONT & LOGIC	00000000 86831	1	38-32-11 //	150-154, 275
YEVM001		S417T108-2 SNSR CONT & LOGIC	00000000 81205	1	38-32-11 //	155, 162-165, 276
YEVM001		S417T108-7 SENSOR-CONT & LOGIC	00000000 59885	1	38-32-11 //	156-157, 166-199, 277-299
YEVM002		4081-0007-3 WIRE HARNESS	00000000 86831	1	38-32-11 //	050-099, 150-155, 162-165, 275-276
YEVM002		01774-0005 WIRE HARNESS	00000000 59885	1	38-32-11 //	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section YEVM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEVTS01	9	S417T108-3 LEVEL SNSR A	00000000 81205	1	38-32-11 //	150-154
YEVTS01	9	S417T108-3 LEVEL SNSR A (SB 38-0035)	00000000 81205	1	38-32-11 //	275
YEVTS01		S417T108-3 LEVEL SNSR A	00000000 81205	1	38-32-11 //	050-099, 155-199, 276-299
YEVTS01		0111-0005-4 LEVEL SNSR A	00000000 86831	1	38-32-11 //	150-154, 275
YEVTS02	9	S417T108-3 LEVEL SNSR B	00000000 81205	1	38-32-11 //	150-154
YEVTS02	9	S417T108-3 LEVEL SNSR B (SB 38-0035)	00000000 81205	1	38-32-11 //	275
YEVTS02		S417T108-3 LEVEL SNSR B	00000000 81205	1	38-32-11 //	050-099, 155-199, 276-299
YEVTS02		0111-0005-4 LEVEL SNSR B	00000000 86831	1	38-32-11 //	150-154, 275
YEVTS03	9	S417T108-8 SENSOR-CONTINUOUS LEVEL (SB38-0035)	00000000 59885	1	38-32-11 //	275-276
YEVTS03		S417T108-8 SENSOR-CONTINUOUS LEVEL	00000000 59885	1	38-32-11 //	156-157, 166-199, 277-299

EQUIPMENT LIST

D280T132

Section Y EVT
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEW++++		USEM00730 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YEW+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEWB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YEWB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEX++++		USEM00732 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YEX+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEXB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YEXB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEY++++		USEM00734 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YEY+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEYB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YEYB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEZ++++		USEM00735 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YEZ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YEZB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YEZB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFA++++		USEM00737 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFA+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFAB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YFAB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFB++++		USEM00739 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFB+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFBB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YFBB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFD++++		USEM01208 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFD+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFDB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YFDB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFE++++		USEM01209 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFE+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFEB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YFEB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFF++++		USEM01210 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-11 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFF+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFFB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YFFB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFG++++		USEM00731 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-21 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFG+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFGB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YFGB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFH++++		USEM00733 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-21 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFH+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFHB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YFHB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFI++++		USEM00736 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-21 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFI+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFIB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YFIB00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFJ++++		USEM00738 POWER SUPPLY-EMER LTS	00000000 81205	0	33-51-21 SCH 33/51/00	ALL

EQUIPMENT LIST

D280T132

Section YFJ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFJB001		2013-1 BATTERY ASSEMBLY	00000000 60540	1	33-51-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YFJB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFU++++		USEB17 BOTTLE-FEXT 1	00000000 81205	0	26-21-11 SCH 26/21/11	ALL

EQUIPMENT LIST

D280T132

Section YFU+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFUB001		30903896 SQUIB-L ENG	00000000 05167	1	26-21-11 / /	050-099, 155-199, 275-299
YFUB001		30903874 SQUIB-L ENG	00000000 05167	1	26-21-11 / /	150-154
YFUB002		30903874 SQUIB-R ENG	00000000 05167	1	26-21-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YFUB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFV++++		USEB18 BOTTLE-FEXT 2	00000000 81205	0	26-21-11 SCH 26/21/11	ALL

EQUIPMENT LIST

D280T132

Section YFV+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFVB001		30903896 SQUIB-L ENG	00000000 05167	1	26-21-11 / /	050-099, 155-199, 275-299
YFVB001		30903874 SQUIB-L ENG	00000000 05167	1	26-21-11 / /	150-154
YFVB002		30903874 SQUIB-R ENG	00000000 05167	1	26-21-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YFVB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFW++++		USEB25 BOTTLE-APU FEXT 1	00000000 81205	0	26-22-21 SCH 26/22/21	ALL

EQUIPMENT LIST

D280T132

Section YFW+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFWB001		30903856 SQUIB	00000000 05167	1	26-22-21 / /	050-099, 150-199
YFWB001		262299 SQUIB	00000000 33525	1	26-22-21 / /	275-276
YFWB001		30903874 SQUIB	00000000 33525	1	26-22-21 / /	277-299

EQUIPMENT LIST

D280T132

Section YFWB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFX++++		USEB138 BOTTLE-APU FEXT 2	00000000 81205	0	26-22-21 SCH 26/22/21	275-299

EQUIPMENT LIST

D280T132

Section YFX+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFXB001		262299 SQUIB	00000000 33525	1	26-22-21 / /	275-276
YFXB001		30903874 SQUIB	00000000 33525	1	26-22-21 / /	277-299

EQUIPMENT LIST

D280T132

Section YFXB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFY++++		USEB19 FEXT BTL 1-CARGO COMPT-LWR LOBE	00000000 81205	0	26-23-11 SCH 26/23/11	ALL

EQUIPMENT LIST

D280T132

Section YFY+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFYB001		30903889 SQUIB-FWD COMPT	00000000 05167	1	26-23-11 / /	050-099, 155-199, 275-299
YFYB001		30903852 SQUIB-FWD COMPT	00000000 05167	1	26-23-11 / /	150-154
YFYB002		30903852 SQUIB-AFT COMPT	00000000 05167	1	26-23-11 / /	ALL

EQUIPMENT LIST

D280T132

Section YFYB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFZ++++		USEB20 FEXT BTL 2-CARGO COMPT-LWR LOBE	00000000 81205	0	26-23-12 SCH 26/23/11	ALL

EQUIPMENT LIST

D280T132

Section YFZ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YFZB001		30903889 SQUIB-FWD COMPT	00000000 05167	1	26-23-12 / /	050-099, 155-199, 275-299
YFZB001		30903852 SQUIB-FWD COMPT	00000000 05167	1	26-23-12 / /	150-154
YFZB002		30903852 SQUIB-AFT COMPT	00000000 05167	1	26-23-12 / /	ALL

EQUIPMENT LIST

D280T132

Section YFZB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGA++++		USEB231 FEXT BTL 2A-	00000000 81205	0	26-23-12 SCH 26/23/12	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YGA+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGAB001		30903889 SQUIB-FWD COMPT	00000000 05167	1	26-23-12 / /	050-099, 155-199, 275-299
YGAB002		30903852 SQUIB-AFT COMPT	00000000 05167	1	26-23-12 / /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YGAB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGBRT01A		2233 LAMP	00000000 08806	1	33-26-11 / /	280-299
YGBRT02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	280-299
YGBRT05A		F15T12-WW LAMP	00000000 08805	2	33-26-11 / /	280-299

EQUIPMENT LIST

D280T132

Section YGBR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGI++++		USEM01289 MODULE-ATTND WORK LIGHT	00000000 81205	1	33-22-32 / /	150-199

EQUIPMENT LIST

D280T132

Section YGI+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGIL01+		S417T505-1 LIGHT-MID ATTND WORK	00000000 81205	1	33-22-32 / /	150-199
YGIL01A		1308 LAMP	00000000 08806	2	33-22-32 / /	150-199

EQUIPMENT LIST

D280T132

Section YGIL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGIS001		L-18366 SWITCH-MID ATTND WORK LIGHT	00000000 90634	1	33-22-32 / /	150-199

EQUIPMENT LIST

D280T132

Section YGIS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGK++++		USEM00933 STOWAGE-OXY MASK,CAPT	00000000 53655	0	23-51-11 SCH 23/51/01	ALL

EQUIPMENT LIST

D280T132

Section YGK+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGKM01+		MC10-25-104 MASK-OXYGEN,CAPT	00000000 53655	1	23-51-11 //	ALL

EQUIPMENT LIST

D280T132

Section YGKM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGL++++		USEM00934 STOWAGE-OXY MASK-F/O	00000000 53655	0	23-51-21 SCH 23/51/01	ALL

EQUIPMENT LIST

D280T132

Section YGL+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGLM01+		MC10-25-104 MASK-OXYGEN,F/O	00000000 53655	1	23-51-21 / /	ALL

EQUIPMENT LIST

D280T132

Section YGLM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGM++++		USEM00936 STOWAGE-OXY MASK,FIRST OBSERVER	00000000 53655	0	23-51-41 SCH 23/51/01	ALL

EQUIPMENT LIST

D280T132

Section YGM+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGMM01+		MC10-25-104 MASK-OXYGEN,FIRST OBSERVER	00000000 53655	1	23-51-41 / /	ALL

EQUIPMENT LIST

D280T132

Section YGMM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGT++++		USEM01312 MODULE-MID CENTER LAVATORY	417T1000	0	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YGT+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGTCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	275-299
YGTCR02		1N5618 DIODE	00000000 12969	1	33-25-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YGTC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGTD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	275-299
YGTD007		BR5000-501 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YGTD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGTK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	275-299
YGTK002		BACR13CJ2 RELAY	417T0000 81205	1	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YGTK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGTM003		S283T018-30 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	275-299
YGTM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	275-299
YGTM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-11 / /	275-276, 280-299
YGTM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-13 / /	277-278
YGTM011		PU90-461 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YGTM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGTRT01		BS060770-1 DOME LIGHT	417T1000 S5065	1	33-26-11 / /	275-299
YGTRT01A		2233 LAMP	417T1000 08806	1	33-26-11 / /	275-299
YGTRT02		BS060780-1 SIGN-RETURN TO SEAT	00000000 S5065	1	33-24-11 / /	275-299
YGTRT02A		MS25237-387 LAMP	00000000 96906	8	33-24-11 / /	275-299
YGTRT04		VB03202-BV03203 MIRROR LIGHT	S417T106 17023	2	33-26-11 / /	275-299
YGTRT04A		F20T12-WW LAMP	S417T106 08805	2	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YGTR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGTS001		10C10B SWITCH-DOOR LATCH	417T1000 15438	1	33-26-11 / /	275-299
YGTS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-11 / /	275-276, 280-299
YGTS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-13 / /	277-278
YGTS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	275-299
YGTS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	275-299
YGTS010		2100-1 SW-HANDICAP LITE	S417T106 96906	1	33-26-11 / /	275-299

EQUIPMENT LIST

D280T132

Section YGTS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YGTV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-11 / /	275-276, 280-299
YGTV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-13 / /	277-278
YGTV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-11 / /	275-276, 280-299
YGTV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-13 / /	277-278

EQUIPMENT LIST

D280T132

Section YGTV00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHG++++		USEM01390 MODULE-EEC MAINT	00000000	0	73-21-11 //	ALL

EQUIPMENT LIST

D280T132

Section YHG+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHGS001		MS24658-23D SWITCH-L ENG POWER	00000000 81205	1	73-21-11 / /	050-099, 150-157, 275-276, 280-299
YHGS001		MS24523-23 SWITCH-L ENG POWER	00000000 81205	1	73-21-11 / /	162-199, 277-278
YHGS002		MS24658-23D SWITCH-L ENG CH SEL	00000000 81205	1	73-21-11 / /	050-099, 150-157, 280-299
YHGS002		MS24523-23 SWITCH-R ENG POWER	00000000 81205	1	73-21-11 / /	162-199, 277-278
YHGS003		MS24658-23D SWITCH-R ENG POWER	00000000 81205	1	73-21-11 / /	050-099, 150-157, 275-276, 280-299
YHGS004		MS24658-23D SWITCH-R ENG CH SEL	00000000 81205	1	73-21-11 / /	050-099, 150-157, 280-299

EQUIPMENT LIST

D280T132

Section YHGS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHI++++		USEM1460 MODULE-ATTND WORK LT	417T3310 81205	1	33-22-31 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHI+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHIL01+		S417T505-1 LIGHT-MID ATTND WORK	00000000 81205	1	33-22-31 / /	050-099, 150-199
YHIL01A		1308 LAMP	00000000 08806	3	33-22-31 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHIL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHIS001		L-18366 SWITCH-MID ATTND WORK LIGHT	00000000 90634	1	33-22-31 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHIS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHQM003	9	8TJ163AAB1 SENSOR-N1 (GE SB 72-0298)	00000000 07482	2	77-12-11 / /	150-153
YHQM003		9221M80P01 SENSOR-N1	00000000 07482	2	77-12-11 / /	150-153

EQUIPMENT LIST

D280T132

Section YHQM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHW++++		USEM10761 CONT PNL-EEC	00000000 81205	0	73-21-11 SCH 73/21/06	ALL

EQUIPMENT LIST

D280T132

Section YHW+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHWS01+	1	S231T290-4086 SW IND-L EEC CONT	00000000 81205	1	73-21-11 //	ALL
YHWS01+	2	S231T290-5086 SW IND-L EEC CONT	00000000 81205	1	73-21-11 //	ALL
YHWS01+	3	S231T290-3086 SW IND-L EEC CONT	00000000 81205	1	73-21-11 //	ALL
YHWS01+	4	S231T290-1086 SW IND-L EEC CONT	00000000 81205	1	73-21-11 //	ALL
YHWS01A		MS25237-387 LAMP,28V-L EEC CONT SW	00000000 96182	2	73-21-11 //	ALL
YHWS01B		MS24515-685AS15 LAMP-5V-L EEC CONT SW	00000000 96906	2	73-21-11 //	ALL
YHWS01D		851-30768-823 DIODE/FUSE ASSY-L EEC CONT SW	00000000 96182	1	73-21-11 //	ALL
YHWS02+	1	S231T290-4086 SW IND-R EEC CONT	00000000 81205	1	73-21-11 //	ALL
YHWS02+	2	S231T290-5086 SW IND-R EEC CONT	00000000 81205	1	73-21-11 //	ALL
YHWS02+	3	S231T290-3086 SW IND-R EEC CONT	00000000 81205	1	73-21-11 //	ALL
YHWS02+	4	S231T290-1086 SW IND-R EEC CONT	00000000 81205	1	73-21-11 //	ALL
YHWS02A		MS25237-387 LAMP,28V-R EEC CONT SW	00000000 96906	2	73-21-11 //	ALL
YHWS02B		MS24515-685AS15 LAMP,5V-R EEC CONT SW	00000000 96906	2	73-21-11 //	ALL
YHWS02D		851-30768-823 DIODE/FUSE ASSY-R EEC CONT SW	00000000 96182	1	73-21-11 //	ALL

EQUIPMENT LIST

D280T132

Section YHWS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHY++++		USEM01584 LAV MS-LF	417T12XX 81205	1	33-26-11 0654+121/200/L050	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHY+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHYB001		3100-101-3 THERMAL SWITCH	S417T106 14604	1	30-71-02 / /	150-199
YHYB002		2372-2 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YHYB003		2372-23 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YHYB004		2372-23 HEATER TAPE-S/O	S417T106 98085	1	30-71-02 / /	150-199
YHYB005		2372-24 HEATER TAPE-TEE	S41TT106 98085	1	30-71-02 / /	150-199
YHYB010		3051-110-7-1-71 HEATER RIBBON-RINSE	S417T106 98085	1	30-71-02 / /	150-199

EQUIPMENT LIST

D280T132

Section YHYB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHYCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHYC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHYD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	050-099, 150-199
YHYD007		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	050-099
YHYD007		BR5000-506 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	150-199

EQUIPMENT LIST

D280T132

Section YHYD00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHYK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	050-099, 150-199
YHYK002		BACR13CJ2 RELAY	417T0000 81205	1	33-26-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHYK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHYM004		S283T018-32 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	050-099, 150-199
YHYM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	050-099, 150-199
YHYM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-12 / /	050-099, 150-199
YHYM011		PU90-419 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHYM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHYRT01		BS060770-1 DOME LIGHT	417T1000 S5065	1	33-26-11 / /	050-099, 150-199
YHYRT01A		2233 LAMP	417T1000 08806	1	33-26-11 / /	050-099, 150-199
YHYRT02		BS060780-1 SIGN-RETURN TO SEAT	S417T106 S5065	1	33-24-11 / /	050-099, 150-199
YHYRT02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	050-099, 150-199
YHYRT05		BV03202-BV03203 MIRROR LIGHT	417T1000 17023	2	33-26-11 / /	050-099, 150-199
YHYRT05A		F15T12-WW LAMP	417T1000 08805	2	33-26-11 / /	050-099, 150-199
YHYRT06		P90-90720-1 LT-LAV SMOKE WARNING	417T0106 S5065	1	26-13-11 / /	155-157, 164-199

EQUIPMENT LIST

D280T132

Section YHYR
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHYS001		10C10B SWITCH-DOOR LATCH	417T1000 15438	1	33-26-11 / /	050-099, 150-199
YHYS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-12 / /	050-099, 150-199
YHYS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	050-099, 150-199
YHYS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHYS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHYV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-12 / /	050-099, 150-199
YHYV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-12 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHYV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHZ++++		USEM01585 LAV MC-F	417T12XX 81205	1	33-26-11 0654+76/200/0000	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHZ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHZB001		3100-101-3 THERMAL SWITCH	S417T106 14604	1	30-71-02 / /	150-199
YHZB002		2372-2 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YHZB003		2372-23 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YHZB004		2372-23 HEATER TAPE-S/O	S417T106 98085	1	30-71-02 / /	150-199
YHZB005		2372-24 HEATER TAPE-TEE	S417T106 98085	1	30-71-02 / /	150-199
YHZB010		3051-110-7-1-71 HEATER RIBBON-RINSE	S417T106 98085	1	30-71-02 / /	150-199

EQUIPMENT LIST

D280T132

Section YHZB00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHZCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHZC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHZD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	050-099, 150-199
YHZD007		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	050-099, 150-199
YHZD008		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	050-099, 150-199
YHZD009		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHZD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHZK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	050-099, 150-199
YHZK002		BACR13CJ2 RELAY	417T0000 81205	1	33-26-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHZK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHZM004		S283T018-32 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	050-099, 150-199
YHZM006		S283T018-32 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	050-099, 150-199
YHZM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	050-099, 150-199
YHZM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-13 / /	050-099, 150-199
YHZM011		PU90-419 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHZM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHZRT01		BS060770-1 DOME LIGHT	417T1000 S5065	1	33-26-11 / /	050-099, 150-199
YHZRT01A		2233 LAMP	417T1000 08806	1	33-26-11 / /	050-099, 150-199
YHZRT02		BS060780-1 SIGN-RETURN TO SEAT	S417T106 S5065	1	33-24-11 / /	050-099, 150-199
YHZRT02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	050-099, 150-199
YHZRT05		BV03202-BV03203 MIRROR LIGHT	417T1000 17023	4	33-26-11 / /	050-099, 150-199
YHZRT05A		F15T12-WW LAMP	417T1000 08805	4	33-26-11 / /	050-099, 150-199
YHZRT06		P90-90720-1 LT-LAV SMOKE WARNING	417T0106 S5065	1	26-13-11 / /	155-157, 164-199

EQUIPMENT LIST

D280T132

Section YHZR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHVS001		10C10B SWITCH-DOOR LATCH	417T1000 15438	1	33-26-11 / /	050-099, 150-199
YHVS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-13 / /	050-099, 150-199
YHVS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	050-099, 150-199
YHVS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	050-099, 150-199
YHVS006		M8805125-001 SWITCH-HANDICAPPED LIGHT	417T0000 96906	1	33-26-11 / /	050-099

EQUIPMENT LIST

D280T132

Section YHVS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YHZV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-13 / /	050-099, 150-199
YHZV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-13 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YHZV00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIA++++		USEM01586 LAV MS-RF	417T12XX 81205	1	33-26-11 0654+121/200/R050	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIA+
Page 1 End
Aug 05/2009



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIAB001		3100-101-3 THERMAL SWITCH	S417T106 14604	1	30-71-02 / /	150-199
YIAB002		2372-2 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YIAB003		2372-23 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YIAB004		2372-23 HEATER TAPE-S/O	S417T106 98085	1	30-71-02 / /	150-199
YIAB005		2372-24 HEATER TAPE-TEE	S417T106 98085	1	30-71-02 / /	150-199
YIAB010		3051-110-7-1-71 HEATER RIBBON-RINSE	S417T106 98085	1	30-71-02 / /	150-199

EQUIPMENT LIST

D280T132

Section YIAB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIACR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIAC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIAD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	050-099, 150-199
YIAD007		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIAD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIAK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	050-099, 150-199
YIAK002		BACR13CJ2 RELAY	417T0000 81205	1	33-26-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIAK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIAM004		S283T018-32 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	050-099, 150-199
YIAM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	050-099, 150-199
YIAM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-13 / /	050-099, 150-199
YIAM011		PU90-419 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIAM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIART01		BS060770-1 DOME LIGHT	417T1000 S5065	1	33-26-11 / /	050-099, 150-199
YIART01A		2233 LAMP	417T1000 08806	1	33-26-11 / /	050-099, 150-199
YIART02		BS060780-1 SIGN-RETURN TO SEAT	S417T106 S5065	1	33-24-11 / /	050-099, 150-199
YIART02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	050-099, 150-199
YIART05		BV03202-BV03203 MIRROR LIGHT	417T1000 17023	4	33-26-11 / /	050-099, 150-199
YIART05A		F15T12-WW LAMP	417T1000 08805	4	33-26-11 / /	050-099, 150-199
YIART06		P90-90720-1 LT-LAV SMOKE WARNING	417T0106 S5065	1	26-13-11 / /	155-157, 164-199

EQUIPMENT LIST

D280T132

Section YIAR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIAS001		10C10B SWITCH-DOOR LATCH	417T1000 15438	1	33-26-11 / /	050-099, 150-199
YIAS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-13 / /	050-099, 150-199
YIAS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	050-099, 150-199
YIAS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIAS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIAV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-13 / /	050-099, 150-199
YIAV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-13 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIAV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIB++++		USEM01587 LAV MS-LA	417T1204 81205	1	33-26-11 0967/200/L050	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIB+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIBB001		3100-101-3 THERMAL SWITCH	S417T106 14604	1	30-71-02 / /	150-199
YIBB002		2372-2 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YIBB003		2372-23 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YIBB004		2372-23 HEATER TAPE-S/O	S417T106 98085	1	30-71-02 / /	150-199
YIBB005		2372-24 HEATER TAPE-TEE	S417T106 98085	1	30-71-02 / /	150-199
YIBB010		3051-110-7-1-71 HEATER RIBBON-RINSE	S417T106 98085	1	30-71-02 / /	150-199

EQUIPMENT LIST

D280T132

Section YIBB00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIBCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIBC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIBD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	050-099, 150-199
YIBD007		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIBD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIBK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	050-099, 150-199
YIBK002		BACR13CJ2 RELAY	417T0000 81205	1	33-26-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIBK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIBM004		S283T018-32 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	050-099, 150-199
YIBM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	050-099, 150-199
YIBM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-12 / /	050-099, 150-199
YIBM011		PU90-419 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIBM00
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIBRT01		BS060770-1 DOME LIGHT	417T1000 S5065	1	33-26-11 / /	050-099, 150-199
YIBRT01A		2233 LAMP	417T1000 08806	1	33-26-11 / /	050-099, 150-199
YIBRT02		BS060780-1 SIGN-RETURN TO SEAT	S417T106 S5065	1	33-24-11 / /	050-099, 150-199
YIBRT02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	050-099, 150-199
YIBRT05		BV03202-BV03203 MIRROR LIGHT	417T1000 17023	4	33-26-11 / /	050-099, 150-199
YIBRT05A		F15T12-WW LAMP	417T1000 08805	4	33-26-11 / /	050-099, 150-199
YIBRT06		P90-90720-1 LT-LAV SMOKE WARNING	417T0106 S5065	1	26-13-11 / /	155-157, 164-199

EQUIPMENT LIST

D280T132

Section YIBR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIBS001		10C10B SWITCH-DOOR LATCH	417T1000 15438	1	33-26-11 / /	050-099, 150-199
YIBS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-12 / /	050-099, 150-199
YIBS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	050-099, 150-199
YIBS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIBS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIBV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-12 / /	050-099, 150-199
YIBV002		ZMV2 FLUSH VALVE (REF M9)	00000000 62701	1	38-32-12 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIBV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIC++++		USEM01588 LAV MC-A	417T1204 81205	1	33-26-11 0970/200/0000	150-199

EQUIPMENT LIST

D280T132

Section YIC+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YICB001		3100-101-3 THERMAL SWITCH	S417T106 14604	1	30-71-02 / /	150-199
YICB002		2372-2 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YICB003		2372-23 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YICB004		2372-23 HEATER TAPE-S/O	S417T106 98085	1	30-71-02 / /	150-199
YICB005		2372-24 HEATER TAPE-TEE	S417T106 98085	1	30-71-02 / /	150-199
YICB010		3051-110-7-1-71 HEATER RIBBON-RINSE	S417T106 98085	1	30-71-02 / /	150-199

EQUIPMENT LIST

D280T132

Section YICB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YICCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	150-199

EQUIPMENT LIST

D280T132

Section YICC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YICD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	150-199
YICD007		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	150-199
YICD008		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	150-199
YICD009		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	150-199

EQUIPMENT LIST

D280T132

Section YICD00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YICK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	150-199
YICK002		BACR13CJ2 RELAY	417T0000 81205	1	33-26-11 / /	150-199

EQUIPMENT LIST

D280T132

Section YICK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YICM004		S283T018-32 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	150-199
YICM006		S283T018-32 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	150-199
YICM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	150-199
YICM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-12 / /	150-199
YICM011		PU90-419 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YICM00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YICRT01		BS060770-1 DOME LIGHT	417T1000 S5065	1	33-26-11 / /	150-199
YICRT01A		2233 LAMP	417T1000 08806	1	33-26-11 / /	150-199
YICRT02		BS060780-1 SIGN-RETURN TO SEAT	S417T106 S5065	1	33-24-11 / /	150-199
YICRT02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	150-199
YICRT05		BV03202-BV03203 MIRROR LIGHT	417T1000 17023	4	33-26-11 / /	150-199
YICRT05A		F15T12-WW LAMP	417T1000 08805	4	33-26-11 / /	150-199
YICRT06		P90-90720-1 LT-LAV SMOKE WARNING	417T0106 S5065	1	26-13-11 / /	155-157, 164-199

EQUIPMENT LIST

D280T132

Section YICR
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YICS001		10C10B SWITCH-DOOR LATCH	417T1000 15438	1	33-26-11 / /	150-199
YICS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-12 / /	150-199
YICS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	150-199
YICS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	150-199
YICS005		MS25253-1 SWITCH-HANDICAPPED LIGHT	00000000 96906	1	33-26-11 / /	150-199

EQUIPMENT LIST

D280T132

Section YICS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YICV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-12 / /	150-199
YICV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-12 / /	150-199

EQUIPMENT LIST

D280T132

Section YICV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YID++++		USEM01589 LAV MS-RA	417T1204 81205	1	33-26-11 0967/200/R050	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YID+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIDB001		3100-101-3 THERMAL SWITCH	S417T106 14604	1	30-71-02 / /	150-199
YIDB002		2372-2 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YIDB003		2372-23 HEATER TAPE-FAUCET	S417T106 98085	1	30-71-02 / /	150-199
YIDB004		2372-23 HEATER TAPE-S/O	S417T106 98085	1	30-71-02 / /	150-199
YIDB005		2372-24 HEATER TAPE-TEE	S417T106 98085	1	30-71-02 / /	150-199
YIDB010		3051-110-7-1-71 HEATER RIBBON-RINSE	S417T106 98085	1	30-71-02 / /	150-199

EQUIPMENT LIST

D280T132

Section YIDB00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIDCR01		1N4148-1 DIODE	00000000 13715	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIDC
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIDD006		346-1 CONVERTER-FREQUENCY 400HZ/60HZ	284T0187 16340	1	25-42-11 / /	050-099, 150-199
YIDD007		BR5000-503 OUTLET-SHAVER	284T0187 17023	1	25-42-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIDD00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIDK001		BACR13CD2 SOCKET-ATTENDANT CALL	00000000 81205	1	33-25-11 / /	050-099, 150-199
YIDK002		BACR13CJ2 RELAY	417T0000 81205	1	33-26-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIDK00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIDM004		S283T018-32 BALLAST-MIRROR LTS	417T1000 81205	1	33-26-11 / /	050-099, 150-199
YIDM008		60B50064-2 WATER HEATER	00000000 81205	1	38-13-11 / /	050-099, 150-199
YIDM009		7800052 FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-13 / /	050-099, 150-199
YIDM011		PU90-419 DETECTOR-SMOKE	S417T106 S5065	1	26-13-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIDM00
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIDRT01		BS060770-1 DOME LIGHT	417T1000 S5065	1	33-26-11 / /	050-099, 150-199
YIDRT01A		2233 LAMP	417T1000 08806	1	33-26-11 / /	050-099, 150-199
YIDRT02		BS060780-1 SIGN-RETURN TO SEAT	S417T106 S5065	1	33-24-11 / /	050-099, 150-199
YIDRT02A		MS25237-387 LAMP	S417T106 96906	8	33-24-11 / /	050-099, 150-199
YIDRT05		BV03202-BV03203 MIRROR LIGHT	417T1000 17023	4	33-26-11 / /	050-099, 150-199
YIDRT05A		F15T12-WW LAMP	417T1000 08805	4	33-26-11 / /	050-099, 150-199
YIDRT06		P90-90720-1 LT-LAV SMOKE WARNING	417T0106 S5065	1	26-13-11 / /	155-157, 164-199

EQUIPMENT LIST

D280T132



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIDS001		10C10B SWITCH-DOOR LATCH	417T1000 15438	1	33-26-11 / /	050-099, 150-199
YIDS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-13 / /	050-099, 150-199
YIDS003		A20247AM1 SW-ATTENDANT CALL AND RESET	00000000 81640	1	33-25-11 / /	050-099, 150-199
YIDS004		920099 SW-ATTENDANT CALL	00000000 71482	1	33-25-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIDS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIDV001		ZSV18 RINSE VALVE	00000000 62701	1	38-32-13 / /	050-099, 150-199
YIDV002		ZMV2 FLUSH VALVE	00000000 62701	1	38-32-13 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIDV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIE++++		USEP078-00 PNL-PURSER LIGHTING/PA	00000000 81205	0	33-21-11 SCH 33/21/01	150-199

EQUIPMENT LIST

D280T132

Section YIE+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIES001		44-MY-232320 SW-PASSENGER LIGHTS,FWD CABIN	00000000 60525	1	33-21-11 / /	150-199
YIES002		44-YY-23734 SW-PASSENGER LIGHTS,MID CABIN	00000000 60525	1	33-21-11 / /	150-199
YIES003		44-MY-232320 SW-PASSENGER LIGHTS,AFT CABIN	00000000 60525	1	33-21-11 / /	150-199
YIES04+		2100-1 SW-FWD PRIORITY	00000000 81205	1	33-21-11 / /	150-199
YIES04A		85 LAMP	00000000 08806	1	33-21-11 / /	150-199
YIES05+		2100-1 SW-MID PRIORITY	00000000 81205	1	33-21-11 / /	150-199
YIES05A		85 LAMP	00000000 08806	1	33-21-11 / /	150-199
YIES06+		2100-1 SW-AFT PRIORITY	00000000 81205	1	33-21-11 / /	150-199
YIES06A		85 LAMP	00000000 08806	1	33-21-11 / /	150-199
YIES07+		2100-3 SW-PURSER SIDEWALL LT TURNOFF	00000000 81205	1	33-21-31 / /	150-199
YIES07A		85 LAMP	00000000 08806	1	33-21-31 / /	150-199
YIES08+		2100-3 SW-PURSER WORK LIGHT	00000000 81205	1	33-22-32 / /	150-199
YIES08A		85 LAMP	00000000 08806	1	33-22-32 / /	150-199
YIES09+		2100-3 SW-STA 679 RH LAV OCCUPIED SIGN	00000000 81205	1	33-26-21 / /	150-199
YIES09A		85 LAMP	00000000 08806	1	33-26-21 / /	150-199

EQUIPMENT LIST

D280T132

Section YIES00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIF++++		USEM01630 GALLEY-F4 FWD	10150F11 BFE	1	25-31-01 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIF+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFB001		20420L-3-8 GALLEY WATER LINE THERMOSTAT	00000000 TBD	1	30-71-25 / /	050-099, 150-199
YIFB002		110-6-21 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199
YIFB003		110-7-6-49 GALLEY WATER LINE HEATER TAPE	00000000 98085	1	30-71-25 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFB00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFC041		BACC18AC15 CB-OVEN NO. 1	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC042		BACC18AC15 CB-OVEN NO. 2	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC043		BACC18AC10 CB-AIR CHILLER	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC044		BACC18AC10 CB-LH COFFEEMAKER	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC045		BACC18AC10 CB-MID COFFEEMAKER	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC046		BACC18AC10 CB-RH COFFEEMAKER	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC047		BACC19Z7R CB-HOT CUP	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC048		BACC18Z7R CB-HOT JUG	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC049		BACC18Z-1R CB-AIR CHILLER CONTROL	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC050		BACC18Z-1R CB-LH COFFEEMAKER CONTROL	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC051		BACC18Z-1R CB-MID COFFEEMAKER CONTROL	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC052		BACC18Z-1R CB-RH COFFEEMAKER CONTROL	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199
YIFC053		BACC18Z-2R CB-WORK LIGHT	10150F11 81205	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFC00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFD050J		BACC63CD32-17P RECEPTACLE-INTERFACE (AC)	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD052J		BACC45FM14-15P RECEPTACLE-INTERFACE (DC)	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD053P		BACC63BN10-5P PLUG-CURRENT TRANSFORMER	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD054J		MS24264R14B7SN RECEPTACLE-	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD054P		BACC45FT14C-7P PLUG-	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD055P		MS24266R20B25SN PLUG-OVEN NO. 1	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD056P		MS24266R20B25SN PLUG-OVEN NO. 2	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD057P		MS24266R16B10SN PLUG-LH COFFEEMAKER	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD058P		MS24266R16B10SN PLUG-MID COFFEEMAKER	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD059P		MS24266R16B10SN PLUG-RH COFFEEMAKER	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD060P		MS24266R10B5S PLUG-WORK LIGHT	10150F11 81205	1	25-31-11 0354/ /	050-099, 150-199
YIFD061J		CA16707 RECEPTACLE-HOT JUG	10150F11 71468	1	25-31-11 0354/ /	050-099, 150-199
YIFD062J		CA16707 RECEPTACLE-HOT CUP	10150F11 71468	1	25-31-11 0354/ /	050-099, 150-199
YIFD063J		DACF15S RECEPTACLE-OVEN 1 CONTROL MODULE	10150F11 71468	1	25-31-11 0354/ /	050-099, 150-199
YIFD064J		DACF15S RECEPTACLE-OVEN 2 CONTROL MODULE	10150F11 71468	1	25-31-11 0354/ /	050-099, 150-199
YIFD068J		AFD5016-8SNA231 RECEPTACLE-INTERFACE (CHILLER)	10150F11 11139	1	25-31-11 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFD00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFK030		KA-D9F-005 RELAY	10150F11 35344	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFL032		14-32280-8P6 FEEDER ENERGIZED (LAMP OLN115-18K)	10150F11 29207	1	25-31-01 0354/ /	050-099, 150-199
YIFL033		BR9172-503 WORK LIGHT	10150F11 15086	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFL00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFM001		72068000 OVENS-1 AND 2	10150F11 SELL	2	25-31-01 0354/ /	050-099, 150-199
YIFM002		521-1-000-1B COFFEEMAKERS-LEFT, MID AND RIGHT	10150F11 SELL	3	25-31-01 0354/ /	050-099, 150-199
YIFM005		DLH-581-004 HOT CUP	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199
YIFM010		DLH-105-57 HOT JUG	10150F11 SELL	1	25-31-11 0354/ /	050-099, 150-199
YIFM011		72038000 OVEN CONTROL MODULE (OVENS 1 AND 2)	10150F11 SELL	2	25-31-01 0354/ /	050-099, 150-199
YIFM016		356-1 AIR CHILLER	10150F21 60299	1	25-31-01 0354/ /	050-099, 150-199
YIFM030		03344-106 BALLAST	10150F11 15086	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFM00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFP031		2-F-225-0019-00000 ELECTRICAL CONTROL PANEL	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFP00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFS030		10HA1C4F3N11R1 SW-AIR CHILLER	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199
YIFS031		10HA1C1F3N1R1 SW-HOT JUG	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199
YIFS033		10HA1C1F3N1R1 SW-HOT CUP	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199
YIFS034		3448-1 SW-WORK LIGHT	10150F11 SELL	1	25-31-01 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIFT030		2B75-1-A CURRENT TRANSFORMER	10150F11 77820	1	25-31-11 0354/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIFT00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIH++++		USEM01619 CONT PNL-FWD CARGO TEMP	00000000 81205	1	21-61-81 / /	ALL

EQUIPMENT LIST

D280T132

Section YIH+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIHL001		231T300-2036 LIGHT INDICATOR-FWD CARGO FAULT	00000000 81205	1	21-61-81 / /	ALL
YIHL01A		MS25237-387 LAMP-28V	00000000 96906	2	21-61-81 / /	ALL
YIHL01D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-61-81 / /	ALL

EQUIPMENT LIST

D280T132

Section YIHL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIHS01+		S231T290-4016 SWITCH INDICATOR-FWD CARGO AIR COND	00000000 81205	1	21-61-81 / /	ALL
YIHS01A		MS24515-685AS15 LAMP-5VAC	00000000 96906	1	21-61-81 / /	ALL
YIHS01B		MS25237-387 LAMP-28VDC	00000000 96906	2	21-61-81 / /	ALL
YIHS01D		851-30768-823 DIODE/FUSE ASSEMBLY	00000000 81205	1	21-61-81 / /	ALL

EQUIPMENT LIST

D280T132

Section YIHS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YII++++		USEM01607 MODULE-STAB TRIM CONTROL-LEFT	00000000 81205	0	27-41-11 SCH 27/41/01	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YII+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIIS001		10-60552-5 SW ASSY-HYDRAULIC PRESSURE	00000000 19156	1	27-41-11 / /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YIIS00
Page 1 End
Mar 14/2007



Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIIV001		401-09772-01 VALVE-SOLENOID,ARM,UP	00000000 81205	1	27-41-11 / /	050-099, 155-199, 275-299
YIIV002		401-09772-01 VALVE-SOLENOID,CONT,UP	00000000 81205	1	27-41-11 / /	050-099, 155-199, 275-299
YIIV003		920129-100 VALVE-MOTOR OPERATED	00000000 81205	1	27-41-11 / /	050-099, 155-199, 275-299
YIIV004		401-09772-01 VALVE-SOLENOID,ARM,DOWN	00000000 81205	1	27-41-11 / /	050-099, 155-199, 275-299
YIIV005		401-09772-01 VALVE-SOLENOID,CONT,DOWN	00000000 81205	1	27-41-11 / /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YIIV00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIJ++++		USEM01608 MODULE-STAB TRIM CONTROL,RIGHT	251T4200 81205	0	27-41-21 SCH 27/41/01	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YIJ+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIJS001		10-60552-5 SW ASSY-HYDRAULIC PRESSURE	00000000 19156	1	27-41-21 / /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YIJS00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIJV001		401-09772-01 VALVE-SOLENOID,ARM,UP	00000000 81205	1	27-41-21 / /	050-099, 155-199, 275-299
YIJV002		401-09772-01 VALVE-SOLENOID,CONT,UP	00000000 81205	1	27-41-21 / /	050-099, 155-199, 275-299
YIJV003		920129-100 VALVE-MOTOR OPERATED	00000000 81205	1	27-41-21 / /	050-099, 155-199, 275-299
YIJV004		401-09772-01 VALVE-SOLENOID,ARM,DOWN	00000000 81205	1	27-41-21 / /	050-099, 155-199, 275-299
YIJV005		401-09772-01 VALVE-SOLENOID,CONT,DOWN	00000000 81205	1	27-41-21 / /	050-099, 155-199, 275-299

EQUIPMENT LIST

D280T132

Section YIJV00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIL++++		USEM01655 MODULE-MID ATTEND	00000000 81205	4	33-22-31 / /	275-299

EQUIPMENT LIST

D280T132

Section YIL+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YILS01+		2100-3 SW-ATTENDANT LT	00000000 91929	1	33-22-31 / /	275-299
YILS01A		85 LAMP	00000000 08806	1	33-22-31 / /	275-299

EQUIPMENT LIST

D280T132

Section YILS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIN++++		USEM01733 PNL - FUEL JETTISON	00000000 81205	0	28-31-11 SCH 28/31/01	050-099, 155-199, 276-299

EQUIPMENT LIST

D280T132

Section YIN+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YINK001		600-154-1002 RELAY-JETTISON PUMP IND	00000000 81205	1	28-31-11 / /	050-099, 155-199, 276-299
YINK002		600-154-1002 RELAY-JETTISON PUMP IND	00000000 81205	1	28-31-11 / /	050, 155-199, 277- 299

EQUIPMENT LIST

D280T132

Section YINK00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YINL01+		S231T300-2036 LAMP-JETTISON FAULT	00000000 81205	1	28-31-11 / /	050-099, 155-199, 276-299
YINL01A		MS25237-387 LAMP	00000000 96906	1	28-31-11 / /	050-099, 155-199, 276-299
YINL01D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-31-11 / /	050-099, 155-199, 276-299
YINL02B		MS24515-685AS15 LAMP	00000000 96906	1	28-31-11 / /	155-199, 276-299

EQUIPMENT LIST

D280T132

Section YINL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YINS003		AC45-0032-1 SWITCH-FUEL JETTISON SELECT	00000000 81205	1	28-31-11 //	050-099, 155-199, 276-299
YINS01+	1	S231T290-4027 SWITCH-NOZZLE VALVE, L	00000000 81205	1	28-31-12 //	050-099, 155-199, 276-299
YINS01+	2	S231T290-5027 SWITCH-NOZZLE VALVE, L	00000000 81205	1	28-31-12 //	050-099, 155-199, 276-299
YINS01A		MS25237-387 LAMP	00000000 96906	1	28-31-12 //	050-099, 155-199, 276-299
YINS01B		MS24515-685AS15 LAMP	00000000 96906	1	28-31-12 //	050-099, 155-199, 276-299
YINS01D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-31-12 //	050-099, 155-199, 276-299
YINS02+	1	S231T290-4027 SWITCH-NOZZLE VALVE, R	00000000 81205	1	28-31-12 //	050-099, 155-199, 276-299
YINS02+	2	S231T290-5027 SWITCH-NOZZLE VALVE, R	00000000 81205	1	28-31-12 //	050-099, 155-199, 276-299
YINS02A		MS25237-387 LAMP	00000000 96906	1	28-31-12 //	050-099, 155-199, 276-299
YINS02B		MS24515-685AS15 LAMP	00000000 96906	1	28-31-12 //	050-099, 155-199, 276-299
YINS02D		851-30768-823 DIODE/FUSE MODULE	00000000 96182	1	28-31-12 //	050-099, 155-199, 276-299

EQUIPMENT LIST

D280T132

Section YINS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIP++++		USEM01111 PNL-ENTERTAINMENT	233T3230 81205	1	23-32-12 P005-00/ /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIP+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIPS001		64AT22-5 SW-ELT	233T3230 91929	1	23-24-11 / /	050-099, 150-199

EQUIPMENT LIST

D280T132

Section YIPS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YIS++++	9	USEM01753 MODULE-ICE DET SYSTEM TEST (SB 30-0017)	00000000 81205	1	30-81-01 / /	150-154
YIS++++		USEM01753 MODULE-ICE DETECTION SYSTEM TEST	00000000 81205	1	30-81-01 / /	050-099, 155-199

EQUIPMENT LIST

D280T132

Section YIS+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YISS001	9	64AT22-7 SW-ICE DETECTION SYS TEST (SB 30-0017)	00000000 91929	1	30-81-01 / /	150-154
YISS001		64AT22-7 SW-ICE DETECTION SYS TEST	00000000 91929	1	30-81-01 / /	050-099, 155-199

EQUIPMENT LIST

D280T132

Section YISS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YITS001		L18366 SW-SIDEWALL WASHLIGHT	00000000 24385	1	33-21-31 / /	050-099

EQUIPMENT LIST

D280T132

Section YITS00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YJE++++		USEM1977 MODULE-THRUST REVERSER	233T4259 81205	1	78-36-11 P061-00/ /	157, 167-199, 277- 299

EQUIPMENT LIST

D280T132

Section YJE+
Page 1 End
Aug 05/2009



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YJEL001		116-565-1042-002 LT-L T/R MAINT (REF M1977)	233T4259 81590	1	78-36-11 / /	157, 167-199, 277- 299
YJEL002		116-565-1042-002 LT-R T/R MAINT (REF M1977)	233T4259 81590	1	78-36-21 / /	157, 167-199, 277- 299

EQUIPMENT LIST

D280T132

Section YJEL00

Page 1 End

Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YJES001		MS24523-26 SW-L T/R DCV TEST (REF M1977)	233T4259 81205	1	78-36-11 / /	157, 167-199, 277- 299
YJES002		2PB11-H58 SW-L T/R MAINT RESET (REF M1977)	233T4259 81205	1	78-36-11 / /	157, 167-199, 277- 299
YJES003		MS24523-26 SW-R T/R DCV TEST (REF M1977)	233T4259 81205	1	78-36-21 / /	157, 167-199, 277- 299
YJES004		2PB11-H58 SW-R T/R MAINT RESET (REF M1977)	233T4259 81205	1	78-36-21 / /	157, 167-199, 277- 299

EQUIPMENT LIST

D280T132

Section YJES00
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YKYM007		7800084-001-L-7800084-002-R- FLUSH CONTROL ASSEMBLY	00000000 58568	1	38-32-16 / /	ALL

EQUIPMENT LIST

D280T132

Section YKYM00

Page 1 End

Mar 07/2008



767-200/300 WIRING DIAGRAM MANUAL

Equip	Opt	Part Number Part Description	Used On Dwg Vendor	Qty	Diagram Station / WL / BL	Effectivity
YKYS002		8AS193 FLUSH SWITCH	00000000 91929	1	38-32-16 / /	ALL

EQUIPMENT LIST

D280T132

Section YKYS00
Page 1 End
Mar 07/2008