

91-21-31

SPLICE LIST



91-21-31
SPLICE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
EFFECTIVE PAGES			SP00400 cont.			SP00800 cont.		
	1 thru 3	Aug 05/2009		2	Jan 21/2005		8	Jan 21/2005
	4	BLANK		3	Jan 21/2005	SP00900	1	Jan 21/2005
SP00000	1	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
	2	Jan 21/2005		5	Jan 21/2005		3	Jan 21/2005
	3	Mar 09/2006		6	Jan 21/2005		4	Jan 21/2005
	4	Jan 21/2005	SP00500	1	Jan 21/2005		5	Jan 21/2005
	5	Jan 21/2005		2	Jan 21/2005		6	Jan 21/2005
SP00100	1	Jan 21/2005		3	Jan 21/2005		7	Jan 21/2005
	2	Jan 21/2005		4	Jan 21/2005		8	Jan 21/2005
	3	Jan 21/2005		5	Jan 21/2005		9	Jan 21/2005
	4	Jan 21/2005		6	Jan 21/2005	SP01000	1	Jan 21/2005
	5	Jan 21/2005	SP00600	1	Jan 21/2005		2	Jan 21/2005
	6	Jan 21/2005		2	Jan 21/2005		3	Jan 21/2005
	7	Jan 21/2005		3	Jan 21/2005		4	Jan 21/2005
SP00200	1	Jan 21/2005		4	Jan 21/2005		5	Jan 21/2005
	2	Jan 21/2005		5	Jan 21/2005		6	Jan 21/2005
	3	Jan 21/2005	SP00700	1	Jan 21/2005		7	Jan 21/2005
	4	Jan 21/2005		2	Jan 21/2005	SP01100	1	Jan 21/2005
	5	Jan 21/2005		3	Jan 21/2005	SP01200	1	Jan 21/2005
	6	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
SP00300	1	Jan 21/2005	SP00800	1	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005		4	Jan 21/2005
	3	Jan 21/2005		3	Jan 21/2005	SP01300	1	Jan 21/2005
	4	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
	5	Jan 21/2005		5	Jan 21/2005		3	Jan 21/2005
	6	Jan 21/2005		6	Jan 21/2005		4	Jan 21/2005
SP00400	1	Jan 21/2005		7	Jan 21/2005		5	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

SPLICE LIST

D280T132

EFFECTIVE PAGES

Page 1
Aug 05/2009



91-21-31
SPLICE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
SP01300 cont.			SP02100 cont.			SP03000 cont.		
	6	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	7	Jan 21/2005	SP02200	1	Jan 21/2005		3	Jan 21/2005
SP01400	1	Jan 21/2005		2	Jan 21/2005	SP03100	1	Jan 21/2005
	2	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005		4	Jan 21/2005		3	Jan 21/2005
	4	Jan 21/2005	SP02300	1	Jan 21/2005	SP03200	1	Jan 21/2005
	5	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
SP01500	1	Jan 21/2005	SP02400	1	Jan 21/2005		3	Jan 21/2005
	2	Jan 21/2005		2	Jan 21/2005	SP03300	1	Jan 21/2005
	3	Jan 21/2005	SP02500	1	Jan 21/2005		2	Jan 21/2005
	4	Jan 21/2005	SP02600	1	Jan 21/2005	SP03400	1	Jan 21/2005
SP01600	1	Jan 21/2005		2	Jan 21/2005	SP03500	1	Jan 21/2005
	2	Jan 21/2005		3	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005	SP02700	1	Jan 21/2005	SP03600	1	Jan 21/2005
	4	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
	5	Jan 21/2005	SP02800	1	Jan 21/2005		3	Jan 21/2005
SP01700	1	Mar 14/2007		2	Jan 21/2005		4	Jan 21/2005
	2	Mar 14/2007		3	Jan 21/2005		5	Jan 21/2005
SP01800	1	Jan 21/2005		4	Jan 21/2005		6	Jan 21/2005
SP01900	1	Jan 21/2005		5	Jan 21/2005	SP03700	1	Jan 21/2005
	2	Jan 21/2005		6	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005	SP02900	1	Jan 21/2005	SP03800	1	Jan 21/2005
	4	Jan 21/2005		2	Jan 21/2005		2	Jan 21/2005
SP02000	1	Jan 21/2005		3	Jan 21/2005	SP03900	1	Jan 21/2005
	2	Jan 21/2005		4	Jan 21/2005		2	Jan 21/2005
	3	Jan 21/2005		5	Jan 21/2005		3	Jan 21/2005
SP02100	1	Jan 21/2005	SP03000	1	Jan 21/2005		4	Jan 21/2005

A = Added, R = Revised, D = Deleted, O = Overflow

SPLICE LIST

D280T132

EFFECTIVE PAGES

Page 2
Aug 05/2009



91-21-31
SPLICE LIST

Section	Page	Date	Section	Page	Date	Section	Page	Date
SP04000	1	Jan 21/2005						
	2	Jan 21/2005						
	3	Jan 21/2005						
	4	Jan 21/2005						
	5	Jan 21/2005						
SP05000	1	Jan 21/2005						
	2	Jan 21/2005						
	3	Jan 21/2005						
SP05200	1	Jan 21/2005						
SP05300	1	Jan 21/2005						
SP05400	1	Jan 21/2005						
SP05500	1	Jan 21/2005						
SP07100	1	Jan 21/2005						
SP09000	1	Jan 21/2005						
SP09500	1	Jan 21/2005						
	2	Jan 21/2005						
	3	Jan 21/2005						
SP09600	1	Jan 21/2005						
SP09700	1	Mar 14/2007						
SPZ0000	1	Mar 14/2007						

A = Added, R = Revised, D = Deleted, O = Overflow

SPLICE LIST
D280T132

EFFECTIVE PAGES
Page 3
Aug 05/2009



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00001		0220/194/L050					ALL
	W0779	016	24		9	34-43-12	ALL
	W0779	017	24		9	34-43-12	ALL
	W0803	017	24		9	34-43-22	ALL
	W0820	032	20		9	33-24-11	150, 152-199
	W0820	900	20		9	33-24-11	150, 152-156, 162-199
	W0820	900	20		9	23-32-21	157
	W1417	901	20		9	23-32-21	150, 152-199
	W1417	901Z			9	23-32-21	150, 152-199
SP00002		TBD / /					150, 152-199
	W0820	031	20		S	33-24-11	150, 152-199
	W0820	901	20		S	33-24-11	150, 152-156, 162-199
	W0820	901	20		S	23-32-21	157
	W1417	902	20		S	23-32-21	150, 152-199
	W1417	902Z			S	23-32-21	150, 152-199
	W1417	903	20		S	23-32-21	150, 152-199
SP00003		0220/194/L050					ALL
	W0209	012	20		9	34-43-12	ALL
	W0779	001	20		9	34-43-12	ALL
	W1417	501	20		9	23-32-21	150, 152-199
	W1417	900	20		9	23-32-21	150, 152-199
	W1417	918	20		9	23-32-21	150, 152-199
SP00004		SHELF/E01/04					157
	W0117	907	20		S	23-32-21	157
	W0117	907Z				23-32-21	157
	W0117	910	20		S	23-32-21	157
	W0117	910Z				23-32-21	157
	W0117	918	20		S	23-32-21	157
	W0117	918Z				23-32-21	157
SP00005		0220/194/L050					ALL
	W0779	023	24		9	34-43-22	ALL
	W0803	015	24		9	34-43-22	ALL
SP00006		SHELF/E01/05					157
	W0117	913	20		S	23-32-21	157
	W0119	902	20		S	23-32-21	157
	W0119	902Z				23-32-21	157

SPLICE LIST
D280T132



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00006		SHELF/E01/05 (continued)					157
	W0119	904	22		S	23-32-21	157
SP00007		0220/194/L050					ALL
	W0211	028	20		9	34-43-22	ALL
	W0803	001	20		9	34-43-22	ALL
SP00008		SHELF/E01/04					157
	W0117	625	20		S	23-32-21	157
	W0117	916	20		S	23-32-21	157
	W0117	917	20		S	23-32-21	157
SP00009		0173/195/L034					ALL
	W0465	016Y	22		9	27-41-11	150-199
	W0465	A-A			9	27-41-11	150-199
	W1281	013Y	22		9	27-41-11	ALL
	W1281	016Y	22		9	27-41-11	050-099, 278-299
	W1281	A-A			9	27-41-11	050-099, 275-299
SP00011		0173/195/L034					ALL
	W0465	006Y	22		9	27-41-11	150-199
	W0465	017Y	22		9	27-41-11	150-199
	W0465	A-C			9	27-41-11	150-199
	W1281	006Y	22		9	27-41-11	050-099, 275-299
	W1281	017Y	22		9	27-41-11	050-099, 278-299
	W1281	A-C			9	27-41-11	050-099, 275-299
SP00015		0173/195/L034					ALL
	W0465	019Y	22		9	27-41-11	150-199
	W0465	B-C			9	27-41-11	150-199
	W1281	014Y	22		9	27-41-11	ALL
	W1281	019Y	22		9	27-41-11	050-099, 278-299
	W1281	B-C			9	27-41-11	050-099, 275-299
SP00027		0173/195/L034					ALL
	W0465	018Y	22		9	27-41-11	150-199
	W0465	B-A			9	27-41-11	150-199
	W1281	012Y	22		9	27-41-11	ALL
	W1281	018Y	22		9	27-41-11	050-099, 278-299
	W1281	B-A			9	27-41-11	050-099, 275-299

SPLICE LIST
D280T132

91-21-31
Section SP00000
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00027		0173/195/L034 (continued)					ALL
	W1281	C-A			9	27-41-11	050-099
SP00029		0173/195/L034					050-099
	W1281	004Y	22		9	27-41-11	050-099
	W1281	C-C			9	27-41-11	050-099
SP00031		0173/195/R037					ALL
	W0469	016Y	22		9	27-41-21	050-099, 150-199, 278-299
	W0469	A-A			9	27-41-21	ALL
	W1293	007Y	22		9	27-41-21	ALL
SP00033		0173/195/R037					ALL
	W0469	006Y	22		9	27-41-21	ALL
	W0469	017Y	22		9	27-41-21	050-099, 150-199, 278-299
	W0469	A-C			9	27-41-21	ALL
SP00037		0220/283/L030					ALL
	W0203	006	24		9	31-51-11	ALL
	W0459	014	24		9	31-51-11	ALL
SP00039		0220/289/0000					ALL
	W0211	023	24		9	31-51-12	ALL
	W0449	004	24		9	31-51-12	ALL
SP00053		0360/195/L020					ALL
	W0689	015	12		S	23-34-18	050-099
	W0689	015	12		9	23-34-18	150-199, 275-299
	W1445	008	12		S	23-34-18	050-099
	W1445	008	12		9	23-34-18	150-199, 275-299
SP00055		0335/192/R055					ALL
	W0853	014	10		S	23-34-19	050-099
	W0853	014	10		9	23-34-19	150-199, 275-299
	W1387	011	12		S	23-34-19	050-099
	W1387	011	12		9	23-34-19	150-199, 275-299
SP00057		0360/195/L020					ALL
	W0689	019	12		S	23-34-18	050-099
	W0689	019	12		9	23-34-18	150-199, 275-299



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00057		0360/195/L020 (continued)					ALL
	W1443	008	12		S	23-34-18	050-099
	W1443	008	12		9	23-34-18	150-199, 275-299
SP00072		1325/198/R094					ALL
	W0916	201B	24		9	52-35-13	ALL
	W0916	B-C			9	52-35-13	ALL
SP00074		1325/198/R094					ALL
	W0916	201R	24		9	52-35-13	ALL
	W0916	B-D			9	52-35-13	ALL
SP00076		D0190/155/R081					ALL
	W0962	202B	24		9	52-35-13	ALL
	W0962	B-A			9	52-35-13	ALL
SP00078		D0190/155/R081					ALL
	W0962	202R	24		9	52-35-13	ALL
	W0962	B-B			9	52-35-13	ALL
SP00080		D0190/155/R083					ALL
	W0962	203B	24		9	52-35-13	ALL
	W0962	C-A			9	52-35-13	ALL
SP00082		D0190/155/R083					ALL
	W0962	203R	24		9	52-35-13	ALL
	W0962	C-B			9	52-35-13	ALL
SP00084		D0165/140/R068					ALL
	W0962	204B	24		9	52-35-13	ALL
	W0962	D-A			9	52-35-13	ALL
SP00086		D0165/140/R068					ALL
	W0962	204R	24		9	52-35-13	ALL
	W0962	D-B			9	52-35-13	ALL
SP00088		D0230/140/R068					050-099
	W0962	205B	24		9	52-35-13	050-099
	W0962	E-A			9	52-35-13	050-099

SPLICE LIST
D280T132

91-21-31
Section SP00000
Page 4
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00090		D0230/140/R068					050-099
	W0962	205R	24		9	52-35-13	050-099
	W0962	E-B			9	52-35-13	050-099
SP00094		0480/194/R071					050-099
SP00094		0479/190/R088					150-199, 275-299
	W0916	206B	24		9	52-34-13	ALL
	W0916	Z-A			9	52-34-13	ALL
SP00096		0480/194/R071					050-099
SP00096		0479/190/R088					150-199, 275-299
	W0916	206R	24		9	52-34-13	ALL
	W0916	Z-B			9	52-34-13	ALL
SP00098		D0550/122/R046					ALL
	W0960	202B	24		9	52-34-13	ALL
	W0960	B-A			9	52-34-13	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00000
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00100		D0550/122/R046					ALL
	W0960	202R	24		9	52-34-13	ALL
	W0960	B-B			9	52-34-13	ALL
SP00102		D0550/127/R053					ALL
	W0960	203B	24		9	52-34-13	ALL
	W0960	C-A			9	52-34-13	ALL
SP00104		D0550/127/R053					ALL
	W0960	203R	24		9	52-34-13	ALL
	W0960	C-B			9	52-34-13	ALL
SP00105		0173/195/R037					ALL
	W0469	019Y	22		9	27-41-21	050-099, 150-199, 278-299
	W0469	B-C			9	27-41-21	ALL
	W1293	003Y	22		9	27-41-21	ALL
SP00106		L1083/12/LE					ALL
	W0430	09TB	20		9	27-88-12	ALL
	W0430	A-A			9	27-88-12	ALL
SP00107		0173/195/R037					ALL
	W0469	018Y	22		9	27-41-21	050-099, 150-199, 278-299
	W0469	B-A			9	27-41-21	ALL
	W0469	C-A			9	27-41-21	050-099
	W1293	006Y	22		9	27-41-21	ALL
SP00108		L1083/12/LE					ALL
	W0430	09TI				27-88-12	ALL
	W0430	09TR	20		9	27-88-12	ALL
	W0430	A-B			9	27-88-12	ALL
SP00109		0173/195/R037					050-099
	W0469	004Y	22		9	27-41-21	050-099
	W0469	C-C			9	27-41-21	050-099
SP00110		L1025/12/LE					ALL
	W0430	10TB	20		9	27-88-12	ALL
	W0430	A-C			9	27-88-12	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00100
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00112		L1025/12/LE					ALL
	W0430	10TI				27-88-12	ALL
	W0430	10TR	20		9	27-88-12	ALL
	W0430	A-D			9	27-88-12	ALL
SP00118		L0479/12/LE					ALL
	W0430	01TB	20		9	27-88-12	ALL
	W0430	A-G			9	27-88-12	ALL
SP00120		L0479/12/LE					ALL
	W0430	01TI				27-88-12	ALL
	W0430	01TR	20		9	27-88-12	ALL
	W0430	A-H			9	27-88-12	ALL
SP00122		L0438/12/LE					ALL
	W0430	02TB	20		9	27-88-12	ALL
	W0430	A-J			9	27-88-12	ALL
SP00123		F271/ /FS					ALL
	W0775	011	20		9	23-11-11	ALL
	W0777	010	20		9	23-11-11	ALL
SP00124		L0438/12/FS					ALL
	W0430	02TI				27-88-12	ALL
	W0430	02TR	20		9	27-88-12	ALL
	W0430	A-K			9	27-88-12	ALL
SP00125		F271/ /FS					ALL
	W0775	010	20		1D	23-11-11	ALL
	W0777	011	20		1D	23-11-11	ALL
SP00129		0230/285/L050					ALL
	W0203	004	22		9	23-51-21	ALL
	W0631	001	22		9	23-51-21	ALL
SP00130		L0629/12/LE					ALL
	W0430	03TB	20		9	27-88-12	ALL
	W0430	A-N			9	27-88-12	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00100
Page 2
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00131		0220/194/L050					ALL
	W0207	013	22		9	23-51-11	ALL
	W0629	001	22		9	23-51-11	ALL
SP00132		L0629/12/LE					ALL
	W0430	03TI				27-88-12	ALL
	W0430	03TR	20		9	27-88-12	ALL
	W0430	A-P			9	27-88-12	ALL
SP00134		L0581/12/LE					ALL
	W0430	04TB	20		9	27-88-12	ALL
	W0430	A-Q			9	27-88-12	ALL
SP00136		L0581/12/LE					ALL
	W0430	04TI				27-88-12	ALL
	W0430	04TR	20		9	27-88-12	ALL
	W0430	A-R			9	27-88-12	ALL
SP00139		0315/190/L050					ALL
	W0689	016	16		S	23-34-16	050-099
	W0689	016	16		9	23-34-16	150-199, 275-299
	W1383	011	16		S	23-34-16	050-099
	W1383	011	16		9	23-34-16	150-199, 275-299
SP00141		0335/192/R055					ALL
	W0853	012	12		S	23-34-17	050-099
	W0853	012	12		9	23-34-17	150-199, 275-299
	W1381	011	12		S	23-34-17	050-099
	W1381	011	12		9	23-34-17	150-199, 275-299
SP00142		L0779/12/LE					ALL
	W0430	05TB	20		9	27-88-12	ALL
	W0430	A-U			9	27-88-12	ALL
SP00143		0360/195/L020					ALL
	W0689	014	16		S	23-34-15	050-099
	W0689	014	16		9	23-34-15	150-199, 275-299
	W1379	011	16		S	23-34-15	050-099
	W1379	011	16		9	23-34-15	150-199, 275-299

SPLICE LIST
D280T132

91-21-31
Section SP00100
Page 3
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00144		L0779/12/LE					ALL
	W0430	05TI				27-88-12	ALL
	W0430	05TR	20		9	27-88-12	ALL
	W0430	A-V			9	27-88-12	ALL
SP00146		L0733/12/LE					ALL
	W0430	06TB	20		9	27-88-12	ALL
	W0430	A-W			9	27-88-12	ALL
SP00148		L0733/12/LE					ALL
	W0430	06TI				27-88-12	ALL
	W0430	06TR	20		9	27-88-12	ALL
	W0430	A-X			9	27-88-12	ALL
SP00154		L0934/12/LE					ALL
	W0430	07TB	20		9	27-88-12	ALL
	W0430	B-A			9	27-88-12	ALL
SP00156		L0934/12/LE					ALL
	W0430	07TI				27-88-12	ALL
	W0430	07TR	20		9	27-88-12	ALL
	W0430	B-B			9	27-88-12	ALL
SP00158		L0880/12/LE					ALL
	W0430	08TB	20		9	27-88-12	ALL
	W0430	B-C			9	27-88-12	ALL
SP00160		L0880/12/LE					ALL
	W0430	08TI				27-88-12	ALL
	W0430	08TR	20		9	27-88-12	ALL
	W0430	B-D			9	27-88-12	ALL
SP00161		0732/193/R027					050-099
SP00161		0730/190/R045					150-199, 275-299
	W0596	210R	24		S	23-41-11	ALL
	W1343	206R	24		S	23-41-11	ALL
	W1343	207R	24		S	23-41-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00100
Page 4
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00163		0732/193/R047					050-099
SP00163		0730/190/R045					150-199, 275-299
	W0596	210B	24		S	23-41-11	ALL
	W1343	206B	24		S	23-41-11	ALL
	W1343	207B	24		S	23-41-11	ALL
SP00165		0732/193/R047					050-099
SP00165		0730/190/R045					150-199, 275-299
	W0596	210Z			S	23-41-11	ALL
	W1343	206Z			S	23-41-11	ALL
	W1343	207Z			S	23-41-11	ALL
SP00166		L188/12/LE					ALL
	W0406	227B	20		9	27-88-12	ALL
	W0406	A-A			9	SPARE	ALL
SP00167		0335/192/R055					ALL
	W0916	231R	24		9	23-41-11	ALL
	W0916	232R	24		9	23-41-11	ALL
	W1343	202R	24		9	23-41-11	ALL
SP00168		L188/12/LE					ALL
	W0406	227R	20		9	27-88-12	ALL
	W0406	A-B			9	27-88-12	ALL
SP00169		0335/192/R055					ALL
	W0916	231B	24		9	23-41-11	ALL
	W0916	232B	24		9	23-41-11	ALL
	W1343	202B	24		9	23-41-11	ALL
SP00170		L314/12/LE					ALL
	W0406	228B	20		9	27-88-12	ALL
	W0406	A-C			9	27-88-12	ALL
SP00171		0335/192/R055					ALL
	W0916	231Z			9	23-41-11	ALL
	W0916	232Z			9	23-41-11	ALL
	W1343	202Z			9	23-41-11	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00172		L314/12/LE					ALL
	W0406	228R	20		9	27-88-12	ALL
	W0406	A-D			9	27-88-12	ALL
SP00178		R0478/12/LE					ALL
	W0480	01TB	20		9	27-88-22	ALL
	W0480	A-A			9	27-88-22	ALL
SP00180		R0478/12/LE					ALL
	W0480	01TI				27-88-22	ALL
	W0480	01TR	20		9	27-88-22	ALL
	W0480	A-B			9	27-88-22	ALL
SP00182		R0437/12/LE					ALL
	W0480	02TB	20		9	27-88-22	ALL
	W0480	A-C			9	27-88-22	ALL
SP00184		R0437/12/LE					ALL
	W0480	02TI				27-88-22	ALL
	W0480	02TR	20		9	27-88-22	ALL
	W0480	A-D			9	27-88-22	ALL
SP00185		1490/190/R070					ALL
	W0571	201R	20		S	23-41-11	ALL
	W1298	201R	20		S	23-41-11	ALL
	W1343	208R	24		S	23-41-11	ALL
SP00187		1490/190/R070					ALL
	W0571	201B	20		S	23-41-11	ALL
	W1298	201B	20		S	23-41-11	ALL
	W1343	208B	24		S	23-41-11	ALL
SP00189		1490/190/R070					ALL
	W0571	201Z			S	23-41-11	ALL
	W1298	201Z			S	23-41-11	ALL
	W1343	208Z			S	23-41-11	ALL
SP00190		R0628/12/LE					ALL
	W0480	03TB	20		9	27-88-22	ALL
	W0480	A-G			9	27-88-22	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00100
Page 6
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00192		R0628/12/LE					ALL
	W0480	03TI				27-88-22	ALL
	W0480	03TR	20		9	27-88-22	ALL
	W0480	A-H			9	27-88-22	ALL
SP00194		R0580/12/LE					ALL
	W0480	04TB	20		9	27-88-22	ALL
	W0480	A-J			9	27-88-22	ALL
SP00196		R0580/12/LE					ALL
	W0480	04TI				27-88-22	ALL
	W0480	04TR	20		9	27-88-22	ALL
	W0480	A-K			9	27-88-22	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00202		R0778/12/LE					ALL
	W0480	05TB	20		9	27-88-22	ALL
	W0480	A-N			9	27-88-22	ALL
SP00204		R0778/12/LE					ALL
	W0480	05TI				27-88-22	ALL
	W0480	05TR	20		9	27-88-22	ALL
	W0480	A-P			9	27-88-22	ALL
SP00206		R0732/12/LE					ALL
	W0480	06TB	20		9	27-88-22	ALL
	W0480	A-Q			9	27-88-22	ALL
SP00207		0220/194/L050					ALL
	W0219	031	22		9	34-57-11	ALL
	W0615	010	22		9	34-57-11	ALL
SP00208		R0732/12/LE					ALL
	W0480	06TI				27-88-22	ALL
	W0480	06TR	20		9	27-88-22	ALL
	W0480	A-R			9	27-88-22	ALL
SP00214		R0933/12/LE					ALL
	W0480	07TB	20		9	27-88-22	ALL
	W0480	A-U			9	27-88-22	ALL
SP00216		R0933/12/LE					ALL
	W0480	07TI				27-88-22	ALL
	W0480	07TR	20		9	27-88-22	ALL
	W0480	A-V			9	27-88-22	ALL
SP00218		R0879/12/LE					ALL
	W0480	08TB	20		9	27-88-22	ALL
	W0480	A-W			9	27-88-22	ALL
SP00220		R0879/12/LE					ALL
	W0480	08TI				27-88-22	ALL
	W0480	08TR	20		9	27-88-22	ALL
	W0480	A-X			9	27-88-22	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00200
Page 1
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00221		0220/194/L050					ALL
	W0207	014	20		9	27-32-11	ALL
	W1297	001	20		9	27-32-11	ALL
SP00223		0238/198/R035					ALL
	W0409	006	20		9	27-32-11	ALL
	W0451	050	24		9	31-31-22	ALL
	W1297	002	20		9	27-32-11	ALL
SP00225		0360/195/L020					ALL
	W0203	014	18		9	27-11-22	ALL
	W1247	001	18		9	27-11-22	ALL
SP00226		R1082/12/LE					ALL
	W0480	09TB	20		9	27-88-22	ALL
	W0480	B-A			9	27-88-22	ALL
SP00228		R1082/12/LE					ALL
	W0480	09TI				27-88-22	ALL
	W0480	09TR	20		9	27-88-22	ALL
	W0480	B-B			9	27-88-22	ALL
SP00230		R1024/12/LE					ALL
	W0480	10TB	20		9	27-88-22	ALL
	W0480	B-C			9	27-88-22	ALL
SP00232		R1024/12/LE					ALL
	W0480	10TI				27-88-22	ALL
	W0480	10TR	20		9	27-88-22	ALL
	W0480	B-D			9	27-88-22	ALL
SP00238		0150/160/R020					ALL
	W0902	002	18		S	33-31-41	ALL
	W0902	093	18		S	33-31-41	ALL
	W0902	A-A			S	33-31-41	ALL
SP00240		0325/193/L030					ALL
	W0902	009	16		S	33-31-41	ALL
	W0902	099	18		S	33-31-41	ALL
	W0902	100	18		S	33-31-41	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00200
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00240		0325/193/L030 (continued)					ALL
	W0902	A-M			S	33-31-41	ALL
SP00244		350/284/L035					050-099, 150-199
	W0428	001	20		S	33-22-31	050-099, 150-199
	W1224	102	20		S	33-22-31	050-099, 150-199
SP00246		0354/280/R032					050-099, 150-199
	W0222	165	20		S	33-22-31	050-099, 150-199
	W1224	150	20		S	33-22-31	050-099, 150-199
SP00250		0287/280/L060					ALL
	W1226	201R	24		9	52-11-13	ALL
	W1226	A-A			9	52-11-13	ALL
SP00251		0238/198/R035					ALL
	W0441	008	22		9	30-32-21	ALL
	W0902	079	22		9	30-32-21	ALL
SP00252		0287/280/L060					ALL
	W1226	201B	24		9	52-11-13	ALL
	W1226	A-B			9	52-11-13	ALL
SP00253		0238/198/R035					ALL
	W0441	010	22		9	30-32-21	ALL
	W0902	090	22		9	30-32-21	ALL
SP00254		0330/305/R010					ALL
	W1226	202R	24		9	52-11-13	ALL
	W1226	B-A			9	52-11-13	ALL
SP00256		0330/305/R010					ALL
	W1226	202B	24		9	52-11-13	ALL
	W1226	B-B			9	52-11-13	ALL
SP00257		0335/192/R055					ALL
	W0645	034	16		S	23-34-11	050-099
	W0645	034	16		9	23-34-11	150-199, 275-299
	W0645	095	16		S	23-34-11	050-099
	W0645	095	16		9	23-34-11	150-199, 275-299

SPLICE LIST
D280T132

91-21-31
Section SP00200
Page 3
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00257		0335/192/R055 (continued)					ALL
	W0853	007	16		S	23-34-11	050-099
	W0853	007	16		9	23-34-11	150-199, 275-299
SP00258		0317/280/L080					ALL
	W1226	203R	24		9	52-11-13	ALL
	W1226	C-A			9	52-11-13	ALL
SP00259		0335/192/R055					ALL
	W0645	101	16		S	23-34-11	050-099
	W0645	101	16		9	23-34-11	150-199, 275-299
	W0853	008	16		S	23-34-11	050-099
	W0853	008	16		9	23-34-11	150-199, 275-299
SP00260		0317/280/L080					ALL
	W1226	203B	24		9	52-11-13	ALL
	W1226	C-B			9	52-11-13	ALL
SP00261		0360/195/L020					ALL
	W0645	094	22		S	23-34-11	050-099
	W0645	094	22		9	23-34-11	150-199, 275-299
	W0689	007	22		S	23-34-11	050-099
	W0689	007	22		9	23-34-11	150-199, 275-299
SP00262		0300/280/L070					ALL
	W1226	204R	24		9	52-11-13	ALL
	W1226	D-A			9	52-11-13	ALL
SP00264		0300/280/L070					ALL
	W1226	204B	24		9	52-11-13	ALL
	W1226	D-B			9	52-11-13	ALL
SP00268		1540/190/R030					ALL
	W0580	059	20		9	38-32-15	156-157, 166-199, 277-299
	W0580	059Z				38-32-15	156-157, 166-199, 277-299
	W0966	058	20		9	38-32-11	050-099, 150-154, 162-165
	W0966	058	20		9	38-32-15	155-157, 166-199, 277-299
	W0966	058	20		9	38-32-14	275-276
	W0966	058Z				38-32-11	050-099, 155, 162-165
	W0966	058Z				38-32-15	156-157, 166-199, 277-299

SPLICE LIST
D280T132

91-21-31
Section SP00200
Page 4
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00268		1540/190/R030 (continued)					ALL
	W0966	058Z				38-32-14	275-276
	W1354	007	20		9	38-32-11	050-099, 150-155, 162-165
	W1354	007	20		9	38-32-14	275-276
	W1354	046	22		9	38-32-11	050-099, 150-155, 162-165
	W1354	046	22		9	38-32-15	156-157, 166-199, 277-299
	W1354	046	22		9	38-32-14	275-276
SP00270		0184/014/FS					ALL
	W0442	216B	20		9	27-88-22	ALL
	W0442	A-A			9	27-88-12	050-099, 150-199, 275-278
	W0442	A-A			9	27-88-22	280-299
SP00271		0238/198/R035					ALL
	W0519	027	22		S	33-16-18	ALL
	W0638	156	22		S	33-16-12	ALL
	W0638	156Z				33-16-12	ALL
SP00272		0184/014/FS					ALL
	W0442	216R	20		9	27-88-22	ALL
	W0442	A-B			9	27-88-22	ALL
SP00273		0238/198/R035					ALL
	W0519	023	22		S	33-16-18	ALL
	W0638	116	22		S	33-16-12	ALL
SP00274		0314/014/FS					ALL
	W0442	217B	20		9	27-88-22	ALL
	W0442	A-C			9	27-88-22	ALL
SP00276		0314/014/FS					ALL
	W0442	217R	20		9	27-88-22	ALL
	W0442	A-D			9	27-88-22	ALL
SP00282		D0550/122/R046					ALL
	W0960	204B	24		9	52-71-13	ALL
	W0960	D-A			9	52-71-13	ALL
SP00284		D0550/122/R046					ALL
	W0960	204R	24		9	52-71-13	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00200
Page 5
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00284		D0550/122/R046 (continued)					ALL
	W0960	D-B			9	52-71-13	ALL
SP00286		D0508/127/R053					ALL
	W0960	205B	24		9	52-34-13	ALL
	W0960	E-A			9	52-34-13	ALL
SP00288		D0508/127/R053					ALL
	W0960	205R	24		9	52-34-13	ALL
	W0960	E-B			9	52-34-13	ALL
SP00290		D0588/125/R052					ALL
	W0960	206R	24		9	52-71-13	ALL
	W0960	F-A			9	52-71-13	ALL
SP00292		D0588/125/R052					ALL
	W0960	206B	24		9	52-71-13	ALL
	W0960	F-B			9	52-71-13	ALL
SP00294		446/122/R046					ALL
	W0916	212R	24		9	52-34-13	ALL
	W0916	A-C			9	52-34-13	ALL
SP00296		446/122/R046					ALL
	W0916	212B	24		9	52-34-13	ALL
	W0916	A-D			9	52-34-13	ALL
SP00298		1113/172/R098					ALL
	W0916	213R	20		9	52-71-12	ALL
	W0916	A-E			9	52-71-12	ALL

SPLICE LIST

D280T132

91-21-31

Section SP00200

Page 6 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00300		1113/172/R098					ALL
	W0916	213B	20		9	52-71-12	ALL
	W0916	A-F			9	52-71-12	ALL
SP00302		D0165/150/R078					ALL
	W0962	206R	24		9	52-71-13	ALL
	W0962	A-A			9	52-71-13	ALL
SP00304		D0165/150/R078					ALL
	W0962	206B	24		9	52-71-13	ALL
	W0962	A-B			9	52-71-13	ALL
SP00306		1324/196/R085					ALL
	W0916	215R	24		9	52-71-13	ALL
	W0916	A-J			9	52-71-13	ALL
SP00308		1324/196/R085					ALL
	W0916	215B	24		9	52-71-13	ALL
	W0916	A-K			9	52-71-13	ALL
SP00310		1113/172/L098					ALL
	W0916	216R	20		9	52-71-12	ALL
	W0916	A-L			9	52-71-12	ALL
SP00312		1113/172/L098					ALL
	W0916	216B	20		9	52-71-12	ALL
	W0916	A-M			9	52-71-12	ALL
SP00314		1460/140/L060					ALL
	W0916	217R	24		9	52-71-13	ALL
	W0916	A-N			9	52-71-13	ALL
SP00316		1460/140/L060					ALL
	W0916	217B	24		9	52-71-13	ALL
	W0916	A-P			9	52-71-13	ALL
SP00318		1560/157/R042					ALL
	W1356	006	20		9	30-71-24	050-099
	W1356	006	22		9	30-71-23	150-154, 275-299
	W1356	006	20		9	30-71-23	155-199

SPLICE LIST
D280T132



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00318		1560/157/R042 (continued)					ALL
	W1356	B-A			9	30-71-24	050-099
	W1356	B-A			9	30-71-23	150-199, 275-299
SP00322		1572/140/L002					ALL
	W1356	002	20		9	30-71-23	050-099, 155-199
	W1356	002	22		9	30-71-23	150-154, 275-299
	W1356	A-A			9	30-71-23	ALL
	W1356	A-C			9	30-71-23	ALL
	W1356	C-A			9	30-71-23	ALL
SP00324		1560/180/R065					050-099
	W1356	005	20		9	30-71-23	050-099
	W1356	H-A			9	30-71-23	050-099
SP00327		905/305/R030					150-199
SP00327		0764/295/R060					275-299
	W0665	062	24		S	23-34-13	275-299
	W0665	066	22		S	33-25-11	150-199
	W0665	066	24		S	23-34-13	275-299
	W0792	066	22		S	33-25-11	150-199
	W0814	189	22		S	33-25-11	275-299
	W0828	024	22		S	33-25-11	150-199
	W0828	117	22		S	33-25-11	150-199
SP00329		905/305/R030					150-199
SP00329		0764/295/R060					275-299
	W0665	063	24		S	23-34-13	275-299
	W0665	067	22		S	33-25-11	150-199
	W0665	067	24		S	23-34-13	275-299
	W0792	066	22		S	33-25-11	275-299
	W0792	107	22		S	33-25-11	150-199
	W0814	189	22		S	33-25-11	150-199
	W0814	647	22		S	33-25-11	275-299
	W0828	027	22		S	33-25-11	150-199
	W0828	102	22		S	33-25-11	150-199
SP00332		1562/181/R064					ALL
	W1358	006	20		9	30-71-23	050-099, 155-199
	W1358	006	22		9	30-71-23	150-154, 275-299
	W1358	T-A			9	30-71-23	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00337		0230/285/L050					ALL
	W0631	015	24		VL	23-51-41	ALL
	W0631	015Z				23-51-41	ALL
	W0849	004	24		VL	23-51-41	ALL
	W0849	004Z				23-51-41	ALL
SP00338		1560/176/L065					050-099, 150-199
SP00338		1560/157/R042					275-276
SP00338		1560/157/L065					277-299
	W1358	008	20		9	30-71-23	050-099, 150-199, 275-276
	W1358	008	22		9	30-71-23	277-299
	W1358	U-A			9	30-71-23	ALL
SP00341		0190/190/L046					ALL
	W0731	051	20		9	34-43-11	050-099, 151
	W0733	051	20		9	34-43-11	050-099, 151
	W0779	025	20		9	34-43-12	ALL
	W0803	025	20		9	34-43-22	ALL
	W9090	906	22		9	34-46-13	150, 152-199, 275-299
SP00342		1564/156/R040					ALL
	W1358	003	20		9	30-71-23	050-099, 155-199
	W1358	003	22		9	30-71-23	150-154, 275-299
	W1358	W-A			9	30-71-23	ALL
SP00343		0160/220/L010					ALL
	W0011	108	20		9	33-13-11	ALL
	W0011	110	20		9	33-13-11	ALL
	W0011	112	20		9	33-13-11	ALL
	W0011	183	20		9	33-13-11	ALL
	W0051	050	20		9	33-13-11	ALL
SP00345		0160/220/L010					ALL
	W0011	120	16		9	33-13-11	ALL
	W0011	664	16		9	33-13-11	ALL
	W0011	716	20		9	33-13-11	ALL
	W0051	100	16		9	33-13-11	ALL
SP00347		0160/220/L010					ALL
	W0011	666	20		9	33-13-13	ALL

SPLICE LIST
D280T132



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00347		0160/220/L010 (continued)					ALL
	W0011	667	18		9	33-13-13	ALL
	W0011	669	18		9	33-13-13	ALL
	W0011	806	18		9	33-13-13	ALL
	W0011	812	20		9	33-13-13	ALL
	W0051	076	12		9	33-13-13	ALL
SP00349		0160/220/L010					ALL
	W0031	781	18		9	33-13-17	ALL
	W0051	084	18		9	33-13-17	ALL
	W0051	119	18		9	33-13-17	ALL
SP00351		0160/220/L010					ALL
	W0011	784	18		9	33-13-17	ALL
	W0051	121	18		9	33-13-17	ALL
SP00353		0160/220/L010					ALL
	W0011	786	18		9	33-13-17	ALL
	W0051	120	18		9	33-13-17	ALL
SP00354		1498/135/R021					050-099, 150-199, 277-299
	W1356	03X	20		9	30-71-24	050-099
	W1356	03X	20		9	30-71-23	150-199, 277-299
	W1356	N-B			9	30-71-24	050-099
	W1356	N-B			9	30-71-23	150-199, 277-299
SP00355		0160/220/L010					ALL
	W0011	116	18		9	33-13-11	050-099, 151
	W0011	118	20		9	33-13-11	050-099, 150-199, 275-278
	W0011	926	18		9	33-13-11	150, 152-199, 275-299
	W0051	071	16		9	33-13-11	ALL
	W0051	798	20		9	33-13-11	050-099
	W0051	798	18		9	33-13-11	150-199, 275-299
SP00358		1480/128/R022					ALL
	W1356	004	20		9	30-71-24	050-099
	W1356	004	22		9	30-71-23	150-154, 275-299
	W1356	004	20		9	30-71-23	155-199
	W1356	E-A			9	30-71-24	050-099
	W1356	E-A			9	30-71-23	150-199, 275-299

SPLICE LIST
D280T132

91-21-31
Section SP00300
Page 4
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00365		0160/220/L010					ALL
	W0011	813	22		9	34-22-36	ALL
	W0011	829	22		9	34-61-16	ALL
	W0031	744	24		9	34-61-26	150-199, 275-299
	W0031	808	22		9	34-22-36	ALL
	W0031	810	22		9	34-22-36	ALL
SP00366		0637/125/L058					050-099
SP00366		0665/125/L036					150-199, 275-299
	W1258	018	20		9	30-71-11	ALL
	W1258	X-C			9	30-71-11	ALL
SP00368		0665/116/L036					150-199, 275-299
	W1258	053	20		9	30-71-11	150-199, 275-299
	W1258	X-D			9	30-71-11	150-199, 275-299
SP00371		0220/194/L050					ALL
	W0203	005	22		9	34-57-21	ALL
	W0617	010	22		9	34-57-21	ALL
	W0617	010Z				34-57-21	ALL
SP00372		0315/188/L075					ALL
	W1258	001	20		9	30-71-21	050-099, 150-199
	W1258	001	22		9	30-71-21	275-299
	W1258	A-A			9	30-71-21	ALL
SP00373		0220/194/L050					ALL
	W0397	018	22		9	34-22-81	ALL
	W1340	014	22		9	34-22-81	ALL
SP00375		0135/170/L016					150-199
SP00376		0255/199/L075					ALL
	W1258	002	20		9	30-71-21	050-099, 150-199
	W1258	002	22		9	30-71-21	275-299
	W1258	B-A			9	30-71-21	ALL
SP00377		0135/170/L016					ALL
	W0606	074	22		9	31-31-22	ALL
	W0606	A-B			9	31-31-22	ALL



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00377		0135/170/L016 (continued)					ALL
	W0606	A-F			9	31-31-22	ALL
SP00379		0135/170/L016					150-199
SP00382		0322/189/L075					ALL
	W1258	003	20		9	30-71-21	050-099, 150-199
	W1258	003	22		9	30-71-21	275-299
	W1258	D-A			9	30-71-21	ALL
SP00386		0661/143/L075					ALL
	W1258	004	22		9	30-71-21	050-099, 275-299
	W1258	004	20		9	30-71-21	150-199
	W1258	E-A			9	30-71-21	ALL
SP00390		0632/138/L068					ALL
	W1258	005	22		9	30-71-21	050-099, 275-299
	W1258	005	20		9	30-71-21	150-199
	W1258	F-A			9	30-71-21	ALL
SP00391		1562/310/L010					ALL
	W0575	021Y	20		9	27-41-11	ALL
	W0591	010Y	20		9	27-41-11	ALL
SP00393		1562/310/L010					ALL
	W0581	021Y	20		9	27-41-21	ALL
	W0603	006Y	20		9	27-41-21	ALL
SP00394		0290/191/L075					ALL
	W1258	006	20		9	30-71-21	050-099, 150-199
	W1258	006	22		9	30-71-21	275-299
	W1258	G-A			9	30-71-21	ALL
SP00399		0368/195/L020					ALL
	W0645	148	22		9	23-31-12	ALL
	W0689	029	22		9	23-31-12	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00300
Page 6 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00400		1090/185/L071					ALL
	W1258	014	20		9	30-71-22	050-099, 155-199
	W1258	014	22		9	30-71-22	150-154, 275-299
	W1258	H-A			9	30-71-22	ALL
SP00402		1090/185/L071					ALL
	W1258	015	20		9	30-71-22	050-099
	W1258	015	22		9	30-71-22	150-199, 275-299
	W1258	I-A			9	30-71-22	ALL
SP00405		0190/190/L046					050-099, 275-299
	W0481	006Y	22		9	27-41-11	050-099, 275-299
	W1281	006Y	22		9	27-41-11	050-099, 275-299
SP00406		1021/196/L056					ALL
	W1258	016	20		9	30-71-22	050-099, 155-199
	W1258	016	22		9	30-71-22	150-154, 275-299
	W1258	J-A			9	30-71-22	ALL
SP00414		0786/178/L059					275-299
	W1258	027	20		9	30-71-22	275-299
	W1258	L-B			9	30-71-22	275-299
SP00416		0786/184/L023					050-099, 150-199
	W1258	059	20		9	30-71-22	050-099, 155-199
	W1258	059	22		9	30-71-22	150-154
	W1258	N-A			9	30-71-22	050-099
	W1258	U-G			9	30-71-22	150-199
SP00418		0786/197/L023					275-299
	W1258	028	20		9	30-71-22	275-299
	W1258	M-B			9	30-71-22	275-299
SP00420		0786/184/L023					050-099, 150-199
	W1258	029	20		9	30-71-22	050-099, 150-199
	W1258	U-H			9	30-71-22	050-099, 150-199
SP00422		0632/132/L070					050-099
	W1258	019	20		9	30-71-21	050-099
	W1258	O-A			9	30-71-21	050-099

SPLICE LIST
D280T132

91-21-31
Section SP00400
Page 1
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00425		0360/195/L020					050-099, 155-199, 275-299
	W0207	023	20		9	27-41-31	050-099, 155-199, 275-299
	W0521	003	20		9	27-41-31	050-099, 155-199, 275-299
SP00426		0632/163/L070					050-099
	W1258	020	20		9	30-71-21	050-099
	W1258	P-A			9	30-71-21	050-099
SP00427		0360/195/L020					050-099, 155-199, 275-299
	W0521	001	20		9	27-41-31	050-099, 155-199, 275-299
	W0521	002	20		9	27-41-31	050-099, 155-199, 275-299
	W1285	003	22		9	27-41-31	050-099, 155-199, 275-299
	W1285	003Z				27-41-31	050-099, 155-199, 275-299
SP00429		0368/195/L020					ALL
	W1407	014	20		S	23-32-11	ALL
	W1407	015	20		S	23-32-11	ALL
	W1417	501	20		S	23-32-21	ALL
SP00430		0246/201/R067					ALL
	W1258	021	20		9	30-71-21	050-099, 150-199
	W1258	021	22		9	30-71-21	275-299
	W1258	Q-A			9	30-71-21	ALL
SP00432		0246/201/R067					ALL
	W1258	007	20		9	30-71-21	ALL
	W1258	Q-B			9	30-71-21	ALL
SP00434		0630/163/L070					050-099
	W1258	022	20		9	30-71-21	050-099
	W1258	R-A			9	30-71-21	050-099
SP00437		0190/190/L046					050-099
	W0481	004Y	22		9	27-41-11	050-099
	W1281	004Y	22		9	27-41-11	050-099
SP00438		1097/188/L072					050-099, 150-199
	W1258	145	20		9	30-71-23	050-099
	W1258	145	20		9	30-71-24	150-199
	W1258	P-G			9	30-71-23	050-099

SPLICE LIST
D280T132

91-21-31
Section SP00400
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00438		1097/188/L072 (continued)					050-099, 150-199
	W1258	P-G			9	30-71-24	150-199
SP00439		0382/280/R042					050-099, 150-199
	W0123	030	20		9	33-27-11	050-099, 150-199
	W0123	A-A			9	33-27-11	050-099, 150-199
SP00441		0382/280/R042					050-099, 150-199
	W0123	031	20		9	33-27-11	050-099, 150-199
	W0123	A-B			9	33-27-11	050-099, 150-199
SP00442		1383/118/R021					ALL
	W1356	025	20		9	30-71-24	050-099
	W1356	025	22		9	30-71-23	150-154
	W1356	025	20		9	30-71-23	155-199
	W1356	A-E			9	30-71-24	050-099
	W1356	A-E			9	30-71-23	150-199
	W1366	001	22		9	30-71-23	275-299
	W1366	G-A			9	30-71-23	275-299
SP00444		1498/135/R021					050-099, 150-199
	W1356	026	20		9	30-71-24	050-099
	W1356	026	20		9	30-71-23	150-199
	W1356	A-F			9	30-71-24	050-099
	W1356	A-F			9	30-71-23	150-199
SP00445		0382/280/R042					050-099, 150-199
	W0123	039	20		9	33-27-11	050-099, 150-199
	W0123	A-C			9	33-27-11	050-099, 150-199
SP00446		1557/142/R028					050-099, 150-199
	W1358	004	20		9	30-71-23	050-099
	W1358	004	20		9	30-71-24	150-199
	W1358	Z-C			9	30-71-23	050-099
	W1358	Z-C			9	30-71-24	150-199
SP00447		0382/280/R042					050-099, 150-199
	W0123	040	20		9	33-27-11	050-099, 150-199
	W0123	A-D			9	33-27-11	050-099, 150-199



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00448		1373/150/L068					150-199
	W1258	147	20		9	30-71-23	150-199
	W1258	Z-B			9	30-71-23	150-199
SP00449		0382/280/R038					050-099, 150-199
	W0123	042	20		9	33-27-11	050-099, 150-199
	W0123	A-I			9	33-27-11	050-099, 150-199
SP00451		0382/280/R038					050-099, 150-199
	W0123	043	20		9	33-27-11	050-099, 150-199
	W0123	A-J			9	33-27-11	050-099, 150-199
SP00453		0382/280/R038					050-099, 150-199
	W0123	047	20		9	33-27-11	050-099, 150-199
	W0123	A-H			9	33-27-11	050-099, 150-199
SP00455		0382/280/R038					050-099, 150-199
	W0123	048	20		9	33-27-11	050-099, 150-199
	W0123	A-G			9	33-27-11	050-099, 150-199
SP00456		1351/170/L070					050-099, 150-199
	W1258	043	20		9	30-71-23	050-099
	W1258	043	20		9	30-71-24	150-199
	W1258	Y-A			9	30-71-23	050-099
	W1258	Y-A			9	30-71-24	150-199
SP00457		0382/284/L042					050-099, 150-199
	W0157	031	20		9	33-27-11	050-099, 150-199
	W0157	A-E			9	33-27-11	050-099, 150-199
SP00458		1351/170/L070					050-099, 150-199
	W1258	146	20		9	30-71-23	050-099
	W1258	146	20		9	30-71-24	150-199
	W1258	Y-B			9	30-71-23	050-099
	W1258	Y-B			9	30-71-24	150-199
SP00459		0382/284/L042					050-099, 150-199
	W0157	032	20		9	33-27-11	050-099, 150-199
	W0157	A-D			9	33-27-11	050-099, 150-199

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00460		1355/170/L072					ALL
	W0578	025	22		S	21-44-11	ALL
	W0580	092	22		S	21-44-11	ALL
SP00462		L254/14/RS					ALL
	W0482	001	18		9	28-25-21	ALL
	W0484	002	20		9	28-25-21	ALL
SP00463		0382/284/L042					050-099, 150-199
	W0157	034	20		9	33-27-11	050-099, 150-199
	W0157	A-B			9	33-27-11	050-099, 150-199
SP00464		L0340/14/RS					ALL
	W0454	008	18		9	28-22-21	ALL
	W0458	001	18		9	28-22-21	ALL
SP00465		0382/284/L042					050-099, 150-199
	W0157	035	20		9	33-27-11	050-099, 150-199
	W0157	A-C			9	33-27-11	050-099, 150-199
SP00466		R0327/14/RS					ALL
	W0456	022	18		9	28-22-21	ALL
	W0462	004	18		9	28-22-21	ALL
SP00467		0382/284/L038					050-099, 150-199
	W0157	050	20		9	33-27-11	050-099, 150-199
	W0157	A-I			9	33-27-11	050-099, 150-199
SP00469		0382/284/L038					050-099, 150-199
	W0157	051	20		9	33-27-11	050-099, 150-199
	W0157	A-J			9	33-27-11	050-099, 150-199
SP00471		0382/284/L038					050-099, 150-199
	W0157	045	20		9	33-27-11	050-099, 150-199
	W0157	A-H			9	33-27-11	050-099, 150-199
SP00473		0382/284/L038					050-099, 150-199
	W0157	046	20		9	33-27-11	050-099, 150-199
	W0157	A-G			9	33-27-11	050-099, 150-199



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00481		0220/194/L050					ALL
	W0629	024	24		W	23-51-11	050-099, 151-199, 275-299
	W0629	030	24		W	23-51-11	ALL
	W0631	026	24		W	23-51-21	151-152
	W0631	926	24		W	23-51-11	150
	W0845	005	24		W	23-51-11	050-099, 151-199, 275-299
SP00489		0764/295/R060					150-199
	W0792	801	16		9	38-13-11	150-199
	W0814	003	16		9	38-13-11	150-199
	W0814	696	16		9	38-13-11	150-199
	W0814	701	16		9	38-13-11	150-199
SP00491		0764/295/R060					150-199
	W0792	141	16		9	38-13-11	150-199
	W0792	150	16		9	38-13-11	150-199
	W0814	900	16		9	38-13-11	150-199
SP00495		0238/198/R035					050-099, 155-199, 276-299
	W0453	006	24		S	31-51-21	050-099, 155-199, 276-299
	W0598	066	24		S	31-51-21	050-099, 155-199, 276-299
SP00497		0238/198/R035					050-099, 155-199, 276-299
	W0453	056	24		S	31-51-21	050-099, 155-199, 276-299
	W0598	015	24		S	31-51-21	050-099, 155-199, 276-299
SP00499		0238/198/R035					050-099, 155-199, 276-299
	W0453	007	24		S	31-51-21	050-099, 155-199, 276-299
	W0596	061	24		S	31-51-21	050-099, 155-199, 276-299



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00501		0238/198/R035					050-099, 155-199, 276-299
	W0453	008	24		S	31-51-21	050-099, 155-199, 276-299
	W0596	062	24		S	31-51-21	050-099, 155-199, 276-299
SP00503		0238/198/R035					050-099, 155-199, 276-299
	W0451	008	24		S	31-51-21	050-099, 155-199, 276-299
	W0510	111	24		S	31-51-21	050-099, 155-199, 276-299
SP00505		0238/198/R035					050-099, 155-199, 276-299
	W0451	006	24		S	31-51-21	050-099, 155-199, 276-299
	W0510	112	24		S	31-51-21	050-099, 155-199, 276-299
SP00507		0220/194/L050					050-099, 151-199, 275-299
	W0631	024	24		W	23-51-21	050-099, 151-199, 275-299
	W0631	026	24		W	23-51-21	050-099, 153-199, 275-299
	W0845	006	24		W	23-51-11	050-099, 151-199, 275-299
SP00508		0865/118/R062					ALL
	W0980	007	18		9	33-31-21	ALL
	W0980	008	18		9	33-31-21	ALL
	W0980	A-A			9	33-31-21	ALL
SP00510		0917/115/R010					ALL
	W0980	008	18		9	33-31-21	ALL
	W0980	A-C			9	33-31-21	ALL
SP00512		0890/120/L062					ALL
	W0938	032	18		9	33-31-21	ALL
	W0938	A-A			9	33-31-21	ALL
SP00514		0860/107/L009					ALL
	W0938	031	18		9	33-31-21	ALL
	W0938	032	18		9	33-31-21	ALL
	W0938	A-C			9	33-31-21	ALL
SP00516		L0669/12/FS					ALL
	W0472	214R	20		9	28-21-11	ALL
	W0472	A-C			9	28-21-11	ALL



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00527		1070/315/R015					156-157, 166-199, 277-299
	W0811	012	24		9	23-25-17	156-157, 166-199, 277-299
	W0813	015	24		9	23-25-17	156-157, 166-199, 277-299
SP00550		1540/190/R030					ALL
	W0580	053	22		9	38-32-15	156-157, 166-199, 277-299
	W0580	053Z				38-32-15	156-157, 166-199, 277-299
	W0966	057	20		9	38-32-11	ALL
	W0966	057Z				38-32-11	050-099, 155-199, 275-299
	W0966	501	22		9	38-32-14	275-276
	W0966	501Z				38-32-14	275-276
	W1354	021	22		9	38-32-11	050-099, 275-276
	W1354	021	20		9	38-32-11	150-156, 162-165
	W1354	021	18		9	38-32-11	157, 166-199, 277-299
	W1354	022	22		9	38-32-11	050-099, 275-276
	W1354	022	20		9	38-32-11	150-156, 162-165
	W1354	022	18		9	38-32-11	157, 166-199, 277-299
	W1354	023	22		9	38-32-11	050-099, 275-276
	W1354	023	20		9	38-32-11	150-156, 162-165
	W1354	023	18		9	38-32-11	157, 166-199, 277-299
	W1354	047	22		9	38-32-11	050-099, 150-155, 162-165
	W1354	047	22		9	38-32-15	156-157, 166-199, 277-299
	W1354	047	22		9	38-32-14	275-276
SP00556		0146/167/L001					ALL
	W0902	201R	24		9	52-71-14	ALL
	W0902	A-W			9	52-71-14	ALL
SP00558		0146/167/L001					ALL
	W0902	201B	24		9	52-71-14	ALL
	W0902	A-X			9	52-71-14	ALL
SP00560		0302/135/R020					ALL
	W0902	202R	24		9	52-71-14	ALL
	W0902	A-Y			9	52-71-14	ALL
SP00561		0335/192/R055					280-299
	W0853	031	12		9	23-34-17	280-299
	W1381	019	12		9	23-34-17	280-299

SPLICE LIST
D280T132

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00562		0302/135/R020					ALL
	W0902	202B	24		9	52-71-14	ALL
	W0902	A-Z			9	52-71-14	ALL
SP00565		0173/195/R034					050-099, 150-199, 278-299
	W0465	017Y	22		9	27-41-11	150-199
	W0469	D-C			9	27-41-11	050-099, 150-199, 278-299
	W1281	017Y	22		9	27-41-11	050-099, 278-299
SP00567		0173/195/R034					050-099, 150-199, 278-299
	W0465	016Y	22		9	27-41-11	150-199
	W0469	D-A			9	27-41-11	050-099, 150-199, 278-299
	W1281	016Y	22		9	27-41-11	050-099, 278-299
SP00568		0354/280/R032					ALL
	W0665	018	22		S	33-25-11	ALL
	W0665	019	22		S	33-25-11	275-299
	W0665	190	22		S	33-25-11	050-099, 150-199
	W0814	635	22		S	33-25-11	275-299
	W0820	016	22		S	33-25-11	275-299
	W0820	059	22		S	33-25-11	050-099, 150-199
SP00569		0173/195/R034					050-099, 150-199, 278-299
	W0465	019Y	22		9	27-41-11	150-199
	W0469	E-C			9	27-41-11	050-099, 150-199, 278-299
	W1281	019Y	22		9	27-41-11	050-099, 278-299
SP00570		0894/320/R030					050-099
SP00570		0905/305/R030					150-199, 275-299
	W0665	020	22		S	33-25-11	275-276
	W0665	026	22		S	33-25-11	275-276
	W0665	028	22		S	33-25-11	050-099
	W0665	180	22		S	33-25-11	150-199
	W0665	181	22		S	33-25-11	050-099
	W0665	191	22		S	33-25-11	050-099
	W0665	511	22		S	33-25-11	275-276
	W0665	528	22		S	33-25-11	277-299
	W0792	068	22		S	33-25-11	275-299
	W0792	125	22		S	33-25-11	150-199
	W0792	185	22		S	33-25-11	150-199

SPLICE LIST

D280T132

91-21-31

Section SP00500

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00570		0894/320/R030 (continued)					050-099
SP00570		0905/305/R030 (continued)					150-199, 275-299
	W0814	013	22		S	33-25-11	050-099
	W0814	191	22		S	33-25-11	150-199
	W0814	665	22		S	33-25-11	275-299
	W0814	824	22		S	33-25-11	050-099
SP00571		0173/195/R034					050-099, 150-199, 278-299
	W0465	018Y	22		9	27-41-11	150-199
	W0469	E-A			9	27-41-11	050-099, 150-199, 278-299
	W1281	018Y	22		9	27-41-11	050-099, 278-299
SP00572		0894/320/R030					050-099
SP00572		0905/305/R030					150-199
	W0665	021	22		9	33-25-11	150-199
	W0665	022	22		9	33-25-11	150-199
	W0665	026	22		S	33-25-11	050-099
	W0665	199	22		S	33-25-11	050-099
	W0792	169	22		S	33-25-11	050-099
	W0792	172	22		S	33-25-11	050-099
	W0792	504	22		9	33-25-11	150-199
	W0828	135	22		9	33-25-11	150-199
SP00573		0173/195/L034					050-099, 150-199, 278-299
	W0465	D-C			9	27-41-21	150-199
	W0469	017Y	22		9	27-41-21	050-099, 150-199, 278-299
	W1281	D-C			9	27-41-21	050-099, 278-299
SP00574		1450/280/L055					050-099
SP00574		0764/295/R060					150-199
SP00574		1439/310/L020					275-299
	W0665	021	22		S	33-25-11	050-099
	W0665	022	22		S	33-25-11	050-099
	W0665	023	22		S	33-25-11	275-299
	W0665	199	22		S	33-25-11	150-199
	W0792	169	22		S	33-25-11	150-199
	W0792	172	22		S	33-25-11	150-199
	W0814	822	22		S	33-25-11	150-154, 156, 162-199
	W0828	029	22		S	33-25-11	275-299
	W0828	135	22		S	33-25-11	050-099
	W0828	608	22		S	33-25-11	050-099

SPLICE LIST

D280T132

91-21-31

Section SP00500

Page 4

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00575		0173/195/L034					050-099, 150-199, 278-299
	W0465	D-A			9	27-41-21	150-199
	W0469	016Y	22		9	27-41-21	050-099, 150-199, 278-299
	W1281	D-A			9	27-41-21	050-099, 278-299
SP00576		1441/280/R045					150-199, 275-299
	W0665	022	22		S	33-25-11	275-299
	W0665	181	22		S	33-25-11	150-199
	W0665	191	22		S	33-25-11	150-154, 156, 162-199
	W0814	013	22		S	33-25-11	150-199
	W0814	824	22		S	33-25-11	150-199
	W1276	013	22		S	33-25-11	275-299
SP00577		0173/195/L034					050-099, 150-199, 278-299
	W0465	E-C			9	27-41-21	150-199
	W0469	019Y	22		9	27-41-21	050-099, 150-199, 278-299
	W1281	E-C			9	27-41-21	050-099, 278-299
SP00579		0173/195/L034					050-099, 150-199, 278-299
	W0465	E-A			9	27-41-21	150-199
	W0469	018Y	22		9	27-41-21	050-099, 150-199, 278-299
	W1281	E-A			9	27-41-21	050-099, 278-299
SP00581		315/190/L050					157, 167-199, 277-299
	W1701	054	24		9	27-48-11	157, 167-199, 277-299
	W1702	095	24		9	27-48-11	157, 167-199, 277-299
SP00583		315/190/L050					157, 167-199, 277-299
	W1701	049	24		9	27-48-11	157, 167-199, 277-299
	W1702	096	24		9	27-48-11	157, 167-199, 277-299
SP00587		1035/301/L057					156-157, 166-199, 277-299
SP00594		1548/247/R076					050-099, 150-199
	W1356	553	20		9	38-15-11	050-099, 150-199
	W1356	M-B			9	38-15-11	050-099, 150-199
SP00596		1548/247/R076					050-099, 150-199
	W1356	55X	20		9	38-15-11	050-099, 150-199
	W1356	M-A			9	38-15-11	050-099, 150-199

SPLICE LIST
D280T132

91-21-31
Section SP00500
Page 5
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00598		L0340/12/RS					ALL
	W0446	212B	18		9	28-43-11	ALL
	W0446	A-A			9	28-43-11	ALL

SPLICE LIST

D280T132

91-21-31

Section SP00500

Page 6 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00600		L0340/12/RS					ALL
	W0446	018	18		9	28-43-11	ALL
	W0446	212R	18		9	28-43-11	ALL
	W0446	A-B			9	28-43-11	ALL
SP00602		1490/190/R070					ALL
	W1298	006	20		9	38-32-11	ALL
	W1358	13F	18		9	38-32-11	ALL
SP00606		1400/290/R080					ALL
	W0828	038	22		S	38-32-13	050-099, 150-156, 162-165, 275-276
	W0828	038	22		S	38-32-16	157, 166-199, 277-299
	W0828	042	22		S	38-32-13	050-099, 150-156, 162-165, 275-276
	W0828	042	22		S	38-32-16	157, 166-199, 277-299
	W0966	022	22		S	38-32-11	ALL
SP00612		1680/255/R059					ALL
	W0242	027	18		9	33-31-31	ALL
	W0242	A-A			9	33-31-31	ALL
SP00614		1833/242/R034					ALL
	W0242	029	18		9	33-31-31	ALL
	W0242	A-C			9	33-31-31	ALL
SP00616		L0669/12/FS					ALL
	W0472	215R	20		9	28-21-11	ALL
	W0472	A-A			9	28-21-11	ALL
SP00618		0786/178/L059					050-099, 275-299
	W1258	017	20		9	30-71-21	050-099
	W1258	017	22		9	30-71-22	275-299
	W1258	L-A			9	30-71-21	050-099
	W1258	L-A			9	30-71-22	275-299
SP00620		0786/197/L023					275-299
	W1258	055	22		9	30-71-22	275-299
	W1258	M-A			9	30-71-22	275-299
SP00624		1373/150/L068					150-199
	W1258	057	22		9	30-71-23	150-154

SPLICE LIST
D280T132

91-21-31
Section SP00600
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00624		1373/150/L068 (continued)					150-199
	W1258	057	20		9	30-71-23	155-199
	W1258	Z-A			9	30-71-23	150-199
SP00628		1498/135/R026					050-099
SP00628		1398/135/R021					150-199
SP00628		1498/135/R021					277-299
	W1356	003	20		9	30-71-24	050-099
	W1356	003	22		9	30-71-23	150-154, 277-299
	W1356	003	20		9	30-71-23	155-199
	W1356	N-A			9	30-71-24	050-099
	W1356	N-A			9	30-71-23	150-199, 277-299
SP00630		1562/179/R064					275-276
	W1358	005	22		9	30-71-23	275-276
	W1358	S-A			9	30-71-23	275-276
SP00632		1560/176/L065					ALL
	W1358	002	20		9	30-71-24	050-099
	W1358	002	22		9	30-71-23	150-154, 275-299
	W1358	002	20		9	30-71-23	155-199
	W1358	V-A			9	30-71-24	050-099
	W1358	V-A			9	30-71-23	150-199, 275-299
SP00648		1562/289/L070					275-299
	W0216	002	18		S	33-51-13	275-299
	W0788	008	18		S	33-51-13	275-299
SP00650		1562/280/R070					275-299
	W0304	020	16		S	33-51-12	275-299
	W0790	011	16		S	33-51-12	275-299
SP00656		0340/280/R080					ALL
	W0780	201R	24		9	52-71-11	ALL
	W0780	A-A			9	52-71-11	ALL
SP00658		0340/280/R080					ALL
	W0780	201B	24		9	52-71-11	ALL
	W0780	A-B			9	52-71-11	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00660		0340/280/R080					ALL
	W0780	202R	24		9	52-71-11	ALL
	W0780	B-A			9	52-71-11	ALL
SP00662		0340/280/R080					ALL
	W0780	202B	24		9	52-71-11	ALL
	W0780	B-B			9	52-71-11	ALL
SP00664		0320/280/L080					ALL
	W1226	208R	24		9	52-71-11	ALL
	W1226	E-A			9	52-71-11	ALL
SP00666		0320/280/L080					ALL
	W1226	208B	24		9	52-71-11	ALL
	W1226	E-B			9	52-71-11	ALL
SP00668		0320/280/L080					ALL
	W1226	209R	24		9	52-71-11	ALL
	W1226	F-A			9	52-71-11	ALL
SP00670		0320/280/L080					ALL
	W1226	209B	24		9	52-71-11	ALL
	W1226	F-B			9	52-71-11	ALL
SP00672		1538/246/R082					050-099
SP00672		1515/274/R085					150-199, 275-299
	W0790	204R	24		9	52-71-11	ALL
	W0790	A-A			9	52-71-11	ALL
SP00674		1538/246/R082					050-099
SP00674		1515/274/R085					150-199, 275-299
	W0790	204B	24		9	52-71-11	ALL
	W0790	A-B			9	52-71-11	ALL
SP00676		1520/280/R080					050-099
SP00676		1515/274/R085					150-199, 275-299
	W0790	205R	24		9	52-71-11	ALL
	W0790	B-A			9	52-71-11	ALL



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00678		1520/280/R000					050-099
SP00678		1515/274/R085					150-199, 275-299
	W0790	205B	24		9	52-71-11	ALL
	W0790	B-B			9	52-71-11	ALL
SP00680		1507/276/L086					ALL
	W0788	201R	24		9	52-71-11	ALL
	W0788	A-A			9	52-71-11	ALL
SP00682		1507/276/L086					ALL
	W0788	201B	24		9	52-71-11	ALL
	W0788	A-B			9	52-71-11	ALL
SP00684		1507/276/L086					ALL
	W0788	202R	24		9	52-71-11	ALL
	W0788	B-A			9	52-71-11	ALL
SP00686		1507/276/L086					ALL
	W0788	202B	24		9	52-71-11	ALL
	W0788	B-B			9	52-71-11	ALL
SP00688		0884/250/R092					050-099
SP00688		0881/250/R092					150-199, 275-299
	W0786	203R	24		9	52-71-12	ALL
	W0786	A-A			9	52-71-12	ALL
SP00690		0884/250/R092					050-099
SP00690		0881/250/R092					150-199, 275-299
	W0786	203B	24		9	52-71-12	ALL
	W0786	A-B			9	52-71-12	ALL
SP00692		0884/250/L095					ALL
	W0784	205R	24		9	52-71-12	ALL
	W0784	A-A			9	52-71-12	ALL
SP00694		0884/250/L095					ALL
	W0784	205B	24		9	52-71-12	ALL
	W0784	A-B			9	52-71-12	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00600
Page 4
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00696		1146/171/R093					ALL
	W0916	218R	20		9	52-71-12	ALL
	W0916	X-A			9	52-71-12	ALL
SP00698		1146/171/R093					ALL
	W0916	218B	20		9	52-71-12	ALL
	W0916	X-B			9	52-71-12	ALL



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00700		1146/171/L093					ALL
	W0916	219R	20		9	52-71-12	ALL
	W0916	B-A			9	52-71-12	ALL
SP00702		1146/171/L093					ALL
	W0916	219B	20		9	52-71-12	ALL
	W0916	B-B			9	52-71-12	ALL
SP00704		0287/245/R080					ALL
	W0780	203R	24		9	52-71-11	ALL
	W0780	C-A			9	52-71-11	ALL
SP00706		0287/245/R080					ALL
	W0780	203B	24		9	52-71-11	ALL
	W0780	C-B			9	52-71-11	ALL
SP00708		0287/250/L080					ALL
	W1226	216R	24		9	52-71-11	ALL
	W1226	G-A			9	52-71-11	ALL
SP00710		0287/250/L080					ALL
	W1226	216B	24		9	52-71-11	ALL
	W1226	G-B			9	52-71-11	ALL
SP00716		1535/246/L093					ALL
	W0788	203R	24		9	52-71-11	ALL
	W0788	C-A			9	52-71-11	ALL
SP00718		1535/246/L093					ALL
	W0788	203B	24		9	52-71-11	ALL
	W0788	C-B			9	52-71-11	ALL
SP00720		0354/280/R032					275-299
	W0222	072	22		9	33-27-11	275-299
	W1230	045	22		9	33-27-11	275-299
SP00724		0354/280/R032					275-299
	W0222	073	22		9	33-27-11	275-299
	W1230	047	22		9	33-27-11	275-299

SPLICE LIST
D280T132

91-21-31
Section SP00700
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00726		1400/290/R080					275-299
	W0304	009	22		9	33-27-11	275-299
	W1240	045	22		9	33-27-11	275-299
SP00728		1400/290/R080					275-299
	W0304	008	22		9	33-27-11	275-299
	W1240	047	22		9	33-27-11	275-299
SP00738		1572/140/0000					ALL
	W0966	B-A			9	38-32-11	ALL
	W1298	007	20		9	38-32-11	ALL
SP00740		1572/140/0000					ALL
	W0966	022	22		9	38-32-11	ALL
	W0966	B-B			9	38-32-11	ALL
SP00742		NL132/087/					ALL
	W3528	01TB	20		8	78-34-11	ALL
	W3528	01TI				78-34-11	ALL
	W3528	A-A			8	78-34-11	ALL
SP00744		NL126/092/					ALL
	W3528	01TR	20		8	78-34-11	ALL
	W3528	A-B			8	78-34-11	ALL
SP00746		NL122/092/					ALL
	W3526	01TB	20		8	78-34-11	ALL
	W3526	01TI				78-34-11	ALL
	W3526	A-A			8	78-34-11	ALL
SP00748		NL122/092/					ALL
	W3526	01TR	20		8	78-34-11	ALL
	W3526	A-B			8	78-34-11	ALL
SP00752		1562/310/L010					ALL
	W0500	012	18		9	27-21-11	ALL
	W0500	012Z				27-21-11	ALL
	W0593	011	18		9	27-21-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00700
Page 2
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00760		0300/277/L070					ALL
	W1224	010	22		9	52-11-12	ALL
	W1224	A-A			9	52-11-12	ALL
SP00762		0300/277/L070					ALL
	W1224	011	20		9	52-11-12	ALL
	W1224	A-B			9	52-11-12	ALL
SP00764 SP00764		P024-00/ / 0462 170/R/					050-099 150-199, 275-299
	W0700	003	20		1A	25-53-11	ALL
	W0700	A-A			1A	25-53-11	ALL
SP00766 SP00766		P024-00/ / 0462 170/R/					050-099 150-199, 275-299
	W0700	034	20		1A	25-53-11	ALL
	W0700	A-B			1A	25-53-11	ALL
SP00768		P027-00/ /					ALL
	W0706	003	20		1A	25-53-21	ALL
	W0706	A-A			1A	25-53-21	ALL
SP00770		P027-00/ /					ALL
	W0706	034	20		1A	25-53-21	ALL
	W0706	A-B			1A	25-53-21	ALL
SP00780		1490/190/R070					ALL
	W0580	019	18		9	38-32-11	050-099, 150-155, 162-165, 275-276
	W0580	019	18		9	38-32-15	156-157, 166-199, 277-299
	W0966	034	22		9	38-32-11	ALL
	W0966	037	18		9	38-32-11	ALL
	W0966	054	20		9	38-32-11	ALL
	W0966	088	22		9	38-32-11	050-099, 150-155, 162-165
	W0966	088	22		9	38-32-15	156-157, 166-199, 277-299
	W0966	088	22		9	38-32-14	275-276
SP00784		0355/140/R064					ALL
	W0616	045	18		9	33-37-11	050-099
	W0616	045	16		9	33-37-11	150-199, 275-299
	W0616	A-A			9	33-37-11	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00786		0355/140/R064					ALL
	W0616	046	18		9	33-37-11	050-099
	W0616	046	16		9	33-37-11	150-199, 275-299
	W0616	A-B			9	33-37-11	ALL
SP00788		0543/284/R050					050-099
SP00788		0544/284/R050					150-199, 275-299
	W0812	190	20		9	33-21-11	ALL
	W0812	F-C			9	33-21-11	ALL
SP00790		0543/284/R050					050-099
SP00790		0546/284/R050					150-199, 275-299
	W0812	191	20		9	33-21-11	ALL
	W0812	F-D			9	33-21-11	ALL
SP00792		0631/284/R050					050-099
SP00792		0625/284/R050					150-199, 275-299
	W0812	179	20		9	33-21-11	ALL
	W0812	F-A			9	33-21-11	ALL
SP00794		0631/284/R050					050-099
SP00794		0625/284/R050					150-199, 275-299
	W0812	180	20		9	33-21-11	ALL
	W0812	F-B			9	33-21-11	ALL
SP00796		0544/284/L050					050-099
SP00796		0546/291/L065					150-199, 275-299
	W0812	184	20		9	33-21-11	ALL
	W0812	E-A			9	33-21-11	ALL
SP00798		0546/284/L050					050-099
SP00798		0546/291/L065					150-199, 275-299
	W0812	185	20		9	33-21-11	ALL
	W0812	E-B			9	33-21-11	ALL

SPLICE LIST

D280T132

91-21-31

Section SP00700

Page 4 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00800		0635/284/L050					050-099
SP00800		0632/291/L065					150-199, 275-299
	W0812	186	20		9	33-21-11	ALL
	W0812	190	20		9	33-21-11	ALL
	W0812	E-C			9	33-21-11	ALL
SP00802		0635/284/L050					050-099
SP00802		0632/291/L065					150-199, 275-299
	W0812	187	20		9	33-21-11	ALL
	W0812	191	20		9	33-21-11	ALL
	W0812	E-D			9	33-21-11	ALL
SP00804		0631/284/R050					050-099
SP00804		0675/284/R050					150-199, 275-278
	W0812	504	20		9	33-21-11	050-099
	W0812	504	20		9	33-21-13	150-199, 275-278
	W0812	S-C			9	33-21-11	050-099
	W0812	S-C			9	33-21-13	150-199, 275-278
SP00806		0631/284/R050					050-099
SP00806		0675/284/R050					150-199, 275-278
	W0812	505	20		9	33-21-11	050-099
	W0812	505	20		9	33-21-13	150-199, 275-278
	W0812	S-D			9	33-21-11	050-099
	W0812	S-D			9	33-21-13	150-199, 275-278
SP00808		0719/284/R050					050-099
SP00808		0675/284/R050					150-199, 275-278
	W0812	192	20		9	33-21-11	050-099
	W0812	192	20		9	33-21-13	150-199, 275-278
	W0812	S-A			9	33-21-11	050-099
	W0812	S-A			9	33-21-13	150-199, 275-278
SP00810		0719/284/R050					050-099
SP00810		0675/284/R050					150-199, 275-278
	W0812	193	20		9	33-21-11	050-099
	W0812	193	20		9	33-21-13	150-199, 275-278
	W0812	S-B			9	33-21-11	050-099
	W0812	S-B			9	33-21-13	150-199, 275-278

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00812		0631/284/L050					050-099
SP00812		0675/284/L050					150-157, 163-199, 275-278
SP00812		0654+69/284/L050					162
	W0812	197	20		9	33-21-11	050-099
	W0812	197	20		9	33-21-13	150-199, 275-278
	W0812	G-A			9	33-21-11	050-099
	W0812	G-A			9	33-21-13	150-199, 275-278
SP00814		0631/284/L050					050-099
SP00814		0675/284/L050					150-157, 275-278
SP00814		0654+69/284/L050					162-199
	W0812	198	20		9	33-21-11	050-099
	W0812	198	20		9	33-21-13	150-199, 275-278
	W0812	G-B			9	33-21-11	050-099
	W0812	G-B			9	33-21-13	150-199, 275-278
SP00816		0719/284/L050					050-099
SP00816		0763/284/L050					150-157, 275-278
SP00816		0670/284/L050					162-199
SP00816		0654+110/284/L050					280-299
	W0812	03V	20		9	33-21-13	280-299
	W0812	199	20		9	33-21-11	050-099
	W0812	199	20		9	33-21-13	150-199, 275-278
	W0812	504	20		9	33-21-11	050-099
	W0812	504	20		9	33-21-13	150-199, 275-299
	W0812	G-C			9	33-21-11	050-099
	W0812	G-C			9	33-21-13	150-199, 275-278
SP00818		0719/284/L050					050-099
SP00818		0763/284/L050					150-157, 275-278
SP00818		0670/284/L050					162-199
SP00818		0654+110/284/L050					280-299
	W0812	03U	20		9	33-21-13	280-299
	W0812	501	20		9	33-21-11	050-099
	W0812	501	20		9	33-21-13	150-199, 275-278
	W0812	505	20		9	33-21-11	050-099
	W0812	505	20		9	33-21-13	150-199, 275-299
	W0812	G-D			9	33-21-11	050-099
	W0812	G-D			9	33-21-13	150-199, 275-278

SPLICE LIST

D280T132

91-21-31

Section SP00800

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00820		0587/280/R025					050-099
SP00820		0568/283/R026					150-199, 275-299
	W0822	049	20		9	33-21-11	ALL
	W0822	G-C			9	33-21-11	ALL
SP00822		0587/280/R025					050-099
SP00822		0568/283/R026					150-199, 275-299
	W0822	050	20		9	33-21-11	ALL
	W0822	G-D			9	33-21-11	ALL
SP00824		0587/280/R025					050-099
SP00824		0568/283/R026					150-199, 275-299
	W0822	040	20		9	33-21-11	ALL
	W0822	G-A			9	33-21-11	ALL
SP00826		0587/280/R025					050-099
SP00826		0568/283/R026					150-199, 275-299
	W0822	041	20		9	33-21-11	ALL
	W0822	G-B			9	33-21-11	ALL
SP00828		0587/280/L025					050-099
SP00828		0628/285/L025					150-199, 275-299
	W0822	045	20		9	33-21-11	ALL
	W0822	F-A			9	33-21-11	ALL
SP00830		0587/280/L025					050-099
SP00830		0628/285/L025					150-199, 275-299
	W0822	046	20		9	33-21-11	ALL
	W0822	F-B			9	33-21-11	ALL
SP00832		0587/280/L025					050-099
SP00832		0628/285/L025					150-199, 275-299
	W0822	047	20		9	33-21-11	ALL
	W0822	049	20		9	33-21-11	ALL
	W0822	F-C			9	33-21-11	ALL
SP00834		0587/280/L025					050-099
SP00834		0628/285/L025					150-199, 275-299
	W0822	048	20		9	33-21-11	ALL
	W0822	050	20		9	33-21-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00800
Page 3
Jan 21/2005

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00834		0587/280/L025 (continued)					050-099
SP00834		0628/285/L025 (continued)					150-199, 275-299
	W0822	F-D			9	33-21-11	ALL
SP00836		0675/280/R025					050-099, 150-199, 275-278
	W0822	061	20		9	33-21-11	050-099
	W0822	061	20		9	33-21-13	150-199, 275-278
	W0822	J-C			9	33-21-11	050-099
	W0822	J-C			9	33-21-13	150-199, 275-278
SP00837		0256/288/L015					ALL
	W2214	003	24		9	52-51-11	050-099, 150-163, 166-199, 275-299
	W2214	A-A			9	52-51-11	050-099, 150-163, 166-199, 275-299
	W2214	A-F			9	52-51-11	050-099, 150-163, 166-199, 275-299
SP00838		0675/280/R025					050-099, 150-199, 275-278
	W0822	062	20		9	33-21-11	050-099
	W0822	062	20		9	33-21-13	150-199, 275-278
	W0822	J-D			9	33-21-11	050-099
	W0822	J-D			9	33-21-13	150-199, 275-278
SP00840		0675/280/R025					050-099, 150-199, 275-278
	W0822	052	20		9	33-21-11	050-099
	W0822	052	20		9	33-21-13	150-199, 275-278
	W0822	J-A			9	33-21-11	050-099
	W0822	J-A			9	33-21-13	150-199, 275-278
SP00841		0256/288/L015					ALL
	W2214	A-E			9	52-51-11	050-099, 150-163, 166-199, 275-299
	W2214	A-Q			9	52-51-11	050-099, 150-163, 166-199, 275-299
SP00842		0675/280/R025					050-099, 150-199, 275-278
	W0822	053	20		9	33-21-11	050-099
	W0822	053	20		9	33-21-13	150-199, 275-278
	W0822	J-B			9	33-21-11	050-099
	W0822	J-B			9	33-21-13	150-199, 275-278
SP00843		0238/273/L015					ALL
	W2214	009	24		9	52-51-11	050-099, 150-163, 166-199, 275-299
	W2214	A-P			9	52-51-11	050-099, 150-163, 166-199, 275-299

SPLICE LIST

D280T132

91-21-31

Section SP00800

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00844		0675/280/L025					050-099
SP00844		0763/280/L025					150-199, 275-278
	W0822	057	20		9	33-21-11	050-099
	W0822	057	20		9	33-21-13	150-199, 275-278
	W0822	H-A			9	33-21-11	050-099
	W0822	H-A			9	33-21-13	150-199, 275-278
SP00846		0675/280/L025					050-099
SP00846		0763/280/L025					150-199, 275-278
	W0822	058	20		9	33-21-11	050-099
	W0822	058	20		9	33-21-13	150-199, 275-278
	W0822	H-B			9	33-21-11	050-099
	W0822	H-B			9	33-21-13	150-199, 275-278
SP00847		0238/273/L015					ALL
	W2214	010	24		9	52-51-11	050-099, 150-163, 166-199, 275-299
	W2214	A-J			9	52-51-11	050-099, 150-163, 166-199, 275-299
SP00848		0675/280/L025					050-099
SP00848		0763/280/L025					150-199, 275-278
	W0822	059	20		9	33-21-11	050-099
	W0822	059	20		9	33-21-13	150-199, 275-278
	W0822	061	20		9	33-21-11	050-099
	W0822	061	20		9	33-21-13	150-199, 275-278
	W0822	H-C			9	33-21-11	050-099
	W0822	H-C			9	33-21-13	150-199, 275-278
SP00849		0238/273/L015					ALL
	W2214	021	24		9	52-51-11	050-099, 150-163, 166-199, 275-299
	W2214	A-K			9	52-51-11	050-099, 150-163, 166-199, 275-299
SP00850		0675/280/L025					050-099
SP00850		0763/280/L025					150-199, 275-278
	W0822	060	20		9	33-21-11	050-099
	W0822	060	20		9	33-21-13	150-199, 275-278
	W0822	062	20		9	33-21-11	050-099
	W0822	062	20		9	33-21-13	150-199, 275-278
	W0822	H-D			9	33-21-11	050-099
	W0822	H-D			9	33-21-13	150-199, 275-278

SPLICE LIST
D280T132

91-21-31
Section SP00800
Page 5
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00852		L0669/14/LE					ALL
	W0472	01TR	20		9	23-41-11	ALL
	W0472	A-E			9	23-41-11	ALL
SP00853		0238/273/L015					ALL
	W2214	019	24		9	52-51-11	050-099, 150-163, 166-199, 275-299
	W2214	A-L			9	52-51-11	050-099, 150-163, 166-199, 275-299
SP00854		L0669/14/LE					ALL
	W0472	01TB	20		9	23-41-11	ALL
	W0472	A-F			9	23-41-11	ALL
SP00856		L0669/14/LE					ALL
	W0472	01TI			9	23-41-11	ALL
	W0472	A-G			9	23-41-11	ALL
SP00858		0367/284/R050					275-299
	W0812	163	20		9	33-21-11	275-299
	W0812	A-C			9	33-21-11	275-299
SP00860		0367/284/R050					275-299
	W0812	164	20		9	33-21-11	275-299
	W0812	A-D			9	33-21-11	275-299
SP00862		0368/284/L050					275-299
	W0812	157	20		9	33-21-11	275-299
	W0812	B-A			9	33-21-11	275-299
SP00864		0368/280/L050					275-299
	W0812	158	20		9	33-21-11	275-299
	W0812	B-B			9	33-21-11	275-299
SP00866		0456/284/L050					275-299
	W0812	159	20		9	33-21-11	275-299
	W0812	163	20		9	33-21-11	275-299
	W0812	B-C			9	33-21-11	275-299
SP00868		0456/284/L050					275-299
	W0812	160	20		9	33-21-11	275-299
	W0812	164	20		9	33-21-11	275-299

SPLICE LIST
D280T132



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00868		0456/284/L050 (continued)					275-299
	W0812	B-D			9	33-21-11	275-299
SP00870		0456/284/R050					050-099, 150-199
SP00870		0458/284/R050					275-299
	W0812	177	20		9	33-21-11	ALL
	W0812	C-C			9	33-21-11	ALL
SP00872		0456/284/R050					050-099, 150-199
SP00872		0458/284/R050					275-299
	W0812	178	20		9	33-21-11	ALL
	W0812	C-D			9	33-21-11	ALL
SP00874		0544/284/R050					050-099, 150-199
SP00874		0540/284/R050					275-299
	W0812	166	20		9	33-21-11	ALL
	W0812	C-A			9	33-21-11	ALL
SP00876		0544/284/R050					050-099
SP00876		0540/284/R050					150-199, 275-299
	W0812	167	20		9	33-21-11	ALL
	W0812	C-B			9	33-21-11	ALL
SP00878		0456/284/L050					ALL
	W0812	171	20		9	33-21-11	ALL
	W0812	D-A			9	33-21-11	ALL
SP00880		0456/284/L050					ALL
	W0812	172	20		9	33-21-11	ALL
	W0812	D-B			9	33-21-11	ALL
SP00882		0544/284/L050					ALL
	W0812	173	20		9	33-21-11	ALL
	W0812	177	20		9	33-21-11	ALL
	W0812	D-C			9	33-21-11	ALL
SP00884		0544/284/L050					ALL
	W0812	174	20		9	33-21-11	ALL
	W0812	178	20		9	33-21-11	ALL
	W0812	D-D			9	33-21-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP00800
Page 7
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00886		0411/284/R050					275-299
	W0812	152	20		9	33-21-11	275-299
	W0812	A-A			9	33-21-11	275-299
SP00888		0411/284/R050					275-299
	W0812	153	20		9	33-21-11	275-299
	W0812	A-B			9	33-21-11	275-299
SP00898		0451/285/L026					275-299
	W0822	070	20		9	33-21-11	275-299
	W0822	K-A			9	33-21-11	275-299

SPLICE LIST
D280T132

91-21-31
Section SP00800
Page 8 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00900		0451/285/L026					275-299
	W0822	071	20		9	33-21-11	275-299
	W0822	K-B			9	33-21-11	275-299
SP00901		0220/194/L50					150
	W0629	024	24		W	23-51-11	150
	W0631	926	24		W	23-51-11	150
	W0845	005	24		W	23-51-11	150
SP00902		0451/285/L026					275-299
	W0822	072	20		9	33-21-11	275-299
	W0822	074	20		9	33-21-11	275-299
	W0822	K-C			9	33-21-11	275-299
SP00903		0220/194/R050					150
	W0631	024	24		W	23-51-21	150
	W0631	026	24		W	23-51-21	150
	W0845	006	24		W	23-51-11	150
SP00904		0451/285/L026					275-299
	W0822	073	20		9	33-21-11	275-299
	W0822	075	20		9	33-21-11	275-299
	W0822	K-D			9	33-21-11	275-299
SP00906		0499/280/R025					050-099
SP00906		0457/286/R025					150-199, 275-299
	W0822	087	20		9	33-21-11	ALL
	W0822	N-C			9	33-21-11	ALL
SP00908		0499/280/R025					050-099
SP00908		0457/286/R025					150-199, 275-299
	W0822	088	20		9	33-21-11	ALL
	W0822	N-D			9	33-21-11	ALL
SP00910		0499/280/R025					050-099
SP00910		0457/286/R025					150-199, 275-299
	W0822	078	20		9	33-21-11	ALL
	W0822	N-A			9	33-21-11	ALL

SPLICE LIST

D280T132

91-21-31
 Section SP00900
 Page 1
 Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00912		0499/280/R025					050-099
SP00912		0457/286/R025					150-199, 275-299
	W0822	079	20		9	33-21-11	ALL
	W0822	N-B			9	33-21-11	ALL
SP00914		0499/280/L025					050-099
SP00914		0540/286/L025					150-199, 275-299
	W0822	083	20		9	33-21-11	ALL
	W0822	M-A			9	33-21-11	ALL
SP00916		0499/280/L025					050-099
SP00916		0540/286/L025					150-199, 275-299
	W0822	084	20		9	33-21-11	ALL
	W0822	M-B			9	33-21-11	ALL
SP00918		0499/280/L025					050-099
SP00918		0540/286/L025					150-199, 275-299
	W0822	085	20		9	33-21-11	ALL
	W0822	087	20		9	33-21-11	ALL
	W0822	M-C			9	33-21-11	ALL
SP00920		0499/280/L025					050-099
SP00920		0540/286/L025					150-199, 275-299
	W0822	086	20		9	33-21-11	ALL
	W0822	088	20		9	33-21-11	ALL
	W0822	M-D			9	33-21-11	ALL
SP00922		1116/280/R025					050-099, 275-299
SP00922		1064/280/R025					150-199
	W0824	001	22		9	33-21-14	050-099
	W0824	001	20		9	33-21-14	150-199, 275-299
	W0824	B-A			9	33-21-14	ALL
SP00924		1116/280/R025					050-099, 275-299
SP00924		1064/280/R025					150-199
	W0824	002	22		9	33-21-14	050-099
	W0824	002	20		9	33-21-14	150-199, 275-299
	W0824	B-B			9	33-21-14	ALL

SPLICE LIST

D280T132

91-21-31

Section SP00900

Page 2

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00926		1116/280/R025					050-099, 275-299
SP00926		1064/280/R025					150-199
	W0824	012	22		9	33-21-14	050-099
	W0824	012	20		9	33-21-14	150-199, 275-299
	W0824	B-C			9	33-21-14	ALL
SP00928		1116/280/R025					050-099, 275-299
SP00928		1064/280/R025					150-199
	W0824	013	22		9	33-21-14	050-099
	W0824	013	20		9	33-21-14	150-199, 275-299
	W0824	B-D			9	33-21-14	ALL
SP00930		1188/280/L025					050-099
SP00930		1152/284/L025					150-199, 275-299
	W0824	006	22		9	33-21-14	050-099
	W0824	006	20		9	33-21-14	150-199, 275-299
	W0824	A-A			9	33-21-14	ALL
SP00932		1188/280/L025					050-099
SP00932		1152/284/L025					150-199, 275-299
	W0824	007	22		9	33-21-14	050-099
	W0824	007	20		9	33-21-14	150-199, 275-299
	W0824	A-B			9	33-21-14	ALL
SP00934		1188/280/L025					050-099
SP00934		1152/284/L025					150-199, 275-299
	W0824	008	22		9	33-21-14	050-099
	W0824	008	20		9	33-21-14	150-199, 275-299
	W0824	012	22		9	33-21-14	050-099
	W0824	012	20		9	33-21-14	150-199, 275-299
	W0824	A-C			9	33-21-14	ALL
SP00936		1188/280/L025					050-099
SP00936		1152/284/L025					150-199, 275-299
	W0824	009	22		9	33-21-14	050-099
	W0824	009	20		9	33-21-14	150-199, 275-299
	W0824	013	22		9	33-21-14	050-099
	W0824	013	20		9	33-21-14	150-199, 275-299
	W0824	A-D			9	33-21-14	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00938		1204/280/R025					050-099
SP00938		1221/280/R025					150-199, 275-299
	W0824	014	22		9	33-21-14	050-099
	W0824	014	20		9	33-21-14	150-199, 275-299
	W0824	D-A			9	33-21-14	ALL
SP00940		1204/280/R025					050-099
SP00940		1221/280/R025					150-199, 275-299
	W0824	015	22		9	33-21-14	050-099
	W0824	015	20		9	33-21-14	150-199, 275-299
	W0824	D-B			9	33-21-14	ALL
SP00942		1204/280/R025					050-099
SP00942		1221/280/R025					150-199, 275-299
	W0824	025	22		9	33-21-14	050-099
	W0824	025	20		9	33-21-14	150-199, 275-299
	W0824	D-C			9	33-21-14	ALL
SP00944		1204/280/R025					050-099
SP00944		1221/280/R025					150-199, 275-299
	W0824	026	22		9	33-21-14	050-099
	W0824	026	20		9	33-21-14	150-199, 275-299
	W0824	D-D			9	33-21-14	ALL
SP00946		1276/280/L025					050-099
SP00946		1284/280/L025					150-199, 275-299
	W0824	019	22		9	33-21-14	050-099
	W0824	019	20		9	33-21-14	150-199, 275-299
	W0824	C-A			9	33-21-14	ALL
SP00948		1276/280/L025					050-099
SP00948		1284/280/L025					150-199, 275-299
	W0824	020	22		9	33-21-14	050-099
	W0824	020	20		9	33-21-14	150-199, 275-299
	W0824	C-B			9	33-21-14	ALL
SP00950		1276/280/L025					050-099
SP00950		1284/280/L025					150-199, 275-299
	W0824	021	22		9	33-21-14	050-099
	W0824	021	20		9	33-21-14	150-199, 275-299

SPLICE LIST

D280T132

91-21-31

Section SP00900

Page 4

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00950		1276/280/L025 (continued)					050-099
SP00950		1284/280/L025 (continued)					150-199, 275-299
	W0824	025	22		9	33-21-14	050-099
	W0824	025	20		9	33-21-14	150-199, 275-299
	W0824	C-C			9	33-21-14	ALL
SP00952		1276/280/L025					050-099
SP00952		1284/280/L025					150-199, 275-299
	W0824	022	22		9	33-21-14	050-099
	W0824	022	20		9	33-21-14	150-199, 275-299
	W0824	026	22		9	33-21-14	050-099
	W0824	026	20		9	33-21-14	150-199, 275-299
	W0824	C-D			9	33-21-14	ALL
SP00954		1108/284/R050					050-099
SP00954		1020/284/R050					150-199
SP00954		1064/284/R050					275-299
	W0816	585	22		9	33-21-14	050-099
	W0816	585	20		9	33-21-14	150-199, 275-299
	W0816	F-A			9	33-21-14	ALL
SP00956		1108/284/R050					050-099
SP00956		1020/284/R050					150-199
SP00956		1064/284/R050					275-299
	W0816	586	22		9	33-21-14	050-099
	W0816	586	20		9	33-21-14	150-199, 275-299
	W0816	F-B			9	33-21-14	ALL
SP00958		1020/284/R050					050-099
SP00958		0932/284/R050					150-199
SP00958		0976/284/R050					275-299
	W0816	596	22		9	33-21-14	050-099
	W0816	596	20		9	33-21-14	150-199, 275-299
	W0816	F-C			9	33-21-14	ALL
SP00960		1020/284/R050					050-099
SP00960		0932/284/R050					150-199
SP00960		0976/284/R050					275-299
	W0816	598	22		9	33-21-14	050-099
	W0816	598	20		9	33-21-14	150-199, 275-299

SPLICE LIST
D280T132

91-21-31
Section SP00900
Page 5
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00960		1020/284/R050 (continued)					050-099
SP00960		0932/284/R050 (continued)					150-199
SP00960		0976/284/R050 (continued)					275-299
	W0816	F-D			9	33-21-14	ALL
SP00962		0979/284/L050					050-099, 275-299
SP00962		932/284/L050					150-199
	W0816	590	22		9	33-21-14	050-099
	W0816	590	20		9	33-21-14	150-199, 275-299
	W0816	E-A			9	33-21-14	ALL
SP00964		0979/284/L050					050-099, 275-299
SP00964		932/284/L050					150-199
	W0816	591	22		9	33-21-14	050-099
	W0816	591	20		9	33-21-14	150-199, 275-299
	W0816	E-B			9	33-21-14	ALL
SP00966		1108/284/L050					050-099
SP00966		1020/284/L050					150-199
SP00966		1062/284/L050					275-299
	W0816	592	22		9	33-21-14	050-099
	W0816	592	20		9	33-21-14	150-199, 275-299
	W0816	596	22		9	33-21-14	050-099
	W0816	596	20		9	33-21-14	150-199, 275-299
	W0816	E-C			9	33-21-14	ALL
SP00968		1108/284/L050					050-099
SP00968		1020/284/L050					150-199
SP00968		1062/284/L050					275-299
	W0816	593	22		9	33-21-14	050-099
	W0816	593	20		9	33-21-14	150-199, 275-299
	W0816	598	22		9	33-21-14	050-099
	W0816	598	20		9	33-21-14	150-199, 275-299
	W0816	E-D			9	33-21-14	ALL
SP00970		1194/284/R050					050-099
SP00970		1152/284/R050					150-199, 275-299
	W0816	600	22		9	33-21-14	050-099
	W0816	600	20		9	33-21-14	150-199, 275-299
	W0816	H-A			9	33-21-14	ALL

SPLICE LIST

D280T132

91-21-31

Section SP00900

Page 6

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00972		1194/284/R050					050-099
SP00972		1152/284/R050					150-199, 275-299
	W0816	601	22		9	33-21-14	050-099
	W0816	601	20		9	33-21-14	150-199, 275-299
	W0816	H-B			9	33-21-14	ALL
SP00974		1108/284/R050					050-099
SP00974		1064/284/R050					150-199, 275-299
	W0816	611	22		9	33-21-14	050-099
	W0816	611	20		9	33-21-14	150-199, 275-299
	W0816	H-C			9	33-21-14	ALL
SP00976		1108/284/R050					050-099
SP00976		1064/284/R050					150-199, 275-299
	W0816	612	22		9	33-21-14	050-099
	W0816	612	20		9	33-21-14	150-199, 275-299
	W0816	H-D			9	33-21-14	ALL
SP00978		1108/284/L050					ALL
	W0816	605	22		9	33-21-14	050-099
	W0816	605	20		9	33-21-14	150-199, 275-299
	W0816	G-A			9	33-21-14	ALL
SP00980		1108/284/L050					ALL
	W0816	606	22		9	33-21-14	050-099
	W0816	606	20		9	33-21-14	150-199, 275-299
	W0816	G-B			9	33-21-14	ALL
SP00982		1194/284/L050					050-099
SP00982		1152/284/L050					150-199, 275-299
	W0816	607	22		9	33-21-14	050-099
	W0816	607	20		9	33-21-14	150-199, 275-299
	W0816	611	22		9	33-21-14	050-099
	W0816	611	20		9	33-21-14	150-199, 275-299
	W0816	G-C			9	33-21-14	ALL
SP00984		1194/284/L050					050-099
SP00984		1152/284/L050					150-199, 275-299
	W0816	608	22		9	33-21-14	050-099
	W0816	608	20		9	33-21-14	150-199, 275-299

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00984		1194/284/L050 (continued)					050-099
SP00984		1152/284/L050 (continued)					150-199, 275-299
	W0816	612	22		9	33-21-14	050-099
	W0816	612	20		9	33-21-14	150-199, 275-299
	W0816	G-D			9	33-21-14	ALL
SP00986		1284/284/R050					050-099
SP00986		1283/284/R050					150-199, 275-299
	W0816	613	22		9	33-21-14	050-099
	W0816	613	20		9	33-21-14	150-199, 275-299
	W0816	K-A			9	33-21-14	ALL
SP00988		1284/284/R050					050-099
SP00988		1283/284/R050					150-199, 275-299
	W0816	614	22		9	33-21-14	050-099
	W0816	614	20		9	33-21-14	150-199, 275-299
	W0816	K-B			9	33-21-14	ALL
SP00990		1194/284/R050					050-099
SP00990		1221/284/R050					150-199
SP00990		1197+132/284/R050					275-299
	W0816	624	22		9	33-21-14	050-099
	W0816	624	20		9	33-21-14	150-199, 275-299
	W0816	K-C			9	33-21-14	ALL
SP00992		1194/284/R050					050-099
SP00992		1221/284/R050					150-199
SP00992		1197+132/284/R050					275-299
	W0816	625	22		9	33-21-14	050-099
	W0816	625	20		9	33-21-14	150-199, 275-299
	W0816	K-D			9	33-21-14	ALL
SP00994		1194/284/L050					050-099
SP00994		1197+132/284/L050					150-199
SP00994		1221/284/L050					275-299
	W0816	618	22		9	33-21-14	050-099
	W0816	618	20		9	33-21-14	150-199, 275-299
	W0816	J-A			9	33-21-14	ALL

SPLICE LIST

D280T132

91-21-31

Section SP00900

Page 8

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP00996		1194/284/L050					050-099
SP00996		1197+132/284/L050					150-199
SP00996		1221/284/L050					275-299
	W0816	619	22		9	33-21-14	050-099
	W0816	619	20		9	33-21-14	150-199, 275-299
	W0816	J-B			9	33-21-14	ALL
SP00998		1284/284/L050					ALL
	W0816	620	22		9	33-21-14	050-099
	W0816	620	20		9	33-21-14	150-199, 275-299
	W0816	624	22		9	33-21-14	050-099
	W0816	624	20		9	33-21-14	150-199, 275-299
	W0816	J-C			9	33-21-14	ALL

SPLICE LIST

D280T132

91-21-31

Section SP00900

Page 9 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01000		1284/284/L050					ALL
	W0816	621	22		9	33-21-14	050-099
	W0816	621	20		9	33-21-14	150-199, 275-299
	W0816	625	22		9	33-21-14	050-099
	W0816	625	20		9	33-21-14	150-199, 275-299
	W0816	J-D			9	33-21-14	ALL
SP01002		1373/284/R050					050-099
SP01002		1372/284/R050					150-199, 275-299
	W0816	626	22		9	33-21-14	050-099
	W0816	626	20		9	33-21-14	150-199, 275-299
	W0816	M-A			9	33-21-14	ALL
SP01004		1373/284/R050					050-099
SP01004		1372/284/R050					150-199, 275-299
	W0816	627	22		9	33-21-14	050-099
	W0816	627	20		9	33-21-14	150-199, 275-299
	W0816	M-B			9	33-21-14	ALL
SP01006		1289/284/R050					050-099
SP01006		1284/284/R050					150-199, 275-299
	W0816	639	22		9	33-21-14	050-099
	W0816	639	20		9	33-21-14	150-199, 275-299
	W0816	M-C			9	33-21-14	ALL
SP01008		1289/984/R050					050-099
SP01008		1284/284/R050					150-199, 275-299
	W0816	640	22		9	33-21-14	050-099
	W0816	640	20		9	33-21-14	150-199, 275-299
	W0816	M-D			9	33-21-14	ALL
SP01010		1284/284/L050					050-099, 150-199, 280-299
SP01010		1349/284/L050					275-278
	W0816	633	22		9	33-21-14	050-099
	W0816	633	20		9	33-21-14	150-199, 275-299
	W0816	L-A			9	33-21-14	ALL
SP01012		1284/284/L050					050-099, 150-199, 280-299
SP01012		1349/284/L050					275-278
	W0816	634	22		9	33-21-14	050-099

SPLICE LIST

D280T132

91-21-31

Section SP01000

Page 1

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01012		1284/284/L050 (continued)					050-099, 150-199, 280-299
SP01012		1349/284/L050 (continued)					275-278
	W0816	634	20		9	33-21-14	150-199, 275-299
	W0816	L-B			9	33-21-14	ALL
SP01014		1372/284/L050					050-099, 150-199, 280-299
SP01014		1368/290/L056					275-278
	W0816	635	22		9	33-21-14	050-099
	W0816	635	20		9	33-21-14	150-199, 275-299
	W0816	639	22		9	33-21-14	050-099
	W0816	639	20		9	33-21-14	150-199, 275-299
	W0816	L-C			9	33-21-14	ALL
SP01016		1372/284/L050					ALL
	W0816	636	22		9	33-21-14	050-099
	W0816	636	20		9	33-21-14	150-199, 275-299
	W0816	640	22		9	33-21-14	050-099
	W0816	640	20		9	33-21-14	150-199, 275-299
	W0816	L-D			9	33-21-14	ALL
SP01018		1444/284/R050					050-099
SP01018		1436/284/R050					150-199
SP01018		1438/284/R050					275-299
	W0816	641	22		9	33-21-14	050-099
	W0816	641	20		9	33-21-14	150-199, 275-299
	W0816	P-A			9	33-21-14	ALL
SP01020		1444/284/R050					050-099
SP01020		1436/284/R050					150-199
SP01020		1438/284/R050					275-299
	W0816	642	22		9	33-21-14	050-099
	W0816	642	20		9	33-21-14	150-199, 275-299
	W0816	P-B			9	33-21-14	ALL
SP01022		1372/284/R050					ALL
	W0816	652	22		9	33-21-14	050-099
	W0816	652	20		9	33-21-14	150-199, 275-299
	W0816	P-C			9	33-21-14	ALL

SPLICE LIST

D280T132

91-21-31

Section SP01000

Page 2

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01024		1372/284/R050					ALL
	W0816	653	22		9	33-21-14	050-099
	W0816	653	20		9	33-21-14	150-199, 275-299
	W0816	P-D			9	33-21-14	ALL
SP01026		1372/284/L050					ALL
	W0816	646	22		9	33-21-14	050-099
	W0816	646	20		9	33-21-14	150-199, 275-299
	W0816	N-A			9	33-21-14	ALL
SP01028		1372/284/L050					050-099, 150-157, 275-299
SP01028		1394/284/L050					162-199
	W0816	647	22		9	33-21-14	050-099
	W0816	647	20		9	33-21-14	150-199, 275-299
	W0816	N-B			9	33-21-14	ALL
SP01030		1441/284/L050					ALL
	W0816	648	22		9	33-21-14	050-099
	W0816	648	20		9	33-21-14	150-199, 275-299
	W0816	652	22		9	33-21-14	050-099
	W0816	652	20		9	33-21-14	150-199, 275-299
	W0816	N-C			9	33-21-14	ALL
SP01032		1441/284/L050					050-099, 150-157, 275-299
SP01032		1317/280/L025					162-199
	W0816	649	22		9	33-21-14	050-099
	W0816	649	20		9	33-21-14	150-199, 275-299
	W0816	653	22		9	33-21-14	050-099
	W0816	653	20		9	33-21-14	150-199, 275-299
	W0816	N-D			9	33-21-14	ALL
SP01034		1328/280/R025					050-099
SP01034		1292/280/R025					150-199, 275-299
	W0824	028	22		9	33-21-14	050-099
	W0824	028	20		9	33-21-14	150-199, 275-299
	W0824	F-A			9	33-21-14	ALL
SP01036		1328/280/R025					050-099
SP01036		1292/280/R025					150-199, 275-299
	W0824	029	22		9	33-21-14	050-099

SPLICE LIST

D280T132

91-21-31

Section SP01000

Page 3

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01036		1328/280/R025 (continued)					050-099
SP01036		1292/280/R025 (continued)					150-199, 275-299
	W0824	029	20		9	33-21-14	150-199, 275-299
	W0824	F-B			9	33-21-14	ALL
SP01038		1328/280/R025					050-099
SP01038		1292/280/R025					150-199, 275-299
	W0824	039	22		9	33-21-14	050-099
	W0824	039	20		9	33-21-14	150-199, 275-299
	W0824	F-C			9	33-21-14	ALL
SP01040		1328/280/R025					050-099
SP01040		1292/280/R025					150-199, 275-299
	W0824	040	22		9	33-21-14	050-099
	W0824	040	20		9	33-21-14	150-199, 275-299
	W0824	F-D			9	33-21-14	ALL
SP01042		1328/280/L025					050-099
SP01042		1364/280/L025					150-199, 275-299
	W0824	033	22		9	33-21-14	050-099
	W0824	033	20		9	33-21-14	150-199, 275-299
	W0824	E-A			9	33-21-14	ALL
SP01044		1328/280/L025					050-099
SP01044		1364/280/L025					150-199, 275-299
	W0824	034	22		9	33-21-14	050-099
	W0824	034	20		9	33-21-14	150-199, 275-299
	W0824	E-B			9	33-21-14	ALL
SP01046		1328/280/L025					050-099
SP01046		1364/280/L025					150-199, 275-299
	W0824	035	22		9	33-21-14	050-099
	W0824	035	20		9	33-21-14	150-199, 275-299
	W0824	039	22		9	33-21-14	050-099
	W0824	039	20		9	33-21-14	150-199, 275-299
	W0824	E-C			9	33-21-14	ALL
SP01048		1328/280/L025					050-099
SP01048		1364/280/L025					150-199, 275-299
	W0824	036	22		9	33-21-14	050-099

SPLICE LIST
D280T132

91-21-31
Section SP01000
Page 4
Jan 21/2005

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01048		1328/280/L025 (continued)					050-099
SP01048		1364/280/L025 (continued)					150-199, 275-299
	W0824	036	20		9	33-21-14	150-199, 275-299
	W0824	040	22		9	33-21-14	050-099
	W0824	040	20		9	33-21-14	150-199, 275-299
	W0824	E-D			9	33-21-14	ALL
SP01050		1405/280/R025					ALL
	W0824	041	22		9	33-21-14	050-099
	W0824	041	20		9	33-21-14	150-199, 275-299
	W0824	H-A			9	33-21-14	ALL
SP01052		1405/280/R025					ALL
	W0824	042	22		9	33-21-14	050-099
	W0824	042	20		9	33-21-14	150-199, 275-299
	W0824	H-B			9	33-21-14	ALL
SP01054		1405/280/R025					ALL
	W0824	052	20		9	33-21-14	ALL
	W0824	H-C			9	33-21-14	ALL
SP01056		1405/280/R025					ALL
	W0824	053	20		9	33-21-14	ALL
	W0824	H-D			9	33-21-14	ALL
SP01058		1435/280/L025					ALL
	W0824	046	22		9	33-21-14	050-099
	W0824	046	20		9	33-21-14	150-199, 275-299
	W0824	G-A			9	33-21-14	ALL
SP01060		1435/280/L025					ALL
	W0824	047	22		9	33-21-14	050-099
	W0824	047	20		9	33-21-14	150-199, 275-299
	W0824	G-B			9	33-21-14	ALL
SP01062		1435/280/L025					ALL
	W0824	048	22		9	33-21-14	050-099
	W0824	048	20		9	33-21-14	150-199, 275-299
	W0824	052	20		9	33-21-14	ALL
	W0824	G-C			9	33-21-14	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01000
Page 5
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01064		1435/280/L025					ALL
	W0824	049	22		9	33-21-14	050-099
	W0824	049	20		9	33-21-14	150-199, 275-299
	W0824	053	20		9	33-21-14	ALL
	W0824	G-D			9	33-21-14	ALL
SP01066		0976/280/R025					ALL
	W0824	055	22		9	33-21-14	050-099
	W0824	055	20		9	33-21-14	150-199, 275-299
	W0824	J-A			9	33-21-14	ALL
SP01068		0976/280/R025					ALL
	W0824	056	22		9	33-21-14	050-099
	W0824	056	20		9	33-21-14	150-199, 275-299
	W0824	J-B			9	33-21-14	ALL
SP01070		0976/280/R025					ALL
	W0824	061	20		9	33-21-14	ALL
	W0824	J-C			9	33-21-14	ALL
SP01072		0976/280/R025					ALL
	W0824	062	20		9	33-21-14	ALL
	W0824	J-D			9	33-21-14	ALL
SP01074		1100/280/L025					050-099
SP01074		1064/280/L025					150-157, 275-299
SP01074		1015/280/L025					162-199
	W0824	057	22		9	33-21-14	050-099
	W0824	057	20		9	33-21-14	150-199, 275-299
	W0824	K-A			9	33-21-14	ALL
SP01076		1100/280/L025					050-099
SP01076		1064/280/L025					150-157, 275-299
SP01076		1015/280/L025					162-199
	W0824	058	22		9	33-21-14	050-099
	W0824	058	20		9	33-21-14	150-199, 275-299
	W0824	K-B			9	33-21-14	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01078		1100/280/L025					050-099
SP01078		1064/280/L025					150-157, 275-299
SP01078		1015/280/L025					162-199
	W0824	059	22		9	33-21-14	050-099
	W0824	059	20		9	33-21-14	150-199, 275-299
	W0824	061	20		9	33-21-14	ALL
	W0824	K-C			9	33-21-14	ALL
SP01080		1100/280/L025					050-099
SP01080		1064/280/L025					150-157, 275-299
SP01080		1015/280/L025					162-199
	W0824	060	22		9	33-21-14	050-099
	W0824	060	20		9	33-21-14	150-199, 275-299
	W0824	062	20		9	33-21-14	ALL
	W0824	K-D			9	33-21-14	ALL
SP01086		0330/280/0000					ALL
	W0114	015	22		9	33-22-41	ALL
	W0114	B-A			9	33-22-41	ALL
	W0114	E-A			9	33-22-41	ALL
SP01088		0330/280/0000					ALL
	W0114	019	22		9	33-22-41	ALL
	W0114	B-B			9	33-22-41	ALL
	W0114	E-B			9	33-22-41	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01000
Page 7 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01114		0284/283/L030					ALL
	W1228	055	22		9	33-22-41	ALL
	W1228	C-A			9	33-22-41	ALL
SP01116		0284/283/L030					ALL
	W1228	056	22		9	33-22-41	ALL
	W1228	C-B			9	33-22-41	ALL
SP01118		0284/283/L030					ALL
	W1228	057	22		9	33-22-41	ALL
	W1228	C-C			9	33-22-41	ALL
SP01120		0284/283/L030					ALL
	W1228	058	22		9	33-22-41	ALL
	W1228	C-D			9	33-22-41	ALL
SP01150		1455/284/R045					275-299
	W0108	019	22		9	33-22-42	275-299
	W0108	020	22		9	33-22-42	275-299
	W0108	I-D			9	33-22-42	275-299
SP01152		1455/284/R045					275-299
	W0108	018	22		9	33-22-42	275-299
	W0108	021	22		9	33-22-42	275-299
	W0108	I-C			9	33-22-42	275-299
SP01162		1455/284/R045					275-299
	W0108	029	22		9	33-22-42	275-299
	W0108	034	22		9	33-22-42	275-299
	W0108	K-C			9	33-22-42	275-299
SP01164		1455/284/R045					275-299
	W0108	028	22		9	33-22-42	275-299
	W0108	033	22		9	33-22-42	275-299
	W0108	K-D			9	33-22-42	275-299

SPLICE LIST
D280T132

91-21-31
Section SP01100
Page 1 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01214		1526/284/0000					050-099, 275-299
	W0100	016	22		9	33-22-42	050-099
	W0100	016	22		9	33-27-11	275-299
	W0100	G-D			9	33-22-42	050-099
	W0100	G-D			9	33-27-11	275-299
	W0100	H-C			9	33-22-42	050-099
	W0100	H-C			9	33-27-11	275-299
SP01216		1526/284/0000					050-099, 275-299
	W0100	017	22		9	33-22-42	050-099
	W0100	017	22		9	33-27-11	275-299
	W0100	G-C			9	33-22-42	050-099
	W0100	G-C			9	33-27-11	275-299
	W0100	H-D			9	33-22-42	050-099
	W0100	H-D			9	33-27-11	275-299
SP01226		0287/280/R035					ALL
	W1228	093	22		9	33-27-11	ALL
	W1228	A-A			9	33-27-11	ALL
SP01228		0287/280/R035					ALL
	W1228	094	22		9	33-27-11	ALL
	W1228	A-B			9	33-27-11	ALL
SP01230		0287/280/R035					ALL
	W1228	095	22		9	33-27-11	ALL
	W1228	A-C			9	33-27-11	ALL
SP01232		0287/280/R035					ALL
	W1228	096	22		9	33-27-11	ALL
	W1228	A-D			9	33-27-11	ALL
SP01234		0287/280/R035					ALL
	W1228	101	22		9	33-27-11	ALL
	W1228	B-A			9	33-27-11	ALL
SP01236		0287/280/R035					ALL
	W1228	102	22		9	33-27-11	ALL
	W1228	B-B			9	33-27-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01200
Page 1
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01238		0287/280/R035					ALL
	W1228	103	22		9	33-27-11	ALL
	W1228	B-C			9	33-27-11	ALL
SP01240		0287/280/R035					ALL
	W1228	104	22		9	33-27-11	ALL
	W1228	B-D			9	33-27-11	ALL
SP01246		0834/280/0000					150-199
SP01248		0834/280/0000					150-199
SP01250		0834/280/0000					150-199
SP01252		0834/280/0000					150-199
SP01256		0834/280/0000					150-199
SP01258		1574/283/R030					ALL
	W0818	515	22		9	33-27-11	ALL
	W0818	A-A			9	33-27-11	ALL
SP01260		1574/283/R030					ALL
	W0818	516	22		9	33-27-11	ALL
	W0818	A-B			9	33-27-11	ALL
SP01262		1574/283/R012					ALL
	W0818	518	22		9	33-27-11	ALL
	W0818	528	22		9	33-27-11	ALL
	W0818	A-D			9	33-27-11	ALL
SP01264		1574/283/R012					ALL
	W0818	517	22		9	33-27-11	ALL
	W0818	529	22		9	33-27-11	ALL
	W0818	A-C			9	33-27-11	ALL
SP01266		1574/283/L030					ALL
	W0818	511	22		9	33-27-11	ALL
	W0818	D-B			9	33-27-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01200
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01268		1574/283/L030					ALL
	W0818	510	22		9	33-27-11	ALL
	W0818	D-A			9	33-27-11	ALL
SP01270		1574/283/R012					ALL
	W0816	024	22		9	33-27-11	ALL
	W0816	B-D			9	33-27-11	ALL
SP01272		1574/283/R012					ALL
	W0816	023	22		9	33-27-11	ALL
	W0816	B-C			9	33-27-11	ALL
SP01274		1548/283/R030					ALL
	W0818	524	22		9	33-27-11	ALL
	W0818	C-A			9	33-27-11	ALL
SP01276		1548/283/R030					ALL
	W0818	525	22		9	33-27-11	ALL
	W0818	C-B			9	33-27-11	ALL
SP01278		1548/283/R030					ALL
	W0818	527	22		9	33-27-11	ALL
	W0818	530	22		9	33-27-11	ALL
	W0818	C-D			9	33-27-11	ALL
SP01280		1548/283/R030					ALL
	W0818	526	22		9	33-27-11	ALL
	W0818	531	22		9	33-27-11	ALL
	W0818	C-C			9	33-27-11	ALL
SP01282		1548/283/L030					ALL
	W0818	520	22		9	33-27-11	ALL
	W0818	B-B			9	33-27-11	ALL
SP01284		1548/283/L030					ALL
	W0818	519	22		9	33-27-11	ALL
	W0818	B-A			9	33-27-11	ALL
SP01286		1548/283/R030					ALL
	W0816	010	22		9	33-27-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01200
Page 3
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01286		1548/283/R030 (continued)					ALL
	W0816	A-A			9	33-27-11	ALL
SP01288		1548/283/R030					ALL
	W0816	011	22		9	33-27-11	ALL
	W0816	A-B			9	33-27-11	ALL
SP01290		1574/284/R030					ALL
	W0816	015	22		9	33-27-11	ALL
	W0816	B-B			9	33-27-11	ALL
SP01292		1574/284/R030					ALL
	W0816	014	22		9	33-27-11	ALL
	W0816	B-A			9	33-27-11	ALL
SP01294		1548/283/L030					ALL
	W0818	531	22		9	33-27-11	ALL
	W0818	B-D			9	33-27-11	ALL
SP01296		1548/283/L030					ALL
	W0818	530	22		9	33-27-11	ALL
	W0818	B-C			9	33-27-11	ALL
SP01298		1548/283/L030					ALL
	W0816	006	22		9	33-27-11	ALL
	W0816	C-A			9	33-27-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01200
Page 4 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01300		1548/283/L030					ALL
	W0816	007	22		9	33-27-11	ALL
	W0816	C-B			9	33-27-11	ALL
SP01302		1548/283/L030					ALL
	W0816	009	22		9	33-27-11	ALL
	W0816	010	22		9	33-27-11	ALL
	W0816	C-C			9	33-27-11	ALL
SP01304		1548/283/L030					ALL
	W0816	008	22		9	33-27-11	ALL
	W0816	011	22		9	33-27-11	ALL
	W0816	C-D			9	33-27-11	ALL
SP01306		1574/284/L032					ALL
	W0816	019	22		9	33-27-11	ALL
	W0816	D-A			9	33-27-11	ALL
SP01308		1574/284/L032					ALL
	W0816	020	22		9	33-27-11	ALL
	W0816	D-B			9	33-27-11	ALL
SP01310		1574/283/L012					ALL
	W0816	022	22		9	33-27-11	ALL
	W0816	023	22		9	33-27-11	ALL
	W0816	D-C			9	33-27-11	ALL
SP01312		1574/283/L012					ALL
	W0816	021	22		9	33-27-11	ALL
	W0816	024	22		9	33-27-11	ALL
	W0816	D-D			9	33-27-11	ALL
SP01314		1574/283/L012					ALL
	W0818	529	22		9	33-27-11	ALL
	W0818	D-D			9	33-27-11	ALL
SP01316		1574/283/L012					ALL
	W0818	528	22		9	33-27-11	ALL
	W0818	D-C			9	33-27-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01300
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01318		1548/283/R030					ALL
	W0816	002	22		9	33-27-11	ALL
	W0816	A-D			9	33-27-11	ALL
SP01320		1548/283/R030					ALL
	W0816	001	22		9	33-27-11	ALL
	W0816	A-C			9	33-27-11	ALL
SP01322		0719/284/L050					050-099
SP01322		1042/284/L050					150-157
SP01322		1025/284/L050					162-199
SP01322		0764/284/L050					275-299
	W0812	675	20		9	33-21-13	ALL
	W0812	H-A			9	33-21-13	ALL
SP01324		0719/284/L050					050-099
SP01324		1042/284/L050					150-157
SP01324		1025/284/L050					162-199
SP01324		0764/284/L050					275-299
	W0812	676	20		9	33-21-13	ALL
	W0812	H-B			9	33-21-13	ALL
SP01326		0808/284/L050					050-099
SP01326		0888/284/L050					150-157
SP01326		1060/284/L050					162-199
SP01326		0807/284/L050					275-299
	W0812	677	20		9	33-21-13	ALL
	W0812	681	20		9	33-21-13	ALL
	W0812	H-C			9	33-21-13	ALL
SP01328		0808/284/L050					050-099
SP01328		0888/284/L050					150-157
SP01328		1060/284/L050					162-199
SP01328		0807/284/L050					275-299
	W0812	678	20		9	33-21-13	ALL
	W0812	682	20		9	33-21-13	ALL
	W0812	H-D			9	33-21-13	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01330		0808/284/R050					050-099
SP01330		1064/284/R056					150-199
SP01330		0844/284/R050					275-299
	W0812	670	20		9	33-21-13	ALL
	W0812	J-A			9	33-21-13	ALL
SP01332		0808/284/R050					050-099
SP01332		1064/284/R056					150-199
SP01332		0844/284/R050					275-299
	W0812	671	20		9	33-21-13	ALL
	W0812	J-B			9	33-21-13	ALL
SP01334		0719/284/R050					050-099, 275-299
SP01334		1020/284/R056					150-199
	W0812	681	20		9	33-21-13	ALL
	W0812	J-C			9	33-21-13	ALL
SP01336		0719/284/R050					050-099, 275-299
SP01336		1020/284/R056					150-199
	W0812	682	20		9	33-21-13	ALL
	W0812	J-D			9	33-21-13	ALL
SP01338		0809/284/L050					050-099
SP01338		0808/284/L050					150-157, 275-299
SP01338		0855/284/L050					162-199
	W0812	688	20		9	33-21-13	ALL
	W0812	K-A			9	33-21-13	ALL
SP01340		0809/284/L050					050-099
SP01340		0808/284/L050					150-157, 275-299
SP01340		0855/284/L050					162-199
	W0812	689	20		9	33-21-13	ALL
	W0812	K-B			9	33-21-13	ALL
SP01342		0883/284/L050					050-099, 275-299
SP01342		0807/284/L050					150-157
SP01342		0935/284/L050					162-199
	W0812	690	20		9	33-21-13	ALL
	W0812	694	20		9	33-21-13	ALL
	W0812	K-C			9	33-21-13	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01344		0883/284/L050					050-099, 275-299
SP01344		0807/284/L050					150-157
SP01344		0935/284/L050					162-199
	W0812	691	20		9	33-21-13	ALL
	W0812	695	20		9	33-21-13	ALL
	W0812	K-D			9	33-21-13	ALL
SP01346		0888/284/R050					050-099
SP01346		0932/284/R050					150-199, 275-299
	W0812	683	20		9	33-21-13	ALL
	W0812	L-A			9	33-21-13	ALL
SP01348		0888/284/R050					050-099
SP01348		0932/284/R050					150-199, 275-299
	W0812	684	20		9	33-21-13	ALL
	W0812	L-B			9	33-21-13	ALL
SP01350		0808/284/R050					050-099
SP01350		0851/284/R050					150-199, 275-299
	W0812	694	20		9	33-21-13	ALL
	W0812	L-C			9	33-21-13	ALL
SP01352		0808/284/R050					050-099
SP01352		0851/284/R050					150-199, 275-299
	W0812	695	20		9	33-21-13	ALL
	W0812	L-D			9	33-21-13	ALL
SP01354		0933/284/L050					050-099, 150-157
SP01354		0768/284/L050					162-199
SP01354		0888/284/L050					275-299
	W0812	702	20		9	33-21-13	ALL
	W0812	M-A			9	33-21-13	ALL
SP01356		0933/284/L050					050-099, 150-157
SP01356		0768/284/L050					162-199
SP01356		0888/284/L050					275-299
	W0812	703	20		9	33-21-13	ALL
	W0812	M-B			9	33-21-13	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01358		976/284/L050					050-099, 150-157, 275-299
SP01358		845/284/L050					162-199
	W0812	704	20		9	33-21-13	ALL
	W0812	708	20		9	33-21-13	ALL
	W0812	M-C			9	33-21-13	ALL
SP01360		976/284/L050					050-099, 150-157, 275-299
SP01360		845/284/L050					162-199
	W0812	705	20		9	33-21-13	ALL
	W0812	709	20		9	33-21-13	ALL
	W0812	M-D			9	33-21-13	ALL
SP01362		1021/284/R050					050-099, 275-299
SP01362		0851/284/R050					150-199
	W0812	697	20		9	33-21-13	ALL
	W0812	N-A			9	33-21-13	ALL
SP01364		1021/284/R050					050-099, 275-299
SP01364		0851/284/R050					150-199
	W0812	698	20		9	33-21-13	ALL
	W0812	N-B			9	33-21-13	ALL
SP01366		0763/284/R050					ALL
	W0812	708	20		9	33-21-13	ALL
	W0812	N-C			9	33-21-13	ALL
SP01368		0763/284/R050					ALL
	W0812	709	20		9	33-21-13	ALL
	W0812	N-D			9	33-21-13	ALL
SP01370		0887/284/L050					050-099
	W0812	715	20		9	33-21-13	050-099
	W0812	P-A			9	33-21-13	050-099
SP01372		0887/284/L050					050-099
	W0812	716	20		9	33-21-13	050-099
	W0812	P-B			9	33-21-13	050-099
SP01374		0932/284/L050					050-099
	W0812	717	20		9	33-21-13	050-099

SPLICE LIST
D280T132

91-21-31
Section SP01300
Page 5
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01374		0932/284/L050 (continued)					050-099
	W0812	721	20		9	33-21-13	050-099
	W0812	P-C			9	33-21-13	050-099
SP01376		0932/284/L050					050-099
	W0812	718	20		9	33-21-13	050-099
	W0812	722	20		9	33-21-13	050-099
	W0812	P-D			9	33-21-13	050-099
SP01378		0932/284/R050					050-099
	W0812	710	20		9	33-21-13	050-099
	W0812	R-A			9	33-21-13	050-099
SP01380		0932/284/R050					050-099
	W0812	711	20		9	33-21-13	050-099
	W0812	R-B			9	33-21-13	050-099
SP01382		0888/284/R050					050-099
	W0812	721	20		9	33-21-13	050-099
	W0812	R-C			9	33-21-13	050-099
SP01384		0888/284/R050					050-099
	W0812	722	20		9	33-21-13	050-099
	W0812	R-D			9	33-21-13	050-099
SP01386		0763/280/L025					050-099
SP01386		0808/280/L025					150-157, 275-299
SP01386		1060/280/L025					162-199
	W0822	100	20		9	33-21-13	ALL
	W0822	P-A			9	33-21-13	ALL
SP01388		0763/280/L025					050-099
SP01388		0808/280/L025					150-157, 275-299
SP01388		1060/280/L025					162-199
	W0822	101	20		9	33-21-13	ALL
	W0822	P-B			9	33-21-13	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01390		0763/280/L025					050-099
SP01390		0808/280/L025					150-157, 275-299
SP01390		1060/280/L025					162-199
	W0822	102	20		9	33-21-13	ALL
	W0822	106	20		9	33-21-13	ALL
	W0822	P-C			9	33-21-13	ALL
SP01392		0763/280/L025					050-099
SP01392		0808/280/L025					150-157, 275-299
SP01392		1060/280/L025					162-199
	W0822	103	20		9	33-21-13	ALL
	W0822	107	20		9	33-21-13	ALL
	W0822	P-D			9	33-21-13	ALL
SP01394		0763/280/R025					050-099
SP01394		0766/285/R029					150-199, 275-299
	W0822	095	20		9	33-21-13	ALL
	W0822	R-A			9	33-21-13	ALL
SP01396		0763/280/R025					050-099
SP01396		0766/285/R029					150-199, 275-299
	W0822	096	20		9	33-21-13	ALL
	W0822	R-B			9	33-21-13	ALL
SP01398		0763/280/R025					050-099
SP01398		0766/285/R029					150-199, 275-299
	W0822	106	20		9	33-21-13	ALL
	W0822	R-C			9	33-21-13	ALL

SPLICE LIST

D280T132

91-21-31

Section SP01300

Page 7 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01400		0763/280/R025					050-099
SP01400		0766/285/R029					150-199, 275-299
	W0822	107	20		9	33-21-13	ALL
	W0822	R-D			9	33-21-13	ALL
SP01402		0847/280/L025					050-099
SP01402		0888/280/L025					150-157, 275-299
SP01402		0930/280/L025					162-199
	W0822	113	20		9	33-21-13	ALL
	W0822	S-A			9	33-21-13	ALL
SP01404		0847/280/L025					050-099
SP01404		0888/280/L025					150-157, 275-299
SP01404		0930/280/L025					162-199
	W0822	114	20		9	33-21-13	ALL
	W0822	S-B			9	33-21-13	ALL
SP01406		0847/280/L025					050-099
SP01406		0888/280/L025					150-157, 275-299
SP01406		0930/280/L025					162-199
	W0822	115	20		9	33-21-13	ALL
	W0822	119	20		9	33-21-13	ALL
	W0822	S-C			9	33-21-13	ALL
SP01408		0847/280/L025					050-099
SP01408		0888/280/L025					150-157, 275-299
SP01408		0930/280/L025					162-199
	W0822	116	20		9	33-21-13	ALL
	W0822	120	20		9	33-21-13	ALL
	W0822	S-D			9	33-21-13	ALL
SP01410		0807/280/R025					ALL
	W0822	108	20		9	33-21-13	ALL
	W0822	T-A			9	33-21-13	ALL
SP01412		0807/280/R025					ALL
	W0822	109	20		9	33-21-13	ALL
	W0822	T-B			9	33-21-13	ALL

SPLICE LIST

D280T132

91-21-31

Section SP01400

Page 1

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01414		0807/280/R025					ALL
	W0822	119	20		9	33-21-13	ALL
	W0822	T-C			9	33-21-13	ALL
SP01416		0807/280/R025					ALL
	W0822	120	20		9	33-21-13	ALL
	W0822	T-D			9	33-21-13	ALL
SP01418 SP01418		0976/280/L025 0850/280/L025					050-099, 150-157, 275-299 162-199
	W0822	126	20		9	33-21-13	ALL
	W0822	U-A			9	33-21-13	ALL
SP01420 SP01420		0976/280/L025 0850/280/L025					050-099, 150-157, 275-299 162-199
	W0822	127	20		9	33-21-13	ALL
	W0822	U-B			9	33-21-13	ALL
SP01422 SP01422		0976/280/L025 0850/280/L025					050-099, 150-157, 275-299 162-199
	W0822	128	20		9	33-21-13	ALL
	W0822	132	20		9	33-21-13	ALL
	W0822	U-C			9	33-21-13	ALL
SP01424 SP01424		0976/280/L025 0850/280/L025					050-099, 150-157, 275-299 162-199
	W0822	129	20		9	33-21-13	ALL
	W0822	133	20		9	33-21-13	ALL
	W0822	U-D			9	33-21-13	ALL
SP01426		0888/280/R025					ALL
	W0822	121	20		9	33-21-13	ALL
	W0822	V-A			9	33-21-13	ALL
SP01428		0888/280/R025					ALL
	W0822	122	20		9	33-21-13	ALL
	W0822	V-B			9	33-21-13	ALL
SP01430		0888/280/R025					ALL
	W0822	132	20		9	33-21-13	ALL

SPLICE LIST

D280T132

91-21-31

Section SP01400

Page 2

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01430		0888/280/R025 (continued)					ALL
	W0822	V-C			9	33-21-13	ALL
SP01432		0888/280/R025					ALL
	W0822	133	20		9	33-21-13	ALL
	W0822	V-D			9	33-21-13	ALL
SP01434		0910/280/L025					050-099
	W0822	139	20		9	33-21-13	050-099
	W0822	W-A			9	33-21-13	050-099
SP01436		0910/280/L025					050-099
	W0822	140	20		9	33-21-13	050-099
	W0822	W-B			9	33-21-13	050-099
SP01438		0910/280/L025					050-099
	W0822	141	20		9	33-21-13	050-099
	W0822	145	20		9	33-21-13	050-099
	W0822	W-C			9	33-21-13	050-099
SP01440		0910/280/L025					050-099
	W0822	142	20		9	33-21-13	050-099
	W0822	146	20		9	33-21-13	050-099
	W0822	W-D			9	33-21-13	050-099
SP01442		0910/280/R025					050-099
	W0822	134	20		9	33-21-13	050-099
	W0822	X-A			9	33-21-13	050-099
SP01444		0910/280/R025					050-099
	W0822	135	20		9	33-21-13	050-099
	W0822	X-B			9	33-21-13	050-099
SP01446		0910/280/R025					050-099
	W0822	145	20		9	33-21-13	050-099
	W0822	X-C			9	33-21-13	050-099
SP01448		0910/280/R025					050-099
	W0822	146	20		9	33-21-13	050-099
	W0822	X-D			9	33-21-13	050-099

SPLICE LIST
D280T132

91-21-31
Section SP01400
Page 3
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01456		0347/280/L030					050-099
SP01456		0325/280/L029					150-199, 275-299
	W1228	038	22		9	33-22-11	ALL
	W1228	D-A			9	33-22-11	ALL
SP01458		0347/280/L030					050-099
SP01458		0325/280/L029					150-199, 275-299
	W1228	039	22		9	33-22-11	ALL
	W1228	D-B			9	33-22-11	ALL
SP01460		0347/280/L030					050-099
SP01460		0325/280/L029					150-199, 275-299
	W1228	040	22		9	33-22-11	ALL
	W1228	D-C			9	33-22-11	ALL
SP01462		0347/280/L030					050-099
SP01462		0325/280/L029					150-199, 275-299
	W1228	041	22		9	33-22-11	ALL
	W1228	D-D			9	33-22-11	ALL
SP01464		1355/170/L072					ALL
	W0578	047	22		S	21-44-21	ALL
	W0580	120	22		S	21-44-21	ALL
SP01466		1400/290/R080					ALL
	W0966	009	24		S	38-14-11	ALL
	W1240	029	24		S	33-22-11	ALL
	W1240	031	24		S	33-22-11	ALL
	W1256	032	24		S	38-15-11	ALL
SP01468		P011-05/ /					ALL
	W0042	051	22		9	74-31-21	ALL
	W0042	051Z				74-31-21	ALL
	W0042	700	22		9	74-31-21	ALL
	W0042	700Z				74-31-21	ALL
	W0044	175	22		9	74-31-21	ALL
	W0044	175Z				74-31-21	ALL
SP01470		P011-05/ /					ALL
	W0040	711	22		9	74-31-21	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01470		P011-05/ / (continued)					ALL
	W0040	711Z				74-31-21	ALL
	W0040	712	22		9	74-31-21	ALL
	W0040	712Z				74-31-21	ALL
	W0042	092	22		9	74-31-21	ALL
	W0042	092Z				74-31-21	ALL
SP01472		P011-05/ /					ALL
	W0042	039	22		9	74-31-11	ALL
	W0042	039Z				74-31-11	ALL
	W0042	704	22		9	74-31-11	ALL
	W0044	199	22		9	74-31-11	ALL
SP01474		P011-05/ /					ALL
	W0042	702	22		9	74-31-11	ALL
	W0042	703	22		9	74-31-11	ALL
	W0044	185	22		9	74-31-11	ALL
SP01484		P011-05/ /					ALL
	W0040	057	22		9	74-31-11	ALL
	W0040	187	22		9	74-31-11	ALL
	W0040	709	22		9	74-31-11	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01510		1750/283/R032					ALL
	W0242	017	20		9	49-15-11	ALL
	W0242	A-F			9	49-15-11	ALL
SP01518		0360/195/L020					ALL
	W0596	020	20		S	28-26-11	ALL
	W0598	020	20		S	28-26-11	ALL
SP01522		0730/190/R045					ALL
	W0602	001R	22		9	26-17-11	ALL
	W0656	032R	22		9	26-17-11	ALL
SP01524		0730/190/R045					ALL
	W0596	070	20		S	28-21-13	ALL
	W0598	025	20		S	28-21-13	ALL
SP01526		0730/190/R045					ALL
	W0596	075	22		S	28-21-13	ALL
	W0598	027	22		S	28-21-13	ALL
SP01528		0730/190/R045					ALL
	W0596	077	22		S	28-21-13	ALL
	W0606	015	22		S	28-21-13	ALL
SP01530		0730/190/R045					ALL
	W0590	033	18		S	28-21-13	ALL
	W0596	074	20		S	28-21-13	ALL
SP01532		0730/190/R045					ALL
	W0590	034	18		S	28-21-13	ALL
	W0596	080	22		S	28-21-13	ALL
SP01536		0360/195/L020					ALL
	W0596	021	20		S	28-26-11	ALL
	W0598	021	20		S	28-26-11	ALL
SP01540		0730/190/R045					ALL
	W0596	069	20		S	28-21-13	ALL
	W0598	024	20		S	28-21-13	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01500
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01542		0730/190/R045					ALL
	W0596	071	20		S	28-21-13	ALL
	W0606	014	20		S	28-21-13	ALL
SP01544		0730/190/R045					ALL
	W0596	076	22		S	28-21-13	ALL
	W0598	028	22		S	28-21-13	ALL
SP01546		1010/196/L048					ALL
	W0596	072	20		S	28-21-13	ALL
	W0614	111	20		S	28-21-13	ALL
SP01548		1010/196/L048					ALL
	W0596	078	22		S	28-21-13	ALL
	W0614	112	22		S	28-21-13	ALL
SP01550		0360/195/L020					ALL
	W0596	121	24		S	28-26-11	ALL
	W0598	070	20		S	28-26-11	ALL
SP01552		1158/133/R077					ALL
	W0658	008	18		9	29-21-31	ALL
	W0658	A-C			9	29-21-31	ALL
SP01554		1158/133/R077					ALL
	W0658	009	18		9	29-21-31	ALL
	W0658	A-A			9	29-21-31	ALL
SP01556		1158/134/R070					ALL
	W0658	010	18		9	29-21-31	ALL
	W0658	B-A			9	29-21-31	ALL
SP01558		1158/134/R070					ALL
	W0658	031	18		9	29-21-31	ALL
	W0658	B-C			9	29-21-31	ALL
SP01560		1164/131/R070					ALL
	W0658	016	18		9	29-21-31	ALL
	W0658	C-A			9	29-21-31	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01500
Page 2
Jan 21/2005

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01562		1164/131/R070					ALL
	W0658	030	18		9	29-21-31	ALL
	W0658	C-C			9	29-21-31	ALL
SP01568		P011-05/ /					ALL
	W0040	145	22		9	23-51-41	ALL
	W0042	194	22		9	23-51-11	ALL
	W0044	145	22		9	23-51-11	ALL
	W0044	156	22		9	23-51-11	ALL
	W0044	726	22		9	23-51-11	ALL
SP01570		P011-05/ /					ALL
	W0042	197	22		9	23-51-21	ALL
	W0044	140	22		9	23-51-21	ALL
	W0044	728	22		9	23-51-21	ALL
SP01582		1439/310/L020					275-299
	W0828	003	20		S	33-26-21	275-299
	W1276	008	20		S	33-26-21	275-299
SP01586		0764/295/R060					150-199
	W0792	090	20		9	33-24-11	150-199
	W0792	578	20		9	33-24-11	150-199
	W0814	577	20		9	33-24-11	150-199
	W0814	801	20		9	33-24-11	150-199
SP01592		P036-00/ /					050-099, 150-199
	W0176	854	24		W	21-24-11	050-099, 150-199
	W0176	A-P			W	21-24-11	050-099, 150-199
SP01594		P036-00/ /					050-099, 150-199
	W0176	858	20		W	21-24-11	050-099, 150-199
	W0176	A-Q			W	21-24-11	050-099, 150-199
SP01596		P036-00/ /					ALL
	W0176	526	24		W	21-25-11	ALL
	W0176	A-A			W	21-25-11	ALL
SP01598		P036-00/ /					ALL
	W0176	527	20		W	21-25-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01500
Page 3
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01598		P036-00/ / (continued)					ALL
	W0176	A-B			W	21-25-11	ALL

SPLICE LIST

D280T132

91-21-31

Section SP01500
Page 4 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01600		P037-00/ /					ALL
	W0192	047	24		W	21-25-21	ALL
	W0192	A-A			W	23-25-21	050-099
	W0192	A-A			W	21-25-21	150-199, 275-299
SP01602		P037-00/ /					ALL
	W0192	046	20		W	21-25-21	ALL
	W0192	A-B			W	21-25-21	ALL
SP01608		P036-00/ /					ALL
	W0176	508	24		W	21-58-14	ALL
	W0176	A-C			W	21-58-14	ALL
SP01610		P036-00/ /					ALL
	W0176	832	20		W	21-58-14	ALL
	W0176	A-D			W	21-58-14	ALL
SP01612		P037-00/ /					ALL
	W0192	704	24		W	21-58-15	ALL
	W0192	A-E			W	21-58-15	ALL
SP01614		P037-00/ /					ALL
	W0192	726	20		W	21-58-15	ALL
	W0192	A-F			W	21-58-15	ALL
SP01616		P037-00/ /					ALL
	W0192	884	24		W	21-26-11	ALL
	W0192	A-G			W	21-26-11	ALL
SP01618		P037-00/ /					ALL
	W0192	871	20		W	21-26-11	ALL
	W0192	A-H			W	21-26-11	ALL
SP01620		P036-00/ /					ALL
	W0176	705	24		W	21-26-11	ALL
	W0176	A-E			W	21-26-11	ALL
SP01622		P036-00/ /					ALL
	W0176	704	20		W	21-26-11	ALL
	W0176	A-F			W	21-26-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01600
Page 1
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01624		1540/190/R030					ALL
	W0966	026	22		9	38-32-11	050-099, 275-299
	W0966	026	20		9	38-32-11	150-199
	W1354	024	22		9	38-32-11	050-099, 275-299
	W1354	024	20		9	38-32-11	150-199
SP01626		1540/190/R030					ALL
	W0966	028	22		9	38-32-11	050-099, 275-299
	W0966	028	20		9	38-32-11	150-199
	W1354	025	22		9	38-32-11	050-099, 275-299
	W1354	025	20		9	38-32-11	150-199
SP01628		1439/190/L090					ALL
	W0578	060	22		9	38-32-11	050-099, 277-299
	W0578	060	20		9	38-32-11	150-199
	W0578	060	22		9	38-32-12	275-276
	W0828	131	22		9	38-32-12	050-099
	W0828	131	20		9	38-32-12	150-156, 162-165
	W0828	131	20		9	38-32-16	157, 166-199
	W0828	603	22		9	38-32-12	050-099
	W0828	603	20		9	38-32-12	150-156, 162-165
	W0828	603	20		9	38-32-16	157, 166-199
	W1276	016	22		9	38-32-12	275-276
	W1276	016	22		9	38-32-16	277-299
	W1276	020	22		9	38-32-12	275-276
	W1276	020	22		9	38-32-16	277-299
SP01632		1572/140/R005					ALL
	W1296	019	20		9	38-32-11	ALL
	W1354	A-B			9	38-32-11	ALL
SP01634		1572/140/0000					ALL
	W1354	015	22		9	38-32-11	050-099, 275-299
	W1354	015	20		9	38-32-11	150-199
	W1354	A-A			9	38-32-11	ALL
SP01638		1010/196/L048					ALL
	W0602	129	16		9	25-65-11	ALL
	W0786	117	16		9	25-65-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01600
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01640		0275/192/L075					ALL
	W1258	061	20		9	30-71-21	050-099, 150-199
	W1258	061	22		9	30-71-21	275-299
	W1258	U-C			9	30-71-21	ALL
SP01644		0273/191/L075					ALL
	W1258	063	20		9	30-71-21	050-099, 150-199
	W1258	063	22		9	30-71-21	275-299
	W1258	Y-C			9	30-71-21	ALL
SP01652		0786/178/L062					050-099
	W1258	067	20		9	30-71-22	050-099
	W1258	T-C			9	30-71-22	050-099
SP01654		0786/178/L062					050-099
	W1258	068	20		9	30-71-22	050-099
	W1258	T-D			9	30-71-22	050-099
SP01658		0145/193/L020					ALL
	W0902	093	18		S	33-31-41	ALL
	W0902	A-B			S	33-31-41	ALL
SP01664		0229/193/R052					ALL
	W0902	096	18		S	33-31-41	ALL
	W0902	A-G			S	33-31-41	ALL
SP01666		0266/193/R048					ALL
	W0902	097	18		S	33-31-41	ALL
	W0902	A-F			S	33-31-41	ALL
SP01668		0325/193/R059					ALL
	W0902	097	18		S	33-31-41	ALL
	W0902	098	18		S	33-31-41	ALL
	W0902	116	18		S	33-31-41	ALL
	W0902	A-J			S	33-31-41	ALL
SP01670		0325/193/R024					ALL
	W0902	098	18		S	33-31-41	ALL
	W0902	099	18		S	33-31-41	ALL
	W0902	A-K			S	33-31-41	ALL



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01672		0325/193/L058					ALL
	W0902	100	18		S	33-31-41	ALL
	W0902	101	18		S	33-31-41	ALL
	W0902	A-U			S	33-31-41	ALL
SP01674		0220/193/L040					ALL
	W0902	114	18		S	33-31-41	ALL
	W0902	A-P			S	33-31-41	ALL
SP01692		0764/280/L010					050-099
SP01692		. 0764/295/R060					150-199, 275-299
	W0665	206R	22		S	23-31-14	275-278
	W0665	219R	22		S	23-31-14	280-299
	W0792	201R	22		S	23-31-14	ALL
	W0792	202R	22		S	23-31-14	ALL
	W0814	201R	22		S	23-31-14	050-099, 150-199, 275-278
	W0814	204R	22		S	23-31-14	275-278
	W0814	205R	22		S	23-31-14	050-099, 150-199
	W0814	228R	22		S	23-31-14	280-299
SP01694		0764/280/L010					050-099
SP01694		. 764/295/R060					150-199, 275-299
	W0665	206B	22		S	23-31-14	275-278
	W0665	219B	22		S	23-31-14	280-299
	W0792	201B	22		S	23-31-14	ALL
	W0792	202B	22		S	23-31-14	ALL
	W0814	201B	22		S	23-31-14	050-099, 150-199, 275-278
	W0814	204B	22		S	23-31-14	275-278
	W0814	205B	22		S	23-31-14	050-099, 150-199
	W0814	228B	22		S	23-31-14	280-299
SP01696		1439/310/L020					ALL
	W0665	212R	22		S	23-31-14	ALL
	W0806	646R	22		S	23-31-15	050-099, 150-199
	W0810	646R	22		S	23-31-17	050-099, 150-199
	W0828	201R	22		S	23-31-14	ALL
	W0828	202R	22		S	23-31-14	050-099, 150-199
	W0828	203R	22		S	23-31-14	ALL
	W1152	220R	22		S	23-31-16	150-199
	W1152	646R	22		S	23-31-16	050-099
	W1276	201R	22		S	23-31-14	275-299

SPLICE LIST

D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01698		1439/310/L020					ALL
	W0665	212B	22		S	23-31-14	ALL
	W0806	646B	22		S	23-31-15	050-099, 150-199
	W0810	646B	22		S	23-31-17	050-099, 150-199
	W0828	201B	22		S	23-31-14	ALL
	W0828	202B	22		S	23-31-14	050-099, 150-199
	W0828	203B	22		S	23-31-14	ALL
	W1152	220B	22		S	23-31-16	150-199
	W1152	646B	22		S	23-31-16	050-099
	W1276	201B	22		S	23-31-14	275-299

SPLICE LIST
D280T132

91-21-31
Section SP01600
Page 5 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01700		1400/290/R080					ALL
	W0828	041	18		S	38-32-13	050-099, 150-156, 162-165, 275-276
	W0828	041	18		S	38-32-16	157, 166-199, 277-299
	W0828	048	18		S	38-32-13	050-099, 150-156, 162-165, 275-276
	W0828	048	18		S	38-32-16	157, 166-199, 277-299
	W0966	039	18		S	38-32-11	ALL
SP01702		1389/117/L005					ALL
	W1366	002	20		9	30-71-23	050-099, 155-199
	W1366	002	22		9	30-71-23	150-154, 275-299
	W1366	A-C			9	30-71-23	ALL
	W1366	J-A			9	30-71-23	ALL
SP01728		1790/260/L040					ALL
	W0502	011	20		9	27-38-11	ALL
	W0514	011	20		9	27-38-11	ALL
SP01742		1790/260/L040					ALL
	W0502	001	20		9	27-38-11	ALL
	W0514	001	20		9	27-38-11	ALL
SP01748		0250/300/L005					ALL
	W0606	019	20		S	28-22-21	050-099, 150-154, 156-162, 165-199
	W0606	019Z				28-22-21	050-099, 150-154, 156-162, 165-199
	W0606	793	20		S	28-22-21	155, 163-164, 275-299
	W0606	793Z				28-22-21	155, 163-164, 275-299
	W1262	001	18		S	28-22-21	ALL
	W1262	001Z				28-22-21	ALL
SP01750		0250/300/L005					ALL
	W0614	019	20		S	28-22-21	050-099, 150-154, 156-162, 165-199
	W0614	019Z				28-22-21	050-099, 150-154, 156-162, 165-199
	W0614	691	20		S	28-22-21	155, 163-164, 275-299
	W0614	691Z				28-22-21	155, 163-164, 275-299
	W1264	001	18		S	28-22-21	ALL
	W1264	001Z				28-22-21	ALL
SP01752		0980/190/R090					ALL
	W0462	004	18		9	28-22-21	ALL
	W1262	001	18		9	28-22-21	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01700
Page 1
Mar 14/2007



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01754		0980/190/L090					ALL
	W0458	001	18		9	28-22-21	ALL
	W1264	001	18		9	28-22-21	ALL
SP01770		1838/218/R019					ALL
	W0270	002	18		8	33-31-31	ALL
	W0270	A-A			8	33-31-31	ALL
SP01772		1838/218/L017					ALL
	W0270	003	18		8	33-31-31	ALL
	W0270	A-C			8	33-31-31	ALL
SP01774		1838/218/R019					ALL
	W0270	004	18		8	33-31-31	ALL
	W0270	A-B			8	33-31-31	ALL
SP01776		1838/218/L017					ALL
	W0270	005	18		8	33-31-31	ALL
	W0270	A-D			8	33-31-31	ALL
SP01794		0303/190/L075					ALL
	W1258	069	20		9	30-71-21	050-099, 150-199
	W1258	069	22		9	30-71-21	275-299
	W1258	A-Z			9	30-71-21	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01700
Page 2 End
Mar 14/2007



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01816		1570/140/R005					ALL
	W1296	020	20		9	38-32-11	ALL
	W1354	028	18		9	38-32-11	ALL
SP01836		1090/185/L071					050-099, 150-199
	W1258	080	20		9	30-71-22	050-099, 155-199
	W1258	080	22		9	30-71-22	150-154
	W1258	Z-E			9	30-71-22	050-099, 150-199
SP01840		1564/160/R026					050-099, 150-199
	W1358	015	16		9	30-71-24	050-099, 150-199
	W1358	N-G			9	30-71-24	050-099, 150-199



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01914		0730/190/R045					ALL
	W0206	025	18		9	27-81-11	ALL
	W0768	082	22		9	27-81-11	ALL
	W0768	083	18		9	27-81-11	ALL
SP01920		0730/190/R045					ALL
	W0274	004	18		9	27-81-21	ALL
	W0628	053	22		9	27-81-21	ALL
	W0628	054	18		9	27-81-21	ALL
SP01922		0730/190/R045					ALL
	W0206	032	18		9	27-51-11	ALL
	W0628	059	18		9	27-51-11	ALL
	W0628	060	22		9	27-51-11	ALL
SP01926		1545/160/L060					ALL
	W0978	301B	22		9	21-31-31	ALL
	W0998	301B	22		9	21-31-31	ALL
SP01928		1545/160/L060					ALL
	W0978	301R	22		9	21-31-31	ALL
	W0998	301R	22		9	21-31-31	ALL
SP01930		1545/160/L060					ALL
	W0978	301Y	22		9	21-31-31	ALL
	W0998	301Y	22		9	21-31-31	ALL
SP01942		0980/190/R090					ALL
	W0462	004Z			9	28-22-21	ALL
	W1262	001Z			9	28-22-21	ALL
	W1262	002	18		9	28-22-21	ALL
SP01944		R0327/14/RS					ALL
	W0456	022Z			9	28-22-21	ALL
	W0462	004Z			9	28-22-21	ALL
SP01946		0980/190/L090					ALL
	W0458	001Z			9	28-22-21	ALL
	W1264	001Z			9	28-22-21	ALL
	W1264	002	18		9	28-22-21	ALL

SPLICE LIST
D280T132

91-21-31
Section SP01900
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01948		L0327/14/RS					ALL
	W0454	008Z			9	28-22-21	ALL
	W0458	001Z			9	28-22-21	ALL
SP01950		L0246/14/RS					ALL
	W0482	001Z			9	28-25-21	ALL
	W0484	002Z			9	28-25-21	ALL
SP01958		1550/180/R065					ALL
	W1356	553	20		9	38-15-11	ALL
	W1356	K-A			9	38-15-11	ALL
SP01960		1547/190/R070					ALL
	W1356	18C	24		9	38-15-11	ALL
	W1356	K-B			9	38-15-11	ALL
SP01962		1790/260/L040					ALL
	W0502	023	16		9	33-45-11	ALL
	W1288	001	16		9	33-45-11	ALL
SP01964		1790/260/L040					ALL
	W0502	024	16		9	33-45-11	ALL
	W1290	001	16		9	33-45-11	ALL
SP01966		0786/197/R024					275-276
SP01972		1536/250/R092					ALL
	W0790	206R	24		9	52-71-11	ALL
	W0790	C-A			9	52-71-11	ALL
SP01974		1536/250/R092					ALL
	W0790	206B	24		9	52-71-11	ALL
	W0790	C-B			9	52-71-11	ALL
SP01976		1384/118/R021					275-276
	W1366	003	20		9	30-71-23	275-276
	W1366	N-A			9	30-71-23	275-276
SP01978		1384/118/R021					275-276
	W1366	03X	20		9	30-71-23	275-276

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01978		1384/118/R021 (continued)					275-276
	W1366	N-B			9	30-71-23	275-276
SP01982		L0669/12/FS					ALL
	W0472	214B	20		9	28-21-11	ALL
	W0472	A-D			9	28-21-11	ALL
SP01984		L0669/12/FS					ALL
	W0472	215B	20		9	28-21-11	ALL
	W0472	A-B			9	28-21-11	ALL
SP01986		P011-05/ /					ALL
	W0042	708	24		9	74-31-11	ALL
	W0044	178	24		9	74-31-11	ALL
SP01990		0587/280/L025					050-099
SP01990		0628/285/L025					150-199, 275-299
	W0822	051	20		S	33-21-11	ALL
	W0822	F-E			S	33-21-11	ALL
SP01992		0587/280/R025					050-099
SP01992		0568/283/R026					150-199, 275-299
	W0822	091	20		S	33-21-11	ALL
	W0822	G-E			S	33-21-11	ALL
SP01994		0675/280/L025					050-099
SP01994		0763/280/L025					150-199, 275-278
	W0822	063	20		S	33-21-11	050-099
	W0822	063	20		S	33-21-13	150-199, 275-278
	W0822	H-E			S	33-21-11	050-099
	W0822	H-E			S	33-21-13	150-199, 275-278
SP01996		0675/280/R025					050-099, 150-199, 275-278
	W0822	092	20		S	33-21-11	050-099
	W0822	092	20		S	33-21-13	150-199, 275-278
	W0822	J-E			S	33-21-11	050-099
	W0822	J-E			S	33-21-13	150-199, 275-278
SP01998		0654+84/284/L025					275-277
	W0822	512	20		9	33-21-11	275-277



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP01998		0654+84/284/L025 (continued)					275-277
	W0822	K-E			9	33-21-11	275-277



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02000		0499/280/L025					050-099
SP02000		0540/286/L025					150-199, 275-299
	W0822	089	20		S	33-21-11	ALL
	W0822	M-E			S	33-21-11	ALL
SP02002		0499/280/R025					050-099
SP02002		0457/286/R025					150-199, 275-299
	W0822	090	20		S	33-21-11	ALL
	W0822	N-E			S	33-21-11	ALL
SP02004		0763/280/L025					050-099
SP02004		0808/280/L025					150-157, 275-299
SP02004		1060/280/L025					162-199
	W0822	104	20		S	33-21-13	ALL
	W0822	P-E			S	33-21-13	ALL
SP02006		0763/280/R025					050-099
SP02006		0766/285/R029					150-199, 275-299
	W0822	105	20		S	33-21-13	ALL
	W0822	R-E			S	33-21-13	ALL
SP02008		0847/280/L025					050-099
SP02008		0888/280/L025					150-157, 275-299
SP02008		0932/280/L025					162-199
	W0822	117	20		S	33-21-13	ALL
	W0822	S-E			S	33-21-13	ALL
SP02010		0807/280/R025					ALL
	W0822	118	20		S	33-21-13	ALL
	W0822	T-E			S	33-21-13	ALL
SP02012		0976/280/L025					050-099, 150-157, 275-299
SP02012		0850/280/L025					162-199
	W0822	130	20		S	33-21-13	ALL
	W0822	U-E			S	33-21-13	ALL
SP02014		0888/280/R025					ALL
	W0822	131	20		S	33-21-13	ALL
	W0822	V-E			S	33-21-13	ALL

SPLICE LIST
D280T132

91-21-31
Section SP02000
Page 1
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02016		0910/280/L025					050-099
	W0822	143	20		S	33-21-13	050-099
	W0822	W-E			S	33-21-13	050-099
SP02018		0910/280/R025					050-099
	W0822	144	20		S	33-21-13	050-099
	W0822	X-E			S	33-21-13	050-099
SP02020		1188/280/L025					050-099
SP02020		1152/284/L025					150-199, 275-299
	W0824	010	20		S	33-21-14	ALL
	W0824	A-E			S	33-21-14	ALL
SP02022		1116/280/R025					050-099, 275-299
SP02022		1064/280/R025					150-199
	W0824	011	20		S	33-21-14	ALL
	W0824	B-E			S	33-21-14	ALL
SP02024		1276/280/L025					050-099
SP02024		1284/280/L025					150-199, 275-299
	W0824	023	20		S	33-21-14	ALL
	W0824	C-E			S	33-21-14	ALL
SP02026		1204/280/R025					050-099
SP02026		1221/280/R025					150-199, 275-299
	W0824	024	20		S	33-21-14	ALL
	W0824	D-E			S	33-21-14	ALL
SP02028		1328/280/L025					050-099
SP02028		1364/280/L025					150-199, 275-299
	W0824	037	20		S	33-21-14	ALL
	W0824	E-E			S	33-21-14	ALL
SP02030		1328/280/R025					050-099
SP02030		1292/280/R025					150-199, 275-299
	W0824	038	20		S	33-21-14	ALL
	W0824	F-E			S	33-21-14	ALL
SP02032		1435/280/L025					050-099, 150-199
	W0824	050	20		S	33-21-14	050-099, 150-199

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02032		1435/280/L025 (continued)					050-099, 150-199
	W0824	G-E			S	33-21-14	050-099, 150-199
SP02034		1405/280/R025					050-099, 150-199
	W0824	051	20		S	33-21-14	050-099, 150-199
	W0824	H-E			S	33-21-14	050-099, 150-199
SP02036		0976/280/R025					ALL
	W0824	064	20		S	33-21-14	ALL
	W0824	J-E			S	33-21-14	ALL
SP02038		1100/280/L025					050-099
SP02038		1064/280/L025					150-157, 275-299
SP02038		1015/280/L025					162-199
	W0824	063	20		S	33-21-14	ALL
	W0824	K-E			S	33-21-14	ALL

SPLICE LIST

D280T132

91-21-31

Section SP02000

Page 3 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity	
SP02146		0786/197/L056					ALL	
	W1258	076	20		9	30-71-22	050-099	
	W1258	076	22		9	30-71-22	150-199, 275-299	
SP02148	W1258	C-E			9	30-71-22	ALL	
	SP02148	0786/197/L056					ALL	
		W1258	077	20		9	30-71-22	ALL
SP02150	W1258	C-F			9	30-71-22	ALL	
	SP02150	0786/197/L056					ALL	
		W1258	082	20		9	30-71-22	050-099, 155-199
W1258		082	22		9	30-71-22	150-154, 275-299	
SP02152	W1258	D-E			9	30-71-22	ALL	
	SP02152	0786/197/L056					ALL	
		W1258	083	20		9	30-71-22	ALL
W1258		D-F			9	30-71-22	ALL	
SP02158	SP02158	0786/184/L005					150-199	
		W1258	074	22		9	30-71-22	150-199
		W1258	V-G			9	30-71-22	150-199
SP02162	SP02162	0786/184/L005					050-099, 150-199	
		W1258	078	20		9	30-71-22	050-099
		W1258	078	22		9	30-71-22	150-199
		W1258	B-E			9	30-71-22	050-099
		W1258	W-G			9	30-71-22	150-199
SP02164	SP02164	0786/184/L005					050-099, 150-199	
		W1258	079	20		9	30-71-22	050-099, 150-199
		W1258	B-F			9	30-71-22	050-099
		W1258	W-H			9	30-71-22	150-199
SP02166	SP02166	0775/177/L062					ALL	
		W1258	086	20		9	30-71-22	050-099
		W1258	086	22		9	30-71-22	150-199, 275-299
		W1258	F-E			9	30-71-22	050-099, 275-299
		W1258	R-G			9	30-71-22	150-199

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02168		0775/177/L062					ALL
	W1258	087	20		9	30-71-22	ALL
	W1258	F-F			9	30-71-22	050-099, 275-299
	W1258	R-H			9	30-71-22	150-199
SP02170		0786/197/L056					150-199
	W1258	088	22		9	30-71-22	150-154
	W1258	088	20		9	30-71-22	155-199
	W1258	G-E			9	30-71-22	150-199
SP02172		0786/197/L056					150-199
	W1258	089	20		9	30-71-22	150-199
	W1258	G-F			9	30-71-22	150-199

SPLICE LIST
D280T132

91-21-31
Section SP02100
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02206		0354/280/R032					280-299
	W0222	627	20		9	33-24-13	280-299
	W1230	138	20		9	33-24-13	280-299
SP02208		0354/280/R032					280-299
	W0222	628	20		9	33-24-13	280-299
	W1230	139	20		9	33-24-13	280-299
SP02210		1562/155/R042					050-099, 150-199
	W1358	15X	16		9	30-71-24	050-099, 150-199
	W1358	O-C			9	30-71-24	050-099, 150-199
	W1358	O-F			9	30-71-24	050-099, 150-199
	W1358	P-C			9	30-71-24	050-099, 150-199
	W1358	P-F			9	30-71-24	050-099, 150-199
	W1358	Q-C			9	30-71-24	050-099, 150-199
	W1358	Q-F			9	30-71-24	050-099, 150-199
SP02214		1562/155/R042					050-099, 150-199
	W1358	N-D			9	30-71-24	050-099, 150-199
	W1358	O-D			9	30-71-24	050-099, 150-199
	W1358	P-D			9	30-71-24	050-099, 150-199
	W1358	Q-D			9	30-71-24	050-099, 150-199
SP02216		1562/155/R042					050-099, 150-199
	W1358	N-E			9	30-71-24	050-099, 150-199
	W1358	O-E			9	30-71-24	050-099, 150-199
	W1358	P-E			9	30-71-24	050-099, 150-199
	W1358	Q-E			9	30-71-24	050-099, 150-199
SP02242		NR280/150/					ALL
	W0288	011	18		9	29-32-11	ALL
	W0400	011	18		9	29-32-11	ALL
SP02244		NL275/147/					ALL
	W0290	012	20		9	29-32-11	ALL
	W0398	011	18		9	29-32-11	ALL
SP02250		P037-00/ /					ALL
	W0192	01U	24		W	21-25-21	ALL
	W0192	A-K			W	21-25-21	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02252		P037-00/ /					ALL
	W0192	01W	24		W	21-25-21	ALL
	W0192	A-J			W	21-25-21	ALL
SP02254		P037-00/ /					ALL
	W0192	01Z	20		W	21-25-21	ALL
	W0192	A-L			W	21-25-21	ALL
SP02256		P036-00/ /					ALL
	W0176	01B	24		W	21-25-11	ALL
	W0176	A-H			W	21-25-11	ALL
SP02258		P036-00/ /					ALL
	W0176	01C	24		W	21-25-11	ALL
	W0176	A-G			W	21-25-11	ALL
SP02260		P036-00/ /					ALL
	W0176	01D	20		W	21-25-11	ALL
	W0176	A-K			W	21-25-11	ALL
SP02270		P008-00/ /					ALL
	W0264	057	16		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0264	204R	16		9	33-13-18	156-157, 166-199, 277-299
	W0632	013	18		9	33-13-18	ALL
	W0711	045	20		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0711	221R	20		9	33-13-18	156-157, 166-199, 277-299
	W0847	001	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0847	203B	18		9	33-13-18	156-157, 166-199
	W0847	203R	18		9	33-13-18	277-299
SP02272		P008-00/ /					ALL
	W0632	046	18		9	33-13-18	ALL
	W0685	001	20		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0685	203R	20		9	33-13-18	156-157, 166-199, 277-299
	W0756	161	20		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0756	290R	20		9	33-13-18	156-157, 166-199, 277-299
	W0756	291R	20		9	33-13-18	156-157, 166-199, 277-299
	W0756	528	20		9	33-13-18	050-099, 150-155, 162-165, 275-276



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02276		P008-00/ /					ALL
	W0483	010	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0483	208R	18		9	33-13-18	156-157, 166-199, 277-299
	W0615	001	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0615	204R	18		9	33-13-18	156-157, 166-199, 277-299
	W0629	014	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0629	206R	18		9	33-13-18	156-157, 166-199, 277-299
	W0632	135R	12		9	33-13-18	156-157, 166-199, 277-299
	W0632	162	14		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0843	001	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0843	204R	18		9	33-13-18	156-157, 166-199, 277-299
SP02280		P008-00/ /					ALL
	W0614	014	20		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0614	201R	20		9	33-13-18	156-157, 166-199, 277-299
	W0632	104	18		9	33-13-18	ALL
	W0779	021	20		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0779	225R	20		9	33-13-18	156-157, 166-199, 277-299
	W0851	214R	20		9	33-13-18	275-299
	W0851	907R	20		9	23-22-12	150, 152-199
SP02282		190/190/L046					ALL
	W0485	017	20		9	33-13-18	ALL
	W0632	019	18		9	33-13-18	ALL
	W0733	072	16		9	33-13-18	ALL
SP02284		0190/190/L046					ALL
	W0519	028	18		9	33-13-18	ALL
	W0614	007	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0614	203R	18		9	33-13-18	156-157, 166-199, 277-299
	W0632	092	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0632	136R	18		9	33-13-18	156-157, 166-199, 277-299
SP02286		0190/190/L046					ALL
	W0631	016	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0631	205R	18		9	33-13-18	156-157, 166-199, 277-299
	W0632	109	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0632	138R	18		9	33-13-18	156-157, 166-199, 277-299
	W0845	001	18		9	33-13-18	050-099, 150-155, 162-165, 275-276
	W0845	203R	18		9	33-13-18	156-157, 166-199, 277-299

SPLICE LIST
D280T132

91-21-31
Section SP02200
Page 3
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02288		0190/190/L046					ALL
	W0481	045	20		9	33-13-18	ALL
	W0632	009	18		9	33-13-18	ALL
	W0731	072	16		9	33-13-18	ALL
	W0756	521	18		9	33-13-18	ALL
	W0768	128	18		9	33-13-18	ALL
SP02290		0190/190/L046					ALL
	W0517	028	18		9	33-13-18	ALL
	W0632	091	18		9	33-13-18	ALL
SP02292		0190/190/L046					ALL
	W0632	110	18		9	33-13-18	ALL
	W1711	034	18		9	33-13-18	ALL
SP02294		0238/198/R035					ALL
	W0590	007	18		9	28-25-21	ALL
	W0606	564	20		9	28-25-21	ALL
	W0606	564Z				28-25-21	ALL
SP02296		P008-00/ /					ALL
	W0606	196R	20		9	26-21-11	ALL
	W0614	197R	20		9	26-21-11	ALL
SP02298		P008-00/ /					ALL
	W0606	083R	20		9	26-21-11	ALL
	W0614	198R	20		9	26-21-11	ALL

SPLICE LIST

D280T132

91-21-31

Section SP02200

Page 4 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02300		P008-00/ /					ALL
	W0606	197R	20		9	26-21-11	ALL
	W0614	195R	20		9	26-21-11	ALL
SP02302		P008-00/ /					ALL
	W0606	198R	20		9	26-21-11	ALL
	W0614	084R	20		9	26-21-11	ALL
SP02304		0263/193/L044					ALL
	W0902	101	18		S	33-31-41	ALL
	W0902	B-A			S	33-31-41	ALL
SP02308		P040-00/ /					ALL
	W1132	019R	18		9	26-15-12	ALL
	W1132	A-C			9	26-15-12	ALL
SP02310		0220/194/L050					ALL
	W0431	010	22		9	30-32-11	ALL
	W0572	548	22		9	30-32-11	ALL
SP02312		0220/194/L050					ALL
	W0431	008	22		9	30-32-11	ALL
	W0572	549	22		9	30-32-11	ALL
SP02314		0220/194/L050					ALL
	W0399	014	22		9	30-33-11	ALL
	W0572	179	22		9	30-33-11	ALL
SP02318		P061-00/ /					ALL
	W0070	642	18		9	33-11-16	ALL
	W0070	A-A			9	33-11-16	ALL
	W0070	B-A			9	33-11-16	ALL
SP02360		P011-05/ /					ALL
	W0040	748	22		9	33-13-19	ALL
	W0044	082	22		9	33-13-19	ALL
	W0044	084	22		9	33-13-19	ALL
	W0044	086	22		9	33-13-19	ALL
	W0044	091	22		9	33-13-19	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02362		P011-05/ /					ALL
	W0040	357R	24		9	33-13-19	ALL
	W0044	300R	24		9	33-13-19	ALL
	W0044	301R	24		9	33-13-19	ALL
	W0044	302R	24		9	33-13-19	ALL
	W0044	303R	24		9	33-13-19	ALL
SP02364		P011-05/ /					ALL
	W0040	357B	24		9	33-13-19	ALL
	W0044	300B	24		9	33-13-19	ALL
	W0044	301B	24		9	33-13-19	ALL
	W0044	302B	24		9	33-13-19	ALL
	W0044	303B	24		9	33-13-19	ALL
SP02366		P011-05/ /					ALL
	W0040	357Y	24		9	33-13-19	ALL
	W0044	300Y	24		9	33-13-19	ALL
	W0044	301Y	24		9	33-13-19	ALL
	W0044	302Y	24		9	33-13-19	ALL
	W0044	303Y	24		9	33-13-19	ALL

SPLICE LIST
D280T132

91-21-31
Section SP02300
Page 2 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02450		0240/276/L017					050-099
SP02450		0239/282/L021					150-199, 275-299
	W1224	105	22		9	33-22-41	ALL
	W1224	B-A			9	33-22-41	ALL
SP02452		0240/276/L017					050-099
SP02452		0239/282/L021					150-199, 275-299
	W1224	106	22		9	33-22-41	ALL
	W1224	B-B			9	33-22-41	ALL
SP02456		0786/180/L026					150-199
	W1258	132	22		9	30-71-22	150-199
	W1258	S-G			9	30-71-22	150-199
SP02458		0786/197/L023					050-099, 150-199
	W1258	133	20		9	30-71-22	050-099
	W1258	133	22		9	30-71-22	150-199
	W1258	L-G			9	30-71-22	050-099
	W1258	X-G			9	30-71-22	150-199
SP02476		0786/180/L026					150-199
	W1258	138	20		9	30-71-22	150-199
	W1258	S-H			9	30-71-22	150-199
SP02480		0238/198/R035					050-099, 150-156, 162-166, 275-299
	W0606	013R	20		9	26-22-21	275-299
	W0606	022R	20		9	26-22-21	275-299
	W0606	187R	20		9	26-22-21	275-299
	W0614	013R	20		9	26-22-21	275-299
SP02490		P011-01/ /					ALL
	W0044	723	20		W	33-11-13	ALL
	W0044	A-A			W	33-11-13	ALL
SP02492		P011-01/ /					ALL
	W0044	724	20		W	33-11-13	ALL
	W0044	A-B			W	33-11-13	ALL
SP02494		0335/192/R055					ALL
	W0756	807	24		9	24-22-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP02400
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02494		0335/192/R055 (continued)					ALL
	W0756	808	24		9	24-22-11	ALL
	W0768	508	24		9	24-22-11	ALL



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02504		422/295/R060					ALL
	W0786	003	20		S	33-51-11	ALL
	W0786	033	22		S	33-51-21	ALL
	W1222	056	22		S	33-51-11	ALL
SP02506		1400/290/R080					ALL
	W0786	073	22		S	33-51-21	ALL
	W0836	003	22		S	33-51-11	ALL
	W1222	018	22		S	33-51-11	ALL
	W1222	081	22		S	33-51-11	ALL
SP02562		0335/192/R055					ALL
	W0756	554	24		S	21-31-11	ALL
	W0756	555	24		S	21-31-11	ALL
	W0768	512	24		S	21-31-21	ALL
	W0768	513	24		S	21-31-11	ALL
SP02564		0905/305/R030					ALL
	W0656	109	16		S	25-65-12	ALL
	W0786	103	16		S	25-65-12	ALL
SP02566		0905/305/R030					ALL
	W0658	022	16		S	25-65-12	ALL
	W0786	102	16		S	25-65-12	ALL
SP02568		0905/289/L071					ALL
	W0596	135	16		S	25-65-11	ALL
	W0786	116	16		S	25-65-11	ALL
SP02592		1383/114/R025					ALL
	W1366	004	18		9	30-71-11	ALL
	W1366	B-C			9	30-71-11	ALL
SP02594		0335/192/R055					150-154, 275-276
	W0282	022	22		9	25-33-11	150-154, 275-276
	W0580	144	20		9	25-33-11	150-154, 275-276
SP02596		0335/192/R055					150-154, 275-276
	W0282	023	22		9	25-33-11	150-154, 275-276
	W0580	145	20		9	25-33-11	150-154, 275-276

SPLICE LIST
D280T132

91-21-31
Section SP02500
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02628		1090/185/L071					050-099
	W1258	164	20		9	30-71-22	050-099
	W1258	Z-F			9	30-71-22	050-099
SP02630		1008/183/R041					ALL
	W0738	511	20		9	27-18-11	155-157, 166-199, 277-299
	W0738	A-A			9	27-18-11	155-157, 166-199, 277-299
	W0752	008	22		9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0752	A-A			9	27-18-11	050-099, 150-154, 162-165, 275-276
SP02632		1008/183/R041					ALL
	W0464	304B	20		9	27-18-11	155-157, 166-199, 277-299
	W0464	404B	20		9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0464	A-A			9	27-18-11	ALL
SP02634		1008/183/R041					ALL
	W0738	512	20		9	27-18-11	155-157, 166-199, 277-299
	W0738	A-B			9	27-18-11	155-157, 166-199, 277-299
	W0752	007	22		9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0752	A-B			9	27-18-11	050-099, 150-154, 162-165, 275-276
SP02636		1008/183/R041					ALL
	W0464	304Y	20		9	27-18-11	155-157, 166-199, 277-299
	W0464	404Y	20		9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0464	A-B			9	27-18-11	ALL
SP02638		1008/183/L041					ALL
	W0756	085	22		9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0756	A-A			9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0942	588	20		9	27-18-11	155-157, 166-199, 277-299
	W0942	A-A			9	27-18-11	155-157, 166-199, 277-299
SP02640		1008/183/L041					ALL
	W0446	305Y	20		9	27-18-11	155-157, 166-199, 277-299
	W0446	406R	20		9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0446	A-C			9	27-18-11	ALL
SP02642		1008/183/L041					ALL
	W0756	086	22		9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0756	A-B			9	27-18-11	050-099, 150-154, 162-165, 275-276

SPLICE LIST
D280T132

91-21-31
Section SP02600
Page 1
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02642		1008/183/L041 (continued)					ALL
	W0942	590	20		9	27-18-11	155-157, 166-199, 277-299
	W0942	A-B			9	27-18-11	155-157, 166-199, 277-299
SP02644		1008/183/L041					ALL
	W0446	305B	20		9	27-18-11	155-157, 166-199, 277-299
	W0446	406Y	20		9	27-18-11	050-099, 150-154, 162-165, 275-276
	W0446	A-D			9	27-18-11	ALL
SP02646		1760/264/L042					ALL
	W0502	012	20		9	27-38-11	ALL
	W0502	A-A			9	27-38-11	ALL
SP02648		1760/264/L042					ALL
	W0514	012	20		9	27-38-11	ALL
	W0514	A-A			9	27-38-11	ALL
SP02650		1760/264/L042					ALL
	W0502	013	20		9	27-38-11	ALL
	W0502	A-B			9	27-38-11	ALL
SP02652		1760/264/L042					ALL
	W0514	013	20		9	27-38-11	ALL
	W0514	A-B			9	27-38-11	ALL
SP02654		1760/264/L042					ALL
	W0502	002	20		9	27-38-11	ALL
	W0502	A-C			9	27-38-11	ALL
SP02656		1760/264/L042					ALL
	W0514	002	20		9	27-38-11	ALL
	W0514	A-C			9	27-38-11	ALL
SP02658		1760/264/L042					ALL
	W0502	003	20		9	27-38-11	ALL
	W0502	A-D			9	27-38-11	ALL
SP02660		1760/264/L042					ALL
	W0514	003	20		9	27-38-11	ALL
	W0514	A-D			9	27-38-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP02600
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02670		0928/260/L090					150-199, 275-299
	W0784	212R	24		9	52-71-12	150-199, 275-299
	W0784	B-A			9	52-71-12	150-199, 275-299
SP02672		0928/260/L090					150-199, 275-299
	W0784	212B	24		9	52-71-12	150-199, 275-299
	W0784	B-B			9	52-71-12	150-199, 275-299
SP02674		0928/260/R090					150-199, 275-299
	W0786	204R	24		9	52-71-12	150-199, 275-299
	W0786	D-A			9	52-71-12	150-199, 275-299
SP02676		0928/260/R090					150-199, 275-299
	W0786	204B	24		9	52-71-12	150-199, 275-299
	W0786	D-B			9	52-71-12	150-199, 275-299
SP02678		P036-00/ /					050-099, 150-199
	W0176	846	24		W	21-24-11	050-099, 150-199
	W0176	A-M			W	21-24-11	050-099, 150-199
SP02680		P036-00/ /					050-099, 150-199
	W0176	844	20		W	21-24-11	050-099, 150-199
	W0176	A-N			W	21-24-11	050-099, 150-199



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02708		1546/185/R065					ALL
	W1356	022	20		9	30-71-23	050-099, 155-199
	W1356	022	22		9	30-71-23	150-154, 275-299
	W1356	D-C			9	30-71-23	ALL
SP02710		0786/197/R065					050-099, 275-299
	W1258	150	20		9	30-71-22	050-099
	W1258	150	22		9	30-71-22	275-299
	W1258	B-C			9	30-71-22	050-099, 275-299
SP02718		1540/158/R062					ALL
	W1356	023	20		9	30-71-23	050-099, 155-199
	W1356	023	22		9	30-71-23	150-154, 275-299
	W1356	F-C			9	30-71-23	ALL
SP02726		1540/158/R062					ALL
	W1356	23X	20		9	30-71-23	ALL
	W1356	F-D			9	30-71-23	ALL
SP02744		1355/170/L072					ALL
	W0578	085	24		S	21-44-11	ALL
	W0580	149	24		S	21-44-11	ALL
SP02746		1390/120/R020					ALL
	W1366	005	20		Y	30-71-23	050-099, 155-199
	W1366	005	22		Y	30-71-23	150-154, 275-299
	W1366	A-D			9	30-71-23	ALL
	W1366	A-E			9	30-71-23	ALL
SP02750		1546/185/R065					ALL
	W1356	22X	20		9	30-71-23	ALL
	W1356	D-D			9	30-71-23	ALL
SP02756		0315/190/L050					ALL
	W0768	518	12		9	24-51-24	ALL
	W1342	001	12		9	24-51-24	ALL
	W1342	007	12		9	24-51-24	ALL
SP02770		0730/190/R045					275-276

SPLICE LIST

D280T132

91-21-31

Section SP02700

Page 1

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02772		0135/170/L016					ALL
	W0606	073	22		9	31-31-22	ALL
	W0606	A-D			9	31-31-22	ALL
SP02774		0135/170/L016					ALL
	W0606	137	20		9	31-31-22	ALL
	W0606	A-E			9	31-31-22	ALL
SP02776		0764/295/R060					150-199
SP02776		0800/280/L080					280-299
SP02778		0764/295/R060					150-199
SP02778		0800/280/L080					280-299
SP02796		0654/284/L050					150-199
SP02796		0634/284/L050					275-278
	W0812	632	20		9	33-21-11	150-199, 275-278
	W0812	B-J			9	33-21-11	150-199, 275-278
SP02798		0654/284/L050					150-199, 275-278
	W0812	633	20		9	33-21-11	150-199, 275-278
	W0812	B-K			9	33-21-11	150-199, 275-278

SPLICE LIST

D280T132

91-21-31

Section SP02700

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02800		0654+84/284/L050					150-157, 275-278
SP02800		0680/284/L050					162-199
	W0812	643	20		9	33-21-11	150-199, 275-278
	W0812	A-E			9	33-21-11	150-199, 275-278
SP02802		0654+84/284/L050					150-157, 275-278
SP02802		0680/284/L050					162-199
	W0812	644	20		9	33-21-11	150-199, 275-278
	W0812	A-F			9	33-21-11	150-199, 275-278
SP02804		724/284/R050					150-199
SP02804		0654+107/284/R050					275-278
	W0812	645	20		9	33-21-11	150-199, 275-278
	W0812	A-K			9	33-21-11	150-199, 275-278
SP02806		724/284/R050					150-199
SP02806		0654+107/284/R050					275-278
	W0812	646	20		9	33-21-11	150-199, 275-278
	W0812	A-L			9	33-21-11	150-199, 275-278
SP02810		0654+66/284/R050					150-199
SP02810		0654+60/284/R050					275-278
	W0812	639	20		9	33-21-11	150-199, 275-278
	W0812	A-R			9	33-21-11	150-199, 275-278
SP02812		0654+66/284/R050					150-199
SP02812		0654+60/284/R050					275-278
	W0812	640	20		9	33-21-11	150-199, 275-278
	W0812	A-S			9	33-21-11	150-199, 275-278
SP02814		0722/284/L050					150-199
	W0812	650	20		9	33-21-11	150-199
	W0812	B-E			9	33-21-11	150-199
SP02816		0722/284/L050					150-199
	W0812	651	20		9	33-21-11	150-199
	W0812	B-F			9	33-21-11	150-199
SP02818		0762/284/R050					150-199
	W0812	652	20		9	33-21-11	150-199

SPLICE LIST
D280T132

91-21-31
Section SP02800
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02818		0762/284/R050 (continued)					150-199
	W0812	A-W			9	33-21-11	150-199
SP02820		0762/284/R050					150-199
	W0812	653	20		9	33-21-11	150-199
	W0812	A-X			9	33-21-11	150-199
SP02822		0759/284/L050					150-199
	W0812	760	20		9	33-21-11	150-199
	W0812	B-G			9	33-21-11	150-199
SP02824		0759/284/L050					150-199
	W0812	761	20		9	33-21-11	150-199
	W0812	B-H			9	33-21-11	150-199
SP02828		0654+64/284/L050					150-199, 275-278
	W0812	762	20		9	33-21-11	150-199, 275-278
	W0812	B-L			9	33-21-11	150-199, 275-278
SP02830		0654+64/284/L050					150-199, 275-278
	W0812	763	20		9	33-21-11	150-199, 275-278
	W0812	B-M			9	33-21-11	150-199, 275-278
SP02834		0654+84/284/L050					150-157, 275-278
SP02834		0720/284/L050					162-199
	W0812	765	20		9	33-21-11	150-199, 275-278
	W0812	A-G			9	33-21-11	150-199, 275-278
SP02836		0654+84/284/L050					150-157, 275-278
SP02836		0720/284/L050					162-199
	W0812	766	20		9	33-21-11	150-199, 275-278
	W0812	A-H			9	33-21-11	150-199, 275-278
SP02840		634/284/R050					150-199
SP02840		0634/284/R050					275-299
	W0812	638	20		9	33-21-11	150-199, 275-299
	W0812	763	20		9	33-21-11	150-199, 275-299
	W0812	A-T			9	33-21-11	150-199, 275-278



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02842		634/284/R050					150-199
SP02842		0634/284/R050					275-299
	W0812	637	20		9	33-21-11	150-199, 275-299
	W0812	762	20		9	33-21-11	150-199, 275-299
	W0812	A-U			9	33-21-11	150-199, 275-278
SP02844		0744/284/R050					150-199
	W0812	761	20		9	33-21-11	150-199
	W0812	773	20		9	33-21-11	150-199
	W0812	A-Z			9	33-21-11	150-199
SP02846		0744/284/R050					150-199
	W0812	760	20		9	33-21-11	150-199
	W0812	774	20		9	33-21-11	150-199
	W0812	A-Y			9	33-21-11	150-199
SP02848		0730/284/R025					150-199
	W0822	501	20		9	33-21-11	150-199
	W0822	A-E			9	33-21-11	150-199
SP02850		0730/284/R025					150-199
	W0822	502	20		9	33-21-11	150-199
	W0822	A-F			9	33-21-11	150-199
SP02852		0730/284/R025					150-199, 275-278
	W0822	189	20		9	33-21-11	150-199, 275-278
	W0822	A-J			9	33-21-11	150-199, 275-278
SP02854		0730/284/R025					150-199, 275-278
	W0822	190	20		9	33-21-11	150-199, 275-278
	W0822	A-K			9	33-21-11	150-199, 275-278
SP02856		0632/284/R025					150-199, 275-278
	W0822	168	20		S	33-21-11	150-199, 275-278
	W0822	A-T			S	33-21-11	150-199, 275-278
SP02858		0632/284/R025					150-199, 275-278
	W0822	181	20		9	33-21-11	150-199, 275-278
	W0822	A-N			9	33-21-11	150-199, 275-278

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02860		0632/284/R025					150-199, 275-278
	W0822	182	20		9	33-21-11	150-199, 275-278
	W0822	A-P			9	33-21-11	150-199, 275-278
SP02862		0654+66/284/L025					150-199, 275-278
	W0822	185	20		9	33-21-11	150-199, 275-278
	W0822	509	20		9	33-21-11	150-199, 275-278
	W0822	A-X			9	33-21-11	150-199, 275-278
SP02864		0654+66/284/L025					150-199, 275-278
	W0822	186	20		9	33-21-11	150-199, 275-278
	W0822	510	20		9	33-21-11	150-199, 275-278
	W0822	A-W			9	33-21-11	150-199, 275-278
SP02866		0654+66/284/L025					150-199, 275-278
	W0822	511	20		S	33-21-11	150-199, 275-278
	W0822	A-Y			S	33-21-11	150-199, 275-278
SP02868		0654+66/284/L025					150-199, 275-278
	W0822	187	20		9	33-21-11	150-199, 275-278
	W0822	A-U			9	33-21-11	150-199, 275-278
SP02870		0654+66/284/L025					150-199, 275-278
	W0822	188	20		9	33-21-11	150-199, 275-278
	W0822	A-V			9	33-21-11	150-199, 275-278
SP02872		0654+84/284/L025					150-157, 275-278
SP02872		0719/284/L025					162-199
	W0822	195	20		9	33-21-11	150-199, 275-278
	W0822	B-E			9	33-21-11	150-199, 275-278
SP02874		0654+84/284/L025					150-199, 275-278
	W0822	196	20		9	33-21-11	150-199, 275-278
	W0822	B-F			9	33-21-11	150-199, 275-278
SP02876		0657/284/L025					150-157
SP02876		0760/284/L025					162-199
	W0822	506	20		9	33-21-11	150-199
	W0822	B-J			9	33-21-11	150-199

SPLICE LIST
D280T132

91-21-31
Section SP02800
Page 4
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02878		0657/284/L025					150-157
SP02878		0760/284/L025					162-199
	W0822	507	20		9	33-21-11	150-199
	W0822	B-K			9	33-21-11	150-199
SP02880		0730/284/R025					150-199
	W0822	164	20		9	33-21-11	150-199
	W0822	A-G			9	33-21-11	150-199
SP02882		0730/284/R025					150-199
	W0822	165	20		9	33-21-11	150-199
	W0822	A-H			9	33-21-11	150-199
SP02884		0730/284/R025					150-199, 275-278
	W0822	166	20		9	33-21-11	150-199, 275-278
	W0822	A-L			9	33-21-11	150-199, 275-278
SP02886		0730/284/R025					150-199, 275-278
	W0822	167	20		9	33-21-11	150-199, 275-278
	W0822	A-M			9	33-21-11	150-199, 275-278
SP02888		0632/284/R025					150-199, 275-278
	W0822	510	20		9	33-21-11	150-199, 275-278
	W0822	A-R			9	33-21-11	150-199, 275-278
SP02890		0632/284/R025					150-199, 275-278
	W0822	509	20		9	33-21-11	150-199, 275-278
	W0822	A-S			9	33-21-11	150-199, 275-278
SP02892		0654+84/284/L025					150-157, 275-278
SP02892		0719/284/L025					162-199
	W0822	167	20		9	33-21-11	150-199, 275-278
	W0822	193	20		9	33-21-11	150-199, 275-278
	W0822	B-G			9	33-21-11	150-199, 275-278
SP02894		0654+81/284/L025					150-157, 275-278
SP02894		0719/284/L025					162-199
	W0822	166	20		9	33-21-11	150-199, 275-278
	W0822	192	20		9	33-21-11	150-199, 275-278
	W0822	B-H			9	33-21-11	150-199, 275-278

SPLICE LIST
D280T132

91-21-31
Section SP02800
Page 5
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02896		0657/284/L025					150-157
SP02896		0760/284/L025					162-199
	W0822	165	20		9	33-21-11	150-199
	W0822	504	20		9	33-21-11	150-199
	W0822	B-L			9	33-21-11	150-199
SP02898		0657/284/L025					150-157
SP02898		0760/284/L025					162-199
	W0822	164	20		9	33-21-11	150-199
	W0822	503	20		9	33-21-11	150-199
	W0822	B-M			9	33-21-11	150-199

SPLICE LIST
D280T132

91-21-31
Section SP02800
Page 6 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02900		705/284/R050					150-199
SP02900		0654+66/284/R050					275-278
	W0812	766	20		9	33-21-11	150-199, 275-278
	W0812	767	20		9	33-21-11	150-199, 275-278
	W0812	A-N			9	33-21-11	150-199, 275-278
SP02902		705/284/R050					150-199
SP02902		0654+66/284/R050					275-278
	W0812	765	20		9	33-21-11	150-199, 275-278
	W0812	768	20		9	33-21-11	150-199, 275-278
	W0812	A-M			9	33-21-11	150-199, 275-278
SP02910		1196/284/R025					150-199, 275-299
	W0824	100	20		S	33-21-14	150-199, 275-299
	W0824	A-K			S	33-21-14	150-199, 275-299
SP02912		1196/284/R025					150-199, 275-299
	W0824	101	20		9	33-21-14	150-199, 275-299
	W0824	A-H			9	33-21-14	150-199, 275-299
SP02914		1196/284/R025					150-199, 275-299
	W0824	102	20		9	33-21-14	150-199, 275-299
	W0824	A-J			9	33-21-14	150-199, 275-299
SP02916		1196/284/R025					150-199, 275-299
	W0824	081	20		9	33-21-14	150-199, 275-299
	W0824	A-F			9	33-21-14	150-199, 275-299
SP02918		1196/284/R025					150-199, 275-299
	W0824	082	20		9	33-21-14	150-199, 275-299
	W0824	A-G			9	33-21-14	150-199, 275-299
SP02920		1196/284/L025					150-199, 275-299
	W0824	083	20		9	33-21-14	150-199, 275-299
	W0824	A-L			9	33-21-14	150-199, 275-299
SP02922		1196/284/L025					150-199, 275-299
	W0824	084	20		9	33-21-14	150-199, 275-299
	W0824	A-M			9	33-21-14	150-199, 275-299

SPLICE LIST
D280T132

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02924		1196/284/L025					150-199, 275-299
	W0824	085	20		9	33-21-14	150-199, 275-299
	W0824	102	20		9	33-21-14	150-199, 275-299
	W0824	A-P			9	33-21-14	150-199, 275-299
SP02926		1196/284/L025					150-199, 275-299
	W0824	086	20		9	33-21-14	150-199, 275-299
	W0824	101	20		9	33-21-14	150-199, 275-299
	W0824	A-N			9	33-21-14	150-199, 275-299
SP02928		1196/284/L025					150-199, 275-299
	W0824	103	20		S	33-21-14	150-199, 275-299
	W0824	A-R			S	33-21-14	150-199, 275-299
SP02930		1197+88/284/R025					150-199, 275-299
	W0824	092	20		9	33-21-14	150-199, 275-299
	W0824	A-S			9	33-21-14	150-199, 275-299
SP02932		1197+88/284/R025					150-199, 275-299
	W0824	093	20		9	33-21-14	150-199, 275-299
	W0824	A-T			9	33-21-14	150-199, 275-299
SP02934		1197+88/284/R025					150-199, 275-299
	W0824	107	20		9	33-21-14	150-199, 275-299
	W0824	A-U			9	33-21-14	150-199, 275-299
SP02936		1197+88/284/R025					150-199, 275-299
	W0824	106	20		9	33-21-14	150-199, 275-299
	W0824	A-V			9	33-21-14	150-199, 275-299
SP02938		1197+88/284/R025					150-199, 275-299
	W0824	104	20		S	33-21-14	150-199, 275-299
	W0824	A-W			S	33-21-14	150-199, 275-299
SP02940		1197+88/284/L025					150-199, 275-299
	W0824	095	20		9	33-21-14	150-199, 275-299
	W0824	106	20		9	33-21-14	150-199, 275-299
	W0824	B-J			9	33-21-14	150-199, 275-299



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02942		1197+88/284/L025					150-199, 275-299
	W0824	096	20		9	33-21-14	150-199, 275-299
	W0824	107	20		9	33-21-14	150-199, 275-299
	W0824	B-H			9	33-21-14	150-199, 275-299
SP02944		1197+88/284/L025					150-199, 275-299
	W0824	090	20		9	33-21-14	150-199, 275-299
	W0824	B-F			9	33-21-14	150-199, 275-299
SP02946		1197+88/284/L025					150-199, 275-299
	W0824	091	20		9	33-21-14	150-199, 275-299
	W0824	B-G			9	33-21-14	150-199, 275-299
SP02948		1197+88/284/L025					150-199, 275-299
	W0824	105	20		S	33-21-14	150-199, 275-299
	W0824	B-K			S	33-21-14	150-199, 275-299
SP02950		1197+44/284/R050					150-199, 275-299
	W0816	662	20		9	33-21-14	150-199, 275-299
	W0816	A-E			9	33-21-14	150-199, 275-299
SP02952		1197+44/284/R050					150-199, 275-299
	W0816	663	20		9	33-21-14	150-199, 275-299
	W0816	A-F			9	33-21-14	150-199, 275-299
SP02954		1152/284/R050					150-199, 275-299
	W0816	670	20		9	33-21-14	150-199, 275-299
	W0816	A-G			9	33-21-14	150-199, 275-299
SP02956		1152/284/R050					150-199, 275-299
	W0816	671	20		9	33-21-14	150-199, 275-299
	W0816	A-H			9	33-21-14	150-199, 275-299
SP02958		1153/284/L050					150-199, 275-299
	W0816	664	20		9	33-21-14	150-199, 275-299
	W0816	A-J			9	33-21-14	150-199, 275-299
SP02960		1153/284/L050					150-199, 275-299
	W0816	665	20		9	33-21-14	150-199, 275-299
	W0816	A-K			9	33-21-14	150-199, 275-299

SPLICE LIST
D280T132

91-21-31
Section SP02900
Page 3
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02962		1197+44/284/L050					150-199, 275-299
	W0816	667	20		9	33-21-14	150-199, 275-299
	W0816	670	20		9	33-21-14	150-199, 275-299
	W0816	A-L			9	33-21-14	150-199, 275-299
SP02964		1197+44/284/L050					150-199, 275-299
	W0816	666	20		9	33-21-14	150-199, 275-299
	W0816	671	20		9	33-21-14	150-199, 275-299
	W0816	A-M			9	33-21-14	150-199, 275-299
SP02966		1197+44/284/L050					150-199, 275-299
	W0816	674	20		9	33-21-14	150-199, 275-299
	W0816	A-P			9	33-21-14	150-199, 275-299
SP02968		1197+44/284/L050					150-199, 275-299
	W0816	675	20		9	33-21-14	150-199, 275-299
	W0816	A-R			9	33-21-14	150-199, 275-299
SP02970		1197+132/284/L050					150-199, 275-299
	W0816	081	20		9	33-21-14	150-199, 275-299
	W0816	677	20		9	33-21-14	150-199, 275-299
	W0816	A-T			9	33-21-14	150-199, 275-299
SP02972		1197+132/284/L050					150-199, 275-299
	W0816	082	20		9	33-21-14	150-199, 275-299
	W0816	676	20		9	33-21-14	150-199, 275-299
	W0816	A-S			9	33-21-14	150-199, 275-299
SP02974		1197+132/284/R050					150-199, 275-299
	W0816	672	20		9	33-21-14	150-199, 275-299
	W0816	A-U			9	33-21-14	150-199, 275-299
SP02976		1197+132/284/R050					150-199, 275-299
	W0816	673	20		9	33-21-14	150-199, 275-299
	W0816	A-V			9	33-21-14	150-199, 275-299
SP02978		1197+44/284/R050					150-199, 275-299
	W0816	081	20		9	33-21-14	150-199, 275-299
	W0816	A-W			9	33-21-14	150-199, 275-299



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP02980		1197+44/284/R050					150-199, 275-299
	W0816	082	20		9	33-21-14	150-199, 275-299
	W0816	A-X			9	33-21-14	150-199, 275-299
SP02982		1702/170/0					150-199, 275-299
	W0910	201R	20		9	32-71-11	150-199, 275-299
	W0910	A-A			9	32-71-11	150-199, 275-299
SP02984		1702/170/0					150-199, 275-299
	W0910	201B	20		9	32-71-11	150-199, 275-299
	W0910	A-B			9	32-71-11	150-199, 275-299
SP02986		1702/170/0					150-199, 275-299
	W0910	202R	20		9	32-71-11	150-199, 275-299
	W0910	A-C			9	32-71-11	150-199, 275-299
SP02988		1702/170/0					150-199, 275-299
	W0910	202B	20		9	32-71-11	150-199, 275-299
	W0910	A-D			9	32-71-11	150-199, 275-299

SPLICE LIST

D280T132

91-21-31

Section SP02900

Page 5 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03032		NL213/163/					ALL
	W0352	020	18		8	36-11-61	050-099, 150-199, 275-278
	W0356	009	18		8	36-11-61	ALL
	W0356	072	18		8	36-23-11	ALL
	W0356	073	18		8	36-23-11	ALL
	W0356	086	18		8	36-23-11	ALL
	W0356	095	18		8	36-23-11	ALL
	W0356	116	18		8	36-11-61	ALL
SP03034		N 213/163/					ALL
	W0352	008	18		8	36-11-61	050-099, 150-199, 275-278
	W0356	004	18		8	36-11-61	ALL
	W0356	057	18		8	36-11-51	ALL
	W0356	064	18		8	36-11-51	ALL
SP03044		MULTI/280/L045					162-199
	W0124	012	22		9	33-27-11	162-199
	W0124	022	22		9	33-27-11	162-199
	W0124	A-D			9	33-27-11	162-199
SP03046		MULTI/280/L045					162-199
	W0124	011	22		9	33-27-11	162-199
	W0124	021	22		9	33-27-11	162-199
	W0124	A-C			9	33-27-11	162-199
SP03070		0786/187/R025					275-299
	W1258	142	22		9	30-71-22	275-299
	W1258	A-M			9	30-71-22	275-299
SP03072		0786/187/R025					275-299
	W1258	144	20		9	30-71-22	275-299
	W1258	A-N			9	30-71-22	275-299
SP03076		N 145/160/					ALL
	W0372	040	20		8	73-21-11	ALL
	W0372	040Z			V	73-21-11	ALL
	W0372	041	20		8	73-21-11	ALL
	W0372	041Z			V	73-21-11	ALL
	W0396	111	20		8	73-21-11	ALL
	W0396	111Z			V	73-21-11	ALL

SPLICE LIST
D280T132**91-21-31**
Section SP03000
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03078		N 145/160/					ALL
	W0372	210R	20		8	73-21-14	ALL
	W0372	210Z			V	73-21-14	ALL
	W0372	220R	20		8	73-21-14	ALL
	W0372	220Z			V	73-21-14	ALL
	W0396	210R	20		8	73-21-14	ALL
	W0396	210Z			V	73-21-14	ALL
SP03080		N 145/160/					ALL
	W0372	006	20		8	73-21-11	ALL
	W0372	006Z			V	73-21-11	ALL
	W0372	014	20		8	73-21-11	ALL
	W0372	014Z			V	73-21-11	ALL
	W0396	014	20		8	73-21-11	ALL
	W0396	014Z			V	73-21-11	ALL
SP03082		N 145/160/					ALL
	W0372	210B	20		8	73-21-14	ALL
	W0372	220B	20		8	73-21-14	ALL
	W0396	210B	20		8	73-21-14	ALL
SP03086		N 145/160/					ALL
	W0372	203R	20		8	73-21-14	ALL
	W0372	203Z			V	73-21-14	ALL
	W0396	203R	20		8	73-21-14	ALL
	W0396	203Z			V	73-21-14	ALL
	W0396	208R	20		8	73-21-14	ALL
	W0396	208Z			V	73-21-14	ALL
SP03090		N 145/160/					ALL
	W0372	203B	20		8	73-21-14	ALL
	W0396	203B	20		8	73-21-14	ALL
	W0396	208B	20		8	73-21-14	ALL
SP03092		N 145/160/					ALL
	W0372	108	20		8	73-21-19	ALL
	W0372	108Z			V	73-21-19	ALL
	W0372	109	20		8	73-21-19	ALL
	W0372	109Z			V	73-21-19	ALL
	W0396	107	20		8	73-21-19	ALL
	W0396	107Z			V	73-21-19	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03096		N 145/160/					ALL
	W0372	003	16		8	73-21-11	ALL
	W0372	003Z			V	73-21-11	ALL
	W0372	010	16		8	73-21-11	ALL
	W0372	010Z			V	73-21-11	ALL
	W0396	003	16		8	73-21-11	ALL
	W0396	003Z			V	73-21-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP03000
Page 3 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL		GA	CO	Type	Diagram	Effectivity
		Wire No.						
SP03100		N 145/160/						ALL
	W0382	040	20		8	73-21-11		ALL
	W0382	040Z			V	73-21-11		ALL
	W0382	041	20		8	73-21-11		ALL
	W0382	041Z			V	73-21-11		ALL
	W0392	111	20		8	73-21-11		ALL
	W0392	111Z			V	73-21-11		ALL
SP03102		N 145/160/						ALL
	W0382	210R	20		8	73-21-14		ALL
	W0382	210Z			V	73-21-14		ALL
	W0382	220R	20		8	73-21-14		ALL
	W0392	210R	20		8	73-21-14		ALL
	W0392	210Z			V	73-21-14		ALL
SP03104		N 145/160/						ALL
	W0382	006	20		8	73-21-11		ALL
	W0382	006Z			V	73-21-11		ALL
	W0382	014	20		8	73-21-11		ALL
	W0382	014Z			V	73-21-11		ALL
	W0392	014	20		8	73-21-11		ALL
	W0392	014Z			V	73-21-11		ALL
SP03106		N 145/160/						ALL
	W0382	210B	20		8	73-21-14		ALL
	W0382	220B	20		8	73-21-14		ALL
	W0382	220Z			V	73-21-14		ALL
	W0392	210B	20		8	73-21-14		ALL
SP03110		N 145/160/						ALL
	W0382	203R	20		8	73-21-14		ALL
	W0382	203Z			V	73-21-14		ALL
	W0392	203R	20		8	73-21-14		ALL
	W0392	203Z			V	73-21-14		ALL
	W0392	208R	20		8	73-21-14		ALL
	W0392	208Z			V	73-21-14		ALL
SP03114		N 145/160/						ALL
	W0382	203B	20		8	73-21-14		ALL
	W0392	203B	20		8	73-21-14		ALL
	W0392	208B	20		8	73-21-14		ALL

SPLICE LIST

D280T132

91-21-31
Section SP03100
Page 1
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03116		N 145/160/					ALL
	W0382	108	20		8	73-21-19	ALL
	W0382	108Z			V	73-21-19	ALL
	W0382	109	20		8	73-21-19	ALL
	W0382	109Z			V	73-21-19	ALL
	W0392	107	20		8	73-21-19	ALL
	W0392	107Z			V	73-21-19	ALL
SP03120		N 145/160/					ALL
	W0382	003	16		8	73-21-11	ALL
	W0382	003Z			V	73-21-11	ALL
	W0382	010	16		8	73-21-11	ALL
	W0382	010Z			V	73-21-11	ALL
	W0392	003	16		8	73-21-11	ALL
	W0392	003Z			V	73-21-11	ALL
SP03122		NR213/163/					ALL
	W0374	020	18		8	36-11-62	050-099, 150-166, 275-299
	W0376	009	18		8	36-11-62	ALL
	W0376	072	18		8	36-23-21	ALL
	W0376	073	18		8	36-23-21	ALL
	W0376	086	18		8	36-23-21	ALL
	W0376	095	18		8	36-23-21	ALL
	W0376	116	18		8	36-11-62	ALL
SP03124		N 213/163/					ALL
	W0372	107	20		8	73-21-14	ALL
	W0372	107Z			V	73-21-14	ALL
	W0396	103	20		8	73-21-14	ALL
	W0396	103Z			V	73-21-14	ALL
	W0396	109	20		8	73-21-14	ALL
	W0396	109Z			V	73-21-14	ALL
SP03138		0335/192/R055					275-299
	W0282	107	20		9	33-24-14	275-299
	W1230	057	20		9	33-24-14	275-299
SP03140		0335/192/R055					275-299
	W0282	105	20		9	33-24-14	275-299
	W1230	056	20		9	33-24-14	275-299



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03196		N 145/160/					ALL
	W0372	226R	20		8	73-21-14	ALL
	W0372	226Z			V	73-21-14	ALL
	W0396	222R	20		8	73-21-14	ALL
	W0396	222Z			V	73-21-14	ALL
	W0396	223R	20		8	73-21-14	ALL
	W0396	223Z			V	73-21-14	ALL
SP03198		N 145/160/					ALL
	W0372	226B	20		8	73-21-14	ALL
	W0396	222B	20		8	73-21-14	ALL
	W0396	223B	20		8	73-21-14	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03204		N 145/160/					ALL
	W0382	226R	20		8	73-21-14	ALL
	W0382	226Z			V	73-21-14	ALL
	W0392	222R	20		8	73-21-14	ALL
	W0392	222Z			V	73-21-14	ALL
	W0392	223R	20		8	73-21-14	ALL
	W0392	223Z			V	73-21-14	ALL
SP03208		N 145/160/					ALL
	W0382	226B	20		8	73-21-14	ALL
	W0392	222B	20		8	73-21-14	ALL
	W0392	223B	20		8	73-21-14	ALL
SP03214		0905/305/R030					275-299
	W0665	021	22		S	33-25-11	275-276
	W0665	028	22		S	33-25-11	275-276
	W0665	512	22		S	33-25-11	275-276
	W0665	527	22		S	33-25-11	277-299
	W0814	191	22		S	33-25-11	275-299
SP03240		0674/138/R067					150-199
	W1258	165	20		9	30-71-21	150-199
	W1258	G-C			9	30-71-21	150-199
SP03242		0661/138/L065					150-199, 275-299
	W1258	166	20		9	30-71-21	150-199
	W1258	166	22		9	30-71-21	275-299
	W1258	H-C			9	30-71-21	150-199, 275-299
SP03244		N213/163/					ALL
	W0374	008	18		8	36-11-62	050-099, 150-166, 275-299
	W0376	004	18		8	36-11-62	ALL
	W0376	057	18		8	36-11-52	ALL
	W0376	064	18		8	36-11-52	ALL
SP03246		0674/138/R067					150-199
	W1258	167	20		9	30-71-21	150-199
	W1258	G-D			9	30-71-21	150-199



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03250		0246/201/R067					050-099, 150-199
	W1258	169	20		9	30-71-21	050-099, 150-199
	W1258	I-C			9	30-71-21	050-099, 150-199
SP03252		0246/201/R067					050-099, 150-199
	W1258	171	20		9	30-71-21	050-099, 150-199
	W1258	I-D			9	30-71-21	050-099, 150-199
SP03254		0255/208/R075					ALL
	W1258	170	20		9	30-71-21	050-099, 150-199
	W1258	170	22		9	30-71-21	275-299
	W1258	J-C			9	30-71-21	ALL
SP03256		0255/208/R075					ALL
	W1258	172	20		9	30-71-21	ALL
	W1258	J-D			9	30-71-21	ALL
SP03258		N 145/160/					ALL
	W0382	107	20		8	73-21-14	ALL
	W0382	107Z			V	73-21-14	ALL
	W0382	110	20		8	SPARE	ALL
	W0382	110Z			V	SPARE	ALL
	W0392	103	20		8	73-21-14	ALL
	W0392	103Z			V	73-21-14	ALL
	W0392	109	20		8	73-21-14	ALL
	W0392	109Z			V	73-21-14	ALL
SP03260		0270/160/					050-099, 275-299
	W1078	529R	22		S	26-18-22	050-099, 275-299
	W1078	529Z				26-18-22	050-099, 275-299
	W1080	108R	22		S	26-18-22	050-099, 275-299
SP03262		0730/190/R045					ALL
	W0606	021	22		S	31-31-22	ALL
	W0614	024	22		S	31-31-22	ALL
SP03264		0730/190/R045					ALL
	W0606	202R	22		S	31-31-22	ALL
	W0614	202R	22		S	31-31-22	ALL

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03266		0730/190/R045					ALL
	W0606	202B	22		S	31-31-22	ALL
	W0614	202B	22		S	31-31-22	ALL
SP03268		0730/190/R045					ALL
	W0606	202Z			S	31-31-22	ALL
	W0614	202Z			S	31-31-22	ALL
SP03280		0320/260/L090					ALL
	W0842	001	20		9	30-46-11	ALL
	W0842	A-A			9	30-46-11	ALL
SP03282		0320/260/L090					ALL
	W0842	002	20		9	30-46-11	ALL
	W0842	A-B			9	30-46-11	ALL
SP03284		0320/260/R090					ALL
	W0844	001	20		9	30-46-11	ALL
	W0844	A-A			9	30-46-11	ALL
SP03286		0320/260/R090					ALL
	W0844	002	20		9	30-46-11	ALL
	W0844	A-B			9	30-46-11	ALL
SP03296		1510/260/L090					ALL
	W0850	001	20		9	30-46-11	ALL
	W0850	A-A			9	30-46-11	ALL
SP03298		1510/260/L090					ALL
	W0850	002	20		9	30-46-11	ALL
	W0850	A-B			9	30-46-11	ALL

SPLICE LIST
D280T132

91-21-31
Section SP03200
Page 3 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03300		1510/260/R090					ALL
	W0852	001	20		9	30-46-11	ALL
	W0852	A-A			9	30-46-11	ALL
SP03302		1510/260/R090					ALL
	W0852	002	20		9	30-46-11	ALL
	W0852	A-B			9	30-46-11	ALL
SP03340		N145/160/					ALL
	W0356	163	20		8	78-36-11	ALL
	W0356	163Z			V	78-36-11	ALL
	W0372	123	20		8	78-36-11	ALL
	W0372	123Z			V	78-36-11	ALL
	W0396	132	20		8	78-36-11	ALL
	W0396	132Z			V	78-36-11	ALL
SP03342		N145/160/					ALL
	W0376	168	20		8	78-36-21	ALL
	W0376	168Z			V	78-36-21	ALL
	W0382	123	20		8	78-36-21	ALL
	W0382	123Z			V	78-36-21	ALL
	W0392	132	20		8	78-36-21	ALL
	W0392	132Z			V	78-36-21	ALL
SP03344		0135/170/L016					ALL
	W0606	138	20		9	31-31-22	ALL
	W0606	A-C			9	31-31-22	ALL
SP03346		0135/170/L016					ALL
	W0606	075	22		9	31-31-22	ALL
	W0606	A-A			9	31-31-22	ALL
SP03368		0315/188/L075					050-099, 150-199
	W1258	600	20		9	30-71-21	050-099, 150-199
	W1258	A-Q			9	30-71-21	050-099, 150-199
SP03372		0654+68/196/L055					150-199
	W1258	602	20		9	30-71-21	150-199
	W1258	B-Q			9	30-71-21	150-199



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03380		0654+68/159/L072					150-199
	W1258	606	20		9	30-71-21	150-199
	W1258	B-M			9	30-71-21	150-199
SP03382		1540/180/R065					150-199
	W1356	005	20		9	30-71-24	150-199
	W1356	H-A			9	30-71-24	150-199
SP03384		1450/170/R070					050-099, 150-199
	W1356	001	16		9	30-71-24	050-099, 150-199
	W1356	G-B			9	30-71-24	050-099, 150-199
SP03385		1450/178/R076					050-099, 150-199
	W1356	N-C			9	30-71-24	050-099, 150-199
	W1356	O-D			9	30-71-24	050-099, 150-199
	W1356	O-E			9	30-71-24	050-099, 150-199
	W1356	Q-D			9	30-71-24	050-099, 150-199
SP03386		1450/140/R070					050-099, 150-199
	W1356	N-F			9	30-71-24	050-099, 150-199
	W1356	O-C			9	30-71-24	050-099, 150-199
	W1356	Q-C			9	30-71-24	050-099, 150-199
	W1356	Q-F			9	30-71-24	050-099, 150-199
SP03387		1450/140/R070					050-099, 150-199
	W1356	015	16		9	30-71-24	050-099, 150-199
	W1356	N-E			9	30-71-24	050-099, 150-199
	W1356	N-G			9	30-71-24	050-099, 150-199
	W1356	O-F			9	30-71-24	050-099, 150-199
	W1356	P-D			9	30-71-24	050-099, 150-199
	W1356	P-F			9	30-71-24	050-099, 150-199
	W1356	Q-E			9	30-71-24	050-099, 150-199



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03476		N 145/160/					ALL
	W0382	130	20		8	73-21-17	ALL
	W0382	130Z			V	73-21-17	ALL
	W0382	131	20		8	73-21-17	ALL
	W0382	131Z			V	73-21-17	ALL
	W0392	100	20		8	73-21-17	ALL
	W0392	100Z			V	73-21-17	ALL
SP03478		N 145/160/					ALL
	W0372	111	20		8	73-21-17	ALL
	W0372	111Z			V	73-21-17	ALL
	W0372	112	20		8	73-21-17	ALL
	W0372	112Z			V	73-21-17	ALL
	W0396	100	20		8	73-21-17	ALL
	W0396	100Z			V	73-21-17	ALL
SP03490		0800/280/L080					275-299
	W0216	035	20		S	33-24-14	275-299
	W0216	035Z				33-24-14	277-299
	W1236	129	20		S	33-24-14	275-299
SP03492		0800/280/L080					275-299
	W0216	036	20		S	33-24-14	275-299
	W0216	036Z				33-24-14	277-299
	W1236	123	20		S	33-24-14	275-299

SPLICE LIST
D280T132

91-21-31
Section SP03400
Page 1 End
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03530		0246/201/L063					050-099, 150-199
	W1258	174	20		9	30-71-21	050-099, 155-199
	W1258	174	22		9	30-71-21	150-154
	W1258	B-O			9	30-71-21	050-099, 150-199
SP03532		0687/163/L072					150-199
	W1258	603	20		9	30-71-21	150-199
	W1258	A-W			9	30-71-21	150-199
SP03534		0687/163/L072					150-199
	W1258	176	20		9	30-71-21	150-199
	W1258	A-X			9	30-71-21	150-199
SP03536		0687/163/L072					150-199
	W1258	177	20		9	30-71-21	150-199
	W1258	B-I			9	30-71-21	150-199
SP03538		0687/163/L072					150-199
	W1258	604	20		9	30-71-21	150-199
	W1258	A-Y			9	30-71-21	150-199
SP03578		0764/295/R060					150-199
	W0792	091	20		9	33-24-11	150-199
	W0792	112	20		9	33-24-11	150-199
	W0814	178	20		9	33-24-11	150-199
	W0814	800	20		9	33-24-11	150-199
SP03580		0354/280/R032					150-157
	W0222	167	18		S	33-51-12	150-157
	W1222	026	16		S	33-51-12	150-157
	W1222	031	18		S	33-51-12	150-157
SP03590		0764/295/R060					050-099, 150-199
	W0665	206R	22		S	23-31-14	150-199
	W0792	206R	22		S	23-31-14	150-199
	W0792	207R	22		S	23-31-14	050-099, 150-199
	W0792	208R	22		S	23-31-14	050-099, 150-199
	W0814	210R	22		S	23-31-14	050-099, 150-199

SPLICE LIST
D280T132



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03592		0764/295/R060					050-099, 150-199
	W0665	206B	22		S	23-31-14	150-199
	W0792	206B	22		S	23-31-14	150-199
	W0792	207B	22		S	23-31-14	050-099, 150-199
	W0792	208B	22		S	23-31-14	050-099, 150-199
	W0814	210B	22		S	23-31-14	050-099, 150-199
SP03598		418/305/L048					150-199
	W0814	848	20		S	26-13-11	150-157
	W0814	848	20		9	26-13-11	162-199
	W0820	102	20		S	26-13-11	150-157
	W0820	102	20		9	26-13-11	162-199

SPLICE LIST

D280T132

91-21-31

Section SP03500

Page 2 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03600		418/305/L048					150-199
	W0814	847	20		S	26-13-11	150-157
	W0814	847	20		9	26-13-11	162-199
	W0820	103	20		S	26-13-11	150-157
	W0820	103	20		9	26-13-11	162-199
SP03602		0418/305/L048					150-199
	W0792	153	20		9	26-13-11	150-199
	W0820	104	20		9	26-13-11	150-199
SP03604		0418/305/L048					150-199
	W0792	154	20		9	26-13-11	150-199
	W0814	849	20		9	26-13-11	150-199
	W0820	083	20		9	26-13-12	162-199
	W0820	105	20		9	26-13-11	150-199
SP03606		418/305/L048					150-199
	W0792	155	20		9	26-13-11	150-199
	W0814	850	20		9	26-13-11	150-199
	W0820	081	20		9	26-13-12	162-199
	W0820	106	20		9	26-13-11	150-199
SP03608		0418/305/L048					150-199
	W0792	156	20		9	26-13-11	150-199
	W0814	851	20		9	26-13-11	150-199
	W0820	082	20		9	26-13-12	162-199
	W0820	107	20		9	26-13-11	150-199
SP03610		0764/295/R060					150-199
	W0792	159	20		9	26-13-11	150-199
	W0814	842	20		9	26-13-11	150-199
SP03612		0764/295/R060					150-199
	W0792	160	20		9	26-13-11	150-199
	W0814	843	20		9	26-13-11	150-199
SP03614		0764/295/R060					150-199
	W0792	167	20		9	26-13-11	150-199
	W0814	837	20		9	26-13-11	150-199
	W0814	844	20		9	26-13-11	150-199

SPLICE LIST

D280T132

91-21-31

Section SP03600

Page 1

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03616		0764/295/R060					150-199
	W0792	168	20		9	26-13-11	150-199
	W0814	838	20		9	26-13-11	150-199
	W0814	845	20		9	26-13-11	150-199
SP03618		0764/295/R060					150-199
	W0792	157	20		9	26-13-11	150-199
	W0814	839	20		9	26-13-11	150-199
	W0814	846	20		9	26-13-11	150-199
SP03622		0764/295/R060					150-199
	W0792	197	20		9	33-26-21	150-199
	W0814	812	20		9	33-26-21	150-199
SP03624		0764/295/R060					150-199
	W0792	190	20		9	33-26-21	150-199
	W0814	884	20		9	33-26-21	150-199
SP03626		0764/295/R060					150-199
	W0792	007	20		9	33-26-21	150-199
	W0792	008	20		9	33-26-21	150-199
	W0792	188	20		9	33-26-21	150-199
	W0814	882	20		9	33-26-21	150-199
SP03628		0764/295/R060					150-199
	W0792	170	22		9	33-25-11	150-199
	W0792	171	22		9	33-25-11	150-199
	W0814	821	22		9	33-25-11	150-199
SP03632		418/305/L048					150-199
	W0792	177	20		9	33-26-11	150-199
	W0814	002	22		9	33-26-11	150-199
SP03634		0764/295/R060					150-199
	W0792	176	20		9	33-26-11	150-199
	W0792	178	20		9	33-26-11	150-199
	W0812	017	20		9	33-26-11	150-199
	W0812	894	20		9	33-26-11	150-199

SPLICE LIST
D280T132

91-21-31
Section SP03600
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03636		1540/190/R030					ALL
	W0966	056	20		9	38-32-11	ALL
	W1354	056	20		9	38-32-11	ALL
SP03638		0350/284/L035					050-099, 150-199
	W0428	013	20		S	35-21-12	050-099, 150-199
	W0714	005	20		S	35-21-12	050-099
	W0714	039	20		S	35-21-12	150-199
SP03640		354/280/R032					050-099, 150-199
	W0222	169	20		S	35-21-13	050-099, 150-199
	W0714	040	20		S	35-21-13	050-099, 150-199
SP03642		0674/194/L062					150-199
	W1258	017	22		9	30-71-22	150-154
	W1258	017	20		9	30-71-22	155-199
	W1258	T-G			9	30-71-22	150-199
SP03644		0674/194/L062					150-199
	W1258	027	20		9	30-71-22	150-199
	W1258	T-H			9	30-71-22	150-199
SP03646		0408/192/L069					050-099, 150-199
	W1258	183	20		9	30-71-21	050-099, 150-199
	W1258	K-C			9	30-71-21	050-099, 150-199
SP03648		0401/176/L070					050-099, 150-199
	W1258	184	20		9	30-71-21	050-099, 150-199
	W1258	L-C			9	30-71-21	050-099, 150-199
SP03650		0401/176/L070					050-099, 150-199
	W1258	185	20		9	30-71-21	050-099, 150-199
	W1258	M-C			9	30-71-21	050-099, 150-199
SP03652		0401/176/L070					050-099, 150-199
	W1258	187	20		9	30-71-21	050-099, 150-199
	W1258	R-C			9	30-71-21	050-099, 150-199
SP03654		0674/162/L072					150-199
	W1258	188	20		9	30-71-21	150-199

SPLICE LIST
D280T132

91-21-31
Section SP03600
Page 3
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03654		0674/162/L072 (continued)					150-199
	W1258	S-C			9	30-71-21	150-199
SP03658		1439/310/L020					050-099, 150-199
	W0216	050	20		S	25-31-31	050-099, 150-199
	W0304	007	20		S	25-31-31	050-099, 150-199
SP03660		1439/310/L020					050-099, 150-199
	W0216	049	20		S	25-31-31	050-099, 150-199
	W0304	001	24		S	25-31-31	050-099, 150-199
SP03662		1439/310/L020					050-099, 150-199
	W0216	048	20		S	25-31-31	050-099, 150-199
	W0304	002	24		S	25-31-31	050-099, 150-199
SP03664		1439/310/L020					050-099, 150-199
	W0216	047	20		S	25-31-31	050-099, 150-199
	W0304	003	24		S	25-31-31	050-099, 150-199
SP03666		1439/310/L020					050-099, 150-199
	W0216	046	20		S	25-31-31	050-099, 150-199
	W0304	004	24		S	25-31-31	050-099, 150-199
SP03668		0764/295/R060					150-199
	W0792	095	20		9	33-26-11	150-199
	W0792	671	22		9	33-26-11	150-199
	W0814	805	22		9	33-26-11	150-199
	W0814	888	20		9	33-26-11	150-199
SP03672		0375/300/L056					150-199
	W0812	904	20		9	33-26-21	150-199
	W0814	810	20		9	33-26-21	150-199
SP03674		375/300/L056					150-199
	W0812	905	20		9	33-26-21	150-199
	W0814	811	20		9	33-26-21	150-199
SP03676		0764/295/R060					150-199
	W0792	003	20		9	33-26-21	150-199
	W0814	809	20		9	33-26-21	150-199

SPLICE LIST
D280T132

91-21-31
Section SP03600
Page 4
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03678		P037-00/ /					150-199, 275-276
	W1118	A-A			Y	21-26-31	150-199, 275-276
SP03680		P037-00/ /					ALL
	W1118	11R	20		W	21-26-31	ALL
	W1118	A-C			W	21-26-31	ALL
SP03682		P037-00/ /					ALL
	W1118	11U	24		W	21-26-31	ALL
	W1118	A-E			W	21-26-31	ALL
SP03684		P037-00/ /					ALL
	W1118	11S	20		W	21-26-31	ALL
	W1118	A-F			W	21-26-31	ALL
SP03686		1490/190/R070					050-099, 155-199, 275-299
	W0580	031	20		9	38-32-11	050-099, 155-199, 277-299
	W0580	031	20		9	SPARE	276
	W0580	055	22		9	38-32-14	275-276
	W0966	060	20		9	38-32-11	050-099, 155-199, 277-299
	W0966	060	20		9	38-32-14	275-276
SP03687		0368/195/L020					050-099
	W1256	602	16		9	30-71-24	050-099
	W1258	618	16		9	30-71-24	050-099
SP03688		335/192/R055					150-199
	W1256	602	16		9	30-71-24	150-199
	W1258	618	16		9	30-71-24	150-199
SP03690							ALL
	W0446	303R	18		9	31-31-25	ALL
	W0446	303Y	18		9	31-31-25	ALL
	W0446	303Z				31-31-25	ALL
	W0446	A-E			9	31-31-25	ALL
	W0446	FRD				31-31-25	ALL
SP03692							ALL
	W0446	303B	18		9	31-31-25	ALL
	W0446	A-F			9	31-31-25	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03694		905/305/R030					150-199
	W0814	190	22		9	33-25-11	150-199
	W0814	855	22		9	33-25-11	150-199
	W0828	028	22		9	33-25-11	150-199
	W0828	119	22		9	33-25-11	150-199
SP03696		0905/305/R030					150-199
	W0665	179	22		9	33-25-11	150-199
	W0665	191	22		9	33-25-11	155, 157
	W0792	068	22		9	33-25-11	150-199
	W0792	503	22		9	33-25-11	150-199
SP03698		1439/310/L020					050-099
SP03698		905/305/R030					150-199
	W0665	020	22		S	33-25-11	050-099, 150-199
	W0665	023	22		S	33-25-11	050-099, 150-199
	W0792	501	22		S	33-25-11	150-199
	W0828	029	22		S	33-25-11	050-099, 150-199
	W0828	611	22		S	33-25-11	050-099



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03700		354/280/R032					050-099, 150-199
	W0665	019	22		S	33-25-11	050-099, 150-199
	W0665	107	22		S	33-25-11	050-099, 150-199
	W0820	016	22		S	33-25-11	050-099, 150-199
SP03702		0764/295/R060					150-199
	W0665	087	24		9	33-25-11	150-199
	W0665	198	24		9	33-25-11	150-199
	W0792	174	22		9	33-25-11	150-199
	W0814	818	22		9	33-25-11	150-199
	W0814	823	22		9	33-25-11	150-199
SP03704		0764/295/R060					150-199
	W0792	037	20		9	33-26-21	150-199
	W0792	191	20		9	33-26-21	150-199
	W0792	193	20		9	33-26-21	150-199
	W0792	194	20		9	33-26-21	150-199
	W0814	623	20		9	33-26-21	150-199
SP03720		0764/295/R060					150-199
	W0792	644	20		9	33-26-21	150-199
	W0812	906	20		9	33-26-21	150-199
SP03722		0764/295/R060					150-199
	W0792	645	20		9	33-26-21	150-199
	W0812	908	20		9	33-26-21	150-199
SP03728		0347/270/L055					275-299
	W1198	006	18		9	33-22-31	275-299
	W1198	A-B			9	33-22-31	275-299
SP03730		0347/270/L055					275-299
	W1198	005	18		9	33-22-31	275-299
	W1198	A-A			9	33-22-31	275-299
SP03774		0175/234/L036					ALL
	W0584	017	20		W	33-13-11	ALL
	W0584	031	18		W	33-13-11	ALL
	W0629	027	18		W	33-13-11	ALL



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03776		0175/234/L036					ALL
	W0584	032	18		W	33-13-11	ALL
	W0629	028	18		W	33-13-11	ALL
SP03778		0175/234/R036					ALL
	W0586	025	20		W	33-13-13	ALL
	W0586	044	18		W	33-13-13	ALL
	W0631	027	18		W	33-13-13	ALL
SP03780		0175/234/R036					050-099, 150-156, 162-166, 275-276
	W0586	045	18		W	33-13-13	050-099, 150-156, 162-166, 275-276
	W0631	028	18		W	33-13-13	050-099, 150-156, 162-166, 275-276
SP03790		1439/310/L020					050-099, 150-199
	W0216	051	18		9	30-71-25	050-099, 150-199
	W0216	053	18		9	30-71-25	050-099, 150-199
	W0304	016	18		9	30-71-25	050-099, 150-199

SPLICE LIST

D280T132

91-21-31

Section SP03700

Page 2 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03814		0764/295/R060					150-199
	W0792	666	20		S	38-32-13	150-156, 162-165
	W0792	666	20		S	38-32-16	157, 166-199
	W0814	682	20		S	38-32-13	150-156, 162-165
	W0814	682	20		S	38-32-16	157, 166-199
	W0814	688	22		S	38-32-13	150-156, 162-165
	W0814	688	22		S	38-32-16	157, 166-199
SP03816		0764/295/R060					150-199
	W0792	669	20		S	38-32-13	150-156, 162-165
	W0792	669	20		S	38-32-16	157, 166-199
	W0814	679	20		S	38-32-13	150-156, 162-165
	W0814	679	20		S	38-32-16	157, 166-199
	W0814	689	22		S	38-32-13	150-156, 162-165
	W0814	689	22		S	38-32-16	157, 166-199
SP03818		0764/295/R060					150-199
	W0792	144	20		S	38-32-12	150-156, 162-165
	W0792	144	20		S	38-32-16	157, 166-199
	W0792	146	18		S	38-32-12	150-156, 162-165
	W0792	146	18		S	38-32-16	157, 166-199
	W0814	893	18		S	38-32-12	150-156, 162-165
	W0814	893	18		S	38-32-16	157, 166-199
SP03819		0764/295/R060					150-199
	W0792	050	20		S	38-32-12	150-156, 162-165
	W0792	050	20		S	38-32-16	157, 166-199
	W0792	114	20		S	38-32-12	150-156, 162-165
	W0792	114	20		S	38-32-16	157, 166-199
	W0792	145	20		S	38-32-12	150-156, 162-165
	W0792	145	20		S	38-32-16	157, 166-199
	W0814	894	22		S	38-32-12	150-155, 162-165
	W0814	894	22		S	38-32-16	156-157, 166-199
SP03870		315/190/L050					ALL
	W0942	320B	24		S	21-64-11	ALL
	W1246	320B	24		S	21-64-11	ALL
SP03872		315/190/L050					ALL
	W0942	320R	24		S	21-64-11	ALL
	W1246	320R	24		S	21-64-11	ALL

SPLICE LIST
D280T132



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL	GA	CO	Type	Diagram	Effectivity
		Wire No.					
SP03874		315/190/L050					ALL
	W0942	320Y	24		S	21-64-11	ALL
	W1246	320Y	24		S	21-64-11	ALL
SP03876		315/190/L050					ALL
	W0942	327B	24		S	21-64-11	ALL
	W1246	327B	24		S	21-64-11	ALL
SP03878		315/190/L050					ALL
	W0942	327Y	24		S	21-64-11	ALL
	W1246	327Y	24		S	21-64-11	ALL
SP03880		315/190/L050					ALL
	W0942	327R	24		S	21-64-11	ALL
	W1246	327R	24		S	21-64-11	ALL
SP03898		1439/310/L020					050-099, 150-199
	W0216	103	20		9	33-24-12	050-099, 150-199
	W0810	701	20		9	33-24-12	050-099, 150-199

SPLICE LIST

D280T132

91-21-31

Section SP03800

Page 2 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03900		1439/310/L020					050-099, 150-199
	W0216	104	20		9	33-24-12	050-099, 150-199
	W0810	700	20		9	33-24-12	050-099, 150-199
SP03902		0354/280/R032					050-099, 150-199
	W0222	603	20		S	33-24-14	050-099, 150-199
	W1230	604	20		S	33-24-14	050-099, 150-199
SP03904		0354/280/R032					050-099, 150-199
	W0222	604	20		S	33-24-14	050-099, 150-199
	W1230	605	20		S	33-24-14	050-099, 150-199
SP03906		0764/295/R060					150-199
	W0792	672	22		9	33-26-11	150-199
	W0814	863	22		9	33-26-11	150-199
	W0814	887	18		9	33-26-11	150-199
	W0814	890	22		9	33-26-11	150-199
SP03908		0764/295/R060					150-199
	W0792	673	22		9	33-26-11	150-199
	W0814	181	22		9	33-26-11	150-199
	W0814	860	22		9	33-26-11	150-199
	W0814	870	22		9	33-26-11	150-199
	W0814	871	22		9	33-26-11	150-199
SP03910		0764/295/R060					150-199
	W0792	046	22		9	33-26-11	150-199
	W0814	897	18		9	33-26-11	150-199
SP03932		0764/178/L062					275-299
	W1258	629	22		9	30-71-22	275-299
	W1258	B-Y			9	30-71-22	275-299
SP03934		0764/178/L062					275-299
	W1258	630	22		9	30-71-22	275-299
	W1258	C-N			9	30-71-22	275-299
SP03936		0786/184/L023					275-299
	W1258	631	22		9	30-71-22	275-299
	W1258	C-O			9	30-71-22	275-299

SPLICE LIST
D280T132

91-21-31
Section SP03900
Page 1
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03938		0786/178/L059					275-299
	W1258	632	22		9	30-71-22	275-299
	W1258	C-P			9	30-71-22	275-299
SP03940		0764/178/L062					275-299
	W1258	633	20		9	30-71-22	275-299
	W1258	C-Q			9	30-71-22	275-299
SP03942		0786/187/R020					275-299
	W1258	634	20		9	30-71-22	275-299
	W1258	C-R			9	30-71-22	275-299
SP03944		0786/184/L023					275-299
	W1258	635	20		9	30-71-22	275-299
	W1258	C-S			9	30-71-22	275-299
SP03946		0786/184/L023					275-299
	W1258	636	20		9	30-71-22	275-299
	W1258	C-T			9	30-71-22	275-299
SP03956		0408/192/L069					050-099, 150-199
	W1258	639	20		9	30-71-21	050-099, 150-199
	W1258	K-D			9	30-71-21	050-099, 150-199
SP03958		0401/176/L070					050-099, 150-199
	W1258	640	20		9	30-71-21	050-099, 150-199
	W1258	L-D			9	30-71-21	050-099, 150-199
SP03960		0401/176/L070					050-099, 150-199
	W1258	641	20		9	30-71-21	050-099, 150-199
	W1258	M-D			9	30-71-21	050-099, 150-199
SP03962		0401/176/L070					050-099, 150-199
	W1258	642	20		9	30-71-21	050-099, 150-199
	W1258	R-D			9	30-71-21	050-099, 150-199
SP03973		0674/162/L072					150-199
	W1258	643	20		9	30-71-21	150-199
	W1258	S-D			9	30-71-21	150-199

SPLICE LIST
D280T132

91-21-31
Section SP03900
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03974		0246/192/L063					050-099, 155-199
	W1258	211	20		9	30-71-21	155-199
	W1258	646	20		9	30-71-21	050-099
	W1258	C-U			9	30-71-21	050-099, 155-199
SP03978		0654+64/196/L067					150-199
	W1258	644	20		9	30-71-21	150-199
	W1258	B-R			9	30-71-21	150-199
SP03984		0375/300/L056					150-199
	W1224	816	22		9	33-22-41	150-199
	W1230	103	22		9	33-22-41	150-199
SP03986		1540/190/R030					156-157, 166-199, 275-299
	W0966	082	22		S	38-32-11	156-157, 166-199
	W0966	082	22		9	38-32-11	275-299
	W0966	082Z				38-32-11	156-157, 166-199, 275-299
	W1354	043	22		S	38-32-11	156-157, 166-199
	W1354	043	22		9	38-32-11	275-299
SP03988		1439/190/L090					157, 166-199, 277-299
	W0578	054	18		9	38-32-11	157, 277-299
	W0578	054	18		S	38-32-11	166-199
	W0828	017	18		9	38-32-16	157
	W0828	017	18		S	38-32-16	166-199
	W0828	130	18		9	38-32-16	157
	W0828	130	18		S	38-32-16	166-199
	W1276	015	18		9	38-32-16	277-299
	W1276	019	18		9	38-32-16	277-299
SP03992		1439/310/L020					050-099
	W0665	071	22		S	33-25-11	050-099
	W0828	607	22		S	33-25-11	050-099
SP03994		1097/188/L072					050-099
	W1258	652	20		9	30-71-22	050-099
	W1258	D-M			9	30-71-22	050-099
SP03996		0786/178/L059					050-099
	W1258	648	20		9	30-71-22	050-099

SPLICE LIST
D280T132



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP03996		0786/178/L059 (continued)					050-099
	W1258	U-G			9	30-71-22	050-099
SP03998		1097/188/L072					050-099
	W1258	653	20		9	30-71-22	050-099
	W1258	D-O			9	30-71-22	050-099



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP04000		0786/197/R060					050-099
	W1258	649	20		9	30-71-22	050-099
	W1258	D-I			9	30-71-22	050-099
SP04002		1090/197/L071					050-099
	W1258	651	20		9	30-71-22	050-099
	W1258	D-K			9	30-71-22	050-099
SP04006		1360/164/L072					050-099
SP04006		1300/164/L072					277-299
	W1258	057	22		9	30-71-23	277-299
	W1258	655	20		9	30-71-24	050-099
	W1258	D-R			9	30-71-24	050-099
	W1258	D-R			9	30-71-23	277-299
SP04008		1300/176/L065					050-099
SP04008		1300/164/L072					277-299
	W1258	657	20		9	30-71-24	050-099
	W1258	657	20		9	30-71-23	277-299
	W1258	D-S			9	30-71-24	050-099
	W1258	D-S			9	30-71-23	277-299
SP04010		0786/174/L062					150-199
	W1258	658	20		9	30-71-22	150-199
	W1258	X-H			9	30-71-22	150-199
SP04040		1572/140/BL 5					050-099, 155-199, 275-299
SP04040		1570/140/BL 5					150-154
	W1354	046	22		9	38-32-11	050-099, 150-155, 162-165
	W1354	046	22		9	38-32-15	156-157, 166-199, 277-299
	W1354	046	22		9	38-32-14	275-276
	W1354	A-F			9	38-32-11	050-099, 150-155, 162-165
	W1354	A-F			9	38-32-15	156-157, 166-199, 277-299
	W1354	A-F			9	38-32-14	275-276
SP04042		1572/140/BL 5					050-099, 155-199, 275-299
SP04042		1570/140/BL 5					150-154
	W1354	047	22		9	38-32-11	050-099, 150-155, 162-165
	W1354	047	22		9	38-32-15	156-157, 166-199, 277-299
	W1354	047	22		9	38-32-14	275-276

SPLICE LIST

D280T132

91-21-31

Section SP04000

Page 1

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP04042		1572/140/BL 5 (continued)					050-099, 155-199, 275-299
SP04042		1570/140/BL 5 (continued)					150-154
	W1354	A-G			9	38-32-11	050-099, 150-155, 162-165
	W1354	A-G			9	38-32-15	156-157, 166-199, 277-299
	W1354	A-G			9	38-32-14	275-276
SP04044		1572/140/BL 5					050-099, 155-199, 275-299
SP04044		1570/140/BL 5					150-154
	W1354	048	20		9	38-32-11	050-099, 150-155, 162-165
	W1354	048	20		9	38-32-15	156-157, 166-199, 277-299
	W1354	048	20		9	38-32-14	275-276
	W1354	A-H			9	38-32-11	050-099, 150-155, 162-165
	W1354	A-H			9	38-32-15	156-157, 166-199, 277-299
	W1354	A-H			9	38-32-14	275-276
SP04046		1572/144/0000					ALL
	W0966	086	22		9	38-32-11	050-099, 150-155, 162-165
	W0966	086	22		9	38-32-15	156-157, 166-199, 277-299
	W0966	086	22		9	38-32-14	275-276
	W0966	A-F			9	38-32-11	050-099, 150-155, 162-165
	W0966	A-F			9	38-32-15	156-157, 166-199, 277-299
	W0966	A-F			9	38-32-14	275-276
SP04048		1572/144/0000					ALL
	W0966	087	22		9	38-32-11	050-099, 150-155, 162-165
	W0966	087	22		9	38-32-15	156, 166
	W0966	087	20		9	38-32-15	157, 167-199, 277-299
	W0966	087	20		9	38-32-14	275-276
	W0966	A-H			9	38-32-11	050-099, 150-155, 162-165
	W0966	A-H			9	38-32-15	156-157, 166-199, 277-299
	W0966	A-H			9	38-32-14	275-276
SP04050		1572/144/0000					ALL
	W0966	088	22		9	38-32-11	050-099, 150-155, 162-165
	W0966	088	22		9	38-32-15	156-157, 166-199, 277-299
	W0966	088	22		9	38-32-14	275-276
	W0966	A-G			9	38-32-11	050-099, 150-155, 162-165
	W0966	A-G			9	38-32-15	156-157, 166-199, 277-299
	W0966	A-G			9	38-32-14	275-276



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP04052		0654+84/284/R025					275-277
	W0822	094	20		9	33-21-11	275-277
	W0822	A-I			9	33-21-11	275-277
SP04056		0335/192/R055					ALL
	W0764	091	16		9	73-21-11	050-099, 155-199, 277-299
	W0764	091	16		S	73-21-11	150-154, 275-276
	W0764	091Z			V	73-21-11	ALL
	W0768	030	16		9	73-21-11	050-099, 155-199, 277-299
	W0768	030	16		S	73-21-11	150-154, 275-276
	W0768	030Z			V	73-21-11	050-099, 155-199, 275-299
	W0768	030Z			S	73-21-11	150-154
SP04058		P036-00/ /					050-099, 162-199
	W0176	29A	22		W	21-66-11	050-099, 162-199
	W0176	A-I			W	21-66-11	050-099, 162-199
SP04060		P036-00/ /					050-099, 162-199
	W0176	40A	20		W	21-66-11	050-099, 162-199
	W0176	A-O			W	21-66-11	050-099, 162-199
SP04062		P036-00/ /					050-099, 162-199
	W0176	45A	20		W	21-66-11	050-099, 162-199
	W0176	A-T			W	21-66-11	050-099, 162-199
SP04064		P036-00/ /					050-099, 162-199
	W0176	42A	22		W	21-66-11	050-099, 162-199
	W0176	A-S			Y	21-66-11	050-099, 162-199
	W0176	A-U			W	21-66-11	050-099, 162-199
SP04066		P037-00/ /					050-099, 162-199
	W0058	076	22		W	21-66-21	050-099, 162-199
	W0192	A-I			W	21-66-21	050-099, 162-199
SP04068		P037-00/ /					050-099, 162-199
	W0192	74X	20		W	21-66-21	050-099, 162-199
	W0192	A-O			W	21-66-21	050-099, 162-199
SP04070		P037-00/ /					050-099, 162-199
	W0192	74Y	20		W	21-66-21	050-099, 162-199

SPLICE LIST
D280T132



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP04070		P037-00/ / (continued)					050-099, 162-199
	W0192	A-P			W	21-66-21	050-099, 162-199
SP04072		P037-00/ /					050-099, 162-199
	W0192	74N	22		W	21-66-21	050-099, 162-199
	W0192	A-Q			W	21-66-21	050-099, 162-199
SP04074		P036-00/ /					050-099, 150, 152-199
	W0056	078	22		W	21-66-31	050-099, 150, 152-199
	W0176	B-I			W	21-66-31	050-099, 150, 152-199
SP04076		P036-00/ /					050-099, 150, 152-199
	W0176	48E	20		W	21-66-31	050-099, 150, 152-199
	W0176	B-H			W	21-66-31	050-099, 150, 152-199
SP04078		P036-00/ /					050-099, 150, 152-199
	W0176	49E	20		W	21-66-31	050-099, 150, 152-199
	W0176	B-L			W	21-66-31	050-099, 150, 152-199
SP04080		P036-00/ /					050-099, 150, 152-199
	W0176	40E	22		W	21-66-31	050-099, 150, 152-199
	W0176	B-M			Y	21-66-31	050-099
	W0176	B-M			W	21-66-31	150, 152-199
	W0176	B-N			W	21-66-31	050-099
	W0176	B-N			Y	21-66-31	150, 152-199
SP04082		P037-00/ /					050-099, 150, 152-199
	W0058	085	22		W	21-66-41	050-099, 150, 152-199
	W0192	A-S			W	21-66-41	050-099, 150, 152-199
SP04084		P037-00/ /					050-099, 150, 152-199
	W0192	75V	20		W	21-66-41	050-099, 150, 152-199
	W0192	A-T			W	21-66-41	050-099, 150, 152-199
SP04086		P037-00/ /					050-099, 150, 152-199
	W0192	75W	20		W	21-66-41	050-099, 150, 152-199
	W0192	A-U			W	21-66-41	050-099, 150, 152-199
SP04088		P037-00/ /					050-099, 150, 152-199
	W0192	75M	22		W	21-66-41	050-099, 150, 152-199

SPLICE LIST
D280T132

91-21-31
Section SP04000
Page 4
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP04088		P037-00/ / (continued)					050-099, 150, 152-199
	W0192	A-V			W	21-66-41	050-099, 150, 152-199
SP04090		0547/150/L080					050-099, 162-199
	W1230	205B	22		S	21-66-11	050-099, 162-199
	W1230	A-B			S	21-66-11	050-099, 162-199
SP04092		0547/150/L080					050-099, 162-199
	W1230	205R	22		S	21-66-11	050-099, 162-199
	W1230	B-A			S	21-66-11	050-099, 162-199
SP04096		P008-00/ /					ALL
	W0264	204B	16		9	33-13-18	156-157, 166-199, 277-299
	W0632	132	18		9	33-13-18	156-157, 166-199, 277-299
	W0711	221B	20		9	33-13-18	156-157, 166-199, 277-299
	W0847	203B	18		9	33-13-18	277-299
	W0847	203R	18		9	33-13-18	156-157, 166-199
SP04098		P008-00/ /					050-099, 156-157, 166-199, 277-299
SP04098		P010-00/ /					155, 164-165
	W0632	131	18		9	33-13-18	156-157, 166-199, 277-299
	W0685	203B	20		9	33-13-18	156-157, 166-199, 277-299
	W0756	290B	20		9	33-13-18	156-157, 166-199, 277-299
	W0756	291B	20		9	33-13-18	156-157, 166-199, 277-299

SPLICE LIST

D280T132

91-21-31

Section SP04000

Page 5 End

Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05000		P010-00/ /					155, 164-165
SP05000		P008-00/ /					156-157, 166-199, 277-299
	W0483	208B	18		9	33-13-18	156-157, 166-199, 277-299
	W0615	204B	18		9	33-13-18	156-157, 166-199, 277-299
	W0629	206B	18		9	33-13-18	156-157, 166-199, 277-299
	W0632	135B	12		9	33-13-18	156-157, 166-199, 277-299
	W0843	204B	18		9	33-13-18	156-157, 166-199, 277-299
SP05004		P008-00/ /					150, 152-199, 275-299
SP05004		P010-00/ /					155, 164-165
	W0614	201B	20		9	33-13-18	156-157, 166-199, 277-299
	W0632	134	18		9	33-13-18	156-157, 166-199, 277-299
	W0779	225B	20		9	33-13-18	156-157, 166-199, 277-299
	W0851	214B	20		9	33-13-18	275-299
	W0851	907B	20		9	23-22-12	156-157, 166-199
SP05008		P010-00/ /					155, 164-165
SP05008		0190/190/L046					156-157, 166-199, 277-299
	W0614	203B	18		9	33-13-18	156-157, 166-199, 277-299
	W0632	136B	18		9	33-13-18	156-157, 166-199, 277-299
SP05010		P010-00/ /					155, 164-165
SP05010		0190/190/L046					156-157, 166-199, 277-299
	W0631	205B	18		9	33-13-18	156-157, 166-199, 277-299
	W0632	138B	18		9	33-13-18	156-157, 166-199, 277-299
	W0845	203B	18		9	33-13-18	156-157, 166-199, 277-299
SP05062		0880/240/L090					050-099, 155-199, 276-299
SP05062		0871/230/L089					150-154, 275
	W1398	001	20		9	21-45-22	ALL
	W1398	A-A			9	21-45-22	ALL
SP05064		0880/240/L090					050-099, 155-199, 276-299
SP05064		0871/230/L089					150-154, 275
	W1398	002	20		9	21-45-22	ALL
	W1398	A-B			9	21-45-22	ALL
SP05066		0880/240/R090					050-099, 155-199, 276-299
SP05066		0871/230/R089					150-154, 275
	W1400	001	20		9	21-45-22	ALL

SPLICE LIST

D280T132

91-21-31

Section SP05000

Page 1

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05066		0880/240/R090 (continued)					050-099, 155-199, 276-299
SP05066		0871/230/R089 (continued)					150-154, 275
	W1400	A-A			9	21-45-22	ALL
SP05068		0880/240/R090					050-099, 155-199, 276-299
SP05068		0871/230/R089					150-154, 275
	W1400	002	20		9	21-45-22	ALL
	W1400	A-B			9	21-45-22	ALL
SP05070		0924/240/L090					150-199, 275-299
	W1498	001	20		9	21-45-22	150-199, 275-299
	W1498	A-A			9	21-45-22	150-199, 275-299
SP05072		0924/240/L090					150-199, 275-299
	W1498	002	20		9	21-45-22	150-199, 275-299
	W1498	A-B			9	21-45-22	150-199, 275-299
SP05074		0924/240/R090					150-199, 275-299
	W1500	001	20		9	21-45-22	150-199, 275-299
	W1500	A-A			9	21-45-22	150-199, 275-299
SP05076		0924/240/R090					150-199, 275-299
	W1500	002	20		9	21-45-22	150-199, 275-299
	W1500	A-B			9	21-45-22	150-199, 275-299
SP05080		1090/185/L071					050-099
	W1258	509	20		9	30-71-22	050-099
	W1258	D-L			9	30-71-22	050-099
SP05086		1008/183/R041					155-157, 166-199, 277-299
	W0464	304R	20		9	27-18-11	155-157, 166-199, 277-299
	W0738	513	20		9	27-18-11	155-157, 166-199, 277-299
SP05088		1008/183/L041					155-157, 166-199, 277-299
	W0446	305R	20		9	27-18-11	155-157, 166-199, 277-299
	W0942	589	20		9	27-18-11	155-157, 166-199, 277-299
SP05090		1790/260/L040					155, 157, 167-199, 277-299
	W0502	025	20		9	27-38-11	157, 167-199, 277-299
	W0514	006	20		9	27-38-11	155, 157, 167-199, 277-299

SPLICE LIST
D280T132

91-21-31
Section SP05000
Page 2
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05092		1790/260/L040					155, 157, 167-199, 277-299
	W0502	026	20		9	27-38-11	157, 167-199, 277-299
	W0514	007	20		9	27-38-11	155, 157, 167-199, 277-299

SPLICE LIST

D280T132

91-21-31

Section SP05000

Page 3 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05244		0705/284/R050					280-299
	W0812	02V	20		9	33-21-11	280-299
	W0812	02W	20		9	33-21-11	280-299
SP05246		0705/284/R050					280-299
	W0812	02U	20		9	33-21-11	280-299
	W0812	02X	20		9	33-21-11	280-299
SP05252		0746/284/R050					280-299
	W0812	760	20		9	33-21-11	280-299
	W0812	774	20		9	33-21-11	280-299
SP05254		0746/284/R050					280-299
	W0812	761	20		9	33-21-11	280-299
	W0812	773	20		9	33-21-11	280-299
SP05298		0654+28/117/0000					277-299
	W0942	595	24		9	21-28-11	277-299
	W1258	609	24		9	21-28-11	277-299

SPLICE LIST
D280T132

91-21-31
Section SP05200
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05300		0654+28/117/0000					277-299
	W0942	596	24		9	21-28-11	277-299
	W1258	607	24		9	21-26-31	277-299
SP05306		1400/290/R080					280-299
	W0304	036	18		S	SPARE	280-299
	W1240	136	18		S	SPARE	280-299
SP05308		1400/290/R080					280-299
	W0216	087	18		S	SPARE	280-299
	W1240	072	18		S	SPARE	280-299
SP05398		1450/190/R070					275-276
	W0580	053	22		9	38-32-14	275-276
	W0966	501	22		9	38-32-14	275-276
	W0966	501Z				38-32-14	275-276

SPLICE LIST

D280T132

91-21-31

Section SP05300

Page 1 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05400		1450/190/R070					275-276
	W0580	054	22		9	38-32-14	275-276
	W0966	502	22		9	38-32-14	275-276
SP05402		1540/190/R030					275-276
	W0966	502	22		9	38-32-14	275-276
	W1354	052	22		9	38-32-14	275-276
SP05428		1490/190/R070					156-157, 166-199, 277-299
	W0580	058	20		9	38-32-15	156-157, 166-199, 277-299
	W0966	089	20		9	38-32-15	156-157, 166-199, 277-299
SP05430		1490/190/R070					156-157, 166-199, 277-299
	W0580	057	20		9	38-32-15	156-157, 166-199, 277-299
	W0966	055	20		9	38-32-15	156-157, 166-199, 277-299
	W0966	086	22		9	38-32-15	156-157, 166-199, 277-299
SP05436		1540/190/R030					150-199, 275-299
	W0580	060	20		9	38-32-15	156-157, 166-199, 277-299
	W0580	060Z				38-32-15	156-157, 166-199, 277-299
	W1354	007	20		9	38-32-15	156-157, 166-199, 277-299
SP05440		0730/190/R045					050-099
SP05442		1450/190/R070					275-276
	W0966	055	20		9	38-32-14	275-276
	W0966	086	22		9	38-32-14	275-276
	W1358	045	18		9	38-32-14	275-276
SP05444		1450/190/R070					275-276
	W0966	089	20		9	38-32-14	275-276
	W1358	044	18		9	38-32-14	275-276

SPLICE LIST

D280T132

91-21-31

Section SP05400

Page 1 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP05582		0784/184/R008					150-199, 275-299

SPLICE LIST

D280T132

91-21-31

Section SP05500

Page 1 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP07128		TBD/ /					275-299
	W0578	134	12		9	21-73-11	275-299
	W1232	557	12		9	21-73-11	275-299
SP07130		TBD/ /					275-299
	W0578	135	12		9	21-73-11	275-299
	W1232	558	12		9	21-73-11	275-299
SP07132		TBD/ /					275-299
	W0578	136	12		9	21-73-11	275-299
	W1232	559	12		9	21-73-11	275-299

SPLICE LIST
D280T132

91-21-31
Section SP07100
Page 1 End
Jan 21/2005



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL	GA	CO	Type	Diagram	Effectivity
		Wire No.					
SP09003		190/190/L046					150, 152-199, 275-299
	W0731	051	20		9	34-43-11	150, 152-199, 275-299
	W9090	905	22		9	34-46-13	150, 152-199, 275-299
SP09004		190/190/L046					150, 152-199, 275-299
	W0733	051	20		9	34-43-11	150, 152-199, 275-299
	W9090	914	22		9	34-46-13	150, 152-199, 275-299
SP09005		190/190/L046					150, 152-199, 275-299
	W0803	012	24		W	34-43-22	150, 152-199, 275-299
	W0803	901	24		W	34-43-22	150, 152-199, 275-299
	W9090	907	22		W	34-46-13	150, 152-199, 275-299

SPLICE LIST

D280T132

91-21-31

Section SP09000

Page 1 End

Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP09571		N 145/160/					ALL
	W0352	101	20		8	78-36-11	050-099, 150-199, 275-278
	W0352	101Z			V	78-36-11	050-099, 150-199, 275-278
	W0372	101	20		8	78-36-11	ALL
	W0372	101Z			V	78-36-11	ALL
SP09573		N 145/160/					ALL
	W0352	103	20		8	78-36-11	050-099, 150-199, 275-278
	W0352	103Z			V	78-36-11	050-099, 150-199, 275-278
	W0372	102	20		8	78-36-11	ALL
	W0372	102Z			V	78-36-11	ALL
SP09575		N 145/160/					ALL
	W0352	215B	20		8	78-36-11	050-099, 150-199, 275-278
	W0352	215Z			V	78-36-11	050-099, 150-199, 275-278
	W0352	216B	20		8	78-36-11	050-099, 150-199, 275-278
	W0352	216Z			V	78-36-11	050-099, 150-199, 275-278
	W0372	218B	20		8	78-36-11	ALL
	W0372	218Z			V	78-36-11	ALL
SP09577		N 145/160/					ALL
	W0352	215R	20		8	78-36-11	050-099, 150-199, 275-278
	W0352	216R	20		8	78-36-11	050-099, 150-199, 275-278
	W0372	218R	20		8	78-36-11	ALL
SP09579		N 145/160/					ALL
	W0356	149	20		8	78-36-11	ALL
	W0356	149Z			V	78-36-11	ALL
	W0396	101	20		8	78-36-11	ALL
	W0396	101Z			V	78-36-11	ALL
SP09581		N 145/160/					ALL
	W0356	151	20		8	78-36-11	ALL
	W0356	151Z			V	78-36-11	ALL
	W0396	102	20		8	78-36-11	ALL
	W0396	102Z			V	78-36-11	ALL
SP09583		N145/160/					ALL
	W0356	215B	20		8	78-36-11	ALL
	W0356	215Z			V	78-36-11	ALL



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP09583		N145/160/ (continued)					ALL
	W0356	216B	20		8	78-36-11	ALL
	W0356	216Z			V	78-36-11	ALL
	W0396	224B	20		8	78-36-11	ALL
	W0396	224Z			V	78-36-11	ALL
SP09585		N145/160/					ALL
	W0356	215R	20		8	78-36-11	ALL
	W0356	216R	20		8	78-36-11	ALL
	W0396	224R	20		8	78-36-11	ALL
SP09587		N 145/160/					ALL
	W0374	101	20		8	78-36-21	050-099, 150-166, 275-299
	W0374	101Z			V	78-36-21	050-099, 150-166, 275-299
	W0382	101	20		8	78-36-21	ALL
	W0382	101Z			V	78-36-21	ALL
SP09589		N 145/160/					ALL
	W0374	103	20		8	78-36-21	050-099, 150-166, 275-299
	W0374	103Z			V	78-36-21	050-099, 150-166, 275-299
	W0382	102	20		8	78-36-21	ALL
	W0382	102Z			V	78-36-21	ALL
SP09591		N 145/160/					ALL
	W0374	215B	20		8	78-36-21	050-099, 150-166, 275-299
	W0374	215Z			V	78-36-21	050-099, 150-166, 275-299
	W0374	216B	20		8	78-36-21	050-099, 150-166, 275-299
	W0374	216Z			V	78-36-21	050-099, 150-166, 275-299
	W0382	218B	20		8	78-36-21	ALL
	W0382	218Z			V	78-36-21	ALL
SP09593		N 145/160/					ALL
	W0374	215R	20		8	78-36-21	050-099, 150-166, 275-299
	W0374	216R	20		8	78-36-21	050-099, 150-166, 275-299
	W0382	218R	20		8	78-36-21	ALL
SP09595		N 145/160/					ALL
	W0376	149	20		8	78-36-21	ALL
	W0376	149Z			V	78-36-21	ALL
	W0392	101	20		8	78-36-21	ALL

SPLICE LIST
D280T132

91-21-31
Section SP09500
Page 2
Jan 21/2005



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP09595		N 145/160/ (continued)					ALL
	W0392	101Z			V	78-36-21	ALL
SP09597		N 145/160/					ALL
	W0376	151	20		8	78-36-21	ALL
	W0376	151Z			V	78-36-21	ALL
	W0392	102	20		8	78-36-21	ALL
	W0392	102Z			V	78-36-21	ALL
SP09599		N 145/160/					ALL
	W0376	215B	20		8	78-36-21	ALL
	W0376	215Z			V	78-36-21	ALL
	W0376	216B	20		8	78-36-21	ALL
	W0376	216Z			V	78-36-21	ALL
	W0392	224B	20		8	78-36-21	ALL
	W0392	224Z			V	78-36-21	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP09601		N 145/160/					ALL
	W0376	215R	20		8	78-36-21	ALL
	W0376	216R	20		8	78-36-21	ALL
	W0392	224R	20		8	78-36-21	ALL



Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SP09728		0236/201/R054					155, 163-164, 275-299
	W0262	138	20		S	28-22-21	155, 163-164, 275-299
	W0262	138Z				28-22-21	155, 163-164, 275-299
	W0606	019	20		S	28-22-21	155, 163-164, 275-299
	W0606	019Z				28-22-21	155, 163-164, 275-299
	W0606	793	20		S	28-22-21	155, 163-164, 275-299
	W0606	793Z				28-22-21	155, 163-164, 275-299
SP09730		0236/201/R054					155, 163-164, 275-299
	W0264	051	18		S	28-22-21	155, 163-164, 275-299
	W0264	658	18		S	28-22-21	155, 163-164, 275-299
	W0614	019	20		S	28-22-21	155, 163-164, 275-299
	W0614	019Z				28-22-21	155, 163-164, 275-299
	W0614	691	20		S	28-22-21	155, 163-164, 275-299
	W0614	691Z				28-22-21	155, 163-164, 275-299

SPLICE LIST
D280T132

91-21-31
Section SP09700
Page 1 End
Mar 14/2007



767-200/300 WIRING DIAGRAM MANUAL

Splice No.	Bundle	Station / WL / BL Wire No.	GA	CO	Type	Diagram	Effectivity
SPZ0001		P003-00/ /					150, 152-199, 275-299
	W0031	140	20		S	33-13-13	150, 152-199, 275-299
	W0031	927	20		S	33-13-13	150, 152-199, 275-299
	W9090	926	20		S	33-13-13	150, 152-199, 275-299
SPZ0002		P001-00/ /					150, 152-199, 275-299
	W0011	116	18		S	33-13-11	150, 152-199, 275-299
	W0011	926	18		S	33-13-11	150, 152-199, 275-299
	W0017	913	20		S	33-13-11	150, 152-199, 275-299

SPLICE LIST

D280T132

91-21-31
Section SPZ0000
Page 1 End
Mar 14/2007