

PARTS CATALOG

Buffer Pass Unit-C1

Canon

Nov 13 2003

PREFACE

This Parts Catalog contains listings of parts used

Diagrams are provided with the listings to aid the service technician in identifying clearly, the item to be ordered.

Whenever ordering parts, consult this Parts Catalog for all of the information pertaining to each item. Be sure to include, in the Parts Request, the full item description, the item part number, and the quantity.

COPYRIGHT (C) 1999 CANON INC.

Use of this manual should be
strictly supervised to avoid
disclosure of confidential
information.

Contents

Parts List Index

Buffer Pass Unit-C1	1-1
---------------------------	-----

Buffer Pass Unit-C1

QA	ASSEMBLY LOCATION DIAGRAM	2-1
Q03	ATTACHMENT PARTS	2-2
Q35	BUFFER PASS ASSEMBLY	2-4
Q36	2ND/3RD DELIVERY ASSEMBLY	2-7
Q37	2ND UPPER DELIVERY ASSEMBLY	2-9
Q38	2ND DELIVERY FRAME ASSEMBLY	2-11
Q39	3RD DELIVERY FRAME ASSEMBLY	2-14
Q93	BUFFER PASS CONTROLLER PCB ASSEMBLY	2-17
Q94	INTERNAL CONNECT DELIVERY CONTROLLER PCB ASSEMBLY 2-18	
QB	LIST OF CONNECTORS	2-19

NUMERICAL INDEX

Buffer Pass Unit-C1

PARTS NUMBER	FIGURE & KEY NO.	PARTS NUMBER	FIGURE & KEY NO.	PARTS NUMBER	FIGURE & KEY NO
FB3-7217-000	Q35 - 9	FC5-1023-000	Q39 - 11	FL2-1201-000	Q38 - 9
FB4-2930-000	Q35 - 3	FC5-1025-000	Q37 - 4	FL2-1203-000	Q38 - 10
FB5-4754-000	Q35 - 10	FC5-1029-000	Q03 - 1	FL2-1206-000	Q39 - 8
FB5-4754-000	Q37 - 26	FC5-1038-000	Q37 - 5	FL2-1207-000	Q39 - 19
FB5-4754-000	Q38 - 21	FC5-1039-000	Q35 - 5	FL2-1208-000	Q39 - 16
FB5-4858-000	Q35 - 28	FC5-1041-000	Q35 - 6	FL2-1209-000	Q39 - 21
FB5-4896-000	Q38 - 7	FC5-1043-000	Q35 - 12	FL2-1210-000	Q39 - 3
FB5-9325-000	Q39 - 1	FC5-1046-000	Q35 - 2	FL2-1212-000	Q38 - 3
FB5-9803-000	Q38 - 22	FC5-1048-000	Q35 - 13	FL2-1612-000	Q35 - 27
FB6-5796-000	Q38 - 23	FC5-1049-000	Q35 - 14	FL2-1613-000	Q35 - 29
FC5-0693-000	Q39 - 17	FC5-1053-000	Q38 - 5	FM2-0194-000	Q35 -
FC5-0805-000	Q38 - 26	FC5-1054-000	Q39 - 5	FM2-1327-000	Q36 -
FC5-0856-000	Q35 - 1	FC5-5474-000	Q38 - 6	FM2-1328-000	Q37 -
FC5-0859-000	Q36 - 1	FC5-5489-000	Q35 - 7	FM2-1331-000	Q38 -
FC5-0870-000	Q37 - 10	FC5-6003-000	Q37 - 22	FM2-1336-000	Q39 -
FC5-0871-000	Q38 - 19	FC5-6004-000	Q03 - 2	FS5-1377-000	Q39 - 28
FC5-0872-000	Q39 - 2	FC5-6006-000	Q39 - 6	FS5-1943-000	Q35 - 18
FC5-0873-000	Q38 - 20	FC5-6008-000	Q39 - 26	FS5-1943-000	Q37 - 7
FC5-0874-000	Q35 - 21	FC5-6010-000	Q37 - 11	FS5-1943-000	Q38 - 11
FC5-0875-000	Q35 - 11	FC5-6014-000	Q38 - 18	FS5-1943-000	Q39 - 9
FC5-0877-000	Q35 - 4	FC5-6019-000	Q39 - 30	FS5-6488-000	Q38 - 28
FC5-0888-000	Q36 - 2	FC5-6205-000	Q03 - 3	FS7-2859-000	Q38 - 24
FC5-0974-000	Q38 - 25	FC5-7385-000	Q35 - 32	FU5-0054-000	Q37 - 13
FC5-0976-000	Q39 - 18	FC5-7386-000	Q35 - 30	FU5-0057-000	Q35 - 19
FC5-0977-000	Q39 - 14	FC5-7387-000	Q35 - 33	FU5-0058-000	Q35 - 20
FC5-0978-000	Q36 - 3	FC5-7388-000	Q35 - 31	FU5-0076-000	Q38 - 12
FC5-0985-000	Q37 - 18	FG3-2933-000	Q93 -	FU5-0077-000	Q37 - 14
FC5-0987-000	Q37 - 1	FG3-3293-000	Q94 -	FU5-0078-000	Q37 - 15
FC5-0988-000	Q37 - 2	FG3-3296-000	Q39 - 13	FU5-3018-000	Q39 - 10
FC5-0989-000	Q37 - 3	FG3-3299-000	Q38 - 16	FU5-3019-000	Q38 - 13
FC5-0991-000	Q37 - 19	FG3-3301-000	Q36 - 5	FU5-3020-000	Q37 - 24
FC5-0996-000	Q38 - 1	FH4-6203-000	Q93 - IC4	FU5-3020-000	Q38 - 14
FC5-0997-000	Q38 - 2	FH4-6204-000	Q94 - IC10	FU5-3021-000	Q37 - 8
FC5-0998-000	Q38 - 17	FH5-1020-000	Q35 - 22	FU5-3022-000	Q37 - 16
FC5-1003-000	Q39 - 20	FH5-1021-000	Q37 - 12	NPN	Q03 -
FC5-1005-000	Q39 - 22	FH5-1108-000	Q37 - 23	NPN	QB -
FC5-1006-000	Q39 - 23	FH7-7312-000	Q35 - 15	NPN	QB - J2102
FC5-1009-000	Q39 - 15	FH7-7312-000	Q37 - 6	NPN	QB - J2103
FC5-1012-000	Q39 - 4	FH7-7312-000	Q38 - 8	NPN	QB - J2104
FC5-1013-000	Q37 - 20	FH7-7312-000	Q39 - 27	NPN	QB - J2105
FC5-1013-000	Q39 - 24	FL2-0227-000	Q35 - 8	NPN	QB - J7421
FC5-1014-000	Q39 - 25	FL2-0228-000	Q35 - 16	NPN	QB - J7423
FC5-1017-000	Q38 - 4	FL2-0229-000	Q35 - 17	NPN	QB - J7431
FC5-1019-000	Q36 - 4	FL2-1200-000	Q37 - 21	NPN	QB - J7432

NUMERICAL INDEX

Buffer Pass Unit-C1

PARTS NUMBER	FIGURE & KEY NO.	PARTS NUMBER	FIGURE & KEY NO.	PARTS NUMBER	FIGURE & KEY NO
NPN	QB - J7441	WS3-5721-000	QB - J742		
NPN	QB - J7442	WT2-5565-000	Q36 - 7		
NPN	QB - J7451	WT2-5565-000	Q39 - 12		
PCB	QB - J1	XA9-1386-000	Q35 - 23		
PCB	QB - J2	XA9-1386-000	Q36 - 6		
PCB	QB - J741	XA9-1386-000	Q36 - 8		
PCB	QB - J742	XA9-1386-000	Q37 - 9		
PCB	QB - J743	XA9-1386-000	Q39 - 29		
PCB	QB - J744	XB1-2300-405	Q35 - 503		
PCB	QB - J745	XB1-2300-405	Q38 - 501		
SYS	QB - J2106	XB1-2300-405	Q39 - 503		
SYS	QB - J2107	XB4-5300-805	Q36 - 502		
VS1-5057-002	Q38 - 27	XB4-5300-805	Q39 - 504		
VS1-5057-002	QB - J7441	XB4-5401-205	Q03 - 501		
VS1-5057-003	Q39 - 7	XB4-5401-205	Q35 - 504		
VS1-5057-003	QB - J7421	XB4-5401-205	Q37 - 503		
VS1-5824-003	QB - J7421	XB4-5401-205	Q38 - 502		
VS1-5824-003	QB - J7423	XB4-5401-205	Q39 - 501		
VS1-6302-010	QB - J741	XD2-1100-502	Q35 - 501		
VS1-6302-010	QB - J2107	XD2-1100-502	Q36 - 501		
VS1-6302-012	QB - J751	XD2-1100-502	Q37 - 501		
VS1-6302-012	QB - J2106	XD2-1100-502	Q38 - 503		
VS1-6314-003	QB - J745	XD2-1100-502	Q39 - 502		
VS1-6314-005	QB - J744	XD3-2200-122	Q35 - 502		
VS1-6314-015	QB - J743	XD3-2200-122	Q37 - 502		
VS1-6314-015	QB - J753	XF2-4104-240	Q37 - 25		
VS1-6321-002	QB - J7441	XF2-4107-940	Q38 - 15		
VS1-6321-003	QB - J2102	XF2-4108-240	Q37 - 17		
VS1-6321-003	QB - J2103	XF2-4606-440	Q35 - 26		
VS1-6321-003	QB - J2104	XF2-4611-940	Q35 - 24		
VS1-6321-003	QB - J7442	XF2-4612-840	Q35 - 25		
VS1-6321-003	QB - J7451	XG9-0520-000	Q38 - 29		
VS1-6483-006	QB - J7431				
VS1-6483-006	QB - J7432				
VS1-6755-006	QB - J2105				
VS1-6757-011	QB - J742				
WS3-5251-000	QB - J7431				
WS3-5251-000	QB - J7432				
WS3-5358-000	QB - J7421				
WS3-5358-000	QB - J7423				
WS3-5569-000	QB - J741				
WS3-5569-000	QB - J751				
WS3-5569-000	QB - J2106				
WS3-5569-000	QB - J2107				

Buffer Pass Unit-C1

F26-2704-000JEX00001-

Contents

QA	ASSEMBLY LOCATION DIAGRAM	2-1
Q03	ATTACHMENT PARTS	2-2
Q35	BUFFER PASS ASSEMBLY	2-4
Q36	2ND/3RD DELIVERY ASSEMBLY	2-7
Q37	2ND UPPER DELIVERY ASSEMBLY	2-9
Q38	2ND DELIVERY FRAME ASSEMBLY	2-11
Q39	3RD DELIVERY FRAME ASSEMBLY	2-14
Q93	BUFFER PASS CONTROLLER PCB ASSEMBLY	2-17
Q94	INTERNAL CONNECT DELIVERY CONTROLLER PCB ASSEMBLY	2-18
QB	LIST OF CONNECTORS	2-19

FIGURE QA
ASSEMBLY LOCATION DIAGRAM





FIGURE Q03 ATTACHMENT PARTS

FINISHER-Q1/R1 With SADDLE FINISHER-Q2/R2



PUNCHER UNIT-L1/M1/N1/P1





FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.Q03	NPN		RF	ATTACHMENT PARTS		
1	FC5-1029-000		1	SHAFT, CONNECTING		
2	FC5-6004-000		1	COVER, PROTECTIVE		
3	FC5-6205-000		1	SHEET, REVERSE PAPER STOPPER		
501	XB4-5401-205		AR	SCREW,P,M4X12		

FIGURE Q35 BUFFER PASS ASSEMBLY



NOTE : This assembly includes the assembly shown in Figure Q93.

注 : このユニットはFigure Q93のユニットを含みます。


FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.Q35	FM2-0194-000		1	BUFFER PASS ASSEMBLY	SEE NOTE	
1	FC5-0856-000		1	STOPPER, GUIDE, UPPER		
2	FC5-1046-000		1	PLATE, PCB GROUNDING		
3	FB4-2930-000		16	SPRING, LEAF		
4	FC5-0877-000		8	ROLLER, BUFFER DRIVE		
5	FC5-1039-000		1	GUIDE, FEEDER, UPPER		
6	FC5-1041-000		1	PLATE, MAGNET		
7	FC5-5489-000		1	PLATE, MAGNET CATCH, 2		
8	FL2-0227-000		1	PANEL, BUFFER PASS, UPPER		
9	FB3-7217-000		2	MAGNET CATCH		
10	FB5-4754-000		4	SPACER		
11	FC5-0875-000		1	GUIDE, BUFFER INLET		
12	FC5-1043-000		4	ROLLER, FEED		
13	FC5-1048-000		2	FLAG, SENSOR		
14	FC5-1049-000		2	SPRING, TORSION		
15	FH7-7312-000		3	PHOTO-INTERRUPTER	PS1,2,3 J2102,2104,2103	
16	FL2-0228-000		1	GUIDE, FEEDER, LOWER		
17	FL2-0229-000		1	PLATE, ROLLER, GROUNDING		
18	FS5-1943-000		8	BUSHING		
19	FU5-0057-000		4	PULLEY, 30T/40T		
20	FU5-0058-000		2	PULLEY, 31T/GEAR, 37T		
21	FC5-0874-000		1	SPRING, GROUNDING		
22	FH5-1020-000		1	MOTOR, STEPPING, DC 24V	M1 J2105	
23	XA9-1386-000		2	SCREW,RS,M3X8		
24	XF2-4611-940		1	BELT, TIMING, COGGED		
25	XF2-4612-840		1	BELT, TIMING, COGGED		
26	XF2-4606-440		2	BELT, TIMING, COGGED		
27	FL2-1612-000		1	PLATE, INLET GROUNDING		
28	FB5-4858-000		2	ELIMINATOR, STATIC CHARGE		
29	FL2-1613-000		3	PLATE, GROUNDING, MIDDLE		
30	FC5-7386-000		12	ELIMINATOR, STATIC CHARGE		
31	FC5-7388-000		6	ELIMINATOR, STATIC CHARGE		

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
32	FC5-7385-000		1	PLATE, GROUNDING CONNECTING		
33	FC5-7387-000		1	PLATE, OUTLET GROUNDING		
501	XD2-1100-502		AR	RING,E		
502	XD3-2200-122		AR	PIN,DOWEL		
503	XB1-2300-405		AR	SCREW,MACH.,TRUSS HEAD,M3X4		
504	XB4-5401-205		AR	SCREW,P,M4X12		

注2: このユニットにKey No. 8の部品は含まれません。

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.Q36	FM2-1327-000		1	2ND/3RD DELIVERY ASSEMBLY	SEE NOTE 1	
1	FC5-0859-000		1	COVER, CONNECTOR		
2	FC5-0888-000		1	PANEL, 2ND DELIVERY BLANKING		
3	FC5-0978-000		1	SHAFT, 2ND DELIVERY HINGE		
4	FC5-1019-000		1	SHAFT, 3RD DELIVERY HINGE		
5	FG3-3301-000		1	CABLE, SENSOR	J745,7421	
6	XA9-1386-000		5	SCREW,RS,M3X8		
7	WT2-5565-000		2	CLAMP, CABLE		
8	XA9-1386-000		4	SCREW,RS,M3X8	SEE NOTE 2	
501	XD2-1100-502		AR	RING,E		
502	XB4-5300-805		AR	SCREW,P,M3X8		

FIGURE Q37
2ND UPPER DELIVERY ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q36.
注：このユニットはFigure Q36のユニットに含まれます。

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.Q37	FM2-1328-000		1	2ND UPPER DELIVERY ASSEMBLY	SEE NOTE	
1	FC5-0987-000		1	FLAG, REVERSE SENSOR		
2	FC5-0988-000		1	SPRING, TORSION		
3	FC5-0989-000		1	ROLLER, REVERSE		
4	FC5-1025-000		1	PLATE, GROUNDING		
5	FC5-1038-000		1	GUIDE, 2ND DELIVERY, UPPER		
6	FH7-7312-000		1	PHOTO-INTERRUPTER	PS1 J7442	
7	FS5-1943-000		2	BUSHING		
8	FU5-3021-000		1	PULLEY, 30T		
9	XA9-1386-000		12	SCREW,RS,M3X8		
10	FC5-0870-000		1	GUIDE, SLIDE		
11	FC5-6010-000		1	COVER, GEAR, 1		
12	FH5-1021-000		1	MOTOR, STEPPING, AC	M2 J7432	
13	FU5-0054-000		2	GEAR, 35T		
14	FU5-0077-000		1	GEAR, 46T		
15	FU5-0078-000		1	GEAR, 30T/24T		
16	FU5-3022-000		1	PULLEY, 30T/GEAR, 35T		
17	XF2-4108-240		1	BELT, TIMING, COGGED		
18	FC5-0985-000		1	GUIDE, REVERSE LOWER		
19	FC5-0991-000		4	SPRING		
20	FC5-1013-000		4	ROLLER		
21	FL2-1200-000		1	GUIDE, REVERSE LOWER AUXILIARY		
22	FC5-6003-000		1	ELIMINATOR, STATIC-CHARGE		
23	FH5-1108-000		1	MOTOR, STEPPING, AC	M1 J7431	
24	FU5-3020-000		1	GEAR, 24T/PULLEY, 30T		
25	XF2-4104-240		1	BELT, TIMING, COGGED		
26	FB5-4754-000		1	SPACER		
501	XD2-1100-502		AR	RING,E		
502	XD3-2200-122		AR	PIN,DOWEL		
503	XB4-5401-205		AR	SCREW,P,M4X12		


注：このユニットはFigure Q36のユニットに含まれます。

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.Q38	FM2-1331-000		1	2ND DELIVERY FRAME ASSEMBLY	SEE NOTE	
1	FC5-0996-000		1	FLAG, 2ND DELIVERY SENSOR		
2	FC5-0997-000		1	SPRING, TORSION		
3	FL2-1212-000		1	FLAPPER, 1ST PAPER DELIVERY		
4	FC5-1017-000		1	ROLLER, 2ND VERTICAL PATH		
5	FC5-1053-000		1	COVER, SOLENOID, 1		
6	FC5-5474-000		1	GUIDE, 2ND DELIVERY ENTRANCE		
7	FB5-4896-000		4	HOLDER, ROLLER		
8	FH7-7312-000		1	PHOTO-INTERRUPTER	PS4 J7451	
9	FL2-1201-000		1	GUIDE, 2ND PAPER DELIVERY		
10	FL2-1203-000		1	SOLENOID	SL1 J7441	
11	FS5-1943-000		2	BUSHING		
12	FU5-0076-000		1	GEAR, 24T		
13	FU5-3019-000		1	PULLEY, 30T/GEAR, 35T		
14	FU5-3020-000		1	GEAR, 24T/PULLEY, 30T		
15	XF2-4107-940		1	BELT, TIMING, COGGED		
16	FG3-3299-000		1	CABLE, 2ND PAPER DELIVERY	J744,7441,7442	
17	FC5-0998-000		1	ROLLER, 2ND PAPER DELIVERY		
18	FC5-6014-000		2	CAP, SPRING		
19	FC5-0871-000		2	SPRING, COMPRESSION		
20	FC5-0873-000		1	COVER, 2ND DELIVERY FRAME		
21	FB5-4754-000		1	SPACER		
22	FB5-9803-000		8	RING		
23	FB6-5796-000		4	ROLLER, PAPER DELIVERY		
24	FS7-2859-000		4	SPRING, COMPRESSION		
25	FC5-0974-000		1	SPRING, TORSION		
26	FC5-0805-000		4	ROLLER, REFORM		
27	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	J7441	
28	FS5-6488-000		2	WASHER		
29	XG9-0520-000		2	BEARING, BALL, MF106ZZS		
501	XB1-2300-405		AR	SCREW,MACH.,TRUSS HEAD,M3X4		
502	XB4-5401-205		AR	SCREW,P,M4X12		

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
503	XD2-1100-502		AR	RING,E		

FIGURE Q39

3RD DELIVERY FRAME ASSEMBLY




NOTE : This assembly is included in the assembly shown in Figure Q36.
 注 : このユニットはFigure Q36のユニットに含まれます。

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.Q39	FM2-1336-000		1	3RD DELIVERY FRAME ASSEMBLY	SEE NOTE	
1	FB5-9325-000		1	MAGNET, 3RD		
2	FC5-0872-000		1	COVER, DELIVERY SOLENOID, 2		
3	FL2-1210-000		1	FRAME, 3RD DELIVERY		
4	FC5-1012-000		1	ROLLER, DUPLEXING ENTRANCE		
5	FC5-1054-000		1	COVER, DELIVERY SOLENOID, 1		
6	FC5-6006-000		1	PLATE, GROUNDING		
7	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J7421	
8	FL2-1206-000		1	SOLENOID		
9	FS5-1943-000		2	BUSHING		
10	FU5-3018-000		1	PULLEY, 30T/GEAR, 35T		
11	FC5-1023-000		1	ARM, SOLENOID, 2		
12	WT2-5565-000		2	CLAMP, CABLE		
13	FG3-3296-000		1	CABLE, 3RD PAPER DELIVERY	J742,7423,7424	
14	FC5-0977-000		1	SPRING, TORSION		
15	FC5-1009-000		1	GUIDE, 3RD DELIVERY, UPPER		
16	FL2-1208-000		1	FLAPPER, 3RD PAPER DELIVERY		
17	FC5-0693-000		4	DAMPER, FLAPPER		
18	FC5-0976-000		1	SPRING, TENSION		
19	FL2-1207-000		1	GUIDE, DUPLEXING ENTRANCE		
20	FC5-1003-000		1	FLAPPER, 2ND PAPER DELIVERY		
21	FL2-1209-000		1	FLAPPER, REVERSE		
22	FC5-1005-000		1	FLAG, DUPLEX ENTRANCE SENSOR		
23	FC5-1006-000		1	SPRING, TORSION		
24	FC5-1013-000		8	ROLLER		
25	FC5-1014-000		8	SPRING		
26	FC5-6008-000		1	GUIDE, DUPLEXING ENTRANCE, 2		
27	FH7-7312-000		1	PHOTO-INTERRUPTER	PS3 J7423	
28	FS5-1377-000		2	BUSHING		
29	XA9-1386-000		1	SCREW,RS,M3X8		
30	FC5-6019-000		1	SPRING, TORSION		
501	XB4-5401-205		AR	SCREW,P,M4X12		

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
502	XD2-1100-502		AR	RING,E		
503	XB1-2300-405		AR	SCREW,MACH.,TRUSS HEAD,M3X4		
504	XB4-5300-805		AR	SCREW,P,M3X8		

FIGURE Q93
BUFFER PASS CONTROLLER PCB ASSEMBLY




NOTE : This assembly is included in the assembly shown in Figure Q35.
注：このユニットはFigure Q35のユニットに含まれます。

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.Q93	FG3-2933-000		1	BUFFER PASS CONT. PCB ASS'Y	SEE NOTE	
IC4	FH4-6203-000		1	IC, TC200G04AN-0021,GATE-ARRAY		

FIGURE Q94

INTERNAL CONNECT DELIVERY CONTROLLER PCB ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q36.
 注：このユニットはFigure Q36のユニットに含まれます。

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.Q94	FG3-3293-000		1	DELIVERY CONTROLLER PCB ASS'Y	SEE NOTE	
IC10	FH4-6204-000		1	IC, S1L50993F22H000,GATE-ARRAY		

FIGURE QB
LIST OF CONNECTORS




FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
Fig.QB	NPN		RF	LIST OF CONNECTORS		
J1	PCB			BUFFER PASS DRIVER		
J2	PCB			BUFFER PASS DRIVER		
J741	PCB			DC CONTROLLER		
J741	VS1-6302-010		1	CONNECTOR, 10P, FEMALE		
J741	WS3-5569-000		10	PIN, CONTACT		
J742	PCB			DC CONTROLLER		
J742	VS1-6757-011		1	CONNECTOR, 11P, FEMALE, Y		
J742	WS3-5721-000		8	SOCKET CONTACT		
J743	PCB			DC CONTROLLER		
J743	VS1-6314-015		1	CONNECTOR, 15P, FEMALE		
J744	PCB			DC CONTROLLER		
J744	VS1-6314-005		1	CONNECTOR, 5P, FEMALE		
J745	PCB			DC CONTROLLER		
J745	VS1-6314-003		1	CONNECTOR, 3P, MALE		
J751	VS1-6302-012		1	CONNECTOR, 12P, MALE		
J751	WS3-5569-000		12	PIN, CONTACT		
J753	VS1-6314-015		1	CONNECTOR, 15P, FEMALE		
J2102	NPN			INSIDE PAPER SENSOR	PS1	
J2102	VS1-6321-003		1	CONNECTOR, 3P, FEMALE		
J2103	NPN			OPEN DETECT SENSOR	PS3	
J2103	VS1-6321-003		1	CONNECTOR, 3P, FEMALE		
J2104	NPN			OUTSIDE PAPER SENSOR	PS2	
J2104	VS1-6321-003		1	CONNECTOR, 3P, FEMALE		
J2105	NPN			BUFFER PASS MOTOR	M1	
J2105	VS1-6755-006		1	CONNECTOR, 6P, FEMALE		
J2106	SYS			TO PRINTER		
J2106	VS1-6302-012		1	CONNECTOR, 12P, MALE		
J2106	WS3-5569-000		12	PIN, CONTACT		
J2107	SYS			TO PRINTER		
J2107	VS1-6302-010		1	CONNECTOR, 10P, FEMALE		
J2107	WS3-5569-000		10	PIN, CONTACT		

FIGURE & KEY NO.	PARTS NUMBER	R A N K	Q'TY	DESCRIPTION	SERIAL NUMBER/ REMARKS	S V C
J7421	NPN			2 FLAPPER SOLENOID	SL2	
J7421	VS1-5057-003		1	CONNECTOR, SNAP TIGHT		
J7421	VS1-5824-003		1	CONNECTOR, 3P, FEMALE		
J7421	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG		
J7423	NPN			DUPLEXING ENTRANCE SENSOR	PS3	
J7423	VS1-5824-003		1	CONNECTOR, 3P, FEMALE		
J7423	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG		
J7431	NPN			2 DELIVERY MOTOR	M1	
J7431	VS1-6483-006		1	CONNECTOR, 6P, FEMALE, GRY		
J7431	WS3-5251-000		4	SOCKET CONTACT		
J7432	NPN			3 PAPER DELIVERY MOTOR	M2	
J7432	VS1-6483-006		1	CONNECTOR, 6P, FEMALE, GRY		
J7432	WS3-5251-000		4	SOCKET CONTACT		
J7441	NPN			1 FLAPPER SOLENOID	SL1	
J7441	VS1-5057-002		1	CONNECTOR, SNAP TIGHT		
J7441	VS1-6321-002		1	CONNECTOR, 2P, FEMALE		
J7442	NPN			2 PAPER DELIVERY SENSOR	PS1	
J7442	VS1-6321-003		1	CONNECTOR, 3P, FEMALE		
J7451	NPN			REVERSE SENSOR	PS4	
J7451	VS1-6321-003		1	CONNECTOR, 3P, FEMALE		

Prepared by
OFFICE IMAGING PRODUCTS QUALITY ASSURANCE CENTER
CANON INC.

Canon