

Saddle Finisher-K3/K4

PARTS CATALOG

REVISION 0

Canon

MAR. 2001

FY8-31F9-000

PREFACE

This Parts Catalog contains listings of parts used in the Canon Saddle Finisher-K3/K4. Diagrams are provided with the listings to aid the service technician in identifying clearly, the item to be ordered.

Whenever ordering parts, consult this Parts Catalog for all of the information pertaining to each item. Be sure to include, in the Parts Request, the full item description, the item part number, and the quantity.

Canon Inc.

Office Imaging Products Quality Assurance Center
5-1, Hakusan 7-chome,
Toride-city, Ibaraki 302-8501, Japan

COPYRIGHT © 2001 CANON INC.

Printed in Japan

Imprimé au Japon

Use of this manual should be strictly supervised to avoid disclosure of confidential information.

CONTENTS

–Saddle Finisher-K3/K4–

QA. ASSEMBLY LOCATION DIAGRAM

Q01. ATTACHMENT PARTS

Q10. EXTERNAL COVERS, PANELS, ETC.

Q11. INTERNAL COMPONENTS 1

Q12. INTERNAL COMPONENTS 2

Q13. INTERNAL COMPONENTS 3

Q14. SADDLE DELIVERY TRAY ASSEMBLY

Q15. POWER CORD TERMINAL ASSEMBLY

Q16. MAIN BODY CABLE ASSEMBLY

Q17. HOPPER ASSEMBLY

Q18. STACKER TRAY FRAME ASSEMBLY

Q19. SAMPLE TRAY FRAME ASSEMBLY

Q20. OPERATION ASSEMBLY

Q21. TRAY ASSEMBLY

Q22. TRAY FRAME ASSEMBLY

Q23. TRAY AUXILIARY PLATE ASSEMBLY

Q24. SWING GUIDE ASSEMBLY

Q30. FEEDER ASSEMBLY

Q31. SORT GUIDE ASSEMBLY

Q32. PAPER FEED LOWER GUIDE ASSEMBLY

Q33. SORT LEFT LOWER GUIDE ASSEMBLY

Q34. KNURLED BELT DRIVE ASSEMBLY

Q36. DELIVERY MOTOR ASSEMBLY

Q37. UPPER FEEDER ASSEMBLY

Q40. STAPLER MOUNT ASSEMBLY

Q41. STAPLER ASSEMBLY

Q45. PUNCH ASSEMBLY

Q46. PUNCH WASTE FEED MOTOR ASSEMBLY

Q50. SADDLE ASSEMBLY

Q52. SADDLE INLET ASSEMBLY

Q53. SADDLE GUIDE ASSEMBLY

Q54. SADDLE STAPLER ASSEMBLY

Q55. SADDLE INLET DRIVE ASSEMBLY

Q56. PASS LOWER GUIDE ASSEMBLY

Q57. INNER SIDE PLATE ASSEMBLY

Q58. SADDLE DELIVERY ASSEMBLY

Q59. MOTOR MOUNT ASSEMBLY

Q90. FINISHER CONTROLLER PCB ASSEMBLY

Q91. SADDLE CONTROLLER PCB ASSEMBLY

Q92. AC FUSE BOX PCB ASSEMBLY

Q93. PUNCH DRIVER PCB ASSEMBLY

Q94. STAPLER DRIVER PCB ASSEMBLY

QB. LIST OF CONNECTORS

–Paper Folding Unit-C1–

QA. ASSEMBLY LOCATION DIAGRAM

Q01. ATTACHMENT PARTS 1

Q02. ATTACHMENT PARTS 2

Q03. ATTACHMENT PARTS 3

Q10. UPPER COVER ASSEMBLY

Q11. INTERNAL COMPONENTS 1

Q12. INTERNAL COMPONENTS 2

Q13. INTERNAL COMPONENTS 3

Q20. FOLDER MOTOR ASSEMBLY

Q21. COUPLING ASSEMBLY

Q31. RIGHT GUIDE ASSEMBLY

Q32. RIGHT INNER GUIDE ASSEMBLY

Q33. LEFT GUIDE ASSEMBLY

Q34. LEFT INNER GUIDE ASSEMBLY

Q35. FEED UPPER GUIDE ASSEMBLY

Q36. INNER LEFT GUIDE ASSEMBLY

Q37. LOWER LEFT GUIDE ASSEMBLY

Q90. FOLDER DRIVER PCB ASSEMBLY

QB. LIST OF CONNECTORS

CONTENTS

–Document Insertion Unit-B1–

PA. ASSEMBLY LOCATION DIAGRAM

P01. MOUNTING HARDWARE 1

P02. MOUNTING HARDWARE 2

P10. EXTERNAL COVERS, PANELS, ETC.

P11. INTERNAL COMPONENTS

P12. PICK-UP TRAY ASSEMBLY

P14. UPPER COVER ASSEMBLY

P20. SEPARATION MOTOR ASSEMBLY

P30. SEPARATION ASSEMBLY

PB. LIST OF CONNECTORS

–Puncher Unit-E1/F1–

Q45. PUNCH ASSEMBLY

Q46. PUNCH WASTE FEED MOTOR ASSEMBLY

C. LIST OF STANDARD FASTENERS

D1. NUMERICAL INDEX (Saddle Finisher-K3/K4)

D2. NUMERICAL INDEX (Paper Folding Unit-C1)

D3. NUMERICAL INDEX (Document Insertion Unit-B1)

D4. NUMERICAL INDEX (Puncher Unit-E1/F1)

Saddle Finisher-K3/K4

Saddle Finisher -K3

100V	50/60Hz	F25 - 9001	MHF00001 -
208V	50Hz	F25 - 9011	PSP00001 -
230V	50Hz	F25 - 9021	UHG00001 -

Saddle Finisher -K4

230V	50Hz	F25 - 9031	UHH00001 -
------	------	------------	------------

CONTENTS

QA. ASSEMBLY LOCATION DIAGRAM	Q90. FINISHER CONTROLLER PCB ASSEMBLY
Q01. ATTACHMENT PARTS	Q91. SADDLE CONTROLLER PCB ASSEMBLY
Q10. EXTERNAL COVERS, PANELS, ETC.	Q92. AC FUSE BOX PCB ASSEMBLY
Q11. INTERNAL COMPONENTS 1	Q93. PUNCH DRIVER PCB ASSEMBLY
Q12. INTERNAL COMPONENTS 2	Q94. STAPLER DRIVER PCB ASSEMBLY
Q13. INTERNAL COMPONENTS 3	QB1. LIST OF CONNECTORS
Q14. SADDLE DELIVERY TRAY ASSEMBLY	D1. NUMERICAL INDEX
Q15. POWER CORD TERMINAL ASSEMBLY	
Q16. MAIN BODY CABLE ASSEMBLY	
Q17. HOPPER ASSEMBLY	
Q18. STACKER TRAY FRAME ASSEMBLY	
Q19. SAMPLE TRAY FRAME ASSEMBLY	
Q20. OPERATION ASSEMBLY	
Q21. TRAY ASSEMBLY	
Q22. TRAY FRAME ASSEMBLY	
Q23. TRAY AUXILIARY PLATE ASSEMBLY	
Q24. SWING GUIDE ASSEMBLY	
Q30. FEEDER ASSEMBLY	
Q31. SORT GUIDE ASSEMBLY	
Q32. PAPER FEED LOWER GUIDE ASSEMBLY	
Q33. SORT LEFT LOWER GUIDE ASSEMBLY	
Q34. KNURLED BELT DRIVE ASSEMBLY	
Q36. DELIVERY MOTOR ASSEMBLY	
Q37. UPPER FEEDER ASSEMBLY	
Q40. STAPLER MOUNT ASSEMBLY	
Q41. STAPLER ASSEMBLY	
Q45. PUNCH ASSEMBLY	
Q46. PUNCH WASTE FEED MOTOR ASSEMBLY	
Q50. SADDLE ASSEMBLY	
Q52. SADDLE INLET ASSEMBLY	
Q53. SADDLE GUIDE ASSEMBLY	
Q54. SADDLE STAPLER ASSEMBLY	
Q55. SADDLE INLET DRIVE ASSEMBLY	
Q56. PASS LOWER GUIDE ASSEMBLY	
Q57. INNER SIDE PLATE ASSEMBLY	
Q58. SADDLE DELIVERY ASSEMBLY	
Q59. MOTOR MOUNT ASSEMBLY	

FIGURE QA

ASSEMBLY LOCATION DIAGRAM (1/2)




FIGURE QA

ASSEMBLY LOCATION DIAGRAM (2/2)




FIGURE Q01 ATTACHMENT PARTS




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q01 -	NPN		RF	ATTACHMENT PARTS	
1	FB4-8246-000		2	PLATE	
2	FB4-8265-000		1	MOUNT, GROUNDING	
3	FB4-8266-000		1	PLATE, GROUNDING	
4	FB4-8340-000		1	LABEL	
5	FB4-8345-000		1	LABEL	
6	FB4-8602-000		1	LABEL	
7	FB4-8722-000		1	GAP TAPE	
8	FB4-8933-000		1	SPACER, COVER, B	
9	FB5-9097-000		1	GUIDE, AUXILIARY	
10	FB5-9173-000		1	LABEL, PUNCH	
11	FB5-9302-000		1	LABEL, OPTION SWITCH	
12	FF5-8463-030		2	PLATE, LATCH	
13	FF5-8464-000		1	PLATE, PIN	
14	XA9-0633-000		4	SCREW,W/WASHER,M4X8	
15	XA9-0949-000		10	SCREW,RS,M4X10	
16	FH2-5006-000		1	CABLE, GROUNDING	100V
17	FB5-9118-000		1	PLATE, GROUNDING	

FIGURE Q10

EXTERNAL COVERS, PANELS, ETC. (1/2)




FIGURE Q10 EXTERNAL COVERS, PANELS, ETC. (2/2)




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q10 -	NPN		RF	EXTERNAL COVERS, PANELS, ETC.	
1	FB2-0037-000		2	PIN, HINGE	
2	FB3-0122-000		1	COVER, PCB	
3	FB4-8726-030		1	PANEL, REAR	
4	FB4-8727-000		1	COVER, PILLAR	
5	FB4-8728-000		2	COVER, FOOT	
6	FB4-8813-000		2	PLATE, SIDE GUIDE	
7	FB4-8828-000		1	PANEL, SADDLE, RIGHT	
8	FF5-8527-000		1	COVER, UPPER, REAR	
9	FG6-3051-050		1	SLIDE GUIDE ASSEMBLY	
9A	FB4-8271-020		1	GUIDE, SLIDE, UPPER	
9B	FB4-8284-000		2	PLATE, SLIDE, 1	
9C	FB4-8285-020		4	PLATE, SLIDE, 2	
9D	FB4-8286-000		2	SPRING, LEAF	
10	FG6-3076-000		2	TRAY ASSEMBLY	
10A	FB4-8298-000		1	TRAY, AUXILIARY	
11	FB4-8931-000		1	PANEL, UPPER, 2	
12	FF5-8621-000		1	PANEL, UPPER, 1	
12A	FB4-8722-000		1	GAP TAPE	
12B	FB4-8933-000		1	SPACER, COVER, B	
13	FB4-8953-000		1	DOOR, FRONT	
14	FB4-8954-000		1	PLATE, FRONT DOOR	
15	FG6-7525-000		1	FRONT DOOR ASSEMBLY	
15A	FB4-8237-000		1	PLATE	
15B	FB4-8239-000		1	PLATE, HINGE	
15C	FB4-8248-000		1	SPANNER, ADJUSTING	
15D	FB4-8604-000		2	PLATE, DOOR SWITCH	
15E	FB4-8697-020		1	COVER, SPRING	
15F	FB4-8698-000		1	SPRING, LEAF	
15G	FB5-9290-000		1	HINGE, DOOR, LOWER	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q10 - 15H	FB5-9072-000		1	LABEL, STAPLER	
15J	XA9-0605-000		12	SCREW,P,M4X8	
16	FB4-8273-000		1	WALL, LOADING, CENTER	
17	FB4-8274-000		1	WALL, LOADING, LOWER	
18	FB4-8275-020		1	SHUTTER	
19	FB4-8276-000		2	PLATE, HURDLE, 1	
20	FB4-8277-000		1	PLATE, HURDLE, 2	
21	FB4-8278-000		1	PLATE, HURDLE, 3	
22	FB4-8279-000		1	GUIDE, SHUTTER	
23	FB4-8280-020		2	MOUNT, SHUTTER	
24	FB4-8282-000		2	MOUNT	
25	FB4-8283-000		1	SUPPORT	
26	FB4-8288-000		1	PLATE	
27	FB4-8344-020		1	PLATE, GROUNDING	
28	FS7-2082-000		2	SPRING, TENSION	
29	XA9-0605-000		AR	SCREW,P,M4X8	
30	FB4-8861-000		1	TRAY, DELIVERY SUB	
31	FB4-8871-000		1	LEVER, TRAY SENSOR, 2	
32	FB4-8874-000		1	SPRING, TORSION	
33	FF3-3865-000		1	CABLE, SADDLE SUB TRAY	J1014,1021
34	WG8-5362-000		1	IC, TLP1241, PHOTO-INTERRUPTER	PI42 J1014
35	XA9-0722-000		8	SCREW,RS,M4X12	
36	XA9-0629-000		AR	SCREW,RS,M4X8	
501	XB4-7401-009		2	SCREW,TAPPING,TRUSS HEAD,M4X10	

INTERNAL COMPONENTS 1




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q11 -	NPN		RF	INTERNAL COMPONENTS 1	
1	FB3-7881-000		1	KNOB	
2	FB4-8250-000		2	STOPPER, TRAY	
3	FB4-8350-000		1	COVER, CONNECTOR	
4	FB5-9065-000		1	COVER, FRONT FRAME	
5	FB5-9070-000		1	COVER, STAPLER FRAME	
6	FF5-9617-000		1	HANDLE	
7	FB5-2692-000		1	LABEL, HANDLE	
8	FH3-2630-000		1	SWITCHING REGULATOR PCB UNIT	100V
	FH3-2631-000		1	SWITCHING REGULATOR PCB UNIT	208/230V
9	FS5-9579-000		1	SCREW, STEPPED, M3	
10	FS7-2171-000		1	SPRING, COMPRESSION	
11	FH6-1579-000		1	FAN	FM2 J72
12	FF5-8461-000		1	LATCH, FRONT	
13	XA9-0629-000		AR	SCREW,RS,M4X8	
14	FB5-9192-000		1	COVER, SADDLE SWITCH	
15	XA9-0732-000		AR	SCREW,RS,M4X8	
16	FF5-9616-000		1	COVER, SADDLE INNER	
16A	FB5-2690-000		1	LABEL	
16B	FB5-2691-000		1	LABEL	
16C	FB5-2709-000		1	LABEL	
17	FG3-1837-000		1	CABLE, OPERATION TRAY CONNECT	J38,45,49,55,58,61 J63,104-107,111,112 J128,712,719,1123
17A	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	J49
17B	VS1-6318-004		1	CONNECTOR, SNAP, TIGHT	J61
17C	VS1-6319-016		1	CONNECTOR, SNAP, TIGHT	J63
17D	VS1-6319-018		1	CONNECTOR, SNAP, TIGHT	J45
17E	VS1-6319-022		1	CONNECTOR, SNAP TIGHT	J38
18	FG3-1838-000		1	CABLE, STAPLER MAIN CONNECTING	J54,57,76,80,110,124 J127,771-773,776,971
19	FG3-1852-000		1	CABLE, SADDLE CONNECTING	J102,122,126,713 J1061,1088-1090,1125

INTERNAL COMPONENTS 2




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q12 -	NPN		RF	INTERNAL COMPONENTS 2	
1	FB1-7214-000		1	KNOB	
2	XA9-0629-000		AR	SCREW,RS,M4X8	
3	FH7-6336-000		1	MICROSWITCH	MSW8 J57
4	FG3-1832-000		1	OPTION SWITCH PCB ASSEMBLY	
5	FB5-9135-000		1	COVER, OPTION SWITCH	
6	FF5-9618-000		1	COVER, SWITCH	
6A	FB5-2694-000		1	LABEL, WARNING	
7	FF6-1219-000		1	COVER, INNER	
7A	FB4-8717-000		1	LABEL, GUIDE, 1	
8	XA9-0605-000		1	SCREW,P,M4X8	
9	FB5-2662-000		1	SPRING, LEAF	
10	FB5-2636-000		1	SPACER, WASTE	
11	WG8-5382-000		1	PHOTO-INTERRUPTER	PI26 J1002
12	XA9-0732-000		AR	SCREW,RS,M4X8	
13	FG3-1865-000		1	CABLE, HOPPER CROSSMEMBER	J748,941,1002
14	FG3-0089-000		1	PUNCH WASTE SENSOR PCB ASS'Y	
15	4S1-9002-000		6	SCREW,M4X6	
16	FS2-6559-000		1	ROLLER	
17	FS5-3794-000		1	GEAR, 30T/PULLEY, 24T	
18	FB5-9287-000		1	SUPPORT, SWITCH	
19	FS5-9438-000		2	SCREW,STEPPED	
20	FS7-2646-000		1	SPRING, TENSION	
21	XA9-1302-000		2	SCREW,MACH.,TRUSS HEAD,M3X14	
22	FB5-2656-000		1	SPACER, HOPPER	
501	XB1-2300-409		3	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XB4-7400-809		1	SCREW,TAPPING,TRUSS HEAD,M4X8	
503	XD2-1100-642		1	RING,E	
504	XB1-2300-609		4	SCREW,MACH.,TRUSS HEAD,M3X6	
505	XB6-7400-606		1	SCREW,TP,M4X6	

INTERNAL COMPONENTS 3




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q13 -	NPN		RF	INTERNAL COMPONENTS 3	
1	FB4-8240-000		2	HINGE, DOOR, LOWER	
2	FB5-2687-000		1	COVER, POWER SUPPLY	
3	FC2-4262-000		1	RAIL, SLIDE, UPPER	
4	FF5-5811-000		1	SUPPORT, RELEASE, FRONT	
5	FF5-5812-000		1	SUPPORT, RELEASE, REAR	
6	XA9-0629-000		AR	SCREW,RS,M4X8	
7	FG3-1851-000		1	CABLE, DC POWER SUPPLY	J85,88,711,718
8	XB7-2201-209		4	NUT,HEX,M12	
9	FB4-8238-000		4	PLATE, CASTER	
10	XZ9-0465-000		4	CASTER	
11	FB4-8817-000		1	ARM, DELIVERY TENSION	
12	FB4-8818-000		1	MOUNT, TENSION ARM	
13	FB4-8819-000		1	ARM, DELIVERY TENSION, 2	
14	FS5-6545-000		1	ROLLER	
15	FS7-2143-000		1	SPRING, TENSION	
16	FS7-2148-000		1	SPRING, COMPRESSION	
17	FB5-2681-000		1	MOUNT, FRONT RAIL, 1	
18	FB5-2682-000		1	MOUNT, REAR RAIL, 1	
19	FF5-9615-000		1	MOUNT, RAIL, 4	
20	XA9-0687-000		7	SCREW,MACH.,TRUSS HEAD,M4X8	
21	XZ9-0520-000		1	RAIL, SLIDE, 4	
22	FB4-8807-000		1	MOUNT, RAIL, 2	
23	XZ9-0521-000		1	RAIL, SLIDE, 5	
24	FB2-4117-000		1	SPRING, LEAF	
25	FB2-4120-000		1	ARM, SWITCH, C	
26	FF5-4231-000		1	ARM, SWITCH, C	
27	FS6-2368-000		1	SPRING, TENSION	
28	FB4-8815-000		1	MOUNT, UPPER GUIDE	
29	FB4-8816-000		1	SPRING, TORSION	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q13 - 30	FF5-8639-000		1	PLATE, UPPER GUIDE	
31	FB3-9233-000		2	GUIDE, CABLE	
32	FB3-9234-000		2	HOLDER, CABLE GUIDE	
33	XA9-0732-000		AR	SCREW,RS,M4X8	
34	FG3-1835-000		1	CABLE, SADDLE	J1016,1017,1019,1034 J1060,1061,1125
34A	VS1-5057-008		1	CONNECTOR, SNAP TIGHT	J1017
34B	VS1-5057-009		1	CONNECTOR, SNAP TIGHT	J1019
34C	VS1-6319-016		1	CONNECTOR, SNAP, TIGHT	J1061
35	FB4-8872-000		1	SPRING, GROUNDING	
36	FB5-9043-000		1	HOLDER, STAPLER CABLE, UPPER	
37	FB5-9044-000		1	HOLDER, STAPLER CABLE, LOWER	
38	FB4-8821-000		2	PLATE, ARM	
39	XA9-0722-000		2	SCREW,RS,M4X12	
501	XB1-2400-609		AR	SCREW,MACH.,TRUSS HEAD,M4X6	
502	XB6-7400-609		1	SCREW,TP,M4X6	
503	XD2-1100-502		1	RING,E	
504	XD2-1100-642		1	RING,E	
505	XB1-2300-609		AR	SCREW,MACH.,TRUSS HEAD,M3X6	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q14 -	FG6-7558-000		1	SADDLE DELIVERY TRAY ASSEMBLY	
1	FB4-8863-000		2	LEVER, TRAY SENSOR	
2	FB4-8864-000		2	COVER, TRAY SENSOR	
3	FB4-8865-000		1	FLAG, TRAY	
4	FB4-8866-000		2	SPRING, TORSION	
5	FB4-8868-000		1	PLATE, BELT LOCK	
6	FF5-8585-000		1	STOPPER, TRAY, 2	
6A	FB4-8873-000		1	RUBBER, STOPPER	
7	FS7-2142-000		1	SPRING, TENSION	
8	WG8-5382-000		3	PHOTO-INTERRUPTER	PI41,43,44 J1024,1029,1022
9	XA9-0605-000		12	SCREW,P,M4X8	
10	XF2-1330-360		1	BELT, TIMING	
11	FG3-0973-000		1	CABLE, SADDLE TRAY	J1014,1017,1019,1020 J1022,1029
11A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1014
11B	VS1-5057-008		1	CONNECTOR, SNAP TIGHT	J1020
12	FF5-8586-000		1	PLATE, TRAY TENSION	
13	FS6-0066-000		1	PULLEY, 35T	
14	FB5-9258-000		1	BLOCK, TRAY STOPPER	
15	FB5-9259-000		1	COVER, TRAY STOPPER	
16	FF6-1214-000		1	MOUNT, TRAY STOPPER	
16A	FB4-8873-000		1	RUBBER, STOPPER	
17	FS7-2645-000		3	SPRING, TENSION	
18	FB4-8872-000		1	SPRING, GROUNDING	
19	FC1-7883-000		1	ROLLER, TENSIONER	
20	FF3-3866-000		1	CABLE, SADDLE TRAY MOTOR	J1020,1024,1025
21	FF5-8583-000		1	PLATE, TENSION, 2	
22	XA9-0628-000		1	SCREW,RS,M4X8	
23	FH6-1911-000		1	MOTOR, STEPPING, DC	M49 J1025
24	FS5-3795-000		1	GEAR, 14T/PULLEY, 40T	
25	FS5-3796-000		1	GEAR, 80T/PULLEY, 36T	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q14 - 26	FS5-6381-000		1	FLANGE	
27	FS5-6547-000		1	FLANGE	
28	FS7-2149-000		1	SPRING, TENSION	
29	XF2-1121-340		1	BELT, TIMING	
30	FB2-7897-000		1	PLATE, ADJUSTING, FRONT	
31	FB2-7898-000		1	PLATE, PIVOT, FRONT	
32	FB2-7899-000		1	SHAFT, PIVOT, FRONT	
33	FB2-7900-000		1	SPRING, LEAF	
34	FB2-8506-000		1	ADJUSTER	
501	XD2-1100-642		2	RING,E	
502	XB4-7400-806		2	SCREW,TAPPING,TRUSS HEAD,M4X8	
503	XB1-2300-609		2	SCREW,MACH.,TRUSS HEAD,M3X6	
504	XB1-2400-609		3	SCREW,MACH.,TRUSS HEAD,M4X6	
505	XD2-1100-502		3	RING,E	

FIGURE Q15 POWER CORD TERMINAL ASSEMBLY





FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q15 -	FG6-7519-000		1	POWER CORD TERMINAL ASSEMBLY	100V SEE NOTE
	FG6-7607-000		1	POWER CORD TERMINAL ASSEMBLY	208/230V SEE NOTE
1	FF3-3613-000		1	CORD, POWER	100V P1 J1122
	FG3-1867-000		1	CODE, POWER SUPPLY	208/230V P2 J1127
1A	VS1-6380-003		1	CONNECTOR, 3P, FEMALE	J1122,1127
1B	WS3-5292-000		2	SOCKET CONTACT	
1C	WT1-5156-000		1	CLIMP-STYLE TERMINAL	208/230V
1D	WT2-0260-000		1	BUSHING (NYLON (R))	208/230V
1E	FB5-9132-000		1	PLATE, BUSHING	208/230V
2	RH7-1289-000		1	FAN	FM1 J715
3	WD3-5075-000		1	BREAKER, CIRCUIT	CB1
4	FG3-1842-000		1	CABLE, AC POWER SUPPLY	J84,1122,1127
4A	WT2-5041-000		1	TIE, CABLE	
501	XB1-2300-609		2	SCREW,MACH.,TRUSS HEAD,M3X6	
502	XB1-2400-606		4	SCREW,MACH.,TRUSS HEAD,M4X6	100V
	XB1-2400-606		5	SCREW,MACH.,TRUSS HEAD,M4X6	208/230V
503	XB1-2403-009		2	SCREW,MACH.,TRUSS HEAD,M4X30	
504	XB2-7400-607		1	SCREW,W/WASHER,M4X6	
505	XD1-4200-402		1	WASHER,TOOTHED LOCK	100V
	XD1-4200-402		2	WASHER,TOOTHED LOCK	208/230V

FIGURE Q16 MAIN BODY CABLE ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q15.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q16 -	FG3-1841-000		1	MAIN BODY CABLE ASSEMBLY	SEE NOTE
1	FB4-8236-000		1	PLATE, CABLE, HOLDER	
2	FH2-6481-000		1	HOUSING	J1121
3	FH2-6482-000		1	COVER, PLUG, A	
4	FH2-6483-000		1	COVER, PLUG, B	
5	FH2-6487-000		1	CLAMP, CABLE	
6	VS1-5452-007		2	CONNECTOR, 7P, FEMALE	J717,1121
7	WS3-5044-000		1	SOCKET, CONTACT, 18-24AWG	
8	WT1-0237-000		1	TERMINAL, RING	
9	WE8-5496-000		1	FERRITE CORE	

FIGURE Q17




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q17 -	FG6-3326-000		1	HOPPER ASSEMBLY	
1	FF5-8626-000		2	PRISM	
2	FB5-2647-000		1	LABEL	
501	XB4-7300-806		2	SCREW,TAPPING,TRUSS HEAD,M3X8	
502	XB4-7401-207		6	SCREW,TAPPING,TRUSS HEAD,M4X12	

FIGURE Q18 STACKER TRAY FRAME ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q18 -	FG6-7530-000		1	STACKER TRAY FRAME ASSEMBLY	
1	FB4-8302-000		2	COVER, GEAR	
2	FB4-8306-000		1	PLATE, STOP	
3	FB4-8310-000		1	COVER, DRIVER	
4	FS5-3744-000		1	PULLEY, 50T	
5	XA9-0629-000		AR	SCREW,RS,M4X8	
6	XA9-0633-000		1	SCREW,W/WASHER,M4X8	
7	XF9-0696-000		1	BELT, TIMING	
8	XG9-0365-000		4	BEARING, BALL	
9	FB4-8320-000		1	LEVER, SENSOR	
10	FB4-8321-000		1	COVER, SENSOR	
11	FB4-8328-000		1	SPRING, TORSION	
12	WG8-5382-000		2	PHOTO-INTERRUPTER	PI17,18 J92,93
13	FS7-0346-000		2	GEAR, 40T	
14	FS7-0347-000		2	GEAR, 24T	
15	FG3-1828-000		1	AREA SENSOR PCB ASSEMBLY	J90
16	FB4-8307-000		1	RATCHET	
17	FS5-6307-000		1	WASHER	
18	FS7-0349-000		1	GEAR, RATCHET, 20T	
19	FS7-2081-000		1	SPRING, COMPRESSION	
20	XD9-0151-000		1	WASHER	
21	FG2-9785-000		1	DRIVER PCB ASSEMBLY	
22	FB4-8337-000		1	PLATE, TRAY STOP	
23	FS2-1617-000		4	BEARING, BALL	
24	FB4-8303-000		1	STOPPER, TRAY	
25	FG3-1849-000		1	CABLE, STACKER TRAY	J89,90,92-94,109
26	FG6-3063-000		1	MOTOR ASSEMBLY	
26A	FS7-0351-000		1	GEAR, 27T	
26B	FB4-8339-000		1	TORQUE LIMITER	
26C	FS7-0350-000		1	GEAR, 14T	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q18 - 26D	FH6-1647-000		1	MOTOR, STEPPING, DC24V	M12 J89
26E	XA9-0629-000		2	SCREW,RS,M4X8	
501	XB6-7400-609		10	SCREW,TP,M4X6	
502	XD2-1100-642		14	RING,E	
503	XD3-2300-162		3	PIN,DOWEL	
504	XD2-1100-322		1	RING,E	
505	XD3-2200-142		1	PIN,DOWEL	
506	XB1-2300-409		3	SCREW,MACH.,TRUSS HEAD,M3X4	
507	XB1-2301-209		2	SCREW,MACH.,TRUSS HEAD,M3X12	
508	XD2-1100-502		2	RING,E	
509	XD2-1100-402		1	RING,E	
510	XD3-2200-162		1	PIN,DOWEL	
511	XB2-6300-607		3	SCREW,W/WASHER,M3X6	

FIGURE Q19 SAMPLE TRAY FRAME ASSEMBLY





FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q19 -	FG6-7531-000		1	SAMPLE TRAY FRAME ASSEMBLY	
1	FB4-8297-000		1	COVER	
2	FB4-8302-000		2	COVER, GEAR	
3	FB4-8304-000		1	STOPPER	
4	FB4-8306-000		1	PLATE, STOP	
5	FB4-8310-000		1	COVER, DRIVER	
6	FB4-8329-000		2	SPRING, LEAF	
7	FS5-3744-000		1	PULLEY, 50T	
8	XA9-0629-000	AR		SCREW,RS,M4X8	
9	XA9-0633-000		1	SCREW,W/WASHER,M4X8	
10	XF9-0696-000		1	BELT, TIMING	
11	XG9-0365-000		4	BEARING, BALL	
12	FB4-8320-000		1	LEVER, SENSOR	
13	FB4-8321-000		1	COVER, SENSOR	
14	FB4-8328-000		1	SPRING, TORSION	
15	WG8-5382-000		2	PHOTO-INTERRUPTER	PI19,20 J86,83
16	FS7-0346-000		2	GEAR, 40T	
17	FS7-0347-000		2	GEAR, 24T	
18	FB4-8307-000		1	RATCHET	
19	FS5-6307-000		1	WASHER	
20	FS7-0349-000		1	GEAR, RATCHET, 20T	
21	FS7-2081-000		1	SPRING, COMPRESSION	
22	XD9-0151-000		1	WASHER	
23	FG2-9785-000		1	DRIVER PCB ASSEMBLY	
24	FB4-8303-000		1	STOPPER, TRAY	
25	FS2-1617-000		4	BEARING, BALL	
26	FG6-3063-000		1	MOTOR ASSEMBLY	
26A	FS7-0351-000		1	GEAR, 27T	
26B	FB4-8339-000		1	TORQUE LIMITER	
26C	FS7-0350-000		1	GEAR, 14T	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q19 - 26D	FH6-1647-000		1	MOTOR, STEPPING, DC24V	M13 J81
26E	XA9-0629-000		2	SCREW,RS,M4X8	
27	FB4-8336-000		1	PLATE, TRAY STOPPER	
28	XA9-0605-000		1	SCREW,P,M4X8	
29	WC4-5159-000		1	SWITCH, MICRO	MSW3 J87
30	FG3-1850-000		1	CABLE, SAMPLE TRAY	J81-83,86,87,113,114
31	FG3-1828-000		1	AREA SENSOR PCB ASSEMBLY	J82
501	XB6-7400-609		10	SCREW,TP,M4X6	
502	XD2-1100-642		14	RING,E	
503	XD3-2300-162		3	PIN,DOWEL	
504	XD2-1100-322		1	RING,E	
505	XD3-2200-142		1	PIN,DOWEL	
506	XB1-2300-409		3	SCREW,MACH.,TRUSS HEAD,M3X4	
507	XB1-2301-209		2	SCREW,MACH.,TRUSS HEAD,M3X12	
508	XD2-1100-502		2	RING,E	
509	XD2-1100-402		1	RING,E	
510	XD3-2200-162		1	PIN,DOWEL	
511	XB2-6300-607		3	SCREW,W/WASHER,M3X6	

FIGURE Q20 OPERATION ASSEMBLY (1/3)



NOTE : This assembly includes the assemblies shown in Figure Q21, Q22, Q23 and Q24.

FIGURE Q20 OPERATION ASSEMBLY (2/3)




FIGURE Q20 OPERATION ASSEMBLY (3/3)





FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q20 -	FG6-7458-000		1	OPERATION ASSEMBLY	SEE NOTE
1	4A1-0746-000		1	PULLEY	
2	FA5-5377-000		1	PULLEY	
3	FB4-8430-000		1	FLAG	
4	FB4-8431-000		1	COVER, SWITCH	
5	FB4-8453-000		1	LINK, SHUTTER	
6	FB4-8457-000		1	PLATE, SHUTTER GEAR	
7	FB4-8458-000		1	SPRING, LEAF	
8	FB4-8459-000		1	SHAFT	
9	FB4-8460-000		1	RATCHET, SHUTTER	
10	FB5-9016-000		1	HOLDER, CABLE	
11	FF5-8494-000		1	GUIDE, CABLE	
12	FS1-1189-000		1	BUSHING	
13	FS1-1213-000		1	BUSHING	
14	FS1-9078-000		4	SCREW, STEPPED, M4	
15	FS2-3470-000		3	PULLEY, 20T	
16	FS2-3504-000		1	PULLEY, 24T	
17	FS2-3514-000		1	PULLEY, 30T	
18	FS2-6466-000		3	FLANGE, ROLLER	
19	FS2-6581-000		1	ROLLER	
20	FS5-3748-000		1	PULLEY, 26T	
21	FS5-3752-000		1	PULLEY, IDLER, 26T	
22	FS7-0358-000		1	PULLEY, 26T/GEAR, 19T	
23	FS7-2088-000		5	SPRING, TENSION	
24	FS7-2093-020		2	SPRING, TENSION	
25	FS7-2633-000		4	SPRING, TENSION	PI12,14,15,32 J62,67,68,34
26	FU3-0004-000		1	GEAR, WORM	
27	WG8-5382-000		4	PHOTO-INTERRUPTER	
28	XG9-0459-000		2	BEARING, BALL	
29	XA9-0629-000	AR		SCREW, RS, M4X8	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q20 - 30	XA9-0915-000		1	SCREW,P,M3X6	
31	XF2-1114-040		1	BELT, TIMING	
32	XF9-0333-000		1	BELT, TIMING, T125	
33	XF9-0358-000		3	BELT, TIMING	
34	XF9-0591-000		1	BELT, TIMING	
35	XG9-0403-000		2	BEARING, BALL	
36	XG9-0407-000		6	BEARING, BALL, UGF106P12ZZD4ML	
37	FG3-0082-000		1	LED PCB ASSEMBLY	
38	FG3-1979-000		1	PHOTO TRANSISTOR PCB ASSEMBLY	
39	FB5-9073-000		1	ROLLER, DELIVERY, LOWER	
40	FS5-0804-000		1	GEAR, 19T	
41	FF5-8491-000		1	PLATE, TENSIONER	
42	FS5-3750-000		1	PULLEY, 26T/32T	
43	RA1-2483-000		2	FLANGE, PULLEY	
44	FG6-3103-000		1	PADDLE MOTOR ASSEMBLY	
44A	FB4-8413-000		1	COVER, MOTOR	
44B	FF3-3605-000		1	CABLE, PADDLE	J64-66
44C	VS1-5057-005		1	CONNECTOR, SNAP TIGHT	J66
44D	VS1-5057-008		1	CONNECTOR, SNAP TIGHT	J64
44E	FH6-1645-000		1	MOTOR, STEPPING, DC24V	M9 J66
45	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	J44
46	FB4-8427-000		1	LINK, ROLLER, 1	
47	FS1-1452-030		2	BUSHING	
48	FF5-8496-000		1	PLATE, TENSIONER 2	
49	FS5-6237-000		1	ROLLER, IDLER	
50	FB5-9005-000		2	CAM, SWING	
51	FF5-8500-020		2	PLATE, SHUTTER TENSIONER	
52	FH6-1644-000		2	MOTOR, DC 24V	M7,8 J60,59
53	FS2-9394-000		2	SCREW,STEPPED,M3X1.4	
54	FS5-6324-000		2	ROLLER	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q20 - 55	FS7-0355-000		1	PULLEY, 24T/ GEAR, 15T	PI9,10,13 J48,52,65
56	FS7-0356-000		1	GEAR, 28T	
57	FS7-0357-000		2	GEAR, 29T	
58	WG8-5464-000		3	PHOTO INTERRUPTER, TLP1253(C6)	
59	XF2-1117-340		1	BELT, TIMING	
60	FF5-8495-000		1	PLATE, TENSIONER	
61	FS2-6488-000		1	ROLLER	
62	FB4-8421-000		1	PLATE, AUXILIARY, REAR	
63	FB4-8441-000		1	PLATE, SENSOR COVER	
64	FS5-3751-000		1	PULLEY, 18T/60T	
65	XA9-0633-000		2	SCREW,W/WASHER,M4X8	
66	XF2-1111-060		1	BELT, TIMING	
67	FB5-9004-000		1	PULLEY, 48T	
68	FG6-7466-000		3	PADDLE ASSEMBLY	
68A	FB4-8436-000		1	HOLDER, PADDLE	
68B	FB5-9000-000		1	PADDLE	MSW4-7 J38,39,45-50 J52-55,58-64,67-69 J1123
69	FB4-8438-000		1	MOUNT, SWITCH, FRONT	
70	FB4-8439-000		1	MOUNT, SWITCH, REAR	
71	FG3-1846-000		1	CABLE, TRAY, 2	
71A	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	J53
71B	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J50
71C	WT2-5178-000		8	CLIP, CABLE	
72	FS7-0359-000		1	GEAR, 26T	
73	RS1-1042-000		2	BUSHING	
74	FB5-8989-000		1	LINK, STOP, 1	
75	FB5-8990-000		1	LINK, STOP, 2	
76	FB5-8991-000		1	LINK, STOP, 3	
77	FB5-8992-000		1	LINK, STOP, 4	
78	FS5-6900-000		4	ROLLER, LINK	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q20 - 79	FB5-8993-000		1	HOLDER, STOP, 1	
80	FB5-8994-000		1	HOLDER, STOP, 2	
81	FB5-9007-000		4	LINK, STOP	
82	FB5-9017-000		2	SPRING, TORSION	
83	FB5-9018-000		2	SPRING, TORSION	
84	FF6-1164-000		1	PLATE, LINK, FRONT	
84A	FB3-7285-000		2	DAMPER, SHUTTER	
84B	FB5-9011-000		2	SHEET, STOP	
85	FB5-8995-000		1	HOLDER, STOP, 3	
86	FB5-8996-000		1	HOLDER, STOP, 4	
87	FF6-1165-000		1	PLATE, LINK, REAR	
87A	FB3-7285-000		2	DAMPER, SHUTTER	
87B	FB5-9011-000		2	SHEET, STOP	
88	FB5-9021-000		1	LINK, TRAY SOLENOID	
89	FB5-9023-000		1	SPRING, TORSION	
90	FF6-1168-000		1	SUPPORT, SOLENOID	
91	FF6-1169-000		1	SOLENOID	SL4 J44
501	XB1-2300-609		2	SCREW,MACH.,TRUSS HEAD,M3X6	
502	XB1-2400-609		6	SCREW,MACH.,TRUSS HEAD,M4X6	
503	XB6-7300-609		10	SCREW,TP,M3X6	
504	XD1-1106-220		2	SHIM	
505	XD1-1108-220		2	SHIM	
506	XD1-4200-402		2	WASHER,TOOTHED LOCK	
507	XD2-1100-322		22	RING,E	
508	XD2-1100-502		17	RING,E	
509	XD2-1100-642		12	RING,E	
510	XD3-2200-082		1	PIN,DOWEL	
511	XD3-2200-102		1	PIN,DOWEL	
512	XD3-2200-122		5	PIN,DOWEL	
513	XD3-2200-142		4	PIN,DOWEL	


TRAY ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q20.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q21 -	FG6-7469-000		1	TRAY ASSEMBLY	SEE NOTE
1	FB4-8366-000		1	LINK, 2	
2	FB4-8368-020		2	LINK, 1	
3	FB5-8986-000		1	PLATE, SIDE, REAR	
4	FB5-8987-000		1	PLATE, SIDE, FRONT	
5	FB5-8988-000		1	RACK, FRONT	
6	FB5-9020-000		1	RIB, DELIVERY, AUXILIARY	
7	FB5-9024-000		1	SPRING, TORSION	
8	FB5-9027-000		1	FLAG, TRAY SENSOR	
9	FS5-6662-000		2	ROLLER, 1	
10	FS5-6663-000		2	ROLLER, 2	
11	FS7-2643-000		1	SPRING, TENSION	


FIGURE Q22 TRAY FRAME ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q20.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q22 -	FG6-7462-000		1	TRAY FRAME ASSEMBLY	SEE NOTE
1	FA2-5970-000		2	SCREW, STEPPED	
2	FB4-8392-000		1	GUIDE, TRAY CABLE	
3	FF5-8481-000		2	PLATE, TENSION	
4	FS1-9120-000		2	SCREW,STEPPED,M3	
5	FS7-2088-000		2	SPRING, TENSION	
6	FU3-0009-000		2	GEAR, 16T/PULLEY, 30T	
7	RA1-2483-000		2	FLANGE, PULLEY	
8	WG8-5382-000		2	PHOTO-INTERRUPTER	PI7,8 J42,43
9	XA9-0629-000		2	SCREW,RS,M4X8	
10	XF2-1110-240		2	BELT, TIMING	
11	FG3-1845-000		1	CABLE, OPERATION TRAY, 1	J34,39-44
11A	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	J44
11B	VS1-6319-022		1	CONNECTOR, SNAP TIGHT	J39
12	FB4-8376-000		2	MOUNT, MOTOR	
13	FH6-1905-000		2	MOTOR, STEPPING, DC	M4,5 J41,40
501	XB6-7300-609		6	SCREW,TP,M3X6	
502	XD1-4200-402		2	WASHER,TOOTHED LOCK	
503	XB1-2300-609		4	SCREW,MACH.,TRUSS HEAD,M3X6	


FIGURE Q23 TRAY AUXILIARY PLATE ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q20.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q23 -	FG6-7463-000		1	TRAY AUXILIARY PLATE ASSEMBLY	SEE NOTE
1	FF5-8483-000		2	RAIL, TRAY	
2	FH6-1899-000		1	MOTOR, STEPPING, DC	M6 J46
3	FS2-6581-000		1	ROLLER	
4	FS5-3746-000		1	PULLEY, IDLER, 18T/48T	
5	FS5-3747-000		1	PULLEY, 36T	
6	RA1-2483-000		1	FLANGE, PULLEY	
7	XA9-0629-000		3	SCREW,RS,M4X8	
8	XF9-0357-000		1	BELT, TIMING	
9	XF9-0539-000		1	BELT, TIMING	
10	FG6-3086-020		1	AUXILIARY TRAY ASSEMBLY	
10A	FB4-8360-000		2	GUIDE, TRAY, 1	
10B	FB4-8361-000		1	GUIDE, TRAY, 2	
11	WG8-5382-000		1	PHOTO-INTERRUPTER	PI11 J51
12	FG3-1857-000		1	CABLE, AUXILIARY TRAY SENSOR	J50,51
501	XB1-2300-609		2	SCREW,MACH.,TRUSS HEAD,M3X6	
502	XD2-1100-322		1	RING,E	
503	XD2-1100-502		1	RING,E	
504	XD2-1100-642		1	RING,E	

FIGURE Q24 SWING GUIDE ASSEMBLY




NOTE : This assembly is included in the assembly shown in Figure Q20.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q24 -	FG6-7474-000		1	SWING GUIDE ASSEMBLY	SEE NOTE
1	FF5-8486-000		1	LINK, ROLLER, 2	
2	FS5-3748-000		1	PULLEY, 26T	
3	FS7-2632-000		2	SPRING, TENSION	
4	XA9-0605-000		6	SCREW,P,M4X8	
5	XG9-0403-000		11	BEARING, BALL	
6	FB4-8397-000		1	ARM, STOP	
7	FS6-8795-000		1	SEAL, JAM	
8	FB4-8394-000		1	GUIDE, RIB	
9	FB4-8395-000		2	HOLDER, GUIDE RIB	
10	FS7-2089-000		2	SPRING, COMPRESSION	
11	FB4-8442-000		1	GUIDE, RIB, 2	
12	FB5-9033-000		1	ROLLER, FEEDER, UPPER	
13	FS5-6158-000		2	ROLLER, LIFTER	
14	FB4-8404-000		2	BUSHING, RUBBER	
15	FB5-9025-000		1	SPRING, TORSION	
16	FB5-9026-000		1	SPRING, TORSION	
17	FF5-8489-000		1	PLATE, SWING, FRONT	
18	FF5-8490-000		1	PLATE, SWING, REAR	
19	FS5-0804-000		2	GEAR, 19T	
20	FB4-8408-000		2	ELIMINATOR, STATIC CHARGE	
21	FB5-9006-000		2	ELIMINATOR, STATIC CHARGE	
22	FB4-8406-000		1	LEVER, SWITCH	
23	FB4-8407-000		1	SPRING, TORSION	
24	FF5-8493-000		1	GUIDE, HARNESS	
25	XA9-0629-000		1	SCREW,RS,M4X8	MSW2 J53
26	FG3-1861-000		1	CABLE, SWING GUIDE SAFETY SW.	
501	XD1-1108-220		3	SHIM	
502	XD2-1100-642		16	RING,E	
503	XD3-2200-122		1	PIN,DOWEL	


FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q24 - 504	XD1-1108-222		4	SHIM	
505	XD3-2200-142		2	PIN,DOWEL	
506	XB1-2300-409		4	SCREW,MACH.,TRUSS HEAD,M3X4	
507	XB1-2301-409		1	SCREW,MACH.,TRUSS HEAD,M3X14	
508	XD2-1100-502		1	RING,E	

FIGURE Q30 FEEDER ASSEMBLY (1/3)



NOTE : This assembly includes the assemblies shown in Figure Q31, Q32, Q33, Q34, Q35 and Q36.

FEEDER ASSEMBLY (2/3)



FEEDER ASSEMBLY (3/3)




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q30 -	FG6-7495-000		1	FEEDER ASSEMBLY	SEE NOTE
1	FA3-4725-000		1	CATCH, MAGNET	
2	FB3-0123-030		1	HOLDER, SWITCH	
3	FB4-8616-000		1	ROLLER, 2	
4	FB4-8617-000		1	ROLLER, BUFFER	
5	FB4-8619-000		1	ROLLER	
6	FB4-8622-000		1	DEFLECTOR, 1	
7	FB4-8623-000		1	DEFLECTOR, 2	
8	FB4-8624-000		2	ARM, DEFLECTOR	
9	FB4-8713-000		2	SHEET, PCB	
10	FB5-2674-000		1	MOUNT	MSW1 J1124
11	FB5-9102-000		1	ROLLER, K1, FRONT	
12	FF3-3746-000		1	FRONT DOOR SWITCH UNIT	
13	FF5-3800-000		1	PLATE, PIN, 1	
14	FA6-0768-020		1	SHEET, STOP	
15	FF5-8529-000		1	MOUNT, TENSIONER	
16	FF5-8532-000		3	PLATE, PIN, 2	
17	FF5-8538-000		1	PLATE, PIN	
18	FF5-8547-000		2	SENSOR PCB ASSEMBLY	
19	FF5-8550-000		1	GUIDE, UPPER	
19A	FA6-0768-020		1	SHEET, STOP	SL1,2 J21,20
20	FF5-8551-000		2	SOLENOID	
21	FF6-1190-000		1	SUPPORT, TENSION	
22	FH6-1898-000		1	MOTOR, STEPPING, DC	
23	FS1-9005-000		3	SCREW, STEPPED, M4	
24	FS2-1528-000		4	BUSHING	M2 J96
25	FS2-3488-000		5	PULLEY, 32T	
26	FS2-3527-000		1	PULLEY, 48T	
27	FS2-9394-000		1	SCREW, STEPPED, M3X1.4	
28	FS5-3905-000		1	PULLEY, 48T	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q30 - 29	FS5-6243-000		1	ROLLER	
30	FS5-6381-000		1	FLANGE	
31	FS5-6487-000		2	WASHER	
32	FS5-6905-000		4	ROLLER, LEVER, 2	
33	FS5-9360-000		2	SCREW, STEPPED, M4	
34	FS7-2107-000		2	SPRING, TENSION	
35	FS7-2108-000		2	SPRING, TENSION	
36	FS7-2109-000		2	SPRING, TENSION	
37	FS7-2110-000		2	SPRING, TENSION	
38	FS7-2111-000		1	SPRING, TENSION	
39	FS7-2112-000		2	SPRING, TENSION	
40	FS7-2121-000		1	SPRING, TENSION	
41	FU3-0007-000		1	GEAR, 30T	
42	XA9-0605-000		7	SCREW, P, M4X8	
43	XA9-0687-000		1	SCREW, MACH., TRUSS HEAD, M4X8	
44	XA9-0732-000		AR	SCREW, RS, M4X8	
45	XF2-1312-160		1	BELT, TIMING	
46	XF2-1606-610		1	BELT, TIMING	
47	XF9-0693-000		1	BELT, TIMING	
48	XF9-0694-000		1	BELT, TIMING	
49	XF9-0695-000		2	BELT, TIMING	
50	XG9-0365-000		10	BEARING, BALL	
51	FG3-0082-000		1	LED PCB ASSEMBLY	
52	FG3-1979-000		1	PHOTO TRANSISTOR PCB ASSEMBLY	
53	FG3-1843-000		1	CABLE, PAPER FEED, FRONT	J21, 23, 25, 26, 28, 30 J31, 35, 70, 98-100, 108
53A	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	J118, 119, 721, 1124 J21
53B	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J30
53C	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J31
53D	VS1-6318-005		1	CONNECTOR, SNAP TIGHT	J35

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q30 - 54	FG3-1844-000		1	CABLE, PAPER FEED, REAR	J19,20,72,91,95-97 J101,103,115-117,120 J121,714,716,741,743 J1065-1067,1128
54A	VS1-5057-002		2	CONNECTOR, SNAP TIGHT	J20,91
54B	VS1-5057-003		2	CONNECTOR, SNAP TIGHT	J72,1067
54C	VS1-5057-009		1	CONNECTOR, SNAP TIGHT	J1066
54D	VS1-5057-010		1	CONNECTOR, SNAP TIGHT	J1065
55	FF5-8534-000		3	PLATE, PIN	
56	FF3-3600-000		1	CABLE, LOWER PASS SENSOR	J28,29
56A	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J28
57	FB4-8641-000		2	FLAG, SENSOR	
58	FB4-8718-000		2	SPRING, TORSION	
59	FF3-3599-000		1	CABLE, BUFFER PASS	J22-24
59A	VS1-5057-007		1	CONNECTOR, SNAP TIGHT	J23
60	FF5-8509-000		1	HOLDER, SENSOR	
61	FB4-8721-000		1	SHEET	
62	WG8-5382-000		6	PHOTO-INTERRUPTER	PI1-6 J100,70,24,33,25,27
63	FG3-0081-000		1	SENSOR PCB ASSEMBLY	
64	FB4-8661-000		1	HOLDER, SENSOR	
65	FF3-3604-000		1	CABLE, PAPER FEED SENSOR	J26,27
65A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J26
66	FB4-8618-000		1	ROLLER, NON-SORT	
67	FC2-5102-000		2	ROLLER, DELIVERY, 1	
68	FS5-6661-000		2	FLANGE	
69	FF5-8548-060		1	MOUNT, SENSOR	
70	FB1-7099-020		1	LEVER, STOP	
71	FB5-9104-000		2	ELIMINATOR, STATIC CHARGE	
72	FF5-8523-000		3	PLATE, PIN	
73	FF5-8530-000		1	MOUNT, TENSIONER, 2	
74	FF5-8531-000		1	MOUNT, TENSIONER, 3	
75	FS1-9255-000		1	SCREW, STEPPED, M4	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q30 - 76	FS7-2636-000		1	SPRING, TENSION	
77	FU3-0005-000		1	GEAR, 25T	
78	FU3-0006-000		1	GEAR, 26T	
79	XG9-0403-000		5	BEARING, BALL	
80	FB5-9075-000		1	GUIDE, STAPLER	
81	FB5-9079-000		1	ROLLER, S2	
82	FB5-9080-000		2	ROLLER	
83	FB5-9103-000		2	BELT, PAPER FEED	
84	FF6-1191-000		1	GUIDE, STAPLER, FRONT	
85	FF6-1192-000		1	GUIDE, STAPLER, REAR	
86	FF6-1193-000		1	GUIDE, STAPLER, CENTER	
87	FS5-0677-000		1	GEAR, 26T	
88	FS5-6901-000		1	ROLLER	
89	FB4-8592-000		1	COVER, RIB	
90	FB4-8668-000		1	GUIDE, PAPER	
91	FB4-8690-000		1	GUIDE, CABLE	
92	FF6-1194-000		1	SUPPORT, SENSOR	
93	FS7-2118-000		1	SPRING, COMPRESSION	
94	FG3-1854-000		1	CABLE, PAPER DELIVERY SENSOR	J31,33
95	FF6-1242-000		1	MOTOR, DC	M1 J95
96	FS5-3794-000		1	GEAR, 30T/PULLEY, 24T	
97	FS5-6941-000		1	SPACER, S2	
501	XB1-2300-409		5	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XB1-2300-609		6	SCREW,MACH.,TRUSS HEAD,M3X6	
503	XB1-2400-609		AR	SCREW,MACH.,TRUSS HEAD,M4X6	
504	XB6-7300-609		2	SCREW,TP,M3X6	
505	XD2-1100-242		11	RING,E	
506	XD2-1100-402		4	RING,E	
507	XD2-1100-502		5	RING,E	
508	XD2-1100-642		29	RING,E	


FIGURE Q31 SORT GUIDE ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q30.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q31 -	FG6-7509-000		1	SORT GUIDE ASSEMBLY	SEE NOTE
1	FB4-8701-000		1	SPRING, TORSION	
2	FB4-8702-000		1	SPRING, TORSION	
3	FB4-8703-000		1	SPRING, TORSION	
4	FB4-8704-000		1	SPRING, TORSION	
5	FF5-3804-000		2	PLATE, PIN, 1	
6	FS1-9168-000		2	SCREW, STEPPED, M4X5	
7	FB4-8620-000		1	ROLLER	
8	FF5-8524-030		1	GUIDE, SORT	
9	FS5-6657-000		2	BUSHING	
10	FS7-2114-000		2	SPRING, TENSION	
11	XG9-0362-000		2	BUSHING, CONDUCTIVE	
12	FB5-9006-000		2	ELIMINATOR, STATIC CHARGE	
13	FB5-9098-000		1	KNOB	
14	FB5-9128-000		1	ELIMINATOR, STATIC CHARGE	
15	FF6-1185-000		2	ROLLER, DELIVERY, 1	
16	FF6-1186-000		2	ROLLER, DELIVERY, 2	
17	XA9-1031-000		1	SCREW, MACH., TRUSS HEAD, M4X8	
18	FB5-9104-000		1	ELIMINATOR, STATIC CHARGE	
19	FB5-9121-000		4	GUIDE, PAPER	
20	FB5-9123-000		1	COVER, SOLENOID	SL5 J36
21	FB5-9124-000		1	LINK	
22	FB5-9011-000		1	SHEET, STOP	
23	FF6-1188-000		2	PLATE, PIN	
24	FF6-1189-000		1	SOLENOID	
25	FS1-1433-000		2	BUSHING	J36,91 J36
26	FS7-2634-000		1	SPRING, TENSION	
27	FG3-1860-000		1	CABLE, SOLENOID	
27A	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
27B	WT2-5565-000		2	CLAMP, CABLE	


PAPER FEED LOWER GUIDE ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q30.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q32 -	FG6-3178-000		1	PAPER FEED LOWER GUIDE ASS'Y	SEE NOTE
1	FB4-8657-000		1	PLATE, SUPPORT	
2	FF5-6194-000		8	ROLLER, FEED	
3	FB4-8715-000		1	LABEL, GUIDE	
4	XA9-0605-000		4	SCREW,P,M4X8	
501	XB1-2400-609		8	SCREW,MACH.,TRUSS HEAD,M4X6	


SORT LEFT LOWER GUIDE ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q30.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q33 -	FG6-3179-000		1	SORT LEFT LOWER GUIDE ASSEMBLY	SEE NOTE
1	FB4-8600-000		1	PLATE, SUPPORT	
2	FA6-0768-020		2	SHEET, STOP	
3	FB4-8716-000		1	LABEL, GUIDE	
4	FF5-8536-000		4	ROLLER, FEED	
5	XA9-0605-000		10	SCREW,P,M4X8	


FIGURE Q34 KNURLED BELT DRIVE ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q30.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q34 -	FG6-7506-000		1	KNURLED BELT DRIVE ASSEMBLY	SEE NOTE
1	FF6-1196-000		1	PLATE, PIN	
2	FH6-1906-000		1	MOTOR, STEPPING, DC	M20 J37
3	FS1-1189-000		1	BUSHING	
4	FS1-1202-000		1	BUSHING	
5	FS5-0801-020		1	GEAR, 39T	
6	FS6-0541-000		1	GEAR, 20T	
7	FS7-2635-000		1	SPRING, TENSION	
8	FU3-0008-000		1	GEAR, 40T	
9	WG8-5382-000		1	PHOTO-INTERRUPTER	PI31 J32
10	XA9-0195-000		2	SCREW,P,M3X8	
11	FG3-1856-000		1	CABLE	J30,32,35,37
12	FB5-9082-000		1	LEVER, VARIABLE	
13	FB5-9083-000		1	RACK, LEVER	
14	FS5-6904-000		2	ROLLER, LEVER, 1	
15	FS5-6905-000		2	ROLLER, LEVER, 2	
16	FS5-6908-000		6	ROLLER, LEVER, 3	
17	FB5-9094-000		2	GUIDE, KNURLED	
501	XB1-2300-409		2	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XB1-2400-609		3	SCREW,MACH.,TRUSS HEAD,M4X6	
503	XD2-1100-502		3	RING,E	
504	XD2-1100-642		1	RING,E	
505	XD3-2200-142		2	PIN,DOWEL	
506	XD2-1100-242		8	RING,E	

DELIVERY MOTOR ASSEMBLY



NOTE : This assembly is included in the assembly shown in Figure Q30.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q36 -	FG6-7501-000		1	PAPER DELIVERY MOTOR ASSEMBLY	SEE NOTE
1	FB4-8630-000		2	MOUNT, PCB	
2	FH6-1652-000		1	MOTOR, STEPPING, DC24V	M3 J97
3	FG2-9785-000		2	DRIVER PCB ASSEMBLY	
501	XB1-2300-609		8	SCREW,MACH.,TRUSS HEAD,M3X6	
502	XB1-2301-209		4	SCREW,MACH.,TRUSS HEAD,M3X12	
503	XB1-2400-609		2	SCREW,MACH.,TRUSS HEAD,M4X6	

FIGURE Q37 UPPER FEEDER ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q37 -	FG6-3170-000		1	UPPER FEEDER ASSEMBLY	
1	FB1-7173-000		2	PIN, HINGE	
2	FB4-8663-000		1	GRIP	
3	FS7-2122-000		1	SPRING, COMPRESSION	
4	FS7-2123-000		1	SPRING, COMPRESSION	
5	FS7-2124-000		1	SPRING, COMPRESSION	
6	XA9-0870-000		AR	SCREW,P,M4X10	
7	FB4-8712-000		1	PLATE, SUPPORT	
8	FF5-8525-000		1	COVER, UPPER	
8A	FC2-3140-000		4	CATCH, MAGNET	
9	XA9-0629-000		1	SCREW,RS,M4X8	
10	FA6-2369-000		2	BLOCK, SLIDER	
11	FF5-8540-000		1	MOUNT, SPRING, 1	
12	FF5-8541-000		1	MOUNT, SPRING, 2	
13	FS7-2120-000		1	SPRING, COMPRESSION	
14	FS7-2125-000		1	SPRING, COMPRESSION	
15	FB4-8682-000		1	SPRING, LEAF, GROUNDING	
16	FB4-8720-000		1	ELIMINATOR, STATIC CHARGE	
17	FF5-6194-000		8	ROLLER, FEED	
18	FF5-8537-000		2	ROLLER, FEED	
19	FS5-6357-000		2	ROLLER, DELIVERY	
20	XA9-0591-000		2	SCREW,M3X8	
21	FB3-0087-000		2	SPRING, LEAF	
501	XD2-1100-322		4	RING,E	
502	XD1-1107-239		2	SHIM	
503	XD2-1100-402		2	RING,E	
504	XD2-2100-502		2	RING,GRIP	

FIGURE Q40 STAPLER MOUNT ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q40 -	NPN		RF	STAPLER MOUNT ASSEMBLY	
1	FB5-9054-000		2	HOLDER, CABLE	
2	FB5-9061-000		1	FLAG, SENSOR	
3	FS5-3907-000		1	PULLEY, 16T/32T	
4	FS5-6324-000		1	ROLLER	
5	FS5-6655-000		2	ROLLER, IDLER	
6	FS5-6903-000		1	ROLLER, STAPLER DRIVE	
7	FS5-9432-000		1	SCREW, STEPPED, M4	
8	FS7-2638-000		1	SPRING, TENSION	
9	XA9-0592-000		1	SCREW, M4X6	
10	FB5-9066-000		2	GUIDE, PAPER	
11	WG8-5382-000		4	PHOTO-INTERRUPTER	PI16,28-30 J73,79,78,77
12	FG3-1839-000		1	CABLE, STAPLER SENSOR	J73,76-79
12A	VS1-6318-012		1	CONNECTOR, SNAP TIGHT	J76
13	FS5-6653-000		2	ROLLER, 1	
14	FF6-1178-000		1	PLATE, CENTER ROLLER, FRONT	
15	FF6-1179-000		1	PLATE, CENTER ROLLER, REAR	
16	FS5-6667-000		4	ROLLER	
17	FS7-2639-000		1	SPRING, TENSION	
18	FS7-2640-000		2	SPRING, TENSION	
19	XA9-0732-000		4	SCREW,RS,M4X8	
20	FG3-1840-000		1	CABLE, STAPLER UNIT	J71,74,774,775
20A	WT2-5178-000		2	CLIP, CABLE	
21	FH6-1900-000		1	MOTOR, STEPPING, DC	M10 J80
22	XF2-1307-060		1	BELT, TIMING	
23	FB5-9042-000		1	BLOCK, STAPLER SLIDER	
24	FB5-9067-000		1	HOLDER, BELT	
25	XA9-1013-000		2	SCREW, M3X8	
26	XF2-1335-060		1	BELT, TIMING	
27	FS5-3908-000		1	PULLEY, 16T	

FIGURE Q41 STAPLER ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q41 -	FG6-7486-000		1	STAPLER ASSEMBLY	
1	FB5-9052-000		1	HOLDER, STAPLER	
2	FB5-9053-000		2	GUIDE, STAPLER SHEET	
3	FB5-9057-000		1	GUIDE, INLET, LOWER	
4	FB5-9069-000		1	SPRING, LEAF	
5	FB5-9074-000		1	SPRING, LEAF	
6	XA9-0915-000		2	SCREW,P,M3X6	
7	FB5-9034-000		1	CARTRIDGE, STAPLER	
8	FB5-9038-000		1	STAPLER ASSEMBLY	M11 J71,74
501	XB6-7300-609		2	SCREW,TP,M3X6	
502	XB6-7400-409		7	SCREW,TP,M4X4	

PUNCH ASSEMBLY



FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q45 -	FG6-7539-000		1	PUNCH ASSEMBLY	K3 TYPE 100/230V
	FG6-7540-000		1	PUNCH ASSEMBLY	K3 TYPE 208V
	FG6-7541-000		1	PUNCH ASSEMBLY	K4 TYPE
	1 FG3-1977-000		1	CABLE, PUNCH PAPER SENSOR	J1001,1131
	1A WT2-5178-000		2	CLIP, CABLE	
2	XA9-0732-000		AR	SCREW,RS,M4X8	
3	FB3-3834-000		1	KNOB	
4	FB5-9161-000		1	LEVER, RELEASE	
5	FB4-8684-000		1	ELIMINATOR, STATIC CHARGE	
6	XZ9-0522-000		2	RAIL, SLIDE	
7	WG8-5382-000		2	PHOTO-INTERRUPTER	PI23,24 J1010,1012
8	XA9-0892-000		2	SCREW,MACH.,TRUSS HEAD,M4X6	
9	FS7-2112-000		1	SPRING, TENSION	
10	FG3-1871-000		1	CABLE, PUNCH UNIT, 2	K3 TYPE 100/230V K4 TYPE J745-747,750,1003 J1005,1007,1009,1013
11	FG3-1870-000		1	CABLE, PUNCH UNIT, 1	K3 TYPE 208V J745-747,750,1003 J1005,1007-1009,1013
	FG6-7548-000		1	PUNCH UNIT, 2 HOLE	K3 TYPE 100/230V
	FG6-7549-000		1	PUNCH UNIT, 2/3 HOLE	K3 TYPE 208V
	FG6-7550-000		1	PUNCH UNIT, 4 HOLE	K4 TYPE
11A	FF6-1207-000		1	MOTOR, DC	M18 J1007
11B	WG8-5382-000		2	PHOTO-INTERRUPTER	K3 TYPE 100/230V K4 TYPE PI22,25 J1009,1013
	WG8-5382-000		3	PHOTO-INTERRUPTER	K3 TYPE 208V PI22,25,33 J1009,1013,1008
11C	FF6-1209-000		2	DUCT, WASTE	K3 TYPE 100/230V
	FF6-1209-000		5	DUCT, WASTE	K3 TYPE 208V
	FF6-1209-000		4	DUCT, WASTE	K4 TYPE
11D	WG8-5464-000		1	PHOTO INTERRUPTER, TLP1253(C6)	PI34 J1003
12	XF2-1308-210		1	BELT, TIMING	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q45 - 13	FB5-9167-000		1	GUIDE, PAPER	
14	FH6-1912-000		1	MOTOR, STEPPING, DC	M19 J1005
15	FS6-0557-000		1	GEAR, 12T/36T	
16	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	J1005
17	FG3-1862-000		1	CABLE, PUNCH SIDE REGISTRATION	J1006,1007,1010,1131
17A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1006
17B	VS1-5057-009		1	CONNECTOR, SNAP TIGHT	J1007
17C	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J1131
18	FG3-1864-000		1	CABLE, PUNCH SHIFT H. POSITION	J1006,1012
19	FH7-7564-000		1	PHOTO-INTERRUPTER	PI21 J1001
20	FS1-9009-000		1	SCREW, STEPPED, M3	
21	FB5-2643-000		1	SCREW, WASTE APPROACH	
22	FB5-2645-000		1	SCREW, WASTE DELIVERY	
23	FB5-2646-000		1	CAM, WASTE CRUSH	
24	FF5-8636-000		1	COVER, SCREW UPPER	
25	FF5-8644-000		1	DUCT, WASTE	
26	FS7-0404-000		1	GEAR, 22T	
27	XG9-0214-000		2	BALL BEARING, NSK MR126JZZMC3	
28	FB5-9148-000		1	HOLDER, BELT, 1	
29	FB5-9149-000		1	HOLDER, BELT, 2	
30	FF6-1205-000		1	SUPPORT, TENSION	
31	FH6-1901-000		1	MOTOR, STEPPING, DC	M17 J744
32	FS2-9394-000		1	SCREW, STEPPED, M3X1.4	
33	FS5-3255-000		1	PULLEY, 24T	
501	XB1-2300-409		7	SCREW, MACH., TRUSS HEAD, M3X4	
502	XB1-2400-409		10	SCREW, MACH., TRUSS HEAD, M4X4	
503	XB4-7400-809		1	SCREW, TAPPING, TRUSS HEAD, M4X8	
504	XB4-7400-609		1	SCREW, TAPPING, TRUSS HEAD, M4X6	
505	XD2-1100-642		6	RING, E	
506	XD3-2200-102		2	PIN, DOWEL	

FIGURE Q46

PUNCH WASTE FEED MOTOR ASSEMBLY





FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q46 -	NPN		RF	PUNCH WASTE FEED MOTOR ASS'Y	
1	FB5-2650-000		1	SPRING, GROUNDING	
2	FS7-0405-000		1	GEAR, 22T/RATCHET	
3	WG8-5382-000		1	PHOTO-INTERRUPTER	PI27 J1004
4	FG3-1863-000		1	CABLE, WASTE FEED MOTOR SENSOR	J742,1004
5	FG6-4847-000		1	MOTOR, DC	M16 J749
501	XB1-2300-409		5	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XB6-7400-607		1	SCREW,TP,M4X6	
503	XD2-1100-642		1	RING,E	


FIGURE Q50 SADDLE ASSEMBLY (1/4)



SADDLE ASSEMBLY (2/4)



FIGURE Q50 SADDLE ASSEMBLY (3/4)



SADDLE ASSEMBLY (4/4)



FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q50 -	NPN		RF	SADDLE ASSEMBLY	
1	FB4-8825-000		1	MOUNT, SPRING	
2	FB5-2684-000		1	STOPPER, SADDLE	
3	FB5-2705-000		1	COVER, SENSOR	
4	FF5-4230-000		1	ARM, HANDLE, C	
5	FS7-2147-000		1	SPRING, TENSION	
6	FB3-7949-000		1	PLATE, SLIDE RAIL	
7	XA9-0732-000	AR		SCREW,RS,M4X8	
8	FB3-7856-000		1	ARM, FRONT	
9	FB3-7869-000		1	PLATE	
10	FB3-7883-000		2	PLATE, COVER	
11	FB3-7912-000		2	ROLLER, WOODRUFF	
12	FB3-7915-000		1	ROLLER, INLET	
13	FB3-7925-000		1	FLAG, ROLLER	
14	FB3-7927-000		2	ROLLER, BACK-UP	
15	FB3-7928-000		1	DEFLECTOR	
16	FB3-7930-000		2	ARM, DEFLECTOR	
17	FB3-7934-000		1	RACK, REAR	
18	FB3-7937-000		2	PLATE	
19	FB3-7939-000		1	PLATE, PRESSURE, FRONT	
20	FB3-7940-000		1	PLATE, PRESSURE, REAR	
21	FB3-7941-000		1	LEVER, STOP	
22	FB3-7943-000		1	GUIDE, SIDE, FRONT	
23	FB3-7944-000		1	GUIDE, SIDE, REAR	
24	FB3-7967-000		1	RACK, FRONT	
25	FB3-7969-000		1	ARM, REAR	
26	FB3-7973-000		1	HOLDER, ROLLER, 2	
27	FB4-8829-000		1	MOUNT, SWITCH	
28	FB4-9011-000		1	ROLLER, HOLDING	
29	FB4-9171-000		2	HOLDER, DOOR SWITCH	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q50 - 30	FB4-9172-000		2	PLATE, SUPPORT	
31	FB5-2697-000		1	DEFLECTOR	
32	FB5-5936-000		2	ROLLER, FOLDING	
33	FB5-5937-000		1	FLAG, SENSOR	
34	FF3-3109-000		1	CABLE, PAPER SENSOR PCB	J800,1054
34A	VS1-5057-005		1	CONNECTOR, SNAP TIGHT	J1054
35	FF3-3878-000		1	CABLE, SADDLE COVER SENSOR	J1027,1028
35A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1028
36	FF5-5809-000		1	PLATE	
37	FF5-5810-000		1	GUIDE, ROLLER	
37A	FB3-7954-000		1	SHEET, ROLLER GUIDE	
38	FH7-5766-000		2	SOLENOID	SL41,42 J1039,1038
39	FS1-1189-000		6	BUSHING	
40	FS1-1213-000		10	BUSHING	
41	FS1-9073-000		1	SCREW,STEPPED,M4	
42	FS1-9076-000		2	SCREW,STEPPED,M4	
43	FS5-1754-000		4	BUSHING	
44	FS5-3576-000		1	PULLEY, 30T	
45	FS5-3577-000		1	PULLEY, 39T	
46	FS5-3580-000		1	PULLEY, 24T	
47	FS5-6550-000		1	FLANGE	
48	FS5-6682-000		2	FLANGE	
49	FS6-0822-000		1	GEAR, 16T/33T	
50	FS6-0823-000		1	GEAR, 16T	
51	FS6-0824-000		1	GEAR, 44T	
52	FS6-0829-000		1	GEAR, 16T/56T	
53	FS6-0830-000		1	GEAR, 16T	
54	FS6-2576-000		2	SPRING, TENSION	
55	FS6-2579-000		1	SPRING, TENSION	
56	FS6-2580-000		2	SPRING, TENSION	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q50 - 57	FS6-2582-000		2	SPRING, TENSION	
58	FS7-2163-000		1	SPRING, TENSION	
59	FS7-2637-000		2	SPRING, TENSION	
60	WG8-5382-000		8	PHOTO-INTERRUPTER	PI46,51,53-58 J1027,1053,1049,1048 J1047,1046,1063,1064
61	XA9-0195-000		2	SCREW,P,M3X8	
62	XF9-0647-000		1	BELT, TIMING	
63	FG3-0535-000		1	SADDLE JAM LED PCB ASSEMBLY	
64	XG9-0453-000		4	BEARING, BALL, 6902ZZNR	
65	FB3-7885-000		1	MOUNT, SENSOR	
66	FB3-7984-000		1	FLAG, SENSOR	
67	FB3-7985-000		1	SPRING, TORSION	
68	FF3-3111-000		1	CABLE, SENSOR	J1062,1063
68A	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J1062
69	FB3-7846-000		3	FLAG, SENSOR	
70	FB3-7847-000		1	MOUNT, SENSOR	
71	FB3-7848-000		3	SPRING, TORSION	
72	FS1-9166-000		3	SCREW, STEPPED	
73	FG5-8408-000		1	PAPER SENSOR PCB ASSEMBLY	
74	FF5-8683-000		1	STATIC CHARGE ELIMINATOR	
75	FF5-9619-000		1	GUIDE, SADDLE, UPPER	
76	FF5-8647-000		2	HOLDER, ROLLER	
77	FS7-2164-000		2	SPRING, TENSION	
78	FB3-7888-000		1	HOLDER, 1	
79	FB3-7889-000		1	HOLDER, 2	
80	FB4-9174-000		1	SPACER, HOLDER	
81	FB5-5939-000		1	PLATE	
82	FF6-1217-000		1	SOLENOID	SL43 J1037
83	FS5-3409-000		1	PULLEY, GUIDE	
84	FH6-1903-000		1	MOTOR, STEPPING, DC	M41 J1040

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q50 - 85	FL6-2067-000		1	PLATE, TENSION	
86	FS5-3909-000		1	PULLEY, 21T/30T	
87	FS5-6547-000		1	FLANGE	
88	FS6-2573-000		1	SPRING, TENSION	
89	XF2-1804-440		1	BELT, TIMING	
90	FB5-2706-000		2	SPRING, LEAF	
91	FF5-8638-000		1	GUIDE, PAPER DELIVERY, UPPER	
91A	FB3-7855-000		1	ELIMINATOR, STATIC CHARGE	
91B	FB4-9167-000		1	SHEET	
92	VS1-5057-002		2	CONNECTOR, SNAP TIGHT	J1037,1039
93	VS1-5352-002		1	CONNECTOR, SNAP TIGHT	J1038
94	FS5-6907-000		2	ROLLER, PAPER DELIVERY	
95	FH6-1906-000		1	MOTOR, STEPPING, DC	M44 J1031
96	FS6-0832-000		1	GEAR, 22T/48T	
97	FB3-7948-000		1	MOUNT, SENSOR	
501	XB1-2400-609		3	SCREW,MACH.,TRUSS HEAD,M4X6	
502	XD2-1100-802		4	RING,E	
503	XB1-2230-809		2	SCREW,MACH.,TRUSS HEAD,M2.3X8	
504	XB1-2300-409		6	SCREW,MACH.,TRUSS HEAD,M3X4	
505	XB1-2300-609		8	SCREW,MACH.,TRUSS HEAD,M3X6	
506	XB1-2300-809		8	SCREW,MACH.,TRUSS HEAD,M3X8	
507	XB1-2400-409		1	SCREW,MACH.,TRUSS HEAD,M4X4	
508	XB1-2400-809		7	SCREW,MACH.,TRUSS HEAD,M4X8	
509	XB1-3400-809		2	SCREW,MACH.,C.S. HEAD,M4X8	
510	XB6-7300-607		1	SCREW,TP,M3X6	
511	XD2-1100-502		13	RING,E	
512	XD2-1100-642		6	RING,E	
513	XD2-3100-152		4	RING,C,EXTERNAL	
514	XD3-1300-082		2	PIN,SPRING	
515	XD3-2300-202		2	PIN,DOWEL	

FIGURE Q52 SADDLE INLET ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q52 -	FG6-7534-000		1	SADDLE INLET ASSEMBLY	
1	FB2-1178-000		1	COUPLING	
2	FB4-8809-000		1	SPRING, TORSION	
3	FB4-8810-000		1	SPRING, TORSION	
4	FB4-8835-000		1	FLAPPER, INLET	
5	FB4-8836-000		1	ROLLER, INLET	
6	FB4-8840-000		1	GUIDE, INLET, 3	
7	FB4-8841-000		1	GUIDE, INLET, 5	
8	FB4-8845-000		1	ARM, FLAPPER, 1	
9	FB4-8850-000		1	SPRING, TORSION	
10	FB4-8851-000		1	SPRING, TORSION	
11	FF5-8590-000		4	PIN, GUIDE, 1	
12	FS1-1376-000		1	BUSHING	
13	FS1-9078-000		1	SCREW, STEPPED, M4	
14	FS2-1542-000		1	BUSHING	
15	FS5-2545-000		1	SPRING, COMPRESSION	
16	XD9-0151-000		1	WASHER	
17	XG9-0365-000		2	BEARING, BALL	
18	FB4-8846-000		1	ARM, FLAPPER, 2	
19	FH6-1690-000		1	SOLENOID, DC24V	SL44 J1055
20	FS7-2145-000		1	SPRING, TENSION	
21	FB4-8848-000		1	GUIDE, INLET, 4	
22	FB4-8849-000		1	MOUNT, UPPER GUIDE HANDLE	
23	FB5-2688-000		1	SPRING, TORSION	
24	FB5-2689-000		1	SPRING, TORSION	
25	FB5-9098-000		1	KNOB	
26	FF5-6194-000		4	ROLLER, FEED	
27	FF5-8591-000		2	PIN, GUIDE, 4	
28	FF6-1222-000		4	DEFLECTOR, SMALL	
28A	FB5-9011-000		2	SHEET, STOP	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q52 - 29	XA9-1031-000		1	SCREW,MACH.,TRUSS HEAD,M4X8	
30	FB1-7018-000		1	SPRING, TORSION	
31	FB4-8843-000		1	MOUNT, SENSOR	
32	FB4-8844-000		1	FLAG, SENSOR	
33	WG8-5382-000		1	PHOTO-INTERRUPTER	PI59 J1056
34	FF3-3751-000		1	CABLE, SADDLE UPPER UNIT	J1055-1057
34A	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	J1055
34B	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	J1057
34C	WT2-5041-000		1	TIE, CABLE	
35	FB5-9264-000		1	PLATE, SENSOR	
501	XB1-2400-609		19	SCREW,MACH.,TRUSS HEAD,M4X6	
502	XD2-1100-322		2	RING,E	
503	XD2-2100-302		1	RING,GRIP	
504	XD2-1100-642		2	RING,E	
505	XD3-2200-142		1	PIN,DOWEL	
506	XB1-2300-409		2	SCREW,MACH.,TRUSS HEAD,M3X4	
507	XD3-1300-082		1	PIN,SPRING	
508	XB1-2400-409		9	SCREW,MACH.,TRUSS HEAD,M4X4	

FIGURE Q53 SADDLE GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q53 -	FG6-4841-000		1	SADDLE GUIDE ASSEMBLY	
1	FA4-6702-000		2	SCREW, CAP	
2	FB3-7852-000		1	LATCH	
3	FB3-7854-000		1	ELIMINATOR, STATIC CHARGE	
4	FB5-2696-000		2	SPRING, LEAF	
5	FF5-8684-000		1	STATIC CHARGE ELIMINATOR	
5A	FB4-9163-000		1	SHEET, 1	
5B	FB4-9164-000		1	SHEET, 2	
6	FS5-6544-000		2	ROLLER, INLET	
501	XB1-2300-409		3	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XB1-2400-609		2	SCREW,MACH.,TRUSS HEAD,M4X6	
503	XB1-2400-809		2	SCREW,MACH.,TRUSS HEAD,M4X8	

FIGURE Q54 SADDLE STAPLER ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q54 -	FG6-7533-000		1	SADDLE STAPLER ASSEMBLY	
1	FB2-6416-000		2	WASHER, RESIN	
2	FB3-7865-000		2	SLIDER, UPPER	
3	FB3-7866-000		1	TOOL, ADJUSTING	
4	FB3-7867-000		1	SLIDER, LOWER	
5	FB4-9173-000		1	SPACER, STAPLER	
6	FB5-2700-000		1	GUIDE, STAPLER, 1	
7	FB5-2701-000		1	GUIDE, STAPLER, 2	
8	FB5-2702-000		1	GUIDE, STAPLER, 3	
9	FB5-2704-000		1	PLATE	
10	FB5-2708-000		1	COVER	
11	FB5-9196-000		1	MOUNT, STAPLER UNIT	
12	FF5-8687-000		2	STAPLER UNIT	
13	FB4-9159-000		1	SHEET, STAPLER	
14	FF5-9620-000		1	COVER, STAPLER	
14A	FB5-2695-000		1	LABEL	
15	FS1-9076-000		2	SCREW, STEPPED, M4	
16	FS5-1753-000		2	BUSHING	
17	FS6-2569-000		1	SPRING, COMPRESSION	
18	XA9-0722-000		1	SCREW, RS, M4X12	
19	XA9-0732-000		15	SCREW, RS, M4X8	
20	XZ9-0400-000	N	2	STAPLE CARTRIDGE	
21	FG3-1848-000		1	CABLE, SADDLE STAPLER	J1035,1036,1114,1115
501	XB1-2300-609		2	SCREW, MACH., TRUSS HEAD, M3X6	
502	XB6-7400-609		9	SCREW, TP, M4X6	
503	XB6-7400-809		4	SCREW, TP, M4X8	
504	XD2-1100-642		1	RING, E	

SADDLE INLET DRIVE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q55 -	FG6-7560-000		1	SADDLE INLET DRIVE ASSEMBLY	
1	FS1-9078-000		2	SCREW, STEPPED, M4	
2	FS2-1542-000		1	BUSHING	
3	FS7-2146-000		1	SPRING, TENSION	
4	XA9-0732-000		4	SCREW, RS, M4X8	
5	FB4-8245-000		1	LATCH	
6	FB4-8804-000		1	SUPPORT, LATCH, RIGHT	
7	FC2-4347-000		1	SHAFT, LATCH	
8	FF5-8587-000		1	PLATE, TENSION	
9	XG9-0365-000		2	BEARING, BALL	
10	FS2-3514-000		1	PULLEY, 30T	
11	FS5-0713-000		1	GEAR, 30T	
12	FS5-3255-000		1	PULLEY, 24T	
13	XD9-0151-000		1	WASHER	
501	XB1-2400-609		4	SCREW, MACH., TRUSS HEAD, M4X6	
502	XB2-8400-809		1	SCREW, W/WASHER, M4X8	
503	XB6-7400-609		3	SCREW, TP, M4X6	
504	XD2-1100-642		4	RING, E	
505	XD2-1100-502		1	RING, E	
506	XD3-2200-122		2	PIN, DOWEL	
507	XD3-2200-162		1	PIN, DOWEL	

FIGURE Q56 PASS LOWER GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q56 -	NPN		RF	PASS LOWER GUIDE ASSEMBLY	
1	FB3-7876-000		1	PLATE, RACK, FRONT	
2	FB3-7877-000		1	PLATE, RACK, REAR	
3	FB3-7878-000		2	BLOCK	
4	FB3-7945-000		1	ROLLER	
5	FB3-7946-000		1	MOUNT, SENSOR	
6	FB3-7947-000		1	PLATE, RACK, REAR	
7	FB4-9012-000		1	GUIDE, ROLLER	
8	FH6-1906-000		1	MOTOR, STEPPING, DC	M45 J1015
9	FS6-0814-000		1	PULLEY, 32T/GEAR, 16T	
10	FS6-0815-000		1	PULLEY, 16T/GEAR, 32T	
11	FS6-2570-000		1	SPRING, TENSION	
12	WG8-5382-000		2	PHOTO-INTERRUPTER	PI48,49 J1113,1043
13	XA9-0195-000		2	SCREW,P,M3X8	
14	XA9-0732-000		5	SCREW,RS,M4X8	
15	XF9-0646-000		1	BELT, TIMING	
16	FG3-1974-000		1	CABLE, SADDLE POSITIONING	J1030,1042,1043,1050 J1051,1113
16A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1030
16B	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J1050
16C	VS1-5057-005		1	CONNECTOR, SNAP TIGHT	J1042
501	XB1-2300-409		2	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XD2-1100-502		2	RING,E	

FIGURE Q57 INNER SIDE PLATE ASSEMBLY





FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q57 -	FG6-7984-000		1	INNER SIDE PLATE ASSEMBLY	
1	FB3-7894-000		1	GUIDE, 1	
2	FB3-7895-000		1	FLAG, SENSOR	
3	FB3-7896-000		1	SPRING, TORSION	
4	FB3-7897-000		2	HOLDER, BELT	
5	FB3-7977-000		1	GUIDE, 2	
6	FF3-4132-000		1	CABLE, H. POSITIONING SENSOR	J1044,1045
6A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1044
6B	WT2-5178-000		1	CLIP, CABLE	
7	FH6-1910-000		1	MOTOR, STEPPING, DC	M43 J12
8	FS5-3574-000		2	PULLEY, 30T	
9	FS5-3575-000		1	PULLEY, 30T	
10	FS5-9212-000		1	SCREW,STEPPED,M3	
11	FS6-0820-000		1	GEAR, 15T/30T	
12	FS6-0821-000		2	GEAR, 30T	
13	FS6-2571-000		2	SPRING, TENSION	
14	WG8-5382-000		1	PHOTO-INTERRUPTER	PI50 J1045
15	XF9-0669-000		2	BELT, TIMING	
501	XB1-2300-609		4	SCREW,MACH.,TRUSS HEAD,M3X6	
502	XB1-2301-209		2	SCREW,MACH.,TRUSS HEAD,M3X12	
503	XD2-1100-502		5	RING,E	


FIGURE Q58 SADDLE DELIVERY ASSEMBLY



NOTE : This assembly does not include the part shown with key No. 26.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q58 -	FG6-4843-000		1	SADDLE DELIVERY ASSEMBLY	
1	4S1-9002-000		1	SCREW,M4X6	
2	FA2-8244-000		2	BUSHING	
3	FB1-7172-000		1	TAPE, DOOR SUPPORT, 1	
4	FB3-7901-000		1	ROLLER, DELIVERY	
5	FB3-7904-000		1	SHAFT	
6	FB3-7906-000		1	ROLLER, IDLER	
7	FB3-7907-000		1	SPRING, TORSION	
8	FB3-7909-000		1	COVER, SENSOR	
9	FB3-7910-000		1	FLAG, SENSOR	
10	FB3-7921-000		1	HANDLE	
11	FB3-7929-000		2	CLAW	
12	FB3-7932-000		1	PLATE, GROUNDING	
13	FB3-7966-000		1	PLATE	
14	FB4-9166-000		2	PADDLE	
15	FB5-2703-000		1	MOUNT, PADDLE	
16	FB5-2711-000		1	BLOCK, STOP	
17	FC1-7432-000		1	SPRING, TORSION	
18	FF3-3205-000		1	CABLE, SENSOR	J1051,1052
18A	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J1051
19	FB3-7978-000		1	STATIC CHARGE ELIMINATOR	
20	FB4-9168-000		1	SHEET	
21	FS1-1187-000		1	BUSHING	
22	FS1-1213-000		1	BUSHING	
23	FS6-0825-000		1	GEAR, 71T	
24	FS6-0826-000		1	GEAR, 17T	
25	WG8-5382-000		1	PHOTO-INTERRUPTER	PI52 J1052
26	4A1-2349-000		1	SHAFT, DOOR	SEE NOTE
501	XB1-2300-609		3	SCREW,MACH.,TRUSS HEAD,M3X6	
502	XB4-7400-806		5	SCREW,TAPPING,TRUSS HEAD,M4X8	

FIGURE Q59 MOTOR MOUNT ASSEMBLY



NOTE : This assembly does not include the part shown with key No. 4.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q59 -	FG5-8391-000		1	MOTOR MOUNT ASSEMBLY	
1	FB1-7214-000		1	KNOB	
2	FH6-1455-000		1	MOTOR, DC24V	M42 J1033
3	FH6-1456-000		1	MOTOR, DC24V	M48 J1032
4	WG8-5464-000		2	PHOTO INTERRUPTER, TLP1253(C6)	SEE NOTE PI45,47 J1026,1018
5	FS1-1206-000		1	BUSHING	
6	FS1-1510-000		1	BUSHING	
7	FS6-0816-000		1	GEAR, 42T	
8	FS6-0817-000		1	GEAR, 16T	
9	FS6-0819-000		2	PULLEY, 44T/GEAR, 24T	
10	FS6-0828-000		1	GEAR, 16T/60T	
11	FS6-0831-000		1	GEAR, 60T	
12	FS6-0833-000		1	GEAR, 16T	
13	FS6-2578-000		1	SPRING, COMPRESSION	
14	RS1-1042-000		1	BUSHING	
15	XA9-0732-000		2	SCREW,RS,M4X8	
16	XF9-0698-000		2	BELT, TIMING	
501	XB1-2400-609		4	SCREW,MACH.,TRUSS HEAD,M4X6	
502	XD2-1100-642		4	RING,E	
503	XD3-2200-102		4	PIN,DOWEL	

FIGURE Q90 FINISHER CONTROLLER PCB ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	RANK	QTY	DESCRIPTION	SERIAL NUMBER / REMARKS
Q90 -	FG3-1825-000		1	FINISHER CONTROLLER PCB ASS'Y	
1	WA3-7744-000		1	IC, M27C4002-80XF1, EP-ROM	IC110
2	WA7-1119-000		1	IC, S-93C66ADP,EEP-ROM,4K	IC107
FU101	VD7-1625-001		1	FUSE, 60V, 5A	
FU102	VD7-1625-001		1	FUSE, 60V, 5A	
IC113	FH4-5560-000		1	IC, M38881M2-010GP, IPC	

FIGURE Q91 SADDLE CONTROLLER PCB ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q91 -	FG3-1833-000		1	SADDLE CONTROLLER PCB ASSEMBLY	
1	WA3-7862-000		1	IC, M27C1001-80XF1, EP-ROM	Q2
FU1	VD7-1621-001		1	FUSE, 60V, 1A	
FU2	VD7-1621-001		1	FUSE, 60V, 1A	
Q4	FH4-5560-000		1	IC, M38881M2-010GP, IPC	

FIGURE Q92 AC FUSE BOX PCB ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q92 -	FG3-1826-000		1	AC FUSE BOX PCB ASSEMBLY	
FU711	VD7-1627-001		1	FUSE, 60V, 7A	
FU712	VD7-1621-002		1	FUSE, 60V, 10A	
FU713	VD7-1625-001		1	FUSE, 60V, 5A	
FU714	VD7-1627-001		1	FUSE, 60V, 7A	
FU716	VD7-1623-001		1	FUSE, 60V, 3.0A	
FU718	VD7-1627-001		1	FUSE, 60V, 7A	
FU719	VD7-1625-001		1	FUSE, 60V, 5A	

FIGURE Q93 PUNCH DRIVER PCB ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q93 -	FG3-1829-000		1	PUNCH DRIVER PCB ASSEMBLY	
FU741	VD7-1621-001		1	FUSE, 60V, 1A	

STAPLER DRIVER PCB ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q94 -	FG3-1827-000		1	STAPLER DRIVER PCB ASSEMBLY	

FIGURE QB LIST OF CONNECTORS (1/7)




FIGURE QB LIST OF CONNECTORS (2/7)




FIGURE QB LIST OF CONNECTORS (3/7)




FIGURE QB LIST OF CONNECTORS (4/7)




FIGURE QB LIST OF CONNECTORS (5/7)




FIGURE QB LIST OF CONNECTORS (6/7)




FIGURE QB LIST OF CONNECTORS (7/7)




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B -	NPN		RF	LIST OF CONNECTORS	
J1	PCB			SADDLE DC CONTROLLER	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
J2	PCB			SADDLE DC CONTROLLER	

	VS1-6321-006		1	CONNECTOR, 6P, FEMALE	
	VS1-6321-006		1	CONNECTOR, 6P, FEMALE	
J4	PCB			SADDLE DC CONTROLLER	
	VS1-6383-004		1	CONNECTOR, 4P, FEMALE	
	WS3-5600-000		4	PIN CONTACT, 22-20AWG	

J5	PCB			SADDLE DC CONTROLLER	
	VS1-0842-006		1	CONNECTOR, 6P, FEMALE	
J6	PCB			SADDLE DC CONTROLLER	
	VS1-0842-007		1	CONNECTOR, 7P, FEMALE	
J7	PCB			SADDLE DC CONTROLLER	

	VS1-0842-010		1	CONNECTOR, 10P, FEMALE	
J8	PCB			SADDLE DC CONTROLLER	
	VS1-0842-014		1	CONNECTOR, 14P, FEMALE	
J9	PCB			SADDLE DC CONTROLLER	
	VS1-0842-015		1	CONNECTOR, 15P, FEMALE	

J10	PCB			SADDLE DC CONTROLLER	
	VS1-0842-008		1	CONNECTOR, 8P, FEMALE	
J11	PCB			SADDLE DC CONTROLLER	
	VS1-0842-012		1	CONNECTOR, 12P, FEMALE	
J12	PCB			SADDLE DC CONTROLLER	

	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	
J13	PCB			SADDLE DC CONTROLLER	
	VS1-0842-004		1	CONNECTOR, 4P, FEMALE	
J14	PCB			SADDLE DC CONTROLLER	
	VS1-6313-009		1	CONNECTOR, 9P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J14	VS1-6314-009		1	CONNECTOR, 9P, FEMALE	
	VT2-5161-018		1	HOLDER, CONNECTOR, 18P	
J15	PCB			SADDLE DC CONTROLLER	
	VS1-0842-008		1	CONNECTOR, 8P, FEMALE	
J16	PCB			SADDLE DC CONTROLLER	

	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J17	PCB			SADDLE DC CONTROLLER	
	VS1-6321-002		1	CONNECTOR, 2P, FEMALE	
J18	PCB			SADDLE DC CONTROLLER	
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	

J19	PCB			A TRAY SENSOR LED	
	VS1-6321-002		1	CONNECTOR, 2P, FEMALE	
J20	NPN			UPPER PASS CHANGE SOLENOID	SL2
	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
	VS1-6321-002		1	CONNECTOR, 2P, FEMALE	

J21	NPN			BUFFER PASS CHANGE SOLENOID	SL1
	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
	VS1-6321-002		1	CONNECTOR, 2P, FEMALE	
J22	PCB			BUFFER PASS PAPER SENSOR	
	VS1-0842-004		1	CONNECTOR, 4P, FEMALE	

J23	VS1-0842-007		1	CONNECTOR, 7P, FEMALE	
	VS1-5057-007		1	CONNECTOR, SNAP TIGHT	
	VS1-6321-007		1	CONNECTOR, 7P, FEMALE	
J24	NPN			BUFFER PASS REAR PAPER SENSOR	PI3
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	

J25	NPN			UPPER COVER OPEN/CLOSE SENSOR	PI5
	VS1-6321-003		1	CONNECTOR, 3P, FEMALE	
J26	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
	VS1-6321-003		1	CONNECTOR, 3P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J27	NPN			NON SORT PAPER DELIVERY SENSOR	PI6
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J28	VS1-0842-004		1	CONNECTOR, 4P, FEMALE	
	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	
	VS1-6320-004		1	CONNECTOR, 4P, FEMALE	
J29	PCB			LOWER PASS PAPER SENSOR	
	VS1-0842-004		1	CONNECTOR, 4P, FEMALE	
J30	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
	VS1-6320-003		2	CONNECTOR, 3P, MALE	
J31	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	
J32	VS1-6320-004		2	CONNECTOR, 4P, FEMALE	PI31
	NPN			BELT HOME POSITION SENSOR	
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J33	NPN			SORT PAPER DELIVERY SENSOR	PI4
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J34	NPN			BIND PAPER DELIVERY SENSOR	PI32
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J35	VS1-6314-005		2	CONNECTOR, 5P, FEMALE	
	VS1-6318-005		1	CONNECTOR, SNAP TIGHT	
J36	NPN			SHEET PRESS SOLENOID	SL5
J37	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	M20
	WS3-5358-000		2	SOCKET CONTACT, 22-26AWG	
	VS1-5824-003		1	CONNECTOR, 3P, FEMALE	
	NPN			BELT MOTOR	
	VS1-6321-005		1	CONNECTOR, 5P, FEMALE	
J38	VS1-6313-011		2	CONNECTOR, 11P, FEMALE	
	VS1-6314-011		2	CONNECTOR, 11P, FEMALE	
	VS1-6319-022		1	CONNECTOR, SNAP TIGHT	
	VT2-5161-022		1	HOLDER, CONNECTOR, 22P	
J39	VS1-6313-011		2	CONNECTOR, 11P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J39	VS1-6314-011		2	CONNECTOR, 11P, FEMALE	
	VS1-6319-022		1	CONNECTOR, SNAP TIGHT	
	VT2-5161-022		1	HOLDER, CONNECTOR, 22P	
	J40 NPN			REAR JOG MOTOR	M5
	VS1-6321-005		1	CONNECTOR, 5P, FEMALE	
J41	NPN			FRONT JOG MOTOR	M4
	VS1-6321-005		1	CONNECTOR, 5P, FEMALE	
J42	NPN			FRONT JOG HOME POSITION SENSOR	PI7
	VS1-6321-003		1	CONNECTOR, 3P, FEMALE	
J43	NPN			REAR JOG HOME POSITION SENSOR	PI8
J44	VS1-6320-003		1	CONNECTOR, 3P, MALE	
	NPN			DELIVERY AUXILIARY SOLENOID	SL4
	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
J45	VS1-6320-002		1	CONNECTOR, 2P, FEMALE	
	VS1-6313-009		2	CONNECTOR, 9P, FEMALE	
J46	VS1-6314-009		2	CONNECTOR, 9P, FEMALE	
	VS1-6319-018		1	CONNECTOR, SNAP, TIGHT	
	VT2-5161-018		1	HOLDER, CONNECTOR, 18P	
	NPN			TRAY SUPPORT MOTOR	M6
	VS1-6321-005		1	CONNECTOR, 5P, FEMALE	
J47	PCB			B TRAY SENSOR PTR	
J48	VS1-6321-004		1	CONNECTOR, 4P, FEMALE	
	NPN			SWING MOTOR CLOCK SENSOR	PI9
J49	VS1-6320-003		1	CONNECTOR, 3P, MALE	
	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
J50	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
	VS1-0842-004		1	CONNECTOR, 4P, FEMALE	
	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J50	VS1-6320-004		1	CONNECTOR, 4P, FEMALE	
J51	NPN			PAPER FEED MOTOR CLOCK SENSOR	PI11
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J52	NPN			TRAY AUXILIARY PLATE SENSOR	PI10
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J53	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
	VS1-5824-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5358-000		1	SOCKET CONTACT, 22-26AWG	
J54	VS1-5824-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5358-000		2	SOCKET CONTACT, 22-26AWG	
	WS3-5649-000		1	CONNECTOR, 3P, FEMALE	
	WT1-5220-000		2	RECEPTACLE	
J55	VS3-5116-002		1	CONNECTOR, 2P, FEMALE	
	VS3-5207-002		1	CONNECTOR, 2P, MALE	
J57	WS3-5174-000		2	SOCKET CONTACT, 16-20AWG	
	WS3-5354-000		2	PIN CONTACT, 16-20AWG	
	NPN			FRONT DOOR SWITCH 2	MSW8
	VS3-5207-002		1	CONNECTOR, 2P, MALE	
	WS3-5354-000		2	PIN CONTACT, 16-20AWG	
J58	VS1-0108-004		1	CONNECTOR, 4P, MALE	
	VS1-0279-004		1	CONNECTOR, 4P, FEMALE	
	WS3-0437-000		4	SOCKET CONTACT, 20-30AWG	
	WS3-0885-000		4	PIN CONTACT, 20-30AWG	
J59	NPN			SWING MOTOR	M8
J60	VS3-0108-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0885-000		1	PIN CONTACT, 20-30AWG	
	NPN			BIND DELIVERY MOTOR	M7
	VS3-0108-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0885-000		2	PIN CONTACT, 20-30AWG	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J61	VS1-6314-004		2	CONNECTOR, 4P, FEMALE	
	VS1-6318-004		1	CONNECTOR, SNAP, TIGHT	
J62	NPN			SHUTTER HOME POSITION SENSOR	PI12
	VS1-6321-003		1	CONNECTOR, 3P, FEMALE	
J63	VS1-6313-008		2	CONNECTOR, 8P, FEMALE	

	VS1-6314-008		2	CONNECTOR, 8P, FEMALE	
	VS1-6319-016		1	CONNECTOR, SNAP, TIGHT	
	VT2-5161-016		1	HOLDER, CONNECTOR, 16P	
J64	VS1-0842-008		1	CONNECTOR, 8P, FEMALE	
	VS1-5057-008		1	CONNECTOR, SNAP TIGHT	

	VS1-6321-008		1	CONNECTOR, 8P, FEMALE	
J65	NPN			PADDLE HOME POSITION SENSOR	PI13
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J66	NPN			PADDLE MOTOR	M9
	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	

	VS1-5057-005		1	CONNECTOR, SNAP TIGHT	
J67	NPN			SWING GUIDE CLOSE SENSOR	PI14
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J68	NPN			SWING GUIDE OPEN SENSOR	PI15
	VS1-6320-003		1	CONNECTOR, 3P, MALE	

J69	PCB			B TRAY SENSOR LED	
	VS1-6320-002		1	CONNECTOR, 2P, FEMALE	
J70	NPN			INLET PAPER PASS SENSOR	PI2
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J71	NPN			STAPLER MOTOR	M11

	VS1-5923-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5018-000		2	SOCKET, CONTACT, AWG18-24	
J72	NPN			FEEDER COOLING FAN	FM2
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
	VS1-6321-003		1	CONNECTOR, 3P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J73	NPN			STAPLER HOME POSITION SENSOR	PI16
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J74	NPN			STAPLER MOTOR	M11
	VS1-6373-007		1	CONNECTOR, 7P, FEMALE	
	WS3-5569-000		7	PIN, CONTACT	
J76	VS1-6313-012		2	CONNECTOR, 12P, FEMALE	
	VS1-6318-012		1	CONNECTOR, SNAP TIGHT	
J77	NPN			BELT MOVE SENSOR 3	PI30
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J78	NPN			BELT MOVE SENSOR 2	PI29
J79	VS1-6320-003		1	CONNECTOR, 3P, MALE	
	NPN			BELT MOVE SENSOR 1	PI28
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J80	NPN			STAPLER SHIFT MOTOR	M10
	VS3-0108-006		1	CONNECTOR, 6P, FEMALE	
J81	WS3-0885-000		6	PIN CONTACT, 20-30AWG	
	NPN			TRAY SHIFT UP MOTOR 1	M13
	VS1-6321-013		1	CONNECTOR, 13P, FEMALE	
J82	PCB			A TRAY ARIA SENSOR	
	VS1-6320-005		1	CONNECTOR, 5P, FEMALE	
J83	NPN			A TRAY PAPER SENSOR	PI20
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J84	PCB			POWER SUPPLY	
	VS3-5083-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
J85	PCB			POWER SUPPLY	
	VS3-5083-010		1	CONNECTOR, 10P, FEMALE	
	WS3-5160-000		10	SOCKET CONTACT, 18-24AWG	
J86	NPN			A TRAY PAPER CLOCK SENSOR	PI19
	VS1-6320-003		1	CONNECTOR, 3P, MALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J87	NPN			TRAY SWITCH	MSW3
	WS3-5666-000		1	CONNECTOR	
J88	PCB			POWER SUPPLY	
	VS1-6321-004		1	CONNECTOR, 4P, FEMALE	
J89	NPN			TRAY SHIFT UP MOTOR 2	M12

	VS1-6321-013		1	CONNECTOR, 13P, FEMALE	
J90	PCB			B TRAY ARIA SENSOR	
	VS1-6320-005		1	CONNECTOR, 5P, FEMALE	
J91	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
	VS1-5824-002		1	CONNECTOR, 2P, FEMALE	

	VS1-6321-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5358-000		2	SOCKET CONTACT, 22-26AWG	
J92	NPN			B TRAY PAPER SENSOR	PI17
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J93	NPN			B TRAY PAPER CLOCK SENSOR	PI18

	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J94	NPN			SUB TRAY SOLENOID	SL3
	VS1-6320-003		1	CONNECTOR, 3P, MALE	
J95	NPN			INLET PASS MOTOR	M1
	VS1-6321-013		1	CONNECTOR, 13P, FEMALE	

J96	NPN			BUFFER MOTOR	M2
	VS1-6321-013		1	CONNECTOR, 13P, FEMALE	
J97	NPN			PAPER DELIVERY MOTOR	M3
	VS1-6320-013		1	CONNECTOR, 10P, FEMALE	
J98	PCB			PAPER INLET PASS SENSOR	

	VS1-6321-004		1	CONNECTOR, 4P, FEMALE	
J99	PCB			A TRAY SENSOR PTR	
	VS1-6321-004		1	CONNECTOR, 4P, FEMALE	
J100	NPN			DOOR OPEN/CLOSE SENSOR	PI1
	VS1-6320-003		1	CONNECTOR, 3P, MALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J101	PCB			DC CONTROLLER	
	VS1-6534-004		1	CONNECTOR, 4P, FEMALE	
	WS3-5658-000		4	SOCKET CONTACT	
J102	PCB			DC CONTROLLER	
	VS1-6313-008		1	CONNECTOR, 8P, FEMALE	
J103	VS1-6314-008		1	CONNECTOR, 8P, FEMALE	
	VT2-5161-016		1	HOLDER, CONNECTOR, 16P	
	PCB			DC CONTROLLER	
	VS1-6314-007		1	CONNECTOR, 7P, FEMALE	
J104	PCB			DC CONTROLLER	
J105	VS1-6313-011		1	CONNECTOR, 11P, FEMALE	
	VS1-6314-011		1	CONNECTOR, 11P, FEMALE	
	VT2-5161-022		1	HOLDER, CONNECTOR, 22P	
	PCB			DC CONTROLLER	
	VS1-6313-009		1	CONNECTOR, 9P, FEMALE	
J106	VS1-6314-009		1	CONNECTOR, 9P, FEMALE	
	VT2-5161-018		1	HOLDER, CONNECTOR, 18P	
	PCB			DC CONTROLLER	
	VS1-6314-004		1	CONNECTOR, 4P, FEMALE	
J107	PCB			DC CONTROLLER	
J108	VS1-6313-008		1	CONNECTOR, 8P, FEMALE	
	VS1-6314-008		1	CONNECTOR, 8P, FEMALE	
	VT2-5161-016		1	HOLDER, CONNECTOR, 16P	
	PCB			DC CONTROLLER	
	VS1-6314-005		1	CONNECTOR, 5P, FEMALE	
J109	PCB			DC CONTROLLER	
J110	VS1-6313-014		1	CONNECTOR, 14P, FEMALE	
	VS1-6314-014		1	CONNECTOR, 14P, MALE	
	VT2-5161-028		1	HOLDER, CONNECTOR, 28P	
	PCB			DC CONTROLLER	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J110	VS1-6313-014		1	CONNECTOR, 14P, FEMALE	
	VS1-6314-014		1	CONNECTOR, 14P, MALE	
	VT2-5161-028		1	HOLDER, CONNECTOR, 28P	
	J111 PCB			DC CONTROLLER	
	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
J112	PCB			DC CONTROLLER	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	
J113	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
	PCB			DC CONTROLLER	
	VS1-6313-013		1	CONNECTOR, 13P, FEMALE	
J114	VS1-6314-013		1	CONNECTOR, 13P, FEMALE	
	VT2-5161-026		1	HOLDER, CONNECTOR, 26P	
	PCB			DC CONTROLLER	
	VS1-6534-004		1	CONNECTOR, 4P, FEMALE	
	WS3-5471-000		3	SOCKET CONTACT, 22-28AWG	
J115	PCB			DC CONTROLLER	
	VS1-6313-012		1	CONNECTOR, 12P, FEMALE	
J116	VS1-6314-012		1	CONNECTOR, 12P, FEMALE	
	VT2-5161-024		1	CONNECTOR, 24P, FEMALE	
	PCB			DC CONTROLLER	
J117	VS1-6313-015		1	CONNECTOR, 15P, FEMALE	
	VS1-6314-015		1	CONNECTOR, 15P, FEMALE	
	VT2-5161-030		1	HOLDER, CONNECTOR, 30P	
	PCB			DC CONTROLLER	
	VS1-6314-009		1	CONNECTOR, 9P, FEMALE	
J118	PCB			DC CONTROLLER	
	VS1-6313-014		1	CONNECTOR, 14P, FEMALE	
J119	VS1-6314-014		1	CONNECTOR, 14P, MALE	
	VT2-5161-028		1	HOLDER, CONNECTOR, 28P	
	PCB			DC CONTROLLER	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J119	VS1-6313-008		1	CONNECTOR, 8P, FEMALE	
	VS1-6314-008		1	CONNECTOR, 8P, FEMALE	
	VT2-5161-016		1	HOLDER, CONNECTOR, 16P	
	J120 PCB			DC CONTROLLER	
	VT2-5161-026		1	HOLDER, CONNECTOR, 26P	
J121	VS1-6314-013		1	CONNECTOR, 13P, FEMALE	
	VS1-6313-013		1	CONNECTOR, 13P, FEMALE	
	J121 PCB			DC CONTROLLER	
	VS1-6314-013		1	CONNECTOR, 13P, FEMALE	
J122	J122 PCB			DC CONTROLLER	
J124	VS1-6313-010		1	CONNECTOR, 10P, FEMALE	
	VS1-6314-010		1	CONNECTOR, 10P, FEMALE	
	VT2-5161-020		1	HOLDER, CONNECTOR, 20P	
	J124 PCB			DC CONTROLLER	
	VS1-6313-016		1	CONNECTOR, 16P, FEMALE	
J126	VS1-6314-016		1	CONNECTOR, 16P, FEMALE	
	VT2-5161-032		1	HOLDER, CONNECTOR, 32P	
	J126 PCB			DC CONTROLLER	
	VS1-6534-002		1	CONNECTOR, 2P, MALE	
	WS3-5658-000		1	SOCKET CONTACT	
J127	J127 PCB			DC CONTROLLER	
J128	VS1-6314-007		1	CONNECTOR, 7P, FEMALE	
	J128 PCB			DC CONTROLLER	
	VS1-6534-005		1	CONNECTOR, 5P, MALE	
	WS3-5658-000		4	SOCKET CONTACT	
J711	J711 PCB			FUSE BOX	
J712	VS3-5083-010		1	CONNECTOR, 10P, FEMALE	
	WS3-5160-000		10	SOCKET CONTACT, 18-24AWG	
	J712 PCB			FUSE BOX	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J712	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
J713	PCB			FUSE BOX	
	VS3-5083-007		1	CONNECTOR, 7P, FEMALE	
J714	WS3-5160-000		7	SOCKET CONTACT, 18-24AWG	
	PCB			FUSE BOX	

	VS3-5083-008		1	CONNECTOR, 8P, FEMALE	
J715	WS3-5160-000		8	SOCKET CONTACT, 18-24AWG	
	PCB			FUSE BOX	
	NPN			POWER SUPPLY COOLING FAN	FM1
J716	PCB			FUSE BOX	

	VS1-6314-008		1	CONNECTOR, 8P, FEMALE	
J717	PCB			FUSE BOX	
	VS1-5452-007		1	CONNECTOR, 7P, FEMALE	
J718	PCB			FUSE BOX	
	VS1-6314-004		1	CONNECTOR, 4P, FEMALE	

J719	PCB			FUSE BOX	
	VS3-5116-002		1	CONNECTOR, 2P, FEMALE	
J720	WS3-5174-000		2	SOCKET CONTACT, 16-20AWG	
	PCB			FUSE BOX	
	VS1-6534-002		1	CONNECTOR, 2P, MALE	

J721	WS3-5658-000		1	SOCKET CONTACT	
	PCB			FUSE BOX	
	VS3-5083-003		1	CONNECTOR, 3P, FEMALE	
J741	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
	PCB			PUNCHER DRIVER	

	VS1-6313-015		1	CONNECTOR, 15P, FEMALE	
	VS1-6314-015		1	CONNECTOR, 15P, FEMALE	
J742	VT2-5161-030		1	HOLDER, CONNECTOR, 30P	
	PCB			PUNCHER DRIVER	
	VS1-0842-004		1	CONNECTOR, 4P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J743	PCB			PUNCHER DRIVER	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
	J744 PCB			PUNCHER DRIVER	
	NPN			PUNCH REGISTRATION MOTOR	M17
J745	PCB			PUNCHER DRIVER	
	VS1-5824-006		1	CONNECTOR, 6P, FEMALE	
	WS3-5358-000		6	SOCKET CONTACT, 22-26AWG	
J746	PCB			PUNCHER DRIVER	
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
J747	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
	PCB			PUNCHER DRIVER	
	VS1-5824-009		1	CONNECTOR, 9P, FEMALE	
	VS1-6094-009		1	CONNECTOR, 9P, FEMALE	
	WS3-5358-000		18	SOCKET CONTACT, 22-26AWG	
J748	VS1-6053-018		1	CONNECTOR, 18P, FEMALE	
	PCB			PUNCHER DRIVER	
	VS1-6314-008		1	CONNECTOR, 8P, FEMALE	
J749	PCB			PUNCHER DRIVER	
	NPN			PUNCH DUST FEED MOTOR	M16
J750	PCB			PUNCHER DRIVER	
	VS1-5824-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
J771	PCB			STAPLER DRIVER	
	VS3-5116-002		1	CONNECTOR, 2P, FEMALE	
J772	WS3-5174-000		2	SOCKET CONTACT, 16-20AWG	
	PCB			STAPLER DRIVER	
	VS1-6314-014		1	CONNECTOR, 14P, MALE	
J773	PCB			STAPLER DRIVER	
	VS1-6314-007		1	CONNECTOR, 7P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J774	PCB			STAPLER DRIVER	
	VS1-5824-007		1	CONNECTOR, 7P, FEMALE	
	WS3-5358-000		7	SOCKET CONTACT, 22-26AWG	
	J775 PCB			STAPLER DRIVER	
	VS3-5116-002		1	CONNECTOR, 2P, FEMALE	
J776	WS3-5174-000		2	SOCKET CONTACT, 16-20AWG	
	PCB			STAPLER DRIVER	
	VS1-6534-006		1	CONNECTOR, 6P, FEMALE	
	WS3-5658-000		6	SOCKET CONTACT	
	J800 PCB			PAPER SENSOR	
J941	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	
	PCB			PUNCHER DUST SENSOR	
	VS1-6321-005		1	CONNECTOR, 5P, FEMALE	
	J971 PCB			OPTION SWITCH	
	VS1-6313-016		1	CONNECTOR, 16P, FEMALE	
J981	VS1-6314-016		1	CONNECTOR, 16P, FEMALE	
	VT2-5161-032		1	HOLDER, CONNECTOR, 32P	
	PCB			SADDLE JAM LED	
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	J1001 NPN			PUNCH REGISTRATION SENSOR	PI21
J1002	VS1-5824-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
	NPN			PUNCH DUST BOX SET SENSOR	PI26
	VS1-6321-003		1	CONNECTOR, 3P, FEMALE	
	J1003 NPN			PUNCH MOTOR CLOCK SENSOR	PI34
J1004	VS1-5824-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
	NPN			PUNCH DUST FEED SENSOR	PI27
	VS1-0842-004		1	CONNECTOR, 4P, FEMALE	
	J1005 NPN			PUNCH SENSOR SHIFT MOTOR	M19

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1005	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	
	VS1-5824-006		1	CONNECTOR, 6P, FEMALE	
	WS3-5358-000		6	SOCKET CONTACT, 22-26AWG	
	J1006 VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
J1007	VS1-5824-003		3	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
	VS1-5824-009		2	CONNECTOR, 9P, FEMALE	
	WS3-5358-000		18	SOCKET CONTACT, 22-26AWG	
	VS1-5057-009		1	CONNECTOR, SNAP TIGHT	
J1008	NPN			PUNCH MOTOR	M18
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
	NPN			PUNCH 2/3 HOLE SENSOR	4 HOLE PI33
	VS1-6094-003		1	CONNECTOR, 3P, FEMALE	4 HOLE
J1009	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	4 HOLE
	NPN			PUNCH MOTOR H. POSITION SENSOR	PI22
	VS1-5824-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
J1010	NPN			PUNCH SENSOR H.POSITION SENSOR	PI23
J1012	VS1-5824-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
	NPN			PUNCH HOME POSITION SENSOR	PI24
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1013	NPN			PUNCH FRONT SENSOR	PI25
J1014	VS1-5824-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
	VS1-0842-003		2	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
J1015	NPN			JOG MOTOR	M45

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1015	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	
J1016	VS1-5057-009		1	CONNECTOR, SNAP TIGHT	
	VS1-5824-009		1	CONNECTOR, 9P, FEMALE	
	VS1-6313-009		1	CONNECTOR, 9P, FEMALE	
	VS1-6314-009		1	CONNECTOR, 9P, FEMALE	

	VS1-6319-018		1	CONNECTOR, SNAP, TIGHT	
	VT2-5161-018		1	HOLDER, CONNECTOR, 18P	
	WS3-5358-000		9	SOCKET CONTACT, 22-26AWG	
J1017	VS1-0842-008		1	CONNECTOR, 8P, FEMALE	
	VS1-6757-009		1	CONNECTOR, 9P	

	VS1-6758-009		1	CONNECTOR, 9P	
	VT2-5161-018		1	HOLDER, CONNECTOR, 18P	
	WS3-5721-000		18	SOCKET CONTACT	
J1018	NPN			FOLDER MOTOR CLOCK SENSOR	PI47
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	

J1019	VS1-0842-009		1	CONNECTOR, 9P, FEMALE	
	VS1-5057-008		1	CONNECTOR, SNAP TIGHT	
	VS1-5824-008		1	CONNECTOR, 8P, FEMALE	
	WS3-5358-000		8	SOCKET CONTACT, 22-26AWG	
J1020	VS1-0842-008		2	CONNECTOR, 8P, FEMALE	

	VS1-5057-008		1	CONNECTOR, SNAP TIGHT	
J1021	NPN			SADDLE TRAY PAPER SENSOR 1	PI42
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1022	NPN			SADDLE TRAY PAPER SENSOR 3	PI44
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	

J1024	NPN			SADDLE TRAY H. POSITION SENSOR	PI41
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1025	NPN			SADDLE TRAY MOTOR	M49
	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	
J1026	NPN			PAPER PUSH CLOCK MOTOR SENSOR	PI45

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1026	VS1-0852-003		1	CONNECTOR, 3P, FEMALE	
J1027	NPN			EJECT COVER OPEN/CLOSE SENSOR	PI46
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
J1028	VS1-0842-003		2	CONNECTOR, 3P, FEMALE	

	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
J1029	NPN			SADDLE TRAY PAPER SENSOR 2	PI43
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1030	VS1-0842-003		2	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	

J1031	NPN			PAPER POSITIONING PLATE MOTOR	M44
	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	
J1032	NPN			PAPER PUSH PLATE MOTOR	M48
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	

J1033	NPN			PAPER FOLDER MOTOR	M42
	VS1-0279-003		1	CONNECTOR, 3P, FEMALE	
	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
J1034	VS1-5729-002		1	CONNECTOR, 2P, MALE	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	

	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
	WS3-5301-000		2	PIN CONTACT	
J1035	VS1-0842-007		1	CONNECTOR, 7P, FEMALE	
	VS1-0852-007		1	CONNECTOR, 7P, FEMALE	
	VS1-5352-007		1	CONNECTOR, 7P	

J1036	VS1-0842-007		2	CONNECTOR, 7P, FEMALE	
	VS1-5057-007		1	CONNECTOR, SNAP TIGHT	
J1037	NPN			PAPER FEED ROLLER SOLENOID	SL43
	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1038	NPN			FLAPPER SOLENOID 2	SL42
	VS1-0852-002		1	CONNECTOR, 2P, FEMALE	
	VS1-5352-002		1	CONNECTOR, SNAP TIGHT	
J1039	NPN			FLAPPER SOLENOID 1	SL41
	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
J1040	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
	NPN			PAPER FEED MOTOR	M41
	VS1-0842-006		1	CONNECTOR, 6P, FEMALE	
J1041	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	
	NPN			GUIDE MOTOR	M43
J1042	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	
	VS1-0842-005		2	CONNECTOR, 5P, FEMALE	
	VS1-5057-005		1	CONNECTOR, SNAP TIGHT	
J1043	NPN			PAPER SET HOME POSITION SENSOR	PI49
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1044	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
	VS1-6094-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
J1045	NPN			PAPER SET SENSOR	PI50
J1046	VS1-6094-003		1	CONNECTOR, 3P, FEMALE	
	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
	NPN			PAPER PUSH PLATE EDGE SENSOR	PI56
J1047	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	NPN			PAPER PUSH H. POSITION SENSOR	PI55
J1048	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	NPN			GUIDE HOME POSITION SENSOR	PI54
J1049	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	NPN			ROLLER POSITION SENSOR	PI53
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q ' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1050	VS1-0842-004		2	CONNECTOR, 4P, FEMALE	
	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	
J1051	VS1-0842-004		2	CONNECTOR, 4P, FEMALE	
	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	
J1052	NPN			PAPER DELIVERY SENSOR	PI52

J1053	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	NPN			INLET COVER OPEN/CLOSE SENSOR	PI51
J1054	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	VS1-0842-005		2	CONNECTOR, 5P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	

J1055	NPN			SADDLE INLET SOLENOID	SL44
J1056	VS1-5824-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5358-000		2	SOCKET CONTACT, 22-26AWG	
	NPN			SADDLE INLET PAPER SENSOR	PI59
	VS1-5824-003		1	CONNECTOR, 3P, FEMALE	

J1057	WS3-5358-000		3	SOCKET CONTACT, 22-26AWG	
	VS1-5824-005		1	CONNECTOR, 5P, FEMALE	
	VS1-6320-006		1	CONNECTOR, 6P, FEMALE	
J1060	WS3-5358-000		5	SOCKET CONTACT, 22-26AWG	
	VS1-6313-008		1	CONNECTOR, 8P, FEMALE	

	VS1-6314-008		1	CONNECTOR, 8P, FEMALE	
	VS1-6319-016		1	CONNECTOR, SNAP, TIGHT	
	VS1-6757-008		1	CONNECTOR, 8P, FEMALE	
	VS1-6758-008		1	CONNECTOR, 8P, FEMALE	
	VT2-5161-016		2	HOLDER, CONNECTOR, 16P	

J1061	WS3-5721-000		16	SOCKET CONTACT	
	VS1-6313-008		1	CONNECTOR, 8P, FEMALE	
	VS1-6314-008		1	CONNECTOR, 8P, FEMALE	
	VS1-6319-016		1	CONNECTOR, SNAP, TIGHT	
	VS1-6757-008		1	CONNECTOR, 8P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1061	VS1-6758-008		1	CONNECTOR, 8P, FEMALE	
	VT2-5161-016		2	HOLDER, CONNECTOR, 16P	
	WS3-5721-000		16	SOCKET CONTACT	
	J1062 VS1-0842-004		2	CONNECTOR, 4P, FEMALE	
	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	
J1063	NPN			VERTICAL PATH SENSOR	PI57
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1064	NPN			PAPER FOLDER H.POSITION SENSOR	PI58
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1065	SYS			TO INSERTER	ACCESSORY
J1066	VS1-6320-010		1	CONNECTOR, 10P, FEMALE	
	VS1-5057-010		1	CONNECTOR, SNAP TIGHT	
	SYS			TO INSERTER	ACCESSORY
	VS1-6321-009		1	CONNECTOR, 9P, FEMALE	
	VS1-5057-009		1	CONNECTOR, SNAP TIGHT	
J1067	SYS			TO INSERTER	ACCESSORY
	VS1-6321-003		1	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
J1088	SYS			TO PAPER FOLDING UNIT	ACCESSORY
	VS1-5057-010		1	CONNECTOR, SNAP TIGHT	
J1089	VS1-6321-010		1	CONNECTOR, 10P, FEMALE	
	SYS			TO PAPER FOLDING UNIT	ACCESSORY
	VS1-5057-009		1	CONNECTOR, SNAP TIGHT	
J1090	VS1-6321-009		1	CONNECTOR, 9P, FEMALE	
	VS1-0279-008		1	CONNECTOR, 8P, FEMALE	FOR NOT FOLDER UNIT
J1113	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	FOR NOT FOLDER UNIT
	NPN			JOG HOME POSITION SENSOR	PI48
	VS1-0852-003		1	CONNECTOR, 3P, FEMALE	
J1114	NPN			REAR STITCH MOTOR	M46
	VS1-0852-007		1	CONNECTOR, 7P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1115	NPN			FRONT STITCH MOTOR	M47
J1121	VS1-0852-007		1	CONNECTOR, 7P, FEMALE	
	SYS			TO COPIER	
	FH2-6481-000		1	HOUSING	
	WS3-5044-000		1	SOCKET, CONTACT, 18-24AWG	
J1122	VS1-5452-007		1	CONNECTOR, 7P, FEMALE	100V
	VS1-6380-003		1	CONNECTOR, 3P, FEMALE	
	VS3-5121-003		1	CONNECTOR, 3P, MALE	
	WS3-5291-000		2	PIN CONTACT	100V
	WS3-5292-000		2	SOCKET CONTACT	
J1123	VS1-5729-002		1	CONNECTOR, 2P, MALE	
	VS3-5116-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5174-000		2	SOCKET CONTACT, 16-20AWG	
	WS3-5301-000		2	PIN CONTACT	
J1124	NPN			FRONT DOOR SWITCH 1	MSW1
J1125	WS3-5649-000		1	CONNECTOR, 3P, FEMALE	
	WT1-5220-000		2	RECEPTACLE	
	VS1-5729-002		1	CONNECTOR, 2P, MALE	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
J1126	WS3-5301-000		2	PIN CONTACT	ACCESSORY
	SYS			TO PAPER FOLDING UNIT	
	VS3-0108-008		1	CONNECTOR, 8P, FEMALE	
J1127	WS3-0885-000		8	PIN CONTACT, 20-30AWG	208/230V
	VS1-6380-003		1	CONNECTOR, 3P, FEMALE	
J1128	WS3-5292-000		2	SOCKET CONTACT	208/230V
	SYS			TO INSERTER	ACCESSORY
	VS1-5729-002		1	CONNECTOR, 2P, MALE	
	WS3-5301-000		2	PIN CONTACT	
J1129	PCB			DC CONTROLLER	

Paper Folding Unit-C1

[F25 - 9101 XCD00001 -]

CONTENTS

QA. ASSEMBLY LOCATION DIAGRAM

Q01. ATTACHMENT PARTS 1

Q02. ATTACHMENT PARTS 2

Q03. ATTACHMENT PARTS 3

Q10. UPPER COVER ASSEMBLY

Q11. INTERNAL COMPONENTS 1

Q12. INTERNAL COMPONENTS 2

Q13. INTERNAL COMPONENTS 3

Q20. FOLDER MOTOR ASSEMBLY

Q21. COUPLING ASSEMBLY

Q31. RIGHT GUIDE ASSEMBLY

Q32. RIGHT INNER GUIDE ASSEMBLY

Q33. LEFT GUIDE ASSEMBLY

Q34. LEFT INNER GUIDE ASSEMBLY

Q35. FEED UPPER GUIDE ASSEMBLY

Q36. INNER LEFT GUIDE ASSEMBLY

Q37. LOWER LEFT GUIDE ASSEMBLY

Q90. FOLDER DRIVER PCB ASSEMBLY

QB. LIST OF CONNECTORS

D2. NUMERICAL INDEX

FIGURE QA ASSEMBLY LOCATION DIAGRAM




FIGURE Q01 ATTACHMENT PARTS 1




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q01 -	NPN		RF	ATTACHMENT PARTS 1	
1	FB4-8755-000		1	MOUNT, CASTER	
2	FB4-8736-000		1	PLATE, LATCH	
3	FB4-8722-000		1	GAP TAPE	
4	FB4-8962-000		1	CASTER	
5	FB4-8739-000		1	PLATE, GUIDE PRESS, LEFT	
6	FA4-6702-000		6	SCREW, CAP	
7	FB4-8737-000		1	PLATE, GUIDE PRESS, RIGHT FRONT	
8	FC2-6544-000		3	PLATE, SPRING SUPPORT	
9	FF3-1637-000		3	ROLLER, PRESSURE	
10	FB4-8738-000		1	PLATE, GUIDE PRESS, RIGHT REAR	
501	XB6-7400-609		AR	SCREW, TP, M4X6	
502	XB6-7400-409		2	SCREW, TP, M4X4	

FIGURE Q02 ATTACHMENT PARTS 2 (1/2)




FIGURE Q02 ATTACHMENT PARTS 2 (2/2)




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q02 -	NPN		RF	ATTACHMENT PARTS 2	
1	FB4-8245-000		2	LATCH	
2	FB4-8803-000		1	SUPPORT, LATCH, LEFT	
3	FB4-8804-000		2	SUPPORT, LATCH, RIGHT	
4	FC2-4262-000		1	RAIL, SLIDE, UPPER	
5	FC2-4278-000		1	PLATE, SLIDE, RAIL, 1	
6	FC2-4279-000		1	PLATE, SLIDE, RAIL, 2	
7	FC2-4277-000		1	COVER, CABLE	
8	XA9-0854-000		8	SCREW,MACH.,TRUSS HEAD,M3X6	
9	FC2-4312-000		1	MOUNT, LATCH, LEFT	
10	FC2-4356-000		2	PLATE, FRAME	
11	FF3-1632-000		2	PIN, POSITIONING	
12	FS1-1451-030		1	BUSHING	
13	FS2-1542-000		2	BUSHING	
14	WG8-5382-000		1	PHOTO-INTERRUPTER	PI71 J1085
15	FS7-2642-000		2	SPRING, COMPRESSION	
16	FC2-4264-000		1	PLATE, BLOWER	
17	FS9-0064-000		1	LABEL	
18	XZ9-0520-000		1	RAIL, SLIDE, 4	
19	FC2-4261-000		1	RAIL, SLIDE, LOWER	
20	FB5-9214-000		1	COVER, FRONT INNER	
21	FB4-8980-000		1	PLATE, REINFORCEMENT	
22	FB3-0123-030		1	HOLDER, SWITCH	
23	FC2-4358-000		1	PLATE, SUPPORT, 2	
24	FG3-0540-000		1	CABLE, FOLDER FRAME REAR	J1085,1087-1089,1091 J1110,1126
25	FS5-9216-000		2	SCREW,STEPPED,M4X6	
26	WC4-5127-000		1	MICROSWITCH	MSW71 J1092
27	XA9-0892-000		2	SCREW,MACH.,TRUSS HEAD,M4X6	
28	XA9-0687-000		16	SCREW,MACH.,TRUSS HEAD,M4X8	
29	FB4-8246-000		1	PLATE	

FIGURE Q03 ATTACHMENT PARTS 3




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q03 -	NPN		RF	ATTACHMENT PARTS 3	
1	FB4-8300-000		1	LEVER, SOLENOID	
2	FB4-8299-000		3	LEVER	
3	FB4-8301-000		3	ROLLER	
4	FB4-8327-000		1	HOLDER	
5	FB4-8331-000		1	SPRING, TORSION	
6	FB4-8335-000		2	SPONGE, RUBBER	
7	XA9-0849-000		1	SCREW,RS,M3X6	
8	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1109
9	FB4-8330-000		1	SPRING, GROUNDING	
10	FH7-5876-000		1	SOLENOID, DC24V	SL71 J1109
11	FB4-8334-000		2	SHEET, SILENCER	
12	FB4-8308-000		1	RUBBER, STOP	
13	XA9-0605-000		3	SCREW,P,M4X8	
501	XD2-1100-322		5	RING,E	
502	XD3-1160-162		3	PIN,SPRING	
503	XD3-1300-162		1	PIN,SPRING	
504	XB1-2300-409		5	SCREW,MACH.,TRUSS HEAD,M3X4	

UPPER COVER ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q10 -	FG6-7581-000		1	UPPER COVER ASSEMBLY	
1	FB4-8802-000		1	PLATE, UPPER PANEL POSITION	
2	FB4-8966-000		1	KNOB, UPPER COVER	
3	FB4-8984-000		1	DAMPER UNIT	
4	FC2-4291-000		1	MOUNT, DAMPER	
5	FC2-4309-000		1	PLATE, SWITCH	
6	FB5-9279-000		1	PANEL, TOP	
7	FS1-9078-000		2	SCREW, STEPPED, M4	
8	FS4-2463-000		1	SPRING, TENSION	
9	WC4-5126-000		1	MICROSWITCH	MSW71 J1092
10	WG8-5382-000		1	PHOTO-INTERRUPTER	PI72 J1086
11	FG3-0539-000		1	CABLE, FOLDER UPPER PANEL	J1091,1092,1086,1087
11A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1087
11B	WT2-5041-000		2	TIE, CABLE	
12	FB4-8978-000		1	LATCH, MAGNET	
13	XA9-0605-000		1	SCREW, P, M4X8	
501	XB1-2301-209		1	SCREW, MACH., TRUSS HEAD, M3X12	
502	XB6-7300-609		2	SCREW, TP, M3X6	
503	XB6-7400-609		4	SCREW, TP, M4X6	
504	XB6-7400-809		2	SCREW, TP, M4X8	
505	XD2-1100-502		2	RING, E	
506	XD2-1100-642		8	RING, E	

FIGURE Q11 INTERNAL COMPONENTS 1




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q11 -	NPN		RF	INTERNAL COMPONENTS 1	
1	FF3-2309-000		1	ARM, DOOR, REAR	
2	FB4-8785-000		2	COVER, PCB	
3	FC2-4302-000		2	PLATE, ARM	
4	FS7-2644-000		2	SPRING, COMPRESSION	
5	FB5-9282-000		4	WASHER	
6	FB5-9200-000		1	ROLLER, 1	
7	XG9-0453-000		8	BEARING, BALL, 6902ZZNR	
8	FF3-1638-000		2	PIN, GUIDE	
9	XF9-0602-000		1	BELT, TIMING	
10	FB5-9270-000		1	ARM, PRESSURE, REAR	
11	FA4-2285-000		2	PULLEY, RELEASE	
12	FA4-2286-000		1	ARM, COMPRESSION, FRONT	
13	FA4-2287-000		1	ARM, COMPRESSION, REAR	
14	FC2-4354-000		1	ARM, PRESSURE, FRONT	
15	FU3-0010-000		3	GEAR, 40T	
16	FB5-9201-000		1	ROLLER, 2	
17	FA4-2313-000		2	SPACER	
18	FA4-2332-000		2	SPACER, GEAR	
19	FS1-3159-000		1	PULLEY, 12T	
20	FS2-0388-000		1	GEAR, 20T	
21	FS5-6324-000		1	ROLLER	
22	FS1-3162-000		2	PULLEY, 24T (1)	
23	FF3-2308-000		1	ARM, DOOR, FRONT	
24	FB5-9202-000		1	ROLLER, 3	
25	FF6-1234-000		1	PANEL, FRONT	
25A	FB4-8998-000		1	LABEL, ARROW	
26	FB4-8781-000		1	PANEL, REAR	
27	FF6-1245-000		1	GEAR, 20T	
28	FB5-9283-000		2	COVER, FRONT, 2	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q11 - 501	XD1-1106-235		1	SHIM	
502	XD2-1100-402		1	RING,E	
503	XD2-1100-502		2	RING,E	
504	XD2-3100-152		10	RING,C,EXTERNAL	
505	XB1-1403-009		2	SCREW,MACH.,PAN HEAD,M4X30	
506	XB6-7400-609		AR	SCREW,TP,M4X6	
507	XB7-2100-409		2	NUT,HEX,M4	
508	XD3-2200-212		4	PIN,DOWEL	
509	XD2-1100-642		8	RING,E	
510	XD1-1108-225		4	SHIM	
511	XB6-7500-609		3	SCREW,TP,M5X6	
516	XB1-2300-609		2	SCREW,MACH.,TRUSS HEAD,M3X6	

FIGURE Q12 INTERNAL COMPONENTS 2




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q12 -	NPN		RF	INTERNAL COMPONENTS 2	
1	FB4-8758-000		1	MOUNT, ACULIDE, REAR	
2	FC2-5100-000		1	KNOB	
3	FB4-8792-000		1	PLATE, KNOB INNER	
4	FB4-8793-000		1	PLATE, KNOB INNER, 2	
5	FB5-9277-000		1	SPRING, TORSION	
6	FB4-8756-000		1	PLATE, FRONT SUB	
7	FB4-8776-000		1	PLATE, FRONT SUB, 2	
8	FA4-2278-000		1	ARM,INLET SOLENOID	
9	XF9-0605-000		1	BELT, TIMING	
10	FF3-1642-000		1	MOUNT, PULLEY	
11	FS1-3163-000		1	PULLEY, 24T (2)	
12	XF2-2506-164		1	BELT, TIMING	
13	FS2-0387-000		1	GEAR, 40T	
14	FS2-6560-000		1	ROLLER	
15	FS5-9213-000		2	SCREW,STEPPED,M4X7	
16	FF5-8573-000		1	MOUNT, PULLEY, A	
17	FF5-8562-000		1	PIN, PLATE, FRONT	
18	FS1-3159-000		3	PULLEY, 12T	
19	FS2-0388-000		1	GEAR, 20T	
20	FA4-2332-000		1	SPACER, GEAR	
21	FC2-6548-000		1	BUSHING	
22	FC2-4268-000		1	ROLLER, PRESSURE	
23	FF6-1233-000		1	HOLDER, LATCH LOCK, REAR	
24	FA4-2275-000		1	CLAW, GUIDE	
25	FF6-1236-000		1	PLATE, TENSIONER	
26	FS2-6438-000		2	ROLLER, TENSIONER	
27	FF5-8563-000		1	PIN, PLATE, REAR	
28	RA1-2483-000		1	FLANGE, PULLEY	
29	FF5-8571-000		1	MOUNT, 2ND FOLDING ROLLER	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q12 - 30	FS1-1376-000		1	BUSHING	SL71
31	FS1-1433-000		1	BUSHING	
32	FH7-5062-000		1	SOLENOID, 24VDC	
33	FS7-2137-000		1	SPRING, TENSION	
34	XF9-0604-000		1	BELT, TIMING	
35	XG3-8016-505		2	BALL BEARING	J791,792,1110
36	FS4-0434-000		1	GEAR, 20T	
37	FS1-1187-000		1	BUSHING	
38	FA4-6702-000		8	SCREW, CAP	
39	FG3-0538-000		1	CABLE, FOLDER DRAWER MAIN	
39A	WT2-5041-000		2	TIE, CABLE	
40	FB5-9212-000		1	GUIDE, FEEDER EXIT	
41	FS7-0390-000		1	GEAR, 40T	
42	4S1-9002-000		2	SCREW,M4X6	
501	XD2-1100-502		15	RING,E	
502	XD3-2200-122		1	PIN,DOWEL	
503	XD3-2200-142		2	PIN,DOWEL	
504	XB6-7300-409		3	SCREW,TP,M3X4	
505	XB6-7400-609	AR		SCREW,TP,M4X6	
506	XD2-1100-322		3	RING,E	
507	XD2-1100-642		4	RING,E	
508	XD3-1300-102		1	PIN,SPRING	

FIGURE Q13 INTERNAL COMPONENTS 3




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q13 -	NPN		RF	INTERNAL COMPONENTS 3	
1	FF1-6572-000		6	PLATE, PIN	
2	FF1-6573-000		2	PIVOT	
3	FB5-9217-000		1	COVER, SOLENOID	
4	FF6-1232-000		1	HOLDER, LATCH LOCK, FRONT	
5	FA2-5970-000		4	SCREW, STEPPED	
6	FC2-4284-000		1	COVER, MOTOR	
7	FC2-4248-000		1	GUIDE, DELIVERY, RIGHT LOWER	
8	FB4-8986-000		1	PLATE, STOPPER	
9	FA4-2341-000		2	ARM, COUPLING	
10	FA4-2281-000		1	SPRING, LEAF, REAR	
11	XA9-0265-000		2	SCREW,W/WASHER,TRUSS HEAD	
12	FF6-1236-000		1	PLATE, TENSIONER	
13	FS2-6438-000		1	ROLLER, TENSIONER	
14	FA4-2332-000		1	SPACER, GEAR	
15	FS1-3159-000		1	PULLEY, 12T	
16	FS2-0388-000		1	GEAR, 20T	
17	FS5-6324-000		1	ROLLER	
18	FA4-2342-000		2	STOP, GUIDE	
19	FA4-2288-000	N	1	PLATE, FRONT, COUPLING, GUIDE	
20	FA4-2289-000	N	1	PLATE, REAR, COUPLING, GUIDE	
21	FA4-2290-000		1	SPRING, LEAF, FRONT	
22	FA4-2362-000		1	COVER, SOLENOID (2)	
23	FS1-9076-000		2	SCREW,STEPPED,M4	
24	FB4-8969-000		1	GUIDE, CENTER RIGHT	
25	FC2-6548-000		1	BUSHING	
26	FB4-8968-000		1	COVER, SENSOR, 3	
27	FG3-0541-000		1	CABLE, DRIVER CONNECTOR	J793,794,1100,1102 J1104,1106,1108,1109
27A	VS1-5057-003		2	CONNECTOR, SNAP TIGHT	J1100,1104
27B	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J1102

FIGURE Q20 FOLDER MOTOR ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q20 -	FG6-7574-000		1	FOLDER MOTOR ASSEMBLY	
1	FA5-5377-000		1	PULLEY	
2	FS2-3819-000		1	PULLEY	
3	FF6-1237-000		1	MOTOR, DC	M71 J1093
4	XF9-0603-000		1	BELT, TIMING	
501	XB1-2400-609		4	SCREW,MACH.,TRUSS HEAD,M4X6	
502	XD2-1100-642		1	RING,E	

FIGURE Q21 COUPLING ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q21 -	FG6-7578-000		1	COUPLING ASSEMBLY	
1	FA6-8230-000		1	COUPLING	
2	FA6-8304-000		1	WASHER, SPRING	
3	FS4-2168-000		1	SPRING, COMPRESSION	
4	FS7-2138-000		1	SPRING, TENSION	
5	FF3-1634-000		1	PLATE, SWING	
6	FS2-3470-000		1	PULLEY, 20T	
7	FS2-3745-000		1	PULLEY, 40T	
8	FS2-6561-000		1	WASHER, PLAIN	
9	FS3-0641-000		1	GEAR, 30T	
10	XG3-6012-405		2	BALL BEARING, NSK MF126ZZ	
11	XG3-8016-505		3	BALL BEARING	
12	XF9-0430-000		1	BELT, TIMING, FLAT	
501	XB6-7400-609		3	SCREW, TP, M4X6	
502	XD2-1100-502		4	RING, E	
503	XD2-1100-642		4	RING, E	
504	XD3-2200-162		2	PIN, DOWEL	
505	XD3-2300-142		1	PIN, DOWEL	
506	XD3-2200-082		1	PIN, DOWEL	

FIGURE Q31 RIGHT GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q31 -	FG6-7569-000		1	RIGHT GUIDE ASSEMBLY	
1	FA1-4842-030		1	ELIMINATOR, STATIC CHARGE	
2	FA3-7418-000		4	SPRING, ROLLER HOLDER	
3	FA3-7419-000		4	ROLLER (OLD)	
4	FB4-8766-000		1	ROLLER, FEEDER HOLDING	
5	FB5-9222-000		1	ROLLER, FEEDER INLET	
6	FC2-4269-000		1	ROLLER, PRESSURE	
7	FC2-4282-000		1	PLATE, ELIMINATOR	
8	FB4-8784-000		1	ARM, PRESS ROLLER	
9	FB5-9281-000		1	LATCH, RIGHT GUIDE, FRONT	
10	FC2-4295-000		1	ARM, ROLLER, RIGHT	
11	FC2-4333-000		1	HANDLE, GUIDE	
12	FG3-1868-000		1	CABLE, RIGHT GUIDE	J1095-1097
12A	WT2-5041-000		8	TIE, CABLE	
13	FF6-1227-000		1	GUIDE, FEEDER INLET	
13A	FB5-9229-000		1	SHEET, INLET GUIDE	
14	FB5-9275-000		2	SPRING, TORSION	
15	FC2-1249-000		2	FLAG, SENSOR	
16	FS1-1187-000		1	BUSHING	
17	FS1-1213-000		2	BUSHING	
18	FS1-1435-000		1	BUSHING	
19	FS1-9076-000		4	SCREW, STEPPED, M4	
20	FS4-0434-000		1	GEAR, 20T	
21	FS2-0386-000		2	GEAR, ROLLER, 20T	
22	WG8-5362-000		2	IC, TLP1241, PHOTO-INTERRUPTER	PI76,77 J1097,1095
23	FS4-2465-000		2	SPRING, TENSION	
24	XH9-0101-000		1	SHEET, RUBBER	
25	FB4-8999-000		1	LABEL, ARROW	
26	FA4-2340-000		1	SPRING, TORSION, REAR, LATCH	
27	FB5-9271-000		1	BALL BEARING, NSK MR106ZZ1MC4E	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q31 - 28	FC2-6542-000	N	1	LATCH, FRONT, GUIDE	
29	FS7-2641-000		2	SPRING, TENSION	
30	XG9-0407-000		1	BEARING, BALL, UGF106P12ZZD4ML	
31	FB5-9206-000		1	GUIDE, RIGHT, 2	
32	XG3-8016-505		2	BALL BEARING	
501	XB1-2300-606		2	SCREW,MACH.,TRUSS HEAD,M3X6	
502	XB6-7300-609		4	SCREW,TP,M3X6	
503	XB6-7400-609		18	SCREW,TP,M4X6	
504	XD2-1100-502		8	RING,E	
505	XD2-1100-642		2	RING,E	
506	XD2-2100-202		2	RING,GRIP	
507	XD3-2200-122		2	PIN,DOWEL	
508	XD3-2200-142		1	PIN,DOWEL	
509	XB1-2300-609		1	SCREW,MACH.,TRUSS HEAD,M3X6	

RIGHT INNER GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q32 -	FG6-7571-000		1	RIGHT INNER GUIDE ASSEMBLY	
1	FA3-7418-000		4	SPRING, ROLLER HOLDER	
2	FA3-7419-000		4	ROLLER (OLD)	
3	FB5-9275-000		1	SPRING, TORSION	
4	FC2-1249-000		1	FLAG, SENSOR	
5	WG8-5362-000		1	IC, TLP1241, PHOTO-INTERRUPTER	PI75 J1101
6	FG3-1976-000		1	CABLE, RIGHT INNER GUIDE	J1100,1101,1109
6A	WT2-5041-000		1	TIE, CABLE	
501	XB6-7400-609		6	SCREW,TP,M4X6	
502	XD2-2100-202		1	RING,GRIP	

FIGURE Q33 LEFT GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q33 -	FG6-7570-000		1	LEFT GUIDE ASSEMBLY	
1	FA4-2336-000		1	SHAFT, HANDLE	
2	FB5-9223-000		1	ROLLER, FEEDER OUTLET	
3	FB4-8771-000		1	COVER, LEFT GUIDE, 2	
4	FB4-8796-000		1	LATCH, LEFT GUIDE, FRONT	
5	FB4-8797-000		1	LATCH, LEFT GUIDE, REAR	
6	FB4-8798-000		1	SPRING, TORSION	
7	FA4-2371-000		1	ELIMINATOR, STATIC CHARGE	
8	FF5-8565-000		1	COVER, LEFT GUIDE	
8A	FB4-8999-000		1	LABEL, ARROW	
9	FC2-4310-000		1	PLATE, REFLECTOR	
10	FC2-4314-000		1	PLATE, STOPPER	
11	FC2-4333-000		1	HANDLE, GUIDE	
12	FB5-9275-000		1	SPRING, TORSION	
13	FC2-1249-000		1	FLAG, SENSOR	
14	FA4-2332-000		1	SPACER, GEAR	
15	FE9-0089-000		2	ROLLER, SIDE SUPPORT	
16	FS7-0391-000		1	GEAR, 20T	
17	FS1-1187-000		1	BUSHING	
18	FS1-1213-000		2	BUSHING	
19	FS1-1435-000		1	BUSHING	
20	FS2-0386-000		1	GEAR, ROLLER, 20T	
21	FS4-2465-000		2	SPRING, TENSION	
22	WG8-5382-000		1	PHOTO-INTERRUPTER	PI74 J1099
23	FG3-0965-000		1	CABLE, LEFT GUIDE	J795,796,1098,1099
23A	WT2-5041-000		7	TIE, CABLE	
24	XH9-0101-000		1	SHEET, RUBBER	
25	FG2-7911-000		1	LED PCB ASSEMBLY 2	
26	FA4-6702-000		3	SCREW, CAP	
27	FB5-9271-000		1	BALL BEARING, NSK MR106ZZ1MC4E	

FIGURE Q34 LEFT INNER GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q34 -	FG6-7572-000		1	LEFT INNER GUIDE ASSEMBLY	
1	FC2-1250-000		1	COVER, SENSOR	
2	FA4-2317-000		1	SHEET	
3	FG2-6904-000		1	SENSOR PCB ASSEMBLY	
4	FH7-5062-000		1	SOLENOID, 24VDC	SL74
5	FG3-1975-000		1	CABLE, LEFT INNER GUIDE	J1102,1103,1106,1112
5A	WT2-5041-000		3	TIE, CABLE	
6	FS2-2265-000		2	SPRING, TENSION (2)	
7	FS2-2264-000		1	SPRING, TENSION (1)	
8	FA4-2348-000	N	1	PLATE, ARM	
9	FA4-2349-000	N	1	MOUNT, COMPRESSION	
10	FA4-2350-000	N	2	ARM, PINCH ROLLER	
11	FA4-2351-000	N	1	LINK	
12	FA4-2352-000		2	ROLLER, PINCH	
13	FA4-2355-000		1	SPRING, TORSION, FRONT	
14	FA4-2356-000		1	SPRING, TORSION, REAR	
15	FA4-2363-000	N	1	LINK	
16	FF3-3877-000		1	SOLENOID, 24VDC	SL73 J1112
501	XB1-2300-409		4	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XB1-2300-609		3	SCREW,MACH.,TRUSS HEAD,M3X6	
503	XD2-1100-242		3	RING,E	
504	XD2-1100-502		4	RING,E	
505	XD2-2100-302		2	RING,GRIP	
506	XB6-7400-609		4	SCREW,TP,M4X6	
507	XB4-7300-609		2	SCREW,TAPPING,TRUSS HEAD,M3X6	
508	XD3-1300-082		2	PIN,SPRING	

FEED UPPER GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q35 -	FG6-7573-000		1	FEED UPPER GUIDE ASSEMBLY	
1	FB4-8977-000		8	SPRING, ROLLER HOLDER	
2	FA3-7419-000		8	ROLLER (OLD)	
3	FC2-5100-000		1	KNOB	
4	FB4-8978-000		2	LATCH, MAGNET	
5	4S1-9002-000		2	SCREW,M4X6	
501	XB6-7400-609		AR	SCREW,TP,M4X6	
502	XB6-7300-609		4	SCREW,TP,M3X6	

FIGURE Q36 INNER LEFT GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q36 -	FG6-7995-000		1	INNER LEFT GUIDE ASSEMBLY	
1	WG8-5362-000		1	IC, TLP1241, PHOTO-INTERRUPTER	PI73 J1105
2	WT2-5041-000		4	TIE, CABLE	
3	FG3-0966-000		1	CABLE, INNER LEFT GUIDE	J1104,1105,1108
3A	WT2-5041-000		4	TIE, CABLE	
4	FG6-3269-000		1	SOLENOID, 24VDC	SL72
5	FB5-9275-000		1	SPRING, TORSION	
6	FC2-1249-000		1	FLAG, SENSOR	
501	XB6-7400-609		4	SCREW,TP,M4X6	
502	XD2-2100-202		1	RING,GRIP	

FIGURE Q37 LOWER LEFT GUIDE ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q37 -	FG6-7582-000		1	LOWER RIGHT GUIDE ASSEMBLY	
1	FG2-7912-000		1	PHOTOTRANSISTOR PCB ASSEMBLY,2	
2	FG3-1872-000		1	CABLE, LOWER LEFT GUIDE	J797-799,1093,1094 J1096
2A	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	J1096
3	FG6-3268-000		1	SOLENOID, 24VDC	SL75
501	XB6-7400-609		3	SCREW,TP,M4X6	

FIGURE Q90 FOLDER DRIVER PCB ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q90 -	FG3-0087-000		1	FOLDER DRIVER PCB ASSEMBLY	
FU791	VD7-1621-001		1	FUSE, 60V, 1A	
J800	FF3-3876-000		1	CABLE, GROUNDING	
LED791	WG1-0373-000		1	LED, SEL2110RTP1	
LED792	WG1-0373-000		1	LED, SEL2110RTP1	

FIGURE QB LIST OF CONNECTORS




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B -	NPN		RF	LIST OF CONNECTORS	
J791	PCB			FOLDER DRIVER	
	FG3-0538-000		1	CABLE, FOLDER DRAWER MAIN	
J792	PCB			FOLDER DRIVER	
	FG3-0538-000		1	CABLE, FOLDER DRAWER MAIN	
J793	PCB			FOLDER DRIVER	
	VS1-0279-008		1	CONNECTOR, 8P, FEMALE	
	WS3-0437-000		8	SOCKET CONTACT, 20-30AWG	
J794	PCB			FOLDER DRIVER	
	VS1-0842-009		1	CONNECTOR, 9P, FEMALE	
J795	PCB			FOLDER DRIVER	
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J796	PCB			FOLDER DRIVER	
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
J797	PCB			FOLDER DRIVER	
	VS1-0842-006		1	CONNECTOR, 6P, FEMALE	
J798	PCB			FOLDER DRIVER	
	VS1-0279-004		1	CONNECTOR, 4P, FEMALE	
	WS3-0437-000		4	SOCKET CONTACT, 20-30AWG	
J799	PCB			FOLDER DRIVER	
	VS1-0279-006		1	CONNECTOR, 6P, FEMALE	
	WS3-0437-000		6	SOCKET CONTACT, 20-30AWG	
J1085	NPN			FOLDER SET SENSOR	PI71
	FG3-0540-000		1	CABLE, FOLDER FRAME REAR	
J1086	NPN			UPPER COVER OPEN/CLOSE SENSOR	PI72
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1087	FG3-0540-000		1	CABLE, FOLDER FRAME REAR	
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1088	SYS			TO SADDLE FINISHER	
	FG3-0540-000		1	CABLE, FOLDER FRAME REAR	
J1089	SYS			TO SADDLE FINISHER	
	FG3-0540-000		1	CABLE, FOLDER FRAME REAR	
J1091	FG3-0540-000		1	CABLE, FOLDER FRAME REAR	

	VS3-0108-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0885-000		2	PIN CONTACT, 20-30AWG	
J1092	NPN			UPPER DOOR OPEN/CLOSE SWITCH	SW71
	WS3-5649-000		1	CONNECTOR, 3P, FEMALE	
	WT1-0183-000		2	SOCKET CONTACT, 22-26AWG	

J1093	NPN			FOLDER MOTOR	M71
	VS1-0279-007		1	CONNECTOR, 7P, FEMALE	
	WS3-0437-000		7	SOCKET CONTACT, 20-30AWG	
J1094	PCB			FEEDER PASS 3 SENSOR PCB	
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	

	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
J1095	NPN			FOLDER PAPER SENSOR 2	PI77
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1096	VS1-0842-006		2	CONNECTOR, 6P, FEMALE	
	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	

J1097	NPN			PAPER FEED SENSOR 1	PI76
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1098	PCB			FEEDER PASS 3 SENSOR	
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	

J1099	NPN			PAPER PATH SENSOR	PI74
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1100	VS1-0842-003		2	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
J1101	NPN			FOLDER PAPER SENSOR 3	PI75

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q B - J1101	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1102	VS1-0842-004		2	CONNECTOR, 4P, FEMALE	
	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	
J1103	PCB			FEEDER PASS 2 SENSOR	
	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	
J1104	VS1-0842-003		2	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
J1105	NPN			FOLDER PAPER SENSOR 1	PI73
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1106	VS1-0279-004		1	CONNECTOR, 4P, FEMALE	
J1108	VS1-0280-004		1	CONNECTOR, 4P, FEMALE	
	WS3-0437-000		4	SOCKET CONTACT, 20-30AWG	
	WS3-0885-000		4	PIN CONTACT, 20-30AWG	
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
	VS1-0280-002		1	CONNECTOR, 2P, FEMALE	
J1109	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
	WS3-0885-000		2	PIN CONTACT, 20-30AWG	
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
	VS1-0280-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
J1110	WS3-1057-000		2	PIN CONTACT, 20-22AWG	
	FG3-0540-000		1	CABLE, FOLDER FRAME REAR	
	FG3-0538-000		1	CABLE, FOLDER DRAWER MAIN	
J1112	NPN			PRESSURE RELEASE SOLENOID	SL73
	VS1-0280-002		1	CONNECTOR, 2P, FEMALE	
J1126	WS3-0885-000		2	PIN CONTACT, 20-30AWG	
	SYS			TO SADDLE FINISHER	
	FG3-0540-000		1	CABLE, FOLDER FRAME REAR	

Document Insertion Unit-B1

[F25 - 9104 XCC00001 -]

CONTENTS

PA. ASSEMBLY LOCATION DIAGRAM

P01. MOUNTING HARDWARE 1

P02. MOUNTING HARDWARE 2

P10. EXTERNAL COVERS, PANELS, ETC.

P11. INTERNAL COMPONENTS

P12. PICK-UP TRAY ASSEMBLY

P14. UPPER COVER ASSEMBLY

P20. SEPARATION MOTOR ASSEMBLY

P30. SEPARATION ASSEMBLY

PB. LIST OF CONNECTORS

D3. NUMERICAL INDEX

FIGURE PA ASSEMBLY LOCATION DIAGRAM




FIGURE P01 MOUNTING HARDWARE 1




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P01 -	NPN		RF	MOUNTING HARDWARE 1	
1	FB4-8939-000		1	SPRING, TORSION	
2	FB4-8940-000		1	HOLDER, SPRING	
3	FF3-3868-000		1	CABLE, PASS SENSOR 3	J1068,1069
4	FS1-9194-000		1	SCREW, STEPPED, M4	
5	FS7-2152-000		1	SPRING, TENSION	
6	XA9-0629-000		7	SCREW,RS,M4X8	
7	XG9-0365-000		2	BEARING, BALL	
8	FB4-7663-000		1	RING, GEAR, A	
9	FB4-8936-000		1	ROLLER, FEED	
10	FB4-8946-000		1	TORQUE LIMITER	
11	FS5-3803-000		1	PULLEY, 30T	
12	FB4-8941-000		1	GUIDE, UPPER	
13	FF1-6572-000		2	PLATE, PIN	
14	XZ9-0289-000		2	CATCH, MAGNET	
15	FB5-9098-000		1	KNOB	
16	FB4-8942-000		1	GUIDE, LOWER	
17	FB4-8947-000		1	SUPPORT, GUIDE	
18	FF5-6194-000		4	ROLLER, FEED	
19	XA9-0685-000		4	SCREW,RS,M4X6	
20	FF5-8617-000		1	PLATE, TENSIONER	
21	FS2-3514-000		1	PULLEY, 30T	
22	FB5-3197-000		1	LABEL, NO.7	
23	FB1-7018-000		1	SPRING, TORSION	
24	FB4-8892-000		1	ARM, SENSOR	
25	WG8-5362-000		1	IC, TLP1241, PHOTO-INTERRUPTER	PI61 J1069
26	FS5-6661-000		1	FLANGE	
27	XA9-0721-000		1	SCREW,RS,M4X10	
28	XA9-0732-000		5	SCREW,RS,M4X8	
501	XB1-2400-609		4	SCREW,MACH.,TRUSS HEAD,M4X6	

MOUNTING HARDWARE 2




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P02 -	NPN		RF	MOUNTING HARDWARE 2	
1	FA6-8685-000		2	SCREW, STEPPED M5	
2	FG3-1869-000		1	CABLE, INSERTER INTERFACE	J841,843,1065,1066 J1128
2A	WT2-5565-000		1	CLAMP, CABLE	
3	WT2-0409-000		1	BUSHING	
4	FF3-3867-000		1	CABLE, PASS SENSOR 3 CONNECTOR	J1067,1068
4A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1068
5	FF5-8616-000		1	PANEL, REAR UPPER, 2	
6	XA9-0629-000		8	SCREW,RS,M4X8	
7	XF2-1618-040		1	BELT, TIMING	
8	XA9-0892-000		AR	SCREW,MACH.,TRUSS HEAD,M4X6	
9	FC1-2309-000		1	RETAINER, CORD	
10	FB5-3194-000		1	LABEL, LIMIT	
11	FB5-3195-000		1	LABEL, PAPER SIZE	
12	FB5-3200-000		1	SPACER, COVER, A	
13	FB4-8935-000		1	SPRING, LEAF	
14	FB3-0835-020		1	GUIDE, CABLE	
501	XB1-2500-806		3	SCREW,MACH.,TRUSS HEAD,M5X8	
502	XB4-7401-009		1	SCREW,TAPPING,TRUSS HEAD,M4X10	

FIGURE P10 EXTERNAL COVERS, PANELS, ETC.




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P10 -	NPN		RF	EXTERNAL COVERS, PANELS, ETC.	
1	FB4-8920-000		1	PANEL, REAR	
2	FB4-8921-000		1	PANEL, FRONT	
3	FB4-8922-000		1	TRAY, AUXILIARY	
4	FB4-8888-000		1	COVER, BOTTOM	
5	FB4-8897-000		2	SUPPORT, BOTTOM PANEL	
501	XB4-7400-809		4	SCREW,TAPPING,TRUSS HEAD,M4X8	

INTERNAL COMPONENTS (1/3)





FIGURE P11 INTERNAL COMPONENTS (2/3)



INTERNAL COMPONENTS (3/3)



FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P11 -	NPN		RF	INTERNAL COMPONENTS	
1	FB4-7563-000		1	ROLLER, PICK-UP PRESSURE	
2	FB4-7567-000		1	PLATE, PICK-UP TENSION, FRONT	
3	FB4-7568-000		1	PLATE, PICK-UP TENSION, REAR	
4	FB4-7570-000		1	UPPER GUIDE, PICK-UP, A	
5	FB4-7571-000		1	UPPER GUIDE, PICK-UP, B	
6	FB4-7572-000		1	UPPER GUIDE, PICK-UP, C	
7	FB4-7584-000		1	LINK, FRONT	
8	FB4-7585-000		1	LINK, REAR	
9	FB4-7599-000		1	COVER, INTERNAL	
10	FB4-7662-000		1	RING, CLUTCH	
11	FB4-7663-000		1	RING, GEAR, A	
12	FB4-7664-000		1	RING, GEAR, B	
13	FB4-7669-000		1	GEAR, 24T	
14	FB4-7670-000		1	GEAR, 24T	
15	FB4-8875-000		1	HINGE UNIT	
16	FB4-8876-000		1	ROLLER, PAPER FEED	
17	FB4-8877-000		1	ROLLER, PICK-UP	
18	FB4-8901-000		1	PLATE	
19	FB4-8905-000		1	HINGE, LEFT, LOWER	
20	FB4-8906-000		1	HINGE, LEFT, UPPER	
21	FF3-3869-000		1	CABLE, LED SENSOR CONNECTOR	J1076,1077
21A	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	J1077
22	FF3-3870-000		1	CABLE, FRONT COVER SENSOR	J1082,1083
22A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1082
23	FF5-8205-000		1	SUPPORT PLATE, GEAR, FRONT	
24	FF6-1300-000		1	GUIDE, PAPER PICK-UP	
24A	FB4-7573-000		1	SHEET, SEPARATION	
25	FF5-8597-000		2	PLATE, PIVOT	
26	FH7-5877-000		1	CLUTCH, ELECTROMAGNETIC	CL61 J1072

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P11 - 27	FS7-2154-000		2	SPRING, TENSION	
28	RS5-9003-000		2	SCREW, STEPPED, M3	
29	FS6-0094-000		2	GEAR, 24T	
30	FS7-0314-000		1	GEAR, 24T	
31	FS7-2039-000		1	SPRING, COMPRESSION	
32	FS5-6158-000		1	ROLLER, LIFTER	
33	XA9-0892-000		AR	SCREW,MACH.,TRUSS HEAD,M4X6	
34	XD9-0152-000		4	WASHER, SHIM	
35	XG9-0237-000		6	BEARING, BALL	
36	FB4-7556-000		1	SHAFT, STOPPER	
37	FB4-7586-000		1	ARM, FRONT	
38	FB4-7587-000		1	ARM, REAR	
39	FB4-7588-000		2	HOLDER, ARM	
40	FB4-7768-000		1	LINK, SHUTTER, A	
41	FB4-8031-000		1	SPRING, TORSION	
42	FB4-8032-000		1	SPRING, TORSION	
43	FB4-8033-000		1	SPRING, TORSION	
44	FB4-7558-000		1	SHEET, DAMPER	
45	FB1-7018-000		3	SPRING, TORSION	
46	FB4-8943-000		3	SHAFT, SENSOR ARM	
47	FF3-3871-000		1	CABLE, SEPARATION SENSOR	J1081,1079,1080
47A	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	J1079
48	WG8-5362-000		6	IC, TLP1241, PHOTO-INTERRUPTER	PI62-67 J1080-1084,1073,1074
49	FB4-8892-000		2	ARM, SENSOR	
50	FG2-9361-000		1	PHOTOTRANSISTOR PCB ASSEMBLY	
51	FB4-7582-000		1	CAP, DOCUMENT SENSOR	
52	FB4-8912-000		1	ARM, SOLENOID	
53	FB4-8918-000		1	SPRING, TORSION	
54	FF5-8598-000		1	PLATE, POSITIONING	
55	FB4-8914-000		1	LINK, SOLENOID	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P11 - 56	FB4-8919-000		1	SHAFT, LINK	SL62 J1071
57	FH7-5874-000		1	SOLENOID, DC24V	
58	FB4-7578-000		2	CAM, PICK-UP RELEASE	
59	FB4-8894-000		1	ARM, PICK-UP RELEASE, REAR	
60	FB4-8895-000		1	ARM, PICK-UP RELEASE, FRONT	
61	FF5-8605-000		1	SUPPORT, GEAR/PULLEY	
62	FS2-6466-000		1	FLANGE, ROLLER	
63	FS7-0397-000		1	GEAR, 22T/PULLEY, 27T	
64	FB5-9531-000		2	COVER, HOOK	
65	FS1-1376-000		1	BUSHING	
66	FS1-1528-000		1	BUSHING	
67	FB4-8925-000		12	SPACER	
68	FF5-8607-000		1	SUPPORT, ADJUSTER, 1	
69	FA6-8623-000		2	FOOT, RUBBER	
70	FB4-2131-000		1	PIN, HINGE GUIDE	
71	FF5-8608-000		1	SUPPORT, ADJUSTER, 2	
72	XA9-1035-000		1	SCREW,M4X4	
73	FS5-6243-000		1	ROLLER	
74	FS5-0748-000		1	GEAR, IDLER, 30T	
75	FB4-8948-000		1	ARM, PICK-UP SENSOR	
76	FB4-8880-000		1	GUIDE, INSIDE	
77	FB4-8917-000		1	SHAFT, HINGE	
78	FG2-9362-000		1	LED PCB ASSEMBLY	
79	FB4-7583-000		1	MOUNT, DOCUMENT SENSOR	
80	XA9-0894-000		1	SCREW,M3X6	
81	FG3-1830-000		1	INSERTER DRIVER PCB ASSEMBLY	SL61 J1070
82	FS1-9167-000		1	SCREW,STEPPED,M4	
83	FF5-8604-000		1	SOLENOID	
84	FS7-2151-000		1	SPRING, TENSION	
501	XB1-2300-609		5	SCREW,MACH.,TRUSS HEAD,M3X6	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P11 - 502	XB1-2400-606		18	SCREW,MACH.,TRUSS HEAD,M4X6	
503	XB4-7401-009		2	SCREW,TAPPING,TRUSS HEAD,M4X10	
504	XD2-1100-502		4	RING,E	
505	XD2-1100-642		11	RING,E	
506	XD2-2100-802		1	RING,GRIP	
507	XB1-2300-409		6	SCREW,MACH.,TRUSS HEAD,M3X4	
508	XB6-7300-609		2	SCREW,TP,M3X6	
509	XD2-1100-322		4	RING,E	
510	XD2-1100-242		6	RING,E	
511	XD3-1200-102		1	PIN,SPRING	
512	XD2-1100-402		2	RING,E	
513	XD2-2100-402		2	RING,GRIP	

FIGURE P12 PICK-UP TRAY ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P12 -	FG6-3310-000		1	PICK-UP TRAY ASSEMBLY	
1	FB4-7710-000		2	BLOCK, TRAY RACK, A4R	
2	FB4-7711-000		2	BLOCK, TRAY RACK, LTR-R	
3	FB4-8886-000		1	GUIDE, SLIDE, REAR	
4	FB4-8887-000		1	GUIDE, SLIDE, FRONT	
5	FB4-8900-000		1	BLOCK, TRAY LIMIT	
6	FC1-6179-000		2	CLAMP, GUIDE	
7	FB5-3193-000		1	LABEL, PAPER SET	
8	FN5-0151-000		2	COVER, LED	
9	FB5-3196-000		1	LABEL, COVER	
10	FS4-0177-000		1	GEAR, 16T	
501	XB4-7300-609		2	SCREW,TAPPING,TRUSS HEAD,M3X6	
502	XD2-2100-602		1	RING,GRIP	

FIGURE P14




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P14 -	FG6-3303-000		1	UPPER PANEL ASSEMBLY	
1	FB4-8896-000		3	ROLLER	
2	FC2-1303-000		3	SHAFT, ROLLER	
3	FC2-2146-000		6	SPRING, LEAF	
4	FF5-8596-000		1	PANEL, UPPER	
4A	FB5-3192-000		1	LABEL, CAUTION	

FIGURE P20 SEPARATION MOTOR ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P20 -	FG6-3307-000		1	SEPARATION MOTOR ASSEMBLY	M61 J1075
1	FH6-1637-000		1	MOTOR, DC24V	
2	FS5-3732-000		1	PULLEY, 18T/55T	
3	FS5-6323-000		1	FLANGE	
4	FS7-2024-000		1	SPRING, TENSION	
5	FS7-2155-000		1	SPRING, TENSION	
6	XA9-0892-000		2	SCREW,MACH.,TRUSS HEAD,M4X6	
7	FC2-1291-000		2	PULLEY	
8	XF2-1607-840		1	BELT, TIMING	
9	XF2-1612-460		1	BELT, TIMING	
10	FB3-7269-000		1	LINK	
11	XA9-0732-000		1	SCREW,RS,M4X8	
501	XB1-2400-409		2	SCREW,MACH.,TRUSS HEAD,M4X4	
502	XD2-1100-502		2	RING,E	
503	XD2-1100-402		1	RING,E	

FIGURE P30 SEPARATION ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P30 -	FG6-3304-000		1	SEPARATION ASSEMBLY	
1	FA4-1159-000		4	RING, RETAINING	
2	FB4-7640-000		2	ROLLER, PICK-UP	
3	FB4-7641-000		2	ARM, PICK-UP, FRONT	
4	FB4-7642-000		2	ARM, PICK-UP, REAR	
5	FB4-7645-000		1	PLATE, SUPPORT	
6	FB4-8878-000		1	ARM, ROD	
7	FB4-8884-000		1	GUIDE, SEPARATION	
8	FS1-1189-000		2	BUSHING	
9	FS1-1508-000		1	BUSHING	
10	FS3-0137-000		1	GEAR, 20T	
11	FS7-0318-000		1	GEAR, 20T	
12	FS7-0322-000		1	GEAR, 20T	
13	XF9-0684-000		2	BELT, TIMING, 92T	
14	FB4-6991-000		12	ROLLER	
15	FB4-7636-000		1	ROLLER,FEED	
16	FB5-9518-000		4	PULLEY, SEPARATION	
17	FB4-7639-000		1	SHAFT, SEPARATION	
18	FB4-7646-000		1	HOLDER, SEPARATION, FRONT	
19	FB4-7647-000		1	HOLDER, SEPARATION, REAR	
20	FB4-7648-000		2	SPRING, LEAF	
21	FB4-7650-000		1	LEVER	
22	FB4-7651-000		1	CAP	
23	FB4-8950-000		1	ROLLER, SEPARATION	
24	FC2-1227-000		1	COLLAR, SHAFT	
25	FC2-1258-000		2	CLAMP, PITCH, SEPARATION	
26	FC2-1369-000		1	PULLEY, SEPARATION	
27	FC2-1370-000		1	RING, PITCH, A	
28	FC2-1371-000		1	RING, PITCH, B	
29	FC2-1827-000		11	BELT, SEPARATION	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P30 - 30	XA9-1028-000		2	SCREW,ALLEN HEAD,M3X10	
31	XG9-0211-000		2	BALL BEARING, MF128ZZ1MC3D4M	
501	XB1-2300-409		10	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XD2-1100-322		2	RING,E	
503	XD2-1100-502		5	RING,E	
504	XD2-1100-642		5	RING,E	
505	XD2-2100-802		2	RING,GRIP	
506	XD3-2200-102		1	PIN,DOWEL	
507	XB1-1300-609		1	SCREW,MACH.,PAN HEAD,M3X6	
508	XB6-7300-409		2	SCREW,TP,M3X4	
509	XD2-1100-802		6	RING,E	

FIGURE PB LIST OF CONNECTORS




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P B -	NPN		RF	LIST OF CONNECTORS	
J841	PCB			INSERTER DRIVER	
	VS1-5824-009		1	CONNECTOR, 9P, FEMALE	
	VS1-6053-018		1	CONNECTOR, 18P, FEMALE	
	VS1-6094-009		1	CONNECTOR, 9P, FEMALE	
J842	WS3-5358-000		18	SOCKET CONTACT, 22-26AWG	
	PCB			INSERTER DRIVER	
	VS1-0842-012		1	CONNECTOR, 12P, FEMALE	
J843	PCB			INSERTER DRIVER	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	
J844	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	
	PCB			INSERTER DRIVER	
	VS1-0842-005		1	CONNECTOR, 5P, FEMALE	
J845	PCB			INSERTER DRIVER	
	VS1-0842-010		1	CONNECTOR, 10P, FEMALE	
J846	PCB			INSERTER DRIVER	
	VS1-0842-006		1	CONNECTOR, 6P, FEMALE	
J847	PCB			INSERTER DRIVER	
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
J1065	SYS			TO SADDLE FINISHER	
	VS1-5824-010		1	CONNECTOR,10P,FEMALE	
	WS3-5358-000		9	SOCKET CONTACT, 22-26AWG	
J1066	SYS			TO SADDLE FINISHER	
	VS1-5824-009		1	CONNECTOR, 9P, FEMALE	
J1067	WS3-5358-000		9	SOCKET CONTACT, 22-26AWG	
	SYS			TO SADDLE FINISHER	
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1068	VS1-0842-003		2	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P B - J1069	NPN			PAPER FEED SENSOR 3	PI61
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1070	NPN			PAPER PICK-UP SOLENOID	SL61
	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
J1071	NPN			STOPPER SOLENOID	SL62
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
J1072	NPN			SEPARATION CLUTCH	CL61
	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
J1073	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
	NPN			INSERTER CLOSE SENSOR	PI66
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1074	NPN			MOTOR CLOCK SENSOR	PI67
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1075	NPN			INSERTER MOTOR	M61
	VS1-0279-002		1	CONNECTOR, 2P, FEMALE	
	WS3-0437-000		2	SOCKET CONTACT, 20-30AWG	
J1076	PCB			PAPER SET SENSOR	
	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
J1077	VS1-0842-002		2	CONNECTOR, 2P, FEMALE	
	VS1-5057-002		1	CONNECTOR, SNAP TIGHT	
J1078	PCB			PAPER SET SENSOR	
	VS1-0842-002		1	CONNECTOR, 2P, FEMALE	
J1079	VS1-0842-006		2	CONNECTOR, 6P, FEMALE	
J1080	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	
	NPN			PAPER FEED SENSOR 1	PI62
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1081	NPN			PAPER FEED SENSOR 2	PI63
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
P B - J1082	VS1-0842-003		2	CONNECTOR, 3P, FEMALE	
	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	
J1083	NPN			COVER OPEN/CLOSE FRONT SENSOR	PI64
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1084	NPN			COVER OPEN/CLOSE REAR SENSOR	PI65
	VS1-0842-003		1	CONNECTOR, 3P, FEMALE	
J1128	SYS		2	TO SADDLE FINISHER	
	VS3-5083-002		1	CONNECTOR, 2P, FEMALE	
	WS3-5160-000		2	SOCKET CONTACT, 18-24AWG	

Puncher Unit-E1/F1

Puncher Unit-E1

〔 F25 - 9102 〕

Puncher Unit-F1

〔 F25 - 9112 〕

CONTENTS

Q45. PUNCH ASSEMBLY

Q46. PUNCH WASTE FEED MOTOR ASSEMBLY

D4. NUMERICAL INDEX

PUNCH ASSEMBLY



FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q45 -	FG6-7541-000		1	PUNCH ASSEMBLY	E1 TYPE
	FG6-7542-000		1	PUNCH ASSEMBLY	F1 TYPE
1	FG3-1977-000		1	CABLE, PUNCH PAPER SENSOR	J1001,1131
1A	WT2-5178-000		2	CLIP, CABLE	
2	XA9-0732-000		AR	SCREW,RS,M4X8	
3	FB3-3834-000		1	KNOB	
4	FB5-9161-000		1	LEVER, RELEASE	
5	FB4-8684-000		1	ELIMINATOR, STATIC CHARGE	
6	XZ9-0522-000		2	RAIL, SLIDE	
7	WG8-5382-000		2	PHOTO-INTERRUPTER	PI23,24 J1010,1012
8	XA9-0892-000		2	SCREW,MACH.,TRUSS HEAD,M4X6	
9	FS7-2112-000		1	SPRING, TENSION	
10	FG3-1871-000		1	CABLE, PUNCH UNIT, 2	J745-747,750,1003 J1005,1007-1009,1013
11	FG6-7550-000		1	PUNCH UNIT, 4 HOLE	E1 TYPE
	FG6-7551-000		1	PUNCH UNIT, 4 HOLE	F1 TYPE
11A	FF6-1207-000		1	MOTOR, DC	M18 J1007
11B	WG8-5382-000		2	PHOTO-INTERRUPTER	PI22,25 J1009,1013
11C	FF6-1209-000		4	DUCT, WASTE	E1 TYPE
	FF6-1209-000		2	DUCT, WASTE	F1 TYPE
11D	WG8-5464-000		1	PHOTO INTERRUPTER, TLP1253(C6)	PI34 J1003
12	XF2-1308-210		1	BELT, TIMING	
13	FB5-9167-000		1	GUIDE, PAPER	
14	FH6-1912-000		1	MOTOR, STEPPING, DC	M19 J1005
15	FS6-0557-000		1	GEAR, 12T/36T	
16	VS1-5057-006		1	CONNECTOR, SNAP TIGHT	J1007
17	FG3-1862-000		1	CABLE, PUNCH SIDE REGISTRATION	J1006,1007,1010,1131
17A	VS1-5057-003		1	CONNECTOR, SNAP TIGHT	J1006
17B	VS1-5057-009		1	CONNECTOR, SNAP TIGHT	J1010
17C	VS1-5057-004		1	CONNECTOR, SNAP TIGHT	J1131
18	FG3-1864-000		1	CABLE, PUNCH SHIFT H. POSITION	J1006,1012

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q45 - 19	FH7-7564-000		1	PHOTO-INTERRUPTER	PI21 J1001
20	FS1-9009-000		1	SCREW, STEPPED, M3	
21	FB5-2643-000		1	SCREW, WASTE APPROACH	
22	FB5-2645-000		1	SCREW, WASTE DELIVERY	
23	FB5-2646-000		1	CAM, WASTE CRUSH	
24	FF5-8636-000		1	COVER, SCREW UPPER	
25	FF5-8644-000		1	DUCT, WASTE	
26	FS7-0404-000		1	GEAR, 22T	
27	XG9-0214-000		2	BALL BEARING, NSK MR126JZZMC3	
28	FB5-9148-000		1	HOLDER, BELT, 1	
29	FB5-9149-000		1	HOLDER, BELT, 2	M17 J744
30	FF6-1205-000		1	SUPPORT, TENSION	
31	FH6-1901-000		1	MOTOR, STEPPING, DC	
32	FS2-9394-000		1	SCREW, STEPPED, M3X1.4	
33	FS5-3255-000		1	PULLEY, 24T	
501	XB1-2300-409		AR	SCREW, MACH., TRUSS HEAD, M3X4	
502	XB1-2400-409		2	SCREW, MACH., TRUSS HEAD, M4X4	
503	XB4-7400-809		1	SCREW, TAPPING, TRUSS HEAD, M4X8	
504	XB4-7400-609		1	SCREW, TAPPING, TRUSS HEAD, M4X6	
505	XD2-1100-642		6	RING, E	
506	XD3-2200-102		2	PIN, DOWEL	
507	XD3-2200-142		1	PIN, DOWEL	
508	XB1-2400-609		5	SCREW, MACH., TRUSS HEAD, M4X6	
509	XB1-2300-609		4	SCREW, MACH., TRUSS HEAD, M3X6	

FIGURE Q46

PUNCH WASTE FEED MOTOR ASSEMBLY




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q46 -	NPN		RF	PUNCH WASTE FEED MOTOR ASS'Y	
1	FB5-2650-000		1	SPRING, GROUNDING	
2	FS7-0405-000		1	GEAR, 22T/RATCHET	
3	WG8-5382-000		1	PHOTO-INTERRUPTER	PI27 J1004
4	FG3-1863-000		1	CABLE, WASTE FEED MOTOR SENSOR	J742,1004
5	FG6-4847-000		1	MOTOR, DC	M16 J749
501	XB1-2300-409		5	SCREW,MACH.,TRUSS HEAD,M3X4	
502	XB6-7400-607		1	SCREW,TP,M4X6	
503	XD2-1100-642		1	RING,E	

D1 NUMERICAL INDEX (Saddle Finisher-K3/K4)

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
4A1-0746-000	Q20 - 1	FB3-7954-000	Q50 - 37A	FB4-8439-000	Q20 - 70
4A1-2349-000	Q58 - 26	FB3-7966-000	Q58 - 13	FB4-8441-000	Q20 - 63
4S1-9002-000	Q12 - 15	FB3-7967-000	Q50 - 24	FB4-8442-000	Q24 - 11
	Q58 - 1	FB3-7969-000	Q50 - 25	FB4-8453-000	Q20 - 5
FA2-5970-000	Q22 - 1	FB3-7973-000	Q50 - 26	FB4-8457-000	Q20 - 6
FA2-8244-000	Q58 - 2	FB3-7977-000	Q57 - 5	FB4-8458-000	Q20 - 7
FA3-4725-000	Q30 - 1	FB3-7978-000	Q58 - 19	FB4-8459-000	Q20 - 8
FA4-6702-000	Q53 - 1	FB3-7984-000	Q50 - 66	FB4-8460-000	Q20 - 9
FA5-5377-000	Q20 - 2	FB3-7985-000	Q50 - 67	FB4-8592-000	Q30 - 89
FA6-0768-020	Q30 - 14	FB3-9233-000	Q13 - 31	FB4-8600-000	Q33 - 1
	Q30 - 19A	FB3-9234-000	Q13 - 32	FB4-8602-000	Q01 - 6
	Q33 - 2	FB4-8236-000	Q16 - 1	FB4-8604-000	Q10 - 15D
FA6-2369-000	Q37 - 10	FB4-8237-000	Q10 - 15A	FB4-8616-000	Q30 - 3
FB1-7018-000	Q52 - 30	FB4-8238-000	Q13 - 9	FB4-8617-000	Q30 - 4
FB1-7099-020	Q30 - 70	FB4-8239-000	Q10 - 15B	FB4-8618-000	Q30 - 66
FB1-7172-000	Q58 - 3	FB4-8240-000	Q13 - 1	FB4-8619-000	Q30 - 5
FB1-7173-000	Q37 - 1	FB4-8245-000	Q55 - 5	FB4-8620-000	Q31 - 7
FB1-7214-000	Q12 - 1	FB4-8246-000	Q01 - 1	FB4-8622-000	Q30 - 6
	Q59 - 1	FB4-8248-000	Q10 - 15C	FB4-8623-000	Q30 - 7
FB2-0037-000	Q10 - 1	FB4-8250-000	Q11 - 2	FB4-8624-000	Q30 - 8
FB2-1178-000	Q52 - 1	FB4-8265-000	Q01 - 2	FB4-8630-000	Q36 - 1
FB2-4117-000	Q13 - 24	FB4-8266-000	Q01 - 3	FB4-8641-000	Q30 - 57
FB2-4120-000	Q13 - 25	FB4-8271-020	Q10 - 9A	FB4-8657-000	Q32 - 1
FB2-6416-000	Q54 - 1	FB4-8273-000	Q10 - 16	FB4-8661-000	Q30 - 64
FB2-7897-000	Q14 - 30	FB4-8274-000	Q10 - 17	FB4-8663-000	Q37 - 2
FB2-7898-000	Q14 - 31	FB4-8275-020	Q10 - 18	FB4-8668-000	Q30 - 90
FB2-7899-000	Q14 - 32	FB4-8276-000	Q10 - 19	FB4-8682-000	Q37 - 15
FB2-7900-000	Q14 - 33	FB4-8277-000	Q10 - 20	FB4-8684-000	Q45 - 5
FB2-8506-000	Q14 - 34	FB4-8278-000	Q10 - 21	FB4-8690-000	Q30 - 91
FB3-0087-000	Q37 - 21	FB4-8279-000	Q10 - 22	FB4-8697-020	Q10 - 15E
FB3-0122-000	Q10 - 2	FB4-8280-020	Q10 - 23	FB4-8698-000	Q10 - 15F
FB3-0123-030	Q30 - 2	FB4-8282-000	Q10 - 24	FB4-8701-000	Q31 - 1
FB3-3834-000	Q45 - 3	FB4-8283-000	Q10 - 25	FB4-8702-000	Q31 - 2
FB3-7285-000	Q20 - 84A	FB4-8284-000	Q10 - 9B	FB4-8703-000	Q31 - 3
	Q20 - 87A	FB4-8285-020	Q10 - 9C	FB4-8704-000	Q31 - 4
FB3-7846-000	Q50 - 69	FB4-8286-000	Q10 - 9D	FB4-8712-000	Q37 - 7
FB3-7847-000	Q50 - 70	FB4-8288-000	Q10 - 26	FB4-8713-000	Q30 - 9
FB3-7848-000	Q50 - 71	FB4-8297-000	Q19 - 1	FB4-8715-000	Q32 - 3
FB3-7852-000	Q53 - 2	FB4-8298-000	Q10 - 10A	FB4-8716-000	Q33 - 3
FB3-7854-000	Q53 - 3	FB4-8302-000	Q18 - 1	FB4-8717-000	Q12 - 7A
FB3-7855-000	Q50 - 91A		Q19 - 2	FB4-8718-000	Q30 - 58
FB3-7856-000	Q50 - 8	FB4-8303-000	Q18 - 24	FB4-8720-000	Q37 - 16
FB3-7865-000	Q54 - 2		Q19 - 24	FB4-8721-000	Q30 - 61
FB3-7866-000	Q54 - 3	FB4-8304-000	Q19 - 3	FB4-8722-000	Q01 - 7
FB3-7867-000	Q54 - 4	FB4-8306-000	Q18 - 2		Q10 - 12A
FB3-7869-000	Q50 - 9		Q19 - 4	FB4-8726-030	Q10 - 3
FB3-7876-000	Q56 - 1	FB4-8307-000	Q18 - 16	FB4-8727-000	Q10 - 4
FB3-7877-000	Q56 - 2		Q19 - 18	FB4-8728-000	Q10 - 5
FB3-7878-000	Q56 - 3	FB4-8310-000	Q18 - 3	FB4-8804-000	Q55 - 6
FB3-7881-000	Q11 - 1		Q19 - 5	FB4-8807-000	Q13 - 22
FB3-7883-000	Q50 - 10	FB4-8320-000	Q18 - 9	FB4-8809-000	Q52 - 2
FB3-7885-000	Q50 - 65		Q19 - 12	FB4-8810-000	Q52 - 3
FB3-7888-000	Q50 - 78	FB4-8321-000	Q18 - 10	FB4-8813-000	Q10 - 6
FB3-7889-000	Q50 - 79		Q19 - 13	FB4-8815-000	Q13 - 28
FB3-7894-000	Q57 - 1	FB4-8328-000	Q18 - 11	FB4-8816-000	Q13 - 29
FB3-7895-000	Q57 - 2		Q19 - 14	FB4-8817-000	Q13 - 11
FB3-7896-000	Q57 - 3	FB4-8329-000	Q19 - 6	FB4-8818-000	Q13 - 12
FB3-7897-000	Q57 - 4	FB4-8336-000	Q19 - 27	FB4-8819-000	Q13 - 13
FB3-7901-000	Q58 - 4	FB4-8337-000	Q18 - 22	FB4-8821-000	Q13 - 38
FB3-7904-000	Q58 - 5	FB4-8339-000	Q18 - 26B	FB4-8825-000	Q50 - 1
FB3-7906-000	Q58 - 6		Q19 - 26B	FB4-8828-000	Q10 - 7
FB3-7907-000	Q58 - 7	FB4-8340-000	Q01 - 4	FB4-8829-000	Q50 - 27
FB3-7909-000	Q58 - 8	FB4-8344-020	Q10 - 27	FB4-8835-000	Q52 - 4
FB3-7910-000	Q58 - 9	FB4-8345-000	Q01 - 5	FB4-8836-000	Q52 - 5
FB3-7912-000	Q50 - 11	FB4-8350-000	Q11 - 3	FB4-8840-000	Q52 - 6
FB3-7915-000	Q50 - 12	FB4-8360-000	Q23 - 10A	FB4-8841-000	Q52 - 7
FB3-7921-000	Q58 - 10	FB4-8361-000	Q23 - 10B	FB4-8843-000	Q52 - 31
FB3-7925-000	Q50 - 13	FB4-8366-000	Q21 - 1	FB4-8844-000	Q52 - 32
FB3-7927-000	Q50 - 14	FB4-8368-020	Q21 - 2	FB4-8845-000	Q52 - 8
FB3-7928-000	Q50 - 15	FB4-8376-000	Q22 - 12	FB4-8846-000	Q52 - 18
FB3-7929-000	Q58 - 11	FB4-8392-000	Q22 - 2	FB4-8848-000	Q52 - 21
FB3-7930-000	Q50 - 16	FB4-8394-000	Q24 - 8	FB4-8849-000	Q52 - 22
FB3-7932-000	Q58 - 12	FB4-8395-000	Q24 - 9	FB4-8850-000	Q52 - 9
FB3-7934-000	Q50 - 17	FB4-8397-000	Q24 - 6	FB4-8851-000	Q52 - 10
FB3-7937-000	Q50 - 18	FB4-8404-000	Q24 - 14	FB4-8861-000	Q10 - 30
FB3-7939-000	Q50 - 19	FB4-8406-000	Q24 - 22	FB4-8863-000	Q14 - 1
FB3-7940-000	Q50 - 20	FB4-8407-000	Q24 - 23	FB4-8864-000	Q14 - 2
FB3-7941-000	Q50 - 21	FB4-8408-000	Q24 - 20	FB4-8865-000	Q14 - 3
FB3-7943-000	Q50 - 22	FB4-8413-000	Q20 - 44A	FB4-8866-000	Q14 - 4
FB3-7944-000	Q50 - 23	FB4-8421-000	Q20 - 62	FB4-8868-000	Q14 - 5
FB3-7945-000	Q56 - 4	FB4-8427-000	Q20 - 46	FB4-8871-000	Q10 - 31
FB3-7946-000	Q56 - 5	FB4-8430-000	Q20 - 3	FB4-8872-000	Q13 - 35
FB3-7947-000	Q56 - 6	FB4-8431-000	Q20 - 4		Q14 - 18
FB3-7948-000	Q50 - 97	FB4-8436-000	Q20 - 68A	FB4-8873-000	Q14 - 6A
FB3-7949-000	Q50 - 6	FB4-8438-000	Q20 - 69		Q14 - 16A

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
FB4-8874-000	Q10 - 32	FB5-9034-000	Q41 - 7	FF5-8464-000	Q01 - 13
FB4-8931-000	Q10 - 11	FB5-9038-000	Q41 - 8	FF5-8481-000	Q22 - 3
FB4-8933-000	Q01 - 8	FB5-9042-000	Q40 - 23	FF5-8483-000	Q23 - 1
	Q10 - 12B	FB5-9043-000	Q13 - 36	FF5-8486-000	Q24 - 1
FB4-8953-000	Q10 - 13	FB5-9044-000	Q13 - 37	FF5-8489-000	Q24 - 17
FB4-8954-000	Q10 - 14	FB5-9050-000	Q40 - 28	FF5-8490-000	Q24 - 18
FB4-9011-000	Q50 - 28	FB5-9052-000	Q41 - 1	FF5-8491-000	Q20 - 41
FB4-9012-000	Q56 - 7	FB5-9053-000	Q41 - 2	FF5-8493-000	Q24 - 24
FB4-9159-000	Q54 - 13	FB5-9054-000	Q40 - 1	FF5-8494-000	Q20 - 11
FB4-9163-000	Q53 - 5A	FB5-9057-000	Q41 - 3	FF5-8495-000	Q20 - 60
FB4-9164-000	Q53 - 5B	FB5-9061-000	Q40 - 2	FF5-8496-000	Q20 - 48
FB4-9166-000	Q58 - 14	FB5-9065-000	Q11 - 4	FF5-8500-020	Q20 - 51
FB4-9167-000	Q50 - 91B	FB5-9066-000	Q40 - 10	FF5-8509-000	Q30 - 60
FB4-9168-000	Q58 - 20	FB5-9067-000	Q40 - 24	FF5-8523-000	Q30 - 72
FB4-9171-000	Q50 - 29	FB5-9069-000	Q41 - 4	FF5-8524-030	Q31 - 8
FB4-9172-000	Q50 - 30	FB5-9070-000	Q11 - 5	FF5-8525-000	Q37 - 8
FB4-9173-000	Q54 - 5	FB5-9072-000	Q10 - 15H	FF5-8527-000	Q10 - 8
FB4-9174-000	Q50 - 80	FB5-9073-000	Q20 - 39	FF5-8529-000	Q30 - 15
FB5-2636-000	Q12 - 10	FB5-9074-000	Q41 - 5	FF5-8530-000	Q30 - 73
FB5-2643-000	Q45 - 21	FB5-9075-000	Q30 - 80	FF5-8531-000	Q30 - 74
FB5-2645-000	Q45 - 22	FB5-9079-000	Q30 - 81	FF5-8532-000	Q30 - 16
FB5-2646-000	Q45 - 23	FB5-9080-000	Q30 - 82	FF5-8534-000	Q30 - 55
FB5-2647-000	Q17 - 2	FB5-9082-000	Q34 - 12	FF5-8536-000	Q33 - 4
FB5-2650-000	Q46 - 1	FB5-9083-000	Q34 - 13	FF5-8537-000	Q37 - 18
FB5-2656-000	Q12 - 22	FB5-9094-000	Q34 - 17	FF5-8538-000	Q30 - 17
FB5-2662-000	Q12 - 9	FB5-9097-000	Q01 - 9	FF5-8540-000	Q37 - 11
FB5-2674-000	Q30 - 10	FB5-9098-000	Q31 - 13	FF5-8541-000	Q37 - 12
FB5-2681-000	Q13 - 17		Q52 - 25	FF5-8547-000	Q30 - 18
FB5-2682-000	Q13 - 18	FB5-9102-000	Q30 - 11	FF5-8548-060	Q30 - 69
FB5-2684-000	Q50 - 2	FB5-9103-000	Q30 - 83	FF5-8550-000	Q30 - 19
FB5-2687-000	Q13 - 2	FB5-9104-000	Q30 - 71	FF5-8551-000	Q30 - 20
FB5-2688-000	Q52 - 23		Q31 - 18	FF5-8583-000	Q14 - 21
FB5-2689-000	Q52 - 24	FB5-9118-000	Q01 - 17	FF5-8585-000	Q14 - 6
FB5-2690-000	Q11 - 16A	FB5-9121-000	Q31 - 19	FF5-8586-000	Q14 - 12
FB5-2691-000	Q11 - 16B	FB5-9123-000	Q31 - 20	FF5-8587-000	Q55 - 8
FB5-2692-000	Q11 - 7	FB5-9124-000	Q31 - 21	FF5-8590-000	Q52 - 11
FB5-2694-000	Q12 - 6A	FB5-9128-000	Q31 - 14	FF5-8591-000	Q52 - 27
FB5-2695-000	Q54 - 14A	FB5-9132-000	Q15 - 1E	FF5-8621-000	Q10 - 12
FB5-2696-000	Q53 - 4	FB5-9135-000	Q12 - 5	FF5-8626-000	Q17 - 1
FB5-2697-000	Q50 - 31	FB5-9148-000	Q45 - 28	FF5-8636-000	Q45 - 24
FB5-2700-000	Q54 - 6	FB5-9149-000	Q45 - 29	FF5-8638-000	Q50 - 91
FB5-2701-000	Q54 - 7	FB5-9161-000	Q45 - 4	FF5-8639-000	Q13 - 30
FB5-2702-000	Q54 - 8	FB5-9167-000	Q45 - 13	FF5-8644-000	Q45 - 25
FB5-2703-000	Q58 - 15	FB5-9173-000	Q01 - 10	FF5-8647-000	Q50 - 76
FB5-2704-000	Q54 - 9	FB5-9192-000	Q11 - 14	FF5-8683-000	Q50 - 74
FB5-2705-000	Q50 - 3	FB5-9196-000	Q54 - 11	FF5-8684-000	Q53 - 5
FB5-2706-000	Q50 - 90	FB5-9258-000	Q14 - 14	FF5-8687-000	Q54 - 12
FB5-2708-000	Q54 - 10	FB5-9259-000	Q14 - 15	FF5-9615-000	Q13 - 19
FB5-2709-000	Q11 - 16C	FB5-9264-000	Q52 - 35	FF5-9616-000	Q11 - 16
FB5-2711-000	Q58 - 16	FB5-9287-000	Q12 - 18	FF5-9617-000	Q11 - 6
FB5-5936-000	Q50 - 32	FB5-9290-000	Q10 - 15G	FF5-9618-000	Q12 - 6
FB5-5937-000	Q50 - 33	FB5-9302-000	Q01 - 11	FF5-9619-000	Q50 - 75
FB5-5939-000	Q50 - 81	FC1-7432-000	Q58 - 17	FF5-9620-000	Q54 - 14
FB5-8986-000	Q21 - 3	FC1-7883-000	Q14 - 19	FF6-1164-000	Q20 - 84
FB5-8987-000	Q21 - 4	FC2-3140-000	Q37 - 8A	FF6-1165-000	Q20 - 87
FB5-8988-000	Q21 - 5	FC2-4262-000	Q13 - 3	FF6-1168-000	Q20 - 90
FB5-8989-000	Q20 - 74	FC2-4347-000	Q55 - 7	FF6-1169-000	Q20 - 91
FB5-8990-000	Q20 - 75	FC2-5102-000	Q30 - 67	FF6-1178-000	Q40 - 14
FB5-8991-000	Q20 - 76	FF3-3109-000	Q50 - 34	FF6-1179-000	Q40 - 15
FB5-8992-000	Q20 - 77	FF3-3111-000	Q50 - 68	FF6-1182-000	Q40 - 29
FB5-8993-000	Q20 - 79	FF3-3205-000	Q58 - 18	FF6-1185-000	Q31 - 15
FB5-8994-000	Q20 - 80	FF3-3599-000	Q30 - 59	FF6-1186-000	Q31 - 16
FB5-8995-000	Q20 - 85	FF3-3600-000	Q30 - 56	FF6-1188-000	Q31 - 23
FB5-8996-000	Q20 - 86	FF3-3604-000	Q30 - 65	FF6-1189-000	Q31 - 24
FB5-9000-000	Q20 - 68B	FF3-3605-000	Q20 - 44B	FF6-1190-000	Q30 - 21
FB5-9004-000	Q20 - 67	FF3-3613-000	Q15 - 1	FF6-1191-000	Q30 - 84
FB5-9005-000	Q20 - 50	FF3-3746-000	Q30 - 12	FF6-1192-000	Q30 - 85
FB5-9006-000	Q24 - 21	FF3-3751-000	Q52 - 34	FF6-1193-000	Q30 - 86
	Q31 - 12	FF3-3865-000	Q10 - 33	FF6-1194-000	Q30 - 92
FB5-9007-000	Q20 - 81	FF3-3866-000	Q14 - 20	FF6-1196-000	Q34 - 1
FB5-9011-000	Q20 - 84B	FF3-3878-000	Q50 - 35	FF6-1205-000	Q45 - 30
	Q20 - 87B	FF3-4132-000	Q57 - 6	FF6-1207-000	Q45 - 11A
	Q31 - 22	FF5-3800-000	Q30 - 13	FF6-1209-000	Q45 - 11C
	Q52 - 28A	FF5-3804-000	Q31 - 5		Q45 - 11C
FB5-9016-000	Q20 - 10	FF5-4230-000	Q50 - 4		Q45 - 11C
FB5-9017-000	Q20 - 82	FF5-4231-000	Q13 - 26	FF6-1214-000	Q14 - 16
FB5-9018-000	Q20 - 83	FF5-5809-000	Q50 - 36	FF6-1217-000	Q50 - 82
FB5-9020-000	Q21 - 6	FF5-5810-000	Q50 - 37	FF6-1219-000	Q12 - 7
FB5-9021-000	Q20 - 88	FF5-5811-000	Q13 - 4	FF6-1222-000	Q52 - 28
FB5-9023-000	Q20 - 89	FF5-5812-000	Q13 - 5	FF6-1242-000	Q30 - 95
FB5-9024-000	Q21 - 7	FF5-6194-000	Q32 - 2	FG2-9785-000	Q18 - 21
FB5-9025-000	Q24 - 15		Q37 - 17		Q19 - 23
FB5-9026-000	Q24 - 16		Q52 - 26		Q36 - 3
FB5-9027-000	Q21 - 8	FF5-8461-000	Q11 - 12	FG3-0081-000	Q30 - 63
FB5-9033-000	Q24 - 12	FF5-8463-030	Q01 - 12	FG3-0082-000	Q20 - 37

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
FG3-0082-000	Q30 - 51	FG6-7984-000	Q57 -	FS5-1753-000	Q54 - 16
FG3-0089-000	Q12 - 14	FH2-5006-000	Q01 - 16	FS5-1754-000	Q50 - 43
FG3-0535-000	Q50 - 63	FH2-6481-000	Q16 - 2	FS5-2545-000	Q52 - 15
FG3-0973-000	Q14 - 11		Q B - J1121	FS5-3255-000	Q45 - 33
FG3-1825-000	Q90 -	FH2-6482-000	Q16 - 3		Q55 - 12
FG3-1826-000	Q92 -	FH2-6483-000	Q16 - 4	FS5-3409-000	Q50 - 83
FG3-1827-000	Q94 -	FH2-6487-000	Q16 - 5	FS5-3574-000	Q57 - 8
FG3-1828-000	Q18 - 15	FH3-2630-000	Q11 - 8	FS5-3575-000	Q57 - 9
	Q19 - 31	FH3-2631-000	Q11 - 8	FS5-3576-000	Q50 - 44
FG3-1829-000	Q93 -	FH4-5560-000	Q90 - IC113	FS5-3577-000	Q50 - 45
FG3-1832-000	Q12 - 4		Q91 - Q4	FS5-3580-000	Q50 - 46
FG3-1833-000	Q91 -	FH6-1455-000	Q59 - 2	FS5-3744-000	Q18 - 4
FG3-1835-000	Q13 - 34	FH6-1456-000	Q59 - 3		Q19 - 7
FG3-1837-000	Q11 - 17	FH6-1579-000	Q11 - 11	FS5-3746-000	Q23 - 4
FG3-1838-000	Q11 - 18	FH6-1644-000	Q20 - 52	FS5-3747-000	Q23 - 5
FG3-1839-000	Q40 - 12	FH6-1645-000	Q20 - 44E	FS5-3748-000	Q20 - 20
FG3-1840-000	Q40 - 20	FH6-1647-000	Q18 - 26D		Q24 - 2
FG3-1841-000	Q16 -		Q19 - 26D	FS5-3750-000	Q20 - 42
FG3-1842-000	Q15 - 4	FH6-1652-000	Q36 - 2	FS5-3751-000	Q20 - 64
FG3-1843-000	Q30 - 53	FH6-1690-000	Q52 - 19	FS5-3752-000	Q20 - 21
FG3-1844-000	Q30 - 54	FH6-1898-000	Q30 - 22	FS5-3794-000	Q12 - 17
FG3-1845-000	Q22 - 11	FH6-1899-000	Q23 - 2		Q30 - 96
FG3-1846-000	Q20 - 71	FH6-1900-000	Q40 - 21	FS5-3795-000	Q14 - 24
FG3-1848-000	Q54 - 21	FH6-1901-000	Q45 - 31	FS5-3796-000	Q14 - 25
FG3-1849-000	Q18 - 25	FH6-1903-000	Q50 - 84	FS5-3905-000	Q30 - 28
FG3-1850-000	Q19 - 30	FH6-1905-000	Q22 - 13	FS5-3907-000	Q40 - 3
FG3-1851-000	Q13 - 7	FH6-1906-000	Q34 - 2	FS5-3908-000	Q40 - 27
FG3-1852-000	Q11 - 19		Q50 - 95	FS5-3909-000	Q50 - 86
FG3-1854-000	Q30 - 94		Q56 - 8	FS5-6158-000	Q24 - 13
FG3-1856-000	Q34 - 11	FH6-1910-000	Q57 - 7	FS5-6237-000	Q20 - 49
FG3-1857-000	Q23 - 12	FH6-1911-000	Q14 - 23	FS5-6243-000	Q30 - 29
FG3-1860-000	Q31 - 27	FH6-1912-000	Q45 - 14	FS5-6307-000	Q18 - 17
FG3-1861-000	Q24 - 26	FH7-5766-000	Q50 - 38		Q19 - 19
FG3-1862-000	Q45 - 17	FH7-6336-000	Q12 - 3	FS5-6324-000	Q20 - 54
FG3-1863-000	Q46 - 4	FH7-7564-000	Q45 - 19		Q40 - 4
FG3-1864-000	Q45 - 18	FL6-2067-000	Q50 - 85	FS5-6357-000	Q37 - 19
FG3-1865-000	Q12 - 13	FS1-1187-000	Q58 - 21	FS5-6381-000	Q14 - 26
FG3-1867-000	Q15 - 1	FS1-1189-000	Q20 - 12		Q30 - 30
FG3-1870-000	Q45 - 10		Q34 - 3	FS5-6487-000	Q30 - 31
FG3-1871-000	Q45 - 10		Q50 - 39	FS5-6544-000	Q53 - 6
FG3-1974-000	Q56 - 16	FS1-1202-000	Q34 - 4	FS5-6545-000	Q13 - 14
FG3-1977-000	Q45 - 1	FS1-1206-000	Q59 - 5	FS5-6547-000	Q14 - 27
FG3-1979-000	Q20 - 38	FS1-1213-000	Q20 - 13		Q50 - 87
	Q30 - 52		Q50 - 40	FS5-6550-000	Q50 - 47
FG5-8391-000	Q59 -		Q58 - 22	FS5-6653-000	Q40 - 13
FG5-8408-000	Q50 - 73	FS1-1376-000	Q52 - 12	FS5-6655-000	Q40 - 5
FG6-3051-050	Q10 - 9	FS1-1433-000	Q31 - 25	FS5-6657-000	Q31 - 9
FG6-3063-000	Q18 - 26	FS1-1452-030	Q20 - 47	FS5-6661-000	Q30 - 68
	Q19 - 26	FS1-1510-000	Q59 - 6	FS5-6662-000	Q21 - 9
FG6-3076-000	Q10 - 10	FS1-9005-000	Q30 - 23	FS5-6663-000	Q21 - 10
FG6-3086-020	Q23 - 10	FS1-9009-000	Q45 - 20	FS5-6667-000	Q40 - 16
FG6-3103-000	Q20 - 44	FS1-9073-000	Q50 - 41	FS5-6682-000	Q50 - 48
FG6-3170-000	Q37 -	FS1-9076-000	Q50 - 42	FS5-6900-000	Q20 - 78
FG6-3178-000	Q32 -		Q54 - 15	FS5-6901-000	Q30 - 88
FG6-3179-000	Q33 -	FS1-9078-000	Q20 - 14	FS5-6903-000	Q40 - 6
FG6-3326-000	Q17 -		Q52 - 13	FS5-6904-000	Q34 - 14
FG6-4841-000	Q53 -		Q55 - 1	FS5-6905-000	Q30 - 32
FG6-4843-000	Q58 -	FS1-9120-000	Q22 - 4		Q34 - 15
FG6-4847-000	Q46 - 5	FS1-9166-000	Q50 - 72	FS5-6907-000	Q50 - 94
FG6-7458-000	Q20 -	FS1-9168-000	Q31 - 6	FS5-6908-000	Q34 - 16
FG6-7462-000	Q22 -	FS1-9255-000	Q30 - 75	FS5-6941-000	Q30 - 97
FG6-7463-000	Q23 -	FS2-1528-000	Q30 - 24	FS5-9212-000	Q57 - 10
FG6-7466-000	Q20 - 68	FS2-1542-000	Q52 - 14	FS5-9360-000	Q30 - 33
FG6-7469-000	Q21 -		Q55 - 2	FS5-9432-000	Q40 - 7
FG6-7474-000	Q24 -	FS2-1617-000	Q18 - 23	FS5-9438-000	Q12 - 19
FG6-7486-000	Q41 -		Q19 - 25	FS5-9579-000	Q11 - 9
FG6-7495-000	Q30 -	FS2-3470-000	Q20 - 15	FS6-0066-000	Q14 - 13
FG6-7501-000	Q36 -	FS2-3488-000	Q30 - 25	FS6-0541-000	Q34 - 6
FG6-7506-000	Q34 -	FS2-3504-000	Q20 - 16	FS6-0557-000	Q45 - 15
FG6-7509-000	Q31 -	FS2-3514-000	Q20 - 17	FS6-0814-000	Q56 - 9
FG6-7519-000	Q15 -		Q55 - 10	FS6-0815-000	Q56 - 10
FG6-7525-000	Q10 - 15	FS2-3527-000	Q30 - 26	FS6-0816-000	Q59 - 7
FG6-7530-000	Q18 -	FS2-6466-000	Q20 - 18	FS6-0817-000	Q59 - 8
FG6-7531-000	Q19 -	FS2-6488-000	Q20 - 61	FS6-0819-000	Q59 - 9
FG6-7533-000	Q54 -	FS2-6559-000	Q12 - 16	FS6-0820-000	Q57 - 11
FG6-7534-000	Q52 -	FS2-6581-000	Q20 - 19	FS6-0821-000	Q57 - 12
FG6-7539-000	Q45 -		Q23 - 3	FS6-0822-000	Q50 - 49
FG6-7540-000	Q45 -	FS2-9394-000	Q20 - 53	FS6-0823-000	Q50 - 50
FG6-7541-000	Q45 -		Q30 - 27	FS6-0824-000	Q50 - 51
FG6-7548-000	Q45 - 11		Q45 - 32	FS6-0825-000	Q58 - 23
FG6-7549-000	Q45 - 11	FS5-0677-000	Q30 - 87	FS6-0826-000	Q58 - 24
FG6-7550-000	Q45 - 11	FS5-0713-000	Q55 - 11	FS6-0828-000	Q59 - 10
FG6-7558-000	Q14 -	FS5-0801-020	Q34 - 5	FS6-0829-000	Q50 - 52
FG6-7560-000	Q55 -	FS5-0804-000	Q20 - 40	FS6-0830-000	Q50 - 53
FG6-7607-000	Q15 -		Q24 - 19	FS6-0831-000	Q59 - 11

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
FS6-0832-000	Q50 - 96	PCB	Q B - J7	RH7-1289-000	Q15 - 2
FS6-0833-000	Q59 - 12		Q B - J8	RS1-1042-000	Q20 - 73
FS6-2368-000	Q13 - 27		Q B - J9		Q59 - 14
FS6-2569-000	Q54 - 17		Q B - J10	VD7-1621-001	Q91 - FU1
FS6-2570-000	Q56 - 11		Q B - J11		Q91 - FU2
FS6-2571-000	Q57 - 13		Q B - J12		Q93 - FU741
FS6-2573-000	Q50 - 88		Q B - J13	VD7-1621-002	Q92 - FU712
FS6-2576-000	Q50 - 54		Q B - J14	VD7-1623-001	Q92 - FU716
FS6-2578-000	Q59 - 13		Q B - J15	VD7-1625-001	Q90 - FU101
FS6-2579-000	Q50 - 55		Q B - J16		Q90 - FU102
FS6-2580-000	Q50 - 56		Q B - J17		Q92 - FU713
FS6-2582-000	Q50 - 57		Q B - J18		Q92 - FU719
FS6-8795-000	Q24 - 7		Q B - J19	VD7-1627-001	Q92 - FU711
FS7-0346-000	Q18 - 13		Q B - J22		Q92 - FU714
	Q19 - 16		Q B - J29		Q92 - FU718
FS7-0347-000	Q18 - 14		Q B - J47	VS1-0108-004	Q B - J58
	Q19 - 17		Q B - J69	VS1-0279-002	Q B - J746
FS7-0349-000	Q18 - 18		Q B - J82		Q B - J1007
	Q19 - 20		Q B - J84		Q B - J1032
FS7-0350-000	Q18 - 26C		Q B - J85	VS1-0279-003	Q B - J1033
	Q19 - 26C		Q B - J88	VS1-0279-004	Q B - J58
FS7-0351-000	Q18 - 26A		Q B - J90	VS1-0279-008	Q B - J1090
	Q19 - 26A		Q B - J98	VS1-0842-002	Q B - J49
FS7-0355-000	Q20 - 55		Q B - J99		Q B - J53
FS7-0356-000	Q20 - 56		Q B - J101		Q B - J111
FS7-0357-000	Q20 - 57		Q B - J102		Q B - J1037
FS7-0358-000	Q20 - 22		Q B - J103		Q B - J1039
FS7-0359-000	Q20 - 72		Q B - J104	VS1-0842-003	Q B - J16
FS7-0404-000	Q45 - 26		Q B - J105		Q B - J18
FS7-0405-000	Q46 - 2		Q B - J106		Q B - J24
FS7-2081-000	Q18 - 19		Q B - J107		Q B - J26
	Q19 - 21		Q B - J108		Q B - J27
FS7-2082-000	Q10 - 28		Q B - J109		Q B - J51
FS7-2088-000	Q20 - 23		Q B - J110		Q B - J65
	Q22 - 5		Q B - J111		Q B - J981
FS7-2089-000	Q24 - 10		Q B - J112		Q B - J1006
FS7-2093-020	Q20 - 24		Q B - J113		Q B - J1012
FS7-2107-000	Q30 - 34		Q B - J114		Q B - J1014
FS7-2108-000	Q30 - 35		Q B - J115		Q B - J1018
FS7-2109-000	Q30 - 36		Q B - J116		Q B - J1021
FS7-2110-000	Q30 - 37		Q B - J117		Q B - J1022
FS7-2111-000	Q30 - 38		Q B - J118		Q B - J1024
FS7-2112-000	Q30 - 39		Q B - J119		Q B - J1027
	Q45 - 9		Q B - J120		Q B - J1028
FS7-2114-000	Q31 - 10		Q B - J121		Q B - J1029
FS7-2118-000	Q30 - 93		Q B - J122		Q B - J1030
FS7-2120-000	Q37 - 13		Q B - J124		Q B - J1043
FS7-2121-000	Q30 - 40		Q B - J126		Q B - J1044
FS7-2122-000	Q37 - 3		Q B - J127		Q B - J1046
FS7-2123-000	Q37 - 4		Q B - J128		Q B - J1047
FS7-2124-000	Q37 - 5		Q B - J711		Q B - J1048
FS7-2125-000	Q37 - 14		Q B - J712		Q B - J1049
FS7-2142-000	Q14 - 7		Q B - J713		Q B - J1052
FS7-2143-000	Q13 - 15		Q B - J714		Q B - J1053
FS7-2145-000	Q52 - 20		Q B - J715		Q B - J1063
FS7-2146-000	Q55 - 3		Q B - J716		Q B - J1064
FS7-2147-000	Q50 - 5		Q B - J717	VS1-0842-004	Q B - J13
FS7-2148-000	Q13 - 16		Q B - J718		Q B - J22
FS7-2149-000	Q14 - 28		Q B - J719		Q B - J28
FS7-2163-000	Q50 - 58		Q B - J720		Q B - J29
FS7-2164-000	Q50 - 77		Q B - J721		Q B - J50
FS7-2171-000	Q11 - 10		Q B - J741		Q B - J742
FS7-2632-000	Q24 - 3		Q B - J742		Q B - J1004
FS7-2633-000	Q20 - 25		Q B - J743		Q B - J1050
FS7-2634-000	Q31 - 26		Q B - J744		Q B - J1051
FS7-2635-000	Q34 - 7		Q B - J745		Q B - J1062
FS7-2636-000	Q30 - 76		Q B - J746		Q B - J1131
FS7-2637-000	Q50 - 59		Q B - J747	VS1-0842-005	Q B - J12
FS7-2638-000	Q40 - 8		Q B - J748		Q B - J66
FS7-2639-000	Q40 - 17		Q B - J749		Q B - J800
FS7-2640-000	Q40 - 18		Q B - J750		Q B - J1015
FS7-2643-000	Q21 - 11		Q B - J771		Q B - J1025
FS7-2645-000	Q14 - 17		Q B - J772		Q B - J1031
FS7-2646-000	Q12 - 20		Q B - J773		Q B - J1041
FU3-0004-000	Q20 - 26		Q B - J774		Q B - J1042
FU3-0005-000	Q30 - 77		Q B - J775		Q B - J1054
FU3-0006-000	Q30 - 78		Q B - J776	VS1-0842-006	Q B - J5
FU3-0007-000	Q30 - 41		Q B - J800		Q B - J1040
FU3-0008-000	Q34 - 8		Q B - J941	VS1-0842-007	Q B - J6
FU3-0009-000	Q22 - 6		Q B - J971		Q B - J23
PCB	Q B - J1	RA1-2483-000	Q B - J981		Q B - J1035
	Q B - J2		Q B - J1129		Q B - J1036
	Q B - J4		Q20 - 43	VS1-0842-008	Q B - J10
	Q B - J5		Q22 - 7		Q B - J15
	Q B - J6		Q23 - 6		Q B - J64

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
VS1-0842-008	Q B - J1017	VS1-5057-009	Q B - J1007	VS1-6314-008	Q B - J1060
	Q B - J1020		Q B - J1016		Q B - J1061
VS1-0842-009	Q B - J1019		Q B - J1066	VS1-6314-009	Q B - J14
VS1-0842-010	Q B - J7		Q B - J1089		Q B - J45
VS1-0842-012	Q B - J11	VS1-5057-010	Q11 - 19B		Q B - J105
VS1-0842-014	Q B - J8		Q30 - 54D		Q B - J117
VS1-0842-015	Q B - J9		Q B - J1065		Q B - J1016
VS1-0852-002	Q B - J1038		Q B - J1088	VS1-6314-010	Q B - J122
VS1-0852-003	Q B - J1026	VS1-5352-002	Q50 - 93	VS1-6314-011	Q B - J38
	Q B - J1113		Q B - J1038		Q B - J39
VS1-0852-007	Q B - J1035	VS1-5352-007	Q B - J1035		Q B - J104
	Q B - J1114	VS1-5452-007	Q16 - 6	VS1-6314-012	Q B - J115
	Q B - J1115		Q B - J717	VS1-6314-013	Q B - J113
VS1-5057-002	Q11 - 17A		Q B - J1121		Q B - J120
	Q20 - 45	VS1-5729-002	Q B - J1034		Q B - J121
	Q20 - 71A		Q B - J1123	VS1-6314-014	Q B - J109
	Q22 - 11A		Q B - J1125		Q B - J110
	Q30 - 53A		Q B - J1128		Q B - J118
	Q30 - 54A	VS1-5824-002	Q B - J53		Q B - J772
	Q31 - 27A		Q B - J54	VS1-6314-015	Q B - J116
	Q50 - 92		Q B - J91		Q B - J741
	Q52 - 34A		Q B - J1055	VS1-6314-016	Q B - J124
	Q B - J20	VS1-5824-003	Q B - J36		Q B - J971
	Q B - J21		Q B - J750	VS1-6318-004	Q11 - 17B
	Q B - J44		Q B - J1001		Q B - J61
	Q B - J49		Q B - J1003	VS1-6318-005	Q30 - 53D
	Q B - J53		Q B - J1006		Q B - J35
	Q B - J91		Q B - J1009	VS1-6318-012	Q40 - 12A
	Q B - J1037		Q B - J1010		Q B - J76
	Q B - J1039		Q B - J1013	VS1-6319-016	Q11 - 17C
VS1-5057-003	Q14 - 11A		Q B - J1056		Q13 - 34C
	Q30 - 53B	VS1-5824-004	Q B - J1131		Q B - J63
	Q30 - 54B	VS1-5824-005	Q B - J1057		Q B - J1060
	Q30 - 65A	VS1-5824-006	Q B - J745		Q B - J1061
	Q45 - 17A		Q B - J1005	VS1-6319-018	Q11 - 17D
	Q50 - 35A	VS1-5824-007	Q B - J774		Q B - J45
	Q56 - 16A	VS1-5824-008	Q B - J1019		Q B - J1016
	Q57 - 6A	VS1-5824-009	Q B - J747	VS1-6319-022	Q11 - 17E
	Q B - J26		Q B - J1007		Q22 - 11B
	Q B - J30		Q B - J1016		Q B - J38
	Q B - J36	VS1-5923-002	Q B - J71		Q B - J39
	Q B - J72	VS1-6053-018	Q B - J747	VS1-6320-002	Q B - J44
	Q B - J1006	VS1-6094-003	Q B - J1008		Q B - J69
	Q B - J1014		Q B - J1044	VS1-6320-003	Q B - J30
	Q B - J1028		Q B - J1045		Q B - J32
	Q B - J1030	VS1-6094-009	Q B - J747		Q B - J33
	Q B - J1044	VS1-6313-008	Q B - J63		Q B - J34
	Q B - J1054		Q B - J102		Q B - J43
VS1-5057-004	Q B - J1067		Q B - J107		Q B - J48
	Q20 - 71B		Q B - J119		Q B - J52
	Q30 - 53C		Q B - J1060		Q B - J67
	Q30 - 56A	VS1-6313-009	Q B - J1061		Q B - J68
	Q45 - 17C		Q B - J14		Q B - J70
	Q50 - 68A		Q B - J45		Q B - J73
	Q56 - 16B		Q B - J105		Q B - J77
	Q58 - 18A		Q B - J1016		Q B - J78
	Q B - J28	VS1-6313-010	Q B - J122		Q B - J79
	Q B - J31	VS1-6313-011	Q B - J38		Q B - J83
	Q B - J50		Q B - J39		Q B - J86
	Q B - J1050		Q B - J104		Q B - J92
	Q B - J1051	VS1-6313-012	Q B - J76		Q B - J93
	Q B - J1062		Q B - J115		Q B - J94
	Q B - J1131	VS1-6313-013	Q B - J113		Q B - J100
VS1-5057-005	Q20 - 44C		Q B - J120	VS1-6320-004	Q B - J28
	Q50 - 34A	VS1-6313-014	Q B - J109		Q B - J31
	Q56 - 16C		Q B - J110		Q B - J50
	Q B - J66		Q B - J118	VS1-6320-005	Q B - J82
	Q B - J1042	VS1-6313-015	Q B - J116		Q B - J90
VS1-5057-006	Q45 - 16		Q B - J741	VS1-6320-006	Q B - J1057
	Q52 - 34B	VS1-6313-016	Q B - J124	VS1-6320-010	Q B - J1065
	Q B - J1005		Q B - J971	VS1-6320-013	Q B - J97
	Q B - J1040	VS1-6314-004	Q B - J61	VS1-6321-002	Q B - J17
VS1-5057-007	Q30 - 59A		Q B - J106		Q B - J19
	Q B - J23		Q B - J718		Q B - J20
	Q B - J1036	VS1-6314-005	Q B - J35		Q B - J21
VS1-5057-008	Q13 - 34A		Q B - J108		Q B - J91
	Q14 - 11B	VS1-6314-007	Q B - J103	VS1-6321-003	Q B - J25
	Q20 - 44D		Q B - J127		Q B - J26
	Q B - J64		Q B - J773		Q B - J42
	Q B - J1019		Q B - J63		Q B - J62
	Q B - J1020	VS1-6314-008	Q B - J102		Q B - J72
VS1-5057-009	Q11 - 19A		Q B - J107		Q B - J1002
	Q13 - 34B		Q B - J119		Q B - J1067
	Q30 - 54C		Q B - J716	VS1-6321-004	Q B - J47
	Q45 - 17B		Q B - J748		Q B - J88

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
VS1-6321-004	Q B - J98	VT2-5161-032	Q B - J971	WS3-5358-000	Q B - J1008
VS1-6321-005	Q B - J99	WA3-7744-000	Q90 - 1		Q B - J1009
	Q B - J37	WA3-7862-000	Q91 - 1		Q B - J1010
	Q B - J40	WA7-1119-000	Q90 - 2		Q B - J1013
	Q B - J41	WC4-5159-000	Q19 - 29		Q B - J1016
	Q B - J46	WD3-5075-000	Q15 - 3		Q B - J1019
	Q B - J941	WE8-5496-000	Q16 - 9		Q B - J1027
VS1-6321-006	Q B - J2	WG8-5362-000	Q10 - 34		Q B - J1044
	Q B - J2	WG8-5382-000	Q12 - 11		Q B - J1045
VS1-6321-007	Q B - J23		Q14 - 8		Q B - J1055
VS1-6321-008	Q B - J64		Q18 - 12		Q B - J1056
VS1-6321-009	Q B - J1066		Q19 - 15		Q B - J1057
	Q B - J1089		Q20 - 27		Q B - J1131
VS1-6321-010	Q B - J1088		Q22 - 8	WS3-5471-000	Q B - J114
VS1-6321-013	Q B - J81		Q23 - 11	WS3-5569-000	Q B - J74
	Q B - J89		Q30 - 62	WS3-5600-000	Q B - J4
	Q B - J95		Q34 - 9	WS3-5649-000	Q B - J54
	Q B - J96		Q40 - 11		Q B - J1124
VS1-6373-007	Q B - J74		Q45 - 7	WS3-5658-000	Q B - J101
VS1-6380-003	Q15 - 1A		Q45 - 11B		Q B - J126
	Q B - J1122		Q45 - 11B		Q B - J128
	Q B - J1127		Q46 - 3		Q B - J720
VS1-6383-004	Q B - J4		Q50 - 60		Q B - J776
VS1-6534-002	Q B - J126		Q52 - 33		Q B - J1129
	Q B - J720		Q56 - 12	WS3-5666-000	Q B - J87
	Q B - J1129		Q57 - 14	WS3-5721-000	Q B - J1017
VS1-6534-004	Q B - J101		Q58 - 25		Q B - J1060
	Q B - J114	WG8-5464-000	Q20 - 58		Q B - J1061
VS1-6534-005	Q B - J128		Q45 - 11D	WT1-0237-000	Q16 - 8
VS1-6534-006	Q B - J776		Q59 - 4	WT1-5156-000	Q15 - 1C
VS1-6757-008	Q B - J1060	WS3-0437-000	Q B - J58	WT1-5220-000	Q B - J54
	Q B - J1061		Q B - J746		Q B - J1124
VS1-6757-009	Q B - J1017		Q B - J1007	WT2-0260-000	Q15 - 1D
VS1-6758-008	Q B - J1060		Q B - J1032	WT2-5041-000	Q15 - 4A
	Q B - J1061		Q B - J1033		Q52 - 34C
VS1-6758-009	Q B - J1017		Q B - J1090	WT2-5178-000	Q20 - 71C
VS3-0108-002	Q B - J59	WS3-0885-000	Q B - J58		Q31 - 27C
	Q B - J60		Q B - J59		Q40 - 20A
VS3-0108-006	Q B - J80		Q B - J60		Q45 - 1A
VS3-0108-008	Q B - J1126		Q B - J80		Q57 - 6B
VS3-5083-002	Q B - J1		Q B - J1126	WT2-5565-000	Q31 - 27B
	Q B - J49	WS3-5018-000	Q B - J71	XA9-0195-000	Q34 - 10
	Q B - J112	WS3-5044-000	Q16 - 7		Q50 - 61
	Q B - J712		Q B - J1121		Q56 - 13
	Q B - J743	WS3-5160-000	Q B - J1	XA9-0591-000	Q37 - 20
	Q B - J1034		Q B - J49	XA9-0592-000	Q40 - 9
	Q B - J1125		Q B - J84	XA9-0605-000	Q10 - 15J
VS3-5083-003	Q B - J84		Q B - J85		Q10 - 29
	Q B - J721		Q B - J112		Q12 - 8
VS3-5083-007	Q B - J713		Q B - J711		Q14 - 9
VS3-5083-008	Q B - J714		Q B - J712		Q19 - 28
VS3-5083-010	Q B - J85		Q B - J713		Q24 - 4
	Q B - J711		Q B - J714		Q30 - 42
VS3-5116-002	Q B - J55		Q B - J721		Q32 - 4
	Q B - J719		Q B - J743		Q33 - 5
	Q B - J771		Q B - J1034	XA9-0628-000	Q14 - 22
	Q B - J775		Q B - J1125	XA9-0629-000	Q10 - 36
	Q B - J1123	WS3-5174-000	Q B - J55		Q11 - 13
VS3-5121-003	Q B - J1122		Q B - J719		Q12 - 2
VS3-5207-002	Q B - J55		Q B - J771		Q13 - 6
	Q B - J57		Q B - J775		Q18 - 5
VT2-5161-016	Q B - J63		Q B - J1123		Q18 - 26E
	Q B - J102	WS3-5291-000	Q B - J1122		Q19 - 8
	Q B - J107	WS3-5292-000	Q15 - 1B		Q19 - 26E
	Q B - J119		Q B - J1122		Q20 - 29
	Q B - J1060		Q B - J1127		Q22 - 9
	Q B - J1061	WS3-5301-000	Q B - J1034		Q23 - 7
VT2-5161-018	Q B - J14		Q B - J1123		Q24 - 25
	Q B - J45		Q B - J1125		Q37 - 9
	Q B - J105		Q B - J1128	XA9-0633-000	Q01 - 14
	Q B - J1016	WS3-5354-000	Q B - J55		Q18 - 6
	Q B - J1017		Q B - J57		Q19 - 9
VT2-5161-020	Q B - J122	WS3-5358-000	Q B - J36		Q20 - 65
VT2-5161-022	Q B - J38		Q B - J53	XA9-0687-000	Q13 - 20
	Q B - J39		Q B - J54		Q30 - 43
	Q B - J104		Q B - J91	XA9-0722-000	Q10 - 35
VT2-5161-024	Q B - J115		Q B - J745		Q13 - 39
VT2-5161-026	Q B - J113		Q B - J747		Q54 - 18
	Q B - J120		Q B - J750	XA9-0732-000	Q11 - 15
VT2-5161-028	Q B - J109		Q B - J774		Q12 - 12
	Q B - J110		Q B - J1001		Q13 - 33
	Q B - J118		Q B - J1003		Q30 - 44
VT2-5161-030	Q B - J116		Q B - J1005		Q40 - 19
	Q B - J741		Q B - J1006		Q45 - 2
VT2-5161-032	Q B - J124		Q B - J1007		Q50 - 7

D2 NUMERICAL INDEX (Paper Folding Unit-C1)

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
4S1-9002-000	Q12 - 42	FB4-8980-000	Q02 - 21	FF6-1236-000	Q13 - 12
FA1-4842-030	Q35 - 5	FB4-8984-000	Q10 - 3	FF6-1237-000	Q20 - 3
FA2-5970-000	Q31 - 1	FB4-8986-000	Q13 - 8	FF6-1245-000	Q11 - 27
FA3-7418-000	Q13 - 5	FB4-8998-000	Q11 - 25A	FG2-6904-000	Q34 - 3
	Q31 - 2	FB4-8999-000	Q31 - 25	FG2-7911-000	Q33 - 25
	Q32 - 1		Q33 - 8A	FG2-7912-000	Q37 - 1
FA3-7419-000	Q31 - 3	FB5-9200-000	Q11 - 6	FG3-0087-000	Q90 -
	Q32 - 2	FB5-9201-000	Q11 - 16	FG3-0538-000	Q12 - 39
	Q35 - 2	FB5-9202-000	Q11 - 24		Q B - J791
FA4-2275-000	Q12 - 24	FB5-9206-000	Q31 - 31		Q B - J792
FA4-2278-000	Q12 - 8	FB5-9212-000	Q12 - 40		Q B - J1110
FA4-2281-000	Q13 - 10	FB5-9214-000	Q02 - 20	FG3-0539-000	Q10 - 11
FA4-2285-000	Q11 - 11	FB5-9217-000	Q13 - 3	FG3-0540-000	Q02 - 24
FA4-2286-000	Q11 - 12	FB5-9222-000	Q31 - 5		Q B - J1085
FA4-2287-000	Q11 - 13	FB5-9223-000	Q33 - 2		Q B - J1087
FA4-2288-000	Q13 - 19	FB5-9229-000	Q31 - 13A		Q B - J1088
FA4-2289-000	Q13 - 20	FB5-9270-000	Q11 - 10		Q B - J1089
FA4-2290-000	Q13 - 21	FB5-9271-000	Q31 - 27		Q B - J1091
FA4-2313-000	Q11 - 17		Q33 - 27		Q B - J1110
FA4-2317-000	Q34 - 2	FB5-9275-000	Q31 - 14		Q B - J1126
FA4-2332-000	Q11 - 18		Q32 - 3	FG3-0541-000	Q13 - 27
	Q12 - 20		Q33 - 12	FG3-0965-000	Q33 - 23
	Q13 - 14		Q36 - 5	FG3-0966-000	Q36 - 3
	Q33 - 14	FB5-9277-000	Q12 - 5	FG3-1868-000	Q31 - 12
FA4-2336-000	Q33 - 1	FB5-9279-000	Q10 - 6	FG3-1872-000	Q37 - 2
FA4-2340-000	Q31 - 26	FB5-9281-000	Q31 - 9	FG3-1975-000	Q34 - 5
FA4-2341-000	Q13 - 9	FB5-9282-000	Q11 - 5	FG3-1976-000	Q32 - 6
FA4-2342-000	Q13 - 18	FB5-9283-000	Q11 - 28	FG6-3268-000	Q37 - 3
FA4-2348-000	Q34 - 8	FB5-9572-000	Q33 - 28	FG6-3269-000	Q36 - 4
FA4-2349-000	Q34 - 9	FC2-1249-000	Q31 - 15	FG6-7569-000	Q31 -
FA4-2350-000	Q34 - 10		Q32 - 4	FG6-7570-000	Q33 -
FA4-2351-000	Q34 - 11		Q33 - 13	FG6-7571-000	Q32 -
FA4-2352-000	Q34 - 12		Q36 - 6	FG6-7572-000	Q34 -
FA4-2355-000	Q34 - 13	FC2-1250-000	Q34 - 1	FG6-7573-000	Q35 -
FA4-2356-000	Q34 - 14	FC2-4248-000	Q13 - 7	FG6-7574-000	Q20 -
FA4-2362-000	Q13 - 22	FC2-4261-000	Q02 - 19	FG6-7578-000	Q21 -
FA4-2363-000	Q34 - 15	FC2-4262-000	Q02 - 4	FG6-7581-000	Q10 -
FA4-2371-000	Q33 - 7	FC2-4264-000	Q02 - 16	FG6-7582-000	Q37 -
FA4-6702-000	Q01 - 6	FC2-4268-000	Q12 - 22	FG6-7995-000	Q36 -
	Q12 - 38	FC2-4269-000	Q31 - 6	FH7-5062-000	Q12 - 32
	Q33 - 26	FC2-4277-000	Q02 - 7		Q34 - 4
FA5-5377-000	Q20 - 1	FC2-4278-000	Q02 - 5	FH7-5876-000	Q03 - 10
FA6-8230-000	Q21 - 1	FC2-4279-000	Q02 - 6	FS1-1187-000	Q12 - 37
FA6-8304-000	Q21 - 2	FC2-4282-000	Q31 - 7		Q31 - 16
FB3-0123-030	Q02 - 22	FC2-4284-000	Q13 - 6		Q33 - 17
FB4-8245-000	Q02 - 1	FC2-4291-000	Q10 - 4	FS1-1213-000	Q31 - 17
FB4-8246-000	Q02 - 29	FC2-4295-000	Q31 - 10		Q33 - 18
FB4-8299-000	Q03 - 2	FC2-4302-000	Q11 - 3	FS1-1376-000	Q12 - 30
FB4-8300-000	Q03 - 1	FC2-4309-000	Q10 - 5	FS1-1433-000	Q12 - 31
FB4-8301-000	Q03 - 3	FC2-4310-000	Q33 - 9	FS1-1435-000	Q31 - 18
FB4-8308-000	Q03 - 12	FC2-4312-000	Q02 - 9		Q33 - 19
FB4-8327-000	Q03 - 4	FC2-4314-000	Q33 - 10	FS1-1451-030	Q02 - 12
FB4-8330-000	Q03 - 9	FC2-4333-000	Q31 - 11	FS1-3159-000	Q11 - 19
FB4-8331-000	Q03 - 5		Q33 - 11		Q12 - 18
FB4-8334-000	Q03 - 11	FC2-4354-000	Q11 - 14		Q13 - 15
FB4-8335-000	Q03 - 6	FC2-4356-000	Q02 - 10	FS1-3162-000	Q11 - 22
FB4-8722-000	Q01 - 3	FC2-4358-000	Q02 - 23	FS1-3163-000	Q12 - 11
FB4-8736-000	Q01 - 2	FC2-5100-000	Q12 - 2	FS1-9076-000	Q13 - 23
FB4-8737-000	Q01 - 7		Q35 - 3		Q31 - 19
FB4-8738-000	Q01 - 10	FC2-6542-000	Q31 - 28	FS1-9078-000	Q10 - 7
FB4-8739-000	Q01 - 5	FC2-6544-000	Q01 - 8	FS2-0386-000	Q31 - 21
FB4-8755-000	Q01 - 1	FC2-6548-000	Q12 - 21		Q33 - 20
FB4-8756-000	Q12 - 6		Q13 - 25	FS2-0387-000	Q12 - 13
FB4-8758-000	Q12 - 1	FE9-0089-000	Q33 - 15	FS2-0388-000	Q11 - 20
FB4-8766-000	Q31 - 4	FF1-6572-000	Q13 - 1		Q12 - 19
FB4-8771-000	Q33 - 3	FF1-6573-000	Q13 - 2		Q13 - 16
FB4-8776-000	Q12 - 7	FF3-1632-000	Q02 - 11		Q02 - 13
FB4-8781-000	Q11 - 26	FF3-1634-000	Q21 - 5	FS2-1542-000	Q34 - 7
FB4-8784-000	Q31 - 8	FF3-1637-000	Q01 - 9	FS2-2264-000	Q34 - 6
FB4-8785-000	Q11 - 2	FF3-1638-000	Q11 - 8	FS2-2265-000	Q21 - 6
FB4-8792-000	Q12 - 3	FF3-1642-000	Q12 - 10	FS2-3470-000	Q21 - 7
FB4-8793-000	Q12 - 4	FF3-2308-000	Q11 - 23	FS2-3745-000	Q20 - 2
FB4-8796-000	Q33 - 4	FF3-2309-000	Q11 - 1	FS2-3819-000	Q12 - 26
FB4-8797-000	Q33 - 5	FF3-3876-000	Q90 - J800	FS2-6438-000	Q13 - 13
FB4-8798-000	Q33 - 6	FF3-3877-000	Q34 - 16		Q12 - 14
FB4-8802-000	Q10 - 1	FF5-8562-000	Q12 - 17	FS2-6560-000	Q21 - 8
FB4-8803-000	Q02 - 2	FF5-8563-000	Q12 - 27	FS2-6561-000	Q21 - 9
FB4-8804-000	Q02 - 3	FF5-8565-000	Q33 - 8	FS3-0641-000	Q12 - 36
FB4-8962-000	Q01 - 4	FF5-8571-000	Q12 - 29	FS4-0434-000	Q31 - 20
FB4-8966-000	Q10 - 2	FF5-8573-000	Q12 - 16		Q21 - 3
FB4-8968-000	Q13 - 26	FF6-1227-000	Q31 - 13	FS4-2168-000	Q10 - 8
FB4-8969-000	Q13 - 24	FF6-1232-000	Q13 - 4	FS4-2463-000	Q31 - 23
FB4-8977-000	Q35 - 1	FF6-1233-000	Q12 - 23	FS4-2465-000	Q33 - 21
FB4-8978-000	Q10 - 12	FF6-1234-000	Q11 - 25		Q11 - 21
	Q35 - 4	FF6-1236-000	Q12 - 25	FS5-6324-000	Q13 - 17

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
FS5-9213-000	Q12 - 15	WS3-0885-000	Q B - J1091	XD2-1100-642	Q31 - 505
FS5-9216-000	Q02 - 25		Q B - J1106	XD2-1100-802	Q02 - 505
FS7-0390-000	Q12 - 41		Q B - J1108	XD2-2100-202	Q31 - 506
FS7-0391-000	Q33 - 16		Q B - J1112		Q32 - 502
FS7-2137-000	Q12 - 33	WS3-1057-000	Q B - J1109		Q33 - 507
FS7-2138-000	Q21 - 4	WS3-5649-000	Q B - J1092		Q36 - 502
FS7-2641-000	Q31 - 29	WT1-0183-000	Q B - J1092	XD2-2100-302	Q34 - 505
FS7-2642-000	Q02 - 15	WT2-5041-000	Q10 - 11B	XD2-3100-152	Q11 - 504
FS7-2644-000	Q11 - 4		Q12 - 39A	XD3-1160-162	Q03 - 502
FS9-0064-000	Q02 - 17		Q31 - 12A	XD3-1300-082	Q34 - 508
FU3-0010-000	Q11 - 15		Q32 - 6A	XD3-1300-102	Q12 - 508
PCB	Q B - J791		Q33 - 23A	XD3-1300-162	Q03 - 503
	Q B - J792		Q34 - 5A	XD3-2200-082	Q21 - 506
	Q B - J793		Q36 - 2	XD3-2200-122	Q12 - 502
	Q B - J794		Q36 - 3A		Q31 - 507
	Q B - J795	XA9-0265-000	Q13 - 11		Q33 - 505
	Q B - J796	XA9-0605-000	Q03 - 13	XD3-2200-142	Q12 - 503
	Q B - J797		Q10 - 13		Q31 - 508
	Q B - J798	XA9-0687-000	Q02 - 28	XD3-2200-162	Q21 - 504
	Q B - J799	XA9-0849-000	Q03 - 7	XD3-2200-212	Q11 - 508
	Q B - J1094	XA9-0854-000	Q02 - 8	XD3-2300-142	Q21 - 505
	Q B - J1098	XA9-0892-000	Q02 - 27	XF2-2506-164	Q12 - 12
	Q B - J1103	XB1-1403-009	Q11 - 505	XF9-0430-000	Q21 - 12
RA1-2483-000	Q12 - 28	XB1-2300-409	Q03 - 504	XF9-0602-000	Q11 - 9
VD7-1621-001	Q90 - FU791		Q34 - 501	XF9-0603-000	Q20 - 4
VS1-0279-002	Q B - J796	XB1-2300-606	Q31 - 501	XF9-0604-000	Q12 - 34
	Q B - J1094		Q33 - 504	XF9-0605-000	Q12 - 9
	Q B - J1098	XB1-2300-609	Q02 - 501	XG3-6012-405	Q21 - 10
	Q B - J1108		Q11 - 516	XG3-8016-505	Q12 - 35
	Q B - J1109		Q31 - 509		Q21 - 11
VS1-0279-004	Q B - J798		Q33 - 501		Q31 - 32
	Q B - J1106		Q34 - 502	XG9-0407-000	Q31 - 30
VS1-0279-006	Q B - J799	XB1-2301-209	Q10 - 501		Q33 - 29
VS1-0279-007	Q B - J1093	XB1-2400-606	Q13 - 506	XG9-0453-000	Q11 - 7
VS1-0279-008	Q B - J793	XB1-2400-609	Q20 - 501	XH9-0101-000	Q31 - 24
VS1-0280-002	Q B - J1108	XB4-7300-609	Q34 - 507		Q33 - 24
	Q B - J1109	XB6-7300-409	Q12 - 504	XZ9-0520-000	Q02 - 18
	Q B - J1112	XB6-7300-609	Q10 - 502		
VS1-0280-004	Q B - J1106		Q31 - 502		
VS1-0842-003	Q B - J795		Q33 - 508		
	Q B - J1086	XB6-7400-409	Q35 - 502		
	Q B - J1087	XB6-7400-609	Q01 - 502		
	Q B - J1095		Q01 - 501		
	Q B - J1097		Q02 - 502		
	Q B - J1099		Q10 - 503		
	Q B - J1100		Q11 - 506		
	Q B - J1101		Q12 - 505		
	Q B - J1104		Q13 - 503		
	Q B - J1105		Q21 - 501		
VS1-0842-004	Q B - J1102		Q31 - 503		
VS1-0842-005	Q B - J1103		Q32 - 501		
VS1-0842-006	Q B - J797		Q33 - 502		
	Q B - J1096		Q34 - 506		
VS1-0842-009	Q B - J794		Q35 - 501		
VS1-5057-003	Q03 - 8		Q36 - 501		
	Q10 - 11A		Q37 - 501		
	Q13 - 27A	XB6-7400-809	Q02 - 506		
	Q B - J1087		Q10 - 504		
	Q B - J1100	XB6-7500-609	Q11 - 511		
	Q B - J1104	XB7-2100-409	Q11 - 507		
VS1-5057-004	Q13 - 27B	XD1-1106-226	Q33 - 506		
	Q B - J1102	XD1-1106-235	Q11 - 501		
VS1-5057-006	Q37 - 2A		Q13 - 501		
	Q B - J1096	XD1-1108-225	Q11 - 510		
VS3-0108-002	Q B - J1091	XD1-4200-402	Q13 - 505		
WC4-5126-000	Q10 - 9	XD2-1100-242	Q34 - 503		
WC4-5127-000	Q02 - 26	XD2-1100-322	Q03 - 501		
WG1-0373-000	Q90 - LED791		Q12 - 506		
	Q90 - LED792	XD2-1100-402	Q11 - 502		
WG8-5362-000	Q31 - 22		Q13 - 502		
	Q32 - 5	XD2-1100-502	Q02 - 503		
	Q36 - 1		Q10 - 505		
WG8-5382-000	Q02 - 14		Q11 - 503		
	Q10 - 10		Q12 - 501		
	Q33 - 22		Q13 - 504		
WS3-0437-000	Q B - J793		Q21 - 502		
	Q B - J796		Q31 - 504		
	Q B - J798		Q33 - 503		
	Q B - J799		Q34 - 504		
	Q B - J1093	XD2-1100-642	Q02 - 504		
	Q B - J1094		Q10 - 506		
	Q B - J1098		Q11 - 509		
	Q B - J1106		Q12 - 507		
	Q B - J1108		Q20 - 502		
	Q B - J1109		Q21 - 503		

D3 NUMERICAL INDEX (Document Insertion Unit-B1)

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
FA4-1159-000	P30 - 1	FB4-8946-000	P01 - 10	PCB	P B - J843
FA6-8623-000	P11 - 69	FB4-8947-000	P01 - 17		P B - J844
FA6-8685-000	P02 - 1	FB4-8948-000	P11 - 75		P B - J845
FB1-7018-000	P01 - 23	FB4-8950-000	P30 - 23		P B - J846
	P11 - 45	FB5-3192-000	P14 - 4A		P B - J847
FB3-0835-020	P02 - 14	FB5-3193-000	P12 - 7		P B - J1076
FB3-7269-000	P20 - 10	FB5-3194-000	P02 - 10		P B - J1078
FB4-2131-000	P11 - 70	FB5-3195-000	P02 - 11	RS5-9003-000	P11 - 28
FB4-6991-000	P30 - 14	FB5-3196-000	P12 - 9	VS1-0279-002	P B - J847
FB4-7556-000	P11 - 36	FB5-3197-000	P01 - 22		P B - J1075
FB4-7558-000	P11 - 44	FB5-3200-000	P02 - 12	VS1-0842-002	P B - J1070
FB4-7563-000	P11 - 1	FB5-9098-000	P01 - 15		P B - J1072
FB4-7567-000	P11 - 2	FB5-9518-000	P30 - 16		P B - J1076
FB4-7568-000	P11 - 3	FB5-9531-000	P11 - 64		P B - J1077
FB4-7570-000	P11 - 4	FC1-2309-000	P02 - 9		P B - J1078
FB4-7571-000	P11 - 5	FC1-6179-000	P12 - 6	VS1-0842-003	P B - J1067
FB4-7572-000	P11 - 6	FC2-1227-000	P30 - 24		P B - J1068
FB4-7573-000	P11 - 24A	FC2-1258-000	P30 - 25		P B - J1069
FB4-7578-000	P11 - 58	FC2-1291-000	P20 - 7		P B - J1071
FB4-7582-000	P11 - 51	FC2-1303-000	P14 - 2		P B - J1073
FB4-7583-000	P11 - 79	FC2-1369-000	P30 - 26		P B - J1074
FB4-7584-000	P11 - 7	FC2-1370-000	P30 - 27		P B - J1080
FB4-7585-000	P11 - 8	FC2-1371-000	P30 - 28		P B - J1081
FB4-7586-000	P11 - 37	FC2-1827-000	P30 - 29		P B - J1082
FB4-7587-000	P11 - 38	FC2-2146-000	P14 - 3		P B - J1083
FB4-7588-000	P11 - 39	FF1-6572-000	P01 - 13		P B - J1084
FB4-7599-000	P11 - 9	FF3-3867-000	P02 - 4	VS1-0842-005	P B - J844
FB4-7636-000	P30 - 15	FF3-3868-000	P01 - 3	VS1-0842-006	P B - J846
FB4-7639-000	P30 - 17	FF3-3869-000	P11 - 21		P B - J1079
FB4-7640-000	P30 - 2	FF3-3870-000	P11 - 22	VS1-0842-010	P B - J845
FB4-7641-000	P30 - 3	FF3-3871-000	P11 - 47	VS1-0842-012	P B - J842
FB4-7642-000	P30 - 4	FF5-6194-000	P01 - 18	VS1-5057-002	P11 - 21A
FB4-7645-000	P30 - 5	FF5-8205-000	P11 - 23		P B - J1070
FB4-7646-000	P30 - 18	FF5-8596-000	P14 - 4		P B - J1072
FB4-7647-000	P30 - 19	FF5-8597-000	P11 - 25		P B - J1077
FB4-7648-000	P30 - 20	FF5-8598-000	P11 - 54	VS1-5057-003	P02 - 4A
FB4-7650-000	P30 - 21	FF5-8604-000	P11 - 83		P11 - 22A
FB4-7651-000	P30 - 22	FF5-8605-000	P11 - 61		P B - J1068
FB4-7662-000	P11 - 10	FF5-8607-000	P11 - 68		P B - J1071
FB4-7663-000	P01 - 8	FF5-8608-000	P11 - 71		P B - J1082
	P11 - 11	FF5-8616-000	P02 - 5	VS1-5057-006	P11 - 47A
FB4-7664-000	P11 - 12	FF5-8617-000	P01 - 20		P B - J1079
FB4-7669-000	P11 - 13	FF6-1300-000	P11 - 24	VS1-5824-009	P B - J841
FB4-7670-000	P11 - 14	FG2-9361-000	P11 - 50		P B - J1066
FB4-7710-000	P12 - 1	FG2-9362-000	P11 - 78	VS1-5824-010	P B - J1065
FB4-7711-000	P12 - 2	FG3-1830-000	P11 - 81	VS1-6053-018	P B - J841
FB4-7768-000	P11 - 40	FG3-1869-000	P02 - 2	VS1-6094-009	P B - J841
FB4-8031-000	P11 - 41	FG6-3303-000	P14 -	VS3-5083-002	P B - J843
FB4-8032-000	P11 - 42	FG6-3304-000	P30 -		P B - J1128
FB4-8033-000	P11 - 43	FG6-3307-000	P20 -	WG8-5362-000	P01 - 25
FB4-8875-000	P11 - 15	FG6-3310-000	P12 -		P11 - 48
FB4-8876-000	P11 - 16	FH6-1637-000	P20 - 1	WS3-0437-000	P B - J847
FB4-8877-000	P11 - 17	FH7-5874-000	P11 - 57		P B - J1075
FB4-8878-000	P30 - 6	FH7-5877-000	P11 - 26	WS3-5160-000	P B - J843
FB4-8880-000	P11 - 76	FN5-0151-000	P12 - 8		P B - J1128
FB4-8884-000	P30 - 7	FS1-1189-000	P30 - 8	WS3-5358-000	P B - J841
FB4-8886-000	P12 - 3	FS1-1376-000	P11 - 65		P B - J1065
FB4-8887-000	P12 - 4	FS1-1508-000	P30 - 9		P B - J1066
FB4-8888-000	P10 - 4	FS1-1528-000	P11 - 66	WT2-0409-000	P02 - 3
FB4-8892-000	P01 - 24	FS1-9167-000	P11 - 82	WT2-5565-000	P02 - 2A
	P11 - 49	FS1-9194-000	P01 - 4	XA9-0629-000	P01 - 6
FB4-8894-000	P11 - 59	FS2-3514-000	P01 - 21		P02 - 6
FB4-8895-000	P11 - 60	FS2-6466-000	P11 - 62	XA9-0685-000	P01 - 19
FB4-8896-000	P14 - 1	FS3-0137-000	P30 - 10	XA9-0721-000	P01 - 27
FB4-8897-000	P10 - 5	FS4-0177-000	P12 - 10	XA9-0732-000	P01 - 28
FB4-8900-000	P12 - 5	FS5-0748-000	P11 - 74		P20 - 11
FB4-8901-000	P11 - 18	FS5-3732-000	P20 - 2	XA9-0892-000	P02 - 8
FB4-8905-000	P11 - 19	FS5-3803-000	P01 - 11		P11 - 33
FB4-8906-000	P11 - 20	FS5-6158-000	P11 - 32		P20 - 6
FB4-8912-000	P11 - 52	FS5-6243-000	P11 - 73	XA9-0894-000	P11 - 80
FB4-8914-000	P11 - 55	FS5-6323-000	P20 - 3	XA9-1028-000	P30 - 30
FB4-8917-000	P11 - 77	FS5-6661-000	P01 - 26	XA9-1035-000	P11 - 72
FB4-8918-000	P11 - 53	FS6-0094-000	P11 - 29	XB1-1300-609	P30 - 507
FB4-8919-000	P11 - 56	FS7-0314-000	P11 - 30	XB1-2300-409	P11 - 507
FB4-8920-000	P10 - 1	FS7-0318-000	P30 - 11		P30 - 501
FB4-8921-000	P10 - 2	FS7-0322-000	P30 - 12	XB1-2300-609	P11 - 501
FB4-8922-000	P10 - 3	FS7-0397-000	P11 - 63	XB1-2400-409	P20 - 501
FB4-8925-000	P11 - 67	FS7-2024-000	P20 - 4	XB1-2400-606	P11 - 502
FB4-8935-000	P02 - 13	FS7-2039-000	P11 - 31	XB1-2400-609	P01 - 501
FB4-8936-000	P01 - 9	FS7-2151-000	P11 - 84	XB1-2500-806	P02 - 501
FB4-8939-000	P01 - 1	FS7-2152-000	P01 - 5	XB4-7300-609	P12 - 501
FB4-8940-000	P01 - 2	FS7-2154-000	P11 - 27	XB4-7400-809	P10 - 501
FB4-8941-000	P01 - 12	FS7-2155-000	P20 - 5	XB4-7401-009	P02 - 502
FB4-8942-000	P01 - 16	PCB	P B - J841		P11 - 503
FB4-8943-000	P11 - 46		P B - J842	XB6-7300-409	P30 - 508

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
XB6-7300-609	P01 - 506				
	P11 - 508				
XD2-1100-242	P01 - 507				
	P11 - 510				
XD2-1100-322	P11 - 509				
	P30 - 502				
XD2-1100-402	P11 - 512				
	P20 - 503				
XD2-1100-502	P01 - 503				
	P11 - 504				
	P20 - 502				
	P30 - 503				
XD2-1100-642	P01 - 504				
	P11 - 505				
	P30 - 504				
XD2-1100-802	P30 - 509				
XD2-2100-402	P11 - 513				
XD2-2100-602	P12 - 502				
XD2-2100-802	P01 - 502				
	P11 - 506				
	P30 - 505				
XD3-1200-102	P11 - 511				
XD3-1200-122	P01 - 505				
XD3-2200-102	P30 - 506				
XD9-0152-000	P11 - 34				
XF2-1607-840	P20 - 8				
XF2-1612-460	P20 - 9				
XF2-1618-040	P02 - 7				
XF9-0684-000	P30 - 13				
XG9-0211-000	P30 - 31				
XG9-0237-000	P11 - 35				
XG9-0365-000	P01 - 7				
XZ9-0289-000	P01 - 14				

D4 NUMERICAL INDEX (Puncher Unit-E1/F1)

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
FB3-3834-000	Q45 - 3				
FB4-8684-000	Q45 - 5				
FB5-2643-000	Q45 - 21				
FB5-2645-000	Q45 - 22				
FB5-2646-000	Q45 - 23				
FB5-2650-000	Q46 - 1				
FB5-9148-000	Q45 - 28				
FB5-9149-000	Q45 - 29				
FB5-9161-000	Q45 - 4				
FB5-9167-000	Q45 - 13				
FF5-8636-000	Q45 - 24				
FF5-8644-000	Q45 - 25				
FF6-1205-000	Q45 - 30				
FF6-1207-000	Q45 - 11A				
FF6-1209-000	Q45 - 11C				
	Q45 - 11C				
FG3-1862-000	Q45 - 17				
FG3-1863-000	Q46 - 4				
FG3-1864-000	Q45 - 18				
FG3-1871-000	Q45 - 10				
FG3-1977-000	Q45 - 1				
FG6-4847-000	Q46 - 5				
FG6-7541-000	Q45 -				
FG6-7542-000	Q45 -				
FG6-7550-000	Q45 - 11				
FG6-7551-000	Q45 - 11				
FH6-1901-000	Q45 - 31				
FH6-1912-000	Q45 - 14				
FH7-7564-000	Q45 - 19				
FS1-9009-000	Q45 - 20				
FS2-9394-000	Q45 - 32				
FS5-3255-000	Q45 - 33				
FS6-0557-000	Q45 - 15				
FS7-0404-000	Q45 - 26				
FS7-0405-000	Q46 - 2				
FS7-2112-000	Q45 - 9				
VS1-5057-003	Q45 - 17A				
VS1-5057-004	Q45 - 17C				
VS1-5057-006	Q45 - 16				
VS1-5057-009	Q45 - 17B				
WG8-5382-000	Q45 - 7				
	Q45 - 11B				
	Q46 - 3				
WG8-5464-000	Q45 - 11D				
WT2-5178-000	Q45 - 1A				
XA9-0732-000	Q45 - 2				
XA9-0892-000	Q45 - 8				
XB1-2300-409	Q45 - 501				
	Q46 - 501				
XB1-2300-609	Q45 - 509				
XB1-2400-409	Q45 - 502				
XB1-2400-609	Q45 - 508				
XB4-7400-609	Q45 - 504				
XB4-7400-809	Q45 - 503				
XB6-7400-607	Q46 - 502				
XD2-1100-642	Q45 - 505				
	Q46 - 503				
XD3-2200-102	Q45 - 506				
XD3-2200-142	Q45 - 507				
XF2-1308-210	Q45 - 12				
XG9-0214-000	Q45 - 27				
XZ9-0522-000	Q45 - 6				

Prepared by
OFFICE IMAGING PRODUCTS QUALITY ASSURANCE CENTER
CANON INC.
Printed in Japan

REVISION 0 [MAR. 2001]

5-1, Hakusan 7-chome, Toride-city, Ibaraki 302-8501, Japan



This publication is
printed on 100%
recycled paper.

Canon