

**Hardware
Documentation
Kit Handbook**

digital

1st Edition, 1978
2nd Edition, April, 1980
3rd Edition, October, 1980
4th Edition, April, 1981
5th Edition, October, 1981
6th Edition, April, 1982

Copyright 1978, 1980, 1981, 1982 by
Digital Equipment Corporation

The material in this manual is for
information purposes and is subject to
change without notice.

Digital Equipment Corporation assumes
no responsibility for any errors which
may appear in this manual.

Printed in U.S.

The following are trademarks of Digital
Equipment Corporation, Maynard,
Massachusetts.

DIGITAL
DEC
PDP
DECUS
UNIBUS
DECsystem-10
DECSYSTEM-20
DIBOL
EDUSYSTEM
VAX
VMS
MASSBUS
OMNIBUS
OS/8
RSTS
RSX
IAS

Introduction

This edition of the Hardware Documentation Kit Handbook introduces a new feature - the 'Multi-media Diagnostics Grid.' Each grid will allow you to select diagnostic software for your Digital system on any loading media available. Ordering part numbers for all media and listings are provided. For further details on how to use the grid see page 75.

This handbook contains documentation kits and diagnostics designed to support Digital's current, high volume products. The book is divided into three distinct sections. Section I supports option level products; Section II supports packaged systems ; and Section III supports Multi-media Diagnostics. The Table of Contents lists products by their Option Designation, while the index sorts products by Kit Number.

Packaged System Matrices (Section II) have been designed for each processor type. The left hand margin of each matrix lists the packaged system designations alphanumerically. The kit numbers run across the top of the matrix. To use the matrix, simply scan the left side of the page for the desired Packaged System Designation and select the kits from the top of the page which have a check mark. Contents of these kits may be reviewed by locating the appropriate kit in the Index.

The amount and types of documentation available for the individual devices vary depending upon the complexity and application of the device. The advantage of kitting these documents is twofold: 1) it simplifies ordering by reducing the number of line items, and 2) it often reduces expense, since most kits are priced below the sum of their loose piece prices. Prices for Hardware Documentation Kits and Diagnostics may be found in Digital's Accessories and Supplies Group Price List.

If you are interested in loose piece hardware documentation or if you are unable to locate a kit for a device you support, you should consider using the Digital Accessories and Supplies Group Documentation Products Directory. If you do not receive the directory you may place yourself on the distribution list by using the convenient form located in the back of this handbook.

Orders may be placed through your local Digital Sales Office. In the Continental U.S. and Puerto Rico, orders may also be placed by calling toll free 800-258-1710. When ordering, please provide the Kit Part Number and Kit Name.

More detailed ordering information begins on page iii.

How to Order

In Continental USA and Puerto Rico, call:

or mail order to:

800-258-1710

Digital Equipment Corporation
P.O. Box CS2008
Nashua, NH 03061

In Alaska, Hawaii or New Hampshire, call:

or mail order to:

603-884-6660

Digital Equipment Corporation
P.O. Box CS2008
Nashua, NH 03061

ARGENTINA

DIGITAL APPROVED DISTRIBUTOR
Coasin Computacion
Calle Nazca 1171
Buenos Aires 1416
Argentina
Telephone: (54)-(1)-580043
Telex: 390-17016

BOLIVIA

Digital Equipment Services, Inc.
Casilla 4301
La Paz
Bolivia
Telephone: (591)-(2)-371933
Telex: 336-5497

AUSTRALIA

Digital Equipment Australia Pty. Ltd.
Accessories & Supplies Group
P.O. Box 384
Chatswood, New South Wales 2067
Australia
Telephone: (61)-(2)-4125252
Telex: 790-24295

BRAZIL

Digital Equipment Comercio e
Industria Ltda
Avenida Presidente Wilson,
231-26 Floor
Castelo
20030 Rio de Janeiro, RJ
Brazil
Telephone: (55)-(21)-2625755

AUSTRIA

Digital Equipment Corporation
Ges, mbH
Shopping City Sued
A-2331 Voessendorf bei Wien
Austria
Telephone: (43)-(222)-677641
Telex: 847-134995

CANADA

Digital Equipment of Canada, Ltd.
Accessories & Supplies Group
940 Belfast Rd.
Ottawa, Ontario K1G 4C2
Canada
Telephone: (800)-(267)-6146
(613)-592-5111
Telex: 610-562-8732

BELGIUM

Digital Equipment N.V.S.A.
Boulevard Brand Whitlock 87
B0-1040 Brussels
Belgium
Telephone: (32)-(2)-7339650
Telex: 846-25297

CHILE

DIGITAL APPROVED DISTRIBUTOR
Sonda, Ltd.
Teatinos 574 2° Piso
Santiago
Chile
Telephone: (56)-(2)-718335
Cable: COACHI KU

CHINA, REPUBLIC OF
DIGITAL APPROVED DISTRIBUTOR
China Computer Corporation
2nd Floor, 75 Nanking East Road,
Sec. 4
Taipei, Taiwan
Republic of China
Telephone: (886)-(2)-7310155
Telex: 785-26834

DENMARK
Digital Equipment Corporation AS
Kristineberg 3
DK-2100 Copenhagen O
Denmark
Telephone: (45)-(1)-299666
Telex: 855-19675

EGYPT
DIGITAL APPROVED DISTRIBUTOR
Giza Systems Engineering
P.O. Box 1913
ET-Cairo
Egypt
Telephone: 987114
987276
Telex: 927-92096 E K A UN

ENGLAND
Digital Equipment Co. Ltd.
Units 9 & 10, Stadium Way
Scours Lane
GB-Reading RG3 6BX
England
Telephone: (44)-(734)-583555
Telex: 851-847188

FINLAND
Digital Equipment Corporation OY
P. 16
SF-02201 Espoo 20
Finland
Telephone: (358)-(0)-423511
Telex: 857-122324

FRANCE
Digital Equipment France
25 Place De La Loire
Rungis 94528
France
Telephone: (33)-(1)-6872570
Telex: 842-204270

GERMANY (WEST)
Digital Equipment GmbH
Wallensteinplatz 2
D-8000 Munich 40
West Germany
Telephone: (49)-(89)-35031
Telex: 841-215191

HOLLAND
Digital Equipment Corporation B.V.
Kaaop Hoorndreef 38
NL-3563 AV Utrecht
Holland
Telephone: (31)-(30)-631222
Telex: 844-40370

HONG KONG
Digital Computer Hong Kong, Ltd.
1303-1309 Dominion Center
43-59A Queen's Road East
Wanchai
Hong Kong
Telephone: (852)-(5)-282306
(852)-(5)-273178
Telex: 780-76424

INDIA
DIGITAL APPROVED DISTRIBUTOR
Hinditron Computers Pvt. Ltd.
504 Raheja Chambers
Backbay Reclamation Narimen Point
Bombay 400 032
India
Telephone: 244207
244238
Telex: 953-0114632
Cable: DECOMP

IRELAND
Digital Equipment International Ltd.
Park House
North Circular Road
IRL-Dublin 7
Ireland
Telephone: (353)-(1)-308433
Telex: 852-31023

ISRAEL

DECsys Computers, Ltd.
4 Yirmiyahu Street
IL-63505 Tel Aviv
Israel

Telephone: (972)-(3)-440763
Telex: 922-32363

ITALY

Digital Equipment S.p.A.
Viale Fulvio Testi 11 ANG
Via M. Gorki 105
20092, Cinisello Balsamo
Milan
Italy

Telephone: (02)-6121951
Telex: 843-333435

JAPAN

Digital Equipment Corporation Int'l.
Accessories & Supplies Group
35th Floor, Sunshine 60
P.O. Box 1135
1-1 Higashi Ikebukuro 3-Chome
Toshima-Ku, Tokyo 170
Japan

Telephone: (81)-(3)-9897111
Telex: 781-26428

KOREA

DIGITAL APPROVED DISTRIBUTOR
Oricom Inc.
C.P.O. Box 289
Seoul
Korea

Telephone: (82)-(2)-763-8151
Telex: 787-26577
Cable: ORICOMENG SEOUL

KUWAIT

DIGITAL APPROVED DISTRIBUTOR
N.C.S. Ltd.
P.O. Box 766
Safat
Kuwait

Telephone: 965-436748
Telex: 959-2272

MEXICO

Digital Equipment de Mexico,
S.A. de C.V.
Apartado Postal 18-990
Mexico 12, D.F.
Mexico

Telephone: (905)-687-3422
Telex: 383-1772599

NEW ZEALAND

Digital Equipment New Zealand Ltd.
P.O. Box 17039
Greenlane, Auckland
New Zealand

Telephone: (64)-(9)-591280
Telex: 791-2726

NIGERIA

DIGITAL APPROVED DISTRIBUTOR
Data Sciences Nigeria, Ltd.
P.O. Box 6352
Ikeja-Lagos
Nigeria

Telephone: 862763
Cable: Earth/Lagos

NORWAY

Digital Equipment Corporation A/S
Pottemarkerveien 5
N-Oslo 5
Norway

Telephone: (47)-(2)-160290
Telex: 856-19079/16903

PERU

DIGITAL APPROVED DISTRIBUTOR
I.R.E.
Avda F.D. Roosevelt 105
Lima 1
Peru

Telephone: (51)-(14)-288650
(51)-(14)-272076
Telex: 354-25663 +

PUERTO RICO

Digital Equipment Latin America
Mercantil Plaza Bldg. 4th Floor
Ponce de la Leon Avenue Stop 27
Hato Rey 00918
Puerto Rico

Telephone: (800)-258-1710
(809)-754-7575
Telex: 385-7056

SAUDI ARABIA

DIGITAL APPROVED DISTRIBUTOR
Digital Equipment Company, Ltd.
C/O Abbar and Zainy
P.O. Box 461
Jeddah
Saudi Arabia
Telephone: (966)-(21)-57352
Telex: 928-401062

Digital Equipment Company, Ltd.
C/O Abbar and Zainy
P.O. Box 567
Dammam
Saudi Arabia
Telephone: (966)-(31)-8644056
Telex: 928-601056

Digital Equipment Company, Ltd.
C/O Abbar and Zainy
P.O. Box 8143
Riyadh
Saudi Arabia
Telephone: (966)-(1)-4657309
Telex: 928-201128

SINGAPORE

Digital Equipment Singapore (Pte)
Ltd.
San Centre, First Floor
Chin Swee Road, Singapore 0316
Republic of Singapore
Telephone: (65)-919266
Telex: 786-25435

**SOUTHEAST EUROPE
& NORTHERN AFRICA**

ALGERIA, CYPRUS, GREECE,
MALTA, MOROCCO, PORTUGAL,
TUNISIA, TURKEY
Digital Equipment Corporation S.A.
SEENA Branch
9, route des Jeunes C.P. 591
Case Tostale 191
1211 Geneva 26
Switzerland
Telephone: (41)-(22)-429930
Telex: 289201

SPAIN

Digital Equipment Corporation S A
Sucursal en Espana
Agustin de Foxa 27
Madrid 16
Spain
Telephone: (34)-(1)-7331900
Telex: 831-42192

SWEDEN

Digital Equipment AB
Box 1250
S-17124 Solna 1
Sweden
Visitors or Shipping Address:
Englundavagen 7, Solna
Telephone: (46)-(8)-7300200
Telex: 854-17050

SWITZERLAND

Digital Equipment Corporation, SA
Schaffhauserstrasse 144
CH-8302 Kloten/ZH
Switzerland
Telephone: (41)-(1)-8169111
Telex: 845-56059

VENEZUELA

DIGITAL APPROVED DISTRIBUTOR
Coasin Computacion, C.A.
Apdo Postal 70136
Caracas 1070A
Venezuela
Telephone: (58)-(2)-387866
(58)-(2)-387842
Telex: 395-21027

YUGOSLAVIA

DIGITAL APPROVED
DISTRIBUTORS

Elektrotehna Do Delta
Milentija Popovica 9
11000 Beograd
Yugoslavia

Telephone: (011) 453-885

Telex: 862-12042

Elektrotehna Do Delta

Aleja Borisa Kidrica 2

Spasicev Prilaz 7

41020 Zagreb

Yugoslavia

Telephone: (041) 52 78 76

Telex: 062-22247

Elektrotehna Do Delta

Parmova 43

61000 Ljubljana

Yugoslavia

Telephone: (061) 312 988

Telex: 062-31366

FOR ALL OTHER COUNTRIES OUTSIDE OF EUROPE CONTACT

INTERNATIONAL MARKET DEVELOPMENT DISTRICT

Digital Equipment Corporation

Accessories & Supplies Group

P.O. Box 577

Littleton, Massachusetts 01460

Telephone: (617)-486-7100

Telex: 710-347-7651

Contents

SECTION 1

OPTION LEVEL KITS

| Device | Kit Number | Page |
|---------------|-------------------|-------------|
| 861 | FB-00861 | 3 |
| 866 | FB-00866 | 3 |
| 871 | FB-00871 | 3 |
| 872 | FB-00872 | 3 |
| 874 | FB-00874 | 3 |
| 11/04 | FB-11/04 | 3 |
| 11/05 | FB-11/05 | 3 |
| 11/15 | FB-11/15 | 4 |
| 11/20 | FB-11/20 | 4 |
| 11/23 | FB-11/23 | 4 |
| 11/23-B | FB-11/23-B | 4 |
| 11/24 | FB-11/24 | 4 |
| 1134A | FB-1134A | 5 |
| 11/35 | FB-11/35 | 5 |
| 11/40 | FB-11/40 | 5 |
| 11/44 | FB-11/44 | 5 |
| 11/45 | FB-11/45 | 5 |
| 11/60 | FB-11/60 | 6 |
| 11/70-01 | FB-11/70-01 | 6 |
| 11/70-02 | FB-11/70-02 | 6 |
| AA11-K | FB-AA11-K | 6 |
| AAV11 | FB-AAV11 | 6 |
| AD11-K | FB-AD11-K | 6 |
| ADV11 | FB-ADV11 | 7 |
| AM11-K | FB-AM11-K | 7 |
| AR11 | FB-AR11 | 7 |
| BA11-A | FB-BA11-A | 7 |
| BA11-F | FB-BA11-F | 7 |
| BA11-K | FB-BA11-K | 7 |
| BA11-L | FB-BA11-L | 7 |
| BA11-M | FB-BA11-M | 7 |
| BA11-N | FB-BA11-N | 7 |
| BA11-P | FB-BA11-P | 8 |
| BA11-R | FB-BA11-R | 8 |
| BA11-S | FB-BA11-S | 8 |
| BA11-U | FB-BA11-U | 8 |
| BA11-V | FB-BA11-V | 8 |
| BDV11 | FB-BDV11 | 8 |
| BM873-YB | FB-BM873-YB | 8 |
| DB11-A | FB-DB11-A | 8 |
| DD11-A | FB-DD11-A | 8 |

TABLE OF CONTENTS

| Device | Kit Number | Page |
|---------------|-------------------|-------------|
| DD11-B..... | FB-DD11-B..... | 8 |
| DD11-C..... | FB-DD11-C..... | 8 |
| DD11-D..... | FB-DD11-D..... | 9 |
| DD11-K..... | FB-DD11-K..... | 9 |
| DD11-P..... | FB-DD11-P..... | 9 |
| DF02..... | FB-DF02..... | 9 |
| DFO3..... | FB-DF03..... | 9 |
| DH11..... | FB-DH11..... | 9 |
| DK8-EF..... | FB-DK8-EF..... | 9 |
| DK8-EP..... | FB-DK8-EP..... | 9 |
| DK8-ES..... | FB-DK8-ES..... | 9 |
| DKC8-AA..... | FB-DKC8-AA..... | 9 |
| DL11-W..... | FB-DL11-W..... | 10 |
| DLV11-E..... | FB-DLV11-E..... | 10 |
| DLV11-F..... | FB-DLV11-F..... | 10 |
| DLV11-J..... | FB-DLV11-J..... | 10 |
| DLV11-K..... | FB-DLV11-K..... | 10 |
| DM11-A..... | FB-DM11-A..... | 10 |
| DM11-B..... | FB-DM11-B..... | 10 |
| DM11-D..... | FB-DM11-D..... | 10 |
| DMC11..... | FB-DMC11..... | 10 |
| DN11..... | FB-DN11..... | 11 |
| DPV11..... | FB-DPV11..... | 11 |
| DQ11..... | FB-DQ11..... | 11 |
| DR11-B..... | FB-DR11-B..... | 11 |
| DR11-C..... | FB-DR11-C..... | 11 |
| DR11-K..... | FB-DR11-K..... | 11 |
| DR11-L..... | FB-DR11-L..... | 11 |
| DR11-M..... | FB-DR11-M..... | 11 |
| DR11-W..... | FB-DR11-W..... | 11 |
| DRS11..... | FB-DRS11..... | 11 |
| DRV11..... | FB-DRV11..... | 12 |
| DRV11-B..... | FB-DRV11-B..... | 12 |
| DRV11-J..... | FB-DRV11-J..... | 12 |
| DRV11-P..... | FB-DRV11-P..... | 12 |
| DSS11..... | FB-DSS11..... | 12 |
| DU11..... | FB-DU11..... | 12 |
| DUP11-D..... | FB-DUP11-D..... | 12 |
| DUV11..... | FB-DUV11..... | 12 |
| DV11..... | FB-DV11..... | 12 |
| DW08-A..... | FB-DW08-A..... | 12 |
| DW08-B..... | FB-DW08-B..... | 13 |
| DW780..... | FB-DW780..... | 13 |
| DZ11-A..... | FB-DZ11-A..... | 13 |
| DZ11-C..... | FB-DZ11-C..... | 13 |
| DZ32..... | FB-DZ32..... | 13 |
| DZV11..... | FB-DZV11..... | 13 |
| FP11-A..... | FB-FP11-A..... | 13 |
| FP11-B..... | FB-FP11-B..... | 13 |
| FP11-C..... | FB-FP11-C..... | 13 |

TABLE OF CONTENTS

| Device | Kit Number | Page |
|---------------|-------------------|-------------|
| FP11-EA | FB-FP11-EA | 14 |
| FP11-F | FB-FP11-F | 14 |
| FP780 | FB-FP780 | 14 |
| FPF11 | FB-FPF11 | 14 |
| FPP8-A | FB-FPP8-A | 14 |
| FPP8-E | FB-FPP8-E | 14 |
| H312 | FB-H312 | 14 |
| H319 | FB-H319 | 14 |
| H7100 | FB-H7100 | 14 |
| H7104 | FB-H7104 | 14 |
| H7422 | FB-H7422 | 14 |
| H745 | FB-H745 | 15 |
| H754 | FB-H754 | 15 |
| H765 | FB-H765 | 15 |
| H766 | FB-H766 | 15 |
| H775 | FB-H775 | 15 |
| H950 | FB-H950 | 15 |
| H9500 | FB-H9500 | 15 |
| H9501 | FB-H9501 | 15 |
| H9506 | FB-H9506 | 15 |
| H9610 | FB-H9610 | 15 |
| H960-D | FB-H960-D | 15 |
| H9600 | FB-H9600 | 15 |
| H9602-C | FB-H9602-C | 16 |
| H9612 | FB-H9612 | 16 |
| H9642 | FB-H9642 | 16 |
| IB11 | FB-IB11 | 16 |
| IBV11 | FB-IBV11 | 16 |
| KA8-E | FB-KA8-E | 16 |
| KA750 | FB-KA750 | 16 |
| KA780 | FB-KA780 | 16 |
| KC750 | FB-KC750 | 17 |
| KC780 | FB-KC780 | 17 |
| KC8-AA | FB-KC8-AA | 17 |
| KC8-E | FB-KC8-E | 17 |
| KD11-F | FB-KD11-F | 17 |
| KD11-HA | FB-KD11-HA | 17 |
| KE11-A | FB-KE11-A | 18 |
| KE11-B | FB-KE11-B | 18 |
| KE11-E | FB-KE11-E | 18 |
| KE11-F | FB-KE11-F | 18 |
| KE44-A | FB-KE44-A | 18 |
| KE8-E | FB-KE8-E | 18 |
| KEV11 | FB-KEV11 | 18 |
| KG11-A | FB-KG11-A | 18 |
| KG8-EA | FB-KG8-EA | 18 |
| KJ11-A | FB-KJ11-A | 18 |
| KK11-B | FB-KK11-B | 18 |
| KM8-AA | FB-KM8-AA | 19 |
| KM8-E | FB-KM8-E | 19 |
| KP8-E | FB-KP8-E | 19 |

TABLE OF CONTENTS

| Device | Kit Number | Page |
|----------|-------------|------|
| KPV11 | FB-KPV11 | 19 |
| KT11-C | FB-KT11-C | 19 |
| KT11-D | FB-KT11-D | 19 |
| KW11-K | FB-KW11-K | 19 |
| KW11-L | FB-KW11-L | 19 |
| KW11-P | FB-KW11-P | 19 |
| KW11-W | FB-KW11-W | 19 |
| KWV11-A | FB-KWV11-A | 20 |
| KY11-C | FB-KY11-C | 20 |
| KY11-LA | FB-KY11-LA | 20 |
| KY11-LB | FB-KY11-LB | 20 |
| KY11-P | FB-KY11-P | 20 |
| LA120 | FB-LA120 | 20 |
| LA120-RA | FB-LA120-RA | 20 |
| LA180 | FB-LA180 | 20 |
| LA34 | FB-LA34 | 20 |
| LA35 | FB-LA35 | 21 |
| LA36 | FB-LA36 | 21 |
| LA38 | FB-LA38 | 21 |
| LAV11 | FB-LAV11 | 21 |
| LK40 | FB-LK40 | 21 |
| LP25 | FB-LP25 | 21 |
| LPA11-K | FB-LPA11-K | 21 |
| LPC01 | FB-LPC01 | 21 |
| LPD11-A | FB-LPD11-A | 22 |
| LPS11 | FB-LPS11 | 22 |
| LS120 | FB-LS120 | 22 |
| M7850 | FB-M7850 | 22 |
| M9301 | FB-M9301 | 22 |
| M9302 | FB-M9302 | 22 |
| M9312 | FB-M9312 | 22 |
| MA780 | FB-MA780 | 22 |
| ME11-L | FB-ME11-L | 22 |
| MF11-L | FB-MF11-L | 23 |
| MF11-LP | FB-MF11-LP | 23 |
| MF11-U | FB-MF11-U | 23 |
| MF11-WP | FB-MF11-WP | 23 |
| MF11S-K | FB-MF11S-K | 23 |
| MJ11 | FB-MJ11 | 23 |
| MK11 | FB-MK11 | 23 |
| ML11 | FB-ML11 | 23 |
| MM11-CP | FB-MM11-CP | 23 |
| MM11-DP | FB-MM11-DP | 24 |
| MM11-E | FB-MM11-E | 24 |
| MM11-F | FB-MM11-F | 24 |
| MM11-L | FB-MM11-L | 24 |
| MM11-LP | FB-MM11-LP | 24 |
| MM11-S | FB-MM11-S | 24 |
| MM11-U | FB-MM11-U | 24 |
| MM11-WP | FB-MM11-WP | 24 |

TABLE OF CONTENTS

| Device | Kit Number | Page |
|----------------|-------------------|-------------|
| MM11-YP | FB-MM11-YP | 25 |
| MM8-EJ | FB-MM8-EJ | 25 |
| MMV11-A | FB-MMV11-A | 25 |
| MRV11-AA | FB-MRV11-AA | 25 |
| MRV11-AC | FB-MRV11-AC | 25 |
| MRV11-BA | FB-MRV11-BA | 25 |
| MRV11-BC | FB-MRV11-BC | 25 |
| MRV11-C | FB-MRV11-C | 25 |
| MRV11-VA | FB-MRV11-VA | 25 |
| MRV11-VC | FB-MRV11-VC | 25 |
| MS11-AP | FB-MS11-AP | 25 |
| MS11-B | FB-MS11-B | 25 |
| MS11-CC | FB-MS11-CC | 26 |
| MS11-FP | FB-MS11-FP | 26 |
| MS11-K | FB-MS11-K | 26 |
| MS11-L | FB-MS11-L | 26 |
| MS11-M | FB-MS11-M | 26 |
| MS750 | FB-MS750 | 26 |
| MS780 | FB-MS780 | 26 |
| MSV11-B | FB-MSV11-B | 26 |
| MSV11-C | FB-MSV11-C | 26 |
| MSV11-D | FB-MSV11-D | 26 |
| MSV11-E | FB-MSV11-E | 26 |
| MSV11-P | FB-MSV11-P | 27 |
| PC05 | FB-PC05 | 27 |
| PC11 | FB-PC11 | 27 |
| PDP-8A | FB-PDP8A | 27 |
| PDP-8E | FB-PDP8E | 27 |
| PDP-8F | FB-PDP8F | 27 |
| PDP-8M | FB-PDP8M | 27 |
| PRS01 | FB-PRS01 | 28 |
| RA80 | FB-RA80 | 28 |
| REV11 | FB-REV11 | 28 |
| RH11 | FB-RH11 | 28 |
| RH70 | FB-RH70 | 28 |
| RH750 | FB-RH750 | 28 |
| RH780 | FB-RH780 | 28 |
| RK05F | FB-RK05F | 28 |
| RK05J | FB-RK05J | 28 |
| RK06 | FB-RK06 | 28 |
| RK07 | FB-RK07 | 29 |
| RK11-C | FB-RK11-C | 29 |
| RK11-D | FB-RK11-D | 29 |
| RK611 | FB-RK611 | 29 |
| RKV11-D | FB-RKV11-D | 29 |
| RL01 | FB-RL01 | 29 |
| RL02 | FB-RL02 | 29 |
| RL11 | FB-RL11 | 29 |
| RL8A | FB-RL8A | 29 |
| RLV11 | FB-RLV11 | 30 |

TABLE OF CONTENTS

| Device | Kit Number | Page |
|----------|-------------|------|
| RLV12 | FB-RLV12 | 30 |
| RM02 | FB-RM02 | 30 |
| RM03 | FB-RM03 | 30 |
| RM05 | FB-RM05 | 30 |
| RM80 | FB-RM80 | 30 |
| RP04 | FB-RP04 | 30 |
| RP05 | FB-RP05 | 30 |
| RP06 | FB-RP06 | 31 |
| RP07 | FB-RP07 | 31 |
| RP11-C | FB-RP11-C | 31 |
| RP11-E | FB-RP11-E | 31 |
| RPR02 | FB-RPR02 | 31 |
| RX01 | FB-RX01 | 31 |
| RX02 | FB-RX02 | 31 |
| RX11 | FB-RX11 | 32 |
| RX211 | FB-RX211 | 32 |
| RX8 | FB-RX8 | 32 |
| RXMM2-B | FB-RXMM2-B | 32 |
| RXMM2-C | FB-RXMM2-C | 33 |
| RXMM3-B | FB-RXMM3-B | 33 |
| RXMM3-C | FB-RXMM3-C | 34 |
| RXV11 | FB-RXV11 | 34 |
| RXV21 | FB-RXV21 | 34 |
| TE10N | FB-TE10N | 34 |
| TE10W | FB-TE10W | 34 |
| TE16 | FB-TE16 | 34 |
| TEV11 | FB-TEV11 | 35 |
| TM02 | FB-TM02 | 35 |
| TM03 | FB-TM03 | 35 |
| TM78 | FB-TM78 | 35 |
| TS11 | FB-TS11 | 35 |
| TU16 | FB-TU16 | 35 |
| TU45 | FB-TU45 | 35 |
| TU58 | FB-TU58 | 35 |
| TU77 | FB-TU77 | 35 |
| TU78 | FB-TU78 | 36 |
| UDA50 | FB-UDA50 | 36 |
| VK100 | FB-VK100 | 36 |
| VT100 | FB-VT100 | 36 |
| VT101 | FB-VT101 | 36 |
| VT102 | FB-VT102 | 36 |
| VT1XX-AB | FB-VT1XX-AB | 36 |
| VT1XX-AC | FB-VT1XX-AC | 37 |
| VT1XX-CA | FB-VT1XX-CA | 37 |
| VT50 | FB-VT50 | 37 |
| VT52 | FB-VT52 | 37 |
| VT55 | FB-VT55 | 37 |

SECTION 2

PACKAGED SYSTEMS MATRICES

| | | |
|------------|---------------------------------|------------------|
| PDP-11/03 | Packaged Systems Matrices | Pages 41-42 |
| PDP-11/23 | Packaged Systems Matrices | Pages 43 thru 48 |
| PDP-11/23B | Packaged Systems Matrices | Pages 49-50 |
| PDP-11/24 | Packaged Systems Matrices | Pages 51 thru 53 |
| PDP-11/34A | Packaged Systems Matrices | Pages 54 thru 59 |
| PDP-11/44 | Packaged Systems Matrices | Pages 60 thru 62 |
| PDP-11/60 | Packaged Systems Matrices | Page 63 |
| PDP-11/70 | Packaged Systems Matrices | Pages 64 thru 67 |
| VAX-11/750 | Packaged Systems Matrices | Page 68 |
| VAX-11/780 | Packaged Systems Matrices | Pages 69-70 |
| VAX-11/782 | Packaged Systems Matrices | Page 71 |

SECTION 3

DIAGNOSTICS KITS

| | | | |
|-------------------|-------------|------------------------|---------|
| AAV11 | 79 | KEV11 | 108 |
| AD01 | 80 | LSI-11 | 109 |
| ADV11 | 81 | MM11, MF11UP | 110 |
| BDV11/M8012 | 82 | MSV11 | 111 |
| DEC/X11 | 83-84-85-86 | PDP-11/04 | 112 |
| DH11 | 87 | PDP-11/23 | 113 |
| DL11E | 88 | PDP-11/24 | 114 |
| DL11W | 89 | PDP-11/34 | 115 |
| DLV11-E | 90 | PDP-11/40 | 116 |
| DLV11J | 91 | PDP-11/44 | 117 |
| DPV11 | 92 | PDP-11/45 | 118 |
| DR11A | 93 | PDP-11/70 | 119 |
| DR11B | 94 | RH11 | 120 |
| DR11C | 95 | RK06/RK07 | 121 |
| DR11K | 96 | RK11 | 122 |
| DR11L/M | 97 | RL01/RL02 | 123 |
| DR11W | 98 | RM02/3/5 | 124 |
| DRV11 | 99 | RP04/5/6 | 125 |
| DRV11B | 100 | RX01/RX02 | 126 |
| DRV11J | 101 | RX02 | 127 |
| DUP-11 | 102 | TM,A,B-11 (TU10) | 128 |
| DUV11-DA | 103 | TM02/TU16 | 129 |
| DZ11 | 104 | TM02/TU45 | 130 |
| FP11 | 105 | TM03/TE16 | 131 |
| FP11F | 106 | TM03/TU45 | 132 |
| FPP11 | 107 | XXDP | 133-134 |

Option Level Kits

OPTION LEVEL KITS

KIT NAME: **861-A/-B/-C/-D/-E
DOCUMENTS**
KIT NUMBER: **FB-00861**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-00861-IP | 861-A/B/C/D/E/F POW IPB |
| EK-861AB-MM | 861-A/B/C/D/E/F MAINT MAN |
| EK-861AB-OP | 861 POWER CONTROLLER USERS |
| MP-N0861-OO | 861 MAINTENANCE PRINTS |

KIT NAME: **866 DOCUMENTS**
KIT NUMBER: **FB-00866**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-866DE-IP | 866-D/E POW CTRLR IPB |
| MP-N0866-DO | 866-D MAINTENANCE PRINTS |

KIT NAME: **871 DOCUMENTS**
KIT NUMBER: **FB-00871**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-00871-IP | 871 POWER CONTROLLER IPB |

KIT NAME: **872 DOCUMENTS**
KIT NUMBER: **FB-00872**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-00872-IP | 872 POWER CONTROLLER IPB |

KIT NAME: **874 DOCUMENTS**
KIT NUMBER: **FB-874**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------------|
| EK-00874-IP | 874 ILLUSTRATED PARTS BREAKDOWN |
| MP-01016 | 874 MAINTENANCE PRINTS |

KIT NAME: **11/04 (KD11-D) CPU/
SYSTEM DOCUMENTS**
KIT NUMBER: **FB-11/04**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EB-19402-20 | PDP-11 PROCESSOR HANDBOOK |
| EK-11004-OP | PDP-11/04 SYSTEM USERS MANUAL |
| EK-11034-MC | PDP 11/04/34 MAINTENANCE CARD |
| EK-KD11D-MM | KD11-D MAINTENANCE MANUAL |
| MP-00019-00 | 11/04 MAINTENANCE PRINTS |

The following documents may be applicable to your system, however, due to their specific nature, they are not included in this kit. If you wish to purchase any of these items, use the Part Number and description provided.

| | |
|-------------|---|
| EK-04525-IP | 11/04 (5.25 inch box) Illustrated Parts Breakdown |
| EK-04105-IP | 11/04 (10.25 inch box) Illustrated Parts Breakdown |

KIT NAME: **11/05 (KD11-B) CPU
SYSTEM DOCUMENTS**
KIT NUMBER: **FB-11/05**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EK-01105-OP | PDP-11/05/10 CMP USR MANUAL |
| EK-11005-TM | PDP-11/05/10 CMP MANUAL |
| EK-KD11B-MM | KD11-B PROC MAINT MANUAL |
| MP-N1105-00 | PDP-11/05 MAINTENANCE PRINTS |

The following documents may be applicable to your system, however due to their specific nature, they are not included in this Kit. If you wish to purchase any of these items, use the Part Number and description provided.

| | |
|-------------|--|
| EK-05525-IP | 11/05 (5.25 inch box) Illustrated Parts Breakdown |
| EK-05105-IP | 11/05 (10.5 inch box) Illustrated Parts Breakdown |

OPTION LEVEL KITS

KIT NAME: 11/15(KC11) CPU/SYSTEM DOCUMENTS

KIT NUMBER: FB-11/15

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------------|--------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EK-11015-TM | PDP-11/15 SYSTEM MANUAL |
| MP-N1115-OO | 11/15 MAINTENANCE PRINTS |

KIT NAME: 11/20(KA11) CPU/SYSTEM DOCUMENTS

KIT NUMBER: FB-11/20

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------------|--------------------------|
| EK-11020-TM | PDP-11/20 SYSTEM MANUAL |
| EK-OKA11-TM | KA11 PROC MANUAL |
| MP-N1120-00 | 11/20 MAINTENANCE PRINTS |

KIT NAME: 11/23 (KDF11) CPU/SYSTEM DOCUMENTS

KIT NUMBER: FB-11/23

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------------|--------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EB-18451-20 | MICROCOMPUTER & MEMORIES HNDBK |
| EB-20175-20 | MICROCOMPUTER INTERFACES HNDBK |
| EK-01123-IP | PDP-11/23 UNIT ASSEMBLY IPB |
| MP-00734-OO | KDF11-A MAINTENANCE PRINTS |

KIT NAME: 11/23-B (PLUS) CPU & SYS DOC

KIT NUMBER: FB-11/23-B

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------------|--------------------------------|
| EB-18451-20 | MICROCOMPUTER & MEMORIES HNDBK |
| EB-20175-20 | MICROCOMPUTER INTERFACES HDBK |
| EK-23BMB-TM | PDP11/23B MOUNT BOX TECH MAN |
| EK-23BMB-UG | PDP11/23B MOUNT BOX USR GDE |
| EK-KDFEB-UG | KDF11-B USER GUIDE |
| EK-MSVOP-UG | MSV11-P USER GUIDE |
| MP-01234-00 | 11/23-B MAINTENANCE PRINTS |
| MP-01235-00 | 11/23-B MAINTENANCE PRINTS |

KIT NAME: 11/24 (KDF11-UA) DOCUMENTS

KIT NUMBER: FB-11/24

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------------|--------------------------|
| EK-11024-TM | 11/24 TECHNICAL MANUAL |
| MP-01018 | 11/24 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **1134A (KD11-EA) CPU/
SYS DOCUMENTS**
KIT NUMBER: **FB-1134A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------|---------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EB-19402-20 | PDP-11 PROCESSOR HANDBOOK |
| EK-11034-MC | PDP 11/04/34 MAINT. CARD |
| EK-11034-UG | PDP-11/34 SYSTEM USERS GUIDE |
| EK-1134A-TM | PDP-11/34A POW SYS DESC |
| EK-KD11EA-MM | KD11-EA MAINTENANCE MANUAL |
| MP-00190-00 | 11/34-A MAINTENANCE PRINTS |

The following documents may be applicable to your system, however due to their specific nature, they are not included in this Kit. If you wish to purchase any of these items, use the Part Number and description provided.

| | |
|-------------|--|
| EK-34A52-IP | 134A (5.25 inch box) Illustrated Parts Breakdown |
| EK-34A10-IP | 1134A (10.5 inch box) Illustrated Parts Breakdown |

KIT NAME: **11/35 (KD11-A) CPU/SYS
DOCUMENTS**
KIT NUMBER: **FB-11/35**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EK-01135-IP | PDP-11/35 16-BIT CMP IPB |
| EK-11035-OP | PDP-11/35 SYSTEM USER GUIDE |
| EK-11035-TM | PDP-11/35 SYSTEM MANUAL |
| EK-KD11A-MM | KD11-A PROC MAINTENANCE MANUAL |
| MP-N1135-00 | PDP-11/35 MAINTENANCE PRINTS |

KIT NAME: **11/40 (KD11-A)
DOCUMENTS**
KIT NUMBER: **FB-11/40**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EK-01140-IP | PDP-11/40 16-BIT CMP IPB |
| EK-11040-TM | PDP-11/40/35 SYSTEM MANUAL |
| EK-KD11A-MM | KD11-A PROC MAINTENANCE MANUAL |
| MP-N1140-00 | PDP-11/40 MAINTENANCE PRINTS |

KIT NAME: **11/44 (KD11-Z) CPU/SYS
DOCUMENTS**
KIT NUMBER: **FB-11/44**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EB-19402-20 | PDP-11 PROCESSOR HANDBOOK |
| EK-01144-IP | PDP-11/44 UNIT ASSEMBLY IPB |
| EK-11044-UG | 11/44 SYSTEM USERS GUIDE |
| EK-KD11Z-TM | PDP-11/44 SYS TECH MANUAL |
| EK-PDP44-MC | 11/44 MAINTENANCE CARD |
| MP-00809-00 | 11/44 SYS MAINTENANCE PRINTS |

KIT NAME: **11/35 (KD11-A) CPU/SYS
DOCUMENTS**
KIT NUMBER: **FB-11/35**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EK-01135-IP | PDP-11/35 16-BIT CMP IPB |
| EK-11035-OP | PDP-11/35 SYSTEM USER GUIDE |
| EK-11035-TM | PDP-11/35 SYSTEM MANUAL |
| EK-KD11A-MM | KD11-A PROC MAINTENANCE MANUAL |
| MP-N1135-00 | PDP-11/35 MAINTENANCE PRINTS |

KIT NAME: **11/45 (KB11-A) CPU/
SYSTEM DOCUMENTS**
KIT NUMBER: **FB-11/45**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EK-01145-IP | PDP-11/45 16 BIT CMP IPB |
| EK-11001-HR | PDP-11/45 MAINTENANCE REF MANUAL |
| EK-11045-MM | PDP-11/45 MAINTENANCE MANUAL |
| EK-11045-OP | PDP-11/45/50/55 USER MANUAL |
| EK-11MOS-TM | PDP-11/45/50 TROUBLESHOOT GUIDE |
| EK-KB11A-MM | KB11-A MAINTENANCE MANUAL |
| EK-OLA36-IP | LA36 DECWRITER II IPB |
| MP-N1145-00 | PDP-11/45 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **11/60 (KD11-K) CPU.SYS DOCUMENTS**
KIT NUMBER: **FB-11/60**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EB-19402-20 | PDP-11 PROCESSOR HANDBOOK |
| EK-11060-OP | PDP-11/60 INSTL/OPS MANUAL |
| EK-11060-SV | PDP-11/60 CAB & POW SUPPLY |
| EK-KD11K-TD | KD11-K PROC TECHNICAL DESC |
| EK-KD11K-TM | KD11-K DESC MANUAL |
| MP-00166-00 | 11/60 SYSTEM MAINTENANCE PRINTS |

KIT NAME: **11/70 (KB11-C) CPU/SYS DOCUMENTS**
KIT NUMBER: **FB-11/70-02**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EB-19402-20 | PDP-11 PROCESSOR HANDBOOK |
| EK-01170-IP | PDP-11/70 16-BIT CMP IPB |
| EK-11070-MM | PDP-11/70 MAINT/INSTL MANUAL |
| EK-11070-OP | PDP-11/70 SYSTEM USERS MANUAL |
| EK-E1170-MC | PDP-11/70 ELEC CMSL CMD REFCO |
| EK-KB11C-TM | KB11-C PROC MANUAL |
| MP-OKB11-CO | KB11-C MAINTENANCE PRINTS |

KIT NAME: **11/70 (KB11-B) CPU/SYS DOCUMENTS**
KIT NUMBER: **FB-11/70-01**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EB-20443-20 | PERIPHERALS HANDBOOK |
| EB-19402-20 | PDP-11 PROCESSOR HANDBOOK |
| EK-01170-IP | PDP-11/70 16-BIT CMP IPB |
| EK-11070-MM | PDP-11/70 MAINT/INSTL MAN |
| EK-11070-OP | PDP-11/70 SYSTEM USERS MANUAL |
| EK-E1170-MC | PDP-11/70 ELEC CNSL CMD REFCO |
| EK-KB11B-TM | KB11-B PROC MANUAL |
| MP-OKB11-BO | KB11-B MAINTENANCE PRINTS |

KIT NAME: **AA11-K/KT DOCUMENTS**
KIT NUMBER: **FB-AA11-K**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-AA11K-TM | AA11-K TECHNICAL MAN |
| MP-00161-00 | AA11-K MAINTENANCE PRINTS |

KIT NAME: **AAV11 DOCUMENTS**
KIT NUMBER: **FB-AAV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-ADV11-OP | ADV11-A, KWV11-A, DRV11, AAV11-A |
| USERS | MANUAL |
| MP-00186-00 | AAV11-A MAINTENANCE PRINTS |

KIT NAME: **AD11-K DOCUMENTS**
KIT NUMBER: **FB-AD11-K**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-AD11K-OP | AD11-K USER MANUAL |
| MP-00047-00 | AD11-K MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **ADV11-A DOCUMENTS**
KIT NUMBER: **FB-ADV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---|
| EK-ADV11-OP | ADV11-A, KWV11-A, DRV11, AAV11-A IPB |
| USERS | MANUAL |
| MP-00193-00 | ADV11-A MAINTENANCE PRINTS |

KIT NAME: **AM11-K DOCUMENTS**
KIT NUMBER: **FB-AM11-K**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------------|
| EK-QM11K-TM | AM11-K MULTIPLE GAIN USER MANUAL |
| MP-00090-00 | AM11-K MAINTENANCE PRINTS |

KIT NAME: **AR11 DOCUMENTS**
KIT NUMBER: **FB-AR11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-OAR11-OP | AR11 USERS GUIDE IPB |
| MP-AR11-00 | AR11 MAINTENANCE PRINTS |

KIT NAME: **BA11-A DOCUMENTS**
KIT NUMBER: **FB-BA11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-BA11A-IP | BA11-A UNIT ASSEMBLY IPB |
| EK-BA11A-TM | BA11-A TECHNICAL MANUAL |
| MP-00832-00 | BA11-A MAINTENANCE PRINTS |

KIT NAME: **BA11-FD/-FE
DOCUMENTS**
KIT NUMBER: **FB-BA11-F**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-BA11F-IP | BA11--F MOUNTING BOX IPB |
| MP-BA11-F | BA11-F MAINTENANCE PRINTS |

KIT NAME: **BA11-K DOCUMENTS**
KIT NUMBER: **FB-BA11-K**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------------|
| EK-BA11K-IP | BA11-K MOUNTING BOX IPB |
| EK-BA11K-OP | BA11-K MOUNTING BOX USERS MANUAL |
| EK-BA11K-TM | BA11-K TECHNICAL MANUAL |
| MP-00311-00 | BA11-K MAINTENANCE PRINTS |

KIT NAME: **BA11-L DOCUMENTS**
KIT NUMBER: **FB-BA11-L**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-BA11L-IP | BA11-L MOUNTING BOX IPB |
| EK-BA11L-TM | BA11-L TECHNICAL MANUAL |
| MP-00018-00 | BA11-L MAINTENANCE PRINTS |

KIT NAME: **BA11-M DOCUMENTS**
KIT NUMBER: **FB-BA11-M**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-BA11M-IP | BA11-M MOUNTING BOX IPB |
| MP-BA11-M | BA11-M MAINTENANCE PRINTS |

KIT NAME: **BA11-N DOCUMENTS**
KIT NUMBER: **FB-BA11-N**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-BA11N-IP | BA11-N MOUNTING BOX IPB |
| EK-BA11N-TM | BA11-N MOUNTING BOX TECH MAN |
| EK-BA11N-UG | BA11-N MOUNTING BOX USR MAN |
| MP-00487-00 | BA11-N MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **BA11-P DOCUMENTS**
KIT NUMBER: **FB-BA11-P**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-BA11P-IP | BA11-P UNIT ASSEMBLY IPB |
| MP-00410-00 | BA11-P MAINTENANCE PRINTS |

KIT NAME: **BDV11 DOCUMENTS**
KIT NUMBER: **FB-BDV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-BDV11-TM | BDV11 TECHNICAL MANUAL |
| MP-00489-00 | BDV11-A MAINTENANCE PRINTS |

KIT NAME: **BA11-R DOCUMENTS**
KIT NUMBER: **FB-BA11-R**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| MP-00589-00 | BA11-R MAINTENANCE PRINTS |

KIT NAME: **BM873-YB DOCUMENTS**
KIT NUMBER: **FB-BM873-YB**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------------|
| EK-BM873-TM | BM873 RESTART/LOADER MANUAL |
| MP-BM873-00 | BM873 MAINTENANCE PRINTS |

KIT NAME: **BA11-S DOCUMENTATION
KIT**

KIT NUMBER: **FB-BA11-S**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-23BMB-TM | PDP11/23B MOUNT BOX TECH MAN |
| EK-23BMB-UG | PDP11/23B MOUNT BOX USR GUIDE |
| MP-01233-00 | BA11-S MAINTENANCE PRINTS |

KIT NAME: **DB11-A DOCUMENTS**
KIT NUMBER: **FB-DB11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-DB11A-TM | DB11-A BUS REPEATER MANUAL |
| MP-DB11-A | DB11-A MAINTENANCE PRINTS |

KIT NAME: **BA11-U DOCUMENTS**
KIT NUMBER: **FB-BA11-U**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-BA11U-IP | BA11-U MOUNTING BOX IPB |
| MP-00361-00 | BA11-U MAINTENANCE PRINTS |

KIT NAME: **DD11-A DOCUMENTS**
KIT NUMBER: **FB-DD11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| MP-DD11-A | DD11-A MAINTENANCE PRINTS |

KIT NAME: **BA11-V DOCUMENTS**
KIT NUMBER: **FB-BA11-V**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-BA11V-IP | BA11-V BOX ASSEMBLY IPB |
| EK-BA11V-RG | BA11-VA CONFIGURATION GDE |
| MP-00840-00 | BA11-V-MAINTENANCE PRINTS |

KIT NAME: **DD11-B DOCUMENTS**
KIT NUMBER: **FB-DD11-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| MP-DD11-B | DD11-B MAINTENANCE PRINTS |

KIT NAME: **DD11-C DOCUMENTS**
KIT NUMBER: **FB-DD11-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| MP-DD11-C | DD11-C MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **DD11-D DOCUMENTS**
KIT NUMBER: **FB-DD11-D**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-ODD11-D0 | DD11-D MAINTENANCE PRINTS |

KIT NAME: **DD11-K DOCUMENTS**
KIT NUMBER: **FB-DD11-K**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-00276-00 | DD11-K MAINTENANCE PRINTS |

KIT NAME: **DD11-P DOCUMENTS**
KIT NUMBER: **FB-DD11-P**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-ODD11-P | DD11-P MAINTENANCE PRINTS |

KIT NAME: **DF02 DOCUMENTS**
KIT NUMBER: **FB-DF02**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-ODF02-IP | DF02 MODEM UNIT ASSEMBLY IPB |
| EK-ODF02-PS | DF02 MODEM POCKET SERVICE GUIDE |
| EK-ODF02-UG | DF02 USER GUIDE |

KIT NAME: **DF03 DOCUMENTS**
KIT NUMBER: **FB-DF03**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-ODF03-IP | DF03 ILLUSTRATED PARTS BREAKDOWN |
| EK-ODF03-PS | DF03 MODEM POCKET SERVICE GUIDE |
| EK-ODF03-UG | DF03 MODEM USERS GUIDE |

KIT NAME: **DH11 DOCUMENTS**
KIT NUMBER: **FB-DH11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-ODH11-MM | DH11 MAINTENANCE MANUAL |
| EK-ODH11-UG | DH11 MUX USER MANUAL |
| MP-DH11-00 | DH11 MAINTENANCE PRINTS |

KIT NAME: **DK8-EF DOCUMENTS**
KIT NUMBER: **FB-DK8-EF**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-DK8-EF | DK8-EF MAINTENANCE PRINTS |

KIT NAME: **DK8-EP DOCUMENTS**
KIT NUMBER: **FB-DK8-EP**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-DK8-EP | DK8-EP MAINTENANCE PRINTS |

KIT NAME: **DK8-ES DOCUMENTS**
KIT NUMBER: **FB-DK8-ES**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-DK8-ES | DK8-ES MAINTENANCE PRINTS |

KIT NAME: **DKC8-AA DOCUMENTS**
KIT NUMBER: **FB-DKC8-AA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-DKC8-A | DKC8-A MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **DL11-W DOCUMENTS**
KIT NUMBER: **FB-DL11-W**

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------|---------------------------|
| EK-DL11-W-MM | DL11-W MAINTENANCE MANUAL |
| EK-DL11W-OP | DL11-W OPERATORS MANUAL |
| MP-00106-00 | DL11-W MAINTENANCE PRINTS |

KIT NAME: **DLV11-E DOCUMENTS**
KIT NUMBER: **FB-DLV11-E**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-DLV11-OP | DLV11-E/F USERS MANUAL |
| MP-00460-00 | DLV11-E MAINTENANCE PRINTS |

KIT NAME: **DLV11-F DOCUMENTS**
KIT NUMBER: **FB-DLV11-F**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-DLV11-OP | DLV11-E/F USERS MANUAL |
| MP-00461-00 | DLV11-F MAINTENANCE PRINTS |

KIT NAME: **DLV11-J DOCUMENTS**
KIT NUMBER: **FB-DLV11-J**

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------|----------------------------|
| EK-DLV11J-UG | DLV11-J USER GUIDE |
| MP-00586-00 | DLV11-J MAINTENANCE PRINTS |

KIT NAME: **DLV11-K DOCUMENTS**
KIT NUMBER: **FB-DLV11-K**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-DLVKA-IN | DLV11-KA INSTALLATION MANUAL |
| MP-00694-00 | DLV11-KA MAINTENANCE PRINTS |

KIT NAME: **DM11-A DOCUMENTS**
KIT NUMBER: **FB-DM11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-DM11A-OP | DM11 USER MANUAL |
| EK-DM11A-TM | DM11 TECHNICAL MANUAL |
| MP-0DM11-A0 | DM11 MAINTENANCE PRINTS |

KIT NAME: **DM11-B DOUCMENTS**
KIT NUMBER: **FB-DM11-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-DM11B-OP | DM11-BB USER MANUAL |
| EK-DM11B-TM | DM11-BB TECHNICAL MANUAL |
| MP-DM11-B | DM11-BB MAINTENANCE PRINTS |

KIT NAME: **DM11-D DOCUMENTS**
KIT NUMBER: **FB-DM11-D**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-DM11A-OP | DM11 USER MANUAL |
| EK-DM11A-TM | DM11 TECHNICAL MANUAL |
| MP-0DM11-D0 | DM11 MAINTENANCE PRINTS |

KIT NAME: **DMC11 DOCUMENTS**
KIT NUMBER: **FB-DMC11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-DMCLU-MM | DMC11 MAINTENANCE MANUAL |
| EK-DMCLU-OP | DMC11 USER MANUAL |
| EK-DMCMP-OP | DMC11 USER MANUAL |
| EK-DMCMP-OP | DMC11 TECHNICAL MANUAL |
| MP-00076-00 | DMC11 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **DN11 DOCUMENTS**
KIT NUMBER: **FB-DN11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-ODN11-OP | DN11 USER MANUAL |
| EK-ODN11-TM | DN11 TECHNICAL MANUAL |
| MP-DN11-00 | DN11 MAINTENANCE PRINTS |

KIT NAME: **DR11-K DOCUMENTS**
KIT NUMBER: **FB-DR11-K**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------------|
| EK-DR11K-MM | DR11-K USER AND MAINTENANCE MANUAL |
| MP-DR11-K | DR11-K MAINTENANCE PRINTS |

KIT NAME: **DPV11 DOCUMENTS**
KIT NUMBER: **FB-DPV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00919 | DPV11 MAINTENANCE PRINTS |

KIT NAME: **DR11-L DOCUMENTS**
KIT NUMBER: **FB-DR11-L**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-DR11L-OP | DR11-L/M USER MANUAL |
| MP-00003-00 | DR11-L MAINTENANCE PRINTS |

KIT NAME: **DQ11 DOCUMENTS**
KIT NUMBER: **FB-DQ11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-ODQ11-MM | DQ11 MAINTENANCE MANUAL |
| EK-ODQ11-OP | DQ11 USERS MANUAL |
| MP-DQ11-00 | DQ11 MAINTENANCE PRINTS |

KIT NAME: **DR11-M DOCUMENTS**
KIT NUMBER: **FB-DR11-M**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-DR11L-OP | DR11-L/M USER MANUAL |
| MP-00004-00 | DR11-M MAINTENANCE PRINTS |

KIT NAME: **DR11-B DOCUMENTS**
KIT NUMBER: **FB-DR11-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------------|
| EK-DR11B-OP | DR11-B/DA11-B USER MANUAL |
| EK-DR11B-TM | DR11-B/DA11-B TECHNICAL MANUAL |
| MP-DR11-B | DR11-B MAINTENANCE PRINTS |

KIT NAME: **DR11-W DOCUMENTS**
KIT NUMBER: **FB-DR11-W**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-DR11W-UG | DR11-W USERS GUIDE |
| MP-00693 | DR11-W MAINTENANCE PRINTS |

KIT NAME: **DR11-C DOCUMENTS**
KIT NUMBER: **FB-DR11-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-DR11C-OP | DR11-C USER MANUAL |
| EK-DR11C-TM | DR11-C TECHNICAL MANUAL |
| MP-DR11-C | DR11-C MAINTENANCE PRINTS |

KIT NAME: **DRS11 DOCUMENTS**
KIT NUMBER: **FB-DRS11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00175-00 | DRS11 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **DRV11 DOCUMENTS**
KIT NUMBER: **FB-DRV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-ADV11-OP | ADV11-A,KWV11-A,DRV11,AAV11-A |
| USER | MANUAL |
| MP-00054-00 | DRV11 MAINTENANCE PRINTS |

KIT NAME: **DRV11-B DOCUMENTS**
KIT NUMBER: **FB-DRV11-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------|----------------------------|
| EK-DRV11B-OP | DRV11-B USER MANUAL |
| MP-00160-00 | DRV11-B MAINTENANCE PRINTS |

KIT NAME: **DRV11-J DOCUMENTS**
KIT NUMBER: **FB-DRV11-J**

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------|----------------------------|
| EK-DRV11J-UG | DRV11-J USER MANUAL |
| MP-00866-00 | DRV11-J MAINTENANCE PRINTS |

KIT NAME: **DRV11-P DOCUMENTS**
KIT NUMBER: **FB-DRV11-P**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-DRV11-OP | DRV11-P USER MANUAL |
| MP-00119-00 | DRV11-P MAINTENANCE PRINTS |

KIT NAME: **DSS11 DOCUMENTS**
KIT NUMBER: **FB-DSS11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00174-00 | DSS11 MAINTENANCE PRINTS |

KIT NAME: **DU11 DOCUMENTS**
KIT NUMBER: **FB-DU11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-ODU11-MM | DU11 MAINT MANUAL |
| EK-ODU11-OP | DU11 USERS MANUAL |
| MP-ODU11-00 | DU11 MAINTENANCE PRINTS |

KIT NAME: **DUP11-DA DOCUMENTS**
KIT NUMBER: **FB-DUP11-D**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-DUP11-MM | DUP11 MAINTENANCE MANUAL |
| EK-DUP11-OP | DUP11 USERS MANUAL |
| MP-DUP11-00 | DUP11 MAINTENANCE PRINTS |

KIT NAME: **DUV11 DOCUMENTS**
KIT NUMBER: **FB-DUV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-DUV11-OP | DUV11 USER MANUAL |
| EK-DUV11-TM | DUV11 TECHNICAL MANUAL |
| MP-00297-00 | DUV11-D MAINTENANCE PRINTS |

KIT NAME: **DV11 DOCUMENTS**
KIT NUMBER: **FB-DV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-ODV11-MM | DV11 MAINTENANCE MANUAL |
| EK-ODV11-OP | DV11 USER MANUAL |
| MP-DV11-00 | DV11 MAINTENANCE PRINTS |

KIT NAME: **DW08-A DOCUMENTS**
KIT NUMBER: **FB-DW08-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-DW08-A | DW08-A MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **DW08-B DOCUMENTS**
KIT NUMBER: **FB-DW08-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-DW08-B | DW08-B MAINTENANCE PRINTS |

KIT NAME: **DW780 DOCUMENTATION**
KIT NUMBER: **FB-DW780**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-DW780-TD | VAX-11/780 DW780 TECHNICAL DESC |
| MP-00497-00 | DW780 MAINTENANCE PRINTS |

KIT NAME: **DZ11-A/B/E DOCUMENTS**
KIT NUMBER: **FB-DZ11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-DZ110-TM | DZ11 TECHNICAL MANUAL |
| EK-DZ110-UG | DZ11 USERS GUIDE |
| EK-ODZ11-MM | DZ11 MAINTENANCE MANUAL |
| MP-00132-00 | DZ11-A/B/E MAINTENANCE PRINTS |

KIT NAME: **DZ11-C/D/F DOCUMENTS**
KIT NUMBER: **FB-DZ11-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-DZ110-TM | DZ11 TECHNICAL MANUAL |
| EK-DZ110-UG | DZ11 USERS GUIDE |
| EK-ODZ11-MM | DZ11 MAINTENANCE MANUAL |
| MP-00253-00 | DZ11-C/D/F MAINTENANCE PRINTS |

KIT NAME: **DZ32 DOCUMENTS**
KIT NUMBER: **FB-DZ32**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------|
| EK-ODZ32-UG | DZ32 USERS GUIDE |
| EK-ODZ32-TM | DZ32 TECHNICAL MANUAL |

KIT NAME: **DZV11 DOCUMENTS**
KIT NUMBER: **FB-DZV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EK-DZV11-TM | DZV11 ASYNCH MULTI TECH MANUAL |
| EK-DZV11-UG | DZV11 ASYNCH MULTIPLEXOR GDE & AD |
| MP-00462-00 | DZV11 MAINTENANCE PRINTS |

KIT NAME: **FP11-A DOCUMENTS**
KIT NUMBER: **FB-FP11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-FP11A-TM | FP11-A TECHNICAL MANUAL |
| EK-FP11A-UC | FP11-A USER GUIDE |
| MP-00189-00 | FP11-A MAINTENANCE PRINTS |

KIT NAME: **FP11-B DOCUMENTS**
KIT NUMBER: **FB-FP11-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-OFP11-MM | FP11-B MAINTENANCE MANUAL |
| MP-FP11-B | FP11-B MAINTENANCE PRINTS |

KIT NAME: **FP11-C DOCUMENTS**
KIT NUMBER: **FB-FP11-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------|---------------------------|
| EK-FP11C-MM | FP11-C MAINTENANCE MANUAL |
| EK-FP11-C-OP | FP11-C USER MANUAL |
| MP-00038-00 | FP-11C MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: FP11-EA DOCUMENTS
KIT NUMBER: FB-FP11-EA

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-FP11E-TM | FP11-E TECHNICAL MANUAL |
| EK-FP11E-UG | FP11-E USERS GUIDE |
| MP-00429-00 | FP11-E MAINTENANCE PRINTS |

KIT NAME: FP11-F DOCUMENTS
KIT NUMBER: FB-FP11-F

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-00810-00 | FP11-F MAINTENANCE PRINTS |

KIT NAME: FP780 DOCUMENTS
KIT NUMBER: FB-FP780

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-FP780-TD | FP780 TECHNICAL DESCRIPTION |
| MP-00565-00 | FP780 MAINTENANCE PRINTS |

KIT NAME: FPF11 DOCUMENTS
KIT NUMBER: FB-FPF11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------|
| EK-FPF11-TM | FPF11 TECHNICAL MANUAL |

KIT NAME: FPP8-A DOCUMENTS
KIT NUMBER: FB-FPP8-A

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-FPP8A-MM | FPP8-A MAINTENANCE MANUAL |
| EK-FPP8A-OP | FPP8-A USER MANUAL |

KIT NAME: FPP8-E DOCUMENTS
KIT NUMBER: FB-FPP8-E

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-FPP8A-MM | FPP8-A MAINTENANCE MANUAL |
| EK-FPP8A-OP | FPP8-A USER MANUAL |
| EK-H9300-IP | H9300 CHASSIS ASSEMBLY IPB |
| MP-00341-00 | FPP8-E MAINTENANCE PRINTS |

KIT NAME: H312 DOCUMENTS
KIT NUMBER: FB-H312

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-H312-A | H312-A MAINTENANCE PRINTS |

KIT NAME: H319 DOCUMENTS
KIT NUMBER: FB-H319

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| MP-H319-00 | H319 MAINTENANCE PRINTS |

KIT NAME: H7100 DOCUMENTS
KIT NUMBER: FB-H7100

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00480-00 | H7100 MAINTENANCE PRINTS |

KIT NAME: H7104 DOCUMENTS
KIT NUMBER: FB-H7104

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-PS750-TD | H7104 TECHNICAL DESCRIPTION |

KIT NAME: H7422 DOCUMENTS
KIT NUMBER: FB-H7422

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-H7422-IP | H7422 IPB |
| MP-00717 | H7422 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: H745 DOCUMENTS
KIT NUMBER: FB-H745

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-OH745-IP | H745 REGULATOR IPB |
| MP-H745-00 | H745 MAINTENANCE PRINTS |

KIT NAME: H754 DOCUMENTS
KIT NUMBER: FB-H754

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-OH754-IP | H754 REGULATOR IPB |
| MP-H754-00 | H754 MAINTENANCE PRINTS |

KIT NAME: H765 DOCUMENTS
KIT NUMBER: FB-H765

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-OH765-IP | H765 POWER SUPPLY IPB |
| MP-H765-00 | H765 MAINTENANCE PRINTS |

KIT NAME: H766 DOCUMENTS
KIT NUMBER: FB-H766

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------|
| EK-OH766-IP | H766 IPB |

KIT NAME: H775 DOCUMENTS
KIT NUMBER: FB-H775

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-OH775-IP | H775 BATTERY BACK-UP IPB |
| MP-00014-00 | H775 MAINTENANCE PRINTS |

KIT NAME: H950 DOCUMENTS
KIT NUMBER: FB-H950

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| MP-H950-00 | H950 MAINTENANCE PRINTS |

KIT NAME: H9500 DOCUMENTS
KIT NUMBER: FB-H9500

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00058-00 | H9500 MAINTENANCE PRINTS |

KIT NAME: H9501 DOCUMENTS
KIT NUMBER: FB-H9501

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00059-00 | H9501 MAINTENANCE PRINTS |

KIT NAME: H9506 DOCUMENTS
KIT NUMBER: FB-H9506

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00079 | H9506 MAINTENANCE PRINTS |

KIT NAME: H9610 DOCUMENTS
KIT NUMBER: FB-H9610

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| MP-H9610-00 | H9610-00 MAINTENANCE PRINTS |

KIT NAME: H960-D DOCUMENTS
KIT NUMBER: FB-H960-D

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| MP-H960-D | H960-D MAINTENANCE PRINTS |
| EK-OH960-UG | H960/H967 CAB. USERS GUIDE |

KIT NAME: H9600 DOCUMENTS
KIT NUMBER: FB-H9600

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00660-00 | H9600 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **H9602-C DOCUMENTS**
KIT NUMBER: **FB-H9602-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| MP-00335-00 | H9602-C MAINTENANCE PRINTS |

KIT NAME: **H9612 DOCUMENTS**
KIT NUMBER: **FB-H9612**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-H9612-00 | H9612 MAINTENANCE PRINTS |

KIT NAME: **H9642 DOCUMENTS**
KIT NUMBER: **FB-H9642**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| MP-00779-00 | H9642-B MAINTENANCE PRINTS |

KIT NAME: **IB11 DOCUMENTS**
KIT NUMBER: **FB-IB11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-IB11A-IN | IB11 INSTALLATION MANUAL |
| MP-00620-00 | IB11 MAINTENANCE PRINTS |

KIT NAME: **IBV11 DOCUMENTS**
KIT NUMBER: **FB-IBV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-IBV11-UG | IBV11-A USER MANUAL |
| MP-00274-00 | IBV11-A MAINTENANCE PRINTS |

KIT NAME: **KA8-E DOCUMENTS**
KIT NUMBER: **FB-KA8-E**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-KA8-E | KA8-E MAINTENANCE PRINTS |

KIT NAME: **VAX-11/750 (KA750) CPU/SYS DOCUMENTS**

KIT NUMBER: **FB-KA750**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EB-17281-20 | VAX HARDWARE HANDBOOK 1980-81 |
| EK-750YA-UG | VAX11/750 SELF MAINT DIAG GUIDE |
| EK-KA750-TD | VAX-11/750 CPU TECH DESC |
| EK-SI750-IN | 11/750 SYSTEM INSTR MANUAL |
| EK-1VAXD-TM | VAX DIAGNOSTIC DESIGN GUIDE |
| EK-UI750-TD | VAX-11/750 TECHNICAL DESCRIPTION |
| EK-VXD75-UG | VAX-11/750 DIAG SYSTEM OVERVIEW |
| MP-00838-00 | 11/750 MAINTENANCE PRINTS |
| MP-01024-00 | VAX-11/750 MAINTENANCE PRINTS |

KIT NAME: **VAX-11/780 CPU AND SYSTEM DOCUMENTS**
KIT NUMBER: **FB-KA780**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------------|
| EB-17281-20 | VAX HARDWARE HANDBOOK 1980-81 |
| EB-19580-20 | VAX-11 ARCHITECTURE HANDBOOK |
| EK-11780-UG | VAX-11/780 HDW USERS GUIDE |
| EK-DS780-TD | VAX-11/780 TECHNICAL DESCRIPTION |
| EK-DS780-UG | VAX-11/780 DIAG SYSTEM USERS GUIDE |
| EK-KA780-TD | VAX-11/780 KA780 PROC TECH |
| EK-MM780-TD | VAX-11/780 BUFFER,CACHE,SBI |
| EK-PS780-TD | VAX-11/780 POWER SYSTEM TECH DESC |
| EK-SI780-IN | VAX-11/780 SYSTEM INSTL MANUAL |
| MP-00539-00 | 11/780 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **KC750 DOCUMENTS**

KIT NUMBER: **FB-KC750**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-KC750-IN | KC750 INSTALLATION GUIDE |
| EK-KC750-TM | KC750 TECHNICAL MANUAL |
| EK-KC750-UG | KC750 USERS GUIDE |

KIT NAME: **KC780 DOCUMENTS**

KIT NUMBER: **FB-KC780**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-KC780-IN | KC780 HDW INSTL |
| EK-KC780-TD | VAX-11/780 CNSL INTFC TECH DE |
| EK-KC780-UG | KC780 OPTION USR GDE |
| MP-00534-00 | KC780 MAINTENANCE PRINTS |

KIT NAME: **KC8-AA DOCUMENTS**

KIT NUMBER: **FB-KC8-AA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-OKC8A-IP | KC8-A CONSOLE IPB |
| MP-KC8-A | KC8-A MAINTENANCE PRINTS |

KIT NAME: **KC8-E DOCUMENTS**

KIT NUMBER: **FB-KC8-E**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-KC8EA-IP | KC8-E/A/EC CONSOLE IPB |
| MP-KC8-E | KC8-E MAINTENANCE PRINTS |

KIT NAME: **KD11-F (LSI-11)**

DOCUMENTS

KIT NUMBER: **FB-KD11-F**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------------|
| EB-18451-20 | MICROCOMPUTER & MEMORIES HNDBK |
| EB-20175-20 | MICROCOMPUTER INTERFACES HNDBK |
| MP-00049-00 | KD11-F MAINTENANCE PRINTS |

The following documents may be applicable to your system, however due to their specific nature, they are not included in this Kit. If you wish to purchase any of these items, use the Part Number and description provided.

| | |
|-------------|------------------------------------|
| EK-01103-IP | 11/03 ILLUSTRATED PARTS BREAKDOWN |
| EK-1103J-IP | 11/03J ILLUSTRATED PARTS BREAKDOWN |
| EK-1103L-IP | 11/03L ILLUSTRATED PARTS BREAKDOWN |

KIT NAME: **KD11-HA (LSI-11/2)**

DOCUMENTS

KIT NUMBER: **FB-KD11-HA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------------|
| EB-18451-20 | MICROCOMPUTER & MEMORIES HNDBK |
| EB-20175-20 | MICROCOMPUTER INTERFACES HNDBK |
| MP-00495-00 | KD11-HA MAINTENANCE PRINTS |

The following documents may be applicable to your system, however due to their specific nature, they are not included in this Kit. If you wish to purchase any of these items, use the Part Number and description provided.

| | |
|-------------|------------------------------------|
| EK-01103-IP | 11/03 ILLUSTRATED PARTS BREAKDOWN |
| EK-1103J-IP | 11/03J ILLUSTRATED PARTS BREAKDOWN |
| EK-1103L-IP | 11/03L ILLUSTRATED PARTS BREAKDOWN |

OPTION LEVEL KITS

KIT NAME: **KE11-A DOCUMENTS**
KIT NUMBER: **FB-KE11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KE11A-OP | KE11-A USER MANUAL |
| EK-KE11A-TM | KE11-A TECHNICAL MANUAL |
| MP-KE11-A | KE11-A MAINTENANCE PRINTS |

KIT NAME: **KE11-B DOCUMENTS**
KIT NUMBER: **FB-KE11-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KE11B-MM | KE11-B MAINTENANCE MANUAL |
| EK-KE11B-OP | KE11-B USER MANUAL |
| MP-KE11-B | KE11-B MAINTENANCE PRINTS |

KIT NAME: **KE11-E DOCUMENTS**
KIT NUMBER: **FB-KE11-E**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KE11E-OP | KE11-E/F USER MANUAL |
| EK-KE11E-TM | KE11-E/F TECHNICAL MANUAL |
| MP-KE11-B | KE11-E MAINTENANCE PRINTS |

KIT NAME: **KE11-F DOCUMENTS**
KIT NUMBER: **FB-KE11-F**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KE11E-OP | KE11-E/F USER MANUAL |
| EK-KE11E-TM | KE11-E/F TECHNICAL MANUAL |
| MP-KE11-F | KE11-F MAINTENANCE PRINTS |

KIT NAME: **KE44-A DOCUMENTS**
KIT NUMBER: **FB-KE44-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KE44A-UG | KE44-A CISP USER GUIDE |
| MP-00813-00 | KE44-A MAINTENANCE PRINTS |

KIT NAME: **KE8-E DOCUMENTS**
KIT NUMBER: **FB-KE8-E**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-KE8-E | KE8-E MAINTENANCE PRINTS |

KIT NAME: **KEV11 DOCUMENTS**
KIT NUMBER: **FB-KEV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-KEV11-IP | KEV11 INSTALLATION PROCEDURES |
| MP-KEV11-00 | KEV11 MAINTENANCE PRINTS |

KIT NAME: **KG11-A DOCUMENTS**
KIT NUMBER: **FB-KG11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KG11A-OP | KG11-A USER MANUAL |
| EK-KG11A-TM | KG11-A TECHNICAL MANUAL |
| MP-KG11-A | KG11-A MAINTENANCE PRINTS |

KIT NAME: **KG8-EA DOCUMENTS**
KIT NUMBER: **FB-KG8-EA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-KG8-E | KG8-E MAINTENANCE PRINTS |

KIT NAME: **KJ11-A DOCUMENTS**
KIT NUMBER: **FB-KJ11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-KJ11-A | KJ11-A MAINTENANCE PRINTS |

KIT NAME: **KK11-B DOCUMENTS**
KIT NUMBER: **FB-KK11-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-00811-00 | KK11-B MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **KM8-AA DOCUMENTS**
KIT NUMBER: **FB-KM8-AA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-KM8-A | KM8-A MAINTENANCE PRINTS |

KIT NAME: **KM8-E DOCUMENTS**
KIT NUMBER: **FB-KM8-E**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-KM8-E | KM8-E MAINTENANCE PRINTS |

KIT NAME: **KP8-E DOCUMENTS**
KIT NUMBER: **FB-KP8-E**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-KP8-E | KP8-E MAINTENANCE PRINTS |

KIT NAME: **KPV11 DOCUMENTS**
KIT NUMBER: **FB-KPV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00356-00 | KPV11 MAINTENANCE PRINTS |

KIT NAME: **KT11-C DOCUMENTS**
KIT NUMBER: **FB-KT11-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-KT11C-MM | KT11-C/CD MAINTENANCE MANUAL |
| EK-KT11C-OP | KT11-C/CD USER MANUAL |
| MP-KT11-C | KT11-C MAINTENANCE PRINTS |

KIT NAME: **KT11-D DOCUMENTS**
KIT NUMBER: **FB-KT11-D**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-KT11D-IN | KT11-D INSTALLATION MANUAL |
| EK-KT11D-OP | KT11-D USER MANUAL |
| EK-KT11D-TM | KT11-D TECHNICAL MANUAL |
| MP-KT11-D | KT11-D MAINTENANCE PRINTS |

KIT NAME: **KW11-K DOCUMENTS**
KIT NUMBER: **FB-KW11-K**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KW11-OP | KW11-K USER MANUAL |
| MP-00048-00 | KW11-K MAINTENANCE PRINTS |

KIT NAME: **KW11-L DOCUMENTS**
KIT NUMBER: **FB-KW11-L**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KW11L-TM | KW11-L TECHNICAL MANUAL |
| MP-KW11-L | KW11-L MAINTENANCE PRINTS |

KIT NAME: **KW11-P DOCUMENTS**
KIT NUMBER: **FB-KW11-P**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KW11P-MM | KW11-P MAINTENANCE MANUAL |
| EK-KW11P-OP | KW11-P USER MANUAL |
| MP-KW11-P | KW11-P MAINTENANCE PRINTS |

KIT NAME: **KW11-W DOCUMENTS**
KIT NUMBER: **FB-KW11-W**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KW11W-TM | KW11-W TECHNICAL MANUAL |
| MP-KW11-W | KW11-W MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **KWV11-A DOCUMENTS**
KIT NUMBER: **FB-KWV11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-ADV11-OP | ADV11-A, KWV11-A, DRV11, AAV11-A |
| OPERATORS | MANUAL |
| MP-00200-00 | KWV11-A MAINTENANCE PRINTS |

KIT NAME: **KY11-C DOCUMENTS**
KIT NUMBER: **FB-KY11-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-KY11C-TD | MP-KY11-NTENANCE PRINTS |

KIT NAME: **KY11-LA DOCUMENTS**
KIT NUMBER: **FB-KY11-LA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-KY11L-IP | KY11-L CONSOLE IPB |
| MP-00017-00 | KY11-LA MAINTENANCE PRINTS |

KIT NAME: **KY11-LB DOCUMENTS**
KIT NUMBER: **FB-KY11-LB**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-KY11L-IP | KY11-L CONSOLE IPB |
| EK-KY1LB-MM | KY11-LB MAINTENANCE MANUAL |
| MP-00015-00 | KY11-LB MAINTENANCE PRINTS |

KIT NAME: **KY11-P DOCUMENTS**
KIT NUMBER: **FB-KY11-P**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-KY11P-IP | KY11-P CONSOLE IPB |
| MP-KY11-P | KY11-P MAINTENANCE PRINTS |

KIT NAME: **LA120 DOCUMENTS**
KIT NUMBER: **FB-LA120**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EB-20752-20 | TERMINALS & COMM HANDBOOK |
| EK-LA120-IP | LA120 DECWRITER III IPB |
| EK-LA120-RG | LA120 OPERATOR REF CARD |
| EK-LA120-SV | LA120 POCKET SV GUIDE |
| EK-LA120-TM | LA120 TECHNICAL MANUAL |
| EK-LA120-UG | LA120 USERS GUIDE |
| MP-00663-00 | LA120 MAINTENANCE PRINTS |

KIT NAME: **LA120-RA DOCUMENTS**
KIT NUMBER: **FB-LA120-RA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-LA2RA-IP | LA120-RA IPB |
| EK-LA2RA-UG | LA120-RA USERS GUIDE |
| MP-01046-00 | LA120-RA MAINTENANCE PRINTS |

KIT NAME: **LA180 DOCUMENTS**
KIT NUMBER: **FB-LA180**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-LA180-IP | LA180 DECPRINTER I IPB |
| EK-LA180-MM | LA180 DECPRINTER I MAINT MANUAL |
| EK-LA180-OP | LA180 USER MANUAL |
| MP-LA180-00 | LA180 MAINTENANCE PRINTS |

KIT NAME: **LA34 DOCUMENTS**
KIT NUMBER: **FB-LA34**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EB-20752-20 | TERMINALS & COMM HANDBOOK |
| EK-LA34S-IP | LA34 DECWRITER IV IPB |
| EK-OLA34-RG | LA34 REFERENCE CARD |
| EK-OLA34-SV | LA34 POCKET SV GUIDE |
| EK-OLA34-UG | LA34 USERS GUIDE |
| MP-00695-00 | LA34 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: LA35 DOCUMENTS
KIT NUMBER: FB-LA35

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-LA356-J1 | LA35/36 MINI MAINT HDW GUIDE |
| EK-LA365-OP | LA35/36 USER MANUAL |
| EK-OLA35-IP | LA35 DECWRITER I IPB |
| MP-LA35-00 | LA35 MAINTENANCE PRINTS |

KIT NAME: LA36 DOCUMENTS
KIT NUMBER: FB-LA36

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EB-20752-20 | TERMINALS & COMM HANDBOOK |
| EK-1LA36-MM | LA36 BSC MACHINE MAINT MANUAL V1 |
| EK-2LA36-MM | LA36 (OPT INFO) MAINT MANUAL V2 |
| EK-LA356-J1 | LA35/36 MINI MAINT HARDWARE GUIDE |
| EK-LA365-OP | LA35/36 DECWRITER II USER MANUAL |
| EK-OLA36-IP | LA36 DECWRITER II IPB |
| MP-LA36-00 | LA36 MAINTENANCE PRINTS |

KIT NAME: LA38 DOCUMENTS
KIT NUMBER: FB-LA38

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EB-20752-20 | TERMINALS & COMM HANDBOOK |
| EK-LA34S-IP | LA34 DECWRITER IV IPB |
| EK-OLA34-RG | LA34 DECWRITER IV REFERENCE GUIDE |
| EK-OLA34-SV | LA34 POCKET SERVICE GUIDE |
| EK-OLA34-UG | LA34 DECWRITER IV USER GUIDE |
| MP-00754-00 | LA38-GA MAINTENANCE PRINTS |

KIT NAME: LAV11 DOCUMENTS
KIT NUMBER: FB-LAV11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-LAV11-OP | LAV11 USERS MANUAL |
| MP-00466-00 | LPV11-P MAINTENANCE PRINTS |

KIT NAME: LK40 DOCUMENTS
KIT NUMBER: FB-LK40

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-LK40B-TM | LK40 TECHNICAL MANUAL |
| EK-OLK40-IP | LK40 IPB |
| MP-LK40-00 | LK40 MAINTENANCE PRINTS |

KIT NAME: LP25 DOCUMENTS
KIT NUMBER: FB-LP25

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| MP-00864-00 | LP25 MAINTENANCE PRINTS |

KIT NAME: LPA11-K DOCUMENTS
KIT NUMBER: FB-LPA11-K

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-LPA11-IN | LPA11-K INSTL & MAINTENANCE |
| EK-LPA11-UG | LPA11-K USER GUIDE |
| MP-00479-00 | LPA11-K MAINTENANCE PRINTS |

KIT NAME: LPC01 DOCUMENTS
KIT NUMBER: FB-LPC01

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-LPC01-MM | LPC01 MAINTENANCE MANUAL |
| MP-LPC01-00 | LPC01 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **LPD11-A DOCUMENTS**
KIT NUMBER: **FB-LPD11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-LPD11-MM | LPD11 MAINT MANUAL |
| EK-LPD11-OP | LPD11 USER MANUAL |
| MP-LPD11-A | LPD11-A MAINTENANCE PRINTS |

KIT NAME: **M9301 DOCUMENTS**
KIT NUMBER: **FB-M9301**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-M9301-TM | M9301 BOOT TECHNICAL MANUAL |
| MP-00196-00 | M9301 MAINTENANCE PRINTS |

KIT NAME: **LPS11 DOCUMENTS**
KIT NUMBER: **FB-LPS11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-LPS11-MM | LPS11-S MAINTENANCE MANUAL |
| EK-LPS11-OP | LPS11 SYSTEM USER GUIDE |
| MP-LPS11-S | LPS11-S MAINTENANCE PRINTS |

KIT NAME: **M9302 DOCUMENTS**
KIT NUMBER: **FB-M9302**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-M9302-00 | M9302 MAINTENANCE PRINTS |

KIT NAME: **LS120 DOCUMENTS**
KIT NUMBER: **FB-LS120**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-L1218-PS | LS120/LA180 POCKET SV GUIDE |
| EK-LS120-IP | LS120 DECWRITER III IPB |
| EK-LS120-OP | LS120 OPERATORS GUIDE |
| EK-LS120-TM | LS120 DECWRITER III TECH MANUAL |
| EK-LS120-UG | LS120 DECWRITER III USER GUIDE |
| MP-00322-00 | LS120 MAINTENANCE PRINTS |

KIT NAME: **M9312 DOCUMENTS**
KIT NUMBER: **FB-M9312**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-M9312-TM | M9312 TECHNICAL MANUAL |
| MP-00617-00 | M9312 MAINTENANCE PRINTS |

KIT NAME: **MA780 DOCUMENTS**
KIT NUMBER: **FB-MA780**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-MA780-TD | MA780 TECHNICAL DESCRIPTION |
| MP-00826-00 | MA780 MAINTENANCE PRINTS |

KIT NAME: **M7850 DOCUMENTS**
KIT NUMBER: **FB-M7850**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-M7850-MM | M7850 MAINTENANCE MANUAL |
| MP-M7850-00 | M7850 MAINTENANCE PRINTS |

KIT NAME: **ME11-L DOCUMENTS**
KIT NUMBER: **FB-ME11-L**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-ME11L-OP | ME11-L USER MANUAL |
| EK-ME11L-OP | ME11-L SYSTEM MANUAL |
| MP-ME11-L | ME11-L MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: MF11-L DOCUMENTS
KIT NUMBER: FB-MF11-L

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-MM11S-OP | MM11-S/L/OP USER MANUAL |
| EK-MM11S-TM | MM11-S/L/LP SYSTEM MANUAL |
| MP-MF11-L | MF11-L MAINTENANCE PRINTS |

KIT NAME: MF11S-K DOCUMENTS
KIT NUMBER: FB-MF11S-K

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| MP-00310-00 | MF11-SK MAINTENANCE PRINTS |
| MP-00325-00 | MS11-K MAINTENANCE PRINTS |

KIT NAME: MF11-LP DOCUMENTS
KIT NUMBER: FB-MF11-LP

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-MM11S-OP | MM11-S/L/OP USER MANUAL |
| EK-MM11S-TM | MM11-S/L/LP SYSTEM MANUAL |
| MP-MF11-LP | MF11-LP MAINTENANCE PRINTS |

KIT NAME: MJ11 DOCUMENTS
KIT NUMBER: FB-MJ11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-OMJ11-MM | MJ11 MAINTENANCE MANUAL |
| EK-OMJ11-OP | MJ11 USER MANUAL |
| MP-MJ11-00 | MJ11 MAINTENANCE PRINTS |

KIT NAME: MF11-U DOCUMENTS
KIT NUMBER: FB-MF11-U DOCUMENTS

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-MF11U-MM | MF11-U/UP MAINTENANCE MANUAL |
| MP-MF11-UP | MF11-U/UP MAINTENANCE PRINTS |

KIT NAME: MK11 DOCUMENTS
KIT NUMBER: FB-MK11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-OMK11-MC | MK11 MAINTENANCE CARD |
| EK-OMK11-TM | MK11 TECH MANUAL |
| EK-OMK11-UG | MK11 USERS GUIDE |
| MP-00523-00 | MK11 MAINTENANCE PRINTS |

KIT NAME: MF11-WP DOCUMENTS
KIT NUMBER: FB-MF11-WP

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-MF11W-MM | MF11-W/WP MAINTENANCE MANUAL |
| EK-MF11W-OP | MF11-W/WP USER MANUAL |
| MP-00034-00 | MF11-W/WP MAINTENANCE PRINTS |

KIT NAME: ML11 DOCUMENTS
KIT NUMBER: FB-ML11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-OML11-UG | ML11 USERS GUIDE |
| EK-OML11-TM | ML11 TECHNICAL MANUAL |
| EK-OML11-TD | ML11 TECHNICAL DESCRIPTION |

KIT NAME: MM11-CP DOCUMENTS
KIT NUMBER: FB-MM11-CP

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EK-MM11C-TM | MM11-C/CP MANUAL (INCL MM11-B/BP) |
| MP-MM11-00 | MM11-C MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **MM11-DP DOCUMENTS**
KIT NUMBER: **FB-MM11-DP**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-MM11D-OP | MM11-D/DP USER MANUAL |
| EK-MM11D-TM | MM11-D/DP TECHNICAL MANUAL |
| MP-00032-00 | MM11-DP MAINTENANCE PRINTS |

KIT NAME: **MM11-LP DOCUMENTS**
KIT NUMBER: **FB-MM11-LP**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-MM11S-OP | MM11-S/L/OP USER MANUAL |
| EK-MM11S-TM | MM11-S/L/LP SYSTEM MANUAL |
| MP-MM11-LP | MM11-LP MAINTENANCE PRINTS |

KIT NAME: **MM11-E DOCUMENTS**
KIT NUMBER: **FB-MM11-E**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-MM11E-OP | MM11-E USER MANUAL |
| EK-MM11E-TM | MM11-E TECHNICAL MANUAL |
| MP-MM11-E | MM11-E MAINTENANCE PRINTS |

KIT NAME: **MM11-S DOCUMENTS**
KIT NUMBER: **FB-MM11-S**

CONTENTS

| PART NUMBER | DESCRIPTION |
|--------------|---------------------------|
| EK-MM11S-OP | MM11-S/L/OP USER MANUAL |
| EK-MM11S-TEM | MM11-S/L/LP SYSTEM MANUAL |
| MP-MM11-S | MM11-S MAINTENANCE PRINTS |

KIT NAME: **MM11-F DOCUMENTS**
KIT NUMBER: **FB-MM11-F**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-MM11F-OP | MM11-F USER MANUAL |
| MP-MM11-F | MM11-F MAINTENANCE PRINTS |

KIT NAME: **MM11-U DOCUMENTS**
KIT NUMBER: **FB-MM11-U DOCUMENTS**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-MF11U-MM | MF11-U/UP MAINTENANCE MANUAL |
| MP-MM11-UP | MM11-U/UP MAINTENANCE PRINTS |

KIT NAME: **MM11-L DOCUMENTS**
KIT NUMBER: **FB-MM11-L**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-MM11S-OP | MM11-S/L/OP USER MANUAL |
| EK-MM11S-TM | MM11-S/L/LP SYSTEM MANUAL |
| MP-MM11-L | MM11-L MAINTENANCE PRINTS |

KIT NAME: **MM11-WP DOCUMENTS**
KIT NUMBER: **FB-MM11-WP**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-MF11W-MM | MF11-W/WP MAINTENANCE MANUAL |
| EK-MF11W-OP | MF11-W/WP USER MANUAL |
| MP-00034-00 | MF11-W/WP MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **MM11-YP DOCUMENTS**
KIT NUMBER: **FB-MM11-YP**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-MM1YP-TM | MM11-YP TECH MANUAL |
| EK-MM1YP-UG | MM11-YP USERS MANUAL |
| MP-00317-00 | MM11-YP MAINTENANCE PRINTS |

KIT NAME: **MM8-EJ DOCUMENTS**
KIT NUMBER: **FB-MM8-EJ**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-MM8-E | MM8-E MAINTENANCE PRINTS |

KIT NAME: **MMV11-A DOCUMENTS**
KIT NUMBER: **FB-MMV11-A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| MP-MMV11-A | MMV11-A MAINTENANCE PRINTS |

KIT NAME: **MRV11-AA DOCUMENTS**
KIT NUMBER: **FB-MRV11-AA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00066-00 | MRV11 MAINTENANCE PRINTS |

KIT NAME: **MRV11-AC DOCUMENTS**
KIT NUMBER: **FB-MRV11-AC**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| MP-00387-00 | MRV11-AC MAINTENANCE PRINTS |

KIT NAME: **MRV11-BA DOCUMENTS**
KIT NUMBER: **FB-MRV11-BA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| MP-00354-00 | MRV11-BA MAINTENANCE PRINTS |

KIT NAME: **MRV11-BC DOCUMENTS**
KIT NUMBER: **FB-MRV11-BC**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| MP-00355-00 | MRV11-BC MAINTENANCE PRINTS |

KIT NAME: **MRV11-C DOCUMENTS**
KIT NUMBER: **FB-MRV11-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| MP-00871-00 | MRV11-C MAINTENANCE PRINTS |

KIT NAME: **MRV11-VA DOCUMENTS**
KIT NUMBER: **FB-MRV11-VA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| MP-00208-00 | MRV11-VA MAINTENANCE PRINTS |

KIT NAME: **MRV11-VC DOCUMENTS**
KIT NUMBER: **FB-MRV11-VC**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| MP-00632-00 | MRV11-VC MAINTENANCE PRINTS |

KIT NAME: **MS11-AP DOCUMENTS**
KIT NUMBER: **FB-MS11-AP**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-MS11A-MM | MS11-A/B/C MAINTENANCE MANUAL |
| EK-MS11A-OP | MS11-A/B/C USER MANUAL |
| MP-00708-00 | MS11-A MAINTENANCE PRINTS |

KIT NAME: **MS11-B DOCUMENTS**
KIT NUMBER: **FB-MS11-B**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-MS11A-MM | MS11-A/B/C MAINTENANCE MANUAL |
| EK-MS11A-OP | MS11-A/B/C USER MANUAL |
| MP-MS11-B | MS11-B MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: MS11-CC DOCUMENTS
KIT NUMBER: FB-MS11-CC

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------|
| EK-MS11A-MM | MS11-A/B/C MAINTENANCE MANUAL |
| EK-MS11A-OP | MS11-A/B/C USER MANUAL |
| MP-MS11-C | MS11-C MAINTENANCE PRINTS |

KIT NAME: MS11-FP DOCUMENTS
KIT NUMBER: FB-MS11-FP

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-MS11E-MM | MS11-E/J MAINTENANCE MANUAL |
| EK-MS11E-OP | MS11-E/J MOS MEMORY USER MANUAL |
| MP-00021-00 | MS11-E MAINTENANCE PRINTS |

KIT NAME: MS11-K DOCUMENTS
KIT NUMBER: FB-MS11-K

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| MP-00325-00 | MS11-K MAINTENANCE PRINTS |

KIT NAME: MS11-L DOCUMENTS
KIT NUMBER: FB-MS11-L

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-MS11L-TM | MS11-L TECH MANUAL |
| EK-MS11L-UG | MS11-L USERS GUIDE |
| MP-00672-00 | MS11-L MAINTENANCE PRINTS |

KIT NAME: MS11-M DOCUMENTS
KIT NUMBER: FB-MS11-M

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-MS11M-TM | MS750 TECHNICAL DESCRIPTION |
| EK-MS11M-UG | MS11-M USER GUIDE |
| MP-00742-00 | MS11-M MAINTENANCE PRINTS |

KIT NAME: MS750 DOCUMENTS
KIT NUMBER: FB-MS750

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-MS750-TD | MS750 TECHNICAL DESCRIPTION |

KIT NAME: MS780 DOCUMENTS
KIT NUMBER: FB-MS780

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-MS780-TD | MS780 TECH DESCRIPTION |
| MP-00498-00 | MS780 MAINTNANCE PRINTS |

KIT NAME: MSV11-B DOCUMENTS
KIT NUMBER: FB-MSV11-B

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| MP-00067-00 | MSV11-B MAINTENANCE PRINTS |

KIT NAME: MSV11-C DOCUMENTS
KIT NUMBER: FB-MSV11-C

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| MP-00259-00 | MSV11-C MAINTENANCE PRINTS |

KIT NAME: MSV11-D DOCUMENTS
KIT NUMBER: FB-MSV11-D

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-MSV1D-OP | MSV11-D/E USER MANUAL |
| MP-00566-00 | MSV11-D MAINTENANCE PRINTS |

KIT NAME: MSV11-E DOCUMENTS
KIT NUMBER: FB-MSV11-E

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-MSV1D-OP | MSV11-D/E USER MANUAL |
| MP-00567-00 | MSV11-E MAINTENANCE PRINTS |

OPTION LEVEL KITS

**KIT NAME: MSV11-P
DOCUMENTATION KIT**
KIT NUMBER: FB-MSV11-P

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------|
| EK-MSVOP-UG | MSV11-P USER GUIDE |
| MP-01239-00 | MSV11-P MAINTENANCE PRINTS |

KIT NAME: PC05 DOCUMENTS
KIT NUMBER: FB-PC05

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-OPC05-IP | PC05 READER PUNCH IPB |
| EK-PC045-OP | PC04/05 USER MANUAL |
| EK-PC405-MM | PC04/05 MAINT MANUAL |
| MP-PC04-05 | PC04/05 MAINTENANCE PRINT |

KIT NAME: PC11 DOCUMENTS
KIT NUMBER: FB-PC11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------|
| EK-OPC11-OP | PC11 USERS MANUAL |
| EK-OPC11-TM | PC11 SYSTEM MANUAL |
| MP-PC11 | PC11 MAINTENANCE PRINT |

KIT NAME: PDP8A DOCUMENTS
KIT NUMBER: FB-PDP8A

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EB-06219-76 | PDP8A MINICOMPUTER HDBK |
| EK-8A000-IP | PDP8A IPB |
| EK-8A001-OP | PDP8A OPERATORS HDBK |
| EK-8A002-MM | PDP8A MAINT MANUAL |
| MP-PDP8A-00 | PDP8A MAINTENANCE PRINT |

KIT NAME: PDP8E DOCUMENTS
KIT NUMBER: FB-PDP8E

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EB-02546-76 | SMALL COMPUTER HDBK (8E/F/M) |
| EK-8E001-MM | PDP8E/F/M MAINT MAN VOL I |
| EK-8E002-MM | PDP8E/F/M MAINT MAN VOL II |
| EK-8E003-MM | PDP8E/F/M MAINT MAN VOL III |
| EK-PDP8E-IP | PDP8E IPB |
| MP-00162-00 | PDP8E MAINTENANCE PRINTS |

KIT NAME: PDP8F DOCUMENTS
KIT NUMBER: FB-PDP8F

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EB-02546-76 | SMALL COMPUTER HDBK (8E/F/M) |
| EK-8E001-MM | PDP8E/F/M MAINT MAN VOL I |
| EK-8E002-MM | PDP8E/F/M MAINT MAN VOL II |
| EK-8E003-MM | PDP8E/F/M MAINT MAN VOL III |
| MP-PDP8F-00 | PDP8F MAINTENANCE PRINT |

KIT NAME: PDP8M DOCUMENTS
KIT NUMBER: FB-PDP8M

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EB-02546-76 | SMALL COMPUTER HDBK (8E/F/M) |
| EK-8E001-MM | PDP8E/F/M MAINT MAN VOL I |
| EK-8E002-MM | PDP8E/F/M MAINT MAN VOL II |
| EK-8E003-MM | PDP8E/F/M MAINT MAN VOL III |
| EK-PDP8M-IP | PDP8M IPB |
| MP-PDP8M-00 | PDP8M MAINTENANCE PRINT |

OPTION LEVEL KITS

KIT NAME: PRS01 DOCUMENTS
KIT NUMBER: FB-PRS01

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-PRS01-MM | PRS01 MAINTENANCE MANUAL |
| MP-00232-00 | PRS01 MAINTENANCE PRINT |

KIT NAME: RH780 DOCUMENTS
KIT NUMBER: FB-RH780

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-RH780-TD | RH780 TECHNICAL DESCRIPTION |
| MP-00499-00 | RH780 MAINTENANCE PRINT |

KIT NAME: RA80 DOCUMENTS
KIT NUMBER: FB-RA80

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------|
| EK-ORA80-UG | RA80 USERS GUIDE |
| MP-01286-00 | RA80 MAINTENANCE PRINT |

KIT NAME: RK05 DOCUMENTS
KIT NUMBER: FB-RK05F

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-ORK05-OP | RK05 USERS MANUAL |
| EK-RK5JF-MM | RK05/J/F MAINTENANCE MANUAL |
| MP-RK05-F | RK05-F MAINTENANCE PRINT |

KIT NAME: REV11 DOCUMENTS
KIT NUMBER: FB-REV11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00073-00 | REV11 MAINT PRINT VOL I |
| MP-00331-00 | REV11 MAINT PRINT VOL II |

KIT NAME: RK05J DOCUMENTS
KIT NUMBER: FB-RK05J

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-ORK05-OP | RK05 USERS MANUAL |
| EK-RK5JF-MM | RK05/J/F MAINTENANCE MANUAL |
| MP-RK05-J | RK05-J MAINTENANCE PRINT |

KIT NAME: RH11 DOCUMENTS
KIT NUMBER: FB-RH11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------|
| MP-00382-00 | RH11 MAINTENANCE PRINT |

KIT NAME: RK06 DOCUMENTS
KIT NUMBER: FB-RK06

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-ORK06-IP | RK06 IPB |
| EK-RK067-SV | RK06/07 SERVICE MANUAL |
| EK-RK067-TD | RK06/07 TECHNICAL MANUAL |
| EK-RK067-UG | RK06/07 USERS GUIDE |
| MP-00182-00 | RK06 MAINTENANCE PRINT |

KIT NAME: RH70 DOCUMENTS
KIT NUMBER: FB-RH70

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------|
| MP-RH70 | RH70 MAINTENANCE PRINT |

KIT NAME: RH750 DOCUMENTS
KIT NUMBER: FB-RH750

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| MP-01045-00 | RH750 MAINTENANCE PRINT |

OPTION LEVEL KITS

KIT NAME: **RK07 DOCUMENTS**
KIT NUMBER: **FB-RK07**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-ORK07-IP | RK07 IPB |
| EK-RK067-SV | RK06/07 SERVICE MANUAL |
| EK-RK067-TD | RK06/07 TECHNICAL MANUAL |
| EK-RK067-UG | RK06/07 USERS GUIDE |
| MP-00576-00 | RK07 MAINTENANCE PRINT |

KIT NAME: **RK11-C DOCUMENTS**
KIT NUMBER: **FB-RK11-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-RK11C-OP | RK11-C USERS MANUAL |
| EK-RK11C-TM | RK11-C TECHNICAL MANUAL |
| MP-RK11-C | RK11-C MAINTENANCE PRINT |

KIT NAME: **RK11-D/E DOCUMENTS**
KIT NUMBER: **FB-RK11-D**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-RK11D-MM | RK11-D MAINTENANCE MANUAL |
| EK-RK11D-OP | RK11-D USERS MANUAL |
| MP-RK11-D | RK11-D MAINTENANCE PRINT |

KIT NAME: **RK611 DOCUMENTS**
KIT NUMBER: **FB-RK611**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-RK611-IP | RK611 IPB |
| EK-RK611-TM | RK611 TECHNICAL MANUAL |
| MP-00105-00 | RK611 MAINTENANCE PRINT |

KIT NAME: **RKV11-D DOCUMENTS**
KIT NUMBER: **FB-RKV11-D**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-RKV11-OP | RKV11-D USERS MANUAL |
| MP-00223-00 | RKV11-D MAINTENANCE PRINT |

KIT NAME: **RL01 DOCUMENTS**
KIT NUMBER: **FB-RL01**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-ORL01-IP | RL01 IPB |
| EK-RL012-PG | RL01/02 POCKET SERVICE GUIDE |
| EK-RL012-TM | RL01/02 TECHNICAL MANUAL |
| EK-RL012-UG | RL01/02 USERS GUIDE |
| MP-00347-00 | RL01 MAINTENANCE PRINT |

KIT NAME: **RL02 DOCUMENTS**
KIT NUMBER: **FB-RL02**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-ORL02-IP | RL02 IPB |
| EK-RL012-PG | RL01/02 POCKET SERVICE GUIDE |
| EK-RL012-TM | RL01/02 TECHNICAL MANUAL |
| EK-RL012-UG | RL01/02 USERS GUIDE |
| MP-00553-00 | RL02 MAINTENANCE PRINT |

KIT NAME: **RL11 DOCUMENTS**
KIT NUMBER: **FB-RL11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------|
| EK-ORL11-TD | RL11 TECHNICAL MANUAL |
| MP-00153-00 | RL11 MAINTENANCE PRINT |

KIT NAME: **RL8A DOCUMENTS**
KIT NUMBER: **FB-RL8A**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-ORL8A-TM | RL8A TECHNICAL MANUAL |
| MP-00538-00 | RL8A/RL28A MAINTENANCE PRINT |

OPTION LEVEL KITS

KIT NAME: RLV11 DOCUMENTS
KIT NUMBER: FB-RLV11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-RLV11-TD | RLV11 TECHNICAL MANUAL |
| MP-00635-00 | RLV11 MAINTENANCE PRINT |

KIT NAME: RLV12 DOCUMENTS
KIT NUMBER: FB-RLV12

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-RLV12-UG | RLV12 USERS GUIDE |
| MP-01282-00 | RLV12 MAINTENANCE PRINT |

KIT NAME: RMO2 DOCUMENTS
KIT NUMBER: FB-RM02

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-ORM02-IP | RM02 IPB |
| EK-RM023-SV | RM02/03 SERVICE MANUAL |
| EK-RM023-UG | RM02/03 USERS GUIDE |
| EK-RMADA-TD | RM MASSBUS ADAPTER TECH MAN |
| ER-ORM02-MP | RM02 MAINTENANCE PRINT |
| ER-ORM02-TM | RM02 TECHNICAL MANUAL |
| MP-00456-00 | RM02 MAINTENANCE PRINT |

KIT NAME: RM03 DOCUMENTS
KIT NUMBER: FB-RM03

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-ORM03-IP | RM03 IPB |
| EK-RM023-SV | RM02/03 SERVICE MANUAL |
| EK-RM023-UG | RM02/03 USERS GUIDE |
| EK-RMADA-TD | RM MASSBUS ADAPTER TECH MAN |
| ER-ORM03-MP | RM03 MAINTENANCE PRINT |
| ER-ORM03-TM | RM03 TECHNICAL MANUAL |
| MP-00350-00 | RM03 MAINTENANCE PRINT |

KIT NAME: RM05 DOCUMENTS
KIT NUMBER: FB-RM05

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------|
| EK-ORM05-SV | RM05 SERVICE MANUAL |
| EK-ORM05-IP | RM05 IPB |
| EK-ORM05-UG | RM05 USERS GUIDE |

KIT NAME: RM80 DOCUMENTS
KIT NUMBER: FB-RM80

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------|
| EK-ORM80-TD | RM80 TECHNICAL MANUAL |
| EK-ORM80-UG | RM80 USERS GUIDE |
| EK-ORM80-IP | RM80 IPB |
| EK-ORM80-SV | RM80 SERVICE MANUAL |
| EK-ORM80-PG | RM80 POCKET GUIDE |
| MP-00875-00 | RM80 MAINTENANCE PRINT |

KIT NAME: RP04 DOCUMENTS
KIT NUMBER: FB-RP04

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-ORP04-IN | RP04 INSTALLATION MANUAL |
| EK-ORP04-IP | RP04 IPB |
| EK-ORP04-MM | RP04 MAINTENANCE MANUAL |
| EK-ORP04-OP | RP04 USERS GUIDE |
| MP-00086-00 | RP04/05/06 MAINT PRINT |

KIT NAME: RP05 DOCUMENTS
KIT NUMBER: FB-RP05

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-RP056-IN | RP05/06 INSTALLATION MANUAL |
| EK-RP056-MM | RP05/06 MAINTENANCE MANUAL |
| EK-RP056-OP | RP05/06 USERS MANUAL |
| ER-00012-TM | RP05/06 TECHNICAL MANUAL |
| ER-00014-TM | RP05/06 LOGIC MANUAL |
| MP-00086-00 | RP04/05/06 MAINT PRINT |

OPTION LEVEL KITS

KIT NAME: RP06 DOCUMENTS
KIT NUMBER: FB-RP06

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-RP056-IN | RP05/06 INSTALLATION MANUAL |
| EK-RP056-MM | RP05/06 MAINTENANCE MANUAL |
| EK-RP056-OP | RP05/06 USERS MANUAL |
| ER-00012-TM | RP05/06 TECHNICAL MANUAL |
| ER-00014-TM | RP05/06 LOGIC MANUAL |
| MP-00086-00 | RP04/05/06 MAINT PRINT |

KIT NAME: RPR02 DOCUMENTS
KIT NUMBER: FB-RPR02

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EK-RPR02-IP | RPR02 660-1 DISK DRIVE IPB |
| EK-RPR02-LS | RPR02 660-A LGC SCHEMATIC MANUAL |
| EK-RPR02-TM | RPR02 660-1 TECHNICAL DESC MANUAL |
| ER-00009-TM | RPR02 DISK DRIVE MAINT MANUAL |
| MP-RPR02-00 | RPR02 MAINTENANCE PRINTS |

KIT NAME: RP07 DOCUMENTS
KIT NUMBER: FB-RP07

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| ER-ORP07-IP | RP07 IPB |
| EK-ORP07-IP | RP07 IPB |
| EK-ORP07-PS | RP07 POCKET SERVICE GUIDE |
| ER-ORP07-MP | RP07 MAINTENANCE PRINT |
| ER-ORP07-UG | RP07 USERS GUIDE |
| ER-ORP07-TD | RP07 TECHNICAL MANUAL |

KIT NAME: RX01 DOCUMENTS
KIT NUMBER: FB-RX01

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-13077-IP | 70-13077 FLEXIBLE DISK DRIVE IPB |
| EK-ORX01-IP | RX01 FLP DSK IPB |
| EK-ORX01-MM | RX8/RX11 FLP DISK SYSTEM |
| EK-ORX01-OP | RX8/RX11 FLOPPY DISK SYSTEM |
| EK-RX012-PS | RX01/RX02 POCKET SERVICE GUIDE |
| EK-RX102-RC | RX01/02 REFERENCE CARD |
| MP-00296-00 | RX01 MAINTENANCE PRINTS |

KIT NAME: RP11-C DOCUMENTS
KIT NUMBER: FB-RP11-C

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------|
| EK-RP11C-MM | RP11-C MAINTENANCE MANUAL |
| EK-RP11C-OP | RP11-C USERS MANUAL |
| MP-RP11-C | RP11-C MAINTENANCE PRINT |

KIT NAME: RX02 DOCUMENTS
KIT NUMBER: FB-RX02

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------------|
| EK-13077-IP | 70-13077 FLEXIBLE DISK DRIVE IPB |
| EK-ORX02-IP | RX02 FLOPPY DISK IPB |
| EK-ORX02-TM | RX02 FLOPPY DISK SYSTEM TECH MAN |
| EK-ORX02-UG | RX02 FLOPPY DISK SYSTEM USER GUIDE |
| EK-RX012-PS | RX01/02 REFERENCE CARD |
| MP-00629-00 | RX02 MAINTENANCE PRINTS |

KIT NAME: RP11-E DOCUMENTS
KIT NUMBER: FB-RP11-E

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-RP11E-IN | RP11-E/RPR02 INSTALLATION MANUAL |
| EK-RP11E-MM | RP11-E MAINTENANCE MANUAL |
| EK-RP11E-OP | RP11-E USER MANUAL |
| MP-RP11-E | RP11-E MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: RX11 DOCUMENTS
KIT NUMBER: FB-RX11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| MP-ORX11-00 | RX11 MAINTENANCE PRINTS |

KIT NAME: RX211 DOCUMENTS
KIT NUMBER: FB-RX211

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00626-00 | RX211 MAINTENANCE PRINTS |

KIT NAME: RX8 DOCUMENTS
KIT NUMBER: FB-RX8

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------|
| MP-RX8-00 | RX8 MAINTENANCE PRINTS |

KIT NAME: SM/SN RXMMX-B DOC KIT
KIT NUMBER: FB-RXMM2-B

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EB-18451-20 | MICROCOMPUTER & MEMORIES HNDBK |
| EB-20175-20 | MICROCOMPUTER INTERFACES HDBK |
| EB-20752-20 | TT & COMM HDBK |
| EK-00874-IP | 874 POWER CTRL IPB |
| EK-23BMB-TM | PDP11/23B MOUNT BOX TECH MAN |
| EK-23BMB-UG | PDP11/23B MOUNT BOX USER GUIDE |
| EK-KDFEB-UG | KDF11-B USER GUIDE |
| EK-MSVOP-UG | MSV11-P USER GUIDE |
| EK-ORL02-IP | RL02 DSK DR IPB |
| EK-RL012-PG | RL01/02 POCKET SV GUIDE |
| EK-RL012-TM | RL01/02 DISK DRIVE TECHNICAL MAN |
| EK-RL012-UG | RL01/RL02 DSK SS USERS GDE |
| EK-VT100-IP | VT100 VIDEO TT IPB |
| EK-VT100-J1 | VT100 MINI MAINT HDW GUIDE |
| EK-VT100-RC | VT100 PROGRAM REF CARD |
| EK-VT100-TM | VT100 TECHNICAL MANUAL |
| EK-VT100-UG | VT100 USER GUIDE |
| MP-00553-00 | RL02 MAINTENANCE PRINT |
| MP-00633-00 | VT100 MAINTENANCE PRINT |
| MP-00779-00 | H9642-B MAINTENANCE PRINT |
| MP-01016-00 | 874 MAINTENANCE PRINT |
| MP-01234-00 | 11/23-B MAINTENANCE PRINT |
| MP-01235-00 | 11T23-B MAINTENANCE PRINT |
| MP-01282-00 | RLV12 MAINTENANCE PRINT |

OPTION LEVEL KITS

KIT NAME: SM/SN RXMMX-C DOC KIT
KIT NUMBER: FB-RXMM2-C

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------------|
| EB-18451-20 | MICROCOMPUTER & MEMORIES HNDBK |
| EB-20175-20 | MICROCOMPUTER INTERFACES HDBK |
| EB-20752-20 | TT & COMM HDBK |
| EK-00874-IP | 874 POWER CTRL IPB |
| EK-23BMB-TM | PDP11/23B MOUNT BOX TECH MAN |
| EK-23BMB-UG | PDP11/23B MOUNT BOX USER GUIDE |
| EK-KDFEB-UG | KDF11-B USER GUIDE |
| EK-LA120-IP | LA120 DECWRITER III IPB |
| EK-LA120-RG | LA120 OPERATOR REF CARD |
| EK-LA120-SV | LA120 POCKET SV GUIDE |
| EK-LA120-TM | LA120 TECHNICAL MANUAL |
| EK-LA120-UG | LA120 USER'S GUIDE |
| EK-MSVOP-UG | MSV11-P USERS GUIDE |
| EK-ORL02-IP | RL02 DSK DR IPB |
| EK-RL012-PG | RL01/02 POCKET SV GUIDE |
| EK-RL012-TM | RL01/02 DSK DR TECHNICAL MAN |
| EK-RL012-UG | RL01/RL02 DSK SS USERS GDE |
| EK-RLV12-UG | RLV12 DKS CTRL USER GUIDE |
| MP-00553-00 | RL02 MAINTENANCE PRINT |
| MP-00633-00 | VT100 MAINTENANCE PRINT |
| MP-00779-00 | H9642-B MAINTENANCE PRINT |
| MP-01016-00 | 874 MAINTENANCE PRINT |
| MP-01234-00 | 11/23-B MAINTENANCE PRINT |
| MP-01235-00 | 11T23-B MAINTENANCE PRINT |
| MP-01282-00 | RLV12 MAINTENANCE PRINT |

KIT NAME: DE/DM/DN-RXMMX-B,,D512X-B DOC
KIT NUMBER: FB-RXMM3-B

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------------|
| EB-18451-20 | MICROCOMPUTER & MEMORIES HNDBK |
| EB-20175-20 | MICROCOMPUTER INTERFACES HDBK |
| EB-20752-20 | TT & COMM HDBK |
| EK-00874-IP | 874 POWER CTRL IPB |
| EK-23BMB-TM | PDP11/23B MOUNT BOX TECH MAN |
| EK-23BMB-UG | PDP11/23B MOUNT BOX USER GUIDE |
| EK-DZV11-TM | DZV11 ASYNCH MULTI TECH MAN |
| EK-DZV11-UG | DZV11 ASYNCH MTLPTX GUIDE & AD |
| EK-FPF11-TM | FPF11 FP PROC TECH |
| EK-KDFEB-UG | KDF11-B USER GUIDE |
| EK-MSVOP-UG | MSV11-P USERS GUIDE |
| EK-ORL02-IP | RL02 DSK DR IPB |
| EK-RL012-PG | RL01/02 POCKET SV GUIDE |
| EK-RL012-TM | RL01/02 DSK DR TECHNICAL MAN |
| EK-RL012-UG | RL01/RL02 DSK SS USERS GDE |
| EK-RLV12-UG | RLV12 DKS CTRL USER GUIDE |
| EK-VT100-IP | VT100 VIDEO TT IPB |
| EK-VT100-J1 | VT100 MINI MAINT HDW GUIDE |
| EK-VT100-RC | VT100 PROGRAM REF CARD |
| EK-VT100-TM | VT100 TECHNICAL MANUAL |
| EK-VT100-UG | VT100 USER GUIDE |
| MP-00462-00 | DZV11 MAINTENANCE PRINT |
| MP-00553-00 | RL02 MAINTENANCE PRINT |
| MP-00633-00 | VT100 MAINTENANCE PRINT |
| MP-00779-00 | H9642-B MAINTENANCE PRINT |
| MP-01016-00 | 874 MAINTENANCE PRINT |
| MP-01234-00 | 11/23-B MAINTENANCE PRINT |
| MP-01235-00 | 11T23-B MAINTENANCE PRINT |
| MP-01282-00 | RLV12 MAINTENANCE PRINT |

OPTION LEVEL KITS

KIT NAME: **DE/DM/DN-RXMMX-C,
D512X-A DOC**
KIT NUMBER: **FB-RXMM3-C**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------------|
| EB-18451-20 | MICROCOMPUTER & MEMORIES HNDKB |
| EB-20175-20 | MICROCOMPUTER INTERFACES HDBK |
| EB-20752-20 | TT & COMM HDBK |
| EK-00874-IP | 874 POWER CTRL IPB |
| EK-23BMB-TM | PDP11/23B MOUNT BOX TECH MAN |
| EK-23BMB-UG | PDP11/23B MOUNT BOX USER GUIDE |
| EK-DZV11-TM | DZV11 ASYNCH MULTI TECH MAN |
| EK-DZV11-UG | DZV11 ASYNCH MTLPSR GUIDE & AD |
| EK-FPF11-TM | FPF11 FP PROC TECH |
| EK-KDFEB-UG | KDF11-B USER GUIDE |
| EK-LA120-IP | LA120 DECWRITER III IPB |
| EK-LA120-RG | LA120 OPERATOR REF CARD |
| EK-LA120-SV | LA120 POCKET SV GUIDE |
| EK-LA120-TM | LA120 TECHNICAL MANUAL |
| EK-LA120-UG | LA120 USER'S GUIDE |
| EK-MSVOP-UG | MSV11-P USERS GUIDE |
| EK-ORL02-IP | RL02 DSK DR IPB |
| EK-RL012-PG | RL01/02 POCKET SV GUIDE |
| EK-RL012-TM | RL01/02 DSK DR TECHNICAL MAN |
| EK-RL012-UG | RL01/RL02 DSK SS USERS GDE |
| EK-RLV12-UG | RLV12 DKS CTRL USER GUIDE |
| EK-00462-00 | DZV11 MAINTENANCE PRINT |
| MP-00553-00 | RL02 MAINTENANCE PRINT |
| MP-00633-00 | VT100 MAINTENANCE PRINT |
| MP-00779-00 | H9642-B MAINTENANCE PRINT |
| MP-01016-00 | 874 MAINTENANCE PRINT |
| MP-01234-00 | 11/23-B MAINTENANCE PRINT |
| MP-01235-00 | 11T23-B MAINTENANCE PRINT |
| MP-01282-00 | RLV12 MAINTENANCE PRINT |

KIT NAME: **RXV11 DOCUMENTS**
KIT NUMBER: **FB-RXV11**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| EK-RXV11-OP | RXV-11 USER MANUAL |
| MP-00024-00 | RXV11 MAINTENANCE PRINTS |

KIT NAME: **RXV21 DOCUMENTS**
KIT NUMBER: **FB-RXV21**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00628-00 | RXV21 MAINTENANCE PRINTS |

KIT NAME: **TE10N DOCUMENTS**
KIT NUMBER: **FB-TE10N**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-OTE16-TM | TE16/TE10W/TE10N MAINTENANCE MAN |
| EK-OTEWN-OP | TE16/TE10W/TE10N USERS MANUAL |
| MP-00364-00 | TE10-N MAINTENANCE PRINTS |

KIT NAME: **TE10W DOCUMENTS**
KIT NUMBER: **FB-TE10W**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-OTE16-TM | TE16/TE10W/TE10N MAINTENANCE MAN |
| EK-OTEWN-OP | TE16/TE10W/TE10N USERS MANUAL |
| MP-00336-00 | TE10-W MAINTENANCE PRINTS |

KIT NAME: **TE16 DOCUMENTS**
KIT NUMBER: **FB-TE16**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-OTE16-IP | TE16 DOC MAGTAPE IPB |
| EK-OTE16-TM | TE16/TE10W/TE10N MAINTENANCE MAN |
| EK-OTEWN-OP | TE16/TE10W/TE10N USERS MANUAL |
| MP-00333-00 | TE16 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: TEV11 DOCUMENTS
KIT NUMBER: FB-TEV11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------|
| MP-00074-00 | TEV11 MAINTENANCE PRINTS |

KIT NAME: TM02 DOCUMENTS
KIT NUMBER: FB-TM02

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-OTM02-IP | TM02 FMTR IPB |
| EK-OTU16-MM | TU16/TM02 MAINTENANCE MANUAL |
| EK-OTU16-OP | TU16/TM02 USER MANUAL |
| MP-OTM02-00 | TM02 MAINTENANCE PRINTS |

KIT NAME: TM03 DOCUMENTS
KIT NUMBER: FB-TM03

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-OTM03-IP | TM03 FORMATTER IPB |
| EK-OTM03-TM | TM03 TECH MANUAL |
| EK-OTM03-UG | TM03 USER GUIDE |
| MP-00349-00 | TM03 MAINTENANCE PRINTS |

KIT NAME: TM78 DOCUMENTS
KIT NUMBER: FB-TM78

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------|
| EK-OTM78-TM | TM78 TECHNICAL MANUAL |
| EK-OTM78-UG | TM78 USERS GUIDE |

KIT NAME: TS11/TS04 DOCUMENTS
KIT NUMBER: FB-TS11

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-OTS11-PS | TS11 POCKET SERVICE GUIDE |
| EK-OTS11-TM | TS11 SUBSYSTEM TECHNICAL MANUAL |
| EK-OTS11-UG | TS11 SUBSYSTEM USERS GUIDE |
| EK-TS11A-IP | TS11-A IPB |
| MP-00849-00 | TS11-A MAINTENANCE PRINTS |

KIT NAME: TU16 DOCUMENTS
KIT NUMBER: FB-TU16

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-OTU16-IP | TU16 DEC MAGTAPE IPB |
| EK-OTU16-MM | TU16/TM02 MAINTENANCE MANUAL |
| EK-OTU16-OP | TU16/TM02 USERS MAN |
| MP-OTU16-00 | TU16-A MAINTENANCE PRINTS |

KIT NAME: TU45 DOCUMENTS
KIT NUMBER: FB-TU45

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-45/03-MM | TU45-A/C/TAU45/TM03 MAINT MANUAL |
| EK-TU45A-MM | TU45 SYSTEM MANUAL |
| MP-00441-00 | TU45 MAINTENANCE PRINTS |

KIT NAME: TU58 DOCUMENTS
KIT NUMBER: FB-TU58

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-OTU58-IP | TU58 IPB |
| EK-OTU58-PS | TU58 POCKET SERVICE GUIDE |
| EK-OTU58-TM | TU58 TECHNICAL MANUAL |
| EK-OTU58-UG | TU58 DECTAPE II USERS GUIDE |
| MP-00747-00 | TU58-C MAINTENANCE PRINTS |

KIT NAME: TU77 DOCUMENTS
KIT NUMBER: FB-TU77

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|----------------------------------|
| EK-ITU77-TM | TU77 MAGNETIC TAPE TRANSPORT V1 |
| EK-2TU77-TM | TU77 MAGTAPE TECHNICAL MANUAL V2 |
| EK-OTU77-IP | TU77 MAGNETIC TAPE TRANSPORT IPB |
| EK-OTU77-UG | TU77 MAG TAPE TRANSPORT |
| MP-00644-00 | TU77 MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: TU78 DOCUMENTS
KIT NUMBER: FB-TU78

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| EK-OTU78-UG | TU78 USERS GUIDE |
| EK-OTU78-PS | TU78 POCKET SERVICE GUIDE |
| EK-1TU78-TM | TU78 TECHNICAL MANUAL VOL 1 |
| EK-2TU78-TM | TU78 TECHNICAL MANUAL VOL 2 |
| MP-01061 | TU78 MAINTENANCE PRINTS |

KIT NAME: UDA50 DOCUMENTS
KIT NUMBER: FB-UDA50

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------|
| EK-UDA50-SV | UDA50 SERVICE MANUAL |
| EK-UDA50-UG | UDA50 USERS GUIDE |
| MP-01331-00 | UDA50 MAINTENANCE PRINT |

KIT NAME: VK100 (GIGI) DOCUMENTS
KIT NUMBER: FB-VK100

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-OGIGI-RC | GIGI PROGRAMMING REFERENCE CARD |
| EK-VK100-RC | VK100 SET-UP REFERENCE CARD |
| EK-VK100-PS | VK100 POCKET SERVICE GUIDE |
| EK-VK100-IN | VK100 INSTALLATION MANUAL |

KIT NAME: VT100 DOCUMENTS
KIT NUMBER: FB-VT100

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--|
| EB-20752-20 | TERMINALS & COMM HANDBOOK |
| EK-VT100-IP | VT100 IPB |
| EK-VT100-J1 | VT100 MINI MAINTENANCE HDANCE HDWR GUIDE |
| EK-VT100-RC | VT100 PROGRAM REFERENCE CARD |
| EK-VT100-TM | VT100 TECHNICAL MANUAL |
| EK-VT100-UG | VT100 USERS GUIDE |
| MP-00633-00 | VT100 MAINTENANCE PRINTS |

KIT NAME: VT101 DOCUMENTS
KIT NUMBER: FB-VT101

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EK-VT101-UG | VT101 USERS GUIDE |
| EK-VT101-RC | VT101 PROGRAMMING REF CARD |
| EK-VT101-IP | VT101 ILLUSTRATED PARTS BREAKDOWN |
| MP-01066 | VT101 MAINTENANCE PRINTS |

KIT NAME: VT102 DOCUMENTS
KIT NUMBER: FB-VT102

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EK-VT102-IP | VT102 ILLUSTRATED PARTS BREAKDOWN |
| EK-VT102-RC | VT102 PROGRAMMING REF CARD |

KIT NAME: VT1XX-AB DOCUMENTS
KIT NUMBER: FB-VT1XX-AB

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------|
| MP-VT1XX-AB | VT1XX-AB MAINTENANCE PRINTS |

OPTION LEVEL KITS

KIT NAME: **VT1XX-AC DOCUMENTS**
KIT NUMBER: **FB-VT1XX-AC**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|--------------------------------|
| EK-VT1AC-UG | VT1XX-AC USERS GUIDE |
| MP-00901-00 | VT1XX-AC MAINTENANCE PRINTS |

KIT NAME: **VT1XX-CA DOUCMENTS**
KIT NUMBER: **FB-VT1XX-CA**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|---------------------------------|
| EK-VTICA-IN | VT1XX-CA INSTALLATION MANUAL |

KIT NAME: **VT50 DOCUMENTS**
KIT NUMBER: **FB-VT50**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-----------------------------------|
| EK-OVT50-TM | VT50 SYSTEM MANUAL |
| EK-VT502-PG | VT50/VT52 POCKET SERVICE GUIDE |
| MP-00036-00 | VT50 MAINTENANCE PRINTS |

KIT NAME: **VT52 DOCUMENTS**
KIT NUMBER: **FB-VT52**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|-------------------------------------|
| EK-OVT52-IP | VT52 DECSCOPE IPB |
| EK-OVT52-MM | VT52 DECSCOPE MAINTENANCE MANUAL |
| EK-VT502-PG | VT50/VT52 POCKET SERVICE GUIDE |
| MP-00035-00 | VT52 MAINTENANCE PRINTS |

KIT NAME: **VT55 DOCUMENTS**
KIT NUMBER: **FB-VT55**

CONTENTS

| PART NUMBER | DESCRIPTION |
|-------------|------------------------------|
| EK-VT55E-TM | VT55-E/F/H/J USERS MANUAL |
| MP-00098-00 | VT55 MAINTENANCE PRINTS |

Package Systems Matrices

| | FB-BAT1-N | FB-BDV11 | FB-DLV11-J | FB-H9610 | FB-H9612 | FB-H9642 | FB-KD11-HA | FB-KEY11 | FB-LA120 | FB-LA38 | FB-MSV11-D | FB-RL01 | FB-RLV11 | FB-RX02 | FB-RXV21 | FB-VT100 |
|-------------|-----------|----------|------------|----------|----------|----------|------------|----------|----------|---------|------------|---------|----------|---------|----------|----------|
| SR-VXLLB-AA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-AD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-AK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-AN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-BD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-BK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-BN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLB-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-AA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-AD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-AK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-AN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-BD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-BK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-BN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXLLC-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-VXSSB-AA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |

| | FB-00871 | FB-11/23 | FB-BA11-N | FB-BD11 | FB-DL11-J | FB-H9610 | FB-H9612 | FB-H9642 | FB-LA120 | FB-LA38 | FB-MSV11-D | FB-RL01 | FB-RL02 | FB-RLV11 | FB-RX02 | FB-RXV21 | FB-VT100 |
|--------------|----------|----------|-----------|---------|-----------|----------|----------|----------|----------|---------|------------|---------|---------|----------|---------|----------|----------|
| SM-WXLLA-AA | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-AD | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-AK | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-AN | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-BA | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-BD | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-BK | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-BN | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-CA | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-CD | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-CK | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLA-CN | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-AA | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-AD | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-AK | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-AN | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-BA | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-BD | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-BK | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-BN | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-CA | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-CD | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-CK | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXLLB-CN | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |
| SM-WXMMMA-AA | ● | ● | ● | ● | ● | ● | | | | | | | | | | | |

| Model | SM-WXMMMA-AD | SM-WXMMMA-AK | SM-WXMMMA-AN | SM-WXMMMA-BA | SM-WXMMMA-BD | SM-WXMMMA-BK | SM-WXMMMA-BN | SM-WXMMMA-CA | SM-WXMMMA-CD | SM-WXMMMA-CK | SM-WXMMMA-CN | SM-WXMMB-AA | SM-WXMMB-AD | SM-WXMMB-AK | SM-WXMMB-AN | SM-WXMMB-BA | SM-WXMMB-BD | SM-WXMMB-BK | SM-WXMMB-BN | SM-WXMMB-CA | SM-WXMMB-CD | SM-WXMMB-CK | SM-WXMMB-CN | SP-WXLLA-AA | SP-WXLLA-AK |
|------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|--------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| FB-00871 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-11/23 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-8A11-N | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-8DV11 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-DLV11-J | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-H9610 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-H9612 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-H9642 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-LA120 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-LA38 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-MSV11-D | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-RL01 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-RL02 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-RLV11 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-RX02 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-RX21 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| FB-VT100 | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |

| | FB-00871 | FB-1123 | FB-BAT1-N | FB-BDV11 | FB-DLV11-J | FB-H9610 | FB-H9612 | FB-H9642 | FB-LA120 | FB-LA38 | FB-MSV11-D | FB-RLU1 | FB-RL02 | FB-RLV11 | FB-RX02 | FB-RXV21 | FB-VT100 |
|-------------|----------|---------|-----------|----------|------------|----------|----------|----------|----------|---------|------------|---------|---------|----------|---------|----------|----------|
| SR-WXMMB-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXMMB-BD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXMMB-BK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXMMB-BN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXMMB-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXMMB-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXMMB-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXMMB-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-AA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-AD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-AK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-AN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-BD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-BK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-BN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSB-AA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSB-AD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSB-AK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSB-AN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SR-WXSSB-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |

PDP-11/23

| | SR-WXSSB-BD | SR-WXSSB-BIK | SR-WXSSB-BN | SR-WXSSB-CA | SR-WXSSB-CD | SR-WXSSB-CK | SR-WXSSB-CN |
|------------|-------------|--------------|-------------|-------------|-------------|-------------|-------------|
| FB-00871 | ● | ● | ● | ● | ● | ● | ● |
| FB-11/23 | ● | ● | ● | ● | ● | ● | ● |
| FB-BAT1-N | ● | ● | ● | ● | ● | ● | ● |
| FB-BDV11 | ● | ● | ● | ● | ● | ● | ● |
| FB-DLV11-J | ● | ● | ● | ● | ● | ● | ● |
| FB-H9610 | ● | ● | ● | ● | ● | ● | ● |
| FB-H9612 | ● | ● | ● | ● | ● | ● | ● |
| FB-H9642 | ● | ● | ● | ● | ● | ● | ● |
| FB-LA120 | ● | ● | ● | ● | ● | ● | ● |
| FB-LA38 | ● | ● | ● | ● | ● | ● | ● |
| FB-MSV11-D | ● | ● | ● | ● | ● | ● | ● |
| FB-RL01 | ● | ● | ● | ● | ● | ● | ● |
| FB-RL02 | ● | ● | ● | ● | ● | ● | ● |
| FB-RLV11 | ● | ● | ● | ● | ● | ● | ● |
| FB-RX02 | ● | ● | ● | ● | ● | ● | ● |
| FB-RXV21 | ● | ● | ● | ● | ● | ● | ● |
| FB-VT100 | ● | ● | ● | ● | ● | ● | ● |

| | FB-0874 | FB-1124 | FB-BAT1-A | FB-BAT1-L | FB-H942 | FB-LA20 | FB-LA38 | FB-M8312 | FB-M811-L | FB-RK07 | FB-RK611 | FB-RL02 | FB-RL11 | FB-RX02 | FB-RX211 | FB-VT100 |
|--------------|---------|---------|-----------|-----------|---------|---------|---------|----------|-----------|---------|----------|---------|---------|---------|----------|----------|
| DE-FXHHA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DE-FXHHA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DE-FXHHA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DE-FXHHA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DE-FXMMMA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DE-FXMMMA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DE-FXMMMA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DE-FXMMMA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DM-FXMMMA-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DM-FXMMMA-BD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DM-FXMMMA-BK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DM-FXMMMA-BN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DM-FXMMMA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DM-FXMMMA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DM-FXMMMA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DM-FXMMMA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DR-FXMMMA-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DR-FXMMMA-BD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DR-FXMMMA-BK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| DR-FXMMMA-BN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-FXHHA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-FXHHA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-FXHHA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-FXHHA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-FXMMMA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |

| | FB-0074 | FB-17/24 | FB-BA11-A | FB-BA11-L | FB-H8642 | FB-LA120 | FB-LA38 | FB-M372 | FB-MS11-L | FB-RK07 | FB-RK611 | FB-RL02 | FB-RL11 | FB-RX02 | FB-RX211 | FB-VT100 |
|-------------|---------|----------|-----------|-----------|----------|----------|---------|---------|-----------|---------|----------|---------|---------|---------|----------|----------|
| SE-FXMMA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-FXMMA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-FXMMA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXHA-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXHA-BD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXHA-BK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXHA-BN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXHA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXHA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXHA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXHA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXMA-BA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXMA-BD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXMA-BK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXMA-BN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXMA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXMA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXMA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-FXMA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SP-FXHA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SP-FXHA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SP-FXHA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SP-FXHA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SP-FXMMA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SP-FXMMA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |

PDP-1134A

| Model | FB-VT100 | FB-TS11 | FB-TM03 | FB-TE16 | FB-RX211 | FB-RX02 | FB-RP06 | FB-RM02 | FB-RL11 | FB-RL02 | FB-RL01 | FB-RK611 | FB-RK07 | FB-RH11 | FB-MS11-L | FB-M9312 | FB-M9302 | FB-M7850 | FB-LA38 | FB-LA36 | FB-LA120 | FB-KY11-LB | FB-H765 | FB-H754 | FB-H745 | FB-DL11-W | FB-BAT1K | FB-1134A | FB-00961 | |
|-------------|----------|---------|---------|---------|----------|---------|---------|---------|---------|---------|---------|----------|---------|---------|-----------|----------|----------|----------|---------|---------|----------|------------|---------|---------|---------|-----------|----------|----------|----------|--|
| SM-30MMB-CN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-AA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-AD | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-AK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-AN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-BA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-BD | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-BK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-BN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-CA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-CD | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-CK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SM-30MMC-CN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30HHA-AA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30HHA-AD | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30HHA-AK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30HHA-AN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30LLA-AA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30LLA-AD | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30LLA-AK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30LLA-AN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30MMA-AA | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30MMA-AD | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30MMA-AK | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SP-30MMA-AN | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| | FB-11/44 | FB-8A11-A | FB-FP11-F | FB-H9842 | FB-KE4A | FB-KK11-B | FB-LA120 | FB-MS11-L | FB-MS11-M | FB-RA90 | FB-RH11 | FB-RK07 | FB-RK611 | FB-RL02 | FB-RL11 | FB-RM02 | FB-TS11 | FB-TU58 | FB-UD450 |
|-------------|----------|-----------|-----------|----------|---------|-----------|----------|-----------|-----------|---------|---------|---------|----------|---------|---------|---------|---------|---------|----------|
| SE-40HHB-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40HHB-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40HHB-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40HHB-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40MMB-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40MMB-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40MMB-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40MMB-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40UAB-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40UAB-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40UAB-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40UAB-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40UAC-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40UAC-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40UAC-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SE-40UAC-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40GAA-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40GAA-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40GAA-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40GAA-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40HHB-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40HHB-CD | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40HHB-CK | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40HHB-CN | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |
| SM-40MMG-CA | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● | ● |

- FB-TU77
- FB-TS11
- FB-TM03
- FB-TE16
- FB-RP06
- FB-RM05
- FB-RM03
- FB-RH70
- FB-MK11
- FB-MJ11
- FB-MJ12
- FB-M831-A
- FB-LP71-A
- FB-LA36
- FB-LA20
- FB-LA120-C
- FB-H980-D
- FB-H980-D
- FB-H9506
- FB-H319
- FB-DM11-D
- FB-DL11-W
- FB-DH11
- FB-DH11-D
- FB-DH11-C
- FB-DB11-A
- FB-DB11-K
- FB-BA11-K
- FB-11/70-02
- FB-00861

SP-70TVC-CN

Diagnostic Kits

INTRODUCING THE MULTI-MEDIA DIAGNOSTICS GRID

DIGITAL has traditionally offered diagnostic software on papertape. Over the years the use of papertape readers has declined and magnetic media has grown in popularity for loading diagnostics. Although DIGITAL'S diagnostics were also available on various media, it was a cumbersome task to cross-reference part numbers from media to media. The multi-media diagnostics grid will alleviate any confusion associated with locating diagnostic software on various media.


To utilize the grids a basic understanding of DIGITAL'S part numbering scheme is necessary. The 'five - two' numbering scheme is used for diagnostic kits; the 'two - five - two' numbering scheme is used to identify loose piece diagnostic components such as disks, magtapes, etc.

The following illustrations explain both numbering schemes in detail.

The 5-2 Numbering Scheme

The format for diagnostic kit model numbers is as follows (5-2 number):

Example:



Software Type ZJ010-RZ

- Q System Software
- Z Diagnostic Software

CPU Identifier ZJ010-RZ

- D VAX-11/750
- E VAX-11/780
- F PDP-8
- J PDP-11
- P PDP-11/40 or higher
- R PDP-11/45 or higher

Unique Identifier ZJ010-RZ

The unique identifier will be numerical characters.

License and Support ZJ010-RZ

This single character indicates whether or not a license is required.

- C Binary License, no support
- D License only
- F Microfiche
- P No License, Binaries only
- R No License, Binaries Documentation

Media ZJ010-RZ


This single character identifies the distribution media. The following codes are assigned:

- A Linctape
- B Papertape
- C Dectape
- D 9 Track Magtape, 800 BPI, 600 ft
- E RK05 Disk Cartridge
- F 7 Track Magtape, 800 BPI, 600 ft
- G TU58 Dectape II Cartridge
- H RL02 Disk Cartridge
- M 9 Track Magtape, 1600 BPI, 2400 ft
- P 9 Track Magtape, 800 BPI, 2400 ft
- Q RL01 Disk Cartridge
- R Microfiche
- T RK06 Disk Cartridge
- V RK07 Disk Cartridge
- X RX02 Floppy Diskette
- Y RX01 Floppy Diskette
- Z No Hardware Dependency

The 2-5-2 Numbering Scheme

The format for the DIGITAL standard numbering system is as follows (2-5-2 number):

Example:



Inventory Class Code AC-8169A-MC

The inventory class code has been defined as MEDIA designation. The diagnostic media designations are:

| | | | |
|----|---------------------|----|----------------------|
| AC | Listing/Document | AS | RX01 Floppy Diskette |
| AH | Microfiche | AT | Card Deck |
| AK | Papertape | AX | RL01 Disk Cartridge |
| AL | Dectape and Lintape | AY | RK07 Disk Cartridge |
| AM | RK06 Disk Cartridge | BA | RX02 Floppy Diskette |
| AN | RK05 Disk Cartridge | BB | 1600 BPI Magtape |
| AP | 800 BPI Magtape | BC | RL02 Disk Cartridge |
| AR | TU60 Cassette | BE | TU58 Dectape |

Unique Identifier AC-8169A-MC

The unique identifier will be alphanumeric.

Revision Identifier AC-8169A-MC

The revision identifier will be a single alpha character and will be changed each time the component is revised.

License Identifier AC-8169A-MC

This single identifier indicates whether the software is restricted or non-restricted, and whether or not a license is required.

- D Diagnostic Software, license required
- M Diagnostic Software, no license required
- Y Diagnostic Software, restricted distribution

CPU Identifier AC-8169A-MC

This single character will indicate the central processor unit on which the software is used.


- A PDP-8
- C PDP-11
- E VAX
- J PDP-9/15/XVM
- K Cross Product Line
- N PDP-14
- P PDP-12
- 1-9 Patch Level

HOW TO USE DIAGNOSTIC GRID

The ordering part number is made up of three distinct parts:

- 1) Class Code 2) Unique Identifier 3) Variant

Example:



For purposes of eliminating redundancy and to promote the ease of using the diagnostic grid, we have listed the class code and variant at the top of each column and listed only the Unique Identifier which changed for each line.

Example: Doc. Part #
 AC **MC**

To order the document for CFKAAC0, 11/34 Basic Inst. Test, order part # AC-8041C-MC

CFKAAC0 8041C

| | | | |
|----------|------|---|---|
| Document | Part | # | AC-8041C-MC |
| RX01 | " | " | AS-9643P-MC |
| RX02 | " | " | BA-F033K-MC |
| RK05 | " | " | AN-E754R-MC |
| RL01 | " | " | AX-E441U-MC |
| TU58 | " | " | *THIS DIAGNOSTIC IS NOT AVAILABLE ON TU58 MEDIA |

800 BPI MAGTAPE
AP-9708Z-MC

| | | Document | | | | | | 800 BPI |
|---------|------------------------|----------|-------|-------|-------|-------|-------|---------|
| | | Part # | RX01 | RX02 | RK05 | RL01 | TU58 | Magtape |
| Pkg ID | Title | AC-MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CFKAAC0 | 11/34 Basic Inst. Test | 8041C | 9643P | F033K | E754R | E441U | * | 9708Z |

Notes:

- 1) *The diagnostic is not available on this type of media.
- 2) The entire PDP-11 diagnostic library, including DEC11 and XXDP™ is located on:

| | | | |
|------|----------|---------|-------------|
| RK06 | Ordering | Part # | AM-S469E-MC |
| RK07 | " | " | AY-E443V-MC |
| RL02 | " | " | BC-F916J-MC |
| 1600 | BPI | Magtape | BB-F751M-MC |

AAV11 DIAGNOSTICS

ZJ248-RZ DOCUMENTATION KIT
 ZJ248-PB PAPERTAPE KIT
 ZJ248-FR MICROFICHE KIT

| <u>ZJ248 KIT CONTENTS</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>FX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|---------------------------|-----------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| MD-11-DVAAA | AAV11 DIAGNOSTIC TEST | 8169A | 9671U | F048P | T069A | E380V | F669D | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

ZJ103 KIT CONTENTS:

| <u>ZJ103 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|------------------------|----------------------------|--------------|--------------|--------------|--------------|--------------|----------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| MD-11-DZADB | AD01-D DIAGNOSTIC TEST | 8322B | * | F028J | E757R | E441V | * | TO72A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

ADV11

ZJ250-RZ DOCUMENTATION KIT
 ZJ250-PB PAPERTAPE KIT
 ZJ250-FR MICROFICHE KIT

| <u>ZJ250 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|-----------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CVADAC0 | ADV11 PERF TEST | 8174C | 9671U | F021P | T069A | E380V | F669D | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

ZJ254-RZ DOCUMENTATION KIT
 ZJ254-PB PAPERTAPE KIT
 ZJ254-FR MICROFICHE KIT

ZJ254 KIT CONTENTS:

| | | <u>DOCUMENT PART #</u> | | | | | | <u>800 BPI MAGTAPE</u> |
|---------------|---------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CVM8AD0 | BDV11-AA DIAGNOSTIC | B061D | 9671U | F022Q | T069A | E380V | * | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

| ZJ129 KIT CONTENTS: | | DOCUMENT PART # | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI MAGTAPE |
|---------------------|--------------------------|--------------------|-------|-------|-------|-------|-------|--------------------|
| PKG ID | TITLE | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CXCPBJ0 | EIS EXER MOD | E667J | F754G | F022Q | T069A | E380V | * | T071A |
| CXLPAF0 | LP11 MODULE | E670F | 9668U | F022Q | T069A | E380V | * | T071A |
| CXRFAG0 | RF11 MODULE | E673G | 9668U | F049P | T069A | E380V | * | T071A |
| CXRRKAG0 | RK11 MODULE | E676G | 9668U | F049P | T069A | E380V | * | T071A |
| CXRPAM0 | RP11 MODULE | E679M | 9668U | F049P | T069A | E380V | * | T071A |
| CXTAADO | TA11 MODULE | E682D | F949G | F049P | T069A | E380V | * | T071A |
| CXTCAGO | TC11 MODULE | E685G | F949G | F049P | T069A | E380V | * | T071A |
| CXCPAGO | PROCESSOR TEST | E664G | F754G | F022Q | T069A | E380V | * | T071A |
| CXXYADO | XY11 PLOT MOD | E661D | F949G | F049P | T069A | E380V | * | T071A |
| CXKWAG0 | KW11-L MODULE | E688G | F754G | F022Q | T069A | E380V | * | T071A |
| CXKWBKO | KW11-P MODULE | E691K | F754G | F022Q | T069A | E380V | * | T071A |
| CXCRAGO | CR11 MODULE | E694G | T070A | F022Q | T069A | E380V | * | T071A |
| CXKEADO | KE11 MODULE | E697D | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXPCCDO | PC11 MODULE | E700D | 9668U | F049P | T069A | E380V | * | T071A |
| CXTMAJO | TM11 MODULE | E703J | F949G | F049P | T069A | E380V | * | T071A |
| CXFPAG0 | FP11 (11/40 & 45) MODULE | E742G | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXCDAAG0 | CD11 MODULE | E788G | T070A | F022Q | T069A | E380V | * | T071A |
| CXRCADO | RC11 MODULE | E932D | 9668U | F049P | T069A | E380V | * | T071A |
| CXBMCNO | BOOTSTRAP ROM MODULE | F057N | T070A | F022Q | T069A | E380V | * | T071A |
| CXDPAEO | DP11 MODULE | E712N | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDLAJO | DL11 MODULE | E709J | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDMBIO | DM11-BB 16-LINE MODULE | E845I | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDCAGO | DC11 MODULE | E706G | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDHALO | DH11 16-LINE PROG | E866L | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDUAIO | DU11 MODULE | E718I | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDQAI0 | DQ11 MODULE | E715I | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDJAKO | DJ11 MODULE | E721K | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDNAHO | DN11 MODULE | E803H | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXKLAEO | KL11 MODULE | E821E | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXKGADO | DG11 MODULE | E824D | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDAGO | DX11 MODULE | E827G | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXCBCFO | CB11-HA MODULE | E833F | T070A | F022Q | T069A | E380V | * | T071A |
| CXCBBEO | CB11 DISTRIBUTE MOD | E836E | T070A | F022Q | T069A | E380V | * | T071A |

ZJ129 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | | | | | | | 800 BPI MAGTAPE |
|----------|----------------------------|----------|-------|-------|-------|-------|-------|-------|--------------------|
| | | PART # | RX01 | RX02 | RK05 | RL01 | TU58 | | |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC | |
| CXMNAAO | MNCAD (A/D) MOD | F416A | 9668U | F049P | T069A | E380V | * | T071A | |
| CXMNBAO | MNCDI MODULE | F419A | 9668U | F049P | T069A | E380V | * | T071A | |
| CXMNCAO | MNCKW MODULE | F422A | 9668U | F049P | T069A | E380V | * | T071A | |
| CXMNDAO | MNCDA (D/A) MOD | F425A | 9668U | F049P | T069A | E380V | * | T071A | |
| CXMNEAO | MNCDO MODULE | F428A | 9668U | F049P | T069A | E380V | * | T071A | |
| CXBMIAO | BOOT ROM MODULE | F542A | T070A | F022Q | T069A | E380V | * | T071A | |
| CXTUAAO | TU58 MODULE | F650A | F949G | F049P | T069A | E380V | * | T071A | |
| CXVTVAO | VTV30J/H VT30H MODULE | F658A | F949G | F049P | T069A | E380V | * | T071A | |
| CXDRFCO | DRV11B MODULE | E739C | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXCBAEO | CB11 SCAN MODULE | E839E | T070A | F022Q | T069A | E380V | * | T071A | |
| CXGTAEAO | GT40 MODULE | E724E | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXLPBFO | LPS-KW MODULE | E727F | 9668U | F022Q | T069A | E380V | * | T071A | |
| CXLPDFO | LPS-AD, NP MODULE | E730F | 9668U | F022Q | T069A | E380V | * | T071A | |
| CXADAEO | AD01-D MODULE | E800E | T070A | F022Q | T069A | E380V | * | T071A | |
| CXLPCEO | LPS11/LPS-VC MODULE | E842E | 9668U | F022Q | T069A | E380V | * | T071A | |
| CXAAADO | AA11/VT01-A MODULE | E848D | T070A | F022Q | T069A | E380V | * | T071A | |
| CXPAAFO | PA611 READER MODULE | E860F | 9668U | F049P | T069A | E380V | * | T071A | |
| CXPABGO | PA611 PUNCH MODULE | E857G | 9668U | F049P | T069A | E380V | * | T071A | |
| CXDRADO | DR11-A MODULE | E854D | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXDRBHO | DR11-B MODULE | E851H | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXDRCIO | DR11-C MODULE | E733I | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXAFAEO | AFC 11 MODULE | E794E | T070A | F022Q | T069A | E380V | * | T071A | |
| CXUDADO | UDC 11 MODULE | E863D | F949G | F049P | T069A | E380V | * | T071A | |
| CXTMBKO | TM02, 03/TU16, TE16 MODULE | E878K | F949G | F049P | T069A | E380V | * | T071A | |
| CXRSAJO | RH11/RS03-04, RS03/LA | E748J | 9668U | F049P | T069A | E380V | * | T071A | |
| CXRPBIO | RH11-RH70 SGL PT DSK | E745I | 9668U | F049P | T069A | E380V | * | T071A | |
| CXKWCBO | KW11-W MODULE | E791B | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXICADO | ICS-11 MODULE | E869D | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXBTABO | BUS TESTER MODULE B | E812B | T070A | F022Q | T069A | E380V | * | T071A | |
| CXBTBBO | BUS TESTER MODULE A | E809B | T070A | F022Q | T069A | E380V | * | T071A | |
| CXARABO | AR11 MODULE | E875B | T070A | F022Q | T069A | E380V | * | T071A | |
| CXBBABO | KIT11-D MODULE | E881B | T070A | F022Q | T069A | E380V | * | T071A | |
| CXDRECO | DR11-M, DR11-L MODULE | E887C | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXICBCO | ICR-11 MODULE | E890C | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXDPBBO | DUP-11 MODULE | E893B | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXNCADO | NC11-A MODULE | E899D | 9668U | F049P | T069A | E380V | * | T071A | |
| CXDRDCO | DR11-K MODULE | E902C | 9664Z | F022Q | T069A | E380V | * | T071A | |
| CXVTABO | VT20 MODULE | E905B | F949G | F049P | T069A | E380V | * | T071A | |

ZJ129 KIT CONTENTS:

| ZJ129 KIT CONTENTS: | | DOCUMENT PART # | RX01 | FX02 | RK05 | RL01 | TU58 | 800 BPI MAGTAPE |
|---------------------|-----------------------------|--------------------|-------|-------|-------|-------|-------|--------------------|
| PKG ID | TITLE | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CXLPEDO | LPD-11 MODULE | E908D | 9668U | F022Q | T069A | E380V | * | T071A |
| CXLPFBO | LP20 MODULE | E815B | 9668U | F022Q | T069A | E380V | * | T071A |
| CXKWFB0 | GROSS TMNG MOD | F001B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDTADO | DTE20 TMNG MOD | E995D | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDLBBO | DL11-E TMNG MOD | E998B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXBMFB0 | BM873-YH MODULE | F066B | T070A | F022Q | T069A | E380V | * | T071A |
| CXBMGB0 | BM873-YJ MODULE | F069B | T070A | F022Q | T069A | E380V | * | T071A |
| CXBMEBO | BM873-YF MODULE | F063B | T070A | F022Q | T069A | E380V | * | T071A |
| CXRPDDO | RH70/RP04,5,6 MODULE | F087D | 9668U | F049P | T069A | E380V | * | T071A |
| CXLKABO | LK11 MODULE | E935B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXKWDBO | KW11-K MODULE | E929B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXFPBDO | FP11-A, B, C MODULE | E938D | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDZAE0 | DZ11 MODULE | E941E | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDVABO | DV11 MODULE | E947B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXADBB0 | AD11-K MODULE | E926B | T070A | F022Q | T069A | E380V | * | T071A |
| CXVSBBO | VSVO1 MODULE | E944B | F949G | F049P | T069A | E380V | * | T071A |
| CXVSACO | VS60 MODULE | E872C | F949G | F049P | T069A | E380V | * | T071A |
| CXKWEB0 | KWV11K MODULE | E920B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXKUABO | KUV11-A MODULE | E992B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXIBADO | IBV11-A MODULE | E914D | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDZBCO | DZV11 MODULE | E911C | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXBMDDO | LSI-11 BDV11 MODULE | F060D | T070A | F022Q | T069A | E380V | * | T071A |
| CXADCBO | ADV11 MODULE | E923B | T070A | F022Q | T069A | E380V | * | T071A |
| CXAACBO | AAV11 MODULE | E917B | T070A | F022Q | T069A | E380V | * | T071A |
| CXTRACO | TR79F MODULE | E896C | F949G | F049P | T069A | E380V | * | T071A |
| CXRKBFO | RK611/RK06,RK07 MOD | E785F | 9668U | F049P | T069A | E380V | * | T071A |
| CXKMCBO | KMC-11 MODULE | E950B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDMCBO | DMC-11 MODULE | E953B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXAABBO | AA11-K MODULE | E959B | T070A | F022Q | T069A | E380V | * | T071A |
| CXVTBBO | DH11/VT20 MODULE | E956B | F949G | F049P | T069A | E380V | * | T071A |
| CXRXAEO | RX01 MODULE | E736E | 9668U | F049P | T069A | E380V | * | T071A |
| CXBEABO | M7855 BUS TESTER MOD | E884B | T070A | F022Q | T069A | E380V | * | T071A |
| CXLPHBO | LPA11-XX MODULE | E974B | 9668U | F022Q | T069A | E380V | * | T071A |
| CXRXBBO | RX02 MODULE | F098C | 9668U | F049P | T069A | E380V | * | T071A |
| CXRLADO | RL11/RLV11/RL01/RL02 MOD | E965D | 9668U | F049P | T069A | E380V | * | T071A |
| CXRMADO | RH11, 70/RM03, 02, S.P. MOD | E971D | 9668U | F049P | T069A | E380V | * | T071A |
| CXRMBBO | RH11/RM03 DUAL PORT MOD | E968C | 9668U | F049P | T069A | E380V | * | T071A |
| CXBMHBO | M9312 MODULE | F072B | T070A | F022Q | T069A | E380V | * | T071A |

ZJ129 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI |
|----------|------------------------|----------|-------|-------|-------|-------|-------|---------|
| | | PART # | | | | | | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CXPCSBO | PCS-11 MODULE | E962B | 9668U | F049P | T069A | E380V | * | T071A |
| CXPLABO | PCL11 MODULE | F084B | 9668U | F049P | T069A | E380V | * | T071A |
| CXDRWBO | DR11-W MODULE | F004B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXTSAAO | TS11/TS04 MODULE | E451A | F949G | F049P | T069A | E380V | * | T071A |
| CXNCBAO | NCV11A MODULE | F234A | 9668U | F049P | T069A | E380V | * | T071A |
| CXDMRBO | DMR11 MODULE | F858B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXRMCAO | RM05/3/2 MODULE | S077A | 9668U | F049P | T069A | E380V | * | T071A |
| CXDPVAO | DPV-11 MODULE | S039A | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXRMDAO | RP04/5/6 RM0 MODULE | S081A | 9668U | F049P | T069A | E380V | * | T071A |
| CXCMABO | CSS CMS11K MODULE | S260B | T070A | F022Q | T069A | E380V | * | T071A |
| CXDMDCO | DMP11 MSTR MODULE | F805C | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDMEBO | DMP11 SLAVE MODULE | F808B | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXDRJAO | DRV11-J MODULE | F818A | * | F022Q | T069A | E380V | * | T071A |
| CXDRKAO | CSS DR70 MODULE | S257A | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXKWGAO | CSS KW11C MODULE | S248A | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXRHA AO | RH01 MODULE | S254A | 9668U | F049P | T069A | E380V | * | T071A |
| CXXYBAO | CSS XY311 MODULE | S251A | F949G | F049P | T069A | E380V | * | T071A |
| CXTMDAO | TM78 MODULE | S210A | F949G | F049P | T069A | E380V | * | T071A |
| CXCMJAO | CMR11 MODULE | S330A | 9664Z | F022Q | T069A | E380V | * | T071A |
| CXVSCAO | VSV11 CSS MODULE | S234A | F949G | F049P | T069A | E380V | * | T071A |
| CXVTC AO | VTV30-K CSS MODULE | S054A | F949G | F049P | T069A | E380V | * | T071A |
| CXDUBAO | UDA MODULE | S914A | 9664Z | F022Q | T069A | E380V | * | T071A |
| CHQFS AO | XXDP + FILE STRUC DOC. | S866A | * | * | * | * | * | * |

All of the diagnostics listed may be found on:

| MEDIA | ORDERING PART # |
|--------------------------------|-----------------|
| RK06 | - AM-S469D-MC |
| RK07 | - AY-E443U-MC |
| RL02 | - BC-F9161-MC |
| 1600 BPI MAGTAPE - BB-7751L-MC | |

DEC/X11

DH11

ZJ114-RZ
ZJ114-PBDOCUMENTATION KIT
PAPERTAPE KIT

| <u>ZJ114 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|------------------------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZDHAC0 | DH11 STAT LOGIC TEST | 8444C | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHB | DH11 MEMORY TEST | 8448B | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHC | DH11 REC AND TRANS LOGIC TEST | 8452B | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHD | DH11 SPEED SEL TEST | 8456C | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHE | DH11 CHAR LENGTH AND BAS DATA TEST | 8460B | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHF | DH11 SINGLE LINE DATA SET | 8464E | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHG | DH11 MULTI-LINE DATA TEST | 8468B | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHH | DH11 AUTO-ECHO TEST | 8472B | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHI | DH11 BREAK AND HALF DUPLEX TEST | 8476C | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZDHJ | DH11 ECHO TEST | 8480B | 9657Q | F024N | E756R | F947J | * | T072A |
| CZDHLC0 | DH11 OVRLY FOR ITEP | 8488C | 9657Q | F024N | E756R | F947J | * | T072A |
| MD-11-DZITA | INTERPROCESSOR TEST PROGRAM | 8810D | 9657Q | F024N | E756R | F947J | * | T072A |
| CZDHND0 | DH11 DATA RELIAB TEST | 8496D | 9657Q | F024N | E756R | F947J | * | T072A |
| CZDHMD0 | DH11 DIAG | 8492D | 9657Q | F024N | E756R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

ZJ117-RZ DOCUMENTATION KIT
 ZJ117-PB PAPERTAPE KIT
 ZJ117-FR MICROFICHE KIT

ZJ117 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | | | | | | 800 BPI |
|-------------|--------------------------|----------|-------|-------|-------|-------|-------|---------|
| | | PART # | RX01 | RX02 | RK05 | RL01 | TU58 | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CZDLCD0 | DL11-C, D, E OFFLINE TST | 8524D | 9656W | F024N | E756R | F947J | * | T072A |
| CZDLBC0 | DL11-E ON LINE TEST | 8520C | 9656W | F024N | E756R | F947J | * | T072A |
| CZDLOD0 | DL11 OVRLY FOR ITEP | 8532D | 9655M | F028J | E756R | F947J | * | T072A |
| MD-11-DZITA | INTERPROCESSOR TEST PROG | 8810D | 9655M | F028J | E756R | F947J | * | T072A |
| CZDLAHO | DL11-E C/D OFFLINE TEST | 8516H | 9656W | F024N | E756R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

DL11W

ZJ235-RZ DOCUMENTATION KIT
ZJ235-PB PAPERTAPE KIT
ZJ235-FR MICROFICHE KIT

| <u>ZJ235 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>FX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|--------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZDLDH0 | DL11-W DIAG | 8528H | 9656W | F024N | E756R | F947J | S046F | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

DLV11-E

ZJ243-FZ
ZJ243-PB
ZJ243-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

ZJ243 KIT CONTENTS:

| <u>ZJ243 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|----------------------|----------------------------|--------------|--------------|--------------|--------------|--------------|----------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CVDVAC0 | DLV11-E OFFLINE TEST | B150C | 9671U | F021P | T069A | E380V | F668D | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

DLV11J

ZJ269-RZ
ZJ269-PB
ZJ269-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

| <u>ZJ269 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|--------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CVDLAB0 | DLV11-J TEST | E188B | 9671U | F048P | T069A | E380V | F668D | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

ZJ314-RZ DOCUMENTATION KIT
 ZJ314-PB PAPERTAPE KIT
 ZJ314-FR MICROFICHE KIT

ZJ314 KIT CONTENTS:

| | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|---------------|------------------|----------------------------|--------------|--------------|--------------|--------------|--------------|----------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CVDPVB0 | DPV-11 FUNC DIAG | S033B | 9671U | F048P | T069A | E380V | B669D | T071A |
| CVCLHB0 | DPV-11 DCLT | F582B | 9671U | F048P | T069A | E380V | * | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

DR11A

ZJ123-RZ DOCUMENTATION KIT
ZJ123-PB PAPERTAPE KIT
ZJ123-FR MICROFICHE KIT

| <u>ZJ123 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|-------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZDRIB0 | DR11A DEV REG TST | 8668B | 9658Y | * | E756R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

ZJ124-RZ
ZJ124-PB
ZJ124-FRDOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

| <u>ZJ124 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|------------------------|----------------------------|--------------|--------------|--------------|--------------|--------------|----------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZDRBG0 | DR11-B/DA11-B NPR DIAG | 8643G | 9658Y | F886H | E756R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

DR11C

ZJ125-RZ DOCUMENTATION KIT
ZJ125-PB PAPERTAPE KIT
ZJ125-FR MICROFICHE KIT

| <u>ZJ125 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|---------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZDRCH0 | DR11C DEV REG | 8647H | 9658Y | F886H | E756R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

DR11K

ZJ187-RZ DOCUMENTATION KIT
ZJ187-PB PAPERTAPE KIT
ZJ187-FR MICROFICHE KIT

ZJ187 KIT CONTENTS:

| | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|---------------|----------------------------|--------------|--------------|--------------|--------------|--------------|----------------------------|
| <u>PKG ID</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZDRGE0 | 8660E | 9658Y | F886H | E756R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

DR11L/M

ZJ205-RZ
ZJ205-PB

DOCUMENTATION KIT
PAPERTAPE KIT

ZJ205 KIT CONTENTS:

DOCUMENT
PART #

RX01

RX02

RK05

RL01

TU58

800 BPI
MAGTAPE

| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
|---------------|-------------------|----------------|--------------|--------------|--------------|--------------|--------------|--------------|
| MD-11-DZDRH | DR11L/M EXERCISER | 8664A | 9658Y | F886H | E757J | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

DR11W

ZJ304-RZ DOCUMENTATION KIT
ZJ304-PB PAPERTAPE KIT
ZJ304-FR MICROFICHE KIT

ZJ304 KIT CONTENTS:

| <u>ZJ304 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|----------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZDRKA0 | DR11-W INTRPROC EXER | E782A | 9658Y | F886H | E756R | F947J | * | T072A |
| CZDRLB0 | DR11-W GEN NPR INTFC | E779B | 9658Y | F886H | E756R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | | BB-F751L-MC |

DRV11

ZJ244-RZ DOCUMENTATION KIT
ZJ244-PB PAPERTAPE KIT
ZJ244-FR MICROFICHE KIT

| <u>ZJ244 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|--------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CVKAFD0 | DRV11 TEST | 8206D | 9663Z | F021P | T069A | E380V | F668D | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

ZJ249 KIT CONTENTS:

DOCUMENT
PART #

RX01

RX02

RK05

RL01

TU58

800 BPI
MAGTAPE

| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
|---------------|-----------------------|----------------|--------------|--------------|--------------|--------------|--------------|--------------|
| MD-11-DVDRA | DRV11B DMA INTF DC | 8178A | 9671U | F048P | T069A | E380V | F668O | T071A |
| MD-11-DVDRB | DRV11B INTERPROC EXER | 8182A | 9671U | F048P | T069A | E380V | F668O | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

DRV11J

ZJ302-RZ DOCUMENTATION KIT
ZJ302-PB PAPERTAPE KIT
ZJ302-FR MICROFICHE KIT

ZJ302 KIT CONTENTS:

| <u>ZJ302 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|------------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CVDRCA0 | DRV11J DIAG TEST PRT 1 | F756A | 9671U | F048P | T069A | E380V | F668D | T071A |
| DVDRDA0 | DRV11J DIAG TEST PRT 2 | F759A | 9671U | F048P | T069A | E380V | F668D | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

DUP-11

ZJ213-RZ
ZJ213-PB
ZJ213-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

ZJ213 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | | | | | | 800 BPI |
|-------------|------------------------------|----------|-------|-------|-------|-------|-------|---------|
| | | PART # | RX01 | RX02 | RK05 | RL01 | TU58 | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CZDPBC0 | DUP-11 AND OFFLINE SDLC XMTR | 8576C | 9658Y | F025K | E756R | F947J | * | T072A |
| CZDPCD0 | DUP-11 OFFLINE SDLC RCVR | 8580D | 9658Y | F025K | E756R | F947J | * | T072A |
| CZDPDD0 | DUP-11 SDLC DECMD TEST | 8584D | 9658Y | F025K | E756R | F947J | * | T072A |
| CZDPEB0 | DUP-11 CONFIDENCE TST | 8588B | 9658Y | F025K | E756R | F947J | * | T072A |
| MD-11-DZDPF | ITEP OVERLAY FOR DUP-11/DA | 8592B | 9658Y | F025K | E756R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

102

DUP-11

DUV11-DA

ZJ237-RZ DOCUMENTATION KIT
ZJ237-PB PAPERTAPE KIT
ZJ237-FR MICROFICHE KIT

ZJ237 KIT CONTENTS:

| <u>ZJ237 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|-------------------------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| MD-11-DZDUO | DU11 OVERLAY FOR INT-TEST PROG | 8700B | 9655M | F028J | E756R | F947J | * | T072A |
| CZDUQC0 | DUV11 OFFLINE LOGIC TEST | 8704C | F804H | F024N | E756R | F947J | F669D | T072A |
| MD-11-DZDUR | DUV11 OFFLINE RCVR TSTS | 8708B | F804H | F024N | E756R | F947J | F669D | T072A |
| MD-11-DZDUS | DUV11 OFFLINE RECR TMG TEST | 8712B | F804H | F024N | E756R | F947J | F669D | T072A |
| MD-11-DZDUT | DUV11 OFFLINE TRANS TEST | 8716B | F804H | F024N | E756R | F947J | F669D | T072A |
| MD-11-DZDUU | DUV11 OFLNE COMBD TMG & INTRPT TEST | 8720B | F804H | F024N | E756R | F947J | F669D | T072A |
| MD-11-DZDUV | DUV11 OFFLINE CMBD TEST | 8724B | F804H | F024N | E756R | F947J | F669D | T072A |
| MD-11-DZITA | INTERPROC TEST PROG (ITEP) | 8810D | F804H | F024N | E756R | F947J | F669D | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | |

DZ11

ZJ223-RZ
ZJ223-PB
ZJ223-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

ZJ223 KIT CONTENTS:

| <u>ZJ223 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|------------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZDZAG0 | DZ11 LN ASYNC MAX TEST | 8781G | 9674L | F024N | E756R | F947J | . | T072A |
| MD-11-DZDZB | DZ11 OVERLAY FOR ITP | 8785B | 9674L | F024N | E756R | F947J | . | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

FP11

ZR101-RZ
ZR101-PBDOCUMENTATION KIT
PAPERTAPE KIT

| <u>ZR101 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|---|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| MD-11-DCFPA | FP11 BASIC INSTRUCTION TEST LDFPS, STFPS, SETI, SETL, SETF, SETD, CFOC | 7710B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPB | FP11 BASIC INST TEST STST | 7714B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPC | FP11 BASIC INST TEST LDF,LDD,STF,STD | 7718B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPD | FP11 BASIC INST TEST ADDF,ADDD,SUBF, SUBD | 7722C | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPE | FP11 BASIC INST TEST CMDF, CMDP | 7726B | 9624F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPF | FP11 BASIC INST TEST MULF, MULD | 7730B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPG | FP11 BASIC INST TEST DIVF, DIVD | 7734C | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPH | FP11 BASIC INST TEST CLRF, CLRD, TSTF, ABSF, ABSD, NEGF, NEGN | 7738B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPI | FP11 BASIC INST TEST LDCFD, LGCDF, STCFD, STCDF | 7742B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPJ | FP11 BASIC INST TEST LDCIF, LDCLF, LDCID, STCFI, STCFL, STCDI | 7746B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPK | FP11 BASIC INST TEST LDEXP, STEXP | 7750B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPL | FP11 BASIC INST TEST MODF, MODD | 7754B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPM | MAINT. INSTRUCTION SET | 7758B | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPO | BASIC INSTR EXERCISER | 7762D | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPR | LDD/STD EXERCISER | 7766C | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPS | ADD & SUBTRACT EXERCISER | 7770D | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPT | MULTIPLY EXERCISER | 7774E | 9642F | F035H | E757R | E380V | * | T071A |
| MD-11-DCFPU | DIVIDE EXERCISER | 7778D | 9642F | F035H | E757R | E380V | * | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

FP11

FP11F

ZJ301-RZ
ZJ301-PB
ZJ301-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

ZJ301 KIT CONTENTS:

DOCUMENT
PART #

RX01

RX02

RK05

RL01

TU58

800 BPI
MAGTAPE

| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
|---------------|------------------|----------------|--------------|--------------|--------------|--------------|--------------|--------------|
| CKFPAC0 | FP11F FLTG PNT A | F630C | F873E | F864E | E754S | E441V | S046F | T071A |
| CKFPBB0 | FP11F FLTG PNT B | F633B | F873E | F864E | E754S | E441V | S046F | T071A |
| CKFPCC0 | FP11F FLTG PNT C | F636C | F873E | F864E | F754S | E441V | S046F | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

| PKG ID | TITLE | DOCUMENT | | | | | | | 800 BPI |
|---------|-----------------------|----------|-------|-------|-------|-------|-------|---------|---------|
| | | PART # | RX01 | FX02 | RK05 | RL01 | TU58 | MAGTAPE | |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC | |
| CJFPAA1 | FPF11 FLT PNT DIAG #1 | S439A | 9642F | F018Q | E754R | E380V | * | T071A | |
| CJFPBAO | FPF11 FLT PNT DIAG #2 | S442A | 9642F | F018Q | E754R | E380V | * | T071A | |

All of the diagnostics listed may be found on:

| MEDIA | ORDERING PART # |
|--------------------------------|-----------------|
| RK06 | - AM-S469D-MC |
| RK07 | - AY-E443U-MC |
| RL02 | - BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | |

ZJ245-RZ
ZJ245-PB
ZJ245-FRDOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KITZJ245 KIT CONTENTS:

| <u>ZJ245 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|----------------------|----------------------------|--------------|--------------|--------------|--------------|--------------|----------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| MD-11-DVKAB | LSI-11 EIS INST TEST | 8190A | 9663Z | F021P | T069A | E380V | F668D | T071A |
| CVKACC0 | LSI-11 FIS INST TEST | 8194C | 9663Z | F021P | T069A | E380V | F668D | T071A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | | BB-F751L-MC |

LSI-11 BASIC KIT

ZJV01-RZ
ZJV01-PBDOCUMENTATION KIT
PAPERTAPE KIT

| <u>ZJV01 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|----------------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| MD-11-DVAAA | AAV11 DIAG. TEST | 8169A | 9663Z | F048P | T069A | E380V | F669D | T071A |
| CVADAC0 | ADV11 PERFORMANCE TEST | 8174C | 9663Z | F021P | T069A | E380V | F669D | T071A |
| MD-11-DVDRA | DRV11B DMA INTF. DIAG. | 8178A | 9671U | F048P | T069A | E380V | F668D | T071A |
| MD-11-DVDRB | DRV11B INTERPROCESSOR EXER | 8182A | 9671U | F048P | T069A | E380V | F668D | T071A |
| CVKAAC0 | LSI-11 BSC INSTR | 8186C | 9663Z | F021P | T069A | E380V | F668D | T071A |
| MD-11-DVKAB | EIS INST. TEST | 8190A | 9663Z | F021P | T069A | E380V | F668D | T071A |
| CVKACC0 | LSI-11 FIS INST. | 8194C | 9663Z | F021P | T069A | E380V | F668D | T071A |
| CVKADC0 | TRAPS TEST | 8198C | 9663Z | F021P | T069A | E380V | F668D | T071A |
| MD-11-DVKAE | DLV11 TEST | 8202B | 9663Z | F021P | T069A | E380V | F668D | T071A |
| CVKAFD0 | DRV11 TEST | 8206D | 9663Z | F021P | T069A | E380V | F668D | T071A |
| MD-11-DVKAH | LSI-11 4K SYS EXER | 8210A | 9663Z | F021P | T069A | E380V | F668D | T071A |
| CZKMAF0 | MOS/CORE 0-124K EXER | 8850F | 9663Z | F021P | T069A | E441V | F668D | T072A |
| CVDLAB0 | DLV-11J TEST | E188B | 9671U | F048P | T069A | E380V | F668D | T071A |
| CVM8AD0 | BDV11/DKF11B BT DIAG | B061D | 9671U | F021P | T069A | E380V | * | T071A |
| CZVTOA0 | M7142 ACCPT TEST | F207A | F358H | B395J | E756R | F947J | * | T072A |

ALSO INCLUDED IN ZJV01-RZ

| | | |
|-------------|-----------------------------|-------------|
| DE-11-XPTIA | PTS RELEASE NOTES | AA-5716A-TC |
| DE-11-XPTSA | PDP-11 PT SOFTWARE HANDBOOK | AA-3457B-TC |
| DE-11-UABLB | NON-SWITCH REGISTER PDP-11 | |
| | ABSOLUTE LOADER VB07.00 | AB-3198A-TC |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

MM11, MF11UP

ZJ195-RZ
ZJ195-PB
ZJ195-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

ZJ195 KIT CONTENTS:

| <u>ZJ195 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|---------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZQMCG0 | 0-124K MEM EXER 16K | 9045G | 9640V | F021P | T069A | E441V | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE | | BB-F751L-MC |

| <u>ZJ246 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|----------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZKMAF0 | MOS/CORE 0-124K EXER | 8850F | 9640V | F034N | T069A | E441V | F668D | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

PDP-11/04 BASIC KIT

ZJ009-RZ DOCUMENTATION KIT
 ZJ009-PB PAPERTAPE KIT
 ZJ009-FR MICROFICHE KIT

ZJ009 KIT CONTENTS:

| | | DOCUMENT PART # | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI MAGTAPE |
|-------------|-------------------------|--------------------|-------|-------|-------|-------|-------|--------------------|
| PKG ID | TITLE | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| MD-11-DGKAA | PDP-11/04 CPU TEST | 8057A | 9640V | F033K | E754S | E441V | * | T071A |
| MD-11-DGKAB | 11/04 TRAPS TEST | 8061C | 9640V | F033K | E754S | E441V | * | T071A |
| CZM9AE0 | BOOT TERM M9301/9400 | 8954E | 9648Q | F021P | E754S | E441V | F668D | T072A |
| CZKMAF0 | MOS/CORE 0-124K EXER | 8850F | 9640V | F021P | E757R | E441V | F668D | T072A |
| CZM9BD0 | M9312/1144 UBI BOOT | E057D | 9648Q | F021P | E754S | E441V | S046F | T072A |
| CZQAGG0 | PDP-11 MAINDEX INDEX | S148G | * | * | * | * | * | * |
| CZUGAA0 | PDP-11 DIAG USERS GUIDE | E121A | * | * | * | * | * | * |

ALSO INCLUDED IN ZJ009-RZ:

| | | |
|-------------|--|-------------|
| DE-11-ZPTIA | PTS RELEASE NOTES | AA-5716A-TC |
| DE-11-UABLA | PDP-11 ABSOLUTE LOADER VA07 | AB-3196A-TC |
| DE-11-UABLB | NON-SWITCH REGISTER PDP-11 ABSOLUTE LOADER VB07 | AB-3198A-TC |
| DE-11-XPTSA | PDP-11 PT SOFTWARE HANDBOOK | AA-3457B-TC |

All of the diagnostics listed may be found on:

| MEDIA | ORDERING PART # |
|--------------------|-----------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

| <u>ZJ012 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|----------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZKMAF0 | MOS/CORE 0-124K EXER | 8850F | 9640V | F021P | T069A | E441V | * | T072A |
| CJKDAD0 | KTF11-AA DIAG | F138D | C638P | F021P | T069A | E380V | F668D | T071A |
| CJKDBD0 | DCF11-AA DIAG | F141D | C638P | F021P | T069A | E380V | F668D | T071A |

THE FOLLOWING DIAGNOSTIC IS NOT INCLUDED IN THE KIT, BUT MAY BE ORDERED SEPARATELY:

| | | | | | | | | |
|---------|------------------|-------|-------|-------|-------|-------|-------|-------|
| CJKDHAO | KEF11-B CIS DIAG | S431A | C638P | F021P | T069A | E380V | F668D | T071A |
|---------|------------------|-------|-------|-------|-------|-------|-------|-------|

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | |

ZJ013-RZ DOCUMENTATION KIT
 ZJ013-PB PAPERTAPE KIT
 ZJ013-FR MICROFICHE KIT

| <u>ZJ013 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | | | | | | <u>800 BPI MAGTAPE</u> |
|----------------------------|-----------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CJKDAD0 | KTF11-A DIAG | F138D | C638P | F021P | T069A | E380V | F668D | T071A |
| CJKDBD0 | DCF11-A DIAG | F141D | C638P | F021P | T069A | E380V | F668D | T071A |
| CJKDCB0 | KEF11-A DIAG #1 | F241B | C638P | F021P | T069A | E380V | F668D | T071A |
| CJKddb0 | KEF11-A DIAG #2 | F244B | C638P | F021P | T069A | E380V | F668D | T071A |
| CJKDEA0 | 11/24 CP CLUSTER DIAG | F605A | * | * | E754S | E380V | * | T071A |
| CJKDFA0 | 11/24 OPTIONS DIAG | F602A | * | * | E754S | E380V | * | T071A |
| CZMSDB0 | MS11-L/M MEMORY | F294B | F685E | F864E | E757R | E441V | S047D | T072A |

THE FOLLOWING DIAGNOSTICS ARE NOT INCLUDED IN THE KIT, BUT MAY BE ORDERED SEPARATELY:

| | | | | | | | | |
|---------|------------------|-------|-------|-------|-------|-------|---|-------|
| CJKDHA0 | KEF11-B CIS DIAG | S431A | C638P | F021P | T069A | E380V | * | T071A |
|---------|------------------|-------|-------|-------|-------|-------|---|-------|

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

| <u>ZJ010 KIT CONTENTS</u> | | <u>DOCUMENT</u> | | | | | | <u>800 BPI</u> |
|---------------------------|---------------------------|-----------------|--------------|--------------|--------------|--------------|--------------|----------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>MAGTAPE</u> |
| | | <u>AC-MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CFKAAC0 | 11/34 BASIC INST. TEST | 8041C | 9643P | F033K | E754S | E441V | * | T071A |
| CFKABD0 | 11/34 TRAPS TEST | 8045D | 9643P | F033K | E754S | E441V | * | T071A |
| MD-11-DFKAC | 11/34 EIS INST TEST | 0017A | 9643P | F033K | E754S | E441V | * | T071A |
| CFKTHB0 | 11/34 MEMORY MANAGEMENT | 8054B | 9643P | F033K | E754S | E441V | * | T071A |
| CFKTGC0 | 11/34 MEMORY MANAGEMENT | 8050C | 9643P | F033K | E754S | E441V | * | T071A |
| CZKMAF0 | MOS/CORE 0-124K EXER | 8850F | 9640V | F021O | E757R | E441V | F668D | T072A |
| CCMF AF0 | MS11, MF11, MA11-P MEMORY | 7883F | B079F | F030J | E754S | E441V | * | T071A |
| CZM9AE0 | BOOT TERM M9301/9400 | 8954E | 9648Q | F021O | E754S | E441V | F668D | T072A |
| MD-11-DZKAQ | PDP-11 POWER FAIL | 8814G | 9640V | F028J | E757R | E441V | * | T072A |
| MD-11-DZKLA | KL11/DL11-A TEL TEST | 8846E | 9646T | F034N | E757R | E441V | * | T072A |
| CZDLDH0 | DL11-W DIAGNOSTIC | 8528H | 9656W | F024N | E756R | F947J | S046F | T072A |
| CZM9BD0 | M9312/1144 UBI BOOT | E057D | 9648Q | F021O | E754S | E441V | S046F | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

PDP-11/40 BASIC KIT

ZP001-RZ DOCUMENTATION KIT
 ZP001-PB PAPERTAPE KIT

ZP001 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT PART # | | | | | | 800 BPI MAGTAPE |
|-------------|---------------------------|-----------------|-------|-------|-------|-------|-------|-----------------|
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | |
| MD-11-DBKDM | TEST 14 TRAPS TEST | 7642D | 9640V | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBA | SXT INSTRUCTION | 7782B | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBB | SOB INSTRUCTION | 7786B | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBC | XOR INSTRUCTION | 7790B | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBD | MARK INSTRUCTION | 7794C | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBE | RTT INSTRUCTION | 7798C | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCQKC | 11/40 & 11/45 INST EXER | 7895G | B079F | F030J | E757R | E380V | * | T071A |
| MD-11-D9EA | MAINTENANCE LOADER | 7635A | * | * | * | * | * | * |
| MD-11-DZKAQ | POWER FAIL | 8814G | 9640V | F029J | E757R | E441V | * | T072A |
| MD-11-DZKLA | KL11/DL11-A TELETYPE TEST | 8846E | 9646T | F034N | E757R | E441V | * | T072A |
| CZQKBH0 | T17-4K SYS EXER | 9031H | 9640V | F033K | E754S | E441V | * | T072A |
| CZQMCG0 | 0-124K MEM EXER 16K | 9045G | 9640V | F033K | E754S | E441V | * | T072A |
| CZKUAE0 | UNIBUS SYS EXER | 8855E | 9640V | F033K | E757R | E441V | S047D | T072A |
| CZKUBC0 | UNIBUS EXER MOD | 8859C | 9640V | F033K | E757R | E441V | S047D | T072A |

116

ALSO INCLUDED IN ZP001-RZ:

| | | |
|-------------|---|-------------|
| CZQAGG0 | PDP-11 PROGRAMMING CARD | EH-S1046-78 |
| DE-11-XPTIA | PDP-11 DIAG MAINDEC INDEX | AC-S148G-MC |
| DE-11-XPTSA | PTS RELEASE NOTES | AA-5716A-TC |
| DE-11-XDTCA | PDP-11 PT SOFTWARE HANDBOOK | AA-3457B-TC |
| DE-11-NFPMA | PDP-11 PT SYSTEM CHECKOUT PKG | AA-3360A-TC |
| DE-11-NFPMA | FPMP-11 DOCUMENT | AA-2224C-TC |
| DE-11-UABLA | FPMP-11 LISTING | AB-2215A-TC |
| DE-11-UODPA | ABSOLUTE LOADER (VA07) | AB-3196A-TC |
| DE-11-UODXA | ODT-11 ON-LINE DEBUGGER (V006A) | AB-3253A-TC |
| | ODT-11X ON-LINE DEBUGGER EXTENDED (V007A) | AB-3259A-TC |
| DE-11-XIOXA | IOX I/O EXECUTIVE (V006A) | AB-3361A-TC |
| DE-11-L1PA | BOOTSTRAP LOADER (V001A) | AB-1584A-TC |
| | DEC/X11 DOCUMENTATION KIT | ZJ129-RZ |

All of the diagnostics listed may be found on:

| MEDIA | ORDERING PART # |
|--------------------------------|-----------------|
| RK06 | - AM-S469D-MC |
| RK07 | - AY-E443U-MC |
| RL02 | - BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | |

PDP-11/40

PDP-11/44 BASIC CPU KIT

ZJ014-RZ
ZJ014-PB
ZJ014-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

ZJ014 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | 800 BPI | | | | | |
|---------|---------------------------|----------|---------|-------|-------|-------|-------|---------|
| | | PART # | RX01 | RX02 | RK05 | RL01 | TU58 | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CKKABC0 | 11/44 TRAPS | F621C | F865E | F864E | E754S | E441V | S046F | F354N |
| CKKACC0 | 11/44 POWER FAIL | F615C | F865E | F864E | E754S | E441V | S046F | F354N |
| CKKKAC0 | 11/44 KK11B CACHE | F624C | F865E | F864E | E754S | E441V | S047D | F354N |
| CKKTAB0 | 11/44 MEM MGMT PRT A | F609B | F865E | F864E | E754S | E441V | S047D | F354N |
| CKKTBC0 | 11/44 MEM MGMT PRT B | F612C | F865E | F864E | E754S | E441V | S047D | F354N |
| CZM9BD0 | M9312/1144 UBI BOOT | E057D | F774H | FO21P | E754S | E441V | S046F | F098W |
| CKKF000 | ROM DIAGN (11/44 UBI) | F639A | * | * | * | * | * | * |
| CKKAAB0 | 11/44 CPU/EIS | F618B | F865E | F864E | E754S | E441V | S046F | F354N |
| CKKFBA0 | 11/44 CNSL ROM DIAG | F642A | * | * | * | * | * | * |
| CKKUAC0 | 11/24/44 UBI MAP | F627C | F865E | F864E | E754S | E441V | S047D | T071A |
| CKFPAC0 | FP11F FLTG PNT PRT A | F630C | F873E | F864E | E754S | E441V | S046F | T071A |
| CKFPBB0 | FP11F FLTG PNT PRT B | F633B | F873E | F864E | E754S | E441V | S046F | T071A |
| CKFPCC0 | FP11F FLTG PNT PRT C | F636A | F873E | F864E | E754S | E441V | S046F | T071A |
| CZDLDH0 | DL11-W/1144 MFM SLU | 852BH | F774H | F024N | E756R | F947J | S046F | T072A |
| CZKEEC0 | CIS INSTR EXER | F226C | F865E | F864E | E757R | E441V | S047D | T072A |
| CZMSDB0 | MS11-L/M DIAG | F294B | F865E | F864E | E757R | E441V | S047D | T072A |
| CZQAGG0 | PDP-11 DIAG MAINDEC INDEX | S148G | * | * | * | * | * | * |

117

All of the diagnostics listed may be found on:

| MEDIA | | ORDERING PART # |
|------------------|---|-----------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE | - | BB-F751L-MC |

PDP-11/44

PDP-11/45 BASIC KIT

ZR001-RZ DOCUMENTATION KIT
ZR001-PB PAPERTAPE KIT

| ZR001 KIT CONTENTS: | | DOCUMENT PART # | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI MAGTAPE |
|---------------------|----------------------------|-----------------|-------|-------|-------|-------|-------|-----------------|
| PKG ID | TITLE | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| MD-11-D9EA | MAINTENANCE LOADER | 7635A | * | * | * | * | * | * |
| MD-11-DCQKC | 11/40 & 11/45 INST EXER | 7895G | B079F | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBA | SXT INSTRUCTION | 7782B | 96410 | F873E | E757R | E380V | * | T071A |
| MD-11-DCKBB | SOB INSTRUCTION | 7786B | 96410 | F873E | E757R | E380V | * | T071A |
| MD-11-DCKBC | XOR INSTRUCTION | 7790B | 96410 | F873E | E757R | E380V | * | T071A |
| MD-11-DCKBD | MARK INSTRUCTION | 7794C | 96410 | F873E | E757R | E380V | * | T071A |
| MD-11-DCKBE | RTT INSTRUCTION | 7798C | 96410 | F873E | E757R | E380V | * | T071A |
| CCKBFD0 | 11/40, 45 STACK LIMIT TEST | 7802D | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBG | SPL INSTRUCTION | 7806B | 96410 | F030J | E757R | E380V | * | T071A |
| CCKBH80 | 11/45 REGISTERS | 7812B | 96410 | F030J | E757R | E380V | * | F354N |
| MD-11-DCKBI | ASH INSTRUCTION | 7814B | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBJ | ASHC INSTRUCTION | 7820A | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBK | MUL INSTRUCTION | 7824A | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBL | DIV INSTRUCTION | 7828A | 97410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBM | TRAPS TEST | 7830E | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBN | PIRQ INTERRUPT | 7834C | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBO | 11/45 PROCESSOR STATES | 7840A | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCKBP | 11/45 POWER FAIL TEST | 7842B | 96410 | F030J | E757R | E380V | * | T071A |
| MD-11-DCQKA | MUL/DIV RANDOM EXERCISER | 7891C | B079F | F030J | E757R | E380V | * | T071A |
| CZQKBH0 | T17-4K SYS EXER | 9031H | 9640V | F033K | E754S | E441V | * | T072A |
| MD-11-DZKLA | KL11/DL11-A TEL TESTS | 8846E | 9646T | F034N | E757R | E441V | * | T072A |
| CZQMCG0 | 0-124K MEM EXER 16K | 9045G | 9640V | F033K | E754S | E441V | * | T072A |
| CZKUAE0 | UNIBUS SYS EXER | 8855E | 9640V | F033K | E757R | E441V | S047D | T072A |
| CZKUBC0 | UNIBUS EXER MOD | 8859C | 9640V | F033K | E757R | E441V | S047D | T072A |
| CZQAGG0 | PDP-11 MAINDEC INDEX | S148G | * | * | * | * | * | * |

118

PDP-11/45

ALSO INCLUDED IN ZR001-RZ:

| | | |
|-------------|---------------------------------|-------------|
| DE-11-UABLA | PDP-11 PROGRAMMING CARD | EH-S1046-78 |
| DE-11-UODPA | ABSOLUTE LOADER (VA07) | AB-3196A-TC |
| DE-11-L1PA | ODT-11 ON-LINE DEBUGGER (V004A) | AB-3253A-TC |
| | BOOTSTRAP LOADER (V001A) | AB-1584A-TC |
| | DEC:X11 DOCUMENTATION KIT | ZJ129-RZ |

All of the diagnostics listed may be found on:

| | MEDIA | ORDERING PART # |
|------|-------|--------------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| | | 1600 BPI MAGTAPE - BB-F751L-MC |

PDP-11/70 BASIC KIT

| | |
|----------|-------------------|
| ZR002-RZ | DOCUMENTATION KIT |
| ZR002-PB | PAPERTAPE KIT |
| ZR002-RY | DOC/RX01 KIT |
| ZR002-RF | DOC/MT7 KIT |
| ZR002-RE | DOC/RK05 KIT |
| ZR002-RP | DOC/MT9 KIT |
| ZR002-PY | RX01 KIT |
| ZR002-PF | MT7 KIT |
| ZR002-PD | MT9 KIT |
| ZR002-PE | RK05 KIT |
| ZR002-FR | MICROFICHE KIT |

| <u>ZR002 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|----------------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CEQKCE0 | 11/70 INST EXER | 7994E | 9662N | F031M | E754S | E441V | * | T071A |
| CEKBAD0 | 11/70-74 CUP #1 | 7962D | 9660S | F031M | E754S | E441V | * | T071A |
| CEKBBF0 | 11/70-74 CPU #2 | 7966F | 9660S | F031M | E754S | E441V | * | T071A |
| CEKBCD0 | 11/70-74 CACHE #1 | 0009D | 9660S | F031M | E754S | E441V | * | T071A |
| CEKBDE0 | 11/70-74 CACHE #2 | 7971E | 9660S | F031M | E754S | E441V | * | T071A |
| CEKBEE0 | 11/70 MEM MGMT | 7975E | 9660S | F031M | E754S | E441V | * | T071A |
| CEKBFD0 | 11/70-74 UNIBUS MAP | 7979D | 9660S | F031M | E754S | E441V | * | T071A |
| CEKBGC0 | 11/70-74 POWER FAIL | 7983C | 9660S | F031M | E754S | E441V | * | T071A |
| CEMJAD0 | 11/70 MEM TEST | 7990D | 9661J | F031M | E754S | E441V | * | T071A |
| CZLACF0 | LA36 TERM (DL & KL11 INTF) | 8898F | 9646T | F021P | E757R | E441V | * | T072A |
| CZM9AE0 | BOOT TERM M9301/9400 | 8954E | 9648Q | F021P | E754S | E441V | F668D | T072A |
| CERHAE0 | 11/70-11/74 CNTRL DIAG. | 7999E | 9662N | F885D | E754S | E441V | * | T071A |
| CZM9BD0 | M9312/1144 UBI BOOT | E057D | 9648Q | F021P | E754S | E441V | S046F | T072A |
| CEMKAB0 | 11/70 MAIN MEMORY | C644B | 9661J | F031M | E754S | E441V | * | T071A |

ALSO INCLUDED IN ZR002-RZ:

| | |
|---------------------------|-------------|
| PDP-11 PROGRAMMING CARD | EH-S1046-78 |
| 11/04/34A/44/60/70 | EB-17716-18 |
| PROCESSOR HANDBOOK | |
| PDP-11 MAINDEC INDEX | AC-S148G-MC |
| XXDP + SUPV. USERS MANUAL | AC-F348E-MC |
| DEC/X11 DOCUMENTATION KIT | ZJ129-RZ |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|------------------|------------------------|
| RK06 | - AM-S469D-MC |
| RK07 | - AY-E443U-MC |
| RL02 | - BC-F9161-MC |
| 1600 BPI MAGTAPE | - BB-F751L-MC |

RH11

ZJ155-RZ DOCUMENTATION KIT
ZJ155-PB PAPERTAPE KIT
ZJ155-FR MICROFICHE KIT

ZJ155 KIT CONTENTS:

| | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|---------------|----------------------------|----------------------------|--------------|--------------|--------------|--------------|--------------|----------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZRSBH0 | RH11 - RS03/RS04 BFT | 9314H | B058H | F557K | E755S | F947J | * | T072A |
| CZRSCG0 | RH11 - RS03/RS04 RELIAB | 9318G | B058H | F557K | E755S | F947J | * | T072A |
| MD-11-DZRS0 | RH11 MAINTENANCE MODE | 9322C | B058H | F557K | E755S | F947J | * | T072A |
| MD-11-DZRSE | RH11 MAINTENANCE MODE DIAG | 9326C | B058H | F557K | E755S | F947J | * | F072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

RK06/RK07

ZJ226-RZ DOCUMENTATION KIT
 ZJ226-PB PAPERTAPE KIT
 ZJ226-PG TU58 KIT
 ZJ226-FR MICROFICHE KIT

| <u>ZJ226 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>FX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|-------------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZR6AC0 | RK611 DSKLS CNTRL PRT 1 | 9338C | 9666P | F026J | E755S | F947J | F692F | T072A |
| CZR6BC0 | RK611 DSKLS CNTRL PRT 2 | 9100C | 9666P | F026J | E755S | F947J | F692F | T072A |
| CZR6CD0 | RK611 DSKLS CNTRL PRT 3 | 9104D | 9666P | F026J | E755S | F947J | F692F | T072A |
| CZR6DC0 | RK611 DSKLS CNTRL PRT 4 | 9108C | 9666P | F026J | E755S | F947J | F692F | T072A |
| CZR6EB0 | RK611 DSKLS CNTRL PRT 5 | 9112B | 9666P | F026J | E755S | F947J | F692F | T072A |
| CZR6HE0 | UNIBUS RK6 DR PRT 1 | 9116E | 9667Q | F026J | E755S | F947J | F693G | T072A |
| CZR6IE0 | UNIBUS RK6 DR PRT 2 | 9120E | 9667Q | F026J | E755S | F947J | F693G | T072A |
| CZR6JE0 | UNIBUS RK6 DR PRT 3 | 9125E | 9667Q | F026J | E755S | F947J | F693G | T072A |
| CZR6KF0 | RK6 FCTNL CTRL | 9128F | 9667Q | F026J | E755S | F947J | F693G | T072A |
| CZR6LC0 | RK06L CTG FMTR | 9132C | 9667Q | F026J | E755S | F947J | F693G | T072A |
| CZR6ME0 | RK611/06 SS VFY 1 | 9136E | 9667Q | F026J | E755S | F947J | S066E | T072A |
| CZR6NE0 | RK611/06 SS VFY 2 | 9140E | F752E | F026J | E755S | F947J | S066E | T072A |
| CZR6PC0 | RK611/06 PERF EXER | 9144C | F752E | F026J | E755S | F947J | S066E | T072A |
| CZR6QC0 | RK6 DR CPT PROG | B161C | F752E | F026J | E755S | F947J | S066E | T072A |
| CZR6RC0 | RK611/06 USR DEFINED | 9148C | F752E | F026J | E755S | F947J | S066E | T072A |
| CZR6GB0 | RK611 DU PORT LGC | E033B | 9666P | F026J | E755S | F947J | F692F | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

121

RK06/RK07

ZJ157-RZ DOCUMENTATION KIT
 ZJ157-PB PAPERTAPE KIT
 ZJ157-FR MICROFICHE KIT

ZJ157 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI |
|-------------|------------------------|----------|-------|-------|-------|-------|-------|---------|
| | | PART # | | | | | | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| MD-11-DZRKH | RK11/RK05 PERF EXER | 9232G | 9650Q | F029H | T069A | E441V | * | T072A |
| CZRKIF0 | RK11 UTIL PKG | 9236F | 9650Q | F029H | T069A | E441V | * | T072A |
| MD-11-DZRKJ | RK11 BASIC LOGIC PRT 1 | 9240E | 9650Q | F029H | T069A | E441V | * | T072A |
| CZRKKF0 | RK11 BASIC LOGIC PRT 2 | 9244F | 9650Q | F029H | T069A | E441V | * | T072A |
| MD-11-DZRKL | RK11/RK05 DYNAMIC TEST | 9248E | 9650Q | F029H | T069A | E441V | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

RL01/RL02

ZJ283-RZ DOCUMENTATION KIT
 ZJ283-PB PAPERTAPE KIT
 ZJ283-FR MICROFICHE KIT
 ZJ283-PG TU58 KIT

ZJ283 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI |
|---------|-------------------|----------|-------|-------|-------|-------|-------|---------|
| | | PART # | | | | | | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CZRLGB0 | RL11/RLV11 CTLR 1 | F111B | F547G | F557K | T069A | E441V | F667D | T072A |
| CZRLHB0 | RL11/RLV11 CTLR 2 | F115B | F547G | F557K | T069A | E441V | F667D | T072A |
| CZRLIC0 | RL01/2 DR TST 1 | F119C | F547G | F557K | T069A | E441V | F667D | T072A |
| CZRLJB0 | RL01/2 DR TST 2 | F123B | F547G | F557K | T069A | E441V | F667D | T072A |
| CZRLNA0 | RL01/2 DR TST 3 | F843A | F753E | F557K | T069A | E441V | F667D | T072A |
| CZRLKB0 | RL01/2 PERF EXER | F127B | F547G | F557K | T069A | E441V | F667D | T072A |
| CZRLLB0 | RL01/2 DRIVE CPT | F131B | F753E | F557K | T069A | E441V | F667D | T072A |
| CZRLMB0 | RL01/2 BSFT | F135B | F753E | F557K | T069A | E441V | F667D | T072A |
| CHSADB0 | PT DIAG SUPR BIN | F743A | S067E | * | T069A | E441V | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

123

RL01/RL02

ZJ312 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | 800 BPI | | | | | |
|---------|-----------------------|----------|---------|-------|-------|-------|-------|---------|
| | | PART # | RX01 | RX02 | RK05 | RL01 | TU58 | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CZRMLB0 | RM05/3/2 FORMATTER | F918B | S169C | S172C | E755S | F947J | F707C | T072A |
| CZRMMB0 | RM05/3/2 FCTNL TST 1 | F921B | S169C | S172C | E755S | F947J | F707C | T072A |
| CZRMNB0 | RM05/3/2 FCTNL TST 2 | F924B | S169C | S172C | E755S | F947J | F707C | T072A |
| CZRMOB0 | RM05/3/2 FCTNL TST 3 | F927B | S169C | S172C | E755S | F947J | F707C | T072A |
| CZRMPB0 | RM05/3/2 DSKLS TST 1 | F930B | S169C | S172C | E755S | F947J | F707C | T072A |
| CZRMQB0 | RM05/3/2 DSKLS TST 2 | F933B | S170C | S172C | E755S | F947J | F707C | T072A |
| CZRMRB0 | RM05/3/2 DU POR TST 1 | F936B | S170C | S172C | E755S | F947J | F708C | T072A |
| CZRMSB0 | RM05/3/2 DU POR TST 2 | F939B | S170C | S172C | E755S | F947J | F708C | T072A |
| CZRMTB0 | RM05/3/2 DRV CMPT TST | F942B | S170C | S172C | E755S | F947J | F708C | T072A |
| CZRMUB0 | RM05/3/2 PERF EXER | S069B | S170C | S172C | E755S | F947J | F708C | T072A |
| CZRMVB0 | RM05/3/2 EXT'D DR TST | S072B | S170C | S172C | E755S | F947J | F708C | T072A |

124

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

RP04/5/6

ZJ180-RZ DOCUMENTATION KIT
ZJ180-PB PAPERTAPE KIT
ZJ180-PG TU58 KIT
ZJ180-FR MICROFICHE KIT

ZJ180 KIT CONTENTS:

DOCUMENT PART # RX01 RX02 RK05 RL01 TU58 800 BPI MAGTAPE

| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
|---------------|-----------------------------------|----------------|--------------|--------------|--------------|--------------|--------------|--------------|
| CZRJAD0 | RP04/5/6 RD/WT | 9180D | 9652P | B020E | E755S | F947J | F675C | T072A |
| CZRJBD0 | RP04/5/6 FMTR | 9185D | 9652P | B020E | E755S | F947J | F675C | T072A |
| CZRJCB0 | RP04/5/6 HEAD ALNMT | 9190B | 9652P | B020E | E755S | F947J | F675C | T072A |
| CZRJDD0 | RP04/5/6 MLT DR LGC | 9195D | 9652P | B020E | E755S | F947J | F675C | T072A |
| CZRJEC0 | RP04/5/6 DL CTRLR | 9200C | 9652P | B020E | E755S | F947J | F675C | T072A |
| MD-11-DZRJF | RP04/5/6 DUAL CNTL LOG TEST PRT 2 | 9204A | 9652P | B020E | E755S | F947J | F675C | T072A |
| CZRJGD0 | RP04/5/6 DSKLS CTRLR 1 | 9208A | 9665K | B020E | E755S | F947J | F676C | T072A |
| CZRJHD0 | RP04/5/6 DSKLS | 9213D | 9665K | B020E | E755S | F947J | F676C | T072A |
| CZRJID0 | RP04/5/6 CTRLR 1 | 9218D | 9665K | B020E | E755S | F947J | F676C | T072A |
| CZRJJ00 | RP04/5/6 CTRLR 2 | 9223D | 9665K | B020E | E755S | F947J | F676C | T072A |

ALSO INCLUDED IN ZJ180-RZ:

MD-11-DTUMA M.P.G. USERS MANUAL 8165C

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------------------|------------------------|
| RK06 | - AM-S469D-MC |
| RK07 | - AY-E443U-MC |
| RL02 | - BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | |

ZJ189 KIT CONTENTS:

| <u>PKG ID</u> | <u>TITLE</u> | <u>DOCUMENT</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI</u> |
|---------------|------------------------------|-----------------|--------------|--------------|--------------|--------------|--------------|----------------|
| | | <u>PART #</u> | | | | | | <u>MAGTAPE</u> |
| | | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| MD-11-DZRXA | RX11 SYSTEM RELIABILITY TEST | 9334E | 9669V | F021P | T069A | E441V | F667D | T072A |
| CZRXBFO | RX11 INTERFACE | 9339F | 9669V | F021P | T069A | E441V | F667D | T072A |
| CHSADB0 | PT DIAG SUPR BIN. | F743B | S067E | * | T069A | E441V | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

RX02

ZJ279-RZ
ZJ279-PB
ZJ279-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

| <u>ZJ279 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|-------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZRXDB0 | RX02 SS PERF EXER | E512B | 9653J | F021P | T069A | E441V | F667D | T072A |
| CZRXEA0 | RX02 FMTR PROG | E622A | 9653J | F021P | T069A | E441V | F667D | T072A |
| CZRXFA0 | RX02 FCTN/LGC | E625A | 9653J | F021P | T069A | E441V | F667D | T072A |
| CZRXCA0 | RX02 UTIL DRVR | E509A | 9653J | F021P | T069A | E441V | F667D | T072A |
| CHSADB0 | PT DIAG SUPR BIN | F743B | S067E | * | T069A | E441V | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | |

127

RX02

ZJF12-RZ DOCUMENTATION KIT
 ZJF12-PB PAPERTAPE KIT
 ZJF12-FR MICROFICHE KIT

ZJF12 KIT CONTENTS:

| | | DOCUMENT PART # | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI MAGTAPE |
|-------------|------------------------------|--------------------|-------|-------|-------|-------|-------|--------------------|
| PKG ID | TITLE | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CZTMAIO | TM, A, B-11 INSTR TEST | 9393I | 9654V | F032N | E755S | F947J | * | T072A |
| CZTMBF0 | TM11 DATA RELIAB (9 TRK) | 9398F | 9654V | F032N | E755S | F947J | * | T072A |
| CZTMEE0 | TMA, B-11 DR FCTN TMR | 9410E | 9654V | F032N | E755S | F947J | * | T072A |
| CZTMFF0 | TMA, B-11 SPMNTL INSTR | 9414F | 9654V | F032N | E755S | F947J | * | T072A |
| MD-11-DZTMG | TMA, B-11 UTILITY PKG | 9418C | 9654V | F032N | E755S | F947J | * | T072A |
| MD-11-DZTMH | TMA, B-11 MULTI-DRIVE RELIAB | 9422F | 9654V | F032N | E755S | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

TM02/TU16

ZJ182-RZ DOCUMENTATION KIT
 ZJ182-PB PAPERTAPE KIT

| <u>ZJ182 KIT CONTENTS:</u> | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|----------------------------|------------------------------------|------------------------|--------------|--------------|--------------|--------------|--------------|------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZTUAH0 | TM02/TU16/TE16 RELIABILITY | 9447H | 9654V | F032N | E755S | F947J | * | T072A |
| CZTUBG0 | TM02/TU16/TE16 BSC FC | 9451G | 9654V | F032N | E755S | F947J | * | T072A |
| CZTUCF0 | TM02/TU16/TE16 CTRL LGC | 9455F | 9654V | F032N | E755S | F947J | * | T072A |
| MD-11-DZTUD | TM02/TU16/TE16 DRIVE FUNCTION TEST | 9459D | 9654V | F032N | E755S | F947J | * | T072A |
| MD-11-DZTUE | TU16 UTILITY DRIVE | 9643D | 9654V | F032N | E755S | F947J | * | T072A |
| MD-11-DZTUF | DATA TAPE CREATE | 9467A | 9654V | F032N | E755S | F947J | * | T072A |
| CZTUGC0 | TM02/TE16 DR FCNT TMR | 9471C | 9654V | F032N | E755S | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F916I-MC |
| 1600 BPI MAGTAPE - | BB-F751L-MC |

ZJ272 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI |
|---------|-----------------------|----------|-------|-------|-------|-------|-------|---------|
| | | PART # | | | | | | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CZTUIA0 | TM02/TU45 DATA RELIAB | E469A | E559F | F032N | E757R | F947J | * | T072A |
| CZTUJA0 | TM02/TU45 BSC FCTN | E472A | E559F | F032N | E757R | F947J | * | T072A |
| CZTUKA0 | TM02/TU45 CTRL LGC | E475A | E559F | F032N | E757R | F947J | * | T072A |
| CZTULA0 | TM02/TU45 DR FCTN TMR | E478A | E559F | F032N | E757R | F947J | * | T072A |
| CZTUMA0 | TM02/TU45 UTIL DRVE | E481A | E559F | F032N | E757R | F947J | * | T072A |
| CZTUNA0 | TM02/TU45 DATA TP CRT | E484A | E559F | F032N | E757R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

TM03/TE16

ZJ236-RZ
ZJ236-PB
ZJ236-FR

DOCUMENTATION KIT
PAPERTAPE KIT
MICROFICHE KIT

ZJ236 KIT CONTENTS:

| | | <u>DOCUMENT PART #</u> | <u>RX01</u> | <u>RX02</u> | <u>RK05</u> | <u>RL01</u> | <u>TU58</u> | <u>800 BPI MAGTAPE</u> |
|---------------|----------------------|----------------------------|--------------|--------------|--------------|--------------|--------------|----------------------------|
| <u>PKG ID</u> | <u>TITLE</u> | <u>AC - MC</u> | <u>AS-MC</u> | <u>BA-MC</u> | <u>AN-MC</u> | <u>AX-MC</u> | <u>BE-MC</u> | <u>AP-MC</u> |
| CZTEAC0 | TM03/TE16 TU77 CLT 1 | A791C | A928Q | F032N | E755S | F947J | * | T072A |
| CZTEBB0 | TM03/TE16 TU77 CLT 2 | A794B | A928Q | F032N | E755S | F947J | * | T072A |
| CZTECC0 | TM03/TE16 TU77 BFT | A797C | A928Q | F032N | E755S | F947J | * | T072A |
| CZTEDC0 | TM03/TE16 TU77 DRT | A800C | A928Q | F032N | E755S | F947J | * | T072A |
| CZTEEC0 | TM03/TE16 TU77 DFT | A803C | A928Q | F032N | E755S | F947J | * | T072A |
| CZTEFB0 | TM03/TE16 TU77 UTIL | B158B | A928Q | F032N | E775S | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

ZJ273 KIT CONTENTS:

| PKG ID | TITLE | DOCUMENT PART # | | | | | | 800 BPI |
|---------|-----------------------|-----------------|-------|-------|-------|-------|------|---------|
| | | AC - MC | RX01 | RX02 | RK05 | RL01 | TU58 | MAGTAPE |
| CZTUOB0 | TM03/TU45 LGC PRT 1 | E487B | E559F | F032N | E757R | F947J | * | T072A |
| CZTUPB0 | TM03/TU45 LGC PRT 2 | E490B | E559F | F032N | E757R | F947J | * | T072A |
| CZTUQB0 | TM03/TU45 BSC FCTN | E493B | E559F | F032N | E757R | F947J | * | T072A |
| CZTURB0 | TM03/TU45 DATA RELIAB | E496B | E559F | F032N | E757R | F947J | * | T072A |
| CZTUSB0 | TM03/TU45 DR FCTN TMR | E499B | E559F | F032N | E757R | F947J | * | T072A |
| CZTUTA0 | TM03/TU45 UTIL DRIVER | E502A | E559F | F032N | E757R | F947J | * | T072A |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | <u>ORDERING PART #</u> |
|--------------------------------|------------------------|
| RK06 - | AM-S469D-MC |
| RK07 - | AY-E443U-MC |
| RL02 - | BC-F9161-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | |

XXDP + OPERATING SYSTEM

| PKG ID | TITLE | DOCUMENT PART # | | | | | | 800 BPI |
|---------|-----------------------|-----------------|-------|-------|-------|-------|-------|---------|
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | MAGTAPE |
| | | | | | | | | |
| CHSAAC0 | XXDP + DIAG SUPR BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHSABBO | APT DIAG SUPR BIN | | S067E | * | E754S | E380V | * | T071A |
| CHSACB0 | ACT DIAG SUPR BIN | | S067E | * | E754S | E380V | * | T071A |
| CHUDIB0 | XXDP + MONTR DIR BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHQHLB0 | XXDP + HELP TEXT FILE | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHSADB0 | PT DIAG SUPR BIN | | S067E | * | E754S | E380V | * | T071A |
| CHDMMB0 | XXDP + MM R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDMTB0 | XXDP + MT R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDMSB0 | XXDP + MS R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDBB0 | XXDP + DB R/W DRV BIN | | F747G | F019I | E754S | E380V | F665F | T071A |
| CHDDDB0 | XXDP + DD R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDKB0 | XXDP + DK R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDLCO | XXDP + DL R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDMB0 | XXDP + DM R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDPB0 | XXDP + DP R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDRBO | XXDP + DR R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDSB0 | XXDP + DS R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDCTA0 | XXDP + CT R/W DRV BIN | | * | * | * | * | F665F | * |
| CHDDTB0 | XXDP + DT R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDXB0 | XXDP + DX R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDDYB0 | XXDP + DY R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDKBB0 | XXDP + KB R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDLPA0 | XXDP + LP W/O DRV BIN | | * | F019I | E754S | E380V | F665F | T071A |
| CHDPDB0 | XXDP + PD R/W DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDPPB0 | XXDP + PP W/O DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDPRB0 | XXDP + PR R/O DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHDPTB0 | XXDP + PT W/O DRV BIN | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHMCTA1 | XXDP + CT MONITOR BIN | | * | * | * | * | F665F | * |
| CHMDBB1 | XXDP + DB MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMDDB1 | XXDP + DD MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMDKB1 | XXDP + DK MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMDLC1 | XXKP + DL MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMDMB1 | XXDP + DM MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMDPB1 | XXDP + DP MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMDRB1 | XXDP + DR MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |

| PKG ID | TITLE | DOCUMENT | RX01 | RX02 | RK05 | RL01 | TU58 | 800 BPI |
|---------|--------------------------|----------|-------|-------|-------|-------|-------|---------|
| | | PART # | | | | | | MAGTAPE |
| | | AC - MC | AS-MC | BA-MC | AN-MC | AX-MC | BE-MC | AP-MC |
| CHMDSB1 | XXDP + DS MONITOR BIN | | F747G | F019I | E754S | E380V | F6663 | T071A |
| CHMDTB1 | XXDP + DT MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMDXB2 | XXDP + DX MONITOR BIN | | S067E | F019I | E754S | E380V | F666E | T071A |
| CHMDYB2 | XXDP + DY MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMMMB1 | XXDP + MM MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMMSB1 | XXDP + MS MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMMTB1 | XXDP + MT MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHMPDB1 | XXDP + PD MONITOR BIN | | F747G | F019I | E754S | E380V | F666E | T071A |
| CHUP1B0 | XXDP + UPD 1 UTIL | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHUP2B1 | XXDP + UPD 2 UTIL | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHUTEB1 | XXDP + XTECO UTIL | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHUXCB0 | XXDP + DEC/X11 CNF/LNK | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHUSUB0 | XXDP + SETUP UTIL | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHQXBA0 | XXDP + BLD FILE | | 9639Q | F019I | E754S | E380V | F665F | T071A |
| CHUPAB0 | XXDP + PATCH FILE | | S067E | F019I | E754S | E380V | F666E | T071A |
| CHQSE0 | XXDP + SUPV USERS MANUAL | F348E | * | * | * | * | * | * |

All of the diagnostics listed may be found on:

| <u>MEDIA</u> | | <u>ORDERING PART #</u> |
|--------------------------------|---|------------------------|
| RK06 | - | AM-S469D-MC |
| RK07 | - | AY-E443U-MC |
| RL02 | - | BC-F916I-MC |
| 1600 BPI MAGTAPE - BB-F751L-MC | | |

Index by Kit Number

INDEX

| | | | |
|-------------|---|------------|----|
| FB-00861 | 3 | FB-DK8-AA | 9 |
| FB-00866 | 3 | FB-DL11-W | 10 |
| FB-00871 | 3 | FB-DLV11-E | 10 |
| FB-00872 | 3 | FB-DLV11-F | 10 |
| FB-00874 | 3 | FB-DLV11-J | 10 |
| FB-11/04 | 3 | FB-DLV11-K | 10 |
| FB-11/05 | 3 | FB-DM11-A | 10 |
| FB-11/15 | 4 | FB-DM11-B | 10 |
| FB-11/20 | 4 | FB-DM11-D | 10 |
| FB-11/23 | 4 | FB-DMC11 | 10 |
| FB-11/23-B | 4 | FB-DN11 | 11 |
| FB-11/24 | 4 | FB-DPV11 | 11 |
| FB-1134A | 5 | FB-DQ11 | 11 |
| FB-11/35 | 5 | FB-DR11-B | 11 |
| FB-11/40 | 5 | FB-DR11-C | 11 |
| FB-11/44 | 5 | FB-DR11-K | 11 |
| FB-11/45 | 5 | FB-DR11-L | 11 |
| FB-11/60 | 6 | FB-DR11-M | 11 |
| FB-11/70-01 | 6 | FB-DR11-W | 11 |
| FB-11/70-02 | 6 | FB-DRS11 | 11 |
| FB-AA11-K | 6 | FB-DRV11 | 12 |
| FB-AAV11 | 6 | FB-DRV11-B | 12 |
| FB-AD11-K | 6 | FB-DRV11-J | 12 |
| FB-ADV11 | 7 | FB-DRV11-P | 12 |
| FB-AM11-K | 7 | FB-DSS11 | 12 |
| FB-AR11 | 7 | FB-DU11 | 12 |
| FB-BA11-A | 7 | FB-DUP11-D | 12 |
| FB-BA11-F | 7 | FB-DUV11 | 12 |
| FB-BA11-K | 7 | FB-DV11 | 12 |
| FB-BA11-L | 7 | FB-DW08-A | 12 |
| FB-BA11-M | 7 | FB-DW08-B | 13 |
| FB-BA11-N | 7 | FB-DW780 | 13 |
| FB-BA11-P | 8 | FB-DZ11-A | 13 |
| FB-BA11-R | 8 | FB-DZ11-C | 13 |
| FB-BA11-S | 8 | FB-DZ32 | 13 |
| FB-BA11-U | 8 | FB-DZV11 | 13 |
| FB-BA11-V | 8 | FB-FP11-A | 13 |
| FB-BDV11 | 8 | FB-FP11-B | 13 |
| FB-BM873-YB | 8 | FB-FP11-C | 13 |
| FB-DB11-A | 8 | FB-FP11-EA | 14 |
| FB-DD11-A | 8 | FB-FP11-F | 14 |
| FB-DD11-B | 8 | FB-FP780 | 14 |
| FB-DD11-C | 8 | FB-FPF11 | 14 |
| FB-DD11-D | 9 | FB-FPP8-A | 14 |
| FB-DD11-K | 9 | FB-FPP8-E | 14 |
| FB-DD11-P | 9 | FB-H312 | 14 |
| FB-DF02 | 9 | FB-H319 | 14 |
| FB-DF03 | 9 | FB-H7100 | 14 |
| FB-DH11 | 9 | FB-H7104 | 14 |
| FB-DK8-EF | 9 | FB-H7422 | 14 |
| FB-DK8-EP | 9 | FB-H745 | 15 |
| FB-DK8-ES | 9 | FB-H754 | 15 |


INDEX

| | | | |
|-------------|----|-------------|----|
| FB-H765 | 15 | FB-LA180 | 20 |
| FB-H766 | 15 | FB-LA34 | 20 |
| FB-H775 | 15 | FB-LA35 | 21 |
| FB-H950 | 15 | FB-LA36 | 21 |
| FB-H9500 | 15 | FB-LA38 | 21 |
| FB-H9501 | 15 | FB-LAV11 | 21 |
| FB-H9506 | 15 | FB-LK40 | 21 |
| FB-H9610 | 15 | FB-LP25 | 21 |
| FB-H960-D | 15 | FB-LPA11-K | 21 |
| FB-H9600 | 15 | FB-LPC01 | 21 |
| FB-H9602-C | 16 | FB-LPD11-A | 22 |
| FB-H9612 | 16 | FB-LPS11 | 22 |
| FB-H9642 | 16 | FB-LS120 | 22 |
| FB-IB11 | 16 | FB-M7850 | 22 |
| FB-IBV11 | 16 | FB-M9301 | 22 |
| FB-KA8-E | 16 | FB-M9302 | 22 |
| FB-KA750 | 16 | FB-M9312 | 22 |
| FB-KA780 | 16 | FB-MA780 | 22 |
| FB-KC750 | 17 | FB-ME11-L | 22 |
| FB-KC780 | 17 | FB-MF11-L | 23 |
| FB-KC8-AA | 17 | FB-MF11-LP | 23 |
| FB-KC8-E | 17 | FB-MF11-U | 23 |
| FB-KD11-F | 17 | FB-MF11-WP | 23 |
| FB-KD11-HA | 17 | FB-MF11S-K | 23 |
| FB-KE11-A | 18 | FB-MJ11 | 23 |
| FB-KE11-B | 18 | FB-MK11 | 23 |
| FB-KE11-E | 18 | FB-ML11 | 23 |
| FB-KE11-F | 18 | FB-MM11-CP | 23 |
| FB-KE44-A | 18 | FB-MM11-DP | 24 |
| FB-KE8-E | 18 | FB-MM11-E | 24 |
| FB-KEV11 | 18 | FB-MM11-F | 24 |
| FB-KG11-A | 18 | FB-MM11-L | 24 |
| FB-KG8-EA | 18 | FB-MM11-LP | 24 |
| FB-KJ11-A | 18 | FB-MM11-S | 24 |
| FB-KK11-B | 18 | FB-MM11-U | 24 |
| FB-KM8-AA | 19 | FB-MM11-WP | 24 |
| FB-KM8-E | 19 | FB-MM11-YP | 25 |
| FB-KP8-E | 19 | FB-MM8-EJ | 25 |
| FB-KPV11 | 19 | FB-MMV11-A | 25 |
| FB-KT11-C | 19 | FB-MRV11-AA | 25 |
| FB-KT11-D | 19 | FB-MRV11-AC | 25 |
| FB-KW11-K | 19 | FB-MRV11-BA | 25 |
| FB-KW11-L | 19 | FB-MRV11-BC | 25 |
| FB-KW11-P | 19 | FB-MRV11-C | 25 |
| FB-KW11-W | 19 | FB-MRV11-VA | 25 |
| FB-KWV11-A | 20 | FB-MRV11-VC | 25 |
| FB-KY11-C | 20 | FB-MS11-AP | 25 |
| FB-KY11-LA | 20 | FB-MS11-B | 25 |
| FB-KY11-LB | 20 | FB-MS11-CC | 26 |
| FB-KY11-P | 20 | FB-MS11-FP | 26 |
| FB-LA120 | 20 | FB-MS11-K | 26 |
| FB-LA120-RA | 20 | FB-MS11-L | 26 |

INDEX

| | | | |
|-----------------|----|------------------|----|
| FB-MS11-M | 26 | FB-RP06..... | 31 |
| FB-MS750..... | 26 | FB-RP07..... | 31 |
| FB-MS780..... | 26 | FB-RP11-C..... | 31 |
| FB-MSV11-B..... | 26 | FB-RP11-E..... | 31 |
| FB-MSV11-C..... | 26 | FB-RPR02..... | 31 |
| FB-MSV11-D..... | 26 | FB-RX01..... | 31 |
| FB-MSV11-E..... | 26 | FB-RX02..... | 31 |
| FB-MSV11-P..... | 27 | FB-RX11..... | 32 |
| FB-PC05..... | 27 | FB-RX211..... | 32 |
| FB-PC11..... | 27 | FB-RX8..... | 32 |
| FB-PDP8A..... | 27 | FB-RXMM2-B..... | 32 |
| FB-PDP8E..... | 27 | FB-RXMM2-C..... | 33 |
| FB-PDP8F..... | 27 | FB-RXMM3-B..... | 33 |
| FB-PDP8M..... | 27 | FB-RXMM3-C..... | 34 |
| FB-RPS01..... | 28 | FB-RXV11..... | 34 |
| FB-RA80..... | 28 | FB-RXV21..... | 34 |
| FB-REV11..... | 28 | FB-TE10N..... | 34 |
| FB-RH11..... | 28 | FB-TE10W..... | 34 |
| FB-RH70..... | 28 | FB-TE16..... | 34 |
| FB-RH750..... | 28 | FB-TEV11..... | 35 |
| FB-RH780..... | 28 | FB-TM02..... | 35 |
| FB-RK05F..... | 28 | FB-TM03..... | 35 |
| FB-RK05J..... | 28 | FB-TM78..... | 35 |
| FB-RK06..... | 28 | FB-TS11..... | 35 |
| FB-RK07..... | 29 | FB-TU16..... | 35 |
| FB-RK11-C..... | 29 | FB-TU45..... | 35 |
| FB-RK11-D..... | 29 | FB-TU58..... | 35 |
| FB-RK611..... | 29 | FB-TU77..... | 35 |
| FB-RKV11-D..... | 29 | FB-TU78..... | 36 |
| FB-RL01..... | 29 | FB-UDA50..... | 36 |
| FB-RL02..... | 29 | FB-VK100..... | 36 |
| FB-RL11..... | 29 | FB-VT100..... | 36 |
| FB-RL8A..... | 29 | FB-VT101..... | 36 |
| FB-RLV11..... | 30 | FB-VT102..... | 36 |
| FB-RLV12..... | 30 | FB-VT1XX-AB..... | 36 |
| FB-RM02..... | 30 | FB-VT1XX-AC..... | 37 |
| FB-RM03..... | 30 | FB-VT1XX-CA..... | 37 |
| FB-RM05..... | 30 | FB-VT50..... | 37 |
| FB-RM80..... | 30 | FB-VT52..... | 37 |
| FB-RP04..... | 30 | FB-VT55..... | 37 |
| FB-RP05..... | 30 | | |

New Literature From Digital



Finally! A single reference source of selected Digital hardware and software documentation products. This new directory makes necessary product information readily accessible and it can be used to determine what documentation products are required to support a particular hardware or software option.

The Directory contains:

SOFTWARE DOCUMENTATION PRODUCTS

- Software Documentation Kits
- Source Microfiche Kits
- Software Manuals, Handbooks, Reference Cards

HARDWARE DOCUMENTATION PRODUCTS

- Hardware Manuals
- Maintenance Prints
- Diagnostic Kits


OTHER FEATURES

- Ordering/Pricing Information
- Accessories & Supplies Group Discount Policy
- System Software Organization
- Understanding Digital's Software Numbering Scheme
- Glossary of Software Terms and Abbreviations
- Documentation Index by Ordering Part Number
- Documentation Index by Description

- Do you always have the necessary documentation at your fingertips?
- Do you know which Digital Engineering changes are applicable to your system?


If you can't answer 'yes' to both of these questions, Digital's Maintenance Documentation Service (MDS) can help.

MDS provides almost all service documentation on microfiche: maintenance manuals, illustrated parts breakdowns, diagnostic listings, diagnostic change orders, diagnostic patch orders, wire lists, Field Change Orders (FCO's), Preventive Maintenance (PM) procedures, and a wealth of other useful information.



- Are you always up-to-date with the latest hardware changes? If not, DEC-O-LOG may be the answer!

DEC-O-LOG is a valuable notification service. A subscription to DEC-O-LOG provides essential information for all Digital customers who maintain their own systems. DEC-O-LOG is a summary of Field Change Orders (FCO's) and Engineering Change Orders (ECO's) for your system's CPU's, peripheral options, subassemblies and modules.



To obtain a copy of any of the above literature fill in and cut out the coupon on the opposite page.

Clip and mail to:

Digital Equipment Corporation
Attn: Circulation Dept. RQ/W83
460 Amherst Street
Nashua, NH 03063

For more information about the products or services described on the opposite page, check the appropriate box(es) below.

- Documentation Products Directory
- Maintenance Documentation Service (MDS) Brochure
- DEC-O-Log Brochure
- Please add me to your mailing list

Name _____

Title _____

Organization _____

Address _____

City, State, Zip _____

Tel./Ext. _____

Hardware Documentation Kit Handbook

Spring 1982

PRINTED IN USA EB 19769 75/82 Copyright © 1982 DIGITAL EQUIPMENT CORPORATION

digital

**We change the way
the world thinks.**

DIGITAL EQUIPMENT CORPORATION
Accessories & Supplies Group
Nashua, N.H. 03063