

29B Programmer Adapter #	256K memory Module/Adapter	Pak	Version	990-0013-056 Part #	Own(2) Own
308A	Module	LogicPak	4	950-1942-008F	Yes(3)
303A002	Adapter		5,6,7,8		Yes(1)
303A003	Adapter		1		
303A004	Adapter		1,2,3		
303A006	Adapter		3,4		Yes(2)
303A007	Adapter		1		
303A008A	Module		2		
303A008B	Adapter		2		
303A009	Adapter		1,2,3,4		Yes(1)
303A010	Adapter		3		
303A011A	Adapter		1thru 17 & 18		Yes(1)
303A011B	Adapter		1 thru 8		
303A012	Adapter		1,2,3		
303A100	Adapter	PALASM	1,2,3	715-1114-001A	Yes(1)
303A101	Adapter		1,2,3,4		
303AECL	Adapter		1		
303AFAIM	Adapter		1,4		
303AAFPC	Adapter		2,3		
303AMECL	Adapter		1		
303ANECL	Adapter		1		
303APLX	Adapter		N/A		
303ATIECL	Adapter		1, 1.1		
UniPak2B	Module	UniPak2B			Yes(1)
350A021	Circuit Card				
351A076B	Module				
351A084	Adapter				
351B066			7,13,15,17,20		
351B067	Module		7		
351B068			7		
351B070B			7,11,13,15,18,27		
351B071			7,9		
351B072	Adapter		7		
351B073			7,9		
351B086	Adapter		7,8,9,11-27	715-0004-001	Yes(1)
351B087			7,9,14,15,18,21		
351B088			7,9,14,18,20,21		
351B089			7,9,18,21		
351B090			9,13,14		
351B092			7,9,15		
351B093			7,9,13,14,15,17,18,20,21,27		
351B094			11		
351B095			11-14,16-27		
351B095P			15-19,21,24,26,27		
351B096			12,26		
351B097			13		
351B099			9,13-23,25-27		
351B101			11,13,17,18,19,23,27		
351B102			11		
351B103	Adapter		15,16,17,21,23,24		

351B103/122D		12,13,17
351B103P		15,16,18-21,24
351B103P/122P		14,25
351B104BD		11,13,15,17-27
351B104BP		27
351B104P/BP		17-27
351B106D		16,20
351B106P		17,22
351B107		11
351B108		11,13
351B109		11
351B110		11
351B111D		17
351B111P		17
351B113D		20
351B120D	Adapter	16-19, 21-27
351B121		20
351B122D		21,25,26
351B122P		21,23,25
351B123D		23,24
351BAMD	Adapter	11
351BZ8		14