

PX3 OWNER'S MANUAL ERRATA

Rev. A2-1, October 17, 2014

MAKE THESE CHANGES TO YOUR REV A2 MANUAL

IMPORTANT NOTE: Items 4 and 5 (below) refer to an assembly error many builders have made. Be sure you mount the plastic bezel that covers the display screen on the **OUTSIDE** of the enclosure as shown in Figure 30 on page 40.

1. **Page 9, PX3 Signal Cabling with KXPA100 Amplifier and KX3 to KXPA100 Adapter Cable:**

Add the following note:

⚠ When used with the KXPA100 Amplifier connected as shown here, the PX3 RS232 data rate must be set to 38400 baud (see menu entry RS232 on page 29).

2. **Page 37, Parts List, Front Panel Board, E850624:** Delete the note that reads:

“One pin has been cut on the 40-pin connector on the reverse side.
This is intentional.”

A few early boards had an unused pin cut off. It is left in place on later boards.

3. **Page 22, Configuring the Power Switch:** Delete the paragraph starting with “Pins 2 & 3:...” Only configurations with pins 3 & 4 and pins 1 & 2 are applicable.

4. **Page 43, Figure 30.** Add the following directly under the figure:

⚠ Be sure you have mounted the plastic bezel on the **OUTSIDE** of the front panel as shown in Figure 30.

5. **Page 45, Figure 34.** Add the following directly under the figure:

⚠ If the side panel does not fit as shown, be sure you have mounted the plastic bezel over the display screen on the **OUTSIDE** of the front panel as shown in Figure 30.