

Manual Supplement

Manual Title:	7321 Users Guide	Supplement Issue:	2
Part Number:	3750942	Issue Date:	5/15
Print Date:	October 2013	Page Count:	1
Revision/Date:			

This supplement contains information necessary to ensure the accuracy of the above manual.

FLUKE®

Calibration

Change #1

On page 3-2, after the last bullet in the **Environmental Conditions** section, add:

Note

The Product can show some control sensitivity to moderate or severe electromagnetic fields or conducted interference of certain frequencies. In the presence of radiated EM disturbances, with frequencies of 250 MHz to 400 MHz and with amplitude >1 V/m to a maximum of 3 V/m, add 0.0025 °C to the stability specification. Stability is not guaranteed if amplitude is >3 V/m. When subject to conducted disturbances of 8 MHz to 80 MHz, and amplitude >3 V, add 0.005 °C to the stability specification.

Change #2, 154

On page 5-2, replace **5.3.2** paragraph, with:

5.3.2 Installation On A Concrete Floor

Using a concrete drill and concrete drill bit, drill three 1/4 inch x 1 3/4 inch deep (approximately 6.5 mm x 32 mm) holes in the concrete floor using the bracket to mark the hole placement. Drop the flare anchor bolt into the hole. Tightening the screw expands the anchor in the drilled hole and secures the bracket. Ensure that the bracket is installed in such a way as to ensure the bath will have a minimum of 6 inches of clearance for air circulation (See Figure 2). Screw the bracket securely to the floor.